

Part #	Part Description	Part no
79641	SEALING RING C/SFT	TATA spare parts
0000140021J	G/KIT OIL SUMP	TATA spare parts
180702	ASSY.CAP	TATA spare parts
184235	ASSY.BREATHER CAP	TATA spare parts
374519	TOP RING 697 TC	TATA spare parts
0000550050J	ROCKER ARM BUSH	TATA spare parts
0000741160DB	LEVEL GAUGE	TATA spare parts
0000780053J	RUBBER PIECE	TATA spare parts
92290600	KIT SEALS	TATA spare parts
940355	LOCKING DEVICE	TATA spare parts
0000940506DB	FILTER COVER	TATA spare parts
947280	SEALING FELT	TATA spare parts
0001300023J	SET PISTON RING STD	TATA spare parts
0001300123J	RINGSET STD 1&2	TATA spare parts
0001310050J	CONNECTING ROD BUSH 74D	TATA spare parts
1317311	N RING NORMAL GR-I	TATA spare parts
1317411	RING PISTON 1ST STD1&2	TATA spare parts
1317511	RING PISTON 2	TATA spare parts
1317611	RING PISTON 2	TATA spare parts
0001420080J	GASKET EXHAUST MANIFOLD	TATA spare parts
0001500127J	CLUTCH ASSY	TATA spare parts
000150016J	BASE BRUSH GEAR	TATA spare parts
0001500327DB	STARTER CLUTCH	TATA spare parts
0001510001J	STARTER MOTOR	TATA spare parts
0001510006J	COVER	TATA spare parts
0001510009J	FIELD COIL MAIN	TATA spare parts
0001510013J	PINION W/BRG	TATA spare parts
0001510014J	BRUSH SET	TATA spare parts
0001510015J	ARMATURE	TATA spare parts
0001510016J	BASE BRUSH GEAR	TATA spare parts
0001510017J	THROUGH STUD	TATA spare parts
0001510028J	DRIVE END SHIELD W/BRG	TATA spare parts
0001510034J	SOL SWITCH	TATA spare parts
0001510046J	OUTER CLUTCH RACE	TATA spare parts
0001510047J	CLUTCH PLATE	TATA spare parts
0001510048J	CL PLATE STEEL	TATA spare parts
0001510049J	C END BRG	TATA spare parts
0001510051J	SPRING WASHER	TATA spare parts
0001510052J	SPACER	TATA spare parts
0001510055J	TERMINAL POSITIVE	TATA spare parts
0001510056J	NEGATIVE TERMINAL	TATA spare parts
0001510065J	CONNECTOR	TATA spare parts
0001510069J	PLUNGER ASSY	TATA spare parts
0001510071J	SCREW	TATA spare parts
0001510072J	PLUNGER NUT	TATA spare parts
0001510074J	GUIDE PIN	TATA spare parts

0001510081J	OIL SEAL	TATA spare parts
0001510109J	FIELD COIL AUX	TATA spare parts
0001510114J	BRUSH SET (4)	TATA spare parts
0001510128J	C/END SHIELD	TATA spare parts
0001510148J	C.E BRACKET ASSY	TATA spare parts
0001510149J	D E BEARING	TATA spare parts
0001510151J	BACK RING	TATA spare parts
0001510152J	SHIM 0.10 MM	TATA spare parts
0001510155DB	UKU/A/OMAIN FIELD COIL	TATA spare parts
0001510162J	WASHER	TATA spare parts
0001510171J	HEX HEAD SCREW	TATA spare parts
0001510172DB	CASTLE NUT	TATA spare parts
0001510172J	TERMINAL NUT	TATA spare parts
0001510193J	PINION SPRING	TATA spare parts
0001510201J	STARTER MOTOR	TATA spare parts
0001510246J	INNER CLUTCH RACE	TATA spare parts
0001510252J	SHIM 0.15 MM	TATA spare parts
0001510271J	SCREW BRUSH	TATA spare parts
0001510352J	SHIM	TATA spare parts
0001510371J	POLE SCREW	TATA spare parts
0001510393J	PRESSURE SPRING	TATA spare parts
0001510471J	SCREW COVER END BEARING	TATA spare parts
0001510493J	SPRING	TATA spare parts
0001540006J	REG CUT OUT	TATA spare parts
0001540007J	COVER ASSEMBLY	TATA spare parts
0001540010J	PULLEY 160 WATT	TATA spare parts
0001540014J	BRUSH SET-2	TATA spare parts
0001540015J	ARMATURE 160W OLD	TATA spare parts
0001540016J	FAN ASSEMBLY	TATA spare parts
0001540018J	CONTACT SET C/O	TATA spare parts
0001540020J	TERM INSUL PLATE	TATA spare parts
1540025	FIELD COIL-1	TATA spare parts
0001540025J	FIELD COIL 160W	TATA spare parts
0001540030J	COMMUTATOR END BEARING	TATA spare parts
0001540050J	TERMINAL INSULATION BUSH	TATA spare parts
0001540051J	BEARING COLLAR	TATA spare parts
0001540062J	WASHER	TATA spare parts
0001540063J	LOCK WASHER	TATA spare parts
0001540064J	RIVET	TATA spare parts
0001540070J	STUD THROUGH STUD	TATA spare parts
0001540071J	POLE SCREW	TATA spare parts
0001540074J	FIXING BOLT	TATA spare parts
0001540075J	LOCK WASHER	TATA spare parts
0001540078J	KEY 5415-0016	TATA spare parts
0001540106J	REGULATOR CUTOFF 300 WATT	TATA spare parts
0001540114J	BRUSH SET-4	TATA spare parts
0001540115J	ARMATURE 300W	TATA spare parts

0001540116J	PULLEY 300 WATT	TATA spare parts
0001540118J	CONTACT SET V/R	TATA spare parts
0001540120J	RETAINING PLATE	TATA spare parts
0001540125J	FIELD COIL 300 WATT	TATA spare parts
0001540130J	DRIVE END BRG 300 WATT	TATA spare parts
0001540150J	TERMINAL INSULATION BUSH	TATA spare parts
0001540152J	TERMINAL INSUL WASHER	TATA spare parts
0001540162J	WASHER	TATA spare parts
0001540163J	LOCK WASHER	TATA spare parts
0001540164J	RIVET	TATA spare parts
0001540165J	DOWEL	TATA spare parts
0001540193J	SPRING 300W	TATA spare parts
0001540202J	DYNAMO 300 WATT	TATA spare parts
0001540215J	ARMATURE 160W	TATA spare parts
0001540218J	CONTACT SET C/R	TATA spare parts
0001540220J	BEARING RETAINER PLATE	TATA spare parts
0001540245J	DRIVE END BRACKET	TATA spare parts
0001540250J	RUBBER BUSHING	TATA spare parts
0001540254J	THERMIAL WASHER	TATA spare parts
0001540306J	REGULATOR 300 W	TATA spare parts
0001540318J	CONTACT SET C/O	TATA spare parts
0001540330J	DRIVE END BRG 160 WATT	TATA spare parts
0001540345J	COMMUTATOR END BRACKET	TATA spare parts
0001540358J	TERMINAL	TATA spare parts
0001540402J	DYNAMO 300W	TATA spare parts
0001540407J	LEAD ASSEMBLY	TATA spare parts
0001540445J	C END BKT 15MM	TATA spare parts
0001540471J	SCREW	TATA spare parts
0001540507J	LEAD ASSEMBLY	TATA spare parts
0001540602J	DY NAMO	TATA spare parts
0001540645J	D.E.BRACKET	TATA spare parts
0001540758J	TERMINAL	TATA spare parts
0001544014DB	CARBON BRUSHSET	TATA spare parts
1544314	SET CARBON BRUSH	TATA spare parts
0001550063J	KEY	TATA spare parts
0001840024J	COVER RING	TATA spare parts
0001840025J	STRAINER	TATA spare parts
2010197	SEALING MEMBER	TATA spare parts
2010463	SLIDING RING	TATA spare parts
2013619	AXIAL SLIDE RING SEAL	TATA spare parts
2013719	SEAL SLIDING	TATA spare parts
0002030075J	THERMOSTAT	TATA spare parts
0002030175J	THERMOSTAT	TATA spare parts
0002210301J	ENGINE NUMBER PLATE	TATA spare parts
0002500004J	ASSY.CLUTCH PRSSURE PLATE	TATA spare parts
0002500103J	ASSY.CLUTCH DISC/H2122/	TATA spare parts
0002500104J	ASSY.PRESSURE PLATE	TATA spare parts

0002500503J	ASSY.CLUTCH DISC	TATA spare parts
0002500603J	CLUTCH DISC 3.5	TATA spare parts
2520016	PIN	TATA spare parts
2520018	NEEDLE	TATA spare parts
2520024	SHIM	TATA spare parts
0002520110J	CLUTCH LINING	TATA spare parts
2520120	SPRING	TATA spare parts
0002520122DB	PRESSURE SPRING	TATA spare parts
2520175	RIVET	TATA spare parts
2520375	RIVET	TATA spare parts
2520516	PIN	TATA spare parts
2520527	SPRING	TATA spare parts
2520713	BRACKET	TATA spare parts
2521014	SUPPORT	TATA spare parts
2521171	ADJ NUT	TATA spare parts
2521232	PROTECTIVE HOUSING	TATA spare parts
2540020	CLUTCH BEARING	TATA spare parts
2540120	CLUTCH RELEASE BEARING	TATA spare parts
278624521213	KIT GEAR BOX GASKETS	TATA spare parts
0002610080J	SEALING RING	TATA spare parts
0002610179J	GEAR BOX GASKET KIT GBC30	TATA spare parts
0002920182J	RUBBER COVER ACCL PEDAL	TATA spare parts
0003230053J	SLEEVE UPPER	TATA spare parts
3230150	JOINT BUSHING	TATA spare parts
3230153	JOINT BUSHING	TATA spare parts
3230353	JOINT BUSHING	TATA spare parts
3230453	JOINT BUSHING LPT 1313	TATA spare parts
3230585	RUBBER	TATA spare parts
3230685	JOINT RUBBER	TATA spare parts
3231585	JOINT RUBBER LOWER	TATA spare parts
3232685	MOUNTING SLEEVE	TATA spare parts
0003260100J	ASSY SHOCK ABSORBER REAR	TATA spare parts
0003300003J	REPAIR KIT-TIE ROD BS1/2/3/4	TATA spare parts
3380026	CUP BALL SOCKET LOW PART	TATA spare parts
3380027	BALL CUP	TATA spare parts
3380227	BALL CUP	TATA spare parts
3380331	LOCKING CAP	TATA spare parts
0003380427DB	BALL CUP	TATA spare parts
3380431	LOCKING CAP	TATA spare parts
3380493	PRESSURE SPRING	TATA spare parts
3380693	PRESSURE SPRING	TATA spare parts
3380727	BALL CUP	TATA spare parts
3380910	BALL SOCKET	TATA spare parts
3381656	DUST CAP	TATA spare parts
3382230	BALL SOCKET HSG	TATA spare parts
3382415	TUBE TIE ROD	TATA spare parts
3382629	ASSY. BALL JOINT LH BS1/2/3/4	TATA spare parts



3383429	ASSY. BALL JOINT RH BS1/2/3/4	TATA spare parts
3383530	BALL SOCKET HSG	TATA spare parts
3383629	BALL SOCKET M28 X1.5 RH	TATA spare parts
0003383629AE	BALL SOCKET HEAD ASSY. 713 715	TATA spare parts
3383630	BALL SOCKET HSG	TATA spare parts
0004000002J	NEW1	TATA spare parts
0004010006J	SIDE RING	TATA spare parts
0004010007J	LOCKING RING	TATA spare parts
0004010106J	SIDE RING	TATA spare parts
0004010306J	SIDE RING	TATA spare parts
0004010307J	LOCK RING	TATA spare parts
0004010506J	SIDE RING LP/LPT1109	TATA spare parts
0004010507J	LOCKING RING	TATA spare parts
4011015	TYRE FLAP for 10 x 20 tyre	TATA spare parts
0004011707DB	LOCK RING	TATA spare parts
4016310	TYRE 9.0 X 20 - 12 PLY CROSS COUNTRY	TATA spare parts
0004200018J	WHEEL CYL 31.8 DIA FRT	TATA spare parts
4200055	BLEEDER VALVE	TATA spare parts
0004200060J	SPRING ASSY	TATA spare parts
0004200118J	WHEEL BRAKE CYLINDER 38.1 DIA	TATA spare parts
0004200160J	SPRING ASSY	TATA spare parts
0004200218J	WHEEL CYL 44.45 DIA RR	TATA spare parts
0004200260J	SPRING ASSY	TATA spare parts
0004210187J	DUST COVER	TATA spare parts
4210887	DUST CAP	TATA spare parts
4211888	SLOTTED PIN	TATA spare parts
0004212089DB	FILLER	TATA spare parts
0004212783DB	PISTON	TATA spare parts
4213883	PISTON	TATA spare parts
0004230069J	BLEEDING SCREW W/O D CAP	TATA spare parts
4230076	SPRING RETAINER	TATA spare parts
4230083	PISTON	TATA spare parts
0004230083J	PISTON PLUNGER	TATA spare parts
4230086	PISTON CUP	TATA spare parts
0004230086J	CUP SEAL	TATA spare parts
0004230087J	REP KIT WHEEL CYLINDER FR	TATA spare parts
4230088	PIN WHEEL CYLINDER	TATA spare parts
0004230088J	PUSH ROD	TATA spare parts
4230093	PRESSURE SPRING	TATA spare parts
0004230099J	WHEEL CYL KIT	TATA spare parts
0004230147J	PUSH ROD	TATA spare parts
0004230177J	CUP SEAL	TATA spare parts
0004230183J	PISTON	TATA spare parts
4230186	PISTON CUP	TATA spare parts
0004230186J	CUP SEAL	TATA spare parts
4230187	PROT CAP	TATA spare parts
0004230187J	RR W/CYL KIT	TATA spare parts

4230188	PIN WHEEL CYLINDER	TATA spare parts
4230284	SCREW NIPPLE	TATA spare parts
0004230287J	DUST COVER	TATA spare parts
0004230387J	DUST COVER	TATA spare parts
0004230487J	REP KIT WHEEL CYLINDER	TATA spare parts
0004230587J	WHEEL CYL KIT	TATA spare parts
0004230687J	REP KIT WHEEL CYLINDER	TATA spare parts
4230886	PISTON CUP	TATA spare parts
4230888	PIN WHEEL CYLINDER	TATA spare parts
4231083	PISTON	TATA spare parts
4231290	STOP SPRING	TATA spare parts
4232083	PISTON	TATA spare parts
0004280024J	NIPPLE	TATA spare parts
4280026	HOLLOW SCREW	TATA spare parts
0004280026J	HOLLOW SCREW	TATA spare parts
0004280035J	HOSE HIGH PRESSURE	TATA spare parts
0004280073J	HOLDER	TATA spare parts
4280124	ANGULAR NIPPLE	TATA spare parts
0004280172J	COUPLING NUT	TATA spare parts
0004280235J	BRAKE HOSE	TATA spare parts
0004280335J	BRAKE HOSE FRONT	TATA spare parts
0004280435J	BRAKE HOSE	TATA spare parts
4280473	HOLDER-BRAKE HOSE	TATA spare parts
0004280535J	ASSY BRAKE HOSE D&WI	TATA spare parts
4284735	BRAKE HOSE 55OMM	TATA spare parts
4290037	JUNCTION BLOCK	TATA spare parts
0004290037J	JUNCTION BLOCK	TATA spare parts
0004290057J	DUMMY COUPLING	TATA spare parts
0004290140DB	SUPPORT	TATA spare parts
0004290330J	PALM COUPLING M	TATA spare parts
0004290330JAE	PALM COUPLING YELLOW 715	TATA spare parts
0004290430J	PALM COUPLING EMERGENCY	TATA spare parts
0004290430JAE	PALM COUPLING EMERGENCY 715	TATA spare parts
0004290431J	SHUT OFF COCK	TATA spare parts
4290437	JUNCTION BLOCK	TATA spare parts
0004300003J	ASSY.VALVE SCREW	TATA spare parts
4300081	CAP VALVE	TATA spare parts
0004300081J	KIT VALVE SEAT	TATA spare parts
0004300102J	CONTAINER	TATA spare parts
4300289	THRUST SPRING	TATA spare parts
0004300901J	ASSY MASTER CYLINDER	TATA spare parts
0004301001J	ASSY MASTER CYLINDER	TATA spare parts
0004301201J	M/CYL W/A NUT	TATA spare parts
0004301301J	MASTER CYLINDER 1.25AS	TATA spare parts
0004310001J	REP KIT MASTER CYLINDER	TATA spare parts
0004310023J	VALVE INLET EXHAUST	TATA spare parts
0004310072J	NUT	TATA spare parts

0004310076J	COPPER WASHER	TATA spare parts
0004310079J	GUIDE SEAL	TATA spare parts
0004310083J	REACTION PISTON	TATA spare parts
4310086	PISTON SLEEVE	TATA spare parts
0004310086J	BACK SEAL	TATA spare parts
4310089	SPRING RETAINER	TATA spare parts
0004310089J	SPRING KEEPER	TATA spare parts
0004310090J	PLUG	TATA spare parts
0004310093J	COIL SPRING	TATA spare parts
0004310099J	R/KIT MINOR	TATA spare parts
0004310120J	CYLINDER	TATA spare parts
0004310121J	VALVE HOUSING	TATA spare parts
0004310122J	COVER	TATA spare parts
0004310123J	VALVE	TATA spare parts
0004310125J	VALVE GUIDE	TATA spare parts
0004310129J	IDENTIFICATION TAG	TATA spare parts
0004310159J	SPRING GUIDE	TATA spare parts
0004310176J	COPPER WASHER	TATA spare parts
0004310186J	CUP SEAL	TATA spare parts
0004310187J	GAITER	TATA spare parts
0004310190J	PLUG	TATA spare parts
0004310193J	SPRING	TATA spare parts
0004310199J	REPAIR KIT MAJOR	TATA spare parts
4310260	SEALING RING	TATA spare parts
0004310263J	VALVE PLUNGER	TATA spare parts
4310265	BLEEDER VALVE	TATA spare parts
0004310274J	BOLT	TATA spare parts
0004310283J	PISTON ASSY.	TATA spare parts
0004310293J	PISTON RETN SPG	TATA spare parts
0004310299J	REPAIR KIT	TATA spare parts
0004310321J	VALVE HOUSING	TATA spare parts
0004310334J	FLUID FILTER	TATA spare parts
0004310381J	VALVE STEM	TATA spare parts
0004310383J	REACTION PISTON	TATA spare parts
4310389	SPRING RETAINER	TATA spare parts
0004310399J	REPAIR KIT-MINOR	TATA spare parts
0004310412J	DIAPHRAM	TATA spare parts
0004310423J	VALVE INLET EXHAUST	TATA spare parts
0004310463J	PLUNGER	TATA spare parts
0004310476J	WASHER	TATA spare parts
0004310499J	REPAIR KIT MAJOR	TATA spare parts
0004310506J	AIR PRESSURE REGULATOR	TATA spare parts
0004310560J	SEALING RING	TATA spare parts
0004310576J	WASHER	TATA spare parts
4310585	FILLER WASHER	TATA spare parts
0004310587J	GAITER	TATA spare parts
0004310599J	REP KIT PR REGULATOR	TATA spare parts

0004310676J	WASHER	TATA spare parts
0004310681DB	VALVE RETAINER	TATA spare parts
4310685	FILLER WASHER	TATA spare parts
4310693	PRESSURE SPRING	TATA spare parts
0004310705J	VALVE	TATA spare parts
0004310776J	WASHER	TATA spare parts
0004310799J	REP KIT PR REGULATOR	TATA spare parts
0004310893J	SPRING	TATA spare parts
0004310999J	REPAIR KIT	TATA spare parts
0004311099J	REP KIT FOOT CONTR VALVE	TATA spare parts
0004311276J	WASHER	TATA spare parts
0004311476J	SPECIAL WASHER	TATA spare parts
4311876	SPACER	TATA spare parts
0004312386DB	SEALING RING	TATA spare parts
0004312493DB	COIL SPRING	TATA spare parts
4312683	PISTON M/C	TATA spare parts
0004312706DB	AIR GOVERNOR	TATA spare parts
0004312793DB	COIL SPRING	TATA spare parts
4320084	GASKET RING	TATA spare parts
0004340075J	PISTON SKIRT	TATA spare parts
0004340084J	SPRING	TATA spare parts
0004340184J	SPRING	TATA spare parts
0004340284J	VALVE SPRING	TATA spare parts
0004600005J	REP KIT DRAG LINK	TATA spare parts
0004600105J	REP KIT DRAG LINK	TATA spare parts
4610879	GASKET	TATA spare parts
0004612852DB	SHIM 0.12 MM	TATA spare parts
0004620627DB	UPPER BALL RACE	TATA spare parts
0004621150DB	BUSH	TATA spare parts
4630027	BALL CUP	TATA spare parts
4630030	BALL SOCKET HSG	TATA spare parts
4630293	PRESSURE SPRING	TATA spare parts
4630331	LOCKING CAP	TATA spare parts
4630456	SEALING CAP	TATA spare parts
4631616	DRAG LINK TUBE	TATA spare parts
0004640120J	HORN BUTTON	TATA spare parts
0004640201J	STEERING WHEEL	TATA spare parts
0004640420J	COVER ASSY	TATA spare parts
4641320	HORN BUTTON	TATA spare parts
0004710034J	COMPRESSION SPRING	TATA spare parts
0004710052J	SEALING RING	TATA spare parts
0004710080J	GASKET	TATA spare parts
0004710280J	RUBBER RING FUEL TANK CAP	TATA spare parts
0004770201J	DOUBLE FUEL FILTER	TATA spare parts
4770329	OVERFLOW VALVE	TATA spare parts
0005000006J	FILLER CAP	TATA spare parts
0005000106J	RADIATOR CAP BS2/4	TATA spare parts

0005000206J	RADIATOR CAP	TATA spare parts
0005000509J	T EMBLEM	TATA spare parts
0005000701J	RADIATOR ASSY W/CAP L/LP	TATA spare parts
0005200105J	RETAINING SCREW	TATA spare parts
0005240188J	HOSE CLIP 75 A WORM	TATA spare parts
0005270068J	1210 MASCOT	TATA spare parts
0005400054J	HEAD LAMP LH RHD	TATA spare parts
0005400144J	ASSY PUSH & PULL SWITCH	TATA spare parts
0005400154J	ASSY REC HD LAMP RH/RHD	TATA spare parts
0005400176J	BATTERY CLAMP	TATA spare parts
0005400254J	ASSY REC HD LAMP LH/LHD	TATA spare parts
0005400354J	HEAD LAMP RH LHD	TATA spare parts
0005400495J	BLINKER LAMP LH	TATA spare parts
0005400595J	BLINKER LAMP RH	TATA spare parts
0005400954J	ASSY.RECT.HEAD LAMP RH	TATA spare parts
0005420002J	OIL PRESS GAUGE	TATA spare parts
0005420020J	HORN 12V	TATA spare parts
0005420035J	HOSE	TATA spare parts
5420083	HOSE	TATA spare parts
0005420083J	HOSE	TATA spare parts
5420084	PLUG WATER TEMP.GAUGE.	TATA spare parts
0005420106J	SPEEDOMETER	TATA spare parts
0005420107J	SPEEDO CABLE	TATA spare parts
0005420184J	PLUG TELE THERMOMETER	TATA spare parts
0005420204J	FUEL TANK UNIT	TATA spare parts
0005420304J	FUEL TANK UNIT	TATA spare parts
0005420307J	SPEEDO CABLE	TATA spare parts
0005420324J	AMMETER	TATA spare parts
0005420502J	OIL PRESSURE GAUGE 9-0 CL	TATA spare parts
0005420507J	FLEX.SPEEDO CABLE	TATA spare parts
0005420605J	WATER TEMP GAUGE	TATA spare parts
0005420607J	SPEEDO CABLE 1550MM	TATA spare parts
0005420705J	WATER TEMP GAUGE	TATA spare parts
0005420707J	SPEEDO CABLE 3015MM	TATA spare parts
0005420807J	SPEEDO CABLE 2660MM	TATA spare parts
0005420907J	SPEEDOMETER CABLE 2830 LG	TATA spare parts
0005440003J	BLACKOUT LAMP	TATA spare parts
0005440048J	RUBBER FLAP	TATA spare parts
0005440068J	MAP READING LAMP	TATA spare parts
0005440068JAE	MAP READING LAMP 1628	TATA spare parts
0005440069J	SCREW & WASHER	TATA spare parts
0005440080J	LENS GASKET	TATA spare parts
0005440089J	RIM GREY	TATA spare parts
0005440090J	LENS HEAD LAMP LH RHD	TATA spare parts
0005440091J	LENS RETG SPRG	TATA spare parts
0005440092J	REFLECTOR LH	TATA spare parts
0005440097J	DECORATIVE RIM	TATA spare parts

0005440101J	HEAD LAMP	TATA spare parts
0005440103J	TAIL LAMP BLACKOUT LAMP	TATA spare parts
5440105	SAFETY REFLECTOR	TATA spare parts
0005440105J	SAFETY REFLECTOR	TATA spare parts
0005440130J	REVERSING LAMP	TATA spare parts
0005440169J	LENS RETG SCREW	TATA spare parts
0005440180J	HOUSING GASKET	TATA spare parts
0005440189J	RIM-HEAD LAMP OLIVE GREEN	TATA spare parts
0005440190J	LENS RH	TATA spare parts
0005440192J	REFLECTOR RH	TATA spare parts
0005440203J	CONVOY LAMP	TATA spare parts
0005440203JAE	CONVOY LAMP 1628	TATA spare parts
5440204	SAFETY REFLECTOR	TATA spare parts
5440205	SAFETY REFLECTOR	TATA spare parts
0005440205J	SAFETY REFLECTOR	TATA spare parts
0005440230J	BLINKER LAMP	TATA spare parts
0005440269J	RIM FXG SCREW	TATA spare parts
0005440280J	GASKET RIM	TATA spare parts
0005440290J	LENS LH LHD	TATA spare parts
0005440292J	REFLECTER LH	TATA spare parts
0005440332J	BLINKER UNIT	TATA spare parts
0005440390J	HEAD LAMP LENS LIFT	TATA spare parts
0005440392J	REFLECTR RH LHD	TATA spare parts
0005440430J	BLINKER LAMP LP	TATA spare parts
0005440503J	TAIL LAMP NO PLATE	TATA spare parts
0005440530J	BLINKER LAMP	TATA spare parts
0005440580J	GASKET BLINKER LENS LH	TATA spare parts
0005440603J	BRAKE TAIL LIGHT	TATA spare parts
0005440680J	GASKET BLINKER LENS RH	TATA spare parts
0005440703J	TAIL LAMP LH	TATA spare parts
5440705	SAFETY REFLECTOR	TATA spare parts
0005440793J	BULB HOLDER	TATA spare parts
5440814	LAMP BLACKOUT FRONT	TATA spare parts
5440880	RUBBER GASKET	TATA spare parts
0005440903J	TAIL LAMP RH	TATA spare parts
0005440990J	LENS BLINKER LH LP	TATA spare parts
0005441003J	ROUND TAIL LAMP LH	TATA spare parts
0005441090J	LENS BLINKER RH LP	TATA spare parts
0005441103J	TAIL LAMP RH ROUND	TATA spare parts
5441292	REFLECTOR	TATA spare parts
5441394	BULB F12V-15W	TATA spare parts
5441493	LAMP SOCKET	TATA spare parts
0005441693DB	LAMP SOCKET	TATA spare parts
5442180	RUBBER GASKET	TATA spare parts
5442389	RIM	TATA spare parts
5442590	GLASS	TATA spare parts
5444003	LAMP BLACKOUT REAR	TATA spare parts

5448232	BLINKER UNIT	TATA spare parts
0005450001J	FUSE BOX	TATA spare parts
0005450004J	CHANGE OVER SWITCH21/80N BLACKOUT	TATA spare parts
0005450004JAE	CHANGEOVER SWITCH-BLACKOUT 1628	TATA spare parts
0005450007J	SWITCH PANEL LIGHT	TATA spare parts
0005450012J	DIPPER SWITCH	TATA spare parts
0005450030J	REP KIT COMBI SWITCH	TATA spare parts
0005450075J	LENTILE HD CSK SCREW	TATA spare parts
0005450092J	BASE PLATE ASSEMBLY	TATA spare parts
0005450095J	PRESSURE PIECE	TATA spare parts
0005450107J	SWITCH PARKING LIGHT	TATA spare parts
0005450109J	STOP LIGHT SWITCH	TATA spare parts
0005450113J	MAIN LIGHT SWITCH	TATA spare parts
0005450117J	GLOW PLUG SWITCH	TATA spare parts
0005450124J	BLINKER SWITCH	TATA spare parts
0005450126J	SOCKET W/COVER	TATA spare parts
0005450128J	PLUG 12 POLE	TATA spare parts
0005450135J	SWITCH KEY	TATA spare parts
0005450207J	SWTICH HEAD LIGHT	TATA spare parts
0005450208J	IGNITION SWITCH	TATA spare parts
0005450209J	STOP LIGHT SWITCH	TATA spare parts
0005450219J	BULB SOCKET	TATA spare parts
5450306	REVERSING LAMP SWITCH	TATA spare parts
0005450369J	PIANO KEY SWITCH/HD.LAMP/	TATA spare parts
0005450426J	PLUG HD LAMP	TATA spare parts
0005450435J	KEY	TATA spare parts
0005450469J	PIANO KEY SWITCH	TATA spare parts
5450525	LAMP SOCKET	TATA spare parts
5450537	KNOB BLACK	TATA spare parts
0005450537J	KNOB	TATA spare parts
0005450569J	PIANO KEY SWITCH 3P WIPER	TATA spare parts
0005450607J	CHANGE OVER SWITCH	TATA spare parts
5450719	LAMP SOCKET	TATA spare parts
0005451026DB	SOCKET 7 POLE	TATA spare parts
0005451235DB	KEY	TATA spare parts
5452209	BR LIGHT SWITCH	TATA spare parts
5452226	12 POLE SOCKET	TATA spare parts
5453115	INDICATOR LAMP	TATA spare parts
5455011	REVERSE LIGHT SWITCH	TATA spare parts
0005460041J	CABLE CONN7POLE	TATA spare parts
0005460088J	HOUSING 9 POLE	TATA spare parts
0005460188J	HOUSING 9 POLE WHITE	TATA spare parts
0005460488J	SLEEVE ADAPTOR	TATA spare parts
0005460588J	HOUSING FEMALE HEAD	TATA spare parts
5461241	CABLE CONNECTOR	TATA spare parts
0005810026J	SPANNER ADJUSTABLE	TATA spare parts
0005810058J	TYRE LEVER	TATA spare parts

5810758	TYRE LEVER	TATA spare parts
0005810801J	BOX SPANNER 27 A/F	TATA spare parts
5811701	SOCKET WRENCH SW 24/27	TATA spare parts
0005830018J	GREASE GUN	TATA spare parts
0005830196J	KEY RING	TATA spare parts
0005830272J	DIPSTICK 160 LITER	TATA spare parts
0005830318J	GREASE GUN	TATA spare parts
5830421	BRAKE BLEEDING TUBE- HYD.BRKE	TATA spare parts
5831315	LIFTING JACK	TATA spare parts
5832418	GREASE GUN	TATA spare parts
0005840102J	NUMBER PLATE	TATA spare parts
0005850001J	TOOL BAG	TATA spare parts
0005850088J	TOOL BAG	TATA spare parts
5890001	WRENCH - FRT AXLE NUT	TATA spare parts
0005890001J	WRENCH - FRT AXLE NUT	TATA spare parts
5890019	ADAPTOR	TATA spare parts
0005890019J	ADAPTER DI	TATA spare parts
5890037	RING PISTON EXPANDER	TATA spare parts
0005890111J	SPECIAL SCREW DRIVER	TATA spare parts
5890113	LOCK SCREW FOR INJ TIMER	TATA spare parts
0005890113J	SCREW DRIVER	TATA spare parts
0005890119J	INJECTOR REMOVER TOOL	TATA spare parts
5890209	30 BI-1/2SQ-87L SOC/FIT & REMOVE PR S	TATA spare parts
0005890209J	SPANNER DI	TATA spare parts
5890235	PULLER	TATA spare parts
5890309	SOCKET	TATA spare parts
5890509	WRENCH FOR CAP NUT HP LINE	TATA spare parts
0005890509J	SOCKET WRENCH	TATA spare parts
5890603	CROW FOOT SPANNER	TATA spare parts
5890753	REAMER ADJUSTING 34X39	TATA spare parts
5890905	HOOK WRENCH	TATA spare parts
5890907	EXTN ROD	TATA spare parts
5893763	TORQUE MULTIPLIER	TATA spare parts
0005900058J	BASE & OUTER TUBE	TATA spare parts
0005910002J	TYRE INFLATOR	TATA spare parts
0005910035J	TUBE ASSY	TATA spare parts
0005910090DB	VALVE RETAINER	TATA spare parts
0005910095J	VALVE	TATA spare parts
0005910099J	REPAIR KIT	TATA spare parts
0005910176J	SPECIAL WASHER	TATA spare parts
0005910187J	OIL FILTER CAP	TATA spare parts
0005910193J	SPRING	TATA spare parts
0005910202DB	TYRE INFLATOR	TATA spare parts
0005910202J	TYRE INFLATOR	TATA spare parts
0005910220DB	FILTER ELEMENT	TATA spare parts
0005910288J	COVER TYRE INFLATOR	TATA spare parts
0005910293J	RELIEF VALVE	TATA spare parts



0005910360J	SEALING RING	TATA spare parts
5910404	INFLATOR HOSE	TATA spare parts
0006710021J	RUBBER MOULDING LH & RH	TATA spare parts
0006710221J	RUBBER MOULDING LH & RH	TATA spare parts
0006710321J	RUBBER MOULDING	TATA spare parts
0006710421J	RUBBER MOULDING RH	TATA spare parts
0006710910J	WIND SHIELD GLASS RH SHEET QUALITY	TATA spare parts
0006780351J	RUBBER MOULDING	TATA spare parts
0006780451J	RUBBER MOULDING	TATA spare parts
0006782010J	REAR CURVED GLASS	TATA spare parts
0006782110J	REAR CURVED GLASS	TATA spare parts
0006890034J	SPRING	TATA spare parts
0006980580J	BEADING SIDE	TATA spare parts
0006980680J	BEADING CENTRE	TATA spare parts
0007200075J	DOOR HANDLE INNER LH	TATA spare parts
0007200175J	DOOR HANDLE INNER RH	TATA spare parts
0007230174J	CAP HINGE	TATA spare parts
0007250079J	HANDLE LH SFC CAB	TATA spare parts
0007250179J	HANDLE RH SFC CAB	TATA spare parts
0007250258J	CHANNEL WINDOW REGULATOR	TATA spare parts
0007250366J	RUBBER PAD SFC CAB	TATA spare parts
0007250910J	GLASS TURNING WINDOW SFC	TATA spare parts
0007251010J	GLASS/SF CAB/V-2	TATA spare parts
0007252810J	DOOR GLASS-REGULATING	TATA spare parts
0007270430J	COVER FRONT LH	TATA spare parts
0007270530J	COVER/FRONT/RH/SF CAB/V-1	TATA spare parts
0007500179J	M/B EMBLEM	TATA spare parts
0007520461J	T EMBLEM L	TATA spare parts
0007520661J	T EMBLEM LP OLD	TATA spare parts
7550007	SQUARE KEY CENTRE FLAP	TATA spare parts
0007600060J	DOVETAIL	TATA spare parts
0007660010J	INNER HANDLE/SF CAB/V-2	TATA spare parts
0007660047J	CHANNEL FOR LIFTING WINDOW/V-2(ZP)	TATA spare parts
0007660101J	DOOR HANDLE OUTER	TATA spare parts
0007660301J	DOOR HANDLE OUTER WITH KEY/SF CAB/V-1	TATA spare parts
0007660302J	DOOR HANDLE OUT W/O KEY	TATA spare parts
0007660360J	DOVETAIL TRIPP	TATA spare parts
0007660760J	DOVETAIL POST SFC CAB	TATA spare parts
7670101	CENTRE FLAP LOCK OLD	TATA spare parts
0007680066J	HANDLE W/CAP SFC CAB	TATA spare parts
0007680201J	WINDOW REGULATOR LH	TATA spare parts
0007680301J	WINDOW REGULATOR RH	TATA spare parts
0007680401J	WINDOWREGULATOR LH	TATA spare parts
0007680501J	WINDOW REGULATOR RH	TATA spare parts
0008100030J	REAR VIEW MIRROR	TATA spare parts
0008100034J	ASH TRAY	TATA spare parts
0008100054J	ASSY.GRAB HANDLE	TATA spare parts

0008100230J	REAR VIEW MIRROR	TATA spare parts
0008100530J	REAR VIEW MIRROR	TATA spare parts
0008101018J	TATA BADGE	TATA spare parts
0008130005J	COVER ASH TRAY	TATA spare parts
0008150015J	BRACKET DOOR LH	TATA spare parts
3959400	SLEEVE PIPE	TATA spare parts
0008150074J	CENTRE BOLT	TATA spare parts
0008150115J	BRACKET DOOR RH	TATA spare parts
0008152814J	BRACKET DOOR STRAP	TATA spare parts
0008200037J	KIT ACCES WIPER MOTOR 17W	TATA spare parts
0008200039J	LINK END ASSY RH	TATA spare parts
0008200044J	WIPER ARM BUS	TATA spare parts
0008200045J	WIPER BLADE BUS	TATA spare parts
0008200139J	LINK END ASSY LH	TATA spare parts
0008200144J	WIPER BLADE	TATA spare parts
0008200145J	WIPER ARM	TATA spare parts
0008200244J	WIPER BLADE	TATA spare parts
0008200245J	WIPER ARM	TATA spare parts
0008200344J	WIPER MOTOR	TATA spare parts
0008200444J	ASSY WIPER ARM RHD	TATA spare parts
0008200445J	WIPER ARM	TATA spare parts
0008200544J	WIPER ARM	TATA spare parts
0008200645J	WIPER BLADE	TATA spare parts
0008200940J	ASSY.WIPER ARM WITH BLADE	TATA spare parts
0008240008J	FINAL GEAR ASSY	TATA spare parts
0008240029J	BUNDY TUBE FRT	TATA spare parts
0008240107J	WHEEL BOX	TATA spare parts
0008240129J	BUNDY TUBE CEN	TATA spare parts
0008240207J	WHEEL BOX	TATA spare parts
0008240229J	BUNDY TUBE RR	TATA spare parts
0008240329J	BUNDY TUBE CEN	TATA spare parts
0008240407J	WHEEL BOX	TATA spare parts
0008240601J	WIPER MOTOR	TATA spare parts
8260384	LOADED SPRING	TATA spare parts
8260684	CLAMPING SPRING	TATA spare parts
8261784	SPRING	TATA spare parts
0008370035J	SPRING	TATA spare parts
0008910044J	RUBBER BUFFER FR LOWER	TATA spare parts
0008910201J	RUBBER MOUNTING	TATA spare parts
0008910298J	PACKING U BOLT	TATA spare parts
0008910301J	RUBBER PAD	TATA spare parts
0008910444J	RUBBER BUFFER FRONT	TATA spare parts
0008910497J	RUBBER PAD	TATA spare parts
0008910544J	RUBBER BUFFER LOWER	TATA spare parts
0008910597J	RUBBER MOUNTING	TATA spare parts
0009800034J	TURN BUCKLE	TATA spare parts
0009800290J	ASSY LETTER T/PLASTIC/	TATA spare parts

0009800390J	LETTER A PLASTIC	TATA spare parts
9810027	ANGULAR CONTACT BEARING	TATA spare parts
0009810027DB	A/CONTACT BRG	TATA spare parts
0009810105J	TAPER ROLLER BEARING INNER	TATA spare parts
9810512	BEARING ROLLER CAGE	TATA spare parts
9810518	BEARING AXIAL ROLLER	TATA spare parts
0009810518DB	AXIAL ROLLER BEARING	TATA spare parts
9810527	BEARING BALL FOUR POINT	TATA spare parts
9810712	ROLLER CAGE	TATA spare parts
9810713	ROLLER CAGE	TATA spare parts
9810806	BEARING TAPER ROLLER	TATA spare parts
9811187	BEARING NEEDLE CAGE	TATA spare parts
9811201	CYL. ROLLER BRG NU309N BS1/2/3/4	TATA spare parts
9811487	NEEDLE	TATA spare parts
9811918	TAPER ROLLER THRUST BEARING	TATA spare parts
9812587	NEEDLE ROLLER	TATA spare parts
9812687	NEEDLE ROLLER	TATA spare parts
9812827	ANGULAR CONTACT BEARING	TATA spare parts
9812927	FOUR POINT BEARING	TATA spare parts
9814005	BEARING TAPER ROLLER	TATA spare parts
9814105	TAPER ROLLER BEARING OUTER	TATA spare parts
0009814205DB	TAPPER ROLLER BEARIING	TATA spare parts
9814227	BALL BEARING-4POINT	TATA spare parts
0009814227DB	BALL BEARING	TATA spare parts
9814312	BEARING ROLLER CAGE	TATA spare parts
9814327	4 POINT BALL BEARING	TATA spare parts
9815312	NEEDLE ROLLER BRG	TATA spare parts
9815905	TAP ROLLER BEARING	TATA spare parts
9816105	BEARING	TATA spare parts
0009816105DB	TAPERED ROLLER BEARING	TATA spare parts
9816112	BEARING ROLLER CAGE	TATA spare parts
9817112	BEARING ROLLER CAGE	TATA spare parts
9817205	BEARING TAPER ROLLER	TATA spare parts
9818601	CYL.ROLLER BEARING	TATA spare parts
9818701	CYL.ROLLER BEARING	TATA spare parts
0009818701DB	BALL BEARING	TATA spare parts
9818905	BEARING TAPER ROLLER	TATA spare parts
9819001	CYL ROLLER BEARING	TATA spare parts
0009819001DB	CYL ROLLER BEARING	TATA spare parts
9819305	BEARING TAPER ROLLER	TATA spare parts
9819405	CONICAL ROLLER BEARING	TATA spare parts
9819512	ROLLER CAGE	TATA spare parts
9819601	CYL ROLLER BRG	TATA spare parts
0009819601DB	ROLLER BRG	TATA spare parts
9819605	BEARING TAPER ROLLER	TATA spare parts
9819612	ROLLER CAGE	TATA spare parts
9819801	CYL.ROLLER BEARING	TATA spare parts

9819901	CYL.ROLLER BEARING	TATA spare parts
9819905	CONICAL ROLLER BEARING	TATA spare parts
0009831010DB	FELT STRAP	TATA spare parts
9840461	SPRING CLAMP	TATA spare parts
0009870035J	PROFILE FILLER RUBBER	TATA spare parts
0009870042J	RUBBER SPACER	TATA spare parts
0009870135J	PROFILE	TATA spare parts
0009870142J	RUBBER SPACER	TATA spare parts
0009870464J	RUBBER PROFILE LP FACE	TATA spare parts
0009870541J	LEATHER WASHER	TATA spare parts
0009870641J	RUBBER RING	TATA spare parts
0009870940J	RUBBER BUFFER	TATA spare parts
0009871240J	RUBBER BUFFER	TATA spare parts
9872935	RUBBER PROFILE	TATA spare parts
9873330	BEADING	TATA spare parts
9880270	LEAD SEAL	TATA spare parts
9880363	SNAP LOCK	TATA spare parts
0009900006J	HEX HEAD BOLT	TATA spare parts
0009900027J	KNOB ASSY	TATA spare parts
0009900041J	WAVED WASHER	TATA spare parts
0009900050J	WHEEL NUT	TATA spare parts
0009900066J	DOUBLE SOCKET	TATA spare parts
0009900096J	HALF ROUND RIVET 5/16X15	TATA spare parts
0009900105J	STUD BOLT	TATA spare parts
0009900111J	SET SCREW	TATA spare parts
0009900150J	WHEEL NUT	TATA spare parts
0009900156J	LOCKING RING	TATA spare parts
0009900211J	BOLT	TATA spare parts
0009900256J	ROUND NUT	TATA spare parts
0009900311J	BOLT	TATA spare parts
0009900398J	SPLIT PIN	TATA spare parts
0009900498J	SPLIT PIN	TATA spare parts
9900567	CLAMPING RING	TATA spare parts
9900596	HALF RD COLD RIVET 12X28	TATA spare parts
0009900598J	SPLIT PIN	TATA spare parts
0009900651J	NYLOCK NUT M8	TATA spare parts
0009900796J	SNAP HEAD RIVET 5/16X1	TATA spare parts
0009900851J	NYLOCK NUT	TATA spare parts
0009900947J	LOCK WASHER	TATA spare parts
0009900996DB	COLD RIVET	TATA spare parts
9901096	HALF RD COLD RIVET 12X38	TATA spare parts
9901138	SCREW	TATA spare parts
0009901140J	WASHER	TATA spare parts
0009901347J	SPECIAL WASHER	TATA spare parts
9901396	HALF RD COLD RIVET 10X26	TATA spare parts
0009901440J	SEALING RING	TATA spare parts
0009901547J	SPRING WASHER	TATA spare parts

9901596	COLD RIVET 10X42	TATA spare parts
9901796	COLD RIVET 10X32	TATA spare parts
9902396	HALF RD COLD RIVET 12X44	TATA spare parts
9902555	CASTLE NUT	TATA spare parts
9902596	HALF RD COLD RIVET 10X35	TATA spare parts
9902651	HEX NUT M14 X 1.5	TATA spare parts
9902996	HALF RD COLD RIVET 10X40	TATA spare parts
0009903008J	TAPPING SCREW	TATA spare parts
0009903151J	HEX NUT	TATA spare parts
0009907206J	HEX SCREW	TATA spare parts
0009908020J	ADJUSTING SCREW	TATA spare parts
0009908925J	SCREW	TATA spare parts
0009910029J	STEEL BALL	TATA spare parts
9910522	BALL END	TATA spare parts
0009930005J	SPRING	TATA spare parts
0009930020J	SPRING RETAINER	TATA spare parts
0009930605DB	SPRING	TATA spare parts
0009938601DB	COIL SPRING	TATA spare parts
0009940011J	WASHER	TATA spare parts
9940037	HOOK SNAP RING	TATA spare parts
0009940040J	CIRCLIP	TATA spare parts
0009940235J	CIRCLIP	TATA spare parts
9940237	LOCKING RING	TATA spare parts
0009940237J	CIRCLIP	TATA spare parts
0009940335J	CIRCLIP	TATA spare parts
0009940435J	CIRCLIP	TATA spare parts
0009940537J	CIRCLIP	TATA spare parts
0009940637J	CIRCLIP	TATA spare parts
0009940837J	CIRCLIP	TATA spare parts
9941437	CIRCLIP	TATA spare parts
9942835	SNAP RING	TATA spare parts
9946041	CIRCLIP	TATA spare parts
9947941	CIR CLIP	TATA spare parts
0009947941DB	SNAP RING	TATA spare parts
9948241	CIRCLIP	TATA spare parts
0009950120J	CLIP	TATA spare parts
0009950202J	HOSE CLIP	TATA spare parts
9950544	CLAMP	TATA spare parts
0009960034J	TURN BUCKLE	TATA spare parts
0009970006J	PLUG OIL FILLING	TATA spare parts
0009970006JAE	PLUG OIL FILLING 1828	TATA spare parts
0009970036J	DRAINING VALVE M18X1.5 TAPER	TATA spare parts
0009970040J	SEALING RING	TATA spare parts
0009970045J	O RING	TATA spare parts
0009970047J	OIL SEAL	TATA spare parts
0009970053J	RUBBER CLAMP	TATA spare parts
0009970145J	O RING	TATA spare parts

0009970147J	GASKET RING CR SHAFT FRT	TATA spare parts
0009970149J	GASKET	TATA spare parts
0009970183J	ELBOW	TATA spare parts
0009970281J	RUBBER GROMMET	TATA spare parts
0009970304J	PLUG M22	TATA spare parts
0009970344J	COPPER SYNTHETIC WASHER	TATA spare parts
9970506	SCREW PLUG OIL FILLING	TATA spare parts
9970581	RUBBER TUBE	TATA spare parts
0009970581J	RUBBER GROMMET	TATA spare parts
0009970645J	O RING	TATA spare parts
0009970781J	RUBBER GROMMET	TATA spare parts
0009970945J	O RING	TATA spare parts
0009971145J	O RING	TATA spare parts
9971236	FUEL COCK 3 WAY	TATA spare parts
9971437	WRONG PART NUMBER	TATA spare parts
0009971545J	O RING	TATA spare parts
9971881	RUBBER GROMMET	TATA spare parts
0009971881J	RUBBER GROMMET	TATA spare parts
9971888	GREASE NIPPLE	TATA spare parts
9971981	RUBBER GROMMET	TATA spare parts
9971988	GREASE CAP	TATA spare parts
0009972045J	O RING	TATA spare parts
0009972245J	O RING	TATA spare parts
9972247	OIL SEAL	TATA spare parts
0009972281J	RUBBER GROMMET	TATA spare parts
0009972345J	O RING	TATA spare parts
0009972381J	RUBBER GROMMET	TATA spare parts
0009972845J	O RING	TATA spare parts
9972881	RUBBER GROMMET	TATA spare parts
9973081	RUBBER GROMMET BS6	TATA spare parts
0009973445J	SEALING RING	TATA spare parts
9973446	OIL SEAL BS2/3/4	TATA spare parts
9973481	RUBBER GROMMET	TATA spare parts
9974930	SEALING PLUG	TATA spare parts
9976647	OIL SEAL	TATA spare parts
9976747	OIL SEAL BS2	TATA spare parts
9977446	OIL SEAL BS1/2/3/4	TATA spare parts
9977947	GASKET RING CR SHAFT FRT	TATA spare parts
9979641	SEALING RING	TATA spare parts
000X00020001	C.T BUZZER	TATA spare parts
000X0002CN	BUZZER	TATA spare parts
000X00030001	REVERSE HORN (12V)	TATA spare parts
000X0003CN	REVERSE HORN (12V)	TATA spare parts
000X0010CN	HAND STRAP	TATA spare parts
000X00190001	PIPE BRACKET(45DEG-38DIA)	TATA spare parts
000X00190002	PIPE BRACKET (45 DEG-38 DIA) (PC)	TATA spare parts
000X0023CN	TATA NAME PLATE (REFLECTIVE)	TATA spare parts

000X00640001	BULB 12V-10W SIN.PT/SIN. FILMT	TATA spare parts
000X00740001	STOP SWITCH	TATA spare parts
000X0074EN	BELL SW(ANCHOR MAKE)(WHITE COL	TATA spare parts
000X0096SN	M.S. UNION 6 MM	TATA spare parts
000X0097SN	M.S. T UNION 6 MM	TATA spare parts
000X0192PN	609 HANDLE	TATA spare parts
000X02680001	BULB 24V 6W	TATA spare parts
000X0271EN000000	KIT BULB 24V-2W S.PT/S.FLM (SENBUS)	TATA spare parts
000X03720001	TAIL LAMP ROUND FIEM WHITE (HISPANO)	TATA spare parts
000X03730001	TAIL LAMP ROUND (WHITE) (LAPL)	TATA spare parts
000X03740001	TAIL LAMP ROUND (AMBER) (LAPL)	TATA spare parts
000X0387PN	COVER FOR ROUND LAMP	TATA spare parts
000X0424EN	AIR-HORN (24 V)	TATA spare parts
000X04250001	REVERSE HORN (24 V)	TATA spare parts
000X0425EN	REVERSE HORN (24V)	TATA spare parts
000X0425EN000000	KIT REVERSE HORN (24 V) (SENBUS)	TATA spare parts
000X04470001	BELL BUZZER (24 V)	TATA spare parts
000X04530001	DOOR HANDLE WITH KEY (RH) (207)	TATA spare parts
000X0453SN	DOOR HANDLE RH WITH KEY (207)	TATA spare parts
000X04590001	KEY FOR BUDGET LOCK	TATA spare parts
000X0486CN	ROOM MIRROR (609)	TATA spare parts
000X0523CN	PARTITION LOCK (RH)	TATA spare parts
000X05560001	REFLECTOR (RED)	TATA spare parts
000X0563EN	FOG LAMP (RECT. SAIKO SM66)	TATA spare parts
000X0564PN	ACRYLIC MINI LAMP (ROUND)	TATA spare parts
000X06210001	DOOR HANDLE WITH KEY - LH	TATA spare parts
000X0621SN	DOOR HANDLE WITH KEY LH	TATA spare parts
000X06280001	ASSY INNER HANDLE RH (207)	TATA spare parts
000X0633RN	MUD FLAP (620X400	TATA spare parts
000X0634RN	MUD FLAP (609 EXPORT)480X400	TATA spare parts
000X06380001	ENGINE HOOD CLAMP (265188700134)	TATA spare parts
000X0638CN	CAB COMPLT RHD SLEEPER	TATA spare parts
000X06440001	BUTTERFLY LOCK & CATCHER	TATA spare parts
000X07610001	BEARING 6201ZZ	TATA spare parts
000X0877CN	NOZZEL ASSY SJ	TATA spare parts
000X09340001	BEADING WITH KEY (L=10 MTR)	TATA spare parts
000X0980CN	REAR VIEW MIRROR	TATA spare parts
000X1054CN000000	PARKING MIRROR ( 6INCH)	TATA spare parts
000X1169EN	QUALIS TAIL LIGHT LH	TATA spare parts
000X1170EN	QUALIS TAIL LIGHT RH	TATA spare parts
000X1210CN	CAB COMPLT RHD SLEEPER	TATA spare parts
000X1289RN000000	RUBBER BEADING	TATA spare parts
000X13270001	BULB 24VX10W(S.C/S.F/PHIL/OSRAM)	TATA spare parts
000X1327EN000000	BULB 24VX10W(S.C/S.F/PHIL	TATA spare parts
000X13280001	BULB 24V 21 WATT	TATA spare parts
000X13340001	STICKER SET FOR CITYRIDE BUS	TATA spare parts
000X13500001	HINGE FOR DRIVER DOOR (CITYRIDE)	TATA spare parts

000X13860001	FUSE CASSETTE TYPE (10 AMPS)	TATA spare parts
000X13910001	FUSE CASSETTE TYPE (15 AMPS)	TATA spare parts
000X13980001	FUSE CASSETTE TYPE (5 AMPS)	TATA spare parts
000X14120001	BULB 24VX10W(S.C/S.F/PHIL/OSRAM)	TATA spare parts
000X14200001	BULB 24V 21/ 5W	TATA spare parts
000X14210001	BULB FOR INDICA SD MRK(PHL/OSRAM)	TATA spare parts
000X14450001	PVC TRIM BEADING(BLACK)(L=10MTR)	TATA spare parts
000X14670001	SPEAKER COVER	TATA spare parts
000X14950001	DRIVER SEAT SHOCK ABSORBER	TATA spare parts
000X1672EN	CAB COMPLT RHD SLEEPER	TATA spare parts
000X17020001	FRP WHEEL HUB COVER FRONT (10X20D)	TATA spare parts
000X17030001	FRP WHEEL HUB COVER REAR (10X20D)	TATA spare parts
000X1703001	FRP WHEEL HUB COVER REAR (10X20D) BS6	TATA spare parts
000X17040001	HUB CAP MTG. CAP	TATA spare parts
000X17070001	BODGET LOCK COVER	TATA spare parts
000X17380001	HUB COVER MTG CAP.	TATA spare parts
000X22830001	STOP SWITCH (NET PL MAKE)	TATA spare parts
000X22840001	STOP SWITCH (PANEL MOUNTED)	TATA spare parts
000X40120001	BULB(PHILIPS/OSRAM/12V/21W)SFLMT/SCONT	TATA spare parts
0011541502DB	DYNAMO 240 W	TATA spare parts
13261600	ASSY SHOCK ABSORBER REAR	TATA spare parts
14208518	WHEEL BRAKE CYLINDER REAR	TATA spare parts
14209418	WHEEL BRAKE CYLINDER 38.1 DIA	TATA spare parts
0019810801DB	ROLLER BRG	TATA spare parts
19812005	BEARING TAPER ROLLER	TATA spare parts
19812405	BEARING TAPER ROLLER	TATA spare parts
19812701	BEARING	TATA spare parts
19813101	CYL ROLLER BRG NU209MN	TATA spare parts
19813105	TAPPER ROLLER BEARING	TATA spare parts
19813705	TAP ROLLER BRG-RR	TATA spare parts
0019813705DB	TAP ROLLER BRG	TATA spare parts
19815105	TAP ROLLER BRG 1210SD	TATA spare parts
19815205	BEARING TAPER ROLLER	TATA spare parts
19815705	BEARING TAPER ROLLER	TATA spare parts
19817105	CONICAL ROLLER BEARING	TATA spare parts
19817905	BEARING TAPER ROLLER	TATA spare parts
0019818005DB	BEARING TAPER ROLLER	TATA spare parts
19818205	BEARING TAPER ROLLER	TATA spare parts
19818305	TAPER ROLLER BEARING	TATA spare parts
19818705	TAPER ROLLER BEARING	TATA spare parts
19819810	ROLLER CAGE	TATA spare parts
19909101	NYLOC BOLT M8X35	TATA spare parts
19970645	O-RING	TATA spare parts
19973040	SEALING RING	TATA spare parts
19976140	GASKET RING	TATA spare parts
22033175	THERMOSTAL INSERT	TATA spare parts
26253827	BRUSH GEAR ASSY	TATA spare parts



26253937	ARMATURE ASSY	TATA spare parts
29812305	TAPER ROLLER BEARING	TATA spare parts
29973040	SEALING RING SPRING SUSPENSION	TATA spare parts
29973140	SEALING RING	TATA spare parts
29974346	OIL SEAL STRG GB MECH	TATA spare parts
29976446	OIL SEAL	TATA spare parts
29978446	SEALING RING	TATA spare parts
29979845	OIL RING	TATA spare parts
33212933	SPRING CLAMP INNER	TATA spare parts
33213133	SPRING CLAMP OUTER	TATA spare parts
340331005020	SWIVEL BUSH 4X4(SEMI-FINISH)	TATA spare parts
39972247	OIL SEAL	TATA spare parts
39972546	OIL SEAL	TATA spare parts
39974446	SEALING RING	TATA spare parts
39975146	OIL SEAL	TATA spare parts
39977546	OIL SEAL	TATA spare parts
0039977546DB	OIL SEAL	TATA spare parts
39977746	OIL SEAL	TATA spare parts
0039977746DB	OIL SEAL	TATA spare parts
49976845	O-RING	TATA spare parts
59971145	O RING	TATA spare parts
6016200002	RADIAL BALL BEARING (6001)	TATA spare parts
69972548	O RING	TATA spare parts
69975446	OIL SEAL TIMING G H-SILICON	TATA spare parts
89970146	SEALING RING	TATA spare parts
89971146	SEALING RING	TATA spare parts
99976146	OIL SEAL TIMING G H-SILICON	TATA spare parts
00XX01680001	DUMMY COVER	TATA spare parts
00XX02070004	264172300123 SPG.DD SEAL ELEPT(L=5MTR)	TATA spare parts
00XX0210RN000000	CAB COMPLT RHD SLEEPER	TATA spare parts
00XX0211RN000000	CAB COMPLT RHD SLEEPER	TATA spare parts
00XX0217PN	GRAB HANDLE DOOR	TATA spare parts
00XX02200001	65872300182 ASSY DOOR STRIKER	TATA spare parts
00XX0220CN	ASSY DOOR STRIKER	TATA spare parts
00XX02240001	ASSY DOOR LOCK RH	TATA spare parts
00XX02250001	ASSY.DOOR LOCK	TATA spare parts
00XX0225CN	DOOR LOCK COMP LH	TATA spare parts
00XX0229CN	ASSY INNER HANDLE	TATA spare parts
119979846	OIL SEAL RA PINION	TATA spare parts
0120100368J	OIL FILLER CAP	TATA spare parts
0120180006J	CAP	TATA spare parts
0120380609J	SET CON ROD BRG STD	TATA spare parts
0120380709J	BRG SET STD 1	TATA spare parts
0120380809J	SET CON ROD BRG RS1	TATA spare parts
0120380909J	BRG.SET.REPAIR SIZE-II	TATA spare parts
0120381009J	SET CON ROD BRG RS3	TATA spare parts
0120381109J	SET CON ROD BRG RS4	TATA spare parts

0120530030J	V GUIDE STD INTAKE	TATA spare parts
0120530130J	V GUIDE STD EXHAUST	TATA spare parts
0120530230J	V GUIDE R/S I INTAKE	TATA spare parts
0120530330J	VALVE GUIDE EXHAUST RS1	TATA spare parts
0120530430J	VALVE GUIDE INLET RS2	TATA spare parts
0120530530J	VALVE GUIDE EXHAUST RS2	TATA spare parts
0120530630J	V GUIDE R/S II INTAKE	TATA spare parts
0120530730J	VALVE GUIDE EXHAUST RS3	TATA spare parts
0120700066J	ASSY CLAMP LOWER	TATA spare parts
0120700132J	FLEXIBLE PIPE	TATA spare parts
0120700432J	FLEXIBLE PIPE LP	TATA spare parts
0120700832J	FLEXIBLE PIPE	TATA spare parts
0120701032J	FLEXIBLE PIPE	TATA spare parts
0120701132J	FLEXIBLE PIPE	TATA spare parts
0120780085J	CLAMP UPPER	TATA spare parts
0120920041J	CONNECTING LINK	TATA spare parts
0120920044J	STAY	TATA spare parts
0121300001J	ASSY ELBOW PIPE	TATA spare parts
0121300217J	ASSY.PISTON 69.98 AIR COMPRESSOR	TATA spare parts
0121300417J	ASSY.PISTON NORMAL I	TATA spare parts
0121300617J	PISTON A C	TATA spare parts
0121420101J	EXHAUST MANIFOLD	TATA spare parts
0121500025J	ASSY BRACKET	TATA spare parts
0121550037J	ALTERNATOR CLAMP	TATA spare parts
0122000001J	REP KIT WATER PUMP MNR	TATA spare parts
0122000004J	WATER PUMP REPAIR KIT MAJ	TATA spare parts
0122000102J	SHAFT WATER PUMP	TATA spare parts
0122000104J	REP KIT MAJOR WATER PUMP	TATA spare parts
0122000201J	ASSY WATER PUMP	TATA spare parts
0122000301J	HOUSING WATER PUMP	TATA spare parts
0122610020J	GEAR CASE COVER REAR	TATA spare parts
0122650145J	GUIDE PLATE	TATA spare parts
0122900026J	ASSY TUBE	TATA spare parts
0122920040J	SUPPORT	TATA spare parts
0123000020J	ACCELERATOR SHAFT	TATA spare parts
0123000028J	DOUBLE LEVER	TATA spare parts
0123000108J	CONTROL KNOB MANUAL	TATA spare parts
0123000415J	PULL ROD	TATA spare parts
0123000720J	ACCELERATOR SHAFT	TATA spare parts
0123000920J	ANCHOR PIN	TATA spare parts
0123010515J	PULLROD	TATA spare parts
0123010519J	ANCHOR PIN	TATA spare parts
0123020143J	CLAMP	TATA spare parts
0123020204J	PULL ROD	TATA spare parts
0123020240J	BRACKET	TATA spare parts
0123121257J	PACKING PLATE	TATA spare parts
0123200002J	FRONT SPRING ASSY	TATA spare parts

0123210053J	SPACER TUBE	TATA spare parts
0123210071J	CENTRE BOLT	TATA spare parts
0123210333J	SPRING CLAMP	TATA spare parts
0123210833J	SPRG CLAMP OUTER	TATA spare parts
0123211633J	SPRING CLAMP	TATA spare parts
0123240153J	SPACER	TATA spare parts
0123250001J	BRACKET REAR SPRING	TATA spare parts
0123250130J	CENTRE PIN	TATA spare parts
0123250330J	CENTRE PIN	TATA spare parts
0123250430J	CENTRE PIN	TATA spare parts
0123250530J	CENTRE PIN	TATA spare parts
0123300125J	FRONT HUB 312	TATA spare parts
0123350115J	REAR AXLE SHAFT GEAR	TATA spare parts
0123500021J	COVER REAR AXLE	TATA spare parts
0123500027J	DIFFERENTIAL HOUSING 14 MM	TATA spare parts
0123500221J	COVER REAR AXLE	TATA spare parts
0123500421J	COVER REAR AXLE HSG	TATA spare parts
0124000240J	WHEEL CARRIER	TATA spare parts
0124000402J	ASSY WHEEL DISC & RIM	TATA spare parts
0124010012J	TUBE FOR 8.25X20 TYRE	TATA spare parts
0124010015J	TYRE FLAP	TATA spare parts
0124100031J	UJ CROSS ASSY 76D	TATA spare parts
0124100602J	PROP SHAFT REAR 70X1310	TATA spare parts
0124100702J	PROP SHAFT FRONT	TATA spare parts
0124100802J	PROP SHAFT FRONT	TATA spare parts
0124130014J	BKT CENTRE BEARING	TATA spare parts
0124200032J	BRAKE TUBE	TATA spare parts
0124200612J	PARK BRAKE LEVER	TATA spare parts
0124201978J	SUPPORT	TATA spare parts
0124230474J	PIVOT PIN	TATA spare parts
0124260430J	BRAKE ROD 1200 MM	TATA spare parts
0124260530J	BRAKE ROD 23/5	TATA spare parts
0124260630J	BRAKE ROD 780 MM	TATA spare parts
0124260730J	BRAKE ROD 9 X 525 MM	TATA spare parts
0124261030J	BRAKE ROD 200 MM	TATA spare parts
0124280040J	BKT BRAKE HOSE	TATA spare parts
0124280140J	CLAMP	TATA spare parts
0124290640J	PLATE	TATA spare parts
0124290740J	CLAMP	TATA spare parts
0124700005J	FILLER CAP	TATA spare parts
0124700006J	STRAINER	TATA spare parts
0124700040J	STRAP W/HESSIAN	TATA spare parts
0124700042J	SUPPORT WITH STRAP	TATA spare parts
0124700313J	LEVER	TATA spare parts
0124700440J	ASSY.STRAP FUEL TANK 430DIA.	TATA spare parts
0124700605J	FUEL CAP ASSY	TATA spare parts
0124701564J	FUEL FEED LINE	TATA spare parts

0124701764J	FUEL FEED LINE	TATA spare parts
0124710122J	PLATE-ZP	TATA spare parts
0124750024J	PIN	TATA spare parts
0124760036J	HOLDING PLATE	TATA spare parts
0124900035J	BRACKET ASSY	TATA spare parts
0124910619J	BRACKET	TATA spare parts
0124910919J	BRACKET	TATA spare parts
0124920101J	EXH PIPE REAR FRT PORTION	TATA spare parts
0124920140J	CLAMP	TATA spare parts
0124920240J	CLAMP	TATA spare parts
0124921504J	EXHAUST PIPE REAR	TATA spare parts
0125200096J	TOWING HOOK FRONT	TATA spare parts
0125200259J	SIDE PANEL RH	TATA spare parts
0125201132J	BRACKET	TATA spare parts
0125230201J	RUNNING BOARD	TATA spare parts
0125250011J	NUMBER PLATE	TATA spare parts
0125250111J	UNIT PLATE FRONT BUMPER	TATA spare parts
0125250143J	PLATE	TATA spare parts
0125250840J	BRACKET	TATA spare parts
0125400005J	MAIN CABLE SET	TATA spare parts
0125401605J	MAIN CABLE SET	TATA spare parts
0125420039J	BRACKET	TATA spare parts
0125451440J	BRACKET CONVOY	TATA spare parts
0125830018J	DRIFT	TATA spare parts
125830099	PULLER F / TAIL PINION CYL-R-BRG OUT.RAC	TATA spare parts
0125890033J	ROCKER	TATA spare parts
0125900030J	TOWING HOOK	TATA spare parts
0127250010J	GLASS PANE	TATA spare parts
0127600031J	ASSY.LOCK LH/SF CAB/V-1	TATA spare parts
0127600131J	ASSY LOCK RH/LHD LOCKING	TATA spare parts
0127600231J	ASSY.LOCK RH/SF CAB/V-1	TATA spare parts
0127600331J	ASSY LOCK LH/LHD	TATA spare parts
0128000062J	BASE FRAME	TATA spare parts
0128910018J	PROTECTIVE CAP	TATA spare parts
0129900095J	HOLLOW RIVET SS:8451-11	TATA spare parts
0129900101J	HEX HEAD BOLT	TATA spare parts
0129950032J	CLAMP	TATA spare parts
0129950120J	CLAMP	TATA spare parts
0129950132J	CLIP	TATA spare parts
0129970030J	SEALING PLUG	TATA spare parts
0129970049J	KIT OVERHAUL GASKET	TATA spare parts
0129970149J	KIT DECARBONISING GASKETS	TATA spare parts
016236XXX0	AL-EXTRUSION (NON SKID)	TATA spare parts
016260XXXX	INNER MOULDING EXTRUSION	TATA spare parts
016289XX0001	AL-EXTRUSION (VINYL FLR/CORN.L-10X20	TATA spare parts
016350XXX0	AL-EXTRUSION (REAR)	TATA spare parts
016350XXX0000020	CAB COMPLT RHD SLEEPER	TATA spare parts

16361000008	AL-EXTRUSION (CUT TO LENGTH OF 4MTR	TATA spare parts
016395XX0001	AL-EXTRUSION (ANGLE 15 X 20)	TATA spare parts
16404000002	AL-EXTRUSION - RAIN CHANNEL(L=2.5MTR)	TATA spare parts
017120XX0001	PIPE/ERW (25.4 DIA X 2 THK)	TATA spare parts
017120XX0002	MS PIPE(25.4 DIA) ( L = 8.8 MTR )	TATA spare parts
017120XX0607	PIPE/ERW (25.4 DIA X 2 THK)(L=4MTR)	TATA spare parts
017120XX0608	PIPE/ERW (25.4 DIA X 2 THK)(PC)L=4MTR	TATA spare parts
017122XX0001	PIPE/ERW (25.4 DIA X 1.2 THK) (PC)(L=9 M	TATA spare parts
017122XX0002	PIPE/ERW (25.4 DIA X 1.2 THK) (PC)( L= 1	TATA spare parts
017122XX0003	PIPE/ERW (25.4 DIA X 1.2 THK) ( L = 6 MT	TATA spare parts
017122XX0059	PIPE/ERW (25.4 DIA X 1.2 THK) (PC)	TATA spare parts
017122XX0103	PIPE/ERW (25.4 DIA X 1.2 THK) (PC)(L=6MT	TATA spare parts
017123XX0002	PIPE/ERW (19.0 DIA X 1.2 THK) (PC) ( L=	TATA spare parts
017123XX0092	PIPE/ERW (19.0 DIA X 1.2 THK) (PC)(L=3MT	TATA spare parts
017127XX0127	PIPE/ERW (38.0 DIA X 2 THK)(PC)(L=6MTR)	TATA spare parts
017127XXX0127	PIPE/ERW (38.0 DIA X 2 THK)(PC)(L=6MTR)	TATA spare parts
17129000001	PIPE/ERW (32 DIA X 2 THK)(PC)L=MTR	TATA spare parts
17129000230	STRAIGHT PIPE(32DIA)(L=1MTR)	TATA spare parts
017143XX0001	PIPE/ERW(19.0DIA1THK)(PC)(L=3MTR)	TATA spare parts
017143XX0002	PIPE/ERW (19.0 DIA X 1 THK) (PC)(L=70 MT	TATA spare parts
17145000056	PIPE/ERW (SKTM 11 19DIA X 2.0 THK)(PC)(L	TATA spare parts
020001XX0001	WEDGE(KEY)BEAD(SMAL-RR/DEST L=10 MTR)	TATA spare parts
020001XX0002	WEDGE STRIP (L = 1.3 MTR )	TATA spare parts
020001XX0032	WEDGE (KEY) BEADING(SMALL-REAR/DEST)(L=1	TATA spare parts
020001XXX1	WEDGE STRIP(VERT.STRIP/R)	TATA spare parts
020001XXX1000000	WEDGE (KEY) SMALL REAR ( 3 MTR )	TATA spare parts
020003XX0001	WEDGE (KEY) BEADING (W/S.BIG-FRT/RE)	TATA spare parts
020003XX0002	WEDGE (KEY) BEADING (W/S.BIG-FRT/RE) ( L	TATA spare parts
020003XX0046	WEDGE (KEY) BEADING (W/S.BIG-FRT/RE)	TATA spare parts
020003XX0047	WEDGE (KEY) BEADING (W/S.BIG-FRT/RE)	TATA spare parts
020003XXX0	WEDGE STRIP(KEY-WINDSHIELD/R)	TATA spare parts
020003XXX0000000	WEDGE (KEY) FRT/REAR W/S (15 MTR)	TATA spare parts
020026XX0001	WEATHER STRIP (EMG.ACR.WINDOW)(L=5MTR)	TATA spare parts
020026XX0002	WEATHER STRIP (L = 1.3 MTR )	TATA spare parts
020044XX0002	WEATHER STRIP (REAR WINDSHIELD)	TATA spare parts
020044XXX0	WEATHER STRIP(REAR WINDSHIELD)	TATA spare parts
020044XXX0000000	WEATHER STR(REAR W/S) (5.7 MTR)	TATA spare parts
020046XX0001	WEATHER STRIP (WINDSHILD FRONT)	TATA spare parts
020046XXX0	WEATHER STRIP(WINDSHILD FRONT)	TATA spare parts
020065XX0001	WEATHER STRIP (L=10MTR)	TATA spare parts
020065XX0002	WEATHER STRIP ( L = 1 MTR )	TATA spare parts
020065XX0004	WEATHER STRIP(L=5MTR)	TATA spare parts
020065XX0007	WEATHER STRIP (L=8.0MTRS)	TATA spare parts
020065XX0008	WEATHER STRIP (L=8.5MTRS)	TATA spare parts
020065XX0011	WEATHER STRIP(L=5MTR)	TATA spare parts
020068XX0004	WEATHER STRIP (L=10 MTRS)	TATA spare parts
020110XXX0	WEATHER STRIP (U-TYPE) (5MM)	TATA spare parts

020116XXX0	WEATHER STRIP (U-TYPE) (4MM)	TATA spare parts
020173XX0001	WEAT.STRIP (PASS.DOOR-BIG BULB)	TATA spare parts
020176XX0001	WEATHER STRIP FOR PASSENGER DOO	TATA spare parts
020176XX0020	WEAT.STRIP (PASS.DOOR-BIG BULB)	TATA spare parts
20231040001	WEAT.STRIP (PASS.DR-MDL-SMALL D)	TATA spare parts
2023104001	WEAT.STRIP (PASS.DR-MDL-SMALL D)	TATA spare parts
20231050001	WEAT.STRIP (PASS.DR-FLAP/SHAFT)	TATA spare parts
020291XXX0	VINYL TUBE (SKIRT PANEL)	TATA spare parts
020294XX0001	PVC TUBE 26.4 ID X 2.00THK ( L = 2.3 MTR	TATA spare parts
020294XX0008	PVC TUBE 26.4 ID X 2.00THK(L=5MTR)	TATA spare parts
020296XX0001	PVC SLEEVE TUBE ( L -6 MTR )	TATA spare parts
020296XX0009	PVC SLEEVE TUBE(L=5MTR)	TATA spare parts
020309XXX0	TRIM STRIP	TATA spare parts
020320XX0037	FRINGE (PVC EXTRUSION)(L=2.5MTR)	TATA spare parts
20412000	MOULDING OUTER WAIST RAIL 10 MTR ROLL	TATA spare parts
020422XX0001	WEATHER STRIP (PASS DOOR GLASS)	TATA spare parts
020422XXX0021050	WEATHER STRIP L=2105	TATA spare parts
020423XX0001	WEATH.STRIP (PASS.DOOR-GLASS KEY)	TATA spare parts
020423XXX0021050	WEATHER STRIP	TATA spare parts
20455000007	WEATHER STRIP (CENTRE-5PC W/S)	TATA spare parts
020464XX0008	REAR WINDSHIELD BEADING- 4MTR	TATA spare parts
020507XX0001	DUST SEAL(SPONGE)(20X3)(L=10MTR)	TATA spare parts
020510XX0001	DUST SEAL(SPONGE)(20X6)(L=10MTR)	TATA spare parts
020510XX0002	DUST SEAL (SPONGE) (20X6)	TATA spare parts
020513XX0001	ENGINE HOOD BEADING ( L = 4 MTR )	TATA spare parts
020513XX0004	ENGINEHOOD BEADING (DUST SEAL) (L=6MTR)	TATA spare parts
020547XX0001	DUST SEAL(EMG.DR/U-FLG L=10MTR)	TATA spare parts
020547XX0053	DUST SEAL(SPONGE/EMG.DR/U-FLG) L=4.00MTR	TATA spare parts
020550XXX0	DUST SEAL (WINDOW)	TATA spare parts
20910000003	RUBBER PAD (70X48)(GREY)	TATA spare parts
020911XXX2000000	WEATHER STRIP (ENTRANCE DOOR)	TATA spare parts
020917XX0006	WEAT.STRIP(BULB+MET.INS/EMG DR L=.8 MTR	TATA spare parts
020917XX0024	WEATHER STRIP(BULB+MET.INS-EMG DOOR)L=5M	TATA spare parts
020917XXX0	WEAT.STRIP(BULB+MET.INS/EMG DR) 1 METER	TATA spare parts
020922XX0001	T-BEADING FOR WINDSHIELD(L=10MTR)	TATA spare parts
020929XX0001	WHEEL ARCH BEADING	TATA spare parts
020929XX0003	RUBBER BEADING (WHEEL ARCH). BS6	TATA spare parts
020933XX0001	RUBBER BEADING FOR WHEEL ARCH	TATA spare parts
020934XX0002	DUST SEAL	TATA spare parts
0210330618J	MAIN BRG SET STD	TATA spare parts
0210330718J	SET MAIN BEARING STD1	TATA spare parts
0210330818J	SET MAIN BEARING RS1	TATA spare parts
0210330918J	MAIN BRG SET RS-2	TATA spare parts
0210331018J	SET MAIN BEARING RS3	TATA spare parts
0210331118J	SET MAIN BEARING RS4	TATA spare parts
0210510024J	CAM BUSH	TATA spare parts
0211310434J	SET CON ROD BRG STD 70/77	TATA spare parts

0211310534J	SET CON ROD BRG STD1	TATA spare parts
0211310634J	SET CON ROD BRG RS1	TATA spare parts
0211310734J	SET CON ROD BRG RS2	TATA spare parts
250201005	GLOW PLUG QUICK START	TATA spare parts
251101005	GLOW PLUG RESISTOR	TATA spare parts
26010000001	HINGE ASSY(WITHOUT HANDLE)(PC)	TATA spare parts
26010000005	HINGE ASSY (WITH HANDLE) (PC)	TATA spare parts
26010000009	HINGE ASSY (WITH HANDLE) (PC)	TATA spare parts
26100000001	LOCK	TATA spare parts
280752294	ASSY. ACCELERATOR PEDAL COMP.	TATA spare parts
281002209	WATER TEMP SENSOR BS4	TATA spare parts
281002214	ENGINE SPEED SENSOR	TATA spare parts
281002514	BOOST PRESSURE/TEMP SENSOR	TATA spare parts
281002687	ACC. PEDAL MODULE SENSOR 697 EUROIII	TATA spare parts
330001004	SOLENOID SWITCH FIP	TATA spare parts
330001015	SOLNOID SWITCH FIP	TATA spare parts
330001042	SOLENOID 697 EURO III	TATA spare parts
330001046	SOLENOID	TATA spare parts
343001001	SWITCH	TATA spare parts
34368	BEARING CONE-4021	TATA spare parts
402736857	FUEL INJ PUMP 3521TC	TATA spare parts
0420100020J	CYL HD COMPT DI	TATA spare parts
0420100044J	ENG RHD L-DI	TATA spare parts
0420100050J	SHORT BLOCK DI	TATA spare parts
0420100120J	CYLINDER HEAD W/O VALVES	TATA spare parts
0420100144J	ENG RHD LP-DI	TATA spare parts
0420100350J	ASYCYLCRCASEWDRIVEGEARCLH	TATA spare parts
0420101044J	ENG RHD SFC L-DI	TATA spare parts
0420300103J	ASSY VIBRATION DAMPER	TATA spare parts
0420320015J	INDICATOR SFC	TATA spare parts
0420370215J	SET PISTON RING RS1	TATA spare parts
0420371115J	SET PISTON RING STD1 & 2	TATA spare parts
0420371215J	SET PISTON RING RS1	TATA spare parts
0420371315J	SET PISTON RING RS2	TATA spare parts
0420530009J	VALVE KIT	TATA spare parts
0420940108J	SUCTION TUBE	TATA spare parts
0421400460J	PIPE AIR 1400MM	TATA spare parts
0421400960J	PIPE AIR	TATA spare parts
0421440521J	PIPE 6DX07X770LGCR19388/2	TATA spare parts
0422500005J	CLUTCH HOUSING	TATA spare parts
0422510004J	COVER CL.HSG-FP	TATA spare parts
0422600639J	GEAR SHIFT LEVER	TATA spare parts
0422600839J	GEAR SHIFT LEVER	TATA spare parts
0422601214J	TOP COVER G30 LP	TATA spare parts
0422601239J	GEAR SHIFT LEVER	TATA spare parts
0422601314J	COVER TOP GEAR	TATA spare parts
0422620162J	BUTTING RING	TATA spare parts

0422630002J	COUNTER SHAFT	TATA spare parts
0422900016J	CLUTCH PEDAL LEVER	TATA spare parts
0422900031J	SUPPORT OUTER	TATA spare parts
0422900119J	ASSY BRACKET STEERING & PEDALS	TATA spare parts
0422900131J	SUPPORT OUTER	TATA spare parts
0422900234J	BRAKE SHAFT LEVER	TATA spare parts
0422900326J	TUBE ASSY	TATA spare parts
0422900339J	CLUTCH CONTROL ROD	TATA spare parts
0422900439J	CLUTCH CONTROL ROD	TATA spare parts
0422900619J	CONTROL LEVER BOX	TATA spare parts
0422901519J	SUPPORT PEDAL	TATA spare parts
0422901919J	SUPPORT PEDAL LEVER COMP	TATA spare parts
0422902519J	SUPPORT PEDAL LEVER	TATA spare parts
0422920009J	TUBE BRAKE LEVER	TATA spare parts
0422930312J	SUPPORT INNER	TATA spare parts
0422940004J	TUBE	TATA spare parts
0423000016J	CAM ASSY	TATA spare parts
0423000121J	ACCELERATOR SHAFT HSG	TATA spare parts
0423000525J	ASSY ACC LEVER	TATA spare parts
0423000925J	LEVER ACCELERATOR	TATA spare parts
0423010225J	PULLROD LHD LP	TATA spare parts
0423010250J	BUSH	TATA spare parts
0423020204J	PUSH ROD	TATA spare parts
0423100058J	SUPPORT TOWING HOOK	TATA spare parts
0423100128J	ENG CROSS MEMBER REAR	TATA spare parts
0423100228J	ASY ENGINE CROSS MEMB RR	TATA spare parts
0423100409J	SUPPORT COUPLING	TATA spare parts
0423100826J	ASSY.ENGINE CROSS MEMBER	TATA spare parts
0423101226J	ENG CR MEMBER LP 342 FR	TATA spare parts
0423101526J	ENG CR MEMBER LP 342 FR	TATA spare parts
0423120017J	CROSS MEMBER(REAR SPRING)BRACKET	TATA spare parts
0423120076J	WASHER	TATA spare parts
0423120260J	SUPPORT X MEMBER	TATA spare parts
0423120335J	END CROSS MEMBER	TATA spare parts
0423120505J	ENG CROSS MEMBER FRONT	TATA spare parts
0423120710J	CROSS MEMBER L/LP	TATA spare parts
0423120910J	CROSS MEMBER	TATA spare parts
0423121652J	SUPPORT	TATA spare parts
0423121910J	CROSS MEMBER	TATA spare parts
0423130008J	BRACKET	TATA spare parts
0423150006J	COUPLING PIN L 342	TATA spare parts
0423150027J	REINFORCEMENT	TATA spare parts
0423150127J	REINFORCEMENT PLATE (SUPPORT TO CROSS ME	TATA spare parts
0423200002J	FRONT SPRING ASSY	TATA spare parts
0423200023J	ASSY SUPPORT	TATA spare parts
0423200113J	LEAF SPRING 1ST	TATA spare parts
0423200115J	1ST LEAF RR SPRING	TATA spare parts



0423200143J	MTG BKT FR RUBBER BUFFER	TATA spare parts
0423200215J	MAIN LEAF REAR SPRING	TATA spare parts
0423200245J	BRACKET RH	TATA spare parts
0423200315J	LEAF SPRING 1ST	TATA spare parts
0423200410J	AUXILLARY SPRING ASSY	TATA spare parts
0423200608J	REAR SPRING ASSY W/AUX	TATA spare parts
0423200610J	AUXILLARY SPRING ASSY	TATA spare parts
0423201006J	REAR SPRING ASSY	TATA spare parts
0423201706J	REAR SPG W/O AUX 1210SD	TATA spare parts
0423210037J	PLATE REAR SPRING	TATA spare parts
0423210053J	SPACER TUBE	TATA spare parts
0423210071J	CENTRE BOLT	TATA spare parts
0423210633J	SPRING CLAMP	TATA spare parts
0423210833J	SPRING CLAMP	TATA spare parts
0423210933J	SPRING CLAMP	TATA spare parts
0423211033J	SPRING CLAMP	TATA spare parts
0423211633J	CLAMP/SRL.NO-4	TATA spare parts
0423220024J	GUIDE PLATE	TATA spare parts
0423220401J	FRONT SPRING HANGER BRACKET FRNT & REAR	TATA spare parts
0423230063J	BRACKET LOWER LH	TATA spare parts
0423240012J	LEAF SPRING 2ND	TATA spare parts
0423240113J	3/4 LEAF RR SPG	TATA spare parts
0423240140J	LEAF SPRING 1ST AUX SPG	TATA spare parts
0423240141J	LEAF SPRING 2ND	TATA spare parts
0423240143J	SPACER PLATE	TATA spare parts
0423240144J	LEAF SPRING 5TH AUX	TATA spare parts
0423240241J	LEAF SPRING 2ND	TATA spare parts
0423240316J	LEAF SPRING 6TH	TATA spare parts
0423240318J	LEAF SPRING 8TH	TATA spare parts
0423240412J	LEAF SPRING 2ND	TATA spare parts
0423240413J	LEAF SPRING 3RD	TATA spare parts
0423240414J	LEAF SPRING 4TH	TATA spare parts
0423240415J	LEAF SPRING 5TH	TATA spare parts
0423240513J	LEAF SPRING 3RD	TATA spare parts
0423240517J	LEAF SPRING 7TH	TATA spare parts
0423240715J	LEAF SPRING 5TH	TATA spare parts
0423240812J	SECOND LEAF	TATA spare parts
0423240914J	LEAF SPRING 4TH	TATA spare parts
0423250030J	CENTRE PIN M12X246	TATA spare parts
0423250044J	RUBBER BUFFER	TATA spare parts
0423250053J	SPACER TUBE	TATA spare parts
0423250217J	SLIDE SUPPORT	TATA spare parts
0423260053J	BUSH	TATA spare parts
0423300025J	FRONT HUB W/BRG	TATA spare parts
0423300027J	ASSY DIFFERENTIAL HOUSING WITH COVER	TATA spare parts
0423300075J	RUBBER BUFFER	TATA spare parts
0423300080J	KING PIN KIT STD	TATA spare parts

0423300103J	TIE ROD	TATA spare parts
0423300125J	HUB FRONT W/O BRG	TATA spare parts
0423300180J	REP KIT KING PIN STD1	TATA spare parts
0423300225J	HUB FRONT W/BRG	TATA spare parts
0423300280J	KINGPIN KIT R/S I	TATA spare parts
0423300325J	FRONT HUB W/O BRG	TATA spare parts
0423300380J	REP KIT KING PIN RS2	TATA spare parts
0423310001J	FRONT AXLE BEAM STD	TATA spare parts
0423320071J	COLLAR BOLT 16X133	TATA spare parts
0423380105J	STEERING LEVER LH RHD	TATA spare parts
0423380108J	STEERING LEVER RH RHD	TATA spare parts
0423380205J	STEERING LEVER LH	TATA spare parts
0423380308J	STEERING LEVER RH	TATA spare parts
0423500017J	DIFFERENTIAL L/LP 34	TATA spare parts
0423500021J	COVER REAR AXLE	TATA spare parts
0423500055J	ADJUSTING SCREW	TATA spare parts
0423500117J	KITASSYDIFFW/OTAPERROLLERBRGCRWHAPINIO	TATA spare parts
0423500154J	KIT BEVEL GEAR 342	TATA spare parts
0423500435J	HUB REAR 342	TATA spare parts
0423510025J	U CLAMP 315 MM	TATA spare parts
0423510825J	U CLAMP	TATA spare parts
0423510925J	U CLAMP REAR SPRING	TATA spare parts
0423530014J	DIFFERENTIAL BEVEL GEAR	TATA spare parts
0423530015J	GEAR REAR AXLE SHAFT	TATA spare parts
0423530172J	HEX NUT (MACHINED) BS1/2/3/4	TATA spare parts
0423560120J	COVER REAR HUB	TATA spare parts
0423570026J	GROOVED NUT	TATA spare parts
0424000140J	SUPPORT SP WHEEL CARRIER	TATA spare parts
0424020071J	WHEEL MOUNTING PIN	TATA spare parts
0424020671J	WHEEL MOUNTING PIN COARSE	TATA spare parts
0424020771J	HUB BOLT M-20X90	TATA spare parts
0424020971J	WHEEL MOUNTING PIN	TATA spare parts
0424021071J	WHEEL MOUNTING PIN	TATA spare parts
0424100002J	PROP SHAFT FR 70X3	TATA spare parts
0424100031J	WRONG PART NUMBER-ASSY. CROSS	TATA spare parts
0424100201J	PROP SHAFT FRT W/CB	TATA spare parts
0424100301J	PROP SHAFT FRT W/CB	TATA spare parts
0424100302J	PROP SHAFT FR 70X3	TATA spare parts
0424100401J	PROP SHAFT FRT W/O CB	TATA spare parts
0424100501J	PROP SHAFT FRT W/O CB	TATA spare parts
0424100701J	PROP SHAFT MIDDLE W/O CB	TATA spare parts
0424101201J	PROP SHAFT FR W/CB 19435	TATA spare parts
0424101301J	PROP SHAFT FR W/CB	TATA spare parts
0424101401J	PROP SHAFT FR W/O CB	TATA spare parts
0424101501J	PROP SHAFT FR W/O CB	TATA spare parts
0424110072J	HEX NUT	TATA spare parts
0424200012J	BRAKE LEVER	TATA spare parts

0424200020J	BRAKE SHOE STD 342	TATA spare parts
0424200032J	BRAKE TUBE	TATA spare parts
0424200081J	INTERMEDIATE LEVER FRONT	TATA spare parts
0424200083J	ASSY.RUBBER SEALING COVER	TATA spare parts
0424200120J	BRAKE SHOE RS1	TATA spare parts
0424200128J	BRAKE TUBE	TATA spare parts
0424200132J	BRAKE TUBE TMC TO RR AXLE	TATA spare parts
0424200220J	BRAKE SHOE RS2	TATA spare parts
0424200228J	BRAKE TUBE	TATA spare parts
0424200232J	BRAKE TUBE	TATA spare parts
0424200281J	INTERMEDIATE LEVER FRONT	TATA spare parts
0424200434J	CONNECTING LINE 342	TATA spare parts
0424200584J	PARKING BRAKE	TATA spare parts
0424200632J	BRAKE TUBE	TATA spare parts
0424200817J	ANCHOR PLATE LH	TATA spare parts
0424200832J	BRAKE TUBE	TATA spare parts
0424200917J	PLATE REAR RH	TATA spare parts
0424201532J	BRAKE TUBE	TATA spare parts
0424201632J	BRAKE TUBE	TATA spare parts
0424201934J	FLEXIBLE CONNECTING PIPE	TATA spare parts
0424201978J	SUPPORT ASSY	TATA spare parts
0424202434J	CONNECTING PIPE	TATA spare parts
0424202634J	CONNECTING PIPE	TATA spare parts
0424203232J	BRAKE TUBE	TATA spare parts
0424204032J	BRAKE TUBE LP 42	TATA spare parts
0424230016J	THRUST PIECE	TATA spare parts
0424230018J	PIN	TATA spare parts
0424230053J	SPACER TUBE	TATA spare parts
0424230152J	SPACER	TATA spare parts
0424260130J	BRAKE ROD 10X1050X80/80	TATA spare parts
0424260330J	PULL ROD 10X2270X80/80	TATA spare parts
0424270008J	SUPPORT FRONT	TATA spare parts
0424270053J	SPACER TUBE PARKING BRAKE	TATA spare parts
0424280043J	BKT BRAKE HOSE	TATA spare parts
0424280048J	BRACKET BRAKE FLUID LINE	TATA spare parts
0424290054J	SPACER PLATE	TATA spare parts
0424290140J	SUPPORT TRUCK BRAKE VALVE	TATA spare parts
0424290142J	BRACKET	TATA spare parts
0424290242J	HOLDING PLATE-FOR AIR LINES	TATA spare parts
0424290402J	PIPE AIR	TATA spare parts
0424290502J	PIPE AIR	TATA spare parts
0424291102J	PIPE AIR	TATA spare parts
0424292302J	PIPE AIR 18 X 1.5 X 1430	TATA spare parts
0424292404J	PIPE AIR 15 X 1.5 X 690	TATA spare parts
0424293404J	PIPE AIR 15D	TATA spare parts
0424293504J	PIPE AIR 15D	TATA spare parts
0424293702J	PIPE AIR	TATA spare parts

0424295702J	PIPE AIR 18 X 1.5 X 930	TATA spare parts
0424297502J	PIPE AIR 12 X 1.5 X 1195	TATA spare parts
0424297602J	PIPE AIR 15 X 1.5 X 726	TATA spare parts
0424298303J	PIPE AIR 18 X 1.5 X 1060	TATA spare parts
0424300105J	AIR CONTAINER	TATA spare parts
0424310060J	GASKET	TATA spare parts
0424310095J	REINFORCEMENT	TATA spare parts
0424310372J	ADAPTER NUT	TATA spare parts
0424320074J	PIN	TATA spare parts
0424320174J	PIN	TATA spare parts
0424600305J	DRAG LINK SFC RHD	TATA spare parts
0424600330J	STEERING SUPPORT	TATA spare parts
0424600409J	STEERING NUT & WORM	TATA spare parts
0424600609J	STEERING NUT & WORM	TATA spare parts
0424600709J	STEERING NUT & WORM	TATA spare parts
0424601101J	STEERING WHEEL 4 SPOKES	TATA spare parts
0424602135J	STEERING BRACKET	TATA spare parts
0424610341J	STEERING BRACKET	TATA spare parts
0424610541J	STEERING BRACKET LHD	TATA spare parts
0424620045J	FLANGE	TATA spare parts
0424620101J	STEERING SPINDLE	TATA spare parts
0424620186J	RUBBER BELLOW	TATA spare parts
0424620301J	STEERING SPINDLE BOTTOM	TATA spare parts
0424630301J	PITMAN ARM LP LHD	TATA spare parts
0424630701J	PITMAN ARM SFC	TATA spare parts
0424700005J	FUEL CAP ASSY	TATA spare parts
0424700040J	STRAP	TATA spare parts
0424700064J	FUEL PIPE	TATA spare parts
0424700070J	OVER FLOW RETURN LINE	TATA spare parts
0424700164J	FUEL PIPE	TATA spare parts
0424700170J	OVER FLOW RETURN LINE	TATA spare parts
0424700237J	ASSY HANDLE	TATA spare parts
0424700257J	DIPSTICK ASSY	TATA spare parts
0424700370J	OVER FLOW RETURN LINE	TATA spare parts
0424700605J	FUEL CAP ASSY	TATA spare parts
0424700864J	FUEL PIPE 10 X 0.7 X 3310	TATA spare parts
0424700964J	FUEL PIPE	TATA spare parts
0424701064J	FUEL PIPE	TATA spare parts
0424701864J	FUEL PIPE 10 X 0.7 X 3610	TATA spare parts
0424703164J	FUEL RETURN LINE	TATA spare parts
0424703364J	FUEL RETURN LINE	TATA spare parts
0424707170J	OVER FLOW RETURN LINE	TATA spare parts
0424707770J	OVER FLOW RETURN LINE	TATA spare parts
0424710274J	PIN	TATA spare parts
0424710374J	PIN	TATA spare parts
0424760435J	BRACKET	TATA spare parts
0424910019J	BRACKET	TATA spare parts

0424920104J	EXHAUST PIPE	TATA spare parts
0424920704J	EXH PIPE REAR FRT PORTION	TATA spare parts
0425000006J	RADIATOR CAP	TATA spare parts
0425000013J	RUBBER MOUTING	TATA spare parts
0425000427J	SUPPORT RADIATOR	TATA spare parts
0425000701J	RADIATOR ASSY LP/DI W/CAP	TATA spare parts
0425000901J	RADIATOR ASSY SFC 3PT MTG	TATA spare parts
0425040070J	STUD	TATA spare parts
0425040170J	STUD	TATA spare parts
0425200145J	BRACKET RR LIGHT RH	TATA spare parts
0425200447J	PROTECTIVE GRILL	TATA spare parts
0425200547J	ASSY.PROTECTIVE GRILL	TATA spare parts
0425200634J	SUPPORT	TATA spare parts
0425201468J	ASSY REINFORCEMENT PLATE BS6	TATA spare parts
0425202145J	BRACKET TAIL LAMP RH	TATA spare parts
0425202386J	SUPPORT	TATA spare parts
0425210128J	BEADING	TATA spare parts
0425230711J	FLOOR PANEL LH	TATA spare parts
0425230811J	FLOOR PANEL RH	TATA spare parts
0425240431J	DISC	TATA spare parts
0425240740J	SUPPORT LH LP/INT/FACE	TATA spare parts
0425241433J	SUPPORT LH	TATA spare parts
0425242123J	BRACKET LH	TATA spare parts
0425260045J	SUPPORT FLAP	TATA spare parts
0425270042J	HOOD STAY	TATA spare parts
0425270061J	TIE ROD	TATA spare parts
0425270329J	GUIDE	TATA spare parts
0425280317J	BRACKET L.H(FOR SIDE POST	TATA spare parts
0425280530J	GUSSET SIDE LH	TATA spare parts
0425280630J	GUSSET SIDE RH	TATA spare parts
0425280717J	BRACKET	TATA spare parts
0425400131J	ASY BATTERYCABLE NEGATIVE	TATA spare parts
0425400430J	BATTERY CABLE +VE	TATA spare parts
0425400460J	PIPE OIL PR 6 X 0.7 X1485	TATA spare parts
0425400805J	MAIN CABLE SET	TATA spare parts
0425400931J	BATTERY CABLE -VE	TATA spare parts
0425401030J	BATTERY CABLE +VE	TATA spare parts
0425401031J	BATTERY CABLE-NEGATIVE	TATA spare parts
0425401430J	BATTERY CABLE +VE	TATA spare parts
0425401431J	BATTERY CABLE -VE	TATA spare parts
0425401860J	PIPE OIL PRESSURE	TATA spare parts
0425402237J	ELECTRIC CABLE	TATA spare parts
0425402760J	PIPE OIL PRESSURE	TATA spare parts
0425405105J	MAIN CABLE SET	TATA spare parts
0425405305J	MAIN CABLE SET	TATA spare parts
0425405805J	MAIN CABLE SET	TATA spare parts
0425406305J	MAIN CABLE SET	TATA spare parts

0425408761J	ASY AIR PR.GAUGE PIPE	TATA spare parts
0425409037J	ELECTRIC CABLE L342/48R	TATA spare parts
0425420643J	PIPE AIR	TATA spare parts
0425420743J	PIPE AIR	TATA spare parts
0425421943J	PIPE AIR 6 X 1 X 855	TATA spare parts
0425424843J	PIPE AIR 6 X 1 X 1380	TATA spare parts
0425426343J	PIPE AIR	TATA spare parts
0425427043J	PIPE AIR 6 X 0.7 X 500	TATA spare parts
0425427143J	PIPE AIR	TATA spare parts
0425440033J	ENGINE LAMP	TATA spare parts
425830067	HOLDER / TORQUEMULTIPLYING WRENCH	TATA spare parts
0425830067J	HOLDER	TATA spare parts
425830082	CLAMP / CHECKING RUN OUT OF CROWN WHEEL	TATA spare parts
0425830082J	CLAMP	TATA spare parts
0425890001J	GAUGE RA BEND CHECKING	TATA spare parts
0425890007J	PRONGED WRENCH	TATA spare parts
0425890031J	TENSION JAWS	TATA spare parts
0425890033J	PULLER	TATA spare parts
0425890035J	DRIFT	TATA spare parts
0425890067J	SERVICE TOOL	TATA spare parts
425890133	PULLER / RA SHAFT / 342	TATA spare parts
0425890133J	PULLER	TATA spare parts
425890139	DRIFT	TATA spare parts
0425890139J	DRIFT	TATA spare parts
425890235	PULLER	TATA spare parts
425890239	DRIFT/INSTALL COUP.FLANGE T-PINION/RA108	TATA spare parts
0425890239J	DRIFT	TATA spare parts
425890633	PULLER / PITMAN ARM / 1210 407	TATA spare parts
0425890633J	PULLER SFC	TATA spare parts
0425890733J	PULLER	TATA spare parts
0425900140J	BRACKET HYDRAULIC PUMP	TATA spare parts
0426003452J	ASY.COWL WELDED WITH TIE	TATA spare parts
0426020208J	COVER FRONT LH	TATA spare parts
0426020308J	COVER FRONT RH	TATA spare parts
0426160437J	COVER	TATA spare parts
0426200614J	ASSY.BRKT.SIDE LH/LPCABII	TATA spare parts
0426210040J	COVER	TATA spare parts
0426221831J	GUSSET FRONT LH	TATA spare parts
0426221931J	GUSSET FRONT RH	TATA spare parts
0426410016J	REINFORCEMENT BRACKET	TATA spare parts
0426420331J	SUPPORT	TATA spare parts
0426460022J	CLIP	TATA spare parts
0426500003J	TOP RAIL LH	TATA spare parts
0426500103J	TOP RAIL RH	TATA spare parts
426571509	ROOF PANEL SFC NORMAL	TATA spare parts
0426571509J	ROOF PANEL SFC NORMAL	TATA spare parts
0426710421J	FILLER PROFILE 2665 MM	TATA spare parts

042680190J	INSTRUMENT PANEL	TATA spare parts
0426891690J	INSTRUMENT PANEL	TATA spare parts
0426950825J	CORNER PANEL INNER LH	TATA spare parts
0426950925J	CORNER PANEL INNER RH	TATA spare parts
0427200030J	GUIDE FRAME LH	TATA spare parts
0427200059J	STOPPER LH	TATA spare parts
0427200159J	STOPPER RH	TATA spare parts
0427200162J	TURNING WINDOW RH	TATA spare parts
0427200183J	DOOR HINGE LOWER RH	TATA spare parts
0427200201J	DOOR LH	TATA spare parts
0427200276J	COVER LH	TATA spare parts
0427200376J	COVER RH	TATA spare parts
0427201062J	TURNING WINDOW	TATA spare parts
0427201162J	TURNING WINDOW RH	TATA spare parts
0427201883J	DOOR HINGE LOWER LH	TATA spare parts
0427202083J	DOOR HINGE UPPER LH	TATA spare parts
0427202183J	DOOR HINGE UPPER RH	TATA spare parts
0427220025J	WEDGE PLATE LH	TATA spare parts
0427220125J	WEDGE PLATE RH	TATA spare parts
0427230003J	STRIKER PLATE	TATA spare parts
427250021	RUBBER CHANNEL	TATA spare parts
0427250021J	RUBBER CHANNEL	TATA spare parts
427250025	VELVETISED RUBBER CHANNEL	TATA spare parts
0427250025J	RUBBER CHANNEL	TATA spare parts
0427250120J	SEALING RUBBER CABDOOR	TATA spare parts
0427250256J	FRAME TURNING	TATA spare parts
0427250284J	WASHER	TATA spare parts
0427270087J	COVER LH	TATA spare parts
0427270187J	COVER RH	TATA spare parts
0427520113J	ANGLE LOCK	TATA spare parts
0427520313J	SUPPORT RH	TATA spare parts
0428150159J	FOOT REST-BUMPER	TATA spare parts
0428200239J	LINK LP/LH ASSY	TATA spare parts
0428300342J	ASY FLAP LH	TATA spare parts
0428800006J	ASSY.FENDER L.H.	TATA spare parts
0428800106J	ASSY.FENDER R.H.	TATA spare parts
0428800670J	BUMPER COMP	TATA spare parts
0428810401J	FENDER L.H.	TATA spare parts
0428810501J	FENDER RH	TATA spare parts
0428850440J	BRACKET LH	TATA spare parts
0428900935J	FRONT MOUTING BKT LH	TATA spare parts
0428901035J	BKT CAB MTG RH FRT	TATA spare parts
0428910236J	SLEEVE	TATA spare parts
0428910318J	MOUTING CUP FRONT	TATA spare parts
0428910336J	SPACER TUBE	TATA spare parts
0428910413J	PLATE	TATA spare parts
0428910618J	PROTECTIVE CAP-BOTTOM FRT	TATA spare parts

0428910636J	SPACER TUBE	TATA spare parts
0428910730J	U CLAMP	TATA spare parts
0428950015J	STUD	TATA spare parts
0428950064J	CLAMP	TATA spare parts
0429900037J	COTTER PIN BS1/2/3/4/6	TATA spare parts
0429900050J	CASTLE NUT M12X1.5	TATA spare parts
0429900140J	WASHER	TATA spare parts
0429900150J	CASTLE NUT	TATA spare parts
0429910015J	BALL PIN	TATA spare parts
0429920020J	SLEEVE	TATA spare parts
0429950020J	DOUBLE CLAMP	TATA spare parts
0429950040J	CLIP	TATA spare parts
0429950140J	SPRING CLIP	TATA spare parts
0429950520J	CLAMP-ON REAR AXLE	TATA spare parts
0429950620J	CLAMP	TATA spare parts
0429970049J	OVERHAUL KIT DI	TATA spare parts
0429970075J	SEALING PLUG	TATA spare parts
0429970149J	DE-CARB KIT	TATA spare parts
0429970249J	KIT OVERHAUL GASKET DI	TATA spare parts
0429970259J	OVER HAUL GASKET KIT 1210	TATA spare parts
430032004	NOZZLE HOLDER	TATA spare parts
430211009	NOZZLE HOLDER	TATA spare parts
430211049	NOZZLE W/HOLDER	TATA spare parts
430232004	NOZZLE HOLDER DI	TATA spare parts
432003628	ASSY INJECTOR NBEF TYPE 697 E III	TATA spare parts
432191217	INJECTOR	TATA spare parts
432193461	ASSY. INJECTOR (NBEF TYPE) BS3	TATA spare parts
432193462	ASSY. INJECTOR 4SP BS-III NBEF TYPE	TATA spare parts
433175147	NOZZLE INJECTOR 160 HP EURO I	TATA spare parts
433175463	NOZZLE 697 EURO III	TATA spare parts
433271046	INJ NOZZLE DI	TATA spare parts
433271268	NOZZLE	TATA spare parts
434250009	INJECTION NOZZLE	TATA spare parts
445020137	HIGH PRESSURE PUMPCP 3.3NH BS4	TATA spare parts
445020150	HIGH PRESSURE PUMPCP 3.3 BS3	TATA spare parts
445120123	INJECTOR CRIN1.6 BS3	TATA spare parts
445120161	INJECTOR CRIN3 BS4	TATA spare parts
445226042	RAIL LWR16 BS3	TATA spare parts
445226044	RAIL LWRN3 BS4	TATA spare parts
450213014	FUEL FILTER	TATA spare parts
450226029	FUEL FILTER ASSY DUAL	TATA spare parts
460414227	ASSY. FIP (207 DI SPACIO BSII)	TATA spare parts
460414245	ASSY FIP 4SPTC BSIII	TATA spare parts
460424232	ASSY FIP ROTARY	TATA spare parts
460424235	ASSY FIP ROTARY	TATA spare parts
460424364	ASSY FIP 497TC BSII	TATA spare parts
460424996	ASSY FIP ROTARY 497 BSIII	TATA spare parts



460424997	ASSY FIP ROTARY 4SP BSIII	TATA spare parts
460426330	FIP (ROTARY) 125HP EUROII 12V	TATA spare parts
460426332	FIP (ROTARY) 145HP EUROII 12V	TATA spare parts
460426333	FIP(ROTARY) 160HP EUROII 12V	TATA spare parts
460426334	FIP (ROTARY) 145HP EUROII 24V	TATA spare parts
460426335	PUMP FUEL INJECTION (ROTARY) EUROII	TATA spare parts
460426337	FIP (ROTARY) 125HP EUROII 24V	TATA spare parts
460426350	FUEL INJECTION PUMP (ROTARY) EURO2	TATA spare parts
460426351	ASSY FIP ROTARY BS II	TATA spare parts
460426387	ASSY. FIP (ROTARY) SK1613 BS2	TATA spare parts
460426396	FUEL INJ PUMP 180 HP EURO II UNIPOLAR	TATA spare parts
460426407	FUEL INJECTION PUMP (ROTARY) BS2	TATA spare parts
460426416	FUEL INJECTION PUMP (ROTARY) BS2	TATA spare parts
460426427	ASSY FIP (ROTARY) 145HP BS II	TATA spare parts
460426431	ASSY FIP ROTARY E-II	TATA spare parts
460426472	FIP TC BSIII ROTARY	TATA spare parts
460426489	FUEL INJECTION PUMP UNIPOLAR SYSTEM	TATA spare parts
460426492	FUEL INJECTION PUMP BI POLAR SYSTEM	TATA spare parts
460426505	FUEL INJECTION PUMP	TATA spare parts
460426508	PUMP FUEL INJECTION	TATA spare parts
460426520	PUMP FUEL INJECTION	TATA spare parts
460426991	ASSY.FIP BS III 697 TCIC BUS APPLICATIO	TATA spare parts
460426992	ASSY.FIP-MICO-VE6	TATA spare parts
460494418	F INJ PUMP W/KSB EXP TC	TATA spare parts
501003634	RELEASE DEVICE	TATA spare parts
501006795	CLUTCH CYLINDER	TATA spare parts
501202797	BREATHER	TATA spare parts
501209188	BALL ROLLER	TATA spare parts
501210058	SWITCH	TATA spare parts
501210855	PULSE SENSOR	TATA spare parts
501213003	STRUT 3 000 P	TATA spare parts
501213226	BUSH HOUSING 0 010 P	TATA spare parts
501213690	ADJUSTING SET	TATA spare parts
501213741	BRAKE ANCHER PLATE	TATA spare parts
501213867	SEALING CAP	TATA spare parts
501214770	PULSE SENSOR	TATA spare parts
501215084	BRAKE LINING KIT	TATA spare parts
501215085	REPAIR KIT BREMSTRAEGER P	TATA spare parts
501215955	CALIPER	TATA spare parts
501215956	CALIPER	TATA spare parts
501216474	SWITCH	TATA spare parts
501251245	OIL PUMP	TATA spare parts
501306828	SEALING CAP	TATA spare parts
501314108	OIL DAM	TATA spare parts
501314501	STOP PIN	TATA spare parts
501315159	BALL CUP	TATA spare parts
501315198	SEALING RING	TATA spare parts

501316950	REV. COUNTER	TATA spare parts
501316953	BRAKE DISC	TATA spare parts
501317161	PIVOT PIN 3 400 P	TATA spare parts
501317255	BUSH	TATA spare parts
501317373	COVER	TATA spare parts
501317662	BRAKE DISC 31 180 P	TATA spare parts
501318085	PRESSURE DISC 0 308 P	TATA spare parts
501318086	KLEMMMUTTER 0 422 P	TATA spare parts
501318087	END COVER 0 815 P	TATA spare parts
501318088	GASKET 0005 P	TATA spare parts
501318092	STEER.KNUCKLE 31120 P	TATA spare parts
501318097	SHAFT SEAL 0015 P	TATA spare parts
501318098	TA.ROLL.BEARING WAHLWEISE 0395 9	TATA spare parts
501318100	STEER.KNUCKLE 33000 P	TATA spare parts
501318101	VORDERRADNABE 22500 P	TATA spare parts
501318102	TA.ROLL.BEARING WAHLWEISE 2860 P	TATA spare parts
501318104	TA.ROLL.BEARING WAHLWEISE 4790 P	TATA spare parts
501318107	SHAFT SEAL WAHLWEISE 0029 9	TATA spare parts
501318112	SCREW	TATA spare parts
501318113	PIN 0	TATA spare parts
501318308	GASKET	TATA spare parts
501318374	AIR BELLOW (FRONT)	TATA spare parts
501318802	SCREEN INSERT	TATA spare parts
501320845	PULSE DISC	TATA spare parts
501321065	GASKET	TATA spare parts
501321099	HEXAGON SCREW	TATA spare parts
501321359	THRUST WASHER 0095 P	TATA spare parts
501322204	SHOCK ABSORBER 4980 P	TATA spare parts
501322258	KASSETENRING	TATA spare parts
501322758	SEALING CAP	TATA spare parts
501322828	GASKET	TATA spare parts
501322829	GASKET	TATA spare parts
501324626	GASKET	TATA spare parts
580464089	ASSY.ELECTRIC FUEL PUMP(EURO-II)	TATA spare parts
60005080009	GLASS TINTED (268X810X5 THK)50	TATA spare parts
60005080010	GLASS TINTED (288X810X5 THK)50	TATA spare parts
60005150025	PASSENGER DOOR GLASS	TATA spare parts
630000016	SHIM RING	TATA spare parts
630000036	SHIM RING	TATA spare parts
630001021	WASHER	TATA spare parts
630001048	WASHER	TATA spare parts
630001049	WASHER	TATA spare parts
630001075	WASHER	TATA spare parts
630004181	SHIM RING	TATA spare parts
630302090	LOCK WASHER	TATA spare parts
630501014	RETAINING RING	TATA spare parts
630501020	CIRCLIP	TATA spare parts

630501040	CIRCLIP	TATA spare parts
630501041	CIRCLIP	TATA spare parts
630501051	CIRCLIP	TATA spare parts
630501061	CIRCLIP	TATA spare parts
630501067	CIRCLIP	TATA spare parts
630501068	CIRCLIP	TATA spare parts
630501069	CIRCLIP	TATA spare parts
630501070	CIRCLIP	TATA spare parts
630501073	CIRCLIP	TATA spare parts
630501074	CIRCLIP	TATA spare parts
630501076	CIRCLIP	TATA spare parts
630501104	CIRCLIP	TATA spare parts
630501111	CIRCLIP	TATA spare parts
630501112	CIRCLIP	TATA spare parts
630501113	CIRCLIP	TATA spare parts
630501114	CIRCLIP	TATA spare parts
630501115	CIRCLIP	TATA spare parts
630501116	CIRCLIP	TATA spare parts
630501117	CIRCLIP	TATA spare parts
630501118	CIRCLIP	TATA spare parts
630501120	CIRCLIP	TATA spare parts
630501140	CIRCLIP	TATA spare parts
630501145	CIRCLIP	TATA spare parts
630501146	CIRCLIP	TATA spare parts
630501147	CIRCLIP	TATA spare parts
630501148	CIRCLIP	TATA spare parts
630501150	CIRCLIP	TATA spare parts
630501151	CIRCLIP	TATA spare parts
630501156	CIRCLIP	TATA spare parts
630501157	CIRCLIP	TATA spare parts
630501159	CIRCLIP	TATA spare parts
630501160	CIRCLIP	TATA spare parts
630501173	CIRCLIP	TATA spare parts
630501174	CIRCLIP	TATA spare parts
630501175	CIRCLIP	TATA spare parts
630501194	CIRCLIP	TATA spare parts
630501195	CIRCLIP	TATA spare parts
630501197	CIRCLIP	TATA spare parts
630501208	CIRCLIP	TATA spare parts
630501210	CIRCLIP	TATA spare parts
630501278	CIRCLIP	TATA spare parts
630501294	CIRCLIP	TATA spare parts
630501295	CIRCLIP	TATA spare parts
630501296	CIRCLIP	TATA spare parts
630501298	CIRCLIP	TATA spare parts
630501299	CIRCLIP	TATA spare parts
630502022	CIRCLIP	TATA spare parts

630502023	CIRCLIP	TATA spare parts
630502048	RETAINING RING	TATA spare parts
630502063	CIRCLIP	TATA spare parts
630502199	RETAINING RING	TATA spare parts
630505501	SNAP RING	TATA spare parts
630505536	SNAP RING	TATA spare parts
630513041	SNAP RING	TATA spare parts
630531052	CIRCLIP 42X2.5	TATA spare parts
630531064	CIRCLIP	TATA spare parts
630531065	RETAINING RING	TATA spare parts
630531141	CIRCLIP	TATA spare parts
630531222	V-RING	TATA spare parts
630532138	V-RING	TATA spare parts
631302047	CYLINDRICAL PIN	TATA spare parts
631302070	CYLINDRICAL PIN	TATA spare parts
631306073	CYLINDRICAL PIN	TATA spare parts
631306229	CYLINDRICAL PIN	TATA spare parts
631329049	SLOT.PIN	TATA spare parts
631329053	SLOT.PIN	TATA spare parts
631329175	SLOT.PIN	TATA spare parts
631610026	SET SCREW	TATA spare parts
632702904	TUBE	TATA spare parts
634300271	SHAFT SEAL	TATA spare parts
634303110	O-RING	TATA spare parts
634303332	O-RING	TATA spare parts
634304536	O-RING	TATA spare parts
634306012	O-RING	TATA spare parts
634307378	SCRAPER	TATA spare parts
634313223	O-RING	TATA spare parts
634313338	O-RING	TATA spare parts
634313505	O-RING	TATA spare parts
634316181	O-RING	TATA spare parts
634801044	SEALING RING	TATA spare parts
634801057	SEALING RING	TATA spare parts
634801062	SEALING RING	TATA spare parts
634801063	SEALING RING	TATA spare parts
634801074	KIT SEAL	TATA spare parts
634801205	ASSY.DAMPER MTG. BKT. RH	TATA spare parts
634801321	SEALING RING	TATA spare parts
635285060	JOINT BEARING	TATA spare parts
635376033	TA.ROLL.BEARING	TATA spare parts
635460021	BALL	TATA spare parts
635460024	BALL	TATA spare parts
636010540	HEXAGON SCREW	TATA spare parts
636010555	HEXAGON SCREW	TATA spare parts
636010575	HEXAGON SCREW	TATA spare parts
636011253	HEXAGON SCREW	TATA spare parts

636011294	HEXAGON SCREW	TATA spare parts
636011335	HEXAGON SCREW	TATA spare parts
636011487	HEXAGON SCREW	TATA spare parts
636011498	HEXAGON SCREW	TATA spare parts
636011522	SCREW	TATA spare parts
636011622	SCREW	TATA spare parts
636015277	HEXAGON SCREW	TATA spare parts
636015299	HEXAGON SCREW	TATA spare parts
636015321	HEXAGON SCREW	TATA spare parts
636015386	HEXAGON SCREW	TATA spare parts
636015387	HEXAGON SCREW	TATA spare parts
636015388	HEXAGON SCREW	TATA spare parts
636015392	HEXAGON SCREW	TATA spare parts
636015393	HEXAGON SCREW	TATA spare parts
636015406	HEXAGON SCREW	TATA spare parts
636015411	HEXAGON SCREW	TATA spare parts
636015601	HEXAGON SCREW	TATA spare parts
636016173	HEXAGON SCREW	TATA spare parts
636016178	HEXAGON SCREW	TATA spare parts
636016180	HEXAGON SCREW	TATA spare parts
636020118	HEXAGON SCREW	TATA spare parts
636020211	ASSY. PIVOT RUBBER BUSH RH BS1/3/4/6	TATA spare parts
636020403	HEXAGON SCREW	TATA spare parts
636020406	HEXAGON SCREW	TATA spare parts
636023052	SCREW	TATA spare parts
636023082	HEXAGON SCREW M16X1.5X 60 MBN10105 10	TATA spare parts
636101741	CAP SCREW	TATA spare parts
636101829	HEXAGON SCREW	TATA spare parts
636301055	SCREW PLUG	TATA spare parts
636302021	SCREW PLUG	TATA spare parts
636302045	SCREW PLUG	TATA spare parts
636302068	SCREW PLUG	TATA spare parts
636304048	SCREW PLUG	TATA spare parts
636304049	SCREW PLUG	TATA spare parts
636305061	SCREW PLUG	TATA spare parts
636611145	STUD	TATA spare parts
636611146	STUD	TATA spare parts
637006125	HEXAGON NUT	TATA spare parts
637006202	HEXAGON NUT	TATA spare parts
637011053	HEXAGON NUT	TATA spare parts
637011589	HEXAGON NUT	TATA spare parts
637011615	LOCKING NUT M 16 X 1.5	TATA spare parts
637510037	PLUG	TATA spare parts
637510110	PROTECT.SLEEVE	TATA spare parts
637510568	PLUG	TATA spare parts
637835026	UNION SCREW	TATA spare parts
637835515	UNION SCREW	TATA spare parts

64605060001	GLASS (460X692X5 THK)	TATA spare parts
64605070001	GLASS CLEAR(397X722X5 THK)	TATA spare parts
659160068	CABLE CLIP	TATA spare parts
662750944011590	REAR WINDSHIELD GLASS /CTR TEMPERED	TATA spare parts
664020075	SPHERICAL RING	TATA spare parts
668071240022600	FR WS/6HD2260X1240X7/LM.GR.BND	TATA spare parts
669970640	SEALING FIBER WASHER	TATA spare parts
671190107	GREASE	TATA spare parts
69015080003	GLASS TINTED (268X810X5)50PERCGRE	TATA spare parts
730002654	SHIM	TATA spare parts
730002655	SHIM	TATA spare parts
730002656	SHIM	TATA spare parts
730002657	SHIM	TATA spare parts
730002658	SHIM	TATA spare parts
730002659	SHIM	TATA spare parts
730002934	SHIM	TATA spare parts
730002935	SHIM	TATA spare parts
730002936	SHIM	TATA spare parts
730002937	SHIM	TATA spare parts
730002938	SHIM	TATA spare parts
730002939	SHIM	TATA spare parts
730003431	SHIM	TATA spare parts
730003432	SHIM	TATA spare parts
730003433	SHIM	TATA spare parts
730003434	SHIM	TATA spare parts
730003435	SHIM	TATA spare parts
730003436	SHIM	TATA spare parts
730004731	SHIM	TATA spare parts
730004732	SHIM	TATA spare parts
730004733	SHIM	TATA spare parts
730004734	SHIM	TATA spare parts
730004735	SHIM	TATA spare parts
730004736	SHIM	TATA spare parts
730004737	SHIM	TATA spare parts
730005856	SHIM	TATA spare parts
730005857	SHIM	TATA spare parts
730006164	SHIM	TATA spare parts
730006165	SHIM	TATA spare parts
730006166	SHIM	TATA spare parts
730006167	SHIM	TATA spare parts
730006168	SHIM	TATA spare parts
730006169	SHIM	TATA spare parts
730006179	SHIM	TATA spare parts
730006180	SHIM	TATA spare parts
730006181	SHIM	TATA spare parts
730006182	SHIM	TATA spare parts
730006183	SHIM	TATA spare parts

730006184	SHIM	TATA spare parts
730006532	SHIM	TATA spare parts
730006533	SHIM	TATA spare parts
730006534	SHIM	TATA spare parts
730007640	SHIM	TATA spare parts
730007781	SHIM	TATA spare parts
730007782	SHIM	TATA spare parts
730008057	SEALING RING	TATA spare parts
730008604	SEALING RING	TATA spare parts
730008637	SEALING RING	TATA spare parts
730101840	WASHER	TATA spare parts
730103102	INTERMEDIATE WASHER	TATA spare parts
730104083	WASHER	TATA spare parts
730104366	WASHER	TATA spare parts
730113437	RING	TATA spare parts
730150767	WASHER	TATA spare parts
730260330	BEARING BUSH	TATA spare parts
730260702	BUSH	TATA spare parts
730260753	BEARING BUSH	TATA spare parts
730300005	LOCK WASHER	TATA spare parts
730300093	LOCK WASHER	TATA spare parts
730300430	SNAP RING	TATA spare parts
730505053	LOCKING WIRE	TATA spare parts
730513755	SNAP RING	TATA spare parts
730513756	SNAP RING	TATA spare parts
730513757	SNAP RING	TATA spare parts
730513758	SNAP RING	TATA spare parts
730513759	SNAP RING	TATA spare parts
730513760	SNAP RING	TATA spare parts
730514017	SNAP RING	TATA spare parts
731101049	BLIND RIVET	TATA spare parts
731201765	CYLINDRICAL PIN	TATA spare parts
731201767	PIN	TATA spare parts
732040385	COMPRESSION SPRING	TATA spare parts
732040386	COMPRESSION SPRING	TATA spare parts
732040409	COMPRESSION SPRING	TATA spare parts
732040630	COMPRESSION SPRING	TATA spare parts
732040819	COMPRESSION SPRING	TATA spare parts
732040984	COMPRESSION SPRING	TATA spare parts
732040985	COMPRESSION SPRING	TATA spare parts
732041374	COMPRESSION SPRING	TATA spare parts
732041612	COMPRESSION SPRING	TATA spare parts
734307287	SEALING RING	TATA spare parts
734310104	SHAFT SEAL	TATA spare parts
734319459	SHAFT SEAL	TATA spare parts
735320500	NEEDLE CAGE	TATA spare parts
735320816	NEEDLE CAGE	TATA spare parts

735330804	BALL BEARING	TATA spare parts
735358192	NEEDLE SLEEVE	TATA spare parts
735470115	NEEDLE ROLLER	TATA spare parts
736008077	FITTING BOLT DC-NR.A942 990 00 114 10.9	TATA spare parts
736010179	HEXAGON SCREW	TATA spare parts
736010180	HEXAGON SCREW	TATA spare parts
736010181	HEXAGON SCREW	TATA spare parts
736305052	SCREW PLUG	TATA spare parts
737006095	LOCKING NUT	TATA spare parts
737835238	UNION SCREW	TATA spare parts
750112047	FLANGE PACKING	TATA spare parts
750112096	GUIDE RING	TATA spare parts
750115969	NEEDLE CAGE	TATA spare parts
750115970	NEEDLE CAGE	TATA spare parts
750115971	NEEDLE CAGE	TATA spare parts
750115972	NEEDLE CAGE	TATA spare parts
750115973	NEEDLE CAGE	TATA spare parts
750115974	ROLLER CAGE	TATA spare parts
750116206	BALL BEARING	TATA spare parts
750116404	BALL BEARING	TATA spare parts
750117083	TA.ROLL.BEARING	TATA spare parts
750117232	TA.ROLL.BEARING	TATA spare parts
750117518	TA.ROLL.BEARING	TATA spare parts
750117844	TA.ROLL.BEARING	TATA spare parts
750117881	TA.ROLL.BEARING	TATA spare parts
750118476	CY.ROLL.BEARING	TATA spare parts
750132100	VALVE	TATA spare parts
750146001	RING PIECE	TATA spare parts
769171700	LOCKING LEVER	TATA spare parts
769171725	PUMP	TATA spare parts
769171728	DOUBLE GEAR	TATA spare parts
769171786	PLANET SHAFT	TATA spare parts
769171832	GEAR SHIFT COVER	TATA spare parts
99906	BEARING CONE-4021	TATA spare parts
1-99-934-013	QUILL ROLLER BEARING	TATA spare parts
1000035	CAM SHAFT BUSHING	TATA spare parts
10003200	ASSY HYD OIL TANK 50 LTRS	TATA spare parts
10005000	OIL TANK ASSY	TATA spare parts
10009000	SCISSOR TIPPING ASSLY ( WITHOUT CYLINDER	TATA spare parts
10009002	REAR HINGE SHAFT	TATA spare parts
10009210	REAR HINGE BODY BRACKET ASSLY.	TATA spare parts
10009212	REAR HINGE SHAFT BUSH ASSY	TATA spare parts
10009321	SCISSOR LINK ( LH-RH)	TATA spare parts
10009323	BUSH SCISSOR LINK	TATA spare parts
10013100	OIL TANK MTG. BKT	TATA spare parts
10013200	OIL TANK	TATA spare parts
100134210940	OIL PRESSURE GAUGE	TATA spare parts



100134211156	PULL ROD LP LPO 316MM	TATA spare parts
100134211508	CABLE SET SE RHD	TATA spare parts
1004320059	CARBON BRUSH	TATA spare parts
100501	ELBOW- GSOV 1/2 NPT	TATA spare parts
100502	ELBOW HPR OUTLET BSIII	TATA spare parts
1006048	NUT	TATA spare parts
1006074	WASHER-SPRING	TATA spare parts
1007247	NUT	TATA spare parts
1007617	WASHER-SPRING	TATA spare parts
1007618	NUT	TATA spare parts
1007631	WASHER-SPRING	TATA spare parts
100801000002	ENGINE W/O RCP	TATA spare parts
100801000004	ENGINE ASSY 692DI RHD	TATA spare parts
100801000006	ENG RHD	TATA spare parts
100801000110	HALF ENG 692DI	TATA spare parts
100803141001	PISTON STD	TATA spare parts
100803141002	PISTON STD 1	TATA spare parts
100803141003	PISTON STD2	TATA spare parts
100803141004	PISTON RS1	TATA spare parts
100803141005	PISTON RS2	TATA spare parts
100803149901	SET PISTON RINGS STD	TATA spare parts
100803149903	SET PISTON RINGS RS1	TATA spare parts
100803149904	SET PISTON RINGS RS2	TATA spare parts
100803310201	SET MAIN BRG STD	TATA spare parts
100803310202	SET MAIN BRG W/THW STD	TATA spare parts
100803310203	SET MAIN BRG W/THW RS1	TATA spare parts
100803310204	SET MAIN BRG W/THW RS2	TATA spare parts
100803310205	SET MAIN BRG W/THW RS3	TATA spare parts
100803310206	SET MAIN BRG W/THW RS4	TATA spare parts
10081000	LEVER MECHANISM ASSLY.	TATA spare parts
10081004	CONNECTING ROD	TATA spare parts
10081006	LEVER ARM	TATA spare parts
10082000	HYDRAULICTANK	TATA spare parts
100825200101	CLUTCH DISC	TATA spare parts
100825400101	CL PR PLATE 280 DIA	TATA spare parts
100831508401	BUSH	TATA spare parts
1008392	SLACK ADJUSTER	TATA spare parts
100842076801	DOUBLE SOCKET	TATA spare parts
100843000500	AIR CONTAINER	TATA spare parts
100882010401	WIPER MOTOR RHD W/O LINK	TATA spare parts
100882010402	WIPER MOTOR LHD W/O LINK	TATA spare parts
100882010701	WHEEL BOX 17W W/O LINK	TATA spare parts
10100005	Rear Hinge Shaft	TATA spare parts
10100007	Tail Door Hinge Pin	TATA spare parts
10100008	Washer for Tail Door Hinge Pin	TATA spare parts
10100009	Cylinder Mounting Pin	TATA spare parts
10100010	Cylinder Eye Spacer	TATA spare parts

10100011	Washer for Cylinder Mounting Pin	TATA spare parts
10100016	Air Control Valve Mounting Plate	TATA spare parts
10100018	Rear Hinge Pin Lock Plate	TATA spare parts
10100032	Metal Strip - Straight	TATA spare parts
10100033	Metal Strip - Bent	TATA spare parts
1010458	BOLT-FLANGE	TATA spare parts
1010461	NEEDLE ROLLER BRG.	TATA spare parts
1010462	BOLT-FLANGE	TATA spare parts
1010463	BOLT-FLANGE	TATA spare parts
1010472	SEAL-OIL	TATA spare parts
1010474	PLUG-DRAIN	TATA spare parts
1010484	PIN-DOWEL	TATA spare parts
1010485	BOLT & WASHER ASSY	TATA spare parts
1010486	GASKET	TATA spare parts
1010487	PLUG-DRAIN	TATA spare parts
1010493	PIN-CLEVIS	TATA spare parts
1010494	CLEVIS	TATA spare parts
1010497	STAY	TATA spare parts
1010511	BOLT-SET	TATA spare parts
1010514	GREASE NIPPLE	TATA spare parts
1010515	FORK-CLUTCH RELEASE	TATA spare parts
1010537	BOLT-FLANGE	TATA spare parts
1010595	KEY-SUNK	TATA spare parts
10106000	Subframe Assy - Standard Body	TATA spare parts
10106001	Cross Member	TATA spare parts
10106006	BODY PROP MOUNTING PIN	TATA spare parts
10106007	Body Guide	TATA spare parts
10106009	Cross Member	TATA spare parts
1010609	PEACE-LOCK	TATA spare parts
1010618	PIN-SPLIT	TATA spare parts
10106300	Cross Bracing	TATA spare parts
10106303	Cross Bracing Plate	TATA spare parts
1010634	SLEEVE-1ST & REVERSE	TATA spare parts
10106402	Body Prop Bush	TATA spare parts
1010644	BOLT-FLANGE 10X70	TATA spare parts
1010646	BUSHING	TATA spare parts
1010649	BOLT-SEAL	TATA spare parts
1010655	PLUG-DUST	TATA spare parts
10106600	Cylinder Mounting Cradle Assy	TATA spare parts
1010661	BOLT-FLANGE 10X30	TATA spare parts
1010664	BOLT-FLANGE 10X70	TATA spare parts
1010665	NUT-FLANGE	TATA spare parts
10106700	Oil Tank Mounting Bracket	TATA spare parts
1010674	PLUG-DUST	TATA spare parts
1010678	RAIL-2ND & 3RD	TATA spare parts
1010679	PIN-INTERLOCK	TATA spare parts
1010684	RAIL-4TH & 5TH	TATA spare parts

1010687	RAIL-1ST & REV A	TATA spare parts
1010688	RAIL-1ST & REV.SHIFT B	TATA spare parts
1010689	PIN-INTERLOCK	TATA spare parts
1010694	FORK-1ST & REV.	TATA spare parts
1010698	JAW-1ST & REV.	TATA spare parts
1010699	JAW SHIFT-1ST & REV	TATA spare parts
1010700	JAW-2ND & 3RD	TATA spare parts
1010702	BOLT-JAW	TATA spare parts
1010703	SPRING-POPPET	TATA spare parts
1010704	LEVER-1ST & REV.SHIFT	TATA spare parts
1010706	SHAFT-1ST & REV.SHIFT LEVER	TATA spare parts
1010707	WASHER-THRUST	TATA spare parts
1010708	BOLT-SET	TATA spare parts
10107100	REAR HINGE BRACKET & BUSH ASSY LH	TATA spare parts
10107101	Rear Hinge Steel Bush Outer	TATA spare parts
10107102	Rear Hinge Inner Bush-SGI	TATA spare parts
10107110	REAR HINGE BUSH ASSEMBLY	TATA spare parts
1010713	NUT	TATA spare parts
1010715	RING-O	TATA spare parts
10107200	REAR HINGE BRACKET & BUSH ASSY RH	TATA spare parts
1010724	BALL-STEEL	TATA spare parts
1010725	GASKET	TATA spare parts
1010733	BREATHER-AIR	TATA spare parts
1010754	RING-O	TATA spare parts
1010756	SEAL-DUST	TATA spare parts
1010765	SEAL-OIL	TATA spare parts
1010766	SHIM	TATA spare parts
1010767	WASHER-PLAIN	TATA spare parts
1010769	PIN-LOCK	TATA spare parts
1010771	RETAINER-SPRING	TATA spare parts
1010774	NUT-FLANGE	TATA spare parts
1010775	PIN-SPRING	TATA spare parts
1010779	SEAL-OIL	TATA spare parts
1010780	BUSHING-SPEEDOMETER	TATA spare parts
1010786	GASKET	TATA spare parts
1010792	BOLT-FLANGE 10X95	TATA spare parts
1010793	BOLT-FLANGE 10X125	TATA spare parts
1010797	SEAL-OIL	TATA spare parts
1010799	RING-SNAP	TATA spare parts
10108000	PIVOT AND ATTACHMENT SET	TATA spare parts
10108001	Attachment Plate 1	TATA spare parts
10108002	Attachment Plate 2	TATA spare parts
10108003	Attachment Plate 3	TATA spare parts
10108004	Attachment Plate 4	TATA spare parts
10108005	Attachment Plate 5	TATA spare parts
10108006	Lower Pivot Attachment 1	TATA spare parts
10108007	Lower Pivot Attachment 2	TATA spare parts

10108008	Lower Pivot Attachment 3	TATA spare parts
10108009	Upper Pivot Attachment 1	TATA spare parts
10108010	Upper Pivot Attachment 2	TATA spare parts
1010805	SLEEVE-PTO	TATA spare parts
1010810	SPRING-RETURN	TATA spare parts
1010811	FORK-PTO SHIFT	TATA spare parts
1010813	BOLT 8X16	TATA spare parts
1010814	BOLT-FLANGE 8X25	TATA spare parts
1010815	KEY-SUNK	TATA spare parts
1010839	PIN-SNAP	TATA spare parts
10109000	Oil Tank Assy	TATA spare parts
10109005	Breather Flange	TATA spare parts
10109009	Tipping Valve Mounting Block ( 01T1d0	TATA spare parts
10109012	DRAIN PLUG 3/4INCH BSP WITH O-RING	TATA spare parts
10109100	Oil Level Indicator 3INCH	TATA spare parts
10111005	Mudguard Flap -3rd Axle	TATA spare parts
1011168	NUT-T JOINT	TATA spare parts
1011197	SEALING RING - SECONDARY	TATA spare parts
1011199	SEALING RING - PRIMARY	TATA spare parts
10113000	2nd Axle Mudguard Assy	TATA spare parts
10114000	Tail Gate Locking Mechanism	TATA spare parts
10114002	Cam	TATA spare parts
10114003	Locking Hook	TATA spare parts
10114004	FORK LH THREADED	TATA spare parts
10114005	Tie Rod	TATA spare parts
10114006	Fork - RH Thread	TATA spare parts
10114009	Spring	TATA spare parts
10114010	Cross Rod	TATA spare parts
10114011	FORK PIN	TATA spare parts
10114015	LOCKING PIN	TATA spare parts
10114100	Hammer Assy	TATA spare parts
10114102	HAMMER PIN DIA40X70L	TATA spare parts
10114200	Profile Mounting Assy	TATA spare parts
10114300	Bearing Assy - Tail Gate lock Mechanism	TATA spare parts
10114301	Outer Bush-Taildoor Locking Mechanism	TATA spare parts
10114302	Inner Bush ( SGI ) - Taildoor Locking Me	TATA spare parts
10114400	TIE ROD	TATA spare parts
10114500	EYE BOLT WITH NUT	TATA spare parts
10116000	Cylinder Mounting Bracket	TATA spare parts
10116006	Inner Bush - Cylinder Mounting Bracket	TATA spare parts
10116007	Inner Bush - Cylinder Mounting Bracket	TATA spare parts
1011875	BEARING-PINION OUTER	TATA spare parts
1011898	SEAT-LOCK	TATA spare parts
1011919	BREATHER-AIR	TATA spare parts
1011922	BOLT-DIFF.CARRIER	TATA spare parts
1011923	BOLT-DIFF.CARRIER	TATA spare parts
1011934	BOLT-ADJUST LOCK PLATE	TATA spare parts

1012508	BOLT-REDUCTION GEAR	TATA spare parts
1012509	NUT-REDUCTION GEAR	TATA spare parts
1012532	BRG-BALL	TATA spare parts
1012536	COVER-DUST	TATA spare parts
1012541	COVER-DUST	TATA spare parts
1012549	BOLT-DIFF CASE SETTING	TATA spare parts
1012556	WASHER-THRUST DIFF.PINION	TATA spare parts
1012580	SPIDER INTER DIFF.PINION	TATA spare parts
1012582	BUSH-DIFF.CAGE	TATA spare parts
1012583	RING-SNAP.BRG.INPUT	TATA spare parts
1012587	RING-SNAP OUTPUT SHAFT	TATA spare parts
1012588	SLEEVE HSG-COVER	TATA spare parts
1012590	CLUTCH DIFF.LOCK	TATA spare parts
1012591	GASKET-CYLINDER BRKT	TATA spare parts
1012612	BOLT-SHIFT UNIT FIX.	TATA spare parts
1012613	BOLT	TATA spare parts
1012614	BOLT	TATA spare parts
1012616	PIN-SPLIT	TATA spare parts
1012618	BEARING-INPUT SHAFT	TATA spare parts
1012619	BEARING-TAPER ROLLER	TATA spare parts
1013465	BEARING-ROLLER	TATA spare parts
1015330	BEARING-TAPER ROLLER	TATA spare parts
1015333	CAP-BRG	TATA spare parts
1015334	BOLT-BRG CAP	TATA spare parts
1015335	PLATE-LOCK	TATA spare parts
1015343	SCREW-ADJ	TATA spare parts
1015344	PAWL-LOCK	TATA spare parts
1015347	COLLAR-PINION BRG	TATA spare parts
1015350	BOLT-RET	TATA spare parts
1015352	BEARING-TAPER ROLLER	TATA spare parts
1015423	PLATE-OIL INTAKE	TATA spare parts
1015424	BOLT-FLANGE	TATA spare parts
1015425	BOLT-FLANGE	TATA spare parts
1015429	PIN-DOWEL	TATA spare parts
1015430	RING-O	TATA spare parts
1015431	PLUG-TAPER	TATA spare parts
1015451	SPACER	TATA spare parts
1015452	NUT-LOCK	TATA spare parts
1015453	ADAPTER-OIL FEED	TATA spare parts
1015459	BRG.-ROLLER	TATA spare parts
1015460	RING-SNAP	TATA spare parts
1015481	BEARING-PILOT	TATA spare parts
1015483	MAIN SHAFT	TATA spare parts
1015484	RING-SNAP	TATA spare parts
1015485	RING-SNAP	TATA spare parts
1015486	WASHER	TATA spare parts
1015490	BEARING-NEEDLE	TATA spare parts

1015491	SLEEVE-1ST	TATA spare parts
1015492	WASHER-1ST GEAR	TATA spare parts
1015501	BEARING-NEEDLE	TATA spare parts
1015502	SLEEVE-3RD BEARING	TATA spare parts
1015506	VEARING-NEEDLE	TATA spare parts
1015507	SLEEVE-BEARING	TATA spare parts
1015508	SPACER	TATA spare parts
1015509	WASHER-THRUST	TATA spare parts
1015512	BEARING-ROLLER	TATA spare parts
1015514	BEARING-ROLLER	TATA spare parts
1015518	SPACER	TATA spare parts
1015523	KEY-SUNK	TATA spare parts
1015527	PLATE-LOCK	TATA spare parts
1015528	SHEET-LOCK(S)	TATA spare parts
1015534	BEARING-NEEDLE	TATA spare parts
1015535	SPACER	TATA spare parts
1015536	WASHER	TATA spare parts
1015537	SHAFT-REVERSE	TATA spare parts
1015539	WASHER-LOCK	TATA spare parts
1015542	PLATE-OIL SEPARATE(S)	TATA spare parts
1015543	RING-O	TATA spare parts
1015544	NUT-CASTLE	TATA spare parts
1015545	BRG.-NEEDLE ROLLER	TATA spare parts
1015549	BOLT-BACK PLATE	TATA spare parts
1015550	RING-SEAL	TATA spare parts
1015551	PIN-SPLIT	TATA spare parts
1015552	RING-O	TATA spare parts
1015554	RING-SNAP	TATA spare parts
1015555	HUB-1ST & REVERSE	TATA spare parts
1015565	SEAL-OIL	TATA spare parts
1015579	BOLT-FLANGE 10X45	TATA spare parts
1015582	BRACKET-CLIP	TATA spare parts
1015584	CASE-LOWER	TATA spare parts
1015585	GASKET	TATA spare parts
1015592	FORK-4TH & 5TH	TATA spare parts
1015594	PLUG-SCREW	TATA spare parts
1015604	GASKET(S)	TATA spare parts
1015613	PLATE-INTERLOCK	TATA spare parts
1015614	LEVER-GEAR SHIFT SLIDING	TATA spare parts
1015619	BOLT	TATA spare parts
1015622	BRG.-ROLLER	TATA spare parts
1015623	RING-SNAP	TATA spare parts
1015624	RING-SEAL	TATA spare parts
1015629	SPACER	TATA spare parts
1015631	BRG-NEEDLE ROLLER	TATA spare parts
1015633	BOLT	TATA spare parts
1015634	PLATE-LOCK	TATA spare parts

1015635	WASHER-LOCK	TATA spare parts
1015637	RET.-BRG.	TATA spare parts
1015642	BOLT-FLANGE	TATA spare parts
1015643	BOLT-FLANGE	TATA spare parts
1015647	LEVER-SPLITTER SHIFT	TATA spare parts
1015652	PIECE-SPLITTER SHIFT FORK	TATA spare parts
1015653	BOLT-REAMER	TATA spare parts
1015654	FORK	TATA spare parts
1015655	RING-SNAP	TATA spare parts
1015656	PIN-POPPET	TATA spare parts
1015660	BOLT-FLANGE	TATA spare parts
1015661	CYLINDER-SERVO	TATA spare parts
1015663	GASKET-PTO	TATA spare parts
1015676	BOLT-FLANGE 8X35	TATA spare parts
1015678	PLUG-TAPER	TATA spare parts
1015780	SCREW-SET	TATA spare parts
1016387	LEVER-SELECTING B	TATA spare parts
1018656	BEARING-BALL	TATA spare parts
1019127	FLANGE-PTO OUTPUT	TATA spare parts
1019291	CYLINDER ASSY	TATA spare parts
1019352	BRACKET-HANGER	TATA spare parts
1019353	COVER	TATA spare parts
1020001202	SPECIAL CEMENT TRANSFER HOSE 4M	TATA spare parts
1020147	SHAFT-PTO OUTPUT	TATA spare parts
1020149	BEARING-NEEDLE ROLLER	TATA spare parts
1020150	BEARING-ROLLER	TATA spare parts
1020151	COVER-PTO REAR	TATA spare parts
1020153	POWER CYLINDER ASSY	TATA spare parts
1020208	COUNTER SHAFT-4RD GEAR	TATA spare parts
1020214	GEAR-SPLITTER	TATA spare parts
1020215	COUNTER SHAFT-CONSTANT GEAR	TATA spare parts
1020297	GEAR-1ST	TATA spare parts
1020771	WASHER-LOCK	TATA spare parts
1020772	NUT-ADJUST	TATA spare parts
1023271	FLANGE-COMP	TATA spare parts
1024587	WASHER	TATA spare parts
1025173	PLATE-CLUTCH HSG.COVER	TATA spare parts
1026137	FLANGE-COMP	TATA spare parts
1026322	WORM-SPEEDOMETER	TATA spare parts
1026323	GEAR-SPEEDOMETER	TATA spare parts
1026572	CASE-SELECTING LEVER	TATA spare parts
1026582	LEVER-GEAR SHIFT	TATA spare parts
102660	DIFF BEARING CONE LH	TATA spare parts
1026679	SEAL-OIL ; INNER	TATA spare parts
1026680	RING-SNAP	TATA spare parts
1026681	SEAL-OIL ; OUTER	TATA spare parts
1026729	JOINT ROD ASSY	TATA spare parts

1026787	BOLT-WITH WASHER	TATA spare parts
1026996	FLANGE ASSY OUTPUT	TATA spare parts
1027114	CLIP-AIR VENT HOSE	TATA spare parts
1027192	HUB	TATA spare parts
1027193	SLEEVE	TATA spare parts
1027304	FORK-2ND & 3RD	TATA spare parts
1027334	CONNECTOR	TATA spare parts
1027385	BRACKET-SPEED CABLE	TATA spare parts
1027554	SPRING-1ST & REV.RETURN	TATA spare parts
1027698	BOLT-PAD	TATA spare parts
1027908	SPRING	TATA spare parts
1027909	PIN	TATA spare parts
1028206	COBRA BRACKET	TATA spare parts
1028252	COBRA BRACKET	TATA spare parts
1028393	FORK-CLUTCH RELEASE	TATA spare parts
1028480	BRACKET A-CLUTCH BOOSTER	TATA spare parts
1028529	GEAR-DRIVE HELICAL;LH	TATA spare parts
1028530	GEAR-DRIVEN HELICAL;RH	TATA spare parts
1028532	GEAR-INTER DIFF.OUTER	TATA spare parts
1028561	PINION-INTER DIFF	TATA spare parts
1028987	CASE-OIL PUMP	TATA spare parts
1029152	KEY-WOODRUF	TATA spare parts
1029155	GEAR-OIL PUMP	TATA spare parts
1029163	SPACER	TATA spare parts
1029354	RING-INNER	TATA spare parts
1029512	COUNTER SHAFT-3RD GEAR	TATA spare parts
1029624	RING-OUTER	TATA spare parts
1029800	LEVER-SELECTING A	TATA spare parts
1030618	Dust Cap	TATA spare parts
1030619	Hose Clamp	TATA spare parts
1030730	SEAL-OIL	TATA spare parts
1030731	SEAL-OIL	TATA spare parts
103089	WASHER PLAIN	TATA spare parts
1030960	COVER-INPUT	TATA spare parts
1031032	CASE SET-CARR.	TATA spare parts
1031033	CARR CASE	TATA spare parts
1031034	COVER-DIFF CARR	TATA spare parts
1031038	BOLT-DIFF.CASE	TATA spare parts
1031039	GEAR-DIFF.SIDE	TATA spare parts
1031040	GEAR-DIFF.PINION	TATA spare parts
1031041	WASHER-THRUST DIFF GEAR	TATA spare parts
1031042	WASHER-THRUST DIFF.PINION	TATA spare parts
1031043	SPIDER-DIFF.PINION	TATA spare parts
1031044	GEAR & PINION SET	TATA spare parts
1031047	BEARING-PILOT PINION	TATA spare parts
1031048	RET-PINION BRG	TATA spare parts
1031049	BRG-RETAINER	TATA spare parts



1031050	SHIM (1.0MM)	TATA spare parts
1031051	SHIM (0.2MM)	TATA spare parts
1031052	SHIM (0.1MM)	TATA spare parts
1031053	SHIM D(0.05)	TATA spare parts
1031054	SHIM (1.0MM)	TATA spare parts
1031055	SHIM (0.2MM)	TATA spare parts
1031056	SHIM (0.1MM)	TATA spare parts
1031057	CASE-SET INTER DIFF	TATA spare parts
1031058	CASE-INTER DIFF OUTER	TATA spare parts
1031061	WASHER-INTER DIFF.INNER	TATA spare parts
1031062	WASHER-INTER DIFF.OUTER	TATA spare parts
1031063	GEAR-INTER DIFF.INNER	TATA spare parts
1031064	SHAFT-THROUGH	TATA spare parts
1031065	CASE-SET CARR	TATA spare parts
1031066	CASE-CARR	TATA spare parts
1031067	GEAR SET-REDUCTION RATIO 6.166	TATA spare parts
1031070	SEAL-OIL	TATA spare parts
1031071	RET-PINION BRG	TATA spare parts
1031072	SHIM (1.0MM)	TATA spare parts
1031073	SHIM (0.2MM)	TATA spare parts
1031074	SHIM (0.1MM)	TATA spare parts
1031075	COLLAR	TATA spare parts
1031115	RING-LOCK PILOT BRG.	TATA spare parts
1031136	COVER-DUST	TATA spare parts
1031138	BOLT-FLANGE	TATA spare parts
1032684	CASE SET-DIFF	TATA spare parts
1032961	SHAFT-AXLE (FR/LH RR/RH)	TATA spare parts
1032962	SHAFT-AXLE (FR/RH RR/LH)	TATA spare parts
1033402	SELECT LEVER ASSY	TATA spare parts
1033408	DRIVE ASSY-PINION	TATA spare parts
1033409	GEAR ASSY-4TH	TATA spare parts
1033448	GEAR ASSY-2ND	TATA spare parts
1033449	GEAR ASSY-3RD	TATA spare parts
1033640	FLANGE-COMP	TATA spare parts
1033896	RING-MIDDLE	TATA spare parts
1034277	SHIM 0.5MM	TATA spare parts
1034330	PAD-SPRING	TATA spare parts
1034595	GEAR & PINION SET (R6.833)	TATA spare parts
1034598	GEAR SET-REDUCTION (R6.833)	TATA spare parts
1035154	RING-OUTER	TATA spare parts
1035158	CONE-SPLITTER SYN.	TATA spare parts
1035159	PINION ASSY-SPLITTER	TATA spare parts
1035498	GEAR-REVERSE	TATA spare parts
1036868	BEARING-HUB INNER	TATA spare parts
1036870	BEARING-HUB OUTER	TATA spare parts
1037031	RETAINER ASSY	TATA spare parts
1037049	OIL PUMP ASSY	TATA spare parts

1037057	STRAINER	TATA spare parts
1037058	BOLT-FLANGE 6X75	TATA spare parts
1037059	SHAFT-OIL PUMP	TATA spare parts
1037200	HOSE-SPLIT OIL	TATA spare parts
1037201	CONNECTOR-L TYPE	TATA spare parts
1037202	CASE-SPLITTER	TATA spare parts
1037209	BOLT-JOINT	TATA spare parts
1037244	STRAINER	TATA spare parts
1037246	RETAINER-OIL PUMP	TATA spare parts
1037569	BOLT	TATA spare parts
1037594	C/BOOSTER-AUTO.	TATA spare parts
1037658	GEAR ASSY-PTO	TATA spare parts
1037661	POWER TAKEOFF ASSY	TATA spare parts
1038172	TAG-RATIO	TATA spare parts
1038173	FLANGE-COMP	TATA spare parts
1038717	BOLT-AXLE SHAFT	TATA spare parts
1039661	PTO ASSEMBLY	TATA spare parts
1039842	RET.-FRONT BRG.	TATA spare parts
1039849	SHAFT ASSY-CLUTCH RELEASE	TATA spare parts
1039869	GEAR-IDLER	TATA spare parts
1039923	HOSE-FLEXIBLE	TATA spare parts
1039933	BRACKET B-CLUTCH BOOSTER	TATA spare parts
1039962	BOLT-FLANGE SPEEDO SENSOR MTG.	TATA spare parts
10400010	CYLINDER MOUNTING SPACER	TATA spare parts
10400017	AIR CONTROL VALVE MOUNTING PLATE (RETRO)	TATA spare parts
10400061	AIR VALVE MOUNTING BRACKET	TATA spare parts
10400062	AIR VALVE MOUNTING BRACKET SHS70X70X2 55	TATA spare parts
1041545	SPRING-SYN.	TATA spare parts
1041578	RING-INNER	TATA spare parts
1041579	HUB	TATA spare parts
1041580	HUB	TATA spare parts
1041581	KEY-SHIFTING	TATA spare parts
1041583	RING-MIDDLE	TATA spare parts
1041674	SLEEVE	TATA spare parts
1041723	CLUTCH HOUSING	TATA spare parts
1041765	CONNECTOR-I	TATA spare parts
1041819	PUSH ROD	TATA spare parts
10424000	OIL TANK & CYL MOUNTING CRADLE ASSY	TATA spare parts
1042615	NUT-CASTLE	TATA spare parts
1042620	NUT CASTLE	TATA spare parts
1043204	COVER-REAR	TATA spare parts
1043215	CASE-SPLITTER UPPER	TATA spare parts
1043383	KEY-SHIFTING	TATA spare parts
1043730	BRACKET-HOSE MTG	TATA spare parts
1043891	POWER SHIFT	TATA spare parts
1044082	GEAR & PINION SET (R7.333)	TATA spare parts
1044085	GEAR SET-REDUCTION (R7.333)	TATA spare parts

1045040	CASE TRANSMISSION	TATA spare parts
1045046	ELBOW	TATA spare parts
1045496	COUNTER SHAFT	TATA spare parts
1045548	SWITCH-INTER LOCK	TATA spare parts
1045549	SWITCH-BACK LAMP	TATA spare parts
1052545	GROMMET-ABS (W/ABS)	TATA spare parts
1052877	HOLDER-SENSOR(W/ABS)	TATA spare parts
1053502	PTO & OIL PUMP ASSY	TATA spare parts
105375	NAME PLATE	TATA spare parts
1056928	HOUSING A-R/A FWD	TATA spare parts
1058023	FINAL DRIVE A-FWD (R7.333)	TATA spare parts
1058024	FINAL DRIVE A-RWD (R7.333)	TATA spare parts
1058042	COBRA BRACKET LH	TATA spare parts
1058046	COBRA BRACKET RH	TATA spare parts
1058240	HOUSING A-R/A FWD	TATA spare parts
1058243	HOUSING A-R/A RWD(ABS)	TATA spare parts
1058330	FINAL DRIVE A-FWD (R6.833)	TATA spare parts
1058333	FINAL DRIVE A-RWD (R6.833)	TATA spare parts
10605000	SUBFRAME ASSY FOR 12 CU M. SCOW	TATA spare parts
1062593	PLATE-REINFORCEMENT	TATA spare parts
107276	SEALANT RTV	TATA spare parts
107981	CAP FILLER	TATA spare parts
108138	GEAR SUPPORT CASE RH	TATA spare parts
108139	DIFF CASE LH NSS	TATA spare parts
108140	DIFF CASE RH NSS	TATA spare parts
108141	SPIDER	TATA spare parts
108142	SIDE PINION	TATA spare parts
108145	SIDE PINION TH WASHR	TATA spare parts
108722	CLIP	TATA spare parts
109895	BRACKET	TATA spare parts
110000100012	PINE CYL. BLOCK 1 INCH. 3	TATA spare parts
1100500030	SPLASH DISC	TATA spare parts
110103012521	DLT TRAILER 12M 13T 3-TML AXLE 4625.S BS	TATA spare parts
110303010587	32FT 3A 13T TRAILER TATA 5525 BS6	TATA spare parts
11030301061	34FT 3A 4FT SWT AIR SUSP TLR BODY BS6	TATA spare parts
110303010630	34FT 4FT 13T 3AXLE TATA TRAILER BS6	TATA spare parts
110303010631	32FT 3A 4FT SW 13T TATA DLT SUSP TLR BOD	TATA spare parts
110303010633	34FT 3A LIFT AXLE 13T TRAILER TATA 5530	TATA spare parts
110303010635	34FT 3A LIFT AXLE 13T TRAILER TATA 5530	TATA spare parts
110303010651	32FT 3A 5FT SW 13T TLR ON SIGNA 5530 BS6	TATA spare parts
110303010652	32FT 3A 4FT 13T TRAILER SIGNA 5530.S BS6	TATA spare parts
110303010717	34FT 3A LIFT AXLE 13T TRAILER TATA 5525	TATA spare parts
1103454008	HEX SCREW	TATA spare parts
110603009144	32 CBM 3A TIP TRAILER BODY BS6	TATA spare parts
11061205189	HEX BOLT M5 X18	TATA spare parts
11061205308	HEX BOLT M5 X 30	TATA spare parts
11061205359	HEX BOLT M5 X35	TATA spare parts

11061296010	HEX BOLT M5X30 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063806350	HEX BOLT M6 X 35	TATA spare parts
11063806406	HEX BOLT M6 X 40	TATA spare parts
11063806457	HEX BOLT M6X45 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063806554	HEX BOLT M6 X 55	TATA spare parts
11063806601	HEX BOLT M6 X 60	TATA spare parts
11063806627	HEX BOLT M6 X 70	TATA spare parts
11063806643	HEX BOLT M6 X 86	TATA spare parts
11063806660	HEX BOLT M6 X 90	TATA spare parts
11063808255	HEX BOLT M8 X 25	TATA spare parts
11063808301	HEX BOLT M8 X 30	TATA spare parts
11063808328	HEX BOLT M8 X 32	TATA spare parts
11063808387	HEX BOLT M8 X 38	TATA spare parts
11063808409	HEX BOLT M8 X 40	TATA spare parts
11063808450	HEX BOLT M8 X 45	TATA spare parts
11063808506	HEX BOLT M8 X 50	TATA spare parts
11063808557	HEX BOLT M8 X 55	TATA spare parts
11063808603	HEX BOLT M8 X 60	TATA spare parts
11063808611	HEX BOLT M8 X 65	TATA spare parts
11063808620	HEX BOLT M8 X 70	TATA spare parts
11063808638	HEX BOLT M8 X 75	TATA spare parts
11063808654	HEX BOLT M8 X 85	TATA spare parts
11063808662	HEX BOLT M8 X 90	TATA spare parts
11063808671	HEX.BOLT M8X95-IS1364-S8.	TATA spare parts
11063808689	HEX BOLT M8 X 100	TATA spare parts
11063808697	HEX BOLT M8 X 110	TATA spare parts
11063808719	HEX BOLT M8X130 IS1364P1-8.8 SS8451-8C	TATA spare parts
11063808735	HEX BOLT M8X150	TATA spare parts
11063810306	HEX BOLT M10 X 33	TATA spare parts
11063810357	HEX BOLT M10 X 35	TATA spare parts
11063810403	HEX BOLT M10 X 40	TATA spare parts
11063810454	HEX BOLT M10 X 45	TATA spare parts
11063810501	HEX BOLT M10 X 50	TATA spare parts
11063810551	HEX BOLT M10 X 55	TATA spare parts
11063810608	HEX BOLT M10 X 60	TATA spare parts
11063810616	HEX BOLT M10 X 65	TATA spare parts
11063810624	HEX BOLT M10 X 70	TATA spare parts
11063810632	HEX BOLT M10 X 75	TATA spare parts
11063810641	HEX BOLT M10 X 80	TATA spare parts
11063810659	HEX BOLT M10 X 5	TATA spare parts
11063810667	HEX BOLT M10 X 90	TATA spare parts
11063810675	HEX BOLT M10 X 95	TATA spare parts
11063810683	HEX BOLT M10 X 100	TATA spare parts
11063810691	HEX BOLT M10 X 110	TATA spare parts
11063810713	HEX BOLT M10 X 130	TATA spare parts
11063810721	HEX BOLT M10 X 140	TATA spare parts
11063810730	HEX BOLT M10 X 150	TATA spare parts

11063810748	HEX BOLT M10X160 IS1364P1-8.8 SS8451-8C	TATA spare parts
11063810756	HEX BOLT M10 X 170	TATA spare parts
11063812406	HEX BOLT M12 X 40	TATA spare parts
11063812457	HEX BOLT M12 X 45	TATA spare parts
11063812503	HEX BOLT M12 X 50	TATA spare parts
11063812554	HEX BOLT M12 X 55	TATA spare parts
11063812619	HEX BOLT M12X65 IS1364P1-8.8-SS9400	TATA spare parts
11063812635	HEX BOLT M12X75	TATA spare parts
11063812651	HEX BOLT M12 X 85	TATA spare parts
11063812660	HEX BOLT M12 X 90	TATA spare parts
11063812678	HEX BOLT M12 X 95	TATA spare parts
11063812686	HEX BOLT M12 X 100	TATA spare parts
11063812694	HEX BOLT M12 X 110	TATA spare parts
11063812716	HEX BOLT M12 X 130	TATA spare parts
11063812724	HEX BOLT M12X140 IS1364P1-8.8 SS8451-8C	TATA spare parts
11063812732	HEX BOLT M12X150 IS1364P1-8.8 SS845	TATA spare parts
11063814409	HEX BOLT M14 X 40	TATA spare parts
11063814557	HEX BOLT M14X55 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063814603	HEX BOLT M14X60	TATA spare parts
11063814638	HEX BOLT M14X75 STRG BOX	TATA spare parts
11063814646	HEX BOLT M14 X 80	TATA spare parts
11063814671	HEX BOLT M14X95 IS1364P1-8.8-SS9400	TATA spare parts
11063816622	HEX BOLT M16 X 70	TATA spare parts
11063816631	HEX BOLT M16 X 75	TATA spare parts
11063816681	HEX BOLT M16X100 IS1364P1-8.8 SS8451-8C	TATA spare parts
11063816711	HEX BOLT M16X130	TATA spare parts
11063816746	HEX BOLT M16 X 160	TATA spare parts
11063820611	BOLT-M20 X 65	TATA spare parts
11063896014	HEX BOLT M10 X 40	TATA spare parts
11063896022	HEX BOLT M10 X 55	TATA spare parts
11063896049	HEX BOLT M8 X 30	TATA spare parts
11063896057	HEX BOLT M10 X 60	TATA spare parts
11063896065	HEX BOLT M12 X 95	TATA spare parts
11063896073	HEX BOLT M16 X 70	TATA spare parts
11063896090	HEX BOLT M8 X 32 8.8	TATA spare parts
11063896103	HEX BOLT M8 X 50	TATA spare parts
11063896111	HEX BOLT M8 X 55	TATA spare parts
11063896120	HEX BOLT M8 X 60	TATA spare parts
11063896146	HEX BOLT M10 X 100	TATA spare parts
11063896154	HEX BOLT M12 X 55	TATA spare parts
11063896162	HEX BOLT M8 X 55	TATA spare parts
11063896171	HEX BOLT M10 X 75	TATA spare parts
11063896189	HEX BOLT M10X80 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063896197	HEX BOLT M10 X 50	TATA spare parts
11063896198	HEX BOLT M10X50 IS1364P1-8.8-SS8451	TATA spare parts
11063896201	HEX BOLT M8 X 110	TATA spare parts
11063896205	HEX BOLT M8X110 IS1364-8.8-SS8451-21	TATA spare parts

11063896219	HEX BOLT M8X100 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063896227	HEX BOLT M12X85 TS17100-8.8 SS8451-8C BS	TATA spare parts
11063896235	HEX BOLT M12X60	TATA spare parts
11063896243	HEX BOLT M6X55 IS1364P1-8.8-SS8451-8C BS	TATA spare parts
11063896251	HEX BOLT M10X85 LPT1615TC	TATA spare parts
11063896260	HEX BOLT M12X90 TS17100-8.8 SS8451-8C	TATA spare parts
11063896278	HEX BOLT M8X105-TS17100-8.8-SS8451-8C	TATA spare parts
11063896294	HEX BOLT M8X65 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063896308	HEX BOLT M8X75 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063896316	HEX BOLT M10X125 IS1364P1-8.8-SS8451S2	TATA spare parts
11063896324	HEX BOLT M12 X 125	TATA spare parts
11063896332	HEX BOLT M12 X 120	TATA spare parts
11063896341	HEX BOLT M10 X 120	TATA spare parts
11063896359	HEX BOLT M6 X 80	TATA spare parts
11063896367	HEX BOLT M10X140-IS1364P1	TATA spare parts
11063896375	HEX BOLT M10X45 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063896383	HEX BOLT M8 X 80-8.8	TATA spare parts
11063896405	BOLT M10X95	TATA spare parts
11063896413	FEX BOLT M12*100	TATA spare parts
11063896421	HEX BOLT M12X65 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063896456	HEX BOLT M6 X 40	TATA spare parts
11063896464	HEX BOLT M12 X 50	TATA spare parts
11063896472	HEX BOLT M10 X 70	TATA spare parts
11063896481	HEX BOLT M16X110 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063896529	HEX BOLT M16X75-IS1364P1-8.8-SS8451-8C	TATA spare parts
11063896600	HEX BOLT M8X75 WH 8.8 TS17140 SS8451-8C	TATA spare parts
11063896618	HEX BOLT M12 X 110	TATA spare parts
11063896651	HEX BOLT M8X90-IS1364P1-8.8-SS8451-8C	TATA spare parts
11063896677	HEX BOLT M10X130 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063896693	HEX BOLT M12X130 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063896707	HEX BOLT M12X70	TATA spare parts
11063896740	HEX BOLT M12*45	TATA spare parts
11063896758	HEX BOLT M8X38	TATA spare parts
11063896766	HEX BOLT M8X35 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063896812	HEX BOLT M10X230 TS17100 8.8 SS8451-8C	TATA spare parts
11063896839	HEX BOLT M6X50 IS1364P1-8.8-SS8451-8C BS	TATA spare parts
11063898025	HEX BOLT M12 X 125	TATA spare parts
11063898050	HEX. BOIT M 6X70	TATA spare parts
11063898068	HEX BOLT M6X35 IS1364P1 8.8 SS8451-8C	TATA spare parts
11063898076	HEX BOLT M8X40 IS1364P1-8.8-SS8451-8C	TATA spare parts
11063898157	HEX BOLT M8X45 IS1364P1-8.8 SS8451-8C	TATA spare parts
11063898165	HEX BOLT M16 X 85	TATA spare parts
11063898624	WATER PUMP BOLT M 10 X 70	TATA spare parts
11063899013	HEX BOLT M10 X 175	TATA spare parts
11063899048	HEX BOLT M8 X 45	TATA spare parts
11063899056	HEX BOLT M8X55-WH-8.8 TS17140 SS8451-8C	TATA spare parts
11063899099	HEX BOLT M8 X 75	TATA spare parts

11063899153	HEX BOLT M10X90 IS1364P1-8.8 SS8451-8C	TATA spare parts
11063899161	HEX BOLT M10 X 110	TATA spare parts
11063899170	HEX BOLT M10 X 65	TATA spare parts
11063899188	HEXBOLTM8X85-WH-8.8TS17140SS8451-8C BS6	TATA spare parts
11063899331	HEX BOLT M10X60 WH 8.8 TS17140 SS8451-8C	TATA spare parts
11063910459	HEX BOLT M10X1.25X45IS13726 8.8SS8451-8C	TATA spare parts
11063910653	HEX BOLT M10X1.25X85IS13726 8.8SS8451-8C	TATA spare parts
11063914403	HEX BOLT M14 X 1.5 X 40	TATA spare parts
11063914454	HEX BOLT M14 X 1.5 X 45	TATA spare parts
11063914624	HEX BOLT M14 X 1.5 X 70	TATA spare parts
11063914632	HEX BOLT M14 X 1.5 X 75	TATA spare parts
11063914641	HEX BOLT M14 X 1.5 X 80	TATA spare parts
11063914691	H/BOLT M14X1.5X110 IS13726 8.8SS8451-8C	TATA spare parts
11063916457	HEX BOLT M16X1.5X45 TS171008.8SS8451-8C	TATA spare parts
11063916554	HEX BOLT M16X1.5X55-IS13726-8.8SS8451-8C	TATA spare parts
11063916601	HEX BOLT M16 X 1.5 X 60	TATA spare parts
11063916627	HEX BOLT M16X1.5 X 70	TATA spare parts
11063916678	HEX BOLT M16 X 1.5 X 95	TATA spare parts
11063916686	HEX BOLT M16 X 1.5 X 100	TATA spare parts
11063916694	HEX BOLT M16X1.5X110IS13726 8.8SS8451-8C	TATA spare parts
11063916708	HEX BOLT M16 X 1.5 X 120	TATA spare parts
11063916724	HEX BOLT	TATA spare parts
11063918662	HEX BOLT M18X1 5X90 IS:13726 8 8	TATA spare parts
11063996019	HEX BOLT M14 X 1.5 X 45	TATA spare parts
11063996027	HEX BOLT M12 X 1.5 X 45	TATA spare parts
11063996035	HEX BOLT M12 X 1.5 X 55	TATA spare parts
11063996043	HEX BOLT M16X1.5X60	TATA spare parts
11063996060	HEX BOLT M14 X 1.5 X 70	TATA spare parts
11063996078	HEXBOLT M16X1.5X50IS13726 -8.8 SS8451-8C	TATA spare parts
11063996086	HEX BOLT M16 X 1.5 X 90	TATA spare parts
11063996094	HEX BOLT M16 X 1.5 X 80	TATA spare parts
11063996108	HEX BOLT M14X1.5X80 IS13726-8.8SS8451-8C	TATA spare parts
11063996116	HEX BOLT M16X1.5X85	TATA spare parts
11063996124	HEX BOLT M16 X 1.5 X 105	TATA spare parts
11063996167	HEX BOLT M16X1.5X125	TATA spare parts
11063996175	HEX BOLT M14 X 1.5 X 55	TATA spare parts
11063996191	HEXBOLT M20X1.5X140IS13726 -8.8SS8451-8C	TATA spare parts
11063996205	BOLT M20 X 90	TATA spare parts
11063996213	HEXBOLT M14X1.5X75	TATA spare parts
11063996230	HEX BOLT M16X1.5X120 IS13726-8.8-SS9400	TATA spare parts
11063996256	HEX. BOLT M14X1.5X100	TATA spare parts
11063996299	HEX BOLT M 20X1.5X130	TATA spare parts
11063996302	HEXBOLT M14X1.5X 95 IS13726 8.8SS8451-8C	TATA spare parts
11063996329	H/BOLT M12X1.5X160 IS13726 8.8 SS8451-8C	TATA spare parts
11063998038	HEX BOLT M16 X 1.5 X 125	TATA spare parts
11063998046	HEXBOLT M14X1.5X125	TATA spare parts
11063998062	HEX BOLT M12 X 1.5 X 70	TATA spare parts

11063998089	HEX BOLT M16X1.5X65	TATA spare parts
11063998097	HEX BOLT M20X1.5X145TS17100 8.8SS8451-8C	TATA spare parts
11063999042	HEX BOLT M12 X 1.5 X 40	TATA spare parts
11063999051	HEX BOLT M12 X 1.5 X 45	TATA spare parts
11063999069	HEX BOLT M12X1.5X50 IS13726-8.8SS8451-8C	TATA spare parts
11063999077	HEX BOLT M12 X 1.5 X 55	TATA spare parts
11063999085	HEX BOLT M12 X 1.5 X 85	TATA spare parts
11063999093	HEX BOLT M12 X 1.5 X 95	TATA spare parts
11063999140	HEX BOLT	TATA spare parts
11063999158	HEX BOLT M10 X 1 X 45	TATA spare parts
11063999174	HEX BOLT M10 X 1 X 48	TATA spare parts
11063999182	HEX BOLT M10 X 1 X 50	TATA spare parts
11063999221	HEX BOLT M12X1.5X65	TATA spare parts
11063999239	HEX BOLT M12 X 1.5 X 70	TATA spare parts
11063999271	HEX BOLT	TATA spare parts
11063999298	BOLT M14X1.5X130 PH 8.8 TS17140SS8451-8C	TATA spare parts
11064006306	HEX BOLT M6 X 30	TATA spare parts
11064008309	HEX BOLT M8 X 30	TATA spare parts
11064008350	HEX BOLT M8 X 35	TATA spare parts
11064008384	HEX BOLT M8 X 38	TATA spare parts
11064008406	HEX BOLT M8 X 40	TATA spare parts
11064008457	HEX BOLT M8 X 45	TATA spare parts
11064008503	HEX BOLT M8 X 50	TATA spare parts
11064008554	HEX BOLT M8X55 IS1364P1-10.9 SS9400	TATA spare parts
11064008601	HEX BOLT M8X60	TATA spare parts
11064008627	HEX BOLT M8X70 IS1364P1-10.9-SS9400	TATA spare parts
11064008635	HEX BOLT M8 X 75	TATA spare parts
11064008643	HEX BOLT M8X80 IS1364P1-10.9 SS8451-8CH	TATA spare parts
11064008651	HEX BOLT M8X85 IS1364P1-10.9 SS9400	TATA spare parts
11064008660	HEX BOLT M8X90	TATA spare parts
11064008678	HEX BOLT M8 X 95	TATA spare parts
11064008694	HEX BOLT M8X110	TATA spare parts
11064010401	BOLT M10X40 HEX HEAD	TATA spare parts
11064010451	HEX BOLT M10 X 45	TATA spare parts
11064010508	HEX BOLT M10 X 50	TATA spare parts
11064010559	HEX BOLT M10 X 55	TATA spare parts
11064010605	HEX BOLT M10X60 IS1364P1-10.9 SS9400	TATA spare parts
11064010648	HEX BOLT M10 X 80	TATA spare parts
11064010664	HEX BOLT M10 X 90	TATA spare parts
11064010672	HEX BOLT M10X95	TATA spare parts
11064010681	HEX BOLT M10X100 IS1364P1-10.9 SS9400	TATA spare parts
11064010699	HEX BOLT M10 X 110	TATA spare parts
11064010702	HEX BOLT M10X120 IS1364P1-10.9SS8451-8CH	TATA spare parts
11064012250	HEX BOLT M12X50 TS17100-10.9-SS9400	TATA spare parts
11064012403	HEX BOLT M12X40	TATA spare parts
11064012454	HEX BOLT M12X45 IS1364P110.9SS8451-8CH	TATA spare parts
11064012501	HEX BOLT M12 X 50	TATA spare parts



11064012551	HEX BOLT M12X55	TATA spare parts
11064012608	HEX BOLT M12X60 IS1364P1 10.9 SS8451-8CH	TATA spare parts
11064012616	HEX BOLT M12 X 65	TATA spare parts
11064012632	HEX BOLT M12 X 75	TATA spare parts
11064012659	HEX BOLT M12 X 85	TATA spare parts
11064012667	HEX BOLT M12X90 TS17100 10.9 BS6-PH2	TATA spare parts
11064012691	HEX BOLT M12X110 IS1364P1-10.9SS8451-8CH	TATA spare parts
11064012713	HEX BOLT M12X130 IS1364P1 109 SS9400	TATA spare parts
11064012756	HEX BOLT M12X75 TS17100 10.9 SS8451-8CH	TATA spare parts
11064014619	HEX BOLT M14 X 65	TATA spare parts
11064014643	HEX BOLT M14 X 80	TATA spare parts
11064016450	HEX BOLT M16X45	TATA spare parts
11064016611	HEX BOLT M16X65 (CLUTCH HOUSING TO GEAR	TATA spare parts
11064016620	HEX BOLT M16X70 TS17100-10.9-SS9400	TATA spare parts
11064016654	HEX BOLT M16 X 85	TATA spare parts
11064016697	HEX BOLT M16X110 IS1364P1-8.8	TATA spare parts
11064096003	HEX BOLT M10X105 TS17100 10.9SS8451-8CH	TATA spare parts
11064096011	HEX BOLT M8 X 35	TATA spare parts
11064096020	HEX BOLT M8X40 IS1364P1-10.9-SS8451-8CH	TATA spare parts
11064096038	HEX BOLT M8X45	TATA spare parts
11064096046	HEX BOLT M 10 X 45 10.9	TATA spare parts
11064096054	HEX BOLT M12 X 50	TATA spare parts
11064096062	HEX BOLT M8 X 105	TATA spare parts
11064096089	HEX BOLT M8 X 125	TATA spare parts
11064096097	HEX BOLT M8 X 110	TATA spare parts
11064096101	HEX BOLT M8X38	TATA spare parts
11064096135	HEX BOLT M10X50 IS1364P1-10.9-SS8451-8CH	TATA spare parts
11064096143	HEXBOLTM6X50IS1364P110.9SS9400	TATA spare parts
11064096151	HEX BOLT M12 X 80	TATA spare parts
11064096160	HEX BOLT	TATA spare parts
11064096178	HEX BOLT M10X35	TATA spare parts
11064096186	HEX BOLT M10X75 IS1364P1-10.9-SS8451-8CH	TATA spare parts
11064096194	HEX BOLT M10 X 70	TATA spare parts
11064096224	HEX BOLT M8X55 IS1364P1 10.9 SS8451-8CH	TATA spare parts
11064096259	HEX BOLT M16X120 IS1364P1-10 9-SS9400	TATA spare parts
11064097069	HEX BOLT M10X60 IS1364P1 10.9 SS8451-8CH	TATA spare parts
11064097093	HEX BOLT M10X80	TATA spare parts
11064098014	HEX BOLT M10X105IS1364P1-10.9SS9400	TATA spare parts
11064098022	HEX BOLT M8 X 125	TATA spare parts
11064098081	HEX BOLT M10X85 IS1364P1 10.9 SS8451-8CH	TATA spare parts
11064098111	HEX BOLT M10X140 IS1364P1 10.9SS8451-8CH	TATA spare parts
11064098111_NIU	HEX BOLT M10X140 IS1364P1 10.9SS8451-8CH	TATA spare parts
11064098120	HEX BOLT M10X160 IS1364P1 10.9SS8451-8CH	TATA spare parts
11064099029	HEX BOLT M8 X 105	TATA spare parts
11064110626	H/BOLT M10X1.25X70IS13726 10.9SS8451-8CH	TATA spare parts
11064114451	HEX BOLT M14 X 1.5 X 45	TATA spare parts
11064114508	HEX BOLT M14X1.5X50 IS13726-10.9 SS9400	TATA spare parts

11064114559	HEX BOLT M14 X 1.5 X 55	TATA spare parts
11064114613	HEX BOLT M14X1.5X65 IS13726-10.9 SS9400	TATA spare parts
11064114621	HEX BOLT M14 X 1.5 X 70	TATA spare parts
11064114648	HEX BOLT M14X1.5X80 TS17100 BS6-PH2	TATA spare parts
11064114702	SCREW	TATA spare parts
11064116501	HEX BOLT M16X1.5X50	TATA spare parts
11064116616	H/BOLT M16X1.5X65 TS17100-10.9SS8451-8CH	TATA spare parts
11064116641	HEX BOLT M16X1.5X80IS13726 10.9SS8451-8C	TATA spare parts
11064118554	HEX BOLT M18X1.5X55-IS13726-10.9-SS9400	TATA spare parts
11064118619	HEX BOLT M18X1.5X65-IS13726-10.9-SS9400	TATA spare parts
11064118694	HEX BOLT M18X1.5X110 IS13726-10.9-SS9400	TATA spare parts
11064120613	HEX BOLT M20X1.5X45 IS13726-10.9 SS-8451	TATA spare parts
11064120656	HEXBOLT M20X1.5X85IS13726 10.9SS8451-8CH	TATA spare parts
11064120711	HEXBOLTM20X1.5X130IS13726-10.9-SS9400 BS	TATA spare parts
11064124724	HEX BOLT M24X2X140 IS13726-10.9-SS9400 B	TATA spare parts
11064196032	HEX BOLT	TATA spare parts
11064196041	HXBOLT M12X1.5X40 IS13726-10.9SS8451-8C	TATA spare parts
11064196059	HEX BOLT 14X1.5X70	TATA spare parts
11064196067	HEXBOLT M12X1.5X45 IS13727	TATA spare parts
11064196105	HEXBOLT M10X1X40 IS13726-10.9-SS8451-8CH	TATA spare parts
11064196113	HEX BOLT M14X1.5X85	TATA spare parts
11064196156	H/BOLT M12X1.5X55 IS13726 10.9SS8451-8CH	TATA spare parts
11064196172	H/BOLT M10X65 TS17100-10.9 SS8451-8CH BS	TATA spare parts
11064198019	HEX BOLT M12X1.5X65	TATA spare parts
11064198027	BOLT M12X15X35 IS13726 109 SS8451S	TATA spare parts
11064198043	HEX BOLT M12X1.5X75 IS:1364 10.9-SS9400	TATA spare parts
11064198060	HEX BOLT M12 X 1.5 X 80	TATA spare parts
11064198078	HEX BOLT M18X1.5X155 TS17100-10.9 SS9400	TATA spare parts
11064198124	HX BOLT M18X1.5X90	TATA spare parts
11064198132	H/BOLT M18X1.5X70	TATA spare parts
11064199015	HEX BOLT M12 X 1.5 X 50	TATA spare parts
11064199023	HEX BOLT M12X1.5X60 IS13726-10.9	TATA spare parts
11064199031	HEX BOLT M12 X 1.5 X 50	TATA spare parts
11064199058	HEX BOLT M12 X 1.5 X 40	TATA spare parts
11064199074	HEX BOLT M12 X 1.5 X 45	TATA spare parts
11064199112	HEX BOLT M12 X 1.5 X 52	TATA spare parts
11064199147	HEX BOLT M12 X 1.5 X 62	TATA spare parts
11064210558	HEX BOLT M10X55	TATA spare parts
11064212631	HEX BOLT M12X75 TS17100 12.9 SS9400 BS6	TATA spare parts
11064296011	HEX BOLT M6X20 IS1364P1 12.9 SS8451-8CH	TATA spare parts
11064298013	HEX FL BOLT M8X25JISB1189 TP2 12.9SS9400	TATA spare parts
11064398018	HEX BOLT M12X1.5X45 TS17100 12.9 SS9400	TATA spare parts
11064398026	HEX.BOLT M12X1.5.X50 BS6-PH2	TATA spare parts
11065508682	HEX BOLT M8 X 100	TATA spare parts
11065508691	HEX BOLT M8 X 110	TATA spare parts
11066806407	HEX BOLT M6X40 IS1364P1-8.8-Y BS6-PH2	TATA spare parts
11066808302	HEX BOLT M8X30 IS1364P1-8.8 SS8451S2-Y	TATA spare parts

11066808400	HEX BOLT M8X40 IS1364P1-8.8-SS8451S2-Y	TATA spare parts
11066808558	HEX BOLT M8X55 IS1364P1-8.8 SS8451S2-Y	TATA spare parts
11066808604	HEX BOLT M8X60 IS1364P1-8.8-SS8451S2-Y	TATA spare parts
11066808621	HEX BOLT M8X70 IS1364P1-8.8-SS8451S2	TATA spare parts
11066808639	HEX BOLT M8X75 IS1364P1-8.8-SS8451S2-Y	TATA spare parts
11066808663	HEX BOLT M8X100 TS17100-8.8-SS8451S2-Y B	TATA spare parts
11066810161	HEX BOLT M10X160 TS17100-8.8 SS8451S2-Y	TATA spare parts
11066810307	HEXBOLTM10X30TS17100-8.8-SS8451S2-Y BS6	TATA spare parts
11066810552	HEX BOLT M10X55 IS1364P1-8.8-SS8451S2-Y	TATA spare parts
11066810617	HEX BOLT M10X65 IS1364P1-8.8 SS8451S2-Y	TATA spare parts
11066810617_niu1	HEX BOLT M10X65 IS1364P1-8.8 SS8451S2-Y	TATA spare parts
11066810625	HEX BOLT M10X70 IS1364P1-8.8-SS8451S2-Y	TATA spare parts
11066810633	HEX BOLT M10X75 TS17100-8.8-SS8451S2-Y B	TATA spare parts
11066810676	HEX BOLT M10X110 IS1364P1-8.8-SS8451S2-Y	TATA spare parts
11066810706	HEX BOLT M10X130 IS1364P1-8.8-SS8451S2-Y	TATA spare parts
11066812458	HEX BOLT M12X45 TS17100-8.8-SS8451S2-Y	TATA spare parts
11066812555	HEX BOLT M12X55 IS1364P1-8.8 SS8451S2-Y	TATA spare parts
11066812695	HEX BOLT M12X125 IS1364P1-8.8-SS8451S2-Y	TATA spare parts
11066812709	HEX BOLT M12X130 IS1364P1-8.8-SS8451S2-Y	TATA spare parts
11066896015	HEX BOLT M12X95 IS1364P1-8.8 SS8451S2-Y	TATA spare parts
11066896031	HEX BOLT M12X115 TS17100 8.8 SS8451S2-Y	TATA spare parts
11066896040	HEX BOLT M10X95 TS17100 8.8 SS8451S2-Y	TATA spare parts
11066914625	HEX BOLT M14X1_5X70 TS17100_8_8SS8451S2_	TATA spare parts
11066914650	H/BOLT M14X1.5X90 IS13726-8.8SS8451S2-Y	TATA spare parts
11066914668	HEXBOLT M14X1.5X100	TATA spare parts
11066916661	H/BOLT M16X1.5X100 IS13726-8.8SS8451S2-Y	TATA spare parts
11066916679	H/BOLT M16X1.5X110TS17100 8.8SS8451S2-Y	TATA spare parts
11066996087	H/BOLT M10X1.25X95 IS13726 8.8SS8451S2	TATA spare parts
11067008351	HEX BOLT M8X35 IS1364P1-10.9-SS8451S2-Y	TATA spare parts
11067008458	HEX. BOLT M 8X45	TATA spare parts
11067010401	HEXFL BOLT M10X40 TS17130-8.8-SS8451S2-Y	TATA spare parts
11067010452	HEX BOLT M10X45 IS1364P1-10.9-SS8451S2-Y	TATA spare parts
11067010614	HEX BOLT M10X65 IS1364P1 10.9SS8451S2	TATA spare parts
11067010673	HEX BOLT M10X110 TS17100-10.9SS8451S2-YH	TATA spare parts
11067010681	HEX BOLT M10X120TS17100-10.9SS8451S2-YH	TATA spare parts
11067012641	HEX BOLT M12X80 IS1364P1-10.9-SS8451S2-H	TATA spare parts
11067012684	HEX BOLT M12X120IS1364P1 10.9SS8451S2-Y	TATA spare parts
11067020008	BOLT M20X1.5X125TS17100-10.9SS8451S2-YH	TATA spare parts
11067020733	BOLT M20X1.5X150TS17100-10.9SS8451S2-YH	TATA spare parts
11067110406	H/BOLT M10X1X40 IS13726-10.9-SS8451S2-YH	TATA spare parts
11067110660	BOLT M10X1.25X100TS17100 10.9SS8451S2-YH	TATA spare parts
11067112352	BOLT M12X1.5X35 IS13726 10.9 SS8451S2-YH	TATA spare parts
11067112450	H/BOLT M12X1.5X45IS13726-10.9SS8451S2-YH	TATA spare parts
11067112557	H/BOLT M12X1.5X55TS17100 10.9SS8451S2-YH	TATA spare parts
11067112620	H/BOLT M12X1.5X70IS13726 10.9SS8451S2	TATA spare parts
11067114550	H/B M14X1.5X55 TS17100 10.9 SS8451S2-YH	TATA spare parts
11067116668	BOLTM16X1.5X100 TS17100 10.9 SS8451S2-YH	TATA spare parts

11067196017	BOLT M14X1.5X50IS13726 10.9SS8457S1-BL-B	TATA spare parts
11067196033	BOLT M14X1.5X70TS17100 10.9SS8457S1-BL-B	TATA spare parts
11067196041	BOLT M10X1X40 TS17100 10.9SS8457S1-BL-B	TATA spare parts
11067296020	HX BOLT M10X45TS17100 10.9SS8457S1-BL-B	TATA spare parts
11067296046	HX BOLT M10X50IS1364P1 10.9SS8457S1-BL-B	TATA spare parts
11067296062	H/BOLT M10X40 TS17100 10.9SS8457S1-BL-B	TATA spare parts
11067296071	H/BOLT M8X40 TS17100 10.9 SS8457S1-BL-B	TATA spare parts
11067396032	BOLT M20X1.5X90 TS17100 8.8SS8457S1-BL-B	TATA spare parts
11067396041	BOLT M20X1.5X130TS17100 8.8SS8457S1-BL-B	TATA spare parts
11067408324	HEX BOLT M8X32 TS17100-8.8SS8457S1-S-B	TATA spare parts
11067496134	H/BOLT M8X70 TS17100-8.8SS8457S1-BL-B	TATA spare parts
11067496142	H/BOLT M10X50 TS17100-8.8-SS8457S1-BL-B	TATA spare parts
11067496231	HEX BOLT M8X60 IS1364P1 8.8SS8457S1-BL-B	TATA spare parts
11067496363	H/BOLT M8X55 TS17100 8.8 SS8457S1-BL-B B	TATA spare parts
11067496380	HEX BOLT M8X45 TS17100 8.8SS8457S BS6-PH	TATA spare parts
11067496398	H/BOLT M10X140 IS1364P1 8.8SS8457S1-BL-B	TATA spare parts
11067496401	HEX BOLT M8X65 IS1364P1 8.8SS8457S1-BL-B	TATA spare parts
11067496436	BOLT M10X110 TS17100 8.8SS8457S1-BL-B BS	TATA spare parts
11067520744	BOLT M20X1.5X160TS17100 BS6-PH2	TATA spare parts
11067596082	BOLT M10X1.25X70TS17100 8.8SS8457S1-BL-B	TATA spare parts
11067596155	BOLT M16X1.5X65 TS17100 8.8SS8457S1-BL-B	TATA spare parts
11067608358	HEX BOLT M8X35 IS1364P1 10.9SS8457S1-S-B	TATA spare parts
11067696061	H/BOLT M12X55 TS17100 10.9SS8457S1-BL-B	TATA spare parts
11067796006	BOLT M14X1.5X45TS17100 -BL-B BS6-PH2	TATA spare parts
11067796065	BOLT M12X1.5X45TS17100 10.9SS8457S1-BL-B	TATA spare parts
11067796081	BOLT M12X1.5X40TS17100 10.9SS8457S1-BL-B	TATA spare parts
11069405047	HEX BOLT M8 X 85	TATA spare parts
11069842854	HEX BOLT 5/16UNCX1 IN BS1768	TATA spare parts
11071505105	HEX FL BOLT M5X10 TS17130-8.8-SS8451-8C	TATA spare parts
11071505300	HEX FL BOLT M5X30 TS17130 8.8 SS8451-8C	TATA spare parts
11071506209	HEX FL BOLT M6 X 20	TATA spare parts
11071506225	HEX FL BOLT M6 X 22	TATA spare parts
11071506250	HEX FL BOLT M6X25 TS17130-8.8-SS8451S2-Y	TATA spare parts
11071506306	HEX FL BOLT M6X30 TS17130-8.8-SS8451-8C	TATA spare parts
11071506357	HEX FL BOLT M6X35 TS17130-8.8-SS8451S2	TATA spare parts
11071506403	HEX FL BOLT M6X40 TS17130-8.8 SS8451S2-Y	TATA spare parts
11071506454	HEX FL BOLT M6X45 TS17130 8.8 SS8451-8C	TATA spare parts
11071506501	HEX FL BOLT M6X50 TS17130 8.8 SS8451-8C	TATA spare parts
11071506551	HEX FL BOLT M6X55 TS17130 8.8 SS8451S2-Y	TATA spare parts
11071506608	HEX FL BOLT M6X60 TS17130 8.8 SS8451-8C	TATA spare parts
11071506705	HEX FL BOLT M6X70 TS17130 8.8 SS8451S2-Y	TATA spare parts
11071508228	HEX FL BOLT M8X22 TS17130-8.8-SS8451S2-Y	TATA spare parts
11071508252	HEX FL BOLT M8X25 TS17130-8.8-SS8451S2-Y	TATA spare parts
11071508252AE	ASSY HVAC WITH MTG BRACKET 1828	TATA spare parts
11071508287	HEX FL BOLT M8X28	TATA spare parts
11071508309	HEX FL BOLT M8X30 TS17130 8.8 SS8451-8C	TATA spare parts
11071508350	HEX FL BOLT M8X35 TS17130 8.8 SS8451-8C	TATA spare parts

11071508384	HEX FL BOLT M8X38 TS17130-8.8-SS8451S2-Y	TATA spare parts
11071508406	HEX FL BOLT M8X40	TATA spare parts
11071508457	HEX FL BOLT M8X45 TS17130-8.8-SS8451-8C	TATA spare parts
11071508503	HEX FL BOLT M8X50 TS17130-8.8-SS8451S2	TATA spare parts
11071508554	HEX FL BOLT M8X55 TS17130 8.8 SS8451-8C	TATA spare parts
11071508651	HEX FL BOLT M8X65 TS17130 8.8 SS8451-8C	TATA spare parts
11071508708	HEX FL BOLT M8X70 TS17130-8 8 SS8451-8C	TATA spare parts
11071508759	HEX FL BOLT M8X75 TS17130-8.8 SS8451-8C	TATA spare parts
11071508805	HEX FL BOLT M8X80	TATA spare parts
11071508902	HEX FL BOLT M8X90 TS17130 8.8 SS8451-8C	TATA spare parts
11071508911	H/FL BOLT M8X95TS17130-10.9SS8451S2-YH	TATA spare parts
11071508929	HEX FL BOLT M8X100 TS17130-8.8-SS8451-8C	TATA spare parts
11071508937	HEX FL BOLT M8X110 TS17130-8.8-SS8451-8C	TATA spare parts
11071508945	HEX FL BOLT M 8X120	TATA spare parts
11071510303	HEXFL BOLT M10X30 TS17130-8.8-SS8451S2-Y	TATA spare parts
11071510303_niu1	HEXFL BOLT M10X30 TS17130-8.8-SS8451S2-Y	TATA spare parts
11071510354	HEXFL BOLT M10X35 TS17130	TATA spare parts
11071510401	HEXFL BOLT M10X40 TS17130-8.8-SS8451S2	TATA spare parts
11071510451	HEX FL BOLT M10X45 TS17130-8.8-SS8451-8C	TATA spare parts
11071510508	HEX FL BOLT M 10X50	TATA spare parts
11071510559	HEXFL BOLT M10X55 TS17130-8.8-SS8451S2-Y	TATA spare parts
11071510605	HEX FL BOLT M10X60 TS17130-8.8-SS8451-8C	TATA spare parts
11071510656	HEX FL BOLT M10 X 65	TATA spare parts
11071510702	HEX FL BOLT M10X70 TS17130-8.8-SS8451-8C	TATA spare parts
11071510753	HEXFL BOLT M10X75 TS17130-8.8-SS8451S2-Y	TATA spare parts
11071510851	HEX FL BOLT M10X85 TS17130 8.8 SS8451-8C	TATA spare parts
11071510907	HEX FL BOLT M10X90 TS17130-8.8-SS8451-8C	TATA spare parts
11071510915	HEXFL BOLT M10X95 TS17130-8.8-SS8451S2-Y	TATA spare parts
11071510923	H/FL BOLT M10X100 TS17130-8.8-SS8451S2-	TATA spare parts
11071510931	HEX FL BOLT M10X110 TS17130 8.8SS8451-8C	TATA spare parts
11071512357	HEX FL BOLT M12X35 TS17130 8.8 SS8451-8C	TATA spare parts
11071512403	HEX FL BOLT M12X40 TS17130-8.8 SS8451-8C	TATA spare parts
11071512454	HEX FL BOLT M12X45(STARTER MTR FITMENT O	TATA spare parts
11071512501	HEX FL BOLT M12X50 TS17130 8.8 SS8451-8C	TATA spare parts
11071512608	HEX FL BOLT M12X60 TS17130 8.8 SS8451-8C	TATA spare parts
11071512756	HEX FL BOLT M12X75 TS17130 8.8 SS8451-8C	TATA spare parts
11071512926	HEX FL BOLT M12X100 TS17130 8.8SS8451-8C	TATA spare parts
11071512951	HEX FL BOLT M12X130 TS17130 8.8 SS8451-8	TATA spare parts
11071512969	HEX FL BOLT M12X140 TS17130-8.8SS8451-8C	TATA spare parts
11071514406	HEX FL BOLT M14X40 TS17130 8.8 SS8451-8C	TATA spare parts
11071514457	HEX FL BOLT M14X45 TS17130 8.8 SS8451-8C	TATA spare parts
11071514503	HEX FL BOLT M14X50 TS17130 8.8 SS8451-8C	TATA spare parts
11071514805	HEX FL BOLT M14X80 TS17130 8.8 SS8451-8C	TATA spare parts
11071598014	H/FL BOLT M8X125	TATA spare parts
11071598073	H/FL BOLT M8X135 TS17130-8.8-SS8451S2-Y	TATA spare parts
11071599011	HEX FL BOLT M10X125 TS17130 8.8SS8451-8C	TATA spare parts
11071610600	FL BOLT M10X1.25X60TS17130-8.8-SS8451-8C	TATA spare parts

11071612351	FL BOLT M12X1.5X35 TS17130 8.8 SS8451-8C	TATA spare parts
11071612408	FL BOLT M12X1.5X40	TATA spare parts
11071612858	FL BOLT M12X1.5X85	TATA spare parts
11071612947	FL BOLT M12X1.5X130 TS17130 8.8S	TATA spare parts
11071614354	FL BOLT M14X1.5X35 TS17130 8.8 SS8451-8C	TATA spare parts
11071614401	FL BOLT M14X1.5X40 TS17130 8.8 SS8451-8C	TATA spare parts
11071614451	FL BOLT M14X1.5X45	TATA spare parts
11071614508	FL BOLT M14X1.5X50 TS17130 8.8 SS8451-8C	TATA spare parts
11071614559	FL BOLT M14X1.5X55 TS17130	TATA spare parts
11071614605	FL BOLT M14X1.5X60	TATA spare parts
11071614851	FL BOLT M14X1.5X85	TATA spare parts
11071614915	FL BOLT M14X1.5X100	TATA spare parts
11071614966	FL BOLT M14X1.5X150	TATA spare parts
11071616501	FL BOLT M16X1.5X50 TS17130 8.8 SS8451-8C	TATA spare parts
11071696016	FL BOLT M14X1.5X105 TS17130 8.8SS8451-8C	TATA spare parts
11071696024	FL BOLT M14X1.5X115 BS6-PH2	TATA spare parts
11071708251	HEX FL BOLT M8X25 TS17130 10.9SS8451-8CH	TATA spare parts
11071708359	HEX FL BOLT M8X35 TS17130 10.9SS8451-8CH	TATA spare parts
11071708405	HEX FL BOLT M8X40	TATA spare parts
11071708502	H/FL BOLT M8X50 TS17130-10.9-SS8451S2-YH	TATA spare parts
11071708553	H/FL BOLT M8X55 TS17130-10.9-SS8451S2-YH	TATA spare parts
11071708600	HEX FL BOLT M8X60 TS17130 10.9SS8451-8CH	TATA spare parts
11071708707	H/FL BOLT M8X70 TS17130-10.9-SS8451S2-YH	TATA spare parts
11071708758	HEX FL BOLT M8X75 TS17130 10.9SS8451-8CH	TATA spare parts
11071708804	HEX FL BOLT M8X80 TS17130 10.9SS8451-8CH	TATA spare parts
11071708901	HEX FL BOLT M8X90 TS17130 10.9SS8451-8CH	TATA spare parts
11071708936	FL BOLT M8X120 TS17130 10.9 SS8451-8CH	TATA spare parts
11071710302	HEX FL BOLT M10X30TS17130 10.9SS8451-8CH	TATA spare parts
11071710353	HEX FL BOLT M10X35TS17130 10.9SS8451-8CH	TATA spare parts
11071710400	H/FL BOLT M10X40 TS17130-10.9SS8451S2-Y	TATA spare parts
11071710451	HEX FL BOLT M10X45TS17130-10.9SS8451-8CH	TATA spare parts
11071710507	HEX FL BOLT M10X50TS17130-10.9SS8451-8CH	TATA spare parts
11071710558	HEX FL BOLT M10X55TS17130 10.9SS8451-8CH	TATA spare parts
11071710582	HEX FL BOLT M10X58	TATA spare parts
11071710639	BOLT FLANGED M10 X 63	TATA spare parts
11071710655	H/FL BOLT M10X65 TS17130-10.9SS8451S2-Y	TATA spare parts
11071710701	HEX FL BOLT M10X70TS17130 10.9SS8451-8CH	TATA spare parts
11071710752	FL BOLT M10X75 TS17130 10.9 SS8451-8CH	TATA spare parts
11071710914	HX FL BOLT M10X100	TATA spare parts
11071710957	FL BOLT M10X130	TATA spare parts
11071710965	.H/FL BOLT M10X95 TS17130-10.9SS8451S2-Y	TATA spare parts
11071712500	HEX FL BOLT M12X50TS17130 10.9SS8451-8CH	TATA spare parts
11071712551	HEX FL BOLT M12X55	TATA spare parts
11071712704	HEX FL BOLT M12X70TS17130 10.9SS8451-8CH	TATA spare parts
11071712852	H/FL BOLT M12X85 TS17130 10.9 SS8451-8CH	TATA spare parts
11071712909	H/FL BOLT M12X90 TS17130 10.9 SS8451-8CH	TATA spare parts
11071798021	HEX.FL BOLT M8X48 TS17130 10.9SS8451-8CH	TATA spare parts

11071798030	HEX FL BOLT M8X105TS17130-10.9SS8451-8CH	TATA spare parts
11071808451	HEX FL BOLT M8X1X45TS17130 10.9SS8451-8C	TATA spare parts
11071810358	FLBOLT M10X1.25X35TS17130 10.9SS8451-8CH	TATA spare parts
11071810455	FLBOLT M10X1.25X45	TATA spare parts
11071810552	FLBOLT M10X1.25X55TS17130 10.9SS8451-8CH	TATA spare parts
11071810609	FL BOLT M10X1.25X60	TATA spare parts
11071812458	FL BOLT M12X1.5X45TS17130	TATA spare parts
11071812709	FL BOLT M12X1.5X70	TATA spare parts
11071812806	FL BOLT M12X1.5X80TS17130 10.9SS8451-8CH	TATA spare parts
11071812857	FL BOLT M12X1.5X85TS17130 10.9SS8451-8CH	TATA spare parts
11071812903	FL BOLT M12X1.5X90TS17130-10.9SS8451-8CH	TATA spare parts
11071812954	FLBOLT M12X1.5X140TS17130 10.9SS8451-8CH	TATA spare parts
11071814400	FL BOLT M14X1.5X40	TATA spare parts
11071814451	HEX FL BOLT M14X1.5X45	TATA spare parts
11071814507	FL BOLT M14X1.5X50TS17130 10.9SS8451-8CH	TATA spare parts
11071814701	FL.BLT M14 X 1.5 X 70	TATA spare parts
11071814809	FL.BOLT M14X1.5X80 TS17130-8.8-SS8451-8C	TATA spare parts
11071814850	FL.BOLT M14X1.5X85TS17130 10.9SS8451-8CH	TATA spare parts
11071814906	FL BOLT M14X1.5X90TS17130 10.9SS8451-8CH	TATA spare parts
11071814949	FLBOLT M14X1.5X130TS17130 10.9SS8451-8CH	TATA spare parts
11071816551	FL BOLT M16X1.5X55TS17130 10.9SS8451-8CH	TATA spare parts
11071816607	FL BOLT M16X1.5X60TS17130 10.9SS8451-8CH	TATA spare parts
11071816968	FLBOLT M16X1.5X150TS17130 10.9SS8451-8CH	TATA spare parts
11071898034	FLBOLT M12X1.25X80	TATA spare parts
11071898042	FLBOLT M12X1.25X60TS17130 10.9SS8451-8CH	TATA spare parts
11071898069	FL BOLT M14X1.5X95	TATA spare parts
11071898077	FL BOLT M12X1.5X95TS17130 10.9SS8451-8CH	TATA spare parts
11071898093	FLBOLT M12X1.5X105TS17130 10.9SS8451-8CH	TATA spare parts
11071910557	HEX FL BOLT M10X55TS17130 12.9SS8451-8CH	TATA spare parts
11071916458	HEX FL BOLT M16X45	TATA spare parts
11073506222	HEX FL BOLT M6X22 TS17130-8.8-SS8451S2-Y	TATA spare parts
11073506281	HEX FL BOLT M6X28 TS17130-8.8 SS8451S2-Y	TATA spare parts
11073506303	H/FL BOLT M6X30 TS17130-8.8-SS8451S2-Y	TATA spare parts
11073506451	H/FL BOLT M6X45 TS17130 8.8 SS8451S2-Y	TATA spare parts
11073506508	HEX FL BOLT M6X50 TS17130 8.8 SS8451S2-Y	TATA spare parts
11073506605	HEX FL BOLT M6X60 TS17130 8.8 SS8451S2-Y	TATA spare parts
11073506621	HEX FL BOLT M6X70 TS17130 8.8 SS8451S2-Y	TATA spare parts
11073508284	H/FL BOLT M8X28 TS17130-8.8-SS8451S2-Y	TATA spare parts
11073508306	HEX FL BOLT M8X30 TS17130 8.8 SS8451S2	TATA spare parts
11073508357	H/FL BOLT M8X35 TS17130 8.8 SS8451S2-Y	TATA spare parts
11073508403	HEX FL BOLT B8X40 TS17130-8.8-SS8451S2-Y	TATA spare parts
11073508454	H/FL BOLT M8X45 TS17130-8.8-SS8451S2-Y	TATA spare parts
11073508551	HEX FL BOLT M8X55 TS17130 8.8 SS8451S2-Y	TATA spare parts
11073508624	HEX FL BOLT M8X70 TS17130 8.8 SS8451S2-Y	TATA spare parts
11073508632	HEX FL BOLT M8X75 TS17130 8.8 SS8451S2-Y	TATA spare parts
11073508641	HEX FL BOLT M8X80 TS17130 8.8 SS8451S2-Y	TATA spare parts
11073508659	HEXFLBOLTM8X90	TATA spare parts

11073508675	HEX FL BOLT M8X110 TS17130-8.8-SS8451S2-	TATA spare parts
11073508934	H/FL BOLT M8X120 TS17130 8.8 SS8451S2-Y	TATA spare parts
11073510459	HEX FL BOLT M10X45 TS17130-8.8-SS8451S2-	TATA spare parts
11073510505	HEX FL BOLT M10X50	TATA spare parts
11073510602	HEX FL BOLT M10X60 TS17130-8.8-SS8451S2	TATA spare parts
11073510611	H/FL BOLT M10X65 TS17130-8.8-SS8451S2-Y	TATA spare parts
11073510645	HEX FL BOLT M10X80 TS17130 8.8 SS8451S2	TATA spare parts
11073510858	HEX FL BOLT M10X85 TS17130-8.8SS8451S2-Y	TATA spare parts
11073512664	HEX FL BOLT M12X100TS17130 8.8SS8451S2-Y	TATA spare parts
11073512681	HEX FL BOLT M12X120TS17130 8.8SS8451S2-Y	TATA spare parts
11073596001	HEX FL BOLT M8X22 TS17130-8.8 SS8451S2-B	TATA spare parts
11073596027	HEX FL BOLT M8X85 TS17130 8.8 SS8451S2-Y	TATA spare parts
11073596094	H/FL BOLT M8X115 TS17130-8.8 SS8451S2-Y	TATA spare parts
11073612359	FL BOLT M12X1.5X35TS17130 8.8 SS8451S2-Y	TATA spare parts
11073696013	FL BOLT M12X1.25X100	TATA spare parts
11073696056	FL BOLT M12X1.25X90	TATA spare parts
11073706353	H/FL BOLT M6X35 TS17130 10.9SS8451S2	TATA spare parts
11073706400	H/FL BOLT M6X40 TS17130 10.9SS8451S2-YH	TATA spare parts
11073706507	H/FL BOLT M6X50 TS17130 10.9 SS8451S2-YH	TATA spare parts
11073708283	H/FL BOLT M8X28 TS17130 10.9SS8451S2-YH	TATA spare parts
11073708402	H/FL BOLT M8X40 TS17130 10.9SS8451S2-YH	TATA spare parts
11073708453	H/FL BOLT M8X45 TS17130	TATA spare parts
11073708615	H/FL BOLT M8X65 TS17130-10.9SS8451S2	TATA spare parts
11073708640	H/FL BOLT M8X80 TS17130 10.9 SS8451S2-YH	TATA spare parts
11073708925	H/FL BOLT M8X100 TS17130-10.9SS8451S2-YH	TATA spare parts
11073710351	HEX FLBOLT M10X35TS17130 10.9SS8451S2-YH	TATA spare parts
11073710407	H/FL BOLT M10X40 TS17130-10.9SS8451S2-YH	TATA spare parts
11073710458	H/FL BOLT M10X45TS17130-10.9SS8451S2-YH	TATA spare parts
11073710504	H/FL BOLT M10X50 TS17130 10.9SS8451S2-YH	TATA spare parts
11073710555	H/FL BOLT M10X55 TS17130 10.9SS8451S2-YH	TATA spare parts
11073710601	H/FL BOLT M10X60 TS17130	TATA spare parts
11073710636	H/FL BOLT M10X75	TATA spare parts
11073710644	H/FL BOLT M10X80 TS17130 10.9SS8451S2-YH	TATA spare parts
11073710709	H/FL BOLT M10X130TS17130-10.9SS8451S2-YH	TATA spare parts
11073712400	H/FL BOLT M12X40 TS17130 10.9SS8451S2-YH	TATA spare parts
11073712451	H/FL BOLT M12X45 TS17130 10.9SS8451S2-YH	TATA spare parts
11073712558	H/FL BOLT M12X55 TS17130-10.9SS8451S2-YH	TATA spare parts
11073712604	H/FL BOLT M12X60 TS17130 10.9SS8451S2-YH	TATA spare parts
11073712612	H/FL BOLT M12X65 TS17130 10.9SS8451S2-YH	TATA spare parts
11073716600	H/FL BOLT M16X60 TS17130-10.9SS8451S2-YH	TATA spare parts
11073796018	H/FL BOLT M8X95TS17130-10.9SS8451S2-YH	TATA spare parts
11073796026	H/FL BOLT M8X105TS17130-10.9SS8451S2-YH	TATA spare parts
11073796051	H/FL.BOLT M8X85 TS17130 10.9SS8451S2-YH	TATA spare parts
11073812609	FLBOLT M12X1.5X60TS17130 10.9SS8451S2-YH	TATA spare parts
11073896012	BOLT M12X1.5X105	TATA spare parts
11074710354	HEX FL BOLT M10X35TS17070 10.9SS8451-8CH	TATA spare parts
11075506203	HEX FL BOLT M6X20 TS17070-8.8-SS8451S2	TATA spare parts



11075506254	HEX FL BOLT M6X25 TS17070-8.8-SS8451S2-Y	TATA spare parts
11075506459	HEX FL BOLT M6X45	TATA spare parts
11075506505	HEX FL BOLT M6X50 TS17070-8.8 SS8451S2-Y	TATA spare parts
11075506611	HEX FL BOLT M6X65 TS17070 8.8 SS8451S2-Y	TATA spare parts
11075508257	HEX FL BOLT M8X25 TS17070 8.8 SS8451S2-Y	TATA spare parts
11075508281	HEX FL BOLT M8X28 TS17070-8.8-SS8451S2-Y	TATA spare parts
11075508303	HEX FL BOLT M8X30 TS17070 8.8 SS8451S2-Y	TATA spare parts
11075508354	HEX FL BOLT M8X35 TS17070-8.8-SS8451S2-Y	TATA spare parts
11075508389	HEX FL BOLT M8X38 TS17130-8.8-SS8451S2-Y	TATA spare parts
11075508401	HEX FL BOLT M8X40 TS17070 8.8 SS8451S2-Y	TATA spare parts
11075508451	HEX FL BOLT M8X45 TS17070 8.8 SS8451S2-Y	TATA spare parts
11075508559	HEX FL BOLT M8X55?TS17070-8.8-SS8451S2-Y	TATA spare parts
11075712351	H/FL BOLT M12X35 TS17070-10.9SS845 BS6	TATA spare parts
11076716708	H/FL BOLT M16X70TS17130-10.9SS8457S1-S-B	TATA spare parts
11077506201	H/FL BOLT M6X20 TS17130-8.8-SS8457S1-S-B	TATA spare parts
11077508254	H/FL BOLT M8X25 TS17130 8.8 SS8457S1-S-B	TATA spare parts
11077508289	H/FL BOLT M8X28 TS17130-8.8SS8457S1-S-B	TATA spare parts
11077510305	H/FL BOLT M10X30	TATA spare parts
11077510658	H/FL BOLT M10X65 TS17130-8.8SS8457S1-S-B	TATA spare parts
11077596013	H/FL BOLT M6X25TS17130-8.8-SS8457S1-BL-B	TATA spare parts
11077596030	H/FL BOLT M6X20	TATA spare parts
11077596064	FL BOLT M10X60 TS17130-8.8 SS8457S1-BL-B	TATA spare parts
11077596129	H/FL BOLT M10X30 TS17130-8.8SS8457S1-S-C	TATA spare parts
11077596188	H/FL BOLT M6X35 TS17130 10.9SS8451S2-YH	TATA spare parts
11077596226	H/FL BOLT M10X45TS17130-8.8SS8457S1-BL-B	TATA spare parts
11077596293	H/FL BOLT M8X45 TS17130-8.8SS8457S1-BL-B	TATA spare parts
11077596340	FL BOLT M10X65 TS17130-8.8SS8457S1-BL-B	TATA spare parts
11077596374	H/FL BOLT M8X55 TS17130-8.8SS8457S1-BL-B	TATA spare parts
11077596382	FL BOLT M10X110 TS17130-8.8SS8457S1-BL-B	TATA spare parts
11077596421	H/FL BOLT M8X35 TS17130-8.8SS8457S1-BL-B	TATA spare parts
11077596498	H/FL BOLT M8X70 TS17130-8.8SS8457S1-BL-B	TATA spare parts
11077796004	FL BOLT M12X60 TS17130-10.9SS8457S1-BL-B	TATA spare parts
11077796021	FL BOLT M12X35 TS17130 10.9SS8457S1-BL-C	TATA spare parts
11077796039	FL BOLT M12X40 TS17130 BS6	TATA spare parts
11077796047	FL BOLT M12X45 TS17130 10.9SS8457S1-BL-C	TATA spare parts
11077796055	FL BOLT M12X50 TS17130 10.9SS8457S1-BL-C	TATA spare parts
11077796063	FL BOLT M12X55 TS17130 10.9SS8457S1-BL-C	TATA spare parts
11077796071	FL BOLT M10X65TS17130-10.9SS8457S1-BL-B	TATA spare parts
11077796080	FL BOLT M10X35 TS17130-10.9 BS6-PH2	TATA spare parts
11077796101	FL BOLT M10X30 TS17130-10.9SS8457S1-BL-B	TATA spare parts
11077896025	BOLT M14X1.5X70TS17130 10.9SS8457S1-BL-B	TATA spare parts
11077896050	BOLT M14X1.5X45TS17130 10.9SS8457S1-BL-B	TATA spare parts
11077896114	BOLT M16X1.5X65TS17130-10.9SS8457S1-BL-B	TATA spare parts
11077896220	BOLTM16X1.5X105TS17130-10.9SS8457S1-BL-B	TATA spare parts
11078596009	FL BOLT M10X40 TS17070 BS6	TATA spare parts
11084108407	CENTRE BOLT M8 X 40 X 10	TATA spare parts
11084108504	CENTRE BOLT M8 X 50 X 10	TATA spare parts

11084110355	CENTRE BOLT M10X35X10 IS9484 10.9 SS9400	TATA spare parts
11084110401	CENTRE BOLT M10X40X10 IS9484	TATA spare parts
11084110509	CENTRE BOLT M 10X50X10	TATA spare parts
11084110550	CENTRE BOLT M10X55X9-IS9484-10.9 SS9400	TATA spare parts
11084110606	CENTRE BOLT M10X60X9 IS9484-10.9-SS9400	TATA spare parts
11084110614	CENTRE BOLT M10X65X9	TATA spare parts
11084110622	CENTRE BOLT M10X70X10 IS9484 10.	TATA spare parts
11084110631	CENTRE BOLT M10X75X10 IS9484 10.9 SS9400	TATA spare parts
11084110649	CENTRE BOLT M10 X 75 X 9	TATA spare parts
11084110657	CENTRE BOLT M10X85X10	TATA spare parts
11084110665	CENTRE BOLT M10 X 81 X 9	TATA spare parts
11084110673	CENTRE BOLT M10 X 100 X11	TATA spare parts
11084110681	CENTRE BOLT M10X90X9-IS9484-10.9-SS9400	TATA spare parts
11084110690	CENTRE BOLT M10X105X10IS9484 10.9 SS9400	TATA spare parts
11084110703	CENTRE BOLT M 10X110X10	TATA spare parts
11084110731	CENTRE BOLT M10 X 122	TATA spare parts
11084110738	CENTRE BOLT M10X122X11	TATA spare parts
11084110762	CENTRE BOLT M10X140X11	TATA spare parts
11084110797	CENTRE BOLT M10X85X11 IS9484 10.9 SS9400	TATA spare parts
11084110801	CENTRE BOLT M10X90X11	TATA spare parts
11084112676	CENTRE BOLT M12X95X11	TATA spare parts
11084112684	CENTRE BOLT M12X 100 X11	TATA spare parts
11084112692	CENTRE BOLT M12X105X11	TATA spare parts
11084112706	CENTRE BOLT M12X110X11 IS9484 10.9SS9400	TATA spare parts
11084112714	CENTRE BOLT M12X115X11	TATA spare parts
11084112749	CENTRE BOLT M12 X 132 X11	TATA spare parts
11084112757	CENTRE BOLT M12 X 137 X11	TATA spare parts
11084112765	CENTRE BOLT M12X144X11	TATA spare parts
11084112781	CENTRE BOLT M12 X 147 X11	TATA spare parts
11084112790	CENTRE BOLT M12 X 155 X11	TATA spare parts
11084112803	CENTRE BOLT M12 X1 60 X11	TATA spare parts
11084112820	CENTRE BOLT M12 X 171 X11	TATA spare parts
11084112854	CENTRE BOLT M12X187X11 IS9484-10.9SS9400	TATA spare parts
11084112862	CENTRE BOLT M12 X 160 X13	TATA spare parts
11084112871	CENTRE BOLT M12X140X11-IS9484-10.9SS9400	TATA spare parts
11084112889	CENTRE BOLT M12X205X11-IS	TATA spare parts
11084112897	CENTRE BOLT M12 X 200 X11	TATA spare parts
11084112901	CENTRE BOLT M12 X 210 X11	TATA spare parts
11084112919	CENTRE BOLT M12X225X11-IS9484-10.9SS9400	TATA spare parts
11084112927	CENTER BOLT M12X1.75PX180	TATA spare parts
11084112951	CENTRE BOLT M12 X 246 X11	TATA spare parts
1112600058	BREATHER	TATA spare parts
11135BP01	CENTRE PIECE FOR FRONT BU	TATA spare parts
11136BP01	L.H. SIDE PIECE FOR FRONT	TATA spare parts
11137BP01	R.H. SIDE PIECE FOR FRONT	TATA spare parts
11138BP01	SIDE PIECE JOINT BKT.	TATA spare parts
11141006250	CUP HEAD BOLT M6 X 25	TATA spare parts

11157SE01	M.S. ARMREST	TATA spare parts
11160610257	NIP BOLT M10 X 25	TATA spare parts
112202007057JO	2CUM OPEN BOX TIPPER ACE GOLD PETROL BS6	TATA spare parts
112408110006	INSPECTION LID ASSEMBLY	TATA spare parts
11291005251	PAN HD SCR M5X25 6.8-H-JISB1111SS8451-8C	TATA spare parts
11295005256	PAN HD SCRM5X25 6.8-H-JISB1111SS8451S2-Y	TATA spare parts
113110200001	TOWING HOOK FRONT AND REAR	TATA spare parts
11321096028	HEX SCREW M4X14 IS1364P2-4.6-SS8451-8C	TATA spare parts
11321304127	HEX SCREW M4 X 12	TATA spare parts
11321305107	HEX SCREW M5X10 IS1364P2 8.8 SS8451-8C	TATA spare parts
11321305123	HEX SCREW M5 X 15	TATA spare parts
11321305166	HEX SCREW M5 X 16	TATA spare parts
11321305182	HEX SCREW M5X18 IS1364P2-8.8 BS6-PH2	TATA spare parts
11321305255	SCREW	TATA spare parts
11321396013	HEX SCREW M5X14	TATA spare parts
11321396064	HEX SCREW M5X16	TATA spare parts
11321396072	HEX SCREW M5X12	TATA spare parts
11321396102	HEX SCREW M4X8 IS1364P2-8.8-SS8451-8C	TATA spare parts
11321398016	HEX SCREW M4 X 16	TATA spare parts
11322010259	SCREW M10 X 25	TATA spare parts
11323906124	HEX SCREW M6 X 12	TATA spare parts
11323906141	HEX SCREW M6X14-IS1364P2-	TATA spare parts
11323906167	HEX SCREW M6 X 16	TATA spare parts
11323906183	HEX SCREW M6 X 18	TATA spare parts
11323906205	HEX SCREW M6 X 20	TATA spare parts
11323906221	HEX SCREW M6 X 22	TATA spare parts
11323906281	HEX SCREW M6 X 28	TATA spare parts
11323906302	HEX SCREW M6X30	TATA spare parts
11323906353	HEX SCREW M6X35 IS1364P2-8.8 SS8451-8C	TATA spare parts
11323906400	HEX SCREW M6X40 IS1364P2-8.8 SS8451-8C B	TATA spare parts
11323908127	HEX SCREW M8 X 12	TATA spare parts
11323908160	HEX SCREW M8 X 16	TATA spare parts
11323908186	HEX SCREW M8 X 18	TATA spare parts
11323908208	HEX SCREW M8 X 20	TATA spare parts
11323908224	HEX SCREW M8 X 22	TATA spare parts
11323908259	HEX SCREW M8 X 25	TATA spare parts
11323908283	HEX SCREW M8 X 28	TATA spare parts
11323908305	HEX SCREW M8X30-IS1364P2-8.8-SS8451-8C	TATA spare parts
11323908356	HEX SCREW M8 X 35	TATA spare parts
11323908402	HEX SCREW M8 X 40	TATA spare parts
11323908453	HEX SCREW M8 X 45	TATA spare parts
11323908551	HEX SCREW M8X55 IS1364P2 8.8 SS8451-8C	TATA spare parts
11323910164	HEX SCREW M10 X 16	TATA spare parts
11323910181	HEX SCREW M10 X 18	TATA spare parts
11323910202	HEX SCREW M10 X 20	TATA spare parts
11323910229	HEX SCREW M10 X 22	TATA spare parts
11323910253	HEX SCREW M10 X 25	TATA spare parts

11323910288	HEX SCREW M10 X 28	TATA spare parts
11323910300	HEX SCREW M10 X 30	TATA spare parts
11323910326	HEX SCREW M10 X 32	TATA spare parts
11323910351	HEX SCREW M10 X 35	TATA spare parts
11323910407	HEX SCREW M10 X 40	TATA spare parts
11323910458	HEX SCREW M10 X 45	TATA spare parts
11323910504	HEX SCREW M10 X 50	TATA spare parts
11323910555	HEX SCREW M10X55 IS1364P2-8.8 SS9400	TATA spare parts
11323910628	HEX SCREW M10X70 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11323910644	HEX SCREW M10X80 IS1364P2-8.8 SS8451-8C	TATA spare parts
11323910679	HEX SCREW M10 X 95	TATA spare parts
11323912205	SCREW M12	TATA spare parts
11323912221	HEX SCREW M12 X 22	TATA spare parts
11323912256	HEX SCREW M12 X 25	TATA spare parts
11323912281	HEX SCREW M12X28 IS1364P2-8.8-SS8451-8C	TATA spare parts
11323912302	HEX SCREW M12 X 30	TATA spare parts
11323912353	HEX SCREW M12 X 35	TATA spare parts
11323912400	HEX SCREW M12 X 40	TATA spare parts
11323912507	HEX SCREW M12X50 IS1364P2-8.8-SS8451-8C	TATA spare parts
11323912558	HEX SCREW M12X55	TATA spare parts
11323912604	HEX. SCREW M 12X60 (ASSY. MTG. BRACKET T	TATA spare parts
11323914259	HEX SCREW M14 X 25	TATA spare parts
11323914356	HEX SCREW M14 X 35	TATA spare parts
11323914402	HEX SCREW M14 X 40	TATA spare parts
11323914453	BOLT 8.8 GRADE-M14X45	TATA spare parts
11323916308	HEX SCREW M16X30 IS 1364 P2 8.8 SS8451 8	TATA spare parts
11323916359	HEX SCREW M16X35 IS1364P2-8.8-SS8451-8C	TATA spare parts
11323916405	HEX SCREW M16X40	TATA spare parts
11323920500	HEX SCREW M20X50 IS1364P2-8.8-SS8451-8C	TATA spare parts
11323996026	HEX SCREW M8 X 22	TATA spare parts
11323996034	HEX SCREW M10 X 22	TATA spare parts
11323996042	HEX SCREW M10 X 28	TATA spare parts
11323996051	HEX SCREW M10 X 30	TATA spare parts
11323996069	HEX SCREW M10 X 35	TATA spare parts
11323996077	HEX SCREW M10 X 45	TATA spare parts
11323996085	HEX SCREW M12 X 25	TATA spare parts
11323996093	HEX SCREW M12 X 30	TATA spare parts
11323996107	HEX SCREW M12 X 35	TATA spare parts
11323996115	HEX SCREW M6 X 28	TATA spare parts
11323996131	HEX SCREW M10X40-IS1364P2-8.8-SS8451-8C	TATA spare parts
11323996174	HEX SCREW M8X14 IS1364P2-8.8-SS8451-8C	TATA spare parts
11323996182	HEX SCREW M10X75 IS1364P2-8.8-SS8451-8C	TATA spare parts
11323996191	HEX SCREW M8 X 12	TATA spare parts
11323996212	HEX SCREW M12X45-IS1364P2	TATA spare parts
11323996221	HEX. SCREW M 14X40	TATA spare parts
11323996247	HEX SCREW M6X10 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11323996271	HEX SCREW M16 X 45	TATA spare parts

11323996352	HEX SCREW M10 X 65	TATA spare parts
11323996361	HEX SCREW M10X55	TATA spare parts
11323996867	SCREW M 10X32	TATA spare parts
11323996875	HEX SCREW M4X12 IS1364P2-8.8-SS8451-8C	TATA spare parts
11323998026	SCREW M8 X 22 S8.8	TATA spare parts
11323998027	HEX SCREW M 8 X 25	TATA spare parts
11323998037	HEX SCREW M8 X 25	TATA spare parts
11323998045	HEX SCREW M10 X 25	TATA spare parts
11323998053	HEX SCREW M6X16 IS1364P2-8.8 SS8451S2	TATA spare parts
11323998061	HEX SCREW M6 X 12	TATA spare parts
11323998070	HEX SCREW M8 X 20	TATA spare parts
11323998088	HEX SCREW M8X30 IS1364P2-8.8-SS8451-8	TATA spare parts
11323998096	HEX SCREW M8 X 35	TATA spare parts
11323998151	HEX SCREW M6X18 IS1364P2-8.8-SS8451-	TATA spare parts
11323998169	HEX SCREW M6 X 20	TATA spare parts
11323998177	HEX SCREW M10 X 20	TATA spare parts
11323998185	HEX SCREW M10X18-IS1364P2-8.8-SS8451-8C	TATA spare parts
11323998193	HEX SCREW M8X40 IS1364P2-8.8-SS8451-8C	TATA spare parts
11323998207	HEX SCREW M8 X 28	TATA spare parts
11323998215	HEX SCREW M6X25 IS1364P2-8.8	TATA spare parts
11323998223	HEX SCREW M8 X 16	TATA spare parts
11323998231	HEX SCREW M6X22 IS1364P2-8.8-SS8451-8C	TATA spare parts
11323998304	HEX SCREW M6X8 IS1364P2-8.8-SS8451-8C	TATA spare parts
11323998347	HEX SSCREW M6X14	TATA spare parts
11323998371	HEX SCREW M8X50 IS1364P2-8.8-SS8451-8C	TATA spare parts
11323998398	HEX SCREW M12 X 40	TATA spare parts
11323998401	HEX SCREW M8X20 IS1364P2-8.8-SS8451-13D	TATA spare parts
11323999017	HEX SCREW M6 X 8	TATA spare parts
11323999025	HEX SCREW M8 X 28	TATA spare parts
11323999068	SCREW 116TS17140	TATA spare parts
11323999114	HEX SCREW M8 X 18	TATA spare parts
11323999262	HEX SCREW M6X30 WH 8.8 TS17140 SS8451-8C	TATA spare parts
11324008120	HEX SCREW M8X1X12 TS17100 8.8 SS8451-8C	TATA spare parts
11324008601	BOLT M8 X 60	TATA spare parts
11324010256	HEX SCR M10X1.25X25IS13725 8.8 SS8451-8C	TATA spare parts
11324012356	HEX SCR M12X1.25X35IS13725 8.8 SS8451-8C	TATA spare parts
11324014251	HEX SCREW M14 X 1.5 X 25	TATA spare parts
11324014286	HEX SCREW M14 X 1.5 X 28	TATA spare parts
11324014308	HEX SCREW M14X1.5X30IS13725-8.8SS8451-8C	TATA spare parts
11324014324	HEX SCR M14 X 1 .5 X 32	TATA spare parts
11324014359	HEX SCREW M14 X 1.5 X 35	TATA spare parts
11324014405	HEX SCREW M14 X 1.5 X 40	TATA spare parts
11324016254	HEX SCR M16X1.5X25 IS13725-8.8SS8451-8C	TATA spare parts
11324016301	HEX SCREW M16 X 1.5 X 30	TATA spare parts
11324016351	HEX SCR M16X1.5X35 IS13725-8.8 SS8451	TATA spare parts
11324016459	HEX SCR M16X1.5X45IS13725	TATA spare parts
11324016602	HEX SCREW M16X1 5X60 IS:13725	TATA spare parts

11324018401	HEX SCREW M18 X 1.5 X 40	TATA spare parts
11324018664	HEX SCREW M18X1.5X90	TATA spare parts
11324069605	SCREW M12 X 1.5 X 40	TATA spare parts
11324096011	HEX SCREW M12 X 1.5 X 25	TATA spare parts
11324096029	HEX SCREW M12 X 1.5 X 30	TATA spare parts
11324096037	HEX SCREW M12 X 1.5 X 35	TATA spare parts
11324096045	HEX SCREW M12 X 1.5 X 40	TATA spare parts
11324096053	HEX SCR M12X1.5X45 IS13725-8.8SS8451-8C	TATA spare parts
11324096061	HEX SCR M14X1.5X45 IS13725-8.8-SS8451-8C	TATA spare parts
11324096096	HEX SCR M12X15X28 IS13725-88SS8451-8C	TATA spare parts
11324096118	HEX SCREW M14X1.5X35 8.8	TATA spare parts
11324096126	HEX SCREW M12 X1.25 X 32	TATA spare parts
11324096134	HEX SCREW M14X1.5X50 8.8	TATA spare parts
11324096142	HEX SCR M14X1.5X40 IS13725-8.8-SS8451-8C	TATA spare parts
11324096151	HEX SCR M12X1.25X42 IS13725-8.8 SS8451S2	TATA spare parts
11324099010	HEX SCREW M12 X 1.5 X 20	TATA spare parts
11324099028	HEX SCREW M12 X 1.5 X 22	TATA spare parts
11324099036	HEX SCREW M12 X 1.5 X 25	TATA spare parts
11324099044	HEX SCREW M12 X 1.5 X 28	TATA spare parts
11324099052	HEX SCREW M12 X 1.5 X 30	TATA spare parts
11324099061	HEX SCREW M12 X 1.5 X 35	TATA spare parts
11324099079	HEX SCREW M12 X 1.5 X 40	TATA spare parts
11324099095	HEX SCREW	TATA spare parts
11324099109	SCREW M12X1.5X35-PH8.8-TS17140-SS8451-8C	TATA spare parts
11324099125	HEX SCREW	TATA spare parts
11324106164	HEX SCREW M6X16 IS1364P2 10.9 SS9400	TATA spare parts
11324106300	HEX SCREW M6 X 30	TATA spare parts
11324108141	HEX SCREW M8X14 IS1364P2-10.9 SS9400	TATA spare parts
11324108167	HEX SCREW M8 X 16	TATA spare parts
11324108183	HEX SCREW M8 X 18	TATA spare parts
11324108205	HEX SCREW M8 X 20	TATA spare parts
11324108221	HEX SCREW M8 X 22	TATA spare parts
11324108256	HEX SCREW M8 X 25	TATA spare parts
11324108281	HEX SCREW M8 X 28	TATA spare parts
11324108302	HEX SCREW M8 X 30	TATA spare parts
11324108353	COM HEAD BOLT (COLLER) M 8 X 35	TATA spare parts
11324108451	HEX SCREW M8 X 45	TATA spare parts
11324110226	HEX SCREW M10X22 TS17100-10.9-SS9400 BS6	TATA spare parts
11324110251	HEX SCREW M10 X 25	TATA spare parts
11324110307	HEX SCREW M10 X 30	TATA spare parts
11324110358	HEX SCREW M10 X 35	TATA spare parts
11324110455	HEX SCREW M10X45 IS1364P2	TATA spare parts
11324112253	HEX SCR M12X25 TS17100-10.9 SS8451-8CH B	TATA spare parts
11324112300	HEX SCREW M12 X 30	TATA spare parts
11324112351	HEX SCREW M12 X 35	TATA spare parts
11324112407	HEX SCREW M12 X 40	TATA spare parts
11324112504	HEX SCREW M12X50 IS1364P2-10.9-SS9400	TATA spare parts

11324114302	HEX SCREW M14X30	TATA spare parts
11324114451	HEX SCREW M14X45 TS17100 10.9SS8451-8CH	TATA spare parts
11324116356	HEX. SCREW M16X35 TS17100 10.9 SS9400	TATA spare parts
11324116500	HEX SCREW M16X50 IS1364P2 10.9 SS9400	TATA spare parts
11324120400	HEX SCREW M20X40 IS1364P2 10.9 SS9400	TATA spare parts
11324196007	HEX SCR M12X30 TS17100 10.9 SS8451-8CH B	TATA spare parts
11324196023	HEX SCREW M8X20 IS1364P2-10.9 SS8451-8CH	TATA spare parts
11324196028	HEX SCREW M8X20 IS1364 10	TATA spare parts
11324196031	HEX SCREW M8 X 22	TATA spare parts
11324196040	HEX SCREW M8X28	TATA spare parts
11324196058	HEX SCREW M8X30	TATA spare parts
11324196066	HEX SCREW M10 X 25	TATA spare parts
11324196074	HEX SCREW M10 X 30	TATA spare parts
11324196082	HEX SCREW M8X35IS1364P2-10.9-SS8451-8CH	TATA spare parts
11324196104	HEX SCREW M8X25	TATA spare parts
11324196112	HEX SCREW M8 X 18	TATA spare parts
11324196121	HEX SCREW M10*40	TATA spare parts
11324196139	HEX SCREW M12X35IS1364P2-10.9 SS8451-8CH	TATA spare parts
11324196147	HEX SCREW M10X35	TATA spare parts
11324196163	HEX SCREW M8X16-IS1364P2-10.9SS8451S2-Y	TATA spare parts
11324196198	HEX SCR M12X45	TATA spare parts
11324196210	HEX SCREW M12X55 TS17100 10.9SS8451-8CH	TATA spare parts
11324210352	HEXSCR M10X1.25X35IS13725 10.9SS8451-8CH	TATA spare parts
11324214358	HEX SCR M14X1.5X35IS13725-10.9SS8451-8CH	TATA spare parts
11324214404	HEX SCR M14X1.5X40	TATA spare parts
11324216407	HEX SCREW M16 X 1.5 X 40	TATA spare parts
11324216458	HEX SCR M16X1.5X45TS17100 10.9SS8451-8CH	TATA spare parts
11324216555	HEX SCREW M16X1.5X55 IS13725-10.9-SS9400	TATA spare parts
11324216601	HEX SCREW M16X1.5X60 TS17100 10.9 SS9400	TATA spare parts
11324218507	HEX SCR M18X1.5X50IS13725-10.9SS8451-8CH	TATA spare parts
11324220404	HEX SCREW M 20X1.5X40	TATA spare parts
11324220455	HEX SCR M20X1.5X45 IS13725 10.9SS8451-8H	TATA spare parts
11324220501	H/SCR.M20X1.5X50 IS13725 10.9 SS8451-8CH	TATA spare parts
11324296001	HEXAGONAL BOLT M16X55 BS6	TATA spare parts
11324296044	HEXSCR M18X1.5X40 TS17100-10.9SS8451-8CH	TATA spare parts
11324296061	HEX SCR M12X1.5X25	TATA spare parts
11324299019	SCREW M12 X1.5 X 22	TATA spare parts
11324299035	HEX SCR M12X1.5X28	TATA spare parts
11324299043	SCREW 180	TATA spare parts
11324299060	HEX SCREW M10 X 1 X 25	TATA spare parts
11324299078	HEX SCREW M12 X 1.5 X 35	TATA spare parts
11324299116	HEX SCREW M12X1.5X40 IS13725-10.9 SS9400	TATA spare parts
11324299124	HEX SCREW M12X1.5X50 IS13725-10.9-SS9400	TATA spare parts
11324299132	HEX SCR M12X1.5X70IS13725 10.9SS8451	TATA spare parts
11324299159	H/SCR M12X1.5X100 BS6-PH2	TATA spare parts
11324306121	SCREW M6 X 12	TATA spare parts
11324504160	HEX SCREW M4X16 IS1364P2-8.8 SS8451S2-Y	TATA spare parts

11324504186	HEX SCREW M4X18 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324505107	HEX SCREW M5X10 IS1364P2 8.8 SS8451S2-Y	TATA spare parts
11324506120	HEX SCREW M6X12 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324506146	HEX SCREW M6X14 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324506162	HEX SCREW M6X16 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324506189	HEXSCREWM6X18IS1364P2-8.8-SS8451S2-Y BS6	TATA spare parts
11324506201	HEX SCREW M6X20 IS1364P2 8.8 SS8451S2-Y	TATA spare parts
11324506251	HEX SCREW M6X25 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324506286	HEX SCREW M6X28 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324508165	HEX SCREW M8X16 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324508181	HEX SCREW M8X18 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324508203	HEX SCREW M8X20 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324508254	HEX SCREW M8X25 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324508301	HEX BOLT M8X30 IS1364P1-8.8 SS8451S2-Y	TATA spare parts
11324508351	HEX SCREW M8X35 IS1364P2-8.8-SS8451	TATA spare parts
11324508408	HEX SCREW M8X40 TS17100-8.8-SS8451S2-Y B	TATA spare parts
11324510208	HEX SCREW M10X20 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324510224	HEX SCREW M10X22 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324510259	HEX SCREW M10X25 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324510283	HEX SCREW M10X28 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324510305	HEX SCREW M10X30 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324510321	HEX SCREW M10X32 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324510500	HEX SCREW M10X50 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324510615	HEX SCREW M10X65	TATA spare parts
11324512251	HEX SCREW M12X25 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324512308	HEX SCREW M12X30 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324512359	HEX SCREW M12X35 IS1364P2-8.8-SS8451S2-Y	TATA spare parts
11324512405	HEX SCREW M12X40	TATA spare parts
11324514408	HEX SCREW M14X40 TS17100-8.8-SS8451S2-Y	TATA spare parts
11324516354	HEX SCREW M16X35 IS1364P2 8.8 SS8451S2	TATA spare parts
11324612302	HEX SCR M12X1.5X30 IS13725-8.8 SS8451S2Y	TATA spare parts
11324612400	H/SCREW M12X1.5X40IS13725- 8.8-SS8451S2-	TATA spare parts
11324614500	H/SCREW M14X1.5X50IS13725-8.8-SS8451S2	TATA spare parts
11324614631	HEX SCR M14X1.5X75	TATA spare parts
11324696018	SCREW M12X1.25X32 TS17100-8.8-SS8451S2-Y	TATA spare parts
11324696034	SCREW M10X1.25X25 IS13725-8.8-SS8451S2-Y	TATA spare parts
11324706188	HEX SCR M6X18 IS1364P2 10.9 SS8451S2-YH	TATA spare parts
11324708181	HEX SCREW M8X18 IS1364P2-10.9-SS8451S2-Y	TATA spare parts
11324708229	HEX SCREW M8X22IS1364P2-10.9 SS8451S2-YH	TATA spare parts
11324708288	HEX SCREW M8X28 IS1364P2 10.9SS8451S2-YH	TATA spare parts
11324708351	HEX SCR M8X35 IS1364P2 10.9 SS8451S2-YH	TATA spare parts
11324710401	HEX SCREW M10X40TS17100-10.9 SS8451S2-H	TATA spare parts
11324810309	HEX SCR M10X1X30 IS13725 10.9SS8451S2-YH	TATA spare parts
11325696003	HEX SCR M8X35 TS17100-8.8-SS8457S1-BL-B	TATA spare parts
11325696011	HEX SCR M6X20 IS1364P2 8.8 SS8457S1-BL	TATA spare parts
11325696283	HEX SCR M8X25 IS1364P2-8.8-SS8457S1-BL-B	TATA spare parts
11325696330	HEX SCR M8X20 TS17100 8.8 SS8457S1-BL-B	TATA spare parts



11325696356	HEX SCR M8X22 TS17100-8.8 SS8457S1-BL-B	TATA spare parts
11325696399	HEX SCR M5X16 IS1364P2 8.8 SS8457S1-S-B	TATA spare parts
11325696411	HEX SCR M6X14 IS1364P2-8.8-SS8457S1-S-B	TATA spare parts
11325696429	HEX SCR M6X12 IS1364P2-8.8-SS8457S1-BL-B	TATA spare parts
11325696453	HEX SCR M10X35 TS17100-8.8SS8457S1-BL-B	TATA spare parts
11325696470	HEX SCR M12X40 TS17100-8.8SS8457S1 BS6-P	TATA spare parts
11325696500	HEX SCR M10X30 TS17100-8.8SS8457S1-BL-B	TATA spare parts
11325696526	HEX SCR M12X25 TS17100-8.8SS8457S1-BL-B	TATA spare parts
11325696542	HEX SCR M12X45 IS1364P2-8.8SS8457S1-BL-B	TATA spare parts
11325696551	HEX SCR M6X16 IS1364P2-8.8-SS8457S1-BL-B	TATA spare parts
11325696569	HEX SCR M10X20 TS17100 BS6-PH2	TATA spare parts
11325696577	HEX SCR M10X18 TS17100 BS6	TATA spare parts
11325696585	HEX SCR M8X16 TS17100-8.8SS8457S1-BL-B	TATA spare parts
11325696615	HEX SCR M6X25 IS1364P2 SS8457S1 BS6-PH2	TATA spare parts
11325696631	HEX SCR M8X30 IS1364P2 8.8 SS8457S1-BL-B	TATA spare parts
11325696658	HEX SCR M8X25 TS17100 8.8 SS8457S1-BL-B	TATA spare parts
11325696682	HEX SCR M8X40 TS17100 8.8 SS8457S1-BL-B	TATA spare parts
11325796032	H/SCR M14X1.5X28TS17100 8.8SS8457S1-BL-B	TATA spare parts
11325796083	SCR M12X1.5X35 TS17100 8.8SS8457S1-BL-B	TATA spare parts
11325896002	HX SCR M12X35 BS6-PH2	TATA spare parts
11325896061	HEX SCR M8X20 IS1364P2 10.9SS8457S1-BL-B	TATA spare parts
11325896070	HEX SCR M8X16 TS17100 10.9SS8457S1-BL-B	TATA spare parts
11325896088	HX SCR M12X30 IS1364P2 10.9SS8457S1-BL-B	TATA spare parts
11325896096	HX SCR M12X40 TS17100 10.9SS8457S1-BL-B	TATA spare parts
11325896126	HEX. BOLT BS6	TATA spare parts
11325996040	SCR M16X1.5X40 IS13725 10.9SS8457S1-BL-B	TATA spare parts
11326506208	GIMLETSCREWM6X20TS1721	TATA spare parts
11326606164	FLNG GIMLET SCR M6X16TS17210S1SS8451S2-Y	TATA spare parts
11326606253	FLNG GIMLET SCR M6X25	TATA spare parts
11327008201	A/H SCR M8X20-Z4-1-8.8TS17207 SS8451S2-Y	TATA spare parts
11327008252	A/H SCR M8X25 Z4-1 8.8TS17207 SS8451S2-Y	TATA spare parts
11327097026	SCR M12X1.25X35Z4-1-8.8TS17207SS8451S2-Y	TATA spare parts
11327108257	HEX SCREW M8X25 Z4 8.8 TS17207	TATA spare parts
11327197012	SCR M10X1.25X25-Z4-8.8 TS17207SS8451S2-Y	TATA spare parts
11327197021	SCREW M12 X 1.25 X30	TATA spare parts
11327606206	ASSY HEX SCREW M6X20-Z3-1-8.8-TS17207	TATA spare parts
11327606257	ASSY HEX SCREW M6X25-Z3-1-8.8-TS17207	TATA spare parts
11329844244	HEX SCREW 3/8UNC-2A-X1.1/2IN-BS1768-S	TATA spare parts
113327	CAP SCREW	TATA spare parts
11333506141	HEX SCREW M6X14 TS17070-8.8-SS8451S2-Y B	TATA spare parts
11341200CF006950	TRAY ASSY (SENBUS)	TATA spare parts
11341201SF006950	FRAME ASSY (SENBUS)	TATA spare parts
11341505064	HEX FL SCR M5X6	TATA spare parts
11341505102	HEX FL SCREW M5X10 TS17130 8.8 SS8451-8C	TATA spare parts
11341505129	HEX FL SCR M5X12 TS17130-8.8-SS8451S2-Y	TATA spare parts
11341505161	HEX FL SCREW M5X16 TS17130 8.8 SS8451-8C	TATA spare parts
11341505200	HEX FL SCR M5X20 TS17130-8.8-SS8451S2-Y	TATA spare parts

11341506087	HEX FL SCREW M6X8 TS17130-8.8-SS8451	TATA spare parts
11341506109	HEX FL SCR M6X10 TS17130-8.8-SS8451S2-Y	TATA spare parts
11341506125	ASSY SEALING RING	TATA spare parts
11341506141	HEX FL SCREW M6 X 14	TATA spare parts
11341506168	HEX FL SCR M6X16 TS17130-8.8-SS8451S2-Y	TATA spare parts
11341506184	HEX FL SCR M6X18 TS17130-8.8-SS8451S2-Y	TATA spare parts
11341506206	HEX FL SCREW M6X20 TS17130 8.8 SS8451-8C	TATA spare parts
11341506222	HEX FL SCREW M6X22 TS17130 8.8 SS8451-8C	TATA spare parts
11341506257	HEX FL SCR M6X25 TS17130-8.8-SS8451S2-Y	TATA spare parts
11341506303	HEX FL SCR M6X30 TS17130-8.8-SS8451S2-	TATA spare parts
11341506354	HEX FL SCR M6X35 TS17130-8.8-SS8451S2-Y	TATA spare parts
11341506401	HEX FL SCREW M6X40 TS17130-8.8-SS8451-8C	TATA spare parts
11341506451	HEX FL SCR M6X45 TS17130-8.8-SS8451S2-Y	TATA spare parts
11341508128	HEX FL SCREW M8X12 TS17130-8.8-SS8451-8C	TATA spare parts
11341508161	HEX FL SCREW M8 X 16	TATA spare parts
11341508187	HEX FL SCREW M8X18 TS17130-8.8-SS8451-8C	TATA spare parts
11341508209	HEX FL SCREW M8X20 TS17130-8.8-SS8451-8C	TATA spare parts
11341508225	HEX FL SCREW M8X22 TS17130 8.8 SS8451-8C	TATA spare parts
11341508250	HEX FL SCREW M8X25	TATA spare parts
11341508306	HEX FL SCREW M8X30 TS17130 8.8 SS8451-8	TATA spare parts
11341508357	HEX FL SCREW M8X35 TS17130 8.8 SS8451-8C	TATA spare parts
11341508403	HEX FL SCREW M8X40	TATA spare parts
11341508608	FL SCREW M8X60	TATA spare parts
11341510149	HEX FL SCR M10 X 14	TATA spare parts
11341510181	HEX FL SCR M10X18 TS17130-8.8-SS8451S2-Y	TATA spare parts
11341510203	HEX FL SCR M10X20 TS17130-8.8-SS8451-8C	TATA spare parts
11341510220	HEX FL SCR M10X22	TATA spare parts
11341510254	HEX FL SCR M10 X 25	TATA spare parts
11341510289	HEX FL SCREW M10X28	TATA spare parts
11341510301	HEX FL SCREW M10X30 TS17130 8.8SS8451-8C	TATA spare parts
11341510327	HEX FL SCREW M10X32	TATA spare parts
11341510351	HEX FL SCREW M10 X 35	TATA spare parts
11341510408	HEX FL SCREW M10X40 TS17130-8.8SS8451-8C	TATA spare parts
11341510459	HEXFLSCREWM10X45TS171308.8SS8451-8C	TATA spare parts
11341512206	HEX FL SCREW M12X20 TS17130 88SS8451-8C	TATA spare parts
11341512257	HEX FL SCREW M12X25	TATA spare parts
11341512281	HEX FL SCREW M12X28	TATA spare parts
11341512303	HEX FL SCR M12X30 TS17130-8.8-SS8451-8C	TATA spare parts
11341512320	HEX FL SCR M12X32 TS17130 8.8 SS8451-8C	TATA spare parts
11341512354	HEX FL SCR M12X35 TS17130 8.8 SS8451-8C	TATA spare parts
11341512389	HEX FL SCREW M12X38 TS17130 8.8SS8451	TATA spare parts
11341512401	HEX FL SCR M12X40 TS17130 8.8 SS8451-8C	TATA spare parts
11341512451	HEX FL SCREW M12X45	TATA spare parts
11341512508	HEX FL SCREW M12X50 TS17130-8.8SS8451-8C	TATA spare parts
11341514250	HEX FL SCR.M14X25 TS17130 8.8SS8451-8C	TATA spare parts
11341514403	HEX FL SCR.M14X40 TS17130 8.8 SS8451-8C	TATA spare parts
11341514551	HEX FL BOLT M14X80 TS17130 8.8 SS8451-8C	TATA spare parts

11341516457	HEX FL SCREW M16X45 TS17130-8.8SS8451-8C	TATA spare parts
11341598020	HEX FL SCREW M6X16 TS17130 8.8SS8451-13C	TATA spare parts
11341610208	HEX FL SCREW M10X1.25X20-8.8-TS17130	TATA spare parts
11341610305	FL SCR M10X1.25X30 TS17130 8.8 SS8451-8C	TATA spare parts
11341612251	HEX FLSCR M12X1.5X25	TATA spare parts
11341612308	FL.SCR.M12X1.5X30 TS17130 8.8 SS8451-8C	TATA spare parts
11341612359	H/FL SCR M12X1.5X35-8.8TS17130 SS8451-8C	TATA spare parts
11341612405	FL.SCR.M12X1.5X40 TS17130 8.8 SS8451-8C	TATA spare parts
11341612456	HEX FL SCREW M	TATA spare parts
11341614301	H/FL SCR M14X1.5X30 TS17130 8.8SS8451-8C	TATA spare parts
11341614351	H/FL SCR M14X1.5X35	TATA spare parts
11341614408	H/FL SCR M14X1.5X40 TS17130 8.8SS8451-8C	TATA spare parts
11341616508	FL SCR M16X1.5X50TS17130 8.8 SS8451-8C	TATA spare parts
11341706141	HEX FL SCR.M6X14 TS17130-10.9 SS8451-8CH	TATA spare parts
11341708127	HEXFLSCRM8X12TS1713010.9SS8451-8CH BS6	TATA spare parts
11341708160	HEX FL.SCR.M8X16 TS17130 10.9 SS8451-8CH	TATA spare parts
11341708160_niu1	HEX FL.SCR.M8X16 TS17130 10.9 SS8451-8CH	TATA spare parts
11341708186	HEX FL SCR.M8X18 TS17130 10.9 SS8451-8CH	TATA spare parts
11341708208	HEX FL SCREW M8X20TS17130 10.9SS8451-8CH	TATA spare parts
11341708224	HEX FL SCREW M8X22TS17130 10.9SS8451-8CH	TATA spare parts
11341708259	H/FL SCR M8X25 TS17130-10.9-SS8451S2	TATA spare parts
11341708305	HEX FL SCR M8X30 TS17130-10.9-SS8451-8CH	TATA spare parts
11341708321	HEX FL SCR M8X32	TATA spare parts
11341708356	HEX FL SCREW M8X35 TS17130 10.9 SS8451-8	TATA spare parts
11341708402	HEX FL SCREW M8X40 TS17130 10.9SS8451-CH	TATA spare parts
11341708500	HEX FL SCR M8X50 TS17130 10.9 SS8451-8CH	TATA spare parts
11341710164	HEX FL SCR M10X16	TATA spare parts
11341710181	HEX FL SCR M10X18 TS17130-10.9SS8451-8CH	TATA spare parts
11341710202	HEX FL SCREW M10X20 TS17130 10.9 SS9400	TATA spare parts
11341710253	HEX FL SCR M10X25	TATA spare parts
11341710288	HEX FL SCR M10X28 TS17130-10.9SS8451-8CH	TATA spare parts
11341710300	HEX FL SCR M10X30 TS17130 10.9SS8451-8CH	TATA spare parts
11341710351	HEX FL SCR M10X35 TS17130 10.9SS8451-8CH	TATA spare parts
11341710407	HEX FL SCREW M10X40TS17130 10.9SS8451-CH	TATA spare parts
11341710458	HEX FL SCR M10X45 TS17130 10.9SS8451-8CH	TATA spare parts
11341710610	HEX FL SCR M10X65 TS17130 10.9SS8451-8CH	TATA spare parts
11341712302	HEX FL SCR M12X30 TS17130 10.9SS8451-8CH	TATA spare parts
11341712353	HEX FL SCR M12X35 TS17130 10.9SS8451-8CH	TATA spare parts
11341712451	HEX FL SCR M12X45TS17130 10.9 SS8451-8CH	TATA spare parts
11341714305	HEX FL SCR M14X30 TS17130 10.9SS8451-8CH	TATA spare parts
11341796000	H/FL SCR M10X30LH TS17130 10.9SS8451-8CH	TATA spare parts
11341812200	FL.SCR M12X1.5X20 TS17130 10.9SS8451-8CH	TATA spare parts
11341812358	FL SCR M12X1.5X35 TS17130 10.9SS8451-8CH	TATA spare parts
11341812404	FL SCR M12X1.5X40 TS17130 10.9SS8451-8CH	TATA spare parts
11341812455	FL SCR M12X1.5X45 TS17130 10.9SS8451-8C	TATA spare parts
11341814229	FL SCR M14X1.5X22 TS17130 10.9SS8451-8CH	TATA spare parts
11341814351	FL SCR M14X1.5X35 TS17130 10.9SS8451-8CH	TATA spare parts

11341816353	FL SCR M16X1.5X35 TS17130 10.9SS8451-8CH	TATA spare parts
11341816400	FL SCR M16X1.5X40 TS17130 10.9SS8451-8CH	TATA spare parts
11341816451	HEX FL SCREW M16X1.5X45	TATA spare parts
11341816507	HEX FL SCREW M16X1.5X50 TS 17130 10.9 SS	TATA spare parts
11341816558	FL SCREW M16X1.5X55	TATA spare parts
11342208306	COLLAR SCREW M8X30-8.8-TS17215 SS8451-8C	TATA spare parts
11342210301	COLLAR SCREW M10 X 30	TATA spare parts
11342296019	SCREW M10X30 8.8 TS17215 SS8451-8C	TATA spare parts
11342296035	SCREW M8X20-TS17215-8.8-SS8451-8C	TATA spare parts
11342408224	COLLAR SCREW M8 X 22	TATA spare parts
11342408283	COLLAR SCREW M8 X 28	TATA spare parts
11342410300	COLLAR SCR M10X30 10.9 TS17215SS8451-8CH	TATA spare parts
11342410555	COLLAR SCREW M10 X 55	TATA spare parts
11342412302	COLLAR SCR M12X30 10.9 TS17215SS8451-8CH	TATA spare parts
11342496026	COLLAR SCREW M10 X 55	TATA spare parts
11342496034	COLLAR SCREW M8 X 25	TATA spare parts
11342496051	COLLAR SCR M12X35 10.9 TS17215SS8451-8CH	TATA spare parts
11342496069	COLLAR SCR M12X70 10.9 TS17215SS8451-8CH	TATA spare parts
11342512455	COLLAR SCREW M12X1.5X45	TATA spare parts
11342514202	COLLAR SCR M14X1.5X20 10.9 TS17215 SS845	TATA spare parts
11342514504	COLLAR SCREW M14X1.5X50	TATA spare parts
11342514610	COLLAR SCREW M14X1.5X65	TATA spare parts
11342514628	COLLAR SCREW M14X1.5X70	TATA spare parts
11342596012	SCREW M12X1.5X45 10.9	TATA spare parts
11342596021	COLLAR SCREW M12X1.5X120	TATA spare parts
11342596039	SCREW M12X1.5X50-10.9	TATA spare parts
11342599011	COLLAR SCREW M14X1.5X95	TATA spare parts
11342708201	SCREW M8X20 8.8 TS17215 SS8451S2-Y	TATA spare parts
11343505100	HEX FL SCR M5X10 TS17130-8.8-SS8451S2-Y	TATA spare parts
11343505169	HEX FL SCR M5X16 TS17130-8.8-SS8451S2-Y	TATA spare parts
11343506084	H/FL SCREW M6X8 TS17130-8.8-SS8451S2	TATA spare parts
11343506122	HEX FL SCR M6X12 TS17130-8.8-SS8451S2-Y	TATA spare parts
11343506149	H/FL SCREW M6X14 TS17130-8.8-SS8451S2-Y	TATA spare parts
11343506181	HEX FL SCR M6X18 TS17130-8.8-SS8451S2-Y	TATA spare parts
11343506203	H/FL SCREW M6X20 TS17130 8.8 SS8451S2-Y	TATA spare parts
11343506220	H/FL SCREW M6X22 TS17130 8.8 SS8451S2-Y	TATA spare parts
11343506408	HEX FL SCR M6X40 TS17130-8.8-SS8451S2-Y	TATA spare parts
11343508125	H/FL SCREW M8X12 TS17130-8.8-SS8451S2-Y	TATA spare parts
11343508141	HEX FL SCR M8X14 TS17130 8.8 SS8451S2	TATA spare parts
11343508168	H/FL SCREW M8X16 TS17130-8.8-SS8451S2-Y	TATA spare parts
11343508184	H/FL SCREW M8X18 TS17130-8.8-SS8451S2-Y	TATA spare parts
11343508206	HEX FL SCR M8X20 TS17130-8.8-SS8451S2-Y	TATA spare parts
11343508222	H/FL SCREW M8X22 TS17130 8.8 SS8451S2-Y	TATA spare parts
11343508257	H/FL SCREW M8X25 TS17130 8.8 SS8451S2-Y	TATA spare parts
11343508303	H/FL SCREW M8X30 TS17130 8.8 SS8451S2-Y	TATA spare parts
11343508605	HEX FL SCR M8X60 TS17130 8.8 SS8451S2-Y	TATA spare parts
11343510146	HEX FL SCR M10X14 TS17130-8.8-SS8451S2-Y	TATA spare parts

11343510201	HEX FL SCR M10X20 TS17130-8.8-SS8451S2-	TATA spare parts
11343510286	HEX FL SCR M10X28 TS17130 8.8 SS8451S2-Y	TATA spare parts
11343510308	H/FL SCREW M10X30 TS17130 8.8SS8451S2-Y	TATA spare parts
11343510359	H/FL SCREW M10X35 TS17130 8.8SS8451S2-Y	TATA spare parts
11343512254	HEX FL SCR M12X25 TS17130 8.8 SS8451S2-Y	TATA spare parts
11343512289	HEX FL SCR M12X28 TS17130-8.8-SS8451S2-Y	TATA spare parts
11343512301	H/FL SCR M12X30 TS17130-8.8-SS8451S2-Y	TATA spare parts
11343512386	HEX FL SCR M12X38 TS17130-8.8-SS8451S2-Y	TATA spare parts
11343596041	HEX FL SCR M6X16 TS17130-8.8-SS8451S2-B	TATA spare parts
11343596075	HEX FL SCR M8X20 TS17130-8.8-SS8451S2-B	TATA spare parts
11343596083	HEX FL SCR M8X16 TS17130-8.8-SS8451S2-B	TATA spare parts
11343596113	HEX FL SCR M8X40 TS17130-8.8-SS8451S2-B	TATA spare parts
11343596121	HEX FL SCR M6X20 TS17130-8.8-SS8451S2-B	TATA spare parts
11343596130	HEX FL SCR M8X35 TS17130-8.8-SS8451S2-B	TATA spare parts
11343610256	FL SCR M10X1.25X25 TS17130 8.8SS8451S2-Y	TATA spare parts
11343610353	FL SCR M10X1.25X35 TS17130 8.8SS8451S2-Y	TATA spare parts
11343612259	H/FL SCR M12X1.5X25TS17130 8.8SS8451S2-Y	TATA spare parts
11343612283	H/FL SCR M12X1.5X28TS17130 8.8SS8451S2-Y	TATA spare parts
11343612305	H/FL SCR M12X1.5X30TS17130 8.8SS8451S2-Y	TATA spare parts
11343612551	H/FL SCR M12X1.5X55TS17130 8.8SS8451S2-Y	TATA spare parts
11343696029	FL SCR M12X1.25X30 TS17130 BS6-PH2	TATA spare parts
11343696037	FL SCR M12X1.25X28 TS17130 8.8SS8451S2-Y	TATA spare parts
11343696045	FL SCR M12X1.25X42 TS17130 8.8SS8451S2-Y	TATA spare parts
11343706148	HEX FL SCR.M6X14 TS17130-10.9 SS8451S2-Y	TATA spare parts
11343706164	H/FL SCR M6X16 TS17130-10.9-SS8451S2-YH	TATA spare parts
11343706202	H/FL SCR M6X20-TS17130	TATA spare parts
11343706300	HEX FL SCR M6X30 TS17130-10.9SS8451S2-YH	TATA spare parts
11343706351	H/FL BOLT M6X35 TS17130 10.9SS8451S2-YH	TATA spare parts
11343708167	HEX FL.SCR.M8X16 TS17130 10.9SS8451S2-Y	TATA spare parts
11343708183	HEXFLSCRM8X18TS1713010.9SS8451S2-YH BS6	TATA spare parts
11343708205	H/FL SCREW M8X20TS17130 10.9SS8451S2-YH	TATA spare parts
11343708221	HEX FL SCR. M8X22TS17130 10.9SS8451S2-YH	TATA spare parts
11343708221_niu1	HEX FL SCR. M8X22TS17130 10.9SS8451S2-Y	TATA spare parts
11343708302	H/FL SCR M8X30 TS17130-10.9-SS8451S2-YH	TATA spare parts
11343708302_niu1	H/FL SCR M8X30 TS17130-10.9-SS8451S2-YH	TATA spare parts
11343708353	HEX FL SCR M8X35 TS17130 10.9SS8451S2-YH	TATA spare parts
11343708507	HEX FL SCR M8X50 TS17130 10.9SS8451S2-YH	TATA spare parts
11343708558	HEX FL SCR M8X55 TS17130 10.9SS8451S2-YH	TATA spare parts
11343710200	H/FL SCR M10X20 TS17130-10.9SS8451S2	TATA spare parts
11343710251	H/FL SCR M10X25 TS17130-10.9SS8451S2-YH	TATA spare parts
11343710285	H/FL SCR M10X28 TS17130 10.9 SS8451S2-YH	TATA spare parts
11343710307	H/FL SCR M10X30 TS17130 10.9SS8451S2-YH	TATA spare parts
11343710358	HEX FL SCR M10X35 TS17130 10.9SS8451S2-Y	TATA spare parts
11343710404	H/FL SCR M10X40-TS17130-10.9-SS8451S2-YH	TATA spare parts
11343712300	H/FL SCR M12X30 TS17130 10.9 SS8451S2-YH	TATA spare parts
11343716356	H/FL SCR M16X35 TS17130 10.9 SS8451S2-YH	TATA spare parts
11343812452	FLSCR M12X1.5X45 TS17130 10.9SS8451S2-Y	TATA spare parts

11343812614	FLSCR M12X1.5X65 TS17130 10.9SS8451S2-YH	TATA spare parts
11344508200	HEX FL SCREW M8X20 TS17070-8.8-SS8451-8C	TATA spare parts
11345506103	HEX FL SCR M6X10 TS17070-8.8-SS8451S2-Y	TATA spare parts
11345506120	HEX FL SCREW M6X12 TS17070-8.8SS8451S2	TATA spare parts
11345506146	HEX FL SCREW M6X14 TS17070-8.8SS8451S2-Y	TATA spare parts
11345506162	HEX FL SCREW M6X16 TS17070-8.8-SS8451S2-	TATA spare parts
11345506189	HEX FL SCREW M6X18 TS17070-8.8 SS8451S2-	TATA spare parts
11345506201	HEX FL SCREW M6X20 TS17070-8.8SS8451S2-Y	TATA spare parts
11345508181	HEX FL SCREW M8X18 TS17070-8.8SS8451S2-Y	TATA spare parts
11345508203	HEX FL SCR M8X20 BS6-PH2	TATA spare parts
11345508220	HEX FL SCR M8X22 TS17070-8.8-SS8451S2-Y	TATA spare parts
11345508254	HEX FL SCREW M8X25 TS17070 8.8SS8451S2-Y	TATA spare parts
11345508301	HEX FL SCREW M8X30 BS6-PH2	TATA spare parts
11345510259	HEX FL SCR M10X25 TS17070-8.8-SS8451S2-Y	TATA spare parts
11345510305	HEX FL SCR M10X30 TS 17070-8.8	TATA spare parts
11345596013	HEX FL SCR M8X25 TS17070 8.8 SS8451S2-B	TATA spare parts
11345708253	HEX FL SCREW M8X25TS17070 SS8451S2-YH	TATA spare parts
11346514401	HEX FL SCR M14X40 TS17130-8.8-SS8457-A B	TATA spare parts
11347508308	H/FL SCR M8X30 TS17130 8.8 SS8457S1-S-B	TATA spare parts
11347508359	HEX FL BOLT M8X40 TS17130-8.8-SS8451-8C	TATA spare parts
11347510353	H/FL SCR M10X35 TS17130 8.8SS8457S1-S-B	TATA spare parts
11347512305	H/FL SCR M12X30 BS6-PH2	TATA spare parts
11347596002	H/FL SCR M12X20 TS17130 8.8SS8457S1-BL-B	TATA spare parts
11347596029	H/FL SCR M6X10 TS17130-8.8-SS8457S1-BS6-	TATA spare parts
11347596037	H/FL SCR M6X12 TS17130-8.8-SS8457S1-BL-A	TATA spare parts
11347596045	H/FL SCR M6X16 TS17130-8.8-SS8457S1-BL-B	TATA spare parts
11347596053	H/FL SCR M6X22 TS17130-8.8-SS8457S1-BL-B	TATA spare parts
11347596061	H/FL SCR M8X18 TS17130-8.8-SS8457S1-BL-B	TATA spare parts
11347596070	H/FL SCR M8X20 TS17130-8.8-SS8457S1-BL-B	TATA spare parts
11347596088	H/FL SCR M6X14 TS17130 8.8 SS8457S1-BL-B	TATA spare parts
11347596096	H/ FL SCR M10X28TS17130 8.8SS8457S1-BL-B	TATA spare parts
11347596134	H/FL SCR M8X30 TS17130 8.8 SS8457S1-BL-B	TATA spare parts
11347596142	H/FL SCR M6X20 TS17130 8.8 SS8457S1-BL-B	TATA spare parts
11347596151	H/FL SCR. M6X25TS17130 8.8 SS8457S1-BL-B	TATA spare parts
11347596291	H/ FL SCR M8X20 TS17130-8.8-SS8457S1-S-B	TATA spare parts
11347596312	H/FL SCR M6X12 TS17130-8.8-SS8457S1	TATA spare parts
11347596339	H/FLSCR M10X18 TS17130-8.8 BS6-PH2	TATA spare parts
11347596363	HEX FL SCR M12X45TS17130 8.8SS8457S1-S-C	TATA spare parts
11347596398	H/FL SCR M8X16 TS17130-8.8-SS8457S1-S-B	TATA spare parts
11347596428	HEX FL SCR M6X14 TS17130-8.8SS8457S1-S-B	TATA spare parts
11347596436	H/FL SCR M6X10 TS17130-8.8-SS8457S1-S-B	TATA spare parts
11347596452	H/FL SCR M8X25 TS17130 8.8 SS8457S1-BL-B	TATA spare parts
11347596461	FL SCR M10X22 TS17130-8.8-SS8457S1-BL-B	TATA spare parts
11347596479	H/FL SCR M8X16 TS17130-8.8-SS8457S1-BL-B	TATA spare parts
11347596487	H/FL SCR M10X25 TS17130 8.8SS8457S1-BL-B	TATA spare parts
11347596495	H/FL SCR M12X28 BS6-PH2	TATA spare parts
11347596509	H/FL SCR M12X40 TS17130 8.8SS8457S1-BL-B	TATA spare parts

11347596517	H/FL SCR M10X30BS	TATA spare parts
11347596541	SCR M10X1.5X14 TS171308.8SS8457S1-BL-B	TATA spare parts
11347596550	HX FL SCR M6X40 TS17130-8.8SS8457S1-BL-B	TATA spare parts
11347596584	HX FL SCR M6X30 TS17130 8.8SS8457S1-BL-B	TATA spare parts
11347796010	FL SCR M10X25 TS17130-10.9SS8457S1-BL-B	TATA spare parts
11347796036	H/FL.SCR.M8X16 BS6-PH2	TATA spare parts
11347796044	H/FL SCR M8X25 TS17130-10.9SS8457S1-BL-B	TATA spare parts
11347796052	FL SCR M12X25 TS17130-10.9 SS8457S1-BL-C	TATA spare parts
11347796061	FL SCR M12X30 TS17130-10.9 SS8457S1-BL-C	TATA spare parts
11347796079	FL SCR M12X35 TS17130-10.9 SS8457S1-BL-C	TATA spare parts
11347796087	COLLAR SCR M12X40TS17215 10.9SS8451S2-BH	TATA spare parts
11347796125	FL SCR M10X25 TS17130-10.9 SS8457S1-BL-C	TATA spare parts
11347796133	FLSCRM10X30TS17130-10.9SS8457S1-BL-CBS6	TATA spare parts
11347796141	FL SCR M10X35 TS17130-10.9 SS8457S1-BL-C	TATA spare parts
11347796150	FL SCR M10X40 TS17130-10.9 SS8457S1-BL-C	TATA spare parts
11347796257	H/FL SCR M8X45 TS17130 10.9SS8457S1-BL-B	TATA spare parts
11347796273	H/FL SCR M8X30 BS6-PH2	TATA spare parts
11347896014	SCR M12X1.5X35 TS17130 10.9SS8457S1-BL-B	TATA spare parts
11349196001	HX FL SCR M6X10 TS17070 8.8SS8457S1-BL-B	TATA spare parts
11349402108	COLLAR SCREW	TATA spare parts
113801	SHIFT FORK SHAFT ASY	TATA spare parts
11381004106	SL CSK SCREW M4 X 10	TATA spare parts
11381004165	SL CSK SCREW M4X16 IS1365-4.8-SS8451-8C	TATA spare parts
11381005129	SL CSK SCREW M5X12	TATA spare parts
11381006125	SL CSK SCR M6X12 IS1365-4.8 SS8451S2-Y	TATA spare parts
11381006141	SL CSK SCREW M6 X 14	TATA spare parts
11381006168	SL CSK SCREW M6 X 16	TATA spare parts
11381006206	SL CSK SCREW M6 X 20	TATA spare parts
11381006303	SL CSK SCREW M6 X 30	TATA spare parts
11381008250	SL CSK SCREW M8 X 25	TATA spare parts
11381008357	SL CSK SCREW M8 X 35	TATA spare parts
11381010165	SCREW AM10X16	TATA spare parts
11381010181	SCREW AM10X18	TATA spare parts
11381010254	SL CSK SCREW M10X25 IS 1365 4-8 SS8451 8	TATA spare parts
11381010408	SCREW AM10 X 40	TATA spare parts
11381099069	SCREW AM10 X 22	TATA spare parts
11384304120	RSD CSK SCREW M4 X 12	TATA spare parts
11384304127	RSD CSK SCREW M4 X 12	TATA spare parts
11384305352	RSD CSK SCREW M5 X 35	TATA spare parts
11384306162	RSD CSK SCREW M6 X 16	TATA spare parts
11384306201	RSD CSK SCREW M6 X 20	TATA spare parts
11384308301	RSD CSK SCREW M8X30 IS8911 4.8 SS8451-8C	TATA spare parts
11384310208	SCREW AM10 X 20	TATA spare parts
11384398032	CSK SCREW M8X 16	TATA spare parts
11384398075	RSD CSK SCR M6X16-IS8911-4.8-SS8451-13D	TATA spare parts
11385605104	CR CSK SCREW M5X10 IS7485 SS8451	TATA spare parts
11385605121	CR CSK SCR M5X12 IS7485 SS8451S2-Y	TATA spare parts

11385605163	CR CSK SCREW M5X16 IS7485 SS8451-8C BS6	TATA spare parts
11385606101	CR CSK SCREW M6X10 IS7485 SS8451-8C	TATA spare parts
11385606127	CR CSK SCR M6X12 IS7485 SS8451S2-Y	TATA spare parts
11385606160	CR CSK SCR M6X16 IS7485 SS8451S2-Y	TATA spare parts
11385606208	CR CSK SCREW M6X20 IS7485 SS8451-8C	TATA spare parts
11385606259	CR CSK SCREW M6X25 IS7485 SS8451-8C	TATA spare parts
11385608201	CR CSK SCREW M8X20 IS7485 SS8451-8C	TATA spare parts
11385608251	CR CSK SCREW M8X25 IS7485 SS8451-8C	TATA spare parts
11385698013	CR CSK SCREW M3X50	TATA spare parts
11385698129	CR CSK SCREW M6X14 IS7485 SS8451-8C	TATA spare parts
11385708256	RD CSK SCR M8X25-48-H- JISB1111SS845 BS6	TATA spare parts
11385806126	RD CSKSCR M6X12-4.8-H-JISB1111SS8451S2-Y	TATA spare parts
11385806169	RD CSKSCR M6X16-4.8-H-JISB1111SS8451S2-Y	TATA spare parts
11385896010	RD CSKSCR M6X20	TATA spare parts
11385896028	RD CSKSCR M6X20-4.8-H-JISB1111SS8451S2-S	TATA spare parts
11385906201	CR CSK SCREW M6X20 IS7485 SS8451S2-Y	TATA spare parts
11385996022	CR CSK SCREW M6X20 IS7485 SS8451S2-B BS6	TATA spare parts
113866	OIL SEAL & RETAINER	TATA spare parts
11387196015	CR CSK SCR M6X16 IS7485 SS8457S1	TATA spare parts
11387196023	CR SCK SCR M6X10 IS7485 SS8457S1-BL-B	TATA spare parts
11387196031	CR CSK SCR M6X25 IS7485 SS8457S1 BS6-PH2	TATA spare parts
11387196040	CR CSK SCREW M6X20 IS7485 SS8457S1-BL-B	TATA spare parts
11387196074	CR CSK SCR M5X12 IS7485 SS8457S1	TATA spare parts
11387196082	CR CSK SCR M6X13 IS7485 SS8457S1-BL-B BS	TATA spare parts
11387506162	CSK SOC SCREW M6 X 16	TATA spare parts
11387596013	CSK SOC SCR M8X20 IS6761 12.9 SS8451-8CH	TATA spare parts
11387596048	CSK SOC SCR M8X25 IS6761 12.9 SS8451-8C	TATA spare parts
11387596129	CSK SOC SCR.M6X30 IS6761 12.9 SS8451-8CH	TATA spare parts
11387596137	CSK SOC SCR.M6X20 IS6761 12.9 SS8451-8CH	TATA spare parts
11388008255	CSK SOC SCR M8X25IS6761 12.9 SS8451S2-Y	TATA spare parts
11388508207	CSK SOC SCREW M8X20	TATA spare parts
11388596025	CSK SCR M6X45 IS6761 12.9 SS8457S1-BL-B	TATA spare parts
11388596033	CSK SCR M6X30 IS6761 12.9 SS8457S1-BL-B	TATA spare parts
11388596041	CSK SCR M6X20 IS6761 12.9SS8457S1-BL-B	TATA spare parts
11388596050	CSKSOC SCR M8X25IS6761 12.9SS8457S1	TATA spare parts
11390804069	SL CH HD SCREW M4 X 6	TATA spare parts
11390804085	SL CH HD SCREW M4 X 8	TATA spare parts
11390804107	SL CH HD SCREW M4 X 10	TATA spare parts
11390804123	SL CH HD SCREW M4 X 12	TATA spare parts
11390804204	SL CH HD SCREW M4 X 20	TATA spare parts
11390804255	SCREW AM 4X25	TATA spare parts
11390804301	SL CH HD SCREW M4 X 30	TATA spare parts
11390805081	SL CH HD SCREW M5 X 8	TATA spare parts
11390805120	SL CH HD SCREW M5 X 12	TATA spare parts
11390805162	SL CH HD SCREW M5 X 16	TATA spare parts
11390805201	SL CH HD SCREW M5 X 20	TATA spare parts
11390806126	SL CH HD SCREW M6 X 12	TATA spare parts



11390806169	SL CH HD SCREW M6 X 16	TATA spare parts
11390806185	SL CH HD SCREW M6 X 18	TATA spare parts
11390806207	SL CH HD SCREW M6 X 20	TATA spare parts
11390806258	SL CH HD SCREW M6 X 25	TATA spare parts
11390899019	SL CH SCREW M4X12 IS1366-BRASS	TATA spare parts
114012580001	FRONT FRP ASSEMBLY	TATA spare parts
114012590001	FRONT GRILL	TATA spare parts
114012600001	FRONT FRP ASSEMBLY	TATA spare parts
114012610001	FRONT FRP ASSEMBLY	TATA spare parts
114012880001	FRONT FRP ASSEMBLY	TATA spare parts
114012890001	FRP FRONT COMPL	TATA spare parts
114013100001	FRP FRONT OUTER SINGLE SKIN AGILE L.R	TATA spare parts
114013300001	FRONT FRP ASSEMBLY -AGILE HR	TATA spare parts
114013310001	FRP FRONT COMPL	TATA spare parts
114013350001	FRONT FRP ASSEMBLY BS6	TATA spare parts
114015500001	FRP FRONT PANEL	TATA spare parts
114015570001	FRONT FLAP ASSY	TATA spare parts
114015680001	TRUSS BAR	TATA spare parts
114015790001	HINGE ASSY.	TATA spare parts
114015800001	FRP FLAP COMPLETE (REAR E	TATA spare parts
114015830001	FRONT GRILL ASSY	TATA spare parts
114020330001	TWIN SPINDLE KIT(CD 64)+SPACER	TATA spare parts
11402033CF	WHEEL BOX (WIPER) (CD 64)	TATA spare parts
11402034CF	WHEEL BOX (WIPER) (CD 50)	TATA spare parts
11402038SF	WHEEL BOX (50.8)TELCO STD ITM.	TATA spare parts
11402078SF	WHEEL BOX (43.0)(MODIFIED)	TATA spare parts
114022200001	FRONT GRILL ASSY	TATA spare parts
114022980001	FRP FRONT COMPL(COMF.2570 HIGH ROOF)	TATA spare parts
114023090001	GRILL	TATA spare parts
114023100001	FRONT LAMP PANEL LH	TATA spare parts
114023110001	FRONT LAMP PANEL RH	TATA spare parts
114023700001	FRP FRONT PANEL FOR COMFORT MODEL	TATA spare parts
114023710001	FRP FRONT FLAP FOR COMFORT MODEL	TATA spare parts
114023720001	FRP FRONT GRILL FOR COMFORT MODEL	TATA spare parts
114024160001	FRP FRONT FLAP COMPLETE-COMFORT2500	TATA spare parts
114024180001	FRP FRONT FIN-COMFORT2500	TATA spare parts
114024320001	FRP FRONT GRILL FOR NIGERIA	TATA spare parts
114024650001	FRONT FRP FLAP	TATA spare parts
114025730001	WIRE MESH OF COMFORT 2570 GRILL	TATA spare parts
114026130001	F.R.P FRONT GRILL	TATA spare parts
114026180001	WHEEL BOX+SPACER	TATA spare parts
114026230001	FRP FRONT PANEL	TATA spare parts
114026550001	F.R.P FRONT PANEL	TATA spare parts
114027370001	FRP FRONT FLAP	TATA spare parts
114027380001	FRP FRONT PANEL	TATA spare parts
114027390001	FRP FRONT PANEL (HR) BS6	TATA spare parts
114027690001	FRP FRONT COMPLETE	TATA spare parts

114027940001	STAY ROD ASSEMBLY	TATA spare parts
114027950001	FRONT FLAP BS6	TATA spare parts
114030010001	FRONT FLAP ASSY	TATA spare parts
114030400001	FRP FRONT FIN FOR COMFORT MODEL	TATA spare parts
114031400001	FRP FRONT PANEL (HR) BS6	TATA spare parts
11404028FN	INSPECTION LID/FRONT FOR 6HD	TATA spare parts
11404045FN	CAB COMPLT RHD SLEEPER	TATA spare parts
11404061FN	CAB COMPLT RHD SLEEPER	TATA spare parts
11404063FN	CAB COMPLT RHD SLEEPER	TATA spare parts
11404064FN	CAB COMPLT RHD SLEEPER	TATA spare parts
11405603171	CR PAN HD SCREW M3X16 IS7483 SS8451-8C	TATA spare parts
11405603308	CR PAN HD SCREW M3X30 IS7483 BS6-PH2	TATA spare parts
11405604088	SCREW M 4X8	TATA spare parts
11405604100	CR PAN HD SCREW M4X10 IS7483 SS8451-8C	TATA spare parts
11405604126	CR PAN HD SCREW M4X12 IS7483 SS8451-8C	TATA spare parts
11405604169	CR PAN HD SCREW M4X16 IS7483 SS8451-8C	TATA spare parts
11405604207	CR PAN HD SCREW M4X20 IS7483 SS8451-8C	TATA spare parts
11405604258	CR PAN HD SCREW M4X25 IS7483 SS8451-8C BS6	TATA spare parts
11405605084	CR PAN HD SCREW M5X8 IS7483 SS8451	TATA spare parts
11405605106	CR PAN HD SCREW M 5 X 10	TATA spare parts
11405605122	CR PAN HD SCREW M5X12 IS7483 SS8451-8C	TATA spare parts
11405605165	CR PAN HD SCREW M5X16	TATA spare parts
11405605203	CR PAN HD SCREW M5X20	TATA spare parts
11405605254	CR PAN HD SCREW M5X25 IS7483 SS8451S2-Y	TATA spare parts
11405606102	CR PAN HD SCREW M6X10	TATA spare parts
11405606129	CR PAN HD SCREW M6X12 IS7483 SS8451-8C	TATA spare parts
11405606161	CR PAN HD SCREW M6X16 IS7483 SS8451-8C	TATA spare parts
11405606200	SCREW	TATA spare parts
11405606251	CR PAN HD SCREW M6X25 IS7483 SS8451-8C	TATA spare parts
11405606307	CR PAN HD SCREW M6X30 IS7483 SS8451-8C B	TATA spare parts
11405606404	CR PAN HD SCREW M6X40 IS7483 SS8451-8C	TATA spare parts
11405606501	CR PAN HD SCREW M6X50 IS7483 SS8451-8C	TATA spare parts
11405608164	CR PAN HD SCREW M8X16 IS7483 SS8451S2-Y	TATA spare parts
11405608202	CR PAN HD SCREW M8X20	TATA spare parts
11405608300	CR PAN HD SCREW M8X30	TATA spare parts
11405608407	CR PAN HD SCREW M8X40 IS7483 SS8451-8C	TATA spare parts
11405608601	CR PAN HD SCREW M8X60	TATA spare parts
11405698066	CR PAN HD SCREW M6 X 25 IS7483 SS8451-13	TATA spare parts
11405698091	CR PAN HD SCREW M6X14 IS7483 SS8451-8C	TATA spare parts
11405698104	CR PAN HD SCREW M6X44 IS7483 SS8451-8C	TATA spare parts
11405698139	CR PAN HD SCREW M6X16 IS7483	TATA spare parts
11405698147	PAN HD SCREW M6X16	TATA spare parts
11405698163	CR PAN HD SCREW M6X35 IS7483 SS8451-8C	TATA spare parts
11405698171	CR PAN HD SCREW M6X28 IS7483 SS8451-8C	TATA spare parts
11405698180	CR PAN HD SCREW M6X18 IS7483 SS8451-8	TATA spare parts
11405698198	CR PAN HD SCREW M6X20 IS7483 SS8451-13D	TATA spare parts
11405698201	CR PAN HD SCREW M5X18 IS7483 SS8451-8C	TATA spare parts

11405698325	CR PAN HD SCR M6X25 IS7483 A2-50ST.STEE	TATA spare parts
11405698341	CR PAN HD SCR M6X12 IS7483 A2-50ST.STEE	TATA spare parts
11406703128	CR PAN HD SCR M3X12 IS7483 SS8451S2-Y BS	TATA spare parts
11406704108	CR PAN HD SCREW M4X10 IS7483 SS8451S2-Y	TATA spare parts
11406704124	CR PAN HD SCREW M4X12 IS7483 SS8451S2-Y	TATA spare parts
11406705104	CR PAN HD SCREW M5X10 IS7483 SS8451S2-Y	TATA spare parts
11406705121	CR PAN HD SCREW M5X12 IS7483 SS8451S2-Y	TATA spare parts
11406705163	CR PAN HD SCREW M5X16 IS7483 SS8451S2-Y	TATA spare parts
11406705201	CR PAN HD SCREW M5X20 IS7483-SS8451S2	TATA spare parts
11406705252	CR PAN HD SCREW M5X25 IS7483 SS8451S2-Y	TATA spare parts
11406706101	CR PAN SCR M6X20 4.8H JISB1111 SS8451-8C	TATA spare parts
11406706127	CR PAN HD SCREW M6X12 IS7483 SS8451S2-Y	TATA spare parts
11406706143	CR PAN HD SCREW M6X14 IS7483 BS6	TATA spare parts
11406706186	CR PAN HD SCREW M6X18 IS7483 SS8451S2-Y	TATA spare parts
11406706208	CR PAN HD SCREW M6X20 IS7483 SS8451S2-Y	TATA spare parts
11406706259	CR PAN HD SCREW M6X25 IS7483 SS8451S2-Y	TATA spare parts
11406706305	CR PAN HD SCREW M6X30 IS7483 SS8451S2-Y	TATA spare parts
11406706356	CR PAN HD SCREW M6X35 IS7483 SS8451S2-Y	TATA spare parts
11406796011	CR PAN HD SCREW M6X16 IS7483 SS8451S2-B	TATA spare parts
11406796037	CR PAN HD SCREW M6X25	TATA spare parts
11406796070	CR PAN HD SCR M6 X14	TATA spare parts
11407396016	CR PAN HD SCR M6X12 IS7483 SS8457S1	TATA spare parts
11407396032	CR PAN HD SCR M6X16 IS7483 SS8457S1-BL-B	TATA spare parts
11407396059	PAN HD SCR M10X75 IS7483 SS8457S1-BL-B	TATA spare parts
11407396083	CR PAN HD SCR M6X10 IS7483 SS8457S1-BL-B	TATA spare parts
11407396211	CR PAN HD SCR M6X25 IS7483 SS8457S1-S-B	TATA spare parts
11407396237	CR PAN HD SCR M6X35 IS7483 SS8457S1-BL-B	TATA spare parts
11407396270	CR PAN HD SCR M5X12 IS7483 SS8457S1-BL-B	TATA spare parts
11407396288	CR PAN HD SCR M6X25 IS7483 SS8457S1-BL-B	TATA spare parts
11407396296	CR PAN HD SCR M6X20 IS7483 SS8457S1-BL-B	TATA spare parts
11407396300	CR PAN HD SCR M6X43 IS7483 SS8457S1-BL-B	TATA spare parts
11407396385	CR PAN HD SCR M6X14 IS7483 SS8457S1-BL-B	TATA spare parts
11407604204	CR PAN HD SCREW M4X20 TS17070-SS8451-8C	TATA spare parts
11411405101	CAP SCREW M5X10 IS2269-12.9 SS9400 BS6	TATA spare parts
11411405160	CAP SCREW M5X16 IS2269-12.9 SS9400	TATA spare parts
11411406085	CAP SCREW M6X8 IS 2269 12.9 SS 9400	TATA spare parts
11411406123	CAP SCREW M6 X 12	TATA spare parts
11411406166	CAP SCREW M6X16 IS2269-12.9 SS9400	TATA spare parts
11411406182	CAP SCREW M6X18 IS2269 12.9 SS9400	TATA spare parts
11411406204	CAP SCREW M6 X 20	TATA spare parts
11411406255	CAP SCREW M6X25 IS2269-12.9 SS9400	TATA spare parts
11411406301	CAP SCREW M6X30 IS2269-12.9	TATA spare parts
11411406352	CAP SCREW M6 X 35	TATA spare parts
11411406409	CAP SCREW M6X40	TATA spare parts
11411406450	CAP SCREW M6X45	TATA spare parts
11411406506	CAP SCREW M6X50 IS2269-12.9 SS9400	TATA spare parts
11411408169	CAP SCREW M8X16 IS2269-12.9-SS9400	TATA spare parts

11411408207	CAP SCREW M8 X 20	TATA spare parts
11411408223	CAP SCREW M8 X 22	TATA spare parts
11411408258	CAP SCREW M8X25 IS2269-12.9-SS9400	TATA spare parts
11411408304	CAP SCREW M8X30	TATA spare parts
11411408355	..CAP SCREW M8X35 IS2269-12.9-SS9400	TATA spare parts
11411408509	CAP SCREW M8X50 IS2269 12.9 SS8451-8CH	TATA spare parts
11411408550	CAP SCREW M8X55 IS2269 12.9 SS9400	TATA spare parts
11411408631	CAP SCREW M8X75 IS2269 12.9 SS9400	TATA spare parts
11411408681	CAP SCREW M8 X 110	TATA spare parts
11411410252	CAP SCREW M10 X 25	TATA spare parts
11411410309	CAP SCREW M10 X 30	TATA spare parts
11411410350	CAP SCREW M10 X 35	TATA spare parts
11411410503	CAP SCREW M10X50 IS2269 12.9 SS8451-8CH	TATA spare parts
11411410601	CAP SCREW M10X60 IS2269 12.9 SS9400	TATA spare parts
11411412352	CAP SCREW M12X35-IS2269-12.9-SS9400	TATA spare parts
11411414550	CAP SCREW M 14X55	TATA spare parts
11411512403	CAP SCREW M12X1.25X40 IS2269 12.9 SS9400	TATA spare parts
11411612700	SCREW M12 X 130	TATA spare parts
11411808256	CAP SCREW M8 X 25	TATA spare parts
11412506121	THIN HEAD CAP SCREW M6X12 TS17216	TATA spare parts
11412506164	THIN HEAD CAP SCREW M6X16 TS17216	TATA spare parts
11412508167	THIN HEAD CAP SCREW M8X16 TS17216	TATA spare parts
11412508205	THIN HEAD CAP SCREW M8X20 - 8.8 TS17216	TATA spare parts
11412508302	THIN HEAD CAP SCREW M8X30 TS17216	TATA spare parts
11413408204	CAP SCREW M8X20 IS2269-12.9-SS8451S2-YH	TATA spare parts
11413506206	THIN HD CAP SCR M6X20 TS17216 SS8451S2-	TATA spare parts
11414406205	CAP SCREW M6X20	TATA spare parts
11415108259	CAP SCR M8X25 IS2269 10.9 SS8457S1-S-B	TATA spare parts
11415408309	CAP SCR M8X30	TATA spare parts
11419205127	CAP SCREW M5X12 TS17070-10.9-SS9400 BS6	TATA spare parts
11420101CF	HINGE ASSY (RADIATOR)	TATA spare parts
11422024SF	RUBBER BUFFER	TATA spare parts
11430806060	GRUB SCREW AM6 X 6	TATA spare parts
11430810105	GRUB SCREW AM 10X10 IS 2388	TATA spare parts
114310190001	FRP PODEST FOR COMFORT-1618 MODEL	TATA spare parts
114310230001	FRP ENGINE HOOD FOR COMFORT-1618 BUS	TATA spare parts
114310310001	FRP ENGINE HOOD FOR COMFORT-1618 BUS	TATA spare parts
114310320001	FRP PODEST FOR COMFORT-1618 MODEL	TATA spare parts
114310600001	ENGINE HOOD	TATA spare parts
114310610001	PODDEST	TATA spare parts
114310900001	FRP PODEST FOR LP 1112	TATA spare parts
114310910001	FRP ENGINEHOOD FOR LP 1112	TATA spare parts
114310930001	ENGINE HOOD	TATA spare parts
114310940001	ENGINE HOOD PODDEST	TATA spare parts
114310950001	FRP PODEST	TATA spare parts
114310960001	FRP ENGINEHOOD	TATA spare parts
114311000001	ENGINE HOOD FRP	TATA spare parts

114311010001	FRP ENGINE HOOD FOR COMFORT-1618 BUS	TATA spare parts
114311040001	FRP PODEST - LP1112	TATA spare parts
114311060001	FRP ENGINEHOOD-1613 ELANZA	TATA spare parts
114311190001	FRP ENGINEHOOD - EURO IV	TATA spare parts
114311200001	FRP PODEST - EURO IV	TATA spare parts
114311210001	FRP PODEST LP 1618/53 RHD BS6	TATA spare parts
114311220001	FRP ENGINEHOOD LP 1618/53 RHD BS6	TATA spare parts
114311300001	FRP PODEST LPO 1613/58 CNG BS6	TATA spare parts
114311310001	FRP ENGINEHOOD LPO 1613/58 CNG BS6	TATA spare parts
114311510001	FRP PODEST LPO HIRA BS6	TATA spare parts
114311520001	FRP ENGINEHOOD HIRA BS6	TATA spare parts
114320620001	BELLOW FOR ENGINE HOOD(275126807702)	TATA spare parts
114320630001	BELLOW FRAME (275126800152)	TATA spare parts
114320840001	RUBBER BELLOW	TATA spare parts
114321080001	RUBBER BELLOW	TATA spare parts
114330090001	LOCK	TATA spare parts
114330100001	CATCHER	TATA spare parts
114330220001	ENGINEHOOD SEALING BEADING(4MTR) BS6-PH2	TATA spare parts
114330220002	ENGINEHOOD SEALING BEADING (L=4MTR) BS6-	TATA spare parts
11433206101	GRUB SCREW EM6 X 10	TATA spare parts
11433208163	GRUB SCREW EM8X16-IS 2388-6.6-SS9400	TATA spare parts
114340010001	ENGIN HOOD BEADING FOR 6HD (L=5 MTR)	TATA spare parts
114340010002	BEADING FOR ENGINE HOOD (L = 4 MTR )	TATA spare parts
114340010004	BEADING FOR ENGINE HOOD	TATA spare parts
11436706148	LEVER SCREW CVA	TATA spare parts
11437506061	SET SCREW M6 X 6	TATA spare parts
11437508081	SET SCREW M8 X 8	TATA spare parts
11437508129	TS17232 IS6094 FPSS9400M8X12	TATA spare parts
11437510255	SET SCREW M10X25 IS6094 P1 SS9400	TATA spare parts
11437912167	SET SCREW M12X16 IS6094 HDP	TATA spare parts
114411120001	FRP REAR PANEL COMPLETE-COMFORT2500	TATA spare parts
114411270001	FRP REAR COMPL(COMF.2570 HIG.ROOF+DICKEY	TATA spare parts
114411580001	REAR FRP STR ASSEMBLY	TATA spare parts
114413220001	REAR FRP ASSEMBLY	TATA spare parts
114423740001	FRP REAR PANEL FOR COMFORT MODEL	TATA spare parts
114423830001	REAR FLAP ASSEMBLY	TATA spare parts
114424170001	REAR DOOR LOCK	TATA spare parts
114424270001	FRP REAR STRUCTURE COMPLETE (LP 1112)	TATA spare parts
114424420001	REAR HEADER CENTER PANEL	TATA spare parts
114424430001	REAR HEADER CORNER PANEL LH	TATA spare parts
114424440001	REAR HEADER CORNER PANEL RH	TATA spare parts
114424450001	REAR PILLAR LH	TATA spare parts
114424460001	REAR PILLAR RH	TATA spare parts
114424470001	REAR_GLASS_MOUNTING_PANEL - H/R	TATA spare parts
114424480001	REAR EMBOSSED PANEL	TATA spare parts
114424490001	REAR LAMP FENDER PANEL LH	TATA spare parts
114424500001	REAR LAMP FENDER PANEL RH	TATA spare parts

114424520001	RR PILLAR LH - H/R	TATA spare parts
114424530001	RR PILLAR RH - H/R	TATA spare parts
114424670001	REAR GLASS MOUNTING PANEL	TATA spare parts
114425080001	DRIVERS S DOOR ASSEMBLY	TATA spare parts
114425090001	REAR FRP	TATA spare parts
114425210001	REAR FRP STR ASSEMBLY	TATA spare parts
114425230001	REAR FRP ASSEMBLY	TATA spare parts
114425700001	FRP REAR STRUCT W/O DICKEY (COM HROOF 25	TATA spare parts
114425720001	FRP REAR STRUCT W/O DICKEY (COM H ROOF 2	TATA spare parts
114425750001	REAR FLAP ASSEMBLY	TATA spare parts
114425920001	REAR FLAP ASSEMBLY	TATA spare parts
114426350001	ELANZA REAR FRP	TATA spare parts
114426670001	REAR FRP PANEL	TATA spare parts
114426880001	REAR FRP PANEL	TATA spare parts
114426920001	REAR DOOR ASSY	TATA spare parts
114427130001	REAR FRP. SINGLE SKIN	TATA spare parts
114427520001	ELANZA REAR FRP	TATA spare parts
114427730001	REAR FRP SINGLE SKIN	TATA spare parts
114427750001	REAR FRP INNER SKIN	TATA spare parts
114427830001	REAR FRP SINGLE SKIN BS6	TATA spare parts
114427930001	REAR FLAP ASSEMBLY	TATA spare parts
114433940002	FRP TAIL LAMP COVER	TATA spare parts
11450604129	CR CH HD SCREW AM4 X 12	TATA spare parts
11450606121	SCREW AM6X12	TATA spare parts
11450606156	SCREW AM6X15	TATA spare parts
11451506121	SCREW AM6 X 12	TATA spare parts
114600280002	REAR INSPECTION DOOR / LH	TATA spare parts
114600290001	REAR INSP DOOR INSTL	TATA spare parts
114601000001	HINGE ASSY FOR REAR BAGGAGE	TATA spare parts
11460100CF	HINGE ASSY (REAR BAGGAGE)	TATA spare parts
11460506354	BUTTON HD SCR M6X35 ISO 7380 12.9 SS9400	TATA spare parts
11460508161	BUTTON HD SCR M8X16 ISO 7380 12.9 SS9400	TATA spare parts
114610020001	LOCK ASSY FOR FLAP	TATA spare parts
11461002SN	LOCK ASSY (REAR BAGGAGE)	TATA spare parts
11461596039	BUTTON HDSCR M10X25ISO7380 8.8SS8451S2-B	TATA spare parts
11461696017	BUT. HD SCR M6X18ISO7380 10.9SS8451S2-B	TATA spare parts
11461696033	BUT. HD SCR M6X16ISO7380 10.9SS8451S2-BH	TATA spare parts
11461696050	BUT.HDSCR M10X16 ISO7380 10.9SS8451S2-BH	TATA spare parts
11461710613	BUT.HDSCR M10X65 ISO7380 12.9SS8451S2-YH	TATA spare parts
114620700001	BUDGET LOCK	TATA spare parts
114620830001	BUDGET LOCK	TATA spare parts
11463696014	B.HD SCR M6X16 ISO7380 10.9SS8457S1-BL-B	TATA spare parts
11463696022	B.HD SCR M6X18 ISO7380 10.9SS8457S1-BL-B	TATA spare parts
11463696031	B.HDSCR M10X16 ISO7380 10.9SS8457S1-BL-B	TATA spare parts
11480304056	WRONG PART NUMBER	TATA spare parts
11480504056	HAMMER DRIVE SCR 4X4.8	TATA spare parts
11480504064	HAMMER DRIVE SCR 4X6.4 IS7519 SS8451-8C	TATA spare parts

114875930001	REAR STRUCTURE ASSEMBLY COMPLETE	TATA spare parts
11490904125	TAPPING SCREW	TATA spare parts
11491206138	TAPPING SCR C-ST3.5X13 IS7170 SS8451-8C	TATA spare parts
11491206197	TAPPING SCR C-ST3.5X19 IS7170 SS8451-8C	TATA spare parts
11491399017	TAPPING SCR C-ST4.8X25-IS7169-SS8451-13D	TATA spare parts
11491404061	TAPPING SCR C-ST2.9X6.5 IS7173-SS8451-8C	TATA spare parts
11491404096	TAPPING SCREW 2.9 X 9.5	TATA spare parts
11491406099	TAPPING SCREW 3.5 X 9.5	TATA spare parts
11491406137	TAPPING SCREW 3.5 X 13	TATA spare parts
11491408130	TAPPING SCR C-ST4.2X13 IS7173-SS8451-8C	TATA spare parts
11491408199	TAP SCREW 4.2 X 19	TATA spare parts
11491408253	TAPPING SCR C-ST42X25 IS7173 SS8451-8C	TATA spare parts
11491410169	TAPPING SCR C-ST4.8X16 IS7173 SS8451S2-Y	TATA spare parts
11491499020	TAPPING SCR C-ST4.8X25-IS	TATA spare parts
11491499054	TAPPING SCR C-ST4.2X13 IS7173 SS8451-13D	TATA spare parts
11492408192	TAPPING SCR C-ST4.2X19 TS17245	TATA spare parts
11492410197	CR PAN HD TAPPING SCR C-ST4.8X19 TS17245	TATA spare parts
11492410405	CR PAN HD TAPPING SCR C-ST4.8X40 TS17245	TATA spare parts
11492410502	CRPANHDTAPPINGSCRC-ST4.8X50TS17245 BS6	TATA spare parts
11492412220	CR PAN HD TAPPING SCR C-ST5.5X22 TS17245	TATA spare parts
11492414168	CR PAN HD TAPPING SCR C-ST6.3X16TS17245	TATA spare parts
11492482139	SCREW B3.5 X 13	TATA spare parts
11492498035	TAPSCR C-ST3.5X13TS17245-A2-50 SS8451-8C	TATA spare parts
11492498043	CR PANHD TAP SCR C-ST4.2X13TS17245-A2-50	TATA spare parts
11492498051	CR PANHD TAP SCR C-ST4.2X19TS17245-A2-5	TATA spare parts
11492498060	TAPPING SCREW C-ST 4.2X32 TS17245 ST STL	TATA spare parts
11492498213	TAP SCREW C-ST4.2X16 TS17245 SS8451-13D	TATA spare parts
11492498256	FL TAP SCR C-ST4.2X9.5	TATA spare parts
11492498264	FL TAP SCR C-ST4.2X13 TS17249SS8451S2-Y	TATA spare parts
11492498272	FL TAP SCR C-ST4.2X16 TS17249SS8451S2-Y	TATA spare parts
11492498299	PAN HD. TAP SCREW 4.2X25	TATA spare parts
11492498302	FL TAP SCR C-ST4.8X16 TS17249SS8451S2-Y	TATA spare parts
11492498311	FL TAP SCR C-ST3.5X16 TS17249SS8451S2-Y	TATA spare parts
11492498329	FL TAP SCR C-ST 3.5X13 TS17249SS8451S2-	TATA spare parts
11492498337	FL TAP SCR C-ST3.5X9.5 TS17249SS8451S2-	TATA spare parts
11492498353	FL TAP SCR C-ST4.8X16 TS17249 SS8451-13D	TATA spare parts
11492498361	CR FL PAN HD TAP SCR C-ST4.8X19 TS17249	TATA spare parts
11492498370	FL TAP SCR C-ST4.8X13 TS17249SS8451S2-Y	TATA spare parts
11492498418	CR FL PAN HD TAP SCR C-ST3.5X25 TS17249	TATA spare parts
11492498477	FL PAN HD TAP SCR C-ST4.2X16TS17249A2-5	TATA spare parts
11492498515	FL TAP SCR C-ST5.5X16	TATA spare parts
11492882161	CSK TAP SCR C-ST3.5X16 TS17246SS8451S2-Y	TATA spare parts
11492884024	CR.CSK TAPPING SCREW C-ST4.2X9.5 TS17246	TATA spare parts
11492898025	CR CSKHDTAP SCR BS6-PH2	TATA spare parts
11493206194	TAPPING SCREW ST 3.5X19	TATA spare parts
11493210221	TAP SCREW CST 4.8X22	TATA spare parts
11493282028	SCREW B3.5 X 9.5	TATA spare parts

11493282168	SCREW B3.5 X 16	TATA spare parts
11493283130	SCREW B3.5 X 13	TATA spare parts
11496404094	TAPPING SCR C-ST2.9X9.5IS7173-SS8451S2-Y	TATA spare parts
11496408138	TAPPING SCR C-ST4.2X13 IS7173-SS8451S2-	TATA spare parts
11497306096	FL TAP SCR C-ST3.5X9.5 TS17249SS8451S2-Y	TATA spare parts
11497396036	FL TAP SCR C-ST4.8X16 TS17249 SS8451S2-B	TATA spare parts
11497396087	FL TAP SCR C-ST48X32	TATA spare parts
11497396109	FL TAP SCR C-ST4.8X22	TATA spare parts
11497404136	TAP.SCR C-ST2.9X13-TS17245 SS8451S2-Y	TATA spare parts
11497410225	P/HD TAP.SCR C-ST4.8X22TS17245SS8451S2	TATA spare parts
11497410322	P/HD TAP.SCR C-ST4.8X32TS17245SS8451S2-Y	TATA spare parts
11497414166	TAP¿SCR¿C-ST6.3X16¿TS17245¿SS8451S2-Y BS	TATA spare parts
11497496057	TAP SCR C-ST4.8X22 TS17245-SS8451S2	TATA spare parts
11498496026	FL TAPSCR C-ST4.8X16TS17249SS8457S1-BL-B	TATA spare parts
11498496042	FLTAPSCR C-ST3.5X9.5TS17249SS8457S1-BL-B	TATA spare parts
11498496077	TAP SCR C-ST4.8X13 TS17249 SS8457S1-BL-B	TATA spare parts
11498496093	FL TAPSCR C-ST4.8X19TS17249SS8457S1-BL-B	TATA spare parts
11498596012	TAP SCR C-ST4.8X19 TS17245 SS8457S1-BL-	TATA spare parts
11498696017	CSKTAPSCRC-ST4.8X22TS17246SS8457S1-BL-A	TATA spare parts
114C514HN	CERAMIC FACING BUTTON	TATA spare parts
114C515HS	CERAMIC FACING BUTTON	TATA spare parts
11500930	BOLT M10 X 1.5 X 30	TATA spare parts
11501822	BOLT M10 X 1.5 X 65	TATA spare parts
115024960001	FRONT SIDE GRILL	TATA spare parts
11505328	BOLT M10X1.5X90	TATA spare parts
11512368	PIN SPRING 5 OD X 45 MM	TATA spare parts
11513011	PIN SPRING	TATA spare parts
11514354	BOLT M10 X 1.5 X 25 MM	TATA spare parts
11514355	BOLT M10 X 1.5 X 35	TATA spare parts
11515309	BOLT M6 X 1.0 X 60	TATA spare parts
11515310	BOLT M6 X 1.0 X 95	TATA spare parts
11515315	BOLT M6 X 1.0 X 20	TATA spare parts
11515316	BOLT M6 X 1.0 X 30	TATA spare parts
11515322	BOLT M8 X 1.25 X 25	TATA spare parts
11515409	BOLT M10 X 1.5 X 90	TATA spare parts
11516059	BOLT M6 X 1.0 X 45	TATA spare parts
11520506162	WING SCREW M6X16 IS3727-4.6-SS8451-8C	TATA spare parts
11542011SF000600	REINFORCEMENT/BRACKET	TATA spare parts
11630206407	STUD CM6X40 IS1862 8.8 SS8451S2-Y BS6	TATA spare parts
11630206458	STUD CM6X45 IS1862 8.8 SS8451S2-Y	TATA spare parts
11630206555	STUD CM6X55 IS1862-8.8-SS8451S2-Y	TATA spare parts
11630208639	STUD CM8X75 IS1862-8.8-SS8451S2-Y	TATA spare parts
11630208647	STUD CM8X80 IS1862 8.8 SS8451S2-Y	TATA spare parts
11630408662	STUD CM8X90 IS1862 10.9 SS8451S2-YH	TATA spare parts
11630408697	STUD CM8X120 IS1862 10.9 SS8451S2-YH	TATA spare parts
11631008358	STUD M8X35-8.8	TATA spare parts
11631208306	STUD AM8 X 30	TATA spare parts



11631210505	STUD AM10 X 50	TATA spare parts
11631210602	STUD AM10 X 60	TATA spare parts
11631296019	STUD AM10X60 TS17111S1 6.6 SS8451-8C	TATA spare parts
11631299018	STUD AM8 X 52	TATA spare parts
11631407252	STUD AM 8X30	TATA spare parts
11631407350	STUD AM8X35 IS1862 8.8 SS9400	TATA spare parts
11631407406	STUD BM8X40 IS1862 8.8 SS9400	TATA spare parts
11631407601	STUD AM8X60 IS1862 8.8 SS9400 BS6	TATA spare parts
11631407635	STUD AM8X75 IS 1862 - 8.8 - SS9400	TATA spare parts
11631408259	STUD AM10X25 IS1862 8.8 SS8451-8C	TATA spare parts
11631408305	STUD AM10 X 30	TATA spare parts
11631408356	STUD M10X35	TATA spare parts
11631408500	STUD AM10 X 60	TATA spare parts
11631408551	STUD AM10X55_IS 1862 -8.8-SS8451-8C	TATA spare parts
11631408623	STUD AM10X70 IS1862 8.8 SS8451-8C	TATA spare parts
11631408640	STUD AM10X80 IS1862 8.8 SS8451-8C	TATA spare parts
11631408691	STUD AM 10X 120	TATA spare parts
11631499017	STUD AM10 X 28	TATA spare parts
11631610309	STUD AM10X30 IS1862 10.9 SS9400	TATA spare parts
11631610406	STUD AM10 X 40	TATA spare parts
11631612301	STUD AM 12X30	TATA spare parts
11631796011	STUD AM12X1.25X40 IS1862 10.9 SS8451-8CH	TATA spare parts
11631796038	STUD AM12X1.25X100	TATA spare parts
11631796046	STUD AM12X1.25X80 IS1862 10.9 SS8451-8CH	TATA spare parts
11631796054	STUD AM12X1.25X50 IS1862 10.9 SS8451-8CH	TATA spare parts
11632406250	STUD BM6X25 IS1862 8.8 SS8451S2-Y	TATA spare parts
11632406357	STUD BM6X35 IS1862 8.8 SS9400	TATA spare parts
11632408252	STUD BM8X25 IS1862 10.9 SS9400	TATA spare parts
11632408350	STUD BM8X35	TATA spare parts
11632410257	STUD BM10X25 IS1862 8.8 SS9400	TATA spare parts
11632496011	STUD BM8X20	TATA spare parts
11632496020	STUD BM10X25	TATA spare parts
11632496038	STUD BM6 X 20	TATA spare parts
11632496054	STUD BM6X18 IS1862 8.8 SS8451S2-Y (FOR	TATA spare parts
11632496062	STUD BM8X25 IS1862 8.8 SS8451-8C	TATA spare parts
11632608201	STUD BM8X20	TATA spare parts
11632608251	STUD BM8X25 IS1862 10.9 SS9400	TATA spare parts
11632608308	STUD BM8X30 IS1862 10.9 SS8451-8CH	TATA spare parts
11632608359	STUD BM8X35 IS1862 10.9 SS9400	TATA spare parts
11632609401	STUD BM12 X 40	TATA spare parts
11632609550	STUD BM12 X 55	TATA spare parts
11632609649	STUD BM12 X 80	TATA spare parts
11632610256	STUD BM10X25 IS1862 10.9 SS9400	TATA spare parts
11632610353	STUD BM10X35	TATA spare parts
11632610400	STUD BM10X40 IS1862 10.9 SS9400	TATA spare parts
11632610507	STUD BM 10 X 50	TATA spare parts
11632610604	STUD BM 10 X 60	TATA spare parts

11632610612	STUD BM10X65	TATA spare parts
11632610621	STUD BM10X70 IS1862 10.9 SS9400 IS1863	TATA spare parts
11632610647	STUD BM 10X80	TATA spare parts
11632610671	STUD BM10X100	TATA spare parts
11632612607	STUD BM12X60 IS1862 10.9 SS8451-8CH	TATA spare parts
11632699036	STUD BM8X22 IS1862-10.9-SS9400	TATA spare parts
11632808251	STUD BM8X25	TATA spare parts
11633912400	STUD BM12X40 TS17070	TATA spare parts
11633912558	STUD BM12X55 TS17070 10.9 SS8451-8CH	TATA spare parts
11633912647	STUD BM12 X 80	TATA spare parts
11633916642	STUD BM16X80 TS17070 10.9 SS8451-8CH	TATA spare parts
11634306201	STUD CM6X20 TS17070-8.8-SS9400	TATA spare parts
11635206162	STUD CM6X16 IS1862 8.8 SS9400 (FOR MTG.	TATA spare parts
11635206189	STUD CM6X18	TATA spare parts
11635206201	STUD CM6 X 20	TATA spare parts
11635206251	STUD CM6X25 IS1862 8.8 SS9400	TATA spare parts
11635206308	STUD CM6X30 IS1862-8.8-	TATA spare parts
11635208254	STUD CM8X25 IS1862-8.8-SS8451S2-Y	TATA spare parts
11635208637	STUD CM8X75 IS1862-8.	TATA spare parts
11635208645	STUD CM8X80 IS1862 8.8 SS8451-8C	TATA spare parts
11635296013	STUD CM8X20 IS1862-8.8-SS8451S2-Y	TATA spare parts
11635296021	STUD CM8 X 30	TATA spare parts
11635298024	STUD CM8 X 68	TATA spare parts
11635408806	STUD CM8X80 IS1862-10.9 SS8451S2-YH (FOR	TATA spare parts
11635410355	STUD CM10X35 IS1862 10.9 SS8451S2-YH	TATA spare parts
11635498015	STUD CM8X32 IS1862 10.9 SS8451S2-YH	TATA spare parts
11636008356	STUD M8 X 35	TATA spare parts
11636008429	STUD M8X42 8.8 TS17112 SS8451-8C	TATA spare parts
11636010326	STUD M10X32 8.8 TS17112 SS8451-8C	TATA spare parts
11636098011	STUD M10X67 8.8 TS17112 SS8451-8C	TATA spare parts
11636098029	STUD M10X75 8.8 TS17112 SS8451-8C	TATA spare parts
11636410359	STUD AM10X35 IS1862 8.8 SS8451S2-Y	TATA spare parts
11636410669	STUD AM10X90 IS1862 8.8 SS8451S2-Y	TATA spare parts
11637408200	STUD BM8X20 IS1862-8.8-SS8451S2-Y	TATA spare parts
11637408455	STUD BM8X45 IS1862FLASE8.8 BS6-PH2	TATA spare parts
11637410255	STUD BM10X25 IS1862-8.8-SS8451S2-Y	TATA spare parts
11637606401	STUD BM6X40 IS1862	TATA spare parts
11637606559	STUD BM6X55 IS1862-10.9-SS8451S2-YH	TATA spare parts
11637608632	STUD BM8X75 IS1862 10.9 SS8451S2-YH	TATA spare parts
11638608253	STUD CM8X25 TS17070-8.8-SS8451S2-Y BS6	TATA spare parts
11638608300	STUD CM8X30 TS17070 8.8 SS8451S2-Y BS6	TATA spare parts
116935	CONNECTOR MALE	TATA spare parts
116936	ELBOW MALE	TATA spare parts
117024620001	LOCK ASSEMBLY - DARSHANA MAKE	TATA spare parts
117040240001	SKIRT PANEL LOCK MECHANISM	TATA spare parts
117040270001	SKIRT PANEL LOCK HANDLE (SINGLE)	TATA spare parts
117200970001	SKIRT PANEL COMPL.	TATA spare parts

117201350001	SKIRT PANEL COMPLETE-DRIVER STEP	TATA spare parts
117201790001	SKIRT PANEL COMPLETE	TATA spare parts
117201810001	SKIRT PANEL COMPL.	TATA spare parts
117202060001	SKIRT PANEL COMPL.	TATA spare parts
117202070001	SKIRT PANEL COMPL.	TATA spare parts
117205230004	SKIRT PANEL COMPLETE L=530	TATA spare parts
117205230006	SKIRT PANEL COMPLETE	TATA spare parts
117205330001	WHEEL SIDE COVER/FRONT	TATA spare parts
117205340001	SKIRT PANEL COMPLETE/S.T.	TATA spare parts
117213430001	SKIRT PANEL COMPL.	TATA spare parts
117213430003	SKIRT PANEL COMPLETE	TATA spare parts
117213430036	SKIRT PANEL COMPLETE	TATA spare parts
117213430039	SKIRT PANEL COMPLETE	TATA spare parts
117213450001	SKIRT PANEL COMPLETE	TATA spare parts
117213470002	SKIRT PANEL COMPLETE	TATA spare parts
117213470007	SKIRT PANEL COMPLETE L=967	TATA spare parts
117213470008	SKIRT PANEL COMPLETE L=614	TATA spare parts
117213490001	SKIRT PANEL COMPLETE	TATA spare parts
117213600006	SKIRT PANEL COMPLETE/F.T L=523	TATA spare parts
117213600009	SKIRT PANEL COMPLETE	TATA spare parts
117213600010	SKIRT PANEL COMPLETE/F.T L=978	TATA spare parts
117213600013	SKIRT PANEL COMPLETE L=1092	TATA spare parts
117213600021	WHEEL SIDE COVER /REAR	TATA spare parts
117213640002	SKIRT PANEL COMPL.	TATA spare parts
117214170001	SKIRT PANEL COMPL.	TATA spare parts
117214170002	DOOR ASSY/S.T	TATA spare parts
117214170004	SKIRT PANEL COMPL.	TATA spare parts
117214170005	SKIRT PANEL COMPL.	TATA spare parts
117214170011	SKIRT PANEL COMPLETE	TATA spare parts
117214270002	SKIRT PANEL COMPLETE	TATA spare parts
117214270003	SKIRT PANEL COMPLETE	TATA spare parts
117214270004	SKIRT PANEL COMPLETE	TATA spare parts
117214270005	SKIRT PANEL COMPLETE	TATA spare parts
117214270006	SKIRT PANEL COMPLETE	TATA spare parts
117214350001	SKIRT PANEL COMPL.	TATA spare parts
117214350002	SKIRT PANEL COMPL	TATA spare parts
117214380001	SKIRT PANEL COMPLETE	TATA spare parts
117214380002	SKIRT PANEL COMPLETE	TATA spare parts
117214520001	SKIERT PANEL COMPLETE	TATA spare parts
117214600001	SKIRT PANEL COMPLETE	TATA spare parts
117214600002	SKIRT PANEL COMPLETE	TATA spare parts
117214600011	BELLOW FRAME (275126800152)	TATA spare parts
117214600013	SKIRT PANEL COMPLETE	TATA spare parts
117214600015	SKIRT PANEL COMPL.	TATA spare parts
117214640001	TRIANGULAR PANEL	TATA spare parts
117214810001	TRIANGULAR PANEL	TATA spare parts
117216210001	SKIRT PANEL COMPLETE	TATA spare parts

117216280001	SKIRT PANEL COMPL.	TATA spare parts
117216330002	SKIRT PANEL COMPLETE	TATA spare parts
117216330003	SKIRT PANEL COMPL.	TATA spare parts
117216370002	SKIRT PANEL COMPLETE	TATA spare parts
117216520001	SKIRT PANEL COMPLETE	TATA spare parts
117216520002	SKIRT PANEL COMPL.	TATA spare parts
117216530001	SKIRT PANEL COMPL.	TATA spare parts
117216540002	SKIRT PANEL COMPL.	TATA spare parts
117216540003	SKIRT PANEL COMPL.	TATA spare parts
117216600003	SKIRT PANEL COMPLETE	TATA spare parts
117216600004	SKIRT PANEL COMPLETE	TATA spare parts
117216670001	SKIRT PANEL COMPLETE	TATA spare parts
117217640001	SKIRT PANEL COMPLETE	TATA spare parts
117218740001	SKIRT PANEL COMPL.	TATA spare parts
117218740002	SKIRT PANEL COMPL.	TATA spare parts
117218780001	SKIRT PANEL COMPLETE	TATA spare parts
117218790001	SKIRT PANEL COMPLETE	TATA spare parts
117218800001	SKIRT PANEL COMPL.	TATA spare parts
117218810001	SKIRT PANEL COMPLETE	TATA spare parts
117219040001	SKIRT PANEL COMPL.	TATA spare parts
117219170001	SKIRT PANEL COMPLETE-LOUVER	TATA spare parts
117219310001	SKIRT PANEL COMPL	TATA spare parts
117219530001	SKIRT PANEL COMPL.	TATA spare parts
117219550001	SKIRT PANEL COMPL.	TATA spare parts
117219640001	SKIRT PANEL COMPLETE	TATA spare parts
117219650001	SKIRT PANEL COMPLETE	TATA spare parts
117221250001	PLASTIC FOOT STEP COVER	TATA spare parts
117221280001	PLASTIC FOOTSTEP COVER FOR SAUDI	TATA spare parts
117221620001	PLASTIC FOOT STEP COVER	TATA spare parts
117222040001	FOOT STEP COVER	TATA spare parts
117222480001	SKIRT PANEL COMPLETE	TATA spare parts
117222700001	PLASTIC FOOT STEP COVER BS6-PH2	TATA spare parts
117249140001	SKIRT PANEL COMPLETE	TATA spare parts
117249150001	SKIRT PANEL COMPLETE	TATA spare parts
117310760001	WHEEL SIDE COVER/F- LH	TATA spare parts
117310770001	WHEEL SIDE COVER/R/ RH	TATA spare parts
117310780001	WHEEL SIDE COVER/F-RH	TATA spare parts
117317880001	SKIRT PANEL COMPLETE-F.T.	TATA spare parts
117318770001	WHEEL SIDE COVER/R	TATA spare parts
117318780001	WHEEL SIDE COVER/F	TATA spare parts
117318790001	SKIRT PANEL/W.A.	TATA spare parts
117318800001	WHEEL SIDE COVER/F	TATA spare parts
117319120001	SKIRT PANEL COMPLETE	TATA spare parts
117319130001	SKIRT PANEL COMPLETE	TATA spare parts
117319130002	SKIRT PANEL COMPLETE	TATA spare parts
117319130003	SKIRT PANEL COMPLETE	TATA spare parts
117319140001	SKIRT PANEL COMPLETE	TATA spare parts

117319150001	SKIRT PANEL COMPLETE	TATA spare parts
117319160001	WHEEL SIDE COVER /F	TATA spare parts
117319170001	DOOR ASSY. / B.B.	TATA spare parts
117319180001	SKIRT PANEL COMPLETE/FT	TATA spare parts
117319190001	DOOR ASSY. / S.T.	TATA spare parts
117319200001	WHEEL SIDE COVER /R	TATA spare parts
117319210001	SKIRT PANEL COMPLETE	TATA spare parts
117319230001	WHEEL SIDE COVER /R	TATA spare parts
117319240001	WHEEL SIDE COVER /F	TATA spare parts
117319250001	WHEEL SIDE COVER /R	TATA spare parts
117319620001	WHEEL SIDE COVER /F	TATA spare parts
117320050001	HINGE ASSY (LH SIDE)	TATA spare parts
117320060001	HINGE ASSY (RH SIDE)	TATA spare parts
117320550001	FLAP LOCK ASSY (BEND FORK)	TATA spare parts
11732055SN	FLAP LOCK ASSY	TATA spare parts
117321650001	FLAP LOCK ASSY (STRAIGHT FORK)	TATA spare parts
117322840001	WHEEL SIDE COVER / F	TATA spare parts
117322850001	WHEEL SIDE COVER/FRONT	TATA spare parts
117322860001	WHEEL SIDE COVER/REAR	TATA spare parts
117322890001	LOCK& ASSEMBLY	TATA spare parts
117323710001	WHEEL SIDE COVER/F LH	TATA spare parts
117324800001	CORNER PANEL ASSEMBLY	TATA spare parts
117324820001	WHEEL SIDE COVER	TATA spare parts
117324900001	WHEEL SIDE COVER	TATA spare parts
117331270001	WHEEL SIDE COVER/R	TATA spare parts
117332550001	WHEEL SIDE COVER/R	TATA spare parts
117332570001	WHEEL SIDE COVER ASSEMBLY	TATA spare parts
117332710001	WHEEL SIDE COVER/R	TATA spare parts
117333230001	WHEEL SIDE COVER/F.	TATA spare parts
117333290001	WHEEL SIDE COVER / F	TATA spare parts
117333300001	WHEEL SIDE COVER/FRONT	TATA spare parts
117333980001	WHEEL ARCH PANEL/R	TATA spare parts
117333990001	WHEEL SIDE COVER/R	TATA spare parts
117334260001	WHEEL SIDE COVER//FRONT	TATA spare parts
117334270001	WHEEL SIDE COVER /REAR	TATA spare parts
117334280001	WHEEL SIDE COVER//FRONT	TATA spare parts
117334290002	WHEEL SIDE COVER /FRONT	TATA spare parts
117334810001	WHEEL SIDE COVER /REAR	TATA spare parts
117334830001	WHEEL SIDE COVER /FRONT	TATA spare parts
117339100001	WHEEL SIDE COVER/F.	TATA spare parts
117339170001	WHEEL SIDE COVER ASSEMBLY	TATA spare parts
117339460001	WHEEL SIDE COVER / F	TATA spare parts
117339470001	WHEEL SIDE COVER / F	TATA spare parts
117347440001	WHEEL SIDE COVER / F	TATA spare parts
117347460001	1WHEEL SIDE COVER / R	TATA spare parts
117347940001	WHEEL SIDE COVER / F	TATA spare parts
117348320001	WHEEL SIDE COVER/FR	TATA spare parts

117348520001	WHEEL SIDE COVER/F	TATA spare parts
117348530001	WHEEL SIDE COVER/R	TATA spare parts
117348650001	WHEEL SIDE COVER/ F	TATA spare parts
117348660001	WHEEL SIDE COVER PASS	TATA spare parts
117348690001	SKIRT PANEL COMPLETE	TATA spare parts
117348810001	WHEEL SIDE COVER / R	TATA spare parts
117348900001	WHEEL SIDE PANEL COMPL./F	TATA spare parts
117348930001	WHEEL SIDE COVER/FR	TATA spare parts
117348980001	WHEEL SIDE COVER/FR	TATA spare parts
117349050001	WHEEL SIDE COVER -REAR	TATA spare parts
117349070001	WHEEL SIDE COVER ÷FRONT	TATA spare parts
117349110001	WHEEL SIDE COVER -REAR	TATA spare parts
117349190001	WHEEL SIDE COVER / R	TATA spare parts
117349230001	WHEEL SIDE COVER/F	TATA spare parts
117349240001	WHEEL SIDE COVER FRONT RH	TATA spare parts
117349260001	WHEEL SIDE COVER -FRONT	TATA spare parts
117349270001	WHEEL SIDE COVER	TATA spare parts
117349550001	WHEEL SIDE COVER	TATA spare parts
117349730001	WHEEL SIDE COVER	TATA spare parts
117349750001	WHEEL SIDE COVER REAR RH	TATA spare parts
117349760001	WHEEL SIDE COVER/FR	TATA spare parts
117349880001	WHEEL SIDE COVER PASSENGER	TATA spare parts
117349900001	WHEEL SIDE COVER / R	TATA spare parts
117349910001	WHEEL SIDE COVER / F	TATA spare parts
117359280001	WHEEL SIDE COVER / FRONT	TATA spare parts
117359290001	WHEEL SIDE COVER / FRONT	TATA spare parts
117359300001	WHEEL SIDE COVER / REAR	TATA spare parts
117400110001	FUEL TANK FLAP ASSY BS6	TATA spare parts
117400190001	FLAP ASSEMBLY	TATA spare parts
117400590001	FUEL TANK FLAP ASSEMBLY	TATA spare parts
117405860004	SKIRT PANEL COMPLETE/F.T	TATA spare parts
117405880003	SKIRT PANEL COMPLETE/F.T L=1373	TATA spare parts
117405940003	SKIRT PANEL COMPL./FT	TATA spare parts
117406460007	SKIRT PANEL COMPLETE / F.T	TATA spare parts
117406460008	SKIRT PANEL COMPL./FT	TATA spare parts
117406550002	SKIRT PANEL COMPLETE/F.T	TATA spare parts
117406610002	SKIRT PANEL COMPL./FT	TATA spare parts
117408490001	SKIRT PANEL COMPLETE/FT	TATA spare parts
117408490002	SKIRT PANEL COMPLETE/F.T L=1248	TATA spare parts
117408490004	WHEEL SIDE COVER/REAR	TATA spare parts
117408530001	SKIRT PANEL COMPL. /FT	TATA spare parts
117408560001	SKIRT PANEL COMPLETE-F.T.	TATA spare parts
117408670001	SKIRT PANEL COMPL./F.T.	TATA spare parts
117408720001	SKIRT PANEL COMPL. /FT	TATA spare parts
117410040003	SKIRT PANEL COMPLETE-FUEL TANK	TATA spare parts
117420660001	FLAP	TATA spare parts
117500660001	SKIRT PANEL COMPL.	TATA spare parts

117501290001	DOOR ASSY/ C.U	TATA spare parts
117506710002	SKIRT PANEL COMPL.	TATA spare parts
117506770001	AC LOUVER SKIRT PANEL COMPL-BIG	TATA spare parts
117506770003	SKIRT PANEL COMPLETE L=1723	TATA spare parts
117509650001	DOOR ASSY/ C.U.	TATA spare parts
117510840006	DOOR ASSEMBLY/B.B.	TATA spare parts
117510840008	DOOR ASSEMBLY	TATA spare parts
117510840013	DOOR ASSEMBLY L=968	TATA spare parts
117510840015	DOOR ASSY. / B.R.	TATA spare parts
117510840021	SKIRT PANEL COMPLETE	TATA spare parts
117511260001	SKIRT PANEL COMPLETE-S.T.	TATA spare parts
117511800010	SKIRT PANEL COMPLETE	TATA spare parts
117511840001	DOOR ASSY. / S.T.	TATA spare parts
117511840002	DOOR ASSEMBLY /S.T. L=946	TATA spare parts
117511840006	SPARE TYRE PANEL	TATA spare parts
117511840007	SKIRT PANEL COMPLETE L=1253	TATA spare parts
117511840015	DOOR ASSY. / S.T	TATA spare parts
117511860001	SKIRT DOOR ASSY/S.T L=593	TATA spare parts
117511860006	SKIRT PANEL COMPLETE	TATA spare parts
117511930001	SKIRT DOOR ASSY L=528	TATA spare parts
117511930002	SKIRT PANEL COMPLETE/B.B	TATA spare parts
117511930003	SKIRT DOOR ASSY/B.B L=1087	TATA spare parts
117512500001	DOOR ASSY. / B.B.	TATA spare parts
117512500002	BATTERY BOX PANEL	TATA spare parts
117512500003	BATTERY BOX PANEL	TATA spare parts
117512510001	DOOR ASSY/S.T	TATA spare parts
117512510004	S.T. PANEL	TATA spare parts
117514140001	DOOR ASST. / S.T.	TATA spare parts
117514250001	SKIRT PANEL COMPLETE/FT	TATA spare parts
117514250002	SKIRT PANEL COMPLETE	TATA spare parts
117514350002	SKIRT PANEL COMPL.	TATA spare parts
117514350003	SKIRT PANEL COMPL.	TATA spare parts
117514360001	SKIRT PANEL COMPL./SPARE TYRE	TATA spare parts
117514430002	SKIRT PANEL COMPLETE-SPARE TYRE	TATA spare parts
117514650001	DOOR ASST. / B.T	TATA spare parts
117514660001	DOOR ASSY. / B.T	TATA spare parts
117516440002	SKIRT PANEL COMPLETE	TATA spare parts
117516460001	DOOR ASSY/ B.B	TATA spare parts
117516460002	SKIRT PANEL COMPLETE	TATA spare parts
117516460004	SKIRT PANEL COMPLETE	TATA spare parts
117516460020	DOOR ASSY./B.B.	TATA spare parts
117516460024	DOOR ASSY./S.T	TATA spare parts
117516460028	DOOR ASSY./S.T	TATA spare parts
117516460033	SKIRT PANEL COMPLETE	TATA spare parts
117516460040	SKIRT PANEL COMPLETE	TATA spare parts
117516670001	DOOR ASSY.	TATA spare parts
117516670002	DOOR ASSEMBLY /S.T.	TATA spare parts

117516670003	DOOR ASSY.	TATA spare parts
117516790013	SKIRT PANEL COMPLETE-BATTERY BOX	TATA spare parts
117516850001	DOOR ASSY. / S.T.	TATA spare parts
117521760001	SKIRT PANEL COMPLETE	TATA spare parts
117521770002	SKIRT PANEL COMPLETE-S.T.	TATA spare parts
117521780001	WHEEL SIDE COVER/REAR	TATA spare parts
117521790001	SKIRT PANEL COMPLETE-BATTERY BOX	TATA spare parts
117521800002	SKIRT PANEL COMPLETE-BAGGAGGE BOX	TATA spare parts
117526200001	BUDGET LOCK COVER BLACK	TATA spare parts
117543650001	SKIRT PANEL COMPLETE	TATA spare parts
117554120001	LOCK (SOUTH CO)	TATA spare parts
117601700006	SKIRT PANEL COMPL.	TATA spare parts
117613290002	SKIRT PANEL COMPLETE L=1228	TATA spare parts
117613430001	SKIRT PANEL COMPL.	TATA spare parts
117613440001	SKIRT PANEL COMPL.	TATA spare parts
117613680007	SKIRT PANEL COMPLETE L=1308	TATA spare parts
117614810001	SKIRT PANEL COMPLETE	TATA spare parts
117614820001	SKIRT PANEL COMPLETE	TATA spare parts
117614980001	SKIRT PANEL COMPLETE	TATA spare parts
117616570002	SKIRT PANEL COMPLETE	TATA spare parts
117616580001	SKIRT PANEL COMPLETE	TATA spare parts
117616800001	SKIERT PANEL COMPLETE	TATA spare parts
117616960001	SKIRT PANEL COMPLETE	TATA spare parts
117617040001	SKIRT PANEL COMPL.	TATA spare parts
117617050001	SKIRT PANEL COMPL.	TATA spare parts
117617320001	SKIRT PANEL COMPLETE	TATA spare parts
117617440005	SKIRT PANEL COMPL.	TATA spare parts
117617550001	SKIRT PANEL COMPL.	TATA spare parts
117617690001	SKIRT PANEL COMPL.	TATA spare parts
117617700001	SKIRT PANEL COMPL.	TATA spare parts
117617750001	SKIRT PANEL COMPLETE	TATA spare parts
117617760001	SKIRT PANEL COMPLETE	TATA spare parts
117617850001	SKIRT PANEL COMPLETE	TATA spare parts
117617860001	SKIRT PANEL COMPLETE	TATA spare parts
117617900001	SKIRT PANEL COMPL.	TATA spare parts
117617910001	SKIRT PANEL COMPL.	TATA spare parts
117617920001	SKIRT PANEL COMPL.	TATA spare parts
117618140001	SKIRT PANEL COMPL.	TATA spare parts
117618150001	SKIRT PANEL COMPL.	TATA spare parts
117618220001	SKIRT PANEL COMPLETE-REAR	TATA spare parts
117618270001	SKIRT PANEL COMPLETE-REAR	TATA spare parts
117619030001	SKIRT PANEL COMPL.	TATA spare parts
117619040001	SKIRT PANEL COMPL.	TATA spare parts
117619140001	SKIRT PANEL COMPLETE	TATA spare parts
117619220001	SKIRT PANEL COMPLETE	TATA spare parts
117619230001	SKIRT PANEL COMPLETE	TATA spare parts
117619240001	SKIRT PANEL COMPLETE	TATA spare parts



117619250001	DOOR ASSY. / B.T	TATA spare parts
117619320001	SKIRT PANEL COMPL	TATA spare parts
117619330001	SKIRT PANEL COMPL	TATA spare parts
117619610001	SKIRT PANEL COMPLETE	TATA spare parts
117619620001	SKIRT PANEL COMPLETE	TATA spare parts
117619800001	SKIRT PANEL COMPLETE	TATA spare parts
117619880001	SKIRT PANEL COMPLETE	TATA spare parts
117623620001	SKIRT PANEL COMPLETE	TATA spare parts
117626590001	TRIANGULAR PANEL	TATA spare parts
118227	DOWEL RING	TATA spare parts
118959	GEAR SIDE	TATA spare parts
119193	WHEEL DIFF.KIT	TATA spare parts
119393	KIT - WHEEL DIFF.	TATA spare parts
119855	FORK SEAL & SPG ASSY	TATA spare parts
119863	SHIFT FORK MTG STUD	TATA spare parts
119881	NUT OUTER	TATA spare parts
119882	NUT INNER	TATA spare parts
119883	LOCK WASHER	TATA spare parts
119902	SUN GEAR	TATA spare parts
119984	CONNECTOR MALE	TATA spare parts
11CX004Z00	PLUG - END CAP	TATA spare parts
12001IP01	CENTRE FIVE BAR SHEET	TATA spare parts
12003IP01	GEAR BOX TRAP DOOR	TATA spare parts
1202610080	SEALING RING	TATA spare parts
12047662	CONNECTOR 2 WAY	TATA spare parts
12047664	LOCK SECONDARY	TATA spare parts
12047767	TERMINAL	TATA spare parts
12047783	LOCK SECONDARY	TATA spare parts
12050500606	HEX NUT M6-4-IS1363P3-SS8451-8C	TATA spare parts
12050500801	HEX NUT M8	TATA spare parts
12051396012	HEX NUT M4 IS1364P3-6-SS8451S2-Y	TATA spare parts
12051500600	HEX NUT M6	TATA spare parts
12051500804	HEX NUT M8	TATA spare parts
12051501002	HEX NUT M10	TATA spare parts
12051501207	HEX NUT M12	TATA spare parts
12051501401	HEX NUT M14	TATA spare parts
12051501606	HEX NUT M16	TATA spare parts
12051501801	HEX NUT M18	TATA spare parts
12051502009	HEX NUT M20	TATA spare parts
12051596011	HEX NUT M12	TATA spare parts
12051596020	HEX NUT M16	TATA spare parts
12051596038	HEX NUT M18	TATA spare parts
12051596046	HEX NUT M10 LH THREAD	TATA spare parts
12051596054	HEX NUT M8LH	TATA spare parts
12051596062	HEXNUT M6 LH IS 1364	TATA spare parts
12051596071	SELF LOCK NUT (6.6 GRADE) M 14	TATA spare parts
12051598022	HEX NUT M8	TATA spare parts

12051598061	HEX. NUT M6	TATA spare parts
12051598073	HEX NUT M10	TATA spare parts
12051598081	HEX NUT M6 IS1364P3-8-SS8	TATA spare parts
12051599011	HEX NUT M8 LH	TATA spare parts
12051599029	HEX NUT M10 LH THREAD	TATA spare parts
12051601201	HEX NUT M12 X 1.25	TATA spare parts
12051601406	HEX NUT M14 X 1.5	TATA spare parts
12051601601	HEX NUT M16 X 1.5	TATA spare parts
12051601805	HEX NUT M18 X 1.5	TATA spare parts
12051602003	HEX NUT M20 X 1.5	TATA spare parts
12051696016	HEX NUT M12 X 1.5	TATA spare parts
12051696024	HEX NUT M18X1.5-IS13722-8-SS8451-8C	TATA spare parts
12051696032	HEX NUT M10 X 1	TATA spare parts
12051696041	SELF LOCK NUT M20	TATA spare parts
12051696059	HEX NUT M16X1.5	TATA spare parts
12051699015	HEX NUT M10 X 1	TATA spare parts
12051699023	HEX NUT M12 X 1.5	TATA spare parts
12051699058	HEX NUT M14 X 1.5	TATA spare parts
12051801201	HEX NUT M12	TATA spare parts
12051900822	HEX NUT	TATA spare parts
12051901001	HEX NUT M10X1 IS13722-12-SS9400	TATA spare parts
12051901205	HEX NUT M12X1-5 IS 13722 12 SS9400	TATA spare parts
12051998039	HEX NUT M12X1.25 IS13722-12-SS9400	TATA spare parts
12052200600	HEX NUT M6	TATA spare parts
12052200804	HEX NUT M8	TATA spare parts
12052201002	HEX NUT M10	TATA spare parts
12052201207	HEX NUT M12	TATA spare parts
12052201606	HEX NUT M16	TATA spare parts
12052296011	HEX NUT M10	TATA spare parts
12052296020	HEX NUT M14 IS1364P3 B10 SS8451-8CH	TATA spare parts
12052296046	HEX NUT M8 IS1364P3-10-SS8451-8CH	TATA spare parts
12052296054	HEX NUT M12	TATA spare parts
12052300809	HEX NUT M8 X 1 10 SS9400	TATA spare parts
12052301406	HEX NUT M14 X 1.5	TATA spare parts
12052301601	HEX NUT M16 X 1.5	TATA spare parts
12052301805	HEX NUT M18 X 1.5	TATA spare parts
12052302003	HEX NUT M20 X 1.5	TATA spare parts
12052396016	HEX NUT M10 X 1	TATA spare parts
12052396024	HEX NUT M18 X 1.5	TATA spare parts
12052396032	HEX NUT M14X1.5 IS13722-10-SS8451-8CH	TATA spare parts
12052396041	HEX NUT M8 X 1	TATA spare parts
12052396059	HEX NUT M12 X 1.5	TATA spare parts
12052396067	HEX NUT M16 X 1.5	TATA spare parts
12052396075	HEX NUT M20 X 1.5	TATA spare parts
12052399015	HEX NUT M10 X 1	TATA spare parts
12052399023	HEX NUT M12 X 1.5	TATA spare parts
12052399040	HEX NUT M24X15 IS13722-10-SS8451-8CH	TATA spare parts

12052500409	HEXNUTM4IS1364P3-8-SS8451S2-Y BS6	TATA spare parts
12052500506	HEX NUT M5 IS1364P3-8-SS8451S2-Y	TATA spare parts
12052500603	HEX NUT M6 IS1364P3-8-SS8451S2-Y	TATA spare parts
12052500808	HEX NUT M8 IS1364P3-8-SS8451S2-Y	TATA spare parts
12052501006	HEX NUT M10 IS1364P3-8-SS8451S2-Y	TATA spare parts
12052501201	HEX NUT M12 IS1364P3-8-SS8451S2-Y	TATA spare parts
12052596015	HEX NUT M6LH IS1364P3-8- SS8451S2-Y BS6-	TATA spare parts
12052601604	HEX NUT M16X1.5 IS13722-8-SS8451	TATA spare parts
12052700807	HEX NUT M8 IS1364P3-10-SS8451S2-YH	TATA spare parts
12052701005	HEX NUT M10 IS1364P3-10-SS8451S2-YH	TATA spare parts
12052701200	HEX NUT M12 IS1364P3-10-SS8451S2-YH BS6	TATA spare parts
12052801000	HEX NUT M10X1.25 IS13722-10-SS8451S2-YH	TATA spare parts
12052801204	HEX NUT M12X1.5 IS13722-10-SS8451S2-YH	TATA spare parts
12052801603	HEX NUT M16X1.5 IS13722-10-SS8451S2-YH B	TATA spare parts
12052811404	HEX NUT M14X1.5 IS13722-10-SS8451-	TATA spare parts
12052896001	HEX NUT M12X1.25 IS13722 10 SS8451S2-YH	TATA spare parts
12053200301	HEX NUT M3 IS1364P3-8-SS9400	TATA spare parts
12053200409	HEX NUT M4	TATA spare parts
12053200506	HEX NUT M5	TATA spare parts
12053201207	HEX NUT M12	TATA spare parts
12053297011	HEX NUT M3 IS1364P3-8-SS8451-8C BS6	TATA spare parts
12053298018	HEX NUT M4	TATA spare parts
12053298026	HEX NUT M5	TATA spare parts
12053299049	HEX NUT M5 IS1364P3-BRASS	TATA spare parts
12053IP03	W/SCREEN CHIP (BOTTOM)	TATA spare parts
12054596012	HEX NUT M10 IS1364P3-8-SS8457S1-BL-B	TATA spare parts
12054596021	HEX NUT M12 IS1364P3-8-SS8457S1-BL-B	TATA spare parts
12054596039	HEX NUT M8	TATA spare parts
12054596152	HEX NUT M6 IS1364P3-8-SS8457S1-BL-B	TATA spare parts
12054696009	HEX NUT M12X1.5 IS13722 8 SS8457S1-BL-B	TATA spare parts
12054796003	HEX NUT M10 IS1364P3 10 SS8457S1-BL-B BS	TATA spare parts
12054796011	HEX NUT M8 IS1364P3 10 SS8457S1-BL-B	TATA spare parts
12054896008	HEX NUT M14X1.5 IS13722 10 SS8457S1-BL-B	TATA spare parts
12054896091	HEX NUT M16X1.5 IS13722-10-SS8457S1-BL-B	TATA spare parts
12054IP03	W/SCREEN CHIP (BOTTOM)	TATA spare parts
12056101207	LOCK NUT M12 X 1.5	TATA spare parts
12056101401	LOCK NUT M14X1.5 IS10410 SS8451-8C	TATA spare parts
12056101606	LOCK NUT M16X1.5-IS10410-SS8451-8C	TATA spare parts
12056101801	LOCK NUT M18 X 1.5	TATA spare parts
12056102203	LOCK NUT M22 X 1.5	TATA spare parts
12056102602	LOCK NUT M26 X 1.5	TATA spare parts
12056103005	LOCK NUT M30X2 IS10410 SS8451-8C BS6	TATA spare parts
12056196011	LOCK NUT M22X1.5-TS17408-SS8451-8C	TATA spare parts
12057010167	SPECIAL HEX NUT	TATA spare parts
120592010001	GP PVC SHEET OOTIS GREY (2440X900X0.5)	TATA spare parts
120592090001	FRONT STRUCTURE ROOF SHEET	TATA spare parts
120621120001	FREE FLOW LOUVERS	TATA spare parts

120624320001	AC LOUVER +READING LAMP &SWITCH RH (HAPP	TATA spare parts
120640360001	GRILLE (CLOSABLE TYPE)	TATA spare parts
12064758	CONNECTOR PLUNGE 3-WAY	TATA spare parts
12066IP03	REAR CORNER PANEL	TATA spare parts
12070IP03	DESTI. BOX TOP	TATA spare parts
120750	ELEC.SHIFT UNIT ASSY	TATA spare parts
12080800604	HEX THIN NUT M6	TATA spare parts
12080800809	HEX THIN NUT M8	TATA spare parts
12080801007	HEX THIN NUT M10	TATA spare parts
12080801201	HEX THIN NUT M12	TATA spare parts
12080801601	HEX THIN NUT M16 IS1364P4-05 SS9400 BS6	TATA spare parts
12080896016	HEX THIN NUT M10	TATA spare parts
12080896024	HEX THIN NUT M12	TATA spare parts
12080896032	HEX THIN NUT M6	TATA spare parts
12080896059	HEX THIN NUT M 8 LH	TATA spare parts
12080897047	HEX THIN NUT M10 IS1364P4	TATA spare parts
12080899023	HEX THIN NUT M10	TATA spare parts
12080900803	HEX THIN NUT M8 X 1	TATA spare parts
12080901001	H THIN NUT M10X1.25 IS13724-05SS8451S2-Y	TATA spare parts
12080901206	HEX THIN NUT M12 X 1.25	TATA spare parts
12080901401	HEX THIN NUT M14 X 1.5	TATA spare parts
12080901605	HEX THIN NUT M16 X 1.5	TATA spare parts
12080901800	HEX THIN NUT M18 X 1.5	TATA spare parts
12080902008	HEX THIN NUT M20 X 1.5	TATA spare parts
12080902202	HEX THIN NUT M22 X 1.5	TATA spare parts
12080902211	HX THIN NUT M22X1.5-IS13724-05SS8451S2-Y	TATA spare parts
12080903004	HEX THIN NUT M30 X 2	TATA spare parts
12080996011	HEX THIN NUT M12 X 1.5	TATA spare parts
12080996029	HEX THIN NUT M14 X 1.5	TATA spare parts
12080996037	HEX THIN NUT M22 X 1.5	TATA spare parts
12080996053	HEX THIN NUT M10 X 1	TATA spare parts
12080996070	HEX THIN NUT M8X1 IS13724-05 SS8451-8C	TATA spare parts
12080998013	HEX NUT	TATA spare parts
12080998030	HEX THIN NUT M18 X 1.5	TATA spare parts
12080998072	HEX THIN NUT M12 X 1.25	TATA spare parts
12080998081	NUT M 36X1.5	TATA spare parts
12080999010	HEX THIN NUT M10 X 1	TATA spare parts
12080999028	HEX THIN NUT M12 X 1.5	TATA spare parts
12080999036	HEX THIN NUT M24 X 1.5	TATA spare parts
12081201003	HEX THIN NUT M12	TATA spare parts
1208200520	BLINKER LAMP	TATA spare parts
12083OP01	PANEL BELOW SMALL WINDOW	TATA spare parts
12084OP01	PANEL NR. DR'S DOOR	TATA spare parts
12085000606	HEX. THIN NUT M 6	TATA spare parts
12085001203	HEX THIN NUT M12 IS1364P4-05 SS8451S2-Y	TATA spare parts
12085100805	HEX THIN NUT M8X1 IS13724-05 SS8451S2-Y	TATA spare parts
12085101003	HEX THIN NUT M10X1 IS13724-05-SS8451S2-Y	TATA spare parts

12085101208	H/THIN NUT M12X1.5 IS13724-05 SS8451S2-Y	TATA spare parts
12085OP01	PANEL NR. DR'S DOOR	TATA spare parts
12086IP04	DR'S SIDE REAR WHEEL COVE	TATA spare parts
12086OP01	PANEL NR. DR'S DOOR	TATA spare parts
12087IP04	CO-DR'S SIDE REAR WHEEL C	TATA spare parts
12087OP01	DR'S DOOR TOP PANEL	TATA spare parts
12088IP04	DR'S SIDE FRONT WHEEL COV	TATA spare parts
12089IP04	CO-DR'S SIDE FRONT WHEEL	TATA spare parts
12089OP01	SKIRT PANEL BELOW MAIN WI	TATA spare parts
12090	MUD FLAP PANEL	TATA spare parts
12090OP01	OPP. REAR DOOR WINDOW SKI	TATA spare parts
12093OP01	EMER. DOOR TOP PANEL	TATA spare parts
12094OP01	PANEL BELOW EMER. DOOR	TATA spare parts
12096OP01	REAR DOOR JAM PANEL	TATA spare parts
12097OP01	FRONT DOOR JAM PANEL	TATA spare parts
12100013	HINGE PIN-TAILDOOR CYLINDER EYE	TATA spare parts
12100014	Hinge Pin (Taildoor Hinge & Cylinder Eye	TATA spare parts
12100015	Washer for Tail Door Hinge Pin	TATA spare parts
12100OP02	TOP PANEL	TATA spare parts
12101000808	SLOTTED NUT M8	TATA spare parts
12101001006	SLOTTED NUT M10	TATA spare parts
12101096015	SLOTTED NUT M10	TATA spare parts
12101096023	SLOTTED NUT M12 X 1.5	TATA spare parts
12101200807	THIN SLOTTED NUT M8	TATA spare parts
12102001409	CASTLE NUT M14 X 1.5	TATA spare parts
12102001603	CASTLE NUT M16 X 1.5	TATA spare parts
12102001808	NUT M1.5X18	TATA spare parts
12102002006	CASTLE NUT M20X1.5 IS2232-A-8-SS8451-8C	TATA spare parts
12102091603	CASTLE NUT	TATA spare parts
12102096019	CASTLE NUT M14 X 1.5	TATA spare parts
12102096027	CASTLE NUT M12 X 1.5	TATA spare parts
12102096043	CASTLE NUT M16 X 1.5	TATA spare parts
12102098011	CASTLE NUT M12 X 1.5	TATA spare parts
12102098020	CASTLE NUT M14 X 1.5	TATA spare parts
12102099018	CASTLE NUT M12 X 1.5	TATA spare parts
121021140001	BEARING (SBG-10-2001 NMD)	TATA spare parts
12102201203	THIN CASTLE NUT M12 X 1.5	TATA spare parts
12102201408	THIN CASTLE NUT M14 X 1.5	TATA spare parts
12102201602	THIN CASTLE NUT M16 X 1.5	TATA spare parts
12102201807	THIN CASTLE NUT M18 X1.5	TATA spare parts
12102202005	THIN CASTLE NUT M20 X 1.5	TATA spare parts
12102296018	THIN CASTLE NUT M14 X 1.5	TATA spare parts
12102296026	THIN CASTLE NUT M16 X 1.5	TATA spare parts
12102296034	CASTLE NUT (M36X1.5) PITMAN ARM	TATA spare parts
12102296051	THIN CASTLE NUT M22X1.5TS17412 SS8451-8C	TATA spare parts
12102298169	THIN CASTLE NUT M16 X 1.5	TATA spare parts
12102299022	CASTTL NUT M36 * 1.5	TATA spare parts

12102299033	THIN CASTLE NUT M24 X1.5	TATA spare parts
12102299041	THIN CASTLE NUT M28 X1.5	TATA spare parts
12102299041AE	CASTLE NUT M 28X1.5 TS 17412 715	TATA spare parts
12102299068	THIN CASTLE NUT M32 X1.5	TATA spare parts
12102299092	THIN CASTLE NUT M36 X 1.5	TATA spare parts
121024490001	FRONT_HEADER_CENTER - H/R	TATA spare parts
121024500001	FRONT HEADER CORNER LH	TATA spare parts
121024510001	FRONT HEADER CORNER RH	TATA spare parts
121024570001	FRONT HEADER CENTER	TATA spare parts
121024580001	FRT HEADER CENT - L/R	TATA spare parts
12105596012	CASTLE NUT M12X1.5 TS17410S-8-SS8451S2-Y	TATA spare parts
12105801201	THIN CASTLE NUT M12X1.5TS17412SS8451S2-Y	TATA spare parts
12110236	TERMINAL	TATA spare parts
12121400608	DOMED CAP NUT M6	TATA spare parts
12121498021	DOMED CAP NUT M8	TATA spare parts
12124639	TERMINAL	TATA spare parts
12126496018	DOMED CAP NUT M6 IS7790-SS8451S2-B	TATA spare parts
12129691	SENSOR TEMPERATURE (OLD T)	TATA spare parts
12140500401	NYLOC NUT M4	TATA spare parts
12140500508	NYLOC NUT M5	TATA spare parts
12140500605	NYLOC NUT M6	TATA spare parts
12140500800	NYLOC NUT M8	TATA spare parts
12140501008	NYLOC NUT M10 IS7002-8-SS8451-8C	TATA spare parts
12140501202	NYLOC NUT M12	TATA spare parts
12140501407	NYLOC NUT M14	TATA spare parts
12140501601	NYLOC NUT M16	TATA spare parts
12140601002	NYLOC NUT M10 X 1	TATA spare parts
12140601011	NYLOC NUT M10X1.25 ISO-10512 8 SS8451-8C	TATA spare parts
12140601207	NYLOC NUT M12X1.5-TS17436-8-SS8451-8C	TATA spare parts
12140601215	NYLOC NUT M12X1.25 ISO-10512 8 SS8451-8C	TATA spare parts
12140601401	NYLOC NUT M14 X 1.5	TATA spare parts
12140601606	NYLOC NUT M16 X 1.5	TATA spare parts
12140698014	NYLOC NUT M20 X 1.5	TATA spare parts
12140700809	NYLOC NUT M8 IS7002-10-SS8451-8CH	TATA spare parts
12140701007	NYLOC NUT M10	TATA spare parts
12140701201	NYLOC NUT M12	TATA spare parts
12140801001	NYLOC NUT M10X1.25 ISO10512-10SS8451-8CH	TATA spare parts
12140801010	NYLOC NUT M10X1 ISO-10512-8-SS8451-8C	TATA spare parts
12140801206	NYLOC NUT M12X1.5 ISO-10512-10SS8451-8C	TATA spare parts
12140801208	NYLOCK NUT M12X1.5 IS10512 10.9SS8451-8C	TATA spare parts
12140801401	NYLOC NUT M14X1.5	TATA spare parts
12140801605	NYLOC NUT M16X1.5 ISO 10512 10SS8451-8CH	TATA spare parts
12140802407	NYLOC NUT M24X2 ISO 10512 10 SS8451- 8CH	TATA spare parts
12141496008	S/LOCK HEX NUT M6	TATA spare parts
12141700802	HEX FL NYLOC NUT M8 ISO 7043-8-SS8451-8C	TATA spare parts
12141701001	HEX FL NYLOC NUT M10 ISO 7043 8SS8451-8C	TATA spare parts
12141701205	HEX FL NYLOC NUT M12	TATA spare parts

12141801013	FL NYLOC NUT M10X1.25ISO12125-8SS8451-8C	TATA spare parts
12142001207	F/NYLOCNUT M12X1.25ISO12125 10SS8451-8CH	TATA spare parts
12142701004	LOCK HEX NUT M10 ISO 7042 10SS8451-8CH	TATA spare parts
12142801203	HEX NUT M12X1.5 ISO 10513 10 SS8451-8CH	TATA spare parts
12143401209	H/FL NUT M12X1.5 ISO 12126 10 SS8451-8CH	TATA spare parts
12143401403	HX/FL NUT M14X1.5 ISO12126 10 SS8451-8CH	TATA spare parts
12143401608	H/FL NUT M16X1.5 ISO 12126 10 SS8451-8CH	TATA spare parts
12143802009	S/L HEX FL NUT M20 ISO7044 10 SS8451-8CH	TATA spare parts
12144001603	S/LOCK HEXNUT M16 ISO7044 10SS8457S1-S-	TATA spare parts
12145000601	NYLOC NUT M6 IS7002-8-SS8451S2-Y	TATA spare parts
12145000805	NYLOC NUT M8 IS7002-8-SS8451S2-Y	TATA spare parts
12145001003	NYLOC NUT M10 IS7002-8-SS8451S2-Y	TATA spare parts
12145001208	NYLOC NUT M12 IS7002-8-SS8451S2-Y	TATA spare parts
12145001402	NYLOC NUT M14 ISO-7040-8-SS8451S2-Y BS6	TATA spare parts
12145002000	NYLOC NUT M20 IS7002-8-SS8451S2-Y BS6-PH	TATA spare parts
12145101407	NYLOC NUT M14X1.5 ISO-10512-8-SS	TATA spare parts
12145101601	NYLOC NUT M16X1.5 ISO-10512-8-SS8451S2-Y	TATA spare parts
12145196017	NYLOC NUT M14X1.5 ISO 10512 8 SS8451S2-B	TATA spare parts
12145201002	NYLOC NUT M10 IS7002-10-SS8451S2-YH	TATA spare parts
12145201207	NYLOC NUT M12 IS7002-10-SS8451S2-YH	TATA spare parts
12145296003	NYLOC NUT M10 IS7002 10 SS8457S1-BL-B	TATA spare parts
12145301007	NYLOC NUT M10X1 ISO 10512 10 SS8451S2-YH	TATA spare parts
12145301201	NYLOCNUT M12X1.25 ISO10512 10SS8451S2-YH	TATA spare parts
12145301210	NYLOC NUT M12X1.5ISO 10512-10SS8451S2-YH	TATA spare parts
12145301210_niu3	NYLOC NUT M12X1.5ISO 10512-10SS8451S2-YH	TATA spare parts
12145396032	NYLOC NUT M14X1.5 ISO10512 10SS8451S2-BH	TATA spare parts
12146296058	NY. NUT M14X1.5 ISO10512 8SS8457S1-BL-B	TATA spare parts
12146296066	NY. NUT M20X1.5 ISO10512 8SS8457S1-BL-B	TATA spare parts
12146396001	NYLOC NUT M12 IS7002 10 SS8457S1-BL-B BS	TATA spare parts
12146700606	NYLOC NUT	TATA spare parts
12146701203	HX FL NYLOC NUT M12	TATA spare parts
12146801607	FL NYLOC NUT M16X1.5ISO12125-8SS8451S2-Y	TATA spare parts
12148496011	FL NUT M12X1.5 ISO 12126 10SS8457S1-BL-B	TATA spare parts
12160500504	HEX WELDED NUT M5	TATA spare parts
12160500601	HEX WELDED NUT M6	TATA spare parts
12160500806	HEX WELDED NUT M8	TATA spare parts
12160501004	HEX WELD NUT M10 IS8856	TATA spare parts
12160501209	HEX WELD NUT M12 IS8856 BS6	TATA spare parts
12165500405	HEX WELD NUT M4 IS8856SS8451S2-Y	TATA spare parts
12200501401	RING NUT M14 X 1.5	TATA spare parts
12200502408	GROOVED NUT	TATA spare parts
12200503501	RING NUT M35 X 1.5	TATA spare parts
12200506004	NUT M60 X 1.5	TATA spare parts
1220105000	WASHER	TATA spare parts
122046330001	SERVICE COVER ASSY	TATA spare parts
12220500801	WING NUT AM8	TATA spare parts
12220501009	WING NUT AM10 IS2636 SS9400	TATA spare parts

12225500604	WING NUT AM6 IS2636 SS8451S2-Y	TATA spare parts
122303140001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122303900001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122305860001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122306440001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122306720001	PASSENGER DOOR ASSEMBLY BS6	TATA spare parts
122306770001	PASSENGER DOOR ASSY BS6	TATA spare parts
122306830001	PASSENGER DOOR ASSEMBLY BS6	TATA spare parts
122310120001	DOUBLE ROLLER ASSY	TATA spare parts
122310125F000000	DOUBLE ROLLER	TATA spare parts
122310390001	LATCH ASSY (TOWER BOLT)	TATA spare parts
122310890001	BEARING CASE-LOWER	TATA spare parts
12231089CN000000	BRG CASE	TATA spare parts
122310900001	BEARING CASE-LOWER	TATA spare parts
122310910001	BEARING CASE LOWER	TATA spare parts
122310920001	BEARING CASE-LOWER	TATA spare parts
122311260001	PASSENGER DOOR ASSEMBLY	TATA spare parts
12231141SF003290	PROTECTOR DOOR GLASS	TATA spare parts
122313990001	HINGE ASSY FOR PASSENGER DOOR	TATA spare parts
122314990001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122315100001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122315890001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122316040001	PASSENGER DOOR ASSY	TATA spare parts
122316330001	PASSENGER DOOR ASSY.	TATA spare parts
122316810001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122318240001	BEARING CASE-LOWER H- 43.5	TATA spare parts
122318240002	BEARING LOWER CASE BS6	TATA spare parts
122319170004	PASS. DOOR ASSY. COMPLETE	TATA spare parts
122319170005	PASS. DOOR ASSY. COMPLETE	TATA spare parts
122319520001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122320300001	SHAFT (2030)	TATA spare parts
122320310001	SHAFT (2031)	TATA spare parts
122320390001	PASSENGER DOOR LOCK ASSY - MINATO TYPE	TATA spare parts
122321460001	NYLON BEARING BS6	TATA spare parts
122321470001	SHAFT FOR PASSENGER DOOR - BLACK BS6	TATA spare parts
122325860001	PASSENGER DOOR ASSY	TATA spare parts
122327340001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122327460001	DOOR ASSY	TATA spare parts
122327470001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122327550001	PASSENGER DOOR ASSEMBLY BS6	TATA spare parts
122327560001	PASSENGER DOOR ASSEMBLY BS6	TATA spare parts
122327910001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122327960001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122327960002	PASSENGER DOOR ASSEMBLY	TATA spare parts
122328070001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122328080001	PASSENGER DOOR ASSY. BS6	TATA spare parts
122328090001	PASSENGER DOOR ASSY COMPLETE	TATA spare parts



122328100001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122328660001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122328700001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122329030001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122329750001	PASSENGER DOOR ASSY.	TATA spare parts
122329760001	PASSENGER DOOR ASSEMBLY COMPLETE	TATA spare parts
122329870001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122329900001	BEARING CASE LOWER	TATA spare parts
122329950001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122329980001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122333010001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122333810001	PASSENGER DOOR ASSY.	TATA spare parts
122334250001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122335050001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122335070001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122335080001	PASSENGER DOOR ASSEMBLY	TATA spare parts
122336010001	PASSENGER DOOR ASSEMBLY COMPLETE	TATA spare parts
122336070001	MOULDED WEATHER STRIP	TATA spare parts
122336170001	PASS. DOOR ASSY COMPLETE-MITECH	TATA spare parts
122336210001	TOWER BOLT BS6	TATA spare parts
122341250001	MOULDED WEATHER STRIP	TATA spare parts
122343790002	GRAB HANDLE PIPE	TATA spare parts
122343810001	WEATHER STRIP FOR PASSENGER DOOR	TATA spare parts
122346060001	MULDED WEATHER STRIP	TATA spare parts
122346090001	MOULDED WEATHER STRIP	TATA spare parts
122349390001	MOULDED WEATHER STRIP	TATA spare parts
122349460001	MOULDED WEATHER STRIP	TATA spare parts
122349470001	MOULDED WEATHER STRIP	TATA spare parts
122349480001	MOULDED WEATHER STRIP	TATA spare parts
122349490001	MOULDED WEATHER STRIP	TATA spare parts
122349680001	MOULDED WEATHER STRIP	TATA spare parts
122349690001	MOULDED WEATHER STRIP	TATA spare parts
122349700001	MOULDED WEATHER STRIP	TATA spare parts
122349840001	MOULDED WEATHER STRIP	TATA spare parts
122349850001	MOULDED WEATHER STRIP	TATA spare parts
122349860001	MOULDED WEATHER STRIP	TATA spare parts
122350330001	MOULDED WEATHER STRIP	TATA spare parts
122350400001	DOOR STOPPER PLATE	TATA spare parts
122360080001	MOULDED WEATHER STRIP	TATA spare parts
122380760001	DOOR GLASS(DK1-GG327 X 1832	TATA spare parts
122380770001	TOP PIVOT BRKT (DK1-TH0301155)	TATA spare parts
122380780001	ROLLER BRKT (DK1-RB0321410-S)	TATA spare parts
122380790001	HINGE WO HANDLE(DK1-DH0800405)	TATA spare parts
122380800001	HINGE+HANDLE(DK1-DH0800405-H)	TATA spare parts
122380810001	CENTER BEADING(DK1-EP2140C15)	TATA spare parts
122380820001	SIDE E.BEADING(DK1-EP2140S45)	TATA spare parts
122380830001	DOOR SIDE BULB BEADING	TATA spare parts

122380840001	DOOR HANDLE(DK1-HL0257-LC)	TATA spare parts
122380850001	BOTTOM BRKT(DK1-BH0481206-50)	TATA spare parts
122380860001	DOOR CATCHER ( DK1-BC8085)	TATA spare parts
122380870001	DOOR STOPER PIN(DK1-SP7796)	TATA spare parts
122380880001	IR SENSOR BRKT-DK1-SMB-225150	TATA spare parts
122380890001	SEALING ASSY(DK1-AC-EL-001)	TATA spare parts
122380900001	DOOR STOPER - BIG-DK1-EPL0001	TATA spare parts
122380910001	CYLINDER BRKT( DK1-CCB43050 )	TATA spare parts
122380920001	CYLINDER BRKT-DK1-CMB10090-35	TATA spare parts
122381080001	DOOR GLASS - STRAIGHT(DK1-GG287X2027)	TATA spare parts
122381090001	GLASS -TAPER(DK1-GG287X2027T)	TATA spare parts
122381100001	ROLLER ASSEMBLY (DK1-RBA-001 )	TATA spare parts
122381110001	SIDE MTNG.HINGE(DH0800405-R)	TATA spare parts
122381120001	DOOR BRUSH(DK1-BR-001)	TATA spare parts
122381140001	DOOR HANDLE(DK1-HL0257-LO)	TATA spare parts
122381150001	SEALING ASSEMBLY-DK1-AC-EL-002	TATA spare parts
122381160001	DOOR STOPPER DK1-EPL0002-M)	TATA spare parts
1223811700001	CY.CONNECT BRKT-DK1-CCB43050-S	TATA spare parts
122381180001	DUMMY CAP-DK1-FD-001	TATA spare parts
122381190001	BOTTOM COVER- DK1-FD-003	TATA spare parts
122398	RING GR. & DR PINION	TATA spare parts
12240500807	NUT M8	TATA spare parts
12240600607	SQUARE WELD NUT M6 DIN 928	TATA spare parts
12240600801	SQUARE WELD NUT M8 DIN 928 BS6	TATA spare parts
122417	KIT WHEEL DIFF CASE	TATA spare parts
122424	KIT BASIC O/HAUL	TATA spare parts
1225-B-496	BUSHING- ANCHOR PIN	TATA spare parts
122511670001	PASSENGER DOOR ASSY	TATA spare parts
122511860001	ENTRANCE DOOR ASSEMBLY.	TATA spare parts
122511870001	PASSENGER DOOR ASSY	TATA spare parts
122520180001	HINGED DOOR LOCK (RHD-RH)	TATA spare parts
122523690001	HINGE COVER	TATA spare parts
122523830001	PASS DOOR LOCK	TATA spare parts
122524140001	DOOR LOCK HANDLE	TATA spare parts
1227-D-940	NUT- INPUT SHAFT	TATA spare parts
122710130001	AIR CYLINDER (63DIAX125)	TATA spare parts
122713120001	PNEUMATIC SYSTEM WITH SENSORS	TATA spare parts
122713200001	PNEUMATIC DOOR SENSOR	TATA spare parts
122732150001	SENSITIVITY KIT (JANSTICS MAKE)	TATA spare parts
122732160001	SENSITIVITY KIT	TATA spare parts
122732180001	CYL SPEED CTRL VALV FORK & PIVOT	TATA spare parts
122732190001	AUXILLARY STEP	TATA spare parts
122732250001	PNEUMATIC DOOR SENSITIVITY KIT	TATA spare parts
122742000001	T VALVE ( PART OF 1227 3225 CF)	TATA spare parts
122742010001	ELECTRO PNEUMATIC SENSOR 24V	TATA spare parts
122742020001	PNEU.DOOR EMG SWITCH INNER	TATA spare parts
122780000001	MAIN A.CUT OFF VALVE-P332PP146	TATA spare parts

122780010001	FILTER REGULATOR ASSY-P114FR06	TATA spare parts
122780020001	SENSOR ON/OFF SWITCH(10246498)	TATA spare parts
122780030001	DOOR OPEN/CLOSE SW(10246497)	TATA spare parts
122780040001	5/2-SOLENOID VALVE-P352DS246	TATA spare parts
122780050001	ELECTRO PNEU. SENSOR-P5901A186	TATA spare parts
122780060001	PE CONVERTER-NO X6MM-P5706PE16	TATA spare parts
122780070001	AIR CYLINDER 50 X125-P21250125	TATA spare parts
122780080001	MAGNETIC SENSOR3WIRE-P540M4034	TATA spare parts
122780090001	IR SENSOR (GTE10-P1221)	TATA spare parts
122780100001	PASS DOOR RELAY-24V(P5741R24C)	TATA spare parts
122780110001	OUTER EMG.SWX6MM (P5242TM06)	TATA spare parts
122780120001	INNER EMG.SWX6MM (P5242NM06)	TATA spare parts
122780150001	PILOT NRV ASSY	TATA spare parts
122780160001	AIR CYLINDER 63X125(P21363125)	TATA spare parts
122780170001	SOLENOID VALVE 24V(P332PV246)	TATA spare parts
122780180001	T CONNECTOR (P4300T006)	TATA spare parts
122780190001	REDUCER 8X6 (10246497)	TATA spare parts
122780200001	INNER EMG.SWITCH( P5242TM06)	TATA spare parts
122780220001	SPEED CONTROL VALVE(P25105106)	TATA spare parts
122780230001	METAL TEE(P4300T006-MT)	TATA spare parts
122790980001	ROCKER SWITCH (24V DC) GEEEN WITH GREEN	TATA spare parts
122790990001	PNEUMATIC CYLINDER (SPC-D-W-MP4-50/100)	TATA spare parts
1230101608	INTER RING 0.3	TATA spare parts
123011160001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
123011210001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
123011220001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
123011610001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
123011620001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
123011640001	EMMG.DOOR ASSY	TATA spare parts
123011880001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
123011890001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
123012050001	EMERGENCY DOOR ASSY	TATA spare parts
123012070001	EMERGENCY DOOR ASSY	TATA spare parts
123012180001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
123012230001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
123012320001	EMERGENCY DOOR ASSEMBLY BS6	TATA spare parts
12301500406	HEX FL NUT AM4 TS17430-8-SS8451S2-Y	TATA spare parts
12301500503	HEX FL NUT AM5 TS17430-8-SS8451-8C	TATA spare parts
12301500601	HEX FL NUT AM6 TS17430-8-SS8451S2-Y	TATA spare parts
12301500805	NUT	TATA spare parts
12301501003	HEX FL NUT AM10 TS17430-8-SS8451S2-Y	TATA spare parts
12301501011	HEX FL NUT AM10X1.25 TS17430-8-SS8451-8C	TATA spare parts
12301501011_niu3	HEX FL NUT AM10X1.25 TS17430-8-SS8451-8C	TATA spare parts
12301501020	HEX FL NUT AM10X1 TS17430-8-SS8451-8C	TATA spare parts
12301501208	HEX FL NUT AM12 TS17430-8-SS8451-8C	TATA spare parts
12301501216	HEX FL NUT AM12X1.5 TS17430-8-SS8451-8C	TATA spare parts
12301501402	HEX FL NUT AM14 TS17430 8 SS8451-8C	TATA spare parts

12301501411	HEX FL NUT AM14X1.5 TS17430 8 SS8451-8C	TATA spare parts
12301501607	HEX FL NUT AM16 TS17430-8-SS8451-8C	TATA spare parts
12301501615	HEX FL NUT AM16X1.5 TS17430-8-SS8451-8C	TATA spare parts
12301510606	HEX FL NUT BM6-TS17430-8-SS8451-8C	TATA spare parts
12301510801	HEX FLANGE NUT BM8 -8	TATA spare parts
12301511009	HEX FL NUT BM10	TATA spare parts
12301600605	HEX FL NUT AM6 TS17430-10-SS9400	TATA spare parts
12301600800	HEX FL NUT AM8 TS17430-10-SS8451-8C	TATA spare parts
12301601008	HEX FL NUT AM10	TATA spare parts
12301601202	HEX FL NUT AM12	TATA spare parts
12301601211	HEX FL NUT AM12X1.5	TATA spare parts
12301601229	H/FL NUT AM12X1.25TS17430-10SS8451S2-YH	TATA spare parts
12301601415	HEX FL NUT AM14X1.5TS17430 10SS8451-8CH	TATA spare parts
12301601601	H/FL NUT AM16 TS17430 10 SS8451-8CH	TATA spare parts
12301601610	HEX FL NUT AM16X1.5 TS17430 10SS8451-8CH	TATA spare parts
123016050001	EMERGENCY DOOR ASSEMBLY BS6	TATA spare parts
12301610805	HEX FL NUT BM8 TS17430 10 SS8451S2-YH	TATA spare parts
12301611003	HEX FL.NUT BM10	TATA spare parts
12301611208	HEX FL NUT BM12 TS17430-10 SS8451-8CH	TATA spare parts
12301611615	HEX FL NUT BM16X1.5-TS17430-10SS8451-8CH	TATA spare parts
12301800507	HEX FL NUT AM5 TS17430-8-SS8451S2	TATA spare parts
12301800604	HEX FL NUT AM6 TS17430-8-SS8451S2-Y	TATA spare parts
12301801015	HEX FL NUT AM10X1.25 TS17430-8SS8451S2	TATA spare parts
12301801201	HEX FL NUT AM12 TS17430-8-SS8451S2-Y	TATA spare parts
12301801228	HEX FL NUT AM12X1.25	TATA spare parts
12301801406	HEX FL NUT AM14 TS17430 8 SS8451S2-Y	TATA spare parts
12301801414	HEX FL NUT AM14X1.5	TATA spare parts
12301801619	HEX FL NUT AM16X1.5 TS17430-8-SS8451S2-Y	TATA spare parts
12301811002	HEX FL NUT BM10 TS17430-8-SS8451S2-Y BS6	TATA spare parts
12301896016	HEX FL NUT AM6 TS17430-8-SS8451S2-B	TATA spare parts
12301896075	HEX FL NUT AM12X1.5 TS17430-8-SS8451S2-Y	TATA spare parts
12301900609	HEX FL NUT AM6 TS17430-10-SS8451S2-YH	TATA spare parts
12301900803	HEX FL NUT AM8 TS17430-10-SS8451S2-YH	TATA spare parts
12301901001	HEX FL NUT AM10 TS17430 10 SS8451S2-YH B	TATA spare parts
12301901010	HEXFL NUT AM10X1.25TS17430 10SS8451S2-YH	TATA spare parts
12301901206	HEX FL NUT AM12 TS17430 10 SS8451S2-YH B	TATA spare parts
12301901214	HEX FL NUT AM12X1.5 TS17430 10SS8451S2-Y	TATA spare parts
12301996002	HEX FLANGE NUT	TATA spare parts
12301996029	HEX FL NUT BM10 TS17430 10 SS8451S2-YH B	TATA spare parts
1230203001	PACKING RING	TATA spare parts
123020360001	ACRYLIC PLATE FOR EMERGENCY DOOR	TATA spare parts
12302201411	HEX FL NUT AM14X1.5 TS17430-10-SS8457-A	TATA spare parts
1230230001	END PLATE PACKING	TATA spare parts
123024520001	DRAW LATCH (SOUTHCO 37-30-294-	TATA spare parts
12302598027	HEX NUT W/COLLAR M16 X1.5	TATA spare parts
12302610108	HEX NUT WITH COLLAR M10IS7795-10-SS9400	TATA spare parts
12302696029	HEX NUT W/C M12X1.5-IS7795-10-SS8451-8CH	TATA spare parts

12302696053	H/NUT W/COLLAR M16X1.5IS7795-10SS845-8CH	TATA spare parts
12302996014	HEX FL NUT AM6-TS17430 BS6-PH2	TATA spare parts
12302996049	FL NUT AM14X1.5	TATA spare parts
12302996057	HEX FL NUT AM10 TS17430-8 SS8457S1-BL-B	TATA spare parts
12302996073	HEX FL NUT AM5 TS17430-8-SS8457S1-BL-B	TATA spare parts
12302996081	HEX FL NUT AM6 TS17430-8-SS8457S1	TATA spare parts
12302996120	FL NUT AM10X1.25 TS17430-8-SS8457S1-S-C	TATA spare parts
12302996227	HEX FL NUT AM8 TS17430-8 BS6-PH2	TATA spare parts
12302996251	HEX FL NUT AM12 TS17430 8 SS8457S1-BL-B	TATA spare parts
12302996286	HEX FL NUT AM10 TS17430-8-SS8457S1-BL-B	TATA spare parts
123030090001	HINGE ASSY	TATA spare parts
123030690001	COVER COMPLETE LOCK	TATA spare parts
123030760001	HINGE ASSEMBLY	TATA spare parts
12303096009	H/FL NUT BM10; TS17430-10-SS8457S1-BL-B	TATA spare parts
12303096041	HEX FL NUT AM12 TS17430 10 SS8457S1-BL-C	TATA spare parts
12303096050	HEX FL NUT AM10 TS17430 10 SS8457S1-BL-C	TATA spare parts
12303096084	HEX FL NUT BM12 TS17430-10 SS8457S1-S-C	TATA spare parts
12303096092	HEX FL NUT AM8 TS17430-8-SS8451S2-Y	TATA spare parts
12303096106	HEX FL NUT BM8 TS17430 10 SS8457S1-BL-B	TATA spare parts
12303096157	HEX FL NUT AM8 TS17430-10SS8457S1-BL-C B	TATA spare parts
123031130001	INNER HANDLE FOR EMERGENCY DOOR	TATA spare parts
123031140001	INNER HANDLE FOR EMERGENCY DOOR	TATA spare parts
123032690001	HINGE ASSY	TATA spare parts
123070210001	EMERGENCY LOCK ASSEMBLY	TATA spare parts
123070270001	LOCK ASSEMBLY EMG DOOR	TATA spare parts
123070300001	EMERGENCY LOCK ASSEMBLY	TATA spare parts
123070310001	LOCK ASSEMBLY EMG DOOR	TATA spare parts
123120160001	LOCK	TATA spare parts
123302300001	DRIVER DOOR ASSEMBLY - LCV	TATA spare parts
123311000001	DRIVERS DOOR ASSEMBLY	TATA spare parts
123311010001	DRIVER S DOOR ASSEMBLY	TATA spare parts
123311200001	DRIVERS S DOOR ASSEMBLY	TATA spare parts
123311380001	DRIVER S DOOR ASSEMBLY	TATA spare parts
123311510001	DRIVER DOOR ASSY	TATA spare parts
123311670001	DRIVERS DOOR ASSEMBLY	TATA spare parts
123311860001	DRIVER DOOR ASSEMBLY	TATA spare parts
123311870001	DRIVER DOOR ASSEMBLY	TATA spare parts
123311950001	DRIVERS DOOR ASSEMBLY	TATA spare parts
123311980001	DRIVERS DOOR ASSEMBLY	TATA spare parts
123313870001	DRIVERS S DOOR ASSEMBLY	TATA spare parts
123313880001	DRIVER DOOR ASSEMBLY	TATA spare parts
123313890001	DRIVERS DOOR ASSEMBLY	TATA spare parts
123314020001	DRIVER S DOOR ASSEMBLY BS6	TATA spare parts
123314350001	DRIVER DOOR ASSEMBLY	TATA spare parts
123314370001	DRIVERS DOOR ASSEMBLY	TATA spare parts
123314440001	DRIVER DOOR ASSY.	TATA spare parts
123316930001	DOUBLE STRIKER FOR DOOR	TATA spare parts

123316940001	SAFETY LATCH FOR EMERGENCY DOOR	TATA spare parts
123319280001	DRIVERS S DOOR ASSEMBLY	TATA spare parts
123319330001	DRIVERS DOOR ASSY BS6	TATA spare parts
123322170001	HINGE ASSY FOR DRIVER DOOR WITH STOPPER	TATA spare parts
123322410001	HINGE ASSY FOR DRIVER DOOR	TATA spare parts
123322450001	MAGAZINE POUCH	TATA spare parts
123322460001	MAGAZINE POUCH IN ABS (RHD)	TATA spare parts
123323910001	UPPER HINGE ASSY	TATA spare parts
123326440001	HINGE ASSEMBLY COMPLETE	TATA spare parts
123326990001	ABS INNER PANEL DRIVER DOOR (LH)	TATA spare parts
123327090001	MAGAZINE POUCH IN ABS (LHD)	TATA spare parts
123331210001	HINGE ASSY PASS.DOOR	TATA spare parts
123344280001	CATCHER BS6	TATA spare parts
1235890014	M B TOOLS	TATA spare parts
1235890114	M B TOOLS	TATA spare parts
1235890415	M B TOOLS	TATA spare parts
1235890535	M B TOOLS	TATA spare parts
12360100CF000000	FRP FRONT STRUCTURE	TATA spare parts
123623040001	FRONT PILLAR LH	TATA spare parts
123623050001	FRONT PILLAR RH	TATA spare parts
123623060001	FRONT PILLAR LH - H/R	TATA spare parts
123623070001	FRONT PILLAR RH - H/R	TATA spare parts
123623120001	FRONT PANEL CENTER	TATA spare parts
123623130001	FRONT PANEL CENTER	TATA spare parts
123624700001	FRONT PILLAR LH	TATA spare parts
123624710001	FRONT PILLAR RH	TATA spare parts
12371110109	THD INSERT AM10X10	TATA spare parts
12371110206	THD INSERT AM10X20TS-17450	TATA spare parts
1238307411	PROTECTION CAP	TATA spare parts
1238308201	GASKET	TATA spare parts
123831070001	POWER PACK KBA -LC36RSH	TATA spare parts
123831080001	CONDENSOR & EVAPURATOR UNIT KBA LC36RSH	TATA spare parts
123890000001	AIR FILTER (W/O OUTER CASING) 4000110	TATA spare parts
123890010001	HYUNDAI PP AIR CLEANER ASSYç 4000519	TATA spare parts
123890050001	AIR FILTER SUCTION HOSE-SPARE	TATA spare parts
123890060001	ROUND TUBE D70 70 X60MM PE-LD	TATA spare parts
123890070001	HYUNDAI PP AIR CLEANER INLET ASSEMBLY	TATA spare parts
123891050001	COOLANT HOSE-2	TATA spare parts
12392010058	SERRATED NUTSERT M5	TATA spare parts
12392010066	SERRATED NUTSERT M6	TATA spare parts
12392020053	NUT INSERT M5	TATA spare parts
12392020061	THIN SHEET NUTSERT M6	TATA spare parts
124012150001	SIDE WIN ASSY(1/3 TOP FIX- D GRN2/3 SLD-	TATA spare parts
124020860001	PEEP GLASS BS6	TATA spare parts
124020870001	QUARTER GLASS BS6	TATA spare parts
124020920001	QUARTER GLASS	TATA spare parts
124021680001	PASS. DOOR GLASS / F	TATA spare parts

124022480001	FIX GLASS	TATA spare parts
124022480002	FIX GLASS	TATA spare parts
124022490001	FIX GLASS- EMG DOOR	TATA spare parts
124022500001	FIX GLASS	TATA spare parts
124022500002	FIX GLASS	TATA spare parts
124022510002	FIX GLASS	TATA spare parts
124022520001	FIX GLASS DRIVER DOOR GREEN TINT 30PERC	TATA spare parts
124023050001	FIX GLASS EMG DOOR	TATA spare parts
124023060001	FIX GLASS	TATA spare parts
124023060003	FIX GLASS	TATA spare parts
124023060006	FIX GLASS	TATA spare parts
124023060007	FIX GLASS	TATA spare parts
124023070001	FIX GLASS	TATA spare parts
124023260001	FIX GLASS (DRIVER DOOR)	TATA spare parts
124023270001	FIX GLASS (DRIVER DOOR)	TATA spare parts
124023300001	FIX GLASS	TATA spare parts
124023300002	FIX GLASS	TATA spare parts
124023300003	FIX GLASS	TATA spare parts
124023300004	FIX GLASS	TATA spare parts
124023300005	FIX GLASS	TATA spare parts
124023320001	FIX GLASS (DRIVER DOOR)	TATA spare parts
124024060001	FIX GLASS	TATA spare parts
124024060002	FIX GLASS	TATA spare parts
124024070001	FIX GLASS	TATA spare parts
124024070002	FIX GLASS	TATA spare parts
124024080001	FIX GLASS - EMG	TATA spare parts
124024100001	FIX GLASS	TATA spare parts
124024100002	FIX GLASS	TATA spare parts
124024100003	FIX GLASS	TATA spare parts
124024100004	FIX GLASS	TATA spare parts
124024100005	FIX GLASS	TATA spare parts
124024100006	FIX GLASS	TATA spare parts
124025760001	PEEP GLASS	TATA spare parts
124025890001	PASSENGER DOOR GLASS/ F	TATA spare parts
124025920001	FIX GLASS	TATA spare parts
124025920002	FIX GLASS	TATA spare parts
124025930001	FIX GLASS	TATA spare parts
124025930002	FIX GLASS	TATA spare parts
124025930003	FIX GLASS	TATA spare parts
124025940001	FIX GLASS	TATA spare parts
124025940002	FIX GLASS	TATA spare parts
124025950001	FIX GLASS - EMERGENCY	TATA spare parts
124026520001	PEEP GLASS	TATA spare parts
124026530001	PEEP GLASS (CLR - 5MM THK)	TATA spare parts
124026570001	DRIVER DOOR WINDOW	TATA spare parts
124026650001	HOOPER TYPE WINDOW	TATA spare parts
124026660001	PEEP WINDOW	TATA spare parts

124026760001	SIDE WINDOW DRV. DOOR	TATA spare parts
124026910001	PEEP GLASS	TATA spare parts
124027560001	PASSENGER DOOR GLASS - FRONT	TATA spare parts
124027580001	PASSENGER DOOR GLASS FRONT	TATA spare parts
124027680001	GLASS TINTED	TATA spare parts
124027830001	FIX GLASS- EMG	TATA spare parts
124027840001	FIX GLASS	TATA spare parts
124027840002	FIX GLASS	TATA spare parts
124027850001	FIX GLASS	TATA spare parts
124027850002	FIX GLASS	TATA spare parts
124027860001	FIX GLASS	TATA spare parts
124027860002	FIX GLASS	TATA spare parts
124027880001	GLASS- FRT PASSANGER DOOR GLASS	TATA spare parts
124027960001	PASSENGER DOOR GLASS/ F	TATA spare parts
124028170001	QUARTER GLASS	TATA spare parts
124028180001	PASSENGER DOOR GLASS/F	TATA spare parts
124028580001	PEEP GLASS BS6-PH2	TATA spare parts
12403040CN114200	SIDE WIN.ASSY.( TOP FIX / CTB / RH /GRE	TATA spare parts
12403041CN009050	CAB COMPLT RHD SLEEPER	TATA spare parts
1240304278	PRESSURE PART	TATA spare parts
124030480003	SIDE WINDOW ASSEMBLY-DRIVER -R/H SIDE	TATA spare parts
12403052CN113600	CAB COMPLT RHD SLEEPER	TATA spare parts
124030560001	SIDE WINDOW ASSEMBLY-EMERGENCY-R/H SIDE	TATA spare parts
124030560003	SIDE WINDOW ASSEMBLY-R/H SIDE	TATA spare parts
124030560006	SIDE WINDOW ASSEMBLY-R/H SIDE	TATA spare parts
124030560014	SIDE WINDOW ASSEMBLY-L/H SIDE	TATA spare parts
124030560016	SIDE WINDOW ASSEMBLY-L/H SIDE	TATA spare parts
124030680001	SIDE WINDOW	TATA spare parts
124030760003	SIDE WINDOW ASSEMBLY-L/H SIDE	TATA spare parts
124031240006	SD WIN ASSY(CTB/3PC/GREEN/PC)	TATA spare parts
124031240015	SD WIN ASSY(CTB/3PC/GREEN/PC)	TATA spare parts
124031240020	SIDE WINDOW ASSY(CTB/3PC/GREEN)	TATA spare parts
124031240021	SD WIN ASSY(CTB/3PC/GREEN/PC)	TATA spare parts
124033610001	PEEP GLASS FOR DRIVER S DOOR	TATA spare parts
124034010001	SD WIN ASSY(CTB -1/3FIX -2/3SLD -CLR-PC)	TATA spare parts
124034010003	SD WIN ASSY(CTB -1/3FIX -2/3SLD -CLR-PC)	TATA spare parts
124034010005	SD WIN ASSY(CTB -1/3FIX -2/3SLD -CLR-PC)	TATA spare parts
124034010007	SD WIN ASSY(CTB -1/3FIX -2/3SLD -CLR-PC)	TATA spare parts
124034010009	SD WIN ASSY-CTB-1/3 FIX-2/3 SLD-CLR TEMP	TATA spare parts
124034010010	SD WIN ASSY-CTB-1/3 FIX-2/3 SLD-CLR TEMP	TATA spare parts
124034010011	SD WIN ASSY-CTB-1/3 FIX-2/3 SLD-CLR TEMP	TATA spare parts
124034390001	SIDE WINDOW ASSEMBLY (EMERGENCY)	TATA spare parts
124035010001	WINDOW ASSY EMERGENCY DOOR	TATA spare parts
124035010002	WINDOW ASSY EMERGENCY DOOR	TATA spare parts
124035020001	SID WIN ASSY CTB 1/3 TOP FIX D GRN 2/3	TATA spare parts
124035020002	SID WIN ASSY CTB 1/3 TOP FIX D GRN 2/3	TATA spare parts
124035020004	SID WIN ASSY CTB 1/3 TOP FIX D GRN 2/3	TATA spare parts



124035020005	SID WIN ASSY CTB 1/3 TOP FIX D GRN 2/3 S	TATA spare parts
124035020006	SID WIN ASSY CTB 1/3 TOP FIX D GRN 2/3 S	TATA spare parts
124035020007	SID WIN ASSY CTB 1/3 TOP FIX D GRN 2/3 S	TATA spare parts
124035020008	SID WIN ASSY CTB 1/3 TOP FIX D GRN 2/3	TATA spare parts
124035020009	SID WINDOW ASSY 1/3 TOP FIX 2/3 SLD	TATA spare parts
124035020010	SID WINDOW ASSY 1/3 TOP FIX 2/3 SLD	TATA spare parts
124035240018	SIDE WINDOW ASSEMBLY	TATA spare parts
124035240026	SIDE WINDOW ASSEMBLY	TATA spare parts
124035240027	SIDE WINDOW ASSEMBLY	TATA spare parts
124035240028	SIDE WINDOW ASSEMBLY	TATA spare parts
124035280001	PEEP GLASS	TATA spare parts
124035600001	DRIVER DOOR WINDOW (CTB-2PC-CLR)	TATA spare parts
124035600002	DRIVER DOOR WINDOW	TATA spare parts
124035850001	WINDOW ASSY - EMG DOOR	TATA spare parts
124035860001	SIDE WINDOW ASSY TOP 1/3 FIX 2/3 SLD	TATA spare parts
124035860002	SIDE WINDOW ASSY TOP 1/3 FIX 2/3 SLD	TATA spare parts
124035860003	SIDE WINDOW ASSY TOP 1/3 FIX 2/3 SLD	TATA spare parts
124035860004	SIDE WINDOW ASSY TOP 1/3 FIX 2/3 SLD	TATA spare parts
124035860005	SIDE WINDOW ASSY TOP 1/3 FIX 2/3 SLD	TATA spare parts
124035860006	SIDE WINDOW ASSY TOP 1/3 FIX 2/3 SLD	TATA spare parts
124035860007	SIDE WINDOW ASSY TOP 1/3 FIX 2/3 SLD	TATA spare parts
124035860008	SIDE WINDOW ASSY TOP 1/3 FIX 2/3 SLD	TATA spare parts
124035860009	SIDE WINDOW ASSY TOP 1/3 FIX 2/3 SLD	TATA spare parts
124035900001	REAR DOOR GLASS	TATA spare parts
124036240001	SIDE WINDOW ASSEMBLY	TATA spare parts
124036240002	SIDE WINDOW ASSEMBLY	TATA spare parts
124036240003	SIDE WINDOW ASSEMBLY	TATA spare parts
124036240004	SIDE WINDOW ASSEMBLY	TATA spare parts
124036250001	SIDE WINDOW EMG. DOOR	TATA spare parts
124036370001	WINDOW ASSY ÷ EMG	TATA spare parts
124036380001	SIDE WINDOW ASSY	TATA spare parts
124036380002	SIDE WINDOW ASSY	TATA spare parts
124036380003	SIDE WINDOW ASSY	TATA spare parts
124036390001	SIDE WINDOW ASSY	TATA spare parts
124036400002	SIDE WINDOW ASSY DRV	TATA spare parts
124036460001	GLASS (PEEP GLASS)	TATA spare parts
124036480001	SIDE WINDOW ASSY	TATA spare parts
124036480002	SIDE WINDOW ASSY	TATA spare parts
124036480003	SIDE WINDOW ASSY	TATA spare parts
124036480004	SIDE WINDOW ASSY	TATA spare parts
124036490001	SIDE WINDOW ASSY	TATA spare parts
124036490002	SIDE WINDOW ASSY	TATA spare parts
124036500001	WINDOW ASSY. DRIVER	TATA spare parts
124036690001	DRIVER DOOR WINDOW ASSY FOR LIBERIA	TATA spare parts
124036700001	SIDE WINDOW ASSY FOR LIBERIA	TATA spare parts
124036700002	SIDE WINDOW ASSY FOR LIBERIA	TATA spare parts
124036700003	SIDE WINDOW ASSY FOR LIBERIA	TATA spare parts

12403670004	SIDE WINDOW ASSY FOR LIBERIA	TATA spare parts
124036710001	SIDE WINDOW ASSY FOR LIBERIA	TATA spare parts
124036720001	PASSENGER DOOR GLASS/F	TATA spare parts
124036780001	SIDE WINDOW ASSEMBLY (CTB)	TATA spare parts
124036780002	SIDE WINDOW ASSEMBLY (CTB)	TATA spare parts
124036780003	SIDE WINDOW ASSEMBLY (CTB)	TATA spare parts
124036780004	SIDE WINDOW ASSEMBLY (CTB)	TATA spare parts
124036780005	SIDE WINDOW ASSEMBLY (CTB)	TATA spare parts
124036840001	QUARTER GLASS BS6	TATA spare parts
124036850001	DR DOOR WINDOW	TATA spare parts
124042310001	QUARTER GLASS-COMFORT BUS-CLEAR	TATA spare parts
124045380001	PASSENGER DOOR GLASS - FRONT	TATA spare parts
124045390001	PASSENGER DOOR GLASS / R	TATA spare parts
124050080001	CO-DRV SIDE WINDOW ASSY. (SM22)	TATA spare parts
124050080002	CO-DRV SIDE WINDOW ASSY. (SM22)	TATA spare parts
124050080005	CO-DRV SIDE WINDOW ASSY.	TATA spare parts
124050080008	CO-DRV SIDE WINDOW ASSY. (SM22)	TATA spare parts
124050090001	SIDE WINDOW ASSY(DRV DOOR-SM22-2PC-CLEAR	TATA spare parts
124050110002	WINDOW ASSEMBLY DRIVER DOOR	TATA spare parts
124050110003	WINDOW ASSEMBLY DRIVER DOOR	TATA spare parts
124050110004	WINDOW ASSEMBLY DRIVER DOOR BS6	TATA spare parts
124050410001	WINDOW ASSY- EMERGENCY DOOR	TATA spare parts
124050420003	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
124050420005	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
124050420008	SIDE WIN ASSY SM 22	TATA spare parts
124050420009	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
124050420014	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
124050420018	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
124050420020	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
124050420021	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
124050420023	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
124050420026	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
124050420027	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
124050420028	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
124050420029	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
124050420030	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
124050440018	SD WIND ASSY (SM 22-1/3 FIX-2/	TATA spare parts
124050440019	SD WIND ASSY (SM 22-1/3 FIX-2/	TATA spare parts
124050440020	SD WIND ASSY (SM 22-1/3 FIX-2/	TATA spare parts
124050440021	SD WIND ASSY (SM 22-1/3 FIX-2/	TATA spare parts
124050440022	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD-LGHT	TATA spare parts
124050440023	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD-LGHT	TATA spare parts
124050440024	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD-LGHT	TATA spare parts
124050960002	DR.DOOR WINDOW ASSY.	TATA spare parts
124051400010	SIDE WINDOW ASSEMBLY	TATA spare parts
124051400013	SIDE WINDOW ASSEMBLY	TATA spare parts
124051400015	SIDE WINDOW ASSEMBLY	TATA spare parts

124051470001	WINDOW ASSEMBLY - EMG	TATA spare parts
124051480001	SD WIND ASSY (1/3 FIX-2/3 SLD- CLR T GLA	TATA spare parts
124051480003	SD WIND ASSY (1/3 FIX-2/3 SLD- CLR T GLA	TATA spare parts
124052220001	IDE WINDOW ASSY (SM 22)	TATA spare parts
124052220002	SIDE WINDOW ASSY (SM 22)	TATA spare parts
124052220003	SIDE WINDOW ASSY (SM 22)	TATA spare parts
124052220004	SIDE WINDOW ASSY (SM 22)	TATA spare parts
124052220005	SIDE WINDOW ASSY (SM 22)	TATA spare parts
124052230001	WINDOW ASSYMBLY DRIVER DOOR	TATA spare parts
124053470002	SIDE WIN ASSY (SM22-FLOCK-2PC-CLR)	TATA spare parts
124053610001	SIDE WINDOW ASSY TOP1/3 FIX DGREY 2/3 SL	TATA spare parts
124053610002	SIDE WINDOW ASSY TOP1/3 FIX DGREY 2/3 SL	TATA spare parts
124053610003	SIDE WINDOW ASSY TOP1/3 FIX DGREY 2/3 SL	TATA spare parts
124053610017	SIDE WINDOW ASSY TOP1/3 FIX DGREY 2/3 SL	TATA spare parts
124053760004	DRV.DOOR WINDOW ASSY	TATA spare parts
124053850001	DRIVER DOOR WINDOW ASSEMBLY	TATA spare parts
124053860003	SIDE WINDOW ASSEMBLY	TATA spare parts
124053860004	SIDE WINDOW ASSEMBLY	TATA spare parts
124053860005	SIDE WINDOW ASSEMBLY	TATA spare parts
124053860006	SIDE WINDOW ASSEMBLY	TATA spare parts
124053870001	WINDOW ASSEMBLY - EMG	TATA spare parts
124053890001	SIDE WINDOW ASSY(SM22-1/3 FIX-2/3 SLD-PC	TATA spare parts
124053890002	SIDE WINDOW ASSY(SM22-1/3 FIX-2/3 SLD-CL	TATA spare parts
124053890003	SIDE WINDOW ASSY(SM22-1/3 FIX-2/3 SLD-CL	TATA spare parts
124053890006	SIDE WINDOW ASSY(SM22-1/3 FIX-2/3 SLD-PC	TATA spare parts
124053890007	SIDE WINDOW ASSY(SM22-1/3 FIX-2/3 SLD-PC	TATA spare parts
124053890008	SIDE WINDOW ASSY(SM22-1/3 FIX-2/3 SLD-PC	TATA spare parts
124053890009	SIDE WINDOW ASSY(SM22-1/3 FIX-2/3 SLD-PC	TATA spare parts
124053890010	SIDE WINDOW ASSY(SM22-1/3 FIX-2/3 SLD-PC	TATA spare parts
124053890011	SIDE WINDOW ASSY(SM22-1/3 FIX-2/3 SLD-PC	TATA spare parts
124054030001	GLASS CLEAR(397X722X5 THK)	TATA spare parts
124054150001	DRV DOOR WINDOW CTB TYPE LIGHT GREEN	TATA spare parts
124054160001	WINDOW ASSY (FULL FIXED)	TATA spare parts
124054260001	SIDE WINDOW ASSY SM 22	TATA spare parts
124054270001	WINDOW ASSY DRV DOOR (SM) BS6	TATA spare parts
124054280001	SIDE WINDOW ASSEMBLY FOR JKSRTC	TATA spare parts
124054290001	SIDE WINDOW ASSEMBLY FOR JKSRTC	TATA spare parts
124054310001	SIDE WINDOW ASSEMBLY FOR JKSRTC	TATA spare parts
124054310002	SIDE WINDOW ASSEMBLY	TATA spare parts
124054310003	SIDE WINDOW ASSEMBLY	TATA spare parts
124054340001	SIDE WINDOW ASSEMBLY (CTB)	TATA spare parts
124054360001	WIND ASSY - EMG (CTB)	TATA spare parts
124054380001	HOOPER WINDOW BS6	TATA spare parts
124059000001	OPTYPE LOCK-OUTER SHUTTER	TATA spare parts
124059010001	OPTYPE LOCK -INNER SHUTTER	TATA spare parts
124059040001	PEEP WINDOW ASSY	TATA spare parts
124080110001	PASS DOOR GLASS	TATA spare parts

124080120001	PASS DOOR GLASS	TATA spare parts
124080160001	PASS DOOR GLASS/F	TATA spare parts
124080170001	PASS DOOR GLASS / FR	TATA spare parts
124080190001	PASSENGER DOOR GLASS/REAR	TATA spare parts
124080200001	PASSENGER DOOR GLASS - FRONT	TATA spare parts
124080210001	PASSENGER DOOR GLASS - FRONT	TATA spare parts
124080240001	PASSENGER DOOR GLASS FRONT	TATA spare parts
124080250001	PASSENGER DOOR GLASS FRONT	TATA spare parts
124080260001	PASSENGER DOOR GLASS REAR	TATA spare parts
124080310001	PASSENGER DOOR GLASS/ R	TATA spare parts
124080320001	PASSENGER DOOR GLASS/ R	TATA spare parts
124080350001	GLASS TINTED	TATA spare parts
124080360001	REAR DOOR GLASS	TATA spare parts
124080420001	PASSENGER DOOR GLASS/REAR	TATA spare parts
124080450001	GLASS TINTED (265X856X5 THK) ç BRONZE	TATA spare parts
124080460001	GLASS- FRT PASSANGER DOOR GLASS	TATA spare parts
124080470001	GLASS - FRT PASSANGER DOOR GLASS	TATA spare parts
124080560001	PASS DOOR GLASS	TATA spare parts
124080580001	GLASS TINTED (288X810X5 THK)	TATA spare parts
124080670001	PASSENGER DOOR GLASS / F	TATA spare parts
124080710001	PASSENGER DOOR GLASS/ R	TATA spare parts
124080740001	PASSENGER DOOR GLASS	TATA spare parts
124080750001	PASSENGER DOOR GLASS	TATA spare parts
124080760001	PASSENGER DOOR GLASS/ F	TATA spare parts
124080770001	PASSENGER DOOR GLASS/R	TATA spare parts
124080790001	PASSENGER DOOR GLASS BS6	TATA spare parts
124080800001	PASSENGER DOOR GLASS BS6	TATA spare parts
124080830001	PASS DOOR GLASS BS6	TATA spare parts
124080840001	PASS DOOR GLASS BS6	TATA spare parts
124080870001	PASSENGER DOOR GLASS	TATA spare parts
124080880001	PASSENGER DOOR GLASS/F	TATA spare parts
124080890001	PASSENGER DOOR GLASS/R	TATA spare parts
1244-H-C008	DISTANCE PIECE	TATA spare parts
124426230001	INNER PANEL	TATA spare parts
124426250001	INNER PANEL	TATA spare parts
124426270001	INNER PANEL	TATA spare parts
124426280001	INNER PANEL	TATA spare parts
124426290001	INNER PANEL	TATA spare parts
124426300001	INNER PANEL ABS	TATA spare parts
124426320001	INNER PANEL	TATA spare parts
124426340001	INNER PANEL	TATA spare parts
124426360001	COVER PANEL	TATA spare parts
12460500328	BRIGHT WASHER 3.2 IS2016 ST SS8451-8C BS	TATA spare parts
12460500433	BRIGHT WASHER 4.3	TATA spare parts
12460500531	BRIGHT WASHER 5.3	TATA spare parts
12460500646	BRIGHT WASHER 6.4	TATA spare parts
12460500841	BRIGHT WASHER 8.4	TATA spare parts

12460501057	BRIGHT WASHER 10.5	TATA spare parts
12460501308	BRIGHT WASHER 13	TATA spare parts
12460501502	BRIGHT WASHER 15	TATA spare parts
12460501707	BRIGHT WASHER 17	TATA spare parts
12460501901	BRIGHT WASHER 19	TATA spare parts
12460502100	BRIGHT WASHER 21	TATA spare parts
12460502304	BRIGHT WASHER 23	TATA spare parts
12460502509	BRIGHT WASHER 25 IS2016 ST SS8451-8C	TATA spare parts
12460502801	BRIGHT WASHER 28 IS2016 ST SS8451-8C BS6	TATA spare parts
12460598107	BRIGHT WASHER 6.4 IS2016-ST-SS8451-13D	TATA spare parts
12460598123	BRIGHT WASHER 10.5	TATA spare parts
12460598140	BRIGHT WASHER 8.4 IS2016 ST SS8451-13D	TATA spare parts
124610080001	FRONT WINDSHIELD	TATA spare parts
124610090001	FRONT WINDSHIELD	TATA spare parts
124620190001	FRONT W/S LAM GLASS W/O BAND	TATA spare parts
124620340001	FRONT WINDSHIELD GLASS(COMFORT-2500)	TATA spare parts
124620370001	FRT W/S COMFORT HRF 2570 (SINGLE PC)	TATA spare parts
124620480001	FRT RUBER BEADING(MOULD) COMFT HIGH ROO	TATA spare parts
124620490001	FRONT WIND SHIELD MOULD.	TATA spare parts
124620540001	FRONT WINDSHIELD - JUPITOR	TATA spare parts
124620700001	FRONT WINDSHIELD RH	TATA spare parts
124620710001	FRONT WINDSHIELD LH	TATA spare parts
124620740001	FRONT WINDSHIELD	TATA spare parts
124620760001	FRT W/S ELANZA SMILY FACE SINGLE PC	TATA spare parts
124620770001	FRONT WINDSHIELD MOULD	TATA spare parts
124620780001	FRONT WINDSHIELD	TATA spare parts
124620800001	FRONT RUBBER BEEDING (MOULDED)	TATA spare parts
124620810001	FRONT RUBBER BEEDING (MOULDED)	TATA spare parts
124620840001	FRONT WINDSHIELD LH	TATA spare parts
124620850001	FRONT WINDSHIELD RH	TATA spare parts
124620860001	FRONT WINDSHIELD	TATA spare parts
124621280001	FRT W/S COMFORT LRF 2570 (SINGLE- PC)	TATA spare parts
124621350001	FRT W/S COMFORT LRF 2570 (2- PC) RH	TATA spare parts
124621360001	FRT W/S COMFORT LRF 2570 (2- PC) LH	TATA spare parts
124630010001	FRONT WINSHIELD MOULD	TATA spare parts
124630070001	FRONT WINDSHIELD MOULD	TATA spare parts
12465000536	BRIGHT WASHER 5.3 IS2016 ST SS8451S2-Y	TATA spare parts
12465000641	BRIGHT WASHER 6.4 IS2016 ST SS8451S2-Y	TATA spare parts
12465000846	BRIGHT WASHER 8.4 IS2016 ST SS8451S2-Y	TATA spare parts
12465001052	BRIGHT WASHER 10.5 IS2016 ST SS8451S2-Y	TATA spare parts
12465001303	BRIGHT WASHER 13 IS2016 ST SS8451S2-Y	TATA spare parts
12465001508	BRIGHT WASHER 15 IS2016 ST SS8451S	TATA spare parts
12465001702	BRIGHT WASHER 17-IS2016-ST-SS8451S2-Y	TATA spare parts
12465002105	BRIGHT WASHER 21 IS2016 ST SS8451S2-Y	TATA spare parts
12465096011	BRIGHT WASHER 6.4 IS2016-ST-SS8451S2-B	TATA spare parts
12465096029	BRIGHT WASHER 10.5 IS2016 SS8451S2-B	TATA spare parts
12466096014	BRIGHT WASHER8.4 IS2016 ST SS8457S1-BL-B	TATA spare parts

12466096081	BRIGHT WASHER 17 IS2016 ST SS8457S1-S-C	TATA spare parts
12466096138	BRIGHT WASHER 6.4IS2016-ST-SS8457S1-BL-B	TATA spare parts
12466096154	BRIGHT WASHER 8.4IS2016-ST-SS8457S1-BL-B	TATA spare parts
12466096162	B. WASHER 10.5 IS2016-ST-SS8457S1-BL-B	TATA spare parts
12466096171	BRIGHT WASHER 13 IS2016 ST SS8457S1-BL-B	TATA spare parts
124710420001	REAR WIND SHIELD	TATA spare parts
124710430001	REAR WIND SHIELD	TATA spare parts
124710450001	REAR WIND SHIELD	TATA spare parts
124720110001	WEATHER STRIP/H(REAR-VERT.5E MODEL)	TATA spare parts
12472011RF000000	WEATHER STR(REAR VERT.5E)	TATA spare parts
124720290001	REAR W/S TOUGHNED GLASS(COMFORT)	TATA spare parts
124720310001	RUBBER MOULD FOR REAR W/S (COMFORT)	TATA spare parts
124720400001	REAR WINDSHIELD GLASS(COMFORT-2500)	TATA spare parts
124720410001	REAR MOULD RUBBER BEADING(COMF-2500)	TATA spare parts
124720550001	REAR WINDSHIELD - JUPITOR	TATA spare parts
124720600001	REAR WINDSHIELD - COMFORT LR	TATA spare parts
124720630001	REAR WINDSHIELD LH	TATA spare parts
124720640001	REAR WINDSHIELD RH	TATA spare parts
124720680001	REAR WIND SHIELD -ELANZA	TATA spare parts
124720700001	REAR WINDSHIELD - COMFORT LR	TATA spare parts
124720710001	REAR WINDSHIELD	TATA spare parts
124720720001	REAR DESTINATION GLASS	TATA spare parts
124720730001	REAR RUBBER BEEDING (MOULD)	TATA spare parts
124720740001	REAR W/S BRONZ TINT	TATA spare parts
124720750001	REAR WINDSHIELD	TATA spare parts
124720770001	RUBBER MOULDING	TATA spare parts
124740100001	REAR WIND SHIELD GLASS	TATA spare parts
12480600663	BLACK WASHER B6.6	TATA spare parts
12480600906	BLACK WASHER B9	TATA spare parts
12480601104	BLACK WASHER B11	TATA spare parts
12480601406	BLACK WASHER B14	TATA spare parts
12480601805	BLACK WASHER B18	TATA spare parts
1250-U-229	PLUG - PLASTIC PROTECTIVE	TATA spare parts
1250307552	GASKET	TATA spare parts
125056	RETAINER ASSY	TATA spare parts
125106	CLUTCH REL SLEEVE & BRG	TATA spare parts
125126	CLUTCH REL BRG W/O SLEEVE	TATA spare parts
125197	INTERMEDIATE RING ASSY	TATA spare parts
12520600408	SPRING WASHER B4	TATA spare parts
12520600505	SPRING WASHER B5	TATA spare parts
12520600602	SPRING WASHER B6	TATA spare parts
12520600700	SPRING WASHER B7	TATA spare parts
12520600807	SPRING WASHER B8 IS3063 SS8400	TATA spare parts
12520601005	SPRING WASHER B10	TATA spare parts
12520601200	SPRING WASHER B12	TATA spare parts
12520601404	SPRING WASHER B14	TATA spare parts
12520601602	SPRING WASHER M16B	TATA spare parts

12520601609	SPRING WASHER B16	TATA spare parts
12520601803	SPRING WASHER B18	TATA spare parts
12520602001	SPRING WASHER B20	TATA spare parts
12520696014	SPRING WASHER B12	TATA spare parts
12520696022	SPRING WASHER B14	TATA spare parts
12520696031	SPRING WASHER B16	TATA spare parts
12520696049	SPRING WASHER B18	TATA spare parts
12520697045	SPRING WASHER B4 IS3063 CD PLATED	TATA spare parts
12520698017	SPRING WASHER B6 IS3063 SS8451-8C	TATA spare parts
12520698025	SPRING WASHER B8 IS3063 CD PLATED	TATA spare parts
12520698033	SPRING WASHER B4	TATA spare parts
12520698041	SPRING WASHER B5	TATA spare parts
12520698050	SPRING WASHER B10-IS3063-SS8451-8C	TATA spare parts
12520698131	SPRING WASHER B8 SS8451-13D	TATA spare parts
12520698211	SPRING WASHER B3 IS3063 SS8451-8C BS6	TATA spare parts
12521200608	SPRING WASHER B6	TATA spare parts
12521201001	SPRING WASHER 10 IS 6735 SS 8400	TATA spare parts
12521201205	SPR.WASHER B18 SS8451-11 IS:3063	TATA spare parts
12521201400	WASHER-30ODX15IDX2.6THK	TATA spare parts
12521298021	SPRING WASHER 6	TATA spare parts
12521501853	SPRING WASHER 18.5	TATA spare parts
12521502051	SPRING WASHER 20.5	TATA spare parts
12521502256	SPRING WASHER 22.5	TATA spare parts
12525100403	SPRING WASHER B4 IS3063 SS8451S2-Y	TATA spare parts
12525100501	SPRING WASHER B5 IS3063 SS8451S2	TATA spare parts
12525100608	SPRING WASHER B6 IS3063 SS8451S2-Y	TATA spare parts
12525100802	SPRING WASHER B8 IS3063 SS8451S2-Y	TATA spare parts
12525101001	SPRING WASHER B10 IS3063 SS8451S2-Y	TATA spare parts
12525101205	SPRING WASHER B12 IS3063 SS8451S2-Y	TATA spare parts
12525101400	SPRING WASHER B14 IS3063 SS8451S2-Y	TATA spare parts
12525101604	SPRING WASHER B16 IS3063 SS8451S2-Y	TATA spare parts
12525196028	SPRING WASHER B8 IS3063 SS8451S2-B	TATA spare parts
12525696101	SPRING WASHER B6 IS3063 SS8457S1	TATA spare parts
12525696128	SPRING WASHER B8 IS3063 SS8457S1-BL-B	TATA spare parts
12525696136	SPRING WASHER B10 IS3063 SS8457S1-BL-B	TATA spare parts
12525696144	SPRING WASHER B12 IS3063 SS8457S1-BL-B B	TATA spare parts
12525696152	SPRING WASHER B5 IS3063 SS8457S1-S-B	TATA spare parts
12525696195	SPRING WASHER B5 IS3063 SS8457S1-BL-B	TATA spare parts
12529000608	SPRING WASHER B6 IS3063 ST.STEEL.	TATA spare parts
125300	KWIK ADJUST	TATA spare parts
1253345001	KNURLED NUT	TATA spare parts
125407	FLYWHEEL RING ASSY	TATA spare parts
125420	KIT CERA FACING W/RIVETS	TATA spare parts
125428	CAM LOAD SPRING	TATA spare parts
125432	SEPARATOR PIN ASSEMBLY	TATA spare parts
1254490002	INSULATOR	TATA spare parts
125485	FACING & REPAIR KIT	TATA spare parts

125486	STRAP & BOLT KIT	TATA spare parts
125487	CAM KIT	TATA spare parts
125488	LEVER KIT ASSY-CONSIST 6 NO.OF 176C146	TATA spare parts
125503000002	D WINDOW ASSY(OPTYPE-FIXED-CLEAR)	TATA spare parts
125503050001	SD WINDOW ASSY(OPTYPE-FIX-GRN-PC)	TATA spare parts
125503050003	EMG. WINDOW ASSY -FIXED TYPE	TATA spare parts
125503070001	EMG WINDOW ASSEMBLY	TATA spare parts
125503070002	EMG WINDOW ASSEMBLY	TATA spare parts
125503070003	EMG WINDOW ASSEMBLY	TATA spare parts
125503080001	SIDE WINDOW ASSY	TATA spare parts
125503080002	EMG WINDOW ASSY	TATA spare parts
125503080003	SIDE WINDOW ASSY	TATA spare parts
125503080004	EMG WINDOW ASSY	TATA spare parts
125512050002	SD WINDOW ASSY(OPTYPE-3PC-TFIX-GRN)	TATA spare parts
125512050003	SIDE WIND.ASSY(1/3 TOP FIX-2/3 SLD-LIGHT	TATA spare parts
125603050005	SIDE WINDOW ASSY	TATA spare parts
125603070001	SIDE WINDOW ASSY FULL SLD	TATA spare parts
125603070002	SIDE WINDOW ASSY FULL SLD GREEN TNT	TATA spare parts
125603080001	SIDE WINDOW ASSY	TATA spare parts
125603080002	SIDE WINDOW ASSY	TATA spare parts
125604010001	WINDOW ASSEMBLY 2PC FULL SLD	TATA spare parts
125604010002	WINDOW ASSEMBLY 2PC FULL SLD	TATA spare parts
125604010003	WINDOW ASSEMBLY 2PC FULL SLD	TATA spare parts
125604010004	WINDOW ASSEMBLY 2PC FULL SLD	TATA spare parts
12560600605	SPRING WASHER A6	TATA spare parts
12560600800	SPRING WASHER A8 TS17741 SS8400	TATA spare parts
12560696017	SPRING WASHER A10	TATA spare parts
12560699016	SPRING WASHER A10	TATA spare parts
12560800604	SPRING WASHER B6 TS17741-SS8400	TATA spare parts
12560800809	SPRING WASHER B8-TS17741-	TATA spare parts
12560801007	SPRING WASHER B10	TATA spare parts
12563	LOCKWIRE	TATA spare parts
12565600808	CURVED SPR.WASHER 8 TS17739 SS8451S2-Y	TATA spare parts
12565696098	SPRING WASHER B6 IS3063 SS8457S1-S-B	TATA spare parts
125674000001	SIDE WINDOW ASSY- EMERGENCY DOOR	TATA spare parts
125674050002	SD WINDOW ASSY(OPTYPE-3PC-TFIX-GRN)	TATA spare parts
125674050003	SD WINDOW ASSY(OPTYPE-3PC-TFIX-GRN)	TATA spare parts
125674070001	WINDOW ASSY - EMG	TATA spare parts
125674090001	WINDOW ASSY - EMG	TATA spare parts
125703150001	SD WINDOW ASSY (OPTYPE-3PC-TFIX-PC)	TATA spare parts
125703150002	SD WINDOW ASSY(OPTYPE-3PC-TFIX-GRN)	TATA spare parts
125712150002	SD WINDOW ASSY(OPTYPE-3PC-TFIX-GRN)	TATA spare parts
125712150004	SD WINDOW ASSY(OPTYPE-3PC-TFIX-GRN)	TATA spare parts
125712150006	SD WINDOW ASSY(OPTYPE-3PC-TFIX-GRN)	TATA spare parts
125712150011	SIDE WIN ASSY(1/3 TOP FIX-2/3 SLD-LIGHT	TATA spare parts
125712150012	SIDE WIN ASSY(1/3 TOP FIX-2/3 SLD-LIGHT	TATA spare parts
125712150013	SIDE WIN ASSY(1/3 TOP FIX-2/3 SLD-LIGHT	TATA spare parts



125712150017	SIDE WIN ASSY(1/3 TOP FIX-2/3 SLD-LIGHT	TATA spare parts
125712150025	SD WINDOW ASSY(OPTYPE-3PC-TFIX-GRN)	TATA spare parts
125712150027	SIDE WIN ASSY(1/3 TOP FIX-2/3 SLD-LIGHT	TATA spare parts
125712150028	SIDE WIN ASSY(1/3 TOP FIX-2/3 SLD-LIGHT	TATA spare parts
125712150030	SIDE WINDOW ASSY	TATA spare parts
125712150031	SIDE WINDOW ASSY	TATA spare parts
125712160001	SID WIN ASSY CTB 1/3 TOP FIX D GRN 2/3 S	TATA spare parts
125712160002	SID WIN ASSY CTB 1/3 TOP FIX D GRN 2/3 S	TATA spare parts
125712160003	SID WIN ASSY CTB 1/3 TOP FIX D GRN 2/3 S	TATA spare parts
125712160004	SID WIN ASSY CTB 1/3 TOP FIX D GRN 2/3 S	TATA spare parts
125712180002	SIDE WINDOW ASSY	TATA spare parts
125712180003	SIDE WINDOW ASSEMBLY	TATA spare parts
125740	CLAMP T BOLT - 4-1/2 INCH	TATA spare parts
125750530001	SIDE WINDOW ASSY(SM22-1/3 FIX-2/3 SLD-CL	TATA spare parts
125774100002	SD WINDOW ASSY(OPTYPE-EMG-3PC-TFIX-GRN)	TATA spare parts
12580500844	WASHER 8.4 DIN935	TATA spare parts
12580600849	TAB WASHER 8.4	TATA spare parts
12580601055	TAB WASHER 10.5	TATA spare parts
12580601306	TAB WASHER 13	TATA spare parts
12580601501	TAB WASHER 15	TATA spare parts
12580603104	TAB WASHER 31 TS17730	TATA spare parts
12580603708	TAB WASHER 37 TYPE B	TATA spare parts
12580698016	TAB WASHER 19 TYPE-B IS8068 SS8451-8C	TATA spare parts
12580800538	WASHER A5.3	TATA spare parts
12580800643	WASHER A6.4 IS5371 SPR ST SS8400	TATA spare parts
12580800848	WASHER A8.4	TATA spare parts
12580801054	WASHER A10.5 IS5371 SS8451-8C	TATA spare parts
12580801259	M-T LOCK WASHER A12.5 IS5371-SS8400	TATA spare parts
12580898031	M-T LOCK WASHER A6.4LH IS5371 SS8451S2-Y	TATA spare parts
12580898040	M-T LOCK WASHER A8.4LH IS5371 SS8451S2-Y	TATA spare parts
12580898058	M-T LOCK WASHER A10.5 IS5371 SS8451-8C	TATA spare parts
12580900842	WASHER B8.4	TATA spare parts
12581000535	WASHER C5.3	TATA spare parts
12581000641	WASHER C6.4	TATA spare parts
12581000829	WASHER C8.2	TATA spare parts
12581000845	WASHER C8.4	TATA spare parts
12581096010	WASHER C5.3 IS 5371	TATA spare parts
12581096036	M-T LOCK WASHER C6.4 IS5371 SS8451S2-Y	TATA spare parts
12581503502	LOCK WASHER A35	TATA spare parts
12585000840	TAB WASHER 8.4 TS17730 SS8451S2-Y	TATA spare parts
12586096018	M-T LOCK WASHER C8.4-IS5371-SS8451S2-B	TATA spare parts
12586300641	M-T LOCK WASHER C6.4 IS5371SS8457S1	TATA spare parts
12586300847	M-T LOCK WASHER C8.4 IS5371SS8457S1	TATA spare parts
1259-Q-303	ANCHOR PIN- BRAKE SHOE	TATA spare parts
126187	PINION PILOT BRG	TATA spare parts
126216	NUT	TATA spare parts
126255	SLIDING CLUTCH	TATA spare parts

126301	GEAR CASE SUPPORT LH	TATA spare parts
126302	PIN-IDLER PINION	TATA spare parts
126305	DIFF BRG ADJUSTER LH	TATA spare parts
126306	PINION IDLER	TATA spare parts
126307	HIGH SPEED CLUTCH PLATE	TATA spare parts
12650600434	WASHER A4.3	TATA spare parts
12650600531	WASHER A5.3 IS5370 ST SS8451-8C	TATA spare parts
12650600647	WASHER A6.4	TATA spare parts
12650600841	WASHER A8.4	TATA spare parts
12650601058	WASHER A10.5	TATA spare parts
12650601309	WASHER A13 IS5370 ST SS8451-8C	TATA spare parts
12650601503	WASHER A15	TATA spare parts
12650601708	WASHER A17	TATA spare parts
12650698051	BRIGHT WASHER 9X13	TATA spare parts
12650698086	WASHER A6.4 IS5370 ST SS8451S2-B	TATA spare parts
12650698094	WASHER A8.4	TATA spare parts
12650698108	WASHER A4.3 BRASS IS5370	TATA spare parts
12650698116	WASHERA10.5IS5370STSS8451-13D	TATA spare parts
12650698183	WASHER A6.4 IS5370 AISI 304	TATA spare parts
12650698191	WASHER A8.4 IS5370 AISI 304	TATA spare parts
12651001054	WASHER B10.5 IS5370 ST SS8451-8C	TATA spare parts
12651001305	WASHER B13 IS5370 ST SS8451-8C	TATA spare parts
12652000647	HARDENED WASHER 6.4	TATA spare parts
12652000841	HARDENED WASHER 8.4 TS 17716	TATA spare parts
12652001058	HARDENED WASHER 10.5	TATA spare parts
12652001309	HARDENED WASHER 13	TATA spare parts
12655000435	WASHER A4.3 IS5370 ST SS8451S2-Y BS6 PH2	TATA spare parts
12655000532	WASHER A5.3 IS5370 ST SS8451S2-Y	TATA spare parts
12655000648	WASHER A6.4 IS5370 ST SS8451S2-Y	TATA spare parts
12655000842	WASHER A8.4 IS5370 ST SS8451S2-Y	TATA spare parts
12655001059	WASHER A10.5 IS5370 ST SS8451S2-Y	TATA spare parts
12655001300	WASHER A13 IS5370 ST SS8451S2-Y	TATA spare parts
12655001504	WASHER A15 IS5370 ST SS8451S2-Y	TATA spare parts
12655001709	WASHER A17-IS5370-ST-SS8451S2-Y	TATA spare parts
12655096009	WASHER A13 IS5370 STEEL SS8457S1-BL-B BS	TATA spare parts
12655096017	WASHER A8.4 IS5370 ST SS8451S2-B	TATA spare parts
12655100842	WASHER A8.4 IS5370 ST SS8457S1-S-B BS6	TATA spare parts
12655196003	WASHER B8.4 IS5370 ST SS8457S1 BL-B BS6-	TATA spare parts
12655196038	WASHER A10.5 IS5370 STEEL SS8457S1-BL-B	TATA spare parts
12655196071	HARDENED WASHER 6.4 TS17716	TATA spare parts
12655196097	WASHER A8.4 IS5370 ST SS8457S1-BL-B	TATA spare parts
1268304594	SYNCHRO.RING	TATA spare parts
1268307170	GASKET	TATA spare parts
126967	SHAFT AXLE	TATA spare parts
12701000844	SPH. WASHER 8.4 IS 4297-SS 8400	TATA spare parts
12701001051	SPHERICAL WASHER C10.5	TATA spare parts
12701096019	SPH.WASHER 13 IS4297 SS8451-8C	TATA spare parts

12701101209	CONICAL SEAT 12 TYPE-A IS4297-SS8400	TATA spare parts
12702001305	SPH.WASHER 13 IS4297 SS8451S2-Y	TATA spare parts
127195	FILLER PLUG	TATA spare parts
1272334003	SLIDING PAD	TATA spare parts
127860	RELEASE BRG & SLEEVE ASSY	TATA spare parts
12809000	OIL TANK ASSY 40 L	TATA spare parts
12815	BUSH-PEDAL SHAFT	TATA spare parts
12815000	BODY LIFTING BRACKET LH	TATA spare parts
12816000	BODY LIFTING BRACKET RH	TATA spare parts
128499	CLUTCH PLATE ASSY	TATA spare parts
12851	BUSHING PEDAL S/ HOLE	TATA spare parts
128532	CLUTCH DRIVEN DISC 352 DIA 1.75INCH G600	TATA spare parts
128580	DRIVEN DISC ASSY	TATA spare parts
128589	FRONT DRIVEN DISC	TATA spare parts
128590	REAR DRIVEN DISC	TATA spare parts
128667	DRIVEN DISC ASSEMBLY	TATA spare parts
128668	DRIVEN DISC ASSEMBLY	TATA spare parts
128861	HUB OIL SEAL	TATA spare parts
1290301140	GASKET	TATA spare parts
1290306066	SLIDING PAD	TATA spare parts
129420	SIDE PINION	TATA spare parts
1295333034	RING	TATA spare parts
1296233006	CLUTCH BODY	TATA spare parts
1296333045	SYNCHRO.RING	TATA spare parts
1297304436	PRESSURE PART	TATA spare parts
129776-12	CLUTCH COVER ASSY G-600 352 DIA	TATA spare parts
129778-12	CLUTCH PRESSURE PLATE	TATA spare parts
129859	ELBOW MALE UNION	TATA spare parts
129866	UNION MALE	TATA spare parts
12CX004Z00	TRUNNION PIVOT HOUSING	TATA spare parts
13008BB01	ALUMINIUM 25MM PIPE	TATA spare parts
13009BB01	ALUMINIUM 35MM PIPE	TATA spare parts
13012OE01	RUB RAIL BEADING	TATA spare parts
13014OE01	FRONT SHOW GUTTER BEADING	TATA spare parts
13015OE01	SIDE GUTTER BEADING	TATA spare parts
13016BP01	REAR BUMPER WEARING STRIP	TATA spare parts
13017BP01	FRONT BUMPER ALU. ANGLE	TATA spare parts
130185	CAP SCREW LONG	TATA spare parts
13020OE01	FRONT SHOW WAIST RAIL BEA	TATA spare parts
130210081359	FRONT MARKER LAMP_SFC FES 407/27	TATA spare parts
130210081360	REAR MARKER LAMP_SFC FES 407/27	TATA spare parts
130210081361	REG NUMBER PLATE LIGHT	TATA spare parts
130210081362	CABIN LAMP ASSY_SFC FES 407/27	TATA spare parts
130210081454	SEALING DRIVER DOOR - 20 MTRS ROLL	TATA spare parts
130210081501	DOOR ASSY_SFC FES 407/27	TATA spare parts
130210081504	DOOR GLASS_SFC FES 407/27	TATA spare parts
130210081509	DOOR ROLLER ASSY_SFCFES 407/27	TATA spare parts

130210081517	SEALING DOOR SIDE LH -20 MTRS ROLL	TATA spare parts
130210081518	SEALING DOOR SIDE RH - 20 MTRS ROLL	TATA spare parts
130210081519	SEALING CENTRE RH - 20 MTRS ROLL	TATA spare parts
130210081520	SEALING DOOR GLASS - 20 MTRS ROLL	TATA spare parts
130210081521	HINGE PESSERGER DOOR_ SFC FES 407/27	TATA spare parts
130210081523	J K DOOR ROLLER ASSEMBLY	TATA spare parts
130210081526	HINGE WITH HANDLE FOR PESSERGER DOOR	TATA spare parts
130210081605	SEALING DOOR GLASS - 20 MTRS ROLL	TATA spare parts
130210081606	DICKEY DOOR HINGE_ SFC FES 407/27	TATA spare parts
130210081607	REAR DICKEY LOCK	TATA spare parts
130210081652	DRIVER QUARTER WINDOW	TATA spare parts
130210081653	GLASS FIXED	TATA spare parts
130210081656	DRIVER FIXED WINDOW	TATA spare parts
130210081657	GLASS FIXED	TATA spare parts
130210081660	DRIVER DOOR WINDOW	TATA spare parts
130210081661	GLASS SLIDING	TATA spare parts
130210081662	GLASS SLIDING	TATA spare parts
130210081665	SIDE WINDOW	TATA spare parts
130210081666	GLASS SLIDING	TATA spare parts
130210081667	GLASS FIXED	TATA spare parts
130210081668	GLASS SLIDING	TATA spare parts
130210081671	CO-DRIVER WINDOW	TATA spare parts
130210081672	GLASS SLIDING	TATA spare parts
130210081673	GLASS FIXED	TATA spare parts
130210081674	GLASS SLIDING	TATA spare parts
130210081677	REAR WINDOW - EMERGENCY EXIT	TATA spare parts
130210081678	GLASS FIXED	TATA spare parts
130210081679	GLASS FIXED	TATA spare parts
130210081680	GLASS FIXED	TATA spare parts
130210081693	FLOCK CHANNEL - 4 MTRS	TATA spare parts
130210081694	LOCK ASSY	TATA spare parts
130210081696	EMMERGENCY DOOR HANDLE_ SFC FES 407/27	TATA spare parts
130210081754	TWO SEATER LH	TATA spare parts
130210081756	DRIVER SEAT	TATA spare parts
130210081757	TWO SEATER RH	TATA spare parts
130210081758	2 SEATER RH	TATA spare parts
130210081761	CO-DRIVER SEAT LH WITH LOW BACK	TATA spare parts
130210081762	2 SEATER LH WITH LOW BACK	TATA spare parts
130210081763	2 SEATER RH WITH LOW BACK	TATA spare parts
130210081765	BENCH SEAT W LEGS-WITH LOW BACK	TATA spare parts
130210081854	REAR BUMPER LH	TATA spare parts
130210081855	REAR BUMPER RH	TATA spare parts
130210081943	DASH BOARD	TATA spare parts
130210081944	ENGINE HOOD RHD	TATA spare parts
130210081952	SUNVISOR RH	TATA spare parts
130210081953	SUNVISOR LH	TATA spare parts
130210081954	REAR VIEW MIRROR (INNER)_ SFC FES 407/27	TATA spare parts

130210097000	HALF LOAD BODY W/ SUPER STR AND CANVAS T	TATA spare parts
130210098000	HALF DROP SIDE LOAD BODY SE1613TC/42	TATA spare parts
130210099688	FIXED WINDOWS GLASSES_SFC FES 407/27	TATA spare parts
130210102901	FRONT MARKER LAMP_COMFYRIDE_20SEATER	TATA spare parts
130210102902	REAR MARKER LAMP_COMFYRIDE_20SEATER	TATA spare parts
130210102906	WINDOW LOCKS	TATA spare parts
130210102908	HINGE PASSENGER DOOR	TATA spare parts
130210102909	HINGE WITH HANDLE-PASSENGER DOOR	TATA spare parts
130210102910	DOOR GLASS	TATA spare parts
130210102913	JK DOOR GLASS RUBBER BEADING	TATA spare parts
130210102914	RUBBER SEALING-4	TATA spare parts
130210102915	RUBBER SEALING-1	TATA spare parts
130210102917	RUBBER SEALING-2	TATA spare parts
130210102918	RUBBER SEALING-3	TATA spare parts
130210102920	PASSENGER DOOR LATCH	TATA spare parts
130210102924	DOOR ROLLER ASSEMBLY	TATA spare parts
130210102929	EMERGENCY DOOR GLASS	TATA spare parts
130210102933	PASSENGER DOOR LOCK BARREL TYPE	TATA spare parts
130210102938	CABIN LAMP ASSEMBLY	TATA spare parts
130210102939	SUNVISIOR RH_COMFYRIDE_20SEATER_LP407/31	TATA spare parts
130210102943	WINDOW GLASS-330X790_COMFYRIDE_20SEATE	TATA spare parts
130210102944	WINDOW GLASS-500X790_COMFYRIDE_20SEATE	TATA spare parts
130210102946	WINDOW GLASS-285X790_COMFYRIDE_20SEATE	TATA spare parts
130210102949	WINDOW GLASS -500X430_COMFYRIDE_20SEATE	TATA spare parts
130210102950	WINDOW GLASS-790X262_COMFYRIDE_20SEATE	TATA spare parts
130210102953	DOOR ASSY_COMFYRIDE_20 SEATER	TATA spare parts
130210102954	SET DOOR GLASS RUBBER BEADING_COMFYRIDE	TATA spare parts
130210102955	DICKEY DOOR HINGE	TATA spare parts
130210102956	REAR VIEW MIRROR-INNER	TATA spare parts
130210119460	RUBBER SEALING FOR DRIVER/EMERGENCY DOOR	TATA spare parts
130210119501	J K DOOR ASSEMBLY	TATA spare parts
130210119661	DRIVER FIXED GLASS	TATA spare parts
130210119665	DR DOOR WINDOW GLASS SLIDING 1	TATA spare parts
130210119666	DR DOOR WINDOW GLASS SLIDING 2	TATA spare parts
130210119671	SIDE WINDOW GLASS SLIDING 1	TATA spare parts
130210119672	SIDE WINDOW GLASS FIXED	TATA spare parts
130210119673	SIDE WINDOW GLASS SLIDING 2	TATA spare parts
130210119676	CO-DRIVER WINDOW GLASS SLIDING 1	TATA spare parts
130210119677	CO-DRIVER WINDOW GLASS FIXED	TATA spare parts
130210119678	CO-DRIVER WINDOW GLASS SLIDING 2	TATA spare parts
130210119681	SLIDING WINDOW CO-DR GLASS 1 407 CNG BUS	TATA spare parts
130210119682	FIXED WINDOW CO-DR GLASS 407 CNG BUS	TATA spare parts
130210119683	SLIDING WINDOW CO-DR GLASS 2 407 CNG BUS	TATA spare parts
130210119686	REAR WINDOW FIXED GLASS 1	TATA spare parts
130210119687	REAR WINDOW FIXED GLASS 2	TATA spare parts
130210119688	REAR WINDOW FIXED GLASS 3	TATA spare parts
130210119691	SIDE FIXED WINDOW GLASS 1 407 CNG BUS	TATA spare parts

130210119692	SIDE FIXED WINDOW GLASS 2 407 CNG BUS	TATA spare parts
130210119694	FIXED GLASS BELOW CO-DRIVER LH	TATA spare parts
130210119696	EMERGENCY DOOR WINDOW GLASS SLIDING 1	TATA spare parts
130210119697	EMERGENCY DOOR WINDOW GLASS FIXED	TATA spare parts
130210119698	EMERGENCY DOOR WINDOW GLASS SLIDING 2	TATA spare parts
130210119751	CO DRIVER SEAT LH	TATA spare parts
130210119752	TWO SEATER AT VENTING	TATA spare parts
130210119753	FIVE SEATER BENCH SEAT	TATA spare parts
130210119755	TWO SEATER RH-EMERGENCY DOOR	TATA spare parts
130210119756	TWO SEATER RH-BATTERY	TATA spare parts
130210119771	RETRACT FOOT STEP	TATA spare parts
130210141901	REAR BUMPER FRP	TATA spare parts
130210141902	REAR DICKEY LOCK	TATA spare parts
130210141903	SLIDING GLASS	TATA spare parts
130210141904	SLIDING GLASS	TATA spare parts
130210141905	SLIDING GLASS	TATA spare parts
130210141906	SLIDING GLASS	TATA spare parts
130210141907	SLIDING GLASS	TATA spare parts
130210141908	SLIDING GLASS	TATA spare parts
130210141909	SLIDING GLASS	TATA spare parts
130210141910	SLIDING GLASS	TATA spare parts
130210141911	SLIDING GLASS	TATA spare parts
130210141912	SLIDING GLASS	TATA spare parts
130210141913	SLIDING GLASS	TATA spare parts
130210141914	SLIDING GLASS	TATA spare parts
130210141915	SLIDING GLASS	TATA spare parts
130210141916	SLIDING GLASS	TATA spare parts
130210141917	REAR WINDSCREEN	TATA spare parts
130210141918	REAR WINDSHIELD RUBBER MOULDING	TATA spare parts
130210185606	DICKY DOOR HINGE	TATA spare parts
130210185666	SIDE WINDOW GLASS-SLIDING	TATA spare parts
130210185668	SIDE WINDOW GLASS-SLIDING	TATA spare parts
130210185672	CO-DRIVER WINDOW GLASS-SLIDING	TATA spare parts
130210185674	CO-DRIVER WINDOW GLASS-SLIDING	TATA spare parts
130210185678	REAR FIXED GLASS RH	TATA spare parts
130210185679	REAR EMERGENCY WINDOW GLASS	TATA spare parts
130210185680	REAR FIXED GLASS LH	TATA spare parts
130210185681	EMERGENCY DOOR HANDLE	TATA spare parts
130210185684	PEEP WINDOW GLASS	TATA spare parts
130210185979	CABIN LAMP ASSEMBLY	TATA spare parts
130210185980	SUNVISOR RH	TATA spare parts
130210185981	SUNVISOR LH	TATA spare parts
130210185991	FRONT BUMPER_UPGRADED FACE_LP709	TATA spare parts
130210185992	FRONT GRILL_UPGRADED FACE_LP709	TATA spare parts
130210185993	GARNISH LH	TATA spare parts
130210185994	GARNISH RH	TATA spare parts
130210185995	GARNISH MIDDLE	TATA spare parts

130210189163	FRONT BUMPER LPO1610/62 BUS	TATA spare parts
130210189901	GLASS FRONT WINDSHIELD BS2	TATA spare parts
130210189902	JK DOOR ASSEMBLY	TATA spare parts
130210189903	BEARING JK DOOR	TATA spare parts
130210189904	JK DOOR GLASS I	TATA spare parts
130210189905	JK DOOR GLASS II	TATA spare parts
130210189906	DASHBOARD	TATA spare parts
130210189907	PASSENGER DOOR LOCK	TATA spare parts
130210189908	REAR DICKEY LOCK	TATA spare parts
130210189909	SIDE DICKEY LOCK	TATA spare parts
130210189910	EMERGENCY DOOR LOCK	TATA spare parts
130210189911	EMERGENCY DOOR LATCH	TATA spare parts
130210189912	SIDE WINDOW GLASS 1	TATA spare parts
130210189913	SIDE WINDOW GLASS 2	TATA spare parts
130210189914	SIDE WINDOW GLASS 3	TATA spare parts
130210189915	SIDE WINDOW GLASS 4	TATA spare parts
130210189916	SIDE WINDOW GLASS 5	TATA spare parts
130210189917	EMERGENCY DOOR WINDOW GLASS	TATA spare parts
130210189919	OUTER RVM LH 1	TATA spare parts
130210189920	OUTER RVM LH2	TATA spare parts
130210189921	RUBBER SEALING DR DOOR & EMR DOOR	TATA spare parts
130210189922	RUBBER SEALING DR DOOR & EMR DOOR	TATA spare parts
130210189923	GAS SPRING REAR & SIDE DICKEY DOOR	TATA spare parts
130210189924	GAS SPRING REAR & SIDE DICKEY DOOR	TATA spare parts
130210189925	HINGE REAR & SIDE DICKEY DOOR	TATA spare parts
130210189926	HINGE REAR & SIDE DICKEY DOOR	TATA spare parts
130210189927	JK DOOR ASSY.REAR-1610_62	TATA spare parts
130210199161	FRONT BUMPER FRP	TATA spare parts
130210199901	GLASS FRONT WINDSHIELD	TATA spare parts
130210199902	REAR WINDSCREEN	TATA spare parts
130210199904	JK DOOR ROLLER ASSEMBLY	TATA spare parts
130210199907	JK DOOR HINGE I	TATA spare parts
130210199908	JK DOOR HINGE II	TATA spare parts
130210199909	JK DOOR GLASS I	TATA spare parts
130210199910	JK DOOR GLASS II	TATA spare parts
130210199911	JK DOOR RUBBER SEALING I	TATA spare parts
130210199912	JK DOOR RUBBER SEALING II	TATA spare parts
130210199913	JK DOOR RUBBER MOULDING I	TATA spare parts
130210199914	JK DOOR RUBBER MOULDING II	TATA spare parts
130210199915	REAR BUMPER FRP	TATA spare parts
130210199916	DRIVER DOOR LOCK	TATA spare parts
130210199917	PASSENGER DOOR LOCK	TATA spare parts
130210199918	PASSENGER DOOR LATCH	TATA spare parts
130210199919	SIDE DICKEY LOCK	TATA spare parts
130210199920	SIDE WINDOW GLASS I	TATA spare parts
130210199921	SIDE WINDOW GLASS II	TATA spare parts
130210199922	SIDE WINDOW GLASS III	TATA spare parts

130210199923	DRIVER DOOR WINDOW GLASS	TATA spare parts
130210199924	DRIVER PARTITION GLASS	TATA spare parts
130210199928	OUTER RVM LH IV	TATA spare parts
130210199932	SUNVISOR RH	TATA spare parts
130210199933	RUBBER SEALING DR DOOR & EMER DOOR	TATA spare parts
130210199934	GAS SPRING REAR & DICKEY DOOR	TATA spare parts
130210199935	HEADLAMP LH I	TATA spare parts
130210199936	HEADLAMP LH II	TATA spare parts
130210199937	JK DOOR ASSY_FRONT-2_RE SLF	TATA spare parts
130210199938	JK DOOR ASSY.REAR-1_RE SLF	TATA spare parts
130210199939	BLINKER LH	TATA spare parts
130210199940	BLINKER RH	TATA spare parts
130210199941	FOG LAMP LH	TATA spare parts
130210199942	FOG LAMP RH	TATA spare parts
130210199943	SIDE INDICATOR LAMP LH	TATA spare parts
130210199944	SIDE INDICATOR LAMP RH	TATA spare parts
130210199945	HEIGHT MARKER LAMP FRONT	TATA spare parts
130210199946	HEIGHT MARKER LAMP REAR	TATA spare parts
130210199947	REAR LICENCE PLATE LAMP	TATA spare parts
130210199948	CABIN LAMP- DRIVER & PASSENGER	TATA spare parts
130210199949	PASSENGER CABIN LAMP	TATA spare parts
130210199951	JK DOOR ASSY.REAR-2_RE SLF	TATA spare parts
130210199954	TAIL LAMP 1	TATA spare parts
130210199955	TAIL LAMP 2	TATA spare parts
130210199956	TAIL LAMP 3	TATA spare parts
130210199957	T BEADING FOR 1510 STAR BUS_10MTRS	TATA spare parts
130210412901	JK DOOR ASSEMBLY	TATA spare parts
130210412902	JK DOOR GLASS I	TATA spare parts
130210412903	JK DOOR GLASS II	TATA spare parts
130210412904	FRP FRONT BUMPER I	TATA spare parts
130210412905	FRONT BUMPER II	TATA spare parts
130210412906	FRP REAR BUMPER II	TATA spare parts
130210412907	PASSENGER DOOR LOCK	TATA spare parts
130210412908	SIDE WINDOW GLASS1	TATA spare parts
130210412909	SIDE WINDOW GLASS 2	TATA spare parts
130210412910	SIDE WINDOW GLASS 3	TATA spare parts
130210412911	SIDE WINDOW GLASS 4	TATA spare parts
130210412912	INNER RVM	TATA spare parts
130210412913	HEADLAMP LH	TATA spare parts
130210412914	HEADLAMP RH	TATA spare parts
130210412915	BLINKER LH	TATA spare parts
130210412916	BLINKER RH	TATA spare parts
130210413902	JK DOOR GLASS I	TATA spare parts
130210413903	JK DOOR GLASS II	TATA spare parts
130210413904	FRP REAR BUMPER	TATA spare parts
130210413905	SIDE WINDOW GLASS1	TATA spare parts
130210413906	SIDE WINDOW GLASS 2	TATA spare parts



130210413907	SIDE WINDOW GLASS 3	TATA spare parts
130210413908	1IDE WINDOW GLASS 4	TATA spare parts
130210413909	EMERGENCY DOOR WINDOW GLASS	TATA spare parts
130210413910	OUTER RVM LH/RH	TATA spare parts
130210413911	HEADLAMP LH	TATA spare parts
130210413912	HEADLAMP RH	TATA spare parts
130210413913	BLINKER LH	TATA spare parts
130210413914	BLINKER RH	TATA spare parts
13023BB01	ALUMINUM FRAME FOR GLASS	TATA spare parts
1303300010	HEX NUT	TATA spare parts
1304207002	STUD	TATA spare parts
1304207058	DETENT PLUNGER	TATA spare parts
1304233006	CLUTCH BODY	TATA spare parts
1304301034	COVER	TATA spare parts
1304301305	GASKET	TATA spare parts
1304301318	COVER	TATA spare parts
1304301382	HOUSING	TATA spare parts
1304301409	SPEEDO.COVER	TATA spare parts
1304301410	SPEEDOMETER COVER	TATA spare parts
1304302232	SEALING CAP	TATA spare parts
1304302349	CONN.PLATE	TATA spare parts
1304302440	COVER	TATA spare parts
1304304050	BUSH	TATA spare parts
1304304443	SLEEVE CARRIER	TATA spare parts
1304304444	SLIDING SLEEVE	TATA spare parts
1304304543	HELICAL GEAR	TATA spare parts
1304304553	HELICAL GEAR	TATA spare parts
1304304591	SYNCHRO.BODY	TATA spare parts
1304304597	SLIDING SLEEVE	TATA spare parts
1304305030	STUD	TATA spare parts
1304305045	REV.IDLER GEAR	TATA spare parts
1304306089	BEARING PLATE	TATA spare parts
1304306090	BEARING PLATE	TATA spare parts
1304306107	SLIDING PAD	TATA spare parts
1304306108	ARTICULAT.BOLT	TATA spare parts
1304307083	PLATE	TATA spare parts
1304307331	COVER	TATA spare parts
1304333011	SLIDING SLEEVE	TATA spare parts
1304334063	GEAR SHIFT FORK	TATA spare parts
1304334079	CYLINDER	TATA spare parts
1304338045	WASHER	TATA spare parts
1304338097	OUTPUT FLANGE	TATA spare parts
130440749000	ATTACHMENT FOR GEAR BOX 1628 DIVO	TATA spare parts
13050504063	CYL PIN 3M6X6 IS2393 BS6	TATA spare parts
13050504209	CYLINDRICAL PIN 3M6X20	TATA spare parts
13050505086	CYL PIN 4M6X8	TATA spare parts
13050505256	CYL PIN 4M6X25 IS2393	TATA spare parts

13050506104	CYL PIN 5m6X10 IS2393	TATA spare parts
13050506121	CYL PIN 5M6X12 IS2393	TATA spare parts
13050506309	CYL PIN 5M6X30-IS2393	TATA spare parts
13050507127	CYL PIN 6m6X12 IS 2393	TATA spare parts
13050507143	CYL PIN 6M6 X 14	TATA spare parts
13050507160	CYL PIN 6M6X16 IS2393	TATA spare parts
13050508166	CYL PIN 8M6 X 16	TATA spare parts
13050508204	CYL PIN 8M6 X 20	TATA spare parts
13050508255	CYL PIN 8 M 6X25	TATA spare parts
13050509251	CYL PIN 10M6 X 25	TATA spare parts
13050509405	CYL PIN 10 M 6X40	TATA spare parts
13050510250	CYL PIN 12 M 6X25 IS2393	TATA spare parts
13050510306	CYL PIN 12 M 6X30 IS2393	TATA spare parts
13050907109	CYL PIN 6H8 X 10	TATA spare parts
13050907168	CYL PIN 6H8 X 16	TATA spare parts
13050909209	CYL PIN 10H8 X 20	TATA spare parts
13050909250	CYL PIN 10H8 X 25	TATA spare parts
13050910258	CYL PIN 12H8 X 25	TATA spare parts
13050910304	CYL PIN 12H8 X 30	TATA spare parts
13050911351	CYL.PIN 16H8 X 35	TATA spare parts
13052005161	CYL PIN 4M6 X 16	TATA spare parts
13055505084	CYL PIN 4M6X8 IS2393 SS8451S2-Y	TATA spare parts
13055507109	CYL PIN 6M6X10 IS2393 SS8451S2-Y	TATA spare parts
13056096005	PARALLEL PIN	TATA spare parts
13080604453	TAPER PIN A 4X45	TATA spare parts
13100605206	GROOVED PIN 4 X 20	TATA spare parts
13100605320	GROOVED PIN 4 X 32	TATA spare parts
13100606202	GROOVED PIN 5 X 20	TATA spare parts
13100606326	GROOVED PIN 5X32 IS7383 SS8451-8C	TATA spare parts
13102104085	GROOVED PIN 4 X 8	TATA spare parts
13102104204	GROOVED PIN 4 X 20	TATA spare parts
13102104280	GROOVED PIN 4X28	TATA spare parts
13102104450	GROOVED PIN 4X45	TATA spare parts
13102105103	GROOVED PIN 5 X 10	TATA spare parts
13102105120	GROOVED PIN 5 X 12	TATA spare parts
13102105201	GROOVED PIN 5 X 20	TATA spare parts
13102105324	GROOVED PIN 5X32 IS12952 SS8451-8C	TATA spare parts
13105008265	GROOVED PIN 8X26 IS12952 SS8451S2-Y BS6	TATA spare parts
1311304103	SLIDING SLEEVE	TATA spare parts
1311304255	SYNCHRO.RING	TATA spare parts
13120406242	DOWEL SLEEVE LIGHT 3.5X24 TS17616 SS8400	TATA spare parts
13120412145	DOWEL SLEEVE LIGHT 10X14 TS17616SS8400	TATA spare parts
13120505101	DOWEL SLEEVE HEAVY 3X10 TS17616 SS8400	TATA spare parts
13120505208	DOWEL SLEEVE HEAVY 3 X 20	TATA spare parts
13120505224	DOWEL SLEEVE HEAVY 3 X 22	TATA spare parts
13120505283	DOWEL SLEEVE HEAVY 3 X 28	TATA spare parts
13120506328	DOWEL SLEEVE HEAVY 3.5X32 TS17616 SS8400	TATA spare parts

13120506450	DOWEL SLEEVE HEAVY 3.5X45	TATA spare parts
13120507201	DOWEL SLEEVE HEAVY 4 X 20	TATA spare parts
13120507227	DOWEL SLEEVE HEAVY 4X22 TS17616 SS8400	TATA spare parts
13120507243	DOWEL SLEEVE HEAVY 4X24 TS17616 SS8400	TATA spare parts
13120507324	DOWEL SLEEVE HEAVY 4X32 TS17616 SS8400	TATA spare parts
13120509220	DOWEL SLEEVE HEAVY 5 X 22	TATA spare parts
13120509246	DOWEL SLEEVE HEAVY 5X24 TS17616 SS8400	TATA spare parts
13120509262	DOWEL SLEEVE HEAVY 5 X 26	TATA spare parts
13120509289	DOWEL SLEEVE HEAVY 5 X 28	TATA spare parts
13120509301	DOWEL SLEEVE HEAVY 5X30-IS5988-SS8400	TATA spare parts
13120509360	DOWEL SLEEVE HEAVY 5 X 36	TATA spare parts
13120509408	DOWEL SLEEVE HEAVY 5 X 40	TATA spare parts
13120510104	DOWEL SLEEVE HEAVY 6 X 10	TATA spare parts
13120510244	DOWEL SLEEVE HEAVY 6X24 TS17616 SS8400	TATA spare parts
13120510325	DOWEL SLEEVE HEAVY 6X32 TS17616 SS8400	TATA spare parts
13120510406	DOWEL SLEEVE HEAVY 6X40 TS17616 SS8400	TATA spare parts
13120510457	DOWEL SLEEVE HEAVY 6 X 45	TATA spare parts
13120510503	DOWEL SLEEVE HEAVY 6 X 50	TATA spare parts
13120511364	DOWEL SLEEVE HEAVY 8 X 36	TATA spare parts
13120511402	DOWEL SLEEVE HEAVY 8 X 40	TATA spare parts
13120512409	DOWEL SLEEVE HEAVY 10 X40	TATA spare parts
13120596017	DOWEL SLEEVE HEAVY 6X20 TS17616SS8451-8C	TATA spare parts
13121206247	SPIRAL PIN 6X24	TATA spare parts
1313207005	BOLT	TATA spare parts
1313333001	SYNCHRO.BODY	TATA spare parts
131500000042	WASHER SEALING	TATA spare parts
131500000125	ASSY. GREASING PIPE (FOR CL. REL BRG)	TATA spare parts
131500000126	COVER (CL. HOUSING-LOWER)	TATA spare parts
131500000130	NEW FUEL FLEX PIPE - 2515	TATA spare parts
13150605088	SPLIT PIN 1.6 X 8	TATA spare parts
13150605100	SPLIT PIN 1.6 X 10	TATA spare parts
13150605126	SPLIT PIN 1.6 X 12	TATA spare parts
13150605207	SPLIT PIN 1.6 X 20	TATA spare parts
13150606106	SPLIT PIN 2 X 10	TATA spare parts
13150606149	SPLIT PIN 2 X 14	TATA spare parts
13150606165	SPLIT PIN 2 X 16	TATA spare parts
13150606181	SPLIT PIN 2 X 18	TATA spare parts
13150606203	SPLIT PIN 2 X 20	TATA spare parts
13150606254	SPLIT PIN 2 X 25	TATA spare parts
13150608141	SPLIT PIN 3.2 X 14	TATA spare parts
13150608168	SPLIT PIN 3.2 X 16	TATA spare parts
13150608184	SPLIT PIN	TATA spare parts
13150608206	SPLIT PIN 3.2X20-IS549-SS8451-8C	TATA spare parts
13150608222	SPLIT PIN 3.2 X 22	TATA spare parts
13150608257	SPLIT PIN 3.2 X 25	TATA spare parts
13150608281	SPLIT PIN 3.2 X 28	TATA spare parts
13150608320	SPLIT PIN 3.2 X 32	TATA spare parts

13150608362	SPLIT PIN 3.2X36 IS549 SS8451-8C	TATA spare parts
13150608401	SPLIT PIN 3.2X40-IS549-SS8451S2-Y	TATA spare parts
13150608508	SPLIT PIN 3.2 X 50	TATA spare parts
13150609181	SPLIT PIN 4 X 18	TATA spare parts
13150609229	SPLIT PIN 4 X 22	TATA spare parts
13150609288	SPLIT PIN 4 X 28	TATA spare parts
13150609326	SPLIT PIN 4 X 32	TATA spare parts
13150609369	SPLIT PIN 4 X 36	TATA spare parts
13150609407	SPLIT PIN 4 X 40	TATA spare parts
13150609458	SPLIT PIN 4X45 IS549 SS8451-8C	TATA spare parts
13150610367	SPLIT PIN 5X36 RIVIGO	TATA spare parts
13150610405	SPLIT PIN 5 X 40	TATA spare parts
13150610456	SPLIT PIN 5 X 45	TATA spare parts
13150610502	SPLIT PIN 5 X 50	TATA spare parts
13150611568	SPLIT PIN 6.3 X 56	TATA spare parts
13150611614	SPLIT PIN 6.3 X 63	TATA spare parts
131509130014	HOSE1350MM FOR AIR FILTR HCBS CNG	TATA spare parts
131509130016	HOSE (AIR INTAKE DUCT) FOR CNG BEST	TATA spare parts
131514600001	PIPE-INTERCOOLER TO ENGINE	TATA spare parts
131514600002	BENT PIPE ( TC TO IC ) LPO1318 LHD	TATA spare parts
131514600003	PIPE (TURBO CHARGER TO INTER COOLER )	TATA spare parts
131514600004	PIPE(INTERCOOLER TO INLET MANIFOLD)	TATA spare parts
131520120001	ASSY THERMOSTAT (PLASTIC IMPELLER PUMP)	TATA spare parts
131526000012	ASSY. TURNING TUBE (W/O BALL JOINT)	TATA spare parts
131526000013	ASSY TURNING TUBE (W/O BALL JOINT)	TATA spare parts
131529000013	ASSY 6 DIA CLUTCH PIPE FOR LPO HCBS	TATA spare parts
131529000014	ASSY 6 DIA CLUTCH PIPE FOR LPO HCBS	TATA spare parts
131529000015	ASSY 6 DIA CLUTCH PIPE FOR LPO 697 BS2	TATA spare parts
131529000020	ASSY. PIPE - CMC TO CL. FLUID CON.	TATA spare parts
131529000023	RUBBER HOSE (CONT. TO MASTER CYL.)	TATA spare parts
131529000027	CLUTCH PEDAL STOPPER RE SLF	TATA spare parts
131529000028	ASSY 6 DIA PIPE FROM CMC TO CL. BOOSTER	TATA spare parts
131529000036	6 DIA CLUTCH PIPE LPT 2518 G600 1ST	TATA spare parts
131529000039	PIPE 6 DIA FROM PURGE TANK TO CLUTCH BOO	TATA spare parts
131530000001	ASSY STOPPER - LPO1616/1610	TATA spare parts
131530000003	MALE CONNECTOR (ACCELERATOR SENSOR)	TATA spare parts
131531200043	PLATE	TATA spare parts
131531700001	ASSY. ENGINE ENCAPSULATION (RH)	TATA spare parts
131531700002	ASSY. NOISE SHIELD ( OIL SUMP)	TATA spare parts
131531700003	ASSY. ENGINE ENCAPSULATION (RH)	TATA spare parts
131532100001	KIT LEVELING VALVE FRT-SUSP-HCBS	TATA spare parts
131532100004	LEVER AT AXLE (FOR LEVELLING ARGMT)	TATA spare parts
131532100006	KIT KNEELING ARGMT - HCBS	TATA spare parts
131532100017	SET CAP NUT & FERRULE FOR 6 DIA PIPE	TATA spare parts
131532100088	ANTI ROLL BAR BUSH	TATA spare parts
131532100095	SHIM 1.0 MM	TATA spare parts
131532400005	ASSY SUSPENSION KIT (AXLE FITMENT PARTS)	TATA spare parts

131532400006	ASSY SUSPENSION KIT(FRAME FITMENT PARTS)	TATA spare parts
131532400007	ASSY SUSPENSION KIT (LINE FITMENT PARTS)	TATA spare parts
131532400028	HEX BOLT 14X55X1.5	TATA spare parts
131532400042	HEX BOLT 16X1.5X120	TATA spare parts
1315334011	ARTICULAT.BOLT	TATA spare parts
1315334041	PISTON	TATA spare parts
131541300001	SPACER PLATE	TATA spare parts
131542000002	ASSY PIPE 18 DIA X 400-INTAKE TO COMP.	TATA spare parts
131542000003	ASSY PIPE 18 DIA X 1200 INTAKE TO COMP.	TATA spare parts
131542000008	T CONNECTOR FOR STOP LT SWITCH - 1616	TATA spare parts
131542000028	BRACKET ( FOR FIT.ON REAR AXLE)	TATA spare parts
131542000041	ASSY PIPE FROM AIR COMP. TO DDU(LAST PC)	TATA spare parts
131542800021	PIPE(ADD. COMPRESSOR HEAD TO AIR DRIER )	TATA spare parts
131542800023	PIPE AC AIR INLET	TATA spare parts
131542900012	BRACKET FOR P.STG. PIPE LINE ON LP/TC	TATA spare parts
131542900019	ASSY PIPE 18 DIA (AIR COMP) ON LPO1512TC	TATA spare parts
131542900021	ASSY PIPE 15 DIA (DRIER TO COMP)LPO1510T	TATA spare parts
131542900036	ASSY. PIPE (15 O.D.) - A/C TO CONSEP	TATA spare parts
131542900037	ASSY. PIPE (15 O.D.)-CONSEP TO CONNECTOR	TATA spare parts
131542900038	ASSY PIPE (15 O.D.)-TEE TO BRK ACTUA. RH	TATA spare parts
131542900046	ASSY HOSE	TATA spare parts
131542900068	ASSY.METAL PIPE COMP TO HOSE(DIA18)	TATA spare parts
131542900069	ASSY.METAL PIPE HOSE TO INT.JOINT(DIA18)	TATA spare parts
131542900070	ASSY.METAL PIPE INT.JOINT TO DDU(DIA18)	TATA spare parts
131542900077	ASSY PIPE INT. TO AIR DRYER	TATA spare parts
131542900096	ASSY.HOSE 3/8IN & 600 MM LENGTH	TATA spare parts
131543100015	BKT. FOR QRV MTG.	TATA spare parts
131543800003	ASSY BRACKET - LH (FOR RADIATOR MTG.)	TATA spare parts
131543800004	RETARDER PIPE LINE - RH	TATA spare parts
131543800005	RETARDER PIPE LINE - LH	TATA spare parts
131543800006	RETARDER PIPE BRACKET - FRONT	TATA spare parts
131543800007	RETARDER PIPE BRACKET - MIDDLE RH	TATA spare parts
131543800008	RETARDER PIPE BRACKET - MIDDLE LH	TATA spare parts
131543800009	BRACKET FOR NYLON PIPE T JOINT	TATA spare parts
131543800010	HAND LEVER BRACKET STICKER	TATA spare parts
131543800013	MOUNTING BRACKET - RH SIDE (INST. CL.)	TATA spare parts
131543800018	ASSY.PIPE CLAMP(RETARDER PIPE 30DIA)	TATA spare parts
131543800019	ASSY PIPE CLAMP	TATA spare parts
131543800031	ASSY.METAL PIPE HOSE TO INT.JOINT(DIA18)	TATA spare parts
131543800032	ASSY.METAL PIPE INT.JOINT TO DDU(DIA18)	TATA spare parts
131543800033	PIPE 18 DIA AIR COMPRESSOR TO TEFLON HOS	TATA spare parts
131543900001	ASSY TUBE WITH CRIMPED R/HOSE LPT2515	TATA spare parts
131543900064	METAL PIPE DIA 15 COMPRESSOR TO DDU	TATA spare parts
131543900118	12DIA PIPE SPV (1) TO AIR DRIER RH (21)	TATA spare parts
131543900119	12DIA PIPE SPV (FRT.) TO A/TANK LH FRT.	TATA spare parts
131543900120	12DIA PIPE SPV TO A/TANK FRT. RH	TATA spare parts
131543900121	12DIA PIPE TEE (REAR) TO A/TANK REAR RH	TATA spare parts

131543900122	12DIA PIPE TEE (REAR) TO A/TANK REAR LH	TATA spare parts
131543900123	6DIA PIPE GHCV TO SPV(23)-3SOCKET TO SPV	TATA spare parts
131543900124	6DIA PIPE CL. BOOSTER TO RR. RH A/TANK-4	TATA spare parts
131543900125	18DIA PIPE BELT DRIVEN COMP. TO A/D RH-3	TATA spare parts
131543900126	18DIA PIPE BELT DRIVEN CONSEP TO A/D RH	TATA spare parts
131543900127	18DIA PIPE CAM DRIVEN COMP. TO A/D LH-3	TATA spare parts
131543900128	18DIA PIPE CAM DRIVEN COMP. TO A/D LH-4	TATA spare parts
131543900129	18DIA PIPE CAM DRIVEN CONSEP TO A/D LH	TATA spare parts
131543900134	18 DIA 2ND METAL PIPE	TATA spare parts
131543900156	ASSY.METAL PIPE 18 O.D SECOND	TATA spare parts
131543900157	ASSY THIRD PIPE (18DIA)	TATA spare parts
131543900158	ASSY FOURTH PIPE (DIA 18)	TATA spare parts
131543900160	18 DIA METAL PIPE 2ND	TATA spare parts
131543900175	METAL PIPE-6DIA-COMPRESSOR CONTROL PORT	TATA spare parts
131543900178	CRIMPED METAL PIPE 12DIA (DTV12 TO A/T)	TATA spare parts
131543900179	CRIMPED METAL PIPE 12DIA (DTV11 TO RVAL)	TATA spare parts
131543900182	ASSY METAL PIPE (18 DIA)-SECOND	TATA spare parts
131543900183	ASSY METAL PIPE (18 DIA)- THIRD	TATA spare parts
131543900201	ASSY METAL PIPE 12 DIA ( RST TO TEE)	TATA spare parts
131543900202	COMPRESSOR TO DDU 2ND PIPE 15 DIA	TATA spare parts
131543900203	COMPRESSOR TO DDU 3RD PIPE 15 DIA	TATA spare parts
131543900204	MASTER CYL TO BOOSTER PIPE 1ST 1ST -6 DI	TATA spare parts
131543900205	MASTER CYL TO BOOSTER PIPE 2ND 1ST-6 DIA	TATA spare parts
131546000004	ASSY PLUG	TATA spare parts
131546800011	ASSY 18 DIA PIPE CRIMPED (TANK TO PUMP)	TATA spare parts
131546800013	P/S PIPE (G.B TO TANK)-NIPPLE TYPE 1616	TATA spare parts
131546800017	ASSY P/STG. CRIMPED PIPE PUMP TO TANK	TATA spare parts
131546800018	ASSY P/STG. CRIMPED PIPE STG. GB TO TANK	TATA spare parts
131546800019	ASSY P/STG. CRIMPED PIPE PUMP TO STG G.B	TATA spare parts
131546800023	ASSY PIPE (STG PUMP TO POWER STG. TANK)	TATA spare parts
131546800025	PIPE AC LUB OUTLET	TATA spare parts
131546800039	ASSY PIPE FROM STG. PUMP TO STG. G.BOX	TATA spare parts
131546800040	KIT PIPE LINE POWER STG RANE 2515TC BS2	TATA spare parts
131546800055	ASSY PIPE FROM STG. PUMP TO STG. G.BOX	TATA spare parts
131546800060	ASSY. P/STG. PIPE KIT-LPO CNG BS3	TATA spare parts
131546800064	ASSY. P/STG. PIPE KIT-LPO 1613 CNG BSIII	TATA spare parts
131546800067	ASSY. P/STG. PIPE KIT-LPO1613CNG	TATA spare parts
131546800068	ASSY P/STG CRIMP PIPE STG G.B TO TANK	TATA spare parts
131546800069	ASSY P/STG CRIMP PIPE STG PUMP TO TANK	TATA spare parts
131546800070	ASSY P/STG VANE PUMP TO P STG G BOX PIPE	TATA spare parts
131546800071	ASSY P/STG PIPE STG G BOX TO OIL CONT.	TATA spare parts
131546800072	ASSY P/STG CRIMP PIPE STG G.B TO TANK	TATA spare parts
131546800073	ASSY P/STG CRIMP PIPE STG PUMP TO TANK	TATA spare parts
131546800087	ASSY PIPE FROM STG. PUMP TO STG. G.BOX	TATA spare parts
131546800088	ASSY. P/STG. PIPE KIT	TATA spare parts
131547100005	ASSY FUEL LINE FOR LPO1616 TC	TATA spare parts
131547100010	ASSY FUEL LINE 15 DIA FOR LPO1616 TC	TATA spare parts

131547100011	ASSY FUEL LINE 15 DIA FOR LPO1616 TC	TATA spare parts
131547100012	ASSY FUEL RETURN LINE 10 DIA FOR LPO1616	TATA spare parts
131547100013	ASSY FUEL RETURN LINE 10 DIA FOR LPO1616	TATA spare parts
131547100027	PROTECTIVE COVER LOW PR. HOSE-32 DIA	TATA spare parts
131547100052	ASSY HP GAS PIPE 1/4INCH OD	TATA spare parts
131547100054	ASSY SUCTION FUEL LINE 10 DIA.	TATA spare parts
131547100055	ASSY RETURN FUEL LINE 6 DIA.	TATA spare parts
131547100058	ASSY.TUBE(WITH CRIMPED R/HOSE)SUCT1512LH	TATA spare parts
131547100059	ASSY.TUBE(WITH CRD R/HOSE)RETURN1512 LHD	TATA spare parts
131547100070	ASSY BRKT FOR LP 909	TATA spare parts
131547100077	ASSY FUEL LINE FOR LPO1618 JNNURM	TATA spare parts
131547100083	INTE. JOINT TO BABY FILTER 15 O.D.	TATA spare parts
131547100084	ASSY SUCTION FUEL LINE WITH 15 DIA	TATA spare parts
131547100085	ASSY FUEL LINE FOR LPO1618 JNNURM	TATA spare parts
131547600031	MALE CONNECTOR 1/8INCH NPT X 1/4INCH ODT	TATA spare parts
131547600039	SS TUBE-1/4INCH OD	TATA spare parts
131547600084	12DIA VENT PIPE FRT. CYL. TO TEE (LH)	TATA spare parts
131547600085	12DIA VENT PIPE RR. CYL. TO TEE (LH))	TATA spare parts
131547600086	12DIA VENT PIPE CONN TO TEE (LH)	TATA spare parts
131547600087	12DIA VENT PIPE TEE TO 22 DIA SKT (LH)	TATA spare parts
131547600088	12DIA VENT PIPE CONN 2 TO TEE (RH)	TATA spare parts
131547600089	12DIA VENT PIPE 5TH CYL TO TEE (RH)	TATA spare parts
131547600090	12DIA VENT PIPE TEE TO 22 DIA SKT (RH)	TATA spare parts
131547610028	ASSY VENTING TUBE	TATA spare parts
131547610036	ASSY PIPE VENTING REAR CYLIND LP 407 CNG	TATA spare parts
131547610037	ASSY BURST DISC IMPROVED	TATA spare parts
131547610048	ASSY VENT LINE REAR CYL	TATA spare parts
131547610050	DOUBLE SOCKET (12OD PIPE X 22 OD PIPE)	TATA spare parts
131547700001	PLUNGER ASSY.	TATA spare parts
131547700002	SEAL KIT	TATA spare parts
131549000025	ASSY BRACKET FOR HEAT SHIELD MTG. IN 407	TATA spare parts
131549000045	ASSY FLEXIBLE EXHAUST PIPE	TATA spare parts
131549000054	BRACKET EXHAUST PIPE MOUNTING FRONT	TATA spare parts
131549000056	ASSY. BRACKET (EXHAUST MTG.)	TATA spare parts
131549000057	ASSY. BRACKET (EXHAUST MTG)	TATA spare parts
131550000024	WATER FILLER PIPE WITH ARMY COLOUR	TATA spare parts
131550000027	ASSY VENT TUBE (AUX. WATER TANK TO ENG)	TATA spare parts
131550000029	VENT TUBE(ENG.TO A.W.TANK)	TATA spare parts
131550000030	VENT TUBE(FROM RAD.TO A.W.TANK)	TATA spare parts
131550000038	DIPSTICK FOR COOLANT TANK	TATA spare parts
131550000049	VENT TUBE (ENGINE TO TANK)	TATA spare parts
131550000050	VENT TUBE (RADIATOR TO TANK)	TATA spare parts
131550000051	WATER FILLER PIPE	TATA spare parts
131550000052	VENT TUBE(ENG.TO A.W.TANK)	TATA spare parts
131550000053	VENT PIPE (RADIATOR TO AUX WATER)	TATA spare parts
131550000054	VENT TUBE(ENG.TO A.W.TANK)	TATA spare parts
131550000055	VENT PIPE (RADIATOR TO AUX WATER TANK)	TATA spare parts

13155000062	WATER FILLER PIPE	TATA spare parts
13155005101	SPLIT PIN 1.6X10 IS549 SS8451S2-Y	TATA spare parts
13155005127	SPLIT PIN 1.6X12 BS6-PH2	TATA spare parts
13155006140	SPLIT PIN 2X14 IS549 SS8451S2-Y	TATA spare parts
13155006182	SPLIT PIN 2X18	TATA spare parts
13155006204	SPLIT PIN 2X20	TATA spare parts
13155008207	SPLIT PIN 3.2X20 IS549 SS8451S2	TATA spare parts
13155008401	SPLIT PIN 3.2X40	TATA spare parts
13155009327	SPLIT PIN 4X32 IS549 SS8451S2-Y BS6-PH2	TATA spare parts
13155009360	SPLIT PIN 4X36 IS549 SS8451S2-Y	TATA spare parts
13155010457	SPLIT PIN 5X45 IS549 SS8451S2-Y BS6	TATA spare parts
13155296083	SPLIT PIN 3.2X22 IS549 SS8457S1-BL-B BS6	TATA spare parts
131554100012	W/H FOR EXHAUST SYSTEM - LPO/TC-UPSRTC	TATA spare parts
131554100016	WIRING HARNESS FOR EXH. BRAKE CONN.	TATA spare parts
131554100026	ASSY BATTERY CABLE + VE	TATA spare parts
131554100027	ASSY BATTERY CABLE - VE	TATA spare parts
131554100030	BATT CUT OFF SW SINGLE POLE	TATA spare parts
131554100037	60 AMP. MAXI FUSE	TATA spare parts
131554100040	RETRO KIT FOR COVER STARTER RELAY LPO151	TATA spare parts
131554100056	PIGTAIL FOR HORN	TATA spare parts
131554200053	SPEEDO METER 1:0.88RANGE 0-140KMPH	TATA spare parts
131554200057	PIG TAIL W/H SUITABLE FOR GEAR BOX G600	TATA spare parts
131554200061	SHORTENING CONNECTOR FOR BATT CUTOFF SW	TATA spare parts
131554200069	PIG TAIL FOR HP SENSOR	TATA spare parts
131554210037	2 POLE CONNECTOR (WATER PROOF) - MALE	TATA spare parts
131554210038	2 POLE CONNECTOR (WATER PROOF) - FEMALE	TATA spare parts
131554210039	TERMINAL - MALE	TATA spare parts
131554210040	TERMINAL -FEMALE	TATA spare parts
131554210041	RUBBER SEAL	TATA spare parts
131554500001	FUSE 5 AMP FOR MSSL WIRING HARNESS	TATA spare parts
131554500002	FUSE 10 AMP FOR MSSL WIRING HARNESS	TATA spare parts
131554500013	W/H-PIG TAIL -ABS GND SPLY (2000 MM)	TATA spare parts
131554500014	MAXI FUSE 30 AMP	TATA spare parts
131560100015	ASSY COWL SHELL PAINTED RHD	TATA spare parts
131560100016	ASSY COWL SHELL PAINTED RHD	TATA spare parts
131560100022	ASSY COWL SHELL PAINTED RHD LPT3118	TATA spare parts
131560100058	ASSY COWL SHELL PAINTED RHD LPT3118BS3	TATA spare parts
131560100067	COWL SHELL PAINTED LPT311	TATA spare parts
131560100070	COWL SHELL PAINTED LPT3118-259260120101	TATA spare parts
131560100074	BASE STRUC FES LOWER COWL	TATA spare parts
131575200002	ASSY T EMBLEM(OVAL STYLE)-CHROME PLATED	TATA spare parts
131581900001	ASSY ENGINE SHIELDING RH - RHD	TATA spare parts
131588500020	ASSY.BUMPER WITH ARMY COLOUR	TATA spare parts
131588500035	ASSY ENGINE HOOD FOR LPO-LHD	TATA spare parts
131591000014	ASSY. DRIVER SEAT MTG. BRACKET	TATA spare parts
131620150002	SWING ARM ASSY WITH BUSH FOR RE BUS	TATA spare parts
131625000001	CLUTCH DISC COVER&BRG ASSY 380 DIA	TATA spare parts



13162600009	ASSY G.B. REAR HALF WITH SEALING PLUG	TATA spare parts
13162600010	ASSY. BKT. WITH DOME & COVER	TATA spare parts
13162910002	ASSY SLAVE CYLINDER MOUNTING BRACKET	TATA spare parts
131629100013	ASSY SLAVE CYLINDER MOUNTING BRACKET	TATA spare parts
131630100001	ACC PDEEL STOPPER BOLT	TATA spare parts
131630100004	ASSY ACC. CONTROL COMPLETE	TATA spare parts
131630100005	ASSY ACC. CONTROL COMPLETE -LPO1512/1616	TATA spare parts
131630100006	ASSY ACC. CONTROL COMPLETE	TATA spare parts
131630100008	ASSY CONTROL SHAFT WITH BRACKET	TATA spare parts
131630100010	ASSY ACC. CONTROL COMPLETE -LPO1512KSRTC	TATA spare parts
131630100011	ASSY CONTROL SHAFT WITH BRACKET	TATA spare parts
131630100014	ASSY ACC. CONTROL COMPLETE	TATA spare parts
131630100015	ASSY STOPPER WITH RUBBER CAP & H.NUT-TC	TATA spare parts
131630100019	ASSY CONTROL SHAFT WITH BRACKET	TATA spare parts
131630100023	ASSY CONTROL SHAFT WITH BRACKET	TATA spare parts
131630100024	ASSY ACC. CONTROL COMPLETE	TATA spare parts
1316306015	SLIDING PAD	TATA spare parts
131631200039	ASSY FIFTH CROSS MEMBER	TATA spare parts
131631200040	ASSY SIXTH CROSS MEMBER - LPO1610/1616	TATA spare parts
131631200041	ASSY SEVENTH CROSS MEM. OF LPO1610/1616	TATA spare parts
131631200043	ASSY ELEVENTH CROSS MEMBER	TATA spare parts
131631200047	ASSY FOURTH CROSS MEMEBER LPO 1616/1610	TATA spare parts
131631200048	ASSY FRAME COMPLETE FRONT MODULE	TATA spare parts
131631200050	ASSY C/M 11TH LPT1613 TRUCK SP.WHEEL	TATA spare parts
131631200055	ASSY FRAME COMPLETE - REAR MODULE	TATA spare parts
131631200058	FRONT FRAME SUB ASSY KIT	TATA spare parts
131631200059	REAR FRAME SUB ASSY KIT 240	TATA spare parts
131631200064	FR FRAME SUB ASSY	TATA spare parts
13163120006491	ASSY FRAME COMPLETE FRONT MODULE	TATA spare parts
13163120006591	ASSY FRAME COMPLETE - REAR MODULE	TATA spare parts
131631200080	ASSY FOURTH CROSS MEMBER	TATA spare parts
131631200087	FT FR ASY KIT AFTR PAINT LPO1623 LCR BS4	TATA spare parts
131631200088	RR FR ASY KIT AFTR PAINT LPO1623 LCR BS4	TATA spare parts
131643200026	ASSY AIR TANK COMPLETE FOR LPO LH 20 LIT	TATA spare parts
131643200027	ASSY AIRTANK WITH DRAIN PLUG RH-LPO CNG	TATA spare parts
131643200028	ASSY AIRTANK WITH DRAIN PLUG LH-LPO CNG	TATA spare parts
131643200030	ASSY AIRTANK WITH DRAIN PLUG RH-1610	TATA spare parts
131643200033	ASSY AIR TANK COMPLETE WITH DRAIN PLUG	TATA spare parts
131646600020	KIT POWER STEERING PIPES 1616 BS4	TATA spare parts
131647500001	ASSY.SUPPORT WITH RUBBER PACKING FOR F/T	TATA spare parts
131647500002	ASSY.SUPP.WITH RUBBER PACKING(350LITRE)	TATA spare parts
131647500005	ASSY SUPPORT WITH STRAP & RUBBER PACKING	TATA spare parts
131647500007	ASSY.SUPPORT WITH RUBBER PACKING	TATA spare parts
131647500009	ASSY SUCTION FUEL LINE COMPL. FOR LPO TC	TATA spare parts
131647500026	ASSY.SUPP.WITH RUBBER PACKING(350LITRE)	TATA spare parts
131649200008	ASSY SILENCER MTG. BKT COMP. 1	TATA spare parts
131649200010	ASSY SILENCER MTG. BKT COMP. 3 LPT2515	TATA spare parts

131649200017	ASSY. BKT. SILEN. MTG. 3RD	TATA spare parts
131649200020	ASSY. BKT. SILEN. MTG. 4TH	TATA spare parts
131649200032	ASSY. BKT. SILENCER MTG.-LPO 1316 - 4	TATA spare parts
131649200033	ASSY. BKT. SILENCER MTG LP 1512 TC	TATA spare parts
131649200039	ASSY. BKT. SILEN. MTG 5TH	TATA spare parts
131649200042	ASSY. BKT. SILENCER MTG.-LPO 1316	TATA spare parts
131649200046	ASSY. BKT. SILENCER MTG. - LPO RE - 1	TATA spare parts
131649200047	ASSY. BKT. SILENCER MTG. - LPO RE 2	TATA spare parts
131649200048	ASSY. BKT. SILENCER MTG. - LPO RE - 3	TATA spare parts
131649200055	ASSY. BKT. SILENCER MTG.- LP 52 CMVR -1	TATA spare parts
131649200058	ASSY. BKT. SILENCER MTG.- LP 52 CMVR -4	TATA spare parts
131649200060	ASSY. BKT. SILENCER MTG.- LP 59 CMVR	TATA spare parts
131649200061	ASSY. BKT. SILENCER MTG.- LP 59 CMVR	TATA spare parts
131649200062	ASSY. BKT. SILENCER MTG.- LP 59 CMVR	TATA spare parts
131649200063	ASSY. BKT. SILENCER MTG.- LP 59 CMVR	TATA spare parts
131649200065	ASSY BRACKET SILENCER MOUNTING	TATA spare parts
131649200066	ASSY BRACKET SILENCER MTG (TAIL PIPE)	TATA spare parts
131649200071	ASSY SILENCER MTG. BKT COMP. - LCV	TATA spare parts
131649200082	ASSY. BKT SILENCER MTG	TATA spare parts
131649200085	ASSY BRACKET SILENCER MTG 1618 840 CH	TATA spare parts
131649200086	ASSY BRACKET SILENCER MTG	TATA spare parts
131650100008	TIERED COOLING SYSTEM - LPO1510 TC	TATA spare parts
131650100014	ASSY RADIATOR PIPE WITH HOSE - LPT 2515	TATA spare parts
131650100016	ASSY RADIATOR PIPE WITH HOSE - 1316 LHD	TATA spare parts
131650100017	ASSY RADIATOR PIPE WITH HOSE - LPO 1512	TATA spare parts
131650100020	ASSY CRIMPED METALLIC PIPE (AUX. COOLANT	TATA spare parts
131650100021	ASSY CRIMPED METALLIC PIPE (AUX. COOLANT	TATA spare parts
131650100022	TIERED COOLING SYS-LPO CNG	TATA spare parts
131650100032	ASSY RADIATOR PIPE WITH HOSE -LPO1512BS3	TATA spare parts
131650100040	TIERED COOLING SYS-LP 1512 TC	TATA spare parts
131650100053	ASSY WATER FILLER PIPE WITH HOSE-LP	TATA spare parts
131650100067	TIERED COOLING SYSTEM WITH PLASTIC TANK	TATA spare parts
131654400006	ASSY TAIL LAMP WITH BKT LH 24 V	TATA spare parts
131654400007	ASSY TAIL LAMP WITH BKT RH 24 V	TATA spare parts
131686000005	ASSY CANOPY COMPLETE FOR LPO LHD	TATA spare parts
131686000011	ASSY CANOPY COMPLETE	TATA spare parts
131688700002	ASSY ENGINE HOOD FOR LPO1616TC	TATA spare parts
131688700011	ASSY ANTISAGGING BAR & BKTS	TATA spare parts
131688700017	ASSY. BUMPER WITH FRONT GUARD - LPO CNG	TATA spare parts
131688700026	ASSY ANTISAGGING BAR & BKTS(LPO1318 LHD)	TATA spare parts
131688700029	ASSY BUMPER WITH REFLECTOR (LP)	TATA spare parts
13181530256	PIN 10F8 X 28 X 24	TATA spare parts
13181530264	PIN 10F 8 X 28 X 23.4	TATA spare parts
13181540219	PIN 14F8 X 30 X 24.5	TATA spare parts
13181540227	PIN 14F8 X 35 X 30	TATA spare parts
13181599019	PIN 8F8 X 24 X 21	TATA spare parts
131820000001	KIT FOR NEW FAN DRIVE OF RE1615/1610	TATA spare parts

13182030150	PIN 10H11 X 22 X 18	TATA spare parts
131826200001	KIT FOR REAR COVER & BUSH - CUB GEAR BOX	TATA spare parts
131826200003	GEAR BOX HI-DECK WITH SAE1 HOUSING	TATA spare parts
131829000001	ASSY KIT PIN, WASHER AND SPLIT PIN	TATA spare parts
131831000005	KIT PART FOR RETRO FIT. WHEEL ARCH LH/RH	TATA spare parts
131842000004	KIT RETRO FIT NEW BRAKE LINING - LPO1616	TATA spare parts
131846000008	KIT PART FOR P/STG PIPE (1316 RHD)	TATA spare parts
131846000015	KIT PART FOR P/STG PIPE LPT3118	TATA spare parts
131846000016	KIT PART FOR P/STG PIPE LPT1613/62	TATA spare parts
131846000019	KIT FOR ASSY STG PIPE-1613CNG BSIV MARCO	TATA spare parts
131846000023	KIT STEERING HORN PAD COMBI SW & PANEL	TATA spare parts
131847000004	KIT PART NO. FOR LP-407CNG FOR GAS PIPES	TATA spare parts
131847000006	KIT FOR GAS PIPES OF LPO CNG	TATA spare parts
131847000015	KIT ASSY. FOR VENT CAP	TATA spare parts
1320103000	WASHER	TATA spare parts
1320150003	VIBRATING PLATE	TATA spare parts
1320550000	DISC	TATA spare parts
1324201019	TUBE	TATA spare parts
1324201041	HOUSING	TATA spare parts
1324202026	INPUT SHAFT	TATA spare parts
1324204007	SYNCHRONIZER	TATA spare parts
1324204008	SYNCHRONIZER	TATA spare parts
1324204009	CLUTCH BODY	TATA spare parts
1324232002	PLANET GEAR SET	TATA spare parts
1324232004	PLANET CARRIER	TATA spare parts
1324233001	CLUTCH BODY	TATA spare parts
1324301119	HOUSING	TATA spare parts
1324302026	INPUT SHAFT	TATA spare parts
1324303001	LAYSHAFT	TATA spare parts
1324303003	HELICAL GEAR	TATA spare parts
1324303004	HELICAL GEAR	TATA spare parts
1324304001	HELICAL GEAR	TATA spare parts
1324304003	HELICAL GEAR	TATA spare parts
1324304005	PLANETENRADSATZ	TATA spare parts
1324304006	SYNCHRO.BODY	TATA spare parts
1324304011	CLUTCH BODY	TATA spare parts
1324304013	CLUTCH BODY	TATA spare parts
1324304014	TUBE	TATA spare parts
1324304015	HELICAL GEAR	TATA spare parts
1324304028	SUN GEAR	TATA spare parts
1324304037	SLEEVE CARRIER	TATA spare parts
1324306013	GEAR SHIFT FORK	TATA spare parts
1324306025	GEAR SHIFT RAIL	TATA spare parts
1324306026	GEAR SHIFT RAIL	TATA spare parts
1324306027	GEAR SHIFT RAIL	TATA spare parts
1324306029	RELAY LEVER	TATA spare parts
1324306031	GEAR SHIFT FORK	TATA spare parts

1324306034	LOCKING LEVER	TATA spare parts
1324306039	GEAR SHIFT FORK	TATA spare parts
1324306040	RELAY LEVER	TATA spare parts
1324307073	DRIVER	TATA spare parts
1324307074	DRIVER	TATA spare parts
1324307082	GASKET	TATA spare parts
1324307096	SHIFT.INTERLOCK	TATA spare parts
1324307102	DRIVER	TATA spare parts
1324307116	DETENT PART	TATA spare parts
1324307118	G.SHIFT HOUSING	TATA spare parts
1324307148	COVER	TATA spare parts
1324307180	G.SHIFT SHAFT	TATA spare parts
1324307193	GEAR SHIFT COVER	TATA spare parts
1324307194	SHIFTING INTERLOCK	TATA spare parts
1324332002	RING GEAR	TATA spare parts
1324332007	RING GEAR CARR.	TATA spare parts
1324332016	PLANETENBOLZEN	TATA spare parts
1324332018	RING GEAR	TATA spare parts
1324334004	GEAR SHIFT RAIL	TATA spare parts
13300508183	SNAP HD RIVET 8X18 IS2155 SS8400	TATA spare parts
13300508302	SNAP HD RIVET 8X30 IS2155 SS8400 BS6	TATA spare parts
13300509163	SNAPHD.RIVET10X16IS2155SS8400BS6	TATA spare parts
13300509180	SNAP HD.RIVET 10X18 IS2155 SS8400	TATA spare parts
13300509201	SNAP HD.RIVET 10X20 IS2155 SS8400	TATA spare parts
13300509228	SNAP HD.RIVET 10X22 IS2155 SS840	TATA spare parts
13300509261	SNAP HEAD RIVET 10 X 26	TATA spare parts
13300509287	SNAP HD.RIVET 10X28 IS2155 SS8400	TATA spare parts
13300510242	SNAP HD RIVET 10X24 IS2155-SS8400 BS6	TATA spare parts
1330100040	WASHER	TATA spare parts
13305298012	SNAP HD BLIND RIVET 4.8X10 TS175	TATA spare parts
13305298021	SNAP BLND RIVET 3.2X8 TS17508 BS6-PH2	TATA spare parts
13305298250	SNAP HEAD RIVET	TATA spare parts
13350502089	RIVET 3 X 8	TATA spare parts
13350503166	RIVET 4 X 16	TATA spare parts
13350505142	RIVET SCAM BRAKE	TATA spare parts
13350507161	RIVET 10X16 TS17570 SS8400	TATA spare parts
13350507226	RIVET 10X22 TS17570 SS8451-8B BS6-PH2	TATA spare parts
13350507242	RIVET 10 X 24	TATA spare parts
13350507269	RIVET 10 X 26	TATA spare parts
13350507285	RIVET 10 X 28	TATA spare parts
13350507307	RIVET 10 X 30	TATA spare parts
13350507323	RIVET 10 X 32	TATA spare parts
13350507358	RIVET 10 X 35	TATA spare parts
13350507382	RIVET 10 X 38	TATA spare parts
13350507404	RIVET 10 X 40	TATA spare parts
13350507455	RIVET 10 X 45	TATA spare parts
13350508222	RIVET 12 X 22	TATA spare parts

13350508265	RIVET 12 X 26	TATA spare parts
13350508281	RIVET 12 X 28	TATA spare parts
13350508303	RIVET 12 X 30	TATA spare parts
13350508320	RIVET 12 X 32	TATA spare parts
13350508354	RIVET 12 X 35	TATA spare parts
13350508389	RIVET 12X38-TS17570	TATA spare parts
13350508427	RIVET 12X42 TS17570 SS8400	TATA spare parts
13350509326	RIVET 14X32 TS17570 SS8400 BS6-PH2	TATA spare parts
13440506083	HOLLOW RIVET A4 X 9 X 8	TATA spare parts
13442506102	HOLLOW RIVET 6 X 10	TATA spare parts
13442506129	RIVET C6 X 12	TATA spare parts
13442508121	HOLLOW RIVET 8 X 12	TATA spare parts
1346307020	BOLT	TATA spare parts
135120270001	3-WAY COCK WITH STRAINER	TATA spare parts
13512027CN	3-WAY COCK D/E	TATA spare parts
13512030SF	CONNECTOR (1/4)	TATA spare parts
135120380001	SOLENOID VALVE-12V/SINGLE COIL	TATA spare parts
13512038CN	SOLENOID VALVE-12V/SINGLE COIL	TATA spare parts
135120470001	SOLENOID VALVE-24V/SINGLE COIL	TATA spare parts
13512047CN000000	SOLENOID VALVE-S.COIL -24 (SENBUS)	TATA spare parts
135120530001	SPEED CONTROL VALVE(BENJO TYPE)	TATA spare parts
13512053CN	SPEED CONTROL VALVE	TATA spare parts
13512071CN000000	CONNECTING ROD	TATA spare parts
135120720011	6MM TUBE (FOR PNEUMATIC DOOR)(L=10 MTR)	TATA spare parts
135120760001	POLYMER TUBE (6 DIA)(L=10 MTRS	TATA spare parts
135120760002	POLYMER TUBE (6 DIA) (L = 44 MTR )	TATA spare parts
135120760013	POLYMER TUBE (6 DIA) - BLUE(L=15 MTR)	TATA spare parts
135120960001	LEVER TYPE SWITCH (PNEUMATIC DOOR)	TATA spare parts
135121350001	EMERGENCY SWITCH OUTSIDE	TATA spare parts
135130070001	POLYMER TUBE DIA 6 - YELLOW	TATA spare parts
135130070013	POLYMER TUBE DIA6- YELLOW	TATA spare parts
135144	CLAMP T BOLT	TATA spare parts
135220760001	SPARE WHEEL CARRIER	TATA spare parts
13522121CF035000	BATTERY CABLE RED (SENBUS)	TATA spare parts
13522122CF045000	BATTERY CABLE (RED) (SENBUS)	TATA spare parts
135222030004	EXHAUST PIPE FOR CUMMINS(82ID) L= 650	TATA spare parts
13600506611	PARALLEL KEY A8X7X63	TATA spare parts
13600599016	PARALLEL KEY A8 X 5 X 25	TATA spare parts
1362670296	PROTECTIVE RUBBER CAP	TATA spare parts
13650504059	WOODRUFF KEY 3 X 5	TATA spare parts
13650505055	WOODRUFF KEY 3 X 6.	TATA spare parts
13650505063	WOODRUFF KEY 4 X 6.	TATA spare parts
13650506078	WOODRUFF KEY 5 X 7.5	TATA spare parts
13650508089	WOODRUFF KEY 6 X 10	TATA spare parts
13650509093	WOODRUFF KEY 8 X 11	TATA spare parts
13650510091	KEY 8 X 13	TATA spare parts
13650596018	WOODRUFF KEY 5X7.5	TATA spare parts

1365890039	DRIFT	TATA spare parts
1365890739	DRIFT	TATA spare parts
1369940035	SPRING WIRE RING	TATA spare parts
1369950135	CLIP	TATA spare parts
13809320155	FIXED ENGAGE COWL	TATA spare parts
13809320156	SLIDING ENGAGE COWL	TATA spare parts
13809320157	CIRCLE NUT	TATA spare parts
13809320158	LOCKING WASHER	TATA spare parts
13809320159	DIFFERENTIAL ADJUSTTING NUT	TATA spare parts
13886	GASKET-R.A. SHAFT	TATA spare parts
13888	GASKET	TATA spare parts
139969	NIPPLE PLAIN HEXAGON	TATA spare parts
1399690	NIPPLE PLAIN HEX	TATA spare parts
14001G01	FRONT WINDSCREEN GLASS	TATA spare parts
14002G01	J/K DOOR GLASS	TATA spare parts
14004G01	DESTINATION GLASS	TATA spare parts
14005G01	REAR WINDSCREEN GLASS	TATA spare parts
14006G01	DRIVER PARTITION GLASS	TATA spare parts
14007G01	MAIN WINDOW BOTTOM FIX GL	TATA spare parts
14009G01	MAIN WINDOW SLIDING GLASS	TATA spare parts
14010G01	MID WINDOW BOTTOM FIX GLA	TATA spare parts
140112780001	STANCHION PIPE WITH PVC SLEEVE WITH CUSH	TATA spare parts
140119220001	PARTITION GLASS ASSY	TATA spare parts
14011G01	MID WINDOW SLIDING GLASS	TATA spare parts
140123690001	AUTO AIR FRESHNER	TATA spare parts
140124610001	HANDLE (PARTITION) WITH KEY	TATA spare parts
140125280002	PARTITION ACRYLIC ASSY - PC	TATA spare parts
140125770002	PARTITION GLASS FRAME ASSY (P.C)	TATA spare parts
140125840002	PARTITION GLASS FRAME ASSY (P.C)	TATA spare parts
140125870001	PARTITION DOOR LOCK ( R3-10-311-50)	TATA spare parts
140127700001	PARTITION GLASS ASSEMBLY	TATA spare parts
140127700002	PARTITION / GLASS ASSEMBLY (P.C)	TATA spare parts
140129570001	SS LATCH (REAR BAGGAGE DOOR)	TATA spare parts
140129860001	LOCK COVER/ PARTITION DOOR	TATA spare parts
140131380001	PARTITION GLASS ASSY	TATA spare parts
140133100001	BEND PIPE (32DIA)	TATA spare parts
14016G01	SMALL WINDOW SLIDING GLAS	TATA spare parts
14017G01	SMALL & DR'S DOOR WINDOW	TATA spare parts
14019G01	DRIVER DOOR WINDOW SLIDIN	TATA spare parts
140210430001	PIPE HOLDER (32 DIA)	TATA spare parts
140210440001	PIPE COVER (32 DIA) YELLOW	TATA spare parts
140210470001	PIPE BRACKET COVER (DIA 32) GREY	TATA spare parts
140210680001	PIPE BKT(38 DIA) BOTTOM	TATA spare parts
140210690001	PIPE BKT.COVER YELLOW	TATA spare parts
140210700001	PIPE BKT.COVER(38 DIA)(GREY)	TATA spare parts
14021G01	EMER. DOOR WINDOW SLIDING	TATA spare parts
140220490001	PLASTIC PIPE BRACKET	TATA spare parts

140220500001	PLASTIC PIPE BRACKET (41 DIA)	TATA spare parts
140220970001	PIPE BRACKET	TATA spare parts
140220970002	PIPE BRACKET (PC)	TATA spare parts
140220980001	RUBBER PAD (66X44)	TATA spare parts
140223280001	PLASTIC PIPE BRACKET (32 DIA)	TATA spare parts
140223290001	PLASTIC PIPE BRACKET (32 X32)	TATA spare parts
140223300001	PLASTIC PIPE BRACKET (38X32)	TATA spare parts
140223420001	PLASTIC PIPE BRACKET(32 DIA)	TATA spare parts
140223430001	PLASTIC PIPE BRACKET (32 DIA)	TATA spare parts
140223470001	PLASTIC PIPE BRACKET (32 DIA) - BLACK	TATA spare parts
140223480001	PLASTIC PIPE BRACKET (32X32) - BLACK	TATA spare parts
14022G01	EMER. DOOR WINDOW SLIDING	TATA spare parts
140231020001	BEND PIPE (32DIA)	TATA spare parts
140311460001	STANCHION PIPE PVC SLEEVE WITH CUSHION F	TATA spare parts
140311470005	STANCHION PIPE	TATA spare parts
14059403908	COMP SPG 210D X1.5WDX50L	TATA spare parts
140703390001	HAND STRAP ASSY(ASH GREY )(L=242)	TATA spare parts
140705290001	HAND STRAP (912)(YELOW)	TATA spare parts
140710480001	HAND STRAP WITH ADVERTISEMENT PROV.	TATA spare parts
140720100001	BRACKET (BLACK)	TATA spare parts
14072010AF	PIPE BRACKET FOR GRAB RAIL	TATA spare parts
140720360001	BRACKET (BLACK)	TATA spare parts
140720360002	GRAB RAIL BRACKET (MSRTC)	TATA spare parts
140720420001	PIPE BRACKET	TATA spare parts
140720420002	BRACKET (BLACK)	TATA spare parts
140720810001	BRACKET PLASTIC	TATA spare parts
140720820001	GRAB RAIL END CAP	TATA spare parts
140721020001	BRACKET	TATA spare parts
140721030001	BRACKET CLOSE END	TATA spare parts
140721060001	PIPE BRACKET	TATA spare parts
140721070001	END BRACKET	TATA spare parts
140721080001	GRAB RAIL BRACKET - GREY	TATA spare parts
140721090001	BRACKET 32DIA - BLACK	TATA spare parts
140721100001	END BUSH 32 DIA-BLACK	TATA spare parts
140721120001	END CAP PLASTIC 32.20 - GOLDEN YELLOW	TATA spare parts
1410023007	CLAMPING JAW	TATA spare parts
1410023008	OIL SEAL	TATA spare parts
1410100002	WASHER	TATA spare parts
1410101600	WASHER	TATA spare parts
1410101612	SHIM 0.12 MM	TATA spare parts
1410101614	SHIM 0.14 MM	TATA spare parts
1410101620	SHIM 0.50 MM	TATA spare parts
1410102625	SHIM 0.10 MM	TATA spare parts
1410102626	SHIM 0.12 MM	TATA spare parts
1410102627	SHIM 0.14 MM	TATA spare parts
1410102628	SHIM 0.16 MM	TATA spare parts
1410102629	SHIM 0.18 MM	TATA spare parts

1410102630	SHIM 0.50 MM	TATA spare parts
1410103025	UNION WASHER	TATA spare parts
1410105001	DELIVERY VALVE WASHER	TATA spare parts
1410107005	PACKING WASHER	TATA spare parts
1410120069	SPRING PLATE LOW	TATA spare parts
1410137003	END PLATE PACKING	TATA spare parts
1410200014	RING 4.1 MM	TATA spare parts
1410202006	ROLLER	TATA spare parts
1410202034	INTER RING	TATA spare parts
1410202035	INTER RING	TATA spare parts
1410202042	WASHER	TATA spare parts
1410202045	RING 4.7 MM	TATA spare parts
1410202046	RING 4.9 MM	TATA spare parts
1410202056	RING 4.2 MM	TATA spare parts
1410202057	RING 4.4 MM	TATA spare parts
1410202058	RING 4.6 MM	TATA spare parts
1410202067	RING 4.8 MM	TATA spare parts
1410206020	WASHER	TATA spare parts
1410281012	OIL SEAL	TATA spare parts
141029790001	HATRACK END CAP- (FRONT)	TATA spare parts
141029800001	HATRACK END CAP-(REAR)	TATA spare parts
141029810001	DUCT END CAP- (FRONT)	TATA spare parts
141029820001	DUCT END CAP-(REAR)	TATA spare parts
1410300042	BEARING BUSH	TATA spare parts
1410300050	BEARING BUSH	TATA spare parts
141031280001	HATRACK ARM RUBBER PAD	TATA spare parts
141031400001	HATRACK ARM END PAD - BLACK	TATA spare parts
141032570003	CONNECTING DUCT COVER- PC	TATA spare parts
1410326030	CONTROL SLEEVE	TATA spare parts
141032650002	CONNECTING DUCT COVER	TATA spare parts
141033010002	DUCT COVER P.C	TATA spare parts
141033041002	DUCT COVER P.C	TATA spare parts
141033050002	DUCT COVER	TATA spare parts
141033080002	DUCT COVER P.C	TATA spare parts
141034130002	DUCT COVER P.C	TATA spare parts
141034140003	CONNECTING DUCT COVER PC	TATA spare parts
141035160002	CONNECTING DUCT END COVER - PC	TATA spare parts
141035660001	BAGGAGE RACK ASSEMBLY -LH	TATA spare parts
141035670001	BAGGAGE RACK ASSEMBLY -RH	TATA spare parts
1410361001	THREADED BUSH	TATA spare parts
141036220002	DUCT COVER PANEL (PC)	TATA spare parts
141036230002	DUCT COVER PANEL (PC)	TATA spare parts
141036240002	DUCT COVER PANEL (PC)	TATA spare parts
141036270002	DUCT COVER PANEL (PC)	TATA spare parts
141036280002	DUCT COVER PANEL (PC)	TATA spare parts
141036300002	DUCT COVER - PC	TATA spare parts
141036310002	DUCT COVER - PC	TATA spare parts



141036320002	DUCT COVER PC	TATA spare parts
141036330001	BAGGAGE RACK FULL ASSLEMBY (LH)	TATA spare parts
141036340001	BAGGAGE RACK FULL ASSLEMBY (RH)	TATA spare parts
141036730002	DUCT COVEL PANEL - PC	TATA spare parts
141036740002	DUCT COVER P.C	TATA spare parts
141036750002	DUCT COVER P.C	TATA spare parts
141037720002	DEFLECTOR PLATE	TATA spare parts
141040790001	SUPPORT PLATE	TATA spare parts
141042450008	PANEL	TATA spare parts
141045750002	HEATLONE RETAINER	TATA spare parts
141052410003	ARM	TATA spare parts
141052480002	HATRACK ARM (P.C)	TATA spare parts
1410551006	WASHER	TATA spare parts
1410551036	CLOSING CAP	TATA spare parts
1411015001	GASKET	TATA spare parts
1411015053	GASKET INSP COVER 4CYL EN	TATA spare parts
1411015055	GASKET INSP COVER 6CYL EN	TATA spare parts
1411015086	I.C. PACKING	TATA spare parts
1411073000	GASKET	TATA spare parts
1413100012	ROLLER PIN	TATA spare parts
1413100030	ROLLER PIN	TATA spare parts
1413121009	PEG	TATA spare parts
1413203002	VALVE PLATE	TATA spare parts
1413300028	HEX NUT	TATA spare parts
1413344001	THREADED RING	TATA spare parts
1413372056	DELIVERY VALVE	TATA spare parts
1413372072	DELIVERY VALVE HOLDER	TATA spare parts
1413402000	CLAMPING SCREW	TATA spare parts
1413410007	SCREW	TATA spare parts
1413417012	LOCKING SCREW	TATA spare parts
1413417050	CLAMPING SCREW	TATA spare parts
1413453001	SCREW	TATA spare parts
1413453025	AIR VENT SCREW	TATA spare parts
1413455080	REDUCING NIPPLE	TATA spare parts
1413456001	SCREW	TATA spare parts
1413457000	THREADED BUSH	TATA spare parts
1413457044	REDUCING UNION	TATA spare parts
1413462049	SCREW PLUG	TATA spare parts
1413462101	THREADED BUSH	TATA spare parts
1413463050	INSPECTION PLUG	TATA spare parts
1413463100	CLOSING PLUG	TATA spare parts
1413502000	STAY BOLT	TATA spare parts
141445	SCREW NO. 14 X 1/2	TATA spare parts
1414612005	SPRING	TATA spare parts
1414613013	SPRING DELIVERY VALVE	TATA spare parts
1414618000	SPRING	TATA spare parts
1414618027	PLUNGER SPRING	TATA spare parts

14150504008	DISC SPRING A40 TS17866 SS8400	TATA spare parts
14150504504	DISC SPRING A45	TATA spare parts
14150701601	DISC SPRING B16	TATA spare parts
14150702501	DISC SPRING B25 TS17866	TATA spare parts
1415126603	PUMP HOUSING	TATA spare parts
1415522061	BEARING END PLATE	TATA spare parts
1415800040	INTERMEDIATE BEARING	TATA spare parts
1416024007	CONTROL RACK	TATA spare parts
1416026004	CONTROL ROD	TATA spare parts
1416026005	CONTROL ROD	TATA spare parts
1416126285	CAMSHAFT	TATA spare parts
1416336060	QUADRANT	TATA spare parts
1416336061	QUADRANT	TATA spare parts
141710250001	FIRST AID BOX (WITH RED CROSS STICKER) B	TATA spare parts
141710340001	FIRE EXTINGUISHER (2KGS)+GAUGE	TATA spare parts
141710450001	FIRE EXTINGUISHER 6 KGS (WITH GAUGE)	TATA spare parts
141710460001	FIRE EXTINGUISHER 6 KGS (WITH GAUGE)	TATA spare parts
141710510001	FIRE EXTINGUISHER 9 KG	TATA spare parts
141710530001	FIRE EXTING (4KG) WITH BRACKET	TATA spare parts
141710590001	FDAS KIT BS6	TATA spare parts
141710620001	FDSS KIT	TATA spare parts
141720400001	FIRE EXTINGUISHER (A/B/C-1KG)(PRESS.TYP)	TATA spare parts
141720630001	FDAS CONTROLLER-SAFEX	TATA spare parts
141725120001	AUTOMATED FIRE SUPPRESSION SYSTEM	TATA spare parts
141725140001	SELF REFLECTIVE HAMMER	TATA spare parts
141730100001	GLASS BREAKING HAMMER WITH BASE	TATA spare parts
1417413012	OVER FLOW VALVE	TATA spare parts
141790260001	AF 300 CONTROL UNIT	TATA spare parts
1418325000	ELEMENT	TATA spare parts
1418325008	ELEMENT	TATA spare parts
1418325096	PUMP ELEMENT	TATA spare parts
1418325898	ELEMENT DI	TATA spare parts
1418522009	DELIVERY VALVE	TATA spare parts
1418522047	DELIVERY VALVE	TATA spare parts
1418522055	DELIVERY VALVE D-EXE PUMP	TATA spare parts
1418720020	ROLLER TAPPET	TATA spare parts
1420005000	LUBRICATION FELT	TATA spare parts
1420026000	VIBRATION DAMPER	TATA spare parts
1420051009	GASKET	TATA spare parts
1420100606	SHIM 0.30 MM	TATA spare parts
1420100607	SHIM 0.40 MM	TATA spare parts
1420100608	SHIM 0.50 MM	TATA spare parts
1420100609	SHIM 0.25 MM	TATA spare parts
1420100610	SHIM 0.35 MM	TATA spare parts
1420100611	SHIM 0.45 MM	TATA spare parts
1420100612	SHIM 0.50 MM	TATA spare parts
1420100651	SHIM 0.10 MM	TATA spare parts

1420101000	SHIM 2.0 MM THICK	TATA spare parts
1420101001	SHIM 1.90 MM	TATA spare parts
1420101003	SHIM 1.7 MM	TATA spare parts
1420101023	WASHER	TATA spare parts
1420101630	WASHER 0.30 MM	TATA spare parts
1420101635	WASHER 1.00 MM	TATA spare parts
1420101636	WASHER 0.30 MM	TATA spare parts
1420101645	WASHER 1.20 MM	TATA spare parts
1420101646	WASHER 1.30 MM	TATA spare parts
1420101647	WASHER 1.40 MM	TATA spare parts
1420101648	WASHER 1.50 MM	TATA spare parts
1420101651	WASHER 1.80 MM	TATA spare parts
1420101652	WASHER 1.90 MM	TATA spare parts
1420101658	WASHER	TATA spare parts
1420103033	WASHER 2.50 MM	TATA spare parts
1420103034	WASHER 2.60 MM	TATA spare parts
1420103035	WASHER 2.70 MM	TATA spare parts
1420103036	WASHER 2.80 MM	TATA spare parts
1420103037	WASHER 2.90 MM	TATA spare parts
1420105000	PACKING WASHER	TATA spare parts
1420113000	GASKET	TATA spare parts
1420114009	SHIM 2.45 MM	TATA spare parts
1420114011	SHIM 2.65 MM	TATA spare parts
1420114013	SHIM 2.85 MM	TATA spare parts
1420151001	LOCK WASHER	TATA spare parts
1420206001	SEALING RING	TATA spare parts
1420210010	O RING	TATA spare parts
1420220005	GUIDE RING	TATA spare parts
1420283001	OIL SEAL	TATA spare parts
1420300061	BEARING BUSH	TATA spare parts
1420324003	SPRING PLATE	TATA spare parts
1420328034	BEARING BUSH	TATA spare parts
1420361000	THREADED BUSH	TATA spare parts
1420362015	BUSH	TATA spare parts
1420400001	GUIDE SLEEVE	TATA spare parts
1420505035	CAP	TATA spare parts
1420505036	CAP	TATA spare parts
1420505040	SEALING RING	TATA spare parts
1420509010	PROTECTIVE	TATA spare parts
1420509011	PROTECTIVE	TATA spare parts
1420521001	CLOSING CAP	TATA spare parts
1420560004	INSPECTION PLUG	TATA spare parts
1420707001	PROTECTIVE SLEEVE	TATA spare parts
1421015060	GOV. COVER PACKING	TATA spare parts
1421015061	GASKET	TATA spare parts
1421030000	CLAMP PLATE	TATA spare parts
1421036010	SHIM 0.20 MM	TATA spare parts

1421323000	FASTENING PLATE	TATA spare parts
1421331009	LOCKING PLATE	TATA spare parts
1421335029	FULL LOAD STRAP	TATA spare parts
14217	PINION BRG CUP OTR	TATA spare parts
14218	PINION BRG CONE OTR	TATA spare parts
1421901036	LEVER FLOATING	TATA spare parts
1421933132	SHACKLE	TATA spare parts
1422003004	CONTROL LEVER	TATA spare parts
1422013036	SWIVELLING LEVER	TATA spare parts
1422013044	SWIVEL LEVER	TATA spare parts
1422033050	FLOATING LEVER	TATA spare parts
1422033051	FLOATING LEVER	TATA spare parts
1422060005	CRANCK LEVER	TATA spare parts
1422125082	ARTI PIECE	TATA spare parts
1422130000	SLIDER	TATA spare parts
1422130011	SLIDER	TATA spare parts
1422133061	GUIDE LEVER	TATA spare parts
1422190040	FLY WEIGHT	TATA spare parts
1423000005	LEVER SHAFT	TATA spare parts
1423002080	LEVER SHAFT	TATA spare parts
1423120063	SEAL	TATA spare parts
1423124108	FIP TIMING PIN	TATA spare parts
1423200020	SLIDER	TATA spare parts
1423300004	NUT	TATA spare parts
1423317044	CAP NUT	TATA spare parts
1423345020	ROUND ADJ NUT	TATA spare parts
1423345052	ADJUSTING NUT	TATA spare parts
1423400005	STUD BOLT	TATA spare parts
1423400019	STOP SCREW	TATA spare parts
1423401000	ADJUSTING SCREW	TATA spare parts
1423412000	GUIDE SCREW	TATA spare parts
1423413000	ADJUSTING SCREW	TATA spare parts
1423450001	BOLT	TATA spare parts
1423450036	HEX SCREW	TATA spare parts
1423450900	BOLT ASSY	TATA spare parts
1423521014	SLIDING BOLT	TATA spare parts
1424611004	SPRING	TATA spare parts
1424615011	SPRING	TATA spare parts
1424615038	SPRING	TATA spare parts
1424619019	IDLING SPRING	TATA spare parts
1424619026	SPRING MAX SPEED INNER	TATA spare parts
1424633001	CONTROL SPRING	TATA spare parts
1424634025	CONTROL SPRING	TATA spare parts
1424634026	CONTROL SPRING	TATA spare parts
1424640009	ADAPTER SPRING	TATA spare parts
1424641000	IDLING SPRING	TATA spare parts
1424650005	SWIVEL SPRING	TATA spare parts

1424650009	RACK RETURN SPRING	TATA spare parts
1424651019	FIP-BROWN TORSION SPRING	TATA spare parts
1425620403	GOVERNOR HOUSING COVER	TATA spare parts
1425703001	GUIDE BUSH	TATA spare parts
14260599012	CLAMP WSN5 X 85	TATA spare parts
14261500508	HOSE CLAMP	TATA spare parts
14261500907	HOSE CLAMP WSN 9	TATA spare parts
14261999031	HOSE CLAMP 0.4 X 300	TATA spare parts
14261999057	STRAP 9 X 0.4 X 375	TATA spare parts
14261999138	STRAP 9 X 0.4 X NL	TATA spare parts
1426449009	DRIVER	TATA spare parts
14270201106	HOSE CLIP 11	TATA spare parts
14270201301	HOSE CLIP 13	TATA spare parts
14270201505	HOSE CLIP 15	TATA spare parts
14270201602	HOSE CLIP 16	TATA spare parts
14270201700	HOSE CLIP 17	TATA spare parts
14270201904	HOSE CLIP 19	TATA spare parts
14270202102	HOSE CLIP 21	TATA spare parts
14270202307	HOSE CLIP 23	TATA spare parts
14270202501	HOSE CLIP 25	TATA spare parts
14270202901	HOSE CLIP 29	TATA spare parts
14270203206	HOSE CLIP 329	TATA spare parts
14270203508	HOSE CLIP 35	TATA spare parts
14270203702	HOSE CLIP 37	TATA spare parts
14270299033	HOSE CLIP	TATA spare parts
1427400000	OIL CUP	TATA spare parts
1427432000	AIR BREATHER	TATA spare parts
1427432010	AIR BREATHER	TATA spare parts
14275	BRG ADJUSTER LOCK RH	TATA spare parts
14280500128	HOSE CLAMP 12	TATA spare parts
14280500161	HOSE CLAMP 16 IS4762	TATA spare parts
14280500209	HOSE CLAMP 20	TATA spare parts
14280500225	HOSE CLAMP 22	TATA spare parts
14280500250	HOSE CLAMP 25	TATA spare parts
14280500306	HOSE CLAMP 30	TATA spare parts
14280500331	HOSE CLIP 35	TATA spare parts
14280500357	HOSE CLAMP 35	TATA spare parts
14280500357AE	HOSE CLAMP 35 -1628	TATA spare parts
14280500403	HOSE CLAMP 40	TATA spare parts
14280500454	HOSE CLAMP 45	TATA spare parts
14280500501	HOSE CLAMP 50	TATA spare parts
14280500608	HOSE CLAMP 60	TATA spare parts
14280500705	HOSE CLAMP 70	TATA spare parts
14280500802	HOSE CLAMP 80	TATA spare parts
14280500900	HOSE CLAMP 90	TATA spare parts
14280501001	HOSE CLAMP 100	TATA spare parts
14280501108	HOSE CLAMP 110	TATA spare parts

14280501159	HOSE CLAMP 115	TATA spare parts
14280501302	HOSE CLAMP 130	TATA spare parts
14280596044	HOSE CLAMP SLTB 78 SAE J1508	TATA spare parts
14280598055	HOSE CLAMP SLTB-76 SAE J 1508	TATA spare parts
14280598071	HOSE CLAMP TB 38	TATA spare parts
14280598080	HOSE CLAMP TB 56	TATA spare parts
14280598098	HOSE CLAMP TB 108	TATA spare parts
14280598101	HOSE CLAMP TB 140	TATA spare parts
14280598110	HOSE CLAMP SLTB-56 SAE J 1508	TATA spare parts
14280598136	HOSE CLAMP TB 76	TATA spare parts
14280598144	HOSE CLAMP TB 126	TATA spare parts
14280598161	HOSE CLAMP TB 148	TATA spare parts
14280598179	HOSE CLAMP	TATA spare parts
14280598187	CLAMP TG 84	TATA spare parts
14280598195	HOSE CLAMP TB 116	TATA spare parts
14280598209	HOSE CLAMP TB 112	TATA spare parts
14280598217	HOSE CLAMP TB 54	TATA spare parts
14280598217AE	HOSE CLAMP TB 54 SAE J1508 1628	TATA spare parts
14280598225	HOSE CLAMP-TB-146	TATA spare parts
14280598233	HOSE CLAMP TB 144	TATA spare parts
14280598241	HOSE CLAMP TB-46 SAE J1508	TATA spare parts
14280598250	HOSE CLAMP TB 114	TATA spare parts
14280598268	HOSE CLAMP TB 30	TATA spare parts
14280598276	HOSE CLAMP TB82 SAE J1508	TATA spare parts
14280598284	HOSE CLAMP TB86 SAE J1508	TATA spare parts
14280598292	HOSE CLIP TB-70 SAE J1508	TATA spare parts
14280598306	HOSE CLAMP TB 42	TATA spare parts
14280598314	HOSE CLAMP TB 64	TATA spare parts
14280598322	HOSE CLAMP TB 66	TATA spare parts
14280598331	HOSE CLAMP TB 138 SAE J1508	TATA spare parts
14280598357	HOSE CLAMP TB100 SAE J1508	TATA spare parts
14280598365	HOSE CLAMP TB58 SAE J1508	TATA spare parts
14280598373	HOSE CLAMP	TATA spare parts
14280598403	HOSE CLAMP TB178 SAE J1508	TATA spare parts
14280598411	HOSE CLAMP TB210 SAE J1508	TATA spare parts
14280598438	HOSE CLAMP TB 94	TATA spare parts
14280598446	HOSE CLAMP TB-106	TATA spare parts
14280598462	HOSE CLAMP TB50 SAE J1508	TATA spare parts
14280598471	HOSE CLAMP TB172	TATA spare parts
14280598471AE	HOSE CLAMP TB172 1628	TATA spare parts
14280598497	HOSE CLAMP TB 158	TATA spare parts
14280598501	HOSE CLAMP TB 154 SAE J1508	TATA spare parts
14280598519	HOSE CLAMP TB 170 SAE J1508	TATA spare parts
14280598551	HOSE CLAMP TB 174	TATA spare parts
14280598560	HOSE CLAMP TB206 SAE J1508 BS6	TATA spare parts
14280598578	HOSE CLAMP SLTB 64 SAE J1508	TATA spare parts
14280598594	HOSE CLAMP SLTB 102	TATA spare parts

14280598608	HOSE CLAMP SLTB 80 SAE J1508	TATA spare parts
14280598616	HOSE CLAMP SLTB112 SAE J1508	TATA spare parts
14280598632	HOSE CLAMP TB88 SAE J1508	TATA spare parts
14280599116	HOSE CLAMP SLTB 74	TATA spare parts
14280599175	HOSE CLAMP TB28	TATA spare parts
14280599183	HOSE CLAMP TB32	TATA spare parts
14280599191	HOSE CLAMP TB 40	TATA spare parts
14280599205	HOSE CLAMP SLTB46 SAE-J1508	TATA spare parts
14280599221	HOSE CLAMP SLTB 44	TATA spare parts
14280599230	HOSE CLAMP SLTB60 SAE J1508 BS6	TATA spare parts
14280599248	HOSE CLAMP TB72 SAE J1508	TATA spare parts
14280599256	HOSE CLAMP TB74 SAE J1508	TATA spare parts
14280599264	HOSE CLAMP TB34	TATA spare parts
14280599272	HOSE CLAMP SLTB 72 BS1/2/3/4/6	TATA spare parts
14280599272AE	HOSE CLAMP SLTB-72 715	TATA spare parts
14280599299	HOSE CLAMP TB-80	TATA spare parts
14280599302	HOSE CLAMP	TATA spare parts
14280599329	HOSE CALMP TB 44	TATA spare parts
14280599337	HOSE CLAMP TB 60	TATA spare parts
14280599353	HOSE CLAMP SLTB 68 SAE J1508	TATA spare parts
14280599361	HOSE CLAMP SLTB 70 SAE J1508	TATA spare parts
14280599370	HOSE CLAMP TB 78 SAE J1508 BS6	TATA spare parts
14280599388	HOSE CLAMP SLTB 84 SAE J1508	TATA spare parts
14280599451	HOSE CLAMP TB 164-SAE J1508	TATA spare parts
1428101024	FLY WEIGHT ASSY	TATA spare parts
1428194021	FLYWEIGHT ASSY	TATA spare parts
1428194031	FLYWEIGHT ASSY	TATA spare parts
1428199000	FLY WEIGHT ASSY.	TATA spare parts
14282598187	CLAMP	TATA spare parts
1428322028	BEARING ASSY	TATA spare parts
14285000166	HOSE CLAMP 16 IS4762 SS8451S2-Y	TATA spare parts
14285000204	HOSE CLAMP 20 IS4762 SS8451S2-Y	TATA spare parts
14285000221	HOSE CLAMP 22 IS4762 SS8451S2-Y	TATA spare parts
14285000255	HOSE CLAMP 25 IS4762 SS8451S2-Y	TATA spare parts
14285000506	HOSE CLAMP 50	TATA spare parts
14285000603	HOSE CLAMP 60 IS4762-SS8451S2-Y	TATA spare parts
14300107CF	SUNVISOR ASSY	TATA spare parts
14300512136	SPRING BAND CLAMP 13DX12W TS17665	TATA spare parts
14300512144	SPR. BD CLAMP 14DX12W TS17665 SS8451S2-	TATA spare parts
14300512152	SPR. BD CLAMP 15DX12W TS17665 SS8451S2-Y	TATA spare parts
14300512161	SPR BAND CLAMP 16DX12W TS17665 SS8451-8C	TATA spare parts
14300512179	SPR. BD CLAMP 17DX12W TS17665 SS8451S2-Y	TATA spare parts
14300512187	SPR.BAND CLAMP 18DX12W TS17665 SS8451-8C	TATA spare parts
14300512195	SPRING HARD CLAMP	TATA spare parts
14300512217	SPRING BAND CLAMP 21DX12W	TATA spare parts
14300512225	SPR. BD CLAMP 22DX12W TS17665 SS8451S2-Y	TATA spare parts
14300512233	SPR BAND CLAMP 23DX12W TS17665 SS8451-8C	TATA spare parts

14300512241	SPR. BD CLAMP 24DX12W TS17665 SS8451S2-Y	TATA spare parts
14300512250	SPR. BD CLAMP 25DX12W TS17665 SS8451S2-Y	TATA spare parts
14300512268	SPR BAND CLAMP 26DX12W TS17665 SS8451-8C	TATA spare parts
14300512276	SPRING BAND CLAMP 27DX12W	TATA spare parts
14300512284	SPR BAND CLAMP 28DX12WTS17665 SS8451-8C	TATA spare parts
14300512292	SPR. BD CLAMP 29DX12W TS17665 SS8451S2-Y	TATA spare parts
14300512306	SPRING BAND CLAMP FORM A 12X30D TS17665	TATA spare parts
14300512349	SPR. BD CLAMP 34DX12W TS17665 SS8451S2-Y	TATA spare parts
14300512357	SPRING BAND CLAMP 35DX12W TS17665	TATA spare parts
14300512365	SPR BAND CLAMP 36DX12WTS17665 SS8451-8C	TATA spare parts
14300512381	SPRING BAND CLAMP 38DX12W	TATA spare parts
14300512403	SPRING BAND CLAMP 40DX12W TS17665	TATA spare parts
14300512420	SPR BAND CLAMP 42DX12WTS17665 SS8451-8C	TATA spare parts
14300512438	SPRING BAND CLAMP 43DX12W TS17665	TATA spare parts
14300512471	SPR BAND CLAMP 47DX12W TS17665 SS8451-8C	TATA spare parts
14300512489	SPRING BAND CLAMP 48DX12W	TATA spare parts
14300512497	SPR. BD CLAMP 49DX12W TS17665 SS8451S2-Y	TATA spare parts
14300512501	SPRING BAND CLAMP 50DX12W	TATA spare parts
14300512519	SPR BAND CLAMP 51DX12WTS17665 SS8451-8C	TATA spare parts
14300512535	SPR BAND CLAMP 53DX12W TS17665 SS8451-8C	TATA spare parts
14300512551	SPRING BAND CLAMP 55DX12W TS17665	TATA spare parts
14300512608	SPRING BAND CLAMP 60DX12W TS17665	TATA spare parts
14300512705	SPR. BD CLAMP 70DX12W TS17665 SS8451S2-Y	TATA spare parts
14300512900	SPR. BD CLAMP 90DX12W TS17665 SS8451S2-Y	TATA spare parts
14300515160	SPRING BAND CLAMP 16DX15W TS17665	TATA spare parts
14300515186	SPR. BAND CLAMP 18DX15W TS17665 SS8457S1	TATA spare parts
14300515194	SPR. BD CLAMP 19DX15W TS17665 SS8451S2-Y	TATA spare parts
14300515208	SPRING BAND CLAMP 20DX15W TS17665	TATA spare parts
14300515224	SPR BAND CLAMP 22DX15W	TATA spare parts
14300515232	SPR. BD CLAMP 23DX15W	TATA spare parts
14300515259	SPRING BAND CLAMP 25DX15W TS17665	TATA spare parts
14300515305	SPR BAND CLAMP 30DX15W TS17665 SS8451-8C	TATA spare parts
14300515496	SPRING BAND CLAMP 49DX15W	TATA spare parts
14301004CN	SUN VISOR ROLLER TYPE (36)	TATA spare parts
143010100001	SUNVISOR ROLLER TYPE (24INCH)(LHD)	TATA spare parts
143010200001	SUNVISOR ROLLER TYPE (36 +LHD+STARBUS)	TATA spare parts
143010210001	SUNVISOR ROLLER TYPE (36 +RHD+STARBUS)	TATA spare parts
143010230001	SUNVISOR (SUN & SHADE)	TATA spare parts
143010300001	SUNVISOR FUJEK (24) RHD	TATA spare parts
143010350001	SUNVISOR 36INCH RHD - BLACK BS6	TATA spare parts
143010360001	SUNVISOR ROLLER TYPE 24INCH RHD - BLACK	TATA spare parts
143040020001	SUNVISOR (SUN & SHADE)	TATA spare parts
143040030001	HANGER FOR SUNVISOR	TATA spare parts
14305012166	SPR BAND CLAMP 16DX12W TS17665SS8451S2	TATA spare parts
14305012182	SPR. BD CLAMP 18DX12W TS17665 SS8451S2-Y	TATA spare parts
14305012191	SPR. BD CLAMP 19DX12W TS17665 SS8451S2-Y	TATA spare parts
14305012204	SPR BAND CLAMP 20DX12W TS17665SS8451S2-Y	TATA spare parts



14305012239	SPR. BD CLAMP 23DX12W TS17665 SS8451S2-Y	TATA spare parts
14305012263	BAND CLAMP 26DX12W TS17665 SS8457S1-S-B	TATA spare parts
14305012271	SPR. BD CLAMP 27DX12W TS17665 SS8451S2-Y	TATA spare parts
14305012280	SPR BAND CLAMP 28DX12WTS17665 SS8451S2	TATA spare parts
14305012301	SPR. BD CLAMP 30DX12W TS17665 SS8451S2-Y	TATA spare parts
14305012328	SPR.BD.CLAMP 32DX12W TS17665 SS8451S2	TATA spare parts
14305012352	SPR BD CLAMP 35DX12W TS17665 SS8451S2-Y	TATA spare parts
14305012361	SPR.BAND CLAMP 36DX12W TS17665SS8451S2-Y	TATA spare parts
14305012433	SPR BAND CLAMP 43DX12W TS17665SS8451S2-Y	TATA spare parts
14305012441	SPR BD CLAMP 44DX12W TS17665 SS8451S2	TATA spare parts
14305012468	PR. BD CLAMP 46DX12W TS17665 SS8451S2-Y	TATA spare parts
14305012476	SPR. BD CLAMP 47DX12W TS17665 SS8451S2-Y	TATA spare parts
14305015173	SPR.BD CLAMP 17DX15W	TATA spare parts
14305096033	CLAMP 21DX12W TS17665 SS8457S1-S-C	TATA spare parts
143066	PLUG EXPANSION	TATA spare parts
14310105SF	ROOM MIRROR ARM	TATA spare parts
143101090001	ROOM MIRROR ARM	TATA spare parts
143101160001	ARM COMPLETE	TATA spare parts
143101180001	ARM COMPL.	TATA spare parts
143110110001	SALOON MIRROR-ENGTECH 9600-08TPM	TATA spare parts
143110430001	WIDE ANGLE SALOON MIRROR	TATA spare parts
14312008GN	MIRROR COMPLETE (ORDINARY)	TATA spare parts
14321004858	CLAMP 48.5 DIN 71555	TATA spare parts
14322521902	PIPE CLAMP TYPE 2	TATA spare parts
14341	PISTON RING	TATA spare parts
14344	O RING RANGE PISTON	TATA spare parts
14345	O RING RANGE BAR	TATA spare parts
14346	ORING RANGE BAR	TATA spare parts
144420180001	CURTAIN HOOKS	TATA spare parts
144420190001	BRACKET	TATA spare parts
144420200001	CLOSE BRACKET	TATA spare parts
144440510001	CURTAIN SET	TATA spare parts
14450601005	LOCKING RING 10	TATA spare parts
14450601307	LOCKING RING 13	TATA spare parts
14450601609	LOCKING RING 16	TATA spare parts
14450699013	SAFETY CLAMP	TATA spare parts
14500101SF	RVM ARM ASSY RHD/RH	TATA spare parts
14500102SF	RVM ARM ASSY LHD/LH	TATA spare parts
14500103SF	RVM ARM ASSY RHD/LH	TATA spare parts
14500104SF	RVM ARM ASSY LHD/RH	TATA spare parts
14500121SF	RVM ARM ASSY (LH)	TATA spare parts
14500123SF	RVM MIRROR ARM ASSY	TATA spare parts
145001760001	RVM ARM ASSY WITH BRACKET(COMFORT-SL)	TATA spare parts
145010420001	RVM ENGTECH MIRROR 10000-05 CVM RH	TATA spare parts
14501042CF000000	REAR VIEW MIRROR RH 6HD BUS LPO_1512_131	TATA spare parts
145010430001	RVM ENGTECH MIRROR 10000-05-01CVM LH	TATA spare parts
14501043CF000000	REAR VIEW MIRROR LH 6HD BUS LPO_1512_131	TATA spare parts

145010440001	UNDER VIEW MIRROR(PARK)ETECH 9600 (6INCH	TATA spare parts
145010520001	MIRROR ARM COMPLETE (DRIVER SIDE)	TATA spare parts
145010670001	PARKING MIRROR (RECTANGULAR)	TATA spare parts
145010710001	LH RVM ASSY	TATA spare parts
145010720001	RH RVM ASSY	TATA spare parts
145010730001	LH RVM ASSY	TATA spare parts
145010770001	RVM ARM ASSEMBLY WITH BRACKET	TATA spare parts
145010780001	MIRROR ARM COMPLETE-DRIVER SIDE	TATA spare parts
1450108014	FELT DISC	TATA spare parts
145010870001	RH RVM ARM ASSEMBLY	TATA spare parts
145010880001	RVM ARM ASSEMBLY	TATA spare parts
145010890001	RVM MOUNTING BRACKET	TATA spare parts
1450109001	PACKING RING	TATA spare parts
1450109042	SEALING RING	TATA spare parts
145010970001	MIRROR ARM COMPL./DRV	TATA spare parts
145010990001	LH RVM ASSEMBLY	TATA spare parts
145011000001	RVM ASSY(RH)	TATA spare parts
145011100001	LH RVM ARM ASSEMBLY	TATA spare parts
145011130001	ARM COMPL	TATA spare parts
145011140001	RVM MTG BKT	TATA spare parts
145011230001	RVM ASSY (LH) MOTORISED	TATA spare parts
145011240001	RVM ASSY (RH) MOTORISED	TATA spare parts
145011260001	RVM ARM ASSY WITH BRACKET(COMFORT-SL)	TATA spare parts
145011290001	RH RVM ARM ASSY WITH BRACKET	TATA spare parts
145011310001	MIRROR ARM COMPLETE/ DRIVER	TATA spare parts
145011330001	LH RVM ARM ASSEMBLY	TATA spare parts
145011340001	RH RVM ARM ASSEMBLY	TATA spare parts
145012380001	ARM COMPLETE	TATA spare parts
145020080001	ARM FOR UNDERVIEW MIRROR	TATA spare parts
14502019SN	BRACKET FOR MIRROR	TATA spare parts
14502025AN	R.V.M.BRACKET	TATA spare parts
14502096SF	CAB COMPLT RHD SLEEPER	TATA spare parts
14502120SF000000	RVM ARM ASSY( 613 - LHD - DRV.SIDE	TATA spare parts
145021870001	ARM BRACKET	TATA spare parts
145025110001	ARM UNDER VIEW MIRROR ELEANZA	TATA spare parts
145040200001	REAR VIEW MIRROR ARM BRACKET	TATA spare parts
1450410011	FILTER SIEVE	TATA spare parts
145090000001	BASE BRACKET LH FOR 14501099CF	TATA spare parts
145090010001	BASE BRACKET RH FOR 14501100CF	TATA spare parts
145090020001	RVM COVER LH FOR 14501099CF	TATA spare parts
145090030001	RVM COVER RH FOR 14501100CF	TATA spare parts
14511000AN	GUARD RAIL BRACKET	TATA spare parts
145110280002	BRACKET FOR GUARD RAIL (PC)	TATA spare parts
145201780001	SCHOOL BUS INSIGNIA	TATA spare parts
145210450001	ARM COMPL	TATA spare parts
145210760007	BROWN VINYL MACAL SERIES BS6	TATA spare parts
145210800001	STICKER - SENEGAL EMERGENT	TATA spare parts

1453315010	CLAMPING NUT	TATA spare parts
1453528011	CLAMPING BOLT	TATA spare parts
14550500249	EXT.CIRCLIP 24X1.75 H-IS3075P1 BS6-PH2	TATA spare parts
14550501601	EXT CIRCLIP 16X1.5H-IS3075P1-SS8400	TATA spare parts
14550502501	EXT CIRCLIP 25 X 2H	TATA spare parts
14550502802	EXT CIRCLIP 28 X 2H	TATA spare parts
14550503400	EXT CIRCLIP 34 X 2.5H	TATA spare parts
14550503507	EXT.CIRCLIP 35X2.5H IS3075 PT1-SS8400	TATA spare parts
14550504007	EXT CIRCLIP 40 X 2.5H	TATA spare parts
14550504201	EXT.CIRCLIP 42X2.5	TATA spare parts
14550504503	EXT CIRCLIP 45 X 2.5H	TATA spare parts
14550599016	CIRCLIP A19X1.7	TATA spare parts
14550600804	EXT CIRCLIP 8 X 0.8N	TATA spare parts
14550601002	EXT CIRCLIP 10 X 1N	TATA spare parts
14550601207	EXT.CIRCLIP 12X1N-IS3075 PT1-SS8400 BS6	TATA spare parts
14550601401	EXT CIRCLIP 14 X 1N	TATA spare parts
14550601509	EXT CIRCLIP 15 X 1N	TATA spare parts
14550601606	EXT CIRCLIP 16 X 1N	TATA spare parts
14550601703	EXT CIRCLIP 17 X 1N	TATA spare parts
14550601801	EXT CIRCLIP 18 X 1.2N	TATA spare parts
14550602009	EXT CIRCLIP 20 X 1.2N	TATA spare parts
14550602203	EXT CIRCLIP 22 X 1.2N	TATA spare parts
14550602408	EXT.CIRCLIP 24X1.2N IS3075 PT1-SS8400	TATA spare parts
14550602505	EXT CIRCLIP 25 X 1.2N	TATA spare parts
14550602807	EXT CIRCLIP 28 X 1.5N	TATA spare parts
14550603005	EXT CIRCLIP 30 X 1.5N	TATA spare parts
14550603200	EXT.CIRCLIP 32X1.5N IS3075 PT1-SS8400	TATA spare parts
14550603404	EXT CIRCLIP 34 X 1.5N	TATA spare parts
14550603501	EXT CIRCLIP 35 X 1.5N	TATA spare parts
14550603510	EXT CIRCLIP 35 X 1.5	TATA spare parts
14550603803	EXT CIRCLIP 38X1.75N-IS3075P1-SS8400	TATA spare parts
14550604001	EXT CIRCLIP 40 X 1.75N	TATA spare parts
14550604010	EXT CIRCLIP 40 X 1.75	TATA spare parts
14550604206	CIRCLIP 42X1.75	TATA spare parts
14550604508	CIRCLIP BS4	TATA spare parts
14550604516	EXT CIRCLIP 45 X 1.75	TATA spare parts
14550604800	EXT CIRCLIP 48 X 1.75N	TATA spare parts
14550605008	EXT.CIRCLIP 50X2N IS3075 PT1 SS8400 BS6	TATA spare parts
14550605504	EXT CIRCLIP 55 X 2N	TATA spare parts
14550605601	EXT CIRCLIP 56 X 2N	TATA spare parts
14550606004	EXT.CIRCLIP 60X2N IS3075 PT1	TATA spare parts
14550607001	CIRCLIP EXT A70 X 2.5	TATA spare parts
14550608805	EXTERNAL CIRCLIP (88 X 3)	TATA spare parts
14550610508	EXT.CIRCLIP 105X4N IS3075 PT1-SS8400	TATA spare parts
14550618002	EXTERNAL CIRCLIP 180X4N IS3075P1-SS8400	TATA spare parts
14550699002	CIRCLIP SDN 5505X08	TATA spare parts
14550699011	EXT CIRCLIP 22X1.5 TS17637	TATA spare parts

14550699029	CIRCLIP 28 X 1.75	TATA spare parts
14550699053	EXT CIRCLIP 52 X 2.5	TATA spare parts
14550699100	EXT.CIRCLIP 6X0.7N-IS3075 PT.1-SS8400	TATA spare parts
14550800501	CIRCLIP E 5.0X0.7 IS3075 PT3 SS8400	TATA spare parts
14550800609	EXT CIRCLIP 6 X 0.7	TATA spare parts
14550800706	CIRCLIP E 7.0X0.9 IS3075 PT3 SS8400	TATA spare parts
14550800901	EXT CIRCLIP 9 X 1.1	TATA spare parts
14550801206	EXT CIRCLIP 12 X 1.3	TATA spare parts
145530	SEAL O RING	TATA spare parts
1455526067	COVER FUEL FILTER	TATA spare parts
145582	SEAL O RING	TATA spare parts
145702960001	RAMP ASSEMBLY	TATA spare parts
145712100001	DOLPHIN GRAB HANDLE (PLASTIC)	TATA spare parts
145712400001	GRAB HANDLE-PASSENGER	TATA spare parts
145712540001	GRAB HANDLE	TATA spare parts
145721490001	REAR W/S GLASS-5D-CLEAR	TATA spare parts
145722630001	LATCH ASSEMBLY	TATA spare parts
145722720001	AIR HORN LEVER TYPE	TATA spare parts
145723540001	STEERING COVER	TATA spare parts
145723640001	MAGAZINE POUCH BS6	TATA spare parts
145725390001	LADDER LATCH	TATA spare parts
1457413010	OVER FLOW VALVE	TATA spare parts
1457431003	FUEL FILTER ELEMENT CARTRIDGE BS1	TATA spare parts
1457431003DF	FUEL FILTER 1.1 L CLOTH	TATA spare parts
1457431147	FILTER ELEMENT	TATA spare parts
1457434002	PRE FILTER ASSY	TATA spare parts
14580505202	INTERNAL CIRCLIP 52X2.5 N	TATA spare parts
14580506209	INT CIRCLIP 62 X 3N	TATA spare parts
14580601104	INT CIRCLIP 11 X 1N	TATA spare parts
14580601201	INTERNAL CIRCLIP 12X1N IS3075P2-SS8400 B	TATA spare parts
14580601601	INT CIRCLIP 16 X 1	TATA spare parts
14580601619	INT CIRCLIP 16 X 1	TATA spare parts
14580602003	INT CIRCLIP 20 X 1N	TATA spare parts
14580602500	INT CIRCLIP 25 X 1.2N	TATA spare parts
14580602801	INTERNAL CIRCLIP 28 X 1.2	TATA spare parts
14580603000	INT CIRCLIP 30 X 1.2N	TATA spare parts
14580603204	INT CIRCLIP 32X1.2N-IS3075P2-SS8400	TATA spare parts
14580603212	INT CIRCLIP 32 X 1	TATA spare parts
14580603506	CIRCLIP 35 DIN 472	TATA spare parts
14580603603	INT CIRCLIP 36 X 1.5N	TATA spare parts
14580603808	INT CIRCLIP 38 X 1.5N	TATA spare parts
14580604006	INT CIRCLIP 40 X 1.75N	TATA spare parts
14580604201	INT CIRCLIP 42 X 1.75N	TATA spare parts
14580604219	INT CIRCLIP 42X1.75 TS17636S1 SS8400	TATA spare parts
14580604502	INT CIRCLIP B45 X 1.75	TATA spare parts
14580604707	INTERNAL CIRCLIP47X1.75N IS3075P2 SS8400	TATA spare parts
14580605002	INT CIRCLIP 50 X 2N	TATA spare parts

14580605509	INT CIRCLIP 55 X 2N	TATA spare parts
14580605606	INT CIRCLIP B56 X 2	TATA spare parts
14580605801	INT CIRCLIP B 58 X 2	TATA spare parts
14580606009	INTERNAL CIRCLIP 60X2N IS3075P2 SS8400	TATA spare parts
14580606203	INTERNAL CIRCLIP 62X2N IS3075P2 SS8400	TATA spare parts
14580606807	INTERNAL CIRCLIP 68X2.5N IS3075P2 SS8400	TATA spare parts
14580607005	INTERNAL CIRCLIP 70X2.5N IS3075P2 SS8400	TATA spare parts
14580607200	INTERNAL CIRCLIP 72X2.5N IS3075P2 SS8400	TATA spare parts
14580607501	INT CIRCLIP 75 X 2.5N BS4	TATA spare parts
14580608001	INTERNAL CIRCLIP 80X2.5N IS3075P2 SS8400	TATA spare parts
14580608508	INTERNAL CIRCLIP 85X3N IS3075P2 SS8400	TATA spare parts
14580609202	INTERNAL CIRCLIP 92X3N IS3075P2 BS6-PH2	TATA spare parts
14580610006	INTERNAL CIRCLIP 100X3N IS3075P2 SS8400	TATA spare parts
14580611002	INT CIRCLIP 110 X 4N	TATA spare parts
14580612009	INT CIRCLIP 120 X 4N	TATA spare parts
14580613005	CIRCLIP	TATA spare parts
14580696008	INTERNALCIRCLIP63X2NIS3075P2SS8400 BS6	TATA spare parts
14592007SN	KNOB (FOR HUB COVER) FRP	TATA spare parts
14592008SN	KNOB (FOR HUB COVER) FRP	TATA spare parts
1460023302	WOODRUFF KEY	TATA spare parts
1460100001	SHIM 1.00 MM	TATA spare parts
1460102312	SLOTTED WASHER	TATA spare parts
146011170001	FRONT BUMPER ASSEMBLY	TATA spare parts
146011220001	FRONT BUMPER ASSY	TATA spare parts
146011270001	FRONT BUMPER COMPLETE	TATA spare parts
146011280001	FRONT BUMPER COMPLETE (I BEAM)	TATA spare parts
146011290001	FRONT BUMPER COMPLETE	TATA spare parts
146011300001	FRONT BUMPER COMPLETE	TATA spare parts
146011310001	FRONT BUMPER (METALLIC) ASSY	TATA spare parts
146011360001	FRONT BUMPER ASSEMBLY	TATA spare parts
146011390001	FRP FRONT BUMPER (CLEAR LENSE H/L CAVITY	TATA spare parts
146012350001	FRP FRONT BUMPER (COMFORT MODEL)	TATA spare parts
1460147006	SLOTTED WASHER	TATA spare parts
14602001CF	END BLADE FRONT/RH	TATA spare parts
14602002CF	END BLADE FRONT/LH	TATA spare parts
14602031SF	CAB COMPLT RHD SLEEPER	TATA spare parts
146020770001	FRONT BUMPER ASSEMBLY	TATA spare parts
146020930001	FRONT BUMPER COMPL (COMFORT-SHEET META	TATA spare parts
146020990001	FRONT BUMPER COMPLETE	TATA spare parts
146021090001	FRONT BUMPER COMPLETE	TATA spare parts
146021100001	FRONT BUMPER COMPLETE METALIC	TATA spare parts
146021260001	FRONT BUMPER COMPT..FRP	TATA spare parts
146021560001	FRONT BUMPER ASSEMBLY	TATA spare parts
146021660001	FRONT BUMPER COMPL	TATA spare parts
146021680001	FRONT BUMPER COMPL	TATA spare parts
146021720001	FRONT BUMPER COMPL	TATA spare parts
1460283311	SHAFT SEALING RING	TATA spare parts

1460362309	PRESSURE CONTROL VALVE	TATA spare parts
1460362457	CONTROL VALVE	TATA spare parts
14604010FN	FRP FRONT BUMPER-CENTER/LP/LPO	TATA spare parts
14611014SF	BUMPER BLADE COMPLETE	TATA spare parts
146110530001	REAR BUMPER ASSEMBLY - LH	TATA spare parts
146110540001	REAR BUMPER ASSEMBLY - RH	TATA spare parts
146110990001	FRP REAR BUMPER (COMFORT MODEL)	TATA spare parts
146111090001	REAR BUMPER COMPL (COMFORT SHEET METAL)	TATA spare parts
146111130001	REAR BUMPER COMPLETE	TATA spare parts
146111160002	REAR BUMPER COMPL	TATA spare parts
146111180001	REAR BUMPER ASSEMBLY	TATA spare parts
146111230001	REAR BUMPER COMPLETE - SHEET METAL	TATA spare parts
146111250001	REAR BUMPER ASSY COMPLETE	TATA spare parts
146111280001	REAR BUMPER COMPLETE - FRP	TATA spare parts
146111320001	REAR BUMPER COMPLETE	TATA spare parts
146111330001	REAR BUMPER ASSY COMPLETE	TATA spare parts
146111370001	REAR BUMPER COMPL (FRP)	TATA spare parts
146111380001	REAR BUMPER COMPL	TATA spare parts
146111390001	REAR BUMPER COMPL	TATA spare parts
146111400001	REAR BUMPER COMPL	TATA spare parts
146111480001	FRP REAR BUMPER (COMFORT MODEL)	TATA spare parts
146111510001	REAR BUMPER COMPL	TATA spare parts
146111520001	REAR BUMPER ASSEMBLY	TATA spare parts
146111580001	REAR BUMPER COMPLETE BS6	TATA spare parts
14612002CF	END BLADE REAR/RH	TATA spare parts
14612003CF	END BLADE REAR/LH	TATA spare parts
14612004PF	TRIM	TATA spare parts
14612011CN	REFLECTOR END BLADE	TATA spare parts
146121210001	REAR BUMPER LH	TATA spare parts
146121220001	REAR BUMPER RH	TATA spare parts
146121250001	REAR BUMPER CENTER	TATA spare parts
146121480001	REAR FRP BUMPER BS6	TATA spare parts
146121490001	REAR FRP BUMPER	TATA spare parts
146121510001	REAR FRP BUMPER	TATA spare parts
14614007FN	FRP REAR BUMP.E.BLADE-LH(MODF)	TATA spare parts
14614009FN	FRP REAR CTR.BUMPER (BIG)	TATA spare parts
14614034FN000000	CAB COMPLT RHD SLEEPER	TATA spare parts
14614035FN000000	CAB COMPLT RHD SLEEPER	TATA spare parts
146157	WASHER PLAIN	TATA spare parts
14620500705	SPRING RING 7	TATA spare parts
14620500802	SPRING RING 8	TATA spare parts
14620503500	SPRING RING 35	TATA spare parts
14620503801	SPRING RING 38	TATA spare parts
14620505502	SPRING RING 55	TATA spare parts
14620507009	SPRING RING 70 TS 17641	TATA spare parts
14621501004	SPRING RING R10	TATA spare parts
14621501608	SPRING RING R16	TATA spare parts

1463104309	TIMING DEVICE PISTON	TATA spare parts
1463161305	LEVER SHAFT	TATA spare parts
1463161329	LEVER SHAFT	TATA spare parts
1463218309	SLIDER	TATA spare parts
1463370326	DELIVERY VALVE HOLDER	TATA spare parts
1463453306	BLEEDER SCREW	TATA spare parts
1463456303	THROTTLE SCREW	TATA spare parts
1466100305	DRIVE SHAFT	TATA spare parts
1466110398	CAM PLATE	TATA spare parts
1466317301	TOOTHED GEAR	TATA spare parts
1467010355	TIMER STOP PIN ASSY	TATA spare parts
1467030302	VANE PUMP	TATA spare parts
1467134663	MPC UNIT 4DL TC MANIFOLD	TATA spare parts
1467230407	KSB UNIT FIP TC	TATA spare parts
1467414436	SOLENOID OPERATED VALVE	TATA spare parts
1468334326	DISTRIBUTOR HEAD	TATA spare parts
1468334835	DISTRIBUTOR HEAD	TATA spare parts
1468522273	DELIVERY VALVE	TATA spare parts
1468532225	DELIVERY VALVE	TATA spare parts
148004000001	LUX RECL SEAT	TATA spare parts
1480107001	GASKET	TATA spare parts
148012730001	2 POINT SEAT BELT(COMMON TO ALL PASSENGER)	TATA spare parts
148020670001	HANDLE (DRIVER DOOR/SEAT) - GREY	TATA spare parts
14802067PF	HANDLE (DRIVER DOOR/SEAT)	TATA spare parts
148024350001	SEAT FIBRE COVER	TATA spare parts
148024360001	GRAB HANDLE- BLACK BS6	TATA spare parts
148040930001	RETRACTABLE ARMREST FOR LP407	TATA spare parts
148040940001	FOLDABLE ARMREST WITH MOUNTING BRACKET	TATA spare parts
148040950001	FOLDABLE ARMREST SUPPORT BRACKET	TATA spare parts
148090000001	3 POINT RETRACTOR TYPE PASSENGER SEAT BELT	TATA spare parts
148090010001	WINGER SEAT BELT&FRT SEAT PASS SIDE	TATA spare parts
148110350001	SEAT ASSY 1S HBK FLR MOUNTED +A REST+ BE	TATA spare parts
148110530001	SEAT ASSY (CHILDREN-2-SEATER-MOD)	TATA spare parts
148110540001	SEAT ASSY (CHILDREN-3-SEATER-MOD)	TATA spare parts
148110540003	SEAT ASSY (CHILDREN-3-SEATER-MOD-BELT)	TATA spare parts
148110540006	CHILDREN SEAT(3-SEATER)	TATA spare parts
148112470002	SEAT ASSY(HBACK-3S-1215MM-BELT+ARM-V.ENG)	TATA spare parts
148112470006	SEAT ASSY(HBACK-3S-1215MM-VALUE ENGG)	TATA spare parts
148112470008	SEAT ASSY(HBACK-3S-1215MM-VALUE ENGG)	TATA spare parts
148112480003	SEAT ASSY(HBACK-2S-810MM-ARM+BELT-V ENG)	TATA spare parts
148112480008	SEAT ASSY(HBACK-2S-810MM+BELT+V ENG)	TATA spare parts
148112480010	SEAT ASSY(HBACK-2S-810MM-VALUE ENGG)	TATA spare parts
148112480012	SEAT ASSY(HBACK-2S-810MM-VALUE ENGG)	TATA spare parts
148112490007	SEAT ASSY(HBACK-3SEATER-REAR SEAT)	TATA spare parts
148112840001	SEAT ASSY (7 SEATER CHILDREN)	TATA spare parts
148113010001	SEAT ASSY(HBACK-3S-1215MM-FLOOR MTG)	TATA spare parts
148113020002	SEAT ASSY(HBACK-3S-1215MM-FR-BELT+AREST)	TATA spare parts

148113020003	SEAT ASSY(HBACK-3S-1215MM-FLOOR-AREST)	TATA spare parts
148113030002	SEAT ASSY(HBACK-2S-810MM-FR-BELT+AREST)	TATA spare parts
148113030003	SEAT ASSY(HBACK-2S-810MM-FLOOR-AREST)	TATA spare parts
148113940001	SEAT ASSY (HBK-3 STR-ARMREST+ SEAT BELT)	TATA spare parts
148113940003	SEAT ASSY (HBK- 3 STR+ SEAT BELT)	TATA spare parts
148113950001	SEAT ASSY (HBK-2 STR-ARMREST+ SEAT BELT)	TATA spare parts
148113950003	SEAT ASSY (HBK- 2 STR+ SEAT BELT)	TATA spare parts
148113960001	SEAT ASSY (HBK- 3 STR+ SEAT BELT)	TATA spare parts
148113990001	SEAT ASSY(HBK-1 STR-SEAT BELT+ARMREST)	TATA spare parts
148114850001	SEAT ASSY(3) FLR MTG ARM REST SEAT BELT	TATA spare parts
148114850002	SEAT ASSY(3) FLR MTG SEAT BELT	TATA spare parts
148114860001	SEAT ASSY(FLR MTG HB)(2)	TATA spare parts
148114860002	SEAT ASSY(FLR MTG HB)(2)ARM SEAT BELT	TATA spare parts
148114860004	SEAT ASSY(2) FLR MTG HB SEAT BELT	TATA spare parts
148114870002	SEAT ASSY(3) FLR MTG SEAT BELT	TATA spare parts
148114880003	SEAT ASSY(3) FLR MTG HB SEAT BELT	TATA spare parts
148114960001	SEAT ASSY (1) JUMP SEAT	TATA spare parts
148116660001	FOLDING SEAT(3)	TATA spare parts
148118780001	SEAT ASSY.3S(HBK FLOOR MTG)	TATA spare parts
148118780002	SEAT ASSY.3S(HBK FLOOR MTG)	TATA spare parts
148118790001	SEAT ASS.1S(HBK FLOOR MTG.)	TATA spare parts
148118860001	SEAT ASSY 3S HBK FLR MOUNTED	TATA spare parts
148118860002	SEAT ASSY 3S HBK FLR MOUNTED	TATA spare parts
148118870001	SEAT ASSY 2S HBK FLR MOUNTED	TATA spare parts
148118870002	SEAT ASSY 2S HBK FLR MOUNTED	TATA spare parts
148118880001	SEAT ASSY 3S HBK FLR MOUNTED	TATA spare parts
148119400002	SEAT ASSY 3S HBK FLR MOUNTED +A REST+ BE	TATA spare parts
148119400003	SEAT ASSY 3S HBK FLR MOUNTED + BELT	TATA spare parts
148119410001	SEAT ASSY 2S HBK FLR MOUNTED +A REST+ BE	TATA spare parts
148119410002	SEAT ASSY 2S HBK FLR MOUNTED +A REST+ BE	TATA spare parts
148119490001	SEAT ASSY 3S HBK FLR MOUNTED + BELT	TATA spare parts
148119490004	3S HBK SEAT ASSY FLR MOUNTED	TATA spare parts
148119500001	SEAT ASSY 3S HBK FLR MOUNTED + BELT	TATA spare parts
148119500004	3S HBK SEAT ASSY FLR MOUNTED	TATA spare parts
148119680001	HIGH BACK 3 SEATER	TATA spare parts
148124380001	SEAT ASSY(HBACK-3S-HIGH ROOF)	TATA spare parts
148124390001	SEAT ASSY(HBACK-3S-HIGH ROOF)	TATA spare parts
148124410001	SEAT ASSY(HBACK-3S-HIGH ROOF)	TATA spare parts
148124420001	SEAT ASSY(HBACK-2S-HIGH ROOF)	TATA spare parts
148124430001	SEAT ASSY(HBACK-2S-HIGH ROOF)	TATA spare parts
148124440001	SEAT ASSY(HBACK-2S-HIGH ROOF)	TATA spare parts
148124450001	SEAT ASSY(HBACK-2S-HIGH ROOF)	TATA spare parts
148124460001	SEAT ASSY(HBACK-3S-HIGH ROOF)	TATA spare parts
148124470001	SEAT ASSY(HBACK-3S-HIGH ROOF)	TATA spare parts
148124490001	SEAT ASSY(HBACK-3S+BELT+TATA JOHNSON)	TATA spare parts
148124690001	SEAT ASSY(3)	TATA spare parts
148124700001	SEAT ASSY(3)	TATA spare parts



148124710001	SEAT ASSY(3)	TATA spare parts
148124720001	SEAT ASSY(3)	TATA spare parts
148124780001	SEAT ASSY(1)	TATA spare parts
148124790001	SEAT ASSY(1)	TATA spare parts
148124800001	SEAT ASSY(3)	TATA spare parts
148124810001	SEAT ASSY(3)	TATA spare parts
148124820001	SEAT ASSY(3)	TATA spare parts
148128560001	SEAT ASSY (3STR-HBK-LHD+SEAT BELT	TATA spare parts
148128570001	SEAT ASSY (2STR-HBK+SEAT BELT)	TATA spare parts
148128610001	SEAT ASSY (1STR-HBK+SEAT BELT)	TATA spare parts
148128820002	SEAT ASSY. (3)	TATA spare parts
148128830002	SEAT ASSY. (3)	TATA spare parts
148128840002	SEAT ASSY. (2)	TATA spare parts
148128850002	SEAT ASSY. (2)	TATA spare parts
148128860002	SEAT ASSY. (3)	TATA spare parts
148128870002	SEAT ASSY	TATA spare parts
148128880002	SEAT ASSY. (3)	TATA spare parts
148128890001	SEAT ASSY. (3)	TATA spare parts
148128890002	SEAT ASSY. (3)	TATA spare parts
148128900001	SEAT ASSY. (2)	TATA spare parts
148128910001	SEAT ASSY. (3)	TATA spare parts
148129900001	SEAT ASSY. (2)	TATA spare parts
148129900002	SEAT ASSY. (2)	TATA spare parts
148129910001	SEAT ASSY. (2)	TATA spare parts
148129920001	SEAT ASSY. (2)	TATA spare parts
148129930001	SEAT ASSY. (2)	TATA spare parts
148129940001	SEAT ASSY. (2)	TATA spare parts
148129990001	SEAT ASSY. (2)	TATA spare parts
148130000001	SEAT ASSY. (2)	TATA spare parts
148130510001	SEAT ASSY. (2)	TATA spare parts
148130520001	SEAT ASSY. (2)	TATA spare parts
148130900001	SEAT ASSY. (1) FOR COMFORT GSO	TATA spare parts
148131870001	SEAT ASSY. (2) FOR LIBERIA	TATA spare parts
148131880001	SEAT ASSY. (3) FOR LIBERIA	TATA spare parts
148131980001	SEAT ASSY. (2) KAD-01-G	TATA spare parts
148131980002	SEAT ASSY. (2) KAD-01-G	TATA spare parts
148131990001	SEAT ASSY. (3) KAD-02-G	TATA spare parts
148131990002	SEAT ASSY. (3) KAD-02-G	TATA spare parts
148132040001	SEAT ASSY. (3) KAD-02-G	TATA spare parts
148132050001	SEAT ASSY. (3) KAD-02-G	TATA spare parts
148134310001	SEAT ASSY(3S-HBACK-SIDE MNTE-D-PINNACLE)	TATA spare parts
148134320001	SEAT ASSY(3S-HBACK-SIDE MNTE-D-PINNACLE)	TATA spare parts
148134330001	SEAT ASSY(3S-HBACK-SIDE MNTE-D-PINNACLE)	TATA spare parts
148134340001	SEAT ASSY(3S-HBACK-SIDE MNTE-D-PINNACLE)	TATA spare parts
148134350001	SEAT ASSY(2S-HBACK-SIDE MNTE-D-PINNACLE)	TATA spare parts
148134360001	SEAT ASSY(2S-HBACK-SIDE MNTE-D-PINNACLE)	TATA spare parts
148134370001	SEAT ASSY(2S-HBACK-SIDE MNTE-D-PINNACLE)	TATA spare parts

148134380001	SEAT ASSY(3S-HBACK-SIDE MNTEd-PINNACLE)	TATA spare parts
148134690001	SEAT ASSY/ (1) JUMP SEAT	TATA spare parts
148134700001	SEAT ASSY. (3) FOR LIBERIA	TATA spare parts
148150050001	FOLDING SEAT-LOCK ASSEMBLY LH	TATA spare parts
148150060001	FOLDING SEAT-LOCK ASSEMBLY RH	TATA spare parts
148170360001	SEAT ASSY 2S	TATA spare parts
148170490001	SEAT ASSY 1S(CVG MAKE)10065230211631	TATA spare parts
148170500001	SEAT ASSY 2S(CVG MAKE)10065220211631	TATA spare parts
148170510001	CO-DRIVER SEAT	TATA spare parts
148170520001	SEAT ASSY 2S(CVG MAKE)10065190202631	TATA spare parts
148170530001	SEAT ASSY 2S(CVG MAKE)10065180202631	TATA spare parts
148170540001	SEAT ASSY 2S(CVG MAKE)10065170202631	TATA spare parts
148170550001	SEAT ASSY 2S(CVG MAKE)10065240211631	TATA spare parts
148170560001	SEAT ASSY 2S(CVG MAKE)10065210202631	TATA spare parts
148170570001	SEAT ASSY 2S(CVG MAKE)10065200202631	TATA spare parts
148170660001	SEAT ASSY 3S	TATA spare parts
148170830001	SEAT ASSEMBLY (3 STR)	TATA spare parts
148170840001	SEAT ASSEMBLY (3 STR)	TATA spare parts
148170850001	SEAT ASSEMBLY (3 STR)	TATA spare parts
148170860001	SEAT ASSEMBLY (3 STR)	TATA spare parts
148170870001	SEAT ASSEMBLY (3 STR)	TATA spare parts
148170980001	SEAT ASSY 2S	TATA spare parts
148170990001	SEAT ASSY 3S	TATA spare parts
148171000001	SEAT ASSY 3S	TATA spare parts
148171010001	SEAT ASSY 3S	TATA spare parts
148171020001	SEAT ASSY 1S	TATA spare parts
148171060001	SEAT ASSEMBLY 1S	TATA spare parts
148171100001	SEAT ASSY(3 STR-ARMREST+SEAT BELT)	TATA spare parts
148171110001	SEAT ASSY(3 STR +SEAT BELT)	TATA spare parts
148171120001	SEAT ASSY(3 STR +SEAT BELT)	TATA spare parts
148171130001	SEAT ASSY(2 STR-ARMREST+SEAT BELT)	TATA spare parts
148171140001	SEAT ASSY(2 STR+SEAT BELT)	TATA spare parts
148171150001	SEAT ASSY(3 STR+SEAT BELT)	TATA spare parts
148171170001	FOLDING SEAT(3STR+ARMREST)	TATA spare parts
148171320001	SEAT ASSY (3 STR- LAP BELT)	TATA spare parts
148171330001	SEAT ASSY (3 STR)	TATA spare parts
148171450001	SEAT ASSY 2S RH	TATA spare parts
148171490001	SEAT ASSY 2 S FLR MOUNTED	TATA spare parts
148171510001	SEAT ASSY 2 S FLR MOUNTED	TATA spare parts
148171520001	SEAT ASSY 3S FLR MOUNTED	TATA spare parts
148171530001	SEAT ASSY 3S FLR MOUNTED	TATA spare parts
148171540001	SEAT ASSY 1S FLR MOUNTED	TATA spare parts
148171630001	SEAT ASSY . (3)	TATA spare parts
148171700001	SEAT ASSY 2S HBK	TATA spare parts
148171710001	SEAT ASSY 2S HBK	TATA spare parts
148171720001	SEAT ASSY 2S HBK	TATA spare parts
148171730001	SEAT ASSY 2S HBK	TATA spare parts

148171740001	SEAT ASSY 2S HBK	TATA spare parts
148171760001	SEAT ASSY 2S HBK	TATA spare parts
148171770001	SEAT ASSY 2S HBK	TATA spare parts
148171780001	SEAT ASSY 2S HBK	TATA spare parts
148171790001	SEAT ASSY 2S HBK	TATA spare parts
148171800001	SEAT ASSY 3S HBK	TATA spare parts
148171810001	SEAT ASSY 3S HBK	TATA spare parts
148171930001	SEAT ASSY (3)	TATA spare parts
148171940001	SEAT ASSY (3)	TATA spare parts
148171950001	SEAT ASSY (3)	TATA spare parts
148171960001	SEAT ASSY (1)	TATA spare parts
148171970001	SEAT ASSY (2)	TATA spare parts
148171980001	SEAT ASSY (2)	TATA spare parts
148171990001	SEAT ASSY (3)	TATA spare parts
148172000001	SEAT ASSY (3)	TATA spare parts
148172010001	SEAT ASSY (3)	TATA spare parts
148172020001	SEAT ASSY (3)	TATA spare parts
148172030001	SEAT ASSY. (2)	TATA spare parts
148172040001	SEAT ASSY. (2)	TATA spare parts
148172050001	SEAT ASSY. (2)	TATA spare parts
148172060001	SEAT ASSY. (3)	TATA spare parts
148172070001	SEAT ASSY. (3)	TATA spare parts
148172080001	SEAT ASSY. (3)	TATA spare parts
148172090001	SEAT ASSY. (3)	TATA spare parts
148172100001	SEAT ASSY. (3)	TATA spare parts
148172110001	SEAT ASSY. (1)	TATA spare parts
148172120001	SEAT ASSY. (2)	TATA spare parts
148172130001	SEAT ASSY. (3)	TATA spare parts
148172140001	SEAT ASSY. (3)	TATA spare parts
148172150001	SEAT ASSY. (3)	TATA spare parts
148172560001	SEAT ASSY (3)	TATA spare parts
148173350001	SEAT ASSY (2)	TATA spare parts
148173360001	SEAT ASSY (2)	TATA spare parts
148173370001	SEAT ASSY (3)	TATA spare parts
148173380001	SEAT ASSY (3)	TATA spare parts
148173500001	SEAT ASSY (3 STR-RH-LAP BELT+ARMREST)	TATA spare parts
148173510001	SEAT ASSY (2STR-LH-LAP BELT+ARMREST)	TATA spare parts
148173860001	SEAT ASSY 3S RH + 1LAPBELT & AMP ARMREST	TATA spare parts
148173870001	ASSY 3 SEATER RH WITH ARMREST	TATA spare parts
148173880001	SEAT ASSY 3S RH FNDR HT 560 + ARM REST	TATA spare parts
148173890001	ASSY 3 SEATER RH WITH ARMREST	TATA spare parts
148173900001	SEAT ASSY. (3) FOR UTC LP 42	TATA spare parts
148173910001	ASSY 3 SEATER RH REAR CUT HT 195	TATA spare parts
148173920001	ASSY 1 SEATER WITH 1 LAP BELT & AMP ARMR	TATA spare parts
148173930001	SEAT ASSY. (2) FOR UTC LP 42	TATA spare parts
148173940001	SEAT ASSY 2S LH + 1 LAP BELTS & AMP ARMR	TATA spare parts
148173950001	SEAT ASSY. (2) FOR UTC LP 42	TATA spare parts

148173960001	SEAT ASSY. (2) FOR UTC LP 52	TATA spare parts
148174640003	SEAT ASSEMBLY (2) RH WITH 1 LAP BELT & A	TATA spare parts
148174650003	SEAT ASSEMBLY (2) RH BS6	TATA spare parts
148174890001	ASSY 2 SEATER LH BS6	TATA spare parts
148180000001	LOCK ASSEMBLY SET(LH+RH) FOR FOLDABLE SE	TATA spare parts
148190030001	3 POINT RETRACTABLE PASSENGER SEAT BELT	TATA spare parts
148501350001	DRIVER SEAT WITH HR-RHD(EXHIBITION BUS	TATA spare parts
148501380001	407 TYPE DRIVER SEAT WITH HDREST (LHD)	TATA spare parts
148501470001	DRIVERS SEAT	TATA spare parts
148501490001	MECHANICAL SUSP SEAT (LHD-MODIFIED)	TATA spare parts
148530100001	GAS SPRING FOR DRV.SEAT(F12106139Q01)	TATA spare parts
148590000001	GAS SPRING FOR 14850149CF MECH.SUS. DR S	TATA spare parts
14961004CN000000	CAB COMPLT RHD SLEEPER	TATA spare parts
149610130001	DRIVER SEAT & BELT	TATA spare parts
14975	BOOT ACCORDION	TATA spare parts
15001F01	OUTSIDE WAIST RAIL BEADIN	TATA spare parts
15002F01	OUTSIDE RUBRAIL BEADING E	TATA spare parts
15003F01	MIRROR BRACKET	TATA spare parts
15005F01	INSIDE MIRROR	TATA spare parts
15006F01	ROUND MIRROR	TATA spare parts
15007F01	DR'S DOOR CHECK BELT BRAC	TATA spare parts
15008F01	DUBAI TYPE MIRROR BRACKET	TATA spare parts
15013F01	BRASS HANDLE NEAR DR'S DO	TATA spare parts
15014F01	ROUND HINGES L.H.	TATA spare parts
15015F01	ROUND HINGES R.H.	TATA spare parts
15017F01	HINGES FOR DEATI. FRAME	TATA spare parts
15020102036	BEARING SRDG BALL	TATA spare parts
15020102044	BEARING SRDG BALL	TATA spare parts
15020102061	BEARING SRDG BALL	TATA spare parts
15020102079	BEARING SRDG BALL	TATA spare parts
15020102087	BEARING SRDG BALL	TATA spare parts
15020103059	BEARING SRDG BALL	TATA spare parts
15020103067	DEEP GROOVE BALL BEARING	TATA spare parts
15020110055	BEARING SRDG BALL	TATA spare parts
15020203037	BEARING SRDG BALL	TATA spare parts
15020302027	BEARING SRDG BALL	TATA spare parts
15020320027	BEARING SRDG BALL	TATA spare parts
15020402064	BEARING SRDG BALL	TATA spare parts
15020502018	SRDG BEARING 12 BC BS1/2/3/4/6	TATA spare parts
15020502034	BEARING SRDG BALL	TATA spare parts
15020502042	BEARING SRDG BALL	TATA spare parts
15020502069	BEARING SRDG BALL	TATA spare parts
15020592017	SRDG BRG	TATA spare parts
15020598015	SRDG BRG	TATA spare parts
15020F01	INSIDE HANDLE	TATA spare parts
150210570001	METER PANEL HARNESS (COCA-COLA)	TATA spare parts
150210610001	METER PANEL HARNESS-OFFER	TATA spare parts

150210680001	METER PANEL HARNESS	TATA spare parts
150210690001	METER PANEL HARNESS	TATA spare parts
150210710001	METER PANEL HARNESS	TATA spare parts
150210870001	METER PANEL HARNESS	TATA spare parts
150210910001	METER PANEL HARNESS	TATA spare parts
150210940001	METER PANEL HARNESS	TATA spare parts
150210960001	METER PANEL HARNESS	TATA spare parts
150210990001	METER PANEL HARNESS	TATA spare parts
150212300001	HEAD LAMP HARNESS	TATA spare parts
150212320001	KIT WIRING HARNESS (ITS-09-077)	TATA spare parts
150212460001	METER PANEL HARNESS	TATA spare parts
150212790001	METER PANEL HARNESS	TATA spare parts
150213440001	USB HARNESS	TATA spare parts
150213600001	W/H EMERGENCY CONTROLLER AIS 140	TATA spare parts
150213680001	METER PANEL HARNESS	TATA spare parts
150213710001	FRONT DOOR HARNESS	TATA spare parts
150214390001	METER PANEL HARNESS- EURO IV	TATA spare parts
150214440001	METER PANEL HARNESS	TATA spare parts
150214540001	W/H EMG SWITCH AIS 140- LP 1613/52	TATA spare parts
150214910001	METER PANEL HARNESS-OFFER	TATA spare parts
150215070001	METER PANEL HARNESS	TATA spare parts
150215310001	METER PANEL HARNESS - HIRA ELANZA BS6	TATA spare parts
150215510001	METER PANEL HARNESS	TATA spare parts
15021F01	BRASS MINI HANDLE	TATA spare parts
15022011055	BEARING 6005	TATA spare parts
150246060001	WIRING HARNESS COMPLETE	TATA spare parts
150246280001	WIRING HARNESS COMPLETE	TATA spare parts
150247060001	ROOF HARNESS COMPLETE	TATA spare parts
150248190001	ROOF HARNESS COMPLETE	TATA spare parts
150248480001	ROOF HARNESS COMPLETE	TATA spare parts
150248520001	ROOF HARNESS COMPLETE	TATA spare parts
150248850001	ROOF HARNESS COMPLETE	TATA spare parts
150249400001	ROOF HARNESS COMPLETE	TATA spare parts
150249470001	ROOF HARNESS COMPLETE	TATA spare parts
150249590001	ROOF HARNESS	TATA spare parts
150249710001	ROOF HARNESS	TATA spare parts
150249780001	ROOF HARNESS COMPLETE	TATA spare parts
150249820001	ROOF HARNESS COMPLETE	TATA spare parts
150249860001	ROOF HARNESS	TATA spare parts
150249900001	ROOF HARNESS COMPLT	TATA spare parts
150249990001	ROOF HARNESS	TATA spare parts
15024F01	BUDGET LOCK KEY	TATA spare parts
150250000001	ROOF HARNESS	TATA spare parts
150250010001	ROOF HARNESS COMPLETE	TATA spare parts
150250040001	ROOF HARNESS COMPLETE	TATA spare parts
150250090001	ROOF HARNESS COMPLETE	TATA spare parts
150250110001	ROOF HARNESS COMPLETE	TATA spare parts

150250130001	ROOF HARNESS	TATA spare parts
150250150001	ROOF HARNESS COMPLETE	TATA spare parts
150250160001	ROOF HARNESS COMPLETE	TATA spare parts
150250180001	ROOF HARNESS COMPLETE	TATA spare parts
150250250001	ROOF HARNESS COMPLETE	TATA spare parts
150250340001	ROOF HARNESS COMPLETE FOR UAE ELANZA	TATA spare parts
150250500001	ROOF HARNESS - KUWAIT SP 36	TATA spare parts
150250550001	ROOF HARNESS COMPLETE	TATA spare parts
150250580001	ROOF HARNESS COMPLETE	TATA spare parts
150250620001	ROOF HARNESS COMPLETE	TATA spare parts
150250660001	ROOF HARNESS COMPLETE FOR ELAN	TATA spare parts
150250670001	ROOF HARNESS COMPLETE FOR GEMS ELANZA	TATA spare parts
150250790001	ROOF HARNESS COMPLETE- ABU DHABI GSO	TATA spare parts
150250810001	ROOF HARNESS LP1518/53 AGILE BS6	TATA spare parts
150250880001	ROOF HARNESS COMPLETE LP 1112/48	TATA spare parts
150250900001	ROOF HARNESS AGILE E-IV	TATA spare parts
150250930001	ROOF HARNESS COMPLETE FOR CONGO ELANZA	TATA spare parts
150250950001	ROOF HARNESS COMPLETE- JKSRTC	TATA spare parts
150251010001	ROOF HARNESS COMPLETE- OIL INDIA	TATA spare parts
150251040001	ROOF HARNESS COMPLETE- UTC LP 42	TATA spare parts
150251050001	ROOF HARNESS COMPLETE- UTC LP 52	TATA spare parts
150251090001	ROOF HARNESS COMPLETE LIBERIA	TATA spare parts
150251110001	ROOF HARNESS COMPLETE- CNG BS6	TATA spare parts
150251160001	ROOF HARNESS COMPLETE- ETHIOPIA ELANZA N	TATA spare parts
150251180001	ROOF HARNESS COMPLETE- STS ELANZA	TATA spare parts
150251230001	ROOF HARNESS COMPLETE	TATA spare parts
150251270001	ROOF HARNESS COMPLETE- SAUDI AGILE	TATA spare parts
150251290001	ROOF HARNESS - QATAR AGILE	TATA spare parts
150251310001	ROOF HARNESS - HIRA ELENZA BS6	TATA spare parts
150251420001	ROOF HARNESS - DUBAI AGILE	TATA spare parts
150251430001	ROOF HARNESS - DUBAI AGILE	TATA spare parts
150251440001	ROOF HARNESS COMPLETE	TATA spare parts
150251460001	ROOF HARNESS STS ELANZA	TATA spare parts
150251470001	ROOF HARNESS - SAUDI AC LC36	TATA spare parts
150251510001	ROOF HARNESS - SAUDI AC LC36	TATA spare parts
150251530001	ROOF HARNESS - OMAN PDO	TATA spare parts
15033F02	FIRST AID BOX	TATA spare parts
15036F02	DIESEL TANK FLAP	TATA spare parts
15037F02	M.S. FLOOR HANDLE	TATA spare parts
15043BB01	35MM TO 25MM PIPE 'T' SO	TATA spare parts
15051F02	J/K DOOR BOTTOM BUSH (MAL	TATA spare parts
15083	6MM TO 8MM COPPER TUBE CONNECTOR	TATA spare parts
15092	DIFF. BEARING CUP RH	TATA spare parts
15100003	REAR HINGE SHAFT DIA60 X 970L	TATA spare parts
15100004	REAR HINGE SHAFT LOCKING PIN	TATA spare parts
15100005	REAR HINGE SHAFT SNAP RING DIA60	TATA spare parts
15109009	TIPPING VALVE MOUNTING BLOCK	TATA spare parts

15111001CF	LAMP BEZEL/LH	TATA spare parts
15111002CF	LAMP BEZEL/RH	TATA spare parts
151110390001	FRONT FLAP STRIP TRUSS BAR -AGILE	TATA spare parts
151110430001	TRUSS BAR- AGILE (BLACK)	TATA spare parts
15112021EN	FRONT COMBINATION LAMP	TATA spare parts
15112055EN	LUMAX HEAD ASSY W/PARKING	TATA spare parts
15112056EN	HEAD-LAMP ASSY. W/PARKNG	TATA spare parts
15112057EN	HEAD-LAMP ASSY. W/PARKNG	TATA spare parts
151121200001	HEAD LAMP SET RHD RH	TATA spare parts
151121210001	HEAD LAMP SET RHD LH	TATA spare parts
151121270001	HEAD LAMP LHD LH (HIGH BEAM)	TATA spare parts
151121280001	HEAD LAMP LHD RH (HIGH BEAM)	TATA spare parts
151121290001	HEAD LAMP LHD LH (LOW BEAM)	TATA spare parts
151121300001	HEAD LAMP LHD RH (LOW BEAM)	TATA spare parts
151122210001	BLINKER LAMP (COMFORT BUS)	TATA spare parts
151122240001	HEAD LAMP SET LHD RH (NON MOT)	TATA spare parts
151122250001	HEAD LAMP SET LHD LH (NON MOT)	TATA spare parts
151124570001	FOG LAMP 24V 85 DIA	TATA spare parts
151124580001	FOG LAMP 12V 85 DIA	TATA spare parts
151124650001	FOG LAMP 24V (ARAI CERTIFIED)	TATA spare parts
151130050001	H L 24V H.B RHD WITH PARKING LH (FIEM)	TATA spare parts
151130090001	HEAD LAMP RHD RH PRIMA 24V	TATA spare parts
151130100001	HEAD LAMP RHD LH PRIMA 24V	TATA spare parts
151130120001	H L 24V L.B RHD LH 24V HLLD (FIEM)	TATA spare parts
151130130001	H L 24V L.B RHD RH 24V HLLD (FIEM)	TATA spare parts
151210340001	CLUSTERED TAIL LAMP RH	TATA spare parts
151210350001	CLUSTERED TAIL LAMP LH	TATA spare parts
15122060EN	CAB COMPLT RHD SLEEPER	TATA spare parts
15122062EN	CAB COMPLT RHD SLEEPER	TATA spare parts
151221080001	LED LAMP (RED) 24 V	TATA spare parts
151221090001	LED LAMP (WHITE) 24 V	TATA spare parts
151221100001	LED LAMP (AMBER) 24 V	TATA spare parts
151222190001	LED TAIL LIGHT PARKING 24V	TATA spare parts
151223000001	BRAKE LIGHT ROUND WITH 21/5 W BULB	TATA spare parts
151234720001	CLUSTERED TAIL LAMP RH	TATA spare parts
151234730001	CLUSTERED TAIL LAMP LH	TATA spare parts
1520100601	WASHER 0.50 MM	TATA spare parts
1520101603	WASHER 0.20 MM	TATA spare parts
1520101607	WASHER 0.3 MM	TATA spare parts
15272000CN	PASSANGER FAN ( 12V )	TATA spare parts
152720030001	SWITCH (PASSENGER-FAN)(WHITE)	TATA spare parts
15272003CN	SWITCH (PASSENGER-FAN)	TATA spare parts
15272008CN	PASSENGER FAN (24 V)	TATA spare parts
15272008CN000000	PASSENGER FAN (24 V) (SENBUS)	TATA spare parts
152720200001	PASS.FAN (24V REMI-RING TYPE-GREY)	TATA spare parts
152720550001	PASS.FAN (24V REMI-RING TYPE-GREY)	TATA spare parts
152720600001	FAN 24V (RING TYPE) BLUE BLADES	TATA spare parts

152721020001	PASSENGER FAN 8INCH ARAI CG MAKE 24V	TATA spare parts
152721040001	PASS.FAN (24V REMI-RING TYPE-GREY)	TATA spare parts
152721050001	PASS FAN BRUSHLESS 12V	TATA spare parts
152721060001	FAN 24V (RING TYPE) BLUE BLADES	TATA spare parts
152721070001	BLDC PASS FAN 24V GREY TOGGLE SW	TATA spare parts
152721080001	BLDC FAN 24V W/SW BLUE- INVEL	TATA spare parts
152740110001	TELCO RELAY(260854549902-24V)	TATA spare parts
152740120001	RELAY COUPLER	TATA spare parts
1530101611	WASHER 0.50 MM	TATA spare parts
1530210003	GASKET DELIVERY VALVE	TATA spare parts
15321003CF	24V/20VA ETC.INV.& ACC.TY	TATA spare parts
15321005CN	DRIVERS CABIN LAMP	TATA spare parts
15321007EN000000	CEILING LAMP (24V)	TATA spare parts
15321010EN	12V/20VA ETC.INV.& ACC.TYPE-A	TATA spare parts
15321031CF	LAMP ASSY/NO PLATE	TATA spare parts
153210820001	REVERSE HORN (24 V)	TATA spare parts
153220060001	DOOR PUSH SWITCH	TATA spare parts
15322006CN	DOOR SWITCH	TATA spare parts
15322006EN	DOOR PUSH SWITCH	TATA spare parts
153220090001	MINI ROUND LAMP (W/O ACRYLIC)	TATA spare parts
153221020011	WHITE REFLECTIVE TAPE	TATA spare parts
153221060024	YELLOW REFLECTIVE TAPE	TATA spare parts
153221180001	REVERSE HORN(24V)	TATA spare parts
153221350001	REVERSE HORN(24V)	TATA spare parts
15326309	SENSOR ASSEMBLY TEMPERATURE	TATA spare parts
1532640055	PLUG SPEEDOMETER DRIVE	TATA spare parts
153310470001	CONTROLLER 24V GPS VA SYSTEM &MIC INPUT	TATA spare parts
153310480001	WIRING HARNESS KIT WITH VOICE ANNOUNCEMENT	TATA spare parts
153310510001	LED DESTINATION F/R 900MM	TATA spare parts
153310540001	DESTINATION CONTROLLER DRC 24V	TATA spare parts
153311250001	DRIVER CONTROL-HANOVER E401F GPS COMPAT	TATA spare parts
153311450001	LED DISPLAY WIRING HARNESS KIT	TATA spare parts
153311470001	DESTINATION CONTROLLER	TATA spare parts
153311530001	DRIVER CONTROLLER CHEMITO- BANGLADESH	TATA spare parts
153311540001	FRONT DEST BOARD CHEMITO- BANGLADESH	TATA spare parts
153320720001	TOWER BOLT (4 INCH)	TATA spare parts
153321860001	REAR DESTINATION BOARD OLA 099 24V	TATA spare parts
153322020001	DESTINATION BOARD 1800MM	TATA spare parts
153322270001	AHUJA MIKE	TATA spare parts
153322370001	CONTR 24V - GPS V.A SYSTEM & MIC	TATA spare parts
153322830001	DEST BOARD REAR 975MM 24V	TATA spare parts
15361003CN	VENTILATOR ASSY COMPLETE	TATA spare parts
153621060001	ROOF HATCH ASSEMBLY	TATA spare parts
153621090001	ROOF HATCH ASSY (770X560 OPEN)	TATA spare parts
153630030001	ROTARY AIR VENTILATOR	TATA spare parts
153630070001	VENTILLATOR ASSEMBLY (ROOF HATCH)	TATA spare parts
153630110001	ROOF HATCH WEBASTO 2M3 MDL(HISPANO)	TATA spare parts



15370011CN	WIPER BLADE ASSY. 650 MM	TATA spare parts
153710180001	WIPER SYSTEM (COMFORT-2500-ALMIGHTY)	TATA spare parts
153710190001	WIPER SYSTEM CHEMOFLEX 145 NM	TATA spare parts
153720020002	CONNECTING ROD (L=60)	TATA spare parts
153720020005	CONNECTING ROD	TATA spare parts
153720020009	CONNECTING ROD (L=210)	TATA spare parts
153720020021	CONNECTING ROD (L=690)	TATA spare parts
153720020031	CONNECTING ROD	TATA spare parts
15372002SF000600	CONNECTING ROD	TATA spare parts
15372002SF001900	CONNECTING ROD	TATA spare parts
15372002SF005050	CONNECTING ROD	TATA spare parts
15372002SF005400	CONNECTING ROD	TATA spare parts
15372002SF007750	CONNECTING ROD	TATA spare parts
153720040001	WIPER ARM (909)	TATA spare parts
153720060001	WIPER BLADE (909)	TATA spare parts
153720070001	CONNECTING ROD	TATA spare parts
153720070006	CONNECTING ROD	TATA spare parts
153720070007	CONNECTING ROD	TATA spare parts
153720140001	WIPER MOTOR (24V-HIGH POWER)	TATA spare parts
153720170001	WIPER MOTOR (24V HIGH POWER)	TATA spare parts
15372036CN	WIPER ARM (370X210 RHD)	TATA spare parts
15372040CN	WIPER ARM (370X295 LHD)	TATA spare parts
15372041CN	WIPER ARM (370X295 RHD)	TATA spare parts
153720420001	WIPER BLADE ASSEMBLY	TATA spare parts
15372042CN	WIPER BLADE (L=711)	TATA spare parts
153720690001	WIPER ARM (370X295)	TATA spare parts
153720710001	WIPER ARM (370X295 LHD)+SPRAYKIT	TATA spare parts
153720770015	CONNECTING ROD	TATA spare parts
153720980001	WIPER MOTOR (24V) HIGH POWER	TATA spare parts
153721410001	WIPER SYSTEM FULL ASSY. (ALMIGHTY)	TATA spare parts
153721510001	WIPER ARM ASSEMBLY. (RH)	TATA spare parts
153721520001	WIPER ARM ASSEMBLY. (LH)	TATA spare parts
153721530001	WIPER BLADE ASSEMBLY	TATA spare parts
153721540001	BUTTERFLY SYSTEM LINKAGE	TATA spare parts
153721550001	WIPER MOTOR	TATA spare parts
153721580001	WASHER TANK	TATA spare parts
153721590001	BUTTERFLY SYSTEM LINKAGE	TATA spare parts
153721980001	WIPER SYSTEM ALMITY	TATA spare parts
153722000001	WIPER SYSTEM (ALMIGHTY MAKE) COMFORT RH	TATA spare parts
153722010001	WIPER MOTOR	TATA spare parts
153722080001	WIPER SYSTEM STAR RH	TATA spare parts
153722290001	WIPER SYSTEM FULL ASSY.(ALMIGHTY)	TATA spare parts
153722330001	WASHER KIT ASSY 95004000	TATA spare parts
153722340001	WIPER MOTOR 24V/70NM/120W	TATA spare parts
153722370001	WIPER SYSTEM ALMIGHTY AGILE LHD	TATA spare parts
153722380001	WIPER SYSTEM - (ALMIGHTY) BS6	TATA spare parts
153722420001	WIPER SYSTEM- MEGHALAYA 24V (ALMIGHTY)	TATA spare parts

153722450001	LINKAGE SYSTEM -92072	TATA spare parts
153722460001	WIPER ARM ASSY. 750(RH)-93063	TATA spare parts
153722470001	WIPER ARM ASSY. 750(LH)-93062	TATA spare parts
153722480001	WIPER BLADE ASSY.40INCH-94110	TATA spare parts
153722490001	WASHER TUBE KIT 24V-95001	TATA spare parts
153722530001	LINKAGE SYSTEM (92092000)	TATA spare parts
153722540001	WIPER ARM 650 RH 93104000	TATA spare parts
153722550001	WIPER ARM 650 LH 93051000	TATA spare parts
153722560001	WIPER BLADE ASSY 36INCH94100000	TATA spare parts
153722590001	WIPER SYSTEM - ALMIGHTY 12 V BS6	TATA spare parts
153722600001	LINKAGE SYSTEM (92408000) BS6	TATA spare parts
153722610001	WIPER BLADE ASSY 32 94094000	TATA spare parts
153722640001	WIPER ARM ASSEMBLY. DRV	TATA spare parts
153722650001	WIPER ARM ASSEMBLY. CO DRV	TATA spare parts
153722660001	WIPER BLADE DRV SIDE 900MM	TATA spare parts
153722670001	WIPER BLADE CO-DRIVER 800MM	TATA spare parts
153722680001	WIPER MOTOR 24V 140 NM	TATA spare parts
153722730001	LINKAGE SYSTEM 92418000	TATA spare parts
153722740001	ARM ASSY 650MM RH 93332000	TATA spare parts
153722750001	ARM ASSY 700MM LH 93333000	TATA spare parts
153722760001	WIPER MOTOR 120NM 24V 9160692000	TATA spare parts
153722770001	WASHER TANK	TATA spare parts
153730970001	WIPER MOTOR 12VDC 120NM 9106960002 BS6	TATA spare parts
1539930701	THRUST SPRING	TATA spare parts
1540101000	WASHER 2.00 MM	TATA spare parts
154012230001	KNOB FOR 6HD AIR CLEANER PANEL (30MM)	TATA spare parts
154012310001	KNOB FOR 6HD AIR CLEANER PANEL (50MM)	TATA spare parts
154013280001	FRP DASHBOARD COMPLETE	TATA spare parts
154013290001	FRP DASHBOARD COMPLETE	TATA spare parts
154013480001	DASHBOARD COMPLETE(METAL SHEET)	TATA spare parts
154013930001	DASHBOARD FOR HISPANO CLUSTER BUS	TATA spare parts
154014290001	FRP DASHBOARD FOR KESRTC JNNURM	TATA spare parts
154014300001	DASHBOARD COMPLETE	TATA spare parts
154014740001	FRP DASHBOARD COMPLETE	TATA spare parts
154014830001	FRP DASHABORD FOR LP 1112	TATA spare parts
154014860001	FRP DASHBOARD- SAUDI ELANZA TATWEER	TATA spare parts
154014920001	DASHBOARD COMPL	TATA spare parts
154014940001	FRP DASHBOARD FOR NBSTC	TATA spare parts
154014990001	FRP DASHBOARD FOR NEPAL	TATA spare parts
154015100001	FRP DASHBOARD COMPLETE	TATA spare parts
154015120001	DASHBOARD COMPLETE	TATA spare parts
154015140001	FRP DASHBOARD LP 1618/53 AGILE BS6	TATA spare parts
154015160001	FRP DASHBOARD JKSRTC LP1613/42	TATA spare parts
154015170001	FRP DASHBOARD UTC JUPITER	TATA spare parts
154015200001	FRP DASHBOARD AGILE 1618/55	TATA spare parts
154015230001	FRP DASHBOARD FOR NBSTC	TATA spare parts
154015260001	FRP DASHBOARD 1618/58 AGILE BS6	TATA spare parts

154015360001	FRP DASHBOARD - HIRA ELANZA BS6	TATA spare parts
154016060001	DASHBOARD COMPLETE	TATA spare parts
154016070001	FRP DASHBOARD 1618/62 AGILE LHD	TATA spare parts
154026150001	DASHBOARD COMPLETE	TATA spare parts
154026250001	DASHBOARD COMPLETE	TATA spare parts
154026260001	FRP DASHBOARD FOR SAUDI ELANZA	TATA spare parts
154026280001	DASHBOARD COMPLETE	TATA spare parts
154026460001	FRP DASHBOARD 1112 AGILE KOTA	TATA spare parts
154026560001	DASHBOARD FOR ERGO CLUSTER ELANZA BUS	TATA spare parts
154026650001	FRP DASHBOARD 1618/62 COMFORT LHD	TATA spare parts
154026710001	DASHBOARD COMPLETE	TATA spare parts
154026730001	FRP DASHBOARD STS DUBAI	TATA spare parts
154026980001	FRP DASHBOARD STS ELANZA	TATA spare parts
154032160002	PANEL	TATA spare parts
154034370001	COOLANT TANK LID OF DASHBOARD	TATA spare parts
154035390001	HINGE ASSY FOR ENGINE HOOD	TATA spare parts
154035490001	AIR CLEANER PANEL ASSEMBLY	TATA spare parts
154041880001	LOCK WITH PLASTIC GRIP	TATA spare parts
154104150002	METER PLATE - PC	TATA spare parts
154111510002	SWITCH PLATE (P.C)	TATA spare parts
154111520002	SWITCH PLATE (P.C)	TATA spare parts
15421503092	BEARING CYL ROLLER	TATA spare parts
15460503067	BEARING CYL ROLLER	TATA spare parts
15460504071	BEARING CYL ROLLER	TATA spare parts
15490953	CONNECTOR	TATA spare parts
15502015EN	PILOT LAMP	TATA spare parts
155020190001	SWITCH (PIANO TYPE)	TATA spare parts
15502019EN	SWITCHES PIANO TYPE	TATA spare parts
155020210001	TOGGLE SWITCH (2P-ON/OFF)	TATA spare parts
15502023EN	AIR HORN SWITCH	TATA spare parts
155020260001	INTERMITTENT BUZZER	TATA spare parts
15502026EN	INTERMITTENT BUZZER	TATA spare parts
155020610001	SPRING LOADED PIANO SW (2P ON-OFF)	TATA spare parts
15502061EN	SPRING LOADED P-SW(2P ON-OFF)	TATA spare parts
15502080EN	PASSANGER BELL (24 V)	TATA spare parts
15502080EN000000	PASSANGER BELL (24 V)	TATA spare parts
15502102EN	8 POLE TG.SW 15A(TWIN HEAD LP)	TATA spare parts
155021210001	MICRO SWITCH (ESSEN MTCRS24R)	TATA spare parts
15502121EN	MICRO SWITCH	TATA spare parts
155021420001	FLASHER UNIT (4X21W/24V-15A)	TATA spare parts
155021590001	PILOT INDICATOR (WITH LED)	TATA spare parts
155021640001	SALOON LAMP SWITCH	TATA spare parts
155021660001	PIANO SWITCH GALACTIC	TATA spare parts
155021680001	PIANO SWITCH RED- EMG SIGNAL	TATA spare parts
155021690001	FUSE BOX COVER	TATA spare parts
155620030001	REFLECTOR (ROUND) INCHEINCH MARK (RED)	TATA spare parts
155621870001	REFLECTOR (RED) E MARK LUMAX MAKE	TATA spare parts

155720060001	LAPL SIDE MARKER LED 24V/12V FLAT	TATA spare parts
155720070001	LAPL SIDE MARKER LED 24V/12V FLAT	TATA spare parts
155720080001	SIDE MARKER FIEM MAKE 24 V	TATA spare parts
155720110001	SIDE MARKER LED 24V	TATA spare parts
155820080001	DOME LAMP (RED LENSE)	TATA spare parts
155820590001	DOME LAMP (YELLOW LENSE) 24V 10W BULB	TATA spare parts
155820670001	FRONT REFLECTOR LH	TATA spare parts
155820680001	FRONT REFLECTOR RH	TATA spare parts
155820780001	DOME LAMP AMBER LED 24V AUTOLITE MAKE	TATA spare parts
155820810001	HIGH MOUNT STOP LAMP 24V LAPL	TATA spare parts
155820850001	REAR BRAKE LIGHT 24V RED	TATA spare parts
155820860001	FRONT TOP MARKER 24V	TATA spare parts
155820870001	LED HEIGHT MARKER LAMP RED 12/24V	TATA spare parts
155910100001	RED REFLECTOR STOP SIGN	TATA spare parts
156013120001	STOP SWITCH (PIPE MOUNTED - 32 DIA)	TATA spare parts
156020160001	NIGHT LAMP(BLUE LENS)	TATA spare parts
156020480001	HIGH MOUNT STOP LAMP 24V LAPL	TATA spare parts
15602096EN000000	CAB COMPLT RHD SLEEPER	TATA spare parts
156021050001	LED ROOF LIGHT PLSS3624 24V	TATA spare parts
156021080001	SPEAKER (SONY MAKE-XS-GF-1021X10CM)	TATA spare parts
156021410001	MOBILE HOLDER BS6	TATA spare parts
156022910001	RC CORD 10 METRS	TATA spare parts
156023060001	LED STEP LAMP-24 V	TATA spare parts
156023220001	SIDE INDICATOR LAMP	TATA spare parts
156023260001	LCD 22INCH CRM-2250H FIX TYPE-24V	TATA spare parts
156030840001	EMERGENCY SWITCH (AIS 140) 24V BS6	TATA spare parts
156030850001	AMPLIFIER 24V EMI/EMC - MASS TRANS BS6	TATA spare parts
156030880001	LED CABIN LAMP 24V	TATA spare parts
156030910001	HANDHELD MICROPHONE - MASS TRANS BS6	TATA spare parts
156030950001	4 CHANNEL MDVR	TATA spare parts
156030960001	INTERNAL CAMERA	TATA spare parts
156030970001	REAR VIEW CAMERA	TATA spare parts
156030980001	7 TFT MONITOR	TATA spare parts
156031010001	SPEAKER COVER	TATA spare parts
156031990001	BULB 12V/5W CAPLESS RINDER	TATA spare parts
156032480001	ABS/ECU HIDING COVER FRP	TATA spare parts
156033250001	EMG EXIT LAMP RIGHT ARROW	TATA spare parts
156033370001	EMG EXIT LAMP LEFT ARROW	TATA spare parts
156033430001	SPEED LIMITER	TATA spare parts
156033450001	END CAP FOR LED	TATA spare parts
156033460001	JUNCTION CAP FOR LED	TATA spare parts
156033530001	SINGLE CONTROL UNIT ASSEMBLY	TATA spare parts
156033540001	CAMERA	TATA spare parts
156033550001	REVERSE CAMERA	TATA spare parts
156033560001	BUS DISPLAY CONTROL ASSEMBLY	TATA spare parts
156033570001	BUS DISPLAY CONTROL MOUNTING STAND	TATA spare parts
156033580001	SPEAKER ASSEMBLY WITH GRILL (ITS-06-000)	TATA spare parts

156033590001	SPEAKER ASSY WITHOUT GRILL	TATA spare parts
156033600001	HEADSET ASSEMBLY WITH VOLUME CONTROL	TATA spare parts
156033610001	DRIVER- MIC ASSEMBLY	TATA spare parts
156033620001	ANTENNA COMBO ASSEMBLY (ITS-08-003)	TATA spare parts
156033910001	JUNAID MAKE LED ROOF LAMP 24V	TATA spare parts
156034080001	BERTH READING LAMP WITH USB	TATA spare parts
156034230001	SPEAKER COVER WHITE	TATA spare parts
156034250001	DUAL USB CHARGER 24V	TATA spare parts
156034270001	BAGGAGE BOX LAMP 24V	TATA spare parts
156034450001	STOP LAMP BOARD 24V	TATA spare parts
156034550001	LED ROOF LAMP WITH NIGHT LAMP	TATA spare parts
156034620001	LED ROOF LAMP 24V GSO	TATA spare parts
156034710001	LED ROOF LIGHT PLSS3624 24V	TATA spare parts
156034740001	WIPER SWITCH	TATA spare parts
156034820001	LED BLUE LIGHT 24V 2380MM	TATA spare parts
156034830001	24V- 9V 750MA EM CHARGER	TATA spare parts
156034920001	LED BLUE LIGHT STRIP 1/2 MTR 24V	TATA spare parts
156034940001	LED STEP LAMP 24V LAPL	TATA spare parts
156034940002	LED STEP LAMP 24V LAPL	TATA spare parts
156035000001	LED ROOF LAMP 24V635MM-ARKA	TATA spare parts
156035010001	DVD PLAYER 24V WITH MIC I/P	TATA spare parts
156035020001	7 TFT FOR CAMERA	TATA spare parts
156035030001	REAR VIEW CAMERA	TATA spare parts
156035040001	SIDE CAMERA	TATA spare parts
156035050001	4 CHANNEL AHD DVR	TATA spare parts
156035080001	VEDIO+POWER CABLE	TATA spare parts
156035220001	LED BLUE LIGHT 24V 800MM	TATA spare parts
156035230001	LED BLUE LIGHT 24V 550MM	TATA spare parts
156035450001	STOP SWITCH MTG PLASTIC COVER	TATA spare parts
156035620001	DUAL USB CHARGER 12/24 - AARGEE	TATA spare parts
156035760001	EMG LIGHTING SYSTEM 24V 300MA	TATA spare parts
156035860001	EMG SIGNALLING CONTROLLER	TATA spare parts
156035890001	LED LAMP 24V LIGHT BUFF- JUNAID	TATA spare parts
15604001PN	ACRYLIC PLATE (216 X 305)	TATA spare parts
156040470001	SWITCH DUMMY COVER 22X44	TATA spare parts
156045220001	DIGITAL CLOCK 12/24V ROOF MOUNTED	TATA spare parts
156045600001	FLASHER 24V 270W	TATA spare parts
156045610001	BUS STOP ABS COVER - LIGHT BUFF	TATA spare parts
156045670001	DONGLE	TATA spare parts
156046260001	SPEAKER COVER LIGHT BUFF	TATA spare parts
156051060001	CAMERA CORD KIT	TATA spare parts
156051090001	INTERNAL CAMERA EMI/EMC	TATA spare parts
156051100001	DVR 24V EMI/ EMC	TATA spare parts
156051120001	DVR UNIT 24V	TATA spare parts
156051140001	INTERNAL CAMERA	TATA spare parts
156055750001	REAR VIEW CAMERA - ACCOLADE	TATA spare parts
156055760001	7INCH DASHBOARD MONITOR - ACCOLADE	TATA spare parts

156055770001	REVERSE CAMERA CABLE L=20MTR- ACCOLADE	TATA spare parts
156075	PLUG EXPANSION	TATA spare parts
156620020405	WATER PUMP BEARING	TATA spare parts
15662002043	BEARING TAPER ROLLER	TATA spare parts
15662002045	BEARING WATER PUMP	TATA spare parts
15662020050	TR R BRG 25-4CC/47X15-32005X	TATA spare parts
15662022095	TAPER ROLLER BRG 32209	TATA spare parts
15662023059	TAPER ROLLER BEARING	TATA spare parts
15664003080	BEARING TAPER ROLLER	TATA spare parts
157098	VALVE SHUTOFF	TATA spare parts
15721298083	BEARING NEEDLE CAGE	TATA spare parts
15723711727	NEEDLE BUSH-22X28X16	TATA spare parts
15723712383	NEEDLE BUSH	TATA spare parts
15729403927	NEEDLE BUSH	TATA spare parts
15749402099	CYL R THRUST CAGE 40X78X7 K89308 INA	TATA spare parts
15900002014	BEARING BALL	TATA spare parts
15950000802	BALL 8D	TATA spare parts
15950001108	BALL 11D	TATA spare parts
15950001701	BALL 17D	TATA spare parts
15950100505	BALL 5D	TATA spare parts
15950100602	BALL 6D	TATA spare parts
15950100807	BALL 8DIA-20	TATA spare parts
15950100904	BALL 9D	TATA spare parts
15950101102	BALL 11DIA-20 IS2898 BS4	TATA spare parts
15950101200	BALL 12D	TATA spare parts
15950101706	BALL 17DIA-20 IS2898	TATA spare parts
15950200305	BALL 3DIA 200	TATA spare parts
15950400100	BALL 7.938DIA-GRADE 200 IS2898	TATA spare parts
15950400126	BALL 9.525D	TATA spare parts
15950400169	BALL 12.7D	TATA spare parts
15950400177	BALL 13.494DIA-GRADE 200 IS2898	TATA spare parts
15950500180	BALL 4.762DIA-GRADE 20	TATA spare parts
15950500210	BALL 5.556DIA-GRADE 20 IS2898	TATA spare parts
15950805088	ROLLER-CENTRAL DETENT	TATA spare parts
15950899015	CYL ROLLER 4X8 BPM	TATA spare parts
15951204126	CYL ROLLER 4 X 12	TATA spare parts
15953520131	NEEDLE ROLLER 2 X 13.8 BS4	TATA spare parts
15953530152	NEEDLE ROLLER 3X15.8	TATA spare parts
15953540131	NEEDLE ROLLER 4 X 13.8	TATA spare parts
15955007201	SNAP RING 72 IS11904	TATA spare parts
15955008500	SNAP RING 85 TS15155	TATA spare parts
15955009000	SNAP RING 90 TS15155	TATA spare parts
15955010008	SNAP RING 100	TATA spare parts
15958098011	INNER RACE	TATA spare parts
15959402113	NEEDLE ROLLER 1.5X9.3	TATA spare parts
16001001600	TAPER PLUG	TATA spare parts
16011PL01	DOVE TAIL MALE	TATA spare parts

16012PL01	DOVE TAIL FEMALE	TATA spare parts
16014PL01	PVS CAP FOR GREASE NIPPLE	TATA spare parts
16015PL01	PVC PACKING ANTI. DISC	TATA spare parts
16016PL01	PVC PACKING FOR BRASS LAT	TATA spare parts
16017PL01	PVC ARM REST 1 INCH	TATA spare parts
16018PL01	T PVC FOR SEAT RAIL & FRO	TATA spare parts
16019PL01	SEAT RAIL BUSH	TATA spare parts
16020PL01	PVC PACKING 3INCH FOR GRAB RA	TATA spare parts
16029LP02	PVC PACKING FLAT FOR 1INCH B	TATA spare parts
16030LP02	PVC PACKINF FOR ALU. RUB	TATA spare parts
16031LP02	1INCH SQUARE BUSH	TATA spare parts
16032LP02	PVC PACKING FOR REAR BUMP	TATA spare parts
16033LP02	PVC INSERT BLACK	TATA spare parts
16034LP02	PVC INSERT APPLE WHITE	TATA spare parts
16035LP02	PVC U SECTION FOR WINDOW	TATA spare parts
16036LP02	PVC FOR STEP & FLOOR CUTO	TATA spare parts
16041LP02	FRP HUBCAP FOR FRONT WHEEL	TATA spare parts
16042LP02	FRP HUBCAP FOR REAR WHEEL	TATA spare parts
16043LP02	FRP DASH BOARD SWITCH STA	TATA spare parts
16080516154	SEALING PLUG M16 X 1.5	TATA spare parts
16080542155	SEALING PLUG M42 X 1.5	TATA spare parts
16080616159	SEALING PLUG MC16 X 1.5	TATA spare parts
16080624151	SEALING PLUG MC24X1.5 TS16464	TATA spare parts
16080624151AE	SEALING PLUG MC24X1.5 -1628	TATA spare parts
16080630151	SEALING PLUG MC30 X 1.5	TATA spare parts
16081001000	SEALING PLUG AM10 X 1	TATA spare parts
16081001204	SEALING PLUG AM12 X 1.5	TATA spare parts
16081001409	SEALING PLUG AM14 X 1.5	TATA spare parts
16081001603	SEALING PLUG AM16 X 1.5	TATA spare parts
16081001808	SEALING PLUG AM18X1.5 TS16460	TATA spare parts
16081002201	SEALING PLUG AM22 X 1.5	TATA spare parts
16081002600	SEALING PLUG AM26X1.5	TATA spare parts
16081051406	SEALING PLUG AM14X1.5 TS16460?SS8451S2-Y	TATA spare parts
16081051805	SEALING PLUG AM18X1.5 TS16460 SS8451S2	TATA spare parts
16081202200	SEALING PLUG CM22 X 1.5	TATA spare parts
16081203800	SEALING PLUG CM38 X 1.5	TATA spare parts
16081205209	SEALING PLUG CM52 X 1.5	TATA spare parts
16081800808	PLUG MC 8X1 IS9645 SS8451-8C	TATA spare parts
16081801006	PLUG MC 10 X 1	TATA spare parts
16081801201	PLUG MC 12X1.5	TATA spare parts
16081801405	PLUG MC 14 X 1.5	TATA spare parts
16081801600	PLUG MC 16 X 1.5	TATA spare parts
16081801804	PLUG MC 18X1.5 IS9645-SS8451-8C BS6	TATA spare parts
16081802207	PLUG MC 22X1.5 IS9645-SS8451-8C	TATA spare parts
16081802401	PLUG MC 24 X 1.5	TATA spare parts
16081803009	PLUG MC 30 X 1.5	TATA spare parts
16081811001	PLUG MC10X1 IS9645-SS9400	TATA spare parts

16081851208	PLUG MC 12X1.5 IS9645-SS8451S2-Y	TATA spare parts
16081851801	PLUG MC 18X1.5 IS9645-SS8451S2-Y	TATA spare parts
16081860819	PLUG MC8X1-IS9645-TS17070-SS8451S2-Y BS6	TATA spare parts
16081861017	PLUG MC10X1-IS9645-TS17070-SS8451S2-Y BS	TATA spare parts
16081861203	PLUG MC 12X1.5 IS9645-TS17070-SS8451S2-Y	TATA spare parts
16081862013	PLUG MC20X1.5-IS9645-TS17070-SS8451S2-Y	TATA spare parts
16081862412	PLUG MC24X1.5-IS9645-TS17070-SS8451S2-Y	TATA spare parts
16082001003	SEALING PLUG M10 X 1	TATA spare parts
16082001208	SEALING PLUG M12X1.5 TS16463 SS8451S2-Y	TATA spare parts
16082001402	SEALING PLUG M14X1.5 TS16463	TATA spare parts
16082001607	SEALING PLUG M16X1.5 TS16463	TATA spare parts
16082001801	SEALING PLUG M18 X 1.5	TATA spare parts
16082002204	SEALING PLUG M22 X 1.5	TATA spare parts
16082003006	SEALING PLUG M30X1.5 TS16463 SS8451S2-Y	TATA spare parts
16082003600	SEALING PLUG M36 X 1.5 TS 16463 BS6-PH2	TATA spare parts
16082004207	SEALING PLUG M42X1.5	TATA spare parts
16082004207AE	SEALING PLUG M42X1.5 -1628	TATA spare parts
16082051001	SEALING PLUG M10X1	TATA spare parts
16082051604	SEALING PLUG M16X1.5 TS16463	TATA spare parts
16082501405	SEALING PLUG M14 X 1.5	TATA spare parts
16082501600	PLUG M16 X 1.5	TATA spare parts
16082502401	SEALING PLUG M24 X 1.5	TATA spare parts
16082503009	PLUG M30 X 1.5	TATA spare parts
16150500803	COUPLING NUT 10	TATA spare parts
16151700601	COUPLING NUT L6	TATA spare parts
16151700806	COUPLING NUT L8	TATA spare parts
16151701004	COUPLING NUT L10	TATA spare parts
16151701209	COUPLING NUT L12	TATA spare parts
16151701501	COUPLING NUT L15	TATA spare parts
16151701802	COUPLING NUT L18	TATA spare parts
16151702205	COUPLING NUT L22 IS8803 SS8451-8C	TATA spare parts
16151771207	COUPLING NUT L12 IS8803 SS8457S1-S-B	TATA spare parts
16153201203	CAP NUT AM 12 X 1.5	TATA spare parts
16153202200	CAP NUT AM 22 X 1.5	TATA spare parts
16220510062	SEALING WASHER AL 6X10	TATA spare parts
16220510097	WASHER A8 X 11.5	TATA spare parts
16220510127	WASHER A8 X 14	TATA spare parts
16220510135	SEALINGWASHER10X13.5IS3175AL	TATA spare parts
16220510143	SEALING WASHER AL 10X14	TATA spare parts
16220510178	SEALINGWASHER12X15.5IS3175AL	TATA spare parts
16220510186	SEALING WASHER AL 12X16	TATA spare parts
16220510216	SEALING WASHER AL 14X18	TATA spare parts
16220510224	SEALING WASHER 14X20 IS3175 AL	TATA spare parts
16220510241	SEALINGWASHER16X20IS3175AL	TATA spare parts
16220510259	SEALING WASHER AL 16X22	TATA spare parts
16220510283	SEALING WASHER AL 18X22	TATA spare parts
16220510291	SEALING WASHER AL 18X24	TATA spare parts



16220510305	SEALING WASHER 20X24 IS3175-AL	TATA spare parts
16220510348	SEALING WASHER AL 22X27	TATA spare parts
16220510429	SEALING WASHER AL 26X31	TATA spare parts
16220510437	SEALING WASHER AL 26X32	TATA spare parts
16220510488	SEALING WASHER AL 30X36	TATA spare parts
16220510526	SEALING WASHER AL 33X39	TATA spare parts
16220510542	WASHER A35 X 41	TATA spare parts
16220510577	SEALING WASHER AL 38X44	TATA spare parts
16220510631	SEALING WASHER 42X49 IS3175 AL	TATA spare parts
16220510674	SEALING WASHER 45X52	TATA spare parts
16220610105	SEALING WASHER ST A8X12	TATA spare parts
16220610121	WASHER A8 X 14	TATA spare parts
16220610148	SEALING WASHER ST A10X14	TATA spare parts
16220610229	SEALING WASHER ST A14X20	TATA spare parts
16220710061	SEALING WASHER CU 6X10	TATA spare parts
16220710096	SEALING WASHER CU 8X11	TATA spare parts
16220710100	SEALING WASHER 8X12 IS:3175 CU	TATA spare parts
16220710126	SEALING WASHER CU 8X14	TATA spare parts
16220710134	SEALING WASHER CU 10X13.5	TATA spare parts
16220710142	SEALING WASHER CU 10X14	TATA spare parts
16220710169	SEALING WASHER 10X16 IS3175 CU	TATA spare parts
16220710177	SEALING WASHER CU 12X15.5	TATA spare parts
16220710185	SEALING WASHER 12X16 IS3175 CU BS6-PH2	TATA spare parts
16220710207	SEALING WASHER 12X18 IS3175 CU	TATA spare parts
16220710215	SEALING WASHER CU 14X18	TATA spare parts
16220710223	SEALING WASHER CU 14X20	TATA spare parts
16220710240	THRUST WASHER (IDLER ARM)	TATA spare parts
16220710258	GASKET ELBOW TO BYPASS PIPE	TATA spare parts
16220710282	SEALING WASHER CU 18X22	TATA spare parts
16220710291	SEALING WASHER CU 18X24	TATA spare parts
16220710304	SEALING WASHER CU 20X24	TATA spare parts
16220710312	SEALING WASHER 20 X 26IS 3175 CU	TATA spare parts
16220710321	SEALING WASHER 21X26 IS3175 CU BS6	TATA spare parts
16220710347	SEALING WASHER CU 22X27	TATA spare parts
16220710380	SEALINGWASHER24X29IS3175CU	TATA spare parts
16220710428	SEALING WASHER CU 26X31	TATA spare parts
16220710452	SEALING WASHER CU 27X32	TATA spare parts
16220710487	SEALING WASHER 30X36 IS:3	TATA spare parts
16220710525	SEALING WASHER 33X39 IS3175 CU	TATA spare parts
16220710541	SEALING WASHER CU 35X41	TATA spare parts
16220710550	SEALING WASHER 36X42 IS3175 CU	TATA spare parts
16220710576	SEALING WASHER 38X44 IS3175 CU	TATA spare parts
16220710592	WASHER 39X46 CU	TATA spare parts
16220710631	SEALING WASHER 42X49 IS3175 CU	TATA spare parts
16220810210	WASHER A14 X 18	TATA spare parts
16221610109	WASHER C8 X 12	TATA spare parts
16221610346	WASHER C22X27DIN7603ALAS	TATA spare parts

16221610737	SEALING WASHER AL 52X60	TATA spare parts
16221710219	SEALING WASHER ST 14X18	TATA spare parts
16221710286	SEALING WASHER ST 18X22	TATA spare parts
16221710341	SEALING WASHER ST 22X27	TATA spare parts
16221710383	SEALING WASHER ST 24X29	TATA spare parts
16221710391	SEALING WASHER ST 24X32	TATA spare parts
16221710545	WASHER C35 X 41	TATA spare parts
16221710570	SEALING WASHER ST 38X44	TATA spare parts
16221710731	WASHER C52 X 60	TATA spare parts
16221810094	SEALING WASHER CU 8X11.5	TATA spare parts
16221810108	SEALING WASHER CU 8X12	TATA spare parts
16221810213	SEALING WASHER CU 14X18	TATA spare parts
16221810221	WASHER C14X20 CU	TATA spare parts
16221810256	WASHER	TATA spare parts
16221810281	WASHER C18X22DIN7603CUASB	TATA spare parts
16221810345	SEALING WASHER CU 22X27	TATA spare parts
16221810434	WASHER C26X32DIN7603CUASB	TATA spare parts
16221810698	WASHER C48 X 55 CU	TATA spare parts
16222210147	WASHER D10 X 14	TATA spare parts
16222210228	WASHER D14 X 20	TATA spare parts
16222310109	SEALING WASHER ST 8X12	TATA spare parts
16222310141	WASHER D10 X 14	TATA spare parts
16222410120	SEALING WASHER ST 8X14	TATA spare parts
16223001207	SEALING RING D12	TATA spare parts
16223001401	SEALING RING D14	TATA spare parts
16261000605	FERRULE L6	TATA spare parts
16261000800	FERRULE L8	TATA spare parts
16261001008	FERRULE L10	TATA spare parts
16261001202	FERRULE L12	TATA spare parts
16261001504	FERRULE L15	TATA spare parts
16261001806	FERRULE L18	TATA spare parts
16261002209	FERRULE L22 TS16592	TATA spare parts
16261071201	FERRULE L12 TS16592 SS8457S1-S-B	TATA spare parts
16262801806	SLIP RING B18	TATA spare parts
163240000000020	AL - EXTRUSION SIDE OUTER (4MTR)-PI	TATA spare parts
16350700807	CONICAL NIPPLE 10	TATA spare parts
16400902601	SOCKET BM26 X 1.5	TATA spare parts
16420800600	COUPLING BODY L6	TATA spare parts
16420800804	COUPLING BODY L8 IS9390 SS8451-8C	TATA spare parts
16420801002	COUPLING BODY L10	TATA spare parts
16420801207	COUPLING BODY L12	TATA spare parts
16420801509	COUPLING BODY L15	TATA spare parts
16420801801	COUPLING BODY L18	TATA spare parts
16420801801AE	COUPLING BODYLPA 1415/	TATA spare parts
16420802203	COUPLING BODY L22 IS9390 SS8451-8C	TATA spare parts
16420851506	COUPLING BODY L15-IS9390 SS8451S2	TATA spare parts
16422000406	SOCKET AL4	TATA spare parts

16422000601	BULK HD ST BODY L6	TATA spare parts
16422000805	BULKHD ST BODY L8 IS9768	TATA spare parts
16422001208	BULK HD ST BODY L12	TATA spare parts
16422001500	BULK HD ST BODY L15	TATA spare parts
16422001801	BULK HD ST BODY L18	TATA spare parts
16440500602	COUPLING BODY L6M	TATA spare parts
16440500807	COUPLING BODY L 8M	TATA spare parts
16440501005	COUPLING BODY L 10M TS16520	TATA spare parts
16440501200	COUPLING BODY L12M	TATA spare parts
16440501501	COUPLING BODY L15M	TATA spare parts
16440501803	COUPLING BODY L18M	TATA spare parts
16440502206	COUPLING BODY L 22M TS16520	TATA spare parts
16440511507	COUPLING BODY L15	TATA spare parts
16440512201	COUPLING BODY L 22M TS16520	TATA spare parts
16440598025	SOCKET 18 TS16529	TATA spare parts
16442800603	COUPLING BODY 6	TATA spare parts
16442801502	COUPLING BODY 15	TATA spare parts
16442811800	COUPLING BODY 18	TATA spare parts
16470599018	SOCKET C4SN15008	TATA spare parts
16471099019	SOCKET D8 SN15008	TATA spare parts
16471502000	SOCKET 20; TS 16517	TATA spare parts
16472000601	SOCKET B6	TATA spare parts
16472001501	SOCKET B15	TATA spare parts
16472001802	SOCKET B18	TATA spare parts
16500602205	ELBOW CM22 X 1.5	TATA spare parts
16500802204	ELBOW K15 M22 X 1.5	TATA spare parts
16500802603	ELBOW K18 M26 X 1.5	TATA spare parts
16502800608	BULK HD ELBOW BODY L6	TATA spare parts
16502801205	ELBOW BULK HEAD L12	TATA spare parts
16502801507	ELBOW L15	TATA spare parts
16502801809	BULK HD ELBOW L18	TATA spare parts
16530901801	BANJO M18 X 1.5	TATA spare parts
16530902203	BANJO M22 X 1.5	TATA spare parts
16530903005	BANJO BOLT M30 X 1.5	TATA spare parts
16531500800	BANJO BOLT A8	TATA spare parts
16531900603	PIPE UNION BOLT 6	TATA spare parts
16531900808	PIPE UNION BOLT 8 IS:3174	TATA spare parts
16531901006	PIPE UNION BOLT 10	TATA spare parts
16531911001	PIPE UNION BOLT 10	TATA spare parts
16531950805	PIPE UNION BOLT 8 M12X1.5 TS16405 SS8451	TATA spare parts
16531951003	PIPE UN BOLT10 M14X1.5 TS16405 SS8451S2-	TATA spare parts
16531951208	PIPE UN BOLT12M16X1.5 TS16405 SS8451S2-Y	TATA spare parts
16531999014	BANJO BOLT	TATA spare parts
16531999022	PIPE UNION BOLT 6 M10X1	TATA spare parts
16531999031	PIPE UNION BOLT 8 M12X1.5	TATA spare parts
16531999049	PIPE UNION BOLT 10M14X1.5	TATA spare parts
16531999073	PIPE UNION BOLT 4 M8X1	TATA spare parts

16531999081	PIPE UNION BOLT 12M16X1	TATA spare parts
16550802204	ELBOW KM22 X 1.5	TATA spare parts
16560501505	BANJO BODY 15	TATA spare parts
16560501807	BANJO BODY 18	TATA spare parts
16561000402	PIPE UNION 6-IS3172-SS845	TATA spare parts
16561000607	PIPE UNION 8	TATA spare parts
16561000801	BANJO BODY 10	TATA spare parts
16590501259	BANJO BODY 10	TATA spare parts
16591002001	BANJO BODY 20	TATA spare parts
16640602205	T SOCKET CM22 X 1.5	TATA spare parts
16641400606	TEE CONNECTOR L6	TATA spare parts
16641400801	EQUAL TEE BODY L8-IS9389-SS8451-8C	TATA spare parts
16641401203	TEE CONNECTOR L12	TATA spare parts
16641401505	EQUAL TEE L15 IS9389 SS8451-FEZN-8C	TATA spare parts
16641401807	TEE CONNECTOR L18	TATA spare parts
16641402200	EQUAL TEE BODY L22 IS9389 SS8451-8C	TATA spare parts
16661000604	EQUAL CROSS L6 - LPT709	TATA spare parts
16661001201	EQUAL CROSS BODY L12	TATA spare parts
167164	ELBOW PLAIN STREET PIPE	TATA spare parts
1684	GASKET	TATA spare parts
17001RU01	RUBBER BUFFER 1INCH	TATA spare parts
17002RU01	RUBBER BUFFER 3/4INCH	TATA spare parts
170049	HOSE ELBOW	TATA spare parts
17006RU01	Rubber packing taper for	TATA spare parts
170105010044	CANOPY COVER SIDE DOOR LH - IRIS	TATA spare parts
170105010045	CANOPY COVER WINDOW SIDE DOOR RH - IRIS	TATA spare parts
170105010046	CANOPY COVER SIDE DOOR LH - MAGIC	TATA spare parts
170105010047	CANOPY COVER WINDOW SIDE DOOR RH - MAGIC	TATA spare parts
17021RU01	RUBBER PROFILE FOR FLOORI	TATA spare parts
17050500101	O RING 6 X 1.80	TATA spare parts
17050500161	O RING 15.60 X 1.80	TATA spare parts
17050500179	O RING 17.17 X 1.80	TATA spare parts
17050500217	O RING 23.52 X 1.80	TATA spare parts
17050500291	O RING	TATA spare parts
17050500489	O-RING 13.2X1.78 TS16220	TATA spare parts
17050501108	O RING 9.20 X 2.65	TATA spare parts
17050501116	O-RING 10.77X2.65-TS16220	TATA spare parts
17050501124	O RING 12.37X2.65 TS16220	TATA spare parts
17050501132	O RING 14 X 2.65	TATA spare parts
17050501141	O RING 15.54 X 2.65	TATA spare parts
17050501159	O-RING 17.12X2.62	TATA spare parts
17050501167	O RING 18.72 X 2.65	TATA spare parts
17050501175	O RING 20.30 X 2.65	TATA spare parts
17050501183	O RING 21.89 X 2.65	TATA spare parts
17050501191	O RING 23.47 X 2.65	TATA spare parts
17050501205	O RING 25 X 2.65	TATA spare parts
17050501230	O RING 29.82X2.65 TS16220	TATA spare parts

17050501248	O RING 31.50 X 2.65	TATA spare parts
17050501264	O RING 34.59*2.62	TATA spare parts
17050501272	O RING 36.17 X 2.65	TATA spare parts
17050501302	O RING 40.94 X 2.65	TATA spare parts
17050501507	O RING 72.69 X 2.65	TATA spare parts
17050501574	O RING 113.97 X 2.62	TATA spare parts
17050501639	O-RING 16X2.65 TS16220	TATA spare parts
17050501744	O-RING 19X2.65 TS16220	TATA spare parts
17050501752	O-RING 7.80 X 2.65 TS 16220	TATA spare parts
17050502091	O RING 17.04 X 3.55	TATA spare parts
17050502112	O RING 20.22 X 3.55	TATA spare parts
17050502139	O RING 23.39 X 3.55	TATA spare parts
17050502147	O-RING 25.00X3.55 TS16220	TATA spare parts
17050502155	O-RING 26.57X3.55 TS16220	TATA spare parts
17050502180	O RING 31.34 X 3.55	TATA spare parts
17050502210	O RING 36.09 X 3.55	TATA spare parts
17050502228	O RING 37.69 X 3.55	TATA spare parts
17050502279	O RING 53.57 X 3.55	TATA spare parts
17050502309	OFLASERING 63.00X3.55 TS16220 BS6-PH2	TATA spare parts
17050502333	O RING 72.62 X 3.55	TATA spare parts
17050502384	O-RING 88.49X3.53 TS16220	TATA spare parts
17050502392	O RING 91.67 X 3.55	TATA spare parts
17050502406	O RING 95 X 3.55	TATA spare parts
17050502414	O RING	TATA spare parts
17050502422	O RING 101.19 X 3.55	TATA spare parts
17050502431	O RING 104.37 X 3.55	TATA spare parts
17050502538	O-RING 136.00X3.55	TATA spare parts
17050502562	O-RING 145.64X3.53 TS16220	TATA spare parts
17050502619	O-RING 171.04X3.53 TS16220	TATA spare parts
17050502708	O-RING 228.19X3.53	TATA spare parts
17050502864	O-RING 38.7X3.55 TS16220 BS6	TATA spare parts
17050503267	'O' RING	TATA spare parts
17050503381	O RING 78.74 X 5.30	TATA spare parts
17050503402	O RING	TATA spare parts
17050503411	O-RING 88.27X5.33	TATA spare parts
17050503445	O RING 97.79 X 5.30	TATA spare parts
17050503488	O RING 110.49 X 5.30	TATA spare parts
17050511928	O-RING 287X2.65 TS16220	TATA spare parts
17050596010	O-RING 238X3.55 TS16220 BS6	TATA spare parts
17050596036	O RING 42.5X3.55 NITRILE TS16220	TATA spare parts
17050599744	O RING 63.22 X 1.78	TATA spare parts
17050599752	O- RING	TATA spare parts
17050600076	O RING 0.924IN X 0.116IN	TATA spare parts
17050600084	O RING 0.755IN X 0.0971IN	TATA spare parts
170508	SD 60 FAN DRIVE	TATA spare parts
17051001001	O RING 10 X 2 NITRILE	TATA spare parts
17051001311	O-RING 13X2 A NITRILE TS16222	TATA spare parts

17051002024	O-RING 20 X 2 NITRILE	TATA spare parts
17051002521	O RING 25 X 2.5 NITRILE	TATA spare parts
17051002644	O RING 26 X 3 NITRILE	TATA spare parts
17051002873	O-RING 28X3 NITRILE TS16222	TATA spare parts
17051003039	O RING 30 X 3 NITRILE	TATA spare parts
17051011007	O-RING 110X5 A NITRILE	TATA spare parts
17051012003	O-RING 120X3 A NITRILE TS16222	TATA spare parts
17051018028	O RING 180 X 5 NITRILE	TATA spare parts
17053204287	O-RING 42.52 X 2.62	TATA spare parts
17053212531	O RING 125X2.65 A NITRILE TS 16222	TATA spare parts
17053501036	O-RING 10X1.8 - C-VITON TS16222	TATA spare parts
17053501150	O-RING 11.8X1.8 C VITON TS16222	TATA spare parts
17053501648	O RING 16X2.65 C-VITON TS16222	TATA spare parts
17053501711	O-RING 17.17X1.8 C VITON TS16222	TATA spare parts
17053501915	O-RING 19X2.65 C VITON TS16222	TATA spare parts
17053502008	O-RING 20.30X2.65 C VITON TS16222	TATA spare parts
17053503128	O-RING 31.5X2.65-C-VITON-TS16222	TATA spare parts
17053503918	O RING 39.35 X 2.62-C-VITON- TS16222	TATA spare parts
17053504817	O RING 48.7X3.55 C VITON TS16222	TATA spare parts
17053505031	O-RING 50X3 C VITON TS16222	TATA spare parts
17053506607	O-RING 66.04X5.3 C VITON TS16222	TATA spare parts
17053506917	O-RING 69.44X3.55 C VITON TS16222	TATA spare parts
17053508201	O-RING 82.27X1.8 C VITON TS16222	TATA spare parts
17053509517	O-RING 95X3.55-C-VITON	TATA spare parts
17053511007	O-RING 110X5-C-VITON	TATA spare parts
17053511201	O-RING 112X3.55 C VITON TS 16222	TATA spare parts
17053525008	O-RING 250X7 C VITON TS16222	TATA spare parts
17059406582	O-RING	TATA spare parts
17060801339	RADIAL SEAL B40 X 65	TATA spare parts
17061502211	OIL SEAL TYPE-4 22X32X7 ISO6194-1	TATA spare parts
17061504028	OIL SEAL A40X55X7 IS5129-P1-1987	TATA spare parts
17061504516	OIL SEAL PROP SHAFT-407	TATA spare parts
17061602216	OIL SEAL B22X32X7 NITRILE TS16282	TATA spare parts
17061602518	OIL SEAL B 25 X 35 X 7 BS4	TATA spare parts
17061603212	OIL SEAL B32X45X7 NITRILE TS16282	TATA spare parts
17061604006	OIL SEAL B40X50X7 NITRILE TS16282	TATA spare parts
17061604022	OIL SEAL B 40 X 55 X 7	TATA spare parts
17061604032	OIL SEAL	TATA spare parts
17061604511	OIL SEAL B45X60X8-NITRILE-TS16282	TATA spare parts
17061604529	OIL SEAL B 45 X 62 X 8	TATA spare parts
17061698019	OIL SEAL B 16 X 24 X 6.5	TATA spare parts
17061710019	OIL SEAL	TATA spare parts
17071001407	SEALING CAP 14	TATA spare parts
17071002004	SEALING CAP 20	TATA spare parts
17071002802	SEALING CAP 28	TATA spare parts
17071200019	DUST CAP	TATA spare parts
17071610012	PLUG BUTTON A 10.0-TS16275	TATA spare parts

17073001005	SEALING CAP B10 DIN443-SS8400	TATA spare parts
17073001404	SEALING CAP B14 DIN443-SS8400	TATA spare parts
17073001501	SEALING CAP B15 DIN443-SS8400	TATA spare parts
17073002001	SEALING CAP B20 DIN443-SS8400	TATA spare parts
17073002206	SEALING CAP B22	TATA spare parts
17073003008	SEALING CAP B30 DIN443-SS8400	TATA spare parts
17073004004	SEALING CAP B40	TATA spare parts
17073004209	SEALING CAP B42 DIN443 SS8400	TATA spare parts
17073503507	LOCKING PLATE 35	TATA spare parts
17073506000	LOCKING PLATE	TATA spare parts
170C428	PRESSURE PLATE	TATA spare parts
170C521	PRESSURE PLATE	TATA spare parts
1710UJ	UJ CROSS KIT 4021	TATA spare parts
17120000001	PIPE/ERW (25.4 DIA X 2 THK)(PC) L =4 MTR	TATA spare parts
17129000001	PIPE/ERW (32 DIA X 2 THK)(PC)	TATA spare parts
17129000002	PIPE/ERW (32 DIA X 2 THK) (PC)( L= 0.8 M	TATA spare parts
17170600606	GREASE NIPPLE AM6	TATA spare parts
17170600801	GREASE NIPPLE	TATA spare parts
17170601009	GREASE NIPPLE AM10 X 1	TATA spare parts
17170601602	GREASE NIPPLE AM16 X 1.5	TATA spare parts
17170650808	GREASE NIPPLE AM8X1-IS4009P2-SS8451S2-Y	TATA spare parts
17170700601	GREASE NIPPLE BM6	TATA spare parts
17170700805	GREASE NIPPLE BM8X1 IS4009P2-SS8451-8C	TATA spare parts
17170701003	GREASE NIPPLE BM10 X 1	TATA spare parts
17170800800	GREASE NIPPLE CM8 X 1	TATA spare parts
17170801008	GREASE NIPPLE CM10 X 1	TATA spare parts
17170801008AE	GREASE NIPPLE CM 10X1 -715	TATA spare parts
17172000606	GREASE NIPPLE AM6	TATA spare parts
17172001007	GREASE NIPPLE AM10 X 1	TATA spare parts
17172001009	GREASE NIPPLE AM10 X 1	TATA spare parts
17172001009AE	GREASE NIPPLE AM 10X1 715	TATA spare parts
17172001602	GREASE NIPPLE AM16 X 1.5	TATA spare parts
17175000054	GREASE CUP AM5	TATA spare parts
172473	ELBOW MALE UNION SET	TATA spare parts
17270701001	ANGULAR BALL JOINT AS10	TATA spare parts
17271001002	BALL END A10	TATA spare parts
17271201001	BALL END B10	TATA spare parts
17271201303	BALL END B13	TATA spare parts
17271201605	BALL END B16	TATA spare parts
17271601000	BALL PIN A10	TATA spare parts
17271601301	BALL PIN C13 TS15622 SS8451-8C	TATA spare parts
17271601603	BALL PIN A16	TATA spare parts
17271710453	BALL PIN B10 X 4.5	TATA spare parts
17271710801	BALL PIN B10 X 8	TATA spare parts
17272027200	BALL PIN A27 X 20	TATA spare parts
17272035407	BALL PIN A35 X 40	TATA spare parts
17273406247	FORK HEAD 6X24 TS 16320 SS-9400	TATA spare parts

17273408169	FORK HEAD 8X16	TATA spare parts
17273410201	FORK HEAD 10 X 20	TATA spare parts
17273410406	FORK HEAD 10 X 40	TATA spare parts
17273412247	FORK HEAD 12X24 TS 16320	TATA spare parts
17273412484	FORK HEAD 12 X 48	TATA spare parts
17273496033	FORK HEAD 12X48	TATA spare parts
173093	ISOLATOR VIBRATION	TATA spare parts
17380600501	KNOTTED CHAIN 1.6 TS15830 GALV	TATA spare parts
173C146	LEVER	TATA spare parts
17410620359	ROLLER CHAIN 1210SD	TATA spare parts
17561000255	V-BELT AV10X902 IS5635	TATA spare parts
17561510709	V BELT	TATA spare parts
17561515522	V BELT	TATA spare parts
17561520755	V-BELT	TATA spare parts
175836	VALVE ELBOW	TATA spare parts
17915203205	KNOB 32 TS15651	TATA spare parts
17915204007	KNOB 40 TS15651	TATA spare parts
179765	CARBURATOR ASSY.	TATA spare parts
18001EL01	BATTERY CABLE	TATA spare parts
18002EL01	PVC WIRE BROWN	TATA spare parts
1800320077	SLIDING BLOCK	TATA spare parts
18003277	DECLUTCH SHIFT ACTIVITY BLOCK	TATA spare parts
18003EL01	PVC WIRE BLUE/WHITE	TATA spare parts
18004EL01	PVC WIRE YELLOW	TATA spare parts
18005EL01	PVC WIRE BROWN	TATA spare parts
18006EL01	PVC WIRE GREY	TATA spare parts
18007EL01	PVC WIRE BLUE/BLACK	TATA spare parts
18008EL01	PVC WIRE RED/WHITE	TATA spare parts
18009EL01	PVC WIRE RED/BLACK	TATA spare parts
18010EL01	PVC WIRE RED/GREEN	TATA spare parts
18011EL01	PVC WIRE BLACK/GREEN	TATA spare parts
18012EL01	PVC WIRE BLACK/WHITE	TATA spare parts
18013EL01	PVC WIRE GREEN	TATA spare parts
18014EL01	FUSE BOX	TATA spare parts
18015EL01	AUTO FUSE	TATA spare parts
18016EL01	FROSTED ROUND GLASS FOR S	TATA spare parts
18018EL01	ROOF LIGHT	TATA spare parts
18019EL01	STEP LIGHT	TATA spare parts
18020EL01	NUMBER PLATE LIGHT	TATA spare parts
18021EL01	RED REFLECTOR (RECT.)	TATA spare parts
18022EL01	WHITE REFLECTOR (RECT.)	TATA spare parts
18024EL01	DESTI.TUBELIGHT	TATA spare parts
18025EL01	ELECTRIC BUZZER	TATA spare parts
18026EL01	DRIVER FAN	TATA spare parts
18027EL01	PUSH BELL SWITCH	TATA spare parts
18028EL01	DASHBOARD SWITCH	TATA spare parts
18032PD01	YELLOW SWITCH FOR PNEUMAT	TATA spare parts



18033PD01	GREEN SWITCH FOR PNEUMATI	TATA spare parts
180371	CLIP	TATA spare parts
180372	CLIP	TATA spare parts
1805890221	CASTER CAMBER GAUGE	TATA spare parts
180810	RING PISTON	TATA spare parts
1809931101	PRESSURE SPRING	TATA spare parts
1809970147	SEALING RING	TATA spare parts
1819950020	CLIP	TATA spare parts
18228010410	BALL VALVE 1/2 IN BSP	TATA spare parts
1824110460	PACKING RING	TATA spare parts
18400000	Hyd. Tail Gate Cylinder SA50	TATA spare parts
1869904540	WASHER	TATA spare parts
1869910055	LOCATING PIN	TATA spare parts
1869932601	SPRING	TATA spare parts
1869950220	CLAMP	TATA spare parts
187317	ADAPTER PLAIN	TATA spare parts
187350	RING PISTON	TATA spare parts
188318	SEAL THERMOSTAT	TATA spare parts
1884110258	RETAINER	TATA spare parts
1884110460	PACKING RING	TATA spare parts
1889940034	LOCK RING	TATA spare parts
1889940134	LOCK RING	TATA spare parts
1889940234	LOCK RING	TATA spare parts
1889940534DB	SPRING RING	TATA spare parts
1900023005	WOODRUFF KEY	TATA spare parts
1900023008	WOODRUFF KEY	TATA spare parts
19001SE01	TWO SEATER SEAT CUSHION	TATA spare parts
1900210013	O RING	TATA spare parts
1900210100	O RING	TATA spare parts
1900210163	SEALING RING	TATA spare parts
19002SE01	TWO SEATER SEAT BACK	TATA spare parts
19003SE01	SIX SEATER SEAT CUSHION	TATA spare parts
19004SE01	SIX SEATER SEAT BACK	TATA spare parts
19005SE01	CUNDUCTOR SEAT CUSHION	TATA spare parts
19006SE01	CUNDOCTOR SEAT BACK	TATA spare parts
1900900018	BEARING BALL	TATA spare parts
1900905376	SHIM 1.96 MM	TATA spare parts
1900910201	ROLLER BEARING	TATA spare parts
1900910202	ROLLER BEARING	TATA spare parts
19020100012	TURN BUCKLE NUT SP M6	TATA spare parts
19020100110	NUT M8	TATA spare parts
19020100357	BLACK WASHER R14DIN440	TATA spare parts
1903103002	LINK PIN	TATA spare parts
1903385005	BANJO	TATA spare parts
1903385009	BANJO	TATA spare parts
19080161321	STRAIGHT UNION 6MM OD	TATA spare parts
19080196120	PUSH IN FITTING	TATA spare parts

19080196281	PUSH IN FITTING	TATA spare parts
19090100095	FORK HEAD G10 X 40	TATA spare parts
19090100133	PULLROD 10 X 560 X 80	TATA spare parts
19090100150	PULLROD 10 X 945 X 60	TATA spare parts
19090100184	PULLROD 10X1300X80/80	TATA spare parts
19090100206	PULLROD 10X1425X80/80	TATA spare parts
19090100249	PULLROD 10X920X80/80	TATA spare parts
19090100257	PULLROD 10X1765X80/80	TATA spare parts
19090100371	PULLROD 10X1100X80/80	TATA spare parts
19200204	FORK PIN	TATA spare parts
19400000	Pneumatic PTO Shift Cylinder	TATA spare parts
195C96	ADJUSTING RING	TATA spare parts
19668	RETAINER - SUN GEAR	TATA spare parts
1999970082	HOSE	TATA spare parts
199C4-2	RIVET	TATA spare parts
1D804400	TIE ROD ASSY	TATA spare parts
1D814000	TAIL DOOR LOCKING MECHANISM	TATA spare parts
1E800013	VALVE MOUNTING PLATE	TATA spare parts
1F200000	ASSY TAIL DOOR LPK2530TC 6X4	TATA spare parts
1F214010	CROSS ROD (NOVUS)	TATA spare parts
1H806000	SUBFRAME ASSEMBLY 14 RIBLESS	TATA spare parts
2000300095	INT RING	TATA spare parts
2000308002	INSULATING BUSH	TATA spare parts
200115100101	STARTER MOTOR	TATA spare parts
200124100101	HOUSING ENG MTG PAD FR	TATA spare parts
200124200101	HOUSING ENG MTG PAD RR RH	TATA spare parts
200124200102	HOUSING ENG MTG PAD RR LH	TATA spare parts
200125400103	CL PR PLATE 280 DIA	TATA spare parts
200125400104	CLUTCH PR PLATE	TATA spare parts
200126203101	ROLLER CAGE	TATA spare parts
200129308701	RETURN SPRING	TATA spare parts
200131008201	COVER FRONT SKIRT	TATA spare parts
200132204201	U CLAMP	TATA spare parts
200132400106	LINK ROD ASSY	TATA spare parts
200132504201	U CLAMP	TATA spare parts
200141100102	ASSY.PROP SHAFT REAR	TATA spare parts
200141308202	PROTECTIVE CAP	TATA spare parts
200146206301	FOAM PACKING	TATA spare parts
200149100106	SILENCER ASSY	TATA spare parts
200154007502	COVER WARNING LAMP	TATA spare parts
200154509904	OIL PRESSURE SWITCH	TATA spare parts
200154600157	ASSY CABLE SET	TATA spare parts
200154610120	W/HARNESS CABIN NLS	TATA spare parts
200154610121	W/H CABIN RHD AMP	TATA spare parts
200154610122	W/H TAIL RHD AMP	TATA spare parts
200160108209	REINF LH INN SIDE BONNET	TATA spare parts
200160108210	REINF RH INN SIDE BONNET	TATA spare parts

200160108211	REINF LH FRT PANEL H/LAMP	TATA spare parts
200160108212	REINF RH FRT PANEL H/LAMP	TATA spare parts
200161200106	PANEL TAIL GATE SILL INNER	TATA spare parts
200161608236	INNER ANGLE(BONNET PANEL INNER) BS6	TATA spare parts
200165700113	ASSY.SUPPORT PLATE MIDDLE. BS6	TATA spare parts
200167102301	W/S GLASS	TATA spare parts
200168906325	INST PANEL RHD W/O S CAN	TATA spare parts
200181100109	RV MIRROR INNER	TATA spare parts
200181100128	ROOF BEADING	TATA spare parts
200181100138	ASSY.SIDE STEP COMPL W/ CHEQUERED PLATE	TATA spare parts
200181100139	ASSY.SIDE STEP COMPL.W/CHEQUERED PLATE	TATA spare parts
200181106327	RUBBER PACKING (END CAP ROOF BEADING)	TATA spare parts
200188500133	BUMPER COMP TM/TE	TATA spare parts
200188500134	BUMPER FR COMP T/S	TATA spare parts
200188600104	BUMPER RR COMP T/S	TATA spare parts
200188600116	PLATE TAIL LAMP MTG	TATA spare parts
200188600117	SIDE BUMPER LH W/HOLES	TATA spare parts
200198800102	ASSY A MASCOT	TATA spare parts
200293	ELBOW MALE UNION	TATA spare parts
2004616001	PULL OFF SPRING	TATA spare parts
2005128	FILTER REGULATOR ASSY	TATA spare parts
2005144	COVER	TATA spare parts
2007014065	CARBON BRUSH SET	TATA spare parts
201080009001	PNEUMATIC DRILLING MACHINE 10MM	TATA spare parts
201080009010	PNEUMATIC DRILL 16MM	TATA spare parts
201080018001	WRENCH 27/24	TATA spare parts
201080034002	PNEUMATIC RIVET	TATA spare parts
201080040003	SCREW DRIVER-TORQUE¿3-17NM	TATA spare parts
201080040004	SCREWDRIVER PM	TATA spare parts
201223240100	FLEX RUBBER ELEMENT	TATA spare parts
201244150110	SP HOSE ASSY	TATA spare parts
201244150111	HOSE	TATA spare parts
201244150113	HOSE	TATA spare parts
201244170103	CONTROL VALVE	TATA spare parts
201244200107	STEEL TUBE	TATA spare parts
201244400100	HYDRAULIC TANK	TATA spare parts
201244405301	GASKET	TATA spare parts
201261100606	U CLAMP SUPPORT	TATA spare parts
201263319201	LOCKING PLATE	TATA spare parts
201263350102	BRACKET 4TH	TATA spare parts
201263356702	PIN	TATA spare parts
201263358001	SCREW EYE BOLT	TATA spare parts
201264306701	PIN	TATA spare parts
201944100103	HOSE 3/8 2140 L	TATA spare parts
201989140100	TIE ROD ASSY	TATA spare parts
202044108103	SEALING WASHER	TATA spare parts
202044148601	SPACER	TATA spare parts

202077209901	PURFORATED SHEET	TATA spare parts
20231040001	WEAT.STRIP (PASS.DR-MDL-SMALL D)	TATA spare parts
20231050001	WEAT.STRIP (PASS.DR-FLAP/SHAFT)	TATA spare parts
203044100110	HOSE	TATA spare parts
203044100117	HOSE ASSY H PR 3/4 INCH	TATA spare parts
203044220102	CONTROL VALVE	TATA spare parts
203063106701	PIN	TATA spare parts
203131	NUT HEAVY HEXAGON	TATA spare parts
2035180	WASHER PLAIN	TATA spare parts
204120000000000	PVC EXTRUSION BLACK ( 20 MTR )	TATA spare parts
204163	HEAD CORROSION RESISTOR	TATA spare parts
20455000007	WEATHER STRIP (CENTRE-5PC W/S)	TATA spare parts
20455000010	WEATHER STRIP - CENTRE(L=2MTR)	TATA spare parts
2049309532	SHIM	TATA spare parts
2049309533	SHIM	TATA spare parts
2049309534	SHIM	TATA spare parts
2049309535	SHIM	TATA spare parts
2049309536	SHIM	TATA spare parts
204994	CONNECTOR MALE	TATA spare parts
204995	ELBOW MALE ADAPTER	TATA spare parts
205003114701	BOTTOM COVER ( FLYWHEEL HOUSING) BS6	TATA spare parts
205009130108	ASY.BRACKET AIR FILTER MT	TATA spare parts
205009130115	BRACKET AIR FILTER	TATA spare parts
205009130123	ASSY.BRACKET	TATA spare parts
205009130130	AIR FILTER ASSY OIL BATH	TATA spare parts
205009135802	RUBBER HOSE AIR INTAKE	TATA spare parts
205009135816	HOSE-FLEXIBLE	TATA spare parts
205020120102	ASSY.T-CONNECTOR	TATA spare parts
205020125801	RUBBER HOSE RADIATOR	TATA spare parts
205024000101	ASSY. RTR/KIT FOR ENG. AT 1 DEG-LPS3516.	TATA spare parts
205024100103	ASSY.TORQUE SUPPORT	TATA spare parts
205024200103	ASSY.RUBBER SUPPORT-REAR	TATA spare parts
205025605102	CLUTCH RELEASE FORK SHORTER 318MM	TATA spare parts
205026159901	ADAPTER	TATA spare parts
205026206301	RUBBER BELLOW	TATA spare parts
205026800102	BRACKET GEAR SHIFT LEVER	TATA spare parts
205026800113	TURNING TUBE ASSY	TATA spare parts
205026807102	SPACER	TATA spare parts
205029104701	COVER FOR ACCL.PEDAL	TATA spare parts
205029104702	RUBBER COVER EPDM	TATA spare parts
205031307119	REINFORCE REAR R.H (BOTTOM)	TATA spare parts
205031307120	REINFORCE REAR L.H (BOTTOM)	TATA spare parts
205032100113	ASSY FRONT SPRING LP BUS	TATA spare parts
205032100114	ASSY FRONT SPRING HIGH CAMBER	TATA spare parts
205032403703	SHACKLE-CAST-VERSION	TATA spare parts
205032407101	LEAF SPRING 1ST	TATA spare parts
205032407102	LEAF SPRING 2ND	TATA spare parts

205032407103	LEAF SPRING 3RD	TATA spare parts
205032407107	LEAF SPRING 7TH	TATA spare parts
205032407109	LEAF SPRING 9TH	TATA spare parts
205032407110	LEAF SPRING 10TH	TATA spare parts
205032504202	U CLAMP	TATA spare parts
205033500101	ASSY. FRT.AXLE COMPL.	TATA spare parts
205035300102	ASSY END YOKE REAR AXLE 1 LPK2516TC	TATA spare parts
205035300103	ASSY END YOKE REAR AXLE 2 LPK2516TC	TATA spare parts
205035305002	END YOKE REAR AXLE LPK2516TC	TATA spare parts
205040300102	SPARE WHEEL LIFTING UNIT	TATA spare parts
205042900102	SET ASSY NYLON PIPE COMPL LPT2515	TATA spare parts
205043100104	PLAST CONTAINER W/STRAP	TATA spare parts
205046107701	PROTECTIVE RUBBER CAP	TATA spare parts
205046108701	SPRING RING	TATA spare parts
205047107701	PROFILED RUBBER PACKING	TATA spare parts
205047107702	RUBBER PACKING	TATA spare parts
205049200109	ASSY SILENCER W/PIPE 2516	TATA spare parts
205049200117	EXHAUST PIPE FRT	TATA spare parts
205049206917	INTERMEDIATE PIPE	TATA spare parts
205050000108	RADIATOR FRAME	TATA spare parts
205050000109	RADIATOR FRAME	TATA spare parts
205050000119	ASSY. BRACKET-LH	TATA spare parts
205050000120	ASSY. BRACKET-RH	TATA spare parts
205050005804	RADIATOR HOSE EPDM	TATA spare parts
205050006905	TIE TUBE	TATA spare parts
205050100106	KIT AUX WATER TANK 2516	TATA spare parts
205050100110	RADIATOR ASSY 1312 TC	TATA spare parts
205050105802	RUBBER HOSE	TATA spare parts
205050106901	VENT TUBE	TATA spare parts
205050106902	WATER FILLER PIPE	TATA spare parts
205050106903	TUBE	TATA spare parts
205050506301	FAN SHROUD	TATA spare parts
205050508201	FAN SHROUD	TATA spare parts
205054100104	BLINKER LAMP LH	TATA spare parts
205054100105	BLINKER LAMP W/O BULB RH	TATA spare parts
205054100106	COVER TOP BATTERY	TATA spare parts
205054100108	BATTERY CARRIER	TATA spare parts
205054100130	ASSY SUPPORT	TATA spare parts
205054109901	BATTERY COVER	TATA spare parts
205054109925	BUZZER UNIT	TATA spare parts
205054200103	TANK UNIT	TATA spare parts
205054207501	SEALING RING	TATA spare parts
205054400103	ASSY.GUARD (4 CH.TAIL LAMP) LPTA 713 TC	TATA spare parts
205054408209	BRACKET (TAIL LAMP GUARD)	TATA spare parts
205054408213	BRACKET (CONVOY LAMP)	TATA spare parts
205060000114	CAB KIT SFC CAB	TATA spare parts
205060010108	ASSY. BONNET STAY	TATA spare parts

205061010107	END CROSS MEMBER MIDDLE	TATA spare parts
205062200101	ASSY SUPPORT WAIST RAIL	TATA spare parts
205067107701	FILLER PROFILE EPDM	TATA spare parts
205068900106	INSTRUMENT PANEL	TATA spare parts
205068900109	ASSY INSTRUMENT PANEL WELDED RHD	TATA spare parts
205070100108	ASSY SUPPORT BOTTOM	TATA spare parts
205070100109	ASSY SUPPORT W/LUG LH&RH	TATA spare parts
205070100110	ASSY SUPPORT WITH LUG RH	TATA spare parts
205070100111	ASSY SUPPORT WITH LUG LH	TATA spare parts
205070108213	SPACER SHEET	TATA spare parts
205072027701	RUBBER PACKING DOOR HINGE	TATA spare parts
205072030119	KIT-DOOR LOCKS & KEYS BS1/2/3	TATA spare parts
205072300101	ASSY HINGE	TATA spare parts
205072300102	ASSY HINGE	TATA spare parts
205081900101	ASSY ENGINE SHEILDING RH	TATA spare parts
205081900105	ASSY.ENGINE SHIELDING RH RHD	TATA spare parts
205081902012	INSULATION LH(BON.SIDE PA	TATA spare parts
205081902013	INSULATION RH(BON.SIDE PA	TATA spare parts
205083100102	ASSY. BLOWER	TATA spare parts
205083106302	AIR DUCT-TOP	TATA spare parts
205083106303	DUCT-SUCTION SIDE	TATA spare parts
205083106305	AIR DUCT BOTTOM	TATA spare parts
205083106306	RUBBER HOSE FORMED	TATA spare parts
205083300101	ASSY. CABLE	TATA spare parts
205083503303	CLAMP	TATA spare parts
205083806301	COVER AIR FILTER LH RHD	TATA spare parts
205088500118	BUMPER COMPLPETE WITH REFLECTIVE TAPE	TATA spare parts
205088500118C0	ASSY BUMPER WITH REFLECTOR - BLACK	TATA spare parts
205088506301	FENDER LH	TATA spare parts
205088506302	FENDER RH	TATA spare parts
205088700103	ENG HOOD	TATA spare parts
205088700105	ASSY.ENGINE HOOD COMPLETE	TATA spare parts
205088700109	ASSY. TOGGLE CLAMP ENGN. HOOD	TATA spare parts
205088706301	ENGINE HOOD COMPLETE	TATA spare parts
205401	PLUG EXPANSION	TATA spare parts
205C61	SHIPPING BOLT	TATA spare parts
206001000088	ENGINE 692D SFC	TATA spare parts
206001150110	ELBOW AIR INTAKE	TATA spare parts
206001153804	ELBOW AIR INTAKE	TATA spare parts
206001170114	OIL DIPSTICK COMPLETE	TATA spare parts
206003123401	SET THRUST WASHER STD	TATA spare parts
206003123402	THRUST WASHER SET R/S-I	TATA spare parts
206003123403	SET THRUST WASHER RS2	TATA spare parts
206003123404	THRUST WASHER 15MM 1210	TATA spare parts
206003123406	SET THRUST WASHER RS2	TATA spare parts
206005113103	BEARING CAMSHAFT	TATA spare parts
206005216201	THRUST WASHER STEEL	TATA spare parts

206007129201	WASHER	TATA spare parts
206009110105	OVERFLOW LINE	TATA spare parts
206009130112	AIR FILTER ASSY OIL BATH	TATA spare parts
206009130114	BRACKET ASSY	TATA spare parts
206009130118	BRACKET AIR FILTER	TATA spare parts
206009130121	BRACKET ASSY	TATA spare parts
206009130137	BEND PIPE	TATA spare parts
206009130138	ASSY CLAMP	TATA spare parts
206009130170	BEND PIPE	TATA spare parts
206009130247	STRAP	TATA spare parts
206009134202	CLAMP	TATA spare parts
206009135801	RUBBER HOSE	TATA spare parts
206009135802	RUBBER HOSE	TATA spare parts
206009136304	RUBBER SLEEVE	TATA spare parts
206009136914	PIPE AIR INLET	TATA spare parts
206009139902	RUBBER STRAP	TATA spare parts
206013113101	CON ROD BRG LOWER STD	TATA spare parts
206013113102	CON ROD BRG UPPER STD	TATA spare parts
206013113103	C R BRG SHELL	TATA spare parts
206013113106	C R BRG SHELL	TATA spare parts
206013116701	PISTON PIN AIR COMP	TATA spare parts
206015009902	STARTER MOTOR TYPE	TATA spare parts
206018130101	OIL FILTER CARTRIDGE-SINGLE LIFE	TATA spare parts
206025200601	REP KIT CLUTCH DISC	TATA spare parts
206025200602	REP KIT CLUTCH DISC	TATA spare parts
206025400601	REP KIT CLUTCH MAJ 4MM	TATA spare parts
206025400602	REP KIT CLUTCH MJR 4MM	TATA spare parts
206025400603	REP KIT CLUTCH MJR 4MM	TATA spare parts
206025400604	REP KIT CLUTCH MAJ 3.5MM	TATA spare parts
206025400605	REP KIT CLUTCH MJR 3.5MM	TATA spare parts
206025400606	REP KIT CLUTCH MNR 3.5MM	TATA spare parts
206025400607	REP KIT CLUTCH MNR 3.5MM	TATA spare parts
206025400608	REP KIT CLUTCH MNR 4MM	TATA spare parts
206025400609	REP KIT CLUTCH MNR 4MM	TATA spare parts
206025400610	CL REP KIT MINOR 4.0	TATA spare parts
206025400611	REP KIT CLUTCH MAJ 3.5MM	TATA spare parts
206025400612	REP KIT CLUTCH MNR 3.5MM	TATA spare parts
206025400613	REP KIT CLUTCH MAJ 3.5MM	TATA spare parts
206025400614	CLUTCH R/KIT MINOR 3.5	TATA spare parts
206025600101	CLUTCH RELEASE FORK W/BRG	TATA spare parts
206025605101	RELEASE FORK	TATA spare parts
206026000119	ASY.GEAR SHIFT LEVER CR19	TATA spare parts
206026000121	ASSY BRACKET	TATA spare parts
206026000123	LINK ROD RHD GBS-40	TATA spare parts
206026000124	LINK ROD ASSY	TATA spare parts
206026000128	GEAR SHIFT LEVER RHD	TATA spare parts
206026400101	PTO ASSY FOR GBS-40	TATA spare parts

206026706301	RUB BELLOW GEAR LEVER	TATA spare parts
206026800101	ASSY SHIFTING YOKE	TATA spare parts
206026807701	PROTECTIVE CAP LHD	TATA spare parts
206026807702	PROTECTIVE CAP RHD	TATA spare parts
206029000115	ASSY BRAKE PEDAL LEVE	TATA spare parts
206029100105	PULL ROD BRAKE	TATA spare parts
206029100114	CLUTCH PEDAL LEVER	TATA spare parts
206029100128	CL MASTER CYL	TATA spare parts
206029106702	PIN	TATA spare parts
206029150113	ASSY.CONNECTING LINE	TATA spare parts
206029150117	ASSY.PIPE DIA 6X0.7X1490	TATA spare parts
206029150122	CONNECTING LINE HYD	TATA spare parts
206029200102	BRAKE PEDAL LEVER	TATA spare parts
206029200107	CLUTCH PEDAL LEVER	TATA spare parts
206029300103	CLUTCH PEDAL LEVER COMP.	TATA spare parts
206029300106	CLUTCH PEDAL LEVER RHD	TATA spare parts
206029300108	LEVER COMPLETE	TATA spare parts
206029300115	ASSY CLUTCH ROD	TATA spare parts
206029300128	ASSY BRAKE TUBE	TATA spare parts
206029300135	CLUTCH ROD	TATA spare parts
206029306701	PIN	TATA spare parts
206029308701	CLUTCH RETURN SPRING	TATA spare parts
206029500107	DOUBLE LEVER BRAKE	TATA spare parts
206030100102	PEDAL ACCELERATOR	TATA spare parts
206030100106	THRUST ROD	TATA spare parts
206030105101	HINGE BOTTOM	TATA spare parts
206030106003	THRUST ROD	TATA spare parts
206031010160	FRAME 1210E42	TATA spare parts
206031010162	ASY FRAME WO FRT CPLG LP/	TATA spare parts
206031200103	S/ABSORBER CROSS MEMBER	TATA spare parts
206031200105	BUMPER CROSS MEMBER	TATA spare parts
206031200110	ASSY.BUMPER CROSS MEMB	TATA spare parts
206031200113	ASSY SUPPORT ENGINE CROSS MEMBER FRT RH	TATA spare parts
206031200114	ASSY SUPPORT ENGINE CROSS MEMBER FRT LH	TATA spare parts
206031200117	ASSY BRACKET RH FRONT MTG	TATA spare parts
206031200136	RUBBER BUFFER	TATA spare parts
206031200139	ASSY BRKT FOR STRG.MNTG	TATA spare parts
206031203401	BUSH BS6	TATA spare parts
206031207122	SUPPORT ENG LONG MEMBER	TATA spare parts
206031207123	CROSS MEMBER	TATA spare parts
206031207139	2ND LEAF	TATA spare parts
206031207154	SUPPORT FRONT LH ENGINE	TATA spare parts
206031207155	SUPPORT FRONT RH ENGINE	TATA spare parts
206031207156	SUP RR LH ENG X MEMBER	TATA spare parts
206031207157	SUP RR RH ENG X MEMBER	TATA spare parts
206031207158	BRACKET FOR STEERING MOUNTING BRACKET	TATA spare parts
206031208205	SHIM	TATA spare parts



206031208235	REINFORCEMENT	TATA spare parts
206032000101	MAIN LEAF WITH BUSH	TATA spare parts
206032000102	LEAF SPRING 1ST W/BUSH	TATA spare parts
206032023401	BUSH	TATA spare parts
206032100102	FRONT SPRING ASSY N/CAMB	TATA spare parts
206032100103	ASSY.FRT.SPRING R SIDE	TATA spare parts
206032100106	FRONT SPRING ASSY N/CAMB	TATA spare parts
206032100107	FRONT SPRING ASSY H/CAMB	TATA spare parts
206032100108	LEAF SPRING 1ST W/BUSH	TATA spare parts
206032100108DF	MAIN LEAF FRONT W/BUSH-TATA1210/1612	TATA spare parts
206032100109	LEAF SPRING 1ST W/BUSH FR	TATA spare parts
206032100110	FRONT SPRING ASSY	TATA spare parts
206032100111	FRONT SPRING ASSY H/CAMB	TATA spare parts
206032100114	FRONT SPRING ASSY	TATA spare parts
206032100115	FRONT SPRING ASSY H/CAMB	TATA spare parts
206032103203	CENTRE BOLT	TATA spare parts
206032107102	1ST LEAF-SPRING	TATA spare parts
206032107103	LEAF SPRING 2ND FRT	TATA spare parts
206032107104	LEAF SPRING 3RD FRT	TATA spare parts
206032107105	LEAF SPRING 4TH FRT	TATA spare parts
206032107106	LEAF SPRING 5TH FRT	TATA spare parts
206032107108	LEAF SPRING 7TH FRT	TATA spare parts
206032107115	2ND LEAF-SPRING	TATA spare parts
206032107117	LEAF SPRING 4TH FRT	TATA spare parts
206032107118DF	FIFTH LEAF FRONT-TATA1210/1612	TATA spare parts
206032107119DF	SIXTH LEAF FRONT-TATA1210/1612	TATA spare parts
206032107120DF	SEVENTH LEAF FRONT-TATA 1210/1612	TATA spare parts
206032107122DF	MAIN LEAF FRONT AUX-B - TATA1210/1612	TATA spare parts
206032107123DF	MAIN LEAF FRONT AUX-A - TATA1210/1612	TATA spare parts
206032107124	11TH LEAF-SPRING	TATA spare parts
206032107124DF	SECOND LEAF FRONT - TATA 1210/1612	TATA spare parts
206032107127	LEAF SPRING 1ST FRT	TATA spare parts
206032107128	LEAF SPRING 2ND FRT	TATA spare parts
206032107129	LEAF SPRING 3RD FRONT	TATA spare parts
206032107130	LEAF SPRING 4TH FRT	TATA spare parts
206032107131	LEAF SPRING 5TH FRT	TATA spare parts
206032107132	LEAF SPRING 6TH FRT	TATA spare parts
206032107133	LEAF SPRING 7TH FRT	TATA spare parts
206032107134	LEAF SPRING 8TH FRT	TATA spare parts
206032107135	LEAF SPRING 9TH FRT	TATA spare parts
206032107136	10TH LEAF	TATA spare parts
206032107138	LEAF SPRING 1ST FRT	TATA spare parts
206032107139	LEAF SPRING 2ND FRT	TATA spare parts
206032107140	LEAF SPRING 3RD FRT	TATA spare parts
206032107141	LEAF SPRING 4TH FRT	TATA spare parts
206032107142	LEAF SPRING 5TH FRT	TATA spare parts
206032107143	LEAF SPRING 6TH FRT	TATA spare parts

206032107144	LEAF SPRING 7TH FRT	TATA spare parts
206032107145	LEAF SPRING 8TH FRT	TATA spare parts
206032107146	LEAF SPRING 9TH FRT	TATA spare parts
206032107147	LEAF SPRING 10TH FRT	TATA spare parts
206032400101	ASSY FRONT SPRING LP BUS	TATA spare parts
206032400102	LEAF SPRING 1ST RR	TATA spare parts
206032400105	REAR SPRING LP BUS	TATA spare parts
206032400107	ASSY SPRING SHACKLE	TATA spare parts
206032400111	ASSY.REAR SPRING LP	TATA spare parts
206032403401	BUSH	TATA spare parts
206032407102	2ND LEAF	TATA spare parts
206032407103	LEAF SPRING 3RD	TATA spare parts
206032407106	6TH LEAF	TATA spare parts
206032608601	SPACER	TATA spare parts
206032803303	BRACKET (FOR ANTIROLL BAR MOUNTING)	TATA spare parts
206032803305	ANTIROLLBAR BRACKET RH	TATA spare parts
206032803306	BKT ANTI ROLL BAR LH	TATA spare parts
206033000112	ASSY FRONT AXLE WITH BRAK	TATA spare parts
206033103001	TAPER ROLLER BEARING	TATA spare parts
206033104201	U CLAMP 210X17DIA	TATA spare parts
206033104202	U CLAMP 17D X 225 LONG	TATA spare parts
206033104206	U-BOLT FRONT (ZN) 17DIA	TATA spare parts
206033104207	U CLAMP 17D X 225 LONG	TATA spare parts
206033104209	U CLAMP 15D X 200 LONG	TATA spare parts
206033104212	U CLAMP 17D X 252 LONG	TATA spare parts
206033105301	GUIDE PLATE CAST FRONT	TATA spare parts
206033105302	GUIDE PLATE	TATA spare parts
206033153301	BRACKET (BREATHER HOSE ON FRT AXLE) BS6	TATA spare parts
206033200103	STUB AXLE ASSY STD	TATA spare parts
206033203101	BEARING TAPER ROLLER	TATA spare parts
206033203102	TAPER ROLLER BEARING	TATA spare parts
206033205101	STUB AXLE POWER STRG	TATA spare parts
206033207201	PLUG STUB AXLE TOP	TATA spare parts
206033717701	SEALING RING	TATA spare parts
206033717701AE	SEALING RINGLPA 1415/	TATA spare parts
206033717702	SEALING RING	TATA spare parts
206033805101	STEERING ARM TOP	TATA spare parts
206033815101	STEERING ARM RIGHT	TATA spare parts
206035005400	SET A/SHAFT & BEVEL GEARS	TATA spare parts
206035013001	TAPER ROLLER BRG 31312-L BS1/2/3/4	TATA spare parts
206035013001AE	TAPER RLLER BRG.(60X135X33)-1628	TATA spare parts
206035013002	BEARING CYL ROLLER	TATA spare parts
206035013101	TAPER ROLLER BRG.	TATA spare parts
206035104201	U-CLAMP 17DIA	TATA spare parts
206035104203	U CLAMP	TATA spare parts
206035104206	U CLAMP 17D X 340 LONG	TATA spare parts
206035104207	U CLAMP 17D X 280 LONG	TATA spare parts

206035104211	U CLAMP 17D X 240 LONG	TATA spare parts
206035104212	U CLAMP 17D X 240 LONG	TATA spare parts
206035104214	U CLAMP 17D X 250 LONG	TATA spare parts
206035104220	U-CLAMP(ZN) 17DIA 220LG	TATA spare parts
206035105301	GUIDE PLATE	TATA spare parts
206035313001	TAPER ROLLER BEARING OUTER	TATA spare parts
206035313002	BEARING CYL ROLLER	TATA spare parts
206035313002AE	CYL Rlr BRG XENON DC/XENON SC	TATA spare parts
206035314301	CIRCLIP	TATA spare parts
206035315102	SHIM 0.10 MM	TATA spare parts
206035315103	SHIM 0.25 MM	TATA spare parts
206035315104	SHIM 0.50MM THK.	TATA spare parts
206035318302	SHIM 0.10 MM	TATA spare parts
206035318303	SHIM	TATA spare parts
206035318304	SHIM	TATA spare parts
206035318306	SHIM 0.10 MM	TATA spare parts
206035318307	SHIM 0.15	TATA spare parts
206035318308	SHIM 0.20 MM	TATA spare parts
206035318309	SHIM 0.50 MM	TATA spare parts
206035318310	SHIM 1.50 MM	TATA spare parts
206035603301	TAPER ROLLER BEARING OUTER	TATA spare parts
206035603302	BEARING TAPER ROLLER	TATA spare parts
206035717701	SEALING RING	TATA spare parts
206040303203	HOOK BOLT ASSY	TATA spare parts
206040308601	SPACER	TATA spare parts
206041100101	PROP SHAFT FR W/CEN BRG	TATA spare parts
206041100110	PROP SHAFT FR 70X3X1408	TATA spare parts
206041100118	PROP SHAFT	TATA spare parts
206041116501	HEX NUT	TATA spare parts
206041118702	SPRING RING 2.60 MM	TATA spare parts
206041118703	SPRING RING 2.65 MM	TATA spare parts
206041118704	SPRING RING 2.70 MM	TATA spare parts
206041118705	SPRING RING 2.75 MM	TATA spare parts
206041118706	SPRING RING 2.50 MM	TATA spare parts
206041118707	SPRING RING 2.55 MM	TATA spare parts
206041308201	SPACER	TATA spare parts
206041308203	SPACER PLATE	TATA spare parts
206042020102	END COVER	TATA spare parts
206042021801	AIR CYLINDER	TATA spare parts
206042100106	BRAKE FLUID CONTAINER	TATA spare parts
206042100109	BRAKE FLUID CONTAINER RH	TATA spare parts
206042120101	REP KIT WHEEL CYL FRT	TATA spare parts
206042120102	REP KIT WHEEL CYL FRT	TATA spare parts
206042320101	REP KIT WHEEL CYL RR	TATA spare parts
206042320102	REP KIT WHEEL CYL RR	TATA spare parts
206042700143	PIPE AIR	TATA spare parts
206042700147	PIPE AIR 15 X 460	TATA spare parts

206042700158	PIPE AIR	TATA spare parts
206042703303	BRACKET BS6	TATA spare parts
206042703311	SUPPORT ASSY	TATA spare parts
206042703322	BRACKET	TATA spare parts
206042706902	PIPE AIR 15 X 1.5 X 695	TATA spare parts
206042710110	PIPE AIR 12 X 1 X 1370	TATA spare parts
206042710113	PIPE AIR 12D	TATA spare parts
206042710163	PIPE AIR 6 X 0.7 X 1340	TATA spare parts
206042710164	PIPE AIR 6 X 0.7 X 1830	TATA spare parts
206042710165	PIPE AIR 6 X 0.7 X 1400	TATA spare parts
206042710166	PIPE AIR 6 X 0.7 X 1700	TATA spare parts
206042710167	PIPE AIR 6 X 1750	TATA spare parts
206042710168	PIPE AIR 6 X 0.7 X 1730	TATA spare parts
206042710169	PIPE AIR 6 X 0.7 X 1215	TATA spare parts
206042720112	ASSY TUBE 6 X 260	TATA spare parts
206042720113	ASSY TUBE 6 DIA X 2000 LG	TATA spare parts
206042720116	ASSY TUBE 6 DIA X 1950 LG	TATA spare parts
206042720146	PIPE AIR 15 X 1.5 X 360	TATA spare parts
206042720147	PIPE AIR 15 X 1.5 X 460	TATA spare parts
206042720154	PIPE AIR 12 X 2605	TATA spare parts
206042720155	ASSY PIPE 12 DIA X 2730LG	TATA spare parts
206042720167	PIPE ASSY 6D X 1810	TATA spare parts
206042730119	ASSY PIPE 12 DIA X 2070LG	TATA spare parts
206042730139	PIPE AIR 12D X 2720 LG	TATA spare parts
206042730165	ASSY PIPE 12DIA X 230LG LPTA 713/32TC	TATA spare parts
206042730166	ASSY.PIPE 12 DIA X 455 LG LPTA 713/32TC	TATA spare parts
206042730185	PIPE ASSY 12D X 955LG	TATA spare parts
206042730188	PIPE ASSY 12D X 560LG	TATA spare parts
206042730197	ASSY TUBE	TATA spare parts
206042730198	ASSY TUBE	TATA spare parts
206042800103	BRAKE TUBE LH	TATA spare parts
206042800104	BRAKE TUBE	TATA spare parts
206042800108	CONNECTING LINE RHD	TATA spare parts
206042800109	CONNECTING LINE RHD	TATA spare parts
206042800115	CONNECTING LINE	TATA spare parts
206042800116	CONNECTING LINE LHD	TATA spare parts
206042800188	BRAKE TUBE	TATA spare parts
206042800194	BRAKE TUBE	TATA spare parts
206042803327	BRACKET (ON CM FRT)	TATA spare parts
206042804203	CLAMP BS6	TATA spare parts
206042804204	CLAMP-AIR COMPRESSOR	TATA spare parts
206042804210	CLIP	TATA spare parts
206042804213	CLAMP	TATA spare parts
206042804215	CLAMP(6DIA.X6DIA.) ZP	TATA spare parts
206042805807	RUBBER HOSE	TATA spare parts
206042806901	PIPE AIR 18 X1.5 X 1710	TATA spare parts
206042810115	ASSY.BR.TUBE CR-50100	TATA spare parts

206042810152	CONN LINE 10 X 1070 LG	TATA spare parts
206042810153	CONN LINE 10 X 1740 LG	TATA spare parts
206042810154	CONN LINE 10 X 950 LG	TATA spare parts
206042810155	CONN LINE 10 X 1260 LG	TATA spare parts
206042810173	BRAKE TUBE 6D	TATA spare parts
206042810174	BRAKE TUBE 6 X0.7 X 1110	TATA spare parts
206042810175	BRAKE TUBE 6 X0.7 X 4370	TATA spare parts
206042820101	CONNECTING LINE	TATA spare parts
206042820102	CONNECTING LINE	TATA spare parts
206042900166	PIPE 455MM LONG	TATA spare parts
206042900167	PIPE(320MM)RH BR ACTU2516	TATA spare parts
206042903320	BRACKET	TATA spare parts
206042903328	BRACKET BS6	TATA spare parts
206042903338	BRACKET	TATA spare parts
206042903339	BRACKET	TATA spare parts
206042903350	BRACKET	TATA spare parts
206042903354	BRACKET BS6	TATA spare parts
206042903356	BRACKET ON AIR LINE	TATA spare parts
206042903357	BRACKET DAMPING AIR LINIS	TATA spare parts
206042903359	BRACKET	TATA spare parts
206042903364	BRACKET	TATA spare parts
206042903365	BRACKET	TATA spare parts
206042903369	BRACKET(FOR AIR LINE ON LG MEMBER LH)	TATA spare parts
206042903376	BRACKET	TATA spare parts
206042903379	BRACKET	TATA spare parts
206042903380	BRACKET TRAILER CRTL VALVE	TATA spare parts
206042903381	BRACKET BS6	TATA spare parts
206042903383	BRACKET (BELOW REAR SPRG.CM) BS6	TATA spare parts
206042906809	ELBOW	TATA spare parts
206042906811	ELBOW	TATA spare parts
206042906812	ELBOW	TATA spare parts
206042906816	ELBOW	TATA spare parts
206042906817	T-CONNECTOR(ON SYSTEM PROT. VALVE)	TATA spare parts
206042906818	T CONNECTOR	TATA spare parts
206042906904	PIPE AIR 15 X 1085	TATA spare parts
206042906906	PIPE AIR 15 X 1.5 X 840	TATA spare parts
206042906909	PIPE FROM SOCKET TO SOCKET	TATA spare parts
206042906972	PIPE AIR 15 X 1.5 X 860	TATA spare parts
206042906974	PIPE AIR 6 X 0.7	TATA spare parts
206042906985	PIPE AIR 6 X 0.7	TATA spare parts
206042909201	WASHER	TATA spare parts
206042910121	PIPE AIR GAUGE	TATA spare parts
206042910193	BRAKE TUBE 6 X0.7 X 1450	TATA spare parts
206042910196	BRAKE TUBE	TATA spare parts
206042910199	BRAKE TUBE	TATA spare parts
206042916919	PIPE AIR 15 X 1.5 X 2500	TATA spare parts
206042916920	PIPE AIR 6 X 0.7	TATA spare parts

206042920103	BRAKE TUBE RH TMC-F W/C	TATA spare parts
206042920131	ASSY AIR PRESSURE PIPE	TATA spare parts
206042920145	BRAKE TUBE RH	TATA spare parts
206042920146	BRAKE TUBE LH	TATA spare parts
206042920149	BRAKE TUBE	TATA spare parts
206042920151	BRAKE TUBE	TATA spare parts
206042920183	BRAKE TUBE LHD CR19536	TATA spare parts
206042930113	PIPE AIR 15D LPO1313	TATA spare parts
206042930115	PIPE AIR 6D LPO1210M	TATA spare parts
206042930125	PIPE AIR	TATA spare parts
206042930186	PIPE AIR 6D	TATA spare parts
206042950144	PIPE AIR	TATA spare parts
206042950168	PIPE AIR	TATA spare parts
206042950170	PIPE AIR	TATA spare parts
206042950174	PIPE AIR 15 X 1650	TATA spare parts
206042960156	PIPE AIR 15 X 1.5 X 1250	TATA spare parts
206042960157	PIPE AIR 12 X 1 X 420	TATA spare parts
206042960158	PIPE AIR 12 X 1 X 1680	TATA spare parts
206042960159	PIPE AIR 12 X 1 X 1300	TATA spare parts
206042960160	ASSY.AIR PIPE 12 DIA X 1X14	TATA spare parts
206042960161	ASSY.AIR PIPE 12 DIA X 1X19	TATA spare parts
206042960162	PIPE AIR 15 X 1.5 X 1560	TATA spare parts
206042960167	ASSY PIPE 12DIA X 1390 LG	TATA spare parts
206042960168	ASSY PIPE 12DIA X 2120 LG	TATA spare parts
206042970104	ASSY AIR PIPE	TATA spare parts
206042970105	ASSY AIR PIPE	TATA spare parts
206042970155	PIPE ASSY 12D X 2370LG	TATA spare parts
206042970156	PIPE ASSY 12D X 2370LG	TATA spare parts
206042970157	ASSY.PIPE 12X1325 LG.	TATA spare parts
206042970165	PIPE AIR 12 X 1 X 3210	TATA spare parts
206042970166	PIPE AIR 12 X 1 X 455	TATA spare parts
206042970167	PIPE AIR 12 X 1 X 320	TATA spare parts
206042970169	PIPE AIR 12 X 1 X 890	TATA spare parts
206042970170	ASSY PIPE 12 OD X 1760 LG	TATA spare parts
206042970179	PIPE AIR 12 X 1590	TATA spare parts
206042970180	PIPE AIR 12 X 1610	TATA spare parts
206042970186	PIPE 12 X 2060	TATA spare parts
206042970187	ASSY PIPE 12 DIA X 2820LG	TATA spare parts
206042970191	PIPE 15 X 1500	TATA spare parts
206042970199	PIPE AIR 15 X 960	TATA spare parts
206042980101	TUBE 12D X 2355 LONG	TATA spare parts
206042980102	PIPE AIR 12 X 1 X 2070	TATA spare parts
206042980109	PIPE ASSY 12D X 1790LG	TATA spare parts
206042980110	PIPE ASSY 12D X 2100LG	TATA spare parts
206042980118	ASSY PIPE 12 OD X 4050 LG	TATA spare parts
206042980120	PIPE ASSY 12D X 2270LG	TATA spare parts
206042980138	ASSY PIPE 12 X 3035 LONG	TATA spare parts

206042980184	ASSY PIPE 12 OD X 1800 L1	TATA spare parts
206042980189	PIPE ASSY 12D X 1200LG	TATA spare parts
206042990111	ASSY PIPE 12 X 4700	TATA spare parts
206042990113	ASSY PIPE 12 X 1560	TATA spare parts
206042990114	ASSY PIPE 12DIA X1820 LG	TATA spare parts
206042990142	PIPE 15 X 1630	TATA spare parts
206042990143	ASY PIPE 15X985 AIR FILTER	TATA spare parts
206042990144	PIPE ASSY 12D X2080 LG	TATA spare parts
206042990195	PIPE ASSY 12D X 1950LG	TATA spare parts
206042990196	PIPE ASSY 12D X 2450LG	TATA spare parts
206043000101	KIT REP MASTER CYL	TATA spare parts
206043018301	PISTON MASTER CYLINDER	TATA spare parts
206043100101	KIT REP MASTER CYL	TATA spare parts
206043100102	KIT REP MASTER CYL	TATA spare parts
206043100105	UNLOADER VALVE	TATA spare parts
206043100106	LINER TYPE SERVO	TATA spare parts
206043100107	ASSY BRAKE MASTER CYL 38.1D BRAKES	TATA spare parts
206043200105	ASSY TUBE 6 DIA X 1205 LG	TATA spare parts
206043210152	PIPE AIR 6 X 0.7 X 1005	TATA spare parts
206043210163	ASY.TUBE 6DIA X0.7X76	TATA spare parts
206043220132	TUBE 6 X 1100	TATA spare parts
206043220192	PIPE 6 X 0.7 X 1930	TATA spare parts
206043230140	ASSY PIPE 15DIA X 690 LG	TATA spare parts
206043230141	ASSY PIPE 15 DIA X 185 LG	TATA spare parts
206044100124	ASSY PIPE	TATA spare parts
206044100126	TUBE ASSY	TATA spare parts
206044100127	TUBE 18X1.5X240 LONG	TATA spare parts
206044100128	TUBE 15X1.5X860 LONG	TATA spare parts
206044100129	TUBE ASSY 15X1.5X1500 LG	TATA spare parts
206044100130	TUBE ASSY 15X1.5X870 LG	TATA spare parts
206044100133	TUBE ASSY	TATA spare parts
206044100134	TUBE ASSY	TATA spare parts
206044100142	TUBE ASSY	TATA spare parts
206044100143	TUBE ASSY	TATA spare parts
206044100149	PIPE AIR	TATA spare parts
206044100162	TUBE	TATA spare parts
206044100177	TUBE 18D X 1.5 X 1835	TATA spare parts
206044100178	TUBE 18D X 1.5 X 495	TATA spare parts
206044100179	PLUG ASSY	TATA spare parts
206044100185	TUBE 15X1.5X220 LONG	TATA spare parts
206044100197	ASSY.PIPE 15X1.5X845 LG.	TATA spare parts
206044103308	BRACKET	TATA spare parts
206044105802	RUB HOSE 3/4X380 LONG	TATA spare parts
206044105803	LP HOSE	TATA spare parts
206044105806	RUB HOSE 3/4X300 LONG	TATA spare parts
206044105807	RUB HOSE 3/4X480 LONG	TATA spare parts
206044106801	SPECIAL BANJO	TATA spare parts

206044106802	BANJO BOLT	TATA spare parts
206044106803	BANJO BODY	TATA spare parts
206044106807	SPECIAL BANJO	TATA spare parts
206044110124	ASSY TUBE-15 O.D. X 825 LG.	TATA spare parts
206044110128	TUBE 18X1.5X255 LONG	TATA spare parts
206044110129	TUBE 18X1.5X985 LONG	TATA spare parts
206044110130	TUBE 18X1.5X300 LONG	TATA spare parts
206044110132	TUBE 15X1.5X335 LONG	TATA spare parts
206044110133	PIPE ASSY	TATA spare parts
206044110134	PIPE ASSY	TATA spare parts
206044400103	BRACKET HYD TANK MTG	TATA spare parts
206046000112	DRAG LINK ASSY	TATA spare parts
206046000117	DRAG LINK ASSY LHD	TATA spare parts
206046000121	DRAG LINK ASSY	TATA spare parts
206046013001	BEARING ROLLER ANG CONTAC	TATA spare parts
206046016501	CASTLE NUT M12 X 1.5	TATA spare parts
206046100110	SUPPORT STRG COLUMN	TATA spare parts
206046100114	SUPPORT STRG COLUMN	TATA spare parts
206046103702	BRACKET STEERING	TATA spare parts
206046106501	ADJUSTING NUT	TATA spare parts
206046207907	STRG SPINDLE BOTTOM	TATA spare parts
206046207909	STRG SPINDLE TOP	TATA spare parts
206046207910	STRG. SPINDLE-BOTTOM	TATA spare parts
206046209202	LOCKING WASHER	TATA spare parts
206046209203	LOCKING WASHER	TATA spare parts
206046209204	LOCK RING	TATA spare parts
206046209205	LOCK RING	TATA spare parts
206046209206	LOCK RING	TATA spare parts
206046214301	CIRCLIP	TATA spare parts
206046219902	STEEL BALL (7.006 DIA.) FOR STEERING BS6	TATA spare parts
206047100110	FUEL TANK 200 LTR RH	TATA spare parts
206047100117	ASSY.FUEL TANK COMPLETE L	TATA spare parts
206047100118	FUEL TANK RH 160 LTR	TATA spare parts
206047100123	ASSY.FUEL TANK COMP.(160L	TATA spare parts
206047100124	ASSY FUEL TANK COMP.(160L	TATA spare parts
206047100133	ASSY SUPPORT W STRAP COMPL	TATA spare parts
206047600113	FUEL RETURN LINE	TATA spare parts
206047600115	FUEL RETURN LINE	TATA spare parts
206047600119	PIPE STEEL	TATA spare parts
206047600124	FUEL LINE	TATA spare parts
206047600125	FUEL RETURN LINE 10 X2220	TATA spare parts
206047600126	FUEL LINE	TATA spare parts
206047603301	BRACKET	TATA spare parts
206047609201	WASHER	TATA spare parts
206047610105	FUEL LINE TANK/FEED PUMP	TATA spare parts
206047610106	FUEL OVERFLOW RETURN LINE	TATA spare parts
206047610174	PIPE 6D X 3590	TATA spare parts



206047610192	ASSY FUEL LINE	TATA spare parts
206047610193	FUEL LINE 10 D X 3500 LG	TATA spare parts
206047620170	ASSY. TUBE 10 O.D. X 1520 LG.	TATA spare parts
206047620171	ASSY. TUBE 10 O.D. X 2650 LG.	TATA spare parts
206049015301	GASKET EXHAUST MANIFOLD	TATA spare parts
206049203318	BRACKET	TATA spare parts
206050000112	RADIATOR FRAME 909	TATA spare parts
206050005805	RUBBER HOSE	TATA spare parts
206050008206	PLATE LHS 1210SD/42	TATA spare parts
206050008207	PLATE RHS 1210SD/42	TATA spare parts
206050008217	SUPPORT	TATA spare parts
206052050102	BUMPER ASSY	TATA spare parts
206052070101	ASSY BRACKET(BONNET STAY)	TATA spare parts
206052400113	BRACKET LH	TATA spare parts
206052400173	PROT GRIL HEAD LAMP	TATA spare parts
206052400187	COWL HALF LH W/FRAME LHD	TATA spare parts
206052400188	COWL HALF RH LP01313	TATA spare parts
206052406501	U SPIRE NUT	TATA spare parts
20605241019260	ASY.FRAME FACE LH(W/O.SUPPORT DOOR POST)	TATA spare parts
20605241019360	ASY.FRAME FACE RH(W/O.SUPPORT DOOR POST)	TATA spare parts
206052418284	BRACKET LH (FRONT POST)	TATA spare parts
206052418285	BRACKET RH	TATA spare parts
206052420108	ASSY.LID ELECTRICAL BOX	TATA spare parts
206052700106	STAY ROD ENG HOOD	TATA spare parts
206054010163	BATTERY CABLE +VE	TATA spare parts
206054010172	ASSY MAIN CABLE SET LP/LP	TATA spare parts
206054010179	MAIN CABLE SET LP RHD	TATA spare parts
206054030127	MAIN CABLE SET RHD	TATA spare parts
206054030128	CABLE SET FRT TO TAIL	TATA spare parts
206054050801	STARTER SWITCH	TATA spare parts
206054053501	KEY PAIR	TATA spare parts
206054060143	MAIN CABLE SET LP RHD	TATA spare parts
206054060179	MAIN CABLE SET RHD	TATA spare parts
206054060180	CABLE SET PANEL LIGHT	TATA spare parts
206054060183	MAIN CABLE SET	TATA spare parts
206054109915	BATTERY 12V-180AH-HARD RUBBER CASING	TATA spare parts
206054109933	COVER FOR BATTERY	TATA spare parts
206054110126	PIPE OIL PRESSURE GAUGE	TATA spare parts
206054110127	PIPE OIL PRESSURE GAUGE	TATA spare parts
206054200108	OIL PR PIPE LHD	TATA spare parts
206054209901	HORN 12V	TATA spare parts
206054209902	BEEPER UNIT-12V	TATA spare parts
206054209903	BEEPER UNIT	TATA spare parts
206054400109	TAIL LAMP LH	TATA spare parts
206054400110	TAIL LAMP RH	TATA spare parts
206054400111	REFLECTOR SAFETY	TATA spare parts
206054400115	BLINKER LAMP LH	TATA spare parts

206054400116	BLINKER LAMP RH	TATA spare parts
206054400118	HEAD LAMP LH	TATA spare parts
206054400125	HEAD LAMP RH	TATA spare parts
206054400130	TAIL LAMP LH ROUND	TATA spare parts
206054400131	TAIL LAMP RH ROUND	TATA spare parts
206054400132	HEAD LAMP LH	TATA spare parts
206054400133	HEAD LAMP RH	TATA spare parts
206054400137	KIT TOP MARKER LAMP	TATA spare parts
206054400138	TOP MARKER LAMP	TATA spare parts
206054500101	COMBI SWITCH	TATA spare parts
206054500108	HAZARD WARNING SWITCH	TATA spare parts
206054500109	HAZARD WARNING SWITCH	TATA spare parts
206054500110	STARTER PUSH BUTTON	TATA spare parts
206054500113	LOW AIR PR IND SWITCH	TATA spare parts
206054500114	SWITCH REVERSE LIGHT	TATA spare parts
206054502401	COMBI SWITCH	TATA spare parts
206054509902	KEY MAIN LINE SWITCH	TATA spare parts
206054600101	MAIN CABLE SET	TATA spare parts
206054600176	MAIN CABLE SET	TATA spare parts
206054608201	CLAMP	TATA spare parts
206058109501	DOUBLE ENDED BOX SPANNER SW17/SW19	TATA spare parts
206058300104	HYDRAULIC JACK 8T	TATA spare parts
206058300106	HYD JACK 12 TON WITH LOCK NUT	TATA spare parts
206058500102	ASSY TOOL BOX	TATA spare parts
206058900101	WHEEL SPANNER 27-30	TATA spare parts
206059900101	ASSY TOWING HOOK NO9 MKII	TATA spare parts
206059903201	EYE BOLT	TATA spare parts
206059906501	NUT	TATA spare parts
206059906701	STOP PIN	TATA spare parts
206059906702	PIN FOR EYE BOLT	TATA spare parts
206059906703	PIN FOR CATCH	TATA spare parts
206059908701	SPRING FOR CATCH	TATA spare parts
206059909201	WASHER PLATE SPRING CLIP	TATA spare parts
206060000122	CAB KIT	TATA spare parts
206060000127	COWL COMPLT RHD	TATA spare parts
206060010108	ANTI SAGGING BAR	TATA spare parts
206060100142	ASY.COWL WELDED COMP.RHD	TATA spare parts
206062010155	LP FACE LH W/FRAME	TATA spare parts
20606201015535	ASSY. FACE COMP.W/FRAME LH CED+SLT BS1-4	TATA spare parts
206062010156	LP FACE RH W/FRAME	TATA spare parts
20606201015635	ASSY. FACE COMP.W/FRAME RH CED+SLT BS1-4	TATA spare parts
206062018202	OUTER COVER 1210/1510	TATA spare parts
206062018203	REINFORCEMENT FRONT POST BS6	TATA spare parts
206068090110	INSTRUMENT PANNEL	TATA spare parts
206072102301	DOOR GLASS LH 1613	TATA spare parts
206072306302	SEALING RUBBER MOULD LH	TATA spare parts
206072306303	SEALING RUBBER MOULD RH	TATA spare parts

206072306304	SEALING RUBBER	TATA spare parts
206075100103	CENTRE FLAP COMPLT	TATA spare parts
206075100106	CENTRE FLAP COMPLT	TATA spare parts
206075100107	KNOB CENTRE FLAP	TATA spare parts
206076603801	DOOR HANDLE OUT W/KEY	TATA spare parts
206076603802	DOOR HANDLE OUTER	TATA spare parts
206076603803	INNER HANDLE	TATA spare parts
206076603804	HANDLE WINDOW REG W/CUP	TATA spare parts
206081508201	RETAINING PLATE	TATA spare parts
206082400101	LINK ROD ASSY	TATA spare parts
206082400101AE	LINK RODLPA 1415/	TATA spare parts
206082400103	LINK FROM WIPER MOTOR	TATA spare parts
206082400103AE	LINK FROM WIPER MOTOR 1415	TATA spare parts
206082400105	ASSY WIPER ARM RHD	TATA spare parts
206082400106	ASSY WIPER ARM	TATA spare parts
206082406001	LINK ROD 224 LONG	TATA spare parts
206082406003	LINK ROD 1004LG.	TATA spare parts
206082500101	INTERIOR LAMP	TATA spare parts
206082602201	GASKET	TATA spare parts
206088070105	ENGINE HOOD RHD	TATA spare parts
206088070106	ENGINE HOOD LHD	TATA spare parts
206088500106	BUMPER COMP	TATA spare parts
206088500109	ASSY BUMPER	TATA spare parts
206088500110	BUMPER LPO LHD	TATA spare parts
206088500112	BUMPER COMP	TATA spare parts
206088500112C0	ASSY BUMPER WITH REFLECTOR - BLACK	TATA spare parts
206088500112C1	ASSY BUMPER WITH REFLECTOR -RUBY RED	TATA spare parts
206088500112C2	ASSY BUMPER WITH REFLECTOR -GOLDEN BROW	TATA spare parts
206088500112C3	ASSY BUMPER WITH REFLECTOR -ARMY COLOUR	TATA spare parts
206088500112C4	ASSY BUMPER WITH REFLECTOR - DEEP GREEN	TATA spare parts
206088500113	ASSY.BUMPER	TATA spare parts
206089107701	PACKING REAR	TATA spare parts
206089107702	PACKING FRONT	TATA spare parts
206098408701	CLAMP	TATA spare parts
206098709903	RUBBER PROFILE-T/W	TATA spare parts
206099700101	DECARBONSING GASKET KIT	TATA spare parts
206099700102	KIT GASKETS OIL SUMP	TATA spare parts
206099706701	CYLINDRICAL PIN 8M6 X 16	TATA spare parts
206244100121	TUBE ASSY	TATA spare parts
206244100122	BENT TUBE	TATA spare parts
206244100123	BENT TUBE	TATA spare parts
206244100125	BENT TUBE	TATA spare parts
206244100126	TUBE ASSY	TATA spare parts
206244100128	BENT TUBE	TATA spare parts
206244100129	BENT TUBE	TATA spare parts
206244100136	PTO-PUMP ASSY	TATA spare parts
206244100157	HYDRAULIC TIPPING KIT COMPLETE	TATA spare parts

206244100167	ASSY.TUBE.	TATA spare parts
206244100168	ASSY.TUBE.	TATA spare parts
206244100169	ASSY.TUBE.	TATA spare parts
206244100170	ASSY.TUBE.	TATA spare parts
206244100171	ASSY.TUBE.	TATA spare parts
206244100174	ASSY.TUBE WITH CRIMPED HOSE.	TATA spare parts
206244100175	ASSY.TUBE	TATA spare parts
206244100176	ASSY.TUBE	TATA spare parts
206244100177	ASSY.TUBE	TATA spare parts
206244100178	ASSY.TUBE	TATA spare parts
206244100179	KIT FOR HYDRAULIC TIPPING.	TATA spare parts
206244105802	HOSE HIGH PRESSURE 1	TATA spare parts
206244105804	HOSE LP (TIPPER/COAL CARR	TATA spare parts
206244109961	KIT HYD TIPPING	TATA spare parts
206244109964	MANUAL VALVE ROTARY	TATA spare parts
206244119911	HYD. CYL. WITH FIXING PLATE	TATA spare parts
206301150101	ELBOW AIR INTAKE	TATA spare parts
206301153802	ELBOW AIR INTAKE	TATA spare parts
206301173301	BRACKET DIPSTICK TUBE	TATA spare parts
206303137006	PULLEY LPO1210M	TATA spare parts
206309110103	FUEL PIPE FEEDPUMP-FILTER	TATA spare parts
206309130110	BRACKET PRECLEANER	TATA spare parts
206309130111	PIPE PRECLEANER	TATA spare parts
206309135801	RUBBER HOSE	TATA spare parts
206309136302	RUBBER SLEEVE	TATA spare parts
206325600102	ASSY RELEASE FORK W BALL PIN CR19632	TATA spare parts
206325600104	ASSY.CL.REL.BRG.W SLEEVE	TATA spare parts
206325605101	CLUTCH RELEASE FORK	TATA spare parts
206326000101	ASSY.BRACKET	TATA spare parts
206328010001	ASSY. AUX GEAR BOX 8 HCF BS2/3	TATA spare parts
206328010002	AUX GEAR BOX 1210SD	TATA spare parts
206328010101	ASSY AGB WITH OIL	TATA spare parts
206328250101	COUPLING FLANGE	TATA spare parts
206328255101	COUPLING FLANGE	TATA spare parts
206333000101	ASY FRONT AXLE COMP CR195	TATA spare parts
206333104202	U CLAMP FR ANTIROLL BAR	TATA spare parts
206333500101	COUPLING FLANGE	TATA spare parts
206333500110	COUPLING FLANGE 1210SD	TATA spare parts
206335000101	REAR AXLE ASSY RA107SALIS	TATA spare parts
206341100112	P/SHAFT AGB - RA 90X3X878	TATA spare parts
206341100114	P/SHAFT FRONT W/CEN BRG	TATA spare parts
206341100117	P/SHAFT FRONT COMP	TATA spare parts
206341100128	P/SHAFT FRONT 76X4X1247	TATA spare parts
206341100144	PROP SHAFT FR 76X4X583	TATA spare parts
206341120103	ASSY PROP SHAFT REAR COMPL 90 DIA 1046L	TATA spare parts
206342800101	BRAKE TUBE LH RHD	TATA spare parts
206346000112	ASSY. DRAG LINK BS1/2/3/4	TATA spare parts

206346000113	ASSY DRAG LINK	TATA spare parts
206346100108	BKT STRG G/BOX MTG	TATA spare parts
206346207901	STRG SPINDLE BOTTOM	TATA spare parts
206346305104	PITMAN ARM	TATA spare parts
206346305105	PITMAN ARM	TATA spare parts
206354110107	PIPE OIL PRESSURE	TATA spare parts
206368098201	INSTRUMENT PANEL	TATA spare parts
206429100108	ASSY SUPPORT COMP-BRAKE	TATA spare parts
206429100110	ASSY BRAKE PEDAL COMP.	TATA spare parts
206431000101	ASSY.FRAME COMP.CR-19678	TATA spare parts
206431000102	FRAME LPT 909 TILT CAB	TATA spare parts
206431000104	ASSY FRAME	TATA spare parts
206431200101	CROSS MEMBER FRT W/T HOOK	TATA spare parts
206431200104	BRACKET RH-ENGINE MTG X MEMBER FRONT	TATA spare parts
206431200105	BRACKET LH-ENGINE MTG X MEMBER FRONT	TATA spare parts
206431200106	CROSS MEMBER FRONT	TATA spare parts
206431207102	SUPPORT RH	TATA spare parts
206431207108	BRACKET RH	TATA spare parts
206431207109	BRACKET LH	TATA spare parts
206431208201	CROSS MEMBER 2ND	TATA spare parts
206431208202	CROSS MEMBER(FRONT) LPT 909	TATA spare parts
206431208212	SPACER BS6	TATA spare parts
206431406701	COUPLING PIN	TATA spare parts
206433200101	ASSY STUB AXLE STD LPT 1109	TATA spare parts
206433205101	STUB AXLE	TATA spare parts
206435100105	ASSY RR AXLE HSG W/TUBE	TATA spare parts
206440300106	ASSY SPARE WHEEL CARRIER LP 909	TATA spare parts
206441110101	PROP SHAFT W/CEN BRG	TATA spare parts
206442100104	ASSY BRAKE DRUM FRT RH	TATA spare parts
206442100105	ASSY BRAKE DRUM FRT LH	TATA spare parts
206442103701	BRAKE DRUM BS2/3/4	TATA spare parts
206442106701	HEX BOLT-W/T COLLAR-M16X1.5X127 BS6-PH2	TATA spare parts
206442118201	DUST COVER BOTTOM	TATA spare parts
206442118202	DUST COVER TOP	TATA spare parts
206442300105	ASSY DRUM BRAKR RR RH	TATA spare parts
206442300106	ASSY DRUM BRAKE RR LH	TATA spare parts
206442318201	DUST COVER BOTTOM	TATA spare parts
206442318202	DUST COVER TOP	TATA spare parts
206442700111	PIPE ASSY 6D	TATA spare parts
206442700112	PIPE 6 X 2160	TATA spare parts
206442700113	PIPE 6 X 780	TATA spare parts
206442700114	PIPE ASSY 6D X 160	TATA spare parts
206442700116	PIPE 6 X 725	TATA spare parts
206442700117	PIPE ASSY 12 OD	TATA spare parts
206442700118	ASSY PIPE 12 OD X 1100 LG	TATA spare parts
206442700119	ASSY PIPE12 OD 1875	TATA spare parts
206442700120	ASSY PIPE 12 OD 118	TATA spare parts

206442700138	ASSY PIPE 15 X 1390	TATA spare parts
206442800116	CONNECTING LINE ASSY	TATA spare parts
206442800117	CONNECTING LINE ASSY	TATA spare parts
206442800118	PIPE ASSY 10 OD	TATA spare parts
206442800120	ASSY PIPE 6 MM OD	TATA spare parts
206442900138	PIPE ASSY 15 OD	TATA spare parts
206442900139	PIPE ASSY 15 OD	TATA spare parts
206442900142	ASSY PIPE	TATA spare parts
206442900143	ASSY PIPE 12 OD	TATA spare parts
206442900144	ASSY PIPE 12 DIA X 865 LG	TATA spare parts
206442900145	ASSY PIPE 12 DIA X 850 LG	TATA spare parts
206442900146	ASSY PIPE 12 OD	TATA spare parts
206442900147	ASSY PIPE 12 OD	TATA spare parts
206442900148	ASSY PIPE 12 DIA X 735 LG	TATA spare parts
206442900149	ASSY PIPE 12 DIA X 750 LG	TATA spare parts
206442900150	ASSY PIPE 12 O.D.	TATA spare parts
206442900151	PIPE ASSY	TATA spare parts
206442900152	ASSY PIPE 12 OD X 1330 LG	TATA spare parts
206442900158	ASSY PIPE 12 DIA X 230 LG	TATA spare parts
206442900159	ASSY PIPE 12 OD	TATA spare parts
206442900160	PIPE ASSY 120DX350LG	TATA spare parts
206442900161	ASSY.PIPE 12 DIA.X 1565 LPT 909	TATA spare parts
206442900164	ASSY PIPE 12 OD 735	TATA spare parts
206442900166	PIPE 12 X 315	TATA spare parts
206442900171	ASSY PIPE	TATA spare parts
206442900172	ASSY.PIPE 6DIA.X 1155LG.	TATA spare parts
206442900174	PIPE ASSY	TATA spare parts
206442900176	ASSY PIPE 12 DIA.	TATA spare parts
206442900190	ASSY NYLON PIPE SET LPT909	TATA spare parts
206442903303	BRACKET LH(BRAKE HOSE)	TATA spare parts
206442903304	BRACKET RH(BRAKE HOSE)	TATA spare parts
206442903306	BRACKET	TATA spare parts
206442903317	BRACKET	TATA spare parts
206442950101	13/8 HOSE ASSY.	TATA spare parts
206443506801	ELBOW	TATA spare parts
206446200106	ASSY BRKT FOR STRG GB MTG	TATA spare parts
206446305101	PITMAN ARM	TATA spare parts
206446600101	DRAG LINK ASSY	TATA spare parts
206447600113	FUEL FEED LINE 10 OD	TATA spare parts
206447600114	ASSY FUEL SUCTION LINE	TATA spare parts
206447600115	PIPE FUEL RETURN LINE	TATA spare parts
206447600116	PIPE 10D X 1150	TATA spare parts
206447600121	PIPE 10D	TATA spare parts
206447600171	ASSY FUEL SUCTION LINE	TATA spare parts
206449100101	SILENCER ASSY	TATA spare parts
206449200105	EXHAUST PIPE FRONT	TATA spare parts
206449200106	ASSY BRACKET EXHAUST	TATA spare parts

206449200107	ASSY BRACKET(FRONT) RH	TATA spare parts
206449200113	ASSY BRACKET	TATA spare parts
206449200115	ASSY SHAFT THROTTLE VALVE	TATA spare parts
206449200117	EXHAUST PIPE FRONT	TATA spare parts
206449206902	EXHAUST PIPE-TAIL	TATA spare parts
206454200101	AIR CYLINDER W/MAGN VALVE	TATA spare parts
206454209902	SPEEDOMETER 1:1.05	TATA spare parts
206454209904	SPEEDOMETER	TATA spare parts
206454400103	ASSY LAMP W/IND.	TATA spare parts
206454504601	ELECTRONIC FLASHER KIT	TATA spare parts
206454504901	RELAY 12V	TATA spare parts
206454504901AE	RELAY-12V LPA 1415/	TATA spare parts
206454600109	MAIN CABLE SET	TATA spare parts
206454820101	MAIN CABLE SET RHD	TATA spare parts
206454820102	CABLE SET FRT TO TAIL	TATA spare parts
206454820103	ASSY CABLE SET	TATA spare parts
206460000101	ASSY CAB COMPLETE LP/LPT909 TILT RHD	TATA spare parts
206460000102	CAB BARE RHD	TATA spare parts
206460100106	ASSY CROSSMEMBER RHD(DASH BOARD-MTG)	TATA spare parts
206460108202	CROSS MEMBER DASHBOARD MTG BS6-PH2	TATA spare parts
206481900101	ASSY. MASCOT 909.	TATA spare parts
206481906302	MASCOT 909	TATA spare parts
206488500101	ASSY BUMPER COMPLETE	TATA spare parts
206488500102	ASSY SUPPORT LH BUMPER MOUNTING	TATA spare parts
206488500103	ASSY SUPPORT RH(BUMPER MTG)	TATA spare parts
206488508201	BRACKET LH	TATA spare parts
206488508202	BRACKET RH	TATA spare parts
206488508203	SUPPORT RH-BUMPER MTG.	TATA spare parts
206488508204	SUPPORT LH-BUMPER MTG	TATA spare parts
206489100101	MTG BKT LH CHASSIS SIDE	TATA spare parts
206489100102	MTG BKT RH CHASSIS SIDE	TATA spare parts
206489100106	MTG BKT BOTTOM FR RH	TATA spare parts
206489100107	MTG BKT BOTTOM FR LH	TATA spare parts
206489100109	ASSY STAY COMPLETE	TATA spare parts
206489100110	ASSY SUPPORT BOTTOM LH	TATA spare parts
206489100111	ASSY SUPPORT BOTTOM RH	TATA spare parts
206489100112	ASSY MOUNTING BRACKET FRONT LH	TATA spare parts
206489100113	ASSY.MTG.BKT.FRONT RH	TATA spare parts
206489100114	ASSY MOUNTING BRACKET REAR(CHASSIS SIDE)	TATA spare parts
206489100118	CROSS TUBE TORSION BAR BS2/3/4	TATA spare parts
206489100125	ASSY. SECONDARY LOCK (LOCKING MECH).	TATA spare parts
206489100127	ASSY. MTG. BKT.L.H. CHASIS SIDE.FORCAB	TATA spare parts
206489100128	ASSY. MTG. BKT. R.H.-CHASIS SIDE	TATA spare parts
206489100129	ASSY. CAM (CAB LOCKING MECHANISM). BS6	TATA spare parts
206489100130	ASSY. HANDLE MTG.(CAB LOCKING MECH.).	TATA spare parts
206489100132	ASSY. LEVER(LOCKING MECH.) BS6	TATA spare parts
206489100133	ASSY. SUPPORT BOTTOM L.H. LPT1109	TATA spare parts

206489100134	SUPPORT BOTTOM R.H.(MUDGUARD) LPTA713TC	TATA spare parts
206489100138	ASSY. HANDLE MTG BKT.COMP. BS6	TATA spare parts
206489106301	MUD GUARD LH	TATA spare parts
206489106302	MUD GUARD RH	TATA spare parts
206489106303	MUD FLAP FRONT INNER LH. LPTA 713 TC	TATA spare parts
206489106304	MUD FLAP FRONT INNER RH. LPTA 713 TC	TATA spare parts
206489106307	MUDGUARD LH LPT1109	TATA spare parts
206489106308	MUDGUARD R.H. LPT1109	TATA spare parts
206494000102	ASSY CO-DRIVERS SEAT	TATA spare parts
206654200101	ASSY. BEEPER UNIT WITH BRACKET	TATA spare parts
206654209901	SPEEDOMETER LP 909 (1:0.89) 37/7 CWP	TATA spare parts
206654209902	BEEPER ALARM UNIT 12V	TATA spare parts
206654504601	ELECTRONIC FLASHER KIT-12 V	TATA spare parts
206654504602	ELECTRONIC FLASHER KIT-12 V	TATA spare parts
206724105101	FRT.ENG.MTG.ARM(FORGED)-4 PT.MTG.RH	TATA spare parts
206724105102	FRT.ENG.MTG.ARM(FORGED)-4 PT.MTG.LH	TATA spare parts
206724200102	ENGINE MTG BRKT RR	TATA spare parts
206724200103	ASSY.ENG.MTG.BKT.REAR(RH) SE/SK 1613TC	TATA spare parts
206724200104	ASSY.ENG.MTG.BKT.REAR(LH) SE/SK 1613TC	TATA spare parts
206724200105	ASSY ENGINE MTG BKT (REAR) LH	TATA spare parts
206724200106	ASSY ENGINE MTG BKT (REAR) RH	TATA spare parts
206724200110	ASSY ENG MTG BKT REAR LH WT. HD10 START	TATA spare parts
206724200112	ASSY. ENG. MTG. BKT. REAR (RH)	TATA spare parts
206724200113	ASSY ENG MTG BKT REAR RH	TATA spare parts
206724200114	ASSY ENG MTG BKT REAR LH	TATA spare parts
206726000101	GBS 40 SK 1613 TC	TATA spare parts
206726000103	ASSY GBS40 5/7.51 8BCF SE1613TC EII	TATA spare parts
206726000106	ASSY.GBS40 WITH PTO PROV(PN SHIFT)SK/EII	TATA spare parts
206726400103	ASSY PULL ROD	TATA spare parts
206726400104	ASSY PTO LEVER SK1613TC	TATA spare parts
206726407501	RUBBER BELLOW-PTO LEVER SE 1613TC	TATA spare parts
206726407503	RUBBER BELLOW PTO	TATA spare parts
206726408201	COVER PLATE (RUBBER BELLOW-PTO LEVER SE	TATA spare parts
206726707501	RUBBER BELLOW (GEAR SHIFT LEVER)	TATA spare parts
206726808201	RING (GEAR SHIFT BELLOW)	TATA spare parts
206729100116	ASSY CLUTCH PEDAL LEVER COMPL. SE 1613TC	TATA spare parts
206729100120	ASSY SLAVE CYLINDER 38.1 MM DIA	TATA spare parts
206729100120AE	ASSY. SLAVE CYLINDER 713	TATA spare parts
206729100121	CLUTCH MASTER CYL. 25.4 DIA. BS2/3	TATA spare parts
206729100128	ASSY CLUTCH BOOSTER (DIA-76.2)	TATA spare parts
206729100133	ASSY CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
206729106001	PUSH ROD SE 1613TC	TATA spare parts
206729106002	PUSH ROD	TATA spare parts
206729107501	GROMMET	TATA spare parts
206729108210	STOPPER (CLUTCH PEDAL)	TATA spare parts
206729200106	ASSY PUSH ROD WITH FORK	TATA spare parts
206729206001	PUSH ROD ( MASTER CYLINDER )	TATA spare parts



206729300105	ASSY CONNECTING LINE-CLUTCH	TATA spare parts
206729300106	ASSY TUBE 1540 LONG	TATA spare parts
206729300110	ASSY.TUBE (1320 LG)	TATA spare parts
206729300113	ASSY.TUBE O.D 6X1350 LG.	TATA spare parts
206729308203	BRACKET (FOR MTG.HYD. CLUTCH HOSE)	TATA spare parts
206730100111	ASSY PULL CABLE 1955MM	TATA spare parts
206730100112	ASSY CABLE MTG BKT	TATA spare parts
206730100113	ASSY HOUSING FOR ACCELARATOR SHAFT	TATA spare parts
206730100114	ASSY ACCELARATOR SHAFT	TATA spare parts
206730100116	ASSY PULL CABLE (ACCELERATOR)	TATA spare parts
206730100117	ASSY.ACCELERATOR PEDAL COMPLETE	TATA spare parts
206730100119	ASSY PULL CABLE (ACCELERATOR)	TATA spare parts
206730100123	ASSY. ACCELERATOR PULL CABLE BS3	TATA spare parts
206730103302	BRACKET CABLE MTG. (FIP SIDE)	TATA spare parts
206730107501	COVER FOR ACCEL. PEDAL	TATA spare parts
206730108202	BRACKET-RETURN SPRING	TATA spare parts
206730108701	RETURN SPRING	TATA spare parts
206730109901	THRUST ROD	TATA spare parts
206731000102	ASSY FRAME COMP-SE/42 WB	TATA spare parts
206731000103	ASSY FRAME COMP.-36 WB	TATA spare parts
206731000109	ASSY FRAME COMPLETE SK/36	TATA spare parts
206731000111	ASSY FRAME COMPLETE SE 1613TC/42	TATA spare parts
206731000114	ASSY FRAME COMPL SE 1613 TC-48 WB	TATA spare parts
206731000115	ASSY FRAME COMPL-SK/36	TATA spare parts
206731000116	ASSY FRAME COMPLETE SK1613/42TC	TATA spare parts
206731000132	ASSY FRAME SE 1613/42 TC - 4 POINT ENG.	TATA spare parts
206731000135	ASSY FRAME COMPL. WITH FRONT COUPLING	TATA spare parts
206731000136	ASSY FRAME COMPLETE SK1613TC/36	TATA spare parts
206731000157	ASSY FRAME COMPL 960 ROH (SK EURO-II)	TATA spare parts
206731000158	ASSY FRAME SK 1613/36 TC EURO-II	TATA spare parts
206731000164	ASSY.FRAME COMPLETE SE-1613TC/42,COWL	TATA spare parts
206731000168	ASSY.FRAME COMP.SE1613TC/42 CAB EURO-II	TATA spare parts
206731000189	ASSY FRAME (RTH+FTH+RUPD)	TATA spare parts
206731000191	ASSY FRAME COMPLETE	TATA spare parts
206731000194	ASSY FRAME COMPLETE	TATA spare parts
206731000202	ASSY. FRAME SK1613 (1290 ROH) BS3	TATA spare parts
206731000204	ASSY FRAME COMPLETE (960 ROH)	TATA spare parts
206731000211	FRAME ASSY WITH FITMENT	TATA spare parts
206731000214	FRAME ASSY WITH FITMENT BS6	TATA spare parts
206731200102	ASSY SUPPORT ENGINE CROSS MEMBER SE1613T	TATA spare parts
206731200103	ASSY SUPP. ENG.CROSS MEM. RR LH SE 1613T	TATA spare parts
206731200105	ASSY ENGINE CROSS MEMBER	TATA spare parts
206731200106	ASSY. SUPPORT ENG. CROSS MEMBER REAR RH	TATA spare parts
206731200107	ASSY. SUPPORT ENG. CROSS MEMBER REAR LH	TATA spare parts
206731200114	ENGINE CROSS MEMBER REAR	TATA spare parts
206731200115	ENGINE CROSS MEMEBR FRONT	TATA spare parts
206731200121	ASSY 3RD CROSS MEMBER	TATA spare parts

206731200122	ASSY SUPPORT (ENG X/M REAR)	TATA spare parts
206731200126	ASSY.4TH C/M WITH SUPPORT	TATA spare parts
206731200128	ASSY SUPPORT ENGINE CROSS MEMBER REAR	TATA spare parts
206731207106	GUSSET RH	TATA spare parts
206731207107	GUSSET LH	TATA spare parts
206731207128	REINFORCEMENT TOP R.H.	TATA spare parts
206731207129	REINFORCEMENT TOP L.H.	TATA spare parts
206731207150	SUPPORT RH(ENG C/M FRONT)	TATA spare parts
206731207151	SUPPORT LH (ENG C/M FRONT)	TATA spare parts
206731207164	REINFORCEMENT - RH (BOTTOM)	TATA spare parts
206731207165	REINFORCEMENT -LH (BOTTOM)	TATA spare parts
206731207170	FRONT REINFORCEMENT (BOTTOM)LH	TATA spare parts
206731207171	FRONT REINFORCEMENT(BOTTOM)RH	TATA spare parts
206731207177	SUPPORT (REAR SPRING CROSS MEMBER).	TATA spare parts
206731207178	SUPPORT-REAR SPRING CROSS MEMBER	TATA spare parts
206731207181	REINFORCEMENT TOP-L.H	TATA spare parts
206731207182	REINFORCEMENT TOP-R.H	TATA spare parts
206731207185	SPACER PLATE	TATA spare parts
206731207186	SUPPORT RH	TATA spare parts
20673120718635	SUPPORT RH_UNPAINTED	TATA spare parts
206731207187	SUPPORT LH	TATA spare parts
206732100111	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
206732100112	ASSY FRONT SPRING LPT1613-SE/SK	TATA spare parts
206732104201	SPRING CLIP	TATA spare parts
206732104202	SPRING CLIP	TATA spare parts
206732107132	SECOND LEAF	TATA spare parts
206732107133	THIRD LEAF	TATA spare parts
206732107134	FOURTH LEAF	TATA spare parts
206732107135	FIFTH LEAF	TATA spare parts
206732107136	SIXTH LEAF	TATA spare parts
206732107137	SEVENTH LEAF	TATA spare parts
206732107138	EIGHTH LEAF	TATA spare parts
206732107139	NINETH LEAF	TATA spare parts
206732108601	SPACER	TATA spare parts
206732404201	SPRING CLIP	TATA spare parts
206732404202	SPRING CLIP	TATA spare parts
206732404203	SPRING CLIP	TATA spare parts
206732404205	SPRING CLIP	TATA spare parts
206732404210	AUX.SPRING CLIP (REAR SPRING) BS6	TATA spare parts
206740300101	BRACKET ASSY SPARE WHEEL CARRIER MTG	TATA spare parts
206741100104	ASSY. PROP. SHAFT COMPLETE-REAR	TATA spare parts
206741100107	ASSY PROP SHAFT COMP. RR	TATA spare parts
206741100110	ASSY PROP.SHAFT FRT 42 WB	TATA spare parts
206741100115	ASSY PROP SHAFT FRT 36WB	TATA spare parts
206741100118	ASSY PROP SHAFT WITH C.B SE 1613 TC 36	TATA spare parts
206741100128	CROSS ASSY	TATA spare parts
206741100129	CENTRE BEARING ASSY	TATA spare parts

206741100134	ASSY PROP SHAFT WITH CENTER BEARING	TATA spare parts
206741100135	LONG FORK SUB ASSY.	TATA spare parts
206741100137	COUPLING FLANGE ASSY	TATA spare parts
206741100154	ASSY PROP SHAFT WITH C. BRG.	TATA spare parts
206741100161	ASSY PROP SHAFT WITH CTR BRG	TATA spare parts
206741100167	ASSY PROP SHAFT WITH CENTRE BEARING	TATA spare parts
206741100179	ASSY PROP SHAFT W C. BRG. 292L	TATA spare parts
206741100185	ASSY.PROP.SHAFT WITH CENTREN BRG	TATA spare parts
206741100199	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
206741105105	FLANGE YOKE.	TATA spare parts
206741105108	FLANGE YOKE	TATA spare parts
206741105111	FLANGE YOKE	TATA spare parts
206741106502	HEX NUT	TATA spare parts
206741110101	ASSY PROP SHAFT FRONT-1055MM	TATA spare parts
206741110102	ASSY PROP SHAFT COMPL.WITH C.B.	TATA spare parts
206741110103	ASSY.PROP.SHAFT FRONT WITH C.B.	TATA spare parts
206741110104	ASSY PROP SHAFT COMPL.WITH C.B.	TATA spare parts
206741110106	ASSY PROPELLER SHAFT FRONT	TATA spare parts
206741119901	COUPLING FLANGE DUST COVER ASSY MIDDLE	TATA spare parts
206741120101	ASSY.PROP.SHAFT COMPLETE REAR	TATA spare parts
206741120102	ASSY.PROP.SHAFT COMPLETE REAR	TATA spare parts
206741120111	ASSY.PROP.SHAFT COMPLETE REAR	TATA spare parts
206741120112	ASSY.PROP.SHAFT.COMPLETE REAR	TATA spare parts
206741120113	ASSY PROP. SHAFT REAR COMPL	TATA spare parts
206741120115	ASSY PROP. SHAFT REAR COMPL	TATA spare parts
206741120116	ASSY. CROSS BS1/2/3/4	TATA spare parts
206741120117	LONG FORK SUB ASSY.	TATA spare parts
206741120118	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
206741120119	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
206741120121	ASSY. REAR PROP SHAFT COMPLETE	TATA spare parts
206741120127	PROPELLER SHAFT REAR	TATA spare parts
206741125103	FLANGE YOKE	TATA spare parts
206741303301	BRACKET (CENTRE BRG)	TATA spare parts
206741303302	BRACKET (FOR CENTRE BEARING)	TATA spare parts
206741303303	CENTER BEARING BRACKET	TATA spare parts
206741990102	SHORT FORK TUBE &REAR HOUSING ASSY.	TATA spare parts
206741990103	PROPELLER SHAFT TUBE ASSY REAR HOUSING	TATA spare parts
206741990106	SLIP YOKE ASSY	TATA spare parts
206742700116	ASSY.PIPE 6DIA.X 725LG.	TATA spare parts
206742700125	ASSY TUBE	TATA spare parts
206742805801	HOSE - 60 LONG	TATA spare parts
206742900128	ASSY TUBE(150.D*1765	TATA spare parts
206742900129	ASSY PIPE 15 DIA X 1400 L	TATA spare parts
206742900130	ASSY PIPE 15 DIA X 1915 L	TATA spare parts
206742900131	ASSY PIPE 15 DIA X 565 LG	TATA spare parts
206742900132	ASSY PIPE 6 DIA X 1140 L	TATA spare parts
206742900133	ASSY PIPE-12*2005	TATA spare parts

206742900134	ASSY TUBE	TATA spare parts
206742900135	ASSY PIPE	TATA spare parts
206742900136	ASSY TUBE(1200*650LG	TATA spare parts
206742900137	ASSY-1200*2175LG	TATA spare parts
206742900145	ASSY.HOSE-CRIMPED	TATA spare parts
206742900147	ASSY HOSE SK 1613 TC	TATA spare parts
206742900150	ASSY HOSE SE 1613 TC	TATA spare parts
206742900154	ASSY.RUBBER HOSE	TATA spare parts
206742900157	ASSY TUBE (120.D*420	TATA spare parts
206742900159	CLUTCH HOSE	TATA spare parts
206742900176	ASSY HOSE 18 DIA X 1055 SE 1613 TC	TATA spare parts
206742904201	DOUBLE CLAMP	TATA spare parts
206742906801	ELBOW.	TATA spare parts
206742910101	ASSY NYLON PIPE SET COMPLETE SE1613/42	TATA spare parts
206742910121	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
206742910134	ASSY.NYLON PIPE SET COMPLETE.	TATA spare parts
206742910144	ASSY.TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
206743100111	ASSY.PIPE 6DIA.X 800 MM L	TATA spare parts
206743100112	PIPE 6 X 845	TATA spare parts
206743200101	ASSY.AIR TANK COM.WITH SUPPORT STRAP SPA	TATA spare parts
206743200102	ASSY.AIR TANK COM.SUPPORT STRAP & SPACER	TATA spare parts
206743200104	SUPPORT ASSY AIR TANK MTG	TATA spare parts
206743203301	BRACKET SOLENOID VALVE MTG	TATA spare parts
206743910122	METAL PIPE ASSY BS6	TATA spare parts
206743910124	NYL/BUNCH SE 1613/42 TC BS-2	TATA spare parts
206743910129	NYL/BUNCH SK 1613/36 TC BS-2	TATA spare parts
206743910135	PIPE BUNCH ASSY BS6	TATA spare parts
206743910147	ASSY. COMP. INLET PIPE	TATA spare parts
206743910148	ASSY. COMP. PIPE FIRST	TATA spare parts
206743910170	ASSY.NYLON PIPE SET COMP. W/VOSS CONN.	TATA spare parts
206743910172	ASSY COMP PIPE SECOND	TATA spare parts
206743910173	ASSY COMP.PIPE THIRD	TATA spare parts
206743910177	ASSY COMP.SECOND PIPE	TATA spare parts
206743910178	ASSY COMP.THIRD PIPE	TATA spare parts
206743910180	ASSY NYLON PIPE SET. W/VOSS	TATA spare parts
206744100110	HYDRAULIC CYLINDER	TATA spare parts
206744100111	LINEAR SPOOL VALVE	TATA spare parts
206744100120	PUMP ELBOW WITH SWIVEL NUT ASSEMBLY	TATA spare parts
206744100125	SWIVEL ELBOW ASSEMBLY WITH PMSC	TATA spare parts
206744100126	SWIVEL ELBOW ASSEMBLY WITH PMSC	TATA spare parts
206744100127	SWIVEL ELBOW ASSEMBLY WITH PMSC	TATA spare parts
206744103301	VALVE MOUNTING BRACKET	TATA spare parts
206744104301	HOSE CLIP	TATA spare parts
206744104302	HOSE CLIP	TATA spare parts
206744105802	RETURN LINE HOSE (1IN ID X 750 L)	TATA spare parts
206744106501	NYLOC NUT¿ M8X1.25	TATA spare parts
206744106804	PARALLEL MALE STUD REDUCER	TATA spare parts

206744106805	PARALLEL MALE STUD COUPLING BODY	TATA spare parts
206744106811	STRAIGHT ADAPTOR	TATA spare parts
206744106812	PARALLEL MALE STUD COUPLING BODY	TATA spare parts
206744109201	STANDARD BONDED SEAL	TATA spare parts
206744109202	SEALING WASHER	TATA spare parts
206744109203	SEALING WASHER	TATA spare parts
206744400101	HYDRAULIC TANK ASSY.	TATA spare parts
206744990101	TANK ASSY	TATA spare parts
206744990102	TIPPER VALVE HT-SAE1150-170-P3/4 BS2/3/4	TATA spare parts
206744993201	HEX.BOLT M12	TATA spare parts
206744993301	CHASSIS BKT	TATA spare parts
206744993302	LIFTING BKT RH	TATA spare parts
206744993303	LIFTING BKT LH	TATA spare parts
206744993304	BRACKET MTG ACV TATA SK1616	TATA spare parts
206744996501	NYLOC NUT M12X1.25	TATA spare parts
206744996801	ADAPTER M39X2 X 1 7/16 INUNF	TATA spare parts
206744996802	ELBOW 3/4INCHBSP X 3/4INCHBSP	TATA spare parts
206744996803	ELBOW M26X1.5 X 1 3/16 INUNF	TATA spare parts
206744997701	RUBBER STRIP FOR FC CYL	TATA spare parts
206744999201	THICK WASHER M12 5MMT	TATA spare parts
206744999901	TANK ASSY MOUNTING KIT BS6	TATA spare parts
206744999902	KIT-CONNECTOR TIPPER VALVE MTG	TATA spare parts
206744999903	TUBE SEAMLESS ASSY KIT 75L	TATA spare parts
206746000103	ASSY STRG BRACKET-V.RATIO STRG.	TATA spare parts
206746000112	ASSY. STG BKT BS1/2/3/4	TATA spare parts
206746108001	COLLAR BOLT	TATA spare parts
206746150102	ASSY.KIT FOR P/STG LINE & CONNECTOR.	TATA spare parts
206746150103	ASSY.KIT FOR P/STG.LINE BKT & CLAMP.	TATA spare parts
206746150104	ASSY.KIT FOR P/STG.LINE & CONNECTOR.	TATA spare parts
206746150105	ASSY.KIT P/STG.LINES BKTS.& CLAMPS.	TATA spare parts
206746150108	ASSY.P/STG.LINES & CONNECTORS.	TATA spare parts
206746207501	RUBBER BELOW (STEERING)	TATA spare parts
206746207503	RUBBER BELLOW (STG COLUMN)	TATA spare parts
206746207902	STEERING SPINDLE BOTTOM	TATA spare parts
206746208201	COVER PLATE	TATA spare parts
206746600101	BALL & NUT POWER STG. GEAR BS1/2/3/4	TATA spare parts
206746600102	ASSY POWER STG.GEAR BOX	TATA spare parts
206746600105	ASSY. UNIVERSAL JOINT BS1/2/3/4	TATA spare parts
206746800102	ASSY.TUBE WITH CRIM.R/HOSE.(SE/SK TC)HYD	TATA spare parts
206746800104	SUCTION LINE HOSE ASSY	TATA spare parts
206746800105	PRESSURE LINE HOSE ASSY	TATA spare parts
206746800106	RETURN LINE HOSE ASSY	TATA spare parts
206746800110	SUCTION LINE HOSE ASSY.	TATA spare parts
206746800111	PRESSURE LINE HOSE ASSY	TATA spare parts
206746803301	BRACKET (FOR STG.PIPE LINE CLAMP) BS6	TATA spare parts
206746990101	BALL JOINT ASSY	TATA spare parts
206747100101	ASSY FUEL TANK COMP.1613S	TATA spare parts

206747100102	ASSY FUEL TANK WELDED	TATA spare parts
206747100106	ASSY FUEL TANK COMPL.(150 LTS. RECT.)	TATA spare parts
206747100108	ASSY FUEL TANK COMP. 225 LTR. ROUND	TATA spare parts
206747100109	ASSY FUEL TANK COMPLETE (150 LTR.RECT)	TATA spare parts
206747500104	ASSY. STRAP	TATA spare parts
206747500105	ASSY. BRACKET	TATA spare parts
206747507701	FUEL TANK RUBBER PACKING	TATA spare parts
206747507702	FUEL TANK RUBBER PACKING	TATA spare parts
206747600110	ASSY TUBE 1225 LONG HOSE TO INT. JOINT	TATA spare parts
206747600127	ASSY TUBE 1500 LONG	TATA spare parts
206747600130	ASSY TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
206747600131	ASSY.TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
206747600132	ASSY.TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
206747600133	ASSY.TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
206747600134	ASSY.TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
206747600135	ASSY TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
206747600137	ASSY.TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
206747600138	ASSY.TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
206747600139	ASSY TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
206747600140	ASSY.TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
206747600146	ASSY.TUBE W/CRIMPED R/HOSE.	TATA spare parts
206747600147	ASSY.TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
206747600148	ASSY.TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
206747600149	ASSY HOSE	TATA spare parts
206747600151	ASSY.HOSE	TATA spare parts
206747600152	ASSY.TUBE W/CRIMPED R/HOSE	TATA spare parts
206747600161	SUCTION LINE (FUEL FILTER TO ENG)	TATA spare parts
206747600163	SUCTION LINE (FUEL TANK TO FILTER)	TATA spare parts
206747600165	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
206747609201	COATED WASHER	TATA spare parts
206747700101	BRACKET ASSY FWS MTG (WITH GUARD)	TATA spare parts
206747700104	BRACKET ASSY BS6	TATA spare parts
206749100101	ASSY.BRACKET(EXHAUST).	TATA spare parts
206749100102	ASSY.BRACKET(EXHAUST).	TATA spare parts
206749100103	ASSY.SILENCER WITH PIPE	TATA spare parts
206749100108	ASSY SILENCER WITH TAIL(SE/SK1613/32TC)	TATA spare parts
206749108201	SUPPORT (EXHAUST) LH	TATA spare parts
206749108203	PLATE EXHAUST	TATA spare parts
206749200103	ASSY.BRACKET (EXH.MOUNTING)	TATA spare parts
206749200112	ASSY EXHAUST PIPE INTERMEDIATE	TATA spare parts
206749200113	ASSY EXHAUST PIPE FRONT	TATA spare parts
206749200123	ASSY.EXHAUST PIPE INTERMEDIATE	TATA spare parts
206749200125	ASSY.EXHAUST PIPE FRONT	TATA spare parts
206749200129	ASSY EXHAUST PIPE INTERMEDIATE	TATA spare parts
206749200130	ASSY EXHAUST PIPE FRONT	TATA spare parts
206749200133	ASSY.EXH.PIPE FRONT	TATA spare parts
206749200134	ASSY EXHAUST PIPE INTERMEDIAT	TATA spare parts

206749200135	ASSY. EXHAUST PIPE INTERMEDIATE	TATA spare parts
206749200137	KIT FOR EXH BRAKE FITMENT ON SK1613TC	TATA spare parts
206749200138	ASSY EXHAUST PIPE FRONT	TATA spare parts
206749200139	ASSY BRACKET (FOR SILENCER MTG)	TATA spare parts
206749203303	BRACKET	TATA spare parts
206749203306	BRACKET	TATA spare parts
206749203315	BRACKET	TATA spare parts
20675042000RCK	ASSY CAB WITH FITMENTS BS3	TATA spare parts
206754100101	ASSY.BATTERY CABLE +VE(BATTERY TO BCS)	TATA spare parts
206754106301	BATTERY TRAY PLASTIC	TATA spare parts
206754110102	ASSY.BATTERY CABLE(-VE)	TATA spare parts
206754200102	ASSY NYLON PIPE FOR GAUGE LINE	TATA spare parts
206754209901	INSTRUMENT CLUSTER (0.88)	TATA spare parts
206754209902	INSTRUMENT CLUSTER-(0.88)	TATA spare parts
206754209933	INSTRUMENT CLUSTER (0.88)ESPDO	TATA spare parts
206754209934	INSTRUMENT CLUSTER-(0.88)ESPDO	TATA spare parts
206754209947	INSTRUMENT CLUSTER-(0.88)	TATA spare parts
206754209959	INST.CLSTR(1;0.88)ESPDO 12V	TATA spare parts
206754209960	INST. CLSTR(1;0.88) ESPDO 12V	TATA spare parts
206754209967	ELECTRONIC SPDOMETER SPARE(0.88)	TATA spare parts
206754209973	INST.CLUSTER (1.04)ESPDO-24V	TATA spare parts
206754209975	INST CLUSTER PTO (1.04)ESPDO-24V	TATA spare parts
206754209978	INST CLUSTER (1.04)ESPDO PTO 24V	TATA spare parts
206754400108	HEADLAMP LH BS6	TATA spare parts
206754400109	HEADLAMP RH BS6	TATA spare parts
206754600119	WIRING HARNESS ENGINE	TATA spare parts
206754600120	WIRING HARNESS ENGINE BS6	TATA spare parts
206754600121	BATTERY CABLE +VE BCS TO MEGA FUSE BS6	TATA spare parts
206754600122	WIRING HARNESS MAIN BS6	TATA spare parts
206754603301	BRACKET MAIN TO TAIL I/C MTG	TATA spare parts
206754609901	STICKER MAXI FUSE BOX BS6	TATA spare parts
206754610101	EARTH STRAP WITH CU TUBE	TATA spare parts
206754610101AE	EARTH STRAP WITH CU TUBE	TATA spare parts
206754620104	WIRING HARNESS PIGTAIL FOR INSP LAMP SKT	TATA spare parts
206754620106	WIRING HARNESS MAIN	TATA spare parts
206754620112	WIRING HARNESS MAIN	TATA spare parts
206754620119	W/H MAIN SK1613/TC BSIII/24V	TATA spare parts
206754660117	W/H MAIN	TATA spare parts
206754820105	W/H-MAIN SK-1613TC E-I & II INST CLUSTE	TATA spare parts
206770110133	KIT PT.NO.OF ASSY.SUPD COMPLETE	TATA spare parts
206787000102	ASSY KIT BODY - 8 CUM BOX	TATA spare parts
206787100101	ASSY SUB-FRAME (8 CUM BOX)	TATA spare parts
206787300101	ASSY. TIPPING BODY COMPLETE (8 CUM BOX)	TATA spare parts
20679842000RCK	ASSY CABIN KIT W/FITMENTS SE1613 TC BS3	TATA spare parts
206829100101	ASSY CONNECTING LINE	TATA spare parts
206829100103	ASSY CONNECTING	TATA spare parts
206829100104	ASSY.TUBE	TATA spare parts

206829100105	ASSY PIPE 6 DIA X 3160 LG	TATA spare parts
206829100106	ASSY TUBE (FROM CLUTCH MASTER CYLINDER	TATA spare parts
206829100107	ASSY TUBE (FROM INT. JOINT TO CLUTCH SLA	TATA spare parts
206829100108	ASSY.TUBE 6X1700 LG.	TATA spare parts
206842700118	ASSY PIPE 12 DIA X 1680LG	TATA spare parts
206842700122	ASSY PIPE 6 DIA X 2360 LG	TATA spare parts
206842900101	ASSY PIPE 18 DIA X 1020LG	TATA spare parts
206842900102	ASSY PIPE 18 DIA X 315 LG	TATA spare parts
206842900103	PIPE ASSY 15D X 440 MM	TATA spare parts
206842900104	ASSY.PIPE 15DIA.X2225LG.	TATA spare parts
206842900109	ASSY PIPE 12 DIA X 680 LG	TATA spare parts
206842900130	ASSY PIPE 12 DIA X 615 LG	TATA spare parts
206842900131	ASSY TUBE 12 DIA X 620 LG	TATA spare parts
206842900132	ASSY TUBE 15X1.5X1175 LG	TATA spare parts
206842900134	ASSY PIPE 12 DIA X 1400LG	TATA spare parts
206842900135	ASSY PIPE 12 DIA X 3100LG	TATA spare parts
206842900136	ASSY PIPE 12 DIA X 1410LG	TATA spare parts
206842900142	ASSY PIPE 12 DIA X 1740LG	TATA spare parts
206842900143	ASSY PIPE 12 DIA X 840 LG	TATA spare parts
206842900144	ASSY PIPE 12 DIA X 1340LG	TATA spare parts
206842900145	ASSY PIPE 12 DIA X 2140LG	TATA spare parts
206842900146	PIPE 12 X1680	TATA spare parts
206842900151	ASSY TUBE	TATA spare parts
206842900152	ASSY TUBE (6X.7X1040 LG.)	TATA spare parts
206842900153	ASSY TUBE (6X0.7X3230 LG.)	TATA spare parts
206842903303	BRACKET(L-SECTION)	TATA spare parts
206842903304	BRACKET	TATA spare parts
206842903306	BRACKET FABRICATED	TATA spare parts
206842903308	BRACKET ( FUEL PRE FILTER )	TATA spare parts
206842903310	BRACKET	TATA spare parts
206842903313	BRACKET(Z-SHAPE)	TATA spare parts
206842903315	BRACKET (U-SHAPE)	TATA spare parts
206842906801	T CONNECTOR	TATA spare parts
206843100101	DUEL BRAKE VALVE-OFFER PART	TATA spare parts
206843200106	ASSY PIPE 6 DIA X 1180 LG	TATA spare parts
206843200114	ASSY PIPE 6 DIA X 630 LG	TATA spare parts
206843200115	ASSY PIPE 6 DIA X 1895LG	TATA spare parts
206843200116	PIPE 6 X 1625	TATA spare parts
206843200118	PIPE 6 X 1860	TATA spare parts
206843500101	HOSE ASSY 3/8 INCH	TATA spare parts
206843500102	HOSE ASSY 3/8 INCH	TATA spare parts
206844100103	ASSY.PIPE 15DIA.X 280LG.	TATA spare parts
206844100113	ASSY PIPE 18 DIA X 470 LG	TATA spare parts
206844100114	ASSY PIPE 15 DIA X 2100LG	TATA spare parts
206844100117	ASSY.PIPE 15DIA.X1830LG.	TATA spare parts
206844100118	TUBE ASSY STRG TO TANK	TATA spare parts
206844100120	ASSY TUBE 18X565 LG	TATA spare parts



206844100121	ASSY. TUBE 15X2280LG	TATA spare parts
206844100123	ASSY.PIPE15D.X985LG(INT.HOSE-STG.GEAR BX	TATA spare parts
206844100125	ASSY TUBE 18X1.5X580 LG.	TATA spare parts
206844100128	ASSY TUBE 15 X 2280	TATA spare parts
206846800103	ASSY TUBE 15 X 280	TATA spare parts
206847107202	BANJO BOLT	TATA spare parts
206847600101	ASSY PIPE 10 DIA X 1535LG	TATA spare parts
206847600102	ASSY PIPE 10 DIA X 1400LG	TATA spare parts
206847600103	ASSY PIPE 6 DIA X 1640LG	TATA spare parts
206847600104	ASSY PIPE 6 DIA X 1135 LG	TATA spare parts
206847600115	F/FEED LINE 15DIA INLINE	TATA spare parts
206847600127	ASSY.TUBE 15DIA.X1515 LG.	TATA spare parts
206847600128	ASSY TUBE 10 X 1730	TATA spare parts
206847600129	ASSY TUBE 10X 1015	TATA spare parts
206847603301	BRACKET	TATA spare parts
206847605801	HOSE	TATA spare parts
206901000116	ASSY 6BT(125HP) ENGINE OP	TATA spare parts
206901000118	ASSY. 6BT(145HP) ENGINE	TATA spare parts
206901000124	ASSY 6BT (145HP) ENGINE	TATA spare parts
206901000126	ASSY 6BT(125HP) ENGINE LPTA 713TC	TATA spare parts
206901000127	ASSY 6BT(125HP) ENGINE W/O CLH & CLH HSG	TATA spare parts
206901000129	ASSY 6BT-125HP ENGINE	TATA spare parts
206901000131	ENGINE 6BT(125HP) 4 PT MTG SE/SK 1613	TATA spare parts
206901000133	ENGINE SE/SK 1615TC 4 POINT MTG.	TATA spare parts
206901000134	ASSY ENG 6BTAA 125HP 12V EURO-II SE/SK16	TATA spare parts
206901000142	ASSY. ENGINE COMP. 6BTAA-125HP EURO2	TATA spare parts
206901000144	ASSY ENG.6BT-125HP 12V EURO I SK/SE 1613	TATA spare parts
206901000148	KIT ASSY.6BT ENG(145HP)WITH CL & CL/HSG	TATA spare parts
206901000160	ENGINE 6BTAA(145HP)EURO-II	TATA spare parts
206901000162	ASSY.6BTAA 145HP E-II 12V	TATA spare parts
206901000170	ENGINE 6BTAA(125HP)EURO-II	TATA spare parts
206901000182	ENGINE 6BTAA 130HP-24V-BSIII	TATA spare parts
206901000183	ASSY. ENGINE COMP. 6BT SA/SK1212 BS3	TATA spare parts
206901000187	ASSY. ENGINE COMP. 6BT-155 HP 3RV BS3	TATA spare parts
206901000188	ASSY.ENGINE-155HP-BSIII	TATA spare parts
206901000189	ENGINE SD1015 155- BSIII	TATA spare parts
206901000191CJO	ENGINE ASSY	TATA spare parts
206901000192	ASSY. ENGINE COMP. 6BT 5.9 145HP BS2	TATA spare parts
206901000199	ENGINE 6BTAA 155HP BSIII-LPA715TC/32-LAT	TATA spare parts
206901000206	ENGINE SE/SK 1613TC BS3 NEW	TATA spare parts
206901000208	OPTION DRG 130HP BS3 SE/SK1613	TATA spare parts
206901000221	ENGINE ASSY OPTION LIST	TATA spare parts
206901000223	ENGINE-OPTION LIST	TATA spare parts
206901000237	ENGINE-OPTION LIST	TATA spare parts
206907150104	KWIK START UNIT(COLD START)	TATA spare parts
206909113301	BRACKET LPTA 713 TC	TATA spare parts
206909130113	ASSY BRKT (AIR FILTE	TATA spare parts

206909130125	ASSY AIR INLET PIPE	TATA spare parts
206909130128	ASSY.CLAMP ON CAB REAR WALL	TATA spare parts
206909130130	ASSY BRACKET	TATA spare parts
206909130133	ASSY AIR INLET DUCT	TATA spare parts
206909130137	ASSY AIR INLET DUCT	TATA spare parts
206909130138	ASSY STRAP W/SHACKLE	TATA spare parts
206909130139	PREFILTER MTG BKT	TATA spare parts
206909130140	ASSY CLAMP	TATA spare parts
206909130142	PRECLEANER ASSY	TATA spare parts
206909130143	ASSY. AIR FILTER ( TELCO	TATA spare parts
206909130145	ASSY. CLAMP	TATA spare parts
206909130149	ASSY. AIR FILTER LPTA 713 TC	TATA spare parts
206909130150	ASSY PIPE(AIR FILTER TO TC) LPTA 713 TC	TATA spare parts
206909130152	ASSY AIR FILTER MOUNTING BRACKET	TATA spare parts
206909130154	ASSY. PROTECTIVE COVER	TATA spare parts
206909130155	ASSY PROTECTIVE COVER LPTA 713 TC	TATA spare parts
206909130156	ASSY. AIR FILTER	TATA spare parts
206909130159	ASSY. PROTECTIVE COVER	TATA spare parts
206909130160	ASSY. AIR FILTER LPTA 713 TC	TATA spare parts
206909130178	ASSY.BRACKET (AIR FILTER MOUNTING)	TATA spare parts
206909130179	ASSY. BRACKET PRE CLEANER MTG.	TATA spare parts
206909130180	ASSY BRACKET	TATA spare parts
206909130181	ASSY BRACKET	TATA spare parts
206909130184	ASSY AIR INLET PIPE	TATA spare parts
206909130185	ASSY.AIR FILTER	TATA spare parts
206909130186	ASSY PROTECTIVE COVER	TATA spare parts
206909130187	ASSY.AIR INLET PIPE	TATA spare parts
206909130198	ASSY.PIPE AIR INTAKE (A/F TO TC)	TATA spare parts
206909130201	ASSY AIR INLET DUCT	TATA spare parts
206909130202	ASSY BKT AIR FILTER MTG	TATA spare parts
206909130203	ASSY BRACKET- PREFILTER MTG	TATA spare parts
206909130204	ASSY AIR FILTER	TATA spare parts
206909130206	ASSY A/L PIPE	TATA spare parts
206909130207	ASSY AIR FILTER	TATA spare parts
206909130209	ASSY MTG BKT A/F	TATA spare parts
206909130210	ASSY MTG. BKT - AIR FILTER	TATA spare parts
206909130216	AIR FILTER PRIMARY	TATA spare parts
206909130222	AIR INLET DUCT	TATA spare parts
206909130223	AIR FILTER SAFETY	TATA spare parts
206909130225	ASSY.AIR INTAKE PIPE (A/FILTER TO TC)	TATA spare parts
206909130227	ASSY. BRACKET (AIR FILTER MTG.)	TATA spare parts
206909130228	ASSY. PROTECTIVE COVER	TATA spare parts
206909130229	ASSY AIR FILTER	TATA spare parts
206909130230	ASSY AIR FILTER	TATA spare parts
206909130231	ASSY BRACKET	TATA spare parts
206909130232	ASSY BRACKET (PRE FILTER MTG)	TATA spare parts
206909130233	ASSY BRACKET	TATA spare parts

206909130237	ASSY CLAMP WITH RUBBER	TATA spare parts
206909130238	ASSY.AIR INTAKE PIPE (A/F TO TC)	TATA spare parts
206909130239	ASSY.AIR FILTER	TATA spare parts
206909130244	ASSY PROTECTIVE COVER	TATA spare parts
206909130245	ASSY PIPE AIR FILTER	TATA spare parts
206909130246	ASSY PROTECTIVE COVER	TATA spare parts
206909130247	ASSY. AIR FILTER MTG.BKT	TATA spare parts
206909130248	ASSY AIR FILTER	TATA spare parts
206909130250	ASSY BKT-AIR FILTER MTG.	TATA spare parts
206909130251	ASSY AIR FILTER MTG BRACKET	TATA spare parts
206909133310	BRACKET AIR DUCT MTG	TATA spare parts
206909134203	CLAMP FOR AIR DUCT	TATA spare parts
206909134205	CLAMP	TATA spare parts
206909135801	RUBBER BELLOW (AT AIR FIL	TATA spare parts
206909135802	RUBBER BELLOW	TATA spare parts
206909135807	RUBBER HOSE	TATA spare parts
206909135810	RUBBER HOSE	TATA spare parts
206909135813	HOSE	TATA spare parts
206909135814	RUBBER BELLOW	TATA spare parts
206909135815	RUBBER HOSE(SNORKEL TO FILTER)SE/SK 1613	TATA spare parts
206909135816	HOSE(AIR FILTER END) LPTA 713 TC	TATA spare parts
206909135822	HOSE-AIRFILTER OUTLET	TATA spare parts
206909135823	HOSE (AIR FILTER OUTLET)	TATA spare parts
206909135825	RUBBER HOSE	TATA spare parts
206909135826	RUBBER HOSE	TATA spare parts
206909135827	HOSE AIR FILTER OUTLET	TATA spare parts
206909135828	HOSE (TC END) LPT 713	TATA spare parts
206909135829	HOSE(AIR FILTER END ) LPT 713	TATA spare parts
206909135830	RUBBER HOSE (AIR FILTER END)	TATA spare parts
206909135831	REDUCER HOSE(FOR AIR FILTER OUTLET)	TATA spare parts
206909135834	HOSE (SNORKEL TO PRE FILTER)	TATA spare parts
206909135835	RUBBER HOSE TURBOCHARGER	TATA spare parts
206909137703	RUBBER STRAP	TATA spare parts
206909139901	RUBBER STRAP	TATA spare parts
206914580101	ASSY. HEAT SHIELD	TATA spare parts
206914603801	PIPE (ENGINE END)	TATA spare parts
206914603812	PIPE-I.C. TO CYL HEAD	TATA spare parts
206914603813	PIPE- T.C. TO I.C.	TATA spare parts
206914603814	PIPE-T.C. TO I/COOLER	TATA spare parts
206914603818	PIPE(IC TO ENGINE)	TATA spare parts
206914603819	PIPE(TC TO INTERCOOLER)	TATA spare parts
206914603820	PIPE(I/C TO ENGINE)	TATA spare parts
206914603823	PIPE TURBOCHARGER TO INTERCOOLER	TATA spare parts
206914603825	PIPE INTERCOOLER TO AIR INTAKE PIPE	TATA spare parts
206914605005	AL PIPE (IC TO ENGINE)	TATA spare parts
206914605006	AL PIPE (TC TO IC)	TATA spare parts
206914605007	AL PIPE (IC TO ENGINE)	TATA spare parts

206914605009	PIPE(IC TO ENG INTAKE)	TATA spare parts
206914605012	PIPE (TC-IC) FOR ERGO CAB	TATA spare parts
206914605802	HOSE HUMP	TATA spare parts
206914605845	HOSE HUMP	TATA spare parts
206914609901	INTERCOOLER	TATA spare parts
206914609902	INTERCOOLAR SE1615TCIC BSIII	TATA spare parts
206914609906	INTERCOOLER	TATA spare parts
206914609907	INTERCOOLER	TATA spare parts
206914609909	INTERCOOLER BS3	TATA spare parts
206914609910	ASSY INTERCOOLER	TATA spare parts
206914609910AE	INTERCOOLER ASSY. 715	TATA spare parts
206914616902	PIPE TC TO INTERCOOLER	TATA spare parts
206914616904	PIPE TC TO INTERCOOLER	TATA spare parts
206918179901	ADAPTER (FOR OIL PR. TRANSDUCER)	TATA spare parts
206920140101	ASSY FAN RING MTG BKT TOP - LH	TATA spare parts
206920140102	ASSY FAN RING MTG BKT TOP - RH	TATA spare parts
206920140103	BRACKET-LH(FOR FAN RING BOTTOM MTG)	TATA spare parts
206920140104	BRACKET-RH(FOR FAN RING BOTTOM MTG)	TATA spare parts
206920140105	ASSY FAN RING MTG BKT TOP - LH	TATA spare parts
206920140106	BRACKET-LH(FOR FAN RING BOTTOM MTG)	TATA spare parts
206920140107	BRACKET-RH(FOR FAN RING BOTTOM MTG)	TATA spare parts
206920140108	ASSY FAN RING MTG BKT TOP - RH	TATA spare parts
206920140109	ASSY BRACKET TOP-LH(FAN RING MOUNTING)	TATA spare parts
206920140113	ASSY BRACKET TOP-RH (FAN RING MOUNTING)	TATA spare parts
206920143801	FAN SHROUD RING(LPTA715TC)	TATA spare parts
206920143803	FAN SHROUD RING	TATA spare parts
206920143803AE	FAN SHROUD RING 715	TATA spare parts
206920147101	FAN SPACER	TATA spare parts
206923116303	RAW EDGE COGGED BELT	TATA spare parts
206923123302	BRACKETPERCAC COMP MTG	TATA spare parts
206950000106	RADIATOR FRAME	TATA spare parts
206950000117	FRAME RADIATOR MTG	TATA spare parts
206950000118	RADIATOR FRAME	TATA spare parts
206950000120	ASSY.RADIATOR MTG.FRAME-COMPL	TATA spare parts
206950000124	ASSY RADIATOR CROSS SE/SK 1615 TC	TATA spare parts
206950000125	ASSY RADIATOR CROSS SE/SK 1615 TC	TATA spare parts
206950000127	ASSY RADIATOR FRAME SE/SK 1615 TC	TATA spare parts
206950000128	ASSY RADIATOR MTG FRAME SE/SK 1615 TC	TATA spare parts
206950000132	ASSY RADIATOR MTG FRAME SE1613TC-EURO-2	TATA spare parts
206950000135	CROSS MEMBER RAD MTG SE/SK 1615 TC	TATA spare parts
206950000137	ASSY BRACKET RH SE/SK 1615 TC	TATA spare parts
206950000138	ASSY BRACKET LH SE/SK 1615 TC	TATA spare parts
206950000139	ASSY BKT COMPL-RH SIDE SUPPORT-RAD MTG	TATA spare parts
206950000140	ASSY BKT COMPL-LH SIDE SUPPORT-RAD MTG	TATA spare parts
206950000153	ASSY. RADIATOR MTG. FRAME-COMPL	TATA spare parts
206950000164	ASSY BRACKET-LH-SIDE MTG	TATA spare parts
206950000165	ASSY BRACKET-RH-SIDE MTG	TATA spare parts

206950000166	ASSY BRACKET-LH AWTANK MTG	TATA spare parts
206950000167	ASSY BRACKET-RH AWTANK MTG	TATA spare parts
206950000172	ASSY.RADIATOR MTG.FRAME-COMPLETE	TATA spare parts
206950000176	ASSY BRACKET LH(A.W.T MOUNTING)	TATA spare parts
206950000177	ASSY BRACKET RH (A.W.T MOUNTING)	TATA spare parts
206950000178	ASSY. RADIATOR MTG. FRAME-COMPLETE	TATA spare parts
206950003307	BRACKET RADIATOR MTG.	TATA spare parts
206950003308	BRACKET-R H (RADIATOR MTG)	TATA spare parts
206950003309	BRACKET-L H (RADIATOR MTG)	TATA spare parts
206950003314	SIDE-RAD MTG BRACKET	TATA spare parts
206950006001	STUD SE/SK 1615 TC	TATA spare parts
206950006004	BOLT SE/SK 1613 TC	TATA spare parts
206950006302	RUBBER MOUNTING SE/SK 1615 TC	TATA spare parts
206950006902	TUBE SE/SK 1615 TC	TATA spare parts
206950006903	TUBE SE/SK 1615 TC	TATA spare parts
206950006904	TUBE SE/SK 1613 TC	TATA spare parts
206950008268	BRACKET-RAD BOTTOM MTG	TATA spare parts
206950008269	BRACKET-RAD BOTTOM MTG	TATA spare parts
206950100128	RADIATOR ASSY	TATA spare parts
206950100132	ASSY.RADIATOR	TATA spare parts
206950100135	ASSY.RADIATOR-COMPLETE	TATA spare parts
206950100135AE	ASSY. RADIATOR 713	TATA spare parts
206950100139	ASSY.RADIATOR-COMPLETE	TATA spare parts
206950100141	ASSY.RADIATOR SE 1615TC	TATA spare parts
206950100143	FIRE WALL BRACKET SE/SK 1615 TC	TATA spare parts
206950100144	ASSY CROSS MEMBER SE/SK 1615 TC	TATA spare parts
206950100145	ASSY BRACKET RH SE/SK 1615 TC	TATA spare parts
206950100146	ASSY BRACKET LH SE/SK 1615 TC	TATA spare parts
206950100147	ASSY.RADIATOR-OFFER DRG.	TATA spare parts
206950100149	ASSY.RADIATOR-COMPLETE	TATA spare parts
206950100153	ASSY AUX. WATER TANK	TATA spare parts
206950100154	ASSY BKT - AUX W/T & RAD TOP	TATA spare parts
206950100155	ASSY RADIATOR SE/SK 1615 TC	TATA spare parts
206950100157	ASSY X-MEMBER - RAD MTG BOTTOM	TATA spare parts
206950100158	ASSY.RADIATOR-SE 1615TC	TATA spare parts
206950100160	RADIATOR ASSY SE 1613TC	TATA spare parts
206950100164	ASSY.RADIATOR-COMPLETE	TATA spare parts
206950100167	RADIATOR SUB ASSY.COMPLETE	TATA spare parts
206950100169	ASSY.RADIATOR-COMPLETE	TATA spare parts
206950100177	SET AUX.WATER TANK WITH BRACKET	TATA spare parts
206950100179	ASSY AUX WATER TANK-TRANSLUSCENT	TATA spare parts
206950100180	KIT RADIATOR & AUX WATER TANK COMPLETE	TATA spare parts
206950100182	ASSY RADIATOR & INTERCOOLAR SE1615_BSIII	TATA spare parts
206950100183	ASSY RADIATOR SE1615TCIC BSIII	TATA spare parts
206950100184	ASSY.RAD.WITH I/COOLER COMP	TATA spare parts
206950100184AE	ASSY.RDTR W/ I/CLR COMPL. -715	TATA spare parts
206950100185	ASSY . RADIATOR	TATA spare parts

206950100185AE	ASSY RADIATOR 715	TATA spare parts
206950100188	ASSY RESERVE TANK	TATA spare parts
206950100190	KIT RADIATOR INTERCOOLER & AUX WATERTANK	TATA spare parts
206950100194	ASSY MTG BKT ( AUX TANK COVER )	TATA spare parts
206950100197	ASSY RAD & IC WITH FRAME	TATA spare parts
206950100198	ASSY.RADIATOR BSIII	TATA spare parts
206950100203	ASSY.RADIATOR WITH I/COOLER COMP.	TATA spare parts
206950100204	ASSY. BRACKET (WATER FILL PIPE MTG)	TATA spare parts
206950100205	ASSY RADIATOR +IC FOR SD1015 BSIII	TATA spare parts
206950100205AE	ASSY RDTR +IC SD1015 -1415	TATA spare parts
206950100207	ASSY RADIATOR WITH FRAME	TATA spare parts
206950100208	ASSY RAD & IC WITH FRAME	TATA spare parts
206950100209	ASSY. RADIATOR 697TCIC/6BT BS3	TATA spare parts
206950100211	ASSY RADIATOR COMPLETE	TATA spare parts
206950100212	ASSY. FRAME	TATA spare parts
206950100213	KIT ENGINE COOLING SYSTEM	TATA spare parts
206950100253	ASSY RADIATOR	TATA spare parts
206950100255	RADIATOR ASSY - SA SAK 1212 BS3	TATA spare parts
206950100271	RADIATOR ASSY	TATA spare parts
206950100272	ENGINE COOLING SYSTEM ASSY	TATA spare parts
206950103302	STAY SUPPORT -AUX WATER TANK	TATA spare parts
206950103303	STAY SUPPORT -AUX WATER TANK	TATA spare parts
206950104203	CLAMP	TATA spare parts
206950105822	RUBBER HOSE	TATA spare parts
206950105823	RUBBER HOSE	TATA spare parts
206950105824	RUBBER HOSE-RAD. TO ENG. INLET	TATA spare parts
206950105825	RUBBER HOSE - RAD.TO ENG.	TATA spare parts
206950105826	HOSE ENGINE TO RADIATOR	TATA spare parts
206950105827	HOSE ENGINE TO RADIATOR	TATA spare parts
206950105828	RUBBER HOSE (RADIATOR TO ENGINE)SD1015TC	TATA spare parts
206950105829	HOSE RUBBER ENGINE TO RADIATOR	TATA spare parts
206950105830	RUBBER HOSE RAD.TO ENGINE	TATA spare parts
206950105831	HOSE(ENG.TO RADIATOR) LPTA 713/32TC	TATA spare parts
206950105834	RUBBER HOSE-RADIATOR VENT LPTA 713 TC	TATA spare parts
206950105835	RUBBER HOSE-ENG.VENT LPTA 713/32TC	TATA spare parts
206950105836	RUBBER HOSE (ENG. TO RAD.TOP)	TATA spare parts
206950105837	RUBBER HOSE (ENG. TO RAD.TOP)	TATA spare parts
206950105838	RUBBER HOSE -RAD TO ENG.	TATA spare parts
206950105839	HOSE-WATER FILLING - 1100 LONG	TATA spare parts
206950105840	VENT HOSE-520 LG	TATA spare parts
206950105844	RUBBER HOSE-RAD. TO TC	TATA spare parts
206950105849	R/HOSE-RAD TO ENGINE SAK1212/32 TC BS II	TATA spare parts
206950105852	RUBBER HOSE - RADIATOR TO ENGINE	TATA spare parts
206950105853	VENT HOSE-RAD TO AWT	TATA spare parts
206950105854	ELBOW HOSE-110X110	TATA spare parts
206950105855	REDUCER ELBOW SAK1212/32 TC BS II	TATA spare parts
206950105856	VENT HOSE (RAD TO ENGINE )	TATA spare parts

206950105862	RUBBER HOSE (RAD. TO ENG.)	TATA spare parts
206950105864	HOSE (ENGINE TOP)	TATA spare parts
206950105865	HOSE (RADIATOR TOP)	TATA spare parts
206950105865AE	HOSE (RADIATOR TOP)LPA 1415/	TATA spare parts
206950105876	RUBBER HOSE-ENGINE TO RAD	TATA spare parts
206950105877	RUBBER HOSE-ENGINE TO RAD	TATA spare parts
206950105878	RUBBER HOSE ENGINE TO RADIATOR	TATA spare parts
206950105879	HOSE (WATER FILL PIPE)	TATA spare parts
206950105880	HOSE (RAD UPPER TANK)	TATA spare parts
206950105881	HOSE(ENGINE COOLANT OUTLET)	TATA spare parts
206950105882	HOSE(RAD LOWER TANK)	TATA spare parts
206950105890	ELBOW HOSE	TATA spare parts
206950106301	RUBBER BUSH SE/SK 1615 TC	TATA spare parts
206950106901	WATER FILL PIPE (BOTTOM)	TATA spare parts
206950106904	PIPE RADIATOR BOTTOM TO ENGINE	TATA spare parts
206950106918	WATER FILLER PIPE SE/SK 1615 TC	TATA spare parts
206950106919	VENT TUBE ENG TO RADIATOR	TATA spare parts
206950106920	VENT TUBE SE/SK 1613	TATA spare parts
206950106921	WATER FILL PIPE-28.6X1500 LPTA 713 TC	TATA spare parts
206950106937	VENT TUBE-ENG TO AWT	TATA spare parts
206950106937AE	VENT TUBE-ENG TO AWTLPA 1415/	TATA spare parts
206950106940	WATER FILL PIPE	TATA spare parts
206950106945	WATER FILL PIPE	TATA spare parts
206950106946	VENT TUBE-ENG TO A W T	TATA spare parts
206950106947	VENT TUBE-RAD TO A W T	TATA spare parts
206950106955	WATER FILL PIPE	TATA spare parts
206950106957	PIPE (ENGINE TO RADIATOR)	TATA spare parts
206950106958	FILL PIPE(AWT TO RAD)	TATA spare parts
206950106965	PIPE WATER FILLER	TATA spare parts
206950106966	FILLER PIPE AUX WATER TANK TO RADIATOR	TATA spare parts
206950108206	AUX WATER TANK COVER	TATA spare parts
206950108257	BRACKET	TATA spare parts
206950108259	BRACKET SUPPORT PIPE BS6	TATA spare parts
206950110102	INTERCOOLER ASSY	TATA spare parts
206950115803	RUBBER HOSE ENGINE TO RADIATOR	TATA spare parts
206950115804	RUBBER HOSE WATER FILLER PIPE TO RAD	TATA spare parts
206950116904	PIPE RADIATOR TO ENGINE	TATA spare parts
206950125801	HOSE ENGINE TO RADIATOR TANK TOP	TATA spare parts
206950125802	HOSE RADIATOR TO ENGINE INTAKE	TATA spare parts
206950125807	HOSE ENGINE TO RADIATOR TANK TOP	TATA spare parts
206950136901	PIPE RADIATOR BOTTOM	TATA spare parts
206950400109	ASSY TIE ROD	TATA spare parts
206950400113	ASSY STAY ROD-RAD FRAME MTG	TATA spare parts
206950400114	ASSY.STAY ROD	TATA spare parts
206950400115	ASSY.STAY ROD (RADIATOR FRAME MTG)	TATA spare parts
206950400120	BRACKET ASSY RADIATOR BOTTOM MTG BS6	TATA spare parts
206950406901	TUBE RADIATOR MTG. SE/SK 1615 TC	TATA spare parts

206950500106	FAN SHROUD	TATA spare parts
206950500109	ASSY.FANSHROUD (508 FAN DIA ) SE/SK TC	TATA spare parts
206950506301	FAN SHROUD	TATA spare parts
206950506314	FAN SHROUD	TATA spare parts
206950506315	FAN SHROUD SE/SK/1613	TATA spare parts
206950506316	FAN SHROUD-LPTA-713 TC	TATA spare parts
206950506318	FAN SHROUD SD 1015 TC	TATA spare parts
206950506319	FAN SHROUD	TATA spare parts
206950506327	FAN SHROUD	TATA spare parts
206950506328	FAN SHROUD	TATA spare parts
206950506330	FAN SHROUD	TATA spare parts
206950506331	FAN SHROUD	TATA spare parts
206950506332	FAN SHROUD	TATA spare parts
206950506337	FAN SHROUD	TATA spare parts
206950506338	FAN SHROUD	TATA spare parts
206963	ADAPTER FILTER HEAD	TATA spare parts
207031000101	ASSY FRAME -LPO1510 CMVR 60% 330CL.	TATA spare parts
207042900103	SET ASSY.NYLON PIPE COMPLT.	TATA spare parts
207042900128	NYLON PIPE SET	TATA spare parts
207046800103	ASSY. TUBE WITH CRIMPED RUBBER HOSE TANK	TATA spare parts
207046800104	ASSY. TUBE WITH CRIMPED RUBBER HOSE PUMP	TATA spare parts
207046800105	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
207047600101	TUBE FUEL TANK TO WATER SEPERATOR	TATA spare parts
207047600102	TUBE WATER SEPERATOR TO FEED PUMP	TATA spare parts
207047600103	ASSY. TUBE-10 O.D. X 3450 LG.	TATA spare parts
207047600106	ASSY. STEEL TUBE-10 O.D. X 2825 LG.	TATA spare parts
207047800101	ASSY. BRACKET WATER SEPARATOR MTG.	TATA spare parts
207049200101	ASSY. EXHAUST PIPE	TATA spare parts
207054209901	INSTRUMENT CLUSTER-1:0.80-RHD	TATA spare parts
207054209916	INSTRUMENT CLUSTER (1:0.80)	TATA spare parts
207054209921	INSTRUMENT CLUSTER(1:0.80)E-SPEEDO	TATA spare parts
207054209922	INSTRUMENT CLUSTER (1:0.88) E-SPD	TATA spare parts
207054209923	INSTRUMENT CLUSTER(1:0.80)E-SPEEDO	TATA spare parts
207054620105	W/H-MAIN LPO-1510 697 BS-II AMMETER	TATA spare parts
207054820102	ASSY.CABLE SET-FRT.TO TAIL LAMP -60% ROH	TATA spare parts
207054820105	W/H MAIN-LPO 1510 CMVR-2000-OFFER	TATA spare parts
207054820106	W/H TAIL LPO1510 CMVR/55 50% ROH OFFER	TATA spare parts
207054820107	W/H TAIL LPO1510 CMVR/55 60% ROH OFFER	TATA spare parts
207054820109	W/H MAIN -LPO 1510 MOT.H/L.INST.CLUSTER	TATA spare parts
207054820112	W/H TAIL -W.B 55	TATA spare parts
207054821601	WIRING HARNESS MAIN	TATA spare parts
207058900601	CRANK SHAFT OIL SEAL PULLER	TATA spare parts
207058900602	CRANK SHAFT OIL SEAL FITMENT	TATA spare parts
207126800107	GEAR LEVER BRACKET LHD LPO1316	TATA spare parts
207142700101	ASSY PIPE 6 DIA X 1860 LG	TATA spare parts
207143400101	ASSY PIPE 6 DIA X 1920 LG	TATA spare parts
207152058203	BRACKET ANTISAGGING BAR	TATA spare parts



207160100105	ASSY COWL SHELL PAINTED LPO1510_53	TATA spare parts
207160100110	ASSY. COWL COMPLT. WITH FITMENTS.	TATA spare parts
207160100121	ASSY COWL SHELL PAINTED LPO 1510	TATA spare parts
207160100129	ASSY.COWL SHELL PAINTED W/O FACE -LHD	TATA spare parts
207160100131	ASSY.COWL FITTED W/O FACE-LPO 1316LHD	TATA spare parts
207160100165	LPO 1512TC COWL PAINTED- W/O FACE	TATA spare parts
207160100172	LPO 1512TC COWL FITTED W/O FACE	TATA spare parts
207160100173	ASSY.FITTED COWL FOR LPO 1313 CMVR 2000	TATA spare parts
207160100174	ASSY.COWL SHELL PAINTED LPO1512C W/O FAC	TATA spare parts
207160100178	ASSY.COWL COMPLT.FOR LPO1512 TC W/O FACE	TATA spare parts
207160100182	ASSY.COWL SHELL PAINTED W/O FACE-RHD	TATA spare parts
207160100199	ASSY.COWL FITTED LPT 1613TC E-II PS	TATA spare parts
207160100209	ASSY. COWL COMPLT WITH FITMENT-LHD	TATA spare parts
207160100210	ASSY.COWL SHELL PAINTED W/O FACE -LHD	TATA spare parts
207160100240	ASSY.COWLCOMPLTWITFITMENT-RHD	TATA spare parts
207160100261	ASSY COWL SHELL PAINTED-RHD	TATA spare parts
207160100268	ASSY. COWL SHELL PAINTED W/O FACE RHD	TATA spare parts
207160100282	ASSY COWL COMP WITH FITMENT W/O FACE RHD	TATA spare parts
207160100283	ASSY COWL SHELL PAINTED W/O FACE(BARE CO	TATA spare parts
207160100327	COWLASSYWITHFITMENT	TATA spare parts
207160106306	BALLATA& PACKING	TATA spare parts
207160107501	RUBBER GROMMET(PEDAL FLOOR)	TATA spare parts
207160108225	MOUNTING BRACKET RH SIDE(INST.CLUSTER)	TATA spare parts
207160110104	LPO1510TC W/OFACE(2.6M) COWL COMPLETE	TATA spare parts
207160110105	ASSY. COWL SHELL PAINTED W/O FACE-RHD	TATA spare parts
207160110107	ASSY. COWL FITTED- LP 1510TC W/FACE PS	TATA spare parts
207160110113	LPO 1510 BS II TC COMPLETE COWL	TATA spare parts
207160110119	ASSY.COWL COMPLT. W/FITMENT LPO1610TC	TATA spare parts
207160110120	COWL BARE LPO1610 TC RHD W/O FACE EUROII	TATA spare parts
207160110137	ASSY. COWL SHELL PAINTED-RHD	TATA spare parts
207160110163	ASSY COWL COMPLT WITH FITMENTS	TATA spare parts
207160110180	ASSY. COWL SHELL PAINTED W/O FACE RHD	TATA spare parts
207160110189	ASSY.COWL SHELL PAINTED LPO1510 BS-II W/	TATA spare parts
207160110190	ASSY.COWL COMP.FOR LPO1510 BS-II W/OFACE	TATA spare parts
207160110193	ASSY.COWL COMPLT.WITH FITMENT-RHD.	TATA spare parts
207160110194	ASSY.COWL SHELL PAINTED W/O FACE-RHD.	TATA spare parts
207160110208	ASSY COWL SHELL PAINTED W/O FACE RHD	TATA spare parts
207160110209	ASSY COWL SHELL PAINTED W/O FACE(BARE CO	TATA spare parts
207160110212	ASSY SEAT SUPPORT	TATA spare parts
207160120103	Z-BRACKET ASSY FUSE BOX MTG	TATA spare parts
207160120104	ASSY Z BRACKET(FUSE BOX MTG.)	TATA spare parts
207160120105	ASSY COWL SHELL COMPLT WITH FITMENTS RHD	TATA spare parts
207160120106	ASSY. COWL SHELL PAINTED	TATA spare parts
207160120115	ASSY.COWL SHELL PAINTED W/O FACE-RHD	TATA spare parts
207160120117	ASSY. COWL SHELL PAINTED W/O FACE-RHD	TATA spare parts
207160120134	ASSY.COWL COMPLT.WITH FITMENTS-RHD	TATA spare parts
207160120164	ASSY.COWL SHELL PAINTED W/O FACE RHD	TATA spare parts

207160120170	ASSY.COWL SHELL PAINTED W/O FACE RHD	TATA spare parts
207160120172	ASSY. BRACKET-RH (INSTRUMENT CLUSTER)	TATA spare parts
207160120173	ASSY.BRACKET(HAND BRAKE VALVE MTG.)	TATA spare parts
207160120174	ASSY.FES PAINTED RHD (TMML DESIGN)	TATA spare parts
207160120185	ASSY.COWL SHELL PAINTED W/O FACE -LHD	TATA spare parts
207160120186	ASSY. COWL COMPLT WITH FITMENT-LHD	TATA spare parts
207160120196	COWL COMPLETE WITH FITMENT	TATA spare parts
207160120259	ASSY INSTRUMENT CLUSTER MOUNTING BRACKET	TATA spare parts
207160120260	ASSY COWL SHELL PAINTED W/O FACE RHD	TATA spare parts
207161600195	ASSY.BRACKET(TWIN HORN MTG)	TATA spare parts
207168900101	ASSY.INSTRUMENT PANEL-RHD	TATA spare parts
207168900102	ASSY INSTRUMENT PANEL RHD	TATA spare parts
207168900103	INSTRUMENT PANNEL COVER	TATA spare parts
207168900104	ASSY. INSTRUMENT PANEL-RHD	TATA spare parts
207168900109	ASSY.COVER(FOR NEW INSTRU.PLASTIC COVER)	TATA spare parts
207168900111	ASSY NACELLE COMPLETE	TATA spare parts
207175200101	ASSY T EMBLEM(OVAL STYLISED)	TATA spare parts
207181100102	KIT FOR BONNET & PODEST INSULATION	TATA spare parts
207181107701	ASSY INSULATION (BONNET CENTER)	TATA spare parts
207181107702	ASSY INSULATION LH (BONNET SIDE)	TATA spare parts
207181107703	ASSY INSULATION RH (BONNET SIDE)	TATA spare parts
207181800101	ASSY TATA 1616 CUMMINS MASCOT	TATA spare parts
207181800103	ASSY. TATA 1512 CUMMINS MASCOT	TATA spare parts
207181800107	ASSY.TATA 1318 C MASCOT	TATA spare parts
207181800108	ASSYTATA 1612 C MASCOT	TATA spare parts
207181800110	ASSY TATA 1515 C MASCOT	TATA spare parts
207181800113	ASSY TATA 1823C MASCOT	TATA spare parts
207181808201	RADIATOR GRILLE	TATA spare parts
207181900105	ASSY ENGINE SIDE SHIELD LH	TATA spare parts
207181900107	ASSY ENGINE SIDE SHIELD LH RHD	TATA spare parts
207181900112	ASSY. ENGINE SIDE SHIELDING RH-RHD	TATA spare parts
207181900114	ASSY ENGINE SHIELDING LH-RHD	TATA spare parts
207181900116	ASSY ENGINE SHIELDING RH-RHD.	TATA spare parts
207181903301	BRACKET (SIDE SHIELD MTG.)	TATA spare parts
207181903302	L BRACKET FOR SIDE SHIELD RH-RHD.	TATA spare parts
207181903303	Z BRACKET FOR	TATA spare parts
207183400101	ASSY. BRKT FOR A/C COMPRESSOR MOUNTING	TATA spare parts
207188500101	ASSY.BUMPER STRAIGHT	TATA spare parts
207188500101C0	ASSY BUMPER WITH REFLECTOR - BLACK	TATA spare parts
207188500102	ASSY. ANTISAGGING BAR	TATA spare parts
207188500107	ASSY SUPPORT LH-FOR ANTI SAGGING BAR	TATA spare parts
207188500108	ASSY. SUPPORT-RH FOR ANTISAGGING BAR	TATA spare parts
207188500109	ASSY. ANTISAGGING BAR	TATA spare parts
207188500115	ASSY.ANTISAGGING BAR	TATA spare parts
207188500122	ASSY.BUMPER COMPLT.WITH REFLECTIVE TAPE	TATA spare parts
207188500125	ASSY.ANTISAGGING BAR	TATA spare parts
207188700101	ASSY ENGINE HOOD COMPLETE-RHD	TATA spare parts

207189100101	ASSY. BRACKET LH COWL MTG. REAR	TATA spare parts
207189100103	ASSY. MTG BRKT 5TH MTG	TATA spare parts
207189100104	ASSY BRACKET LH (COWL MTG REAR)	TATA spare parts
207189100105	ASSY BRACKET RH (COWL MTG REAR)	TATA spare parts
207189100111	ASSY BRACKET LH (COWL MTG. FRONT)	TATA spare parts
207189100112	ASSY BRACKET RH(COWL MTG.FRONT)	TATA spare parts
207189100113	ASSY BRACKET LH(COWL MTG.REAR).	TATA spare parts
207189100114	ASSY BRACKET RH(COWL MTG.REAR).	TATA spare parts
207189100119	ASSY BRACKET-RH(COWL MTG.REAR)	TATA spare parts
207189100120	ASSY BRACKET LH(COWL MTG.REAR)	TATA spare parts
207189100121	ASSY BRACKET LH(COWL MTG.FRONT)	TATA spare parts
207189100122	ASSY. OUTRIGGER-RH(COWL MTG.FRONT)	TATA spare parts
207189100123	4TH LEAF	TATA spare parts
207189107701	PACKING(5TH MTG)-COWL MTG.	TATA spare parts
207189107702	PACKING REAR (COWL MTG.)	TATA spare parts
207189107703	PACKING FRONT (COWL MTG.)	TATA spare parts
207191000101	ASSY.DRIVERS SEAT KNITTED TYPE	TATA spare parts
207198800148	BRACKET (WIPER MOTOR)	TATA spare parts
207198808252	BRACKET(WIPER MOTOR)	TATA spare parts
207301000102	ENGINE (130HP) 24V BS-III HIGH TORQUE	TATA spare parts
207301000105	ENGINE-130HP 24V BS-IV-LCCR	TATA spare parts
207301000132	ENGINE 130HP AUTO DRAIN	TATA spare parts
207301000133	ENGINE ASSY 155HP AUTO DRAIN	TATA spare parts
207309130103	RESTRICTION INDICATOR PIPE ASSY	TATA spare parts
207324200102	ASSY BKT LH-ENGINE MTG.TOP	TATA spare parts
207324200103	ASSY BKT-ENGINE MTG. BOTTOM	TATA spare parts
207324200105	ASSY.BKT.RH. ENGINE MTG.TOP	TATA spare parts
207324200107	ASSY. RUBBER SUPPORT-REAR	TATA spare parts
207324200116	BRACKET ASSY FRAME SIDE LH	TATA spare parts
207324200118	BRACKET ASSY;ENGINE MOUNT;REAR TOP LH	TATA spare parts
207324200119	BRACKET ASSY ENGINE MOUNT REAR TOP RH	TATA spare parts
207324200120	BRACKET ASSY;ENGINE MTG;REAR BOTTOM LH	TATA spare parts
207324200121	BRACKET ASSY;ENGINE MTG;REAR BOTTOM RH	TATA spare parts
207324200122	BRACKET ASSY FRAME SIDE RH	TATA spare parts
207324200124	BRACKET ASSY ENGINE MTG TOP REAR-LH	TATA spare parts
207324200125	BRACKET ASSY ENGINE MTG TOP REAR-RH	TATA spare parts
207326800105	GEAR LEVER BRACKET LHD LPO1512	TATA spare parts
207326800106	ASSY.HOUSING BLOCK	TATA spare parts
207326800110	ASSY HOUSING BLOCK	TATA spare parts
207326800111	ASSY BRACKET	TATA spare parts
207326800113	ASSY.TURNING TUBE R.H.D	TATA spare parts
207326800117	ASSY. TURNING TUBE	TATA spare parts
207326800123	ASSY BRACKET	TATA spare parts
207326800124	ASSY TURNING TUBE(WITHOUT BALL JOINT)	TATA spare parts
207326800127	ASSY BRACKET(FOR GEAR SHIFT LEVER).	TATA spare parts
207326800128	ASSY. TURNING TUBE (W/O BALL JOINT)	TATA spare parts
207326800131	ASSY.GEAR SHIFT LEVER	TATA spare parts

207326860101	BRACKET ASSY GEAR SHIFT LEVER MTG	TATA spare parts
207329000101	ASSY KIT CLUTCH CONTROL FOR RETRO FIT	TATA spare parts
207329100102	ASSY. TUBE 6 O.D. X 2060 LG.	TATA spare parts
207329100104	ASSY. TUBE (6 O.D. X 935 LG.)	TATA spare parts
207329100105	ASSY. CONNECTING LINE FOR HYD. CLUTCH	TATA spare parts
207329100106	ASSY. CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
207329100118	ASSY CONTROL MOUNTING BRACKET WITH TUBE	TATA spare parts
207329100124	ASSY BRACKET FOR CB MTG	TATA spare parts
207329100125	ASSY TUBE WITH LEVER	TATA spare parts
207329100126	ASSY PULL ROD	TATA spare parts
207329100135	PIPE ASSY (CB TO M-CYL)	TATA spare parts
207329100136	PIPE ASSY (CB TO M-CYL)	TATA spare parts
207329100140	HYD PIPE& ASSY JOINT TO CLUTCH BOOSTER	TATA spare parts
207329100142	CLUTCH CONTROL MTG ASSY	TATA spare parts
207329100144	HYD PIPE ASSY MASTER CLY TO HOSE	TATA spare parts
207329100145	HYD PIPE ASSY JOINT TO CLUTCH BOOSTER	TATA spare parts
207329100146	BUNDY TUBE ASSY CLUTCH PIPE	TATA spare parts
207329106701	PIN	TATA spare parts
207329108601	THRUST WASHER	TATA spare parts
207329500102	ASSY.SUPPORT PEDAL WITH TUBE	TATA spare parts
207329500105	ASSY BRACKET	TATA spare parts
207329500106	ASSY. BRACKET-FOR M/CYL.MTG.	TATA spare parts
207330100101	ASSY. BRACKET (FOR SPEED LIMITER)	TATA spare parts
207330100102	BRACKET ASSY ACCELERATOR PEDAL	TATA spare parts
207330100110	ASSY. BRACKET	TATA spare parts
207330100111	ASSY. CONTROL SHAFT	TATA spare parts
207330100116	ASSY. CONTROL BKT.	TATA spare parts
207330100117	ASSY. CONTROL SHAFT	TATA spare parts
207330100123	BRACKET ASSY FOR ACC. PEDAL MTG.	TATA spare parts
207330100132	ACCELERATOR CABLE ASSY	TATA spare parts
207330100133	CLAMP ACCELERATOR CABLE MTG	TATA spare parts
207330101601	PLASTIC COVER(ACCELERATOR PEDAL)	TATA spare parts
207330103302	BRACKET	TATA spare parts
207330108701	FIP LEVER SPRING	TATA spare parts
207330990101	RETRO KIT PARTIAL CABLE WITH BKT LPO1512	TATA spare parts
207331000101	ASSY FRAME COMP.	TATA spare parts
207331000103	ASSY.FRAME-LPO1613TC-CAR CARRIER	TATA spare parts
207331000104	ASSY FRAME LPO 1512/55 50%ROH TC PSTG	TATA spare parts
207331000107	ASSY. FRAME COMPLETE-LPO 47 W.B	TATA spare parts
207331000108	ASSY.FRAME COMPLETE LPO 1510TC/55 60%	TATA spare parts
207331000109	ASSY.FRAME COMPLETE LPO55 50%	TATA spare parts
207331000110	ASSY. FRAME COMPLETE-LPO 55W.B/CAR CAR	TATA spare parts
207331000113	ASSY FRAME LPO 1512/53 60% ROH TC PSTG	TATA spare parts
207331000118	ASSY.FRAME COMPLETE-LPO 55 W.B/60%ROH	TATA spare parts
207331000120	ASSY.FRAME COMPLETE (LPO 1512TC/53)	TATA spare parts
207331000121	ASSY.FRAME COMPLETE( 50% ROH) - CAR CARR	TATA spare parts
207331000125	ASSY FRAME LPO1512(JNNURM)WITH OUTRIGGE	TATA spare parts

207331000128	ASSY. FRAME COMPLETE WEVELLER SUSPENSION	TATA spare parts
207331000129	ASSY FRAME COMPLETE	TATA spare parts
207331000131	ASSY FRAME FRONT WEVELLER REAR PNEUMATIC	TATA spare parts
207331000133	ASSY FRAME COMPLETE (LPO 1512 WEVELLER)	TATA spare parts
207331000134	ASSY FRAME LPO TC/55 (LEAF+P/N SUSP)	TATA spare parts
207331000135	ASSY FRAME. LPO 1512TC/58 BS-III	TATA spare parts
207331000140	FRAME ASSY	TATA spare parts
207331000142	FRAME ASASY COMPLETE (TMML WEVELLER)	TATA spare parts
207331000149	ASSY FRAME COMPLETE LPO1512/58WB	TATA spare parts
207331000151	ASSY FRAME COMPLETE	TATA spare parts
207331000152	ASSY. FRAME COMPLETE	TATA spare parts
207331000153	ASSEMBLY FRAME WITHOUT OUTRIGGERS	TATA spare parts
207331000155	FRAME ASSY COMPLETE NORMAL SUSPENSION	TATA spare parts
207331000161	FRAME ASSY WITH FITMENT	TATA spare parts
207331200103	ASSY. ENG. C/M FRONT	TATA spare parts
207331200106	ASSY CROSS MEMBER SHK ABSORBER	TATA spare parts
207331200112	ALLIGATED CROSS MEMBER ASSY	TATA spare parts
207331200115	ASSY CROSS MEMBER	TATA spare parts
207331200116	CROSS MEMBER ASSY. (REAR SUSPENSION)	TATA spare parts
207331207104	REINFORCEMENT-RH (BOTTOM-FRONT)	TATA spare parts
207331207105	REINFORCEMENT-LH (BOTTOM-FRONT)	TATA spare parts
207331207106	REINFORCEMENT-RH (BOTTOM-REAR)	TATA spare parts
207331207107	REINFORCEMENT-LH (BOTTOM-REAR)	TATA spare parts
207331207108	REINFORCEMENT RH (TOP)	TATA spare parts
207331207109	REINFORCEMENT-LH (TOP)	TATA spare parts
207331207110	SUPPORT-ENG. MTG. C/M FRONT	TATA spare parts
207331207113	REINFORCEMENT FRONT RH (BOTTOM)	TATA spare parts
207331207114	REINFORCEMENT FRONT LH (BOTTOM)	TATA spare parts
207331207117	GUSSET RH	TATA spare parts
207331207118	GUSSET LH	TATA spare parts
207331207119	SUPPORT (ENG. MTG. C/M FRONT)	TATA spare parts
207331207124	SPACER FRONT - 7MM-LH	TATA spare parts
207331207126	END CROSS MEMBER	TATA spare parts
207331207146	SUPPORT C/M FRONT(LH)	TATA spare parts
207331207147	SUPPORT CM/ FRONT (RH)	TATA spare parts
207331208201	GUSSET RH	TATA spare parts
207331208202	GUSSET LH	TATA spare parts
207331307105	REINFORCEMENT TOP-RH	TATA spare parts
207331307106	REINFORCEMENT TOP-LH	TATA spare parts
207331307111	SUPPORT (SPRING CROSS MEMBER)	TATA spare parts
207331307112	PACKING PLATE (CROSS MEMBER BOTTOM)	TATA spare parts
207331307113	PACKING PLATE (CROSS MEMBER TOP)	TATA spare parts
207331308202	CROSS MEMBER (REAR SPRING)	TATA spare parts
207331700102	ASSY ENGINE SHIELDING BOTTOM	TATA spare parts
207331700105	ASSY.BOTTOM SHIELD GEAR BOX	TATA spare parts
207331700108	ASSY OUTRIGGER III (LH)	TATA spare parts
207331700109	ASSY OUTIGGER -III	TATA spare parts

207331700110	ASSY OUTRIGGER (7TH CM) LPO 1512 JNNURM	TATA spare parts
207331700115	ASSY OUTRIGGER-2 (FRONT LH SIDE)	TATA spare parts
207331700116	ASSY OUTRIGGER-3 (FRONT LH SIDE)	TATA spare parts
207331700117	ASSY OUTRIGGER-4 (FRONT RH-SIDE)	TATA spare parts
207331700118	ASSY OUTRIGGER -1	TATA spare parts
207331700122	ASSY OUTRIGGER (FRONT DOOR)	TATA spare parts
207331700123	ASSY OUTRIGGER (FRONT LH SIDE)	TATA spare parts
207331700124	OUTRIGGER ASSY-LH (FRONT WHEEL ARC)	TATA spare parts
207331700125	OUTRIGGER ASSY-RH (FRONT WHEEL ARC)	TATA spare parts
207331700126	ASSEMBLY OUTRIGGER (FUEL TANK)	TATA spare parts
207331707202	TOE HOOK	TATA spare parts
207331708201	BRACKET ( ENG SHIELD )	TATA spare parts
207331708202	SUPPORT BRACKET - LH ( G/B SHIELD )	TATA spare parts
207331708203	SUPPORT BRACKET - RH ( G/B SHIELD )	TATA spare parts
207331708208	BRACKET	TATA spare parts
207332000102	KIT FOR RETRO FITMENT - LPO1512TC ARMY	TATA spare parts
207332000105	KIT FOR REAR PNEUMATIC SUSPENSION	TATA spare parts
207332100102	ASSY. FRONT SPRING-LH	TATA spare parts
207332104203	SPRING CLIP	TATA spare parts
207332104204	SPRING CLIP	TATA spare parts
207332300103	ASSY. BRACKET LH SHOCK ABS. MTG.	TATA spare parts
207332300104	ASSY. BRACKET RH SHOCK ABS. MTG.	TATA spare parts
207332400102	ASSY. REAR SPRING BS2/3/4	TATA spare parts
207332400103	FRONT AIR SPRING CROSS MEMBER ASSY	TATA spare parts
207332400104	REAR AIR SPRING CROSS MEMBER CROSS BEAM	TATA spare parts
207332400105	ANTI ROLL BAR HANGER LINK PIVOT BKT-LH	TATA spare parts
207332400106	ANTI ROLL BAR HANGER LINK PIVOT BKT-RH	TATA spare parts
207332400107	REAR AIR SPRING BRACKET-LH	TATA spare parts
207332400108	REAR AIR SPRING BRACKET-RH	TATA spare parts
207332400109	PARALLEL LINK PIVOT & AIR SPRING BKT ASS	TATA spare parts
207332400110	PARALLEL LINK PIVOT & AIR SPRING BKT ASS	TATA spare parts
207332400111	CONNECTING ROD ASSY	TATA spare parts
207332400112	SUBFRAME ANTI ROLL BAR SUB ASSY	TATA spare parts
207332400116	LINK CHANNEL MTG BKT	TATA spare parts
207332406701	TAPER PIVOT BOLT	TATA spare parts
207332406901	TAPER SLEEVE	TATA spare parts
207332407101	REAR FLITCH LH	TATA spare parts
207332407102	REAR FLITCH RH	TATA spare parts
207332407103	REAR AIR SPRING CROSS MEMBER FLITCH-LH	TATA spare parts
207332407104	REAR AIR SPRING CROSS MEMBER FLITCH-RH	TATA spare parts
207332407105	BRACKET SUSPENSION PIPE INLET CONNECTOR	TATA spare parts
207332950101	NYLON PIPE BUNCH ASSY RR AIR SUSPENSION	TATA spare parts
207333000105	ASSY FRONT AXLE COMPLETE	TATA spare parts
207333000106	ASSY FRONT AXLE COMPLETE	TATA spare parts
207333000107	FRONT AXLE ASSY WITH CGT BRAKES 825 SCD	TATA spare parts
207340100105	ASSY. WHEEL RIM BS2/3/4	TATA spare parts
207340100107	ASSY WHEEL RIM	TATA spare parts

207340100122	ASSY WHEEL RIM 7.5 X 20	TATA spare parts
207340100126	WHEEL RIM ASSY	TATA spare parts
207340100128	WHEEL RIM ASSY.	TATA spare parts
207340100132	ASSY WHEEL RIM 7.0 X 20	TATA spare parts
207340100139	WHEEL RIM ASSY WITH VALVE BS6-PH2	TATA spare parts
207340100140	WHEEL RIM ASSY WITH VALVE BS6-PH2	TATA spare parts
207340109905	LOCK RING	TATA spare parts
207340109906	FLANGE RING	TATA spare parts
207340109907	LOCKING RING (FOR 3 PIECE WHEEL DISC)	TATA spare parts
207340109908	FLANGE RING	TATA spare parts
207340150101	ASSY.FLAP 10.00R20	TATA spare parts
207340300101	CAGE TYPE SPARE WHEEL CARIEER.	TATA spare parts
207340300104	ASSY. BKT (LH)FOR CAGE TYPE SWC MTG	TATA spare parts
207340300105	ASSY. BKT (RH) FOR CAGE TYPE SWC MTG.	TATA spare parts
207341100101	ASSY PROPELLOR SHAFT	TATA spare parts
207341100105	ASSY. PROP.SHAFT REAR COMPLETE	TATA spare parts
207341100108	ASSY PROPELLER SHAFT FRONT	TATA spare parts
207341100110	ASSY KIT PROP.SHAFT	TATA spare parts
207341100111	ASSY. PROP.SHAFT WITH CENTER BRG. FRONT	TATA spare parts
207341100115	ASSY.PROP.SHAFT WITH CEN.BRG.MIDDLE	TATA spare parts
207341100122	ASSY. PROP.SHAFT WITH C.B FRONT(L=1922)	TATA spare parts
207341100133	ASSY PROP SHAFT WITH CB MIDDLE (L= 1474)	TATA spare parts
207341100135	ASSY FIRST PROP SHAFT	TATA spare parts
207341100136	ASSY PROP SHAFT MIDDLE	TATA spare parts
207341100137	BRACKET-PROP SHAFT GUARD MTG	TATA spare parts
207341100141	ASSY.FRONT PROP.SHAFT	TATA spare parts
207341100144	ASSY. GUARD PPROP.SHAFT	TATA spare parts
207341100146	ASY PROP SFT1ST 837L 101X130-8 1	TATA spare parts
207341100148	ASY PROP SFT1ST C10949L 101X130-8 1	TATA spare parts
207341100149	ASSY PROP SHAFT 1ST	TATA spare parts
207341100150	ASY PROP SFT 1ST	TATA spare parts
207341100152	ASY PROP SFT1ST 1623L 101X130-8	TATA spare parts
207341100154	ASY PROPELLER SHAFT 1ST 1869L	TATA spare parts
207341100155	ASSY PROPELLER SHAFT 1ST 1892L	TATA spare parts
207341100168	ASY PROP SFT1ST 1882 101X130-8	TATA spare parts
207341100171	ASY PROP SHAFT 1ST 1739L 100X130-8	TATA spare parts
207341100172	ASY PROP SFT 2ND 1623L 100X130-8	TATA spare parts
207341100173	ASSY PROP.SHAFT 1129L 100X130-8 MIDDLE	TATA spare parts
207341100174	ASSY PROP SFT FRT 1725L 100X130-8	TATA spare parts
207341100175	ASSY PROP.SHAFT L-665	TATA spare parts
207341100178	ASSY PROP.SHAFT 953L 100X130-8	TATA spare parts
207341100179	ASY PROP.SHAFT 949L 100X130-8	TATA spare parts
207341100181	PROPELLER SHAFT ASSY WITH CENTRE BEARING	TATA spare parts
207341100190	PROP.SHAFT FRT.1882L 100X130-8	TATA spare parts
207341100191	ASSY PROP SHAFT	TATA spare parts
207341103308	CENTER BEARING BRACKET-I	TATA spare parts
207341108205	GUARD PROPELLER SHAFT	TATA spare parts

207341109201	HARDENED WASHER I.D. 13	TATA spare parts
207341109903	HEX NUT (FOR FRT AND MIDDLE PROP SHAFT)	TATA spare parts
207341109904	SHORT FORK TUBE & FRONT END PIECE SUB AS	TATA spare parts
207341109905	SHORT FORK TUBE & FRONT END PIECE SUB AS	TATA spare parts
207341110108	COUPLING FLANGE DUST COVER ASSY BS6	TATA spare parts
207341110115	ASSY PROP SHAFT L-1778 DIA100	TATA spare parts
207341110116	ASSY PROP SHAFT L-1126 DIA100	TATA spare parts
207341115101	COUPLING FLANGE DUST COVER ASSY(FOR FRT	TATA spare parts
207341120102	ASSY PROP SHAFT COMP REAR(L=1720-1744)	TATA spare parts
207341120104	ASSY.PROP.SHAFT COMP.REAR	TATA spare parts
207341120117	ASSY REAR PROP SHAFT	TATA spare parts
207341120119	ASSY. SHORT FORK/ TUBE / REAR HOUSING	TATA spare parts
207341120121	ASY PROP SFT REAR 1218L 101X130-8 1	TATA spare parts
207341120122	ASY PROP SFT REAR	TATA spare parts
207341120125	ASSY PROP SHAFT REAR	TATA spare parts
207341120127	ASY PROP SFT REAR 1722L 101X130-8 1	TATA spare parts
207341120128	ASY PROP SFT REAR 1732L 101X130-8 1	TATA spare parts
207341120130	ASSY PROPELLER SHAFT REAR 1876L	TATA spare parts
207341120139	ASSY PROP SFT REAR 1678L 100X130-8	TATA spare parts
207341120141	ASY PROP SFT REAR 1519 100X130-8	TATA spare parts
207341120142	ASY PROP SFT REAR 1537 100X130-8	TATA spare parts
207341120144	ASSY PROP SFT REAR 1697L 100X130-8	TATA spare parts
207341120145	ASSY PROP SFT REAR 1722L 100X130-8	TATA spare parts
207341120146	ASSY PROP SFT REAR 1732L 100X130-8	TATA spare parts
207341120147	ASY PROP SFT REAR 1860L 100X130-8	TATA spare parts
207341120165	ASSY PROP SFT REAR L-1722-100X130-8	TATA spare parts
207341120166	SHORT FORKTUBE REAR HOUSING ASSY	TATA spare parts
207341120175	ASSY REAR SHAFT L-1655 DIA 100	TATA spare parts
207341129904	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
207341300101	LONG FORK SUB ASSY.	TATA spare parts
207341300102	CENTERBEARINGASSY	TATA spare parts
207341300103	SLIP YOKE ASSY BS6	TATA spare parts
207341303101	CENTER BEARING BS6	TATA spare parts
207341303304	BRACKET -CENTER BEARING	TATA spare parts
207341303305	BRACKET -CENTER BEARING -II	TATA spare parts
207341303306	BRACKET CENTER BEARING MTG.-II	TATA spare parts
207341303307	ASSY CENTER BEARING BRACKET-II	TATA spare parts
207341303311	BRACKET FOR CENTER BEARING MTG.-I	TATA spare parts
207341303312	BRACKET FOR CENTER BEARING MTG.-II	TATA spare parts
207341303319	CENTER BRG. MTG. BRKT	TATA spare parts
207341303320	CENTER BRG. MTG. BRKT	TATA spare parts
207341303321	CENTER BRG. MTG. BRKT	TATA spare parts
207341303322	CENTER BRG. MTG. BRKT	TATA spare parts
207341303323	BRACKET 1ST CENTER BRG MTG	TATA spare parts
207341303324	BRACKET 2ND CENTER BRG MTG	TATA spare parts
207341304201	BOOT CLAMP OUTER BS6	TATA spare parts
207341304301	ASSY. CENTER BEARING (FRT & MID) BS3/4	TATA spare parts



207341307701	BOOT	TATA spare parts
207341308201	BEARINGRETAINER	TATA spare parts
207341308202	BOOTCANASSEMBLY	TATA spare parts
207341400101	ASSY.SHORT FORK TUBE & FRT END PIECE(FOR	TATA spare parts
207341400102	ASSY.SHORT FORK TUBE & FRT END PIECE(FOR	TATA spare parts
207341400103	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
207341400105	SHORT FORKTUBE & FRONT END PIECE	TATA spare parts
207341400106	SHORT FORK TUBE & FRONT END PIECE	TATA spare parts
207341400108	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
207341400110	ASSY.SHORT FORK TUBE & FRT END PIECE	TATA spare parts
207341400111	SHORT FORK TUBE & FRONT END PIECE	TATA spare parts
207341400119	SHORT FORK TUBE & FRONT END PIECE	TATA spare parts
207341400120	SHORT FORK TUBE & FRONT END PIECE ASSY (	TATA spare parts
207341500101	SHORT FORK TUBE REAR HOUSING ASSY.	TATA spare parts
207341500103	SHORT FORKTUBE REAR HOUSING ASSY.	TATA spare parts
207341500104	SHORT FORK TUBE REAR HOUSING ASSY	TATA spare parts
207341500107	SHORT FORK	TATA spare parts
207341500108	SHORT FORK TUBE REAR HOUSING ASSY.	TATA spare parts
207341500109	SHORT FORK TUBE REAR HOUSING ASSY.	TATA spare parts
207341500110	SHORT FORKTUBE REAR HOUSING ASSY.	TATA spare parts
207341990102	RETRO KIT-PROP SHAFT CB MTG BKT	TATA spare parts
207342700102	ASSY TUBE 6 X 1990	TATA spare parts
207342700103	ASSY TUBE 6 X 1180	TATA spare parts
207342700104	ASSY.TUBE 6 O.D. X 300 LG.	TATA spare parts
207342900105	ASSY.TUBE 15 O.D. X 1570 LG.	TATA spare parts
207342900106	ASSY.TUBE 15 O.D. X 2700 LG.	TATA spare parts
207342900122	ASSY.TUBE 15 O.D. X 1380 LG.	TATA spare parts
207342900140	ASSY.TUBE WITH CRIMPED R/HOSE (AIR DUCT	TATA spare parts
207342900141	ASSY.TUBE(WITH CRIMPED R/HOSE COMPLETE)	TATA spare parts
207342900142	ASSY. TUBE (15 O.D. X 3230 LG.)	TATA spare parts
207342900151	ASSY TUBE ( 12 O.D. X 2320 LG.) LPK2516	TATA spare parts
207342900159	SET ASSY.NYLON PIPES COMPL.	TATA spare parts
207342900179	SET ASSY. NYLON PIPE COMPL.	TATA spare parts
207342900183	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
207342900184	ASSY TUBE(15 O.D X 1020 LG)	TATA spare parts
207342900202	QRV MOUNTING BRACKET	TATA spare parts
207342903304	Z-BRACKET	TATA spare parts
207342903309	BRACKET	TATA spare parts
207342906802	ELBOW 1510CNG	TATA spare parts
207342910104	ASSY.PIPE-1890 LG.(FROM COMPRESSOR)	TATA spare parts
207342910105	ASSY.PIPE-1330 LG.(TO AIR DRYER)	TATA spare parts
207343200101	ASSY TUBE 6 X 1750	TATA spare parts
207343200125	ASSY AIR TANK COMP 30 LTR (VOSS+VOSS)	TATA spare parts
207343200126	ASSY AIR TANK COMP 30 LTRS (VOSS+MET)	TATA spare parts
207343200130	AIR TANK ASSY	TATA spare parts
207343200131	AIR TANK ASSY	TATA spare parts
207343200132	AIR TANK ASSY 30 LTR (V+V)	TATA spare parts

207343200137	AIR TANK ASSY 30 LTR (V+V)	TATA spare parts
207343200138	AIR TANK ASSY 30 LTR (V+M)	TATA spare parts
207343200148	AIR TANK ASSY 30 LTR WITH BKT (V+M)	TATA spare parts
207343200156	AIR TANK ASSY 254 PITCH(V+M) FRONT	TATA spare parts
207343700170	KIT DUAL TREADLE VALVE	TATA spare parts
207343700186	AIR DRYER WITHOUT PR PORT	TATA spare parts
207343700187	HAND BRAKE VALVE SELF RETURN	TATA spare parts
207343700216	AIR DRYER 9 BAR(ASP+)	TATA spare parts
207343700217	AIR DRYER CARTRIDGE ASP+	TATA spare parts
207343700223	KIT QRV SPARE	TATA spare parts
207343700230	REPAIR KIT FOR QUICK RELEASE VALVE	TATA spare parts
207343700273	DUAL TREADLE VALVE	TATA spare parts
207343703301	BRACKET	TATA spare parts
207343703302	BRACKET ABS MODULATOR MTG	TATA spare parts
207343706801	COUPLING BODY M36X2 PIPE ENDS	TATA spare parts
207343709901	CONNECTOR	TATA spare parts
207343900107	ASSY. TUBE (15 O.D X 2640 LG.)	TATA spare parts
207343900108	ASSY. TUBE (15 O.D X 2810 LG.)	TATA spare parts
207343900109	SET ASSY NYL PIPE COMP LPO1512 LHD	TATA spare parts
207343900113	SET ASSY NYL PIPE COMP TF LPO1512TC-VOSS	TATA spare parts
207343900127	SET ASSY NYL PIPE LPO1512/LHD VOSS	TATA spare parts
207343900130	ASSY.TUBE 18 O.D. X 1570 LG.	TATA spare parts
207343900131	ASSY.TUBE 18 O.D. X 1890 LG.	TATA spare parts
207343900132	ASSY.TUBE 18 O.D. X 1330 LG.	TATA spare parts
207343900135	SET ASSY NYL W/PLASTIC VOSS CONNET.	TATA spare parts
207343900137	SET ASY NYL W/PLATIC VOSS LPO1512TC	TATA spare parts
207343900139	KIT SET ASSY NYL PIPE-P/N SUSP(1512)	TATA spare parts
207343900140	KIT SET ASSY NYL PIPE-P/N SUSP(1512)	TATA spare parts
207343900158	ASSY FIRST PIPE (DIA 18)-1512 JNNURM	TATA spare parts
207343900159	ASSY SECOND PIPE (DIA 18)-1512 JNNURM	TATA spare parts
207343900160	ASSY THIRD PIPE (DIA 18)-1512 JNNURM	TATA spare parts
207343900161	SET ASSY NYL PIPE COMP LPO1512-RHD	TATA spare parts
207343900162	ASSY FOURTH PIPE (DIA 18)	TATA spare parts
207343900163	METAL PIPELINE WITH CRIMPED TEFLON HOSE	TATA spare parts
207343900174	SET ASSEMBLY NYL.W/PLASTIC VOSS	TATA spare parts
207343900176	SET ASSY. NYL. PLASTIC PIPE	TATA spare parts
207343900178	CLUTCH PIPE	TATA spare parts
207343900180	SUB ASSY.AIR TANK COMP-VOSS(230 SCD)	TATA spare parts
207343900181	ASSY. PIPE	TATA spare parts
207343900183	SET ASSY NYL PIPE COMP	TATA spare parts
207343900185	ASSY. PIPE	TATA spare parts
207343900187	ASSY THIRD PIPE (DIA 18)	TATA spare parts
207343900189	ASSY FIRST PIPE (18 DIA) WITH CRIMPED HO	TATA spare parts
207343900190	ASSY SECOND PIPE (18 DIA)	TATA spare parts
207343900191	ASSY THIRD PIPE (18DIA)	TATA spare parts
207343900192	ASSY FOURTH PIPE(18 DIA) OIL SEPERATOR T	TATA spare parts
207343900195	THIRD PIPE (18 DIA) TO OIL SERPARATOR	TATA spare parts

207343900196	FOURTH PIPE (18 DIA) OIL SEPERATOR TO AI	TATA spare parts
207343900198	SUB ASSY AIR TANK	TATA spare parts
207343900199	ASSY AIR TANK COMPLETE	TATA spare parts
207343900201	SET ASSY NYLON PIPE COMPLETE	TATA spare parts
207343900203	ASSY NYLON PIPE BUNCH COMPLET	TATA spare parts
207343900204	ASSY NYLON BUNCH COMPLETE LPO1512TC/58	TATA spare parts
207343900206	SET ASSY NYLON PIPE FOR LPO 1512 TC ARMY	TATA spare parts
207343900210	ASSY PIPE(18 DIA)-COMP TO OIL SEP	TATA spare parts
207343900211	ASSY PIPE(18 DIA)-OIL SEP TO AIR DRYER	TATA spare parts
207343900212	ASSY.6 DIA PIPE FOR EXHAUST BRAKE VALVE	TATA spare parts
207343900216	ASSY.PIPE-THIRDç METAL PIPE	TATA spare parts
207343900229	ASSY.NYLON PIPE BUNCH FOR LPO 1512/55 TC	TATA spare parts
207343900230	ASSY METAL PIPELINE CRIMPED TEFLON HOSE	TATA spare parts
207343900235	ASSY NYLON BUNCH LPO 1512/53 WB TNSTC	TATA spare parts
207343900237	ASSY METAL PIPELINE CRIMPED TEFLON HOSE	TATA spare parts
207343900238	SET ASSY NYLON PIPE FOR LPO 1512	TATA spare parts
207343900241	SET ASSY NYLON PIPE BUNCH	TATA spare parts
207343900242	NYLON PIPE	TATA spare parts
207343900248	METAL PIPE ASSY SECOND	TATA spare parts
207343900249	METAL PIPE ASSY THIRD	TATA spare parts
207343900250	METAL PIPE ASSY FOURTH	TATA spare parts
207343900254	HOSE ASSY WITH END FITTINGS BS6	TATA spare parts
207343900255	HOSE ASSY WITH END FITTINGS	TATA spare parts
207343900256	HOSE ASSY WITH END FITTINGSBS6	TATA spare parts
207343900263	METAL PIPE ASSY THIRD	TATA spare parts
207343900274	PIPE ASSY NYLON COMPLETE	TATA spare parts
207343900285	PIPE ASSY FIRST METAL PIPE (TEFLON HOSE)	TATA spare parts
207343900308	AC OUTLET PIPE (FIRST PIPE)	TATA spare parts
207343900310	NYLON PIPE BUNCH LPO 1512/55BSIII APSRTC	TATA spare parts
207343900316	PIPE ASSY COMPRESSOR FOURTH METAL PI	TATA spare parts
207343900317	PIPE ASSY COMP FOURTH METAL PIPE	TATA spare parts
207343900322	PIPE ASSY NYLON BUNCH	TATA spare parts
207343900323	PIPE ASSY NYLON BUNCH	TATA spare parts
207343900326	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
207343900327	NYLON PIPE ASSY SET	TATA spare parts
207343900341	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
207343900342	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
207343900344	PIPE ASSY NYLON BUNCH	TATA spare parts
207343900347	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
207343900352	NYLON PIPE BUNCH ASSY	TATA spare parts
207343900354	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
207343900356	NYLON PIPE BUNCH ASSY	TATA spare parts
207343900362	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
207343900374	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
207343900384	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
207343900386	PIPE ASSY THIRD METAL PIPE	TATA spare parts
207343900388	METAL PIPE ASSY FOURTH	TATA spare parts

207343900390	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
207343906803	ADAPTOR	TATA spare parts
207343908202	BRACKET	TATA spare parts
207343908203	BRACKET (AIR COMP.PIPE)	TATA spare parts
207343908206	BRACKET COMPRESSOR MTG	TATA spare parts
207343910122	SET ASSY NYLON PIPE BUNCH FOR LPO1512/55	TATA spare parts
207343910128	ASSY NYLON PIPE BUNCH	TATA spare parts
207343910157	PIPE ASSY 1ST METAL PIPE (TEFLON HOSE)	TATA spare parts
207343910158	PIPE ASSY 3RD METAL PIPE (18 OD)	TATA spare parts
207343910159	PIPE ASSY 4TH METAL PIPE (18 OD)	TATA spare parts
207343910170	PIPE ASSY 2ND METAL PIPE (18 OD)	TATA spare parts
207343910178	PIPE ASSY 2ND METAL PIPE	TATA spare parts
207343910182	PIPE ASSY FOURTH METAL PIPE	TATA spare parts
207343910183	PIPE ASSY	TATA spare parts
207343910211	PIPE ASSY INTAKE METAL PIPE	TATA spare parts
207343910281	PIPE ASSY FIRST METAL PIPE (TEFLON HOSE)	TATA spare parts
207343910282	METAL PIPE ASSY SECOND	TATA spare parts
207343910283	METAL PIPE ASSY THIRD	TATA spare parts
207343930110	PIPE ASSY BUNCH FOR LP1512	TATA spare parts
207343930173	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
207343940128	PIPE ASSY SECOND METAL PIPE COMP-18 DIA.	TATA spare parts
207343940129	PIPE ASSY THIRD METAL PIPE 18 DIA	TATA spare parts
207343940130	PIPE ASSY FOURTH METAL PIPE 18 DIA	TATA spare parts
207343940131	PIPE ASSY FIRST METAL PIPE (TEFLON HOSE)	TATA spare parts
207343940134	PIPE ASSY BUNCH COMPLETE	TATA spare parts
207343940136	PIPE ASSY	TATA spare parts
207343940162	PIPE ASSY BUNCH	TATA spare parts
207343950106	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
207344100101	ASSY. TUBE (18 O.D. X 1460 LG.)	TATA spare parts
207344100103	ASSY. TUBE 15 O.D. X 790 LG.	TATA spare parts
207344100104	ASSY. TUBE 15 O.D. X 1820 LG.	TATA spare parts
207344100105	ASSY HOSE	TATA spare parts
207344100106	TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
207344100107	ASSY TUBE	TATA spare parts
207346000119	SEALED DRAG LINK-LPO 1512 RHD	TATA spare parts
207346000121	SEALED DRAG LINK LPO1512LHD	TATA spare parts
207346000126	SEALED DRAG LINK-LPO 1512LHD	TATA spare parts
207346000128	ASSY SEALED DRAG LINK-QHT LPO 15T(NGT)	TATA spare parts
207346000129	DRAGLINK ASSY	TATA spare parts
207346000130	DRAG LINK ASSY (SEALED TYPE)	TATA spare parts
207346100101	ASSY STEERING COL. SUPPORT COMPLETE RHD	TATA spare parts
207346100103	ASSY. STEERING COL. SUPPORT-RHD	TATA spare parts
207346100105	ASSY.STEERING COLUMN SUPPORT COMPLETE	TATA spare parts
207346100112	ASSY STEERING COLUMN SUPPORT-RHD	TATA spare parts
207346100120	BRACKET ASSY STG GEAR BOX MTG	TATA spare parts
207346100125	STEERING COLUMN ASSY	TATA spare parts
207346150106	KIT ASSY. PIPES STG	TATA spare parts

207346200102	ASSY INTERMEDIATE SPINDLE	TATA spare parts
207346200122	ASSY STEERING SPINDLE (TOP)	TATA spare parts
207346200124	STEERING SPINDLE ASSY	TATA spare parts
207346207903	STEERING SPINDLE TOP 332 LG.	TATA spare parts
207346207905	STEERING SPINDLE TOP	TATA spare parts
207346305101	PITMAN ARM	TATA spare parts
207346600107	ASSY. POWER STEERING HYDRAULIC TANK	TATA spare parts
207346600107AE	HYDRAULIC RESERVOIR LPA 1415/	TATA spare parts
207346800101	HOSE ASSY TANK OUTLET TO STRG PUMP INLET	TATA spare parts
207346800102	TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
207346800104	PRESSURE LINE ASSY	TATA spare parts
207346800106	RETURN LINE ASSY	TATA spare parts
207346800107	SUCTION LINE HOSE ASSY	TATA spare parts
207346800108	PRES. LINE HOSE ASSY	TATA spare parts
207346800109	PRES. LINE HOSE ASSY	TATA spare parts
207346800110	RETURN LINE HOSE ASSY	TATA spare parts
207346800111	RETURN LINE HOSE ASSY	TATA spare parts
207346800113	RETURN LINE HOSE ASSY STRG GB TO TANK	TATA spare parts
207346800114	SUCTION LINE HOSE ASSY TANK TO PUMP	TATA spare parts
207346800116	PRES. LINE HOSE ASSY PUMP TO STRG GEAR	TATA spare parts
207346800117	ASSY. TUBE (WITH CRIMPED RUBBER COMPLT.)	TATA spare parts
207346800119	ASSY. TUBE (WITH CRIMPED RUBBER COMPLT.)	TATA spare parts
207346800127	ASSY HOSE CRIMPED - SUCTION LINE(STG. TA	TATA spare parts
207346800128	ASSY HOSE CRIMPED - PRESSURE LINE (STG.	TATA spare parts
207346800129	ASSY HOSE - CRIMPED RETURN LINE(STG GB T	TATA spare parts
207346800133	SUCTION LINE ASSY	TATA spare parts
207346800134	PRESSURE LINE ASSY	TATA spare parts
207346800135	RETURN LINE ASSY-FOR ZF P/STRG	TATA spare parts
207346900107	DRAG LINK ASSY	TATA spare parts
207346990104	KIT-DRAG LINK REPLACEMENT OF SEALED TYPE	TATA spare parts
207346990105	KIT-DRAG LINK REPLACEMENT OF SEALED TYPE	TATA spare parts
207346990106	KIT-DRAG LINK REPLACEMENT OF SEALED TYPE	TATA spare parts
207346990107	KIT-DRAG LINK REPLACEMENT OF SEALED TYPE	TATA spare parts
207346990108	KIT-DRAG LINK REPLACEMENT OF SEALED TYPE	TATA spare parts
207347500104	BRACKET ASSY FUEL TANK MTG	TATA spare parts
207347500105	ASSY SUPPORT FUEL TANK(TMML)	TATA spare parts
207347500106	FUEL TANK STRAP ASSY WITH BRACKET	TATA spare parts
207347500107	ASSY BRACKET	TATA spare parts
207347600101	ASSY TUBE 15 X 380	TATA spare parts
207347600102	ASSY TUBE 15 X 1415	TATA spare parts
207347600103	ASSY TUBE 15 X 1610	TATA spare parts
207347600104	ASSY TUBE 15 X 2060	TATA spare parts
207347600105	ASSY TUBE 15 X 1605	TATA spare parts
207347600108	ASSY. TUBE-WITH CRIMPED R/HOSE COMPLT.	TATA spare parts
207347600109	ASSY. TUBE-WITH CRIMPED R/HOSE COMPLT.	TATA spare parts
207347600115	ASSY. TUBE (WITH CRIMPED R/HOSE COMPLT.)	TATA spare parts
207347600116	ASSY. TUBE (WITH CRIMPED R/HOSE COMPLT.)	TATA spare parts

207347600117	ASSY. TUBE (10 O.D. X 3110 LG.)	TATA spare parts
207347600118	ASSY. TUBE WITH CRIMPED RUBBER HOSE 1ST	TATA spare parts
207347600119	ASSY. TUBE WITH CRIMPED RUBBER HOSE 2ND	TATA spare parts
207347600120	ASSY. TUBE WITH CRIMPED RUBBER HOSE 1ST	TATA spare parts
207347600121	ASSY. TUBE (6 O.D. X 1415 LG.) 2ND PIPE	TATA spare parts
207347600122	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
207347600133	DIESEL TANK TO INTE.JOINT 15 OD 160L 285	TATA spare parts
207347600135	DISEL.TANK TO INTE.JOINT 10 OD 160L	TATA spare parts
207347600136	INTE. JOINT TO BABY FILTER 10 O.D.	TATA spare parts
207347600137	EJECTOR TO INTERM. JOINT 06 O.D	TATA spare parts
207347600138	INT.JOINT TO DIESEL TANK 06 OD 160L	TATA spare parts
207347600139	MAIN FUEL LINE	TATA spare parts
207347600140	RETURN FUEL LINE	TATA spare parts
207347600141	ASSY. FUEL SUCTION LINE 1 DIA. 15	TATA spare parts
207347600142	ASSY TUBE	TATA spare parts
207347600143	ASSY. FUEL SUCTION LINE 2 DIA. 15	TATA spare parts
207347600146	ASSY TUBE (INTERM. JOINT TO DIESEL TANK)	TATA spare parts
207347600147	ASSY.TUBE (DIESEL TANK TO INTE. JOINT 15	TATA spare parts
207347600166	FUEL LINES ASSY TANK TO FWS	TATA spare parts
207347600167	FUEL LINES ASSY FWS TO ENGINE	TATA spare parts
207347600168	FUEL RETURN LINE ASSY ENGINE TO FUEL TANK	TATA spare parts
207347600170	FUEL NYLON PIPE ASSY (ENGINE TO TANK)	TATA spare parts
207347600171	FUEL NYLON PIPE ASSY (TANK TO FWS)	TATA spare parts
207347600172	FUEL NYLON PIPE ASSY (FWS TO ENGINE)	TATA spare parts
207347600180	ASSY FUEL LINE (FUEL TANK TO WATER S	TATA spare parts
207347600182	ASSY FUEL RETURN LINE	TATA spare parts
207347600183	FUEL LINES ASSY (TANK TO FWS)	TATA spare parts
207347600184	FUEL LINES ASSY (ENGINE TO TANK)	TATA spare parts
207347600185	FUEL LINES ASSY (FWS TO ENGINE)	TATA spare parts
207347600186	TUBE ASSY WITH ADAPTOR	TATA spare parts
207349000102	BRKT EGP MTG-LCCR	TATA spare parts
207349000103	BRACKET ASSY	TATA spare parts
207349000107	BRACKET ASSY EGP MTG	TATA spare parts
207349000109	BRACKET ASSY;EGP MTG;REAR	TATA spare parts
207349000110	BRACKET ASSY DECOMP PIPE MTG	TATA spare parts
207349008201	BRACKET	TATA spare parts
207349008202	CLAMPING PLATE	TATA spare parts
207349008205	SUPPORT BRACKET (ON ENGINE)	TATA spare parts
207349008209	CLAMP FOR MUFFLER	TATA spare parts
207349008211	L BRACKET	TATA spare parts
207349100102	ASSY. SILENCER WITH PIPES	TATA spare parts
207349100103	ASSY.SILENCER WITH PIPES	TATA spare parts
207349100105	ASSY SILENCER WITH PIPE	TATA spare parts
207349100107	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
207349100108	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
207349100109	ASSY SILENCER WITH TAIL PIPE (NG3-A) DOU	TATA spare parts
207349100111	EXHAUST GAS PROCESSURE (ISBE 5.9 130HP)	TATA spare parts

207349109910	HEAT SHIELD ASSY	TATA spare parts
207349109911	HEAT SHIELD ASSY	TATA spare parts
207349109912	HEAT SHIELD ASSY	TATA spare parts
207349109913	HEAT SHIELD ASSY	TATA spare parts
207349109914	HEAT SHIELD ASSY	TATA spare parts
207349109915	HEAT SHIELD ASSY	TATA spare parts
207349109916	HEAT SHIELD ASSY	TATA spare parts
207349110101	SET AFTER TREATMENT 130HP TC ISBE 5.9	TATA spare parts
207349200107	ASSY INTERMEDIATE PIPE(AT MUFLLER)	TATA spare parts
207349200108	ASSY BRACKET (EXH. BRAKE MTG)	TATA spare parts
207349200112	ASSY BRKT EXHT PIPE-LCCR	TATA spare parts
207349200113	ASSY BRKT EXHST PIPE END-LCCR	TATA spare parts
207349200114	ASSY BRKT EGP MTG	TATA spare parts
207349200115	ASSY BRKT EGP MTG	TATA spare parts
207349200116	ASSY PIPE(TURBO TO EXHT BRAKE)-LCCR	TATA spare parts
207349200117	ASSEMBLY UREA AIR MIX LINE	TATA spare parts
207349200122	FLEX PIPE ASSY	TATA spare parts
207349200123	EXHAUST PIPE ASSY	TATA spare parts
207349200124	DECOMP PIPE ASSY	TATA spare parts
207349200126	ASSY DECOMP PIPE	TATA spare parts
207349200128	PIPE ASSY; TC TO EXHAUST BRAKE	TATA spare parts
207349200129	PIPE ASSY UREA AIR MIX	TATA spare parts
207349200132	SUPPORT BRACKET ASSY	TATA spare parts
207349200134	AIR PIPE LINE AIR OIL FILTER TO DU	TATA spare parts
207349203305	SUPPROT BRACKET FROM CROSS MEMBER	TATA spare parts
207349203306	Z BRACKET EXHAUST MOUNTING	TATA spare parts
207349203308	ASSY SUPPORT BRACKET EGP PIPE-LCCR	TATA spare parts
207349203309	BRKT EXHT PIPE-LCCR	TATA spare parts
207349203314	BRACKET	TATA spare parts
207349203317	BRACKET	TATA spare parts
207349203319	BRACKET EXHAUST TAIL PIPE MTG	TATA spare parts
207349203320	BRACKET	TATA spare parts
207349206911	TAIL PIPE	TATA spare parts
207349206918	TAIL PIPE POST SILENCER	TATA spare parts
207349206930	TAIL PIPE	TATA spare parts
207349208220	EXHAUST PIPE CLAMP	TATA spare parts
207349208221	EXHAUST PIPE CLAMP	TATA spare parts
207349209901	HEAT SHIELD ASSY BEND 1	TATA spare parts
207349209902	HEAT SHIELD ASSY BEND 2	TATA spare parts
207349209903	HEAT SHIELD ASSY BEND 3	TATA spare parts
207349209904	HEAT SHIELD ASSY BEND 4	TATA spare parts
207349209907	HEAT SHILED ASSY BEND 7	TATA spare parts
207349209908	HEAT SHIELD ASSY BEND 8	TATA spare parts
207349209909	HEAT SHIELD ASSY BEND 9	TATA spare parts
207350105801	INTERCOOLER HOSE INLET BS3/4/6	TATA spare parts
207350105802	I/C HOSE OUTLET	TATA spare parts
207350106901	WATER FILL PIPE	TATA spare parts

207354100102	BATTERY CARRIER ASSY	TATA spare parts
207354100107	ASSY.LINK -450 MM LG-50 MMSQ	TATA spare parts
207354100116	BATTERY CABLE LINK	TATA spare parts
207354107501	BOOT FOR BATT.CABLE CLAMP +VE-RED	TATA spare parts
207354107502	BOOT FOR BATT.CABLE CLAMP -VE-BLACK	TATA spare parts
207354110101	ASSY.BATT.CABLE -VE 50 SQ MM -1560MM LG	TATA spare parts
207354200103	ASSY.BKT. - HORN MTG.	TATA spare parts
207354200117	INSTRUMENT CLUSTER ASSY	TATA spare parts
207354208202	BRACKET FOR AUS-32 LEVEL GAUGE	TATA spare parts
207354209901	RPM METER 24V	TATA spare parts
207354209903	HIGHTEMP.SENSING BUZZER UNIT-24V	TATA spare parts
207354209904	OIL PRESSURE GAUGE -ELECT. -24V	TATA spare parts
207354209905	RPM METER 24V	TATA spare parts
207354209906	HORN-DIA 125 24V RIS CAPACITOR	TATA spare parts
207354209907	HORN/12V/DIA 125/RIS CAPACITOR	TATA spare parts
207354209908	VOLTMETER	TATA spare parts
207354209909	HORN 24V	TATA spare parts
207354209912	INTRUMENT CLUSTER (1 : 0.80) LPO1512	TATA spare parts
207354209913	INSTRUMENT CLUSTER (1:0.80)	TATA spare parts
207354209914	INSTRUMENT CLUSTER (1:0.80)	TATA spare parts
207354209921	INSTRUMENT CLUSTER (1:0.88)	TATA spare parts
207354209931	INSTRUMENT CLUSTER (1:0.88)	TATA spare parts
207354209940	INSTRUMENT CLUSTER (1:0.80) E-SPD	TATA spare parts
207354209941	INSTRUMENT CLUSTER (1:0.80) E-SPEED	TATA spare parts
207354209942	INSTRUMENT CLUSTER (1:0.80)	TATA spare parts
207354209943	INSTRUMENT CLUSTER (1:0.80) E-SPD	TATA spare parts
207354209945	INSTRUMENT CLUSTER (1:0.88) E-SPD	TATA spare parts
207354209946	INSTRUMENT CLUSTER (1:0.80) E-SPD	TATA spare parts
207354209948	INSTRUMENT CLUSTER (.88)	TATA spare parts
207354209949	INSTRUMENT CLUSTER (0.88)	TATA spare parts
207354309901	TEMP. TRANSDUCER	TATA spare parts
207354400103	HEADLAMP ASSY LH	TATA spare parts
207354400104	HEADLAMP ASSY RH	TATA spare parts
207354440101	ASSY HEADLAMP -1.8PERC (RHD)24V W/O HLLA	TATA spare parts
207354440102	ASSY HEADLAMP -1.8PERC (RHD)24V W/O HLLA	TATA spare parts
207354440103	HEADLAMP ASSY LH	TATA spare parts
207354440104	HEADLAMP ASSY RH	TATA spare parts
207354500101	ASSY. MAIN LINE SWITCH BS1/2/3/4	TATA spare parts
207354500102	ASSY. MAIN LINE SWITCH	TATA spare parts
207354500105	ASSY. MAIN LINE SWITCH	TATA spare parts
207354509901	STARTER CUM IGNITION SWITCH	TATA spare parts
207354509907	BATT CUT-OFF SWITCH	TATA spare parts
207354600101	ASSY MAIN CABLE SET	TATA spare parts
207354600102	ASSY CABLE SET FRT TO TAIL	TATA spare parts
207354600114	W/H ABS	TATA spare parts
207354600128	WIRING HARNESS LP 1512	TATA spare parts
207354600134	WIRING HARNESS ABS FRAME	TATA spare parts



207354600139	WIRING HARNESS ABS SPLIT	TATA spare parts
207354600141	WIRING HARNESS TAIL	TATA spare parts
207354600143	WIRING HARNESS MAIN	TATA spare parts
207354600145	WIRING HARNESS TAIL	TATA spare parts
207354601603	W/H MAIN LPO1512 WITH TMML STRUCTURE	TATA spare parts
207354601604	W/H MAIN	TATA spare parts
207354601629	WIRING HARNESS MAIN	TATA spare parts
207354601631	WIRING HARNESS TAIL	TATA spare parts
207354601695	WIRING HARNESS MAIN	TATA spare parts
207354601696	WIRING HARNESS P-CAN	TATA spare parts
207354609901	8 POLE CONN. FOR W/H JUMPER CABLE	TATA spare parts
207354620102	W/H MAIN LPO-1512TC INT F/B I/CLTR	TATA spare parts
207354620107	W/H-MAIN LPO-1512TC SPEED LIMITER	TATA spare parts
207354620114	W/H MAIN LPO-1316TC RHD	TATA spare parts
207354620115	W/H MAIN LPO1512 TC BS-III B/O-JSQR ARM	TATA spare parts
207354620120	WIRING HARNESS ENGINE	TATA spare parts
207354620123	W/H TAIL/55	TATA spare parts
207354620124	WIRING HARNESS MAXI FUSE	TATA spare parts
207354620125	W/H ENGINE LPO1512 TC BSIII ERGOPACK	TATA spare parts
207354620126	W/H POWERCABLE STARTER TO ALT. LCCR	TATA spare parts
207354620129	WIRING HARNESS PIGTAIL	TATA spare parts
207354620135	MAIN WIRING HARNESS	TATA spare parts
207354620136	WIRING HARNESS TAIL	TATA spare parts
207354707101	PLATE SPEED LIMITER DEVICE MOTOR MTG	TATA spare parts
207354820102	W/H MAIN ARMY B/O E-I	TATA spare parts
207354820103	ASSY. CABLE SET FRONT TO TAIL -ARMY (55)	TATA spare parts
207354820105	WIRING HARNESS MAIN	TATA spare parts
207354820109	WIRING HARNESS TAIL	TATA spare parts
207354820111	W/H TAIL-W.B 55-LPO 1512TC/1510TC E-II J	TATA spare parts
207354820112	W/H MAIN-12V-INST.CLUSTER	TATA spare parts
207354820113	W/H MAIN 24V-INST.CLUSTER	TATA spare parts
207354820115	W/H MAIN 12V-INST CLUSTER CMVR	TATA spare parts
207354820119	W/H MAIN -INST.CLUSTER/MOTOR. H/L E-II J	TATA spare parts
207354820125	W/H MAIN-LPO 1512TC-BS-II ARMY	TATA spare parts
207354820135	W/H MAIN LPO1512TC/55 INST.CLUSTER	TATA spare parts
207354821602	W/H MAIN LPO-1512TC INT F/B PTO	TATA spare parts
207354821606	WIRING HARNESS-BATT.TAP PIG TAIL - FOR A	TATA spare parts
207354821607	W/H-PIG TAIL -ABS GND SPLY¿ OFFER	TATA spare parts
207358900103	WHEEL SPANNER (30-32 A/F) 480 MM LENGTH	TATA spare parts
207360100101	ASSY COWL COMPLETE LPO 1512TC	TATA spare parts
207360100105	ASSY COWL FITTED COMPLETE 1512 PN SUS	TATA spare parts
207360100107	ASSY COWL SHELL PAINTED 1512 PN SUS	TATA spare parts
207360100109	ASSY COWL COMPLETE WITH FITMENTS-L.H.D	TATA spare parts
207360100110	LPO1512/55TC ASSY COWL PAINTED LHD	TATA spare parts
207360100120	LPO1512TC ARMY COWL PAINTED	TATA spare parts
207360100150	ASSY DRIVER STATION W/O PAINTED	TATA spare parts
207360100158	ASSY OUTRIGGER FOR REAR COWL MTG - RH	TATA spare parts

207360120127	ASSY COWL COMPLETE WITH FITMENTS	TATA spare parts
207360120130	ASSY COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
207381107701	ASSY INSULATION (BONNET CENTER)	TATA spare parts
207381107702	ASSY INSULATION LH (BONNET SIDE)	TATA spare parts
207381107703	ASSY INSULATION RH (BONNET SIDE)	TATA spare parts
207381107704	INSULATION COMPLETE	TATA spare parts
207381107705	INSULATION COMPLETE	TATA spare parts
207381806302	MASCOT 1313 TC	TATA spare parts
207388500101	ASSY BUMPER COMPLETE	TATA spare parts
207388500102	ASSY.ANTISAGGING BAR	TATA spare parts
207388500103	ASSY.SUPPORT L.H.(FOR ANTISAGGING BAR)	TATA spare parts
207388500104	ASSY. SUPPORT R.H.(FOR ANTISAGGING BAR)	TATA spare parts
207388500105	ASSY.BUMPER	TATA spare parts
207388700101	ASSY ENGINE HOOD COMPLETE RHD	TATA spare parts
207388706301	ENGINE HOOD LPO 1512 TC	TATA spare parts
207388707701	ENGINE HOOD RUBBER BEADING	TATA spare parts
207424200102	ASSY BRACKET LH ENG MTG TOP ON ENGINE	TATA spare parts
207424200103	ASSY BRACKET RH ENG MTG TOP ON ENGINE	TATA spare parts
207424200104	ASSY BRACKET ENG MTG REAR RH ON FRAME	TATA spare parts
207424200105	ASSY BRACKET ENG MTG REAR LH ON FRAME	TATA spare parts
207429100102	ASSY CONTROL MTG. BRACKET WITH TUBE	TATA spare parts
207429100119	ASSY.PIPE	TATA spare parts
207429100121	ASSY STOPPER	TATA spare parts
207429500107	ASSY.BRACKET-M/CYL MTG.	TATA spare parts
207429500112	ASSY. BRACKET (CLUTCH BOOSTER MTG. BKT.)	TATA spare parts
207429500115	ASSY. LEVER	TATA spare parts
207429500116	ASSY CONTROL MTG. BKT. WITH TUBE	TATA spare parts
207429500119	ASSY. CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
207429500122	ASSY. PUSH ROD WITH FORK (AT CLUTCH)	TATA spare parts
207430100101	ASSY PULL ROD -ACCELERATOR	TATA spare parts
207430100102	ASSY ACCELERATOR CABLE MTG. BRACKET	TATA spare parts
207430100104	ASSY INTERMEDIATE LEVER	TATA spare parts
207430100105	ASSY BRACKET WITH BUSH	TATA spare parts
207430100106	ASSY. ACCELERATOR PULL CBL. 2670MM BS2/3	TATA spare parts
207430100108	ASSY. PULL CABLE-ACCELERATOR	TATA spare parts
207430100112	ASSY. PULL CABLE-ACCELERATOR	TATA spare parts
207430100113	ASSY. PULL CABLE -ACCEL. 3700MM BS2/3	TATA spare parts
207430108206	BRACKET FOR ACCELERATOR	TATA spare parts
207430108701	TENNSION SPRING FOR FIP	TATA spare parts
207431000101	FRAME ASSY LPT 1613 42 WB	TATA spare parts
207431000102	ASSY FRAME LPTW1613TC/48	TATA spare parts
207431000103	ASSY. FRAME-LPT1613TC-52-50%	TATA spare parts
207431000104	ASSY. FRAME LPT1613TC-52-60%	TATA spare parts
207431000106	ASSY. FRAME -LPT1613TC/42 WITH PS	TATA spare parts
207431000113	ASSY FRAME LPT1613TC/52 50% E-II P/S.	TATA spare parts
207431000115	ASSY.FRAME LPT1613TC/48 RAISED COWL	TATA spare parts
207431000116	ASSY FRAME-LPT1613TC/52-50% REVISED CM	TATA spare parts

207431000117	ASSY.FRAME LPT1613TC/52-60% RAISED COWL	TATA spare parts
207431000118	ASSY. FRAME-LPT 1613TC/42	TATA spare parts
207431000120	ASSY FRAME LPT1613TC/42 EX MODEL	TATA spare parts
207431000121	ASSY FRAME COMPLETE 60% ROH	TATA spare parts
207431000124	ASSY FRAME-TABLE DRG.	TATA spare parts
207431000125	ASSY.FRAME COMPLETE-LPT 1613TC/48 EII PS	TATA spare parts
207431000128	ASSY. FRAME 1613 TLT TC 52 WB EURO II	TATA spare parts
207431000129	ASSY.FRAME LPT 1613TC EX/42/TLT/SLP/E-II	TATA spare parts
207431000130	ASSY FRAME COMPLETE 50% ROH	TATA spare parts
207431000131	ASSY. FRAME COMP.LPT1613TC EX 48.55 WBAS	TATA spare parts
207431000133	ASSY.FRAME (42 WB)	TATA spare parts
207431000135	ASSY FRAME COMPLETE 50% ROH	TATA spare parts
207431000136	ASSY FRAME COMPLETE 60% ROH	TATA spare parts
207431000138	ASSY FRAME COMPLETE (LPT1613TC)	TATA spare parts
207431200103	ASSY.GUSSET-RH	TATA spare parts
207431200104	ASSY.GUSSET-LH	TATA spare parts
207431207114	REINFORCEMENT- AT SPRING HANGER BKT	TATA spare parts
207431700101	ASSY.BOTTOM SHIELD (ENGINE)	TATA spare parts
207431700102	ASSY.TRANSMISSION SHIELD(FRONT SIDE)	TATA spare parts
207431700104	ASSY SUPPORT BRACKET (ENGINE SIDE)	TATA spare parts
207431700107	ASSY SUPPORT BRACKET.(REAR TRANS. SIDE)	TATA spare parts
207431700108	ASSY TRANSMISSION SHIELD(REAR SIDE)	TATA spare parts
207441100104	DRIVE SHAFT FRONT	TATA spare parts
207441100110	ASSY.PROPELLER SHAFT WITH CENTER BRG.	TATA spare parts
207441100116	ASSY.PROP.SHAFT WITH CENTER BRG.(L=1876)	TATA spare parts
207441100119	PROPELLER SHAFT ASSY FRONT	TATA spare parts
207441100126	ASSY.FRONT PROP.SHAFT COMPLETE	TATA spare parts
207441109901	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
207441109903	PROPELLER SHAFT TUBE ASSY	TATA spare parts
207441120102	ASSY.PROP.SHAFT REAR (CLOSE L1684)	TATA spare parts
207441120105	ASSY.PROP.SHAFT REAR COMP(CLOSED L=1547)	TATA spare parts
207441120108	ASSY.PROP.SHAFT REAR COMP.(CLOSED =1884)	TATA spare parts
207441120113	ASSY.REAR PROP.SHAFT COMPLETE	TATA spare parts
207441120114	ASSY.REAR PROP.SHAFT COMPLETE	TATA spare parts
207441129902	PROPELLER SHAFT TUBE ASSY	TATA spare parts
207441300101	ASSY.BRACKET RH (PROP.SHAFT GUARD MTG.)	TATA spare parts
207441300102	ASSY.BRACKET LH (PROP.SHAFT GUARD MTG.)	TATA spare parts
207441303302	CENTRE BEARING BRACKET	TATA spare parts
207441308204	PROP SHAFT GUARD -RH (REAR)	TATA spare parts
207441308205	PROP SHAFT GUARD -LH (REAR)	TATA spare parts
207442900101	ASSY.TUBE-15 O.D. X 2280 LG.	TATA spare parts
207442900120	ASSY TUBE 15 O.D.X 2435 LG	TATA spare parts
207442903301	PARTING BKT	TATA spare parts
207443900155	ASSY NYLON PIPE SET COMPLETE-48WBTC	TATA spare parts
207443900189	ASSY CHASS SET COMPL-LPT1613/52/COWL/DDU	TATA spare parts
207443900193	ASSY.NY.PIPE SET CHASSIS COMPL-1613/VOSS	TATA spare parts
207443910101	ASSY.NYLON PIPE SET COMPL WT PLASTIC CTR	TATA spare parts

207443910104	ASSY NYLON PIPE SET CHASSIS	TATA spare parts
207443910121	ASSY COMPRESSOR PIPE THIRD	TATA spare parts
207443910122	ASSY. COMPRESSOR PIPE SECOND	TATA spare parts
207443910123	ASSY COMPRESSOR PIPE SECOND	TATA spare parts
207443910126	ASSY. COMPRESSOR PIPE FIRST	TATA spare parts
207443910130	ASSY COMPRESSOR PIPE THIRD	TATA spare parts
207443910132	ASSY.COMP.PIPE 2ND	TATA spare parts
207443910133	ASSY.COMP PIPE 3RD	TATA spare parts
207443910134	ASSY.COMP.PIPE 2ND	TATA spare parts
207443910135	ASSY.COMP.PIPE 2ND	TATA spare parts
207446100103	ASSY BRACKET-STRG.G/BOX MTG.	TATA spare parts
207446100104	ASSY BRACKET POWER STG GB MOUNTING	TATA spare parts
207446200101	ASSY STEERING SPINDLE - MIDDLE	TATA spare parts
207446800110	ASSY PIPES & CLAMPS	TATA spare parts
207446800116	KIT ASSY P/STG.LINE & CONNECTOR M/S TF	TATA spare parts
207447600106	ASSY.TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
207447600107	ASSY.TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
207447600108	ASSY TUBE WITH CRIMPED R/HOSE COMPLETE	TATA spare parts
207447600109	ASSY TUBE WITH CRIMPED R/HOSE COMPLETE	TATA spare parts
207447600111	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
207447600112	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
207447600126	ASSY.TUBE WITH CRIMPED RUBBER HOSE(FUEL	TATA spare parts
207447600128	ASSY.TUBE WITH CRIMPED RUBBER HOSE(RUBBE	TATA spare parts
207447600134	ASSY.TUBE WITH CRIMPED R/HOSE	TATA spare parts
207447600135	ASSY.TUBE WITH CRIMPED R/HOSE	TATA spare parts
207447600136	ASSY TUBE WITH CRIMPED R/HOSE.	TATA spare parts
207447600137	ASSY.TUBE WITH CRIMPED R/HOSE	TATA spare parts
207449100101	ASSY.SILENCER WITH PIPES	TATA spare parts
207449100110	ASSY EXT. PIPE (INT).	TATA spare parts
207449100111	ASSY EXHAUST PIPE 81.2 OD X 1.6 THK)	TATA spare parts
207449100113	ASSY SECOND EXHAUST PIPE	TATA spare parts
207449100116	ASSY MUFFLER WITH TAIL PIPE	TATA spare parts
207449100117	ASSY. SECOND EXHAUST PIPE	TATA spare parts
207449200101	ASSY EXHAUST PIPE INT.	TATA spare parts
207449200103	ASSY.EXHAUST PIPE-76.2X1.6 THK	TATA spare parts
207449200107	ASSY PIPE	TATA spare parts
207449200108	EXHAUST PIPE	TATA spare parts
207449200113	ASSY. EXHAUST PIPE	TATA spare parts
207449200116	ASSY. EXHAUST PIPE	TATA spare parts
207449208202	BRACKET	TATA spare parts
207449208203	BRACKET	TATA spare parts
207449208205	BRACKET	TATA spare parts
207454209901	HIGH TEMP.SENSING BUZZER UNIT	TATA spare parts
207454209902	OIL PRESSURE GAUGE ELECT	TATA spare parts
207454209903	RPM METER-12V-1600-2200 RPM	TATA spare parts
207454620101	W/H TAIL LPT1613/52 W/709TILT	TATA spare parts
207454820101	ASSY MAIN CABLE SET	TATA spare parts

207454820102	ASSY CABLE SET	TATA spare parts
207460100101	COWL COMPLT W/FIT	TATA spare parts
207460100102	COWL BARE	TATA spare parts
207460100113	LPT1613 TC PS COWL COMPLETE	TATA spare parts
207481800102	ASSY TATA1613 CUMM MASCOT	TATA spare parts
207552070102	ASSY.BRACKET(BONNET STAY)	TATA spare parts
207552070105	ASSY.REINFORCEMENT(RADIATOR SHELL)	TATA spare parts
207552070109	ASSY BONNET CENTRE SK1613	TATA spare parts
20755207010935	ASSY. BONNET CENTER CED+SEAL BS1/2/3/4	TATA spare parts
207552070110	ASSY. AIR SCOOP LH	TATA spare parts
207552070111	ASSY. AIR SCOOP RH	TATA spare parts
207552070112	BONNET ASSY CENTER	TATA spare parts
207552077703	INSULATION (BONNET MIDDLE) BS6	TATA spare parts
207552700101	ASSY. BONNET SEAL(SFC) BS6	TATA spare parts
207552700115	ASSY. AIR SCOOP LH	TATA spare parts
207552700116	ASSY. AIR SCOOP RH	TATA spare parts
207555100101	MASCOT ASSY	TATA spare parts
207555100105	MASCOT ASSY BS6	TATA spare parts
207560000101	BARE CAB 1615	TATA spare parts
207560000107	ASSY CAB COMPLETE 1615 SE	TATA spare parts
207560000118	ASSY CAB COMP. SE 1613 TC	TATA spare parts
207560000119	ASSY CAB COMPLETE 1615 SK	TATA spare parts
207560000120	ASSY CAB COMP. SK 1613 TC	TATA spare parts
207560000121	SK 1615 RHD TC CAB FABRICATED	TATA spare parts
207560000129	ASSY BODY COMPLT. RHD SE1613 EURO2	TATA spare parts
207560000141	ASSY BARE CAB SE/SK 1615TC	TATA spare parts
207560000144	ASSY. BODY COMPLETE	TATA spare parts
207560000152	ASSY CAB PAINTED SK1615TC RHD	TATA spare parts
207560000161	ASSY CAB COMP. SK 1613 TC RAISED AIR FIL	TATA spare parts
207560000162	ASSY. BODY SHELL PAINTED	TATA spare parts
207560000182	ASSY. CAB SHELL PAINTED	TATA spare parts
207560000183	ASSY. CAB SHELL PAINTED	TATA spare parts
207560000184	ASSY. CAB SHELL PAINTED	TATA spare parts
207560000185SJ	ASSY. BODY COMPLETE SPARE	TATA spare parts
207560000186	ASSY. CAB SHELL PAINTED	TATA spare parts
207560000189	CAB SK 1613 TC COMPLETE	TATA spare parts
207560000189SJ	CAB SK 1613 TC COMPLETE SPARE CAB	TATA spare parts
207560000190	ASSY. CAB SHELL PAINTED EURO I	TATA spare parts
207560000201	ASSY BODY COMPL (FOR SA1212 BS-II)	TATA spare parts
207560000202	ASSY CAB SHELL PAINTED	TATA spare parts
207560000220	ASSY BODY COMPL (FOR SA1212 BS-III)	TATA spare parts
207560000220SJ	ASSY BODY COMPL (FOR SA1212 BS-III)	TATA spare parts
207560000221	ASSY CAB SHELL PAINTED (SA1212 BSIII)	TATA spare parts
207560008203	Z-BKT.RH(REINFORCEMENT) BS6	TATA spare parts
207560008204	Z-BKT.LH(REINFORCEMENT) BS6	TATA spare parts
207560010105	ASSY. BONNET STAY	TATA spare parts
207560100102	ASSY TIE MEMBER (TOP	TATA spare parts

207560100106	TIE MEMBER (BOTTOM)SK1613	TATA spare parts
207560100111	ASSY TIE MEMBER WITH TUBULAR FRAME	TATA spare parts
207560100117	ASSY. KIT FOR RETROFITMENT	TATA spare parts
207560100118	ASSY CAB COMPLETE	TATA spare parts
207560100119	ASSY CAB SHELL PAINTED	TATA spare parts
207560100123	ASSY CAB COMPLETE FOR SE1613 BS-II	TATA spare parts
207560100124	ASSY. CAB SHELL PAINTED FOR SE1613 BS-II	TATA spare parts
207560100126	ASSY. CAB COMPLETE	TATA spare parts
207560100127	ASSY. CAB SHELL PAINTED	TATA spare parts
207560100128	TIE MEMBER(TO)SK1613	TATA spare parts
207560100130	ASSY. CAB COMPLETE	TATA spare parts
207560100131	ASSY. CAB SHELL PAINTED	TATA spare parts
207560100137	ASSY.TIE MEMBER COMP.TOP(WITH TUB.FRAME)	TATA spare parts
207560100164	ASSY. CAB COMPLETE	TATA spare parts
207560100165	ASSY. CAB SHELL PAINTED	TATA spare parts
207560100168	ASSY. CAB COMPLETE	TATA spare parts
207560100169	ASSY. CAB SHELL PAINTED	TATA spare parts
207560100180	ASSY. CAB COMPLETE	TATA spare parts
207560100181	ASSY. CAB SHELL PAINTED/BARE CAB	TATA spare parts
207560100184	ASSY. CAB COMPLETE	TATA spare parts
207560100185	ASSY. CAB SHELL PAINTED	TATA spare parts
207560100188	ASSY. CAB SK TC BS-2	TATA spare parts
207560100189	ASSY. CAB SHELL PAINTED	TATA spare parts
207560100196	ASSY CAB COMPLE	TATA spare parts
207560100196SJ	CAB COMP SE 1613 TC BS-III CAB SPARE	TATA spare parts
207560100197	ASSY CAB SHELL PAINTED	TATA spare parts
207560108228	DOOR STOPPER BS6	TATA spare parts
207560108229	CLIP CORNER BS6	TATA spare parts
207560108232	SUPPORT LH BS6	TATA spare parts
207560108233	SUPPORT RH BS6	TATA spare parts
207560110105CK	ASSY. CAB COMPLETE- SE1613/42 BS1- CKD	TATA spare parts
207560110107	ASSY. CAB COMPLETE	TATA spare parts
207560110107SJ	CAB COMP SPARE PART SK 1613 BS3 TC	TATA spare parts
207560110108	ASSY. CAB SHELL PAINTED	TATA spare parts
207560110111	ASSY. CAB COMPLETE	TATA spare parts
207560110111SJ	ASSY. CAB COMP. SPARESK1616 697/BSIII/42	TATA spare parts
207560110112	ASSY. CAB COMPLETE	TATA spare parts
207560110112SJ	ASSY. CAB COMPL(SK 1613 697 BS3 SPARE)	TATA spare parts
207560110113	ASSY. CAB COMPLETE	TATA spare parts
207560110114	ASSY. CAB COMPLETE	TATA spare parts
207560110114SJ	CAB COMPLETE SPARE PARTS	TATA spare parts
207560110115	ASSY. CAB COMPLETE	TATA spare parts
207560110117	ASSY. CABIN BARE SK1613 BS3	TATA spare parts
207560110124SJ	ASSY. CAB COMP. W/FITMENTS SK1613 BS3	TATA spare parts
207560110125	CAB SHELL PAINTED SK 1613C	TATA spare parts
207560110125SJ	ASSY. CAB SHELL PAINTED	TATA spare parts
207560110129	ASSY CAB COM SK 1613 697 BS-III	TATA spare parts

207560110129SJ	ASSY CAB COM SK 1613 697 BS-III SPARE PA	TATA spare parts
207560110141SJ	ASSY. CAB COMPLETE(SA/SAK1212)(SPARE)	TATA spare parts
207560110142	ASSY CAB SHELL PAINTED	TATA spare parts
207560110145SJ	ASSY. CAB COMPLETE SPARE PART	TATA spare parts
207560110154	ASSY.SUPPORT BKT.(FRONT WALL) BS6	TATA spare parts
207560110156	ASSY.CAB COMPLETE	TATA spare parts
207560110164	CAB COMPLETE	TATA spare parts
207560110165	ASSY. CAB SHELL PAINTED	TATA spare parts
207560110193	CAB ASSY WITH FITMENTS	TATA spare parts
207560120104	ASSY. CAB SHELL PAINTED BS4	TATA spare parts
207560120109	CAB SHELL ASSY PAINTED	TATA spare parts
207560120110	TIE MEMBER FRAME ASSY FRONT	TATA spare parts
207560120112	SUPPORT TUBE ASSY BS6	TATA spare parts
207560120114	TIE MEMBER ASSY WITH FRAME TOP	TATA spare parts
207560120119	CABIN SHELL ASSY PAINTED SA1212 BS6	TATA spare parts
207560120136	CAB SHELL ASSY;PAINTED BS6	TATA spare parts
207561060103	ASSY FLOOR CENTRE	TATA spare parts
207561108220	REINFORCEMENT LH	TATA spare parts
207561108221	REINFORCEMENT RH	TATA spare parts
207561600107	ASSY. FLOOR CENTRE,RHD SE1613TC EURO1	TATA spare parts
207561600108	ASSY. FLOOR CENTER-RHD	TATA spare parts
207561600109	ASSY WHEEL ARCH LH	TATA spare parts
207561600110	ASSY WHEEL ARCH RH	TATA spare parts
207561600112	ASSY. FLOOR CENTRE SE 1613 TC EURO2	TATA spare parts
207561600115	ASSY. FLOOR CENTRE RHD	TATA spare parts
207561600118	ASSY. FLOOR CENTRE-RHD	TATA spare parts
207561600119	ASSY. FLOOR CENTRE-RHD	TATA spare parts
207561600121	ASSY. FLOOR CENTRE	TATA spare parts
207561600122	ASSY. FLOOR CENTRE	TATA spare parts
207561600123	ASSY. FLOOR PLATE-FRONT	TATA spare parts
207561606301	COVER (FLOOR CENTRE) BS6	TATA spare parts
207561608201	FLOOR PLATE RH-RHD BS6	TATA spare parts
207561608217	MUDGUARD LH	TATA spare parts
207561608218	MUDGUARD RH	TATA spare parts
207561608224	FLOOR PLATE LH-RHD BS6	TATA spare parts
207562000105	FRAME ASSY FRONT WALL BS6	TATA spare parts
207562000156	ASSY.FRONT PANEL COMPLETE	TATA spare parts
207562000163	ASSY. FRONT PANEL COMPLETE	TATA spare parts
207562060125	ASSY.PANEL INNER WIND SHIELD	TATA spare parts
207562070101	ASSY. PANEL OUTER W/S RHD	TATA spare parts
207562600138	BRACKET ASSY FUSE BOX MTG TOP BS6	TATA spare parts
207564000101	ASSY. REAR WALL COMPLETE	TATA spare parts
207564000113	REAR WALL COMPLETE ASSY BS6	TATA spare parts
207564700116	ASSY.REAR WALL COMPLETE	TATA spare parts
207565100101	ASSY TOP RAIL SIDE LH	TATA spare parts
207565100102	ASSY TOP RAIL SIDE RH	TATA spare parts
207565208201	TOP RAIL SIDE LH	TATA spare parts

207565208202	TOP RAIL SIDE RH	TATA spare parts
207566060105	ASSY. STEP WELL BOTTOM L.H. BS6	TATA spare parts
207566060106	ASSY. STEP WELL BOTTOM R.H. BS6	TATA spare parts
207566060109	ASSY. STEP WELL SIDE L.H.	TATA spare parts
207566060110	ASSY. STEP WELL SIDE R.H.	TATA spare parts
207566400101	ASSY. SEAT BOX(DRIVER) BS6	TATA spare parts
207566600105	FOOT STEP ASSY BS6	TATA spare parts
207567106302	PROFILE RUBBER MOULD W/S(KEYLESS)	TATA spare parts
207568090103	ASSY GLOVE BOX LID	TATA spare parts
207568090105	ASSY GLOVE BOX	TATA spare parts
207568400106	ASSY.FLOOR MAT SIDE COMPLT RH RHD	TATA spare parts
207568400107	ASSY.FLOOR MAT SIDE COMPLT LH	TATA spare parts
207568400122	ASSY. FLOOR MAT CENTRE	TATA spare parts
207568400125	ASSY. FLOOR MAT LH	TATA spare parts
207568400126	ASSY. FLOOR MAT RH	TATA spare parts
207568400127	ASSY. FLOOR MAT CENTRE	TATA spare parts
207568400128	ASSY. FLOOR MAT CENTRE	TATA spare parts
207568400133	ASSY. FLOOR MAT CENTRE	TATA spare parts
207568400138	ASSY FLOOR MAT CENTRE	TATA spare parts
207568400139	ASSY.FLOOR MAT LH	TATA spare parts
207568400140	ASSY.FLOOR MAT RH	TATA spare parts
207568400145	ASSY.FLOOR MAT RH BS6	TATA spare parts
207568400146	ASSY. FLOOR MAT CENTRE BS6	TATA spare parts
207568706301	COVER TOE PANEL TRIM LH	TATA spare parts
207568900101	ASSY. INSTRUMENT PANEL	TATA spare parts
207568900106	ASSY.COVER(PLASTIC INSTRUMENT PANEL)	TATA spare parts
207568900109	ASSY. KIT FOR LOCKS & KEY	TATA spare parts
207568900110	ASSY. KIT FOR LOCKS & KEY(COMMON KEY)	TATA spare parts
207568900114	ASSY LOCK GLOVE BOX	TATA spare parts
207568900115	ASSY INSTRUMENT PANEL RHD	TATA spare parts
207568900120	ASSY. MOBILE HOLDER	TATA spare parts
207568906301	LID CENTRE	TATA spare parts
207568906302	LID CENTRE	TATA spare parts
207568906303	NACELLE FRONT	TATA spare parts
207568906304	NACELLE REAR	TATA spare parts
207568906316	LID CENTER	TATA spare parts
207569000101	ASSY.CORNER PANEL LH(RHD) BS6	TATA spare parts
207569000102	ASSY. CORNER PANEL RH(RHD) BS6	TATA spare parts
207569506301	CLIP	TATA spare parts
207569507701	RUBBER CAP(HAND HOLD)	TATA spare parts
207572000101	ASY.DOOR COMPL.WITH PADDING L.H.	TATA spare parts
207572000102	ASY.DOOR COMPL.WITH PADDING R.H.	TATA spare parts
207572000105	ASSY. DOOR SHELL LH BS1/2/3/4	TATA spare parts
207572000106	ASSY DOOR SHELL RH	TATA spare parts
20757200010635	ASSY. DOOR SHELL RH+CED+SEAL BS1/2/3/4	TATA spare parts
207572100101	ASSY.GUIDE FRAME(REAR)LH	TATA spare parts
207572100102	ASSY.GUIDE FRAME(REAR)RH	TATA spare parts



207572100104	ASSY.GUIDE FRAME(FRONT)LH	TATA spare parts
207572100105	ASSY.GUIDE FRAME(FRONT)RH	TATA spare parts
207572300103	ASSY. HANDLE(WINDOW WINDING)	TATA spare parts
207572300104	ASSY. DOOR HINGE SEAL(FRONT) BS6	TATA spare parts
207572300105	ASSY. DOOR HINGE SEAL(REAR) BS6	TATA spare parts
207572300107	RUBBER BEADING(DOOR STOPPER)	TATA spare parts
207572300109	RUBBER BEADING ASSY DOOR APERTURE BS6	TATA spare parts
207572300110	STOPPER FRONT DOOR LH BS6	TATA spare parts
207572300111	STOPPER FRONT DOOR RH BS6	TATA spare parts
207572306302	PLASTIC SKIRT(DOOR)	TATA spare parts
207572306303	FOAM(X-LINK)	TATA spare parts
207572306304	PLASTIC MEMBRANE LH(DOOR)	TATA spare parts
207572306305	PLASTIC MEMBRANE RH(DOOR)	TATA spare parts
207572307707	DOOR OUTER SEAL LH	TATA spare parts
207572307708	DOOR OUTER SEAL RH	TATA spare parts
207572308201	COVER DOOR POST BS6	TATA spare parts
207572500112	ASSY.QUARTER WINDOW LH	TATA spare parts
207572500113	ASSY.QUARTER WINDOW RH	TATA spare parts
207572500114	ASSY.WEATHER STRIP (INNER) LH	TATA spare parts
207572500115	ASSY.WEATHER STRIP (INNER) RH	TATA spare parts
207572500118	ASSY.WINDOW REGULATOR LH(SHIVANI LOCKS)	TATA spare parts
207572500119	ASSY.WINDOW REGULATOR RH(SHIVANI LOCKS)	TATA spare parts
207572500120	ASSY.W/STRIP TURNING WINDOW LH	TATA spare parts
207572500121	ASSY.W/STRIP TURNING WINDOW RH	TATA spare parts
207572500122	ASSY. OUTER BEADING SFC LH(DOOR)	TATA spare parts
207572500123	ASSY. OUTER BEADING SFC RH(DOOR)	TATA spare parts
207572500124	ASSY. CHANNEL PROFILE(WINDOW REGULATOR)	TATA spare parts
207572500128	BEADING ASSY TURNING WINDOW LH	TATA spare parts
207572500129	BEADING ASSY TURNING WINDOW RH	TATA spare parts
207572500130	OUTER BEADING ASSY LH	TATA spare parts
207572500131	OUTER BEADING ASSY RH	TATA spare parts
207572500132	QUARTER WINDOW ASSY LH	TATA spare parts
207572500133	QUARTER WINDOW ASSY RH	TATA spare parts
207572506305	GRAB HANDLE(DOOR)	TATA spare parts
207572506306	DOOR LOCK COVER LH(DOOR PAD)	TATA spare parts
207572506307	DOOR LOCK COVER RH(DOOR PAD)	TATA spare parts
207572706301	COVER BS6	TATA spare parts
207581050101	ASSY. GRAB HANDLE (TOP RAIL)	TATA spare parts
207581100102	ASSY SUNVISOR	TATA spare parts
207581100108	KIT FOR ASSY RVM COMPLETE FOR SE/SK CAB	TATA spare parts
207581100114	KIT-ORVM LH BS6	TATA spare parts
207581100116	KIT-ORVM RH BS6	TATA spare parts
207581100119	KIT-ORVM LH BS6	TATA spare parts
207581100122	KIT-ORVM RH BS6	TATA spare parts
207581106302	CLAMP(CENTRE FLAP STAY ROD)	TATA spare parts
207581106303	RETRO-REFLECTIVE TAPE	TATA spare parts
207581106304	RETRO-REFLECTIVE TAPE	TATA spare parts

207581106305	RETRO-REFLECTIVE TAPE WHITE 1120 LG	TATA spare parts
207581116301	STICKER BHARAT STG. III	TATA spare parts
207581506901	HAND HOLD RH BS6	TATA spare parts
207581506902	HAND HOLD LH BS6	TATA spare parts
207581506905	HAND HOLD LH BS6	TATA spare parts
207581900107	ASSY ENGINE SIDE SHIELD FRONT LH	TATA spare parts
207581900108	ASSY ENGINE SIDE SHIELD FRONT RH	TATA spare parts
207581900109	ASSY ENGINE SHIELDING LH (REAR EXTN)	TATA spare parts
207581900110	ASSY ENGINE SHIELDING RH (REAR EXTN)	TATA spare parts
207581900114	ASSY. ENGINE SIDE SHIELD FRONT RH	TATA spare parts
207581900119	ASSY. ENGINE SIDE SHIELD LH(FRONT)	TATA spare parts
207581900120	ASSY. ENGINE SIDE SHIELD RH(FRONT)	TATA spare parts
207581900121	ASSY. ENGINE SIDE SHIELD LH(REAR)	TATA spare parts
207581900122	ASSY. ENGINE SIDE SHIELD RH(REAR)	TATA spare parts
207581900129	ASSY. ENGINE SIDE SHIELD FRONT LH	TATA spare parts
207581900130	ASSY. ENGINE SIDE SHIELD FRONT RH	TATA spare parts
207581900131	ASSY. SIDE NOISE SHIELD (RH)	TATA spare parts
207581900133	SIDE SHIELD ASSY- FRONT LH	TATA spare parts
207581900134	SIDE SHIELD ASSY.- REAR LH	TATA spare parts
207581900135	ASSY. ENGINE SIDE SHIELD FRONT LH	TATA spare parts
207581900136	ASSY. ENGINE SIDE SHIELD REAR LH	TATA spare parts
207581900137	ASSY. ENGINE SIDE SHIELD FRONT RH	TATA spare parts
207581900138	ASSY. ENGINE SIDE SHIELD REAR RH	TATA spare parts
207581906317	PLUG GROMMET BS6	TATA spare parts
207581907710	GROMMET FLOOR	TATA spare parts
207582400111	ASSY. KIT FOR WIPER ACCESSORIES	TATA spare parts
207583100101	RUBBER BEADING(FLAP)	TATA spare parts
207583200101	CLOSING PLATE ASSY	TATA spare parts
207583300101	ASSY. CABLE (AIR SCOOP)	TATA spare parts
207583300102	ASSY. CABLE (AIR SCOOP)LH	TATA spare parts
207583805601	HANDLE (VENTILATION FLAP)	TATA spare parts
207588016303	FENDER FRONT LH BS1/2/3/4	TATA spare parts
207588016304	FENDER FRONT RH BS1/2/3/4	TATA spare parts
207588016305	MUDFLAP LH (SPRAY SUPPRESSION) SE/SK	TATA spare parts
207588016306	MUDFLAP RH (SPRAY SUPPRESSION) SE/SK	TATA spare parts
207588017701	BEADING FENDER. ( SFC )	TATA spare parts
207588050105	ASSY. COVER(BUMPER)-LH	TATA spare parts
207588050106	ASSY. COVER(BUMPER)-RH	TATA spare parts
207588500107C0	ASSY BUMPER WITH REFLECTOR_FUPD - BLACK	TATA spare parts
207588500108	ASSY.BUMPER COMPLETE	TATA spare parts
207588700101	ENGINE HOOD	TATA spare parts
207588700103	ASSY. ENGINE HOOD COMPLETE	TATA spare parts
207588700106	ASSY ENGINE HOOD COMPLETE	TATA spare parts
207588700107	ASSY. ENGINE HOOD COMPLT. BS6	TATA spare parts
207588700108	ASSY SEALING RUBBER(ENGINE HOOD)	TATA spare parts
207588706302	ENGINE HOOD (FRP) SE 1613 TC	TATA spare parts
207588707702	SEALING RUBBER-ENGINE HOOD	TATA spare parts

207588707705	SEALING-ENGINE HOOD	TATA spare parts
207588707706	SEALING-ENGINE HOOD	TATA spare parts
207588707707	SEALING-ENGINE HOOD	TATA spare parts
207589010101	ASSY.BKT COMPLT.LH(CAB MT	TATA spare parts
207589010102	ASSY.BKT.COMPLT.RH(CAB MT	TATA spare parts
207589010104	ASSY BRACKET LH(CAB MTG. FRONT) SK1615 T	TATA spare parts
207589010105	ASSY BRACKET RH(CAB MTG. FRT) SK 1615 TC	TATA spare parts
207589010107	ASSY BRACKET COMPLTLH-CAB MTG FRONT	TATA spare parts
207589010108	ASSY BRACKET COMPLT RH-CAB MTG FRONT	TATA spare parts
207589010112	ASSY.BRACKET COMPLETE LH CAB MTG.FRONT	TATA spare parts
207589010113	ASSY.BRACKET COMPLETE RH CAB MTG.FRONT	TATA spare parts
207589010117	ASSY. BKT. COMPLT.(CAB MTG. FRONT)	TATA spare parts
207589100103	ASSY BRACKET REAR LH	TATA spare parts
207589100104	ASSY BRACKET REAR RH	TATA spare parts
207589100108	ASSY BRACKET LH-REAR MTG	TATA spare parts
207589100109	ASSY BRACKET RH-MTG REAR	TATA spare parts
207589100118	ASSY BRACKET COMPLT LH (CAB MTG.FRONT)	TATA spare parts
207589100119	ASSY BRACKET COMPLT RH (CAB MTG FRONT)	TATA spare parts
207589100124	ASSY. BRACKET COMPLT.RH(CAB MTG. REAR)	TATA spare parts
207589100126	ASSY. BRACKET COMPLT.LH(CAB MTG.REAR)	TATA spare parts
207589100127	ASSY. BRACKET COMPLT. LH(CAB MTG.FRONT)	TATA spare parts
207589100128	ASSY. BRACKET COMPLT. RH (CAB MTG FRONT)	TATA spare parts
207591000101	ASSY. DRIVER'S SEAT	TATA spare parts
207591000104	ASSY.DRIVER SEAT COMP.	TATA spare parts
207591040101	ASSY.CO DRIVER SEAT RHD	TATA spare parts
207591500102	ASSY. SEAT BELT KIT	TATA spare parts
207591700101	ASSY. MOUNTING FRAME	TATA spare parts
207594000107	ASSY.CO-DRIVER SEAT COMP.	TATA spare parts
207597500101	SEAT BELT ASSY 3-PT NON ELR CO-DRIVER FR	TATA spare parts
207597500102	SEAT BELT ASSY 3-PT NON ELR DRIVER FRONT	TATA spare parts
207597500106	SEAT BELT ASSY NON ELR FRONT BS6	TATA spare parts
207597500107	CABLE BUCKLE ASSY CO-DRIVER BS6	TATA spare parts
207597500108	CABLE BUCKLE ASSY DRIVER BS6	TATA spare parts
207597500111	KIT-SEAT BELT ASSY 3-PT NON ELR FRONT BS	TATA spare parts
207597500113	KIT-SEAT BELT ASSY 3-PT NON ELR FRONT BS	TATA spare parts
207597500114	SEAT BELT ASSY 3-PT NON ELR CO-DRIVER FR	TATA spare parts
207598806301	MASCOT 1615TC	TATA spare parts
207599100101	PIN(WITH NYLON INSERT)	TATA spare parts
207601000124	ASSY 6BT ENG.125HP 12V	TATA spare parts
207601000128	ENGINE ASSY	TATA spare parts
207601000133	ASSY 6BT ENG.125HP 12V 4PT MTG SE1613TC	TATA spare parts
207601000135	6BT ENG.125HP 24V 4PT MTG LP/LPO 1512TC	TATA spare parts
207601000137	ASSY ENG 125 HP 24 V EURO II LPO1512TC	TATA spare parts
207601000145	ASSY 6BTAA(160HP) LM ENG OPTION DRG-24V	TATA spare parts
207601000160	ASSY. ENG. 6BT 125 HP 4-PT MNTG 24V L	TATA spare parts
207601000166	ASSY ENG LMRO LP/LPO 100HP EUROII 24 V	TATA spare parts
207601000168	ASSY ENG 6BT-100HP 24V-VISCOUS-LPO1610TC	TATA spare parts

207601000170	ASSY ENG LMFO RE 100HP EUROII 24 V	TATA spare parts
207601000176	ASSY ENG 6BTA 160 HP LM LOWERED LHD E II	TATA spare parts
207601000180	OPTION DRG 6BTA-EII 24V-45A 160HP ENGINE	TATA spare parts
207601000182	ASSY ENGINE COMPLETE 6BTAA-160 H.P.12V	TATA spare parts
207601000190	ASSY.6BT(145HP)CUMM.ENGINE	TATA spare parts
207601000191	6BT-145HP12V W/O CL&CL.HSG-LPT1615	TATA spare parts
207601000194	ASSY.ENGINE 6BTA 160HP-LPK2516W/O C/STAR	TATA spare parts
207601000211	ENGINE ASSY-OPTION DRG	TATA spare parts
207601000216	ENGINE 6BTAA 180HP 24V-LMFO	TATA spare parts
207601000231	ASSY ENGINE 6BTAA 160 HP E II LMFO LOWER	TATA spare parts
207601000232	ENGINE 6BTAA-12HP LPO 1512	TATA spare parts
207601000235	ASSY ENGINE 180 HP FOR LPO 1318 BS-II	TATA spare parts
207601000237	ENGINE 6BTAA EII 160HP ENG RETARDER	TATA spare parts
207601000241	ASSY ENGINE LPO 1612RE BS3 130HP	TATA spare parts
207601000253	ENGINE B5.9-230HP BS III CNG LN BURN	TATA spare parts
207601000254	ENGINE 6B-TAA-235HP-24V BS-II	TATA spare parts
207601000260	ASSY ENGINE 6BT5.9TAA 180HP 2X24V EII	TATA spare parts
207601000266	ENGINE B5.9-230G BS3 CNG-AUTOTRAN	TATA spare parts
207601000273	ENGINE 6BTAA 125BS2-24V-VP14-LMRO	TATA spare parts
207601000281	ASSY. ENGINE COMP. 6BT-235HP LHD BS2	TATA spare parts
207601000286	ENGINE 130HP-24V-BS3 NEW RECP	TATA spare parts
207601000290	ENGINE 6B-TAA-180HP-24V BS-III(FE)	TATA spare parts
207601000293	ENGINE130HP-24V-BS3 NEW RECIPE	TATA spare parts
207601000295	ENG. OPT. LIST 6BTAA 160HP BS-I 12V-LMRO	TATA spare parts
207601000303	ASSY. ENGINE COMPLETE 6 BTAA 180 HP EU	TATA spare parts
207601000304	ASSY. ENGINE COMPLETE 6 BTAA 180 HP EU	TATA spare parts
207601000305	ENGINE 130HP-24V-BS3 230CC A/C	TATA spare parts
207601000311	ENGINE 210HP 24V EURO-IV	TATA spare parts
207601000313	ASSY ENGINE COMPLETE LPK 2518C BS3	TATA spare parts
207601000316	ENGINE LPK2518 BSIII (NEW RECIPE)	TATA spare parts
207601000322	ENGINE 6BTAA 155HP-24V-LMFO BS3	TATA spare parts
207601000329	ENGINE 6B5.9TAA-235HP-BS3.	TATA spare parts
207601000330	ASSY ENGINE 6B-235HP-BS3	TATA spare parts
207601000331	OPTION DRG 6BTAA-235HP-BSII/LPK1623	TATA spare parts
207601000333	ENGINE 6BTAA -180 HP-24V BS	TATA spare parts
207601000335	ENGINE 6B5.9TAA-235HP-BS3	TATA spare parts
207601000341	ENGINE LPTA 1623 BSIII ISBE	TATA spare parts
207601000345	ENGINE 160HP LPO 1616 BSIV LMFO	TATA spare parts
207601000349	ASSY. ENGINE COMP. 6BT BS3	TATA spare parts
207601000351	ENGINE 145HP 24V BS-II LPA 1415	TATA spare parts
207601000357	ASSY.6BTAA-180HP BSIII/380 DIA CLUTCH	TATA spare parts
207601000363	ASSY ENGINE COMPLETE FOR NEW RECP. 6BT-1	TATA spare parts
207601000365	ASSY-6BTAA-180HP-BS3-NEW REC ENG-WITH AC	TATA spare parts
207601000367	ENGINE 6BTAA.215 AT 2500 .24V.LMFO.BS3	TATA spare parts
207601000368	ENGINE 6BTAA-215HP-BS3-IMP-REC-LPK2	TATA spare parts
207601000370	ASSY-6BTAA-180HP-BS3-NEW-REC-ENG/LPK3118	TATA spare parts
207601000373	AASY ENGINE 180 HP BS3 ENHD OIL DRAIN IN	TATA spare parts

207601000382	ASSY ENGINE COMPLETE 6BT (125 HP) LOW MO	TATA spare parts
207601000386	ENGINE B5.9 MECH(155HP)	TATA spare parts
207601000390	ENGINE 6BTAA-180HP BSIII-AUTO DRAIN	TATA spare parts
207601000391	ENGINE WITH AUTO DRAIN 180HP	TATA spare parts
207601000393	ENGINE BSIII (NEW RECIPE)	TATA spare parts
207601000394	ASSY. ENGINE COMP. 6BT 180HP 3RV BS3	TATA spare parts
207601000395	ENGINE OPTION LIST ASSY	TATA spare parts
207601000398	ASSY. ENGINE COMP. 6BT BS3	TATA spare parts
207601010103	ENG. OPTION LIST 130HP HE250 TURBO BS3	TATA spare parts
207601010109	ASSY. ENGINE COMPLETE LMRO E6(HE250) BS3	TATA spare parts
207601010114	ASSY.ENGINE	TATA spare parts
207601010116	ENGINE ASSY-OPTION DRG	TATA spare parts
207601010118	ENGINE ASSY-OPTION DRG	TATA spare parts
207601010120	ASSY ENGINE COMPLETE	TATA spare parts
207601010121	ENGINE ASSY	TATA spare parts
207601010124	ENGINE OPTION LIST	TATA spare parts
207601010133	ENGINE ASSY-OPTION DRG	TATA spare parts
207601010142	ENGINE ASSY-OPTION LIST	TATA spare parts
207601010162	ENGINE ASSY	TATA spare parts
207601170101	ASSY. OIL FILLER PIPE COMPLETE	TATA spare parts
207607106001	LEVER FUEL INJECTION PUMP	TATA spare parts
207607150101	ASSY. BRACKET ( COLD START PILOT)	TATA spare parts
207609113303	CLAMP (FOR TC INLET PIPE)	TATA spare parts
207609113304	BRACKET-BABY FILTER MTG	TATA spare parts
207609130102	ASSY. AIR FILTER MTG. BRACKET	TATA spare parts
207609130103	ASSY. AIR FILTER-TELCO OFFER DRG.	TATA spare parts
207609130106	ASSY.AIR FILTER MTG BRACKET.	TATA spare parts
207609130108	ASSY AIR FILTER LPO 1313 TC	TATA spare parts
207609130109	ASSY. PIPE WITH FLANGE-LHD	TATA spare parts
207609130110	ASSY. AIR CLEANER	TATA spare parts
207609130117	ASSY. BRACKET ( SNORKEL MTG UPPER)	TATA spare parts
207609130118	ASSY. BRACKET ( SNORKEL MTG LOWER)	TATA spare parts
207609130134	ASSY.PROTECTIVE COVER	TATA spare parts
207609130136	ASSY AIR INTAKE PIPE	TATA spare parts
207609130137	ASSY STRAP WITH SHACKLE-COMPLETE	TATA spare parts
207609130145	ASSY AIR FILTER MTG BRACKET	TATA spare parts
207609130148	ASSY AIR FILTER LPO 1313 TC	TATA spare parts
207609130155	ASSY.AIR CLEANER	TATA spare parts
207609130181	ASSY AIR CLEANER	TATA spare parts
207609130183	ASSY AL-PIPE	TATA spare parts
207609130189	ASSY.KIT AIRFILTER COMP	TATA spare parts
207609130194	ASSY AIR CLEANER	TATA spare parts
207609130195	ASSEMBLY PRE-CLEANER	TATA spare parts
207609130196	ASSEMBLY MOUNTING BRACKET	TATA spare parts
207609130197	ASSY VACCUM INDICATOR PIPE	TATA spare parts
207609130198	VACUUM INDICATOR	TATA spare parts
207609130199	ASSY AIR CLEANER	TATA spare parts

207609130200	ASSY AIR INLET SNORKEL	TATA spare parts
207609130207	ASSY AIR FILTER	TATA spare parts
207609130208	ASSY BRACKET(AIR FILTER MTG.)	TATA spare parts
207609130210	ASSY.BRACKET-UPPER(AIR DUCT MTG.)	TATA spare parts
207609130212	ASSY KIT AIR FILTER	TATA spare parts
207609130213	ASSY CONNECTOR FLOOR MTD.	TATA spare parts
207609130214	ASSY SNORKEL BOX	TATA spare parts
207609130215	ASSY PRECLEANER	TATA spare parts
207609130216	ASSY BRACKET-AT REAR WALL(PREFILTER MTG)	TATA spare parts
207609130217	BRACKET(AIR INLET DUCT MTG)	TATA spare parts
207609130258	ASSY. AIR FILTER LPO 1316	TATA spare parts
207609130259	ASSY. AIR INLET DUCT (COMPLETE)	TATA spare parts
207609130260	ASSY AIR FILTER WITH STOPPER CONE	TATA spare parts
207609130261	ASSY BRACKET AIR INLET DUCT MTG-TOP	TATA spare parts
207609130262	ASSY BRACKET (AIR INLET DUCT MTG BOTTOM)	TATA spare parts
207609130263	ASSY AIR FILTER MTG BRACKET	TATA spare parts
207609130266	ASSY STRAP WITH SHACKLE	TATA spare parts
207609130270	ASSY. PIPE	TATA spare parts
207609130274	ASSY PIPE (AIR FILTER TO TURBO)	TATA spare parts
207609130275	ASSY. BRACKET (AIR INTAKE CLAMPING)	TATA spare parts
207609130276	ASSY MUDGUARD & AIR FILTER MTG. BKT	TATA spare parts
207609130283	ASSY STRAP WITH SHACKLE	TATA spare parts
207609130284	ASSY BRACKET(PRE FILTER MTG)	TATA spare parts
207609130285	ASSY. AIR INTAKE PIPE	TATA spare parts
207609130289	BRACKET FOR PIPE HOLDING	TATA spare parts
207609130290	BRACKET FOR PIPE HOLDING	TATA spare parts
207609130293	ASSY RESTRICTION INDICATOR PIPE	TATA spare parts
207609130295	ASSY AIR INLET SNORKEL	TATA spare parts
207609130298	ASSY VACCUM INDICATOR HOSE	TATA spare parts
207609130304	ASSY BRACKET(FOR AIR FILTER MTG)	TATA spare parts
207609130315	ASSY PIPE WITH FLANGE (AIR FILTER)	TATA spare parts
207609130320	ASSY FLANGED PIPE FOR NATURAL ASPIR	TATA spare parts
207609130321	ASSY BKT FOR SERVICE INDICATOR MTG	TATA spare parts
207609130323	ASSY PIPE WITH FLANGE FOR WITH FACE COWL	TATA spare parts
207609130324	AIR INTAKE ASSY. PIPE	TATA spare parts
207609130326	PIPE ASSY	TATA spare parts
207609130329	AIR CLEANER ASSY	TATA spare parts
207609130330	KIT-AIR INTAKE	TATA spare parts
207609130334	CLAMP AIR FILTER BS6	TATA spare parts
207609130335	KIT-AIR INTAKE SYSTEM	TATA spare parts
207609130339	REDUCER HOSE	TATA spare parts
207609130340	AIR CLEANER ASSY WITH MTG BRACKET	TATA spare parts
207609130341	KIT-AIR INTAKE ASSY	TATA spare parts
207609130345	SERVICE INDICATOR	TATA spare parts
207609133321	BRACKET AIR INTAKE	TATA spare parts
207609133349	SUPPORT BKT. DUCT MTG. G1150	TATA spare parts
207609133350	SUPPORT BKT. DUCT MTG.	TATA spare parts

207609133352	BRACKET DIPSTICK MTG	TATA spare parts
207609133801	AIR INTAKE PIPE INTMD.FITLER TO TC	TATA spare parts
207609133802	AIR INTAKE PIPE	TATA spare parts
207609133809	AL. CAST PIPE	TATA spare parts
207609133810	AL. CAST PIPE LPO LHD	TATA spare parts
207609133811	AIR INTAKE PIPE	TATA spare parts
207609133822	AL CAST PIPE-2	TATA spare parts
207609133824	AL CAST PIPE	TATA spare parts
207609133828	PIPE AIR INTAKE	TATA spare parts
207609133832	AL PIPE FOR AIR FILTER	TATA spare parts
207609133835	AIR INTAKE PIPE (NATURAL ASPIRATION)	TATA spare parts
207609133837	PIPE AIR INTAKE	TATA spare parts
207609133838	PIPE AIR FILTER TO TC	TATA spare parts
207609134201	CLAMP-FOR AIR DUCT HOLDING	TATA spare parts
207609134203	T BOLT TYPE HOSE CLAMP	TATA spare parts
207609134204	COATED CLAMP (DIA 127)	TATA spare parts
207609134205	COATED CLAMP (DIA 114)	TATA spare parts
207609135801	HOSE	TATA spare parts
207609135806	HOSE (AIR FILTER TO PIPE) 1510CNG	TATA spare parts
207609135807	RUBBER HOSE-AT TC INTAKE	TATA spare parts
207609135808	RUBBER HOSE-AT AIR FILTER	TATA spare parts
207609135810	RUBBER HOSE.1/LPO 1313	TATA spare parts
207609135811	RUBBER HOSE	TATA spare parts
207609135814	RUBBER HOSE	TATA spare parts
207609135820	HOSE (T.C.END) LPTA 713 TC	TATA spare parts
207609135822	HOSE (TC END) LPO916/42 LHD BS II	TATA spare parts
207609135823	HOSE (A/F OUT LET )	TATA spare parts
207609135830	HOSE ( A/F OUTLET )LPO916/42 LHD BS II	TATA spare parts
207609135834	RUBBER HOSE-AIRFILTER INLET	TATA spare parts
207609135835	ELBOW HOSE	TATA spare parts
207609135836	REDUCER HOSE (OF AIR FILTER OUTLET)	TATA spare parts
207609135837	REDUCER HOSE (TC INLET)	TATA spare parts
207609135838	CORROGATED HOSE(AIR FILTER TO TC)BS2/3/4	TATA spare parts
207609135839	HOSE (PRE-CLEANER TO AIR FILTER)	TATA spare parts
207609135841	HOSE DIA 127X320	TATA spare parts
207609135843	REDUCER HOSE (ON AIR FILTER OUTLET)	TATA spare parts
207609135844	REDUCER HOSE (ON AIR FILTER OUTLET)	TATA spare parts
207609135848	RUBBER BELOW ( PRE CLEANER TO AIR FILTER	TATA spare parts
207609135849	RUBBER HOSE (AT TURBO OUTLET	TATA spare parts
207609135855	ELBOW HOSE	TATA spare parts
207609135856	RUBBER HOSE (AIR FILTER OUTLET	TATA spare parts
207609135859	RUBBER HOSE (FROM AIR FILTER OUTLET)	TATA spare parts
207609135864	REDUCER HOSE	TATA spare parts
207609135866	HOSE BET AIR FILTER AND PRECLEANER	TATA spare parts
207609135867	RUBBER HOSE (AT AIR FILTER)	TATA spare parts
207609135877	HOSE(TC INLET)	TATA spare parts
207609135883	HOSE RUBBER (AT AIR FILTER)	TATA spare parts

207609135884	REDUCER HOSE DIA 102 TO 76	TATA spare parts
207609135885	REDUCER HOSE	TATA spare parts
207609135886	RUBBER HOSE AIR FILTER OUTLET	TATA spare parts
207609135890	HOSE REDUCER AIR FILTER	TATA spare parts
207609135891	REDUCER HOSE	TATA spare parts
207609136906	ASSY PIPE (TC TO AIR FILTER)	TATA spare parts
207609136913	ASSY PIPE (TC TO AIR FILTER)	TATA spare parts
207609136921	AIR INTAKE PIPE	TATA spare parts
207609136950	AIR INLET PIPE-I	TATA spare parts
207609136951	AIR INLET PIPE-II	TATA spare parts
207609136954	AIR INTAKE PIPE	TATA spare parts
207609136956	PIPE ASSY	TATA spare parts
207609136998	PIPE-1	TATA spare parts
207609136999	PIPE-2	TATA spare parts
207609137113	BRACKET-A/FILTER MTG.	TATA spare parts
207609137114	L BRACKET TWISTED (SNORKEL)	TATA spare parts
207609137123	SAPCER - FRONT	TATA spare parts
207609137124	SPACER-REAR	TATA spare parts
207609137133	L BKT TWISTED (SNORKEL)	TATA spare parts
207609137701	AIR INLET PIPE	TATA spare parts
207609137702	AIR INLET DUCT-TOP	TATA spare parts
207609137705	AIR INTAKE SNORKEL	TATA spare parts
207609138216	CLAMP	TATA spare parts
207609139903	ADOPTOR M10X1	TATA spare parts
207609139909	MOUNTING BRACKET BOTTOM STRIP	TATA spare parts
207609140101	ASSY SNORKEL MESH	TATA spare parts
207609140102	ASSY AIR FILTER	TATA spare parts
207609140103	AIR CLEANER ASSY	TATA spare parts
207609140104	PRECLEANER METAL	TATA spare parts
207609140105	ASSY AIR PRECLEANER MOUNTING BRACKET	TATA spare parts
207609140117	ASSY. AIR FILTER W/DUCT PRECLEANER BS3/4	TATA spare parts
207609140256	BRACKET ASSY	TATA spare parts
207609146902	PIPE (AIR FILTER)	TATA spare parts
207609146903	ASSY PIPE WITH FLANGE	TATA spare parts
207609146904	ALUMINIUM PIPE (A/F TO TC)	TATA spare parts
207609990102	KIT-AIR FILTER & AIR PRE FILTER	TATA spare parts
207613130105	ACCESSORY DRIVE GEAR	TATA spare parts
207613130106	PIPE ASSY	TATA spare parts
207613130109	PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
207613136903	FLEXIBLE HOSE	TATA spare parts
207613136904	PLAIN HOSE COUPLING	TATA spare parts
207613136905	ELBOW HOSE COUPLING	TATA spare parts
207613136906	PLAIN HOSE	TATA spare parts
207613136907	PLAIN HOSE COUPLNG	TATA spare parts
207613136908	PLAIN STREET PIPE ELBOW	TATA spare parts
207613136909	PLAIN HOSE	TATA spare parts
207613136910	WATER INLET CONNECTION	TATA spare parts



207613136911	PIPE PLUG	TATA spare parts
207613138202	SPRING HOSE CLAMP	TATA spare parts
207613139901	AIR COMPRESSOR	TATA spare parts
207613139902	SEALING WASHER	TATA spare parts
207613139903	BANJO CONNECTOR SCREW	TATA spare parts
207613139904	AIR COMPRESSOR BRACE	TATA spare parts
207613139905	RECTANGULAR RING SEAL	TATA spare parts
207613139906	HEX FLANGE HEAD CAP	TATA spare parts
207613139907	STUD	TATA spare parts
207613139908	HEXAGON FLANGE NUT	TATA spare parts
207613139909	REDUCING PIPE BUSHING	TATA spare parts
207613139910	HEX FLANGE HEAD CAP SCREW	TATA spare parts
207613139911	HEX FLANGE HEAD CAP SCREW	TATA spare parts
207613139912	CLIP	TATA spare parts
207613139913	CLIP	TATA spare parts
207613139914	O RING SEAL	TATA spare parts
207613139915	HEX FLANGE HEAD CAP SCREW	TATA spare parts
207613139916	RECTANGULAR REAR SEAL	TATA spare parts
207614110103	EXHAUST GAS PROCESSOR	TATA spare parts
207614110105	DOC ASSY	TATA spare parts
207614580101	HEAT SHIELD	TATA spare parts
207614580103	ASSY. HEAT SHIELD	TATA spare parts
207614600101	ASSY. PIPE INTERCOOLER TO ENGINE (TURBO	TATA spare parts
207614600102	ASSY. PIPE INTERCOOLER TO ENGINE (TURBO	TATA spare parts
207614600105	PIPE (IC TO ENGINE)	TATA spare parts
207614600106	ASSY HOSE (TURBO ASPIRATION) LP1512	TATA spare parts
207614600107	ASSY PIPE	TATA spare parts
207614600109	ASSY HOSE WITH O-RING (TURBO ASPIRATION)	TATA spare parts
207614600112	PIPE IC TO ENGINE (LPO 1618 JNNURM)	TATA spare parts
207614600113	ASSY HOSE PIPE NATURAL AISPIRATION	TATA spare parts
207614600114	ASSY HOSE PIPE NATURAL AISPIRATION 22 ID	TATA spare parts
207614600115	INTERCOOLER ASSY	TATA spare parts
207614603301	BRACKET TC TO INTERCOOLER PIPE CLAMPING	TATA spare parts
207614603801	BENT PIPE (IC TO ENGINE )	TATA spare parts
207614603802	BENT PIPE- TC TO IC	TATA spare parts
207614603803	PIPE (TURBO CHARGER TO INTER COOLER )	TATA spare parts
207614603806	AL - PIPE ( TC TO ENGINE )	TATA spare parts
207614603807	BENT PIPE ( TC TO I/C )	TATA spare parts
207614603808	ALUMINIUM PIPE (TC TO IC)	TATA spare parts
207614603809	ALUMINIUM PIPE (TC TO IC)	TATA spare parts
207614603810	PIPE(IC TO ENGINE)	TATA spare parts
207614603817	PIPE-INTERCOOLER TO ENGINE	TATA spare parts
207614603820	PIPE ( INTERCOOLER TO ENGINE INLET )	TATA spare parts
207614603824	CAST PIPE INTERCOOLER TO ENGINE	TATA spare parts
207614603825	PIPE(TC TO INTERCOOLER)	TATA spare parts
207614603826	PIPE TC TO TANK	TATA spare parts
207614603827	PIPE (IC TO ENGINE)	TATA spare parts

207614603830	PIPE (TC TO IC)	TATA spare parts
207614603831	PIPE (IC TO ENGINE)	TATA spare parts
207614603832	BENT PIPE(IC TO CYL.HEAD INLET)	TATA spare parts
207614603834	PIPE(TC TO IC)	TATA spare parts
207614603835	PIPE (INTERCOOLER TO ENGINE)	TATA spare parts
207614603836	PIPE (IC TO ENGINE)	TATA spare parts
207614603843	PIPE ( TC TO IC)	TATA spare parts
207614603844	PIPE (IC TO INTAKE MANIFOLD)	TATA spare parts
207614603848	PIPE (TC TO IC)	TATA spare parts
207614603849	PIPE (TC TO IC)	TATA spare parts
207614603850	PIPE (IC TO ENGINE)	TATA spare parts
207614603855	ALUMINIUM PIPE (TC TO IC)	TATA spare parts
207614603857	PIPE IC TO ENGINE (NATURAL ASPIRATED)	TATA spare parts
207614603861	PIPE INTERCOOLER TO ENGINE	TATA spare parts
207614603862	PIPE TURBOCHARGER TO INTERCOOLER	TATA spare parts
207614603863	PIPE INTERCOOLER TO ENGINE	TATA spare parts
207614603864	PIPE TURBOCHARGER TO INTERCOOLER	TATA spare parts
207614603867	PIPE INTERCOOLER TO ENGINE	TATA spare parts
207614603870	PIPE INTERCOOLER INTAKE	TATA spare parts
207614603871	PIPE INTERCOOLER	TATA spare parts
207614605802	HOSE HUMP BS4	TATA spare parts
207614605802AE	HOSE HUMPLPT 2523/	TATA spare parts
207614605845	HOSE HUMP	TATA spare parts
207614606901	PIPE(IC TO INTAKE MANIFOLD)	TATA spare parts
207614606902	PIPE	TATA spare parts
207614606903	PIPE	TATA spare parts
207614606908	PIPE(IC TO TC)	TATA spare parts
207614606915	PIPE(IC TO ENG)	TATA spare parts
207614606917	ALUMINIUM PIPE (TC TO IC)	TATA spare parts
207614606927	PIPE IC TO ENG	TATA spare parts
207614606933	PIPE ENGINE TO INTERCOOLER	TATA spare parts
207614606934	PIPE INTERCOOLER TO ENGINE	TATA spare parts
207614606935	PIPE ENGINE TO INTERCOOLER	TATA spare parts
207614606936	PIPE INTERCOOLER TO ENGINE	TATA spare parts
207614606937	PIPE INTERCOOLERTOTURBOCHARGER	TATA spare parts
207614606938	PIPE INTERCOOLERTOAIRINATKEPIPE	TATA spare parts
207614606941	PIPE ENGINE TO INTERCOOLER	TATA spare parts
207614606942	PIPE INTERCOOLER TO ENGINE	TATA spare parts
207614606943	PIPE TURBOCHARGER TO INTERCOOLER	TATA spare parts
207614606945	PIPE TC TO IC	TATA spare parts
207614606946	PIPE INTERCOOLER TO ENGINE	TATA spare parts
207614606947	PIPE TURBOCHARGER TO INTERCOOLER	TATA spare parts
207614606948	PIPE INTERCOOLER TO ENGINE	TATA spare parts
207614606949	PIPE TURBOCHARGER TO INTERCOOLER -	TATA spare parts
207614609905	INTER COOLER (LPO1512TC-EURO-II)	TATA spare parts
207614609907	INTERCOOLER	TATA spare parts
207614609908	INTERCOOLER - M/S TATA TOYO	TATA spare parts

207614609909	INTERCOOLER	TATA spare parts
207614609910	INTERCOOLER	TATA spare parts
207614609911	INTERCOOLER	TATA spare parts
207614609915	INTERCOOLER BS3	TATA spare parts
207614609916	INTERCOOLER	TATA spare parts
207614609917	ASSY. INTERCOOLER (LPK2523) BS2/3	TATA spare parts
207614609918	ASSY INTERCOOLER	TATA spare parts
207614609925	INTERCOOLER - LPO 130 HP BS-III	TATA spare parts
207614609926	INTERCOOLER - LPO 130 HP BS-III	TATA spare parts
207614609927	INTERCOOLER (LPTA1623 ISBE-TATATOYO)	TATA spare parts
207614609932	INTERCOOLER - LPO 130 HP BS-III	TATA spare parts
207614609933	INTERCOOLER FOR LPA 1415 TC BSII	TATA spare parts
207615999901	SCREW HEX FLANGE HEAD CAP	TATA spare parts
207615999902	PULLEY FAN RATIO 1.2 1 BS1/2/3/4	TATA spare parts
207615999903	BRACE ALTERNATOR	TATA spare parts
207620140105	ASSY BRACKET LH-TOP (FAN RING MTG)	TATA spare parts
207620140108	BRACKET ASSY FAN RING MTG TOP LH	TATA spare parts
207620140109	BRACKET ASSY FAN RING MTG TOP RH	TATA spare parts
207620143303	BRACKET LH (FOR FAN RING BOTTOM MTG)	TATA spare parts
207620143304	BRACKET RH (FOR FAN RING BOTTOM MTG)	TATA spare parts
207620143801	FAN RING (LPO 1612TC BS-III)	TATA spare parts
207620143802	FAN RING(LPK-2523 TC LHD)	TATA spare parts
207620150107	ASSY BKT WITH STOPPER(IDLER PULLEY)	TATA spare parts
207620150113	ASSEMBLY BRACKET.	TATA spare parts
207620150114	ASSY.BRACKET.	TATA spare parts
207620150115	ASSEMBLY BEARING HOUSING	TATA spare parts
207620150116	ASSY.ADJUSTING SCREW.	TATA spare parts
207620150118	SWING ARM ASSY.	TATA spare parts
207620150122	ASSEMBLY BRACKET( FAN DRIVE )	TATA spare parts
207620150123	ASSY.FAN RING MTG.BKT.LONG.	TATA spare parts
207620150124	ASSY.FAN RING MTG.BKT.SHORT.	TATA spare parts
207620150125	ASSY.BEARING HOUSING	TATA spare parts
207620150126	ASSY.BRACKET - FAN DRIVE	TATA spare parts
207620150127	ASSY BKT FAN DRIVE	TATA spare parts
207620150128	ASSY BEARING HSG	TATA spare parts
207620153101	BALL BEARING	TATA spare parts
207620153102	DEEP GROOVE BALL BEARING	TATA spare parts
207620153201	BOLT	TATA spare parts
207620153202	SHOULDER BOLT	TATA spare parts
207620153203	SHOULDER BOLT	TATA spare parts
207620153401	BUSH.	TATA spare parts
207620154701	COVER.	TATA spare parts
207620156301	COGGED V-BELT	TATA spare parts
207620156302	COGGED V BELT	TATA spare parts
207620157005	PULLEY- ENGINE	TATA spare parts
207620157006	PULLEY (FAN).	TATA spare parts
207620157007	IDLER PULLY	TATA spare parts

207620157010	PULLEY (FAN)	TATA spare parts
207620157902	SHAFT FOR VISCOUS FAN MTG 28	TATA spare parts
207620157903	SHAFT.	TATA spare parts
207620157905	SHAFT (FOR VISCOUS FAN WITH THREADED MTG)	TATA spare parts
207620158201	DUST COVER	TATA spare parts
207620158605	SPACER	TATA spare parts
207620158606	SPACER SLEEVE.	TATA spare parts
207620158607	SPACER.	TATA spare parts
207620158701	COMPRESSION SPRING.	TATA spare parts
207620159202	WASHER	TATA spare parts
207620159902	STOPPER BRACKET SWING ARM ASSY.	TATA spare parts
207623120102	ASSY BRACKET(A/C COMP MTG)	TATA spare parts
207650000101	ASSY. RADIATOR MTG. FRAME	TATA spare parts
207650000102	ASSY BRACKET (RAD MTG - ON CHASSIS -LH)	TATA spare parts
207650000103	ASSY.RADIATOR MTG.FRAME COMPLETE	TATA spare parts
207650000106	ASSY FRAME RADIATOR MTG.	TATA spare parts
207650000110	ASSY STUD	TATA spare parts
207650000112	ASSY.RADIATOR MTG.FRAME-COMPL.	TATA spare parts
207650000116	ASSY. RADIATOR MTG. FRAME	TATA spare parts
207650000126	ASSY BRACKET RAD. MTG - LH	TATA spare parts
207650000127	ASSY BRACKET (RAD MTG - RH)	TATA spare parts
207650000128	ASSY.RAD.MTG.FRAME-COMPL	TATA spare parts
207650000129	ASSY RADIATOR FRAME	TATA spare parts
207650000138	ASSY.RADIATOR FRAME	TATA spare parts
207650000144	ASSY BOLT WITH SQ WASHER .	TATA spare parts
207650000149	ASSY.RADIATOR MTG FRAME-COMplete	TATA spare parts
207650000150	ASSY RADIATOR MTG BRACKET-RH	TATA spare parts
207650000151	ASSY RADIATOR MTG. BRACKET-LH	TATA spare parts
207650000152	ASSY.RADIATOR MTG.BRACKET	TATA spare parts
207650000154	ASSY. RADIATOR MTG. FRAME	TATA spare parts
207650000157	ASSY. RADIATOR LPO1618 6BT BS3	TATA spare parts
207650000158	ENGINE COOLING SYSTEM-LPO1618 TC BS-III	TATA spare parts
207650000159	ASSY FRAME-RAD MTG-COMPL	TATA spare parts
207650000160	ASSY BRACKET-LH(RAD FRAME SIDE MTG)	TATA spare parts
207650000161	ASSY BRACKET-RH(RAD FRAME SIDE MTG)	TATA spare parts
207650000162	ASSY RADIATOR FRAME	TATA spare parts
207650000163	BRACKET-LH (RAD FRAME SIDE MTG.)	TATA spare parts
207650000164	BRACKET-RH (RAD FRAME SIDE MTG)	TATA spare parts
207650000167	ASSY MUDGUARD & AUX WATER TANK MTG BKT	TATA spare parts
207650000168	ASSY. BRACKET-LH (RAD FRAME SIDE MTG.)	TATA spare parts
207650000169	ASSY. BRACKET-RH (RAD FRAME SIDE MTG)	TATA spare parts
207650000170	ENG COOLING SYS-LPO1618TC BS-III(BMTC)	TATA spare parts
207650000180	ASSY RAD FRAME(LP 1512 1DEG TILTED ENG)	TATA spare parts
207650000181	ASSY RUBBER BUSH(227.5 LONG)	TATA spare parts
207650000182	ASSY. RADIATOR MTG. FRAME	TATA spare parts
207650000185	ASSY. COOLING SYSTEM BS3/4	TATA spare parts
207650000186	RADIATOR MTG BKT LH	TATA spare parts

207650000187	RADIATOR BKT (RH)	TATA spare parts
207650000189	ASSY RAD MTG BKT-RH	TATA spare parts
207650000190	ASSY RAD MTG BKT-LH	TATA spare parts
207650000191	ASSY ENGINE COOLING SYSTEM LPO	TATA spare parts
207650000194	ASSY BRACKET-RH(RAD FRAME SIDE MTG)	TATA spare parts
207650000195	ASSY BRACKET-LH(RAD FRAME SIDE MTG)	TATA spare parts
207650000196	ASSY RADIATOR & INTERCOOLER	TATA spare parts
207650000201	ASSY. RADIATOR LPO 1512TC BS3/4	TATA spare parts
207650000202	ASSY RADIATOR FRAME - LPO 130 HP TC BS-I	TATA spare parts
207650000203	ASSY. RADIATOR BS3	TATA spare parts
207650000207	ASSY RADIATOR - LPO 130 HP TC BS-III	TATA spare parts
207650000216	ASSY.BRIDGE(FOR AUX TANK MTG)	TATA spare parts
207650000219	BRACKET ON L.M.(RAD FRAME SIDE MTG)	TATA spare parts
207650000220	ASSY BRACKET RH (RAD MTG-ON CHASSIS)	TATA spare parts
207650000221	ASSY BRACKET LH (RAD MTG-ON CHASSIS)	TATA spare parts
207650000234	RADIATOR ASSY. MTG. BKT.	TATA spare parts
207650000236	BRACKET ASSY WITH BOSS (RAD FRAME MTG)	TATA spare parts
207650000237	ENGINE COOLING SYSTEM WITH BRACKET	TATA spare parts
207650000245	ENGINE COOLING SYSTEM ASSY	TATA spare parts
207650000247	BRACKET ASSY RADIATOR FRAME MTG	TATA spare parts
207650003304	MTG PLATE(RAD BOTTOM PIPE TO ENG PUMP)	TATA spare parts
207650003314	RAD MTG BKT BOTTOM RH	TATA spare parts
207650003315	RAD MTG BKT BOTTOM LH	TATA spare parts
207650006901	TUBE	TATA spare parts
207650006903	PIPE(RAD BOTTOM TO ENGINE PUMP)	TATA spare parts
207650007113	BENT PLATE-RH (RAD MTG WITH ENG CM )	TATA spare parts
207650007114	BENT PLATE-LH (RAD MTG WITH ENG C M )	TATA spare parts
207650007126	BEND PLATE;RADIATOR MTG;LH	TATA spare parts
207650007127	BRACKET;RADIATOR MTG(RH-SIDE)	TATA spare parts
207650007701	RUBBER FLAP(BETWEN RAD TOP & COWL)	TATA spare parts
207650007702	PP FLAP (BETWEEN RADIATOR TOPP & COWL)	TATA spare parts
207650008217	GUSSET-(RAD.MTG.)	TATA spare parts
207650008268	BRACKET-RAD BOTTOM MTG	TATA spare parts
207650009201	WASHER	TATA spare parts
207650009901	CONNECTOR	TATA spare parts
207650010101	RADIATOR	TATA spare parts
207650010103	ASSY WATER FILL PIPE	TATA spare parts
207650100102	KIT-ENGINE COOLING SYSTEM	TATA spare parts
207650100105	RADIATOR 1313	TATA spare parts
207650100109	ASSY. RADIATOR BLOCK COMPLETE	TATA spare parts
207650100116	ASSY. AUXILIARY WATER TANK	TATA spare parts
207650100117	ASSY. BRACKET	TATA spare parts
207650100119	ASSY. STRAP WITH SHACKLE COMP.	TATA spare parts
207650100124	ASSY. RADIATOR BLOCK COMPLETE	TATA spare parts
207650100126	KIT-COOLING SYSTEMN15	TATA spare parts
207650100129	RADIATOR ASSY	TATA spare parts
207650100134	ASSY. RADIATOR BLOCK COMPLETE	TATA spare parts

207650100142	SET COOLING PACKAGE	TATA spare parts
207650100144	RADIATOR FRAME	TATA spare parts
207650100148	PIPE ASSY RADIATOR TO OIL COOLER	TATA spare parts
207650100150	PIPE ASSY OIL COOLER TO ENGINE	TATA spare parts
207650100152	ASSY. RADIATOR BS1/2/3	TATA spare parts
207650100154	ASSY. RADIATOR BS1	TATA spare parts
207650100156	ASSY RADIATOR	TATA spare parts
207650100158	ASSY. RADIATOR COMPLETE	TATA spare parts
207650100162	ASSY.RADITOR	TATA spare parts
207650100164	ASSY. RADIATOR COMPLETE	TATA spare parts
207650100168	ASSY RADIATOR	TATA spare parts
207650100171	ASSY. AUX WATER TANK (LPO-LHD)	TATA spare parts
207650100172	BRACKET FOR AUX. WATER TANK MOUNTING	TATA spare parts
207650100177	ASSY.BRACKET-A.W.T. MTG.	TATA spare parts
207650100178	ASSY.AUX. WATER TANK	TATA spare parts
207650100179	ASSY. BRACKET (RADIATOR FRAME MOUNTING O	TATA spare parts
207650100181	ASSY RADIATOR-COMPL.	TATA spare parts
207650100183	ASSY PIPE ( RAD TO ENG )	TATA spare parts
207650100188	ASSY RADIATOR COMPLETE	TATA spare parts
207650100190	ASSY.RADIATOR COMPLETE	TATA spare parts
207650100193	BRACKET ASSY AUX WATER TANK MTG	TATA spare parts
207650100196	RADIATOR ASSY	TATA spare parts
207650100197	ASSY. AUXILIARY WATER TANK (8 LTS)	TATA spare parts
207650100201	ASSY RADIATOR BLOCK COMPLETE	TATA spare parts
207650100203	ASSY RADIATOR WITH INTERCOOLER	TATA spare parts
207650100204	ASSY. RADIATOR BS2/3	TATA spare parts
207650100205	ASSY.AUX.WATER TANK	TATA spare parts
207650100206	ASSY RADIATOR WITH INTERCOOLER	TATA spare parts
207650100207	ASSY. RADIATOR BS2	TATA spare parts
207650100209	ASSY.AUX.WATER TANK	TATA spare parts
207650100209AE	ASSY.AUX.WATER TANK -1415	TATA spare parts
207650100210	ASSY.MTG.BKT AUX.WATER TANK	TATA spare parts
207650100231	ASSY.AUX.WATER TANK	TATA spare parts
207650100236	ASSY RADIATOR WITH INTERCOOLER	TATA spare parts
207650100241	ASSY RADIATOR (TATA TOYO)	TATA spare parts
207650100253	ASSY RADIATOR LPO1616BS4	TATA spare parts
207650100254	ASSY INTERCOOLER LPO1616BS4	TATA spare parts
207650100255	RESERVE TANK	TATA spare parts
207650100261	ASSY RADIATOR+IC FOR LPA 1415 BSII	TATA spare parts
207650100262	ASSY RADIATOR FOR LPA 1415 BSII	TATA spare parts
207650100273	RADIATOR ASSY	TATA spare parts
207650100274	RADIATOR ASSY WITH INTERCOOLER	TATA spare parts
207650100275	KIT-ENGINE COOLING SYSTEM	TATA spare parts
207650100279	RADIATOR ASSY	TATA spare parts
207650100280	KIT-COOLING SYSTEM	TATA spare parts
207650100286	RADIATOR ASSY	TATA spare parts
207650100290	PIPE ASSY RADIATOR TO WATER PUMP	TATA spare parts

207650100292	PIPE RADIATOR TO RETARDER	TATA spare parts
207650100293	PIPE RETARDER TO ENGINE	TATA spare parts
207650100294	PIPE RETARDER TO ENGINE	TATA spare parts
207650100295	PIPE ASSY RADIATOR TO ENGINE	TATA spare parts
207650100296	PIPE ASSY	TATA spare parts
207650100299	INTERCOOLER ASSY	TATA spare parts
207650100303	PIPE RADIATOR TO RETARDER	TATA spare parts
207650100305	CHANNEL ASSY TOP	TATA spare parts
207650100314	FILLER NECK ASSY	TATA spare parts
207650100323	ENGINE COOLING SYSTEM ASSY	TATA spare parts
207650100327	RADIATOR ASSY	TATA spare parts
207650100334	PIPE ASSY RADIATOR TO WATER PUMP	TATA spare parts
207650100346	PIPE ASSY LCL WATER PUMP	TATA spare parts
207650100347	PIPE ASSY	TATA spare parts
207650103311	L-BRACKET	TATA spare parts
207650105804	HOSE (FROM ENGINE OUTLET )	TATA spare parts
207650105805	HOSE (ENGINE TO RADIATOR INLET ) BS4	TATA spare parts
207650105806	RUBBER HOSE	TATA spare parts
207650105808	HOSE(ENGINE TO RADIATOR INLET)	TATA spare parts
207650105816	HOSE WATER PUMP END	TATA spare parts
207650105818	HOSE(ENG.TO RADIATOR) LPTA 713/32TC	TATA spare parts
207650105824	RUBBER HOSE ENG TO RAD.	TATA spare parts
207650105825	RUBBER HOSE ENG. TO RAD.	TATA spare parts
207650105828	RUBBER HOSE 6 ID X 460 LG	TATA spare parts
207650105829	RUBBER HOSE(RADIATOR TO ENGINE INLET)	TATA spare parts
207650105840	RUBBER HOSE-WATER FILL LINE	TATA spare parts
207650105841	STRAIGHT HOSE	TATA spare parts
207650105842	RUBBER HOSE-RAD TO ENGINE	TATA spare parts
207650105844	RUBBER HOSE- ENG TO RADIATOR	TATA spare parts
207650105845	HOSE 6 ID X 80 LONG BS4	TATA spare parts
207650105846	RUBBER HOSE BS4	TATA spare parts
207650105847	RUBBER HOSE(RADIATOR TO WATER PUMP)	TATA spare parts
207650105848	HOSE ( DIA 28.6)	TATA spare parts
207650105849	VENT HOSE-RAD TO A.W.TANK	TATA spare parts
207650105851	REDUCER HOSE	TATA spare parts
207650105856	HOSE(RAD TO ENGINE-ON ENGINE)	TATA spare parts
207650105859	VENT HOSE-ENGINE TO AWT-700 LG	TATA spare parts
207650105860	RUBBER HOSE-RAD TO ENGINE	TATA spare parts
207650105861	RUBBER HOSE-RAD TO ENGINE	TATA spare parts
207650105863	RUBBER HOSE-AWT TO RADIATOR	TATA spare parts
207650105865	R/HOSE(RADTOENG. RAD)LPO916/42 LHD BS II	TATA spare parts
207650105866	R/HOSE(RADTOENG.ENG.)LPO916/42 LHD BS II	TATA spare parts
207650105868	RUBBER HOSE	TATA spare parts
207650105870	RUBBERHOSE ENG END(ENG TO RAD TOP TANK)	TATA spare parts
207650105871	RUBBER HOSE (RAD.BOTTOM TO ENG)	TATA spare parts
207650105872	HOSE (RADIATOR BOTTOM TO ENGINE)	TATA spare parts
207650105873	RUBBER HOSE-RAD END(RAD TOP TANK TO ENG)	TATA spare parts

207650105874	RUBBER HOSE-ENG END(RAD TOP TANK TO ENG)	TATA spare parts
207650105875	HOSE (AUX TANK TO VENT TUBE-ENGINE)	TATA spare parts
207650105878	HOSE	TATA spare parts
207650105879	HOSE	TATA spare parts
207650105889	HOSE	TATA spare parts
207650105891	HOSE	TATA spare parts
207650105895	HOSE (RADIATOR TO ENGINE) TOP	TATA spare parts
207650105896	HOSE (ENGINE TO RADIATOR) BOTTOM	TATA spare parts
207650105897	HOSE (RADIATOR BOTTOM TO WATER PUMP)	TATA spare parts
207650105899	HOSE (RAD. TO WATER FILL PIPE)	TATA spare parts
207650106327	FAN SHROUD	TATA spare parts
207650106903	WATER FILL PIPE	TATA spare parts
207650106904	FILL PIPE	TATA spare parts
207650106907	VENT TUBE (RADIATOR TO AUX. WATER TANK )	TATA spare parts
207650106908	VENT TUBE (ENGINE )	TATA spare parts
207650106910	VENT TUBE ASSY;AUX WATER TANK TO ENGINE	TATA spare parts
207650106916	WATER FILL PIPE(FROM A.W.T.TO RADIATOR)	TATA spare parts
207650106917	VENT TUBE(ENG.TO A.W.TANK)	TATA spare parts
207650106918	VENT TUBE(FROM RAD.TO A.W.TANK)	TATA spare parts
207650106919	PIPE (ENGINE TO RADIATOR )	TATA spare parts
207650106924	VENT PIPE (RADIATOR TO AUX WATER TANK)	TATA spare parts
207650106925	VENT TUBE (AUX. TANK TO ENG.)	TATA spare parts
207650106926	PIPE (COOLANT FILLING)	TATA spare parts
207650106927	WATER FILLER PIPE 1/LPO1512/53TC BS-III	TATA spare parts
207650106928	TUBE VENT ENG TO AUX WATER TANK	TATA spare parts
207650106936	VENT TUBE	TATA spare parts
207650106937	VENT TUBE	TATA spare parts
207650106945	WATER FILL PIPE	TATA spare parts
207650106954	WATER FILL PIPE	TATA spare parts
207650106960	VENT TUBE-ENGINE TO AWT	TATA spare parts
207650106961	VENT TUBE-RAD TO AWT	TATA spare parts
207650106972	VENT TUBE-ENG TO AWT	TATA spare parts
207650106973	VENT TUBE - RAD TO AWT	TATA spare parts
207650106974	WATER FILL PIPE	TATA spare parts
207650106976	WATER FILL PIPE	TATA spare parts
207650106977	VENT TUBE-RAD TO A.W.T.	TATA spare parts
207650106988	PIPE ( ENGINE TO RADIATOR )	TATA spare parts
207650106989	VENT TUBE (RADIATOR TO AUX. WATER TANK)	TATA spare parts
207650106992	WATERFILLPIPE(AUX.WATERTNKTORAD.BOTTOM)	TATA spare parts
207650106993	WATER FILL PIPE (ENG TO RAD.TOP TANK)	TATA spare parts
207650106994	VENT TUBE(RAD TO AUX WATER TANK)	TATA spare parts
207650106995	VENT TUBE(ENG AUX WATER TANK)	TATA spare parts
207650106996	WATER FILL PIPE (ON AUX WATER TANK)	TATA spare parts
207650106997	WATER FILL PIPE(RAD TOP TANK TO ENG)	TATA spare parts
207650106998	WATER FILL PIPE(INTERMEDIATE)	TATA spare parts
207650108220	PLATE -A.W.TANK MTG-INSIDE DASHBOARD	TATA spare parts
207650109901	RUBBER STRAP	TATA spare parts



207650110101	ASSY.PIPE(RADIATOR TO WATER PUMP)	TATA spare parts
207650110104	ASSY RADIATOR FRAME-LPT1615 BSIII-ARMY	TATA spare parts
207650110107	ASSY.BRACKET(TRANSLUCENT TANK)	TATA spare parts
207650110111	ASSY ENGINE COOLING PACKAGE	TATA spare parts
207650110123	WATER FILLER PIPE AWT TO RADIATOR	TATA spare parts
207650110124	VENT TUBE ASSY ENGINE TO AUX WATER TANK	TATA spare parts
207650110125	RADIATOR ASSY	TATA spare parts
207650110126	ENGINE COOLING SYSTEM ASSY	TATA spare parts
207650110127	ENGINE COOLING SYSTEM ASSY	TATA spare parts
207650110302	ENGINE COOLING SYSTEM BS3/4	TATA spare parts
207650115804	RUBBER HOSE (RADIATOR TO ENGINE)	TATA spare parts
207650115805	VENT HOSE	TATA spare parts
207650115806	VENT HOSE	TATA spare parts
207650115809	REDUCER HOSE(90DEG)	TATA spare parts
207650115823	HOSE RADIATOR TO ENGINE	TATA spare parts
207650115824	HOSE ENGINE TO RADIATOR	TATA spare parts
207650115826	HOSE RETARDER OUTLET	TATA spare parts
207650115827	HOSE ENGINE TO RADIATOR	TATA spare parts
207650115828	HOSE ENGINE TO RADIATOR	TATA spare parts
207650115831	HOSE	TATA spare parts
207650115833	HOSE RADIATOR BOTTOM TANK TO ENGINE	TATA spare parts
207650115834	HOSE ASSY	TATA spare parts
207650116903	WATER FILL PIPE-AUX W/TANK TO RAD BOTTOM	TATA spare parts
207650116906	WATER FILL PIPE	TATA spare parts
207650116908	ENGINE VENT TUBE	TATA spare parts
207650116912	VENT TUBE(ENG TO AUX WATER TANK)	TATA spare parts
207650116913	WATER FILL PIPE (RAD. TOP TO ENGINE)	TATA spare parts
207650116915	RADIATOR VENT TUBE	TATA spare parts
207650116917	COOLANT OUTLET PIPE(ENG TO RAD)	TATA spare parts
207650116918	WATER FILL PIPE (RADIATOR END)	TATA spare parts
207650116923	PIPE (ENGINE TO RADIATOR)	TATA spare parts
207650116934	VENT PIPE AUX WATER TANK TO ENGINE	TATA spare parts
207650116935	VENT TUBE AUX WATER TANK TO RADIATOR	TATA spare parts
207650116936	WATER FILLER PIPE AWT TO RADIATOR	TATA spare parts
207650116941	WATER FILLER PIPE AWT TO RADIATOR	TATA spare parts
207650116942	VENT TUBE ASSY AUX WATER TANK TO ENGINE	TATA spare parts
207650116944	WATER FILLER PIPE AWT TO RADIATOR	TATA spare parts
207650116945	WATER FILLER PIPE AWT TO RADIATOR	TATA spare parts
207650116961	WATER FILLER PIPE AWT TO RADIATOR	TATA spare parts
207650116964	VENT TUBE ASSY AUX WATER TANK TO ENGINE	TATA spare parts
207650116965	WATER FILLER PIPE	TATA spare parts
207650116966	PIPE RADIATOR TO WATER PUMP	TATA spare parts
207650116972	WATER FILLER PIPE AWT TO RADIATOR	TATA spare parts
207650116974	VENT TUBE ASSY AUX WATER TANK TO ENGINE	TATA spare parts
207650116990	VENT TUBE ASSY AUX WATER TANK TO ENGINE	TATA spare parts
207650116991	WATER FILLER PIPE AWT TO RADIATOR	TATA spare parts
207650116994	HOSE	TATA spare parts

207650116995	HOSE	TATA spare parts
207650116996	HOSE	TATA spare parts
207650120101	SET-COOLING SYSTEM	TATA spare parts
207650126901	PIPE(ENG TO RADIATOR)	TATA spare parts
207650126910	PIPE RADIATORBOTTOMTOENGINEPUMP	TATA spare parts
207650130104	RADIATOR ASSY WITH INTERCOOLER & SHROUD	TATA spare parts
207650130105	SET-COOLING SYSTEM	TATA spare parts
207650205807	HOSE BS4	TATA spare parts
207650205808	HOSE ENGINE TO RADIATOR	TATA spare parts
207650205809	HOSE-RADIATOR LOWER TANK	TATA spare parts
207650206901	VENT TUBE(ENG.TO A.W.TANK)	TATA spare parts
207650206902	VENT PIPE (RADIATOR TO AUX WATER TANK)	TATA spare parts
207650206903	WATER FILLER PIPE	TATA spare parts
207650206909	WATER FILL PIPE	TATA spare parts
207650206916	WATER FILLER PIPE	TATA spare parts
207650206917	VENT PIPE (RADIATOR TO AUX WATER TANK)	TATA spare parts
207650206918	VENT PIPE (AUX WATER TANK TO ENGINE)	TATA spare parts
207650206926	VENT TUBE(ENG TO AW TANK)	TATA spare parts
207650206927	VENT TUBE (ENGINE TO AUX. WATER TANK)	TATA spare parts
207650206929	PIPE (ENGINE TO RADIATOR) TOP	TATA spare parts
207650206939	HOSE	TATA spare parts
207650206945	RADIATOR WATER FILL PIPE	TATA spare parts
207650206946	VENT TUBE	TATA spare parts
207650206948	FILL PIPE (AWT TO RAD)	TATA spare parts
207650206967	FILLER PIPE	TATA spare parts
207650206968	VENT TUBE ENGINE TO AUX TANK	TATA spare parts
207650400102	ASSY BRACKET RH	TATA spare parts
207650400104	ASSLY STAY ROD(RAD MTG)	TATA spare parts
207650400106	BRACKET ASSY RADIATOR MTG BOTTOM-RH	TATA spare parts
207650400107	BRACKET ASSY RADIATOR MTG BOTTOM-LH	TATA spare parts
207650400110	BRACKET RADIATOR MTG ASSY COMP TOP RH	TATA spare parts
207650400111	BRACKET RADIATOR MTG ASSY COMP TOP LH	TATA spare parts
207650400114	ASSY.BRACKET- RAD MTG.ON L.M.	TATA spare parts
207650400116	ASSY RADIATOR MTG BKT(LH)	TATA spare parts
207650400117	ASSY RADIATOR MTG BKT(RH)	TATA spare parts
207650400118	ASSY RAD MTG BKT-LH(BRTS)	TATA spare parts
207650400119	ASSY RAD MTG BKT-RH(BRTS)	TATA spare parts
207650400124	ASSY RAD MTG BKT-LH	TATA spare parts
207650400125	ASSY RAD MTG BKT-RH	TATA spare parts
207650400135	ASSY RADIATOR MTG BRACKET LH	TATA spare parts
207650400137	BRACKET ASSY RADIATOR MTG BOTTOM RH	TATA spare parts
207650400138	BRACKET ASSY RADIATOR MTG BOTTOM LH	TATA spare parts
207650403308	BRACKET RADIATOR ASSY MTG BOTTOM	TATA spare parts
207650403309	BRACKET PIPE MTG	TATA spare parts
207650403310	BRACKET PIPE MTG	TATA spare parts
207650403312	L-BRACKET	TATA spare parts
207650403313	Z-BRACKET PIPE MTG	TATA spare parts

207650403320	BRACKET BS6	TATA spare parts
207650506309	FAN SHROUD	TATA spare parts
207650506310	FAN SHROUD	TATA spare parts
207650506312	FAN SHROUD	TATA spare parts
207650506314	FAN SHROUD	TATA spare parts
207650506320	FANSHROUD	TATA spare parts
207650506321	FAN SHROUD	TATA spare parts
207650506322	FAN SHROUD(LPO1512 TC E-III)	TATA spare parts
207650506323	FAN SHROUD LPO1623 TC/62 BS-II	TATA spare parts
207650506324	FAN SHROUD	TATA spare parts
207650506325	FAN SHROUD	TATA spare parts
207650506328	FAN SHROUD	TATA spare parts
207650506329	FAN SHROUD	TATA spare parts
207650506330	FAN SHROUD	TATA spare parts
207650506332	FAN SHROUD	TATA spare parts
207650506334	FANSHROUDLPO1623TC/62BS-II	TATA spare parts
207650506335	FAN SHROUD	TATA spare parts
207650506336	FAN SHROUD	TATA spare parts
207650506337	FAN SHROUD	TATA spare parts
207650506338	FAN SHROUD (JET RING FAN)	TATA spare parts
207650506343	FAN SHROUD (24INC JET RING FAN)	TATA spare parts
207650506348	FAN SHROUD	TATA spare parts
207650506355	FAN SHROUD	TATA spare parts
207650506358	FAN SHROUD	TATA spare parts
207650507705	RUBBER FLAP TOP	TATA spare parts
207650507706	RUBBER FLAP SIDE	TATA spare parts
207650516301	FAN SHROUD	TATA spare parts
207650516303	FAN SHROUD	TATA spare parts
207650603801	INTERCOOLER PIPE (OUTLET)	TATA spare parts
207650603802	INTERCOOLER PIPE (INLET)	TATA spare parts
207650606901	PIPE INTERCOOLER TO ENGINE	TATA spare parts
207650606902	PIPE TURBOCHARGER TO INTERCOOLER	TATA spare parts
207650606903	PIPE INTERCOOLER TO ENGINE	TATA spare parts
207650606904	PIPE TURBOCHARGER TO INTERCOOLER	TATA spare parts
207650980102	SET-AUX WATER TANK WITH BRACKET	TATA spare parts
207650990101	KIT-RADIATOR SHROUD FAN INTERCOOLER	TATA spare parts
207650990102	KIT-ENGINE COOLING SYSTEM	TATA spare parts
207650990103	KIT-ENGINE COOLING SYSTEM BS4	TATA spare parts
207729150102	CONNECTING LINE ASSY	TATA spare parts
207729150103	ASSY TUBE DIA 6X2380 MM	TATA spare parts
207729150107	ASSY TUBE 6 OD X 2110 LG	TATA spare parts
207729150108	ASSY PIPE LPK2516RHD	TATA spare parts
207729150109	ASSY. CONNECTING LINE (FOR HYD.CLUTCH)	TATA spare parts
207729150111	ASSY. CONNECTING LINE (HYD. CLUTCH)	TATA spare parts
207729150112	ASSY TUBE 6 O.D. X 2310 LG	TATA spare parts
207729150113	ASSY. CONNECTING LINE (FOR HYD. CLUTCH)	TATA spare parts
207729150117	ASSY. TUBE (6 O.D. X 2500 LG.)	TATA spare parts

207729153301	BRACKET (Z-SHAPE) BS6	TATA spare parts
207742700102	PIPE ASSY 6D X 1715 LG	TATA spare parts
207742700103	PIPE ASSY 6D X 1230 LG	TATA spare parts
207742700104	PIPE ASSY 6D X 1160 LG	TATA spare parts
207742700105	PIPE 6 X 1725	TATA spare parts
207742700106	PIPE 6 X 2890	TATA spare parts
207742700107	PIPE ASSY 12D X 1625 LG	TATA spare parts
207742700108	PIPE ASSY 12D X 1860 LG	TATA spare parts
207742700111	PIPE ASSY 6D X 1055 LG	TATA spare parts
207742700112	PIPE ASSY 6D X 1050 LG	TATA spare parts
207742700113	ASSY.HOSE 3/8	TATA spare parts
207742700114	ASSY TUBE-12 OD X 1585 LG	TATA spare parts
207742700116	ASSY TUBE	TATA spare parts
207742700120	ASSY TUBE	TATA spare parts
207742700121	ASSY TUBE	TATA spare parts
207742700130	ASSY TUBE 6 DIA X 1260LG LPS 3516	TATA spare parts
207742700131	ASSY.TUBE 6 DIA.X1220LG LPS 3516	TATA spare parts
207742700134	ASSY.PIPE 12DIA.X1235LG.	TATA spare parts
207742700135	ASSY.TUBE 6 DIA.X 610LG	TATA spare parts
207742700136	ASSY TUBE 12 DIA X 1920LG	TATA spare parts
207742700137	ASSY TUBE 15 DIA X 440 LG	TATA spare parts
207742700138	ASSY TUBE 15 DIA X 460 LG	TATA spare parts
207742700140	ASSY TUBE	TATA spare parts
207742700141	ASSY TUBE-6 OD X 1980 LG	TATA spare parts
207742700142	ASSY TUBE-6 OD X 1390 LG	TATA spare parts
207742700143	ASSY TUBE-6 OD X 1095 LG	TATA spare parts
207742700144	ASSY TUBE	TATA spare parts
207742700145	ASSY TUBE-6 OD X 1260 LG	TATA spare parts
207742700146	ASSY TUBE-6 OD X 1345 LG	TATA spare parts
207742700148	ASSY TUBE	TATA spare parts
207742900104	PIPE 15 X 1.5 X 1030	TATA spare parts
207742900105	PIPE ASSY 15D X 1.5 X 545	TATA spare parts
207742900106	PIPE ASSY 15D X 315 LG	TATA spare parts
207742900107	PIPE ASSY 12D X 270 LG	TATA spare parts
207742900108	PIPE ASSY 12D X 1 X 1100	TATA spare parts
207742900109	PIPE ASSY 12D X 1390 LG	TATA spare parts
207742900111	PIPE ASSY 6D X 1485 LG	TATA spare parts
207742900112	PIPE ASSY 6D X 3040 LG	TATA spare parts
207742900115	PIPE ASSY 12D X 1 X 2140	TATA spare parts
207742900116	PIPE ASSY 12D X 1515 LG	TATA spare parts
207742900119	PIPE ASSY 12D X 1520 LG	TATA spare parts
207742900120	PIPE ASSY 12D X 1620 LG	TATA spare parts
207742900121	PIPE ASSY 6D X 1540 LG	TATA spare parts
207742900122	PIPE ASSY 6D X 1675 LG	TATA spare parts
207742900123	PIPE ASSY 6D X 1610 LG	TATA spare parts
207742900125	PIPE ASSY 12D X 320 LG	TATA spare parts
207742900126	PIPE ASSY 12D X 2160 LG	TATA spare parts

207742900131	PIPE ASSY 12D X 1650 LG	TATA spare parts
207742900132	PIPE ASSY 12D X 2280 LG	TATA spare parts
207742900133	PIPE ASSY 12D X 1850 LG	TATA spare parts
207742900134	PIPE ASSY 12D X 2170 LG	TATA spare parts
207742900135	PIPE ASSY 12D X 2165 LG	TATA spare parts
207742900137	PIPE 12 X 2380	TATA spare parts
207742900142	ASSY.PIPE (15DIA X 580 LG	TATA spare parts
207742900143	ASSY PIPE 12 DIA X 455	TATA spare parts
207742900145	ASSY.PIPE (12 DIA X 1595	TATA spare parts
207742900147	ASSY PIPE	TATA spare parts
207742900149	ASSY TUBE 12 O.D. X 1260 LONG	TATA spare parts
207742900150	ASSY TUBE 12 O.D. X 1670 LONG	TATA spare parts
207742900159	PIPE 12 X 1595	TATA spare parts
207742900160	PIPE 12 X 2185	TATA spare parts
207742900161	ASSY.PIPE (15DIA X 585 LG	TATA spare parts
207742900164	ASSY PIPE 12 DIA X 1590	TATA spare parts
207742900165	ASSY.PIPE(12 DIA X 720 LG	TATA spare parts
207742900166	ASSY PIPE 12 DIA X 1565 L	TATA spare parts
207742900167	ASSY PIPE 12 DIA X 1980	TATA spare parts
207742900168	PIPE 12 X 1000	TATA spare parts
207742900170	ASSY PIPE 12 DIA X 1255	TATA spare parts
207742900171	ASSY PIPE 12 DIA X 1890	TATA spare parts
207742900172	ASSY PIPE 12 DIA X 1030	TATA spare parts
207742900173	ASSY PIPE 12 DIA X 1845	TATA spare parts
207742900178	ASSY TUBE-15 OD X 4310 LG	TATA spare parts
207742900179	ASSY TUBE	TATA spare parts
207742900180	ASSY TUBE	TATA spare parts
207742900181	ASSY TUBE	TATA spare parts
207742900182	ASSY TUBE	TATA spare parts
207742900183	ASSY TUBE	TATA spare parts
207742900185	ASSY TUBE	TATA spare parts
207742900186	ASSY TUBE	TATA spare parts
207742900188	ASSY TUBE	TATA spare parts
207742900189	ASSY TUBE	TATA spare parts
207742900195	ASSY TUBE	TATA spare parts
207742900198	ASSY TUBE	TATA spare parts
207742903304	BRACKET (HAT SHAPE)	TATA spare parts
207742903305	BRACKET (L-SHAPE) BS6	TATA spare parts
207742903306	BRACKET	TATA spare parts
207742903311	L-BRACKET	TATA spare parts
207742903318	BRACKET BS6-PH2	TATA spare parts
207742903324	BRACKET(Z SHAPE)	TATA spare parts
207742903338	BRACKET	TATA spare parts
207742903339	BRACKET	TATA spare parts
207742906802	T CONNECTOR	TATA spare parts
207742906803	T-CONNECTOR-FOR STOP LIGHT SWITCH	TATA spare parts
207742906806	T-CONNECTOR	TATA spare parts

207742906807	DOUBLE SOCKET (FOR DIFF. LOCK)	TATA spare parts
207742910102	ASSY PIPE 15 DIA X 1460 LG	TATA spare parts
207742910103	ASSY PIPE 15 DIA X 2255 LG	TATA spare parts
207742910104	ASSY PIPE 15 DIA X 1440 LG	TATA spare parts
207742910105	ASSY PIPE 15 DIA X 1360 LG	TATA spare parts
207742910106	ASSY PIPE 6 DIA X 595 LG	TATA spare parts
207742910107	ASSY PIPE 12 DIA X 1425 LG	TATA spare parts
207742910111	ASSY PIPE 12 DIA X 1570 LG	TATA spare parts
207742910112	ASSY PIPE 12 DIA X 980 LG	TATA spare parts
207742910114	ASSY PIPE 12 DIA X 1095 LG	TATA spare parts
207742910119	ASSY TUBE 6 DIA X 2140 LG LPS 3516	TATA spare parts
207742910120	ASSY TUBE 6 DIA X 600 LG	TATA spare parts
207742910121	ASSY TUBE 12 DIA X 420 LG	TATA spare parts
207742910122	ASSY TUBE 12 DIA X 500 LG	TATA spare parts
207742910123	ASSY TUBE 15 DIA X 530 LG	TATA spare parts
207742910129	3/8 INCH HOSE ASSY. WITH END FITTINGS.	TATA spare parts
207742910131	ASSY TUBE-15 OD X 1685 LG	TATA spare parts
207742910132	ASSY TUBE-15 OD X 2040 LG	TATA spare parts
207742910135	ASSY TUBE-6 OD X 2060 LG	TATA spare parts
207742910136	ASSY TUBE	TATA spare parts
207742910139	ASSY TUBE-6 OD X 2140 LG	TATA spare parts
207742910140	ASSY TUBE-6 O.D. X 2200 LG	TATA spare parts
207742910143	ASSY TUBE	TATA spare parts
207742910144	ASSY TUBE	TATA spare parts
207742910145	AIR TUBE W/CRIMPED R/HOSE LPK2516TC 6X4	TATA spare parts
207742910147	ASSY TUBE (15 O.D. X 1850 LG.)-R/HOSE T	TATA spare parts
207742910148	ASSY TUBE (15 O.D. X 2450 LG.)-TO AIR D	TATA spare parts
207742910149	ASSY NYLON PIPE SET FOR LPK2516TC 6X4	TATA spare parts
207742910153	ASSY NYLON PIPE SET COMPLETE LPT 2515TC	TATA spare parts
207742910170	ASSY NYLON TUBE- 12 O. D. X 500 LG.	TATA spare parts
207742910178	ASSY NYLON TUBE AIR DRYER->SPV LPK2516TC	TATA spare parts
207742920145	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
207742920146	SET ASSY NYLON PIPES COMPLETE	TATA spare parts
207742920156	ASSY NYLON TUBE	TATA spare parts
207742920179	SET ASSY NYLON PIPE COMPLETE	TATA spare parts
207742920185	SET ASSY NYLON PIPE COMPL	TATA spare parts
207742920188	ASSY TUBE(15 O.D. X 4330 LG)	TATA spare parts
207742920189	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
207742920190	ASSY TUBE 15 O.D. X 1240 LG	TATA spare parts
207742920194	SET ASSY NYLON PIPE COMP.	TATA spare parts
207742940126	SET ASSY NYLON PIPE COMPL.LPS4018 TC E-2	TATA spare parts
207743200101	PIPE ASSY 12D X 2380 LG	TATA spare parts
207743200104	TUBE ASSY 6D X 1745	TATA spare parts
207743200105	TUBE ASSY 6D X 1090	TATA spare parts
207743200117	ASSY PIPE 6 DIA X 2955 LG	TATA spare parts
207743200118	ASSY TUBE 6 DIA X 540 LG	TATA spare parts
207743200124	ASSY TUBE 6 DIA X 1010 LG	TATA spare parts

207743900101	SET ASSY NYLON PIPE LPS4018	TATA spare parts
207743900134	ASSY NYLON PIPE LPT2515/56	TATA spare parts
207743900172	ASSY TUBE(15 O.D. X 1300 LG)	TATA spare parts
207743900173	ASSY TUBE (15 O.D. X 2850 LG)	TATA spare parts
207743900174	ASSY TUBE(15 O.D. X 3030 LG)	TATA spare parts
207743900175	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
207743900175AE	ASSY TUBE W/CRIMPED R/HOSE-1415	TATA spare parts
207743900176	SET ASSY NYLON PIPE COMPL LPT2515/56 TC	TATA spare parts
207743910124	ASSY. NYLON PIPE SET COMPLETE	TATA spare parts
207743910127	ASSY.COMP.OUTLET 1ST PIPE(18 O.D.-1400L)	TATA spare parts
207743910128	ASSY.COMP.OUTLET 2ND PIPE(18 O.D.-1660L)	TATA spare parts
207743910129	ASSY.COMP.OUTLET 3RD PIPE(18 O.D.-1100L)	TATA spare parts
207743910130	ASSY.TUBE WITH CRIMPED RUBBER HOSE COMP.	TATA spare parts
207743910133	ASSY.COMP.OUTLET 2ND PIPE-18 OD	TATA spare parts
207743910134	ASSY.COMP.OUTLET 3RD PIPE-15 OD	TATA spare parts
207743910135	ASSY.COMP.OUTLET 1ST PIPE 18 OD	TATA spare parts
207743910136	ASSY.COMP.OUTLET 2ND PIPE-18 OD	TATA spare parts
207743910137	ASSY.COMP.OUTLET 3RD PIPE-15 OD	TATA spare parts
207746303302	BRACKET	TATA spare parts
207746800101	PIPE 18 X 1.5 X 335	TATA spare parts
207746800104	PIPE ASSY 15 X1.5 X 1990	TATA spare parts
207746800105	PIPE 15 X 1.5 X 600	TATA spare parts
207746800106	PIPE 18 X 1.5 X 330	TATA spare parts
207746800107	PIPE 15 X 130	TATA spare parts
207746800108	PIPE 15 X 2160	TATA spare parts
207746800109	PIPE 15 X 2580	TATA spare parts
207746800110	PIPE 15 X 2560	TATA spare parts
207746800111	PIPE 15 X 2150	TATA spare parts
207746800113	PIPE ASSY 15D X 1990 LG	TATA spare parts
207746800114	TUBE ASSY 15 O.D X 1810 LONG LPK 2516TC	TATA spare parts
207746800119	ASSY TUBE W/CRIMPED R HOSE	TATA spare parts
207746800127	TUBE ASSY WITH CRIMPED R/HOSE	TATA spare parts
207746800128	ASSY TUBE WITH CRIMPED RUBBER HOSE COMP	TATA spare parts
207746800129	TUBE ASSY WITH CRIMPED R/HOSE	TATA spare parts
207746800130	ASSY. TUBE WITH CRIMPED RUBBER HOSE COM.	TATA spare parts
207746800131	ASSY HOSE HYD TANK TO PUMP	TATA spare parts
207746800132	ASSY TUBE WITH CRIMPED R/HOSE COMPLT.	TATA spare parts
207746800133	ASSY TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
207746800134	ASSY TUBE 15ODX1.5THKX475 L	TATA spare parts
207746800135	ASSY TUBE STRG PUMP OUTLET TO STRG GB IN	TATA spare parts
207746800136	ASSY TUBE STRG GB OUTLET TO HYD TANK INL	TATA spare parts
207746800137	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
207746800138	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
207746800147	HOSE ASSY TANK TO PUMP	TATA spare parts
207746800148	HOSE ASSY-G/BOX TO TANK	TATA spare parts
207746800153	RETURN LINE HOSE ASSY	TATA spare parts
207746800154	RETURN LINE HOSE ASSY	TATA spare parts

207746800155	PR.LINE HOSE ASSY	TATA spare parts
207746800156	PR LINE HOSE ASSY	TATA spare parts
207746800157	SUCTION LINE HOSE ASSY	TATA spare parts
207746800158	ASSY MALE ADAPTOR	TATA spare parts
207746800159	ASSY MALE ADAPTOR	TATA spare parts
207746800160	ASSY MALE ADAPTOR	TATA spare parts
207746800161	ASSY CONE TYPE NIPPLE	TATA spare parts
207746800162	ASSY CONE TYPE BEND NIPPLE	TATA spare parts
207746800163	ASSY CONE TYPE BEND NIPPLE	TATA spare parts
207746800170	SUTION LINE HOSE ASSY COMMON	TATA spare parts
207746800171	PR.LINE HOSE ASSY	TATA spare parts
207746800172	RETURN LINE HOSE ASSY	TATA spare parts
207746800173	RETURN LINE HOSE ASSY COMMON	TATA spare parts
207746800174	RETURNLINE HOSE ASSY	TATA spare parts
207746800181	SUCTION LINE HOSE ASSY	TATA spare parts
207746800182	HIGH PRESSURE LINE ASSY	TATA spare parts
207746800183	RETURN LINE ASSY	TATA spare parts
207746800184	RETURN LINE ASSY	TATA spare parts
207746800185	PRESSURE LINE ASSY	TATA spare parts
207747600101	PIPE 10D X 2340	TATA spare parts
207747600102	PIPE 6 X 1775	TATA spare parts
207747600103	PIPE 15D X 390	TATA spare parts
207747600104	PIPE 15D X 1745 LG	TATA spare parts
207747600105	PIPE 10D X 1860 LG	TATA spare parts
207747600106	PIPE 10D X 740 LG	TATA spare parts
207747600111	TUBE ASSY 10D X 1840 LG	TATA spare parts
207747600112	PIPE 10D X 740 LG	TATA spare parts
207747600113	TUBE ASSY 15D X 2400 LG	TATA spare parts
207747600114	ASSY TUBE SUCTION 530 LO	TATA spare parts
207747600126	ASSY PIPE 15DIAX1840 LG	TATA spare parts
207747600128	ASSY. TUBE	TATA spare parts
207747600130	ASSY.TUBE W/RUBBER HOSE COMPLETE	TATA spare parts
207747600134	ASSY TUBE-10 OD X 2100 LG	TATA spare parts
207747600135	ASSY TUBE 10 OD X 1540 LG	TATA spare parts
207747600167	ASSY.TUBE WITH CRIMPED R/HOSE.	TATA spare parts
207747600168	ASSY.TUBE WITH CRIMPED R/HOSE	TATA spare parts
207747600169	ASSY TUBE WITH CRIMPED R/HOSE COMPLETE-S	TATA spare parts
207747600170	ASSY TUBE WITH CRIMPED R/HOSE COMPLETE-R	TATA spare parts
207747600171	ASSY TUBE W/ CRIMPED R/HOSE SUCTION	TATA spare parts
207747600172	ASSY TUBE W/ CRIMPED R/HOSE RETURN LINE	TATA spare parts
207747600179	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
207747600180	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
207747600181	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
207747600182	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
207747600190	ASSY TUBE WITH CRIMPED R/H	TATA spare parts
207747600191	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
207747600192	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts



207747600193	ASSY TUBE (15 O.D.X210 LG)	TATA spare parts
207747600194	ASSY TUBE(15 O.D. X 370 LG)	TATA spare parts
207747600195	ASSY TUBE(15 O.D X 2410 LG)	TATA spare parts
207747600197	ASSY.TUBE WITH CRIMPED R/HOSE(RETURN LIN	TATA spare parts
207747606801	COUPLING BODY	TATA spare parts
207824200101	ENG MTG BKT REAR	TATA spare parts
207829100109	CLUTCH PEDAL LEVER COMPLT	TATA spare parts
207829100111	CLUTCH MASTER CYLINDER WITH BOTTLE	TATA spare parts
207829100120	CLUTCH MASTER CYL.	TATA spare parts
207829100122	CLUTCH MASTER CYLINDER	TATA spare parts
207829106002	FORK (CMC)	TATA spare parts
207829200115	ASSY BRAKE PEDAL LEVER COMPL. SE 1613 TC	TATA spare parts
207829206701	PIN (CLUTCH LEVER)	TATA spare parts
207829300109	ASSY TUBE	TATA spare parts
207829300110	ASSY TUBE	TATA spare parts
207830100112	ASSY PULL ROD ACCL.5	TATA spare parts
207830100115	ASSY ACCEL PEDAL E1613	TATA spare parts
207830100128	LEVER ACCELERATOR	TATA spare parts
207830100134	ASSY. LEVER (INLINE FIP) LHD	TATA spare parts
207830100135	ASSY. HOUSING ACCL. SHAFT	TATA spare parts
207830100140	ASSY. BRACKET ACCEL	TATA spare parts
207830100144	ASSY BRACKET (ACEL M	TATA spare parts
207830100145	ASSY PULL ROD 440MM	TATA spare parts
207830100146	ASSY. PULL ROD	TATA spare parts
207830100147	ACCELERATOR SHAFT	TATA spare parts
207830100148	HOUSING ACCL SHAFT	TATA spare parts
207830100149	ASSY. CONTROL SHAFT SE/SK 1613 TC	TATA spare parts
207830100150	ASSY ACCELERATOR LEVER	TATA spare parts
207830103202	BOLT (FOR ACCL.)-MOUNTING OF LEVER WITH	TATA spare parts
207830107905	CONTROL SHAFT	TATA spare parts
207830109901	THRUST ROD	TATA spare parts
207830200104	ASSY. PULL CABLE ENG STOP 2425MM BS1/2/3	TATA spare parts
207830200105	ASSY. PULL CABLE ENGINE STOP	TATA spare parts
207830200107	ASSY PULL CABLE ENGINE STOP	TATA spare parts
207830203301	BRACKET-ENGINE STOP CABLE	TATA spare parts
207830205601	KNOB(ENGINE SSSSTOP CABLE	TATA spare parts
207831000102	ASSY FRAME 1615TC SE42	TATA spare parts
207831000109	ASSY. FRAME 1615 TC SK 36	TATA spare parts
207831000110	ASSY FRAME SK 1615/36 TC PS-4PENG-3PRAD	TATA spare parts
207831000111	ASSY FRAME COMPLETE SE1615TC	TATA spare parts
207831200101	ASSY SUPPORT FRONT LH SE 1615TC	TATA spare parts
207831200102	ASSY SUPPORT ENG.CROSS MEM.LH SE1615TC	TATA spare parts
207831200103	ASSY SUPPORT FRONT RH SE 1615TC	TATA spare parts
207831200104	ASSY. SUPPORT REAR RH	TATA spare parts
207831200106	ASSY ENGINE CROSS MEMBER FRONT	TATA spare parts
207831200107	GUSSET RH SE/SK 1615 TC	TATA spare parts
207831200108	GUSSET LH SE/SK 1615 TC	TATA spare parts

207831200109	SUPPORT FRONT LH SE/SK 1615 TC	TATA spare parts
207831200110	SUPPORT FRONT RH SE/SK 1615 TC	TATA spare parts
207831200111	ASSY SUPPORT REAR-LH (ENG. C.M. FRONT)	TATA spare parts
207831200112	ASSY SUPPORT REAR RH (ENG. C.M. FRONT)	TATA spare parts
207831200113	ASSY SUPPORT FRONT- LH-ENG C.M. FRONT	TATA spare parts
207831200114	ASSY SUPPORT FRONT- RH-ENG C.M. FRONT	TATA spare parts
207831203201	SPECIAL BOLT (REAR SPG.BRACKET TO L.M.)	TATA spare parts
207831207121	REINFORCEMENT REAR (TOP) RH	TATA spare parts
207831207122	REINFORCEMENT REAR (TOP) LH	TATA spare parts
207831207139	REINFORCEMENT L.H.	TATA spare parts
207831207140	REINFORCEMENT R.H.	TATA spare parts
207831207141	REINFORCEMENT BOTTOM- LH	TATA spare parts
207831207142	REINFORCEMENT- RH	TATA spare parts
207831207143	REINFORCEMENT TOP- LH	TATA spare parts
207831207144	REINFORCEMENT TOP- RH	TATA spare parts
207831207145	REINFORCEMENT (HELPER SPRING BKT)	TATA spare parts
207831207148	REINFORCEMENT TOP- RH	TATA spare parts
207831207149	REINFORCEMENT TOP- LH	TATA spare parts
207831207154	REINFORCEMENT REAR (BOTTOM- LH)	TATA spare parts
207831207155	REINFORCEMENT REAR (BOTTOM - RH)	TATA spare parts
207831208203	END CROSS MEMBER	TATA spare parts
207831307101	GUSSET RH	TATA spare parts
207831307102	GUSSET LH.	TATA spare parts
207831307105	GUSSET PLATE RH SE/SK 1613 TC	TATA spare parts
207831307106	GUSSET PLATE LH SE/SK 1613 TC	TATA spare parts
207833000101	ASSY. FRONT AXLE WITH 1516 BRAKES	TATA spare parts
207841100101	ASSY.PROP.SHAFT WITH C/BRG	TATA spare parts
207841100116	ASSY P/SHAFT W/CENTRE BRG	TATA spare parts
207841100117	ASSY P/SHAFT FRT-280 LG	TATA spare parts
207841100119	ASSY P/SHAFT COMP. REAR	TATA spare parts
207841303302	BRACKET CENTRE BEARING MOUNTING SK1613TC	TATA spare parts
207842700101	ASSY TUBE	TATA spare parts
207842700102	ASSY TUBE	TATA spare parts
207842700121	ASSY TUBE (60.D*685L	TATA spare parts
207842700122	ASSY TUBE 60D*720LG	TATA spare parts
207842700123	ASSY. BRACKET (FOR FLICK VALVE)	TATA spare parts
207842700124	ASSY TUBE	TATA spare parts
207842700125	ASSY TUBE	TATA spare parts
207842700126	ASSY TUBE	TATA spare parts
207842700127	ASSY TUBE	TATA spare parts
207842900106	ASSY.PIPE 12DIA.X 1830LG.	TATA spare parts
207842900107	ASSY TUBE(120D*1750L	TATA spare parts
207842900110	ASSY TUBE(12 *1775LG	TATA spare parts
207842900112	ASSY TUBE(120.D*120L	TATA spare parts
207842900113	ASSY TUBE	TATA spare parts
207842900154	ASSY PIPE 15X1485 LONG LPT 1613TC	TATA spare parts
207842900155	ASSY TUBE	TATA spare parts

207842900156	ASSY TUBE	TATA spare parts
207842900157	PIPE ASSY 15DIA X 650 LONG	TATA spare parts
207842900159	ASSY TUBE	TATA spare parts
207842900160	ASSY TUBE	TATA spare parts
207842900162	ASSY TUBE	TATA spare parts
207842900163	ASSY TUBE	TATA spare parts
207842900164	ASSY TUBE	TATA spare parts
207842900165	ASSY TUBE	TATA spare parts
207842900166	ASSY PIPE 12*1*455 L	TATA spare parts
207842900168	ASSY TUBE	TATA spare parts
207842900171	ASSY NYLON PIPE SET SE1613/42	TATA spare parts
207842903310	BRACKET (Q.R.V MTG.ON RA 109 AXLE.)	TATA spare parts
207842908204	HOLDING PLATE BS6	TATA spare parts
207843100127	ASSY TUBE	TATA spare parts
207843100128	ASSY TUBE	TATA spare parts
207843100129	ASSY PIPE 6X1620	TATA spare parts
207843100130	ASSY.TUBE	TATA spare parts
207843100131	ASSY PIPE-6X1040	TATA spare parts
207843100132	ASSY PIPE-6X2100	TATA spare parts
207843100133	ASSY PIPE-6X145	TATA spare parts
207843700103	LEVER TYPE CONTROL VALVE PTO	TATA spare parts
207843700106	LEVER TYPE CONTROL VALVE	TATA spare parts
207843700110	DUAL BRAKE VALVE	TATA spare parts
207843900101	ASSY.NYLON PIPE SET COMPLETE.	TATA spare parts
207844800113	ASSY TUBE	TATA spare parts
207844800114	ASSY TUBE	TATA spare parts
207846000105	ASSY DRAG LINK	TATA spare parts
207846000107	ASSY DRAG LINK	TATA spare parts
207846600101	KIT POWER STEERING	TATA spare parts
207846600107	STG.TANK ASSY.	TATA spare parts
207846800105	ASSY PIPE 15 DIA X 1700 SE/SK 1615 TC	TATA spare parts
207846800106	ASSY PIPE 15 DIA X 2290 SE/SK 1615 TC	TATA spare parts
207846900101	DRAG LINK END ASSY	TATA spare parts
207847600112	ASSY TUBE 1670 LONG	TATA spare parts
207847600113	ASSY.PIPE 10DIA.X 1850LG.	TATA spare parts
207847600123	ASSY TUBE 875 LONG	TATA spare parts
207847600126	ASSY TUBE SUCTION 1715LON	TATA spare parts
207847600127	ASSY TUBE10X1500LG	TATA spare parts
207847604201	CLAMP	TATA spare parts
207849100106	SILENCER W/TAIL PIPE	TATA spare parts
207849100107	ASSY. SILENCER (GENSET)	TATA spare parts
207849100108	ASSY SILENCER W/PIPE	TATA spare parts
207849100109	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
207849100111	ASSY.EXHAUST PIPE (76.2 OD X 1.6 THK.)	TATA spare parts
207849100140	ASSY.SILENCER WITH PIPE.	TATA spare parts
207849200114	ASSY PIPE INNER	TATA spare parts
207849200115	ASSY. PIPE (INTERMEDIATE.) SE 1613 TC	TATA spare parts

207849200118	ASSY EXHAUST PIPE FRONT	TATA spare parts
207849200136	ASSY.EXHAUST PIPE	TATA spare parts
207849200137	ASSY.EXHAUST PIPE.	TATA spare parts
207849200147	ASSY EXHAUST PIPE INTRMEDIATE	TATA spare parts
207849203303	BRACKET SE 1615TC	TATA spare parts
207849203304	BRACKET	TATA spare parts
207849203305	BRACKET	TATA spare parts
207849203307	BRACKET	TATA spare parts
207849208201	EXHAUST PIPE CLAMP	TATA spare parts
207854200101	ASSYKIT FOR WATER-IN-FUELINDUNIT 12V	TATA spare parts
207854200102	ASSYKIT FOR WATER-IN-FUELINDUNIT 12V	TATA spare parts
207854200103	ASSYKIT FOR WATER-IN-FUELINDUNIT 12V	TATA spare parts
207854200104	ASSY.NYLON TUBE FOR PR.GAUGE	TATA spare parts
207854200109	ASSY COVER (6 RELAYS & FLASHER)	TATA spare parts
207854209901	DIGITAL HOURMETER	TATA spare parts
207854209902	ELECTRICAL TEMP GAUGE	TATA spare parts
207854209903	HIGH TEMP BUZZER UNIT	TATA spare parts
207854209905	ELECTRICAL TEMP GAUGE	TATA spare parts
207854209906	HIGH TEMP WARNING BUZZER	TATA spare parts
207854209909	HORN 12V	TATA spare parts
207854209912	ASSYKIT FOR WATER-IN-FUELINDUNIT 12V	TATA spare parts
207854209915	SPEEDOCABLE-2450MM	TATA spare parts
207854209917	ELECT.HIGH TEMP GAUGE-12V	TATA spare parts
207854209923	HORN 12V W/O RIS CAP.-LT-112 DIA	TATA spare parts
207854209925	DIGITAL HOUR METER	TATA spare parts
207854209930	DIGITAL HOUR METER	TATA spare parts
207854209931	SPEEDOCABLE-2450MM (DIA-3.8)	TATA spare parts
207854209932	SPEEDOCABLE-2450MM (DIA-3.8)	TATA spare parts
207854400106	ASSY.CAB LAMP(WITH BULB)	TATA spare parts
207854400107	ASSY.CAB LAMP (WITH BULB-24V)	TATA spare parts
207854500102	COMBI SWITCH	TATA spare parts
207854500103	ASSY COMBI SWITCH	TATA spare parts
207854500105	HAZARD WARNING SW 12V-PUSH PULL	TATA spare parts
207854500403	ASSYKIT FOR WATER-IN-FUELINDUNIT 12V	TATA spare parts
207854500406	RPM METER 24V	TATA spare parts
207854509901	HAZARD WARNING SWITCH	TATA spare parts
207854509903	STARTER RALAY	TATA spare parts
207854509904	LOW AIR PRESSURE SWITCH	TATA spare parts
207854600102	INSULATOR - SINGLE POLE	TATA spare parts
207854820101	MAIN CABLE SET	TATA spare parts
207854820102	ASSY CABLE SET	TATA spare parts
207854820108	CABLE SET FRT TO TAIL	TATA spare parts
207854820109	MAIN CABLE SET	TATA spare parts
207854820115	ASSY MAIN CABLE SET	TATA spare parts
207854820120	ASSY.MAINCABLE SET-RHD.SE/SK1613TC OFFER	TATA spare parts
207854820121	ASSY.CABLE SET -FRT TO TAIL-W.B 42	TATA spare parts
207854820124	ASSY.CABLE SET FRT.TO TAIL .SK1613/36	TATA spare parts

207854820127	W/H CAB LAMP	TATA spare parts
207924108201	REINFORCEMENT	TATA spare parts
20800000002	BUSH (AL PIPE) (OD-27)	TATA spare parts
208024200101	ASSY.BRACKET-LH (ENG.MTG.REAR BOTTOM)	TATA spare parts
208031200101	ASSY.ENGINE CROSS MEMBER-(REAR)	TATA spare parts
208034100101	ASSY. FIFTH WH.COUPLING 2 IN	TATA spare parts
208034100106	FIFTH WHEEL COUPLING ASSY	TATA spare parts
208034108201	JAW	TATA spare parts
208034108703	JAW SPRING	TATA spare parts
20803432000R40	60R_RESTRUCTURE_FOR_CVBU_IN_APL_VIEW	TATA spare parts
20803432000R40SJ	60R_RESTRUCTURE_CVBU_IN_APL_VIEW SPARE	TATA spare parts
208034990106	BODY ASSY	TATA spare parts
208034993402	GRIP BUSH	TATA spare parts
20803732000R40	60R_RESTRUCTURE_FOR_CVBU_IN_APL_VI	TATA spare parts
208041120102	ASSY. PROPELLER SHAFT	TATA spare parts
208041120103	ASSY. PROPELLER SHAFT	TATA spare parts
208041120104	CROSS ASSY	TATA spare parts
208041120105	LONG FORK SUB ASSY.	TATA spare parts
208041120106	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
208041125104	FLANGE YOKE	TATA spare parts
208043900147	SET ASSY.NYLON PIPE COMPLETE	TATA spare parts
208043900151	SET ASSY. NYLON PIPE COMPLETE	TATA spare parts
208043900158	SET ASSY.NYLON PIPE WITH PLASTIC CONN.	TATA spare parts
208043900162	ASSY.TUBE(15ODX3020LG)	TATA spare parts
208043900163	ASSY.TUBE(15ODX1300LG)	TATA spare parts
208043900164	ASSY.TUBE(180DX1883LG) 2ND PIPE	TATA spare parts
208043900165	ASSY.TUBE(15ODX1291LG) 3RD PIPE	TATA spare parts
208046150101	KIT ASSY PIPES LPS 3516 TC	TATA spare parts
208046150103	KIT ASSY PIPELPS 3516 E-II	TATA spare parts
208046150104	KIT ASSY PIPE LPS3516/4018(J)LOWERED	TATA spare parts
208046800104	SUCTION LINE HOSE ASSY	TATA spare parts
208046800105	SUCTION LINE HOSE ASSY	TATA spare parts
208046800106	RETURN HOSE ASSY	TATA spare parts
208046800107	PRESSURE LINE HOSE ASSY	TATA spare parts
208046800108	PRESSURE LINE HOSE ASSY.	TATA spare parts
208046800109	PRESSURE LINE HOSE ASSY. RHD	TATA spare parts
208046800110	RETURN LINE HOSE ASSY -FROM STRG GEAR BO	TATA spare parts
208046800111	RETURN LINE HOSE ASSY RHD	TATA spare parts
208046800112	PRESSURE LINE HOSE ASSY-RHD	TATA spare parts
208046800113	RETURN LINE HOSE ASSY-RANE/CHINA	TATA spare parts
208046800114	PRESSURE LINE HOSE ASSY	TATA spare parts
208046800115	RETURN LINE HOSE ASSY	TATA spare parts
208049100101	ASSY SILENCER WITH SHORT TAIL PIPE	TATA spare parts
208049208201	BRACKET	TATA spare parts
208049208202	BRACKET	TATA spare parts
208049208203	BRACKET	TATA spare parts
208049208204	CLAMP (SILENCER MTG )	TATA spare parts

208054100102	ASSY.BATT.COVER - 150 AH	TATA spare parts
208054100104	ASSY. BATT. COVER - 150AH SIDE MOUNTED	TATA spare parts
208054106301	BATT.TRAY PLASTIC LPS3516TC	TATA spare parts
208054106303	BATTERY COVER PLASTIC)	TATA spare parts
208054209901	INSTRUMENT CLUSTER-(1.04)	TATA spare parts
208054209902	INSTRUMENT CLUSTER-(1:1.04)	TATA spare parts
208054209905	INSTR CLTR (1.04)LPS3516TC 12V ABS	TATA spare parts
208054209906	INSTR CLST (1.04)LPS3516TC 12V ABS	TATA spare parts
208054209907	INST CLT(1.04)LPS3516TC 12V F/L ABS	TATA spare parts
208054209911	INST CLUST 12V E-SPD (1.04) ABS	TATA spare parts
208054209915	ELECTRONIC INST CLUSTER(1:0.97) LPS-3518	TATA spare parts
208054209916	ELECT. INSTR. CLSTR. 7750 552HZ	TATA spare parts
208054504901	HEADLAMP LEVELLING SWITCH	TATA spare parts
208054600102	W/H PIGTAIL ABS	TATA spare parts
208054600102AE	W/H PIG TAIL ABS ECU(WABCO)-1628	TATA spare parts
208054600103	WIRING HARNESS ENGINE	TATA spare parts
208054600105	WIRING HARNESS MAIN	TATA spare parts
208054601602	WIRING HARNESS MAIN BS4	TATA spare parts
208054620101	W/H MAIN LPS-3516TC BSII 12V-	TATA spare parts
208054620104	W/H MAIN LPS-3516TC BSII I/C ABS	TATA spare parts
208054820101	W/H-MAIN LPS-3516TC BS-II I/C	TATA spare parts
20807	CAP SCREW	TATA spare parts
208124200104	BRACKET ASSY ENGINE ARM MTG LH BS6	TATA spare parts
208124200105	BRACKET ASSY ENGINE MTG TOP RH BS6	TATA spare parts
208130100126	ACCELERATOR CABLE ASSY	TATA spare parts
208131200103	CROSS MEMBER ASSY ENGINE MTG FRONT BS6	TATA spare parts
208131203301	BRACKET SUPPORT LH BS6	TATA spare parts
208131203302	BRACKET SUPPORT RH BS6	TATA spare parts
208131703305	Z-BRACKET	TATA spare parts
208132107101	PACKING PLATE	TATA spare parts
208141110105	SHORT FORK TUBE&FRONT END PIECE ASSY	TATA spare parts
208141110106	SHORT FORK TUBE&FRONT END PIECE ASSY	TATA spare parts
208143900145	PIPE ASSY COMPRESSOR TO JOINT 1	TATA spare parts
208143900149	PIPE ASSY COMP INLET WITH CRIMPED HOSE	TATA spare parts
208143900160	PIPE ASSY BUNCH COMPLETE	TATA spare parts
208143900164	PIPE ASSY BUNCH COMPLETE	TATA spare parts
208143900176	METAL PIPE ASSY SECOND	TATA spare parts
20815	LIFTING EYE	TATA spare parts
208154600101	WIRING HARNESS ABS SPLIT	TATA spare parts
208154600102	WIRING HARNESS ABS FRAME	TATA spare parts
208154660104	WIRING HARNESS ASSY MAIN	TATA spare parts
208154660105	WIRING HARNESS ASSY MAIN	TATA spare parts
208154707101	PLATE SPEED LIMITER DEVICE MOTOR MTG	TATA spare parts
208200990103	ASSY KIT FULLY BUILD SIGNA CAB 4018 BS I	TATA spare parts
208200990103IP	ASSY. CABIN KIT SIGNA SUNRISE ORAG BS4	TATA spare parts
208200990103JS	ASSY. CABIN KIT SIGNA TITANIUM WHITE BS4	TATA spare parts
208200990104	ASSY. CAB FULLY BUILD 4018 SLEEPER	TATA spare parts

208200990105	ASSY FULLY BUILD BL CAB SIGNA 4018	TATA spare parts
208200990105IP	ASSY. CABIN KIT SIGNA SLPR SUN ORAG BS4	TATA spare parts
208200990105JS	ASSY. CAB KIT SIG 3518.S TITAN_ WH SLP	TATA spare parts
208200990106	ASSY FULLY BUILD AC CAB SIGNA 4018	TATA spare parts
208200990106IP	ASSY. CAB KIT 4018.S SUN_ ORAG SLP AC BS4	TATA spare parts
208200990106JS	ASSY. CAB SIGNA FULLY BUILD TITAN_ WH-AC	TATA spare parts
208200990107	ASSY FULLY BUILD BL LD CAB SIGNA 4018	TATA spare parts
208200990107IP	ASSY. CAB FULLY BUILD BL LD SUNRISE_ ORAG	TATA spare parts
208200990107JS	ASSY. CAB KIT SIG 4018.S TITAN_ WH SLP-LD	TATA spare parts
208200990108	ASSY. CAB FULLY BUILD SIGNA 4018 CR	TATA spare parts
208224200101	ASSY BRACKET-LH (ENGINE MTG)	TATA spare parts
208224200102	ASSY BRACKET-RH (ENGINE MTG)	TATA spare parts
208224200108	BRACKET ASSY ENGINE MTG BOTTOM-LH	TATA spare parts
208224200109	BRACKET ASSY ENGINE MTG BOTTOM-RH	TATA spare parts
208226807701	BELLOW BS6	TATA spare parts
208226900103	BRACKET RH (OILCOOLER ASSEMBLY)	TATA spare parts
208226900104	BRACKET LH (OILCOOLER ASSEMBLY)	TATA spare parts
208228990102	TUBE ASSY	TATA spare parts
208229100101	ALUMINIUM MASTER CYLINDER	TATA spare parts
208229100102	BRKT.ASSY.FOR CLUTCH BOOSTER MTG.(G1400)	TATA spare parts
208229100107	ASSY MTG BKT COMPLETE	TATA spare parts
208229100108	ASSY. CLUTCH PEDAL COMPLETE	TATA spare parts
208229100112	ASSY. CLUTCH FLUID RESERVOIR WITH CLAMP	TATA spare parts
208229100113	BRACKET ASSY	TATA spare parts
208229106301	BEADING	TATA spare parts
208229150101	ASSY. CONNECTING LINE (FOR HYD. CLUTCH)	TATA spare parts
208229150104	ASSY. TUBE	TATA spare parts
208229150106	ASSY. HYD.PIPE LINE (FROM M.CYL. TO C.B)	TATA spare parts
208229300101	ASSY PIPE LINE(MC TO CB 1STPIPE)	TATA spare parts
208229300102	ASSY. HYD PIPE LINE(FROM M.CYL TO C.B.)	TATA spare parts
208229305801	HOSE PIPE(FROM RES. TO MC)	TATA spare parts
208229500101	ASSY.CONTROL MTG.BKT.WITH CYL.MTG.BKT	TATA spare parts
208230100101	ASSY. BRACKET	TATA spare parts
208230100102	ASSY. PULL ROD (L=938)	TATA spare parts
208230100103	ASSY. PULL ROD (L=776)	TATA spare parts
208230100106	ASSY.ACCELERATOR PEDAL COMPLETE	TATA spare parts
208230100108	ACCELERATOR CABLE 3105MM BS3	TATA spare parts
208230100110	BRACKET ASSY ACCELERATOR PEDAL	TATA spare parts
208230100112	ACCELERATOR CABLE ASSY	TATA spare parts
208231000105	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
208231000108	ASSY. FRAME WITH FITMENT BS3/4	TATA spare parts
20823100010804	ASSY FRAME 4018.S(FAB 4 HOLE BRKT)BS3/4	TATA spare parts
20823100010806	ASSY FRAME (CAST TYPE 6 HOLE BRKT)	TATA spare parts
208231000109	ASSY FRAME 4018.S(CAST 6 HOLE BRKT)BS3/4	TATA spare parts
20823100010904	ASSY FRAME 4018.S(FAB 4 HOLE BRKT)BS3/4	TATA spare parts
20823100010906	ASSY FRAME (CAST TYPE 6 HOLE BRKT)	TATA spare parts
208231000112	ASSY. FRAME WITH FITMENT BS1/2/3/4	TATA spare parts

208231000115	FRAME ASSY WITH FITMENT	TATA spare parts
208231000117	ASSY. FRAME WITH FITMENT	TATA spare parts
208231107110	REINFORCEMENT LH	TATA spare parts
208231107111	REINFORCEMENT RH	TATA spare parts
208231200101	ASSY. SUPPORT LH (ENGG. MTG. C.M. FRONT)	TATA spare parts
208231200102	ASSY. SUPPORT RH (ENGG. MTG. C.M. FRONT)	TATA spare parts
208231200103	ASSY. ENGINE CM (FRONT) WITH SPACER	TATA spare parts
208231200108	ASSY.BRKT.FOR 5TH SUPPORT ON G.B	TATA spare parts
208231200110	ASSY BRACKET-RH CHEQUERED PLATE	TATA spare parts
208231200111	ASSY BRACKET-LH CHEQUERED PLATE	TATA spare parts
208231200113	ASSY CHEQUERED PLATE	TATA spare parts
208231200114	CROSS MEMBER ASSY REAR	TATA spare parts
208231200116	ASSY. ENG. CROSS MEMBER (REAR)	TATA spare parts
208231200118	ASSY. 4TH CROSS MEMBER.	TATA spare parts
208231200121	ASSY. ENG. CROSS MEMBER (FRONT)	TATA spare parts
208231200123	BRACKET SUPPORT ASSY RH	TATA spare parts
208231200124	SUPPORT BRACKET ASSY LH	TATA spare parts
208231200125	SUPPORT BRACKET CHEQUERED PLATE	TATA spare parts
208231200126	ALLIGATED CROSS MEMBER ASSY	TATA spare parts
208231200127	END CROSS MEMBER ASSY WITH GUSSET	TATA spare parts
208231200128	CROSS MEMBER ASSY	TATA spare parts
208231200130	BRACKET ASSY GEAR BOX MTG RH	TATA spare parts
208231200131	BRACKET ASSY GEAR BOX MTG LH	TATA spare parts
208231207102	SPACER PLATE	TATA spare parts
208231207103	STEEL CHEQUERED PLATE (BATTERY MTG.)	TATA spare parts
208231207104	STEEL CHEQUERED PLATE (SPARE WHEEL MTG.)	TATA spare parts
208231207109	REINFORCEMENT	TATA spare parts
208231207110	SUPPORT Z-RH	TATA spare parts
208231207111	SUPPORT Z-LH	TATA spare parts
208231207128	BASE PLATE SUPPORT	TATA spare parts
208231207129	SUPPORT BOTTOM (4TH CROSS MEMBER)	TATA spare parts
208231207130	SUPPORT PLATE CROSS MEMBER MTG	TATA spare parts
208231207134	PLATE	TATA spare parts
208231207135	SUPPORT TOP -LH (4TH CROSS MEMBER)	TATA spare parts
208231207138	REINFORCEMENT REAR RH	TATA spare parts
208231207139	REINFORCEMENT REAR LH	TATA spare parts
208231207140	REINFORCEMENT RH	TATA spare parts
208231207141	REINFORCEMENT LH	TATA spare parts
208231700103	ASSY. FUPD CROSS BEAM COMPLETE	TATA spare parts
208231700104	ASSY FUPD MTG. BKT.(RH)	TATA spare parts
208231700105	ASSY FUPD MTG. BKT.(LH)	TATA spare parts
208231700108	ASSY HSNP MTG BRACKET	TATA spare parts
208231700109	ASSY. FUPD MTG. BKT. (RH)-FACELIFT BS3/4	TATA spare parts
208231700110	ASSY. FUPD MTG. BKT. (LH)-FACELIFT BS3/4	TATA spare parts
208231700111	END BRACKET ASSY RH (HYD. TANK)	TATA spare parts
208231700112	SUPPORT CHANNEL ASSY. (HYD. TANK)	TATA spare parts
208231700114	ASSY. FUPD CROSS BEAM BS3/4	TATA spare parts



208231707119	END BRACKET LH (HYD. TANK)	TATA spare parts
208231990102	ASSY.RETRO KIT FOR RAMP LPS-4018	TATA spare parts
208231993301	BRACKET (BREATHER MOUNTING)	TATA spare parts
208231998001	HEX SCREW M14X35 SS8451 IS1364P2-12.9	TATA spare parts
208232400102	LEAF SPRING ASSY REAR	TATA spare parts
208232400104	1ST LEAF ASSY WITH BUSH	TATA spare parts
208232403301	BRACKET SPRING HANGER REAR-REAR	TATA spare parts
208232404202	CLIP	TATA spare parts
208232404203	SPRING CLIP	TATA spare parts
208232404204	SPRING CLIP	TATA spare parts
208232407101	4TH LEAF AUX SPRING	TATA spare parts
208232407102	8TH LEAF MAIN SPRING	TATA spare parts
208232407103	6TH LEAF AUX SPRING	TATA spare parts
208232407104	1ST LEAF BS6	TATA spare parts
208232407105	2ND LEAF MAIN SPRING	TATA spare parts
208232407106	4TH LEAF MAIN SPRING	TATA spare parts
208232407107	3RD LEAF MAIN SPRING	TATA spare parts
208232407108	9TH LEAF MAIN SPRING	TATA spare parts
208232407109	5TH LEAF AUX SPRING	TATA spare parts
208232407110	3RD LEAF AUX SPRING	TATA spare parts
208232407111	5TH LEAF MAIN SPRING	TATA spare parts
208232407112	1ST LEAF AUX SPRING	TATA spare parts
208232407113	7TH LEAF MAIN SPRING	TATA spare parts
208232407114	6TH LEAF MAIN SPRING	TATA spare parts
208232407115	2ND LEAF AUX SPRING	TATA spare parts
208232407116	7TH LEAF AUX SPRING	TATA spare parts
208232407117	10TH LEAF MAIN SPRING	TATA spare parts
208232990101	ASSY.PARABOLIC SPG. KIT FOR LPS4018	TATA spare parts
208233000101	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
208234200101	STRUCTURE ASSY FIFTH WHEEL COUPLING	TATA spare parts
208234200102	PLATE & FIFTH WHEEL COUPLING ASSY	TATA spare parts
208234207101	MOUNTING PLATE FIFTH WHEEL COUPLINGBS6	TATA spare parts
208240100101	ASSY. WHEEL RIM BS4/6	TATA spare parts
208240100102	WHEEL RIM BASE	TATA spare parts
208240100103	WHEEL RIM ASSY BS6	TATA spare parts
208240109902	WHEEL RIM BASE BS6	TATA spare parts
208240307701	RUBBER PAD	TATA spare parts
208241106101	LOCKING PLATE	TATA spare parts
208241120101	ASSY. PROPELLER SHAFT	TATA spare parts
208241120102	CROSS ASSY.	TATA spare parts
208241120103	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
208241120106	LONG FORK SUB ASSY.	TATA spare parts
208241120107	SHORT FORK TUBE&REAR HOSING ASSY	TATA spare parts
208241120108	ASSY PROPEELER SHAFT	TATA spare parts
208241120110	ASSY. PROPELLER SHAFT BS1/3/4	TATA spare parts
208241120111	SHORT FORK TUBE&REAR HOUSING ASSY	TATA spare parts
208241120112	ASSY. PROPELLER SHAFT	TATA spare parts

208241120113	SLIP YOKE ASSY.	TATA spare parts
208241120114	ASSY. PROPELLER SHAFT	TATA spare parts
208241120131	PROPELLER SHAFT ASSY REAR	TATA spare parts
208241120135	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
208241125101	LONG FORK	TATA spare parts
208241125102	SHORT FORK	TATA spare parts
208241125103	FLANGE YOKE	TATA spare parts
208241125104	FLANGE YOKE	TATA spare parts
208242920101	ASSY.TUBE ON COMP.O/P(1045 LG)	TATA spare parts
208243200101	ASSY. BRACKET - 15L TANK MTG.	TATA spare parts
208243200102	ASSY.AIR TANK (15 LTR) FOR ABS.	TATA spare parts
208243200115	ASSY.AIR TANK (15 LTR)	TATA spare parts
208243200116	AIR TANK ASSY WITH BKT	TATA spare parts
208243200117	AIR TANK ASSY WITH FITTINGS	TATA spare parts
208243200122	ASSY BRACKET MODULATOR VALVE MTG FRONT	TATA spare parts
208243200123	ASSY. AIR TANK 30 LIT. (BRKT. CD 312) LH	TATA spare parts
208243200124	ASSY. AIR TANK 30 LIT. (BRKT. CD 312)RH	TATA spare parts
208243207501	RUBBER GROMMET (FOR SPEEDOMETER CABLE)	TATA spare parts
208243208202	BRACKET-FRONT (15L AIR TANK MTG.)	TATA spare parts
208243208203	BRACKET-REAR (15L AIR TANK MTG.)	TATA spare parts
208243506803	SEALING PLUG	TATA spare parts
208243700128	PALM COUPLING SUPPLY LINE-TRAILER	TATA spare parts
208243700129	PALM COUPLING CONTROL LINE-TRAILER	TATA spare parts
208243700133	PALM COUPLING CONTROL LINE TRACTOR	TATA spare parts
208243700134	PALM COUPLING ASSY SUPPLY LINE TRACTOR	TATA spare parts
208243700135	PALM COUPLING CONTROL LINE TRAILER	TATA spare parts
208243700136	PALM COUPLING ASSY SUPPLY LINE TRAILER	TATA spare parts
208243707708	SEAL BS6-PH2	TATA spare parts
208243710108	AIR PROCESSING UNIT	TATA spare parts
208243710110	AIR PROCESSING UNIT	TATA spare parts
208243710112	BRACKET ASSY APU MTG	TATA spare parts
208243710117	AIR TANK ASSY	TATA spare parts
208243710118	AIR TANK ASSY	TATA spare parts
208243800101	PIPE ASSY GEAR BOX TO OIL COOLER	TATA spare parts
208243800102	PIPE ASSY OIL COOLER TO GEAR BOX	TATA spare parts
208243900102	SET ASSY NYLON PIPE COMP	TATA spare parts
208243900108	SET ASSY NYLON PIPE COMP	TATA spare parts
208243900129	ASSY TUBE WITH CRIMPED HOSE COMP.(AIR FI	TATA spare parts
208243900130	ASSY TUBE(18 O.D.X2561LG)	TATA spare parts
208243900131	ASSY TUBE(15 O.D.X1785LG)	TATA spare parts
208243900132	ASSY. TUBE ON COMP.O/P(DL-1295 LG) BS1-4	TATA spare parts
208243900138	SET ASSY.NY PIPE WITH PLASTIC CONNECTOR	TATA spare parts
208243900143	SET ASSY.NYLON PIPE COMP FOR LPS 4018	TATA spare parts
208243900152	ASSY. SET NYLON PIPE CHASSIS BS1/3	TATA spare parts
208243900179	NYLON PIPE BUNCH ASSY LPS4018	TATA spare parts
208243910116	ASSY METAL PIPE 2ND LPS 4018	TATA spare parts
208243910119	PIPE BUNCH ASSY	TATA spare parts

208243910131	PIPE ASSY BUNCH COMPLETE FOR LPS 4018	TATA spare parts
208243910165	ASSY. PIPE BUNCH COMPLETE BS4	TATA spare parts
208243910178	PIPE ASSY	TATA spare parts
208243910184	PIPE BUNCH ASSY	TATA spare parts
208243910188	METAL PIPE ASSY	TATA spare parts
208243910192	METAL PIPE ASSY	TATA spare parts
208243910195	PIPE BUNCH ASSY	TATA spare parts
208243910198	PIPE BUNCH ASSY	TATA spare parts
208243920117	METAL PIPE ASSY	TATA spare parts
208243920118	METAL PIPE ASSY	TATA spare parts
208243920119	METAL PIPE ASSY	TATA spare parts
208243990113	KIT-PALM COUPLING BS6-PH2	TATA spare parts
208246100101	ASSY. STEERING COLUMN SUPPORT	TATA spare parts
208246100104	ASSY. STG COLUMN SUPPORT COMPLETE	TATA spare parts
208246100105	ASSY. STEERING COLUMN SUPPORT	TATA spare parts
208246200101	ASSY. STEERING SPINDLE BS1/2/3/4	TATA spare parts
208246200102	ASSY. STEERING SPINDLE BS1/2/3/4	TATA spare parts
208246200103	ASSY. STEERING SPINDLE (TOP)	TATA spare parts
208246207906	STEERING SPINDLE (TOP)	TATA spare parts
208246207910	SLEEVE STG LEEVE	TATA spare parts
208246207911	STEERING SLEEVE	TATA spare parts
208247100101	ASSY. FUEL TANK COMPLETE (400 LTR)	TATA spare parts
208247500105	ASSY. BRACKET FUEL TANK MTG . BS1- 4/6	TATA spare parts
208247500108	FUEL TANK MTG . ASSY BRACKET	TATA spare parts
208247500110	BRACKET ASSY FUEL TANK MTG	TATA spare parts
208247600101	ASSY TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
208247600103	ASSY. SUCTION LINE	TATA spare parts
208247600104	ASSY. RETURN LINE	TATA spare parts
208247600109	FUEL PIPE LINE ASSY FILTER TO ENGINE	TATA spare parts
208247600111	FUEL SUCTION LINE ASSY	TATA spare parts
208247600112	SUCTION LINE ASSY FILTER TO FIP	TATA spare parts
208247600113	FUEL RETURN LINE ASSY	TATA spare parts
208247600114	BRACKET ASSY (FUEL WATER SEPERATOR MTG)	TATA spare parts
208247600118	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
208247600119	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
208247600120	RETURN PIPE ASSY FUEL TANK TO ENGINE	TATA spare parts
208247600122	PIPE ASSY TANK TO INT JOINT	TATA spare parts
208247600123	PIPE ASSY TANK TO INT JOINT	TATA spare parts
208247600124	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
208247600125	FUEL SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
208247600126	FUEL SUCTION PIPE ASSY FUEL FTR TO ENG	TATA spare parts
208247703301	BRACKET PRIMING PUMP MTG	TATA spare parts
208249100101	ASSY. SILENCER W/TAIL PIPE BS1/2/3	TATA spare parts
208249200102	ASSY. EXHAUST PIPE (TC MTG.)	TATA spare parts
208249200105	ASSY. EXHAUST PIPE BS1/2/3	TATA spare parts
208249200108	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
208249200109	ASSY. BRACKET (TC OUTLET)	TATA spare parts

208249200122	BRACKET ASSY EGP MTG	TATA spare parts
208249200123	BRACKET ASSY EGP MTG	TATA spare parts
208249200124	BRACKET ASSY NOX SENSOR MTG	TATA spare parts
208249200126	PIPE ASSY T-CONNECTOR TO AIR OIL FILTER	TATA spare parts
208249200127	PIPE ASSY AIR OIL FILTER TO DU	TATA spare parts
208249200128	BRACKET ASSY TAIL PIPE MTG	TATA spare parts
208249203301	BRACKET (ON CROSS MEMBER)	TATA spare parts
208249203302	BRACKET DECOMP PIPE MTG	TATA spare parts
208249203303	BRACKET (ON LONG MEMBER)	TATA spare parts
208249203304	BRACKET (ON LONG MEMBER)	TATA spare parts
208249203305	BRACKET	TATA spare parts
208249203306	BRACKET	TATA spare parts
208249203308	BRACKET EGP MTG	TATA spare parts
208249203309	L-BRACKET EXHAUST MTG	TATA spare parts
208249203314	BRACKET EXHAUST PIPE MTG	TATA spare parts
208249204202	CLAMP SILENCER MTG	TATA spare parts
208249206911	TAIL PIPE	TATA spare parts
208249207123	SPACER	TATA spare parts
208249208201	CLAMP (SILENCER MTG)	TATA spare parts
20824932000R40SJ	ASSY. CAB COMPLETE SIGNA LPS 4018.S BS3	TATA spare parts
208249990102	KIT-HEAT SHIELD FOR SILENCER & EXH PIPE	TATA spare parts
208250990101	RETRO KIT COOLING SYSTEM FOR LPS 4923TC	TATA spare parts
208252200101	ASSY.BKT LH REAR COMPLETE	TATA spare parts
208252200102	ASSY.BKT RH REAR COMPLETE	TATA spare parts
208252200103	ASSY.BKT.LH FRT(REAR WHEEL ARCH MTG.)	TATA spare parts
208252200104	ASSY.BKT.RH FRT(REAR WHEEL ARCH MTG.)	TATA spare parts
208252200109	CLAMP ASSY FENDER BS6	TATA spare parts
208252200110	CLAMP ASSY FENDER	TATA spare parts
208252206301	WHEEL ARCH REAR LH BS1/2/3/4	TATA spare parts
208252206302	WHEEL ARCH REAR RH BS1/2/3/4	TATA spare parts
208252206306	WHEEL ARCH REAR-LH	TATA spare parts
208252206307	WHEEL ARCH REAR-RH	TATA spare parts
208254100106	ASSY BATT CABLE (LINK)-50SQMM -(300MM)	TATA spare parts
208254100107	ASSY BATT CABLE(COT TUBE)+VE	TATA spare parts
208254100108	ASSY BATT CABLE (LINK)-50SQMM - (200MM)	TATA spare parts
208254100109	ASSY BATTERY CABLE +VE 50QMM(BATT-BCS)-5	TATA spare parts
208254100110	ASSY BATTERY CABLE +VE 50QMM(SM-BCS)-165	TATA spare parts
208254100111	ASSY BATT CUT OFF SWITCH MTG BKT	TATA spare parts
208254100112	ASSY BATTERY CABLE(+VE) 50SQM COT (BCS-S	TATA spare parts
208254100117	ASSY SUPPORT (100AH BATTERY)	TATA spare parts
208254100119	ASSY MTG BKT-BCS	TATA spare parts
208254100121	BATTERY CUT-OFF SW MOUNTING BRACKET	TATA spare parts
208254100122	ASSY. BATTERY CABLE +VE 1750MM BS6	TATA spare parts
208254100130	TELEMATICS UNIT	TATA spare parts
208254106301	BATTERY TRAY 100AH-PLASTIC	TATA spare parts
208254106302	BATTERY TRAY(PLASTIC)-150AH	TATA spare parts
208254108206	BATTERY CLAMP (100AH) - CHANNEL	TATA spare parts

208254109905	ELECT. INSTR. CLSTR 8320 552HZ BS1/2/3	TATA spare parts
208254109908	AIR PRESSURE TRANSDUCER BS3/4	TATA spare parts
208254110102	ASSY BATT CABLE -VE WITH PIGTAIL-1260LG	TATA spare parts
208254110104	ASSY BATT CABLE(COT TUBE)-VE (BATT-BCS)	TATA spare parts
208254110105	ASSY BATTERY CABLE -VE 50QMM(BATT-BCS)-7	TATA spare parts
208254110106	ASSY BATT CABLE -VE WITH PIGTAIL 700MM	TATA spare parts
208254110107	ASSY BATTERY CABLE (-VE) 50SQM COT(BCS-S	TATA spare parts
208254200105	ASSY BRACKET [BUZZER BEEPER & WIF]	TATA spare parts
208254200106	ASSY NYLON PIPE FOR GUAGE LINE -1516FACE	TATA spare parts
208254209904	ELECTRONIC SPEEDOMETER 1:1.04	TATA spare parts
208254209906	INSTRUMENT CLUSTER 1:1.04	TATA spare parts
208254209908	WIRING HARNESS FOR INSTRUMENT CLUSTER	TATA spare parts
208254209909	TRIP E-SPEEDOMETER 24V (1:1.04)	TATA spare parts
208254209912	INST CLSTR LPS4018 697 (1.04) 24V	TATA spare parts
208254209914	INST CLSTR (1.04) LPS4018TC 24V ABS	TATA spare parts
208254209916	INSTR CLTR (1.04)LPS4018TC 24V ABS	TATA spare parts
208254209918	INST CLT (1.04)LPS4018TC 24V F/L ABS	TATA spare parts
208254209920	INST CLST (1.04)LPS4018 697 24V ABS	TATA spare parts
208254209922	INST CLUST 24V E-SPD (1.04) ABS	TATA spare parts
208254209927	INSTRUMENT CLUSTER 24V E-SPEEDO(0.80) AB	TATA spare parts
208254209929	TRIP E-SPEEDOMETER (0.80)	TATA spare parts
208254209931	INST CLUST-24V E-SPD (1.04) ABS	TATA spare parts
208254209964	ASSY TANK UNIT(400LRS)-BIPOLAR	TATA spare parts
208254209968	INST CLSTR E-SPD(0.74)24V LPS4923	TATA spare parts
208254209970	ELECTR.SPEEDO METER(0.74)24V	TATA spare parts
208254209975	E-SPEEDOMETER (1.0) 24V	TATA spare parts
208254209978	ELECTR.SPEEDO METER(1:0.96)24V	TATA spare parts
208254209979	ELECTR.SPEEDO METER(1:0.96)24V	TATA spare parts
208254209984	INSTRUMENT CLUSTER E-SPD(0.96) 24V LPS35	TATA spare parts
208254209985	INST CLSTR E-SPD(0.96)24V LPS3518	TATA spare parts
208254209989	INSTR CLSTR WITH E-SPEEDO 1:1.09 BSIV-SC	TATA spare parts
208254209994	INST.CLUSTER-1:0.88 LPS-4923 TC BS-III	TATA spare parts
208254209995	ASSY. INSTRUMENT CLUSTER 24 V BS2/3	TATA spare parts
208254249901	ECU 24V ABS 4S/3M	TATA spare parts
208254249902	WIRING HARNESS FRAME BS1/3	TATA spare parts
208254400101	ASSY ENGINE LAMP BIPOLAR TYPE	TATA spare parts
208254400145	ASSY BLINKER LAMP 12V LH	TATA spare parts
208254400148	ASSY REVOLVONG LAMP 24V	TATA spare parts
208254400148AE	ASSY REVOLVONG LAMP 24V-1628	TATA spare parts
208254407701	GASKET REVOLVING LAMP	TATA spare parts
208254440122	ASSY BLINKER LAMP 24V LH	TATA spare parts
208254440123	ASSY BLINKER LAMP 24V RH	TATA spare parts
208254600101	W/H FRAME ABSLPS4018/4923TC	TATA spare parts
208254600102	W/H FRAME ABS LPS-4018/3516	TATA spare parts
208254600103	W/H PIGTAIL TAIL LAMP LPS4018/4923/3516	TATA spare parts
208254600106	ASSY PLUG SUPPORT BKT(JUMPER CABLE)	TATA spare parts
208254600107	ASSY PLUG SUPPORT BKT(JUMPER CABLE)CM	TATA spare parts

208254600108	W/H FRAME ABS6-4S/3M	TATA spare parts
208254600119	BRACKET JUMPER CABLE LIGHITING ASSY	TATA spare parts
208254600126	WIRING HARNESS ABS FRAME	TATA spare parts
208254600127	WIRING HARNESS ABS SPLIT	TATA spare parts
208254600128	WIRING HARNESS ABS FRAME	TATA spare parts
208254600129	WIRING HARNESS ABS SPLIT	TATA spare parts
208254600130	WIRING HARNESS FRAME BS3/4	TATA spare parts
208254600134	JUMPER CABLE ABS CONNECTION	TATA spare parts
208254600144	WIRING HARNESS FRONT	TATA spare parts
208254600145	WIRING HARNESS MAIN	TATA spare parts
208254600146	WIRING HARNESS TAIL	TATA spare parts
208254600147	WIRING HARNESS TAIL	TATA spare parts
208254600148	WIRING HARNESS TAIL	TATA spare parts
208254600149	WIRING HARNESS MAIN	TATA spare parts
208254600150	WIRING HARNESS FRONT	TATA spare parts
208254600151	WIRING HARNESS ROOF	TATA spare parts
208254600152	WIRING HARNESS MAIN	TATA spare parts
208254600153	WIRING HARNESS ENGINE	TATA spare parts
208254600155	WIRING HARNESS TAIL	TATA spare parts
208254600158	WIRING HARNESS ABS FRAME	TATA spare parts
208254601669	WIRING HARNESS MAIN BS4	TATA spare parts
208254601670	WIRING HARNESS SCR UNIT	TATA spare parts
208254601671	WIRING HARNESS TAIL	TATA spare parts
208254601678	WIRING HARNESS TAIL	TATA spare parts
208254603302	BRACKET JUMPER CABLE MTG	TATA spare parts
208254620101	W/H MAIN LPS4018TC 24V UNIPOLAR	TATA spare parts
208254620102	W/H TAIL LPS4018TC 24V UNIPOLAR	TATA spare parts
208254620102B	W/H TAIL LPS4018TC 24V UNIPOLAR UNMODIFI	TATA spare parts
208254620103	W/H ENGINE LPS4018TC 24V UNIPOLAR	TATA spare parts
208254620104	W/H ROOF LPS4018TC UNIPOLAR	TATA spare parts
208254620105	W/H BATT TAP (PIGTAIL) 24V	TATA spare parts
208254620107	WIRING HARNESS MAIN	TATA spare parts
208254620108	WIRING HARNESS TAIL	TATA spare parts
208254620109	WIRING HARNESS-ENGINE	TATA spare parts
208254620110	W/H-ROOF LPS-4018TC BIPOLAR	TATA spare parts
208254620111	WIRING HARNESS MAIN 4018TC UNI I BS2/3	TATA spare parts
208254620112	WIRING HARNESS MAIN	TATA spare parts
208254620114	W/H TAIL LPS4923TC/38 BSII 24V	TATA spare parts
208254620117	W/H TAIL	TATA spare parts
208254620122	W/H MAIN LPS-4018TC/4923TC AIS-O75	TATA spare parts
208254620128	WH TAIL LPS4018TC/32 BSII REAR EXH	TATA spare parts
208254620130	WIRING HARNESS STOP LT.SW.AND LP SW.	TATA spare parts
208254620131	WH TAIL LPS4923TC/38 EII 24V G1150	TATA spare parts
208254620135	W/H PIGTAIL-JUMPER CABLE	TATA spare parts
208254620137	W/H MAIN	TATA spare parts
208254620147	W/H ROOF LPS4018TC UNIPOLAR	TATA spare parts
208254620155	W/H ENGINE	TATA spare parts

208254620156	WIRING HARNESS TAIL BS1/3	TATA spare parts
208254620157	WIRING HARNESS MAIN BS3	TATA spare parts
208254620160	WIRING HARNESS MAIN	TATA spare parts
208254620162	WIRING HARNESS	TATA spare parts
208254620168	WIRING HARNESS MAIN BS3	TATA spare parts
208254620169	WIRING HARNESS MAIN BS4	TATA spare parts
208254620170	WIRING HARNESS SCR UNIT BS4	TATA spare parts
208254620171	WIRING HARNESS TAIL	TATA spare parts
208254660104	WIRING HARNESS ROOF	TATA spare parts
208254660109	W/H ENGINE LPS4018TC 24V UNIPOLAR	TATA spare parts
208254660110	W/H ROOFLAMP LPS4018TC UNIPOLAR	TATA spare parts
208254660113	W/H BATT TAP(PIGTAIL) LPS/LPK 24V	TATA spare parts
208254660126	W/H MAIN LPS-4018TC/4923TC AIS-O75	TATA spare parts
208254660153	WIRING HARNESS TAIL BS3	TATA spare parts
208254660155	W/H ENGINE LPK-2518 TC BS-III	TATA spare parts
208254660159	W/H ENGINE	TATA spare parts
208254660160	WH TAIL	TATA spare parts
208254660161	WIRING HARNESS MAIN WITHOUT TELEMATICS	TATA spare parts
208254660165	WIRING HARNESS MAIN BS3	TATA spare parts
208254660166	MAIN WIRING HARNESS	TATA spare parts
208254660173	WIRING HARNESS MAIN ASSY	TATA spare parts
208254800101	TELEMATICS CONTROL UNIT BS3/4	TATA spare parts
208254820101	W/H-MAIN LPS-4018TC BS-II BIPOLAR I/C	TATA spare parts
208254820102	W/H-MAIN LPS-4018TCBS-IIUNIPOLAR	TATA spare parts
208254820103	W/H-TAIL LPS-4018TC/32 BSII UNIPOL	TATA spare parts
208254820111	W/H ENGINE LPS4018TC 24V UNIPOLAR	TATA spare parts
208254820112	W/H JUMPER CABLE	TATA spare parts
208254820113	W/H PIGTAIL ELECT. SPEEDOMETER	TATA spare parts
208254820114	WIRING HARNESS JUMPER CABLE AT CROSS MEM	TATA spare parts
208254820117	JUMPER CABLE LIGHTING	TATA spare parts
208254820118	JUMPER CABLE LIGHTING CONNECTION	TATA spare parts
208254821601	W/H ROOFLAMP LPS-4018TC UNIPOLAR	TATA spare parts
208254829901	SOCKET JUMPER CABLE	TATA spare parts
208258409901	TRANSFER LABEL	TATA spare parts
208258902601	DRIFT FRONT COVER OIL SEAL PRESSING	TATA spare parts
208258902602	DRIFT REAR COVER OIL SEAL PRESSING	TATA spare parts
208258902603	DRIFT INNER RACE BEARING FITMENT	TATA spare parts
208258902604	DRIFT INNER RACE BEARING FITMENT	TATA spare parts
208258902605	DRIFT INNER RACE BEARING FITMENT	TATA spare parts
208258902606	PULLER MAIN SHAFT ASSY	TATA spare parts
208258904701	FUEL WATER SEPARATOR TOOL	TATA spare parts
20826000004R40	LPS 4018.S CR BS _CAB_TPL 83GR FORCE VE	TATA spare parts
20826132000R40	TATA LPS 4018 CR BS IV _CAB/COWL	TATA spare parts
20827332000R40	60R_RESTRUCTURE_FOR_CVBU_IN_APL_VIEW	TATA spare parts
20827432000R40	60R_RESTRUCTURE_FOR_CVBU_IN_APL_VIEW	TATA spare parts
20827632000R40	60R_RESTRUCTURE_FOR_CVBU_IN_APL_VIEW	TATA spare parts
20827732000R40	60R_RESTRUCTURE_FOR_CVBU_IN_APL_VIEW	TATA spare parts

20828632000R40	60R_RESTRUCTURE_FOR_CVBU_IN_APL_VIEW	TATA spare parts
208354209902	OIL PRESSURE GAUGE ELECTRICAL	TATA spare parts
208354209903	AIR PRESSURE GAUGE	TATA spare parts
208400041	MOULDING END (LH)	TATA spare parts
208460000105	ASSY BARE COWL	TATA spare parts
208460000107	ASSY COWL COMP RHD	TATA spare parts
208460000108	SK 1613TC COWL FITTED EURO I	TATA spare parts
208460000117	ASSY BARE COWL SE1613TC PAINTED	TATA spare parts
208460000119	ASSY COWL SHELL PAINTED SE1613TC EUROII	TATA spare parts
208460000120	ASSY. COWL COMPLETE 1613TC-EURO-II	TATA spare parts
208460000121	ASSY. COWL COMPLETE	TATA spare parts
208460000124	ASSY. COWL PAINTED	TATA spare parts
208460000132	ASSY. COWL COMPLETE SK1613TC EURO I	TATA spare parts
208460000133	ASSY. COWL PAINTED SK1613TC EURO I	TATA spare parts
208460100101	ASSY. COWL COMPLETE RHD	TATA spare parts
208460100102	ASSY. COWL SHELL PAINTED	TATA spare parts
208460100112	ASSY COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
208460100112SJ	ASSY COWL COMPLETE WITH FITMENTS RHD SPA	TATA spare parts
208460100113	ASSY COWL SHELL PAINTED RHD	TATA spare parts
208460100117	ASSY. COWL COMPLETE	TATA spare parts
208460100118	ASSY. COWL SHELL PAINTED(BARE COWL)	TATA spare parts
208460100122	ASSY. COWL COMPLETE	TATA spare parts
208460100122SJ	COWL COMPLETE SPARE PART	TATA spare parts
208460100123	ASSY. COWL SHELL PAINTED	TATA spare parts
208460100128SJ	ASSY COWL COMPLETE	TATA spare parts
208460100129SJ	ASSY COWL COMPLETE_ SPARE PARTS	TATA spare parts
208460100130	ASSY. COWL SHELL PAINTED	TATA spare parts
208460100135	ASSY. COWL COMPLETE 1616 SE BSIII	TATA spare parts
208460100136	SE 1616 COWLSHELL PAINTED	TATA spare parts
208460100138	ASSY COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
208460100139	ASSY COWL SHELL PAINTED RHD	TATA spare parts
208460100146	ASSY. COWL COMP.1616 SK BSIII	TATA spare parts
208460100147	SK 1616 COWLSHELL PAINTED	TATA spare parts
208460100152	ASSY. COWL COMPLETE 1613 SE BS 3	TATA spare parts
208460100152SJ	ASSY. COWL COMPLETE- SPARE	TATA spare parts
208460100153	ASSY. COWL COMPLETE 1613 SK BS 3	TATA spare parts
208460100153SJ	A. COWL COMPLETE 1613 SK BS3 SPARE PART	TATA spare parts
208460100155SJ	ASSY COWL COMPL(SE1613 697 BS3 ERGO SPA)	TATA spare parts
208460100156SJ	ASSY.COWL COMPLETE SPARE PARTS	TATA spare parts
208460100157	ASSY COWL SHELL PAINTED	TATA spare parts
208460100159	ASSY. COWL COMPLETE	TATA spare parts
208460100159SJ	COWL COMPLETE SPARE PART	TATA spare parts
208460100160	ASSY. COWL SHELL PAINTED	TATA spare parts
208460100164SJ	ASSY.COWL COMPLETE	TATA spare parts
208460100165	ASSY.COWL SHELL PAINTED	TATA spare parts
208460100184	COWL ASSY WITH FITMENT	TATA spare parts
208460100185	COWL SHELL ASSY PAINTED	TATA spare parts



208460100187	COWL ASSY PAINTED	TATA spare parts
208460100192	COWL SHELL ASSY PAINTED	TATA spare parts
208460100198	COWL SHELL ASSY IN WHITE	TATA spare parts
208460100199	COWL SHELL ASSY PAINTED	TATA spare parts
208460110101	"COWL ASSY,PAINTEDç"	TATA spare parts
208468900103	ASSY. KIT FOR LOCKS & KEY(COMMON KEY)	TATA spare parts
208481106301	STICKER BHARAT STG. I	TATA spare parts
208489010101	ASSY. CROSS MEMBER-COWL MTG. REAR	TATA spare parts
208489100101	ASSY BRACKET (COWL MTG RR) SE 1613TC	TATA spare parts
208489100102	ASSY BRACKET-COWL MTG REAR	TATA spare parts
208489100104	ASSY. BRACKET (COWL MTG. REAR )	TATA spare parts
208529100101	PIPE ASSY 6D X 1510 LG	TATA spare parts
208529100102	CONNECTING LINE	TATA spare parts
208529100104	ASSY. TUBE-6 O.D. X 1630 LG.	TATA spare parts
208542700106	ASSY PIPE 12 DIA X 2295MM	TATA spare parts
208542700107	ASSY PIPE 12 DIA X 840MM	TATA spare parts
208542700111	ASSY TUBE 12 DIA X 1520MM	TATA spare parts
208542700112	ASSY PIPE 6 DIA X 1480 MM	TATA spare parts
208542700113	ASSY PIPE 6 DIA X 2190MM	TATA spare parts
208542700115	ASSY PIPE 12 DIA X 610 MM	TATA spare parts
208542700116	ASSY. BRAKE PIPE 6 O.D. X 825 LPT 1613TC	TATA spare parts
208542700117	ASSY TUBE 12 DIA X 750 MM	TATA spare parts
208542700118	ASSY PIPE 12 DIA X 2200MM	TATA spare parts
208542700119	ASSY.TUBE WITH CRIMPED R/HOSE LPT1615TC	TATA spare parts
208542700122	ASSY.HOSE LPT1615TC	TATA spare parts
208542700123	ASSY.TUBE 6DIAX1685LG LPT1615TC	TATA spare parts
208542700124	ASSY.TUBE 6DIAX1240LG LPT1615TC	TATA spare parts
208542700125	ASSY.TUBE 12DIAX890LG LPT1615TC	TATA spare parts
208542700126	ASSY.TUBE 12DIAX1630LG LPT1615TC	TATA spare parts
208542900101	TUBE ASSY 18D X 920 LG	TATA spare parts
208542900102	PIPE ASSY 15D X 1685 LG	TATA spare parts
208542900103	PIPE ASSY 15D X 1185 LG	TATA spare parts
208542900104	PIPE ASSY 15D X 1030 LG	TATA spare parts
208542900106	PIPE ASSY 6D X 670 LG	TATA spare parts
208542900107	PIPE ASSY 6D X 2160 LG	TATA spare parts
208542900109	PIPE ASSY 12D X 700 LG	TATA spare parts
208542900110	PIPE ASSY 12D X 2995 LG	TATA spare parts
208542900111	PIPE ASSY 12D X 2765 LG	TATA spare parts
208542900112	PIPE 12 X 910	TATA spare parts
208542900113	PIPE ASSY 12D X 1505 LG	TATA spare parts
208542900114	ASSY PIPE 12 DIA	TATA spare parts
208542900115	PIPE 12 X 1265	TATA spare parts
208542900116	PIPE ASSY 12D X 685 LG	TATA spare parts
208542900117	PIPE ASSY 12D X 1890 LG	TATA spare parts
208542900118	PIPE ASSY 12D X 1720 LG	TATA spare parts
208542900119	PIPE 6 X 805	TATA spare parts
208542900120	PIPE 6 X 1885	TATA spare parts

208542900121	PIPE 6 X 810	TATA spare parts
208542900122	PIPE ASSY 6D X 1975 LG	TATA spare parts
208542900123	TUBE ASSY 12D X 2370 LG	TATA spare parts
208542900125	ASSY PIPE 6 X 710 MM	TATA spare parts
208542900128	ASSY PIPE 15 X 1910	TATA spare parts
208542900148	ASSY.PIPE 12DIA.X 1 X 110 MM LG LP1312TC	TATA spare parts
208542900149	ASSY PIPE 12 DIA X 2034MM	TATA spare parts
208542900150	ASSY PIPE 12 DIA X 1640MM	TATA spare parts
208542900157	ASSY PIPE 12 DIA X 880 MM	TATA spare parts
208542900158	ASSY PIPE 12 DIA X 2200MM	TATA spare parts
208542900159	ASSY PIPE 12 DIA X 890 MM	TATA spare parts
208542900160	ASSY PIPE 6 DIA X 740 MM	TATA spare parts
208542900161	ASSY PIPE 6 DIA X 2035MM	TATA spare parts
208542900162	ASSY. TUBE 6DIA X 745 LONG LPT 1613TC	TATA spare parts
208542900163	ASSY PIPE 6 DIA X 2025 MM	TATA spare parts
208542900164	ASSY PIPE 15 DIA X 1800MM	TATA spare parts
208542900165	ASSY PIPE 15 DIA X 2760MM	TATA spare parts
208542900166	ASSY PIPE 15 DIA X 2820MM	TATA spare parts
208542900167	ASSY PIPE 15 DIA X 2370MM	TATA spare parts
208542900168	ASSY PIPE 15 X 1385 MM	TATA spare parts
208542900170	ASSY PIPE 12 DIA X 275 MM	TATA spare parts
208542900171	ASSY PIPE 12 DIA X 810 MM	TATA spare parts
208542900172	ASSY PIPE 12 DIA X 1195MM	TATA spare parts
208542900174	ASSY TUBE 15 DIA X 1480MM	TATA spare parts
208542900175	ASSY TUBE 15 DIA X 1570MM	TATA spare parts
208542900176	ASSY TUBE 15 DIA X 1930MM	TATA spare parts
208542900177	ASSY TUBE 15 DIA X 3130MM	TATA spare parts
208542900178	ASSY TUBE 12 DIA X 1520MM	TATA spare parts
208542900181	ASSY PIPE-15X2060 LG	TATA spare parts
208542900183	ASSY PIPE 12 DIA X 680 MM	TATA spare parts
208542900184	ASSY PIPE 15 DIA X 890 MM	TATA spare parts
208542900185	ASSY PIPE 18 DIA X 1070MM	TATA spare parts
208542900186	ASSY PIPE 6 X 790 MM	TATA spare parts
208542900187	ASSY TUBE 15 DIA X 2230MM	TATA spare parts
208542900188	ASSY TUBE 15 DIA X 2300MM	TATA spare parts
208542900189	ASSY PIPE 15 O.D. X 2150	TATA spare parts
208542900190	ASSY TUBE 12 DIA X 2200MM	TATA spare parts
208542900191	ASSY.TUBE WITH CRIMPED R/HOSE LPT1615TC	TATA spare parts
208542900198	ASSY.TUBE 12DIA X 190LG LPT1615TC	TATA spare parts
208542900199	ASSY.TUBE 12DIA X 1520LG LPT1615TC	TATA spare parts
208542903301	BRACKET	TATA spare parts
208542903310	BRACKET (L- SHAPE)	TATA spare parts
208542903314	BRACKET(U SHAPE)	TATA spare parts
208542903315	BRACKET (Z-SHAPE)	TATA spare parts
208542903317	L-BRACKET (FITTED FRONT SIDE OF ENGINE)	TATA spare parts
208542903318	L-BRACKET(FITTED AT REAR SIDE OF ENGINE)	TATA spare parts
208542903319	L-BRACKET	TATA spare parts

208542903320	BRACKET (ZFLASESHAPE) BS6-PH2	TATA spare parts
208542903321	BRACKET (Z-SHAPE)	TATA spare parts
208542903322	BRACKET (U-SHAPE)	TATA spare parts
208542903323	BRACKET (FOR HYD. CLUTCH LINE) (B)	TATA spare parts
208542910101	ASSY.TUBE 12DIAX1840LG LPT1615TC	TATA spare parts
208542910103	ASSY.TUBE 12DIAX1070LG LPT1615TC	TATA spare parts
208542910104	ASSY.TUBE 12DIAX2060LG LPT1615TC	TATA spare parts
208542910105	ASSY.TUBE 6DIAX1675LG LPT1615TC	TATA spare parts
208542910106	ASSY.TUBE 6DIAX1130LG LPT1615TC	TATA spare parts
208542910107	ASSY.TUBE 6DIAX1675LG LPT1615TC	TATA spare parts
208542910108	ASSY.TUBE 6DIAX1155LG LPT1615TC	TATA spare parts
208542910128	ASSY TUBE 15 OD X 3755 LONG LP1312TC	TATA spare parts
208542910131	ASSY. TUBE WITH CRIMPED R/HOSE COMPLETE	TATA spare parts
208542910132	ASSY. TUBE-12 O.D. X 915 LG.	TATA spare parts
208542910133	ASSY. TUBE-12 O.D. X 1250 LG.	TATA spare parts
208543100101	PIPE ASSY 6D X 610 LG	TATA spare parts
208543100102	PIPE 6 X 2200	TATA spare parts
208543100105	PIPE ASSY	TATA spare parts
208543100106	PIPE ASSY 6D X 585 LG	TATA spare parts
208543100107	PIPE 12 X 1245	TATA spare parts
208543100118	ASSY PIPE 6 DIA X 460 MM	TATA spare parts
208543100119	ASSY PIPE 6 DIA X 1170 MM	TATA spare parts
208543100126	ASSY. TUBE-6 O.D. X 495 LG.	TATA spare parts
208546800101	1/2INCH HOSE ASSY 450MM LONG	TATA spare parts
208546800102	ASSY PIPE 18 DIA X 625 LG	TATA spare parts
208546800103	ASSY PIPE 15 DIA X 1665LG	TATA spare parts
208546800107	HOSE ASSY	TATA spare parts
208546800108	ASSY HIGH PRESSURE HOSE	TATA spare parts
208546800109	ASSY. TUBE (18X900)	TATA spare parts
208546800110	ASSY. TUBE (15X925)	TATA spare parts
208546800113	HOSE ASSY	TATA spare parts
208546800116	ASSY TUBE W/ CRIMPED RUBBER HOSE	TATA spare parts
208546800117	ASSY TUBE W/ CRIMPED RUBBER HOSE	TATA spare parts
208547100102	PIPE 15 X 1620	TATA spare parts
208547100103	TUBE 10X860 LONG	TATA spare parts
208547100104	PIPE 10D X 1800	TATA spare parts
208547100105	TUBE 10D X 1110 LG	TATA spare parts
208547100106	FUEL SUCTION TUBE 1312	TATA spare parts
208547100109	TUBE ASSY 15D X 1445 LG	TATA spare parts
208547100110	TUBE ASSY 15D X 396 LG	TATA spare parts
208547100111	ASSY.PIPE 15 DIA.X 1196 M	TATA spare parts
208547100117	ASSY TUBE 15 DIA X 1520MM	TATA spare parts
208547100118	ASSY TUBE 10 DIA X 1620MM	TATA spare parts
208547100120	ASSY SUCTION LINE PA	TATA spare parts
208547100123	ASSY SUCTION LINE PA	TATA spare parts
208547100125	ASSY.TUBE WITH CRIMPED R/HOSE COMPLT.	TATA spare parts
208547100126	ASSY.TUBE WITH CRIMPED R/HOSE COMPLT.	TATA spare parts

208730100135	ASSY ACCELERATOR CABLE LPTA 713 TC	TATA spare parts
208730103309	BRACKET AT FIP LEVER	TATA spare parts
208732403202	CENTRE BOLT	TATA spare parts
208854229921	RPM METER 24V	TATA spare parts
208854229923	RPM METER 24V	TATA spare parts
208854229924	RPM METER 24V	TATA spare parts
208854309901	TEMP.TRANSDUCER-DOUBLE POLE	TATA spare parts
208881806301	MASCOT 1613 TC	TATA spare parts
208931000102	ASSY FRAME COMPLETE	TATA spare parts
208931200107	ASSY GUSSET-LH	TATA spare parts
208931200108	ASSY GUSSET-RH	TATA spare parts
208941110102	ASSY PROPELLER SHAFT FRONT	TATA spare parts
208941120102	ASSY PROPELLER SHAFT REAR	TATA spare parts
208949200102	BRACKET ASSY	TATA spare parts
208949203303	BRACKET EXH BRAKE UNIT	TATA spare parts
20910000003	RUBBER PAD (70X48)(GREY)	TATA spare parts
20910000024	RUBBER PAD 94X39 GREY	TATA spare parts
209124108601	SPACER	TATA spare parts
209124200101	ASSY.BRACKET ENGINE MTG.REAR ON FRAME	TATA spare parts
209124200102	ASSY. BRACKET (TOP) ENGINE MTG.REAR LH.	TATA spare parts
209124200103	ASSY.BRACKET ENGINE MTG. REAR-LH	TATA spare parts
209124200104	ASSY. BKT (TOP) RH.	TATA spare parts
209126800104	ASSY.BRACKET	TATA spare parts
209126800107	ASSY. BRACKET	TATA spare parts
209126800110	ASSY. TURNING TUBE	TATA spare parts
209129100101	ASSY. BRACKET-FOR SLAVE CYL. MTG.	TATA spare parts
209129100102	ASSY. TUBE WITH LEVER	TATA spare parts
209129100103	ASSY. PULL ROD	TATA spare parts
209129106003	CLUTCH RELEASE LEVER	TATA spare parts
209129106701	PIN	TATA spare parts
209129500102	ASSY. BRACKET-MASTER CYL.MTG.	TATA spare parts
209129500103	ASSY.PEDAL SUPPORT WITH TUBE	TATA spare parts
209130200101	ASSY.STOP CABLE(COMPL)	TATA spare parts
209131200102	ASSY. SHOCK ABSORBER C.M	TATA spare parts
209131207105	SUPPORT,RH	TATA spare parts
209131207106	SUPPORT,LH	TATA spare parts
209131207107	REINFORCEMENT-RH	TATA spare parts
209131207108	REINFORCEMENT-LH	TATA spare parts
209131207109	CROSS MEMBER.	TATA spare parts
209131207110	CROSS MEMBER-REAR SPRING	TATA spare parts
209131207111	SUPPORT-TOP	TATA spare parts
209131207112	SUPPORT -LH-ENG. CM FRONT	TATA spare parts
209131207113	SUPPORT - RH-ENG C.M. FRONT	TATA spare parts
209131207114	PLATE	TATA spare parts
209131207115	PLATE	TATA spare parts
209131307103	REINFORCEMENT-FRONT-RH(BOTTOM)	TATA spare parts
209131307104	REINFORCEMENT-FRONT-LH(BOTTOM)	TATA spare parts

209131307105	REINFORCEMENT RH.	TATA spare parts
209131307106	REINFORCEMENT LH.	TATA spare parts
209131307107	REINFORCEMENT REAR R.H (BOTTOM)	TATA spare parts
209131307108	REINFORCEMENT REAR L.H (BOTTOM)	TATA spare parts
209132100103	ASSY FRRONT SPRING HIGH CAMBER	TATA spare parts
209132100104	ASSY FIRST LEAF WITH BUSH	TATA spare parts
209132100105	ASSY FRONT SPRING	TATA spare parts
209132100107	ASSY FIRST LEAF WITH BUSH	TATA spare parts
209132100108	ASSY FRONT SPRING(HIGH CAMBER)	TATA spare parts
209132107102	SECOND LEAF	TATA spare parts
209132107103	THIRD LEAF	TATA spare parts
209132107104	FOURTH LEAF	TATA spare parts
209132107105	FIFTH LEAF	TATA spare parts
209132107106	SIXTH LEAF	TATA spare parts
209132107107	SEVENTH LEAF	TATA spare parts
209132107108	EIGHTH LEAF	TATA spare parts
209132107109	NINTH LEAF	TATA spare parts
209132107110	TENTH LEAF	TATA spare parts
209132107111	ELEVENTH LEAF	TATA spare parts
209132107112	TWELEVETH LEAF	TATA spare parts
209132107125	PACKING PLATE	TATA spare parts
209132107127	SECOND LEAF	TATA spare parts
209132107128	THIRD LEAF	TATA spare parts
209132107129	FOURTH LEAF	TATA spare parts
209132107130	FIFTH LEAF	TATA spare parts
209132107131	SIXTH LEAF	TATA spare parts
209132107132	SEVENTH LEAF	TATA spare parts
209132107133	EIGHTH LEAF	TATA spare parts
209132107134	NINTH LEAF	TATA spare parts
209132107135	TENTH LEAF	TATA spare parts
209132107136	ELEVENTH LEAF	TATA spare parts
209132107137	TWELVTH LEAF	TATA spare parts
209133000101	ASSY FRONT AXLE -4018 3516 2516	TATA spare parts
209143200101	ASSY. AIR TANK	TATA spare parts
209143200102	ASSY. AIR TANK	TATA spare parts
209146100101	ASSY BKT STEERING G.B.MTG.	TATA spare parts
209146207902	STEERING SPINDLE-BOTTOM	TATA spare parts
209146207905	STEERING SPINDLE (BOTTOM) 1/713 VFJ	TATA spare parts
209149200101	BRACKET COMPLETE	TATA spare parts
209149203302	SUPPORT BRACKET-EXH. BRAKE	TATA spare parts
209154200101	AIR CYL W/MAGNETIC VALVE	TATA spare parts
209154200102	AIR CYL W/MAGNETIC VALVE	TATA spare parts
209154200103	AIR CYL W/MAGNETIC VALVE	TATA spare parts
209154500101	ASSY.PIANO KEY SWITCH.	TATA spare parts
209154509901	BATTERY CUT OFF SWITCH	TATA spare parts
209154509902	BATTERY CUT OFF SWITCH	TATA spare parts
209181900101	ASSY. ENGINE SHIELDING LH RHD	TATA spare parts

209189100101	ASSY.BRACKET LH RHD COWL MTG. BKT.	TATA spare parts
209189100103	ASSY. BRACKET LH-COWL MTG. REAR	TATA spare parts
209189100104	ASSY. BRACKET RH-COWL MTG. REAR	TATA spare parts
209260000101	ASSY BARE CAB LPT 1109	TATA spare parts
209260000102	ASSY CAB COMPLETE	TATA spare parts
209326800102	ASSY TURNING TUBE	TATA spare parts
209329300101	ASSY BRACKET	TATA spare parts
209330100101	ASSY LEVER	TATA spare parts
209330100104	ASSY CONTROL SHAFT	TATA spare parts
209330100105	ASSY PULL ROD	TATA spare parts
209330100106	ASSY PULL CABLE ACCELERATOR 1771MM	TATA spare parts
209330100107	BRACKET - CABLE MOUNTING	TATA spare parts
209330103302	BRACKET	TATA spare parts
209330103303	BRACKET	TATA spare parts
209330200101	ENGINE STOP CABLE	TATA spare parts
209330200103	ENGINE STOP CABLE	TATA spare parts
209331000102	FRAME ASSY COMP	TATA spare parts
209331200103	ASSY. REINFORCEMENT BRACKET LH	TATA spare parts
209331200104	ASSY. REINFORCEMENT BRACKET RH	TATA spare parts
209331200105	ASSY. SUPPORT (REAR) LH	TATA spare parts
209331200106	ASSY. SUPPORT (REAR) RH	TATA spare parts
209331200107	ASSY.ENG.X-MEMB. REAR	TATA spare parts
209331200108	ASSY. SUPPORT (FRT) LH	TATA spare parts
209331200109	ASSY. SUPPORT (FRT) RH	TATA spare parts
209331200112	ASSY. BUMPER C/M (FRONT)W/TOWING HOOK	TATA spare parts
209331207105	REINFORXEMENT R.H	TATA spare parts
209331207106	REINFORCEMENT R.H	TATA spare parts
209331207107	REINFORCEMENT L.H	TATA spare parts
209331207108	REINFORCEMENT L.H	TATA spare parts
209331207118	SUPPORT BRACKET FRONT LH BS6	TATA spare parts
209331207119	SUPPORT BRACKET FRONT RH BS6	TATA spare parts
209331207120	SUPPORT LH	TATA spare parts
209331207121	SUPPORT LH (TOP FLANGE)	TATA spare parts
209333000101	ASSY. FRONT AXLE 1009 W BRAKES	TATA spare parts
209333000102	ASSY.FRT.AXLE WITH S-CAM BRK.SPIG.COMPL	TATA spare parts
209335000102	ASSY.REAR AXLE COMPL.WITH BRAKE LPT 1009	TATA spare parts
209335000106	ASSY.REAR AXLE COMPL.WITH BRAKE LPT 1109	TATA spare parts
20933XX0001	WHEEL ARCH BEADING WITH METAL(L=2300)	TATA spare parts
209341110101	ASSY PROP SHAFT FRT W/CB	TATA spare parts
209342100106	BRAKE CHAMBER	TATA spare parts
209342100113	FLANGE TUBE & BKT.ASSY.FLH	TATA spare parts
209342100114	FLANGE TUBE & BKT.ASSY.FRH	TATA spare parts
209342100115	LINED SHOE LH & RH LPT 1109	TATA spare parts
209342100118	KIT-LINING SET(STD) LPT1109	TATA spare parts
209342100119	KIT-LINING SET(R/S I) LPT1109	TATA spare parts
209342100120	KIT-LINING SET(R/S II) LPT1109	TATA spare parts
209342103701	TORQUE PLATE FLH	TATA spare parts

209342103702	TORQUE PLATE FRH	TATA spare parts
209342109203	WASHER 2.5MM	TATA spare parts
209342109204	WASHER 1.5 MM	TATA spare parts
209342300101	ASSY BRACKET LH	TATA spare parts
209342300102	ASSY BRACKET RH	TATA spare parts
209342300104	SPRING BRAKE ACTUATOR	TATA spare parts
209342300111	ACTUATOR REPAIR KIT LPT 1009	TATA spare parts
209342300112	SPR.BRK ACTUATOR WITH ADAPTOR LPT 1109	TATA spare parts
209342300112AE	SPRNG BRK ACTR W/ADPT(12/12)-715	TATA spare parts
209342300113	SLACK ADJUASTER REAR RH	TATA spare parts
209342300114	SLACK ADJUSTER LPT1109	TATA spare parts
209342303701	TORQUE PLATE RH/LH	TATA spare parts
209342305103	S CAMSHAFT¿ LH	TATA spare parts
209342305104	S CAMSHAFT¿ RH	TATA spare parts
209342308601	SLEEVE (SLACK ADJ.END) DELRIN	TATA spare parts
209342700105	ASSY. PIPE 12 DIA X 465 LONG LPT 1109	TATA spare parts
209342700121	ASSY.PIPE 12DIA X 400MM LG LPT 1109	TATA spare parts
209342900116	ASSY PIPE 15DIA X 385 LG	TATA spare parts
209342900117	ASSY PIPE 15DIA X 520 LG	TATA spare parts
209342900124	ASSY. PIPE	TATA spare parts
209342900125	ASSY PIPE-15 DIA.X1644 LG	TATA spare parts
209342900149	NYLON PIPE AIR DRYER TO SPV 1109 TC	TATA spare parts
209342900150	ASSY.TUBE SPV FRONT TO AIR TANK	TATA spare parts
209342900152	NYLON TUBE (DTV TO FRT.BRK.CH.TEE)1109	TATA spare parts
209342900153	NYLON TUBE (TEE TO FRONT BRK.CH.RH)1109	TATA spare parts
209342900155	ASSY TUBE-REAR AIR TANK TO DTV	TATA spare parts
209342900159	ASSY TUBE-SPV 24 TO EXHAUST BRK CYLINDER	TATA spare parts
209342900164	TUBE ASSY TEE TO REAR BRAKE CHAMBER 1109	TATA spare parts
209342900166	ASSY NYLON PIPE SET 1109 TC	TATA spare parts
209342900167	ASSY BRAKE PIPE LPT1109	TATA spare parts
209342903302	BRACKET BS6	TATA spare parts
209346108001	HEX SCREW	TATA spare parts
209346108002	HEX SCREW (STRG GEAR BOX TO BRACKET)	TATA spare parts
209346108003	HEX SCREW (STRG GEAR BOX TO BRACKET)	TATA spare parts
209346200103	ASSY BRACKET FOR POWER STG.	TATA spare parts
209346200106	ASSY BRACKET LPT1109	TATA spare parts
209346200108	STEERING GEAR ASSY WITH PITMAN ARM & U-J	TATA spare parts
209346207109	SPACER PLATE	TATA spare parts
209346306002	PITMAN ARM	TATA spare parts
209346306003	PITMAN ARM	TATA spare parts
209346400102	STRG WHEEL 475 DIA	TATA spare parts
209346600102	ASSY DRAG LINK	TATA spare parts
209346600103	ASSY DRAG LINK LPT1109	TATA spare parts
209346600104	STG GEAR BOX	TATA spare parts
209346600105	U J ASSY	TATA spare parts
209347100102	ASSY.FUEL TANK COMPLETE LPT 1109	TATA spare parts
209347600103	ASSY PIPE	TATA spare parts

209347600104	ASSY PIPE	TATA spare parts
209347600105	PIPE ASSY LPT1109	TATA spare parts
209349200101	ASSY EXHAUST PIPE FRONT	TATA spare parts
209349200106	ASSY EXHAUST PIPE INTERMEDIATE	TATA spare parts
209354400101	ASSY.LAMP WARNING IND.	TATA spare parts
209354820101	ASSY MAIN CABLE SET RHD	TATA spare parts
209354820102	ASSY CABLE SET FRT TO TAIL	TATA spare parts
209360000101	ASSY BARE CAB LPT 1009	TATA spare parts
209360000102	ASSY CAB COMP. LPT 1009	TATA spare parts
209368908201	INSTRUMENT PANEL RHD LPT 1009	TATA spare parts
209370000101	ASSY LOAD BODY COMPLETE LPT1109	TATA spare parts
209370000102	ASSY LOAD BODY HIGH DECK	TATA spare parts
209370000103	ASSY. LOAD BODY COMP LPT1109	TATA spare parts
209370000104	ASSY LOAD BODY HIGH DECK	TATA spare parts
209370000105	KIT ASSY. LOADBODY COMPLETE	TATA spare parts
209370100107	ASSY.LONG RUNNER RH 36 WB	TATA spare parts
209370100108	ASSY.LONG RUNNER LH 36 WB	TATA spare parts
209370100113	ASSY. MUDGUARD -RH REAR	TATA spare parts
209370100114	ASSY. MUDGUARD -LH REAR	TATA spare parts
209370100117	ASSY.SUPPORT	TATA spare parts
209370100126	ASSY. FLOOR WELDED COMPLETE	TATA spare parts
209370200101	ASSY FRONT PANEL COMPL W/LOADGUARD 909	TATA spare parts
209370200104	ASSY. FRONT PANEL	TATA spare parts
209370300101	ASSY SIDE PANEL LH	TATA spare parts
209370300102	ASSY SIDE PANEL RH	TATA spare parts
209370400101	ASSY TAIL GATE 1109/1009	TATA spare parts
209370400103	ASSY. TAIL GATE.	TATA spare parts
209370813204	U-CLAMP BS6	TATA spare parts
209370817101	PLATE	TATA spare parts
209381806301	MASCOT 1009	TATA spare parts
209388500103	ASSY BUMPER COMPLETE LPT1109	TATA spare parts
209388500104	ASSY.END COVER RH-BUMPER	TATA spare parts
209531500103	ASSY. TOWING HOOK	TATA spare parts
209531500108	ASSY REAR TOWING HOOK	TATA spare parts
209556300104	ASSY CENTRE BRG COMPL	TATA spare parts
209642900104	ASSY. TUBE-15 O.D. X 910 LG.	TATA spare parts
209642900105	ASSY.NYLON PIPE SET COMP LP 1510	TATA spare parts
209642900122	ASSY NYLON PIPE SET SK1613/36CMVR2K	TATA spare parts
209642900123	ASSY. TUBE (15 O.D. X 4450 LG.)	TATA spare parts
209642900124	ASSY NYLON PIPE SET LPT1613/42 CMVR 2K	TATA spare parts
209642900160	ASSY.RUBBER HOSE CRIMPED.	TATA spare parts
209642900161	ASSY.RUBBER HOSE CRIMPED.	TATA spare parts
209642900168	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
209642903303	Z-BRACKET-NYLON BRAKE PIPES JUNCTION	TATA spare parts
209642910101	ASSY TUBE DIA 15 X 4420 LG.	TATA spare parts
209642910137	ASSY.NYLON PIPE SET COMPLETE.	TATA spare parts
209642910155	SET NYLON PIPES W/ EXH. BRAKE LINES	TATA spare parts



209642910161	ASSY.NYLON PIPE SET COMPLETE.	TATA spare parts
209642940136	ASSY.NYLON PIPE COMPLETE LPO 1316/55 TC	TATA spare parts
209643900101	ASSY TUBE(15 O.D. X 450 LG)	TATA spare parts
209643900102	ASSY TUBE(15 O.D. X 2800 LG)	TATA spare parts
209643900103	ASSY TUBE(15 O.D. X 2850 LG)	TATA spare parts
209643900129	SET ASSY NYLON PIPE COML(TF/NPA/215A)	TATA spare parts
209643910111	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
209643910115	ASSY PIPE WITH CRIMPED HOSE (AIR DUCT TO	TATA spare parts
209643910146	ASSY.NYLON PIPE SET W/VOSS CONN.	TATA spare parts
209643910147	ASSY.NYLON PIPE SET COMP.W/VOSS CONN	TATA spare parts
209643920109	ASSY.NYLON PIPE SET COMPT.	TATA spare parts
209646150129	KIT ASSY. PIPES	TATA spare parts
209646150144	KIT ASSY.STRG PIPES	TATA spare parts
209646150148	KIT ASSY PIPES LPO1316TC/LHD(JSR)	TATA spare parts
209646150152	KIT ASSY PIPES LPT2515TC	TATA spare parts
209646150153	KIT ASSY PIPES LPT2515TC	TATA spare parts
209646150163	KIT ASSY PIPES(TAURUS)LPS3516TC	TATA spare parts
209646150165	KIT ASSY PIPES LPK2516TC	TATA spare parts
209646150167	KIT ASSY PIPES LPK2516TC	TATA spare parts
209646150169	KIT ASSY PIPSE TAU NIPP LPS3516TC/32	TATA spare parts
209646150171	KIT ASSY PIPES(TAU NIPP)LPT1613CMVR	TATA spare parts
209646150173	KIT ASSY PIPES(TAU NIPP)LPT1613CMVR	TATA spare parts
209646150175	KIT ASSY PIPES(TAU NIPP)LPO1512TC	TATA spare parts
209646150176	KIT ASSY PIPES(TAU NIPP)LPO1512TC	TATA spare parts
209646150178	KIT ASSY PIPES(TAU NIPP)LPT1613TC	TATA spare parts
209646150180	KIT ASSY PIPES (TAU NIPP)LPT1613	TATA spare parts
209646150182	KIT ASSY PIPELINES&CONNECTORS	TATA spare parts
209646150188	KIT ASSY PIPES & CONNECTORS	TATA spare parts
209646150196	KIT ASSY P/STG.LINE & CONNECTOR M/S TF	TATA spare parts
209646160102	KIT ASSY.P/STG.PIPE LINES & CONN.	TATA spare parts
209646160104	KIT ASSY.P/STG.PIPE LINES & CONNECTOR	TATA spare parts
209646800101	ASSY TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
209646800102	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
209646800103	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
209646800104	NOT VALID IN MASTER PRESENT IN STRUCTURE	TATA spare parts
209646800115	SUCTION LINE HOSE ASSY	TATA spare parts
209646800116	PR.LINE HOSE ASSY	TATA spare parts
209646800117	RETURNLINE HOSE ASSY	TATA spare parts
209646800118	RETURNLINE HOSE ASSY	TATA spare parts
209646800119	PR.LINE HOSE ASSY	TATA spare parts
209646800126	SUCTION LINE HOSE ASSY TANK TO PUMP	TATA spare parts
209646800127	PR LINE HOSE ASSY	TATA spare parts
209646800128	RETURN LINE HOSE ASSY	TATA spare parts
209646800129	RETURN LINE HOSE ASSY	TATA spare parts
209646800130	SUCTION LINE HOSE ASSY. (TANK TO PUMP)	TATA spare parts
209646800131	PRESSURE LINE HOSE ASSY. (STRG GEAR BOX	TATA spare parts
209646800133	RETURN LINE HOSE ASSY. (STRG TANK TO STR	TATA spare parts

209646800134	RETURN LINE HOSE ASSY.	TATA spare parts
209646800135	RETURN LINE HOSE ASSY.	TATA spare parts
209647600116	ASSY. TUBE-10 O.D. X 2675 LG.	TATA spare parts
209647600117	ASSY. TUBE-10 O.D. X 2445 LG.	TATA spare parts
209647600118	ASSY. TUBE-10 O.D. X 2965 LG.	TATA spare parts
209647600119	ASSY.TUBE DIA-10 O.D X 1475 LG.	TATA spare parts
209647600120	ASSY TUBE DIA-10 OD X 2010 LG	TATA spare parts
209647600121	ASSY.TUBE 10 O.D X 2246 LG.	TATA spare parts
209647600122	ASSY. TUBE-10 O.D. X 2150 LG.	TATA spare parts
209647600138	ASSY.TUBE WITH CRIMPED RUBBER HOSE.	TATA spare parts
209647600139	ASSY.TUBE WITH CRIMPED R/HOSE.	TATA spare parts
209647600140	ASSY.TUBE WITH CRIMPED R/HOSE.	TATA spare parts
209647600141	ASSY FUEL LINE-TANK TO WATER SEP.	TATA spare parts
209647600142	ASSY FUEL LINE-WATER SEP. TO HOSE	TATA spare parts
209647600143	ASSY RETURN LINE	TATA spare parts
209647600153	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
209647600154	ASSY.TUBE W/CRIMPED R/HOSE.(SUCTION PORT	TATA spare parts
209647600155	ASSY.TUBE WITH CRIMPED R/HOSE.	TATA spare parts
209647600156	ASSY.TUBE W/CRIMPED R/HOSE(W/SEPARATOR T	TATA spare parts
209647600157	ASSY.TUBE WITH CRIMPED R/HOSE.	TATA spare parts
209647600158	ASSY.TUBE W/CRIMPED R/HOSE(FEED PUMP TO	TATA spare parts
209647600159	ASSY.TUBE W/CRIMPED R/HOSE(OVERFLOW LINE	TATA spare parts
209647600160	ASSY.TUBE WITH CRIMPED R/HOSE.	TATA spare parts
209647600161	ASSY.TUBE WITH CRIMPED R/HOSE.	TATA spare parts
209724200103	ASSY ENG MTG BKT REAR RH	TATA spare parts
209724200104	ASSY ENG MTG BKT REAR LH	TATA spare parts
209724200105	ASSY.ENGINE MOUNTING BRACKET REAR RH	TATA spare parts
209726000101	ASSY G600-6/8.47 DIR/SHIFT WITH PTO PROV	TATA spare parts
209726100101	ASSY G600-6/8.47 DIR/SHIFT WITH PTO(APP)	TATA spare parts
209728400101	ASSY LINK ROD	TATA spare parts
209728400103	ASSY LINK ROD (FOR AGB)SA1212	TATA spare parts
209728400104	ASSY LINK ROD (FOR AGB)SAK1212	TATA spare parts
209728400105	ASSY LINK ROD(FOR AGB SHIFTING)	TATA spare parts
209728500101	SET PART FOR BEARING LOWER & UPPER HALF	TATA spare parts
209729100104	CLUTCH PEDAL ASSY WITH BUSH BS6	TATA spare parts
209729300102	BUNDY TUBE ASSY	TATA spare parts
209729300103	BUNDY TUBE ASSY BS6	TATA spare parts
209729300104	BUNDY TUBE ASSY BS6	TATA spare parts
209729300106	CLUTCH MASTER CYLINDER WITH RESERVOIR BS	TATA spare parts
209729300107	MAJOR KIT-MASTER CYLINDER BS6	TATA spare parts
209729300108	MINOR KIT-MASTER CYLINDER BS6	TATA spare parts
209729300109	BUNDY TUBE ASSY BS6	TATA spare parts
209731000101	ASSY FRAME COMPLETE	TATA spare parts
209731000103	ASSY FRAME SAK1212/32 TC RTH ST. BUMPER	TATA spare parts
209731000106	ASSY FRAME COMPL SAK1212/32 CURV BUMPER	TATA spare parts
209731000110	ASSY FRAME SA 1212/42 TC RTH WITH BUMPER	TATA spare parts
209731000117	ASY FRM COMPL WITH STG BKT(CURVED BUMPER	TATA spare parts

209731000127	ASSY.FRAME-COMPL-SA1212-BS-II/42	TATA spare parts
209731000129	ASSY.FRAME COMPLETE-SA1212(FOR S-CAM)	TATA spare parts
209731000130	ASSY FRAME-COMPL	TATA spare parts
209731000131	ASSY FRAME-COMplete	TATA spare parts
209731000142	FRAME ASSY WITH FITMENT BS6	TATA spare parts
209731200103	ASSY 3RD CROSS MEMBER	TATA spare parts
209731200104	ASSY 3RD CROSS MEMBER	TATA spare parts
209731200105	ASSY. CROSS MEMBER	TATA spare parts
209731200106	ASSY CROSS MEMBER - AUX. GEARBOX	TATA spare parts
209731200111	ASSY. AGB CROSS MEMBER	TATA spare parts
209731200114	C-CHANNEL ASSY BS6	TATA spare parts
209731200117	CROSS MEMBER ASSY ENGINE MTG REAR BS6	TATA spare parts
209731200118	SUPPORT ASSY ENGINE CROSS MEMBER REAR BS	TATA spare parts
209731200121	CROSS MEMBER ASSY AGB MTG BS6	TATA spare parts
209731200128	CROSS MEMBER ASSY 3RD BS6	TATA spare parts
209731207106	REINFORCEMENT	TATA spare parts
209731207108	CROSS MEMBER 3RD BS6	TATA spare parts
209731207112	REINFORCEMENT BOTTOM-RH BS6	TATA spare parts
209731207120	REINFORCEMENT BOTTOM-RH BS6	TATA spare parts
209731207134	REINFORCEMENT FRONT-RH BS6	TATA spare parts
209731207135	REINFORCEMENT FRONT-LH BS6	TATA spare parts
209731208202	GUSSET PLATE L.H	TATA spare parts
209731208203	GUSSET PLATE R.H.	TATA spare parts
209731208205	CROSS MEMBER (REAR SPRING)	TATA spare parts
209731540104	BRACKET ASSY BATTERY TRAY MTG BS6	TATA spare parts
209731540105	BRACKET ASSY BATTERY TRAY MTG BS6	TATA spare parts
209731540106	BATTERY SUPPORT ASSY BS6	TATA spare parts
209731700101	ASSY.REAR UNDERRUN PROTECTIVE DEVICE	TATA spare parts
209731700121	ASSY BRACKET-RH (AGB.SHIELD MTG.)	TATA spare parts
209731700134	ASSY BKT COMPLTE FUPD RH	TATA spare parts
209731700137	ASSY BKT COMPLTE FUPD LH	TATA spare parts
209731708221	REINFORCEMENT FRAME FUPD LH	TATA spare parts
209731708222	REINFORCEMENT FRAME FUPD-RH	TATA spare parts
209740200105	TUBE AND VALVE ASSY.	TATA spare parts
209740206303	9.00-20 12PR TYRE	TATA spare parts
209740206304	FLAP FOR 9.00-20 TYRE	TATA spare parts
209740300102	ASSY SPARE WHEEL CARRIER	TATA spare parts
209740300106	BRACKET ASSY BS6	TATA spare parts
209740308601	SPACER	TATA spare parts
209740999001	EXTENDER FOR AIR FILLING NOZZLE	TATA spare parts
209741100101	ASSY PROP SHAFT REAR 55 X 75 DIA	TATA spare parts
209741100103	ASSY. PROPELLER SHAFT COMPLETE (GEAR BOX	TATA spare parts
209741100106	ASSY PROPELLER SHAFT COMPLETE-FRONT	TATA spare parts
209741100109	ASSY PROP SHAFT COMPLETE-REAR.	TATA spare parts
209741100114	ASSY PROP SHAFT(GB TO AGB)	TATA spare parts
209741100116	PROPELLER SHAFT ASSY. (AGB TO RA)	TATA spare parts
209741100117	PROPELLER SHAFT ASSY. (AGB TO FA)	TATA spare parts

209741100123	CROSS ASSY.	TATA spare parts
209741100125	PROPELLER SHAFT ASSY (GB TO AGB)	TATA spare parts
209741100126	PROPELLER SHAFT ASSY. (AGB TO RA)	TATA spare parts
209741100127	PROPELLER SHAFT ASSY.(AGB TO FA)	TATA spare parts
209741100132	PROPELLER SHAFT COMPLETE (GB TO AGB)	TATA spare parts
209741100135	LONG FORK SUB ASSY	TATA spare parts
209741100136	SHORT FORK TUBE & REAR HOUSING ASSY. (AG	TATA spare parts
209741100137	SHORT FORK TUBE & REAR HOUSING ASSY. (AG	TATA spare parts
209741109902	PROPELLER SHAFT TUBE ASSY BS6	TATA spare parts
209741120118	PROPELLER SHAFT ASSY GB TO AGB BS6	TATA spare parts
209741120119	PROPELLER SHAFT ASSY AGB TO REAR AXLE BS	TATA spare parts
209741129901	SHORT FORK TUBE ASSY GB TO AGB BS6	TATA spare parts
209741129902	SHORT FORK ASSY AGB TO REAR AXLE BS6	TATA spare parts
209741129903	LONG FORK ASSY GB TO AGB BS6	TATA spare parts
209742100101	BRACKET ASSY ABS SENSOR MTG	TATA spare parts
209742100103	BRAKE ASSY FRONT LH	TATA spare parts
209742100104	BRAKE ASSY FRONT RH	TATA spare parts
209742100105	LINED SHOE ASSY	TATA spare parts
209742100110	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
209742100111	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
209742103304	BRACKET ABS SENSOR MTG	TATA spare parts
209742107501	GROMMET FRONT SENSOR CABLE	TATA spare parts
209742109901	POLE WHEEL	TATA spare parts
209742109904	KIT BUSH(ABS)	TATA spare parts
209742109909	KIT TORQUE PLATE ASSY	TATA spare parts
209742109910	KIT TORQUE PLATE ASSY	TATA spare parts
209742109911	KIT BRACKET ASSY	TATA spare parts
209742800104	ASSY.TUBE (950 LG.)(FROM AIR CYL./M CYL.	TATA spare parts
209742800105	ASSY.TUBE (2375 LG.)(FROM 3-WAY UNION TO	TATA spare parts
209742800106	ASSY.TUBE(1930 LG.)(FROM 3-WAY UNION TO	TATA spare parts
209742800108	ASSY.TUBE (4140 LG.)(FROM AIR CYL./M CYL	TATA spare parts
209742900120	ASSY.TUBE.(2870 LG.)(FROM AIR COMP 4TH P	TATA spare parts
209742900121	ASSY.TUBE.(1930 LG.) (FROM AIR COMP 5TH	TATA spare parts
209742900127	ASSY.TUBE (330 LG.)	TATA spare parts
209742900132	SET ASSY NYLON PIPE COPL	TATA spare parts
209742900133	SET ASSY NYLON PIPE COMPL	TATA spare parts
209743200101	ASSY DDU MTG. BKT	TATA spare parts
209743200104	ASSY AIR CONTAINER(SUITABLE FOR VOSS)	TATA spare parts
209743200107	ASSY BRACKET-RH AIR TANK MTG	TATA spare parts
209743200108	ASSY BRACKET-LH AIR TANK MTG	TATA spare parts
209743200115	AIR TANK ASSY BS6	TATA spare parts
209743700118	BRACKET ASSY BS6	TATA spare parts
209743700119	SPRING BRAKE ACTUATOR BS6	TATA spare parts
209743700131	GRADUATED HAND CONTROL VALVE	TATA spare parts
209743700132	BRACKET ASSY MODULATOR VALVE MTG FRT	TATA spare parts
209743700133	BRACKET ASSY MODULATOR VALVE MTG REAR	TATA spare parts
209743703303	BRACKET QRV MTG	TATA spare parts

209743900105	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
209743900106	ASSY NYLON PIPE WITH VOSS FITTING	TATA spare parts
209743900108	ASY NYL PIPE WITH CLUTCH BOOSTER	TATA spare parts
209743900120	ASSY. COMPRESSOR 1ST PIPE WITH HOSE	TATA spare parts
209743900121	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
209743900122	ASSY. COMPRESSOR 3RD PIPE	TATA spare parts
209743900123	ASSY. COMPRESSOR 4TH PIPE	TATA spare parts
209743900124	ASSY 1ST COMP OUTLET PIPE	TATA spare parts
209743900125	ASSY 2ND COMP OUTLET PIPE	TATA spare parts
209743900126	ASSY 3RD COMP OUTLET PIPE	TATA spare parts
209743900136	PIPE BUNCH ASSY	TATA spare parts
209743900155	BUNCH PIPE ASSY	TATA spare parts
209743900177	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
209743900178	METAL PIPE ASSY JOINT 2 TO DDU	TATA spare parts
209743900179	METAL PIPE ASSY JOINT 1 TO JOINT 2	TATA spare parts
209743910102	ASSY NYLON PIPE BUNCH	TATA spare parts
209743910103	ASSY NYLON PIPE BUNCH	TATA spare parts
209743910110	PIPE ASSY	TATA spare parts
209743910116	METAL PIPE ASSY. JOINT 1 TO JOINT 2	TATA spare parts
209743910117	METAL PIPE ASSY JOINT 2 TO DDU	TATA spare parts
209743910120	PIPE ASSY.BUNCH COMPLETE	TATA spare parts
209743910134	BUNCH PIPE ASSY	TATA spare parts
209743910151	BUNCH PIPE ASSY BS6	TATA spare parts
209743910158	METAL PIPE ASSY BS6	TATA spare parts
209743910170	PIPE ASSY BS6	TATA spare parts
209743920140	PIPE BUNCH ASSY BS6	TATA spare parts
209745207107	BRACKET BS6	TATA spare parts
209746050101	ASSY DRAG LINK SA1212 VRSTG	TATA spare parts
209746300101	DRAGLINK END ASSY BS6	TATA spare parts
209746356001	PITMAN ARM	TATA spare parts
209746600101	BRACKET ASSY STG GEAR BOX MTG BS6	TATA spare parts
209746900104	DRAG LINK ASSY FRONT BS6	TATA spare parts
209746900105	SUCTION LINE HOSE ASSY	TATA spare parts
209746900106	PRESSURE LINE ASSY	TATA spare parts
209746900107	RETURN LINE ASSY	TATA spare parts
209746990102	KIT P/STG LINE & CONNECTOR BSIII	TATA spare parts
209747500101	BRACKET ASSY	TATA spare parts
209747600103	ASSY.TUBE (2064 LG.)	TATA spare parts
209747600104	ASSY.TUBE.(1077 LG.)	TATA spare parts
209747600105	HOSE ASSY-MAIN LINE	TATA spare parts
209747600106	HOSE ASSY-MAIN LINE	TATA spare parts
209747600107	HOSE ASSY-RETURN LINE	TATA spare parts
209747600109	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
209747600112	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
209747600113	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
209747600114	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
209747600115	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts

209747600116	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
209747600117	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
209747600118	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
209747600119	BRACKET ASSY BS6	TATA spare parts
209747600120	SUCTION PIPE ASSY FUEL TANK TO FILTER BS	TATA spare parts
209747700101	FUEL W/SEP WITH HEAD & HEATER ASSY	TATA spare parts
209747700102	BRACKET ASSY FUEL FILTER MTG	TATA spare parts
209747709901	HEAD WITH PRIMING PUMP & HEATER	TATA spare parts
209747900105	ASSY FUEL LINE	TATA spare parts
209747900106	ASSEMBLY FUEL LINE	TATA spare parts
209747900110	HOSE ASSY-MAIN LINE	TATA spare parts
209747900111	HOSE ASSY-RETURN LINE	TATA spare parts
209749100103	STAY ROD ASSY BS6	TATA spare parts
209749100105	ASST SILENCER WITH TAIL PIPE	TATA spare parts
209749100106	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
209749200101	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
209749200102	ASSY SILENCER WITH TAILPIPE	TATA spare parts
209749200103	EXHAUST PIPE ASSY INT	TATA spare parts
209749200105	BRACKET ASSY EGP MTG	TATA spare parts
209749200106	BRACKET ASSY EGP MTG	TATA spare parts
209749200108	ASSY PIPE (INTERMEDIATE TO SILENCER)	TATA spare parts
209749200108AE	ASSY PIPE (INTER T SILNCR) -1415	TATA spare parts
209749200109	ASSY.PIPE (INTERMEDIATE TO SILENCER)	TATA spare parts
209749200111	ASSY.J BRACKET	TATA spare parts
209749200112	ASSY.J BRACKET	TATA spare parts
209749200113	BRACKET ASSY EGP MTG	TATA spare parts
209749200114	ASSY. J BRACKET	TATA spare parts
209749200119	ASSY EXHAUST PIPE (FRONT)	TATA spare parts
209749200131	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
209749200134	STAY ROD ASSY BS6	TATA spare parts
209749200136	EXHAUST PIPE ASSY WITH BELLOW BS6	TATA spare parts
209749200140	STRUCTURE ASSY BS6	TATA spare parts
209749200142	BASE PLATE EGP MTG BKT ASSY BS6	TATA spare parts
209749200144	BRACKET ASSY STAY ROD MTG BS6	TATA spare parts
209749200145	SUCTION LINE TANK TO SM BS6	TATA spare parts
209749200146	BRACKET ASSY BS6-PH2	TATA spare parts
209749200149	BRACKET ASSY UREA TANK MTG BS6	TATA spare parts
209749200150	RETURN LINE DM TO TANK BS6	TATA spare parts
209749200151	PRESSURE LINE SM TO DM BS6	TATA spare parts
209749200153	DEF TANK ASSY BS6 BS6	TATA spare parts
209749200154	EXHAUST PIPE ASSY BS6	TATA spare parts
209749200155	BRACKET ASSY BS6	TATA spare parts
209749200156	HOSE UREA TANK HEATING BS6	TATA spare parts
209749200157	HOSE UREA TANK HEATING SUCTION LINE BS6	TATA spare parts
209749200158	COOLANT PIPE ENGINE TO VALVE BS6	TATA spare parts
209749200159	HOSE UREA TANK HEATING RETURN LINE BS6	TATA spare parts
209749200164	EXHAUST PIPE ASSY BS6	TATA spare parts

209749200168	BRACKET ASSY BS6	TATA spare parts
209749200170	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
209749200172	STRAP ASSY-UREA TANK MTG BS6	TATA spare parts
209749200173	STRAP ASSY UREA TANK MTG BS6	TATA spare parts
209749200174	STRAP ASSY UREA TANK MTG BS6	TATA spare parts
209749200175	COOLANT PIPE ENGINE TO VALVE BS6	TATA spare parts
209749203309	BRACKET	TATA spare parts
209749203310	L-BRACKET EXHAUST MTG	TATA spare parts
209749203328	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
209749203329	BRACKET BS6	TATA spare parts
209749203330	BRACKET BS6	TATA spare parts
209749207701	RUBBER PACKING BS6	TATA spare parts
209749207702	RUBBER PACKING UREA TANK BS6	TATA spare parts
209749208201	L-PLATE(EXHAUST MTG)	TATA spare parts
209749208202	Z-PLATE(EXHAUST MTG)	TATA spare parts
209749208207	L-BRACKET(EXHAUST MTG)	TATA spare parts
209749208210	BRACKET-EXHAUST PIPE	TATA spare parts
209749208211	Z-PLATE (EXHAUST MTG.)	TATA spare parts
209749208225	BRACKET BS6	TATA spare parts
209749990101	HEAT SHIELD ASSY BS6	TATA spare parts
209754100102	BATTERY TRAY ASSY	TATA spare parts
209754209904	INSTRUMENT CLUSTER 12V 0.88	TATA spare parts
209754209905	INSTRUMENT CLUSTER 12V 0.88	TATA spare parts
209754209906	INSTR CLTR (0.91)SA1212TC BSII 9X20TYRE	TATA spare parts
209754209910	INST CLUSTER ESPEEDO(0.91)SA1212TCBSIII	TATA spare parts
209754209911	INST CLUSTER ESPEEDO(0.88)SAK1212TCBSIII	TATA spare parts
209754209913	E-SPEEDOMETER (1:0.91) 12V	TATA spare parts
209754209914	INST.CLUSTER (1 0.91) SA-1212	TATA spare parts
209754209916	INST. CLUSTER SA-1212 TC BS-III(1:0.91)	TATA spare parts
209754209919	INST CLUSTER (1 0.88)SA-1212 TC BS-II 12	TATA spare parts
209754400103	BRACKET ASSY TAIL LAMP MTG LH BS6	TATA spare parts
209754400104	BRACKET ASSY TAIL LAMP MTG RH BS6	TATA spare parts
209754400402	ROOF LAMP ASSY BS6	TATA spare parts
209754500157	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
209754504901	SWITCH ABS OFF	TATA spare parts
209754504903	SWITCH FUEL HEATER	TATA spare parts
209754504904	SWITCH POWER TAKE OFF BS6	TATA spare parts
209754504905	SWITCH FUEL HEATER BS6	TATA spare parts
209754504906	SWITCH ABS OFF BS6	TATA spare parts
209754504907	CARRIER PLATE ASSY FACIA SWITCH MTG BS6	TATA spare parts
209754600108	WIRING HARNESS ABS	TATA spare parts
209754600112	WIRING HARNESS ABS	TATA spare parts
209754600131	BRACKET ASSY MAXI FUSE MTG BS6	TATA spare parts
209754600150	WIRING HARNESS ENGINE	TATA spare parts
209754600151	WIRING HARNESS MAIN	TATA spare parts
209754600154	WIRING HARNESS TAIL	TATA spare parts
209754600158	WIRING HARNESS SCR UNIT BS6	TATA spare parts

209754600159	WIRING HARNESS ENGINE BS6	TATA spare parts
209754600160	WIRING HARNESS TAIL BS6	TATA spare parts
209754600161	WIRING HARNESS MAIN BS6	TATA spare parts
209754600162	BATTERY CABLE +VE MEGA FUSE BS6	TATA spare parts
209754600163	ATTERY CABLE +VE BCS TO MEGA FUSE BS6	TATA spare parts
209754600167	WIRING HARNESS TAIL BS6	TATA spare parts
209754600175	WIRING HARNESS SCR UNIT BS6	TATA spare parts
209754600178	WIRING HARNESS ENGINE BS6	TATA spare parts
209754601603	WIRING HARNESS TAIL	TATA spare parts
209754601617	CABLE BATTERY +VE WITH MEGA FUSE	TATA spare parts
209754601618	CABLE BATTERY +VE BCS TO STARTER MOTOR	TATA spare parts
209754601619	CABLE BATTERY +VE BCS TO STARTER MOTOR	TATA spare parts
209754601620	CABLE BATTERY -VE BCS TO STARTER MOTOR	TATA spare parts
209754601621	CABLE BATTERY +VE WITH MEGA FUSE	TATA spare parts
209754601622	CABLE BATTERY -VE TO CUT OFF SWITCH	TATA spare parts
209754601623	CABLE BATTERY -VE BCS TO STARTER MOTOR	TATA spare parts
209754603301	BRACKET MAXI FUSE MTG	TATA spare parts
209754606305	FUSEBOXCOVER	TATA spare parts
209754609901	RELAY WITH DIODE BS6	TATA spare parts
209754609905	STICKER MAXI FUSE BOX BS6	TATA spare parts
209754620102	W/H MAIN SAK1212TC BSIII 24V	TATA spare parts
209754630101	WIRING HARNESS LOAD BODY BS6	TATA spare parts
209754630103	WIRING HARNESS ABS FRAME BS6	TATA spare parts
209754640101	BATTERY CABLE BS6	TATA spare parts
209754640102	BATTERY CABLE +VE BCS TO MEGA FUSE BS6	TATA spare parts
209754660113	W/H MAIN SA/SAK-1212TC ERGO	TATA spare parts
209754660114	W/H TAIL SA/SAK-1212TC ERGO	TATA spare parts
209754660116	WIRING HARNESS ROOF	TATA spare parts
209754660118	WIRING HARNESS MAIN	TATA spare parts
209754660119	WIRING HARNESS TAIL	TATA spare parts
209754660120	WIRING HARNESS TAIL	TATA spare parts
209754720102	BRACKET ASSY BS6	TATA spare parts
209754820105	W/H MAIN SA1212TC EII CIV M-HL I/C	TATA spare parts
209754820106	W/H-TAIL SA-1212/42TC E-II	TATA spare parts
209754820107	W/H-TAIL SAK-1212TC/32 E-II	TATA spare parts
209754820108	W/H MAIN SAK1212TC EII M-HL I/C	TATA spare parts
209754820112	WIRING HARNESS TAIL BSII SCAM BRAKE	TATA spare parts
209754820113	W/H TAIL SAK-1212TC/42 BSII SCAM BRAKE	TATA spare parts
209754820114	WIRING HARNESS MAIN BSII SCAM BRAKE	TATA spare parts
209758300102	ASSY. SPACER BLOCK COMPLETE	TATA spare parts
209770000101	ASSEMBLY LOADBODY	TATA spare parts
209792000101	REAR BENCH SEAT ASSY BS6	TATA spare parts
209828400101	ASSY LEVER-AGB SHIFTING	TATA spare parts
209828400102	ASSY LINK ROD	TATA spare parts
209831200101	ASSY ENG CROSS MEMBER REAR	TATA spare parts
209841100101	472 90 DIA ASSY P/ SHAFT COMPL REAR	TATA spare parts
209924100101	ASSY ENGINE MTG. ARM FRONT-RH	TATA spare parts



209924100102	ASSY ENG MTG ARM FRONT LH	TATA spare parts
209924105101	ENGINE MTG ARM FRT. RH	TATA spare parts
209924105102	ENGINE MTG ARM FRT LH	TATA spare parts
209924108201	REINFORCEMENT LH	TATA spare parts
209924108202	REINFORCEMENT RH	TATA spare parts
209924108203	REINFORCEMENT	TATA spare parts
209924109201	WASHER	TATA spare parts
209926000101	ASSY G600 DIR/SHIFT GBOX/SIDE MTD PTO	TATA spare parts
209926100101	ASSY G600-6/8.47 DIR/SHIFT WITH PTO PROV	TATA spare parts
209926700106	ASSY TOP COVER COMP(RHD)-6 SPEED	TATA spare parts
209928010102	AUX GEAR BOX ASSY	TATA spare parts
209928010103	AUX GEAR BOX ASSY BS6	TATA spare parts
209928010104	AUX GEAR BOX ASSY BS6	TATA spare parts
209928100101	HOUSING & COVER ASSY TRANSFER CASE BS6	TATA spare parts
209928400101	ASSY LINK ROD-FAT ROLE	TATA spare parts
209928400102	ASSY. LINK ROD	TATA spare parts
209928400103	ASSY. PIN (LEVER MTG.)	TATA spare parts
209928400104	ASSY. T/CASE SHIFTING LEVER	TATA spare parts
209928400105	ASSY LINK ROD (FOR AGB SHIFTING)	TATA spare parts
209928400106	ASSY T/CASE SHIFTING LEVER	TATA spare parts
209928400107	ASSY LINK ROD(FOR AGB SHIFTING)	TATA spare parts
209928403701	CYLINDER COVER INPUT	TATA spare parts
209928407901	SHIFTER SHAFT BS6	TATA spare parts
209928408201	BRACKET (AGB MTG)	TATA spare parts
209930100102	ASSY PULL ROD	TATA spare parts
209931000112	ASSY.FRAME COMPLETE	TATA spare parts
209931000113	ASSY FRAME COMPL WITH STG BKT (FAT ROLE)	TATA spare parts
209931000115	FRAME ASSY	TATA spare parts
209931000116	ASSY. FRAME COMPLETE	TATA spare parts
209931000117	ASSY FRAME COMPL WITH STG BKT	TATA spare parts
209931200101	ASSY. SUPPORT LH FRONT(FRT. ENG. C/M)	TATA spare parts
209931200102	ASSY. SUPPORT FRONT R.H. (FRT. ENG. C/M)	TATA spare parts
209931200103	ASSY. SUPPORT LH REAR(FRT. ENG. C/M)	TATA spare parts
209931200104	ASSY. SUPPORT RH REAR (FRT. ENG. C/M)	TATA spare parts
209931200105	ASSY ENGINE CROSS MEMBER FRONT	TATA spare parts
209931200110	ASSY. REINFORCEMENT BKT. RH	TATA spare parts
209931200111	ASSY REINFORCEMENT BRACKET L.H.	TATA spare parts
209931200114	ASSY. END CROSS MEMBER	TATA spare parts
209931200116	ASSY BRACKET LH (BUMPER SUPPORT)	TATA spare parts
209931200117	ASSY BRACKET RH (BUMPER SUPPORT)	TATA spare parts
209931200120	ASSY SUPPORT-ENG X-MEMBER REAR-RH	TATA spare parts
209931200121	ASSY SUPPORT-ENG X-MEMBER REAR-LH	TATA spare parts
209931200122	ASSY ENGINE MTG X-MEMBER REAR	TATA spare parts
209931200123	ASSY SUPPORT(BUMPER)-LH	TATA spare parts
209931200124	ASSY SUPPORT(BUMPER)-RH	TATA spare parts
209931200125	ASSY ENGINE MTG CROSS-MEMBER FRONT	TATA spare parts
209931200126	ASSY CROSS MEMBER AGB	TATA spare parts

209931207112	REINFORCEMENT LH	TATA spare parts
209931207113	REINFORCEMENT RH	TATA spare parts
209931207124	STIFFNER	TATA spare parts
209931207130	GUSSET-RH.	TATA spare parts
209931207131	GUSSET-LH.	TATA spare parts
209931207135	SUPPORT-FRT ENG X-MEMBER(REAR)-RH	TATA spare parts
209931207136	SUPPORT-FRT ENG X-MEMBER(REAR)-LH	TATA spare parts
209931207137	SUPPORT-FRT ENG X-MEMBER(FRONT)-RH	TATA spare parts
209931207138	SUPPORT-FRT ENG X-MEMBER(FRONT)-LH	TATA spare parts
209931207142	REINFORCEMENT-LH(BOTTOM)	TATA spare parts
209931207143	REINFORCEMENT-RH(BOTTOM)	TATA spare parts
209931207150	SUPPORT CROSS-MEMBER FRONT RH	TATA spare parts
20993120715035	SUPPORT X-MEMBER FRONT RH_UNPAINTED	TATA spare parts
209931207151	SUPPORT CROSS-MEMBER FRONT LH	TATA spare parts
20993120715135	SUPPORT X-MEMBER FRONT LH_UNPAINTED	TATA spare parts
209931208204	REINFORCEMENT (END CROSS MEM. FOR TOWIN	TATA spare parts
209931208210	PACKING PLATE-1 THK (ENG CROSS MEM. FRT	TATA spare parts
209931208215	CROSS MEMBER REAR SPRING	TATA spare parts
209931208216	GUSSET	TATA spare parts
209931208217	GUSSET	TATA spare parts
209932100105	LEAF SPRING ASSY FRONT BS6	TATA spare parts
209932100106	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
209932103201	CENTER BOLT BS6	TATA spare parts
209932107102	2ND LEAF BS6	TATA spare parts
209932107103	3RD LEAF BS6	TATA spare parts
209932107104	4TH LEAF BS6	TATA spare parts
209932107105	5TH LEAF BS6	TATA spare parts
209932107106	6TH LEAF BS6	TATA spare parts
209932107107	7TH LEAF BS6	TATA spare parts
209932107108	8TH LEAF BS6	TATA spare parts
209932107109	9TH LEAF BS6	TATA spare parts
209932107110	SPACER BS6	TATA spare parts
209932300101	ASSY. BRACKET (SHOCK ABSORBER)	TATA spare parts
209932300104	ASSY SHOCK ABSORBER BRACKET RH	TATA spare parts
209932300105	BRACKET ASSY SHOCK ABSORBER FRONT-LH BS6	TATA spare parts
209932300106	BRACKET ASSY SHOCK ABSORBER FRONT-RH BS6	TATA spare parts
209932303201	BOLT (S/ABSR TO BKT UPPER)	TATA spare parts
209932400104	REAR SPRING ASSY BS6	TATA spare parts
209932400105	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
209932403201	CENTER BOLT BS6	TATA spare parts
209932404201	U CLAMP	TATA spare parts
209932407102	2ND LEAF MAIN SPRING BS6	TATA spare parts
209932407103	3RD LEAF MAIN SPRING BS6	TATA spare parts
209932407104	4TH LEAF MAIN SPRING BS6	TATA spare parts
209932407105	5TH LEAF MAIN SPRING BS6	TATA spare parts
209932407106	6TH LEAF MAIN SPRING BS6	TATA spare parts
209932407107	7TH LEAF MAIN SPRING BS6	TATA spare parts

209932407108	8TH LEAF MAIN SPRING BS6	TATA spare parts
209932407109	9TH LEAF MAIN SPRING BS6	TATA spare parts
209932407110	10TH LEAF MAIN SPRING BS6	TATA spare parts
209932407111	11TH LEAF MAIN SPRING BS6	TATA spare parts
209932407112	1ST LEAF AUX SPRING BS6	TATA spare parts
209932407113	2ND LEAF AUX SPRING BS6	TATA spare parts
209932407114	3RD LEAF AUX SPRING BS6	TATA spare parts
209932407115	4TH LEAF AUX SPRING BS6	TATA spare parts
209932407117	5TH LEAF AUX SPRING BS6	TATA spare parts
209933100101	ASSY RUBBER BUFFER	TATA spare parts
209933100102	ASSY SUPPORT RUBBER BUFFER LEFT	TATA spare parts
209933100103	ASSY SUPPORT RUBBER BUFFER RIGHT	TATA spare parts
209940106301	12X20 18PR NYLON SAND GRIP	TATA spare parts
209941100102	ASSY PROP SHAFT COMP(GEAR BOX TO AUX GEA	TATA spare parts
209941100105	ASSY PROPELLOR SHAFT COMPL.	TATA spare parts
209941100113	ASSY PROPELLER SHAFT(GB TO AGB)	TATA spare parts
209941100114	ASSY PROPELLER SHAFT COMPLETE	TATA spare parts
209941100119	ASSEMBLY PROP SHAFT COMPLETE(GB TO AGB)	TATA spare parts
209941120101	ASSY PROP SHAFT COMPL	TATA spare parts
209941120102	ASSY PROP SHAFT REAR COMPLT	TATA spare parts
209942900149	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
209942900163	SET ASSY NYLON PIPE COMPLETE	TATA spare parts
209942900165	ASSY TUBE(15 O.D.X3010 LG)W/H TO I/JOINT	TATA spare parts
209942900166	ASSY TUBE(15 O.D.X2700 LG)W/H - INT.JOIT	TATA spare parts
209942900167	ASSY TUBE(6 O.D.X3230LG)-A/CYL-LCRV	TATA spare parts
209942900170	SET ASSY NYLON PIPE	TATA spare parts
209942900173	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
209943200101	ASSY BRACKET RH (AIR TANK MTG)	TATA spare parts
209943200102	ASSY BRACKET LH(AIR TANK MTG)	TATA spare parts
209943200103	ASSY.AIR TANK COMP.WITH SUPPORT SPACER S	TATA spare parts
209943200109	ASSY BRACKET ( FOR DDU MTG )	TATA spare parts
209943200110	ASSY.AIR TANK COMPLETE WITH BRACKETS	TATA spare parts
209943900101	ASSY TUBE WITH CRIPMED RUBBER HOSE (A/FI	TATA spare parts
209943900108	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
209943900114	SET-NYLON PIPE BUNCH COMPLETE	TATA spare parts
209943910101	COMP OUTLET 1ST PIPE	TATA spare parts
209943910106	ASSY COMP OUTLET PIPE 2ND	TATA spare parts
209943910108	ASSY COMP OUTLET PIPE 3RD	TATA spare parts
209943910109	ASSY COMP OUTLET 2ND PIPE	TATA spare parts
209946000107	ASSY DRAG LINK(SD1015TC/42)LHD	TATA spare parts
209946000115	ASSY.DRAG LINK SA/SAK 1212 TC SCAM	TATA spare parts
209946000122	ASSY.DRAGLINK(SD1015LHDBSII)	TATA spare parts
209946200102	ASSY.BRACKET(STG.GEAR BOX MTG.BRACKET)	TATA spare parts
209946207901	STEERING SPINDLE TOP	TATA spare parts
209946306001	PITMAN ARM	TATA spare parts
209946600101	ASSY BRACKET P/STG HYD TANK MTG	TATA spare parts
209946607501	RUBBER BELLOW (STG CUT-OUT)	TATA spare parts

209946800102	ASSY TUBE	TATA spare parts
209946800124	SUCTION LINE ASSY	TATA spare parts
209946800125	PRESSURE LINE ASSY	TATA spare parts
209946800126	RETURN LINE ASSY	TATA spare parts
209946806801	BANJO	TATA spare parts
209946990101	ASSY. KIT FOR POWER STG. LINE	TATA spare parts
209947100110	ASSY DIP STICK (COMPL) 225 LTR ROUND	TATA spare parts
209947100111	ASSY FUEL TANK COMPL.(225 LTR. ROUND)	TATA spare parts
209947500104	ASSY BRACKET	TATA spare parts
209947500106	ASSY SUPPORT	TATA spare parts
209947900101	HOSE ASSY-RETURN LINE	TATA spare parts
209947900102	HOSE ASSY-MAIN LINE	TATA spare parts
209947900104	HOSE ASSY-MAIN LINE	TATA spare parts
209947900105	HOSE ASSY-MAIN LINE	TATA spare parts
209947900106	HOSE ASSY-RETURN LINE	TATA spare parts
209947900107	HOSE ASSY-RETURN LINE	TATA spare parts
209947900115	ASSY.FUEL LINE(FUELTANK TO HEATING UNIT)	TATA spare parts
209947900116	ASSY.FUEL LINE(HEATING UNIT TO BABY FLT)	TATA spare parts
209947900118	FIP TO FUEL TANK (RETURN LINE)	TATA spare parts
209947900119	ASSY.FUEL LINE(FUELTANK TO HEATING UNIT)	TATA spare parts
209947900120	ASSY.FUEL LINE(HEATING UNIT TO BABY FLT)	TATA spare parts
209947900125	FUELSUCTIONLINEASSY(F\TTOB\F)	TATA spare parts
209947900126	FUELLINESASSYRETURN	TATA spare parts
209949100102	ASSY SILENCER WITH PIPE	TATA spare parts
209949100103	ASSY SILENCER WITH PIPE	TATA spare parts
209949100104	SILENCER SD 1015/36/42 TC BS 3	TATA spare parts
209949200101	ASSY EXHAUST PIPE-FRONT	TATA spare parts
209949200102	ASSY EXHAUST PIPE-INTERMEDIATE	TATA spare parts
209949200105	ASSY EXHAUST BRACKET	TATA spare parts
209949200106	ASSY EXHAUST PIPE INTERMEDIATE-REAR	TATA spare parts
209949200107	TAIL PIPE	TATA spare parts
209949200111	ASSY EXH. PIPE INTERMEDIATE -REAR	TATA spare parts
209949200112	ASSY EXHAUST PIPE INTERMEDIATE (FRONT)	TATA spare parts
209949200114	ASSY EXHAUST PIPE (FRONT)	TATA spare parts
209949200115	ASSY EXHAUST PIPE INERMEDIATE TO MUFFLER	TATA spare parts
209949200119	ASSY EXHAUST INTERMEDIATE PIPE (FRONT)	TATA spare parts
209949200120	ASSY EXHAUST PIPE INTERMEDIATE-REAR	TATA spare parts
209949200123	ASSY EXHAUST PIPE INTERMEDIATE - FRONT	TATA spare parts
209949203301	BRACKET	TATA spare parts
209949203303	BRACKET	TATA spare parts
209949208204	CLAMP (EXHAUST)	TATA spare parts
209949208205	CLAMP (EXHAUST)	TATA spare parts
209949208206	CLAMP (EXHAUST)-(EXH PIPE TO BRKT)	TATA spare parts
209949208207	CLAMP ( EXHAUST )-(EXH PIPE TO BRKT)	TATA spare parts
209949208209	BRACKET (FOR REAR EXHAUST PIPE MTG)	TATA spare parts
209954008201	MTG. BRACKET FOR CHANGE-OVER SWITCH & AM	TATA spare parts
209954100101	ASSY. CU. BATTERY CABLE +VE (360MM)	TATA spare parts

209954100102	ASSY BATT CABLE +VE ( 1200MM)	TATA spare parts
209954100103	ASSY. CU. BATTERY CABLE +VE	TATA spare parts
209954100104	ASSY BATT CABLE CONNECTOR	TATA spare parts
209954110101	ASSY. CU. BATTERY CABLE -VE (560MM)	TATA spare parts
209954110102	ASSY. BATTERY CABLE (-VE) (12V)	TATA spare parts
209954200101	ASSY LOW COOLANT LEVEL SENSOR	TATA spare parts
209954208201	MOUNTING BRACKET FOR INTEGRATED FUSE BOX	TATA spare parts
209954209902	INSTRUMENT CLUSTER (0.84)	TATA spare parts
209954209903	SPEEDOMETER (0.84)	TATA spare parts
209954209904	OIL PRESSURE GAUGE	TATA spare parts
209954209911	INSTRUMENT CLUSTER SD-1015 TC BS-III	TATA spare parts
209954209912	SPEEDOMETER (0.97)	TATA spare parts
209954209915	INST.CLUSTER(1 0.82)SD-1015 TC BS-ILHD	TATA spare parts
209954600102	ASSY.CABLE SET -F/TAIL/SD/1015/36	TATA spare parts
209954620102	W/H PIGTAIL BERU CONTROLLER	TATA spare parts
209954620103	W/H POWER CABLE-1	TATA spare parts
209954620104	W/H POWER CABLE-2	TATA spare parts
209954620106	W/H PIGTAIL FUEL HEATER	TATA spare parts
209954620107	W/H MAIN	TATA spare parts
209954820103	WIRING HARNESS MAIN	TATA spare parts
209954820104	WIRING HARNESS-TAIL	TATA spare parts
209954820105	W/H-MAIN SD-1015TCARMYE-IIM-H/LIN CL	TATA spare parts
209954820106	W/H-TAIL SD-1015TC/36 E-II ARMY B/O	TATA spare parts
209954820107	W/H-TAIL SD-1015TC/42 E-II ARMY B/O	TATA spare parts
209954821601	W/H MAIN SD1015 TC BSIII 24V	TATA spare parts
209956000102	ASSY. MECH. WINCH 5T	TATA spare parts
209956000111	ASSY. MECH. WINCH 5T	TATA spare parts
209956500106	ASSY BRACKET W/O PULLEY MTG	TATA spare parts
209960100101	ASSY BODY SHELL COMPL	TATA spare parts
209960100102	CAB SHELL PAINTED SD 1015 FATROL BS II	TATA spare parts
209961060103	ASSY FLOOR CENTRE	TATA spare parts
209970020101	ASSY LOAD BODY COMPT.	TATA spare parts
209983100101	SUB-ASSY. AIR DUCT (BOTTOM)	TATA spare parts
209983106301	DUCT	TATA spare parts
209983500104	ASSY.BRACKET FOR VALVE MTG.(CAB HEATING)	TATA spare parts
209991040101	ASSY SEAT CO-DRIVER - RHD	TATA spare parts
20AX038Z00	LINK A FRAME	TATA spare parts
20AX039C01	LINK TORQUE ROD	TATA spare parts
2100202039	INT RING	TATA spare parts
210021910153	SWING CONTROLLER	TATA spare parts
210021930100	CONTROL CABINET	TATA spare parts
2101034017	TERMINAL PLATE	TATA spare parts
210115009901	STARTER MOTOR	TATA spare parts
210115009902	GENERATOR 160W W/PULLEY	TATA spare parts
210115009904	VOLTAGE REGULATOR 20AMP	TATA spare parts
210115009905	VOLTAGE REGULATOR	TATA spare parts
210115009906	ALTERNATOR WITH REGULATOR	TATA spare parts

210115100101	STARTER MOTOR 24V	TATA spare parts
210120030680	FLASHER	TATA spare parts
210122660189	ASSY GPS UNIT W/DISPLAY(ULF)HCBS	TATA spare parts
210122719922	CO-AXIAL CABLE FOR GPS FM RADIO ANTENNA	TATA spare parts
210122880147	COOLENT LEVEL SENSOR FOR SFC	TATA spare parts
210123160173	PCB SUB ASSY. EMOS 12-24VDC	TATA spare parts
210123440120	ATCU MICROPHONE ASSEMBLY	TATA spare parts
210124389931	NPS PIGTAIL (FLRY-B)	TATA spare parts
210124829913	FUSE 80A(BUSSMANN 170M1807)	TATA spare parts
210125239902	DIA 25MM HST	TATA spare parts
210125239903	DIA 35MM HST	TATA spare parts
210154100116	BATTERY CABLE -VE	TATA spare parts
210154200132	SPEEDOCABLE 2100MM	TATA spare parts
210154202911	TEMPERATURE TRANSDUCER	TATA spare parts
210154202915	FUEL TANK UNIT	TATA spare parts
210154202918	SPEEDOMETER	TATA spare parts
210154202920	GAUGE FUEL	TATA spare parts
210154202922	AIR PRESSUR GAUGE	TATA spare parts
210154202923	WATER TEMP GAUGE	TATA spare parts
210154202924	WATER TEMP GAUGE	TATA spare parts
210154509901	FUSE BOX	TATA spare parts
210154509902	STARTER PUSH BUTTON	TATA spare parts
210154509904	STARTER PUSH BUTTON	TATA spare parts
210154509905	MAIN LINE SWITCH	TATA spare parts
210154509906	STARTER PUSH BUTTON	TATA spare parts
210173	CAP SCREW CARRIER TO HSG	TATA spare parts
210174	OIL SEAL	TATA spare parts
210322379944	SILICON ENGINES-nls-22749944	TATA spare parts
210322589965	DIAGNOSTIC S/W FOR VP37 TRUCK -ENGLISH	TATA spare parts
210322679966	PCMCIA TO SINGLE RS232 SERIAL PORT CARD	TATA spare parts
210322739995	DIA S/W FOR ABS - CV	TATA spare parts
210322739996	DIA S/W FOR ABS - CV	TATA spare parts
210322749944	USB SILICON ENGINES - MODEL 9009	TATA spare parts
210322819971	Diagnostic Software for BCM	TATA spare parts
210323039956	USB S/W DICOR 1.4 & 2.2 ENGLISH	TATA spare parts
210323039961	USB-RS 232 SAFARI DICOR 3L	TATA spare parts
210323039964	USB S/W TRUCK BSIII - ENGINE	TATA spare parts
210323039966	USB Software ABS - English	TATA spare parts
210323039968	USB S/W TRUCK VOITH REATARDER - ENG	TATA spare parts
210323039969	USB S/W XENON 2.2LDICOR-SPANISH	TATA spare parts
210323039970	USB S/W MPFI BSIII(ALL VEH)-ENG	TATA spare parts
210323039970_niu1	USB S/W MPFI BSIII(ALL VEH)-ENG	TATA spare parts
210323039983	USB S/W INDICA DICOR1.4 - TURKISH	TATA spare parts
210323239950	DIAG S/W TOOL ABS8.1 USB/RS232	TATA spare parts
210323239987	INDICA CRDI 1.4&2.2 THAI - RS232 & USB	TATA spare parts
210323249966	Diagnostic software for New Indica	TATA spare parts
210323259933	HS LIGHT INTERFACE FOR DIAGNOSTICS	TATA spare parts

210323269944	DIAGNOSTIC S/W - TATA MPFI-LPG-CNG	TATA spare parts
210323269955	OBDII CONNECTOR CABLE	TATA spare parts
210323279944	TATA DIAGNOSTICS S/W EMS - TRUCK	TATA spare parts
210323289914	DIAGNOSTIC SOFTWARE - ACE XENON WINGER	TATA spare parts
210323299928	PORTABLE ENGINE PARA.SETTING SYS(COLOUR)	TATA spare parts
210323299953	REPROGRAMMING S/W FOR CRDI 1.4L & .2.2L	TATA spare parts
210323300175	ASSY. PORTABLE DIAGN. TESTER	TATA spare parts
210323309997	DIA SW FOR VP37 EMS ECU USING MOBILE DEV	TATA spare parts
210323349998	Diagnostic software for New Indica	TATA spare parts
210323359944	DIAGNOSTIC SW FOR DICOR ENGINE (ALL)	TATA spare parts
210323359944_niu3	DIAGNOSTIC SW FOR DICOR ENGINE (ALL)	TATA spare parts
210323389907	DIAGNOSTIC SOFTWARE FOR WORLD TRUCK	TATA spare parts
210323399907	DIAG S/W SCN 2.3 DIESEL EMS	TATA spare parts
210323399907_niu1	DIAG S/W SCN 2.3 DIESEL EMS	TATA spare parts
210323479991	FUEL SOLENOID	TATA spare parts
210323489969	MAGNETIC PICKUP	TATA spare parts
210323609978	DIAGNOSTIC SOFTWARE FOR LCV/HCV TRUCK V	TATA spare parts
210323659968	SAMTEC HP-BA-5000 HS+ I/F USB POWERED	TATA spare parts
210323859941	TML UNIVERSAL FLASHING TOOL S/W FOR CV	TATA spare parts
210323969935	DIAGNOSTICS S/W FOR HYBRID COMM.VEHICLE	TATA spare parts
210323999949	TATA ULTRA DIAGNOSTIC TOOL	TATA spare parts
210324400124	TUNISIA COMPLETE EOL SYSTEM ASSEMBLY	TATA spare parts
210324400525	TUNISIA COMPLETE EOL SYSTEM ITEMS	TATA spare parts
210324400526	SOFTWARE LICENCES FOR TUNISIA EOL	TATA spare parts
210324450537	TUNISIA XENON REPAIR BLEED UNIT	TATA spare parts
210324769907	GES-GARUDA II USB ENABLED FULL SET	TATA spare parts
210324769908	GES-GARUDA II-USB-CABLE BS6	TATA spare parts
210324769909	GES-GARUDA II-OBDII-CABLE BS6	TATA spare parts
210325229990	TDS BS4 TELEMATICS SOFTWARE	TATA spare parts
210325309940	IB BNGL EOL LPT1212 SOFTWARE	TATA spare parts
2103426015	SCREW	TATA spare parts
210424	KIT - BASIC OVERHAUL	TATA spare parts
210508	PINION NUT	TATA spare parts
210509	FLAT WASHER	TATA spare parts
210592	PINION BRG CAGE & CUP ASY	TATA spare parts
210601	CAP SCREW LH	TATA spare parts
210724	PINION OIL SEAL	TATA spare parts
210922089901	AVT 101 OBD II cable	TATA spare parts
210923299903	MAXI FUSE 120A WHT BOLT	TATA spare parts
210923490538	DIGITAL INSULA. TESTER FLUKE-1507 + CASE	TATA spare parts
210924789939	ELECTRICAL H/GLOVES GP-0*- PRESEL MAKE	TATA spare parts
210924789941	RESCUE HOOK CS-45- CATU MAKE	TATA spare parts
210924809983	SAFETY VOLTAGE INDICATOR & PROVING UNIT	TATA spare parts
210952	BRG CAGE & CUP ASSY	TATA spare parts
212401150002	INSPECTION LID ASSY	TATA spare parts
21300000001	BUSH (43ODX38ID)	TATA spare parts
21301000001	PIPE END (D=15)	TATA spare parts

21301000002	END BUSH FOR GRAB RAIL	TATA spare parts
21303000003	END BUSH (AL.PIPE)	TATA spare parts
214001700001	FRONT FRP ASSEMBLY BS6	TATA spare parts
214001710001	FRONT FRP ASSY BS6	TATA spare parts
214010170001	FRONT FRP FLAP - 4 TONNER	TATA spare parts
214010200001	FRONT FLAP	TATA spare parts
214020520001	FRT LAMP FEND PNL LH - SUPREME	TATA spare parts
214020530001	FRT LAMP FEND PNL RH - SUPREME	TATA spare parts
214020570001	FRONT GRILL	TATA spare parts
214020860001	FRONT FLAP BS6	TATA spare parts
214020990001	FRONT FLAP NEO BS6-PH2	TATA spare parts
21410551036	BASE PLUG	TATA spare parts
214310030001	ENGINE HOOD	TATA spare parts
214310040001	FRP ENGH.PODEST	TATA spare parts
214310180001	ENGINE HOOD	TATA spare parts
214310190001	PODDEST	TATA spare parts
214410310001	REAR FRP	TATA spare parts
214410440001	REAR FRP	TATA spare parts
214410720001	REAR FRP BS6	TATA spare parts
214410800001	REAR FRP ASSY BS6	TATA spare parts
214410840001	REAR FRP BS6	TATA spare parts
214421930001	REAR HEADER CENTER PANEL	TATA spare parts
214421940001	REAR HEADER CORNER PANEL LH	TATA spare parts
214421950001	REAR HEADER CORNER PANEL LH	TATA spare parts
214421960001	REAR PILLAR LH	TATA spare parts
214421970001	REAR PILLAR RH	TATA spare parts
214422000001	REAR LAMP FENDER PANEL LH	TATA spare parts
214422010001	REAR LAMP FENDER PANEL LH	TATA spare parts
214422040001	REAR FRP ASSEMBLY	TATA spare parts
214422070001	REAR GLASS MOUNTING PANEL	TATA spare parts
214620230001	INGE ASSEMBLY (LH)	TATA spare parts
214620240001	HINGE ASSEMBLY (RH)	TATA spare parts
214620250001	HINGE ASSEMBLY (LH)	TATA spare parts
214620260001	HINGE ASSEMBLY (RH)	TATA spare parts
215009130101	ASSY AL PIPE	TATA spare parts
215009135801	RUBBER HOSE (AIR FILTER OUT LET)	TATA spare parts
215009137101	BRACKET (AIR FILTER MTG)	TATA spare parts
215024200104	ASSY BRACKET-RH (ENGINE MTG BOTTOM )	TATA spare parts
215024200105	SSY BRACKET -LH (ENG. MTG BOTTOM )	TATA spare parts
215024200108	ASSY.BRACKET(ENGINE MTG.REAR TOP)	TATA spare parts
215024200109	ASSY.BRACKET(ENGINE MTG-REAR TOP)	TATA spare parts
215026800114	ASSY TURNING TUBE	TATA spare parts
215026800115	ASSY BRACKET	TATA spare parts
215026809901	GEAR SHIFT LEVER	TATA spare parts
215029100105	ASSY.BRAKE PEDAL COMPL.	TATA spare parts
215029100110	ASSY.CLUTCH PEDAL LEVER COMPL.	TATA spare parts
215029150103	ASSY.TUBE	TATA spare parts



215029150104	ASSY.TUBE	TATA spare parts
215030100101	ASSY.PEDAL LEVER ACCL.(LHD)	TATA spare parts
215030100104	ASSY.PULL CABLE(ACCL.)	TATA spare parts
215031000102	ASSY FRAME COMPLETE LPO916_42WB_LHD	TATA spare parts
215031200101	ASSY ENG CROSS MEMBER RAER	TATA spare parts
215031200103	ASSY ENGINE C.M. FRONT	TATA spare parts
215031200111	ASSY CROSS MEMBER	TATA spare parts
215031207113	SUPPORT LH (TUBULAR X MEMBER)	TATA spare parts
215031207116	REINFORCEMENT-R.H(TOP)	TATA spare parts
215031207117	REINFORCEMENT L.H (TOP)	TATA spare parts
215031207122	SUPPORT ( ENGINE C.M. FRONT )	TATA spare parts
215031207125	REINFORCEMENT FRONT RH(BOTTOM)	TATA spare parts
215031207126	REINFORCEMENT FRONT LH(BOTTOM)	TATA spare parts
215031207127	REINFORCEMENT REAR RH(BOTTOM)	TATA spare parts
215031207128	REINFORCEMENT REAR LH(BOTTOM)	TATA spare parts
215031207138	REINFORCEMENT RH	TATA spare parts
215031207139	REINFORCEMENT LH	TATA spare parts
215031207140	SUPPORT RH (TUBULAR X-MEMBER )	TATA spare parts
215032103301	FRONT SPRING HANGER -LH	TATA spare parts
215032103302	FRONT SPRING HANGER-RH	TATA spare parts
215032900101	ASSY REAR ANTIROLL BAR WITH EYEPIECES	TATA spare parts
215032900107	ASSY LINK (ANTI ROLL BAR)	TATA spare parts
215032900108	ASSY BKT (FOR REAR ARB LINK TO CM)	TATA spare parts
215033103201	U-CLAMP FRONT	TATA spare parts
215035103201	U CLAMP (REAR)	TATA spare parts
215041303301	CENTER BEARING BRACKET	TATA spare parts
215042700101	ASSY BRACKET(HAND BRAKE VALVE)	TATA spare parts
215042900109	ASSY BRACKET	TATA spare parts
215042900134	ASSY.TUBE WITH HOSES(CRIMPED)	TATA spare parts
215042900135	ASSY.PIPE	TATA spare parts
215042900136	ASSY.PIPE	TATA spare parts
215042900137	ASSY.NYLON PIPE SET COMPL.	TATA spare parts
215044806801	BANJO BODY	TATA spare parts
215046200104	ASSY ZF POWER STEERING G.BOX	TATA spare parts
215046200106	ASSY.STG & COWL MTG. COMPLETE	TATA spare parts
215046203301	BKT.(HYD. TANK MOUNTING)	TATA spare parts
215046600105	ASSY STEERING PUMP-ZF	TATA spare parts
215046600108	ASSY.DRAG LINK	TATA spare parts
215046800104	ASSY.TUBE WITH CRIMED RUBBER HOSE COM.	TATA spare parts
215046800106	ASSY.TUBE WITH CRIMED RUBBER HOSE.	TATA spare parts
215046800107	HOSE ASSY(FROM G.BOX TO HY.TANK)	TATA spare parts
215046800108	HOSE ASSY(FROM HYD.TK.TO PUMP)	TATA spare parts
215046990101	ROTOR KIT WITH FRONT & PRESSURE PL	TATA spare parts
215046996601	FLOW LIMITING PISTON	TATA spare parts
215046997701	SHAFT SEAL	TATA spare parts
215046997702	PRESSURE PLATE	TATA spare parts
215047600107	ASSY.TUBE WITH CRIMED R/HOSE.	TATA spare parts

215047600108	ASSY.TUBE WITH CRIMPED R/HOSE	TATA spare parts
215049100101	ASSY SILENCER WITH PIPES	TATA spare parts
215049200114	ASSY FRONT EXHAUST PIPE	TATA spare parts
215049200115	ASSY INTERMEDIATE PIPE	TATA spare parts
215049200119	ASSY EXHAUST MTG BRACKET	TATA spare parts
215054200101	LOW COOLANT LEVEL SENSOR	TATA spare parts
215054209905	ELECT.TEMP. GAUGE-24V	TATA spare parts
215054209906	OIL PR. GAUGE ELECT.-24V	TATA spare parts
215054209910	SPEEDOMETER -TRIP DIST.-1:0.63	TATA spare parts
215054209912	SPEEDOMETER (1:0.60) TRIP DISTANCE	TATA spare parts
215054400103	ASSY.E CERT.H/L.BULBS RH-LHD 24V-	TATA spare parts
215054400104	ASSY.E CERT.H/L.BULBS LH-LHD 24V-	TATA spare parts
215054400105	ASSY.E CERT.H/L.BULBS RH-LHD 24V-	TATA spare parts
215054400106	ASSY.E CERT.H/L.BULBS LH-LHD 24V-	TATA spare parts
215054400107	ASSY.E CERT.H/L.BULBS RH-LHD 24V-	TATA spare parts
215054400108	ASSY.E CERT.H/L.BULBS LH-LHD 24V-	TATA spare parts
215054400109	ASSY.E CERT.H/L.BULBS RH-LHD 24V-	TATA spare parts
215054400110	ASSY.E CERT.H/L.BULBS LH-LHD 24V-	TATA spare parts
215054440101	ASSY.LAMP WARNING IND. 24 V	TATA spare parts
215054500102	ASSY.BKT.-RELAY MTG. -LPO 916TC	TATA spare parts
215054506901	PIANO KEY SW. (COOLANT LEVEL CHK)	TATA spare parts
215054820107	W/H MAIN--LPO 916TC LHD	TATA spare parts
215054820108	W/H TAIL-LPO 916TC LHD/42	TATA spare parts
215060000114	ASSY COWL COMPLETE WITHOUT FACE -LHD	TATA spare parts
215060000115	ASSY COWL SHELL PAINTED	TATA spare parts
215068900103	ASSY DASHBOARD COMPLETE LHD	TATA spare parts
215068906302	DASHBOARD LH.LHD	TATA spare parts
215068908204	INSTRUMENT PANEL	TATA spare parts
215069106302	INSULATION SIDE	TATA spare parts
215081800102	ASSY TATA 916 CUMMINS MASCOT	TATA spare parts
215083100103	ASSY. PLENUM CHAMBER COMPLETE	TATA spare parts
215083100104	BLEEDER ASSY.	TATA spare parts
215083106306	COVER (HEATER UNIT).	TATA spare parts
215083108205	CLAMP FOR HOSE.	TATA spare parts
215083500101	ASSY. BRACKET FOR COIL HSG.MTG. R.H.	TATA spare parts
215083500102	ASSY. BRACKET FOR COIL HSG.MTG. L.H.	TATA spare parts
215083505801	RUBBER HOSE (HEATING COIL TO ENGINE)	TATA spare parts
215083505802	RUBBER HOSE (WATER VALVE TO ENGINE)	TATA spare parts
215083505803	RUBBER HOSE(HEATING COIL TO WATER VALVE)	TATA spare parts
215089100101	ASSY MTG BKT REAR-LH	TATA spare parts
215089100103	ASSY MTG BKT REAR-RH	TATA spare parts
215089100106	ASSY MTG BKT FRONT-RH	TATA spare parts
215089100119	ASSY MTG BKT FRONT-RH(ADDITIONAL)	TATA spare parts
215252070101	ASSY BONNET CENTRE WITH AIR SCOOP	TATA spare parts
215260100111	SD 1015TC RHD FATROLE CAB FITTED	TATA spare parts
215260100116	SA 1212TC RHD DOMESTIC CAB FITTED	TATA spare parts
215260100118	SA 1212TC RHD DGBR CAB FITTED	TATA spare parts

215260100119	CAB COMPLETE SAK1212TC/32 3 WAY TIPPER	TATA spare parts
215260100137	ASSY.CAB FITTED SD 1015TC-LHD	TATA spare parts
215260100140	ASSY. CAB SHELL SA 1212 TC PAINTED	TATA spare parts
215260100141	ASSY. CAB SHELL PAINTED SA 1212 TC	TATA spare parts
215260100145	ASSY. CAB SHELL PAINTED SAK 1212TC/32	TATA spare parts
215260100150	ASSY BODY SHELL COMPL SD1015 BSIII	TATA spare parts
215260100150SJ	ASSY BODY SHELL COMPL SD1015 BSIII	TATA spare parts
215281200101	ASSY T EMBLEM (OVAL STYLISED)	TATA spare parts
215281800101	ASSY. TATA 1015 CUMMINS MASCOT	TATA spare parts
215281800104	ASSY TATA 1212 CUMMINS MASCOT	TATA spare parts
215283100101	ASSY. BLOWER.	TATA spare parts
215283100105	ASSY. COIL HOUSING COMPLETE.	TATA spare parts
215283100106	ASSY. PIPE CONNECTOR (WATER VALVE).	TATA spare parts
215283106303	AIR DUCT TOP.	TATA spare parts
215283106304	COIL HOUSING.	TATA spare parts
215283106305	HOSE BEND.	TATA spare parts
215283106306	HOSE STRAIGHT.	TATA spare parts
215283106309	AIR DUCT TOP.(L.H.D.).	TATA spare parts
215283106311	DUCT SUCTION SIDE	TATA spare parts
215283300101	ASSY CABLE (WATER VALVE).	TATA spare parts
215283400101	ASSY. HEATER COIL.	TATA spare parts
215283400156	BLOWER UNIT 24 V	TATA spare parts
215283505802	RUBBER HOSE (HEATING COIL-WATER PUMP).	TATA spare parts
215283505803	STRAIGHT SOCKET LPTA 713 TC	TATA spare parts
215283505804	RUBBER HOSE (WATER VALVE-ENGINE NIPPLE).	TATA spare parts
215283505805	RUBBER HOSE (HEATING COIL-WATER PUMP).	TATA spare parts
215283506301	T CONNECTOR.	TATA spare parts
215283507501	SEALING GASKET	TATA spare parts
215288050102	ASSY BUMPER	TATA spare parts
215288050102B0	BUMPER PAINTED BLACK	TATA spare parts
215288050102C0	ASSY BUMPER WITH REFLECTOR - BLACK	TATA spare parts
215324200103	ASSY RUBBER SUPPORT RH REAR	TATA spare parts
215324200104	ASSY RUBBER SUPPORT LH REAR	TATA spare parts
215329100104	ASSY PIPE	TATA spare parts
215329100105	ASSY PIPE	TATA spare parts
215329100110	ASSY. BRAKE PEDAL LEVER COMPLETE	TATA spare parts
215329300102	ASSY.BRACKET	TATA spare parts
215331000101	ASSY FRAME	TATA spare parts
215331000102	ASSY FRAME LP 1109/42 TC BS-II	TATA spare parts
215331000103	ASSY FRAME LP 1109/36 TC	TATA spare parts
215331000107	ASSY FRAME LPT 1109/42	TATA spare parts
215331000108	FRAME ASSY WITH FITMENT	TATA spare parts
215331000110	ASSY.FRAME LPT 1109 / 36 MODIFIED	TATA spare parts
215331000111	ASSY.FRAME COMPLETE 1109 LP 42 60%	TATA spare parts
215331000112	FRAME ASSY	TATA spare parts
215331000120	ASSY FRAME WITH 7 THK LM 1109 LPT 36 EX	TATA spare parts
215331000121	ASSY. FRAME WITH 7 THK LM	TATA spare parts

215331000155	ASSY FRAME WITH LPT1613 LONG MEMBER	TATA spare parts
215331107160	EXTENSION PIECE L.H.	TATA spare parts
215331107161	EXTENSION PIECE R.H.	TATA spare parts
215331200101	ASSY.CROSS MEMBER	TATA spare parts
215331200102	ASSY CROSSMEMBER	TATA spare parts
215331200110	ASSY SUPPORT (REAR)LH	TATA spare parts
215331200111	ASSY. SUPPORT (REAR)RH	TATA spare parts
215331200112	ASSY. SUPPORT(FRT)LH	TATA spare parts
215331200113	ASSY SUPPORT (FRT) RH	TATA spare parts
215331207103	REINFORCEMENT LH (BOTTOM)	TATA spare parts
215331207104	REINFORCEMENT L.H. (BOTTOM)	TATA spare parts
215331207105	SUPPORT TOP RH	TATA spare parts
215331207106	SUPPORT TOP LH	TATA spare parts
215331700101	ASSY.BKT.COMPL.RH.	TATA spare parts
215331700102	ASSY.BKT.COMPL.LH	TATA spare parts
215331700103	ASSY TUBE	TATA spare parts
215331700108	ASSY.BKT.COMPL.RH	TATA spare parts
215331700109	ASSY.BKT.COMPL.LH.	TATA spare parts
215331700110	ASSY.FRAME LPT 1109 / 36 MODIFIED	TATA spare parts
215331700111	ASSY.FRAME LPT 1109 42 MODIFIED	TATA spare parts
215331700116	ASSY. FRAME COMPL. LPT1112 BSIII_36 WB	TATA spare parts
215331700120	ASSY.SIDE SHIELD RH ENG.ENCAP.(1109/1112	TATA spare parts
215331700121	ASSY.SHIELD CENT PIECE ENG ENCAP(1109/12	TATA spare parts
215331700122	ASSY.SIDE SHIELD LH ENG.ENCAP(1109/1112)	TATA spare parts
215331700123	ASSY.ENG.ENCAPSULATION COMPL.	TATA spare parts
215331700124	ASSY.BOTTOM SHIELD G/BOX(LP/LPT1109/1112	TATA spare parts
215331700134	ASSY.BOTTOM SHIELD(RAD.SIDE)1109/1112	TATA spare parts
215331700135	ASSY. SIDE SHIELD LH(CAB-BODY)1109/1112	TATA spare parts
215331700136	ASSY.BKT.RH (FRONT)	TATA spare parts
215331700137	ASSY.BKT.LH(FRT)	TATA spare parts
215331700138	ASSY.BKT.RH(REAR)	TATA spare parts
215331700139	ASSY.BKT.LH (REAR)	TATA spare parts
215331700141	ASSY CHANNEL(RUPD)	TATA spare parts
215331700142	ASSY. SIDE SHIELD RH(CAB-BODY)1109/1112	TATA spare parts
215331700143	ASSY AIR DEFLECTOR	TATA spare parts
215331700144	RADIATOR BOTTOM SHIELD MTG.BRACKET	TATA spare parts
215331700161	FRAME ASSY WITH FITMENT	TATA spare parts
215331700162	ASSY.BEAM FUPD	TATA spare parts
215331700165	ASSY.SUPPORT BRACKET (R.H)	TATA spare parts
215331700166	ASSY.SUPPORT BRACKET (L.H)	TATA spare parts
215331700171	ASSY BRACKET COMPLETE R.H.(RUPD)	TATA spare parts
215331700172	ASSY BRACKET COMPLETE L.H.(RUPD)	TATA spare parts
215331707115	BRACKET FOR GEAR BOX SHIELD	TATA spare parts
215331707116	BRACKET (FOR GB SHL) R.H	TATA spare parts
215331708207	BRACKET LH	TATA spare parts
215331708208	BRACKET LH	TATA spare parts
215331708210	BRACKET LH REAR FOR MTG. RAD.SHIELD	TATA spare parts

215331708217	BRACKET RH REAR FOR MTG. RAD.SHIELD	TATA spare parts
215332100102	ASSY FRONT SPRING	TATA spare parts
215332100104	FIRST LEAF WITH BUSH	TATA spare parts
215332100109	ASSY FRONT SPRING(DRIVER SIDE)	TATA spare parts
215332100111	ASSY.FRONT SPRING	TATA spare parts
215332100113	ASSY.FIRST LEAF WITH BUSH	TATA spare parts
215332100114	ASSY. FRONT SPRING VE (LH/RH)	TATA spare parts
215332100115	ASSEMBLY MAIN LEAF WITH BUSHES	TATA spare parts
215332100115DF	MAIN LEAF FRONT W/BUSH - LPT1109 HEX2	TATA spare parts
215332100127	ASSY BRACKET.RH (FRONT AXLE STOPPER)	TATA spare parts
215332100128	ASSY BRACKET LH ( FRONT AXLE STOPPER)	TATA spare parts
215332100134	SPRING ASSY FRONT VE (DRIVER SIDE)	TATA spare parts
215332100135	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
215332103202	CENTRE BOLT M12X1.75X160	TATA spare parts
215332104201	SPRING CLIP(FOR AUX. SPRING)	TATA spare parts
215332107112	SECOND LEAF	TATA spare parts
215332107113	THIRD LEAF	TATA spare parts
215332107114	FOURTH LEAF	TATA spare parts
215332107115	FIFTH LEAF	TATA spare parts
215332107116	SIXTH LEAF	TATA spare parts
215332107117	SEVENTH LEAF	TATA spare parts
215332107118	EIGHTH LEAF	TATA spare parts
215332107119	NINETH LEAF	TATA spare parts
215332107120	TENTH LEAF	TATA spare parts
215332107150	SECOND LEAF	TATA spare parts
215332107151	THIRD LEAF	TATA spare parts
215332107152	FOURTH LEAF	TATA spare parts
215332107153	FIFTH LEAF	TATA spare parts
215332107154	SIXTH LEAF	TATA spare parts
215332107155	SEVENTH LEAF	TATA spare parts
215332107156	EIGHTH LEAF	TATA spare parts
215332107157	NINETH LEAF	TATA spare parts
215332107158	TENTH LEAF	TATA spare parts
215332107159	ELEVENTH LEAF	TATA spare parts
215332107160	TWELVETH LEAF	TATA spare parts
215332107162	SECOND LEAF	TATA spare parts
215332107162DF	SECOND LEAF FRONT - LPT1109 EX2	TATA spare parts
215332107173	PACKING PLATE	TATA spare parts
215332107180	THIRD LEAF	TATA spare parts
215332107180DF	THIRD LEAF FRONT - LPT1109 HEX2	TATA spare parts
215332107181	FOURTH LEAF	TATA spare parts
215332107181DF	FOURTH LEAF FRONT - LPT1109 HEX2	TATA spare parts
215332107182	FIFTH LEAF	TATA spare parts
215332107182DF	FIFTH LEAF FRONT - LPT1109 HEX2	TATA spare parts
215332107183	SIXTH LEAF	TATA spare parts
215332107184	SEVENTH LEAF	TATA spare parts
215332107185	EIGHTH LEAF	TATA spare parts

215332107186	NINTH LEAF	TATA spare parts
215332117115	SECOND LEAF	TATA spare parts
215332117116	THIRD LEAF	TATA spare parts
215332117117	FOURTH LEAF	TATA spare parts
215332117118	FIFTH LEAF	TATA spare parts
215332117119	SIXTH LEAF	TATA spare parts
215332117120	SEVENTH LEAF	TATA spare parts
215332117121	EIGHTH LEAF	TATA spare parts
215332117122	NINTH LEAF	TATA spare parts
215332200101	ASSY FRONT BUMP STOPPER BS6	TATA spare parts
215332207101	CASTER PLATE	TATA spare parts
215332300101	ASSY BRACKET(L.H) FRONT SHOCK ABSORBER	TATA spare parts
215332300102	ASSY BRACKET (RH)	TATA spare parts
215332300105	ASSY FRONT SHOCK ABSORBER BRKT.(TOP)	TATA spare parts
215332303706	SHOCK ABSORBER MTG. BRKT FRT BOTTOM LH.	TATA spare parts
215332303707	SHOCK ABSORBER MTG.BRACKET FRONT BOTTON	TATA spare parts
215332308201	SHOCK ABSORBER BRACKET (BOTTOM LH)	TATA spare parts
215332308202	SHOCK ABSORBER BRACKET (BOTTOM RH)	TATA spare parts
215332400103	ASSY REAR SPRING WITH AUX SPRING	TATA spare parts
215332400104	ASSY FIRST LEAF WITH BUSH	TATA spare parts
215332400104DF	MAIN LEAF REAR W/BUSH - LPT1109 HEX2	TATA spare parts
215332400105	ASSY.REAR SPRING LPT 1109	TATA spare parts
215332400108	ASSY.REAR SPRING WITH AUX.SPRING	TATA spare parts
215332400109	ASSY REAR LEAF SPRING LPT 1109	TATA spare parts
215332403203	CENTRE PIN	TATA spare parts
215332407113	SECOND LEAF	TATA spare parts
215332407113DF	SECOND LEAF REAR - LPT1109 HEX2	TATA spare parts
215332407114	THIRD LEAF	TATA spare parts
215332407114DF	THIRD LEAF REAR - LPT1109 HEX2	TATA spare parts
215332407115	FOURTH LEAF	TATA spare parts
215332407116	FIFTH LEAF	TATA spare parts
215332407117	SIXTH LEAF	TATA spare parts
215332407118	SEVENTH LEAF	TATA spare parts
215332407119	FIRST LEAF AUX SPRING	TATA spare parts
215332407120	SECOND LEAF AUX SPRING	TATA spare parts
215332407121	THIRD LEAF AUX SPRING	TATA spare parts
215332407122	FOURTH LEAF AUX SPRING	TATA spare parts
215332407123	FIFTH LEAF AUX SPRING	TATA spare parts
215332407124	SIXTH LEAF AUX SPRING	TATA spare parts
215332407125	SEVENTH LEAF AUX SPRING	TATA spare parts
215332407126	EIGHTH LEAF AUX SPRING	TATA spare parts
215332407127	FIRST LEAF(AUX. SPRING)	TATA spare parts
215332407127DF	MAIN LEAF-AUX. SPRING - LPT1109 HEX2	TATA spare parts
215332407128	SECOND LEAF(AUX.SPRING)	TATA spare parts
215332407128DF	SECOND LEAF-AUX.SPRING-LPT1109 HEX2	TATA spare parts
215332407129	THIRD LEAF(AUX.SPRING)	TATA spare parts
215332407129DF	THIRD LEAF(AUX.SPRING)-LPT1109 HEX2	TATA spare parts

215332407130	FOURTH LEAF(AUX.SPRING)	TATA spare parts
215332407131	FIFTH LEAF(AUX.SPRING)	TATA spare parts
215332407132	SIXTH LEAF(AUX.SPRING)	TATA spare parts
215332407136	FOURTH LEAF	TATA spare parts
215332407136DF	FOURTH LEAF REAR - LPT1109 HEX2	TATA spare parts
215332407137	FIFTH LEAF	TATA spare parts
215332407138	SIXTH LEAF	TATA spare parts
215332407142	PACKING PLATE	TATA spare parts
215332506501	NUT	TATA spare parts
215333000101	ASSY.FRT.AXLE WITH S-CAM BRK.SPIG.COMPL.	TATA spare parts
215333000104	ASSY FRONT AXLE WITH S'CAM BRAKE COMP.	TATA spare parts
215333000108	ASSY.FRONT AXLE WITH S-CAM BRAKES.	TATA spare parts
215333000110	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
215333200101	ASSY.STUB AXLE NORMAL	TATA spare parts
215333200105	ASSY.STUB AXLE STD RH	TATA spare parts
215333200109	ASSY.STUB AXLE STD LH	TATA spare parts
215333200111	SET THRUST PAD (NORMAL)	TATA spare parts
215333200114	STUB AXLE ASSY ABS RH	TATA spare parts
215333200115	STUB AXLE ASSY ABS LH	TATA spare parts
215333203108	THURST BEARING NORMAL	TATA spare parts
215333203401	KING PIN BUSH	TATA spare parts
215333206702	KING PIN- NORMAL	TATA spare parts
215333400103	FRONT HUB ASSY	TATA spare parts
215333408301	SHIM FRONT AXLE	TATA spare parts
215333408302	SHIM FRONT AXLE	TATA spare parts
215333408303	SHIM FRONT AXLE	TATA spare parts
215333408304	SHIM	TATA spare parts
215333408305	SHIM	TATA spare parts
215333408306	SHIM	TATA spare parts
215333408307	SHIM-0.05 MM	TATA spare parts
215333408601	SPACER TUBE	TATA spare parts
215333408603	SPACER	TATA spare parts
215333800103	ASSY.TIE ROD	TATA spare parts
215333800112	TIE ROD END ASSY RH	TATA spare parts
215333800113	TIE ROD END ASSY LH	TATA spare parts
215333805103	STEERING ARM TOP	TATA spare parts
215333805104	STEERING ARM	TATA spare parts
215335103201	U-CLAMP (BANJO)	TATA spare parts
215340100104	ASSY. WHEEL RIM-6X20 134MM OFFSET	TATA spare parts
215340100105	ASSY.WHEEL RIM-6X20 134MM OFFSET	TATA spare parts
215340100106	ASSY.WHEEL RIM-6X20 134MM OFFSET.	TATA spare parts
215340100122	WHEEL RIM ASSY-OFFER DRG BS6	TATA spare parts
215340100123	WHEEL RIM ASSY	TATA spare parts
215340100124	ASSY. WHEEL RIM BS2/3/4	TATA spare parts
215340109929	LOCK RING	TATA spare parts
215340109930	LOCK RING	TATA spare parts
215340109942	LOCK RING	TATA spare parts

215340109943	FLANGE	TATA spare parts
215340109948	LOCK RING	TATA spare parts
215340300106	ASSY.SPARE WHEEL CARRIER	TATA spare parts
215340300108	WHEELDISC&RIM B6X20(SPIGOTED)	TATA spare parts
215340307101	SPACER PLATE	TATA spare parts
215340307102	SPACER(FOR SPARE WHEEL CARRIER)	TATA spare parts
215340307103	SPACER PLATE	TATA spare parts
215341100103	ASSY PROPELLER SHAFT WITH CENTRE BRG	TATA spare parts
215341100106	ASSY PROPELLER SHAFT REAR	TATA spare parts
215341110101	ASSY PROP SHAFT W CENTRE BRG 908L	TATA spare parts
215341110104	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
215341118201	SPACER CENTER BEARING MTG.BKT.	TATA spare parts
215341118202	SPACER CENTRE BRG MTG	TATA spare parts
215341120101	ASSY PROP SHAFT(REAR) 1280L	TATA spare parts
215341120105	ASSY. PROP. SHAFT REAR COMPL. 684MM	TATA spare parts
215341120106	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
215341120107	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
215342100101	BRAKE CHAMBER WITH ADAPTOR-TYPE-16	TATA spare parts
215342100109	ASSY.DRUM BRK.RH FRONT ASBESTOS	TATA spare parts
215342100112	ASSY.DRUM BRK.LH FRONT ASBESTOS	TATA spare parts
215342100122	FLANGE TUBE & BRACKET ASSY.LH	TATA spare parts
215342100123	FLANGE TUBE & BRACKET ASSY.RH	TATA spare parts
215342100124	LINED SHOE LH & RH STD. LPT1109	TATA spare parts
215342100125	KIT-LINING SET STD	TATA spare parts
215342100126	KIT-LINING SET(1.0 MM O/S)-R/S I	TATA spare parts
215342100127	KIT-LINING SET (2.0 MM O/S) R/S II	TATA spare parts
215342100140	BRAKE ASSY FRONT AXLE LH W/T D/C.	TATA spare parts
215342100141	BRAKE ASSY FRONT AXLE RH W/T D/C.	TATA spare parts
215342100142	BRAKE ASSY FRONT AXLE RH W/T D/C.	TATA spare parts
215342100143	BRAKE ASSY FRONT AXLE LH W/T D/C.	TATA spare parts
215342103701	TORQUE PLATE LH	TATA spare parts
215342103702	TORQUE PLATE RH	TATA spare parts
215342103703	BRAKE ASSY TORQUE PLATE LH	TATA spare parts
215342103704	BRAKE ASSY TORQUE PALTE RH	TATA spare parts
215342108201	ANCHOR BRACKET ASA RH	TATA spare parts
215342108202	ANCHOR BRACKET ASA LH	TATA spare parts
215342300101	ASSY.DRUM BRAKE RH REAR -ASBESTOS TYPE	TATA spare parts
215342300103	ASSY.DRUM BRAKE LH REAR -ASBESTOS TYPE	TATA spare parts
215342300105	ASSY BRACKET L.H (16/24 BRK CHAMBER MTG)	TATA spare parts
215342300106	ASSY BRACKET R.H(16/24 BRK CHAMBER MTG)	TATA spare parts
215342300108	SLACK ADJUSTER R.H	TATA spare parts
215342300109	SLACK ADJUASTER L.H	TATA spare parts
215342300110	SPR.BRK.ACTUATOR R.H	TATA spare parts
215342300111	SPR.BRK.ACTUATOR L.H	TATA spare parts
215342300117	REPAIR KIT	TATA spare parts
215342300120	SLACK ADJUSTER RH	TATA spare parts
215342300121	SLACK ADJUSTER LH	TATA spare parts



215342300124	SLACK ADJUSTER LH	TATA spare parts
215342300125	SLACK ADJUSTER R.H	TATA spare parts
215342300126	SLACK ADJUSTER(LH)	TATA spare parts
215342300127	SLACK ADJUSTER(RH)	TATA spare parts
215342300130	SPRING BRAKE ACTUATOR RH (TYPE 16/24)	TATA spare parts
215342300131	SPRING BRAKE ACTUATOR LH(TYPE 16/24)	TATA spare parts
215342300132	ASSY BRACKET LH (FOR 16/24 STRAIGHT PORT	TATA spare parts
215342300133	ASSY BRACKET RH (FOR 16/24 STRAIGHT PORT	TATA spare parts
215342400102	ASSY PULL ROD	TATA spare parts
215342400103	BRACKET FOR PULL ROD	TATA spare parts
215342407102	BRACKET FOR LCRV MTG	TATA spare parts
215342806501	HEX NUT W/C M12X1.5-IS7795-12-SS8451	TATA spare parts
215342900111	ASSY.TUBE	TATA spare parts
215342900143	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
215342900155	ASSY.NYLON PIPE SET COMPL.	TATA spare parts
215342900160	ASSY.NYLON PIPE SET COMPL.	TATA spare parts
215342910125	ASSY.PIPE	TATA spare parts
215342910126	SET.ASSY.NYLON PIPE COMPLETE	TATA spare parts
215342910158	SET ASSY.PIPE NYLON LP/LPT1109/36	TATA spare parts
215342910159	SET ASSY.NYLON PIPE LP/LPT1109/42	TATA spare parts
215342990132	BRAKE SUPPORT TUBE FLNG & BRKT ASSY-LH	TATA spare parts
215342990133	BRAKE SUPPORT TUBE FLNG & BRKT ASSY-RH	TATA spare parts
215342990138	KIT LINED SHOE	TATA spare parts
215342990139	BRAKE SUPPORT LINED SHOE ASSY BS2/3/4	TATA spare parts
215342990140	KIT-CAMSHAFT	TATA spare parts
215342990141	KIT-CAMSHAFT	TATA spare parts
215342990142	KIT DUST SHIELD ASSY	TATA spare parts
215342990143	KIT BUSH (WITH BRACKET VERSION)	TATA spare parts
215342990145	KIT SEAL ACTUATOR	TATA spare parts
215342990152	KIT CAP PROTECTIVE ADJUSTER	TATA spare parts
215342990153	BUSH KIT	TATA spare parts
215342990158	KIT BOOT	TATA spare parts
215342990159	KIT BOLT	TATA spare parts
215342990160	KIT PWWI - VISUAL	TATA spare parts
215342990165	KIT BUSH	TATA spare parts
215342990201	REPAIR KIT (SBA TYPE 16/24)	TATA spare parts
215343200108	ASSY AIR TANK WITH SUPPORT STRAP SPACER	TATA spare parts
215343200109	ASSY.AIR TANK COMPLETE WITH SUPPORT SPAC	TATA spare parts
215343206101	LOCK PLATE R.H (FOR AIR TANK MTG)	TATA spare parts
215343206102	LOCK PLATE L.H (FOR AIR TANK MTG)	TATA spare parts
215343700101	SPRING BRAKE ACTUATOR RH(16/24)VOSS	TATA spare parts
215343700102	SPRING BRAKE ACTUATOR(16/24)VOSS SCL	TATA spare parts
215343900140	ASSY NYLON PIPE SET CHASSIS COMPL 42WB	TATA spare parts
215343900143	ASSY NYLON PIPE SET CHASSIS COMPL 36WB	TATA spare parts
215343900145	ASSY METAL PIPE WITH CRIMPED HOSE	TATA spare parts
215343900153	ASSY METAL PIPE DIA15(COMP TO DDU)	TATA spare parts
215343900154	PIPE BUNCH ASSY	TATA spare parts

215343900155	ASSY NYLON PIPE SET CHASSIS COMPL-36WB	TATA spare parts
215343900157	ASSY NYLON PIPE CHASSIS COMPL LPT1109/36	TATA spare parts
215343900160	ASSY NYLON PIPE SET CHASSIS COMPL 42WB	TATA spare parts
215343900162	ASSY METAL PIPE (FROM DDU TO COMP)	TATA spare parts
215343900163	ASSY METAL PIPE WITH CRIMP HOSE	TATA spare parts
215343900165	ASSY BKT(HOSE MTG.ON REAR BANJO AXLE)	TATA spare parts
215343900235	PIPE BUNCH ASSY	TATA spare parts
215343908201	PLATE¿ BS6	TATA spare parts
215343910146	ASSY METAL PIPE(FROM COMPRESSOR TO DDU)	TATA spare parts
215343910149	ASSY NYLON PIPE CHASSIS COMPL LPT1109/42	TATA spare parts
215343910155	ASSY METAL PIPE DIA15(COPMRESSOR TO DDU)	TATA spare parts
215343920101	METAL PIPE ASSY HOSE TO COUPLING	TATA spare parts
215343920102	METAL PIPE ASSY COUPLING TO DDU	TATA spare parts
215343920103	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
215343920104	METAL PIPE ASSY HOSE TO COUPLING	TATA spare parts
215343920105	METAL PIPE ASSY COUPLING TO DDU	TATA spare parts
215343920106	METAL PIPE ASSY COUPLING TO DDU	TATA spare parts
215343920107	METAL PIPE ASSY COUPLING TO DDU	TATA spare parts
215346106301	RUBBER BELLOW FLOOR	TATA spare parts
215346108201	CLAMPING RING (RUBBER BELLOW FLOOR)	TATA spare parts
215346200101	ASSY. POWER STG GEAR BOX LPT1109 BS2/3/4	TATA spare parts
215346200105	STRG GEAR BOX WITH NRB WITH P.ARM & UJ	TATA spare parts
215346200107	ASSY STEERING WORM WITH NUT LPT909	TATA spare parts
215346200114	ASSY SIDE COVER WITH BUSH	TATA spare parts
215346200115	ASSY GEAR BOX HOUSING (WITH BUSH)LH	TATA spare parts
215346200124	KIT FOR WORM &MAIN NUT ASSY	TATA spare parts
215346200127	ASSY BRACKET (FOR P. STG.)	TATA spare parts
215346200129	ASSY BRACKET	TATA spare parts
215346200133	ASSEMBLY BRACKET POWER STEERING GB MOUN	TATA spare parts
215346200135	ASSEMBLY MOUNTING BRACKET POWER STRG	TATA spare parts
215346200144	HOUSING ASSY	TATA spare parts
215346200145	HOUSING COVER ASSY	TATA spare parts
215346200146	SECTOR SHAFT ASSY	TATA spare parts
215346200147	PISTON ASSY	TATA spare parts
215346200148	COMPLETE SEALING KIT	TATA spare parts
215346200149	SMALL COMPONENT SET	TATA spare parts
215346200150	ASSY. UNIVERSAL JOINT	TATA spare parts
215346203101	ANGULAR CONTACT BEARING	TATA spare parts
215346203201	ADJUSTING SCREW	TATA spare parts
215346203203	ADJUSTER	TATA spare parts
215346203204	BOLT-COVER PLATE	TATA spare parts
215346203403	BUSH BEARING	TATA spare parts
215346203404	BUSH	TATA spare parts
215346203405	BUSH	TATA spare parts
215346204703	DUST COVER	TATA spare parts
215346204704	DUST CAP	TATA spare parts
215346205301	GASKET SIDE COVER	TATA spare parts

215346206507	LOCK NUT	TATA spare parts
215346206508	LOCK NUT-ADJUSTER	TATA spare parts
215346206509	LOCK NUT-SECTOR SHAFT	TATA spare parts
215346206510	LOCK NUT-SCREW PLUG	TATA spare parts
215346207202	OIL PLUG-DRAIN	TATA spare parts
215346207203	OIL PLUG-FILLER	TATA spare parts
215346207205	BREATHER PLUG	TATA spare parts
215346207802	OIL SEAL	TATA spare parts
215346207803	OIL SEAL-WORM	TATA spare parts
215346207804	OIL SEAL-SECTOR SHAFT	TATA spare parts
215346207906	SECTOR SHAFT	TATA spare parts
215346207909	STEERING SPINDLE SLEEVE MIDDLE	TATA spare parts
215346207912	SECTOR SHAFT	TATA spare parts
215346208203	BALL GUIDE HALF	TATA spare parts
215346208601	SPACER	TATA spare parts
215346208602	SPACER	TATA spare parts
215346208603	SPACER	TATA spare parts
215346209202	LOCK WASHER	TATA spare parts
215346209204	TAB WASHER-SECTOR SHAFT	TATA spare parts
215346209205	TAB WASHER-SCREW PLUG	TATA spare parts
215346209206	WASHER-ADJUSTER	TATA spare parts
215346209207	SPRING WASHER-COVER PLATE	TATA spare parts
215346209208	WASHER-OIL PLUG	TATA spare parts
215346209209	SPRING WASHER	TATA spare parts
215346306001	PITMAN ARM	TATA spare parts
215346306002	PITMAN ARM	TATA spare parts
215346600101	ASSY.DRAG LINK	TATA spare parts
215346600104	ASSY. DRAG LINK-RHD BS2/3/4	TATA spare parts
215346600106	DRAG LINK ASSY RHD	TATA spare parts
215346600107	ROTOR SET	TATA spare parts
215346603701	HOUSING	TATA spare parts
215346606501	LOCKNUT BS6	TATA spare parts
215346606601	PISTON BS6	TATA spare parts
215346607801	SHAFT SEAL	TATA spare parts
215346607803	OILSEAL WORM BS6	TATA spare parts
215346607901	SHAFT	TATA spare parts
215346609203	SPRINGWASHER BS6	TATA spare parts
215346800101	RETURN LINE HOSE ASSY. STRG PUMP TO CONT	TATA spare parts
215346800102	SUCTION LINE HOSE ASSY.	TATA spare parts
215346800103	PRESSURE LINE HOSE ASSY. STRG PUMP TO ST	TATA spare parts
215346800105	VANE&PUMP	TATA spare parts
215346800106	ASSY. PRESSURE LINE-CRIMPED (PUMP TO GB)	TATA spare parts
215346800107	ASSY SUCTION LINE-CRIMPED (RESERVOIR TO	TATA spare parts
215346800108	ASSY PRESSURE LINE-CRIMPED (PUMP TO GEAR	TATA spare parts
215346800109	ASSY. RETURN LINE-CRIMPED GEAR BOX TO R	TATA spare parts
215346800118	ASSY. PRESSURE LINE-CRIMPED (PUMP TO GB)	TATA spare parts
215346800119	ASSY. RETURN LINE-CRIMPED (GB TO TANK)	TATA spare parts

215346800122	ASSY.SUCTION LINE(RESERVOIR TO PUMP)	TATA spare parts
215346800123	ASSY PRESSURE LINE(PUMP TO GEAR BOX)	TATA spare parts
215346800124	ASSY RETURN LINE(RESERVOIR TO PUMP)	TATA spare parts
215346800130	SUCTION LINE ASSY	TATA spare parts
215346800131	PRESSURE LINE ASSY	TATA spare parts
215346800132	RETURN LINE ASSY	TATA spare parts
215346900101	DRAG LINK END ASSY	TATA spare parts
215347600103	ASSY.HOSE FEED PUMP TO SUCTION PIPE	TATA spare parts
215347600105	ASSY PIPE	TATA spare parts
215347600107	FUEL SUCTION LINE	TATA spare parts
215347600108	FUEL RETURN LINE	TATA spare parts
215347600109	ASSY.BRACKET(FOR WATER SEPERATOR)	TATA spare parts
215347600110	ASSY FUEL LINE(SUCTION)	TATA spare parts
215347600111	ASSY.FUEL LINE(SUCTION)	TATA spare parts
215347600112	ASSY.FUEL LINE(RETURN)	TATA spare parts
215347600113	ASSY. SUCTION LINE(TANK TO STRAINER)	TATA spare parts
215347600114	ASSY SUCTION LINE(STRAINER TO W/SEP)	TATA spare parts
215347600115	ASSY.SUCTION LINE(W/SEP TO FEED PUMP)	TATA spare parts
215347600116	ASSY RETURN LINE(ENGINE O/FLOW TO TANK)	TATA spare parts
215347600119	ASSY RETURN LINE(ENGINE O/FLOW TO TANK)	TATA spare parts
215347990104	RETRO KIT OF WATER SEPARATOR FOR LPT1109	TATA spare parts
215349200101	ASSY.EXHAUST PIPE FRONT	TATA spare parts
215349200102	ASSY.EXH.INTERMEDIATE PIPE	TATA spare parts
215349200103	ASSY.EXHAUST PIPE FRONT.	TATA spare parts
215349200104	ASSY EXHAUST INTERMEDIATE PIPE	TATA spare parts
215349200107	ASSY EXHAUST INTERMEDIATE PIPE	TATA spare parts
215349200112	ASSY.FRONT PIPE (FOR BS-II)LPT1109	TATA spare parts
215349200113	ASSY. BRACKET (FRONT SILENCER MTG) RH	TATA spare parts
215349200114	ASSY EXHAUST PIPE FRONT(WITH FLEX BELLOW	TATA spare parts
215349206910	EXHAUST TAIL PIPE	TATA spare parts
215349206911	EHXAUST TAIL PIPE	TATA spare parts
215354100102	ASSY.BATT.CU.CABLE 900MM W/COT 35SQ	TATA spare parts
215354100103	ASSY.BATT.CU.CABLE -VE 975MM W/COT 35SQ	TATA spare parts
215354100104	ASSY.BATT.CABLE 2650MM 50SQ.MM.LPT1116 (	TATA spare parts
215354100105	ASSY.BATT.CABLE 2400MM 50SQ.MM LPT1116 (	TATA spare parts
215354100107	ASSY. BATT. CABLE +VE 1250MM W/COT TUBE	TATA spare parts
215354100108	ASSY. BATT. CABLE -VE 1050MM W/COT TUBE	TATA spare parts
215354100116	ASSY.BOTTOM PLATE WITH LOCATING PIN 100A	TATA spare parts
215354100117	BOTTOM PLATE WITH LOCATING PIN SF 100AH	TATA spare parts
215354108201	BOTTOM PLATE 100AH AMARON BS6	TATA spare parts
215354108202	CLAMP STRAP SF 100AH	TATA spare parts
215354108203	CLAMPING STRAP 100AH AMARON	TATA spare parts
215354108205	INTERMEDIATE BRKT_SF100AH	TATA spare parts
215354200106	INST.CLUST.1:1.035 PTO FOG LPT1109	TATA spare parts
215354200121	INST.CLUSTER 0.72 ESPEEDO LPT1112	TATA spare parts
215354200136	INST.CLUSTER 0.85 LPT1109 EX2	TATA spare parts
215354200140	ASSY.SEAT BELT WAR.&CAB TILT WARNING ALA	TATA spare parts

215354209901	INSTRUMENT CLUSTER (1: 0.88)	TATA spare parts
215354209904	INSTRUMENT CLUSTER (1:0.88)	TATA spare parts
215354209909	INSTRUMENT CLUSTER (1: 0.88)	TATA spare parts
215354400103	ASSY.TAIL LAMP BKT.LH	TATA spare parts
215354400104	ASSY.TAIL LAMP BKT.RH	TATA spare parts
215354400115	ASSY 5 CH. TAIL LAMP MTG BKT MAIN LH	TATA spare parts
215354400117	ASSY 5 CH. TAIL LAMP MTG BKT MAIN RH	TATA spare parts
215354601619	W/H MAIN LPT1116 24V EII RHD	TATA spare parts
215354620101	W/H-MAIN-LPT-1109 BS-II	TATA spare parts
215354620103	W/H-MAIN LP-1109 BS-II M/S MSSL	TATA spare parts
215354620105	W/H-TAIL LP/LPT-1109/42 BS-II	TATA spare parts
215354620106	W/H-ENGINE LP/LPT-1109 BS-II	TATA spare parts
215354620120	WIRING HARNESS TAIL	TATA spare parts
215354620121	WIRING HARNESS ENGINE	TATA spare parts
215354620123	W/H MAIN LPT1116 24V EII RHD	TATA spare parts
215354620127	W/H TAIL LPT1112/42WB BSIII	TATA spare parts
215354620128	W/H TAIL LPT1112/36WB BSIII	TATA spare parts
215354620129	W/H MAIN LPT1116/42WB LHD 24V E-II	TATA spare parts
215354620130	W/H TAIL LP/LPT1116/42WB	TATA spare parts
215354660117	W/H MAIN LPT1116 24V EII RHD	TATA spare parts
215354690129	WIRING HARNESS PIGTAIL PARKING & SEAT BE	TATA spare parts
215354820108	W/H MAIN -LP/LPT1109	TATA spare parts
215354820109	W/H TAIL--36 WB	TATA spare parts
215354820111	W/H TAIL--42 WB	TATA spare parts
215354820120	W/H MAIN-LPT /LP 1109 E-II	TATA spare parts
215354820121	W/H-MAIN.LPT/LPT-1109 BS-II INST C	TATA spare parts
215355100103	MASCOT ASSY	TATA spare parts
215358400101	ASSY.KIT FOR HAND TOOLS	TATA spare parts
215360000102	ASSY CAB COMPLETE LPT1109 W/PSTRG	TATA spare parts
215360000104	ASSY COWL COMPLETE LP1109 SCAM RHD	TATA spare parts
215360000105	ASSY BARE COWL LP1109 SCAM	TATA spare parts
215360000108	ASSY. CAB SHELL PAINTED	TATA spare parts
215360000111	ASSY.CAB COMPLETE	TATA spare parts
215360000116	ASSY COWL COMPLETE LP1109/36 BSII	TATA spare parts
215360000117	ASSY CAB COMPLETE -LPT1109 EX	TATA spare parts
215360000118	ASSY CAB COMPLETE	TATA spare parts
215360000118RF	ASSY CAB COMPLETE	TATA spare parts
215360000119	ASSY CAB SHELL PAINTED	TATA spare parts
215360000119RF	ASSY CAB SHELL PAINTED	TATA spare parts
215360000134	ASSY.CAB COMPLETE-RHD	TATA spare parts
215360000135	ASSY.BODY SHELL PAINTED-RHD 1116	TATA spare parts
215360000143	ASSY CAB SHELL PAINTD-1109 (12.5T GVW)	TATA spare parts
215360000144	ASSY CAB COMPLETE-1109 (12.5T GVW)	TATA spare parts
215360000146	ASSY CAB COMPLETE 1109 NEW	TATA spare parts
215360000149	ASSY.BODYSHELL PAINTED RHD	TATA spare parts
215360000151	ASSY.CAB COMPLETE-RHD (1109EX2)	TATA spare parts
215360000153	ASSY CAB SHELL PAINTED	TATA spare parts

215360000156	PARTIALLY FITTED CAB W/O ELECT&CONTROLS	TATA spare parts
215360000157	ASSY. CABIN BARE LPT 1109 EX CLB BS3	TATA spare parts
215360000160	ASSY.CAB COMPLETE 1109 EX2 BS3 SLPR	TATA spare parts
215360000161	ASSY.CAB COMPLETE 1109 H EX2 BS3 CRDI	TATA spare parts
215360000173	ASSY. CABIN BARE NSLPR TCAB BLW BS3/4	TATA spare parts
215360000173AWBL	BARE CAB-LPK1212/LPT1512 ARTIC WHITE BL	TATA spare parts
215360000173BRBL	BARE CAB-LPK1212/LPT1512 BRICK RED BLW	TATA spare parts
215360000174	PARTIALLY FITTED CAB W/O ELECT&CONTROLS	TATA spare parts
215360000174BRBL	CAB PARTIALLY FITTED LPK1212/LPT1512 BR	TATA spare parts
215360000181	CAB SHELL ASSY PAINTED	TATA spare parts
215360000183	ASSY. CABIN WITHOUT FITMENTS BS3/4	TATA spare parts
215360000183BRNB	CAB PARTIALLY FITTED LPT1412 BR NB	TATA spare parts
215360000183GBNB	CAB PARTIALLY FITTED LPT1412 GB NB	TATA spare parts
215360000184	CAB ASSY	TATA spare parts
215360000185	BODY SHELL ASSY PAINTED	TATA spare parts
215360000195	CAB SHELL ASSY PAINTED	TATA spare parts
21536000Z134	ASSY.CAB COMPLETE 1116 RHD WITH H/D	TATA spare parts
21536000Z135	ASSY CAB SHELL PAINTED(BARE CAB)	TATA spare parts
21536000Z142	ASSY.CAB COMPLETE-RHD (1116/48WB)	TATA spare parts
21536000Z143	ASSY.BODY SHELL PAINTED-RHD(BARE CAB)	TATA spare parts
21536000Z153	ASSY BODY SHELL COMPLETE - LHD 1116 EX2	TATA spare parts
21536000Z154	ASSY BODY SHELL PAINTED- LHD 1116 EX2	TATA spare parts
21536000Z155	ASSY CAB W/PARTIAL FITMENTS LHD LPT1116	TATA spare parts
215360010102	ASSY. CAB SHELL PAINTED BS3/4	TATA spare parts
215360010102BRBL	BARE CAB-LPT1412 BRICK RED BLW	TATA spare parts
215360010102GBBL	BARE CAB-LPT1412 GOLDEN BROWN BLW	TATA spare parts
215360010117	CAB SHELL PAINTED	TATA spare parts
215360010117BRNB	BARE CAB-LPT1412 BRICK RED NB	TATA spare parts
215360010117GBNB	BARE CAB-LPT1412 GOLDEN BROWN NB	TATA spare parts
215360010130	BODY SHELL ASSY PAINTED BS6	TATA spare parts
215360010139	CAB (SLEEPER) BS6	TATA spare parts
215360100104	ASSY DASHBOARD CROSS MEMBER(LPK1109)	TATA spare parts
215360100105	ASSY. D.B CR.MEMBER RHD.(W/O HAND BRAKE)	TATA spare parts
215360108201	STEP BOARD.	TATA spare parts
215360CK0197	CAB KIT-LPT 1109/42WB EX2 497TCIC BS-II	TATA spare parts
215360CK0199	CAB KIT-ALL 1109 EX VEHICLES	TATA spare parts
215361000110	ASSY SUBSTR. WITH FLR & W/O STEP PNL-LHD	TATA spare parts
215361000115	ASSY SUB-STR W/FLR W/O STEP PANEL	TATA spare parts
215361000119	SUBSTRUCTURE ASSY WITH FLOOR	TATA spare parts
215362600110	INNER PANEL & FIREWALL ASSY	TATA spare parts
215363000107	ASSY SIDE WALL COMPLETE - LH	TATA spare parts
215363000108	ASSY SIDE WALL COMPLETE - RH	TATA spare parts
215368400101	ASSY. PVC FLOOR MAT - RHD (LPT 1116)	TATA spare parts
215368400102	ASSY. PVC FLOOR MAT - LHD (LPT 1116)	TATA spare parts
215368400103	ASSY FLOOR MAT-RHD LPT-LCV BS-IV	TATA spare parts
215368400109	FLOOR MAT ASSY	TATA spare parts
215368900102	ASSY DASH BOARD COMPLTE(RHD)	TATA spare parts

215368900105	KIT-NACELLE	TATA spare parts
215370000101	ASSY. LOADBODY COMPLETE.	TATA spare parts
215370000119	ASSY.LOAD BODY 1109 36 EXP DSLB	TATA spare parts
215370100103	ASSY.LONG RUNNER R.H. 42 WB	TATA spare parts
215370100104	ASSY.LONG RUNNER L.H. 42 WB	TATA spare parts
215370100133	KIT ASSY. SUPD	TATA spare parts
215370100134	KIT ASSY. SUPD	TATA spare parts
215370200102	ASSY.FRONT PANEL COMPL.WITH LOADGUARD.	TATA spare parts
215370506301	MUDFLAP LH REAR - SPRAY SUPPRESSION	TATA spare parts
215370506302	MUDFLAP RH REAR - SPRAY SUPPRESSION	TATA spare parts
215370506303	MUD FLAP REAR-LH (SPRAY SUPPR.)	TATA spare parts
215370506304	MUD FLAP REAR-RH (SPRAY SUPPSN.)	TATA spare parts
215370813201	U-BOLT	TATA spare parts
215372200101	ASSY. DOOR SHELL LH BS1/2/3/4	TATA spare parts
215372700101	ASSY PADDING DOOR R.H.	TATA spare parts
215372700102	ASSY PADDING DOOR L.H.	TATA spare parts
215372700104	ASSY PADDING DOOR R.H.	TATA spare parts
215372700105	ASSY PADDING DOOR L.H.	TATA spare parts
215381000103	ASSY.KIT FOR RVM COMPL	TATA spare parts
215381000104	ASSY.KIT REAR VIEW MIRROR OUTSIDE COMPLT	TATA spare parts
215381000106	ASSY KIT RVM COMPL	TATA spare parts
215381060101	ASSY. STEP ADDITIONAL.	TATA spare parts
215381100199	ASSY FRAME COMPLETE-RVM	TATA spare parts
215381106901	GRAB HANDLE L.H.	TATA spare parts
215381106902	GRAB HANDLE R.H.	TATA spare parts
215381800101	ASSY. MASCOT 1109.	TATA spare parts
215381800102	MASCOT 1109 TC	TATA spare parts
215381800103	ASSY 1109 EX TURBO MASCOT	TATA spare parts
215381800106	ASSY 1109 EX2 TURBO MASCOT	TATA spare parts
215381800108	MASCOT ASSY	TATA spare parts
215381900101	ASSY.MASCOT 1116 EX	TATA spare parts
215381906301	COVER STEP BOARD	TATA spare parts
215388200101	ASSY.FENDER LH	TATA spare parts
215388200102	ASSY.FENDER RH	TATA spare parts
215388500109	ASSY. BUMPER COMPLETE BS2/3/4	TATA spare parts
215388500128	ASSY.BRACKET LH (BUMPER MTG)	TATA spare parts
215388500129	ASSY.BRACKET RH (BUMPER MTG.)	TATA spare parts
215388500130	ASSY BRACKET LH(BUMPER MTG.)	TATA spare parts
215388500131	ASSY BRACKET RH(BUMPER MTG.)	TATA spare parts
215388500132	ASSY.BRACKET RH (BUMPER MTG)	TATA spare parts
215388500133	ASSY.BRACKET LH (BUMPER MTG)	TATA spare parts
215389100101	ASSY.MTG.BKT.BOTTOM LH RHD FRT LPT1109	TATA spare parts
215389100102	ASSY.SUPPORT STAY REAR(FOR FLOOR).	TATA spare parts
215389100103	ASSY.SUPPORT STAY REAR(FOR AUX. TANK).	TATA spare parts
215389100106	ASSY.ENGINE SHIELDING LH	TATA spare parts
215389100107	ASSY.ENGINE SHIELDING RH	TATA spare parts
215389100110	ASSY.MUDFLAP FRONT OUTER LH	TATA spare parts

215389100111	ASSY.MUDFLAP FRONT OUTER RH	TATA spare parts
215389100112	ASSY.NOISE SHIELD FRONT LH	TATA spare parts
215389100113	ASSY. NOISE SHIELD FRONT RH	TATA spare parts
215389100114	ASSY.TIE MEMBER (REAR MTG)-1116 CAB	TATA spare parts
215389100115	ASSY.CAB STAY COMPLETE - 1116	TATA spare parts
215389100117	ASSY.ENGINE SHIELDING LH	TATA spare parts
215389100118	ASSY.ENGINE SHIELDING RH	TATA spare parts
215389100119	ASSY.MUDFLAP FRONT OUTER-LH	TATA spare parts
215389100120	ASSY.MUDFLAP FRONT OUTER-RH	TATA spare parts
215389100122	ASSY HANDLE MOUNTING	TATA spare parts
215389100123	ASSY MTG BRKT COMPLETE RH (CHASSIS SIDE)	TATA spare parts
215389100124	ASSY MTG BRKT BOTTOM LH RHD FRT	TATA spare parts
215389100125	ASSY MTG BRKT BOTTOM RH RHD FRT	TATA spare parts
215389100126	ASSY.BRKT CYLINDER MTG BOTTOM	TATA spare parts
215389100128	ASSY.STAY COMPLETE	TATA spare parts
215389100135	ASSY.ENGINE SHIELDING-RH	TATA spare parts
215389100138	ASSY SUPPORT BOTTOM (MUDGUARD).	TATA spare parts
215389100140	ASSY.MUDFLAP FRONT INNER COMPLETE-LH	TATA spare parts
215389100141	ASSY.MUDFLAP FRONT INNER COMPLETE-RH	TATA spare parts
215389100144	ASSY TIE MEMBER(LPK1109)	TATA spare parts
215389106303	MUDGUARD LH. LPT 1109	TATA spare parts
215389106304	MUDGUARD RH. LPT 1109	TATA spare parts
215389106305	MUD FLAP FRONT	TATA spare parts
215389106309	MUDFLAP FRONT (SPRAY SUPPSN.)	TATA spare parts
215389106310	MUDGUARD-LH	TATA spare parts
215389106311	MUDGUARD-RH	TATA spare parts
215389106313	MUDFLAP - LH (SPRAY SUPPRESSION)	TATA spare parts
215389106314	MUDFLAP - RH (SPRAY SUPPRESSION)	TATA spare parts
215389108201	PACKING 1.6 THK. BS6	TATA spare parts
215389108202	PACKING 2.5 THK. BS6	TATA spare parts
215389108203	PACKING 1.6 THK. BS6	TATA spare parts
215389108204	PACKING 5 THK. BS6	TATA spare parts
215389110103	ASSY.MUDGUARD MTG.BRKT COMPLETE-LH	TATA spare parts
215389110104	ASSY.MUDGUARD MTG.BRKT COMPLETE-RH	TATA spare parts
215391000101	ASSY. DRIVER SEAT	TATA spare parts
215391000102	ASSY.DRIVER SEAT	TATA spare parts
215391000103	ASSY.DRIVER SEAT WITH HEAD REST	TATA spare parts
215391000110	ASSY.DR.SEAT W/O H.REST-RH-VINYL-TJC	TATA spare parts
215391100105	SEAT BOX ASSY DRIVER SEAT	TATA spare parts
215394000104	ASSY.CO-DRIVER SEAT WITH HR COMPL.	TATA spare parts
215394000106	ASSY.CO-DRIVER SEAT WITH HR COMPL.	TATA spare parts
215394000107	ASSY.CO-DRIVER SEAT WITH HR COMPL.	TATA spare parts
215394000112	ASSY.DR.SEAT W/O H.REST-LH-VINYL	TATA spare parts
215394000114	CO-DRIVER SEAT ASSY WITH HEADREST	TATA spare parts
215394000115	CO-DRIVER SEAT ASSY WITH HEADREST S/RHD	TATA spare parts
215424100101	ASSY. BRACKET -RH (ENG.MTG.FRONT)	TATA spare parts
215424100102	ASSY. BRACKET -LH (ENG.MTG.FRONT)	TATA spare parts



215424105101	FRONT ENG MTG ARM(FORGED FOR 4 PT MTG)RH	TATA spare parts
215424105102	FRONT ENG MTG ARM(FORGED FOR 4 PT MTG)LH	TATA spare parts
215424200101	ASSY. BRACKET ENG. MTG. RH REAR	TATA spare parts
215424200102	ASSY. BRACKET ENG. MTG. LH REAR	TATA spare parts
215424200103	ASSY.BRACKET(ENGINE MTG.REAR TOP)	TATA spare parts
215424200105	ASSY.BRACKET (ENG.MTG.BOTTOM)	TATA spare parts
215426800101	ASSY BRACKET (GEAR SHIFT LINKAGE MTG )	TATA spare parts
215426800108	ASSY TURNING TUBE WITH FORK(LHD)-W/O BAL	TATA spare parts
215426800111	ASSY BRACKET COMPLETE (LHD)	TATA spare parts
215426800116	ASSY TURNING TUBE (W/O BALL JOINT)	TATA spare parts
215426800118	ASSY TURNING TUBE	TATA spare parts
215426800120	ASSY BKT (G.S.LEVER MTG)	TATA spare parts
215428100102	ASSY CABLE 2000MM	TATA spare parts
215428100104	ASSY CABLE 2200MM	TATA spare parts
215428450108	BRACKET REAR TRANSFER CABLE MOUNTING	TATA spare parts
215428450112	ASSY. BRACKET (FOR AGB LEVER MTG.)	TATA spare parts
215428450114	BELLOW LPTA 713 TC	TATA spare parts
215428450115	ASSY. BRACKET	TATA spare parts
215428450117	ASSY BRACKET (AGB LEVER MTG)	TATA spare parts
215428450118	ASSY AGB LEVER COMPLETE	TATA spare parts
215428450120	ASSY AGB BRACKET(FOR LEVER MTG)	TATA spare parts
215428450123	ASSY.LEVER COMPLETE	TATA spare parts
215428450124	ASSY BRACKET REAR(AGB PULL CABLE)	TATA spare parts
215428456003	SHIFTER SHAFT DISTRIBUTOR GEAR	TATA spare parts
215428456004	PNEUMATIC CYLINDER ASSY	TATA spare parts
215428457107	SPACER	TATA spare parts
215428457108	SPACER ( AGB MTG)	TATA spare parts
215428457502	RUBBER SLEEVE	TATA spare parts
215428458219	CLAMP	TATA spare parts
215428459902	FORK HEAD	TATA spare parts
215429100101	ASSY PIPE 6 DIA X 750 LG LPTA 713 TC	TATA spare parts
215429100102	ASSY PIPE 6 DIA X 1470 LG LPTA 713 TC	TATA spare parts
215429100103	ASSY PIPE 6DIA X 1735 LG LPTA 713/32TC	TATA spare parts
215429100106	ASSY.PIPE	TATA spare parts
215429100107	ASSY.PIPE	TATA spare parts
215429100108	ASSY COVER ( CONTROLS )	TATA spare parts
215429100110	ASSY PIPE	TATA spare parts
215429100111	ASSY PIPE	TATA spare parts
215429105801	HOSE (FLUID CONTAINER TO MASTER CYLINDER	TATA spare parts
215430100101	ASSY PEDAL LEVER ACCELERATOR (RHD)	TATA spare parts
215430100102	ASSY BRACKET ACCELERATOR (RHD)	TATA spare parts
215430100103	BRACKET ACCEL CABLE MTG.	TATA spare parts
215430100104	ASSY ACCELERATOR PEDAL WITH BRACKET	TATA spare parts
215430100105	PULL CABLE(FOR 713 TC RHD) 2830MM	TATA spare parts
215430100106	ASSY.PULL CABLE ACCELERATOR	TATA spare parts
215430100107	ASSY.PULL CABLE(ACCEL.)	TATA spare parts
215430100107AE	ASSY.PULL CABLE(ACCEL.) 715	TATA spare parts

215430100108	ASSY. BRACKET ACCELERATOR	TATA spare parts
215430200101	ASSY CABLE COMPLETE 3465MM	TATA spare parts
215430200103	ASSY.CABLE COMPLETE(MECH ENG STOP)	TATA spare parts
215430200103AE	ASSY.CABLE(MECH ENG STOP) -713	TATA spare parts
215431000101	ASSY FRAME LPTA 713/32 TC	TATA spare parts
215431000104	ASSY FRAME	TATA spare parts
215431000105	ASSY. FRAME LPTA 713 EURO2	TATA spare parts
215431000108	ASSY FRAME	TATA spare parts
215431200104	ASSY. BRACKET FOR AGB MOUNTING	TATA spare parts
215431200105	ASSY.ENGINE CROSS MEMBER FRONT	TATA spare parts
215431200106	ASSY.CROSS MEMBER	TATA spare parts
215431200108	ASSY REINFORCEMENT LH (FOR FRONT SPRING)	TATA spare parts
215431200109	ASSY REINFORCEMENT RH (FOR FRONT SPRING)	TATA spare parts
215431200111	ASSY CROSSMEMBER FOR AGB MTG.	TATA spare parts
215431200113	ASSY CM SUPPORT LH(FOR TUBULAR CM)	TATA spare parts
215431200114	ASSY CM SUPPORT RH(FOR TUBULAR CM)	TATA spare parts
215431200115	BRACKET (FOR AGB MTG.) BS6	TATA spare parts
215431200116	ASSY X-MEMBER(W/O AIRFILTER MTG BKT)	TATA spare parts
215431200127	ASSY.ENGINE CROSS MEMBER FRONT	TATA spare parts
21543120012735	ASSY.ENGINE CROSS MEMBER FRONT_UNPAINTE	TATA spare parts
215431207101	REINFORCEMENT FRT.SPRING BKT.RH	TATA spare parts
215431207103	REINFORCEMENT LH (BOTTOM)	TATA spare parts
215431207104	REINFORCEMENT RH (BOTTOM)	TATA spare parts
215431207107	SUPPORT	TATA spare parts
215431207122	SUPPORT LH (TOP)	TATA spare parts
215431207123	SUPPORT RH (TOP)	TATA spare parts
215431207130	STIFFNER R H	TATA spare parts
215431207131	STIFFNER L H	TATA spare parts
215431207142	REINFORCEMENT LH(BOTTOM)	TATA spare parts
215431207143	REINFORCEMENT RH (BOTTOM)	TATA spare parts
215431207145	SPACER (FOR AGB MTG.) BS6	TATA spare parts
215431207161	BRACKET L H(ENGINE CROSS MEMBER SUPPORT	TATA spare parts
21543120716135	BRACKET (ENG X MEM SUPP)_UNPAINTED	TATA spare parts
215431207162	BRACKET-R H (ENGINE CROSS MEMBER SUPPORT	TATA spare parts
21543120716235	BRACKET-RH (ENG CROSS MEM SUP)_UNPAINTED	TATA spare parts
215431208202	GUSSET PLATE (FOR END CROSS MEMBER )	TATA spare parts
215431208203	REINFORCEMENT TOP	TATA spare parts
215431208204	3RD CROSS MEMBER	TATA spare parts
215431700104	ASSY.X-MEMBER WITH SUPPORT	TATA spare parts
215431990101	KIT FOR FRAME REINFORCEMENT	TATA spare parts
215431990103	KIT FOR FASTENERS	TATA spare parts
215432100101	ASSY FRONT SPRING (NON DRIVERS SIDE)	TATA spare parts
215432100101AE	ASY FR SPRNG CO DRIVR-1415-713/5	TATA spare parts
215432100102	ASSY FRONT SPRING (DRIVERS SIDE )	TATA spare parts
215432100102AE	ASSY FR SPRNG(DRIVER)-1415-713/5	TATA spare parts
215432103703	SPACER(REAR SPRING)	TATA spare parts
215432104201	U CLAMP LH	TATA spare parts

215432104202	SPRING CLIP	TATA spare parts
215432104203	SPRING CLIP	TATA spare parts
215432104204	SPACER TUBE	TATA spare parts
215432107101	FIFTH LEAF(DRIVER SIDE)	TATA spare parts
215432107102	NINTH LEAF(DRIVER SIDE)	TATA spare parts
215432107103	FIFTH LEAF(NON-DRIVER SIDE)	TATA spare parts
215432107104	NINTH LEAF(NON-DRIVER SIDE)	TATA spare parts
215432107105	ELEVENTH LEAF	TATA spare parts
215432300106	ASSY.SHOCK ABSORBER BRACKET LH	TATA spare parts
215432300107	ASSY.SHOCK ABSORBER BRACKET RH	TATA spare parts
215432300111	ASSY SHOCK ABSORBER BKT	TATA spare parts
215432300112	ASSY SHOCKABSORBER BKT RH	TATA spare parts
215432404201	SPRING CLIP	TATA spare parts
215432404202	SPRING CLIP	TATA spare parts
215432404204	DISTANCE TUBE	TATA spare parts
215432407101	FOURTH LEAF	TATA spare parts
215432407102	SIXTH LEAF	TATA spare parts
215433856003	STEERING ARM	TATA spare parts
215435900101	LEVER TYPE CONTROL VALVE	TATA spare parts
215440100103	ASSY RUNFLAT WITH TYRE & RIM	TATA spare parts
215440100104	ASSY RUNFLAT WITH TYRE & RIM	TATA spare parts
215440100106	ASSY WHEEL RIM 8.25 X 22.5	TATA spare parts
215440106301	11R22.5 XZY-2	TATA spare parts
215440106302	TYRE 12-20 18PR CROSS COUNTRY	TATA spare parts
215441100102	ASSY PROPELLER SHAFT ( TRANSFER CASE TO	TATA spare parts
215441100102AE	ASSY PROP SFT RR (AUX GB) -713	TATA spare parts
215441100104	ASSY PROPELLER SHAFT ( TRANSFER CASE TO	TATA spare parts
215441100106	ASSY PROPELLER SHAFT (FROM G.B.TO TRANSF	TATA spare parts
215441100106AE	PROPELLER SHAFT GB TO TC -713	TATA spare parts
215441100108	ASY. PROP SHAFT- 76DX863L (AGB TO RH)	TATA spare parts
215441100108AE	ASSY PROP SFT F(FRM AX GB)-1415	TATA spare parts
215441100110	ASY. PROP SHAFT- 76DX353L RR.AGB- RH	TATA spare parts
215441100110AE	ASY. PP SHAFT- 76DX353LLPA 1415	TATA spare parts
215441100112	ASSY PROP SHAFT COMPLETE-(FRONT )	TATA spare parts
215441100112AE	ASSY PROP SFT COMPL-FRT-1415-715	TATA spare parts
215442400101	L.C.R.V.ASSY.	TATA spare parts
215442700102	HOSE ASSY.	TATA spare parts
215442800101	ASSY PIPE 6DIAX1890 LG LPTA 713/32TC	TATA spare parts
215442800102	ASSY.PIPE 6DIAX2465LG LPTA 713/32TC	TATA spare parts
215442800103	ASSY.PIPE 6DIAX2030LG LPTA 713/32TC	TATA spare parts
215442800104	ASSY BKT ( BRAKE FLUID CONTAINER )	TATA spare parts
215442800106	ASSY CONNECTING LINE(FRONT BRAKE)	TATA spare parts
215442800107	ASSY CONNECTING LINE( REAR BRAKE )	TATA spare parts
215442803301	BRACKET FOR LCRV MTG	TATA spare parts
215442808201	BRACKET	TATA spare parts
215442900103	ASSY.PIPE 18X1.5X1280 LG. LPTA 713/32TC	TATA spare parts
215442900104	ASSY.PIPE 15X1.5X3150 LG. LPTA 713/32TC	TATA spare parts

215442900105	ASSY.PIPE 15X1.5X2285 LG. LPTA 713/32TC	TATA spare parts
215442900106	ASSY.PIPE 15X1.5X710 LG. LPTA 713/32TC	TATA spare parts
215442900107	ASSY.PIPE 12X1X780 LG. LPTA 713/32TC	TATA spare parts
215442900108	ASSY.PIPE 12X1X2400 LG LPTA 713/32TC	TATA spare parts
215442900112	ASSY.PIPE 12X1X2320 LG LPTA 713/32TC	TATA spare parts
215442900113	ASSY.PIPE 12X1X1150 LG LPTA 713/32TC	TATA spare parts
215442900114	ASSY.PIPE 12X1X1345 LG LPTA 713/32TC	TATA spare parts
215442900115	ASSY.PIPE 12X1X1320 LG LPTA 713/32TC	TATA spare parts
215442900116	ASSY. PIPE 12X1X2240 LG LPTA 713/32TC	TATA spare parts
215442900120	ASSY. PIPE 12X1X2245 LG LPTA 713/32TC	TATA spare parts
215442900121	ASSY. PIPE 12X1X1550 LG LPTA 713/32TC	TATA spare parts
215442900122	ASSY. PIPE 12X1X1280 LG LPTA 713/32TC	TATA spare parts
215442900123	ASSY. PIPE 6X.7X530 LG LPTA 713/32TC	TATA spare parts
215442900124	ASSY.PIPE 12X1X525 LG. LPTA 713/32TC	TATA spare parts
215442900125	ASSY.PIPE 12X1X875 LG. LPTA 713/32TC	TATA spare parts
215442900126	ASSY. PIPE 6X.7X3000 LG LPTA 713/32TC	TATA spare parts
215442900129	ASSY. PIPE 12X1X2220 LG LPTA 713/32TC	TATA spare parts
215442900130	ASSY.PIPE 12X1X1145 LG LPTA 713/32TC	TATA spare parts
215442900135	ASSY.HOSE(CRIMPED) LPTA 713 TC	TATA spare parts
215442900136	ASSY.HOSE(CRIMPED) LPTA 713 TC	TATA spare parts
215442900137	ASSY.HOSE(CRIMPED) LPTA 713 TC	TATA spare parts
215442900138	ASSY.HOSE(CRIMPED) LPTA 713 TC	TATA spare parts
215442900139	ASSY.HOSE(CRIMPED) LPTA 713 TC	TATA spare parts
215442900140	ASSY.HOSE(CRIMPED) LPTA 713 TC	TATA spare parts
215442900141	HOSE ASSY. LPTA 713/32TC	TATA spare parts
215442900142	BRAKE HOSE-FOR FRONT R.H BRAKE	TATA spare parts
215442900196	ASSY NYLON PIPE SET	TATA spare parts
215442903303	BRACKET	TATA spare parts
215443100101	ASSY PIPE 6DIAX1510 LG LPTA 713/32TC	TATA spare parts
215443100102	ASSY PIPE 6DIAX2465 LG LPTA 713/32TC	TATA spare parts
215443100106	ASSY PIPE 6DIAX420 LG LPTA 713/32TC	TATA spare parts
215443100109	DOUBLE CHECK VALVE	TATA spare parts
215443108201	FRONT PALM COUPLING BKT	TATA spare parts
215443200101	ASSY BRACKET (AIR DRYER MTG )	TATA spare parts
215443200103	KIT ASSY AIR TANK ( FOR VOSS )	TATA spare parts
215443203301	BRACKET ( DDU MTG )	TATA spare parts
215443900101	ASSY NYLON PIPE SET LPTA713/32BS2	TATA spare parts
215443900149	ASSY NYLON PIPE SET( TAURUS )	TATA spare parts
215446000101	ASSY DRAG LINK (713 RHD)	TATA spare parts
215446000105	ASSY DRAG LINK (LHD)	TATA spare parts
215446000114	ASSY DRAG LINK	TATA spare parts
215446106302	RUBBER BELLOW(FLOOR)	TATA spare parts
215446150106	ASSY KIT PIPE FOR HYD P/STEERING	TATA spare parts
215446150107	ASSY KIT PIPE FOR HYD P/STEERING	TATA spare parts
215446200101	ASSY BRACKET	TATA spare parts
215446200102	ASSY STEERING SPINDLE LPTA 713 TC	TATA spare parts
215446200104	ASSY STEERING SPINDLE	TATA spare parts

215446200109	ASSY STG G.B MTG BRACKET	TATA spare parts
215446200111	ASSY.STG.SPINDLE	TATA spare parts
215446200112	ASSY.STG.SPINDLE	TATA spare parts
215446206301	RUBBER BELLOW LPTA 713 TC	TATA spare parts
215446207901	STEERING SPINDLE	TATA spare parts
215446207903	STEERING SPINDLE BOTTOM LPTA 713 TC	TATA spare parts
215446207905	STEERING SPIMNDLE BOTTOM	TATA spare parts
215446207906	STG.SPINDLE BOTTOM	TATA spare parts
215446207907	STG.SPINDLE BOTTOM	TATA spare parts
215446208202	CLAMPING RING	TATA spare parts
215446305101	PITMAN ARM	TATA spare parts
215446305102	PITMAN ARM	TATA spare parts
215446600102	ASSY P/STG GEAR BOX	TATA spare parts
215446600102AE	ASSY PWR STRNG GR BOX -1415-715	TATA spare parts
215446800104	HOSE ASSY. LPTA 713/32TC	TATA spare parts
215446800105	HOSE ASSY. LPTA 713/32TC	TATA spare parts
215446800106	ASSY.PIPE LPTA 713/32TC	TATA spare parts
215446800107	ASSY.PIPE LPTA 713/32TC	TATA spare parts
215446800108	ASSY.PIPE	TATA spare parts
215446800111	SUCTION LINE HOSE ASSY.(FROM HYD.TANK TO	TATA spare parts
215446800112	PRESSUR LINE HOSE ASSY.(FROM PUMP TO S.G	TATA spare parts
215446800113	RETURN LINE HOSE ASSY.(FROM STG G BOX TO	TATA spare parts
215446800114	RETURN LINE HOSE ASSY.(FROM INT JOINT TO	TATA spare parts
215446800118	SUCTION HOSE ASSY.(FROM HYD.TANK TO PUMP	TATA spare parts
215446800119	PRESSUR L.HOSE ASSY.(FROM P TO S.G.BOX )	TATA spare parts
215446800120	RTN L. HOSE ASSY.(S/G BOX TO RESERVOIR)	TATA spare parts
215446800123	PRESSURE LINE ASSY	TATA spare parts
215446800124	SUCTION LINE ASSY	TATA spare parts
215446800125	RETURN LINE ASSY	TATA spare parts
215446800126	RETURN LINE ASSY	TATA spare parts
215446800131	PRESSURE LINE ASSY	TATA spare parts
215446800132	RETURN LINE ASSY	TATA spare parts
215446990114	BALL JOINT ASSY	TATA spare parts
215447500102	ASSY.FUEL TANK COMPL.200LTR.RECTANGULAR	TATA spare parts
215447600103	ASSY.CONNECTING LINE LPTA 713/32TC	TATA spare parts
215447600104	ASSY.CONNECTING LINE LPTA 713/32TC	TATA spare parts
215447600105	ASSY.TUBE LPTA 713/32TC	TATA spare parts
215447600106	ASSY.TUBE LPTA 713/32TC	TATA spare parts
215447600107	ASSY SUCTION TUBE-10 DIA & 15 DIA UNION	TATA spare parts
215447600108	ASSY RETURN LINE -DIA6 X .7 THK	TATA spare parts
215447600109	ASSY SUCTION TUBE-15 DIA & 15 DIA UNION	TATA spare parts
215449000101	ASSY.BRACKET	TATA spare parts
215449000104	ASSY BRKT	TATA spare parts
215449000107	ASSY.BRACKET	TATA spare parts
215449000108	ASSY BRACKET	TATA spare parts
215449000109	ASSY EXHAUST BRACKET.	TATA spare parts
215449008208	BRACKET	TATA spare parts

215449100101	ASSY.SILENCER WITH PIPE LPTA 713/32TC	TATA spare parts
215449100102	ASSY SILENCER WITH PIPES(LPTA713/32TC	TATA spare parts
215449100103	ASSY.SILENCER	TATA spare parts
215449106901	EXHAUST PIPE REAR	TATA spare parts
215449200101	ASSY.EXHAUST PIPE LPTA 713/32TC	TATA spare parts
215449200102	ASSY.EXHAUST PIPE	TATA spare parts
215449200103	ASSY FRONT EXHAUST PIPE	TATA spare parts
215449200104	ASSY EXHAUST PIPE INTERMEDIATE	TATA spare parts
215449200111	ASSY FRONT EXHAUST PIPE	TATA spare parts
215449200112	ASSY.EXHAUST PIPE (FRONT)	TATA spare parts
215449200113	ASSY EXHAUST PIPE (SECOND)	TATA spare parts
215449208201	BRACKET(FOR EXHAUST BRAKE UNIT MTG)	TATA spare parts
215454009901	PLATE-WIRING DIAGRAM	TATA spare parts
215454100101	ASSY. CARRIER WELDED COMPLETE	TATA spare parts
215454100108	ASSY BKT (FOGLAMP MTG)SD1015TC/LPTA713TC	TATA spare parts
215454100109	ASSY GUARD(FOGLAMP)	TATA spare parts
215454100110	ASSY.BATT.CABLE +VE (ST.MOTOR TO BCSW.)	TATA spare parts
215454100112	ASSY CU-BATTERY CABLE(-VE)BCS TO SM	TATA spare parts
215454100113	ASSY BATTERY CABLE (+VE) BATT TO BCS	TATA spare parts
215454100114	ASSY BATTERY CABLE (-VE) BATT TO BCS	TATA spare parts
215454100146	ASSEMBLY BATTERY CARRIER COMPLETE	TATA spare parts
215454109902	BATTERY COVER-PP -COPOLYMER-180AH	TATA spare parts
215454110102	ASSY. BATT.CABLE -VE (ST.MOTOR TO BCSW.)	TATA spare parts
215454110103	ASSY.BATT.CABLE -VE(BATTERY TO BCS)	TATA spare parts
215454208201	MTG.BKT-REVERSE BEEPER	TATA spare parts
215454208204	MOUNTING BKT-WIF	TATA spare parts
215454209901	SPEEDO CABLE 4300MM	TATA spare parts
215454209903	FUEL GAUGE WITH RED BAND	TATA spare parts
215454400105	ASSY.HEAD LAMP-LH/RHD	TATA spare parts
215454400106	ASSY.HEAD LAMP-RH/RHD	TATA spare parts
215454400109	ASSY. GUARD (4 CH TAIL LIGHT)	TATA spare parts
215454400110	ASSY LAMP WARNING INDICATOR-BRAKE FL.	TATA spare parts
215454400112	ASSY LAMP WARNING INDICATOR-EXH.BR.ON	TATA spare parts
215454400113	ASSY LAMP WARNING INDICATOR	TATA spare parts
215454400115	ASSY LAMP WARNING INDICATOR-4 BANK 24V	TATA spare parts
215454400116	ASSY LAMP WARNING INDICATOR-4 BANK 24V	TATA spare parts
215454400117	ASSY LAMP WARNING INDICATOR-4 BANK	TATA spare parts
215454400124	ASSY TAIL LAMP BKT RH	TATA spare parts
215454400125	ASSY TAIL LAMP BKT LH	TATA spare parts
215454409901	12 POLE SOCKET	TATA spare parts
215454409902	B/O HEAD LAMP OF LPTA 1623	TATA spare parts
215454409903	MAP READING LAMP	TATA spare parts
215454409906	CONVOY LAMP	TATA spare parts
215454500101	ASSY INSTRUMENT PANEL	TATA spare parts
215454506901	PIANO SW(BRAKE FAIL)	TATA spare parts
215454509902	INSPECTION LAMP 10 M LONG CABLE	TATA spare parts
215454509905	PLUG SOCKET (FOR INSPECTION LAMP)	TATA spare parts

215454601602	WIRING HARNESS MAIN	TATA spare parts
215454601602AE	WIRING HARNESS MAIN 1415	TATA spare parts
215454601603	WIRING HARNESS INSTRUMENT CONSOLE	TATA spare parts
215454601603AE	WIRING HRNSS INSTMT -1415-715	TATA spare parts
215454601605	WIRING HARNESS-MAIN	TATA spare parts
215454601605AE	WIRING HARNESS-MAIN 715	TATA spare parts
215454601607	W/H PARK BRAKE SW. WITH LUG	TATA spare parts
215454601608	WIRING HARNESS PARK BRAKE SWITCH WITH CO	TATA spare parts
215454601609	W/H-MAIN LPTA-713TC BS-III	TATA spare parts
215454601611	W/H POWER CABLE-1	TATA spare parts
215454601612	W/H POWER CABLE-2	TATA spare parts
215454601613	W/H POWER CABLE-3	TATA spare parts
215454620109	WIRING HARNESS MAIN	TATA spare parts
215454820101	ASSY MAIN CABLE SET	TATA spare parts
215454820102	ASSY. CABLE SET - FRT. TO TAIL	TATA spare parts
215454820108	WIRING HARNESS MAIN LHD	TATA spare parts
215454820108AE	WIRING HARNESS MAIN 713	TATA spare parts
215454820109	ASSY.CABLE SET FRT.TO TAIL LAMP-LHD	TATA spare parts
215454820110	W/H MAIN-LPTA-713TC-EURO-II	TATA spare parts
215454820111	W/H TAIL-LPTA-713TC-E-II WB-32	TATA spare parts
215454820112	ASSY.CABLE SET (FOR CAB LAMP)	TATA spare parts
215454820113	W/H-MAIN LPTA713TC E-II ARMY BULLET PRF	TATA spare parts
215454820117	W/H-TAIL LPTA-713TC/32 ARMY AMBULANCE	TATA spare parts
215454820119	WIRING HARNESS TAIL	TATA spare parts
215454820119AE	WIRING HARNESS TAIL 715	TATA spare parts
215454821604	W/H PIGTAIL GRID HEATER CONTROLLER UNIT	TATA spare parts
215454908201	INSTRUMENT PANEL AND LAYOUT	TATA spare parts
215458109901	TOMMY BAR	TATA spare parts
215458409903	TRANSFER LABEL (REAR TYRE PRESSURE)	TATA spare parts
215460000101	ASSY.CAB.COMPLETE	TATA spare parts
215460000102	CAB ASSY BARE LPTA713TC	TATA spare parts
215460000113	ASSY CAB COMPLETE-LHD	TATA spare parts
215460000114	ASSY BODY SHELL PAINTED-LHD(BARE CAB)	TATA spare parts
215460000115	ASSY CAB COMPLETE-LPTA713TC EURO-II-RHD	TATA spare parts
215460000116	ASSY CAB SHELL PAINTED-RHD-EURO-II	TATA spare parts
215460000123	ASSY. CAB SHELL PAINTED (BARE CAB)	TATA spare parts
215460000129	ASSY SHELL PAINTED RHD	TATA spare parts
215460000141	ASSY SHELL PAINTED RHD	TATA spare parts
215460100101	ASSY FOOT STEP BOARD	TATA spare parts
215460100103	ASSY. BRACKET RIFLE MTG	TATA spare parts
215460100106	ASSY. BRACKET COLD START BOTTLE.	TATA spare parts
215460100107	ASSY. BRACKET RIFLE MTG.R.H.	TATA spare parts
215460100112	ASSY BRACKET-FLICK VALVE MTG.	TATA spare parts
215460108212	COVER PANEL	TATA spare parts
215461108206	REINFORCEMENT-LH(FLOOR INSIDE)	TATA spare parts
215461108207	REINFORCEMENT-RH(FLOOR INSIDE)	TATA spare parts
215462608207	PANEL FIREWALL	TATA spare parts

215465070102	ASSY. BKT. ROOF PANEL.	TATA spare parts
215465700102	ASSY. RING.(ROOF HATCH).	TATA spare parts
215465700104	ASSY RING (ROOF HATCH)	TATA spare parts
215466060101	ASSY ADDITIONAL STEP (TUBULAR)	TATA spare parts
215468400103	FLOOR MAT SET BS-II RHD	TATA spare parts
215468900101	ASSY. REINFORCEMENT COMPLETE (INSIDE)	TATA spare parts
215468900102	ASSY. REINFORCEMENT TOP	TATA spare parts
215468900105	ASSY. REINFORCEMENT COMPLETE (OUTSIDE)	TATA spare parts
215468900106	ASSY. DASH BOARD COMP.	TATA spare parts
215468900107	ASSY. BRACKET ELBOW DUCT DASH BOARD L.H.	TATA spare parts
215468900108	ASSY. BRACKET ELBOW DUCT R.H.	TATA spare parts
215468900111	ASSY DASH BOARD COMPLETE	TATA spare parts
215468900115	ASSY.REINF.INSIDE SHROUD MTG.COMPLETE	TATA spare parts
215468900117	ASSY.REINFORCEMENT RHD	TATA spare parts
215468900118	ASSY.DASHBOARD COMPLETE	TATA spare parts
215468906301	DASHBOARD LH	TATA spare parts
215468906302	DASHBOARD RH	TATA spare parts
215468906303	DASHBOARD (CENTRE)	TATA spare parts
215468906304	SPEAKER GRILL	TATA spare parts
215468906306	DASH BOARD CENTER LHD	TATA spare parts
215468906307	DASH BOARD RH LHD	TATA spare parts
215468906310	DASH BOARD LH LHD ( FOR KWIK START )	TATA spare parts
215468908206	INSTRUMENT PANEL & LAYOUT	TATA spare parts
215469106305	INSULATION TOP-RHD	TATA spare parts
215469400101	ASSY. PADDING. (REAR WALL)	TATA spare parts
215469500102	ASSY.ROOF LINING.	TATA spare parts
215472000101	KIT RH & LH DOOR FOR SPARE	TATA spare parts
215475200101	ASSY. STAY ROD.	TATA spare parts
215481100102	ASSY REAR VIEW MIRROR	TATA spare parts
215481100109	GRAB HANDLE LH	TATA spare parts
215481100110	GRAB HANDLE RH	TATA spare parts
215481100111	GRAB HANDLE	TATA spare parts
215481800101	ASSY. TATA 713 CUMMINS MASCOT - LPTA713T	TATA spare parts
215481800103	ASSY. TATA 715 CUMMINS MASCOT	TATA spare parts
215481900103	ASSY. BAZZLE LH	TATA spare parts
215481900104	ASSY. BAZZLE RH	TATA spare parts
215481900106	ASSY COVER CENTRE	TATA spare parts
215481900107	ASSY. T-EMBLEM (OVAL STYLISED) LPTA713TC	TATA spare parts
215481900109	ASSY CLIP	TATA spare parts
215481905801	THREADED BOSS MIDDLE BOTTOM.	TATA spare parts
215481905802	THREADED BOSS MIDDLE TOP.	TATA spare parts
215481905803	THREADED BOSS SIDE BOTTOM.	TATA spare parts
215482409901	WIPER MOTOR-12V-2 SPEED HI POWER	TATA spare parts
215483100101	BLEEDER ASSY.	TATA spare parts
215483100103	ASSY. COIL HOUSING	TATA spare parts
215483106301	ADAPTOR HOUSING.	TATA spare parts
215483106302	CAP FOR PLENUM CHAMBER.	TATA spare parts



215483106306	ADAPTOR HOUSING PLENUM CHAMBER	TATA spare parts
215483106307	ADAPTOR HOUSING	TATA spare parts
215483300102	ASSY.PUSH PULL CABLE	TATA spare parts
215483400101	ASSY. HEATER COIL COMPL.	TATA spare parts
215483500102	ASSY. HOSE LPTA 713 TC	TATA spare parts
215483505801	RUBBER HOSE LPTA 713 TC	TATA spare parts
215483505803	RUBBER HOSE LPTA 713 TC	TATA spare parts
215483505805	RUBBER HOSE ( HEATING COIL -LG 220 )	TATA spare parts
215488500101	ASSY BUMPER LPTA 713 TC	TATA spare parts
215488500101B0	BUMPER PAINTED BLACK- LPTA 713	TATA spare parts
215488500102	ASSY. GUARD FOR BLACK OUT LAMP.	TATA spare parts
215488500103	ASSY. GUARD HEAD LAMP.L.H. LPTA 713 TC	TATA spare parts
215488500104	ASSY. GUARD HEAD LAMP.R.H. LPTA 713 TC	TATA spare parts
215488500106	ASSY. BUMPER COMPLETE	TATA spare parts
215488500106B0	ASSY BUMPER PAINTED IN BLACK	TATA spare parts
215488500109	FOG LAMP MTG BKT	TATA spare parts
215489100103	ASSY CAB TILTING BAR LPTA 713 TC	TATA spare parts
215489100104	ASSY. TIE MEMBER (REAR MOUNTING)	TATA spare parts
215489100105	ASSY MTG BKT BOTTOM RH FRT (RHD) CAB	TATA spare parts
215489100106	ASSY MTG BKT BOTTOM-LH RHD FRONT	TATA spare parts
215489100107	ASSY. STAY COMPLETE	TATA spare parts
215489100110	ASSY. SUPPORT BRACKET LH	TATA spare parts
215489100111	ASSY. SUPPORT BRACKET RH	TATA spare parts
215489100116	ASSY SECONDARY LOCK	TATA spare parts
215489100120	ASSY MTG BRACKET LH (CHASSIS SIDE)	TATA spare parts
215489100121	ASSY MTG BRACKET RH (CHASSIS SIDE)	TATA spare parts
215489100123	ASSY CHAIN WITH RING & WIRE LOOP	TATA spare parts
215489100126	ASSY MTG BRACKET RH LHD	TATA spare parts
215489100127	ASSY MTG BRACKET LH LHD	TATA spare parts
215489100128	ASSY CROSS TUBE(TORSION BAR) -LHD	TATA spare parts
215489100132	ASSY MTG BKT BOTTOM LH-FRONT	TATA spare parts
215489100134	ASSY MTG BKT BOTTOM RH FRONT	TATA spare parts
215489100142	ASSY MOUNTING BRACKET FRONT LH	TATA spare parts
215489100143	ASSY MOUNTING BRACKET FRONT RH	TATA spare parts
215489100154	ASSY COWL MTG BKT REAR LH	TATA spare parts
215489100155	ASSY COWL MTG BKT REAR RH	TATA spare parts
215489106301	MUDGUARD LH LPTA 713 TC	TATA spare parts
215489106302	MUDGUARD RH LPTA 713 TC	TATA spare parts
215489106303	MUDFLAP INNER LH	TATA spare parts
215491100103	ASSY SEAT BOX COMPLETE (DRIVER SEAT)-RHD	TATA spare parts
215491500101	ASSY SEAT BELT KIT	TATA spare parts
215494000101	ASSY.CODRIVERS SEAT COMP.RHD.	TATA spare parts
215494000103	ASSY CO-DRIVER SEAT	TATA spare parts
215494000104	ASSY CO-DRIVER SEAT COMPLETE-LHD	TATA spare parts
215494000110	ADDITIONAL SEAT	TATA spare parts
215498800101	ASSY MASCOT 4X4	TATA spare parts
215715100101	INTER BRACKET ASSEMBLY BS6	TATA spare parts

215715100102	ENGAGING LEVER ASSEMBLY BS6	TATA spare parts
215715100103	FIXING BRACKET ASSEMBLY BS6	TATA spare parts
215715100104	FIELD COIL ASSEMBLY BS6	TATA spare parts
215715100105	BRUSH GEAR ASSEMBLY BS6	TATA spare parts
215715100106	BEARING BUSH ASSEMBLING KIT BS6	TATA spare parts
215715100107	FASTENERS ASSEMBLING KIT BS6	TATA spare parts
215715100109	SEALING ASSEMBLING KIT BS6	TATA spare parts
215715100110	BRUSH ASSEMBLING KIT BS6	TATA spare parts
215715100111	ARMATURE ASSEMBLING KIT BS6	TATA spare parts
215715100112	CE BRACKET ASSEMBLY BS6	TATA spare parts
215715100113	RELAY ASSEMBLY BS6	TATA spare parts
215715100114	DRIVE ASSEMBLY (9 TEETH) BS6	TATA spare parts
215754100104	ASSY.BATTERY CARRIER(STEEL)-12V 120AH	TATA spare parts
215754100105	ASSY.BATTERY CARRIER(STEEL)-12V 150AH	TATA spare parts
215754100106	ASSY.BATTERY CARRIER(STEEL)-2X12V 120AH	TATA spare parts
215754100107	ASSY.BATTERY CARRIER(STEEL)-2X12V 150AH	TATA spare parts
215754100108	ASSY.BATT.CABLE-50SQ MM+VE -1350 MM	TATA spare parts
215754100119	ASSY. CARRIER-WELDING	TATA spare parts
215754100120	ASSY. BATTERY CLAMPING CHANNEL	TATA spare parts
215754100125	ASSY.BATT.CABLE +VE (BATTERY TO BCSW.)	TATA spare parts
215754100126	ASSY.BATT.CABLE +VE (ST.MOTOR TO BCSW.)	TATA spare parts
215754100127	ASSY.BAT.CABLE +VE 50SQMM 2010MM	TATA spare parts
215754100128	ASSY FRAME WITH COVER -RH	TATA spare parts
215754100133	ASSY FRAME WITH COVER -LH	TATA spare parts
215754100136	ASSY BATT CABLE (-VE)70SQM	TATA spare parts
215754100137	ASSY BATT CABLE (LINK)-70SQMM -(300MM)	TATA spare parts
215754100138	ASSY BATT CABLE(-VE) 70SQM COT (BCS-STM)	TATA spare parts
215754100139	ASSY BATT CABLE(+VE) 70SQM	TATA spare parts
215754100140	ASSY BATT CABLE(+VE) 50SQM COT	TATA spare parts
215754100141	ASSY BATT CABLE(-VE) 50SQM COT	TATA spare parts
215754100143	ASSY BATT CABLE(+VE) 70SQM	TATA spare parts
215754100148	ASSY.BATTERY CABLE +VE(1400MM)	TATA spare parts
215754100149	ASSY.BATTERY CABLE -VE (1600MM)	TATA spare parts
215754100150	ASSY.BATTERY CABLE +VE(640MM)	TATA spare parts
215754100151	ASSY BATTERY CABLE VE(950MM)	TATA spare parts
215754100157	ASSY MOUNTING BRACKET	TATA spare parts
215754100158	ASSY BATTERY CABLE +VE(70 SQ.MM) 900MM B	TATA spare parts
215754100159	ASSY BATTERY CABLE LINK-220MM--70SQ.MM	TATA spare parts
215754100164	ASSY BATTERY CABLE +VE(70 SQ.MM) 750MM	TATA spare parts
215754100165	ASSY BATTERY CABLE -VE(70 SQ.MM) 1000MM	TATA spare parts
215754100170	ASSY. SUPPORT	TATA spare parts
215754100175	ASSY. BATTERY CABLE +VE(70SQ.MM) 3000MM	TATA spare parts
215754100176	ASSY. BATTERY CABLE -VE(70SQ.MM) 3000MM	TATA spare parts
215754100181	ASSY. BATTERY CABLE +VE(4800MM) 95 SQ.MM	TATA spare parts
215754100182	ASSY. BATTERY CABLE -VE(4800MM) 95 SQ.MM	TATA spare parts
215754100183	ASSY.BATTERY CABLE LINK(250MM)95 SQ.MM	TATA spare parts
215754100185	ASSY BATTERY CABLE(+VE)	TATA spare parts

215754100186	ASSY BATTERY CUT-OFF SW MTG BKT	TATA spare parts
215754100187	ASSY BATTERY CABLE +VE	TATA spare parts
215754106301	BATT COVER PLASTIC 100AH	TATA spare parts
215754108205	CHANNEL-BATTERY CLAMPING	TATA spare parts
215754108208	BATTERY CLAMP	TATA spare parts
215754108216	CHANNEL BATTERY CLAMPING	TATA spare parts
215754108219	CLAMPING STUD 229 MM	TATA spare parts
215754108801	BENT STUD-310MM	TATA spare parts
215754109904	GRS STARTER MOTOR 24V WITH TCO & INTERME	TATA spare parts
215754109905	DIRECT DRIV STR. MOTOR 24V W/TCO BS2/3/4	TATA spare parts
215754109910	BATTERY CABLE +VE 95SQ.MM(ST.MOT TO BCS)	TATA spare parts
215754109911	BATTERY CABLE-VE 95SQ.MM.(ST.MOT TO BCS)	TATA spare parts
215754109912	BATTERY CABLE+VE 95SQ.MM(BCS TO BATTERY)	TATA spare parts
215754109913	ASSY BATTERY CABLE -VE(BCS TO BATTERY)	TATA spare parts
215754109914	BATTERY CABLE LINK 95 SQ.MM.	TATA spare parts
215754110101	ASSY.BATT.CABLE -VE(BATTERY TO BCSW.)	TATA spare parts
215754110102	ASSY. BATT.CABLE -VE (ST.MOTOR TO BCSW.)	TATA spare parts
215754110103	ASSY.BATT.CABLE -VE 50 SQMM 1530MM	TATA spare parts
215754110104	ASSY BATTERY CABLE -VE	TATA spare parts
215754200109	ASSY. MOUNTING BRACKET-FOR RELAYS &FUSE	TATA spare parts
215754200119	CABLE TIE-PUSH MOUNTING	TATA spare parts
215754200121	BATTERY CABLE CLAMP DIA 23-27	TATA spare parts
215754200158	MULTIPLE FANOUT UNIT ASSY	TATA spare parts
215754200162	SPEED SENSOR	TATA spare parts
215754200164	ASSEMBLY MOUNTING BRACKET FOR CONTRACT	TATA spare parts
215754200170	KIT RSL INST.TC LPT 1613-1210COWL&709CAB	TATA spare parts
215754200171	KIT RSL INST.TC LPT 2518/3118/3723/3718	TATA spare parts
215754200172	KIT RSL INST.TC LPK 16T/25T/31T/LPS35T/4	TATA spare parts
215754200173	MOTOR ACTUATOR ASSY WITH W/H	TATA spare parts
215754200174	SPEED SENSOR WITH W/H	TATA spare parts
215754200175	CONTROL CABLE 3MM MECH.	TATA spare parts
215754200176	KIT-ELECTRICAL ITEMS INSTALLATION	TATA spare parts
215754206302	ECU COVER	TATA spare parts
215754206303	PROTECTIVE COVER	TATA spare parts
215754208201	BKT.-RELAY BASE MTG.	TATA spare parts
215754208223	GPS MOUNTING BRACKET-MM	TATA spare parts
215754209905	FUEL GAUGE	TATA spare parts
215754209906	FUEL GAUGE 12V	TATA spare parts
215754209907	TEMP.GAUGE	TATA spare parts
215754209908	AIR PRESSURE GAUGE	TATA spare parts
215754209909	RPM METER	TATA spare parts
215754209910	RPM METER 12V	TATA spare parts
215754209911	RPM METER ASSY. 24V 552 HZ	TATA spare parts
215754209913	RPM METER ASSY. 12V 420 HZ	TATA spare parts
215754209915	TRIP SPEEDOMETER	TATA spare parts
215754209916	SPEEDOMETER (0.80)	TATA spare parts
215754209917	SPEEDOMETER 0.88	TATA spare parts

215754209921	INSTRUMENT CLUSTER -1:0.91	TATA spare parts
215754209922	INST.CLUSTER .LP LPT2515 (1.04)	TATA spare parts
215754209924	INSTRUMENT CLUSTER 1:0.80	TATA spare parts
215754209925	INSTRUMENT CLUSTER 1:0.88	TATA spare parts
215754209927	INSTRUMENT CLUSTER 1:0.88	TATA spare parts
215754209929	INSTRUMENT CLUSTER 1:0.88	TATA spare parts
215754209930	INSTRUMENT CLUSTER 1:0.88	TATA spare parts
215754209936	INSTRUMENT CLUSTER LPK 2516 12V(1.04)	TATA spare parts
215754209937	CRYSTAL RPM WITH DIGITAL HOURMETER	TATA spare parts
215754209939	INSTRUMENT CLUSTER LPK 2516 24V	TATA spare parts
215754209940	INSTRUMENT CLUSTER 1:1.04	TATA spare parts
215754209941	INSTRUMENT CLUSTER (1:0.8)	TATA spare parts
215754209944	INSTRUMENT CLUSTER (1:0.90)	TATA spare parts
215754209945	INSTRUMENT CLUSTER(1:0.88)BS-III	TATA spare parts
215754209946	INSTRUMENT CLUSTER(1:0.91)BS-II	TATA spare parts
215754209948	INSTRUMENT CLUSTER (1:1.04)	TATA spare parts
215754209949	INST.CLST.(1:0.88)W/O H/L LVL SW.	TATA spare parts
215754209950	INSTRUMENT CLUSTER(1:1.04)BS-III	TATA spare parts
215754209952	BUZZER	TATA spare parts
215754209956	RPM METER 24V 420 HTZ	TATA spare parts
215754209961	INSTRUMENT CLUSTER 1:0.80	TATA spare parts
215754209965	REMOTE BATTERY CUT-OFF SWITCH	TATA spare parts
215754209965AE	REMOTE BATTERY CUT-OFF SW 1828	TATA spare parts
215754209969	SPEEDO METER RATIO 0.93	TATA spare parts
215754209970	INSTR CLSTR (0.80) LPS4923TC 24V	TATA spare parts
215754209971	INSTRUMENT CLUSTER (0.80) 24V	TATA spare parts
215754209972	INSTR CLUSTER (0.80)ABS LPS4923TC	TATA spare parts
215754209976	FUEL GAUGE ASSY.24V	TATA spare parts
215754209977	FUEL GAUGE ASSY 12V	TATA spare parts
215754209979	TEMPERATURE GAUGE	TATA spare parts
215754209980	AIR PRESSURE GAUGE	TATA spare parts
215754209981	CRYSTAL RPM WITH DIGITAL HOURMETER-12V	TATA spare parts
215754209982	RPM METER (W/O DIGITAL HOUR METER)	TATA spare parts
215754209983	CRYSTAL RPM WITH DIGITAL HOURMETER-12V	TATA spare parts
215754209984	CRYSTAL RPM WITH DIGITAL HOURMETER-24V	TATA spare parts
215754209990	INSTRUMENT CLUSTER-(1:0.80)	TATA spare parts
215754209991	E-SPEEDO RATIO 0.88 WITH MF & DIAL 0-100	TATA spare parts
215754209993	E-SPEEDO RATIO:0.88 WITH MF DIAL:0-140	TATA spare parts
215754209994	TIMER RELAY 24V	TATA spare parts
215754209995	CONTACTOR RELAY.	TATA spare parts
215754209996	SPEEDO SENSOR WITH NURLING	TATA spare parts
215754209997	CONTACTOR RELAY	TATA spare parts
215754209998	BATTERY CUT OFF SWITCH BS1/2/3/4	TATA spare parts
215754219901	ELET. S.M. WI. LCD ODO.M.24V(1:0.86)	TATA spare parts
215754300150	TANK UNIT	TATA spare parts
215754400110	BLINKER LAMP W/O BULB RH	TATA spare parts
215754400111	BLINKER LAMP W/O BULB LH	TATA spare parts

215754400114	ASSY. HEAD LAMP LH W/HL BULB 12V EURO1/2	TATA spare parts
215754400115	ASSY. HEAD LAMP RH W/HL BULB 12V EURO1/2	TATA spare parts
215754400116	ASSY. HEAD LAMP LH W/HALO. BULB BS2/3/4	TATA spare parts
215754400117	ASSY. HEAD LAMP RH W/HALO. BULB BS2/3/4	TATA spare parts
215754400155	ASSY TAIL LAMP BRACKET(RH)	TATA spare parts
215754400156	ASSY TAIL LAMP BKT(LH)	TATA spare parts
215754400157	ASSY 12 POLE NATO SOCKET	TATA spare parts
215754403303	LAMP TAIL LAMP MTG BKT	TATA spare parts
215754408206	MOUNTING BRACKET - REAR ILLUMINATION LAMP	TATA spare parts
215754408207	MOUNTING BRACKET.-HORN FOR REVERSE	TATA spare parts
215754408213	BRACKET CONTRACTOR RELAY.	TATA spare parts
215754408214	CONTACTOR RELAY MTG BKT	TATA spare parts
215754440109	TOP MARKER LAMP(24V-5W) 1300MM	TATA spare parts
215754440110	ASSY SIDE INDICATION LAMP LH	TATA spare parts
215754440111	LAMP ASSY SIDE INDICATOR CAT-6 24V-LH BS	TATA spare parts
215754440112	ASSY SIDE INDICATION LAMP RH	TATA spare parts
215754440113	LAMP ASSY SIDE INDICATOR CAT-6 24V-RH BS	TATA spare parts
215754500109	ASSY BRAKE SW(DOUBLE CONTACT)	TATA spare parts
215754509901	ASSY CLUTCH SWITCH	TATA spare parts
215754509905	ASSY.MAIN LINE SWITCH	TATA spare parts
215754509907	ASSY. HAZARD WARNING SWITCH	TATA spare parts
215754509908	STARTER PUSH BUTTON BS6	TATA spare parts
215754509930	COLD START SWITCH	TATA spare parts
215754600106	WIRING HARNESS FRAME	TATA spare parts
215754600107	W/H PIGTAIL ELECTRONIC SPEEDO SENSOR	TATA spare parts
215754600168	WIRING HARNESS ABS SPLIT	TATA spare parts
215754600169	WIRING HARNESS ABS FRAME	TATA spare parts
215754620101	PIG-TAIL FOR MECH SPEEDOMETER	TATA spare parts
215754820106	MAIN CABLE SET LPT2515TC	TATA spare parts
215754820107	ASSY.INTEGRAL W/H MAIN 24V	TATA spare parts
215754820113	MAIN CABLE SET RHD SK1615TC	TATA spare parts
215754820115	ASSY. CABLE SET-FRT.TO TAIL -60 % R.O.H	TATA spare parts
215754820116	ASSY MAIN CABLE SET-R.H.D	TATA spare parts
215754820125	W/H MAIN -LPK 2516TC -24V-RHD	TATA spare parts
215754820127	W/H TAIL LPT-1613/42 CMVR	TATA spare parts
215754820128	W/H MAIN AC VEH	TATA spare parts
215754820132	ASSY.CABLE SET -PANEL LAMPS	TATA spare parts
215754820133	ASSY.CABLE SET - GAUGES EARTHING	TATA spare parts
215754820135	W/H MAIN LP-1510 CMVR	TATA spare parts
215754820142	W/H MAIN -LPK 2516TC LHD (12V)	TATA spare parts
215754820144	ASSY.MAIN CABLE SET-RHD SE/SK-CMVR	TATA spare parts
215754820145	ASSY.CABLE SET FRT.TO TAIL-SE1613/42 WB.	TATA spare parts
215754820149	ASSY.CABLE SET FRT.TO TAIL-SK1613/36 WB	TATA spare parts
215754820150	W/H MAIN-LPK2516 EURO-II 12V	TATA spare parts
215754820151	W/H TAIL-OFFER-LPK 2516 EURO-II 24V/12V	TATA spare parts
215754820152	W/H ROOF R LPK 2516 EURO-II 24V	TATA spare parts
215754820153	W/H MAIN-INTEGRAL TYPE	TATA spare parts

215754820154	W/H TAIL-INTEGRAL TYPE WB-32	TATA spare parts
215754820155	W/H MAIN -LPT 1613 CMVR	TATA spare parts
215754820164	W/H GAUGE EARTHING -LPT 1613 CMVR	TATA spare parts
215754820165	W/H PANEL LAMPS-LPT 1613 CMVR	TATA spare parts
215754820166	W/H TAIL LP 1510/48 CMVR	TATA spare parts
215754820167	W/H PANEL LAMPS -LP 1510 CMVR	TATA spare parts
215754820170	W/H TAIL SK 1613CMVR-2000	TATA spare parts
215754820173	W/H MAIN LPT 2516TC/48 COWL-OFFER	TATA spare parts
215754820174	W/H MAIN-LPO 1610TC RE BUS	TATA spare parts
215754820175	W/H TAIL-LPO 1610TC/59 RE BUS	TATA spare parts
215754820176	W/H TAIL -LPT 2515TC	TATA spare parts
215754820182	W/H INSTRUMENT PANEL	TATA spare parts
215754820183	W/H MAIN BIPOLOR LPS 4018TC	TATA spare parts
215754820184	W/H TAIL LPS 4018TC	TATA spare parts
215754820185	W/H ROOF -LPS 4018TC	TATA spare parts
215754820186	W/H TAIL LPT 2516TC/48	TATA spare parts
215754820191	JUMPER CABLE LENGTH 5300MM BS2/3/4	TATA spare parts
215754821606	W/H-MAIN LPO-1316TC LHD INT F/B	TATA spare parts
215754990101	BATTERY KIT FOR 150A.(SIKKIM VEHICLE)	TATA spare parts
215782400107	ACCE.KIT FOR 17W WIPER MOTOR	TATA spare parts
215782900101	PIGTAIL BS6-PH2	TATA spare parts
215832100101	ASSY. REINFORCEMENT PLATE BS6	TATA spare parts
215832100102	ASSY. REINFORCEMENT PLATE BS6	TATA spare parts
215833103201	U CLAMP (FRONT)	TATA spare parts
215861600101	ASSY.STEP PANEL INNER LH	TATA spare parts
215861600102	ASSY.STEP PANEL INNER R.H.	TATA spare parts
215870000101	ASSY. LOAD BODY COMPLETE (BOLTED SIDE PA	TATA spare parts
215870000102	KIT ASSY.LOAD BODY COMPLETE	TATA spare parts
215881100101	ASSY. MUD-FLAP REAR.	TATA spare parts
215889100102	ASSY.MTG.BRACKET BOTTOM RH-LHD	TATA spare parts
215889100103	ASSY. CROSS TUBE(W/MTG BRACKET FRT LH &	TATA spare parts
215889100104	ASSY. SUPPORT BOTTOM LH. (MUDGUARD)	TATA spare parts
215889100105	ASSY. SUPPORT BOTTOM RH. (MUDGUARD)	TATA spare parts
215889100107	ASSY.MTG.BKT.BOTTOM LH -LHD	TATA spare parts
215889100108	ASSY MTG.BRKT BOTTOM RH FRONT RHD CAB	TATA spare parts
215889100110	ASSY. MTG. BKT.L.H. CHASIS SIDE.FORCAB.	TATA spare parts
2158891001100D	ASSY MTG BKT REAR LH CHASIS SIDE FOR CAB	TATA spare parts
215889100111	ASSY. MTG. BKT.R.H. CHASIS SIDE.FORCAB.	TATA spare parts
215889106301	MUDGUARD L.H.	TATA spare parts
215889106302	MUDGUARD R.H.	TATA spare parts
215889106303	MUD FLAP F/INNER L.H.	TATA spare parts
215889106304	MUD FLAP F/INNER RH.	TATA spare parts
215889106305	MUD FLAP FRONT OUTER-LH.	TATA spare parts
215889106306	MUD FLAP FRONT OUTER-RH.	TATA spare parts
215921	COUPLING PLAIN HOSE	TATA spare parts
215960000105	ASSY COWL COMPLETE W/O FACE -RHD	TATA spare parts
215960000106	ASSY COWL SHELL PAINTED W/O FACE-RHD	TATA spare parts

215960108210	VERT. SUPPORT	TATA spare parts
215964	HOSE PLAIN	TATA spare parts
215983500101	ASSY BKT FOR A/C COMPRESSOR MTG	TATA spare parts
215983500102	ASSY MTG BKT FOR ADDITIONAL ALTERNATOR	TATA spare parts
215988700101	ASSY ENGINE HOOD COMPLETE-RHD	TATA spare parts
216031000103	ASSY.FRAME COMPLETE	TATA spare parts
216032103701	SPACER	TATA spare parts
216032300112	ASSY. BRACKET L.H	TATA spare parts
216032300113	ASSY. BRACKET R.H	TATA spare parts
216042900102	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
216047100101	ASSY.FUEL TANK COMPLETE (250 LIT.)	TATA spare parts
216049100101	ASSY. SILENCER WITH TAIL PIPE	TATA spare parts
216054100105	ASSY CU BATT.CABLE +VE COMP.BCOS.TO BATT	TATA spare parts
216054100106	ASSY CU BATT.CABLE +VE COMP.BCOS TO ST.M	TATA spare parts
216054100108	ASSY TRAY	TATA spare parts
216054110101	ASSY.CU BATT.CABLE -VE COMP.BCOS TO BATT	TATA spare parts
216054110102	ASSY CU BATT.CABLE -VE COMP.BCOS TO ST.M	TATA spare parts
216054208201	MTG.BKT-NATO SOCKET AND REAR FOG LAMP	TATA spare parts
216054400106	ASSY. FRT. FOG LAMP.-24 V-YELLOW COLOUR	TATA spare parts
216154100101	ASSY.BATT.COVER - 120 AH	TATA spare parts
216154100102	ASSY.BATTERY COVER - 150 AH	TATA spare parts
216154100103	ASSY.BATTERY COVER - 150 AH	TATA spare parts
216154100105	PP-BATTERY COVER	TATA spare parts
216154100107	ASSY BATT COVER PLASTIC 150AH	TATA spare parts
216154100108	ASSY BATT COVER PLASTIC 120AH 2067542016	TATA spare parts
216154100109	ASSY BATT.COVER PLASTIC	TATA spare parts
216154100110	ASSY BATT COVER PLASTIC 100AH	TATA spare parts
216154100113	CARRIER PLATE FACIA SW	TATA spare parts
216160000102	ASSY. COWL COMPLETE.	TATA spare parts
216160000103	ASSY. COWL SHELL PAINTED	TATA spare parts
216160000104	ASSY.COWL COMPLETE LP1109 W/O FACE BSII	TATA spare parts
216160000106	ASSY. BARE COWL W/O FACE LP1109/36 BSII	TATA spare parts
216160100112	ASSY.BRACKET(AIR DUCT)	TATA spare parts
216188200104	ASSY.BKT.HEAD LAMP&BLINKER MTG.L.H.	TATA spare parts
216188200105	ASSY.BKT.HEAD LAMP RELAYS & BLINKER R.H.	TATA spare parts
216254820102	ASSY.CABLE SET -FRT.TO TAIL W.B 42	TATA spare parts
216254820103	ASSY.CABLE SET -FRT.TO TAIL W.B.48	TATA spare parts
216254820104	ASSY.CABLE SET-STOPLIGHT & LOW AIR PR.SW	TATA spare parts
216254820105	ASSY.CABLE SET-FRT.TO TAIL LAMP-W.B 59	TATA spare parts
216254820106	ASSY.CABLE SET -FRT.TO TAIL LAMP W.B-52	TATA spare parts
216301000101	ENGINE 180 HP BSIII LMRO	TATA spare parts
216301000104	ASSY ENGINE COMPLETE	TATA spare parts
216301000371	ENGINE ISBE5.9 180HP LMFO BSIV	TATA spare parts
216309130104	BRACKETASSY BS6	TATA spare parts
216309133801	PIPE AIR FILTER TO TC	TATA spare parts
216309135801	REDUCER HOSE (ON AIR OUTLET FILTER)	TATA spare parts
216309135804	REDUCER HOSE	TATA spare parts

216309135806	RUBBER HOSE ASSY HFM TO TC	TATA spare parts
216309135807	REDUCER HOSE (ON AIR FILTER OUTLET)	TATA spare parts
216309136901	PIPE(AIR FILTER TO TC)	TATA spare parts
216309136903	HOSE PIPE	TATA spare parts
216314606902	PIPE(TC TO IC)	TATA spare parts
216314606903	PIPE(IC TO ENGINE)	TATA spare parts
216314606904	PIPE TC TO IC	TATA spare parts
216314606906	ALUMINIUM PIPE DIA76X3THK (TC TO IC)	TATA spare parts
216314606907	ALUMINIUM PIPE DIA76.2X2THK. (IC TO ENGI	TATA spare parts
216314606908	PIPE INTERCOOLER TO ENGINE	TATA spare parts
216314606909	PIPE ENGINE TO INTERCOOLER	TATA spare parts
216314606910	PIPE INTERCOOLER TO ENGINE	TATA spare parts
216314606911	PIPE ENGINE TO INTERCOOLER	TATA spare parts
216314609902	INTERCOOLER	TATA spare parts
216315130101	KIT ALTERNATOR 24V 75A LPO1616	TATA spare parts
21632	DIFF. BEARING CUP LH	TATA spare parts
216324200101	ASSY.BRACKET-RH (ENGINE MTG.TOP)	TATA spare parts
216324200102	ASSY.BRACKET-LH (ENGINE MTG.TOP)	TATA spare parts
216324200103	ASSY.BKT.REAR (ENGINE MTG. BOTTOM)	TATA spare parts
216324200104	ASSY BRACKET TOP ENGINE MTG REAR-LH	TATA spare parts
216324200118	REAR ENGINE (TOP) MOUNT	TATA spare parts
216324200120	REAR ENGINE MOUNTING (TOP) RH SIDE	TATA spare parts
216324200125	BRACKET ASSY CHASSIS LH	TATA spare parts
216324200126	BRACKET ASSY CHASSIS RH	TATA spare parts
216324200129	ENGINE MOUNT ASSEMBLY LH	TATA spare parts
216324200130	ENGINE MOUNT ASSEMBLY RH	TATA spare parts
216324200135	ENGINE MTG.BRACKET LH FLYWHEEL SIDE	TATA spare parts
216324200136	ENGINE MOUNT-B ASSY LH CHASSIS SIDE	TATA spare parts
216324200137	ENGNIIE MTG.BRACKET RH FLYWHEEL SIDE	TATA spare parts
216324200138	ENGINE MOUNT-B ASSY	TATA spare parts
216324200140	ASSY ENGINE MTG BKT LH(FLYWHEEL SIDE)	TATA spare parts
216324200141	ASSY ENGINE MTG BKT RH(FLYWHEEL SIDE)	TATA spare parts
216324200142	ASSY ENGINE MTG BKT LH(CHASSIS SIDE)	TATA spare parts
216324200143	ASSY ENGINE MTG BKT RH(CHASSIS SIDE)	TATA spare parts
216324200144	ENGINE MOUNT ASSY LH FLYWHEEL SIDE	TATA spare parts
216324200145	ENGINE MOUNT ASSY RH FLYWHEEL SIDE	TATA spare parts
216324203302	BRACKET ENGINE MTG REAR-LH	TATA spare parts
216324203303	BRACKET ENGINE MTG REAR-RH	TATA spare parts
216324203703	BRACKET ENGINE MTG REAR F/W HSG LH	TATA spare parts
216324203704	BRACKET ENGINE MTG REAR F/W HSG RH	TATA spare parts
216324990102	KIT-ENGINE MTG - RETRO KIT	TATA spare parts
216326100101	ASSY GEAR BOX SUPPORT BKT-RH	TATA spare parts
216326100102	ASSY GEAR BOX SUPPORT BKT-LH	TATA spare parts
216326100103	ASSY GB SUPPORT BKT AT GB-RH	TATA spare parts
216326800101	ASSY.TURNING TUBE	TATA spare parts
216326800102	ASSY.TURNING TUBE (WITHOUT BALL JOINT).	TATA spare parts
216326800105	ASSY GEAR SHIFT BKT(BRTS 75AMP ALT)	TATA spare parts



216326800106	ASSY GEAR SHIFT BKT (LPO 1621-BS-IV)	TATA spare parts
216326800120	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
216326800127	ASSY.TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
216326800132	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
216326800138	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
216326800139	ASSY BKT (GEAR SHIFT LEVER MTG.)	TATA spare parts
216326800140	LINK ROD MTG BRACKET ASSY	TATA spare parts
216326800147	TURNING TUBE ASSY	TATA spare parts
216326800150	ASSY SELECTOR SHIFTER FORK WITH G.S. LEV	TATA spare parts
216326808001	FLAGE SERRATED BOLT M10 X 130	TATA spare parts
216326808002	FLANGE BOLT SERRATIONS-M10X125	TATA spare parts
216327000103	KIT AUTO TRANSMISSION	TATA spare parts
216327000104	AUTOMATIC TRANSMISSION UNIT T270R 2INCH	TATA spare parts
216327000105	KIT-AUTOMATIC TRANSMISSION	TATA spare parts
216327000106	KIT-AUTOMATIC TRANSMISSION	TATA spare parts
216327000108	AUTOMATIC TRANSMISSION	TATA spare parts
216327103702	CONVERTER HOUSING	TATA spare parts
216327200109	SHAFT ASSEMBLY	TATA spare parts
216327203205	BOLT FLANGE 1/2-20	TATA spare parts
216327203209	BOLT BS6	TATA spare parts
216327203210	SCREW - 5/16 - 24UNF-0.87INCHLG	TATA spare parts
216327204601	FLANGE 150CS (SUP PN 29545137)	TATA spare parts
216327209202	WASHER FLANGE (SUP PN 29536848)	TATA spare parts
216327405503	HUB ADAPTER	TATA spare parts
216327407103	FLEX PLATE	TATA spare parts
216327408705	SPRING ACCUMULATOR	TATA spare parts
216327409004	VALVE CONTROL MAIN	TATA spare parts
216327409006	VALVE EXHAUST BACKFILL	TATA spare parts
216327508201	GASKET HOUSING	TATA spare parts
216327600104	HOSE TRANS TO COOLER	TATA spare parts
216327600105	HOSE COOLER TO TRNASMISSION	TATA spare parts
216327600110	HOSE TRANSMISSION TO COOLER	TATA spare parts
216327600111	HOSE COOLER TO TRANSMISSION	TATA spare parts
216327603601	FILTER CONTROL MAIN	TATA spare parts
216327604909	TCM FOR LPO1621 BS-IV AC	TATA spare parts
216327604914	HARNESS INTERNAL	TATA spare parts
216327606806	CONNECTOR ELBOW AUTOMATIC TRANSMISSION	TATA spare parts
216327606807	ELBOW FITTING	TATA spare parts
216327606808	STRAIGHT FITTING	TATA spare parts
216327609901	FILLTUBE/DIPSTICK ASSY	TATA spare parts
216327609902	SHIFT SELECTOR	TATA spare parts
216327609903	SHIFTER CABLE	TATA spare parts
216327609904	KIT-TRANSMISSION CONNECTION	TATA spare parts
216327700102	ASSY SHIFT SELECTOR-GEN4 AUTOMATIC TRANS	TATA spare parts
216327700104	BRACKET ASSY SHIFT SELECTOR MTG	TATA spare parts
216327800104	ASSEMBLY BRACKET ACCUMULATOR MTG	TATA spare parts
216327800105	ASSY BRACKET OTW MTG	TATA spare parts

216327800106	BRACKET ASSY (ACCUMULATOR MTG)	TATA spare parts
216327800109	BRACKET ASSY OTW MTG	TATA spare parts
216327804301	RETAINER CLIP	TATA spare parts
216327807124	BRACKET	TATA spare parts
216327807125	BRACKET	TATA spare parts
216327807127	CLAMP HOLDING BRACKET	TATA spare parts
216327807143	BRACKET TRANSMISSION HOSE HOLDING	TATA spare parts
216327807144	BRACKET TRANSMISSION HOSE HOLDING	TATA spare parts
216327807149	BRACKET OIL COOLER HOSE	TATA spare parts
216327807150	SPACER	TATA spare parts
216327807157	BRACKET BS6	TATA spare parts
216329100104	ASSY FORK(CLUTCH BOOSTER)	TATA spare parts
216329100106	ASSY. CLUTCH FLUID CONTAINER WITH CLAMP	TATA spare parts
216329100125	ASSY. CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
216329100133	ASSY CLUTCH BOOSTER MTG BKT	TATA spare parts
216329100134	ASSY PEDAL SUPPORT WITH TUBE COMP	TATA spare parts
216329100141	ASSY CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
216329100143	ASSY CLUTCH CONTROL COMPLETE	TATA spare parts
216329100147	ASSY RUBBER HOSE(CMC TO CONTAINER)	TATA spare parts
216329100148	ASSY.PIPE 6 O.D (CB TO CMC)	TATA spare parts
216329100152	ASSY CB MTG BKT	TATA spare parts
216329100153	ASSY. CLUTCH BOOSTER 4" WABCO BS1/2/3/4	TATA spare parts
216329100154	ASSY CB.SUPPORT BKT 4INCH	TATA spare parts
216329100158	ASSY RUBBER HOSE	TATA spare parts
216329100160	ASSY CLUTCH BOOSTER MTG BKT 4IN	TATA spare parts
216329100162	SUPPORT BRACKET (FOR CLUTCH ASSY)	TATA spare parts
216329100163	RUBBER HOSE CMC TO CL CONTAINER	TATA spare parts
216329100165	PIPE ASSY-2 6OD (CB TO CMC)	TATA spare parts
216329100166	RUBBER HOSE CMC TO CL CONTAINER	TATA spare parts
216329100167	PIPE ASSY CMC TO INT JOINT	TATA spare parts
216329100168	PIPE ASSY INT JOINT TO CLUTCH BOOSTER	TATA spare parts
216329100173	CLUTCH PIPE ASSY	TATA spare parts
216329106911	HOSE MASTER CYLINDER TO FLUID CONTAINER	TATA spare parts
216329150101	ASSY CONNECTING LINE	TATA spare parts
216329150102	ASSY TUBE(6 O.D. X 3160 LG.)	TATA spare parts
216329500102	ASSY.PEDAL SUPPORT WITH TUBE	TATA spare parts
216329500104	ASSY.SUPPORT PEDAL WITH TUBE	TATA spare parts
216329500130	T BRACKET (ON G.B.)	TATA spare parts
216329500138	ACC MTG BKT W/STOPPER	TATA spare parts
216329500140	ASSY SUPPORT PEDAL WITH TUBE	TATA spare parts
216329503302	BRACKET CLUTCH HOSE	TATA spare parts
216329508202	SUPPORT CLUTCH HOSE	TATA spare parts
216329508203	SUPPORT CLUTCH HOSE	TATA spare parts
216329508204	SUPPORT CLUTCH HOSE	TATA spare parts
216330100103	ASSY. ACLTR LEVER W/O BALL PIN	TATA spare parts
216330100104	ASSY. ACLTR LEVER W/O BALL PIN	TATA spare parts
216330100109	ASSY BRACKET WITH SENSOR MTG BKT	TATA spare parts

216330100110	ASSY CONTROL SHAFT WITH SENSOR BKT	TATA spare parts
216330100114	ASSY STOPPER	TATA spare parts
216330100121	ASSY BKT SENSOR & CABLE HOLDING BKT	TATA spare parts
216330100127	BRACKET ASSY ACCELERATOR CABLE MTG	TATA spare parts
216330106001	EXTENDED LEVER FIP LEVER	TATA spare parts
216330107110	ACC.CABLE MTG.BKT.	TATA spare parts
216330107114	BKT FOR RETURN SPRING¿ AT FOB	TATA spare parts
216330200101	ASSY STOP CABLE COMPLETE	TATA spare parts
216330200103	ASSY MTG BKT FOR EMOS SOLENOID	TATA spare parts
216330200104	ASSY FIP EXTENSION LEVER	TATA spare parts
216331000101	ASSY. FRAME COMPLETE.	TATA spare parts
216331000102	ASSY. FRAME COMPLETE.	TATA spare parts
216331000103	ASSY. FRAME FOR LPT1613TC/62 TRUCK CHASS	TATA spare parts
216331000106	ASSY.FRAME COMPLETE	TATA spare parts
216331000107	FRAME ASSY WITH FITMENT	TATA spare parts
216331000109	ASSY.FRAME COMPL(PNEUM.SUSPENSION-VOITH	TATA spare parts
216331000110	ASSY FRAME COMP(FRONT WAV REAR PN SUS)	TATA spare parts
216331000114	ASSY FRAME WITH OUTRIGGER LPO1618 BMTC	TATA spare parts
216331000115	ASSY.FRAME COMPLETE (NORMAL SUSP)1823	TATA spare parts
216331000116	ASSY FRAME WITH OUTRIGGER LPO1621/62 EIV	TATA spare parts
216331000120	ASSY FRAME WITH OUTRIGGER LPO 1618TC/62	TATA spare parts
216331000129	ASSY FRAME COMPLETE	TATA spare parts
216331000145	FRAME ASSY WITH FITMENT	TATA spare parts
216331000149	FRAME ASSY WITH OUTRIGGER	TATA spare parts
216331000152	FRAMEASSYWITFITMENT	TATA spare parts
216331000153	ASSY FRAME COMPLETE WITH PLATES	TATA spare parts
216331000156	FRAME ASSY WITHOUT OUTRIGGERS	TATA spare parts
216331000158	FRAMEASSYCOMPLETE	TATA spare parts
216331000159	FRAME ASSY WITH FITMENT	TATA spare parts
216331107132	LONG MEMBER RH HUMP LPO1618 840 CH HT	TATA spare parts
216331107133	LONG MEMBER LH HUMP LPO 1618 840 CH HT	TATA spare parts
216331107140	LONG MEMBER RH REAR OUTRIGGER	TATA spare parts
216331107141	LONG MEMBER LH REAR OUTRIGGER	TATA spare parts
216331200101	ASSY. END CROSS MEMBER	TATA spare parts
216331200102	ASSY RETARDER MTG BKT-LH	TATA spare parts
216331200103	ASSY RETARDER MTG BKT-RH	TATA spare parts
216331200105	ASSY CROSS MEMBER (FOR REAR SHOCK ABSORB	TATA spare parts
216331200107	ASSY CROSS MEMBER (OUTRIGGER SUPPORT)	TATA spare parts
216331200108	ASSY RECT.TUBULAR CROSS MEMBER-OUTRIGGE	TATA spare parts
216331200111	ASSY BUMPER CROSS MEMBER	TATA spare parts
216331200112	ASSY SUPPORT(ENG. CM FRONT )	TATA spare parts
216331200113	ASSY SPACER PLATE	TATA spare parts
216331200114	ASSY SUPPORT(THIRD X-MEMBER MTG)	TATA spare parts
216331200115	ASSY SPACER PLATE(THIRD X MEM MTG)	TATA spare parts
216331200117	FRT¿ BUMPER¿ CROSS MEMBER	TATA spare parts
216331200118	ASSY ENGINE CROSS MEMBER FRONT	TATA spare parts
216331200122	ALLIGATED CROSS MEMBER ASSY	TATA spare parts

216331200124	CROSS MEMBER ASSY	TATA spare parts
216331200125	ASSY SPACER	TATA spare parts
216331200126	REINFRMT TO BE WELDED FOR C/M	TATA spare parts
216331200130	ASSY SUPPORT(ENG.CR.MEM)LOWERED	TATA spare parts
216331200131	ASSEMBLY CROSS MEMBER	TATA spare parts
216331200132	ASSEMBLY CROSS MEMBER	TATA spare parts
216331200133	ASSEMBLY CROSS MEMBER	TATA spare parts
216331200134	ASSEMBLY CROSS MEMBER	TATA spare parts
216331200137	ASSEMBLY CROSS MEMBER	TATA spare parts
216331200138	ASSEMBLY CROSS MEMBER	TATA spare parts
216331200141	ASSY BUMPER CROSS MEMBER	TATA spare parts
216331200143	ASSY BUMPER CROSS MEMBER REAR	TATA spare parts
216331200147	ASSEMBLY CROSS MEMBER DAMPER	TATA spare parts
216331200148	ASSY CROSS MEMBER	TATA spare parts
216331200151	CROSS MEMBER ASSY	TATA spare parts
216331200152	BRACKET HAT TYPE ASSY	TATA spare parts
216331200153	ASSY. TUBULAR CROSS MEMBER	TATA spare parts
216331200154	CROSS MEMBER ASSY	TATA spare parts
216331200155	CROSS MEMBER ASSY	TATA spare parts
216331200168	SUPPORT ASSY	TATA spare parts
216331207113	END CROSS MEMBER - FOR 285 WEB	TATA spare parts
216331207127	SPACER - 4MM	TATA spare parts
216331207128	SPACER REAR - 7MM	TATA spare parts
216331207129	SPACER FRONT - 7MM	TATA spare parts
216331207130	SPACER - 5MM	TATA spare parts
216331207131	SPACER ROUND - 5MM	TATA spare parts
216331207161	BASE PLATE CROSS MEMBER SUPPORT	TATA spare parts
216331207178	GUSSET LH-¿ BCM	TATA spare parts
216331207179	GUSSET RH-¿ BCM	TATA spare parts
216331207184	SUPPORT LH (ENGINE CROSS MEMBER FRONT)	TATA spare parts
216331207185	SUPPORT RH (ENGINE CROSS MEMBER FRONT)	TATA spare parts
216331207214	FLITCH (RH)	TATA spare parts
216331207215	FLITCH (LH)	TATA spare parts
216331207222	FLITCH RH	TATA spare parts
216331207223	FLITCH LH	TATA spare parts
216331207231	FRONT EXTENSION	TATA spare parts
216331207232	SPACER 5MM AT ARB	TATA spare parts
216331207233	SPACER FRONT - 7MM	TATA spare parts
216331207234	END CROSS MEMBER - FOR 285 WEB BS6	TATA spare parts
216331207238	BUMPER CM SUPPORT RH	TATA spare parts
216331207239	BUMPER CM SUPPORT LH	TATA spare parts
216331207251	SUPPORT BOTTOM FOR CROSS MEMBER	TATA spare parts
216331207252	SUPPORT BOTTOM FOR CROSS MEMBER	TATA spare parts
216331207253	SUPPORT BOTTOM FOR CROSS MEMBER (RH)	TATA spare parts
216331207254	SUPPORT BOTTOM FOR CROSS MEMBER (LH)	TATA spare parts
216331208201	GUSSET-TOP R.H BUMPER CROSS MEMBER	TATA spare parts
216331208202	GUSSET-TOP L.H-BUMPER CROSS MEMBER	TATA spare parts

216331300101	GUSSET ASSY - RH	TATA spare parts
216331300102	GUSSET ASSY - LH	TATA spare parts
216331307101	SUPPORT TOP - R.H	TATA spare parts
216331307102	SUPPORT TOP - L.H	TATA spare parts
216331307104	REINFORCEMENT RH - TOP	TATA spare parts
216331307106	REINFORCEMENT RH	TATA spare parts
216331307113	REINFORCEMENT RH	TATA spare parts
216331307114	REINFORCEMENT LH	TATA spare parts
216331307117	REINFORCEMENT - RH	TATA spare parts
216331307118	REINFORCEMENT - LH	TATA spare parts
216331307123	REINFORCEMENT BOTTOM - RH	TATA spare parts
216331307124	REINFORCEMENT BOTTOM - LH	TATA spare parts
216331307125	REINFORCEMENT - RH	TATA spare parts
216331307126	REINFORCEMENT - LH	TATA spare parts
216331307133	REINFORCEMENT RH LPO 1621 BS IV	TATA spare parts
216331307134	REINFORCEMENT LH LPO 1621 BS IV	TATA spare parts
216331307135	SPRING BRACKET RH LPO 1621 BS IV	TATA spare parts
216331307136	REINFORCEMENT LH LOP 1621 BS IV	TATA spare parts
216331307137	REINFORCEMENT RH	TATA spare parts
216331307138	REINFORCEMENT LH	TATA spare parts
216331307139	SPACER	TATA spare parts
216331307142	REINFORCEMENT-RH	TATA spare parts
216331307143	REINFORCEMENT-LH	TATA spare parts
216331307146	REINFORCEMENT	TATA spare parts
216331307154	REINFORCEMENT RH	TATA spare parts
216331307155	REINFORCEMENT LH	TATA spare parts
216331307156	REINFORCEMENT RH	TATA spare parts
216331307157	REINFORCEMENT LH	TATA spare parts
216331307158	REINFORCEMENT-TOP LH	TATA spare parts
216331307159	REINFORCEMENT-TOP RH	TATA spare parts
216331307160	REINFORCEMENT LH	TATA spare parts
216331307161	REINFORCEMENT RH	TATA spare parts
216331307168	REINFORCEMENT LH	TATA spare parts
216331307169	REINFORCEMENT RH	TATA spare parts
216331307184	GUSSET RH	TATA spare parts
216331307185	GUSSET LH	TATA spare parts
216331307186	GUSSET RH	TATA spare parts
216331307187	GUSSET LH	TATA spare parts
216331308201	GUSSET TOP -R.H END CROSS MEMBER	TATA spare parts
216331308202	GUSSET TOP -L.H END CROSS MEMBER	TATA spare parts
216331308203	BRACKET MUX 2B MTG	TATA spare parts
216331308213	GUSSET RH	TATA spare parts
216331308214	GUSSET LH	TATA spare parts
216331308215	GUSSET RH	TATA spare parts
216331308216	GUSSET LH	TATA spare parts
216331308217	GUSSET RH	TATA spare parts
216331308218	GUSSET LH	TATA spare parts

216331308219	REINFORCEMENT RH	TATA spare parts
216331308220	REINFORCEMENT LH	TATA spare parts
216331308221	REINFORCEMENT RH	TATA spare parts
216331308222	REINFORCEMENT LH	TATA spare parts
216331317123	REINFORCEMENT RH	TATA spare parts
216331317124	REINFORCEMENT LH	TATA spare parts
216331320106	WHEEL ARCH MTG ASSY	TATA spare parts
216331320115	WHEEL ARCH MTG ASSY	TATA spare parts
216331328231	PACKING PLATE	TATA spare parts
216331328232	PACKING PLATE	TATA spare parts
216331700102	ASSY GEAR BOX SHIELD BOTTOM	TATA spare parts
216331700103	ASSY NOISE SHIELD ( OIL SUMP)	TATA spare parts
216331700104	ASSY ENGINE ENCAPSULATION	TATA spare parts
216331700105	ASSY. ENGINE ENCAPSULATION LH	TATA spare parts
216331700107	END CROSS MEMBER. (210 DEEP TAIL END)	TATA spare parts
216331700108	ASSY.SIDE PLATE	TATA spare parts
216331700109	ASSY.BRACKET-LH ( RUPD )	TATA spare parts
216331700110	ASSY.BRACKET-RH ( RUPD )	TATA spare parts
216331700127	ASSY OUTRIGGER-I (LH)	TATA spare parts
216331700128	ASSY OUTRIGGER-I (RH)	TATA spare parts
216331700129	ASSY OUTRIGGER-II (LH)	TATA spare parts
216331700130	ASSY OUTRIGGER-II (RH)	TATA spare parts
216331700131	ASSY OUTRIGGER-III (LH)	TATA spare parts
216331700132	ASSY OUTRIGGER-III (RH)	TATA spare parts
216331700134	ASSY OUTRIGGER-V	TATA spare parts
216331700135	ASSY OUTRIGGER IV RH	TATA spare parts
216331700136	ASSY OUTRIGGER V RH	TATA spare parts
216331700137	ASSY OUTRIGGER-I (LH)	TATA spare parts
216331700138	ASSY OUTRIGGER-I (RH)	TATA spare parts
216331700139	ASSY OUTRIGGER-II (LH)	TATA spare parts
216331700140	ASSY OUTRIGGER-II (RH)	TATA spare parts
216331700141	ASSY OUTRIGGER-III (LH)	TATA spare parts
216331700142	ASSY OUTRIGGER-III (RH)	TATA spare parts
216331700143	ASSY OUTRIGGER-IV (LH)	TATA spare parts
216331700144	ASSY OUTRIGGER-IV (RH)	TATA spare parts
216331700145	ASSY OUTRIGGER-V (LH)	TATA spare parts
216331700146	ASSY OUTRIGGER-VI (RH)	TATA spare parts
216331700155	ASSY. OUTRIGGER -1 (FRONT LH SIDE)	TATA spare parts
216331700156	ASSY. OUTRIGGER -2 (FRONT LH SIDE)	TATA spare parts
216331700157	ASSY. OUTRIGGER -3 (FRONT LH SIDE)	TATA spare parts
216331700158	ASSY. OUTRIGGER -4 (FRONT RH SIDE)	TATA spare parts
216331700160	ASSY OUTRIGGER-IV	TATA spare parts
216331700161	ASSY OUTRIGGER IV RH	TATA spare parts
216331700162	REAR DOOR FRONT OUTRIGGER TN	TATA spare parts
216331700163	ASSY FUPD MTG. BKT. (LH)	TATA spare parts
216331700164	ASSY FUPD MTG. BKT. (RH)	TATA spare parts
216331700166	ASSY OUTRIGGER -V (LH)	TATA spare parts

216331700167	ASSY OUTRIGGER V RH	TATA spare parts
216331700168	ASSY OUTRIGGER MIDDLE DOOR LH	TATA spare parts
216331700169	ASSY OUTRIGGER MIDDLE DOOR RH	TATA spare parts
216331700192	ASSY OUTRIGGER (FRONT RH SIDE)	TATA spare parts
216331700196	ASSY. FUPD CROSS BEAM COMPLETE	TATA spare parts
216331700201	ENGINE MOUNT BRACKET ASSEMBLY LH-FRAME S	TATA spare parts
216331700202	ENGINE MOUNT ASSEMBLY RH FRAME SIDE	TATA spare parts
216331700212	ASSY. OUTRIGGER -2 (FRONT LH SIDE)	TATA spare parts
216331700214	ASSY AC COMPRESSOR MTG BKT	TATA spare parts
216331700218	3RD RIGHT SIDE OUTRIGGER	TATA spare parts
216331700219	5TH RIGHT SIDE OUTRIGGER	TATA spare parts
216331700220	6TH RIGHT SIDE OUTRIGGER	TATA spare parts
216331700221	7TH RIGHT SIDE OUTRIGGER	TATA spare parts
216331700222	8TH RIGHT SIDE OUTRIGGER	TATA spare parts
216331700223	8TH LEFT SIDE OUTRIGGER	TATA spare parts
216331700224	7TH LEFT SIDE OUTRIGGER	TATA spare parts
216331700225	1ST LEFT SIDE OUTRIGGER	TATA spare parts
216331700226	12TH LEFT SIDE OUTRIGGER	TATA spare parts
216331700228	2ND LEFT SIDE OUTRIGGER	TATA spare parts
216331700229	4L OUTRIGGER WITH FUEL FILTER MTG BKT	TATA spare parts
216331700230	ASSY SUPPORT PLATE RH	TATA spare parts
216331700231	ASSY SUPPORT PLATE LH	TATA spare parts
216331700236	BRACKET BODY MOUNTING RH MIDDLE OF PS	TATA spare parts
216331700237	BRACKET BODY MOUNTING LH MIDDLE OF PS	TATA spare parts
216331700238	BRACKET BODY MOUNTING RH (FRONT AXLE)	TATA spare parts
216331700239	BRACKET BODY MOUNTING LH (FRONT AXLE)	TATA spare parts
216331700240	OUTRIGGER ASSY	TATA spare parts
216331700244	OUTRIGGER ASSY RH	TATA spare parts
216331700245	OUTRIGGER ASSY FUEL TANK	TATA spare parts
216331700246	OUTRIGGER ASSY FUEL TANK	TATA spare parts
216331700247	OUTRIGGER ASSY	TATA spare parts
216331700248	OUTRIGGER ASSY	TATA spare parts
216331700249	OUTRIGGER ASSY	TATA spare parts
216331700250	OUTRIGGER ASSY	TATA spare parts
216331700252	OUTRIGGER ASSY	TATA spare parts
216331700258	OUTRIGGER ASSY RH	TATA spare parts
216331700270	OUTRIGGER ASSY RH	TATA spare parts
216331700272	OUTRIGGER ASSY RH	TATA spare parts
216331700273	OUTRIGGER ASSY LH	TATA spare parts
216331700274	OUTRIGGER ASSY RH	TATA spare parts
216331700275	OUTRIGGER ASSY LH	TATA spare parts
216331700289	BRACKET ASSY BODY MTG	TATA spare parts
216331703301	SUPPORT BRACKET (SIDE SHIELDING)	TATA spare parts
216331703302	SUPPORT BRACKET LH (GEAR BOX SHIELD)	TATA spare parts
216331703303	SUPPORT BRACKET RH (GEAR BOX SHIELD)	TATA spare parts
216331707148	OUTRIGGER GUSSET	TATA spare parts
216331707153	C-CHANNEL	TATA spare parts

216331707154	C-CHANNEL	TATA spare parts
216331707155	C-CHANNEL	TATA spare parts
216331707185	C-CHANNEL	TATA spare parts
216331707186	C-CHANNEL	TATA spare parts
216331707261	BRACKET BODY MOUNTING RH	TATA spare parts
216331707262	BRACKET BODY MOUNTING LH	TATA spare parts
216331707288	TOWING HOOK	TATA spare parts
216331707290	SPACER	TATA spare parts
216331708276	SUPPORT SHEET BODY MTG	TATA spare parts
216331708277	SUPPORT SHEET BODY MTG	TATA spare parts
216331709201	WASHER BS6	TATA spare parts
216331717120	PLATE	TATA spare parts
216331717122	PLATE	TATA spare parts
216331717123	PLATE	TATA spare parts
216331717124	PLATE	TATA spare parts
216331717125	PLATE	TATA spare parts
216331717126	PLATE	TATA spare parts
216331717127	PLATE	TATA spare parts
216331717128	PLATE	TATA spare parts
216331717129	PLATE	TATA spare parts
216331717130	PLATE	TATA spare parts
216331717131	PLATE	TATA spare parts
216331717132	PLATE	TATA spare parts
216331717134	GUSSET-LH	TATA spare parts
216331717135	PLATE	TATA spare parts
216331717136	PLATE	TATA spare parts
216331717137	PLATE	TATA spare parts
216331717138	PLATE	TATA spare parts
216331717139	PLATE-RH	TATA spare parts
216331717140	PLATE-LH	TATA spare parts
216331717141	PLATE-LH	TATA spare parts
216331717146	C PLATE	TATA spare parts
216331717160	PLATE-RH	TATA spare parts
216331717167	GUSSET-RH	TATA spare parts
216331717182	PLATE	TATA spare parts
216331717199	PLATE FOR BODY BUILDING	TATA spare parts
216331727101	SPACER FRONT	TATA spare parts
216331727110	PLATE LH	TATA spare parts
216331727111	PLATE RH	TATA spare parts
216331800104	ASSY OUTRIGGER-3 (FRONT LH-SIDE)	TATA spare parts
216331800105	ASSY OTRIGER FRT-RH DOOR LPO1621BS4	TATA spare parts
216331800109	ASSY OUTRIGGER(FRONT DOOR)	TATA spare parts
216332100114	BRACKET ASSY CROSS CONNECTION	TATA spare parts
216332100115	TORQUE ROD ASSY FRONT	TATA spare parts
216332100118	ASSY. FRONT SPRING CO-DRIVER SIDE	TATA spare parts
216332100119	ASSY. FRONT SPRING DRIVER SIDE	TATA spare parts
216332100121	FRONT SPRING ASSY	TATA spare parts



216332100122	FRONT SPRING ASSY	TATA spare parts
216332100123	FIRST LEAF ASSY	TATA spare parts
216332100124	SECOND LEAF ASSY	TATA spare parts
216332100139	LEAF SPRING ASSY FRONT-LH	TATA spare parts
216332100140	LEAF SPRING ASSY FRONT-RH	TATA spare parts
216332103202	CENTER BOLT	TATA spare parts
216332103203	CENTER BOLT	TATA spare parts
216332103204	CENTER BOLT	TATA spare parts
216332103307	BRACKET FRONT SPRING LOWER-LH	TATA spare parts
216332103308	BRACKET FRONT SPRING LOWER-RH	TATA spare parts
216332104205	U-BOLT	TATA spare parts
216332104206	SPRING CLIP	TATA spare parts
216332104207	SPRING CLIP	TATA spare parts
216332104802	DOWEL PIN	TATA spare parts
216332107108	THIRD LEAF	TATA spare parts
216332107109	FOURTH LEAF	TATA spare parts
216332107110	FIFTH LEAF	TATA spare parts
216332107111	SIXTH LEAF	TATA spare parts
216332107112	SEVENTH LEAF	TATA spare parts
216332107113	EIGHTH LEAF	TATA spare parts
216332107114	NINETH LEAF	TATA spare parts
216332107115	TENTH LEAF	TATA spare parts
216332107120	BRACKET HEIGHT SENSOR LINK MTG	TATA spare parts
216332107701	RUBBER BLOCK WEWELLER SUSPENSION	TATA spare parts
216332108201	LOCKING SHEET	TATA spare parts
216332108202	SPRING CLIP (WEWELLER)	TATA spare parts
216332204201	U-CLAMP-FRONT	TATA spare parts
216332207111	BRACKET CHARGING VALVE MTG	TATA spare parts
216332300103	ASSY SHOCK ABSORBER MTG BKT WITH MTG PIN	TATA spare parts
216332300104	ASSY SHOCK ABSORBER MTG BKT WITH MTG PIN	TATA spare parts
216332300105	SHOCK ABSORBER ASSYFRONT	TATA spare parts
216332300106	BRACKET ASSY SHOCK ABSORBER MTG UPPER-LH	TATA spare parts
216332300107	BRACKET ASSY SHOCK ABSORBER MTG UPPER-RH	TATA spare parts
216332303301	BRACKET (SHOCK ABSORBER FRONT BOTTOM)	TATA spare parts
216332303302	BRACKET (SHOCK ABSORBER FRONT BOTTOM)	TATA spare parts
216332303304	COMBINED ARB AND SHOCK ABS MTG BKT-LH	TATA spare parts
216332303305	COMBINED ARB AND SHOCK ABS MTG.BKT-RH	TATA spare parts
216332308601	SHIM 1.00 THK.	TATA spare parts
216332308602	SHIM 2.00 THK.	TATA spare parts
216332309201	WASHER	TATA spare parts
216332400101	ASSY REAR SPRING	TATA spare parts
216332400102	ASSY FIRST LEAF WITH BUSH	TATA spare parts
216332400104	LEVELLING VALVE ASSY - LH	TATA spare parts
216332400105	PARALLEL LINK ASSY LH	TATA spare parts
216332400106	PARALLEL LINK ASSY RH	TATA spare parts
216332400107	LEVELLING VALVE ASSY - RH	TATA spare parts
216332400108	REAR AIR SPRING C/M FLITCH & GUSSET-RH	TATA spare parts

216332400109	REAR AIR SPG C/M FLITCH & GUSSET-LH	TATA spare parts
216332400110	REAR AIR SPRING BKT-LH	TATA spare parts
216332400111	REAR AIR SPRING BKT-RH	TATA spare parts
216332400112	COMPOUND LINK	TATA spare parts
216332400113	PARALLEL LINK PIVOT AND AIR SPRING BKT-	TATA spare parts
216332400114	PARALLEL LINK PIVOT AND AIR SPRING BKT-L	TATA spare parts
216332400115	FRONT AIR SPRING CROSS MEMBER ASSY (8TH	TATA spare parts
216332400116	SUBFRAME ASSY WITH ANTI ROLL BAR ASSY	TATA spare parts
216332400117	AXLE ASSY- REAR AIR SUSPENSION	TATA spare parts
216332400119	ASSY KIT REAR PN SUSPENSION	TATA spare parts
216332400126	Non Return Valve (NRV)	TATA spare parts
216332400127	ASSY ELBOW WITH NUT	TATA spare parts
216332400129	ASSY CONNECTING ROD	TATA spare parts
216332400130	12INCH ROLLING DIAPHGRM	TATA spare parts
216332400131	BUMP STOP (BIG)	TATA spare parts
216332400132	ASSY. REAR SPRING	TATA spare parts
216332400143	HANGER LINK ASSY	TATA spare parts
216332400144	PARALLEL LINK PIVOT AND AIR SPRING BKT-R	TATA spare parts
216332400145	PARALLEL LINK PIVOT AND AIR SPRING BKT-L	TATA spare parts
216332400146	ASSY. AIR SPRING REAR 12 BS2/3/4/6	TATA spare parts
216332400147	SUB FRAME	TATA spare parts
216332400153	COMPOUND LINK PULLER	TATA spare parts
216332400154	SHOCK ABSORBER CLAMP (AIR SUS)	TATA spare parts
216332400192	HANGER LINK ASSY	TATA spare parts
216332400193	BRACKET COMPOUND LINK	TATA spare parts
216332400196	REAR AIR SPRING CM FLITCH & GUSSET LH	TATA spare parts
216332400197	REAR AIR SPRING CM FLITCH & GUSSET RH	TATA spare parts
216332403201	CENTER BOLT	TATA spare parts
216332403202	MOUNTING BOLT M20X2.5X200	TATA spare parts
216332403203	HEX BOLT M16X2X120	TATA spare parts
216332403204	HEX BOLT M16X2X60	TATA spare parts
216332403205	HEX BOLT M16X2X100 - 10.9	TATA spare parts
216332403206	HEX FLANGE BOLT	TATA spare parts
216332403209	HEX FLANGE BOLT	TATA spare parts
216332403210	HEX FLANGE BOLT	TATA spare parts
216332403211	HEX FLANGE BOLT	TATA spare parts
216332403212	HEX BOLT	TATA spare parts
216332403301	HANGER LINK BKT - LH	TATA spare parts
216332403302	HANGER LINK BKT - RH	TATA spare parts
216332403303	REAR LEVELLING VALVE BKT - LH	TATA spare parts
216332403304	REAR LEVELLING VALVE BKT - RH	TATA spare parts
216332403305	HANGER LINK BOTTOM CUP	TATA spare parts
216332403308	BRACKET RADIUS ROD MTG	TATA spare parts
216332403309	BRACKET LEVELLING VALVE MTG LH	TATA spare parts
216332403310	BRACKET LEVELLING VALVE MTG RH	TATA spare parts
216332403313	HANGER LINK BKT - LH	TATA spare parts
216332403314	HANGER LINK BKT - RH	TATA spare parts

216332403315	PIVOT BOLT PULLER	TATA spare parts
216332403701	U-BOLT SADDLE	TATA spare parts
216332404201	U-BOLT M22X2.5X405MM	TATA spare parts
216332406502	HEX NUT M16X2	TATA spare parts
216332406701	TAPER PIVOT SPIGOT	TATA spare parts
216332407102	SECOND LEAF	TATA spare parts
216332407103	THIRD LEAF	TATA spare parts
216332407104	FOURTH LEAF	TATA spare parts
216332407105	FIFTH LEAF	TATA spare parts
216332407106	SIXTH LEAF	TATA spare parts
216332407107	SEVENTH LEAF	TATA spare parts
216332407108	EIGHTH LEAF	TATA spare parts
216332407109	NINTH LEAF	TATA spare parts
216332407110	TENTH LEAF	TATA spare parts
216332407111	ELEVENTH LEAF	TATA spare parts
216332407112	TWELVETH LEAF	TATA spare parts
216332407113	THIRTEENTH LEAF	TATA spare parts
216332407114	FOURTEENTH LEAF	TATA spare parts
216332407115	REAR AIR SPRING CROSS MEMBER CROSS BEAM	TATA spare parts
216332407116	9TH CROSS MEMBER CROSS BEAM	TATA spare parts
216332407117	REAR FLITCH -RH	TATA spare parts
216332407119	LEVELLING VALVE LEVER	TATA spare parts
216332407120	CASTERPLATE BS6	TATA spare parts
216332407145	HANGER LINK MTG. BKT. BS6	TATA spare parts
216332407146	FLITCH REAR-LH	TATA spare parts
216332407147	FLITCH REAR-RH	TATA spare parts
216332407148	BEAM	TATA spare parts
216332407150	BRACKET HANGER LINK MTG	TATA spare parts
216332407501	RUBBER BUSH HALF	TATA spare parts
216332407502	SPHERILASTIC BUSH	TATA spare parts
216332407503	SPHERILASTIC BUSH	TATA spare parts
216332407601	LINK CHANNEL	TATA spare parts
216332407901	ANTI ROLL BAR REAR	TATA spare parts
216332410101	REAR SUSPENSION ASSY	TATA spare parts
216332410102	CROSS MEMBER ASSY FRONT AIR SPRING	TATA spare parts
216332410103	PARALLEL LINK PIVOT & AIR SPRING BKT LH	TATA spare parts
216332410104	PARALLEL LINK PIVOT & AIR SPRING BKT RH	TATA spare parts
216332410106	BRACKET REAR AIR SPRING MTG LH	TATA spare parts
216332410107	BRACKET REAR AIR SPRING MTG RH	TATA spare parts
216332410108	PARALLEL LINK ASSY LH	TATA spare parts
216332410109	PARALLEL LINK ASSY RH	TATA spare parts
216332410110	RADIUS ROD ASSY	TATA spare parts
216332410113	BUSH ASSY	TATA spare parts
216332410121	SUBFRAME ASSY	TATA spare parts
216332410122	LEVELLING VALVE ASSY LH	TATA spare parts
216332410123	LEVELLING VALVE ASSY RH	TATA spare parts
216332410124	CONNECTING ROD ASSY	TATA spare parts

216332600101	ASSY REAR SHOCK ABSORBER BRACKET LH	TATA spare parts
216332600102	ASSY SHOCK ABSORBER BRACKET - RH	TATA spare parts
216332600103	ASSY REAR SHOCK ABSORBER FOR PN SUSP	TATA spare parts
216332800104	LINK ASSY FRONT ANTI ROLL BAR	TATA spare parts
216332803301	CLAMP ANTI ROLL BAR MTG	TATA spare parts
216332803701	BRACKET ANTIROLL BAR MTG.	TATA spare parts
216332807104	CLAMP ANTIROLL BAR LINK	TATA spare parts
216332807901	ANTI ROLL BAR FRONT	TATA spare parts
216332950101	PIPE BUNCH ASSY	TATA spare parts
216333000101	ASSY.FRONT AXLE COMPL.WITH BRAKES	TATA spare parts
216333000105	ASSY. FRONT AXLE COMPLETE WITH BRAKES	TATA spare parts
216333000106	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
216333000107	ASSY. FRONT AXLE COMPL 7.5T	TATA spare parts
216333000112	FRONT AXLE ASSY 8H MTG CGT BRAKES WITH A	TATA spare parts
216333000114	FRONT AXLE ASSY 8H MTG NGT BRAKES WITH A	TATA spare parts
216333000116	FRONT AXLE ASSY 6TON WITH NGT ABS BRAKES	TATA spare parts
216333000117	FRONT AXLE ASSY 6TON WITH NGT ABS BRAKES	TATA spare parts
216340100101	ASSY.WHEEL NUT.(M22 LENGTH=33)	TATA spare parts
216340150101	ASSY. RADIAL TYRE 10.00R20	TATA spare parts
216340150102	ASSY. RADIAL TUBE 10.00R20	TATA spare parts
216340150103	FLAP 10.00R20	TATA spare parts
216340150107	TYRE 11R22.5 CITY BUSES	TATA spare parts
216341100101	ASSY. PROP.SHAFT WITH C.B FRONT L=1922	TATA spare parts
21634110010160	ASSY PROP SHAFT WITHOUT PAINTING FRT	TATA spare parts
216341100110	PROPELLER SHAFT FROM GBOX TO RETARDER	TATA spare parts
216341100111	PROPELLER SHAFT FRM RETARDER TO CBRG	TATA spare parts
216341100112	PROPELLER SHAFT FROM CBRG TO REAR AXLE	TATA spare parts
216341100114	ASSY COMP FRONT PROP SHAFT-LPO1616VOITH	TATA spare parts
216341100115	ASSY COMP MIDDLE PROPSHAFT-LPO1623-VOITH	TATA spare parts
216341100116	ASSY PROP SHAFT COMPL.- 1ST	TATA spare parts
216341100117	ASSY PROP SHAFT COMPL-1ST(150 SERRATED)	TATA spare parts
216341100122	ASSY PROP SHAFT WITH CB-FRONT(L=2080)	TATA spare parts
216341100125	ASSY COMP FRONT PROP-SHAFT LPO1618(BRTS)	TATA spare parts
216341100127	ASSY COMP MIDDLE PROP SHAFT- LPO 1618	TATA spare parts
216341100128	ASSY COMP FRONT PROP SHAFT- LPO 1620	TATA spare parts
216341100145	ASSY. CENTRE BEARING BS3/4	TATA spare parts
216341100155	COUPLING FLANGE	TATA spare parts
216341100156	CROSS ASSY	TATA spare parts
216341100158	FLANGE YOKE	TATA spare parts
216341100159	ASSY SHORT FORK TUBE & FRONT END PIECE(F	TATA spare parts
216341100160	ASSY SHORT FORK TUBE & FRONT END PIECE(M	TATA spare parts
216341100164	"ASSY SHORT FORK,TUBE & FRONT END PIECE"	TATA spare parts
216341100170	ASSY.PRO.SHAFT INTERMEDIATE	TATA spare parts
216341100171	ASSY.PRO.SHAFT REAR	TATA spare parts
216341100177	ASSY FRONT PROP SHAFT-LPO1823-VOITH	TATA spare parts
216341100178	ASSY MIDDLE PROP SHAFT-LPO1823-VOITH	TATA spare parts
216341100197	ASSY PROP SHAFT LENGTH 1975 DIA 100 (DR	TATA spare parts

216341104701	DUST COVER	TATA spare parts
216341106502	HEX NUT	TATA spare parts
216341108209	GUARD-PROP SHAFT	TATA spare parts
216341108601	SPACER	TATA spare parts
216341109202	HARDENED WASHER I.D. 15- TS17716	TATA spare parts
216341109901	FLANGE YOKE	TATA spare parts
216341109906	SHORT FORKE TUBE & FRONT END PIECE ASSY	TATA spare parts
216341109908	SHORT FORK TUBE & FRT END PIECE ASSY	TATA spare parts
216341109919	SHORT FORK TUBE & FRT END PIECE ASSY	TATA spare parts
216341109920	SHORT FORK TUBE & FRT END PIECE ASSY	TATA spare parts
216341109921	SHORT FORK TUBE & FRT END PIECE ASSY	TATA spare parts
216341109923	SHORT FORK TUBE& FRONT END PIECE ASSY	TATA spare parts
216341109924	SHORT FORK TUBE& FRONT END PIECE ASSY	TATA spare parts
216341109926	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
216341109927	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
216341109928	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
216341109929	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
216341109930	SHORT FORKETUBE & FRONT END PIECE ASSY	TATA spare parts
216341109931	SHORT FORKETUBE & FRONT END PIECE ASSY	TATA spare parts
216341110101	ASSY PROPELLER SHAFT-1	TATA spare parts
216341110102	ASSY PROPELLER SHAFT-2	TATA spare parts
216341110103	ASSY PROPELLER SHAFT-3	TATA spare parts
216341110109	ASSY PROP SHAFT LENGTH 1904 DIA 100 (DR	TATA spare parts
216341110110	ASSY PROP SHAFT LENGTH 1951 DIAç 100 (DR	TATA spare parts
216341110111	ASSY PROP SHAFT LENGTH 1904 DIAç 100 (DR	TATA spare parts
216341110112	ASSY GUARD-PROP SHAFT	TATA spare parts
216341110113	ASSY PROP SHAFT L-1824 (101.57 DIA 590)	TATA spare parts
216341110114	ASSY PROP SHAFT L-1889 (101.57 DIA 590)	TATA spare parts
216341110116	ASSY PROP SHAFT L-1948 DIA100	TATA spare parts
216341110117	ASSY PROP SHAFT L-1893 DIA100	TATA spare parts
216341110121	ASSY PROP SHAFT L-1836 DIA100	TATA spare parts
216341110133	PROPELLER SHAFT ASSY WITH CB	TATA spare parts
216341110134	PROPELLER SHAFT ASSY WITH CB MIDDLE	TATA spare parts
216341110135	PROPELLER SHAFT ASSY WITH CB FRONT L-179	TATA spare parts
216341110136	PROPELLER SHAFT ASSY WITH CB L-1901 DIA	TATA spare parts
216341110137	PROPELLER SHAFT ASSY WITH CB L-1972 DIA	TATA spare parts
216341110138	PROPELLER SHAFT ASSY WITH CB MIDDLE	TATA spare parts
216341110141	PROPELLER SHAFT ASSY WITH CB FRONT	TATA spare parts
216341115101	COMPANION FLANGE	TATA spare parts
216341120101	ASSY PROP SHAFT REAR	TATA spare parts
216341120104	ASSY. PROPLLER SHAFT COMPLETE (AFTER RET	TATA spare parts
216341120105	ASSY. PROPLLER SHAFT COMPLETE (BEFORE RE	TATA spare parts
216341120109	ASSY COMPL REAR PROP SHAFT-LPO1623-VOITH	TATA spare parts
216341120110	ASSY PROP SHAFT COMPL.- 2ND	TATA spare parts
216341120111	ASSY PROP SHAFT COMPL.- 3RD	TATA spare parts
216341120112	ASSY PROP SHAFT COMPL.- 4TH	TATA spare parts
216341120113	ASSY PROP SHAFT COMPL-2ND(150 SERRATED)	TATA spare parts

216341120114	ASSY PROP SHAFT COMPL-3RD(150 SERRATED)	TATA spare parts
216341120115	ASSY PROP SHAFT COMPL-4TH(150 SERRATED)	TATA spare parts
216341120116	ASSY. PROP.SHAFT COMPLETE(REAR)L=1970	TATA spare parts
216341120123	ASSY COMP REAR PROP-SHAFT LPO 1618	TATA spare parts
216341120131	ASSY PROP SHAFT WITH CB-FRONT(L=2080)	TATA spare parts
216341120134	ASSY REAR PROP SHAFT-LPO1823-VOITH	TATA spare parts
216341120145	REAR HSG TUBE & SHORT FORK SUB ASSY	TATA spare parts
216341120149	REAR HSG TUBE & SHORT FORK SUB ASSY	TATA spare parts
216341120152	ASSY REAR SHAFT L-1859 DIA 100(590 DRHC-	TATA spare parts
216341120160	ASSY REAR PROPELLER SHAFT	TATA spare parts
216341120165	ASSY REAR PROP SHAFT L-1860 (DIA101.57)	TATA spare parts
216341120166	ASSY REAR SHAFT L-1868 DIA 100	TATA spare parts
216341120168	SHORT FORK TUBE AND REAR HOUSING ASSEMBL	TATA spare parts
216341120175	ASSY PROP SHAFT REAR L-1139	TATA spare parts
216341120176	SHORT FORK TUBE & REAR HOUSING SUB ASSY	TATA spare parts
216341120182	PROPELLER SHAFT ASSY REAR	TATA spare parts
216341120183	PROPELLER SHAFT ASSY REAR L-1859 DIA 101	TATA spare parts
216341120190	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
216341129908	SHORT FORK TUBE & REAR HOUSING SUB ASSY	TATA spare parts
216341129909	SHORT FORK TUBE & REAR HSG. ASSY	TATA spare parts
216341303301	BRACKET PROP.SHAFT CENTRE BEARING BKT-1	TATA spare parts
216341303302	BRACKET PROP.SHAFT CENTRE BEARING BKT-2	TATA spare parts
216341303303	BRACKET(PROP.SHAFT CENTRE BEARING BKT-2)	TATA spare parts
216341303304	BRACKET(PROP.SHAFT CENTRE BEARING BKT-1)	TATA spare parts
216341303305	BRACKET(PROP.SHAFT CENTRE BEARING BKT-2)	TATA spare parts
216341303306	BRACKET(PROP.SHAFT CB BKT)FREE MTD RET.	TATA spare parts
216341303309	BRACKET(PROP.SHAFT CENTRE BEARING BKT-1)	TATA spare parts
216341303310	BRACKET(PROP.SHAFT CENTRE BEARING BKT-2)	TATA spare parts
216341303313	BRACKET(PROP.SHAFT CENTRE BEARING BKT-1)	TATA spare parts
216341303314	BRACKET(PROP.SHAFT CENTRE BEARING BKT-2)	TATA spare parts
216341303326	CENTERBEARINGMOUNTINGBRACKETFORFIRSTPP	TATA spare parts
216341303327	BRACKET FOR CENTER BEARING MOUNTING-2	TATA spare parts
216341303329	BRACKET(PROP.SHAFT CENTRE BEARING BKT-2)	TATA spare parts
216341303330	CB BKT FOR THIRD PROPELLER SHAFT	TATA spare parts
216341303350	CENTER BEARING MTG BKT FOR FIRST P.SHAFT	TATA spare parts
216341303351	CENTER BEARING MTG BKT FOR 2ND P.SHAFT	TATA spare parts
216341303352	CENTER BEARING MTG BKT FOR THIRD P.SHAFT	TATA spare parts
216341303356	CENTER BEARING MTG BRACKET - 1 FOR FIRST	TATA spare parts
216341303357	CENTER BEARING MTG BRACKET - 2 FOR SECON	TATA spare parts
216341303360	CENTER BRG. MTG. BRKT-2 (FOR SECOND PROP	TATA spare parts
216341303362	CENTER BRG. MTG. BRKT-1 (FOR FIRST PROP	TATA spare parts
216341303363	CENTER BRG. MTG. BRKT	TATA spare parts
216341303364	CENTER BRG. MTG. BRKT	TATA spare parts
216341303369	CENTER BRG. MTG. BRKT	TATA spare parts
216341303370	CENTER BRG. MTG. BRKT	TATA spare parts
216341303371	BRACKET(PROP.SHAFT CENTRE BEARING BKT-1)	TATA spare parts
216341303372	CENTER BRG. MTG. BRKT	TATA spare parts

216341303374	BRACKET 2ND CENTER BRG MTG	TATA spare parts
216341303375	BRACKET 1ST CENTER BRG MTG	TATA spare parts
216342100101	AUTO SLACK ADJUSTER	TATA spare parts
216342300102	ASSY. BRACKET - LH	TATA spare parts
216342300103	ASSY. BRACKET - RH	TATA spare parts
216342303701	BRACKET ACTUATOR MTG LH	TATA spare parts
216342303702	BRACKET ACTUATOR MTG RH	TATA spare parts
216342400101	RETARDER MTG BKT-RH(WITH ADAPTER PLATE)	TATA spare parts
216342400102	RETARDER MTG BKT-LH(WITH ADAPTER PLATE)	TATA spare parts
216342428201	PLATE H.B.V. MTG. BKT	TATA spare parts
216342700105	ASSY. RETARDER MTG. BKT.	TATA spare parts
216342900116	ASSY. BRACKET FOR QUICK RELEASE VALVE	TATA spare parts
216342900117	SET ASSY NYLON PIPE COMP. LPO1616	TATA spare parts
216342900132	ASSY.TUBE WITH CRIMPED R/HOSE (AIR DUCT)	TATA spare parts
216342990107	BRAKE SHOE ASSY WITH LINER & ROLLER	TATA spare parts
216343107101	BRACKET (RELAY VALVE MTG.)	TATA spare parts
216343200101	KIT ASSY AIR TANK	TATA spare parts
216343200105	ASSY AIR TANK 30 LIT.(VOSS COMP.)FRT LH	TATA spare parts
216343200106	ASSY AIR TANK 30 LIT.(VOSS COMP.)FRT RH	TATA spare parts
216343200113	SUB ASSY.AIR TANK COMP-VOSS	TATA spare parts
216343200115	ASSY AIR TANK WITH BKTS-RH(VOSS+METRIC)	TATA spare parts
216343200118	ASSY AIR TANK WITH BKTS (VOSS+METRIC)	TATA spare parts
216343200119	ASSY.AIR TANK WITH SEAL PLUG-VOSS+METRIC	TATA spare parts
216343200122	SUB ASSY.AIR TANK(15 L)	TATA spare parts
216343200123	ASSY. AIR OIL SEPARATOR BS4	TATA spare parts
216343200129	ASSY. 20 LIT. AIR TANK 240 PITCH	TATA spare parts
216343200135	AIR TANK ASSY 20 LTR--SUSPENSION CIRCUIT	TATA spare parts
216343200138	AIR TANK ASSY 30L VOSS+METRIC(REAR BRAKE	TATA spare parts
216343200141	AIR TANK ASSY 30 LTR	TATA spare parts
216343200142	AIR TANK ASSY 30 LTR	TATA spare parts
216343200143	AIR TANK ASSY 20 LTRS	TATA spare parts
216343200144	AIR TANK ASSY 20 LTRS (V+V)	TATA spare parts
216343200145	AIR TANK ASSY 20 LTRS	TATA spare parts
216343200146	BRACKET ASSY (AIR TANK MTG.)	TATA spare parts
216343200147	AIR TANK ASSY 30 LTR (V+M)	TATA spare parts
216343200149	AIR TANK ASSY 30 LTR (V+V)	TATA spare parts
216343200150	AIR TANK ASSY 20 LTRS (V+M)	TATA spare parts
216343200152	AIR TANK ASSY 254 PITCH(V+M)	TATA spare parts
216343208601	SPACER	TATA spare parts
216343209901	AIR OIL SEPARATOR ELEMENT SPINON BS4	TATA spare parts
216343400115	ASSY. RETARDER VALVE MTG. BRACKET	TATA spare parts
216343400118	SOLENOID VALVE RETARDER CONTROL 3/2 (NC)	TATA spare parts
216343400119	SOLENOID VALVE RETARDER CONTROL 3/2 (NO)	TATA spare parts
216343400122	RETARDER KIT SUPPLIER SCOPE LPO1823SA	TATA spare parts
216343400128	EXHAUST BRAKE ASSY	TATA spare parts
216343400129	BRACKET ASSY	TATA spare parts
216343403209	HEX BOLT	TATA spare parts

216343403210	HEX BOLT (VR119 H01.219814)	TATA spare parts
216343403211	HEX BOLT (VR119 153.00244710)	TATA spare parts
216343403212	HEX BOLT (VR119 153.00244010)	TATA spare parts
216343403213	HEX BOLT (VR119 H01.238187)	TATA spare parts
216343404301	CIRCLIP (VR119 190.00298710)	TATA spare parts
216343404302	CIRCLIP (VR119 190.00206410)	TATA spare parts
216343404701	COVER - (153.00474910)	TATA spare parts
216343404702	COVER - (153.00501802)	TATA spare parts
216343405301	O-RING B-90X3-N	TATA spare parts
216343405302	SEAL RING A-14X20	TATA spare parts
216343405303	GASKET (VR119 H53.010110)	TATA spare parts
216343406805	COUPLING BODY M12X1.5-M18X1.5 (BODY TO T	TATA spare parts
216343406806	PRESSURE SWITCH	TATA spare parts
216343407202	SCREW PLUG(VR119 H01.217523)	TATA spare parts
216343407203	SCREW PLUG(VR119 H01.220623)	TATA spare parts
216343407204	SCREW PLUG(VR119 153.00256711)	TATA spare parts
216343407805	O-RING (VR119 H01.238931)	TATA spare parts
216343407806	O-RING (VR119 H01.064756)	TATA spare parts
216343407807	O-RING (VR119 H01.069497)	TATA spare parts
216343407808	O-RING (VR119 H01.026946)	TATA spare parts
216343407809	SEAL (VR 119 153.00484801)	TATA spare parts
216343408501	WATER SOCKET (VR119 153.00484710)	TATA spare parts
216343409203	WASHER (VR119 H67.155610)	TATA spare parts
216343409903	SCREW PLUG M14X1.5 DRAIN WATER SOCKET	TATA spare parts
216343409904	O-RING B-55 56X3 53-N	TATA spare parts
216343409905	SEAL RING A-14X18	TATA spare parts
216343409909	VALVE PIECE (VR119 H67.383010)	TATA spare parts
216343409910	OIL COOLER (VR119 H67.237110)	TATA spare parts
216343409911	PRESSURE SENSOR	TATA spare parts
216343409912	TEMPERATURE SENSOR	TATA spare parts
216343700101	ASSY. BRACKET (PROP. VALVE MTG)	TATA spare parts
216343700130	ASSY HBV BRACKET- RH	TATA spare parts
216343700131	ASSY HBV BRACKET- LH	TATA spare parts
216343700153	ASSY. EXHAUST BRAKE CYLINDER	TATA spare parts
216343700159	EXHAUST BRAKE ASSY W/O AIR CYLINDER BS6	TATA spare parts
216343700166	EXHAUST BRAKE CYLINDER ASSY 40 DIA	TATA spare parts
216343700179	FOUR CIRCUIT PROTECTION VALVE 9.5 BAR	TATA spare parts
216343700195	AIR PROCESSING UNIT BS6	TATA spare parts
216343700210	28DIA EXH.BRAKE CYLINDER WITH ADAPTOR	TATA spare parts
216343700221	AIR DRYER(9BAR-VOSS) WITHOUT PR PORT	TATA spare parts
216343700225	SET ASSY NYLON PIPE FOR LPO 1612/62WB	TATA spare parts
216343700227	AIR DRYER(9BAR-VOSS)WITHOUT PR PORT	TATA spare parts
216343700228	ASSY PIPE 25 OD COMP. INLET WITH CRIMPED	TATA spare parts
216343700230	ASSY PIPE 25 OD COMP INLET WITH CRIMPED	TATA spare parts
216343700250	SOLENOID VALVE 3/2 (NORMALLY CLOSED)	TATA spare parts
216343700252	QUICK RELEASE VALVE	TATA spare parts
216343700267	AIR PROCESSING UNIT	TATA spare parts



216343700275	AIR PROCESSING UNIT	TATA spare parts
216343703301	BRACKET RETARDER MOUNTING	TATA spare parts
216343704901	2/2 SOLONOIDE VALVE	TATA spare parts
216343704902	2/2 SOLONOIDE VALVE	TATA spare parts
216343706803	COUPLING BODY (M36X2 3/4 IN-14 NPTF)	TATA spare parts
216343706804	ELBOW (M33X2 M36X2)	TATA spare parts
216343708205	BRACKET (QRV MOUNTING)	TATA spare parts
216343708215	FRONT BRAKE CIRCUIT RELAY MTG.BKT.	TATA spare parts
216343708217	FRONT RELAY MTG. BRACKET FOR LPO1628	TATA spare parts
216343708230	MTG BKT-MODULATOR VALVE REAR	TATA spare parts
216343709904	KIT 160CC COMPRESSOR HEAD	TATA spare parts
216343709918	ASSY. CYLINDER HEAD BS2/3	TATA spare parts
216343709919	DESICCANT CARTRIDGE	TATA spare parts
216343710103	EXHAUST BRAKE UNIT 80 DIA	TATA spare parts
216343710104	ASSY. 80DIA. EX. BRAKE W/28D.CYL. BS1- 4	TATA spare parts
216343710104AE	ASSY EXHAUST BRAKE 2523	TATA spare parts
216343710109	PRESSURE LIMITING VALVE	TATA spare parts
216343710110	QUICK RELEASE VALVE	TATA spare parts
216343710118	AIR DRYER 8.1 BAR OSC CARTRIDGE & W/O CT	TATA spare parts
216343800106	ASSY.PIPE CLAMP(RETARDER PIPE)	TATA spare parts
216343800110	ASSY.PIPE CLAMP(RETARDER PIPE)	TATA spare parts
216343800113	ASSY PIPE CLAMP	TATA spare parts
216343800116	OUTLET PIPE-I(FREE & TRASM MTD RETARDER)	TATA spare parts
216343800118	INLET PIPE-2(FREE & TRANS MTD RETARDER)	TATA spare parts
216343800119	INLET PIPE-I(FREE & TRANS MTD RETARDER)	TATA spare parts
216343800129	ASSY.PIPE CLAMP(RETARDER PIPE)	TATA spare parts
216343800137	ASSY. BRACKET (FOR MTG. RETARDER PIPE)	TATA spare parts
216343800138	ASSY.BRACKET (FOR MTG.RETARDER PIPE)	TATA spare parts
216343800147	ENGINE PIPE FROM RETARDER 60 DIA	TATA spare parts
216343800149	BKT. FOR INLET PIPE AT ADOPTER PLATE	TATA spare parts
216343800150	INLET PIPE -2	TATA spare parts
216343800154	INLET PIPE-2	TATA spare parts
216343800164	PIPE ASSY WATER INLET TO RETARDER	TATA spare parts
216343800165	PIPE ASSY WATER OUTLET TO RETARDER	TATA spare parts
216343800166	BRACKET ASSY FOR MTG.RETARDER PIPE	TATA spare parts
216343803301	BRACKET RETARDER COOLING LINES	TATA spare parts
216343803302	BRACKET RETARDER COOLING LINES	TATA spare parts
216343805808	HOSE	TATA spare parts
216343805809	HOSE	TATA spare parts
216343805810	HOSE	TATA spare parts
216343805811	HOSE	TATA spare parts
216343805812	HOSE	TATA spare parts
216343805812AE	HOSELPA 1415/	TATA spare parts
216343805813	HOSE	TATA spare parts
216343805814	HOSE	TATA spare parts
216343805815	REDUCER HOSE	TATA spare parts
216343805816	HOSE	TATA spare parts

216343805827	HOSE	TATA spare parts
216343805828	HOSE	TATA spare parts
216343805830	HOSE - WA048	TATA spare parts
216343805831	HOSE PIPE (FOR REAR BY PASS)	TATA spare parts
216343805845	HOSE FOR FRONT BY PASS	TATA spare parts
216343806911	RETARDER PIPE	TATA spare parts
216343806912	RETARDER PIPE	TATA spare parts
216343806913	RETARDER WATER OUTLET FIRST PIPE-60 OD	TATA spare parts
216343806914	PIPE	TATA spare parts
216343806915	OUTLET PIPE - 3 (FREE MTG RETARDER)	TATA spare parts
216343806916	INLET PIPE - 5 (FREE MTG RETARDER)	TATA spare parts
216343806917	INLET PIPE - 4 (FREE MTG RETARDER)	TATA spare parts
216343806918	PIPE INLET-3(FREE MTD. RETARDER)	TATA spare parts
216343806920	PIPE	TATA spare parts
216343806926	PIPE-1 (AUX.WATER TANK BYPASS)	TATA spare parts
216343806927	RETARDER WATER OUTLET SOCKET	TATA spare parts
216343806932	PIPE WITH FLANGE (VOITH RETARDER)	TATA spare parts
216343806941	RETARDER PIPE INLET	TATA spare parts
216343806942	RETARDER PIPE OUTLET	TATA spare parts
216343806943	INTERMEDIATE PIPE (AUX. TANK TO ENGINE I	TATA spare parts
216343806945	NIPPLE FOR THERMOSTAT BY PASS	TATA spare parts
216343806966	RETARDER WATER INLET SECOND PIPE-60 OD	TATA spare parts
216343807101	BRACKET (RETARDER PIPE MTG.)	TATA spare parts
216343807102	BRACKET (RETARDER PIPE MTG.)	TATA spare parts
216343807104	BRACKET (RETARDER PIPE MTG.)	TATA spare parts
216343807105	BRACKET (FOR MTG. RETARDER PIPE)	TATA spare parts
216343807111	BRACKET (FOR RETARDER INLET PIPE AT X-ME	TATA spare parts
216343807112	BRACKET FOR RETARDER INLET PIPE AT GEAR	TATA spare parts
216343807113	BRACKET FOR RETARDER INLET PIPE AT 3RD X	TATA spare parts
216343900102	SET ASSY NYLON PIPE COMP FOR VOITH FM	TATA spare parts
216343900105	SET ASSY NYLON PIPE RETRO KIT	TATA spare parts
216343900108	SET ASSY NYL PIPE COMP LPT1613-VOSS	TATA spare parts
216343900115	SET ASSY NYL PIPE COMP LPO1616-VOSS	TATA spare parts
216343900116	SET ASSY NYL PIPE COMP LPO1616-VOSS-PACO	TATA spare parts
216343900138	SET ASY NYL PIPE COMP(RETRO)LPO1616	TATA spare parts
216343900140	ASSY FIRST PIPE (DIA 18)	TATA spare parts
216343900159	SET.ASSY.NYL.PIPE LPO1618 W/HUMP	TATA spare parts
216343900165	ASSY THIRD PIPE (DIA 18)-1618 JNNURM	TATA spare parts
216343900166	ASSY MTG BKT FOR OIL SEPARATOR	TATA spare parts
216343900167	ASSY SECOND PIPE (DIA 18)	TATA spare parts
216343900168	ASSY FOURTH PIPE (DIA 18)	TATA spare parts
216343900172	HOSE 3/8IN WITH M22X1.5 PORT 615LG BS4	TATA spare parts
216343900174	HOSE 3/8IN WITH M18X1.5 PORT 535LG BS4	TATA spare parts
216343900176	SET.ASSY.NYLON PIPE	TATA spare parts
216343900177	PIPE ASSY 1ST METAL PIPE (TEFLON HOSE)	TATA spare parts
216343900178	ASSY SECOND PIPE (DIA 18) WITH O RING	TATA spare parts
216343900179	ASSY THIRD PIPE (DIA 18) WITH O RING	TATA spare parts

216343900180	ASSY FOURTH PIPE (DIA 18) WITH 'O' RING	TATA spare parts
216343900181	ASSY.TUBE WITH CRIMPED R/HOSE (AIR DUCT)	TATA spare parts
216343900190	SET.ASSY.NYL.PIPE LPO1618 W/HUMP A.DR	TATA spare parts
216343900195	ASSY THIRD PIPE (18 DIA)	TATA spare parts
216343900196	ASSY FOURTH PIPE (18 DIA)	TATA spare parts
216343900201	SET.ASSY.NYL.PIPE LPO1623 RETARDER & CLT	TATA spare parts
216343900204	SET.ASSY.NYLON PIPE RETARDER & CLT BOOST	TATA spare parts
216343900209	SET ASSY.NYLON PIPE COMP. FOR LPO 1618 T	TATA spare parts
216343900212	ASSY FIRST PIPE (DIA 18)	TATA spare parts
216343900213	ASSY SECOND PIPE (DIA 18)	TATA spare parts
216343900214	ASSY THIRD PIPE (DIA 18)	TATA spare parts
216343900215	ASSY FOURTH PIPE (DIA 18)	TATA spare parts
216343900221	ASSY FIRST PIPE (DIA 18)	TATA spare parts
216343900222	ASSY SECOND PIPE (DIA 18)	TATA spare parts
216343900223	ASSY THIRD PIPE (DIA 18)	TATA spare parts
216343900224	ASSY FOURTH PIPE (DIA 18)	TATA spare parts
216343900231	ASSY PIPE CONSEP UNIT	TATA spare parts
216343900233	ASSY THIRD METAL PIPE-AIR COMPRESSOR.	TATA spare parts
216343900236	SET ASY NYLON PIPE LPO 1612 BSIII	TATA spare parts
216343900240	ASSY PIPE-SECOND METAL PIPE COMP-18 DIA.	TATA spare parts
216343900241	ASSY.PIPE-THIRD METAL PIPE	TATA spare parts
216343900245	5/8INC HOSE ASSY WITH O RING NIPPLE	TATA spare parts
216343900246	SET.ASSY.NYL.PIPE LPO1618	TATA spare parts
216343900247	ASSY NYLON PIPE FOR LPO 1618/58 WB	TATA spare parts
216343900248	ASSY NYLON PIPE BUNCH FOR LPO 1612/62 WB	TATA spare parts
216343900250	5/8INC HOSE ASSY WITH O RING NIPPLE (55	TATA spare parts
216343900252	PIPE ASSY 2ND METAL PIPE	TATA spare parts
216343900262	ASSY HOSE PIPE NATURAL ASPIRATION 18 OD	TATA spare parts
216343900267	PIPE ASSY COMP INTAKE WITH HOSE	TATA spare parts
216343900268	ASSY HOSE PIPE NATURAL ASPIRATION 22 ID	TATA spare parts
216343900272	SET ASY NYLON PIPE FOR LPT 1613	TATA spare parts
216343900273	ASSY METAL 1ST PIPE WITH CRIMPED TEFLON	TATA spare parts
216343900275	ASSY PIPE CLAMP (P - CLAMP) FOR LPO1612	TATA spare parts
216343900276	PIPE ASSY 3RD METAL PIPE	TATA spare parts
216343900277	ASSY FOURTH PIPE (DIA 18)	TATA spare parts
216343900278	PIPE BUNCH ASSY LPO1621 BS-IV	TATA spare parts
216343900279	ASSY 25OD PIPE FOR NATURAL ASPIRATION	TATA spare parts
216343900294	PIPE ASSY 3RD METAL PIPE (18 OD)	TATA spare parts
216343900308	PIPE ASSY 4TH METAL PIPE (18 OD)	TATA spare parts
216343900309	PIPE ASSY 5TH METAL PIPE (18 OD)	TATA spare parts
216343900315	PIPE ASSY 2ND METAL PIPE	TATA spare parts
216343900316	PIPE ASSY 4TH METAL PIPE	TATA spare parts
216343900317	PIPE ASSY 3RD METAL PIPE	TATA spare parts
216343900324	PIPE ASSY	TATA spare parts
216343900325	PIPE ASSY FOURTH METAL PIPE (18 OD)	TATA spare parts
216343900329	PIPE ASSY 1ST METAL PIPE (TEFLON HOSE)	TATA spare parts
216343900330	PIPE ASSY SECOND METAL PIPE	TATA spare parts

216343900331	PIPE ASSY THIRD METAL PIPE	TATA spare parts
216343900332	PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
216343900354	PIPE ASSY FIRST WITH HOSE 18 DIA	TATA spare parts
216343900365	BRACKET ASSY MODULATOR VALVE	TATA spare parts
216343903301	BKT (QUICK RELEASE VALVE) FRONT	TATA spare parts
216343903309	BRACKET	TATA spare parts
216343906802	SEALING PLUG M12X1.5	TATA spare parts
216343906803	SEALING PLUG M16X1.5	TATA spare parts
216343906806	SEALING PLUG	TATA spare parts
216343906903	METAL PIPE-6 DIA-COMPRESSOR CONTROL PORT	TATA spare parts
216343906905	METAL PIPE-6 DIA-COMPRESSOR CONTROL PORT	TATA spare parts
216343907102	QRV MTG BKT FOR FRONT LP	TATA spare parts
216343907103	3/8 IN HOSE MOUNTING BKT	TATA spare parts
216343907104	PRESSURE REDUCTION VALVE MTG BKT	TATA spare parts
216343907111	R12 RELAY MTG BKT	TATA spare parts
216343907501	RUBBER BS6	TATA spare parts
216343908201	P-CLAMP BS6-PH2	TATA spare parts
216343908202	SUPPORT PLATE BS6-PH2	TATA spare parts
216343908203	SUPPORT PLATE BS6-PH2	TATA spare parts
216343910119	PIPE ASSY THIRD METAL PIPE (18 OD)	TATA spare parts
216343920131	PIPE BUNCH ASSY LPO1618 BS-III	TATA spare parts
216343920134	PIPE BUNCH ASSY	TATA spare parts
216343920135	PIPE BUNCH ASSY FOR LPO1618/62WB BS-III	TATA spare parts
216343920137	PIPE BUNCH ASSY	TATA spare parts
216343920179	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
216343920263	PIPE ASSY 4TH METAL PIPE	TATA spare parts
216343930108	PIPE ASSY	TATA spare parts
216343930180	PIPE BUNCH ASSY FOR LPO1621/59WB BS-IV	TATA spare parts
216343940130	PIPE BUNCH ASSY FOR LPO1618/62WB BS-III	TATA spare parts
216343940191	PIPE ASSY 2ND METAL PIPE (18DIA)	TATA spare parts
216343940192	PIPE ASSY THIRD METAL PIPE	TATA spare parts
216343950124	PIPE ASSY 1ST METAL PIPE (TEFLON HOSE)	TATA spare parts
216343950137	PIPE ASSY THIRD METAL PIPE	TATA spare parts
216343950170	PIPE ASSY 1ST METAL PIPE (18 OD)	TATA spare parts
216343960130	PIPE BUNCH ASSY	TATA spare parts
216343970129	PIPE BUNCH ASSY	TATA spare parts
216343980101	REPAIR KIT - AIR DRYER	TATA spare parts
216343990110	KIT-EXHAUST BRAKE VALVE 40 DIA.	TATA spare parts
216345903301	L-BRACKET	TATA spare parts
216346000101	ASSY. DRAG LINK	TATA spare parts
216346000102	DRAG LINK ASSY	TATA spare parts
216346000107	ASSY DRAG LINK REAR	TATA spare parts
216346000109	DRAG LINK ASSY	TATA spare parts
216346000112	ASSY DRAG LINK REAR	TATA spare parts
216346000115	ASSY DRAG LINK REAR	TATA spare parts
216346000116	ASSY DRAG LINK FRONT	TATA spare parts
216346000132	ASSY DRAG LINK (SEALED TYPE)	TATA spare parts

216346100101	ASSY. STEERING COLOUMN SUPPORT	TATA spare parts
216346100102	ASSY STEERING COLUMN SUPPORT RHD	TATA spare parts
216346100107	MOUNTING BRACKET ASSEMBLY	TATA spare parts
216346100113	ASSY STEERING COLUMN SUPPORT RHD	TATA spare parts
216346100122	ASSY. BKT.STEERING G.B.MTG	TATA spare parts
216346100127	ASSY PIPE FOR CLAMP FOR STG HOSE	TATA spare parts
216346100128	ASSY CLAMP FOR STG HOSE	TATA spare parts
216346100129	ASSY STG COLUMN ( W/O STR WHEEL)	TATA spare parts
216346100134	NACELLE MTG BKT	TATA spare parts
216346100135	NACELLE MTG BKT LH	TATA spare parts
216346100137	ASSY STEERING COLUMN	TATA spare parts
216346100140	ASSY STEERING COLOUMN	TATA spare parts
216346100142	ASSY STEERING COLOUMN - ERGO	TATA spare parts
216346100144	ASSY BKT STEERING GEAR BOX MTG.	TATA spare parts
216346100147	BRACKET ASSY STEERING GEAR BOX MTG	TATA spare parts
216346100148	BRACKET ASSY STEERING GEAR BOX MTG	TATA spare parts
216346100151	BRACKET ASSY POWER STG GEAR BOX MTG	TATA spare parts
216346100152	RUBBER BELLOW ASSY BS6	TATA spare parts
216346150101	KIT POWER STEERING PIPE	TATA spare parts
216346150102	KIT FOR POWER STEERING PIPELINES	TATA spare parts
216346200102	INTERMEDIATE SHAFT LPO1621 - LOWERED COW	TATA spare parts
216346200103	ASSY STEERING SPINDLE (TOP)	TATA spare parts
216346200105	ASSY. STEERING SPINDLE	TATA spare parts
216346200108	SPINDLE ASSY BOTTOM	TATA spare parts
216346200109	ASSY RETARDER HAND LEVER MTG. BKT.	TATA spare parts
216346303701	BRACKET BS6	TATA spare parts
216346304101	RELAY ARM	TATA spare parts
216346305103	PITMAN ARM	TATA spare parts
216346306001	INTERMEDIATE PITMAN ARM	TATA spare parts
216346600107	POWER STG. PUMP ASSY	TATA spare parts
216346600111	KIT ASSY PIPES	TATA spare parts
216346600114	POWER STEERING PUMP ASSY	TATA spare parts
216346600115	STEERING GEAR BOX	TATA spare parts
216346609902	SECTOR SHAFT ASSY	TATA spare parts
216346703303	BRACKET RELAY ARM MTG BS6	TATA spare parts
216346800101	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
216346800103	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
216346800113	ASSY P/STG CRIMP PIPE STG G.B TO TANK	TATA spare parts
216346800114	ASSY P/STG CRIMP PIPE STG PUMP TO TANK	TATA spare parts
216346800124	ASSY PIPE STG TANK TO STG PUMP	TATA spare parts
216346800125	ASSY PIPE STG PUMP-STG G BOX	TATA spare parts
216346800126	ASSY PIPE STG G.B.-STG TANK	TATA spare parts
216346800127	ASY PIPE.STG.TANK=STG PUMP-1621BS4	TATA spare parts
216346800128	ASSY PIPE STG.PUMP-STG G.B-1621BS4	TATA spare parts
216346800129	ASY PIPE STG.G.B-STG TANK-1621BS4	TATA spare parts
216346800146	ASSY HOSE CRIMPED-PRESSURE LINE(STG.PUMP	TATA spare parts
216346800147	ASSY HOSE CRIMPED - SUCTION LINE (STG. T	TATA spare parts

216346800149	ASY HOSE - CRIMPED RETURN LINE (STG GB	TATA spare parts
216346800150	SUCTION LINE ASSY	TATA spare parts
216346800151	PRESSURE LINE ASSY	TATA spare parts
216346800152	RETURN LINE ASSY	TATA spare parts
216346800158	SUCTION LINE ASSY	TATA spare parts
216346800159	PRESSURE LINE ASSY	TATA spare parts
216346800160	RETURN LINE ASSY	TATA spare parts
216346800161	SUCTION LINE ASSY	TATA spare parts
216346800162	PRESSURE LINE ASSY	TATA spare parts
216346800163	RETURN LINE ASSY	TATA spare parts
216346800167	RETURN LINE ASSY-ZF	TATA spare parts
216346800168	PRESSURE LINE ASSY -ZF	TATA spare parts
216346900102	DRAG LINK ASSY REAR	TATA spare parts
216346900106	DRAG LINK ASSY FRONT	TATA spare parts
216346990104	REPAIR KIT-STEERING	TATA spare parts
216346990105	KIT-STEERING THREADED END	TATA spare parts
216346990107	CARTRIDGE ASSY	TATA spare parts
216346990108	KIT-DRAG LINK	TATA spare parts
216346990134	KIT-SEAL	TATA spare parts
216346990135	MAJOR KIT-SEAL	TATA spare parts
216346990136	MAJOR KIT-SEAL	TATA spare parts
216346990137	HOUSING BS6	TATA spare parts
216347100118	ASSY FUEL TANK COMP(160 LTR)	TATA spare parts
216347100120	FUEL TANK ASSY COMPLETE (350 LTR.)	TATA spare parts
216347150107	ASSY BRACKET (FUEL FILTER) LPO1621 BS-IV	TATA spare parts
216347150109	ASSY FUEL FILTER BRKT.	TATA spare parts
216347150110	ASSY FUEL FILTER MTG BKT	TATA spare parts
216347500101	ASSY SUPPORT WITH STRAP(F.TANK 500 DIA)	TATA spare parts
216347500104	ASSY.BKT.& ASSY.SUPPORT	TATA spare parts
216347500108	ASSY BRACKET (FOR FUEL TANK MOUNTING)	TATA spare parts
216347500114	BRACKET ASSY FUEL TANK MTG	TATA spare parts
216347507106	SPACER	TATA spare parts
216347600101	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
216347600102	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
216347600108	EJECTOR TO INTERM. JOINT 10 O.D	TATA spare parts
216347600110	ASSY TUBE 6 DIA WITH CRIMPED R/HOSE	TATA spare parts
216347600114	INTER.JOINT TO DIESEL TANK 10 O.D (160L)	TATA spare parts
216347600115	DIESEL TANK TO INTE.JOINT 1621BS-IV 160L	TATA spare parts
216347600116	INTE. JOINT TO FUEL FILTER	TATA spare parts
216347600117	EJECTOR TO INTERM. JOINT 1621 BS-IV	TATA spare parts
216347600128	MAIN FUEL LINE FROM INTERMEDIATE JOINT	TATA spare parts
216347600129	FUEL RETURN LINE	TATA spare parts
216347600130	MAIN FUEL LINE FROM FUEL TANK TO INTERME	TATA spare parts
216347600131	RETURN FUEL LINE FROM FUEL TANK TO INTE	TATA spare parts
216347600132	DIESEL TANK TO INTE.JOINT 15 O.D	TATA spare parts
216347600133	INTER.JOINT TO DIESEL TANK 10 O.D	TATA spare parts
216347600137	FUEL RETURN PIPE ASSY FUEL TANK TO ENG	TATA spare parts

216347600141	FUEL SUCTION PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
216347600142	FUEL SUCTION PIPE ASSY	TATA spare parts
216347600143	FUEL SUCTION PIPE ASSY FUEL TANK TO ENG	TATA spare parts
216347600147	DIESEL TANK TO INT JOINT LPO 1621	TATA spare parts
216347600148	INT JOINT -FUEL FILTER LPO1621	TATA spare parts
216347600149	INJECTOR-INT. JOINT LPO1621	TATA spare parts
216347600180	ASSY RETURN FUEL LINE	TATA spare parts
216347600181	ASSY SUCTION FUEL LINE(TANK TOWATER SEP)	TATA spare parts
216347600182	TUBE ASSY FUEL LINE (WATER SEP TO ENG)	TATA spare parts
216347600183	FUEL SUCTION PIPE ASSY (TANK TO FWS)	TATA spare parts
216347600224	FUEL SUCTION PIPE ASSY	TATA spare parts
216347600225	FUEL SUCTION PIPE ASSY FUEL FTR TO ENG	TATA spare parts
216347600226	RETURN FUEL PIPE ASSY	TATA spare parts
216347600227	FUEL SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
216347600228	FUEL SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
216347600229	FUEL RETURN PIPE ASSY	TATA spare parts
216347600230	FUEL SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
216347600231	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
216347600240	BRACKET ASSY HP REGULATOR MTG BS6-PH2	TATA spare parts
216347605801	RUBBER HOSE FOR FUEL LINE	TATA spare parts
216347606801	REDUCER HOSE(DIA 12 TO 6) FOR FUEL LINE	TATA spare parts
216347620101	FUEL NYLON PIPE ASSY (FWS TO ENGINE)	TATA spare parts
216347620102	FUEL NYLON PIPE ASSY (TANK TO FWS)	TATA spare parts
216347620103	FUEL NYLON PIPE ASSY (ENGINE TO TANK)	TATA spare parts
216347700101	FUEL WATER SEPARATOR MTG BKT	TATA spare parts
216347700102	FUEL WATER SEPARATOR MTG BKT RH	TATA spare parts
216347700103	BRACKET ASSY FUEL FILLER MTG	TATA spare parts
216349000107	ASSY CLAMP AT EGP MTG	TATA spare parts
216349000111	ASSY MTG BRACKET	TATA spare parts
216349000116	ASSY MTG BKT	TATA spare parts
216349000117	ASSY MTG BKT(EGP)	TATA spare parts
216349000118	ASSY EXHAUST BKT	TATA spare parts
216349000123	ASSY MTG BKT (EGP)	TATA spare parts
216349000127	ASSY BRACKET	TATA spare parts
216349000129	ASSY MTG BKT (EGP)	TATA spare parts
216349003601	AIR OIL SEPARATOR ELEMENT SPINON BS4	TATA spare parts
216349008201	BRACKET	TATA spare parts
216349008202	CLAMP	TATA spare parts
216349008208	CLAMPING BRACKET-EXH MTG	TATA spare parts
216349008209	CLAMPING BRACKET	TATA spare parts
216349008210	BRACKET	TATA spare parts
216349008212	BRACKET	TATA spare parts
216349008213	BRACKET	TATA spare parts
216349100102	ASSY SILENCER WITH PIPE	TATA spare parts
216349100103	ASSY SILENCER WITH PIPE	TATA spare parts
216349100108	ASSY MUFFLER WITH TAIL PIPE	TATA spare parts
216349100112	ASSY MUFFLER WITH TAIL PIPE(NT6A)	TATA spare parts

216349100113	ASSY SILENCER WITH PIPE	TATA spare parts
216349100117	ASSY UREA TANK 30L MTG BKT-LH	TATA spare parts
216349100118	ASSY UREA TANK 30L MTG BKT-RH	TATA spare parts
216349100122	ASSY CLAMP FOR TAIL PIPE	TATA spare parts
216349100125	EXHAUST GAS PROCESSOR (180 HP) BS4	TATA spare parts
216349100130	SILENCER ASSY WITH TAIL PIPE	TATA spare parts
216349100211	BRACKET ASSY	TATA spare parts
216349106301	TURBO OUT	TATA spare parts
216349106302	2ND FROM TURBO	TATA spare parts
216349106303	3RD FROM TURBO	TATA spare parts
216349106304	4TH FROM TURBO	TATA spare parts
216349106305	5TH FROM TURBO	TATA spare parts
216349106306	6TH FROM TURBO	TATA spare parts
216349106307	7TH FROM TURBO	TATA spare parts
216349106308	8TH FROM TURBO	TATA spare parts
216349106309	9TH FROM TURBO	TATA spare parts
216349107501	RUBBER GROMMET	TATA spare parts
216349107502	RUBBER BUFFER	TATA spare parts
216349110108	SET AFTER TREATMENT SYSTEM	TATA spare parts
216349200101	ASSY.EXHAUST PIPE COMPLETE	TATA spare parts
216349200102	ASSY.INTERMEDIATE PIPE	TATA spare parts
216349200103	ASSY.BRACKET-COMPL	TATA spare parts
216349200104	ASSY. EXHAUST PIPE AT EXHAUST MANIFOLD	TATA spare parts
216349200105	ASSY.EXHAUST PIPE COMPLETE	TATA spare parts
216349200106	RETROKIT FOR EXHAUST BRK ON LPO1616TC	TATA spare parts
216349200108	ASSY. EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
216349200109	ASSY EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
216349200110	ASSY INTERMEDIATE PIPE	TATA spare parts
216349200111	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
216349200112	ASSY EXHAUST PIPE (AT EXHAUST MANIFOLD)	TATA spare parts
216349200115	ASSY EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
216349200116	ASSY EXHAUST BRACKET	TATA spare parts
216349200118	ASSY EXHAUST PIPE	TATA spare parts
216349200119	ASSY INTERMEDIATE PIPE(AT MUFLER)	TATA spare parts
216349200123	ASSY BRACKET (EXHAUST BKT)	TATA spare parts
216349200124	ASSY INTERMEDIATE PIPE	TATA spare parts
216349200130	ASSY BRACKET (EXHAUST MTG)	TATA spare parts
216349200136	AIR PIPE LINE AIR OIL FILTER TO DU	TATA spare parts
216349200154	ASSY. EXHAUST PIPE WITH FLEX. (AT INLET	TATA spare parts
216349200155	ASSY BRACKET FOR MUFFLER	TATA spare parts
216349200156	ASSY. INTERMEDIATE PIPE	TATA spare parts
216349200157	ASSY EXHAUST PIPE	TATA spare parts
216349200158	ASSY EXHAUST PIPE	TATA spare parts
216349200160	ASSY EXHAUST FIRST PIPE	TATA spare parts
216349200161	ASSY BKT EXHAUST PIPE	TATA spare parts
216349200162	ASSY BKT EXHAUST MTG	TATA spare parts
216349200163	ASSY MTG BKT EXHAUST	TATA spare parts



216349200164	ASSY MTG BKT EXHAUST	TATA spare parts
216349200165	ASSY EXHAUST PIPE	TATA spare parts
216349200168	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
216349200172	ASSY.EXHAUST PIPE (AT INLET MANIFOLD)	TATA spare parts
216349200173	ASSY EXHAUST PIPE(INTERMEDIATE)	TATA spare parts
216349200174	UREA AIR MIX LINE	TATA spare parts
216349200178	ASSY EXHAUST BRAKE SUPPORT BRACKET	TATA spare parts
216349200185	ASSY EXHAUST BRACKET	TATA spare parts
216349200188	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
216349200191	EXHAUST PIPE ASSEMBLY WITH FLEXIBLE HOSE	TATA spare parts
216349200194	ASSEMBLY DECOMPOSE PIPE	TATA spare parts
216349200195	ASSEMBLY BRACKET EXHAUST MOUNTING	TATA spare parts
216349200196	ASSEMBLY PIPE EXHAUST	TATA spare parts
216349200197	ASSEMBLY TAIL PIPE	TATA spare parts
216349200198	ASSY EXHAUST PIPE (TC MTG)	TATA spare parts
216349200199	SUPPORT BRACKET EXHAUST BRAKE	TATA spare parts
216349200202	EXHAUST PIPE ASSY	TATA spare parts
216349200203	BRACKET ASSY EXHAUST MTG	TATA spare parts
216349200205	ASSY BRACKET (EXHAUST MTG)	TATA spare parts
216349200206	ASSY BRACKET (EXHAUST MTG)	TATA spare parts
216349200207	ASSY BRACKET NOX SENSOR MTG	TATA spare parts
216349200208	ASSEMBLY UREA AIR MIX LINE	TATA spare parts
216349200209	ASSY UREA AIR MIX LINE	TATA spare parts
216349200213	BRACKET ASSY	TATA spare parts
216349200224	EXHAUST PIPE ASSY	TATA spare parts
216349200225	EXHAUST PIPE ASSY	TATA spare parts
216349200226	DECOMP PIPE ASSY	TATA spare parts
216349200227	BRACKET ASSY	TATA spare parts
216349200228	BRACKET ASSY	TATA spare parts
216349200229	BRACKET ASSY	TATA spare parts
216349200231	EXHAUST PIPE ASSY	TATA spare parts
216349200235	EXHAUST PIPE ASSY	TATA spare parts
216349200236	BRACKET ASSY	TATA spare parts
216349200237	BRACKET ASSY	TATA spare parts
216349203303	BRACKET	TATA spare parts
216349203304	CLAMPING PLATE	TATA spare parts
216349203319	BRACKET(EXHAUST)	TATA spare parts
216349203320	BRACKET ( EXHAUST )	TATA spare parts
216349203325	CLAMP	TATA spare parts
216349203326	BRACKET	TATA spare parts
216349203336	BRACKET FOR HOLDING CLAMP	TATA spare parts
216349203337	CLAMP EXHAUST	TATA spare parts
216349203340	BRACKET (EXHAUST)	TATA spare parts
216349203356	BRACKET EXHAUST	TATA spare parts
216349203371	BRACKET	TATA spare parts
216349203379	SUPPORT BRACKET	TATA spare parts
216349204201	CLAMP	TATA spare parts

216349206301	COVER (NOX SENSOR)	TATA spare parts
216349206302	GROMMET UREA TANK	TATA spare parts
216349206954	TAIL PIPE	TATA spare parts
216349206994	EXHAUST TAIL PIPE	TATA spare parts
216349207103	CLAMPING PLATE	TATA spare parts
216349207104	EXHAUST BKT (FOR 1ST PIPE)	TATA spare parts
216349207114	MTG BKT FOR NOX SENSOR	TATA spare parts
216349207119	EXHAUST MOUNTING BRACKET	TATA spare parts
216349207130	EXHAUST PIPE BRACKET	TATA spare parts
216349208202	EXHAUST BRACKET	TATA spare parts
216349208207	EXHAUST BRACKET	TATA spare parts
216349208208	EXHAUST BRACKET	TATA spare parts
216349208218	EXHAUST BRACKET	TATA spare parts
216349208224	CLAMP	TATA spare parts
216349208225	BRACKET FOR EXHAUST SYSTEM	TATA spare parts
216349208227	EXHAUST BRACKET	TATA spare parts
216349208235	CLAMP FOR MUFFLER	TATA spare parts
216349208254	BKT FOR AIR OIL SEPARATOR	TATA spare parts
216349208255	EXHAUST BRACKET	TATA spare parts
216349208263	L-BRACKET	TATA spare parts
216349208271	L-BRACKET EXHAUST SYSTEM	TATA spare parts
216349208278	PLATE FOR CLAMPING	TATA spare parts
216349208289	CLAMP	TATA spare parts
216349208290	CLAMP	TATA spare parts
216349209913	HEAT SHIELD TURBO OUT	TATA spare parts
216349209914	HEAT SHIELD (2ND FROM TURBO OUT)	TATA spare parts
216349209915	HEAT SHIELD (3RD FROM TURBO OUT)	TATA spare parts
216349209916	HEAT SHIELD (4TH FROM TURBO OUT)	TATA spare parts
216349209917	HEAT SHIELD (5TH FROM TURBO OUT)	TATA spare parts
216349209918	HEAT SHIELD (6TH FROM TURBO OUT)	TATA spare parts
216349209919	HEAT SHIELD (7TH FROM TURBO OUT)	TATA spare parts
216349209920	HEAT SHIELD (8TH FROM TURBO OUT)	TATA spare parts
216349209921	HEAT SHIELD (9TH FROM TURBO OUT)	TATA spare parts
216349209925	ASSY. FILTER HEAD BS4	TATA spare parts
216349209931	HEAT SHIELD (6TH FROM TURBO OUT)	TATA spare parts
216349209932	HEAT SHILED	TATA spare parts
216349209933	HEAT SHILED	TATA spare parts
216349209934	HEAT SHIELD	TATA spare parts
216349210101	EXHAUST ASSY WITH FLEX PIPE	TATA spare parts
216349210102	EXHAUST PIPE INTERMEDIATE	TATA spare parts
216349210103	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
216349210104	EXHAUST PIPE EXHAUST MANIFOLD END	TATA spare parts
216349210105	EXHAUST PIPE ASSY	TATA spare parts
216349210106	EXHAUST PIPE ASSY WITH FLEXIBLE HOSE	TATA spare parts
216349210107	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
216349210108	EXHAUST PIPE INTERMEDIATE	TATA spare parts
216349210109	PIPE ASSY UREA AIR MIX	TATA spare parts

216349210110	DECOMPOSE PIPE ASSY	TATA spare parts
216349210111	BRACKET ASSY EXHAUST TAIL PIPE MTG	TATA spare parts
216349210115	BRACKET ASSY TAIL PIPE MTG	TATA spare parts
216349216917	TAIL PIPE EXHAUST SYSTEM	TATA spare parts
216349216930	TAIL PIPE	TATA spare parts
216349990103	KIT ASSY HEAT SHIELD FOR EXHAUST PIPE	TATA spare parts
216349990104	SET - AFTER TREATMENT SYSTEM	TATA spare parts
216349990106	KIT-EXHAUST PIPE HEAT SHIELD ASSY	TATA spare parts
216349990108	KIT-HEAT SHIELD-EXHAUST PIPE	TATA spare parts
216350000108	ASSY RADIATOR FRAME	TATA spare parts
216350000116	BKT ON LONG MEMBER FOR HOLDING OTW PIPE	TATA spare parts
216350000117	ASSY BKT FOR OTW PIPE CLAMP HOLDING	TATA spare parts
216350000118	BKT FOR RADIATOR MTG RH(BOTTOM)	TATA spare parts
216350000119	BKT FOR RADIATOR MTG LH (BOTTOM)	TATA spare parts
216350000120	RADIATOR MTG BKT (TOP LH)	TATA spare parts
216350000121	RADIATOR MTG BKT (TOP RH)	TATA spare parts
216350000125	BRACKETASSY RADIATORMTG TOP-RH	TATA spare parts
216350000126	BRACKETASSY RADIATORMTG TOP-LH	TATA spare parts
216350000127	ENGINE COOLING SYSTEM WITH BRACKET	TATA spare parts
216350003327	BRACKET FOR CLAMPING PIPE (TC TO IC)	TATA spare parts
216350103311	BRACKET	TATA spare parts
216350105801	HOSE FOR OTW PIPE TO ENGINE WATER PUMP	TATA spare parts
216350105803	HOSE (RAD TOP TO ENG)	TATA spare parts
216350105804	HOSE (RAD BOTTOM TO ENG PUMP)	TATA spare parts
216350110108	ASSY.COOLING SYSTEM	TATA spare parts
216350110109	RADIATOR ASSY	TATA spare parts
216350110110	INTERCOOLER ASSY	TATA spare parts
216350110111	AUXILIARY WATER TANK ASSY	TATA spare parts
216350115802	HOSE RAD TOP TO ENGINE	TATA spare parts
216350115803	RUBBER HOSE (WATER FILL PIPE)	TATA spare parts
216350115804	RUBBER HOSE WATER FILL PIPE	TATA spare parts
216350115807	HOSE RADIATOR TOP TO ENGINE	TATA spare parts
216350206910	PIPE AUX TANK TO RAD BOTTOM	TATA spare parts
216350206917	ASSY PIPE RADIATOR TO OIL COOLER	TATA spare parts
216350206918	PIPE FROM OIL COOLER TO WATER PUMP	TATA spare parts
216350206919	FILL PIPE	TATA spare parts
216350206920	PIPE ASSY RADIATOR TO OIL COOLER	TATA spare parts
216350206925	VENT TUBE(ENGINE TO AUX TANK)	TATA spare parts
216350206935	VENT TUBE AUX WATER TANK TO ENGINE	TATA spare parts
216350206936	FILLER PIPE	TATA spare parts
216350206937	PIPE OIL COOLER TO WATER PUMP	TATA spare parts
216350206938	PIPE RADIATOR BOTTOM TO OIL COOLER	TATA spare parts
216350400101	DAT MTG BKT	TATA spare parts
216350403304	BRACKET	TATA spare parts
216350403305	BRACKET	TATA spare parts
216350404201	IC OUTLET PIPE CLAMP	TATA spare parts
216350404202	FILL PIPE CLAMP MTG BKT	TATA spare parts

216350407105	PLATE RADIATOR MTG BRACKET	TATA spare parts
216350407106	PLATE RADIATOR MTG BRACKET	TATA spare parts
216350408204	BRACKET	TATA spare parts
216350506301	FAN SHROUD	TATA spare parts
216350506302	FAN SHROUD	TATA spare parts
216354000110	ELECTROMAGNETIC RETARDER UNIT ASSY	TATA spare parts
216354100102	MUX-2B MOUNTING COVER	TATA spare parts
216354100103	CBCU-E MOUNTING COVER	TATA spare parts
216354100111	POSITIVE BATTERY CABLE	TATA spare parts
216354100112	NEGATIVE BATTERY CABLE	TATA spare parts
216354100113	LINK CABLE	TATA spare parts
216354100114	POSITIVE CUTT-OFF TO STARTER MOTOR CABLE	TATA spare parts
216354100119	ASSY BATTERY MTG. CARRIER	TATA spare parts
216354100120	ASSY. BRACKET REMOTE CUT-OFF SWITCH	TATA spare parts
216354100128	BATTERY CABLE LINK	TATA spare parts
216354100138	CABLE BATT +VE FROM C/O TO STARTER MOTOR	TATA spare parts
216354100150	ASSY. CABLE ELECT. CUT SW. TO SM+VE BS4	TATA spare parts
216354103302	BRACKET FOR CONNECTOR PARKING	TATA spare parts
216354110102	BATTERY CABLE NEGATIVE	TATA spare parts
216354110105	CABLE BATTERY -VE TO STARTER	TATA spare parts
216354110106	CABLE BATTERY-VE & STARTER	TATA spare parts
216354200106	ECU VOITH RETARDER	TATA spare parts
216354200110	ECU SPEED LIMITER BS2/3/4	TATA spare parts
216354200112	SPEED LIMITER	TATA spare parts
216354200121	BKT (SPEED LIMITER-ACTUATOR MOTOR	TATA spare parts
216354200122	BKT (SPEED LIMITER-ACTUATOR MOTOR	TATA spare parts
216354200123	MTG BKT FOR STARTER RELAY	TATA spare parts
216354200132	SEALING KIT SLD	TATA spare parts
216354200136	E.C.U SPEED LIMITER(80KMPH)	TATA spare parts
216354200140	MOTOR ACTUATOR UNIT ASSEMBLY	TATA spare parts
216354200141	ASSEMBLY WIRING HARNESS MOTOR UNIT TO EC	TATA spare parts
216354200142	INSTALLATION KIT	TATA spare parts
216354200143	SEALING KIT	TATA spare parts
216354200144	CONTROL CABLE 1512 LENGTH 2415MM	TATA spare parts
216354200145	ASSEMBLY WIRING HARNESS (SUPPLY)	TATA spare parts
216354200150	ASSY BEEPER MTG BRACKET	TATA spare parts
216354200151	VEHICLE SPEED SENSOR	TATA spare parts
216354200154	ASSEMBLY INSTRUMENT CLUSTER MOUNTING PL	TATA spare parts
216354200155	ASSEMBLY BRACKET FOR MOUNTING ASSEMBLY I	TATA spare parts
216354200158	ASSEMBLY ENGINE LAMP MOUNTING BRACKET B	TATA spare parts
216354200169	UREA LEVEL GAUGE W/IND BS4	TATA spare parts
216354200172	PRESSURE SWITCH 0.3 BAR	TATA spare parts
216354200173	PRESSURE SWITCH 0.6 BAR	TATA spare parts
216354200176	KIT SPEED LIMITER 70KM/H	TATA spare parts
216354200178	HAND LEVER VOITH RETARDER	TATA spare parts
216354200180	KIT SPEED LIMITER 60KM/H RATIO(0.88)	TATA spare parts
216354200195	INSTRUMENT CLUSTER ASSY	TATA spare parts

216354200196	INSTRUMENT CLUSTER	TATA spare parts
216354203301	BRACKET FOR BLOWER SWITCH	TATA spare parts
216354204901	INDICATOR BANK	TATA spare parts
216354207702	COVER IGNITION RELAY	TATA spare parts
216354208220	BATTERY CUT OFF MTG. PLATE	TATA spare parts
216354208222	MTG. BRACKET 4ST RELAY	TATA spare parts
216354209901	INST.CLUSTER-1:0.88	TATA spare parts
216354209902	INSTRU CLUSTER-1:0 88)-LHD LPO 1613 TC	TATA spare parts
216354209903	INSTRUMENT CLUSTER 1:1.04 RETARDER	TATA spare parts
216354209905	INSTRUMENT CLUSTER 1:0.88	TATA spare parts
216354209915	SPEEDO METER 1:0.88 RANGE 0-140KMPH	TATA spare parts
216354209933	INSTRUMENT CLUSTER (1:0.88) E-SPD	TATA spare parts
216354209935	INSTRUMENT CLUSTER (1:0.88) E-SPD	TATA spare parts
216354209936	INSTRUMENT CLUSTER (1:0.88) E-SPD	TATA spare parts
216354209938	INSTRUMENT CLUSTER (1 0.88) E-SPD EURO2	TATA spare parts
216354209940	INSTRUMENT CLUSTER (1:0.88) E-SPD	TATA spare parts
216354209953	SPEEDO-METER ELECTRONIC(:0.80 0-100)	TATA spare parts
216354209954	SPEEDO-METER ELECTRONIC(0.80 0-100)	TATA spare parts
216354209955	SPEEDO-METER ELECTRONIC(0.80 0-140)	TATA spare parts
216354209956	SPEEDO-METER ELECTRONIC(0.80 0-140)	TATA spare parts
216354209957	SPEEDO-METER ELECTRONIC(0.88 0-140)	TATA spare parts
216354209958	SPEEDO-METER ELECTRONIC(0.88 0-140)	TATA spare parts
216354209966	INSTRUMENT CLUSTER (1:0.88) E-SPD	TATA spare parts
216354209968	INSTRUMENT CLUSTER (1:1.04)	TATA spare parts
216354209970	INSTRUMENT CLUSTER (1:1.04) E-SPD	TATA spare parts
216354209977	INST.CLUSTER	TATA spare parts
216354209977C	INSTRUMENT CLUSTER ASSYCORE	TATA spare parts
216354209979	INSTRUMENT CLUSTER LPO1616	TATA spare parts
216354209980	INSTRUMENT CLUSTER(1:0.80) LP-1512	TATA spare parts
216354209982	INSTRUMENT CLUSTER (1:0.80) LPO 1512	TATA spare parts
216354209984	INSTRUMENT CLUSTER SPEEDO RATIO(1:0.88)	TATA spare parts
216354209991	INST.CLUSTER(1:0.86)	TATA spare parts
216354209995	INSTRUMENT CLUSTER ERGOPACK	TATA spare parts
216354210101	TEMPERATURE GAUGE TRANSMISSION OIL	TATA spare parts
216354300101	ASSY. MTG BRACKET AUTODRAIN CONTROLL	TATA spare parts
216354400101	ASSY.IND.LAMP ALTERNATOR-2 OFF	TATA spare parts
216354400102	ASSY.IND. LMAP ALTERNATOR-1 OFF	TATA spare parts
216354400103	BKT FOR MTG ACCELERATOR ACTUATOR	TATA spare parts
216354400104	HEAD LAMP LH 24V WITH 24V LEVELLING MOTO	TATA spare parts
216354400105	HEAD LAMP RH 24V WITH 24V LEVELLING MOTO	TATA spare parts
216354400106	HEAD LAMP LH 24V WITH 24V LEVELLING MOTO	TATA spare parts
216354400107	HEAD LAMP RH 24V WITH 24V LEVELLING MOTO	TATA spare parts
216354400108	LAMP H/L(-1.8PERC)24VHLL W/O RIM 24V RHD	TATA spare parts
216354400109	LAMP H/L(-1.8PERC)24VHLL W/O RIM 24V RHD	TATA spare parts
216354400116	LAMP H/L(-1.8%)24VHLL 24V RHD-LH	TATA spare parts
216354400117	LAMP H/L(-1.8%)24VHLL 24V RHD-RH	TATA spare parts
216354408219	SPEED LIMITER MTG BRACKET	TATA spare parts

216354600128	FUSE BOX COVER WITH SCREEN PRINTING	TATA spare parts
216354600131	FUSE BOX COVER WITH SCREEN PRINTING	TATA spare parts
216354600136	W/H TAIL	TATA spare parts
216354600152	WIRING HARNESS TAIL	TATA spare parts
216354600160	WIRING HARNESS ENGINE	TATA spare parts
216354600162	WIRING HARNESS AUTO TRANSMISSION	TATA spare parts
216354600164	WIRING HARNESS MAIN	TATA spare parts
216354600166	PIGTAIL ABS WIRING HARNESS	TATA spare parts
216354600167	MAIN WIRING HARNESS	TATA spare parts
216354600169	WIRING HARNESS ABS FRAME	TATA spare parts
216354600176	WIRING HARNESS RSL MOTOR	TATA spare parts
216354600178	BATTERY CABLE +VE MEGA FUSE TO CUT OFF	TATA spare parts
216354600181	BATTERY CABLE ASSY	TATA spare parts
216354600184	WIRING HARNESS ABS FRAME	TATA spare parts
216354600185	WIRING HARNESS ABS SPLIT	TATA spare parts
216354600188	WIRING HARNESS TAIL	TATA spare parts
216354600194	WIRING HARNESS MAIN	TATA spare parts
216354600196	WIRING HARNESS CAN BACKBONE FRONT	TATA spare parts
216354600198	WIRING HARNESS MAXI FUSE	TATA spare parts
216354601610	WIRING HARNESS P-CAN	TATA spare parts
216354601613	TOP COVER BATTERY-180AH WITH MAGIC EYE	TATA spare parts
216354601615	WIRING HARNESS PIG TAIL FOR WIPER MOTOR	TATA spare parts
216354601686	WIRING HARNESS RETARDER	TATA spare parts
216354601690	WIRING HARNESS MAIN	TATA spare parts
216354601691	WIRING HARNESS ABS PIGTAIL	TATA spare parts
216354601693	CABLE ASSY BATTERY -VE WIRING HARNESS	TATA spare parts
216354601694	WIRING HARNESS AFTER TREATMENT	TATA spare parts
216354601699	WIRING HARNESS TAIL	TATA spare parts
216354606303	FUSE BOX COVER WITH PRINTING	TATA spare parts
216354608201	L-BRACKET CONNECTOR MTG	TATA spare parts
216354610102	WIRING HARNESS AUTO TRANSMISSION	TATA spare parts
216354610104	WIRING HARNESS CAN BACKBONE REAR	TATA spare parts
216354610125	WIRING HARNESS MAIN	TATA spare parts
216354610126	WIRING HARNESS MAIN	TATA spare parts
216354610166	KIT WIRING HARNESS (ARTICULATED)	TATA spare parts
216354611603	WIRING HARNESS MAXI FUSE	TATA spare parts
216354611618	WIRING HARNESS CAN CHASSIS	TATA spare parts
216354611619	WIRING HARNESS CAN BACKBONE REAR	TATA spare parts
216354611620	WIRING HARNESS CAN BACKBONE FRONT	TATA spare parts
216354611646	W/H PIGTAIL WIF	TATA spare parts
216354620102	W/H MAIN LPO 1616-VOITH RETARDER	TATA spare parts
216354620103	W/H MAIN LPO 1616-VOITH RETARDER	TATA spare parts
216354620121	W/H MAIN	TATA spare parts
216354620122	W/H TAIL LPO-1618 TC MULTIPLEXING	TATA spare parts
216354620123	M CAN W/H MULTIPLEXING SYSTEM	TATA spare parts
216354620124	POWER CABLE STARTER TO MAXIFUSE I/P	TATA spare parts
216354620129	W/H TAIL LPO1621TC BSIV	TATA spare parts

216354620130	W/H AFTER TREATMENT FOR LPO1621 BSIV	TATA spare parts
216354620131	W/H ENGINE LPO1621TC BSIV	TATA spare parts
216354620132	CAN BACKBONE	TATA spare parts
216354620134	W/H PIGTAIL FOR PTO	TATA spare parts
216354620135	W/H MAIN LPO-1612 TC BS-II SLD & AMMETER	TATA spare parts
216354620150	W/H MAIN LPO1823TC S/A WITH VOITH RN	TATA spare parts
216354620151	WIRING HARNESS MAIN LPO1823;S/A WITH VOI	TATA spare parts
216354620152	WIRING HARNESS TAIL	TATA spare parts
216354620153	W/H MAIN LPO1616TC BSIV NOR ST & TWO LEV	TATA spare parts
216354620156	W/H RETARDER ECU TO DASHBOARD	TATA spare parts
216354620157	W/H SENSOR VOITH RETARDER	TATA spare parts
216354620160	WIRING HARNESS AFTER TREATMENT	TATA spare parts
216354620163	WIRING HARNESS ENGINE	TATA spare parts
216354620164	WIRING HARNESS CAN BACKBONE	TATA spare parts
216354620174	W/H MAINLPO1613TCBS-III CARCARRIER	TATA spare parts
216354620175	W/H MAIN	TATA spare parts
216354620178	WIRING HARNESS-MAIN WITH VOITH RETARDER	TATA spare parts
216354620179	WIRING HARNESS MAIN -VOITH RETARDER AMM	TATA spare parts
216354620183	W/H MAIN	TATA spare parts
216354620185	W/H MAIN LPO1316TC	TATA spare parts
216354620186	W/H MAIN LPO1512 TC MULTIPLEXING WITH TM	TATA spare parts
216354620187	WIRING HARNESS AUTO TRANSMISSION	TATA spare parts
216354620188	WIRING HARNESS MAIN	TATA spare parts
216354620189	WIRING HARNESS TAIL	TATA spare parts
216354620190	WIRING HARNESS MAXIFUSE	TATA spare parts
216354620191	W/H AFTER TREATMENT LCCR-IV 1618 FE	TATA spare parts
216354620192	WIRING HARNESS PIGTAIL FOR HORN	TATA spare parts
216354620193	WIRING HARNESS PIGTAIL FOR EX. BRAKE SOL	TATA spare parts
216354620194	WIRING HARNESS MAIN	TATA spare parts
216354620195	W/H ENGINE LPO 1618 FE LCCR -IV	TATA spare parts
216354620199	W/H MAIN LPO1618 BSIV JNNURM-II	TATA spare parts
216354620201	W/H TAIL LPO1618/62 BSIV JNNURM-II	TATA spare parts
216354620202	W/H ENGINE LPO1618 FE ISBE 5.9 BSIII	TATA spare parts
216354620203	W/H MAXI FUSE LPO1618 BSIV JNNURM-II	TATA spare parts
216354620204	W/H CAN BACKBONE FRONT LPO1618 BSIV JNNU	TATA spare parts
216354620205	WIRING HARNESS MAIN	TATA spare parts
216354620206	W/H CAN BACKBONE REAR LPO1618 BSIV JNNUR	TATA spare parts
216354620207	WIRING HARNESS FRONT LAMP	TATA spare parts
216354620209	W/H PIGTAIL AUTO DRAIN WIF LPO 1512/1618	TATA spare parts
216354620210	WIRING HARNESS TAIL	TATA spare parts
216354620211	WIRING HARNESS MAIN	TATA spare parts
216354620213	W/H MAIN	TATA spare parts
216354620216	WIRING HARNESS CAN BACKBONE FRONT	TATA spare parts
216354620217	WIRING HARNESS PIGTAIL EXT. BRK.	TATA spare parts
216354620218	W/H AUTO DRAIN	TATA spare parts
216354620219	W/H PIGTAIL PARKING BRAKE SOLENOID	TATA spare parts
216354620220	PIG TAIL STEERING WHEEL ADJUSTMENT	TATA spare parts

216354620221	W/H BATTERY CUT-OFF SWITCH	TATA spare parts
216354620222	WIRING HARNESS MAIN	TATA spare parts
216354620223	W/H AFTER TREATMENT	TATA spare parts
216354620224	W/H ENGINE	TATA spare parts
216354620225	W/H MAXIFUSE	TATA spare parts
216354620226	W/H CAN BACKBONE REAR	TATA spare parts
216354620228	W/H WIF PIGTAIL	TATA spare parts
216354620233	WIRING HARNESS MAIN	TATA spare parts
216354620234	WIRING HARNESS CAN BACKBONE FRONT	TATA spare parts
216354620235	WIRING HARNESS RSL MOTOR	TATA spare parts
216354630103	WIRING HARNESS CENTER	TATA spare parts
216354630113	WIRING HARNESS MAIN	TATA spare parts
216354630114	WIRING HARNESS PANEL	TATA spare parts
216354630115	WIRING HARNESS MAIN	TATA spare parts
216354630116	WIRING HARNESS MAIN ASSY	TATA spare parts
216354700103	BRACKET ASSY SPEED LIMITER ACTUATOR MTG	TATA spare parts
216354709901	FASTAG	TATA spare parts
216354800108	SCU ASSEMBLY	TATA spare parts
216354800109	BRACKET ASSY ECU MTG	TATA spare parts
216354800110	BRACKET ASSY REAR CBCU MTG	TATA spare parts
216354803301	L-BRACKET	TATA spare parts
216354804901	ECU ECAS	TATA spare parts
216354804902	DRIVER - MIC ASSEMBLY	TATA spare parts
216354804903	HEADPHONE	TATA spare parts
216354807501	RUBBER GROMMET	TATA spare parts
216354820101	ASSY.MAIN CABLE SET-R.H.D	TATA spare parts
216354820102	ASSY.CABLE SET-FRT.TO TAIL -W.B 62	TATA spare parts
216354820105	ASSY.MAIN CABLE SET-R.H.D	TATA spare parts
216354820108	W/H MAIN -INST.CLUSTER	TATA spare parts
216354820109	W/H TAIL-W.B 62 LPO 1616TC	TATA spare parts
216354820110	WIRING HARNESS TAIL	TATA spare parts
216354820110AE	W/H TAIL -W.B 47-OFFERLPA 1415/	TATA spare parts
216354820113	W/H MAIN LPO 1616-VOITH RETARDER	TATA spare parts
216354820114	W/H-TAIL- LPO-1616TC/62 VOITH RETARDER	TATA spare parts
216354821603	W/H TAIL LPO1613/62TC CAR CARR PTO	TATA spare parts
216354821608	W/H PIGTAIL-VOITH RET DIAGNOSIS	TATA spare parts
216354821609	W/H-PIG TAIL FOR SPEED SENSOR	TATA spare parts
216354821636	WIRING HARNESS-POWE SUPPLY ALT-2 TO STR	TATA spare parts
216354821658	EARTHING CABLE ENGINE BLOCK	TATA spare parts
216354821659	NEGATIVE POWER CABLE FOR ALTERNATOR TO S	TATA spare parts
216354821665	PIGTAIL FOR MUX-2B LPO1616 FE	TATA spare parts
216354900101	PLATE ASSY	TATA spare parts
216354904902	TRANSMISSION CONTROL MODULE	TATA spare parts
216354998201	STICKER BATTERY CUT-OFF SW	TATA spare parts
216360000119	COWL ASSY WITH CED COATING	TATA spare parts
216360000120	COWL ASSY	TATA spare parts
216360100106	COWL STRUCTURE	TATA spare parts



216360100124	COWL MTG(CO DRIVER)	TATA spare parts
216360100132	ASSY. COWL BARE LPT1613 ERGO BS3	TATA spare parts
216360100185	ASSY FRONT STRUCTURE	TATA spare parts
216360100187	DRIVER STATION ASSY	TATA spare parts
216360100189	ASSY DRIVER STATION W/O PAINTED	TATA spare parts
216360100192	ASSY COWL SHELL PAINTED	TATA spare parts
216360100193	DRIVER STATION ASSY W/O PAINTED	TATA spare parts
216360100194	DRIVER STATION ASSY CED PAINTED	TATA spare parts
216360100201	ASSY OUTRIGGER (DRIVER SIDE)	TATA spare parts
216360100202	ASSY.OUTRIGGER	TATA spare parts
216360100203	ASSY.CAB MTG.BKT.	TATA spare parts
216360100208	CAB MTG. BKT	TATA spare parts
216360100212	ASSY CAB MOUNTING BRACKET (CO-DRIVER SID	TATA spare parts
216360100232	ASSY OUTTRIGGER (CO-DRIVER SIDE)	TATA spare parts
216360100235	ASSY OUTRIGGER (COWL MTG REAR)	TATA spare parts
216360100252	ASSY COWL SHELL PAINTED W/O FACE RHD	TATA spare parts
216360100266	ASSY OUTRRIGER HEAD LAMP MTG LH	TATA spare parts
216360100273	ASSY OUTRRIGER HEAD LAMP MTG RH	TATA spare parts
216360100276	ASSY COWL COMPLETE FOR LPO 1621TC BS-IV	TATA spare parts
216360100277	ASSEMBLY OUTRIGGER (DRIVER SIDE)	TATA spare parts
216360100278	ASSY OUTRIGGER FOR REAR COWL MTG	TATA spare parts
216360100282	CAB MOUNTING BRACKET (CO-DRIVER SIDE)	TATA spare parts
216360100285	BRACKET ASSY AC UNIT MTG LH	TATA spare parts
216360100308	OUTRIGGER ASSY COWL MTG	TATA spare parts
216360107105	CABMOUNT(BALLATAPACKING)	TATA spare parts
216360107173	BALLATA PAKING	TATA spare parts
216360107236	MOUNTING BKT BOTTOM RH FOR RADIATOR GRI	TATA spare parts
216360107237	MOUNTING BKT BOTTOM LH FOR RADIATOR GRI	TATA spare parts
216360107266	BALLATA PACKING	TATA spare parts
216360107288	BALLATA PACKING¿ FOR COWL MTG.	TATA spare parts
216360107324	BALLAT PACKING FOR COWL MOUNTING	TATA spare parts
216360107325	BALLATA PACKING FOR COWL	TATA spare parts
216360107701	BALATA PACKING COWL MTG	TATA spare parts
216362100103	ASSY OUTRIGGER-RH	TATA spare parts
216362100104	ASSY OUTRIGGER LH	TATA spare parts
216362100108	ASSY OUTRIGGER-RH	TATA spare parts
216362100109	ASSY OUTRIGGER-LH	TATA spare parts
21637	DIFF.BRG.ADJUSTER RH	TATA spare parts
216370000101	KIT-SUPD	TATA spare parts
216370108202	BRACKET SUPD MTG	TATA spare parts
216370108204	BRACKET SUPD MTG	TATA spare parts
216370108205	BRACKET SUPD MTG	TATA spare parts
216370108206	BRACKET SUPD MTG	TATA spare parts
216370108207	BRACKET SUPD MTG	TATA spare parts
216370108209	BRACKET DRIVE AWAY SUPD MTG BS6	TATA spare parts
216370900109	SUPD ASSY BS6	TATA spare parts
216382400101	BRACKET WIPER MOTOR MTG	TATA spare parts

216382403301	BRACKET (WIPER MOTOR)	TATA spare parts
216383400106	COMPRESSOR ASSY 655CC	TATA spare parts
216383400112	ASSY HEATER UNIT MTG STRUCTURE	TATA spare parts
216383400114	BLOWER ASSY	TATA spare parts
216383403309	BRACKET HEATER PIPE MTG	TATA spare parts
216383406302	HEATER ADAPTOR	TATA spare parts
216383407701	HEATER HOSE INLET	TATA spare parts
216383407702	HEATER HOSE OUTLET	TATA spare parts
216383556301	BELT	TATA spare parts
216383605803	HEATER HOSE ENGINE END	TATA spare parts
216386800106	LHS CABLE - Z1 (2.6 METERS)	TATA spare parts
216386800108	NOZZLES TYPE DW2	TATA spare parts
216386804207	FASTENERS AND CLAMPS KIT	TATA spare parts
216388700102	ASSY ENGINE HOOD	TATA spare parts
216388700104	ASSY ENGINE HOOD LPO1621 BS4 WITH AC	TATA spare parts
216388707701	SEALING RUBBER (ENGINE HOOD)	TATA spare parts
216389100103	ASSY COWL MTG BRACKET REAR-RH	TATA spare parts
216389100104	ASSY Z-BRACKET (COWL MTG. LH FRONT)	TATA spare parts
216389100105	REAR MTG ASSY BOTTOM-RH	TATA spare parts
216389100106	OUTRIGGER ASSY COWL MTG FRONT-RH	TATA spare parts
216389100107	OUTRIGGER ASSY COWL MTG FRONT-LH	TATA spare parts
216389107701	BALATA PACKING COWL MTG FRONT-RH	TATA spare parts
216398000101	KIT-TEMPORARY STRUCTURE WITH CANOPY	TATA spare parts
216398808201	BRACKET(WIPER MOTOR)	TATA spare parts
216432407902	ANTI ROLL BAR	TATA spare parts
216515440101	ALTERNATOR 24V-75A BS3/4	TATA spare parts
216516100101	CONTAINER FOR LP1613 697 BSIV(ECU)	TATA spare parts
216516100102	CONTAINER FOR LPO1613/55 697 BSIV	TATA spare parts
216516100109	CONTAINER FOR LP1613 697 BSIV OBD-II	TATA spare parts
216516100110	CONTAINER FOR LPO1613 697 BSIV OBD-II	TATA spare parts
216524100101	ASSY HOUSING[ENGINE MOUNTING PAD FRONT]	TATA spare parts
216524200101	BRACKET ASSY ENGINE	TATA spare parts
216524200102	BRACKET ASSY ENGINE	TATA spare parts
216524203701	ENGINE¿ MTG¿ ASSYBS	TATA spare parts
216524203702	ENGINE¿ MTG¿ ASSYBS	TATA spare parts
216526717701	PACKING(GS BRACKET MTG)	TATA spare parts
216526800102	ASSY. BRACKET (GEAR SHIFT LEVER)	TATA spare parts
216526800103	ASSY. BRACKET (GEAR SHIFT LEVER)	TATA spare parts
216526800104	ASSY.BRACKET (FOR GEAR SHIFT LEVER)	TATA spare parts
216526800106	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
216526800108	ASSEMBLY BRACKET (FOR GEAR SHIFT LEVER)	TATA spare parts
216526800109	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
216526800111	ASSY SEL & SHIFTER YOKE & FORK	TATA spare parts
216526800112	ASSY GEAR SHIFT LEVER	TATA spare parts
216526800114	ASSY BRACKET (FOR GEAR SHIFT MTG)	TATA spare parts
216526800116	ASSY GEAR SHIFT LEVER	TATA spare parts
216526800122	BRACKET ASSY GEAR SHIFT LEVER MTG	TATA spare parts

216526800123	ASSY SEL & SHIFTER YOKE & FORK	TATA spare parts
216526800127	GEAR¿ SHIFT¿ LEVERB	TATA spare parts
216526800131	TURNING¿ TUBE¿ ASSY	TATA spare parts
216526807701	PACKING (GS BRACKET MTG)	TATA spare parts
216526807702	PACKING (GS BRACKET MTG)	TATA spare parts
216526860101	ASSEMBLY BRACKET (FOR GEAR SHIFT LEVER)	TATA spare parts
216526990101	KIT-GEAR SHIFT	TATA spare parts
216529100118	PIPE ASSY (BOOSTER TO M.CYL-6.OD)	TATA spare parts
216529100120	ASSY. CLUTCH BOOSTER BS4	TATA spare parts
216529100121	CLUTCH PEDAL LEVER ASSY.	TATA spare parts
216529100122	CLUTCH PEDAL MTG. BRACKET ASSY	TATA spare parts
216529300101	SPARE KIT - CLUTCH BOOSTER	TATA spare parts
216529300102	BUNDY¿ TUBE¿ ASSYBS	TATA spare parts
216529500101	BRACKET FOR CLUTCH BOOSTER MTG	TATA spare parts
216530107101	SPACER PLATE	TATA spare parts
216531000103	ASSY. FRAME COMPLETE FOR LPO 1510697/55	TATA spare parts
216531000104	ASSY. FRAME COMPLETE FOR LPO 1510697/53	TATA spare parts
216531000110	FRAME ASSY WITH FITMENT	TATA spare parts
216531000113	ASSY. FRAME LPO1613 697 55/60% WEVLLER	TATA spare parts
216531000116	ASSY FRAME COMPLETE LP1613 BSIV/52WB	TATA spare parts
216531000119	ASSEMBLY FRAME COMPLETE	TATA spare parts
216531000121	FRAME ASSY	TATA spare parts
216531000125	FRAME ASSY WITH FITMENT	TATA spare parts
216531000129	FRAME ASSY WITH FITMENT	TATA spare parts
216531000131	FRAME ASSY WITH FITMENT	TATA spare parts
216531200101	ASSY. BRACKET R.H RAD. MTG.	TATA spare parts
216531200102	ASSY. BRACKET LH. RAD. MTG.	TATA spare parts
216531200104	ASSY SUPPORT BKT-R.H (REAR ENG MTG)	TATA spare parts
216531200105	ASSY.SUPPORT BKT.LH(REAR ENG. MTG.)	TATA spare parts
216531200110	ASSY BRACKET RH(RADIATOR MTG)	TATA spare parts
216531200111	ASSY BRACKET LH (RADIATOR MTG)	TATA spare parts
216531200116	ASSY BRACKET RH (RADIATOR MTG) WITH SHIM	TATA spare parts
216531200117	ASSY BRACKET LH (RADIATOR MTG) WITH SHIM	TATA spare parts
216531200118	SUPPORT ASSY RH	TATA spare parts
216531200119	SUPPORT ASSY LH	TATA spare parts
216531200120	SUPPORT ASSY RH	TATA spare parts
216531200121	SUPPORT ASSY LH	TATA spare parts
216531200124	BRACKET ASSY RADIATOR	TATA spare parts
216531200125	BRACKET ASSY RADIATOR	TATA spare parts
216531200126	BRACKET ASSY CROSS MEMBER MTG RH	TATA spare parts
216531200127	BRACKET ASSY CROSS MEMBER MTG LH	TATA spare parts
216531200128	SUPPORT ASSY ENGINE	TATA spare parts
216531200129	SUPPORT ASSY ENGINE	TATA spare parts
216531200131	CROSS¿ MEMBER¿ ASSY	TATA spare parts
216531307186	L-REINFORCEMENT BOTTOM-RH	TATA spare parts
216531307187	L-REINFORCEMENT BOTTOM-LH	TATA spare parts
216531990101	KIT-ENGINE CROSS MEMBER REAR	TATA spare parts

216532100101	ASSY FRONT SPRING	TATA spare parts
216532107113	PACKINGPLATE BS6	TATA spare parts
216532300103	ASSY. FRONT SHOCK ABSORBER BS6	TATA spare parts
216532403202	CENTERBOLTM12X210 BS6	TATA spare parts
216532407125	8TH CROSS MEMBER	TATA spare parts
216532603701	BRACKET-LH SHOCK ABS MTG. BS6	TATA spare parts
216532603702	BRACKET-RH SHOCK ABS MTG. BS6	TATA spare parts
216541100104	ASSY PROP SHAFT WITH CENTRE BEARING	TATA spare parts
216541110103	PROPELLER¿ SHAFT¿ ASSY	TATA spare parts
216541110104	PROPELLER¿ SHAFT¿ ASSY	TATA spare parts
216541110105	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
216541110106	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
216541120117	PROPELLER¿ SHAFT¿ ASSY	TATA spare parts
216541120118	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
216541120119	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
216541120120	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
216541303302	BRACKET(CENTRE BRG.)	TATA spare parts
216541303304	BRACKET(CENTRE BRG.)	TATA spare parts
216541303324	BRACKET(FOR 1ST CENTRE BEARING)	TATA spare parts
216541303325	BKT( FOR 2ND CENTRE BEARING )	TATA spare parts
216541303326	BRACKET( FOR 1ST CENTRE BEARING)	TATA spare parts
216541303327	BKT( FOR 1ST CENTRE BEARING	TATA spare parts
216541303328	BRACKET(FOR 1ST CENTRE BEARING M/S DANA)	TATA spare parts
216541303330	CENTER BEARING	TATA spare parts
216542900101	ASSY STEEL TUBE(15 O.D X 2260 LG.)	TATA spare parts
216542900102	ASSY STEEL TUBE 15 O.D X 2100 LG.)	TATA spare parts
216543200101	SUB ASSY AIR TANKS 240 CD STRAP	TATA spare parts
216543200102	SUB ASSY AIR TANKS 220 CD STRAP	TATA spare parts
216543700122	CONDENSATE OIL SEPERATOR MTG BRKT	TATA spare parts
216543708201	BRACKET (PURGE TANK)	TATA spare parts
216543900104	SET ASSY NYL PIPE COMP LPO1510CMVR	TATA spare parts
216543900105	SET ASSY NYL PIPE COMP LPO1510 CMVR	TATA spare parts
216543900110	SET ASSY NYL PIPE COMP LPO1510(VOSS)	TATA spare parts
216543900204	ASSY.18DIA FIRST METAL PIPE LINE FROM CO	TATA spare parts
216543900205	ASSY PIPE-SECOND METAL PIPE COMP-18 DIA.	TATA spare parts
216543900206	ASSY.PIPE-THIRD METAL PIPE	TATA spare parts
216543900207	FOURTH METAL PIPE (OILSEP-AIR DRYER)	TATA spare parts
216543900212	ASSY NYLON PIPE BUNCH COMPLETE	TATA spare parts
216543900215	METAL PIPELINE CRIMPED TEFLON HOSE-1ST P	TATA spare parts
216543900216	ASSY.METAL PIPE 18 O.D SECOND PIPE	TATA spare parts
216543900217	ASSY.NYLON PIPE BUNCH FOR LP1613/52	TATA spare parts
216543900223	PIPE BUNCH ASSY LP1613/59 BS-IV	TATA spare parts
216543900224	PIPE ASSY COMP.TO AIR DRYER II PIPE	TATA spare parts
216543900225	PIPE ASSY COMP.TO AIR DRYER III PIPE	TATA spare parts
216543900230	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
216543900231	PIPE ASSY COMPRESSOR-2	TATA spare parts
216543900232	PIPE ASSY COMPRESSOR-3	TATA spare parts

216543900233	PIPE ASSY COMPRESSOR-4	TATA spare parts
216543900234	PIPE ASSY FIRST WITH HOSE 18 DIA	TATA spare parts
216543900235	PIPE ASSY SECOND METAL PIPE -I	TATA spare parts
216543900236	PIPE ASSY METAL THIRD-COMP TO AIR DRYER	TATA spare parts
216543900269	BUNCH PIPE ASSY	TATA spare parts
216543900296	PIPE ASSY	TATA spare parts
216543900299	PIPE ASSY	TATA spare parts
216543910136	PIPE BUNCH ASSY	TATA spare parts
216543910161	PIPE ASSY BUNCH COMPLETE	TATA spare parts
216543910201	PIPE ASSY BUNCH COMPLETE	TATA spare parts
216543920101	PIPE ASSY BUNCH COMPLETE	TATA spare parts
216543920116	PIPE ASSY COMPRESSOR-2	TATA spare parts
216543920117	PIPE ASSY COMPRESSOR-3	TATA spare parts
216543920118	PIPE ASSY COMPRESSOR-4	TATA spare parts
216543920119	PIPE ASSY FIRST WITH HOSE 18 DIA	TATA spare parts
216543920126	PIPE ASSY BUNCH COMPLETE	TATA spare parts
216543920134	PIPE ASSY COMPRESSOR OUTLET-2	TATA spare parts
216543920135	PIPE ASSY COMPRESSOR OUTLET-3	TATA spare parts
216546100106	STEERING COLUMN W/O STRG WHEEL W/SPINDL	TATA spare parts
216546150101	KIT ASSY PIPES LPO1510/55EU-II(697)	TATA spare parts
216546800105	SUCTION LINE HOSE ASSEMBLY	TATA spare parts
216546800106	RETURN LINE HOSE ASSY.LPO 1510/55 BS II	TATA spare parts
216546800107	PRESSURE LINE HOSE ASSY	TATA spare parts
216546800118	RETURNç LINEç ASSYB	TATA spare parts
216546800119	RETURNç LINEç ASSYB	TATA spare parts
216546800120	SUCTIONç LINEç ASSY	TATA spare parts
216546800121	PRESSURE LINE ASSY	TATA spare parts
216546800122	SUCTION LINE ASSY	TATA spare parts
216546800123	RETURN LINE ASSY	TATA spare parts
216546800125	PRESSUREç LINEç ASSY	TATA spare parts
216546800126	PRESSUREç LINEç ASSY	TATA spare parts
216547104201	BRACKET(FUEL FEED PUMP MTG.)	TATA spare parts
216547600115	ASSY. SUCTION LINE(BABY FILTER TO ENG)	TATA spare parts
216547600116	ASSY. SUCTION PIPE(TANK TO BABY FILTER)	TATA spare parts
216547600117	RETURN FUEL LINE	TATA spare parts
216547600118	FUEL LINE (ENGINE TO FUEL FILTER)	TATA spare parts
216547600119	FUEL LINE (BABY FILTER TO FUEL FILTER)	TATA spare parts
216547600120	FUEL LINE (BABY FILTER TO TANK)	TATA spare parts
216547600121	FUEL RETURN LINE	TATA spare parts
216547600134	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
216547600135	FUEL SUCTION PIPE ASSY TANK TO P/FILTER	TATA spare parts
216547600136	FUEL SUCTION PIPE ASSY P/FILTER TO W/SEP	TATA spare parts
216547600137	FUEL PIPE ASSY RETURN LINE	TATA spare parts
216547600150	FUEL LINES ASSY (TANK TO BABY FILTER)	TATA spare parts
216547600151	FUEL LINES ASSY (BABY FILTER TO FWS)	TATA spare parts
216547600152	FUEL LINES ASSY (TANK TO ENGINE)	TATA spare parts
216547600153	FUEL LINES ASSY (FWS TO ENGINE)	TATA spare parts

216547600154	FUEL SUCTION PIPE ASSY FUEL TANK TO FTR	TATA spare parts
216547600155	SUCTION FUEL PIPE - FUEL TANK TO WATER S	TATA spare parts
216547600156	SUCTION PIPE ASSY -WATER SEPARATOR TO FU	TATA spare parts
216547600157	SUCTION PIPE ASSY - FUEL FILTER TO ENGIN	TATA spare parts
216547600158	RETURN FUEL PIPE ASSY - ENGINE TO FUEL T	TATA spare parts
216547600159	SUCTION FUEL PIPE - FUEL TANK TO WATER S	TATA spare parts
216547600160	RETURN FUEL PIPE ASSY - ENGINE TO FUEL T	TATA spare parts
216547703301	FUEL FILTER MTG. BKT.	TATA spare parts
216547990101	ASSY.RETROFITMENT KIT - MECH.FEED PUMP	TATA spare parts
216549100101	ASSY MUFFLER WITH TAIL PIPE	TATA spare parts
216549100102	ASSY MUFFLER WITH TAIL PIPE	TATA spare parts
216549100103	ASSY.MUFFLER WITH TAIL PIPE	TATA spare parts
216549100105	ASSY PIPE EXHAUST TO DPS(BEFORE DOC POC)	TATA spare parts
216549100106	ASSY PIPE EXHAUST TO DPS (AFTER DOC POC)	TATA spare parts
216549100111	TUBE ASSY (EXHAUST PIPE TO DPS-FRONT)	TATA spare parts
216549100112	TUBE ASSY (EXHAUST PIPE TO DPS - REAR)	TATA spare parts
216549100113	SILENCER ASSY WITH TAIL PIPE	TATA spare parts
216549105801	RUBBER HOSE SILENCER TO DPS	TATA spare parts
216549105802	RUBBER HOSE	TATA spare parts
216549106905	TUBE OD6 X 0.7 (HOSE TO DPS)	TATA spare parts
216549106906	TUBE OD6 X 0.7 (HOSE TO DPS)	TATA spare parts
216549106907	TUBE OD6 X 0.7 (HOSE TO DPS)	TATA spare parts
216549106908	TUBE OD6 X 0.7 (HOSE TO DPS)	TATA spare parts
216549106910	TUBE	TATA spare parts
216549106911	TUBE	TATA spare parts
216549109901	ASSY. HEAT SHIELD	TATA spare parts
216549109902	ASSY. HEAT SHIELD	TATA spare parts
216549200105	ASSY. EXHAUST PIPE FRONT (1ST PIPE)	TATA spare parts
216549200106	ASSY EXHAUST FIRST PIPE	TATA spare parts
216549200107	ASSY. EXHAUST PIPE (2ND PIPE)	TATA spare parts
216549200112	EXHUAT PIPE(FIRST)	TATA spare parts
216549200113	ASSY. EXHAUST PIPE	TATA spare parts
216549200116	ASSY. INTERMEDIATE PIPE	TATA spare parts
216549200119	ASSY. BRACKET(AT EXH BRAKE)	TATA spare parts
216549200120	ASSY. INTERMEDIATE PIPE	TATA spare parts
216549200121	ASSY. BRACKET (EXHAUST MTG.)	TATA spare parts
216549200123	BRACKET (DPS SENSOR¿ MTG)	TATA spare parts
216549200124	ASSY. EXHAUST PIPE(EXHAUST BRAKE-DOC)	TATA spare parts
216549200125	ASSY EXHAUST PIPE DOC TO MUFLER	TATA spare parts
216549200126	ASSY EXHAUST PIPE¿ DOC TO MUFLER	TATA spare parts
216549200127	ASSY INTERMEDIATE PIPE	TATA spare parts
216549200133	EXHAUST PIPE ASSY INT	TATA spare parts
216549200134	BRACKET ASSY	TATA spare parts
216549200136	EXHAUST¿ PIPE¿ ASSY	TATA spare parts
216549200138	EXHAUST¿ PIPE¿ ASSY	TATA spare parts
216549200140	BRACKET ASSY (EXHAUST	TATA spare parts
216549203301	Z BRACKET SILENCER MTG	TATA spare parts

216549203302	BRACKET	TATA spare parts
216549203304	BRACKET	TATA spare parts
216549205301	GASKET	TATA spare parts
216549208203	CLAMP	TATA spare parts
216549208204	CLAMP	TATA spare parts
216549208212	L-BRACKET	TATA spare parts
216549208213	L-BRACKET	TATA spare parts
216549208214	DOC CLAMP	TATA spare parts
216549208215	DOC CLAMP	TATA spare parts
216549208218	EXHAUST CLAMP	TATA spare parts
216549208220	BRACKET	TATA spare parts
216549208221	SUPPORT PLATE	TATA spare parts
216549208224	CLAMP (EXHAUST MTG.)	TATA spare parts
216549208225	BRACKET	TATA spare parts
216549208226	BRACKET	TATA spare parts
216549208227	CLAMP	TATA spare parts
216549208228	L BRACKET	TATA spare parts
216549208229	L BRACKET	TATA spare parts
216549208233	L-BRACKET	TATA spare parts
216549208235	L-BRACKET	TATA spare parts
216549208240	BRACKET	TATA spare parts
216554100102	ASSY. BATT. CABLE -VE	TATA spare parts
216554100103	ASSY. BATT. CABLE -VE	TATA spare parts
216554100104	ASSY BATT. CABLE +VE	TATA spare parts
216554100105	ASSY. BATT. CABLE +VE	TATA spare parts
216554100106	ASSY. BATT. CABLE +VE (MANNUAL TO REMOTE	TATA spare parts
216554100107	BATT. CABLE +VE(MANNUAL REM CUT-OFF SWIT	TATA spare parts
216554100108	ASSY. BATT. CABLE +VE	TATA spare parts
216554100109	ASSY. BATT. CABLE +VE( MEGA TO MANNUAL C	TATA spare parts
216554100110	ASSY. BATT. CABLE +VE	TATA spare parts
216554100111	ASSY. BATT. CABLE +VE	TATA spare parts
216554208201	SUPPORT BRACKET (WH SENSOR)	TATA spare parts
216554208202	MTG. BKT. COVER (BOOST PR. SENSOR)	TATA spare parts
216554209902	INSTRUMENT CLUSTER(0.88)EGR BSIV	TATA spare parts
216554209903	INSTRUMENT CLUSTER(0.80) EGR BSIV	TATA spare parts
216554209904	RPM METER 24V 582 HZ	TATA spare parts
216554209907	INSTRUMENT CLUSTER ASSY	TATA spare parts
216554209909	INSTRUMENT CLUSTER ASSY	TATA spare parts
216554240101	ASSY. MOUNTING BRACKET (RESISTOR)	TATA spare parts
216554507701	DUMMY CAP HAZARD SWITCH	TATA spare parts
216554507702	DUMMY COVER PUSH BUTTON	TATA spare parts
216554507703	DUMMY COVER MAIN LINE SWITCH	TATA spare parts
216554600102	WIRING HARNESS MAIN	TATA spare parts
216554600103	WIRING HARNESS ENGINE	TATA spare parts
216554606302	FUSE BOX COVER AND STICKER ASSY	TATA spare parts
216554608201	BRACKET CHANNEL MTG	TATA spare parts
216554620101	WIRING HARNESS SENSOR FOR EGR	TATA spare parts

216554620102	WIRING HARNESS ENGINE FOR EGR	TATA spare parts
216554620103	WIRING HARNESS MAIN FOR LP1613/697	TATA spare parts
216554620110	W/H DPS INTERCONNECTION	TATA spare parts
216554620111	W/H BATTERY CUT-OFF SWITCH	TATA spare parts
216554620112	W/H PIGTAIL VOLTMETER	TATA spare parts
216554620113	WIRING HARNESS TAIL	TATA spare parts
216554620114	MAIN WIRING HARNESS BS4	TATA spare parts
2165600003R40	ASSEMBLY BODY FITTED	TATA spare parts
216589100101	ASSY. BRACKET RH (COWL MTG. REAR)	TATA spare parts
216632403306	COMPOUND LINK PIVOT BKT	TATA spare parts
216700990102	KIT FULLY TRIMMED CABIN FOR LPK 2518 BS4	TATA spare parts
216700990103	KIT FULLY TRIMMED CABIN FOR LPK 2518	TATA spare parts
216700990104	KIT FULLY TRIMMED CABIN FOR LPK 2518 BS4	TATA spare parts
216700990105	KIT FULLY TRIMMED CAB FOR PRIMA 3123.K	TATA spare parts
216700990106	KIT FULLY TRIMMED CAB FOR PRIMA 2518.K	TATA spare parts
216724200102	ASSY BRACKET (ENG. MTG. TOP)	TATA spare parts
216724200103	ASSY.BRACKET-LH(ENG.MTG.-REAR BOTTOM)	TATA spare parts
216724200104	ASSY.BRACKET-RH(ENG.MTG.-REAR BOTTOM)	TATA spare parts
216724200106	BRACKET ASSY CHASSIS RH	TATA spare parts
216724200106NR	BRACKET ASSY CHASSIS RH	TATA spare parts
216724200107	BRACKET ASSY CHASSIS LH	TATA spare parts
216724200107NR	BRACKET ASSY CHASSIS LH	TATA spare parts
216724200108	BRACKET ASSY ENGINE MTG TOP REAR	TATA spare parts
216726800102	ASSY.TURNING TUBE (GEAR SHIFT LINKAGE)	TATA spare parts
216726800108	ASSY. BRACKET (G/SHIFT LINKAGE)	TATA spare parts
216726800111	ASSY.TURNING TUBE (WITH BUSH)	TATA spare parts
216726800116	ASSY. TURNING TUBE WITH BUSH	TATA spare parts
216726800124	ASSY. TURNING TUBE WITH G.S. LINKAGE	TATA spare parts
216726800129	ASSY BRACKET - LINK ROD MTG	TATA spare parts
216726806701	PIN	TATA spare parts
216726807108	LEVER (TURNING TUBE) BS6	TATA spare parts
216729100102	ASSY CLUTCH BOOSTER WITH FORK	TATA spare parts
216729100105	ASSY. CLUTCH BOOSTER W/FORK BS1/2/3/4	TATA spare parts
216729100106	ASSY. BRACKET (CLUTCH BOOSTER MTG)	TATA spare parts
216729100107	ASSY. CLUTCH BOOSTER W/FORK BS3/4	TATA spare parts
216729100111	ASSY BRACKET (CLUTCH BOOSTER MTG.)	TATA spare parts
216729100112	BUNDY TUBE ASSY CMC TO LONG MEMBER	TATA spare parts
216729100113	BUNDY TUBE ASSY LONG MEMBER	TATA spare parts
216729107701	CLUTCH PEDAL FOAM	TATA spare parts
216729150109	ASSY PIPE (FROM RES TO MC)	TATA spare parts
216729300103	ASSY. TUBE ( DIA 6 X 1880 LG.)	TATA spare parts
216729300105	ASSY. PIPE (DIA 6 X 2190 LG.)	TATA spare parts
216729300107	BUNDY TUBE ASSY LONG MEMBER	TATA spare parts
216729300108	BUNDY TUBE ASSY CMC TO LONG MEMBER	TATA spare parts
216729500102	ASSY.CONTROL MTG. BRACKET WITH CYL. MTG.	TATA spare parts
216729508202	BRACKET HP PIPE CONNECTOR HOLDING	TATA spare parts
216729508203	L-BRACKET CLUTCH PIPE MTG	TATA spare parts



216729990101	ASSY SPARE PARTS KIT FOR 352 DIA/RETRO	TATA spare parts
216729990103	SPARE KIT CLUTCH BOOSTER (TYPE-1)	TATA spare parts
216729990104	KIT CLUTCH BOOSTER ASSY MINOR (TYPE-1)	TATA spare parts
216730100101	ASSY. BRACKET	TATA spare parts
216731000101	ASSY. FRAME COMPLETE LPK2516/ LPK2518	TATA spare parts
216731000102	ASSY FRAME COMPLETE WITH FITMENTS	TATA spare parts
216731000103	ASSY. FRAME WITH FITMENT BS2/3/4	TATA spare parts
216731000104	ASSY FRAME COMPLETE	TATA spare parts
216731000105	ASSY FRAME COMPLETE(1487 ROH)	TATA spare parts
216731000106	ASSY FRAME COMPLETE(1487 ROH)	TATA spare parts
216731000108	ASSY. FRAME COMPLETE (FOR G-1150)	TATA spare parts
216731000109	ASSY. FRAME COMPLETE	TATA spare parts
216731000110	ASSY FRAME COMPLETE (1487 ROH)	TATA spare parts
216731000112	ASSY FRAME COMPLETE FOR 7M3 RMC	TATA spare parts
216731000113	ASSY. FRAME LPK2518TC	TATA spare parts
216731000117	ASSY. FRAME WITH FITMENT BS1/2/3/4	TATA spare parts
216731000118	ASSY. FRAME WITH FITMENT BS3/4	TATA spare parts
216731000119	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
216731000122	ASSY FRAME LPK2518(CAST 6 HOLE BRKT)BS4	TATA spare parts
21673100012204	ASSY FRAME LPK2518(FAB 4 HOLE BRKT)BS4	TATA spare parts
21673100012206	ASSY FRAME (CAST TYPE 6 HOLE BRKT)	TATA spare parts
216731000123	ASSY. FRAME WITH FITMENTS LPK 2518 BS4	TATA spare parts
216731000124	FRAME ASSY WITH FITMENT	TATA spare parts
216731000126	FRAME ASSY WITH FITMENT	TATA spare parts
216731000138	FRAME ASSY WITH FITMENT	TATA spare parts
216731000140	FRAME ASSY WITH FITMENT	TATA spare parts
216731000142	FRAME ASSY WITH FITMENT	TATA spare parts
216731000145	ASSY. FRAME 2518 (FAB 4 HOLE BRKT) BS3/4	TATA spare parts
216731000156	FRAME ASSY WITH FITMENT	TATA spare parts
216731107103	REINFORCEMENT RH	TATA spare parts
216731107104	REINFORCEMENT LH	TATA spare parts
216731107123	REINFORCEMENT RH	TATA spare parts
21673110712335	REINFORCEMENT RH_UNPAINTED	TATA spare parts
216731107124	REINFORCEMENT LH	TATA spare parts
21673110712435	REINFORCEMENT LH_UNPAINTED	TATA spare parts
216731200101	ASSY SUPPORT-RH(2ND C.M)	TATA spare parts
216731200102	ASSY SUPPORT-LH (2ND C.M)	TATA spare parts
216731200103	ASSY SUPPORT (3RD C.M )	TATA spare parts
216731200104	ASSY. ENG. CROSS MEMBER(FRONT) BS1/2/3/4	TATA spare parts
216731200106	ASSY. STIFFENER WITH SPACER(2ND C.M)	TATA spare parts
216731200107	ASSY. STIFFENER WITH SPACER(3RD C.M)	TATA spare parts
216731200111	ASSY BKT WITH PLATE-5TH SUPP ON LM-RH	TATA spare parts
216731200112	ASSY BKT WITH PLATE-5TH SUPP ON LM-LH	TATA spare parts
216731200113	ASSY ENGINE X-MEMBER REAR(WITH SUPPORT)	TATA spare parts
216731200118	CROSS MEMBER ASSY 6TH	TATA spare parts
216731200119	END CROSS MEMBER ASSY	TATA spare parts
216731200120	BRACKET ASSY RADIATOR MTG RH	TATA spare parts

216731200121	BRACKET ASSY RADIATOR MTG LH	TATA spare parts
216731207105	STIFFENER (2ND C.M)	TATA spare parts
216731207106	STIFFENER (3RD C.M)	TATA spare parts
216731207119	END X-MEMBER	TATA spare parts
216731208201	END CROSS MEMBER	TATA spare parts
21673120820135	END CROSS MEMBER	TATA spare parts
216731208601	SPACER PLATE (2ND C.M)	TATA spare parts
216731208602	SPACER PLATE (3RD C.M)	TATA spare parts
216731307101	REINFORCEMENT-RH (FRONT SPR BKT)	TATA spare parts
216731307102	REINFORCEMENT-LH (FRONT SPR BKT)	TATA spare parts
216731700102	ASSY NOISE SHIELD - BOTTOM(GEAR BOX)	TATA spare parts
216731700103	ASSY NOISE SHIELD - TOP (GEAR BOX)	TATA spare parts
216731700106	ASSY NOISE SHIELD (RADIATOR BOTTOM)	TATA spare parts
216731700107	ASSY. MTG. BRACKET(ENG. SHIELD BOTTOM)	TATA spare parts
216731700112	NOISE SHIELD ASSY REAR	TATA spare parts
216731700114	NOISE SHIELD ASSY REAR	TATA spare parts
216731700120	BRACKET ASSY RADIATOR MOUNTING BS6	TATA spare parts
216731910161	BREATHER HOSE ASSY	TATA spare parts
216731990102	KIT ASSY FOR 6TH X-MEMBER	TATA spare parts
216731993301	BRACKET FOR BREATHER	TATA spare parts
216731993303	BRACKET (FOR BREATHER)	TATA spare parts
216731993304	BRACKET (FOR BREATHER)	TATA spare parts
216732300101	LOAD BODY MTG BKT.-RH	TATA spare parts
216732400101	ASSY SUSPENSION COMPLETE-26T VAVE	TATA spare parts
216732400105	ASSY TRUNNION BKT-26T VAVE	TATA spare parts
216732400108	ASSLY.PIVOT HSG.VAVE SUSPENSION	TATA spare parts
216732400110	ASSY 26T VAVE SUSP	TATA spare parts
216732400111	ASSY TRUNNION BRACKET VAVE (26T)	TATA spare parts
216732400113	ASSLY.PIVOT HOUSING	TATA spare parts
216732400114	RETRO KIT 26T REVERSE U BOLT	TATA spare parts
216732400120	ASSY BOGIE SUSP KIT	TATA spare parts
216732400123	RUBBER BOLSTER SPRING ASSEMBLY	TATA spare parts
216732400124	ASSEMBLY ADAPTOR PLATE	TATA spare parts
216732400126	LINK ASSLY-V ROD	TATA spare parts
216732400127	ASSY. BUSH CENTER (V ROD) BS2/3/4	TATA spare parts
216732400129	ASSLY.RUBBER BOLTSTER	TATA spare parts
216732400131	ASSY ADAPTOR PLATE (AXLE)	TATA spare parts
216732403201	HEX BOLT M16X2X70-10.9 DACROMET FINISH	TATA spare parts
216732403704	GUIDE PLATE	TATA spare parts
216732403705	PIVOT HOUSING	TATA spare parts
216732403712	ADAPTOR PLATE FINISHED	TATA spare parts
216732404201	U-CLAMP	TATA spare parts
216732404202	SPRING CLIP-REAR	TATA spare parts
216732404203	SPRING CLIP-REAR	TATA spare parts
216732404204	SPRING CLIP-REAR	TATA spare parts
216732404205	U CLAMP	TATA spare parts
216732404206	U-BOLT REAR SPRING (M24X2)	TATA spare parts

216732406501	NUT U CLAMP	TATA spare parts
216732406502	HEX.NUT M24X2 GRD.10 PREVAILING TORQUE T	TATA spare parts
216732406503	M20 SLOTTED NUT	TATA spare parts
216732406504	HEX.FL NUT M16-10 DACROMET FINISH	TATA spare parts
216732406505	NUT U-BOLT REAR SPRING (M24X2)	TATA spare parts
216732406702	4 DIA.SPLIT PIN	TATA spare parts
216732407602	PARALLEL LINK	TATA spare parts
216732408801	STUD ADAPTOR PLATE	TATA spare parts
216732409202	HARDENED WASHER M24	TATA spare parts
216732409204	M20 WASHER	TATA spare parts
216732409205	WASHER REAR SPRING (M24)	TATA spare parts
216733000101	FRT AXLE LPT1615 (180MM/70 DEG INC)	TATA spare parts
216733000102	ASSY.FR.AXLE COMPL.WITH BRAKES-180 LINER	TATA spare parts
216733000107	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
216733000108	FRONTAXLEASSYWITHBRAKE ABS BS6	TATA spare parts
216733105101	BEAM FRONT AXLE 6.5TP-II	TATA spare parts
216733805101	TIE ROD ARM RH	TATA spare parts
216733805102	TIE ROD ARM LH	TATA spare parts
216741100101	ASSY. PROP. SHAFT WITH CENTRE BRG.(1408)	TATA spare parts
216741100103	SHORT FORK TUBE & FRONT END PIECE	TATA spare parts
216741100104	CENTRE BEARING ASSY	TATA spare parts
216741100105	COUPLING FLANGE & DUST COVER ASSY.	TATA spare parts
216741100106	HEX NUT	TATA spare parts
216741100107	ASSY. PROP. SHAFT WITH CENTRE BRG.	TATA spare parts
216741100108	"SHORT FORK,TUBE & FRONT END PIECE ASSY"	TATA spare parts
216741106502	HEX. NUT	TATA spare parts
216741110102	PROPELLER SHAFT ASSY FRONT	TATA spare parts
216741110103	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
216741110115	PROPELLER SHAFT ASSY REAR	TATA spare parts
216741120103	ASSY PROP. SHAFT-FRONT(1385 CLOSED)	TATA spare parts
216741120104	ASSY PROP.SHAFT-IN-AXL(663 CLOSED)	TATA spare parts
216741120105	CROSS ASSY	TATA spare parts
216741120106	DUST COVER ASSY	TATA spare parts
216741120107	ASSY. UNIVERSAL JOINT BS2/3	TATA spare parts
216741120108	DUST COVER ASSY	TATA spare parts
216741120109	ASSY. PROP. SHAFT REAR	TATA spare parts
216741120111	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
216741120113	CROSS ASSY.	TATA spare parts
216741120114	LONG FORK SUB ASSY.	TATA spare parts
216741120115	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
216741120116	CROSS ASSY.	TATA spare parts
216741120117	LONG FORK SUB ASSY.	TATA spare parts
216741120118	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
216741120119	ASSY PROP. SHAFT-FRONT(1430-CLOSED)-RSB	TATA spare parts
216741120120	ASSY. PROP. SHAFT-INT-AXL(600-CL)BS2/3	TATA spare parts
216741120121	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
216741120122	LONG FORK SUB ASSY.	TATA spare parts

216741120123	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
216741120127	ASSY PROP. SHAFT-FRONT(1340 CLOSED)	TATA spare parts
216741120128	ASSY PROP.SHAFT-IN-AXL(690 CLOSED)	TATA spare parts
216741120129	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
216741120130	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
216741120131	ASSY PROP. SHAFT-FRONT(1365 CLOSED)	TATA spare parts
216741120132	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
216741120135	SHORT FORK SUB ASSY.	TATA spare parts
216741120136	ASSY PROP. SHAFT-FRONT(1390 CLOSED)	TATA spare parts
216741120138	ASSY PROP SHAFT-REAR(960 CLOSED-RSB)	TATA spare parts
216741120139	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
216741120141	LONG FORK SUB ASSY.	TATA spare parts
216741120143	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
216741120144	ASSY PROP. SHAFT-FRONT(1467 CLOSED)	TATA spare parts
216741120146	ASSY PROP SHAFT-INT AXLE (639-CLOSED)	TATA spare parts
216741120147	LONG FORK SUB ASSY	TATA spare parts
216741120148	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
216741120149	ASSY. PROP. SFT-INT-AXLE (669-CL)BS1/3/4	TATA spare parts
216741120150	LONG FORK SUB ASSY.	TATA spare parts
216741120151	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
216741120157	SLIP YOKE ASSY.	TATA spare parts
216741120167	PROPELLER SHAFT ASSY INTER AXLE	TATA spare parts
216741120170	LONG FORK SUB ASSY	TATA spare parts
216741120171	LONG FORK SUB ASSY	TATA spare parts
216741120173	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
216741120179	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
216741120181	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
216741120182	PROPELLER SHAFT ASSY INTERAXLE	TATA spare parts
216741120185	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
216741120186	PROPELLER SHAFT ASSY INTERAXLE	TATA spare parts
216741120187	PROPELLER DRIVE SHAFT ASSY	TATA spare parts
216741125101	FLANGE YOKE	TATA spare parts
216741125102	SHORT FORK	TATA spare parts
216741125103	LONG FORK	TATA spare parts
216741125104	REAR HOUSING	TATA spare parts
216741125105	FLANGE YOKE	TATA spare parts
216741125106	SHORT FROK	TATA spare parts
216741125107	LONG FROK	TATA spare parts
216741125108	REAR HOUSING	TATA spare parts
216741125109	FLANGE YOKE	TATA spare parts
216741125110	FLANGE YOKE	TATA spare parts
216741125112	FLANGE YOKE	TATA spare parts
216741129904	FLANGE YOKE	TATA spare parts
216741129913	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
216741990111	SHORT FORKTUBE & FRONT END PIECE ASSY	TATA spare parts
216741990112	SHORT FORK TUBE & REAR END PIECE	TATA spare parts
216741990113	SHORT FORK TUBE & REAR END PIECE	TATA spare parts

216741990117	LONG FORK ASSLY	TATA spare parts
216741990118	SHORT FORK TUBE AND REAR END PIECE	TATA spare parts
216742100137	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
216742100138	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
216742100139	DRUM BRAKE ASSY WITH DC_FRONT_LH	TATA spare parts
216742100140	DRUM BRAKE ASSY WITH DC_FRONT_RH	TATA spare parts
216742100144	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
216742100145	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
216742300115	ASSY DRUM BRAKE LH W/DC	TATA spare parts
216742300116	ASSY DRUM BRAKE RH W/DC	TATA spare parts
216742300117	ASSY DRUM BRAKE LH W/DC	TATA spare parts
216742300118	ASSY DRUM BRAKE RH W/DC	TATA spare parts
216742300156	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
216742300157	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
216742300158	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
216742300159	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
216743200102	ASSY.AIR TANK COMPLT.230STRAP C.D.(VOSS)	TATA spare parts
216743200107	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
216743207101	AIR TANK SUPPORT CHANNEL	TATA spare parts
216743208201	BASE PLATE (DUAL BRAKE VALVE)	TATA spare parts
216743900101	ASSY.NYLON PIPE SET COMPLETE (VOSS)	TATA spare parts
216743900102	ASSY.TUBE (15 O.D. X 2560 LG.)-HOSE TO I	TATA spare parts
216743900103	ASSY.TUBE (15 O.D. X 2625 LG.)-TO DDU IN	TATA spare parts
216743900104	ASSY.NYLON PIPE SET COMPLETE (VOSS)	TATA spare parts
216743900106	ASSY. NYLON PIPE SET COMPLETE (VOSS)	TATA spare parts
216743900107	ASSY.NYLON PIPE SET COMPLT.380 DIA CLUTH	TATA spare parts
216743900109	ASSY.COMPRESSOR 2ND PIPE DIA 18 X 2170LG	TATA spare parts
216743900110	ASSY.COMPRESSOR 3RD PIPE DIA 18 X 1610LG	TATA spare parts
216743900111	ASSY.COMPRESSOR 4TH PIPE DIA 18 X 1770LG	TATA spare parts
216743900112	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
216743900113	ASSY. COMPRESSOR 3RD PIPE	TATA spare parts
216743900116	ASSY.COMP.2ND PIPE	TATA spare parts
216743900117	ASSY.COMP.3RD PIPE	TATA spare parts
216743900118	ASSY.COMP.4TH PIPE	TATA spare parts
216743900119	ASSY.COMP.2ND PIPE	TATA spare parts
216743900120	ASSY.COMP.3RD PIPE	TATA spare parts
216743900121	ASSY.COMP.4TH PIPE	TATA spare parts
216743900122	ASSY.COMP.4TH PIPE	TATA spare parts
216743900123	ASSY.NYLON PIPE SET COMPLETE (VOSS)	TATA spare parts
216743900125	ASSY.COMP.2ND PIPE	TATA spare parts
216743900126	ASSY. NYLON PIPE SET COMPLETE	TATA spare parts
216743900127	ASSY.COMP. 1ST PIPE WITH ASSY.COMPRES	TATA spare parts
216743900128	ASSY. NYLON PIPE SET COMPLETE (VOSS)	TATA spare parts
216743900132	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
216743900133	ASSY. COMPRESSOR 3RD PIPE	TATA spare parts
216743900135	ASSY. NYLON PIPE SET COMPLETE	TATA spare parts
216743900137	ASSY. NYLON PIPE SET COMPLETE	TATA spare parts

216743900145	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
216743900148	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
216743900149	ASSY. NYLON PIPE SET COMPLETE	TATA spare parts
216743900150	ASSY. NYLON PIPE SET COMPLETE	TATA spare parts
216743900184	BUNCH ASSY PIPE	TATA spare parts
216743900186	BUNCH ASSY PIPE	TATA spare parts
216743900187	PIPE ASSY JOINT-3 TO DDU	TATA spare parts
216743910102	ASSY COMP INLET PIPE	TATA spare parts
216743910104	ASSY NYLON PIPE BUNCH COMPLETE	TATA spare parts
216744000116	TIPPING ASSY	TATA spare parts
216744000117	CYLINDER ASSY HYDRAULIC	TATA spare parts
216744100105	PUMP ASSYGEAR XPL SERIES/G750GB	TATA spare parts
216744100119	CYLINDER ASSY	TATA spare parts
216744100120	CYLINDER BODY FIXING ASSEMBLY	TATA spare parts
216744100125	MTG KIT HT-VALVE SAE INLET	TATA spare parts
216744103204	HEXAGONAL BOLT M16 X 55 X 1.5P BS6	TATA spare parts
216744103303	BRACKET CHASSIS	TATA spare parts
216744103305	CHASSIS BRACKET	TATA spare parts
216744105801	HOSE LP ID 90 LENGHT 1200 MM	TATA spare parts
216744105802	HOSE HP 2SN3/4IN LENGTH 1830 MM	TATA spare parts
216744105803	HOSE HP 2SN3/4 ID90IN LENGTH 1380 MM	TATA spare parts
216744105817	HP HOSE BS6	TATA spare parts
216744106502	NYLON INSERT LOCK NUT BS6	TATA spare parts
216744106902	TUBE PVC OD20XID15	TATA spare parts
216744108203	BRACKET AIR VALVE MTG BS6	TATA spare parts
216744109003	JOYSTICK AIR CONTROL VALVE WITHç PTO SWI	TATA spare parts
216744109203	WASHER BS6	TATA spare parts
216744109901	ADAPTER 1 IN	TATA spare parts
216744109902	ADAPTER M39X2 WITH O RINGS	TATA spare parts
216744109904	ADAPTER 1 IN BSPOTF SEAL 1 3/16 ORFS	TATA spare parts
216744109906	NYLON CABLE TIE ( 4.8X300 ) BS6	TATA spare parts
216744109908	GREASE NIPPLE BS6	TATA spare parts
216744109909	GREASE NIPPLE BS6	TATA spare parts
216744119901	O-RING	TATA spare parts
216744400102	HYDRAULIC TANK ASSY	TATA spare parts
216744400104	TANK BODY KIT BP W/O BAFFEL BS6	TATA spare parts
216744990101	KIT-HYDRAULIC TIPPING WITH PUMP /48WB	TATA spare parts
216744993201	ALLEN BOLT M8X80 BS6	TATA spare parts
216744996601	TIPPING CYLINDER BS2/3/4	TATA spare parts
216744997101	ALUMINIUM PLATE DCV BS6	TATA spare parts
216744997701	RUBBER STRAP	TATA spare parts
216744997702	METAL STRAP ASSEMBLY 30W X 2T	TATA spare parts
216744997705	RUBBER STRAP BS6	TATA spare parts
216744999002	AIR CONTROL VALVE	TATA spare parts
216744999003	SINGLE PIECE 2 EYE BALL	TATA spare parts
216744999005	BALL VALVE 1IN 1/2 BSP	TATA spare parts
216744999006	BALL VALVE 1INCH1/2 BSP	TATA spare parts

216744999007	BALL VALVE	TATA spare parts
216744999008	LINER SPOOL VALVE BS6	TATA spare parts
216744999906	PRESSURE ADAPTER KIT BS6	TATA spare parts
216744999908	GEAR PUMP ASSY BS6-PH2	TATA spare parts
216746150105	KIT ASSY PIPES(TAU NIPP)LPK2518TC/38	TATA spare parts
216746800114	ASSY RETURN LINE	TATA spare parts
216746800116	PRESSURE LINE ASSY	TATA spare parts
216746800118	PRESSURE LINE ASSY	TATA spare parts
216746800119	RETURN LINE ASSY	TATA spare parts
216746990104	KIT-PIPE & ADAPTER	TATA spare parts
216746990106	KIT-PIPE & ADAPTER	TATA spare parts
216747108202	BRACKET PRIMING PUMP MTG	TATA spare parts
216747600102	SUCTION LINE (FUEL TANK TO FUEL FILTER)	TATA spare parts
216747600103	SUCTION LINE (FUEL FILTER TO ENG)	TATA spare parts
216747600104	RETURN LINE ASSY ON TANK (ENG TO F/TANK)	TATA spare parts
216747600110	SUCTION LINE (FUEL TANK TO FUEL FILTER)	TATA spare parts
216747600111	SUCTION LINE (FUEL FILTER TO ENG)	TATA spare parts
216747600112	RETURN LINE ASSY ON TANK (ENG TO F/TANK)	TATA spare parts
216749200101	ASSY. EXHAUST PIPE (FRONT)	TATA spare parts
216749200106	ASSY. MUFFLER WITH TAIL PIPE BS2/3	TATA spare parts
216749200107	ASSY. EXHAUST PIPE(INTERMEDIATE)	TATA spare parts
216749200108	ASSY. EXHAUST PIPE-FRONT	TATA spare parts
216749200111	ASSY. EXHAUST PIPE(INTERMEDIATE)	TATA spare parts
216749200113	ASSY. BRACKET	TATA spare parts
216749200115	ASSY. BRACKET	TATA spare parts
216749200116	ASSY. MUFFLER WITH TAIL PIPE	TATA spare parts
216749200117	EXHAUST PIPE ASSY SECOND	TATA spare parts
216749203301	BRACKET (INTMEDIATE PIPE MTG.)	TATA spare parts
216749203303	BRACKET	TATA spare parts
216749203304	BRACKET	TATA spare parts
216754100106	ASSY. BATTERY CARRIER COMP. BS2/3/4	TATA spare parts
216754108207	SUPPORT PLATE FOR BATTERY CARRIER MOUNTI	TATA spare parts
216754108208	BATTERY TOP CLAMPING	TATA spare parts
216754200115	LEVEL GAUGE W/INDICATOR BS2/4	TATA spare parts
216754209902	INSTRUMENT CLUSTER 1:0.935 (24V)	TATA spare parts
216754209903	INSTRUMENT CLUSTER 1:0.935 (24V)	TATA spare parts
216754209904	INSTRUMENT CLUSTER 1:0.93	TATA spare parts
216754209909	TRIP E-SPEEDOMETER 24V (0.93)	TATA spare parts
216754209910	INST CLUST 24V E-SPD (0.93)	TATA spare parts
216754209911	INST CLUST 24V (0.93)	TATA spare parts
216754209912	RPM WITH DIGITAL HOUR METER 24V 552HZ	TATA spare parts
216754209913	TRIP SPEEDOMETER RATIO 0.93	TATA spare parts
216754209914	INSTRUMENT CLUSTER (0.93) INTERAXLE LOC	TATA spare parts
216754209915	INST CLSTR (0.93) INTERAXLE LOCK	TATA spare parts
216754209916	INSTRUMENT CLUSTR (1.04) 24V INTERAXLE	TATA spare parts
216754209917	INST CLUSTR (1.04) 24V INTERAXLE	TATA spare parts
216754209920	INST CLSTR 1:0.88 ESPD 24V TC LPK	TATA spare parts

216754209921	INST CLSTR 1:0.88 ESPD 24V TC LPK	TATA spare parts
216754209924	INST CLSTR(1:1.04) 24V LPK G1150	TATA spare parts
216754209925	INST CLSTR(1:1.04) 24V LPK G1150	TATA spare parts
216754209927	ELECTRONIC SPEEDOMETER 1:1.0- DIAL (0 -1	TATA spare parts
216754209928	INST CLSTR(1.0) 24V LPK G1150 11X20	TATA spare parts
216754209929	INST CLSTR(1:1.0) 24V LPK G1150 SRT(6.83	TATA spare parts
216754209930	INST CLSTR(1.0) 24V LPK G1150 SRT(6.83)	TATA spare parts
216754209939	INST.CLUSTER 1:2.07(24V)	TATA spare parts
216754209942	INST CLUSTER 24V 41/6 8070 PULSES/KM	TATA spare parts
216754209943	INST CLUSTER(1:2.07) LPK-2518 TC BS III	TATA spare parts
216754209948	ELECTRONIC INST.CLUSTER(8320PULSES/KM)LP	TATA spare parts
216754209949	INST.CLUSTER(1:1.04)LPK-2518 TC BS-III	TATA spare parts
216754209951	E-SPEEDOMETER(1:2.07)NON-CONTACT	TATA spare parts
216754209954	ELECT. INSTR. CLSTR 8070 552HZ	TATA spare parts
216754209955	ELECT. INSTR. CLSTR.7750PULSES 552HZ	TATA spare parts
216754209956	ELECT INST CLSTR 7260PULSES 0.9	TATA spare parts
216754209958	INSTRUMENT CLUSTER ASSY	TATA spare parts
216754209962	INSTRUMENT CLUSTER ASSY	TATA spare parts
216754600124	WIRING HARNESS MAIN BS3	TATA spare parts
216754600125	WIRING HARNESS MAIN BS3	TATA spare parts
216754600126	WIRING HARNESS RSL FRAME	TATA spare parts
216754600127	WIRING HARNESS RSL FRAME	TATA spare parts
216754601651	WIRING HARNESS TAIL	TATA spare parts
216754601653	WIRING HARNESS LOAD BODY BS6	TATA spare parts
216754610101	WIRING HARNESS ADD ON FEED PUMP	TATA spare parts
216754620103	W/H ROOF-NS CAB LPK2518/2516TC	TATA spare parts
216754620104	WIRING HARNESS TAIL LPK-2518TC/48 BSII	TATA spare parts
216754620106	WIRING HARNESS TAIL BSII 24V SRT	TATA spare parts
216754620107	W/H TAIL LPK2518TC/48 BSII 24V	TATA spare parts
216754620108	W/H TAIL LPK2518TC BSIII SRT G1150	TATA spare parts
216754620109	W/H TAIL LPK2518TC/38 BSII G1150	TATA spare parts
216754620110	W/H MAIN LPK1616/36 697-BSIII	TATA spare parts
216754620111	W/H ENGINE LPK1616/36 697 BSIII	TATA spare parts
216754620112	W/H TAIL LPK1616/36 697-BSIII	TATA spare parts
216754620114	W/H MAIN LPK-2518TC BSIII 24V WITH AIS	TATA spare parts
216754620116	W/H LPK-2518TC/38 BSIII 24V	TATA spare parts
216754620132	WIRE HARNESS TAIL	TATA spare parts
216754620133	W/H MAIN	TATA spare parts
216754620135	W/H TAIL	TATA spare parts
216754620136	WIRE HARNESS TAIL	TATA spare parts
216754620137	W/H TAIL	TATA spare parts
216754620140	W/H MAIN	TATA spare parts
216754620144	W/H TAIL	TATA spare parts
216754660102	W/H ROOF-NS CAB LPK TC	TATA spare parts
216754660109	WIRING HARNESS TAIL	TATA spare parts
216754660112	W/H ENGINE LPK1616/36 697 BSIII	TATA spare parts
216754660113	W/H TAIL LPK1616/36 697-BSIII	TATA spare parts



216754660115	W/H MAIN LPK-2518TC BSIII 24V WITH AIS 0	TATA spare parts
216754660121	W/H TAIL LPK-3118 TC/56 BS-III 24V WITH	TATA spare parts
216754660126	W/H MAIN LPK-2518 BSIII 24V ERGO PACK WI	TATA spare parts
216754660129	W/H TAIL LPK 2518 TC	TATA spare parts
216754660133	WIRE HARNESS TAIL	TATA spare parts
216754660134	WIRE HARNESS MAIN	TATA spare parts
216754660135	W/H TAIL	TATA spare parts
216754660137	WIRE HARNESS TAIL	TATA spare parts
216754660138	WIRING HARNESS TAIL	TATA spare parts
216754660143	W/H TAIL LPK2518	TATA spare parts
216754660144	WIRING HARNESS ENGINE BS3	TATA spare parts
216754660146	W/H TAIL	TATA spare parts
216754660155	W/H TAIL	TATA spare parts
216754660167	WIRING HARNESS¿TAIL	TATA spare parts
216783106301	FACE DUCT	TATA spare parts
216783400101	ASSY.FRONT AC UNIT	TATA spare parts
216783400102	ASSY. CONDENSER WITH FRAME	TATA spare parts
216783400104	ASSY. CONTROL PANEL	TATA spare parts
216783403301	AC UNIT MTG BKT LH	TATA spare parts
216783403302	AC UNIT MTG BKT RH	TATA spare parts
216783403303	AC UNIT MTG BKT CENTER	TATA spare parts
216783403304	AC HOSE CLAMP	TATA spare parts
216783403305	MTG BKT FOR AC PIPE	TATA spare parts
216783403307	AC HOSE MTG BKT	TATA spare parts
216783403315	MTG BKT FIREWALL	TATA spare parts
216783406901	ASSY. DISCHARGE PIPE	TATA spare parts
216783406902	ASSY SUCTION PIPE	TATA spare parts
216783406903	ASSY LIQUID PIPE	TATA spare parts
216783406904	ASSY LIQUID SUCTION PIPE DAROMA	TATA spare parts
216787000106	ASSY.TIPPING KIT(14 CUM/BOX)	TATA spare parts
216787000109	ASSY KIT COMPL-14CUM-BOX & HYD TIPPING	TATA spare parts
216787000116	ASSY KIT COMPL-14CUM-BOX (37TON TMLSUS)	TATA spare parts
216787000118	ASSY TIPPER LPK 2518/38WB	TATA spare parts
216787000119	ASSY KIT 14CUM BOX BODY LPK2518/38WB	TATA spare parts
216787000128	ASSY KIT LPK 2518/16 CUM	TATA spare parts
216787000136	TIPPER BODY ASSY WITH HYDRAULICS	TATA spare parts
216787000199	LOAD BODY ASSY BS6	TATA spare parts
216787010101	LOAD BODY BS6	TATA spare parts
216787010106	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
216787010110	LOAD BODY BS6	TATA spare parts
216787010121	LOAD BODY BS6	TATA spare parts
216787010122	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
216787010130	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
216787010131	LOAD BODY BS6	TATA spare parts
216787010138	MUDGUARD ASSY LH BS6	TATA spare parts
216787010143	MUDGUARD ASSY¿RH BS6	TATA spare parts
216787010184	LOAD BODY BS6	TATA spare parts

216787010197	MUDGUARD ASSY BS6	TATA spare parts
216787010198	MUDGUARD ASSY BS6	TATA spare parts
216787010199	MUDGUARD ASSY BS6	TATA spare parts
216787010219	TIPPER BODY ASSY WITH SUBFRAME BS6	TATA spare parts
216787020101	MUDGUARD ASSY BS6	TATA spare parts
216787100120	ASSY SUB-FRAME (TIPPER)	TATA spare parts
216787100122	ASSY.SUB FRAME	TATA spare parts
216787100127	ASSY SUB-FRAME (TIPPER)	TATA spare parts
216787100129	ASSY SUB-FRAME (TIPPER)	TATA spare parts
216787100132	SUBFRAME ASSY	TATA spare parts
216787100145	HINGE ASSY BS6	TATA spare parts
216787100146	SUBFRAME ASSY WITH MOUNTINGS	TATA spare parts
216787100172	SUBFRAME ASSY BS6	TATA spare parts
216787100173	CRADLE ASSY CYL MTG BS6	TATA spare parts
216787100179	SUBFRAME ASSY BS6	TATA spare parts
216787100187	BRACKET ASSY LH BS6	TATA spare parts
216787100188	BRACKET ASSY RH BS6	TATA spare parts
216787100193	SUBFRAME ASSY BS6	TATA spare parts
216787100210	SUBFRAME ASSY WITH MOUNTINGS BS6	TATA spare parts
216787100212	SUBFRAME ASSY WITH MOUNTINGS BS6	TATA spare parts
216787100214	SUBFRAME ASSY WITH MOUNTINGS BS6	TATA spare parts
216787100221	SUBFRAME ASSY BS6	TATA spare parts
216787100239	BOX ASSY TIPPER BODY BS6	TATA spare parts
216787100261	LOAD BODY BS6	TATA spare parts
216787100263	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
216787103404	BODY PROP BUSH	TATA spare parts
216787106704	PIN REAR HINGE BS6	TATA spare parts
216787107113	PLATE HINGE BS6	TATA spare parts
216787107601	BODY PROP HOLLOW SECTION	TATA spare parts
216787108290	STOPPER PLATE BS6	TATA spare parts
216787110136	SUBFRAME ASSY WITH MOUNTINGS BS6	TATA spare parts
216787118208	STOPPER PLATE BS6	TATA spare parts
216787300114	LOAD BODY WITHOUT HYDRAULIC KIT	TATA spare parts
216787300115	ASSY.TIPPING BODY COMPLETE	TATA spare parts
216787300116	ASSY.TIPPING BODY (37TON TMLSUS)	TATA spare parts
216787300117	ASSY.TIPPING BODY-20 CUM BOX	TATA spare parts
216787300126	ASSY.TIPPING BODY	TATA spare parts
216787300127	ASSY.TIPPING BODY-16 CUM BOX_HD	TATA spare parts
216787300129	ASSY.TIPPING BODY-16 CUM BOX	TATA spare parts
216787300140	TIPPER BODY ASSY	TATA spare parts
216787306903	PIPE BS6	TATA spare parts
216787400102	TAILDOOR ASSEMBLY - 16 BOX (LPK2518/48)	TATA spare parts
216787400103	TAILGATE ASSY	TATA spare parts
216787400106	TAILGATE ASSY BS6	TATA spare parts
216787400109	TAILGATE ASSY BS6	TATA spare parts
216787400123	TAILGATE ASSY BS6	TATA spare parts
216787406701	TAILDOOR HINGE PIN	TATA spare parts

216787406702	SPLIT PIN	TATA spare parts
216787406703	TAILDOOR HINGE PIN WASHER	TATA spare parts
216787406704	BODY PROP PIN	TATA spare parts
216787800107	CHAIN	TATA spare parts
216787800119	BODY MTG BS6	TATA spare parts
216787800126	RESILIENCE MTG ASSY BS6	TATA spare parts
216787800127	RESILIENCE MTG ASSY	TATA spare parts
216787803301	RESILIENCE MTG BS6	TATA spare parts
216787807105	PLATE BOTTOM CLAMP BS6	TATA spare parts
216787808218	ATTACHMENT PLATE 3 BS6	TATA spare parts
216787900118	LOCK SUPPORT TAILGATE	TATA spare parts
216787900125	FRAME ASSY BS6	TATA spare parts
216787907701	RAIN FLAP BS6	TATA spare parts
216787907702	RAIN FLAP BS6	TATA spare parts
216787907703	DUST COVER BS6	TATA spare parts
216787907705	RAIN FLAP REAR BS6	TATA spare parts
216787907706	RAIN FLAP REAR BS6	TATA spare parts
216787907709	MUDGUARD BS6	TATA spare parts
216787908225	MUDGUARD BS6	TATA spare parts
216787908228	RAIN FLAP LH BS6	TATA spare parts
216787908253	RAIN FLAP LH BS6	TATA spare parts
216787908254	RAIN FLAP RH BS6	TATA spare parts
216787908255	RAIN FLAP LH BS6	TATA spare parts
216787908256	RAIN FLAP RH BS6	TATA spare parts
216787908257	RAIN FLAP RH BS6	TATA spare parts
216787908259	RAIN FLAP LH BS6	TATA spare parts
216787908260	RAIN FLAP RH BS6	TATA spare parts
216787990107	ASSY KIT COMPL-20CUM-BOX & HYD TIPPING	TATA spare parts
216787990122	KIT-BOX TIPPER & HYD TIPPING	TATA spare parts
216787999908	CLAMP BS6	TATA spare parts
216787999909	CLAMP BS6	TATA spare parts
216820150101	ASSY FRAME FOR PULLEY MOUNTING	TATA spare parts
216820150102	ASSY SLIDER	TATA spare parts
216820150103	ASSY BEARING BLOCK COMPLETE FOR VISCUSS	TATA spare parts
216820155502	ADAPTOR-FIXED FAN MTG	TATA spare parts
216826800102	ASSY GEAR SHIFT LEVER-BUTT WELD	TATA spare parts
216829106001	CLUTCH RELEASE LEVER	TATA spare parts
216829300101	KIT ASSY. CLUTCH BOOSTER-DIA. 90	TATA spare parts
216829300102	ASSY CLUTCH BOOSTER	TATA spare parts
216829300103	ASSY FRT BKT.(FOR MTG BOOSTER ON CLUTCH)	TATA spare parts
216829300104	KIT ASSY. CLUTCH BOOSTER (DIA. 90).	TATA spare parts
216829306701	CLEVIS	TATA spare parts
216829306801	ADOPTER (M12X1.5)	TATA spare parts
216829306802	ADOPTER (M14X1.5)	TATA spare parts
216829307101	FRONT BRACKET	TATA spare parts
216829307102	REAR BRACKET	TATA spare parts
216829307103	REAR BRACKET.	TATA spare parts

216829308501	TEE	TATA spare parts
216829309001	ACTUATOR	TATA spare parts
216829500101	ASSY.CONTROL MTG.BKT.COMPOSITE	TATA spare parts
216830100101	ASSY PULL CABLE-ACCELERATOR	TATA spare parts
216830100102	ASSY PULL ROD	TATA spare parts
216830100110	BRACKET ACCELERATOR CABLE MOUNTING.	TATA spare parts
216830100111	CABLE ACCELERATOR	TATA spare parts
216830103301	BKT	TATA spare parts
216830103302	BRACKET	TATA spare parts
216830103303	BKT ON ENGINE	TATA spare parts
216830106001	LEVER ACCELARATOR	TATA spare parts
216830106002	LEVER	TATA spare parts
216830106701	PIVOT PIN	TATA spare parts
216830200101	ASSY PULL CABLE ENGINE STOP	TATA spare parts
216831000103	ASSY FRAME COMPLETE 1610TCW B 58 75_BSII	TATA spare parts
216831200104	ASSY.CROSS MEMBER (TUBULAR)	TATA spare parts
216831200105	ASSY CROSS MEMBER	TATA spare parts
216831207109	SPACER CROSS MEMBER	TATA spare parts
216831207115	SPACER (TUBULAR CROSS MEMBER)	TATA spare parts
216831207117	SUPPORT (CROSS MEMBER FRONT)	TATA spare parts
216831307106	REINFORCEMENT-RH(FRT-FRT SPRING MTG BRT)	TATA spare parts
216831307107	REINFORCEMENT-LH(FRT-FRT SPRING MTG BRT)	TATA spare parts
216831700102	ASSY. ENGINE SHIELD REAR	TATA spare parts
216831700103	ASSY. NOISE SHIELD (OIL SUMP)	TATA spare parts
216832300102	BRACKET (SHOCK ABSORBER MTG. & BUMP STOP	TATA spare parts
216832300103	BRACKET (SHOCK ABSORBER MTG. & BUMP STOP	TATA spare parts
216832403307	8TH CROSS MEMBER SUPPORT BKT - LH	TATA spare parts
216842900101	SET ASSY NYLON BRAKE PIPE COMPL 1610RE	TATA spare parts
216842900123	HOSE ASSY- (AIR DUCT TO COMPR)	TATA spare parts
216846100102	ASSY.BRACKET STG.GEAR BOX	TATA spare parts
216846800102	ASSY TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
216846800103	ASSY TUBE WITH CRIMP RUBBER HOSE	TATA spare parts
216847600101	ASSY.TUBE WITH CRIMPED R/HOSE. (OVERFLOW	TATA spare parts
216849200101	ASSY.EXHAUST PIPE	TATA spare parts
216849200102	ASSY BKT.(EX.PIPE MTG.)	TATA spare parts
216849200103	ASSY.BRACKET (EX.PIPE MTG.)	TATA spare parts
216849200104	ASSY.BRACKET (EXHAUST TAIL PIPE MTG.)	TATA spare parts
216849200105	ASSY EXHAUST PIPE	TATA spare parts
216849206903	EXHAUST INTERMEDIATE PIPE	TATA spare parts
216849208203	CLAMP	TATA spare parts
216849208207	CLAMP	TATA spare parts
216854100101	ASSY.BATT.CABLE +VE 70MMSQ 700 MM LG.	TATA spare parts
216854820101	W/H MAIN LPO1610;1612 RE BUS;ELEC.SPEEO	TATA spare parts
216854820102	W/H TAIL LPO1610;1612 RE BUS ELECTR.SPEO	TATA spare parts
216924200101	ASSY.BKT.LH.(ENGINE MTG.TOP)	TATA spare parts
216924200102	ASSY.BKT.RH.(ENGINE MTG.TOP)	TATA spare parts
216924200103	CLUTCH BOOSTER MTG. BKT.	TATA spare parts

216929100104	ASSY. PIPE (M/CYL TO CLUTCH BOOSTER)	TATA spare parts
216929106001	PUSH ROD	TATA spare parts
216931000102	ASSY FRAME COMPLETE(LPO WEVELLER/60%ROH	TATA spare parts
216932403308	8TH CROSS MEMBER SUPPORT BKT - RH	TATA spare parts
216941100104	ASSY.PROP.SHAFT W/C.B.(FRONT)-1867	TATA spare parts
216941100106	ASSY.PROP.SHAFT W/C B MIDDLE-1126	TATA spare parts
216941120102	ASSY PROP SHAFT COMP REAR-1710	TATA spare parts
216943900102	SET ASSY NYL PIPE COMP	TATA spare parts
216943900104	SET ASSY NYL PIPE COMP	TATA spare parts
216949100101	ASSY. SILENCER WITH TAIL PIPE	TATA spare parts
216954209901	INSTRUMENT CLUSTER (1:0.80)	TATA spare parts
216954209904	INSTRUMENT CLUSTER (1:0.80)	TATA spare parts
216954209906	INSTRUMENT CLUSTER (0.80)-E-SPD	TATA spare parts
216954209910	INSTRUMENT CLUSTER (1:0.80) E-SPD	TATA spare parts
216954209911	INSTRUMENT CLUSTER (1:0.80) E-SPD	TATA spare parts
216954408201	MOUNTING BRACKET - AMMETER	TATA spare parts
216954620101	W/H MAIN LPO-1510TC INT F/B I/CLTR	TATA spare parts
217010080002	SKIRT PANEL COMPL. (DRV. STEP)	TATA spare parts
217010120002	SKIRT PANEL COMPL.	TATA spare parts
217010140003	SKIRT PANEL COMPL.	TATA spare parts
217010140007	SKIRT PANEL COMPL. /FT	TATA spare parts
217010150003	SKIRT PANEL COMPL.	TATA spare parts
217010170007	SKIRT PANEL COMPLETE L=660	TATA spare parts
217010180002	SKIRT PANEL COMPL.	TATA spare parts
217010580001	PANEL (DRIVER. STEP)	TATA spare parts
217010590001	BATTERY BOX FLAP	TATA spare parts
217010600001	BATTERY BOX FLAP	TATA spare parts
217010610001	SPARE TYRE FLAP	TATA spare parts
217010690001	SKIRT PANEL COMPLETE L=2350	TATA spare parts
217010710001	SKIRT PANEL COMPLETE L=1289	TATA spare parts
217010720001	SKIRT PANEL COMPLETE L=1357	TATA spare parts
217010740001	SKIRT PANEL COMPL./FT	TATA spare parts
217010750001	SKIRT PANEL COMPL.	TATA spare parts
217010760002	SKIRT PANEL COMPL.	TATA spare parts
217010770001	SKIRT PANEL COMPL.	TATA spare parts
217010890003	SKIRT PANEL COMPL.	TATA spare parts
217010930002	SKIRT PANEL COMPL/ BATTERY FLAP	TATA spare parts
217011080001	SKIRT PANEL COMPL.	TATA spare parts
217011090001	FLAP ASSEMBLY	TATA spare parts
217011580001	SKIRT PANEL COMPL/ BATTERY FLAP	TATA spare parts
217011580003	BATTERY BOX FLAP L=380	TATA spare parts
217012240001	SKIRT PANEL COMPL.(F.T)	TATA spare parts
217012240002	SKIRT PANEL COMPL.	TATA spare parts
217012240003	SKIRT PANEL COMPL.	TATA spare parts
217012240004	SKIRT PANEL COMPL.	TATA spare parts
217012240005	SKIRT PANEL COMPL.	TATA spare parts
217012250001	BATTERY BOX FLAP	TATA spare parts

217020950001	SKIRT PANEL COMPL.	TATA spare parts
217021280004	ROLLED C SEC.	TATA spare parts
217021300001	WHEEL ARCH PANEL REAR	TATA spare parts
217021310001	WHEEL ARCH PANEL/ FRONT LH	TATA spare parts
217021310002	WHEEL ARCH PANEL/ FRONT LH	TATA spare parts
217021320001	WHEEL ARCH PANEL/ FRONT RH	TATA spare parts
217021340001	WHEEL ARCH PANEL/ FRONT LH	TATA spare parts
217032407603	COMPOUND LINK	TATA spare parts
217040380001	SKIRT PANEL COMPLETE	TATA spare parts
217040390001	SKIRT PANEL COMPLETE	TATA spare parts
217040400001	SKIRT PANEL COMPLETE	TATA spare parts
217040410001	SKIRT PANEL COMPLETE	TATA spare parts
217040420001	SKIRT PANEL COMPLETE	TATA spare parts
217040430001	SKIRT PANEL COMPLETE	TATA spare parts
217040440001	SKIRT PANEL COMPLETE	TATA spare parts
217040450001	SKIRT PANEL COMPLETE	TATA spare parts
217040460001	SKIRT PANEL COMPLETE	TATA spare parts
217040470001	SKIRT PANEL COMPLETE	TATA spare parts
217040480001	SKIRT PANEL COMPLETE	TATA spare parts
217040490001	SKIRT PANEL COMPLETE	TATA spare parts
217040500001	SKIRT PANEL COMPLETE	TATA spare parts
217040540001	TAPER PANEL	TATA spare parts
217100990101	KIT FULLY TRIMMED CAB FOR PRIMA 2516.K	TATA spare parts
217124100101	ASSY. BRACKET-R.H (ENG. MTG. FRONT)	TATA spare parts
217124100102	ASSY. BRACKET-L.H (ENG. MTG. FRONT)	TATA spare parts
217126800102	ASSY TURNING TUBE W/BALL JOINT	TATA spare parts
217126800113	ASSY BRACKRT(G.S LEVER)	TATA spare parts
217126800120	ASSY.BRACKET (G.S.LEVER MTG.)	TATA spare parts
217126800122	ASSY.TURNING TUBE W/BUSH	TATA spare parts
217126800126	ASSY.TURNING TUBE (G/SHIFT LINKAGE)	TATA spare parts
217126800137	ASSY BRACKET(GEAR SHIFT LEVER MTG)	TATA spare parts
217126800138	ASSY TURNING TUBE(WITHOUT BALL JOINT)	TATA spare parts
217126805101	HOUSING BLOCK(G.S.LEVER)	TATA spare parts
217126990101	RETRO KIT PTO & APP MK-III-LPK 2516 LHD	TATA spare parts
217129100101	ASSY.REFILLING CONTAINER COMPLETE	TATA spare parts
217129500102	ASSY.CTRL.MTG.BKT.WITH CYL.MTG.BKT.LH	TATA spare parts
217129990101	ASSY. RETRO KIT FOR CLUTCH ACTUATION SYS	TATA spare parts
217130100101	ASSY BRACKET(ACCL. LEVER MTG)	TATA spare parts
217130100102	ASSY LEVER (WITH BALL PIN)	TATA spare parts
217130100103	ASSY CONTROL SHAFT	TATA spare parts
217130100105	ASSY. BOTOM LEVER ACCL	TATA spare parts
217131000101	ASSY FRAME LPK 2516/38 MODIFIED	TATA spare parts
217131000105	CHASSIS FRAME LPK 2516TC	TATA spare parts
217131000106	ASSY FRAME COMPLETE-WITH SINGLE REINF.	TATA spare parts
217131000113	ASSY FRAME COMPLETE (LPK2516TC BS-I)	TATA spare parts
217131200111	ASSY SUPPORT 3RD X-MEMBER	TATA spare parts
217131200112	ASSY SUPPORT 2ND X-MEMBER	TATA spare parts

217131200113	ASSY. 4TH X-MEMBER(BRIZE)WITH GUSSET	TATA spare parts
217131200114	ASSY.5TH X-MEMBER(BRIZE) WITH GUSSET	TATA spare parts
217131200121	ASSY. 6TH CROSS-MEMBER WITH SUPPORT	TATA spare parts
217131200122	ASSY. 7TH CROSS-MEMBER WITH SUPPORT	TATA spare parts
217131200124	ASSY. GUSSET-RH (L. M. EXTENSION)	TATA spare parts
217131200125	ASSY. GUSSET-LH L.M.	TATA spare parts
217131207109	X-MEMBER (C-SECTION)	TATA spare parts
217131207110	X-MEMBER (BRIDGE)	TATA spare parts
217131207111	SUPPORT - (DOUBLE X-MBR)	TATA spare parts
217131207112	SUPPORT - RH (4TH X-MBR)	TATA spare parts
217131207113	END X-MEMBER	TATA spare parts
217131207114	SUPPORT - (END X-MEMBER)	TATA spare parts
21713120711435	SUPPORT - (END X-MEMBER)_UNPAINTED	TATA spare parts
217131207115	SUPPORT - (REAR SPR-FRONT)	TATA spare parts
217131207116	SUPPORT - RH (REAR SPR-REAR)	TATA spare parts
217131207117	SUPPORT - LH (REAR SPR-REAR)	TATA spare parts
217131207118	SUPPORT - LH (4TH X-MBR)	TATA spare parts
217131207119	REINFORCEMENT (ANTIROLE BAR MTG.AT L.M)	TATA spare parts
217131207122	STIFFENER (AT ENG. C.M FRONT)	TATA spare parts
217131207123	STIFFENER (AT ENG. C.M REAR)	TATA spare parts
217131207132	SUPPORT (DBLE X-MEMBER)-LH	TATA spare parts
217131300102	ASSY. 8TH CROSS MEMBER	TATA spare parts
217131307111	GUSSET-R.H	TATA spare parts
217131307112	GUSSET-L.H	TATA spare parts
217131307125	REINFORCEMENT-RH (FRONT SPR BKT)	TATA spare parts
217131307126	REINFORCEMENT-LH (FRONT SPR BKT)	TATA spare parts
217131308201	SPACER PLATE - FRONT SPR BKT REAR	TATA spare parts
217131308203	GUSSET TOP RH (BUMPER CROSS MEMBER)	TATA spare parts
217131308204	GUSSET TOP LH (BUMPER CROSS MEMBER)	TATA spare parts
217131308205	GUSSET TOP-RH BUMPER CROSS MEMBER	TATA spare parts
217131308206	GUSSET TOP-LH BUMPER CROSS MEMBER	TATA spare parts
217131700101	ASSY ENG SHIELD-BOTTOM.LPK 2516 BS-2	TATA spare parts
217131700102	ASSY MTG. BRACKET(FOR ENG BOTTOM SHIELD)	TATA spare parts
217131700103	ASSY G/BOX SHIELD-TOP LPK 2516 BS-2	TATA spare parts
217131700104	ASSY G/BOX SHIELD-BOTTOM.LPK 2516 BS-2	TATA spare parts
217131700105	ASSY KIT FOR N/SHIELD(LPK 2516 TC/N/LOW)	TATA spare parts
217131700106	ASSY. NOISE SHIELD -CAB END	TATA spare parts
217131700107	ASSY ENG SHIELD - BOTTOM	TATA spare parts
217131700108	ASSY.G/BOX SHIELD-BOTTOM	TATA spare parts
217131703201	THREADED PIN	TATA spare parts
217131708203	BRACKET(ENG SHIELD BOTTOM)	TATA spare parts
217131708204	MOUNTING BRACKET L.H(G/BOX NOISE SHIELD)	TATA spare parts
217131708205	MOUNTING BRACKET R.H(G/BOX NOISE SHIELD)	TATA spare parts
217131708206	BRACKET(G/BOX NOISE SHIELD)	TATA spare parts
217131709101	HARDENED WASHER BS6	TATA spare parts
217132100104	ASSY.BRACKET AXLE STOPPER-LH	TATA spare parts
217132100105	ASSY.BRACKET AXLE STOPPER-RH	TATA spare parts

217132100106	ASSY SPRING SHACKLE FRONT SPRING	TATA spare parts
217132100107	ASSY AXLE STOPPER MTG BKT-LH	TATA spare parts
217132100108	ASSY AXLE STOPPER MTG BKT-RH	TATA spare parts
217132400101	ASSY. REAR SPRING BS2/3/4/6	TATA spare parts
217132400102	ASSY FIRST LEAF WITH BUSH	TATA spare parts
217132400104	ASSY REAR SPRING	TATA spare parts
217132400106	ASSY. FIRST LEAF W/BUSHES BS1/2/3	TATA spare parts
217132400108	1ST LEAF ASSY WITH BUSH	TATA spare parts
217132403201	CENTRE BOLT	TATA spare parts
217132403301	SPRING BRACKET-REAR	TATA spare parts
217132403304	SPRING BRACKET CENTRE BS1/2/3/4	TATA spare parts
217132403309	LINK CHANNEL MTG BKT	TATA spare parts
217132404204	SPRING CLIP	TATA spare parts
217132404205	SPRING CLIP	TATA spare parts
217132404212	SPRING CLIP REAR SPRING	TATA spare parts
217132407101	REBOUND LEAF	TATA spare parts
217132407102DF	MAIN LEAF REAR W/BUSH - TATA2515EX/2416	TATA spare parts
217132407103	SECOND LEAF	TATA spare parts
217132407103DF	SECOND LEAF REAR - TATA2515EX/2416	TATA spare parts
217132407104	THIRD LEAF	TATA spare parts
217132407104DF	THIRD LEAF REAR - TATA2515EX/2416	TATA spare parts
217132407105	FOURTH LEAF	TATA spare parts
217132407105DF	FOURTH LEAF REAR - TATA2515EX/2416	TATA spare parts
217132407106	LEAF NO 5	TATA spare parts
217132407107	LEAF NO 6	TATA spare parts
217132407108	LEAF NO 7	TATA spare parts
217132407109	LEAF NO 8	TATA spare parts
217132407110	LEAF NO 9	TATA spare parts
217132407111	LEAF NO 10	TATA spare parts
217132407112	LEAF NO 11	TATA spare parts
217132407113	LEAF NO 12	TATA spare parts
217132407114	1STLEAF BS6	TATA spare parts
217132407115	2ND LEAF	TATA spare parts
217132407119	FIFTH LEAF	TATA spare parts
217132407119DF	FIFTH LEAF REAR - TATA2515EX/2416	TATA spare parts
217132407120	SIXTH LEAF	TATA spare parts
217132407121	SEVENTH LEAF	TATA spare parts
217132407122	EIGHTH LEAF	TATA spare parts
217132407123	NINTH LEAF	TATA spare parts
217132407124	TENTH LEAF	TATA spare parts
217132407125	ELEVENTH LEAF	TATA spare parts
217132407125DF	ELEVENTH LEAF REAR - TATA2525EX/2416	TATA spare parts
217132407126	PACKING PLATE	TATA spare parts
217132504201	U CLAMP	TATA spare parts
217132508602	SPACER-U CLAMP	TATA spare parts
217132800102	ASSY ANTI ROLL BAR WITH EYE PIECE COMPL(	TATA spare parts
217133000101	ASSY.FR.AXLE COMPL.WITH BRAKES-SPIGOTTED	TATA spare parts



217133000102	ASSY. FRONT AXE COMPLETE WITH BRAKE-LHD	TATA spare parts
217135000101	ASSY TANDEM AXL-6.83 RATIO/1044SP	TATA spare parts
217140300101	HOLDINGBRACKETASSY BS6	TATA spare parts
217140300102	BRACKETASSY BS6	TATA spare parts
217140300103	ASSY SPARE WHEEL CARRIER	TATA spare parts
217140309101	HARDENED WASHER BS6	TATA spare parts
217141000104	STRAP BOLT KIT	TATA spare parts
217141000105	STRAP BOLT KIT	TATA spare parts
217141000107	KIT-UNIVERSAL JOINT BS1/2/3/4	TATA spare parts
217141000107DF	UJ CROSS 41.28 X 126	TATA spare parts
217141108201	PROP. SHAFT GUARD	TATA spare parts
217141114201	BEARING STRAP	TATA spare parts
217141120101	ASSY. PROP. SHAFT COMPLETE (REAR)L=132	TATA spare parts
217141120102	ASSY PROP SHAFT	TATA spare parts
217141120105	ASSY. BOOT	TATA spare parts
217141120107	ASSY PROPELLER SHAFT L1520	TATA spare parts
217141120108	PROPELLER SHAFT LPK 2516 6X4	TATA spare parts
217141120110	SLIP YOKE ASSY.	TATA spare parts
217141120112	SLIP YOKE ASSY.	TATA spare parts
217141120113	ASSY. PROP SHAFT COMPLETE -MAIN(1495)	TATA spare parts
217141120122	ASSY. PROP SHAFT COMPLETE -MAIN(1403)	TATA spare parts
217141120126	ASSY.PROP.SHAFT COMPLT-MAIN(1495)	TATA spare parts
217141120127	ASSY. CROSS BS1/2	TATA spare parts
217141120128	DUST COVER ASSY.	TATA spare parts
217141120129	ASSY.PROP SHAFT COMPLETE-MAIN(1403)	TATA spare parts
217141120130	ASSY. PROP.SHAFT COMPLETE-MAIN(1435)	TATA spare parts
217141120131	CROSS ASSY	TATA spare parts
217141120133	LONG FORK SUB ASSY	TATA spare parts
217141120134	ASSY.PROP.SHAFT INTER AXLE(760CLOSED)	TATA spare parts
217141120135	CROSS ASSY	TATA spare parts
217141120136	REAR HOUSING TUBE & SHORT FORK SUB ASSY	TATA spare parts
217141120137	LONG FORK SUB ASSY INTER AXLE	TATA spare parts
217141125101	END PIECE-PROP. SHAFT REAR	TATA spare parts
217141125102	FLANGE YOKE-INTER AXLE PROP. SHAFT	TATA spare parts
217141125104	FLANGE YOKE	TATA spare parts
217141125105	SHORT FORK	TATA spare parts
217141125106	REAR HOUSING	TATA spare parts
217141125107	LONG FORK	TATA spare parts
217141125108	FLANGE YOKE	TATA spare parts
217141125109	FLANGE YOKE INTER AXLE SHAFT	TATA spare parts
217142107101	BRACKET	TATA spare parts
217142900102	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
217142900104	ASSY TUBE(15 O.D. X 2300 LG)	TATA spare parts
217142900105	ASSY TUBE (15 O.D. X 3190 LG)LPK2516	TATA spare parts
217143200101	ASSY. BRACKET-R.H(A/TANK MTG.) .	TATA spare parts
217143200102	ASSY. BRACKET-L.H(A/TANK MTG.)	TATA spare parts
217143200115	ASSY BRACKET(HAND BRAKE VALAVE MTG)	TATA spare parts

217143200116	ASSY.BRACKET FOR HBV ISO VALVE PTO ETC	TATA spare parts
217143200120	ASSY.AIR TANK COMPLETE(VOSS)K.B.	TATA spare parts
217143208202	BASE PLATE (FOOT BRAKE VALVE)	TATA spare parts
217143700101	ASSY. BRACKET FOR HBV	TATA spare parts
217143700103	BRACKET ( AIR DRYER )	TATA spare parts
217143900146	ASSY TUBE(15 O.D. X 2450 LG)	TATA spare parts
217143900192	SET ASSY.NYLON PIPE COMP.	TATA spare parts
217143903301	BRACKET (FOR RA 109 AXLE)	TATA spare parts
217143906802	SOCKET (FOR M16X1.5 TO M14X1.5)	TATA spare parts
217143906805	SOCKET (FOR M12X1.5 TO M14X1.5)	TATA spare parts
217143906806	SOCKET (FOR M14X1.5 TO M14X1.5)	TATA spare parts
217143907501	RUBBER GROMMET	TATA spare parts
217143910138	SET ASSY.NYLON PIPE COMPLETE	TATA spare parts
217143910183	ASSY.TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
217143910184	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
217143910186	ASSY. TUBE (15 O.D. X 1850 LG.)	TATA spare parts
217143910188	ASSY.NYLON PIPE SET COMPLETE (VOSS)	TATA spare parts
217143910189	ASSY.NYLON PIPE SET COMPLETE(VOSS)LHD	TATA spare parts
217143910190	3/8INHOSE ASSY.WITH 'O'RING NIPPLE 615LG	TATA spare parts
217143910191	ASSY. COMPRESSOR 1ST PIPE WITH HOSE	TATA spare parts
217143910192	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
217143910193	ASSY. COMPRESSOR 3RD PIPE	TATA spare parts
217143910194	ASSY. HOSE 3/8 W/ O RING NIPPLE BS1-4	TATA spare parts
217143910195	ASSY.ADAPTOR(COMP OUTLET PORT)	TATA spare parts
217143910196	ASSY. COMPRESSOR 1ST PIPE WITH HOSE	TATA spare parts
217143910197	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
217143910198	ASSY. COMPRESSOR 3RD PIPE	TATA spare parts
217143910199	ASSY. NYLON PIPE SET COMPLETE	TATA spare parts
217144100104	PNEUMATIC PTO SHIFT CYLINDER	TATA spare parts
217144100105	TANK RUBBER MOUNTING KIT	TATA spare parts
217144100106	PACKSET(COMPLETE) FOR CYL	TATA spare parts
217144100108	CYLINDER	TATA spare parts
217144100109	PISTON WITH EYE	TATA spare parts
217144100110	HYD. TAIL GATE CYL.	TATA spare parts
217144100113	ASSY.HYD.CYLINDER	TATA spare parts
217144103201	ALLEN KEY BOLT M8 X 80	TATA spare parts
217144103202	CYLINDER MOUNTING BOLT M16 X 50	TATA spare parts
217144103301	CYLINDER MOUNTING BRACKET	TATA spare parts
217144103401	INNER BUSH - CYLINDER MOUNTING BRACKET	TATA spare parts
217144103402	INNER BUSH - CYLINDER MOUNTING BRACKET	TATA spare parts
217144103701	BREATHER FLANGE	TATA spare parts
217144104201	PVC HOSE CLAMP	TATA spare parts
217144105801	PVC FLEXIBLE TUBE	TATA spare parts
217144105802	FLEXIBLE TUBE PVC 20MM- PER MTR	TATA spare parts
217144105803	HOSE 1/4 INCH X 700 MM L TG CYL.	TATA spare parts
217144105804	HOSE 1/4 INCH X 325 MM L TG CYL.	TATA spare parts
217144106501	NYLOC NUT M12 X 1.25 P	TATA spare parts

217144106701	CYLINDER MOUNTING PIN	TATA spare parts
217144106702	COTTER PIN - CYLINDER MOUNTING	TATA spare parts
217144106703	HINGE PIN-TAILDOOR CYLINDER EYE	TATA spare parts
217144106801	ADAPTOR 1 1/2INCH BSP MALE X1-7/6INCH UN	TATA spare parts
217144106802	ADAPTOR 1/8INCH X 1/8INCH	TATA spare parts
217144106803	ADAPTOR 3/4INCH BSP MALE X M 30 X 2	TATA spare parts
217144106804	ADAPTOR 3/4INCH BSP MX 1-3/16INCH UNF OR	TATA spare parts
217144106805	ADAPTOR M26X1-1/2INCHX1-3/16INCH UNF ORS	TATA spare parts
217144106901	BASE TUBE	TATA spare parts
217144106902	STAGE	TATA spare parts
217144106903	STAGE	TATA spare parts
217144107101	AIR CONTROL VALVE MOUNTING PLATE	TATA spare parts
217144107102	LOCKING PLATE FOR CYL	TATA spare parts
217144107701	SLIDER DIA 141	TATA spare parts
217144107702	SNAP RING DIA 141	TATA spare parts
217144107703	O RING BASE DIA 141	TATA spare parts
217144107704	DOWTY SEAL 1/4INCH	TATA spare parts
217144107705	O RING 18.77 X 1.78	TATA spare parts
217144107706	O RING 23.52 X 1.78	TATA spare parts
217144108001	GRUB SCREW	TATA spare parts
217144108601	CYLINDER EYE SPACER	TATA spare parts
217144109001	VALVE BLOCK MOUNTING O RING	TATA spare parts
217144109201	WASHER FOR CYLINDER MOUNTING PIN	TATA spare parts
217144109202	COPPER WASHER 1/8INCH	TATA spare parts
217144109203	PLAIN WASHER M6	TATA spare parts
217144109204	M.S. PLAIN WASHER M12	TATA spare parts
217144109901	SPHERICAL EYE DIA 50.8	TATA spare parts
217144109902	GREASE NIPPLE - 45 DEGREE	TATA spare parts
217146000108	HYD. TANK ASSY. (P/STG. SYSTEM)	TATA spare parts
217146100101	ASSY STRG GEAR BOX MTG. BRACKET	TATA spare parts
217146100102	ASSY. STG. GEAR BOX & MTG.BKT(RH)BS2/3/4	TATA spare parts
217146100103	ASSY STEERING COLUMN SUPPORT-LHD	TATA spare parts
217146150102	KIT ASSY.PIPES(TAR NIPP)LPK2516TC LHD	TATA spare parts
217146150104	KIT ASSY. PIPES-LPK2516	TATA spare parts
217146800101	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
217146800102	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
217146800103	RETURN LINE HOSE ASSY STRG GBOX TO TANK	TATA spare parts
217146800104	SUCTION LINE HOSE ASSY HYD TANK TO STRG	TATA spare parts
217146800105	PR.LINE HOSE ASSY STRG PUMP TO STRG GBOX	TATA spare parts
217146800106	PR.LINE HOSE ASSY STRG PUMP TO STRG GBOX	TATA spare parts
217146800109	SUCTION LINE HOSE ASSY	TATA spare parts
217146800110	PRESSURE LINE HOSE ASSY	TATA spare parts
217146800111	RETURN LINE HOSE ASSY	TATA spare parts
217146800114	SUCTION LINE HOSE ASSEMBLY	TATA spare parts
217146800116	LPK 2516 RETUN LINE	TATA spare parts
217146800117	PRESSURE LINE HOSE ASSEMBLY	TATA spare parts
217146800118	SUCTION LINE HOSE ASSEMBLY	TATA spare parts

217146800124	SUCTION LINE HOSE ASSEMBLY	TATA spare parts
217146800125	RETURN LINE HOSE ASSEMBLY	TATA spare parts
217146800126	PRESSURE LINE HOSE ASSY.	TATA spare parts
217146807503	RUBBER GROMMET	TATA spare parts
217146807504	RUBBER GROMMET	TATA spare parts
217147500103	ASSY. SUPPORT WITH SPACER	TATA spare parts
217147500104	ASSY. SUPPORT WITH SPACER	TATA spare parts
217147600101	ASSY.TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
217147600104	ASSY TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
217147600105	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
217147600107	ASSY.TUBE WITH CRIMPED R/HOSE RETURNPIPE	TATA spare parts
217147600108	ASSY.TUBE WITH CRIMPED R/HOSE RETURNPIPE	TATA spare parts
217147603301	L-BRACKET	TATA spare parts
217149100101	ASSY.SILENCER WITH TAIL PIPE	TATA spare parts
217149100103	ASSY. MUFFELER WITH TAIL(LPK2516/38	TATA spare parts
217149200101	ASSY. EXHAUST PIPE	TATA spare parts
217149200103	ASSY.EXHAUST PIPE-INTERMEDIATE	TATA spare parts
217149200104	ASSY. EXHAUST PIPE-FRONT	TATA spare parts
217149200109	ASSY EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
217149203303	BRACKET (INTMEDIATE PIPE MTG.)	TATA spare parts
217149203304	BRACKET	TATA spare parts
217149204201	CLAMP (MUFFLER SUPPORT)	TATA spare parts
217149206907	TAIL PIPE(EXHAUST)	TATA spare parts
217149208201	CLAMP	TATA spare parts
217149208202	CLAMP	TATA spare parts
217154100101	ASSY BATT CABLE (LINK)LG 200 - 50SQMM BS	TATA spare parts
217154209901	INSTRUMENT CLUSTER 1:1.04	TATA spare parts
217154209902	INSTRUMENT CLUSTER 1:1.04	TATA spare parts
217154209912	INSTR CLSTR (0.9)LPT1615TC 12V BSI	TATA spare parts
217154209915	INST CLSTR(1.04)LPK1615TC LHD 12V	TATA spare parts
217154209916	INSTR CLSTR (0.9)LPK1615TC 12V BSI	TATA spare parts
217154209917	INSTR CLSTR (0.9) LPK1615TC 12V BSI	TATA spare parts
217154209918	MECH SPEEDOMETER (0.90)	TATA spare parts
217154209919	INST CLUST 24V E-SPD (1.04)	TATA spare parts
217154209922	INST CLUST 24V E-SPD (1.04)	TATA spare parts
217154209930	INST CLST E-SPD(0.90)1615TC ARMY	TATA spare parts
217154209931	TRIP E-SPEEDOMETER RATIO (0.90) -IIL	TATA spare parts
217154209935	INSTR CLSTR(1.04) E-SPD 12V	TATA spare parts
217154209937	INST CLST E-SPD(0.90)552HZ ARMY	TATA spare parts
217154209943	INST CLST E-SPD(0.90)552HZ LPT1615/TC BS	TATA spare parts
217154209945	INST CLUSTER(1:0.88)LPT-1615 TC BS-I	TATA spare parts
217154400101	ASSY.ROUND H/L WITH PIG TAIL 24V	TATA spare parts
217154600101	W/H PIGTAIL ALTERNATOR	TATA spare parts
217154620103	W/H MAIN LPK2516TC 24V BSII	TATA spare parts
217154620105	W/H TAIL LPK2516TC BSII	TATA spare parts
217154620108	WIRING HARNESS TAIL	TATA spare parts
217154620111	W/H MAIN	TATA spare parts

217154620112	W/H TAIL	TATA spare parts
217154660102	W/H TAIL LPK-2516/38 TC	TATA spare parts
217154660103	W/H MAIN-LPK-2516TC 24V	TATA spare parts
217154660109	W/H-ENGINE LPK2516TC 24V TILT CAB	TATA spare parts
217154660110	W/H TAIL LPK2516TC/38 LHD 24V BSII	TATA spare parts
217154660114	W/H-ENGINE LPK2523TC	TATA spare parts
217154660122	W/H TAIL	TATA spare parts
217154660125	W/H TAIL	TATA spare parts
217154820101	W/H MAIN LPK2516TC-12V-M.H/L EI&II	TATA spare parts
217154820104	W/H MAIN LPK2516TC-24V-M.H/L EI&II	TATA spare parts
217154820105	W/H TAIL- W.B-38	TATA spare parts
217154820107	W/H MAIN-E-I & II-LPS 3516TC-12V	TATA spare parts
217154820108	W/H MAIN LPK-2516TC BS-II 12V I/C-	TATA spare parts
217154820109	W/H MAIN LPK-2516TC BS-II 24V	TATA spare parts
217154820110	W/H MAIN LPK2516TC E-II AC 12V I/C	TATA spare parts
217154820111	W/H MAIN LPK2516TC	TATA spare parts
217154820115	W/H MAIN LPK1615TC LHD BS-I INST CLSTR	TATA spare parts
217154820117	W/H MAIN LPK1615TC BS-I RHD INST CLSTR	TATA spare parts
217187000106	ASSY KIT COMPL-14CM/BODY & HYD TIPPING)	TATA spare parts
217187000116	TIPPER BODY ASSY WITH MTG DETAILS	TATA spare parts
217187000117	TIPPER BODY ASSY WITH MTG DETAILS	TATA spare parts
217187100103	HY FIX LOCKING BAR MOUNTING KIT	TATA spare parts
217187100104	HYFIX BODY CLAMP ASSY	TATA spare parts
217187100105	HAMMER ASSY	TATA spare parts
217187100106	CYLINDER MOUNTING CRADLE ASSY	TATA spare parts
217187100107	2ND AXLE MUDGUARD ASSY	TATA spare parts
217187100108	BEARING ASSY - TAIL GATE LOCK MECHANISM	TATA spare parts
217187100110	ASSY. STRUCTURE (MUDGUARD SUPPORT)	TATA spare parts
217187100111	ASSY. HINGE COMPLETE (MUDFLAP)	TATA spare parts
217187100129	SUBFRAME ASSY	TATA spare parts
217187103201	HEX HEAD BOLT M12X50 GRADE 10.9	TATA spare parts
217187103202	PIVOT BOLT M16 X 110	TATA spare parts
217187103203	PIVOT BOLT M16 X 150	TATA spare parts
217187103204	HEX HEAD BOLT M12X40 GRADE8.8	TATA spare parts
217187103401	OUTER BUSH-TAILDOOR LOCKING MECHANISM	TATA spare parts
217187103402	REAR HINGE INNER BUSH-SGI	TATA spare parts
217187103403	REAR HINGE STEEL BUSH OUTER	TATA spare parts
217187103404	BODY PROP BUSH	TATA spare parts
217187106301	HYFIX RUBBER	TATA spare parts
217187106302	RAIN FLAP-LH (MUD FLAP MIDDLE)	TATA spare parts
217187106303	RAIN FLAP-RH (MUD FLAP MIDDLE)LPK2516TC	TATA spare parts
217187106304	RAIN FLAP-LH (MUD FLAP REAR)	TATA spare parts
217187106305	RAIN FLAP-RH (MUD FLAP REAR)	TATA spare parts
217187106306	RAIN FLAP-SIDE (FRONT)	TATA spare parts
217187106307	RAIN FLAP-SIDE (REAR)	TATA spare parts
217187106501	NUT M16 - PIVOT MOUNTING	TATA spare parts
217187107103	ATTACHMENT PLATE 1	TATA spare parts

217187107104	ATTACHMENT PLATE 5	TATA spare parts
217187107105	ATTACHMENT PLATE 4	TATA spare parts
217187107106	ATTACHMENT PLATE 3	TATA spare parts
217187107107	ATTACHMENT PLATE 2	TATA spare parts
217187107108	CROSS BRACING PLATE	TATA spare parts
217187107901	REAR HINGE SHAFT	TATA spare parts
217187108201	BODY GUIDE	TATA spare parts
217187109201	WASHER M16	TATA spare parts
217187109901	CROSS BRACING	TATA spare parts
217187109902	CROSS MEMBER	TATA spare parts
217187109903	LOWER PIVOT ATTACHMENT 3	TATA spare parts
217187109904	LOWER PIVOT ATTACHMENT 2	TATA spare parts
217187109905	LOWER PIVOT ATTACHMENT 1	TATA spare parts
217187109906	CROSS MEMBER	TATA spare parts
217187109907	UPPER PIVOT ATTACHMENT 2	TATA spare parts
217187109908	UPPER PIVOT ATTACHMENT 1	TATA spare parts
217187300103	TAIL GATE LOCKING MECHANISM	TATA spare parts
217187300104	PROFILE MOUNTING ASSY	TATA spare parts
217187303401	INNER BUSH(SGI) - TAILDOOR MECH .	TATA spare parts
217187306001	TIE ROD	TATA spare parts
217187306002	CROSS ROD	TATA spare parts
217187306003	FORK - RH THREAD	TATA spare parts
217187306101	LOCKING HOOK	TATA spare parts
217187306301	MUDGUARD FLAP -3RD AXLE	TATA spare parts
217187306601	CROSS ROD (NOVUS)	TATA spare parts
217187306701	HINGE PIN (TAILDOOR HINGE & CYLINDER EYE	TATA spare parts
217187306702	TAIL DOOR HINGE PIN	TATA spare parts
217187306703	REAR HINGE PIN LOCK PLATE	TATA spare parts
217187306704	LOCKING PIN BOLTS M10X20	TATA spare parts
217187307101	METAL STRIP - STRAIGHT	TATA spare parts
217187307102	METAL STRIP - BENT	TATA spare parts
217187307701	CARTRIDGE	TATA spare parts
217187307901	CAM	TATA spare parts
217187308201	BASE 162 X 1480	TATA spare parts
217187308202	BASE 162 X 1544	TATA spare parts
217187308203	STAGE 141 X 1446-HC	TATA spare parts
217187308204	STAGE 120 X 1510-HC	TATA spare parts
217187308701	SPRING	TATA spare parts
217187309201	WASHER FOR TAIL DOOR HINGE PIN	TATA spare parts
217187309202	WASHER FOR TAIL DOOR HINGE PIN	TATA spare parts
217187400101	TAIL DOOR ASSY	TATA spare parts
217232400132	SUBFRAME	TATA spare parts
217310150001	SKIRT PANEL COMPL. /FT	TATA spare parts
217310160001	W/A PANEL COMPL	TATA spare parts
217310170001	SKIRT PANEL COMPL.	TATA spare parts
217310170002	SKIRT PANEL COMPL./SPARE TYRE	TATA spare parts
217310180001	SKIRT PANEL COMPL.	TATA spare parts

217310190001	W/A PANEL COMPL	TATA spare parts
217310200001	W/A PANEL COMPL	TATA spare parts
217310210001	W/A PANEL COMPL	TATA spare parts
217310220001	SKIRT PANEL COMPL.	TATA spare parts
217310220002	SKIRT PANEL COMPL.	TATA spare parts
217310230001	SKIRT PANEL COMPL.	TATA spare parts
217332406902	COWHORN DOWEL	TATA spare parts
217432407120	TAPER SLEEVE	TATA spare parts
217470000101	ASSY.LOAD BODY WITH CANOPY	TATA spare parts
217470400107	ASSY CANVAS COVER	TATA spare parts
217510152284	TAIL DOOR ASSEMBLY BS6	TATA spare parts
217525050011	LANDING LEG MIDDLE CROSS ANGLE - 44 - 68	TATA spare parts
217525050012	LANDING LEG MIDDLE ANGLE - 45 -1096MM	TATA spare parts
217525050336	LANDING LEG SIDE ANGLE 645 X 50 X 50 X 3	TATA spare parts
217532407121	M24 MACHINED WASHER	TATA spare parts
217535020071	TAIL DOOR BS6	TATA spare parts
217535020462	BATTERY COVER BS6	TATA spare parts
217535020463	CONTROL VALVE COVER BS6	TATA spare parts
217535020468	FUEL COVER BS6	TATA spare parts
217535020469	R-PAS SUPPORT ANGLE BS6	TATA spare parts
217535080030	BUMPER PLATE-LH/RH (RUPD SUPPORTING PLAT	TATA spare parts
217535100635	COLLAR PLATE 80 10 MM THK BS6	TATA spare parts
217535160253	REAR DOOR LOCK 320 92 16 MM THK BS6	TATA spare parts
217565080023	SUB FRAME BS6	TATA spare parts
217570020005	PARTATION BS6	TATA spare parts
217585016045	BODY BS6	TATA spare parts
217585016048	MUD GUARD BS6	TATA spare parts
217585081009	LANDING LEG BRACKET- RH BS6	TATA spare parts
217585081010	LANDING LEG BRACKET- LH BS6	TATA spare parts
217590000802	WIRE MESH ASSLY FOR TAIL LAMP BS6	TATA spare parts
217590000991	RUPD ASSEMBLY FOR TT BS6	TATA spare parts
217590001508	AXLE LIFTING MECHANISM TATA DLT AIR SUSP	TATA spare parts
217590001858	12T SUSPENSION ASSY 135X150 AXLE TUBE BS	TATA spare parts
217590001887	13T SUSPENSION ASSEMBLY BS6	TATA spare parts
217590002066	NEW AIR SUSPENSION 575 RIDE HEIGHT BS6	TATA spare parts
217632407504	RUBBER CONNECTOR	TATA spare parts
217700990101	ASSY SFC CAB WITH FITMENT	TATA spare parts
217700990102	ASSY SFC COWL WITH FITMENT	TATA spare parts
217716100101	CONTAINER (ECU-SK1613 BS-III)	TATA spare parts
217716100103	CONTAINER	TATA spare parts
217726400101	PUMP-PTO ASSY FOR SK 1613	TATA spare parts
217729100105	CLUTCH PEDAL ASSY WITH STOPPER	TATA spare parts
217729103302	Z-BRACKET	TATA spare parts
217729300102	BUNDY TUBE ASSY CMC TO LONG MEMBER	TATA spare parts
217729503301	BRACKET BUNDY TUBE MTG BS6	TATA spare parts
217730100101	ASSY HOUSING FOR ACCEL SHAFT	TATA spare parts
217730100102	ASSY ACCEL SHAFT	TATA spare parts

217730100103	ASSY LEVER WITH BUSH	TATA spare parts
217730100105	ASSY PULL ROD 640 L-FIP END	TATA spare parts
217730100108	ASSY ACCL LEVER	TATA spare parts
217730100109	ASSY PULL ROD	TATA spare parts
217730100110	ACCELERATOR BRACKET ASSY	TATA spare parts
217730100111	ASSY. ACCELERATOR SHAFT	TATA spare parts
217730100112	ASSY CONTROL SHAFT WITH BRACKET	TATA spare parts
217731000102	ASSY.FRAME COMPLETE FOR SK1613/32,CMVR	TATA spare parts
217731000105	ASSY FRAME COMPLETE WITH FRONT COUPLING	TATA spare parts
217731000107	ASSY FRAMESK1613/36 SK1613,BS-II 697TCIC	TATA spare parts
217731000108	ASSY FRAME SK 1613/36 697 BS2 1290 ROH	TATA spare parts
217731000114	FRAME ASSY	TATA spare parts
217731200103	ASSY SUPPORT RH ECMF	TATA spare parts
217731200105	ASSY ENGINE CM FRONT COMPLETE	TATA spare parts
217731200106	ASSY SUPPORT RH ECMR	TATA spare parts
217731200107	ASSY SUPPORT RH ECMR	TATA spare parts
217731200108	ASSY SUPPORT LH ECMR	TATA spare parts
217731200109	ASSY SUPPORT RH ECMR	TATA spare parts
217731200110	ASSY SUPPORT LH ECMF	TATA spare parts
217731200111	ASSY SUPPORT RH (ENG.CROSS MEMB.)	TATA spare parts
217731200112	ASSY SUPPORT LH (ENG.CROSS MEMB.REAR)	TATA spare parts
217731200113	ASSY ENGINE CROSS MEMBER REAR	TATA spare parts
217731200118	CROSS MEMBER ASSY ENGINE MTG REAR	TATA spare parts
21773120011835	ENGINE CROSS MEMBER UNPAINTED	TATA spare parts
217731207120	REINFORCEMENT R.H (BOTTOM)	TATA spare parts
217731207121	REINFORCEMENT L.H (BOTTOM)	TATA spare parts
217731207124	REINFORCEMENT BOTTOM RH	TATA spare parts
217731207125	REINFORCEMENT BOTTOM LH	TATA spare parts
217731700101	ASSY NOISE SHIELD RADIATOR BOTTOM	TATA spare parts
217731700102	ASSY NOISE SHIELD ENGINE BOTTOM FRONT	TATA spare parts
217731700103	ASSY NOISE SHIELD ENGINE REAR BOTTOM	TATA spare parts
217731700105	ASSY BRACKET RH RADIATOR NOISE SHIELD	TATA spare parts
217731700106	ASSY BRACKET LH RADIATOR NOISE SHIELD	TATA spare parts
217731700107	ASSY CHANNEL-RH (ENG NOISE SHIELD)	TATA spare parts
217732103201	CENTRE BOLT	TATA spare parts
217732400133	12INCH ALUMINIUM PISTON	TATA spare parts
217740300101	SPARE WHEEL CARRIER ASSY	TATA spare parts
217741100107	ASSY PROP SHAFT W/ C. BRG. 420L	TATA spare parts
217741100109	ASSYPROP SHAFT FRONT WITH CENTER BEARIG	TATA spare parts
217741100110	ASSY.PROP.SHAFT WITH CENTREN BRG	TATA spare parts
217741100113	ASSY GUARD(PROP SHAFT)	TATA spare parts
217741100116	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
217741100117	CENTRE BEARING ASSY.	TATA spare parts
217741106501	HEX NUT	TATA spare parts
217741110101	ASSY PROPELLER SHAFT FRONT	TATA spare parts
217741110102	ASSY PROPELLER SHAFT FRONT	TATA spare parts
217741120106	ASSY. PROPELLER SHAFT REAR	TATA spare parts



217741120108	ASSY PROPELLER SHAFT REAR	TATA spare parts
217741303301	BRACKET CENTRE BEARING MOUNTING	TATA spare parts
217741303302	BRACKET CENTER BRG MTG	TATA spare parts
217741303303	BRACKET CENTER BRG MTG	TATA spare parts
217742400105	ASST BRACKET (AT REAR AXLE L.S VALVE)	TATA spare parts
217742400107	ASSY. PULL ROD (L. S. VALVE)	TATA spare parts
217743700101	ASSY.BRACKET.	TATA spare parts
217743900101	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
217743900106	ASSY.TUBE O.D 15 X 1900 LG.	TATA spare parts
217743900135	ASSY. NYLON PIPE SET COMPLETE(STANDARD-N	TATA spare parts
217743900137	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
217743900146	ASSY.NYLON PIPE SET COMPLT W/VOSS	TATA spare parts
217743900150	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
217743900151	ASSY. COMPRESSOR 3RD PIPE	TATA spare parts
217743900152	ASSY.NYLON PIPE SET COMPLETE VOSS	TATA spare parts
217743900153	ASSY.COMPRESSOR 1ST PIPE WITH HOSE	TATA spare parts
217743900156	ASSY.NYLON PIPE SET COMPLETE VOSS	TATA spare parts
217743900162	ASSY.COMP.INLET PIPE	TATA spare parts
217743900175	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
217743900176	NYL/BUNCH SK 1613/42 697 BS-3 (NEW)	TATA spare parts
217743903302	PLATE BRACKET BS6	TATA spare parts
217743903303	Z-BRACKET	TATA spare parts
217743903304	STRAIGHT BRACKET¿BS6	TATA spare parts
217743910102	PIPE ASSY BUNCH COMPLETE	TATA spare parts
217743910140	METAL PIPE ASSY 3RD TO DDU	TATA spare parts
217743910142	PIPE ASSY BUNCH COMPLETE	TATA spare parts
217743910149	METAL PIPE ASSY SECOND	TATA spare parts
217743910150	PIPE ASSY BUNCH COMPLETE	TATA spare parts
217743910201	PIPE ASSY BUNCH COMP FOR SK1613	TATA spare parts
217743910223	METAL PIPE ASSY HOSE TO 3RD METAL PIPE	TATA spare parts
217743910224	METAL PIPE ASSY 3RD TO DDU	TATA spare parts
217743910226	METAL PIPE ASSY WITH TEFLON HOSE	TATA spare parts
217743910227	PIPE ASSY BUNCH COMPLETE	TATA spare parts
217743910238	METAL PIPE ASSY HOSE TO 3RD METAL PIPE	TATA spare parts
217744100012	KIT HYD HOSES (SINGLE CYL) SK1613 BS-III	TATA spare parts
217744100104	KIT HYD.AGGRET.(SINGLE CYL)SK1613 BS-III	TATA spare parts
217744100105	KIT HYD.AGGRET.(SINGLE CYL)	TATA spare parts
217744100106	KIT HYD.AGGRET.(TWIN CYL)	TATA spare parts
217744100112	SUCTION HOSE PTO TO TANK	TATA spare parts
217744100113	RETURN LINE HOSE 1 IN X 830 MM	TATA spare parts
217744100116	M 33 X 2 /17/16- 12 UNF ADAPTER	TATA spare parts
217744100119	M 22 X 1.5 / M 26 X 1.5 SQUARE ELBOW	TATA spare parts
217744100130	PRESSURE PIPE HOSE (3/4IN X 680 MM)	TATA spare parts
217744100131	RETURN LINE HOSE (1/2 X 2560 OL) CYL	TATA spare parts
217744100132	PRESSURE HOSE (3/4 ID X 1800 L) MCV T	TATA spare parts
217744100133	M22 X 1.5/13/16-16 UNF ADAPTOR	TATA spare parts
217744100134	M22 X 1.5/13/16-12 UNF ADAPTOR	TATA spare parts

217744100135	RETURN LINE HOSE (1/2 ID X 1900 OL)	TATA spare parts
217744100136	PRESSURE HOSE (3/4 ID X 1905 L)	TATA spare parts
217744100137	OIL PIPE S/A DIA 18 (CYLINDER TOP)	TATA spare parts
217744100138	OIL PIPE S/A DIA 18 (CYLINDER BOTTOM)	TATA spare parts
217744100139	OIL PIPE S/A DIA 18 (CYLINDER BOTTOM)	TATA spare parts
217744100140	PRESSURE PIPE HOSE (1/2IN X 2160 MM)	TATA spare parts
217744100141	PRESSURE PIPE HOSE (3/4IN X 1400 MM)	TATA spare parts
217744100142	TEL CYL 2 STAGE (72-2-50M)	TATA spare parts
217744100144	ASSY LINEAR SPOOL VALVE	TATA spare parts
217744100145	SUCTION HOSE TANK TO PTO	TATA spare parts
217744100146	PRESSURE HOSE 3/4IN ID X 1070 OL	TATA spare parts
217744100147	1 3/16-12 UNF / M26 X 1.5 MALE ADAPTER	TATA spare parts
217744100148	1 7/16-12 UNF / M39 X 2.0 MALE ADAPTER	TATA spare parts
217744100151	SUCTION HOSE 1 IN ID	TATA spare parts
217744100152	RETURN LINE HOSE 1IN ID	TATA spare parts
217744100153	PRESSURE HOSE 3/4IN IDX1100 LONG	TATA spare parts
217744100154	PRESSURE HOSE 3/4 IN IDX1750 LONG	TATA spare parts
217744100155	PRESSURE HOSE 1/2IN IDX2450 LONG	TATA spare parts
217744100156	PRESSURE HOSE 3/4INCHIDX1900 LONG	TATA spare parts
217744100157	PRESSURE HOSE 1/2INCHIDX2700 LONG	TATA spare parts
217744100158	PRESSURE HOSE 3/4INCHIDX210 LONG	TATA spare parts
217744100159	PRESSURE HOSE 1/2INCHIDX120 LONG	TATA spare parts
217744100172	CYLINDER ASSY 2-STAGE TELESCOPIC	TATA spare parts
217744106802	M22 X 1.5 / M 26 X 1.5 ADAPTER	TATA spare parts
217744106810	M22X1.5/M24X1.5 MALE COUPLING BODY	TATA spare parts
217744106811	M27X2/M30X2 MALE COUPLING BODY	TATA spare parts
217744106812	M22X1.5/M26X1.5 ELBOW BODY	TATA spare parts
217744106813	COUPLING BODY M26X1.5/M27X2 MALE	TATA spare parts
217744106814	M30X2/M22X1.5 MALE COUPLING BODY	TATA spare parts
217744106815	M24X1.5/M26X1.5 MALE COUPLING BODY	TATA spare parts
217744106816	M39X2/M30X2 MALE COUPLING BODY	TATA spare parts
217744109902	PTO ASSY	TATA spare parts
217744150101	KIT FOR HYDRAULIC TIPPING	TATA spare parts
217744150107	KIT HYD.AGGRET(SING.CYL)SK1613/36	TATA spare parts
217744400101	HYDRULIC TANK ASSY. (50 LTRS.)	TATA spare parts
217744400102	HYDRAULIC TANK ASSY	TATA spare parts
217744990012	KIT HYD.HOSES 2CYL SK1613 8CUM/960ROH	TATA spare parts
217744990101	KIT HYD.AGGRT.2CYL SK1613 8CUM/960ROH	TATA spare parts
217744990102	KIT HYD.AGGRT.2CYL SK1613 42WB/TAL	TATA spare parts
217745903301	L-BRACKET	TATA spare parts
217745909201	SPECIAL WASHER	TATA spare parts
217746106301	RUBBER BELLOW STEERING COLUMN	TATA spare parts
217746150102	KIT ASSY P/STG PIPELINE&CONNECTOR	TATA spare parts
217746150104	KIT ASSY P/STG PIPELINES&CONNECTOR	TATA spare parts
217746150106	KIT-PIPE & ADAPTER	TATA spare parts
217746600104	ASSY BRACKET(STRG COLUMN SUPPORT TO COW)	TATA spare parts
217746608205	BRACKET FOR P/STG.TANK.	TATA spare parts

217746800101	ASSY HOSE-STG.TANK TO PUMP	TATA spare parts
217746800102	ASSY HOSE-STG.G.B.TO TANK	TATA spare parts
217746800103	SUCTION LINE HOSE ASSY	TATA spare parts
217746800104	PR. LINE HOSE ASSY	TATA spare parts
217746800105	RETURNLINE HOSE ASSY	TATA spare parts
217746800106	RETURN LINE HOSE ASSY	TATA spare parts
217746800109	SUCTION LINE ASSY	TATA spare parts
217746800110	PRESSURE LINE ASSY	TATA spare parts
217746800111	RETURN LINE ASSY	TATA spare parts
217747100102	ASSY BRACKET (WATER SEP.MTG.)	TATA spare parts
217747150104	ASSY.RETROFIT.KIT W/ELE FEED PUMP-SK1613	TATA spare parts
217747600103	ASSYTUBE WITH CRIMPED R/HOSE(FUEL TANK T	TATA spare parts
217747600104	ASSYTUBE WITH CRIMPED R/HOSE (WATER SEP	TATA spare parts
217747600105	ASSYTUBE WITH CRIMPED R/HOSE (ENGINE TO	TATA spare parts
217747600106	ASSY.TUBE WITH CRIMPED RUBBER HOSE(SUCTI	TATA spare parts
217747600107	ASSY.TUBE WITH CRIMPED RUBBER HOSE (BABY	TATA spare parts
217747600115	ASSY.NYLON PIPE WITH CRIMPED RUBBER HOSE	TATA spare parts
217747600116	ASSY.NYLON PIPE WITH CRIMPED RUBBER HOSE	TATA spare parts
217747600117	ASSY.NYLON PIPE WITH CRIMPED RUBBER HOSE	TATA spare parts
217747600123	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
217747600125	SUCTION PIPE TANK TO PRE FILTER	TATA spare parts
217747600126	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
217747600127	SUCTION PIPE ASSY PRE FILTER TO FILTER	TATA spare parts
217747600128	SUCTION PIPE FUEL TANK TO W/SEP	TATA spare parts
217747600129	SUCTION LINE PIPE W/SEP TO FILTER	TATA spare parts
217747600130	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
217747600131	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
217747600132	SUCTION PIPE ASSY TANK TO PRE-FILTER	TATA spare parts
217747600133	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
217747703301	BRACKET FUEL FILTER MTG	TATA spare parts
217749100102	ASSY SILENCER WITH SHORT TAIL PIPE	TATA spare parts
217749200101	ASSY.EXH.PIPE INTERMEDIATE	TATA spare parts
217749200107	ASSY EXHAUST PIPE FRONT 1ST PIPE	TATA spare parts
217749200108	ASSY EXHAUST PIPE INTERMEDIATE	TATA spare parts
217749200110	ASSY EXHAUST PIPE REAR	TATA spare parts
217749200112	ASSY EXHAUST 2ND PIPE(SE/SK)	TATA spare parts
217749200114	EXHAUST PIPE	TATA spare parts
217749200115	ASSY. BRACKET-MUFFLER CLAMP	TATA spare parts
217749200129	EXHAUST PIPE ASSY SECOND	TATA spare parts
217749200130	EXHAUST PIPE ASSY THIRD	TATA spare parts
217749200131	ASSY BRACKET	TATA spare parts
217749200136	EXHAUST PIPE ASSY INT	TATA spare parts
217749200138	ASSY BRACKET (FOR SILENCER MTG)	TATA spare parts
217749200140	EXHAUST PIPE ASSY SECOND	TATA spare parts
217749200141	EXHAUST PIPE ASSY THIRD	TATA spare parts
217749200142	EXH PIPE SK 1613/36 697 BS-3 TWP CAB	TATA spare parts
217749200143	ASSY 3RD PIPE EXHAUST	TATA spare parts

217749200145	ASSY 3RD PIPE (EXHAUST)	TATA spare parts
217749200146	EXHAUST PIPE ASSY INT	TATA spare parts
217749203304	BRACKET DOC POC MTG	TATA spare parts
217749203305	EXHAUST BRACKET	TATA spare parts
217749203306	BRACKET DOC POC MTG	TATA spare parts
217749203319	BRACKET EXHAUST MTG	TATA spare parts
217749203320	BRACKET EXHAUST MTG	TATA spare parts
217749203322	BRACKET EXHAUST PIPE MTG	TATA spare parts
217749206901	TAIL PIPE	TATA spare parts
217749206931	TAIL PIPE	TATA spare parts
217749206938	TUBE HOSE TO DPS	TATA spare parts
217749206939	TUBE DPS SENSOR OUTLET	TATA spare parts
217749208201	OVAL CLAMP-FOR SILENCER	TATA spare parts
217749208202	EXHAUST MTG.PLATE (ON C/M)	TATA spare parts
217749208225	BRACKET	TATA spare parts
217749208228	BRACKET	TATA spare parts
217749208231	EXHAUST CLAMP	TATA spare parts
217749600101	HEAT SHIELD ASSY EXHAUST PIPE	TATA spare parts
217749990107	KIT-EXHAUST PIPE HEAT SHIELD	TATA spare parts
217754209907	INSTRUMENT CLUSTER (0.88)	TATA spare parts
217754209908	INSTRUMENT CLUSTR (0.88) ESPDO 12V	TATA spare parts
217754600101	WIRING HARNESS ABS FRAME	TATA spare parts
217754600107	WIRING HARNESS ABS FRAME	TATA spare parts
217754600108	WIRING HARNESS MAIN)	TATA spare parts
217754600110	WIRING HARNESS MAIN	TATA spare parts
217754600111	WIRING HARNESS ENGINE	TATA spare parts
217754600113	WIRING HARNESS ABS FRAME	TATA spare parts
217754600115	PIGTAIL MAXI FUSE	TATA spare parts
217754600116	BATTERY CABLE +VE BCS O/P TO SM	TATA spare parts
217754600117	PIGTAIL MAXI FUSE	TATA spare parts
217754600120	WIRING HARNESS ABS FRAME	TATA spare parts
217754601608	WIRING HARNESS TAIL	TATA spare parts
217754601619	WIRING HARNESS TAIL	TATA spare parts
217754620101	W/H MAIN SK-1613 697 BSII 12V	TATA spare parts
217754620103	WIRING HARNESS TAIL	TATA spare parts
217754620104	WIRING HARNESS TAIL	TATA spare parts
217754620115	WIRING HARNESS MAIN	TATA spare parts
217754660111	WIRING HARNESS MAIN	TATA spare parts
217754660112	WIRING HARNESS MAIN	TATA spare parts
217754820101	W/H MAIN-SK 697 BS-II MOTOR H/L	TATA spare parts
217754820102	W/H TAIL-SK W.B-32 BS-II--JSR MODEL	TATA spare parts
217754820103	W/H TAIL-SK W.B-36 BS-II	TATA spare parts
217754820104	W/H-MAIN SK-1613 697 BS-II INST CLUSTER	TATA spare parts
217783300102	CONTROL PANEL ASSY	TATA spare parts
217783400101	AC UNIT ASSY	TATA spare parts
217783400104	RESISTOR ASSY	TATA spare parts
217783400105	VENTILATION UNIT ASSY	TATA spare parts

217783400108	BLOWER ASSY	TATA spare parts
217783400109	THERMO EXPANSION VALVE	TATA spare parts
217783400113	WIRING HARNESS	TATA spare parts
217783400114	BLOWER HSG ASSY	TATA spare parts
217783403301	BRACKET LH	TATA spare parts
217783403302	BRACKET RH	TATA spare parts
217783403303	BRACKET BLOWER MTG	TATA spare parts
217783450101	CONDENSER UNIT ASSY	TATA spare parts
217783600102	SUCTION PIPE HVAC END	TATA spare parts
217783600103	SUCTION PIPE COMPRESSOR END	TATA spare parts
217783600104	DISCHARGE PIPE CONDENSER END	TATA spare parts
217783600105	LIQUID PIPE CONDENSER END	TATA spare parts
217783600106	LIQUID PIPE HVAC END	TATA spare parts
217783750101	BRACKET ASSY AC PIPE MTG	TATA spare parts
217783750102	BRACKET ASSY AC PIPE MTG	TATA spare parts
217783750104	BRACKET ASSY AC UNIT MTG	TATA spare parts
217783784203	P-CLAMP	TATA spare parts
217783784204	P CLAMP BS6	TATA spare parts
217826800101	ASSY GEAR SHIFT LEVER KNOB	TATA spare parts
217826800108	TURNING TUBE ASSY. (WITHOUT BALL JOINT)	TATA spare parts
217826807101	BRACKET LINK ROD MTG	TATA spare parts
217829100101	ASSY CLUTCH BOOSTER WITH	TATA spare parts
217829100102	ASSY. CLUTCH BOOSTER (TYPE-1) BS3/4	TATA spare parts
217829200101	ASSY BRACKET CLUTCH BOOSTER MTG	TATA spare parts
217829300101	ASSY.TUBE 6 O.D.X 1535 LG. (1ST PIPE)	TATA spare parts
217829300102	ASSY.TUBE 6 O.D.X 3100 LG. (2ND PIPE)	TATA spare parts
217831000104	ASSY FRAME COMPLETE - LPT1623TC/52(888 F	TATA spare parts
217831200107	ASSY ENGINE CROSS MEMBER REAR (WITH SUPP	TATA spare parts
217831200108	ASSY RADIATOR MTG BKT-RH	TATA spare parts
217831200109	ASSY RADIATOR MTG BKT-LH	TATA spare parts
217832403206	TAPER PIVOT BOLT	TATA spare parts
217832404201	U CLAMP M22X2.5X514	TATA spare parts
217833000101	ASSY FRONT AXLE WITH NGT BRAKES & ABS	TATA spare parts
217841100106	ASSY MTG BRACKET (PROP SHAFT GUARD)	TATA spare parts
217841100107	ASSY PROP SHAFT FRONT(L=1217)	TATA spare parts
217841120104	ASSY PROP SHAFT REAR(L=1140)	TATA spare parts
217841120105	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
217841303302	SPACER BRACKET (FOR CENTRE BEARING)	TATA spare parts
217841303303	SPACER BRACKET (FOR CENTER BEARING)	TATA spare parts
217841303304	SPACER BRACKET (FOR CENTER BEARING)	TATA spare parts
217842300102	DRUM BRAKE BRAKE ASSY REAR LH W/T D/C	TATA spare parts
217842300103	DRUM BRAKE REAR BRAKE ASSY RH W/T D/C	TATA spare parts
217843910102	ASSY METAL PIPE (18OD) FROM JOINT-1 TO J	TATA spare parts
217843910103	ASSY.METAL PIPE (15OD)FROM JOINT-2 TO AI	TATA spare parts
217846150104	KIT ASSY.PIPES & CONNECTORS	TATA spare parts
217847600108	ASSY. SUCTION FUEL LINE	TATA spare parts
217847600109	ASSY. RETURN FUEL LINE	TATA spare parts

217849200103	ASSY. EXHAUST PIPE	TATA spare parts
217849200104	ASSY. EXHAUST PIPE	TATA spare parts
217849200106	ASSY. EXHAUST PIPE	TATA spare parts
217849208201	EXHAUST BRACKET	TATA spare parts
217849208202	BRACKET	TATA spare parts
217849208203	BRACKET	TATA spare parts
217849208204	BRACKET	TATA spare parts
217849208205	BRACKET	TATA spare parts
217849208206	BRACKET	TATA spare parts
217854209901	ELE. S.M. WI. LCD ODO.M.24V (1:1.7)	TATA spare parts
217854440102	ASSY WARNING LAMP (24V)	TATA spare parts
217854600103	WIRING HARNESS FRAMEç 48 WB	TATA spare parts
217854620101	W/H MAIN	TATA spare parts
217854620104	W/H INST. CONSOLE	TATA spare parts
217854620107	W/H TAIL	TATA spare parts
217924200101	ASSY.BRACKET COMP-RH (ENG.MTG.REAR)	TATA spare parts
217924200102	ASSY.BRACKET COMP-LH (ENG.MTG.REAR)	TATA spare parts
217926800105	ASSY G S LEVER WITH ASSY TURNING TUBE	TATA spare parts
217926800106	ASSY TURNING TUBE (W/O BALL JOINT)	TATA spare parts
217926800108	ASSY G S LEVER WITH ASSY TUBE LHD	TATA spare parts
217926805101	SELECTOR AND SHIFTER YOKE	TATA spare parts
217926810103	ASSY SUPPORT TUBE	TATA spare parts
217926810104	ASSY BRACKET G S LEVER (W/POWER STG)	TATA spare parts
217926810108	ASSY BRACKET W/TOP PLATE (G S L MTG)LHD	TATA spare parts
217926810109	ASSY SUPPORT TUBE	TATA spare parts
217926810111	CABLE ANCHORING BRACKET	TATA spare parts
217929100101	HYD.PIPELINE FROM HOSE TO CLUTCH BOOSTER	TATA spare parts
217929100104	ASSY BRACKET (CLUTCH BOOSTER MTG.)	TATA spare parts
217929100112	ASSY SUPPORT COMPLETE (CLUTCH)	TATA spare parts
217929100113	HYD. PIPELINE FROM MASTER CLY TO HOSE	TATA spare parts
217929100119	HYD.PIPELINE FROM HOSE TO CLUTCH BOOSTER	TATA spare parts
217929108201	L-BRACKET CLUTCH PIPE MTG BS6	TATA spare parts
217929500101	ASSY.SUPPORT BRACKET CLUTCH BOOSTER MTG.	TATA spare parts
217930100101	ASSY.PULL CABLE-ACCELERATOR	TATA spare parts
217930100102	ACCELERATOR CABLE ASSY	TATA spare parts
217931000101	ASSY.FRAME COMPLETE	TATA spare parts
217931000102	FRAME ASSY WITH FITMENT	TATA spare parts
217931000105	ASSY.FRAME COMPLETE LPT1116/48WB	TATA spare parts
217931000106	FRAME ASSY WITH FITMENT	TATA spare parts
21793120010135	ASSY ENGINE CROSS MEMBER REAR	TATA spare parts
217931200103	ASSY.END CROSSMEMBER COMPLETE	TATA spare parts
217931200105	ASSY.CROSSMEMBER (CENTRE BRG.MTG)	TATA spare parts
217931200109	ASSY.CROSSMEMBER FRONT	TATA spare parts
217931200110	ASSY RUPD BRACKET COMPLETE RH	TATA spare parts
217931200111	ASSY RUPD BRACKET COMPLETE LH	TATA spare parts
217931200120	ASSY CROSS MEMBER COMPLETE	TATA spare parts
217931700101	ASSY.BRACKET-RH (RUPD MTG)	TATA spare parts

217931700102	ASSY.BRACKET-LH (RUPD MTG)	TATA spare parts
217931700120	BRACKET ASSY RUPD MTG RH	TATA spare parts
217931700121	BRACKET ASSY RUPD MTG LH	TATA spare parts
217931700123	BEAM ASSY RUPD	TATA spare parts
217931708201	SPACER	TATA spare parts
217932407122	12INCH STEEL CLAMP PLATE	TATA spare parts
217940109920	TUBE	TATA spare parts
217940109921	FLAP	TATA spare parts
217941110101	ASSY.PROP SHAFT FRONT 1116LPT42	TATA spare parts
217941110102	ASSY.PROP SHAFT FRONT COMPLETE	TATA spare parts
217941120101	ASSY. PROP SHAFT REAR 1116 LPT42	TATA spare parts
217941308201	BRACKET-CENTRE BEARING MTG.	TATA spare parts
217942303302	BRACKET ASSY SENSOR MTG REAR	TATA spare parts
217943700102	SBA TYPE 16/16 DOUBLE O-RING ARRANGMENT	TATA spare parts
217943700103	BRAKE CHAMBER TYPE 16 FOR DOUBLE O-RING	TATA spare parts
217943900101	ASSY METAL PIPE SECOND COMP TO DDU	TATA spare parts
217943900126	ASSY NYLON PIPE SET CHASSIS COMPL	TATA spare parts
217943900151	HOSE ASSY WITH DOUBLE O-RING +NON METRIC	TATA spare parts
217943900152	HOSE ASSY WITH DOUBLE O-RING+NON METRIC	TATA spare parts
217943900153	HOSE 3/8IN ASSEMBLY WITH VOSS+DOUBLE O-R	TATA spare parts
217943900154	HOSE ASSY WITH ZERO LEAK-490MM LENGTH	TATA spare parts
217943900156	HOSE ASSEMBLY WITH VOSS TYPE 3/8 IN (550	TATA spare parts
217943900158	HOSE ASSY WITH NON METRIC	TATA spare parts
217943900160	ASSY BRACKET FOR PARKING & SERVICE HOSE	TATA spare parts
217943900170	ASSY NYLON PIPE SET CHASSIS COMPLETE	TATA spare parts
217943900172	ASSY METAL PIPE (FROM CRIMP HOSE TO DDU)	TATA spare parts
217943903301	BRACKET FOR QUICK RELEASE VALVE	TATA spare parts
217943903302	TRAILER CONTROL VALVE MOUNTING BRACKET	TATA spare parts
217943903304	BRACKET FOR REAR HOSE MTG.ON LH LM	TATA spare parts
217943903306	BRACKET HOSE MTG LCRV BS6	TATA spare parts
217943903307	BRACKET (FRONT HOSE MOUNTING)	TATA spare parts
217943910101	ASSY. METAL PIPE(COMP TO AIRDRIER)	TATA spare parts
217943910121	ASSY NYLON PIPE SET CHASSIS COMP LPT1116	TATA spare parts
217943910127	ASSY NYLON PIPE SET CHASSIS COMPL	TATA spare parts
217946103501	SPACER (STG GBOX MTG BKT.)	TATA spare parts
217946200101	ASSY BKT. FOR STG. GEAR BOX MTG.	TATA spare parts
217946200108	ASSEMBLY BRACKET STG. GB MOUNTING	TATA spare parts
217946200109	ASSY STRG G.BOX MTG BRACKET LPT1116	TATA spare parts
217946200120	ASSY RES. TANK MTG. BKT.	TATA spare parts
217946207120	SIDE PLATE FOR STG. GEAR BOX MTG. BKT.	TATA spare parts
217946300101	PITMAN ARM	TATA spare parts
217946600103	ASSY DRAG LINK	TATA spare parts
217946800106	ASSY PIPE (PUMP TO GEAR BOX)	TATA spare parts
217946800107	ASSY PIPE (GEAR BOX TO RES. TANK)	TATA spare parts
217946800108	ASSY PIPE (RES. TANK TO PUMP)	TATA spare parts
217946800109	ASSY PIPE (PUMP TO GEAR BOX)	TATA spare parts
217946800110	ASSY PIPE (GEAR BOX TO RES. TANK)	TATA spare parts

217946800111	ASSY PIPE (RES. TANK TO PUMP)	TATA spare parts
217946800114	ASSY SUCTION LINE	TATA spare parts
217946800115	ASSY RETURN LINE	TATA spare parts
217946800116	ASSY PRESSURE LINE	TATA spare parts
217946809201	SEALING RING ASSY	TATA spare parts
217947500101	ASSY.STRAP(FUEL TANK 430 DIA)	TATA spare parts
217947600101	ASSY. SUCTION PIPE(TANK TO BABY FILTER)	TATA spare parts
217947600102	ASSY. SUCTION LINE(STRAINER TO FEEDPUMP)	TATA spare parts
217947600103	ASSY. RETURN LINE(OVERFLOW TO TANK)	TATA spare parts
217947600104	ASSY SUCTION LINE(TANK-BABY FILTER)	TATA spare parts
217949200101	ASSY EXHAUST PIPE FRONT	TATA spare parts
217949200102	ASSY.BRACKET (2ND PIPE MTG)	TATA spare parts
217949200103	ASSY BRACKET(SILENCER MTG)	TATA spare parts
217949200113	BRACKET ASSY (DPS MOUNTING BRACKET)	TATA spare parts
217954100101	BATTERY CABLE -VE	TATA spare parts
217954100102	ASSY. BATT.CABLE -VE 400MM W/COT 70SQ.MM	TATA spare parts
217954200101	INSTRUMENT CLUSTER ASSY	TATA spare parts
217954204901	MICRO RELAY 24V/10A	TATA spare parts
217954204902	MICRO RELAY 24V/10A NO/NC-R.ENGG	TATA spare parts
217954240101	INST. CLUSTER 0.72 LPT1116 EIII	TATA spare parts
217954240102	INST.CLUSTER 1:0.85ç 24V	TATA spare parts
217954600132	WIRING HARNESS ENGINE	TATA spare parts
217954620101	W/H TAIL LPT1116/42WB EIII W/PTO	TATA spare parts
217954660102	WIRING HARNESS MAIN LPT1116 RHD 24V	TATA spare parts
217954660103	WIRING HARNESS ENGINE LPT1116 RHD 24V	TATA spare parts
217954660104	WIRING HARNESS TAIL LPT1116 RHD 24V 48WB	TATA spare parts
218032406901	M12 X 1.75 X 55MM STUD	TATA spare parts
2181000001	NUT	TATA spare parts
218132403310	PIVOT BOLT PULLER	TATA spare parts
218200990102	KIT FULLY TRIMMED CABIN FOR LPK 1618	TATA spare parts
218200990104	KIT-FOR CABIN OF LPK 1618 BLOWER BS4	TATA spare parts
218200990106	KIT FOR CABIN OF LPK 1618 BSIV BLOWER	TATA spare parts
21823036300R40	PARTIALLY FITTED CAB	TATA spare parts
218231000103	ASSY. FRAME COMPLETE LPK1618/FIX CAB	TATA spare parts
218231000104	FRAME ASSY WITH FITMENT	TATA spare parts
218231000105	ASSY. FRAME WITH FITMENT BS4	TATA spare parts
218231000107	FRAME ASSY WITH FITMENT	TATA spare parts
218231200104	ASSY. RADIATOR MTG. BKT.-RH	TATA spare parts
218231200105	ASSY. RADIATOR MTG. BKT.-LH	TATA spare parts
218231200106	ASSY. 4TH CROSS MEMBER	TATA spare parts
21823120010661	ASSY. 4TH CROSS MEMBER	TATA spare parts
218231307116	SUPPORT TOP-RH (4 TH CROSS MEMBER)	TATA spare parts
218231307117	SUPPORT TOP-LH (4 TH CROSS MEMBER)	TATA spare parts
218231308201	GUSSET TOP-RH (BUMPER C/M)	TATA spare parts
218231308202	GUSSET TOP-LH(BUMPER CROSS MEMBER)	TATA spare parts
218231708206	CLAMP(BREATHER MTG)	TATA spare parts
218232107107	PLATE	TATA spare parts



218232403207	M16 X 2 X 140MM HEX BOLT	TATA spare parts
218241100103	COUPLING FLANGE & DUST COVER ASSY	TATA spare parts
218241100104	ASSY. CENTER BEARING BS1/2/3/4	TATA spare parts
218241110102	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
218241120107	ASSY. PROP SHAFT	TATA spare parts
218243900101	BUNCH ASSY PIPE	TATA spare parts
218243900102	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
218243900103	ASSY. COMPRESSOR 3RD PIPE	TATA spare parts
218243900104	ASSY. NYLON PIPE SET COMPLETE	TATA spare parts
218243900107	METAL PIPELINE WITH CRIMPED TEFLON HOSE	TATA spare parts
218243900132	BUNCH ASSY PIPE	TATA spare parts
218243900153	METAL PIPE ASSY JOINT 2 TO DDU INLET	TATA spare parts
218243900154	METAL PIPE ASSY JOINT 1 TO JOINT 2	TATA spare parts
218243900156	BUNCH ASSY PIPE	TATA spare parts
218243900163	PIPE ASSY AIR COMPRESSOR INTAKE	TATA spare parts
218247600103	SUCTION LINE (TANK TO FILTER)	TATA spare parts
218247600104	SUCTION LINE (FILTER TO ENG)	TATA spare parts
218247600105	RETURN LINE ASSY ON TANK	TATA spare parts
218247600106	SUCTION LINE TUBE ASSY TANK TO W/SEP	TATA spare parts
218247600107	SUCTION FUEL PIPE W/SEP TO FIP	TATA spare parts
218247600108	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
218247605802	RUBBER HOSE (RETURN LINE)	TATA spare parts
218247605815	RUBBER HOSE (SUCTION LINE)	TATA spare parts
218247700101	BRACKET ASSY RIVIGO	TATA spare parts
218249200103	ASSY. EXHAUST PIPE(INTERMEDIATE)	TATA spare parts
218249200108	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
218249200109	PIPE ASSY T-CONNECTOR TO AIR OIL FILTER	TATA spare parts
218249200111	PIPE ASSY AIR OIL FILTER TO DU	TATA spare parts
218249200112	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
218249200113	BRACKET ASSY EGP MTG	TATA spare parts
218249200114	ASSY. BRACKET UREA & DOSING UNIT MTG BS4	TATA spare parts
218249203310	BRACKET EXHAUST PIPE SUPPORT	TATA spare parts
218249203312	BRACKET TAIL PIPE CLAMP	TATA spare parts
218249203313	BRACKET AIR OIL SEPARATOR MTG	TATA spare parts
218254600101	WIRING HARNESS ABS	TATA spare parts
218254600104	WIRING HARNESS ENGINE	TATA spare parts
218254600105	WIRING HARNESS ENGINE	TATA spare parts
218254600107	WIRING HARNESS ENGINE	TATA spare parts
218254610101	WIRING HARNESS MAIN BS6	TATA spare parts
218254610102	WIRING HARNESS TAIL	TATA spare parts
218254620102	WIRING HARNESS TAIL	TATA spare parts
218254620103	WIRING HARNESS SCR UNIT	TATA spare parts
218254660104	WIRING HARNESS TAIL	TATA spare parts
21826000013R40	CAB PARTIALLY FITTED LPK 1618 BS3	TATA spare parts
218287000101	ASSY. KIT COMP.-10CUM-BOX &HYD TIPPING	TATA spare parts
218287000102	ASSY TIPPING KIT 10 CUM BOX	TATA spare parts
218287000105	ASSY. KIT COMP-10CUM-BOX BODY	TATA spare parts

218287100101	ASSY SUB FRAME	TATA spare parts
218287100102	ASSY SUB FRAME	TATA spare parts
218287300101	ASSY. TIPPING BODY COMPLETE(10CUM)	TATA spare parts
218287300102	ASSY TIPPING BODY COMPLETE	TATA spare parts
218332403208	M16 X 2 X 160MM HEX BOLT	TATA spare parts
218432403209	M20 X 2.5 X 200MM HEX BOLT	TATA spare parts
218509130101	ASSY BRKT (AIR FILTER MTG)	TATA spare parts
218514603802	BENT PIPE(IC TO CYL HEAD INLET)	TATA spare parts
218514603803	PIPE(IC TO CYL HEAD INLET)	TATA spare parts
218514605801	HOSE HUMP	TATA spare parts
218514608201	CLAMP	TATA spare parts
218514608202	CLAMP PLATE	TATA spare parts
218514608203	CLAMP	TATA spare parts
218514609902	ASSY INTERCOOLER	TATA spare parts
218524200101	ASSY.BRACKET(ENGINE MTG.REAR TOP)	TATA spare parts
218526800109	ASSY TURNING TUBE (W/O BALL JOINT)	TATA spare parts
218526800110	ASSY. BRKT. FOR GEAR SHIFT LINKAGE	TATA spare parts
218531000101	ASSY FRAME	TATA spare parts
218531200104	ASSY ENGINE CROSS MEMBER (REAR)	TATA spare parts
218531207101	SUPPORT (ENGINE CROSS MEMBER FRONT)	TATA spare parts
218531207107	SUPPORT (TUBULAR X MEMBER)	TATA spare parts
218531208203	PACKING PLATE (3.15 THK)	TATA spare parts
218532100109	ASSY.FRONT SPRING	TATA spare parts
218532107118	FIRST LEAF	TATA spare parts
218532107119	SECOND LEAF	TATA spare parts
218532107120	THIRD LEAF	TATA spare parts
218532107121	FOURTH LEAF	TATA spare parts
218532107122	FIFTH LEAF	TATA spare parts
218532107123	SIXTH LEAF	TATA spare parts
218532107124	SEVENTH LEAF	TATA spare parts
218532107125	EIGHTH LEAF	TATA spare parts
218532300101	ASSY BRACKET (FRONT SHOCK ABSORBER)	TATA spare parts
218532400101	ASSY REAR SPRING	TATA spare parts
218532406503	M20 X 2.5 NYLOC NUT	TATA spare parts
218532407101	FIRST LEAF	TATA spare parts
218532407102	SECOND LEAF	TATA spare parts
218532407103	THIRD LEAF	TATA spare parts
218532407104	FOURTH LEAF	TATA spare parts
218532407105	FIFTH LEAF	TATA spare parts
218532407106	SIXTH LEAF	TATA spare parts
218532407107	SEVENTH LEAF	TATA spare parts
218532504201	U CLAMP (FLAT TYPE)	TATA spare parts
218533103202	U CLAMP FRONT	TATA spare parts
218542300104	BRAKE DRUM LH W/O PLUMMER BLOCK	TATA spare parts
218542300105	BRAKE DRUM RH W/O PLUMMER BLOCK	TATA spare parts
218543200104	SUB.ASSY.AIR TANK(20LTR)LH AUXILLARY	TATA spare parts
218543900112	ASSY METAL PIPE WITH CRIMPED HOSE	TATA spare parts

218543900113	ASSY METAL PIPE 1ST(AC TO DDU)	TATA spare parts
218546200104	ASSY STG AND COWL MTG BKT RHD	TATA spare parts
218546306002	PITMAN ARM RH	TATA spare parts
218546600105	ASSY DRAG LINK COMPL.RHD	TATA spare parts
218546800105	ASSY PRESSURE LINE (PUMP TO GEAR BOX)	TATA spare parts
218546800106	ASSY RETURN LINE(GEAR BOX TO RES. TANK)	TATA spare parts
218546800107	ASSY SUCTION LINE(RES. TANK TO PUMP)	TATA spare parts
218547600106	ASSY.SUCTION LINE(TANK TO STRAINER)	TATA spare parts
218547600107	ASSY. RETURN LINE(ENGINE O/FLOW TO TANK)	TATA spare parts
218549100102	ASSY. SILENCER WITH SHORT TAIL PIPE	TATA spare parts
218549200106	ASSY EXHAUST PIPE (END)	TATA spare parts
218549200109	ASSY. EXHAUST PIPE(FRONT)	TATA spare parts
218549200110	ASSY. EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
218549207102	BRACKET FOR CLMAPING INT PIPE	TATA spare parts
218549207104	L BRACKET(FOR EXHAUST)	TATA spare parts
218549207105	BRACKET(FOR EXHAUST)	TATA spare parts
218550000101	ASSY. RAD. MTG. FRAME(COMPL.)	TATA spare parts
218550008201	GUSSET(RAD. FRAME MTG.)	TATA spare parts
218550100102	SET AUX WATER TANK WITH BRKT	TATA spare parts
218550105801	RUBBER HOSE (ENG TO RAD)	TATA spare parts
218550105803	RUBBER HOSE(WATER FILL LINE)	TATA spare parts
218554100102	ASSY.BATTERY CABLE 3750MM -VE 50SQ.MM-TM	TATA spare parts
218554100103	ASSY.BATT.CABLE 50SQMM BOTH SIDE LUG-L37	TATA spare parts
218554209901	ELET.S.M.WI.LCD ODO.M.24V(1:0.85)FOR LPO	TATA spare parts
218554209902	REMOTE BATTERY CUT-OFF SW. 24V	TATA spare parts
218554400103	HEAD LAMP LOW BEAM LH-LPO 918	TATA spare parts
218554400104	HEAD LAMP LOW BEAM RH-LPO 918	TATA spare parts
218554401601	ASSY WARNING LAMP IND.(24V)	TATA spare parts
218554401602	ASSY WARNING LAMP IND.(24V)	TATA spare parts
218554630101	W/H MAIN LPO918/42WB SA BSII 24V RHD	TATA spare parts
218554630102	W/H ENGINE LPO918/42WB BSII 24V RHD	TATA spare parts
218554630103	W/H TAIL LPO918/42WB BSII 24V RHD	TATA spare parts
218554630104	W/H INST. CONSOLE LPO918/42WB BSII 24V	TATA spare parts
218554630105	W/H MAXI FUSE & BATT. CUT OFF SW. LPO918	TATA spare parts
218560000109	COWL SHELL PAINTED RHD	TATA spare parts
218589100101	ASSY CAB MTG BRKT REAR	TATA spare parts
218589100103	ASSY MTG BKT FRT LH (FOR RHD)	TATA spare parts
218609136901	PIPE (100 ODX100 LONG )	TATA spare parts
218620159901	STOPPER BRACKET (SWING ARM ASSY)	TATA spare parts
218624203303	ENGINE MTG BKT RH REAR	TATA spare parts
218624203304	ENGINE MTG BKT LH REAR	TATA spare parts
218626000102	ASSY.KIT GEAR SHIFT CABLES	TATA spare parts
218626000103	ASSY PGS KIT10M LGTH CBLE+FITTINGVOITH	TATA spare parts
218626800107	SHIFTER CABLE ASSY.-10 M	TATA spare parts
218626800108	TRANSMISSION HANDLE ASSY	TATA spare parts
218627000102	ASSY KIT AUTO TRANS	TATA spare parts
218627208201	ACCUMULATORMTG BKT REAR	TATA spare parts

218627208202	ACCUMULATOR MTG BKT FRONT	TATA spare parts
218627600104	HOSE ASSY TRANS TO OIL COOLER	TATA spare parts
218627600105	HOSE ASSY COOLER TO TRANS	TATA spare parts
218627700101	ASSY SHIFT LEVER MTG BKT T-270R(ALLISON)	TATA spare parts
218627706001	SELECTOR SHIFT (4LLRF)	TATA spare parts
218627706002	MTG BKT (RETARDER CONTROL LEVER)	TATA spare parts
218629100101	ASSY HOSE CLUTCH MASTER TO RES TANK	TATA spare parts
218629100115	ASSY PIPE SECOND	TATA spare parts
218629805801	RUBBER HOSE.	TATA spare parts
218630100101	ASSY CABLE (ACCELERATOR) FOR HCBS	TATA spare parts
218630100107	ASSY PULL CABLE (ACCELERATOR)	TATA spare parts
218630100110	ACC. LEVER MTG BKT FRT	TATA spare parts
218630100111	ASSY. BKT. (ACC. CABLE HOLDING)	TATA spare parts
218630100112	ACC LEVER FRONT FOR HCBS CNG BS3 MT	TATA spare parts
218630100113	THRUST ROD	TATA spare parts
218630100114	ASSY CABLE ACCELERATOR	TATA spare parts
218630100115	ASSY. ACCELERATOR LEVER MOUNTING BRACKET	TATA spare parts
218630100116	SPRING MTG BKT-ACCELERATOR(ENGINE SIDE)	TATA spare parts
218630100117	ACC THRUST ROD ASSY	TATA spare parts
218630100119	ACC BEL CRANK ASSY WITH MTG PIN	TATA spare parts
218630100120	ASSY STOPPER BRACKET	TATA spare parts
218630100121	ASSY PEDAL COMPLETE	TATA spare parts
218630100123	ASSY CABLE ACCELERATOR	TATA spare parts
218630100124	BRACKET-FLOOR TO STOPPER BKT	TATA spare parts
218630100125	BRACKET-FLOOR TO PEDAL ASSY	TATA spare parts
218630100127	AFICD MTG BKT LOWER	TATA spare parts
218630106001	THRUST ROD DIA 8	TATA spare parts
218630106701	PIN BELL CRANK LEVER	TATA spare parts
218630108203	CLUTCH PEDAL LEVER BKT ( AFICD MTG )	TATA spare parts
218630108204	CLUTCH PEDAL SUPPORT BKT ( AFICD MTG )	TATA spare parts
218630108205	AFICD MTG L BKT	TATA spare parts
218630108701	SPRING(FOR BELLCRANK LEVER RETURN)	TATA spare parts
218630108703	SPRING FOR BELL CRANK LEVER RETURN	TATA spare parts
218630108704	SPRING FOR BELL CRANK LEVER RETURN	TATA spare parts
218630108706	SPRING -ACCL. PEDAL	TATA spare parts
218630109909	ADOPTER M12X1/8INCH BSP	TATA spare parts
218630109910	REINFORCEMENT BKT DRIVER STATION - AFICD	TATA spare parts
218630109911	REINFORCEMENT BKT- I DRIVER ST- AFICD	TATA spare parts
218630109912	REINFORCEMENT BKT-II DRIVER ST-AFICD	TATA spare parts
218630109914	M12X1.5 UNION NUT	TATA spare parts
218630109915	6MM BRASS OLIVE	TATA spare parts
218630109916	NYLON TUBE	TATA spare parts
218630506301	ACC.PEDEL RUBBER BOOT	TATA spare parts
218630508201	RETAINER PLATE	TATA spare parts
218630990101	BALL JOINT	TATA spare parts
218630997801	BELLOWS	TATA spare parts
218631100105	ASSY BUMPER BKT (LH)	TATA spare parts

218631100106	ASSY BUMPER BKT (RH)	TATA spare parts
218631100107	ASSY. BUMPER BKT. RH	TATA spare parts
218631100117	ASSY. 3RD CROSS MEMBER REINFORCEMENT	TATA spare parts
218631100118	LONGITUDINAL REINFORCEMENT	TATA spare parts
218631100124	ASSY LONG MEMBER LH	TATA spare parts
218631100125	ASSY SUPPORT LH BELLOW MTG BKT	TATA spare parts
218631100127	ASSY RH LONG MEMBER	TATA spare parts
218631107120	SIDE RIB	TATA spare parts
218631107121	SIDE RIB	TATA spare parts
218631108206	STIFFNER PLATE	TATA spare parts
218631200106	ASSY BELLOW MTG BKT RH(FRT MOD)	TATA spare parts
218631200107	ASSY BELLOW MOUNTING BRACKET LH	TATA spare parts
218631200111	ASSY STG G.BOX MTG BKT	TATA spare parts
218631200112	ASSY.SUPPORT ENG.CROSS MEMBER COMPLETE.	TATA spare parts
218631200114	ASSY RH V ROD MTG BKT	TATA spare parts
218631200121	ASSY BUMPER CROSS MEMBER	TATA spare parts
218631200122	ASSY BEVEL GEAR BOX MTG. BKT.	TATA spare parts
218631200123	ASSY LH V ROD MRG BKT	TATA spare parts
218631200131	END PEICE(RH) VERTICAL	TATA spare parts
218631200132	END PEICE(LH) VERTICAL	TATA spare parts
218631200135	FR BUMERASSY(CHASSIS PART)	TATA spare parts
218631200137	ASSY END CROSS MEMBER FRT LH	TATA spare parts
218631200138	ASSY END CROSS MEMBER FRT RH	TATA spare parts
218631200139	ASSY CHANNEL END CROSS MBR(FRT MOD)	TATA spare parts
218631200140	ASSY REAR OUTRIGGER RH	TATA spare parts
218631200141	ASSY REAR OUTRIGGER LH	TATA spare parts
218631200142	ASSY FRONT OUTRIGGER RH	TATA spare parts
218631200143	FR OUT RIGGER LHS	TATA spare parts
218631200144	ASSY 2 ND CROSS MBR MTG BKT RH	TATA spare parts
218631200145	ASSY BOTTOM REINFORCEMENT SHEET	TATA spare parts
218631200146	ASSY TOW HOOK MTG BKT FRONT	TATA spare parts
218631200147	TOWING HOOK	TATA spare parts
218631200148	ASSY FRT BUMPER WITH TOW HOOK MTG	TATA spare parts
218631200151	ASSY V ROD MTG BKT FRT RH	TATA spare parts
218631200180	ASSY PARALLEL ROD MTG BKT -LH	TATA spare parts
218631200181	ASSY PARALLEL ROD MTG BKT -RH	TATA spare parts
218631203304	2ND CROSS MEMBER MTG BKT LH	TATA spare parts
218631207137	SUPPORT BELLOW MTG. BKT. FRONT	TATA spare parts
218631207138	ANGLE SUPPORT (FOR BELLOW MTG BKT FRONT)	TATA spare parts
218631207149	SECOND CROSS MEMBER (F/M)	TATA spare parts
218631207175	VERTICAL SUPPORT ( AIR SPRING)	TATA spare parts
218631207176	VERTICAL PLATE (BELLOW-PRLL ROD MTG BKT)	TATA spare parts
218631207177	COVER PLATE (BELLOW & PARLL ROD MTG BKT)	TATA spare parts
218631207180	2ND CHANNEL (CROSS SUPPORT)	TATA spare parts
218631207204	V ROD MTG BLOCK-1 FRT RH	TATA spare parts
218631207205	V-ROD MTG BLOCK-2 FRT - RH	TATA spare parts
218631207206	REINFORCEMENT PLATE-I V ROD MTG FRT RH	TATA spare parts

218631207207	REINFORCEMENT PLATE-II V ROD MTG FRT RH	TATA spare parts
218631217108	W/H HOLDING BKT FRONT MODULE	TATA spare parts
218631217109	COVER PLATE	TATA spare parts
218631217110	COVER PLATE	TATA spare parts
218631217111	SUPPORT ENG CROSS MEMBER	TATA spare parts
218631300101	ASSY CHANNEL (CROSS SUPPORT)	TATA spare parts
218631300102	ASSY CHANNEL (CROSS SUPPORT)	TATA spare parts
218631300105	ASSY KNEELING CROSS MEMBER	TATA spare parts
218631307130	LONGITUDINAL REINFORCEMENT LEFT	TATA spare parts
218631307131	LONGITUDINAL REINFORCEMENT CENTER	TATA spare parts
218631307132	LONGITUDIANL REINFORCEMENT RIGHT	TATA spare parts
218631708205	BKT CLUTCH HOSE MTG	TATA spare parts
218631708214	PIPE LINE CLAMPING BKT	TATA spare parts
218631708216	BKT ON CLUTCH HOUSING	TATA spare parts
218631708224	BKT PARTITION	TATA spare parts
218631708242	INTER COOLER CLAMP BKT	TATA spare parts
218632100101	ASSY.KIT FOR SUSPENSION	TATA spare parts
218632100103	ASSY BELLOW FOR FRT AXLE	TATA spare parts
218632100104	ASSY SHOCK ABSORBER FOR FRT AXLE	TATA spare parts
218632100107	ASSY KNEELING KIT	TATA spare parts
218632107101	LINK (CONNECTING ROD ASSY)	TATA spare parts
218632107102	LINK (CONNECTING ROD ASSY)	TATA spare parts
218632107501	RUBBER BUSH	TATA spare parts
218632107502	RUBB BUSH BET VALVE CONNE ROD TO CON.LIN	TATA spare parts
218632300101	ASSY CONNECTING LINK(FOR SUSP LEVELLING)	TATA spare parts
218632400101	ASSY KIT FOR SUSP	TATA spare parts
218632400103	PARALLEL LINK ASSY RH	TATA spare parts
218632400104	PARALLEL LINK ASSY RH	TATA spare parts
218632400106	ASSY. AIR SPRING BS3/4	TATA spare parts
218632400108	BRACKET ASSY REAR AIR SPRING RH	TATA spare parts
218632400109	ANTI ROLL BAR ASSY	TATA spare parts
218632400110	PARALLEL LINK PIVOT - LH	TATA spare parts
218632400113	HANGER LINK BKT - LH	TATA spare parts
218632400114	HANGER LINK BKT - RH	TATA spare parts
218632400122	RUBBER CONNECTOR-SUB ASSY	TATA spare parts
218632400125	LINK PULLER(TAPPER PIVOT JOINT)_	TATA spare parts
218632400129	NRV & AIR FILTER ASSY	TATA spare parts
218632400131	ASSY REAR AIR SPRING CROSS MEMBER	TATA spare parts
218632400134	RADIUS ROD ASSY	TATA spare parts
218632400135	REAR AIR SPRING BKT ASSY - LH	TATA spare parts
218632400141	METRIC TO VOSS ADAPTOR M14X1.5 NG8	TATA spare parts
218632400144	ASSY NYLON CLUSTER COMPLTET-VOSS FITTINS	TATA spare parts
218632403202	HEX BOLT M16X2X120MM	TATA spare parts
218632403301	LEVELING VALVE BKT - LH	TATA spare parts
218632403302	LEVELING VALVE BKT FRONT	TATA spare parts
218632404201	T CONNECTOR CLAMP	TATA spare parts
218632404801	COWHORN DOWEL	TATA spare parts

218632406502	HEX NUT	TATA spare parts
218632406503	M16X2 HEX NUT	TATA spare parts
218632406506	M24X3 CASTLE NUT	TATA spare parts
218632406510	U CLAP NUT(M22X2.5)	TATA spare parts
218632406701	3/16IN X 2 1/2IN SPLIT PIN	TATA spare parts
218632406804	M12X1.5 T CONNECTOR	TATA spare parts
218632406807	BULK HEAD ELBOW- M12X1.5 X L6	TATA spare parts
218632406808	BULK HEAD ELBOW- M10X1 X L6	TATA spare parts
218632406901	CROSS LINK	TATA spare parts
218632407101	FLITCH-LH	TATA spare parts
218632407102	FLITCH - RH	TATA spare parts
218632407103	REAR FLITCH LH	TATA spare parts
218632407104	REAR FLITCH - RH	TATA spare parts
218632407105	C-FLITCH (FRONT) LH	TATA spare parts
218632407106	C-FLITCH FRONT RH	TATA spare parts
218632407109	SHOCK ABSORBER CLAMP	TATA spare parts
218632407123	M16 SPRING WASHER	TATA spare parts
218632407702	ROLLING DIAPHRAGM 12 INCH (REAR AIR SUSP	TATA spare parts
218632407702DF	BELLOW RUBBER - REAR AIR SUSPENSION	TATA spare parts
218632409207	MACHINED WASHER (M24)	TATA spare parts
218632409209	SPHERICAL WASHER (M22)	TATA spare parts
218632600101	HEX BOLT V-ROD MOUNTING	TATA spare parts
218632800101	ASSY FRONT ANTI ROLL BAR	TATA spare parts
218632800102	ASSY. BALL JOINT FOR FRONT ARB	TATA spare parts
218632807101	CLAMP FRONT ANTI ROLL BAR	TATA spare parts
218632807701	BUSH FRONT ANTI ROLL BAR	TATA spare parts
218632808201	SPACER FRT ANTI ROLL BAR	TATA spare parts
218632808202	SPACER FOR ARB CLAMP	TATA spare parts
218633000106	ASSY FRT AXLE	TATA spare parts
218633100101	ASSY TIE ROD	TATA spare parts
218633100102	DISC BRAKE	TATA spare parts
218633100103	DISC BRAKE	TATA spare parts
218633100104	DISCBRAKE	TATA spare parts
218633100115	BALL JOINT RH	TATA spare parts
218633100116	BALL JOINT LH	TATA spare parts
218633100117	ADJUST KIT	TATA spare parts
218633100118	BRAKE LINE KIT	TATA spare parts
218633100119	BRAKE CYLINDER	TATA spare parts
218633100120	BRAKE CYLINDER	TATA spare parts
218633100121	GREASE	TATA spare parts
218633100122	SHOCK ABSORBER	TATA spare parts
218633100123	IMPULSE DISC	TATA spare parts
218633103001	BALL JOINT RH	TATA spare parts
218633103002	BALL JOINT LH	TATA spare parts
218633103124	AX.ROLLER BEARING	TATA spare parts
218633103125	ROLLER BEARING	TATA spare parts
218633103126	ROLLER BEARING	TATA spare parts

218633103127	TAPER ROLLER BRG 32309	TATA spare parts
218633103128	TAPER ROLLER BRG 534565/52898	TATA spare parts
218633103202	WHEEL BOLT	TATA spare parts
218633103204	HEXAGON SCREW M18X1.5X60	TATA spare parts
218633103301	BRAKE CARRIER	TATA spare parts
218633105101	FRONT AXLE BEAM	TATA spare parts
218633105102	SPRING CARRIER RH	TATA spare parts
218633105103	SPRING CARRIER LH	TATA spare parts
218633105104	FIXING DEVICE	TATA spare parts
218633106101	REPAIR KIT ADAPTOR	TATA spare parts
218633106301	SPRING BELLOWS	TATA spare parts
218633106302	BUFFER	TATA spare parts
218633106701	CYLINDRICAL PIN	TATA spare parts
218633106704	PIVOT PIN	TATA spare parts
218633107101	BRAKE DISC	TATA spare parts
218633107102	PULSE DISC	TATA spare parts
218633107601	BRAKE CYLINDER	TATA spare parts
218633107602	BRAKE CYLINDER	TATA spare parts
218633107701	SEAL KIT	TATA spare parts
218633107702	SEAL KIT	TATA spare parts
218633107703	BELLOWS	TATA spare parts
218633107704	LUBRICATING NIPPLE	TATA spare parts
218633107801	O RING	TATA spare parts
218633107804	SHAFT SEAL	TATA spare parts
218633107805	O-RING	TATA spare parts
218633107806	O-RING	TATA spare parts
218633107807	SEALING RING	TATA spare parts
218633107808	SHAFT SEAL	TATA spare parts
218633107901	TRACK ROD	TATA spare parts
218633107904	NEEDLE SLEEVE	TATA spare parts
218633108003	HEXAGON SCREW M18X1.5X60	TATA spare parts
218633108004	CAP BOLT M8 X 12	TATA spare parts
218633108005	CAP CREW M16X1.5X50	TATA spare parts
218633108006	CAP CREW M16X1.5X50	TATA spare parts
218633108007	CAP SCREW	TATA spare parts
218633108008	LOCK BOLT NUT	TATA spare parts
218633108009	CAP SCREW	TATA spare parts
218633108210	CLIP	TATA spare parts
218633108211	PNEUMAT.SPRING	TATA spare parts
218633108212	STRUT	TATA spare parts
218633108301	FRONT HUB THRUST WASHER	TATA spare parts
218633109205	DISC BRAKE	TATA spare parts
218633109206	DISC BRAKE	TATA spare parts
218633109207	BRAKE DISC	TATA spare parts
218633109904	FIXING DEVICE	TATA spare parts
218633109906	SEALING HOLDER	TATA spare parts
218633200101	ASSY STUB AXLE	TATA spare parts



218633206701	KING PIN	TATA spare parts
218633406501	LOCKING NUT M16 X 1.5	TATA spare parts
218633800101	ASSY TIE ROD	TATA spare parts
218633805101	STEERING ARM RH	TATA spare parts
218633805102	TIE ROD ARM RH	TATA spare parts
218633805103	TIE ROD ARM LH	TATA spare parts
218633993401	STOP BUSH	TATA spare parts
218633995501	FRONT HUB	TATA spare parts
218633996101	WASHER	TATA spare parts
218633996102	WASHER	TATA spare parts
218633996103	WASHER	TATA spare parts
218633996104	STOP WASHER	TATA spare parts
218633996501	CASTLE NUT	TATA spare parts
218633996502	FRONT HUB LOCKING NUT	TATA spare parts
218633996503	LOCKING NUT M16 X 1.5	TATA spare parts
218633998001	HEX SCREW ( TIE ROD ARM )	TATA spare parts
218633998002	HEX SCREW ( STEERING ARM )	TATA spare parts
218633998003	STOP SCREW	TATA spare parts
218633999902	REPAIR KIT	TATA spare parts
218633999903	REPAIR KIT	TATA spare parts
218640100101	ASSY.WHEEL NUT (M22 X 1.5)	TATA spare parts
218640100103	ASSY WHEEL RIM & VALVE COMPLETE	TATA spare parts
218640100104	TPMS INSTRUMENT KIT	TATA spare parts
218640100105	WHEEL RIM ASSY WITH VALVE	TATA spare parts
218640100116	WHEEL RIM ASSY WITH VALVE	TATA spare parts
218640100118	WHEEL RIM ASSY WITH VALVE&BS6	TATA spare parts
218640100120	ALLOY WHEEL ASSY	TATA spare parts
218640100125	WHEEL RIM ASSY WITH VALVE	TATA spare parts
218640109946	TUBELESS TYRE 295/80 R22.5	TATA spare parts
218641100101	ASSY.PROPELLER SHAFT COMPLETE	TATA spare parts
218641100102	ASSY.PROPELLER SHAFT COMPLETE	TATA spare parts
218641100103	ASSY. PROPELLER SHAFT (GUARD)	TATA spare parts
218641100104	ASSY. U-BRACKET	TATA spare parts
218642150101	KIT ASSY NYLON PIPES & CLAMPSLPO 1623/62	TATA spare parts
218642910101	NON-RETURN VALVE	TATA spare parts
218643107701	COVER(FOR BRAKE PEDAL)	TATA spare parts
218643506803	MALE COUPLING BODY(COMP. OEM CONN.)	TATA spare parts
218643700101	ASSY QRV BKT RR	TATA spare parts
218643700102	ASSY CONSEPMTG BKT	TATA spare parts
218643703303	BRACKET RELAY VALVE MTG	TATA spare parts
218643900101	ASSY PNEU. PIPE OD 15X1.5 THK(1510MM LON	TATA spare parts
218643900102	ASSY PNEU. PIPE OD 15X1.5 THK(1517MM LON	TATA spare parts
218643900103	ASSY PIPE ( 12 X 1 ) TESTCONN TO RV SIGN	TATA spare parts
218643900106	STEEL PIPE DIA. 6	TATA spare parts
218643900110	ASSY PIPE ( 15 X 1.5 ) REARTNK TO RV SUP	TATA spare parts
218643900111	ASSY PIPE ( 12 X 1 ) RV TO MV REAR R	TATA spare parts
218643900112	ASY PIPE4 OD12X1 TEST CONN. T TO RV SIG	TATA spare parts

218643900114	ASY PIPE OD 15X1.5 CONSEP TO AIR DRIER	TATA spare parts
218643900115	ASY PIPE OD 12X1 AIRDRIER TO PURGE TANK	TATA spare parts
218643900116	ASY PIPE OD 15X1.5 AIRDRIER TO SPV	TATA spare parts
218643900117	ASY PIPE OD 12 X 1 SPV21 TO REAR TANK	TATA spare parts
218643900118	ASY PIPE OD 12X1 AIRTANK REAR TO DBV P11	TATA spare parts
218643900119	ASY PIPE OD 12X1 DBV P21 TO TEST CON.TEE	TATA spare parts
218643900120	ASY PIPE OD 6X.7 TEE TO TEST CONNECTOR	TATA spare parts
218643900121	ASY PIPE1 OD12X1 TEST CONN. TO RV SIGNAL	TATA spare parts
218643900122	ASY PIPE OD 12X1 RV DELIVARY TO MV RRLH	TATA spare parts
218643900123	ASY PIPE1 OD 15X1.5 AIT TANK REAR TO RV	TATA spare parts
218643900124	ASY PIPE OD 12X1 AIRTANK FRT. TO DBV P12	TATA spare parts
218643900125	ASY PIPE1 OD 12X1 DBV P22 TO QRV	TATA spare parts
218643900126	ASY PIPE3 OD 12X1 DBV P22 TO QRV	TATA spare parts
218643900127	ASY PIPE5 OD12X1 TEST CONN. TO RV SIG	TATA spare parts
218643900128	ASY PIPE4 OD 12X1 HAND BRAKE V TO QRV HS	TATA spare parts
218643900129	ASY PIPE5 OD 12X1 HAND BRAKE V TO QRV HS	TATA spare parts
218643900130	ASY PIPE2 OD15X1.5 SPV24 TO SUSP TNK TEE	TATA spare parts
218643900131	ASY PIPE5 OD 15X1.5 AIR TANK REAR TO RV	TATA spare parts
218643900132	ASY PIPE2 OD 15X1.5 AIR TANK REAR TO RV	TATA spare parts
218643900133	ASY PIPE2 OD 12X1 HAND BRAKE V TO QRV HS	TATA spare parts
218643900134	ASY PIPE 12X1 QRV TO PARTING BKT MV FRLH	TATA spare parts
218643900135	ASY PIPE 12X1 QRV TO PARTINGBKT MV FR RH	TATA spare parts
218643900136	ASY PIPE OD 6X.7 SPV P23 TO HAND BRAKE V	TATA spare parts
218643900137	ASY PIPE1 OD 12X1 HAND BRAKE V TO QRV HS	TATA spare parts
218643900138	ASY PIPE2 OD12X1 TEST CONN.T TO RV SIG	TATA spare parts
218643900139	ASY PIPE3 OD 12X1 HAND BRAKE V TO QRV HS	TATA spare parts
218643900140	ASY PIPE6 OD 12X1 HAND BRAKE V TO QRV HS	TATA spare parts
218643900141	ASY PIPE3 OD12X1 TEST CONN.T TO RV SIG	TATA spare parts
218643900142	ASY PIPE2 OD 12X1 DBV PORT22 TO QRV	TATA spare parts
218643900143	ASY PIPE OD 15X1.5 QRV TO BRAKE CHAM. LH	TATA spare parts
218643900144	ASY PIPE OD 15X1.5 QRV TO BRAKE CHAM. RH	TATA spare parts
218643900145	ASY PIPE7 OD15X1.5 SPV24 TO SUSP TNK TEE	TATA spare parts
218643900146	ASSY PIPE OD 15X1.5 RET.TANL TO UNION	TATA spare parts
218643900147	ASY PIPE5 OD15X1.5 SPV24 TO SUSP TNK TEE	TATA spare parts
218643900148	ASY PIPE1 OD15X1.5 SPV24 TO 30L SUSP TNK	TATA spare parts
218643900149	ASY PIPE3 OD15X1.5 SPV24 TO SUSP TNK TEE	TATA spare parts
218643900150	ASY PIPE4 OD15X1.5 SPV24 TO SUSP TNK TEE	TATA spare parts
218643900151	ASY PIPE OD15X1.5 SUSP TNK TO AUX TNK T	TATA spare parts
218643900152	ASY PIPE OD15X1.5 AUX TNK TO RETARD. TNK	TATA spare parts
218643900153	ASSY PIPE ( UNION TO PROP VALVE )	TATA spare parts
218643900154	ASSY PIPE ( SPV 24 TO SUSPEN SAIS TNK TE	TATA spare parts
218643900155	ASSY PIPE ( 15 X 1.5 ) AIR TANK REAR TO	TATA spare parts
218643900156	ASSY PIPE ( 15 X 1.5 ) AIR TANK REAR TO	TATA spare parts
218643900199	ASSY HOSE 3/8 INCH	TATA spare parts
218643900201	ASSY HOSE FILTER TO AIR COMP	TATA spare parts
218643903301	SUPPORT BRACKET	TATA spare parts
218643903302	SUPPORT BRKT	TATA spare parts

218643903304	SUPPORT BRKT	TATA spare parts
218643903305	SUPPORT BRKT	TATA spare parts
218643903307	W/HARNESS BKT	TATA spare parts
218643903311	SUPPORT BRACKET (COMP. OUTLET PIPE)	TATA spare parts
218643903312	SUPPORT BRACKET(COMP. OUTLET PIPE)	TATA spare parts
218643903313	SUPPORT BRACKET	TATA spare parts
218643906806	TEE SOCKET M12XM6XM6 (TUBE ENDS)	TATA spare parts
218643910103	ASSYPIPE 1A OD12X1TESTCONN TO RV SIGNAL	TATA spare parts
218643910105	ASSY PIPE 2A OD12X1 DBV PORT22 TO QRV FR	TATA spare parts
218643910106	ASSY PIPE2 OD 6X.7 SPV23 TO HAND BRAKE	TATA spare parts
218643910109	ASSY PIPE ( 15 X 1.5 ) SPV 24 TO SUS TNK	TATA spare parts
218643910110	ASSY PIPE1A OD15X1.5 REARTNK TO RVSUPPLY	TATA spare parts
218643910112	ASSY HOSE 3/8INCH	TATA spare parts
218643910113	ASSY. BRACKET (MODULATOR VALVE MOUNTING	TATA spare parts
218643910114	ASY PIPE1 OD18X1.5 COMP-HOSE TO CONSEP	TATA spare parts
218643910115	ASY PIPE4 OD 18X1.5 COMP-HOSE TO CONSEP	TATA spare parts
218643910116	ASY PIPE5 OD 18X1.5 COMP-HOSE TO CONSEP	TATA spare parts
218643910117	ASY PIPE6 OD 18X1.5 COMP-HOSE TO CONSEP	TATA spare parts
218643910118	ASY PIPE OD 18X1.5 CONSEP TO AIR DRIER	TATA spare parts
218643910119	ASSY PIPE2 OD 18X1.5 COMP HOSE TO CONSE	TATA spare parts
218643910120	ASSY PIPE 3 OD18X1.5 COMPHOSE TO CONSEP	TATA spare parts
218643910121	ASSY PIPE 6DOX0.75 T TO PRES SWITCH RELS	TATA spare parts
218643910122	ASSY PIPE 18ODX1.5THK COMP TO HOSE	TATA spare parts
218643910126	ASSY PIPE 12ODX1THK AUX TNK TO PG TEE	TATA spare parts
218643910127	ASSY PIEP 6DOX.7 THK PG TEE TO PG	TATA spare parts
218643910128	ASSY NYLON PIPE DTV TO PRESS. GAUGE	TATA spare parts
218643990104	ASSY KIT ABS	TATA spare parts
218643998501	CONNECTOR BKOCK	TATA spare parts
218646207902	SPINDLE (BEVEL GEARBOX TO STG.GEAR BOX).	TATA spare parts
218646306001	PITMAN ARM	TATA spare parts
218646600101	ASSY DRAG LINK	TATA spare parts
218646600102	STG G.BOX ASSY	TATA spare parts
218646600103	ASSY VANE PUMP	TATA spare parts
218646600104	ASSY BEVEL G.BOX	TATA spare parts
218646600106	ASSY DRAG LINK	TATA spare parts
218646600107	ASSY VANE PUMP	TATA spare parts
218646603415	GREASE NIPPLE (FOR DIA. 35 BALL JOINT)	TATA spare parts
218646603416	GREASE NIPPLE ( FOR DIA. 40 BALL JOINT)	TATA spare parts
218646603417	DUST COVER (FOR 35 DIA. BALL JOINT)	TATA spare parts
218646603418	DUST COVER (FOR 40 DIA. BALL JOINT)	TATA spare parts
218646603419	SLOTTED NUT ( FOR DIA. 35 BALL JOINT)	TATA spare parts
218646603420	SLOTTED NUT( FOR DIA. 40 BALL JOINT)	TATA spare parts
218646604701	HOUSING	TATA spare parts
218646800101	HOSE ASSY(G/B TO TANK)	TATA spare parts
218646800102	HOSE ASSY(TANK TO VANE PUMP)	TATA spare parts
218646800103	HOSE ASSEMBLY(PUMP TO STG G/BOX)	TATA spare parts
218646990101	RH THREADED END REPAIR KIT	TATA spare parts

218646990102	GROOVED END REPAIR KIT	TATA spare parts
218647500104	ASSY BKT LP FILTER MTG	TATA spare parts
218647500115	ASSY BRACKET MTG SOLENOID VALVE	TATA spare parts
218647500118	ASSY BRKT MTG SOLEN	TATA spare parts
218647503301	L-CLAMP(1/2INC OD CNG PIPE)	TATA spare parts
218647503302	CLAMP VENT PIPE	TATA spare parts
218647508203	CLAMP SUPPORT 1/2INCH TUBE	TATA spare parts
218647508204	BRKT CLAMP CNG PIPE	TATA spare parts
218647508205	BRKT CLAMP CNG PIPE	TATA spare parts
218647508206	BRKT CLAMP CNG PIPE	TATA spare parts
218647508207	DOUBLE CLAMP SUPPORT PLATE	TATA spare parts
218647509901	COMPLIANCE PLATE	TATA spare parts
218647509915	SAFETY INSTRUCTIONS IN HINDI (CBG BUS)	TATA spare parts
218647510102	ASSY CAP - RECEPTICAL	TATA spare parts
218647600101	OMB CYLINDER VALVE 1IN	TATA spare parts
218647600102	RECPTICLE 1/2 INCH OD -WEH	TATA spare parts
218647600103	HP GAUGE PANEL MOUNTED	TATA spare parts
218647600104	1/4 CHECK VALVE WEH	TATA spare parts
218647600105	HIGH PRESSURE SOLENOID VALVE (24V)	TATA spare parts
218647600106	ASSY. HOSE 1/2 INCH HPR TO LPF	TATA spare parts
218647600107	ASSY. HOSE 1/2 INCH LPF TO ENGINE	TATA spare parts
218647600108	ASSY CHECK VALVE 1/4 IN OD X1/4 IN NPT M	TATA spare parts
218647600133	ASY FERRULE SET 1/2INC (SS-810-SET)	TATA spare parts
218647604201	CLAMP CNG TUBE (1/2 INCH)	TATA spare parts
218647606101	TAB WASHER B 23 IS	TATA spare parts
218647606102	TAB WASHER B 28 IS :8068	TATA spare parts
218647606801	MALE CONN 3/4 THREAD SAE (O RING) X 1/4	TATA spare parts
218647606803	1/2 NPTX 1/2 OD CONNECTOR	TATA spare parts
218647606804	REDUCING UNION TEE 1/2 OD	TATA spare parts
218647606805	1/4 NPT FEMALE X 1/4 OD CONNECTOR	TATA spare parts
218647606806	UNION 1/2 OD X 1/2 OD	TATA spare parts
218647606807	UNION TEE 1/2 OD X 1/2 OD X 1/2 OD	TATA spare parts
218647606808	REDUCER 1/2 OD X 1/4 OD	TATA spare parts
218647606816	ELBOW 3/8IN NPT X M12	TATA spare parts
218647606827	TUBE ADAPTOR 1/4 OD X 1/4 NPT MALE	TATA spare parts
218647606828	NUT 1/2INC FRACTIONAL (SS-812-1)	TATA spare parts
218647606831	REDUCING PORT CONNECTOR 1/2IN OD X1/4INO	TATA spare parts
218647606925	HP GAS TUBE 1/2IN OD-.049THK WITH PVC SL	TATA spare parts
218647606926	HP GAS TUBE 1/2 IN OD-.049THK WITH PVCSL	TATA spare parts
218647606927	HP GAS TUBE 1/2IN OD-.049THK WITH PVCSLE	TATA spare parts
218647606928	HP GAS TUBE 1/2IN OD-.049THK WITH PVCSLE	TATA spare parts
218647606929	HP GAS TUBE 1/2IN OD-.049THK WITH PVCSLE	TATA spare parts
218647606930	HP GAS TUBE 1/4IN OD WITH PVC SLEEVE	TATA spare parts
218647606934	HP GAS TUBE 1/4IN OD WITH PVC SLEEVE	TATA spare parts
218647606935	HP GAS TUBE 1/4IN OD WITH PVC SLEEVE	TATA spare parts
218647606936	HP GAS TUBE 1/4IN OD WITH PVC SLEEVE	TATA spare parts
218647606937	HP GAS TUBE 1/4IN OD WITH PVC SLEEVE	TATA spare parts

218647606939	HP GAS TUBE 1/4IN OD WITH PVC SLEEVE	TATA spare parts
218647606941	HP GAS TUBE 1/4IN OD WITH PVC SLEEVE	TATA spare parts
218647606942	HP GAS TUBE 1/2IN OD WITH PVC SLEEVE	TATA spare parts
218647606944	HP GAS TUBE 1/4 IN OD WITH PVC SLEEVE	TATA spare parts
218647606947	HP GAS TUBE 1/4INOD WITH PVC SLEEVE	TATA spare parts
218647606960	25 OD MS TUBE	TATA spare parts
218647608201	CLAMP PLATE (1/2INCH CNG TUBE)	TATA spare parts
218647609901	PROTECTIVE COVER (HPR TO VLPF)	TATA spare parts
218647609902	PROTECTIVE COVER (VLPF TO CLPF)	TATA spare parts
218647609903	CORRUGATED TUBE	TATA spare parts
218647609904	PROTECTIVE COVER (CLPF TO ENGINE INLET)	TATA spare parts
218647609905	PROTECTIVE COVER (HPR OUTLET TO ENGINE)	TATA spare parts
218647609906	PROTECTIVE COVER (ENGINE OUTLET TO HPR)	TATA spare parts
218647609911	PVC SLEEVE	TATA spare parts
218647609917	DECAL FOR 3WAY VALVE	TATA spare parts
218647610119	ASSY HOSE (HPR TO VLPF)	TATA spare parts
218647610120	ASSY. VENT PIPE	TATA spare parts
218647610121	ASSY COOLANT HOSE(HPR TO ENGINE INLET)	TATA spare parts
218647610122	ASSY COOLANT HOSE (ENGINE OUTLET TO HPR)	TATA spare parts
218647610123	ASSY HOSE (VLPF TO CLPF)	TATA spare parts
218647610124	ASSY HOSE (CLPF TO FUEL INLET ON ENGINE)	TATA spare parts
218647610128	ASSY PIPE 12 DIA	TATA spare parts
218647610129	ASSY PIPE 12 DIA	TATA spare parts
218647610130	ASSY PIPE 22 DIA	TATA spare parts
218647610131	ASSY PIPE 22 DIA	TATA spare parts
218647610132	ASSY PIPE 22 DIA	TATA spare parts
218647610133	ASSY PIPE 22 DIA	TATA spare parts
218647610135	ASSY. HOSE (HPR TO COOLANT LINE)	TATA spare parts
218647610136	ASSY PIPE 12ODX1 THK	TATA spare parts
218647610137	ASSY PIPE 12 OD X1THK	TATA spare parts
218647610138	11SY PIPE 22OD	TATA spare parts
218647610139	ASSY PIPE 22 OD	TATA spare parts
218647610140	ASY PIPE OD 22	TATA spare parts
218647610141	ASSY PIPE 22 OD	TATA spare parts
218647610143	ASSY. 2 OD PIPE	TATA spare parts
218647610145	ASSY HOSE (HPR COOLANT LINE)	TATA spare parts
218647610146	ASSY PIPE 22 OD	TATA spare parts
218647610147	ASSY PIPE 12 OD X 1THK	TATA spare parts
218647610148	ASSY VENT PIPE 22OD - AC BUS	TATA spare parts
218647700101	ASSY HPR (BS III)	TATA spare parts
218647700103	ASSY. HP FILTER WITH CARTRIDGE	TATA spare parts
218647706801	CONNECTOR (VLPF OUTLET)	TATA spare parts
218647709901	HP FILTER CARTRIDGE	TATA spare parts
218647709902	INLET FILTER (SOLEND VALVE)	TATA spare parts
218647800101	ASSY BRACKET(ON LONG MEMBER)	TATA spare parts
218647910104	ASSY PIPE OD12X1 PARTING BKT TO MV FRONT	TATA spare parts
218647910107	ASY PIPE 2A OD 12X1 HAND BRAKE TO QRV HS	TATA spare parts

218647910108	ASSY PIPE ( 15 X 1.5 ) SPV 24 TO SUS TNK	TATA spare parts
218647994901	SOLENOID COIL	TATA spare parts
218647996801	TEFLON TAPE 1/4INCH	TATA spare parts
218647996802	LEAK DETECTOR	TATA spare parts
218647997701	LOW PRESSURE GAUGE RUBBER PLUG	TATA spare parts
218647997802	O-RING (FILT.SCREW PLUG)	TATA spare parts
218647997803	BACKUP O-RING	TATA spare parts
218647997804	O-RING (RECEPTACLE)	TATA spare parts
218647997805	O-RING (SOLEND INLT)	TATA spare parts
218647997806	CIRCLIP HP FILTER	TATA spare parts
218647997807	DRAIN PLUG O-RING	TATA spare parts
218647999902	GREASE	TATA spare parts
218649100101	ASSY HEAT SHEILD MUFFLER	TATA spare parts
218649100102	ASSY HEAT SHIELD MUFFLER	TATA spare parts
218649100103	ASSY HEAT SHIELD CATCON	TATA spare parts
218649100104	ASSY MTG BKT(CATCON HEAT SHEILD)	TATA spare parts
218649200105	ASSY SILENCER	TATA spare parts
218649200106	ASSY EXHAUST PIPE (FROM TC)	TATA spare parts
218649200109	CATCON HANGER BRACKET REAR	TATA spare parts
218649200110	ASSY. HANGER SILENCER FRONT	TATA spare parts
218649200111	ASSY. HANGER SILENCER REAR	TATA spare parts
218649200112	ASSY EXHAUST PIPE INTMD & REDUCER	TATA spare parts
218649200113	ASSY. BRACKET CATCON MOUNTING FRONT	TATA spare parts
218649206905	TAIL PIPE (SILENCER)	TATA spare parts
218649206909	TAIL PIPE	TATA spare parts
218649208201	EXHAUST CLAMP CATCON FRONT	TATA spare parts
218649208203	EXHAUST CLAMP	TATA spare parts
218649208206	CATCON HANGER BRKT FRT	TATA spare parts
218649208208	BRKT CATCON MTG RR	TATA spare parts
218649208209	EXHAUST CLAMP	TATA spare parts
218649208210	CLAMP (SILENCER)	TATA spare parts
218649208211	SILENCER MTG BRKT FRT	TATA spare parts
218649208212	SILENCER MOUNTING BRACKET REAR	TATA spare parts
218649208213	SILENCER MTG BRKT MIDDLE	TATA spare parts
218649208214	BRKT SILENCER CLAMP	TATA spare parts
218649208216	EXHAUST CLAMP(TAIL PIPE)	TATA spare parts
218650000101	ASSY KIT RADIATOR COMPLETE	TATA spare parts
218650000105	ASSY KIT RADIATOR COMPL.	TATA spare parts
218650000106	RADIATOR ASSY. WITH FRAME	TATA spare parts
218650000111	ASSY. KIT RADIATOR COMP	TATA spare parts
218650000116	ASSY KIT RADIATOR COMP.	TATA spare parts
218650000117	RADIATOR WITH FRAME	TATA spare parts
218650000117DF	RADIATOR-LPO1618DSL/1623CNG MARCOPOLO	TATA spare parts
218650000118	INTERCOOLER	TATA spare parts
218650000119	ASSY. FAN SHROUD	TATA spare parts
218650100101	ASSY.AUX.TANK FOR RADIATOR	TATA spare parts
218650100102	RUBBERISED CLAMP	TATA spare parts

218650100103	ASSY PIPE RADIATOR TO ENGINE	TATA spare parts
218650100105	ASSY AUXILIARY TANK	TATA spare parts
218650100106	ASSY PIPE ENGINE TO RADIATOR	TATA spare parts
218650100107	ASSY PIPE RADIATOR TO TRANS OIL COOLER	TATA spare parts
218650100108	ASSY PIPE RADIATOR TO TRANS OIL COOLER	TATA spare parts
218650100109	ASSY PIPE ENGINE TO RADIATOR	TATA spare parts
218650105801	HOSE OIL COOLER TO ENGINE INLET	TATA spare parts
218650105802	HOSE RADIATOR	TATA spare parts
218650105803	HOSE FILLER PIPE 28 MM ID	TATA spare parts
218650105804	REDUCER HOSE ( ON OIL COOLER )	TATA spare parts
218650105806	HOSE RAD TO ASSY RAD BOTTOM PIPE	TATA spare parts
218650106901	PIPE( ENGINE TO RADIATOR)	TATA spare parts
218650106902	WATER FILL PIPE	TATA spare parts
218650106904	PIPE AUX TANK TO RADIATOR	TATA spare parts
218650106905	VENT TUBE ENGINE TO AUX TANK	TATA spare parts
218650106906	VENT TUBE RAD TO AUX TANK	TATA spare parts
218650106907	PIPE AUX TANK TO RADIATOR	TATA spare parts
218650106908	PIPE THERMOSTAT BYPASS	TATA spare parts
218650106909	PIPE ENGINE HEAD BYPASS	TATA spare parts
218650106910	VENT TUBE RAD TO AUX TANK	TATA spare parts
218650106911	PIPE THERMOSTAT BYPASS	TATA spare parts
218650108201	CLAMP (RADIATOR PIPE BOTTOM)	TATA spare parts
218650108205	CLAMP HOLDING BKT ( OIL COOLER HOSE )	TATA spare parts
218650108206	CLAMP HOLDING BKT(RAD BOTTOM PIPE )	TATA spare parts
218650400101	ASSY BKT RADIATOR MTG LOWER RH	TATA spare parts
218650400102	ASSY PIPE CLAMP ( COOLANT PIPES )	TATA spare parts
218650400103	ASSY PIPE CLAMP (COOLANT PIPES )	TATA spare parts
218650408201	RADIATOR MTG BKT BOTTOM LH	TATA spare parts
218651000105	ASSY REAR TUBELAR STRUCTURE	TATA spare parts
218651100101	ASSY PANEL AIR FILTER	TATA spare parts
218651100102	ASSY MTG BKT HEAT SHIELD FRT LH	TATA spare parts
218651100103	ASSY MTG BKT HEAT SHIELD RR RH	TATA spare parts
218651100104	ASSY MTG BKT HEAT SHIELD FRT RH	TATA spare parts
218651100105	ASSY MTG BKT HEAT SHIELD RR LH	TATA spare parts
218651108201	FLOOR PANEL FRONT	TATA spare parts
218651108202	FLOOR PANEL REAR	TATA spare parts
218651108231	MTG BKT HEAT SHIELD	TATA spare parts
218651108234	CLAMP SHEET	TATA spare parts
218651108235	PANEL AIR FILTER FRT	TATA spare parts
218651108236	PANEL MTG BKT	TATA spare parts
218651200118	ASSY OUTTRIGGER REAR RH	TATA spare parts
218651200131	ASSY RR OUTRIGGER FRONT RH	TATA spare parts
218651200133	ASSY BRACKET RADIATOR MOUNTING BOTTOM R	TATA spare parts
218651200134	BKT CNG LEAKAGE SENCOR MTG.	TATA spare parts
218651208221	BRACKET SILENCER CLAMP MOUNTING	TATA spare parts
218651208230	MTG BKT HEAT SHIELD	TATA spare parts
218651208247	W/H HOLDING BKT REAR STRUCTURE	TATA spare parts

218654100102	ASSY.BATT.CABLE +VE 2000 MM.	TATA spare parts
218654100108	ASSY. BATT. CABLE +VE	TATA spare parts
218654100109	ASSY. BATT. CABLE LINK 305MM	TATA spare parts
218654100110	ASSY. BATTERY CABLE +VE(STR MOT.)	TATA spare parts
218654103301	W/H BRACKET-1	TATA spare parts
218654103302	W/H BRACKET-2	TATA spare parts
218654103303	W/H BRACKET-3	TATA spare parts
218654103304	W/H BRACKET-4	TATA spare parts
218654103306	W/H BRACKET-6	TATA spare parts
218654107501	CAP(BATT. TERMINAL +VE)	TATA spare parts
218654107502	CAP(BATT. TERMINAL -VE)	TATA spare parts
218654109901	BATTERY 12V 180AH LOW MAINT.BS3/4	TATA spare parts
218654109902	TOP COVER (MHD 1800 WITH TAKE-OFF)	TATA spare parts
218654110103	ASSY. BATT. CABLE -VE	TATA spare parts
218654110106	ASSY. BATT. CABLE -VE FOR BODY	TATA spare parts
218654200101	ASSY.KIT FOR CNG GAS LEAKAGE INDICATOR	TATA spare parts
218654200102	ASSY.KIT FOR CNG GAS SENSOR	TATA spare parts
218654200105	ASSY.KIT ROAD SPEED LIMITER 24V	TATA spare parts
218654200107	MTG.BKT-CNG GAS SENSOR	TATA spare parts
218654200109	ASSY. KIT ROAD SPEED LIMITER(24V)	TATA spare parts
218654200110	ENGINE OIL LEVEL SWITCH	TATA spare parts
218654200111	ASSY.KIT FOR CNG GAS LEAKAGE IND	TATA spare parts
218654204902	RELAY 24V DC 70A	TATA spare parts
218654209902	SPEEDOCABLE (COMPOSITE-12.5 M)	TATA spare parts
218654209904	CNG GAS LEAK INDICATOR	TATA spare parts
218654209908	SPEEDOCABLE (COMPOSITE-12.5 M)	TATA spare parts
218654209912	SPEEDO CABLE COMP JIS 11.5M	TATA spare parts
218654209916	SPEED SENSOR FOR SPEED LIMITER	TATA spare parts
218654209917	ELCTRIC ACTUATOR 24V	TATA spare parts
218654209918	ELECTRONIC CONTROL UNIT -24V	TATA spare parts
218654209919	INST.CLUSTER LPO1623/62CNG BSIII	TATA spare parts
218654209920	INST.CLUSTER LPO1623/63CNG BSIII	TATA spare parts
218654209921	BOOSTER BOX FOR AUTO TRANS VEHICLE	TATA spare parts
218654209922	ELECT. SPEEDOMETER-16475 PULSES/KM	TATA spare parts
218654209923	ELECT. RPM MOVEMENT 570HZ 24V WITH LCD	TATA spare parts
218654209924	VOLT METER MOVEMENT 16-32V	TATA spare parts
218654209925	EOPG MOVEMENT 24 (WITH WARNING LAMP)	TATA spare parts
218654209928	BOWDEN CABLE M/S PRICOL 1.7M	TATA spare parts
218654209930	TEMP. GAUGE WITH WARING LAMP¿ 40-120	TATA spare parts
218654209932	ENGINE OIL TEMP. GAUGE	TATA spare parts
218654209934	ELECT. SPEEDOMETER(16190 PULSES/KM)	TATA spare parts
218654209935	ELECT.SPEEDOMETER (16475 PULSES) WITH OP	TATA spare parts
218654249902	DC-DC CONVERTER (24-12V DC)-18A	TATA spare parts
218654309901	TEMP. TRANSDUCER-ENG. OIL	TATA spare parts
218654400142	ASSY TAIL LAMP (RH) (24V) 1	TATA spare parts
218654400143	ASSY TAIL LAMP (LH) (24V) 1	TATA spare parts
218654506901	PIANO SW.(ALARM RESET) W/O CONN.	TATA spare parts



218654506902	PIANO SW.(RAMP IN) W/O CONN.	TATA spare parts
218654506903	PIANO SW.(RAMP OUT) W/O CONN.	TATA spare parts
218654506904	PIANO SW.(ON-BATT.) W/O CONN.	TATA spare parts
218654506909	PIANO SW-(ALARM RESET)	TATA spare parts
218654506910	PIANO SW-KNEELING FRONT	TATA spare parts
218654506911	PIANO SW-KNEELING REAR	TATA spare parts
218654506912	PIANO SW-KNEELING BOTH	TATA spare parts
218654506913	PIANO SW-BATT. CUT OFF (RED)	TATA spare parts
218654506914	PIANO SW-ENG. SHUT DWN OVERRIDE	TATA spare parts
218654509900	TRANS OIL PRESSURE SWITCH	TATA spare parts
218654509901	10PSI SW FOR RELS	TATA spare parts
218654509903	DIODE MODULE 4 DIODES	TATA spare parts
218654509904	ASSY.DIODE MODULE (4 DIODE)	TATA spare parts
218654509905	DIODE BLADE FUSE TYPE	TATA spare parts
218654509907	BLADE TYPE FUSE 1A	TATA spare parts
218654509908	BLADE TYPE FUSE 5A	TATA spare parts
218654509909	BLADE TYPE FUSE 7.5A	TATA spare parts
218654509910	BLADE TYPE FUSE 10A	TATA spare parts
218654509911	BLADE TYPE FUSE 15A	TATA spare parts
218654509912	BLADE TYPE FUSE 25A	TATA spare parts
218654509913	MAXI FUSE 30A	TATA spare parts
218654509914	MAXI FUSE 60A	TATA spare parts
218654509915	GLASS FUSE 15A	TATA spare parts
218654509916	BATT. CUT OFF SW (1-POLE)	TATA spare parts
218654509917	STARTER PREVENTION SWITCH	TATA spare parts
218654509918	MEGA FUSE 150 A	TATA spare parts
218654509919	MEGA FUSE HOLDER	TATA spare parts
218654600101	PIGTAIL WIPER MOTOR	TATA spare parts
218654600102	PIGTAIL FOR HORN	TATA spare parts
218654600104	PIGTAIL W/H $\frac{1}{2}$ FOR CN	TATA spare parts
218654600110	GROUND CABLE FOR TRANSMISSION ECU	TATA spare parts
218654604902	RETARDER SW. BYPASS PIGTAIL	TATA spare parts
218654660101	W/H MAIN LPO-1623/62 RE CNG HCBS	TATA spare parts
218654660102	W/H TAIL LPO-1623/62 RE CNG HCBS-	TATA spare parts
218654660103	W/H BODY LPO-1623/62 RE CNG HCBS	TATA spare parts
218654660104	W/H MAIN LPO 1623/62 RE CNG BSIII	TATA spare parts
218654660105	W/H TAIL LPO 1623/62 RE CNG BSIII	TATA spare parts
218654660106	W/H BODY LPO 1623/62 RE CNG BSIII	TATA spare parts
218654660107	24 V FLASHER 5W SIDE INDICATOR ADDED	TATA spare parts
218654660108	STARTER INTERLOCK RELAY 24 V	TATA spare parts
218654660109	HORIZONTAL COOLANT LEVEL SENSOR	TATA spare parts
218654660110	W/H MAIN LPO 1623/63 RE CNG BSIII	TATA spare parts
218654660111	W/H TAIL LPO 1623/63 RE CNG BSIII	TATA spare parts
218654660112	W/H BODY LPO 1623/63 RE CNG BSIII	TATA spare parts
218654660113	CAN BACKBONE HARNESS OFF	TATA spare parts
218654660114	W/H ABS	TATA spare parts
218654660115	PIGTAIL W/H-4ST RELAY & INT.LOCK RELAY	TATA spare parts

218654660116	ADD ON HARNESS FOR AFICD CONTROLLER	TATA spare parts
218654660117	CNG PRES. AND IGNITION KILL SYSTEM W/H	TATA spare parts
218654660118	PIGTAIL FOR VARIOUSELE SPEED SENSER	TATA spare parts
218654660119	PIGTAIL FOR ADVERTISEMENT DISPLAY	TATA spare parts
218654660120	W/H SIDE MARKER LAMP	TATA spare parts
218654660121	W/H PIGTAILST. LOCK CUM IGN. SW.	TATA spare parts
218654660122	WIPER FUSE ADD ON HARNESS	TATA spare parts
218654660123	CUT OFF SW. INLINE FUSE PIGTAIL	TATA spare parts
218654660124	PIGTAIL 150 A FUSE ALTERNATOR	TATA spare parts
218654820106	W/H FOR CNG GAS LEAK INDICATOR	TATA spare parts
218654990106	VIW CONN. SEALING KIT	TATA spare parts
218659100101	ASSY RAMP COMPLT.	TATA spare parts
218659100111	FLOW CONTROL VALVE	TATA spare parts
218659100112	SOLENOID OPERATED CONTROL VALVE	TATA spare parts
218660000102	ASSY.DRIVERS STATION COMPLETE	TATA spare parts
218660000103	ASSY. DRIVER STATION	TATA spare parts
218660100108	ASSY.SEAT STAND.	TATA spare parts
218660100110	ASSY.ANGLE AIR TANK MTG.	TATA spare parts
218660100119	ASSY.ANGLE AIR TANK MTG.	TATA spare parts
218660106304	BALATA PACKING ( DRIVER STATION FRT MTG)	TATA spare parts
218660106305	BALATA PACKING ( DRIVER STATION RR MTGS)	TATA spare parts
218691500101	SEAT BELT ASSY ( ELR )	TATA spare parts
218715400101	ALTERNATOR 24V 90A WITH 8 GROOVE	TATA spare parts
218729100103	ASSY. CLUTCH MASTER CYL W/RESERV. BS3/4	TATA spare parts
218729300103	ASSY.PIPE LINE DIA-6 (1950 LG.)	TATA spare parts
218729300105	MAJOR REPAIR KIT CLUTCH MASTER CYLINDER	TATA spare parts
218729300106	MINOR REPAIR KIT CLUTCH MASTER CYLINDER	TATA spare parts
218729300107	KIT FLUID RESERVOIR	TATA spare parts
218730100101	ASSY. PULL ROD (630L)	TATA spare parts
218731000101	ASSY FRAME COMPLETE SE1613 BS2 W/ FRONT	TATA spare parts
218731000102	ASSY FRAME SE 1613/42 697 BS2 1560 ROH	TATA spare parts
218731000115	ASSY FRAME COMPLETE	TATA spare parts
218731200104	ASSY. SUPPORT RH(ENG CROSS MEMEBER)	TATA spare parts
218731200105	ASSY. SUPPORT LH(ENG CROSS MEMBER)	TATA spare parts
218731300101	ASSY. GUSSET RH(FRAME)	TATA spare parts
218731300102	ASSY. GUSSET LH(FRAME)	TATA spare parts
218731700102	ASSY NOISE SHIELD GEAR BOX BOTTOM	TATA spare parts
218731700105	ASSY. FUPD BKT. LH	TATA spare parts
218731700106	ASSY. FUPD BKT. RH	TATA spare parts
218731700111	ASSY. PLATE LH(FOR BUMPER MOUNTING)	TATA spare parts
218731700112	ASSY. PLATE RH(FOR BUMPER MOUNTING)	TATA spare parts
218731709901	SPACER(FUPD)	TATA spare parts
218732407124	M20 MACHINED WASHER	TATA spare parts
218733000101	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
218733000102	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
218741100101	ASSY PROP SHAFT WITH CTR BRG	TATA spare parts
218741100104	ASSY. GUARD	TATA spare parts

218741100105	ASSY SUPPORT	TATA spare parts
218741108201	CHANNEL(GUARD MTG )	TATA spare parts
218741109201	SPECIAL WASHER	TATA spare parts
218741110101	ASSY.PROP.SHAFT WITH CENTRE BEARING	TATA spare parts
218741110104	ASSY PROP. SHAFT FRONT WITH C.B.	TATA spare parts
218741110105	ASSY.PROP.SHAFT FRONT WITH C.B.	TATA spare parts
218741113701	COMPANION FLANGE (FRONT PROP SHAFT)	TATA spare parts
218741120101	ASSY.PROP.SHAFT COMP.(REAR)	TATA spare parts
218741120108	ASSY.PROP.SHAFT REAR	TATA spare parts
218743900103	ASSY.NYLON PIPE SET COM.	TATA spare parts
218743900106	ASSY.NYLON PIPE SET COM.	TATA spare parts
218743900109	ASSY.TUBE WITH CRIMPED R/HOSE.	TATA spare parts
218743900136	ASSY.TUBE O.D 15X2190 LG.	TATA spare parts
218743900137	ASSY.TUBE O.D 15X2550 LG.	TATA spare parts
218743900161	ASSY.NYLON PIPE SET COMPLETE.	TATA spare parts
218743900167	ASSY.TUBE W/CRIMPED TEFLON HOSE.	TATA spare parts
218743900168	ASSY.TUBE OD 18X1.5 (COMP.2ND PIPE)	TATA spare parts
218743900169	ASSY.TUBE OD 15X1.5 (COMP.3RD PIPE)	TATA spare parts
218743900170	ASSY.TUBE WITH CRIMPED R/HOSE.	TATA spare parts
218743900172	ASSY.COMP.PIPE 2ND	TATA spare parts
218743900174	ASSY.NYLON PIPE SET COMPT.W/PLASTIC VOSS	TATA spare parts
218743900180	PIPE BUNCH ASSY	TATA spare parts
218743900189	METAL PIPE ASSY SECOND	TATA spare parts
218743900190	METAL PIPE ASSY THIRD	TATA spare parts
218746100101	ASSY.STEERING COL.WITHOUT STG.WHEEL	TATA spare parts
218746100102	ASSY.STEERING COLUMN SUPPORT	TATA spare parts
218746150102	ASSY.KIT FOR P/STG.LINE & CONNECTOR	TATA spare parts
218746150104	ASSY.KIT FOR RANE P/STG.LINE & CONNECTOR	TATA spare parts
218746150105	KIT P/STG.LINE & CONNECTOR.	TATA spare parts
218746150106	KIT FOR P/STG.LINE & CONNECTOR.	TATA spare parts
218746200101	ASSY STEERING SPINDLE	TATA spare parts
218746600107	STRG GEAR BALL & NUT POWER STG	TATA spare parts
218746600108	ASSY.P.STG.G.BOX WITH PRS.RLF.VLV	TATA spare parts
218746600110	HOUSING ASSY	TATA spare parts
218746600111	SECTOR SHAFT ASSY.	TATA spare parts
218746605401	BEVEL GEAR	TATA spare parts
218746800101	SUCTION LINE HOSE ASSY	TATA spare parts
218746800102	PRESSURE LINE HOSE ASSY	TATA spare parts
218746800103	RETURN LINE HOSE ASSY	TATA spare parts
218746800105	SUCTION LINE HOSE ASSY.	TATA spare parts
218746800106	PRESSOR LINE HOSE ASSY	TATA spare parts
218746800108	RETURN LINE HOSE ASSY.	TATA spare parts
218746800109	SUCTION LINE HOSE ASSY.(HYD TANK TO STRG	TATA spare parts
218746800110	PRESSURE LINE HOSE ASSY.(STRG PUMP TO ST	TATA spare parts
218746800111	RETURN LINE HOSE ASSY.(P/STRG GEAR BOX T	TATA spare parts
218746800112	RETURN LINE HOSE ASSY.(P/STRG GEAR BOX T	TATA spare parts
218746800113	SUCTION LINE HOSE ASSY.(HYD TANK TO STRG	TATA spare parts

218746800114	SUCTION LINE HOSE ASSY.(HYD TANK TO STRG	TATA spare parts
218746800115	RETURN LINE HOSE ASSY.(P/STRG GEAR BOX T	TATA spare parts
218746800116	SUCTION LINE HOSE ASSY.	TATA spare parts
218746800117	RETURN LINE HOSE ASSY.	TATA spare parts
218746800118	SUCTION LINE HOSE ASSY	TATA spare parts
218746800119	PRESSURE LINE HOSE ASSY	TATA spare parts
218746800120	RETURN LINE HOSE ASSY	TATA spare parts
218747150103	ASSY.RETROFIT KIT W/ELE.FUEL PUMP ETC.	TATA spare parts
218747600101	ASSYTUBE WITH CRIMPED RUBBER HOSE (FUEL	TATA spare parts
218747600103	ASSYTUBE WITH CRIMPED RUBBER HOSE (FUEL	TATA spare parts
218747600110	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
218747600111	ASSY.NYLON PIPE W/CRIMPED R/HOSE	TATA spare parts
218747600112	ASSY.NYLON PIPE W/CRIMPED R/HOSE	TATA spare parts
218747600113	ASSY.NYLON PIPE W/CRIMPED R/HOSE	TATA spare parts
218747600115	ASSY TUBE W/CRIMPED R/HOSE	TATA spare parts
218747600116	ASSY TUBE W/CRIMPED RUBBER HOSE	TATA spare parts
218747603301	BRACKET (BABY FILTER MTG.)	TATA spare parts
218749100102	ASSY.SILENCER WITH TAIL PIPE	TATA spare parts
218749100103	ASSY.MUFFLER	TATA spare parts
218749200110	ASSY EXHAUST PIPE REAR	TATA spare parts
218749200112	ASSY.BRACKET	TATA spare parts
218749203301	BRACKET	TATA spare parts
218749203302	BRACKET	TATA spare parts
218749203306	BRACKET	TATA spare parts
218754107501	RUBBER GROMMET FOR BATTERY CABLE. BS6	TATA spare parts
218754400101	ASSY ENGINE LAMP 12V	TATA spare parts
218754400102	ENGINE LAMP (24V)	TATA spare parts
218754600104	WIRING HARNESS ABS FRAME	TATA spare parts
218754600105	WIRING HARNESS ABS ECU	TATA spare parts
218754601611	WIRING HARNESS TAIL	TATA spare parts
218754620103	W/H TAIL SE-1613/42 12V BSII	TATA spare parts
218754620108	W/H MAIN-SK1613 697 BS-II	TATA spare parts
218754620110	W/H MAIN-SE1613 697 BS-II	TATA spare parts
218754660108	W/H MAIN-SK1613 697 BS-II	TATA spare parts
218754660123	WIRING HARNESS TAIL	TATA spare parts
218754660124	WIRING HARNESS TAIL	TATA spare parts
218754660127	WIRING HARNESS MAIN	TATA spare parts
218754820101	W/H MAIN-SE 697 BS-II MOTOR.H/L	TATA spare parts
218754820102	W/H TAIL-SE W.B-42	TATA spare parts
218754820104	W/H-MAIN SE-1613 697BS-II INST CLUSTER	TATA spare parts
218754820122	KIT-WINDSHIELD WASHER SYSTEM BS6	TATA spare parts
218770110101	KIT PT.NO.OF ASSY.SUPD COMPLETE	TATA spare parts
21879842000R40	TATA SE1613 CRI6 BS-IV. _CAB/COWL	TATA spare parts
218846607901	SHAFT	TATA spare parts
218900990101	KIT FULLY TRIMMED CABIN FOR LPK 1615	TATA spare parts
218900990102	KIT FULLY TRIMMED CABIN FOR LPK 1615	TATA spare parts
21892142300R40	6OR_RESTRUCTURE_FOR_CVBU_IN_APL_VIEW	TATA spare parts

218924200101	ASSY BRACKET (ENG.MTG.REAR TOP)	TATA spare parts
218924200102	ASSY BRACKET-RH(ENG.MTG.REAR BOTTOM)	TATA spare parts
218924200103	ASSY BRACKET-LH(ENG.MTG.REAR BOTTOM)	TATA spare parts
218926000101	BRACKET ASSY WITH BOSS LIFTING HOOK FRT	TATA spare parts
218926730105	CONNECTING LINK ASSY	TATA spare parts
218926800110	TURNING TUBE ASSY. (WITH BUSH)	TATA spare parts
218926800113	ASSY TURNING TUBE(WITH BUSH)	TATA spare parts
218926800115	ASSY BRACKET (GEAR SHIFT LEVER)	TATA spare parts
218929100112	ASSY SUPPORT PEDAL LEVER COMPLETE	TATA spare parts
218929300103	BUNDY TUBE ASSY MIDDLE	TATA spare parts
218929300106	ASSY.TUBE	TATA spare parts
218931000102	FRAME ASSY WITH FITMENT	TATA spare parts
218931000103	ASSY FRAME COMPLETE	TATA spare parts
218931000105	ASSY FRAME COMPLETE	TATA spare parts
218931000106	FRAME ASSY	TATA spare parts
218931000109	FRAME ASSY WITH FITMENT	TATA spare parts
218931200101	END CROSS MEMBER ASSY WITH GUSSET	TATA spare parts
218931200104	ASSY SUPPORT (3RD X-MEMBER)	TATA spare parts
218931200109	SUPPORT ASSY LH	TATA spare parts
218931200110	SUPPORT ASSY RH	TATA spare parts
218931207103	SPACER-ENG X-MEMBER FRONT	TATA spare parts
218931207104	SUPPORT(FRONT)-RH ENG X-MEMBER-FRONT	TATA spare parts
218931207105	SUPPORT(FRONT)-LH ENG X-MEMBER-FRONT	TATA spare parts
218931207106	SUPPORT(REAR)-RH ENG X-MEMBER-FRONT	TATA spare parts
218931207107	SUPPORT(REAR)-LH ENG X-MEMBER-FRONT	TATA spare parts
218931207110	SPACER-ENG MTG X-MEMBER REAR	TATA spare parts
218931300101	END CROSS MEMBER ASSY	TATA spare parts
21894100010	RETRO KIT WITH P/SHAFT E-MTG R/PAD & CM	TATA spare parts
218941000101	RETRO KIT WITH P/SHAFT,E-MTG. R/PAD & CM	TATA spare parts
218941100101	PROPELLER SHAFT ASSY FRONT	TATA spare parts
218941100102	KIT-PROPELLER SHAFT ASSY	TATA spare parts
218941100107	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
218941100110	PROPELLER SHAFT ASSY;FRONT	TATA spare parts
218941110101	SHORT FORK TUBE&FRONT END PIECE ASSY	TATA spare parts
218941110102	SHORT FORK TUBE&FRONT END PIECE ASSY	TATA spare parts
218941120101	ASSY. PROPELLER SHAFT COMP. REAR BS1/3	TATA spare parts
218941120103	PROPELLER SHAFT ASSY REAR	TATA spare parts
218941120106	PROPELLER SHAFT ASSY;REAR	TATA spare parts
218941120107	SHORT FORK TUBE AND REAR HSG ASSLY	TATA spare parts
218941300101	BRACKET ASSY PROPELLER SHAFT GUARD	TATA spare parts
218941303301	BRACKET CENTER BEARING	TATA spare parts
218941303302	BRACKET CENTER BEARING	TATA spare parts
218943200101	ASSY.AIR TANK COMP.250 STRAP C.D.(VOSS)	TATA spare parts
218943900163	ASSY.NYLON PIPE SET COMPLT W/VOSS	TATA spare parts
218943900168	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
218943900169	ASSY. COMPRESSOR 3RD PIPE	TATA spare parts
218943900170	ASSY.NYLON PIPE SET COMPLT VOSS	TATA spare parts

218943900171	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
218943900172	ASSY. COMPRESSOR 3RD PIPE	TATA spare parts
218943900175	BUNCH ASSY PIPE	TATA spare parts
218943910101	PIPE BUNCH ASSY COMPLETE	TATA spare parts
218943910110	PIPE ASSY JOINT-2 TO DDU	TATA spare parts
218943910123	BUNCH ASSY PIPE	TATA spare parts
218946603101	BALL BEARING	TATA spare parts
218947600103	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
218947600104	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
218947600105	SUCTION LINE (FUEL TANK TO FUEL FILTER)	TATA spare parts
218947600106	SUCTION LINE (FUEL FILTER TO ENG)	TATA spare parts
218947600107	RETURN LINE ASSY ON TANK (ENG TO F/TANK)	TATA spare parts
218947600108	FUEL PIPE ASSY RETURN LINE	TATA spare parts
218947600109	SUCTION PIPE ASSY TANK TO FILTER	TATA spare parts
218947600110	FUEL PIPE ASSY SUCTION FUEL FTR TO ENG	TATA spare parts
218949100101	ASSY. MUFFLER WITH TAIL PIPE	TATA spare parts
218949200101	ASSY EXHAUST PIPE-INTERMEDIATE	TATA spare parts
218949200103	EXHAUST ASSY FRONT	TATA spare parts
218949200107	BASE PLATE TAIL PIPE ASSY MTG BKT	TATA spare parts
218949203308	C-BRACKET	TATA spare parts
218949208201	BRACKET-INTERMEDIATE PIPE MTG	TATA spare parts
218949208204	BRACKET	TATA spare parts
218954500106	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
218954600102	WIRING HARNESS TAIL	TATA spare parts
218954600103	WIRING HARNESS ENGINE	TATA spare parts
218954600104	WIRING HARNESS TAIL	TATA spare parts
218954600105	WIRING HARNESS TAIL	TATA spare parts
218987100101	ASSY SUB-FRAME(8.5CUM BOX)	TATA spare parts
2190-3103023	AXLE-PACKING RING	TATA spare parts
2190-3103024	AXLE-PACKING RING	TATA spare parts
219016100102	CONTAINER (ECU-497TC BS-III)LPT1112	TATA spare parts
219016100105	CONTAINER (ECU-497TC BS-III)	TATA spare parts
219016100111	CONTAINER (ECU-497TC BS-III) GB-8.02	TATA spare parts
219016100113	CONTAINER (ECU-497TC BS-III)GB-7.51)	TATA spare parts
219016100117	CONTAINER (ECU-497TC BS-III)GB-7.51	TATA spare parts
219016100118	CONTAINER (ECU-497TC BS-III) GB-8.02	TATA spare parts
219016100119	CONTAINER (ECU 497 TCIC CRDI) BS3	TATA spare parts
219016100123	CONTAINER ECU 497TCIC 69/5857 BS3/4	TATA spare parts
219016100124	CONTAINER(ECU497TCIC BS4-6.9.5.857 OBDII	TATA spare parts
219016100134	CONTAINER (ECU-497TC GB-8.02 RAR-5.28)	TATA spare parts
219024200101	ASSY RUBBER SUPPORT (RH) REAR	TATA spare parts
219024200102	ASSY RUBBER SUPPORT (LH) REAR	TATA spare parts
219024200103	ASSEMBLY ENGINE MTG. BKT RH (BOTTOM)	TATA spare parts
219024200104	ASSY ENGINE MTG BKT RH(TOP)	TATA spare parts
219024200105	ASSEMBLY ENGINE MTG. BKT LH (BOTTOM)	TATA spare parts
219024200106	ASSY ENGINE MTG BKT LH(TOP)	TATA spare parts
219026800101	ASSY TURNING TUBE(WITHOUT BALL JOINT)	TATA spare parts

219026800103	ASSY SUPPORT TUBE	TATA spare parts
219026800106	TURNING TUBE ASSY	TATA spare parts
219026810101	ASSY BRACKET (G.S.LEVER MTG)	TATA spare parts
219029100103	ASSY TUBE(CLUTCH 6 ODX0.7 THK)	TATA spare parts
219029100113	BUNDY TUBE ASSY	TATA spare parts
219029100114	HYD PIPE CMC ASSY TO FIREWALL	TATA spare parts
219029100117	CLUTCH PEDAL ASSY WITH BUSH BS6	TATA spare parts
219029100122	CLUTCH PEDAL ASSY WITH BUSH BS6-PH2	TATA spare parts
219029300101	HYD PIPE ASSY FROM COUPLING BODY TO HOSE	TATA spare parts
219029300102	BUNDY TUBE ASSY MIDDLE	TATA spare parts
219029300103	BUNDY TUBE ASSY	TATA spare parts
219029300104	BUNDY TUBE ASSY CMC TO FIREWALL	TATA spare parts
219029300106	CLUTCHBOOSTERASSY BS6	TATA spare parts
219029300110	BUNDY TUBE ASSY CMC TO FIREWALL BS6	TATA spare parts
219029300112	CLUTCH BOOSTER ASSY BS6	TATA spare parts
219029300115	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
219029300116	BUNDY TUBE ASSY MIDDLE BS6	TATA spare parts
219029300117	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
219029300122	REPAIR KIT BS6	TATA spare parts
219029500101	BRACKET ASSY CLUTCH CONTROL MTG BS6	TATA spare parts
219029500103	CLUTCH PEDAL & SENSOR MTG BRACKT BS6-PH2	TATA spare parts
219031000102	ASSY FRAME COMPLETE LPT	TATA spare parts
219031000103	ASSY FRAME BS-IV WITH 7 THK LONG MEMBER/	TATA spare parts
219031000104	FRAME COMPLETE LPT 1109 SLEEPER CAB	TATA spare parts
219031000105	ASSY FRAME COMPLETE LPT1109H EX2 BSIII/4	TATA spare parts
219031000106	ASSY. FRAME COMPLETE	TATA spare parts
219031000109	FRAME ASSY	TATA spare parts
219031000113	FRAME ASSY	TATA spare parts
219031000114	FRAME ASSY WITH FITMENT	TATA spare parts
219031000118	FRAME ASSY WITH FITMENT	TATA spare parts
219031000122	FRAME ASSY WITH FITMENT_8545MM LENGTH	TATA spare parts
2190310001220C	FRAME ASSY WITH FITMENT_8295MM LENGTH	TATA spare parts
219031000123	FRAME ASSY WITH FITMENT	TATA spare parts
219031000130	FRAME ASSY WITH FITMENT	TATA spare parts
219031000131	FRAME ASSY WITH FITMENT	TATA spare parts
219031000139	FRAME ASSY WITH FITMENT	TATA spare parts
219031000145	FRAME ASSY WITH FITMENT	TATA spare parts
219031100101	ASSY EXTENSION PIECE R.H.	TATA spare parts
219031100102	ASSY EXTENSION PIECE L.H.	TATA spare parts
219031200105	ASSY BKT RH ENGINE MTG CM FRONT	TATA spare parts
219031200106	ASSY BKT LH ENGINE MTG CM FRONT	TATA spare parts
219031200109	ASSY CROSS MEMBER(2ND)	TATA spare parts
219031200116	ASSY. CROSS MEMBER REAR SPRING BS6	TATA spare parts
219031200117	CROSS MEMBER ASSY	TATA spare parts
219031200118	BRACKET ASSY CROSS MEMBER MTG RH	TATA spare parts
219031200119	BRACKET ASSY CROSS MEMBER MTG LH	TATA spare parts
219031200128	END CROSS MEMBER ASSY	TATA spare parts

219031200131	CROSS MEMBER ASSY	TATA spare parts
219031200132	CROSSMEMBERASSYENGINEAR BS6	TATA spare parts
219031200133	CROSS MEMBER ASSY BS6	TATA spare parts
219031207115	END CROSS MEMBER ( 195 DEEP TAIL END )	TATA spare parts
219031207142	REINFORCEMENT BOTTOM RH BS6	TATA spare parts
219031207143	REINFORCEMENT BOTTOM LH BS6	TATA spare parts
219031207144	REINFORCEMENT TOP-RH BS6	TATA spare parts
219031207145	REINFORCEMENT TOP-LH BS6	TATA spare parts
219031207149	SPACER PLATE BS6	TATA spare parts
219031207157	SUPPORT BS6	TATA spare parts
219031207159	REINFORCEMENT REAR-RH BS6	TATA spare parts
219031207160	REINFORCEMENT REAR-LH BS6	TATA spare parts
219031207161	REINFORCEMENT REAR-RH BS6	TATA spare parts
219031207162	REINFORCEMENT REAR-LH BS6	TATA spare parts
219031207164	REINFORCEMENT BOTTOM RH BS6	TATA spare parts
219031207165	REINFORCEMENT BOTTOM LH BS6	TATA spare parts
219031207166	SPACER PLATE BS6	TATA spare parts
219031208216	CROSS MEMBER	TATA spare parts
219031300101	SUPPORT ASSY LH BS6	TATA spare parts
219031300102	SUPPORT ASSY RH BS6	TATA spare parts
219031300103	SUPPORT ASSY LH	TATA spare parts
219031300104	SUPPORT ASSY RH	TATA spare parts
219031300105	SUPPORT ASSY LH	TATA spare parts
219031300106	SUPPORT ASSY RH	TATA spare parts
219031700105	ASSY CLUTCH & GEAR BOX SHILED	TATA spare parts
219031700109	ASSY. BEAM FUPD BS2/3/4	TATA spare parts
219031700110	ASSY. FRAME LPT 1109 BS3/4	TATA spare parts
219031700111	FRAME ASSY WITH FITMENT	TATA spare parts
219031700112	FRAME ASSY WITH FITMENT 1109 /36 LPT BS-	TATA spare parts
219031700114	ASSY FUPD BRACKET COMPLETE-RH	TATA spare parts
219031700115	ASSY FUPD BRACKET COMPLETE-LH	TATA spare parts
219031700116	ASSY.SUPPORT BRACKET (L.H)	TATA spare parts
219031700117	ASSY.SUPPORT BRACKET (R.H)	TATA spare parts
219031700120	FRAME ASSY WITH FITMENT	TATA spare parts
219031700122	ASSY FUPD BRACKET -RH	TATA spare parts
219031700123	ASSY FUPD BRACKET COMPLETE-LH	TATA spare parts
219031700126	ASSY. BRACKET RUPD (RH)	TATA spare parts
219031700127	ASSY. BRACKET RUPD (LH)	TATA spare parts
219031700129	ASSY. CHANNEL RUPD	TATA spare parts
219031700135	BRACKET ASSY	TATA spare parts
219031708206	END CROSS MEMBER (4 THK)	TATA spare parts
219031708207	BRACKET NOISE SHEILD MTG RH	TATA spare parts
219031708208	BRACKET NOISE SHIELD MTG LH	TATA spare parts
219031708209	BRACKET NOISE SHEILD MTG RH	TATA spare parts
219031708210	BRACKET NOISE SHIELD MTG LH	TATA spare parts
219032100104	FRONT SPRING ASSY	TATA spare parts
219032100105	FRONT SPRING ASSY	TATA spare parts



219032100106	1ST LEAF ASSY WITH BUSH	TATA spare parts
219032100107	FRONT SPRING ASSY	TATA spare parts
219032100108	1ST LEAF ASSY WITH BUSH	TATA spare parts
219032100110	LEAF SPRING ASSY FRONT	TATA spare parts
219032100111	LEAF ASSLY 1ST	TATA spare parts
219032100118	BRACKET ASSY AXLE STOPPER RH	TATA spare parts
219032100119	BRACKET ASSY AXLE STOPPER LH	TATA spare parts
219032100120	LEAF SPRING ASSY FRONT-LHBS6	TATA spare parts
219032100121	LEAF SPRING ASSY FRONT-RHBS6	TATA spare parts
219032100122	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
219032100123	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
219032100125	FRONT SPRING ASSY BS6	TATA spare parts
219032100126	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
219032100128	BUMPSTOPPERASSY BS6	TATA spare parts
219032100140	FRONTSPRINGASSY BS6	TATA spare parts
219032100141	1ST LEAF WITH BUSH BS6	TATA spare parts
219032103201	CENTER BOLT	TATA spare parts
219032103202	CENTER BOLT BS6	TATA spare parts
219032107102	2ND LEAF	TATA spare parts
219032107103	3RD LEAF	TATA spare parts
219032107104	4TH LEAF	TATA spare parts
219032107105	5TH LEAF	TATA spare parts
219032107106	6TH LEAF	TATA spare parts
219032107107	7TH LEAF	TATA spare parts
219032107108	8TH LEAF	TATA spare parts
219032107109	9TH LEAF	TATA spare parts
219032107114	2ND LEAF	TATA spare parts
219032107115	3RD LEAF	TATA spare parts
219032107116	4TH LEAF	TATA spare parts
219032107117	5TH LEAF	TATA spare parts
219032107118	6TH LEAF	TATA spare parts
219032107119	7TH LEAF	TATA spare parts
219032107120	8TH LEAF	TATA spare parts
219032107121	9TH LEAF	TATA spare parts
219032107126	LEAF 2	TATA spare parts
219032107127	3RD LEAF	TATA spare parts
219032107128	4TH LEAF	TATA spare parts
219032107129	5TH LEAF	TATA spare parts
219032107130	6TH LEAF	TATA spare parts
219032107131	7TH LEAF	TATA spare parts
219032107132	8TH LEAF	TATA spare parts
219032107133	9TH LEAF	TATA spare parts
219032107134	10TH LEAF	TATA spare parts
219032107161	CASTER PLATE	TATA spare parts
219032107166	2ND LEAF BS6	TATA spare parts
219032107168	3RD LEAF BS6	TATA spare parts
219032107170	SPACER BS6	TATA spare parts

219032107171	SPACER BS6	TATA spare parts
219032107173	3RD LEAF BS6	TATA spare parts
219032107174	2ND LEAF BS6	TATA spare parts
219032107182	2ND LEAF BS6	TATA spare parts
219032107183	3RD LEAF BS6	TATA spare parts
219032107184	4TH LEAF BS6	TATA spare parts
219032107185	5TH LEAF BS6	TATA spare parts
219032107186	6TH LEAF BS6	TATA spare parts
219032107187	7TH LEAF BS6	TATA spare parts
219032107188	8TH LEAF BS6	TATA spare parts
219032107189	9TH LEAF BS6	TATA spare parts
219032107190	10TH LEAF BS6	TATA spare parts
219032107198	CASTER PLATE BS6	TATA spare parts
219032107199	SPACERBS6	TATA spare parts
219032117102	2ND LEAF BS6	TATA spare parts
219032117103	3RD LEAF BS6	TATA spare parts
219032117104	4TH LEAF BS6	TATA spare parts
219032117105	5TH LEAF BS6	TATA spare parts
219032117106	6TH LEAF BS6	TATA spare parts
219032117107	7TH LEAF BS6	TATA spare parts
219032117108	8TH LEAF BS6	TATA spare parts
219032117109	9TH LEAF BS6	TATA spare parts
219032117110	10TH LEAF BS6	TATA spare parts
219032300104	BRACKET ASSY FRONT SHOCK ABSORBER MTG LH	TATA spare parts
219032300105	BRACKET ASSY SHOCK ABSORBER MTG FRONT-LH	TATA spare parts
219032301601	FRONT SHOCK ABSORBER ASSY BS6-PH2	TATA spare parts
219032303302	BRACKETASSYSHOCKABSORBERMTGFRONT-LHBS	TATA spare parts
219032303304	BRACKETASSYSHOCKABSORBERMTGFRONT-RHBS	TATA spare parts
219032400102	REAR SPRING ASSY WITH AUX. SPRING	TATA spare parts
219032400103	1ST LEAF WITH BUSH	TATA spare parts
219032400105	REAR SPRING ASSY WITH AUX	TATA spare parts
219032400106	1ST LEAF ASSY WITH BUSH	TATA spare parts
219032400119	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
219032400120	REAR SPRING ASSY BS6	TATA spare parts
219032404201	SPRING CLIP REAR	TATA spare parts
219032404202	SPRING CLIP REAR	TATA spare parts
219032404203	SPRING CLIP REAR	TATA spare parts
219032404204	SPRING CLIP AUX SPRING	TATA spare parts
219032407102	2ND LEAF	TATA spare parts
219032407103	3RD LEAF	TATA spare parts
219032407104	4TH LEAF	TATA spare parts
219032407105	5TH LEAF	TATA spare parts
219032407106	6TH LEAF	TATA spare parts
219032407107	7TH LEAF	TATA spare parts
219032407108	8TH LEAF	TATA spare parts
219032407111	2ND LEAF	TATA spare parts
219032407112	3RD LEAF	TATA spare parts

219032407113	4TH LEAF	TATA spare parts
219032407114	5TH LEAF	TATA spare parts
219032407115	6TH LEAF	TATA spare parts
219032407116	7TH LEAF	TATA spare parts
219032407117	8TH LEAF	TATA spare parts
219032407119	1ST LEAF AUX SPRING	TATA spare parts
219032407120	2ND LEAF AUX SPRING	TATA spare parts
219032407121	3RD LEAF AUX SPRING	TATA spare parts
219032407122	4TH LEAF AUX SPRING	TATA spare parts
219032407123	5TH LEAF AUX SPRING	TATA spare parts
219032407124	6TH LEAF AUX SPRING	TATA spare parts
219032407131	SPACER REAR SPRING	TATA spare parts
219032407133	1ST LEAF AUX SPRING	TATA spare parts
219032407134	2ND LEAF AUX SPRING	TATA spare parts
219032407135	3RD LEAF AUX SPRING	TATA spare parts
219032407136	4TH LEAF AUX SPRING	TATA spare parts
219032407137	5TH LEAF AUX SPRING	TATA spare parts
219032407138	6TH LEAF AUX SPRING	TATA spare parts
219032407142	7TH LEAF AUX SPRING	TATA spare parts
219032407143	8TH LEAF AUX SPRING	TATA spare parts
219032407145	2ND LEAF BS6	TATA spare parts
219032407146	3RD LEAF BS6	TATA spare parts
219032407148	4TH LEAF BS6	TATA spare parts
219032407149	5TH LEAF BS6	TATA spare parts
219032407150	6TH LEAF BS6	TATA spare parts
219032407151	7TH LEAF BS6	TATA spare parts
219032407152	8TH LEAF BS6	TATA spare parts
219032407153	1ST LEAF AUX SPRING BS6	TATA spare parts
219032407154	2ND LEAF AUX SPRING BS6	TATA spare parts
219032407155	3RD LEAF AUX SPRING BS6	TATA spare parts
219032407156	4TH LEAF AUX SPRING BS6	TATA spare parts
219032407157	5TH LEAF AUX SPRING BS6	TATA spare parts
219032407158	6TH LEAF AUX SPRING BS6	TATA spare parts
219032407159	7TH LEAF AUX SPRING BS6	TATA spare parts
219032407160	8TH LEAF AUX SPRING BS6	TATA spare parts
219032504201	U - BOLT	TATA spare parts
219032800101	LINK ASSY ANTI ROLL BAR FRONT	TATA spare parts
219032800102	ANTI ROLL BAR ASSY FRONT	TATA spare parts
219032803701	BRACKET ANTI ROLL BAR MTG FRONT-LH BS6	TATA spare parts
219032803702	BRACKET ANTI ROLL BAR MTG FRONT-RH BS6	TATA spare parts
219033000101	ASSY.FRT.AXLE WITH S-CAM BRK.ON FRT.AXLE	TATA spare parts
219033000103	ASSY.FRT.AXLE WITH S-CAM BRK.ON FRT.AXLE	TATA spare parts
219033000105	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
219033000107	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
219033000110	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
219033000113	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
219033000114	ASSY. FRONT AXLE WITH BRAKE BS4	TATA spare parts

219033207201	SEALING PLUG	TATA spare parts
219033400101	ASSY.HUB FRONT WHEEL(SPIGOTTED)	TATA spare parts
219033400109	TAPER ROLLER BEARING BS6-PH2	TATA spare parts
219033405101	WHEEL HUB FRONT(SPIGOTTED)	TATA spare parts
219033405501	FRONT HUB	TATA spare parts
219033405502	FRONT HUB ABS BS6-PH2	TATA spare parts
219033409201	LOCK WASHER BS6-PH2	TATA spare parts
21903501113	BRAKE ARM	TATA spare parts
219040106701	HUB BOLT FRONT	TATA spare parts
219040107702	TYRE 8.25X20-16PR NYLON(LUG TYPE PATTERN	TATA spare parts
219040107707	FLAP	TATA spare parts
219040109908	TUBE	TATA spare parts
219040300101	ASSY.WHEEL DISC & RIM 6.5X20(SPIGOTTED)	TATA spare parts
219040300102	ASSY.WHEELDISC&RIM 6.5X20(SPIGOT)	TATA spare parts
219040308201	REINFORCMENT BS6	TATA spare parts
21904048000R40	6OR_RESTRUCTURE_FOR_CVBU_IN_APL_VIEW	TATA spare parts
219041000101	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
219041000102	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
219041000103	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
219041000104	ASSY. UNITIZED PROP. SHAFT 42WB	TATA spare parts
219041000120	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
219041000122	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
219041100101	ASSY.PROP.SHAFT WITH CENTRE BEARING.	TATA spare parts
219041100104	ASSY.PROP.SHAFT (REAR)	TATA spare parts
219041100106	ASSY.PROP.SHAFT WITH CENTRE BEARING	TATA spare parts
219041100109	ASSY.PROP.SHAFT COMPL.(REAR)	TATA spare parts
219041108203	PROP. SHAFT GUARD	TATA spare parts
219041108205	BRACKET PROPELLER SHAFT GUARD	TATA spare parts
219041110101	ASSY PROP SHAFT WITH CENTRE BRG	TATA spare parts
219041110118	ASSY.PROP.SHAFT (FRONT)	TATA spare parts
219041110119	ASSY.PROP.SHAFT (FRONT)	TATA spare parts
219041118201	SPACER(CENTRE BEARING MTG.BKT.)	TATA spare parts
219041118202	SPACER CENTER BRG MTG	TATA spare parts
219041118203	SPACER CENTER BRG MTG	TATA spare parts
219041118205	SPACER CENTRE BEARING MTG.BKT.	TATA spare parts
219041120101	ASSY PROP SHAFT REAR COMPLETE	TATA spare parts
219041120104	PROPELLER SHAFT ASSY FRONT	TATA spare parts
219041120115	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
219041120123	ASSY.REAR PROP.SHAFT COMPLETE	TATA spare parts
219041120126	PROPELLER SHAFT ASSY REAR BS6	TATA spare parts
219041129901	FLANGE YOKE	TATA spare parts
219041129902	KIT- U J	TATA spare parts
219041129903	SLEEVE YOKE	TATA spare parts
219041129904	KIT-SLIP YOKE ASSY	TATA spare parts
219042100148	AUTO SLACK ADJUSTER	TATA spare parts
219042100150	DRUM BRAKE ASSY¿ LH	TATA spare parts
219042100151	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts

219042108211	ANCHOR BRACKET ASA LH BS6	TATA spare parts
219042108212	ANCHOR BRACKET AUTO SLACK ADJUSTER RH BS	TATA spare parts
219042300103	ASSY BRACKET LH (FOR 16/24 STRAIGHT PORT	TATA spare parts
219042300104	ASSY BRACKET RH (FOR 16/24 STRAIGHT PORT	TATA spare parts
219042300105	AUTO_SLACK_ADJUSTER (STRAIGHT)	TATA spare parts
219042303702	BRACKET ACTUATOR MTG LH	TATA spare parts
219042303703	BRACKET ACTUATOR MTG RH	TATA spare parts
219042900101	SET ASSY.NYLON PIPE COMPLETE	TATA spare parts
219042990134	BRACKET ASSLY LH	TATA spare parts
219042990135	BRACKET ASSLY RH	TATA spare parts
219042990138	BUSH(BI METAL)	TATA spare parts
219043400102	BRACKET ASSY BS6	TATA spare parts
219043700110	HAND BRAKE VALVE ASSY BS6	TATA spare parts
219043700115	BRACKET ASSY MODULATOR VALVE MTG	TATA spare parts
219043700120	RELAY VALVE & MODULATOR VALVE ASSY BS6	TATA spare parts
219043708201	BRACKET MODULATOR VALVE MTG.	TATA spare parts
219043709901	REPAIR KIT BRAKE CHAMBER	TATA spare parts
219043709902	REPAIR KIT BRAKE ACTUATOR	TATA spare parts
219043900130	ASSY NYLON PIPE SET COMPLETE(CHASSIS)	TATA spare parts
219043900168	ASSY NYLON PIPE CHASSIS COMPL LPT1109/42	TATA spare parts
219043900201	ASSLY METAL PIPE DIA15 (COMP. TO DDU)	TATA spare parts
219043900223	PIPE ASSY CRIMPED HOSE TO DDU	TATA spare parts
219043900224	PIPE ASSY COMPRESSOR TO CRIMPED HOSE	TATA spare parts
219043900226	PIPE BUNCH ASSY COMPLETE FOR 30WB	TATA spare parts
219043900237	PIPE ASSY MODULATOR PORT TO REAR-LH	TATA spare parts
219043900238	PIPE ASSY MODULATOR PORT TO REAR-RH	TATA spare parts
219043900239	PIPE ASSY BRACKET TO T-CONN	TATA spare parts
219043903305	BRACKET	TATA spare parts
219043903310	BRACKET FOR METAL PIPE CLAMPING	TATA spare parts
219043903313	BRACKET (NYLON BUNCH)	TATA spare parts
219043903322	BRACKET	TATA spare parts
219043903323	BRACKET	TATA spare parts
219043906808	SOCKET	TATA spare parts
219043907501	GROMMET	TATA spare parts
219043908201	BRACKET	TATA spare parts
219043910101	ASSY METAL PIPE (FROM DDU TO COMP)	TATA spare parts
219043910103	NYLON PIPE KIT FOR LPT1109 42WB	TATA spare parts
219043910104	RETRO KIT FOR LPT1109 42WB	TATA spare parts
219043910118	ASSY.NYLON PIPE SET CHASSIS COMPL.	TATA spare parts
219043910125	ASSY.NYLON PIPE SET-LPT1109/48 SLEEP.CAB	TATA spare parts
219043910136	NYLON PIPE BUNCH ASSY .	TATA spare parts
219043910139	METAL PIPE ASSY HOSE END TO DDU	TATA spare parts
219043910201	METAL PIPE ASSY WITH CRIMPED RUBBER HOSE	TATA spare parts
219043910202	METAL PIPE ASSY JOINT 1 TO JOINT 2	TATA spare parts
219043910203	METAL PIPE ASSY JOINT TO DDU	TATA spare parts
219043910205	PIPE BUNCH ASSY CHASSIS	TATA spare parts
219043910221	PIPE BUNCH ASSY COMP FOR LPT1109/42WB	TATA spare parts

219043910226	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
219043910249	RELAY VALVE & MODULATOR VALVE ASSY BS6	TATA spare parts
219043910251	MODULATOR VALVE WITH MTG BKT BS6	TATA spare parts
219043910252	METAL PIPE ASSY JOINT TO DDU BS6	TATA spare parts
219043910256	METAL PIPE ASSY JOINT 1 TO JOINT 2 BS6	TATA spare parts
219043910259	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
219043910262	METAL PIPE ASSY CRIMPED HOSE TO DDU	TATA spare parts
219043910263	PIPE BUNCH ASSY CABIN BS6	TATA spare parts
219043920126	PIPE BUNCH ASSY	TATA spare parts
219043920136	"PIPE ASSY FROM, QRV TO RBA LH"	TATA spare parts
219043920137	"PIPE ASSY FROM, QRV TO RBA RH"	TATA spare parts
219043920149	PIPE ASSY AXLE MTG BKT TO RBA LH	TATA spare parts
219043920152	PIPE ASSY AXLE MTG BKT TO RBA RH	TATA spare parts
219043920193	PIPE BUNCH ASSY COMP FOR LPT1109/42WB	TATA spare parts
219043920212	PIPE BUNCH ASSY	TATA spare parts
219043920215	PIPE BUNCH ASSY COMP FOR LPT1109/36WB	TATA spare parts
219043920220	PIPE BUNCH ASSY	TATA spare parts
219043920227	METAL PIPE ASSY HOSE TO COUPLING	TATA spare parts
219043920228	METAL PIPE ASSY COUPLING TO DDU	TATA spare parts
219043930125	PIPE BUNCH ASSY COMP FOR LPT1109/48WB	TATA spare parts
219043930140	PIPE BUNCH ASSY	TATA spare parts
219043930161	PIPE BUNCH ASSY COMP FOR LPT1109/42WB	TATA spare parts
219043930173	PIPE BUNCH ASSY COMP FOR LPT1109/48WB	TATA spare parts
219043930201	PIPE BUNCH ASSY	TATA spare parts
219043930204	PIPE BUNCH ASSY	TATA spare parts
219043930206	PIPE BUNCH ASSY	TATA spare parts
219043930299	PIPE BUNCH ASSY	TATA spare parts
219043940106	PIPE BUNCH ASSY	TATA spare parts
219043950105	PIPE ASSY BS6	TATA spare parts
219043950111	PIPE BUNCH ASSY CHASSIS	TATA spare parts
219046100104	ASSY BRACKET POWER STG GB MOUNTING	TATA spare parts
219046100107	STEERING COLUMN ASSY	TATA spare parts
219046100109	STEERING COLUMN ASSY UPPER	TATA spare parts
219046100110	STEERING COLUMN ASSY INTERMEDIATE 25MM	TATA spare parts
219046100112	RUBBER BELLOW ASSY	TATA spare parts
219046100113	RUBBER BELLOW ASSY¿BS6	TATA spare parts
219046100116	INTERMEDIATE SHAFT ASSY 20MM	TATA spare parts
219046200106	FILTER ASM	TATA spare parts
219046200111	ASSY. STEERING GEAR BOX (POWER)	TATA spare parts
219046200120	ASSY RES. TANK MTG. BKT.	TATA spare parts
219046305101	PITMAN ARM	TATA spare parts
219046306001	PITMAN ARM	TATA spare parts
219046600102	DRAG LINK ASSEMBLY-RHD	TATA spare parts
219046600109	POWER STEERING GEAR ASSY	TATA spare parts
219046600110	POWER STEERING GEAR ASSY	TATA spare parts
219046600111	STEERING GEAR BOX ASSY	TATA spare parts
219046600112	KIT-SEAL INPUT SHAFT	TATA spare parts

219046600113	VALVE¿HSG¿ASSY	TATA spare parts
219046600114	RACK¿ASSY	TATA spare parts
219046600115	STEERING GEAR BOX ASSY	TATA spare parts
219046600116	HOUSING ASSY BS6	TATA spare parts
219046600117	HOUSING ASSY	TATA spare parts
219046600118	HOUSING ASSY VALVE BS6	TATA spare parts
219046603102	NEEDLE BEARING	TATA spare parts
219046608002	ADJUSTING SCREW	TATA spare parts
219046703301	BRACKET STG GEAR BOX MTG	TATA spare parts
219046707101	SPACER	TATA spare parts
219046800101	RETURN LINE ASSY	TATA spare parts
219046800102	PRESSURE LINE ASSY	TATA spare parts
219046800103	SUCTION LINE ASSY	TATA spare parts
219046800104	SUCTION LINE ASSY	TATA spare parts
219046800106	HIGH PRESSURE LINE ASSY	TATA spare parts
219046800108	RETURN LINE ASSY RESERVOIR TO JOINT	TATA spare parts
219046800109	ASSY PIPE SUCTION LINE(RES. TANK TO PUMP	TATA spare parts
219046800110	ASSY PIPE TRANSFER LINE (PUMP TO GEAR BO	TATA spare parts
219046800111	ASSY PIPE RETURN(GEAR BOX TO RES. TANK)	TATA spare parts
219046800124	SUCTION LINE ASSY RESERVOIR END	TATA spare parts
219046800131	SUCTION LINE ASSY	TATA spare parts
219046800132	RETURN LINE ASSY	TATA spare parts
219046800133	HIGH PRESSURE LINE ASSY	TATA spare parts
219046900101	DRAG LINK ASSY	TATA spare parts
219046900103	BALL JOINT ASSY	TATA spare parts
219046990102	BALL JOINT ASSY	TATA spare parts
219047100105	FUEL TANK ASSY 120 LTR	TATA spare parts
219047100106	ASSY FUEL CAP & CHAIN - REUTTER BS1-4	TATA spare parts
21904742000R40	PARTIALLY FITTED CAB W/O ELECTRICALS	TATA spare parts
219047600101	ASSY FUEL LINE (SUCTION)-TANK TO BABY FI	TATA spare parts
219047600102	ASSY. FUEL SUCTION LINE (BABY FILTER TO	TATA spare parts
219047600105	ASSY FUEL LINE (SUCTION)- WATER SEPARATO	TATA spare parts
219047600107	ASSY.SUCTION LINE(STRAINER TO MECH.F/P)	TATA spare parts
219047600108	ASSY.SUCTION LINE(FUEL TANK TO STRAINER)	TATA spare parts
219047600111	ASSY SUCTION LINE (TANK TO STRAINER)	TATA spare parts
219047600112	ASSY.SUCTION LINE (STRAINER TO W/SEP)	TATA spare parts
219047600113	ASSY.SUCTION LINE (W/SEP TO MECH.FEED PU	TATA spare parts
219047600114	ASSY.RETURN LINE (OVERFLOW TO TANK)	TATA spare parts
219047600132	FUEL SUCTION LINE TANK TO PREFILTER	TATA spare parts
219047600134	FUEL SUCTION LINE ASSY MAIN F.TO FIP	TATA spare parts
219047600135	RETURN LINE ASSY ON TANK	TATA spare parts
219047600140	FUEL SUCTION PIPE ASSY PROTECTOMAINFIL	TATA spare parts
219047600141	FUEL SUCTION PIPE ASSY PROTECT TO M. FIL	TATA spare parts
219047600142	FUEL SUCTION PIPE ASSY M.FILTER TO FIP	TATA spare parts
219047600143	FUEL RETURN PIPE ASSY	TATA spare parts
219047600144	SUCTION PIPE ASSY FUEL TANK TO STRAINER	TATA spare parts
219047600145	SUCTION PIPE ASSY BABY FILTER TO PUMP	TATA spare parts

219047600146	SUCTION PIPE ASSY FEED PUMP TO FILTER	TATA spare parts
219047600147	SUCTION PIPE ASSY FILTER TO FIP	TATA spare parts
219047600148	FUEL RETURN PIPE ASSY ENGINE TO TANK	TATA spare parts
219047608203	BRACKET PRE FILTER MTG	TATA spare parts
219047608204	BRACKET PRE FILTER MTG	TATA spare parts
219047608205	BRACKET PRE FILTER MTG	TATA spare parts
219047990102	ELECTRIC FEED PUMP KIT LP/LPT1112 BSIII	TATA spare parts
219049100101	ASSY.SILENCER	TATA spare parts
219049100104	PIPE ASSY DPS SENSOR	TATA spare parts
219049100105	ASSY. EXHAUST PIPE (SILENCER-DPS)	TATA spare parts
219049100107	SILENCER ASSY	TATA spare parts
219049100113	PIPE ASSY DPS SENSOR INTAKE	TATA spare parts
219049100115	PIPE ASSY DPS SENSOR REAR	TATA spare parts
219049105801	RUBBER HOSE(PRE-CATCON)	TATA spare parts
219049105802	RUBBER HOSE POST-CATCON	TATA spare parts
219049105803	RUBBER HOSE PRE CATCON	TATA spare parts
219049105805	TUBE DPS SENSOR OUTLET	TATA spare parts
219049105806	HOSE DPS SENSOR	TATA spare parts
219049109901	HEAT SHIELD-EXHAUST POC DOC	TATA spare parts
219049109902	HEAT SHIELD OUTER	TATA spare parts
219049109903	HEAT SHIELD OUTER	TATA spare parts
219049109904	HEAT SHIELD OUTER	TATA spare parts
219049109905	HEAT SHIELD OUTER	TATA spare parts
219049109906	HEAT SHIELD OUTER	TATA spare parts
219049109907	HEAT SHIELD OUTER	TATA spare parts
219049109908	HEAT SHIELD OUTER	TATA spare parts
219049200101	ASSY.FRONT EXHAUST PIPE	TATA spare parts
219049200104	BRACKET FOR SILENCER MOUNTING RR	TATA spare parts
219049200106	ASSY INTERMEDIATE PIPE:36WB	TATA spare parts
219049200107	ASSY INTERMEDIATE PIPE(42WB)	TATA spare parts
219049200108	ASSY BRACKET (FOR EXHAUST MTG)	TATA spare parts
219049200109	ASSY.FRONT EXHAUST PIPE (WITH FLIEX BELL	TATA spare parts
219049200110	ASSY.FRONT EXHAUST PIPE (WITH FLEXIBLE B	TATA spare parts
219049200111	ASSY.MOUNTING STRAP	TATA spare parts
219049200112	ASSY. BRACKET (SILENCER MTG. TOP)	TATA spare parts
219049200114	ASSY.FRONT EXHAUST PIPE WITH BELLOW	TATA spare parts
219049200115	ASSY. HOOK WITH BRACKET	TATA spare parts
219049200117	ASSY.FRONT EXHAUST PIPE WITH FLEX BELLOW	TATA spare parts
219049200119	PIPE ASSY WITH BELLOW FRONT	TATA spare parts
219049200121	ASSY. BRACKET (POC DOC MTG)	TATA spare parts
219049200123	PIPE ASSY INTERMEDIATE	TATA spare parts
219049200124	BRACKET ASSY MAIN SILENCER MTG	TATA spare parts
219049200127	BRACKET ASSY FRONT PIPE MTG	TATA spare parts
219049200131	EXHAUST PIPE ASSY INT LH	TATA spare parts
219049200137	EXH PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
219049200138	EXH PIPE ASSY FLANGE TO CATCONE FRONT	TATA spare parts
219049200139	SILENCER ASSY W/O BRACKET	TATA spare parts



219049200140	BRACKET ASSY DOC POC MTG	TATA spare parts
219049203306	BRACKET	TATA spare parts
219049203307	BRACKET CATCON MTG REAR	TATA spare parts
219049208201	BRACKET	TATA spare parts
219049208202	BRACKET FOR SILENCER MOUNTING	TATA spare parts
219049208203	BRACKET FOR SILENCER MOUNTING	TATA spare parts
219049208206	BRACKET	TATA spare parts
219049208210	SUPPORT BRACKET	TATA spare parts
219049208213	STRAP (POC-DOC MTG)	TATA spare parts
219049209901	HEAT SHIELD-EXHAUST PIPE-1ST PIECE	TATA spare parts
219049209902	HEAT SHIELD-EXHAUST PIPE-2ND PIECE	TATA spare parts
219049209903	HEAT SHIELD-EXHAUST PIPE-3RD PIECE	TATA spare parts
219049209904	HEAT SHIELD-EXHAUST PIPE-4TH PIECE	TATA spare parts
219049209905	HEAT SHIELD-EXHAUST PIPE-5TH PIECE	TATA spare parts
219049700102	NOISE SHIELD ASSY BOTTOM FRONT	TATA spare parts
219054100109	BATT CABLE+VE 0.6M W/COT 35SQMM	TATA spare parts
219054100110	ASSY BATT CABLE +VE 0.6M 35SQ ISO	TATA spare parts
219054100113	ASSY. BATTERY CABLE MEGA FUSE	TATA spare parts
219054100116	EARTH CABLE	TATA spare parts
219054100122	BATTERY CABLE + VE	TATA spare parts
219054108202	LPT STARTER FUSE MTG BKT	TATA spare parts
219054108203	STARTER FUSE MTG BKT _LPT	TATA spare parts
219054110101	ASSY. COPPER BATTERY CABLE - VE	TATA spare parts
219054110102	ASSY. COPPER BATTERY CABLE - VE	TATA spare parts
219054200103	INSTRU.CLUSTER 0.72 LP 1112	TATA spare parts
219054200107	INSTRUMENT CLUSTER ASSY	TATA spare parts
219054200108	INST.CLUST 0.85 ESP LPT1109 BS3	TATA spare parts
219054200110	INST.CLUST 0.85 ESP LPT1109BS3	TATA spare parts
219054200114	INST_CLUSTER_LPT1109BSIV_W_PTO	TATA spare parts
219054200116	ASSY BRACKET (HORN MTG)	TATA spare parts
219054200117	ASSY MTG BRKT- AUTO DRAIN CONTROLLER	TATA spare parts
219054200120	ASSY. MTG BRACKET AUTODRAIN CONTROLLER	TATA spare parts
219054200129	INSTRUMENT CLUSTER ASSY	TATA spare parts
219054200133	INSTRUMENT CLUSTER ASSY	TATA spare parts
219054200212	INSTRUMENT CLUSTER ASSY	TATA spare parts
219054201601	INSTRUMENT CLUSTER (1:0.72)	TATA spare parts
219054204901	MICRO RELAY 12V 20A NO W/DIODE	TATA spare parts
219054204902	MICRO RELAY 12V 20A NO W/DIODE-M/S R ENG	TATA spare parts
219054208201	BRACKET FOR ACC RELAY MOUNTING	TATA spare parts
219054208204	MOUNTING BRACKET AUTODRAIN CONTROLLER	TATA spare parts
219054209901	INSTRUMENT CLUSTER(1:0.72)	TATA spare parts
219054209904	INSTRUMENT CLUSTER(1:0.72)	TATA spare parts
219054209907	INSTRUMENT CLUSTER(1:0.72)	TATA spare parts
219054209908	INSTRUMENT CLUSTER (1:0.72)	TATA spare parts
219054209909	INSTRUMENT CLUSTER (1:0.72)	TATA spare parts
219054304901	WIF CONTROLLER WITH AUTO DRAIN BS1-4	TATA spare parts
219054400105	LAMP INSPECTION (7M) - 12V	TATA spare parts

219054400109	TAIL LAMP MTG ASSY LH	TATA spare parts
219054400110	TAIL LAMP MTG ASSY RH	TATA spare parts
219054500101	ASSY COMBINATION SWITCH	TATA spare parts
219054500107	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
219054600103	BATTERY CABLE +VE MEGA FUSE	TATA spare parts
219054600111	BATTERY CABLE +VE	TATA spare parts
219054600112	WIRING HARNESS MAIN	TATA spare parts
219054600113	BATTERY CABLE +VE	TATA spare parts
219054600114	WIRING HARNESS TAIL	TATA spare parts
219054600118	WIRING HARNESS MAIN	TATA spare parts
219054600126	BATTERY CABLE -VE VEH BATT TO SM	TATA spare parts
219054600158	BATTERY CABLE -VE	TATA spare parts
219054600161	FUSE BOX COVER	TATA spare parts
219054600162	BATTERY CABLE +VE MAXI FUSE O/P TO SM	TATA spare parts
219054600163	BATTERY CABLE + VE	TATA spare parts
219054600164	WIRING HARNESS ABS PIGTAIL	TATA spare parts
219054600165	WIRING HARNESS ABS PIGTAIL	TATA spare parts
219054600167	WIRING HARNESS MAIN ABS	TATA spare parts
219054600168	WIRING HARNESS MAIN ABS	TATA spare parts
219054600170	WIRING HARNESS ENGINE	TATA spare parts
219054600171	WIRING HARNESS ENGINE	TATA spare parts
219054600174	WIRING HARNESS TAIL	TATA spare parts
219054600176	WIRING HARNESS MAIN ABS BS4	TATA spare parts
219054600177	WIRING HARNESS MAIN ABS	TATA spare parts
219054600179	WIRING HARNESS TAIL	TATA spare parts
219054600180	WIRING HARNESS TAIL	TATA spare parts
219054600182	WIRING HARNESS CAB TILT SWITCH	TATA spare parts
219054600183	WIRING HARNESS CAB TILT SWITCH	TATA spare parts
219054600185	WIRING HARNESS TAIL	TATA spare parts
219054600186	WIRING HARNESS TAIL	TATA spare parts
219054600188	WIRING HARNESS TAIL	TATA spare parts
219054600192	WIRING HARNESS TAIL	TATA spare parts
219054600194	WIRING HARNESS TAIL	TATA spare parts
219054600197	WIRING HARNESS ENGINE	TATA spare parts
219054600198	WIRING HARNESS ENGINE	TATA spare parts
219054601621	PIGTAIL EXHAUST BRAKE SOLENOID VALVE	TATA spare parts
219054601629	BATTERY CABLE -VE	TATA spare parts
219054601642	WIRING HARNESS MAIN	TATA spare parts
219054601643	WIRING HARNESS ENGINE	TATA spare parts
219054601660	BATTERY CABLE +VE	TATA spare parts
219054601666	WIRING HARNESS TAIL	TATA spare parts
219054601688	WIRING HARNESS ABS PIGTAIL	TATA spare parts
219054601693	WIRING HARNESS MAIN ABS	TATA spare parts
219054601696	WIRING HARNESS TAIL	TATA spare parts
219054603306	BRACKET MEGA FUSE BOX HOLDER MTG	TATA spare parts
219054603307	BRACKET ENGINE CONNECTOR MTG	TATA spare parts
219054608204	W/H MTG BKT ON RADIATOR BKT-LPT1112	TATA spare parts

219054608209	BRACKET F/B MTG LH	TATA spare parts
219054610101	WIRING HARNESS ENGINE	TATA spare parts
219054610102	WIRING HARNESS ENGINE	TATA spare parts
219054610104	WIRING HARNESS TAIL	TATA spare parts
219054610106	WIRING HARNESS TAIL	TATA spare parts
219054610108	WIRING HARNESS TAIL	TATA spare parts
219054610110	WIRING HARNESS TAIL	TATA spare parts
219054610111	WIRING HARNESS TAIL	TATA spare parts
219054610113	WIRING HARNESS MAIN ABS	TATA spare parts
219054610114	WIRING HARNESS MAIN ABS	TATA spare parts
219054610115	WIRING HARNESS MAIN ABS	TATA spare parts
219054610137	BATTERY CABLE POSITIVE	TATA spare parts
219054610140	FUSE BOX MTG ASSY	TATA spare parts
219054610151	WIRING HARNESS ABS FRAME	TATA spare parts
219054610156	WIRING HARNESS ABS FRAME	TATA spare parts
219054610170	WIRING HARNESS,SENSOR	TATA spare parts
219054610198	WIRING HARNESS MAIN	TATA spare parts
219054610199	WIRING HARNESS ENGINE	TATA spare parts
219054611610	WIRING HARNESS TAIL	TATA spare parts
219054611611	WIRING HARNESS TAIL	TATA spare parts
219054611619	WIRING HARNESS ENGINE	TATA spare parts
219054611627	WIRING HARNESS TAIL	TATA spare parts
219054611628	WIRING HARNESS MAIN	TATA spare parts
219054611629	WIRING HARNESS TAIL	TATA spare parts
219054611630	WIRING HARNESS TAIL	TATA spare parts
219054611631	WIRING HARNESS ENGINE	TATA spare parts
219054611639	WIRING HARNESS TAIL	TATA spare parts
219054611641	WIRING HARNESS MAIN ABS	TATA spare parts
219054611652	WIRING HARNESS ENGINE	TATA spare parts
219054611656	WIRING HARNESS CAB TILT SWITCH	TATA spare parts
219054611660	WIRING HARNESS TAIL	TATA spare parts
219054611663	WIRING HARNESS ENGINE	TATA spare parts
219054611665	WIRING HARNESS MAIN ABS	TATA spare parts
219054611666	PIGTAIL ENGINE LAMP	TATA spare parts
219054611667	WIRING HARNESS TAIL	TATA spare parts
219054611668	WIRING HARNESS MAIN	TATA spare parts
219054611679	WIRING HARNESS TAIL	TATA spare parts
219054611684	WIRING HARNESS TAIL	TATA spare parts
219054611685	WIRING HARNESS TAIL	TATA spare parts
219054611687	WIRING HARNESS TAIL	TATA spare parts
219054611688	WIRING HARNESS TAIL	TATA spare parts
219054620101	W/H SIDE MARKER LAMP LPT1112/36WB	TATA spare parts
219054620102	W/H SIDE MARKER LAMP LPT1112/42WB	TATA spare parts
219054620106	W/H SENSOR LPT1112 BS-III¿ SLEEPER CAB W	TATA spare parts
219054620107	W_H_TAIL_LPT_1112_42WB_BSIV	TATA spare parts
219054620108	W/H TAIL LPT1112/36WB EX2	TATA spare parts
219054620109	W/H TAIL	TATA spare parts

219054620111	WIRING HARNESS TAIL	TATA spare parts
219054620115	WIRING HARNESS SENSOR	TATA spare parts
219054620117	WIRING MAIN HARNESS BS3	TATA spare parts
219054620119	W/H MAIN (WITH AD) LPT 709/909 CANOPY	TATA spare parts
219054620121	W/H MAIN LPT1112 BSIII S/CAB	TATA spare parts
219054620122	W/H TAIL LPT 1109 BSIV	TATA spare parts
219054620123	W/H_TAIL_LPT_1109_BSIV_36WB_PTO_EOBD	TATA spare parts
219054620124	WIRING HARNESS TAIL	TATA spare parts
219054620126	W/H TAIL LPT1109/42WB W/PTO EX2 WITH OBD	TATA spare parts
219054620137	WIRING HARNESS TAIL	TATA spare parts
219054620166	WIRING HARNESS ENGINE	TATA spare parts
219054620168	WIRING HARNESS ENGINE	TATA spare parts
219054620169	WIRING HARNESS MAIN	TATA spare parts
219054620171	WIRING HARNESS MAIN BS4	TATA spare parts
219054620172	WIRING HARNESS MAIN	TATA spare parts
219054620178	BATTERY CABLE +VE	TATA spare parts
219054620179	BATTERY CABLE +VE	TATA spare parts
219054630104	W/H SIDE MARKER LAMP LPT1109/42WB WITH H	TATA spare parts
219054630105	W/H SIDE MARKER LAMP LPT1109/36WB	TATA spare parts
219054640101	W/H ENGINE	TATA spare parts
219054660101	W/H MAIN LP/LPT-1112 BS-III	TATA spare parts
219054660102	W/H TAIL-LP/LPT-1112/36 BS-III	TATA spare parts
219054660103	W/H TAIL-LP/LPT-1112/42-BS-III	TATA spare parts
219054660104	W/H ENGINE-LP/LPT-1112 BS-III	TATA spare parts
219054660105	W/H INST CONS-LP/LPT-1112 BS-3	TATA spare parts
219054660106	W/H MAIN LP/LPT-1112 BS-III	TATA spare parts
219054660131	W/H SIDE MARKER LAMP	TATA spare parts
219054660138	W/H SIDE MARKER LAMP LPT1109/36WB HDLB-T	TATA spare parts
219054660140	W/H MAIN LPT407/709/1109EXBSIII_AD	TATA spare parts
219054660141	¿WIRING HARNESS MAIN(WITH AD)LPT 1109	TATA spare parts
219054670102	W/H SENSOR LPT 497 BSIII_AD	TATA spare parts
219054690130	RETRO W/H AUTODRAIN CONTROLLER	TATA spare parts
219054690135	RETRO W/H 3 POLE SENSOR AUTODRAIN	TATA spare parts
219054690137	W/H SENSOR LPT 497 BSIII_AD	TATA spare parts
219054690138	W/H MAIN(WITH AD)LPT407/709/909/1109 EX	TATA spare parts
219054690139	MAIN WIRING HARNESS	TATA spare parts
219054707101	PLATE SPEED LIMITER DEVICE MOTOR MTG	TATA spare parts
219054820101	W/H MAIN LP/LPT-1112 BS-III	TATA spare parts
219054820102	W/H TAIL -W.B 36	TATA spare parts
219054820103	W/H TAIL-W.B 42	TATA spare parts
219054820104	W/H MAIN LP/LPT-1112 BS-III	TATA spare parts
219054820105	W/H TAIL-LP/LPT-1112/36-BS-III	TATA spare parts
219054820106	W/H TAIL-LP/LPT-1112/42-BS-III	TATA spare parts
219054820107	W/H ENGINE-LP/LPT-1112	TATA spare parts
219054820109	W/H MAIN LP/LPT-1112 BS-III	TATA spare parts
219054820110	W/H-ADD ON FOR FEED PUMP LPT-1112 BS-III	TATA spare parts
219054900103	BRACKET ASSY ECU MTG BS6	TATA spare parts

219058903501	SPL SOCKET WRENCH¿ FOR LOCK RING M62X2	TATA spare parts
21906000001R40	ASSY. CAB W/PARTIAL FITMENTS LPK1212 BS3	TATA spare parts
21906000007R40	ASSEMBLY BODY FITTED	TATA spare parts
21906000008R40	ASSEMBLY BODY FITTED	TATA spare parts
219060000101	ASSY. CAB COMPLETE LPT1112 BSIII	TATA spare parts
219060000102	ASSY. CABIN BARE LPT 1109EX CLB PTOP BS3	TATA spare parts
219060000105	ASSY.COWL COMPLETE LP1112 BSIII	TATA spare parts
219060000106	ASSY.COWL SHELL PAINTED LP1112 BS III	TATA spare parts
21906000011R40	PARTIAL FITTED CABIN	TATA spare parts
219060000125	ASSY.CAB COMPLETE.	TATA spare parts
219060000126	ASSY CAB SHELL PAINTED	TATA spare parts
219060000129	PARTIALLY FITTED CAB W/O ELECT&CONTROLS	TATA spare parts
219060000130	ASSY. CABIN BARE LPT 1109 EX2 TCAB BS3	TATA spare parts
21906000014R40	PARTIALLY FITTED CAB W/O ELECTICALS &AMP	TATA spare parts
219060000150	ASSY.CAB COMPLETE 1109 H EX2 BSIII	TATA spare parts
219060000152	PARTIALLY FITTED CAB W/O ELECT.& CONTROL	TATA spare parts
219060000153	ASSY. CABIN BARE LPT 1109 HEX2 CLB BS3	TATA spare parts
219060000157	ASSY. CABIN BARE LPT 1109 EX CLB BS3/4	TATA spare parts
219060000157BRBL	BARE CAB-LPT1109 BRICK RED BLW	TATA spare parts
219060000157GBBL	BARE CAB-LPT1109 GOLDEN BROWN BLW	TATA spare parts
219060000160	ASSY. CABIN W/O FITMENT LPT1109 BS3	TATA spare parts
219060000161	ASSY.CAB COMPLETE.(POWER STRNG)	TATA spare parts
219060000168	CAB SHELL ASSY PAINTED	TATA spare parts
219060000175	ASSY. CABIN BARE LPT 1109 EX CLB BS4	TATA spare parts
219060000175AWNB	BARE CAB LPT1109 ARTIC WHITE NB	TATA spare parts
219060000175GBNB	BARE CAB LPT1109 GOLDEN BROWN NB	TATA spare parts
219060000175GYNB	BARE CAB LPT1109 GOLDEN YELLOW NB	TATA spare parts
2190606001CK99	ASSY. CABIN KIT LPT1109 BS2/3/4	TATA spare parts
219060CK0195	CAB KIT-1112 EX/36 BSIII PS	TATA spare parts
219060CK0196	CAB KIT-1109H EX2 BSIII/42 SCLB	TATA spare parts
219060CK0197	CAB LPT 1109H EX2 BSIII/42 PTOP 12.99T	TATA spare parts
219060CK0198	ASSY. CABIN KIT LPT1109 EX2 TCAB BS3	TATA spare parts
219060CK0199	CAB LPT 1109H EX2 BSIII/42 PTOP 12.99T	TATA spare parts
219061000111	ASSY.SUBSTRUCTURE W/O STEP PNL	TATA spare parts
219061000116	ASSY.SUBSTRUCTURE WITH FLOOR & W/O STPL	TATA spare parts
219081100101	ASSY COVER LH (PANEL OUTER CORNER FRONT)	TATA spare parts
219081100102	ASSY COVER RH (PANEL OUTER CORNER FRONT)	TATA spare parts
219081800101	ASSY. 1112 EX MASCOT	TATA spare parts
219081800110	ASSY 1109H EX2 BS-III MASCOT	TATA spare parts
219081800111	MASCOT ASSY 1109 EX	TATA spare parts
219081800112	ASSY 1109H EX2 CRDI BS-III MASCOT	TATA spare parts
219082903301	BRACKET BS6	TATA spare parts
219089100102	ASSY MTG BRKT COMPLETE - LH (CHASSIS SID	TATA spare parts
2190891001020D	ASSY MTG BKT COMPLT-LH CHASSIS SIDE BS6	TATA spare parts
219089100103	ASSY MTG BRKT COMPLETE RH (CHASSIS SIDE)	TATA spare parts
219089100104	ASSY.MUDGUARD SUPPORT LH	TATA spare parts
219089100105	ASSY.MUDGUARD SUPPORT RH	TATA spare parts

219116100102	CONTAINER (ECU- 697TC BSIII)(MODIFIED)	TATA spare parts
219120140101	FAN ENGINE	TATA spare parts
219120157001	PULLEY	TATA spare parts
219124200101	ASSY.BRACKET ENGINE MTG.REAR	TATA spare parts
219126800108	ASSY.BELLOW MOUNTING BRACKET	TATA spare parts
219126800109	ASSY.CONTROL BOX	TATA spare parts
219126800112	ASSY. BRACKET CONTROL BOX MOUNTING	TATA spare parts
219126800118	ASSY GEAR SHIFTING CABLE	TATA spare parts
219126800121	ASSY MTG BKT PGS -VOITH	TATA spare parts
219126800122	ASSY CABLE SHIFTING MECH	TATA spare parts
219126806901	LEVER PIVOT PIN	TATA spare parts
219126807902	LINK ROD	TATA spare parts
219126807903	LINK ROD	TATA spare parts
219126808205	CONTROL BOX COVER BOTTOM	TATA spare parts
219126808208	CONTROL BOX LOWER COVER	TATA spare parts
219126808240	JOINING ANGLE	TATA spare parts
219126808241	ANGLE - FIXED	TATA spare parts
219129100105	ASSY BKT BOOSTER MTG	TATA spare parts
219129100108	ASSY SUPPORT COMPLETE (CLUTCH)	TATA spare parts
219129100110	ASSY CLUTCH PEDAL COMPLETE	TATA spare parts
219129100114	ASSY PIPE 8 OD FIRST	TATA spare parts
219129100115	ASSY PIPE 8OD SECOND	TATA spare parts
219129100116	ASSY PIPE 8 OD THIRD	TATA spare parts
219129100117	ASSY PUSH ROD	TATA spare parts
219129100118	ASSY PIPE 8OD FORTH	TATA spare parts
219129100119	ASSY PIPE 8 OD FIFTH	TATA spare parts
219129106001	CLUTCH RELEASE LEVER	TATA spare parts
219129106802	PIPE UNION BOLT	TATA spare parts
219129106901	PIPE 8 O.D. (FIRST)	TATA spare parts
219129106902	PIPE 8 O.D. (SECOND)	TATA spare parts
219129106903	PIPE 8 O.D. (THIRD)	TATA spare parts
219129106904	PIPE 8 O.D. (FOURTH)	TATA spare parts
219129106905	PIPE 8 O.D. (FIFTH)	TATA spare parts
219131108205	1ST REAR SUPPORT CROSS MEMBER	TATA spare parts
219131108206	2ND REAR SUPPORT CROSS MEMBER	TATA spare parts
219131108207	3RD REAR SUPPORT CROSS MEMBER	TATA spare parts
219131200150	ASSY BASE PLATE FOR FRONT OUT- RIGGER	TATA spare parts
219131203306	BRACKET ( HOSE CLAMPING)	TATA spare parts
219131206925	TOWING HOOK	TATA spare parts
219131207120	REINFORCEMENT PLATE ( FRONT SUSPENSION)	TATA spare parts
219131208201	GUSSET V ROD MTG BKT	TATA spare parts
219131700106	ASSY. BOTTOM SHIELD REAR	TATA spare parts
219131700107	ASSY. BOTTOM SHIELD FRONT	TATA spare parts
219131708271	BRACKET (BOTTOM NOISE SHIELD)	TATA spare parts
219132100102	RELAY AND INVERSION VALVE	TATA spare parts
219132100103	RELAY VALVE	TATA spare parts
219132100120	KIT LEVELLING VALVE -FRONT SUSPENSION	TATA spare parts

219132400102	RUBBER CONNECTOR SUB-ASSY.	TATA spare parts
219132400103	ASSY. REAR SHOCK ABSORBER	TATA spare parts
219132400104	ASSY LEVELLING VALVE	TATA spare parts
219132400105	MK II LEV.VALVE MINOR KIT	TATA spare parts
219132400106	MK II LEV. VALVE MAJOR KIT	TATA spare parts
219132403404	SPHERILASTIC BUSH ASSY	TATA spare parts
219132403701	U BOLT SADDLE	TATA spare parts
219132404201	U CLAMP M22X2.5X405MM	TATA spare parts
219132406601	VALVE POPPET	TATA spare parts
219132407103	LEVELLING VALVE LEVER	TATA spare parts
219132407701	12 INCH ROLLING DIAPHRAGM	TATA spare parts
219132407902	CONNECT.ROD (LEV.VALVE)	TATA spare parts
219141100101	ASSY.PROPELLER SHAFT	TATA spare parts
219142906802	L - SOCKET	TATA spare parts
219143700102	CONSEP UNIT	TATA spare parts
219143703301	MTG BKT CONSEP UNIT	TATA spare parts
219146207901	SPINDLE (BEVEL G/B TO STG.G/B)	TATA spare parts
219146607801	OIL SEAL	TATA spare parts
219147100103	ASSY HOSE WATER SEP TO BABY FILTER	TATA spare parts
219147500101	ASSY.BRACKET	TATA spare parts
219147506701	PIN	TATA spare parts
219147600101	ASSY PIPE FIP TO TANK	TATA spare parts
219147600102	ASSY PIPE WASTER SEP TO FEED PUMP	TATA spare parts
219147600103	ASSY PIPE BABY FILTER TO TANK	TATA spare parts
219147600104	ASSY PIPE ELE FEED PUMP TO DUAL FILTER	TATA spare parts
219149200101	ASSY EXHAUST PIPE - SECOND	TATA spare parts
219149200102	ASSY BRACKET	TATA spare parts
219149206902	EXHAUST PIPE - 3RD	TATA spare parts
219149208202	EXHAUST PIPE MTG BKT	TATA spare parts
219149208203	EXHAUST PIPE MTG BKT	TATA spare parts
219150100101	ASSY.RADIATOR WITH FRAME & INTERCOOLER	TATA spare parts
219150100102	RADIATOR ASSY	TATA spare parts
219150100103	ASSY AUXILLIARY TANK	TATA spare parts
219150100104	INTERCOOLER ASSY	TATA spare parts
219150105801	HOSE( AT WATER PUMP)	TATA spare parts
219150105802	HOSE ( RAD TOP )	TATA spare parts
219150105804	REDUCER HOSE ( DIA 12 TO 6 )	TATA spare parts
219150106901	PIPE (DIA 58 - ENG TO RAD )	TATA spare parts
219150106902	PIPE ( FILLING LINE DIA 28.6 )	TATA spare parts
219150506302	FAN SHROUD (WITH FAN RING )	TATA spare parts
219154100104	ASSY BATTERY CABLE LINK	TATA spare parts
219154110102	ASSY COPPER BATTERY CABLE -VE	TATA spare parts
219154209903	INST.CLUSTER(WITH E.S.M)-1:0.88	TATA spare parts
219154209905	VEHICLE SPEED SENSOR FOR E.S.M	TATA spare parts
219154509901	BATT. CUT OFF SW (1-POLE)	TATA spare parts
219154660101	W/H TAIL-LPO-1615 BS-III-RE-BUS	TATA spare parts
219154660102	W/H MAIN-LPO-1615 BS-III-RE-BUS	TATA spare parts

219154820101	W/H TAIL LPO 1615 697 E-III RE	TATA spare parts
219154820102	W/H MAIN LPO 1615 697 E-III RE	TATA spare parts
219158300101	ASSY HYD JACK COMPLETE	TATA spare parts
219160108202	STOPPER CLUTCH PEDAL	TATA spare parts
219216100101	CONTAINER (ECU 697TCIC BS3)-LPO1615	TATA spare parts
219224200102	ASSY.BRACKET-LH(ENG.MTG.REAR).	TATA spare parts
219224200103	ASSY.BRACKET-RH(ENG.MTG.REAR).	TATA spare parts
219226800103	ASSY.BRACKET (FOR GEAR SHIFT LEVER).	TATA spare parts
219226800104	ASSY. SELEC. SHIFTER FORK W/LEVR BS1- 4	TATA spare parts
219226800105	ASSY GEAR SHIFT LEVER	TATA spare parts
219226800107	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
219226808001	FLANGE BOLT	TATA spare parts
219226808002	FLANGE BOLT	TATA spare parts
219231000104	ASSY FRAME COMPLETE	TATA spare parts
219241100101	ASSY PROP SHAFT WITH CENTER BEARING	TATA spare parts
219241100104	ASSY. PROP SHAFT WITH CENTRE BRG. FRONT	TATA spare parts
219243900111	SET ASSY NYL PIPE LPO1615(VOSS)	TATA spare parts
219246150101	KIT ASSY PIPES FOR LPO 1615 697	TATA spare parts
219246150102	KIT ASSY PIPES FOR LPO 1615 697	TATA spare parts
219246607802	DUST CAP	TATA spare parts
219247600101	FUEL TANK SUCTION PORT TO BABY FILTER	TATA spare parts
219247600102	WATER SEPARATOR TO ELECTRIC FEED PUMP	TATA spare parts
219247600103	ELECTRIC FEED PUMP TO ENGINE	TATA spare parts
219247600104	BABY FILTER TO WATER SEPARATOR	TATA spare parts
219247600105	OVERFLOW LINE TO FUEL TANK RETURN PORT	TATA spare parts
219247600106	ENGINE TO WATER SEPARATOR (FUEL LINE)	TATA spare parts
219249208202	BRACKET	TATA spare parts
219254209903	INSTRUMENT CLUSTER (1:0.80)	TATA spare parts
219254209913	INSTRUMENT CLUSTER (1:0.88) E-SPD	TATA spare parts
219254209914	INSTRUMENT CLUSTER (1:0.88) E-SPD	TATA spare parts
219254660101	W/H-MAIN,LPO-1615 697 BS-III	TATA spare parts
219254660102	W/H-TAIL-LPO1615/53 697 BS-III	TATA spare parts
219254660104	W/H-ENGINE-LPO1615 697 BS-III	TATA spare parts
219300000154	ASSY KIT - FRAME RETRO	TATA spare parts
219300000158	ASSY RETRO KIT - 2ND X MEMBER (80 MM GUS	TATA spare parts
219309130102	HOSE CLAMP T BOLT	TATA spare parts
219309130103	HOSE CLAMP T BOLT BS4	TATA spare parts
219309130201	AIR FILTER ELEMENT PRIMARY	TATA spare parts
219309130202	AIR FILTER ELEMENT SECONDARY	TATA spare parts
219309130203	ELEMENT-AIR CLEANER(PRIMARY)	TATA spare parts
219309130204	ELEMENT-AIR CLEANER(SAFETY)	TATA spare parts
219309139001	DUST CAP SFC410	TATA spare parts
219322100101	ASSY. AIR COMPRESSURE PIPE	TATA spare parts
219322106801	CONNECTOR-M27 M22	TATA spare parts
219322106802	UNION-2W M22 M20	TATA spare parts
219331700102	BRAKE CHAMBER PROTECTION ASSEMBLY	TATA spare parts
219331700136	ASSY. RETRO KIT-FRAME REINFORCEMENT FOR	TATA spare parts



219331707141	REINFORCEMENT-LH ENG. MTG. REAR	TATA spare parts
219331707142	REINFORCEMENT-RH ENG. MTG. REAR	TATA spare parts
219331707149	FRAME REINFORCEMENT INNER - LH	TATA spare parts
219331707150	FRAME REINFORCEMENT INNER - RH	TATA spare parts
219331707151	FRAME REINFORCEMENT INNER - LH	TATA spare parts
219331707152	FRAME REINFORCEMENT INNER - LH	TATA spare parts
219340100101	ASSY TYRE 12R20 - 18PR RIB	TATA spare parts
219340100102	WHEEL RIM 8.5X20	TATA spare parts
219340107702	FLAP 12.00-20	TATA spare parts
219340109902	TUBE 12.00-20	TATA spare parts
219340200101	ASSY TYRE 12R20 - 18PR LUG	TATA spare parts
219340206302	TYRE 12.00-20	TATA spare parts
219346607201	OIL PLUG	TATA spare parts
219349008202	BRKT SIL MTG RR	TATA spare parts
219349100104	ASSY SILENCER	TATA spare parts
219349100105	ASSY FIRST EXHAUST PIPE	TATA spare parts
219349100106	ASSY SECOND PIPE EXH	TATA spare parts
219349200101	ASSY BRKT SIL MTG FRT	TATA spare parts
219349206903	EXHAUST PIPE	TATA spare parts
219349207106	BRKT(EXHAUST PIPE MTG)	TATA spare parts
219349207107	BRKT(EXHAUST PIPE MTG)	TATA spare parts
219349207108	BRKT(EXHASUT PIPE MTG)	TATA spare parts
219349207109	BRKT(EXHAUST PIPE MTG)	TATA spare parts
219349208206	CLAMP	TATA spare parts
219349208208	CLAMP	TATA spare parts
219349208211	BRACKET(EXHAUST PIPE MTG)	TATA spare parts
219350400001	RADIATOR PROTECTOR	TATA spare parts
219354100101	BRKT ASM-BATTERY	TATA spare parts
219354108216	BRACKET(HOURMETER MTG)	TATA spare parts
219354200102	ASSY TELEMATICS CONTROL UNIT GSM	TATA spare parts
219354200103	ASSY GPS ANTENNA	TATA spare parts
219354200105	DATA INTERFACE UNIT	TATA spare parts
219354200107	FM RADIO SPEAKER	TATA spare parts
219354200108	MICROPHONE	TATA spare parts
219354200109	ASSY WIRING HARNESS	TATA spare parts
219354200110	TELEMATICS CONTROL UNIT- CDMA	TATA spare parts
219354400102	ASSY. LAMP GAURD	TATA spare parts
219354440103	ASSY HEAD LAMP (24V)	TATA spare parts
219354600101	W/H PIGTAIL HOURMETER	TATA spare parts
219370000101	LOAD BODY ASSY	TATA spare parts
219370000102	ASSY LOAD BODY 16 CU M ROCK SCOPE TYPE	TATA spare parts
219370000113	ASSY SCOOP TYPE LOAD BODY-15CUM-RAEX 400	TATA spare parts
219372500101	ASSY CRANK WINDOW LIFTER	TATA spare parts
219381100104	KIT ASSY RVM COMPLETE	TATA spare parts
219381900101	ASSY ARRESTER RAIN FLAP	TATA spare parts
219381906301	FRONT RAIN FLAP	TATA spare parts
219398410101	BED A	TATA spare parts

219416100101	CONTAINER(ECU-697TCIC BSIII)	TATA spare parts
219416100102	CONTAINER(ECU)	TATA spare parts
219416100104	CONTAINER SK1616 BSIII	TATA spare parts
219424200101	ASSY.BRACKET (ENG.MTG.REAR BOTTOM)	TATA spare parts
219424200102	ASSY.BKT.RH.(ENG.MTG.REAR)	TATA spare parts
219424200103	ASSY.BKT.LH.(ENG.MTG.REAR	TATA spare parts
219424200107	ASSY SUPPORT LH (ENGINE MTG REAR)	TATA spare parts
219424200108	ASSY SUPPORT RH (ENGINE MTG REAR)	TATA spare parts
219424200109	ASSY BRACKET LH (ENGINE MTG REAR)	TATA spare parts
219424200110	ASSY BRACKET RH (ENGINE MTG REAR)	TATA spare parts
219424200111	ASSY.COMPONENT SET ENG.MTG.REAR	TATA spare parts
219429100104	ASSY CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
219429100108	ASSY PEDAL LEVER CLUTCH	TATA spare parts
219429107103	STOPPER	TATA spare parts
219429200101	ASSY PEDAL LEVER BRAKE COMPLETE	TATA spare parts
219429300103	ASSY TUBE 6X2180 LG.	TATA spare parts
219430100102	ASSY BRACKET (ACCL STOPPER)	TATA spare parts
219430100106	ASSY STOPPER	TATA spare parts
219431000101	ASSY.FRAME COMPLETE.	TATA spare parts
219431000102	ASSY FRAME COMPLETE	TATA spare parts
219431000103	ASSY.FRAME COMPLETE.SE 1615 697 BS-3	TATA spare parts
219431000107	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
219431000108	ASSY FRAME COMPLETE	TATA spare parts
219431000109	FRAME ASSY WITH FITMENT	TATA spare parts
219431000112	ASSY FRAME COMPLETE (960 ROH)	TATA spare parts
219431000113	RETRO KIT FOR TWIN PROP SHAFT	TATA spare parts
219431000114	ASSY FRAME COMPLETE	TATA spare parts
219431000115	FRAME ASSY WITH FITMENT	TATA spare parts
219431200102	ASSY SPRING CROSS MEMBER W/SUPPORT	TATA spare parts
219431200105	ASSY SUPPORT RH ENG CROSSMEMB FRONT	TATA spare parts
219431200106	ASSY SUPPORT LH ENG CROSSMEMB FRONT	TATA spare parts
219431200111	ASSY SUPPORT RH (ENGINE C/M FRONT)	TATA spare parts
219431200112	ASSY SUPPOERT LH (ENGINE C/M FRONT)	TATA spare parts
219431200113	ASSY.ENGINE CROSS MEMBER FRONT	TATA spare parts
219431200114	ASSY SUPPORT (ENGINE C/M REAR)	TATA spare parts
219431200115	ASSY.ENGINE CROSS MEMBER REAR	TATA spare parts
219431200116	ASSY CROSS MEMBER (CENTRE BEARING MTG)	TATA spare parts
21943120011661	ASSY CROSS MEMBER_UNAPINTED	TATA spare parts
219431200119	ASSY SIDE SUPPORT	TATA spare parts
219431207111	REINFORCEMENT R.H (BOTTOM)	TATA spare parts
219431207112	REINFORCEMENT L.H (BOTTOM)	TATA spare parts
219431700101	ASSY.NOISE SHIELD RADIATOR BOTTOM.	TATA spare parts
219431700102	ASSY.NOISE SHIELD ENGINE BOTTOM FRONT.	TATA spare parts
219431700103	ASSY NOISE SHIELD ENGINE REAR BOTTOM	TATA spare parts
219431700104	ASSY.NOISE SHIELD GEAR BOX FRONT	TATA spare parts
219431700106	ASSY.BKT-RH ENGINE NOISE SHIELD.	TATA spare parts
219431700107	ASSY.BKT-LH ENGINE NOISE SHIELD	TATA spare parts

219431700108	ASSY.BKT.RH (G.B NOISE SHIELD MTG.)	TATA spare parts
219431700109	ASSY.BKT-LH (G/BOX NOISE SHIELD MTG.)	TATA spare parts
219431700111	ASSY BRACKET WITH SPACER	TATA spare parts
219431700116	ASSY RADIATOR GUARD	TATA spare parts
219431700117	ASSY BRACKET LH (RADIATOR GUARD)	TATA spare parts
219431700118	ASSY BRACKET RH (RADIATOR GUARD)	TATA spare parts
219431708218	GUSSET (5 TH CROSS MEMBER)	TATA spare parts
219431708220	SPACER PLATE (5TH CROSS MEMBER)	TATA spare parts
219433000101	SK 1613 ASSY.FA .COMP.W/BRAKES(SPIG)	TATA spare parts
219433000102	ASSY.FA COMP.W/BRKS.(SPIGOTTE)RAF7_180MM	TATA spare parts
219441100101	CROSS ASSY.	TATA spare parts
219441100101DF	UJ CROSS 42 X 120-LPK1615	TATA spare parts
219441100105	ASSY GUARD (PROP SHAFT)	TATA spare parts
219441100106	LONG FORK SUB ASSY.¿ REAR	TATA spare parts
219441100109	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
219441100110	COUPLING FLANGE ASSY	TATA spare parts
219441100112	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
219441100115	SLIP YOKE ASSEMBLY	TATA spare parts
219441100118	CROSS ASSY	TATA spare parts
219441100119	CENTER BEARING ASSY	TATA spare parts
219441100120	COUPLING FLANGE ASSY	TATA spare parts
219441100121	S/FORK TUBE & FEP ASSY	TATA spare parts
219441105101	FLANGE YOKE	TATA spare parts
219441105102	SHORT FORK	TATA spare parts
219441105104	COUPLING FLANGE	TATA spare parts
219441105108	LONG FORK	TATA spare parts
219441105109	FULL RND FLANGE YOKE	TATA spare parts
219441105110	COMPANION FLANGE	TATA spare parts
219441105112	FLANGE YOKE	TATA spare parts
219441106501	NUT	TATA spare parts
219441106502	HEX NUT	TATA spare parts
219441110101	ASSY.PROP.SHAFT WITH C.B	TATA spare parts
219441110102	ASSY.PROP SHAFT FRONT W C.B 1616SE	TATA spare parts
219441110117	ASSY. PROP. SHAFT FRONT BS3/4	TATA spare parts
219441120101	ASSY.PROP.SHAFT REAR	TATA spare parts
219441120103	ASSY PROPELLER SHAFT COMPLETE REAR	TATA spare parts
219441120104	ASSY.PROP SHAFT REAR 1616SE42 BS3	TATA spare parts
219441120109	ASSY PROPELLER SHAFT REAR	TATA spare parts
219441120110	LONG FORK SUB ASSY	TATA spare parts
219441120111	S/FORK TUBE & REAR HOUSING¿ASSY	TATA spare parts
219441300101	ASSY CENTRE BEARING	TATA spare parts
219441300102	CENTER BEARING	TATA spare parts
219441300103	ASSY SUPPORT (CENTRE BRG.CROSS MEMBER)	TATA spare parts
219441303301	CENTRE BEARING BRACKET	TATA spare parts
219441303302	SPACER PLATE	TATA spare parts
219441303303	CENTRE BEARING BRACKET	TATA spare parts
219442300101	ASSY. BRACKET AIR TANK MTG. REAR	TATA spare parts

219442300102	ASSY. BRACKET RH(AIR TANK MTG. FRONT)	TATA spare parts
219442300103	ASSY. BRACKET LH(AIR TANK MTG. FRONT)	TATA spare parts
219443200104	ASSY. AIR TANK MTG BKT-RH	TATA spare parts
219443200105	ASSY. AIR TANK MTG BKT-LH	TATA spare parts
219443200106	ASSY.AIR TANK COMPLT.WITH VOSS CONNECTN	TATA spare parts
219443200107	ASSY.AIR TANK COMPLT.WITH VOSS CONNECTN	TATA spare parts
219443700103	ASSY.BRACKET.	TATA spare parts
219443900132	ASSY.TUBE W/CRIMPED R/HOSE.	TATA spare parts
219443900153	ASSY.NYLON PIPE SET SK1615/36	TATA spare parts
219443900160	ASSY.NYLON PIPE SET COMPLETE.	TATA spare parts
219443900167	ASSY.NYLON PIPE SET COMPT.W/PLASTIC VOSS	TATA spare parts
219443900169	ASSY.COMP.PIPE SECOND	TATA spare parts
219443900170	ASSY.COMP.PIPE THIRD	TATA spare parts
219443900171	ASSY.COMP.PIPE SECOND	TATA spare parts
219443900172	ASSY.COMP.PIPE THIRD.	TATA spare parts
219443900174	ASSY.COMP.PIPE 2ND.	TATA spare parts
219443900175	ASSY.COMP.PIPE 3RD	TATA spare parts
219443900176	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
219443900178	3/8INC HOSE ASSY.W/ O RING NIPPLE.	TATA spare parts
219443900180	ASSY.COMP.PIPE INLET	TATA spare parts
219443910101	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
219443910103	ASSY.COMPRESSOR PIPE 2ND	TATA spare parts
219443910104	ASSY.COMPRESSOR PIPE 3RD	TATA spare parts
219446600101	ASSY.BRACKET.(FOR P/STG.TANK )	TATA spare parts
219446604301	CIRCLIP	TATA spare parts
219447150107	ASSY. RETRO KIT FOR ELECTRICAL FEED PUMP	TATA spare parts
219447600108	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
219447600109	ASSY RUBBER HOSE	TATA spare parts
219447600110	ASSY.TUBE WITH CRIMPED R/HOSE	TATA spare parts
219447600111	ASSY.TUBE WITH CRIMPED R/HOSE.(OVERFLOW	TATA spare parts
219447600112	ASSY.TUBE WITH CRIMPED R/HOSE.(SUCTION P	TATA spare parts
219447600113	ASSY.TYBE WITH CRIMPED R/HOSE.(BABY FILT	TATA spare parts
219447600114	ASSY.TUBE WITH CRIMPED R/HOSE.	TATA spare parts
219447600115	ASSY.TUBE WITH CRIMPED R/HOSE	TATA spare parts
219447600116	ASSY FUEL PIPE	TATA spare parts
219447600121	ASSY.NYLON PIPE W/CRIMPED RUBBER HOSE	TATA spare parts
219447608205	BRACKET(FUEL FEED PUMP MTG.)	TATA spare parts
219449100102	ASSY SILENCER NT6 WITH TAIL PIPE	TATA spare parts
219449100103	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
219449200101	ASSY FIRST EXHAUST PIPE	TATA spare parts
219449200102	ASSY SECOND EXHAUST PIPE	TATA spare parts
219449200103	ASSY THIRD EXHAUST PIPE	TATA spare parts
219449200106	ASSY EXHAUST PIPE REAR	TATA spare parts
219449200107	EXHAUST HEAT SHIELD	TATA spare parts
219449200111	ASSY.SECOND PIPE	TATA spare parts
219449200112	ASSY.THIRD PIPE	TATA spare parts
219449200113	ASSY. BRACKET(SILENCER MTG.)	TATA spare parts

219449200116	ASSY.THIRD PIPE EXHAUST	TATA spare parts
219449200117	ASSY. SECOND PIPE EXHAUST	TATA spare parts
219449200122	ASSY.BRACKET	TATA spare parts
219449200123	ASSY FIRST EXHAUST PIPE	TATA spare parts
219449200124	ASSY. SECOND PIPE (EXHAUST)	TATA spare parts
219449200125	ASSY. BRACKET (EXH MTG)	TATA spare parts
219449200126	ASSY FIRST EXHAUST PIPE	TATA spare parts
219449200127	ASSY. THIRD PIPE EXHAUST	TATA spare parts
219449200129	ASSY. INTERMEDIATE PIPE (EXHAUST)	TATA spare parts
219449203301	BRACKET (3RD PIPE)	TATA spare parts
219449203302	BRACKET	TATA spare parts
219449203310	BRACKET	TATA spare parts
219449203314	BRACKET	TATA spare parts
219449203319	BRACKET EXHAUST MTG.	TATA spare parts
219449203320	BRACKET	TATA spare parts
219449203322	L-BRACKET	TATA spare parts
219449203323	L-BRACKET	TATA spare parts
219449203324	BRACKET	TATA spare parts
219449203325	L-BRACKET (EXHAUST MTG.)	TATA spare parts
219449208206	BRACKET	TATA spare parts
219449208208	Z-BRACKET	TATA spare parts
219449208209	BEACKET (EXHAUST MTG)	TATA spare parts
219454106301	BATTERY TRAY PLASTIC(D H-12MM)-BSIII	TATA spare parts
219454106302	BATTERY TRAY PLASTIC(D H-80MM)SFC-BSIII	TATA spare parts
219454108201	BATTERY CLAMP -485 (CENTER TO CENTRE)MM	TATA spare parts
219454209901	INSTRUMENT CLUSTER-(0.88)	TATA spare parts
219454209902	INSTRUMENT CLUSTER-(0.88)	TATA spare parts
219454209920	INSTRUMENT CLUSTER-(0.88)ESPDO	TATA spare parts
219454209926	INST. CLSTR-(0.88)ESPDO	TATA spare parts
219454209940	INSTRUMENT CLUSTER (1:1.04) E-SPEEDO SK	TATA spare parts
219454209941	INSTRUMENT CLUSTER (1:0.88) E-SPEEDO	TATA spare parts
219454209942	INSTRUMENT CLUSTER (1:1.04) E-SPEEDO SK-	TATA spare parts
219454209943	INSTRUMENT CLUSTER (1:0.88) E-SPEEDO	TATA spare parts
219454209944	RPM METER ASSEMBLY 24V (438 HZ)	TATA spare parts
219454209945	RPM METER ASSEMBLY 24V (438 HZ)WITH DIGI	TATA spare parts
219454209946	RPM METER ASSEMBLY 24V (420 HZ)WITH DIGI	TATA spare parts
219454209948	RPM METER ASSEMBLY 24V (438 HZ) WITH DIG	TATA spare parts
219454209949	ELEC.INST CLUSTER 24V 41/6 8320 PULSES/K	TATA spare parts
219454209951	ELEC.INST CLUSTER 24V 41/7 7040 PULSES/K	TATA spare parts
219454209953	INSTRUMENT CLUSTER (1:0.88) E-SPEEDO	TATA spare parts
219454209954	INSTRUMENT CLUSTER (1:0.88) E-SPEEDO	TATA spare parts
219454209955	INSTRUMENT CLUSTER (1:0.88) E-SPEEDO SK	TATA spare parts
219454209956	INSTRUMENT CLUSTER (1:1.04) E-SPEEDO SK	TATA spare parts
219454209962	INSTRUMENT CLUSTER ASSY	TATA spare parts
219454620103	W/H MAIN SK1615 BS-III	TATA spare parts
219454620105	W/H ENGINE	TATA spare parts
219454620106	W/H TAIL SE-1615/42 BS-III	TATA spare parts

219454620107	W/H TAIL	TATA spare parts
219454620116	W/H MAIN SK 1616 697 BS-III 12V	TATA spare parts
219454620120	WIRING HARNESS MAIN	TATA spare parts
219454660103	W/H TAIL SK-1615/36 BS-III	TATA spare parts
219454660105	W/H TAIL SE-1615/42 BS-III	TATA spare parts
219454660106	W/H ENGINE SE/SK1615 BS-III	TATA spare parts
219454660109	W/H MAIN SE1615 BS-III-I/C	TATA spare parts
219454660110	W/H MAIN SK1615 BS-III-I/C	TATA spare parts
219454660121	W/H MAIN SK1615 BS-III-I/C	TATA spare parts
219454660123	W/H ENGINE SE/SK1615BSIII	TATA spare parts
219454660124	W/H TAIL SE-1615/42 BS-III	TATA spare parts
219454660125	W/H TAIL SK1615/36	TATA spare parts
219454660126	W/H TAIL SK1615/32	TATA spare parts
219454660130	W/H TAIL SK1615/42 BSIII	TATA spare parts
219454660133	WIRING HARNESS PIGTAIL FOR EXHAUST BRAKE	TATA spare parts
219454660134	W/H MAIN SK 1616 697 BS-III 12V	TATA spare parts
219454660138	W/H MAIN SE/SK-1613 697 BS-III	TATA spare parts
219454660139	W/H MAIN SE/SK 1613 697 BS-II	TATA spare parts
219454660140	WIRING HARNESS SENSOR SK-1613 697 BS-IV	TATA spare parts
219454660141	WIRING HARNESS ENGINE SK-1613 697 BS-IV	TATA spare parts
219454660145	WH MAIN SK1616 ERGO WILLIUM CONTROL	TATA spare parts
219454660150	W/H MAIN SE-1613 697 BS-III	TATA spare parts
219454660151	W/H TAIL SK-1613 697 BS-IV	TATA spare parts
219454821615	W/H MAIN SK 1616 697 BS-III 12V	TATA spare parts
219470110105	KIT PT.NO.OF ASSY.SUPD COMPLETE	TATA spare parts
219482409901	WINDSHIELD WASHER UNIT	TATA spare parts
219509130103	ASSY BKT - AIR FILTER MTG	TATA spare parts
219509130104	ASSY AIR FILTER (SE/SK 1615 TCIC BS-III)	TATA spare parts
219509130105	ASSY AIR INTAKE PIPE (FLT TO R/HOSE) 127	TATA spare parts
219509130106	ASSY SUPPORT BRACKET ( ON CLUTCH HSG)	TATA spare parts
219509130107	COATED CLAMP (DIA 127 )	TATA spare parts
219509130108	ASSY PROTECTIVE COVER	TATA spare parts
219509130113	SET ASSY SNORKEL PREFILTER & HOSES	TATA spare parts
219509130114	ASSY AIR FILTER	TATA spare parts
219509130119	ASSY BRACKET (AL-PIPE)	TATA spare parts
219509130121	ASSY PROTECTIVE COVER	TATA spare parts
219509130138	ASSY AIR INTAKE PIPE (A/F TO T/C)	TATA spare parts
219509133308	BRACKET (HFM SENSOR MTG.)	TATA spare parts
219509133801	EXTENSION PIPE	TATA spare parts
219509133803	EXTENSION PIPE (AL-102 DIA )	TATA spare parts
219509133804	AL PIPE(SNORKEL TO A/F)	TATA spare parts
219509135802	RUBBER HOSE (REDUCER)	TATA spare parts
219509135804	HOSE	TATA spare parts
219509135805	RUBBER HOSE (REDUCER)	TATA spare parts
219509135806	HOSE FLEXIBLE-OFFER DRG	TATA spare parts
219509136302	DUCT AIR INTAKE INLET	TATA spare parts
219514603801	PIPE (IC TO AIR INTAKE)	TATA spare parts

219514603803	REDUCER PIPE (TC TO IC)	TATA spare parts
219514603804	PIPE (IC TO AIR INTAKE)	TATA spare parts
219514603806	REDUCER PIPE (TC TO IC)	TATA spare parts
219514606905	PIPE (IC TO TC)	TATA spare parts
219514606906	PIPE (IC TO ENGINE)	TATA spare parts
219514609901	INTERCOOLER	TATA spare parts
219514609902	INTERCOOLER	TATA spare parts
219514609903	INTERCOOLER	TATA spare parts
219514609904	INTERCOOLER	TATA spare parts
219514609907	INTERCOOLER	TATA spare parts
219514609908	INTERCOOLER	TATA spare parts
219546608301	SHIM	TATA spare parts
219550000103	ASSY BRACKET -RAD MTG BOTTOM(ON C.M.)	TATA spare parts
219550003301	BRACKET -SIDE RADIATOR MTG	TATA spare parts
219550008201	BRACKET-RAD BOTTOM MTG(ON RADIATOR )	TATA spare parts
219550100103	ASSY RADIATOR & INTERCOOLER	TATA spare parts
219550100104	ASSY RADIATOR	TATA spare parts
219550100109	ASSY.RAD.FRAME WITH TIE MEMBER	TATA spare parts
219550100120	ASSY RADIATOR COMPLETE	TATA spare parts
219550100124	SET-ENGINE COOLING SYSTEM	TATA spare parts
219550100125	ASSY BRACKET	TATA spare parts
219550100127	ASSY RADIATOR WITH FRAME	TATA spare parts
219550100128	ASSY RADIATOR WITH IC	TATA spare parts
219550100129	KIT ENGINE COOLING SYSTEM	TATA spare parts
219550100130	KIT ENGINE COOLING SYSTEM	TATA spare parts
219550100132	ASSY RADIATOR	TATA spare parts
219550100133	ASSY RADIATOR FRAME	TATA spare parts
219550100134	ASSY RADIATOR	TATA spare parts
219550100136	KIT ENGINE COOLING SYSTEM	TATA spare parts
219550100137	ASSY RADIATOR	TATA spare parts
219550100139	KIT ENGINE COOLING SYSTEM	TATA spare parts
219550100152	KIT ENGINE COOLING SYSTEM	TATA spare parts
219550100153	KIT ENGINE COOLING SYSTEM	TATA spare parts
219550100154	KIT ENGINE COOLING SYSTEM	TATA spare parts
219550100155	KIT ENGINE COOLING SYSTEM	TATA spare parts
219550100157	ASSY RADIATOR	TATA spare parts
219550100158	ASSY RADIATOR FRAME	TATA spare parts
219550100160	RADIATOR ASSY	TATA spare parts
219550103303	SUPPORT BRACKET	TATA spare parts
219550105801	HOSE (TO RAD INLET)SK1615/36CMVR BSIII	TATA spare parts
219550105802	HOSE (RAD TO ENGINE)	TATA spare parts
219550105803	REDUCER ELBOW SK1615/36CMVR BSIII	TATA spare parts
219550105804	HOSE (RADIATOR TO ENGINE)	TATA spare parts
219550105807	HOSE ( RAD TO WP)	TATA spare parts
219550105808	HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
219550105809	RUBBER HOSE (RAD TO ENGINE)	TATA spare parts
219550105811	RUBBER HOSE-RAD TO ENGINE	TATA spare parts

219550106901	WATER FILL PIPE	TATA spare parts
219550106902	WATER FILL PIPE	TATA spare parts
219550506301	FAN SHROUD	TATA spare parts
219550506302	FAN SHROUD	TATA spare parts
219550506303	FAN SHROUD	TATA spare parts
219615400101	ALTERNATOR 24V 80A LIN BS6-PH2	TATA spare parts
219615400103	ALTERNATOR BS6-PH2	TATA spare parts
219616100101	CONTAINER (ECU 497TC BS-III) 41/7 RA	TATA spare parts
219624203701	BRACKET ENGINE MTG BOTTOM REAR-LH&BS6	TATA spare parts
219624203702	BRACKET ENGINE MTG BOTTOM REAR-RH&BS6	TATA spare parts
219626800111	TURNING TUBE ASSYBS6	TATA spare parts
219626800114	GEAR SHIFT LEVER ASSY WITH SHIFT YOKE&BS	TATA spare parts
219626800116	TURNING TUBE ASSY BS6-PH2	TATA spare parts
219626810102	SUPPORT TUBE ASSY BS6	TATA spare parts
219626813701	BRACKET BS6	TATA spare parts
219629100101	ASSY.BRACKET(CLUTCH BOSSTER MTG.)	TATA spare parts
219629100102	ASSY. CLUTCH BOOSTER BS1/2/3/4	TATA spare parts
219629100102AE	ASSY CLUTCH BOOSTER -1415	TATA spare parts
219629300102	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
219629300103	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
219629303301	BRACKET CLUTCH PIPE MTG BS6	TATA spare parts
219630100102	BRACKET ASSY ACCELERATOR MTG BS6	TATA spare parts
219630100103	ACCELERATOR PEDAL ASSY BS6	TATA spare parts
219630100104	ACCELERATOR PEDAL ASSY	TATA spare parts
219630100108	BRACKET ASSY ACCELERATOR MTG BS6-PH2	TATA spare parts
219631000107	FRAME ASSY WITH FITMENT BS6	TATA spare parts
219631000109	FRAME ASSY WITH FITMENT BS6	TATA spare parts
219631000122	FRAME ASSY WITH FITMENT BS6	TATA spare parts
219631000126	FRAME ASSY WITH FITMENT BS6	TATA spare parts
219631200103	ASSY.THIRD CROSS MEMBER	TATA spare parts
219631200120	CROSS MEMBER ASSY ENGINE MTG FRONT BS6	TATA spare parts
219631200121	GUSSET ASSY RH BS6	TATA spare parts
219631200122	GUSSET ASSY LH BS6	TATA spare parts
219631200124	GUSSET ASSY RH BS6	TATA spare parts
219631200125	GUSSET ASSY LH BS6	TATA spare parts
219631200129	CROSS MEMBER ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
219631200130	CROSS MEMBER ASSY CTR BRG MTG BS6-PH2	TATA spare parts
219631203701	BRACKET ENGINE CROSS MEMBER MTG BS6-PH2	TATA spare parts
219631207123	CROSS MEMBER ENGINE MTG FRONT BS6-PH2	TATA spare parts
219631207128	CROSS MEMBER BUMPER BS6	TATA spare parts
219631207131	CROSS MEMBER BS6-PH2	TATA spare parts
219631207133	LFLASEPLATE LH BS6-PH2	TATA spare parts
219631307118	SPACER PLATE BS6-PH2	TATA spare parts
219631308205	REINFORCEMENT RH BS6-PH2	TATA spare parts
219631308206	REINFORCEMENT LH BS6-PH2	TATA spare parts
219632400102	AIR TANK ASSY WITH BRACKET	TATA spare parts
219632404201	U-BOLT REAR	TATA spare parts



219632404801	DOWEL	TATA spare parts
219632950101	NYLON PIPE BUNCH ASSY	TATA spare parts
219633000101	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
219641110101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
219641110102	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
219641110103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
219641110104	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
219641110105	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
219641110106	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
219641110107	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
219641110108	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
219641110109	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
219641110110	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
219641110111	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
219641110115	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
219641110116	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
219641110117	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
219641110118	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
219641110120	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
219641110133	PROPELLER SHAFT ASSY BS6	TATA spare parts
219641110150	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
219641110151	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
219641110154	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
219641110156	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
219641110163	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
219641110168	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
219641120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
219641120104	SHORT FORK TUBE - REAR HOUSING ASSY BS6	TATA spare parts
219641120110	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
219641120112	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
219641120132	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
219641120134	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
219641120143	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
219641120145	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
219641300101	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
219641300102	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
219641300103	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
219641300104	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
219641300112	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
219641300113	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
219641307101	BRACKET CENTER BRG MTG BS6	TATA spare parts
219641307102	BRACKET CENTER BRG MTG BS6	TATA spare parts
219641307103	BRACKET CENTER BRG MTG BS6	TATA spare parts
219641307104	BRACKET CENTER BRG MTG BS6	TATA spare parts
219641307106	BRACKET CENTER BRG MTG BS6	TATA spare parts
219641307107	BRACKET CENTER BRG MTG BS6	TATA spare parts
219641307110	BRACKET-CENTER BRG MTG BS6	TATA spare parts

219643700116	BRACKET ASSY MODULATOR VALVE MTG BS6	TATA spare parts
219643703303	BRACKET BS6-PH2	TATA spare parts
219643703305	BRACKET BS6-PH2	TATA spare parts
219643703306	BRACKET BS6-PH2	TATA spare parts
219643703307	BRACKET BS6-PH2	TATA spare parts
219643703318	BRACKET BS6-PH2	TATA spare parts
219643900118	PIPE ASSY BS6	TATA spare parts
219643900122	PIPE ASSY TEE TO DOOR ACTUATOR BS6	TATA spare parts
219643900124	PIPE ASSY BS6	TATA spare parts
219643900133	PIPE ASSY BS6	TATA spare parts
219643900138	PIPE ASSY BS6	TATA spare parts
219643900140	PIPE ASSY BS6	TATA spare parts
219643900142	PIPE ASSY BS6	TATA spare parts
219643900147	NYLON PIPE BUNCH ASSY CABIN BS6-PH2	TATA spare parts
219643900170	METAL PIPE ASSY BS6	TATA spare parts
219643900171	METAL PIPE ASSY BS6	TATA spare parts
219643900172	METAL PIPE ASSY BS6	TATA spare parts
219643900173	METAL PIPE ASSY BS6	TATA spare parts
219643900177	PIPE ASSY BS6-PH2	TATA spare parts
219643900180	PIPE ASSY	TATA spare parts
219643900206	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
219643900238	PIPE ASSY BS6-PH2	TATA spare parts
219643900244	METAL PIPE ASSY BS6-PH2	TATA spare parts
219643900251	PIPE ASSY BS6-PH2	TATA spare parts
219643900252	NYLON PIPE BUNCH ASSY CABIN BS6-PH2	TATA spare parts
219643900254	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
219643903301	BRACKET BS6-PH2	TATA spare parts
219643910103	METAL PIPE ASSY 2ND METAL PIPE (18 OD) B	TATA spare parts
219643910104	METAL PIPE ASSY 3RD METAL PIPE (18 OD) B	TATA spare parts
219643910105	METAL PIPE ASSY BS6	TATA spare parts
219643910126	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
219643910189	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
219643910197	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
219643910199	PIPE ASSY BS6-PH2	TATA spare parts
219646106301	RUBBER BELLOW	TATA spare parts
219646608401	PROTECTIVE SLEEVE	TATA spare parts
219646703302	BRACKET PIPE CLAMP BS6-PH2	TATA spare parts
219646703303	LFLASEBRACKET BS6-PH2	TATA spare parts
219646800101	PRESSURE LINE ASSY BS6	TATA spare parts
219646800102	SUCTION LINE ASSY BS6	TATA spare parts
219646800103	SUCTION LINE ASSY BS6	TATA spare parts
219646800104	RETURN LINE ASSY BS6	TATA spare parts
219646800105	PRESSURE LINE ASSY BS6	TATA spare parts
219646800106	RETURN LINE ASSY BS6	TATA spare parts
219646800107	PRESSURE LINE ASSY BS6	TATA spare parts
219646800108	RETURN LINE ASSY BS6	TATA spare parts
219646800129	RETURN LINE ASSY BS6-PH2	TATA spare parts

219646800132	RETURN LINE ASSY BS6-PH2	TATA spare parts
219646800133	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
219646800134	SUCTION LINE ASSY BS6-PH2	TATA spare parts
219646800135	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
219646800136	SUCTION LINE ASSY BS6-PH2	TATA spare parts
219646800137	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
219646800138	RETURN LINE ASSY BS6-PH2	TATA spare parts
219646800145	RETURN LINE ASSY BS6-PH2	TATA spare parts
219646800146	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
219646800148	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
219646800149	RETURN LINE ASSY BS6-PH2	TATA spare parts
219647600110	FUEL PIPE ASSY BS6	TATA spare parts
219647600111	SUCTION PIPE ASSY FILTER TO FEED PUMP BS	TATA spare parts
219647600112	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
219647600113	FUEL PIPE ASSY BS6	TATA spare parts
219647600115	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
219647600116	FUEL PIPE ASSY BS6	TATA spare parts
219647600117	FUEL PIPE ASSY BS6	TATA spare parts
219647600118	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
219647600120	FUEL RETURN PIPE ASSY BS6	TATA spare parts
219647600121	FUEL PIPE ASSY TANK TO FILTER BS6	TATA spare parts
219647600123	FUEL PIPE ASSY BS6	TATA spare parts
219647600124	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
219647600125	FUEL RETURN PIPE ASSY BS6	TATA spare parts
219647600127	FUEL PIPE ASSY BS6	TATA spare parts
219647600129	FUEL PIPE ASSY BS6	TATA spare parts
219647600130	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
219647600132	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
219647600135	FUEL PIPE ASSY TANK TO FILTER BS6	TATA spare parts
219647600136	FUEL RETURN PIPE ASSY ENGINE TO T-CONN B	TATA spare parts
219647600151	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
219647600170	FUEL PIPE ASSY BS6-PH2	TATA spare parts
219647600171	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
219647600172	FUEL PIPE ASSY BS6-PH2	TATA spare parts
219647600173	FL RTN PIPE ASSY ENG TO FUEL TANK BS6-PH	TATA spare parts
219647600174	FUEL PIPE ASSY TANK TO FILTER BS6-PH2	TATA spare parts
219647600175	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
219647600176	FUEL PIPE ASSY BS6-PH2	TATA spare parts
219647600177	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
219647600198	FUEL PIPE ASSY BS6-PH2	TATA spare parts
219647600199	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
219647610101	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
219647610102	FUEL PIPE ASSY BS6-PH2	TATA spare parts
219647700101	BRACKET ASSY FILTER MTG BS6	TATA spare parts
219647700102	BRACKET ASSY W/SEP MTG BS6-PH2	TATA spare parts
219649100102	PIPE ASSY BS6	TATA spare parts
219649100103	PIPE ASSY BS6	TATA spare parts

219649106801	CONNECTOR BS6	TATA spare parts
219649106805	CONNECTOR BS6	TATA spare parts
219649107501	RUBBER BUFFER BS6	TATA spare parts
219649108401	TUBE BS6	TATA spare parts
219649200101	EXHAUST PIPE ASSY INTERMEDIATE BS6	TATA spare parts
219649200102	EXHAUST PIPE ASSY WITH BELLOW BS6	TATA spare parts
219649200109	BRACKET ASSY EGP MTG BS6	TATA spare parts
219649200111	BRACKET ASSY BS6	TATA spare parts
219649200112	TAIL PIPE ASSY BS6	TATA spare parts
219649200114	CLAMP ASSY EGP MTG BS6	TATA spare parts
219649200115	BRACKET ASSY EGP MTG BS6	TATA spare parts
219649200116	TAIL PIPE ASSY BS6	TATA spare parts
219649200118	TAIL PIPE ASSY BS6	TATA spare parts
219649200119	EXHAUST PIPE ASSY WITH BELLOW BS6	TATA spare parts
219649200120	EXHAUST PIPE ASSY BS6	TATA spare parts
219649200121	BRACKET ASSY EGP MTG BS6	TATA spare parts
219649200125	PIPE ASSY BS6	TATA spare parts
219649200126	PIPE ASSY BS6	TATA spare parts
219649200127	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
219649200128	EXHAUST PIPE ASSY WITH BELLOW BS6	TATA spare parts
219649200129	EXHAUST PIPE ASSY BS6	TATA spare parts
219649200130	PIPE ASSY BS6	TATA spare parts
219649200131	PIPE ASSY BS6	TATA spare parts
219649200133	BRACKET ASSY EGP MTG BS6	TATA spare parts
219649200135	BRACKET ASSY TAIL PIPE MTG BS6	TATA spare parts
219649200136	UREA PIPE ASSY BS6	TATA spare parts
219649200137	UREA PIPE ASSY BS6	TATA spare parts
219649200138	PIPE ASSY UREA RETURN BS6	TATA spare parts
219649200139	UREA PIPE ASSY BS6	TATA spare parts
219649200140	UREA PIPE ASSY BS6	TATA spare parts
219649200141	BRACKET ASSY EGP MTG BS6	TATA spare parts
219649200143	UREA PIPE ASSY BS6	TATA spare parts
219649200145	TAIL PIPE ASSY BS6	TATA spare parts
219649200146	EXHAUST PIPE ASSY WITH BELLOW BS6-PH2	TATA spare parts
219649200147	EXHAUST PIPE ASSY WITH BELLOW BS6-PH2	TATA spare parts
219649200148	EXHAUST PIPE ASSY WITH BELLOW BS6-PH2	TATA spare parts
219649200149	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
219649200157	EXHAUST PIPE ASSY BS6-PH2	TATA spare parts
219649200158	EXHAUST PIPE ASSY BS6-PH2	TATA spare parts
219649200159	EXHAUST PIPE ASSY BS6-PH2	TATA spare parts
219649200161	BRACKET ASSY UREA TANK MTG BS6	TATA spare parts
219649200164	BRACKET ASSY BS6-PH2	TATA spare parts
219649200165	TAIL PIPE ASSY BS6-PH2	TATA spare parts
219649200166	TAIL PIPE ASSY BS6-PH2	TATA spare parts
219649200168	TAIL PIPE ASSY BS6-PH2	TATA spare parts
219649200169	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
219649200175	PIPE ASSY UREA RETURN BS6-PH2	TATA spare parts

219649203303	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
219649203304	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
219649203305	BRACKET BS6	TATA spare parts
219649203306	BRACKET BS6	TATA spare parts
219649203307	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
219649203309	BRACKET BS6	TATA spare parts
219649203311	BRACKET SUPPORT BS6	TATA spare parts
219649203313	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
219649203314	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
219649203315	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
219649203318	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
219649203319	BRACKET BS6-PH2	TATA spare parts
219649203320	BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
219649203321	BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
219649203322	BRACKET SUPPORT BS6-PH2	TATA spare parts
219649206911	TAIL PIPE BS6	TATA spare parts
219649206923	TAIL PIPE BS6	TATA spare parts
219649206926	TAIL PIPE BS6	TATA spare parts
219649207113	SUPPORT PLATE BS6	TATA spare parts
219649207801	SEAL BS6	TATA spare parts
219649208211	CLAMP (EXHAUST)	TATA spare parts
219649208213	CLAMP (EXHAUST)	TATA spare parts
219649208215	CLAMP (EXHAUST)	TATA spare parts
219649990102	HEAT SHIELD ASSY BS6-PH2	TATA spare parts
219654504903	SWITCH STEERING WHEEL ADJUSTMENT	TATA spare parts
219654600101	WIRING HARNESS MAIN BS6	TATA spare parts
219654600102	BATTERY CABLE +VE BS6	TATA spare parts
219654600104	WIRING HARNESS ENGINE BS6	TATA spare parts
219654600105	WIRING HARNESS TAIL BS6	TATA spare parts
219654600107	WIRING HARNESS AFTER TREATMENT BS6	TATA spare parts
219654600109	WIRING HARNESS EGP PIGTAIL BS6	TATA spare parts
219654600110	WIRING HARNESS PANEL BS6	TATA spare parts
219654600111	WIRING HARNESS MAXI FUSE	TATA spare parts
219654600117	WIRING HARNESS AFTER TREATMENT BS6	TATA spare parts
219654600118	PIGTAIL UREA LEVEL SENSOR BS6	TATA spare parts
219654600120	WIRINGHARNESSTAIL BS6	TATA spare parts
219654600122	WIRING HARNESS TAIL BS6	TATA spare parts
219654600123	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
219654600125	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
219654600127	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
219654600130	WIRING HARNESS PANEL BS6-PH2	TATA spare parts
219654600131	WIRING HARNESS EGP PIGTAIL BS6-PH2	TATA spare parts
219654600134	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
219654600136	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
219654600141	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
219654600145	BATTERY CABLE -VE BS6-PH2	TATA spare parts
219654600152	WIRING HARNESS MAIN BS6-PH2	TATA spare parts

219654600153	WIRING HARNESS PANEL BS6-PH2	TATA spare parts
219654600154	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
219654600155	WIRING HARNESS MAIN	TATA spare parts
219654600156	WIRING HARNESS PANEL	TATA spare parts
219654600158	EARTH CABLE BS6-PH2	TATA spare parts
219654608202	L-BRACKET BS6	TATA spare parts
219654620106	WIRING HARNESS TAIL/55WB	TATA spare parts
219654640101	WIRING HARNESS POWER CABLE BS6	TATA spare parts
219654800101	PANEL ECU MTG BS6	TATA spare parts
219654800103	PANEL ECU MTG BS6-PH2	TATA spare parts
219654803301	PANEL ELECTRICAL AGGREGATE MTG BS6	TATA spare parts
219654803305	BRACKET ECU MTG BS6-PH2	TATA spare parts
219654806301	COVER ECU PROTECTION BS6	TATA spare parts
219683550104	BRACKET ASSY COMPRESSOR MTG BS6-PH2	TATA spare parts
219688700103	ENGINE HOOD ASSY BS6	TATA spare parts
219688700104	RUBBER BELLOW ASSY GEAR SHIFT LEVER BS6	TATA spare parts
219688700108	RUBBER BELLOW ASSY GEAR SHIFT LEVER BS6	TATA spare parts
219688701601	SEAL BS6	TATA spare parts
219688706304	COVERPLATEHOOD BS6	TATA spare parts
219688707701	SEAL BS6	TATA spare parts
219688707702	RUBBER BELLOW GEAR SHIFT LEVER UPPER BS6	TATA spare parts
219688707703	RUBBER BELLOW GEAR SHIFT LEVER LOWER BS6	TATA spare parts
219688707704	SEAL ENGINE HOOD BS6	TATA spare parts
219709130101	ASSY VACUUM INDICATOR PIPE	TATA spare parts
219709130102	ASSY AIR COMPRESSOR INLET PIPE	TATA spare parts
219709130103	ASSY SNORKEL BOX	TATA spare parts
219709130104	ASSY SERVICE INDICATOR	TATA spare parts
219709130106	ASSY BRACKET FOR AIR COMP. INLET PIPE	TATA spare parts
219709133801	ALUMINIUM PIPE	TATA spare parts
219709133802	ALUMINIUM PIPE	TATA spare parts
219709133803	ALUMINIUM PIPE	TATA spare parts
219709135801	ELBOW HOSE	TATA spare parts
219709135802	HOSE	TATA spare parts
219709136901	PIPE (INTERMEDIATE)	TATA spare parts
219709136902	PIPE (LONG)	TATA spare parts
219709137701	O-RING(2.65 X 28)	TATA spare parts
219709137702	O-RING(2.65 X 25)	TATA spare parts
219709139901	ADAPTER M22X1.5(AIR FILTER INTERMEDIATE)	TATA spare parts
219709139902	ADAPTER M26X1.5(AIR COMP INLET)	TATA spare parts
219720156302	BELT (BANDED TYPE)	TATA spare parts
219729100101	ASSY.FORK (CLUTCH MASTER CYLINDER)	TATA spare parts
219729306701	CLEVIS PIN 10F8X34X29	TATA spare parts
219730100101	ASSY LEVER	TATA spare parts
219731000101	ASSY.FRAME COMPLETE	TATA spare parts
219742400102	ASSY HOSE(COMPRESSOR)	TATA spare parts
219743207101	MTG PLATE CONSEP UNIT	TATA spare parts
219743506801	COUPLING M26X1.5 - M22X1.5 (PIPE END)	TATA spare parts

219746800101	ASSY.STG.PIPE ( 15 O.D.)	TATA spare parts
219746800102	ASSY PIPE (P/STG TANK TO PUMP)	TATA spare parts
219749206901	TAIL PIPE	TATA spare parts
219754209901	INSTRUMENT CLUSTER	TATA spare parts
219754209905	INSTR CLSTR E-SPEEDO 1:0.88 24V	TATA spare parts
219754209906	ELECTRONIC SPEEDOMETER (1:0.88)	TATA spare parts
219754209908	ELECTRONIC SPEEDO METER (1:0.88)	TATA spare parts
219754209910	VEHICLE SPEED SENSOR (12/24V)	TATA spare parts
219754209911	VEHICLE SPEED SENSOR (12/24V)	TATA spare parts
219754209912	ELECTRONIC SPEEDO METER RATIO-0.88 12V	TATA spare parts
219754209913	INSTRUMENT CLUSTER RESLFL ELEC.SPEEDO &HR	TATA spare parts
219754820101	W/H MAIN LPO 1612 RE BS-III INST CLUSTE	TATA spare parts
219754820102	W/H TAIL LPO 1612/59RE BS-III INST.CLST	TATA spare parts
219758400101	ASSY.GREASE PIPE(FOR CLUTCH RELEASE BRG)	TATA spare parts
219826700101	ASSY GEARSHIFT LEVER KNOB	TATA spare parts
219826700102	ASSY GEARSHIFT LEVER LPA 713BP 5 SPEED	TATA spare parts
219826800102	ASSY TURNING TUBE WITH LEVER	TATA spare parts
219826800104	ASSY BRACKET LHD	TATA spare parts
219826800121	BRACKET ASSY GEAR SHIFT LEVER MTG	TATA spare parts
219826800125	TURNING TUBE ASSY	TATA spare parts
219826807701	RUBBER BELLOW	TATA spare parts
219826807702	RETAINER RING	TATA spare parts
219826807704	RUBBER BELLOW OUTER	TATA spare parts
219827505503	FLEX PLATE ADAPTOR ASSY(ATIN1200)	TATA spare parts
219827505504	HUB ADAPTOR	TATA spare parts
219827508204	FLEXPLATE	TATA spare parts
219827508205	RING ASSY ADAPTOR	TATA spare parts
219827508206	WEAR PLATE	TATA spare parts
219827606806	T CONNECTOR	TATA spare parts
219827800103	BOLT AND WASHER KIT	TATA spare parts
219827803201	BOLT - M10	TATA spare parts
219827803209	BOLT M10 X1.5 X25	TATA spare parts
219827803210	BOLT M5X0.8X10	TATA spare parts
219827803211	HEX SCREW	TATA spare parts
219827803212	BOLT M12 X 1 25 X 35	TATA spare parts
219828010101	ASSY AUX. GEAR BOX COMP. WITH PNEUMATIC	TATA spare parts
219828450101	ASSY. LEVER COMPLETE	TATA spare parts
219828450102	ASSY BRACKET (FOR AGB LEVER MTG )	TATA spare parts
219828450105	BRACKET ASSY AGB LEVER MOUNTING	TATA spare parts
219828459901	SLEEVE	TATA spare parts
219829100103	ASSY BRAKE PEDAL COMPLETE	TATA spare parts
219829100107	PIPE ASSY;INTERMEDIATE	TATA spare parts
219829100108	PIPE ASSY;HYD CLUTCH	TATA spare parts
219829100110	CLUTCH PIPE ASSY;MASTER CYLINDER END	TATA spare parts
219829100111	ASSY CLUTCH PIPE	TATA spare parts
219829100113	CLUTCH PEDAL ASSY WITH BUSH	TATA spare parts
219829300101	BUNDY TUBE ASSY CMC TO FIREWALL	TATA spare parts

219829300102	BUNDY TUBE ASSY MIDDLE	TATA spare parts
219830100101	ASSY PULL CABLE ACCELERATOR	TATA spare parts
219830103301	BRACKET (ON TIMING GB COVER FOR ACC)	TATA spare parts
219831000106	FRAME ASSY WITH FITMENT	TATA spare parts
219831000111	FRAME ASSY	TATA spare parts
219831107121	REINFORCEMENT RH	TATA spare parts
219831107122	REINFORCEMENT LH	TATA spare parts
219831200105	ASSY 3RD CROSS MEMBER WITH SUPPORT	TATA spare parts
219831200106	ASSY TUBULAR CROSS MEMBER COMPLETE	TATA spare parts
219831200113	BRACKET ASSY;RH (CONDENSOR MTG-RH)	TATA spare parts
219831200114	BRACKET ASSY;LH (CONDENSOR MTG-LH)	TATA spare parts
219831200115	FRAME ASSY COMPLETE-FOR AC CONDENSOR MT	TATA spare parts
219831200123	EXTENSION PIECE ASSY FRONT-LH	TATA spare parts
219831200124	EXTENSION PIECE ASSYPERCFRONT-RH	TATA spare parts
219831207118	SUPPORTPERENGINE CROSS MEMBER MTGPERC	TATA spare parts
219831207119	SUPPORTPERENGINE CROSS MEMBER MTGPERC	TATA spare parts
219831207127	END CROSS MEMBER	TATA spare parts
219831300101	GUSSET ASSY WITH REINFORCEMENT RH	TATA spare parts
219831300102	GUSSET ASSY WITH REINFORCEMENT LH	TATA spare parts
219831307101	REINFORCEMENT RH	TATA spare parts
219831307102	REINFORCEMENT LH	TATA spare parts
219831308201	GUSSETPERCRH	TATA spare parts
219831308202	GUSSETPERCLH	TATA spare parts
219831540101	BRACKET ASSYPERCBATTERY CUT OFF SWITCH M	TATA spare parts
219832107109	DISTANCE TUBE BS6	TATA spare parts
219841100101	ASSY PROPELLAR SHAFT FRONT (FROM AUX.GB	TATA spare parts
219841100101AE	ASSY PROP SFT FR(AX.GB T FA)-715	TATA spare parts
219841100102	ASSY PROPELLAR SHAFT REAR (FROM AUX.GB T	TATA spare parts
219841100102AE	ASSY PROP SFT R(AX.GB T R A)-715	TATA spare parts
219842300102	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
219842300103	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
219842309906	KIT TORQUE PLATE ASSY LH	TATA spare parts
219842309907	KIT TORQUE PLATE ASSY RH	TATA spare parts
219842309908	KIT BUSH	TATA spare parts
219843200101	KIT ASSY AIR TANK ( FOR VOSS )	TATA spare parts
219843700120	BRACKET ASSY MODULATOR VALVE MTG.RH	TATA spare parts
219843700122	BRACKET ASSY	TATA spare parts
219843703306	BRACKET QRV MTG	TATA spare parts
219843709901	STICKER (FOR FRONT PALM COUPLING)	TATA spare parts
219843900102	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
219843900104	METAL PIPE ASSY JOINT 1 TO JOINT 2	TATA spare parts
219843900105	METAL PIPE ASSY JOINT 2 TO AIR DRYER	TATA spare parts
219843900109	ASSY 2ND COMP OUTLET PIPE	TATA spare parts
219843900110	ASSY 3RD COMP OUTLET PIPE	TATA spare parts
219843900111	ASSY 1ST COMP OUTLET PIPE	TATA spare parts
219843900113	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
219843900116	ASSY 2 ND COMP OUTLET PIPE 18 OD	TATA spare parts



219843900120	ASSY NYLON PIPE SET	TATA spare parts
219843903301	BRACKET-HOSE MTG.	TATA spare parts
219843910162	PIPE ASSY AIR FILTER DUCT TO COMPRESSOR	TATA spare parts
219843910166	PIPE ASSY. BUNCH COMPLTE	TATA spare parts
219846000102	ASSY DRAG LINK	TATA spare parts
219846150101	SUCTION LINE HOSE ASSY.	TATA spare parts
219846150102	PRESSURE LINE HOSE ASSY.	TATA spare parts
219846150103	RETURN LINE HOSE ASSY.	TATA spare parts
219846150104	RETURN LINE HOSE ASSY.	TATA spare parts
219846150105	ASSY KIT PIPES RHD P/STG WITH PLASTIC TA	TATA spare parts
219846600106	STEERING GEAR BOX	TATA spare parts
219846600108	MAJOR KIT-SEAL	TATA spare parts
219847600101	ASSY FUEL LINE-FUEL TANK TO WATER SEPARA	TATA spare parts
219847600102	ASSY FUEL LINE- WATER SEPARATOR TO BABY	TATA spare parts
219847600103	ASSY FUEL RETURN LINE	TATA spare parts
219847600104	ASSY FUEL LINE-FUEL TANK TO FUEL HEATER	TATA spare parts
219847600105	ASSY FUEL LINE-FUELHEATER TO BABY FILTER	TATA spare parts
219847600114	FUEL SUCTION PIPE FUEL TANK TO W/SEP	TATA spare parts
219847600115	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
219847600116	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
219847700102	ASSY.BRACKET (FUEL HEATER MOUNTING)	TATA spare parts
219847704901	ASSY FUEL HEATER	TATA spare parts
219849100102	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
219849200102	EXHAUSTPIPEASSYWITHFLEXBELLOW	TATA spare parts
219849200103	BRACKET ASSY EGP MTG	TATA spare parts
219849206901	TAILPIPE	TATA spare parts
219849206902	TAIL PIPE	TATA spare parts
219854400118	HEADLAMP ASSY WITH CELAR LENS RH	TATA spare parts
219854400119	HEADLAMP ASSY WITH CELAR LENS LH	TATA spare parts
219854500116	BRACKET ASSYPERCBATTERY CUT OFF SWITCH M	TATA spare parts
219854504901	BATTERY CUT OFF SWITCH	TATA spare parts
219854504903	PIANO SWITCHPERCCOLD START	TATA spare parts
219854600111	WIRING HARNESS ABS	TATA spare parts
219854600132	BRACKET ASSYPERC MAXI FUSE MTG	TATA spare parts
219854600139	WIRING HARNESS TAIL	TATA spare parts
219854600146	PIGTAIL OIL PRESSURE GAUGE	TATA spare parts
219854600147	JUMP START BRACKET	TATA spare parts
219854600154	CABLEPERCBATTERY +VE TO CUT OFF SWITCH	TATA spare parts
219854600157	WIRING HARNESS MAIN	TATA spare parts
219854600158	CABLE BATTERY +VE WITH MEGA FUSE	TATA spare parts
219854600162	WIRING HARNESS ENGINE	TATA spare parts
219854601616	BATT CABLE -VEPERCWINCH BCS TO WINCH MTR	TATA spare parts
219854601617	BATT CABLE +VEPERCWINCH BCS TO CONTROL B	TATA spare parts
219854601618	WIRING HARNESS MAIN	TATA spare parts
219854601619	BATT CABLE +VEPERCVEH BCS TO WINCH BCS	TATA spare parts
219854601621	BATT CABLE -VEPERCVEH BCS TO WINCH BCS	TATA spare parts
219854601624	WIRING HARNESSPERCTAIL	TATA spare parts

219854601627	CABLE ASSYPERCSTARTER TO ALTERNATOR	TATA spare parts
219854601629	POWER CABLE ASSY WITH GRID HEATER FUSE	TATA spare parts
219854608213	BRACKET	TATA spare parts
219854620104	WIRING HARNESS TAIL	TATA spare parts
219854620105	WIRING HARNESS MAIN	TATA spare parts
219854620106	WIRING HARNESS CONSOLE	TATA spare parts
219856000101	BRACKET ASSY (WINCH MOUNTING)	TATA spare parts
219856000103	KIT-WINCH	TATA spare parts
219856309901	FAIRLEAD	TATA spare parts
219856309902	REMOTE CONTROL WITH CABLE	TATA spare parts
219856600106	"BRACKET ASSY,WINCH MTG"	TATA spare parts
219860000101SJ	ASSY CAB COMPLETE 715 BS-II CMVR	TATA spare parts
219860000104SJ	ASSY COWL COMPLETE-RHD(LPA713 SPARE)	TATA spare parts
219860000105	ASSY CAB COMPLETE-715 TC BS-III 24V	TATA spare parts
219860000107	CAB COMPLETE-713 TC BS-III CMVR	TATA spare parts
219868906302	DASHBOARD RH (RHD) ATU	TATA spare parts
219872700103	ASSY.PADDING DOOR L.H	TATA spare parts
219872700104	ASSY PADDING DOOR R.H	TATA spare parts
219883100101	ASSY FACE DUCT LH	TATA spare parts
219883100102	ASSY FACE DUCT RH	TATA spare parts
219883100116	ASSY PLENUM CHAMBER COMPLETE RHD	TATA spare parts
219883400105	THERMO&SENSOR&ASSY	TATA spare parts
219883400203	ASSY AC UNIT	TATA spare parts
219883400204	AC UNIT ASSY;RH	TATA spare parts
219883400206	KIT FOR AC PIPES	TATA spare parts
219883400207	ASSY CONTROL PANEL	TATA spare parts
219883400208	ASSY CONDENSOR UNIT 24V	TATA spare parts
219883400301	BLOWER AND AIR INTAKE ASSY	TATA spare parts
219883400302	AIR INTAKE KINEMATICS ASSY	TATA spare parts
219883400304	BLOWER (MOTOR HOLDER) ASSY COMPLETE	TATA spare parts
219883400305	RESISTOR (PLATE TYPE)	TATA spare parts
219883400306	EVAPORATOR ASSEMBLY ( CORE + PIPES)	TATA spare parts
219883400308	O RING SET FOR TXV	TATA spare parts
219883400309	SEALING SET COMPLETE	TATA spare parts
219883400310	MOUNTING BRACKET SET COMPLETE	TATA spare parts
219883400311	HVAC- WIRE HARNESS	TATA spare parts
219883400312	DRAIN HOSE ASSY	TATA spare parts
219883400313	VENTILATION DUCT ASSY	TATA spare parts
219883400318	INTERFACE BKT SET	TATA spare parts
219883403328	AC PIPE MTG BKT	TATA spare parts
219883406901	SUCTION PIPE HVAC END	TATA spare parts
219883406902	LIQUID PIPE HVAC END	TATA spare parts
219883406903	DISCHARGE PIPE COMP. END	TATA spare parts
219883406904	SUCTION PIPE COMP. END	TATA spare parts
219883406905	LIQUID PIPE COND. END	TATA spare parts
219883406906	DISCHARGE PIPE COND. END	TATA spare parts
219883600101	DISCHARGE PIPE;CONDENSER END	TATA spare parts

219883600102	SUCTION PIPE;HVAC END	TATA spare parts
219883600103	LIQUID PIPE ASSY	TATA spare parts
219883600104	SUCTION PIPE;COMPRESSOR END	TATA spare parts
219883600105	DISCHARGE PIPE;COMPRESSOR END	TATA spare parts
219883753301	BRACKETPERCAC PIPE MTG	TATA spare parts
219887309901	TROOP CARRIER COMP BODY ASSY ON LPTA715	TATA spare parts
219889100103	ASSY SUPPORT BKT-LH	TATA spare parts
219889100104	ASSY SUPPORT BKT-RH	TATA spare parts
21CX007Z00	PLATE CORNER BRACKET	TATA spare parts
220001107101	PLATE CYL BLOCK STIFFNER	TATA spare parts
220001139901	LINER CYLINDER	TATA spare parts
220001143702	SCREW HEX HEAD CAP	TATA spare parts
220001143703	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143704	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143705	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143706	SCREW HEXAGON HEAD CAP	TATA spare parts
220001143707	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143708	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143709	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143710	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143711	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143712	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143713	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143714	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143715	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143716	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143717	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143718	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143719	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143720	SCREW HEX FLANGE HEAD CAP (M 8 X 1.25 X	TATA spare parts
220001143721	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143722	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143723	SCREW CAPTIVE WASHER CAP	TATA spare parts
220001143724	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143725	SCREW TWELVE POINT CAP	TATA spare parts
220001143726	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001143727	SCREW TWELVE POINT CAP	TATA spare parts
220001143728	SCREW HEX FLANGE HEAD CAP	TATA spare parts
220001144701	COVER VALVE	TATA spare parts
220001144702	COVER REAR	TATA spare parts
220001144703	COVER GEAR	TATA spare parts
220001145301	GASKET GEAR HOUSING	TATA spare parts
220001145302	GASKET GEAR COVER	TATA spare parts
220001145303	GASKET LUB OIL CLR COVER	TATA spare parts
220001145304	GASKET REAR COVER	TATA spare parts
220001145305	GASKET COVER PLATE	TATA spare parts
220001145401	HOUSING GEAR	TATA spare parts

220001147101	PLATE COVER	TATA spare parts
220001147102	PLATE COVER	TATA spare parts
220001153701	BLOCK CYLINDER	TATA spare parts
220001153702	PLUG THREADED	TATA spare parts
220001153703	PLUG EXPANSION	TATA spare parts
220001153704	PLUG THREADED	TATA spare parts
220001153705	PLUG EXPANSION	TATA spare parts
220001153706	PLUG PIPE	TATA spare parts
220001153707	PLUG EXPANSION	TATA spare parts
220001153708	PLUG PIPE	TATA spare parts
220001153709	PLUG PIPE	TATA spare parts
220001153710	PLUG THREADED	TATA spare parts
220001153711	PLUG EXPANSION	TATA spare parts
220001153712	PLUG EXPANSION	TATA spare parts
220001153713	HEAD CYLINDER	TATA spare parts
220001153714	PLUG PIPE	TATA spare parts
220001153715	PLUG THREADED	TATA spare parts
220001153716	PLUG THREADED	TATA spare parts
220001153717	PLUG EXPANSION	TATA spare parts
220001153718	PLUG EXPANSION	TATA spare parts
220001153719	PLUG EXPANSION	TATA spare parts
220001153720	PLUG EXPANSION	TATA spare parts
220001153722	PLUG THREADED	TATA spare parts
220001155301	GASKET CYLINDER HEAD	TATA spare parts
220001156101	LOCK PLATE	TATA spare parts
220001156501	NUT LOCK BS4	TATA spare parts
220001156502	NUT REGULAR HEXAGON	TATA spare parts
220001156503	NUT HEXAGON FLANGE	TATA spare parts
220001156504	NUT LOCK	TATA spare parts
220001156505	NUT LOCK	TATA spare parts
220001156506	NUT CONNECTING ROD	TATA spare parts
220001156507	BOLT CONNECTING ROD	TATA spare parts
220001157101	PLATE CLAMPING	TATA spare parts
220001158802	STUD BS4	TATA spare parts
220001159201	WASHER SEALING	TATA spare parts
220001159202	WASHER PLAIN	TATA spare parts
220001159203	WASHER SEALING	TATA spare parts
220001159204	WASHER BEVEL	TATA spare parts
220001159205	WASHER PLAIN	TATA spare parts
220001159206	WASHER PLAIN SET	TATA spare parts
220001159901	SEAL RECTANGULAR RING	TATA spare parts
220001159902	SEAL RECTANGULAR RING	TATA spare parts
220001173701	DIPSTICK	TATA spare parts
220001175301	GASKET BREATHER	TATA spare parts
220001176901	TUBE BREATHER	TATA spare parts
220001179901	BREATHER CRANKCASE	TATA spare parts
220001185301	GASKET OIL DRAIN	TATA spare parts

220001185302	GASKET OIL PAN	TATA spare parts
220001185303	GASKET OIL PAN	TATA spare parts
220001188201	PAN OIL	TATA spare parts
220001593401	BUSHING REDUCING PIPE	TATA spare parts
220001593402	BUSHING REDUCING PIPE	TATA spare parts
220001593403	BUSHING REDUCING PIPE	TATA spare parts
220001593404	BUSHING	TATA spare parts
220003103701	CRANKSHAFT ENGINE	TATA spare parts
220003105401	GEAR CRANK SHAFT	TATA spare parts
220003109901	HEAD CORROSION RESISTOR	TATA spare parts
220003113702	HOUSING FLYWHEEL	TATA spare parts
220003113703	HOUSING FLYWHEEL CAST IRON	TATA spare parts
220003115401	GEAR FLYWHEEL RING	TATA spare parts
220003115801	ASSY. FLYWHEEL BS2/3	TATA spare parts
220003123101	BEARING MAIN	TATA spare parts
220003123102	BEARING CONNECTING ROD	TATA spare parts
220003123103	BEARING CRANKSHAFT THRUST	TATA spare parts
220003133701	UNION MALE	TATA spare parts
220003136901	TEE STREET PIPE	TATA spare parts
220003139901	DAMPER VIBRATION	TATA spare parts
220003146701	PIN PISTON	TATA spare parts
220003148001	DOWEL PIN	TATA spare parts
220003148002	DOWEL RING	TATA spare parts
220003153701	CONNECTOR MALE	TATA spare parts
220003153702	CONNECTOR MALE	TATA spare parts
220003153703	CONNECTOR MALE	TATA spare parts
220003153704	CONNECTOR MALE	TATA spare parts
220003156601	ROD ENGINE CONNECTING	TATA spare parts
220003156602	ROD PUSH	TATA spare parts
220003166601	PISTON ENGINE	TATA spare parts
220005103101	BEARING BALL	TATA spare parts
220005105401	GEAR CAMSHAFT	TATA spare parts
220005109901	ISOLATOR NOISE	TATA spare parts
220005113701	RING SET	TATA spare parts
220005114701	CAP FILLER	TATA spare parts
220005117501	BELT V RIBBED	TATA spare parts
220005118701	SPRING VALVE	TATA spare parts
220005119901	TENSIONER BELT	TATA spare parts
220005123701	ROTAR VALVE	TATA spare parts
220005129001	VALVE CHECK	TATA spare parts
220005129002	VALVE SHUTOFF	TATA spare parts
220005129003	VALVE INTAKE	TATA spare parts
220005129004	VALVE EXHAUST	TATA spare parts
220005129005	GUIDE VALVE STEM	TATA spare parts
220005129006	INSERT VALVE	TATA spare parts
220005129901	COLLET VALVE	TATA spare parts
220005143301	BRACKET LIFTING	TATA spare parts

220005143302	BRACKET LIFTING	TATA spare parts
220005148701	SPRING COMPRESSION	TATA spare parts
220005148702	SPRING COMPRESSION	TATA spare parts
220005149901	CAP FILLER	TATA spare parts
220005149903	LEVER ROCKER	TATA spare parts
220005149904	SHAFT ROCKER LEVER	TATA spare parts
220006103701	CLIP	TATA spare parts
220006104201	CLAMP V BAND	TATA spare parts
220006104202	CLAMP TUBE	TATA spare parts
220006104203	CLAMP RETAINING	TATA spare parts
220006104301	CLIP	TATA spare parts
220006104302	CLIP	TATA spare parts
220006104303	CLIP	TATA spare parts
220006105301	GASKET CONNECTION	TATA spare parts
220006109901	PLUNGER PRS REGULATOR	TATA spare parts
220007103701	PUMP FUEL INJECTION	TATA spare parts
220007103702	INJECTOR	TATA spare parts
220007106801	CONNECTION WATER TRANSFER	TATA spare parts
220007106802	CONNECTION WATER INLET	TATA spare parts
220007107701	SEAL INJECTOR	TATA spare parts
220007109901	SHIELD DUST	TATA spare parts
220007123701	RING RETAINING	TATA spare parts
220007123702	CONNECTOR BANJO	TATA spare parts
220007123703	CONNECTOR BANJO	TATA spare parts
220007124201	CLAMP INJECTOR	TATA spare parts
220007126901	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
220007128001	SCREW BANJO CONNECTOR	TATA spare parts
220007128002	SCREW BANJO CONNECTOR	TATA spare parts
220007129901	DRAIN COCK	TATA spare parts
220007133701	ISOLATOR NOISE	TATA spare parts
220007146901	MANIFOLD FUEL	TATA spare parts
220007146902	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
220009105201	SUPPORT FUEL PUMP	TATA spare parts
220009105202	SUPPORT FUEL PUMP	TATA spare parts
220009105203	SUPPORT FUEL PUMP	TATA spare parts
220009105401	GEAR FUEL PUMP	TATA spare parts
220009109901	PUMP FUEL TRANSFER	TATA spare parts
220009113301	BRACKET FILTER	TATA spare parts
220009118201	STRAINER FUEL	TATA spare parts
220009119901	FILTER FUEL	TATA spare parts
220009126901	TUBE FUEL SUPPLY	TATA spare parts
220009126902	TUBE AIR FUEL CONTROL	TATA spare parts
220009126903	TUBE AIR FUEL CONTROL	TATA spare parts
220009126904	TUBE FUEL SUPPLY	TATA spare parts
220009126905	TUBE FUEL SUPPLY	TATA spare parts
220009126906	TUBE FUEL SUPPLY	TATA spare parts
220009144901	ADAPTER FILTER HEAD	TATA spare parts

220011309001	VALVE BYPASS	TATA spare parts
220013103701	BRACE AIR COMPRESSOR	TATA spare parts
220013103702	BRACE TUBE	TATA spare parts
220013109901	COMPRESSOR AIR	TATA spare parts
220013109902	BRACE FUEL PUMP	TATA spare parts
220013109903	BRACE TUBE	TATA spare parts
220014103301	ELBOW PLAIN UNION	TATA spare parts
220014103701	MANIFOLD OIL	TATA spare parts
220014103702	ELBOW PLAIN STREET PIPE	TATA spare parts
220014103703	ELBOW MALE ADAPTER	TATA spare parts
220014104601	COUPLING ELBOW HOSE	TATA spare parts
220014104602	COUPLING ELBOW HOSE	TATA spare parts
220014105301	GASKET INT MANIFOLD COVER	TATA spare parts
220014105302	GASKET COVER PLATE	TATA spare parts
220014113701	MANIFOLD EXHAUST	TATA spare parts
220014114701	COVER INTAKE MANIFOLD	TATA spare parts
220014115301	GASKET EXHAUST MANIFOLD	TATA spare parts
220014116801	CONNECTION EXHAUST OUTLET	TATA spare parts
220014513701	TURBOCHARGER	TATA spare parts
220014515301	GASKET TURBOCHARGER	TATA spare parts
220014526901	TUBE COMPRESSOR AIR INLET	TATA spare parts
220015104901	MOTOR STARTING	TATA spare parts
220015107901	CAMSHAFT	TATA spare parts
220015108601	SPACER STARTING MOTOR	TATA spare parts
220015109901	BRACE ALTEROTOR	TATA spare parts
220015114201	ADAPTER PLAIN	TATA spare parts
220015134901	ADAPTER PLAIN	TATA spare parts
220015139901	PULLEY ALTERNATOR	TATA spare parts
220015403301	SUPPORT ALTEROTOR	TATA spare parts
220015404901	ALTERNATOR	TATA spare parts
220017309901	SEAL VALVE	TATA spare parts
220018109901	PUMP LUBRICATING OIL	TATA spare parts
220018109902	SEAL OIL	TATA spare parts
220018109903	SCREEN OIL SUCTION	TATA spare parts
220018133701	HEAD LUB OIL FILTER	TATA spare parts
220018133702	HEAD LUB OIL FILTER	TATA spare parts
220018136901	TUBE OIL FILTER	TATA spare parts
220018139901	OIL FILTER ELEMENT (SPINON) BS2/3	TATA spare parts
220018156801	CONNECTION OIL SUCTION	TATA spare parts
220018166901	TUBE TUR OIL DRAIN	TATA spare parts
220018166902	TUBE LUB OIL SUPPLY	TATA spare parts
220018169901	CONNECTION TUR OIL DRAIN	TATA spare parts
220018176901	TUBE OIL GAUGE	TATA spare parts
220018176902	GASKET OIL COOLER CORE	TATA spare parts
220018179901	NOZZLE PISTON COOLING	TATA spare parts
220020105301	GASKET HYDRAULIC PUMP	TATA spare parts
220020109901	PUMP WATER	TATA spare parts

220020113701	CORE COOLER	TATA spare parts
220020124201	CLAMP V BAND	TATA spare parts
220020126901	TUBE CPR WATER INLET	TATA spare parts
220020126902	TUBE CPR WATER OUTLET	TATA spare parts
220020126903	TUBE CORROSION RESISTOR	TATA spare parts
220020126904	TUBE CORROSION RESISTER	TATA spare parts
220020129901	THERMOSTAT	TATA spare parts
220020129902	RESISTOR CORROSION	TATA spare parts
220020129903	CONNECTION WATER OUTLET	TATA spare parts
220020147001	PULLEY FAN	TATA spare parts
220020148601	SPACER MOUNTING	TATA spare parts
220020148602	SPACER MOUNTING	TATA spare parts
220020148603	SPACER MOUNTING	TATA spare parts
220020155201	SUPPORT FAN	TATA spare parts
220020304201	CLAMP HOSE	TATA spare parts
220020304202	CLAMP HOSE	TATA spare parts
220020304203	CLAMP HOSE	TATA spare parts
220020304204	CLAMP HOSE	TATA spare parts
220020304205	CLAMP SPRING HOSE	TATA spare parts
220020304206	CLAMP TUBE	TATA spare parts
220020304206AE	CLAMP TUBE 1628	TATA spare parts
220020304601	COUPLING PLAIN HOSE	TATA spare parts
220020305801	HOSE PLAIN	TATA spare parts
220020305802	HOSE PLAIN	TATA spare parts
220020305803	HOSE PLAIN	TATA spare parts
220020305804	HOSE PLAIN	TATA spare parts
220020305805	HOSE PLAIN	TATA spare parts
220020305806	HOSE PLAIN	TATA spare parts
220020305807	HOSE PLAIN	TATA spare parts
220020305808	CLAMP HOSE	TATA spare parts
220020305809	HOSE FLEXIBLE	TATA spare parts
220020305810	HOSE FLEXIBLE	TATA spare parts
220020305811	HOSE FLEXIBLE	TATA spare parts
220020305812	HOSE PLAIN	TATA spare parts
220022104201	CLAMP SPRING HOSE	TATA spare parts
220022109901	SEAL O RING	TATA spare parts
220022109902	SEAL O RING	TATA spare parts
220022109903	SEAL O RING	TATA spare parts
220022109904	SEAL O RING	TATA spare parts
220022109905	SEAL O RING	TATA spare parts
220022109906	SEAL O RING	TATA spare parts
220022109907	SEAL O RING	TATA spare parts
220022109908	SEAL O RING	TATA spare parts
220022109909	SEAL O RING	TATA spare parts
220022109910	SEAL O RING BS6	TATA spare parts
220022109912	SEAL O RING	TATA spare parts
220022109913	SEAL O RING	TATA spare parts



220128450101	ASSY BRACKET (FOR AGB LEVER MTG)	TATA spare parts
220128450102	ASSY BRACKET REAR (AGB PULL CABLE)	TATA spare parts
220128450104	ASSY BRACKET (AGB SUPPORT MTG)LH SIDE	TATA spare parts
220128450105	ASSY BRACKET (AGB MTG)RH SIDE	TATA spare parts
220131000102	ASSY. FRAME	TATA spare parts
220132100101	ASSY FRONT SPRING	TATA spare parts
220132300101	ASSY BRACKET SHOCK ABSORBER MTG - LH	TATA spare parts
220132300102	ASSY BRACKET SHOCK ABSORBER MTG -RH	TATA spare parts
220132404201	U' CLAMP	TATA spare parts
220132600102	ASSY REAR SHOCK ABSORBER	TATA spare parts
220141100101	ASSY PROP SHAFT(GB TO AGB)	TATA spare parts
220141100107	ASSY PROP SHAFT COMP.(AGB TO RA)	TATA spare parts
220141100114	CROSS ASSY.	TATA spare parts
220141120101	ASSY PROP SHAFT(AGB TO FA)	TATA spare parts
220143200101	ASSY BKT FOR DDU MTG.	TATA spare parts
220146000102	DRAG LINK ASSY (TALBROS) LPTA1413	TATA spare parts
220149208201	BRACKET	TATA spare parts
220188200101	ASSY.FENDER-LH	TATA spare parts
220188200102	ASSY.FENDER-RH	TATA spare parts
220200990105	KIT FOR CABIN LPK 1613 CRI6 BSIV BLOWER	TATA spare parts
220209136901	AIR INLET PIPE	TATA spare parts
220214606901	PIPE (TC TO IC)	TATA spare parts
220224200101	ASSY BRACKET (ENGINE MTG. REAR BOTTOM)	TATA spare parts
220229100102	BUNDY TUBE ASSY CMC TO LONG MEMBER	TATA spare parts
220230100102	BRACKET ASSY ACCELERATOR PEDAL	TATA spare parts
220231000101	ASSY.FRAME COMPLETE(36 W.B)	TATA spare parts
220231000102	ASSY. FRAME COMPLETE(32 W.B)	TATA spare parts
220231000103	ASSY FRAME COMPLETE	TATA spare parts
220231000105	FRAME ASSY	TATA spare parts
220231000106	FRAME ASSY WITH FITMENT	TATA spare parts
220231200101	ASSY. 4TH CROSS MEMBER	TATA spare parts
22023120010161	ASSY. 4TH CROSS MEMBER_UNASSEMBLED	TATA spare parts
220231200102	ASSY REINFORCEMENT BKT-RH	TATA spare parts
220231200103	ASSY REINFORCEMENT BKT-LH	TATA spare parts
220231200105	ASSY SUPPORT WITH SPACER(ENG C/M REAR)	TATA spare parts
220231200110	ASSY ENGINE CROSS MEMBER (REAR)	TATA spare parts
220231200111	ASSY. RETRO KIT-STIFFENER (ENG.C.M)	TATA spare parts
220231200121	CROSS MEMBER ASSY ENGINE REAR	TATA spare parts
22023120012135	CROSS MBR ENGINE REAR_UNPAINTED	TATA spare parts
220231207101	REINFORCEMENT FRONT BOTTOM-LH	TATA spare parts
220231207102	REINFORCEMENT FRONT BOTTOM-RH	TATA spare parts
220231207110	REINFORCEMENT BOTTOM -RH	TATA spare parts
220231207111	REINFORCEMENT BOTTOM -RH	TATA spare parts
220231207117	STIFFENER RH(3RD CROSS MEMBER)	TATA spare parts
220231207119	STIFFENER-LH(3RD CROSS MEMBER)	TATA spare parts
220231307101	REINFORCEMENT BOTTOM-RH	TATA spare parts
220231307102	REINFORCEMENT BOTTOM-LH	TATA spare parts

220231700101	ASSY. NOISE SHIELD(GEAR BOX -REAR)	TATA spare parts
220231700102	ASSY SUPPORT BRKT(G/BOX SHLD MTG-REAR)	TATA spare parts
220231700103	ASSY SUPPORT BRACKET RH(G/B SHIELD MTG F	TATA spare parts
220231700104	ASSY SUPPORT BRACKET LH(G/B SHIELD MTG-F	TATA spare parts
220231700105	ASSY SUPPORT BRACKET-RH(ENG SHLD MTG-REA	TATA spare parts
220231700106	ASSY SUPPORT BRACKET-LH (ENG SHLD MTG-RE	TATA spare parts
220231700107	ASSY SUPPORT BRKT(ENG SHLD MTG-MIDDLE)	TATA spare parts
220232100101	ASSY BRACKET-RH AXLE STOPPER	TATA spare parts
220232100102	ASSY BRACKET-LH AXLE STOPPER	TATA spare parts
220232300101	ASSY BRACKET (FRONT SHOCK ABSORBER)	TATA spare parts
220232300102	SHOCK ABSORBER BKT ASSY TOP	TATA spare parts
22024036300RCK	ASSY CABIN KIT FOR 22024036300R LPK 1613	TATA spare parts
220241100101	ASSY. PROP. SHAFT WITH CENTRE BRG(486-L)	TATA spare parts
220241100104	ASSY. PROP. SHAFT WITH CB	TATA spare parts
220241108201	CHENNEL PROP SHAFT GURD MTG	TATA spare parts
220241120101	ASSY PROP SHAFT REAR(CLOSE LENGTH	TATA spare parts
220241303301	CENTRE BEARING BRACKET	TATA spare parts
220243200102	ASSY BRACKET-RH(AIR TANK MTG.)	TATA spare parts
220243200103	ASSY BRACKET-LH(AIR TANK MTG.)	TATA spare parts
220243200104	ASSY.AIR TANK COMPLETE WITH STRAP & SUPP	TATA spare parts
220243200106	ASSY.AIR TANK COMPLETE WITH VOSS CONNECT	TATA spare parts
220243200107	ASSY.AIR TANK COMPLETE WITH VOSS CONNECT	TATA spare parts
220243200110	SUB ASSY. AIR TANK (15 LTR)	TATA spare parts
220243200111	ASSY. AUX. AIR TANK WITH BRACKETS	TATA spare parts
220243700107	ASSY BRACKET-DDU MTG.	TATA spare parts
220243900101	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
220243900104	ASSY. NYLON PIPE SET COMPLETE (VOSS) 36W	TATA spare parts
220243900105	ASSY.NYLON PIPE SET COMPLETE (VOSS)	TATA spare parts
220243900118	ASSY.NYLON PIPE SET COMPLETE (VOOS) 36WB	TATA spare parts
220243900119	ASSY.COMPRESSOR 1ST PIPE	TATA spare parts
220243900120	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
220243900121	ASSY.COMPRESSOR 3RD PIPE	TATA spare parts
220243900126	BUNCH ASSY PIPE	TATA spare parts
220243900129	METAL PIPE ASSY JOINT 1 TO JOINT 2	TATA spare parts
220243900130	PIPE ASSY COMPRESSOR TO JOINT-1	TATA spare parts
220243900141	BUNCH ASSY PIPE	TATA spare parts
220243900173	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
220243900174	METAL PIPE ASSY HOSE TO INT JOINT	TATA spare parts
220243900175	METAL PIPE ASSY INT JOINT TO DDU	TATA spare parts
220243903301	Z-BRACKET	TATA spare parts
220243903302	Z-BRACKET	TATA spare parts
220243903303	L-BRACKET	TATA spare parts
220243903304	ZFLASEBRACKET BS6-PH2	TATA spare parts
220243903305	BRACKET	TATA spare parts
220243903308	STRAIGHT BRACKET BS6	TATA spare parts
220244100114	CYLINDER ASSY	TATA spare parts
220244100116	HYDRAULICCYLINDER	TATA spare parts

220244100120	CYLINDER ASSY HYDRAULIC BS6	TATA spare parts
220244105802	HOSE PUMP TO VALVE	TATA spare parts
220244105803	HOSE-TANK TO PUMP	TATA spare parts
220244105804	HOSE ASSY BS6	TATA spare parts
220244105805	SUCTION HOSE ASSY BS6	TATA spare parts
220244105807	RETURN LINE HOSE BS6	TATA spare parts
220244105808	RETURN LINE HOSE BS6	TATA spare parts
220244106803	ADAPTOR 1 1/2" BSP X 1 7/16" U	TATA spare parts
220244106804	ASSY. ELBOW M39X2-1-3/4INCH ID HOSE CONN	TATA spare parts
220244107701	HOSE ASSY HYD TANK TO PUMP	TATA spare parts
220244108203	CLAMP BS6	TATA spare parts
220244109204	PLAIN WASHER BS6	TATA spare parts
220244400102	HYDRAULIC GEAR PUMP-REAR PTO	TATA spare parts
220244400105	HYDRAULIC TANK ASSY BS6	TATA spare parts
220246150104	KIT ASSY.PIPES & CONNECTORS	TATA spare parts
220246150108	KIT PIPE LINE	TATA spare parts
220246800111	ASSY RETURN LINE (STG.GB TO RES. OIL TAN	TATA spare parts
220246800112	ASSY SUCTION LINE (RES.OIL TANK TO STG.P	TATA spare parts
220246800116	SUCTION LINE ASSY	TATA spare parts
220246800117	PRESSURE LINE ASSY	TATA spare parts
220246800118	PRESSURE LINE ASSY	TATA spare parts
220247600101	ASSY.BRACKET(WATER SEPARATOR MTG.)	TATA spare parts
220247600102	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
220247600103	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
220247600104	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
220247600105	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
220247600106	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
220247600107	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
220247600108	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
220247600109	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
220247600110	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts
220247600117	ASSY. SUCTION LINE (BABY TO FUEL FILTER)	TATA spare parts
220247600118	ASSY SUCTION LINE (TANK TO BABY FILTER)	TATA spare parts
220247600119	ASSY RETURN LINE (ACCUM. TO FUEL TANK)	TATA spare parts
220247600121	SUCTION PIPE ASSY W/SEP TO FILTER	TATA spare parts
220247600125	SUCTION LINE PIPE ASSY (TANK TO FILTER)	TATA spare parts
220247600126	SUCTION LINE PIPE ASSY (FILTER TO ENG)	TATA spare parts
220247600127	RETURN LINE PIPE ASSY	TATA spare parts
220247600128	SUCTION PIPE ASSY FUEL TANK TO W/SEP	TATA spare parts
220247600130	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
220247600131	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
220247608201	BRACKET (FUEL FEED PUMP MTG.)	TATA spare parts
220247608203	BRACKET(FOR FILTER MTG)	TATA spare parts
220247700101	BRACKET ASSY W/SEP MTG	TATA spare parts
220247707101	BRACKET (FILTER MTG.)	TATA spare parts
220249100101	ASSY. SILENCER WITH TAIL PIPE	TATA spare parts
220249100104	SILENCER ASSY WITH FLANGE	TATA spare parts

220249200101	ASSY. INTERMEDIATE PIPE(TURBO END)	TATA spare parts
220249200102	ASSY. INTERMEDIATE PIPE (MUFFLER END)	TATA spare parts
220249200103	ASSY.BRACKET	TATA spare parts
220249200104	ASSY. BRACKET (EXHAUST MTG.)	TATA spare parts
220249200105	ASSY INTERMEDIATE PIPE(MUFFLER END)	TATA spare parts
220249200106	ASSY INTERMEDIATE PIPE(TURBO END)	TATA spare parts
220249200107	ASSY. FIRST EXHAUST PIPE	TATA spare parts
220249200109	ASSY INTERMEDIATE PIPE-2ND(MUFFLER END)	TATA spare parts
220249200112	EXHAUST THIRD PIPE ASSEMBLY	TATA spare parts
220249200113	EXHAUST SECOND PIPE ASSEMBLY	TATA spare parts
220249200118	ASSY BRACKET (EXHAUST MTG.)	TATA spare parts
220249200120	ASSY BRACKET (EXHAUST MTG.)	TATA spare parts
220249200122	EXHAUST PIPE ASSY CENTER	TATA spare parts
220249200123	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
220249200126	BRACKET ASSY SILENCER MTG	TATA spare parts
220249200127	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
220249200128	BRACKET ASSY TAIL PIPE MTG	TATA spare parts
220249200132	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
220249203301	BRACKET	TATA spare parts
220249203304	BRACKET	TATA spare parts
220249203305	BRACKET SILENCER MTG	TATA spare parts
220249203307	CLAMP	TATA spare parts
220249203308	CLAMP	TATA spare parts
220249203309	CLAMP	TATA spare parts
220249203310	CLAMP	TATA spare parts
220249203311	BRACKET EXHAUST PIPE MTG	TATA spare parts
220249203312	BRACKET EXHAUST PIPE MTG	TATA spare parts
220249203313	BRACKET SILENCER MTG	TATA spare parts
220249203315	BRACKET EXHAUST PIPE CLAMPING	TATA spare parts
220249203317	BRACKET EXHAUST BRAKE SUPPORT	TATA spare parts
220249203318	BRACKET DPS SENSOR MTG	TATA spare parts
220249204201	CLAMP	TATA spare parts
220249204202	CLAMP DOC POC	TATA spare parts
220249206908	TAIL PIPE	TATA spare parts
220249206916	PIPE (DPS TO DOC POC OUTLET)	TATA spare parts
220249206920	TUBE HOSE TO DPS	TATA spare parts
220249206921	TUBE HOSE TO DPS	TATA spare parts
220249208201	EXHAUST MTG. PLATE (ON CROSS MEMBER)	TATA spare parts
220249208202	BRACKET	TATA spare parts
220249208203	BRACKET	TATA spare parts
220249208204	PLATE (EXHAUST MTG.)	TATA spare parts
220249208208	BRACKET	TATA spare parts
220249600101	HEAT SHIELD ASSY EXHAUST PIPE	TATA spare parts
220249604202	CLAMP HEAT SHIELD REAR BS6	TATA spare parts
220249605305	HEAT SHIELD DOC POC	TATA spare parts
220249990101	HEAT SHIELD ASSY-INT. PIPE EXHUAST	TATA spare parts
220249990105	KIT-EXHAUST HEAT SHIELD	TATA spare parts

220249990106	KIT-EXHAUST PIPE HEAT SHIELD	TATA spare parts
220249990107	KIT-EXHAUST HEAT SHIELD	TATA spare parts
220250116901	VENT TUBE (UCWL TO AUX. TANK)	TATA spare parts
220250116902	VENT TUBE (RADIATOR TO AUX TANK)	TATA spare parts
220250116903	WATER FILL PIPE	TATA spare parts
220250116904	WATER FILL PIPE	TATA spare parts
220254209901	PLATE-DIGITAL HOUR METER	TATA spare parts
220254209903	INST CLUSTER(1:0.88)LPK 1613 697 BS-III	TATA spare parts
220254209904	E-RPM METER WITH DIGITAL DISPLAY	TATA spare parts
220254600103	WIRING HARNESS FRONT	TATA spare parts
220254600104	WIRING HARNESS MAIN	TATA spare parts
220254600106	WIRING HARNESS SENSOR	TATA spare parts
220254600107	WIRING HARNESS ABS FRAME	TATA spare parts
220254600111	WIRING HARNESS ABS PIGTAIL	TATA spare parts
220254600120	WIRING HARNESS ENGINE	TATA spare parts
220254600121	INTERAXLE SW PIGTAIL	TATA spare parts
220254660101	W/H MAIN LPK-1613 697 BS-II	TATA spare parts
220254660102	W/H TAIL LPK-1613/36 697 BS-II	TATA spare parts
220254660103	W/H ENGINE LPK-1613 697 BS-II	TATA spare parts
220254660104	W/H INST CONSOLE LPK1613 697 BSII	TATA spare parts
220254660105	WIRING HARNESS TAIL	TATA spare parts
220254660106	W/H-PIG TAIL (DIGITAL HOUR METER)	TATA spare parts
220254660116	W/H MAIN LPK 1613 697 BS-IV 12V	TATA spare parts
220254660117	W/H TAIL-LPK 1613 697 BS-IV 12V	TATA spare parts
220254660118	W/H ENGINE-LPK 1613 697 BS-IV 12V	TATA spare parts
220254660119	W/H INSTRUMENT CONSOLE	TATA spare parts
220254660122	WIRING HARNESS TAIL	TATA spare parts
220254660123	WIRING HARNESS MAIN	TATA spare parts
220254660124	WIRING HARNESS MAIN	TATA spare parts
220254660125	WIRING HARNESS TAIL	TATA spare parts
220254660126	WIRING HARNESS ENGINE	TATA spare parts
220254660127	WIRING HARNESS MAIN	TATA spare parts
220287000103	ASSY LOAD BODY _10CUM_ BOX	TATA spare parts
220287000147	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
220287000156	LOAD BODY BS6	TATA spare parts
220287000157	CUBED BODY ASSEMBLY - 12 BOX (SIGNA 1923	TATA spare parts
220287000159	TIPPER BODY ASSEMBLY - 12 BOX (SIGNA 192	TATA spare parts
220287000170	LOAD BODY W/ SUBFRAME ASSY W/O KIT BS6	TATA spare parts
220287000174	LOAD BODY WITHOUT SUBFRAME BS6	TATA spare parts
220287000175	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
220287010101	LOAD BODY W/O SUBFRAME ASSY BS6	TATA spare parts
220287100101	ASSY.SUB FRAME	TATA spare parts
220287100102	CYLINDER	TATA spare parts
220287100110	CRADLE ASSY CYL MTG BS6	TATA spare parts
220287100127	SUBFRAME ASSY BS6	TATA spare parts
220287100136	SUBFRAME ASSY BS6	TATA spare parts
220287100143	SUBFRAME ASSY WITH MOUNTINGS BS6	TATA spare parts

220287100156	FLOOR ASSY BS6	TATA spare parts
220287100165	SUBFRAME ASSY BS6	TATA spare parts
220287107120	PLATE HOOK BS6	TATA spare parts
220287108233	PLATE CRADLE SUPPORT BS6	TATA spare parts
220287108269	STOPPER PLATE BS6	TATA spare parts
220287118232	MUDGUARD BS6	TATA spare parts
220287118234	RAIN FLAP BS6	TATA spare parts
220287118235	RAIN FLAP BS6	TATA spare parts
220287118238	PLATE MUDGUARD BS6	TATA spare parts
220287200103	FRONT WALL ASSY BS6	TATA spare parts
220287300132	SIDE BOARD ASSY LH BS6	TATA spare parts
220287300133	SIDE BOARD ASSY RH BS6	TATA spare parts
220287400109	TAILGATE ASSY BS6	TATA spare parts
220287400111	TAILGATE ASSY BS6	TATA spare parts
220287400112	TAILGATE ASSY BS6	TATA spare parts
220287800105	CHAIN BS6	TATA spare parts
220287800121	CHAIN	TATA spare parts
220287808233	PLATE BOTTOM CLAMP BS6	TATA spare parts
220287900101	MUDGUARD ASSY BS6	TATA spare parts
220287900102	FRAME ASSY BS6	TATA spare parts
220287900112	LOCK SUPPORT TAILGATE LH BS6	TATA spare parts
220287900113	LOCK SUPPORT TAILGATE RH BS6	TATA spare parts
220287907701	RAIN FLAP BS6	TATA spare parts
220287907702	RAIN FLAP REAR BS6	TATA spare parts
220287908201	RAIN FLAP BS6	TATA spare parts
220287908203	RAIN FLAP LH BS6	TATA spare parts
220287908204	RAIN FLAP RH BS6	TATA spare parts
220287999903	REFLECTIVE TAPE BS6	TATA spare parts
2203-K-3001	SHIM	TATA spare parts
2203-L-3002	SHIM	TATA spare parts
220360000101	ASSY CAB COMPLETE	TATA spare parts
220510130001	REAR INNER DOME - FRP BS6	TATA spare parts
220510140001	FRONT INNER DOME BS6	TATA spare parts
220510150001	REAR INNER DOME - FRP BS6	TATA spare parts
220510160001	FRONT INNER DOME BS6	TATA spare parts
220520150017	WAIST RAIL PVC MOULDING	TATA spare parts
220609135801	HOSE (AIR FILTER END)	TATA spare parts
220609136901	PIPE (AIR FILTER END)	TATA spare parts
220629300101	ASSY. YUBE (6 O.D. X 590 LG.)	TATA spare parts
220629300102	ASSY. TUBE (6 O.D. X 1455 LG.)	TATA spare parts
22063810675	WATER PUMP BOLT M 10 X 95	TATA spare parts
220643906801	SEALING PLUG	TATA spare parts
220646100101	ASSY STEERING G/BOX MTG BRACKET	TATA spare parts
220649100103	ASSY MUFFLER WITH TAIL PIPE	TATA spare parts
220654200101	ERPM W/DGTL H/METER 24V	TATA spare parts
220700990102	ASSY. RETRO KIT FOR CHASSIS MOUNT AIR DU	TATA spare parts
220700990105	ASSY. CABIN KIT LPK2523 NSLPR BLW BS4/6	TATA spare parts

220726800116	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
220726800120	ASSY SUPPORT TUBE (G/SHIFT BRACKET)	TATA spare parts
220726800125	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
220726800126	ASSY BRACKET(LINK ROD MTG)	TATA spare parts
220726800130	ASSY. TURNING TUBE (WITH BUSH)	TATA spare parts
220726800134	ASSY. BRACKET#(GEAR SHIFT LINKAGE)	TATA spare parts
220726800137	ASSY TURNING TUBE WITHOUT BALL JOINT	TATA spare parts
220726800142	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
220726907101	BRACKET-RH (OIL COOLER MTG)	TATA spare parts
220726907102	BRACKET-LH (OIL COOLER MTG)	TATA spare parts
220729100102	ASSY PEDAL LEVER COMPLETE	TATA spare parts
220729100103	ASSY CLUTCH FLUID RESERVIOR WITH CLAMP	TATA spare parts
220729100104	CLUTCH PEDAL ASSY WITH BUSH	TATA spare parts
220729100111	ASSY CLUTCH PEDAL COMPLETE	TATA spare parts
220729300103	ASSY TUBE (DIA 6 X 3200 LG.)	TATA spare parts
220729300104	ASSY. TUBE (DIA 6 X 3070 LG.)	TATA spare parts
220729500102	BRACKET ASSY CLUTCH PEDAL MTG	TATA spare parts
220730100101	ASSY CONTROL SHAFT	TATA spare parts
220730100102	ASSY LEVER	TATA spare parts
220730100103	ASSY PULL ROD (L=970)	TATA spare parts
220730100105	ASSY. SUPPORT BKT FOR CABLE HOLDER	TATA spare parts
220730100106	ASSY PULL CABLE-ACCELERATOR	TATA spare parts
220730100113	ASSY CONTROL SHAFT	TATA spare parts
220730100114	ASSY PULL CABLE ACCELERATOR	TATA spare parts
220730100115	ASSY ACCELERATOR BRACKET-COMPLETE	TATA spare parts
220730100118	ASSY PULL CABLE ENGINE STOP	TATA spare parts
220730100119	ASSY PULL ROD	TATA spare parts
220730100120	ASSY PULL CABLE ACCELERATOR	TATA spare parts
220730100121	ASSY PULL CABLE ENGINE STOP	TATA spare parts
220731000101	ASSY FRAME COMPLETE	TATA spare parts
220731000102	ASSY FRAME COMPLETE	TATA spare parts
220731000103	ASSY FRAME COMPLETE (1487 ROH)	TATA spare parts
220731000105	ASSY FRAME COMPLET(1487 ROH-TILT CAB)	TATA spare parts
220731000108	ASSY FRAME COMPLETE (1487 ROH-TILT CAB)	TATA spare parts
220731000109	ASSY. FRAME WITH FITMENT BS3	TATA spare parts
220731000114	ASSY. FRAME WITH FITMENT BS4	TATA spare parts
22073100011404	ASSY FRAME LPK2523(FAB 4 HOLE BRKT)BS4	TATA spare parts
22073100011406	ASSY FRAME (CAST TYPE 6 HOLE BRKT)	TATA spare parts
220731000122	FRAME ASSY WITH FITMENT	TATA spare parts
220731000125	ASSY. FRAME LPK2518(FAB 4 HOLE BKT)BS3/4	TATA spare parts
220731107119	REINFORCEMENT-RH	TATA spare parts
220731107120	REINFORCEMENT-LH	TATA spare parts
220731130113	AIR FILTER MNTG BRACKET	TATA spare parts
220731200101	ASSY BRACKET-RH(RADIATOR MTG BOTTOM)	TATA spare parts
220731200102	ASSY BRACKET-LH(RADIATOR MTG BOTTOM)	TATA spare parts
220731200110	ASSY ENGINE X-MEMBER REAR(WITH SUPPORT)	TATA spare parts
220731200111	ASSY.END CROSS MEMBER WITH GUSSET	TATA spare parts

220731200113	ASSY.END CROSS MEMBER WITH GUSSET	TATA spare parts
22073120011361	ASSY.END CROSS MEMBER_UNASSEMBLED	TATA spare parts
220731200114	CROSS MEMBER ASSY CENTER	TATA spare parts
220731200116	RADIATOR GRILL SUPPORT ASSY FRONT-RH	TATA spare parts
220731200117	RADIATOR GRILL SUPPORT ASSY FRONT-LH	TATA spare parts
220731200118	BRACKET ASSY RADIATOR MTG - RH	TATA spare parts
220731200119	BRACKET ASSY RADIATOR MTG.-LH	TATA spare parts
220731200120	RADIATOR GRILL SUPPORT ASSY FRONT-RH	TATA spare parts
220731200121	RADIATOR GRILL SUPPORT ASSY FRONT-LH	TATA spare parts
220731200122	BRACKET ASSY RADIATOR MTG RH	TATA spare parts
220731200123	BRACKET ASSY,RADIATOR MTG,LH	TATA spare parts
220731207110	STIFFENER ENGINE MTG CROSS MEMBER REAR	TATA spare parts
220731207117	C-CHANNEL (FOR DOUBLE X-MEMBER ASSY)	TATA spare parts
220731207118	SUPPORT - TOP (6TH CROSS MEMBER)	TATA spare parts
220731207119	SUPPORT - BOTTOM (6TH CROSS MEMBER)	TATA spare parts
220731207120	GUSSET - DOUBLE X MEMBER ASSY	TATA spare parts
220731900201	RADIATOR PROTECTIVE GRILL ASSY	TATA spare parts
220731990102	ASSY BRACKET (BUMPER SUPPORT)	TATA spare parts
220731990103	ASSY BUMPER WITH END COVER	TATA spare parts
220732100104	ASSY AXLE STOPPER LH	TATA spare parts
220732100105	ASSY AXLE STOPPER RH	TATA spare parts
220732100109	BRACKET ASSY BUMP STOPPER LH	TATA spare parts
220732100110	BRACKET ASSY BUMP STOPPER RH	TATA spare parts
220732100112	BRACKET ASSY FRONT SPRING	TATA spare parts
220732100114	AXLE STOPPER ASSY LH	TATA spare parts
220732100115	AXLE STOPPER ASSY RH	TATA spare parts
220732100119	BRACKET ASSY SPRING HANGER FRONT BS6	TATA spare parts
220732100120	FRONT SPRING ASSY	TATA spare parts
220732100121	1ST LEAF ASSY WITH BUSH	TATA spare parts
220732100123	BAR PIN BUSHING	TATA spare parts
220732100125	FRONT SPRING ASSY	TATA spare parts
220732100126	THRUPIN BUSHING	TATA spare parts
220732100129	BRACKET BUMP STOPPER ASSY BS6	TATA spare parts
220732100132	FRONT SPRING ASSY BS6	TATA spare parts
220732100138	FRONT SPRING ASSY BS6	TATA spare parts
220732100142	BRACKET BUMP STOPPER ASSY BS6	TATA spare parts
220732103201	CENTER BOLT BS6	TATA spare parts
220732103202	HEX FLANGE BOLT M24X3X175	TATA spare parts
220732103203	HEX BOLT M12X1.75X125 BS6	TATA spare parts
220732103205	CENTER BOLT BS6	TATA spare parts
220732103206	CENTER BOLT LEAF SPRING BS6	TATA spare parts
220732103301	BRACKET FRONT SPRING HANGER-REAR	TATA spare parts
220732103702	BRACKET SPRING HANGER	TATA spare parts
220732103707	CAP END CLOSURE	TATA spare parts
220732103710	BRACKET-FRONT SPRING MTG BS6	TATA spare parts
220732104203	SPRING CLIP	TATA spare parts
220732104204	SPRING CLIP	TATA spare parts



220732104205	SPRING CLIP BS6	TATA spare parts
220732106503	HEX NUT M12X1.75 BS6	TATA spare parts
220732107121	2ND LEAF	TATA spare parts
220732107122	3RD LEAF	TATA spare parts
220732107123	4TH LEAF	TATA spare parts
220732107124	5TH LEAF	TATA spare parts
220732107125	6TH LEAF	TATA spare parts
220732107126	7TH LEAF	TATA spare parts
220732107127	SPACER	TATA spare parts
220732107128	CASTER PLATE	TATA spare parts
220732107130	PLATE SHACKLE	TATA spare parts
220732107131	1ST LEAF	TATA spare parts
220732107132	2ND LEAF	TATA spare parts
220732107133	3RD LEAF	TATA spare parts
220732107134	4TH LEAF	TATA spare parts
220732107135	SPACER BS6	TATA spare parts
220732107142	CASTER PLATE BS6	TATA spare parts
220732107143	2ND LEAF BS6	TATA spare parts
220732107144	4TH LEAF BS6	TATA spare parts
220732107147	3RD LEAF BS6	TATA spare parts
220732107157	CENTER PAD (ASSEMBLY LEAF SPRING) BS6	TATA spare parts
220732108601	LINER BS6	TATA spare parts
220732108602	SPACER SPRING CLIP BS6	TATA spare parts
220732300101	ASSY SHOCK ABSORBER BRACKET TOP	TATA spare parts
220732300103	BRACKET ASSY SHOCK ABSORBER BS6	TATA spare parts
220732400104	REAR TANDEM BOGIE SUSP. COMP	TATA spare parts
220732400114	REAR BOGIE SUSPENSION ASSY	TATA spare parts
220732400134	BRACKET ASSY SPRING HANGER	TATA spare parts
220732400135	HANGER ASSY EQUALIZER BS6	TATA spare parts
220732400136	BEAM EQUALISING ASSY	TATA spare parts
220732400144	AXLE STOPPER ASSY	TATA spare parts
220732400146	RUBBER STOPPER ASSY	TATA spare parts
220732400147	SADDLE TOP	TATA spare parts
220732403213	HEX FLANGE BOLT	TATA spare parts
220732403214	HUCK SPIN BOLT PIN	TATA spare parts
220732403215	HEX FLANGE BOLT BS6	TATA spare parts
220732403216	HEX FLANGE BOLT M24X3X190	TATA spare parts
220732403711	BRACKET AXLE MTG FWD-LH	TATA spare parts
220732403712	BRACKET AXLE MTG FWD-RH	TATA spare parts
220732403713	BRACKET AXLE MTG RWD-LH	TATA spare parts
220732403714	BRACKET AXLE MTG RWD-RH	TATA spare parts
220732403724	SADDLE HANGER BKT	TATA spare parts
220732403725	END CAP	TATA spare parts
220732403726	BRACKET AXLE MTG FWD-LH	TATA spare parts
220732403727	BRACKET AXLE MTG FWD-RH	TATA spare parts
220732403728	BRACKET AXLE MTG RWD-LH	TATA spare parts
220732403729	BRACKET AXLE MTG RWD-RH	TATA spare parts

220732404801	DOWEL	TATA spare parts
220732406305	SPRING CONICAL PROGRESSIVE BS6	TATA spare parts
220732406504	HUCK SPIN COLLAR	TATA spare parts
220732406506	HEX FLANGE NUT M20X1.5	TATA spare parts
220732406903	CROSS TUBE	TATA spare parts
220732407112	PLATE BUMP STOPPER	TATA spare parts
220732407114	SPACER	TATA spare parts
220732408601	SPACER PLATE-ARTICULATION STOPPER	TATA spare parts
220732800103	CONNCTING LINK ASSY	TATA spare parts
220732803301	BRACKET ARB MTG (ON AXLE)	TATA spare parts
220732990101	KIT-PROGRESSIVE LOAD SPRING	TATA spare parts
220732990102	KIT-SADDLE CAP FASTNERS	TATA spare parts
220732990103	KIT-SHEAR & PROGRESSIVE LOAD SPRING	TATA spare parts
220732990104	KIT-SHEAR SPRING	TATA spare parts
220732990105	KIT-BAR PIN END & BUSHING WHEEL END	TATA spare parts
220732990106	KIT-EQUALIZING BEAM BUSHING	TATA spare parts
220732990107	KIT-CROSS TUBE & END PLUG	TATA spare parts
220733000101	ASSY.FRONT AXLE WITH BRAKES COMPLETE-LHD	TATA spare parts
220733000107	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
220733105101	FRONT AXLE BEAM	TATA spare parts
220740100102	ASSY TYRE TUBE & FLAP(11.00X20) MINE LUG	TATA spare parts
220740109901	TUBE REAR 11-20 LUG	TATA spare parts
220740109903	FLAP REAR 11-20 LUG	TATA spare parts
220740300101	ASSY SPACER PLATE(SPARE WHEEL MTG BKT)	TATA spare parts
220741108201	PROP. SHAFT GUARD	TATA spare parts
220741108202	GUARD PROPELLER SHAFT	TATA spare parts
220741110101	ASSY PROPELER SHAFT FRONT	TATA spare parts
220741120105	ASSY PROP. SHAFT-FRONT-RSB	TATA spare parts
220741120107	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
220741120110	ASSY PROP. SHAFT-FRONT-RSB (1200-CLOSED)	TATA spare parts
220741120111	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
220741120113	ASSY PROP.SHAFT (600 CLOSED)	TATA spare parts
220741120114	CROSS ASSY	TATA spare parts
220741120116	ASSY PROPSHAFT INTERAXLE(CL600/180 DIA)	TATA spare parts
220741120124	PROPELLER SHAFT ASSY REAR	TATA spare parts
220741120125	ASSY. PROPELLER SHAFT INTERAXLE BS3/4	TATA spare parts
220741120126	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
220741120127	LONG FORK ASSY	TATA spare parts
220741120128	SHORT FORK ASSY	TATA spare parts
220741124201	CLAMP	TATA spare parts
220741127701	BELLOW	TATA spare parts
220741208201	BRACKET	TATA spare parts
220741208202	CHANNEL(GUARD MTG )	TATA spare parts
220741990102	FLANGE YOKE	TATA spare parts
220742300122	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
220742300123	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
220743200103	SUB ASSY AIR TANK(15 LTR)70 MM BKT C.D	TATA spare parts

220743200104	ASSY BRACKET-RH(AIR TANK MTG FRONT)	TATA spare parts
220743200105	ASSY BRACKET-LH(AIR TANK MTG FRONT)	TATA spare parts
220743200106	ASSY BRACKET-RH(AIR TANK MTG REAR)	TATA spare parts
220743200107	ASSY BRACKET-LH(AIR TANK MTG REAR)	TATA spare parts
220743200108	BRACKET ASSY AIR TANK MTG BS6	TATA spare parts
220743200111	AIR TANK ASSY COMPLETE	TATA spare parts
220743200112	AIR TANK ASSY	TATA spare parts
220743700128	SPRING BRAKE ACTUATOR	TATA spare parts
220743700130	BRACKET ASSY FOR MODULATOR VALVE	TATA spare parts
220743700140	SPRING BRAKE ACTUATOR	TATA spare parts
220743700141	PRESSURE LIMITING VALVE	TATA spare parts
220743703301	BRACKET DDU MOUNTING	TATA spare parts
220743900105	ASSY.NYLON PIPE SET COMPLETE (VOSS)	TATA spare parts
220743900106	ASSY.NYLON PIPE SET COMPLETE (VOSS)	TATA spare parts
220743900109	ASSY.TUBE WITH CRIMPED R/HOSE(COMP.INLET)	TATA spare parts
220743900110	ASSY. COMPRESSOR 1ST PIPE WITH HOSE	TATA spare parts
220743900111	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
220743900112	ASSY. COMPRESSOR 3RD PIPE	TATA spare parts
220743900113	ASSY. COMPRESSOR 4TH PIPE	TATA spare parts
220743900114	ASSY. COMPRESSOR 5TH PIPE	TATA spare parts
220743900115	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
220743900116	ASSY.NYLON PIPE SET COMPLETE(VOSS)LHD	TATA spare parts
220743900126	ASSY. COATED CLAMP BIG (DIA 80)	TATA spare parts
220743900127	ASSY.NYLON PIPE SET COMPLETE (VOSS)	TATA spare parts
220743900128	ASSY. COMPRESSOR INLET PIPE	TATA spare parts
220743900130	ASSY.NYLON PIPE SET COMPLETE (VOSS)	TATA spare parts
220743900181	BUNCH ASSY PIPE	TATA spare parts
220743900223	PIPE METAL ASSY	TATA spare parts
220743900224	PIPE METAL ASSY	TATA spare parts
220743900227	NYLON PIPE BUNCH ASSY	TATA spare parts
220743903302	T-CONNEC.MOUNTING BRKT.(REAR FRONT AXLE)	TATA spare parts
220743903303	T-CONNEC.MOUNTING BRKT.(REAR REAR AXLE)	TATA spare parts
220743906801	ADAPTOR M22 X PIPE 25 OD	TATA spare parts
220743910103	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
220743910105	PIPE ASSY COMPRESSOR INLET	TATA spare parts
220746150106	KIT ASSY.PIPES & CONNECTORS	TATA spare parts
220746305102	PITMAN ARM	TATA spare parts
220746305103	PITMAN ARM	TATA spare parts
220746800105	SUCTION LINE HOSE ASSY.	TATA spare parts
220746800106	PRESSURE LINE HOSE ASSY.	TATA spare parts
220746800107	RETURN LINE HOSE ASSY.	TATA spare parts
220746800108	RETURN LINE HOSE ASSY.	TATA spare parts
220746800109	RETURN LINE HOSE ASSY.	TATA spare parts
220746800116	RETURN LINE ASSY	TATA spare parts
220746800126	PRESSURE LINE ASSY	TATA spare parts
220746990106	KIT-PIPE & ADAPTER	TATA spare parts
220747507102	REINFORCEMENT (FUEL TANK MTG)	TATA spare parts

220747600103	ASSY.TUBE WITH CRIMPED R/HOSE SUCTION PI	TATA spare parts
220747600104	ASSY.TUBE WITH CRIMPED R/HOSE RETURN PIP	TATA spare parts
220747600105	ASSY.TUBE WITH CRIMPED R/HOSE SUCTION PI	TATA spare parts
220747600106	ASSY.TUBE WITH CRIMPED R/HOSE RETURN PIP	TATA spare parts
220747600110	SUCTION PIPE (FUEL FILTER TO ENG)	TATA spare parts
220747600111	RETURN LINE ASSY ON TANK (ENG TO F/TANK)	TATA spare parts
220747600112	SUCTION PIPE ASSY (TANK TO FILTER)	TATA spare parts
220747700101	ASSY. HEAD & FUEL WATER SEPARATOR BS3/4	TATA spare parts
220747700102	ASSY. FUEL WATER SEPARATOR BS3/4	TATA spare parts
220747700103	FUEL FILTER (FWS) W/AUTO DRAIN BS3/4	TATA spare parts
220747700108	FUEL FILTER (FWS) ELEMENT SPINON BS3/4	TATA spare parts
220747700109	FUEL FILTER (FWS) SPINON TYPE BS3/4	TATA spare parts
220747700110	WATER SEPARATOR DRAIN VALVE ASY	TATA spare parts
220747709901	HEAD ASSEMBLY	TATA spare parts
220747709902	FUEL FILTER (FWS) ELEMENT SPINON BS3/4	TATA spare parts
220747709911	WATER SEPARATOR SENSOR ASSY	TATA spare parts
220749200101	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
220749200102	BRACKET ASSY EGP MTG	TATA spare parts
220749200103	BRACKET ASSY NOX SENSOR MTG	TATA spare parts
220749200106	ASSY INTERMEDIATE PIPE(WITH FLEXI CONNE)	TATA spare parts
220749200107	ASSY BRACKET-COMPL(NELSON MUFFLER MTG)	TATA spare parts
220749200114	ASSY. EXHAUST PIPE (TC MTG.) BS2/3/4	TATA spare parts
220749200115	EXHAUST BRAKE MTG BKT. (TC OULET)	TATA spare parts
220749208204	BRACKET-RH ( MUFFLER MTG.)	TATA spare parts
22075338000R40	60R_RESTRUCTURE_FOR_CVB_U_IN_APL_VIEW	TATA spare parts
220754100105	ASSY BATTERY CARRIER COMPLETE.	TATA spare parts
220754209907	INST CLST E-SPD(2.0)2523TC RA 6.83	TATA spare parts
220754209911	ELECTR SPEEDO MTR(1.82)24V 0-140KMPH	TATA spare parts
220754209912	TRIP E-SPEEDOMETER RATIO (0.78)	TATA spare parts
220754209914	ELECTR SPEEDO MTR(0.78)24V 0-140KMPH	TATA spare parts
220754209916	INST CLST ESPD(0.90) LPK 2523TC/38	TATA spare parts
220754241601	SPEEDOMETER (1:0.78)(BACKLIT) 24V	TATA spare parts
220754408204	ASSY TAIL LAMP MTG BKT	TATA spare parts
220754440101	ASSY LAMP 7-BANK WARN IND LPK-2523TC T/C	TATA spare parts
220754600103	WIRING HARNESS TAIL	TATA spare parts
220754600106	WIRING HARNESS ABS FRAME	TATA spare parts
220754600111	WIRING HARNESS MAIN	TATA spare parts
220754600112	WIRING HARNESS TAIL	TATA spare parts
220754601609	WIRING HARNESS ROOF	TATA spare parts
220754620102	W/H TAIL -LPK-2523TC/38 BSII	TATA spare parts
220754620113	WIRING HARNESS ROOF-NS CAB	TATA spare parts
220754660103	W/H-MAIN LPK-2523TC BS-II T/CAB	TATA spare parts
220754660104	W/H INST CONSOLE LPK-2523TC	TATA spare parts
220754660106	W/H-MAIN LPK-2523TC LHD T/CAB	TATA spare parts
220754660108	W/H-TAIL LPK-2523TC G-1150 T/C	TATA spare parts
220754660113	WIRING HARNESS ROOF	TATA spare parts
220754903301	BRACKET DC TO DC CONVERTER MTG BS6	TATA spare parts

220754904901	DCTODCCONVERTER BS6	TATA spare parts
220783500101	ASSY CONDENSER COMPLETE-LHD	TATA spare parts
220787000101	ASSY KIT COMPL-16CUM BOX BODY & HYD TIP	TATA spare parts
220787000103	ASSY KIT COMPL-14CUM-SCOOP & HYD TIPPING	TATA spare parts
220787100101	ASSY SUB FRAME	TATA spare parts
220787100106	ASSY SUB-FRAME(14CUM-SCOOP)	TATA spare parts
220787300101	ASSY.TIPPING BODY COMPLETE-16 CUM BOX	TATA spare parts
220787300102	ASSY. TIPPING BODY COMPLETE(14CUM SCOOP)	TATA spare parts
22079138100R40	ASSEMBLY BODY FITTED	TATA spare parts
220924200103	ASSY BRACKET RH. ENG MTG TOP	TATA spare parts
220924200104	ASSY BRACKET LH ENG MTG TOP	TATA spare parts
220924200105	ASSY BRACKET ENG. MTG REAR RH	TATA spare parts
220928400102	ASSY LEVER (AGB SHIFTING)	TATA spare parts
220928450101	ASSY. MTG. BKT. REAR(AGB PULL CABLE )	TATA spare parts
220929100107	ASSY.HYD.PIPE (M/CYL TO BOOSTER)	TATA spare parts
220929100108	ASSY.HYD.PIPE(M/CYL.TO BOOSTER)	TATA spare parts
220930100107	ASSY.PULL CABLE ACCELERATOR	TATA spare parts
220930100108	ASSY.ACCELERATOR PEDAL WITH RUBBER COVER	TATA spare parts
220931000105	ASSY FRAME COMPLETE-LPA1415	TATA spare parts
220931200108	ASSY SUPPORT- ENG X-MEMBER REAR-RH	TATA spare parts
220931200109	ASSY SUPPORT- ENG X-MEMBER REAR-LH	TATA spare parts
220931200110	ASSY. CROSS MEMBER	TATA spare parts
220931207113	SUPPORT- FRT ENG X-MEMBER(FRONT)- RH	TATA spare parts
220931207114	SUPPORT- FRT ENG X-MEMBER(FRONT)- LH	TATA spare parts
220931207115	SUPPORT-FRT ENG X-MEMBER(REAR) - RH	TATA spare parts
220931207116	SUPPORT-FRT ENG X-MEMBER(REAR) - LH	TATA spare parts
220931207120	FRONT GUSSET	TATA spare parts
220932100103	ASSY BUMP STOPPER BRACKET-LH	TATA spare parts
220932100104	ASSY BUMP STOPPER BRACKET-RH	TATA spare parts
220932100105	ASSY FRONT SPRING	TATA spare parts
220932104201	U BOLT	TATA spare parts
220932107102	CASTER PLATE	TATA spare parts
220932300101	ASSY BRACKET SHOCK ABSORBER (TOP)	TATA spare parts
220932404201	U CLAMP (LENGTH-465)	TATA spare parts
220932407103	SPACER B/W AXLE AND REAR SPRING	TATA spare parts
220932803301	BRACKET ANTIROLL BAR ON AXLE-LH	TATA spare parts
220941100106	ASSY. PROP SHAFT COMPLETE. (GB TO AGB)	TATA spare parts
220941100106AE	ASSY.PROP SFT CMPL(GB T AGB-1415	TATA spare parts
220941100107	ASSY. PROP SHAFT COMPLETE. (AGB TO RA)	TATA spare parts
220941100107AE	ASSY PROP SFT COMP(AGB T RA-1415	TATA spare parts
220941120105	ASSY. PROP SHAFT COMPLETE. (AGB TO FA)	TATA spare parts
220941120105AE	ASSY PROP SFT COMP(AGB T FA-1415	TATA spare parts
220943200103	ASSY. AIR TANK (20L)	TATA spare parts
220943900107	SET ASSY. NYL PIPE 1415/42 TC-VOSS BSII	TATA spare parts
220943900107AE	SET NYL PIPE TC-VOSS BSII -1415	TATA spare parts
220943900109	ASSY SECOND PIPE (DIA 18) WITH O RING LP	TATA spare parts
220943900110	ASSY THIRD PIPE (DIA 18) WITH O RING LP1	TATA spare parts

220946100103	ASSY.BRACKET STEERING G/B MTG.	TATA spare parts
220946100105	ASSY. DRAG LINK	TATA spare parts
220946100106	ASSY HOSE CRIMPED - PRESSURE LINE (STG.	TATA spare parts
220946100107	ASSY HOSE CRIMPED - SUCTION LINE (STG. T	TATA spare parts
220946100108	ASSY HOSE CRIMPED - RETURN LINE (STG GB	TATA spare parts
220946100109	DRAG LINK ASSY (SEALED TYPE)	TATA spare parts
220947900102	HOSE ASSY-MAIN LINE	TATA spare parts
220947900104	HOSE ASSY-RETURN LINE	TATA spare parts
220949100104	ASSY SECOND EXHAUST PIPE	TATA spare parts
220949100105	ASSY. EXHAUST PIPE (2ND PIPE) LHD	TATA spare parts
220949100106	SUPPORT BRACKET (EXHAUST BRAKE)	TATA spare parts
220949100107	ASSY SILENCER NT6-A WITH TAIL PIPE	TATA spare parts
220949100111	ASSY PIPE (INTERMEDIATE TO SILENCER)	TATA spare parts
220949208207	EXHAUST BRACKET	TATA spare parts
220949208208	EXHAUST BRACKET	TATA spare parts
220949208209	EXHAUST BRACKET	TATA spare parts
220949208212	EXHAUST BRACKET	TATA spare parts
220949208213	EXHAUST BRACKET	TATA spare parts
220954660106	W/H MAIN FOR LPO1415TC 4X4	TATA spare parts
220954660106AE	W/H MAIN FOR LPO1415TC 4X4 1415	TATA spare parts
220960100101SJ	ASSY. COWL COMP. WITH FITMENTS W/O FACE	TATA spare parts
220960100102	ASSY. COWL SHELL PAINTED W/O FACE LHD	TATA spare parts
220960100113	ASSY BRACKET FRONT MTG (AGB PULL CABLE)	TATA spare parts
220981800101	ASSY TATA 1415 C MASCOT	TATA spare parts
220988500101	ASSY BRACKET LH (BUMPER MTG)	TATA spare parts
220988500102	ASSY BRACKET-RH (BUMPER MTG.)	TATA spare parts
220988500103	ASSY. BUMPER (STRAIGHT)	TATA spare parts
220989100101	ASSY. OUTRIGGER RH (COWL MTG FRONT)	TATA spare parts
220989100102	ASSY. OUTRIGGER LH (COWL MTG FRONT)	TATA spare parts
220989100103	ASSY. BRACKET (COWL MTG REAR)	TATA spare parts
220989107701	PACKING REAR (COWL MTG)	TATA spare parts
2210-C-C055	CAM SHAFT RH FWD (4923)	TATA spare parts
2210-D-C056	CAM SHAFT LH FWD (4923)	TATA spare parts
2210-D-C211	CAM SHAFT LH REAR (4923)	TATA spare parts
2210-E-C212	CAM SHAFT RH REAR (4923)	TATA spare parts
2210-U-C099	CAM SHAFT RH REAR (2518)	TATA spare parts
2210-V-C100	CAM SHAFT LH REAR (2518)	TATA spare parts
221020440001	FRONT HEADER CENTER	TATA spare parts
221270808201	PACKING FOR U BOLT	TATA spare parts
221270900116	ASSY SUPD LH	TATA spare parts
221270900117	ASSY SUPD RH	TATA spare parts
221270900171	ASSEMBLY SUPD LH (SPOT WELDED)	TATA spare parts
221270900172	ASSEMBLY SUPD RH (SPOT WELDED)	TATA spare parts
221270900177	SUPD ASSY LH	TATA spare parts
221270900178	SUPD ASSY RH	TATA spare parts
221270900183	SUPD ASSY LH	TATA spare parts
221270900184	SUPD ASSY RH	TATA spare parts

221270907102	PLATESUPD MTG ON CHASIS	TATA spare parts
221270907103	PLATE SUPD MTG ON CHASIS	TATA spare parts
221270907701	PACKING PAD BS6	TATA spare parts
221270908219	BKT. SUPD MTG ON CHASSIS	TATA spare parts
221270908220	BKT. SUPD MTG ON CHASSIS	TATA spare parts
221270918231	SEAL	TATA spare parts
221270990106	SUPD KIT	TATA spare parts
221270990113	SUPD KIT FOT LPT2518_62WB	TATA spare parts
221270990116	SUPD KIT FOR LPT2521/48WB/BS-IV.	TATA spare parts
221344009901	PUMP ASSY AXIAL PISTON PUMP	TATA spare parts
221370000133	ASSY LOAD BODY COMPLETE	TATA spare parts
221370000139	ASSY LOADBODY COMPLETE	TATA spare parts
221370306305	RETRO REFLECTIVE TAPE BS6	TATA spare parts
221370400101	ASSEMBLY TAIL GATE	TATA spare parts
221370406301	RETRO REFLECTIVE TAPE RED 2080 LG	TATA spare parts
221370900154	ASSEMBLY SUPD LH (LPT 1613/1616 42 WB)	TATA spare parts
221370900155	ASSMEBLY SUPD RH	TATA spare parts
221370900156	ASSEMBLY SUPD LH (LPT 1613/1615 48 WB)	TATA spare parts
221370900157	ASSEMBLY SUPD RH (LPT 1613/1615 48 WB)	TATA spare parts
221370900160	SUPD ASSY RH	TATA spare parts
221370900161	SUPD ASSY LH	TATA spare parts
221370900188	ASSY. SUPD LH(SE 1613 697BSII)	TATA spare parts
221370900189	ASSY. SUPD RH (SE 1613 697BSII)	TATA spare parts
221370900201	ASSEMBLY SUPD LH (SPOT WELDED)	TATA spare parts
221370900202	ASSEMBLY SUPD RH (SPOT WELDED)	TATA spare parts
221370910107	SUPD ASSY LH	TATA spare parts
221370910108	SUPD ASSY RH	TATA spare parts
221370990118	KIT ASSY SUPD	TATA spare parts
221370990119	KIT-DRIVE AWAY SUPD	TATA spare parts
221370990120	SUPD KIT FOR LPT 1613/1616(52 WB)	TATA spare parts
221470000112	ASSY. LOADBODY COMPLETE	TATA spare parts
221470100104	ASSY. SPRAY SUPPRESSION SUPPORT	TATA spare parts
221470100165	ASSY SUPD 64WB LH	TATA spare parts
221470100166	ASSY SUPD 64WB RH	TATA spare parts
221470100167	ASSY SUPD -LH 52WB	TATA spare parts
221470100168	ASSY SUPD-RH 52WB	TATA spare parts
221470100171	ASSY SUPD MOUNTING BRACKET	TATA spare parts
221470100174	SUPD ASSY LH	TATA spare parts
221470100175	SUPD ASSY RH	TATA spare parts
221470108223	SPRAY SUPPRESSION MTG. BRACKET LH	TATA spare parts
221470108224	SPRAY SUPPRESSION MTG. BRACKET RH	TATA spare parts
221470118201	SPRAY SUPPRESION SIDE COVER(LH)-REAR FOR	TATA spare parts
221470118202	SPRAY SUPPRESION SIDE COVER(LH)-FRONT FO	TATA spare parts
221470118203	SIDE COVER SPRAY SUPPRESSION (RH)-REAR SI	TATA spare parts
221470118204	SIDE COVER SPRAY SUPPRESSION(RH)-FRONT SI	TATA spare parts
221470128212	FRONT PLATE SPRAY SUPPRESSION LH	TATA spare parts
221470128213	SPRAY SUPPRESSION RH	TATA spare parts

221470805001	MTG CLEAT	TATA spare parts
221470805002	RESILIENCE MTH BKT (BOTTOM)	TATA spare parts
221470805003	RESILIENCE MTG BKT (TOP)	TATA spare parts
221470805004	RESILIENCE MTG BKT	TATA spare parts
221470805005	RESILIENCE MTG BKT	TATA spare parts
221470805006	RESILIENCE MTG BKT	TATA spare parts
221470805007	RESILINSE MTG BKT	TATA spare parts
221470805008	RESILINSE MTG BKT	TATA spare parts
221470807701	BALATA PACKING	TATA spare parts
221470808701	COMPRESSION SPRING RESILIENCE MOUNTING	TATA spare parts
221470809202	WASHER LOADBODY MOUNTING	TATA spare parts
221470900119	SUPDASSY LH	TATA spare parts
221470900120	SUPDASSY RH	TATA spare parts
221470905309	FOAM PACKING BS6	TATA spare parts
221470905310	FOAM PACKING BS6	TATA spare parts
221470905311	FOAM PACKING BS6	TATA spare parts
221470905313	FOAM PACKING BS6	TATA spare parts
221470906301	MUDFLAP SPRAY SUPPRESSION	TATA spare parts
221470906306	SIDE FLAP COVER SIDE GUARD SPRAY SUPPRESS	TATA spare parts
221487109970	PUSH IN ELBOW	TATA spare parts
221570100114	ASSY SUPD LH	TATA spare parts
221570100116	SUPD ASSEMBLY LH	TATA spare parts
221570100117	SUPD ASSEMBLY RH	TATA spare parts
221570100119	ASSY SUPD RH	TATA spare parts
221570100120	ASSY SUPD SINGLE	TATA spare parts
221744103306	AIR VALVE MOUNTING BRACKET	TATA spare parts
221744103307	AIR VALVE MOUNTING BRACKET SHS70X70X2 55	TATA spare parts
221744103308	BRACKET AIR VALVE MTG BS6	TATA spare parts
221744107101	AIR CONTROL VALVE MOUNTING PLATE (RETRO)	TATA spare parts
221744109005	AIR CONTROL VALVE	TATA spare parts
221744109901	GREASE NIPPLE 1/8INCH BSP	TATA spare parts
221744109905	ADAPTOR M33X2X1*7/16INCH UNF	TATA spare parts
221744109906	ADAPTOR M22X1.5X1 3/16INCH UNF	TATA spare parts
221744109910	ADAPTOR 1/2INCH BSP(M)X3/4INCH BSP	TATA spare parts
221744109911	ADAPTOR 1/2INCH BSP(M)X3/4INCH BSP	TATA spare parts
221744109912	ELBOW 1 1/2INCH BSP(M)XM1 1/2INCH	TATA spare parts
221744400101	AIR BREATHER ASSEMBLY	TATA spare parts
221744400102	CYL.ASSY.	TATA spare parts
221744400104	OIL TANK ASSY - BOTTOM OUTLET	TATA spare parts
221744400105	OIL TANK ASSY	TATA spare parts
221744400109	S5LT SCISSOR TIPPING ASSLY(WITHOUT CYL.)	TATA spare parts
221744403201	CYLINDER MOUNTING BOLT M16 X 60	TATA spare parts
221744403302	CYLINDER MOUNTING BRACKET	TATA spare parts
221744403303	LIFTING BKT RH 129 IGUS BUSH	TATA spare parts
221744403304	LIFTING BKT LH 129 IGUS BUSH	TATA spare parts
221744404601	PTO	TATA spare parts
221744405001	ASSY CYLINDER - TIP TRAILER	TATA spare parts



221744405002	BASE	TATA spare parts
221744405003	STAGE	TATA spare parts
221744405004	STAGE	TATA spare parts
221744405005	STAGE	TATA spare parts
221744405006	STAGE	TATA spare parts
221744405007	TIPPING CYL	TATA spare parts
221744405009	TIPING CYLINDER	TATA spare parts
221744405010	TIPPING CYLINDER	TATA spare parts
221744405011	STAGE 1510-SHP-HC	TATA spare parts
221744405016	TIPPING CYLINDER	TATA spare parts
221744405401	GEAR PUMP	TATA spare parts
221744405801	HOSE OIL TANK TO HYD CYLINDER	TATA spare parts
221744405802	HOSE 2000	TATA spare parts
221744405803	HOSE 1500	TATA spare parts
221744405804	HOSE 1IN ID X1150 R1 1 7/16 UNF	TATA spare parts
221744405805	HOSE 1INCH I.D X 1100R2 1 7/16INCH UNF	TATA spare parts
221744405806	HOSE 3/4INCH I.D X 2400R2 1 3/16INCH U	TATA spare parts
221744405807	HOSE 3/4INCH IDX2600 R2 1*3/16INCH	TATA spare parts
221744405808	HOSE 1INCH IDX1500 R1 1*7/16INCH UNF	TATA spare parts
221744406801	OIL LEVEL INDICATOR 1/1/4 INCHBSP	TATA spare parts
221744406802	RLF ELEMENT	TATA spare parts
221744406803	AIR BREATHER FILTER ELEMENT	TATA spare parts
221744406804	OIL LEVEL INDICATOR 1*1/4INCH BSP	TATA spare parts
221744407104	BOTTOM PLATE	TATA spare parts
221744407105	LOCKING PLATE	TATA spare parts
221744407106	THRUST PLATE	TATA spare parts
221744407801	SHAFT SEAL 42X55X6(BLACK PUMP)	TATA spare parts
221744407802	SHAFT SEAL BA 24X40X7	TATA spare parts
221744407803	SHAFT SEAL BAU 24X40X7	TATA spare parts
221744407901	DRIVE GEAR	TATA spare parts
221744407902	DRIVEN SHAFT	TATA spare parts
221744408601	CYLINDER MOUNTING SPACER	TATA spare parts
221744408702	RELIEF VALVE SPRING - 3DHMP VALVE	TATA spare parts
221744409001	AIR CONTROL VALVE	TATA spare parts
221744409002	BALL VALVE 1_1/2IN BSP LP	TATA spare parts
221744409003	VALVE MOUNTING BLOCK	TATA spare parts
221744409901	SLIDER	TATA spare parts
221744409902	SLIDER	TATA spare parts
221744409903	SLIDER	TATA spare parts
221744409904	LIFTRING	TATA spare parts
221744409905	LIFTRING	TATA spare parts
221744409914	SLIDER TYPE 072(2 X 1/2)	TATA spare parts
221744409915	LIFTRING TYPE 091	TATA spare parts
221744409917	SLIDER TYPE	TATA spare parts
221744409918	STOPRING TYPE	TATA spare parts
221744409919	INNER STOPRING TYPE	TATA spare parts
221744409920	INNER STOPRING TYPE	TATA spare parts

221744409926	AIR BREATHER FILTER HOUSING	TATA spare parts
221744409931	AIR BREATHER SLEEVE/ STRAINER	TATA spare parts
221744909909	HOSE	TATA spare parts
221744909910	HOSE	TATA spare parts
221744909911	HOSE	TATA spare parts
221744909912	HOSE	TATA spare parts
221744909913	HOSE	TATA spare parts
221744909914	HOSE	TATA spare parts
221744909915	HOSE	TATA spare parts
221744909916	HOSE	TATA spare parts
221744909917	HOSE	TATA spare parts
221744909918	HOSE	TATA spare parts
221744909919	HOSE	TATA spare parts
221744909920	HOSE	TATA spare parts
221744909921	HOSE	TATA spare parts
221744909922	O-RING	TATA spare parts
221744909923	O-RING	TATA spare parts
221744909924	O-RING	TATA spare parts
221744909925	AIR BREATHER ASSY	TATA spare parts
221744909926	HYD TANK	TATA spare parts
221744909928	UNDER BODY VALVE	TATA spare parts
221744909929	RETURN FILTER	TATA spare parts
221744909930	STRAINER FILTER	TATA spare parts
221744909931	FLOW CONTROL VALVE	TATA spare parts
221744909932	3-SPOOL VALVE	TATA spare parts
221744909933	EJECTOR CYLINDER	TATA spare parts
221744909934	KIT-EJECTOR CYLINDER SEAL	TATA spare parts
221744909935	TAILGATE CYLINDER	TATA spare parts
221744909936	KIT-TAILGATE CYLINDER SEAL	TATA spare parts
221744909937	SLIDER CYLINDER	TATA spare parts
221744909938	KIT-SLIDER CYLINDER SEAL	TATA spare parts
221744909939	PACKER CYLINDER	TATA spare parts
221744909940	KIT-PACKER CYLINDER SEAL	TATA spare parts
221744909941	BINLIFTER CYLINDER	TATA spare parts
221744909942	KIT-BINLIFTER CYLINDER SEAL	TATA spare parts
221744909943	LEVEL INDICATOR	TATA spare parts
221744909944	HOSE	TATA spare parts
221744909945	RETURN FILTER	TATA spare parts
221744909947	FACE SHEET	TATA spare parts
221744909948	WEAR PLATE	TATA spare parts
221744909949	EJECTOR PIN CYLINDER	TATA spare parts
221744909950	BINLIFTER ASSY WITH CYLINDER BRACKET	TATA spare parts
221744909951	BINLIFTER SIDEARM	TATA spare parts
221744909952	CAM	TATA spare parts
221744909953	STOPPER PLATE	TATA spare parts
221744909954	SQUARE BAR	TATA spare parts
221744909955	CYLINDER MOUNTING PROFILE	TATA spare parts

221744909956	RECTANGULAR PIPE	TATA spare parts
221744909957	LIFTER HOOK	TATA spare parts
221744909958	COMB	TATA spare parts
221744909959	BINLIFTER ARM	TATA spare parts
221744909960	ROUND BAR	TATA spare parts
221744909961	ARM PIN SUPORT	TATA spare parts
221744909962	BINLIFTER PIPE	TATA spare parts
221744909963	BINLIFTER ARM PIN	TATA spare parts
221744909964	BINLIFTER ARM NUT	TATA spare parts
221744909965	BINLIFTER ARM PIN PROFILE	TATA spare parts
221744909966	PACKER ASSY	TATA spare parts
221744909967	PACKER PLATE 20 MM PROFILE	TATA spare parts
221744909968	PACKER PLATE 20 MM PROFILE	TATA spare parts
221744909969	SHOE BLOCK	TATA spare parts
221744909970	MALE ASSY	TATA spare parts
221744909971	PACKER PLATE 25 MM PROFILE	TATA spare parts
221744909972	FEMALE ASSY	TATA spare parts
221744909973	CHECK VALVE	TATA spare parts
221744909974	BALL VALVE	TATA spare parts
221744909975	BUSH	TATA spare parts
221744909976	PLATE	TATA spare parts
221744909977	ANGLE	TATA spare parts
221744909978	WASHER	TATA spare parts
221744909979	SUPPORT	TATA spare parts
221744909980	PLATE	TATA spare parts
221744909981	ANGLE	TATA spare parts
221744909982	PIN	TATA spare parts
221744909983	ROLLER	TATA spare parts
221744909984	WASHER	TATA spare parts
221744909985	PIN	TATA spare parts
221744909986	SPRING	TATA spare parts
221744909987	SPRING	TATA spare parts
221744909988	PLATE	TATA spare parts
221744909989	PLATE	TATA spare parts
221744909990	PLATE	TATA spare parts
221744909991	PLATE	TATA spare parts
221744909992	PLATE	TATA spare parts
221744990102	SPARE SEAL KIT	TATA spare parts
221744990103	SPARE SEAL KIT HYD.CYLINDER	TATA spare parts
221744990105	SEAL KIT FOR GEAR PUMP	TATA spare parts
221744990106	COMPLETE SEAL KIT(O-RINGS GREASE ETC)	TATA spare parts
221744990107	REPAIR KIT 3DHMP VALVE	TATA spare parts
221744990108	RLF SEAL KIT	TATA spare parts
221744990109	COMPLETE PACKSET	TATA spare parts
221744990110	PACKSET FOR STAGE DIA	TATA spare parts
221744990111	PACKSET FOR STAGE DIA	TATA spare parts
221744990112	PACKSET FOR STAGE DIA	TATA spare parts

221744990113	SEAL KIT	TATA spare parts
221744990114	SEAL KIT	TATA spare parts
221744995302	GASKET (PTO)	TATA spare parts
221744997801	SPARE SEAL KIT	TATA spare parts
221744999001	SPARE SEAL KIT	TATA spare parts
221754304901	STARTING RELAY 12 V	TATA spare parts
221754304902	COIL 12 V	TATA spare parts
221754504901	PENDANT SWITCH	TATA spare parts
221781074702	COVER TUBE S/A	TATA spare parts
221787000102	ASSY LOADBODY COMPLETE	TATA spare parts
221787000104	REAR HINGE BODY BRACKET ASSLY.	TATA spare parts
221787000105	SUBFRAME ASSEMBLY 12/14STD	TATA spare parts
221787000107	SUBFRAME ASSEMBLY 14 RIBLESS	TATA spare parts
221787000114	TAILDOOR ASSEMBLY 6 RIBLESS	TATA spare parts
221787000120	TAIL DOOR LOCKING MECHANISM	TATA spare parts
221787000123	TIE ROD ASSY	TATA spare parts
221787005101	AXLE ASSY	TATA spare parts
221787008206	CHASIS BRACKET (2 NO.)	TATA spare parts
221787009001	CONTROL VALVE	TATA spare parts
221787100103	EQUILIZER ASSEMBLY	TATA spare parts
221787100104	HANGER ASSEMBLY	TATA spare parts
221787100105	LEAF SPRING ASSY. 80 X 13X 14L	TATA spare parts
221787100106	PIVOT BRACKET ASSEMBLY	TATA spare parts
221787100107	ASSY SIDE BOARD	TATA spare parts
221787100108	ASSY FLOOR	TATA spare parts
221787100109	ASSY HEAD BOARD	TATA spare parts
221787100110	TIE ROD WITH YOKE	TATA spare parts
221787100123	BUSH ASSY	TATA spare parts
221787100127	HOOK ASSEMBLY RH	TATA spare parts
221787100130	SUBFRAME ASSEMBLY	TATA spare parts
221787100136	PISTON ASSY.	TATA spare parts
221787100137	PISTON ASSY.	TATA spare parts
221787100138	SERVO SLEEVE ASSY.	TATA spare parts
221787100139	CONTROL VALVE ASSY.	TATA spare parts
221787100140	FILTER COMPLETE	TATA spare parts
221787100142	PRESSURE HOSE ASSY. (3/4 IN IDX850L)	TATA spare parts
221787100143	CYLINDER MOUNTING CRADLE ASSEMBLY	TATA spare parts
221787100144	BODY LOCK ASSEMBLY (LARGE)	TATA spare parts
221787100146	RETURN LINE FILTER ASSY.	TATA spare parts
221787100147	SPARE COMPLETE TANK	TATA spare parts
221787100164	CYLINDER (WELDED TYPE)	TATA spare parts
221787100165	REAR END ASSEMBLY WITH 'O'-RING & BACK U	TATA spare parts
221787100166	TANK ASSEMBLY	TATA spare parts
221787100167	BODY LOCK ASSEMBLY	TATA spare parts
221787100174	HOSE ASSLY 950 LONG	TATA spare parts
221787100183	GBS 40 PARALLAL AXIS PTO	TATA spare parts
221787100186	HYDROLIC JACK PISTON NO-2	TATA spare parts

221787100187	HRDROLIC JACK PISTON NO-3	TATA spare parts
221787100188	RETURN LINE FILTER ASSY 140 L	TATA spare parts
221787100190	TUBE SUB ASSEMBLY	TATA spare parts
221787100191	PISTON 1 ASSEMBLY	TATA spare parts
221787100192	PISTON 2 ASSEMBLY	TATA spare parts
221787100193	PISTON 3 ASSEMBLY	TATA spare parts
221787100198	BRACKET DINARM ASSLY LH	TATA spare parts
221787100199	BRACKET DINARM ASSLY RH	TATA spare parts
221787103003	NEEDLE BEARING	TATA spare parts
221787103004	BEARING SPHERICAL	TATA spare parts
221787103008	BALL 7/32 IN	TATA spare parts
221787103101	SPHERICAL BEARING	TATA spare parts
221787103102	BEARING	TATA spare parts
221787103103	BEARING	TATA spare parts
221787103106	T-METALLIC PISTON BRG (DIA 91)	TATA spare parts
221787103107	T-METALLIC PISTON BRG (DIA 110)	TATA spare parts
221787103109	S-T-METALLIC PISTON BRG (DIA 91)	TATA spare parts
221787103110	S-T-METALLIC PISTON BRG (DIA 110)	TATA spare parts
221787103114	6208ZZ BEARING 715-368	TATA spare parts
221787103115	302010 BEARING 715-330	TATA spare parts
221787103116	NKI50/35 BEARING 715-350I	TATA spare parts
221787103117	NKI55/35 BRG 715-355I	TATA spare parts
221787103118	IR50/25 BEARING 715-3R502	TATA spare parts
221787103119	BEARINGç 6001	TATA spare parts
221787103120	BEARING	TATA spare parts
221787103201	U-BOLT	TATA spare parts
221787103202	U-BOLT - LOCATOR	TATA spare parts
221787103209	U-BOLT	TATA spare parts
221787103215	M12 X 75 LG BOLT	TATA spare parts
221787103216	M8 X 15 LG.ç BOLT	TATA spare parts
221787103218	BOLT FRONT PIVOT	TATA spare parts
221787103219	M8X1.25- 20L HEX HEAD BOLT	TATA spare parts
221787103305	HEX BOLT M10X30 -10.9	TATA spare parts
221787103306	CYLINDER MOUNTING BRACKET	TATA spare parts
221787103307	CYLINDER LIFTING BRACKET LH	TATA spare parts
221787103308	CYLINDER LIFTING BRACKET RH	TATA spare parts
221787103309	MOUNTING BRACKET-LEFT	TATA spare parts
221787103310	MOUNTING BRACKET-RIGHT	TATA spare parts
221787103311	BOTTOM MOUNTING BRACKET	TATA spare parts
221787103312	BRACKET AIR VALVE MTG BS6	TATA spare parts
221787103317	BRACKET	TATA spare parts
221787103403	CHASSIS BUSH	TATA spare parts
221787103405	BUSH	TATA spare parts
221787103406	IGUS BUSH GSM 6065-40	TATA spare parts
221787103415	BUSH	TATA spare parts
221787103416	BODY PROP BUSH	TATA spare parts
221787103417	HOPPER FULCRUM BUSH	TATA spare parts

221787103418	CYLINDER TOP PROFILE BUSH	TATA spare parts
221787103419	CYLINDER BOTTOM PROFILE BUSH	TATA spare parts
221787103501	BOSS/30X30X20	TATA spare parts
221787103701	ADJUSTABLE TORQUE ARM	TATA spare parts
221787103702	RIGID TORQUE ARM	TATA spare parts
221787103703	CAM	TATA spare parts
221787103704	T-ADAPTER	TATA spare parts
221787103712	AIR CLEANER ASSLY	TATA spare parts
221787103713	CYL HEAD SUB ASSY WITH VALVES	TATA spare parts
221787103716	MAST CABLE GUIDE ASSY	TATA spare parts
221787103716AE	MAST CABLE GUIDE ASSY. 2523	TATA spare parts
221787103717	ROPE TENSIONER ASSY	TATA spare parts
221787103717AE	ROPE TENSIONER ASSY. 2523	TATA spare parts
221787103718	OUTBOARD LEG SHOW ASSY LPTA 1828	TATA spare parts
221787103718AE	O/B/L SHOW ASSY/7 TON LRV-2523	TATA spare parts
221787103730	HOUSING	TATA spare parts
221787103731	HEAD END COVER	TATA spare parts
221787104101	TOW BAR ASSY	TATA spare parts
221787104102	SNATCH BLOCK	TATA spare parts
221787104206	CLAMP	TATA spare parts
221787104207	VINLY DIPPED CLAMP ) DES TO SUIT 3/4INCH	TATA spare parts
221787104208	L-CLAMP	TATA spare parts
221787104212	BODY LOCK S/A	TATA spare parts
221787104217	CLAMP SINGLE RAIL MNTD	TATA spare parts
221787104218	PIPE CLAMP	TATA spare parts
221787104219	L - CLAMP	TATA spare parts
221787104220	VINYL DIPPED CLAMP	TATA spare parts
221787104301	CIRCLIP GE 50 DO	TATA spare parts
221787104304	CIRCLIP 30I UNI 7437	TATA spare parts
221787104305	CIRCLIP 28I UNI 7437	TATA spare parts
221787104702	COVER TUBE FLANGE S/A	TATA spare parts
221787104704	PLASTIC COVER	TATA spare parts
221787104705	INTAKE COVER 230-104-01	TATA spare parts
221787104706	8.5 EXHAUST CVR S 230-117	TATA spare parts
221787104707	8.5 EXHAUST CVR H 230-117-1	TATA spare parts
221787104708	COVER RCA	TATA spare parts
221787104901	ELECTIRCAL WIRING HARNESS	TATA spare parts
221787104902	SIDE INDICATOR	TATA spare parts
221787104903	REAR SEARCH LIGHT	TATA spare parts
221787104905	POWER CABLE	TATA spare parts
221787104906	2 BUTTON SWITCH (TYPE- ON/OFF)	TATA spare parts
221787104907	CONDENER CORE	TATA spare parts
221787104908	SOLENOID VALVE	TATA spare parts
221787104909	AXIAL FAN	TATA spare parts
221787104910	RD BOTTLE	TATA spare parts
221787104911	EVAPORATOR COIL	TATA spare parts
221787104912	THERMOSTATIC EXPANSION VALVE	TATA spare parts

221787104913	BLOWER FAN	TATA spare parts
221787104914	TEMPERATURE SENSORS	TATA spare parts
221787104915	SOLENOID VALVE	TATA spare parts
221787104916	COMPRESSOR	TATA spare parts
221787104917	COMPRESSOR MOUNTING BRACKET	TATA spare parts
221787104918	CONTROL PANEL	TATA spare parts
221787104919	RELAY BOX	TATA spare parts
221787104920	WIRING HARNESS	TATA spare parts
221787104921	INTERNAL LAMP + SWITCH	TATA spare parts
221787105001	TARPAULIN HOOK	TATA spare parts
221787105101	CLUTCH (BOTH SIDE JAW CUT)	TATA spare parts
221787105102	CLUTCH COLLAR HALF	TATA spare parts
221787105201	DUST COVER	TATA spare parts
221787105202	END CAP FOR CHASSI BRACKET	TATA spare parts
221787105203	DUST COVER (WITH STICKER)	TATA spare parts
221787105204	END CAP FOR CHASSIS BRACKET	TATA spare parts
221787105205	DUST COVER	TATA spare parts
221787105401	CLUTCH PINION	TATA spare parts
221787105402	WORM WHEEL WITH CI CENTER	TATA spare parts
221787105403	WORM SHAFT	TATA spare parts
221787105404	WORM DRIVE GEAR	TATA spare parts
221787105405	WORM DRIVE PINION	TATA spare parts
221787105406	TRANSMISSION PINION	TATA spare parts
221787105407	EXTERNAL GEAR	TATA spare parts
221787105408	INTERNAL GEAR	TATA spare parts
221787105802	HOSE 3/4INCHI.D X 1800 SAE100R2	TATA spare parts
221787105804	HOSE 1INCHI.DX1500 R1 1 7/16INCHUNF	TATA spare parts
221787105805	FUEL HOSE	TATA spare parts
221787105806	FUEL HOSE	TATA spare parts
221787105807	HOSE	TATA spare parts
221787105808	HOSE	TATA spare parts
221787105809	HOSE	TATA spare parts
221787105810	HOSE	TATA spare parts
221787105811	HOSE	TATA spare parts
221787105814	PR. HOSE (3/4IN IDX2200L)	TATA spare parts
221787105815	SUCITON HOSE (1 IN IDX1140L)	TATA spare parts
221787105817	SLUMMER HOSE (1/2IN ID)	TATA spare parts
221787105818	RLFEXTENSIONPIPE170L	TATA spare parts
221787105819	HOSE 3/4INX1800	TATA spare parts
221787105820	HOSE 3/4INX1350	TATA spare parts
221787105821	R2 HOSE 3/4 IN 1350 LG	TATA spare parts
221787105822	SUCTION HOSE ID 1INCX1200L	TATA spare parts
221787105823	SUCTION HOSE	TATA spare parts
221787105824	DISCHARGE HOSE	TATA spare parts
221787105904	LOCK KEY	TATA spare parts
221787106003	LINK	TATA spare parts
221787106004	CONTROL LEVER	TATA spare parts

221787106101	LOCK RINGS (LOCK RINGS SET FOR ALL STAGE	TATA spare parts
221787106102	M12 PLAIN WASHER 5MM THK	TATA spare parts
221787106103	M8 PLAIN WASHER	TATA spare parts
221787106104	M5 PLAIN WASHERS	TATA spare parts
221787106105	GUIDE LOCKRING FOR 90 DIA (EXTERNAL)	TATA spare parts
221787106106	THRUST PLATE BRITE	TATA spare parts
221787106107	PIN LOCKING PLATE	TATA spare parts
221787106108	REAR HINGE BKT.PLATE REINF.SMALL	TATA spare parts
221787106109	REAR HINGE BKT PLATE	TATA spare parts
221787106110	REAR HINGE BKT.PLATE REINF.	TATA spare parts
221787106301	S S SHEET	TATA spare parts
221787106302	S S SHEET	TATA spare parts
221787106303	S S SHEET	TATA spare parts
221787106305	FRP WHEEL ARC LH	TATA spare parts
221787106306	FRP WHEEL ARC LH	TATA spare parts
221787106514	M 8 NYLOC NUT	TATA spare parts
221787106515	M5 NYLOCK NUT	TATA spare parts
221787106520	NYLOC NUT M10 X 1.5	TATA spare parts
221787106523	PLAIN NUT	TATA spare parts
221787106524	SHEET METAL NUT	TATA spare parts
221787106525	NYLOC NUT	TATA spare parts
221787106526	NYLOC NUT M16	TATA spare parts
221787106527	CLINCH NUT	TATA spare parts
221787106529	NUT M8 UNI 5588	TATA spare parts
221787106530	HEX.NUT M6	TATA spare parts
221787106602	PISTON EYE TYPE 091 M/CED	TATA spare parts
221787106603	PISTON S 091-1445-HC	TATA spare parts
221787106604	PISTON S 091-1525-HC	TATA spare parts
221787106606	T-TYPE METAL PISTON BEARING	TATA spare parts
221787106607	PISTON ROD S/A	TATA spare parts
221787106608	PISTON	TATA spare parts
221787106701	EQUILIZER PIN	TATA spare parts
221787106702	STABLIZER PIN FRONT	TATA spare parts
221787106703	STABLIZER MOUNTING PIN	TATA spare parts
221787106704	KING PIN	TATA spare parts
221787106706	REAR HING PIN / SHAFT	TATA spare parts
221787106707	REAR HING PIN / SHAFT LOCKING PLATE	TATA spare parts
221787106708	REAR HING / SHAFT LOCKING PLATE STOPPER	TATA spare parts
221787106710	PIN FOR CAM MOUNTING	TATA spare parts
221787106726	PIN	TATA spare parts
221787106728	DOWEL PIN	TATA spare parts
221787106729	BODY PROP PIN	TATA spare parts
221787106730	HOPPER FULCRUM PIN	TATA spare parts
221787106731	CYLINDER TOP PROFILE PIN	TATA spare parts
221787106732	CYLINDER BOTTOM PROFILE PIN	TATA spare parts
221787106733	REAR LEG GUARD PIN	TATA spare parts
221787106801	BRAKE LINE HOSES	TATA spare parts



221787106803	O-RING ID 26.5 X 3.55 MM CS	TATA spare parts
221787106804	1 1/2 IN BSP X 1 7/16 UNF ADAPTER	TATA spare parts
221787106805	R 1 1IN 1515L 1 7/16_12UNF BS 90DEG BSS	TATA spare parts
221787106806	1 7/16 UNF X M39X2 ADAPTER	TATA spare parts
221787106807	M26 X 1.5 _ 1 3/16_12 ORFS UNF ELBOW	TATA spare parts
221787106808	R2 3/4 IN 2300LG 1 3/16_12 UNF BS 90DEG	TATA spare parts
221787106809	1 3/16 UNF X 3/4 IN BSP ADAPTER	TATA spare parts
221787106811	1 3/16 UNF X 1 IN BSP ADAPTER	TATA spare parts
221787106812	1 3/16 UNF BOTH SIDE FOS 50MM LG	TATA spare parts
221787106813	HOSE CLAMP HOLDER	TATA spare parts
221787106814	PVC COATED HOSE CLAMP FOR OD 40 MM HOSE	TATA spare parts
221787106815	PVC COATED HOSE CLAMP FOR OD 32 MM HOSE	TATA spare parts
221787106816	PUSH IN FITTING	TATA spare parts
221787106817	PUSH PULL CABLE	TATA spare parts
221787106821	SUCTION HOSE	TATA spare parts
221787106822	PRESSURE HOSE	TATA spare parts
221787106823	PRESSUREHOSE	TATA spare parts
221787106825	SUCTION HOSE 105 DEG	TATA spare parts
221787106826	HOSE	TATA spare parts
221787106827	PIPE RETURN HYD TANK	TATA spare parts
221787106828	REDUCING FITTING	TATA spare parts
221787106829	REDUCING FITTING	TATA spare parts
221787106830	ADAPTOR REDUCING	TATA spare parts
221787106831	ADAPTOR REDUCING	TATA spare parts
221787106832	STUD STANDPIPE ADAPTOR	TATA spare parts
221787106833	REDUCER ADAPTOR	TATA spare parts
221787106834	ADAPTOR REDUCING	TATA spare parts
221787106835	REDUCER	TATA spare parts
221787106836	REDUCER ADAPTOR	TATA spare parts
221787106837	BULKHEAD ELBOW	TATA spare parts
221787106838	REDUCER ADAPTOR	TATA spare parts
221787106839	BULKHEAD ELBOW	TATA spare parts
221787106840	PNEUMATIC ELBOW	TATA spare parts
221787106841	AIR TUBE 6MM	TATA spare parts
221787106842	PEUMATIC FITTING 6MM	TATA spare parts
221787106843	PIPE CLAMP TWIN 18MM/18MM	TATA spare parts
221787106848	ADAPTOR 1 X 1/4 INBSP M X1 X 3/16 IN	TATA spare parts
221787106849	1-3/16_12 X 1IN BSP ELBOW ADAPTER	TATA spare parts
221787106850	STRAIGHT COUPLING BODY	TATA spare parts
221787106851	ADAPTOR 1/4 IN X 1/2 IN <sub>ç</sub> STRAIGHT	TATA spare parts
221787106852	ADAPTOR 3/8 IN X 1/2 IN <sub>ç</sub> STRAIGHT	TATA spare parts
221787106853	ADAPTOR 1/2 INX1/2 IN <sub>ç</sub> STRAIGHT	TATA spare parts
221787106854	BANJO FITTING 3/8 INX3/8 IN	TATA spare parts
221787106902	BASE 149-1479-4/4SAE-190-C219	TATA spare parts
221787106903	BASE 149-1559-4/4SAE-190	TATA spare parts
221787106904	FUEL PIPE 8.0 14 B 1000 WB	TATA spare parts
221787106905	SILENCER PIPING	TATA spare parts

221787106906	SILENCER	TATA spare parts
221787106907	POLYURETHANE TUBE	TATA spare parts
221787106908	PNEUMATIC AIR TUBE (OD 6 X ID 4MM)	TATA spare parts
221787106916	TUBE DIA. 105 X DIA. 95 X 1002 L	TATA spare parts
221787106917	TUBE 2 ND STAGE DIA. 90 X DIA. 80 X 1002	TATA spare parts
221787106918	TUBE III STAGE OD75 X ID65 X 1002 L (FC)	TATA spare parts
221787106919	EXHAUST PIPE 230-109-1 ( FOR 230-8.5	TATA spare parts
221787106920	2SY EXHAUST PIPE 230-109-2 (FOR 20	TATA spare parts
221787106921	POLYURETHANE TUBE	TATA spare parts
221787106923	PROP SQ.TUBE	TATA spare parts
221787106924	REAR SUPPORT LEG TUBE (OUTER)	TATA spare parts
221787106925	TUBE S/A	TATA spare parts
221787106926	CORREGATED HOSE	TATA spare parts
221787106927	SUCTION HOSE	TATA spare parts
221787106928	RETURN HOSE	TATA spare parts
221787106929	PRESSURE HOSE	TATA spare parts
221787106930	HOSE WITH ONE END BEND	TATA spare parts
221787107101	MAIN LEAF	TATA spare parts
221787107102	2 ND LEAF	TATA spare parts
221787107103	3 RD LEAF	TATA spare parts
221787107109	SPRING 10LEAF	TATA spare parts
221787107110	TOP LEAF-930010(YTE75/90)	TATA spare parts
221787107111	2 LEAF-930010(YTE75/90)	TATA spare parts
221787107112	HOOK LEAF-930011(3RD LEAF)YTE75/90	TATA spare parts
221787107120	LANDING LEG	TATA spare parts
221787107130	BOTTOM PLATE PISTON TYPE 091	TATA spare parts
221787107202	MAGNETIC DRAIN PLUG 3/4 IN BSP	TATA spare parts
221787107204	M22X1.5 PLUG	TATA spare parts
221787107205	PLUG M22X1.5	TATA spare parts
221787107206	DRAIN PLUG (BOC)	TATA spare parts
221787107501	TEFLON BUSH	TATA spare parts
221787107503	MUD GUARD RUBBER	TATA spare parts
221787107504	V BELT COGGED	TATA spare parts
221787107505	V BELT RAW EDGE COGGED LP	TATA spare parts
221787107506	GROMMET RUBBER ID 25MM	TATA spare parts
221787107707	'O' RING PISTON TOP 091	TATA spare parts
221787107708	'O' RING PISTON BOTTOM 091	TATA spare parts
221787107713	SEAL KIT	TATA spare parts
221787107714	SEAL KIT	TATA spare parts
221787107718	SEALING RING - BOWL(89X102X3.2T)	TATA spare parts
221787107719	O RING - DIPSTICK (2X5)	TATA spare parts
221787107720	O RING FOR FUEL FILTER	TATA spare parts
221787107721	SEAL RING	TATA spare parts
221787107722	SEALING RING	TATA spare parts
221787107723	SEALING RING	TATA spare parts
221787107724	STD. BONDED SEAL BS6	TATA spare parts
221787107725	STD. BONDED SEAL BS6	TATA spare parts

221787107727	STD.BONDED SEAL ID48.7 X OD59.0 X 3THK	TATA spare parts
221787107731	SEAL KIT(ROD SEAL/WIPER SEAL/GUIDE STRIP	TATA spare parts
221787107735	C.E.COVER CLAMPING RING	TATA spare parts
221787107738	DOWTY SEAL	TATA spare parts
221787107739	SEAL	TATA spare parts
221787107745	RUBBER FOR CYLIDER SUPPORT	TATA spare parts
221787107746	SEAL KIT FOR DIA. 105 STAGE	TATA spare parts
221787107747	SEAL KIT FOR DIA. 90 STAGE	TATA spare parts
221787107748	SEAL KIT FOR DIA. 75 STAGE	TATA spare parts
221787107749	SEAL 20X30X5	TATA spare parts
221787107750	Q-RING	TATA spare parts
221787107751	O RING	TATA spare parts
221787107752	GASKET	TATA spare parts
221787107753	MOUNTING RUBBER PAD	TATA spare parts
221787107754	EPDM GASKET	TATA spare parts
221787107801	SEAL BOTTOM PLATE TYPE 149	TATA spare parts
221787107802	SEAL	TATA spare parts
221787107803	O RING ID 118.2 X C/S 3.5 NBR 90 SHORE A	TATA spare parts
221787107804	BACKUP RING (OD 127.6 X ID 118 X THK 1.7	TATA spare parts
221787107805	O RING DIA 117.2 XDIA 5.7 NBR 90 SHORE A	TATA spare parts
221787107806	STOPRING FOR BORE 80 DIA TUBE (INTERNAL)	TATA spare parts
221787107807	STOPRING FOR BORE 95 DIA TUBE (INTERNAL)	TATA spare parts
221787107903	REAR HINGE SHAFT	TATA spare parts
221787107904	PIVOT SHAFT	TATA spare parts
221787107905	CLOSURE FLANGE	TATA spare parts
221787107906	STABLIZER CONNECTING SHAFT	TATA spare parts
221787107907	SHAFT	TATA spare parts
221787107913	WORM GEAR SHAFT	TATA spare parts
221787107914	TRANSMISSION SHAFT	TATA spare parts
221787107915	CENTRAL SHAFT	TATA spare parts
221787107916	SHIFT SHAFT	TATA spare parts
221787108013	M8 X 75 SOCKET HEADED CAP SCREW	TATA spare parts
221787108014	M5 X 25 LEN. SOCKET HEAD CAP SCREW	TATA spare parts
221787108024	HEX. HEAD SCREW	TATA spare parts
221787108025	HEX HEAD SCREW M8X16	TATA spare parts
221787108026	SCREW	TATA spare parts
221787108027	CAP SCREW	TATA spare parts
221787108028	CAP SCREW	TATA spare parts
221787108029	HEX. HEAD SCREW M10X25MM	TATA spare parts
221787108030	CAP SCREW-GR-12.9	TATA spare parts
221787108031	CAP SCREW-GR-12.9	TATA spare parts
221787108032	SCREW	TATA spare parts
221787108034	HEX. HEAD SCREW M10X30	TATA spare parts
221787108035	HEX HEAD SCREW M8X40	TATA spare parts
221787108036	CSK SCREW	TATA spare parts
221787108038	HEX HEAD SCREW M14X1.5X55 GR. 10.9	TATA spare parts
221787108039	M8X16MMç GRUB SCREW FOR PISTON EYE	TATA spare parts

221787108040	HEX. SCREW M6X14 GR 10.9	TATA spare parts
221787108041	M8 X 45L CAP SCREW	TATA spare parts
221787108042	M8 CAP SCREW	TATA spare parts
221787108043	M10 CAP SCREW	TATA spare parts
221787108044	GRUB SCREW M4X14	TATA spare parts
221787108045	HEX.HD.SCREW M6X30-8.8	TATA spare parts
221787108046	HEX.HD.SCREW M8X25-8.8	TATA spare parts
221787108047	HEX.SOC.HD.CAP.SCREW M8X100-12.9	TATA spare parts
221787108201	FRONT HANGER	TATA spare parts
221787108202	REAR HANGER	TATA spare parts
221787108203	AIR TANK	TATA spare parts
221787108204	CHASSIS FRAME	TATA spare parts
221787108205	TIPPING CYLINDER	TATA spare parts
221787108217	CHASSIS BKT 110 129 149 IB	TATA spare parts
221787108224	SHIM KIT - TRUNNION	TATA spare parts
221787108225	ORIFICE	TATA spare parts
221787108226	ORIFICE	TATA spare parts
221787108229	MOTOR FAN 24V 280 DIA.	TATA spare parts
221787108230	SILENCER MOUNTING BRACKET	TATA spare parts
221787108231	BRACKET	TATA spare parts
221787108232	BRACKET	TATA spare parts
221787108240	ADAPTOR 1 INBSP(M)X1 3/16 INUNFORS	TATA spare parts
221787108241	ADAPTOR 1 INCH BSP M X17/16 INCH BS6	TATA spare parts
221787108244	C.E.COVER	TATA spare parts
221787108245	PACKER PLATE	TATA spare parts
221787108248	EJECTION BARRIER NARROW	TATA spare parts
221787108249	LOCKING PLATE	TATA spare parts
221787108250	CAM	TATA spare parts
221787108251	BUSH	TATA spare parts
221787108252	CAM ROLLER	TATA spare parts
221787108253	HEX. HEAD BOLT	TATA spare parts
221787108254	NYLOC NUT	TATA spare parts
221787108255	FABRICATION TORQUE TUBE NARRO	TATA spare parts
221787108256	FAB CARRIAGE NARROW	TATA spare parts
221787108257	HEX. HEAD BOLT	TATA spare parts
221787108258	WASHER	TATA spare parts
221787108259	HEX. HEAD BOLT	TATA spare parts
221787108260	PIN DINARM	TATA spare parts
221787108261	FAB FRAME EUROLIFT NARROW	TATA spare parts
221787108262	CSK HEAD SCREW	TATA spare parts
221787108263	SPLIT PIN	TATA spare parts
221787108264	DOWEL PIN	TATA spare parts
221787108265	TAB WASHER	TATA spare parts
221787108266	SKT. HEAD CAP SCREW	TATA spare parts
221787108267	PIVOT BOTTOM	TATA spare parts
221787108268	PLAIN NUT	TATA spare parts
221787108269	HEX. HEAD SCREW	TATA spare parts

221787108270	HEX. HEAD BOLT	TATA spare parts
221787108271	SUPPORT CHANEL LH	TATA spare parts
221787108272	SUPPORT CHANEL RH	TATA spare parts
221787108273	PIVOT PIN ASSY	TATA spare parts
221787108274	HEX. HEAD SCREW	TATA spare parts
221787108275	ADAPTOR	TATA spare parts
221787108276	SEAMLESS PIPE	TATA spare parts
221787108277	BINLIFT VALVE	TATA spare parts
221787108278	ELBOW .	TATA spare parts
221787108279	T ADAPTOR	TATA spare parts
221787108280	HYDRAULIC CYLINDER	TATA spare parts
221787108281	SEAMLESS PIPE	TATA spare parts
221787108282	PIPE CLAMP	TATA spare parts
221787108283	PLATE 3 PUMP SUPPORT	TATA spare parts
221787108284	PLATE 4 PUMP SUPPORT	TATA spare parts
221787108285	BOX SECTION	TATA spare parts
221787108286	PLATE 2 PUMP SUPPORT	TATA spare parts
221787108287	PLATE PUMP SUPPORT	TATA spare parts
221787108288	HEX. HEAD SCREW	TATA spare parts
221787108289	WEAR PLATE	TATA spare parts
221787108290	PUSH PULL CABLE FORK	TATA spare parts
221787108301	BASE 192X1464 (INNER STOPRING FITTED)	TATA spare parts
221787108302	STAGE 170X1427 (INNER STOPRING FITTED)	TATA spare parts
221787108303	STAGE 150X1427 (INNER STOPRING FITTED)	TATA spare parts
221787108304	INNER GUIDE RING 192	TATA spare parts
221787108305	INNER GUIDE RING 170	TATA spare parts
221787108306	OUTER GUIDE RING 170	TATA spare parts
221787108307	OUTER GUIDE RING 150	TATA spare parts
221787108308	INNER SNAP RING 192	TATA spare parts
221787108309	OUTER STOP RING 170	TATA spare parts
221787108310	OUTER SNAP RING 170	TATA spare parts
221787108311	INNER SNAP RING 170	TATA spare parts
221787108312	OUTER STOP RING 150	TATA spare parts
221787108313	OUTER SNAP RING 150	TATA spare parts
221787108314	OIL TANK STEEL STRAP ( 115L & 178L)	TATA spare parts
221787108402	SLEEVE	TATA spare parts
221787108403	FOG LAMP - 441	TATA spare parts
221787108403AE	FOG LAMP - 441 2523	TATA spare parts
221787108404	HELOGEN BULB	TATA spare parts
221787108404AE	HELOGEN BULB H-3 2523	TATA spare parts
221787108405	PIANO SWITCH	TATA spare parts
221787108405AE	PIANO SWITCH 2523	TATA spare parts
221787108406	SEARCH LAMP ASSY/LRV	TATA spare parts
221787108407	REVOLVING LIGHT 12 -V	TATA spare parts
221787108408	SLEEVE	TATA spare parts
221787108603	SPACER	TATA spare parts
221787108702	RELIEF VALVE SPRING - 3DHMP VALVE	TATA spare parts

221787108706	SPRING/LOWER RING (DIA 91)	TATA spare parts
221787108707	SPRING FRONT PIVOT	TATA spare parts
221787108708	CARBON SPRING 715-113	TATA spare parts
221787108709	CARBON SPRING 715-113-1	TATA spare parts
221787108710	SPRING	TATA spare parts
221787108803	STUD	TATA spare parts
221787108804	MALE STUD COUPLING	TATA spare parts
221787108805	MALE STUD COUPLING	TATA spare parts
221787108806	ADJUSTABLE MALE STUD	TATA spare parts
221787108807	MALE STUD COUPLING	TATA spare parts
221787108808	ADJ. MALE STUD ELBOW	TATA spare parts
221787108809	ADJ. MALE STUD ELBOW	TATA spare parts
221787108810	STUD STANDPIPE ADAPTOR	TATA spare parts
221787108811	MALE STUD COUPLING	TATA spare parts
221787108812	MALE STUD COUPLING	TATA spare parts
221787108817	STUD 8X20	TATA spare parts
221787109001	RE VALVE	TATA spare parts
221787109004	AIR CONTROL VALVE BS1/2/3/4	TATA spare parts
221787109006	HIGH PR. RELIEF VALVE	TATA spare parts
221787109011	BALL VALVE BS6	TATA spare parts
221787109014	SPARE COMPLETE VALVE	TATA spare parts
221787109015	MOUNTING FOR CAB CONTROL VALVE	TATA spare parts
221787109018	CABIN CONTROL VALVE	TATA spare parts
221787109022	DUAL PRESSURE FLOW VALVE	TATA spare parts
221787109023	SOLENOID-2WAY POPPET	TATA spare parts
221787109030	FRONT END CONTROL VALVE	TATA spare parts
221787109202	SPRING WASHER M12 SQUARE SECTION	TATA spare parts
221787109217	COPPER WASHER OD44 X ID38 X 1.2MM THK	TATA spare parts
221787109218	M8 SPRING WASHERS	TATA spare parts
221787109219	DOWTY WASHER 1 1/4IN BSP	TATA spare parts
221787109220	DOWTY WASHER 3/4IN BSP	TATA spare parts
221787109221	DOWTY WASHER 1IN BSP	TATA spare parts
221787109222	COPPER WASHER (22.5 ID) IS 3175	TATA spare parts
221787109223	COPPER WASHER (33.5 ID) IS 3175	TATA spare parts
221787109226	SPRING WASHER B8	TATA spare parts
221787109235	NYLON WASHER	TATA spare parts
221787109236	WASHER SPRING	TATA spare parts
221787109237	PLAIN WASHER	TATA spare parts
221787109238	SPRING WASHER	TATA spare parts
221787109239	WASHER	TATA spare parts
221787109240	SPRING WASHER M8	TATA spare parts
221787109241	WASHER M10	TATA spare parts
221787109242	WASHER M16	TATA spare parts
221787109243	WASHER M20 HARDENED	TATA spare parts
221787109244	M10 SPRING WASHER SQ. SECTION	TATA spare parts
221787109245	PLAIN WASHER M6	TATA spare parts
221787109246	SCHNORR WASHER 8	TATA spare parts

221787109247	WASHER DIA 22X28X1.5	TATA spare parts
221787109248	COPPER WASHER 10X16X1.5	TATA spare parts
221787109249	M8 SPRING WASHER	TATA spare parts
221787109250	SEALING WASHER	TATA spare parts
221787109251	PLAIN WASHER ID 6.4XOD 18	TATA spare parts
221787109252	PLAIN WASHER A 8.5	TATA spare parts
221787109253	SEALING WASHER - ID14 X OD18	TATA spare parts
221787109255	SEALING WASHER 21X26	TATA spare parts
221787109907	STAGE HC A/S	TATA spare parts
221787109909	STAGE HC-A/S	TATA spare parts
221787109914	COMPLETE PACKSET	TATA spare parts
221787109917	CHARGE PUMP	TATA spare parts
221787109918	CYLINDER BLOCK KIT	TATA spare parts
221787109919	SEAL KIT	TATA spare parts
221787109921	V BELT COGGED (FOR BLOWER PULLEY )	TATA spare parts
221787109922	OIL SIGHT GLASS	TATA spare parts
221787109923	PUMP CONTROL CABLE	TATA spare parts
221787109924	ACCELERATOR CABLE	TATA spare parts
221787109925	THERMOSWITCH	TATA spare parts
221787109926	OIL FILTER ELEMENT	TATA spare parts
221787109927	FUEL FILTER ELEMENT PRE	TATA spare parts
221787109928	FUEL FILTER ELEMENT MICRO	TATA spare parts
221787109933	ELBOW (PNEUMATIC)	TATA spare parts
221787109941	BULL EYE	TATA spare parts
221787109942	FILLER BREATHER	TATA spare parts
221787109943	FILTER CARTRIDGE	TATA spare parts
221787109963	1 1/2IN OIL LEVEL INDICATOR-CIRCULAR TYP	TATA spare parts
221787109964	FILLER BREATHER	TATA spare parts
221787109965	RETURN LINE FILTER	TATA spare parts
221787109966	MCV MTG. BLOCK	TATA spare parts
221787109967	OIL TANK MTG PAD KIT	TATA spare parts
221787109968	1 1/2 IN BALL VALVE	TATA spare parts
221787109969	MCV	TATA spare parts
221787109970	CABLE TIE (250 MM LENGTH) BLACK COLOR	TATA spare parts
221787109971	TAL -LOGO	TATA spare parts
221787109972	SAFETY STICKER	TATA spare parts
221787109973	TIPPING INSTRUCTIONS	TATA spare parts
221787109974	PNEUMATIC CAB CONTROL	TATA spare parts
221787109975	GREASE NIPPLE M10X1	TATA spare parts
221787109978	MANUAL CONTROL VALVE	TATA spare parts
221787109982	ADAPTER OF MKII-2 PUMP WITH REARDELIVERY	TATA spare parts
221787109993	SEAL KIT	TATA spare parts
221787109994	SPARE COMPLETE CYLINDER	TATA spare parts
221787109995	HYDRAULIC TANK	TATA spare parts
221787109996	FILLER BREATHER CAP	TATA spare parts
221787109998	OIL LEVEL GAUGE & SEAL	TATA spare parts
221787109999	WIRE ROPE WITH EYE HOOK	TATA spare parts

221787109999AE	WIRE ROPE/13MMX90 MTR 2523	TATA spare parts
221787110101	DINARM ASSLY	TATA spare parts
221787110102	PLATE LIFT ARM ASSLY LH	TATA spare parts
221787110103	PLATE LIFT ARM ASSLY RH	TATA spare parts
221787110104	ASSLY LINK ROTATE	TATA spare parts
221787110105	PIPE ASSEMBLY	TATA spare parts
221787110106	PIPE ASSEMBLY	TATA spare parts
221787110107	JUNCTION BOX ASSLY BODY	TATA spare parts
221787110109	SWEEPER ASSEMBLY WIDE	TATA spare parts
221787110110	AIR BREATHER ASSY	TATA spare parts
221787110111	ASSY BOX TYPE TIPPER BODY	TATA spare parts
221787110131	MUDGUARD ASSY	TATA spare parts
221787110144	TIP VALVE	TATA spare parts
221787110145	PTO G600 TYPE V1	TATA spare parts
221787110150	MTG KIT JT-VALVE ON SAE INLET	TATA spare parts
221787110152	CYLINDER	TATA spare parts
221787110154	TIPPING CYLINDER	TATA spare parts
221787110155	TIPPING CYLINDER	TATA spare parts
221787110156	CYLINDER	TATA spare parts
221787110157	TIPPING CYLINDER	TATA spare parts
221787110158	TIPPING CYLINDER BS3/4	TATA spare parts
221787110159	9KL WATER TANK FULL BODY	TATA spare parts
221787110160	ASSY TIPPER BODY COMPLETE	TATA spare parts
221787110161	TAIL DOOR ASSY	TATA spare parts
221787110162	CRADLE ASSY	TATA spare parts
221787110163	TAILDOOR HINGE ASSY	TATA spare parts
221787110164	SUBFRAME ASSEMBLY	TATA spare parts
221787110165	STABALIZER ASSY	TATA spare parts
221787110166	HOOK ASSEMBLY	TATA spare parts
221787110167	HOOK BLOCK ASSEMBLY	TATA spare parts
221787110168	REAR HINGE BUSH ASSY	TATA spare parts
221787110169	SPARE WHEEL WINCH	TATA spare parts
221787110171	OUTER TUBE SUBASSEMBLY	TATA spare parts
221787110172	REAR END ASSEMBLY	TATA spare parts
221787110173	COVER TUBE ASSEMBLY	TATA spare parts
221787110174	RETURN LINE FILTER ASSY(300 LPM)	TATA spare parts
221787110177	OIL TANK 74L + METAL STRAP	TATA spare parts
221787110179	STABILIZER ASSEMBLY	TATA spare parts
221787110180	SUBFRAME ASSEMBLY	TATA spare parts
221787110181	CYLINDER MTG.CRADLE ASSEMBLY	TATA spare parts
221787110182	TIPPER BODY ASSEMBLY	TATA spare parts
221787110183	CRASH GUARD ASSEMBLY	TATA spare parts
221787110184	RETURN LINE FILTER SEAL KIT	TATA spare parts
221787110185	RUBBERç PAD ASSEMBLY	TATA spare parts
221787110190	CARRYING ROLLER CPL. OF AM6SHC RH	TATA spare parts
221787110191	TIPPER BODY ASSEMBLY (20 CUM STD)	TATA spare parts
221787110192	TIPPER BODY ASSEMBLY (18 CUM STD)	TATA spare parts



221787110193	TAILDOOR ASSEMBLY (20 CUM STD)	TATA spare parts
221787110194	TAILDOOR ASSEMBLY (18 CUM STD)	TATA spare parts
221787110195	STABILIZER ASSEMBLY HINGE BUSH	TATA spare parts
221787110197	SPARE COMPLETE CYLINDER	TATA spare parts
221787118217	TEE MALE	TATA spare parts
221787118218	STRAIGHT COUPLING	TATA spare parts
221787118219	BRACKET COVER SUPPORT	TATA spare parts
221787118220	TAPE DOUBLE SIDED	TATA spare parts
221787118221	EQUAL TEE	TATA spare parts
221787118222	GRIPPER PLATE	TATA spare parts
221787118223	CLAMP PLATE	TATA spare parts
221787118224	TAILGATE WIDE	TATA spare parts
221787118247	TRANSMISSION SIDE PLATE	TATA spare parts
221787119901	SPARE COMPLETE TANK WITH VALVE	TATA spare parts
221787119911	BALL VALVE BS6	TATA spare parts
221787119913	SPARE COMPLETE CYLINDER BS3	TATA spare parts
221787119916	ELBOW WITH NIPPLE	TATA spare parts
221787119918	SAE SPLIT FLANGE SET	TATA spare parts
221787119919	ADAPTOR	TATA spare parts
221787119920	ADJ. EQUAL TEE	TATA spare parts
221787119921	EQUAL TEE	TATA spare parts
221787119922	BOLT	TATA spare parts
221787119923	BOLT	TATA spare parts
221787119924	BOLT	TATA spare parts
221787119925	FLANGE BOLT	TATA spare parts
221787119926	INSPECTION WINDOW	TATA spare parts
221787119927	HEX. HEAD SCREW	TATA spare parts
221787119928	NYLOC NUT	TATA spare parts
221787119929	BOLT	TATA spare parts
221787119930	CARTRIDGE 120BAR	TATA spare parts
221787119931	SOLENOID COIL	TATA spare parts
221787119933	BASE RELAY	TATA spare parts
221787119934	RUN/ TIP SWITCH	TATA spare parts
221787119935	FUSE	TATA spare parts
221787119936	EJECTOR CYLINDER 12N	TATA spare parts
221787119937	BOLT M8X45MM	TATA spare parts
221787119938	PACKER CYLINDER	TATA spare parts
221787119941	BOLT M8X55MM	TATA spare parts
221787119942	COTTER PIN	TATA spare parts
221787119944	SWEEPER CYLINDER	TATA spare parts
221787119945	PIN	TATA spare parts
221787119949	PIN	TATA spare parts
221787119951	HEX. BOLT	TATA spare parts
221787119952	BOLT M16X50MM	TATA spare parts
221787119953	BOLT M16X50MM	TATA spare parts
221787119954	BLOCK PACKER ARM	TATA spare parts
221787119955	GREASE NIPPLE	TATA spare parts

221787119956	SHAFT SEAL	TATA spare parts
221787119957	SEAL KIT FOR PUMP	TATA spare parts
221787119958	HYDRAULIC OIL TANK CPL.	TATA spare parts
221787119959	FABRICATION HYD OIL TANK	TATA spare parts
221787119960	ELEMENT	TATA spare parts
221787119962	FLUID LEVEL GUAGE	TATA spare parts
221787119963	BREATHER FILTER ELEMENT	TATA spare parts
221787119963DF	BREATHER FILTER-HYDRAULIC TANK	TATA spare parts
221787119964	HOUSING	TATA spare parts
221787119965	COVER	TATA spare parts
221787119966	SEAL KIT FOR BINLIFT VALVE	TATA spare parts
221787119967	O RING FOR SAE FLANGE 2 1/2 INC	TATA spare parts
221787119968	O RING FOR SAE FLANGE 1INC	TATA spare parts
221787119969	O RING FOR SAE FLANGE 3/4INC	TATA spare parts
221787119988	SPARE WHEEL WINCH RETRO KIT FOR PRIMA	TATA spare parts
221787119989	WIRE ROPE	TATA spare parts
221787119990	SPIGOT	TATA spare parts
221787119995	FILTER 715-203-1	TATA spare parts
221787119996	CARBON 715-208-68	TATA spare parts
221787119997	CARBON 715-208-259	TATA spare parts
221787119998	RETURN LINE FILTER ELEMENT BS3/4	TATA spare parts
221787120100	ASSY SIDE DOOR LOCKING LH	TATA spare parts
221787120102	ASSY SIDE DOOR LOCKING RH	TATA spare parts
221787120103	ASSY SIDE BOARD FLAP HINGE	TATA spare parts
221787120104	TAILDOOR ASSEMBLY (2.66 CUM - SK407/31)	TATA spare parts
221787120105	ASSLY TAILDOOR LOCKING MECHANISM	TATA spare parts
221787120108	SUB ASSY FRAME FOR LPK909/27	TATA spare parts
221787120109	TIPPER BODY ASSEMBLY (5 CUM - LPK909/27)	TATA spare parts
221787120110	TAILDOOR ASSEMBLY (5 CUM - LPK909/27)	TATA spare parts
221787120111	PULLING PIPE ASSEMBLY	TATA spare parts
221787120113	TIPPING CYLINDER	TATA spare parts
221787120115	RUBBER PAD ASSLY - FRONT	TATA spare parts
221787120116	RUBBER PAD ASSLY - REAR	TATA spare parts
221787120117	ASSLY MUDGUARD LH /RH FOR LPK909	TATA spare parts
221787120118	ASSY FRONT LOCKING	TATA spare parts
221787120120	TIPPER BODY ASSEMBLY (3 CUM - LPK407/27)	TATA spare parts
221787120129	TAIL DOOR ASSY(14CUM STD TIPPER ON)	TATA spare parts
221787120130	HYDRAULIC CYLINDER	TATA spare parts
221787120131	HYDRAULIC CYLINDER	TATA spare parts
221787120132	HYDRAULIC CYLINDER	TATA spare parts
221787120133	HYDRAULIC CYLINDER	TATA spare parts
221787120134	HYDRAULIC CYLINDER	TATA spare parts
221787120135	HYDRAULIC CYLINDER	TATA spare parts
221787120137	ASSY. TIPPING LOAD BODY	TATA spare parts
221787120139	ASSY SIDE BOARD FLAP LH/RH	TATA spare parts
221787120140	ASSLY TAILDOOR LOCKING MECHANISM FOR LPK	TATA spare parts
221787120145	SEALKIT CYLINDER 3 STAGE	TATA spare parts

221787120146	TIP VALVE MTG BLOCK KIT WITH BEND PIPE A	TATA spare parts
221787120147	BEND PIPE ASSEMBLY	TATA spare parts
221787120148	TIP VALVE 40 KIT TATA 1613	TATA spare parts
221787120149	TIP VALVE 40 (THREE PORTS)	TATA spare parts
221787120150	MOUNTING KIT CYLINDER	TATA spare parts
221787120151	OIL TANK WITH MOUNTING KIT	TATA spare parts
221787120152	OIL TANK ASSEMBLY 31L (CYL)	TATA spare parts
221787120153	RETURN LINE FILTER AND BREATHER KIT	TATA spare parts
221787120154	BREATHER ASSEMBLY	TATA spare parts
221787120155	MOUNTING KIT OIL TANK	TATA spare parts
221787120156	HOSE AND ADAPTOR KIT ON LPK1613	TATA spare parts
221787120157	SUCTION HOSE 1 IN X 1570L 1 IN BSP ST. F	TATA spare parts
221787120158	HOSE 1/2 IN BSP X 1500L 1/2 IN BSP ST. F	TATA spare parts
221787120159	HOSE 3/4 IN BSP X 800L 3/4 IN BSP ST FS	TATA spare parts
221787120160	GASKET KIT	TATA spare parts
221787120161	SUCTION HOSE 1 IN X 1370L 1 IN BSP ST. F	TATA spare parts
221787120162	HOSE 1/2 IN BSP X 1300L 1/2 IN BSP ST. F	TATA spare parts
221787120163	BODY LOCK ASSEMBLY WITH LOCKING BRACKET	TATA spare parts
221787120164	TIP VALVE MTG BLOCK KIT	TATA spare parts
221787120165	BEND PIPE ASSEMBLY	TATA spare parts
221787120166	TIP VALVE KIT	TATA spare parts
221787120167	TIP VALVE 120 THREE PORTS	TATA spare parts
221787120168	OIL TANK ASSEMBLY (55L)	TATA spare parts
221787120169	MOUNTING KIT OIL TANK	TATA spare parts
221787120170	MOUNTING KIT	TATA spare parts
221787120171	SUCTION HOSE 1 IN X 1050L (CYLINDER)	TATA spare parts
221787120172	SEAL KIT CYLINDER 3 STAGE	TATA spare parts
221787120173	BOTTOM PLATE KIT 130 CYLINDER	TATA spare parts
221787120177	SEALKIT CYLINDER 170-4	TATA spare parts
221787120178	BOTTOM PLATE KIT 170 CYLINDER	TATA spare parts
221787120179	PISTON EYE 111 WITH SPH. BEARING	TATA spare parts
221787120180	MOUNTING KIT FOR TATA 4018	TATA spare parts
221787120181	HOSE AND ADAPTOR KIT ON TATA 4018	TATA spare parts
221787120182	BEND PIPE AND 1 BSP MTG BLOCK ASSEMBLY F	TATA spare parts
221787120183	AIR CONTROL VALVE LINE KIT	TATA spare parts
221787120184	OIL TANK WITH MOUNTING KIT	TATA spare parts
221787120185	OIL TANK ASSEMBLY - 115L	TATA spare parts
221787120186	RETURN LINE FILTER 220 & BREATHER KIT	TATA spare parts
221787120187	RETURN LINE FILTER ASSEMBLY (IN TO OUT)	TATA spare parts
221787120188	TIPPER VALVE MTG BLOCK KIT	TATA spare parts
221787120189	VLAVE 220 LPM	TATA spare parts
221787120190	MOUNTING KIT OIL TANK 115L	TATA spare parts
221787120191	OUTER COVER ASSEMBLY 168X1050	TATA spare parts
221787120192	BOTTOM PLATE KIT	TATA spare parts
221787120193	PISTON HEAD 073 KIT	TATA spare parts
221787120194	RETURN LINE FILTER ASSEMBLY (IN TO OUT)	TATA spare parts
221787120195	AIR CONTROL VALVE LINE KIT ON LPK1613	TATA spare parts

221787120196	AIR CONTROL WITH PTO ENGAGEMENT WARNING	TATA spare parts
221787120197	HOSE AND ADAPTOR KIT ON SK1613	TATA spare parts
221787120198	AIR CONTROL VALVE LINE KIT ON SK1613	TATA spare parts
221787120199	OIL TANK WITH MOUNTING KIT	TATA spare parts
221787129901	JOINT	TATA spare parts
221787129902	TARPAULIN SYSTEM	TATA spare parts
221787129903	GREASE NIPPLE	TATA spare parts
221787129904	SEAL KIT	TATA spare parts
221787129905	FILLER CUM BREATHER	TATA spare parts
221787129906	METALLIC STRAINER	TATA spare parts
221787129907	CABLE TIES	TATA spare parts
221787129908	SS LOCKING ARRANGEMENT + HINGES	TATA spare parts
221787130100	AIR CONTROL VALVE LINE KIT	TATA spare parts
221787130101	HOSE AND ADAPTOR KIT	TATA spare parts
221787130102	HOSE 3/4 IN BSP X 1700L 3/4 IN BSP ST FS	TATA spare parts
221787130103	HOSE 3/4 IN BSP X 1300L 3/4 IN BSP ST FS	TATA spare parts
221787130115	LIMITER VALVE ASSEMBLY	TATA spare parts
221787130116	LEVER TYPE CONTROL VALVE	TATA spare parts
221787130117	AIR TANK 50 LITERS 3 PORT	TATA spare parts
221787130120	TELESCOPIC CYLINDER	TATA spare parts
221787130124	OPEN LOOP DIRECTIONAL VALVE	TATA spare parts
221787130126	SUB FRAME ASSEMBLY	TATA spare parts
221787130127	TAIL DOOR ASSEMBLY	TATA spare parts
221787130128	TAILDOOR ASSY 14 STD TATA 2518	TATA spare parts
221787130143	WIRING HARNESS (TROLLY)	TATA spare parts
221787130144	HYDRAULIC TANK - (STRAP MOUNTED)	TATA spare parts
221787130145	ASSY. SUB FRAME	TATA spare parts
221787130147	HYDRAULIC TANK	TATA spare parts
221787130148	ASSY. SUB FRAME	TATA spare parts
221787130149	WIRING HARNESS DLT TRAILER	TATA spare parts
221787130152	PTO WITH PUMP	TATA spare parts
221787130153	GEAR PUMP	TATA spare parts
221787130154	HOPPER ASSEMBLY	TATA spare parts
221787130155	HOPPER BODY	TATA spare parts
221787130156	SUB FRAME ASSEMBLY	TATA spare parts
221787130157	REAR LEG GUARD TUBE ASSY	TATA spare parts
221787130158	HYDRAULIC TANK S/A	TATA spare parts
221787130159	OIL LEVEL GUAGE ASSEMBLY	TATA spare parts
221787130160	DOUBLE ACTING SOL.OP.DCV	TATA spare parts
221787130161	HYDRAULIC CYLINDER	TATA spare parts
221787130162	OIL TANK ASSEMBLY	TATA spare parts
221787130163	MANIFOLD ASSY(WITH CHECK VALVE AND RELIE	TATA spare parts
221787130164	AXIAL PISTON PUMP	TATA spare parts
221787130166	1/2 X 16MM PIPE FERRUL & NUT	TATA spare parts
221787130168	TEE ADAPTOR 16MM X 16MM X 1/4&QUOT	TATA spare parts
221787130170	3/4INCH BSP X 16MM PIPE FERRUL & NUT	TATA spare parts
221787130171	COUNTER BALANCE VALVE	TATA spare parts

221787130173	BELT	TATA spare parts
221787209901	SNAP RING FOR PISTON TYPE 091	TATA spare parts
221787300111	ADJUSTABLE TORQUE ARM ASSEMBLY(YTE75/90)	TATA spare parts
221787300112	TORQUE ARM PIVOT ASSEMBLY(POLY)YTE75/90	TATA spare parts
221787300113	EQUALIZER ASSEMBLY LH(YTE75/90)	TATA spare parts
221787300114	EQUALIZER ASSEMBLY RH(YTE75/90)	TATA spare parts
221787300115	REAR HANGER ASSEMBLY(YTE75/90)	TATA spare parts
221787303101	THRUST BEARING	TATA spare parts
221787303102	SPHERICAL BEARING CAM SHAFT	TATA spare parts
221787303103	HOUSING SPHERICAL BEARING	TATA spare parts
221787303107	60091969 ROLL BEARING 30315 A DIN 720 BS	TATA spare parts
221787303115	SPHERICAL BEARING DIA 50	TATA spare parts
221787303201	M22 X2.0 U BOLT	TATA spare parts
221787303204	M12X1.75X50HT HEX BOLT	TATA spare parts
221787303205	M10X1.5X20 HEX BOLT CAM SHAFT HOUSING	TATA spare parts
221787303207	U BOLT (YTE75/90)	TATA spare parts
221787303208	CENTRE BOLT (YTE75/90)	TATA spare parts
221787303212	HEX BOLT M12X1.25X75-10.9	TATA spare parts
221787303216	HEX. HEAD BOLT M12X80	TATA spare parts
221787303217	U BOLT/355X97X16X2	TATA spare parts
221787303218	U BOLT/330X97X16X2	TATA spare parts
221787303219	U BOLT/340X97X16X2	TATA spare parts
221787303220	U BOLT/160X76X10X1.5	TATA spare parts
221787303233	M12 X 60 HEX HEAD BOLT 10.9 GRADE	TATA spare parts
221787303234	SOCKET HEAD BOLT M10 X 25 GR 10.9	TATA spare parts
221787303235	SOCKET HEAD BOLT M8 X 85 GR 10.9	TATA spare parts
221787303236	HEX HEAD BOLT M12X40 GR 10.9	TATA spare parts
221787303237	HEX HEAD BOLT M12X50 GR 10.9	TATA spare parts
221787303238	HEX HEAD BOLT M6X15 GR 10.9	TATA spare parts
221787303239	HEX HEAD BOLT M8X30-GR 10.9	TATA spare parts
221787303240	HEX BOLT M8X25 GR10.9	TATA spare parts
221787303241	SOCKET HEAD BOLT M8 X 30-GR 10.9	TATA spare parts
221787303242	SOCKET HEAD BOLT M8 X 50-GR 10.9	TATA spare parts
221787303243	SOCKET HEAD BOLT M8 X 70-GR 10.9	TATA spare parts
221787303244	HEX HEAD BOLT M16X1.5*55 $\frac{1}{2}$ GR 10.9	TATA spare parts
221787303245	HEX BOLT M08 X25 GR8.8	TATA spare parts
221787303246	HEX HEAD BOLT M10 X 100 $\frac{1}{2}$ GR 10.9	TATA spare parts
221787303247	HEX BOLT M08 X25 GR8.8	TATA spare parts
221787303248	HEX BOLT M8X35 8.8	TATA spare parts
221787303302	STRUT BRACKET	TATA spare parts
221787303303	L-L REINFORCEMENT BRACKET FRONT BOTTOM	TATA spare parts
221787303304	L-L REINFORCEMENT BRK FRONT SIDE CROSS	TATA spare parts
221787303305	FRONT HANGER	TATA spare parts
221787303306	REAR HANGER	TATA spare parts
221787303307	LIFTING BRACKET RH	TATA spare parts
221787303308	LIFTING BRACKET LH	TATA spare parts
221787303309	CHASSIS BRACKET	TATA spare parts

221787303310	KNOCK-OFF VALVE MTG BKT	TATA spare parts
221787303311	OIL TANK MTG BKT	TATA spare parts
221787303312	CHASSIS BRACKET	TATA spare parts
221787303313	LIFTING BRACKET LH	TATA spare parts
221787303314	LIFTING BRACKET RH	TATA spare parts
221787303315	HOSE CLAMP ROUTING BRACKET	TATA spare parts
221787303316	AIR CONTROL VALVE MOUNTING BRACKET - SK1	TATA spare parts
221787303317	CHASSIS BRACKET	TATA spare parts
221787303318	CHASSIS BRACKET 170 & 192	TATA spare parts
221787303319	K O BRACKETS	TATA spare parts
221787303320	AIR CONTROL VALVE MOUNTING BRACKET - LPK	TATA spare parts
221787303403	CAMSHAFT BUSH	TATA spare parts
221787303407	EQUALIZER BUSH (BRONZE)	TATA spare parts
221787303408	ANCHOR PIN BUSH	TATA spare parts
221787303411	BUSH	TATA spare parts
221787303412	REAR HINGE OUTER BUSH	TATA spare parts
221787303413	STABILIZER BUSH M10 HOLE	TATA spare parts
221787303414	STABILIZER BUSH (13 HOLE)	TATA spare parts
221787303415	STAB MTG LOCK BUSH 60X45X30	TATA spare parts
221787303416	BEARING BUSH	TATA spare parts
221787303417	BEARING BUSH	TATA spare parts
221787303418	BARREL/TELESCOPIC BUSH/105X45X35	TATA spare parts
221787303418AE	BARREL/TELESCOPIC BUSH -2523	TATA spare parts
221787303420	NYLON BUSH	TATA spare parts
221787303421	BUSH FOR UPPER ARM	TATA spare parts
221787303422	BUSH FOR LOWER ARM	TATA spare parts
221787303423	REAR HINGE OUTER BRACKET BUSH	TATA spare parts
221787303424	REAR HINGE INNER BRACKET BUSH	TATA spare parts
221787303428	DU BUSH	TATA spare parts
221787303429	IGUSS BUSH PSM	TATA spare parts
221787303430	DU BUSH	TATA spare parts
221787304201	TOP CLAMP PLATE	TATA spare parts
221787304203	HOSE ROUTING CLAMP 1 IN P TYPE	TATA spare parts
221787304204	HOSE ROUTING CLAMP 1/2 IN P-TYPE	TATA spare parts
221787304205	HOSE ROUTING CLAMP 3/4 IN P TYPE	TATA spare parts
221787304206	HOSE CLIP FOR 1 3/4 SUCTION	TATA spare parts
221787304301	CIRCLIP ANCHOR PIN	TATA spare parts
221787304302	CIRCLIP CAMSHAFT	TATA spare parts
221787304306	CIRCLIP 78 DIN 472 (82.5X2.5)	TATA spare parts
221787304307	CIRCLIP 97 DIN 472 (102.5X3)	TATA spare parts
221787304308	CIRCLIP 75 GE 50 DO DIN 472	TATA spare parts
221787304309	CIRCLIP/85/90/95	TATA spare parts
221787304309AE	CIRCLIP/85/90/95 2523	TATA spare parts
221787304310	CIRCLIP	TATA spare parts
221787304311	TAIL DOOR HINGE PIN COLLER	TATA spare parts
221787304312	FULCRUM HINGE PIN COLLER	TATA spare parts
221787304703	DUST COVER L UPPER	TATA spare parts

221787304704	DUST COVER L LOWER	TATA spare parts
221787304705	DUST COVER R UPPER	TATA spare parts
221787304706	DUST COVER R LOWER	TATA spare parts
221787304707	HOUSING PTO	TATA spare parts
221787304711	PLASTIC DUMMY COVER FOR TIP VALVE MTG BL	TATA spare parts
221787304902	TAIL LAMP ASSLY RHS 24V	TATA spare parts
221787304906	THERMOSWITCH BS6	TATA spare parts
221787304908	HOUR METER BS6	TATA spare parts
221787304910	METAL CLAD SOCKET	TATA spare parts
221787304910AE	METAL CLAD SOCKET 2523	TATA spare parts
221787304911	SIDE INDICATOR ASSY	TATA spare parts
221787304911AE	SIDE INDICATOR ASSY 2523	TATA spare parts
221787305002	TIPPING VALVE MTG BLOCK	TATA spare parts
221787305003	TIP VALVE MTG BLOCK	TATA spare parts
221787305004	OIL TANK (31 L)	TATA spare parts
221787305005	TIP VALVE MTG BLOCK FOR FMET	TATA spare parts
221787305006	OIL TANK 55L (130 CYL)	TATA spare parts
221787305007	1 BSP MTG BLOCK	TATA spare parts
221787305008	SAE 1 MOUNTING BLOCK	TATA spare parts
221787305009	HYDRAULIC OIL TANK 115L	TATA spare parts
221787305102	D SHACKLE /32 MM	TATA spare parts
221787305102AE	D SHACKLE /32 MM 2523	TATA spare parts
221787305103	FORK/60X15X8	TATA spare parts
221787305306	INTERMEDIATE RING 1.3 MM THICK	TATA spare parts
221787305401	PINION GEAR	TATA spare parts
221787305402	BEVEL GEAR	TATA spare parts
221787305403	INPUT GEAR	TATA spare parts
221787305404	JACKSHAFT(GEARED)	TATA spare parts
221787305405	GEAR	TATA spare parts
221787305406	GEAR BOX 5 TON (MECHANICAL)	TATA spare parts
221787305407	PROPLER SHAFT FOR LRV	TATA spare parts
221787305412	SLIDING GEAR	TATA spare parts
221787305501	HUB(SQUARE AXLE)	TATA spare parts
221787305805	HOSE 1 IN ID X 1500L	TATA spare parts
221787305806	CAP FILTER ELEMENT LIG & CE	TATA spare parts
221787305807	CEMENT TRANSFER HOSE WITH ONE	TATA spare parts
221787305808	PRESSURE HOSE (1/2IN IDX700 LONG)	TATA spare parts
221787305809	SUCTION HOSE	TATA spare parts
221787305810	RETURN LINE HOSE	TATA spare parts
221787305818	1 3/4 IN BSP L.P. HOSE	TATA spare parts
221787305819	1 IN BSP H.P.HOSE X1550L 1 IN BSP STRAIG	TATA spare parts
221787305820	1 IN BSP H.P.HOSE X 3000L BOTH SIDE 1 IN	TATA spare parts
221787305821	1 IN BSP HOSE X1300L 1 IN BSP STRIGHT FS	TATA spare parts
221787305822	HOSE ID3/4 INX2600	TATA spare parts
221787306301	WHEEL ARCH PLASTIC	TATA spare parts
221787306303	BREATHER FILTER CAP	TATA spare parts
221787306304	R L F BODY	TATA spare parts

221787306305	BREATHER FILTER BOWL	TATA spare parts
221787306306	BREATHER FILTER STRAINER	TATA spare parts
221787306307	CABLE TIE 150 MM	TATA spare parts
221787306502	WHEEL NUT RH-ISO	TATA spare parts
221787306505	LANDING LEG MTG BOLT WASHER NUT M16X40	TATA spare parts
221787306506	LANDING LEG MTG BOLT WASHER NUT M16X50	TATA spare parts
221787306509	NYLOCK NUT M16 COARSE THREAD	TATA spare parts
221787306510	NYLOCK NUT M12 FINE THREAD	TATA spare parts
221787306511	NYLOC NUT M8	TATA spare parts
221787306514	NYLOC NUT M14X1.5	TATA spare parts
221787306515	LOCK NUT FOR PUMP PTO	TATA spare parts
221787306517	HEX NUT M8 GR 10.9 DIN 934	TATA spare parts
221787306518	NYLOC NUT M12 GR 10.9 DIN 985	TATA spare parts
221787306519	NYLOCK NUT M8 GR10.9 DIN 934	TATA spare parts
221787306520	NYLOC NUT M16X1.5¿ DIN 985 GR 10.9	TATA spare parts
221787306521	NYLOCK NUT M08 GR8.8 DIN 934	TATA spare parts
221787306522	NYLOC NUT M10¿ GR 10.9 DIN985	TATA spare parts
221787306523	M6 NYLOCK NUT	TATA spare parts
221787306524	M16X 1.5 X10 MM BULK HEAD NUT FERRULE SL	TATA spare parts
221787306525	NYLOC NUT M8X1.0	TATA spare parts
221787306618	BOTTOM PLATE PISTON RAISED	TATA spare parts
221787306619	BOTTOM PLATE PISTON	TATA spare parts
221787306620	DUST COVER YELLOW	TATA spare parts
221787306622	PISTON	TATA spare parts
221787306623	PISTON	TATA spare parts
221787306625	PISTON	TATA spare parts
221787306629	PISTON	TATA spare parts
221787306630	PISTON HEAD	TATA spare parts
221787306631	PISTON¿ 092 X 1432	TATA spare parts
221787306632	PISTON EYE	TATA spare parts
221787306633	PISTON EYE CIRCLIP	TATA spare parts
221787306634	PISTON 111X1432	TATA spare parts
221787306635	PISTON EYE 111	TATA spare parts
221787306636	PISTON O RING	TATA spare parts
221787306713	ANCHOR PIN	TATA spare parts
221787306802	FERRUL	TATA spare parts
221787306806	ACCELERATOR CABLE	TATA spare parts
221787306808	ELBOW 1 1/2 IN + PARTS	TATA spare parts
221787306809	ELBOW 1 1/4 IN + PARTS	TATA spare parts
221787306810	ELBOW FOR PUMP PTO	TATA spare parts
221787306811	ADAPTOR	TATA spare parts
221787306812	MAGNETIC VALVE ADAPTOR	TATA spare parts
221787306813	CENTER PORT PUMP ADAPTOR	TATA spare parts
221787306820	STRAIGHT COUPLING 1/8 IN ST 6MM PUSH-IN	TATA spare parts
221787306821	ELBOW COUPLING 1/8 IN BSP M 6MM PUSH-IN	TATA spare parts
221787306822	ADAPTOR 1 1/4 IN BSP (M) PORT FIT WITH D	TATA spare parts
221787306823	ADAPTOR M39*2 (M) PORT FIT WITH D.S X1 I	TATA spare parts



221787306824	ADAPTOR 1 1/4 IN BSP (M) PORT FIT WITH D	TATA spare parts
221787306825	ADAPTOR 3/4 IN BSP (M) PORT FIT WITH D.S	TATA spare parts
221787306826	ELBOW M26 X 1.5 (M) PORT FIT WITH CHECK	TATA spare parts
221787306827	ADAPTOR 3/4 IN BSP(M) PORT FIT WITH D.S	TATA spare parts
221787306828	ADAPTOR 1 1/4 BSP(M) PORT FIT WITH D.S X	TATA spare parts
221787306829	ELBOW 1 BSP FEMALE SWIVEL X 1 BSP (M)	TATA spare parts
221787306830	ADAPTOR 3/4 BSP(M) PORT FIT WITH D.S X	TATA spare parts
221787306831	ADAPTOR 1 BSP (M) PORT FIT WITH D.S X 3	TATA spare parts
221787306832	ADAPTOR 1 BSP (M) PORT FIT X 1 BSP(M)	TATA spare parts
221787306833	ADAPTOR 1 BSP (M) PORT FIT X 1 BSP(M)	TATA spare parts
221787306834	POPPET VALVE 1 1/2 IN BSP (M) X 1 3/4 IN	TATA spare parts
221787306835	ADAPTOR M26*1.5 (M) PORT FIT WITH D.S X	TATA spare parts
221787306836	ADAPTOR 1/2 IN BSP (M) PORT FIT WITH D.S	TATA spare parts
221787306837	ELBOW 1/2 IN BSP FEMALE SWIVEL X 3/4 IN	TATA spare parts
221787306838	T 1/4 IN	TATA spare parts
221787306839	CONNECTOR WITH FERRULE 1/4 X3/8 IN	TATA spare parts
221787306840	CONNECTOR WITH FERRULE M12X1.5X3/8	TATA spare parts
221787306841	NYLON TUBE 3/8 IN X1/4 IN YELLOW	TATA spare parts
221787306842	NYLON TUBE 3/8IN X1/4 IN RED	TATA spare parts
221787306904	FLANGE PIPE (328 L)	TATA spare parts
221787306906	AIR TUBE¿ OD6MMXID4MM(MTRS)	TATA spare parts
221787306907	BEND PIPE 192	TATA spare parts
221787306908	PVC FLEXIBLE TUBE 10/7 MM COLOUR-BLACK I	TATA spare parts
221787306909	PVC FLEXIBLE TUBE 18/14 MM COLOUR-BLACK	TATA spare parts
221787306910	PVC FLEXIBLE TUBE 24/18 MM COLOUR-BLACK(	TATA spare parts
221787307103	REGISTRATION WHITE PLATE	TATA spare parts
221787307707	LIFTRING FL	TATA spare parts
221787307708	MUDGUARD	TATA spare parts
221787307709	SPARY SUPPRESSION	TATA spare parts
221787307710	SET OF RUBBER O RINGS	TATA spare parts
221787307711	WIPER¿ SEAL¿ 111	TATA spare parts
221787307712	WIPER SEAL 092	TATA spare parts
221787307713	WIPER SEAL 073	TATA spare parts
221787307714	SEAL FOR BOTTOM PLATE	TATA spare parts
221787307715	SAE BLOCK O RING	TATA spare parts
221787307716	CORK GASKET FOR 40 LPM TIPPING VALVE	TATA spare parts
221787307717	SEAL RING FOR CHASSIS BRACKET	TATA spare parts
221787307718	DOWTY SEAL 3/4 IN	TATA spare parts
221787307719	TANK MOUNTING RUBBER PAD (31L)	TATA spare parts
221787307720	MOULDED RUBBER SLEEVE (31L)	TATA spare parts
221787307721	RETURN LINE FILTER GASKET-1	TATA spare parts
221787307722	RETURN LINE FILTER GASKET-2	TATA spare parts
221787307723	RETURN LINE ELEMENT O RING	TATA spare parts
221787307724	BREATHER GASKET	TATA spare parts
221787307725	WIPER¿ SEAL¿ 130	TATA spare parts
221787307726	SEAL FOR BOTTOM PLATE	TATA spare parts
221787307727	PISTON O RING	TATA spare parts

221787307728	TANK MOUNTING RUBBER PAD (55L TO 178L)	TATA spare parts
221787307729	MOULDED RUBBER SLEEVE (55L & 80L)	TATA spare parts
221787307730	SEAL RING FOR CHASSIS BRACKET	TATA spare parts
221787307731	ELEMENT O- RING	TATA spare parts
221787307732	WIPER¿ SEAL¿ 170	TATA spare parts
221787307733	WIPER SEAL 150	TATA spare parts
221787307734	SEAL FOR BOTTOM PLATE- 192	TATA spare parts
221787307735	PISTON 111 O RING	TATA spare parts
221787307736	MOULDED RUBBER SLEEVE ( 115L & 178L)	TATA spare parts
221787307801	DUST SEAL CAMSHAFT	TATA spare parts
221787307802	O RING CAMSHAFT	TATA spare parts
221787307803	LIP SEAL 5MM	TATA spare parts
221787307823	OIL SEAL 111	TATA spare parts
221787307824	OIL SEAL 092	TATA spare parts
221787307825	OIL SEAL 073	TATA spare parts
221787307826	OIL SEAL 130	TATA spare parts
221787307827	OIL SEAL 170	TATA spare parts
221787307828	OIL SEAL 150	TATA spare parts
221787307903	EQUALIZER SHAFT	TATA spare parts
221787307905	AXLE SHAFT(SQUARE)	TATA spare parts
221787307906	REAR HINGE SHAFT	TATA spare parts
221787307907	REAR HINGE SHAFT 75X994L	TATA spare parts
221787307908	SHAFT PIN/115X36X25	TATA spare parts
221787307909	PTO GBS 40 WITH 44 CC	TATA spare parts
221787307913	SHAFT & BUSH¿ ASSY	TATA spare parts
221787307914	INPUT SHAFT	TATA spare parts
221787307915	PROPELLER SHAFT	TATA spare parts
221787308266	INNER STOPRING	TATA spare parts
221787308267	INNER STOPRING FL 110	TATA spare parts
221787308269	BASE	TATA spare parts
221787308271	BASE	TATA spare parts
221787308275	STAGE	TATA spare parts
221787308278	STAGE	TATA spare parts
221787308281	STAGE	TATA spare parts
221787308284	STAGE	TATA spare parts
221787308285	SLIDER MK4	TATA spare parts
221787308286	SLIDER FL	TATA spare parts
221787308287	SLIDER FL 129/HP 129(2X1/2) MK4	TATA spare parts
221787308288	LIFT RING	TATA spare parts
221787308289	LIFT RING	TATA spare parts
221787308290	BASE	TATA spare parts
221787308291	REAR ATTACHEMENT PLATE	TATA spare parts
221787308292	ATTACHMENT PLATE 1	TATA spare parts
221787308293	ATTACHMENT PLATE 2	TATA spare parts
221787308294	ATTACHMENT PLATE 3	TATA spare parts
221787308295	ATTACHMENT PLATE 4	TATA spare parts
221787308296	LOWER PIVOT	TATA spare parts

221787308297	SPRING PIVOT	TATA spare parts
221787308298	UPPER PIVOT	TATA spare parts
221787308299	HEX HEAD BOLT M16X110-10.9	TATA spare parts
221787308502	SOCKET HEAD M8 X 25 GR 10.9	TATA spare parts
221787308503	SOCKET HEAD M10 X 40 GR 10.9	TATA spare parts
221787308603	ALLU PACKING	TATA spare parts
221787308605	JOINT FOR EXH INLET	TATA spare parts
221787308606	CYLINDER MOUNTING SPACER	TATA spare parts
221787308701	SPRING SEAT-L(LOW-50MM)	TATA spare parts
221787308702	BRAKE RETURN SPRING	TATA spare parts
221787308704	PIN RETURN SPRING	TATA spare parts
221787308801	WHEEL STUD RH-ISO	TATA spare parts
221787308802	SET BOLT M8X1.25X35- 8.8	TATA spare parts
221787309007	KNOCK OFF VALVE	TATA spare parts
221787309008	POPPET VALVE 1 1/2 IN BSP (M) X 1 1/4 IN	TATA spare parts
221787309205	WASHER ANCHOR PIN	TATA spare parts
221787309206	SPACER WASHER CAMSHAFT	TATA spare parts
221787309207	M10 EXTERNAL STAR WASHER	TATA spare parts
221787309209	EQUALIZER WASHER	TATA spare parts
221787309214	HARDENED WASHER M16 32/17X5	TATA spare parts
221787309215	THICK WASHER M12 (5MM)	TATA spare parts
221787309216	PLAIN WASHER M8	TATA spare parts
221787309217	STABILIZER LOCKING SPLIT WASHER	TATA spare parts
221787309226	COPPER WASHER	TATA spare parts
221787309228	M8 SPRING WASHER SQ. SECTION	TATA spare parts
221787309229	PLAIN WASHER M8 DIN 125	TATA spare parts
221787309230	M12 HARDENED WASHER 29/13*4	TATA spare parts
221787309231	PLAIN WASHER M12 DIN 125	TATA spare parts
221787309232	PLAIN WASHER M6 DIN 125	TATA spare parts
221787309233	M16 HARDENED WASHER 32/17*5	TATA spare parts
221787309234	M6 SPRING WASHER	TATA spare parts
221787309235	HEX HEAD M10 X 15 GR 10.9 SERRATED WASHE	TATA spare parts
221787309236	HEX HEAD M10 X 15 GR 10.9 SERRATED WASHE	TATA spare parts
221787309237	WASHER M8	TATA spare parts
221787309238	TAILDOOR HINGE WASHER 10T	TATA spare parts
221787309903	LANDING LEG(GEARED)	TATA spare parts
221787309904	LANDING LEG (NON-GEARED)	TATA spare parts
221787309905	LANDING LEG(HANDLE)	TATA spare parts
221787309906	LANDING LEG(CONNECTING PIPE WITH FASTNER	TATA spare parts
221787309922	EQUALIZER HANGER	TATA spare parts
221787309924	M8X1.0EQUALIZER SHAFT GREASE NIPPLE	TATA spare parts
221787309925	ADJUSTABLE TORQUE ARM SCREW(350MM)	TATA spare parts
221787309926	FIXED TORQUE ARM(YTE75/90)	TATA spare parts
221787309927	EQUALIZER	TATA spare parts
221787309928	ADJUSTABLE TORQUE ARM SCREW(CENTRE260N	TATA spare parts
221787309929	ADJUSTABLE TORQUE ARM END R/H	TATA spare parts
221787309930	ADJUSTABLE TORQUE ARM END L/H	TATA spare parts

221787309931	ADJUSTABLE TORQUE ARM SCREW(CENTRE350M	TATA spare parts
221787309932	ADJUSTABLE TORQUE ARM SCREW(CENTRE420M	TATA spare parts
221787309933	TORQUE ARM PIN BUSH (POLY)	TATA spare parts
221787309935	GREASE NIPPLE EXTENSION	TATA spare parts
221787309936	M8X1EQUALIZER SHAFT PLUG	TATA spare parts
221787309941	RUPD	TATA spare parts
221787309943	CAM ROLLER	TATA spare parts
221787309944	ROLLER RETAINER WIRE	TATA spare parts
221787309948	UNIVERSAL CRANK	TATA spare parts
221787309986	SPARE COMPLETE CYLINDER	TATA spare parts
221787309987	PUMP-PTO ASSY	TATA spare parts
221787309992	TIPPING CYLINDER	TATA spare parts
221787309995	60017776 RUBBER RING BS6	TATA spare parts
221787318200	HEX HEAD BOLT M16X150-10.9	TATA spare parts
221787318201	LIFTING BRACKET FC129 RH	TATA spare parts
221787318202	LIFTING BRACKET FC129 LH	TATA spare parts
221787318203	LIFTING BRACKET FC149 RH	TATA spare parts
221787318204	LIFTING BRACKET FC149 LH	TATA spare parts
221787318205	LEGS LOCK FOR TOW HITCH	TATA spare parts
221787318205AE	LEGS FOR TOW HITCH 2523	TATA spare parts
221787318206	LEGS FOR TOW HITCH	TATA spare parts
221787318207	TOW HITCH ASSY	TATA spare parts
221787318207AE	TOW HITCH ASSY. 2523	TATA spare parts
221787318208	PAWL PUSH LEVER	TATA spare parts
221787318208AE	PAWL PUSH LEVER 2523	TATA spare parts
221787318209	RATCHET	TATA spare parts
221787318209AE	RATCHIT 2523	TATA spare parts
221787318210	COMP SPRING LRV/60X13X10X1.5 MM	TATA spare parts
221787318210AE	COMP SPRING /60X13X10X1.5-2523	TATA spare parts
221787318211	STUD ROD/100X6	TATA spare parts
221787318211AE	STUD ROD/100X6 2523	TATA spare parts
221787318212	PAWL	TATA spare parts
221787318212AE	PAWL 2523	TATA spare parts
221787318213	BOOM DRUM SHAFT	TATA spare parts
221787318213AE	BOOM DRUM SHAFT 2523	TATA spare parts
221787318214	BOOM SHIV CABLE YOKE	TATA spare parts
221787318214AE	BOOM SHIV CABLE YOKE 2523	TATA spare parts
221787318218	CRANK HANDLE ASSY	TATA spare parts
221787318219	BASE 130X1323(INNER STOPRING FITTED)	TATA spare parts
221787318220	STAGE 111X1286(INNER STOPRING FITTED)	TATA spare parts
221787318221	STAGE 092X1286(INNER STOPRING FITTED)	TATA spare parts
221787318222	INNER GUIDE RING 130	TATA spare parts
221787318223	INNER GUIDE RING 111	TATA spare parts
221787318224	OUTER GUIDE RING 111	TATA spare parts
221787318225	INNER GUIDE RING 092	TATA spare parts
221787318226	OUTER GUIDE RING 092	TATA spare parts
221787318227	OUTER GUIDE RING 073	TATA spare parts

221787318228	INNER SNAP RING 130	TATA spare parts
221787318229	OUTER STOP RING 111	TATA spare parts
221787318230	OUTER SNAP RING 111	TATA spare parts
221787318231	INNER SNAP RING 111	TATA spare parts
221787318232	OUTER STOP RING 092	TATA spare parts
221787318233	OUTER SNAP RING 092	TATA spare parts
221787318234	INNER SNAP RING 092	TATA spare parts
221787318235	OUTER STOP RING 073	TATA spare parts
221787318236	OUTER SNAP RING 073	TATA spare parts
221787318237	OIL TANK STEEL STRAPS (31L)	TATA spare parts
221787318238	BASE 150 X 1464(INNER STOPRING FITTED)	TATA spare parts
221787318239	STAGE 130 X 1427(INNER STOPRING FITTED)	TATA spare parts
221787318240	STAGE 111 X 1427(INNER STOPRING FITTED)	TATA spare parts
221787318241	INNER GUIDE RING 150	TATA spare parts
221787318242	OUTER GUIDE RING 130	TATA spare parts
221787318243	INNER SNAP RING 150	TATA spare parts
221787318244	OUTER STOP RING 130	TATA spare parts
221787318245	OUTER SNAP RING 130	TATA spare parts
221787318246	OIL TANK STEEL STRAP (55L & 80L)	TATA spare parts
221787318247	AIR TANK BRACKET (50 LITERS)	TATA spare parts
221787400101	HAMMER ASSEMBLY	TATA spare parts
221787400102	STRICKER PLATE ASSY.	TATA spare parts
221787400103	ASSY TAIL DOOR	TATA spare parts
221787400105	TAILDOOR ASSEMBLY	TATA spare parts
221787406701	FORK PIN	TATA spare parts
221787406702	TAIL DOOR HINGE PIN	TATA spare parts
221787406703	BODY PROP PIN	TATA spare parts
221787406704	PIN FOR CAM MOUNTING	TATA spare parts
221787406705	FORK PIN	TATA spare parts
221787406706	STABILIZER MTG. PIN	TATA spare parts
221787406707	STABILIZER HINGE PIN 45X570L	TATA spare parts
221787406708	PIN (COLLER)/30X167X40 LRV	TATA spare parts
221787406708AE	PIN (COLLER)/30X167X40 LRV 2523	TATA spare parts
221787406709	PIN/30X150 LRV	TATA spare parts
221787406709AE	PIN/30X150 LRV 2523	TATA spare parts
221787406710	PIN/30X108 LRV	TATA spare parts
221787406710AE	PIN/30X108 LRV 2523	TATA spare parts
221787406711	LOCKING PIN HANDLE/30X37X16	TATA spare parts
221787406711AE	LOCKING PIN HANDLE/30X37X16-2523	TATA spare parts
221787406712	PIN/30X136 LRV	TATA spare parts
221787406712AE	PIN/30X136 LRV 2523	TATA spare parts
221787406713	SHAFT PIN/300X20	TATA spare parts
221787406714	FORK PIN FOR FORK/20X10	TATA spare parts
221787406715	R/T PIN/160X32X25	TATA spare parts
221787406716	MS PIN/90X8	TATA spare parts
221787406717	MS PIN/50X10	TATA spare parts
221787406718	MS PIN/108X20	TATA spare parts

221787406719	PIN/25X150	TATA spare parts
221787406720	PIN/25X131	TATA spare parts
221787406721	MS PIN/50X20	TATA spare parts
221787406722	LOCKING PIN/30X149X50	TATA spare parts
221787406722AE	LOCKING PIN/30X149X50 2523	TATA spare parts
221787406723	O.B.LEG PIN/60X225	TATA spare parts
221787406723AE	O.B.LEG PIN/60X225 2523	TATA spare parts
221787406724	MS PIN/55X25X12	TATA spare parts
221787406724AE	MS PIN/55X25X12 2523	TATA spare parts
221787406725	MS PIN (HOLDING )/150X12	TATA spare parts
221787406725AE	MS PIN (HOLDING )/150X12 2523	TATA spare parts
221787406726	PIN LEG JACK /25X129X40 LRV	TATA spare parts
221787406726AE	PIN LEG JACK /25X129X40 LRV-2523	TATA spare parts
221787406727	PIN/25X60	TATA spare parts
221787406727AE	PIN/25X60 2523	TATA spare parts
221787406728	MS PIN/125X15	TATA spare parts
221787406732	SIDE BOARD¿ FLAP HINGE PIN	TATA spare parts
221787406733	TAIL DOOR HINGE PIN	TATA spare parts
221787406734	FULCRUM HINGE PIN	TATA spare parts
221787406735	CYLINDER BOTTOM HINGE PIN	TATA spare parts
221787406741	TRUNION PIN CAP DIA 50 X 55	TATA spare parts
221787406742	TRUNION PIN CAP DIA 60 X 55	TATA spare parts
221787406743	CYLINDER MOUNTING PIN STD BODY	TATA spare parts
221787406744	SPLIT PIN ¿10 X 90MM	TATA spare parts
221787406745	CYLINDER MOUNTING PIN ROCK BODY	TATA spare parts
221787407101	LOCKING PROFILE PLATE	TATA spare parts
221787407102	REAR ATTACHMENT PLATE LH	TATA spare parts
221787407103	REAR ATTACHMENT PLATE RH	TATA spare parts
221787407104	RIBBED ATTACHMENT PLATE -3 LH	TATA spare parts
221787407105	RIBBED ATTACHMENT PLATE -3 RH	TATA spare parts
221787407106	RIBBED ATTACHMENT PLATE -4 LH	TATA spare parts
221787407107	RIBBED ATTACHMENT PLATE -4 RH	TATA spare parts
221787407109	ATTACHMENT PLATE 1-RH	TATA spare parts
221787407110	ATTACHMENT PLATE 1-LH	TATA spare parts
221787407111	ATTACHMENT PLATE 2-LH	TATA spare parts
221787407112	ATTACHMENT PLATE 2-RH	TATA spare parts
221787407115	CYL. MTG. BLOCK STOPPER 12X12X40	TATA spare parts
221787407116	BOTTOM PLATE	TATA spare parts
221787407117	BOTTOM LOCK PLATE	TATA spare parts
221787407118	LOCKING PLATE FOR M12 BOLT	TATA spare parts
221787407119	BOTTOM PLATE	TATA spare parts
221787407120	BOTTOM LOCK¿ PLATE	TATA spare parts
221787407121	BOTTOM PLATE 192	TATA spare parts
221787407122	BOTTOM LOCK¿ PLATE 192	TATA spare parts
221787407124	TAILDOOR HINGE L PLATE	TATA spare parts
221787408701	TENSION SPRING	TATA spare parts
221787408702	SPRING	TATA spare parts

221787408703	COMP SPRING LRV/70X29X25X MM	TATA spare parts
221787408703AE	COMP SPRING LRV/70X29X25 -2523	TATA spare parts
221787408704	COMP SPRING LRV FOR ADDA/80X32X22X5	TATA spare parts
221787408705	COMP SPRING LRV/105X20 X15X2.5 MM	TATA spare parts
221787408706	SPRING ROD/383X20	TATA spare parts
221787408708	SPRING	TATA spare parts
221787408715	TAIL DOOR LOCKING SPRING	TATA spare parts
221787909904	PIN	TATA spare parts
221787909905	TAIL DOOR LOCKING ASSY	TATA spare parts
221787909907	HANDLE	TATA spare parts
221787909908	FOOT STEP	TATA spare parts
221787909909	C-SECTION	TATA spare parts
221787990114	KIT FOR ASSY SK1613/36 SUBFRAME	TATA spare parts
221787990116	SEAL KIT	TATA spare parts
221787990117	SPARE SEAL KIT	TATA spare parts
221787990129	SEAL KIT TAILGATE CYLINDER	TATA spare parts
221787990130	SEAL KIT PACKER CYLINDER	TATA spare parts
221787990131	SEAL KIT SWEEPER CYLINDER	TATA spare parts
221787990133	PULLING PIPE ASSEMBLY	TATA spare parts
221787990134	SPHERICAL EYE D.50 DO	TATA spare parts
221787990151	PISTON EYE 092 WITH SPHERICAL BEARING FI	TATA spare parts
221787990154	KIT	TATA spare parts
221787990158	HYDRAULIC CYLINDER	TATA spare parts
221787999916	60092943 RING NILO 3015 AK BS6	TATA spare parts
221787999917	SNAP RING	TATA spare parts
221787999919	AIR CONTROL VALVE COVER	TATA spare parts
221787999920	KNOCK-OFF STOPPER	TATA spare parts
221787999921	REAR HINGE RIB -1	TATA spare parts
221787999922	REAR HINGE RIB -2	TATA spare parts
221787999923	REAR HINGE RIB -3	TATA spare parts
221787999924	FRONT LOWER PIVOT RH	TATA spare parts
221787999925	BREATHER EXTENSION	TATA spare parts
221787999926	CANVAS CANOPY/TARPOULINE ALL TYPE	TATA spare parts
221787999927	BACK REST FOR LRV	TATA spare parts
221787999929	ANCHOR CHAIN/12 MMX6 FEET WITH HOOK	TATA spare parts
221787999929AE	ANCHOR CHAIN/12X6 W/HOOK -2523	TATA spare parts
221787999930	SPRING ROD/156X35	TATA spare parts
221787999930AE	SPRING ROD/156X35 2523	TATA spare parts
221787999931	BOOM HEEL	TATA spare parts
221787999931AE	BOOM HEEL 2523	TATA spare parts
221787999932	CHAIN MS/8 MM	TATA spare parts
221787999932AE	CHAIN MS/8 MM 2523	TATA spare parts
221787999933	SHOW ASSY	TATA spare parts
221787999933AE	SHOW ASSY. 2523	TATA spare parts
221787999938	TOW CHAIN/16 MMX6 METER WITH HOOK	TATA spare parts
221787999938AE	TOW CHAIN WITH HOOK -2523	TATA spare parts
221787999939	WIRE ROPE SLING 11MMX6DIAX19/11X16 MTR S	TATA spare parts

221787999939AE	WIRE ROPE SLING 11MMX6DX19-2523	TATA spare parts
221787999940	DUMMY NYLON	TATA spare parts
221787999941	1.1 LITER FUEL FILTER KIT	TATA spare parts
221787999942	LUB OIL FILTER ELEMENT	TATA spare parts
221787999943	CANVAS CANOPY/TARPOULINE ALL TYPE	TATA spare parts
221787999943AE	CANVAS CANOPY-2523	TATA spare parts
221787999944	CUSHION SEAT/1225X450X50	TATA spare parts
221787999944AE	CUSHION SEAT/1225X450X50 2523	TATA spare parts
221787999945	CUSHION BACK SEAT/1225X280X50	TATA spare parts
221787999945AE	CUSHION BACK SEAT -2523	TATA spare parts
221787999946	HYDROLIC WINCH MNT 35 ES/DINAMIC OIL	TATA spare parts
221787999946AE	HYDROLIC WINCH MNT DINAMIC -2523	TATA spare parts
221787999947	T-PNEUMATIC CONNECTOR	TATA spare parts
221787999949	PTO ACTUATION VALVE	TATA spare parts
221787999960	FILTER ELEMENT	TATA spare parts
221787999961	OIL LEVEL INDICATOR 1-1/4 BSP	TATA spare parts
221787999962	AIR TEE 6MM PUSH-IN	TATA spare parts
221787999963	BREATHER ELEMENT	TATA spare parts
221787999964	GREASE NIPPLE M8	TATA spare parts
221787999965	QUICK RELEASE COUPLING (11900600057)	TATA spare parts
221787999970	M22X1.5 X M16X1.5 ADAPTOR RING	TATA spare parts
221849200102	ASSY. BRACKET(EXHAUST MOUNTING)	TATA spare parts
221970803201	U-BOLT	TATA spare parts
221970900105	SUPD ASSY LH	TATA spare parts
221970900106	SUPD ASSY RH	TATA spare parts
221970900137	SUPD ASSY	TATA spare parts
221970900139	ASSEMBLY SPOT WELDED SUPD	TATA spare parts
221970900141	ASSEMBLY SPOT WELD SUPD LH	TATA spare parts
221970900142	ASSEMBLY SPOT WELD SUPD	TATA spare parts
221970900145	SUPD ASSY LH	TATA spare parts
221970900146	SUPD ASSY LH	TATA spare parts
221970900147	SUPD ASSY RH	TATA spare parts
221970900148	ASSEMBLY SPOT WELD SUPD	TATA spare parts
221970900150	SUPD ASSY RH BS6	TATA spare parts
221970900151	SUPD ASSY RH BS6	TATA spare parts
221970900152	SUPD ASSY RH BS6	TATA spare parts
221970900154	SUPD ASSY RH BS6	TATA spare parts
221970905301	FOAM PACKING BS6	TATA spare parts
221970905305	FOAM PACKING BS6	TATA spare parts
221970905308	FOAM PACKING BS6	TATA spare parts
221970905309	FOAM PACKING BS6	TATA spare parts
221970905312	FOAM PACKING BS6	TATA spare parts
221970905313	FOAM PACKING BS6	TATA spare parts
221970908241	SUPPORT BKT	TATA spare parts
221970908242	SUPPORT BKT	TATA spare parts
221970908243	SUPPORT BKT	TATA spare parts
221970908246	SUPPORT BKT	TATA spare parts



221970908247	SUPPORT BKT	TATA spare parts
221970908248	SUPPORT BKT	TATA spare parts
221970908249	SUPPORT BKT	TATA spare parts
221970908250	SUPPORT BKT	TATA spare parts
221970990106	SUPD KIT	TATA spare parts
221970990107	SUPD KIT FOR LPT 3723/62WB	TATA spare parts
221970990109	KIT-DRIVE AWAY SUPD	TATA spare parts
222029100103	ASSY SUPPORT BKT COPMLETE (CLUTCH)	TATA spare parts
222029100105	ASSY BRAKE PEDAL LEVER	TATA spare parts
222029100106	ASSY BRACKET (CLUTCH & BRAKE PEDAL)	TATA spare parts
222029100107	CLUTCH PIPE FOR CASSPIER	TATA spare parts
222032600101	ASSY SHOCK ABSORBER MTG BKT LH	TATA spare parts
222032600102	ASSY SHOCK ABSORBER MTG BKT REAR- RH	TATA spare parts
222041110101	ASSY PROP SHAFT FRONT(GB TO AGB/TC)	TATA spare parts
222047600101	FUEL RETURN LINE FOR CASSPIER VEHICLE	TATA spare parts
222047600102	FUEL SUCTION LINE FOR CASSPIER VEHICLE	TATA spare parts
222049100103	ASSY EXHAUST PIPE THIRD (81.2 ODX1.6THK)	TATA spare parts
222049100104	ASSY EXHAUST PIPE FOURTH (81.2ODX1.6THK)	TATA spare parts
222054110101	ASSY CU BATTERY CABLE -VE	TATA spare parts
222054209901	SPEEDO METER (1:0.75)	TATA spare parts
222109130102	ASSY BKT - AIR FILTER MTG	TATA spare parts
222109130203	ASSY BRACKET WITH CLAMP	TATA spare parts
222124200101	ASSY.BRACKET (ENG.MTG.REAR BOTTOM)	TATA spare parts
222129300101	ASSY.TUBE(O.D-6) M/CYL.TO INT.JOINT.	TATA spare parts
222129300102	ASSY TUBE(O.D-6) INT.JIONT TO CL.BOOSTER	TATA spare parts
222131000101	ASSY FRAME (960 ROH)	TATA spare parts
222131000105	ASSY FRAME COMPLETE	TATA spare parts
222131200106	ASSY.SUPPORT RH ENG.CROSS MEMB.FRONT	TATA spare parts
222131200107	ASSY SUPPORT LH ENG.CROSS MEMB FRONT	TATA spare parts
222131207102	REINFORCEMENT TOP LH	TATA spare parts
222131207103	REINFORCEMENT TOP RH	TATA spare parts
222131207105	REINFORCEMENT BOTTOM LH	TATA spare parts
222131207106	REINFORCEMENT BOTTOM RH	TATA spare parts
222131207107	SPACER PLATE	TATA spare parts
222131208201	END CROSS MEMBER	TATA spare parts
22213120820135	END CROSS MEMBER_UNPAINTED	TATA spare parts
222131307101	REINFORCMENT BOTTOM RH	TATA spare parts
222131307102	REINFORCMENT BOTTOM LH	TATA spare parts
222131307103	REINFORCEMENT TOP RH	TATA spare parts
222131307104	REINFORCEMENT TOP LH	TATA spare parts
222132100102	BUMP STOPPER LH	TATA spare parts
222132100103	BUMP STOPPER RH	TATA spare parts
222132103301	SPRING HANGER BRACKET	TATA spare parts
222132107101	CASTER PLATE	TATA spare parts
222132404201	U CLAMP	TATA spare parts
222133000101	ASSY.FRONT AXLE COMP.W/BRAKES (SPIGOTTED)	TATA spare parts
222141100101	CROSS ASSY.	TATA spare parts

222141105101	FLANGE YOKE	TATA spare parts
222141106501	HEX NUT	TATA spare parts
222141108201	CHANNEL (GUARD MTG)	TATA spare parts
222141110101	ASSY.FRONT PROP. SHAFT W C.B 1616SE BS3	TATA spare parts
222141110102	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
222141110103	COUPLING FLANGE ASSY.	TATA spare parts
222141120101	ASSY. PROP. SHAFT REAR BS3	TATA spare parts
222141120102	ASSY. REAR PROP SHAFT	TATA spare parts
222141120103	ASSY. REAR PROP SHAFT 1616 SE BS3	TATA spare parts
222141120104	LONG FORK SUB ASSY	TATA spare parts
222141120105	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
222141120106	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
222141120107	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
222141120109	ASSY PROP SHAFT (REAR)	TATA spare parts
222141300101	CENTRE BEARING ASSY.	TATA spare parts
222141303301	BRACKET (FOR CENTRE BEARING)	TATA spare parts
222143200101	ASSEMBLY BRACKET RH(AIR TANK MTG.)	TATA spare parts
222143200102	ASSEMBLY BRACKET LH(AIR TANK MTG.)	TATA spare parts
222143900101	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
222143900105	ASSY.TUBE O.D 15 (1ST COMP.PIPE)	TATA spare parts
222143900107	ASSY.TUBE O.D 15 (3RD COMP. PIPE)	TATA spare parts
222143900108	ASSY.TUBE W/CRIMPED R/HOSE (COMP.INLET)	TATA spare parts
222143900111	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
222143900114	ASSY TUBE WITH TEFLOC HOSE	TATA spare parts
222143900115	ASSY.COMPRESSOR PIPE 2ND	TATA spare parts
222143900116	ASSY.COMPRESSOR PIPE 3RD	TATA spare parts
222143900117	ASSY COMPRESSORE PIPE 2ND	TATA spare parts
222143900123	ASSY.COMPRESSOR PIPE FIRST	TATA spare parts
222143900124	ASSY.COMP.PIPE SECOND	TATA spare parts
222143900125	ASSY. COMP. PIPE SECOND	TATA spare parts
222143900126	ASSY. COMP .PIPE THIRD	TATA spare parts
222146000101	ASSY STG BKT	TATA spare parts
222147600101	ASSY.TUBE W/CRIMPED R/HOSE	TATA spare parts
222147600102	ASSY.TUBE W/CRIMPED R/HOSE	TATA spare parts
222147600103	ASSY.TUBE W/CRIMPED R/HOSE.	TATA spare parts
222147600104	ASSY.TUBE W/CRIMPED R/HOSE.	TATA spare parts
222147600110	ASSY.NYLON PIPE WITH CRIMPED RUBBER HOSE	TATA spare parts
222147600111	ASSY. NYLON PIPE W/CRIMPED RUBBER HOSE	TATA spare parts
222147600112	ASSY.NYLON PIPE WITH CRIMPED RUBBER HOSE	TATA spare parts
222149100101	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
222149200101	ASSY INTERMEDATE PIPE	TATA spare parts
222149200102	ASSY THIRD PIPE EXHAUST	TATA spare parts
222149208201	BRACKET (EXHAUST MTG.)	TATA spare parts
222149208202	BRACKET	TATA spare parts
222154209903	INSTRUMENT CLUSTER(1.04)ESPDO24V	TATA spare parts
222154209904	INST. CLSTR(1 : 0.93)ESPDO 24V	TATA spare parts
222154209914	ESPEEDOMETER RATIO-1.04 (0-140)	TATA spare parts

222154209916	ESPEEDOMETER SPARE RATIO-0.93 (0-140)	TATA spare parts
222154209917	ESPEEDOMETER SPARE RATIO-1.04 (0-140)	TATA spare parts
222154660105	W/H MAIN SK1616/697BSII	TATA spare parts
222187000101	ASSY KIT COMPL-8.5CUM-BOX & HYD TIPPING	TATA spare parts
222187100101	ASSY SUB-FRAME(8.5CUM-SCOOP)	TATA spare parts
222209130102	ASSY CLAMP(INTAKE PIPE HOLDER)	TATA spare parts
222209130108	ASSY AIR INTAKE PIPE	TATA spare parts
222209135801	HOSE AIR FILTER	TATA spare parts
222209138203	BRACKET(1ST AIRINTAKE PIPE MTG.)	TATA spare parts
222209145801	REDUCER HOSE (AIR FILTER END)	TATA spare parts
222214606901	PIPE (TC TO IC)	TATA spare parts
222214606902	PIPE (IC TO ENGINE)	TATA spare parts
222214606903	PIPE (IC TO ENGINE)	TATA spare parts
222216100101	CONTAINER (ECU 697TCIC BS3)	TATA spare parts
222224200101	ASSY.BRACKET-RH(ENG.MTG.-REAR BOTTOM)	TATA spare parts
222224200102	ASSY.BRACKET-LH(ENG.MTG.-REAR BOTTOM)	TATA spare parts
222224200103	ASSY BRACKET-RH(ENG MTG REAR TOP)	TATA spare parts
222224200104	ASSY BRACKET-LH(ENG MTG REAR TOP)	TATA spare parts
222226800102	ASSY BRACKET G/S LEVER MTG	TATA spare parts
222226800105	ASSY.TURNING TUBE (WITH BUSH)	TATA spare parts
222229100109	ASSY CLUTCH BOOSTER MTG BRACKET	TATA spare parts
222229300101	ASSY PIPE	TATA spare parts
222230100101	ASSY BRACKET (ELECTRONIC ACC. PEDAL MTG)	TATA spare parts
222231000101	ASSY. FRAME COMPLETE	TATA spare parts
222231000106	FRAME ASSY WITH FITMENT	TATA spare parts
222231200101	ASSY ENG CROSS MEMBER-FRONT WITH SUPPORT	TATA spare parts
222231200102	ASSY ENG CROSS MEMBER REAR	TATA spare parts
222231200106	ASSY SUPPORT ENG X-MEMBER REAR	TATA spare parts
222231200109	ASSY. SUPPORT (ENG. C/M FRONT)	TATA spare parts
222231200110	ASSY. SUPPORT-LH(ENG C/M FRONT)	TATA spare parts
222231200111	ASSY. CROSS MEMBER(ENG FRONT)	TATA spare parts
222231200112	ASSY CROSS MEMBER REAR	TATA spare parts
222231200113	ASSY 4TH CROSS MEMBER	TATA spare parts
222231700101	ASSY NOISE SHIELD	TATA spare parts
222232100102	ASSY. LEAF SPRING FRONT BS1/2/3/4	TATA spare parts
222232100103	ASSY. FIRST LEAF W/BUSH BS1/2/3/4	TATA spare parts
222232100103DF	MAIN LEAF FRONT W/BUSH LPS4018	TATA spare parts
222232100108	1ST LEAF ASSY WITH BUSH	TATA spare parts
222232100111	PARABOLICLEAFSPRINGASSY FRONT BS6	TATA spare parts
222232100112	1STLEAFASSYWITHBUSH BS6	TATA spare parts
222232107102	SECOND LEAF	TATA spare parts
222232107102DF	SECOND LEAF FRONT LPK1618/2518/LPS4018	TATA spare parts
222232107103	THIRD LEAF	TATA spare parts
222232107104	FOURTH LEAF	TATA spare parts
222232107105	FIFTH LEAF	TATA spare parts
222232107106	SIXTH LEAF	TATA spare parts
222232107107	SEVENTH LEAF	TATA spare parts

222232107108	EIGHTH LEAF	TATA spare parts
222232107109	NINTH LEAF	TATA spare parts
222232107110	9TH LEAF	TATA spare parts
222232107111	8TH LEAF	TATA spare parts
222232107113	7TH LEAF	TATA spare parts
222232107114	6TH LEAF	TATA spare parts
222232107115	5TH LEAF	TATA spare parts
222232107116	4TH LEAF	TATA spare parts
222232107117	3RD LEAF	TATA spare parts
222232107118	2ND LEAF	TATA spare parts
222232107119	10TH LEAF	TATA spare parts
222232107120	SPACER- BS6	TATA spare parts
222232107121	3RDLEAF BS6	TATA spare parts
222232107123	4THLEAF BS6	TATA spare parts
222232107124	2NDLEAF BS6	TATA spare parts
222232400103	REAR SPRING ASSY BS6	TATA spare parts
222232400104	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
222232403201	CENTER BOLT BS6	TATA spare parts
222232403701	BRACKET SPRING HANGER REAR-REAR BS6	TATA spare parts
222232407101	2ND LEAF MAIN SPRING BS6	TATA spare parts
222232407104	SPACER BS6	TATA spare parts
222232407105	6TH LEAF MAIN SPRING BS6	TATA spare parts
222232407106	4TH LEAF MAIN SPRING BS6	TATA spare parts
222232407110	10TH LEAF MAIN SPRING BS6	TATA spare parts
222232407111	5TH LEAF AUX SPRING BS6	TATA spare parts
222232407113	2ND LEAF AUX SPRING BS6	TATA spare parts
222232407114	8TH LEAF MAIN SPRING BS6	TATA spare parts
222232407115	3RD LEAF MAIN SPRING BS6	TATA spare parts
222232407116	9TH LEAF MAIN SPRING BS6	TATA spare parts
222232407117	5TH LEAF MAIN SPRING BS6	TATA spare parts
222232407120	7TH LEAF MAIN SPRING BS6	TATA spare parts
222232407121	6TH LEAF AUX SPRING BS6	TATA spare parts
222232407123	3RD LEAF AUX SPRING BS6	TATA spare parts
222232407125	7TH LEAF AUX SPRING BS6	TATA spare parts
222232407127	4TH LEAF AUX SPRING BS6	TATA spare parts
222232407130	1ST LEAF AUX SPRING BS6	TATA spare parts
222241100101	ASSY. PROP. SHAFT WITH CENTRE BEARING	TATA spare parts
222241100102	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
222241100103	COUPLING FLANGE ASSY	TATA spare parts
222241120103	SHORT FORK TUBE-1514 MM & REAR HOUSING A	TATA spare parts
222241120104	ASSY. PROP SHAFT - 2015 CLOSED	TATA spare parts
222241120109	ASSY PROP SHAFT REAR(CLOSE LENGTH=1500)	TATA spare parts
222241125101	FULL RND FLANGE YOKE	TATA spare parts
222243900101	ASSY. COMPRESSOR INLET PIPE	TATA spare parts
222243900102	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
222243900103	ASSS. COMPRESSOR 3RD PIPE	TATA spare parts
222243900105	ASSY. NYLON PIPE SET COMPLETE	TATA spare parts

222246150104	KIT ASSY. PIPES LPK1616	TATA spare parts
222246800104	ASSY. SUCTION LINE	TATA spare parts
222246800105	ASSY PRESSURE LINE	TATA spare parts
222246800106	ASSY RETURN LINE	TATA spare parts
222246800115	ASSY. PRESSURE PIPE LINE	TATA spare parts
222246800119	RETURN LINE ASSY	TATA spare parts
222246800120	RETURN LINE ASSY	TATA spare parts
222247600101	TANK TO BABY FILTER (ASSY. NYLON SUCTION	TATA spare parts
222247600102	BABY FILTER TO MECH. FEED PUMP (ASSY.NYL	TATA spare parts
222247600103	ASSY. NYLON RETURN PIPE (3RD PIPE)	TATA spare parts
222249200101	ASSY. EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
222249200102	ASSY. EXHAUST FIRST PIPE	TATA spare parts
222249200104	ASSY. INTERMEDIATE PIPE	TATA spare parts
222249200105	ASSY INTERMEDIATE PIPE(MUFFLER END)	TATA spare parts
222249200106	ASSY EXHUAST PIPE (INTERMEDIATE)	TATA spare parts
222250100101	SET COOLING PACKAGE-BSIII	TATA spare parts
222250105803	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
222250506301	JET RING FAN SHROUD	TATA spare parts
222254100101	ECU MTG BKT	TATA spare parts
222254100103	ASSEMBLY MOUNTING BRACKET FOR BATTERY CU	TATA spare parts
222254108201	DC-DC CONVERTER MTG BKT	TATA spare parts
222254110101	ASSY.BATTERY CABLE -VE 900MM (50SQ.MM)	TATA spare parts
222254209903	INTRUMENT CLUSTER 1.04 RATIO LPK-1616	TATA spare parts
222254660102	W/HMAINLPK1616BSIIIERGOPACK	TATA spare parts
222254660104	W/H MAIN LPK1616 BS-III ERGO	TATA spare parts
222254660105	W/H MAIN LPK1616 BSIII ERGO PACK AUTODRA	TATA spare parts
222300300001	PASSENGER DOOR ASSEMBLY - FRONT	TATA spare parts
222301180001	PASSENGER DOOR ASSEMBLY	TATA spare parts
222311020001	PASSENGER DOOR ASSEMBLY(TOWARDS FRONT)	TATA spare parts
222311030001	PASSENGER DOOR ASSEMBLY(TOWARDS FRONT)	TATA spare parts
222315260001	PASSENGER DOOR ASSEMBLY	TATA spare parts
222321220001	NYLON BEARING ID 12.4 OD 28 WITDH 10 BS6	TATA spare parts
222330160001	MOULDED WEATHER STRIP	TATA spare parts
222340150001	MOULDED WEATHER STRIP	TATA spare parts
222524200103	ASSY ENG MTG BKT(REAR)ON FRAME L.H	TATA spare parts
222524200104	ASSY ENG MTG BKT(REAR) RH(ON FRAME)	TATA spare parts
222546101601	ASSY TIE ROD	TATA spare parts
222624100101	ASSY. BRACKET-R.H(ENG. MTG. FRONT)	TATA spare parts
222624100102	ASSY. BRACKET-LH(ENG MTG FRONT)	TATA spare parts
222624200101	ASSY ENG MTG REAR TOP RH	TATA spare parts
222624200102	ASSY ENG MTG REAR BKT LH TOP	TATA spare parts
222628500107	ASSY RUBBER PAD	TATA spare parts
222628500107AE	ASSY RUBBER PAD 1628	TATA spare parts
222630100101	ASSY MTG BRACKET (ACCL PEDAL)	TATA spare parts
222640100102	WHEEL RIM 10X20 125 OFFSET	TATA spare parts
222640100102AE	WHEEL RIM 10X20 125 OFFSET-1828	TATA spare parts
222640300104	ASSY LIFTING ARM COMPLETE	TATA spare parts

222641100103	ASSY.PROPELLER SHAFT (INTER AXLE)	TATA spare parts
222641120105	SHORT FORK AND REAR HOUSING ASSY	TATA spare parts
222646600101	ASSY. STEERING GEAR BOX RATIO 26.2 BS3/4	TATA spare parts
222647100106	ASSY FUEL TANK COMPLETE(300 LTR RECT)	TATA spare parts
222647800101	ASSY BKT FUEL WATER SEPARATOR	TATA spare parts
222649200102	ASSY EXHAUST PIPE ( EXH ELBOW SIDE )	TATA spare parts
222654108205	BATTERY CUT-OFF SW MTG BKT	TATA spare parts
222654209902	INST CLST E-SPDO(2.55)24V BSIII ARMY	TATA spare parts
222654400101	ASSY GRILL GUARD - ASSY 5-CH TAIL LAMP	TATA spare parts
222654400101AE	ASSY GRILL GUARD-ASSYTLAMP -1628	TATA spare parts
222654408201	GRILL GUARD MTG BRKT(5 CH.TAIL LAMP)	TATA spare parts
222654504901	DIFFERENTIAL LOCK SWITCH BS6	TATA spare parts
222744000141	KIT-HYDRAULIC BS6	TATA spare parts
222744000149	KIT-HYDRAULIC BS6	TATA spare parts
222744100102	TIPPING ASSY	TATA spare parts
222744105802	HOSE PUMP TO VALVE	TATA spare parts
222744105819	HOSE ASSY BS6	TATA spare parts
222744105822	SUCTION HOSE BS6	TATA spare parts
222744105823	PRESSURE HOSE ASSY BS6	TATA spare parts
222744105824	PRESSURE HOSE ASSY BS6	TATA spare parts
222744109905	AIR CONTROL VALVE	TATA spare parts
222744990101	TANK ASSY + METAL STRAPS	TATA spare parts
222744990106	CYLINDER ASSY	TATA spare parts
222744990109	TANK ASSY OIL TANK + METAL STRAPS	TATA spare parts
222744993201	BOLT HEX. HEAD M16X55	TATA spare parts
222744993202	BANJO BOLT	TATA spare parts
222744994201	CLAMP HOSE ROUTING CLAMP 30 ID	TATA spare parts
222744994202	CLAMP HOSE ROUTING CLAMP 38 ID	TATA spare parts
222744994203	CLAMP HOSE ROUTING CLAMP 52 ID	TATA spare parts
222744995801	HOSE VALVE TO CYLINDER	TATA spare parts
222744996602	PISTON S 110-1400-MK5-HC	TATA spare parts
222744996702	PIN ROUND HEAD GROOVED 6X15 MM	TATA spare parts
222744996803	ELBOW LP 90 1 IN- LP28 + PARTS	TATA spare parts
222744997708	RUBBER FOR METAL STRAP	TATA spare parts
222744997715	O RING PISTON BOTTOM 110	TATA spare parts
222744999001	LINER SPOOL VALVE	TATA spare parts
222744999901	CHASSIS BKT (LOWER)	TATA spare parts
222744999902	FILTER ASSY BODY	TATA spare parts
222744999903	VALVE MOUNTING BLOCK	TATA spare parts
222744999904	LOAD BODY W/HYVA HYD KIT 23 CUM PRIMA BS	TATA spare parts
222744999905	BRACKET CHASSIS BRACKET 286	TATA spare parts
222744999906	GEAR PUMP ASSY	TATA spare parts
222744999909	GEAR PUMP ASSY (PARTY P/N 312908323T0S)	TATA spare parts
222744999911	RLF EXTENSION PIPE 265L	TATA spare parts
222744999947	GEAR PUMP ASSY	TATA spare parts
222744999950	GEAR PUMP ASSY	TATA spare parts
222787000110	TIPPER BODY ASSY WITH MTG DETAILS	TATA spare parts

222787000129	ASSY. TIPPER BODY	TATA spare parts
222787000164	TIPPER BODY ASSY	TATA spare parts
222787000181	TIPPER BODY ASSY	TATA spare parts
222787000224	LOAD BODY WITH MOUNTINGS BS6	TATA spare parts
222787000227	TIPPER BODY ASSY BS6	TATA spare parts
222787000228	SUBFRAME ASSY WITH MOUNTINGS BS6	TATA spare parts
222787000229	TIPPER BODY ASSY WITH MTG BS6	TATA spare parts
222787000249	LOAD BODY WITH MOUNTINGS BS6	TATA spare parts
222787000250	TIPPER BODY ASSY WITH HYDRAULICS MTG DET	TATA spare parts
222787000251	TIPPER BODY ASSY BS6 W/O. HYD	TATA spare parts
222787000252	SUBFRAME ASSY WITH MOUNTINGS BS6	TATA spare parts
222787010110	SUBFRAME ASSEMBLY	TATA spare parts
222787010113	LOAD BODYWITHOUT SUBFRAME BS6	TATA spare parts
222787010114	LOAD BODY ASSY WITH SUBFRAME 23 CUM BS6	TATA spare parts
222787010153	LOAD BODY ASSY COMPLETE BS6	TATA spare parts
222787010180	TIPPER BODY ASSY WITH HYDRAULICS MTG DET	TATA spare parts
222787010184	LOAD BODY WITH MOUNTINGS BS6	TATA spare parts
222787010185	TIPPER BODY ASSY BS6 W/O. HYD	TATA spare parts
222787010187	SUBFRAME ASSY WITH MOUNTINGS BS6	TATA spare parts
222787100126	ASSY. TIPPER BODY WITH MOUNTING DETAILS	TATA spare parts
222787100141	ASSY. TIPPER BODY WITH MTG. DETAILS	TATA spare parts
222787100155	ASSY. SUB FRAME	TATA spare parts
222787100175	ASSY. TIPPER BODY WITH MTG. DETAILS	TATA spare parts
222787100219	ASSY TIPPER BODY WITH MTG. DETAILS	TATA spare parts
222787100222	ASSY TIPPER BODY WITH MTG. DETAILS	TATA spare parts
222787100247	TIPPER BODY ASSY WITH MTG DETAILS	TATA spare parts
222787100254	STABILIZER ASSY BS6	TATA spare parts
222787100270	CRADLE ASSY CYL MTG BS6	TATA spare parts
222787100292	SUBFRAME ASSY BS6	TATA spare parts
222787100305	SUBFRAME ASSY WITH MOUNTINGS BS6	TATA spare parts
222787106704	COLLAR BS6	TATA spare parts
222787106706	LOCKING PIN BS6	TATA spare parts
222787106707	BUSH BS6	TATA spare parts
222787106708	PIN TAIL LOCK BS6	TATA spare parts
222787106709	PIN TAIL LOCK BS6	TATA spare parts
222787106710	PIN TAIL LOCK BS6	TATA spare parts
222787106801	LP ADAPTOR WITH O-RING (1 IN-LP28)	TATA spare parts
222787110119	MUDGUARD ASSY RH BS6	TATA spare parts
222787300132	ASSY. TIPPER BODY	TATA spare parts
222787300133	ASSY. SUB FRAME	TATA spare parts
222787300142	ASSY. TIPPER BODY	TATA spare parts
222787300143	ASSY. SUB-FRAME	TATA spare parts
222787300152	TIPPER BODY ASSY	TATA spare parts
222787300164	ASSY. SUB FRAME	TATA spare parts
222787300166	ASSY. SUB FRAME	TATA spare parts
222787300171	ASSY. TIPPER BODY	TATA spare parts
222787300172	SUBFRAME ASSEMBLY	TATA spare parts

222787300173	TIPPER BODY ASSEMBLY	TATA spare parts
222787300174	SUBFRAME ASSEMBLY	TATA spare parts
222787300177	ASSY LOAD BODY W/O HYDRAULIC KIT	TATA spare parts
222787300178	SUBFRAME ASSY	TATA spare parts
222787300182	TIPPER BODY ASSY W/O SUB FRAME HYD	TATA spare parts
222787300183	SUB FRAME ASSY	TATA spare parts
222787300184	TIPPER BODY ASSY ( WITHOUT SUBFRAME AND	TATA spare parts
222787300206	LOAD BODY ASSY	TATA spare parts
222787300219	HINGE ASSY TAILGATE BS6	TATA spare parts
222787300220	HINGE ASSY TAILGATE BS6	TATA spare parts
222787303201	U-BOLT	TATA spare parts
222787303401	HINGE BUSH BS6	TATA spare parts
222787306701	LOCKING PIN BS6	TATA spare parts
222787307102	PLATE	TATA spare parts
222787307104	STOPPER PLATE BS6	TATA spare parts
222787310103	HINGE ASSY TAILGATE BS6	TATA spare parts
222787310104	HINGE ASSY BS6	TATA spare parts
222787310105	HINGE ASSY BS6	TATA spare parts
222787310121	LADDER BS6	TATA spare parts
222787400108	TAILDOOR ASSEMBLY	TATA spare parts
222787400109	TAIL DOOR ASSEMBLY	TATA spare parts
222787400111	TAIL DOOR ASSY	TATA spare parts
222787400120	HINGE ASSY TAILGATE BS6	TATA spare parts
222787400123	TAILGATE ASSY BS6	TATA spare parts
222787400129	TAILGATE ASSY BS6	TATA spare parts
222787400131	TAILGATE ASSY BS6	TATA spare parts
222787406909	TUBE BS6	TATA spare parts
222787609914	WINCH SPARE WHEEL BS6	TATA spare parts
222787800114	BODY MTG BS6	TATA spare parts
222787800121	BODY MTG BS6	TATA spare parts
222787800124	CHAIN BS6	TATA spare parts
222787800129	CHAIN BS6	TATA spare parts
222787800132	CHAIN	TATA spare parts
222787800138	BODY MTG BS6	TATA spare parts
222787800139	BODY MTG BS6	TATA spare parts
222787800140	RESILIENCE MTG ASSY UPPER BS6	TATA spare parts
222787800144	RESILIENCE MTG ASSY UPPER BS6	TATA spare parts
222787800145	BODY MTG BS6	TATA spare parts
222787800146	BODY MTG BS6	TATA spare parts
222787800159	RESILIENCE MTG ASSY BS6	TATA spare parts
222787803301	RESILIENCE MTG BS6	TATA spare parts
222787803302	RESILIENCE MTG BS6	TATA spare parts
222787803303	RESILIENCE MTG BS6	TATA spare parts
222787803304	RESILIENCE MTG BS6	TATA spare parts
222787803310	RESILIENCE MTG BS6	TATA spare parts
222787807102	REAR ATTACHMENT PLATE RH	TATA spare parts
222787807104	RIBBED ATTACHMENT PLATE 2	TATA spare parts



222787807105	RIBBED ATTACHMENT PLATE - 3	TATA spare parts
222787807106	FRONT LOWER PIVOT LH	TATA spare parts
222787807107	FRONT LOWER PIVOT RH	TATA spare parts
222787807108	REAR ATTACHMENT PLATE LH	TATA spare parts
222787807109	REAR ATTACHMENT PLATE LH	TATA spare parts
222787900109	CAM MOUNTING ASSEMBLY	TATA spare parts
222787900110	CAM HAMMER ASSEMBLY LH	TATA spare parts
222787900111	CAM HAMMER ASSEMBLY RH	TATA spare parts
222787900112	HOOK ASSEMBLY LH	TATA spare parts
222787900113	HOOK ASSEMBLY RH	TATA spare parts
222787900114	HOOK BLOCK ASSEMBLY LH	TATA spare parts
222787900115	HOOK BLOCK ASSEMBLY RH	TATA spare parts
222787900132	MUDGUARD ASSY LH BS6	TATA spare parts
222787900138	MUDGUARD ASSY BS6	TATA spare parts
222787900140	LOCK SUPPORT TAILGATE LH BS6	TATA spare parts
222787900141	LOCK SUPPORT TAILGATE RH BS6	TATA spare parts
222787900143	MUDGUARD ASSY FRONT (L.H) FOR 24 CUM HD	TATA spare parts
222787900144	MUDGUARD ASSY FRONT (R.H) FOR 24 CUM HD	TATA spare parts
222787903001	BUSH	TATA spare parts
222787906703	PIN FOR CAM MOUNTING	TATA spare parts
222787906704	FORK PIN	TATA spare parts
222787907501	RUBBER GROMMET BODY HARNESS BS6	TATA spare parts
222787907703	RAIN FLAP REAR BS6	TATA spare parts
222787908701	SPRING	TATA spare parts
222787908705	SPRING HOOK	TATA spare parts
222787990173	STABILIZER ASSEMBLY WITH MOUNTING KIT	TATA spare parts
222787993401	UPPER REAR HINGE BEARING BUSH	TATA spare parts
222787993403	REAR HINGE BUSH	TATA spare parts
222787996702	LOCKING PIN	TATA spare parts
222787999906	REFLECTIVE TAPE TAILGATE VERTICAL BS6	TATA spare parts
222787999920	REFLECTIVE TAPE -14.5 MTR BS6	TATA spare parts
222844000107	GEAR PUMP ASSY	TATA spare parts
222844000108	TIPPING ASSY	TATA spare parts
222844000109	GEAR PUMP	TATA spare parts
222844000112	HYDRAULIC KIT ASSY WIS-28TA ç- SK407	TATA spare parts
222844000120	TIPPING ASSY BS6	TATA spare parts
222844100102	BRACKET CYLINDER MTG	TATA spare parts
222844100104	BRACKET CYLINDER MTG	TATA spare parts
222844100105	CHECK VALVE ASSY BS6	TATA spare parts
222844100107	CHECK VALVE BS6	TATA spare parts
222844100108	BRACKET ASSY CYLINDER MTG,BOTTOM	TATA spare parts
222844100109	CYLINDER ASSY	TATA spare parts
222844100110	BODY LOCK ASSY BS6	TATA spare parts
222844100112	CYLINDER ASSY HYDRAULIC	TATA spare parts
222844103303	CCV MOUNTING BRACKET	TATA spare parts
222844105801	HOSE ASSY	TATA spare parts
222844105808	SUCTION HOSE BS6	TATA spare parts

222844105810	HOSE ASSY	TATA spare parts
222844106503	NYLOC NUT BS6	TATA spare parts
222844106801	ELBOW ASSY SWIVEL BS6	TATA spare parts
222844106802	ELBOW ASSY SWIVEL	TATA spare parts
222844106808	PRESSURE HOSE 1½ ID X140 L	TATA spare parts
222844108001	HEX.HD.SCREW M6X12-10.9(300 HR SSR & 200	TATA spare parts
222844108002	HEX.HD.SCREW M8X16-10.9 (300 HR SSR&200	TATA spare parts
222844108003	HEX.HD.SCREW M8X25-10.9(300 HR SSR & 200	TATA spare parts
222844108004	HEX HEAD SCREW BS6	TATA spare parts
222844108005	HEX HEAD SCREW BS6	TATA spare parts
222844109203	SEALING WASHER BS6	TATA spare parts
222844109204	SEALING WASHER BS6	TATA spare parts
222844109205	SEALING WASHER 33 X 39	TATA spare parts
222844109206	SPRING WASHER (300 HR SSR & 200 UVR)	TATA spare parts
222844109902	PARALLEL MALE STUD COUPLING BODY M22X1.5	TATA spare parts
222844109905	COUPLING BODY PARALLEL MALE STUD BS6	TATA spare parts
222844109906	ADAPTER MALE BS6	TATA spare parts
222844109910	ADAPTER	TATA spare parts
222844109912	ADAPTER BS6	TATA spare parts
222844109915	INSTRUCTION LABEL BS6	TATA spare parts
222844109918	VALVE MOUNTING BRACKET BS6	TATA spare parts
222844109919	MOUNTING PLATE BS6	TATA spare parts
222844109922	ELBOW ASSY WITH SWIVEL NUT BS6	TATA spare parts
222844109924	ELBOW ASSY;SWIVEL BS6	TATA spare parts
222844109925	VALVE ELBOW WITH SWIVEL NUT ASSY.	TATA spare parts
222844109931	CHECK VALVE ASSY BS6	TATA spare parts
222844109932	TIPPING VALVE BS6	TATA spare parts
222844109933	ADAPTER BS6	TATA spare parts
222844109934	CLAMP BS6	TATA spare parts
222844109935	BRACKET BS6	TATA spare parts
222844109936	INSTRUCTION STICKER (SAFE TIPPING) U/B	TATA spare parts
222844109938	ADAPTOR EN 1A 1INCH BSP X M30X2	TATA spare parts
222844109940	HYDRAULIC TANK ASSY BS6	TATA spare parts
222844109942	PLAIN WASHER BS6	TATA spare parts
222844109945	RUBBER STRIP BS6	TATA spare parts
222844109959	VINYL DIPPED CLAMP 1/2 ID HOSE BS6	TATA spare parts
222844109965	SUCTION HOSE BS6	TATA spare parts
222844109966	SUCTION HOSE BS6	TATA spare parts
222844109970	PRESSURE HOSE ASSY BS6	TATA spare parts
222844109971	PRESSURE HOSE ASSY BS6	TATA spare parts
222844109972	PRESSURE HOSE WITH U BEND BS6	TATA spare parts
222844109973	HOSE CLAMP MOUNTING BRACKET-1 BS6	TATA spare parts
222844109974	SOLENOID ACTUATED VALVE BS6	TATA spare parts
222844400102	TANK ASSY HYDRAULIC	TATA spare parts
222844400104	HYDRAULIC TANK BS6	TATA spare parts
222844994202	CLAMP;HOSE BS6	TATA spare parts
222844995802	HOSE BS6	TATA spare parts

222844995803	PRESSURE HOSE¿BS6	TATA spare parts
222844995804	HOSE BS6	TATA spare parts
222844995806	RETURN HOSE BS6	TATA spare parts
222844995812	HP HOSE ASSY	TATA spare parts
222844999001	LINER SPOOL VALVE	TATA spare parts
222844999002	AIR CONTROL VALVE	TATA spare parts
222844999003	AIR CONTROL VALVE BS6	TATA spare parts
222870000116	ASSY LOAD BODY COMPLETE SFC 407/2750WB C	TATA spare parts
222870000117	ASSY LOAD BODY BOLTED COMPLETE	TATA spare parts
222870000141	ASSY LOAD BODY COMPLETE	TATA spare parts
222870000148	ASSEMBLY LOADBODY LPT407/34EX	TATA spare parts
22287000016120	ASSY. LOADBODY COMP.-CLOSE PITCH PANELS	TATA spare parts
222870000164	LOAD BODY COMPLETE SFC 407 CNG 31 WB	TATA spare parts
222870000169	ASSY. LOADBODY COMPLETE	TATA spare parts
222870000172	LOAD BODY ASSY	TATA spare parts
222870000180	ASSEMBLY LOADBODY COMPLETE	TATA spare parts
222870000188	ASSY. LOADBODY COMPLETE	TATA spare parts
222870000198	ASSY LOAD BODY 1109 LPT 36 LD EX2	TATA spare parts
222870000207	ASSY.LOAD BODY WELDED COMPLETE	TATA spare parts
222870000212	ASSY. LOADBODY COMPLETE	TATA spare parts
222870000214	ASSY LOAD BODY COMPLETE	TATA spare parts
222870000220	ASSY LOAD BODY COMPLETE	TATA spare parts
222870000221	LOAD BODY ASSY	TATA spare parts
222870000248	LOAD BODY ASSY SFC 407 29WB PICK UP NDLB	TATA spare parts
222870000249	LOAD BODY ASSY WITH FENDER	TATA spare parts
222870000284	LOAD BODY ASSY	TATA spare parts
222870000285	LOAD BODY ASSY	TATA spare parts
222870000294	LOAD BODY ASSY	TATA spare parts
222870000296	LOAD BODY ASSY	TATA spare parts
222870000315	LOAD BODY ASSY BS6	TATA spare parts
222870000320	LOAD BODY ASSY BS6	TATA spare parts
222870000325	LOAD BODY ASSY BS6	TATA spare parts
222870000328	LOAD BODY ASSY BS6	TATA spare parts
222870000329	LOAD BODY ASSY BS6	TATA spare parts
222870000340	BRACKETASSY MUDGUARDMTG BS6	TATA spare parts
222870000341	BRACKETASSY STAYRODMTG BS6	TATA spare parts
222870000342	BRACKETASSY SUPDMTG BS6	TATA spare parts
222870000346	LOAD BODY ASSY BS6	TATA spare parts
222870000350	LOAD BODY ASSY BS6	TATA spare parts
222870000371	LOAD BODY ASSY BS6-PH2	TATA spare parts
222870010102	BRACKET ASSY BS6	TATA spare parts
222870010112	LOAD BODY ASSY BS6	TATA spare parts
222870010122	LOAD BODY ASSY BS6	TATA spare parts
222870010124	LOAD BODY ASSY BS6	TATA spare parts
222870010128	LOAD BODY ASSY BS6	TATA spare parts
222870010203	LOAD BODY ASSY	TATA spare parts
222870010213	LOAD BODY ASSY BS6	TATA spare parts

222870010215	LOAD BODY ASSY BS6	TATA spare parts
222870010217	LOAD BODY ASSYBS6	TATA spare parts
222870010224	LOAD BODY ASSY BS6	TATA spare parts
222870010230	LOAD BODY ASSY BS6	TATA spare parts
222870010232	LOAD BODY ASSY BS6	TATA spare parts
222870010248	LOAD BODY ASSY	TATA spare parts
222870010271	LOAD BODY ASSY	TATA spare parts
222870010279	LOAD BODY ASSY;BS6	TATA spare parts
222870010281	LOAD BODY ASSY	TATA spare parts
222870010292	LOAD BODY ASSY BS6	TATA spare parts
222870010295	LOAD BODY ASSY BS6	TATA spare parts
222870020104	LOAD BODY ASSY BS6	TATA spare parts
222870020105	LOAD BODY ASSY BS6	TATA spare parts
222870020236	LOAD BODY ASSY BS6	TATA spare parts
222870020238	LOAD BODY ASSY BS6	TATA spare parts
222870020241	LOADBODYASSY BS6	TATA spare parts
222870020243	LOADBODYASSY BS6	TATA spare parts
222870020264	LOAD BODY ASSY BS6	TATA spare parts
222870020269	LOAD BODY ASSY BS6	TATA spare parts
222870100109	BRACKET ASSY MUDGUARD MTG BS6	TATA spare parts
222870100121	SPRAY SUPPRESSION ASSY LH	TATA spare parts
222870100122	SPRAY SUPPRESSION ASSY RH	TATA spare parts
222870100129	ASSY CHAIN COMPLETE	TATA spare parts
222870100179	ASSY. SUPD LH	TATA spare parts
222870100180	ASSY. SUPD RH	TATA spare parts
222870100187	ASSY. SUPD (LH)	TATA spare parts
222870100188	ASSY. SUPD (RH)	TATA spare parts
222870100195	ASSY SUPD LH SFC 407 2750WB	TATA spare parts
222870100196	ASSY SUPD RH SFC 407 2750WB	TATA spare parts
222870100215	ASSY SUPD	TATA spare parts
222870100229	BRACKET ASSY BS6	TATA spare parts
222870100231	LEG ASSY BS6	TATA spare parts
222870104212	HOOK BS6	TATA spare parts
222870106309	MUDGUARD FRONT	TATA spare parts
222870106310	MUDGUARD REAR	TATA spare parts
222870106315	MUDGUARD R.H.	TATA spare parts
222870106316	MUDGUARD L.H.	TATA spare parts
222870106317	MUDGUARD (FRONT) RH	TATA spare parts
222870106318	MUDGUARD (FRONT) L.H.	TATA spare parts
222870106325	MUDGUARD LH REAR	TATA spare parts
222870106326	MUDGUARD RH REAR	TATA spare parts
222870106327	MUDGUARD LH FRONT	TATA spare parts
222870106328	MUDGUARD RH FRONT	TATA spare parts
222870106329	MUDGUARD LH CENTRE-SPRAY SUPPRESSION	TATA spare parts
222870106330	MUDGUARD RH CENTRE-SPRAY SUPPRESSION	TATA spare parts
222870106350	STAY ROD LH	TATA spare parts
222870106351	STAY ROD REAR	TATA spare parts

222870106352	MUDGUARD LH	TATA spare parts
222870106353	MUDGUARD RH	TATA spare parts
222870106909	MUDGUARD STAY ROD	TATA spare parts
222870108273	MUDGAURD LH	TATA spare parts
222870108274	MUDGUARD RH	TATA spare parts
222870108275	MUDGAURD RH	TATA spare parts
222870108276	MUDGAURD LH	TATA spare parts
222870108277	MUDGUARD STAY	TATA spare parts
222870110125	BRACKET ASSY TOP MARKER LAMP MTG BS6	TATA spare parts
222870110128	ASSEMBLY SUPD LH	TATA spare parts
222870110129	ASSEMBLY SUPD RH	TATA spare parts
222870110131	ASSEMBLY SUPD LH	TATA spare parts
222870110132	ASSEMBLY SUPD RH	TATA spare parts
222870110163	ASSY SUPD LH	TATA spare parts
222870110164	ASSY SUPD RH	TATA spare parts
222870110206	SUPD ASSY LH BS6	TATA spare parts
222870110207	SUPD ASSY RH BS6	TATA spare parts
222870110208	SUPD ASSY	TATA spare parts
222870118213	MUDGAURD STAY ROD(REAR)	TATA spare parts
222870118263	SIDE GUARD	TATA spare parts
222870118266	MUDGUARD	TATA spare parts
222870118267	MUDGUARD	TATA spare parts
222870118272	MUDGUARDLH BS6	TATA spare parts
222870118273	MUDGUARDRH BS6	TATA spare parts
222870118274	MUDGUARD CENTER BS6	TATA spare parts
222870120105	ASSY MUD FLAP REAR	TATA spare parts
222870120106	ASSEMBLY MUD FLAP REAR	TATA spare parts
222870120177	BRACKET ASSY MUDGUARD MTG BS6	TATA spare parts
222870128244	BRAKET FOR SUPD MTG ON CHASSIS	TATA spare parts
222870128245	BRAKET FOR SUPD MTG ON CHASSIS	TATA spare parts
222870130135	ASSY. SUPD (LH)	TATA spare parts
222870130142	ASSY. SUPD LH .	TATA spare parts
222870130143	ASSY. SUPD RH .	TATA spare parts
222870130161	ASSY. FLOOR COMPLETE	TATA spare parts
222870130170	ASSY SUPD LH	TATA spare parts
222870130171	ASSY SUPD RH	TATA spare parts
222870138236	MUDGAURD STAY ROD REAR	TATA spare parts
222870140109	SUPPORT ASSY MUDGUARD STAY ROD	TATA spare parts
222870140110	SUPPORT ASSY MUDGUARD	TATA spare parts
222870140131	LEG ASSY SUPD	TATA spare parts
222870140132	SUPD ASSY RH	TATA spare parts
222870140151	ASSY SUPD	TATA spare parts
222870140168	MUD GUARD MTG ASSY BS6	TATA spare parts
222870140201	SUPD ASSY LH BS6	TATA spare parts
222870140202	SUPD ASSY LH BS6	TATA spare parts
222870140203	SUPD ASSY BS6	TATA spare parts
222870140208	SUPD ASSY BS6	TATA spare parts

222870150117	SUPD ASSY LH BS6	TATA spare parts
222870150118	SUPD ASSY RH BS6	TATA spare parts
222870150129	BRACKET ASSY SUPD MTG BS6	TATA spare parts
222870150131	BRACKET ASSY LOAD BODY MTG BS6	TATA spare parts
222870150135	SUPD ASSY	TATA spare parts
222870150144	BRACKET ASSY STAY ROD MTG BS6	TATA spare parts
222870150151	SUPD ASSY LH BS6	TATA spare parts
222870150152	SUPD ASSY RH BS6	TATA spare parts
222870150154	SUPD ASSY LH BS6	TATA spare parts
222870150155	SUPD ASSY RH BS6	TATA spare parts
222870150158	SUPD ASSY BS6	TATA spare parts
222870150191	SUPD ASSY BS6	TATA spare parts
222870150194	BRACKET ASSY BS6	TATA spare parts
222870150195	BRACKET ASSY MUDGUARD MTG BS6	TATA spare parts
222870160101	BRACKET ASSY BS6	TATA spare parts
222870160136	SUPD ASSY LH BS6	TATA spare parts
222870160137	SUPD ASSY RH BS6	TATA spare parts
222870160140	SUPD ASSY RH BS6	TATA spare parts
222870160141	SUPD ASSY LH BS6	TATA spare parts
222870160142	SUPD ASSY LH BS6	TATA spare parts
222870160143	SUPD ASSY RH BS6	TATA spare parts
222870160144	BRACKET ASSY MUDGUARD MTG BS6	TATA spare parts
222870160145	BRACKET ASSY SUPD MTG BS6	TATA spare parts
222870160146	SUPD ASSY BS6	TATA spare parts
222870160152	SUPD ASSY RH BS6	TATA spare parts
222870160153	SUPD ASSY LH BS6	TATA spare parts
222870168257	STAY ROD BS6	TATA spare parts
222870170105	SUPD ASSY LH BS6	TATA spare parts
222870170106	SUPD ASSY RH BS6	TATA spare parts
222870170108	SUPD ASSY LH	TATA spare parts
222870170109	SUPD ASSY RH	TATA spare parts
222870200101	ASSY FRONT WALL	TATA spare parts
222870200120	FRONT WALL ASSY BS6	TATA spare parts
222870200122	ASSY FRONT WALL	TATA spare parts
222870200137	ASSY FRONT WALL	TATA spare parts
222870200168	ASSY FRONT PANEL	TATA spare parts
222870200172	ASSEMBLY FRONT WALL	TATA spare parts
222870200187	ASSY FRONT WALL	TATA spare parts
222870200191	FRONT WALL ASSY	TATA spare parts
222870228241	BKT. MUDGUARD MTG. . BS6	TATA spare parts
222870228243	STAY ROD BS6	TATA spare parts
222870228245	MOUNTING BRACKET DRIVEAWAY SUPD	TATA spare parts
222870228246	MOUNTING BRACKET DRIVEAWAY SUPD	TATA spare parts
222870238274	STAY ROD BS6	TATA spare parts
222870238283	MUDGUARDBS6	TATA spare parts
222870238284	MUDGUARDBS6	TATA spare parts
222870248209	MUDGUARD CENTER BS6	TATA spare parts

222870248253	MUDGUARD CENTER BS6	TATA spare parts
222870248254	MUDGUARD CENTER BS6	TATA spare parts
222870248255	MUDGUARD BS6	TATA spare parts
222870248256	MUDGUARD BS6	TATA spare parts
222870248261	BUSH - BS6	TATA spare parts
222870258288	MUDGUARD CENTER-LH BS6	TATA spare parts
222870258289	MUDGUARD CENTER-RH BS6	TATA spare parts
222870258291	MUDGUARD CENTER-LH BS6	TATA spare parts
222870258292	MUDGUARD CENTER-RH BS6	TATA spare parts
222870300121	ASSY SIDE WALL LH	TATA spare parts
222870300126	ASSY SIDE WALL RH	TATA spare parts
222870300136	ASSY SIDE WALL LH	TATA spare parts
222870300137	ASSY SIDE WALL RH	TATA spare parts
222870300141	ASSY SIDE PANEL LH	TATA spare parts
222870300142	ASSY SIDE PANEL RH	TATA spare parts
222870300168	ASSEMBLY SIDE PANEL L.H	TATA spare parts
222870300169	ASSEMBLY SIDE PANEL R.H	TATA spare parts
222870300170	ASSY SIDE PANEL RH	TATA spare parts
222870300171	ASSY SIDE PANEL LH	TATA spare parts
222870300198	ASSY SIDE WALL LH	TATA spare parts
222870300199	ASSY SIDE WALL RH	TATA spare parts
222870300213	SIDE WALL ASSY LH	TATA spare parts
222870300233	SIDE WALL ASSY RH	TATA spare parts
222870304209	LOCK PLATE LH (TAIL GATE LOCKING)	TATA spare parts
222870304211	HANDLE CLAMP RH (TAIL GATE LOCKING)	TATA spare parts
222870306302	RETRO REFLECTIVE TAPE 150 LG	TATA spare parts
222870306303	RETRO REFLECTIVE TAPE 400 LG	TATA spare parts
222870306304	RETRO REFLECTIVE TAPE 500 LG	TATA spare parts
222870306305	RETRO REFLECTIVE TAPE 763 LG	TATA spare parts
222870306306	RETRO REFLECTIVE TAPE 450 LG	TATA spare parts
222870306308	RETRO REFLECTIVE TAPE 600 LG	TATA spare parts
222870306312	RETRO REFLECTIVE TAPE LPT 909/34 WB/HD	TATA spare parts
222870308235	CLAMP HANDLE LH	TATA spare parts
222870308236	CLAMP HANDLE RH	TATA spare parts
222870308262	CLAMP LH (TAIL GATE)	TATA spare parts
222870308263	CLAMP RH (TAIL GATE)	TATA spare parts
222870310108	SIDE WALL ASSY LH	TATA spare parts
222870310109	SIDE WALL ASSY RH	TATA spare parts
222870310116	ASSY SIDE PANEL LH	TATA spare parts
222870310117	ASSY SIDE PANEL RH	TATA spare parts
222870310118	SIDE WALL ASSY LH	TATA spare parts
222870310119	SIDE WALL ASSY RH	TATA spare parts
222870310126	SIDE WALL ASSY LH	TATA spare parts
222870310127	SIDE WALL ASSY RH	TATA spare parts
222870310130	SIDE WALL ASSY LH BS6	TATA spare parts
222870310131	SIDE WALL ASSY RH BS6	TATA spare parts
222870310197	SIDE WALL ASSY LH BS6	TATA spare parts

222870310198	SIDE WALL ASSY RH BS6	TATA spare parts
222870310199	SIDE WALL ASSY LH BS6	TATA spare parts
222870320101	SIDE WALL ASSY RH BS6	TATA spare parts
222870338258	MUDGUARD CENTER BS6	TATA spare parts
222870348201	STAY ROD BS6	TATA spare parts
222870400101	ASSY TAIL GATE	TATA spare parts
222870400115	ASSY BRACKET (HANDLE)	TATA spare parts
222870400121	TAILGATE ASSY	TATA spare parts
222870400122	ASSY TAIL GATE	TATA spare parts
222870400125	TAILGATEASSY LOADBODY BS6	TATA spare parts
222870400127	ASSY TAIL GATE	TATA spare parts
222870400143	ASSY TAIL GATE	TATA spare parts
222870400145	ASSEMBLY TAIL GATE	TATA spare parts
222870400148	ASSY TAIL GATE	TATA spare parts
222870406302	RETRO-REFLECTIVE TAPE	TATA spare parts
222870406304	RETRO REFLECTIVE TAPE-REAR RED 1920 LG	TATA spare parts
222870406307	PLATE REAR MARKING LH	TATA spare parts
222870406308	PLATE REAR MARKING RH	TATA spare parts
222870406906	STEP TAIL GATE	TATA spare parts
222870803213	U-BOLT (LENGTH-320MM)	TATA spare parts
222870803214	U-BOLT (LENGTH-270MM)	TATA spare parts
222870803215	U-BOLT BS6	TATA spare parts
222870803807	CLEAT BS6	TATA spare parts
222870808201	RESILIENCE MOUNTING BRACKET BS6	TATA spare parts
222870808202	BRACKET BOTTOM U BOLT CLAMP	TATA spare parts
222870808204	BRACKET U BOLT MOUNTING	TATA spare parts
222870808205	BRACKET U BOLT MOUNTING	TATA spare parts
222870808209	ALUMINUM PACKING BS6	TATA spare parts
222870808702	BUSH BS6	TATA spare parts
222870808703	BUSH - BS6	TATA spare parts
222870808704	BUSH BS6	TATA spare parts
222870900102	ASSEMBLY CLEAT MOUNTING CHASIS	TATA spare parts
222870900104	ASSY STOPPER SIDE & REAR	TATA spare parts
222870900106	ASSYCLEATMOUNTINGLONGRUNNER BS6	TATA spare parts
222870900123	ASSY TOGGLE CLAMP BS6	TATA spare parts
222870900139	OVERHEAD BAR ASSY BS6	TATA spare parts
222870900152	ASSY SUPPORT LONG MEMBER	TATA spare parts
222870900153	ASSY SUPPORT LONG MEMBER	TATA spare parts
222870904203	HOOK BS6	TATA spare parts
222870905304	FOAM PACKING BS6	TATA spare parts
222870905609	HANDLE LH	TATA spare parts
222870905610	HANDLE RH	TATA spare parts
222870905611	HANDLE-LH (TAIL GATE LOCKING)	TATA spare parts
222870905612	HANDLE-RH-(TAIL GATE LOCKING)	TATA spare parts
222870906305	BALATA PACKING	TATA spare parts
222870906310	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222870906316	BALATA PACKING LONG RUNNER	TATA spare parts



222870906318	BALATA PACKING BS6	TATA spare parts
222870906320	BALATA PACKING BS6	TATA spare parts
222870906336	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222870906337	BALATA PACKING LONG RUNNER	TATA spare parts
222870906343	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222870906351	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222870906352	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222870906353	BALATA PACKING LONG RUNNER	TATA spare parts
222870906355	BALATA PACKING LONG RUNNER	TATA spare parts
222870906364	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222870906365	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222870906376	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222870906703	LOCK ROD REAR	TATA spare parts
222870906712	PIN (HINGE)	TATA spare parts
222870906714	PIN(HINGE)	TATA spare parts
222870906904	LADER STEP	TATA spare parts
222870907707	STRAP	TATA spare parts
222870908257	SUPPORT BRACKET	TATA spare parts
222870909907	DECAL-TATA	TATA spare parts
222870990154	KIT SUPD(SIDE UNDER PROTECTION DEVICE)	TATA spare parts
222870990157	KIT ASSY FOR SUPD	TATA spare parts
222870990168	KIT LOADBODY FOR LPT 1116/42 WB ND	TATA spare parts
222887000125	LOAD BODY BS6	TATA spare parts
222887000127	TIPPER BODY ASSY WITH SUBFRAME BS6	TATA spare parts
222887000128	LOAD BODY BS6	TATA spare parts
222887000129	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
222887010101	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
222887010111	COUPLING TORSIONAL BS6	TATA spare parts
222887010141	TIPPER BODY ASSY WITH SUBFRAME BS6	TATA spare parts
222887100114	SUB FRAME ASSY	TATA spare parts
222887100151	HINGE ASSY MUDFLAP BS6	TATA spare parts
222887100183	RUBBER PAD ASSY BS6	TATA spare parts
222887100192	SUBFRAME ASSY BS6	TATA spare parts
222887100196	FLOOR ASSY BS6	TATA spare parts
222887100198	SUBFRAME ASSY BS6	TATA spare parts
222887103203	U-BOLT BS6	TATA spare parts
222887103207	U-BOLT BS6	TATA spare parts
222887107107	U-BOLT SPACER BS6	TATA spare parts
222887107130	ATTACHEMENT PLATE BS6	TATA spare parts
222887107134	ATTACHEMENT PLATE BS6	TATA spare parts
222887107147	ATTACHMENT PLATE BS6	TATA spare parts
222887107701	SPACER RUBBER	TATA spare parts
222887109901	ALUMINIUM PACKING BS6	TATA spare parts
222887110102	FLOOR ASSY BS6	TATA spare parts
222887110104	SPRAY SUPPRESSION ASSY BS6	TATA spare parts
222887110108	HINGE ASSY BS6	TATA spare parts
222887110115	SUBFRAME ASSY BS6	TATA spare parts

222887110123	TUBE ASSY OUTER BS6	TATA spare parts
222887110140	LOCK SUPPORT TAILGATE RH BS6	TATA spare parts
222887110141	LOCK SUPPORT TAILGATE LH BS6	TATA spare parts
222887110145	BODY LOCK ASSY BS6	TATA spare parts
222887110146	BODY LOCK ASSY BS6	TATA spare parts
222887110147	BRACKET ASSY BS6	TATA spare parts
222887110157	VERTICAL STIFFENER SIDE WALL BS6	TATA spare parts
222887110166	SUPPORT ASSY BODY FRAME BS6	TATA spare parts
222887110187	SUBFRAME ASSY BS6	TATA spare parts
222887118222	MUDGUARD VALANCE COVER BS6	TATA spare parts
222887118271	MUDGUARD FRONT COVER LH BS6	TATA spare parts
222887118272	MUDGUARD FRONT COVER RH BS6	TATA spare parts
222887128230	STOPPER HINGE PIN BS6	TATA spare parts
222887128246	PILLAR TAILGATE BS6	TATA spare parts
222887128250	PILLAR TAILGATE BS6	TATA spare parts
222887128269	PLATE MUDGUARD BS6	TATA spare parts
222887128270	PLATE MUDGUARD BS6	TATA spare parts
222887128272	SUPPORT FLOOR CHANNEL BS6	TATA spare parts
222887128274	STOPPER PLATE BS6	TATA spare parts
222887128275	SUPPORT FLOOR CHANNEL BS6	TATA spare parts
222887128282	STOPPER PLATE BS6	TATA spare parts
222887138217	MUDGUARD SUPPORT BS6	TATA spare parts
222887138218	MUDGUARD PLATE BS6	TATA spare parts
222887138220	RUBBER MUDGUARD BS6	TATA spare parts
222887138222	MUDGUARD SUPPORT BS6	TATA spare parts
222887138227	MUDGUARD REAR WHEEL LH / RH BS6	TATA spare parts
222887138229	GUSSET BS6	TATA spare parts
222887138230	GUSSET BS6	TATA spare parts
222887200111	FRONT WALL ASSY BS6	TATA spare parts
222887200112	FRONT WALL ASSY BS6	TATA spare parts
222887300113	HINGE ASSY TAILGATE BS6	TATA spare parts
222887300124	SIDE PANEL BS6	TATA spare parts
222887300126	SIDE PANEL BS6	TATA spare parts
222887303401	HINGE BUSH BS6	TATA spare parts
222887306703	HINGE PIN BS6	TATA spare parts
222887318220	SUPPORT BS6	TATA spare parts
222887318222	SUPPORT BS6	TATA spare parts
222887400111	TAILGATE ASSY BS6	TATA spare parts
222887400112	TAILGATE ASSY BS6	TATA spare parts
222887400113	TAILGATE ASSY BS6	TATA spare parts
222887400121	TAIL DOOR ASSY BS6	TATA spare parts
222887800107	SUPPORT PLATE BS6	TATA spare parts
222887800108	BODY MTG BS6	TATA spare parts
222887803804	LOCK SUPPORT TAILGATE LH BS6	TATA spare parts
222887803805	LOCK SUPPORT TAILGATE LH BS6	TATA spare parts
222887808207	PLATE BOTTOM CLAMP BS6	TATA spare parts
222887808213	PLATE BOTTOM CLAMP BS6	TATA spare parts

222887900112	SPRAY SUPPRESSION ASSY	TATA spare parts
222887900132	MUDGUARD SUPPORT BS6	TATA spare parts
222887900133	CHAIN BS6	TATA spare parts
222887900136	BRACKET ASSY LH BS6	TATA spare parts
222887900137	BRACKET ASSY RH BS6	TATA spare parts
222887900139	SPRAY SUPPRESSION ASSY BS6	TATA spare parts
222887900160	NYLON TUBE BS6	TATA spare parts
222887900175	NYLON TUBE BS6	TATA spare parts
222887903404	LOCK BS6	TATA spare parts
222887905805	C-SECTION BS6	TATA spare parts
222887905811	C-SECTION BS6	TATA spare parts
222887906310	MUDGUARD MESH BS6	TATA spare parts
222887906314	MUDGUARD MESH BS6	TATA spare parts
222887906908	LADDER BS6	TATA spare parts
222887907501	RUBBER GROMMET BS6	TATA spare parts
222887908224	MUDGUARD PLATE BS6	TATA spare parts
222887908251	PIN CYL MTG BS6	TATA spare parts
222887909908	TIPPING HINGE PINBS6	TATA spare parts
222887909915	PIN BS6	TATA spare parts
222887999910	REFLECTIVE TAPE BS6	TATA spare parts
222887999919	RETRO REFLECTIVE TAPE BS6	TATA spare parts
222887999920	RETRO REFLECTIVE TAPE BS6	TATA spare parts
222887999921	REFLECTIVE TAPE BS6	TATA spare parts
222887999925	REFLECTIVE TAPE SIDEWALL BOTTOM-II BS6	TATA spare parts
222887999926	REFLECTIVE TAPE TAILGATE HORIZONTAL BS6	TATA spare parts
222887999927	REFLECTIVE TAPE TAILGATE VERTICAL BS6	TATA spare parts
222944000116	BRACKET AIR VALVE MTG BS6	TATA spare parts
222944109917	O-RING BS6	TATA spare parts
222944109937	CARTRIDGE RELIEF VALVE BS6	TATA spare parts
222944109992	CHECK VALVE BS6	TATA spare parts
222944109994	FILTER ELEMENT BS6	TATA spare parts
222944119902	AIR BREATHER ASSY BS6	TATA spare parts
222970000104	ASSY LOADBODY COMPLETE	TATA spare parts
222970000110	ASSY. LOADBODY COMPLETE	TATA spare parts
222970000112	ASSY LOAD BODY COMPLETE	TATA spare parts
222970000141	ASSY LOADBODY COMPLETE 4530 WB HD	TATA spare parts
222970000156	LOAD BODY WELDED COMPLETE	TATA spare parts
222970000159	ASSY LOAD BODY COMPLETE	TATA spare parts
222970000191	LOAD BODY ASSY	TATA spare parts
222970000192	LOAD BODY ASSY	TATA spare parts
222970000193	ASSY. LOAD BODY BOLTED BS3/4	TATA spare parts
222970000194	LOADBODY ASSY BOLTED	TATA spare parts
222970000198	LOAD BODY ASSY	TATA spare parts
222970000202	LOAD BODY ASSY	TATA spare parts
222970000204	LOAD BODY ASSY	TATA spare parts
222970000206	LOAD BODY ASSY	TATA spare parts
222970000218	LOAD BODY ASSY	TATA spare parts

222970000220	LOAD BODY ASSY BS6	TATA spare parts
222970000226	ASSY LOADBODY COMPLETE	TATA spare parts
222970000227	LOAD BODY ASSY	TATA spare parts
222970000229	LOAD BODY ASSY	TATA spare parts
222970000233	LOAD BODY ASSY BS6	TATA spare parts
222970000236	LOAD BODY ASSY	TATA spare parts
222970000239	LOAD BODY ASSY	TATA spare parts
222970000240	LOAD BODY ASSY	TATA spare parts
222970000244	LOAD BODY ASSY 35WB HDLB	TATA spare parts
222970000245	LOAD BODY ASSY	TATA spare parts
222970000257	LOAD BODY ASSY W/O SUPD	TATA spare parts
222970000258	LOAD BODY ASSY BS6	TATA spare parts
222970000259	LOAD BODY ASSY BS6	TATA spare parts
222970000261	LOAD BODY ASSY BS6	TATA spare parts
222970000263	LOAD BODY ASSY BS6	TATA spare parts
222970000269	LOAD BODY ASSY BS6	TATA spare parts
222970000270	LOAD BODY ASSY BS6	TATA spare parts
222970000271	LOAD BODY ASSY BS6	TATA spare parts
222970000281	LOAD BODY ASSY BS6	TATA spare parts
222970000283	LOAD BODY ASSY BS6	TATA spare parts
222970000288	LOAD BODY ASSY BS6	TATA spare parts
222970000291	LOAD BODY ASSY BS6	TATA spare parts
222970000292	LOAD BODY ASSY BS6	TATA spare parts
222970000297	LOAD BODY ASSY BS6	TATA spare parts
222970000302	LOAD BODY ASSY BS6	TATA spare parts
222970000345	BRACKETASSY MUDGUARDMTG BS6	TATA spare parts
222970000348	LOAD BODY ASSY	TATA spare parts
222970000356	LOAD BODY ASSY BS6	TATA spare parts
222970000391	LOAD BODY ASSY BS6	TATA spare parts
222970000392	LOAD BODY ASSY BS6	TATA spare parts
222970010105	LOAD BODY ASSY BS6	TATA spare parts
222970010112	LOAD BODY ASSY BS6	TATA spare parts
222970010123	LOAD BODY ASSY BS6	TATA spare parts
222970010137	SUPD ASSY BS6	TATA spare parts
222970010140	SUPD ASSY BS6	TATA spare parts
222970010143	LEG ASSY BS6	TATA spare parts
222970010148	SUPD ASSY RH BS6	TATA spare parts
222970010149	SUPD ASSY LH BS6	TATA spare parts
222970010150	SUPD ASSY RH BS6	TATA spare parts
222970010151	SUPD ASSY LH BS6	TATA spare parts
222970010173	BRACKET ASSY BS6	TATA spare parts
222970010174	BRACKET ASSY BS6	TATA spare parts
222970010178	BRACKET ASSY BS6	TATA spare parts
222970010183	BRACKET ASSY BS6	TATA spare parts
222970010201	LOAD BODY ASSY BS6	TATA spare parts
222970010210	LOAD BODY ASSY BS6	TATA spare parts
222970010231	LOAD BODY ASSY BS6	TATA spare parts

222970010233	LOAD BODY ASSY BS6	TATA spare parts
222970100134	ASSY. SUPD (RH)	TATA spare parts
222970100136	ASSY. SUPD (LH)	TATA spare parts
222970100155	ASSY SUPD RH	TATA spare parts
222970100156	ASSY SUPD LH	TATA spare parts
222970100167	NUMBER PLATE ASSY	TATA spare parts
222970100224	SUPD ASSY RH BS6	TATA spare parts
222970100225	SUPD ASSY BS6	TATA spare parts
222970100230	SUPD ASSY RH	TATA spare parts
222970100231	SUPD ASSY LH	TATA spare parts
222970100235	SUPD ASSY LH	TATA spare parts
222970100239	BRACKET ASSY TAIL LAMP NUMBER PLATE MTG	TATA spare parts
222970100240	SUPD ASSY LH	TATA spare parts
222970100244	CIRCULAR MUDGUARD ASSY LH	TATA spare parts
222970100245	CIRCULAR MUDGUARD ASSY RH	TATA spare parts
222970100246	SUPD ASSY RH	TATA spare parts
222970100252	SUPD ASSY LH	TATA spare parts
222970100253	SUPD ASSY RH	TATA spare parts
222970100259	SUPD ASSY BS6	TATA spare parts
222970100264	BRACKETASSY STAYRODMTG BS6	TATA spare parts
222970100267	BRACKET ASSY MUDGUARD MTG BS6	TATA spare parts
222970106306	MUDGUARD SPRAY SUPPRESSION	TATA spare parts
222970106324	MUDFLAP BS6	TATA spare parts
222970106325	MESH MUDFLAP	TATA spare parts
222970106326	MUDFLAP	TATA spare parts
222970106327	MUD FLAP	TATA spare parts
222970106342	MESH MUDFLAP BS6	TATA spare parts
222970106347	BALATA PACKING LONG RUNNER BS6-PH2	TATA spare parts
222970108290	BRACKET SIDEMARKERLAMPMTG BS6	TATA spare parts
222970110132	ASSY. SUPD-RH	TATA spare parts
222970110133	ASSY. SUPD-LH	TATA spare parts
222970110152	SUPD ASSY LH	TATA spare parts
222970110174	ASSY SPRAY SUPPRESSION	TATA spare parts
222970110186	SPRAY SUPPRESSION RH TT	TATA spare parts
222970120123	SUPDASSY	TATA spare parts
222970120124	SUPDASSY	TATA spare parts
222970120186	BRACKET ASSY SUPD MTG BS6	TATA spare parts
222970120196	BRACKET ASSY MUDGUARD MTG BS6	TATA spare parts
222970128254	PLATE U-BOLT MTG BS6-PH2	TATA spare parts
222970128288	CONNECTING BRACKET BS6	TATA spare parts
222970128289	CONNECTING BRACKET BS6	TATA spare parts
222970128290	BRACKET SIDE SUPPORT FRONT-LH BS6	TATA spare parts
222970128291	BRACKET SIDE SUPPORT FRONT-RH BS6	TATA spare parts
222970130110	SUPD ASSY LH	TATA spare parts
222970130111	SUPD ASSY RH	TATA spare parts
222970130114	ASSY SPRAY SUPPRESSION - LH	TATA spare parts
222970130115	SUPD ASSY LH	TATA spare parts

222970130116	SUPD ASSY RH	TATA spare parts
222970130122	ASSEMBLY SUPD LH	TATA spare parts
222970130123	SUPD ASSY RH	TATA spare parts
222970130129	SUPD ASSY LH	TATA spare parts
222970130130	SUPD ASSY RH	TATA spare parts
222970130144	SUPD ASSY LH BS6	TATA spare parts
222970130145	SUPD ASSY LH	TATA spare parts
222970130146	SUPD ASSY RH	TATA spare parts
222970130149	SUPD ASSY LH	TATA spare parts
222970130150	SUPD ASSY RH	TATA spare parts
222970130153	ASSY SPRAY SUPPRESSION - RH	TATA spare parts
222970130163	SUPD ASSY RH BS6	TATA spare parts
222970130169	SUPD ASSY	TATA spare parts
222970130170	BRACKETASSY SUPDMTG BS6	TATA spare parts
222970130187	BRACKET ASSY TAIL LAMP MTG	TATA spare parts
222970138237	BRACKET SIDE SUPPORT REAR-LH BS6	TATA spare parts
222970138238	BRACKET SIDE SUPPORT REAR-RH BS6	TATA spare parts
222970138255	CLIP (WIRING HARNESS) BS6	TATA spare parts
222970138268	BRACKET EOM CLIP MTG BS6	TATA spare parts
222970140115	BRACKET ASSY TAIL LAMP STIFFENER MTG	TATA spare parts
222970140120	SUPD ASSY LH	TATA spare parts
222970140121	SUPD ASSY RH	TATA spare parts
222970140150	SUPD ASSY 35WB	TATA spare parts
222970140152	SUPD ASSY 35WB	TATA spare parts
222970140155	SUPD ASSY LH BS6	TATA spare parts
222970140163	BRACKET ASSY SUPD MTG BS6	TATA spare parts
222970140167	SUPD ASSY LH	TATA spare parts
222970140168	SUPD ASSY RH	TATA spare parts
222970140178	SUPD ASSY LH	TATA spare parts
222970140179	SUPD ASSY RH	TATA spare parts
222970140180	SUPD ASSY	TATA spare parts
222970140181	SUPD ASSY	TATA spare parts
222970140186	SUPD ASSY BS6	TATA spare parts
222970140187	SUPD ASSY BS6	TATA spare parts
222970140188	SUPD ASSY LH BS6	TATA spare parts
222970140189	SUPD ASSY RH BS6	TATA spare parts
222970140192	BRACKET ASSY MUDGUARD MTG BS6	TATA spare parts
222970140193	SUPD ASSY LH BS6	TATA spare parts
222970140194	SUPD ASSY RH BS6	TATA spare parts
222970140197	SUPD ASSY RH BS6	TATA spare parts
222970148249	BRACKET MUDGUARD MTG	TATA spare parts
222970148261	TAIL LAMP MTG BKT LH	TATA spare parts
222970148262	TAIL LAMP MTG BKT RH	TATA spare parts
222970148266	MUDGUARD MTG BRACKET(FORM TYPE)	TATA spare parts
222970150101	SUPD ASSY LH	TATA spare parts
222970150103	SUPD ASSY LH BS6	TATA spare parts
222970150104	SUPD ASSY RH BS6	TATA spare parts

222970150106	SUPD ASSY	TATA spare parts
222970150107	SUPD ASSY LH BS6	TATA spare parts
222970150108	SUPD ASSY RH BS6	TATA spare parts
222970150111	SUPD ASSY LH	TATA spare parts
222970150112	SUPD ASSY RH	TATA spare parts
222970150113	SUPD ASSY LH BS6	TATA spare parts
222970150114	SUPD ASSY RH BS6	TATA spare parts
222970150115	SUPD ASSY LH	TATA spare parts
222970150116	SUPD ASSY RH	TATA spare parts
222970150117	SUPD ASSY LH	TATA spare parts
222970150118	SUPD ASSY LH	TATA spare parts
222970150119	SUPD ASSY LH	TATA spare parts
222970150120	SUPD ASSY RH	TATA spare parts
222970150121	SUPD ASSY RH	TATA spare parts
222970150122	SUPD ASSY	TATA spare parts
222970150123	SUPD ASSY	TATA spare parts
222970150130	SUPD ASSY BS6	TATA spare parts
222970150136	SUPD ASSY LH BS6	TATA spare parts
222970150137	SUPD ASSY RH BS6	TATA spare parts
222970150170	SUPD ASSY RH BS6	TATA spare parts
222970150185	SUPPORT PLATE ASSY BS6	TATA spare parts
222970160107	SUPD ASSY¿BS6	TATA spare parts
222970160108	SUPD ASSY¿BS6	TATA spare parts
222970160115	SUPD ASSY RH BS6	TATA spare parts
222970160121	SUPD ASSY BS6	TATA spare parts
222970160140	BRACKETASSY MUDGUARDMTG BS6	TATA spare parts
222970160143	SUPD ASSY RH BS6	TATA spare parts
222970160144	SUPD ASSY RH BS6	TATA spare parts
222970160145	SUPD ASSY	TATA spare parts
222970160146	SUPD ASSY LH BS6	TATA spare parts
222970160150	SUPD ASSY RH BS6	TATA spare parts
222970160151	SUPD ASSY BS6	TATA spare parts
222970160176	SUPD ASSY BS6	TATA spare parts
222970160177	SUPD ASSY BS6	TATA spare parts
222970160188	SUPD ASSY BS6	TATA spare parts
222970160189	SUPD ASSY BS6	TATA spare parts
222970160195	SUPD ASSY BS6	TATA spare parts
222970168231	GUSSET CROSS MEMBER	TATA spare parts
222970168232	GUSSET CROSS MEMBER	TATA spare parts
222970170104	BRACKET ASSY BS6	TATA spare parts
222970188209	PLATE U-BOLT MTG BS6	TATA spare parts
222970188259	MUDGUARD CENTER	TATA spare parts
222970188261	MUDGUARD LH	TATA spare parts
222970188262	MUDGUARD RH	TATA spare parts
222970188274	MUDGUARD	TATA spare parts
222970188275	MUDGUARD	TATA spare parts
222970188281	MUDGUARD CENTER BS6	TATA spare parts

222970188287	STAY ROD	TATA spare parts
222970188288	STAY ROD	TATA spare parts
222970188297	MUDGUARDLH BS6	TATA spare parts
222970188298	MUDGUARDRH BS6	TATA spare parts
222970188299	STAYROD BS6	TATA spare parts
222970190110	BRACKET ASSY MUDGUARD MTG BS6	TATA spare parts
222970190112	BRACKET ASSY MUDGUARD MTG RH BS6	TATA spare parts
222970198205	END PLATE LONG RUNNER BS6	TATA spare parts
222970198211	STOPPERPLATEBALATAPACKING BS6	TATA spare parts
222970198249	MUDGUARD CENTER BS6	TATA spare parts
222970198285	MUDGUARD BS6	TATA spare parts
222970200115	FRONT WALL ASSY	TATA spare parts
222970200118	FRONT WALL ASSY	TATA spare parts
222970218248	CONNECTING BRACKET BS6	TATA spare parts
222970218266	MUDGUARD CENTER BS6	TATA spare parts
222970218270	MUDGUARD CENTER BS6	TATA spare parts
222970218271	BRACKET BS6	TATA spare parts
222970228236	BRACKET BS6	TATA spare parts
222970238202	CAP SUPD FRONT	TATA spare parts
222970300124	ASSY SIDE WALL RH	TATA spare parts
222970300125	ASSY SIDE WALL LH	TATA spare parts
222970300143	SIDE WALL ASSY LH	TATA spare parts
222970300144	SIDE WALL ASSY RH	TATA spare parts
222970300173	SIDE WALL ASSY LH	TATA spare parts
222970300174	SIDE WALL ASSY RH	TATA spare parts
222970300196	SIDE WALL ASSY LH	TATA spare parts
222970303401	BUSH (OVER HEAD BAR)	TATA spare parts
222970306301	RETRO REFLECTIVE TAPE BS6	TATA spare parts
222970306303	RETRO REFLECTIVE TAPE BS6	TATA spare parts
222970306308	RETRO REFLECTIVE TAPE	TATA spare parts
222970306310	RETRO REFLECTIVE TAPE YELLOW BS6	TATA spare parts
222970306313	PACKING PAD (OVER HEAD BAR) BS6	TATA spare parts
222970308291	CLAMP HANDLE LH	TATA spare parts
222970308292	CLAMP HANDLE RH	TATA spare parts
222970310101	SIDE WALL ASSY RH	TATA spare parts
222970310104	SIDE WALL ASSY LH	TATA spare parts
222970310105	SIDE WALL ASSY RH	TATA spare parts
222970328245	WALL CAP FRONT SIDE WALL BS6	TATA spare parts
222970338233	HAT SECTION BS6	TATA spare parts
222970338234	BRACKET BS6	TATA spare parts
222970338236	BRACKET LH BS6	TATA spare parts
222970338237	BRACKET RH BS6	TATA spare parts
222970348201	STAY ROD BS6	TATA spare parts
222970400107	ASSY. TAIL GATE	TATA spare parts
222970400111	TAILGATE ASSY LOAD BODY	TATA spare parts
222970400113	ASSY.TAIL GATE	TATA spare parts
222970400117	ASSY TAIL GATE	TATA spare parts



222970400122	TAILGATE ASSY	TATA spare parts
222970400123	TAILGATE ASSY LOAD BODY	TATA spare parts
222970400132	TAILGATE ASSY BS6	TATA spare parts
222970406301	REFLECTIVETAPE BS6	TATA spare parts
222970406302	RETRO REFLECTIVE TAPE BS6	TATA spare parts
222970406304	RETRO REFLECTIVE TAPE RED BS6	TATA spare parts
222970408217	ENDCOVERTAILGATE(LH) BS6	TATA spare parts
222970408218	END COVER TAIL GATE (RH) BS6	TATA spare parts
222970408274	BRACKET BS6	TATA spare parts
222970800107	CLAMP ASSY U-BOLT SUPPORT	TATA spare parts
222970803201	U-CLAMP	TATA spare parts
222970803202	U-CLAMP	TATA spare parts
222970803203	U-BOLT	TATA spare parts
222970803204	U-BOLT	TATA spare parts
222970803205	CLAMP U-BOLT	TATA spare parts
222970803206	U-BOLT BS6	TATA spare parts
222970803801	PACKING U-CLAMP	TATA spare parts
222970807101	PLATE	TATA spare parts
222970808210	RESILIENCE MOUNTING BRACKET (FRAME)	TATA spare parts
222970808222	RESILIENCE MOUNTING BRACKET	TATA spare parts
222970808223	BRACKET CLEAT	TATA spare parts
222970900105	ASSY HINGE	TATA spare parts
222970900109	ASSY OVER HEAD BAR (FRONT)	TATA spare parts
222970900114	ASSEMBLY¿ RUBBER STOPPER	TATA spare parts
222970900117	OVERHEAD BAR ASSY BS6	TATA spare parts
222970900126	SUPD ASSY BS6	TATA spare parts
222970900128	SUPD ASSY LH	TATA spare parts
222970900129	SUPD ASSY RH	TATA spare parts
222970900131	SUPD ASSY RH BS6	TATA spare parts
222970900134	SUPD ASSY BS6	TATA spare parts
222970900201	SUPD ASSY LH	TATA spare parts
222970900202	SUPD ASSY RH	TATA spare parts
222970906301	BALATA PACKING (CLEAT)	TATA spare parts
222970906303	BALATA PACKING (LONG RUNNER)	TATA spare parts
222970906304	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222970906307	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222970906315	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222970906317	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222970906327	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222970906331	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222970906333	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222970906335	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222970906336	BALATA PACKING LONG RUNNER BS6	TATA spare parts
222970906915	HANDLE	TATA spare parts
222970907705	RUBBER BUFFER BS6	TATA spare parts
222970908226	WASHER BS6	TATA spare parts
222987100134	CRADLE ASSY CYL MTG BS6	TATA spare parts

222987100135	HINGE TAILGATE BS6	TATA spare parts
222987106906	PIPE BS6	TATA spare parts
222987106912	C-SECTION BS6	TATA spare parts
222987128201	MUDGUARD SUPPORT BS6	TATA spare parts
222987128203	MUDGUARD SUPPORT BS6	TATA spare parts
222987200103	BRACKET ASSY CYLINDER MTG BS6	TATA spare parts
222987300102	LANDING LEG BS6	TATA spare parts
222987900137	PIPE ASSY BS6	TATA spare parts
222987900144	PIPE ASSY BS6	TATA spare parts
222987907102	MUDGUARD MESH BS6	TATA spare parts
222987908207	SIDE MARKER LAMP MTG BS6	TATA spare parts
222987999901	REFLECTIVE TAPE BS6	TATA spare parts
222987999902	REFLECTIVE TAPE BS6	TATA spare parts
223001020001	EMG. DOOR ASSY	TATA spare parts
223010160001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
223010290001	EMERGENCY DOOR ASSY	TATA spare parts
223010340001	EMERGENCY DOOR ASSY	TATA spare parts
223010350001	EMERGENCY DOOR ASSEMBLY BS6	TATA spare parts
223020250001	COVER DRIVER DOOR	TATA spare parts
223020260001	COVER (ABS)	TATA spare parts
223020270001	COVER	TATA spare parts
223020280001	ACRYLIC COVER	TATA spare parts
223020310001	EMERGENCY DOOR COVER	TATA spare parts
223020660001	HINGE ASSEMBLY	TATA spare parts
223020950001	COVER	TATA spare parts
223144990101	GEAR PUMP	TATA spare parts
223170000131	ASSY LOAD BODY COMPLETE	TATA spare parts
223170000134	ASSY LOAD BODY COMPLETE WITH SUPERSTRUCTURE	TATA spare parts
223170000136	LOAD BODY ASSY	TATA spare parts
223170000139	ASSY LOAD BODY COMPLETE	TATA spare parts
223170000142	LOAD BODY ASSY .	TATA spare parts
223170000149	LOAD BODY ASSY COMPLETE	TATA spare parts
223170000222	LOAD BODY ASSY BS6	TATA spare parts
223170000224	LOAD BODY ASSY. BS6	TATA spare parts
223170100143	SPRAY SUPPRESSION ASSY LH BS6	TATA spare parts
223170100144	SPRAY SUPPRESSION ASSY RH BS6	TATA spare parts
223170100156	ASSY RUBBER PADING	TATA spare parts
223170107106	MOUNTING PLATE BS6	TATA spare parts
223170110190	FLOOR ASSY LOAD BODY BS6	TATA spare parts
223170128285	REAR STEP	TATA spare parts
223170128288	MUDGAURD FRONT STAY	TATA spare parts
223170128289	MUDGAURD STAY 520MM	TATA spare parts
223170158277	BALATA PACKAGING BS6	TATA spare parts
223170170123	FLOOR PANEL ASSY BS6	TATA spare parts
223170178219	BRACKET JERRY CAN MTG BS6	TATA spare parts
223170200114	ASSY SUPPORT LH (CANOPY SUPERSTRUCTURE)	TATA spare parts
223170200115	ASSY SUPPORT RH (CANOPY SUPERSTRUCTURE)	TATA spare parts

223170200116	ASSY SUPPORT CENTER	TATA spare parts
223170200121	FRONT WALL ASSY BS6	TATA spare parts
223170300119	SIDE PANEL ASSY BS6	TATA spare parts
223170400129	ASSY TAIL GATE	TATA spare parts
223170400132	TAILGATE ASSY	TATA spare parts
223170400145	LADDER ASSY BS6	TATA spare parts
223170400150	LADDER ASSY BS6	TATA spare parts
223170400152	LADDER ASSY BS6	TATA spare parts
223170400153	LADDER ASSY RH BS6	TATA spare parts
223170400154	LADDER ASSY LH BS6	TATA spare parts
223170400157	TAILGATE ASSY BS6	TATA spare parts
223170406306	REFLECTIVE TAPE BS6-PH2	TATA spare parts
223170500136	ASSY CANOPY SUPPORT	TATA spare parts
223170500142	ASSY CANVAS FOR SD1015/42WB	TATA spare parts
223170500165	KIT-CANOPY LOAD BODY -- BS6	TATA spare parts
223170503304	BRACKET LH FRONT & REAR (SUPERSTRUCTURE)	TATA spare parts
223170503305	BRACKET RH FRONT REAR (SUPERSTRUCTURE)	TATA spare parts
223170504205	CLAMP (BACK REST)	TATA spare parts
223170508214	TUBULAR FRAME BS6	TATA spare parts
223170509902	TARPAULIN FOR LPTA 2038 MHC 6X6 LOAD BOD	TATA spare parts
223170804202	U-BOLT PACKING	TATA spare parts
223170808205	PACKING	TATA spare parts
223170808206	CLAMPING PLATE	TATA spare parts
223170809902	U-BOLT	TATA spare parts
223170809911	U BOLT	TATA spare parts
223170900108	HINGE ASSY BS6	TATA spare parts
223170900177	ASSY STOPPER PAD BS6	TATA spare parts
223170906705	PIN (HINGE)	TATA spare parts
223170906706	PIN (HINGE)	TATA spare parts
223170908201	LATCH HANDLE RH	TATA spare parts
223170908202	LATCH HANDLE LH	TATA spare parts
223170908232	PIN	TATA spare parts
223170920109	SUPD ASSY LH	TATA spare parts
223170920110	SUPD ASSY RH	TATA spare parts
223170927730	RUBBER PAD	TATA spare parts
223170938265	HANDLE LATCH LH BS6	TATA spare parts
223170990144	HEAT SHIELD ASSY FRONT WALL BS6	TATA spare parts
223170990145	HEAT SHIELD ASSY SIDE WALL BS6	TATA spare parts
223300000101	BRAKE CHAMBER TY 30/30	TATA spare parts
223300000102	TRAILER ABS MODULE	TATA spare parts
223300000103	DIAGNOSTICS CABLE + X1 CONNECTOR	TATA spare parts
223300000104	PALM COUPLING SUPPLY (RED)	TATA spare parts
223300000105	PALM COUPLING CONTROL (YELLOW)	TATA spare parts
223300000106	AUTOMATIC LOAD SENSING VALVE WITHOUT RE	TATA spare parts
223300000107	PARK AND SHUNT VALVE WITH EMERGENCY FUN	TATA spare parts
223300000108	TEST CONNECTOR (M16X1.5)	TATA spare parts
223300000109	TEST CONNECTOR (M22X1.5)	TATA spare parts

223300000110	POWER SUPPLY CABLE ISO 7638 12M	TATA spare parts
223300000111	WHEEL SPEED SENSOR EXTENSION CABLE 4M	TATA spare parts
223300000112	BRAKE CHAMBER TY 30	TATA spare parts
223300000113	ABS READY ROUND 5 IN AXLE	TATA spare parts
223300000114	ABS READY ROUND 5 IN AXLE	TATA spare parts
223300000115	SPRING SEAT (20MM)	TATA spare parts
223300003101	OUTER BEARING (TM) CUP	TATA spare parts
223300003102	INNER BEARING (90MM) CUP	TATA spare parts
223300003208	FLANGE BOLT M8*1.25*25 (HUB CAP)	TATA spare parts
223300006504	SPINDLE ADSJUSMENT NUT	TATA spare parts
223300006505	SPINDLE LOCK NUT	TATA spare parts
223300008204	HUB SEAL	TATA spare parts
223300009203	LOCK WASHER	TATA spare parts
223300009204	TAB LOCK WASHER	TATA spare parts
223300009904	HUB CAP O RING	TATA spare parts
223300909001	LOAD SENSING VALVE LINKAGE	TATA spare parts
223310190001	DRIVER DOOR ASSEMBLY	TATA spare parts
223310300001	DRIVER DOOR ASSY	TATA spare parts
223310330001	DRIVER DOOR ASSEMBLY	TATA spare parts
223320720001	HINGE COVER	TATA spare parts
223378106604	PISTON EYE GREASED	TATA spare parts
223387100002	STABILIZER ASSEMBLY	TATA spare parts
223387100101	TIPPING CYLINDER	TATA spare parts
223387100102	TIPPING CYLINDER	TATA spare parts
223387100103	TIPPING CYLINDER	TATA spare parts
223387100104	TIPPING CYLINDER	TATA spare parts
223387100105	TIPPING CYLINDER	TATA spare parts
223387100106	TIPPING CYLINDER	TATA spare parts
223387100107	TIPPING CYLINDER	TATA spare parts
223387100108	TIPPING CYLINDER	TATA spare parts
223387100109	HYFIX ASSEMBLY	TATA spare parts
223387100110	RETURN LINE FILTER ASSYEMBLY(PLASTIC CAP	TATA spare parts
223387100111	RETURN LINE FILTER ASSYEMBLY(AL. CAP)	TATA spare parts
223387100112	BREATHER FILTER ASSEMBLY	TATA spare parts
223387100113	P.T VALVE ASSEMBLY	TATA spare parts
223387100114	KNOCK-OFF VALVE ASSEMBLY + ACCESSORIES	TATA spare parts
223387100121	CRADLE ASSEMBLY-TATA 16 RB	TATA spare parts
223387100122	SUBFRAME ASSEMBLY-TATA 3138 18 RB	TATA spare parts
223387100123	SUBFRAME ASSEMBLY-TATA 3138 20STD	TATA spare parts
223387100124	SUBFRAME ASSEMBLY-TATA 2538 16STD	TATA spare parts
223387100125	TIPPING CYLINDER TATA 16 STD	TATA spare parts
223387100126	TIPPING CYLINDER TATA 16 RB	TATA spare parts
223387100127	CYLINDER	TATA spare parts
223387100128	CYLINDER	TATA spare parts
223387100129	CYLINDER	TATA spare parts
223387100130	CYLINDER	TATA spare parts
223387100132	CYLINDER MTG PIN-TATA 16 RB	TATA spare parts

223387100133	CYLINDER TOP MOUNTING PLATE	TATA spare parts
223387100134	CYLINDER MTG PIN-TATA18 RB	TATA spare parts
223387100135	SEAMLESS TUBE ASSEMBLY KIT-(C-TYPE)	TATA spare parts
223387100144	HYVA JT VALVE	TATA spare parts
223387100145	PT VALVE ASSY	TATA spare parts
223387103101	REAR HINGE BEARING BUSH DIA60	TATA spare parts
223387103102	REAR HINGE BEARING BUSH DIA75	TATA spare parts
223387103201	BOLT M8 X 1.25 X 20 SET	TATA spare parts
223387103202	BOLT M24 X 100	TATA spare parts
223387103203	FLANGE BOLT M14X55 X1.5 P 10.9	TATA spare parts
223387103204	HEX. HEAD BOLT M14X1.5X50-10.9	TATA spare parts
223387103205	HEX. HEAD BOLT M16X150 X2 P - 10.9	TATA spare parts
223387103206	HEX. HEAD BOLT M16X110X2 P - 10.9	TATA spare parts
223387103207	LOCKING BOLT M12X90	TATA spare parts
223387103208	BOLT M16	TATA spare parts
223387103209	HEX HEAD BOLT M6 X 14	TATA spare parts
223387103210	HEX. SCREW M5 X20	TATA spare parts
223387103211	HEX. SCREW M8 X30- 8.8	TATA spare parts
223387103212	SKT. HEAD CAP SCREW M8X80- 8.8	TATA spare parts
223387103213	HEX. BOLT M12 X75	TATA spare parts
223387103214	HEX. BOLT M12 X75- 10.9	TATA spare parts
223387103301	OIL TANK BRACKET-TATA 20 STD	TATA spare parts
223387103401	BODY PROP BUSH	TATA spare parts
223387103402	REAR HINGE BUSH	TATA spare parts
223387103403	CI BUSH	TATA spare parts
223387103404	CHASSIS BRACKET BOTTOM (CI BUSH)-TATA 18	TATA spare parts
223387103405	CHASSIS BRACKETBOTTOM (IGUS BUSH)-TATA 1	TATA spare parts
223387103406	CHASSIS BRACKETBOTTOM (IGUS BUSH)-TATA 1	TATA spare parts
223387103407	IGUSBUSH	TATA spare parts
223387103408	BUSH	TATA spare parts
223387103409	DRILLED BUSH-TATA 16/18 RB	TATA spare parts
223387103410	BUSH	TATA spare parts
223387103412	BUSH	TATA spare parts
223387104201	U-BOLT	TATA spare parts
223387104301	CIRCLIP DIN 472	TATA spare parts
223387104302	HOSE CLIP FOR SUCTION HOSE	TATA spare parts
223387104701	DUST COVER YELLOW	TATA spare parts
223387104702	DUST COVER YELLOW	TATA spare parts
223387104703	DUST COVER FOR COVER YELLOW	TATA spare parts
223387104704	COVER PIN60	TATA spare parts
223387104705	COVER (PLASTIC)	TATA spare parts
223387104706	COVER (ALUMINIUM)	TATA spare parts
223387104707	COVER	TATA spare parts
223387105001	OIL TANK-TATA 16 RB	TATA spare parts
223387105002	OIL TANK-TATA 18 RB/20 STD	TATA spare parts
223387105003	P.T. VALVE MTG. BLOCK	TATA spare parts
223387105004	TIPPING VALVE MOUNTING BLOCK	TATA spare parts

223387105801	HOSE RLF	TATA spare parts
223387106501	TOP NUT M48X3 ZP	TATA spare parts
223387106502	STUD WITH NUT	TATA spare parts
223387106503	M-16 NUT	TATA spare parts
223387106504	NUT M24	TATA spare parts
223387106505	NYLOC COARSE THREAD NUT M16X2 P	TATA spare parts
223387106506	FLANGED NUT M14X1.5 - 10.9	TATA spare parts
223387106507	NYLOC NUT M12	TATA spare parts
223387106508	NUT M16	TATA spare parts
223387106509	NYLOC NUT M6	TATA spare parts
223387106510	PLAIN NUT M12	TATA spare parts
223387106601	PISTON HEAD MACHINED	TATA spare parts
223387106604	PISTON EYE SPH. GREASED	TATA spare parts
223387106605	PISTON EYE SPH. GREASED	TATA spare parts
223387106606	PISTON HC	TATA spare parts
223387106607	PISTON HC	TATA spare parts
223387106608	PISTON HC	TATA spare parts
223387106609	PISTON HC	TATA spare parts
223387106610	PISTON HC	TATA spare parts
223387106611	PISTON HC	TATA spare parts
223387106612	PISTON HC	TATA spare parts
223387106613	PISTON HC	TATA spare parts
223387106701	PIN-3	TATA spare parts
223387106702	PIN-2	TATA spare parts
223387106703	PIN-1	TATA spare parts
223387106704	SECURING PIN	TATA spare parts
223387106705	SPLIT PIN DIA 8 X 45	TATA spare parts
223387106706	STAY ROPE MTG PIN	TATA spare parts
223387106707	TAILDOOR HINGE PIN DIA25X95L	TATA spare parts
223387106708	TAILDOOR HINGE PIN DIA30X95L	TATA spare parts
223387106709	STABILIZER MTG TOP PIN	TATA spare parts
223387106710	PROP MTG PIN	TATA spare parts
223387106711	STABILIZER HINGE PIN	TATA spare parts
223387106712	LOCKING PIN DIA10X25L	TATA spare parts
223387106713	CYLINDER MTG PIN-TATA 16/20 STD	TATA spare parts
223387106714	SPLIT PIN DIA 10X75	TATA spare parts
223387106801	OUTER STOPRING HD	TATA spare parts
223387106802	OUTER STOPRING HD	TATA spare parts
223387106803	OUTER STOPRING	TATA spare parts
223387106804	OUTER STOPRING	TATA spare parts
223387106805	LIFTRING HD	TATA spare parts
223387106806	SNAPRING FOR PISTON	TATA spare parts
223387106807	SNAPRING FOR PISTON	TATA spare parts
223387106808	STAY ROPE WITH SPRING TATA 16 RB	TATA spare parts
223387106810	LP ADAPTOR 1 1/2IN + ORING	TATA spare parts
223387106811	LP ELBOW 1IN- + PARTS	TATA spare parts
223387106812	ELBOW 1 1/4IN + PARTS	TATA spare parts

223387106813	ELBOW 1 1/2IN + PARTS	TATA spare parts
223387106814	ADAPTOR G3/4INX1IN3/16 UNF	TATA spare parts
223387106815	ADAPTOR 1IN BSP X 1IN 3/16 UNF	TATA spare parts
223387106816	ADAPTOR M30X2 X 3/4IN BSP	TATA spare parts
223387106817	ADAPTOR M30X2 X 1*1/4IN BSP	TATA spare parts
223387106818	ADAPTOR 1INX1IN	TATA spare parts
223387106819	ADAPTOR 1 1/4INX1IN	TATA spare parts
223387106901	FLANGE PIPE	TATA spare parts
223387106905	PVC FLEXIBLE TUBE	TATA spare parts
223387106906	AIR TUBE OD 6 X ID 4MM	TATA spare parts
223387106907	SEAMLESS TUBE ASSEMBLY-60L	TATA spare parts
223387107101	LOCKING PLATE	TATA spare parts
223387107102	LOCKING PLATE	TATA spare parts
223387107103	LOCKING PLATE	TATA spare parts
223387107104	BOTTOM PLATE	TATA spare parts
223387107105	BOTTOM PLATE	TATA spare parts
223387107106	BOTTOM PLATE	TATA spare parts
223387107107	BOTTOM PLATE PISTON	TATA spare parts
223387107108	BOTTOM PLATE PISTON	TATA spare parts
223387107109	BASE SAE	TATA spare parts
223387107110	BASE SAE	TATA spare parts
223387107111	BASE SAE	TATA spare parts
223387107112	BASE SAE	TATA spare parts
223387107113	BASE SAE	TATA spare parts
223387107114	BASE SAE	TATA spare parts
223387107115	BASE SAE	TATA spare parts
223387107116	STAGE	TATA spare parts
223387107117	STAGE	TATA spare parts
223387107119	STAGE	TATA spare parts
223387107120	STAGE	TATA spare parts
223387107121	STAGE	TATA spare parts
223387107122	STAGE	TATA spare parts
223387107123	STAGE	TATA spare parts
223387107124	STAGE	TATA spare parts
223387107125	STAGE	TATA spare parts
223387107126	STAGE	TATA spare parts
223387107127	STAGE	TATA spare parts
223387107128	STAGE	TATA spare parts
223387107129	STAGE	TATA spare parts
223387107130	STAGE	TATA spare parts
223387107131	STAGE	TATA spare parts
223387107132	SEAL BOTTOM PLATE	TATA spare parts
223387107133	SEAL BOTTOM PLATE	TATA spare parts
223387107134	SEAL BOTTOM PLATE	TATA spare parts
223387107135	BASE SAE	TATA spare parts
223387107136	THRUST PLATE	TATA spare parts
223387107137	THRUST PLATE	TATA spare parts

223387107138	REAR ATTACHMENT PLATE LH-16 RB TATA	TATA spare parts
223387107139	REAR ATTACHMENT PLATE LH-16 STD TATA	TATA spare parts
223387107140	RIBBED ATTACHMENT PLATE - 1	TATA spare parts
223387107141	RIBBED ATTACHMENT PLATE-2	TATA spare parts
223387107142	CYLINDER TOP MOUNTING PLATE	TATA spare parts
223387107701	SHAFT SEAL	TATA spare parts
223387107702	SHAFT SEAL	TATA spare parts
223387107703	SHAFT SEAL	TATA spare parts
223387107704	SEAL KIT GEAR PUMP 4H	TATA spare parts
223387107705	SEAL KIT GEAR PUMP 4H	TATA spare parts
223387107706	SEAL KIT GEAR PUMP 4H	TATA spare parts
223387107707	SEAL	TATA spare parts
223387107708	SEAL	TATA spare parts
223387107709	RUBBER PAD	TATA spare parts
223387107710	RUBBER PAD BELOW OIL TANK-18 RB TATA	TATA spare parts
223387107711	RUBBER PAD BELOW OIL TANK-TATA 16 STD	TATA spare parts
223387107712	RUBBER FOR METAL STRAP-18 RB TATA	TATA spare parts
223387107713	BONDED SEAL 3/4IN	TATA spare parts
223387107714	DOWTY SEAL 1IN	TATA spare parts
223387107715	BONDED SEAL 1 1/4IN	TATA spare parts
223387107716	HOSE VALVE TO CYLINDER 3/4INI.DX 1500 R2	TATA spare parts
223387107717	HOSE PUMP TO VALVE 1INIDX2200 POWERFLEX	TATA spare parts
223387107718	HOSE VALVE TO CYLINDER 3/4INI.D X 1800 S	TATA spare parts
223387107719	HOSE PUMP TO VALVE 3/4INIDX3130 R2 1INBS	TATA spare parts
223387107720	HOSE PUMP TO VALVE 1INID X2500LG 1INBSP	TATA spare parts
223387107721	HOSE TANK TO PUMP 1 3/4IN 1.2M	TATA spare parts
223387107722	HOSE VALVE TO CYLINDER ID1INX1500L-1INBS	TATA spare parts
223387107801	O-RING COVER	TATA spare parts
223387107802	RETURN LINE FILTER SEAL KIT	TATA spare parts
223387107901	DRIVEN SHAFT	TATA spare parts
223387107902	DRIVER SHAFT	TATA spare parts
223387107903	STABILIZER MTG. SHAFT	TATA spare parts
223387107904	REAR HINGE SHAFT DIA60X970L	TATA spare parts
223387107905	REAR HINGE SHAFT X75X970L BS6	TATA spare parts
223387108001	HEX. HEAD SCREW M8X30 - 8.8	TATA spare parts
223387108002	HEX. HEAD SCREW M8X22	TATA spare parts
223387108003	SCREW	TATA spare parts
223387108004	SOCKET HEAD CAP SCREW M6 X 30-8.8	TATA spare parts
223387108201	METAL STRAP-TATA 18 RB	TATA spare parts
223387108202	RUBBER FOR METAL STRAP-TATA 16 STD	TATA spare parts
223387108203	METAL STRAP-TATA 16 STD	TATA spare parts
223387108601	CYLINDER EYE SPACER	TATA spare parts
223387108701	SPRING	TATA spare parts
223387108702	SPRINGS (PIVOT)	TATA spare parts
223387109001	NON RETURN VALVE	TATA spare parts
223387109002	O RING KIT - PT VALVE	TATA spare parts
223387109201	WASHER M48 DIN 125B ZP	TATA spare parts



223387109202	SPRING WASHER M8 SET	TATA spare parts
223387109203	M8 SPRING WASHER	TATA spare parts
223387109204	SPRING WASHER M24	TATA spare parts
223387109205	M16 HARDENED WASHER 32/17X5	TATA spare parts
223387109207	PLAIN WASHER M6	TATA spare parts
223387109208	COPPER WASHER 1/8IN	TATA spare parts
223387109209	WASHER	TATA spare parts
223387109210	PL. WASHER M12	TATA spare parts
223387109211	M5 SPRING WASHER	TATA spare parts
223387109212	M8 SPRING WASHER SQ. SECTION	TATA spare parts
223387109213	COPPER WASHER 1X1/2 IN	TATA spare parts
223387109214	COPPER WASHER 1X1/2IN	TATA spare parts
223387109901	SLIDER 110 (2X1/2) MK4	TATA spare parts
223387109902	SLIDER 129 (2X1/2) MK4	TATA spare parts
223387109903	SLIDER MK4	TATA spare parts
223387109904	SLIDER MK4	TATA spare parts
223387109905	SPHERICAL EYE D.50 GREASING TYPE	TATA spare parts
223387109906	SLIDER (2X1/2)	TATA spare parts
223387109907	SLIDER (2X1/2) MK4	TATA spare parts
223387109908	SLIDER (2X1/2)	TATA spare parts
223387109909	SLIDER	TATA spare parts
223387109910	SLIDER (2X1/2)	TATA spare parts
223387109911	SLIDER (2X1/2) MK4	TATA spare parts
223387109912	SLIDER	TATA spare parts
223387109913	SLIDER	TATA spare parts
223387109914	OUTER STOPRING HD	TATA spare parts
223387109915	OUTER STOPRING	TATA spare parts
223387109916	OUTER STOPRING HD	TATA spare parts
223387109917	OUTER STOPRING	TATA spare parts
223387109918	OUTER STOPRING	TATA spare parts
223387109919	LIFTRING	TATA spare parts
223387109920	LIFTRING	TATA spare parts
223387109921	LIFTRING	TATA spare parts
223387109922	SPHERICAL EYE D.50 MAINT.FREE	TATA spare parts
223387109923	COMPLETE SEAL KIT FOR CYLINDER	TATA spare parts
223387109924	COMPLETE SEAL KIT FOR CYLINDER	TATA spare parts
223387109925	COMPLETE SEAL KIT FOR CYLINDER	TATA spare parts
223387109926	COMPLETE SEAL KIT FOR CYLINDER	TATA spare parts
223387109927	GEAR PUMP-4H	TATA spare parts
223387109928	GEAR PUMP-4H	TATA spare parts
223387109929	GEAR PUMP-4H BS2/3/4/6	TATA spare parts
223387109930	POWER BLOCK (RUBBER PAD)	TATA spare parts
223387109931	MOUNTING EYE	TATA spare parts
223387109932	HOOK	TATA spare parts
223387109933	GREASE NIPPLE	TATA spare parts
223387109934	ALUMINIUM BODY	TATA spare parts
223387109935	RETURN LINE FILTER ELEMENT	TATA spare parts

223387109936	HOUSING	TATA spare parts
223387109937	BREATHER FILTER ELEMENT	TATA spare parts
223387109938	SLEEVE	TATA spare parts
223387109939	BREATHER EXTENSION HT	TATA spare parts
223387109940	PRESSURE CATRIDGE	TATA spare parts
223387109941	STAY ROPE WITH SPRING 1875 L	TATA spare parts
223387109942	STAY ROPE WITH SPRING 2000 L	TATA spare parts
223387109943	STAY ROPE WITH SPRING 1950 L	TATA spare parts
223387109944	STAY ROPE WITH SPRING 1810 L	TATA spare parts
223387109945	STAY ROPE WITH SPRING 1840 L	TATA spare parts
223387109946	STAY ROPE WITH SPRING 1775 L	TATA spare parts
223387109947	GREASE NIPPLE	TATA spare parts
223387109948	BODY PROP	TATA spare parts
223387109950	UPPER PIVOT	TATA spare parts
223387109951	UPPER PIVOT	TATA spare parts
223387109952	FRONT LOWER PIVOT LH	TATA spare parts
223387109953	LOWER PIVOT	TATA spare parts
223387109954	LOCKING RING DIA75	TATA spare parts
223387109955	LOCKING RING DIA60	TATA spare parts
223387109956	STAGE-1360-HC	TATA spare parts
223387109957	STAGE 1440-HC	TATA spare parts
223387109958	STAGE 1440-HC	TATA spare parts
223387109959	GREASE NIPPLE	TATA spare parts
223387109960	NYLON CABLE TIE 4 X 254	TATA spare parts
223387109961	CONNECTOR 1/8IN BSPX6X4 PU	TATA spare parts
223387109962	AIR CONTROL VALVE BS2/3/4	TATA spare parts
223387109963	OIL LEVEL INDICATOR	TATA spare parts
223387109965	OIL TANK-TATA 16 STD	TATA spare parts
223387109966	BALL VALVE 1 1/2IN	TATA spare parts
223449108204	CLAMP	TATA spare parts
223489107701	PACKING FRONT(COWL MTG.)	TATA spare parts
223610200001	FRONT FRP PANEL	TATA spare parts
223620360001	HINGE	TATA spare parts
223620370001	HINGE	TATA spare parts
223620450001	STAY ROD FOR FRONT FLAP	TATA spare parts
223620500001	FRT PNL CENT - SUPREME	TATA spare parts
223620530001	FRT PILLAR LH - SUPREME	TATA spare parts
223620540001	FRT PILLAR RH - SUPREME	TATA spare parts
22391160000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 3521.T B	TATA spare parts
223926800101	BASE PLATE SUPPORT TUBE ASSY	TATA spare parts
223926800102	BASE PLATE SUPPORT TUBE ASSY	TATA spare parts
223926800103	GEAR SHIFT UNIT ASSY	TATA spare parts
223926800104	GEAR SELECT CABLE ASSY	TATA spare parts
223926800105	GEAR SELECT CABLE ASSY	TATA spare parts
223926800106	CABLE SHIFT SYSTEM ASSY	TATA spare parts
223926800107	TURNING TUBE ASSY BS6	TATA spare parts
223926800110	TURNING TUBE ASSY BS6	TATA spare parts

223926800112	TURNING TUBE ASSY BS6	TATA spare parts
223926800114	TURNING TUBE ASSY BS6	TATA spare parts
223926800116	TURNING TUBE ASSY BS6-PH2	TATA spare parts
223926800120	TURNING TUBE ASSY BS6-PH2	TATA spare parts
223926800123	TURNING TUBE ASSY BS6-PH2	TATA spare parts
223926800124	TURNING TUBE ASSY BS6-PH2	TATA spare parts
223926800126	TURNING TUBE ASSY BS6-PH2	TATA spare parts
223926803701	BRACKET BS6	TATA spare parts
223926803702	BRACKET GEAR SHIFT LEVER MTG BS6	TATA spare parts
223926810101	SUPPORT TUBE ASSY BS6	TATA spare parts
223926820101	ANCHOR BRACKET ASSY SHIFT CABLE CABLE	TATA spare parts
223926820104	BASE PLATE ASSY	TATA spare parts
223926820106	ANCHOR BRACKET ASSY SHIFT CABLE BS6	TATA spare parts
223929300101	BUNDY TUBE ASSY LONG MEMBER	TATA spare parts
223930100101	BRACKET ASSY ACCELERATOR MTG BS6	TATA spare parts
223931000105	FRAME ASSY WITH FITMENT BS6	TATA spare parts
223931000111	FRAME ASSY WITH FITMENT	TATA spare parts
223931000115	FRAME ASSY WITH FITMENT BS6	TATA spare parts
223931000117	FRAME ASSY WITH FITMENT BS6	TATA spare parts
223931000126	FRAME ASSY WITH FITMENT BS6	TATA spare parts
223931200101	CROSS MEMBER ASSY BS6	TATA spare parts
223931200105	BRACKET ASSY RAIDATOR MTG RH BS6	TATA spare parts
223931200106	BRACKET ASSY RAIDATOR MTG LH BS6	TATA spare parts
223941100103	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
223941100104	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
223941110101	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
223941110103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
223941110104	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
223941110105	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
223941110106	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
223941110111	PROPELLER SHAFT ASSY-COUPLING BS6	TATA spare parts
223941110113	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
223941120101	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
223941120102	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
223941120104	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
223941120105	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
223941120106	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
223941303301	BRACKET ASSY CENTER BRG MTG	TATA spare parts
223941303303	BRACKET CENTER BRG MTG BS6	TATA spare parts
223941303304	BRACKET CENTER BRG MTG	TATA spare parts
223941303305	BRACKET CENTER BRG MTG	TATA spare parts
223941303306	BRACKET CENTER BRG MTG BS6	TATA spare parts
223941303307	BRACKET CENTER BRG MTG BS6	TATA spare parts
223941303308	BRACKET CENTER BRG MTG BS6	TATA spare parts
223941990101	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
223941990103	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
223941990108	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts

223941990109	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
223941990111	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
223941990112	LONG FORK ASSY BS6-PH2	TATA spare parts
223943203301	BRACKET BS6	TATA spare parts
223943700108	AIRCOMPRESSORASSY BS6	TATA spare parts
223943900102	PIPE BUNCH ASSY	TATA spare parts
223943900113	METAL PIPE ASSY	TATA spare parts
223943900116	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
223943900150	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
223943900154	METAL PIPE ASSY BS6	TATA spare parts
223943900156	METAL PIPE ASSY BS6	TATA spare parts
223943900161	PIPE BUNCH ASSY	TATA spare parts
223943900170	METAL PIPE ASSY BS6	TATA spare parts
223943900182	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
223943900195	METAL PIPE ASSY BS6	TATA spare parts
223943900197	METAL PIPE ASSY BS6	TATA spare parts
223943900202	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
223943900221	PIPE BUNCH ASSY BS6	TATA spare parts
223943910102	NYLON PIPE BUNCH ASSY	TATA spare parts
223943910110	PIPE BUNCH ASSY BS6	TATA spare parts
223943910121	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
223943910141	PIPEBUNCHASSY BS6	TATA spare parts
223943980112	MINOR KIT AIR COMPRESSOR BS6	TATA spare parts
223943980113	KIT PISTON AND CONNECTING ROD BS6	TATA spare parts
223943980114	MINOR KIT CYLINDER HEAD BS6	TATA spare parts
223943980116	MAJOR KIT CYLINDER HEAD BS6	TATA spare parts
223943980117	MAJOR KIT CYLINDER HEAD BS6	TATA spare parts
223943980118	MINOR KIT CYLINDER HEAD BS6	TATA spare parts
223946600101	POWER STEERING GEAR ASSY	TATA spare parts
223946600102	HOUSING ASSY	TATA spare parts
223946600103	WORM VALVE & RACK ASSY	TATA spare parts
223946600104	S/SHAFT ASSY	TATA spare parts
223946800101	PRESSURE LINE ASSY STG GEAR BOX END	TATA spare parts
223946800102	SUCTION LINE ASSY	TATA spare parts
223946800103	PRESSURE LINE ASSY STG GEAR BOX END	TATA spare parts
223946800104	HIGH PRESSURE LINE ASSY PUMP END	TATA spare parts
223946990123	SEAL KIT ASSY	TATA spare parts
223947500105	BRACKET ASSY FUEL TANK MTG BS6	TATA spare parts
223947500106	BRACKET ASSY BS6	TATA spare parts
223947507103	SPACER BS6	TATA spare parts
223947600101	FUEL SUCTION PIPE ASSY	TATA spare parts
223947600102	SUCTION PIPE T-CONN-3 TO FUEL FILTER	TATA spare parts
223947600104	RETURN PIPE ASSY FEED PUMP TO FUEL TANK	TATA spare parts
223947600105	FUEL SUCTION PIPE ASSY FILTER TO FIP	TATA spare parts
223947600106	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
223947600109	FUEL SUCTION PIPE ASSY TANK TO P/FILTER	TATA spare parts
223947600110	SUCTION PIPE ASSY FILTER TO PUMP BS6	TATA spare parts

223947600111	SUCTION PIPE ASSY FILTER TO FEED PUMP BS	TATA spare parts
223947600112	RETURN PIPE HP PUMP TO T-CONN BS6	TATA spare parts
223947600114	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
223947700101	BRACKET ASSY FILTER MTG	TATA spare parts
223949200101	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
223949200103	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
223949200104	BRACKET ASSY SILENCER MTG	TATA spare parts
223949200106	CLAMP ASSY EGP MTG BS6	TATA spare parts
223949200107	BRACKET ASSY EGP MTG BS6	TATA spare parts
223949200109	BRACKET ASSY BS6	TATA spare parts
223949200113	EXHAUST PIPE ASSY BS6	TATA spare parts
223949200114	BRACKET ASSY DOSING UNIT MTG BS6	TATA spare parts
223949200115	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
223949200123	FLEX BELLOW ASSY BS6	TATA spare parts
223949200126	PRESSURE LINE SM TO DM BS6	TATA spare parts
223949200127	PIPE RETURN LINE BS6	TATA spare parts
223949200128	DEF RESERVOIR ASSY BS6	TATA spare parts
223949200129	FILTER HEAD BS6	TATA spare parts
223949200130	PLASTIC CAP DEF TANK WITH LOCK BS6	TATA spare parts
223949200131	UREA TANK ASSY BS6	TATA spare parts
223949200136	PRESSURE LINE SM TO DM BS6	TATA spare parts
223949200137	PIPE RETURN LINE BS6	TATA spare parts
223949200140	SUCTION PIPE BS6	TATA spare parts
223949200141	SUCTION PIPE BS6	TATA spare parts
223949200150	BRACKET ASSY-EXHAUST PIPE SUPPORT BS6	TATA spare parts
223949203302	L-BRACKET EXHAUST PIPE MTG	TATA spare parts
223949203303	BRACKET EXHAUST PIPE CLAMPING	TATA spare parts
223949203310	L-BRACKET EXHAUST MTG BS6	TATA spare parts
223949203311	BRACKET BS6	TATA spare parts
223949203314	BRACKET SILENCER MTG	TATA spare parts
223949204201	CLAMP EGP MTG BS6	TATA spare parts
223949204202	DRAIN PLUG BS6	TATA spare parts
223949205801	BREATHERASSY BS6	TATA spare parts
223949206903	TUBE HOSE TO DPS	TATA spare parts
223949206906	TUBE HOSE TO DPS	TATA spare parts
223949207701	RETAINER BS6	TATA spare parts
223949207801	SEALINGRING BS6	TATA spare parts
223949208201	CLAMP SILENCER MTG	TATA spare parts
223949990115	KIT-EXHAUST SHIELD BS6	TATA spare parts
223949990117	BRACKET ASSY BS6	TATA spare parts
223954600101	BATTERY CABLE +VE BCS O/P TO SM	TATA spare parts
223954600102	BATTERY CABLE -VE	TATA spare parts
223954600103	WIRING HARNESS ENGINE	TATA spare parts
223954600104	WIRING HARNESS FRONT	TATA spare parts
223954600105	WIRING HARNESS MAIN	TATA spare parts
223954600108	WIRING HARNESS TAIL	TATA spare parts
223954600113	BRACKET ASSY MEGA FUSE MTG	TATA spare parts

223954600114	WIRING HARNESS TAIL BS6	TATA spare parts
223954600115	BRACKET ASSY RELAY & FUSE BOX MTG BS6	TATA spare parts
223954600119	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
223954600122	WIRING HARNESS TAIL BS6	TATA spare parts
223954600123	WIRING HARNESS RPAS BS6	TATA spare parts
223954600124	WIRING HARNESS TAIL	TATA spare parts
223954600127	WIRING HARNESS ABS FRAME	TATA spare parts
223954600129	WIRING HARNESS ABS FRAME 4S4M BS6	TATA spare parts
223954606301	STICKER MAXI FUSE BOX BS6	TATA spare parts
223954610101	WIRING HARNESS-MAIN BS6	TATA spare parts
223954630101	WIRING HARNESS TAIL BS6	TATA spare parts
223954630102	WIRING HARNESS TAIL BS6	TATA spare parts
223954630103	WIRING HARNESS ABS FRAME BS6	TATA spare parts
223954630104	WIRING HARNESS ABS FRAME BS6	TATA spare parts
223954630106	WIRING HARNESS ABS FRAME BS6	TATA spare parts
223954700101	BRACKET ASSY GEAR SHIFT ADVISORY MTG	TATA spare parts
224020000001	PEEP GLASS FOR 909-CLEAR-(310X385X4)	TATA spare parts
224029300101	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
224029300104	PIPE ASSY CMC TO CLUTCH BOOSTER BS6-PH2	TATA spare parts
224029503301	BRACKET BUNDY TUBE MTG BS6	TATA spare parts
224031000110	FRAME ASSY WITH FITMENT BS6	TATA spare parts
224031000113	FRAME ASSY WITH FITMENT BS6	TATA spare parts
224031200103	CROSS MEMBER ASSY ENGINE MTG FRONT BS6	TATA spare parts
224031200104	CROSS MEMBER ASSY ENGINE	TATA spare parts
224031700102	BRACKET ASSY GEAR BOX MTG RH BS6	TATA spare parts
224031700103	BRACKET ASSY GEAR BOX MTG LH BS6	TATA spare parts
224041110110	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
224041110112	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
224041110116	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
224041110119	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
224041120106	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
224041120107	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
224041120109	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
224041300101	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
224041300102	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
224041300106	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
224041300107	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
224041990106	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
224046703301	BRACKET BS6	TATA spare parts
224046800101	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
224046800102	SUCTION LINE ASSY BS6	TATA spare parts
224046800103	PRESSURE LINE ASSY BS6	TATA spare parts
224047600111	FUEL SUCTION PIPE ASSY TANK TO P/FILTER	TATA spare parts
224047600112	FUEL SUCTION PIPE ASSY-FILTER TO FIP BS6	TATA spare parts
224047600113	FUEL RETURN PIPE ASSY HP PUMP TO T-CONN	TATA spare parts
224047600114	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
224047600115	SUCTION PIPE ASSY FILTER TO PUMP BS6	TATA spare parts

224049200113	BRACKET ASSY BS6	TATA spare parts
224049200117	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
224049200129	SUCTION PIPE BS6	TATA spare parts
224049200130	SUCTION PIPE BS6	TATA spare parts
224049200140	PRESSURE LINE SM TO DM BS6	TATA spare parts
224049200146	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
224049200147	EXHAUST PIPE ASSY SECOND BS6	TATA spare parts
224049200148	BRACKET ASSY EGP MTG BS6	TATA spare parts
224049200152	BRACKET ASSY TAIL PIPE MTG BS6	TATA spare parts
224049200155	PROTECTIVE COVER SM - BS6	TATA spare parts
224049200182	BRACKET ASSY TAIL PIPE MTG BS6 PH2	TATA spare parts
224049203322	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
224049203334	L-BRACKET EXHAUST MTG BS6	TATA spare parts
224049203338	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
224049203365	BRACKET EXHAUST PIPE MTG BS6 PH2	TATA spare parts
224049204205	CLAMP BS6	TATA spare parts
224049204206	CLAMP BS6	TATA spare parts
224049204207	CLAMP BS6-PH2	TATA spare parts
224049205301	GASKET BS6	TATA spare parts
224050090001	SIDE WIN ASSY-SM22-FULL SLD-CLR GLASS-PC	TATA spare parts
224050090002	SIDE WIN ASSY-SM22-FULL SLD-CLR GLASS-PC	TATA spare parts
224050090007	HOOPER TYPE WINDOW	TATA spare parts
224050090009	SIDE WIN ASSY-SM22-FULL SLD-CLR GLASS-PC	TATA spare parts
224050090015	SIDE WIN ASSY-SM22-FULL SLD-CLR GLASS-PC	TATA spare parts
224050090016	SIDE WIN ASSY-SM22-FULL SLD-CLR GLASS-PC	TATA spare parts
224050090017	SIDE WIN ASSY-SM22-FULL SLD-CLR GLASS-PC	TATA spare parts
224050100001	SIDE WIN ASSY-SM22-FULL SLD-CLR GLASS-PC	TATA spare parts
224050100005	SIDE WIN ASSY-SM22-FULL SLD-CLR GLASS-PC	TATA spare parts
224050130001	SIDE WINDOW ASSY (SM22)	TATA spare parts
224050200001	SIDE WINDOW DRV.DOOR	TATA spare parts
224050270001	SIDE WINDOW EMG DOOR	TATA spare parts
224050280001	SIDE WINDOW ASSEMBLY EMG	TATA spare parts
224050710002	SIDE WINDOW ASSY (OWS)	TATA spare parts
224050710005	SIDE WINDOW ASSY (OWS)	TATA spare parts
224050730002	DRIVER DOOR WINDOW ASSY.	TATA spare parts
224050910001	SIDE WINDOW DRIVER DOOR FOR TML 909	TATA spare parts
224050930002	SIDE WINDOW ASSY (OWS) FOR 909	TATA spare parts
224050930003	SIDE WINDOW ASSY (OWS) FOR 909	TATA spare parts
224050930004	SIDE WINDOW ASSY (OWS) FOR 909	TATA spare parts
224050930005	SIDE WINDOW ASSY (OWS) FOR 909	TATA spare parts
224050930006	SIDE WINDOW ASSY (OWS) FOR 909	TATA spare parts
224050930007	SIDE WINDOW ASSY (OWS) BS6	TATA spare parts
224050930008	SIDE WINDOW ASSY (OWS) BS6	TATA spare parts
224050930009	SIDE WINDOW ASSY BS6	TATA spare parts
224050930010	SIDE WINDOW ASSY BS6	TATA spare parts
224050930011	SIDE WINDOW ASSY (OWS) FOR 909 BS6	TATA spare parts
224050930015	SIDE WINDOW ASSY (OWS) FOR 909 BS6	TATA spare parts

224050940002	SIDE WINDOW ASSY (OWS) FOR 909	TATA spare parts
224050950001	EMERGENCY DOOR WINDOW ASSEMBLY	TATA spare parts
224051030003	SIDE WINDOW DRIVER DOOR (OWS) BS6	TATA spare parts
224051040001	SIDE WINDOW ASSY (OWS) BS6	TATA spare parts
224051050001	SIDE WINDOW ASSY EMG (OWS) BS6	TATA spare parts
224051160003	SIDE WINDOW ASSY BS6	TATA spare parts
224051160004	SIDE WINDOW ASSY BS6	TATA spare parts
224051160007	SIDE WINDOW ASSY BS6	TATA spare parts
224051160008	SIDE WINDOW ASSY BS6	TATA spare parts
224051160009	SIDE WINDOW ASSY BS6	TATA spare parts
224051170001	OSIDE WINDOW ASSY BS6	TATA spare parts
224051180001	SIDE WINDOW DRIVER DOOR BS6	TATA spare parts
224051200001	SIDE WINDOW ASSY EMG BS6	TATA spare parts
224054600113	PIGTAIL ASSY EMS WIRING HARNESS BS6	TATA spare parts
224054610101	WIRING HARNESS ASSY MAIN BS6	TATA spare parts
224054620101	BRACKET BS6-PH2	TATA spare parts
224054620102	WIRING HARNESS ENGINE BS6	TATA spare parts
224054630101	WIRING HARNESS ABS FRAME BS6	TATA spare parts
224054630104	WIRING HARNESS SCR UNIT BS6	TATA spare parts
224054630105	WIRING HARNESS EGP PIGTAIL BS6	TATA spare parts
224054630106	WIRING HARNESS TAIL BS6	TATA spare parts
224054630114	WIRING HARNESS TAIL BS6	TATA spare parts
224054900101	BRACKET ASSY ECU MTG BS6	TATA spare parts
224054900102	BRACKET ASSY DOSING CONTROLLER UNIT MTG	TATA spare parts
224054900103	STIFFENER ECU MTG BRACKET BS6	TATA spare parts
224054903303	COVER DOSING CONTROLLER UNIT BS6	TATA spare parts
22410348000RCK	ASSY. CAB KIT W/FITMENTS SIGNA 2821.T 5L	TATA spare parts
22411248000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 2821 T B	TATA spare parts
224129300101	BUNDY TUBE ASSY CMC TO LONG MEMBER BS6	TATA spare parts
224129300102	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
224131000102	FRAME ASSY WITH FITMENT	TATA spare parts
224131000105	FRAME ASSY WITH FITMENT	TATA spare parts
224131000110	FRAME ASSY WITH FITMENT BS6	TATA spare parts
224131000115	FRAME ASSY WITH FITMENT BS6	TATA spare parts
224131000121	FRAME ASSY WITH FITMENT BS6	TATA spare parts
224131000124	FRAME ASSY WITH FITMENT BS6	TATA spare parts
224131000126	FRAME ASSY WITH FITMENT BS6	TATA spare parts
224131000133	FRAME ASSY WITH FITMENT BS6	TATA spare parts
224131107102	REINFORCEMENT RH	TATA spare parts
224131107103	REINFORCEMENT LH	TATA spare parts
224131107105	REINFORCEMENT BOTTOM	TATA spare parts
224131107113	REINFORCEMENT RH BS6	TATA spare parts
224131107114	REINFORCEMENT LH BS6	TATA spare parts
224131200103	CROSS MEMBER ASSY BS6	TATA spare parts
224131307101	REINFORCEMENT BUMPER CROSS MEMBER RH BS6	TATA spare parts
224131307102	REINFORCEMENT BUMPER CROSS MEMBER LH BS6	TATA spare parts
224131700102	BRACKETASSY RAIDATORMTG RH BS6	TATA spare parts



224131700103	BRACKETASSY RAIDATOR MTG LH BS6	TATA spare parts
224133000102	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
224133105101	FRONT AXLE BEAM BS6-PH2	TATA spare parts
224133405501	FRONT HUB BS6	TATA spare parts
224141110103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
224141110104	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
224141110105	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
224141120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
224141303301	BRACKET CENTER BRG MTG BS6	TATA spare parts
224141990108	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
224141990109	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
224141990113	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
224143900102	PIPE BUNCH ASSY	TATA spare parts
224143900103	PIPE ASSY INT JOINT TO INT JOINT	TATA spare parts
224143900133	PIPE BUNCH ASSY	TATA spare parts
224143900164	METAL PIPE ASSY	TATA spare parts
224143900175	PIPE BUNCH ASSY BS6	TATA spare parts
224143900191	PIPE BUNCH ASSY BS6	TATA spare parts
224143900194	METAL PIPE ASSY BS6	TATA spare parts
224143903301	Z-BRACKET BS6	TATA spare parts
224143910102	PIPE BUNCH ASSY BS6	TATA spare parts
224143910105	PIPE BUNCH ASSY BS6	TATA spare parts
224143910107	PIPE BUNCH ASSY BS6	TATA spare parts
224146305101	PITMAN ARM BS6	TATA spare parts
224146800101	SUCTION LINE ASSY BS6	TATA spare parts
224146800102	PRESSURE LINE ASSY BS6	TATA spare parts
224146800104	HIGH PRESSURE LINE ASSY STG GB END BS6	TATA spare parts
224146800105	HIGH PRESSURE LINE ASSY PUMP END BS6	TATA spare parts
224149200101	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
224149200102	BRACKET ASSY CATCON MTG	TATA spare parts
224149200103	BRACKET ASSY SIENCER MTG	TATA spare parts
224149200104	BRACKET ASSY TAIL PIPE MTG	TATA spare parts
22415168000RCK	ASSY COWL KIT W/FITMENTS LPT 2821 BS6	TATA spare parts
224154600101	WIRING HARNESS TAIL	TATA spare parts
224154600102	WIRING HARNESS TAIL BS6	TATA spare parts
224154600103	WIRING HARNESS ABS FRAME	TATA spare parts
224154600104	PIGTAIL VEHICLE TRACKING SYSTEM BS6	TATA spare parts
224154610107	WIRING HARNESS MAIN BS6	TATA spare parts
224154610108	WIRING HARNESS MAIN BS6	TATA spare parts
224154630101	WIRING HARNESS TAIL BS6	TATA spare parts
224154630102	WIRING HARNESS ABS FRAME BS6	TATA spare parts
224270000111	LOAD BODY ASSY BS6	TATA spare parts
224270000112	LOAD BODY ASSY	TATA spare parts
224270000113	LOAD BODY ASSY	TATA spare parts
224270000122	MUDGUARD ASSY BS6	TATA spare parts
224270000123	MUDGUARD ASSY BS6	TATA spare parts
224270010104	LOAD BODY ASSY BS6	TATA spare parts

224270010202	LOAD BODY ASSY BS6	TATA spare parts
224270100138	BRACKET STAY ROD MTG BS6	TATA spare parts
224270108214	MUDGUARD BS6	TATA spare parts
224270108215	MUDGUARD CENTER-LH BS6	TATA spare parts
224270108216	MUDGUARD CENTER-RH BS6	TATA spare parts
224270108231	CLOSURE PLATE LONG RUNNER 3MM THIK BS6	TATA spare parts
224270108236	MUDGUARD CENTER-LH BS6	TATA spare parts
224270108237	MUDGUARD CENTER-RH BS6	TATA spare parts
224270108239	MUDGUARD LH BS6	TATA spare parts
224270108240	MUDGUARD RH BS6	TATA spare parts
224270108241	MUDGUARD CENTER-LH BS6	TATA spare parts
224270108242	MUDGUARD CENTER-RH BS6	TATA spare parts
224270906301	BALATA PACKING LONG RUNNER BS6	TATA spare parts
224610030001	FRT W/S JUPITOR METAL MINI/MIDI 2-PC RH	TATA spare parts
224610040001	FRT W/S JUPITOR METAL MINI/MIDI 2-PC LH	TATA spare parts
224610080001	FRONT WINDSHIELD GLASS BS6	TATA spare parts
224610090001	FRONT WINDSHIELD BS6	TATA spare parts
224620000001	FRT WINDSHIELD 912/712/708 TMML TYPE SIN	TATA spare parts
224620010001	FRONT WINDSHIELD MOULD	TATA spare parts
224620070001	FRT W/S 912/712/708 TMML TYPE SINGLE PC	TATA spare parts
224620080001	FRONT WINDSHIELD	TATA spare parts
224620090001	FRONT WINDSHIELD MOULD	TATA spare parts
224620120001	FRONT WINDSHIELD BS6	TATA spare parts
224620130001	FRONT WINDSHIELD MOULD BS6	TATA spare parts
224620160001	FRONT WINDSHIELD MOULD BS6	TATA spare parts
224620170001	FRONT W/S MOULD 2340 WIDTH BS6	TATA spare parts
2247-A-105	ROLLER- BRAKE SHOE	TATA spare parts
224710030001	REAR WINSHIELD	TATA spare parts
224710050001	REAR WINDSHIELD GLASS BS6	TATA spare parts
224710070001	REAR WINDSHIELD BS6	TATA spare parts
224720030001	REAR WINDSHIELD LP 912 AIS 052 TP II SDX	TATA spare parts
224720040001	REAR WINDSHIELD MOULD	TATA spare parts
224720050001	REAR W/S GLASS - JNNURM MIDI	TATA spare parts
224720270001	REAR W/S MOULD 2200 WIDTH BS6	TATA spare parts
224720280001	REAR W/S MOULD 2340 WIDTH BS6	TATA spare parts
2254500040	GLOW COIL	TATA spare parts
225669050001	SD WINDOW ASSY(OPTYPE-2PC-GRN-DRV)	TATA spare parts
225670000003	WINDOW ASSY (DRIVER DOOR )	TATA spare parts
225673000002	SD WINDOW ASSY(OPTYP-2PC-GRN)	TATA spare parts
225673050001	SD WINDOW ASSY(OPTYPE-2PC-GRN)	TATA spare parts
225673050008	DRIVER DOOR WINDOW ASSY	TATA spare parts
225676050001	SIDE WINDOW ASSEMBLY (DRV. DOOR)	TATA spare parts
225677000001	DRIVER DOOR WINDOW	TATA spare parts
225677010001	DRIVER DOOR WINDOW	TATA spare parts
225718130145	LUBE FILTER	TATA spare parts
225720000001	REVERSE HORN (12V)	TATA spare parts
2281000001	NUT	TATA spare parts

23015806	O-RING 23.5 MM ID	TATA spare parts
23015927	O-RING 37.5 MM ID	TATA spare parts
23017303	O-RING 14.0 MM ID	TATA spare parts
23019664	O-RING 16.4 MM ID	TATA spare parts
23040579	O-RING 7.6 MM ID	TATA spare parts
23042434	SEALRING KIT EXTERNAL	TATA spare parts
23045586	SPRING ASSEMBLY C1	TATA spare parts
23045611	SEALRING C2 PISTON 116.3 MM ID	TATA spare parts
23045612	SEALRING C1 PISTON 101.1 MM ID	TATA spare parts
23045613	SEALRING EXTERNAL	TATA spare parts
23045614	SEALRING C1 PISTON 178.8 MM ID	TATA spare parts
23045615	SEALRING PISTON 202.1 MM ID	TATA spare parts
23045618	RING RETAINING EXTERNAL	TATA spare parts
23045654	SEALRING C5 PISTON 258.7 MM ID	TATA spare parts
23045816	BEARING ASSEMBLY ROLLER	TATA spare parts
23045918	BEARING ASSEMBLY THRUST PUMP	TATA spare parts
23046228	BEARING ASSEMBLY THRUST	TATA spare parts
23046274	O-RING 25.1 MM ID	TATA spare parts
23046291	RING RETAINING INTERNAL	TATA spare parts
23046354	PIN DOWEL 10 X 50 MM	TATA spare parts
23046376	SEAL FACE	TATA spare parts
23046437	BEARING ASSEMBLY CONE AND ROLLER	TATA spare parts
23046438	CUP ROLLER BEARING	TATA spare parts
23046868	SEALRING LOCKUP PISTON 279.9 MM ID	TATA spare parts
23047019	O-RING 291.7 MM ID	TATA spare parts
23047102	VENT ASSEMBLY	TATA spare parts
23047185	O-RING 4.4 INCH ID	TATA spare parts
23047489	BOLT M16 X 2 X 30	TATA spare parts
23047834	BEARING ASSEMBLY THRUST	TATA spare parts
23047854	BEARING ASSEMBLY THRUST	TATA spare parts
23048133	PISTON BALANCE ROTATING CLUTCH	TATA spare parts
23048530	PLATE C2 CLUTCH PRESSURE	TATA spare parts
23048628	PLATE C2 CLUTCH FRICTION	TATA spare parts
23048692	PISTON C2	TATA spare parts
23049200	TUBE OIL FILL	TATA spare parts
23049315	VALVE LOCKUP	TATA spare parts
23049316	VALVE LUBE REGULATOR	TATA spare parts
23049320	VALVE EXHAUST BACK	TATA spare parts
23049326	SPRING LOCKUP	TATA spare parts
23049327	SPRING LUBE REGULATOR	TATA spare parts
23049337	STOP LOCKUP	TATA spare parts
23049338	STOP LUBE REGULATOR	TATA spare parts
23049342	STOP EXHAUST BACK	TATA spare parts
23049345	PIN RETENTION 5 OD X 43 MM	TATA spare parts
23049376	GEAR SET ASSEMBLY CYCLOIDAL	TATA spare parts
23049377	O-RING 368.3 MM ID	TATA spare parts
23049391	SPRING EXHAUST BACK	TATA spare parts

23100015015	FLAME TORCH WITH ACC	TATA spare parts
23570	CAMSHAFT SHIM WASHER	TATA spare parts
236335706102	WASHER - LOCKNUT BS6	TATA spare parts
236C20	SNAP RING	TATA spare parts
236C8	C RING	TATA spare parts
23CX005C01	ACTUATOR ARM SPACER	TATA spare parts
241020610001	HATRACK ARM COMPL	TATA spare parts
2414610010	MAIN SPRING	TATA spare parts
2424650008	GOVERNOR SPRING	TATA spare parts
2430100011	WASHER 1.00 MM	TATA spare parts
2430100015	WASHER 1.15 MM	TATA spare parts
2430100018	WASHER 1.30 MM	TATA spare parts
2430100020	WASHER 1.35 MM	TATA spare parts
2430100021	WASHER 1.40 MM	TATA spare parts
2430100023	WASHER 1.45 MM	TATA spare parts
2430100024	WASHER 1.50 MM	TATA spare parts
2430100025	WASHER 1.55 MM	TATA spare parts
2430100028	WASHER 1.65 MM	TATA spare parts
2430100029	WASHER 1.70 MM	TATA spare parts
2430100030	WASHER 1.75 MM	TATA spare parts
2430100033	WASHER 1.85 MM	TATA spare parts
2430100035	WASHER 1.95MM	TATA spare parts
2430100531	SHIM 0.92MM	TATA spare parts
2430100535	SHIM 1.00 MM	TATA spare parts
2430100543	SHIM 1.16 MM	TATA spare parts
2430100547	SHIM 1.24MM THICK	TATA spare parts
2430100575	SHIM 1.80 MM	TATA spare parts
2430100583	SHIM 1.96 MM	TATA spare parts
2430136017	INTERMEDIATE DISC	TATA spare parts
2433124011	SPINDLE	TATA spare parts
2433124035	SPINDLE	TATA spare parts
2433300000	LOCK NUT	TATA spare parts
2433317244	NOZZLE CAP NUT	TATA spare parts
2433458102	NOZZLE CAP NUT	TATA spare parts
243418137201	SCREW PLUG	TATA spare parts
243418175303	GASKET	TATA spare parts
2434619017	SPRING	TATA spare parts
2434619048	SPRING INJECTOR	TATA spare parts
2435100043	NOZZLE HOLDER BODY	TATA spare parts
2440105000	PACKING RING	TATA spare parts
2440109005	PACKING RING	TATA spare parts
2440200000	ROLLER	TATA spare parts
2440210009	O RING FOR HOUSING	TATA spare parts
2440362009	REDUCING NIPPLE	TATA spare parts
2443120001	SLIDER	TATA spare parts
2443120022	PRESSURE SPINDLE	TATA spare parts
2443203001	FEED PUMP VALVE	TATA spare parts

2443355000	REDUCING NIPPLE	TATA spare parts
2443385025	CONNECTION	TATA spare parts
2443462009	SCREW PLUG	TATA spare parts
2443462014	SCREW PLUG	TATA spare parts
2444601000	SNAP RING	TATA spare parts
2444615006	HELICAL SPRING	TATA spare parts
2444617010	HELICAL SPRING	TATA spare parts
2447222099	HAND PRIMER	TATA spare parts
2449998313	SPINDLE BLUE	TATA spare parts
2449998314	SPINDLE WHITE	TATA spare parts
2449998709	PUMP PLUNGER BLUE	TATA spare parts
2449998711	PUMP PLUNGER YELLOW	TATA spare parts
2449998713	PUMP PLUNGER WHITE	TATA spare parts
245020030001	MIRROR ARM	TATA spare parts
245020040001	CLASS VI MIRROR ARM (FRONT PROXIMITY)	TATA spare parts
245020060001	CLASS VI MIRROR ARM (FRONT PROXIMITY) BS	TATA spare parts
2450556000	INSPECTION BOWL	TATA spare parts
2450990003	SCREW	TATA spare parts
245110060001	GUARD RAIL BRACKET	TATA spare parts
245110070001	GUARD RAIL BRACKET	TATA spare parts
2453345000	TIGHTENING NUT	TATA spare parts
2453405001	STUD SCREW	TATA spare parts
2454642001	HELICAL SPRING	TATA spare parts
245920040001	FRP WHEEL HUB COVER-FRONT	TATA spare parts
245920050001	FRP WHEEL HUB COVER-REAR	TATA spare parts
2459999000	CLIP	TATA spare parts
246010100001	FRONT BUMPER ASSEMBLY BS6	TATA spare parts
246010140001	FRONT BUMPER ASSY BS6	TATA spare parts
246020070001	FRP FRONT BUMPER	TATA spare parts
246020110001	FRONT BUMPER CENTER PIECE	TATA spare parts
246020120001	FRONT BUMPER PIECE LH	TATA spare parts
246020130001	FRONT BUMPER PIECE RH	TATA spare parts
246020140001	FRT BUMP. LH - W/O F/L C/OP - SUPREME	TATA spare parts
246020150001	FRT BUMP. RH - W/O F/L C/OP - SUPREME	TATA spare parts
246020210001	FRP FRONT BUMPER - 4 TONNER	TATA spare parts
246020230001	FRONT BUMPER ASSEMBLY	TATA spare parts
246020240001	FRONT BUMPER ASSEMBLY BS6	TATA spare parts
246110110001	REAR FRP BUMPER	TATA spare parts
246120120001	REAR BUMPER CENTER PIECE	TATA spare parts
246120130001	REAR BUMPER. LH - W/O F/L C/OP - SUPREME	TATA spare parts
246120140001	REAR BUMPER. RH - W/O F/L C/OP - SUPREME	TATA spare parts
248110800001	SEAT ASSEMBLY - HBK 2S FLR MOUNTED	TATA spare parts
248110810001	SEAT ASSEMBLY - HBK 2S FLR MOUNTED	TATA spare parts
248110830001	SEAT ASSEMBLY - HBK 2S FLR MOUNTED	TATA spare parts
248110840001	SEAT ASSEMBLY - HBK 2S FLR MOUNTED	TATA spare parts
248110850002	SEAT ASSEMBLY - HBK 5S FLR MOUNTED	TATA spare parts
248110860001	SEAT ASSEMBLY - HBK 2S FLR MOUNTED	TATA spare parts

248110870001	SEAT ASSEMBLY - HBK 2S FLR MOUNTED	TATA spare parts
248110880001	SEAT ASSEMBLY - HBK 2S FLR MOUNTED	TATA spare parts
248110890001	SEAT ASSEMBLY - HBK 2S FLR MOUNTED	TATA spare parts
248110900001	SEAT ASSEMBLY - HBK 1S FLR MOUNTED	TATA spare parts
248111100001	SEAT ASSY (2S) + ARMREST	TATA spare parts
248111100003	SEAT ASSY (2S)	TATA spare parts
248111150001	SEAT ASSY (2S)	TATA spare parts
248111150004	SEAT ASSY 2S	TATA spare parts
248111200001	1 SEATER¿ SEAT	TATA spare parts
248111240001	SEAT ASSY (5S)	TATA spare parts
248112270001	SEAT ASSY(2 STR+SEAT BELT)	TATA spare parts
248112270002	SEAT ASSY(2 STR-ARMREST+SEAT BELT)	TATA spare parts
248112280001	SEAT ASSY (2 STR+SEAT BELT)	TATA spare parts
248112280002	SEAT ASSY (2 STR- ARMREST+SEAT BELT)	TATA spare parts
248112430001	MIDDLE SEAT ASSY 1S	TATA spare parts
248112440001	CABIN SEAT ASSY	TATA spare parts
250051320102	CONTROL VALVE	TATA spare parts
250051323001	BALL	TATA spare parts
250051326502	NUT	TATA spare parts
250051327206	PLUG	TATA spare parts
250051327707	O RING	TATA spare parts
250051327708	O RING	TATA spare parts
250051327710	SEAL	TATA spare parts
250051327788	O RING	TATA spare parts
250051328003	SCREW	TATA spare parts
250051328004	BOLT	TATA spare parts
250051328704	SPRING	TATA spare parts
250051329201	WASHER	TATA spare parts
250051329907	RETAINER TIPPER	TATA spare parts
250051329908	QUAD RING	TATA spare parts
250051329909	BACK UP RING	TATA spare parts
250052210104	CARTRIDGE KIT	TATA spare parts
250052213709	BODY	TATA spare parts
250052213710	RING	TATA spare parts
250052216703	PIN VICKERS PUMP	TATA spare parts
250052217705	O RING	TATA spare parts
250052218003	SCREW	TATA spare parts
250052218703	SPRING	TATA spare parts
250052220104	VANE KIT	TATA spare parts
250052224102	SNAP RING	TATA spare parts
250052225903	KEY	TATA spare parts
250200560001	ROOF HARNESS COMPLETE FOR NIGERIA PRISON	TATA spare parts
250200590001	ROOF HARNESS COMPL LP912/909	TATA spare parts
250200700001	ROOF HARNESS COMPLETE	TATA spare parts
250200740001	ROOF HARNESS COMPLETE - 9T ZEAL	TATA spare parts
250200890001	ROOF HARNESS LP 913 CONGO	TATA spare parts
250201019	GLOW PLUG QUICK START	TATA spare parts

250210850001	METER PANEL HARNESS LP 913	TATA spare parts
250211160001	MET . PAN. HARNESS-ILCV RDE BS6-PH2	TATA spare parts
2502201068	ASSY BR LEVER	TATA spare parts
2502201201	PIPE AIR 18 X 503	TATA spare parts
250221640001	WIRING HARNESS COMPLETE	TATA spare parts
250221680001	ROOF HARNESS COMPLETE	TATA spare parts
2502801104	CABLE ASSY +VE	TATA spare parts
2502801123	ELECTRIC CABLE	TATA spare parts
2502801134	ELECTRIC CABLE	TATA spare parts
2502801144	ELECTRIC CABLE	TATA spare parts
250330103701	GEAR CASE	TATA spare parts
250330137902	DRIVE SHAFT	TATA spare parts
250330138601	SPACER DRIVE SHAFT	TATA spare parts
250330145403	DOUBLE GEAR C/S 4TH SPEED	TATA spare parts
250330150110	GEAR CASE COVER RR RHD	TATA spare parts
250330150111	GEAR CASE COVER RR LHD	TATA spare parts
250330153101	CYL. ROLLER BRG.	TATA spare parts
250330153703	GEAR CASE COVER REAR RHD	TATA spare parts
250330153704	GEAR CASE COVER REAR LHD	TATA spare parts
250330158603	SPACER	TATA spare parts
250330177901	REV.IDLER SHAFT	TATA spare parts
250526000101	KIT-GASKET GEAR BOX G40 5/7.51 BS1/2/3/4	TATA spare parts
250526000102	KIT GASKETS GBS40	TATA spare parts
250526000401	GASKET&SEAL KIT-FUL REMOT	TATA spare parts
250526010001	GEARBOX GBS40 8.98 SFCRHD	TATA spare parts
250526010005	GEARBOX GBS40 8.98 LP RHD	TATA spare parts
250526010009	GEAR BOX GBS40 LP342 RHD	TATA spare parts
250526010017	GEARBOX GBS40 8.98 SK RHD	TATA spare parts
250526010019	GEARBOX GBS40 SK RHD RIS	TATA spare parts
250526010027	GEARBOX GBS40 SK W/PTOAPP	TATA spare parts
250526010049	GBS40 GEAR BOX	TATA spare parts
250526010088	GEARBOX GBS40 W/O LEV FR	TATA spare parts
250526010093	ASSY.GBS40 GEARBOX-8.98R	TATA spare parts
250526010104	GEARBOX 40 SFC8.02 SD WITH8 H PTO	TATA spare parts
250526010105	GEARBOX GBS40 8.02 8HCF	TATA spare parts
250526010140	ASSY GBS40 GR.BOX	TATA spare parts
250526010151	ASSY GEAR BOX GBS-40 8.98/8 HCF SK	TATA spare parts
250526010159	GEARBOX GBS40 8.02 RIS 8H	TATA spare parts
250526010163	ASSY.GEAR BOX COMP.WITH SHIFT LEVER-RHD	TATA spare parts
250526010177	G/BOX GBS 40 LP	TATA spare parts
250526010186	GEARBOX GBS40 PTO W/O LEV	TATA spare parts
250526010187	ASSY GBS 40-5/8.98GB 8BCF SFC TYPE GSL R	TATA spare parts
250526010188	GBS 40/8.98 R/SK	TATA spare parts
250526010194	GEAR BOX GBS40 8.02 6HCF	TATA spare parts
250526010207	ASSY GBS40-5/7.51 8BCF FR PTO PROV	TATA spare parts
250526010209	ASSY GB G40-5/6.34 W/8BCF LPO 916 RHD	TATA spare parts
250526010210	ASSY G40-5/6.34 W/8BCF LPO 916 LHD	TATA spare parts

250526020121	GEARBOX ASSY GBS40	TATA spare parts
250526020122	GBS40/SF/RH/CL30	TATA spare parts
250526020124	GEARBOX GBS40 7.51 6HCF	TATA spare parts
250526020142	GEARBOX 40 SFC8.98 RIS 8H	TATA spare parts
250526020173	GEARBOX 40 7.51SFCRHRIS8C	TATA spare parts
250526020194	GEARBOX GBS40 APPMK2 7.51	TATA spare parts
250526030107	ASSY GEAR BOX GBS40 7.5 8BCF	TATA spare parts
250526030114	GEARBOX G40 PTO PNEU SHFT	TATA spare parts
250526030144	ASSY GBS-40 FRC 8H	TATA spare parts
250526030145	ASSY GBS40 8BCF RIS FR LHD	TATA spare parts
250526030151	GEAR BOX GBS40 7.51 RATIO	TATA spare parts
250526030152	ASSY GBS40/7.51 8BCF W/PTO	TATA spare parts
250526030171	GEARBOX GBS40 8.98 8HCF	TATA spare parts
250526030173	GEARBOX GBS40 8.98	TATA spare parts
250526030174	ASSY GBS40-5/8.98 GR.BOX 6HCF COMP	TATA spare parts
250526030183	ASSY. GEAR BOX GBS40 CF/FULL REMOTE BS1	TATA spare parts
250526030186	ASSY.GBS40 7.51A GEARBOX(L)W/PTO COMP	TATA spare parts
250526030188	ASSY GBS40-751 GEAR BOX COMPL.	TATA spare parts
250526030190	GEARBOX GBS40 8.02	TATA spare parts
250526030196	GEARBOX GBS40 8.02 RIS 8H	TATA spare parts
250526040107	GEAR BOX GBS40 1312TC RHD	TATA spare parts
250526040115	GBS-40-5/7.51A G.BOX WITH APP MK II 6BT	TATA spare parts
250526040124	ASSY GBS40-5/6.34 6BCF.FULL REMOTE (LHD	TATA spare parts
250526040125	ASSY G40-5/7.51 6BCF SFC APP MKII 6BT RH	TATA spare parts
250526040127	ASSY G40-5/7.51 8BCF SFC 6BT CUM ENG RHD	TATA spare parts
250526040129	ASSY GBS40-5/7.51 GEAR BOX RHD	TATA spare parts
250526040138	ASSY. GEAR BOX GBS40 7.5 8BCF BS1/2/3	TATA spare parts
250526040142	ASSY. GBS-40 GEAR BOX LPTA 713TC EURO2	TATA spare parts
250526040143	ASSY GBS40-5/7.51 8BCF FASTER 3&4 RATIO	TATA spare parts
250526040145	ASSY GBS40-5/7.51(F)8BCF, SE1613TC EII	TATA spare parts
250526040152	ASSY GBS40-5/6.89 8BCF LPT1613	TATA spare parts
250526040155	ASSY GBS 40 5/7 51 8BCF LPT1613	TATA spare parts
250526040156	ASSY GBS40-5/7.51 8BCF SFC FOR SE1613	TATA spare parts
250526040157	ASSY. GBS 40 GEAR BOX WITH 6 BOLT COUPLI	TATA spare parts
250526040157AE	ASSY GEAR BOX 713	TATA spare parts
250526040158	ASSY GBS40-5/7.51 GEARBOX(FASTER RATIO)	TATA spare parts
250526040159	ASSY GBS40-5/7.51GEARBOX W/6BCF FASTER	TATA spare parts
250526040168	ASSY G40-5/7.51 PNEU.PTO FAST.3/4TH 6BCF	TATA spare parts
250526040170	ASSY GBS 40-5/7.51 F3/4 FR W/8BOLT COU	TATA spare parts
250526040174	ASSY.GBS40-5/7.51A 8BCF W/697TC FR(CR)	TATA spare parts
250526040177	ASSY GBS 40 GEAR BOX WITH OIL	TATA spare parts
250526040178	ASSY GBS40 GEARBOX WITH OIL	TATA spare parts
250526040180	ASSY GBS40-5/6.34 W/6BCF PTO PRO.FR.COM	TATA spare parts
250526040181	ASSY GBS40-5/6.34 G.BOX W/6BCF W/FR COML	TATA spare parts
250526040183	ASSY GBS40-5/7.51A W/6BCF SFC PTO PROV.	TATA spare parts
250526040184	ASSY GBS40-5/7.51(F)W/8BCF FR LP1512-497	TATA spare parts
250526040185	GBS40-5/7.51A W/8BCF SE(BIG DOM)PTO PRO.	TATA spare parts



250526040186	GBS40-5/7.51A W/6BCF & APP SK(BIG	TATA spare parts
250526040187	ASSY GBS40-5/7.51(F3/4) W/6BCF W/PTO PRO	TATA spare parts
250526040189	GBS40-5/6.34 W/6BCF W/PTO W/FR (497TCIC)	TATA spare parts
250526040190	GBS40-5/7.51(FASTER 3/4)W/8BCF W/PTO(49	TATA spare parts
250526040192	GBS40-5/6.34 W/6BCF SFC W/O PTO 497BS-3	TATA spare parts
250526040194	GBS40-5/7.51(FASTER) W/8BCF W/O PTO	TATA spare parts
250526050101	GEAR BOX GBS40-5/6.34 6BCF SFC PTO PRO 4	TATA spare parts
250526050103	ASSY GEAR BOX GBS40-5/7.51A 6 BOLT COUP.	TATA spare parts
250526050105	ASSY GBS40-5/8.02 W/6BCF FR 497(LPK909)	TATA spare parts
250526050106	ASSY GBS40-5/8.02 GEARBOX 8BCF FR 497	TATA spare parts
250526050107	GBS40-5/8.02 W/8BCF W/PTO PROV.FR 497ENG	TATA spare parts
250526050109	ASSY GBS40-5/7.51A W/6BCF FR PTO PRO 697	TATA spare parts
250526050110	GBS40-5/8.02 W/8BF FR 497ENGINE 330DIA	TATA spare parts
250526050111YA	YELLOW AGGR FOR ASSY GBS40-5/7.51	TATA spare parts
250526050113	ASSY GEAR BOX COMP.GBS40-5/8.02SFC8BCFW/	TATA spare parts
250526050114	ASSY GBS40-5/8.02 SFC 8BCF W/O PTO PROV	TATA spare parts
250526050115	ASSY GBS40-5/8.02 6BCF FR 497 W/O PTO	TATA spare parts
250526050118	GEAR BOX GBS40-5/6.34 W/6BCF APP MK-II F	TATA spare parts
250526050121	ASSY GBS40-5/7.51A 8BCF W/O PTO FR BOOST	TATA spare parts
250526050124	GBS40-5/8.02 W/8BCF W/O PTO (697)FR.COMP	TATA spare parts
250526050127	ASSY. GEAR BOX GBS40 5/7.51 W/O PTO E1	TATA spare parts
250526050133	ASSY GBS40-5/8.02 W/6BCF W/PTO PROV FR 4	TATA spare parts
250526050136	"ASSY. GBS40-5/8.98,FR W/6BFC 497E"	TATA spare parts
250526050137	GEAR BOX GBS40-5/8.02 SFC 6BCF W/PTO PRO	TATA spare parts
250526050138	ASSY GBS40-5/8.02 SFC 6BCF W/O PTO PROV	TATA spare parts
250526050140	ASSY. GBS40-5/8.02 FR W/8BFC W/O PTO PRO	TATA spare parts
250526050141	ASSY GBS40-5/8.02 W/8BCF W/O PTO (3RD F)	TATA spare parts
250526050142	ASSY GEAR BOX COMP. GBS40-5/8.02(F) W/8B	TATA spare parts
250526050147	GEAR BOX GBS40-5/6.34W/6BCFW/PTO	TATA spare parts
250526050154	GEAR BOX GBS40-5/7.51(F) FR W/8BCF W/O P	TATA spare parts
250526050159	GEAR BOX GBS40-5/8.02 W/8BCF FR	TATA spare parts
250526050161	ASSY GEAR BOX GBS40-5/8.02 FR 497ENG 330	TATA spare parts
250526050162	GBS40-5/8.02F 8BCF 497ENG 330D W/O PTO	TATA spare parts
250526050163	GEAR BOX ASSY GBS40-5/7.51F 8BCF W/O PTO	TATA spare parts
250526050164	GEAR BOX GBS40-5/8.02F,8BCF,PTO PROV,49	TATA spare parts
250526050166	GBS40-5/7.51A W/6BCF FR APP MK-II 697 E	TATA spare parts
250526050167	ASSY GBS40 8.02F SER C/F W/PTO 497E	TATA spare parts
250526050177	GEAR BOX ASSY WITH PTO	TATA spare parts
250526050178	GEAR BOX ASSY	TATA spare parts
250526050179	GEAR BOX ASSY	TATA spare parts
250526050184	GEAR BOX ASSY	TATA spare parts
250526050188	GEAR BOX ASSY	TATA spare parts
250526050191	GEAR BOX ASSY BS6	TATA spare parts
250526050192	GEAR BOX ASSY	TATA spare parts
250526050194	GEAR BOX ASSY BS6	TATA spare parts
250526050195	GEAR BOX ASSY WITH PTO BS6	TATA spare parts
250526050196	GEAR BOX ASSY BS6	TATA spare parts

250526050197	GEAR BOX ASSY BS6	TATA spare parts
250526050198	GEAR BOX ASSY BS6	TATA spare parts
250526050199	GEAR BOX ASSY BS6	TATA spare parts
250526050202	GEAR BOX ASSY BS6	TATA spare parts
250526050210	GEAR BOX ASSY BS6	TATA spare parts
250526050211	GEAR BOX ASSY BS6	TATA spare parts
250526050213	GEAR BOX ASSY BS6	TATA spare parts
250526050215	GEAR BOX ASSY BS6	TATA spare parts
250526050216	GEAR BOX ASSY	TATA spare parts
250526050219	GEAR BOX ASSY BS6	TATA spare parts
250526050220	GEAR BOX ASSY BS6	TATA spare parts
250526050221	GEAR BOX ASSY BS6	TATA spare parts
250526050222	GEAR BOX ASSY BS6	TATA spare parts
250526050225	GEAR BOX ASSY BS6-PH2	TATA spare parts
250526103701	GEAR BOX HOUSING	TATA spare parts
250526103702	GEAR BOX HOUSING	TATA spare parts
250526103703	GEAR BOX HOUSING	TATA spare parts
250526103707	GEAR BOX HSG CR50590/02	TATA spare parts
250526103709	GEAR BOX HOUSING	TATA spare parts
250526103713	GEAR BOX HOUSING	TATA spare parts
250526103720	GEAR BOX HOUSING	TATA spare parts
250526103722	GEAR BOX HOUSING 6.34 RATIO	TATA spare parts
250526103723	GEAR BOX HOUSING BS1/2/3/4	TATA spare parts
250526103724	GEAR BOX HOUSING	TATA spare parts
250526103728	GEAR BOX HOUSING(LPT613BS-II LHD )	TATA spare parts
250526103729	GEARBOXHOUSING BS6	TATA spare parts
250526159901	ADAPTOR BREATHER	TATA spare parts
250526200107	RET SPRING W/SPH WASHER	TATA spare parts
250526200109	ASSY 1ST SPEED GEAR	TATA spare parts
250526200109DF	GEAR FIRST SPEED 38T - GB40	TATA spare parts
250526200111	4TH SPEED GEAR - 20 T GBS40 HELICAL	TATA spare parts
250526200118	ASSY. HELICAL GEAR (3RD SPEED) BS1/2/3	TATA spare parts
250526200118DF	GEAR THIRD SPEED 26T HELICAL - GB40	TATA spare parts
250526200131	ASSY GR.CASE COVER R	TATA spare parts
250526200132	ASSY GEAR CASE COVER REAR L.H.	TATA spare parts
250526200135	ASSY. HELICAL GEAR 4TH SPEED BS1/2/3	TATA spare parts
250526200135DF	GEAR FOURTH SPEED 20T HELICAL - GB40	TATA spare parts
250526200150	DOUBLE ROW NEEDLE CAGE	TATA spare parts
250526200157	ASSY GEAR-SPEEDOMETER DRIVE	TATA spare parts
250526200158	ASSY PINION-SPEEDOMETER DRIVE	TATA spare parts
250526200176	ASSY GEAR-SPEEDOMETER DRIVE	TATA spare parts
250526200184	ASSY. HELICAL GEAR 3RD SPEED BS2/3/4	TATA spare parts
250526200185	ASSY HELICAL GEAR 3RD SPEED COMPLETE BS6	TATA spare parts
250526200192	ASSY. HELICAL GEAR 2ND SPEED BS6	TATA spare parts
250526200194	HELICAL GEAR ASSY 4TH SPEED (EN353/8.02)	TATA spare parts
250526200204	MAIN SHAFT ASSY BS6	TATA spare parts
250526200205	MAIN SHAFT ASSY BS6	TATA spare parts

250526200208	MAIN SHAFT ASSY BS6	TATA spare parts
250526203001	CYLINDRICAL ROLLER	TATA spare parts
250526203101	BEARING CYL ROLLER	TATA spare parts
250526203102	BEARING D/ROW NEEDLE CAGE	TATA spare parts
250526203103	BEARING D/ROW NEEDLE CAGE	TATA spare parts
250526203105	BEARING CYL ROLLER	TATA spare parts
250526203106	FOUR POINT BALL BEARING (QJ309) BS1- 4	TATA spare parts
250526203107	BEARING BALL FOUR POINT	TATA spare parts
250526203108	BEARING D/ROW NEEDLE CAGE	TATA spare parts
250526203109	BEARING BALL FOUR POINT	TATA spare parts
250526203110	DOUBLE ROW NEEDLE CAGE	TATA spare parts
250526203111	DOUBLE ROW NEEDLE CAGE	TATA spare parts
250526203112	BEARING BALL FOUR POINT	TATA spare parts
250526203113	BEARING CYL ROLLER	TATA spare parts
250526203114	CYLINDRICAL ROLLER BEARING	TATA spare parts
250526203115	CYLINDRICAL ROLLER BEARING	TATA spare parts
250526203116	DOUBLE ROW NEEDLE CAGE 2ND/3RD SPEED	TATA spare parts
250526203117	BEARING D/ROW NEEDLE CAGE	TATA spare parts
250526203118	BEARING D/ROW NEEDLE CAGE	TATA spare parts
250526203119	BEARING BALL FOUR POINT	TATA spare parts
250526203120	DOUBLE ROW NEEDLE CAGE	TATA spare parts
250526203121	DOUBLE ROW NEEDLE CAGE	TATA spare parts
250526203122	CYLINDRICAL ROLLER BEARING	TATA spare parts
250526203123	DOUBLE ROW NEEDLE CAGE BS4	TATA spare parts
250526203123AE	DOUBLE ROW NEEDLE CAGE	TATA spare parts
250526203124	DOUBLE ROW NEEDLE CAGE BS4	TATA spare parts
250526203125	DOUBLE ROW NEEDLE CAGE	TATA spare parts
250526203126	DOUBLE ROW NEEDLE CAGE	TATA spare parts
250526203127	FOUR POINT BALL BEARING	TATA spare parts
250526203128	CYLINDRICAL ROLLER BEARING	TATA spare parts
250526203129	CYL ROLLER BRG NUP 309 EN BS1/2/3/4	TATA spare parts
250526203129AE	CYLINDRICAL ROLLER BEARING 713	TATA spare parts
250526203130	CYL ROLLER BRG	TATA spare parts
250526203135	CYL ROLLER BRG	TATA spare parts
250526203136	CYL.ROLLER BRG.	TATA spare parts
250526203137	CYL.ROLLER BRG.(45X100X25)-M/S ZXY CHINA	TATA spare parts
250526203139	CYL. ROLLER BRG.(NUP309EWCN)(45X100X25)M	TATA spare parts
250526203144	FOUR POINT BALL BEARING BS6	TATA spare parts
250526203404	COLLAR BUSHING 47.2MM BS6	TATA spare parts
250526203405	COLLAR BUSHING (1ST GEAR WITH NEEDLE CAG	TATA spare parts
250526203406	COLLAR BUSHING (1ST GEAR WITH NEEDLE CAG	TATA spare parts
250526203407	COLLAR BUSHING 47.5MM BS6	TATA spare parts
250526203408	COLLAR BUSHING (1ST GEAR WITH NEEDLE CAG	TATA spare parts
250526203409	COLLAR BUSHING (1ST GEAR WITH NEEDLE CAG	TATA spare parts
250526203410	COLLAR BUSHING (1ST GEAR WITH NEEDLE CAG	TATA spare parts
250526203411	COLLAR BUSHING (1ST GEAR WITH NEEDLE CAG	TATA spare parts
250526203702	GEAR CASE COVER REAR(NON PTO)	TATA spare parts

250526203703	GEAR CASE COVER REAR WITH PTO OPENING	TATA spare parts
250526203705	GEAR CASE COVER REAR	TATA spare parts
250526203707	HOUSING REAR COVER BS6	TATA spare parts
250526203708	HOUSING REAR COVER BS6	TATA spare parts
250526203802	SYNCHRO CONE BS1/2/3/4	TATA spare parts
250526203802AE	SYNCHRONISING CONE 713	TATA spare parts
250526203803	SYNCHRO CONE	TATA spare parts
250526203804	SYNCHRO CONE	TATA spare parts
250526204302	SNAP RING 2.68 MM THK	TATA spare parts
250526204303	SNAP RING 2.73 MM THK	TATA spare parts
250526204304	SNAP RING 2.78 MM THK	TATA spare parts
250526204305	SNAP RING 2.83 MM THK	TATA spare parts
250526204306	SNAP RING 2.88 MM THK	TATA spare parts
250526204307	SNAP RING 2.93 MM THK	TATA spare parts
250526205101	END YOKE	TATA spare parts
250526205102	COUPLING FLANGE (120 DIA. SERRATED)	TATA spare parts
250526205408	GEAR 3RD SPEED 7.51R	TATA spare parts
250526205415	HELICAL GEAR 4TH SPEED	TATA spare parts
250526205461	HELICAL GEAR 3RD SPEED BS6	TATA spare parts
250526205466	HELICAL GEAR 2ND SPEED	TATA spare parts
25052620546623	HELICAL GEAR 2ND SPEED	TATA spare parts
25052620546724	HELICAL GEAR 4TH SPEED	TATA spare parts
250526205470	SENSING WHEEL CONTACTLESS SPEEDOMETER BS	TATA spare parts
250526206501	HEX BOLT W/NYLOCK INSERT	TATA spare parts
250526206701	RETAINING PIN	TATA spare parts
250526206703	RETENTION PIN	TATA spare parts
250526207801	OIL SEAL R R GBS 40 /50	TATA spare parts
250526207802	OIL SEAL R R GBS 40 /50	TATA spare parts
250526207803	OIL SEAL R R GBS 40 /50 BS1/2/3/4	TATA spare parts
250526207804	OIL SEAL	TATA spare parts
250526207805	OIL SEAL	TATA spare parts
250526207806	OIL SEAL	TATA spare parts
250526207807	OIL SEAL	TATA spare parts
250526207808	OIL SEAL	TATA spare parts
250526207809	OIL SEAL(REAR)(58X75X11) BS3/4/6	TATA spare parts
250526207811	OIL SEAL (78X58X12)	TATA spare parts
250526207902	SHAFT SPEEDO DRIVE	TATA spare parts
250526207903	MAIN SHAFT -LONGER PILOT BRG BS1/2/3/4	TATA spare parts
250526207903AE	MAIN SFT (LONGER PILOT BRG) -713	TATA spare parts
250526207903DF	MAIN SHAFT - LONGER PILOT BEARING - GB40	TATA spare parts
250526208601	BUTTING RING 2.95 MM	TATA spare parts
250526208602	BUTTING RING 3.05 MM	TATA spare parts
250526208603	BUTTING RING 3.15 MM	TATA spare parts
250526208604	BUTTING RING 3.25 MM	TATA spare parts
250526208605	BUTTING RING 3.35 MM	TATA spare parts
250526208606	BUTTING RING 3.45 MM	TATA spare parts
250526208607	BUTTING RING 3.55 MM	TATA spare parts

250526208608	BUTTING RING 6.95 MM	TATA spare parts
250526208609	BUTTING RING 7.05 MM	TATA spare parts
250526208610	BUTTING RING 7.15 MM	TATA spare parts
250526208611	BUTTING RING 7.25 MM	TATA spare parts
250526208612	BUTTING RING 7.35 MM	TATA spare parts
250526208613	BUTTING RING 7.75 MM	TATA spare parts
250526208614	BUTTING RING 7.85 MM	TATA spare parts
250526208615	BUTTING RING 7.95 MM	TATA spare parts
250526208617	BUTTING RING 2.90 MM	TATA spare parts
250526208618	BUTTING RING 3.00 MM	TATA spare parts
250526208619	BUTTING RING 3.10 MM	TATA spare parts
250526208620	BUTTING RING 3.20 MM	TATA spare parts
250526208621	BUTTING RING 3.30 MM	TATA spare parts
250526208622	BUTTING RING 3.40 MM	TATA spare parts
250526208623	BUTTING RING 3.50 MM	TATA spare parts
250526208624	BUTTING RING 3.60 MM	TATA spare parts
250526208625	SPACER	TATA spare parts
250526208626	SPACER (MAIN SHAFT PILOT BRG.)	TATA spare parts
250526209902	CARRIER 1ST SPEED	TATA spare parts
250526209903	CARRIER 2/5TH SPEED	TATA spare parts
250526209904	SOCKET	TATA spare parts
250526250135	GEAR ASSY DRIVE SHAFT BS6	TATA spare parts
250526253101	BEARING ROLLER CAGE	TATA spare parts
250526253102	BEARING ROLLER CAGE	TATA spare parts
250526253103	BEARING ROLLER CAGE	TATA spare parts
250526253104	BEARING ROLLER CAGE	TATA spare parts
250526253105	BEARING ROLLER CAGE	TATA spare parts
250526253106	BEARING ROLLER CAGE	TATA spare parts
250526253107	BEARING ROLLER CAGE	TATA spare parts
250526253108	BEARING ROLLER CAGE	TATA spare parts
250526253109	PILOT BEARING GBS40 GEARBOX LP	TATA spare parts
250526253110	BEARING ROLLER CAGE	TATA spare parts
250526253111	PILOT BEARING	TATA spare parts
250526253112	ROLLER CAGE-D/SHAFT	TATA spare parts
250526253113	ROLLER CAGE BEARING GBS40	TATA spare parts
250526253114	ROLLER CAGE	TATA spare parts
250526253115	ROLLER CAGE-D/SHAFT	TATA spare parts
250526253116	ROLLER CAGE BEARING GBS40	TATA spare parts
250526253117	ROLLER CAGE-D/SHAFT	TATA spare parts
250526253118	ROLLER CAGE LNGR 28X48X30.8 BS1/2/3/4/6	TATA spare parts
250526253119	ROLLER CAGE	TATA spare parts
250526253121	NEEDLE CAGE	TATA spare parts
250526253701	GEAR BOX HOUSING COVER (FR TOP)BS1/2/3/4	TATA spare parts
250526254605	SYNCHRO RING	TATA spare parts
250526255301	GASKET FRT COVER TOP-HSG BS4	TATA spare parts
250526257802	OIL SEAL FRT GBS40/50	TATA spare parts
250526257803	OIL SEAL FRT GBS40/50	TATA spare parts

250526257804	OIL SEAL	TATA spare parts
250526257805	OIL SEAL	TATA spare parts
250526257806	OIL SEAL DRIVE SHAFT	TATA spare parts
250526257807	OIL SEAL DRIVE SHAFT	TATA spare parts
250526257808	OIL SEAL DRIVE SHAFT BS1/2/3/4	TATA spare parts
250526257809	OIL SEAL DRIVE SHAFT	TATA spare parts
250526257810	OIL SEAL FRT GBS40/50	TATA spare parts
250526257811	OIL SEAL DRIVE SHAFT	TATA spare parts
250526257812	OIL SEAL DRIVE SHAFT	TATA spare parts
250526257813	OIL SEAL DRIVE SHAFT	TATA spare parts
250526257814	OIL SEAL DRIVE SHAFT	TATA spare parts
250526257818	OIL SEAL (57X39X7)	TATA spare parts
250526257902	DRIVE SHAFT BS1/2/3/4	TATA spare parts
250526257902DF	DRIVE SHAFT - GB40	TATA spare parts
250526257904	DRIVE SHAFT (6.34)	TATA spare parts
250526257905	DRIVE SHAFT	TATA spare parts
250526257906	DRIVE SHAFT(F/352 DIA.SPICER CL.SPLINES)	TATA spare parts
250526257908	DRIVE SHAFT	TATA spare parts
250526257910	DRIVE SHAFT EN353	TATA spare parts
250526257912	DRIVE SHFT 6.34 RATIO 310 DIA CLUCTH	TATA spare parts
250526257913	DRIVE SHAFT(17 T) BS1/2/3	TATA spare parts
250526257913AE	DRIVE SHAFT 713	TATA spare parts
250526257913DF	DRIVE SHAFT 17T SINGLE BEARING-497/GB40	TATA spare parts
250526257914	DRIVESHAFT(T=17) 497 ENGINE (330 DIA)	TATA spare parts
250526257915	DRIVE SHAFT (17T) EN353(697ENG.) BS1/2/3	TATA spare parts
250526257915DF	DRIVE SHAFT 17T - 697/GB40	TATA spare parts
250526257917	DRIVE SHAFT (T=19) (697 ENG.)	TATA spare parts
250526257918	DRIVESHAFT(T=17)497ENGINE	TATA spare parts
250526257919	DRIVE SHAFT (15T)(8.02)NUP 497ENG. BS2/3	TATA spare parts
250526257921	DRIVE SHAFT (NUP)(T=19)(497/310)287.4MM	TATA spare parts
250526257922	DRIVE SHAFT 8.02 (T=15)497 330DIA	TATA spare parts
250526257923	DRIVE SHAFT (NUP)(T=15)(697)	TATA spare parts
250526257927	DRIVE SHAFT (T15) 497 ENG. BS3/4	TATA spare parts
250526257930	DRIVE SHAFT	TATA spare parts
250526257931	DRIVE SHAFT BS6	TATA spare parts
250526257933	DRIVE SHAFT BS6	TATA spare parts
250526258201	OIL SLINGER-FRONT SIDE	TATA spare parts
250526258601	BUTTING RING 2.95 MM BS4	TATA spare parts
250526258602	BUTTING RING 3.05 MM	TATA spare parts
250526258603	BUTTING RING 3.15 MM	TATA spare parts
250526258604	BUTTING RING 3.25 MM	TATA spare parts
250526258605	BUTTING RING 3.35 MM	TATA spare parts
250526258606	BUTTING RING 3.45 MM	TATA spare parts
250526258607	BUTTING RING 3.55 MM	TATA spare parts
250526258609	BUTTING RING 3.65 MM	TATA spare parts
250526300136	COUNTER SHAFT ASSY BS6-PH2	TATA spare parts
250526300137	COUNTER SHAFT ASSY WITH PTO	TATA spare parts

250526300139	COUNTER SHAFT ASSY WITH PTO BS6-PH2	TATA spare parts
250526303101	BEARING TAPER ROLLER	TATA spare parts
250526303103	BEARING TAPER ROLLER	TATA spare parts
250526303104	TAPER ROLLER BRG. BS1/2/3/4/6	TATA spare parts
250526303105	TAPER ROLLER BEARING	TATA spare parts
250526303106	TAPER ROLLER BRG.COUNTER SHAFT	TATA spare parts
250526303107	TAPER ROLLER BEARING	TATA spare parts
250526303108	TAPER ROLLER BEARING	TATA spare parts
250526303109	TAPER ROLLER BEARING	TATA spare parts
250526303110	TAPERED ROLLER BRG	TATA spare parts
250526303111	TAPER ROLLER BEARING M/S ZXY CHINA BS6	TATA spare parts
250526303801	COVER(GEAR CASE COVER REA	TATA spare parts
250526305401	4TH GEAR C/SHAFT -28T GBS40 BS1/2/3	TATA spare parts
250526305401DF	GEAR FOURTH SPEED 28T-COUNTER SHAFT-GB40	TATA spare parts
250526305402	TWIN GEAR 2ND/3RD COUNTER SHAFT G40 BS3	TATA spare parts
250526305402DF	GEAR SECOND/THIRD 22T-17T TWIN -C/SHAFT-	TATA spare parts
250526305407	CONSTANTMESH GEAR (6.34)	TATA spare parts
250526305409	CONSTANTMESH GEAR(MAT EN353) BS1/2/3	TATA spare parts
250526305410	TWIN GEAR-C/SHAFT EN353	TATA spare parts
250526305411	3RD GEAR COUNTER SHAFT (T=22) BS1/2/3	TATA spare parts
250526305411DF	GEAR THIRD SPEED 22T-C/SHAFT-GB40	TATA spare parts
250526305411DFNG	GEAR THIRD SPEED 22T-C/SHAFT-GB40-MODIFI	TATA spare parts
250526305412	2ND GEAR COUNTER SHAFT (T=17) BS1/2/3/4	TATA spare parts
250526305412DF	GEAR SECOND SPEED 17T-C/SHAFT-497/GB40	TATA spare parts
250526305413	3RD GEAR(T=22)COUNTER SHAFT (EN353)	TATA spare parts
250526305414	2ND GEAR (T=17)COUNTER SHAFT(EN353) BS4	TATA spare parts
250526305414DF	GEAR SECOND SPEED 17T-C/SHAFT-697&6BT/GB	TATA spare parts
250526305415	3RD GEAR(T=23)COUNTER SHAFT BS1/2/3/4	TATA spare parts
250526305415DF	GEAR THIRD SPEED 23T-C/SHAFT-GB40	TATA spare parts
250526305416	3RD SPEED GEAR COUNTER SHAFT	TATA spare parts
250526305419	2ND GEAR (T=17) COUNTER SHAFT	TATA spare parts
250526305420	3RD GEAR (T=23)COUNTER SHAFT BS4	TATA spare parts
250526305420DF	GEAR THIRD SPEED 23T-C/SHAFT-GB40 MOD	TATA spare parts
250526305421	3RD SPEED GEAR(T=24) COUNTER SHAFT	TATA spare parts
250526305422	4TH GEAR COUNTER SHAFT(8.02/8.98) BS4	TATA spare parts
250526305423	CONSTANT MESH GEAR COUNTER SHAFT	TATA spare parts
250526305424	2ND GEAR (T=17) C.SHAFT(EN353) PRESS FIT	TATA spare parts
250526305425	3RD GEAR COUNTER SHAFT (T=22) BS1/2/3	TATA spare parts
250526305426	4TH GEAR COUNTER SHAFT PRESS FIT	TATA spare parts
250526305427	CONSTANT MESH GEAR COUNTER SHAFT	TATA spare parts
250526305429	CONSTANT MESH GEAR C.SHAFT-PRESS FIT	TATA spare parts
250526305430	GEAR 2ND SPEED COUNTER SHAFT	TATA spare parts
250526307101	GEAR BOX HOUSING COVER	TATA spare parts
250526307901	COUNTER SHAFT -11 T (GBS40) BS2/3	TATA spare parts
250526307901DF	COUNTER SHAFT 11T - GB40	TATA spare parts
250526307902	COUNTER SHAFT 8.02 BS2/3/4	TATA spare parts
250526307903	COUNTER SHAFT 8.02 BS2/3	TATA spare parts

250526307906	COUNTER SHAFT-MAT-EN353 BS1/2/3/4	TATA spare parts
250526307911	COUNTER SHAFT W/O PTO PROV	TATA spare parts
250526307912	COUNTER SHAFT (GBS40) BS3/4	TATA spare parts
250526307913	COUNTER SHAFT W/PTO PROV PRESS FIT	TATA spare parts
250526307914	COUNTER SHAFT W/O PTO PROV PRESS FIT	TATA spare parts
250526307916	COUNTER SHAFT	TATA spare parts
250526308201	G.B.HSG COVER FRONT LOWER	TATA spare parts
250526350102	REVERSE IDLER GEAR 20 T GBS40 BS1/2/3/4	TATA spare parts
250526350102AE	REVERSE IDLE GEAR WITH BUSH 713	TATA spare parts
250526350102DF	GEAR REVERSE IDLER 20T - GB40	TATA spare parts
250526350105	ASSY. REVERSE IDLER GEAR BS1/2/3	TATA spare parts
250526350106	ASSY. REVERSE IDLER GEAR (EN36) BS1-4	TATA spare parts
250526353401	BUSH REVERSE IDLER GEAR	TATA spare parts
250526353402	BUSH REVERSE IDLER GEAR	TATA spare parts
250526353403	BUSH REVERSE IDLER GEAR	TATA spare parts
250526355404	REVERSE IDLER GEAR (EN36)	TATA spare parts
250526400102	PTO W/O SHIFT LEVER PNEUMATIC	TATA spare parts
250526400106	PTO LEVER	TATA spare parts
250526400109	PTO HOUSING	TATA spare parts
250526400110	PTO LEVER RHD	TATA spare parts
250526400111	PTO LEVER ASSY	TATA spare parts
250526400112	PTO PULL ROD ASSY	TATA spare parts
250526400135	PTO HOUSING GBS40	TATA spare parts
250526400136	PTO W/O SHFT LEVER PNEUMA	TATA spare parts
250526400137	ASSY. PTO W/O SHIFT LEVER? BS3	TATA spare parts
250526400140	ASSY HOUSING-PNEUMATIC	TATA spare parts
250526400151	ASSY. PTO PUMP BS3/4	TATA spare parts
250526400152	PTO ASSY	TATA spare parts
250526403101	BEARING CYL ROLLER	TATA spare parts
250526403103	BEARING BALL	TATA spare parts
250526403104	BEARING BALL	TATA spare parts
250526403105	BEARING BALL	TATA spare parts
250526403106	BALL BEARING	TATA spare parts
250526403107	LEADER PART NO.BALL BEARING	TATA spare parts
250526403701	PTO HOUSING HALF OUTER	TATA spare parts
250526403705	HOUSING INNER	TATA spare parts
250526403710	REAR COVER	TATA spare parts
250526404701	BEARING COVER	TATA spare parts
250526405101	PTO SHIFTER FORK	TATA spare parts
250526405301	GASKET	TATA spare parts
250526405302	GASKET/BEARING TO COVER	TATA spare parts
250526405303	GASKET	TATA spare parts
250526405305	GASKET	TATA spare parts
250526405401	PTO SLIDING GEAR 7.51	TATA spare parts
250526405402	PTO SLIDING GEAR 8.98	TATA spare parts
250526406101	LOCKING PLATE	TATA spare parts
250526407901	PTO INPUT SHAFT 7.51	TATA spare parts



250526407902	PTO INPUT SHAFT 8.98	TATA spare parts
250526407903	PTO OUTPUT SHAFT	TATA spare parts
250526407906	PTO SHIFTER SHAFT	TATA spare parts
250526407907	SHIFTER SHAFT	TATA spare parts
250526407908	OUTPUT SHAFT	TATA spare parts
250526408401	PTO SLEEVE	TATA spare parts
250526408601	SPACER	TATA spare parts
250526408612	SPACER	TATA spare parts
250526408613	SPACER	TATA spare parts
250526408614	SPACER	TATA spare parts
250526510101	ASSY SELECTOR FORK - SHAFT REVERSE SPEED	TATA spare parts
250526510102	ASSY SELECTOR FORK - SHAFT 4/5TH SPEED B	TATA spare parts
250526510105	SELECTOR SHAFT REPAIR KIT	TATA spare parts
250526515101	SHIFTING FORK REV SPEED	TATA spare parts
250526515102	SELECTOR FORK 4TH/5TH GEAR GBS40 BS1- 4	TATA spare parts
250526515901	SLIDING KEY	TATA spare parts
250526700103	GEAR SHIFT LEVER	TATA spare parts
250526700105	GEAR SHIFT LEVER	TATA spare parts
250526700107	GEAR SHIFT LEVER	TATA spare parts
250526700108	GEAR SHIFT LEVER	TATA spare parts
250526700109	GEAR BOX SHIFT LEVER KNOB	TATA spare parts
250526700141	ASSY GEAR SHIFT LEVER GB 40 SFC	TATA spare parts
250526700150	GEAR SHIFT LEVER	TATA spare parts
250526700153	ASSY.GEAR SHIFT LEVER (BUTT)	TATA spare parts
250526700156	ASSY.GEAR SHIFT LEVER ARC	TATA spare parts
250526700158	ASSY.GEAR SHIFT LEVER(BUTTWELD)	TATA spare parts
250526700159	ASSY GEAR SHIFT LEVER (ARC WELD)	TATA spare parts
250526700160	ASSY GEAR SHIFT LEVER (BUTT WELD)	TATA spare parts
250526700165	ASSY GEARSHIFT LEVER (UPPER+LOWER)RHD	TATA spare parts
250526700167	ASSY. GEAR SHIFT KNOB	TATA spare parts
250526700172	GEAR SHIFT KNOB ASSY BS6	TATA spare parts
250526705101	GEAR SHIFT LEVER LOWER	TATA spare parts
250526705104	SHIFTER FINGER BS4	TATA spare parts
250526705105	SWING LEVER-SHIFTER FORK 1ST GEAR	TATA spare parts
250526706001	GEAR SHIFT LEVER LOWER	TATA spare parts
250526706003	GEAR SHIFT LEVER UPPER	TATA spare parts
250526706005	GEAR SHIFT LEVER UPPER PART	TATA spare parts
250526706009	SHIFTING LEVER BS1/2/3/4/6	TATA spare parts
250526706011	SHIFTING LEVER BS6	TATA spare parts
250526706015	SHIFTING LEVER BS6	TATA spare parts
250526707908	SELECTOR & SHIFTER SHAFT LP 1512 TC	TATA spare parts
250526707909	SELECTOR & SHIFTER SHAFT (LHD)	TATA spare parts
250526707909AE	SLCTR & SHFTR SFT (LHD) -713	TATA spare parts
250526707911	SELECTOR AND SHIFTER SHAFT(RHD)(NEUTRAL	TATA spare parts
250526707913	SELECTOR & SHIFTER SHAFT	TATA spare parts
250526708701	COMPRESSION SPRING (CENTRAL DETENT)	TATA spare parts
250526708702	COMPRESSION SPRING (REVERSE DETENT)	TATA spare parts

250526709928	GEAR SHIFT LEVER LOWER PART	TATA spare parts
250526710102	HOUSING COVER TOP	TATA spare parts
250526710103	HOUSING COVER TOP	TATA spare parts
250526710232	TOP COVER LOWER HALF	TATA spare parts
250526710233	TOP COVER UPPER HALF	TATA spare parts
250526710234	TOP COVER COMP UP&LOW RHD	TATA spare parts
250526710236	TOP COVER LOWER HALF COMP	TATA spare parts
250526710237	SUB-ASSY.LOWER HALF	TATA spare parts
250526710247	GEAR CASE COVER TOP	TATA spare parts
250526710253	ASSY GEAR CASE COVER TOP (UPPER HALF)RHD	TATA spare parts
250526710254	ASSY GEAR CASE COVER TOP (UPPER HALF)LHD	TATA spare parts
250526710257	ASSY GEAR CASE COVER TOP (UPPER HALF)RHD	TATA spare parts
250526710259	ASSY BRACKET RHD	TATA spare parts
250526710260	ASSY.BRACKET LHD	TATA spare parts
250526710261	ASSY TOP COVER (UPPER HALF)RHD	TATA spare parts
250526710267	ASSY TOP COVERW/G S LEVER BOTTOM	TATA spare parts
250526710286	ASSY GEAR CASE COVER TOP(UPPER HALF)RHD	TATA spare parts
250526710289	GEAR CASE COVER ASSY BS6	TATA spare parts
250526710293	ASSY GEAR CASE COVER TOP (UPPER HALF)RHD	TATA spare parts
250526710295	COVERASSYTOPUPPER-HALF BS6	TATA spare parts
250526710296	COVERASSYTOP(UPHF/RDSFT/NEUSWT)SFGLVR B	TATA spare parts
250526710299	SWING LEVER SHIFTER FORK 1ST GR ASSY BS6	TATA spare parts
250526710303	COVER ASSY TOP-LOWER BS6	TATA spare parts
250526710305	COVER ASSY WITH SHIFTING LEVER TOP	TATA spare parts
250526710310	COVER ASSY TOP UPPER-HALF	TATA spare parts
250526710311	COVER ASSY TOP	TATA spare parts
250526710312	COVER ASSY TOP	TATA spare parts
250526710313	COVER ASSY TOP BS6	TATA spare parts
250526710319	COVER ASSY TOP BS6	TATA spare parts
250526713402	STOPPER PIECE CHECK PLATE	TATA spare parts
250526713403	STOPPER PIECE CHECK PLATE	TATA spare parts
250526713407	STOPPER PIECE CHECK PLATE	TATA spare parts
250526713408	PRESSUR PIECE CHECK PLATE	TATA spare parts
250526713409	PRESSUR PIECE CHECK PLATE	TATA spare parts
250526713410	INTERLOCK PIN CHECK PLATE BS4	TATA spare parts
250526713702	GEAR CASE COVER TOP LP	TATA spare parts
250526713703	GEAR CASE COVER TOP RIS	TATA spare parts
250526713716	GEAR SHIFT DOME	TATA spare parts
250526713752	TOP COVER LOWER HALF	TATA spare parts
250526713754	GEAR CASE COVER TOP	TATA spare parts
250526713755	GEAR CASE COVER TOP LOWER HALF	TATA spare parts
250526713756	TOP COVER UPPER HALF	TATA spare parts
250526713757	DOME TOP COVER ASSY	TATA spare parts
250526713759	GEAR CASE COVER TOP (LOWER HALF)	TATA spare parts
250526715101	GEAR SHIFT LEVER LOW PART	TATA spare parts
250526716701	PIN SWING LEVER	TATA spare parts
250526717701	RUBBER BELLOW	TATA spare parts

250526718203	CAP GEAR SHIFT DOME	TATA spare parts
250526718222	CAP	TATA spare parts
250526718701	PRESSURE SPRING	TATA spare parts
250526718702	PRESSURE SPRING	TATA spare parts
250526718703	PRESSURE SPRING	TATA spare parts
250526800103	GEAR SHIFT LEVER RHD	TATA spare parts
250526800104	GEAR SHIFT LEVER LHD	TATA spare parts
250526800106	ASSY GEAR SHIFT LEVER CO	TATA spare parts
250526800112	ASSY.G.S.LEVER SFC (RHD) CAB GBS-40	TATA spare parts
250526800120	ASSY LEVER	TATA spare parts
250526800123	ASSY GEAR SHIFT LEVER KNOB	TATA spare parts
250526800124	GEAR KNOB	TATA spare parts
250526815101	SHIFT MASS	TATA spare parts
250526820116	BRACKET ASSY CABLE ANCHORING SHIFT BS6-P	TATA spare parts
250526826002	SHIFT LEVER BS6-PH2	TATA spare parts
250526826302	BASE PLATE	TATA spare parts
250526994301	CIRCLIP	TATA spare parts
250526994701	COVER	TATA spare parts
250526995101	HOUSING	TATA spare parts
250526995102	FORK	TATA spare parts
250526995301	GASKET	TATA spare parts
250526996501	HEX NUT	TATA spare parts
250526996605	PISTON	TATA spare parts
250526997201	PLUG	TATA spare parts
250526997701	O-RING	TATA spare parts
250526998401	SLEEVE	TATA spare parts
250526998701	SPRING	TATA spare parts
250526998801	STUD	TATA spare parts
250526999201	WASHER	TATA spare parts
250526999202	SPRING WASHER	TATA spare parts
250526999901	ADAPTER	TATA spare parts
250530010041	GEARBOX GBS40 SFC RHD	TATA spare parts
250530103701	GEARBOX HOUSING	TATA spare parts
250530106701	PIVOT PIN	TATA spare parts
250530116701	THRUST PIN BS4	TATA spare parts
250530120102	TOP COVER GEAR CASE	TATA spare parts
250530120105	TOP COVER GEAR CASE COMP	TATA spare parts
250530120125	ASY GEAR CASE COVER TOP 2	TATA spare parts
250530123713	TOP COVER GEAR CASE	TATA spare parts
250530123714	TOP COVER GEAR CASE	TATA spare parts
250530125101	SELECTOR FORK 4/5 TH	TATA spare parts
250530125102	SHIFTER FORK 4/5 TH	TATA spare parts
250530125151	SELECTOR FORK 4 & 5TH SPEED BS6	TATA spare parts
250530125301	GASKET TOP COVER	TATA spare parts
250530128801	STUD M8 X 38	TATA spare parts
250530129201	WASHER	TATA spare parts
250530134701	GEAR BOX HOUSING COVER FRT TOP BS1/2/3/4	TATA spare parts

250530134701AE	COVER FRONT TOP 713	TATA spare parts
250530135301	GASKET	TATA spare parts
250530135401	4TH GEAR COUNTER SHAFT(8.02/8.98)(R)	TATA spare parts
250530137901	DRIVE SHAFT 17 T GBS40	TATA spare parts
250530137901DF	DRIVE SHAFT 17T - GB40	TATA spare parts
250530137905	ASSY. DRIVE SHAFT (15T GBS40 ) BS3/4	TATA spare parts
250530137905DF	DRIVE SHAFT 15T - GB40	TATA spare parts
250530138601	BUTTING RING 2.90 MM BS4	TATA spare parts
250530138602	BUTTING RING 3.00 MM	TATA spare parts
250530138603	BUTTING RING 3.10 MM	TATA spare parts
250530138604	BUTTING RING 3.20 MM	TATA spare parts
250530138605	BUTTING RING 3.30 MM	TATA spare parts
250530138606	BUTTING RING 3.40 MM	TATA spare parts
250530138607	BUTTING RING 3.50 MM	TATA spare parts
250530138608	BUTTING RING 3.60 MM	TATA spare parts
250530138609	BUTTING RING 3.70 MM	TATA spare parts
250530143101	TAPER.ROLLER BRNG. GBS-40 GEAR BOX	TATA spare parts
250530144701	COVER FRONT LOWER	TATA spare parts
250530144702	COVER REAR	TATA spare parts
250530145301	GASKET LOWER COVER	TATA spare parts
250530145401	4TH GEAR COUNTER SHAFT(8.02/8.98) BS1- 4	TATA spare parts
250530145401DF	GEAR FOURTH SPEED 29T - C/SHAFT - GB40	TATA spare parts
250530145402	CONSTANT MESH GEAR 36T GBS40 BS1/2/3/4	TATA spare parts
250530145402DF	GEAR CONSTANT MESH 36T - GB40	TATA spare parts
250530145406	CONSTANT MESH GEAR - 38T GBS40 BS2/3/4	TATA spare parts
250530145406DF	GEAR CONSTANT MESH 38T - GB40	TATA spare parts
250530147901	COUNTER SHAFT (PTO PROV) BS1/2/3	TATA spare parts
250530147901DF	COUNTER SHAFT 7.51 PTO PROV - GB40	TATA spare parts
250530150103	SYNCRO SLEEVE 4/5 TH SPEED BS1/2	TATA spare parts
250530150104	ASSY HELICAL GEAR 4TH SPEED COMPLETE BS6	TATA spare parts
250530150105	4TH GEAR (HELICAL) (19T)GBS40 BS1/2/3/4	TATA spare parts
250530150105DF	GEAR FOURTH SPEED 19T HELICAL - GB40	TATA spare parts
250530150106	ASSY 1ST SPEED GEAR	TATA spare parts
250530150106DF	GEAR FIRST SPEED 39T - GB40	TATA spare parts
250530153103	BEARING CYL ROLLER	TATA spare parts
250530153401	COLLAR BUSHING 47.20 MM	TATA spare parts
250530153401DF	COLLAR BUSHING - 47.20 MM - GB40	TATA spare parts
250530153402	COLLAR BUSHING 47.30 MM	TATA spare parts
250530153403	COLLAR BUSHING 47.40 MM	TATA spare parts
250530153404	COLLER BUSH 47.50 MM	TATA spare parts
250530153405	COLLER BUSH 47.60 MM	TATA spare parts
250530153406	COLLAR BUSHING 47.70 MM	TATA spare parts
250530153407	COLLAR BUSHING 47.80 MM	TATA spare parts
250530153408	COLLAR BUSHING 47.90 MM	TATA spare parts
250530153701	COVER REAR SPLINE	TATA spare parts
250530153702	COVER REAR LHD	TATA spare parts
250530153713	TOP COVER SFC W/RIS	TATA spare parts

250530153714	TOP COVER SFC W/RIS TIPER	TATA spare parts
250530154701	TOP COVER	TATA spare parts
250530155401	1ST SPEED GEAR 39T GBS40 BS1/2/3/4	TATA spare parts
250530155402	HELICAL GEAR 4TH SPEED(8.02/8.98)	TATA spare parts
250530155403	SYNCHRO SLEEVE 4/5TH SPEED BS1/2/3/4	TATA spare parts
250530155403AE	SYNNISING SLEEVE 4TH & 5TH -713	TATA spare parts
250530155403DF	SYNCHRO SLEEVE - 4/5TH SPEED - GB40	TATA spare parts
250530155403DFNG	SYNCHRO SLEEVE W/3HOLE-4/5SPEED-GB40-MO	TATA spare parts
250530155409	SPEEDOGEAR (MAIN SHAFT) 9T GBS40	TATA spare parts
25053015540922	GEAR SPEEDOMETER DRIVE (FINISH TURNED)	TATA spare parts
250530155410	GEAR S/DRIVE STEEL SMA RH	TATA spare parts
250530155412	1ST SPEED GEAR - 38 T GBS40 BS2/3/4	TATA spare parts
250530157901	MAIN SHAFT - 8T GBS40 BS3/4	TATA spare parts
250530157901DF	MAIN SHAFT 8T - GB40	TATA spare parts
250530177901	SHAFT REVERSE IDLER GEAR	TATA spare parts
250530206101	SPRING WASHER	TATA spare parts
250558900102	PULLER FOR D&M/S BEARINGS	TATA spare parts
250558900103	PULLER INNER RACE D&M/S	TATA spare parts
250558900105	COUNTERSHAFT GEARS REMOVAL PULLER BS6-PH	TATA spare parts
250558900107	HOLDING FIXTURE D/SHAFT	TATA spare parts
250558900108	PULLER DRIVE & MAIN SHAFT	TATA spare parts
250558900109	SPECIAL WRENCH	TATA spare parts
250558900110	PULLER REV IDLER SHAFT	TATA spare parts
250558903101	PULLER INNER RACE C/S BRG	TATA spare parts
250558907101	GAUGE ADJ ENG SLEEVES	TATA spare parts
250558907901	DRIFT OIL SEAL FR COVER	TATA spare parts
250558908401	SLEEVE INNER RACE C/S BRG	TATA spare parts
250558909902	DRIFT OUTER RACE C/S BRG	TATA spare parts
250626010003	GEAR BOX G30 LP RHD	TATA spare parts
250626010004	GEAR BOX G30LP LHD	TATA spare parts
250626010005	GR BOX ASSY	TATA spare parts
250626010017	GEAR BOX ASSY	TATA spare parts
250626010021	ASY.GBC.30 GEAR BOX COMPLETE	TATA spare parts
250626010023	ASYGBC30GEARBOXCOMP	TATA spare parts
250626010051	G/BOX GBC 30 LP	TATA spare parts
250626010053	G/BOX GBC 30 SE	TATA spare parts
250626010065	ASSY G/BOX G30	TATA spare parts
250626010074	G/BOX GBC 30 WITH PTO OPN	TATA spare parts
250626010078	GBC 30 GEAR BOX 6.7	TATA spare parts
250626010088	GEARBOX G30 RHD RAT REMOTE	TATA spare parts
250626103502	BOSS MAGNET	TATA spare parts
250626103701	HOUSING GEARBOX	TATA spare parts
250626103704	GEAR CASE GBC-30	TATA spare parts
250626103707	GEAR BOX HOUSING	TATA spare parts
250626103708	HOUSING GEARBOX	TATA spare parts
250626103710	GEAR CASE G30 W/O PTO OPN	TATA spare parts
250626105301	GASKET TOP COVER	TATA spare parts

250626107202	MAGNETIC DRAIN PLUG	TATA spare parts
250626107203	MAGNETIC DRAIN PLUG	TATA spare parts
250626107204	MAGNETIC DRAIN PLUG	TATA spare parts
250626107206	MAGNETIC DRAIN PLUG	TATA spare parts
250626203101	BEARING NEEDLE CAGE	TATA spare parts
250626203102	BEARING CYL ROLLER	TATA spare parts
250626203105	CYL.ROLLER BRG.	TATA spare parts
250626203106	BEARING NEEDLE CAGE	TATA spare parts
250626203107	BEARING CYL ROLLER	TATA spare parts
250626203108	BEARING NEEDLE CAGE	TATA spare parts
250626203109	CVL.ROLLER BRG.FOR GBC30 G/BOX	TATA spare parts
250626203110	BEARING NEEDLE CAGE	TATA spare parts
250626203112	BEARING BALL FOUR POINT	TATA spare parts
250626203113	FOUR POINT CONTACT BALL BEARRING	TATA spare parts
250626203114	NEEDLE CAGE ASSY	TATA spare parts
250626203116	CYLINDRICAL ROLLER BEARING	TATA spare parts
250626204601	SHIFTER SLEEVE	TATA spare parts
250626205401	REVERSE GEAR 1ST TYPE -35T GBC30	TATA spare parts
250626205402	1ST SPEED GEAR-39T GBC30	TATA spare parts
250626205405	4TH SPEED GEAR-20T GBC30	TATA spare parts
250626205406	ENGAGING GEAR 4/5 -26T GBC30	TATA spare parts
250626206503	CASTLE NUT MAIN SHAFT	TATA spare parts
250626207801	DOUBLE LIP OIL SEAL-REAR COVER	TATA spare parts
250626207802	OIL SEAL	TATA spare parts
250626207804	ROTARY SHAFT SEAL BS4	TATA spare parts
250626207804AE	OIL SEAL 1828	TATA spare parts
250626207901	MAIN SHAFT	TATA spare parts
250626207902	MAINSHAFT-8T GBC30	TATA spare parts
250626207904	SHAFT SPEEDO DRIVE	TATA spare parts
250626208601	SPACER	TATA spare parts
250626208603	BUTTING RING 8.25 MM	TATA spare parts
250626208604	BUTTING RING 8.30 MM	TATA spare parts
250626208605	BUTTING RING 8.35 MM	TATA spare parts
250626208606	BUTTING RING 8.40 MM	TATA spare parts
250626208607	BUTTING RING 8.55	TATA spare parts
250626208608	BUTTING RING 8.50 MM	TATA spare parts
250626208609	BUTTING RING 5.15MM	TATA spare parts
250626208610	BUTTING RING 8.60 MM	TATA spare parts
250626208611	BUTTING RING 6.35 MM	TATA spare parts
250626253101	PILOT BEARING	TATA spare parts
250626253102	BEARING NEEDLE CAGE	TATA spare parts
250626253103	BEARING NEEDLE CAGE	TATA spare parts
250626253104	PILOT BEARING	TATA spare parts
250626253105	NEEDLE ROLLER & CAGE ASEMBLY	TATA spare parts
250626253107	PILOT BEARING	TATA spare parts
250626257901	M.D.GEAR-15T	TATA spare parts
250626257904	DRIVE SHAFT	TATA spare parts

250626303101	TAPER ROLLER BEARING BS2/3/4	TATA spare parts
250626303102	TAPERED ROLLER BRG CBC30 GEARBOX	TATA spare parts
250626303103	BEARING	TATA spare parts
250626305401	DOUBLE GEAR-34T/23T GBC30	TATA spare parts
250626305402	GEAR TWIN C/SHAFT	TATA spare parts
250626305405	DOUBLE GEAR SMALL-29T GBC30	TATA spare parts
250626305406	DOUBLE GEAR BIG-34T GBC30	TATA spare parts
250626307901	COUNTER SHAFT	TATA spare parts
250626353105	ROLLER CAGE BEARING	TATA spare parts
250626353106	ROLLER CAGE	TATA spare parts
250626355401	GEAR REVERSE IDLER	TATA spare parts
250626355404	REVERSE IDLER GEAR-23T GBC30	TATA spare parts
250626357901	SHAFT REVERSE IDLER GEAR	TATA spare parts
250626510103	ASSY SHIFTER FORK	TATA spare parts
250626515101	SHIFTER FORK 1ST SPEED	TATA spare parts
250626515102	SHIFTER FORK 4/5 TH SPEED	TATA spare parts
250626515103	SHIFTER FORK REV SPEED	TATA spare parts
250626515109	SHIFTER FORK W/O RIS LUG	TATA spare parts
250626515111	SHIFTER FORK 1ST SPEED	TATA spare parts
250626515112	SHIFTER FORK REV SPEED	TATA spare parts
250626515113	SHIFTER FORK 4/5 TH SPEED	TATA spare parts
250626515114	SHIFTER FORK REV SPEED	TATA spare parts
250626517901	SHIFTER SHAFT 1 ST SPEED	TATA spare parts
250626517902	SHIFTER SHAFT 2/3RD SPEED	TATA spare parts
250626517903	SHIFTER SHAFT 4/5TH SPEED	TATA spare parts
250626517904	SHIFTER SHAFT REV SPEED	TATA spare parts
250626517907	SHIFTER SHAFT REV SPEED	TATA spare parts
250626517908	SHIFTER SHAFT 1ST SPEED	TATA spare parts
250626517909	SHIFTER SHAFT 2/3RD SPEED	TATA spare parts
250626517910	SHIFTER SHAFT 4/5TH SPEED	TATA spare parts
250626700114	KNOB GEAR SHIFT LEVER	TATA spare parts
250626703401	PRESSURE PIECE STOP PLATE	TATA spare parts
250626705101	SHIFTER FINGER	TATA spare parts
250626707101	GUIDE PLATE	TATA spare parts
250626707102	GUIDE PLATE REMOTE SHIFTG	TATA spare parts
250626707902	SELECTOR & SHIFTER SHAFT	TATA spare parts
250626710102	ASSY GEAR CASE COVER TOP	TATA spare parts
250626710109	TOP COVER SUB ASSY	TATA spare parts
250626710110	TOP COVER W/SLIDING KEY	TATA spare parts
250626710112	TOP COVER	TATA spare parts
250626710143	TOP COVER RHD	TATA spare parts
250626710147	TOP COVR UPPER HALF W/LEV	TATA spare parts
250626713701	TOP COVER GEARBOX	TATA spare parts
250626713702	TOP COVER GAERBOX	TATA spare parts
250626713704	TOP COVER LP W/RIS	TATA spare parts
250626713709	TOP COVER LP	TATA spare parts
250626713710	TOP COVER CR19449	TATA spare parts

250626713753	TOP COVER LOWER HALF	TATA spare parts
250626713754	GEAR CASE COVER TOP-UPPER	TATA spare parts
250626715301	GASKET-TOP COVER UPPER	TATA spare parts
250626717701	PROTECTIVE FOR RIS	TATA spare parts
250626717702	RUBBER BELLOW	TATA spare parts
250626718701	PRESSURE SPRING GBC-30	TATA spare parts
250626719902	ADAPTER	TATA spare parts
250658900101	HOLDING FIXTURE D/SHAFT	TATA spare parts
250658900102	PULLER	TATA spare parts
250658900103	SPANNER D/SHAFT NUT	TATA spare parts
250658908401	DRIFT	TATA spare parts
250658909902	DRIFT	TATA spare parts
250725607701	RUBBER BELLOW	TATA spare parts
250726000101	KIT GASKETS & SEALS GBS50	TATA spare parts
250726010007	GEARBOX GBS50 RHD	TATA spare parts
250726010012	GEARBOX GBS50 RHD RIS	TATA spare parts
250726010033	ASSY GBS50 2515 TC	TATA spare parts
250726010034	GEARBOX GBS50 LHD LPT/LPO	TATA spare parts
250726010103	GEARBOX GBS50 RHD PTO PRO	TATA spare parts
250726010104	ASSY GBS 50 (LH) WITH PROV.FOR PTO & APP	TATA spare parts
250726010105	ASSY GBS5/1-50GEAR BOX RH W PROV.FOR PTO	TATA spare parts
250726010106	GEARBOX GBS50 RHD APPMK3	TATA spare parts
250726010108	GEARBOX GBS50 RHD PTO PRO	TATA spare parts
250726010110	ASSY.GBS-50 FOR SE1615	TATA spare parts
250726010113	ASSY GBS50-5/7.83(6BT )W/PTO LHD	TATA spare parts
250726010114	ASSY GBS 50 W/PTO	TATA spare parts
250726010126	ASSY G 50 COMP W/O PTO WITH CUM.ENG	TATA spare parts
250726010128	GBS50-5/7.83 GEAR BOX W/APP MK III LPK25	TATA spare parts
250726010131	ASSY GBS50 COMPLETE	TATA spare parts
250726010133	ASSY KIT-G-50 GEARBOX	TATA spare parts
250726010135	ASSY KIT FOR GBS 50 LP VEHICLES	TATA spare parts
250726103703	GR BOX HSG	TATA spare parts
250726103704	HOUSING GEARBOX	TATA spare parts
250726105303	GASKET	TATA spare parts
250726106101	LOCKING PLATE LH	TATA spare parts
250726106102	LOCKING PLATE RH	TATA spare parts
250726106104	LOCKING PLATE RH	TATA spare parts
250726106105	LOCKING PLATE	TATA spare parts
250726106706	PIVOT PIN	TATA spare parts
250726106707	PIVOT PIN	TATA spare parts
250726200105	CONTACT BRG	TATA spare parts
250726200110	ASSY GEAR BOX HSG COVER REAR RH	TATA spare parts
250726200119	GEAR REVERSE	TATA spare parts
250726200120	SYNCRO SLEEVE 1ST/REV	TATA spare parts
250726200121	SUB ASSY SYNCHRO SLEEVE 1ST/REV	TATA spare parts
250726200122	GEAR 1ST SPEED	TATA spare parts
250726200123	GEAR 2ND SPEED	TATA spare parts



250726200124	SYNCRO SLEEVE	TATA spare parts
250726200125	GEAR 3RD SPEED	TATA spare parts
250726200126	GEAR 4TH SPEED	TATA spare parts
250726200127	SYNCRO SLEEVE 4/5TH SPEED	TATA spare parts
250726200139	ASSY GEAR BOX HSG COVER REAR RH	TATA spare parts
250726203102	BEARING CYL ROLLER	TATA spare parts
250726203103	BEARING CYL ROLLER	TATA spare parts
250726203104	BEARING NEEDLE CAGE	TATA spare parts
250726203105	BEARING BALL FOUR POINT	TATA spare parts
250726203106	CYLINDRICAL ROLLER BEARING	TATA spare parts
250726203107	ROLLER CAGE	TATA spare parts
250726203108	CYLINDRICAL ROLLER BEARING	TATA spare parts
250726203109	CYLINDRICAL ROLLER BEARING	TATA spare parts
250726203110	CYL ROLLER BRG NU309EN	TATA spare parts
250726203111	BEARING NEEDLE CAGE	TATA spare parts
250726203412	COLLAR BUSH	TATA spare parts
250726203705	COVER REAR GEARBOX HSG	TATA spare parts
250726203709	GEAR BOX HSG COVER REAR LH	TATA spare parts
250726204603	SHIFTER SLEEVE BS1/2	TATA spare parts
250726204604	SYNCRO RING	TATA spare parts
250726204605	ENGAGING RING REV SPEED 51T GBS50	TATA spare parts
250726204606	SYNCHRONISING SLEEVE(1/R/2/3 SPEED) 51T	TATA spare parts
250726204607	SYNCHRONISING SLEEVE 4TH 5TH SPEED 51T G	TATA spare parts
250726204608	SYNCRO RING 5TH SPEED	TATA spare parts
250726204609	SYNCHRONISING CONE	TATA spare parts
250726204610	SYNCHRO CONE	TATA spare parts
250726204611	SYNCHRO. RING(1/2/3/4) 51T GBS50 BS1/2	TATA spare parts
250726204613	SYNCHRONISING RING(5TH SPEED) 51T GBS50	TATA spare parts
250726204618	SYNCHRONISING CONE 1/2/3/4/5 SPEED	TATA spare parts
250726205001	COUPLING FLANGE 8 HOLE BS1/2/3/4	TATA spare parts
250726205302	GASKET REAR COVER	TATA spare parts
250726205413	GEAR 4TH SPEED	TATA spare parts
250726205414	GEAR 3RD SPEED 29T GBS50	TATA spare parts
250726205415	GEAR 2ND SPEED 37T GBS50	TATA spare parts
250726205416	GEAR 1ST SPEED 45T GBS50	TATA spare parts
250726205417	REVERSE GEAR MAIN SHAFT 42T GBS50	TATA spare parts
250726205418	HELICAL GEAR 4TH SPEED 23T GBS50	TATA spare parts
250726206702	RETENTION PIN	TATA spare parts
250726206702AE	RETENTION PIN 715	TATA spare parts
250726206703	RETENTION PIN(IND) GBS-50	TATA spare parts
250726206704	RETENTION PIN	TATA spare parts
250726206707	RETENTION PIN	TATA spare parts
250726207902	MAIN SHAFT	TATA spare parts
250726208603	SPACER 7.85 MM	TATA spare parts
250726208604	SPACER 7.95 MM	TATA spare parts
250726208605	SPACER 8.05 MM	TATA spare parts
250726208606	SPACER 8.15 MM	TATA spare parts

250726208607	SPACER 8.25 MM	TATA spare parts
250726208608	SPACER 8.35 MM	TATA spare parts
250726208609	SPACER 8.45 MM	TATA spare parts
250726208610	SPACER 8.55 MM	TATA spare parts
250726208611	SPACER 8.65 MM	TATA spare parts
250726208613	BUTTING RING M/SHAFT	TATA spare parts
250726208614	BUTTING RING M/SHAFT	TATA spare parts
250726208615	BUTTING RING M/SHAFT	TATA spare parts
250726208616	BUTTING RING M/SHAFT	TATA spare parts
250726208617	BUTTING RING M/SHAFT	TATA spare parts
250726208618	BUTTING RING M/SHAFT	TATA spare parts
250726208619	BUTTING RING M/SHAFT	TATA spare parts
250726208620	BUTTING RING M/SHAFT	TATA spare parts
250726208621	BUTTING RING M/SHAFT	TATA spare parts
250726208622	BUTTING RING M/SHAFT	TATA spare parts
250726208623	BUTTING RING M/SHAFT	TATA spare parts
250726208624	BUTTING RING M/SHAFT	TATA spare parts
250726208625	BUTTING RING M/SHAFT	TATA spare parts
250726208626	BUTTING RING M/SHAFT	TATA spare parts
250726208627	BUTTING RING M/SHAFT	TATA spare parts
250726208628	BUTTING RING M/SHAFT	TATA spare parts
250726208629	BUTTING RING M/SHAFT	TATA spare parts
250726208630	BUTTING RING M/SHAFT	TATA spare parts
250726208631	BUTTING RING	TATA spare parts
250726208703	COMP SPRING	TATA spare parts
250726208704	COMPRESSION SPRING	TATA spare parts
250726208705	COMPRESSION SPRING	TATA spare parts
250726208705AE	COMPRESSION SPRING 715	TATA spare parts
250726208706	RETURN SPRING	TATA spare parts
250726208707	RETURN SPRING	TATA spare parts
250726208708	RETURN SPRING	TATA spare parts
250726253101	ROLLER BEARING	TATA spare parts
250726253102	ROLLER BEARING	TATA spare parts
250726253103	ROLLER RING	TATA spare parts
250726253104	ROLLER RING	TATA spare parts
250726254201	LOCKING PLATE D/SHAFT	TATA spare parts
250726254702	COVER FRONT TOP	TATA spare parts
250726254705	COVER FRONT UPPER	TATA spare parts
250726257801	OIL SEAL	TATA spare parts
250726257802	OIL SEAL	TATA spare parts
250726257803	OIL SEAL DOUBLE LIP D/SHAFT	TATA spare parts
250726257804	OIL SEAL DOUBLE LIP D/SHAFT	TATA spare parts
250726257805	OIL SEAL	TATA spare parts
250726257904	DRIVE SHAFT	TATA spare parts
250726257911	DRIVE SHAFT 350D BS1/2	TATA spare parts
250726258601	SPACER DRIVE SHAFT	TATA spare parts
250726300103	ASSY COUNTER SHAFT GB 50	TATA spare parts

250726303101	TAPER ROLLER BRG 30309	TATA spare parts
250726303101AE	BEARING TAPER ROLLER 715	TATA spare parts
250726303102	TAPER ROLLER BEARING	TATA spare parts
250726303103	TAPER ROLLER BRG	TATA spare parts
250726303104	T.R.BRG.	TATA spare parts
250726303702	COVER GEARBOX HSG REAR	TATA spare parts
250726304702	GEAR BOX HOUSING COVER FRONT LOWER	TATA spare parts
250726305303	GASKET	TATA spare parts
250726305304	GASKET	TATA spare parts
250726305407	GEAR 4TH SPEED C/SHAFT	TATA spare parts
250726305408	CONSTANTMESH GEAR COUNTER SHAFT 43T GBS	TATA spare parts
250726305409	TWIN COU/SHAFT GEAR 2ND/3RD 27TX20T GBS5	TATA spare parts
250726307903	COUNTER SHAFT	TATA spare parts
250726307907	COUNTER SHAFT	TATA spare parts
250726308201	GEARBOX HOUSING COVER FRONT	TATA spare parts
250726308302	SHIM 0.05 MM	TATA spare parts
250726308303	SHIM 0.10 MM	TATA spare parts
250726308304	SHIM 0.20 MM	TATA spare parts
250726308305	SHIM 0.40 MM	TATA spare parts
250726308306	SHIM 0.80 MM	TATA spare parts
250726350102	GEAR REVERSE IDLER	TATA spare parts
250726357901	SHAFT REVERSE IDLER GEAR	TATA spare parts
250726400107	LEVER ASSY	TATA spare parts
250726400109	PTO FOR GBS-50	TATA spare parts
250726400112	ASSY POWER TAKE OFF COUNTER ENGINEWISE	TATA spare parts
250726403101	DEEP GROOVE BALL BEARING	TATA spare parts
250726403102	DEEP GROOVE BALL BEARING	TATA spare parts
250726403103	DEEP GROOVE BALL BEARING	TATA spare parts
250726403104	DEEP GROOVE BALL BEARING	TATA spare parts
250726403701	HOUSING HALF INNER	TATA spare parts
250726403702	ASSY HOUSING HALF-OUTER	TATA spare parts
250726404701	BEARING COVER	TATA spare parts
250726405302	GASKET	TATA spare parts
250726406001	SHIFTER SHAFT MKIII	TATA spare parts
250726407901	INPUT GEAR SHAFT	TATA spare parts
250726407903	OUTPUT GEAR SHAFT	TATA spare parts
250726700110	SPACER SHIFTER FINGER	TATA spare parts
250726700116	SHIFT FORK SUB ASSY 1/REV	TATA spare parts
250726700117	SHIFT FORK SUB ASSY 2/3RD	TATA spare parts
250726700118	SHIFT FORK SUB ASSY 4/5TH	TATA spare parts
250726700124	SUBASSY CONNECTING FLANGE	TATA spare parts
250726700125	SUBASSY BALL&SOCKET BIG	TATA spare parts
250726700126	SUBASSY BALL&SOC LH SMALL	TATA spare parts
250726700127	SUBASSY BALL&SOC RH SMALL	TATA spare parts
250726700128	CONNECTING FLANGE	TATA spare parts
250726700129	CONNECTING TUBE	TATA spare parts
250726700138	SUBASSY BALL&SOC RH SMALL	TATA spare parts

250726700139	SUBASSY BALL&SOC LH SMALL	TATA spare parts
250726700140	SUBASSY BALL&SOCKET BIG	TATA spare parts
250726700142	BALL JOINT	TATA spare parts
250726700143	SUB ASSY BALL & SOCKET JT SMALL	TATA spare parts
250726700149	SUB ASSY BALL & SOCKET JOINT BIG	TATA spare parts
250726700150	ASSY BALL JOINT	TATA spare parts
250726700151	SUB ASSY. BALL & SOCKET JOINT BS1- 4/6	TATA spare parts
250726700152	SUB ASSY. BALL & SOCKET JOINT BIG BS1-4	TATA spare parts
250726700153	SUB ASSY BALL & SOCKET JT SMALL	TATA spare parts
250726700159	BALL JOINT ASSY. RH OF LPTA 1623	TATA spare parts
250726700161	BALL JOINT ASSYRH SMALL	TATA spare parts
250726700403	DETENTCUM INTERLOCK FINFER	TATA spare parts
250726703101	NEEDLE BUSH	TATA spare parts
250726703102	NEEDLE BUSH	TATA spare parts
250726703103	NEEDLE BUSH	TATA spare parts
250726703702	SHIFT FORK 2/3	TATA spare parts
250726705117	SHIFTER FORK 4/5TH	TATA spare parts
250726705118	SHIFTER FORK 2/3RD	TATA spare parts
250726705119	SHIFTER FORK 1ST/REV	TATA spare parts
250726705120	STOP SEGMENT	TATA spare parts
250726705121	SHIFTER FINGER	TATA spare parts
250726705125	DETENT CUM INTERLOCK FINGER	TATA spare parts
250726705126	SHIFTER FINGER	TATA spare parts
250726706001	SHIFTER ROD 2/3RD SPEED	TATA spare parts
250726706002	SHIFTER ROD 1ST/REV SPEED	TATA spare parts
250726706009	SHIFTING LEVER	TATA spare parts
250726706013	SHIFTING LEVER	TATA spare parts
250726706014	SHIFTING LEVER	TATA spare parts
250726706701	PIN	TATA spare parts
250726706703	SHIFTER PIN	TATA spare parts
250726706705	DETENT PIN	TATA spare parts
250726706706	GUIDE PIN SHIFTER FINGER	TATA spare parts
250726706707	LOCKING PIN	TATA spare parts
250726706710	DETENT PLUNGER	TATA spare parts
250726706901	CONNECTING TUBE	TATA spare parts
250726707101	INTERLOCK PLATE	TATA spare parts
250726707910	SELECTOR & SHIFTER SHAFT	TATA spare parts
250726707911	INTERLOCK ROD	TATA spare parts
250726707913	SELECT & SHIFT SHAFT LHD	TATA spare parts
250726707915	SEL & SHIFTERS	TATA spare parts
250726707918	SELECTOR & SHIFTER SHAFT	TATA spare parts
250726707919	INTERLOCK ROD	TATA spare parts
250726707920	SELECTOR & SHIFTER SHAFT	TATA spare parts
250726707921	SELECTOR & SHIFTER SHAFT LHD 15DEG	TATA spare parts
250726707922	SELECTOR & SHIFTER SHAFT RHD 35DEG	TATA spare parts
250726707923	SELECTOR & SHIFTER SHAFT LHD 35DEG	TATA spare parts
250726707925	SELECTOR & SHIFTER SHAFT LHD 15DEG	TATA spare parts

250726708201	DUST CAP	TATA spare parts
250726708204	DUST CAP	TATA spare parts
250726708608	SPACER PRESSURE SRING	TATA spare parts
250726708609	SPACER	TATA spare parts
250726708610	SPACER INTERLOCK PLATE	TATA spare parts
250726708704	PRESSURE SPRING	TATA spare parts
250726708705	PRESSURE SPRING SMALL	TATA spare parts
250726708706	PRESSURE SPRING	TATA spare parts
250726708708	COMPRESSION SPRING(SELECTION)	TATA spare parts
250726708709	DETENT SPRING	TATA spare parts
250726708710	PRESSURE SPRING (DETENT)	TATA spare parts
250726709902	BRASS PAD	TATA spare parts
250726710113	TOP COVER UP & LOW HALF	TATA spare parts
250726710114	COVER TOP LOW W/SIDE COVR	TATA spare parts
250726710117	TOP COVER UP & LOW HALF	TATA spare parts
250726710133	TOP COVER UPPER & LOW HALF	TATA spare parts
250726710134	ASSY G/BOX COVER TOP	TATA spare parts
250726710146	ASSY GEAR BOX HSG COVER TOP RHD 35DEG	TATA spare parts
250726710403	DETENT COVER	TATA spare parts
250726713101	NEEDLE ROL BRG SHELL TYPE	TATA spare parts
250726713103	NEEDLE BUSH	TATA spare parts
250726713104	NEEDLE BUSH	TATA spare parts
250726713105	NEEDLE BUSH INA HK 2520 BS4	TATA spare parts
250726713707	TOP COVER-UPPER	TATA spare parts
250726713711	COVER LH SIDE	TATA spare parts
250726713712	COVER RH SIDE	TATA spare parts
250726713715	G/B HSG COVER TOP LOWER HALF	TATA spare parts
250726713716	COVER TOP UPPER HALF	TATA spare parts
250726713717	TOP COVER UPPER HALF	TATA spare parts
250726713720	TOP COVER SIDE	TATA spare parts
250726713721	DETENT COVER	TATA spare parts
250726713722	GR BOX HSG COVER TOP UPPE	TATA spare parts
250726713723	COVER TOP LOWER HALF	TATA spare parts
250726713725	TOP COVER	TATA spare parts
250726715307	GASKET COVER RH SIDE	TATA spare parts
250726715308	GASKET	TATA spare parts
250726716708	THRUST PIN FOR R.I.S	TATA spare parts
250726717108	ANGLE PLATE-SHIFT LINK	TATA spare parts
250726717801	SCRAPER RING	TATA spare parts
250726717802	OIL SEAL	TATA spare parts
250726717803	SCRAPER RING	TATA spare parts
250726718202	CUP	TATA spare parts
250726800104	KNOB GEAR SHIFT LEVER	TATA spare parts
250726800106	GEAR SHIFT LEVER	TATA spare parts
250726800113	ASSY GEAR SHIFT LEVER KNOB LPT 2516TC	TATA spare parts
250726806002	GEAR SHIFT LEVER	TATA spare parts
250726806301	KNOB GEAR SHIFT LEVER	TATA spare parts

250726809901	GEAR SHIFT LEVER (LOWER PART)	TATA spare parts
250826000101	KIT GASKETS & SEALS GBS24	TATA spare parts
250826010011	GEARBOX GBS24 RHD W/LGSL	TATA spare parts
250826103701	HOUSING GEARBOX	TATA spare parts
250826103706	HOUSING GEARBOX	TATA spare parts
250826105302	GASKET TOP COVER	TATA spare parts
250826200104	SYNCHRO SLEEVE 2/3RD SPD	TATA spare parts
250826200105	RETURN SPRING ASSY	TATA spare parts
250826200110	SYNCHRO SLEEVE 4/5TH SPD	TATA spare parts
250826200111	GEAR 3RD SPEED M/SHAFT	TATA spare parts
250826200112	GEAR 4TH SPEED M/SHAFT	TATA spare parts
250826200115	RETURN SPRING ASSY	TATA spare parts
250826203101	NEEDLE CAGE	TATA spare parts
250826203102	BEARING NEEDLE CAGE DR	TATA spare parts
250826203104	ASSY.NEEDLE CAGE	TATA spare parts
250826203402	COLLAR BUSH 45.00 MM	TATA spare parts
250826203402DF	COLLAR BUSH - 45.00 MM	TATA spare parts
250826203403	COLLER BUSH 45.10 MM	TATA spare parts
250826203404	COLLER BUSH 45.20 MM	TATA spare parts
250826203405	COLLAR BUSH 45.30 MM	TATA spare parts
250826203406	COLLAR BUSH 45.40 MM	TATA spare parts
250826203406DF	COLLAR BUSH - 45.40 MM	TATA spare parts
250826203801	SYNCHRO CONE BS2/3/4	TATA spare parts
250826204601	SHIFTER SLEEVE BS2/3/4	TATA spare parts
250826204602	SYNCHRO RING 4TH SPEED	TATA spare parts
250826204603	SYNCHRO RING 3RD SPEED	TATA spare parts
250826204604	SHIFTER SLEEVE 1ST SPEED	TATA spare parts
250826205301	GASKET COVER REAR	TATA spare parts
250826205404	SYNCHRO SLEEVE 2/3RD SPD BS2/3/4	TATA spare parts
250826205405	SYNCHRO SLEEVE 4/5TH SPD	TATA spare parts
250826205407	GEAR 3RD SPEED	TATA spare parts
250826205408	GEAR 4TH SPEED	TATA spare parts
250826205409	GEAR 2ND SPEED	TATA spare parts
250826205410	GEAR 1ST SPEED	TATA spare parts
250826205411	GEAR REVERSE M/SHAFT	TATA spare parts
250826206701	RETENTION PIN	TATA spare parts
250826206702	RETENTION PIN	TATA spare parts
250826208602	SPACER 9.80 MM	TATA spare parts
250826208604	SPACER 10.0 MM THICK	TATA spare parts
250826208606	SPACER 6.3 0 MM M/S	TATA spare parts
250826208608	SPACER 6.50 MM M/S	TATA spare parts
250826208610	SPACER 6.70 MM M/S	TATA spare parts
250826208611	SPACER 6.80 MM M/S	TATA spare parts
250826208612	SPACER 6.90 MM M/S	TATA spare parts
250826208613	SPACER MAIN SHAFT 7.0THK	TATA spare parts
250826208614	SPACER M/SHAFT	TATA spare parts
250826208618	SPACER 10.20 MM M/S	TATA spare parts

250826208701	COMPRESSION SPRING	TATA spare parts
250826209901	CARRIER	TATA spare parts
250826209903	CARRIER	TATA spare parts
250826254201	CLAMPING PLATE	TATA spare parts
250826254601	SYNCHRO RING 5TH SPEED	TATA spare parts
250826257902	DRIVE SHAFT 807	TATA spare parts
250826257905	DRIVE SHAFT 909 SHORTER	TATA spare parts
250826257906	DRIVE SHAFT	TATA spare parts
250826258701	COMPRESSION SPRING	TATA spare parts
250826305301	GASKET	TATA spare parts
250826305402	GEAR TWIN COUNTER SHAFT	TATA spare parts
250826307903	COUNTER SHAFT	TATA spare parts
250826400101	PTO ASSY COMPLETE	TATA spare parts
250826403701	HOUSING PTO	TATA spare parts
250826405401	INTERMEDIATE GEAR	TATA spare parts
250826513701	SHIFTER FORK 4/5TH SPEED	TATA spare parts
250826513702	SHIFTER FORK 2/3RD SPEED	TATA spare parts
250826515101	SHIFT FORK 2/3 807	TATA spare parts
250826515102	GEAR SHIFT 4/5 TH SPEED	TATA spare parts
250826515105	SHIFTER FORK 1ST SPEED	TATA spare parts
250826517901	G.S. ROD	TATA spare parts
250826517904	SHIFTER SHAFT 4/5TH SPEED	TATA spare parts
250826517905	SHIFTER SHAFT	TATA spare parts
250826517906	SHIFTET SHAFT 1ST SPEED	TATA spare parts
250826517907	REVERSE G.S. ROD	TATA spare parts
250826518602	SPACER	TATA spare parts
250826518701	PRESSURE SPRING	TATA spare parts
250826710117	TOP COVER SYB ASSY	TATA spare parts
250826713705	TOP COVER	TATA spare parts
250826719902	GR SHIFT LEVER LOWER PART	TATA spare parts
251029300102	CLUTCH SLAVE CYLINDER 38.1 DIA. BS1/2/3	TATA spare parts
251046510101	HYDRAULIC TANK SUB ASSY	TATA spare parts
251046517701	SEALING RING	TATA spare parts
251046517703	SEALING RING	TATA spare parts
251046530102	DIPSTICK ASSY	TATA spare parts
251050106501	CAP NUT	TATA spare parts
251050106829	ADAPTER	TATA spare parts
251050106830	ADAPTER	TATA spare parts
251051200104	BYPASS VALVE ASSY	TATA spare parts
251051200105	BYPASS VALVE ASSY	TATA spare parts
251051300107	MANUAL CONTROL VALVE DA	TATA spare parts
251051300108	MANUAL CONTROL VALVE MKII	TATA spare parts
251051300109	MANUAL CONTROL VALVE	TATA spare parts
251051300110	MANUAL CONTROL VALVE	TATA spare parts
251051300112	REP KIT MCV 90 & 905	TATA spare parts
251051300115	MANUAL CONTROL VALVE	TATA spare parts
251051300119	MANUAL CONTROL VALVE	TATA spare parts

251051300131	ASSY.M.C.V. SK36	TATA spare parts
251051313201	PIVOT	TATA spare parts
251051313702	VALVE BODY	TATA spare parts
251051318201	FOOT	TATA spare parts
251051320104	SPOOL SUB ASSY	TATA spare parts
251051320105	SPOOL SUB ASSY	TATA spare parts
251051320108	SPOOL ASSEMBLY	TATA spare parts
251051320110	SPOOL SUB ASSY	TATA spare parts
251051320111	SPOOL ASSEMBLY	TATA spare parts
251051327701	BACK UP RING	TATA spare parts
251051328702	CENTERING SPRING	TATA spare parts
251051329203	WASHER	TATA spare parts
251051334704	END COVER	TATA spare parts
251051334705	COVER	TATA spare parts
251051340104	RELIEF VALVE ASSY	TATA spare parts
251051340105	RELIEF VALVE ASSY	TATA spare parts
251051340106	RELIEF VALVE ASSY	TATA spare parts
251051347203	VALVE CAP	TATA spare parts
251051347701	TEFLON RING	TATA spare parts
251051348306	SHIM	TATA spare parts
251051348307	SHIM	TATA spare parts
251051348308	SHIM	TATA spare parts
251051348704	SPRING	TATA spare parts
251051349005	SPOOL	TATA spare parts
251051801101	BALL CUP	TATA spare parts
251051803302	BRACKET	TATA spare parts
251051804302	SPRING CLIP	TATA spare parts
251051804704	COVER	TATA spare parts
251051806701	BALL PIN POWER SPG	TATA spare parts
251051807202	LOCKING CAP	TATA spare parts
251051807701	TEFLON RING	TATA spare parts
251051809901	BALL CUP	TATA spare parts
251051827702	TEFLON RING	TATA spare parts
251051830101	BALL JOINT RH	TATA spare parts
251051830102	BALL JOINT LH	TATA spare parts
251051834201	CLAMP	TATA spare parts
251052100101	POWER STEERING GEAR PUMP	TATA spare parts
251052100102	KIT POWER STRG GEAR PUMP	TATA spare parts
251052130101	PRESSURE PLATE ASSY	TATA spare parts
251052300108	R/KIT FOR TELE.CYL.1612SE	TATA spare parts
251052300128	AXIAL PISTON PUMP MK II	TATA spare parts
251052300131	AXIAL PISTON PUMP MKIII	TATA spare parts
251052300134	REP KIT APP MK 2	TATA spare parts
251052300136	REPAIR KIT AXIAL PISTON PUMP MK-III	TATA spare parts
251052300141	ASSY AXIAL PISTON PUMP	TATA spare parts
251052300142	APP MK II W/PNE SHIFT CYLINDER	TATA spare parts
251052300143	ASSY APP MK-II W/SHIFT CYL MAGNETIC VALV	TATA spare parts



251052313103	NEEDLE BUSH	TATA spare parts
251052313104	BEARING BALL ANG CONTACT	TATA spare parts
251052313405	SHIFTER PIECE	TATA spare parts
251052313501	BUSH REMOVAL PIECE	TATA spare parts
251052313705	COVER AXIAL PISTON PUMP	TATA spare parts
251052313706	PLUNGER HOUSING	TATA spare parts
251052313710	PLUNGER HOUSING	TATA spare parts
251052313711	SEAL HOUSING	TATA spare parts
251052313713	SHIFTER HOUSING	TATA spare parts
251052313714	SHIFTER HOUSING LH	TATA spare parts
251052313718	SEAL HOUSING MK 2	TATA spare parts
251052313719	PLUNGER HOUSING	TATA spare parts
251052313720	SHIFTER HOUSING RH	TATA spare parts
251052313768	SEAL HOUSING	TATA spare parts
251052315302	GASKET	TATA spare parts
251052315303	GASKET	TATA spare parts
251052315304	GASKET	TATA spare parts
251052316002	SHIFTER SHAFT	TATA spare parts
251052316301	PLASTIC PLUG	TATA spare parts
251052316302	PLASTIC PLUG SUCTION END	TATA spare parts
251052317202	BLEEDING PLUG	TATA spare parts
251052317204	END PIECE	TATA spare parts
251052317207	PLUG	TATA spare parts
251052317701	OIL SEAL	TATA spare parts
251052318603	RING BACK UP	TATA spare parts
251052318604	SPACER	TATA spare parts
251052318605	SPACER	TATA spare parts
251052318701	SPRING	TATA spare parts
251052318702	SPRING	TATA spare parts
251052318703	DETENT SPRING	TATA spare parts
251052319201	WASHER	TATA spare parts
251052319901	BALL SEAT APP MKII	TATA spare parts
251052324402	SPRING GUIDE	TATA spare parts
251052324601	COUPLING SLEEVE	TATA spare parts
251052326602	PLUNGER	TATA spare parts
251052326604	POPPET	TATA spare parts
251052326605	SLEEVE	TATA spare parts
251052326606	SLEEVE	TATA spare parts
251052326607	POPPET MK 3	TATA spare parts
251052328702	COMPRESSION RING	TATA spare parts
251052328703	COMPRESSION SPRING	TATA spare parts
251052330104	BEARING RACE LARGE	TATA spare parts
251052330111	BIG RACE LARGE	TATA spare parts
251052333101	THRUST BALL BEARING	TATA spare parts
251052333102	BEARING RACE SMALL	TATA spare parts
251052333103	BEARING RACE LARGE	TATA spare parts
251052333104	CYL ROLLER THRUST CAGE	TATA spare parts

251052333105	BEARING RACE SMALL	TATA spare parts
251052333106	CYL ROLLER THRUST CAGE	TATA spare parts
251052333107	BRG RACE LARGE	TATA spare parts
251052333108	CYL R THRUST CAGE	TATA spare parts
251052333407	BUSH	TATA spare parts
251052334301	SNAP RING	TATA spare parts
251052337906	SHAFT	TATA spare parts
251052337907	SHAFT AUX PUMP	TATA spare parts
251053200503	SEAL HOUSING	TATA spare parts
251053200703	EYE FOR 4 3/4 CYLINDER	TATA spare parts
251053203402	BUSH	TATA spare parts
251053203403	BUSH	TATA spare parts
251053203404	BUSH	TATA spare parts
251053206501	LOCK NUT	TATA spare parts
251053207701	O RING	TATA spare parts
251053207702	O RING	TATA spare parts
251053208307	SHIM	TATA spare parts
251053209202	BACK UP WASHER	TATA spare parts
251053226503	LOCK NUT	TATA spare parts
251053226603	PISTON	TATA spare parts
251053228605	LANTERN RING	TATA spare parts
251053300102	TELESCOPIC CYLINDER ASSY	TATA spare parts
251053300105	REP KIT TELESCOPIC CYL	TATA spare parts
251053300108	KIT-REP TELESCOPIC CYL BS2/3/4	TATA spare parts
251053303401	BUSH	TATA spare parts
251053303402	BUSH	TATA spare parts
251053307701	NYLON PIECE	TATA spare parts
251053307703	NYLON PIECE	TATA spare parts
251053310108	TUBE ASSY STAGE 1	TATA spare parts
251053313401	SEAL HOUSING	TATA spare parts
251053314702	NUT CYL HEAD	TATA spare parts
251053314704	NUT CYL HEAD CAST	TATA spare parts
251053316603	PISTON STAGE	TATA spare parts
251053316606	PISTON STAGE 1	TATA spare parts
251053316902	TUBE	TATA spare parts
251053316905	TUBE INNER	TATA spare parts
251053316906	TUBE	TATA spare parts
251053317701	RING BACK UP	TATA spare parts
251053317702	RING BACK UP	TATA spare parts
251053317703	SEAL	TATA spare parts
251053317704	RING BACK UP	TATA spare parts
251053317705	SCRAPER RING	TATA spare parts
251053317710	GLAND SEAL	TATA spare parts
251053317714	SEAL	TATA spare parts
251053317715	RING BACK UP	TATA spare parts
251053320103	TUBE SUB ASSY	TATA spare parts
251053324702	NUT STAGE 2	TATA spare parts

251053326605	PISTON STAGE 2	TATA spare parts
251053326904	TUBE STAGE 2	TATA spare parts
251053327701	RING BACK UP	TATA spare parts
251053327702	RING BACK UP	TATA spare parts
251053327703	SEAL	TATA spare parts
251053327704	SCRAPER RING	TATA spare parts
251053327707	GLAND SEAL	TATA spare parts
251053327709	PISTON SEAL NEW	TATA spare parts
251053910103	SEAL ASSY	TATA spare parts
251053927703	PISTON SEAL	TATA spare parts
251053937703	SCRAPER RING	TATA spare parts
251058010004	ASSY 8 TON HYD JACK WITH SPACER BLOCK	TATA spare parts
251058900101	SPANNER PISTON STAGE 1&2	TATA spare parts
251058900102	SPANNER	TATA spare parts
251058900103	SPANNER	TATA spare parts
251058907901	HOLDING DEVICE FOR PISTON	TATA spare parts
251058907902	LOCKING TOOL FOR TUBE ST2	TATA spare parts
251058908201	TOOL FOR SEAL STAGE2	TATA spare parts
251110060001	HEAD LAMP LH NON MOT 12V (FIEM)	TATA spare parts
251110070001	HEAD LAMP RH NON MOT 12V (FIEM)	TATA spare parts
251110080001	HEAD LAMP RH MOTORIZED 12V (FIEM)	TATA spare parts
251110090001	HEAD LAMP LH MOTORIZED 12V (FIEM)	TATA spare parts
251110100001	FRONT DIRECTION INDICATOR	TATA spare parts
251110110001	LAMP BEZEL RH	TATA spare parts
251110120001	LAMP BEZEL LH	TATA spare parts
251110130001	HEAD LAMP RHD RH PRIMA 12V MOTORIZED BS6	TATA spare parts
251110140001	HEAD LAMP RHD LH PRIMA 12V MOTORIZED BS6	TATA spare parts
251120060001	HEAD LAMP SET-LH	TATA spare parts
251120070001	HEAD LAMP SET-RH	TATA spare parts
251120090001	ARAI CERT FOG LAMP 12V	TATA spare parts
251153200106	BUCKET CYLINDER	TATA spare parts
251153200108	RIGGER CYLINDER ASSY	TATA spare parts
251153210103	TUBE ASSY	TATA spare parts
251153227903	PISTON ROD	TATA spare parts
251153227905	PISTON ROD	TATA spare parts
251153227907	PISTON ROD	TATA spare parts
251524200101	BRACKET	TATA spare parts
251524200102	BRACKET	TATA spare parts
251524208202	LOCK PLATE	TATA spare parts
251524208203	LOCK PLATE	TATA spare parts
251526000101	KIT GASKETS GBS18	TATA spare parts
251526010001	GEARBOX GBS18 W/PTO PROV	TATA spare parts
251526010002	GEARBOX GBS18 W/O PTO PROV	TATA spare parts
251526010004	GEARBOX GBS18 W/PTOW/OGSL	TATA spare parts
251526010006	ASSY.GB18 W/PTO OPNG W/RIS FOR LHD	TATA spare parts
251526010008	ASSY.GB18 G.BOX W/PTO OPNG.W/RIS RHD	TATA spare parts
251526010009	ASSY.GB18 G.BOX W/O PTO OPNG.W/RIS RHD	TATA spare parts

251526010014	GEARBOX GBS18 W/PTO RIS	TATA spare parts
251526010015	GBS 18 WITH 6.01 R R-H D	TATA spare parts
251526010016	ASSY.GBS18 G.BOX W/PTO OPNG W/RIS RHD	TATA spare parts
251526010018	GEARBOX GBS18 W/O PTO RIS	TATA spare parts
251526010018YA	YELLOW AGGR ASSY.GBS18 G.BOX W/O PTO	TATA spare parts
251526010019	GEARBOX GBS18 W/O PTO RIS	TATA spare parts
251526010023	ASSY GBS18-5/5.54 W RIS W/O PTO 4X4 RHD	TATA spare parts
251526010107	GEAR BOX ASSY GBS18 LP	TATA spare parts
251526010122	ASSY G18/5.53 W/O PTO FOR LP/LPT407 RHD	TATA spare parts
251526010131	ASSY G-18/5.53 W/PTO PROV.C/FLAN.LPT 407	TATA spare parts
251526010137	ASSY G18 5/5.53*PTO*CPL FLG*SFC407 RH	TATA spare parts
251526010139	ASSY G.BOX COMP.W/O PTO FOR SE407 F LESS	TATA spare parts
251526010152	ASSY. GBS18-5/5.54 WITH 101PCD CPFLANGE	TATA spare parts
251526100102	HOUSING GEARBOX	TATA spare parts
251526103702	HOUSING GEARBOX W/O PTO	TATA spare parts
251526103703	HOUSING GEARBOX W/PTO	TATA spare parts
251526103705	HOUSING GEARBOX W/O PTO	TATA spare parts
251526103706	HOUSING GEARBOX W/PTO	TATA spare parts
251526105301	GASKET TOP COVER	TATA spare parts
251526106701	PIVOT PIN	TATA spare parts
251526107201	MAGNATIC PLUG	TATA spare parts
251526200104	GEAR REVERSE MAIN SHAFT	TATA spare parts
251526200106	GEAR ENGAGING 2/3RD SPD	TATA spare parts
251526200109	GEAR ENGAGING 4/5TH SPD	TATA spare parts
251526200111	COUPLING FLANGE	TATA spare parts
251526200112	GEAR SUBASSY 2ND SPEED	TATA spare parts
251526200117	ASSY.PINION SPEEDOMETER DRIVE	TATA spare parts
251526200118	GEAR SPEEDO NYLON BIG RHD	TATA spare parts
251526200119	ASSY.GEAR SPEEDOMETER DRIVE	TATA spare parts
251526200139	ASSY END YOKE	TATA spare parts
251526203102	FOUR POINT BEARING	TATA spare parts
251526203103	BEARING NEEDLE CAGE	TATA spare parts
251526203104	NEEDLE CAGE 1ST/2ND	TATA spare parts
251526203105	NEEDLE CAGE 1ST/2ND SPEED	TATA spare parts
251526203106	BALL BEARING	TATA spare parts
251526203107	BEARING NEEDLE CAGE	TATA spare parts
251526203108	BEARING NEEDLE CAGE	TATA spare parts
251526203109	BEARING BALL FOUR POINT	TATA spare parts
251526203111	BEARING NEEDLE CAGE	TATA spare parts
251526203112	BEARING NEEDLE CAGE	TATA spare parts
251526203113	NEEDLE CAGE (1ST/2ND)	TATA spare parts
251526203114	BEARING SRDG BALL	TATA spare parts
251526203115	BEARING SRDG BALL	TATA spare parts
251526203116	NEEDLE CAGE NYLON CAGE	TATA spare parts
251526203117	NEEDLE BEARING 1ST/2ND GEAR	TATA spare parts
251526203118	NEEDLE CAGE-3RD./4TH.GEAR	TATA spare parts
251526203119	BALL BEARING	TATA spare parts

251526203120	BALL BEARING	TATA spare parts
251526203121	BALL BEARING	TATA spare parts
251526203122	NEEDLE CAGE 1ST/2ND SPEED	TATA spare parts
251526203123	NEEDLE CAGE-3RD./4TH.GEAR	TATA spare parts
251526203125	NEEDLE CAGE 1ST/2ND SPEED	TATA spare parts
251526203126	BALL BEARING	TATA spare parts
251526203401	COLLAR BUSH 4TH SPEED	TATA spare parts
251526203402	COLLOR BUSH(4TH SPEED)	TATA spare parts
251526203404	COLLAR BUSH-4TH SPEED	TATA spare parts
251526203701	COVER GB HSG REAR RHD	TATA spare parts
251526203702	GEAR CASE COVER REAR LHD	TATA spare parts
251526203705	GEAR CASE COVER REAR LHD	TATA spare parts
251526203801	SYNCHRO CONE 4/5 TH SPEED BS2/3/4	TATA spare parts
251526203802	SYNCHRO CONE 1 ST SPEED BS2/3/4	TATA spare parts
251526203803	SYNCHRO CONE 2ND/3RD SPEED BS2/3/4	TATA spare parts
251526203804	SYNCHRO CONE 1 ST SPEED	TATA spare parts
251526203805	SYNCHRO CONE 2/3 RD SPEED	TATA spare parts
251526203806	SYNCHRO CONE 4/5 TH SPEED	TATA spare parts
251526203807	SYNCHRO CONE 4/5 TH SPEED	TATA spare parts
251526203808	SYNCHRO CONE 2/3 RD SPEED	TATA spare parts
251526203809	SYNCHRO CONE 1 ST SPEED	TATA spare parts
251526204302	SNAP RING 2.68 MM	TATA spare parts
251526204303	SNAP RING 2.73 MM	TATA spare parts
251526204304	SNAP RING 2.78 MM	TATA spare parts
251526204305	SNAP RING 2.83 MM	TATA spare parts
251526204306	SNAP RING 2.88 MM	TATA spare parts
251526204307	SNAP RING 2.93 MM	TATA spare parts
251526204311	CIRCLIP 2.46 MM	TATA spare parts
251526204312	CIRCLIP 2.50 MM	TATA spare parts
251526204313	CIRCLIP 2.54 MM	TATA spare parts
251526204314	CIRCLIP 2.58 MM	TATA spare parts
251526204315	CIRCLIP 2.62 MM	TATA spare parts
251526204316	CIRCLIP 2.66 MM	TATA spare parts
251526204318	CIRCLIP 2.50 MM	TATA spare parts
251526204319	CIRCLIP 2.54 MM	TATA spare parts
251526204320	CIRCLIP 2.58 MM	TATA spare parts
251526204321	CIRCLIP 2.62 MM	TATA spare parts
251526204322	CIRCLIP 2.66 MM	TATA spare parts
251526204324	SNAP RING 2.50 MM	TATA spare parts
251526204333	CIRCLIP 2.7	TATA spare parts
251526204334	CIRCLIP 2.8	TATA spare parts
251526204335	CIRCLIP 2.75	TATA spare parts
251526204336	CIRCLIP(2.46 THK)	TATA spare parts
251526204337	CIRCLIP(2.42 THK)	TATA spare parts
251526204338	CIRCLIP(2.38 THK)	TATA spare parts
251526204339	CIRCLIP(2.34 THK)	TATA spare parts
251526204340	CIRCLIP(2.42 THK)	TATA spare parts

251526204341	CIRCLIP(2.38 THK)	TATA spare parts
251526204601	SHIFTER SLEEVE 4/5 TH BS2/3/4	TATA spare parts
251526204604	SHIFTER SLEEVE REV/1/2/3 BS2/3/4	TATA spare parts
251526204605	SYNCHRO RING 2 ND SPEED	TATA spare parts
251526204606	SHIFTER SLEEVE 1/REV	TATA spare parts
251526205301	GASKET	TATA spare parts
251526205401	4TH SPEED GEAR (22T) G8 BS2/3/4	TATA spare parts
251526205401DF	GEAR FOURTH SPEED 22T - GB18	TATA spare parts
251526205402	2ND SPEED GEAR (32T) G8 BS2/3/4	TATA spare parts
251526205402DF	GEAR SECOND SPEED 32T - GB18	TATA spare parts
251526205403	GEAR REVERSE SPEED	TATA spare parts
251526205407	GEAR ENGAGING 2/3RD SPEED	TATA spare parts
251526205407DF	GEAR ENGAGING 2/THIRD SPEED - GB18	TATA spare parts
251526205408	HELICAL GEAR 23T (3RD SPD) GBS18 BS2/3/4	TATA spare parts
251526205408DF	GEAR THIRD SPEED 23T - GB18	TATA spare parts
251526205410	GEAR ENGAGING 4/5TH SPEED	TATA spare parts
251526205411	GEAR FIRST SPEED BS2	TATA spare parts
251526205411DF	GEAR FIRST SPEED 38T - GB18	TATA spare parts
251526205413	ENGAGING GEAR (4TH/5TH SPEED) BS2/3/4	TATA spare parts
251526205413DF	GEAR ENGAGING 4/5TH SPEED - GB18	TATA spare parts
251526205418	REVERSE GEAR BS2/3/4	TATA spare parts
251526205418DF	GEAR REVERSE SPEED - GB18	TATA spare parts
251526205422	GEAR 4TH SPEED 22 TEETH	TATA spare parts
251526206503	SCREW M8X28 W/NYL INCERT	TATA spare parts
251526206701	BALL PIN	TATA spare parts
251526207802	OIL SEAL REAR GBS18	TATA spare parts
251526207803	OIL SEAL MAIN SHAFT	TATA spare parts
251526207804	OIL SEAL MAIN SHAFT	TATA spare parts
251526207805	OIL SEAL MAIN SHAFT	TATA spare parts
251526207904	MAIN SHAFT BS2/3/4	TATA spare parts
251526207904DF	MAIN SHAFT - GB18	TATA spare parts
251526208203	DUST COVER ASSY COUPLING FLANGE	TATA spare parts
251526208601	SPACER	TATA spare parts
251526208603	SPACER 6.65 MM	TATA spare parts
251526208604	SPACER 6.70 MM	TATA spare parts
251526208605	SPACER 6.75 MM	TATA spare parts
251526208606	SPACER 6.80 MM	TATA spare parts
251526208607	SPACER 6.85 MM	TATA spare parts
251526208608	SPACER 6.90 MM	TATA spare parts
251526208609	SPACER 6.95 MM	TATA spare parts
251526208610	SPACER 7.00 MM	TATA spare parts
251526208611	SPACER 7.05 MM	TATA spare parts
251526208612	SPACER 7.10 MM	TATA spare parts
251526208613	SPACER 7.15 MM	TATA spare parts
251526208614	SPACER 7.20 MM	TATA spare parts
251526208615	SPACER 7.25 MM	TATA spare parts
251526208616	SPACER 7.30 MM	TATA spare parts

251526208617	SPACER 7.35 MM	TATA spare parts
251526208618	SPACER 7.40 MM	TATA spare parts
251526208619	SPACER 7.45 MM	TATA spare parts
251526208627	SPACER	TATA spare parts
251526208701	COMPRESSION SPRING	TATA spare parts
251526208702	SPRING RING	TATA spare parts
251526209901	CARRIER 2/3RD SPEED	TATA spare parts
251526209902	CARRIER 1ST SPEED	TATA spare parts
251526209903	CARRIER 4/5TH SPEED	TATA spare parts
251526209905	CARRIER 1ST SPEED	TATA spare parts
251526209906	CARRIER 1ST SPEED	TATA spare parts
251526209907	CARRIER 2/3RD SPEED	TATA spare parts
251526253101	ROLLER CAGE-DRIVE/MAIN SHAFT	TATA spare parts
251526253102	BEARING ROLLER CAGE	TATA spare parts
251526253103	BEARING ROLLER CAGE	TATA spare parts
251526253104	BEARING ROLLER CAGE	TATA spare parts
251526253105	BEARING ROLLER CAGE	TATA spare parts
251526253106	NEEDLE CAGE	TATA spare parts
251526253107	ROLLER CAGE-DRIVE/MAIN SHAFT	TATA spare parts
251526253702	COVER FRONT GR BOX HSG	TATA spare parts
251526254306	CIRCLIP-2.5 THK	TATA spare parts
251526254307	CIRCLIP-2.4 THK	TATA spare parts
251526254308	CIRCLIP-2.3 THK.	TATA spare parts
251526254309	CIRCLIP-2.2 THK.	TATA spare parts
251526254310	CIRCLIP-2.1 THK.	TATA spare parts
251526255301	GASKET FRONT COVER	TATA spare parts
251526255302	GASKET FRONT COVER	TATA spare parts
251526256501	LOCK NUT LH THREAD	TATA spare parts
251526257801	OIL SEAL FRT GBS18	TATA spare parts
251526257802	OIL SEAL DRIVE SHAFT	TATA spare parts
251526257803	OIL SEAL DRIVE SHAFT	TATA spare parts
251526257804	OIL SEAL DRIVE SHAFT	TATA spare parts
251526257805	OIL SEAL DRIVE SHAFT	TATA spare parts
251526257806	OIL SEAL (DRIVE SHAFT )	TATA spare parts
251526257807	OIL SEAL DRIVE SHAFT	TATA spare parts
251526257902	DRIVE SHAFT	TATA spare parts
251526257902DF	DRIVE SHAFT 19T/36T 5S/5.54 RATIO - GB18	TATA spare parts
251526257904	DRIVE SHAFT N/M 18 T GBS18	TATA spare parts
251526257904DF	DRIVE SHAFT 18T/36T 5S/6.01 RATIO - GB18	TATA spare parts
251526257908	DRIVESHAFT-6.01 RATIO BS2/3/4	TATA spare parts
251526257908DF	DRIVE SHAFT 18T/36T 5S/6.01 RATIO - GB18	TATA spare parts
251526257909	DRIVE SHAFT (EN353)	TATA spare parts
251526257913	ASSY. DRIVE SHAFT (RAT 5.54) BS2	TATA spare parts
251526257913DF	DRIVE SHAFT 19T/36T W/CIR GRV-5S/5.54-GB	TATA spare parts
251526258201	OIL SLINGER (DRIVE SHAFT)	TATA spare parts
251526258301	SHIM 1.2MM THK.	TATA spare parts
251526258602	SPACER D/SHAFT	TATA spare parts

251526303102	BEARING TAPER ROLLER	TATA spare parts
251526303103	TAPER ROLLER BRG.	TATA spare parts
251526303104	TAPERED ROLLER BEARING(30X72X20.75)	TATA spare parts
251526305401	GEAR CONMESH C/SHAFT	TATA spare parts
251526305402	C/SHAFT GEAR SMALL 33 T GBS18	TATA spare parts
251526305402DF	GEAR SMALL C/SHAFT 33T - GB18	TATA spare parts
251526305402DFNG	GEAR SMALL C/SHAFT 33T - GB18 MODIFIED	TATA spare parts
251526305403	C/SHAFT GEAR BIG 37 T GBS18	TATA spare parts
251526305403DF	GEAR BIG C/SHAFT 37T - GB18	TATA spare parts
251526305408	CONSTANT MESH GEAR-COUNTER SHAFT	TATA spare parts
251526305408DF	GEAR CONSTANT MESH 36T - GB18	TATA spare parts
251526305409	4TH SPEED GEAR-COUNTER SHAFT	TATA spare parts
251526305410	CONSTANT MESH GEAR-COUNTER SHAFT	TATA spare parts
251526307902	COUNTER SHAFT	TATA spare parts
251526307902DF	COUNTER SHAFT - GB18	TATA spare parts
251526307904	COUNTER SHAFT (GBS18-5/5.54) BS2/3/4	TATA spare parts
251526307904DF	COUNTER SHAFT - GB18	TATA spare parts
251526353101	ROLLER CAGE REV IDLER	TATA spare parts
251526353102	ROLLER CAGE REV IDLER	TATA spare parts
251526353103	ROLLER CAGE REV IDLER	TATA spare parts
251526353104	ROLLER CAGE REVERSE IDLER	TATA spare parts
251526353105	ROLLER CAGE REVERSE IDLER	TATA spare parts
251526353106	ROLLER CAGE REVERSE IDLER	TATA spare parts
251526353107	ROLLER CAGE REVERSE IDLER	TATA spare parts
251526355402	REVERSE IDLER GEAR 22T GBS18 BS2/3/4	TATA spare parts
251526355402DF	GEAR REVERSE IDLER 22T - GB18	TATA spare parts
251526357901	SHAFT REVERSE IDLER GEAR	TATA spare parts
251526358601	SPACER	TATA spare parts
251526400101	PTO COMP GBS18 W/O SH LEV	TATA spare parts
251526400103	ASSY PTO HOUSING	TATA spare parts
251526400104	PTO COMP GBS18 W/O SH LEVER	TATA spare parts
251526403103	TAPER ROLLER BEARING	TATA spare parts
251526403104	TAPER ROLLER BEARING	TATA spare parts
251526403105	TAPER ROLLER BEARING	TATA spare parts
251526403106	TAPER ROLLER BEARING	TATA spare parts
251526403107	TAPER ROLLER BEARING	TATA spare parts
251526403702	GBS-18 PTO HOUSING	TATA spare parts
251526405101	SHIFTER FORK	TATA spare parts
251526405401	INTER MEDIATE GEAR.	TATA spare parts
251526407901	IDLER GEAR 407 PTO SHAFT	TATA spare parts
251526407902	SHIFTER SHAFT	TATA spare parts
251526407904	MAIN SHAFT 407 PTO	TATA spare parts
251526510102	INTERMEDIATE LEVER	TATA spare parts
251526510103	SHIFTER DOG 1/REV INLINE	TATA spare parts
251526510104	INTERMEDIATE LEVER	TATA spare parts
251526513704	SHIFTER DOG 1/REV SPEED	TATA spare parts
251526515102	SELECTOR FORK REV SPEED	TATA spare parts



251526515105	SHIFTER DOG REV SPEED	TATA spare parts
251526515106	SHIFTER DOG 2/3RD SPEED	TATA spare parts
251526515107	SHIFTER DOG 1ST SPEED	TATA spare parts
251526515108	SHIFTER FORK 1/2/3RD SPD	TATA spare parts
25152651510830	SH FORK 1/2/3 CHROME PLATED	TATA spare parts
251526515109	SHIFTER FORK 4/5TH SPEED	TATA spare parts
25152651510930	SHIFTER FORK 4/5 CHROME PLATED	TATA spare parts
251526515111	INTERMED LEVER REV GEAR	TATA spare parts
251526515114	INTERMEDIATE LEVER	TATA spare parts
251526515901	SLIDING KEY	TATA spare parts
251526516702	PLUNGER TOP COVER	TATA spare parts
251526518701	COMPRESSION SPRING	TATA spare parts
251526700118	TOP COVER W/O RIS	TATA spare parts
251526703101	NEEDLE BEARING	TATA spare parts
251526703102	NEEDLE BEARING LP 407	TATA spare parts
251526703103	NEEDLE BEARING	TATA spare parts
251526703401	SPRING SEAT LP 407	TATA spare parts
251526705101	SHIFTER FINGER	TATA spare parts
251526706001	SHIFTING LEVER	TATA spare parts
251526706002	SHIFTING LEVER	TATA spare parts
251526706701	THRUST PIN RIS	TATA spare parts
251526706702	PRESSURE PIECE LP 407	TATA spare parts
251526707902	SHIFTER SHAFT 1ST SPEED	TATA spare parts
251526707903	SHIFTER SHAFT 2/3RD SPD	TATA spare parts
251526707904	SHIFTER SHAFT 4/5TH SPD	TATA spare parts
251526707908	SHIFTER SHAFT 1ST SPEED	TATA spare parts
251526707910	SHIFTER SHAFT REV W/RIS	TATA spare parts
251526707911	SELECTOR & SHIFT SHAFT LP	TATA spare parts
251526707912	SHIFTER SHAFT REV LP 407	TATA spare parts
251526707913	SHIFTER SHAFT 1ST LP 407	TATA spare parts
251526707914	SELECTOR SHIFTER SHAFT (RHD).	TATA spare parts
251526707915	SELECTOR SHIFTER SHAFT (LHD)	TATA spare parts
251526707916	SHIFTER SHAFT (REV.SPEED) LP VEH.	TATA spare parts
251526707917	SHIFTER SHAFT (REVERSE SPEED)	TATA spare parts
251526708602	SPACER	TATA spare parts
251526708603	SPACER	TATA spare parts
251526710103	TOP COVER SUB ASSY	TATA spare parts
251526710111	ASSY.G.B.HSG.COVER TOP COMP.W/G.S.LEVER	TATA spare parts
251526710115	TOP COVER SUB ASSY W/RIS	TATA spare parts
251526710116	TOP COVER 1/REV INLINE	TATA spare parts
251526710117	TOP COVER W/GSL 1/R INLIN	TATA spare parts
251526710119	TOP COVER W/PIN FOR RIS	TATA spare parts
251526710120	ASSY GEARBOX HOUSING COVER TOP	TATA spare parts
251526710124	ASSY GEAR CASE COVER TOP (LOWER HALF)	TATA spare parts
251526710125	GEAR BOX COVER	TATA spare parts
251526710127	G/BOX COVER TOP L/HALF LP	TATA spare parts
251526710128	ASSY GR CASE COVR TOP RHD	TATA spare parts

251526713401	BUSH	TATA spare parts
251526713402	BUSH ON TOP COVER	TATA spare parts
251526713403	PRESSURE PIECE GSL	TATA spare parts
251526713404	BUSH TOP COVER	TATA spare parts
251526713704	TOP COVER	TATA spare parts
251526713705	G/BOX COVER TOP(RIS)BARE	TATA spare parts
251526713708	COVER TOP RIS	TATA spare parts
251526713709	GER. CASE COVER TOP	TATA spare parts
251526713710	GEAR CASE COVER LOWER HALF	TATA spare parts
251526713803	GEAR CASE COVER TOP LOWER HALF	TATA spare parts
251526713805	GEAR CASE COVER TOP(UPPER HALF) C.I.	TATA spare parts
251526716501	SLOTTED PLUG	TATA spare parts
251526716701	PIN TOP COVER	TATA spare parts
251526718201	CAP GEAR SHIFT DOME	TATA spare parts
251526718202	BALL PIECE GR SHIFT DOME	TATA spare parts
251526718204	CAP	TATA spare parts
251526718205	BRACKET	TATA spare parts
251526718701	PRESSURE SPRING	TATA spare parts
251526718702	PRESSURE SPRING	TATA spare parts
251526718703	COMPRESSION SPRING	TATA spare parts
251526800101	GEAR SHIFT LEVER RHD	TATA spare parts
251526800103	GEAR SHIFT LEVER LHD	TATA spare parts
251526800105	GEAR SHIFT LEVER RHD	TATA spare parts
251526800108	G S LEVER W/O KNOB	TATA spare parts
251526800109	ASSY GEARSHIFT LEVER (FOR 407 4X4 LHD)	TATA spare parts
251526800110	ASSY GR SHAFT W/LEVR KNOB	TATA spare parts
251526800112	GEAR SHIFT LEVER ASSY	TATA spare parts
251526800113	ASSY GR SHIFT LEVER 709	TATA spare parts
251526800120	G S LEVER SFC 407 RHD- FACELESS	TATA spare parts
251626010015	ASSY. GEAR BOX G27/7.36 W/O PTO BS2/3	TATA spare parts
251626010018	GEARBOX GBS27 SFCRHD 7.36	TATA spare parts
251626010020	ASSY G27/6.17 W/O PTO W/O H BR RHD	TATA spare parts
251626010022	ASSLY G27/6.17,PTO PROV.FULL REMOTE,RHD	TATA spare parts
251626010030	ASSY GBS27-5/7.36 FOR SFC 609LHD	TATA spare parts
251626010103	ASSY.G27/7.36 W.PTO FOR LP 609 RHD.	TATA spare parts
251626010105	ASSY GBS 27/7.36 W/P	TATA spare parts
251626010107	GEAR BOX ASSY	TATA spare parts
251626010108	ASSY.G27/7.36 W/PROVN.FOR PTO(SFC 609)	TATA spare parts
251626010111	ASSY.GEAR BOX GBS27-5/7.36 PTO PROV BS2	TATA spare parts
251626010112	ASSY. GEAR BOX GBS27 W/PTO-LHD EURO1	TATA spare parts
251626010122	ASSY G27-5/4.2 WITH PROV FOR PTO (LHD)	TATA spare parts
251626010123	ASSY G27-5/4.2 WITHOUT PTO (LHD)	TATA spare parts
251626010156	ASSY G27-5/6.17 W/O PTO CPL.FLG FOR SFC	TATA spare parts
251626010157	ASSY G27-5/6.17 PTO PROV CPL FLG SFC709	TATA spare parts
251626010159	ASSY G27-5/6.17 PTO PROV CPL FLG LPT709	TATA spare parts
251626010163	GBS27-5/7.36 W/O PTO W/F.REMOTE(909)EN36	TATA spare parts
251626010163YA	YELLOW AGGR GBS27-5/7.36 W/O PTO	TATA spare parts

251626010165	ASSY GBS27-5.7.36 W/O PTO W/O H BR (85R)	TATA spare parts
251626010166	ASSY GBS27-5/7.36 W/PTO (85R)	TATA spare parts
251626010167	ASSY.G27-5/7.36 W/PNE PTO SK407(SFC)	TATA spare parts
251626010168	GEAR BOX ASSY.G27-5/7.36 W/PTO PROV.(LHD	TATA spare parts
251626010173	ASSY.G27-5/7.36	TATA spare parts
251626010176	ASSY G27/7.36 W/O PTO W/O H BR& RHD	TATA spare parts
251626010179	ASSY. GBS27-5-6.17 FOR LP407 CNG BS-IV	TATA spare parts
251626010181	ASSY GEAR BOX GBS27-5/7.36	TATA spare parts
251626010187	ASSY G27/7.36 W/O PTO WITH 497 MFIP	TATA spare parts
251626010197	GEAR BOX ASSY	TATA spare parts
251626010198	GEAR BOX ASSY	TATA spare parts
251626010199	GEAR BOX ASSY WITH PTO	TATA spare parts
251626010204	GEAR BOX ASSY	TATA spare parts
251626010207	GEAR BOX ASSY	TATA spare parts
251626010211	GEAR BOX ASSY BS6	TATA spare parts
251626100107	HOUSING GEARBOX W/O PTO	TATA spare parts
251626100111	HOUSING GEARBOX W/O PTO	TATA spare parts
251626100114	ASSY FILTER BREATHER	TATA spare parts
251626103710	HOUSING GEARBOX W/O PTO	TATA spare parts
251626103712	GEAR BOX HOUSING W/O PTO OPENING BS2/3/4	TATA spare parts
251626103713	GEAR BOX HOUSING W/PTO OPENING BS2/3/4	TATA spare parts
251626105304	GASKET TOP COVER	TATA spare parts
251626200135	SYNCRO SLEEVE 1/REV	TATA spare parts
251626200136	SYNCRO SLEEVE 2/3RD	TATA spare parts
251626200137	ASSY. HELICAL GEAR 3RD SPEED BS2/3/4	TATA spare parts
251626200138	ASSLY. HELICAL GEAR 4TH SPEED (7.36)	TATA spare parts
251626200144	GEAR ASSY REVERCE SPEED	TATA spare parts
251626200145	GEAR ASSY 1ST SPEED	TATA spare parts
251626200146	GEAR ASSY 2ND SPEED	TATA spare parts
251626200147	GEAR ASSY 3RD SPEED	TATA spare parts
251626200154	REAR COVER SUB ASSY	TATA spare parts
251626200157	SYNCRO SLEEVE 4/5TH SPD	TATA spare parts
251626200158	ASSY.HELICAL GEAR 4TH	TATA spare parts
251626200159	ASSY. RR COVER RHD W/O HAND BRAKE BS3/4	TATA spare parts
251626200167	GEAR ASSY 4TH SPEED 7.36	TATA spare parts
251626200167DF	GEAR FOURTH SPEED 7.36 - GB27	TATA spare parts
251626200167DFNG	GEAR FOURTH SPEED 7.36 - GB27 MODIFIED	TATA spare parts
251626200168	GEAR ASSY 4TH SPEED 6.17	TATA spare parts
251626200173	BEARING NEEDLE CAGE	TATA spare parts
251626200176	ASSY. HELICAL GEAR (3RD SPEED) BS2/3/4	TATA spare parts
251626200181	HELICAL GEAR 4TH SPEED	TATA spare parts
251626200183	ASSY HELICAL GEAR 3RD SPEED	TATA spare parts
251626200192	ASSY HELICAL GEAR 3RD SPEED COMPL.	TATA spare parts
251626200193	ASSY GEAR SPEEDOMTER DRIVE	TATA spare parts
251626200194	ASSY GEAR SPEEDOMETER DRIVE	TATA spare parts
251626200196	ASSY REVERSE GEAR (EN36)	TATA spare parts
251626200197	ASSY. HELICAL GEAR 4TH SP (6.17) BS2/3/4	TATA spare parts

251626200205	ASSLY. COUPLING FLANGE(SERRATED TYPE)	TATA spare parts
251626203107	BEARING CYL ROLLER	TATA spare parts
251626203109	CYL.R/BRG	TATA spare parts
251626203110	CYLINDRICAL ROLLER BEARING	TATA spare parts
251626203111	NEEDLE CAGE	TATA spare parts
251626203112	NEEDLE CAGE ASSY	TATA spare parts
251626203113	FOUR POINT BALL BEARING	TATA spare parts
251626203114	CYLINDRICAL ROLLER BEARING	TATA spare parts
251626203115	FOUR POINT BALL BEARING	TATA spare parts
251626203118	CYL.ROLLER BRG. (45X85X19) BS2/3/4	TATA spare parts
251626203120	CYL ROLLER BEARING¿BS6	TATA spare parts
251626203459	BUSH REAR COVER	TATA spare parts
251626203472	COLLAR BUSH REV	TATA spare parts
251626203473	COLLAR BUSH 35.10 MM	TATA spare parts
251626203474	COLLAR BUSH 35.20 MM	TATA spare parts
251626203475	COLLAR BUSH 35.30 MM	TATA spare parts
251626203476	COLLER BUSH 35.40 MM	TATA spare parts
251626203477	COLLAR BUSH 35.50 MM	TATA spare parts
251626203478	COLLER BUSH 35.60 MM	TATA spare parts
251626203479	COLLAR BUSH 35.70 MM	TATA spare parts
251626203480	COLLAR BUSH 35.80 MM	TATA spare parts
251626203481	COLLER BUSH 35.90 MM	TATA spare parts
251626203702	GEAR CASE COVER	TATA spare parts
251626203810	COVER REAR RHD	TATA spare parts
251626203811	REAR COVER G27 W/O H.BR.LHD	TATA spare parts
251626204302	SNAP RING 1.88 MM	TATA spare parts
251626204303	SNAP RING 1.93 MM	TATA spare parts
251626204304	SNAP RING 1.98 MM	TATA spare parts
251626204305	SNAP RING 2.03 MM	TATA spare parts
251626204306	SNAP RING 2.08 MM	TATA spare parts
251626204307	SNAP RING 2.13 MM	TATA spare parts
251626204601	SHIFTER SLEEVE 1/REV SPD	TATA spare parts
251626204602	SYNCHRO RING 4TH SPD 709	TATA spare parts
251626204603	SYN. RING 4TH SPEED	TATA spare parts
251626204605	SYNCHRO SLEEVE 1ST/R	TATA spare parts
251626204606	SHIFTER SLEEVE 1ST/R BS2/3/4	TATA spare parts
251626205101	COUPLING FLANGE	TATA spare parts
251626205403	HELICAL GEAR	TATA spare parts
251626205417	SYNCHRO SLEEVE 1/REV	TATA spare parts
251626205418	SYNCHRO SLEEVE 2/3RD	TATA spare parts
251626205419	GEAR REV M/S 7.36 & 7.17	TATA spare parts
251626205419DF	GEAR REVERSE SPEED EN36 - GB27	TATA spare parts
251626205420	1ST GEAR MAIN SHAFT(7.36)(43T) BS2/3/4	TATA spare parts
251626205420DF	GEAR FIRST SPEED M/SHAFT 43T 7.36 - GB27	TATA spare parts
251626205421	2ND GEAR MAIN SHAFT BS2/3/4	TATA spare parts
251626205421DF	GEAR SECOND SPEED M/SHAFT - GB27	TATA spare parts
251626205421DFNG	GEAR SECOND SPEED M/SHAFT - GB27 - MODIF	TATA spare parts

251626205422	HELICAL GEAR 3RD SPEED	TATA spare parts
251626205422DF	GEAR THIRD SPEED HELICAL - GB27	TATA spare parts
251626205423	HELICAL GEAR 4 SPEED 7.36 RATIO	TATA spare parts
251626205428	HELICAL GEAR (4TH SPEED) (7.36)	TATA spare parts
251626205429	GEAR 4TH SPEED GBS27M	TATA spare parts
251626205430	SYNCHRONISING SLEEVE (4TH/5TH) BS2/3/4	TATA spare parts
251626205430DF	SYNCHRO SLEEVE 4TH/5TH SPEED - GB27	TATA spare parts
251626205431	2ND GEAR MAIN SHAFT BS2/3/4	TATA spare parts
251626205432	GEAR 3RD SPEED GBS27M	TATA spare parts
251626205435	HELICAL GEAR 1ST SPEED(4.2 RATIO)	TATA spare parts
251626205436	GEAR 2ND (RATIO 4.2)	TATA spare parts
251626205438	REVERSE GEAR	TATA spare parts
251626205441	REVERSE GEAR (MAIN SHAFT) EN353	TATA spare parts
251626205442	REVERSE GEAR (EN36) BS2/3/4	TATA spare parts
251626205442DF	GEAR REVERSE 7.36 & 7.17 - GBS27	TATA spare parts
251626205443	HELICAL GEAR 4TH SPEED (6.17) NEEDLE	TATA spare parts
251626207804	DOUBLE LIP OIL SEAL-REAR COVER	TATA spare parts
251626207807	OIL SEAL (REAR COVER)-SIGMA NOK BS6	TATA spare parts
251626207904	MAIN SHAFT	TATA spare parts
251626207905	MAIN SHAFT REMOTE LP/LPT BS2/3/4	TATA spare parts
251626207905DF	MAIN SHAFT REMOTE - GB27	TATA spare parts
251626208664	SPACER MAIN SHAFT	TATA spare parts
251626208665	SPACER 16.35 MM	TATA spare parts
251626208666	SPACER 16.45 MM	TATA spare parts
251626208667	SPACER 16.55 MM	TATA spare parts
251626208668	SPACER MAIN SFT 16.65 THK	TATA spare parts
251626208669	SPACER (INNER) (NUT BEARING)	TATA spare parts
251626208670	SPACER (OUTER)	TATA spare parts
251626250102	COVER FRONT TOP	TATA spare parts
251626250106	ASSLY.DRIVE SHAFT 7.36 RATIO BS6	TATA spare parts
251626253101	NEEDLE CAGE	TATA spare parts
251626253701	COVER FRONT TOP	TATA spare parts
251626254601	SYNCHRO RING 5TH D/S BS2/3/4	TATA spare parts
251626255301	GASKET-FRONT COVER	TATA spare parts
251626257904	DRIVE SHAFT 7.36 BS2/3/4	TATA spare parts
251626257904DF	DRIVE SHAFT 7.36 - GB27	TATA spare parts
251626257905	DRIVE SHAFT 6.17 BS2/3/4	TATA spare parts
251626257906	DRIVE SHAFT (RATIO-7.36 )	TATA spare parts
251626258301	SHIM 0.05 THK	TATA spare parts
251626258302	SHIM 0.1 THK	TATA spare parts
251626258303	SHIM 0.2 THK	TATA spare parts
251626258304	SHIM 0.4 THK	TATA spare parts
251626258305	SHIM 0.6 THK	TATA spare parts
251626258601	SPACER (DRIVE SHAFT)	TATA spare parts
251626300104	ASSLY. COUNTER SHAFT,7.36 RATIO.	TATA spare parts
251626300106	COUNTER SHAFT ASSY 7.36	TATA spare parts
251626303102	BEARING TAPER ROLLER	TATA spare parts

251626303103	BEARING TAPER ROLLER	TATA spare parts
251626303104	T R BRG	TATA spare parts
251626303105	TAPER ROLLER BEARING-COUNTER SHAFT	TATA spare parts
251626303106	TAPER ROLLER BEARING-COUNTER SHAFT	TATA spare parts
251626303107	TAPER ROLLER BEARING-COUNTER SHAFT	TATA spare parts
251626303108	TAPER ROLLER BEARING-COUNTER SHAFT	TATA spare parts
251626303109	TAPER ROLLER BRG 30207 BS2/3/4	TATA spare parts
251626303110	TAPER ROLLER BEARING-COUNTER SHAFT	TATA spare parts
251626305101	COVER FRONT LOWER	TATA spare parts
251626305407	CONT MESH GR.6.17R.C SFT	TATA spare parts
251626305408	GEAR CONMESH 7.36 C/SHAFT	TATA spare parts
251626305408DF	GEAR CONSTANT MESH 26T 7.36-C/SHAFT-GB27	TATA spare parts
251626305410	GEAR 4TH SPEED 7.36 C/S	TATA spare parts
251626305410DF	GEAR FOURTH SPEED 7.36 C/SHAFT-GB27	TATA spare parts
251626305411	GEAR 4TH SPEED 6.17 C/S	TATA spare parts
251626305422DF	GEAR THIRD SPEED HELICAL W/HOLE - GB27	TATA spare parts
251626307101	GEAR BOX COVER FRONT LOWER	TATA spare parts
251626307904	COUNTER SHAFT 6.17 (GBS27) BS2/3/4	TATA spare parts
251626307904DF	COUNTER SHAFT 6.17 RATIO - GB27	TATA spare parts
251626307906	COUNTER SHAFT 6.36 BS2/3/4	TATA spare parts
251626307906DF	COUNTER SHAFT 7.36 RATIO - GB27	TATA spare parts
251626307907	COUNTER SHAFT	TATA spare parts
251626308302	SHIM	TATA spare parts
251626308303	SHIM	TATA spare parts
251626308304	SHIM	TATA spare parts
251626308305	SHIM	TATA spare parts
251626353102	N R BRG NW 325231	TATA spare parts
251626353103	BEARING ROLLER CAGE	TATA spare parts
251626353104	ROLLER RING [REV IDLER GEAR]	TATA spare parts
251626353105	ROLLER CAGE REV IDLER GEAR	TATA spare parts
251626353106	ROLLER CAGE	TATA spare parts
251626355405	GEAR REVERSE IDLER BS2/3/4	TATA spare parts
251626355405DF	GEAR REVERSE IDLER - GB27	TATA spare parts
251626356102	TH WASHER REV IDLER GEAR	TATA spare parts
251626357905	SHAFT REV IDLER GEAR	TATA spare parts
251626358603	SPACER REV IDLER GEAR	TATA spare parts
251626358604	SPACER - REV IDLER GEAR	TATA spare parts
251626400102	PTO ASSY GBS27 W/O SH LEV	TATA spare parts
251626400103	ASSY PTO(7.36)PNEUM.SHIFT COMP.W/O LEVER	TATA spare parts
251626405402	INTERMEDIATE GEAR (6.17)	TATA spare parts
251626407901	SHIFTER SHAFT	TATA spare parts
251626510115	SHIFT FORK 1/REV FORGED	TATA spare parts
251626510116	SHIFT FORK 1/REV SFC FORG	TATA spare parts
251626515113	SHIFTER FORK 1/REV	TATA spare parts
251626515114	SHIFTER FORK 2/3RD	TATA spare parts
251626515115	SHIFTER FORK 4/5TH	TATA spare parts
251626515120	SHIFTER FORK 1/REV DIR SH	TATA spare parts

251626515121	GEAR SHIFT FORK (1ST/REV)	TATA spare parts
251626516701	THRUST PIN	TATA spare parts
251626516702	THRUST PIN (FOR REVERSE LIGHT SWITCH)	TATA spare parts
251626517905	SHIFTER SHAFT 1/REV	TATA spare parts
251626517906	SHIFTER SHAFT 2/3RD	TATA spare parts
251626517907	SHIFTER SHAFT 4/5TH	TATA spare parts
251626517908	SHIFTER SHAFT	TATA spare parts
251626707901	SELECTOR & SHIFTER SHAFT-RHD	TATA spare parts
251626710113	TOP COVER UPR & LOW HALF	TATA spare parts
251626710115	TOP COVER SUBASSY L/HALF	TATA spare parts
251626710116	TOP COVER ASSY UPR HALF	TATA spare parts
251626710118	ASSY BELL CRANK LEVER	TATA spare parts
251626710140	ASSY GEAR CASE COVER TOP-UPPER HALF	TATA spare parts
251626710142	ASSY TOP COVER[UPPER & LOWER HALF] RHD	TATA spare parts
251626710147	ASSY GEAR CASE COVER TOP (UPPER HALF)	TATA spare parts
251626710151	COVER TOP ASSY ROD SHIFT	TATA spare parts
251626710152	COVER ASSY TOP-UPPER BS6	TATA spare parts
251626713703	INTERLOCK FINGER	TATA spare parts
251626713705	GEAR CASE COVER TOP-UPPER HALF	TATA spare parts
251626713706	GEAR CASE COVER TOP-LOWER HALF	TATA spare parts
251626713707	GEAR CASE COVER TOP(UPPER HALF)(FOR NEUT	TATA spare parts
251626713708	GEAR CASE COVER TOP(LOWER HLF-CBL SHIFT)	TATA spare parts
251626713803	TOP COVER LOWER HALF	TATA spare parts
251626713804	TOP COVER UPPER HALF	TATA spare parts
251626713805	SIDE COVER	TATA spare parts
251626713806	GEAR CASE COVER	TATA spare parts
251626715102	SHIFTER FINGER	TATA spare parts
251626715103	SHIFTER FINGER	TATA spare parts
251626715105	SHIFTING FINGER(FOR NEUTRAL SWITCH)	TATA spare parts
251626715301	GASKET UP/HALF TO L/HALF	TATA spare parts
251626715302	GASKET SIDE COVER	TATA spare parts
251626715303	GASKET TOP COVER	TATA spare parts
251626716703	HEX BOLT	TATA spare parts
251626716705	PRESSURE PIECE	TATA spare parts
251626717201	SEALING PLUG	TATA spare parts
251626717901	SELECTOR & SHIFTER SHAFT	TATA spare parts
251626718201	CUP	TATA spare parts
251626718601	SPACER	TATA spare parts
251626718602	CRINKLED WASHER	TATA spare parts
251626718603	CRINKLED WASHER	TATA spare parts
251626718704	COMPRESSION SPRING	TATA spare parts
251626718705	COMPRESSION SPRING INNER	TATA spare parts
251626718707	COMPRESSION SPRING OUTER	TATA spare parts
251626718801	STUD	TATA spare parts
251626718802	STUD TOP COVER L/HALF	TATA spare parts
251626718803	STUD TOP COVER U/HALF	TATA spare parts
251626800103	GEAR SHIFT LEVER SFC RHD	TATA spare parts

251626800105	GEAR SHIFT LEVER RHD	TATA spare parts
251730300101	WS FITMENT_FRNT_LCV SENEGAL_39901826300	TATA spare parts
251730300201	WS FITMENT_REAR_LCV SENEGAL_39901926300	TATA spare parts
251731500401	STRETCH PANEL FIXTURE UNIT_SENEGAL_LH	TATA spare parts
251731500501	STRETCH PANEL FIXTURE UNIT_SENEGAL_RH	TATA spare parts
251826010004	GEARBOX GBS22R 7.66W/OPTO	TATA spare parts
251826010005	GEARBOX GBS22L 7.66W/OPTO	TATA spare parts
251826010007	GEARBOX GBS22R 7.66 W/PTO	TATA spare parts
251826010009	GEARBOX GBS22R 7.66 RIS	TATA spare parts
251826100101	KIT GASKETS GBS22 W/O PTO	TATA spare parts
251826100102	KIT GASKETS GBS22 W/PTO	TATA spare parts
251826200103	GEAR 4TH SPEED	TATA spare parts
251826200105	SYNCHRO SLEEVE 1/REV SPD	TATA spare parts
251826200112	SYNCHRO SLEEVE 1/REV SPD	TATA spare parts
251826204601	SHIFTER SLEEVE 1/REV SPD	TATA spare parts
251826205401	GEAR 1ST SPEED	TATA spare parts
251826205402	GEAR 2ND SPEED	TATA spare parts
251826205403	GEAR 3RD SPEED	TATA spare parts
251826205404	GEAR 4TH SPEED	TATA spare parts
251826205405	GEAR REVERSE MAIN SHAFT	TATA spare parts
251826205406	SYNCHRO SLEEVE 1/REV	TATA spare parts
251826205407	SYNCHRO SLEEVE 4/5TH	TATA spare parts
251826205410	GEAR 1ST SPEED	TATA spare parts
251826207801	DOUBLE LIP OIL SEAL-REAR COVER	TATA spare parts
251826207803	DOUBLE LIP OIL SEAL-REAR COVER	TATA spare parts
251826207803AE	DBLE LIP OIL SEAL (RR COVER)-715	TATA spare parts
251826207901	MAIN SHAFT	TATA spare parts
251826208602	SPACER 4.10 MM	TATA spare parts
251826208603	SPACER 4.20 MM	TATA spare parts
251826208604	SPACER 4.30 MM	TATA spare parts
251826208605	SPACER 4.40 MM	TATA spare parts
251826208606	SPACER 4.50 MM	TATA spare parts
251826208607	SPACER 4.60 MM	TATA spare parts
251826208608	SPACER 4.70 MM	TATA spare parts
251826208609	SPACER 4.80 MM	TATA spare parts
251826208610	SPACER 4.90 MM	TATA spare parts
251826208611	SPACER 5.00 MM	TATA spare parts
251826208612	SPACER 6.90 MM	TATA spare parts
251826208613	SPACER 7.00 MM	TATA spare parts
251826208614	SPACER 7.10 MM	TATA spare parts
251826208615	SPACER 7.20 MM	TATA spare parts
251826208616	SPACER 7.30 MM	TATA spare parts
251826208617	SPACER 7.40 MM	TATA spare parts
251826208618	SPACER 9.70 MM	TATA spare parts
251826208619	SPACER 9.80 MM	TATA spare parts
251826208620	SPACER 9.90 MM	TATA spare parts
251826208621	SPACER MAIN SHAFT (10.0-0.04 THK.)	TATA spare parts



251826208622	SPACER 10.10 MM	TATA spare parts
251826208623	SPACER 10.20 MM	TATA spare parts
251826208624	SPACER 10.30 MM	TATA spare parts
251826208626	BUTTING RING 5.50 MM	TATA spare parts
251826208627	BUTTING RING 5.55 MM	TATA spare parts
251826208628	BUTTING RING 5.60 MM	TATA spare parts
251826208629	BUTTING RING 5.65 MM	TATA spare parts
251826208630	BUTTING RING 5.70 MM	TATA spare parts
251826208631	BUTTING RING 5.75 MM	TATA spare parts
251826208632	BUTTING RING 5.80 MM	TATA spare parts
251826208633	BUTTING RING 5.85 MM	TATA spare parts
251826208634	BUTTING RING 5.90 MM	TATA spare parts
251826208635	BUTTING RING 5.95 MM	TATA spare parts
251826208636	BUTTING RING 6.00 MM	TATA spare parts
251826208637	BUTTING RING 6.05 MM	TATA spare parts
251826208638	BUTTING RING 6.10 MM	TATA spare parts
251826208639	BUTTING RING 6.15 MM	TATA spare parts
251826208640	BUTTING RING 6.20 MM	TATA spare parts
251826208641	BUTTING RING 6.25 MM	TATA spare parts
251826208642	BUTTING RING 6.30 MM	TATA spare parts
251826208643	BUTTING RING 6.35 MM	TATA spare parts
251826208644	BUTTING RING 6.40 MM	TATA spare parts
251826208645	BUTTING RING 6.45 MM	TATA spare parts
251826208646	BUTTING RING 6.50 MM	TATA spare parts
251826208647	BUTTING RING 6.55 MM	TATA spare parts
251826208648	BUTTING RING 6.60 MM	TATA spare parts
251826208649	BUTTING RING 6.70 MM	TATA spare parts
251826208650	BUTTING RING-6.80 THK	TATA spare parts
251826209902	CARRIER-1ST/REV	TATA spare parts
251826257901	DRIVE SHAFT	TATA spare parts
251826257902	DRIVE SHAFT	TATA spare parts
251826305401	GEAR CONMESH C/SHAFT	TATA spare parts
251826305402	GEAR 4TH COUNTER SHAFT	TATA spare parts
251826305402DF	GEAR FOURTH COUNTER SHAFT	TATA spare parts
251826305403	GEAR CONMESH C/SHAFT	TATA spare parts
251826307901	COUNTER SHAFT	TATA spare parts
251826307902	COUNTER SHAFT	TATA spare parts
251826355401	REVERSE IDLER GEAR	TATA spare parts
251826358601	SPACER ERV IDLER GEAR	TATA spare parts
251826400101	HOUSING PTO	TATA spare parts
251826407901	SHAFT G22/G27/G24 POWER TAKE OFF	TATA spare parts
251826515101	GEAR SHIFT FORK 1/REV	TATA spare parts
251826515102	GEAR SHIFT FORK 2/3 RD	TATA spare parts
251826515103	GEAR SHIFT FORK 4/5 TH	TATA spare parts
251826515104	CLAMP SELECTOR SHAFT	TATA spare parts
251826517101	LUG [SHIFTER FORK (1/REV.SPEED)] BS6	TATA spare parts
251826517902	SHIFTER SHAFT 2/3 RD	TATA spare parts

251826517903	SHIFTER SHAFT 4/5 TH	TATA spare parts
251826517904	SHIFTER SHAFT 1/REV	TATA spare parts
251826700101	KNOB GEAR SFT	TATA spare parts
251826710101	TOP COVER GEARBOX	TATA spare parts
251826710104	GEAR SHIFT LEVER	TATA spare parts
251826713401	PRESSURE PEICE CHECKPLATE	TATA spare parts
251826713702	TOP COVER WITH RIS	TATA spare parts
251826800101	GEAR SHIFT LEVER	TATA spare parts
251826800102	GEAR SHIFT LEVER LHD	TATA spare parts
251826806502	LOCK NUT GSL KNOB	TATA spare parts
251926010010	GEARBOX GBS16 T/E 3.86	TATA spare parts
251926010011	GEARBOX GBS16R T/M 3.86	TATA spare parts
251926010014	GEARBOX GBS16R T/M 3.86	TATA spare parts
251926010015	GEARBOX GBS16L T/M 3.86	TATA spare parts
251926010103	GEARBOX GBS16R SUMO 3.86	TATA spare parts
251926010108	ASSY G-16GB PU/CRCAB BEN/SEAT COM	TATA spare parts
251926100115	HOUSING G/BOX SUB ASSY	TATA spare parts
251926103401	BUSH	TATA spare parts
251926103405	BUSH 4TH/OD	TATA spare parts
251926103406	BUSH 4TH/OD	TATA spare parts
251926103407	BUSH 4TH/OD	TATA spare parts
251926103408	BUSH	TATA spare parts
251926103803	ADAPTER- FOR GEARBOX MTG.	TATA spare parts
251926104801	HOLLOW DOWEL	TATA spare parts
251926105301	GASKET GB HSG FRONT	TATA spare parts
251926108802	STUD	TATA spare parts
251926108804	STUD	TATA spare parts
251926108806	STUD	TATA spare parts
251926108808	STUD	TATA spare parts
251926108809	STUD M8	TATA spare parts
251926108811	STUD	TATA spare parts
251926108812	STUD	TATA spare parts
251926108817	STUD (FOR ADAPTER HOUSING)	TATA spare parts
251926200104	GEAR SPEEDO DRIVE NYL BIG	TATA spare parts
251926200105	GEAR SPEEDO DR NYL SMALL	TATA spare parts
251926200106	COVER RR SUB ASSY GB HSG	TATA spare parts
251926200112	COUPLING FLANGE	TATA spare parts
251926200115	GEAR O/D	TATA spare parts
251926200121	SPARES KIT(3.75R MOD SYN	TATA spare parts
251926200123	GEAR 3RD SPEED	TATA spare parts
251926200129	ASSEMBLY REAR COVER (GBS16)	TATA spare parts
251926200131	HELICAL GEAR 3RDSPEED--EN353	TATA spare parts
251926200132	HELICAL GEAR OVER DRIVE--EN353	TATA spare parts
251926203103	NEEDLE CAGE	TATA spare parts
251926203104	NEEDLE CAGE	TATA spare parts
251926203106	BEARING BALL DEEP GROOVE	TATA spare parts
251926203109	NEEDDLE CAGE [1ST/2ND SPEED]	TATA spare parts

251926203110	NEEDLE CAGE 3/REV	TATA spare parts
251926203112	BEARING SRDG BALL	TATA spare parts
251926203113	BEARING BALL DEEP GROOVE	TATA spare parts
251926203115	NEEDLE CAGE [OVERDRIVE]	TATA spare parts
251926203117	BEARING NEEDLE CAGE	TATA spare parts
251926203118	BALL BEARING	TATA spare parts
251926203119	SRDG BALL BEARING	TATA spare parts
251926203121	NEEDLE CAGE [1ST/2ND SPEED]	TATA spare parts
251926203125	SRDG BALL BEARING	TATA spare parts
251926203126	SRDG BALL BEARING	TATA spare parts
251926203404	BUSH COVER REAR	TATA spare parts
251926203405	BUSH COVER REAR	TATA spare parts
251926203801	SYNCRO CONE 1/2/3RD SPD	TATA spare parts
251926203802	SYNCRO CONE 4TH/OD	TATA spare parts
251926203805	SYNCHRO CONE 1/2/3RD SPD	TATA spare parts
251926203809	SYNCHRO CONE 4TH/OD	TATA spare parts
251926203810	COVER REAR GB HSG	TATA spare parts
251926204302	CIRCLIP 2.45 MM	TATA spare parts
251926204303	CIRCLIP 2.50 MM	TATA spare parts
251926204304	CIRCLIP 2.55 MM	TATA spare parts
251926204305	CIRCLIP 2.60 MM	TATA spare parts
251926204306	CIRCLIP 2.65 MM	TATA spare parts
251926204308	CIRCLIP 2.70 MM	TATA spare parts
251926204309	CIRCLIP 2.65 MM	TATA spare parts
251926204310	CIRCLIP 2.60 MM	TATA spare parts
251926204311	CIRCLIP 2.55 MM	TATA spare parts
251926204312	CIRCLIP 2.50 MM	TATA spare parts
251926204313	CIRCLIP 2.45 MM	TATA spare parts
251926204321	CIRCLIP 2.45 MM	TATA spare parts
251926204322	CIRCLIP 2.50 MM	TATA spare parts
251926204323	CIRCLIP 2.55 MM	TATA spare parts
251926204324	CIRCLIP 2.60 MM	TATA spare parts
251926204325	CIRCLIP 2.10 MM	TATA spare parts
251926204327	CIRCLIP 2.30 MM	TATA spare parts
251926204328	CIRCLIP 2.40 MM	TATA spare parts
251926204329	CIRCLIP 2.70 MM	TATA spare parts
251926204330	CIRCLIP 2.40 MM	TATA spare parts
251926204331	CIRCLIP 2.35 MM	TATA spare parts
251926204335	SNAP RING 1.9 MM	TATA spare parts
251926204336	SNAP RING 2.0 MM	TATA spare parts
251926204337	SNAP RING 2.1 MM	TATA spare parts
251926204338	CIRCLIP 2.25 MM	TATA spare parts
251926204344	CIRCLIP A22 X 2.40 MM	TATA spare parts
251926204345	CIRCLIP A22 X 2.35 MM	TATA spare parts
251926204346	CIRCLIP A22 X 2.30 MM	TATA spare parts
251926204347	CIRCLIP A22 X 2.25 MM	TATA spare parts
251926204350	CIRCLIP A22 X 2.10 MM	TATA spare parts

251926204601	GEAR ENG 1/REV/2/3RD	TATA spare parts
251926204606	SHIFTER SLEEVE 2/3RD	TATA spare parts
251926204612	SHIFTER SLEEVE 4TH/OD	TATA spare parts
251926204613	GEAR ENGAGING 4TH/OD	TATA spare parts
251926204614	SYNCHRO RING O/D GEAR	TATA spare parts
251926204617	SHIFTER SLEEVE 2/3RD	TATA spare parts
251926204618	SHIFTER SLEEVE 1ST/REV	TATA spare parts
251926205102	COUPLING FLANGE	TATA spare parts
251926205103	END YOKE	TATA spare parts
251926205301	GASKET (GEAR CASE COVER REAR)	TATA spare parts
251926205402	GEAR 1ST SPEED	TATA spare parts
251926205404	GEAR 3RD SPEED--NLS	TATA spare parts
251926205409	GEAR SPEEDO DR BIG STEEL	TATA spare parts
251926205418	GEAR REVERSE SPEED	TATA spare parts
251926205420	GEAR 1ST SPEED	TATA spare parts
251926205421	HELICAL GEAR 2ND SPEED-NLS-5423	TATA spare parts
251926205422	GEAR REVERSE SPEED MAIN SHAFT	TATA spare parts
251926205423	HELICAL GEAR 2ND SPEED--EN353	TATA spare parts
251926206701	PLUG SPEEDO SHAFT	TATA spare parts
251926207801	OIL SEAL MAIN SHAFT	TATA spare parts
251926207802	OIL SEAL-MAIN SHAFT	TATA spare parts
251926207803	OIL SEAL	TATA spare parts
251926207804	OIL SEAL-MAIN SHAFT	TATA spare parts
251926207805	OIL SEAL-MAIN SHAFT	TATA spare parts
251926207806	OIL SEAL-MAIN SHAFT	TATA spare parts
251926207807	OIL SEAL-MAIN SHAFT	TATA spare parts
251926207808	OIL SEAL-MAIN SHAFT	TATA spare parts
251926207902	SPEEDO DRIVE SHAFT	TATA spare parts
251926207904	MAIN SHAFT	TATA spare parts
251926207906	SPEEDO DRIVE SHAFT JIS	TATA spare parts
251926208201	DUST PROTECTOR	TATA spare parts
251926208603	SPACER 5.20 MM	TATA spare parts
251926208604	SPACER 5.15 MM	TATA spare parts
251926208605	SPACER 5.10 MM	TATA spare parts
251926208606	SPACER 5.05 MM	TATA spare parts
251926208608	SPACER 4.95 MM	TATA spare parts
251926208609	SPACER 4.90 MM	TATA spare parts
251926208610	SPACER 4.85 MM	TATA spare parts
251926208612	SPACER 4.75 MM	TATA spare parts
251926208613	SPACER 4.70 MM	TATA spare parts
251926208614	SPACER 4.65 MM	TATA spare parts
251926208615	SPACER 4.60 MM	TATA spare parts
251926208616	SPACER 4.55 MM	TATA spare parts
251926208618	SPACER 4.50 MM	TATA spare parts
251926208619	SPACER 4.45 MM	TATA spare parts
251926208620	SPACER 5.35 MM	TATA spare parts
251926208621	SPACER 5.30 MM	TATA spare parts

251926208622	SPACER 5.40 MM	TATA spare parts
251926208623	SPACER 4.40 MM	TATA spare parts
251926208624	SPACER 4.45 MM	TATA spare parts
251926208626	SPACER 4.55 MM	TATA spare parts
251926208627	SPACER 4.60 MM	TATA spare parts
251926208628	SPACER 4.65 MM	TATA spare parts
251926208629	SPACER 4.70 MM	TATA spare parts
251926208630	SPACER 4.75 MM	TATA spare parts
251926208631	SPACER 5.45 MM	TATA spare parts
251926208701	SPRING RING 1/2/3 SY CONE	TATA spare parts
251926208702	SPRING RING 4/OD SY CONE	TATA spare parts
251926208718	SPACER	TATA spare parts
251926250110	DRIVE SHAFT SUB ASSY 3.86	TATA spare parts
251926250113	BEARING TUBE D/S COVER	TATA spare parts
251926250116	ASSY BRG. TUBE	TATA spare parts
251926253103	BEARING PILOT	TATA spare parts
251926253105	BEARING PILOT	TATA spare parts
251926253106	BEARING ROLLER CAGE	TATA spare parts
251926253107	ROLLER CAGE	TATA spare parts
251926253108	ROLLER CAGE	TATA spare parts
251926253801	COVER FRONT GEAR CASE	TATA spare parts
251926254302	CIRCLIP 1.95 MM	TATA spare parts
251926254303	CIRCLIP 2.00 MM	TATA spare parts
251926254305	CIRCLIP 2.10 MM	TATA spare parts
251926254306	CIRCLIP 2.15 MM	TATA spare parts
251926254308	CIRCLIP 1.90 MM	TATA spare parts
251926254309	CIRCLIP 1.85 MM	TATA spare parts
251926254311	CIRCLIP-DRIVE SHAFT	TATA spare parts
251926254312	CIRCLIP-DRIVE SHAFT	TATA spare parts
251926254313	CIRCLIP-DRIVE SHAFT	TATA spare parts
251926257801	OIL SEAL DRIVE SHIFT DOUBLE LIP	TATA spare parts
251926257801AE	DBLE LIP OIL SEAL(DRV)-XEN DC/SC	TATA spare parts
251926257802	OIL SEAL DRIVE SHIFT DOUBLE LIP	TATA spare parts
251926257803	OIL SEAL DRIVE SHIFT DOUBLE LIP	TATA spare parts
251926257804	OIL SEAL DRIVE SHIFT DOUBLE LIP	TATA spare parts
251926257805	OIL SEAL DRIVE SHIFT DOUBLE LIP	TATA spare parts
251926257806	OIL SEAL DRIVE SHIFT DOUBLE LIP	TATA spare parts
251926257807	OIL SEAL DRIVE SHIFT DOUBLE LIP	TATA spare parts
251926257808	OIL SEAL DRIVE SHIFT DOUBLE LIP	TATA spare parts
251926257809	OIL SEAL DRIVE SHIFT DOUBLE LIP	TATA spare parts
251926257810	DOUBLE LIP OIL SEAL	TATA spare parts
251926258201	BEARING TUBE NLS-0113	TATA spare parts
251926258601	SPACER 0.80 MM	TATA spare parts
251926258603	SPACER 1.20 MM	TATA spare parts
251926258606	SPACER 0.60 MM	TATA spare parts
251926258607	SPACER 1.00 MM	TATA spare parts
251926258608	SPACER 0.40 MM	TATA spare parts

251926258609	SPACER 0.20 MM	TATA spare parts
251926303101	BEARING TAPER ROLLER	TATA spare parts
251926303102	TAPER ROLLER BEARING	TATA spare parts
251926303103	TAPER ROLLER BEARING-COUNTER SHAFT	TATA spare parts
251926303104	TAPER ROLLER BRG 1988/22	TATA spare parts
251926303105	TAPER ROLLER BEARING-COUNTER SHAFT	TATA spare parts
251926305403	GEAR CONMESH C/SHAFT	TATA spare parts
251926305404	GEAR OVERDRIVE	TATA spare parts
251926305405	GEAR CONMESH	TATA spare parts
251926305406	GEAR TWIN 2/3RD	TATA spare parts
251926307902	COUNTER SHAFT 3.75	TATA spare parts
251926307904	COUNTER SHAFT 3.86	TATA spare parts
251926308302	SHIM 0.050 MM	TATA spare parts
251926308303	SHIM 0.125 MM	TATA spare parts
251926308304	SHIM 0.240 MM	TATA spare parts
251926308305	SHIM 0.500 MM	TATA spare parts
251926308306	SHIM-COUNTER SHAFT	TATA spare parts
251926308601	SPACER COUNTER SHAFT	TATA spare parts
251926350101	GEAR REVERSE IDLER	TATA spare parts
251926350104	GEAR REVERSE IDLER 3.86	TATA spare parts
251926353401	BUSH REV IDLER GEAR	TATA spare parts
251926355301	GASKET SIDE COVER	TATA spare parts
251926355404	GEAR REVERSE IDLER 3.86	TATA spare parts
251926356101	LOCK WASHER R/IDLER GEAR	TATA spare parts
251926357901	SHAFT REVERSE IDLER GEAR	TATA spare parts
251926358201	COVER SIDE GEARBOX HSG	TATA spare parts
251926510102	COVER SWINGLEVER NLS 0104	TATA spare parts
251926510103	LOCKING PIN	TATA spare parts
251926513101	NEEDLE CAGE SWING LEVER	TATA spare parts
251926513102	NEEDLE CAGE SWING LEVER	TATA spare parts
251926513105	NEEDLE CAGE SWING LEVER	TATA spare parts
251926513106	NEEDLE CAGE	TATA spare parts
251926513405	CONNECTING BUSH UJ	TATA spare parts
251926513706	SHIFTER FORK 4TH/OD	TATA spare parts
251926513707	SHIFTER FORK 1/REV	TATA spare parts
251926513709	SHIFTER DOG 4TH/OD	TATA spare parts
251926513710	COVER SWING LEVER	TATA spare parts
251926513716	SHIFTER FORK 2/3RD	TATA spare parts
251926513717	SHIFTER FORK 1/REV	TATA spare parts
251926513803	COVER SWING LEVER	TATA spare parts
251926514301	SPRING CLIP	TATA spare parts
251926515103	SHIFTER FORK 4TH/OD	TATA spare parts
251926515105	INTER LOCK PIECE	TATA spare parts
251926515106	SWING LEVER	TATA spare parts
251926515301	GASKET SWING LEVER COVER	TATA spare parts
251926515302	GASKET	TATA spare parts
251926516301	PAD UJ BUSH	TATA spare parts

251926516703	PIN SWING LEVER	TATA spare parts
251926516706	THRUST PIN	TATA spare parts
251926516707	THRUST PIN FOR RIS	TATA spare parts
251926516708	THRUST PIN FOR RIS	TATA spare parts
251926516709	THRUST PIN FOR RIS	TATA spare parts
251926516710	SHIFTING PIN	TATA spare parts
251926516711	CYLINDRICAL PIN UJ	TATA spare parts
251926516712	PIN SWING LEVER LONGER	TATA spare parts
251926517902	SHIFTER SHAFT 4TH/OD	TATA spare parts
251926517907	SHIFTER SHAFT 4TH/OD	TATA spare parts
251926517908	SHIFTER SHAFT OUTER	TATA spare parts
251926517912	SHIFTER SHAFT	TATA spare parts
251926518602	SPACER SWING LEVER	TATA spare parts
251926518616	SPACER (5.00)	TATA spare parts
251926518801	HEX FIT BOLT	TATA spare parts
251926700104	KNOB GEAR NLS S LEVER PR TYPE	TATA spare parts
251926710122	ADAPTER HSG SUB ASSY	TATA spare parts
251926710124	ADAPTER HSG	TATA spare parts
251926710125	EXTENSION ARM W/BUSH	TATA spare parts
251926710126	SUPPORT EXTENSION ARM	TATA spare parts
251926710133	SUPPORT EXTENSION BOX T/S	TATA spare parts
251926710134	SUPPORT EXTENSION ARM T/E	TATA spare parts
251926710138	ASSY.EXTENSION BOX SUPPORT	TATA spare parts
251926710142	ASSY EXTENSION BOX SUPPORT(FOR PICK-UP)	TATA spare parts
251926710144	EXTENSION ARM W/BUSH	TATA spare parts
251926710147	ASSY. EXT. ARM	TATA spare parts
251926713402	BUSH EXT BOX	TATA spare parts
251926713419	PRESSURE PIECE	TATA spare parts
251926713421	BUSH	TATA spare parts
251926713422	BUSH EXTENSION ARM	TATA spare parts
251926713702	SHIFTING YOKE	TATA spare parts
251926713704	SHIFTING YOKE	TATA spare parts
251926715301	GASKET EXTENSION BOX	TATA spare parts
251926716311	TOP COVER EXTENSION ARM	TATA spare parts
251926716312	BOTT COVER EXTENSION ARM	TATA spare parts
251926716313	PLUG ADAPTOR HOUSING	TATA spare parts
251926716315	BOTT COVER EXTENSION ARM	TATA spare parts
251926716316	TOP COVER EXTENSION ARM	TATA spare parts
251926716704	PIN	TATA spare parts
251926716708	PIN	TATA spare parts
251926717104	GUIDE PLATE	TATA spare parts
251926717801	OIL SEAL	TATA spare parts
251926717802	DUST SEAL	TATA spare parts
251926718203	END COVER EXTENSION BOX	TATA spare parts
251926718213	CAP EXTENSION BOX	TATA spare parts
251926718709	COMPRESSION SPRING	TATA spare parts
251926800117	GEAR SHIFT BLOCK	TATA spare parts

251926800132	GEAR SHIFT LEVER UP PART	TATA spare parts
251926800135	GEAR SHIFT LEVER L U/PART	TATA spare parts
251926800137	GEAR SHIFT LEVER R COMP	TATA spare parts
251926800138	GEAR SHIFT LEVER COMPLT	TATA spare parts
251926800147	GEAR SHIFT LEVER	TATA spare parts
251926800154	SHIFTING YOKE ASSY	TATA spare parts
251926803401	BUSH GEAR SHIFT LEVER	TATA spare parts
251926803404	BUSH GEAR SHIFT LEVER	TATA spare parts
251926806311	SPACER GEAR SHIFT LEVER	TATA spare parts
251926806701	PIN	TATA spare parts
251926806703	PIN	TATA spare parts
251926806704	PIN	TATA spare parts
251926807706	RUBBER BUSH GSL	TATA spare parts
251926807713	RUBBER BELLOW GSL CAB	TATA spare parts
251926807714	SEALING NLS BELLOW GSL	TATA spare parts
251926807715	RUBBER BELLOW GSL	TATA spare parts
251926807716	RUBBER BELLOW GSL	TATA spare parts
251926807717	RUBBER BELLOW	TATA spare parts
251926808210	CLAMPING PLATE	TATA spare parts
251926808211	CLAMPING PLATE	TATA spare parts
251926808601	SPACER GSL	TATA spare parts
251926808701	COMPRESSION SPRING GSL	TATA spare parts
251926808703	LOCKING WIRE GSL	TATA spare parts
251926808704	SPRING GEAR SHIFT LEVER	TATA spare parts
251926808707	SPRING GEAR SHIFT LEVER	TATA spare parts
251926808708	PIN SHIFTING YOKE	TATA spare parts
251926809922	GEAR SHIFT LEVER LOWER	TATA spare parts
251926809936	GEAR SHIFT LEVER LOWER	TATA spare parts
2519N6000101	KIT G/BOX GASKET GBS 16	TATA spare parts
252001150106	ASSY CYLINDER HEAD COVER	TATA spare parts
252001153401	VALVE SEAT RING INLET	TATA spare parts
252001157701	SEALING RING	TATA spare parts
252001158401	PROTECTIVE SLEEVE	TATA spare parts
252001165301	GASKET INJECTION NOZZLE	TATA spare parts
252001168001	PRESSURE LOCK	TATA spare parts
252005153401	VALVE GUIDE INLET STD	TATA spare parts
252005153402	VALVE GUIDE INLET STD-1	TATA spare parts
252005153404	VALVE GUIDE INLET RS2	TATA spare parts
252005153405	VALVE GUIDE EXHAUST STD	TATA spare parts
252005153406	VALVE GUIDE EXHAUST STD1	TATA spare parts
252005153407	VALVE GUIDE EXHAUST RS1	TATA spare parts
252007130101	DRIVE GEAR ASSY	TATA spare parts
252007140101	SET FUEL PR LINES	TATA spare parts
252007140103	PRESSURE LINE 1ST	TATA spare parts
252007140104	PRESSURE LINE 2ND	TATA spare parts
252007140105	PRESSURE LINE 3RD	TATA spare parts
252007140106	PRESSURE LINE 4TH	TATA spare parts



252007140107	PRESSURE LINE 5TH	TATA spare parts
252007140108	PRESSURE LINE 6TH	TATA spare parts
252007140111	LEAKAGE FUEL LINE DI	TATA spare parts
252007144203	SEAL CAMP	TATA spare parts
252007148001	PIPE UNION BOLT	TATA spare parts
252015130101	GENERATOR W/PULLEY 160W	TATA spare parts
252018130106	SPRING RETAINER	TATA spare parts
252018130113	SPRING RETAINER	TATA spare parts
252018135301	GASKET OIL FILTER	TATA spare parts
252018137201	SCREW PLUG	TATA spare parts
252018137203	SEALING PLUG	TATA spare parts
252018137701	SEALING RING	TATA spare parts
252018137702	OIL SEAL	TATA spare parts
252018137703	SEALING RING	TATA spare parts
252018138701	SPRING PR RELIEF VALVE	TATA spare parts
252018139001	PLUNGER PR RELIEF VALVE	TATA spare parts
252020100101	ASSY WATER PUMP	TATA spare parts
252020100501	WATER PUMP HOUSING	TATA spare parts
252020109901	IMPELLER WATER PUMP	TATA spare parts
252020120101	ASSY WATER COOLING LINE UP	TATA spare parts
252020125001	FLANGE	TATA spare parts
252020125301	GASKET	TATA spare parts
252020147003	PULLEY WATER PUMP CAST DI	TATA spare parts
2520381250	CON ROD BUSH NORMAL I	TATA spare parts
252101153806	ELBOW AIR INTAKE	TATA spare parts
252101153807	COVER CYLINDER HEAD	TATA spare parts
252101155305	GASKET	TATA spare parts
252101155306	GASKET AIR INTAKE ELBOW	TATA spare parts
252103110102	ASSY FLYWHEEL W/RING GEAR	TATA spare parts
252103110103	FLYWHEEL W/RING GEAR	TATA spare parts
252107108701	RELEASE SPRING	TATA spare parts
252107140110	SET FUEL PR LINES	TATA spare parts
252109120101	OVERELOW LINE	TATA spare parts
252109130102	AIR FILTER ASSY	TATA spare parts
252109137501	RUBBER GROMMET	TATA spare parts
252114110101	EXHAUST MANIFOLD W/STUD	TATA spare parts
252114113707	EXHAUST MANIFOLD	TATA spare parts
252114113708	EXHAUST MANIFOLD	TATA spare parts
252118100102	OIL PUMP STRAINER	TATA spare parts
252118170101	OIL COOLER ASSY	TATA spare parts
252118170102	OIL COOLER ASSY	TATA spare parts
252118173701	OIL COOLER ASSY	TATA spare parts
252118173703	COVER OIL COOLER	TATA spare parts
252118175301	GASKET (COVER ON OIL COOLER)	TATA spare parts
252118175302	GASKET O/COOLER-CYL BLOCK	TATA spare parts
252118177201	SEALING PLUG	TATA spare parts
252118177701	PLUNGER BYPASS VALVE	TATA spare parts

252120120102	UPP.COOL.WATER LINE	TATA spare parts
252122125101	ENGINE SUPPORT FRT LH	TATA spare parts
252122125102	ENGINE SUPPORT FRT RH	TATA spare parts
252125103701	CLUTCH HSG.280D	TATA spare parts
252201130101	OIL SUMP ASSY	TATA spare parts
252201139901	DIPSTICK	TATA spare parts
252203138601	SPACER VIB DAMPER	TATA spare parts
252218130101	OIL FILTER ASSY	TATA spare parts
252218130103	HOUSING OIL FILTER	TATA spare parts
252218133201	CENTRE PIN	TATA spare parts
252220159901	V BELT	TATA spare parts
252301000044	HALF ENG SCAM G30 LOWRHD	TATA spare parts
252301000229	HALF ENG 692 LP RHD	TATA spare parts
252301000235	HALF ENG 692 G40 310D RHD	TATA spare parts
252301000243	SHORT BLOCK	TATA spare parts
252301000327	ASY.ENG.COMPL.CR50334/1-L	TATA spare parts
252301000366	ENGD03RCPFCTW DRATED310RH	TATA spare parts
252301000390	HALF ENG 692 G30 C/TI	TATA spare parts
252301000391	HALF ENG 692 G40 C/TI RHD	TATA spare parts
252301000392	ENG.692DI280DIA CL.GBC30	TATA spare parts
252301000488	HALF ENG 692 G40 LOW SCAM	TATA spare parts
252301100119	CAP MAIN BRG IV	TATA spare parts
252301100126	CAP MAIN BRG REAR	TATA spare parts
252301100128	CYL.BLOCK W/O CL HSG.	TATA spare parts
252301100165	BRG.CAP MAIN NO-4	TATA spare parts
252301100170	CYLINDER BLOCK LINERED	TATA spare parts
252301100189	ASSY.CYL.BLOCK W/O CLUTCH	TATA spare parts
252301100199	CYLINDER BLOCK LINERED	TATA spare parts
252301100205	CYLINDER BLOCK LOW ENG	TATA spare parts
252301100216	ASY.CYL.BLOCK W/O CLU.HSG	TATA spare parts
252301100232	CYLINDER BLOCK LINERED	TATA spare parts
252301100235	ASY.CYL.BLOCK W.CLUTCH HO	TATA spare parts
252301100258	CYLINDER BLOCK LINERED	TATA spare parts
252301103201	BOLT MAIN BEARING CAP	TATA spare parts
252301103722	LINER CYLINDER	TATA spare parts
252301107201	SEALING PLUG	TATA spare parts
252301130101	OIL SUMP ASSY	TATA spare parts
252301130102	OIL SUMP ASSY SFC	TATA spare parts
252301130107	DRAIN PLUG MAGNETIC	TATA spare parts
252301130112	OIL SUMP ASSY	TATA spare parts
252301130113	COMBI SCREW M8 X 20	TATA spare parts
252301130114	ASSY COMBI SCREW	TATA spare parts
252301130117	OIL SUMP ASSY	TATA spare parts
252301133702	RETAINING FLANGE ON OIL SUMP	TATA spare parts
252301133703	FLANGE OIL SUMP DIPSTICK	TATA spare parts
252301135102	FLANGE OIL SUMP	TATA spare parts
252301140117	COVER PUSH ROD	TATA spare parts

252301140119	COMBI SCREW	TATA spare parts
252301140121	ASSY TGH WITH BOTTOM COVER CYL PIN&STDUS	TATA spare parts
252301144701	COVER	TATA spare parts
252301150106	COVER CYLINDER HEAD	TATA spare parts
252301150112	ASSY CYL HEAD COVER CR-50831	TATA spare parts
252301150114	ASSY AIR INTAKE ELBOW SFC	TATA spare parts
252301150124	ELBOW AIR INTAKE	TATA spare parts
252301150129	COVER CYLINDER HEAD	TATA spare parts
252301150130	COVER CYLINDER HEAD	TATA spare parts
252301150132	COVER CYLINDER HEAD	TATA spare parts
252301150136	CYLINDER HEAD W/VALVES	TATA spare parts
252301150150	ASSY.CYL.HEAD COVER	TATA spare parts
252301150152	ASSY.CYL.HEAD COVER WITH	TATA spare parts
252301150154	KIT VALVE SEAT STD	TATA spare parts
252301150168	CYLINDER HEAD W/O VALVES	TATA spare parts
252301150169	CYLINDER HEAD W/VALVES	TATA spare parts
252301153401	VALVE SEAT INLET STD	TATA spare parts
252301153402	VALVE SEAT EXHAUST STD	TATA spare parts
252301153403	VALVE SEAT INLET STDI	TATA spare parts
252301153404	VALVE SEAT EXHAUST STD1	TATA spare parts
252301153405	VALVE SEAT INLET RS1	TATA spare parts
252301153406	VALVE SEAT EXHAUST RS1	TATA spare parts
252301153411	VALVE SEAT INLET RS2	TATA spare parts
252301153412	VALVE SEAT EXHAUST RS2	TATA spare parts
252301153416	VALVE SEAT INLET STD	TATA spare parts
252301153816	COVER CYLINDER HEAD	TATA spare parts
252301155301	GASKET CYLINDER HEAD	TATA spare parts
252301155302	GASKET CYLINDER HEAD	TATA spare parts
252301155303	GASKET CYLINDER HEAD	TATA spare parts
252301155304	GASKET CYLINDER HEAD	TATA spare parts
252301155307	GASKET CYL HEAD COVER	TATA spare parts
252301155310	CYLINDER HEAD GASKET SS	TATA spare parts
252301160101	INJ NOZZLE W/HOLDER	TATA spare parts
252301160106	NOZZLE HOLDER WITH NOZZLE	TATA spare parts
252301160107	ASSY NOZZLE HOLDER WITH NOZZLE	TATA spare parts
252301170115	TUBE DIPSTICK	TATA spare parts
252301170122	BREATHER BS1/2/3/4	TATA spare parts
252301170123	CAP	TATA spare parts
252301170151	DIPSTICK	TATA spare parts
252301170155	COVER TGH TOP W/POINTER	TATA spare parts
252301170156	ASSY TUBE DIPSTICK	TATA spare parts
252301170161	PIPE OIL FILLER	TATA spare parts
252301170162	CAP OIL FILLER	TATA spare parts
252301170165	TUBE DIPSTICK	TATA spare parts
252301170174	CAP OIL FILLER	TATA spare parts
252301170176	PIPE OIL FILLER	TATA spare parts
252301170184	DIPSTICK	TATA spare parts

252301170194	ASSY TUBE DIPSTICK W/O NUT & SLIP RING	TATA spare parts
252301170196	ASSY OIL SEPARATOR	TATA spare parts
252301170199	OIL FILLER	TATA spare parts
252301170203	DIPSTICK	TATA spare parts
252301170205	TUBE DIPSTICK	TATA spare parts
252301170208	OIL DIPSTICK ASSY	TATA spare parts
252301170211	TUBE DIPSTICK W/BKT	TATA spare parts
252301170212	DIPSTICK	TATA spare parts
252301173309	BRACKET DIPSTICK	TATA spare parts
252301174201	CLAMP HOSE TO T G HSG	TATA spare parts
252301174216	CLAMP LOWER	TATA spare parts
252301174217	CLAMP UPPER	TATA spare parts
252301174218	CLAMP FOR DIPSTICK TUBE.	TATA spare parts
252301174219	CLAMP LOWER	TATA spare parts
252301175801	HOSE	TATA spare parts
252301175804	WRONG PART NUMBER	TATA spare parts
252301175809	TUBE 325 MM	TATA spare parts
252301175811	TUBE 350 MM	TATA spare parts
252301175814	TUBE 275 MM	TATA spare parts
252301176928	FINOLEX TUBE	TATA spare parts
252301176937	TUBE	TATA spare parts
252301176941	TUBE	TATA spare parts
252301177202	PLUG	TATA spare parts
252301177702	RUBBER RING	TATA spare parts
252301178501	DOUBLE SOCKET	TATA spare parts
252301600068	HALF ENG 692 G30 RHD	TATA spare parts
252301600074	ASY.ENGINE COMP.WITH CLUTCH	TATA spare parts
252301610003	ASSY.692DI LINERED ENG.COM	TATA spare parts
252301610032	ENG 692DI RHD LP G30 310D	TATA spare parts
252301610097	692DI/G30/LPT/RSV/LN/FR/	TATA spare parts
252301620003	ENG.692DI/LP-LPO/G40/DR	TATA spare parts
252301620018	ENGINE ASSY 692 DI	TATA spare parts
252301620021	692 ENG/SFC/G40/RQV/NL/FR	TATA spare parts
252301620044	HALF ENG 692 LINERE	TATA spare parts
252301620084	ENGINE 692DI 310 G40 LIN	TATA spare parts
252301630018	ASSY ENGINE 692 D23	TATA spare parts
252301630073	HALF ENG EXH BRK G40	TATA spare parts
252301630074	HALF ENG G30 EXH BR LOW	TATA spare parts
252301640012	ENGINE 692DI RSV 310 G30	TATA spare parts
252301640013	ENGINE ASSY 692DI RHD SFC	TATA spare parts
252301640032	ASSY ENGINE COMP 692DI LOWERED 310DIA CL	TATA spare parts
252301640056	ASY.ENG.COMP.W.280D W.EXH	TATA spare parts
252301650045	HALF ENG 692 LOWERE	TATA spare parts
252303100103	CR SHAFT W/BEARING	TATA spare parts
252303100104	CRANKSHAFT STD W/CWT	TATA spare parts
252303100107	STD ASSY CR SH FUL/CIRCWT	TATA spare parts
252303100126	ASSY.CR.SFT W.CWT.N DI/PC1	TATA spare parts

252303103101	BEARING BALL DEEP GROOVE	TATA spare parts
252303103102	BEARING BALL	TATA spare parts
252303103103	BALL BEARING	TATA spare parts
252303103202	BOLT COUNTER WEIGHT	TATA spare parts
252303107802	RING SEALING HALF	TATA spare parts
252303110102	FLYWHEEL W/RING GEAR	TATA spare parts
252303110103	FLY WHEEL W/RING GEAR	TATA spare parts
252303110104	FLYWHEEL W/RING GEAR 310DCL. BS2	TATA spare parts
252303110105	FLYWHEEL W/RING GEAR 280D	TATA spare parts
252303110106	FLYWHEEL W/RING GEAR	TATA spare parts
252303120101	SET MAIN BRG W/THW STD	TATA spare parts
252303120102	SET MAIN BRG STD1	TATA spare parts
252303120103	SET MAIN BRG RS1	TATA spare parts
252303120104	SET MAIN BRG RS2	TATA spare parts
252303120105	SET MAIN BRG RS3	TATA spare parts
252303120106	SET MAIN BRG RS4	TATA spare parts
252303120107	SET THRUST WASHER STD	TATA spare parts
252303120108	SET THRUST WASHER STD1	TATA spare parts
252303120109	SET THRUST WASHER STD2	TATA spare parts
252303120122	SET MAIN BRG W/O THW STD	TATA spare parts
252303120123	SET MAIN BRG W/O THW STD1	TATA spare parts
252303120124	SET MAIN BRG W/O THW RS1	TATA spare parts
252303120125	SET MAIN BRG W/O THW RS2	TATA spare parts
252303120126	SET MAIN BRG W/O THW RS3	TATA spare parts
252303120127	SET MAIN BRG W/O THW RS4	TATA spare parts
252303123102	SET MAIN BEARING HALF U/L NORMAL I	TATA spare parts
252303123415	THRUST WASHER UPP STD	TATA spare parts
252303123416	THRUST WASHER LOW STD	TATA spare parts
252303123470	THRUST WASHER LOW STD	TATA spare parts
252303123474	THRUST WASHER UPP STD	TATA spare parts
252303130102	ASSY VIBRATION DAMPER	TATA spare parts
252303130112	VIBRATION DAMPER	TATA spare parts
252303130114	VIBRATION DAMPER	TATA spare parts
252303130119	VIBRATION DAMPER	TATA spare parts
252303133202	LOCK VIBRATION DAMPER BS4	TATA spare parts
252303137006	PULLEY CRANKSHAFT	TATA spare parts
252303138201	INDICATOR TIMER	TATA spare parts
252303138601	THRUST SPACER	TATA spare parts
252303138603	THRUST SPACER	TATA spare parts
252303140114	PISTON STD1 D1	TATA spare parts
252303140116	PISTON RS1	TATA spare parts
252303140117	PISTON RS2	TATA spare parts
252303140134	ASY.PISTON STD I92.01DIA.	TATA spare parts
252303140138	PISTON RS1	TATA spare parts
252303140141	PISTON STD 91.89D	TATA spare parts
252303140143	PISTON W/RINGS STD 91.91D	TATA spare parts
252303140151	PISTON W/RINGS 92 N-1 4RV	TATA spare parts

252303140184	PISTON ASSY	TATA spare parts
252303140186	BARE PISTON SET STD 692 4RV	TATA spare parts
252303140187	SET PISTON BARE STD-I 692 4RV	TATA spare parts
252303140188	SET PISTON BARE STD-II 692 4RV	TATA spare parts
252303140189	BARE PISTON SET RS-I 692 4RV	TATA spare parts
252303140190	SET PISTON BARE RS-II 692 4RV	TATA spare parts
252303141038	PISTON BARE 91.92	TATA spare parts
252303141039	BARE PISTON 91.93	TATA spare parts
252303141040	BARE PISTON 91.94	TATA spare parts
252303141041	R C PISTON STD 91.95 DIA	TATA spare parts
252303141044	PISTON STD 91.98D R/CARR.	TATA spare parts
252303141053	BARE PISTON 92 RS1 4 RVRC	TATA spare parts
252303141055	BARE PISTON 92 RS2 4 RVRC	TATA spare parts
252303146703	PIN PISTON	TATA spare parts
252303146706	PIN PISTON	TATA spare parts
252303149945	OIL RING STD I/2 CHROME	TATA spare parts
252303149946	OIL RING 4 RV SHIM RS1	TATA spare parts
252303149947	RING OIL RS2 GR2	TATA spare parts
252303149968	2ND RING 92 SH/RC 3RV/4RV	TATA spare parts
252303149974	3RD RING 92 SH/RC 4RV STD	TATA spare parts
252303149988	RING TOP RS1	TATA spare parts
252303149989	RING TOP RS2	TATA spare parts
252303150104	CONNECTING ROD SE RC PIST	TATA spare parts
252303150106	ASSY.CON.ROD W/O BRG.SHELLS	TATA spare parts
252303150107	CONNECTING ROD W/O BRG	TATA spare parts
252303150120	CONNECTING ROD W/O BRG	TATA spare parts
252303150122	CONNECTING ROD W/O BRG	TATA spare parts
252303153404	BUSH CON ROD STD	TATA spare parts
252303153405	BUSH CON ROD RS1	TATA spare parts
252303153406	BUSH CON ROD STD	TATA spare parts
252303153407	BUSH CON ROD RS1	TATA spare parts
252303153423	BUSH CON ROD STD	TATA spare parts
252303160110	SHIM PISTON STD	TATA spare parts
252303160193	SET PISTON RINGS STD 4RV	TATA spare parts
252303160194	SET PISTON RINGS STD1 4RV	TATA spare parts
252303160195	SET PISTON RINGS RS1 4RV	TATA spare parts
252303160196	SET PISTON RINGS RS2 4RV	TATA spare parts
252303160197	RING OIL GR3 3RV	TATA spare parts
252303160202	ASSY.PISTON-STD 91.88 O	TATA spare parts
252303160218	PISTON W/RINGS STD 91.88D	TATA spare parts
252303160223	PISTON SET W/RINGS 692DI	TATA spare parts
252303160263	SET PISTON BARE STD	TATA spare parts
252303160266	SET PISTON BARE STD2	TATA spare parts
252303160267	SET PISTON BARE STD2	TATA spare parts
252303160268	SET PISTON RINGS STD 3RV	TATA spare parts
252303160269	SET PISTON RINGS STD1 3RV	TATA spare parts
252303160270	SET PISTON RINGS RS1 3RV	TATA spare parts

252303160271	SET PISTON RINGS RS2 3RV	TATA spare parts
252303161032	PISTON STD	TATA spare parts
252303161055	PISTON 4 RV	TATA spare parts
252303161056	PISTON	TATA spare parts
252303166702	PIN PISTON	TATA spare parts
252303166703	PIN PISTON	TATA spare parts
252303169910	COMP.RING GROOVE II	TATA spare parts
252303169911	COMPRESSOR RING GROOVE II	TATA spare parts
252303169916	SCRAPER RING GROOVE III	TATA spare parts
252303169926	RING OIL STD	TATA spare parts
252303169927	CHROME PLATED OIL RING	TATA spare parts
252303169931	RING COMP STD GR1	TATA spare parts
252303169932	RING OIL STD1/2	TATA spare parts
252303169978	COMP RING II	TATA spare parts
252303169982	TOP RING 92 DIA 3 RV IP	TATA spare parts
252303169983	2ND RING 92 DIA 3 RV IP	TATA spare parts
252303170235	OIL RING 92 DIA 4 RV RC	TATA spare parts
252303170249	RING OIL CONF.GR4	TATA spare parts
252303170250	OIL RING 92 DIA 3 RV GOE	TATA spare parts
252303171004	PISTON STD 91.89D	TATA spare parts
252303171006	PISTON STD 91.91D	TATA spare parts
252303171007	PISTON STD 692DI	TATA spare parts
252303171025	PISTON BARE 91.89D IP	TATA spare parts
252303171026	PISTON BARE 91.90D 3RV	TATA spare parts
252303171049	PISTON BARE 91.89D	TATA spare parts
252303171050	PISTON BARE 91.90D	TATA spare parts
252303171080	PISTON BARE 692 3RV	TATA spare parts
252303179910	RING TOP 692DI	TATA spare parts
252303200101	CRANKSHAFT STD W/CWT	TATA spare parts
252303200103	CRANKSHAFT STD W/CWT	TATA spare parts
252303200108	CRANKSHAFT RS1 W/CWT	TATA spare parts
252303205107	CRANKSHAFT STD 692	TATA spare parts
252305100102	CAMSHAFT W/CYL PIN STD	TATA spare parts
252305100103	CAMSHAFT W/CYL PIN STD1	TATA spare parts
252305100104	CAMSHAFT W/CYL PIN STD	TATA spare parts
252305100105	CAMSHAFT W/CYL PIN STD1	TATA spare parts
252305100108	INJECTOR TIMER ASSY	TATA spare parts
252305100109	GEAR CAMSHAFT	TATA spare parts
252305105901	PARALLEL KEY	TATA spare parts
252305107915	CAM SHAFT NORMAL-S-CAM	TATA spare parts
252305108601	THRUST SPACER	TATA spare parts
252305113101	BUSH CAMSHAFT	TATA spare parts
252305113702	GEAR CRANKSHAFT	TATA spare parts
252305115401	GEAR FIP DRIVE	TATA spare parts
252305115402	GEAR CAMSHAFT	TATA spare parts
252305120104	KIT VALVE	TATA spare parts
252305120105	KIT VALVE	TATA spare parts

252305129008	VALVE INLET	TATA spare parts
252305130101	LOCK HALF KIT	TATA spare parts
252305130102	VALVE SPRING KIT	TATA spare parts
252305140101	SHAFT ROCKER ARM W/RA	TATA spare parts
252305140102	ASSY R/ARM SHAFT&R/ARM FR	TATA spare parts
252305140103	ASSY R/ARM SFT & R/ARM RR	TATA spare parts
252305140104	ASSY ROCKERARM LEFT WITH BALLPIN BS6	TATA spare parts
252305140105	ASSY ROCKER ARM RIGHT WITH BALL PIN BS6-	TATA spare parts
252305140107	KIT-FOR RA BUSH	TATA spare parts
252305140109	KIT-ROCKER ARM	TATA spare parts
252305146701	BALL PIN TAPPET ADJUSTER	TATA spare parts
252305150101	KIT VALVE GUIDE STD	TATA spare parts
252305153405	VALVE GUIDE EXHAUST STD	TATA spare parts
252305159008	INLET VALVE	TATA spare parts
252305167901	PUSH ROD	TATA spare parts
252305167902	PUSH ROD	TATA spare parts
252305177701	CONNECTING NIPPIE OUTER	TATA spare parts
252305177702	CONNECTING NIPPLE INSIDE	TATA spare parts
252305990101	KIT CAMSHAFT	TATA spare parts
252307100109	CONTROL SHAFT W/LEVER	TATA spare parts
252307100111	LEVER ASSY W/BALL PIN	TATA spare parts
252307100121	ANCHOR PIN WITH HOLE	TATA spare parts
252307100122	LEVER ASSY LP LHD	TATA spare parts
252307100123	LEVER W/BALL PIN LP LHD	TATA spare parts
252307100138	LEVER ASSY	TATA spare parts
252307100164	ANCHOR PIN W/HOLE	TATA spare parts
252307100175	PULL ROD ASSY	TATA spare parts
252307100224	LEVER ASSY RQV RHD	TATA spare parts
252307100225	CONTROL SHAFT W/LEVER RHD	TATA spare parts
252307100228	LEVER FOR AIR CYLINDER	TATA spare parts
252307100241	RSV FIP W 9.5D PLUNGER CR	TATA spare parts
252307100269	LEVER ASSY RSV	TATA spare parts
252307100273	FUEL INJ.PUMP RSV632E1870	TATA spare parts
252307103305	BRACKET	TATA spare parts
252307103309	BRACKET - FIP LINKAGE-LP1510 RSV TYPE	TATA spare parts
252307105401	GEAR FUEL INJ PUMP	TATA spare parts
252307107106	LEVER STOPPER	TATA spare parts
252307108605	SLEEVE	TATA spare parts
252307110107	BRACKET AIR CYLINDER	TATA spare parts
252307110108	ASSY. BRKT IDLING UNIT	TATA spare parts
252307116702	PIVOT PIN AIR CYLINDER	TATA spare parts
252307118001	COLLAR SCREW	TATA spare parts
252307119204	SPACER	TATA spare parts
252307123701	SUPPORT FUEL INJ PUMP	TATA spare parts
252307125301	GASKET	TATA spare parts
252307128801	STUD	TATA spare parts
252307140101	SET FUEL PR LINES	TATA spare parts



252307140102	PRESSURE LINE 1ST	TATA spare parts
252307140103	PRESSURE LINE 2ND	TATA spare parts
252307140104	PRESSURE LINE 3RD	TATA spare parts
252307140105	PRESSURE LINE 4TH	TATA spare parts
252307140106	PRESSURE LINE 5TH	TATA spare parts
252307140107	PRESSURE LINE 6TH	TATA spare parts
252307140111	PRESSURE LINE 1ST	TATA spare parts
252307140112	PRESSURE LINE 2ND	TATA spare parts
252307140113	PRESSURE LINE 3RD	TATA spare parts
252307140114	PRESSURE LINE 4TH	TATA spare parts
252307140115	PRESSURE LINE 5TH	TATA spare parts
252307140116	PRESSURE LINE 6TH	TATA spare parts
252307140117	SET OF FUEL PRESS PIPE	TATA spare parts
252307140118	SET FUEL PR LINES	TATA spare parts
252307140119	PRESSURE LINE 1ST	TATA spare parts
252307140120	PRESSURE LINE 2ND	TATA spare parts
252307140121	PRESSURE LINE 3RD	TATA spare parts
252307140122	PRESSURE LINE 4TH	TATA spare parts
252307140123	PRESSURE LINE 5TH	TATA spare parts
252307140124	PRESSURE LINE 6TH	TATA spare parts
252307140125	SET FUEL PR LINES	TATA spare parts
252307140132	SET FUEL PR LINES	TATA spare parts
252307140136	PRESS. LINE 4TH CYL.	TATA spare parts
252307140137	PRESS LINE 5TH CYL.	TATA spare parts
252307140138	PRESS LILNE 6TH CYL.	TATA spare parts
252307150104	KIT COLD START PILOT	TATA spare parts
252307150104AE	COLD START PILOT KIT-1415	TATA spare parts
252309110102	BRACKET FUEL FILTER	TATA spare parts
252309110103	OVER FLOW VALVE ASSY	TATA spare parts
252309110109	BKT FUEL FILTER W/HOOK	TATA spare parts
252309113304	STAY ROD	TATA spare parts
252309113701	BKT DOUBLE FUEL FILTER	TATA spare parts
252309120101	OVERFLOW LINE WITH EJECTR	TATA spare parts
252309120106	OVER FLOW LINE W/EJECTOR	TATA spare parts
252309120119	FUEL OVERFLOW LINE	TATA spare parts
252309120120	FUEL PIPE FEEDPUMP-FILTER	TATA spare parts
252309120126	ASSY FUEL LINE FILTER TO FIP	TATA spare parts
252309120127	FUEL PIPE	TATA spare parts
252309123301	BRACKET OVER FLOW LINE	TATA spare parts
252309126801	EJECTOR	TATA spare parts
252309130106	AIR FILTER ASSY OIL BATH 70 DIA	TATA spare parts
252309130112	A/FILTER ELEMENT DRY TYPE	TATA spare parts
252309130117	A/FILTER ELEMENT DRY TYPE	TATA spare parts
252309130132	SERVICE INDICATOR ASSY	TATA spare parts
252309130138	FILTER ELEMENT-DRY	TATA spare parts
252309130139	FILTER ELEMENT-DRY	TATA spare parts
252309130141	SERVICE INDICATOR	TATA spare parts

252309130157	PIN HANDLE	TATA spare parts
252309130162	AIR FILTER ASSY OIL BATH	TATA spare parts
252309130164	ASSY SUPPORT FOR BRACKET	TATA spare parts
252309130168	PRECLEANER ASSY	TATA spare parts
252309130170	PIPE AIR INLET	TATA spare parts
252309130171	PIPE AIR INLET	TATA spare parts
252309130188	PRECLEANER ASSY	TATA spare parts
252309130191	AIR FILTER ASSY OIL BATH 80 DIA	TATA spare parts
252309130195	CLAMP ASSY	TATA spare parts
252309130203	AIR FILTER ASSY OIL BATH	TATA spare parts
252309130204	AIR FILTER ASSY OIL BATH	TATA spare parts
252309130210	ASSY AIR INT.SCOOP(S/METL	TATA spare parts
252309130212	TUBE W/BRACKET	TATA spare parts
252309130218	ASSY AIR FILTER WITH SERVICE INDICATOR	TATA spare parts
252309130222	ASSY FILTER ELEMENT SECONDARY 8M3	TATA spare parts
252309130223	SAFETY CARTRIDGE 8M3	TATA spare parts
252309130246	ASSY AIR FILTER	TATA spare parts
252309130247	ASSY.STRAP WITH SHACKLE COMPLETE	TATA spare parts
252309130255	BEND PIPE PLASTIC RHD	TATA spare parts
252309130256	PIPE AIR INLET	TATA spare parts
252309133309	BRACKET-ZP	TATA spare parts
252309134204	TOGGLE CLAMP	TATA spare parts
252309134205	PIPE CLAMP	TATA spare parts
252309134210	CLAMP	TATA spare parts
252309135807	RUBBER BELOW 610	TATA spare parts
252309135810	RUBBER HOSE AIR INTAKE	TATA spare parts
252309135812	RUBBER HOSE	TATA spare parts
252309135822	HOSE AIR INTAKE	TATA spare parts
252309135826	HOSE P-200/87	TATA spare parts
252309136316	RUBBER BELLOW	TATA spare parts
252309136930	TUBE AIR INLET	TATA spare parts
252309137701	RUBBER SLEEVE	TATA spare parts
252309137715	RUBBER SLEEVE	TATA spare parts
252309137718	RUBBER SEAL	TATA spare parts
252309137719	RUBBER SLEEVE	TATA spare parts
252309137720	RUBBER SLEEVE	TATA spare parts
252309137721	RUBBER PACKING	TATA spare parts
252309138503	CONNECTOR	TATA spare parts
252313100101	KIT AIR COMP CYL HEAD	TATA spare parts
252313100102	CYL HEAD AIR COMP 77D	TATA spare parts
252313103702	CYLINDER SLEEVE/SEMIFINSH	TATA spare parts
252313103704	CYL SLEEVE N2	TATA spare parts
252313103710	CYL SLEEVE A/C STD 70D	TATA spare parts
252313103711	CYLINDER SLEEVE NORMAL I	TATA spare parts
252313103712	CYL SLEEVE A/C STD2 70D	TATA spare parts
252313103717	CYL HEAD AIR COMP 77D	TATA spare parts
252313105301	GASKET SLV TO HEAD 70D	TATA spare parts

252313105302	CYL HEAD AIR COMP 77D	TATA spare parts
252313130103	ELBOW PIPE	TATA spare parts
252313130104	ELBOW PIPE	TATA spare parts
252313130105	ELBOW PIPE AIR COMP	TATA spare parts
252313130106	ASSY PIPE	TATA spare parts
252313130107	ASSY TUBE-RUBBER HOSE TO AIR COMP.	TATA spare parts
252313135801	RUB HOSE COVER CYL HD-A/C	TATA spare parts
252313138203	PLATE	TATA spare parts
252313140113	A.C.PISTON 69.97	TATA spare parts
252313140114	PISTON AIR COMP STD	TATA spare parts
252313140116	PISTON AIR COMP STD1	TATA spare parts
252313140119	PISTON AIR COMP STD2	TATA spare parts
252313140124	ASSY.PISTON NORMAL	TATA spare parts
252313140125	PISTON W/RING NORMAL 70 DIA ALUMINIUM	TATA spare parts
252313140126	ASSY PISTON AIR COMPRESSOR	TATA spare parts
252313140127	SET AC PISTON RING STD 70	TATA spare parts
252313140128	SET PISTON RING STD1&2 70	TATA spare parts
252313140130	PISTON ASSY.STD	TATA spare parts
252313140131	PISTON AIR COMP STD 69.93	TATA spare parts
252313140132	ASSY PISTON NORMAL A/C AL 69.94 DIA	TATA spare parts
252313140134	PISTON W/RING N1	TATA spare parts
252313140140	PISTON W/RING NORMAL-I 70 DIA ALUMINIUM	TATA spare parts
252313140143	PISTON W/RING NORMAL-II 70 DIA ALUMINIUM	TATA spare parts
252313140145	PISTON AL W/O RING STD	TATA spare parts
252313140146	PISTON AL W/O RING STD1	TATA spare parts
252313140147	PISTON AL W/O RING STD2	TATA spare parts
252313140148	PISTON AL W/O RING STD	TATA spare parts
252313141019	PISTON A/C AL 69.93	TATA spare parts
252313141020	A C PISTON 69.94 DIA	TATA spare parts
252313146701	PISTON PIN	TATA spare parts
252313149908	COMPRESSION RING	TATA spare parts
252313149914	SCRAPPER RING STD	TATA spare parts
252313149934	COMP RING GR 1&2 STD	TATA spare parts
252313149937	NOSE SCRAPER RING STD	TATA spare parts
252313149940	OIL RING GR4 STD	TATA spare parts
252313158201	VALVE DISC	TATA spare parts
252314110103	EXHAUST MANIFOLD	TATA spare parts
252314110107	EXHAUST MANIFOLD W/BUSH	TATA spare parts
252314110108	EXHAUST MANIFOLD W/BUSH	TATA spare parts
252314110112	ASSY.THROTTLE VALVE	TATA spare parts
252314110115	EXHAUST MANIFOLD W/TVALVE	TATA spare parts
252314110122	ASSY.EXH.MANIFOLD.W/THROTTLE VAL.RHD	TATA spare parts
252314110123	EXHAUST MANIFOLD W/BUSH	TATA spare parts
252314113701	EXHAUST MANIFOLD	TATA spare parts
252314113702	EXHAUSTE MANIFOLD	TATA spare parts
252314113705	EXHAUST MANIFOLD	TATA spare parts
252314113706	EXHAUST MANIFOLD	TATA spare parts

252314113710	EXHAUST MANIFOLD	TATA spare parts
252314113714	EXHAUST MANIFOLD LHD	TATA spare parts
252314113715	EXH MANIFOLD 50 MM OFFSET	TATA spare parts
252314115102	THROTTLE VALVE W/HOLE	TATA spare parts
252314115103	THROTTLE VALVE W/HOLE	TATA spare parts
252314130108	LEVER PLATE	TATA spare parts
252314130110	LEVER W/ BALL PIN	TATA spare parts
252314130112	LEVER W/BALL PIN	TATA spare parts
252314130122	SHAFT THROTTLE VALVE	TATA spare parts
252314130123	THROTTLE VALVE	TATA spare parts
252314130164	ASSY THROTTLE VALVE	TATA spare parts
252314133201	HEX COLLAR SCREW	TATA spare parts
252314133701	THROTTLE VALVE	TATA spare parts
252314137102	STOPPER PLATE	TATA spare parts
252314137106	STOPPER PLATE	TATA spare parts
252314137109	STOPPER PLATE	TATA spare parts
252315103701	INTERMEDIATE FLANGE	TATA spare parts
252315103703	INTERMEDIATE FLANGE	TATA spare parts
252315103704	INTERMEDIATE FLANGE	TATA spare parts
252315130101	PULLEY 300W GENERATOR	TATA spare parts
252315137001	PULLEY 160W GENERATOR	TATA spare parts
252315140109	BRACKET ALTERNATOR	TATA spare parts
252315140116	BRACKET ASSY	TATA spare parts
252318100101	OIL PUMP W/RELIEF VALVE	TATA spare parts
252318100106	ASSY OIL PUMP COVER	TATA spare parts
252318100107	OIL PUMP W/O STRAINER	TATA spare parts
252318100110	OIL PUMP ASSY	TATA spare parts
252318100111	KIT OIL PUMP GEAR	TATA spare parts
252318100118	ASSY OILPUMP COMPLETE	TATA spare parts
252318100123	GEAR SET FOR OIL PUMP	TATA spare parts
252318100124	KIT OIL PUMP RELIEF VALVE	TATA spare parts
252318100141	OIL FILTER ASSY	TATA spare parts
252318105401	OIL PUMP GEAR DRIVE SHAFT	TATA spare parts
252318105402	OIL PUMP GEAR	TATA spare parts
252318105409	GEAR OIL PUMP	TATA spare parts
252318105410	GEAR OIL PUMP	TATA spare parts
252318106501	CAP NUT MODIFIED	TATA spare parts
252318107201	PLUG OIL PUMP REL VALVE	TATA spare parts
252318107901	SHAFT OILPUMP DRIVEN GEAR	TATA spare parts
252318107908	DRIVE SHAFT OIL PUMP	TATA spare parts
252318130101	OIL FILTER ASSY	TATA spare parts
252318130102	COVER ASSY OIL FILTER	TATA spare parts
252318130108	OIL FILTER CARTRIDGE-SINGLE LIFE	TATA spare parts
252318130109	OIL FILTER CARTRIDGE-SINGLE LIFE	TATA spare parts
252318130110	OIL FILTER CARTRIDGE-SINGLE LIFE	TATA spare parts
252318130113	SPRING RETAINER	TATA spare parts
252318130114	OIL FILTER ASSY	TATA spare parts

252318130117	OIL FILTER W/O CARTRIDGE	TATA spare parts
252318130123	OIL FILTER CARTRIDGE-SINGLE LIFE	TATA spare parts
252318130124	OIL FILTER CARTRIDGE-SINGLE LIFE	TATA spare parts
252318130127	OIL FILTER CARTRIDGE-SINGLE LIFE	TATA spare parts
252318130130	OIL FILTER CARTRIDGE-SINGLE LIFE	TATA spare parts
252318130132	OIL FILTER CARTRIDGE-SINGLE LIFE	TATA spare parts
252318130139	COVER ASSY OIL FILTER	TATA spare parts
252318130141	OIL FILTER ASSY	TATA spare parts
252318130142	LUBE OIL FILTER-SPIN ON	TATA spare parts
252318130146	ASSY FULL FLOW OIL FILTER	TATA spare parts
252318130147	COVER ASSY OIL FILTER	TATA spare parts
252318130176	OIL FILTER ASSY	TATA spare parts
252318130182	FILTER CARTRIDGE-DOUBLE LIFE	TATA spare parts
252318130183	FILTER CARTRIDGE-DOUBLE LIFE	TATA spare parts
252318133201	CENTRE BOLT	TATA spare parts
252318133701	OILFILTER COVER	TATA spare parts
252318134701	COVER OIL FILTER	TATA spare parts
252318135301	GASKET	TATA spare parts
252318150101	SUCTION TUBE W/STRAINER	TATA spare parts
252318150103	ASYSUCTIONTUBEWSTRAINERCR	TATA spare parts
252318150106	STRAINER OIL PUMP	TATA spare parts
252318170110	OIL COOLER ASSY	TATA spare parts
252318170112	OIL COOLER ASSY	TATA spare parts
252318170118	OIL LINE O/FILTER TO FIP	TATA spare parts
252318170121	ASSY.OIL LINE	TATA spare parts
252318173702	COVER OIL COOLER	TATA spare parts
252318173704	COVER OIL COOLER	TATA spare parts
252318930132	OIL FILTER CARTRIDGE-SINGLE LIFE	TATA spare parts
252320100103	ASSY WATER PUMP	TATA spare parts
252320100105	WATER PUMP ASSY L/ENG.	TATA spare parts
252320100112	ASSY.WATER PUMP	TATA spare parts
252320100113	WATER PUMP ASSY	TATA spare parts
252320100115	REP KIT WATER PUMP MJR	TATA spare parts
252320100116	REP KIT WATER PUMP MNR	TATA spare parts
252320103701	HOUSING WATER PUMP	TATA spare parts
252320107701	SLIDING SEAL RING	TATA spare parts
252320120104	UPP.COOL.WATER LINE	TATA spare parts
252320120105	UPP.COOL.WATER LINE	TATA spare parts
252320120107	UPP.COOL.WATER LINE	TATA spare parts
252320120123	KIT RADIATOR HOSE WAX THR	TATA spare parts
252320120129	KIT RADIATOR HOSE CLIPS	TATA spare parts
252320125301	GASKET WATER PUMP ( TALBROS )	TATA spare parts
252320137001	PULLEY WATER PUMP	TATA spare parts
252320140102	PULLEY WATER PUMP	TATA spare parts
252320140104	ASSY. FAN BS2/3/4	TATA spare parts
252320156301	V BELT COGGED 1450MM BS3	TATA spare parts
252320159902	FAN BELT	TATA spare parts

252322107101	LIFTING HOOK FRONT	TATA spare parts
252322107102	LIFTING HOOK REAR	TATA spare parts
252322120101	ENG MOUTING ARM FRONT	TATA spare parts
252322123203	HEX COLLAR SCREW (M14X1.5X100 LONG)	TATA spare parts
252322123204	COLLAR SCREW	TATA spare parts
252322123205	COLLAR SCREW	TATA spare parts
252322123206	COLLAR SCREW	TATA spare parts
252322125101	SUPPORT ARM	TATA spare parts
252322125102	ENG SUPPORT ASSY	TATA spare parts
252322148201	ENGINE NUMBER PLATE	TATA spare parts
252323100101	STEERING PUMP	TATA spare parts
252323100102	SEAL KIT P/STRG PUMP	TATA spare parts
252323100104	ROTOR SET	TATA spare parts
252323103101	BEARING BALL	TATA spare parts
252323103102	BEARING NEEDLE CAGE	TATA spare parts
252323103701	HOUSING	TATA spare parts
252323104301	RETAINING RING	TATA spare parts
252323104302	SNAP RING	TATA spare parts
252323104701	COVER	TATA spare parts
252323104801	DOWEL PIN	TATA spare parts
252323105901	WOODRUFF KEY	TATA spare parts
252323107202	SCREW PLUG	TATA spare parts
252323107901	SHAFT	TATA spare parts
252323108701	COMPRESSION SPRING	TATA spare parts
252323108702	HOOK SPRING RING	TATA spare parts
252323108703	PRESSURE SPRING	TATA spare parts
252323109902	PRESSURE PLATE	TATA spare parts
252323109903	FRONT PLATE	TATA spare parts
252324100101	ENG MOUNTING PAD FRONT	TATA spare parts
252324100102	ENG MOUNTING PAD REAR	TATA spare parts
252324100106	ENG MOUNTING PAD REAR	TATA spare parts
252324100109	KIT MTG PAD 0101/02/06	TATA spare parts
252325103705	CLUTCH HSG.GBS40	TATA spare parts
252325103707	CLUTCH HSG.310D	TATA spare parts
252325103708	CLUTCH HSG.G40	TATA spare parts
252325103709	CLUTCH HSG.G40	TATA spare parts
252325103710	CLUTCH HSG.GBS40	TATA spare parts
252325103711	CLUTCH HSG.310D	TATA spare parts
252325103713	CLUTCH HSG.G30	TATA spare parts
252325103714	CLUTCH HSG.G30	TATA spare parts
252325103715	CLUTCH HSG.GBC30	TATA spare parts
252325106701	PIN BS4	TATA spare parts
252325106703	PIN	TATA spare parts
252325108201	CLUTCH HSG.LOW PART	TATA spare parts
252325108202	CLUTCH COVER BOTTOM	TATA spare parts
252325108203	PROTECTIVE COVER CL HSG	TATA spare parts
252325109902	CHEESE HEAD SCREW	TATA spare parts

252340100102	PIPE AIR	TATA spare parts
252340100106	PIPE AIR	TATA spare parts
252340100110	PIPE AIR	TATA spare parts
252340100120	PIPE AIR	TATA spare parts
252340140101	PRESSURE REGULATOR VALVE	TATA spare parts
252340140106	FOOT CONTROL VALVE	TATA spare parts
252340140109	PRESSURE REGULATOR VALVE	TATA spare parts
252340140110	FOOT CONTROL VALVE	TATA spare parts
252340140111	PRESSURE REGULATOR VALVE	TATA spare parts
252340140112	FOOT CONTROL VALVE	TATA spare parts
252340140122	REPAIR KIT FOOT CONTROL VALVE	TATA spare parts
252340140124	REP KIT FOOT CON VALVE	TATA spare parts
252340140128	PRESSURE REGULATOR VALVE	TATA spare parts
252340146302	RUBBER COVER FOOT CONTROL VALVE	TATA spare parts
252340146801	DOUBLE SOCKET	TATA spare parts
252340146802	T CONNECTOR	TATA spare parts
252340148501	DOUBLE SOCKET	TATA spare parts
252340149201	SEALING RING	TATA spare parts
252340150102	AIR CYLINDER	TATA spare parts
252340150105	AIR CYLINDER	TATA spare parts
252340150107	AIR CYLINDER	TATA spare parts
252340150110	ACTUATING CYLINDER	TATA spare parts
252340150114	EXHAUST BRAKE CYLINDER	TATA spare parts
252340150118	EXH BRAKE CYLINDER	TATA spare parts
252340150119	EXH BRAKE CYLINDER	TATA spare parts
252340150123	REP KIT EXH BR CYLINDER	TATA spare parts
252340150125	EXH BRAKE CYLINDER	TATA spare parts
252340153301	BRACKET	TATA spare parts
252344110107	PULL ROD	TATA spare parts
252344110108	PULL ROD	TATA spare parts
252344110109	PULL ROD LHD	TATA spare parts
252344110112	PULL ROD	TATA spare parts
252344110115	PULL ROD	TATA spare parts
252344110117	PULL ROD	TATA spare parts
252344110125	PULL ROD	TATA spare parts
252344110128	PULL ROD	TATA spare parts
252344110138	PULL ROD	TATA spare parts
252344110141	PULL ROD	TATA spare parts
252344110158	ASSY PULL ROD EXH MANIFOLD SIDE RHD	TATA spare parts
252344110167	PULL ROD	TATA spare parts
252344110175	ASSY PULL ROD COMP	TATA spare parts
252344110178	ASSY PULL ROD	TATA spare parts
252344110180	PULL ROD RHD	TATA spare parts
252344117906	PULL ROD	TATA spare parts
252344117944	PULL ROD 636 LONG	TATA spare parts
252344117949	PULL ROD LHD	TATA spare parts
252344117954	PULL ROD RQV FIP	TATA spare parts

252344117955	PULL ROD - FIP LINKAGE-LP1510 RSV TYPE	TATA spare parts
252344117958	PULL ROD	TATA spare parts
252350000101	ASSY RADIATOR FRAM	TATA spare parts
252350000102	ASSY RADIATOR FRAME	TATA spare parts
252350000104	RADIATOR FRAME	TATA spare parts
252350000124	RADIATOR FRAME COMP	TATA spare parts
252350005805	RUBBER HOSE	TATA spare parts
252350100113	RADIATOR ASSY	TATA spare parts
252350100114	RADIATOR ASSY TOP FILLING	TATA spare parts
252350100115	RADIATOR ASSY LP/LPO	TATA spare parts
252350100122	RADIATOR ASSY	TATA spare parts
252350100126	ASSY CLAMP CR50747	TATA spare parts
252350100137	DRAIN COCK ASSY	TATA spare parts
252350100142	FILLER CAP	TATA spare parts
252350100144	RADIATOR	TATA spare parts
252350100145	FILLER CAP	TATA spare parts
252350100149	RADIATOR ASSY	TATA spare parts
252350100152	RADIATOR CAP	TATA spare parts
252350100153	FILLER CAP	TATA spare parts
252350100187	RADIATOR ASSY	TATA spare parts
252350100197	RADIATOR ASSY	TATA spare parts
252350100208	RADIATOR ASSY	TATA spare parts
252350100212	RADIATOR ASSY	TATA spare parts
252350100213	RADIATOR ASSY	TATA spare parts
252350100217	RADIATOR ASSY	TATA spare parts
252350100218	ASSY.RADIATOR BLOCK WITH	TATA spare parts
252350100219	RADIATOR ASSY	TATA spare parts
252358909902	DRIFT	TATA spare parts
252399000101	KIT DECARBONISING GASKETS	TATA spare parts
252399000102	KIT ENG OVERHAUL GASKETS	TATA spare parts
2523N3140161	SET PISTON W/O R RS2 4RV	TATA spare parts
2523N5990101	CAM KIT W/O TIM CAMSHAFT	TATA spare parts
2523N9000102	OVERHAUL KIT 909 DUMMY	TATA spare parts
252401000103	HALF ENG 495DI	TATA spare parts
252401000104	ENGINE ASSY 495NA LP	TATA spare parts
252401000105	ENGINE ASSY 495NA	TATA spare parts
252401100105	CYL.BLOCK W/O CL HSG.	TATA spare parts
252401130104	KIT OIL SUMP GASKET	TATA spare parts
252401130106	OIL SUMP ASSY	TATA spare parts
252401133701	FLANGE OIL SUMP DIPSTICK	TATA spare parts
252401150109	COVER CYLINDER HEAD	TATA spare parts
252401153402	VALVE SEAT RING STD	TATA spare parts
252401153403	VALVE SEAT RING STDI	TATA spare parts
252401153807	COVER CYLINDER HEAD	TATA spare parts
252401153808	CYLINDER HEAD COVER.	TATA spare parts
252401153809	CAP CYL HEAD COVER	TATA spare parts
252401155301	GASKET	TATA spare parts



252401155302	GASKET	TATA spare parts
252401155303	GASKET CYLINDER HEAD	TATA spare parts
252401155305	GASKET	TATA spare parts
252401155306	GASKET	TATA spare parts
252401170105	DIPSTICK	TATA spare parts
252401170108	TUBE DIPSTICK	TATA spare parts
252401170110	DIPSTICK W/O O RING	TATA spare parts
252401170112	ASSY TUBE DIPSTICK W/O NUT & SLIP RING	TATA spare parts
252403100103	CRANKSHAFT STD W/CWT	TATA spare parts
252403100106	CRANKSHAFT STD1 W/CWT	TATA spare parts
252403110103	ASSY FLY WHEEL WITH RING GEAR	TATA spare parts
252403113701	HOUSING FLYWHEEL GODREJ	TATA spare parts
252403120104	SET MAIN BRG STD	TATA spare parts
252403120105	SET MAIN BRG STD1	TATA spare parts
252403120106	SET MAIN BRG RS1	TATA spare parts
252403120107	SET MAIN BRG RS2	TATA spare parts
252403120108	SET MAIN BRG RS3	TATA spare parts
252403120109	SET MAIN BRG RS4	TATA spare parts
252403120110	SET CON ROD BRG STD	TATA spare parts
252403120111	SET CON ROD BRG STD1	TATA spare parts
252403120112	SET CON ROD BRG RS1	TATA spare parts
252403120113	SET CON ROD BRG RS2	TATA spare parts
252403120114	SET CON ROD BRG RS3	TATA spare parts
252403120115	SET CON ROD BRG RS4	TATA spare parts
252403130103	PULLEY COMP	TATA spare parts
252403130117	PULLEY COMP	TATA spare parts
252403138202	PROTECTIVE COVER BS6	TATA spare parts
252403138601	SPACER PLATE	TATA spare parts
252403140105	SET PISTON RING	TATA spare parts
252403140106	PISTON SET 495 WITH RINGS	TATA spare parts
252403140107	SET PISTON RINGS	TATA spare parts
252405100106	SET CAMSHAFT BEARING	TATA spare parts
252405120101	KIT ENGINE VALVE MJR	TATA spare parts
252405120102	KIT ENGINE VALVE MNR	TATA spare parts
252407140101	SET FUEL PR LINES	TATA spare parts
252407140102	PRESSURE LINE 1ST	TATA spare parts
252407140104	PRESSURE LINE 3RD	TATA spare parts
252407140105	PRESSURE LINE 4TH	TATA spare parts
252409110103	BRACKET FUEL FILTER	TATA spare parts
252409110108	BRACKET FUEL FILTER	TATA spare parts
252409113702	BRACKET FUEL FILTER	TATA spare parts
252409113703	BRACKET FUEL FILTER	TATA spare parts
252409118207	STAY FUEL FILTER	TATA spare parts
252409120102	FUEL LINE	TATA spare parts
252409120103	FUEL LINE	TATA spare parts
252409120106	FUEL LINE	TATA spare parts
252409120110	FUEL LINE	TATA spare parts

252409120112	ASSY OVERFLOW LINE GENSETS & EX60	TATA spare parts
252409120120	FUEL FLEX LINE	TATA spare parts
252409123303	BRACKET (OVERFLOW LINE)	TATA spare parts
252409130133	AIR FILTER ASSY OIL BATH	TATA spare parts
252409135802	RUBBER HOSE AIR FILTER	TATA spare parts
252409135806	RUBBER HOSE	TATA spare parts
252409135810	RUB HOSE ELBOW TO A/FIL	TATA spare parts
252409135811	RUB HOSE ELBOW TO A/FIL	TATA spare parts
252414110106	ASSY EXH MANIFOLD WITH STUD	TATA spare parts
252414113704	EXHAUST ELBOW	TATA spare parts
252414113706	EXHAUST MANIFOLD	TATA spare parts
252414115301	GASKET	TATA spare parts
252414115303	GASKET EXHAUST MANIFOLD	TATA spare parts
252414115304	GASKET EXHAUST MANIFOLD BS4	TATA spare parts
252415103701	INTERMEDIATE FLANGE	TATA spare parts
252415103801	INTERMEDIATE FLANGE	TATA spare parts
252415140105	CLAMPING BOLT	TATA spare parts
252415140109	BRACKET ALTERNATOR MTG	TATA spare parts
252415140110	CLAMPING ROD COMP	TATA spare parts
252415140111	CLAMPING ROD	TATA spare parts
252415143201	HEX BOLT	TATA spare parts
252415144202	CLAMP ALTERNATOR	TATA spare parts
252415146501	CLAMPING NUT BS4	TATA spare parts
252415400101	STARTER MOTOR 12V	TATA spare parts
252418100102	OIL PUMP ASSY	TATA spare parts
252418130103	INLET PIPE	TATA spare parts
252418130104	OUTLET PIPE	TATA spare parts
252418130108	ASSY. OIL FILTER COMPLETE	TATA spare parts
252418133701	BRACKET FOR OIL FILTER MTG	TATA spare parts
252418137601	ADAPTER	TATA spare parts
252418137602	MOUNTING BLOCK	TATA spare parts
252418150105	STRAINER OIL PUMP	TATA spare parts
252418158201	SUCTION DISH	TATA spare parts
252418158202	STRAINER	TATA spare parts
252420100103	ASSY. WATER PUMP BS2/3	TATA spare parts
252420104701	BACK COVER	TATA spare parts
252420105301	GASKET	TATA spare parts
252420120104	ASSY UPPER COOL WATERLINE	TATA spare parts
252420148202	ASSY.FAN 457 DIA (GENSET)	TATA spare parts
252420305802	RUBBER HOSE	TATA spare parts
252422126101	LOCKING PLATE	TATA spare parts
252422150108	ASSY BRACKET FRONT -RIGHT	TATA spare parts
252422150109	ASSY BRACKET FRONT-LEFT FOR EX60	TATA spare parts
252425100102	FLY WHEEL HOUSING VOLTAS	TATA spare parts
252425103705	CLUTCH HSG.RHD	TATA spare parts
252450000101	RADIATOR FRAME ASSY	TATA spare parts
252450005801	RUBBER HOSE	TATA spare parts

252450006901	SPACER TUBE	TATA spare parts
252450100103	RADIATOR ASSY	TATA spare parts
252450105801	RUBBER HOSE	TATA spare parts
252450105802	RUBBER HOSE	TATA spare parts
252499000101	KIT ENG OVERHAUL GASKETS	TATA spare parts
252499000102	KIT DECARBONISING GASKETS	TATA spare parts
2524N3120104	SET M BRG STD W/O COL BRG	TATA spare parts
2524N3120107	SET M BRG RS3 W/O COL BRG	TATA spare parts
252500000040	ENGINE ASSY 697TC SCAM PS	TATA spare parts
252500210107	ECU (FUEL SYSTEM) LOADED WITH CALIBRATIO	TATA spare parts
252500210108	ECU (FUEL SYSTEM) LOADED WITH CALIBRATIO	TATA spare parts
252500210110	ECU (FUEL SYSTEM) LOADED WITH CALIBRATIO	TATA spare parts
252500210111	ECU (FUEL SYSTEM) LOADED WITH CALIBRATIO	TATA spare parts
252500210117	ECU+CAL FILE WITH RSL IOBDII	TATA spare parts
252500210118	CONTAINER 3.8SGI OBD-2 (LP407CNG BS-IV)	TATA spare parts
252500990101	ENGINE OVERHAUL GASKET KIT (TATA 5.7 SGI	TATA spare parts
252500990102	DECARBONISING GASKET KIT (TATA 5.7 SGI B	TATA spare parts
252500990103	ASSY LONG BLOCK (TATA 5.7 SGI BSIV NA EN	TATA spare parts
252500990104	ASSY HALF BLOCK (TATA 5.7 SGI BSIV NA EN	TATA spare parts
252500990106	ASSY HALF BLOCK (LP913 AC)	TATA spare parts
252500990111	ASSY LONG BLOCK (TATA 5.7 SGI BSIV ENGIN	TATA spare parts
252500990113	ASSY HALF BLOCK (LP913 NON AC)	TATA spare parts
252500990115	LONG BLOCK 5.7 SGI 580 ECU	TATA spare parts
252500990116	ASSY HALF BLOCK 5.7 SGI 580 ECU	TATA spare parts
252500990117	ASSY LONG BLOCK LP913 AC CNG 580 ECU	TATA spare parts
252500990118	ASSY HALF BLOCK LP913 CNG 580 ECU	TATA spare parts
252500990120	ASSY LONG BLOCK LPO 1613 580 ECU	TATA spare parts
252500990121	ASSY HALF BLOCK 5.7 SGI 580 ECU	TATA spare parts
252500990124	ENGINE OVERHAUL GASKET KIT	TATA spare parts
252500990125	ENGINE OVERHAUL GASKET KIT	TATA spare parts
252500990127	LONG BLOCK BS6	TATA spare parts
252500990128	HALF BLOCK BS6	TATA spare parts
252500990132	LONG BLOCK BS6	TATA spare parts
252500990133	HALF BLOCK BS6	TATA spare parts
252501000004	ASY.ENG.W 310DIA.CLUTCH	TATA spare parts
252501000014	HALF ENG 697TC RHD 77DPS	TATA spare parts
252501000016	ENG ASSY697NA W/310D CL	TATA spare parts
252501000017	ENGINE 697 NA AUTO RHD	TATA spare parts
252501000054	ENGINE NA NLRHD12V70DPS	TATA spare parts
252501000078	ENGINE 697 NA LOW-W/PS	TATA spare parts
252501000119	HALF ENG NA LE RHD AC77D	TATA spare parts
252501000121	SHORT BLK 697 NA-EXCV	TATA spare parts
252501000125	HALF ENG NA LERHD SCAM PS	TATA spare parts
252501000126	HALF ENG NA LELHD SCAM PS	TATA spare parts
252501000130	ASSY SHORT BLOCK 697 LHD	TATA spare parts
252501000189	ENGINE EXCAVATOR	TATA spare parts
252501000208	ENGINE NA NLRHDRQV 12V94D	TATA spare parts

252501000216	ASY.ENG.(LINERED)W.310 CL	TATA spare parts
252501000234	ASSY ENGINE 697 NA	TATA spare parts
252501000239	HALF ENG NA LE RHD DAOH	TATA spare parts
252501000278	ENGINE ASSY 697TC	TATA spare parts
252501000279	ENGINE NA NLRHD PS12V94D	TATA spare parts
252501000280	ENGINE NA LERHD RQV24V94D	TATA spare parts
252501000282	ASSY.697 NA ENGINE LINERED	TATA spare parts
252501000298	ENGINE 697NA 24VG40 FRRQV	TATA spare parts
252501000304	ENGINE NA NLRHD12VSCAM W/O PSTG.697 RHD	TATA spare parts
252501000306	ENGINE 697 NA	TATA spare parts
252501000312	ENGINE 697NA PS RHD 130PS	TATA spare parts
252501000313	ENGINE NA LHD LPO12V 94	TATA spare parts
252501000318	ENGINE NA NLRHD RQV12V94D	TATA spare parts
252501000329	ASSY.ENGINE(LINERD)W PS	TATA spare parts
252501000350	ENGINE 697TC SCAMNL PSLIN	TATA spare parts
252501000392	ENGINE ASSY 697 TC 350	TATA spare parts
252501000405	ENGINE ASSY 697TC EXC200	TATA spare parts
252501000428	ASSY.697 NA ENG.W.G-40,24V&RATNS.P/S.RH	TATA spare parts
252501000429	ENGINE NA LELHD 24VSCAMPS	TATA spare parts
252501000440	ENGINE NA RHDG40 SCAM DR	TATA spare parts
252501000441	ENGINE NA LE RHD 12V SCAM	TATA spare parts
252501000451	ENG.ASSY.NA	TATA spare parts
252501000460	ASSY 697NA ENG W310D CL RHD DAOH BRAKES	TATA spare parts
252501000461	ENGINE NA LERHD 12VSCAMPS	TATA spare parts
252501000462	ASSY ENGINE COMP.697NA	TATA spare parts
252501000482	HALF ENG NA NL RHD SCAM	TATA spare parts
252501000486	HALF ENG NA LE RHD SCAM	TATA spare parts
252501000488	HALF ENG NA LE RHD SCAM	TATA spare parts
252501010001	SHORT BLOCK 697 EXC	TATA spare parts
252501100118	CYL.BLOCK W/O CL HSG.	TATA spare parts
252501100125	HALF ENG 697 LOW SCAM	TATA spare parts
252501100130	MAIN BEARING CAP 5TH	TATA spare parts
252501100132	ASSY MAIN BEARING CAP 2525	TATA spare parts
252501100142	CYL.BLOCK W/LINER	TATA spare parts
252501100144	697TC CYL BLK W/O LI	TATA spare parts
252501100151	CYLINDER BLOCK 697TC EXCA	TATA spare parts
252501100159	CAP MAIN BRG IV	TATA spare parts
252501100162	CYL BLOCK T/WASHER TY T C	TATA spare parts
252501100177	ASSY 4TH MAIN BEARING CAP BS6	TATA spare parts
252501100190	CYLINDER BLOCK 697NA	TATA spare parts
252501100196	ASSY.CYL.BLOCK WITH LINER	TATA spare parts
252501100198	CYL.BLOCK 697NA LIN SCAM	TATA spare parts
252501100208	CYLINDER BLOCK 697TC SCAM	TATA spare parts
252501100209	CYL.BLOCK 697TC SCAM	TATA spare parts
252501100219	ASSY CYL.BLOCK WITH LINER CMVR 2K1510/16	TATA spare parts
252501100220	CYL BLOCK 697 S-CAM	TATA spare parts
252501100233	ASSY.CYL.BLOCK W/O CL.HSG VER-DIPSTICK	TATA spare parts

252501100239	ASSY.CYL.BLOCK W/O CLUTCH/FLYWHEEL HSG.	TATA spare parts
252501100241	ASSY. CYL.BLOCK W/O CLUTCH HSG. BS1	TATA spare parts
252501100242	ASSY.CYL.BLOCK WITH LINER	TATA spare parts
252501100252	ASSY. CYLINDER BLOCK W/O CLUTCH HSG BS2	TATA spare parts
252501100268	ASSY. CYL.BLOCK W/O CL HSG. EURO2	TATA spare parts
252501100282	ASSY.CYL.BLOCK WITHOUT CLUTCH HOUSING.	TATA spare parts
252501100286	ASSY.CYL.BLOCK W/O 330 DIA.CL.HSG.697NA	TATA spare parts
252501100290	ASSY.CYL.CRANKCASE WITH LINER (697EIII)	TATA spare parts
252501100291	ASSY.CYL.CRANKCASE W/O FLYWHEEL HOUSING	TATA spare parts
252501100298	ASSY. CYL BLOCK W/O CLUTCH HSG. BS2/3/4	TATA spare parts
252501100313	ASSY CYL BLOCK WITHOUT CLUTCH HOUSING	TATA spare parts
252501100340	ASSY CYL.CRANKCASE W/O FLYWHEEL HOUSING	TATA spare parts
252501100348	CYL BLOCK ASSY WITH CLUTCH HSG	TATA spare parts
252501103702	LINER CYLINDER	TATA spare parts
25250110370260	2.53E+13	TATA spare parts
252501103739	CYLINDER LINER	TATA spare parts
252501103762	CAP MAIN BEARING REAR BS6	TATA spare parts
252501105301	GASKET BS6	TATA spare parts
252501106901	TUBE	TATA spare parts
252501108202	CORE PLUG. 25 DIA	TATA spare parts
252501108203	CORE PLUG (22DIA.) 697 ENGINE CYL.HEAD	TATA spare parts
252501108206	CORE PLUG ( DIA 56)	TATA spare parts
252501130105	FLANGE ASSY	TATA spare parts
252501130106	KIT OIL SUMP GASKETS	TATA spare parts
252501130107	OIL SUMP ASSY	TATA spare parts
252501130108	OIL SUMP ASSY	TATA spare parts
252501130129	SET OIL SUMP GASKET	TATA spare parts
252501130130	KIT OIL SUMP GASKETS	TATA spare parts
252501130131	SET OIL SUMP GASKET	TATA spare parts
252501130139	ASSY.OIL SUMP COMPLETE	TATA spare parts
252501130145	ASSY OIL SUMP	TATA spare parts
252501130146	ASSY.MAGNETIC DRAIN PLUG	TATA spare parts
252501130147	ASSY OIL SUMP	TATA spare parts
252501130152	OIL SUMP GASKET	TATA spare parts
252501130156	ASSYOIL SUMP 692DI W/O DIPSTICK HOLE	TATA spare parts
252501130158	ASSY OIL SUMP COMPLETE LPT1613TURBO	TATA spare parts
252501130163	ASSY OIL SUMP COMPLETE	TATA spare parts
252501130165	ASSY. OIL SUMP COMPLETE BS1/2/3/4	TATA spare parts
252501130168	OIL SUMP GASKET W/BEED	TATA spare parts
252501130171	GASKET ASSEMBLY OIL SUMP(697 ENG)	TATA spare parts
252501130173	ASSY.OIL SUMP WITH NOISE PADS(2515)	TATA spare parts
252501130174	ASSY.OIL SUMP WITH NOISE PADS(613)	TATA spare parts
252501130205	OIL SUMP ASSY WITH TUBE BS6	TATA spare parts
252501130206	FLANGE ASSY WITH TUBE BS6	TATA spare parts
252501135301	GASKET LEFT	TATA spare parts
252501135302	GASKET RIGHT	TATA spare parts
252501135303	GASKET	TATA spare parts

252501135304	GASKET	TATA spare parts
252501135305	GASKET LEFT	TATA spare parts
252501135306	GASKET RIGHT	TATA spare parts
252501135310	GASKET OIL SUMP SINGLE PIECE	TATA spare parts
252501135311	GASKET OIL SUMP SINGLE PIECE	TATA spare parts
252501135319	GASKET-OIL PAN	TATA spare parts
252501136301	A/VIBRATION PAD 1.5X230X101 MM	TATA spare parts
252501137701	OIL PAN DAMPER	TATA spare parts
252501137702	OIL PAN DAMPER-SMALL	TATA spare parts
252501137703	OIL PAN DAMPER	TATA spare parts
252501140114	PUSH ROD CHAMBER COVER	TATA spare parts
252501140137	ASSY.ADAPTOR WITH PIPE	TATA spare parts
252501140145	ASSY TGH ADAPTOR + O-RING + EXT.CIRCLIP	TATA spare parts
252501140155	ASSY.TGH COVER(MECH FEED PP)WITH NOISE	TATA spare parts
252501140156	ASSY.PRC COVER WITH NOISE PADS	TATA spare parts
252501140160	ASSY.TGH COVER(W/O OIL HOLE)NOISE PAD	TATA spare parts
252501140169	ASSY TGH COVER WITH HELICOIL	TATA spare parts
252501140170	ASSY.CLOSING PLATE WITH ASSY.ADAPTOR	TATA spare parts
252501140174	ASSY TGH COVER WITH NOISE PAD	TATA spare parts
252501140178	ASSY TIMING GEAR HSG WITH BOTTOM COVER	TATA spare parts
252501140186	ASSEMBLY TIMING GEAR HOUSING WITH BOTTOM	TATA spare parts
252501140188	ASSY TIMING GEAR HSG WITH ASSY ADAPTOR	TATA spare parts
252501140189	ASSEMBLY ADAPTOR (ON TGH HOUSING)	TATA spare parts
252501140207	TIMING GEAR HSG ASSY WITH BOTTOM COVER B	TATA spare parts
252501143702	BOTTOM COVER FOR 4SP & 697 TGH	TATA spare parts
252501143706	COVER FRONT-TIMING GEAR HSG(MECH.FEED P)	TATA spare parts
252501143802	CLOSING PLATE FOR FIP LOCATION	TATA spare parts
252501143804	COVER FRONT TIMING GEAR HOUSING	TATA spare parts
252501143805	COVER FRONT TIMING GEAR HOUSING	TATA spare parts
252501145301	GASKET PUSH ROD CH COVER	TATA spare parts
252501145302	GASKET-TGH TO CYL BLOCK	TATA spare parts
252501145306	GASKET (TGH COVER)	TATA spare parts
252501145308	GASKET (TGH) COVER	TATA spare parts
252501145309	GASKET ( AIR COMPRESSOR )	TATA spare parts
252501145318	GASKET ( TGH COVER ) BS6	TATA spare parts
252501146301	GASKET PUSH ROD CH COVER	TATA spare parts
252501146302	GASKET PUSH ROD CH COVER	TATA spare parts
252501146303	GASKET PUSH ROD CH.COVER.	TATA spare parts
252501146304	GASKET PUSH ROD CH.COVER.	TATA spare parts
252501146305	GASKET (PUSH ROD CHAMBER COVER)	TATA spare parts
252501147701	PTFE SEAL-CRANKSHAFT	TATA spare parts
252501147702	FRONT COVER DAMPER	TATA spare parts
252501147703	PRC BAFFLE COVER	TATA spare parts
252501147705	FRONT COVER DAMPER	TATA spare parts
252501148801	STUD (CM6X16)	TATA spare parts
252501150107	TIMING GEAR HOUSING	TATA spare parts
252501150109	ELBOW AIR INTAKE	TATA spare parts

252501150113	CYL HD W/VA	TATA spare parts
252501150114	ELBOW AIR INTAKE	TATA spare parts
252501150124	CYLINDER HEAD W/VALVES	TATA spare parts
252501150125	CYLINDER HEAD W/O VALVES	TATA spare parts
252501150133	CYL HEAD W/VALVE D/SPRING	TATA spare parts
252501150140	ASSY CYL HEAD W/O VALVES CMVR 2K1510/161	TATA spare parts
252501150141	CYLINDER HEAD WITH VALVE	TATA spare parts
252501150142	AIR INTAKE ELBOW M22 X 1.5 HOLE	TATA spare parts
252501150145	ASSY. AIR INTAKE ELBOW	TATA spare parts
252501150148	SET VALVE SEAT RINGS STD BS1/2/3	TATA spare parts
252501150149	SET VALVE SEAT RINGS STD1	TATA spare parts
252501150159	ASSY.CYL.HEAD WITHOUT VALVES 10MMOFFSET	TATA spare parts
252501150160	ASSY.CYL.HEAD WITH VALVES SINGLE SPRING	TATA spare parts
252501150162	AIR INTAKE ELBOW	TATA spare parts
252501150163	ASSY CYL HEAD COVER SIDE ENTRY-CMVR 2K	TATA spare parts
252501150168	ASSY CYL HEAD W/O VALVES CORE PLUGS	TATA spare parts
252501150169	ASSY.CYL.HEAD WITH VALVES(CORE PLUGS).	TATA spare parts
252501150173	ASSY.ELBOW(FOR TOP ENTRY CYL.HEAD COVER)	TATA spare parts
252501150179	ASSY.CYL.HEAD WITH VALVES	TATA spare parts
252501150180	ASSEMBLY CYLINDER HEAD (WITHOUT VALVES)	TATA spare parts
252501150182	ASSY.CYL.HEAD WITHOUT VALVES 697	TATA spare parts
252501150186	ASSY. CYL. HEAD W/VALV (INC. HOLES)BS2/3	TATA spare parts
252501150190	ASSY.CYL.HEAD WITH VALVES(60 DEG)-BS-III	TATA spare parts
252501150191	ASSY.CYL.HEAD WITHOUT VALVES (60 DEG)	TATA spare parts
252501150192	ASSY. CYL. HEAD W/VALVES (60 DEG)BS1/2/3	TATA spare parts
252501150193	ASSY.CYL.HEAD WITHOUT VALVES(60 DEG)	TATA spare parts
252501150203	ASSY CYLINDER HEAD WITH VALVES	TATA spare parts
252501150204	ASSY CYLINDER HEAD WITHOUT VALVES	TATA spare parts
252501150205	ASSY. THROTTLE BODY	TATA spare parts
252501150212	ASSY. CYLINDER HEAD COVER (INJ.OUTSIDE S	TATA spare parts
252501150215	ASSY CYLINDER HEAD (WITHOUT VALVES)	TATA spare parts
252501150218	ASSY. CYL. HEAD WITHOUT VALVES (CNG) BSI	TATA spare parts
252501150219	ASSY. CYLINDER HEAD WITH VALVES BS4	TATA spare parts
252501150229	HEAD ASSY WITHOUT VALVES	TATA spare parts
252501150230	HEAD ASSY WITH VALVES	TATA spare parts
252501150270	SET-VALVE SPRING	TATA spare parts
252501150277	CYL HEAD ASSY W/O VALVES BS6	TATA spare parts
252501150278	CYL HEAD ASSY WITH VALVES BS6	TATA spare parts
252501150283	CYLINDER HEAD ASSY W/O VALVES BS6	TATA spare parts
252501150284	CYL HEAD ASSY WITH VALVES BS6	TATA spare parts
252501153410	VALVE SEAT EXHAUST STD	TATA spare parts
252501153411	VALVE SEAT EXHAUST STD1	TATA spare parts
252501153422	VALVE SEAT RING-INLET CNG -NORMAL	TATA spare parts
252501153425	VALVE SEAT RING-EXHAUST CNG -NORMAL	TATA spare parts
252501153426	VALVE SEAT RING-EXHAUST(CNG)-NORMAL-I	TATA spare parts
252501153433	VALVE SEAT RING INLET-NORMAL	TATA spare parts
252501153447	VALVE SEAT RING INTAKE- NORMAL	TATA spare parts

252501153450	VALVE SEAT RING EXHAUST- NORMAL	TATA spare parts
252501153713	AIR INTAKE ELBOW	TATA spare parts
252501153807	COVER CYLINDER HEAD	TATA spare parts
252501153810	ELBOW AIR INTAKE	TATA spare parts
252501153811	COVER CYLINDER HEAD	TATA spare parts
252501153816	COVER CYLINDER HEAD	TATA spare parts
252501153817	CYL.HEAD COVER	TATA spare parts
252501153820	CAP OIL FILLER	TATA spare parts
252501153822	COVER CYLINDER HEAD	TATA spare parts
252501153826	ELBOW AIR INTAKE	TATA spare parts
252501153829	CYL HEAD COVER	TATA spare parts
252501153830	ELBOW AIR INTAKE	TATA spare parts
252501153847	AIR INTAKE PIPE. 697 ENGINE	TATA spare parts
252501153849	AIR INLET ELBOW LPT1613	TATA spare parts
252501153852	AIR INTAKE ELBOW-SE1613 CMVR 2000	TATA spare parts
252501153859	AIR INLET ELBOW 697NA CMVR 2K	TATA spare parts
252501153867	AIR INLET ELBOW LPT1613	TATA spare parts
252501153868	AIR INLET ELBOW(LPT613 E-II)	TATA spare parts
252501153869	CYL.HEAD COVER-TOP ENTRY FLANGE TYPE	TATA spare parts
252501153875	AIR INTAKE ELBOW(697TC EURO III)	TATA spare parts
252501153876	CYL HEAD COVER (INJ.OUTSIDE) BS III	TATA spare parts
252501153877	AIR INTAKE ELBOW TOP ENTRY	TATA spare parts
252501153878	CYLINDER HEAD COVER(INJ.OUTSIDE)-AL	TATA spare parts
252501153879	AIR INTAKE ELBOW	TATA spare parts
252501153881	AIR INTAKE ELBOW	TATA spare parts
252501153882	AIR INLET ELBOW (FLAME START)	TATA spare parts
252501153883	AIR INLET ELBOW (WITH LDA CONNECTION)	TATA spare parts
252501153884	CYL.HEAD COVER (INJ. OUTSIDE REAR ENTRY)	TATA spare parts
252501153886	AIR INTAKE ELBOW (FLAME START)	TATA spare parts
252501153888	AIR INTAKE ELBOW (FLAME START)	TATA spare parts
252501153891	AIR INTAKE ELBOW (WITH LDA PROVISION)	TATA spare parts
252501153895	CYLINDER HEAD COVER (INJ. OUTSIDE REAR E	TATA spare parts
252501153896	AIR INTAKE ELBOW	TATA spare parts
252501153897	ROCKER ARM COVER - TATA 5.7 SGI BSIV	TATA spare parts
252501153898	AIR INTAKE ELBOW TOP ENTRY CYL. HEAD COV	TATA spare parts
252501153899	COVER - ROCKER SIDE ENTRY DIESEL	TATA spare parts
252501155301	GASKET CYLINDER HEAD	TATA spare parts
252501155314	GASKET CYL HEAD COVER	TATA spare parts
252501155315	CYL.HEAD COVER GASKET	TATA spare parts
252501155316	GASKET CYL HEAD COVER	TATA spare parts
252501155321	CYL HEAD GASKET-NON-RETROQUE 697 CMVR 2K	TATA spare parts
252501155322	GASKET-CYL.HD.COVER BS1/2/3	TATA spare parts
252501155326	GASKET CYLINDER HEAD NON RETORQUE	TATA spare parts
252501155329	CYLINDER HEAD GASKET	TATA spare parts
252501155330	CYLINDER HEAD GASKET	TATA spare parts
252501155333	CYLINDER HEAD GASKET	TATA spare parts
252501155335	GASKET-TOP ENTRY CYL.HEAD COVER	TATA spare parts



252501155336	GASKET(CYL.HEAD-CYL.CRANKCASE) BS1/2/3/4	TATA spare parts
252501155337	CYLINDER HEAD GASKET FOR 697TURBO ENGINE	TATA spare parts
252501155339	GASKET(CYL.HEAD TO CYL.CRANKCASE)EUROIII	TATA spare parts
252501155340	GASKET-CYL. HEAD COVER EURO3 BS2/3	TATA spare parts
252501155341	GASKET-CYLINDER HEAD 697TURBO BS1/2/3	TATA spare parts
252501155347	CYLINDER HEAD GASKET-MLS	TATA spare parts
252501155348	GASKET-CYL.HD COVER INJ OUTSIDE	TATA spare parts
252501155350	GASKET - ROCKER ARM COVER	TATA spare parts
252501155352	GASKET- THROTTLE BODY TO INT. MANIFOLD	TATA spare parts
252501155354	GASKET-CYL HEAD COVER REUSABLE	TATA spare parts
252501155355	GASKET - ROCKER ARM COVER BS3/4	TATA spare parts
252501155359	GASKET-CYL. HEAD COVER(SPLIT TYPE)	TATA spare parts
252501156907	PROTECTIVE SLEEVE -UPPER	TATA spare parts
252501156908	PROTECTIVE SLEEVE-LOWER	TATA spare parts
252501157707	O RING - RAIL MTG.	TATA spare parts
252501158803	HEX.FLANGE BOLT (FOR AL COVER)	TATA spare parts
252501158805	HEX.FLANGE BOLT (FOR AL COVER)	TATA spare parts
252501158806	HEX FLANGE BOLT (M8X135L) BS4	TATA spare parts
252501158808	STUD BM12X25 (COMPRESSOR MTG.) (B)	TATA spare parts
252501159904	STRAIGHT REDUCER	TATA spare parts
252501159908	HEX COLLER SCREW	TATA spare parts
252501159910	HEXAGONAL HEAD SCREW FOR M.B.CAP MTG.	TATA spare parts
252501159912	HEX COLLAR BOLT-WITH RELIEF GROOVE BS4	TATA spare parts
252501160101	NOZZLE WITH HOLDER	TATA spare parts
252501160111	NOZZLE HOLDER	TATA spare parts
252501160121	INJECTOR (697SK & 1510) CMVR	TATA spare parts
252501160123	ASSY.INJECTOR 697 E-II	TATA spare parts
252501160125	ASSY INJECTOR 145 HP BS I	TATA spare parts
252501160127	ASSY.INJECTOR NORMAL 697 EURO III	TATA spare parts
252501160128	ASSY INJECTOR NBEF TYPE 697 E III	TATA spare parts
252501160130	ASSY.NOZZLE HOLDER-145PS BS-II	TATA spare parts
252501160133	ASSY.INJECTOR	TATA spare parts
252501160140	ASSY. FUEL INJECTOR BS4	TATA spare parts
252501160141	ASSY. FUEL INJECTOR BS3/4	TATA spare parts
252501160143	ASSY INJECTOR NORMAL 697 EUROIII(K TYPE)	TATA spare parts
252501160144	ASSY INJECTOR NBEF 697 EUROIII (K TYPE)	TATA spare parts
252501160148	INJECTOR ASSY	TATA spare parts
252501163809	AIR INTAKE ELBOW	TATA spare parts
252501163811	CYL HEAD COVER (LOWER)	TATA spare parts
252501163812	CYLINDER HEAD COVER (TOP)	TATA spare parts
252501163815	AIR INTAKE ELBOW	TATA spare parts
252501165101	CLAW INJECTOR OUTSIDE COVER	TATA spare parts
252501165301	GASKET CYL HEAD COVER	TATA spare parts
252501165302	GASKET CYLINDER HEAD	TATA spare parts
252501165303	GASKET CYL HEAD 697NA	TATA spare parts
252501169202	SEALING WASHER 3THK - INJECTOR	TATA spare parts
252501170115	TUBE DIPSTICK W/SLEEVE	TATA spare parts

252501170118	TUBE DIPSTICK W/O SLEEVE	TATA spare parts
252501170119	DIPSTICK	TATA spare parts
252501170124	PIPE OIL FILLER W/BKT	TATA spare parts
252501170125	CAP ASSY. WITH HINGE	TATA spare parts
252501170128	DIPSTICK	TATA spare parts
252501170130	TUBE DIPSTICK	TATA spare parts
252501170131	DIPSTICK	TATA spare parts
252501170143	DIPSTICK	TATA spare parts
252501170147	DIPSTICK	TATA spare parts
252501170158	PIPE OIL FILLER W/BKT	TATA spare parts
252501170163	DIPSTICK	TATA spare parts
252501170177	CAP OIL FILLER W/CHAIN	TATA spare parts
252501170181	ASSY CAP W/CHAIN-OIL FILL	TATA spare parts
252501170184	ASSY OIL DIPSTICK	TATA spare parts
252501170189	ASSY. FRAME W/BRACKET	TATA spare parts
252501170191	DIPSTICK ASSY COMPLETE	TATA spare parts
252501170193	TUBE DIPSTICK W/O NUT&FERRULE	TATA spare parts
252501170194	ASSY.OIL DIPSTICK COMPLETE	TATA spare parts
252501170198	ADAPTER ASSY DIPSTICK TUBE BS6-PH2	TATA spare parts
252501170202	ASSY.OIL FILLER PIPE LPT1613	TATA spare parts
252501170203	ASSY OIL DIPSTICK LP/LPT	TATA spare parts
252501170204	ASSY OIL DIPSTICK	TATA spare parts
252501170207	ASSY TUBE DIPSTICK LP/LPT	TATA spare parts
252501170208	ASSY TUBE DIPSTICK SE	TATA spare parts
252501170212	ASSY OIL DIPSTICK WITH O RING 1320L VER	TATA spare parts
252501170216	ASSY OIL FILLER PIPE.	TATA spare parts
252501170219	ASSY.TUBE DIPSTICK(1300MM)-EURO-II	TATA spare parts
252501170227	ASSY.BRACKET DIPSTICK CLAMPING ON CYLHD	TATA spare parts
252501170228	ASSY.BRACKET(DIPSTICK MTG)	TATA spare parts
252501170229	ASSY.OIL FILLER PIPE LPT 2515-697TC	TATA spare parts
252501170235	ASSY.TUBE DIPSTICK 330 LONG	TATA spare parts
252501170236	ASSY.OIL DIPSTICK COMPLETE.	TATA spare parts
252501170238	ASSY. OIL DIPSTICK COMPLETE (1393L)	TATA spare parts
252501170240	ASSY. TUBE DIPSTICK (1180L)	TATA spare parts
252501170246	ASSY OIL SAPERATOR WITH OIL FILL CAP	TATA spare parts
252501170248	ASSY.DIPSTICK COMPLETE (1393 L)	TATA spare parts
252501170250	ASSY.DIPSTICK COMPLETE (1513 L)	TATA spare parts
252501170252	ASSY.OIL DIPSTICK-1393 L (SE/SK-1613)	TATA spare parts
252501170253	ASSY.OIL DIPSTICK-1513 L(LP1510/LPT2515)	TATA spare parts
252501170258	ASSY TUBE DIPSTICK	TATA spare parts
252501170259	ASSY OIL DIPSTICK COMPLETE	TATA spare parts
252501170277	ASSY. OIL SEPERATOR WITH OIL FILL CAP	TATA spare parts
252501170286	ASSEMBLY BRACKET (DIPSTICK MOUNTING)	TATA spare parts
252501170295	ASSY TUBE WITH CLAMP(BREATHER TO ATM)	TATA spare parts
252501170306	ASSEMBLY TUBE WITH CLAMP	TATA spare parts
252501170309	ASSYTUBE DIPSTICK	TATA spare parts
252501170310	ASSY OIL DIPSTICK COMPLETE	TATA spare parts

252501170313	ASSY OIL SEPERATOR	TATA spare parts
252501170315	ASSEMBLY BRACKET (DIPSTICK SUPPORT)	TATA spare parts
252501170328	ASSEMBLY TUBE DIPSTICK	TATA spare parts
252501170329	ASSY OIL DIPSTICK COMPLETE	TATA spare parts
252501170331	PIPE ASSY PIPE ASSLY WITH CLAMP	TATA spare parts
252501170334	OIL SAPERATOR ASSY	TATA spare parts
252501170335	ASSY OIL DIPSTICK COMPLETE	TATA spare parts
252501170337	ASSY. OIL DIPSTICK COMPLETE	TATA spare parts
252501170348	OIL MIST SEPARATOR ASSY BS6	TATA spare parts
252501170349	TUBE ASSY OMS TO OIL SUMP BS6-PH2	TATA spare parts
252501170353	TUBE ASSY CYL HEAD COVER TO OMS BS6-PH2	TATA spare parts
252501170355	TUBE ASSY OMS TO OIL SUMP BS6	TATA spare parts
252501170356	DIPSTICK TUBE ASSY BS6	TATA spare parts
252501170359	TUBE ASSY CYL HEAD COVER TO OMS BS6	TATA spare parts
252501170361	TUBE OMS TO AIR INTAKE SYSTEM BS6	TATA spare parts
252501170362	DIPSTICK ASSY BS6	TATA spare parts
252501170364	TUBE OMS TO AIR INTAKE SYSTEM BS6	TATA spare parts
252501170365	DIPSTICK TUBE ASSY BS6	TATA spare parts
252501170367	DIPSTICK ASSY BS6	TATA spare parts
252501170368	OIL MIST SEPARATOR ASSY BS6-PH2	TATA spare parts
252501170371	TUBE ASSY OMS TO OIL SUMP BS6	TATA spare parts
252501170374	BREATHER ASSY	TATA spare parts
252501170377	TUBE OMS TO AIR INTAKE SYSTEM BS6-PH2	TATA spare parts
252501170379	DIPSTICK ASSY BS6-PH2	TATA spare parts
252501173328	BRACKET OIL SEPARATOR MTG BS6-PH2	TATA spare parts
252501173330	SUPPORT BRACKET BS6-PH2	TATA spare parts
252501173332	BRACKET OIL SEPARATOR MTG BS6	TATA spare parts
252501173333	SUPPORT BRACKET BS6	TATA spare parts
252501173335	SUPPORT BRACKET BS6	TATA spare parts
252501173336	BRACKET OIL FILLER MTG BS6	TATA spare parts
252501173337	SUPPORT BRACKET DIPSTICK MTG BS6	TATA spare parts
252501173342	SUPPORT BRACKET BS6-PH2	TATA spare parts
252501174204	CLAMP FOR DIPSTICK	TATA spare parts
252501174205	CLAMP SUPPORT (FOR DIPSTICK MTG.TUBE)	TATA spare parts
252501174206	CLAMP (LOWER)	TATA spare parts
252501174207	SUPPORT(DIPSTICK TUBE)	TATA spare parts
252501174212	CLAMP BS6	TATA spare parts
252501175804	HOSE OIL FILLER	TATA spare parts
252501175805	HOSE	TATA spare parts
252501175806	HOSE	TATA spare parts
252501175809	HOSE OIL SEPARATOR	TATA spare parts
252501175810	TUBE OIL FILLER 600 LONG	TATA spare parts
252501175814	HOSE (OIL DRAIN)	TATA spare parts
252501175828	RUBBER HOSE (CYLINDER HEAD COVER TO OMS)	TATA spare parts
252501175829	HOSE (OMS TO OIL SUMP)	TATA spare parts
252501175830	RUBBER HOSE (OMS OIL RETURN)	TATA spare parts
252501175840	HOSE (OIL SEPERATOR)	TATA spare parts

252501175842	HOSE (OIL SEPERATOR)	TATA spare parts
252501175851	HOSE BLOWBY BS6	TATA spare parts
252501175854	HOSEOILFILLER BS6	TATA spare parts
252501175855	HOSE OIL FILLER BS6	TATA spare parts
252501176911	FINOLEX TUBE	TATA spare parts
252501176963	TUBEOMS BS6	TATA spare parts
252501179903	LOCK NUT OIL SEPERATOR	TATA spare parts
252501179908	PLUG (FOR DIPSTICK HOLE ON CYL.BLOCK)	TATA spare parts
252501179909	OIL FILLING CAP ADAPTOR	TATA spare parts
252501179910	ADAPTOR FOR STEPPER MOTOR	TATA spare parts
252501179915	ADAPTER DIPSTICK TUBE BS6-PH2	TATA spare parts
252501600101	ENGINE NA LOW LHD SCAM	TATA spare parts
252501600102	ENGINE NA LOW RHD SCAM	TATA spare parts
252501600106	ENGINE NA RHD SCAM PS	TATA spare parts
252501600117	ASSY. ENG COMPLETE FOR 697 NA CNG BSIII	TATA spare parts
252501600120	HALF ENG NA LE RHD SCAM	TATA spare parts
252501600123	ASSY.ENGINE COMPL.W CLUTC	TATA spare parts
252501600125	HALF ENG 697TC SCAM	TATA spare parts
252501600128	ENGINE ASSY 697NA	TATA spare parts
252501600131	697NA 110PS W 330CL HSG PSTG EX BR(1510	TATA spare parts
252501600167	ENGINE NA RHD 130PS 94DMS	TATA spare parts
252501600169	ENGINE NALE RHD130PS 94D	TATA spare parts
252501600192	ASSY.ENG.COMP.W/CL 65AMP.ALT.& H.D.-LHD	TATA spare parts
252501600198	ENGINE 12V-FOR CONS EQUIP	TATA spare parts
252501600214	697TC 130PS/310CL/35AMP/W/OPSTG SE1613	TATA spare parts
252501600216	ENGINE 697TC CMVR 2K-M/STRG&KKK LPT1613R	TATA spare parts
252501600217	ASSY ENGINE LPT713 CMVR RHD HD PS S'CAM	TATA spare parts
252501600232	ENGINE ASSY COMPLT WITH CLUTCH	TATA spare parts
252501600233	ENGINE 697 NA LP 1510 RHD CMVR 2K M/STRG	TATA spare parts
252501600236	ENGINE 697NA FOR 713SOUTH AFRICA 310DIA	TATA spare parts
252501600239	ENGINE 697 NA LP 1510 RHD CMVR 2K P/STRG	TATA spare parts
252501600240	ENGINE 697TC CMVR 2K-M/STRG&KKK SE1613RH	TATA spare parts
252501600243	ENGINE 697NA CMVR 2K (12V M/STRG)1613SK	TATA spare parts
252501600251	ENGINE 697TC 130PS H.TORQUE CMVR2K	TATA spare parts
252501600252	ENG. SE1613 HI TORQUE FIP 330D CL.	TATA spare parts
252501600254	ENGINE 697TC 130PS 330 CL V DIP -LPT1613	TATA spare parts
252501600255	ASSY.697TC 130PS C2K V.DIP M.STRG-SE1613	TATA spare parts
252501600256	ASSY. ENGINE LPT 613 LHD EURO II	TATA spare parts
252501600258	ASSY. ENGINE 697TC EURO II 330D CLUTCH	TATA spare parts
252501600260	ENGINE 697NA 330 DIA CL CMVR2K M/STRG	TATA spare parts
252501600264	ASSY ENGINE FOR LP613 P/S LHD 310DIA	TATA spare parts
252501600267	ENGINE 697NA 130PS C2K MSTG 330D CL.HSG-	TATA spare parts
252501600268	ENG LPT1613TC HI TORQ HOL VERT DPT 330DI	TATA spare parts
252501600273	ENGINE 697TC M STG 310CL-LPT1613	TATA spare parts
252501600274	ENGINE ASSY 697NA TELCON	TATA spare parts
252501600276	ASSY ENGINE 697 TURBO CMVR2000	TATA spare parts
252501600288	ENGINE 697NA 330 DIA CL CMVR2K P/STRG	TATA spare parts

252501600289	ASSY.ENG-697NA130PSC2K PSRG VDIP EXH 31	TATA spare parts
252501600295	ASSY. ENG LPT1313 697NA C2K PSTRG 12V SL	TATA spare parts
252501600296	ASSY ENG LPT613 CMVR LHD VERT. EXH	TATA spare parts
252501600307	ASSY.ENG 2518 EURO-III COWL	TATA spare parts
252501600308	ASSY.687TC 130PS EURO-II(LP613 LHD)	TATA spare parts
252501600357	697TCIC-145HP EURO-I PSTG 352FHSG 2515	TATA spare parts
252501600359	ASSY.ENG 1613 LPT EURO-II COWL	TATA spare parts
252501600360	ASSY.ENGINE.COMP.330CL EXH.BR-SK1613 P/	TATA spare parts
252501600362	ASSY ENGINE 130HP BSII PS 330DIA CL 24 V	TATA spare parts
252501600363	ASSY.ENG.1615 EURO-III	TATA spare parts
252501600364	ASSY.ENG.2515 EURO-II	TATA spare parts
252501600365	ASSY.ENG.1613 LPT EURO-II CAB	TATA spare parts
252501600367	ASSY.ENG.COMP 697TCIC 2515 EURO-II CAB	TATA spare parts
252501600368	ASSYENGINE COMPSE/SK-1613-BSII	TATA spare parts
252501600369	ASSY.ENG.WITH FL.HSG.697TCICBSIII(155PS)	TATA spare parts
252501600370	ASSY.ENG.1613 SE/SK EURO-II	TATA spare parts
252501600371	ASSY.ENG.1613 LPT EURO-II	TATA spare parts
252501600372	ASSY.ENG.COMP.-697TCIC-BSII-LPT2515 COWL	TATA spare parts
252501600373	ASSY. ENGINE COMP. 697NA 24V BS1	TATA spare parts
252501600374	ASSY ENGINE 697 TCIC EUROIII	TATA spare parts
252501600375	ASSY ENG.WITH FLY HSG697TCIC BS-III SE/K	TATA spare parts
252501600376	ASSY.ENG.COMPLT.697TCIC 130PSBSII 24V	TATA spare parts
252501600377	TATA MOBILE 207/31	TATA spare parts
252501600378	ASSY.ENGINE COMPLETE -WHEEL LOADER	TATA spare parts
252501600380	ASSY.ENG.COMP.(LPK1613)	TATA spare parts
252501600385	ASSY.ENG.-LPT2515 E II COWL	TATA spare parts
252501600386	ASSY.ENGINE COMPLETE 155PS 24V.	TATA spare parts
252501600387	ASSY.ENG.COMP.130PS FLAME START	TATA spare parts
252501600389	ENGINE COMP(130PS EURO-II-LP713)	TATA spare parts
252501600390	ASSY.ENGINE COMP(130PS E-II-LPT/LPK 713)	TATA spare parts
25250160039020	STAGE ENGINE ASSY. 697TCIC	TATA spare parts
252501600395	ASSY.ENG.COMP. LP1510 E II W.MECH F PUMP	TATA spare parts
252501600398	ASSY.ENG COMPLETE-130PS E-III WITH FLAME	TATA spare parts
252501610101	ASSY. ENGINE COMPLETE LPT 2516 COWL	TATA spare parts
252501610103	ASSY.ENG.COMPLETE 697 TCIC E-III 180PS	TATA spare parts
252501610106	ASSY ENGINE COMP. 697TCIC 130PS E-II W/O	TATA spare parts
252501610107	ASSY. ENGINE 697CRDi 130PS W/O HD EURO2	TATA spare parts
252501610108	ASSY ENGINE COMPLETE	TATA spare parts
252501610114	ASSY. ENGINE COMPLETE LPT 1116 SA C	TATA spare parts
252501610115	ASSY ENGINE COMPLETE 697 NA CNG BSIII	TATA spare parts
252501610117	ASSY. ENG COMPLETE FOR 697 NA CNG BSIII	TATA spare parts
252501610122	ENGINE COMPLETE 697 TCIC E-III 155PS 2	TATA spare parts
252501610123	ASSY.ENGINE COMPLETE-130PS E-IV LPT 613	TATA spare parts
252501610124	ASSY ENGINE COMPLETE LPT3118 COWL 24V	TATA spare parts
252501610128	ENGINE 697 TCIC 130PS E-II WITH HD LP613	TATA spare parts
252501610129	ASSY ENGINE COMPLETE 697 NA CNG LPT1613	TATA spare parts
252501610131	ASSYENGINECOMPLETE697TCIC130PSE-II	TATA spare parts

252501610140	ASSY. ENG COMPLETE FOR 697 NA CNG BSIII	TATA spare parts
252501610148	ENGINE ASSY.100KW LPT BSIII COWL(352DIA	TATA spare parts
252501610149	ASSY ENGINE COMPLETE 697 TCIC BS III - 1	TATA spare parts
252501610151	ASSY ENGINE COMPLETE 697 CNG NA BSIV	TATA spare parts
252501610153	ENGINE COMPLETE 100 KW BSIII SE/SK 1613	TATA spare parts
252501610154	ENGINE COMPLETE-LPK1616 BSIII	TATA spare parts
252501610158	ASSY. ENGINE COMPLETE LPT 1116 SA CAB-LH	TATA spare parts
252501610159	ASSY. ENGINE COMPLETE TATA 5.7 SGI BSIV	TATA spare parts
252501610167	ENGINE ASSY 155PS 697 TCIC BSIII 12V	TATA spare parts
252501610173	ASSY. ENGINE 697CRDi 130PS LP1613 BS4	TATA spare parts
252501610175	ASSY.ENG COMP.697TCIC BS-IV:LPT1613 SIDE	TATA spare parts
252501610185	ENGINE ASSY 697TCIC 100KW BSIII	TATA spare parts
252501610186	ENGINE ASSY. 697TCIC 100KW BSIII CAB 24V	TATA spare parts
252501610191	ENGINE COMPLETE 697 TCIC BSIII/36 LPK	TATA spare parts
252501610192	ENG COMP 100 KW BSIII SE/SK 1613	TATA spare parts
252501610193	ASSY ENGINE COMPLETE FOR LP913 AC	TATA spare parts
252501610194	ENGINE CRI6-75BS-IV SE/SK1613(CRI6-75)	TATA spare parts
252501610202	ASSY.ENG COMP.697TCIC BS-IV LPT1613 COWL	TATA spare parts
252501610203	ASSY.ENG 697 CR BS3:LPT1613 COWL	TATA spare parts
252501610205	ENG ASSY 697 TCIC CRBSIII LPT1613	TATA spare parts
252501610206	ENGINE COMP.5.7 SGI BSIV NA ENG IOBD II	TATA spare parts
252501610208	ASSY. ENGINE LPT1116 48WB BS2 SA	TATA spare parts
252501610218	ASSY ENGINE COMPLETE FOR LP913 NON AC	TATA spare parts
252501610226	ENGINE ASSY 5.7 SGI BSIV NA OBDII	TATA spare parts
252501610230	ENGINE ASSY	TATA spare parts
252501610231	ENGINE ASY COMPLETE LP913 AC	TATA spare parts
25250161023170	ENGINE ASY COMPLETE LP913 AC	TATA spare parts
252501610233	ENGINE COMPLETE LPO 1613 CNG BSIV	TATA spare parts
252501610238	ASSY.ENG COMP.697TCIC BS-IV:LPT1613	TATA spare parts
252501610250	ENGINE ASSY	TATA spare parts
252501610260	ENGINE ASSY BS6	TATA spare parts
252501610261	ASSY. ENGINE W/O COMPRESSOR 697CRDi BS4	TATA spare parts
252501610262	ENGINE ASSY W/O COMPRESSOR	TATA spare parts
252501610269	ENGINE ASSY	TATA spare parts
252501610270	ENGINE ASSY	TATA spare parts
252501610271	ENGINE ASSY	TATA spare parts
252501610273	ENGINE ASSY	TATA spare parts
252501610280	ASSY. ENGINE COMPLETE-697CRDi BS4 160HP	TATA spare parts
252501610283	ENGINE ASSY	TATA spare parts
252501610284	ENGINE ASSY BS6	TATA spare parts
252501610287	ENGINE ASSY	TATA spare parts
252501610293	ENGINE ASSY BS6	TATA spare parts
252501990103	LONG BLOCK 697NA	TATA spare parts
252501990104	LONG BLOCK 697TC	TATA spare parts
252501990107	ASSY.SHORT BLOCK	TATA spare parts
252501990109	SHORT BLOCK LP 613	TATA spare parts
252501990110	LONG BLOCK 697NA	TATA spare parts

252501990111	LONG BLOCK 697TC	TATA spare parts
252501990114	ENG. O/H GASKET KIT	TATA spare parts
252501990115	ENG.O/H GASKET KIT697TC W/O CYL HD GASKE	TATA spare parts
252501990117	HALF BLOCK-697NA	TATA spare parts
252501990118	HALF BLOCK 697NA CMVR-2K LP1510 RHD	TATA spare parts
252501990119	HALF BLOCK 697NA CMVR-2KLPT1613 RHD	TATA spare parts
252501990121	HALF BLOCK 697NA CMVR-2K1613SK RHD	TATA spare parts
252501990123	HALF BLOCK 697TC CMVR-2K1613SE RHD	TATA spare parts
252501990125	HALF BLOCK 697TC CMVR-2KLPT1613 RHD	TATA spare parts
252501990127	LONG BLOCK 697NA CMVR-2KLP1510 RHD	TATA spare parts
252501990129	LONG BLOCK 697NA CMVR-2K1613SK RHD	TATA spare parts
252501990130	ASSY LONG BLOCK 1613 SE CMVR2000	TATA spare parts
252501990131	LONG BLOCK 697TC-LPT1613 CMVR 2000	TATA spare parts
252501990136	LONG BLOCK-697NA CMVR 2K-LPT613 BS1	TATA spare parts
252501990138	HALF BLOCK-LPT613-697NA CMVR2K	TATA spare parts
252501990148	HALF BLOCK LPT1613 697TC 330CL	TATA spare parts
252501990149	LONG BLOCK LPT1613 697TC 330CL	TATA spare parts
252501990151	HALF BLOCK SE1613 697TC 330CL	TATA spare parts
252501990152	LONG BLOCK SE1613 697TC 330CL	TATA spare parts
252501990154	HALF BLOCK SK1613 697NA 330CL	TATA spare parts
252501990155	LONG BLOCK SK1613 697NA 330CL	TATA spare parts
252501990157	HALF BLOCK LPT1613 697TC 330CL	TATA spare parts
252501990158	LONG BLOCK LPT1613 697TC 330CL	TATA spare parts
252501990163	HALF BLOCK LP1510 697NA 330CL	TATA spare parts
252501990164	LONG BLOCK LP1510 697NA 330CL	TATA spare parts
252501990174	ASSY.LONG BLOCK LPT2515-697TC	TATA spare parts
252501990176	DECARBONISING KIT FOR 697 NA/TC ENGINE	TATA spare parts
252501990177	ASSY. HALF BLOCK(LPT613) EURO2	TATA spare parts
252501990178	LONG BLOCK LPT 613-EURO2	TATA spare parts
252501990181	ASSY.HALF BLOCK LPT2515-697TC	TATA spare parts
252501990183	ASSY HALF BLOCK-SK 1613 - 697 NA	TATA spare parts
252501990184	ASSY LONG BLOCK-SK 1613 - 697 NA	TATA spare parts
252501990187	ASSY.LONG BLOCK 697 TCIC E-II-2515	TATA spare parts
252501990188	ASSY.HALF BLOCK 697 TCIC E-II-2515	TATA spare parts
252501990191	ENGINE OVERHAUL GASKET KIT(697BSII)	TATA spare parts
252501990192	ASSY.LONG BLOCK SE/SK 1613-697TC BS-I	TATA spare parts
252501990193	ASSY.HALF BLOCK SE/SK 1613-697TC BS-I	TATA spare parts
252501990196	ASSY.LONG BLOCK LPT 1613-697 TC BS-I	TATA spare parts
252501990197	ASSY.HALF BLOCK LPT 1613-697TC BS-I	TATA spare parts
252501990201	ASSY.LONG BLOCK-SE/SK 1613 BS-II	TATA spare parts
252501990202	ASSY.HALF BLOCK-SE/SK 1613 BS-II	TATA spare parts
252501990205	ASSY.LONG BLOCK (LPT 1613 BS-II)	TATA spare parts
252501990206	ASSY.HALF BLOCK (LPT 1613 BS-II)	TATA spare parts
252501990213	ASSY.LONG BLOCK 697TCIC-BSII-2515 CAB	TATA spare parts
252501990214	ASSY.HALF BLOCK 697TCIC-BSII-2515 CAB	TATA spare parts
252501990217	ASSY.LONG BLOCK (697TCIC BSIII)	TATA spare parts
252501990218	ASSY.HALF BLOCK (697TCIC BSIII)	TATA spare parts

252501990221	ENGINE OVERHAUL GASKET KIT(697BSIII)	TATA spare parts
252501990222	SET ANTI VIBRATION PAD	TATA spare parts
252501990223	ASSY.HALF BLOCK LPT/LPK1613 BS-II	TATA spare parts
252501990224	ASSY LONG BLOCK(LPT/LPK1613) BS-II	TATA spare parts
252501990227	ASSY.HALF BLOCK SE/SK1613 BS-II	TATA spare parts
252501990228	ASSY.LONG BLOCK SE/SK1613 BS-II	TATA spare parts
252501990231	HALF BLOCK LPT2515BS-II W/ MECH FEED PUM	TATA spare parts
252501990232	LONG BLOCK 697TCIC W/ MECH FEED PUMP BS2	TATA spare parts
252501990235	ASSY. HALF BLOCK LPT 2516 BS-II	TATA spare parts
252501990236	ASSY LONG BLOCK	TATA spare parts
252501990239	ASSY. LONG BLOCK LPT 2518 BS-II	TATA spare parts
252501990241	HALF BLOCK-613 E-III	TATA spare parts
252501990243	LONG BLOCK- 613 E-III	TATA spare parts
252501990245	LONG BLOCK- 697 NA CNG BSIII ENGINE	TATA spare parts
252501990246	ASSY. HALF BLOCK 697 NA CNG BSIII	TATA spare parts
252501990247	ASSY. LONG BLOCK 697 NA CNG BSIII	TATA spare parts
252501990248	LONG BLOCK 697 NA CNG BSIII	TATA spare parts
252501990256	ASSY HALF BLOCK (697 TCIC BSIII 102 KW)	TATA spare parts
252501990257	ASSY LONG BLOCK (697 TCIC BSIII 102 KW)	TATA spare parts
252501990258	ASSY LONG BLOCK (TATA 5.7 SGI BSIV NA EN	TATA spare parts
252501990259	ASSY HALF BLOCK	TATA spare parts
252501990262	ASSY. LONG BLOCK 697CRDI BS4	TATA spare parts
252501990264	ASSY HALF BLOCK	TATA spare parts
252501990266	GASKET KITS (ENGINE OVER HAUL) LPO 1613	TATA spare parts
252501990267	DECARBONISING GASKET KIT LPO 1613 BSIV	TATA spare parts
252501990268	SET-INLET AND EXHAUST VALVE (60DEG)	TATA spare parts
252501990269	KIT INSERT EXHAUST/INTAKE	TATA spare parts
252501990270	LONG BLOCK (LPT 1613 BS-IV) SIDE ENTRY	TATA spare parts
252501990272	ASSY HALF BLOCK LPT 1613 BSIV SIDE ENTRY	TATA spare parts
252501990274	GASKET KITS (ENGINE OVER HAUL) LPT 1613	TATA spare parts
252501990275	DECARBONISING GASKET KIT LPT 1613 BSIV	TATA spare parts
252501990282	ASSY. LONG BLOCK 697CRDI BS4	TATA spare parts
252501990285	ASSY HALF BLOCK SE/SKç 1613 BSIV	TATA spare parts
252501990286	ASSY. LONG BLOCK 697CRDi BS4	TATA spare parts
252501990288	ASSY HALF BLOCK LPT 1613 COWL BSIV SIDE	TATA spare parts
252501990304	ASSY. LONG BLOCK LPT 1613 BS3	TATA spare parts
252501990306	LONG BLOCK ASSY 697 NA CMVR	TATA spare parts
252501990309	HALF BLOCK ASSY LPT1613 COWL CR BSIII	TATA spare parts
252501990311	KIT-GASKET ENG.OVERHAUAL 697CR BSIII	TATA spare parts
252501990314	LONG BLOCK ASSY (LP713 E-II)	TATA spare parts
252501990317	HALF BLOCK ASSY (LP713 E-II)	TATA spare parts
252501990318	LONG BLOCK ASSY (LPT 813 EII)	TATA spare parts
252501990325	ASSY. LONG BLOCK 697TCIC	TATA spare parts
252501990326	KIT-GASKET ENGINE OVERHAUL	TATA spare parts
252501990329	HALF BLOCK ASSY	TATA spare parts
252501990343	LONG BLOCK ASSY	TATA spare parts
252501990348	ASSY. LONG BLOCK 697CRDI BS4	TATA spare parts



252501990350	HALF BLOCK ASSY	TATA spare parts
252501990354	ASSY. LONG BLOCK 697CRDI BS4	TATA spare parts
252501990356	LONG BLOCK ASSY	TATA spare parts
252501990358	HALF BLOCK ASSY	TATA spare parts
252501990359	HALF BLOCK ASSY	TATA spare parts
252501990362	HALF BLOCK ASSY	TATA spare parts
252501990364	LONG BLOCK ASSY	TATA spare parts
252501990371	LONG BLOCK ASSY	TATA spare parts
252501990372	HALF BLOCK ASSY	TATA spare parts
252501990375	LONG BLOCK ASSY 697CRDI BS4	TATA spare parts
252501990382	LONG BLOCK ASSY	TATA spare parts
252503100144	CRANKSHAFT STD W/CWT NA	TATA spare parts
252503100145	CRANKSHAFT STD1 INTCWT NA	TATA spare parts
252503100146	CRANKSHAFT STD W/CWT TC	TATA spare parts
252503100147	CRANKSHAFT STD1 INTCWT TC	TATA spare parts
252503100237	ASSY. CRANKSHAFT WITH PIN(FOR PTFE SEAL)	TATA spare parts
252503103101	PILOT BEARING CRANKSHAFT	TATA spare parts
252503103103	SRDG BALL BEARING	TATA spare parts
252503103201	BOLT COUNTER WEIGHT	TATA spare parts
252503103202	HEX FL BOLT M12X1.5X33 TS17130 10.9	TATA spare parts
252503107801	RING SEALING HALF	TATA spare parts
252503107803	SEAL CRANKSHAFT REAR(PTFE)	TATA spare parts
252503107912	CRANKSHAFT STD	TATA spare parts
252503107919	697NA NOR CRANKSHAFT INTEGRAL	TATA spare parts
252503107920	CRANKSHAFT STD1 INTCWT NA	TATA spare parts
252503107928	CRANKSHAFT STD W/CWT TC	TATA spare parts
252503107929	CRANKSHAFT 697TC INT.N1	TATA spare parts
252503107932	CRANKSHAFT RS1 INTCWT NA	TATA spare parts
252503107934	CRANKSHAFT 697 NA/TC	TATA spare parts
252503107940	CRANKSHAFT - NORMAL BS1/2/3/4	TATA spare parts
252503107942	CRANKSHAFT NORMAL(FOR REAR PTFE SEAL)	TATA spare parts
252503107956	CRANK SHAFT-NORMAL (130PS E-III)	TATA spare parts
252503108201	LOCKING RING	TATA spare parts
252503110104	FLY WHEEL	TATA spare parts
252503110106	FLYWHEEL W/RING GEAR 310D	TATA spare parts
252503110107	FLYWHEEL W/RING GEAR 350D	TATA spare parts
252503110117	ASSY. FLYWHEEL W/RING GEAR BS2	TATA spare parts
252503110121	ASSY.? FLYWHEEL W/RING GEAR FOR 130 PS	TATA spare parts
252503110122	ASSY.FLYWHEEL-697TC 15D-STD/H.TOR-310CL	TATA spare parts
252503110123	ASSY FLYWHEEL WITH RING GEAR CMVR 2K1510	TATA spare parts
252503110124	ASSY FLYWHEEL WITH RING GEAR-697NACMVR	TATA spare parts
252503110126	FLYWHEEL 125T 15 DEGREE 697 BS1/2/3	TATA spare parts
252503110126DF	FLYWHEEL CI 15DEG 125T 697BS2	TATA spare parts
252503110127	ASSY.FLYWHEEL(697NA-110PS:11-1DEG)330CL	TATA spare parts
252503110128	FLYWHEEL 125T 11 DEGREE 697 BS1 330 DIA	TATA spare parts
252503110128DF	FLYWHEEL CI 11DEG 697BS2/330 CLUTCH	TATA spare parts
252503110130	ASSY.FLYWHEEL WITH RING GEAR-10+/-1DEG	TATA spare parts

252503110132	ASSY FLYWHEEL W/RING GEAR 146T 697 BS3	TATA spare parts
252503110132DF	FLYWHEEL SG 697BS3 1613 HIGH APP	TATA spare parts
252503110133	ASSY. FLYWHEEL WITH RING GEAR	TATA spare parts
252503110136	ASSY.FLYWHEEL W/ RING GEAR & WEAR PLATE	TATA spare parts
252503110138	ASSY. FLYWHEEL WITH RING GEAR	TATA spare parts
252503110139	ASSY FLYWHEEL WITH RING GEAR 697 CNG	TATA spare parts
252503110141	ASSY FLYWHEEL WITH RING GEAR	TATA spare parts
252503110142	ASSY FLYWHEEL WITH RING GEAR 697 NA CNG	TATA spare parts
252503110143	ASSY. FLYWHEEL WITH RING GEAR - 697 CNG	TATA spare parts
252503110145	ASSY. FLYWHEEL W/RING GEAR BS4	TATA spare parts
252503110151	FLYWHEEL ASSEMBLY WITH WEAR PLATE	TATA spare parts
252503110157	ASSY. FLYWHEEL W/RING GEAR BS3/4	TATA spare parts
252503110161	FLYWHEEL ASSY WITH RING GEAR	TATA spare parts
252503110166	FLYWHEEL ASSY WITH RING GEAR BS6	TATA spare parts
252503110175	FLYWHEEL ASSY WITH RING GEAR BS6	TATA spare parts
252503110176	FLYWHEEL ASSY WITH RING GEAR BS6-PH2	TATA spare parts
252503113701	HOUSING FLYWHEEL 697NA	TATA spare parts
252503113709	HOUSING FLYWHEEL 697NA EX	TATA spare parts
252503113710	HOUSING FLYWHEEL 697TC	TATA spare parts
252503113714	HOUSING FLYWHEEL 697TC	TATA spare parts
252503113719	HOUSING FLYWHEEL 697TC	TATA spare parts
252503113721	FLYWHEEL HSG.(352DIA.SPICER CLUTCH):CAST	TATA spare parts
252503113722	FLYWHEEL HOUSING-EX-100 EXCAVATOR	TATA spare parts
252503113724	FLYWHEEL HOUSING BS3/EURO3	TATA spare parts
252503113726	FLYWHEEL HOUSING	TATA spare parts
252503113729	FLYWHEEL HOUSING BS6	TATA spare parts
252503115404	RING GEAR	TATA spare parts
252503115454	RING GEAR 697TC LPT2515EX BS2/3/4	TATA spare parts
252503117101	WEAR PLATE-FLYWHEEL ( FOR 352 DIA CLUTCH	TATA spare parts
252503118201	COVER	TATA spare parts
252503118203	BACK COVER	TATA spare parts
252503118204	COVER	TATA spare parts
252503118209	COVER CLUTCH HOUSING	TATA spare parts
252503118210	COVER BS6	TATA spare parts
252503120101	SET MAIN BRG STD	TATA spare parts
252503120102	SET MAIN BRG STD1	TATA spare parts
252503120103	SET MAIN BRG RS1	TATA spare parts
252503120104	SET MAIN BRG RS2	TATA spare parts
252503120105	SET MAIN BRG RS3	TATA spare parts
252503120106	SET MAIN BRG RS4	TATA spare parts
252503120110	SET CON ROD BRG STD	TATA spare parts
252503120111	SET CON ROD BRG STD1	TATA spare parts
252503120112	SET CON ROD BRG RS1	TATA spare parts
252503120113	SET CON ROD BRG RS2	TATA spare parts
252503120114	SET CON ROD BRG RS3	TATA spare parts
252503120115	SET CON ROD BRG RS4	TATA spare parts
252503120116	M/BRG SET STD	TATA spare parts

252503120122	SET THRUST WASHER STD	TATA spare parts
252503120123	SET THRUST WASHER STD1	TATA spare parts
252503120124	SET THRUST WASHER STD2	TATA spare parts
252503120125	M B SET W/O T/W STD	TATA spare parts
252503120126	SET MAIN BRG W/O THW STD1	TATA spare parts
252503120127	SET MAIN BRG W/O THW RS1	TATA spare parts
252503120128	SET MAIN BRG W/O THW RS2	TATA spare parts
252503120129	SET MAIN BRG W/O THW RS3	TATA spare parts
252503120130	SET MAIN BRG W/O THW RS4	TATA spare parts
252503120133	SET MAIN BRG W/THW STD	TATA spare parts
252503120134	SET MAIN BRG W/THW STD1	TATA spare parts
252503120135	SET MAIN BRG W/THW RS1	TATA spare parts
252503120136	SET MAIN BRG W/THW RS2	TATA spare parts
252503120137	SET MAIN BRG W/THW RS3	TATA spare parts
252503120138	SET MAIN BRG W/THW RS4	TATA spare parts
252503120139	M B SET W/O T/W STD	TATA spare parts
252503120140	SET MAIN BRG W/O THW STD1	TATA spare parts
252503120143	M B SET W/O T/W STD	TATA spare parts
252503120144	SET M/BRG UP./LOW. STD I	TATA spare parts
252503120145	SET THRUST WASHER UPP/LOWER STD	TATA spare parts
252503120146	SET THRUST WASHER UPP/LOW STD	TATA spare parts
252503120159	SET MAIN BRG.UPPER/LOWER NORMAL EURO III	TATA spare parts
252503120161	SET MAIN BRG.UPPER/LOWER NORMAL EURO III	TATA spare parts
252503123105	MAIN BEARING - UPPER NORM	TATA spare parts
252503123107	MAIN BEARING-LOWER NORMAL	TATA spare parts
252503123438	THRUST WASHER LOW STD	TATA spare parts
252503123439	THRUST WASHER LOW STD1	TATA spare parts
252503123442	THRUST WASHER UPP STD	TATA spare parts
252503123443	THRUST WASHER UPP STD1	TATA spare parts
252503123445	THRUST WASHER LOWER STD	TATA spare parts
252503123446	THRUST WASHER UPPER STD	TATA spare parts
252503130106	VIBRATION DAMPER	TATA spare parts
252503130107	VIBRATION DAMPER 2GR	TATA spare parts
252503130108	ASSY VIBRATION DAMPER DOUBLE GROOVE	TATA spare parts
252503130110	ASSY VIBRATION DAMPER	TATA spare parts
252503130119	VIBRATION DAMPER 2GR	TATA spare parts
252503130120	ASSY.VIBRATION DAMPER-SINGLE GROOVE.	TATA spare parts
252503130123	ASSY.VIBRATION DAMPER-SINGLE GROOVE.	TATA spare parts
252503130130	ASSY. VIBRATION DAMPER 697 NA CNG BSIII	TATA spare parts
252503130139	ASSEMBLY VIBRATION DAMPER	TATA spare parts
252503130144	ASSY VIBRATION DAMPER PULLEY (8PK)	TATA spare parts
252503130148	ASSY. VIBRATION DAMPER -TC	TATA spare parts
252503130151	VIBRATION DAMPER ASSY BS6	TATA spare parts
252503130153	VIBRATION DAMPER ASSY WITH PULLEY	TATA spare parts
252503137004	PULLEY FOR PS PUMP	TATA spare parts
252503137006	CRANKSHAFT PULLEY	TATA spare parts
252503137012	PULLEY CRANKSHAFT	TATA spare parts

252503137015	PULLEY CRANKSHAFT	TATA spare parts
252503137023	PULLEY FOR AC DRIVE	TATA spare parts
252503137025	DAMPER PULLEY	TATA spare parts
252503138201	OIL SLINGER	TATA spare parts
252503138603	SPACER (SUITABLE FOR SLINGER).	TATA spare parts
252503140109	SET PISTON RINGS STD TC	TATA spare parts
252503140111	SET PISTON RINGS RS1	TATA spare parts
252503140128	PISTON ASSY 96.95D STD	TATA spare parts
252503140155	RING PISTON CONF OIL	TATA spare parts
252503140161	CONFORMABLE OIL RING STDI	TATA spare parts
252503140163	CONFORMABLE OIL RING R/SI	TATA spare parts
252503140165	SET PISTON RINGS STD 4RV	TATA spare parts
252503140166	SET PISTON RINGS STD1 4RV	TATA spare parts
252503140168	SET PISTON RINGS RS1 4RV	TATA spare parts
252503140170	SET PISTON BARE STD	TATA spare parts
252503140178	SET PISTON W/RINGS STD	TATA spare parts
252503140181	SET PISTON W/RINGS RS1	TATA spare parts
252503140182	SET PISTON W/RINGS RS2	TATA spare parts
252503140196	SET PISTON W/RINGS STD	TATA spare parts
252503140217	SET-ASSY PISTON WITH RINGS	TATA spare parts
252503140225	SET PISTON RINGS STD 3RV	TATA spare parts
252503140237	SET PISTON BARE STD 3RV	TATA spare parts
252503140354	ASSY.PISTON WITH RINGS	TATA spare parts
252503140355	ASSY.OIL CONTROL RING GROOVE III	TATA spare parts
252503140358	ASSY.PISTON WITH RINGS	TATA spare parts
252503140363	SET ASSY. PISTON GEOTZE WITH GEOTZE RING	TATA spare parts
252503140366	PISTON ASSY WITH RINGS PIN & CIRCLIP	TATA spare parts
252503140373	SET ASSY.PISTON WITH RINGS & PISTON PIN	TATA spare parts
252503140378	SET-PISTON ASSY WITH RING & PIN	TATA spare parts
252503140390	SET-PISTON ASSY WITH RING & PIN BS6	TATA spare parts
252503140392	PISTON ASSY WITH PIN & CIRCLIP BS6-PH2	TATA spare parts
252503141050	PISTON STD 96.890 DIA	TATA spare parts
252503141051	PISTON STD 96.900 DIA	TATA spare parts
252503141052	BARE PISTON 97 STD 3RV TC	TATA spare parts
252503141069	PISTON STD 96.90D 3RV	TATA spare parts
252503141070	ALUMINIUM PISTON STD 96.91 DIA	TATA spare parts
252503141076	PISTON 96.87DIA	TATA spare parts
252503141077	PISTON STD 96.88D 3RV	TATA spare parts
252503141078	PISTON STD 96.89 DIA	TATA spare parts
252503141091	PISTON 96.89DIA	TATA spare parts
252503141093	PISTON 697 CNG BSIII (NORMAL III) 96.90	TATA spare parts
252503144301	CIRCLIP	TATA spare parts
252503144304	FLAT CIRCLIP	TATA spare parts
252503146701	PISTON PIN	TATA spare parts
252503146702	GUDGEON PIN (M/S MENON PISTONS)	TATA spare parts
252503146704	PISTON PIN	TATA spare parts
252503146705	PISTON PIN 697 CNG BSIII	TATA spare parts

252503149927	DOUBLE TRAPEZE RING GR I 97 DIA	TATA spare parts
252503149931	COMPRESSION RING GR II 97 DIA.	TATA spare parts
252503149942	MOLYBDENUM COATED TRAPEZOIDAL RING (GIL)	TATA spare parts
252503149943	RING PISTON 2ND 3RV	TATA spare parts
252503149946	RING TOP 697NA GR1	TATA spare parts
252503149951	NAPIER RING GROOVE II (M/S IPL)	TATA spare parts
252503149952	COMPR.RING GR.II	TATA spare parts
252503149960	PISTON RING-GR-I	TATA spare parts
252503149961	TAPER COMP W/ID STEP RING-GR-II	TATA spare parts
252503149964	INTER.STEPPED KEYSTONE RING TOP	TATA spare parts
252503149965	INTER STEPPED COMPRESSION RING (GOETZE)	TATA spare parts
252503150107	CONNECTING ROD SERRATED	TATA spare parts
252503150117	SET-CON ROD/BUSH NORMAL BS6	TATA spare parts
252503150119	ASSY CONROD W/RS1 BUSH	TATA spare parts
252503150125	ASSY CON ROD W/BUSH NON-SERRATED	TATA spare parts
252503150149	ASSY. CONNECTING ROD WITH BUSH & BOLT FR	TATA spare parts
252503150167	CONNECTING ROD ASSY WITH BUSH & BOLT BS6	TATA spare parts
252503153103	CON ROD BEARING- NORMAL	TATA spare parts
252503153201	BOLT CON ROD	TATA spare parts
252503153203	BOLT	TATA spare parts
252503153204	CONNECTING ROD BOLT-FULLY THREADED	TATA spare parts
252503153205	CONNECTING ROD SCREW.	TATA spare parts
252503153206	BOLT CONNECTING ROD	TATA spare parts
252503160102	ASY SPRG LOADED CONF OIL RING STD GR III	TATA spare parts
252503160107	PISTON ASSY 96.89D STD	TATA spare parts
252503160124	ASSY CONFORMABLE OIL RING	TATA spare parts
252503160126	SET PISTON W/RINGS 3R NA	TATA spare parts
252503160127	SET PISTON W/RINGS STD	TATA spare parts
252503160128	SET PISTON W/RINGS STD	TATA spare parts
252503160130	SET PISTON BARE 3RV	TATA spare parts
252503160131	SET PISTON BARE 3RV	TATA spare parts
252503160138	SET PISTON BARE 3RV	TATA spare parts
252503160157	SET PISTON BARE 3RV	TATA spare parts
252503160180	PISTON SET W/RINGS 697NA	TATA spare parts
252503161036	PISTON (96.88 --17MM TOP LAND)	TATA spare parts
252503161044	BARE PISTON 97 STD 3RV	TATA spare parts
252503171005	PISTON STD.96.89 130PSBSII	TATA spare parts
252503990105	SET MAIN BRG W/O THW RS1	TATA spare parts
252503990106	SET MAIN BRG W/O THW RS2	TATA spare parts
252503990107	SET MAIN BRG W/O THW RS3	TATA spare parts
252503990108	SET MAIN BRG W/O THW RS4	TATA spare parts
252503990116	M B SET UPPER/LOWER R/S I	TATA spare parts
252503990117	M B SET UPPER/LOW. R/S II	TATA spare parts
252503990118	M B SET UPPE/LOWE.R/S III	TATA spare parts
252503990119	M B SET UPPE./LOWE.R/S IV	TATA spare parts
252503990120	CON ROD BRG SET R/S I	TATA spare parts
252503990121	CON ROD BRG SET R/S II	TATA spare parts

252503990122	CON ROD BRG SET RS III	TATA spare parts
252503990123	CON ROD BRG SET R/S IV	TATA spare parts
252503990124	SET CON ROD BRG STD	TATA spare parts
252503990125	CON ROD BRG SET STD I	TATA spare parts
252503990126	SET BARE PISTON 697NA/TC CMVR-2K	TATA spare parts
252503990129	SET PISTON RING 697NA/TC CMVR-2K	TATA spare parts
252503990148	SET-BARE PISTON 697TCIC BS2/3	TATA spare parts
252503990153	SET-BARE PISTON-697TCIC_BSII	TATA spare parts
252503990155	SET-PISTON RINGS 697CRDI BS2	TATA spare parts
252503990161	SET-PISTON-STD-(BS-III)	TATA spare parts
252503990164	SET-PISTON RINGS (BS-III)	TATA spare parts
252503990165	SET-CON ROD BRG-NORMAL (BS-III)	TATA spare parts
252503990167	CON. ROD BUSH SET STD	TATA spare parts
252503990179	SET-PISTON RINGS (BS-III)	TATA spare parts
252503990182	SET-PISTON W/PIN & CIRCLIPS 697 NA BS3/4	TATA spare parts
252503990183	SET-PISTON RINGS 697NA CNG BS3/4	TATA spare parts
252503990188	SET-PISTON RINGS BS3/4	TATA spare parts
252503990194	SET CON ROD BRG	TATA spare parts
252503990196	SET-CONNECTING ROD/BUSH	TATA spare parts
252503990197	PISTON WITH PIN & CIRCLIP BS3/4	TATA spare parts
252503990227	SET-PISTON ASSY WITH PIN & CIRCLIP	TATA spare parts
252503990228	SET-PISTON RING	TATA spare parts
252503990233	SET-PISTON ASSY WITH PIN & CIRCLIP	TATA spare parts
252503990234	SET-PISTON RING STD	TATA spare parts
252505100109	SET CAMSHAFT BEARING	TATA spare parts
252505100114	CAMSHAFT 697NA DAOH STD	TATA spare parts
252505100115	ASSY.CAM SHAFT WITH CYL.P	TATA spare parts
252505100118	CAMSHAFT 697TC DAOH STD	TATA spare parts
252505100122	SET CAMSHAFT BEARING	TATA spare parts
252505100125	CAMSHAFT 697NA SCAM STD	TATA spare parts
252505100126	CAMSHAFT 697NA SCAM STD1	TATA spare parts
252505100127	ASSY.CAM SHAFT 697 S-CAM	TATA spare parts
252505100132	CAMSHAFT 697TC SCAM STD	TATA spare parts
252505100140	CAMSHAFT 697NA SCAM STD BS1/2/3	TATA spare parts
252505100143	ASSY. CAMSHAFT WITH PIN	TATA spare parts
252505100145	ASSY. CAMSHAFT W/CYL. PIN-NORMAL BS2/3/4	TATA spare parts
252505103201	BOLT (CAM SHAFT GEAR MTG)	TATA spare parts
252505107958	CAM SHAFT NORMAL-S-CAM	TATA spare parts
252505107965	CAMSHAFT NORMAL	TATA spare parts
252505107976	CAMSHAFT NORMAL 697 NA CNG BSIII	TATA spare parts
252505107982	CAMSHAFT BS6	TATA spare parts
252505108601	SPACER FOR CAM SHAFT	TATA spare parts
252505115401	CAM SHAFT TIMING GEAR	TATA spare parts
252505115402	CAMSHAFT GEAR (HIGH MODULE)	TATA spare parts
252505115406	CAM SHAFT GEAR - 697 CNG BSIV	TATA spare parts
252505120101	VALVE KIT MNR	TATA spare parts
252505120102	VALVE KIT MJR	TATA spare parts

252505124301	LOCK HALF BS6-PH2	TATA spare parts
252505125102	LOCK RETAINER VALVE SPG	TATA spare parts
252505129012	INLET VALVE TUFTRIDED	TATA spare parts
252505129013	EXHAUST VALVE TUFTRIDED	TATA spare parts
252505129016	INLET VALVE(STELLITE TUFFTRIED)	TATA spare parts
252505129017	EXHAUST VALVE(STELLITE TUFFTRIDED)	TATA spare parts
252505129018	INLET VALVE(60 DEG) BS1/2/3/4	TATA spare parts
252505129020	INLET VALVE (60 DEG)	TATA spare parts
252505129021	INLET VALVE 60 DEG INDUCTION HARDENED	TATA spare parts
252505129023	INLET VALVE 60DEG INDUCTION HARDENED	TATA spare parts
252505129031	INLET VALVE 697 EURO IV	TATA spare parts
252505129034	INLET VALVE (TATA 5.7 BS IV - TCIC) BS6	TATA spare parts
252505129046	EXHAUST VALVE BS6	TATA spare parts
252505129047	EXHAUST VALVE BS6	TATA spare parts
252505129048	INTAKE VALVE BS6	TATA spare parts
252505129049	INTAKE VALVE BS6-PH2	TATA spare parts
252505129050	EXHAUST VALVE BS6-PH2	TATA spare parts
252505140103	ASSY.ROCKER ARM WITH BALL PIN LH	TATA spare parts
252505140104	ASSY.ROCKER ARM WITH BALL PIN RH	TATA spare parts
252505140105	ASSY.ROCKER ARM SHAFT WITH ROCKER ARM F.	TATA spare parts
252505140106	ASSY.ROCKER ARM SHAFT WITH ROCKER ARM R.	TATA spare parts
252505140108	ASSY. ROCKER ARM WITH BUSH&INSERT-RH	TATA spare parts
252505140109	ASSY.ROCKER ARM WITH BUSH&INSERT - LH	TATA spare parts
252505140112	ASSY.ROCKER ARMSHAFT WITH ROCKER ARM-F.	TATA spare parts
252505140113	ASSY.ROCKER ARMSHAFT WITH ROCKER ARM-F.	TATA spare parts
252505140116	ASSY ROCKER ARM SHAFT WITH R/A (FRONT)	TATA spare parts
252505140117	ASSY ROCKER ARM SHAFT WITH R/A (REAR)	TATA spare parts
252505140120	ASSY ROCKER ARM LEFT WITH BUSH	TATA spare parts
252505140121	ASSY ROCKER ARM RIGHT WITH BUSH	TATA spare parts
252505153402	VALVE GUIDE INLET STD	TATA spare parts
252505153403	VALVE GUIDE INLET STD1	TATA spare parts
252505153407	VALVE GUIDE EXHAUST STD	TATA spare parts
252505153408	VALVE GUIDE EXHAUST STD1	TATA spare parts
252505153423	VALVE GUIDE INLET - STANDARD	TATA spare parts
252505153433	VALVE GUIDE INTAKE BS6	TATA spare parts
252505155102	LOCK RETAINER VALVE SPG	TATA spare parts
252505158703	VALVE SPRING	TATA spare parts
252505159903	SEAL VALVE STEM BS6	TATA spare parts
252505160102	ASSY.PUSH ROD-TUBULAR	TATA spare parts
252505167901	PUSH ROD	TATA spare parts
252505990103	SET INLET & EXHAUST VALVES 697NA BS1/2/3	TATA spare parts
252505990108	SET-VALVE GUIDE SEAL INLET/EXHAUST 6CYL	TATA spare parts
252505990120	SET CAM SHAFT BUSH	TATA spare parts
252507100110	LEVER ASSY	TATA spare parts
252507100141	LEVER W/BALL PIN	TATA spare parts
252507100163	F I PUMP RSV 115 PS	TATA spare parts
252507100207	LEVER FOR AIR CYLINDER	TATA spare parts

252507100210	F I PUMP RQV W/IDL.UNIT	TATA spare parts
252507100211	ASSY LEVER COMPLETE	TATA spare parts
252507100232	F I PUMP RQV W/IDL.UNIT	TATA spare parts
252507100242	ASSY.LEVER COMPLETE	TATA spare parts
252507100271	F I PUMP RQV W/IDL.UNIT	TATA spare parts
252507100273	F I PUMP RQV W/IDL.UNIT	TATA spare parts
252507100276	F I PUMP RQV W/IDL.UNIT	TATA spare parts
252507100294	F I PUMP RSV W/IDL.UNIT	TATA spare parts
252507100299	ASSY RSV FIP W/IDLING	TATA spare parts
252507100332	ASSY.CONTROL SHAFT	TATA spare parts
252507100342	FUEL INJECTION PUMP-130HP	TATA spare parts
252507100354	ASSY FIP 697NA CMVR 1613SK	TATA spare parts
252507100360	ASSY PULL ROD WITH FORK1510/1613	TATA spare parts
252507100364	FUEL INJ PUMP LPT1613 TURBO CMVR 2K	TATA spare parts
252507100365	ASSY.CONTROL SHAFT VERTICAL DIPSTICK	TATA spare parts
252507100374	ASSY FIP (ROTARY) 24V BS II	TATA spare parts
252507100381	LOW PRESSURE REGULATOR	TATA spare parts
252507100399	ASSY.FIP-ROTARY(12V) 697	TATA spare parts
252507103101	INTEGRAL SHAFT BEARING(FEED PUMP)	TATA spare parts
252507103102	INTEGRAL SFT BRG.(MECH. FEED PUMP) BS2/3	TATA spare parts
252507103803	ADAPTOR PLATE (DOUBLE BALL BRG.ARRGT.)	TATA spare parts
252507105303	GASKET (MECH.FEED PUMP)	TATA spare parts
252507105402	INJ.PUMP GEAR (MECH.FEED PUMP)	TATA spare parts
252507106903	SPACER	TATA spare parts
252507107911	PULL ROD	TATA spare parts
252507107918	SHAFT (ELECTRONIC IGNITION DRIVE)	TATA spare parts
252507108203	COVER (ELECTRONIC IGNITION)	TATA spare parts
252507108603	SLEEVE 115 LONG-V.DIP FOR TC CMVR	TATA spare parts
252507109201	WASHER	TATA spare parts
252507109901	CAM (MECH.FEED PUMP) BS2/3	TATA spare parts
252507109902	SPIDER-(MECH.FEED PUMP)	TATA spare parts
252507109905	HOUSING COVER	TATA spare parts
252507109906	O - RING	TATA spare parts
252507109907	SHAFT	TATA spare parts
252507109908	COILED SPRING	TATA spare parts
252507109909	SHIM	TATA spare parts
252507110103	ASSY LEVER	TATA spare parts
252507110107	ASSY. CNG REGULATOR	TATA spare parts
252507110108	ASSY. CNG REGULATOR WITH CONNECTORS	TATA spare parts
252507110109	ASSY. CNG INJECTOR BS4	TATA spare parts
252507116801	CONN. 7/16IN-20 UNF-2A X 1/4IN-18NPT	TATA spare parts
252507116802	CNG OUTLET CONNECTOR	TATA spare parts
252507116803	CONNECTOR (M18X1.5) X 3/8IN NPT	TATA spare parts
252507116804	COOLANT CONNECTOR	TATA spare parts
252507117703	O RING - CNG INJECTOR TOP (SQT)	TATA spare parts
252507117704	O RING - CNG INJECTOR BOTTOM (SQT)	TATA spare parts
252507120108	ASSY.FIP 130PS @ 2800RPM FOR LP613 CMVR	TATA spare parts



252507120111	ASSY.FIP	TATA spare parts
252507120112	ASSY.FIP(12V)697TC-E-II-TRUCK	TATA spare parts
252507120117	ASSY.FIP-MICO-VE6	TATA spare parts
252507120118	ASSY.FEED PUMP(MECHANICAL)	TATA spare parts
252507120122	ASSY.LDA LINE-ELBOW TO FIP	TATA spare parts
252507120124	ASSY.FIP BS III 697 TCIC BUS APPLICATIO	TATA spare parts
252507120126	ASSY FIP (ROTARY) 145HP BS II	TATA spare parts
252507120127	ASSY.FIP(24V)LP 613	TATA spare parts
252507120134	ASSY. FUEL INJECTION PUMP BS2	TATA spare parts
252507120136	ASSY.FIP	TATA spare parts
252507120138	ASSY.FEED PUMP(MECH)	TATA spare parts
252507120147	ASSY. FIP (ROTARY) EURO III	TATA spare parts
252507120156	ASSY. FUEL INJECTION PUMP 697CRDI BS3/4	TATA spare parts
252507120166	ASSY. FUEL INJECTION PUMP 100KW BS3	TATA spare parts
252507123301	REAR SUPPORT BRACKET-FIP TO CYL.BLOCK	TATA spare parts
252507123302	REAR SUPPORT BRACKET(FIP TO BLOCK)E-III	TATA spare parts
252507123303	CLAMP ON CYLINDER BLOCK (FOR HP LINES)	TATA spare parts
252507123701	SUPPORT-INJ.PUMP(O RING)-IN LINE PUMP.	TATA spare parts
252507123702	SUPPORT (FIP - BS-II)	TATA spare parts
252507123704	SUPPORT ( FOR FUEL INJECTION PUMP CB:18	TATA spare parts
252507123708	SUPPORT (FOR FUEL INJECTION PUMP)	TATA spare parts
252507123801	SUPPORT PIECE (FOR HP LINES)	TATA spare parts
252507124203	CLAMP - CNG INJECTORS DUAL	TATA spare parts
252507125302	GASKET (FIP SUPPORT PLATE TO TGH)	TATA spare parts
252507129201	HARDENED WASHER	TATA spare parts
252507130121	ASSY. BRACKET (MTG.FUEL SHUT OFF VALVE)	TATA spare parts
252507130123	ASSY CAM SHAFT GEAR AND DRIVE GEAR(FIP)	TATA spare parts
252507135403	INJECTION PUMP GEAR FOR PUMP	TATA spare parts
252507136701	BALL PIN	TATA spare parts
252507136702	BALL PIN (FIP)	TATA spare parts
252507140101	SET FUEL PR LINES TC	TATA spare parts
252507140102	PRESSURE LINE 1ST	TATA spare parts
252507140103	PRESSURE LINE 2ND	TATA spare parts
252507140104	PRESSURE LINE 3RD	TATA spare parts
252507140105	PRESSURE LINE 4TH	TATA spare parts
252507140106	PRESSURE LINE 5TH	TATA spare parts
252507140107	PRESSURE LINE 6TH	TATA spare parts
252507140108	PRESSURE LINE 1ST	TATA spare parts
252507140109	PRESSURE LINE 2ND	TATA spare parts
252507140110	PRESSURE LINE 3RD	TATA spare parts
252507140111	PRESSURE LINE 4TH	TATA spare parts
252507140112	PRESSURE LINE 5TH	TATA spare parts
252507140113	PRESSURE LINE 6TH	TATA spare parts
252507140114	SET FUEL PR LINES NA	TATA spare parts
252507140124	HIGH PR LINE NO.1 697 NA	TATA spare parts
252507140125	HIGH PR LINE NO.2 697NA	TATA spare parts
252507140126	HIGH PR LINE NO.3 697NA	TATA spare parts

252507140127	HIGH PR. LINE NO.4 697NA	TATA spare parts
252507140128	HIGH PR. LINE NO.5 697NA	TATA spare parts
252507140129	HIGH PR. LINE NO.6 697NA	TATA spare parts
252507140139	FUEL LEAKAGE LINE CMVR 2K1510/1613	TATA spare parts
252507140141	ASSY.FUEL PRESSURE LINE NO.1 (BENT)	TATA spare parts
252507140142	ASSY.FUEL PRESSURE LINE NO.2 (BENT)	TATA spare parts
252507140143	ASSY.FUEL PRESSURE LINE NO.3 (BENT)	TATA spare parts
252507140144	ASSY.FUEL PRESSURE LINE NO.4 (BENT)	TATA spare parts
252507140145	ASSY.FUEL PRESSURE LINE NO.5 (BENT)	TATA spare parts
252507140146	ASSY.FUEL PRESSURE LINE NO.6 (BENT)	TATA spare parts
252507140149	SET FUEL PRESSURE LINES 697NA CMVR	TATA spare parts
252507140156	SET FUEL PRESSURE LINES 697TC CMVR	TATA spare parts
252507140158	ASSY. FUEL PR. LINE NO.1 (BENT) EURO2	TATA spare parts
252507140159	ASSY. FUEL PR. LINE NO.2 (BENT) EURO2	TATA spare parts
252507140160	ASSY. FUEL PRESSURE LINE NO.3 (BENT) E2	TATA spare parts
252507140161	ASSY. FUEL PRESS. LINE NO.4(BENT) EURO2	TATA spare parts
252507140162	ASSY. FUEL PR. LINE NO.5 (BENT) EURO2	TATA spare parts
252507140163	ASSY. FUEL PR. LINE NO.6 (BENT) EURO2	TATA spare parts
252507140164	KIT-HP LINES-ROTARY PUMP BS2/3	TATA spare parts
252507140167	KIT H.P.LINES (ROTARY FIP) BS2/3	TATA spare parts
252507140168	ASSY.FUEL PRESSURE LINE NO.1 (BENT)	TATA spare parts
252507140169	AASY.FUEL PRESSURE LINE NO.2 (BENT)	TATA spare parts
252507140170	ASSY.FUEL PRESSURE LINE NO.3 (BENT)	TATA spare parts
252507140171	ASSY.FUEL PRESSURE LINE NO.4 (BENT)	TATA spare parts
252507140172	ASSY.FUEL PRESSURE LINE NO.5 (BENT)	TATA spare parts
252507140173	ASSY.FUEL PRESSURE LINE NO.6 (BENT)	TATA spare parts
252507140175	ASSY.CLAMP (FOR H.P.LINES)	TATA spare parts
252507140187	KIT OF H.P. LINES (ROTORY PUMP)	TATA spare parts
252507140190	ASSY. FUEL RAIL (697 EURO4) BS3/4	TATA spare parts
252507140193	ASSY FUEL PRESSURE LINE 1 (BENT) : RAIL	TATA spare parts
252507140194	ASSY FUEL PRESSURE LINE 2 (BENT) : RAIL	TATA spare parts
252507140203	SET ASSEMBLY FUEL PRESSURE LINES 1&2 WIT	TATA spare parts
252507140204	ASSY FUEL PRESSURE LINE 1 (BENT) FIPC	TATA spare parts
252507140205	ASSY FUEL PRESSURE LINE 2 (BENT) FIPC	TATA spare parts
252507140221	HIGH PRESSURE LINE ASSEMBLY 1	TATA spare parts
252507140222	HIGH PRESSURE LINE ASSEMBLY 2	TATA spare parts
252507140223	HIGH PRESSURE LINE ASSEMBLY 3	TATA spare parts
252507140224	ASSEMBLY HIGH PRESSURE LINE .4	TATA spare parts
252507140225	HIGH PRESSURE LINE ASSEMBLY 5	TATA spare parts
252507140226	HIGH PRESSURE LINE AASSEMBLY 6	TATA spare parts
252507140229	ASSY.H.P LINES WITH CLAMPS SUPPORTS &FAS	TATA spare parts
252507140243	ASSY FUEL PRESSURE LINE 1 (BENT) : RAIL	TATA spare parts
252507140244	ASSEMBLY FUEL PRESSURE LINE 2 (BENT) : R	TATA spare parts
252507140245	ASSEMBLY FUEL PRESSURE LINE 3 (BENT) : R	TATA spare parts
252507140246	ASSEMBLY FUEL PRESSURE LINE 4 (BENT) : R	TATA spare parts
252507140247	ASSEMBLY FUEL PRESSURE LINE 5 (BENT) : R	TATA spare parts
252507140248	ASSEMBLY FUEL PRESSURE LINE 6 (BENT) : R	TATA spare parts

252507140252	KIT-HP LINES CLAMPS & ISOLATORS BS2/3	TATA spare parts
252507140260	SET HP LINE ASSEMBLY- 697 BS II	TATA spare parts
252507140266	SET : ASSEMBLY FUEL PRESSURE LINES 1&2 W	TATA spare parts
252507140267	ASSEMBLY FUEL PRESSURE LINE 1 (BENT)	TATA spare parts
252507140268	ASSEMBLY FUEL PRESSURE LINE 2 (BENT)	TATA spare parts
252507140274	ASSY CNG HOSE 9.5 BAR-1000MM (SQT)	TATA spare parts
252507140291	SET ASSY FUEL PRESSURE LINES 1&2 WITH BR	TATA spare parts
252507140294	ASSY CNG LP HOSE-1150MM LONG	TATA spare parts
252507140297	ASSY CNG RAIL WITH INJECTORS AND SENSORE	TATA spare parts
252507140319	CNG RAIL ASSY WITH INJ & SENSOR 5.7 TC	TATA spare parts
252507140320	CNG RAIL (EXTRUDED) SUB ASSEMBLY 5.7 SGI	TATA spare parts
252507140341	HOSE ASSY CNG LP 5/8IN-18UNFX7/8IN-14UNF	TATA spare parts
252507140345	LP HOSE ASSY	TATA spare parts
252507140346	CNG RAIL ASSY WITH INJECTOR & SENSOR	TATA spare parts
252507140350	CNG RAIL ASSY WITH INJECTOR & SENSORBS6	TATA spare parts
252507140351	LP HOSE ASSY BS6	TATA spare parts
252507140354	SUPPORT BRACKET FUEL LINES ASSY BS6	TATA spare parts
252507140356	LP HOSE ASSY BS6	TATA spare parts
252507140357	LP HOSE ASSY BS6-PH2	TATA spare parts
252507140369	BRACKET ASSY BS6-PH2	TATA spare parts
252507140370	BRACKET ASSY BS6-PH2	TATA spare parts
252507143305	SUPPORT BRACKET (FOR HP LINES)	TATA spare parts
252507143309	SUPPORT BRACKET (FOR HP LINES)	TATA spare parts
252507143315	SUPPORT BRACKET (HPR COOLANT HOSE) BS6	TATA spare parts
252507143322	BRACKET BS6-PH2	TATA spare parts
252507143704	BRACKET (H.P. LINE SUPPORT)	TATA spare parts
252507143802	BARE CNG RAIL FINISHED	TATA spare parts
252507146802	CNG CONNECTOR ON CNG RAIL	TATA spare parts
252507147204	CNG RAIL PORT PLUG - M22X1.5	TATA spare parts
252507147502	GASKET RING	TATA spare parts
252507147503	SLEEVE (FOR HP LINES)	TATA spare parts
252507147506	ISOLATOR_ PLASTIC FOR HP LINES	TATA spare parts
252507147705	O-RING 12 X 2	TATA spare parts
252507147706	O' RING PORT PLUG ON CNG RAIL 19 I.D. X	TATA spare parts
252507147707	O' RING 24.0 I.D. X 3 CROSS SECTION FOR	TATA spare parts
252507147708	O-RING PRESSURE REGULATOR BS6	TATA spare parts
252507148005	PLUG CNG RAIL PORT DRILLING	TATA spare parts
252507148201	CLAMP (H.P LINES)	TATA spare parts
252507148702	LP FILTER RETAINING SPRING	TATA spare parts
252507149903	LP FILTER ASSY IN CNG RAIL	TATA spare parts
252507149904	PLUG CNG RAIL FOR LPF M27X2	TATA spare parts
252507149905	BARE CNG RAIL (EXTRUDED) 5.7 SGI BSIV (S	TATA spare parts
252507149906	BARE CNG RAIL (EXTRUDED)5.7 SGI BSIV	TATA spare parts
252507150102	ASSY.PIPE UNION (FLAME START)	TATA spare parts
252507150103	ASSY. CONNECTING PIPE	TATA spare parts
252507153303	BRACKET-ELECTROMAGNETIC VALVE(24V)MTG.	TATA spare parts
252507155801	RUBBER HOSE (L=400)	TATA spare parts

252507155802	RUBBER HOSE (L=340)	TATA spare parts
252507155803	RUBBER HOSE (400L)	TATA spare parts
252509100101	LINE HAND PRIMER-697TC EURO II	TATA spare parts
252509100102	ASSY BRACKET MOUNTING LINE HAND PRIMER	TATA spare parts
252509110107	STRAINER ASSY	TATA spare parts
252509110108	ASSY.FUEL FILTER BRACKET-	TATA spare parts
252509110114	ASSY. FUEL FILTER CUM WATER SEPERATOR	TATA spare parts
252509110116	FUEL FILTER CUM WATER SEPERATOR WITH HEA	TATA spare parts
252509110122	FUEL FILTER BRACKET (FOR F.G FILTER)	TATA spare parts
252509110123	BRACKET ASSY FUEL FILTER MTG	TATA spare parts
252509110138	ASSY. FUEL FILTER 24V BS3/4	TATA spare parts
252509113705	BRACKET FUEL FILTER	TATA spare parts
252509113708	BRACKET	TATA spare parts
252509113711	BKT FUEL FILTER & PS PUMP	TATA spare parts
252509113716	BRACKET(FOR F.F.& P.STG.P.MTG)709 T.CAB.	TATA spare parts
252509113718	BRACKET (FUEL FILTER MTG)	TATA spare parts
252509113724	BRACKET-FOR FUEL FILTER & STEERING PUMP	TATA spare parts
252509113730	BRACKET (FUEL FILTER MOUNTING : 1613)	TATA spare parts
252509119902	EXCHANGE FILTER INSERT	TATA spare parts
252509119903	TEMPERATURE SENSOR	TATA spare parts
252509119906	EXCHANGE FILTER INSERT	TATA spare parts
252509119908	EXCHANGE FILTER INSERT	TATA spare parts
252509119910	TEMPERATURE SENSOR	TATA spare parts
252509119911	WATER LEVEL SENSOR	TATA spare parts
252509120106	ASSY FUEL LINE	TATA spare parts
252509120116	FUEL LINE FEEDPUMP-FILTER	TATA spare parts
252509120117	FUEL LINE F/FILTER TO FIP	TATA spare parts
252509120119	BENJO BOLT	TATA spare parts
252509120127	FUEL LINE	TATA spare parts
252509120128	FUEL LINE	TATA spare parts
252509120129	FUEL OVERFLOW LINE	TATA spare parts
252509120130	FUEL OVERFLOW LINE	TATA spare parts
252509120131	KIT FUEL LINE	TATA spare parts
252509120132	FUEL OVERFLOW LINE	TATA spare parts
252509120133	FUEL LINE	TATA spare parts
252509120134	FUEL LINE FEEDPUMP-FILTER	TATA spare parts
252509120135	FUEL LINE	TATA spare parts
252509120136	FUEL OVERFLOW LINE	TATA spare parts
252509120140	FUEL OVERFLOW LINE	TATA spare parts
252509120141	FUEL OVERFLOW LINE	TATA spare parts
252509120142	ASSY FUEL OVERFLOW LINE	TATA spare parts
252509120147	FUEL LINE FEEDPUMP-FILTER	TATA spare parts
252509120149	FUEL OVERFLOW LINE	TATA spare parts
252509120150	ASSY OVERFLOW LINE (COMBINED).	TATA spare parts
252509120151	ASSY.OVERFLOW LINE	TATA spare parts
252509120152	FUEL LINE FILTER TO FIP	TATA spare parts
252509120162	ASSY.FUEL LINE(FILTER TO FIP)	TATA spare parts

252509120163	FUEL LINE (FEED PUMP TO FILTER)	TATA spare parts
252509120170	ASSEMBLY FUEL LINE-FUEL FILTER TO FIP	TATA spare parts
252509120171	ASSEMBLY OVERFLOW LINE(FROM FUEL FILTER)	TATA spare parts
252509120172	ASSY.COMBIND OVERFLOW LINE-ON FIP	TATA spare parts
252509120173	ASSY.FUEL LINE-INLINE PRIMER TO FILTER	TATA spare parts
252509120177	ASSY.OVERFLOW LINE-FROM FUEL FILTER	TATA spare parts
252509120179	ASSY. FUEL LINE(FUEL FLTR TO FIP)	TATA spare parts
252509120188	ASSY.FUEL FILTER(W/T OVERFLOW VALVE)STAR	TATA spare parts
252509120189	ASSY.COMBIND OVERFLOW LINE-ON FIP	TATA spare parts
252509120191	ASSY.FUEL LINE-FILTER TO FIP	TATA spare parts
252509120201	ASSY.OVER FLOW LINE (BS III)	TATA spare parts
252509120204	ASSY.FUEL LINE-FUEL FILTER TO FIP	TATA spare parts
252509120205	ASSY FUEL FILTER SPIN ON BSII	TATA spare parts
252509120206	ASSY FUEL FILTER W/ WATER SEPARATOR	TATA spare parts
252509120211	ASSY. FUEL OVERFLOW LINE	TATA spare parts
252509120212	ASSY.OVERFLOW LINE (FROM FILTER)	TATA spare parts
252509120213	ASSY.FUEL FILTER & OVER FLOW VALVE	TATA spare parts
252509120214	ASSY.FUEL FILTER WITH STAR FILTER INSERT	TATA spare parts
252509120215	ASSY.OVERFLOW VALVE BS4	TATA spare parts
252509120224	ASSY.OVERFLOW LINE (WITH OVERFLOW CONN)	TATA spare parts
252509120225	ASSY.OVERFLOW LINE (FROM FUEL FILTER)	TATA spare parts
252509120226	ASSY.COMBINED OVERFLOW LINE (ON FIP)	TATA spare parts
252509120227	ASSY.FUEL LINE(MECH.FEED PUMP TO FILTER)	TATA spare parts
252509120228	ASSY COMBINED OVERFLOW LINE (ON F.I.P.)	TATA spare parts
252509120231	ASSY.BRACKET (ASSY.LINE-MECH.FEED PUMP T	TATA spare parts
252509120233	ASSY.FUEL LINE (FUEL FILTER TO FIP)	TATA spare parts
252509120234	ASSY. FUEL LINE (MECH. FEED PUMP TO FUEL	TATA spare parts
252509120235	ASSY. FUEL LINE FILTER TO FIP	TATA spare parts
252509120238	ASSY. HEAD (FWS SPINON) BS2/3	TATA spare parts
252509120239	FUEL FILTER (FWS) ELEMENT SPINON BS2/3	TATA spare parts
252509120240	HEAD & WATER SEPERATOR (SPIN ON ) BS2/3	TATA spare parts
252509120242	FUEL LINE ASSY (MECH FEED PUMP TO WS)	TATA spare parts
252509120248	FUEL LINE ASSY.(FEED PUMP TO FUEL FILTER	TATA spare parts
252509120260	ASSY. INJECTOR LEAK OFF LINE BS3/4	TATA spare parts
252509120264	CATRIDGE (FUEL WATER SEP) SPINON BS2/3	TATA spare parts
252509120267	FUEL LINE ASSEMBLY (FUEL FILTER TO FIP)	TATA spare parts
252509120268	FUEL LINE ASSEMBLY (FEED PUMP TO FUEL FI	TATA spare parts
252509120287	FUEL LINE ASSEMBLY ( FUEL FILTER TO FIP	TATA spare parts
252509120288	FUEL LINE ASSEMBLY (FEED PUMP TO FUEL FI	TATA spare parts
252509120291	ASSY NYLON FUEL LINE (FUEL FILTER TO H.P	TATA spare parts
252509120292	ASSY FUEL ACCUMULATOR	TATA spare parts
252509120304	FUEL LINE ASSY.(FEED PUMP TO FUEL FILTER	TATA spare parts
252509120306	ASSY OVERFLOW LINE (PUMP TO ACCUMULATOR	TATA spare parts
252509120307	ASSY OVERFLOW LINE (RAIL TO ACCUMULATOR)	TATA spare parts
252509120310	ASSY FUEL LINE (697 MECH FEED PUMP TO FU	TATA spare parts
252509120311	ASSY FUEL LINE (FIP TO FUEL FILTER	TATA spare parts
252509120313	PLASTIC FUEL ACCUMULATOR	TATA spare parts

252509120314	ASSY FUEL LINE (MECH FEED PUMP TO FF)	TATA spare parts
252509120321	LEAK OFF PIPE ASSY INJECTOR	TATA spare parts
252509123304	BRACKET (SUPPORT W/H MOULD & OVERFLOW L	TATA spare parts
252509123312	SUPPORT-OVERFLOW LINE	TATA spare parts
252509123317	BRACKET (FUEL ACCUMULATOR SUPPORT)	TATA spare parts
252509124204	C-CLAMP (FOR INJ. LEAKOFF LINE SUPPORT)	TATA spare parts
252509125810	HOSE(7.5 I D X 320 L)	TATA spare parts
252509125811	HOSE(5.5 I DX 250 L)	TATA spare parts
252509130109	ASSY BRACKET-AIR FILTER MTG SE1613TURBO	TATA spare parts
252509130116	ASSY CLAMP PAINTED	TATA spare parts
252509130117	AIR FILTER ELEMENT(CARTRIDGE) BS1/2/3	TATA spare parts
252509130121	STRAP	TATA spare parts
252509130122	AIR FILTER ASSY	TATA spare parts
252509130124	CLAMP	TATA spare parts
252509130125	AIR INLET DUCT	TATA spare parts
252509130133	PIPE AIR	TATA spare parts
252509130135	AIR FILTER ASSY OIL BATH	TATA spare parts
252509130138	ASSY CLAMP	TATA spare parts
252509130158	DUCT AIR INLET	TATA spare parts
252509130167	DUCT AIR INLET	TATA spare parts
252509130184	PROTECTIVE	TATA spare parts
252509130191	ASSY DUST BOWL	TATA spare parts
252509130197	ASSY AIR FILTER DRY TYPE	TATA spare parts
252509130199	AIR FILTER ELEMENT	TATA spare parts
252509130202	A/FILTER SECONDARY CARTRIDGE	TATA spare parts
252509130203	SAFETY CARTRIDGE	TATA spare parts
252509130204	AIR FILTER ASSY	TATA spare parts
252509130205	TUBE WITH BRACKET	TATA spare parts
252509130206	TUBE WITH BRACKET	TATA spare parts
252509130216	SERVICE INDICATOR	TATA spare parts
252509130237	ASSY PROTECTIVE COVER SE1613CMVR2000	TATA spare parts
252509130256	PIPE LPO1313	TATA spare parts
252509130257	ASSY PIPE	TATA spare parts
252509130288	ASSY.AIR FILTER(OIL BATH)	TATA spare parts
252509130289	ASSY.AIR FILTER MTG.BRACKET	TATA spare parts
252509130290	AIR FILTER ASSY 1612	TATA spare parts
252509130292	ASSY.BRACKET(AIR FILTER MOUNTING)	TATA spare parts
252509130298	AIR FILTER W/O ELEMENT	TATA spare parts
252509130303	PIPE AIR	TATA spare parts
252509130306	AIR FILTER ASSY OIL BATH	TATA spare parts
252509130310	HOUSING FOR AIR FILTER	TATA spare parts
252509130314	ASSY.AIR INLET DUCT	TATA spare parts
252509130317	BRACKET	TATA spare parts
252509130325	DUCT AIR INLET	TATA spare parts
252509130328	AIR FILTER ASSY OIL BATH	TATA spare parts
252509130329	DUCT ON AIR FILTER	TATA spare parts
252509130330	FILTER CATRIDGE OUTER	TATA spare parts

252509130331	SAFETY CARTRIDGE INNER	TATA spare parts
252509130334	ASSY AIR PIPE	TATA spare parts
252509130342	ASSY PIPE W FLANGE(AIR FLTR OUTLET) RHD	TATA spare parts
252509130345	ASSY BEND PIPE	TATA spare parts
252509130349	ASSY SUPPORT-ON LONG MEMBER FOR AIR FILT	TATA spare parts
252509130351	ASSY AIR INTAKE SCOOP WITH SAE CLAMP	TATA spare parts
252509130353	ASSY.AIR FILTER MTG BKT (MANN AIR FILTER	TATA spare parts
252509130356	ASSY STRAP WITH SHACKLE	TATA spare parts
252509130362	ASSY. CLAMP	TATA spare parts
252509130363	ASSY.AIR PRESSURE LINE-ELBOW TO LDA	TATA spare parts
252509130378	ASSY.PIPE-AIR FILTER TO ENG	TATA spare parts
252509130382	CARTRIDGE (OUTER) AIR FILTER CMVR 2KSE/S	TATA spare parts
252509130383	SAFTY CARTRIDGE AIR FILTER CMVR 2KSE/SK1	TATA spare parts
252509130384	ASSY.BRACKET(FOR AIR INLET PIPE CLAMPING	TATA spare parts
252509130385	ASSY. AIR CLEANER SFC 713 WITH 697NA	TATA spare parts
252509130387	ASSY.BRACKET-AIR INTAKE PIPE CLAMPING	TATA spare parts
252509130388	SUPPORT-AIR FILTER ON LONG MEMBER	TATA spare parts
252509130390	ASSY AIR INLET DUCT	TATA spare parts
252509130397	SAFETY CARTRIDGE 12M3	TATA spare parts
252509130399	ASSY AIR INLET DUCT SE1613	TATA spare parts
252509133306	BRACKET	TATA spare parts
252509133340	BRACKET AIR FILTER	TATA spare parts
252509133348	BRACKET	TATA spare parts
252509133353	SUPPORT (FOR AIR INLET PIPE)	TATA spare parts
252509133361	SUPPORT (AIR INLET CLAMP)	TATA spare parts
252509133374	SUPPORT BRACKET (AIR FILTER MOUNTING)	TATA spare parts
252509133375	SUPPORT(AIR FILTER)	TATA spare parts
252509133376	SUPPORT BRACKET (AIR FILTER MOUNTING)	TATA spare parts
252509133377	BRACKET (AIR FILTER MOUNTING)	TATA spare parts
252509133379	BRACKET (FOR AIR FILTER MTG)	TATA spare parts
252509133380	BRACKET (FOR AL CAST PIPE SUPPORT)	TATA spare parts
252509133396	BRACKET (AIR INTAKE PIPE SUPPORT)	TATA spare parts
252509133398	SUPPORT BRACKET (AIR INTAKE PIPE)	TATA spare parts
252509133399	SUPPORT BRACKET (AIR INTAKE PIPE)	TATA spare parts
252509133801	AIR INLET PIPE 1613 TURBO	TATA spare parts
252509133807	AIR INTAKE PIPE-FROM AIR FILTER TO T.C	TATA spare parts
252509133814	AIR INTAKE PIPE(AIR FILTER TO TC)	TATA spare parts
252509133818	AIR INTAKE PIPE (AIR FILTER TO TC)	TATA spare parts
252509133821	AIR INTAKE PIPE 102 ODX 76 OD	TATA spare parts
252509133823	AIR INLET PIPE	TATA spare parts
252509133824	AIR INLET PIPE-TURBINE END	TATA spare parts
252509133825	AIR INLET PIPE-AIR FILTER END	TATA spare parts
252509133826	PIPE (AIR FILTER TO TURBOCHARGER)	TATA spare parts
252509133827	AIR INTAKE PIPE (AIR FILTER TO TC)	TATA spare parts
252509133830	ASSY AIR INTAKE PIPE (AIR FILTER TO TC)	TATA spare parts
252509133831	PIPE	TATA spare parts
252509133838	PIPE	TATA spare parts

252509133855	AIR INTAKE PIPE	TATA spare parts
252509133857	AIR INTAKE PIPE (HFM SENSOR TO TC)	TATA spare parts
252509133863	AIR INTAKE PIPE (HFM SENSOR TO TC)	TATA spare parts
252509133866	AIR INTAKE PIPE (HFM SENSOR TO TC)	TATA spare parts
252509133867	AIR INTAKE PIPE (AIR FLTR TO HFM SENSOR)	TATA spare parts
252509133880	AIR INTAKE PIPE	TATA spare parts
252509133881	AIR INTAKE PIPE	TATA spare parts
252509133883	PIPE HFM SENSOR TO TC	TATA spare parts
252509133884	PIPE AIR FILTER TO TC	TATA spare parts
252509133886	PIPE AIR FILTER TO HFM SENSOR	TATA spare parts
252509134222	CLAMP-FOR AIR INLET PIPE CLAMPING	TATA spare parts
252509134228	CLAMP (FOR PIPE TC TO IC)	TATA spare parts
252509135807	RUBBER HOSE	TATA spare parts
252509135809	RUBBER HOSE TAPERED	TATA spare parts
252509135810	RUBBER HOSE	TATA spare parts
252509135811	RUBBER HOSE	TATA spare parts
252509135818	RUBBER HOSE AIR FILTER	TATA spare parts
252509135820	RUBBER HOSE	TATA spare parts
252509135824	HOSE	TATA spare parts
252509135827	RUBBER HOSE EXC	TATA spare parts
252509135828	RUBBER HOSE EXC	TATA spare parts
252509135831	RUB HOSE A/FILTER-A/INLET	TATA spare parts
252509135833	TAPERED HOSE 2416	TATA spare parts
252509135840	RUBBER HOSE	TATA spare parts
252509135845	RUB HOSE PIPE TO ELBOW	TATA spare parts
252509135854	HOSE BEND PIPE TO ELBOW	TATA spare parts
252509135855	RUB HOSE IN PIPE-A/FILTER	TATA spare parts
252509135865	HOSE A/FILTER TO PI	TATA spare parts
252509135866	HOSE PIPE TO ELBOW	TATA spare parts
252509135869	HOSE AIR INTAKE	TATA spare parts
252509135870	RUB HOSE AIR INTAKE	TATA spare parts
252509135874	PIPE	TATA spare parts
252509135875	HOSE-AIR FILTER OUTLET	TATA spare parts
252509135879	HOSE ON TC INLET	TATA spare parts
252509135886	HOSE-ON TC INLET-SE1613 CMVR2K	TATA spare parts
252509135890	HOSE-AIR FILTER TO T.C.	TATA spare parts
252509135891	HOSE (ON AIR FILTER OUTLET) SE1613	TATA spare parts
252509135892	RUBBER BELLOW	TATA spare parts
252509135896	HOSE AIR FILTER TO T/CHARGER 1613 SE TUR	TATA spare parts
252509135898	RUBBER HOSE-AIR FILTER-TC-LIFTED COWL	TATA spare parts
252509135899	HOSE(OIL B.A.FILTER TO ENG) LIFTED COWL	TATA spare parts
252509136301	PRECLEANER	TATA spare parts
252509136306	RUBBER CUFF	TATA spare parts
252509136311	PLASTIC COVER FOR 02 98.	TATA spare parts
252509136312	RUBBER BELLOW	TATA spare parts
252509136316	RUBBER BUFFER	TATA spare parts
252509136317	RUBBER SEAL	TATA spare parts



252509136322	AIR INTAKE SCOOP PLASTIC	TATA spare parts
252509136330	SCOOP ON A.FILTER INLET	TATA spare parts
252509136331	AIR INTAKE SCOOP SK1613	TATA spare parts
252509136906	FINOLEX TUBE	TATA spare parts
252509136907	TUBE	TATA spare parts
252509136967	BEND PIPE	TATA spare parts
252509136969	INLET PIPE A/FIL	TATA spare parts
252509136978	PIPE A/FILTER TO ELBOW	TATA spare parts
252509138214	DUST BOWL	TATA spare parts
252509138299	DUST BOWL FOR 0298.	TATA spare parts
252509138401	SLEEVE-ON TC INLET	TATA spare parts
252509139902	RUBBER STRAP	TATA spare parts
252509139904	BANJO BOLT	TATA spare parts
252509139932	RUBBER STRAP 1613 SE TURBO	TATA spare parts
252509139943	ADAPTOR (43 LG)	TATA spare parts
252509139948	COVER ASSY TOP BS6	TATA spare parts
252509140106	ASSY.AIR INTAKE PIPE(SNORKLE TO A/F)	TATA spare parts
252509140110	ASSY.STRAP 70W	TATA spare parts
252509140111	SAFETY CARTRIDGE PAPER BS1/2/3	TATA spare parts
252509140112	ASSY.OIL BATH AIR FILTER SK1613	TATA spare parts
252509140113	ASSY.AIR FILTER MOUNTING BRACKET.	TATA spare parts
252509140114	ASSY. AIR FILTER DRY TYPE BS1/2/3	TATA spare parts
252509140123	FILTER CATRIDGE OUTER	TATA spare parts
252509140124	SAFETY CARTRIDGE PAPER	TATA spare parts
252509140130	ASSY.AIR FILTER COMPLETE	TATA spare parts
252509140133	SAFETY CARTRIDGE PAPER	TATA spare parts
252509140134	FILTER CATRIDGE OUTER BS1/3	TATA spare parts
252509140135	SAFETY CARTRIDGE PAPER	TATA spare parts
252509140138	ASSY. SNORKEL(AIR INLET DUCT)	TATA spare parts
252509140139	ASSY. CLAMP-TOP(FOR AIR INLET PIPE)	TATA spare parts
252509140140	ASSY. CLAMP BOTTOM (AIR INLET PIPE)	TATA spare parts
252509140143	ASSY.AIRFILTER	TATA spare parts
252509140150	ASSY.PIPE WITH FLANGE.	TATA spare parts
252509140154	ASSY.AIR INTAKE PIPE (SNORKLE TO AIRFILT	TATA spare parts
252509140156	ASSY.AIR FILTER MTG BRACKET	TATA spare parts
252509140157	ASSY. BRACKET (AIR INTAKE PIPE SUPPORT)	TATA spare parts
252509140161	ASSY.AIR FILTER MTG.BRACKET	TATA spare parts
252509140163	ASSY.AIR FILTER	TATA spare parts
252509140164	ASSY.STRAP WITH RUBBER STRAP	TATA spare parts
252509140165	ASSY.BRACKET-FOR INLET PIPE	TATA spare parts
252509140169	ASSY AIR INTAKE PIPE-A/F TO TC	TATA spare parts
252509140174	SUPPORT(AIR FILTER)	TATA spare parts
252509140175	ASSEMBLY AIR FILTER COMPLETE	TATA spare parts
252509140190	ASSY.PIPE WITH FLANGE	TATA spare parts
252509140192	ASSY.AIR INLET PIPE WITH ADAPTOR	TATA spare parts
252509140193	ASSY.AIR INLET DUCT	TATA spare parts
252509140194	ASSY.BRACKET(AIR INLET DUCT MTG.BOTTOM)	TATA spare parts

252509140195	ASSY.AIR FILTER MTG.BRACKET	TATA spare parts
252509140198	ASSEMBLY AIR CLEANER	TATA spare parts
252509140201	ASSY. AIR INTAKE PIPE (SNORKEL TO AIR FI	TATA spare parts
252509140205	ASSY. BRACKET (AIR INLET DUCT MTG. TOP)	TATA spare parts
252509140219	AIR INTAKE PIPE	TATA spare parts
252509140221	ASSEMBLY AIR FILTER MOUNTING BRACKET	TATA spare parts
252509140222	ASSY. AIR FILTER	TATA spare parts
252509140223	ASSY. AIR INTAKE PIPE (SNORKEL TO AIR FI	TATA spare parts
252509140226	ASSY. BRACKET SNORKLE MTG.	TATA spare parts
252509140231	ASSY BRACKET AIR INLET DUCT MTG BOTTOM	TATA spare parts
252509140238	ASSEMBLY BRACKET (AIR FILTER MOUNTING)	TATA spare parts
252509140239	ASSY. BRACKET (AIR INTAKE PIPE SUPPORT)	TATA spare parts
252509140240	ASSY PIPE WITH FLANGE	TATA spare parts
252509140241	ASSY BRACKET FOR AIR FILTER MOUNTING (T.	TATA spare parts
252509140242	ASSY PIPE - AIR INLET	TATA spare parts
252509140243	ASSY PIPE WITH FLANGE	TATA spare parts
252509140250	PIPE (AIR FILTER TO TURBOCHARGER)	TATA spare parts
252509140251	ASSY.DUCT ON AIR FILTER	TATA spare parts
252509140252	ASSY PROTECTIVE COVER	TATA spare parts
252509140257	ASSY AIR FILTER MTG BRACKET (ON LM)	TATA spare parts
252509140269	ASSEMBLY PIPE WITH FLANGE	TATA spare parts
252509140271	KIT AIR FILTER PIPES & HOSES	TATA spare parts
252509140274	ASSY. AIR FILTER COMPLETE	TATA spare parts
252509140275	ASSY. PIPE POWDER COATED WITH MESH	TATA spare parts
252509140277	ASSY. PIPE WITH CLAMP	TATA spare parts
252509140301	BRACKET ASSY	TATA spare parts
252509140302	ASSY BRACKET AIR INTAKE	TATA spare parts
252509140335	PIPE ASSY WITH BOSS+D35 BS6	TATA spare parts
252509140337	PIPE ASSY WITH BOSS BS6	TATA spare parts
252509140341	BRACKET ASSYBS6	TATA spare parts
252509140342	PIPE ASSY WITH CLAMP BS6	TATA spare parts
252509140346	KIT-AIR INTAKE SYSTEM BS6	TATA spare parts
252509140347	AIR CLEANER ASSY WITH MTG BRACKET BS6	TATA spare parts
252509140357	PIPE AIR FILTER TO PRE FILTER BS6	TATA spare parts
252509140358	BRACKET ASSY BS6	TATA spare parts
252509140359	BRACKET ASSY BS6	TATA spare parts
252509140360	DAMPER ASSY BS6	TATA spare parts
252509143308	SUPPORT BRACKET	TATA spare parts
252509143309	AIR INTAKE PIPE (AIR FILTER TO HFM SENSO	TATA spare parts
252509143313	SUPPORT BRACKET (AF PIPE) BS6	TATA spare parts
252509143314	BRACKET (AF PIPE SUP)	TATA spare parts
252509143325	SUPPORT BRACKET	TATA spare parts
252509143332	BRACKET	TATA spare parts
252509143337	SUPPORT BRACKET	TATA spare parts
252509143338	BRACKET AIR FILTER PIPE MTG BS6	TATA spare parts
252509143340	BRACKET AIR FILTER PIPE MTG	TATA spare parts
252509143342	SUPPORT BRACKET AIR INTAKE PIPE BS6	TATA spare parts

252509143343	SUPPORT BRACKET AIR INTAKE PIPE BS6	TATA spare parts
252509143345	SUPPORT BRACKET ASSY BS6	TATA spare parts
252509145802	HOSE(ON TC INLET).	TATA spare parts
252509145804	REDUCER HOSE(127 AID X 102 ID).	TATA spare parts
252509145804AE	RED HOSE(127 X 102 ) LPA 1415	TATA spare parts
252509145806	HOSE ON TC INLET	TATA spare parts
252509145807	HOSE-TC INLET	TATA spare parts
252509145808	REDUCER HOSE ON AIR FILTER OUTLET	TATA spare parts
252509145809	HOSE (TC INLET)	TATA spare parts
252509145810	HOSE (AIR FILTER PIPE TO TURBOCHARGER)	TATA spare parts
252509145811	HOSE-TOP-AT AIR FILTER INLET	TATA spare parts
252509145812	HOSE-BOTTOM-AT TC INLET	TATA spare parts
252509145814	RUBBER HOSE (AIR FILTER OUTLET)	TATA spare parts
252509145815	HOSE (INLET PIPE TO TEL TC)	TATA spare parts
252509145816	HOSE (INLET PIPE TO THL TC)	TATA spare parts
252509145817	HOSE	TATA spare parts
252509145819	REDUCER HOSE	TATA spare parts
252509145820	HOSE (SNORKEL PIPE TO AIR FILTER)	TATA spare parts
252509145827	HOSE	TATA spare parts
252509145832	BRACKET (AIR FILTER PIPE SUPPORT)	TATA spare parts
252509145840	HOSE (A/F PIPE TO ETC)	TATA spare parts
252509145846	HOSE (A/F PIPE TO ETC)	TATA spare parts
252509145852	HOSE (A/F PIPE TO ETC)	TATA spare parts
252509145853	HOSE (AIR FILTER TO PIPE)	TATA spare parts
252509145856	HOSE (AIR INTAKE TO TC)	TATA spare parts
252509145858	HOSE (HFM SENSOR TO TC)	TATA spare parts
252509145860	RUBBER HOSE (AIR FILTER TO PIPE)	TATA spare parts
252509145867	HOSE (AIR FILTER TO AIR INTAKE PIPE)	TATA spare parts
252509145869	HOSE (HFM SENSOR TO AIR INTAKE PIPE)	TATA spare parts
252509145870	HOSE AIR INTAKE PIPE TO TC	TATA spare parts
252509145872	HOSE	TATA spare parts
252509145874	HOSE (AIR FILTER TO PIPE)	TATA spare parts
252509145875	HOSE AIR FILTER PIPE TO TC BS6	TATA spare parts
252509145876	SILICON HOSE (IC PIPE ASSY TO ETB)	TATA spare parts
252509145877	HOSE DEGREE (AF TO AF PIPE)	TATA spare parts
252509145878	HOSE ELBOW (ASSY PIPE WITH MESH)	TATA spare parts
252509145879	HOSE REDUCER DEGREE (AF PIPE TO ETB)	TATA spare parts
252509145888	HOSE	TATA spare parts
252509145889	HOSE	TATA spare parts
252509145890	HOSE	TATA spare parts
252509145891	HOSE AIR INTAKE PIPE	TATA spare parts
252509145899	HOSE	TATA spare parts
252509146901	INLET PIPE (80 DIA.)	TATA spare parts
252509146906	PIPE-DUCT TO AIR FILTER	TATA spare parts
252509146907	AIR INTAKE PIPE ( AIR FILTER TO TC) SE16	TATA spare parts
252509146908	PIPE DUCT TO AIR FILTER INLET	TATA spare parts
252509146917	PIPE (3000 L)	TATA spare parts

252509146953	AIR INLET PIPE	TATA spare parts
252509146959	AIR INTAKE PIPE	TATA spare parts
252509146969	PIPE	TATA spare parts
252509146972	NYLON TUBE (8 OD X 6 ID) BS6	TATA spare parts
252509146974	HOSE BS6	TATA spare parts
252509148255	BRACKET-LH (FOR SNORKEL PIPE MTG)	TATA spare parts
252509148256	BRACKET-RH(FOR SNORKEL PIPE MTG)	TATA spare parts
252509148278	L-BRACKET AIR INTAKE PIPE SUPPORT	TATA spare parts
252509148279	SUPPORT BRACKET PIPE	TATA spare parts
252509150121	AIR FILTER ASSY	TATA spare parts
252509155801	HOSE BS6	TATA spare parts
252509155802	HOSE	TATA spare parts
252509155803	HOSE AIR FILTER TO AIR INTAKE PIPE	TATA spare parts
252509155804	HOSE	TATA spare parts
252509155805	REDUCER HOSE	TATA spare parts
252509155808	HOSE AIR FILTER TO INTAKE PIPE BS6	TATA spare parts
252509155809	HOSE AIR INTAKE PIPE TO THROTTLE BODY BS	TATA spare parts
252509155811	HOSE AIR INTAKE PIPE TO THROTTLE BODY BS	TATA spare parts
252509155812	HOSE AIR FILTER OUTLET BS6	TATA spare parts
252509155816	HOSE TC INTAKE BS6	TATA spare parts
252509990104	RETRO KIT 6DIA EJECTOR & HOSE (1613)	TATA spare parts
252509990105	RETRO KIT 6DIA EJECTOR & HOSE(2515)	TATA spare parts
252513100101	CYL HEAD AIR COMP 94D	TATA spare parts
252513100102	REP KIT CYL HEAD 94D MJR	TATA spare parts
252513100103	REP KIT CYL HEAD 94D MNR	TATA spare parts
252513100104	SET A/C BRG STD 94 DIA 697NA/TC	TATA spare parts
252513100105	SET CON ROD BRG STD1 94D	TATA spare parts
252513100106	CYL HEAD AIR COMP 94D	TATA spare parts
252513100107	CYL HEAD AIR COMP 94D	TATA spare parts
252513100108	SET A/C BRG STD 94 DIA 697NA/TC	TATA spare parts
252513100109	BEARING SET STD.1 A/C	TATA spare parts
252513100110	SET CON ROD BRG R/S1 94D	TATA spare parts
252513100111	SET CON ROD BRG R/S2 94D	TATA spare parts
252513100114	ASSY CYL HEAD AIR COMPRESSOR 94 DIA:	TATA spare parts
252513100115	OIL LINE ASSY	TATA spare parts
252513100117	R/KIT A/C CYL HEAD	TATA spare parts
252513100119	ASSY.CYL.HD.(REED TYPE)94DIA.	TATA spare parts
252513100126	ASSY. CYLINDER HEAD BS1/2/3/4	TATA spare parts
252513100128	CYLINDER HEAD ASSY.	TATA spare parts
252513100130	ASSY.CYL.HEAD - UNLOADER VALVE	TATA spare parts
252513100149	READ VALVE ASSY.	TATA spare parts
252513103401	CON ROD BUSH 94D AC	TATA spare parts
252513103702	CYL SLEEVE A/C STD 77D	TATA spare parts
252513103703	CYL SLEEVE A/C STD1 77D	TATA spare parts
252513103707	CYLINDER SLEEVE STD BS1/2/3/4	TATA spare parts
252513104202	COATED CLAMP	TATA spare parts
252513105301	GASKET-94 DIA	TATA spare parts

252513105302	GASKET-94 DIA	TATA spare parts
252513108201	HEAT SHIELD- COMPRESSOR	TATA spare parts
252513108202	HEAT SHIELD-AIRCOMPRESSOR	TATA spare parts
252513109201	PLAIN WASHER (M912580) BS6-PH2	TATA spare parts
252513130101	SUCTION TUBE	TATA spare parts
252513130102	PIPE ELBOW	TATA spare parts
252513130106	TUBE ASSY	TATA spare parts
252513130107	TUBE ASSY	TATA spare parts
252513130112	ASSY.TUBE	TATA spare parts
252513130113	ASSY.TUBE	TATA spare parts
252513130118	ASSY.TUBE	TATA spare parts
252513130121	ASSY.PIPE WITH FERRULE	TATA spare parts
252513130122	ASSY.TUBE	TATA spare parts
252513130125	ASSY.TUBE WITH CRIMPED HOSES	TATA spare parts
252513130126	ASSY. TUBE	TATA spare parts
252513130135	ASSY PIPE WITH FERRULE	TATA spare parts
252513130136	ASSY. PIPE WITH FERRULE	TATA spare parts
252513130144	ASSY TUBE (AIR COMPRESSOR INLET)	TATA spare parts
252513130159	ASSEMBLY PIPE WITH FERRULE (230CC COMP)	TATA spare parts
252513130174	ASSY PIPE (AIR INTAKE PIPE TO AIR COMP)	TATA spare parts
252513130175	ASSY PIPE (AIR INTAKE PIPE TO A/C INLET)	TATA spare parts
252513130178	ASSY BRACKET (FOR A/C PIPE ) LPT1613 SE	TATA spare parts
252513130192	ASSY PIPE	TATA spare parts
252513130193	ASSY AIR COMP PIPE WITH FERRULE	TATA spare parts
252513130209	PIPE ASSEMBLY (AIR INLET PIPE TO AIR COM	TATA spare parts
252513130210	PIPE ASSY AIR INTAKE PIPE TO AIR COMP	TATA spare parts
252513130211	PIPE ASSY AIR INTAKE PIPE TO AIR COMP	TATA spare parts
252513135801	RUBBER HOSE	TATA spare parts
252513135802	RUBBER HOSE	TATA spare parts
252513135804	RUB HOSE CYL HD COVER-AC	TATA spare parts
252513135806	HOSE ON AIR COMP.INLET-L	TATA spare parts
252513135808	RUBBER HOSE (CYL.HEAD COVER TO AC HEAD)	TATA spare parts
252513135813	HOSE(AIR COMPRESSOR)	TATA spare parts
252513135816	HOSE (A/C COMPRESSOR TO PIPE)	TATA spare parts
252513135823	HOSE	TATA spare parts
252513136946	PIPE (AIR COMPRESSOR INLET)	TATA spare parts
252513136954	PIPE	TATA spare parts
252513137101	FLANGE(FOR CLOSING AIR COMPRESSOR HOLE)	TATA spare parts
252513138203	PLATE	TATA spare parts
252513140101	SET PISTON RING STD 77D	TATA spare parts
252513140102	SET PISTON RING STD1 77D	TATA spare parts
252513140104	ASSY AC PISTON STD W/RING	TATA spare parts
252513140113	ASSY PISTON STD 77 DIA AIR COMPRESSOR	TATA spare parts
252513140116	COM/PISTON 77-10 MM	TATA spare parts
252513140119	COM/PISTON 77-20 MM	TATA spare parts
252513140121	PISTON W/O RING STD 77D	TATA spare parts
252513140122	PISTON W/O RING STDI 77D	TATA spare parts

252513140124	PISTON W/O RING STD 94D	TATA spare parts
252513140125	PISTON ASSY STD	TATA spare parts
252513140133	ASSY PISTON N-9 NORMAL	TATA spare parts
252513140142	SET PISTON RING STD 94D	TATA spare parts
252513140143	SET PISTON RING STD1 94D	TATA spare parts
252513141011	PISTON STD 77D AC	TATA spare parts
252513141012	PISTON STD 77D AC	TATA spare parts
252513141021	PISTON STD 94DIA AIR COMPRESSOR	TATA spare parts
252513141022	PISTON STD 94DIA AIR COMPRESSOR	TATA spare parts
252513141023	PISTON STD 94DIA AIR COMPRESSOR	TATA spare parts
252513141041	PISTON N-9 NORMAL	TATA spare parts
252513149920	94D A/C PISTON RING STD	TATA spare parts
252513149921	RING PISTON STDI	TATA spare parts
252513149932	NOSE SCRAPER RING STD	TATA spare parts
252513150101	SUCTION VALVE ASSY	TATA spare parts
252513150102	DELIVERY VALVE ASSY	TATA spare parts
252513158202	DISC-VALVE	TATA spare parts
252513158205	DISC-SPRING	TATA spare parts
252513990105	REPAIR KIT AIR COMPR.ITEMS	TATA spare parts
252513990106	KIT-AIR COMPRESSOR	TATA spare parts
252514100101	ASSY GASKET (INTAKE MANIFOLD)	TATA spare parts
252514100102	AIR INTAKE MANIFOLD ASSY (FRONT ETB) BS6	TATA spare parts
252514100105	ASSY FLANGE HEATER ADAPTOR (GRID HEATER	TATA spare parts
252514100108	MANIFOLD INTAKE ASSY WITH CAPS	TATA spare parts
252514100125	INTAKE MANIFOLD ASSY WITH CORE PLUG	TATA spare parts
252514100127	PIPE ASSY WITH FLANGE	TATA spare parts
252514100129	BRACKET (LAMBDA & TEMP SENSOR CONN) BS6	TATA spare parts
252514103801	INTAKE MANIFOLD - BS IV (FRONT ETB)	TATA spare parts
252514103812	AIR INTAKE ELBOW BS6	TATA spare parts
252514105301	GASKET INTAKE MANIFOLD	TATA spare parts
252514110107	ASSY EXH ELBOW	TATA spare parts
252514110111	EXHAUST MANIFOLD	TATA spare parts
252514110114	EXHAUST MANIFOLD TC RHD	TATA spare parts
252514110135	ASSY GASKET (EXHAUST MANIFOLD)	TATA spare parts
252514110136	ASSY GASKET (EXHAUST MANIFOLD)	TATA spare parts
252514110162	ASSY EXHAUST PIPE (TC TO SILENCER)	TATA spare parts
252514110182	CATALYTIC CONVERTER	TATA spare parts
252514110189	ASSY EGR PIPE (EX MAN TO EGR COOLER)	TATA spare parts
252514110190	ASSY EGR PIPE (EGR COOLER TO ELBOW)	TATA spare parts
252514110192	DIESEL & PARTICULATE OXIDATION CATALYST	TATA spare parts
252514110199	ASSY EGR COOLER	TATA spare parts
252514110221	ASSEMBLY EGR PIPE EXHAUST MANIFOLD	TATA spare parts
252514110222	ASSEMBLY EGR PIPE EGR COOLER	TATA spare parts
252514110228	ASSY. CATALYTIC CONVERTOR BS4	TATA spare parts
252514110235	ASSY EGR COOLER(CAST) W/O VALVE	TATA spare parts
252514110239	ASSY PM METALIT (DIA 200 X174)	TATA spare parts
252514110245	ASSY DOC (DIA 172X127) (40GM)	TATA spare parts

252514110262	ASSY. EGR PIPE (COOLER TO ELBOW) BS3/4	TATA spare parts
252514110267	ASSY EGR PIPE(EXH MANIFOLD TO EGR VALVE)	TATA spare parts
252514110281	ASSEMBLY EGR VALVE 24V	TATA spare parts
252514110286	ASSEMBLY EGR VALVE 24V	TATA spare parts
252514110288	ASSEMBLY EGR COOLER (CAST)WITH EGR VALVE	TATA spare parts
252514110337	ASSY EGR PIPE	TATA spare parts
252514110339	ASSEMBLY EGR PIPE LPT1613SE	TATA spare parts
252514110346	ASSEMBLY EGR VALVE 24V	TATA spare parts
252514110351	ASSY EGR VALVE	TATA spare parts
252514110394	COOLANT PIPE EGR OUTLET (EGR TO UCWL)	TATA spare parts
252514110397	ASSY. AFTER TREATMENT SYSTEM BS4	TATA spare parts
252514111603	ASSY. GASKET (EX. MAN TO TC)	TATA spare parts
252514111604	GASKET (EX MAN TO EGR ADAPTOR)	TATA spare parts
252514113201	HEX BOLT-120 LONG	TATA spare parts
252514113202	HEX BOLT M 10 X 125	TATA spare parts
252514113203	HEX BOLT(115 LONG)	TATA spare parts
252514113204	HEX FLANGE BOLT	TATA spare parts
252514113205	HEX FLANGE BOLT	TATA spare parts
252514113303	SUPPORT BRACKET EXHAUST ELBOW BS6	TATA spare parts
252514113304	SUPPORT BRACKET SHIELD EXH ELBOW BS6	TATA spare parts
252514113702	EXHAUST MANIFOLD	TATA spare parts
252514113705	EXHAUST MANIFOLD TC RHD	TATA spare parts
252514113713	EXHAUST MANIFOLD	TATA spare parts
252514113770	EXHAUST MANIFOLD LHD	TATA spare parts
252514113772	EXHAUST MANIFOLD	TATA spare parts
252514113774	EXHAUST MANIFOLD 1613 CMVR2000	TATA spare parts
252514113777	EXHAUST MANIFOLD	TATA spare parts
252514113779	EXHAUST MANIFOLD (EX-100 EXCAVATOR)	TATA spare parts
252514113780	EXHAUST MANIFOLD (FOR 180PS BSIII T.CAB)	TATA spare parts
252514113781	EXHAUST MANIFOLD	TATA spare parts
252514113782	EXHAUST MANIFOLD	TATA spare parts
252514113784	BRACKET (EGR COOLER & COMMON RAIL)	TATA spare parts
252514113789	EXHAUST MANIFOLD	TATA spare parts
252514113790	EXHAUST MANIFOLD (BSIV)	TATA spare parts
252514113797	EGR CAST PIPE ( EGR PIPE TO EGR VALVE )	TATA spare parts
252514113798	MANIFOLD EXHAUST CAB	TATA spare parts
252514113902	EXHAUST MANIFOLD	TATA spare parts
252514115102	CLAMP EXHAUST MANIFOLD	TATA spare parts
252514115103	THROTTLE VALVE	TATA spare parts
252514115301	GASKET	TATA spare parts
252514115302	GASKET	TATA spare parts
252514115308	GASKET EXHAUST MANIFOLD	TATA spare parts
252514115312	GASKET (EGR VALVE TO EGR COOLER)	TATA spare parts
252514115313	GASKET (EGR PIPE FLANGE TO EGR VALVE)	TATA spare parts
252514115314	GASKET (EGR COOLER TO EGR VALVE)	TATA spare parts
252514115316	GASKET (EGR PIPE FLANGE TO EGR VALVE)	TATA spare parts
252514115318	GASKET ASSY EXH MANIFOLD	TATA spare parts

252514115319	GASKET ASSY EXHAUST MANIFOLD	TATA spare parts
252514117902	THROTTLE SHAFT	TATA spare parts
252514118219	HEAT SHIELD (FOR EXHAUST MANIFOLD)	TATA spare parts
252514118220	HEAT SHIELD - TURBOCHARGER	TATA spare parts
252514118221	HEAT SHIELD-TURBOCHARGER	TATA spare parts
252514118227	HEAT SHIELD	TATA spare parts
252514118802	STUD	TATA spare parts
252514119201	WASHER	TATA spare parts
252514120104	EGR PIPE ASSY WITH CLAMP	TATA spare parts
252514120113	BRICK BS6	TATA spare parts
252514120115	BRICK BS6	TATA spare parts
252514120118	HEAT SHIELD ASSY EXHAUST ELBOW BS6	TATA spare parts
252514120125	HEAT SHIELD ASSY EXHAUST ELBOW BS6	TATA spare parts
252514120126	HEAT SHIELD ASSY EXHAUST MANIFOLD BS6	TATA spare parts
252514120201	CATALYTIC CONVERTER ASSY BS6	TATA spare parts
252514120203	CATALYTIC CONVERTER ASSY BS6	TATA spare parts
252514123703	MANIFOLD EXHAUST 697 COWL	TATA spare parts
252514123716	EXHAUST MANIFOLD	TATA spare parts
252514123721	EXHAUST MANIFOLD	TATA spare parts
252514123723	BRACKET	TATA spare parts
252514123727	BRACKET	TATA spare parts
252514123729	EXHAUST ELBOW BS6-PH2	TATA spare parts
252514123730	EXHAUST ELBOW TURBOCHARGER BS6	TATA spare parts
252514123732	EXHAUST ELBOW TURBOCHARGER BS6	TATA spare parts
252514130102	CONTROL SHAFT W/LEVER	TATA spare parts
252514130114	PULL ROD ASSY	TATA spare parts
252514130122	LEVER W/BALL PIN	TATA spare parts
252514130123	LEVER W/BALL PIN	TATA spare parts
252514130124	STOPPER PLATE	TATA spare parts
252514130127	LEVER ACCELERATOR CON	TATA spare parts
252514130164	THROTTLE VALVE ASSY	TATA spare parts
252514136908	SLEEVE	TATA spare parts
252514136929	SLEEVE	TATA spare parts
252514137105	LINK FOR SPRING	TATA spare parts
252514138201	BRACKET	TATA spare parts
252514138209	BRACKET	TATA spare parts
252514138216	SUPPORT BRACKET	TATA spare parts
252514510101	TURBOCHARGER	TATA spare parts
252514510102	TURBOCHARGER 1210 SD	TATA spare parts
252514510104	ASSY TURBOCHARGER CMVR2000 SE	TATA spare parts
252514510105	ASSY. TURBOCHARGER-FOR CMVR2000 LP/LPT	TATA spare parts
252514510106	TURBOCHARGER SE1613 CMVR2K	TATA spare parts
252514510107	ASSY.CLAMP(ON HOLSET TC OUTLET)	TATA spare parts
252514510109	TURBOCHARGER LPT1613 CMVR2K	TATA spare parts
252514510111	TURBOCHARGER 25 DEG.	TATA spare parts
252514510112	ASSY.TURBOCHARGER -EUROII	TATA spare parts
252514510113	VEE BAND CLAMP	TATA spare parts



252514510114	ASSY. TURBOCHARGER BS2	TATA spare parts
252514510116	ASSY.TURBO CHARGER (EURO-III)	TATA spare parts
252514510117	ASSY TURBOCHARGER-LPT2515 145PS	TATA spare parts
252514510119	ASSY.TURBOCHARGER -145PS-TILTCAB	TATA spare parts
252514510120	ASSY.TURBOCHARGER (BS III TILT CAB)	TATA spare parts
252514510121	ASSY.TURBOCHARGER)-130PS TILT CAB	TATA spare parts
252514510122	ASSY.TURBOCHARGER-145PS	TATA spare parts
252514510123	ASSY.TURBOCHARGER -145PS TILT CAB	TATA spare parts
252514510125	ASSY TURBOCHARGER	TATA spare parts
252514510126	ASSY. TURBOCHARGER - LPT 613 E-III	TATA spare parts
252514510127	TURBOCHARGER 160PS BS II COWL	TATA spare parts
252514510129	ASSY TURBOCHARGER	TATA spare parts
252514510131	TURBOCHARGER 130 PS BSIII	TATA spare parts
252514510132	TURBOCHARGER 130 PS BSIII	TATA spare parts
252514510134	TURBOCHARGER-160PS-BSII-COWL	TATA spare parts
252514510137	TURBOCHARGER 130 PS BSIII-COWL	TATA spare parts
252514510138	TURBOCHARGER 130 PS BSIII-CAB	TATA spare parts
252514510145	ASSY. TURBOCHARGER BS3/4	TATA spare parts
252514510147	ASSEMBLYTURBOCHARGER	TATA spare parts
252514510156	ASSY. TURBOCHARGER BS4	TATA spare parts
252514510159	TURBOCHARGER ASSY BS6	TATA spare parts
252514510164	TURBOCHARGER ASSY	TATA spare parts
252514510165	TURBOCHARGER ASSY	TATA spare parts
252514510166	ASSY. TURBOCHARGER BS4	TATA spare parts
252514510169	TURBOCHARGER ASSY	TATA spare parts
252514580101	HEAT SHIELD	TATA spare parts
252514600108	ASSY.ADAPTOR WITH PIPE (TEL-TC OUTLET)	TATA spare parts
252514600109	ASSY.INTERCOOLER	TATA spare parts
252514600110	ASSY. CLAMP	TATA spare parts
252514600111	ASSY.INTERCOOLER	TATA spare parts
252514600112	ASSY.ADAPTOR WITH PIPE (TEL TC)	TATA spare parts
252514600113	INTERCOOLER ASSEMBLY	TATA spare parts
252514600126	ASSY. PIPE (IC TO ELBOW) WITH BOSS	TATA spare parts
252514600131	ASSY AIR INTAKE PIPE AIR FILTER TO TURBO	TATA spare parts
252514600134	INTERCOOLER ASSEMBLY	TATA spare parts
252514600135	ASSY PIPE WITH BOSS	TATA spare parts
252514600140	ASSY ADAPTOR WITH PIPE ( TEL TC )	TATA spare parts
252514600149	I/C ASSY-LPT 1613 697 BS4 TILT CAB	TATA spare parts
252514600166	TC ADAPTOR	TATA spare parts
252514600170	ASSEMBLY BRACKET (IC PIPE SUPPORT)	TATA spare parts
252514600196	ASSY PIPE (IC TO ELBOW)	TATA spare parts
252514600201	ASSY INTERCOOLER (TATA TOYO)	TATA spare parts
252514600212	PIPE INTERCOOLER TO THROTTLE BODY BS6	TATA spare parts
252514600213	INTERCOOLER ASSY BS6	TATA spare parts
252514600214	PIPE TC ADAPTER PIPE TO INTERCOOLER BS6	TATA spare parts
252514600215	PIPE ASSY INTERCOOLER OUTLET BS6	TATA spare parts
252514603301	BRACKET L.H. FOR I.C.PIPE CLAMPING	TATA spare parts

252514603302	BRACKET R.H. FOR I.C.PIPE CLAMPING	TATA spare parts
252514603303	SUPPORT BRACKET (FOR IC TO ELBOW PIPE)	TATA spare parts
252514603305	SUPPORT BRACKET	TATA spare parts
252514603318	SUPPORT BRACKET BS6	TATA spare parts
252514603319	SUPPORT BRACKET TC PIPE TO INTERCOOLER B	TATA spare parts
252514603320	SUPPORT BRACKET BS6	TATA spare parts
252514603321	SUPPORT BRACKET TC PIPE TO INTERCOOLER B	TATA spare parts
252514603322	SUPPORT BRACKET BS6	TATA spare parts
252514603324	SUPPORT BRACKET (TO TO IC PIPE) BS6	TATA spare parts
252514603325	SUPPORT BRACKET (PIPE IC TO ETB HOSE)BS6	TATA spare parts
252514603801	CAST PIPE-FROM T.C.TO I.C.	TATA spare parts
252514603802	CAST PIPE-I.C.TO CYL.HEAD COVER	TATA spare parts
252514603805	CAST PIPE-ON IC INLET	TATA spare parts
252514603806	CAST PIPE-ON IC OUTLET	TATA spare parts
252514603808	PIPE (IC TO AIR INTAKE ELBOW)	TATA spare parts
252514603809	PIPE (TC TO IC)	TATA spare parts
252514603812	CAST PIPE TC TO IC	TATA spare parts
252514603813	CAST PIPE IC TO AIR INTAKE ELBOW	TATA spare parts
252514603814	CAST PIPE (TC TO IC)	TATA spare parts
252514603815	PIPE (IC TO ELBOW)	TATA spare parts
252514603816	CAST PIPE (TC TO IC)1/LPLPT1615/2518BS3	TATA spare parts
252514603817	CAST PIPE (IC ELBOW)1/LPLPT16152518BS3	TATA spare parts
252514603818	PIPE (TURBOCHARGER TO IC)	TATA spare parts
252514603819	PIPE (INTERCOOLER TO ELBOW)	TATA spare parts
252514603820	ALUMINIUM PIPE-TC TO IC	TATA spare parts
252514603821	AL PIPE-INTERCOOLER TO ENGINE	TATA spare parts
252514603822	PIPE (TC TO IC)-TC-SE/SK 1613	TATA spare parts
252514603823	CAST PIPE (TC TO IC)-TC-LPT 1613	TATA spare parts
252514603830	PIPE(TURBOCHARGER TO IC)	TATA spare parts
252514603831	PIPE (IC TO AIR INTAKE ELBOW)	TATA spare parts
252514603857	PIPE INTERCOOLER LH	TATA spare parts
252514603858	PIPE INTERCOOLER OUTLET	TATA spare parts
252514604201	COATED CLAMP (FOR IC PIPE)	TATA spare parts
252514604203	COATED CLAMP (FOR IC PIPE)	TATA spare parts
252514605301	GASKET BETWEEN CAST PIPE UPPER & LOWER	TATA spare parts
252514605801	RUBBER HOSE-50 I.D. X 80 LONG	TATA spare parts
252514605802	RUBBER HOSE 68DX80LONG 697TC CMVR/H TOR	TATA spare parts
252514605804	HOSE	TATA spare parts
252514605807	HOSE (TC OUTLET)	TATA spare parts
252514605810	RUBBER HOSE (IC PIPE TO GRID HEATER)	TATA spare parts
252514605811	REDUCER HOSE (TC OUT TO IC PIPE)	TATA spare parts
252514605814	HOSE (IC PIPE TO INTAKE ELBOW)	TATA spare parts
252514605816	HOSE (IC TO INTAKE ELBOW)	TATA spare parts
252514605821	HOSE (TC ADAPTOR TO IC PIPE)	TATA spare parts
252514605822	HOSE (TC ADAPTER TO PIPE)	TATA spare parts
252514605823	ASSY HOSE HUMP	TATA spare parts
252514605825	HOSE (TC TO IC )	TATA spare parts

252514605826	RUBBER HOSE	TATA spare parts
252514605832	HOSE INTERCOOLER OUTLET BS6	TATA spare parts
252514605833	REDUCER HOSE	TATA spare parts
252514605834	REDUCER HOSE	TATA spare parts
252514606902	ALUMINIUM PIPE (FROM T/C TO I/C)	TATA spare parts
252514606903	ALUMINIUM PIPE (FROM I/C TO ENGINE)	TATA spare parts
252514606904	PIPE (TC TO IC)	TATA spare parts
252514606905	PIPE (TC TO IC)	TATA spare parts
252514606910	INTERCOOLER PIPE	TATA spare parts
252514606912	PIPE (INTERCOOLER TO ELBOW)	TATA spare parts
252514606916	PIPE-IC TO ELBOW; COWL	TATA spare parts
252514606917	PIPE-IC TO ELBOW CAB	TATA spare parts
252514606921	PIPE (T.C TO I.C)	TATA spare parts
252514606943	PIPE (TC TO IC) LPT 1613 SLTC	TATA spare parts
252514606956	PIPE (IC TO ELBOW) LPT 1613 SLTC	TATA spare parts
252514606961	PIPE (IC TO INTAKE ELBOW)	TATA spare parts
252514606966	PIPE (TC TO IC)	TATA spare parts
252514606967	PIPE (TC ADAPTER TO IC)	TATA spare parts
252514606973	PIPE TC END (TC TO IC)	TATA spare parts
252514606974	PIPE IC END (TC TO IC)	TATA spare parts
252514606983	PIPE (IC TO AIR INTAKE ELBOW)	TATA spare parts
252514606985	PIPE (TC TO IC)	TATA spare parts
252514606986	PIPE (IC TO ELBOW)	TATA spare parts
252514606987	PIPE TC ADAPTER PIPE TO INTERCOOLER	TATA spare parts
252514606997	PIPE TC TO IC	TATA spare parts
252514606998	PIPE INTERCOOLER TO INTAKE ELBOW	TATA spare parts
252514609901	INTERCOOLER LP1510 697TC ENGINE	TATA spare parts
252514609902	INTERCOOLER LP1510 697TC ENGINE	TATA spare parts
252514609903	INTERCOOLER LP1510 697TC ENGINE	TATA spare parts
252514609906	INTERCOOLER-LPT613 E-II	TATA spare parts
252514609908	INTERCOOLER 2515-CMVR	TATA spare parts
252514609911	INTER COOLER (LPT 2515)	TATA spare parts
252514609914	INTERCOOLER	TATA spare parts
252514609916	INTERCOOLER INNER FIN TYPE (FRAMELESS)	TATA spare parts
252514609922	INTERCOOLER - LPT 1613 697 BS3 COWL	TATA spare parts
252514609923	INTERCOOLER ASSY	TATA spare parts
252514609927	INTERCOOLER ASSY	TATA spare parts
252514609928	INTERCOOLER ASSY	TATA spare parts
252514616902	PIPE (TC TO IC)	TATA spare parts
252514616903	PIPE INTERCOOLER TO ENGINE	TATA spare parts
252514616905	PIPE TC TO IC	TATA spare parts
252514616906	PIPE INTERCOOLER TO ELBOW	TATA spare parts
252514616907	PIPE TC TO IC	TATA spare parts
252514616914	PIPE	TATA spare parts
252514616915	PIPE TC TO IC	TATA spare parts
252514616917	PIPE ASSY TC OUT TO INTERCOOLER BS6	TATA spare parts
252514616918	PIPE TC TO IC	TATA spare parts

252514616920	PIPE INTERCOOLER TO AIR INTAKE PIPE	TATA spare parts
252514700130	ASSY COOLENT LINE ( INLET)	TATA spare parts
252514700134	ASSY COOLANT OUTLINE (EGR TO UCL)	TATA spare parts
252514700141	ASSY. COOLANT OUTLET LINE (EGR TO UCWL)	TATA spare parts
252514700144	ASSY COOLANT OUTLET LINE(EGR TO UWCL)	TATA spare parts
252514700145	ASSY INLET LINE(OIL COOLER COVER TO EGR)	TATA spare parts
252514700150	ASSY COOLANT INLET LINE (EGR COOLER)	TATA spare parts
252514700165	ASSEMBLY EGR COOLANT LINE-OUTLET	TATA spare parts
252514700167	ASSY COOLANT INLET LINE (OIL COOLER TO E	TATA spare parts
252514700172	ASSEMBLY EGR COOLANT LINE-OUTLET	TATA spare parts
252514700174	COOLANT PIPE ASSY INT OC TO EGR COOLER	TATA spare parts
252514700196	SUPPORT BRACKET ASSY	TATA spare parts
252514700199	ASSY SUPPORT BRACKET	TATA spare parts
252514700203	COOLANT PIPE ASSY EGR OUTLET	TATA spare parts
252514700210	EGR PIPE ASSY EGR TO UCWL	TATA spare parts
252515103704	INTERMEDIATE FLANGE 1313	TATA spare parts
252515103705	INTERME FLANGE HYD CLUTCH	TATA spare parts
252515140101	BRACKET ALTERNATOR MTG	TATA spare parts
252515140109	ASSY.TENSIONING ROD COMPLETE	TATA spare parts
252515140110	ASSY.TENSIONING ROD	TATA spare parts
252515140114	ASSY.BRACKET (ALTERNATOR MTG.)	TATA spare parts
252515140115	ASSY.BRACKET(ALTERNATOR & IDLER MTG)	TATA spare parts
252515140118	CLAMP ROD	TATA spare parts
252515140119	CLAMPING ROAD ASSY	TATA spare parts
252515140132	BRACKET 24V80A ALTERNATOR	TATA spare parts
252515140136	CLAMP ROD 24V80A ALTERNAT	TATA spare parts
252515140144	ASSY.CLAMPING ROD	TATA spare parts
252515140145	ASSY.BRACKET(ALTR MTG)	TATA spare parts
252515140147	ASSY.BRACKET (24V 75A.ALT.MTG)	TATA spare parts
252515140160	ASSY.BRACKET(90AMP)	TATA spare parts
252515140169	ASSEMBLY IDLER	TATA spare parts
252515140179	ASSEMBLY IDLER (8PK)	TATA spare parts
252515140182	ASSY CLAMPING ROD COMPLETE	TATA spare parts
252515140186	AUTO TENSIONER ASSY BS6	TATA spare parts
252515140193	SUPPORT BRACKET ALTERNATOR MTG BS6	TATA spare parts
252515140194	SUPPORT BRACKET ALTERNATOR MTG BS6	TATA spare parts
252515143401	BUSH ALTERNATOR MOUNTING	TATA spare parts
252515143402	BUSH ALTERNATOR MOUNTING	TATA spare parts
252515143405	SLEEVE ALTERNATOR	TATA spare parts
252515143701	BRACKET (ALTERNATOR & PSTRG MTG.)	TATA spare parts
252515143702	BRACKET ALTERNATOR MOUNTING	TATA spare parts
252515143703	BRACKET ALTERNATOR MOUNTING.	TATA spare parts
252515143706	BRACKET (CASTING)- 90AMP ALTE	TATA spare parts
252515143711	BRACKET AC & ALTERNATOR MTG	TATA spare parts
252515143716	BRACKET ALTERNATOR MTGBS6	TATA spare parts
252515143718	BRACKET ALTERNATOR MTG	TATA spare parts
252515143723	BRACKET ALTERNATOR MTG	TATA spare parts

252515144210	CLAMPING PIECE	TATA spare parts
252515146303	POLY V BELT 8PK 1260L	TATA spare parts
252515146303DF	BELT POLY V 8PK 1260MM L - 697BS3/4-1613	TATA spare parts
252515146307	POLY V-BELT BS6	TATA spare parts
252515146308	BELT ALTERNATOR	TATA spare parts
252515146502	CLAMPING NUT	TATA spare parts
252515148001	SCREW (FOR ALTERNATOR TENSIONER)	TATA spare parts
252515148206	PROTECTIVE COVER	TATA spare parts
252515148603	SPACER ALTERNATOR MTG BS6	TATA spare parts
252515148801	SLIDER BOLT (FOR ALTERNATOR TENSIONER)	TATA spare parts
252515148802	SUPPORT BRACKET	TATA spare parts
252515148803	SUPPORT BRACKET	TATA spare parts
252515148804	SUPPORT BRACKET	TATA spare parts
252515148805	SUPPORT BRACKET	TATA spare parts
252515189902	LAMBDA SENSOR BS6	TATA spare parts
252515209901	BOOST PRESSURE SENSOR : 697 BSIV	TATA spare parts
252515209902	SPEED SENSOR 697 BSIV	TATA spare parts
252515209903	CAM PHASE SENSOR 697 BSIV	TATA spare parts
252515209904	MASS AIR FLOW SENSOR HFM 497 BS3/4	TATA spare parts
252515209905	HFM SENSOR BS3/4	TATA spare parts
252515209906	DPS SENSOR BS3/4	TATA spare parts
252515209907	OIL PRESSURE & TEMPERATURE SENSOR BS6	TATA spare parts
252515209908	GAS PRESSURE SENSOR BS6	TATA spare parts
252515210101	ASSY. ELECTRONIC THROTTLE BODY - 57 MM	TATA spare parts
252515210102	ASSY. ELECTRONIC THROTTLE BODY(57MM) BS4	TATA spare parts
252515216901	PLUG FOR ETC(57 MM)	TATA spare parts
252515230102	ELECTRONIC THROTTLE BODY ASSY BS6-PH2	TATA spare parts
252515409901	SPARK PLUG 697 CNG BS4	TATA spare parts
252518100107	OIL PUMP ASSY	TATA spare parts
252518100116	KIT OIL PUMP GEAR	TATA spare parts
252518100118	OIL PUMP EXC	TATA spare parts
252518100121	OIL PUMP ASSY.SHORTER	TATA spare parts
252518100123	OIL LINE ASSY	TATA spare parts
252518100129	OIL LINE ASSY	TATA spare parts
252518100139	OIL PUMP ASSY SHORTER	TATA spare parts
252518100141	ASSY OIL PUMP SE1613 HI TORQUE	TATA spare parts
252518100142	ASSEMBLY OIL PUMP WITH STRAINER	TATA spare parts
252518100143	ASSY.OIL PUMP WITH STRAINER.	TATA spare parts
252518100144	ASSY. OIL PUMP(50 MM)W/O STRAINER BS1- 4	TATA spare parts
252518100146	ASSY DRIVE SHAFT(50 MM GEAR)	TATA spare parts
252518100147	ASSY.OIL PUMP WITH STRAINER	TATA spare parts
252518100148	ASSY. OIL PUMP W/STRAINER (50MM G) BS1-4	TATA spare parts
252518100149	ASSY.OIL PUMP WITH STRAINER (50 MM GEAR)	TATA spare parts
252518100150	ASSY.OIL PUMP WITH STRAINER (50 MM GEAR)	TATA spare parts
252518100151	ASSY. OIL PUMP W/STRAINER(50MM GEAR) BS1	TATA spare parts
252518100160	OIL PUMP ASSY	TATA spare parts
252518100161	OIL PUMP ASSY WITH STRAINER	TATA spare parts

252518100164	OIL PUMP ASSY WITH STRAINER	TATA spare parts
252518103201	BOLT	TATA spare parts
252518103703	HOUSING OIL PUMP	TATA spare parts
252518103704	OIL PUMP HOUSING (FOR 50 MM LONG GEARS)	TATA spare parts
252518103802	COVER OIL PUMP ASSY	TATA spare parts
252518105301	GASKET OIL PUMP TO STRAINER	TATA spare parts
252518105401	GEAR OIL PUMP DR SHAFT	TATA spare parts
252518105402	GEAR OIL PUMP DRIVEN	TATA spare parts
252518105403	GEAR OIL PUMP DR SHAFT	TATA spare parts
252518105404	GEAR OIL PUMP DRIVEN	TATA spare parts
252518105405	50 MM OIL PUMP GEAR (DRIVE SHAFT)	TATA spare parts
252518105406	50 MM OIL PUMP GEAR (DRIVEN SHAFT)	TATA spare parts
252518105407	GEAR OIL PUMP	TATA spare parts
252518105408	GEAR DRIVEN SHAFT	TATA spare parts
252518107201	PLUG	TATA spare parts
252518107901	SHAFT OIL PUMP DR GEAR	TATA spare parts
252518107902	DRIVE SHAFT OIL PUMP	TATA spare parts
252518107905	DRIVE SHAFT OIL PUMP	TATA spare parts
252518107906	SHAFT	TATA spare parts
252518109901	EXTENSION PIECE	TATA spare parts
252518130106	ASSY OIL FILTER W/O CARTRIDGE(30MU) CMVR	TATA spare parts
252518130124	OIL FILTER ELEMENT (CARTRIDGE) BS1/2/3	TATA spare parts
252518130125	OIL FILTER CARTRIDGE CMVR 2000 30MU	TATA spare parts
252518130126	ASSY.OIL FILTER COMPLETE	TATA spare parts
252518130127	ASSY OIL FILTER (30MICRONS) CMVR 2K1510/	TATA spare parts
252518130128	ASSY.OIL FILTER COMPLETE(30MICRON)697NA	TATA spare parts
252518130129	ASSY OIL FILTER ELEMENT 697 CMVR2K LONG	TATA spare parts
252518130130	OIL FILTER CARTRIDGE CMVR 2000	TATA spare parts
252518130137	ASSY.OIL FILTER COMP.(SPINON)	TATA spare parts
252518130138	ASSY.OIL FILTER HEAD(SPIN ON)	TATA spare parts
252518130139	OIL FILTER ELEMENT SPINON BS2/3/4	TATA spare parts
252518130141	ASSY. SOCKET (WATER OUTLET)	TATA spare parts
252518130144	MALE STUD COUPLING BODY	TATA spare parts
252518130158	HEAD ASSY. SPIN ON OIL FILTER	TATA spare parts
252518130159	HEAD ASSY.SPIN ON OIL FILTER	TATA spare parts
252518130160	HEAD & LUBE FILTER ASSY.SPIN ON	TATA spare parts
252518130161	HEAD & LUBE FILTER ASSY.SPIN ON (FG)W/O	TATA spare parts
252518130162	ASSY OIL LINE (OIL FILTER TO FIP)	TATA spare parts
252518130163	ASSY OIL FILTER	TATA spare parts
252518130164	OIL FILTER ELEMENT SPINON BS3/4	TATA spare parts
252518130166	HEAD ASSY	TATA spare parts
252518130175	OIL FILTER ELEMENT ASSY	TATA spare parts
252518130177	OIL FILTER ASSY BS6	TATA spare parts
252518130178	LUBRICATION FILTER ASSY WITH HEAD BS6	TATA spare parts
252518130179	FILTER HEAD ASSY BS6	TATA spare parts
252518135303	GASKET OIL FILTER ON CYL BLOCK	TATA spare parts
252518135306	GASKET OIL FILTER	TATA spare parts

252518150103	SUCTION TUBE W/STRAINER	TATA spare parts
252518150111	SUCTION TUBE W/STRAINER	TATA spare parts
252518150113	SUCTION TUBE W/STRAINER	TATA spare parts
252518150115	ASSEMBLY STRAINER-OIL PUMP	TATA spare parts
252518150116	ASSEMBLY STRAINER OIL PUMP	TATA spare parts
252518150140	ASSY.STRAINER-OIL PUMP	TATA spare parts
252518150141	STRAINER ASSY OIL PUMP	TATA spare parts
252518150143	STRAINER ASSY OIL PUMP	TATA spare parts
252518150144	STRAINER OIL PUMP BS6-PH2	TATA spare parts
252518153501	BOSS	TATA spare parts
252518170104	FLANGE TC OIL OUTLET	TATA spare parts
252518170106	OIL COOLER ASSY	TATA spare parts
252518170107	TUBE ASSY	TATA spare parts
252518170108	NOZZLE ASSY	TATA spare parts
252518170109	RELIEF VALVE	TATA spare parts
252518170125	OIL COOLER ASSY	TATA spare parts
252518170143	ASSY OIL COOLER ELECT O PR GAUGE	TATA spare parts
252518170150	ASSY.RELIEF VALVE.	TATA spare parts
252518170151	ASSY LUBE LINE	TATA spare parts
252518170152	ASSY OIL OUTLET TUBE	TATA spare parts
252518170154	ASSY.OIL RETURN LINE ON OIL SUMP-SE1613	TATA spare parts
252518170155	ASSY LUBE LINE ( OIL COOLER TO TC ) SE16	TATA spare parts
252518170157	OIL OUTLET TUBE(TC TO CYL.BLK)-LPT1613CM	TATA spare parts
252518170160	ASSY. PISTON COOL NOZZLE W/DOWEL BS1- 4	TATA spare parts
252518170167	OIL OUTLET TUBE(TC TO CYL.BLK)-SE1613CMV	TATA spare parts
252518170168	PLATE TYPE H/ EXCHANGER 697TC	TATA spare parts
252518170169	ASSY OIL COOLER PLATE TYPE H.EXCHANGER	TATA spare parts
252518170171	ASSY.LUBE LINE (LPT1613HOLSET HIGH.& STD	TATA spare parts
252518170174	ASSY.OIL LINE OIL FILTER TO FIP-697	TATA spare parts
252518170175	ASSY.LUBE OIL LINE(PLATE C TO TOURBOCHAR	TATA spare parts
252518170176	ASSY.OIL LINE FLEXIBLE-OFFER DRG	TATA spare parts
252518170178	ASSY.LUBE OIL LINE PLATE C TO HOLSET TC	TATA spare parts
252518170181	ASSY.LUBE LINE	TATA spare parts
252518170182	ASSY. LUB LINE	TATA spare parts
252518170184	ASSY OIL COOLER PLATE TYPE H.EXCHANGER	TATA spare parts
252518170185	ASSEMBLY LUBE LINE (OIL COOLER TO TC)	TATA spare parts
252518170186	ASSEMBLY LUBE LINE (FLXIBLE)	TATA spare parts
252518170187	ASSEMBLY LUBE LINE (FLEXIBLE)	TATA spare parts
252518170188	ASSY.LUBE LINE(COOLER TO TC W/FLANGE)	TATA spare parts
252518170190	ASSY.OIL LINE (OIL FILTER TO A/C INLET)	TATA spare parts
252518170191	ASSY.OIL COOLER WITH PLATE TYPE HT.EXCH.	TATA spare parts
252518170192	ASSY. OIL OUTLET TUBE WITH HOSE(CRIMPED)	TATA spare parts
252518170196	ASSY. LUBE LINE (FLEXIBLE)	TATA spare parts
252518170197	OIL COOLER ASSY	TATA spare parts
252518170198	ASSY. OIL COOLER WITH COVER BS1/2/3	TATA spare parts
252518170203	ASSY.OIL COOLER WITH COVER & NVH PADS	TATA spare parts
252518170204	ASSY.OIL COOLER WITH COVER & NVH PADS	TATA spare parts

252518170205	ASSY. LUBE LINE (FLEXIBLE)	TATA spare parts
252518170207	ASSY OIL OUTLET TUBE WITH CRIMPED HOSE	TATA spare parts
252518170208	ASSY OIL OUTLET TUBE WITH CRIMPED HOSE	TATA spare parts
252518170209	ASSY. ADAPTER (OIL RETURN)	TATA spare parts
252518170211	ASSY. OIL COOLER COMPLETE	TATA spare parts
252518170213	ASSY LUBE LINE(OIL FILTER TO A/C)	TATA spare parts
252518170225	NOZZLE ASSY WITH DOWEL PIN (1-3-5)	TATA spare parts
252518170226	NOZZLE ASSY WITH DOWEL PIN (2-4-6)	TATA spare parts
252518170230	ASSY. OIL COOLER WITH 6 PLATE TYPE HT.EX	TATA spare parts
252518170231	ASSY. 6 PLATE TYPE HEAT EXCHANGER (POSH)	TATA spare parts
252518170232	ASSY. OIL COOLER COMPLETE	TATA spare parts
252518170244	ASSY OIL OUTLET TUBE WITH CRIMP HOSE	TATA spare parts
252518170248	ASSY TC OIL RETURN LINE	TATA spare parts
252518170249	ASSEMBLY LUBE LINE	TATA spare parts
252518170252	ASSY. OIL COOLER 8 PLATE HEAT EXCHANGER	TATA spare parts
252518170253	ASSY 8 PLATE TYPE HEAT EXCHANGER BS6	TATA spare parts
252518170257	HOSE ASSY	TATA spare parts
252518170266	ASSY LUBE LINE	TATA spare parts
252518170271	TC OIL SUPPLY LINE ASSY BS6	TATA spare parts
252518170272	OIL RETURN PIPE ASSY TURBOCHARGER BS6	TATA spare parts
252518170281	OIL SUPPLY LINE ASSY AIR COMPRESSOR	TATA spare parts
252518170282	OIL SUPPLY LINE ASSY AIR COMPRESSOR	TATA spare parts
252518170291	OIL OUTLET LINE ASSY TC	TATA spare parts
252518170293	PISTON COOLING NOZZLE ASSY	TATA spare parts
252518170301	OIL OUTLET LINE ASSY TC	TATA spare parts
252518170302	OIL LINE ASSY OIL COOLER TO TC	TATA spare parts
252518170305	OIL OUTLET LINE ASSY TC	TATA spare parts
252518170313	OIL SUPPLY LINE ASSY AIR COMPRESSOR BS6	TATA spare parts
252518170316	OIL COOLER ASSY WITH COVER BS6-PH2	TATA spare parts
252518173204	DOUBLE PIPE UNION BOLT 6 M10X1	TATA spare parts
252518173304	BRACKET	TATA spare parts
252518173308	BRACKET BS6	TATA spare parts
252518173709	MALE STUD ELBOW BODY	TATA spare parts
252518173805	OIL COOLER COVER AL-PLATE TYPE	TATA spare parts
252518173808	OIL COOLER COVER BS1/2/3	TATA spare parts
252518173809	OIL COOLER COVER	TATA spare parts
252518173812	OIL COOLER COVER-6 PLATE COOLER M/S POSH	TATA spare parts
252518175101	FLANGE	TATA spare parts
252518175301	GASKET	TATA spare parts
252518175302	GASKET FLANGE	TATA spare parts
252518175304	GASKET(HEAT EXCHANGER TO OIL C.COVER)	TATA spare parts
252518175305	GASKET (FOR 697 OIL COOLER COVER- PN_NJ)	TATA spare parts
252518175310	GASKET (OIL PIPING) OUTLET	TATA spare parts
252518175312	GASKET OIL COOLER	TATA spare parts
252518175801	RUBBER HOSE	TATA spare parts
252518175802	HOSE TC OIL OUTLET TO BLOCK BS1/2/3	TATA spare parts
252518177201	SCREW PLUG	TATA spare parts



252518177202	CONNECTOR	TATA spare parts
252518177701	OIL COOLER DAMPER	TATA spare parts
252518179201	SEALING WASHER	TATA spare parts
252518179202	SEALING WASHER	TATA spare parts
252518179908	HEX. SCREW M8X1.25X43 LENGTH	TATA spare parts
252518179909	WASHER DIA 17 X 1.6 THK.	TATA spare parts
252518179910	WASHER DIA 24 X 1.6 THK	TATA spare parts
252518179911	BUSH	TATA spare parts
252518179914	WASHER DIA 22X1.6 THK BS6	TATA spare parts
252518179915	BUSH DIA 22X1.5 BS6	TATA spare parts
252518179916	LOCK NUT DIA 22X1.5 BS6	TATA spare parts
252518179919	GASKET BS6	TATA spare parts
252518179921	WASHER DIA 17X1.6THK BS6	TATA spare parts
252518990123	KIT-SPIN ON OIL FILTER WITH GASKET & FAS	TATA spare parts
252520100101	REP KIT W/PUMP 0105 MNR	TATA spare parts
252520100102	REP KIT W/PUMP 0105 MJR	TATA spare parts
252520100103	WATER PUMP ASSY	TATA spare parts
252520100105	WATER PUMP ASSY	TATA spare parts
252520100106	ASSY WATER PUMP	TATA spare parts
252520100107	WATER PUMP ASSY	TATA spare parts
252520100109	WATER PUMP ASSY	TATA spare parts
252520100110	ASSY COVER	TATA spare parts
252520100113	REP KIT W/PUMP 0109 MNR	TATA spare parts
252520100114	REP KIT W/PUMP 0107 MJR	TATA spare parts
252520100115	KIT WATER PUMP MINOR	TATA spare parts
252520100116	ASSY. WATER PUMP BS2	TATA spare parts
252520100117	WATER PUMP ASSY	TATA spare parts
252520100118	REP KIT W/PUMP 0116 MNR	TATA spare parts
252520100119	MAJOR REPAIR KIT-WATER PUMP BS1/2/3/4	TATA spare parts
252520100121	ASSY. WATER PUMP BS2/3	TATA spare parts
252520100124	ASSY. WATER PUMP BS1/2/3/4	TATA spare parts
252520100125	ASSY. WATER PUMP(STD) BS2/3	TATA spare parts
252520100126	ASSY.WATER PUMP (BS-III)	TATA spare parts
252520100130	ASSY.WATER PUMP (LPT1618 LHD)	TATA spare parts
252520100131	ASSY WATER PUMP	TATA spare parts
252520100132	INSERT (FOR WATER PUMP)	TATA spare parts
252520100137	KIT-MINOR-WATERPUMP- 252520100126	TATA spare parts
252520100138	KIT-MAJOR-WATERPUMP- 252520100126	TATA spare parts
252520100141	ASSY. WATER PUMP(INT SFT BRG) BS1/2/3/4	TATA spare parts
252520100142	IMPELLER (PLASTIC) BS6	TATA spare parts
252520100145	ASSY. WATER PUMP-INT.SHAFT BRG BS1/2/3/4	TATA spare parts
252520100150	ASSY. WATER PUMP W/ADAPTOR BS3/4	TATA spare parts
252520100161	WATER PUMP	TATA spare parts
252520100162	IMPELLER	TATA spare parts
252520100164	WATER PUMP	TATA spare parts
252520100165	IMPELLER BS6	TATA spare parts
252520100166	WATER PUMP	TATA spare parts

252520100176	WATER PUMP ASSY (INTEGRAL SHAFT BRG.)	TATA spare parts
252520100177	WATER PUMP ASSY (INTERGRAL SHAFT BRG)	TATA spare parts
252520100180	ASSY. WATER PUMP BS3/4	TATA spare parts
252520100181	ASSY. WATER PUMP	TATA spare parts
252520100182	ASSY. WATER PUMP BS3/4	TATA spare parts
252520103101	BEARING TAPER ROLLER	TATA spare parts
252520103105	WATER PUMP BEARING BALL AND ROLLER BS6	TATA spare parts
252520103110	BALL & ROLLER BEARING WATER PUMP BS6	TATA spare parts
252520103701	COVER WATER PUMP	TATA spare parts
252520103702	IMPELLER WATER PUMP	TATA spare parts
252520103704	HOUSING WATER PUMP	TATA spare parts
252520103709	WATER PUMP BACK COVER (STANDARD)	TATA spare parts
252520103710	HOUSING WATER PUMP	TATA spare parts
252520103711	WATER PUMP BACK COVER (WITH PLASTIC IMPE	TATA spare parts
252520103712	BACK COVER	TATA spare parts
252520103720	BACK COVER WATER PUMP	TATA spare parts
252520103722	WATER PUMP HOUSING	TATA spare parts
252520103741	BACK COVER	TATA spare parts
252520103744	WATER PUMP HOUSING	TATA spare parts
252520103802	ADAPTOR M/S AUTOLEC	TATA spare parts
252520105102	COVER WATER PUMP	TATA spare parts
252520105301	GASKET WATER PUMP	TATA spare parts
252520105302	GASKET W/PUMP	TATA spare parts
252520105310	FIBER GASKET BS6	TATA spare parts
252520105318	GASKET(FIBER)	TATA spare parts
252520105501	HUB-WATER PUMP SHAFT	TATA spare parts
252520105504	HUB-WATER PUMP SHAFT	TATA spare parts
252520105505	HUB-WATER PUMP SHAFT	TATA spare parts
252520106101	LOCKING PLATE	TATA spare parts
252520107708	UNITISED SEAL BS6	TATA spare parts
252520107714	SEAL WATER PUMP (KACO)	TATA spare parts
252520107903	SHAFT WATER PUMP	TATA spare parts
252520108302	SHIM WATER PUMP 0.05MM	TATA spare parts
252520108303	SHIM 0.1MM THK	TATA spare parts
252520108304	SHIM 0.15MMTHK	TATA spare parts
252520108305	SHIM 0.2 THK.	TATA spare parts
252520108306	SHIM 0.5MMTHK	TATA spare parts
252520109904	ALLEN BOLT M8X30	TATA spare parts
252520109905	HEX. BOLT M8X20	TATA spare parts
252520109906	HEX BOLT M8X30	TATA spare parts
252520109907	O RING M/S AUTOLEC	TATA spare parts
252520109908	HEX. BOLT M8X55	TATA spare parts
252520120107	THERMOSTAT ASSY BELLOW TYPE	TATA spare parts
252520120108	THERMOSTAT	TATA spare parts
252520120109	UPP.COOL.WATER LINE	TATA spare parts
252520120113	UPP.COOL.WATER LINE	TATA spare parts
252520120117	UPP.COOL.WATER LINE	TATA spare parts

252520120118	REPAIR KIT MINOR W/PUMP	TATA spare parts
252520120119	REPAIR KIT MAJOR W/PUMP	TATA spare parts
252520120129	THERMOSTAT ASSY	TATA spare parts
252520120131	THERMOSTAT ASSY	TATA spare parts
252520120137	THERMOSTAT ASSY WAX TYPE	TATA spare parts
252520120143	ASSY.TEE CONNECTOR	TATA spare parts
252520120148	THERMOSTAT ASSY.	TATA spare parts
252520120156	ASSY.UPPER COOLING WATER LINE	TATA spare parts
252520120158	ASSY.UPPER COOLING WATER LINE	TATA spare parts
252520120159	ASSY UPPER COOLING WATER LINE (LP713)	TATA spare parts
252520120161	THERMOSTAT 697 NYLON HSG	TATA spare parts
252520120162	UPPER COOLING WATER LINE SE1613TURBO	TATA spare parts
252520120164	UPPER COOLING WATER LINE(LP/LPT)1613TURB	TATA spare parts
252520120165	ASSY THERMOSTAT 83 DEGREE S.O.T.	TATA spare parts
252520120167	THERMOSTAT ASSY-83DEG.SOT-SE	TATA spare parts
252520120170	THERMOSTAT 697 NYLON HSG	TATA spare parts
252520120173	THERMOSTAT ASSY SE/SK	TATA spare parts
252520120174	THERMOSTAT LP/LPT	TATA spare parts
252520120175	ASSY THERMOSTAT	TATA spare parts
252520120176	ASSY.UPPER COOLING WATER LINE	TATA spare parts
252520120177	ASSY.THERMOSTAT- SE-83DEG-BOLTED	TATA spare parts
252520120178	ASSY.UPPER COOLING WATER LINE(LPT613-EII	TATA spare parts
252520120181	ASSY.THERMOSTAT 83D-CU BR-SE	TATA spare parts
252520120182	ASSY.UPPER COOLING WATER LINE EURO-III	TATA spare parts
252520120183	ASSY THERMOSTAT-35DIA BYPASS	TATA spare parts
252520120184	ASSY. THERMOSTAT-35DIA BYPASS BS1/2/3/4	TATA spare parts
252520120196	ASSY. THERMOSTAT EURO2	TATA spare parts
252520120199	ASSY.UPPER COOLING W.LINE(FLAME START)	TATA spare parts
252520120203	ASSY. UPPER COOLING WATER LINE	TATA spare parts
252520120204	ASSY. UPPER COOLING WATER LINE	TATA spare parts
252520120210	ASSY UPPER COOLING WATER LINE	TATA spare parts
252520120211	ASSY. UPPER COOLING WATER LINE	TATA spare parts
252520120214	ASSY UPPER WATER COOLING LINE	TATA spare parts
252520120216	ASSY UPPER COOLING WATER LINE¿ (LPT 613	TATA spare parts
252520120218	ASSY UPPER WATER COOLING LINE - FRONT	TATA spare parts
252520120220	ASSY UPPER WATER COOLING LINE	TATA spare parts
252520120224	ASSY UPPER COOLING WATER LINE	TATA spare parts
252520120242	ASSY. UPPER WATER COOLING LINE	TATA spare parts
252520120248	ASSY.THERMOSTAT(35DIA BYPASS)	TATA spare parts
252520120260	ASSY. UPPER WATER COOLING LINE	TATA spare parts
252520120273	ASSY.SOCKET (WATER OUTLET)	TATA spare parts
252520120286	WATER PIPE ASSY TURBOCHARGER OUTLET BS6	TATA spare parts
252520120287	ASSY COOLANT LINE (FRONT)	TATA spare parts
252520120291	UPPER COOLING WATER PIPE ASSY	TATA spare parts
252520120293	COOLANT LINE ASSY FRONT BS6	TATA spare parts
252520120298	UPPER COOLING WATER PIPE ASSY	TATA spare parts
252520120309	ASSY. THERMOSTAT BS4	TATA spare parts

252520120310	THERMOSTAT ASSY	TATA spare parts
252520120314	HOSE ASSY BS6	TATA spare parts
252520120318	WATER PIPE ASSY TURBOCHARGER INTAKE BS6	TATA spare parts
252520120319	UPPER COOLING WATER PIPE ASSY	TATA spare parts
252520120320	WATER PIPE ASSY TURBOCHARGER OUTLET BS6	TATA spare parts
252520121601	ASSY. THERMOSTAT W/O BYPASS - 87 C	TATA spare parts
252520121602	ASSY.THERMOSTAT (W/O BYPASS 87DEG)	TATA spare parts
252520123302	SUPPORT BRACKET (TC COOLANT OUTLET LINE)	TATA spare parts
252520123701	TOP COVER	TATA spare parts
252520123810	COVER RE	TATA spare parts
252520123811	TOP COVER	TATA spare parts
252520123814	COVER - THERMOSTAT	TATA spare parts
252520123822	UPPER COOLING WATER LINE	TATA spare parts
252520125003	FLANGE	TATA spare parts
252520125301	GASKET	TATA spare parts
252520125304	GASKET UP WATER COOL LINE	TATA spare parts
252520125306	GASKET COOLANT CONNECTOR	TATA spare parts
252520125802	RUBBER HOSE	TATA spare parts
252520125803	RUBBER HOSE	TATA spare parts
252520125808	RUBBER HOSE	TATA spare parts
252520125817	HOSE(THERMOSTAT TO W.PUMP)	TATA spare parts
252520125820	RUBBER HOSE	TATA spare parts
252520125821	RUBBER HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
252520125841	RUBBER HOSE (UCWL TO THERMOSTAT)	TATA spare parts
252520125842	RUBBER HOSE (THERMOSTAT TO WATER PUMP)	TATA spare parts
252520125849	RUBBER HOSE	TATA spare parts
252520125850	HOSE	TATA spare parts
252520126802	SOCKET	TATA spare parts
252520137003	PULLEY WATER PUMP	TATA spare parts
252520137009	PULLEY WATER PUMP	TATA spare parts
252520137010	W PUMP PULLEY	TATA spare parts
252520137011	PULLEY WATER PUMP	TATA spare parts
252520137013	IDLER PULLEY-WATRE PUMP	TATA spare parts
252520140101	PULLEY	TATA spare parts
252520140102	ASSY PULLEY WATER PUMP	TATA spare parts
252520140103	FAN ASSY	TATA spare parts
252520140104	FAN ASSY	TATA spare parts
252520140105	ASSY. FAN BS1/2/3	TATA spare parts
252520140106	FAN ASSY	TATA spare parts
252520140108	FAN ASSY	TATA spare parts
252520140109	ASSY FAN (WITHOUT VISCOUS COUPLING)	TATA spare parts
252520140110	ASSY FAN WITH VISCOUS COUPLING-E II	TATA spare parts
252520140111	ASSY. VISCOUS COUPLING-EURO II BS1/2/3	TATA spare parts
252520140112	ASSY.BRACKET TOP-RH(FAN RING MTG)	TATA spare parts
252520140113	ASSY BRACKET TOP-LH(FAN RING MTG)	TATA spare parts
252520140114	ASSY.BRACKET BOTTOM-RH FAN RING MTG	TATA spare parts
252520140115	ASSY.BRACKET-BOTTOM-LH FAN RING MTG	TATA spare parts

252520140116	ASSY FAN(WITH VISCOUS COUPLING)2515TURBO	TATA spare parts
252520140117	ASSY. FAN (W/O VISCOUS COUPLING) BS1/2/3	TATA spare parts
252520140124	ROLLED PULLEY-WATER PUMP	TATA spare parts
252520140127	VISCO DRIVE WITH FAN	TATA spare parts
252520140128	VISCOUS COUPLING	TATA spare parts
252520140129	ASSY.FAN WITHOUT VISCOUS COUPLING	TATA spare parts
252520140131	ASSY.BRACKET-BOTTOM-RH (FOR FAN RING)	TATA spare parts
252520140133	FAN / FAN DRIVE ASSEMBLY	TATA spare parts
252520140135	FAN/ FANDRIVE ASSY (22 IN-LOW SPEED)	TATA spare parts
252520140136	BRACKET - TOP - LH FOR FAN RING MOUNTING	TATA spare parts
252520140137	BRACKET - TOP - RH FOR FAN RING MOUNTING	TATA spare parts
252520140138	ASSY JET RING FAN(22IN) WITH VISCOUS CO	TATA spare parts
252520140139	JET RING FAN	TATA spare parts
252520140140	VISCOUS COUPLING FOR JET RING FAN (22 IN	TATA spare parts
252520140142	JET RING FAN	TATA spare parts
252520140144	FAN / FAN DRIVE ASSY.	TATA spare parts
252520140145	VISCOUS COUPLING FOR JET RING FAN	TATA spare parts
252520140147	VISCOUS CLUTCH WITH FAN DML 550	TATA spare parts
252520140148	VISCO CLUTCH ASSY	TATA spare parts
252520140151	ROLLED PULLEY (WATER PUMP)-3 GR	TATA spare parts
252520140152	ASSY ROLLED PULLEY (WATER PUMP)-3 GR	TATA spare parts
252520140153	ASSY. VISCOUS FAN (550 DIA) BS3/4	TATA spare parts
252520140154	ASSY JET RING FAN	TATA spare parts
252520140155	ASSY VISCOUS COUPLING FOR JET RING FAN	TATA spare parts
252520143812	INTERMEDIATE RING FAN	TATA spare parts
252520143813	FAN INTER.RING 697NAENGINE	TATA spare parts
252520143815	INTERMEDIATE RING FAN	TATA spare parts
252520143824	INT/RING 697NA LPT1613	TATA spare parts
252520143826	INTERMEDIATE RING FAN	TATA spare parts
252520143831	FAN INTERMEDIATE RING	TATA spare parts
252520143833	INT/RING 697NA LPT2213	TATA spare parts
252520143837	SPACER(FOR FAN)73MM WIDTH	TATA spare parts
252520143839	FAN SHROUD RING 2515 TURBO	TATA spare parts
252520143842	SPACER FOR FAN	TATA spare parts
252520143843	SPACER FOR COMPRESSOR PULLEY	TATA spare parts
252520143844	SPACER (FOR FAN)	TATA spare parts
252520143845	SPACER (FOR FAN)	TATA spare parts
252520143847	FAN SPACER - 50	TATA spare parts
252520143851	SPACER FAN BS6	TATA spare parts
252520147009	WATER PUMP PULLEY	TATA spare parts
252520147011	WATER PUMP PULLEY-3	TATA spare parts
252520147013	PULLEY (FOR AIR COMPRESSOR & FAN DRIVE)	TATA spare parts
252520147014	PULLEY (FOR 13 CFM AIR COMPRESSOR)	TATA spare parts
252520147024	DOUBLE GROOVE PULLEY (230CC AIR COMP)	TATA spare parts
252520147025	WATER PUMP PULLEY	TATA spare parts
252520147028	WATER PUMP PULLEY	TATA spare parts
252520147029	WATER PUMP PULLEY	TATA spare parts

252520147031	WATER PUMP PULLEY	TATA spare parts
252520147035	PULLEY WATER PUMP BS6	TATA spare parts
252520147038	PULLEY FAN DRIVE BS6	TATA spare parts
252520148606	INTERMEDIATE SPACER FAN	TATA spare parts
252520153701	BEARING HOUDING	TATA spare parts
252520156301	V BELT	TATA spare parts
252520156302	V BELT	TATA spare parts
252520156303	V BELT	TATA spare parts
252520156305	V BELT COGGED 1280MM BS2/3/4	TATA spare parts
252520156305DF	BELT COGGED V 1450MM/1280MM L-497/697	TATA spare parts
252520156306	V BELT COGGED 1325 MM BS1/2/3/4	TATA spare parts
252520156306DF	BELT COGGED V 1325MM L - LP709	TATA spare parts
252520156307	V BELT COGGED	TATA spare parts
252520156310	V BELT (COGGED-1210 LG)	TATA spare parts
252520156310AE	V BELT (COGGED-1210 LG) 2523	TATA spare parts
252520156311	COGGED 'V' BELT (1255 LONG)	TATA spare parts
252520156312	COGGED V-BELT 1355 MM LONG	TATA spare parts
252520156314	V BELT GOGGED BS4	TATA spare parts
252520156323	COGGED V BELT-1450MM LONG	TATA spare parts
252520156325	V BELT COGGED 1325 MM LONG	TATA spare parts
252520156326	RAW EDGE COGGED V BELT 12	TATA spare parts
252520156327	V BELT COGGED 1325 MM LONG	TATA spare parts
252520156328	COGGED V BELT-1450MM LONG	TATA spare parts
252520156329	COGGED V-BELT 1355 MM LONG	TATA spare parts
252520156330	COGGED V-BELT 1355 MM LONG	TATA spare parts
252520156339	BANDED COGGED V BELT - 1280L	TATA spare parts
252520156342	COGGED BELT(980 LENGTH)	TATA spare parts
252520156343	V BELT COGGED 1325 LONG	TATA spare parts
252520156344	COGGED V BELT 995 MM LONG(IMPROVED)	TATA spare parts
252520156346	COGGED V BELT 1380 MM LONG	TATA spare parts
252520156347	COGGED V-BELT BANDED TYPE TWIN (1380MM)	TATA spare parts
252520156350	COGGED V-BELT BANDED TYPE TWIN (1280MM)	TATA spare parts
252520156366	POLY V-BELT BS6-PH2	TATA spare parts
252520158201	BRACKET	TATA spare parts
252520300101	ASSY COOLENT HOSE- 1200MM	TATA spare parts
252520300102	ASSY COOLENT HOSE- 2350MM	TATA spare parts
252520300104	ASSY COOLENT HOSE- 1000MMBS6	TATA spare parts
252520300106	ASSY. COOLENT HOSE - 2000MM	TATA spare parts
252520300109	COOLANT HOSE ASSY BS6-PH2	TATA spare parts
252520300111	COOLANT HOSE ASSY	TATA spare parts
252520305801	RUBBER HOSE	TATA spare parts
252520305803	RUBBER HOSE-THERMOSTAT TO W.P	TATA spare parts
252520305806	REDUCER HOSE THERMOSTAT TO WATER PUMP	TATA spare parts
252520305808	HOSE (THERMOSTATE TO WATER PUMP)	TATA spare parts
252520305811	HOSE (THERMOSTATE TO WATER PUMP) - 697 C	TATA spare parts
252520305812	COOLENT HOSE FOR CNG REGULATOR - 600 MM	TATA spare parts
252520305813	COOLENT HOSE FOR CNG REGULATOR - 800 MM	TATA spare parts

252520305814	COOLENT HOSE FOR CNG REGULATOR - 1000 MM	TATA spare parts
252520305815	COOLENT HOSE FOR CNG REGULATOR - 1150 MM	TATA spare parts
252520305816	COOLENT HOSE FOR CNG REGULATOR - 1400 MM	TATA spare parts
252520305821	HOSE (THERMOSTAT TO WATER PUMP)	TATA spare parts
252520305822	COOLENT HOSE FOR CNG REGULATOR - 1250 MM	TATA spare parts
252520305825	HOSE (THERMOSTAT TO WATER PUMP)	TATA spare parts
252520305830	HOSE BS6-PH2	TATA spare parts
252520990104	KIT-WATER PUMP REPAIR-MAJOR	TATA spare parts
252520990105	KIT-WATER PUMP REPAIR-MINOR	TATA spare parts
252520990107	KIT WATER PUMP REPAIR-MAJOR(252520100124)	TATA spare parts
252520990110	KIT-MINOR-WATER PUMP	TATA spare parts
252520990111	KIT-MAJOR-WATER PUMP	TATA spare parts
252520990114	KIT-MINOR-WATERPUMP-252520100141	TATA spare parts
252520990115	KIT-MAJOR-WATERPUMP 252520100141	TATA spare parts
252520990116	REPAIR KIT WATERPUMP MAJOR: 252520100150	TATA spare parts
252520990117	REPAIR KIT WATERPUMP MINOR: 252520100150	TATA spare parts
252522100102	ASSY LIFTING HOOK REAR	TATA spare parts
252522100105	ASSEMBLY LIFTING HOOK	TATA spare parts
252522100106	ASSY LIFTING HOOK (REAR)	TATA spare parts
252522100108	ASSY LIFTING HOOK LPT1613 SE	TATA spare parts
252522100109	ASSY LIFTING HOOK LPO1613	TATA spare parts
252522100111	ASSEMBLY LIFTING HOOK	TATA spare parts
252522100114	LIFTING HOOK ASSY	TATA spare parts
252522107105	LIFTING HOOK FRONT	TATA spare parts
252522107106	LIFTING HOOK RE	TATA spare parts
252522107108	HOOK-FRONT	TATA spare parts
252522107109	LIFTING HOOK REAR 697TC	TATA spare parts
252522107111	LIFTING HOOK (REAR)	TATA spare parts
252522107112	LIFTING HOOK (FRONT)	TATA spare parts
252522107118	LIFTING HOOK (REAR)	TATA spare parts
252522120101	ASSY BRACKET FABRICATED	TATA spare parts
252522120115	ASSY BRACKET-ENGINE MTG REAR	TATA spare parts
252522120116	ASSY ENGINE MOUNTING BRACKET-FRONT	TATA spare parts
252522123202	HEX COLLAR SCREW	TATA spare parts
252522123203	HEX COLLAR SCREW	TATA spare parts
252522123204	HEX COLLAR SCREW	TATA spare parts
252522125102	ENGINE MOUNTING ARM FRT	TATA spare parts
252522125104	ENGINE SUPPORT SUSP FRT	TATA spare parts
252522125105	ENGINE MOUNTING ARM FRONT(0 DEG)-2515	TATA spare parts
252522125109	ENGINE MTG ARM-FRONT BS6	TATA spare parts
252522150103	ASSY BRACKET REAR	TATA spare parts
252523110109	SILENT BLOCK BUSH TEN ROD	TATA spare parts
252523110113	CLAMPING LEVER ASSY	TATA spare parts
252523110115	ASSY BRACKET(FOR P.STRG.MTG)	TATA spare parts
252523110116	CLAMPING LEVER ASSEMBLY.	TATA spare parts
252523110122	ASSEMBLY BRACKET (FOR PSTRG. MTG.)	TATA spare parts
252523110126	ASSEMBLY CLAMP ROD	TATA spare parts

252523110129	ASSEMBLY CLAMP ROD	TATA spare parts
252523110133	ASSEMBLY CLAMP ROD	TATA spare parts
252523113401	INNER BUSH	TATA spare parts
252523113402	OUTER BUSH	TATA spare parts
252523113701	BRACKET (POWER STEERING MOUNTING)	TATA spare parts
252523113705	BRACKET (FOR PSTG PUMP MOUNTING)	TATA spare parts
252523113706	BRACKET (PSTG MOUNTING)	TATA spare parts
252523113710	BRACKET AC COMP MTG	TATA spare parts
252523116704	PIN	TATA spare parts
252523116705	PIVOT PIN	TATA spare parts
252523116801	COUPLING BODY (M36X2;M26X1.5)	TATA spare parts
252523116802	COUPLING BODY (M33X2 M36X2)	TATA spare parts
252523117005	PULLEY	TATA spare parts
252523117701	RUBBER BUSH	TATA spare parts
252523118602	SPACER	TATA spare parts
252523119904	BRACKET POWER STEERING MTG	TATA spare parts
252523119905	BRACKET POWER STEERING MTG	TATA spare parts
252523120101	ASSY.BRACKET (FOR IDLER PULLEY)	TATA spare parts
252523120102	ASSY.IDLER	TATA spare parts
252523120106	ASSY.IDLER	TATA spare parts
252523123101	BEARING TENSIONER ASSY	TATA spare parts
252523140108	ASSY.BRACKET(FOR AIR COPM.MOUNTING)	TATA spare parts
252523140109	SINGLE CYLINDER COMPRESSOR	TATA spare parts
252523140110	ASSY.PIPE UNION	TATA spare parts
252523140111	ASSY.AIR COMPR(WATER COOLED)	TATA spare parts
252523140112	ASSY.AIR COMP.WATER INLET LINE	TATA spare parts
252523140113	ASSY.BRACKET(FOR 230CC AIR COMP.MOUNTING)	TATA spare parts
252523140115	ASSY. TENSIONER PLATE WITH PULLEY	TATA spare parts
252523140117	ASSY.AIR COMP.WATER INLET LINE	TATA spare parts
252523140118	ASSY PIPE AIR COMPRESSOR INLET	TATA spare parts
252523140126	ASSEMBLY BANJO AND TUBE	TATA spare parts
252523140127	ASSY PIPE AIR COMPRESSOR INLET - LPO 161	TATA spare parts
252523140128	WATER INTAKE LINE ASSY-AIR COMP BS6	TATA spare parts
252523140129	ASSY CRIMPED HOSE WITH PIPE	TATA spare parts
252523140139	ASSY. PIPE AIR COMPRESSOR AIR INLET - LP	TATA spare parts
252523140146	WATER INTAKE PIPE ASSY AIR COMP BS6	TATA spare parts
252523140148	PIPE ASSY AIR COMP INTAKE BS6	TATA spare parts
252523140149	PIPE ASSY AIR FILTER TO AIR COMP BS6	TATA spare parts
252523140150	PIPE ASSY AIR FILTER TO AIR COMP BS6	TATA spare parts
252523140151	WATER INTAKE LINE ASSY AIR COMP BS6	TATA spare parts
252523140152	PIPE ASSY AIR COMP INTAKE BS6	TATA spare parts
252523140153	PIPE ASSY AIR FILTER TO AIR COMP BS6-PH2	TATA spare parts
252523140155	SUPPORT BRACKET ASSY BS6	TATA spare parts
252523140156	PIPE ASSY AIR COMP INTAKE BS6	TATA spare parts
252523143202	HEX BOLT	TATA spare parts
252523143203	BANJO BOLT	TATA spare parts
252523143301	SUPPORT BRACKET (GEAR DRIVEN COMPRESSOR)	TATA spare parts



252523143304	SUPPORT BRACKET (COMP.INTAKE PIPE)	TATA spare parts
252523143307	SUPPORT BRACKET GEAR DRIVEN COMPRESSOR B	TATA spare parts
252523143308	SUPPORT BRACKET BS6	TATA spare parts
252523143309	SUPPORT BRACKET BS6	TATA spare parts
252523143706	BRACKET (FOR 230CC A/C)	TATA spare parts
252523145401	ADDITIONAL COMPRESSOR GEAR	TATA spare parts
252523145802	HOSE (WATER OUTLET)	TATA spare parts
252523145806	HOSE (WATER OUTLET A/C HEAD)	TATA spare parts
252523145807	HOSE OIL RETURN	TATA spare parts
252523145809	HOSE (WATER OUTLET A/C HEAD)	TATA spare parts
252523145810	RUBBER HOSE (A/C TO EGR OUTLINE)	TATA spare parts
252523145814	HOSE WATER OUTLET AC HEAD BS6	TATA spare parts
252523146301	V BELT COGGRD (1050MM)	TATA spare parts
252523146302	V BELT COGGRD (995 MM)	TATA spare parts
252523146307	V BELT COGGED 1015 MM	TATA spare parts
252523146308	V BELT COGGED 1070 MM	TATA spare parts
252523146313	V-BELT COGGERD (1060L)	TATA spare parts
252523146316	V BELT COGGED (995L)	TATA spare parts
252523146319	BELT AC COMP	TATA spare parts
252523146321	BELT AC COMP	TATA spare parts
252523146701	PIVOT PIN	TATA spare parts
252523146703	PIVOT PIN	TATA spare parts
252523146801	SOCKET	TATA spare parts
252523147004	PULLEY (FOR ADDITIONAL AIR COMP.DRIVE)	TATA spare parts
252523147007	PULLEY (CASTING) (FOR 230CC AIR COMP.DRI	TATA spare parts
252523147009	IDLER PULLEY	TATA spare parts
252523147704	SEALING RING (GEAR DRIVEN AIR COMPRESSOR	TATA spare parts
252523148601	SPACER (PIVOT PIN)	TATA spare parts
252523149904	ADAPTOR	TATA spare parts
252523400103	CLAMPING LEVER ASSY	TATA spare parts
252523400105	CLAMPING LEVER ASSY	TATA spare parts
252523400106	ASSY BRACKET	TATA spare parts
252523400111	PUMP CARTRIDGE KIT	TATA spare parts
252523400113	SEAL KIT V PUMP	TATA spare parts
252523400116	ASSY.BRACKET (P/STRG.MTG.)	TATA spare parts
252523400117	BRACKET-STEERING PUMP(ON CYL.HEAD)	TATA spare parts
252523400128	CLAMPING ROD ASSY	TATA spare parts
252523403304	BRACKET PUMP MTG	TATA spare parts
252523403401	LONG BUSH	TATA spare parts
252523403704	BRACKET-STEERING PUMP (ON CYL.HEAD)	TATA spare parts
252523407002	PULLEY PUMP	TATA spare parts
252523407003	PULLEY PUMP	TATA spare parts
252523407005	PULLEY P/S PUMP	TATA spare parts
252523407006	PULLEY (POWER STEERING):CAST	TATA spare parts
252523407008	PULLEY (POWER STEERING PUMP )	TATA spare parts
252523407102	PLATE	TATA spare parts
252523407801	OIL SEAL	TATA spare parts

252523407802	O RING	TATA spare parts
252523407803	O RING	TATA spare parts
252523408601	SPACER	TATA spare parts
252525103540	CLUTCH HSG. FULLY FINISH-330DIA. BS1/2/3	TATA spare parts
252525103701	CLUTCH HSG.310D	TATA spare parts
252525103703	CLUTCH HOUSING GBC 40 RHD	TATA spare parts
252525103704	CLUTCH HSG.310D	TATA spare parts
252525103722	CLUTCH HSG.310D	TATA spare parts
252525103727	CLUTCH HSG.	TATA spare parts
252525103728	CLUTCH HSG.	TATA spare parts
252525103735	CLUTCH HOUSING 613/713	TATA spare parts
252525103737	CLUTCH HOUSING 330DIA CLUTCH	TATA spare parts
252525103740	CLUTCH HOUSING (310 DIA BS-III)	TATA spare parts
252525103741	CLUTCH HOUSING (310 DIA)	TATA spare parts
252525103742	CLUTCH HOUSING (SUITABLE FOR 330 DIA. CL	TATA spare parts
252525103745	CLUTCH HOUSING (SUITABLE FOR 330D CLCH)	TATA spare parts
25252510374520	CLUTCH HOUSING ( 330D CLCH) FINISH	TATA spare parts
252525103747	CLUTCH HOUSING	TATA spare parts
252525106301	CLUTCH HOUSING LOWER PART	TATA spare parts
252525106701	PIN( FOR ENGINE TIMING SETTING)	TATA spare parts
252525107701	CLUTCH COVER DAMPER	TATA spare parts
252525108206	CLUTCH HOUSING LOWER PART(330 DIA CL HSG	TATA spare parts
252525406101	LOCKING PLATE	TATA spare parts
252525406501	ADJUSTING NUT	TATA spare parts
252525406702	PIN	TATA spare parts
252525408401	SLEEVE	TATA spare parts
252525408701	ANTIRATTLE SPG	TATA spare parts
252525408703	SPRING PLATE	TATA spare parts
252526200118	ASSY.HELICAL GEAR 3RD SPEED	TATA spare parts
252530137003	PULLEY	TATA spare parts
252540140101	PRESSURE REGULATOR VALVE	TATA spare parts
252540150101	AIR CYLINDER	TATA spare parts
252540150102	AIR CYLINDER	TATA spare parts
252550000103	RADIATOR FRAME	TATA spare parts
252550000105	RADIATOR FRAME	TATA spare parts
252550000112	RADIATOR FRAME	TATA spare parts
252550000137	ASSY.BRACKET-LH	TATA spare parts
252550000138	BRACKET RH	TATA spare parts
252550000141	FRAME - RADIATOR	TATA spare parts
252550000146	ASSY SPACER TUBE	TATA spare parts
252550000148	ASSY RAD.FRAME 3 PT. MTG.	TATA spare parts
252550000149	RADIATOR FRAME	TATA spare parts
252550000153	ASSY RADIATOR FRAME	TATA spare parts
252550000154	ASSY RADIATOR FRAME	TATA spare parts
252550000155	ASSY RADIATOR FRAME	TATA spare parts
252550000168	ASSY RADIATOR FRAME LPT1613	TATA spare parts
252550000170	ASSEMBLY RADIATOR MOUNTING FRAME	TATA spare parts

252550000175	ASSY RADIATOR FRAME SE1613	TATA spare parts
252550000182	ASSY.RADIATOR FRAME LP1512TC-TRNS.TANK	TATA spare parts
252550000183	ASSY.BRACKET RAD 3RD PT MTG-ON COWL	TATA spare parts
252550000187	ASSY.RADIATOR FRAME	TATA spare parts
252550000190	ASSY RADIATOR FRAME WITH TOP BKT. SE/SK	TATA spare parts
252550000197	ASSY CROSS PLATE	TATA spare parts
252550000198	ASSY.RADIATOR FRAME WITH BRACKET	TATA spare parts
252550000203	ASSY.RAD.FRAME WITH BRACKET TRANS.TANK	TATA spare parts
252550000204	ASSY.BRACKET(RH)-ON LM	TATA spare parts
252550000205	ASSY.BRACKET(LH) ON LM.	TATA spare parts
252550000207	ASSY.SPACER TUBE 88 LONG	TATA spare parts
252550000208	ASSY.RADIATOR FRAME(SE/SK).	TATA spare parts
252550000212	ASSY.BRIDGE FOR RAD.TOP MTG.SE/SK1613	TATA spare parts
252550000213	ASSY.BRACKET-RH FOR BRIDGE MTG	TATA spare parts
252550000214	BRIDGE	TATA spare parts
252550000215	ASSY.BRACKET-LH FOR BRIDGE MTG	TATA spare parts
252550000216	ASSY.RAD.FRAME LPT2515 EX-TURBO	TATA spare parts
252550000222	ASSY BRACKET RAD FRAME SIDE MTG	TATA spare parts
252550000223	BRACKET-LH RAD FRAME SIDE MTG	TATA spare parts
252550000224	BRACKET-RH-RAD FRAME SIDE MTG	TATA spare parts
252550000225	BRACKET(RAD FRAME SIDE MTG)	TATA spare parts
252550000226	ASSY.RUBBER BUSH RAD FRAME SIDE MTG	TATA spare parts
252550000229	BRACKET-RH(ON L.M.-SIDE MTG)	TATA spare parts
252550000237	ASSY.BRACKET-LH RADIATOR FRAME SIDE MTG	TATA spare parts
252550000238	ASSY.BRACKER-RH RADIATOR FRAME SIDE MTG	TATA spare parts
252550000239	ASSY.BRACKET-LH(RADIATOR FRAME SIDE MTG)	TATA spare parts
252550000240	ASSY.BRACKET-RH(RADIATOR FRAME SIDE MTG)	TATA spare parts
252550000242	ASSY.BRACKET-LH RADIATOR FRAME SIDE MTG	TATA spare parts
252550000243	ASSY.BRACKET-RH-OM L.M.SIDE MTG	TATA spare parts
252550000244	ASSY.BRACKET ON L.M.-LH	TATA spare parts
252550000245	ASSY.BRACKET ON L.M.-RH	TATA spare parts
252550000247	BRACKET ON L.M. RAD FRAME SIDE MTG	TATA spare parts
252550000248	ASSY.BRACKET LH(RADIATOR FRAME SIDE MTG)	TATA spare parts
252550000249	ASSY.BRACKET RH(RADIATOR FRAME SIDE MTG)	TATA spare parts
252550000251	ASSY RADIATOR MTGFRAME COMPLETE	TATA spare parts
252550000263	ASSY CLAMP WITH SLEEVE-FOR HOSE	TATA spare parts
252550000271	ASSY BRACKET-LH (RADIATOR FRAME SIDE MTG)	TATA spare parts
252550000272	ASSY BRACKET-RH (RADIATOR FRAME SIDE MTG)	TATA spare parts
252550000275	BRACKET-LH (RADIATOR FRAME SIDE MTG)	TATA spare parts
252550000276	BRACKET-RH (RADIATOR FRAME SIDE MTG)	TATA spare parts
252550000282	BRACKET ASSY AIR INTAKE PIPE SUPPORT	TATA spare parts
252550000283	ASSY.RUBBER BUSH (RAD FRAME SIDE MTG)	TATA spare parts
252550000284	ASSY BRACKET (AIR INTAKE PIPE SUPPORT)	TATA spare parts
252550000285	ASSY BRACKET (RAD FRAME SIDE MTG LH)	TATA spare parts
252550000287	ASSY BRACKET (RAD FRAME MOUNING RH)	TATA spare parts
252550000290	ASSY BRACKET (AIR INTAKE PIPE SUPPORT)	TATA spare parts
252550000291	BRACKET ON L.M - LH (RAD.FRAME SIDE MTG)	TATA spare parts

25255000292	BRACKET ON L.M -RH (RAD.FRAME SIDE MTG)	TATA spare parts
25255000297	BRACKET ASSY	TATA spare parts
25255000305	ASSY. RADIATOR MTG. BRACKET- LH	TATA spare parts
25255000306	ASSY.RADIATOR MTG BRACKET-RH	TATA spare parts
25255000315	BRACKET ASSY RADIATOR MTG LM BS6	TATA spare parts
25255000316	BRACKET ASSY RADIATOR MTG LM BS6	TATA spare parts
25255000317	BRACKET ASSY BS6	TATA spare parts
25255000318	BRACKET ASSY BS6	TATA spare parts
25255000319	STAY ROD ASSY BS6	TATA spare parts
25255000320	BRACKET ASSY LONG	TATA spare parts
25255000321	BRACKET ASSY RADIATOR MTG BS6	TATA spare parts
25255000322	BRACKET ASSY RADIATOR MTG BS6	TATA spare parts
25255000323	STAY ROD ASSY BS6	TATA spare parts
25255000324	STAY ROD ASSY RADIATOR FRAME MTG BS6	TATA spare parts
252550003307	BRACKET BOTTOM	TATA spare parts
252550003321	BRACKET	TATA spare parts
252550003322	BRACKET RAD. 3RD PT MTG	TATA spare parts
252550003332	BRACKET RADIATOR 3RD PT MTG	TATA spare parts
252550003335	BRACKET ON LM FOR RAD.FRAME MOUNTING	TATA spare parts
252550003336	BRACKET ON LM FOR RAD. FRAME MOUNTING	TATA spare parts
252550003337	BRACKET ON LONG MEMBER (FOR RADIATOR FRA	TATA spare parts
252550005807	RUBBER HOSE	TATA spare parts
252550005808	RUBBER HOSE	TATA spare parts
252550005810	RUBBER HOSE	TATA spare parts
252550005811	RUBBER HOSE EPDM	TATA spare parts
252550005812	RUBBER HOSE EPDM	TATA spare parts
252550005813	REDUCER HOSE (28.6 O.D.TO 20 O.D.X 100L)	TATA spare parts
252550005814	HOSE(RAD TO W.PUMP)-MECH.FEED PUMP-BS-II	TATA spare parts
252550005815	HOSE(RAD.TO W.PUMP)-MECH.FEED PUMP-BSIII	TATA spare parts
252550005816	HOSE (RADIATOR TO WATER PUMP) SE/SK1613	TATA spare parts
252550005819	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252550005821	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252550005822	HOSE (ENGINE TO RADIATOR)	TATA spare parts
252550005823	HOSE HUMP	TATA spare parts
252550005824	VENT HOSE	TATA spare parts
252550005834	VENT HOSE - 1845L	TATA spare parts
252550005845	HOSE (RAD. TO W.P.)	TATA spare parts
252550005846	HOSE (RAD. TO W.P.)	TATA spare parts
252550005856	HOSE(RAD TO WP)	TATA spare parts
252550005857	HOSE(RAD TO WP)	TATA spare parts
252550005858	RUBBER HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252550005862	HOSE (RAD TO W.P)	TATA spare parts
252550005870	RUBBER BELLOW	TATA spare parts
252550006901	SPACER TUBE	TATA spare parts
252550006902	SPACER TUBE	TATA spare parts
252550006903	SPACER TUBE	TATA spare parts
252550006904	SPACER TUBE (170 LG) BS6	TATA spare parts

252550006906	TUBE L-30 LPT2515-697-145	TATA spare parts
252550007105	WASHER	TATA spare parts
252550008262	RADIATOR MTG BKT RH	TATA spare parts
252550008263	RADIATOR MTG BKT LH	TATA spare parts
252550008264	BRACKET-RH (RADIATOR MTG-BOTTOM)	TATA spare parts
252550008265	BRACKET-LH (RADIATOR MTG.BOTTOM)	TATA spare parts
252550008296	BRACKET	TATA spare parts
252550009202	STEP WASHER	TATA spare parts
252550009901	TIE ROD 235 LONG	TATA spare parts
252550009903	TIE ROD 325 LONG	TATA spare parts
252550009905	TIE ROD (315 LONG)	TATA spare parts
252550009920	BRACKET TIE ROD ASSY MTG LH	TATA spare parts
252550100105	WATER TANK AUX	TATA spare parts
252550100106	FILLER CAP RADIATOR	TATA spare parts
252550100107	RADIATOR ASSY	TATA spare parts
252550100113	ASSY RAD.BLOCK WITH FIL CAP & D COCK	TATA spare parts
252550100114	ASSY CAP-RADIATOR	TATA spare parts
252550100116	ASSY RAD.BLOCK WITH FIL CAP & D COCK	TATA spare parts
252550100120	ASSY. RADIATOR COMPLETE.	TATA spare parts
252550100122	RADIATOR ASSY	TATA spare parts
252550100124	RADIATOR ASSY	TATA spare parts
252550100137	ASY.RADIATOR BLOCK COMPL.	TATA spare parts
252550100140	VACUUM AND PRESSURE CAP	TATA spare parts
252550100141	RADIATOR ASSY	TATA spare parts
252550100166	RADIATOR ASSY	TATA spare parts
252550100167	CONNECTOR RAD TO W/PUMP	TATA spare parts
252550100169	RADIATOR ASSY EXP VOLUME	TATA spare parts
252550100174	ASSY RADIATOR BLOCK	TATA spare parts
252550100181	RADIATOR ASSY	TATA spare parts
252550100183	ASSY FILLER CAP	TATA spare parts
252550100184	RADIATOR ASSY	TATA spare parts
252550100186	ASSY. RADIATOR COMPLETE.	TATA spare parts
252550100189	ASSY. RADIATOR COMPLETE.	TATA spare parts
252550100195	ASSY RADIATOR CAP	TATA spare parts
252550100196	ASSY. RADIATOR COMPLETE.	TATA spare parts
252550100201	RADIATOR 1510LP/1612LPT	TATA spare parts
252550100222	RADIATOR 1612/1613 SE	TATA spare parts
252550100224	ASSY.RADIATOR COMPLETE. SFC	TATA spare parts
252550100225	ASSY. RADIATOR 697NA BS1	TATA spare parts
252550100228	ASSY.RADIATOR BLOCK COMPLETE LP/LPO	TATA spare parts
252550100232	ASSY RADIATOR COMP	TATA spare parts
252550100234	ASSY. RADIATOR COMPLETE.	TATA spare parts
252550100238	RADIATOR	TATA spare parts
252550100239	ASSY RADIATOR SE 1613	TATA spare parts
252550100240	ASSY RADIATOR LP/LPT 1613	TATA spare parts
252550100244	ASSY RADIATOR	TATA spare parts
252550100245	ASSY RADIATOR COMPLETE	TATA spare parts

252550100246	ASSY RADIATOR COMPLETE	TATA spare parts
252550100247	ASSY.RADIATOR COMPLETE. SFC	TATA spare parts
252550100251	ASSY RADIATOR COMPLETE	TATA spare parts
252550100252	ASSY.RADIATOR COMPLETE. SFC	TATA spare parts
252550100254	ASSY CONNECTOR (RADIATOR TO W.P) CABHEAT	TATA spare parts
252550100255	ASSY.RADIATOR COMPLETE	TATA spare parts
252550100259	ASSY.RADIATOR LPT1613 TURBO	TATA spare parts
252550100261	ASSEMBLY RADIATOR-OFFER DRG	TATA spare parts
252550100262	ASSY RADIATOR-SE/SK	TATA spare parts
252550100263	RADIATOR SUB ASSY.COMPLETE	TATA spare parts
252550100265	BOTTOM TANK ASSY.	TATA spare parts
252550100267	RADIATOR SUB ASSY.COMPLETE	TATA spare parts
252550100269	BOTTOM TANK ASSY.	TATA spare parts
252550100270	RESERVE TANK LP/LPT1613 TURBO	TATA spare parts
252550100278	ASSY RADIATOR -697 TC EURO - II	TATA spare parts
252550100280	ASSY RADIATOR LPT2515	TATA spare parts
252550100282	RADIATOR -SE/SK1613	TATA spare parts
252550100283	RESERVE TANK ASSY COMPLETE SE/SK1613CMVR	TATA spare parts
252550100284	ASSY.RADIATOR WITH TRANSLUCENT TANK	TATA spare parts
252550100285	RESERVE TANK ASSY	TATA spare parts
252550100286	RESERVE TANK ASSY COMPLETE	TATA spare parts
252550100290	RADIATOR ASSY W/O SURGE TANK	TATA spare parts
252550100291	ASSY.TIE ROD(RAD.FR.MTG.TOP ON LM)	TATA spare parts
252550100292	ASSY.CONNECTOR(RAD. TO WATER PUMP)	TATA spare parts
252550100298	REAERVE TANK ASSY	TATA spare parts
252550100299	ASSY.BRACKET-RH (RAD.FRAME)	TATA spare parts
252550100301	ASSY.BRACKET-LH(RAD.FRAME MTG.ON LM)	TATA spare parts
252550100303	ASSY.BRACKET (VENT TUBE SUPPORT FRONT)	TATA spare parts
252550100307	ASSEMBLY BRACKET(VENT TUBE SUPPORT REAR)	TATA spare parts
252550100310	ASSEMBLY BRACKET -RH (FRAME MTG.ON L.M.)	TATA spare parts
252550100311	ASSEMBLY BRACKET -LH(FRAME MTG. ON L.M.)	TATA spare parts
252550100315	ASSY RADIATOR	TATA spare parts
252550100319	ASSY. RADIATOR W/FRAME & IC BS2/3/4	TATA spare parts
252550100320	ASSY.RADIATOR WITH FRAME	TATA spare parts
252550100325	ENGINE COOLING SYSTEM 2515-EII-T.CAB	TATA spare parts
252550100326	ASSY.RADIATOR WITH FRAME	TATA spare parts
252550100327	ASSY.AUX.TANK & P.STG.TANK MTG.BRACKET	TATA spare parts
252550100328	ASSY.RADIATOR WITH FRAME & INTERCOOLER	TATA spare parts
252550100329	ASSY RADIATOR (SFC:712 BS:III)	TATA spare parts
252550100330	ASSY.BRACKET (VENT TUBE SUPPORT FRONT)	TATA spare parts
252550100331	ASSY.BRACKET (VENT TUBE SUPPORT REAR)	TATA spare parts
252550100334	FILL PIPE BRACKET	TATA spare parts
252550100335	ASSY.BRACKET COMP.(AUX.WATER TANK MTG)	TATA spare parts
252550100340	ASSY.RADIATOR WITH INTERCOOLER	TATA spare parts
252550100341	ASSY.RADIATOR	TATA spare parts
252550100345	ASSY SUPPORT ( AUX. TANK MTG)	TATA spare parts
252550100353	ASSEMBLY RADIATOR	TATA spare parts

252550100360	RADIATOR ASSY. (SE/SK 1613 BS-II)	TATA spare parts
252550100365	ASSY. CONNECTOR (RADIATOR TO WATER PUMP)	TATA spare parts
252550100371	RADIATOR ASSY WITH LEVEL SENSOR 813	TATA spare parts
252550100372	ENGINE COOLING SYSTEM	TATA spare parts
252550100377	ASSY.ENG COOLING SYSTEM	TATA spare parts
252550100378	RADIATOR AND INTER COOLER ASSY(180 COWL	TATA spare parts
252550100385	ASSY. BRACKET-RH (RAD. MTG. ON LM)	TATA spare parts
252550100386	ASSY. BRACKET-LH(RA.MTG. ON LM)	TATA spare parts
252550100391	RADIATOR ASSEMBLY	TATA spare parts
252550100392	ASSY RADIATOR & INTERCOOLER COMPLETE	TATA spare parts
252550100396	RADIATOR ASSY	TATA spare parts
252550103302	BRACKET-LH (TIE ROD MTG.ON LONGMEMBER)	TATA spare parts
252550103303	BRACKET-RH (TIE ROD MTG.ON LONGMEMBER)	TATA spare parts
252550103314	SUPPORT (FOR FILL PIPE & IC PIPE )	TATA spare parts
252550103325	SUPPORT (PIPE IC TO INTAKE ELBOW)	TATA spare parts
252550103366	SUPPORT BRACKET BS6	TATA spare parts
252550103367	SUPPORT BRACKET BS6	TATA spare parts
252550103368	SUPPORT BRACKET BS6	TATA spare parts
252550103369	SUPPORT BRACKET BS6	TATA spare parts
252550103370	SUPPORT BRACKET BS6	TATA spare parts
252550103375	SUPPORT BRACKET (VENT HOSE) BS6	TATA spare parts
252550103376	SUPPORT BRACKET (FOR VENT TUBE) BS6	TATA spare parts
252550103377	SUPPORT BRACKET (HOSE RADIATOR TO WP)BS6	TATA spare parts
252550103385	SUPPORT BRACKET BS6-PH2	TATA spare parts
252550104201	CLAMP-PIPE	TATA spare parts
252550104207	CLAMP(FOR WATER FILL PIPE)2515 TURBO.	TATA spare parts
252550105808	HOSE	TATA spare parts
252550105813	RUBBER HOSE	TATA spare parts
252550105816	RUBBER HOSE	TATA spare parts
252550105829	RUB HOSE RAD TO W/PUMP	TATA spare parts
252550105830	RUBBER HOSE	TATA spare parts
252550105833	HOSE (20 O D PIPE TO RADIATOR)	TATA spare parts
252550105834	RUBBER HOSE (L=930) LP613	TATA spare parts
252550105835	RUBBER HOSE (L=520) LP613	TATA spare parts
252550105836	Z HOSE(THERMOSTAT-RADIATOR) LP1510CMVR2	TATA spare parts
252550105837	HOSE(RADIATOR TO WATER PUMP)LP1510CMVR2	TATA spare parts
252550105840	HOSE-THERMOSTAT TO RADIATOR	TATA spare parts
252550105845	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252550105852	RUBBER HOSE(FROM RAD.TO WATER PUMPSE1	TATA spare parts
252550105855	RUBBER HOSE (VENT TUBE ON ENGINE)	TATA spare parts
252550105856	Z HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
252550105857	HOSE (RAD TO W.P.)	TATA spare parts
252550105858	HOSE (RAD. TO W.P.)	TATA spare parts
252550105859	HOSE-RADIATOR TO WATER PUMP	TATA spare parts
252550105860	HOSE-RADIATOR TO THERMOSTAT	TATA spare parts
252550105862	RUBBER HOSE VENT-100 LONG	TATA spare parts
252550105863	HOSE(THEROSTAT TO RAD.)LPT2515 697-145	TATA spare parts

252550105864	HOSE(RAD.TO WATER PUMP)LPT2515-697-145	TATA spare parts
252550105865	HOSE-WATER FILL PIPE 20 ID X 90 X 105	TATA spare parts
252550105868	HOSE	TATA spare parts
252550105869	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252550105874	HOSE DAT TO WATER FILL PIPE	TATA spare parts
252550105875	HOSE RAD TO WATER FILL PIPE	TATA spare parts
252550105876	VENT HOSE	TATA spare parts
252550105877	OVERFLOW TUBE	TATA spare parts
252550105890	HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
252550105892	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252550105893	RUBBER HOSE L=385UCWL TO RADIATOR	TATA spare parts
252550105894	HOSE-550 LONG	TATA spare parts
252550105895	REDUCER HOSE	TATA spare parts
252550105896	FILL PIPE HOSE	TATA spare parts
252550105897	HOSE-460 L-AUX W/TANK TO RAD -2ND	TATA spare parts
252550105898	HOSE-TOP	TATA spare parts
252550105899	HOSE-RAD TO WATER PUMP	TATA spare parts
252550106302	CAP AUX WATER TANK	TATA spare parts
252550106305	RECOVERY TANK	TATA spare parts
252550106306	RECOVERY COOLANT TANK	TATA spare parts
252550106307	RECOVERY COOLENT TANK	TATA spare parts
252550106901	TUBE	TATA spare parts
252550106917	PIPE (550 LONG )	TATA spare parts
252550106918	PIPE-400 MM LONG	TATA spare parts
252550106919	PIPE-20 O.D.X1.5 THK.CEW1 ANLD SS4045	TATA spare parts
252550106920	PIPE (20 O.D. X 1.5 THICK)	TATA spare parts
252550106925	VENT TUBE-COOLING LINE TO RADIATOR 697 T	TATA spare parts
252550106926	PIPE 20 OD X 1.5 THICK	TATA spare parts
252550106930	VENT TUBE	TATA spare parts
252550106934	WATER FILL PIPE	TATA spare parts
252550106935	WATER FILL PIPE	TATA spare parts
252550106938	WATER FILL PIPE-II (AUX. TANK TO RAD)	TATA spare parts
252550106942	VENT TUBE (AUX.WATER TANK TO U.C.W.LINE)	TATA spare parts
252550106947	WATER FILL PIPE(TRANS.TANK TORAD)LPT2515	TATA spare parts
252550106948	VENT TUBE(UCWL TO RAD)D	TATA spare parts
252550106953	VENT TUBE(TRANS TANK TO UCWL)SE/SK1613	TATA spare parts
252550106955	WATER FILL PIPE (AUX.WATER TANK END)	TATA spare parts
252550106956	WATER FILL PIPE (RADIATOR END)	TATA spare parts
252550106957	VENT -PIPE RADIATOR	TATA spare parts
252550106960	WATER FILL PIPE (RADIATOR END)	TATA spare parts
252550106961	VENT TUBE (U.C.W.LINE TO AUX.WATER TANK)	TATA spare parts
252550106962	VENT TUBE (RADIATOR TO AUX.WATER TANK)	TATA spare parts
252550106963	FILL PIPE-TOP	TATA spare parts
252550106964	WATER FILL PIPE-BOTTOM	TATA spare parts
252550106965	WATER FILL PIPE(20 O.D.X1.5THK)AUX.END	TATA spare parts
252550106966	WATER FILL PIPE(28.6 OD X 1.5THK)RAD.END	TATA spare parts
252550106967	FILL PIPE-BOTM 28.6X1.22ERW1 ANLD IS3074	TATA spare parts



252550106968	VENT TUBE (AUX.WATER TANK TO U.C.W.LINE)	TATA spare parts
252550106969	VENT TUBE (RADIATOR)	TATA spare parts
252550106970	WATER FILL PIPE(AUX.WATER TANK END)	TATA spare parts
252550106972	PIPE FOR RAD. HOSE	TATA spare parts
252550106978	WATER FILL PIPE	TATA spare parts
252550106979	WATER FILL PIPE (AUX. WATER TANK)	TATA spare parts
252550106980	WATER FILL PIPE (AUX WATER TANK TO RAD.)	TATA spare parts
252550106981	WATER FILL PIPE (RADIATOR END)	TATA spare parts
252550106984	VENT PIPE (RADIATOR TO AUX.TANK)	TATA spare parts
252550106989	WATER FILL PIPE (AUX WATER TANK END)	TATA spare parts
252550106992	PIPE CONNECTOR FOR RAD HOSE	TATA spare parts
252550106998	PIPE CONNECTOR (BETWEEN RADIATOR TO THER)	TATA spare parts
252550106999	VENT PIPE FOR RADIATOR	TATA spare parts
252550108223	SUPPORT BRACKET BS6-PH2	TATA spare parts
252550108299	BRACKET (RADIATOR MTG.BOTTOM)	TATA spare parts
252550109903	RESERVE TANK	TATA spare parts
252550110112	ASSY CLAMP(FOR WATER FILL PIPE)	TATA spare parts
252550110113	ASSY BRACKET (WATER FILL PIPE & IC PIPE)	TATA spare parts
252550110114	ASSY. BRACKET AUXILARY TANK MTG	TATA spare parts
252550110119	ASSY. CONNECTOR RAD TO WATER PUMP (HEATE	TATA spare parts
252550110123	ASSEMBLY TIE ROD (RAD FRAME MTG ON LONG	TATA spare parts
252550110125	ASSY RADIATOR FOR LPT1613 CAB	TATA spare parts
252550110126	ASSY RADIATOR FOR LPT1613 COWL	TATA spare parts
252550110129	ENGINE COOLING SYSTEM 1613 BSIII	TATA spare parts
252550110130	RADIATOR ASSY	TATA spare parts
252550110132	RADIATOR ASSY - LPT 1613 697 BS3 COWL	TATA spare parts
252550110133	RADIATOR ASSY	TATA spare parts
252550110138	ASSY BKT TIE ROD MTG ON LM RH	TATA spare parts
252550110139	ASSY TIE ROD RH WITH RUBBER BUSH & TUBE	TATA spare parts
252550110141	ASSY. FILLER PIPE (RAD. TO WATER PUMP)	TATA spare parts
252550110142	ASSY BKT TIE ROD MTG ON LM LH	TATA spare parts
252550110143	ASSY TIE ROD LH WITH RUBBER BUSH & TUBE	TATA spare parts
252550110145	FILL PIPE ( AUX. TANK ON FIRE WALL)	TATA spare parts
252550110155	ASSY RADIATOR WITH INTERCOOLER AND FAN S	TATA spare parts
252550110156	RADIATOR ASSY- LPT 1613 697 BS4 TILT CAB	TATA spare parts
252550110165	ASSY BRACKET RH MOUNTING OF RADIATOR ON	TATA spare parts
252550110171	ASSY BKT LH MOUNTING OF RADIATOR ON LONG	TATA spare parts
252550110188	ASSY.RADIATOR WITH AUX. TANK	TATA spare parts
252550110194	ASSEMBLY BRACKET (VENT TUBES SUPPORT)	TATA spare parts
252550110196	RESERVE TANK ASSY 6L	TATA spare parts
252550110202	ASSY SUPPORT BRACKET	TATA spare parts
252550110203	ASSY SUPPORT BRACKET	TATA spare parts
252550110205	ASSY.BRACKET (VENT TUBE SUPPORT FRONT)	TATA spare parts
252550110213	ASSY. RADIATOR WITH AUX. TANK & FAN SHRO	TATA spare parts
252550110215	RADIATOR ASSY	TATA spare parts
252550110216	ASSY. FILL PIPE	TATA spare parts
252550110219	ASSY. PLASTIC AUX. WATER TANK	TATA spare parts

252550110221	ASSY. BRACKET (RAD. MTG. - LHS)	TATA spare parts
252550110222	ASSY. BRACKET (RAD. MTG. - RHS)	TATA spare parts
252550110226	ASSEMBLY BRACKET (IC PIPES SUPPORT)	TATA spare parts
252550110236	ASSEMBLY BRACKET (AC PIPE SUPPORT)	TATA spare parts
252550110258	ASSEMBLY BRACKET (IC PIPES SUPPORT)	TATA spare parts
252550110260	ASSY RAD WITH INTERCOOLER & FAN SHROUD	TATA spare parts
252550110271	ASSY AUX TANK	TATA spare parts
252550110286	ASSEMBLY BRACKET (VENT LINES SUPPORT)	TATA spare parts
252550110287	ASSEMBLY BRACKET (VENT LINES SUPPORT)	TATA spare parts
252550110296	ASSY RADIATOR (M/S TATA TOYO)	TATA spare parts
252550110321	SET-COOLING SYSTEM	TATA spare parts
252550110324	RADIATOR ASSY	TATA spare parts
252550110336	ASSY. RAD WITH AUX.TANK & FAN SHROUD	TATA spare parts
252550110350	BRACKET TIE ROD MTG ON LM LH	TATA spare parts
252550110351	BRACKET TIE ROD MTG ON LM RH	TATA spare parts
252550110355	TIE ROD ASSY WITH BUSH	TATA spare parts
252550110359	ENGINE COOLING SYSTEM	TATA spare parts
252550110362	SET-COOLING PACKAGE	TATA spare parts
252550110365	RADIATOR ASSY	TATA spare parts
252550110366	WATER FILLER PIPE ASSY WITH CLAMP	TATA spare parts
252550110397	FILLER PIPE	TATA spare parts
252550115802	HOSE (RADIATOR TO PIPE)	TATA spare parts
252550115804	RUBBER HOSE (THERMOSTAT TO RADIATOR TOP)	TATA spare parts
252550115805	HOSE(RAD TO W.P.)	TATA spare parts
252550115810	HOSE (PIPE TO WATER PUMP)	TATA spare parts
252550115811	HOSE (RADIATOR TO WP)	TATA spare parts
252550115815	HOSE (WATER FILL PIPE TO RAD)	TATA spare parts
252550115822	HOSE VENT (AUX. TANK TO RADIATOR)	TATA spare parts
252550115824	HOSE (THERMOSTAT TO RADIATOR) - 697 CNG	TATA spare parts
252550115829	VENT HOSE AUX WATER TANK TO THERMOSTAT	TATA spare parts
252550115832	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252550115845	HOSE (THERMOSTAT TO PIPE CONNECTOR)	TATA spare parts
252550115848	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252550115849	HOSE (PIPE CONNECTOR TO RADIATOR)	TATA spare parts
252550115853	HOSE (TS TO AUX TANK)	TATA spare parts
252550115854	HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
252550115857	RUBBER HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
252550115858	VENT HOSE (RADIATOR TO THERMOSTAT)	TATA spare parts
252550115859	HOSE (THERMOSTAT TO RAD)	TATA spare parts
252550115860	HOSE (RAD TO WP)	TATA spare parts
252550115882	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252550115883	HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
252550115884	VENT HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
252550115885	HOSE RADIATOR TO WATER PUMP	TATA spare parts
252550115886	HOSE (THERMOSTAT TO PIPE CONNECTOR)	TATA spare parts
252550115887	HOSE PIPE CONNECTOR TO RADIATOR	TATA spare parts
252550115889	HOSE-PIPE CONNECTOR TO RADIATOR BS6	TATA spare parts

252550116949	VENT TUBE (UCWL TO AUX TANK)	TATA spare parts
252550116950	WATER FILL PIPE(20 OD)AUX.END	TATA spare parts
252550116951	WATER FILL PIPE(28.6 OD)RAD. END	TATA spare parts
252550116952	VENT TUBE (RADIATOR TO AUX TANK)	TATA spare parts
252550116967	VENT LINE FOR RADIATOR (LP913 AC)	TATA spare parts
252550116976	PIPE CONNECTOR ASSY BS6	TATA spare parts
252550116978	PIPE CONNECTOR ASSY	TATA spare parts
252550116979	VENT PIPE RADIATOR	TATA spare parts
252550116982	VENT TUBE (UCWL TO AUX TANK)	TATA spare parts
252550116983	VENT TUBE (THERMOSTAT TO AUX TANK)	TATA spare parts
252550116988	WATER FILL PIPE-LP613 BS1 LHD MARCOPOLO	TATA spare parts
252550118202	BRACKET (FOR FILL PIPE)	TATA spare parts
252550118204	SUPPORT BRACKET WATER FILL PIPE BOTTOM	TATA spare parts
252550118214	BRACKET FILLER PIPE MTG	TATA spare parts
252550118215	SUPPORT BRACKET IC TO ENG PIPE MTG	TATA spare parts
252550118216	SUPPORT BRACKET TC TO INTERCOOLER PIPE	TATA spare parts
252550118217	SUPPORT BRACKET IC TO ENG PIPE MTG	TATA spare parts
252550120105	PIPE ASSY RADIATOR TO OIL COOLER BS6	TATA spare parts
252550120106	PIPE ASSY THERMOSTAT TO RADIATOR BS6	TATA spare parts
252550120107	RADIATOR CORE ASSY BS6	TATA spare parts
252550120108	AUX TANK ASSY WITH HOSES BS6	TATA spare parts
252550120109	FILLER PIPE ASSY BS6	TATA spare parts
252550120110	RADIATOR & FAN SHROUD ASSY BS6	TATA spare parts
252550120111	FILLER PIPE ASSY BS6	TATA spare parts
252550120112	RADIATOR & FAN SHROUD ASSY BS6	TATA spare parts
252550120114	AUX TANK ASSY BS6	TATA spare parts
252550120115	BRACKET BS6	TATA spare parts
252550120117	ENGINE COOLING SYSTEM	TATA spare parts
252550120118	BRACKET ASSY RADIATOR MTG LM	TATA spare parts
252550120119	RADIATOR ASSY	TATA spare parts
252550120120	INTERCOOLER ASSY	TATA spare parts
252550120121	RADIATOR ASSY WITH SHROUD BS6	TATA spare parts
252550120122	RADIATOR CORE ASSY BS6	TATA spare parts
252550120124	COOLANT FILLER PIPE ASSY BS6	TATA spare parts
252550120125	FAN BS6	TATA spare parts
252550120126	RUBBER CLAMP ASSY BS6	TATA spare parts
252550120139	COOLANT FILLER PIPE ASSY BS6-PH2	TATA spare parts
252550125810	HOSE RADIATOR TO WATER PUMP	TATA spare parts
252550125811	HOSE THERMOSTAT TO RADIATOR	TATA spare parts
252550125813	VENT HOSE THERMOSTAT TO RADIATOR	TATA spare parts
252550125815	HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
252550125819	HOSE THERMOSTAT TO RADIATOR	TATA spare parts
252550125820	VENT HOSE THERMOSTAT TO RADIATOR	TATA spare parts
252550125827	HOSE PIPE TO WATER PUMP BS6	TATA spare parts
252550125829	HOSE OIL COOLER OUTLET BS6	TATA spare parts
252550125830	HOSE (INTERCOOLER INTAKE)	TATA spare parts
252550125837	VENT HOSE BS6	TATA spare parts

252550125838	VENT HOSE BS6	TATA spare parts
252550125839	TUBE OVER FLOW BS6	TATA spare parts
252550125840	HOSE THERMOSTAT TO RADIATOR	TATA spare parts
252550125842	HOSE AUX WATER TANK TO FILLER PIPE	TATA spare parts
252550125843	HOSE FILLER PIPE TO RADIATOR	TATA spare parts
252550125844	VENT HOSE AUX WATER TANK TO RADIATOR	TATA spare parts
252550125846	HOSE T-CONNECTOR TO WATER PUMP	TATA spare parts
252550125847	HOSE T-CONNECTOR TO WATER PUMP	TATA spare parts
252550125848	HOSE RADIATOR TO T-CONNECTOR	TATA spare parts
252550125849	REDUCER HOSE AUX WATER TANK (DIA. 9 TO 6	TATA spare parts
252550125850	HOSE-RADIATOR TO WATER PUMP BS6	TATA spare parts
252550125851	HOSE VENT-RADIATOR TO AUX TANK BS6	TATA spare parts
252550125864	HOSE RADIATOR BOTTOM TANK TO FILLER PIPE	TATA spare parts
252550125865	HOSE AUX WATER TANK TO FILLER PIPE BS6-P	TATA spare parts
252550125867	HOSE BS6-PH2	TATA spare parts
252550125868	HOSE BS6-PH2	TATA spare parts
252550125869	VENT HOSE AUX WATER TANK TO RADIATOR BS6	TATA spare parts
252550125870	HOSE BS6-PH2	TATA spare parts
252550126909	PIPE AUX WATER TANK TO PIPE ASSY BS6	TATA spare parts
252550126910	VENT TUBE RADIATOR TO AUX WATER TANK BS6	TATA spare parts
252550126911	PIPE OIL COOLER TO ENGINE WATER PUMP BS6	TATA spare parts
252550126912	VENT TUBE UCWL TO AUX WATER TANK BS6	TATA spare parts
252550126913	FILLER PIPE AUX WATER TANK TO RADIATOR	TATA spare parts
252550126914	VENT TUBE UCWL TO AUX WATER TANK BS6	TATA spare parts
252550126918	VENT TUBE UCWL TO AUX WATER TANK BS6-PH2	TATA spare parts
252550126919	PIPE RADIATOR TO WATER PUMP BS6-PH2	TATA spare parts
252550500103	FAN SHROUD 613	TATA spare parts
252550500105	FAN SHROUD	TATA spare parts
252550500106	ASSY FAN SHROUD	TATA spare parts
252550500107	ASSY FAN SHROUD	TATA spare parts
252550500108	ASSY FAN SHROUD	TATA spare parts
252550500150	FAN SHROUD	TATA spare parts
252550504201	HOSE CLAMP-595	TATA spare parts
252550506312	ASSY FAN SHROUD LPT1613 TURBO	TATA spare parts
252550506315	FAN SHROUD CNG BUS	TATA spare parts
252550506317	FAN SHROUD LPT 1613 TURBO	TATA spare parts
252550506318	FAN SHROUD SE1613	TATA spare parts
252550506320	FAN SHROUD LP1510 697 E-II VISCOUS FAN	TATA spare parts
252550506321	FAN SHROUD SE1613	TATA spare parts
252550506323	FAN SHROUD	TATA spare parts
252550506324	FAN SHROUD 2515WITH697TSIC-145	TATA spare parts
252550506327	FAN SHROUD	TATA spare parts
252550506328	FAN SHROUD	TATA spare parts
252550506330	FAN SHROUD	TATA spare parts
252550506333	FAN SHROUD - LPS 4018 697 BS-II	TATA spare parts
252550506334	FAN SHROUD (WITH ONE CLIP)	TATA spare parts
252550506335	FAN SHROUD (WITH ONE CLIP)	TATA spare parts

252550506337	FAN SHROUD	TATA spare parts
252550506338	FAN SHROUD	TATA spare parts
252550506339	FAN SHROUD	TATA spare parts
252550506341	FAN SHROUD	TATA spare parts
252550506344	FAN SHROUD (22INCH JETTRING FAN) TATA T	TATA spare parts
252550506345	FAN SHROUD - 697 CNG BSIV	TATA spare parts
252550506348	FAN SHROUD (22 JETRING FAN)	TATA spare parts
252550506350	FAN SHROUD FOR DIA. 500 FAN	TATA spare parts
252550506355	FAN SHROUD (TATA TOYO)	TATA spare parts
252550506361	FAN SHROUD (22INCH JETTRING FAN)	TATA spare parts
252550506365	FAN SHROUD (22INCH JETTRING FAN)	TATA spare parts
252550506370	FAN SHROUD BS6	TATA spare parts
252550506376	FAN SHROUD	TATA spare parts
252550506381	FAN SHROUD	TATA spare parts
252550506383	FAN SHROUD BS6	TATA spare parts
252550507703	RUBBER RING FAN RING TO SHROUD	TATA spare parts
252550507708	RUBBER SHIELD FOR RADIATOR	TATA spare parts
252550508201	FAN SHROUD 1516	TATA spare parts
252554209903	RPM CUM HOUR METER	TATA spare parts
252599000101	KIT ENG OVERHAUL GASKETS	TATA spare parts
252599000102	KIT DECARBONISING GASKETS	TATA spare parts
252599000103	KIT ENG OVERHAUL GASKETS	TATA spare parts
252599000104	KIT DECARBONISING GASKETS	TATA spare parts
2525N3120102	SET MAIN BRG STD1 W/O COL	TATA spare parts
2525N3120103	M B SET RS I W/O COL BRG	TATA spare parts
2525N3120106	M B SET RS 4 W/O COL BRG	TATA spare parts
252603120106	M BEARING SET COLLAR TYPE R/S-IV	TATA spare parts
252658900701	EXTRA DEEP SOCKET	TATA spare parts
252700210115	ECU WITH CLBRN LP407 WT RSL-3.8SGI BSIV	TATA spare parts
252700210116	ECU WITH CLBRN LP407 WT RSL-3.8SGI BSIV	TATA spare parts
252700210127	ECU WT CLBRN LP9.6T W/O RSL -3.8SGI BSIV	TATA spare parts
252700210128	ECU WT CLBRN LP9.6T WT RSL-3.8SGI BSIV	TATA spare parts
252700990101	ASSY LONG BLOCK TATA 3.8 SGI BSIV NA EN	TATA spare parts
252700990102	ASSY HALF BLOCK (TATA 3.8 SGI BSIV NA EN	TATA spare parts
252700990104	DECARBONISING GASKET KIT (TATA 3.8 SGI B	TATA spare parts
252700990105	ENGINE OVERHAUL GASKET KIT ( TATA 3.8 S	TATA spare parts
252700990106	DECARBONISING GASKET KIT ( TATA 3.8 SGI	TATA spare parts
252700990108	ASSY HALF BLOCK - TATA 3.8 SGI BSIV NA E	TATA spare parts
252700990109	ASSY LONG BLOCK TATA 3.8 SGI BSIV NA EN	TATA spare parts
252700990110	ASSY HALF BLOCK TATA 3.8 SGI BSIV NA EN	TATA spare parts
252700990111	ENGINE OVERHAUL GASKET KIT	TATA spare parts
252700990112	DECARBONISING GASKET KIT (TATA 3.8 SGI B	TATA spare parts
252700990114	LONG BLOCK 497 BS-IV	TATA spare parts
252700990115	LONG BLOCK 497CR BS-IV	TATA spare parts
252700990116	HALF BLOCK 497 BS-IV ENGINE	TATA spare parts
252700990118	LONG BLOCK 497Y1 BS-III (LPO BUS)	TATA spare parts
252700990119	HALF BLOCK 497Y1 BS-III (LPO BUS)	TATA spare parts

252700990120	LONG BLOCK 497 Y1 BS-III (LPT TRUCK)	TATA spare parts
252700990121	HALF BLOCK 497 Y1 BS-III (LPT TRUCK)	TATA spare parts
252700990122	ENGINE OVERHAUL GASKET KIT(497 Y1 TRUCK	TATA spare parts
252700990123	DECARBURISING KIT 497 Y1 LPT/LPO	TATA spare parts
252700990124	ASSY. HALF BLOCK - TATA 3.8 SGI BSIV NA	TATA spare parts
252700990125	ASSY LONG BLOCK - TATA 3.8 SGI BSIV NA	TATA spare parts
252700990126	ASSY LONG BLOCK - TATA 3.8 SGI BSIV NA	TATA spare parts
252700990127	ASSY. HALF BLOCK - TATA 3.8 SGI BSIV NA	TATA spare parts
252700990129	ASSY. HALF BLOCK - TATA 3.8 SGI BSIV NA	TATA spare parts
252700990132	LONG BLOCK 497 Y1 BS-III LPO AC BUS	TATA spare parts
252700990133	HALF BLOCK 497Y1 LPO AC BUS	TATA spare parts
252700990134	ENGINE OVERHAUL GASKET KIT ( TATA 3.8 SG	TATA spare parts
252700990135	DECARBONISING GASKET KIT ( TATA 3.8 SGI	TATA spare parts
252700990136	ASSY. HALF BLOCK - TATA 3.8 SGI BSIV TC	TATA spare parts
252700990137	ASSY. LONG BLOCK - TATA 3.8 SGI BSIV TC	TATA spare parts
252700990139	ASSY. LONG BLOCK - TATA 3.8 SGI BSIV NA	TATA spare parts
252700990142	DECARBURIZING GASKET KIT	TATA spare parts
252700990145	ASSY.LONG BLOCK - LP909TMML ECU580	TATA spare parts
252700990146	ASSY. HALF BLOCK - TATA 3.8 SGI BS4	TATA spare parts
252700990147	ASSY. HALF BLOCK - TATA 3.8 SGI BS4	TATA spare parts
252700990148	ASSY. LONG BLOCK TATA 3.8 SGI LP407 TMML	TATA spare parts
252700990150	ASSY. LONG BLOCK - IOBDII SFC407 ECU 580	TATA spare parts
252700990151	ASSY HALF BLOCK - SFC407	TATA spare parts
252700990154	KIT-LONG BLOCK BS6	TATA spare parts
252700990155	KIT-HALF BLOCK BS6	TATA spare parts
252700990156	ASSY. LONG BLOCK - 3.8 SGI BSVI TC ENG B	TATA spare parts
252700990157	ASSY. HALF BLOCK -3.8 SGI BSVI TC ENG. B	TATA spare parts
252700990158	KITLONGBLOCK BS6	TATA spare parts
252700990159	KIT HALF BLOCK BS6	TATA spare parts
252700990163	ASSY HALF BLOCK BS6	TATA spare parts
252700990164	ASSY LONG BLOCK BS6	TATA spare parts
252700990165	ASSY LONG BLOCK BS6	TATA spare parts
252700990166	ASSY HALF BLOCK BS6	TATA spare parts
252701000009	ENGINE ASSY 497D	TATA spare parts
252701000014	ENGINE ASSY 497D	TATA spare parts
252701000117	ENGINE ASSY 497D W/CL	TATA spare parts
252701000122	ASSY.ENG.COMP.WITH CL.& P.STRG.	TATA spare parts
252701000127	ENGINE 497 GODREJ	TATA spare parts
252701000128	ENGINE 497 VOLTAS	TATA spare parts
252701000131	ENG 497D LPT RHD MECH	TATA spare parts
252701000133	HALF ENG LP/LPT	TATA spare parts
252701000134	HALF ENG SFC	TATA spare parts
252701000137	ENGINE 497X128 GEN SET	TATA spare parts
252701000138	ENGINE 497 FIRE	TATA spare parts
252701000142	HALF ENG 497D LP/LPT	TATA spare parts
252701000156	497NA BSII FIP675 20deg FW	TATA spare parts
252701000167	ENGINE ASSY 497D TRUCK	TATA spare parts

252701000168	ENGINE 497/S CAM/SFC709	TATA spare parts
252701000169	ENGINE ASSY 497D BUS	TATA spare parts
252701000206	ENGINE SFC 709 CMVR2000 497TC	TATA spare parts
252701000207	ENGINE ASSY LPT709 CMVR2000 12V35A	TATA spare parts
252701000208	ASSY ENG COMP W CLUTCH 12V 65A:LP709 RHD	TATA spare parts
252701000209	ASSY.ENG.COMP.WITH CLUTCH (W/O HD)-RHD	TATA spare parts
252701000213	ASSY ENGINE LPT509 LHD PSTG NON SCAM	TATA spare parts
252701000214	ENGINE GENSET 30KVA	TATA spare parts
252701000227	ASSY ENG COMP W/CL P STRG 65A S'CAM:RHD	TATA spare parts
252701000233	ASSY. ENG LPT1109 WITH 310CL	TATA spare parts
252701000236	ASSY ENGINE LPT709-EUROII	TATA spare parts
252701000238	ENGINE GENSET 50KVA	TATA spare parts
252701000246	ENGINE GENSET 35KVA	TATA spare parts
252701000248	ENGINE 497 TC (S- CAM) EUROII	TATA spare parts
252701000249	ASSY ENGINE SFC 709-EUROII	TATA spare parts
252701000252	ASSY ENGINE LP1109	TATA spare parts
252701000254	ENGINE GENSET 40KVA	TATA spare parts
252701000262	ENGINE GENSET 62.5KVA	TATA spare parts
252701000263	ASSY ENG. 709LHD P/STRG SCAM W/O CAB HTG	TATA spare parts
252701000264	ENG. LP509 CMVR P/S 65A VADC W/O SCAM H	TATA spare parts
252701000270	ASSY.ENG.COMP.WITH CL PST 65A HD-LP-LHD	TATA spare parts
252701000277	ASSY ENG LPT1109 W/310CL G40 RE AUX	TATA spare parts
252701000278	ASSY ENG COMP W/310 CL G40 RE TANK	TATA spare parts
252701000279	ASSY ENG COMP LP1109 W/310CL ME STRG	TATA spare parts
252701000288	ASSY ENGINE LPT709 TC/IC HIGH TORQUE	TATA spare parts
252701000296	ASSY ENG COMP SFC709EX HIGH TORQUE	TATA spare parts
252701000297	ASSY ENG LP712 TC-EURO III	TATA spare parts
252701000298	ASSY.ENGINE COMPLETE (30KVA-CPCB)	TATA spare parts
252701000299	ASSY.ENGINE COMPLETE (35KVA-CPCB)	TATA spare parts
252701000301	ASSY.ENGINE COMPLETE (40KVA-CPCB)	TATA spare parts
252701000303	ASSY.ENGINE COMPLETE (50KVA-CPCB)	TATA spare parts
252701000304	ASSY.ENGINE COMPLETE (62.5KVA-CPCB)	TATA spare parts
252701000308	ASSY ENGINE LPT709 EURO I HD P/S	TATA spare parts
252701000312	ASSY.ENG.COMP.MECH.ENG.STOP-HT-LPT909	TATA spare parts
252701000313	ASSY.ENG.MECH.ENG.STOP-HT-LP709 TCIC	TATA spare parts
252701000315	ASSY ENGINE COMP W'310 DIA CLUTCH:LPT113	TATA spare parts
252701000316	ASSY ENG LPT712/912 TC-EURO III	TATA spare parts
252701000324	ASSY ENG LPT709/909 TC-EURO II EX	TATA spare parts
252701000325	ASSY ENG COMP W CLUTCH TCIC LPT1109:BSII	TATA spare parts
252701000327	ASSY ENG SFC709 TC-EURO II EX	TATA spare parts
252701000329	ENG ASSY LP 1512/52 BS III WITH 497 TCIC	TATA spare parts
252701000330	ASSY ENGINE COMP W'310 DIA CLUTCH:LP1112	TATA spare parts
252701000331	ASSY ENG COMP W CLUTCH SFC:712 BS:III	TATA spare parts
252701000332	ASSY.ENG.COMP.(JD315-WITH_AIR_COMP)	TATA spare parts
252701000337	ASSY ENGINE LP709 E II EX NO LOSS TANK	TATA spare parts
252701000343	ASSY ENGINE LPT709/909 EII EX NO LOSS TA	TATA spare parts
252701000344	ASSY ENG COMP W'CLUTCH TCIC LP:BSIII NLT	TATA spare parts

252701000345	ASSY ENG COMP W'CLU TCIC LPT712:BS3 NLT	TATA spare parts
252701000347	ASSY ENG COMP W'CLU TCIC LPT:BS2EX NLT	TATA spare parts
252701000348	ASSY ENG LPT 709 EII EX:EMOS PS HD	TATA spare parts
252701000349	ASSY ENGINE COMPLETE BS III	TATA spare parts
252701000350	ASSY ENGINE COMPLETE BS III	TATA spare parts
252701000351	ENGINE LPT1109 BS:II EX W. PS NLT W/O CB	TATA spare parts
252701000352	ASSY ENG COMP W'CLUTCH LPT1112:BSIII	TATA spare parts
252701000353	ASSY ENGINE COMP WCLUTCH	TATA spare parts
252701000354	ASSY. ENGINE COMP. W/CLUTCH TCIC BS2/3	TATA spare parts
252701000355	ASSY ENG COMP W'CL LPT712 BS3 PSTG NLT	TATA spare parts
252701000358	ASSY ENG COMP WITH CL TCIC BS IIEX SFC70	TATA spare parts
252701000362	ASSY ENG 497TCIC 1512 BSIII W. M F PUMP	TATA spare parts
252701000363	ASSY ENGINE WITH CLUTCH 497 TCIC BS II 3	TATA spare parts
252701000366	ASSY ENG COMP:497TC-ICBS-IIEX:NLT:LP909	TATA spare parts
252701000368	ASSY. ENGINE COMP. 497TCIC PSTG NLT BS3	TATA spare parts
252701000369	ENGINE 497TCIC BS-III	TATA spare parts
252701000377	ASSY. ENGINE COMPLETE 497 CNG BS-III	TATA spare parts
252701000380	ENGINE 497 NA 5 TONNER BACKHOE LOADER	TATA spare parts
252701000385	ASSY.ENGINE COMPLETE BS-IV	TATA spare parts
252701000387	ASSY.ENG.COMP.497TCIC BS-III Y1	TATA spare parts
252701000395	ASSY ENGINE COMP.TATA 3.8 SGI BSIV TCIC	TATA spare parts
252701010101	SET NOISE DAMPER PADS 497 TCIC	TATA spare parts
252701010104	ASSY ENGINE COMP.LPO BUS	TATA spare parts
252701010105	ASSY ENGINE LPT1109 BS:II EX W. PS 65 A	TATA spare parts
252701010107	ENGINE 497TC99BSIII 76PS@2200	TATA spare parts
252701010109	ASSY. ENGINE COMPLETE W 310 DIA CLU L	TATA spare parts
252701010110	ASSY ENG COMP 497 BS-IV FOR LPT 410 PSTG	TATA spare parts
252701010111	ASSY.ENGINE COMPLETE TATA 3.8 SGI BSIV N	TATA spare parts
252701010118	ASSY. ENGINE COMPLETE 497 CNG BSIV	TATA spare parts
252701010121	ASSY ENG.COM.497DI38 BSIII49.5PS@2000BHL	TATA spare parts
252701010126	ASSY ENG.COM.497TC48 BSIII CLASS(76PS@22	TATA spare parts
252701010129	ASSY.ENGINE COMPLETE:TATA 3.8 SGI BS-IV	TATA spare parts
252701010135	ASSY ENG COMPLETE 497 CRDI BS-III	TATA spare parts
252701010138	ASSY ENG COMP 497 BS-IV LP 712	TATA spare parts
252701010140	ASSY ENG COMP 497 CR BS-III	TATA spare parts
252701010142	ASSY ENG COM 497TC47 GENSET 65HP (60HZ)	TATA spare parts
252701010143	ASSY ENG COM 497TC46 GENSET 80HP (60HZ)N	TATA spare parts
252701010144	ASSY ENG COM 497TC45 GENSET 96HP (60HZ)	TATA spare parts
252701010149	ENGINE ASSY LPT1412 SLEEPER CAB	TATA spare parts
252701010150	ASSY ENG COM CPCB EOU GSET 40KVA (50HZ)	TATA spare parts
252701010151	ASSY ENG COM CPCB EOU GSET 50KVA (50HZ)	TATA spare parts
252701010152	ASSY ENG COM CPCB EOU GSET 62.5KVA (50HZ)	TATA spare parts
252701010154	ASSY ENG COM.497TC99 CEV BSIII (76PS@220	TATA spare parts
252701010158	ASSY.ENGINE COMPLETE TATA 3.8 SGI BS-IV	TATA spare parts
252701010159	ASSY.ENGINE COMPLETE:TATA 3.8 SGI BS-IV	TATA spare parts
252701010161	ENGINE COMPLETE Y1 LPO BUS (497TC73)	TATA spare parts
252701010165	TATA MOBILE 207/31	TATA spare parts



252701010173	ENGINE LPO 9.6T 52WB 497VP37 BS3 125HP 1	TATA spare parts
252701010176	ENGINE COMP 497TC76 47KW @ 1500 CPCB2	TATA spare parts
252701010179	ENGINE COMP LP1512 BSIV (OBD)	TATA spare parts
252701010191	ASSY.ENG.COM.497TC99BSIII 76PS(PTFE)	TATA spare parts
252701010195	ASSY.ENG.COMP EX-70NA TELCON (PTFE REAR	TATA spare parts
252701010197	ASSY ENG497 BS-IV	TATA spare parts
252701010198	ASSY ENG497 BS-IV LP712 MARCOPOLO(OBD)	TATA spare parts
252701010206	ENGINE COMP 497TC74 67KW @1500 CPCB2 B	TATA spare parts
252701010208	ASSY.ENG.COM.497TC40 BSIII 86PS@2200,W.L	TATA spare parts
252701010210	ASSY ENGINE 497 BS-IV	TATA spare parts
252701010211	LP 909/49WB CNG BS-IV OBD	TATA spare parts
252701010212	ENGINE LP 407 CNG/34WB BS-IV	TATA spare parts
252701010213	ASSY.ENG COMP TATA 3.8 SGI BSIV NA IOBD	TATA spare parts
252701010214	ASSY.ENG COMP IOBD II SFC407	TATA spare parts
252701010215	ASSY. ENGINE COMPLETE TATA 3.8 SGI BSIV	TATA spare parts
252701010216	ASSY.ENGINE COMPLETE TATA 3.8 SGI BS-IV	TATA spare parts
252701010217	ENGINE COMPL.(MULTIPLEXING)(497TC92)	TATA spare parts
252701010219	ENGINE.COMP 3.8 SGI IOBD II LPT909	TATA spare parts
252701010220	ENGINE 62.5 KVA - CPCB II	TATA spare parts
252701010223	ENGINE ASSY COMPL ULTRA BUS 497TC41	TATA spare parts
252701010224	ENGINE ASSY COMPL 497 BS-III CR LPK1109	TATA spare parts
252701010232	ENGINE ASSY Y1 LPO W MULTIPLEXING	TATA spare parts
252701010236	ENG ASSY COMPL ULTRA BUS 497TC41 NON AC	TATA spare parts
252701010237	ENGINE ASSY 497TC47 GEN 65HP(60HZ)	TATA spare parts
252701010238	ASSY ENG COM GENSET 80HP(60HZ)PTFE	TATA spare parts
252701010239	ASSY ENG COM GENSET 96HP (60HZ)NON EMISS	TATA spare parts
252701010240	ASSY ENG COM CPCB EOU 40KVA(50HZ) PTFE	TATA spare parts
252701010241	ENGINE ASSY CPCB EOU GSET 50KVA (50HZ)	TATA spare parts
252701010242	ASSY ENG COM CPCB EOU GSET 62.5KVA(50HZ)	TATA spare parts
252701010243	ENGINE COMPLETE (ENGINE TYPE-497TC70)	TATA spare parts
252701010251	ENGINE ASSY	TATA spare parts
252701010252	ENGINE ASSY COMPLETE (40KVA-CPCB) PTFE	TATA spare parts
252701010253	ENGINE ASSY COMPLETE (50KVA-CPCB) PTFE	TATA spare parts
252701010254	ENGINE ASSY COMPLETE (62.5KVA-CPCB) PTFE	TATA spare parts
252701010259	497TC75 GENSET 50 KVA CPCB II	TATA spare parts
252701010260	497TC76 GENSET 40 KVA CPCB II	TATA spare parts
252701010262	497TC74 62.5KVA CPCBII GOEM	TATA spare parts
252701010265	497TC77 35 KVA CPCB-II GOEM	TATA spare parts
252701010270	ENGINE ASSY 3.8SGI BS4 IOBD II - LP 909	TATA spare parts
252701010275	ENGINE ASSY	TATA spare parts
252701010276	ENGINE ASSY	TATA spare parts
252701010277	ENGINE ASSY LPT407 CNG BS-IV	TATA spare parts
252701010280	ENGINE ASSY LPT909 CNG BS-IV	TATA spare parts
252701010282	ENGINE ASSY 497NA EX70 24V PTFE	TATA spare parts
252701010284	LPT 1212/42 MX BS-III	TATA spare parts
252701010293	ENGINE 497TCIC CEV BSIII 76PS ACE WITH G	TATA spare parts
252701010296	ENGINE COMPLETE (ENG TYPE-497TC42)	TATA spare parts

252701010306	ENGINE WITH EGR	TATA spare parts
252701010307	FES 712/912 BS IV BSIV TMML BUS ABS	TATA spare parts
252701010308	ENGINE ASSY	TATA spare parts
252701010309	ENGINE ASSY WITH EGR	TATA spare parts
252701010313	ENGINE ASSY WITH EGR	TATA spare parts
252701010315	ENGINE ASSY	TATA spare parts
252701010316	ENGINE ASSY	TATA spare parts
252701010317	ENGINE COMPLETE LPT 1109 (94 DIA. COMP)	TATA spare parts
252701010318	ASSY ENG.COM.497NA 497DI57 EX70 24V PTFE	TATA spare parts
252701010321	ENGINE ASSY	TATA spare parts
252701010326	ENGINE ASSY	TATA spare parts
252701010327	ENGINE ASSY	TATA spare parts
252701010328	ENGINE ASSY	TATA spare parts
252701010330	ENGINE ASSY	TATA spare parts
252701010335	ENGINE 497TCIC 101PS ESCORTS & VOLTAS	TATA spare parts
252701010337	ENGINE ASSY	TATA spare parts
252701010358	ENGINE ASSY	TATA spare parts
252701010359	ENGINE ASSY	TATA spare parts
252701010362	ENGINE ASSY	TATA spare parts
252701010363	ENGINE ASSY	TATA spare parts
252701010364	ENGINE ASSY	TATA spare parts
252701010367	ENGINE ASSY	TATA spare parts
252701010368	ENGINE ASSY	TATA spare parts
25270101036870	ENGINE ASSY_IPBT	TATA spare parts
252701010372	ENGINE ASSY	TATA spare parts
252701010374	ENGINE ASSY	TATA spare parts
25270101037470	ENGINE ASSY_IPBT	TATA spare parts
252701010375	ENGINE ASSY	TATA spare parts
25270101037570	ENGINE ASSY_IPBT	TATA spare parts
252701010376	ENGINE ASSY	TATA spare parts
252701010378	ENGINE ASSY 497TC39 101PS BSIII ESCORTS	TATA spare parts
252701010380	ENGINE ASSY	TATA spare parts
252701010382	ENGINE ASSY BS6	TATA spare parts
252701010388	ENGINE ASSY 609G SFC BS6	TATA spare parts
252701010389	ENG ASSY 497DI38 49.5PS@2000 EX70 BSIII	TATA spare parts
252701010395	ENGINE ASSY BS6	TATA spare parts
252701010396	ENGINE ASSY	TATA spare parts
252701010397	ENGINE ASSY BS6	TATA spare parts
252701010399	ENGINE ASSY 497CEVBSIV 76PS	TATA spare parts
252701020101	ASSY. ENGINE 497 CEV BS4 WITH CLUTCH & G	TATA spare parts
252701020114	ENGINE ASSY BS6	TATA spare parts
252701020117	ENGINE ASSY WITH CLUTCH & GB 497NA BS II	TATA spare parts
252701020118	ENGINE ASSY	TATA spare parts
252701020123	ENGINE ASSY COMPLETE BS6	TATA spare parts
252701020127	ENGINE ASSY BS6-PH2	TATA spare parts
252701020128	ENGINE ASSY BS6	TATA spare parts
252701020129	ENGINE ASSY	TATA spare parts

252701020133	ENGINE ASSY BS6-PH2	TATA spare parts
252701020135	ENGINE ASSY BS6-PH2	TATA spare parts
252701020136	ENGINE ASSY BS6-PH2	TATA spare parts
25270102013670	ENGINE ASSY BS6-PH2	TATA spare parts
252701020143	ENGINE ASSY 3.8SGI CNG BS6-PH2	TATA spare parts
25270102014370	ENGINE ASSY W/CLUTCH 3.8SGI CNG BS6-PH2	TATA spare parts
252701020144	ENGINE ASSY BS6-PH2	TATA spare parts
252701020165	ENGINE ASSY WITH CLUTCH & GB	TATA spare parts
252701100127	ASSY. CYLINDER BLOCK W/O CL/FLY HSG BS3	TATA spare parts
252701100145	ASSY. CYL CRANKCASE W/O CLUTCH HSG BS2	TATA spare parts
252701100160	ASSY. CYL. CRANKCASE W/O CL HSG BS3/4	TATA spare parts
252701100165	ASSY CYLINDER CRANKCASE WITH LINER:BSIII	TATA spare parts
252701100170	ASSY CYL CRANKCASE WITHOUT FLY HSG E III	TATA spare parts
252701100171	ASSY CYL CRANKCASE WITH LINER BS-III	TATA spare parts
252701100173	ASSY. CYL CRANKCASE W/O CL HSG BS2/3/4	TATA spare parts
252701100202	ASSY CYLINDER CRANKCASE W/O CLUTCH HOUSI	TATA spare parts
252701100204	ASSY. CYL CRANKCASE W/O FLY HSG BS3	TATA spare parts
252701100218	ASSY. CYLINDER CRANKCASE W/O FLY HSG BS3	TATA spare parts
252701100233	ASSY CYL CRANKCASE WITH CLT HSG LP1112	TATA spare parts
252701100240	ASSY. CYL. CRANKCASE WITH CLUTCH HSG	TATA spare parts
252701100242	ASSY.CYL.CRANKCASE WITH FLYWHEEL HSG	TATA spare parts
252701100244	ASSY.CYL.CRANKCASE WITHOUT FLYWHEEL HSG.	TATA spare parts
252701100255	ASSY CYL CRANKCASE W/O FLYWHEEL HSG	TATA spare parts
252701100266	ASSY.CRANKCASE WITH FLYWHEEL HSG	TATA spare parts
252701100268	ASSY.CRANKCASE W/O FLYWHEEL HSG	TATA spare parts
252701100274	CRANKCASE ASSY W/O FLYWHEEL HSG )(77D)	TATA spare parts
252701100279	CYLINDER BLOCK ASSY WITH CLUTCH HOUSING	TATA spare parts
252701100323	CYLCRANKCASEASSYW/OCLUTCHHSG	TATA spare parts
252701100351	ASSY CYL CRANKCASE WITHOUT CLUTCH HSG	TATA spare parts
252701103718	CYLINDER CRANKCASE	TATA spare parts
252701103720	CYL.CRANKCASE- REINFORCED	TATA spare parts
252701103727	CYLINDER LINER 497 TCIC BS1/2/3/4	TATA spare parts
252701103727DF4F	CYLINDER LINER SET 497-709/909 FF STD	TATA spare parts
252701103727DF4S	CYLINDER LINER SET 497-709/909 STD SF	TATA spare parts
252701103727DF4S10	CYLINDER LINER SET 497-709/909 SF OS10-0	TATA spare parts
252701103727DF4S20	CYLINDER LINER SET 497-709/909 SF OS20-0	TATA spare parts
252701103727DF4S30	CYLINDER LINER SET 497-709/909 SF OS30-0	TATA spare parts
252701103727DF4S40	CYLINDER LINER SET 497-709/909 SF OS40-1	TATA spare parts
252701103727DF4S60	CYLINDER LINER SET 497-709/909 SF OS60-1	TATA spare parts
252701103727DF6F	CYLINDER LINER SET 697- LPT/K1613 FF STD	TATA spare parts
252701103727DF6S	CYLINDER LINER SET 697-LPT/LPK1613 SF ST	TATA spare parts
252701103727DF6S10	CYLINDER LINER SET 697-LPT/LPK1613 SF OS	TATA spare parts
252701103727DF6S20	CYLINDER LINER SET 697-LPT/LPK1613 SF OS	TATA spare parts
252701103727DF6S30	CYLINDER LINER SET 697-LPT/LPK1613 SF OS	TATA spare parts
252701103727DF6S40	CYLINDER LINER SET 697-LPT/LPK1613 SF OS	TATA spare parts
252701103727DF6S60	CYLINDER LINER SET 697-LPT/LPK1613 SF OS	TATA spare parts
252701103729	CYLINDER LINER :497 TC IC BS-III	TATA spare parts

252701103731	CYLINDER LINER :497 TC IC BS-III	TATA spare parts
252701103756	CYLINDER LINER (M/S IPL)	TATA spare parts
252701130104	KIT OIL SUMP GASKETS	TATA spare parts
252701130114	OIL SUMP ASSY	TATA spare parts
252701130116	OIL SUMP ASSY	TATA spare parts
252701130117	OIL SUMP ASSY	TATA spare parts
252701130119	ASSY FLANGE OIL SUMP	TATA spare parts
252701130124	OIL SUMP ASSY	TATA spare parts
252701130125	ASSY. OILSUMP W/O DIPST. FLANGES BS2/3/4	TATA spare parts
252701130127	ASSY OIL SUMP COMP	TATA spare parts
252701130131	ASSY OIL SUMP	TATA spare parts
252701130133	ASSY OIL SUMP COMP W/COUP NUT & FERRULE	TATA spare parts
252701130140	ASSY GASKET OIL SUMP	TATA spare parts
252701130141	SET-OIL SUMP GASKETS BS2/3/4	TATA spare parts
252701130143	ASSY OIL SUMP COMP W/COUP NUT & FERRULE	TATA spare parts
252701130145	ASSY GASKET OIL SUMP	TATA spare parts
252701130151	ASSY FLANGE-TURBOCHARGER OIL RETURN	TATA spare parts
252701130152	ASSY GASKET OIL SUMP	TATA spare parts
252701130155	ASSY.OIL SUMP WITH OUT FLANGE	TATA spare parts
252701130158	ASSY OIL SUMP W/O DIPSTICK & FLANGES	TATA spare parts
252701130159	SET ASSY.OILSUMP WITH NOISE DAMPER PADS	TATA spare parts
252701130169	ASSY OIL SUMP GASKET	TATA spare parts
252701130183	ASSY COMBI SCREW	TATA spare parts
252701130199	GASKET ASSY OIL SUMP M/S SANKAR SEALING	TATA spare parts
252701130209	ASSY OIL SUMP COMPLETE	TATA spare parts
252701130215	OIL SUMP ASSYBS6	TATA spare parts
252701130225	OIL SUMP ASSY W/O FLANGE BS6	TATA spare parts
252701130227	OIL SUMP ASSY BS6-PH2	TATA spare parts
252701135301	GASKET LEFT OIL SUMP	TATA spare parts
252701135302	GASKET RIGHT OIL SUMP	TATA spare parts
252701135303	GASKET OIL SUMP	TATA spare parts
252701135308	ASSY GASKET OIL SUMP	TATA spare parts
252701135309	ASSY GASKET OIL SUMP	TATA spare parts
252701136301	CAP FOR OIL DRAIN PLUG	TATA spare parts
252701137701	NOISE PAD 1 HEAD COVER	TATA spare parts
252701137702	NOISE PAD 2 HEAD COVER	TATA spare parts
252701138801	STUD OIL SUMP MOUNTING	TATA spare parts
252701140102	COVER PUSH ROD CHAMBER	TATA spare parts
252701140117	ASSY TIMING GEAR HSG WITH BOTTOM COVER	TATA spare parts
252701140129	ASSY PIPE (FRONT OIL FILLER )	TATA spare parts
252701140130	ASSY.TGH WITH THREAD INSERTS:497/697 ENG	TATA spare parts
252701140134	SET ASSY PUSH ROD CHAMBER COVER WITH NOI	TATA spare parts
252701140135	ASSY TGH WITH THREAD INSERTS	TATA spare parts
252701140144	ASSY TIMING GEAR HOUSING WITH BOTTOM COV	TATA spare parts
252701143703	COVER FRONT TGH WITH OIL HOLE	TATA spare parts
252701143706	COVER FRONT TGH WITH OUT OIL HOLE	TATA spare parts
252701145301	GASKET PUSH ROD COVER	TATA spare parts

252701145302	GASKET (TGH TO BLOCK)	TATA spare parts
252701145303	GASKET-PUSHROD CHAMBER COVER.	TATA spare parts
252701145304	GASKET PRC COVER	TATA spare parts
252701145305	GASKET-TGH COVER	TATA spare parts
252701145306	GASKET TGH	TATA spare parts
252701145312	TGH COVER GASKET BS4	TATA spare parts
252701145313	GASKET (TGH TO BLOCK)	TATA spare parts
252701145315	GASKET (BRACKET TO OIL SUMP) BSIV	TATA spare parts
252701147701	SEAL CRANKSHAFT FRONT	TATA spare parts
252701147702	OIL SEAL-CRANKSHAFT FRONT(VITON OFFER)	TATA spare parts
252701149201	SEALING WASHER (PUSH ROD CHAMBER COVER)	TATA spare parts
252701150102	CYLINDER HEAD W/O VALVES	TATA spare parts
252701150108	ELBOW AIR INTAKE	TATA spare parts
252701150115	CYLINDER HEAD W/VALVES	TATA spare parts
252701150116	CYLINDER HEAD W/O VALVES	TATA spare parts
252701150118	ELBOW AIR INTAKE	TATA spare parts
252701150136	ASSY CYL HD W/O VALVES	TATA spare parts
252701150137	CYLINDER HEAD WITH VALVES	TATA spare parts
252701150139	SET VALVE SEAT RINGS STD	TATA spare parts
252701150140	SET VALVE SEAT RINGS STD1	TATA spare parts
252701150141	CYLINDER HEAD W/O VALVES	TATA spare parts
252701150142	CYLINDER HEAD W/VALVES	TATA spare parts
252701150143	ASSY AIR-FUEL MIXER LANDI-RENZO 497CNG	TATA spare parts
252701150156	ASSY.CYLINDER HEAD COVER WITH SLEEVE-CNG	TATA spare parts
252701150160	ASSY SUPPORT-VENT TUBES ON AIR INLET	TATA spare parts
252701150161	ASSY AIR INTAKE ELBOW :SFC709EX	TATA spare parts
252701150162	ASSY.CYL.HEAD WITH VALVES-CR	TATA spare parts
252701150163	ASSY.CYL.HEAD WITH OUT VALVES-CR	TATA spare parts
252701150165	ASSY CYLHEAD W/O VALVES:4SP/497 BS-III	TATA spare parts
252701150168	ASSY.CYL.HEAD WITHOUT VALVES 497X128	TATA spare parts
252701150169	ASSY.CYL.HEAD WITH VALVES(497) BSII	TATA spare parts
252701150170	ASSY SUPPORT VENT TUBES:ON AIR INT.ELBOW	TATA spare parts
252701150174	ASSY.CYL.HEAD WITH VALVES 497 BS-III	TATA spare parts
252701150175	ASSY.CYL HEAD W/O VALVES 4SP/497 BS-III	TATA spare parts
252701150178	ASSY AIR INTAKE ELBOW:SFC709 BS:II EX	TATA spare parts
252701150188	ASSY CYL HEAD W/VALVE:497BSIIEX (60 DEG)	TATA spare parts
252701150190	ASSY CYLINDER HEAD WITH VALVES	TATA spare parts
252701150198	ASSY. CYL. HEAD WITH VALVES	TATA spare parts
252701150199	ASSY. CYL. HEAD WITHOUT VALVES	TATA spare parts
252701150205	ASSY CYLINDER HEAD W/O VALVES 497 CNG	TATA spare parts
252701150206	ASSY. CYLINDER-HEAD WITH VALVES 497 CNG	TATA spare parts
252701150211	ASSY. CYLINDER HEAD W/VALVES BS4	TATA spare parts
252701150212	ASSY. CYLINDER HEAD WITHOUT VALVES	TATA spare parts
252701150213	ASSY.CYL.HEAD WITH VALVES-60 DEG ECCENTC	TATA spare parts
252701150215	ASSY.CYL.HEAD W/O VALVES-60 DEG ECCENTRC	TATA spare parts
252701150223	ASSY CYL HEAD WT VALVES-3.8 SGI BSIV TC	TATA spare parts
252701150224	ASSY CYL HEAD WITHOUT VALVES	TATA spare parts

252701150225	ASSY CYLINDER HEAD WITH VALVES	TATA spare parts
252701150226	ASSY CYLINDER HEAD WITHOUT VALVE	TATA spare parts
252701150229	ASSY CYLINDER HEAD COVER (ALUMINIUM SIDE	TATA spare parts
252701150236	ASSY CYLINDER HEAD COVER (ALLUMINIUM SID	TATA spare parts
252701150238	ASSY CYLINDER HEAD COVER (AL FRONT)	TATA spare parts
252701150241	ASSY CYLINDER HEAD COVER (ALLUMINIUM SID	TATA spare parts
252701150242	ASSY CYLINDER HEAD COVER ALLUMINIUM FRT	TATA spare parts
252701150243	ASSY CYLINDER HEAD COVER	TATA spare parts
252701150246	ASSY CYLINDER HEAD COVER (AL FRONT)	TATA spare parts
252701150264	ASSY CYLINDER HEAD W/O VALVES 60-DEG.	TATA spare parts
252701150267	ASSY CYLINDER HEAD COVER (ALLUMINIUM FRO	TATA spare parts
252701150270	ASSY AIR INTAKE ELBOW	TATA spare parts
252701150276	ASSEBMLY CYLINDER HEAD WITHOUT VALVES	TATA spare parts
252701150294	ELBOW ASSY AIR INTAKE	TATA spare parts
252701150296	CYLINDER HEAD ASSY WITH VALVESBS6	TATA spare parts
252701150297	CYLHEADASSYWITHVALVES BS6	TATA spare parts
252701150298	CYL HEAD ASSY WITH VALVES BS6	TATA spare parts
252701150299	CYL HEAD ASSY W/O VALVES	TATA spare parts
252701150301	CYL HEAD ASSY WITH VALVES	TATA spare parts
252701150302	SUPPORT BRACKET ASSY (AIR INTAKE ELBOW)	TATA spare parts
252701150306	SEALING PLUG BS6	TATA spare parts
252701153302	SUPPORT BRACKET (MANIFOLD TO ELBOW)	TATA spare parts
252701153303	SUPPORT BRACKET (FOR AIR INTAKE ELBOW)	TATA spare parts
252701153822	AIR INTAKE ELBOW:LP/LPT709 TC/IC HIGH TQ	TATA spare parts
252701153825	AIR INTAKE ELBOW	TATA spare parts
252701153827	AIR INTAKE ELBOW-(FOR THL)-CIL GENSET	TATA spare parts
252701153835	AIR INLATE ELBOW CPCB 40KVA	TATA spare parts
252701153836	AIR INTAKE ELBOW (497 TC IC BS:II)	TATA spare parts
252701153844	ROCKER ARM COVER	TATA spare parts
252701153845	AIR INTAKE ELBOW 497 BS-IV	TATA spare parts
252701153847	AIR INTAKE ELBOW	TATA spare parts
252701153848	AIR INTAKE ELBOW	TATA spare parts
252701153851	AIR INTAKE ELBOW	TATA spare parts
252701153867	AIR INTAKE ELBOW	TATA spare parts
252701153868	AIR INTAKE ELBOW LP1512 BS-IV	TATA spare parts
252701153874	AIR INTAKE ELBOW (OBD 497 BS-IV)	TATA spare parts
252701153876	ELBOW AIR INTAKE	TATA spare parts
252701153889	ELBOW AIR INTAKE	TATA spare parts
252701153890	CYLINDER HEAD COVER BS6-PH2	TATA spare parts
252701155301	GASKET CYLINDER HEAD	TATA spare parts
252701155302	GASKET CYLINDER HEAD COVER BS2/3/4	TATA spare parts
252701155307	GASKET FOR CYL HEAD COVER	TATA spare parts
252701155308	GASKET AIR INTAKE ELBOW	TATA spare parts
252701155309	GASKET AIR INTAKE ELBOW	TATA spare parts
252701155310	GASKET-CYL. HEAD -1.35MM THICK BS1- 4/6	TATA spare parts
252701155312	CYLINDER HEAD GASKET (MLS)::EUROIII	TATA spare parts
252701155313	CYLINDER HEAD GASKET(MLS) EUROIII	TATA spare parts

252701155314	GASKET- THROTTLE BODY TO INT. MANIFOLD	TATA spare parts
252701155315	GASKET-NON ASBESTOS (AIR INTAKE ELBOW)	TATA spare parts
252701155316	GASKET (ROCKER ARM COVER)	TATA spare parts
252701155317	GASKET - ROCKER ARM COVER (AL - TALBROS)	TATA spare parts
252701155318	GASKET CYLINDER HEAD COVER BS3/4	TATA spare parts
252701155322	GASKET (AIR INTAKE ELBOW)	TATA spare parts
252701155324	GASKET ELBOW	TATA spare parts
252701155325	AIR INTAKE ELBOW GASKET	TATA spare parts
252701155328	GASKET AIR INTAKE ELBOW	TATA spare parts
252701155329	GASKET (SPLIT HEAD COVER)	TATA spare parts
252701155332	GASKET CYLINDER HEAD	TATA spare parts
252701159901	REDUCER	TATA spare parts
252701159903	STRAIGHT REDUCER	TATA spare parts
252701159904	STRAIGHT REDUCER (497X128 TC EURO II)	TATA spare parts
252701160105	INJECTOR W/NOZZLE	TATA spare parts
252701160116	ASSY.INJECTOR	TATA spare parts
252701160117	ASSY INJECTOR	TATA spare parts
252701160118	ASSY.INJECTOR NORMAL 497 BS-III	TATA spare parts
252701160119	ASSY.INJ.NBFE TYPE 497 BS-III	TATA spare parts
252701160122	ASSY.INJECTOR CPCB 40KVA	TATA spare parts
252701160140	ASSY FUEL INJECTOR(497 BS-IV)	TATA spare parts
252701160141	ASSY INJECTOR WITH K-FACTOR	TATA spare parts
252701160146	NOZZLE HOLDER ASSEMBLY	TATA spare parts
252701160147	NOZZLE HOLDER ASSY	TATA spare parts
252701160148	NOZZLE HOLDER ASSY	TATA spare parts
252701160155	INJECTOR ASSY	TATA spare parts
252701163202	BANJO BOLT	TATA spare parts
252701163803	CONNECTOR SINGLE TUBE	TATA spare parts
252701163804	CONNECTOR TWO TUBES NORMAL INJ.	TATA spare parts
252701163807	CONNECTOR ONE TUBE(MIM)	TATA spare parts
252701163808	CONNECTOR TWO TUBES	TATA spare parts
252701165101	CLAW INJECTOR OUTSIDE COVER	TATA spare parts
252701169203	SEALING WASHER	TATA spare parts
252701169205	SEALING WASHER	TATA spare parts
252701169908	NOZZLE	TATA spare parts
252701170109	DIPSTICK	TATA spare parts
252701170115	PIPE OIL FILLER W/BKT	TATA spare parts
252701170116	DIPSTICK	TATA spare parts
252701170118	TUBE DIPSTICK COMP LP	TATA spare parts
252701170119	TUBE DIPSTICK	TATA spare parts
252701170132	ASSY. BRIDGE	TATA spare parts
252701170134	DIPSTICK	TATA spare parts
252701170137	ASSY TUBE COMPLETE SFC	TATA spare parts
252701170138	TUBE DIPSTICK SFC	TATA spare parts
252701170140	PIPE OIL FILLER W/BKT	TATA spare parts
252701170148	ASSY.OIL DIPSTICK COMPLETE(B)	TATA spare parts
252701170152	ASSY. SUPPORT (DIPSTICK MTG.ON BRIDGE)	TATA spare parts

252701170154	ASSY.OIL FILLER PIPE WITH BRACKET	TATA spare parts
252701170161	ASSY DIPSTICK COMPLETE	TATA spare parts
252701170170	ASSY BKT DIPSTIC MTG :LPT 709 TC IC	TATA spare parts
252701170171	ASSY BRACKET DIPSTIC MOUNTING:LPT1113	TATA spare parts
252701170172	ASSY. OIL DIPSTICK COMPLETE	TATA spare parts
252701170174	ASSY. DIPSTICK TUBE COMPLETE	TATA spare parts
252701170184	ASSY.TUBE (CYL.HEAD COVER TO OMS)	TATA spare parts
252701170187	ASSY TUBE WITH CLAMP (OMS TO OIL SUMP)	TATA spare parts
252701170191	ASSEMBLY OIL MIST SEPARATOR BS-IV	TATA spare parts
252701170195	ASSY OIL DIPSTICK COMPLETE	TATA spare parts
252701170199	PIPE ASSY WITH CLAMP (OMS TO OIL SUMP)	TATA spare parts
252701170205	ASSY OIL DIPSTICK COMPLETE	TATA spare parts
252701170219	ASSY BRACKET DIPSTICK MOUNTING	TATA spare parts
252701170221	ASSY CLAMP WITH WELD NUT (FOR DIPSTICK S	TATA spare parts
252701170223	ASSY BRACKET WITH WELD NUT (FOR DIPSTICK	TATA spare parts
252701170232	ASSY BKT DIP MOUNTING LPT1112	TATA spare parts
252701170235	ASSEMBLY CLAMP WITH WELD NUT	TATA spare parts
252701170237	ASSY PIPE WITH CLAMP(BREATHER TO ATM)	TATA spare parts
252701170244	ASSY. DIPSTICK COMPLETE ROPE TYPE	TATA spare parts
252701170249	ASSEMBLY BRACKET (FOR OMS MOUNTING)	TATA spare parts
252701170251	ASSY TUBE WITH CLAMP (OMS TO OIL SUMP)	TATA spare parts
252701170252	ASSY TUBE WITH CLAMP (OMS TO ATMOSPHERE)	TATA spare parts
252701170256	ASSY BRACKET FOR DIPSTIC TUBE	TATA spare parts
252701170257	COATED CLAMP :LP FESLF	TATA spare parts
252701170283	ASSY BRACKET(FOR DIPSTIC MTG)	TATA spare parts
252701170299	DIPSTICK TUBE ASSY	TATA spare parts
252701170301	DIPSTICK TUBE ASSY L1121	TATA spare parts
252701170305	CLAMP ASSY WITH SLEEVE	TATA spare parts
252701170306	BRACKET ASSY DIPSTICK MTG	TATA spare parts
252701170311	ASSY DIPSTICK TUBE WITH ADAPTOR(EXOTECH)	TATA spare parts
252701170312	DIPSTICK ASSY	TATA spare parts
252701170358	DIPSTICK TUBE ASSY WITH ADAPTOR	TATA spare parts
252701170361	TUBE ASSY BREATHER TO ATM	TATA spare parts
252701170366	BRACKET ASSY DIPSTICK MTG	TATA spare parts
252701170369	ADAPTER ASSY WITH PIPE	TATA spare parts
252701170381	DIPSTICK ASSY	TATA spare parts
252701170382	DIPSTICK ASSY	TATA spare parts
252701170383	DIPSTICK ASSY ROPE ULTRA	TATA spare parts
252701170390	TUBE ASSY WITH CLAMP OMS TO ATM	TATA spare parts
252701170392	TUBE ASSY WITH CLAMP OMS TO OIL SUMP	TATA spare parts
252701170393	TUBE ASSY OMS TO ATMOSPHERE	TATA spare parts
252701170394	PIPE ASSY	TATA spare parts
252701170396	BRACKET ASSY OIL SEPARATOR MTG	TATA spare parts
252701170398	BRACKET ASSY DIPSTICK MTG	TATA spare parts
252701173313	SUPPORT-OIL FILLING MTG	TATA spare parts
252701173343	SUPPORT BRACKET BS6	TATA spare parts
252701174204	CLAMP-BREATHER	TATA spare parts



252701174205	CLAMP FOR DIPSTIC MTG	TATA spare parts
252701174232	CLAMP DIPSTICK MTG	TATA spare parts
252701174259	CLAMP BS6-PH2	TATA spare parts
252701175808	HOSE-BREATHER	TATA spare parts
252701175810	HOSE (BREATHER)	TATA spare parts
252701175814	RUBBER HOSE (OMS TO OIL SUMP)	TATA spare parts
252701175815	RUBBER HOSE (CYL. HEAD COVER TO OMS) 497	TATA spare parts
252701175816	RUBBER HOSE (OMS OUTLET)	TATA spare parts
252701175825	RUBBER HOSE (OMS TO OIL SUMP)	TATA spare parts
252701175827	RUBBER HOSE(CYL.HEAD COVER TO OMS)	TATA spare parts
252701175830	RUBBER HOSE (CYL HEAD COVER TO OMS)	TATA spare parts
252701175854	RUBBER HOSE	TATA spare parts
252701175855	RUBBER HOSE	TATA spare parts
252701175861	RUBBER HOSE CYL HEAD COVER TO OMS	TATA spare parts
252701175863	RUBBER HOSE CYLHEAD COVER TOOMS	TATA spare parts
252701175864	RUBBER HOSE CYLHEAD COVER TOOMS	TATA spare parts
252701175865	HOSE BLOWBY	TATA spare parts
252701175866	RUBBER HOSE	TATA spare parts
252701176960	TUBE (FOR BREATHER OUTLET)	TATA spare parts
252701176980	PIPE	TATA spare parts
252701176989	PIPE	TATA spare parts
252701176995	TUBE OMS BS6	TATA spare parts
252701178205	SUPPORT CLAMP DIPSTICK	TATA spare parts
252701178206	SUPPORT DIPSTICK	TATA spare parts
252701178208	BKT DIPSTICK TUBE	TATA spare parts
252701178255	BRACKET ASSY OMS MTG	TATA spare parts
252701179910	O-RING DIPSTICK BS6	TATA spare parts
252701180101	BRACKET ASSY DIPSTICK MTG	TATA spare parts
252701180102	TUBE ASSY WITH CLAMP	TATA spare parts
252701180105	SUPPORT BRACKET ASSY	TATA spare parts
252701180108	OIL MIST SEPARATOR ASSY BS6	TATA spare parts
252701180109	TUBE ASSY OMS TO OIL SUMP BS6	TATA spare parts
252701180113	PIPE ASSY OIL SEPARATOR TO AIR FILTER BS	TATA spare parts
252701180116	PIPE ASSY BLOWBY BS6	TATA spare parts
252701180117	PIPE ASSY OMS TO AIR FILTER PIPE BS6	TATA spare parts
252701180119	PIPE ASSY OIL SEPARATOR TO AIR FILTER BS	TATA spare parts
252701180120	BRACKET ASSY OIL SEPARATOR MTG BS6	TATA spare parts
252701180121	SUPPORT BRACKET OMS TO OIL SUMP BS6	TATA spare parts
252701180128	TUBE ASSY OMS TO OIL SUMP BS6	TATA spare parts
252701180129	PIPE ASSY OMS TO AIR FILTER PIPE BS6	TATA spare parts
252701180130	PIPE ASSY BLOWBY BS6	TATA spare parts
252701180135	ADAPTER DIPSTICK TUBE BS6-PH2	TATA spare parts
252701180136	OIL MIST SEPARATOR ASSY BS6-PH2	TATA spare parts
252701180137	PIPE ASSY OMS TO AIR FILTER PIPE BS6-PH2	TATA spare parts
252701180142	PIPE ASSY OMS TO AIR FILTER PIPE BS6-PH2	TATA spare parts
252701190102	TUBE ASSY BREATHER TO ATM	TATA spare parts
252701190104	BRACKET ASSY DIPSTICK MTG	TATA spare parts

25270190115	PIPE ASSY	TATA spare parts
252701980103	HALF BLOCK	TATA spare parts
252701980105	LONG BLOCK	TATA spare parts
252701980108	HALF BLOCK ASSY	TATA spare parts
252701980109	HALF BLOCK ASSY	TATA spare parts
252701980111	HALF BLOCK ASSY	TATA spare parts
252701980112	LONG BLOCK ASSY	TATA spare parts
252701980113	LONG BLOCK ASSY	TATA spare parts
252701980114	LONG BLOCK ASSY	TATA spare parts
252701980120	LONG BLOCK ASSY	TATA spare parts
252701980122	KIT-HALF BLOCK ASSY	TATA spare parts
252701980124	HALF BLOCK ASSY	TATA spare parts
252701980126	HALF BLOCK	TATA spare parts
252701980127	KIT-HALF BLOCK ASSY	TATA spare parts
252701980131	LONG BLOCK	TATA spare parts
252701980132	LONG BLOCK ASSY	TATA spare parts
252701980135	LONG BLOCK ASSY	TATA spare parts
252701980138	HALF BLOCK ASSY	TATA spare parts
252701980139	LONG BLOCK ASSY	TATA spare parts
252701980140	HALF BLOCK ASSY	TATA spare parts
252701980141	LONG BLOCK ASSY	TATA spare parts
252701980142	HALF BLOCK ASSY	TATA spare parts
252701980145	KIT-ENGINE OVERHAUL GASKET	TATA spare parts
252701980147	HALF BLOCK ASSY	TATA spare parts
252701980148	LONG BLOCK ASSY	TATA spare parts
252701980152	HALF BLOCK ASSY	TATA spare parts
252701980153	LONG BLOCK ASSY	TATA spare parts
252701980157	HALF BLOCK ASSY	TATA spare parts
252701980158	LONG BLOCK ASSY	TATA spare parts
252701980161	HALF BLOCK ASSY	TATA spare parts
252701980162	LONG BLOCK ASSY	TATA spare parts
252701980164	HALF BLOCK ASSY	TATA spare parts
252701980165	LONG BLOCK ASSY	TATA spare parts
252701980169	HALF BLOCK ASSY	TATA spare parts
252701980171	LONG BLOCK ASSY	TATA spare parts
252701980172	KIT-GASKET	TATA spare parts
252701980175	HALF BLOCK ASSY	TATA spare parts
252701980177	LONG BLOCK ASSY	TATA spare parts
252701980180	HALF BLOCK ASSY	TATA spare parts
252701980182	LONG BLOCK ASSY	TATA spare parts
252701980187	HALF BLOCK ASSY	TATA spare parts
252701980189	ASSY. LONG BLOCK LPT 1512 BS4	TATA spare parts
252701980192	KIT-HALF BLOCK ASSY	TATA spare parts
252701980207	LONG BLOCK ASSY	TATA spare parts
252701980226	KIT-ENGINE OVERHAUL SEAL BS6	TATA spare parts
252701980235	HALF BLOCK ASSY	TATA spare parts
252701980236	LONG BLOCK ASSY	TATA spare parts

252701980250	HALF BLOCK ASSY	TATA spare parts
252701980252	LONG BLOCK ASSY	TATA spare parts
252701980255	HALF BLOCK ASSY (497NA49PS@2000RPM)	TATA spare parts
252701980257	LONG BLOCK ASSY (497NA49PS@2000RPM)	TATA spare parts
252701980273	KIT-HALF BLOCK BS6-PH2	TATA spare parts
252701980274	KIT-LONG BLOCK BS6-PH2	TATA spare parts
252701980275	KIT LONG BLOCK BS6-PH2	TATA spare parts
252701980276	KIT HALF BLOCK BS6-PH2	TATA spare parts
252701980278	KIT-LONG BLOCK BS6-PH2	TATA spare parts
252701980281	KIT-LONG BLOCK BS6-PH2	TATA spare parts
252701980282	KIT-HALF BLOCK BS6-PH2	TATA spare parts
252701990101	KIT- ENGINE OVERHAUL GASKET BS2	TATA spare parts
252701990102	KIT DECARHOUSING GASKETS	TATA spare parts
252701990103	LONG BLOCK 497NA	TATA spare parts
252701990105	SHORT BLOCK LPT909	TATA spare parts
252701990106	ASSY SHORT BLOCK LPT 1009	TATA spare parts
252701990107	HALF BLOCK 497 NA - BUS	TATA spare parts
252701990108	HALF BLOCK 497 NA - TRUCK	TATA spare parts
252701990110	LONG BLOCK 497NA	TATA spare parts
252701990112	HALF BLOCK 497X128 CMVR 20000-SFC709	TATA spare parts
252701990113	ASSY.LONG BLOCK 497X128 CMVR2000-SFC709	TATA spare parts
252701990114	HALF BLOCK 497X128 CMVR 2000-LP/LPT-709	TATA spare parts
252701990115	ASSY.LONG BLOCK 497X128 CMVR2000-LP/LPT	TATA spare parts
252701990116	SHORT BLOCK 497TC VA	TATA spare parts
252701990117	ASSY.LONG BLOCK-497X128 TC I2K-SFC 709	TATA spare parts
252701990133	ASSY.SHORT BLOCK LP/LPT1109	TATA spare parts
252701990134	ASSY.LONG BLOCK-LP/LPT 1109	TATA spare parts
252701990137	HALF BLOCK 497X128TURBO S-CAM EUROII	TATA spare parts
252701990138	LONG BLOCK 497X128 TURBO S-CAM EURO II	TATA spare parts
252701990141	ASSY HALF BLOCK(497X128TCIC I2K)LP/LPT-E	TATA spare parts
252701990143	ASSY LONG BLOCK(497X128TCIC I2K)LP/LPT-E	TATA spare parts
252701990146	ASSY HALF BLOCK 497 EURO-II-LP/LPT1109	TATA spare parts
252701990148	ASSY LONG BLOCK 497 EURO-II-LP/LPT1109	TATA spare parts
252701990150	ASSY LONG BLOCK LP/LPT709 497BSIII	TATA spare parts
252701990152	ASSY HALF BLOCK LP/LPT709 497TCIC BSIII	TATA spare parts
252701990154	KIT-GASKET (ENGINE OVERHAUL) 497 BS3	TATA spare parts
252701990155	DECARBONISING GASKET KIT:497 BS:III	TATA spare parts
252701990156	ASSY LONG BLOCK:497 TCIC BS:III LP:1512	TATA spare parts
252701990158	ASSY HALF BLOCK :497 BS:III LP:1512	TATA spare parts
252701990160	ASSY LONG BLOCK :LPT1109 BSII EX	TATA spare parts
252701990162	ASSY HALF BLOCK LPT1109 BSII EX	TATA spare parts
252701990165	LONG BLOCK 497 CNG BS-III	TATA spare parts
252701990167	HALF BLOCK 497 CNG BS-III	TATA spare parts
252701990168	KIT GASKETS ENGINE-OVERHAUL 497 CNG BS-3	TATA spare parts
252701990183	ASSY LONG BLOCK(SFC712) 497TCIC BS:III	TATA spare parts
252701990184	ASSY HALF BLOCK(SFC712) 497TCIC BS:III	TATA spare parts
252701990188	DECARB GASKET KIT W/O CYL HEAD GASKET	TATA spare parts

252701990189	OVERHAUL GASKET W/O CYL HEAD GASKET	TATA spare parts
252701990191	SET OF VALVE	TATA spare parts
252701990193	VALVE SEAL SET (497CR BS-IV ENGINE)	TATA spare parts
252701990204	ASSY LONG BLOK	TATA spare parts
252701990206	ASSY HALF BLOCK	TATA spare parts
252701990208	ENGINE OVERHAUL GASKET KIT	TATA spare parts
252701990209	DECARBURIZING KIT	TATA spare parts
252701990211	SET OF VALVE SEAT RING INLET & EXHUAUST	TATA spare parts
252701990228	LONG BLOCK 497TCIC LP 709	TATA spare parts
252701990230	ASSY HALF BLOCK LP 709	TATA spare parts
252701990237	ASSY. LONG BLOCK 497CRDI BS3/4	TATA spare parts
252701990243	LONG BLOCK ASSY WITH CL HSG LP1512	TATA spare parts
252701990245	LONG BLOCK ASSY(77DIA AC)CLHSG Y1 MBCAP	TATA spare parts
252701990247	LONG BLOCK (77 DIA AC)W CL HSG	TATA spare parts
252701990251	LONG BLOCK ASSY (94DIA AIR COMP PTFE)	TATA spare parts
252701990255	ASSY. LONG BLOCK 497CRDI BS3	TATA spare parts
252701990257	LONG BLOCK ASSY (AC TRUCK)	TATA spare parts
252701990262	LONG BLOCK ASSY 650 FESLF BS IV	TATA spare parts
252701990270	ASSY. LONG BLOCK 497CRDI BS3/4	TATA spare parts
252701990272	HALF BLOCK	TATA spare parts
252701990274	LONG BLOCK	TATA spare parts
252701990282	KIT INLET/EXHAUST VALVES TATA 3.8 SGI BS	TATA spare parts
252701990283	HALF BLOCK ASSY 497TCIC BS-III CLASS	TATA spare parts
252701990284	LONG BLOCK	TATA spare parts
252701990285	LONG BLOCK 497TCIC HARVESTER	TATA spare parts
252701990287	HALF BLOCK ASSY GENSET ENGINE CPCB-I	TATA spare parts
252701990288	LONG BLOCK ASSY GENSET ENGINE CPCB-I	TATA spare parts
252701990291	ASSY. HALF BLOCK 497TC BS-III 86PS ECEL	TATA spare parts
252701990295	ASSY. HALF BLOCK 497TCIC BSIII CEV THCM	TATA spare parts
252701990296	ASSY. LONG BLOCK 497TCIC BSIII CEV THCM	TATA spare parts
252701990299	ASSY. HALF BLOCK 497TCIC BS-III CEV PTFE	TATA spare parts
252701990301	ASSY. LONG BLOCK 497TCIC BS-III CEV PTFE	TATA spare parts
252701990309	ASSY LONG BLOCK 497NA CEV EX-70	TATA spare parts
252701990318	HALF BLOCK ASSY W/O AC	TATA spare parts
252701990321	HALF BLOCK Y1 ULTRA AC	TATA spare parts
252701990324	LONG BLOCK ASSY GENSET ENGINE CPCB-I	TATA spare parts
252701990325	LONG BLOCK ASSY GENSET ENGINE CPCB-I	TATA spare parts
252701990339	HALF BLOCK FOR LPO NON AC	TATA spare parts
252701990340	KIT-HALF BLOCK ASSY	TATA spare parts
252701990342	KIT-HALF BLOCK ASSY	TATA spare parts
252701990344	KIT-GASKET ENGINE OVERHAUL	TATA spare parts
252701990345	KIT-GASKET ENGINE OVERHAUL	TATA spare parts
252701990347	ASSY. LONG BLOCK 497TCIC BS3	TATA spare parts
252701990349	HALF BLOCK-497 BS-III MFIP	TATA spare parts
252701990350	HALF BLOCK ENGINE LPT1109SLTB	TATA spare parts
252701990355	HALF BLOCK	TATA spare parts
252701990359	KIT-LONG BLOCK	TATA spare parts

252701990363	ASSY. LONG BLOCK W/CL HSG. 497CRDi BS3/4	TATA spare parts
252701990366	KIT-HALF BLOCK WITH CLUTCH HSG BSIV	TATA spare parts
252701990368	KIT-HALF BLOCK	TATA spare parts
252701990370	KIT - LONG BLOCK	TATA spare parts
252701990372	LONG BLOCK KIT	TATA spare parts
252701990382	KIT-ENGINE OVERHAUL GASKET	TATA spare parts
252701990384	HALF BLOCK ASSY	TATA spare parts
252701990388	HALF BLOCK	TATA spare parts
252701990390	LONG BLOCK	TATA spare parts
252701990393	ASSY. LONG BLOCK 497CRDi BS3/4	TATA spare parts
252701990395	HALF BLOCK ASSY	TATA spare parts
252701990396	KIT-ENGINE OVERHAUL GASKET	TATA spare parts
252701990397	KIT-DECARBONISING GASKET	TATA spare parts
252701990399	HALF BLOCK ASSY	TATA spare parts
252703100140	ASSY.CR.SHAFT WITH COUNTER WTs-NORMAL	TATA spare parts
252703100141	CRANKSHAFT 497 N I	TATA spare parts
252703100172	CRANKSHAFT RS1 W/CWT	TATA spare parts
252703100230	ASSY CRANKSHAFT INT WITH PIN:NOR BSIII	TATA spare parts
252703100266	ASSY CRANKSHAFT(INT) WITH PIN NORMAL	TATA spare parts
252703100293	ASSY. CRANKSHAFT(INT) W/PIN NORM BS2/3/4	TATA spare parts
252703100298	ASSY. CRANKSAHFT W/PIN NORMAL BS2/3/4	TATA spare parts
252703107933	CRANKSHAFT STD INTCWT	TATA spare parts
252703107935	CRANKSHAFT REPAIR I-INTEGRAL	TATA spare parts
252703107951	CRANKSHAFT(INTEGRAL)-MICROALLOY	TATA spare parts
252703107954	CRANKSHAFT MICRO ALLOY NORMAL	TATA spare parts
252703110103	FLYWHEEL RING GEAR	TATA spare parts
252703110106	FLYWHEEL W/RING GEAR	TATA spare parts
252703110107	FLYWHEEL W/RING GEAR	TATA spare parts
252703110116	ASSY FLYWHEEL W/RING	TATA spare parts
252703110118	ASSY.FLYWHEEL WITH RING GEAR	TATA spare parts
252703110119	ASSY FLYWHEEL	TATA spare parts
252703110121	ASSY.FLYWHEEL WITH RING GEAR-GEN-SET	TATA spare parts
252703110123	ASSY FLYWHEEL WITH RING GEAR	TATA spare parts
252703110125	ASSY.FLYWHEEL WITH RING GEAR:1109 EUROII	TATA spare parts
252703110126	ASSY COUPLING GENSET 62.5 KVA	TATA spare parts
252703110128	ASSY FLYWHEEL WITH RING GEAR 497 HIGH TO	TATA spare parts
252703110129	ASSY.FLYWHEEL WITH RING GEAR	TATA spare parts
252703110133	ASSY FLYWHEEL WITH RING GEAR: BS-III	TATA spare parts
252703110134	ASSY.FLYWHEEL WITH RING GEAR 14 DEG	TATA spare parts
252703110135	ASSY. FLYWHEEL W/RING GEAR 330DCL. BS2/3	TATA spare parts
252703110137	ASSY. FLYWHEEL RING GEAR BS3/4	TATA spare parts
252703110141	ASSY FLYWHEEL WITH RING GEAR BS-III	TATA spare parts
252703110142	ASSY FLYWHEEL WITH RING GEAR	TATA spare parts
252703110146	ASSY FLYWHEEL RING GEAR (497 BSIV)	TATA spare parts
252703110149	ASSY FLYWHEEL	TATA spare parts
252703110157	ASSY FLYWHEEL WITH RING GEAR	TATA spare parts
252703110173	ASSY FLYWHEEL WITH RING GEAR BS-III	TATA spare parts

252703110174	ASSY.FLYWHEEL WITH RING GEAR	TATA spare parts
252703110176	ASSY FLYWHEEL WITH RING GEAR	TATA spare parts
252703110179	ASSY FLYWHEEL WITH RING GEAR(PTFE)	TATA spare parts
252703110184	ASSY.FLYWHEEL WITH RING GEAR	TATA spare parts
252703110194	ASSY FLYWHEEL WITH RING GEAR	TATA spare parts
252703110195	ASSY FLYWHEEL WITH RING GEAR	TATA spare parts
252703110201	ASSY. FLYWHEEL WITH RING GEAR	TATA spare parts
252703110202	ASSY FLYWHEEL WITH RING GEAR (PTFE)	TATA spare parts
252703110206	ASSY. FLYWHEEL WITH RING GEAR	TATA spare parts
252703110244	FLYWHEEL ASSY WITH DRIVING RING	TATA spare parts
252703110249	FLYWHEEL ASSY WITH RING GEAR BS6	TATA spare parts
252703110253	FLYWHEEL ASSY WITH RING GEAR BS6-PH2	TATA spare parts
252703110258	FLYWHEEL ASSY WITH RING GEAR BS6-PH2	TATA spare parts
252703113301	COVER PLATE (FOR FLYWHEEL HOUSING)	TATA spare parts
252703113303	COVER FLYWHEEL HOUSING UPPER	TATA spare parts
252703113701	FLYWHEEL HOUSING (JD-315 LOADER)	TATA spare parts
252703113702	FLY WHEEL HSG CPCB WITH 5/8THREAD HOL	TATA spare parts
252703113703	FLYWHEEL HOUSING	TATA spare parts
252703113705	FLYWHEEL HOUSING	TATA spare parts
252703113707	FLYWHEEL HOUSING (497 BS-IV)	TATA spare parts
252703113709	FLYWHEEL HOUSING	TATA spare parts
252703113717	FLYWHEEL HOUSING	TATA spare parts
252703113720	FLYWHEEL HOUSING BS6	TATA spare parts
252703113724	FLYWHEEL HOUSING BS6-PH2	TATA spare parts
252703113725	FLYWHEEL HOUSING BS6-PH2	TATA spare parts
252703115301	GASKET INSPECTION WINDOW	TATA spare parts
252703120103	SET MAIN BRG SHELL UP/LO NORMAL	TATA spare parts
252703120110	SET MAIN BRG UPPER/LOWER:NORMAL:EURO III	TATA spare parts
252703120112	SET-MAIN BRG.UP/LO(BIMETAL)NORMAL-E-III	TATA spare parts
252703123105	MAIN BEARING - UPPER - NORMAL	TATA spare parts
252703123106	MAIN BEARING - LOWER - NORMAL	TATA spare parts
252703123107	MAIN BEARING - UPPER - NORMAL-I	TATA spare parts
252703123108	MAIN BEARING - LOWER - NORMAL-I	TATA spare parts
252703123117	MAIN BEARING UPPER - NORMAL (M/S MENON)	TATA spare parts
252703123119	MAIN BEARING LOWER - NORMAL (M/S MENON)	TATA spare parts
252703130104	PULLEY WITH COVER	TATA spare parts
252703130106	PULLEY-CRANKSHAFT (20 DEG)(EX-70 EXCA)	TATA spare parts
252703130109	ASSY. PULLEY WITH COVER (2 GROOVE)	TATA spare parts
252703130115	PULLEY ASSY WITH COVER BS6-PH2	TATA spare parts
252703130116	ASSLY PULLEY WITH COVER	TATA spare parts
252703130119	ASSY PULLEY WITH COVER	TATA spare parts
252703130122	ASSY CRANKSHAFT PULLEY WITH COVER	TATA spare parts
252703130126	CRANKSHAFT PULLEY ASSY WITH COVER	TATA spare parts
252703137006	PULLY CRANSHAFT	TATA spare parts
252703137010	PULLEY CRANKSHAFT	TATA spare parts
252703137011	PULLEY CRANKSHAFT	TATA spare parts
252703137018	CRANKSHAFT PULLEY	TATA spare parts

252703137023	CRANKSHAFT PULLEY (DOUBLE POLY V) LPA512	TATA spare parts
252703137026	SUB ASSEMBLY CRANK SHAFT PULLEY	TATA spare parts
252703138601	SPACER	TATA spare parts
252703138603	SPACER - OIL SLINGER	TATA spare parts
252703140112	PISTON STD 96.88D	TATA spare parts
252703140113	ASSY PISTON STD	TATA spare parts
252703140121	ASSY PISTON WITH PIN&CIRCLIPS	TATA spare parts
252703140125	SET PISTON BARE 497D	TATA spare parts
252703140130	SET PISTON BARE 497D	TATA spare parts
252703140208	SET-PISTON(NORMAL-II) BSIII	TATA spare parts
252703140214	SET-ASSY.PISTON GOETZE WITH RINGS	TATA spare parts
252703140218	SET-ASSY.PISTON WITH RINGS	TATA spare parts
252703140225	SET ASSY PISTON WITH RINGS	TATA spare parts
252703140229	SET-ASSY.PISTON WITH RINGS M/S FM	TATA spare parts
252703141011	609 PISTON 96.89	TATA spare parts
252703141012	PISTON BARE 96.90D STD	TATA spare parts
252703141043	PISTON (STD-III DIA.96.890)	TATA spare parts
252703141077	PISTON:NORMAL II(96.89DIA)GOE.INDIA BS2	TATA spare parts
252703141081	PISTON:NORMAL III(96.90DIA)BS3	TATA spare parts
252703150124	ASSY. CON ROD W/BUSH/BOLT FS NORM BS1-4	TATA spare parts
252703990101	SET MAIN BRG STD	TATA spare parts
252703990102	SET MAIN BRG STD1	TATA spare parts
252703990103	SET MAIN BRG RS1	TATA spare parts
252703990104	SET MAIN BRG RS2	TATA spare parts
252703990105	SET MAIN BRG RS3	TATA spare parts
252703990106	SET MAIN BRG RS4	TATA spare parts
252703990107	SET OF PISTON RINGS-STD (GOTZE)	TATA spare parts
252703990108	SET PISTON RINGS STD	TATA spare parts
252703990109	SET PISTON W/PIN & RINGS STD-96.90(NPR)	TATA spare parts
252703990110	SET PISTON W/RINGS STD	TATA spare parts
252703990113	SET MAIN BRG W/O THW STD	TATA spare parts
252703990114	SET MAIN BRG SHELL UPPER & LOWER NORMAL I	TATA spare parts
252703990115	SET M.BRG.HALF U/L.R/S.1	TATA spare parts
252703990132	BARE PISTON SET STD	TATA spare parts
252703990134	SET OF BARE PISTON 497 TC CMVR EURO 2 N	TATA spare parts
252703990163	SET-CON.ROD BUSH(R/S-II)	TATA spare parts
252703990166	SET OF BARE PISTON 497TC BS:III	TATA spare parts
252703990167	SET BARE PISTON 497 BSII	TATA spare parts
252703990169	BARE PISTON SET 497 BS2/3	TATA spare parts
252703990171	SET PISTON RING 497 BS 2	TATA spare parts
252703990172	SET PISTON 497 TC BSIII	TATA spare parts
252703990173	SET OF PISTON RINGS 497TC BSIII	TATA spare parts
252703990176	SET-PISTON RING (497 CR) BS3/4	TATA spare parts
252703990178	SET-PISTON WITH PIN & CIRCLIPS - 497	TATA spare parts
252703990179	SET-PISTON RINGS - 497 NA CNG BS3/4	TATA spare parts
252703990195	SET-PISTON WITH PIN & CIRCLIP BS3/4	TATA spare parts
252703990219	SET-PISTON WITH PIN & CIRCLIPS	TATA spare parts

252703990220	SET-PISTON RINGS	TATA spare parts
252703990224	SET THRUST WASHER (NORMAL /NORMAL I) TA	TATA spare parts
252703990229	SET OF BARE PISTONS	TATA spare parts
252703990233	SET OF BARE PISTONS	TATA spare parts
252703990234	SET MAIN BEARING 497 BS III REP-I	TATA spare parts
252703990235	SET MAIN BEARING 497 BS III REP-II	TATA spare parts
252703990236	SET MAIN BEARING 497 BS III REP-III	TATA spare parts
252703990237	SET MAIN BEARING 497 BS III REP-IV	TATA spare parts
252703990239	SET-PISTON ASSY WITH PIN & CIRCLIP	TATA spare parts
252703990240	SET-PISTON RING	TATA spare parts
252703990260	KIT-PISTON RINGS BS6	TATA spare parts
252703990261	KIT-BAREPISTON BS6	TATA spare parts
252703990265	KIT-PISTON RINGS BS6	TATA spare parts
252703990266	PISTON ASSY WITH PIN & CIRCLIP BS6	TATA spare parts
252703990271	SET-BEARING CONNECTINGROD BS6	TATA spare parts
252705100103	CAMSHAFT STD	TATA spare parts
252705100104	ASSY CAM SHAFT W/PIN	TATA spare parts
252705100105	ASSY.CAMSHAFT NORMAL WIT	TATA spare parts
252705100108	ASSY. CAMSHAFT W/PIN STD BS2/3	TATA spare parts
252705100110	ASSY CAMSHAFT W' CYL PIN:NORMAL 94D AC	TATA spare parts
252705100112	ASSY. CAMSHAFT W/CYL. PIN-NORMAL BS2/3/4	TATA spare parts
252705107908	CAMSHAFT - NORMAL GENSET	TATA spare parts
252705107914	CAMSHAFT NORMAL	TATA spare parts
252705107920	CAMSHAFT (NORMAL)- 3.8 SGI BSIV TCIC	TATA spare parts
252705107922	CAMSHAFT (NORMAL ) GENSET	TATA spare parts
252705110101	GEAR CAMSHAFT	TATA spare parts
252705110102	ASSY CAMSHAFT GEAR	TATA spare parts
252705115401	GEAR CAMSHAFT	TATA spare parts
252705115403	CAM SHAFT GEAR-EURO II	TATA spare parts
252705115404	CAM SHAFT GEAR 497CNG HALL-EFFECT SENSOR	TATA spare parts
252705129001	EXHAUST VALVE	TATA spare parts
252705129002	INTAKE VALVE	TATA spare parts
252705140101	ROCKER ARM SHAFT WITH ARM	TATA spare parts
252705140102	ROCKER ARM SHAFT	TATA spare parts
252705140103	ROCKER ARM SHAFT W/RA	TATA spare parts
252705140104	ROCKER ARM SHAFT W/RA	TATA spare parts
252705140105	ROCKER ARM SHAFT	TATA spare parts
252705140113	ASSY.ROCKER ARM SHAFT WITH ROCKER ARM CO	TATA spare parts
252705147901	ASSY. ROCKER ARM SHAFT	TATA spare parts
252705147902	ROCKER ARM SHAFT	TATA spare parts
252705159901	VALVE STEM SEAL INTAKE	TATA spare parts
252705159902	VALVE STEM SEAL EXHAUST	TATA spare parts
252707100116	ASSY FIP WITH LEVER/EX60 675 TYPE	TATA spare parts
252707100118	ASSY FIP 658 TYPE FOR LPT709/509	TATA spare parts
252707100120	F I PUMP SFC 709	TATA spare parts
252707100127	ASSY FIP	TATA spare parts
252707100141	F I PUMP W/LEVER	TATA spare parts



252707100153	ASSY FIP 081 TYPE FOR LP709 SCAM	TATA spare parts
252707100157	ASSY.FUEL INJECTION PUMP	TATA spare parts
252707100159	ASSY.FUEL INJECTION PUMP	TATA spare parts
252707100171	ASSY FIP WITH LEVER	TATA spare parts
252707100173	ASSY FIP ROTARY	TATA spare parts
252707100175	ASSY F.I.P WITH LEVERS NON S CAM-OFFER	TATA spare parts
252707100176	ASSY F.I.P. WITH LEVERS S CAM OFFER	TATA spare parts
252707100178	ASSY FUEL INJECTION PUMP 50 KVA GENSET	TATA spare parts
252707100182	ASSY FIP	TATA spare parts
252707100184	ASSY FIP WITH LEVER SUPPORT & GEAR-40KV	TATA spare parts
252707100186	ASSY FIP	TATA spare parts
252707100187	ASSY FIP	TATA spare parts
252707100189	ASSY.ELECTRIC FUEL PUMP EURO-II	TATA spare parts
252707100197	ASSY.FIP JD-315 LOADER	TATA spare parts
252707100210	ASSY FUEL INJ PUMP	TATA spare parts
252707100212	ASSY FIP (30KVA)	TATA spare parts
252707100214	ASSY FIP (50 KVA)	TATA spare parts
252707100216	ASSY.FIP (E040161000)-40KVA CPCB GENSET	TATA spare parts
252707100220	ASSY. INJECTION PUMP	TATA spare parts
252707100222	ASSY FIP (35 KVA)	TATA spare parts
252707100243	FUEL INJEICION PUMP (ROTORY) BS3	TATA spare parts
252707100251	ASSY FUEL INJECTION PUMP:709 BS:II EX	TATA spare parts
252707100264	ASSY FIP WITH LEVER-76PS 497	TATA spare parts
252707100265	ASSY FIP WITH LEVER	TATA spare parts
252707100270	ASSY.FIP101PS	TATA spare parts
252707100271	ASSYFIP	TATA spare parts
252707100272	ASSY FIP WITH LEVER SUPPORT & GEAR 101	TATA spare parts
252707100277	ASSY ENGINE STOP SOLENOID 24VDC	TATA spare parts
252707100284	FUEL INJECTION PUMP	TATA spare parts
252707100285	ASSY CNG RAIL (EXTRUDED) WITH INJECTORS	TATA spare parts
252707100286	CNG RAIL (EXTRUDED) SUB ASSEMBLY- 3.8 SG	TATA spare parts
252707100294	ASSY FIP (40 KVA CPCB II)	TATA spare parts
252707100296	ASSY FIP (62.5 KVA-CPCB II)	TATA spare parts
252707100298	ASSY FIP(50KVA CPCB II)	TATA spare parts
252707100299	ASSYFIP(35KVA)	TATA spare parts
252707100327	ASSY FIP BS-III	TATA spare parts
252707100330	CNG RAIL ASSY WITH INJ & SENSOR	TATA spare parts
252707100331	CNG RAIL (EXTRUDED) SUB ASSEMBLY- 3.8 SG	TATA spare parts
252707100333	CNG RAIL ASSY WITH INJECTOR & SENSOR	TATA spare parts
252707103802	BARE CNG RAIL FINISHED (3.8 SGI BSIV)	TATA spare parts
252707109903	BARE CNG RAIL (EXTRUTED)3.8 SGI BSIV	TATA spare parts
252707110101	INJECTION TIMER	TATA spare parts
252707110102	DRIVE GEAR FIP	TATA spare parts
252707110104	INJECTION TIMER ASSY	TATA spare parts
252707110108	ASSY. CNG REGULATOR WITH CONNECTORS (SQT	TATA spare parts
252707110110	ASSY FIP 65HP(60 HZ)	TATA spare parts
252707110112	ASSY FIP 80HP(60 HZ)	TATA spare parts

252707110114	ASSY FIP 96HP(60HZ)	TATA spare parts
252707110115	ASSY. INJECTOR CNG BS4	TATA spare parts
252707115401	DRIVE GEAR FIP	TATA spare parts
252707118701	SPRING TIMER	TATA spare parts
252707119901	TIMER SEGMENT	TATA spare parts
252707119902	SPRING SEAT MALE	TATA spare parts
252707119903	SPRING SEAT FEMALE	TATA spare parts
252707119905	TIMER SEGMENT	TATA spare parts
252707120103	ASSY.BRACKET-FIP MTG.ON CYL.CRANKCASE	TATA spare parts
252707120107	ASSY. FUEL INJECTION PUMP 497CRDI BS3/4	TATA spare parts
252707120113	BRACKET ASSY	TATA spare parts
252707120114	THROTTLE LEVER	TATA spare parts
252707120116	FUEL INJECTION PUMP	TATA spare parts
252707120117	FUEL INJECTION PUMP ASSY	TATA spare parts
252707123701	SUPPORT (FOR FUEL INJECTION PUMP)EURO II	TATA spare parts
252707123702	SUPPORT FOR FUEL INJECTION PUMP :BS-III	TATA spare parts
252707123704	SUPPORT-INJECTION PUMP	TATA spare parts
252707123705	FIP SUPPORT PLATE	TATA spare parts
252707123711	SUPPORT BRACKET FIP	TATA spare parts
252707123713	SUPPORT PLATE (FOR FUEL INJECTION PUMP)	TATA spare parts
252707123715	SUPPORT BRACKET	TATA spare parts
252707125301	GASKET (FOR SUPPORT INJ.PUMP):EURO II	TATA spare parts
252707125302	GASKET (FIP TO SUPPORT )	TATA spare parts
252707125303	GASKET SUPPORT INJECTION PUMP	TATA spare parts
252707125304	GASKET SUPPORT INJECTION PUMP	TATA spare parts
252707125305	GASKET-SUPPORT FIP	TATA spare parts
252707125308	FIP TO SUPPORT FLANGE GASKET	TATA spare parts
252707125309	FIP SUPPORT FLANGE	TATA spare parts
252707125310	GASKET(FIP SUPPORT PLATE TO TGH)	TATA spare parts
252707129203	SPHERICAL WASHER FEMALE	TATA spare parts
252707130104	ASSY.PULL ROD	TATA spare parts
252707130110	VACCUM CYL ENG STOP	TATA spare parts
252707130112	BRACKET ENG STOP CYL	TATA spare parts
252707130114	ASSY VACUUM CYLINDER	TATA spare parts
252707130115	ASSY.BRACKET COMPLETE (ENG.STOP)	TATA spare parts
252707130122	BKT ENGINE STOP	TATA spare parts
252707130129	ASSY BRACKET COMPLETE	TATA spare parts
252707130130	ASSY VACUUM CYLINDER	TATA spare parts
252707130132	ASSY.BRACKET COMPLETE-ENGINE STOP	TATA spare parts
252707130133	ASSY VACUUM CYLINDER	TATA spare parts
252707130134	ASSY CAMSHAFT GEAR AND DRIVE GEAR(FIP)	TATA spare parts
252707133304	BRACKET ENG STOP	TATA spare parts
252707135401	DRIVE GEAR (FIP):EURO II	TATA spare parts
252707135402	INJECTION PUMP GEAR :EURO II	TATA spare parts
252707136701	CLEVIS PIN	TATA spare parts
252707136702	CLEVIS PIN	TATA spare parts
252707137901	PULL ROD	TATA spare parts

252707138206	FUEL STOP LEVER-ON FIP	TATA spare parts
252707138801	STUD (FUEL STOP ARRANGMEN	TATA spare parts
252707140102	CLAMP LOWER	TATA spare parts
252707140103	FUEL LEAKAGE LINE	TATA spare parts
252707140119	SET FUEL PR LINES	TATA spare parts
252707140120	FUEL PRES LINE NO 1	TATA spare parts
252707140121	FUEL PRES LINE NO 2	TATA spare parts
252707140122	FUEL PRESS LINE BENT	TATA spare parts
252707140124	FUEL PR. LINE	TATA spare parts
252707140125	SET FUEL PR LINES	TATA spare parts
252707140135	ASSY FUEL LEAKAGE LINE	TATA spare parts
252707140141	FUEL LINE NO 4	TATA spare parts
252707140149	SET FUEL PRESSURE LINE	TATA spare parts
252707140150	ASSY FUEL PRE LINES BENT CYL NO 1	TATA spare parts
252707140151	ASSY FUEL PRESSURE LINE BENT CYL NO 2	TATA spare parts
252707140152	ASSY FUEL PRE LINE BENT CYL NO 3	TATA spare parts
252707140153	ASSY FUEL PRE LINE BENT CYL NO 4	TATA spare parts
252707140157	SET ASSY FUEL PRESSURE LINES-EURO II	TATA spare parts
252707140169	SET: ASSY FUEL PRESSURE LINES EURO III	TATA spare parts
252707140170	ASSY FUEL PRESSURE LINE BENT CYL:1 BSIII	TATA spare parts
252707140171	ASSY FUEL PRESSURE LINE BENT CYL:2 BSIII	TATA spare parts
252707140172	ASSY FUEL PRESSURE LINE BENT CYL:3 BSIII	TATA spare parts
252707140173	ASSY FUEL PRESSURE LINE BENT CYL:4 BSIII	TATA spare parts
252707140176	SET-FUEL PRESSURE LINE BS3	TATA spare parts
252707140187	ASSY. FUEL RAIL 497CRDI BS3/4	TATA spare parts
252707140188	ASSY.FUEL PRESSURE LINE1(BENT)RAIL T INJ	TATA spare parts
252707140190	ASSY FUEL PRESSURE LINE2(BENT)RAIL T INJ	TATA spare parts
252707140193	SET ASSY HP LINE PUMP	TATA spare parts
252707140194	SET HP LINES WITH CLAMPS (PUMP TO R	TATA spare parts
252707140195	ASSY FUEL PRESSURE LINE-1(BENT) (PUMP CB	TATA spare parts
252707140196	ASSY FUEL PRESSURE LINE-2(BENT) (PUMP CB	TATA spare parts
252707140204	ASSEMBLY BRACKET (HP LINE SUPPO)	TATA spare parts
252707140210	KIT-HP LINES CLAMPS & SUPPORT BKT BS3	TATA spare parts
252707140216	ASSEMBLY BRACKET (HP LINES AND HARNESS S	TATA spare parts
252707140230	KIT-HP LINES 6.35 DIA. 497 B BS2/3	TATA spare parts
252707140245	ASSY CNG LP HOSE-1400MM	TATA spare parts
252707140246	ASSY CNG LP HOSE 9.5 BAR -1100MM (HPR TO	TATA spare parts
252707140251	ASSY CNG LP HOSE 9.5 BAR- 1200MM	TATA spare parts
252707140260	SET HP LINES CLAMP BRACKETS	TATA spare parts
252707140263	ASSY. BRACKET (HP LINE SUPPORT)	TATA spare parts
252707140282	ASSY. BRACKET (SUPPORT LDA LINE)	TATA spare parts
252707140283	LP HOSE ASSY	TATA spare parts
252707140289	HOSE ASSY CNG LP 5/8 -18UNF BOTH ENDS	TATA spare parts
252707140306	LP HOSE ASSY BS6	TATA spare parts
252707140338	SET-HP LINE ASSY	TATA spare parts
252707140339	HP PIPE ASSY RAIL TO INJECTOR	TATA spare parts
252707140340	HP PIPE ASSY RAIL TO INJECTOR	TATA spare parts

252707140341	HP PIPE ASSY RAIL TO INJECTOR	TATA spare parts
252707140342	HP PIPE ASSY RAIL TO INJECTOR	TATA spare parts
252707140343	SUPPORT BRACKET ASSY HP LINES	TATA spare parts
252707140344	SUPPORT BRACKET ASSY HP LINES	TATA spare parts
252707140355	HP PIPE ASSY WITH CLAMPS	TATA spare parts
252707140375	COMMON RAIL ASSY	TATA spare parts
252707140376	FUEL PR PIPE ASSY RAIL TO INJECTOR	TATA spare parts
252707140377	FUEL PR PIPE ASSY	TATA spare parts
252707140383	FUEL PR PIPE ASSY RAIL TO INJECTOR	TATA spare parts
252707140384	FUEL PR PIPE ASSY RAIL TO INJECTOR	TATA spare parts
252707140385	FUEL PR PIPE ASSY RAIL TO INJECTOR	TATA spare parts
252707140387	LP HOSE ASSY BS6	TATA spare parts
252707140388	LP HOSE ASSY BS6-PH2	TATA spare parts
252707140391	LP HOSE ASSY BS6	TATA spare parts
252707140392	LP HOSE ASSY-OFFER DRG BS6	TATA spare parts
252707140394	LP HOSE ASSY BS6	TATA spare parts
252707143305	BRACKET(HP LINE SUPPORT) (MTG ON EGR COO	TATA spare parts
252707143306	BRACKET (HP LINE SUPPORT-NPSTG) (MTG ON	TATA spare parts
252707143307	BRACKET (HP LINE SUPPORT) (MTG ON PSTG M	TATA spare parts
252707143312	SUPPORT BRACKET (FOR HP LINES)	TATA spare parts
252707143701	BRACKET(HP LINE SUPPORT) (MTG ON CYL HEA	TATA spare parts
252707143702	SUPPORT BRACKET	TATA spare parts
252707144203	WASHER	TATA spare parts
252707146907	HOSE (REDUCER FOR LEAKOFF):L=300MM	TATA spare parts
252707146909	HOSE (REDUCER FOR LEAKOFF)L=350MM	TATA spare parts
252707147501	RUBBER PIECE	TATA spare parts
252707147503	ISOLATOR PLASTIC (FOR HP LINES)	TATA spare parts
252707147506	ISOLATORCLAMP(HPLINE)(M/SIAI)	TATA spare parts
252707148201	PIPE CLAMP UPPER	TATA spare parts
252707148202	CLAMPING PIECE LOWER	TATA spare parts
252707148204	CLAMP	TATA spare parts
252707148205	BRACKET(FOR OVERFLOW LINE)	TATA spare parts
252707148206	BRACKET	TATA spare parts
252707148207	BRACKET	TATA spare parts
252707150111	LP HOSE ASSY BS6-PH2	TATA spare parts
252707157101	PLATE (SUPPORT COLDSTART PILOT MTG)	TATA spare parts
252709110103	DOUBLE FUEL FILTER	TATA spare parts
252709110104	FUEL FILTER STAGE1	TATA spare parts
252709110105	FUEL FILTER STAGE2	TATA spare parts
252709110106	ASSY FUEL FILTER	TATA spare parts
252709110111	ASSY FUEL FILTER	TATA spare parts
252709110112	DOUBLE FUEL FILTER	TATA spare parts
252709110116	FUEL WATER SEPARATOR SPINON	TATA spare parts
252709110120	ASSY FUEL FILTER	TATA spare parts
252709110121	ASSY FUEL FILTER HEAD	TATA spare parts
252709110122	ASSY FUEL LINE (FEED PUMP TO FUEL FILTER	TATA spare parts
252709110123	ASSY FUEL LINE (FUEL FILTER TO FIP)	TATA spare parts

252709110124	ASSY FUEL FILTER	TATA spare parts
252709110126	ASSY. FUEL FILTER W/QUICK FIX CONN BS3/4	TATA spare parts
252709110136	PROTECT FILTER (BOSCH) BS3/4	TATA spare parts
252709110138	ASSY. MAIN FILTER BS3/4	TATA spare parts
252709110142	ASSY. FUEL FILTER MAIN 12V BS3/4	TATA spare parts
252709110148	FUEL FILTER ASSY WITH WIF SENSOR	TATA spare parts
252709110149	FUEL PRE FILTER ASSY	TATA spare parts
252709110151	FUEL FILTER ELEMENT ASSY	TATA spare parts
252709113201	PIPE UNION BOLT	TATA spare parts
252709113703	BRACKET F/FILTER & GSL	TATA spare parts
252709113704	BRACKET FUEL FILTER	TATA spare parts
252709113708	BRACKET (FUEL FILTER MTG):SFC712 BS:III	TATA spare parts
252709113709	BRACKET (FUEL FILTER MTG) LP/LPT 497 BS-	TATA spare parts
252709113710	BRACKET FUEL FILTER MTG	TATA spare parts
252709113713	FUEL FILTER MOUNTING BRACKET	TATA spare parts
252709113714	BRACKET (FUEL FILTER MTG)	TATA spare parts
252709116101	LOCK PLATE F/FILTER BKT	TATA spare parts
252709118001	AIR VENT SCREW	TATA spare parts
252709119902	FUEL FILTER ELEMENT BS3/4	TATA spare parts
252709119903	WATER LEVEL SENSOR	TATA spare parts
252709119904	TEMPERATURE SENSOR	TATA spare parts
252709119910	FILTER HEAD ASSEMBLY	TATA spare parts
252709119911	WATER LEVEL SENSOR BS3/4	TATA spare parts
252709119912	TEMPERATURE SENSOR	TATA spare parts
252709119913	FILTER ELEMENT -PROTECT FILTER BS1- 4	TATA spare parts
252709119916	PIGTAIL ASSY 24V-12 V	TATA spare parts
252709119917	FUEL FILTER ELEMENT ASSY	TATA spare parts
252709119922	FUEL FILTER ELEMENT ASSY	TATA spare parts
252709120113	FUEL LINE FILTER TO FIP	TATA spare parts
252709120114	FUEL LINE FEEDPUMP-FILTER	TATA spare parts
252709120115	OVER FLOW LINE COMBINED	TATA spare parts
252709120117	FUEL LINE FILTER TO FIP	TATA spare parts
252709120118	FUEL LINE FEEDPUMP-FILTER	TATA spare parts
252709120124	ASSY.OVER FLOW LINE-COMBINED	TATA spare parts
252709120129	ASSY OVERFLOW LINE (COMBINED)-SFC/LP/LPT	TATA spare parts
252709120133	ASSY FUEL LINE	TATA spare parts
252709120136	ASSY.FUEL LINE FEED PUMP TO FILTER	TATA spare parts
252709120137	ASSY.FUEL LINE FEED PUMP TO FILTER	TATA spare parts
252709120138	ASSY FUEL LINE	TATA spare parts
252709120139	ASSY.FUEL LINE FILTER OUTLET TO FIP	TATA spare parts
252709120140	FUEL LINE FUEL FILTER TO FIP	TATA spare parts
252709120143	FUEL LINE FUEL FILTER TO FIP	TATA spare parts
252709120144	FUEL LINE FUEL FILTER TO FIP	TATA spare parts
252709120147	ASSY FUEL LINE(FILTER-FIP):LP/LPT	TATA spare parts
252709120149	ASSY.OVERFLOW LINE	TATA spare parts
252709120155	ASSY FUEL LINE:EURO II LP/LPT	TATA spare parts
252709120156	ASSY FUEL LINE(FILT TO FI)SFC	TATA spare parts

252709120157	ASSY.OVERFLOW LINE-EURO-II	TATA spare parts
252709120161	ASSY.FUEL LINE(FILTER TO FIP)-LP/LPT	TATA spare parts
252709120163	ASSY FUEL LINE FLTR TO FIP:LP/LPT BSIII	TATA spare parts
252709120164	ASSY FUEL LINE (FLTR TO FIP)	TATA spare parts
252709120166	ASSY FUEL LINE (FILTER TO FIP):LP1512	TATA spare parts
252709120168	ASSY OVERFLOW LINE:497TCIC BS:III	TATA spare parts
252709120170	ASSY OVERFLOW LINE(FROM FUEL FILTER):BS3	TATA spare parts
252709120171	ASSY.FUEL LINE FILTER TO FIP	TATA spare parts
252709120173	ASSY. COMBINED OVERFLOW LINE (ON F.I.P)	TATA spare parts
252709120174	ASSY. OVERFLOW LINE (FROM FUEL FILTER)	TATA spare parts
252709120175	ASSY FUEL LINE (MECH FEED PUMP)	TATA spare parts
252709120176	ASSY FUEL LINE (FUEL FILTER TO MECH FEED	TATA spare parts
252709120182	ASSY. FUEL WATER SEPARATOR BS3	TATA spare parts
252709120186	ASSY. HEAD (FUEL-WATER SEP) BS2/3	TATA spare parts
252709120203	ASSY. INJECTOR LEAKOFF LINE BS3/4	TATA spare parts
252709120207	ASSY OVERFLOW LINE 497 TCIC BS-III	TATA spare parts
252709120208	ASSY BRACKET WITH WELD NUT	TATA spare parts
252709120211	ASSY OVERFLOW LINE ( FIP TO ACCUMULATOR	TATA spare parts
252709120213	ASSY OVERFLOW LINE ( RAIL TO ACCUMULATOR	TATA spare parts
252709120217	ASSY FUEL LINE (F.PUMP TO FILTER) LP/LPT	TATA spare parts
252709120218	ASSY FUEL LINE (FILTER TO FIP) LP/LPT712	TATA spare parts
252709120230	ASSY OVERFLOW LINE(COMBINED)	TATA spare parts
252709120234	ASSY FUEL-WATER SEPERATOR	TATA spare parts
252709120235	FUEL-WATER SEPERATOR SPIN ON	TATA spare parts
252709120253	ASSY. FUEL FILTER (FWS) AUTO DRAIN BS3	TATA spare parts
252709120254	ASSY. FUEL WATER SEP. (A/D) SPINON BS2/3	TATA spare parts
252709120255	ASSY. AUTODRAIN VALVE BS1/2/3/4	TATA spare parts
252709120258	ASSY. FUEL WATER SEP. (AUTO DRAIN) BS2/3	TATA spare parts
252709120259	FUEL FILTER (FWS) ELEMENT SPINON BS2/3	TATA spare parts
252709120265	ASSY. OVERFLOW LINE	TATA spare parts
252709120266	ASSY SUPPORT FOR FUEL RETURN LINE	TATA spare parts
252709120278	SUPPORT ASSY OVERFLOW LINE ASSY	TATA spare parts
252709120282	CLAMP ASSY WITH SLEEVE	TATA spare parts
252709120289	OVERFLOW PIPE ASSY RAIL TO ACCUMULATOR	TATA spare parts
252709120293	OVERFLOW PIPE ASSY FIP TO ACCUMULATOR	TATA spare parts
252709120294	OVERFLOW PIPE ASSY RAIL TO ACCUMULATOR	TATA spare parts
252709120295	BRACKET FUEL ACCUMULATOR SUPPORT	TATA spare parts
252709120296	FUEL - WATER SEPERATOR SPIN ON	TATA spare parts
252709120297	CATRIDGE - FUEL WATER SEPERATOR - SPINON	TATA spare parts
252709120304	LEAK OFF PIPE ASSY INJECTOR	TATA spare parts
252709120309	FUEL OVERFLOW PIPE ASSY	TATA spare parts
252709120310	LEAK OFF PIPE ASSY INJECTOR	TATA spare parts
252709123302	BRACKET	TATA spare parts
252709123308	SUPPORT OVERFLOW LINE	TATA spare parts
252709123309	BRACKET LEAK OFF PIPE	TATA spare parts
252709124203	CLAMP (FOR OVERFLOW LINE)	TATA spare parts
252709124206	P TYPE CLAMP (FOR OVER FLOW LINE)	TATA spare parts

252709125804	RUB HOSE OVERFLOW LINE	TATA spare parts
252709125805	HOSE-340 MM	TATA spare parts
252709125809	HOSE (FOR ASSY OVER FLOW LINE)	TATA spare parts
252709128201	SUPPORT BRACKET (OVER FLOW LINE)	TATA spare parts
252709129901	BANJO	TATA spare parts
252709129917	HEAT SHIELD BS6-PH2	TATA spare parts
252709130070	KIT AIR INTAKE SYSTEM	TATA spare parts
252709130085	KIT AIR-INTAKE SYST. SFC407 CNG	TATA spare parts
252709130089	KIT AIR-INTAKE SYST LP909 CNGBS4	TATA spare parts
252709130090	KIT AIR-INTAKE SYSTEM	TATA spare parts
252709130109	BRACKET AIR FILTER	TATA spare parts
252709130124	DUCT AIR INLET	TATA spare parts
252709130132	AIR INLET DUCT LHD BUS	TATA spare parts
252709130133	CLAMP A/FILTER PIPE RHD	TATA spare parts
252709130136	ASSY AIR INLET DUCT	TATA spare parts
252709130137	BRACKET TOP INLET DUCT	TATA spare parts
252709130138	BRACKET BOTTOM IN DUCT	TATA spare parts
252709130141	ASSY AIR FILTER	TATA spare parts
252709130143	ELEMENT PRIMARY	TATA spare parts
252709130144	AIR FILTER ELEMENT(SAFETY) 497 Y1 APP	TATA spare parts
252709130162	AIR FILTER ASSY OIL BATH	TATA spare parts
252709130165	BRACKET AIR FILTER	TATA spare parts
252709130167	AIR FILTER ASSY OIL BATH	TATA spare parts
252709130170	AIR FILTER ASSY OIL BATH	TATA spare parts
252709130176	ASSY.AIR FILTER	TATA spare parts
252709130177	BRACKET COMPLETE(AIR FILTER MTG) LPT709	TATA spare parts
252709130184	AIR CLEANER ASSEMBLY	TATA spare parts
252709130185	ASSY. AIR FILTER	TATA spare parts
252709130192	ASSY AIR LINE	TATA spare parts
252709130203	ASSY ADAPTOR	TATA spare parts
252709130210	ASSY BRACKET	TATA spare parts
252709130211	ASSY STRAP	TATA spare parts
252709130214	ASSY AIR FILTR W/O S	TATA spare parts
252709130219	ASSY.PIPE(AIR FILTER TO T	TATA spare parts
252709130221	ASSY.AIR FILTER COMPLETE	TATA spare parts
252709130222	ASSY.PIPE	TATA spare parts
252709130223	ASSY.CLAMP FOR INTAKE PIPE	TATA spare parts
252709130232	ASSY INTAKE PIPE	TATA spare parts
252709130236	ASSY AIR FILTER	TATA spare parts
252709130238	ASSY AIR FILTER-OFFER DRG	TATA spare parts
252709130240	ASSY STRAP	TATA spare parts
252709130246	ASSY AIR FILTER WITH SERVICE INDICATOR	TATA spare parts
252709130247	ASSY AIR FILTER 8 CU	TATA spare parts
252709130248	ASSY FILTER ELEMENT SECONDARY 8M3	TATA spare parts
252709130249	SAFETY CARTRIDGE 8M3	TATA spare parts
252709130253	ASSY AIR FILTER W/O SERVICE INDICATOR	TATA spare parts
252709130254	ASSY AIR FILTER WITH SERVICE INDICATOR	TATA spare parts

252709130255	SAFETY CARTRIDGE 8M3	TATA spare parts
252709130256	ASSY FILTER ELEMENT SECONDARY 8M3	TATA spare parts
252709130260	ASSY.AIR FILTER -8 CUBIC METER	TATA spare parts
252709130266	ASSY. AIR FILTER-8M3 COST RED.	TATA spare parts
252709130268	ASSY.AIR FILTER (8M3)W/DUST VALVE - LHD	TATA spare parts
252709130272	ASSY PIPE(AIR FILTER TO TC):LP/LPT-S CAM	TATA spare parts
252709130273	ASSY AIR INLET DUCT	TATA spare parts
252709130274	ASSY AIR LINE-AIR INTAKE ELBOW TO LDA	TATA spare parts
252709130275	ASSY.AIR FILTER (8M3)- LHD	TATA spare parts
252709130280	ASSY PIPE (AIR FLTR TO TC):SFC S'CAM	TATA spare parts
252709130281	ASSY CLAMP (FOR AIR INTAKE PIPE):LP/LPT	TATA spare parts
252709130282	ASSY AIR INLET DUCT LPT 709 LHD	TATA spare parts
252709130289	ASSY.INTERMEDIATE PIPE(W/O S-CAM)	TATA spare parts
252709130291	ASSY DRYTYPE AIR FILTER 9M3 BSIII	TATA spare parts
252709130292	ASSY HOSE AIR INLET DUCT TO AIR FLTR	TATA spare parts
252709130293	ASSY AIR INLET DUCT :497 TC IC BS:III	TATA spare parts
252709130294	ASSY BRACKET (TOP) FOR AIR INLET DUCT	TATA spare parts
252709130295	ASSY BRACKET BOTTOM FOR AIR INLET DUCT	TATA spare parts
252709130296	AIR INLET PIPE (AIR FILTER END):LP1512	TATA spare parts
252709130298	ASSY DRYTYPE AIR FILTER 9M3 BSIII	TATA spare parts
252709130303	ASSY SAFETY CARTRIDGE 9M3	TATA spare parts
252709130304	ASSY FILTER ELEMENT 9M3	TATA spare parts
252709130308	ASSY AIR FILTER COMPLETE (9M3-SFC)	TATA spare parts
252709130313	OUTLET PIPE BRACKET ASSEMBLY	TATA spare parts
252709130314	ASSY AIR INLET DUCT	TATA spare parts
252709130315	T BOLT TYPE HOSE CLAMP-	TATA spare parts
252709130316	T BOLT TYPE HOSE CLAMP- BS4	TATA spare parts
252709130317	ASSY. AIR CLEANER W/MTG BKT BS/2/4/6	TATA spare parts
252709130319	T BOLT TYPE HOSE CLAMP	TATA spare parts
252709130320	SET:A/F PIPES & HOSES:M/S FLTG:497BS-III	TATA spare parts
252709130321	T BOLT TYPE HOSE CLAMP-TB 52	TATA spare parts
252709130322	T BOLT TYPE HOSE CLAMP-TB 34	TATA spare parts
252709130324	SET A/F PIPES & HOSES 497BS-IIEX	TATA spare parts
252709130329	AIR FILTER ELEMENT-PRIMARY BS2/3/4	TATA spare parts
252709130330	AIR CLEANER ELEMENT(SAFETY) BS2/3/4	TATA spare parts
252709130359	ASSY AIR CLEANER WITH MTG.BKT	TATA spare parts
252709130360	HOSE CLAMP T BOLT BS4	TATA spare parts
252709130361	SET AF PIPE &HOSES	TATA spare parts
252709130375	ASSY. AIR INTAKE SYSTEM	TATA spare parts
252709130379	SET AF PIPE & HOSES	TATA spare parts
252709130384	AIR FILTER ELEMENT PRIMARY	TATA spare parts
252709130386	ASSY. AIR CLEANER WITH BKT	TATA spare parts
252709130388	ASSY. AIR INTAKE SYSTEM	TATA spare parts
252709130398	SET AIR FILTER PIPES & HOSES	TATA spare parts
252709133305	SUPPROT [INLET PIPE-RHD]	TATA spare parts
252709133319	SUPPORT	TATA spare parts
252709133320	SUPPORT (INTAKE PIPE	TATA spare parts



252709133321	ASSY. BRACKET- AIR FILTER MOUNTING	TATA spare parts
252709133325	SUPPORT (FOR AIR INTAKE PIPE)	TATA spare parts
252709133337	BRACKET(AIR FILTER MOUNTING)	TATA spare parts
252709133338	SUPPORT BRACKET (AIR FILTER MOUNTING)	TATA spare parts
252709133339	ASSY. BRACKET ( AIR INTAKE PIPE SUPPORT)	TATA spare parts
252709133348	SUPPORT BRACKET (CLEAN SIDE DUCT) 497 LP	TATA spare parts
252709133353	SUPPORT BRACKET(AIR INTAKE PIPE) LP/LPT	TATA spare parts
252709133354	SUPPORT BRACKET (HMF SENSOR PIPE MTG)	TATA spare parts
252709133355	SUPPORT BRACKET (HMF SENSOR PIPE MTG) LP	TATA spare parts
252709133356	SUPPORT BRACKET(AIR INTAKE PIPE)	TATA spare parts
252709133360	SUPPORT BRACKET (FLEETGAURD) BS6	TATA spare parts
252709133366	SUPPORT BRACKET (CLEAN SIDE DUCT)	TATA spare parts
252709133375	SUPPORT BRACKET (ADAPTOR HFM SENSOR)	TATA spare parts
252709133801	AIR INLET PIPE (TC END):CAST	TATA spare parts
252709133807	CAST ADAPTOR (AIR FLTR TO HFM SENSOR)	TATA spare parts
252709133826	PIPE FILTERTOTC	TATA spare parts
252709134208	MOUNTING BRACKET M/S F.GUARD 497 BS-3N B	TATA spare parts
252709134209	AIR CLEANER MTG. BKT	TATA spare parts
252709134211	SUPPORT BKT (FOR ASSY PIPE)	TATA spare parts
252709134213	PCLAMP/SFLTG497Y1APPLICATION BS6	TATA spare parts
252709134215	P CLAMP M/S FLTG 497 Y1 APPLICATION BS6	TATA spare parts
252709134217	MOUNTING BRACKET (CLAMP) (FLTGD) BS6	TATA spare parts
252709134218	P CLAMP M/S FLTG 497 Y1 APPLICATION BS6-	TATA spare parts
252709134236	CLAMP BS6-PH2	TATA spare parts
252709135803	RUB HOSE A/FILTER TO PIPE	TATA spare parts
252709135806	HOSE ELBOW TO PIPE LPLHD	TATA spare parts
252709135809	HOSE ASSY AIR FILTER TO TC	TATA spare parts
252709135810	HOSE FILTER TO DUCT LP	TATA spare parts
252709135812	HOSE ELBOW TO PIPE LHD	TATA spare parts
252709135813	HOSE A/FILTER TO PIPE LHD	TATA spare parts
252709135817	HOSE ELBOW TO PIPE RHD	TATA spare parts
252709135821	HOSE A/FILTER TO DUCT RHD	TATA spare parts
252709135826	HOSE A/FILTER TO INT PIPE	TATA spare parts
252709135827	HOSE A/FILTER TO IN DUCT	TATA spare parts
252709135828	HOSE A/FILTER TO IN PIPE	TATA spare parts
252709135829	HOSE A/FILTER TO IN DUCT	TATA spare parts
252709135835	HOSE PIPE TO TC	TATA spare parts
252709135836	HOSE AIR FILTER TO PIPE	TATA spare parts
252709135837	HOSE A/FILT TO INLET DUCT	TATA spare parts
252709135841	RUBBER HOSE	TATA spare parts
252709135842	AIR SUCT HOSE	TATA spare parts
252709135844	HOSE (AIR FILTER TO TC PI	TATA spare parts
252709135845	HOSE(SNORKEL TO AIR FILTE	TATA spare parts
252709135846	HOSE TC TO PIPE	TATA spare parts
252709135848	RUBBER HOSE PIPE TO TC	TATA spare parts
252709135849	RUBBER HOSE	TATA spare parts
252709135851	HOSE TAPER	TATA spare parts

252709135857	HOSE-AIR INLET DUCT TO AIR FILTER LP709E	TATA spare parts
252709135858	HOSE (AIR FILTER TO PIPE):LP/LPT	TATA spare parts
252709135859	HOSE-INTAKE PIPE TO TC	TATA spare parts
252709135862	RUBBER HOSE (PIPE TO TC) :SFC	TATA spare parts
252709135863	RUBBER HOSE AIR FILTER TO PIPE	TATA spare parts
252709135865	RUBBER HOSE (AIR FILTER TO PIPE)-SFC	TATA spare parts
252709135866	HOSE (INT.PIPE TO PIPE)	TATA spare parts
252709135867	HOSE (AIR FILTER TO INT.PIPE)	TATA spare parts
252709135869	HOSE AIR INTAKE PIPE TO TC:EURO III	TATA spare parts
252709135873	RUBBER HOSE (AIR INLET PIPE TO TC)	TATA spare parts
252709135874	RUBBER HOSE (A/F PIPE TO TC)	TATA spare parts
252709135876	RUBBER HOSE [PIPE TO TC]SFC709 BS2 EX	TATA spare parts
252709135877	REDUCER ELBOW HOSE	TATA spare parts
252709135878	ELBOW HOSE	TATA spare parts
252709135879	STRAIGHT HOSE BS2/3/4	TATA spare parts
252709135880	REDUCER ELBOW HOSE	TATA spare parts
252709135881	REDUCER ELBOW HOSE	TATA spare parts
252709135884	HOSE 497 BS3 TC	TATA spare parts
252709135887	GASKETFILTERELEMENT BS6	TATA spare parts
252709135888	HOSE (A/I PIPE TO LANDI MIXER) LP909 CNG	TATA spare parts
252709135889	HOSE ( AIR SUPPLY PIPE TO AF)	TATA spare parts
252709136301	RUBBER BUFFER	TATA spare parts
252709136303	RUB BUFFER INL DUCT LHD	TATA spare parts
252709136304	RUBBER SEAL A/FILTER	TATA spare parts
252709136305	GASKET-BODY	TATA spare parts
252709136306	GASKET	TATA spare parts
252709136313	COVER (SNORKEL) 497/4SP MARCOPOLO BUS	TATA spare parts
252709136314	RUBBER BUFFER	TATA spare parts
252709136315	SNORKEL ASSY.	TATA spare parts
252709136318	EJECTOR VOLVE	TATA spare parts
252709136319	DUCT AIR INTAKE	TATA spare parts
252709136322	DUST UNLOADER VALVE	TATA spare parts
252709136914	PIPE A/FILTER - ELBOW RHD	TATA spare parts
252709136918	PIPE A/FILTER TO IN ELBOW	TATA spare parts
252709136922	PIPE AIR INLET TO FILTER	TATA spare parts
252709136935	PIPE	TATA spare parts
252709136938	TUBE (LDA TO FIP)	TATA spare parts
252709136939	PIPE (AIR FILTER TO TC) NON SCAM	TATA spare parts
252709136968	PIPE (THROTTLE BODY TO AIR FILTER)-FLTGD	TATA spare parts
252709136996	PIPE AIR FILTER TO TC	TATA spare parts
252709137702	AIR INLET DUCT-PLASTIC	TATA spare parts
252709137703	ASSY AIR INLET	TATA spare parts
252709137704	AIR INLET DUCT	TATA spare parts
252709137705	AIRINLET DUCT LP709	TATA spare parts
252709137707	RUBBER GASKET	TATA spare parts
252709137802	HOSE	TATA spare parts
252709138244	BRACKET (SERVICE INDICATOR MOUNTING)	TATA spare parts

252709138247	BRACKET SERVICE INDI	TATA spare parts
252709138261	HEAT SHIELD ( FOR INTAKE PIPE )	TATA spare parts
252709139906	CONNECTOR PIPE	TATA spare parts
252709139910	RUBBER BUSH	TATA spare parts
252709139913	CLAMP	TATA spare parts
252709139915	ADAPTER	TATA spare parts
252709139916	BOLT HEX HEAD	TATA spare parts
252709139917	WASHER PLAIN 6 MM	TATA spare parts
252709139920	HEX HEAD BOLT BS6	TATA spare parts
252709140002	KIT AIR-INTAKE SYST LP 909 CNG B	TATA spare parts
252709140003	KIT AIR-INTAKE SYST.FLTGD LP 407 CNG B	TATA spare parts
252709140112	ASSY BRACKET (TOP) FOR AIR INTAKE DUCT.	TATA spare parts
252709140115	SERVICE INDICATOR	TATA spare parts
252709140116	HOSE CLAMP - T BOLT	TATA spare parts
252709140117	HOSE CLAMP - T BOLT	TATA spare parts
252709140118	AIR INTAKE KIT	TATA spare parts
252709140120	KIT-AIR INTAKE SYSTEM BS6	TATA spare parts
252709140124	ASSY AIR CLEANER	TATA spare parts
252709140135	ASSY PIPE WITH CLAMP & BOSS	TATA spare parts
252709140136	ASSY PIPE WITH CLAMP	TATA spare parts
252709140137	PIPE & BRACKET ASSY.	TATA spare parts
252709140138	PIPE & BRACKET ASSY	TATA spare parts
252709140139	PIPE & BRACKET ASSY 2	TATA spare parts
252709140141	PIPE & BRACKET ASSY 3	TATA spare parts
252709140142	PIPE ASSY	TATA spare parts
252709140144	HOSE CLAMP T BOLT	TATA spare parts
252709140145	PIPE & BRACKET ASSY	TATA spare parts
252709140146	ISOLATOR VIBRATION	TATA spare parts
252709140147	ISOLATOR VIBRATION	TATA spare parts
252709140151	AIR INTAKE SYSTEM (497 BS-IV)	TATA spare parts
252709140153	SET AIR INTAKE SYS 9M3 A/F SFC407 FLTG	TATA spare parts
252709140154	PIPE AND BRACKET ASSY	TATA spare parts
252709140155	PIPE (W/O BOSS) & BRACKET ASSY	TATA spare parts
252709140156	PIPE ASSEMBLY WITH BRACKET	TATA spare parts
252709140157	PIPE ASSEMBLY WITH BRACKET	TATA spare parts
252709140166	STRAP & RUBBER ASSY	TATA spare parts
252709140168	ASSY PIPE	TATA spare parts
252709140169	ASSY BRACKET	TATA spare parts
252709140172	KIT AIR-INTAKE SYT.FLTGD LP909 CNG BSIV	TATA spare parts
252709140175	SET AIR INTK SYST LP712 MARCOPOLO	TATA spare parts
252709140176	PIPE AND BRACKET ASSY	TATA spare parts
252709140179	SET AIR FILTER PIPE & HOSES	TATA spare parts
252709140196	ASSY. AIR FILTER MTG BRACKET	TATA spare parts
252709140201	HOSE CLAMP T BOLT	TATA spare parts
252709140202	BRACKET ASSY.	TATA spare parts
252709140203	ASSY AIR INLET DUCT(PLASTIC)	TATA spare parts
252709140208	HOSE CLAMP T BOLT	TATA spare parts

252709140209	ISOLATOR VIBRATION	TATA spare parts
252709140210	PIPE & BRACKET ASSY	TATA spare parts
252709140213	ASSY. BRACKET (DIRTY SIDE DUCT)	TATA spare parts
252709140216	ASSEMBLY PROTECTIVE COVER BS6	TATA spare parts
252709140218	ASSY AIR FILTER MTG. BRACKET LP407 BS6	TATA spare parts
252709140221	BRACKET ASSY	TATA spare parts
252709140222	KIT-AIR INTAKE ASSY FLTGD LP407 CNG BSIV	TATA spare parts
252709140231	T BOLT TYPE HOSE CLAMP	TATA spare parts
252709140242	ASSY AIR CLEANER WITH MTG.BKT	TATA spare parts
252709140253	ASSY AIR LINE (AIR INTAKE ELBOW TO FIP)	TATA spare parts
252709140258	AIR FILTER ELEMENT - PRIMARY BS3/4/6	TATA spare parts
252709140259	AIR FILTER ELEMENT(SAFETY) 497Y1 BS3/4/6	TATA spare parts
252709140261	HOSE CLAMP(T BOLT TYPE) M/S FLTG LPA512	TATA spare parts
252709140270	AIR CLEANER ASSY	TATA spare parts
252709140274	SET AIR INTAKE SYSTEM	TATA spare parts
252709140280	ASSEMBLY PRIMARY ELEMENT 9M3	TATA spare parts
252709140288	ASSY BRACKET AIR FILTER MOUNTING	TATA spare parts
252709140297	KIT & LAYOUT AIR INTAKE	TATA spare parts
252709140307	PIPE ASSY AIR FILTER TO TC	TATA spare parts
252709140318	TUBE ASSY (FIP SIDE)	TATA spare parts
252709140319	BRACKET AIR FILTER MOUNTING	TATA spare parts
252709140320	BRACKET DIRTY SIDE PIPE	TATA spare parts
252709140327	SET-AIR INTAKE SYSTEM HOSE PIPES TEL HON	TATA spare parts
252709140330	KIT-AIR INTAKE ASSY	TATA spare parts
252709140334	ASSLY PIPE & BRACKET	TATA spare parts
252709140336	SNORKEL	TATA spare parts
252709140338	PIPE ASSY POWDER COATED	TATA spare parts
252709140340	SET AIR INTAKE SYSTEM	TATA spare parts
252709140354	BRACKET ASSY AIR FILTER MTG	TATA spare parts
252709140359	PIPEASSY	TATA spare parts
252709140363	AIR FILTER ASSY	TATA spare parts
252709140364	RAIN HOOD SNORKEL	TATA spare parts
252709140367	PIPE ASSY	TATA spare parts
252709140382	AIR FILTER HOUSING ASSY COVER	TATA spare parts
252709140388	KIT-AIR FILTER ASSY	TATA spare parts
252709140389	AIR CLEANER ASSY WITH CARTRIDGE BS6	TATA spare parts
252709140390	AIR CLEANER ASSY	TATA spare parts
252709140391	PIPE ASSY WITH BRACKET	TATA spare parts
252709140393	AIR INTAKE SYSTEM ASSY	TATA spare parts
252709140394	AIR INTAKE PIPE ASSY WITH ADAPTER	TATA spare parts
252709140397	SNORKEL ASSY AIR INTAKE DUCT	TATA spare parts
252709143304	BRACKET ASSY AIR INTAKE DUCT	TATA spare parts
252709143306	BRACKET ASSY AIR INTAKE DUCT	TATA spare parts
252709143307	BRACKET ASSY AIR INTAKE DUCT	TATA spare parts
252709143317	SUPPORT BRACKET HFM SENSOR PIPE MTG	TATA spare parts
252709143318	SUPPORT BRACKET AIR INTAKE PIPE	TATA spare parts
252709143322	SUPPORT BRACKET BS6-PH2	TATA spare parts

252709143325	BRACKET CLEAN SIDE PIPE SUPPORT BS6-PH2	TATA spare parts
252709143327	BRACKET BS6-PH2	TATA spare parts
252709145807	HOSE REDUCER ELBOW	TATA spare parts
252709145808	HOSE INTERMEDIATE	TATA spare parts
252709145809	HOSE (AIR FILTER TO ASSY. PIPE)	TATA spare parts
252709145810	HOSE (AIR FILTER TO SNORKEL PIPE)	TATA spare parts
252709145811	COBRA HOSE (A/F TO ETC)	TATA spare parts
252709145812	HOSE REDUCER ELBOW	TATA spare parts
252709145817	HOSE REDUCER 90 DEG	TATA spare parts
252709145818	HOSE REDUCER HUMP	TATA spare parts
252709145819	HOSE DEGREE	TATA spare parts
252709145820	HOSE REDUCER ELBOW	TATA spare parts
252709145821	HOSE	TATA spare parts
252709145824	HOSE HUMP	TATA spare parts
252709145825	HOSE REDUCER DEGREE	TATA spare parts
252709145826	HOSE	TATA spare parts
252709145827	HOSE ( REDUCER ELBOW )	TATA spare parts
252709145829	REDUCER HOSE	TATA spare parts
252709145830	HOSE	TATA spare parts
252709145831	REDUCER HOSE	TATA spare parts
252709145833	HOSE REDUCER ELBOW	TATA spare parts
252709145835	HOSE REDUCER ELBOW (AF TO INT.PIPE)	TATA spare parts
252709145842	HOSE REDUCER ELBOW WITH HUMP	TATA spare parts
252709145843	HOSE REDUCER ELBOW	TATA spare parts
252709145848	REDUCER HOSE	TATA spare parts
252709145851	HOSE REDUCER ELBOW BS6	TATA spare parts
252709145855	HOSE REDUCER ELBOW	TATA spare parts
252709145856	HOSE REDUCER ELBOW BS6	TATA spare parts
252709145866	HOSE REDUCER (IC PIPE TO ETB)	TATA spare parts
252709145885	HOSE REDUCER ELBOW	TATA spare parts
252709145887	HOSE REDUCER	TATA spare parts
252709145889	HOSE (AIR FILTER TO TC)	TATA spare parts
252709145892	HOSE HUMP	TATA spare parts
252709145893	HOSE REDUCER ELBOW	TATA spare parts
252709145899	HOSE	TATA spare parts
252709146950	PIPE	TATA spare parts
252709146955	PIPE (HMF SENSOR TO TC)	TATA spare parts
252709146989	PIPE ASSY PODWER COATED	TATA spare parts
252709146990	PIPE HFM TO TC	TATA spare parts
252709148201	BRACKET ASSY.	TATA spare parts
252709150113	PIPE ASSY WITH BRACKET	TATA spare parts
252709150130	RESTRICTION INDICATOR PIPE ASSY	TATA spare parts
252709150147	RESTRICTION INDICATOR PIPE ASSY	TATA spare parts
252709150149	BRACKET WITH WELD NUT BS6	TATA spare parts
252709150152	BRACKET ASSY	TATA spare parts
252709150153	BRACKET ASSY	TATA spare parts
252709150174	ADAPTER AIR INTAKE	TATA spare parts

252709150175	AIR FILTER ASSY WITH BRACKET	TATA spare parts
252709150176	BRACKET WITH WELD NUT	TATA spare parts
252709150177	PIPE ASSY WITH CLAMP INTERMEDIATE BS6	TATA spare parts
252709150180	AIR INTAKE SYSTEM ASSY	TATA spare parts
252709150186	PIPE ASSY FILTER TO HFM SENSOR	TATA spare parts
252709150187	PIPE ASSY WITH BRACKET	TATA spare parts
252709150198	KIT-AIR INTAKE SYSTEM	TATA spare parts
252709150203	AIRINTAKESYSTEMASSY	TATA spare parts
252709150204	SET-AIR FILTER WITH BKT PIPE & HOSE	TATA spare parts
252709150211	PIPE ASSY WITH CLAMP	TATA spare parts
252709150221	PIPE ASSY WITH CLAMP	TATA spare parts
252709150222	PIPE ASSY	TATA spare parts
252709150225	PIPEASSYWITHBRACKET	TATA spare parts
252709150234	AIR INTAKE SYSTEM ASSY	TATA spare parts
252709150238	RESTRICTION&INDICATOR&PIPE&ASSY	TATA spare parts
252709150244	SUPPORT BRACKET AIR INTAKE PIPE	TATA spare parts
252709150247	PIPE&ASSY&WITH&ADAPTER	TATA spare parts
252709150248	PIPE&ASSY&WITH&BRACKET	TATA spare parts
252709150250	PIPE ASSY WITH CLAMP	TATA spare parts
252709150252	KIT-AIR INTAKE PIPE & BRACKET ASSY	TATA spare parts
252709150255	KIT-AIR INTAKE SYSTEM	TATA spare parts
252709150257	KIT AIR INTAKE SYSTEM	TATA spare parts
252709150260	KIT-AIR FILTER ASSY	TATA spare parts
252709150261	PIPE ASSY WITH BRACKET	TATA spare parts
252709150279	PIPE ASSY AIR FILTER INTAKE	TATA spare parts
252709150292	PIPE ASSY WITH BRACKET BS6	TATA spare parts
252709150293	KIT-AIR INTAKE ASSY BS6	TATA spare parts
252709150301	BRACKETASSYAIRFILTERMTG BS6	TATA spare parts
252709150302	AIR FILTER ASSY WITH BRACKET	TATA spare parts
252709150308	KIT-AIR FILTER & AIR PRE CLEANER ASSY	TATA spare parts
252709150309	KIT-AIRINTAKESYSTEM BS6	TATA spare parts
252709150310	AIR INTAKE PIPE BS6	TATA spare parts
252709150312	RESTRICTION INDICATOR PIPE ASY BS6	TATA spare parts
252709150313	KIT-AIRINTAKESYSTEMBS6	TATA spare parts
252709150315	PIPE & BRACKET ASY BS6	TATA spare parts
252709150318	PIPE ASSY WITH BRACKET BS6	TATA spare parts
252709150320	KIT-AIR INTAKE ASSY BS6	TATA spare parts
252709150321	AIR CLEANER ASSY WITH MTG BRACKET BS6	TATA spare parts
252709150335	AIR CLEANER ASSY BS6	TATA spare parts
252709150341	PIPE & BRACKET ASY BS6	TATA spare parts
252709150342	KIT AIR INTAKE BS6	TATA spare parts
252709150344	PIPE ASSY WITH BRACKET BS6	TATA spare parts
252709150347	PIPE & BRACKET ASY BS6	TATA spare parts
252709150351	KIT-AIR INTAKE ASSY BS6	TATA spare parts
252709150363	BRACKET ASSY SNORKEL MTG BS6-PH2	TATA spare parts
252709150364	AIR INTAKE SYSTEM-OFFER DRG BS6-PH2	TATA spare parts
252709150376	PIPE ASSY SNORKEL TO AIR FILTER BS6-PH2	TATA spare parts

252709150377	BRACKET ASSY SNORKEL MTG BS6-PH2	TATA spare parts
252709150378	BRACKET ASSY SNORKEL MTG BS6-PH2	TATA spare parts
252709150379	PIPE ASSY AIR FILTER HOSE TO ETB HOSE BS	TATA spare parts
252709150381	PIPE ASSY AIR INTAKE BS6-PH2	TATA spare parts
252709155803	RUBBER HOSE AIR FILTER TO TC PIPE	TATA spare parts
252709155807	RUBBER HOSE AIR INTAKE PIPE TO TC	TATA spare parts
252709155808	REDUCER HOSE	TATA spare parts
252709155811	HOSE	TATA spare parts
252709155813	HOSE	TATA spare parts
252709155815	HOSE&REDUCER&ELBOW	TATA spare parts
252709155816	REDUCER HOSE PIPE TO TC	TATA spare parts
252709155822	HOSEBS6	TATA spare parts
252709155823	HOSE REDUCER FILTER PIPE TO ETB BS6	TATA spare parts
252709155825	HOSE DEGREE BS6	TATA spare parts
252709155826	HOSE REDUCER DEGREE BS6	TATA spare parts
252709155827	HOSE ELBOW BS6	TATA spare parts
252709155835	HOSE BS6	TATA spare parts
252709155841	HOSE REDUCER ELBOW BS6	TATA spare parts
252709155842	BLOWBY HOSE ASSY BS6	TATA spare parts
252709155843	HOSE REDUCER DEGREE BS6	TATA spare parts
252709155850	HOSE REDUCER DEGREE BS6	TATA spare parts
252709155851	HOSE REDUCER DEGREE BS6	TATA spare parts
252709155852	HOSE REDUCER DEGREE BS6	TATA spare parts
252709155859	HOSE REDUCER ELBOW BS6-PH2	TATA spare parts
252709156906	TUBEASSYBS6	TATA spare parts
252709156907	TUBE ASSY UCL TO RADIATOR BS6	TATA spare parts
252709156912	TUBEBS6	TATA spare parts
252709180254	SET-INLET & EXHAUST VALVES BS6-PH2	TATA spare parts
252713100101	OIL LINE AC - OILSUMP SFC	TATA spare parts
252713100102	OIL LINE AC - OILSUMP LPT	TATA spare parts
252713100105	ASSY.OIL-LINE VAC-PUMPSUMP LP40734WBCNGM	TATA spare parts
252713100109	ASSY. CYLINDER HEAD BS2/3/4	TATA spare parts
252713103301	BRACKET PIPE SUPPORT	TATA spare parts
252713103706	SLEEVE CYLINDER STD AC	TATA spare parts
252713103711	CYLINDER SLEEVE BS2	TATA spare parts
252713103712	CYLINDER SLEEVE (DIA 94) NORMAL	TATA spare parts
252713105307	GASKET BLOCK TO AC SLEEVE	TATA spare parts
252713105308	GASKET BLOCK TO AC SLEEVE	TATA spare parts
252713105310	GASKET BLOCK TO AC SLEEVE	TATA spare parts
252713105311	GASKET BLOCK TO AC SLEEVE	TATA spare parts
252713105312	GASKET BLOCK TO AC SLEEVE	TATA spare parts
252713105317	GASKET	TATA spare parts
252713115301	GASKET-A/C	TATA spare parts
252713117101	FLANGE	TATA spare parts
252713130101	TUBE ASSY	TATA spare parts
252713130102	ASSY PIPE 709 SCAM	TATA spare parts
252713130105	ASSY PIPE-AIR COMPRESSOR INLET	TATA spare parts

252713130106	ASSY PIPE	TATA spare parts
252713130108	SET-PIPE COUPLING BODY NUT & FERRULE	TATA spare parts
252713130109	SET-PIPE.COUPLING BODY NUT & FERRULE	TATA spare parts
252713130110	ASSY. PIPE	TATA spare parts
252713130112	SET-PIPE COUPLING BODY NUT & FERRULE	TATA spare parts
252713130113	ASSEMBLY PIPE WITH FERRULE (COMP.IN.)	TATA spare parts
252713130114	ASSY.PIPE WITH FERRULE (AIR COMPRESSOR I	TATA spare parts
252713130116	ASSY PIPE WITH FERRULE (AIR FILTER SIDE)	TATA spare parts
252713130117	ASSY PIPE WITH FERRULE (AIR COMPRESSOR I	TATA spare parts
252713130118	ASSY PIPE (WITH CRIMP HOSE)	TATA spare parts
252713130119	ASSY BRACKET WITH WELD NUT (A/C INLET PI	TATA spare parts
252713130121	ASSY PIPE WITH FERRULE(COMP INLET)	TATA spare parts
252713130122	ASM PIPE (AIR COMPRESSOR INLET)	TATA spare parts
252713130128	ASSEMBLY PIPE (AIR COMPRESSOR INLET)	TATA spare parts
252713130132	ASSY PIPE WITH FERRULE (AIR COMPRESSOR I	TATA spare parts
252713130133	PIPE ASSY WITH FERRULE	TATA spare parts
252713130139	BRACKET ASSY AIR COMPRESSOR PIPE MTG	TATA spare parts
252713130143	ASSY PIPE WITH FERRULE AND COUPLING NUT	TATA spare parts
252713130156	ASSY. P-CLAMP WITH WELD NUT	TATA spare parts
252713130157	ASSY PIPE WITH FURULE (AIR COMPRESSOR IN	TATA spare parts
252713130159	PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
252713130162	PIPE ASSY AIR FILTER TO AIR COMPRESSOR	TATA spare parts
252713130176	PIPE ASSY WITH CAP NUT & FERRULE	TATA spare parts
252713130177	CLAMP AIR COMPRESSOR PIPE	TATA spare parts
252713130179	AIR SUPPLY PIPE ASSY WITH ELBOW	TATA spare parts
252713130185	PIPE ASSY WITH FERRULE & NUT	TATA spare parts
252713130188	PIPE ASSY AIR INTAKE PIPE TO AIR COMP	TATA spare parts
252713130189	AIR SUPPLY PIPE A/F TO AIR COMPRESSOR	TATA spare parts
252713130190	PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
252713130192	BRACKET ASSY AIR COMPRESSOR PIPE MTG	TATA spare parts
252713130194	AIR SUPPLY PIPE ASSY AIR COMPRESSOR	TATA spare parts
252713130195	AIR SUPPLY PIPE A/F TO AIR COMPRESSOR	TATA spare parts
252713133301	BRACKET (AIR COMPRES	TATA spare parts
252713134201	CLAMP (AIR COMPRESSO	TATA spare parts
252713134202	BRACKET (AIR COMPRES	TATA spare parts
252713134206	CLAMP	TATA spare parts
252713134207	CLAMP	TATA spare parts
252713134214	P CLAMP 18 DIA	TATA spare parts
252713134217	CLAMP	TATA spare parts
252713135802	HOSE (COMPRESSOR INLET PIPE)	TATA spare parts
252713135833	HOSE	TATA spare parts
252713136904	PIPE-ELBOW TO A C	TATA spare parts
252713136906	PIPE AIR COMPRESSOR	TATA spare parts
252713136907	PIPE	TATA spare parts
252713136915	PIPE (ELBOW TO AIR C	TATA spare parts
252713136916	PIPE	TATA spare parts
252713136920	PIPE (15 O.D.X1.5 THK CEW1 ANLD IS:3074)	TATA spare parts



252713140101	ASSY.PISTON N-9-NORMAL	TATA spare parts
252713149902	INT.BEVELLED NOSE SCRAPER RING	TATA spare parts
252713990101	SET CON ROD BRG SHELL L/U (A/C) NORMAL	TATA spare parts
252714100104	AIR INTAKE MANIFOLD ASSY	TATA spare parts
252714100105	ASSY AIR INTAKE MANIFOLD	TATA spare parts
252714100108	AIR INTAKE MANIFOLD BS6	TATA spare parts
252714100110	AIR INTAKE MANIFOLD BS6-PH2	TATA spare parts
252714103801	AIR INTAKE MANIFOLD (FRONT ETB)	TATA spare parts
252714103804	AIR INTAKE MANIFOLD - (REAR ETB )	TATA spare parts
252714110104	ASSY INTERMEDIATE PI	TATA spare parts
252714110113	ASSY.BRACKET (MTG.GEAR SHIFT BRACKET)	TATA spare parts
252714110116	ASSY.ADAPTOR-BETWEEN MANIFOLD & THL TC	TATA spare parts
252714110119	SUPPORT	TATA spare parts
252714110125	ASSY.BRACKET (SUPPORT INT.BRACKET)-LPT	TATA spare parts
252714110127	ASSY INT. PIPE (THL) LP709	TATA spare parts
252714110130	ASSY CATCON UMICORE-SES 497CNG BS3 LP909	TATA spare parts
252714110131	ASSY BRACKET TC INTERMEDIATE PIPE BSIII	TATA spare parts
252714110132	ASSY BRACKET (TC INT PIPE)	TATA spare parts
252714110141	ASSY EGR PIPE WITH FLANGE	TATA spare parts
252714110143	ASSY EGR PIPE (FROM MANIFOLD )	TATA spare parts
252714110144	ASSY EGR PIPE (EGR COOLER TO ELBOW)	TATA spare parts
252714110145	ASSY. CATALYTIC CONVERTER 497 CNG BSIV	TATA spare parts
252714110148	ASSY EGR VALVE (12V ELECTRICAL)	TATA spare parts
252714110151	ASSY POC (DIA 174.6X174)	TATA spare parts
252714110152	ASSY DOC (DIA 172X100) (40GM)	TATA spare parts
252714110153	ASSEMBLY EGR COOLER(CAST) WITH VALVE	TATA spare parts
252714110154	ASSY EGR COOLER (FABRICATED) WITH VALVE	TATA spare parts
252714110156	ASSY. AFTER TREATMENT SYSTEM	TATA spare parts
252714110162	ASSY EGR PIPE	TATA spare parts
252714110165	ASSY BRACKET (TC INTERMEDIATE PIPE)	TATA spare parts
252714110184	ASSY GASKET(EXHAUST MANI.497SIDE ENTRY)	TATA spare parts
252714110186	ASSY EGR PIPE WITH SUPPORT	TATA spare parts
252714110188	ASSY EGR PIPE WITH SUPPORT	TATA spare parts
252714110191	ASSY EGR VALVE CPCB II	TATA spare parts
252714110193	PIPE EXHAUST (EX MAN ADAPTOR TO EGR)	TATA spare parts
252714110196	ASSY EGR COOLER WITH VALVE LP1512	TATA spare parts
252714110201	ASSY EGR PIPE	TATA spare parts
252714110202	PIPE ASSY EGR	TATA spare parts
252714110205	ASSY EGR VALVE CPCB-II	TATA spare parts
252714110208	ASSY. EGR COOLER(PDC CAST) W/VALVE BS3/4	TATA spare parts
252714110212	PIPE ASSY WITH FLANGE (EGR VALVE TO IC)	TATA spare parts
252714110226	EGR VALVE ASSY	TATA spare parts
252714110240	CATALYTIC CONVERTOR ASSY	TATA spare parts
252714110253	CATALYTIC CONVERTOR ASSY	TATA spare parts
252714110259	AFTER TREATMENT SYSTEM ASSY	TATA spare parts
252714110260	PARTIAL FLOW FILTER ASSY CERAMIC	TATA spare parts
252714110265	EGR COOLER ASSY WITH EGR VALVE	TATA spare parts

252714110267	DOC ASSY	TATA spare parts
252714110270	ASSY. AFTER TREATMENT SYSTEM BS4	TATA spare parts
252714110275	EGR PIPE ASSY COOLER TO AIR INTAKE ELBOW	TATA spare parts
252714110282	CLOSE COUPLED CATCON ASSY BS6	TATA spare parts
252714110283	CATALYTIC CONVERTER ASSY BS6	TATA spare parts
252714110290	BRACKET ASSY WITH WELD NUT	TATA spare parts
252714110293	BRICK BS6	TATA spare parts
252714110294	BRICK BS6	TATA spare parts
252714110307	EGR COOLER & VALVE ASSY	TATA spare parts
252714110308	EGR PIPE ASSY EGR TO TURBOCHARGER	TATA spare parts
252714110309	CATALYST GPF BS6-PH2	TATA spare parts
252714110310	BRACKET ASSY	TATA spare parts
252714110311	PIPE ASSY EXHAUST	TATA spare parts
252714110320	CATCON ASSY DOC & PFF	TATA spare parts
252714110358	BRACKET ASSY WITH FASTENER BS6-PH2	TATA spare parts
252714110359	BRACKET BS6-PH2	TATA spare parts
252714110364	CATALYTIC CONVERTER ASSY BS6-PH2	TATA spare parts
252714110365	CATALYTIC CONVERTER ASSY BS6-PH2	TATA spare parts
252714111601	ASSY. GASKET (EX. MAN TO TC)	TATA spare parts
252714113312	SUPPORT BRACKET(TC WATER OUTLET)	TATA spare parts
252714113313	SUPPORT BRACKET(TC WATER INLET)	TATA spare parts
252714113321	SUPPORT BRACKET BS6	TATA spare parts
252714113322	SUPPORT BRACKET BS6	TATA spare parts
252714113413	EXHAUST MANIFOLD	TATA spare parts
252714113701	EGR MOUNTING BRACKET	TATA spare parts
252714113703	EGR CAST PIPE(EGR PIPE TO EGR VALVE)	TATA spare parts
252714113705	EXHAUST MANIFOLD	TATA spare parts
252714113707	EXHAUST MANIFOLD LHD	TATA spare parts
252714113710	INTERMEDIATE PIPE	TATA spare parts
252714113711	EXHAUST MANIFOLD BS2/3	TATA spare parts
252714113713	EXHAUST MANIFOLD	TATA spare parts
252714113717	INTERMEDIATE PIPE (CAST)- TC TO EXH.PIPE	TATA spare parts
252714113720	INTERMEDIATE PIPE CAST TC TO EXH PIPE	TATA spare parts
252714113722	EXHAUST MANIFOLD	TATA spare parts
252714113723	INTERMEDIATE PIPE (CAST) SFC712 BS III	TATA spare parts
252714113727	EXHAUST MANIFOLD	TATA spare parts
252714113728	EXHAUST MANIFOLD (497 BS-IV)	TATA spare parts
252714113730	EXHAUST MANIFOLD	TATA spare parts
252714113731	INTERMEDIATE PIPE	TATA spare parts
252714113732	INTERMEDIATE PIPE(CAST)TC TO EXH PIPE	TATA spare parts
252714113738	EGR CAST PIPE (EGR PIPE TO EGR VALVE)	TATA spare parts
252714113739	EGR CAST PIPE ( COOLER TO PIPE)	TATA spare parts
252714113740	EXHAUST MANIFOLD	TATA spare parts
252714113742	EGR MOUNTING BRACKET	TATA spare parts
252714113752	EXHAUST MANIFOLD	TATA spare parts
252714113753	EGR CAST PIPE(COOLER TO EGR PIPE)	TATA spare parts
252714113754	EXHAUST MANIFOLD	TATA spare parts

252714113758	BRACKET EGR COOLER MOUNTING	TATA spare parts
252714113760	ADAPTER (EX MAN TO EGR PIPE)	TATA spare parts
252714113761	EXHAUST MANIFOLD (TC)	TATA spare parts
252714113762	INTERMEDIATE PIPE (TC TO EXH PIPE)	TATA spare parts
252714113766	EXHAUST MANIFOLD	TATA spare parts
252714113767	EXHAUST MANIFOLD	TATA spare parts
252714113768	BRACKET EGR & RAIL MTG	TATA spare parts
252714113769	EGR CAST PIPE EGR PIPE TO EGR VALVE	TATA spare parts
252714113770	EXHAUST MANIFOLD	TATA spare parts
252714113771	PIPE INTERMEDIATE	TATA spare parts
252714113772	PIPE INTERMEDIATE	TATA spare parts
252714113774	PIPE INTERMEDIATE BS6	TATA spare parts
252714113775	PIPE INTERMEDIATE BS6	TATA spare parts
252714113776	PIPE INTERMEDIATEBS6	TATA spare parts
252714113778	PIPE INTERMEDIATE BS6	TATA spare parts
252714113780	PIPE INTERMEDIATE BS6	TATA spare parts
252714114201	CLAMP OUTER	TATA spare parts
252714114202	CLAMP SIDE	TATA spare parts
252714115303	GASKET TC TO INTERME PIPE	TATA spare parts
252714115304	GASKET INT PIPE	TATA spare parts
252714115306	GASKET TC TO EXH MANIFOLD	TATA spare parts
252714115307	GASKET EXHAUST MANIFOLD	TATA spare parts
252714115308	GASKET TC TO INT.PIPE	TATA spare parts
252714115309	GASKET-ADAPTOR TO TC	TATA spare parts
252714115313	GASKET-TC TO EXH.ELBOW	TATA spare parts
252714115317	GASKET-EGR VALVE	TATA spare parts
252714115318	EXHAUST STEEL GASKET	TATA spare parts
252714115320	GASKET (FOR EGR ELBOW)	TATA spare parts
252714115326	GASKET (TC TO ADAPTER)	TATA spare parts
252714115333	GASKET TC TO INTERMEDIATE PIPE	TATA spare parts
252714115334	GASKET TC TO INTERMEDIATE PIPE	TATA spare parts
252714115804	HOSE (AIR IN PIPE TO VAC MODULATOR)	TATA spare parts
252714117102	EGR FLANGE	TATA spare parts
252714118203	SUPPORT-INTERMEDIATE PIPE	TATA spare parts
252714118206	HEAT SHIELD (FOR EXHAUST MANIFOLD)	TATA spare parts
252714118207	SUPPORT BRACKET (TC-INTERMEDIATE PIPE)	TATA spare parts
252714118208	SUPPORT BRACKET (TC-INTERMEDIATE PIPE)	TATA spare parts
252714118212	HEAT SHIELD EXHAUST MANIFOLD	TATA spare parts
252714118216	SUPPORT BRACKET INTERMEDIATE PIPE	TATA spare parts
252714118218	HEAT SHIELD	TATA spare parts
252714118220	HEAT SHIELD BS6	TATA spare parts
252714118224	HEAT SHIELD BS6-PH2	TATA spare parts
252714118803	STUD EGR COOLER	TATA spare parts
252714118804	STUD SPECIAL(TURBOCHARGER MTG)	TATA spare parts
252714118806	STUD SPECIAL(TURBOCHARGER MTG) BS6	TATA spare parts
252714119904	MAGNETIC PICKUP (DUAL COIL)	TATA spare parts
252714119915	THERMAL INSULATION	TATA spare parts

252714130103	ASSY. HEAT SHIELD- STARTER	TATA spare parts
252714130108	ASSY HEAT SHIELD(STA	TATA spare parts
252714130109	ASSY.HEAT SHIELD	TATA spare parts
252714130110	ASSY HEAT SHIELD):HIGH TORQUE	TATA spare parts
252714130118	ASSY. HEAT SHIELD (FOR TC)	TATA spare parts
252714138207	HEAT-SHIELD EXH-MANIFOLD 497 CNG LANDI	TATA spare parts
252714138213	HEAT SHIELD (FOR EXHAUST MANIFOLD)	TATA spare parts
252714138215	HEAT SHIELD EXHAUST MANIFOLD	TATA spare parts
252714138217	HEAT SHIELD EXHAUST MANIFOLD	TATA spare parts
252714138226	"HEAT SHIELD,EXHAUST MANIFOLD"	TATA spare parts
252714510104	ASSY.TURBOCHARGER (K16)	TATA spare parts
252714510106	TURBO CHARGER	TATA spare parts
252714510107	ASSY TURBOCHARGER-OFFER DRG	TATA spare parts
252714510108	ASSY. TURBOCHARGER 50KVA	TATA spare parts
252714510109	ASSY.TURBOCHARGER-62.5KVA GENSET	TATA spare parts
252714510111	ASSY. TURBOCHARGER HIGH TORQUE BS2/3	TATA spare parts
252714510114	TURBO CHARGER FOR HIGH TORQUE ENGINES	TATA spare parts
252714510116	ASSY.TURBOCHARGER	TATA spare parts
252714510117	ASSY.TURBOCHARGER CPCB GENSET	TATA spare parts
252714510119	ASSY TURBOCHARGER :SFC709EX	TATA spare parts
252714510120	ASSY. TURBOCHARGER BS3	TATA spare parts
252714510121	ASSY.TURBOCHARGER-CPCB 40/45/50KVA	TATA spare parts
252714510124	ASSY TURBOCHARGER LP/LPT BS:II EX	TATA spare parts
252714510125	ASSY. TURBOCHARGER :SFC 712 BS:III	TATA spare parts
252714510127	ASSY TURBOCHARGER(LPT BS:II EX	TATA spare parts
252714510129	ASSY TURBOCHARGER(SFC709 BS:II	TATA spare parts
252714510136	ASSY TURBOCHARGER:LP/LPT BS3	TATA spare parts
252714510137	ASSY TURBOCHARGER SFC 497 BS3	TATA spare parts
252714510138	ASSY. TURBOCHARGER 497CRDI BS3/4	TATA spare parts
252714510139	ASSY TURBOCHARGER	TATA spare parts
252714510142	ASSY. TURBOCHARGER BS3	TATA spare parts
252714510143	ASSY TURBOCHARGER 497 SFC BS	TATA spare parts
252714510148	ASSY TURBOCHARGER	TATA spare parts
252714510150	ASSY. TURBOCHARGER	TATA spare parts
252714510156	ASSY TURBOCHARGER	TATA spare parts
252714510163	ASSY.TURBOCHARGER-CPCB II GENSET	TATA spare parts
252714510165	ASSY. TURBOCHARGER W/ADAPTER BS3	TATA spare parts
252714510175	ASSY. TURBOCHARGER LP BS3/4	TATA spare parts
252714510178	TURBOCHARGER ASSY	TATA spare parts
252714510182	TURBOCHARGER	TATA spare parts
252714510184	TURBOCHARGER ASSY BS6-PH2	TATA spare parts
252714519901	VEE BAND CLAMP:EURO III	TATA spare parts
252714519902	VEE BAND CLAMP (497 BS-IV)	TATA spare parts
252714600102	ASSY CLAMP(FOR PIPE:TC TO IC):LPT709TCIC	TATA spare parts
252714600107	ASSY.INTERCOOLER	TATA spare parts
252714600108	ASSY CLAMP-FOR PIPE IC TO AIR IN ELBOW	TATA spare parts
252714600109	ASSY INTERCOOLER SFC709EX HT	TATA spare parts

252714600112	ASSY ADAPTOR WITH PIPE TEL TC:497 BSIII	TATA spare parts
252714600113	ASSY PIPE TC TO IC:LP709 BSIII	TATA spare parts
252714600114	ASSY SUPPORT:FOR PIPE IC TO AIR INTAKE	TATA spare parts
252714600115	ASSY PIPE (IC TO AIR INTAKE ELBOW)	TATA spare parts
252714600116	ASSY PIPE (IC TO AIR INTAKE ELBOW)	TATA spare parts
252714600117	ASSY PIPE WITH CLAMP HOSE TC OUT TO IC	TATA spare parts
252714600118	ASSY PIPE IC TO AIR INTAKE ELBOW:LPT	TATA spare parts
252714600119	INTERCOOLER LP/LPT BS-III	TATA spare parts
252714600134	ASSY ADAPTOR WITH PIPE	TATA spare parts
252714600137	ASSY INTERCOOLER LP/LPT BSIIEX	TATA spare parts
252714600138	PIPE	TATA spare parts
252714600139	PIPE	TATA spare parts
252714600140	ASSY INTERCOOLER LPT BS:IIEX	TATA spare parts
252714600141	ASSY PIPE (TC TO IC):LPT 1113 BS:III	TATA spare parts
252714600143	ASSY PIPE (IC TO AIR INTAKE):LPT1113 BS3	TATA spare parts
252714600144	ASSY ADAPTER PIPE W CLAMP(TC TO IC):SFC	TATA spare parts
252714600146	ASSY PIPE(IC TO AIR IN ELBOW):SFC712 BS3	TATA spare parts
252714600148	ASSY. INTERCOOLER (SFC:712) BS3	TATA spare parts
252714600166	ASSY INTERCOOLER LPT709 BS-II	TATA spare parts
252714600170	ASSY. PIPE (TC TO IC)	TATA spare parts
252714600175	ASSY PIPE WITH ADAPTOR(TEL TC) 497BS3N	TATA spare parts
252714600179	INTERCOOLER:LPT709 BSIIEX BS2/3/4	TATA spare parts
252714600185	ASSY PIPE (HOSE TO ELBOW)	TATA spare parts
252714600188	ASSY PIPE ( TC TO IC)	TATA spare parts
252714600189	ASSY PIPE (IC TO AIR INTAKE ELBOW)	TATA spare parts
252714600190	ASSY INTERCOOLER BS-IV	TATA spare parts
252714600191	ASSY INTERCOOLER	TATA spare parts
252714600193	ASSY PIPE (INTERCOOLER TO HOSE )	TATA spare parts
252714600194	ASSY INTERCOOLER	TATA spare parts
252714600201	ASSY. INTERCOOLER BS3	TATA spare parts
252714600202	ASSY INTERCOOLER (VAVE)	TATA spare parts
252714600203	ASSY INTERCOOLER Y1 LPO BUS	TATA spare parts
252714600233	ASSY PIPE (HOSE TO ELBOW)	TATA spare parts
252714600239	ASSY PIPE (IC TO AIR INTAKE ELBOW)	TATA spare parts
252714600245	PIPE ASSY TC TO IC	TATA spare parts
252714600268	INTERCOOLER ASSY VAVE	TATA spare parts
252714600272	BRACKET ASSY WITH NUT	TATA spare parts
252714600274	BRACKET ASSY IC PIPE MTG	TATA spare parts
252714600276	BRACKET ASSY IC PIPE MTG	TATA spare parts
252714600280	BRACKET ASSY IC PIPE MTG	TATA spare parts
252714600284	SUPPORT BRACKET ASSY PIPE TC TO IC	TATA spare parts
252714600285	PIPE ASSY TC HOSE TO IC INTAKE HOSE	TATA spare parts
252714600293	PIPE ASSY TC TO INTERCOOLER	TATA spare parts
252714600294	BRACKET ASSY IC PIPE MTG	TATA spare parts
252714600295	INTERCOOLER	TATA spare parts
252714600296	INTERCOOLER ASSY	TATA spare parts
252714600301	PIPE TURBOCHARGER TO INTERCOOLERBS6	TATA spare parts

252714600303	INTERCOOLER BS6	TATA spare parts
252714600304	PIPE TC TO IC BS6	TATA spare parts
252714600308	PIPE ASSY	TATA spare parts
252714600312	INTERCOOLER ASSY	TATA spare parts
252714600316	PIPE TURBOCHARGER TO INTERCOOLER BS6	TATA spare parts
252714600317	INTERCOOLER BS6	TATA spare parts
252714600320	PIPE TC TO IC BS6-PH2	TATA spare parts
252714603301	SUPPORT FOR PIPE TC TO IC:LP709 BSIII	TATA spare parts
252714603302	SUPPORT FOR FILL PIPE & IC PIPE	TATA spare parts
252714603305	SUPPORT (FOR PIPE TC TO IC)	TATA spare parts
252714603306	SUPPORT(FOR FILL PIPE & IC PIPE):BS-III	TATA spare parts
252714603318	SUPPORT BRACKET IC TO AIR INTAKE PIPE	TATA spare parts
252714603321	SUPPORT BRACKET (CLEAN SIDE DUCT)	TATA spare parts
252714603322	SUPPORT BRACKET FOR AIR INTAKE ELBOW PIP	TATA spare parts
252714603325	SUPPORT BRACKET (TC TO IC PIPE)	TATA spare parts
252714603326	SUPPORT BRACKET IC TO AIR INTAKE PIPE	TATA spare parts
252714603331	BRACKET INTERCOOLER PIPE SUPPORT	TATA spare parts
252714603332	SUPPORT (FOR PIPE)ON CAB MTG BKT	TATA spare parts
252714603334	BRACKET AIR INTAKE PIPE MTG	TATA spare parts
252714603335	SUPPORT BRACKET	TATA spare parts
252714603338	BRACKET IC PIPE MTG	TATA spare parts
252714603344	SUPPORT BRACKET INTERCOOLER PIPE	TATA spare parts
252714603346	SUPPORT BRACKET	TATA spare parts
252714603347	SUPPORT BRACKET	TATA spare parts
252714603353	SUPPORTBRACKETBS6	TATA spare parts
252714603355	SUPPORT BRACKET BS6	TATA spare parts
252714603801	PIPE CAST (TC TO IC)	TATA spare parts
252714603802	PIPE CAST (IC TO AIR INTAKE ELBOW)	TATA spare parts
252714603804	PIPE- TURBOCHARGER TO INTERCOOLER	TATA spare parts
252714603805	ADAPTOR (TC END)	TATA spare parts
252714603806	DUCT (I.C TO AIR INTAKE ELBOW) 497	TATA spare parts
252714603810	PIPE ( TC TO IC )	TATA spare parts
252714603811	PIPE (IC TO AIR INTAKE ELBOW)	TATA spare parts
252714603812	ADAPTOR (TC END)	TATA spare parts
252714603815	ELBOW (TC COMPRESSOR OUTLET)	TATA spare parts
252714603817	ELBOW (TC COMPRESSOR OUTLET)	TATA spare parts
252714603818	DUCT (I.C TO AIR INTAKE ELBOW)	TATA spare parts
252714603820	PIPE INTERCOOLER TO AIR INTAKE	TATA spare parts
252714603834	PIPE CAST (TC TO IC)	TATA spare parts
252714603835	AIR INTAKE PIPE (TC TO IC)	TATA spare parts
252714603837	CAST PIPE TC TO IC	TATA spare parts
252714603838	CAST PIPE (TC TO IC)	TATA spare parts
252714603840	CAST PIPE (TC TO IC)	TATA spare parts
252714603848	ADAPTER (EGR COOLER TO EGR VALVE)	TATA spare parts
252714603852	ELBOW (TC COMPRESSOR OUTLET)	TATA spare parts
252714603853	PIPE INTERCOOLER TO AIR INTAKE ELBOW	TATA spare parts
252714603856	ELBOW CAST TC COMPRESSOR OUTLET	TATA spare parts

252714603857	PIPE TC TO INTERCOOLER	TATA spare parts
252714603858	PIPE TC TO INTERCOOLER	TATA spare parts
252714603859	ADAPTER TC COMPRESSOR OUTLET	TATA spare parts
252714603860	ADAPTER TC COMPRESSOR OUTLET	TATA spare parts
252714603861	ADAPTER TC COMPRESSOR OUTLET	TATA spare parts
252714603864	ELBOW BS6	TATA spare parts
252714603865	ELBOW BS6	TATA spare parts
252714603866	ELBOW BS6-PH2	TATA spare parts
252714604201	TYPE CLAMP:497 TCIC BS-III	TATA spare parts
252714604202	P TYPE CLAMP:497 TCIC BS-III	TATA spare parts
252714604209	P CLAMP (TC TO IC PIPE)	TATA spare parts
252714604211	P-CLAMP INTERCOOLER OUTLET HOSE	TATA spare parts
252714604212	P TYPE CLAMP	TATA spare parts
252714604214	P TYPE CLAMP (497 Y1 LPT)	TATA spare parts
252714604219	P TYPE CLAMP	TATA spare parts
252714604223	P TYPE CLAMP	TATA spare parts
252714604231	CLAMP INTERCOOLER PIPE	TATA spare parts
252714604232	CLAMP INTERCOOLER PIPE	TATA spare parts
252714605803	HOSE (TC OUTLET):LPT 709 TC/IC	TATA spare parts
252714605804	HOSE (INT COOLER TO PIPE):SFC709EX	TATA spare parts
252714605808	HUMP HOSE-LP/LPT709 TC IC HIGH BS2/3/4/6	TATA spare parts
252714605809	REDUCER HOSE TC OUT TO IC PIPE	TATA spare parts
252714605812	REDUCER HOSE TC OUT TO IC PIPE INTAKE	TATA spare parts
252714605813	REDUCER HOSE TC OUT TO IC PIPE INTAKE	TATA spare parts
252714605815	HOSE(FOR DUCT & ELBOW) 497 TCIC BSIIIN	TATA spare parts
252714605817	HOSE(ASSY PIPE TO AIR INTAKE ELBOW)	TATA spare parts
252714605820	HOSE (TC TO PIPE)	TATA spare parts
252714605821	HUMP HOSE	TATA spare parts
252714605836	PIPE (TC TO IC)	TATA spare parts
252714605844	HUMP HOSE (IC TO TC PIPE) BS6-PH2	TATA spare parts
252714605851	HUMP HOSE	TATA spare parts
252714605854	HOSE PIPE TURBOCHARGER TO INTERCOOLER	TATA spare parts
252714605865	HOSE ADAPTER TO IC PIPE	TATA spare parts
252714605873	HOSE BS6	TATA spare parts
252714606902	OUTLET PIPE-INTERCOOLER TO INLET ELBOW	TATA spare parts
252714606905	PIPE (TC TO IC) :LPT 709 TC/IC	TATA spare parts
252714606909	PIPE(65 O.D.):IC OUTLET TO ELBOW	TATA spare parts
252714606910	PIPE(65 O.D.):HUMP HOSE TO AIR IN ELBOW	TATA spare parts
252714606911	PIPE	TATA spare parts
252714606912	PIPE (IC OUT TO CYL HEAD COVER):SFC709EX	TATA spare parts
252714606924	PIPE (TC TO IC) 497 TCIC BS-III	TATA spare parts
252714606942	PIPE (TC TO IC)	TATA spare parts
252714606946	IC PIPING (IC TO ETB)	TATA spare parts
252714606951	PIPE (IC TO AIR INTAKE ELBOW)	TATA spare parts
252714606953	PIPE	TATA spare parts
252714606955	PIPE	TATA spare parts
252714606961	PIPE	TATA spare parts

252714606962	PIPE TC TO IC	TATA spare parts
252714606964	PIPE BS6	TATA spare parts
252714606965	PIPEBS6	TATA spare parts
252714606969	PIPEBS6	TATA spare parts
252714606971	PIPE BS6	TATA spare parts
252714606981	PIPE ASSY WITH BOSS IC TO ETB HOSE BS6	TATA spare parts
252714606982	PIPE BS6	TATA spare parts
252714608201	SUPPORT-ON EXH.MANIFOLD FOR TC-IC PIPE	TATA spare parts
252714608202	SUPPORT (FOR PIPE) :ON TIE MEMBER	TATA spare parts
252714608203	SUPPORT (FOR PIPE TC TO IC):SFC709EX	TATA spare parts
252714700101	ASSY COOLANT INLET LINE(OIL C.V. TO EGR	TATA spare parts
252714700103	ASSY.COOLANT OULET LINE(EGR V. TO UCWL)	TATA spare parts
252714700108	COOLANT PIPE ASSY COOLER TO EGR VALVE	TATA spare parts
252714700122	PIPE ASSY WITH HOSE EGR COOLER TO UWCL	TATA spare parts
252714700127	PIPE ASSY EGR TO UCWL	TATA spare parts
252714700141	COOLANT PIPE ASSY EGR COOLER TO UCWL	TATA spare parts
252714700143	COOLANT PIPE ASSY OIL COOLER COVER TO EG	TATA spare parts
252714700146	COOLANT PIPE ASSY	TATA spare parts
252714703304	SUPPORT BRACKET (EGR COOLANT LINE)	TATA spare parts
252715108601	SPACER STATER MOTOR	TATA spare parts
252715110101	ASSY.INSTRUMENT PANEL WITH MTG.BRACKET	TATA spare parts
252715130103	OIL LINE O/GALLERY-V/PUMP	TATA spare parts
252715130104	OIL LINE O/GALLERY-V/PUMP	TATA spare parts
252715135801	HOSE VAC PUMP TO OIL SUMP	TATA spare parts
252715139901	ADAPTER OIL GALLERY	TATA spare parts
252715140109	CLAMPING ROD COMP	TATA spare parts
252715140110	CLAMPING ROD COMP LPT	TATA spare parts
252715140114	BKT ALTERNATOR 40A/70A	TATA spare parts
252715140117	BKT ALTERNATOR	TATA spare parts
252715140118	TENSIONING ROD COMP	TATA spare parts
252715140119	ASSY.CLAMP ROD COMPLETE	TATA spare parts
252715140120	CLAMPING ROD COMPL SFC	TATA spare parts
252715140121	CLAMPING ROD LP 609	TATA spare parts
252715140122	ASSY CLAMPING ROD	TATA spare parts
252715140123	BKT ALTERNATOR	TATA spare parts
252715140124	ASSY BRACKET	TATA spare parts
252715140163	ASSY BRACKET (ALTERNATOR MOUNTING)	TATA spare parts
252715140165	ASSY TENSIONING ROD COMPLETE	TATA spare parts
252715140168	ASSY TENSIONING ROD COMPLETE.(ALTERNATOR	TATA spare parts
252715140169	ASSY&&CLAMPING&&ROD&&(ALTERNATOR&&WITH	TATA spare parts
252715140170	ASSY BRACKET ALTERNATOR (WITH VACCUM PUN	TATA spare parts
252715140184	ASSEMBLY CLAMP ROD	TATA spare parts
252715140190	ASSY TENSIONING ROD COMPLETE	TATA spare parts
252715140205	PULLEY IDLER ASSY	TATA spare parts
252715140219	ASSY CLAMP ROD COMPLETE	TATA spare parts
252715140220	ASSY. CLAMP ROD	TATA spare parts
252715140221	ASSY CLAMP ROD COMPLETE	TATA spare parts



252715140235	CLAMP ROD ASSY BS6	TATA spare parts
252715140238	CLAMP ROD ASSY WITH NUT	TATA spare parts
252715140245	SUPPORT BRACKET ALTERNATOR MTG BS6-PH2	TATA spare parts
252715140247	CLAMP ROD ASSY BS6	TATA spare parts
252715140251	BRACKET ASSY WITH FASTENER BS6	TATA spare parts
252715140252	COVER ASSY BS6	TATA spare parts
252715140255	BRACKET LAMBDA SENSOR MTG BS6	TATA spare parts
252715140261	BRACKET ASSY	TATA spare parts
252715143301	BRACKET	TATA spare parts
252715143702	BRACKET (ALTERNATOR MOUNTING)	TATA spare parts
252715143703	ALTERNATOR CAST BRACKET	TATA spare parts
252715143705	BRACKET (ALTERNATOR MOUNTING) BS6-PH2	TATA spare parts
252715143706	BRACKET (FOR ALTERNATOR & AC MOUNTING)	TATA spare parts
252715143713	CAST BRACKET (FOR ALT.MTG.LOWER)	TATA spare parts
252715143720	BRACKET (ALTERNATOR MOUNTING)	TATA spare parts
252715143722	BRACKET (ALTERNATOR MOUNTING)	TATA spare parts
252715143731	BRACKET ALTERNATOR MTG	TATA spare parts
252715143732	BRACKET ASSY ALTERNATOR MTG BS6	TATA spare parts
252715143733	BRACKET ALTERNATOR MTG BS6-PH2	TATA spare parts
252715146306	POLY-V BELT-1630 MM	TATA spare parts
252715146313	POLY V BELT (8PK) 1290MM Y1 AC	TATA spare parts
252715146314	POLY V BELT (6PK) 1500MM AC	TATA spare parts
252715146315	POLY-V BELT (6PK-1645MM)	TATA spare parts
252715146318	POLY-V BELT 8PK 1310	TATA spare parts
252715146329	POLY V-BELT-OFFER DRG BS6	TATA spare parts
252715146330	POLY V BELT (6PK) 1248	TATA spare parts
252715148001	SCREW (FOR IDLER TENSIONER)	TATA spare parts
252715148002	SCREW(FOR IDLER TENSIONER)	TATA spare parts
252715148201	SUPPORT BRACKET	TATA spare parts
252715148202	SUPPORT BRACKET	TATA spare parts
252715148219	SUPPORT BRACKET BS6	TATA spare parts
252715148220	BRACKET¿BS6	TATA spare parts
252715148222	PROTECTIVE COVER ALTERNATOR BS6	TATA spare parts
252715148223	BRACKET BS6-PH2	TATA spare parts
252715148224	BRACKET BS6-PH2	TATA spare parts
252715148802	SLIDER BOLT	TATA spare parts
252715148804	SLIDER BOLT	TATA spare parts
252715209902	MASS AIR FLOW SENSOR (HFM7) 497 I4	TATA spare parts
252715210103	ASSY. ELECTRONIC THROTTLE BODY - 52 MM	TATA spare parts
252715210117	ASSY. ELECTRONIC THROTTLE BODY-52MM BS4	TATA spare parts
252715216901	PLUG BS6	TATA spare parts
252715230101	ELECTRONIC THROTTLE BODY BS6-PH2	TATA spare parts
252715240101	TEMPERATURE SENSOR EXHAUST MANIFOLD BS6	TATA spare parts
252716101204	CONTAINER ASSY	TATA spare parts
252718100103	ASSY DRIVE SHAFT OIL PUMP BS6	TATA spare parts
252718100104	ASSY OIL PUMP COVER	TATA spare parts
252718100110	OIL PUMP ASSY LP609	TATA spare parts

252718100111	ASSY. OIL PUMP W/O STRAINER BS2/3/4	TATA spare parts
252718100112	ASSY. OIL PUMP COVER	TATA spare parts
252718100122	OIL PUMP ASSY W/O STRAINER BS6	TATA spare parts
252718107201	PLUG RELIEF VALVE	TATA spare parts
252718107901	SHAFT OIL PUMP	TATA spare parts
252718130101	OIL FILTER ASSY	TATA spare parts
252718130103	OIL FILTER W/O CARTRIDGE	TATA spare parts
252718130105	OIL FILTER CARTRIDGE BS2	TATA spare parts
252718130117	ASSY SUPPLY LINE OUTLET	TATA spare parts
252718130118	ASSY SUPPLY LINE INLET	TATA spare parts
252718130121	ASSY.OIL LINE-FILTER TO FIP	TATA spare parts
252718130122	ASSY.SUPPLY LINE -INLET-OFFER DRG	TATA spare parts
252718130123	ASSY.SUPPLY LINE -OUTLET-OFFER DRG	TATA spare parts
252718130127	ASSY OIL FILTER COMPLETE (SPINON):BS:III	TATA spare parts
252718130130	LUBE OIL FITER ASSY :SPINON:497	TATA spare parts
252718130132	OIL FILTER ELEMENT SPINON BS2/3/4	TATA spare parts
252718130136	ASSY OIL FILTER COMPLETE	TATA spare parts
252718130137	HEAD ASSY	TATA spare parts
252718130139	ASSY. OIL FILTER COMP. 497 BS3/4	TATA spare parts
252718130141	ASSY OIL FILTER	TATA spare parts
252718130142	ASSY OIL FILTER	TATA spare parts
252718130145	OIL FILTER ELEMENT SPINON BS3/4/6	TATA spare parts
252718130145CS	DEMO CUT SECTION MODEL FOR 252718130145	TATA spare parts
252718130147	LUBE OIL FILTER ELEMENT ASSEMBLY	TATA spare parts
252718130149	LUBE OIL FILTER ASSY SPINON	TATA spare parts
252718130150	HEAD ASSY	TATA spare parts
252718130152	ASSY OIL FILTER COMPLETE	TATA spare parts
252718130153	ASSY HEAD	TATA spare parts
252718130154	ASSY OIL LINE (OIL FILTER TO FIP)	TATA spare parts
252718130161	ASSY. OIL FILTER	TATA spare parts
252718130165	ASSY.OIL SUPPLY LINE (FLEXIBLE)	TATA spare parts
252718130166	SET:ASSY OIL FILTER COMP.	TATA spare parts
252718130172	ASSY OIL FILTER COMP	TATA spare parts
252718130176	ASSY. OIL FILTER COMPLETE	TATA spare parts
252718130177	ASSY OIL FILTER HEAD	TATA spare parts
252718130181	OIL FILTER COMPLETE ASSY (M/S FLEETGUARD	TATA spare parts
252718130189	OIL FILTER ASSY	TATA spare parts
252718130193	OIL PIPE ASSY OIL FILTER TO FIP	TATA spare parts
252718130201	LUBRICATION FILTER ASSY WITH HEAD BS6	TATA spare parts
252718130207	OIL FILTER BS6-PH2	TATA spare parts
252718135104	ADAPTER OIL FILTER	TATA spare parts
252718135301	GASKET	TATA spare parts
252718140103	LUBRICATION OIL FILTER ASSY BS6	TATA spare parts
252718140104	FILTER HEAD ASSY BS6	TATA spare parts
252718150111	ASSY. STRAINER	TATA spare parts
252718150115	ASSY STRAINER	TATA spare parts
252718170101	OIL COOLER ASSY	TATA spare parts

252718170104	ASSY. OIL COOLER BS2/3/4	TATA spare parts
252718170105	OIL LINE TC TO OIL COOLER	TATA spare parts
252718170110	ASSY.OIL LINE INLET-OIL COOLER TO TC	TATA spare parts
252718170111	ASSY.OIL LINE-OUTLET-TC TO OIL SUMP	TATA spare parts
252718170112	ASSY.OIL LINE-INLET-OIL COOLER TO TC	TATA spare parts
252718170116	ASSY OIL LINE-OIL COOLER TO TC	TATA spare parts
252718170123	ASSY. OIL COOLER	TATA spare parts
252718170127	ASSY OIL LINE OIL SUPPLY TO TC:EUROIII	TATA spare parts
252718170128	ASSY.LUBE LINE(OIL FILTER TO FIP)-	TATA spare parts
252718170129	ASSY. FLANGE WITH TUBE	TATA spare parts
252718170130	ASSY. OIL LINE(OIL COOLER TO TC)SFC 712	TATA spare parts
252718170140	ASSY OIL COOLER WITH ASSY PL TYPE HEAT	TATA spare parts
252718170141	ASSY PLATE TYPE HEAT EXCHANGER	TATA spare parts
252718170145	ASSY OILLINE:FLEXIBLE(OC-TC)AL OILCOOLER	TATA spare parts
252718170146	ASSY OILLINE:FLEXIBLE(OC-TC)AL OILCOOLER	TATA spare parts
252718170147	ASSY OIL COOLER COVER 497 ENG	TATA spare parts
252718170151	ASSY FLANGE W CRIMPED HOSE:497 TCIC BSII	TATA spare parts
252718170153	SET ASSY OILCOOLER W NOISE DAMPER	TATA spare parts
252718170154	SET ASSY OILCOOLERW NOISE DAM.PADS	TATA spare parts
252718170164	ASSY OIL COOLER-AL	TATA spare parts
252718170165	ASSY OIL COOLER-AL	TATA spare parts
252718170169	ASSY OIL COOLER PLATE TYPE HEAT EXCHA	TATA spare parts
252718170172	ASSY.OIL COOLER WITH ASSY.PL TYPE HEAT	TATA spare parts
252718170178	ASSY.OIL COOLER WITH ASSY.PL.TYPE HEAT	TATA spare parts
252718170197	ASSLY OIL COOLER	TATA spare parts
252718170206	ASSY OIL RETURN TUBE WITH CRIMPED HOSE	TATA spare parts
252718170212	ASSY.OIL LINE (OIL FILTER TO FIP)	TATA spare parts
252718170213	OIL RETURN LINE ASSY (TC)	TATA spare parts
252718170214	OIL LINE ASSY (OIL INLET LINE FOR TC)	TATA spare parts
252718170215	ASSY OIL LINE(FILTER TO FIP)	TATA spare parts
252718170222	ASSY OIL COOLER WITH ASSY PL TYPE HEAT	TATA spare parts
252718170228	ASSY OIL RETURN LINE	TATA spare parts
252718170232	TC OIL SUPPLY LINE ASSY	TATA spare parts
252718170233	TC OIL SUPPLY LINE ASSY	TATA spare parts
252718170235	OIL COOLER COVER ASSY M/S PN-NJ 497BSIV	TATA spare parts
252718170237	TC OIL SUPPLY LINE ASSY	TATA spare parts
252718170246	OIL LINE ASSY (160CC AIR COMP)	TATA spare parts
252718170252	TC OIL SUPPLY LINE ASSY	TATA spare parts
252718170260	OIL COOLER ASSY	TATA spare parts
252718170268	ASSY OIL COVER COMPLETE (PLATE TYPE HEAT	TATA spare parts
252718170275	OIL COOLER ASSY WITH COVER	TATA spare parts
252718170279	OIL COOLER ASSY BS6-PH2	TATA spare parts
252718170280	OIL COOLER ASSY BS6-PH2	TATA spare parts
252718170281	PISTON COOLING NOZZLE ASSY BS6	TATA spare parts
252718170285	OIL COOLER ASSY	TATA spare parts
252718171601	PLATE TYPE OIL COOLER GASKET	TATA spare parts
252718171611	TUBE ASSY TURBOCHARGER OIL INTAKE	TATA spare parts

252718173809	OIL COOLER COVER	TATA spare parts
252718173810	OIL COOLER COVER 497 BS-III	TATA spare parts
252718175301	GASKET OIL COOLER	TATA spare parts
252718175302	GASKET OIL COOLER COVER	TATA spare parts
252718175308	GASKET OIL FLTR ON CYL BLOCK TALBROS	TATA spare parts
252718175311	GASKET(PLATE TYPE O/COOLER)	TATA spare parts
252718175312	GASKET-NON ASBESTOS (OIL COOLER COVER)	TATA spare parts
252718175314	GASKET TURBO RETURN ADAPTER	TATA spare parts
252718175803	HOSE TC TO OUTLET O/SUMP	TATA spare parts
252718175804	HOSE TC OUTLET	TATA spare parts
252718175806	HOSE (TC OUTLET) FOR GENSET	TATA spare parts
252718175808	HOSE (TC OUT TO OIL SUMP):HIGHTORQUE	TATA spare parts
252718175809	HOSE	TATA spare parts
252718175810	HOSE	TATA spare parts
252718175813	HOSE (TC OUTLET TO CYL CRANKCASE)	TATA spare parts
252718175814	HOSE TC OUTLET TO CYL CRANKCASE:BS:III	TATA spare parts
252718175817	HOSE:TC OUTLET TO CYL CRANKCASE	TATA spare parts
252718175818	HOSE:TC OUTLET TO CYL CRANKCASE	TATA spare parts
252718175821	HOSE-TC OIL OUTLET TO CYLINDER BLOCK	TATA spare parts
252718175824	RUBBER HOSE(TC TO CYL.BLOCK) 497 BS-III	TATA spare parts
252718175835	RUBBER HOSE (ALTERNATOR TO OIL SUMP)	TATA spare parts
252718177201	ADAPTER	TATA spare parts
252718177202	OIL COOLER CONNECTOR	TATA spare parts
252718177204	ADAPTOR TC OIL RETURN:BS:III	TATA spare parts
252718177206	THREADED PLUG	TATA spare parts
252718177207	SEALING PLUG	TATA spare parts
252718177210	CONNECTOR (OIL COOLER)	TATA spare parts
252718177214	ADAPTOR OIL TEMP SENSOR	TATA spare parts
252718179903	PIPE UNION BOLT (TURBO OIL SUPPLY LINE)	TATA spare parts
252718179905	WASHER	TATA spare parts
252718990139	OIL FILTER ELEMENT (SPINON) BS1/3/4	TATA spare parts
252720100102	SHAFT BEARING HOUSING	TATA spare parts
252720100104	ASSY. WATER PUMP BS1	TATA spare parts
252720100105	WATER PUMP ASSY	TATA spare parts
252720100123	WATER PUMP ASSY	TATA spare parts
252720100125	WATER PUMP ASSY WITH ADAPTER	TATA spare parts
252720105301	GASKET W/PUMP TO CYL BLK	TATA spare parts
252720105306	GASKET WATER PUMP TALBROS	TATA spare parts
252720105310	W/P GASKET WITH SILICONE BEADING	TATA spare parts
252720107106	LIFTING HOOK (REAR)	TATA spare parts
252720107801	O RING	TATA spare parts
252720107802	OIL SEAL BIG	TATA spare parts
252720107803	OIL SEAL SMALL	TATA spare parts
252720107901	SHAFT BEARING HOUSING	TATA spare parts
252720120106	UPP.COOL.WATER LINE	TATA spare parts
252720120107	THERMOSTAT ASSY 88 DEGT	TATA spare parts
252720120108	UPP.COOL.WATER LINE	TATA spare parts

252720120109	THERMOSTAT ASSY 88 DEG	TATA spare parts
252720120110	THERMOSTAT ASSY 88 DEG	TATA spare parts
252720120113	UPP.COOL.WATER LINE	TATA spare parts
252720120114	ASSY.THERMOSTAT	TATA spare parts
252720120118	THERMOSTAT ASSY 74 DEG	TATA spare parts
252720120119	THERMOSTAT ASSY 74 DEG	TATA spare parts
252720120120	ASSY.UPPER COOLING WATER LINE CAB HEAT	TATA spare parts
252720120121	THERMOSTAT ASSY 74 DEG	TATA spare parts
252720120123	ASSY.THERMOSTAT 76 DEG SOT	TATA spare parts
252720120124	ASSY.UPPER COOLING WATER LINE (HD)	TATA spare parts
252720120125	UPPER WATER COOLING LINE	TATA spare parts
252720120130	ASSY UPPER COOLING LINE	TATA spare parts
252720120131	ASSY UPPER COOLING WATER LINE	TATA spare parts
252720120134	ASSY UPPER COOLING WATER LINE-HD	TATA spare parts
252720120135	ASSY.UPPER COOLING WATER LINE GENSET	TATA spare parts
252720120140	THERMOSTAT	TATA spare parts
252720120141	ASSY THERMOSTAT (OFFER DRG):SFC	TATA spare parts
252720120142	ASSY THERMOSTAT PLASTIC-SFC	TATA spare parts
252720120143	THERMOSTAT	TATA spare parts
252720120144	ASSY SEALING PLUG WITH TUBE 6 DIA	TATA spare parts
252720120146	ASSY THERMOSTAT	TATA spare parts
252720120151	ASSY THERMOSTAT	TATA spare parts
252720120152	ASSY.THERMOSTAT	TATA spare parts
252720120154	ASSY UPPER COOLING WATER LINE	TATA spare parts
252720120155	ASSY UPPER COOLING WATER LINE:4SPTC EIII	TATA spare parts
252720120156	ASSY THERMOSTAT (SFC709EX)	TATA spare parts
252720120159	ASSY UPPER COOLING WATER LINE:BS:III	TATA spare parts
252720120160	THERMOSTAT ASSEMBLY :87DEG SOT	TATA spare parts
252720120163	ASSY.UPPER COOLING WATER LINE(509M-H&D)	TATA spare parts
252720120164	ASSY UPPER COOLING WATER LINE SFCBS IIE X	TATA spare parts
252720120166	ASSY UPPER COOLING WATER LINE:HD:LP709	TATA spare parts
252720120167	ASSY UPPER COOLING WATER LINE:497 BSIIEX	TATA spare parts
252720120168	UPPER COOLING WATER LINE LP407 CNG BSIII	TATA spare parts
252720120169	ASSY UPPER COOLING WATER LINE:BS2EX NLT	TATA spare parts
252720120171	ASSY THERMOSTAT W JIGGLE PINS:87 DEG:NLT	TATA spare parts
252720120172	UPPER COOLING WATER LINE SFC407CNG BSIII	TATA spare parts
252720120182	ASSY. THERMOSTAT W/PINS (83 DEG)BS2/3/4	TATA spare parts
252720120183	ASSY UPPER COOLING WATER LINE:BSIII	TATA spare parts
252720120186	ASSY UPPER COOLING WATER LINE(HD&EMOS)	TATA spare parts
252720120192	ASSY. UPPER COOLING WATER LINE	TATA spare parts
252720120194	ASSY THERMOSTAT (497 BS-IV)	TATA spare parts
252720120196	ASSY UPPER COOLING WATER LINE	TATA spare parts
252720120197	ASSY. THERMOSTAT	TATA spare parts
252720120199	ASSY UPPER COOLING WATER LINE	TATA spare parts
252720120201	ASSY. UPPER COOLING WATER LINE	TATA spare parts
252720120207	ASSY. UPPER COOLING WATER LINE (SFC407)	TATA spare parts
252720120208	ASSY. UPPER WATER COOLING PIPE (FABRICAT	TATA spare parts

252720120211	ASSY WATER PUMP	TATA spare parts
252720120212	UPPER COOLING WATER LINE	TATA spare parts
252720120217	ASSY THERMOSTST	TATA spare parts
252720120225	ASSY.THERMOSTAT	TATA spare parts
252720120235	ASSY. THERMOSTAT (QUICK WAX) BS2/3	TATA spare parts
252720120246	ASSY UPPER COOLING WATER LINE	TATA spare parts
252720120257	CONNECTION ASSY PIPE(CONTR TO EGR)	TATA spare parts
252720120258	WATER LINE ASSY CONNECTOR TO TC INTAKE	TATA spare parts
252720120259	COOLANT RETURN LINE ASSY TC OUTLET	TATA spare parts
252720120262	ASSY THERMOSTAT (VERTICAL)	TATA spare parts
252720120264	PIPE ASSY EGR WATER OUTLET LINE	TATA spare parts
252720120269	ASSY UPPER COOLING WATER LINE	TATA spare parts
252720120283	TC WATER INLET LINE	TATA spare parts
252720120284	COOLING LINE ASSY UPPER	TATA spare parts
252720120285	ASSY UPPER COOLING WATER LINE	TATA spare parts
252720120304	UPPER COOLING WATER LINE ASSY	TATA spare parts
252720120312	ASSY THERMOSTAT	TATA spare parts
252720120327	THERMOSTAT ASSY	TATA spare parts
252720120333	ADAPTER UPPER COOLING LINE	TATA spare parts
252720120334	HOSE COOLANT RETURN PIPE	TATA spare parts
252720120339	THERMOSTAT ASSY	TATA spare parts
252720120340	THERMOSTAT ASSY	TATA spare parts
252720120343	UPPER COOLING WATER PIPE ASSY	TATA spare parts
252720120353	TUBE ASSY TC COOLANT RETURN BS6	TATA spare parts
252720120356	TUBE ASSY TC COOLANT INTAKE BS6	TATA spare parts
252720120357	ADAPTER UPPER COOLING LINE BS6	TATA spare parts
252720120361	HOSE COOLANT RETURN PIPE BS6-PH2	TATA spare parts
252720120362	THERMOSTAT ASSY	TATA spare parts
252720120364	BRACKET ASSY THERMOSTAT MTG BS6-PH2	TATA spare parts
252720120366	HOSE COOLANT RETURN PIPE BS6	TATA spare parts
252720120367	TUBE ASSY TC COOLANT INTAKE BS6	TATA spare parts
252720120369	ADAPTER UPPER COOLING LINE BS6-PH2	TATA spare parts
252720120372	TUBE ASSY TC COOLANT INTAKE BS6	TATA spare parts
252720120379	HOSE COOLANT RETURN PIPE BS6	TATA spare parts
252720120381	HOSE COOLANT RETURN PIPE BS6	TATA spare parts
252720120385	THERMOSTAT BS6-PH2	TATA spare parts
252720121601	ASSY THERMOSTAT	TATA spare parts
252720123303	SUPPORT BRACKET T-CONNECTOR BS6-PH2	TATA spare parts
252720123802	UPPER WATER COOLING LINE	TATA spare parts
252720123805	COOLANT CONNECTOR	TATA spare parts
252720123824	COOLANT CONNECTOR BS6-PH2	TATA spare parts
252720123825	COOLANT CONNECTOR BS6	TATA spare parts
252720123826	COOLANT CONNECTOR BS6-PH2	TATA spare parts
252720124202	SUPPORT CLAMP	TATA spare parts
252720125301	GASKET-UPPER COOLING WATER LINE	TATA spare parts
252720125302	GASKET(UCW LINE)	TATA spare parts
252720125801	HOSE WP BYPASS-THERMOSTAT	TATA spare parts

252720125802	HOSE THERMOSTAT TO W/PUMP	TATA spare parts
252720125803	RUBBER HOSE BYPASS THERMO	TATA spare parts
252720125804	HOSE-THERMOSTAT TO WATER PUMP	TATA spare parts
252720125807	RUBBER HOSE(UCWL TO THERMOSTAT)	TATA spare parts
252720125808	RUBBER HOSE(THERMOSTAT TO WATER PUMP)	TATA spare parts
252720125809	HOSE ( THERMOSTAT TO RADIATOR )	TATA spare parts
252720125810	HOSE ( THERMOSTAT TO WATER PUMP )	TATA spare parts
252720125811	HOSE (RADIATOR TO THERMOSTAT)	TATA spare parts
252720125812	HOSE (THERMOSTAT TO WATER PUMP)	TATA spare parts
252720125816	HOSE ( THERMOSTAT TO RADIATOR )	TATA spare parts
252720125820	HOSE(THERMOSTAT TO WATER PUMP)	TATA spare parts
252720125823	HOSE(UCWL TO THERMOSTAT)	TATA spare parts
252720125824	RUBBER HOSE (THERMOSTAT TO WATER PUMP)	TATA spare parts
252720125828	HOSE L TYPE	TATA spare parts
252720125837	HOSE UPPER COOLING LINE TO THERMOSTAT	TATA spare parts
252720125842	HOSE THERMOSTAT	TATA spare parts
252720125844	HOSE THERMOSTAT TO WATER PUMP	TATA spare parts
252720125846	HOSE ASSY COOLANT RETURN BS6	TATA spare parts
252720125884	HOSE THERMOSTAT TO RADIATOR	TATA spare parts
252720125887	RUBBER HOSE THERMO STATTO WATER PUMP	TATA spare parts
252720126801	CONNECTION COUPLING BODY M16XM14	TATA spare parts
252720140102	ASSY.FAN 457 DIA (GENSET)	TATA spare parts
252720140103	ASSY. FAN 515 DIA 497CIC BS3	TATA spare parts
252720140106	ASSY. BRACKET (FANRING)(BOTTOM LH SIDE)	TATA spare parts
252720140107	ASSY. BARCKET (FANRING)(BOTTOM RH SIDE)	TATA spare parts
252720140108	ASSY BRT.(FANRING) BOTTOM RHSIDE MECH.FP	TATA spare parts
252720140109	ASSY VISCOUS FAN (550 DIA)	TATA spare parts
252720140110	ASSY. VISCOUS FAN(430 DIA) BS4	TATA spare parts
252720140111	ASSY. BRACKET (FAN RING) BOTTOM LH SIDE	TATA spare parts
252720140123	ASSY.VISCOUS FAN(430 DIA)	TATA spare parts
252720140133	VISCOUS FAN ASSY	TATA spare parts
252720140138	VISCOUS CLUTCH ASSY	TATA spare parts
252720140140	FAN ASSY	TATA spare parts
252720140153	FAN ASSY BS6-PH2	TATA spare parts
252720140154	FAN ASSY BS6-PH2	TATA spare parts
252720143802	INTERMEDIATE RING FAN	TATA spare parts
252720143805	SPACER FOR FAN	TATA spare parts
252720143806	SPACER (FOR FAN) - 53MM SPACER	TATA spare parts
252720143808	FAN SHROUD RING	TATA spare parts
252720143811	FAN SPACER-86PS BSIII	TATA spare parts
252720143813	SPACER (FOR FAN)	TATA spare parts
252720143816	SPACER (FOR FAN)-41.5 MM	TATA spare parts
252720143819	SPACER FAN BS6	TATA spare parts
252720143822	ADAPTER FAN MTG	TATA spare parts
252720147003	PULLEY FAN	TATA spare parts
252720147004	WATER PUMP PULLEY	TATA spare parts
252720147012	WATER PUMP PULLEY	TATA spare parts

252720147013	PULLEY SINGLE GROOVE WATER PUMP:BS:III	TATA spare parts
252720147014	PULLEY WATER PUMP	TATA spare parts
252720147017	WATER PUMP PULLEY	TATA spare parts
252720147022	WATER PUMP PULLEY (SINGLE GROOVE)	TATA spare parts
252720147023	WATER PUMP PULLEY	TATA spare parts
252720147024	WATER PUMP PULLEY	TATA spare parts
252720147031	WATER PUMP PULLEY	TATA spare parts
252720147035	WATER PUMP PULLEY	TATA spare parts
252720147038	WATER PUMP PULLEY	TATA spare parts
252720147040	WATER PUMP PULLEY	TATA spare parts
252720147042	WATER PUMP PULLEY	TATA spare parts
252720147045	WATER PUMP PULLEY	TATA spare parts
252720148202	FAN	TATA spare parts
252720150101	ASSY. BEARING HOUSING BS1	TATA spare parts
252720156301	V BELT COGGED 850 MM	TATA spare parts
252720156305	V BELT 1400 LONG BS2/3/4	TATA spare parts
252720156307	V-BELT(COGGED):1280MM(IMPROVED)	TATA spare parts
252720156308	POLY V BELT 8PK BS3/4/6	TATA spare parts
252720156308DF	BELT POLY V 8PK 1245MM L -497CRDI BS4	TATA spare parts
252720156309	POLY V BELT (1295)	TATA spare parts
252720156317	BELT	TATA spare parts
252720156325	POLY V-BELT BS6-PH2	TATA spare parts
252720300101	ASSY COOLENT HOSE- 1200 MM (UWCL TO HPR)	TATA spare parts
252720300102	ASSY COOLENT HOSE- 1500 MM BS6	TATA spare parts
252720300103	ASSY COOLENT HOSE- 1400 MM (HPR TO RADIA	TATA spare parts
252720300105	COOLANT HOSE ASSY BS6	TATA spare parts
252720300106	COOLANT HOSE ASSY BS6	TATA spare parts
252720305801	HOSE WATER PUMP TO THERMOSTAT	TATA spare parts
252720305802	HOSE UPPER COOLING LINE TO THERMOSTAT	TATA spare parts
252720305803	HOSE BS6	TATA spare parts
252720305806	HOSE WATER PUMP TO THERMOSTAT BS6	TATA spare parts
252720305807	HOSE BS6	TATA spare parts
252721990101	ASSY. AIR FILTERS 9M3	TATA spare parts
252722100101	ASSY LIFTING HOOK REAR	TATA spare parts
252722100102	ASSY LIFTING HOOK REAR	TATA spare parts
252722100116	LIFTING HOOK ASSY	TATA spare parts
252722107102	LIFTING HOOK REAR	TATA spare parts
252722107104	LIFTING HOOK FRONT	TATA spare parts
252722107106	LIFTING HOOK (REAR)	TATA spare parts
252722107107	LIFTING HOOK (REAR)	TATA spare parts
252722107108	LIFTING HOOK (REAR)	TATA spare parts
252722107115	LIFTING HOOK (FRONT)	TATA spare parts
252722107120	LIFTING HOOK REAR	TATA spare parts
252722107121	LIFTING HOOK FRONT (497 SIDE ENTRY)	TATA spare parts
252722107123	LIFTING HOOK (FRONT)	TATA spare parts
252722107128	LIFTING HOOK	TATA spare parts
252722107135	LIFTING HOOK	TATA spare parts



252722107137	LIFTING HOOK FRONT	TATA spare parts
252722120111	ASSY.BRACKET - REAR	TATA spare parts
252722120112	ASSY.BRACKET - FRONT-RIGHT	TATA spare parts
252722120113	ASSY.BRACKET - _FRONT-LEFT	TATA spare parts
252722120114	ASSY.SUPPORT ENGINE FRONT	TATA spare parts
252722120115	ASSY.SUPPORT ENGINE FRONT	TATA spare parts
252722120116	ASSY.SUPPORT ENGINE FRONT-RH	TATA spare parts
252722120117	ASSY.SUPPORT ENGINE FRONT-LH	TATA spare parts
252722120121	ASSY. SUPPORT ENG. FRONT-LH	TATA spare parts
252722120122	ASSY. SUPPORT ENG. FRONT-RH	TATA spare parts
252722125107	ENGINE MOUNTING ARM LH	TATA spare parts
252722125108	ENGINE MOUNTING ARM RH	TATA spare parts
252722125112	ENGINE MOUNTING ARM LH LP712 AC BUS 497	TATA spare parts
252722125119	ENGINE MOUNTING ARM- RIGHT (PAINTED)	TATA spare parts
252723110103	STEERING PUMP BS1/2/3/4	TATA spare parts
252723113302	BRACKET BOTTOM SIDE	TATA spare parts
252723113303	BRACKET (FOR POWER STRG. PUMP)	TATA spare parts
252723113702	ADAPTOR PLATE	TATA spare parts
252723115301	GASKET (POWER STEERING PUMP)	TATA spare parts
252723115302	GASKET POWER STEERING PUMP&BS6	TATA spare parts
252723115401	STEERING PUMP GEAR	TATA spare parts
252723116304	POLY-V BELT 1060MM	TATA spare parts
252723116304DF	BELT POLY V 1060MM L 497/ULTRABUS	TATA spare parts
252723116308	POLY V-BELT	TATA spare parts
252723116315	POLY V-BELT 4-PEAKS -985	TATA spare parts
252723116320	V-BELT	TATA spare parts
252723116701	PIVOT PIN	TATA spare parts
252723116801	COUPLING BODY	TATA spare parts
252723117701	SEALING RING (STEERING PUMP MTG.)	TATA spare parts
252723120109	TENSIONING ROD COMPLT	TATA spare parts
252723120115	IDLER ASSY	TATA spare parts
252723120116	BRACKET IDLER PULLEY	TATA spare parts
252723120118	IDLER ASSY	TATA spare parts
252723127002	PULLEY IDLER	TATA spare parts
252723140101	ASSY.AIR COMP.WATER INLET LINE	TATA spare parts
252723140102	ASSY. PIPE AIR COMPRESSOR INLET LINE	TATA spare parts
252723140103	AIR INTAKE SYSTEM ASSY PIPE(COMPRESSOR)	TATA spare parts
252723140107	INTAKE PIPE ASSY AIR COMP	TATA spare parts
252723140110	AIRINTAKEPIPEASSYAIRCOMPBS6	TATA spare parts
252723140111	INTAKE PIPE ASSY AIR COMP BS6	TATA spare parts
252723140113	AIRINTAKEPIPEASSYAIRCOMPBS6	TATA spare parts
252723140114	AIR INTAKE PIPE ASSY AIR COMP BS6	TATA spare parts
252723140116	AIR INTAKE PIPE ASSY AIR COMP BS6-PH2	TATA spare parts
252723140117	AIR INTAKE PIPE ASSY AIR COMP BS6-PH2	TATA spare parts
252723143301	SUPPORT BRACKET (GEAR DRIVEN COMPRESSOR)	TATA spare parts
252723145801	HOSE (WATER OUTLET A/C HEAD)	TATA spare parts
252723400105	ASSY.BRACKET(P/STRG PUMP MTG)	TATA spare parts

252723400113	ASSY.CLAMPING ROD COMPLETE	TATA spare parts
252723400114	ASSY.CLAMPING ROD	TATA spare parts
252723400116	BRACKET PUMP MTG RHD	TATA spare parts
252723400122	ASSY BRACKET(PSTG PUMP MTG)	TATA spare parts
252723400125	ASSY.CLAMPING ROD	TATA spare parts
252723400126	ASSY.CLAMPING ROD COMPLETE	TATA spare parts
252723400133	ASSY. CLAMPING ROD	TATA spare parts
252723400134	ASSY. CLAMPING ROD	TATA spare parts
252723400136	ASSY BRACKET (PSTRG MTG.)	TATA spare parts
252723400140	ASSY.CLAMPING ROD COMPLETE 497 ENGINE	TATA spare parts
252723400143	ASSY CLAMP ROD	TATA spare parts
252723400144	ASSY. CLAMP ROD COMPLETE	TATA spare parts
252723400157	ASSY.CLAMPING ROD COMPLETE	TATA spare parts
252723400166	ASSY CLAMP ROD COMPLETE	TATA spare parts
252723403705	BRACKET (ZF P/STRG.PUMP)	TATA spare parts
252723403709	BRACKET POWER STEERING MOUNTING	TATA spare parts
252723403711	BRACKET (FOR MTG POWER STEERING)	TATA spare parts
252723403712	PULLEY (FOR POWER STEERING PUMP)	TATA spare parts
252723403713	BRACKET (FOR POWER STG. MOUNTING)	TATA spare parts
252723403716	PULLEY POWER STG PUMP (ZF POWER STG PUMP)	TATA spare parts
252723403719	BRACKET (PSTRG PUMP MTG) LP/LPT 1109	TATA spare parts
252723403720	PULLEY 4PK (FOR POWER STEERING)	TATA spare parts
252723403721	BRACKET (FOR PSTRG.MTG) Y1 LPO W/AC	TATA spare parts
252723403725	BRACKET (FOR POWER STRG. PUMP)	TATA spare parts
252723403727	PULLEY POWER STEERING PUMP	TATA spare parts
252723403729	BRACKET (FOR PSTRG PUMP)	TATA spare parts
252723403732	BRACKET POWER STEERING PUMP MTG	TATA spare parts
252723406302	V BELT GOGGED	TATA spare parts
252723406304	V-BELT -1098 LG.(COGGED)	TATA spare parts
252723406305	V-BELT - 850 LG.(COGGED)	TATA spare parts
252723406314	"BELT,POWER STEERING PUMP"	TATA spare parts
252723407003	PULLEY SFC 609	TATA spare parts
252723407007	PULLEY P/STRG PUMP CAST	TATA spare parts
252723407008	PULLEY:CAST(FOR PSTG):LP1512 BSIII	TATA spare parts
252723407014	PULLEY (ZF POWER STEERING PUMP)	TATA spare parts
252723407017	PULLEY (FOR PSTRG. PUMP)	TATA spare parts
252723407020	PULLEY (FOR ZF POWER STR. PUMP)	TATA spare parts
252723407023	PULLEY POWER STEERING PUMP SIDE ENTRY	TATA spare parts
252723407024	PULLEY POWER STG	TATA spare parts
252723407025	CAST PULLEY (DIA 146) PSTRG PUMP	TATA spare parts
252725103709	CLUTCH HSG.LP609	TATA spare parts
252725103716	CLUTCH HOUSING 310 DIA	TATA spare parts
252725103717	FLYWHEEL HOUSING FOR GENSET	TATA spare parts
252725103726	CLUTCH HOUSING 310DIA. 497TCIC BS2/3/4	TATA spare parts
252725103728	CLUTCH HOUSING:LP909BS-IIEX 49WB:497TCIC	TATA spare parts
252725103729	CLUTCH HOUSING	TATA spare parts
252725103730	CLUTCH HOUSING 497 BSIV LP 1512 (330D CL	TATA spare parts

252725106701	PIN (66 MM LENGTH)	TATA spare parts
252725108205	CLUTCH HOUSING LOWER PART	TATA spare parts
252750000106	RADIATOR FRAME	TATA spare parts
252750000108	ASSY SUPPORT PLATE	TATA spare parts
252750000109	PAD RADIATOR MTG SIDE	TATA spare parts
252750000112	BKT RADIATOR RH BOTTOM	TATA spare parts
252750000115	ASSY FRAME W/TOP BRKT	TATA spare parts
252750000116	BKT RADIATOR LH	TATA spare parts
252750000117	ASSY BRACKET RH	TATA spare parts
252750000118	PAD RADITOR MTG TOP	TATA spare parts
252750000131	RADIATOR FRAME	TATA spare parts
252750000132	ASSY FRAME WITH TOP BRACKET	TATA spare parts
252750000133	ASSY.BRACKET-RH (RADIATOR MTG.)	TATA spare parts
252750000134	ASSY.BRACKET-LH (RADIATOR MTG.)	TATA spare parts
252750000135	BRACKET LH-RAD BOTTOM MOUNTING LPT1109	TATA spare parts
252750000136	BRACKET RH-RAD BOTTOM MOUNTING LPT1109	TATA spare parts
252750000141	ASSY BRACKET RAD MTG BOTTOM:EURO III	TATA spare parts
252750000142	ASSY BRACKET (RAD MTG BOTTOM)	TATA spare parts
252750000143	ASSY. RADIATOR MTG. PAD-BOTTOM	TATA spare parts
252750000144	ASSY. RADIATOR MTG. PAD TOP	TATA spare parts
252750000148	SET ASSY.RAD. & INTERCOOLER	TATA spare parts
252750000151	ASSY RUBBER BUSH(RAD SIDE MOUNTING )	TATA spare parts
252750000152	ASSY BRCKET FOR RAD. MTG(ON LONGMEMBER)	TATA spare parts
252750000156	ASSY BRACKET RAD MTG BOTTOM	TATA spare parts
252750000163	ASSY.RADIATOR MTG.PAD SIDE.	TATA spare parts
252750000164	ASSY.RADIATOR MTG.PAD TOP	TATA spare parts
252750000165	RADIATOR MTG PAD ASSY BS6-PH2	TATA spare parts
252750000171	ASSY BRACKET (RAD MTG BOTTOM)	TATA spare parts
252750000172	ASSY.RUBBER BUSH (RAD. FRAME SIDE MTG.)	TATA spare parts
252750000175	ENGINE COOLING SYSTEM	TATA spare parts
252750000176	ASSY.RUBBER BUSH (RAD. FRAME SIDE MTG.)	TATA spare parts
252750000188	BRACKET RADIATOR MTG BOTTOM	TATA spare parts
252750000194	BRACKET ASSY RADIATOR ASSY MTG BOTTOM	TATA spare parts
252750000202	TIE BAR ASSY	TATA spare parts
252750000205	BRACKET ASSY TIE ROD MTG LH	TATA spare parts
252750000206	TIE BAR ASSY BS6	TATA spare parts
252750000207	BRACKET TIE ROD ASSYBRACKET TIE ROD ASSY	TATA spare parts
252750000208	STAY ROD ASSY RADIATOR FRAME MTG BS6	TATA spare parts
252750003401	RUBBER BUSH(RADIATOR MOUNTING FRAME) BS	TATA spare parts
252750005801	RUBBER HOSE RAD TO W/PUMP	TATA spare parts
252750005802	HOSE(T.VENT TO COOLANT FILLING PIPE)NLT	TATA spare parts
252750005803	HOSE(NO LOSS TANK TO FILLER PIPE)	TATA spare parts
252750005804	HOSE(COOLANT FILLING PIPE TO RAD VENT)	TATA spare parts
252750005805	RUBBER HOSE(COOLANT FILLING PIPE TO RAD)	TATA spare parts
252750005808	HOSE (RADIATOR TO WATER PUMP):HD LPT709	TATA spare parts
252750005809	HOSE (RAD TO WATER PUMP)SFC709 BSIEX HD	TATA spare parts
252750005817	RUBBER HOSE(COOLANT FILL PIPE TO RAD)	TATA spare parts

252750005818	HOSE (NO LOSS TANK TO FILLER PIPE)	TATA spare parts
252750005819	HOSE(T.VENT TO COOLANT FILLING PIPE)	TATA spare parts
252750005820	HOSE(RADIATOR TO COOLANT FILLING PIPE)	TATA spare parts
252750005821	RUBBER HOSE (FILLING PIPE TO RADIATOR)	TATA spare parts
252750005822	HOSE (COOLANT FILLING PIPE TO RADIATOR )	TATA spare parts
252750005823	RUBBER HOSE (NO LOSS TANK TO FILLER PIPE)	TATA spare parts
252750005824	HOSE ( THERMOSTAT VENT TO COOLANT FILLING PIPE)	TATA spare parts
252750005825	RUBBER HOSE (FOR COOLANT FILLING PIPE)	TATA spare parts
252750005828	HOSE(NO LOSS TANK TO FILLER PIPE)	TATA spare parts
252750005829	RUBBER HOSE (COOLANT FILLING PIPE TO RADIATOR)	TATA spare parts
252750005830	RUBBER HOSE(NO LOSS TANK TO PIPE)	TATA spare parts
252750005833	RUBBER HOSE (COOLANT FILLING PIPE TO RADIATOR)	TATA spare parts
252750005834	HOSE(COOLANT FILLING PIPE TO RADIATOR VENT)	TATA spare parts
252750005838	HOSE (COOLANT FILLING PIPE TO RADIATOR)	TATA spare parts
252750005857	HOSE (THERMOSTAT VENT TO COOLANT FILLING PIPE)	TATA spare parts
252750005863	HOSE FILLER PIPE TO RADIATOR	TATA spare parts
252750005869	HOSE	TATA spare parts
252750005870	HOSE	TATA spare parts
252750005871	HOSE NO LOSS TANK TO FILLER PIPE	TATA spare parts
252750005872	HOSE FILLER PIPE TO RADIATOR	TATA spare parts
252750005876	HOSE NO LOSS TANK TO FILLER PIPE BS6	TATA spare parts
252750005877	HOSE THERMOSTAT VENT TO FILLER NECK BS6	TATA spare parts
252750005879	HOSE THERMOSTAT VENT TO FILLER NECK BS6	TATA spare parts
252750005880	RUBBER BELLOW BS6	TATA spare parts
252750005884	HOSE NO LOSS TANK TO FILLER NECK BS6-PH2	TATA spare parts
252750005885	HOSE VENT TUBE TO FILLER NECK BS6-PH2	TATA spare parts
252750008207	BRACKET RADIATOR MTG	TATA spare parts
252750008209	RADIATOR MTG BRACKET RH	TATA spare parts
252750008211	BKT RADIATOR LH BOTTOM	TATA spare parts
252750008212	BKT RADIATOR RH BOTTOM	TATA spare parts
252750008213	BKT RADIATOR RH	TATA spare parts
252750008214	BKT RADIATOR LH	TATA spare parts
252750008215	BKT RADIATOR RH ON C/M	TATA spare parts
252750008216	BRACKET-LH(RADIATOR MTG.ON CROSS MEMBER)	TATA spare parts
252750008221	RADIATOR MOUNTING BRACKET-TOP LH SIDE	TATA spare parts
252750008222	RADIATOR MOUNTING BRACKET-TOP RH SIDE	TATA spare parts
252750008227	RADIATOR MOUNTING BRACKET:EURO III	TATA spare parts
252750008229	RADIATOR MTG BKT:LH (LP/LPT1112)	TATA spare parts
252750008232	RADIATOR MTG BKT:RH (LP/LPT1112)	TATA spare parts
252750008233	RADIATOR MOUNTING BRACKET (ON LONG MEMBER)	TATA spare parts
252750008239	RADIATOR MTG BRACKET (RH SIDE)	TATA spare parts
252750008240	RADIATOR MTG BRACKET (LH)	TATA spare parts
252750008241	RADIATOR MTG BKT LH LPT 1112 BSIII W/VISC FAN	TATA spare parts
252750008242	RADIATOR MTG BKT RH LPT 1112 BSIII W/VISC FAN	TATA spare parts
252750008243	RADIATOR MOUNTING BRACKET RH SIDE	TATA spare parts
252750008244	RADIATOR MOUNTING BRACKET LH SIDE	TATA spare parts
252750008246	RADIATOR MOUNTING BRACKET FOR LPT 712	TATA spare parts

252750008250	RADIATOR MOUNTING BRACKET	TATA spare parts
252750008259	RADIATOR MOUNTING BRACKET	TATA spare parts
252750008262	BRACKET (FOR RADIATOR MOUNTING)	TATA spare parts
252750008263	BRACKET RADIATOR MTG LH	TATA spare parts
252750008264	BRACKET RADIATOR MTG RH	TATA spare parts
252750008266	BRACKET RADIATOR ASSY MTG LH	TATA spare parts
252750008267	BRACKET RADIATOR ASSY MTG RH	TATA spare parts
252750010107	ASSY. RADIATOR	TATA spare parts
252750010108	ASSY ENGINE COOLING SYSTEM	TATA spare parts
252750010109	RECOVERY BOTTLE ASSY	TATA spare parts
252750010110	ASSY ENGINE COOLING SYSTEM	TATA spare parts
252750010111	ASSY RADIATOR	TATA spare parts
252750010113	ENGINE COOLING SYSTEM -497TC 50KVA	TATA spare parts
252750100109	BRACKET AUX WATER TANK	TATA spare parts
252750100112	ASSY CONNECTOR	TATA spare parts
252750100115	ASSY.HOSE W/TEE(RAD TO W/P)LP909CENGLANDI	TATA spare parts
252750100121	HOSE CLAMP	TATA spare parts
252750100124	RADIATOR ASSY	TATA spare parts
252750100127	RADIATOR ASSY	TATA spare parts
252750100128	WATER TANK AUX RHD	TATA spare parts
252750100130	RADIATOR ASSY	TATA spare parts
252750100131	CAP AUX WATER TANK	TATA spare parts
252750100134	VALVE UNIT ASSY	TATA spare parts
252750100135	TEE CONNECTOR	TATA spare parts
252750100136	HOSE WITH TUBE	TATA spare parts
252750100137	HOSE WITH TEE CONNECTOR	TATA spare parts
252750100138	AUX WATER TANK	TATA spare parts
252750100139	VALVE UNIT	TATA spare parts
252750100145	RADIATOR ASSY SFC	TATA spare parts
252750100146	TUBE WATER INLET ASSY	TATA spare parts
252750100151	RADIATOR ASSY	TATA spare parts
252750100156	ASSY RADIATOR BLOCK	TATA spare parts
252750100162	ASSY.RADIATOR-OFFER DRG.	TATA spare parts
252750100167	WATER TANK AUX	TATA spare parts
252750100170	RADIATOR ASSY	TATA spare parts
252750100171	ASSY RADIATOR BLOCK	TATA spare parts
252750100191	ASSY.CLAMP WITH SLEEVE (FOR VENT HOSES)	TATA spare parts
252750100212	ASSY AUX. WATER TANK	TATA spare parts
252750100213	ASSY RADIATOR:OFFER DRG-R.LOC AUX TANK	TATA spare parts
252750100214	ASSY CLAMP FRONT	TATA spare parts
252750100216	ASSY SUPPORT SUP.BOTM.RH	TATA spare parts
252750100220	ASSY SUPPORT (TO CLAMP VENT TUBES):LP709	TATA spare parts
252750100221	ASSY SUPPORT	TATA spare parts
252750100228	ASSY. AUXILLARY TANK BS1/2/3	TATA spare parts
252750100229	AUXILIARY WATER TANK BS2/3	TATA spare parts
252750100230	RADIATOR LPT 407	TATA spare parts
252750100231	RADIATOR 709E TURBO ALUMINIUM	TATA spare parts

252750100232	ASSY RADIATOR	TATA spare parts
252750100233	ASSY RADIATOR BLOCK	TATA spare parts
252750100235	ASSY. CLAMP (RH)	TATA spare parts
252750100238	ASSY SUPPORT LPTA 713TC	TATA spare parts
252750100239	ASSY BRACKET - AUX TANK LPT 1009	TATA spare parts
252750100242	ASSY RADIATOR BLOCK (OFFER DRAWING)	TATA spare parts
252750100243	ASSY CLAMP	TATA spare parts
252750100244	ASSY RADIATOR	TATA spare parts
252750100246	ASSY.RADIATOR	TATA spare parts
252750100249	SET- ASSY.AUX. TANK & MTG. CLAMPS BS2/3	TATA spare parts
252750100250	SET-ASSY.AUX.TANK & MTG.CLAMPS OFFER-LP	TATA spare parts
252750100251	AUX WATER TANK-BUS	TATA spare parts
252750100254	ASSY. CLAMP (LH)	TATA spare parts
252750100258	ASSY RADIATOR LPT 709E TURBO	TATA spare parts
252750100259	ASSY RADIATOR BLOCK LPT509 LPT407	TATA spare parts
252750100260	ASSY FILLER PIPE (HD)	TATA spare parts
252750100261	ASSY RADIATOR	TATA spare parts
252750100262	ASSY RADIATOR LPT407	TATA spare parts
252750100263	ASSY RADIATOR COMPLETE LPT407TURBO	TATA spare parts
252750100278	BRACKET - RH-RADIATOR TO BASE FRAME	TATA spare parts
252750100279	BRACKET - LH-RADIATOR TO BASE FRAME	TATA spare parts
252750100282	ASSY RADIATOR LP/LPT 709 TURBO	TATA spare parts
252750100283	SET-ASSY.RADIATOR & HOSE LP/LPT	TATA spare parts
252750100291	ASSY BRACKET-SUPPORT FOR RADIATOR	TATA spare parts
252750100297	ASSY RADIATOR -50KVA GENSET	TATA spare parts
252750100304	ASSY.RADIATOR WITH FANSHROUD-LPT-709	TATA spare parts
252750100308	ASSY RAD.W FANSHROUD& IC LP/LPT709	TATA spare parts
252750100309	ASSY.RADIATOR-LP/LPT-709	TATA spare parts
252750100313	ASSY.AUXILARY TANK WITH CAP	TATA spare parts
252750100318	ASSY RAD W'INTERCOOLER :SFC EX	TATA spare parts
252750100319	RADIATOR SUB ASSY :SFC709EX	TATA spare parts
252750100320	SET-ASSY.AUX.TANK & CLAMPS LP-LHD	TATA spare parts
252750100324	ASSY RADIATOR MOUNTING FRAME:497 BS:III	TATA spare parts
252750100327	DRAIN COCK ASSY	TATA spare parts
252750100328	PRESSURE CAP	TATA spare parts
252750100333	TOP TANK ASSY	TATA spare parts
252750100334	OUTLET PIPE	TATA spare parts
252750100335	DRAIN COCK	TATA spare parts
252750100336	PRESSURE CAP ON RADIATOR	TATA spare parts
252750100340	ASSY RADIATOR LP/LPT BS-III	TATA spare parts
252750100344	ASSY CLAMP WITH SLEEVE:497 TC IC BS-III	TATA spare parts
252750100347	ASSY. RADIATOR W/FAN & INTER COOLER BS3	TATA spare parts
252750100348	ASSY. BRACKET (FOR RADIATOR MTG. BOTTOM)	TATA spare parts
252750100349	ASSY. BRACKET R.H. (ON LONG MEMBER)	TATA spare parts
252750100350	ASSY. BRACKET L.H. (ON LONG MEMBER)	TATA spare parts
252750100351	ASSY. BRACKET RADIATOR MTG. TOP	TATA spare parts
252750100354	ASSY. RADIATOR (SFC 712) BS3	TATA spare parts

252750100357	ASSY RADIATOR LP/LPT1112:BSIII	TATA spare parts
252750100362	ASSY RAD MTG FRAME:497BSIIE:NL.TANK	TATA spare parts
252750100363	ASSY. RADIATOR 497TCIC BS2/3/4	TATA spare parts
252750100369	DRAIN COCK	TATA spare parts
252750100371	ASSY COOLANT FILL PIPE W PR CAP & CHAIN	TATA spare parts
252750100376	ASSEMBLY RADIATOR: LP709 BSIIE	TATA spare parts
252750100387	ASSY RAD MTG FRAME:LP/LPT1109:BSIIE	TATA spare parts
252750100389	ASSY. RADIATOR 497TCIC BS3	TATA spare parts
252750100390	ASSY RAD MTG FRAME LP/LPT1112 BSIII NLT	TATA spare parts
252750103201	ASSY. STUD	TATA spare parts
252750103305	BRACKET RADIATOR MTG ON LM	TATA spare parts
252750103307	SUPPORT BRACKET BS6-PH2	TATA spare parts
252750104201	CLAMP	TATA spare parts
252750104204	HOSE CLAMP 42 DIA	TATA spare parts
252750104205	HOSE CLAMP-34 DIA.	TATA spare parts
252750104206	HOSE CLAMP-27 DIA BS4	TATA spare parts
252750104207	HOSE CLAMP-42 DIA	TATA spare parts
252750104208	HOSE CLAMP-34 DIA BS4	TATA spare parts
252750104209	HOSE CLAMP-27 DIA BS4	TATA spare parts
252750104216	P TYPE CLAMP	TATA spare parts
252750104225	CLAMP BS6-PH2	TATA spare parts
252750105801	HOSE T STAT TO RADIATOR	TATA spare parts
252750105802	HOSE A/TANK TO WP 1400 MM	TATA spare parts
252750105804	RUBBER HOSE 165 MM	TATA spare parts
252750105805	HOSE T STAT TO CON 600 MM	TATA spare parts
252750105806	HOSE A/TANK TO CON 800 MM	TATA spare parts
252750105809	HOSE RAD TO A/TANK 1020MM	TATA spare parts
252750105810	HOSE THERMO-A/TANK 1220MM	TATA spare parts
252750105811	HOSE AIR VENT	TATA spare parts
252750105812	RUBBER HOSE WATER INLET	TATA spare parts
252750105813	HOSE A/TANK-W/P IN LHD900	TATA spare parts
252750105814	HOSE AUX TANK	TATA spare parts
252750105815	HOSE WATER INLET 1250MM	TATA spare parts
252750105816	HOSE RAD TO A/TANK 765MM	TATA spare parts
252750105817	HOSE THERMO-A/TANK 1120MM	TATA spare parts
252750105818	HOSE A/TANK TO VALVE UNIT	TATA spare parts
252750105819	RUBBER HOSE	TATA spare parts
252750105821	RUBBER HOSE WATER INLET	TATA spare parts
252750105822	HOSE RADIATOR TO W/PUMP	TATA spare parts
252750105823	HOSE W/PUMP TO RADIATOR	TATA spare parts
252750105826	HOSE (AUX TANK TO UPPER COOLING WATER LI	TATA spare parts
252750105827	HOSE A/TANK TO RAD 1125MM	TATA spare parts
252750105828	HOSE A/TANK TO UCL 1350MM	TATA spare parts
252750105829	HOSE A/TANK TO RAD 870MM	TATA spare parts
252750105830	HOSE A/TANK TO W/P 1420MM	TATA spare parts
252750105831	HOSE WATER INLET 1375MM	TATA spare parts
252750105832	RUB HOSE VENT 1450MM	TATA spare parts

252750105835	RUBBER HOSE	TATA spare parts
252750105836	HOSE A/TANK TO W/P 1100MM	TATA spare parts
252750105838	HOSE A/TANK TO RAD 970MM	TATA spare parts
252750105845	HOSE A/TANK TO RAD 1045MM	TATA spare parts
252750105846	HOSE A/TANK TO TH 1550MM	TATA spare parts
252750105847	RUBBER HOSE 1220 LONG 497 ENGINE	TATA spare parts
252750105850	HOSE	TATA spare parts
252750105851	RUBBER HOSE(L=420):A.TANK TO VENTTUBE LP	TATA spare parts
252750105852	RUBBER HOSE(L=470):A.TANK TO VENTTUBE LP	TATA spare parts
252750105853	RUBBER HOSE L=435 MM	TATA spare parts
252750105854	RUBBER HOSE L=845 MM	TATA spare parts
252750105856	HOSE AUX TANK	TATA spare parts
252750105857	HOSE AUX TANK	TATA spare parts
252750105858	HOSE-180 MM LG	TATA spare parts
252750105859	RUBBER HOSE (RADIATOR TO FILLER PIPE)	TATA spare parts
252750105860	RUBBER HOSE	TATA spare parts
252750105861	RUBBER HOSE (1770 LG)	TATA spare parts
252750105862	RUBBER HOSE - AUX TANK TO RAD 1685 LONG	TATA spare parts
252750105864	MOULDED HOSE	TATA spare parts
252750105865	RUBBER HOSE	TATA spare parts
252750105866	RUBBER HOSE	TATA spare parts
252750105867	HOSE-L=115 MM	TATA spare parts
252750105868	RUBBER HOSE-L=775	TATA spare parts
252750105869	HOSE-WATER PUMP TO RAD-TATA TOYO	TATA spare parts
252750105871	HOSE-RADIATOR TO WATER PUMP	TATA spare parts
252750105872	HOSE-RADIATOR TO THERMOSTAT	TATA spare parts
252750105875	RUBBER HOSE-RADIATOR TO WATER PUMP	TATA spare parts
252750105879	HOSE-UCWL TO THERMOSTAT	TATA spare parts
252750105880	RUBBER HOSE THERMOSTAT TO WATER PUMP	TATA spare parts
252750105881	RUBBER HOSE	TATA spare parts
252750105882	HOSE UCW LINE TO THERMOSTAT:EURO III	TATA spare parts
252750105883	RUBBER HOSE THERMOSTAT TO WATER PUMP	TATA spare parts
252750105884	HOSE THERMOSTAT TO RADIATOR:BS:III	TATA spare parts
252750105887	HOSE RADIATOR TO WATER PUMP:LP709BSIII	TATA spare parts
252750105888	RUBBER HOSE FOR VENTING L=425MM:LPT709	TATA spare parts
252750105889	RUBBER HOSE FOR VENTING:L=1075:LP709	TATA spare parts
252750105890	VENT TUBE TO UCW LPT 709 BS:III	TATA spare parts
252750105893	RUBBER HOSE (TH.STAT TO WATER PUMP)	TATA spare parts
252750105894	HOSE (WATER PUMP TO RADIATOR)	TATA spare parts
252750105896	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252750105897	HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
252750106303	FILLER CAP	TATA spare parts
252750106304	PRESSURE RELIEF CAP	TATA spare parts
252750106306	TUBE	TATA spare parts
252750106311	FILLER NECK	TATA spare parts
252750106312	FILLER PIPE	TATA spare parts
252750106313	PIPE	TATA spare parts



252750106316	PIPE (RADIATOR TO WATERPUMP) BSIV	TATA spare parts
252750106320	COOLANT FILLER PIPE ASSY	TATA spare parts
252750106322	PIPE CONN.(BETWEEN THER. TO RAD.) BS6	TATA spare parts
252750106901	TUBE AIR INLET	TATA spare parts
252750106902	TUBE WATER INLET	TATA spare parts
252750106903	OVER FLOW TUBE	TATA spare parts
252750106906	TUBE(PRES REL CAP)LPT709	TATA spare parts
252750106911	CONNECTOR RAD.TO W/PUMP	TATA spare parts
252750106912	TUBE AUX TANK	TATA spare parts
252750106913	PIPE 497 NA ENGINE	TATA spare parts
252750106914	PIPE (L=280MM)	TATA spare parts
252750106915	PIPE- 320 MM	TATA spare parts
252750106919	PIPE 20 O.D.X 1.5 THK	TATA spare parts
252750106920	PIPE 20 DIA X 1.5 TH	TATA spare parts
252750106921	VENT TUBE-TUBE 10 O.D.X 0.7THK SS:4040	TATA spare parts
252750106922	VENT TUBE-TUBE 10 O.D.X 0.7THK SS:4040	TATA spare parts
252750106926	VENT TUBE(TUBE 10 O.D.X 0.7 THK.SS:4040)	TATA spare parts
252750106927	VENT TUBE(TUBE 10 O.D.X 0.7 THK.SS:4040)	TATA spare parts
252750106928	PIPE(20 O.D.X 1.5 THK.CEW1 ANLD SS:4045)	TATA spare parts
252750106929	PIPE(20 O.D.X 1.5 THK.CEW1 ANLD SS:4045)	TATA spare parts
252750106933	PIPE(20 O.D.X1.5THK.CEW1 ANLD)A.TANK-RAD	TATA spare parts
252750106937	FILL PIPE AUX TANK TO RADIATOR:LP709	TATA spare parts
252750106938	FILL PIPE AUX TANK TO RAD:LPT BS-III	TATA spare parts
252750106939	FILL PIPE(20 ODX1.5THK CEW1 ANLD)LPT1113	TATA spare parts
252750106940	VENT TUBE AUX TANK TO UCW:LPT709 BSIII	TATA spare parts
252750106941	VENT TUBE AUX TANK TO RAD:LPT709 BSIII	TATA spare parts
252750106945	TUBE (PVC L190 2 THK 12 O.D.)	TATA spare parts
252750106965	VENT TUBE	TATA spare parts
252750106980	PIPE CONN.(BETWEEN THER. TO RAD.)	TATA spare parts
252750106998	PIPE BS6	TATA spare parts
252750106999	PIPE BS6	TATA spare parts
252750107503	RUBBER GROMMET (10 DIA.I.D.) :LP709	TATA spare parts
252750107504	RUBBER GROMMET (20 DIA.I.D.):LP 709	TATA spare parts
252750107701	GASKET AUX W/TANK CAP	TATA spare parts
252750108202	CLAMP FRONT A/TANK	TATA spare parts
252750108205	CLAMP	TATA spare parts
252750108211	CLAMP AUX. TANK	TATA spare parts
252750108220	COATED CLAMP (TO CLAMP VENT TUBES):LP709	TATA spare parts
252750108225	CLAMP REAR	TATA spare parts
252750108231	CLAMPING BKT. CLAMP PIPE ON LONG MEMBER	TATA spare parts
252750108232	CLAMPING BRACKET CLAMP PIPE TO RADIATOR	TATA spare parts
252750108235	BRACKET-SMALL	TATA spare parts
252750108239	CLAMP REAR-LP/LPT 709	TATA spare parts
252750108240	ASSY.CLAMP FRONT-LP/LPT 709	TATA spare parts
252750108241	SUPPORT	TATA spare parts
252750108242	PRESSURE CAP ON AUXILLARY TANK- 7 PSI	TATA spare parts
252750108243	PRESSURE CAP ON AUXILLARY TANK ( 14 PSI	TATA spare parts

252750108244	SUPPORT-TO SUPPORT FILL PIPE	TATA spare parts
252750108245	SUPPORT- FOR FILL PIPE	TATA spare parts
252750108246	CLAMP ( FOR FILLER PIPE )	TATA spare parts
252750108250	BRACKET (FOR 20 DIA.FILL PIPE)	TATA spare parts
252750108251	SUPPORT-FOR FILL PIPE & PIPE IC OUTLET	TATA spare parts
252750108252	SUPPORT (FOR FILL PIPE):LP709 EUROIII	TATA spare parts
252750108259	BRACKET LOWER(NO LOSS TANK)	TATA spare parts
252750108260	BRACKET UPPER(FOR NO LOSS TANK)	TATA spare parts
252750108264	SUPPORT PLATE (FOR COOLANT FILLING PIPE)	TATA spare parts
252750108265	SUPPORT PLATE(FOR COOLANT FILLING PIPE)	TATA spare parts
252750108266	BRACKET FILLER PIPE MOUNTING 497 IV	TATA spare parts
252750108267	BRACKET ( NO LOSS TANK MOUNTING )	TATA spare parts
252750108270	SUPPORT PLATE (FOR COOLANT FILLING PIPE)	TATA spare parts
252750108271	SUPPORT BRACKET (FOR COOLANT PIPE)	TATA spare parts
252750109903	RUBBER STRAP 300 MM	TATA spare parts
252750109904	RUBBER STRAP 340 MM	TATA spare parts
252750109908	RUBBER STRAP (L=352):LPT709	TATA spare parts
252750109913	RUBBER PACKING	TATA spare parts
252750109917	DRAIN COCK	TATA spare parts
252750110117	ASSY RADIATOR	TATA spare parts
252750110126	ASSY RAD W/OFR.& IC(VAVE)	TATA spare parts
252750110130	ASSY RAD:LPT709 BSIIEX	TATA spare parts
252750110133	ASSY. RADIATOR WITH INTERCOOLER BS3/4	TATA spare parts
252750110134	ASSY. RADIATOR BS3/4	TATA spare parts
252750110136	ASSY RAD MTG FRAME	TATA spare parts
252750110140	ASSY RAD (525 CORE) WITH IC & FRAME	TATA spare parts
252750110156	ASSY CLAMP WITH SLEEVE	TATA spare parts
252750110158	ASSY FILLER PIPE(SFC)	TATA spare parts
252750110160	ASSY RADIATOR SFC407	TATA spare parts
252750110169	ASSY RAD IC W/O FRAME (VAVE)	TATA spare parts
252750110171	ASSY RAD IC W/O FRAME (VAVE)	TATA spare parts
252750110172	ASSY RAD WITH IC LPO BUS	TATA spare parts
252750110173	ASSY RADIATOR (VAVE) LP/LPT 712	TATA spare parts
252750110174	ASSY RADIATOR (VAVE)	TATA spare parts
252750110175	ASSY. RADIATOR Y1 LPO BUS BS3/4	TATA spare parts
252750110190	ASSY COOLANT FILL PIPE	TATA spare parts
252750110193	ASSY. PIPE(UWCL TO RADIATOR)	TATA spare parts
252750110196	ASSY PIPE(RAD TO NO LOSS TANK PIPE)	TATA spare parts
252750110202	ASSY RADIATOR	TATA spare parts
252750110232	ASSY PIPE WITH CLAMP	TATA spare parts
252750110242	ASSY PIPE WITH CLAMP	TATA spare parts
252750110243	ASSY PIPE (UWCL TO RADIATOR)	TATA spare parts
252750110244	ASSY PIPE (UWCL TO RADIATOR)	TATA spare parts
252750110260	ASSY TUBE WITH CRIMPED HOSE	TATA spare parts
252750110285	RADIATOR ASSY WITH AUX TANK INTERCOOLER	TATA spare parts
252750110290	ASSY PIPE (AUX TANK TO RADIATOR)	TATA spare parts
252750110293	ASSY RADIATOR WITH IC LP FESLF	TATA spare parts

252750110297	PIPE (RADIATOR TO WATER PUMP)	TATA spare parts
252750110298	BRACKET (RADIATOR TO WATER PUMP)	TATA spare parts
252750110306	RESERVE TANK ASSY 6L LP FESLF	TATA spare parts
252750110310	PLASTIC RESERVE TANK ASSY BS6	TATA spare parts
252750110314	SHROUDç LPçFESLF	TATA spare parts
252750110316	TOPçBRACKET	TATA spare parts
252750110326	RADIATOR ASSY WITH INTERCOOLER	TATA spare parts
252750110337	ASSY.RAD. WITH AUX.TANK	TATA spare parts
252750110339	RADIATOR ASSY WITH INTERCOOLER	TATA spare parts
252750110340	RADIATOR ASSY CORE	TATA spare parts
252750110341	PIPE (ASSY FILL PIPE WITH CRIMPED HOSE)	TATA spare parts
252750110343	RADIATOR ASSY	TATA spare parts
252750110347	SHROUD	TATA spare parts
252750110353	SHROUD	TATA spare parts
252750110355	RADIATOR ASSY	TATA spare parts
252750110358	PIPE ASSY VENT LINE	TATA spare parts
252750110360	FILLER NECK ASSY	TATA spare parts
252750110362	VENT PIPE ASSY WITH CLAMP	TATA spare parts
252750110367	PIPE ASSY	TATA spare parts
252750110370	BRACKET ASSY	TATA spare parts
252750110371	NO LOSS TANK ASSY	TATA spare parts
252750110372	PIPE ASSY	TATA spare parts
252750110374	RADIATOR ASSY WITH INTERCOOLER	TATA spare parts
252750110375	RADIATOR ASSY WITH FRAME	TATA spare parts
252750110389	PIPE ASSY THERMOSTAT TO RADIATOR	TATA spare parts
252750110391	RADIATOR ASSY WITH INTERCOOLER	TATA spare parts
252750110392	PIPE ASSY UCWL TO RADIATOR	TATA spare parts
252750113301	SUPPORT BRACKET (VENT PIPE)	TATA spare parts
252750115807	RUBBER HOSE (RAD TO W.P):MECH FEED PUMP	TATA spare parts
252750115809	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252750115811	HOSE (FILLER PIPE TO NOLOSS TANK	TATA spare parts
252750115814	RUBBER HOSE (TS TO WATER PUMP) 497 IV	TATA spare parts
252750115815	RUBBER HOSE (UWCL TO THERMOSTAT)	TATA spare parts
252750115816	RUBBER HOSE(THERMOSTATE TO FILLER PIPE)	TATA spare parts
252750115817	HOSE RADIATOR TO WATER PUMP	TATA spare parts
252750115818	RADIATOR TOP HOSE	TATA spare parts
252750115820	RUBBER HOSE ( THERMOSTAT WATER PUMP )	TATA spare parts
252750115821	RUBBER HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
252750115822	RUBBER HOSE (THERMOSTAT TO WATER PUMP)	TATA spare parts
252750115823	HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
252750115826	RADIATOR BOTTOM HOSE	TATA spare parts
252750115827	RADIATOR TOP HOSE	TATA spare parts
252750115828	HOSE (NO LOSS TANK TO FILLER PIPE)	TATA spare parts
252750115829	HOSE ( COOLANT FILLING PIPE TO RADIATOR)	TATA spare parts
252750115832	HOSE ( WATERPUMP TO RADIATOR)	TATA spare parts
252750115840	HOSE ( RADIATOR TO WATER PUMP )	TATA spare parts
252750115841	HOSE ( PIPE TO WATER PUMP )	TATA spare parts

252750115848	HOSE (UWCL TO RADIATOR)	TATA spare parts
252750115849	RUBBER HOSE (RADIATOR TO NO LOSS TANK)	TATA spare parts
252750115850	HOSE ( RADIATOR TO WATER PUMP )	TATA spare parts
252750115851	HOSE ( RADIATOR TO PIPE )	TATA spare parts
252750115853	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252750115854	HOSE (VENT LINE TO RADIATOR)	TATA spare parts
252750115860	HOSE ( RADIATOR TO PIPE )	TATA spare parts
252750115861	HOSE (PIPE TO FILLER NECK)	TATA spare parts
252750115862	HOSE(RADIATOR TO WATER PUMP)	TATA spare parts
252750115863	HOSE(THERMOSTAT TO RADIATOR)	TATA spare parts
252750115864	HOSE (RAD TO ASSY PIPE)	TATA spare parts
252750115865	HOSE(ASSY PIPE TO WATER PUMP)	TATA spare parts
252750115866	HOSE (RAD TO ASSY PIPE)	TATA spare parts
252750115868	HOSE (RAD TO WATER PUMP)	TATA spare parts
252750115869	HOSE (THERMOSTAT TO RAD)	TATA spare parts
252750115870	HOSE (UCWL TO THERMOSTAT)	TATA spare parts
252750115871	HOSE WATER PUMP TO RAD	TATA spare parts
252750115873	HOSE (EGR VENT TO RAD)	TATA spare parts
252750115885	HOSE (ASSY. PIPE TO WATER PUMP)	TATA spare parts
252750115895	HOSE (RADIATOR TO FILLER PIPE)	TATA spare parts
252750115897	HOSE (FILLER NECK TO RAD.)	TATA spare parts
252750115898	HOSE (RAD. TO ASSY PIPE)	TATA spare parts
252750116911	T-TUBE BS6-PH2	TATA spare parts
252750116912	PIPE BS6	TATA spare parts
252750116970	PIPE (VENT PIPE FOR RADIATOR TC)	TATA spare parts
252750116973	VENT HOSE THERMOSTAT TO RADIATOR BS6	TATA spare parts
252750118206	BRACKET RADIATOR ASSY MTG LH	TATA spare parts
252750118207	BRACKET RADIATOR ASSY MTG RH	TATA spare parts
252750118219	SUPPORT PLATE COOLANT FILLER PIPE MTG BS	TATA spare parts
252750118224	SUPPORT BRACKET AIR INTAKE PIPE BS6-PH2	TATA spare parts
252750120107	SUPPORT BRACKET COOLANT FILLER PIPE	TATA spare parts
252750120123	ENGINE COOLING SYSTEM	TATA spare parts
252750120124	SET-RADIATOR & INTERCOOLER	TATA spare parts
252750120125	RADIATOR ASSY	TATA spare parts
252750120138	RADIATOR ASSY WITH IC & FAN SHROUD ASSY	TATA spare parts
252750120142	TIE ROD ASSY RADIATOR MTG	TATA spare parts
252750120144	COOLANT FILLER PIPE ASSY	TATA spare parts
252750120145	RADIATOR ASSY	TATA spare parts
252750120146	RADIATOR ASSY WITH INTERCOOLER & SHROUD	TATA spare parts
252750120147	RADIATOR ASSY	TATA spare parts
252750120151	SET ASSY RAD. & INTERCOOLER	TATA spare parts
252750120158	RADIATOR ASSY	TATA spare parts
252750120159	SHROUD ASSY WITH FLAP	TATA spare parts
252750120161	FRAME ASSY WITH BRACKET RADIATOR MTG BS6	TATA spare parts
252750120163	RADIATOR ASSY WITH INTERCOOLER & SHROUD	TATA spare parts
252750120164	COOLANT FILLER PIPE ASSY WITH PR CAP BS6	TATA spare parts
252750120165	SET-RADIATOR & INTERCOOLER	TATA spare parts

252750120166	PIPE ASSY WITH BRACKET	TATA spare parts
252750120167	RADIATOR ASSYBS6	TATA spare parts
252750120168	FILL PIPE ASSY (CRIMPED) BS6	TATA spare parts
252750120170	RADIATOR WITH INTERCOOLER SHROUD & BKT B	TATA spare parts
252750120173	FRAME ASSY WITH BRKT RAD. MTG BS6-PH2	TATA spare parts
252750120187	FRAME ASSY WITH BRACKET RADIATOR MTG BS6	TATA spare parts
252750120189	RADIATOR ASSY	TATA spare parts
252750120190	PRESSURE CAP	TATA spare parts
252750120191	RECOVERY BOTTLE ASSY	TATA spare parts
252750120201	TUBE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
252750120203	RADIATOR ASSY WITH INTERCOOLER - SHROUD	TATA spare parts
252750120211	BRACKET ASSY FILLER NECK MTG BS6-PH2	TATA spare parts
252750120212	FILLER NECK ASSY WITH CAP BS6-PH2	TATA spare parts
252750120214	FILLER NECK ASSY WITH CAP BS6-PH2	TATA spare parts
252750120220	BRACKET ASSY FILLER NECK MTG BS6-PH2	TATA spare parts
252750120223	PIPE ASSY RADIATOR TO NO LOSS TANK PIPE	TATA spare parts
252750125801	HOSE (RADIATOR TO ASSY PIPE)	TATA spare parts
252750125803	HOSE (RAD TO WP)	TATA spare parts
252750125804	HOSE (THERMOSTAT TO PIPE CONNECTOR)	TATA spare parts
252750125805	HOSE (CONNECTOR TO RAD)	TATA spare parts
252750125807	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252750125808	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
252750125810	HOSE PIPE TO WATER PUMP	TATA spare parts
252750125816	RUBBER HOSE (AUX TANK TO RADIATOR)	TATA spare parts
252750125820	HOSE PIPE TO WATER PUMP	TATA spare parts
252750125822	HOSE (PIPE RADIATOR TO WATER PUMP)	TATA spare parts
252750125844	HOSE (FILLER NECK TO AUX. TANK)	TATA spare parts
252750125853	HOSE FILLER NECK TO AUX TANK	TATA spare parts
252750125854	HOSE(RADIATOR TO ASSLY PIPE)	TATA spare parts
252750125859	HOSE RADIATOR TO WATER PUMP	TATA spare parts
252750125864	HOSE RADIATOR TO PIPE WATER INTAKE	TATA spare parts
252750125865	RUBBER HOSE TSTO RADIATOR	TATA spare parts
252750125867	VENTHOSE THERMO STATTO RADIATOR	TATA spare parts
252750125874	HOSE CONNECTOR TO RADIATOR	TATA spare parts
252750125875	HOSE THERMOSTAT TO PIPE CONNECTOR	TATA spare parts
252750125876	HOSE	TATA spare parts
252750125882	HOSE	TATA spare parts
252750125890	HOSE RADIATOR TO WATER PUMP BS6	TATA spare parts
252750125891	HOSE BS6	TATA spare parts
252750125892	HOSE CONNECTOR TO RADIATOR BS6	TATA spare parts
252750125893	VENT TUBE BS6	TATA spare parts
252750125894	HOSE THERMOSTAT TO PIPE CONNECTOR BS6	TATA spare parts
252750125896	RUBBER HOSE THERMOSTAT TO RADIATOR	TATA spare parts
252750125897	HOSE RADIATOR TO WATER PUMP BS6-PH2	TATA spare parts
252750125898	HOSE THERMOSTART TO RADIATOR BS6	TATA spare parts
252750125899	HOSE THERMOSTART TO RADIATOR BS6	TATA spare parts
252750135801	HOSE RADIATOR TO WATER PUMP BS6	TATA spare parts

252750135813	HOSE BS6	TATA spare parts
252750135814	HOSE BS6	TATA spare parts
252750135815	HOSE BS6	TATA spare parts
252750135816	HOSE BS6	TATA spare parts
252750135817	FILLER HOSE BS6-PH2	TATA spare parts
252750135824	HOSE RADIATOR TO WATER PUMP BS6-PH2	TATA spare parts
252750135828	HOSE FILLER NECK TO RADIATOR BS6-PH2	TATA spare parts
252750135829	HOSE NO LOSS TANK TO FILLER NECK BS6-PH2	TATA spare parts
252750135840	HOSE BS6-PH2	TATA spare parts
252750135841	HOSE BS6-PH2	TATA spare parts
252750135842	HOSE BS6-PH2	TATA spare parts
252750135843	HOSE THERMOSTAT TO FILLER NECK BS6-PH2	TATA spare parts
252750404201	CLAMP EGR LINE	TATA spare parts
252750404202	CLAMP BS6-PH2	TATA spare parts
252750500103	FAN SHROUD PLASTIC	TATA spare parts
252750500108	ASSY FAN SHROUD COMPLETE:SFC709EX	TATA spare parts
252750500113	ASSY FAN SHROUD COMPLETE:SFC407	TATA spare parts
252750500114	FAN SHROUD COMPLETE SFC407	TATA spare parts
252750500119	ASSY. FAN SHROUD	TATA spare parts
252750506303	FAN SHROUD LPT1109	TATA spare parts
252750506305	FAN SHROUD PLASTIC 709 CMVR	TATA spare parts
252750506306	FAN SHROUD PLASTIC 709 CMVR	TATA spare parts
252750506307	FAN SHROUD	TATA spare parts
252750506310	FAN SHROUD 515 DIA FAN:497 TCIC BS:III	TATA spare parts
252750506311	FAN SHROUD (470 DIA FAN):LP/LPT BS:II EX	TATA spare parts
252750506312	FAN SHROUD (515 DIA FAN):SFC712 BS:III	TATA spare parts
252750506313	FAN SHROUD(515 DIA FAN):LP/LPT1112	TATA spare parts
252750506318	FAN SHROUD (550 DIA JET RING FAN)	TATA spare parts
252750506323	FAN SHROUD ( 550 DIA VISSCUSS FAN)	TATA spare parts
252750506329	FAN SHROUD( 430 DIA VISCOUS FAN )	TATA spare parts
252750506333	FAN SHROUD	TATA spare parts
252750506340	FAN SHROUD C TYPE (550 DIA VISCOUS FAN)	TATA spare parts
252750506361	FAN SHROUD	TATA spare parts
252750506365	FAN SHROUD	TATA spare parts
252750506367	SHROUD-FRP BS6	TATA spare parts
252750506370	FAN SHROUD BS6	TATA spare parts
252750506372	FAN SHROUD BS6	TATA spare parts
252750506373	FAN SHROUD BS6-PH2	TATA spare parts
252750506374	FAN SHROUD BS6-PH2	TATA spare parts
252750990105	COOL SYS KIT 709 BUS LHD	TATA spare parts
252750990106	COOL SYS KIT 709 BUS RHD	TATA spare parts
252750990107	COOL SYS KIT 709 TRUCKLHD	TATA spare parts
252750990108	COOL SYS KIT 709 TRUCKRHD	TATA spare parts
252754200111	WIRING HARNESS	TATA spare parts
252754209904	EGR CONTROLLER FOR 76 / 86 PS	TATA spare parts
252754209905	EGR CONTROLLER FOR 101 PS	TATA spare parts
252754209906	ECU 62.5 KVA	TATA spare parts

252754209907	ECU?? 50 KVA	TATA spare parts
252754209908	ECU-40KVA (EGR)	TATA spare parts
252754209909	ECU-35KVA(EGR)	TATA spare parts
252754620101	WIRING HARNESS ENGINE	TATA spare parts
252754623301	BRACKET	TATA spare parts
252901103703	LINER CYLINDER 695DI	TATA spare parts
252901130101	OIL SUMP ASSY	TATA spare parts
252901150101	ELBOW AIR INLET	TATA spare parts
252901153803	COVER CYLINDER HEAD	TATA spare parts
252901155301	GASKET CYLINDER HEAD	TATA spare parts
252901170101	DIPSTICK	TATA spare parts
252901170104	TOP COVER W/POINTER	TATA spare parts
252901175801	TUBE OIL FILLER	TATA spare parts
252901176903	TUBE	TATA spare parts
252903100108	CRANKSHAFT W/CWT	TATA spare parts
252903140140	RING OIL CONF.	TATA spare parts
252903140148	SET PISTON W/RINGS STD	TATA spare parts
252903140149	SET PISTON RINGS STD	TATA spare parts
252903141021	BARE PISTON 1312/807 STD	TATA spare parts
252903141022	PISTON STD 94.90D	TATA spare parts
252903146701	PIN PISTON	TATA spare parts
252903149931	RING PISTON KEYSTONE	TATA spare parts
252903149932	2/3RD RING 1312/807	TATA spare parts
252903150102	CONNECTING ROD	TATA spare parts
252907100101	F I P ASSY.	TATA spare parts
252907140102	SET FUEL PR LINES	TATA spare parts
252909120103	OVERFLOW LINE	TATA spare parts
252909120104	KIT FUEL LINE	TATA spare parts
252909130109	AIR FILTER ASSY	TATA spare parts
252909130128	BKT W/PVC SLEEVING	TATA spare parts
252909130131	PRECLEANER	TATA spare parts
252909130141	PRECLEANER	TATA spare parts
252909130145	AIR FILTER ASSY	TATA spare parts
252909133312	BRACKET	TATA spare parts
252909133313	SUPPORT BRACKET AIR FILTE	TATA spare parts
252909135804	RUBBER BELLOW	TATA spare parts
252909135805	HOSE AIR INTAKE	TATA spare parts
252909136302	RUBBER STRAP	TATA spare parts
252909136310	RUBBER SEAL	TATA spare parts
252909138219	PROTECTIVE COVER	TATA spare parts
252918150101	ASSY STRAINER OIL PUMP	TATA spare parts
252920143702	INTERMEDIATE RING FAN	TATA spare parts
252922125101	ENG MTG ARM FRONT	TATA spare parts
252925103701	CLUTCH HOUSING GBC40	TATA spare parts
252925103703	CLUTCH HOUSING 310DIA(MECH)	TATA spare parts
252925103706	CLUTCH HSG.310D	TATA spare parts
252925103707	CLUTCH HSG.	TATA spare parts

252940100106	PIPE AIR	TATA spare parts
252950000101	RADIATOR FRAME	TATA spare parts
252950000102	RADIATOR FRAME	TATA spare parts
252950006901	SPACER TUBE	TATA spare parts
252950105802	RUBBER HOSE	TATA spare parts
252954400102	INDICATOR LAMP LOW AIR PR	TATA spare parts
252999000101	KIT ENG OVERHAUL GASKETS	TATA spare parts
252999000102	KIT ENG OVERHAUL GASKETS	TATA spare parts
252999000103	KIT DECARBONISING GASKETS	TATA spare parts
253210100001	REVERSE HORN (12V)(W.P COUPLER)	TATA spare parts
253220000001	STEP LAMP 12V 7048 SLA TM---1/BUS	TATA spare parts
253220010001	SUMO NO. PLATE LAMP	TATA spare parts
253300000003	ENGINE ASSY 6SP	TATA spare parts
253301000104	ENGINE ASSY 6SP LHD PS	TATA spare parts
253301100111	CYLINDER BLOCK 6SP	TATA spare parts
253301130108	OIL SUMP ASSY	TATA spare parts
253301135304	GASKET OIL SUMP RIGHT	TATA spare parts
253301135305	GASKET OIL SUMP LEFT	TATA spare parts
253301140101	COVER PUSH ROD CHAMBER	TATA spare parts
253301145301	GASKET PUSH ROD CH COVER	TATA spare parts
253301150101	CYLINDER HEAD W/VALVES	TATA spare parts
253301150102	CYLINDER HEAD W/O VALVES	TATA spare parts
253301150103	COVER CYLINDER HEAD	TATA spare parts
253301150104	AIR INTAKE ELBOW	TATA spare parts
253301150109	COMBI BOLT ASSY	TATA spare parts
253301150113	COVER CYLINDER HEAD	TATA spare parts
253301150114	ELBOW AIR INTAKE	TATA spare parts
253301153202	STRETCH BOLT	TATA spare parts
253301155301	GASKET CYLINDER HEAD	TATA spare parts
253301155302	GASKET INTAKE ELBOW	TATA spare parts
253301600101	HALF ENG 6SP	TATA spare parts
253301990101	KIT ENG OVERHAUL GASKETS	TATA spare parts
253301990102	KIT DECARBONISING GASKETS	TATA spare parts
253301990103	KIT OIL SUMP GASKETS	TATA spare parts
253303100101	CRANKSHAFT STD W/CWT	TATA spare parts
253303100104	CRANKSHAFT 6SP CPN1	TATA spare parts
253303103201	BOLT COUNTERWEIGHT	TATA spare parts
253303107801	OIL SEAL CRANKSHAFT FRT	TATA spare parts
253303110103	FLYWHEEL W/RING GEAR	TATA spare parts
253303115401	RING GEAR FLYWHEEL	TATA spare parts
253303120101	SET OF MN.BRG. SHELL UPPER & LOWER STD	TATA spare parts
253303120102	SET OF MN. BRG. SHELL UPPER & LOWER STD1	TATA spare parts
253303130102	VIBRATION DAMPER	TATA spare parts
253303130106	VIBRATION DAMPER 2GR	TATA spare parts
253303130107	ASSY.VIBRATION DAMPER	TATA spare parts
253303130108	ASSY.VIBRATION DAMPER	TATA spare parts
253303140101	OIL CONTROL RING	TATA spare parts



253303149901	RING COMP GR1 NPR	TATA spare parts
253303149902	RING COMP GR2 NPR	TATA spare parts
253303990101	SET PISTON W/RINGS STD	TATA spare parts
253303990105	SET PISTON RINGS STD NPR	TATA spare parts
253303990106	SET OF MAIN BRG STD	TATA spare parts
253303990117	SET PISTON RINGS 6SP	TATA spare parts
253303990120	SET OF MN. BRG. SHELL UPPER & LOWER R/S1	TATA spare parts
253303990121	SET OF MN. BRG.SHELL UPPER & LOWER R/S2	TATA spare parts
253303990122	SET OF MN. BRG. SHELL UPPER & LOWER R/S3	TATA spare parts
253303990123	SET M.BRG.HALF U/L.R/S.4	TATA spare parts
253305100102	CAMSHAFT ASSY STD	TATA spare parts
253305100103	CAM SHAFT 608 N1	TATA spare parts
253307100102	F I PUMP W/LEVER	TATA spare parts
253307100106	FIP W/BANJO	TATA spare parts
253307140101	SET FUEL PR LINES	TATA spare parts
253307140104	PRESSURE LINE 3	TATA spare parts
253307140106	PRESSURE LINE 5	TATA spare parts
253309113701	BRACKET FUEL FILTER	TATA spare parts
253309120102	FUEL LINE ASSY	TATA spare parts
253309120104	FUEL LINE ASSY	TATA spare parts
253313100102	CYLINDER HEAD A/COMP 77D	TATA spare parts
253313103701	CYLINDER HEAD A/COMP NEW	TATA spare parts
253315140108	CLAMPING ROD 38MM OFFSET	TATA spare parts
253315140109	ASSY CLAMP ROD COMPLETE [38 MM OFFSET]	TATA spare parts
253315140115	ASSY. BRACKET (ALTERNATOR MOUNTING)	TATA spare parts
253315143702	BRACKET-FOR 65AMP ALTERNATOR	TATA spare parts
253315144204	CLAMPING PIECE	TATA spare parts
253318100101	OIL PUMP ASSY	TATA spare parts
253318100102	ASSY OIL PUMP(WITHOUT OIL PUMP COVER)	TATA spare parts
253318100103	OIL PUMP ASSY	TATA spare parts
253318103701	HOUSING OIL PUMP	TATA spare parts
253318170103	OIL COOLER ASSY	TATA spare parts
253318173703	COVER OIL COOLER	TATA spare parts
253318175302	GASKET OIL COOLER	TATA spare parts
253318175303	GASKET OIL COOLER COVER	TATA spare parts
253318178001	COLLAR SCREW	TATA spare parts
253320110101	PULLEY WATER PUMP	TATA spare parts
253320120102	UPP.COOL.WATER LINE	TATA spare parts
253320120105	ASSY.THERMOSTAT 76 DEG SOT	TATA spare parts
253320137003	PULLEY WATER PUMP	TATA spare parts
253323100101	STEERING PUMP	TATA spare parts
253323400102	ASSY BKT POWER STRG-RHD	TATA spare parts
253323400103	TENSIONER ASSY	TATA spare parts
253325103701	CLUTCH HSG.	TATA spare parts
253325108201	CLUTCH HSG.LOW.PART	TATA spare parts
253350000101	PAD RADIATOR MTG BOTTOM	TATA spare parts
253350000106	PAD RADIATOR MTG TOP	TATA spare parts

253350000108	SUPPORT PLATE W/CHAIN	TATA spare parts
253350000116	PAD RADIATOR MTG BOTTOM	TATA spare parts
253350000118	PAD RADIATOR MTG TOP	TATA spare parts
253350100104	ASSY.RAD.WITH DRAIN COCK & CAP	TATA spare parts
253350100108	RADIATOR ASSY	TATA spare parts
253350100116	ASSY.RAD.WITH DRAIN COCK & CAP	TATA spare parts
253350100119	ASSY.RAD.WITH DRAIN COCK & CAP	TATA spare parts
2533N1990101	ENG OVERHAUL KIT	TATA spare parts
2533N1990102	DE GASKET KIT	TATA spare parts
253401000009	ENGINE ASSY 497SP	TATA spare parts
253401000010	ENGINE ASSY 497SP	TATA spare parts
253401000101	ENGINE COMPLETE 407	TATA spare parts
253401000118	ENGINE 497SP INDU H/COMBN	TATA spare parts
253401000134	ENGINE ASSY 4SP SFC RHD	TATA spare parts
253401000136	ENGINE ASSY 4SP LP/LPTRHD	TATA spare parts
253401000151	ENGINE 4SP W/CLUTCH CMVR 2000	TATA spare parts
253401000153	ASSY ENG COMP W/CLUTCH-LPT407 CMVR 2000	TATA spare parts
253401000154	ENGINE 4SP TC	TATA spare parts
253401000156	ASSY.ENG.COMPLETE WITH CLUTCH-4SP RTV-R	TATA spare parts
253401000159	ENGINE ASSY SFC407 EURO-II	TATA spare parts
253401000167	ENGINE4SP TC CMVR2000 407 FACELESS	TATA spare parts
253401000173	ASSY ENGINE 4SP LP407-EUROII	TATA spare parts
253401000174	ENGINE 4SP TC EURO II	TATA spare parts
253401000175	ASSY. ENG SFC 407 BUS EURO II	TATA spare parts
253401000178	ASSY. ENGINE LP407 CNG RHD	TATA spare parts
253401000180	ASSY ENGINE 4SP NA FOR BANGLADESH 35A	TATA spare parts
253401000181	ASSY ENGINE 4SP NA CMVR FACELESS	TATA spare parts
253401000183	ASSY ENGINE 207DI AAZAADI W/POWER STRG	TATA spare parts
253401000184	ASSY ENGINE 207DI AAZAADI W/MECH STRG	TATA spare parts
253401000190	ASSY.ENGINE COMPLETE - SFC 4X4-RHD	TATA spare parts
253401000192	ASSY.ENG SFC 407LHD EURO II HD PS	TATA spare parts
253401000193	ASSY. ENGINE 4SP RTV HIGH TORQUE NA	TATA spare parts
253401000204	ASSY ENG 407 SK BS III WITH PS	TATA spare parts
253401000209	ASSY. ENGINE COMPLETE WITH CLUTCH (407 C	TATA spare parts
253401000212	ASSY.ENGINE COMPLETE-SFC407(PST HD)-RHD	TATA spare parts
253401000214	ASSY.ENGINE 407.BS-III SFC-RHD	TATA spare parts
253401000214YA	YELLOW AGGR FOR 4SP BSIII ENGINE ASSY	TATA spare parts
253401000217	ASSY.ENG COMP.LP410 TCIC BS-III	TATA spare parts
253401000220	ASSY ENG LPT 407 EURO II EX	TATA spare parts
253401000222	ASSY.ENG.207 DI EURO -II W/O PS EX	TATA spare parts
253401000223	ASSY ENG 207 DI EURO -II WITH PS EX	TATA spare parts
253401000225	ASSY ENG 207 DI EURO -III W/O PS	TATA spare parts
253401000226	ASSY ENG 207 DI EURO -III WITH PS	TATA spare parts
253401000235	ASSY. ENG COMP. WITH CLUTCH HSG	TATA spare parts
253401000236	ASSY.ENG.COMP.SFC407 BS-II 4X4 W/O PSTRG	TATA spare parts
253401000241	ASSY ENG COMP W/ CL HSG TCD REDN & P/STG	TATA spare parts
253401000242	ASSY.4SPNA ENGINE COMPL FOR GENSET 40KVA	TATA spare parts

253401000243	ASSY ENG.COMP.4SPTC BS-II WITH P.STRG	TATA spare parts
253401000244	ASSY.ENG.COMP. LP407CNG BSIII-RHD	TATA spare parts
253401000245	ENG.COMP. SFC407CNG BSIII-RHD	TATA spare parts
253401000249	ASSY.ENGINE COMPLETE	TATA spare parts
253401000250	ASSY ENG COMP (NOLOSS TABNK) LP407	TATA spare parts
253401000258	ASSY. ENG.COMPLETE 4SPTC BSII P.STRG HD	TATA spare parts
253401000260	ASSY.ENG.COMP. 4SP TCIC BSIII LP410	TATA spare parts
253401000261	ASSY.ENG.COMP.4SP TCIC BS3	TATA spare parts
253401000262	ASSY ENG LPT407 BSII EX NLT	TATA spare parts
253401000263	ASSY ENG.COMP. DICOR E-III SPRINT	TATA spare parts
253401000264	ASSY ENG.COMP DICOR E-II SPRINT	TATA spare parts
253401000265	ASSY.ENG. 207DI EII EX W/E-FAN PS S.A.	TATA spare parts
253401000265YA	YELLOW AGGREGATE FOR ASSY.ENG. 207DI EII	TATA spare parts
253401000269	ASSY.ENG.COMP LP/LPK 407 BS-II	TATA spare parts
253401000274	ASSY ENG.COPM.LPK 407 BSIIEX(TIPPER)PSTG	TATA spare parts
253401000279	ASSY.ENG.COMPL.3L DICOR BS-III WASTEGATE	TATA spare parts
253401000280	ASSY.ENG.COMPL.3L DICOR E-II WASTEGATE	TATA spare parts
253401000285	ASSY.ENG.COMP.3L DICOR E-II WG LHD	TATA spare parts
253401000299	ASSY.ENG W/CL HSG.4SP NABS2-207DI-EX+PS	TATA spare parts
253401000300	ASSY.ENG W/CL HSG 4SPNABS3 207DI-EX+PS	TATA spare parts
253401000301	ASSY.ENG. COMPLETE DICOR E-II COLOMBIA	TATA spare parts
253401000308	ASSY ENG.COMP.4SPTC BS-II WITH P.STRG	TATA spare parts
253401000311	ASSY ENG.COMP.4SPTC BS-II	TATA spare parts
253401000317	ASSY ENGINE COMPLETE GODREJ 4SP NA	TATA spare parts
253401000320	ASSY.ENG.COMP SK407 BS-II WPSTG TIPPER	TATA spare parts
253401000323	ASSY ENGINE COMPLETE 4SP TCIC BS-III	TATA spare parts
253401000326	207 DI TC CR BS-IV - PICKUP	TATA spare parts
253401000331	ASSY. ENGINE COMPLETE	TATA spare parts
253401000336	ENGINE LPT 407 LHD BSII WITH PS	TATA spare parts
253401000337	ASSY. ENG. 4SP DICOR	TATA spare parts
253401000338	ENGINE ASSY	TATA spare parts
253401000342	ASSY.ENGINE 4SPTCIC BSIII(MECH.FIE)	TATA spare parts
253401000344	ENGINE W/CL HSG XENON RX W/PS 4SP	TATA spare parts
253401000348	ASSY ENGINE 4SPTCIC BSIII(MFIE)	TATA spare parts
253401000353	ASSY ENGINE 207DI/28 EX 4SPNA BS1 MS LOW	TATA spare parts
253401000355	ASSY.ENGINE 4SPCR BSIV 85PS W/O P.STRG	TATA spare parts
253401000358	ASSY.ENG.COMP.W/CL.HSG.4SPTC CR BS4+PS	TATA spare parts
253401000360	ASSY.ENG.COMP.WITH CL.HSG.4SP CR BS-IV	TATA spare parts
253401000362	ENGINE COMP. W/ CL.HSG. 207DI E-II	TATA spare parts
253401000363	ENGINE 4SPTCIC BSIII(MECH.FIE)LP407 W/O	TATA spare parts
253401000365	ASSY. ENG COMPLETE	TATA spare parts
253401000369	ENGINE COMPLETE BSIII	TATA spare parts
253401000371	ASSY ENGINE 4SPTCIC BSIII MFIE LP709	TATA spare parts
253401000381	ENGINE ASSY COMP 4SPTC XENON	TATA spare parts
253401000385	ENGINE ASSY. 4SPTC EURO-II	TATA spare parts
253401000390	ENGINE COMP 497S PTC7642KW@1500GOEM	TATA spare parts
253401000391	ASSY ENG COMP 497SPTC78 30KW @1500 GOEM	TATA spare parts

253401010101	ENGINE ASSY W/CLU. HSG. XENON RX BSIV	TATA spare parts
253401010103	ENGINE ASSY 4SPCR BS4 XENON EX(HVAC+PS)	TATA spare parts
253401010104	ENGINE ASSY 4SPCR BS4 XENON RX(HVAC+PS)	TATA spare parts
253401010112	ENGINE XENON RX BS 3 W PS & 260 DIA CLUT	TATA spare parts
253401010114	ENGINE ASSY	TATA spare parts
253401010118	ENGINE ASSY	TATA spare parts
253401010119	ENGINE ASSY	TATA spare parts
253401010121	ENGINE ASSY 4SPCR BS-IV+PS 207DI	TATA spare parts
253401010122	ENGINE ASSY 4SPNA 207DI RX	TATA spare parts
253401010123	ENGINE 4SPTCIC BSIII MFIE LPT708 PS	TATA spare parts
253401010128	ENGINE ASSY	TATA spare parts
253401010129	ENGINE SK407EX/31WB 4SPCR BS-IV PTO TIP	TATA spare parts
253401010131	ASSY ENGINE	TATA spare parts
253401010137	ASSY.ENGINE 4SPCR BSIV 85PS SFC709 WITH	TATA spare parts
253401010141	ENGINE LPT407EX2/38WB 4SP CR BS-IV	TATA spare parts
253401010142	ENGINE ASSY	TATA spare parts
253401010145	ENGINE ASSY	TATA spare parts
253401010147	ENGINE ASSY	TATA spare parts
253401010148	ENGINE ASSY	TATA spare parts
253401010153	ASSY.ENGINE 4SPCR BSIV 85PS SFC407 BUS T	TATA spare parts
253401010165	ENGINE ASSY	TATA spare parts
253401010170	ENGINE ASSY BS6	TATA spare parts
253401010172	ENGINE ASSY BS6	TATA spare parts
253401010173	ENGINE ASSY	TATA spare parts
253401010174	ENGINE ASSY 4SPCR ULTRA T.7 BS6	TATA spare parts
253401010175	ENGINE ASSY W/O CLUTCH & CLUTCH HSG BS6	TATA spare parts
253401010176	ENGINE ASSY BS6	TATA spare parts
253401010177	ENGINE ASSY BS6	TATA spare parts
253401010180	ENGINE ASSY BS6	TATA spare parts
253401010182	ENGINE ASSY BS6	TATA spare parts
253401010183	ENGINE ASSY BS6	TATA spare parts
253401010186	ENGINE ASSY BS6	TATA spare parts
253401010187	ENGINE ASSY BS6	TATA spare parts
253401010194	ENGINE ASSY BS6	TATA spare parts
253401010197	ENGINE ASSY BS6	TATA spare parts
253401010204	ENGINE ASSY 4SP NA 62PS	TATA spare parts
253401010205	ENGINE ASSY BS6-PH2	TATA spare parts
253401010208	ENGINE ASSY BS6	TATA spare parts
253401010216	ENGINE ASSY BS6-PH2	TATA spare parts
253401010217	ENGINE ASSY BS6-PH2	TATA spare parts
253401010219	ENGINE ASSY BS6	TATA spare parts
253401010220	ENGINE ASSY BS6-PH2	TATA spare parts
253401010225	ENGINE ASSY BS6-PH2	TATA spare parts
253401010228	ENGINE ASSY BS6-PH2	TATA spare parts
253401010229	ENGINE ASSY 4SP NA 62PS 2800RPM MARINE	TATA spare parts
253401010234	ENGINE ASSY BS6-PH2	TATA spare parts
253401010243	ENGINE SUB ASSY 4SP NG WJ POWER CHP UNIT	TATA spare parts

253401010261	ENGINE ASSY BS6-PH2	TATA spare parts
253401100116	CYLINDER BLOCK 407	TATA spare parts
253401100118	CYL.BLOCK W/O CL HSG.	TATA spare parts
253401100130	CYL.BLOCK W/O CL HSG. SAFARI DICOR	TATA spare parts
253401100135	CYLINDER BLOCK LINERED	TATA spare parts
253401100141	ASSY.CYL.CRANKCASE W/O CL.HSG/FLY.WH.HSG	TATA spare parts
253401100146	CYL BLOCK 4SP W CLUTCH HOUSING	TATA spare parts
253401100147	CYL.CRANKCASE	TATA spare parts
253401100149	CYL. BLOCK W/O CLUTCH HSG.EUROII	TATA spare parts
253401100153	ASSY. CYL. CRANKCASE WITHOUT CLUTCH HSG.	TATA spare parts
253401100160	ASSY.CYL.CRANKCASE W/O CL. HSG.-STG.II	TATA spare parts
253401100164	ASSY. CRANKCASE W/O FLYWHEEL HSG. BS3	TATA spare parts
253401100176	ASSY.CYL.CRANKCASE W/O CLUTCH HSG.BS-II	TATA spare parts
253401100181	ASSY.CYL.CRANKCASE W/O CLHSG TCDRED BSII	TATA spare parts
253401100188	ASSY CYL CRANKCASE WITH CLUTCH HOUSING	TATA spare parts
253401100189	ASSY CYL CRANKCASE W/O CL HSG	TATA spare parts
253401100196	ASSY.CYL.CRANKCASE W/O CL HSG	TATA spare parts
253401100222	ASSY CRANKCASE W/O CL HSG	TATA spare parts
253401100236	ASSY.CYL.CRANKCASE WITH FL.HOUSING.	TATA spare parts
253401100237	ASSY CRANKCASE W.O CL HSG 4SPTC-PTFE SEA	TATA spare parts
253401100246	ASSY. CRANKCASE W/O FLYWHEEL HSG.	TATA spare parts
253401100248	CYL CRANKCASE ASSY WITH CLUTCH HSG	TATA spare parts
253401100249	CYL CRANKCASE ASSY WITH CLUTCH HSG	TATA spare parts
253401100254	CYL BLOCK ASSY WITH FLYWHEEL HSG	TATA spare parts
253401100262	CYL CRANKCASE ASSY WITH FLYWHEEL HSG BS6	TATA spare parts
253401100265	CYL CRANKCASE ASSY W/O FLY HSG BS6	TATA spare parts
253401100271	CYL CRANKCASE ASSY W/O FLY HSG BS6	TATA spare parts
253401103702	LINER CYLINDER 407	TATA spare parts
253401103712	CYLINDER LINER :4SP BS:III	TATA spare parts
253401103718	CYLINDER LINER	TATA spare parts
253401103729	CYLINDER LINER :4SP BS:III	TATA spare parts
253401103733	CYLINDER LINER KUSALAVA BS-III	TATA spare parts
253401107201	PLUG OIL GALLERY	TATA spare parts
253401107202	PLUG (MAIN OIL GALLERY)	TATA spare parts
253401107204	ADAPTOR(OIL INLET ON BLOCK)4SPTC BSII	TATA spare parts
253401108001	HEX SCREW	TATA spare parts
253401108201	CORE PLUG	TATA spare parts
253401108202	CORE PLUG	TATA spare parts
253401108206	CORE PLUG BS6-PH2	TATA spare parts
253401109902	CLAMPING SLEEVE CYL.BLOCK(REAR SEAL)	TATA spare parts
253401130111	DRAIN PLUG MAGNETIC BS4	TATA spare parts
253401130115	OIL SUMP ASSY	TATA spare parts
253401130117	OIL SUMP	TATA spare parts
253401130124	GASKET OIL SUMP TO CYL BLOCK BS2/3/4	TATA spare parts
253401130129	ASSY.OIL SUMP	TATA spare parts
253401130135	ASSY.OIL SUMP GASKET	TATA spare parts
253401130137	ASSY OIL SUMP COMPLETE	TATA spare parts

253401130147	ASSY FLANGE	TATA spare parts
253401130152	OIL SUMP LP 407	TATA spare parts
253401130153	ASSY.OIL SUMP W/PLUG	TATA spare parts
253401130157	ASSY. FLANGE (OIL SUMP) OUTER	TATA spare parts
253401130159	ASSY OIL SUMP COMP W/COUP NUT & FERRULE	TATA spare parts
253401130167	OIL SUMP GASKET	TATA spare parts
253401130171	ASSY.OIL SUMP GASKET	TATA spare parts
253401130172	OIL SUMP W/COUP NUT & FERRULE	TATA spare parts
253401130173	ASSY.FLANGE WITH TUBE	TATA spare parts
253401130176	ASSY.MAGNETIC DRAIN PLUG	TATA spare parts
253401130188	ASSY.GASKET OIL SUMP W/BEED	TATA spare parts
253401130191	ASSY OIL SUMP 4SP EURO III	TATA spare parts
253401130204	ASSY. OIL SUMP	TATA spare parts
253401130246	ASSY.OIL SUMP COMP. W/COUP.NUT&FERRULE	TATA spare parts
253401130266	ASSY.OIL SUMP	TATA spare parts
253401130278	ASSY.OIL SUMP	TATA spare parts
253401130301	OILSUMP BS6	TATA spare parts
253401130303	OIL SUMP ASSY	TATA spare parts
253401130310	ASSY.OIL SUMP COMP.W/COUP.NUT & FERRULE	TATA spare parts
253401130317	GASKET (OIL SUMP)	TATA spare parts
253401133504	OILSUMPBOSS BS6	TATA spare parts
253401133701	FLANGE - OUTER	TATA spare parts
253401135301	GASKET LEFT	TATA spare parts
253401135302	GASKET RIGHT	TATA spare parts
253401135303	GASKET FLANGE	TATA spare parts
253401135313	ASSY.OIL SUMP GASKET	TATA spare parts
253401135314	ASSY.OIL SUMP GASKET	TATA spare parts
253401140101	COVER PUSH ROD CHAMBER	TATA spare parts
253401140105	ASSY PUSHROD CHAMBER COVER WITH GASKET	TATA spare parts
253401140110	HOUSING TIMING GEAR	TATA spare parts
253401140115	PLUG TGH	TATA spare parts
253401140117	COMBI SCREW	TATA spare parts
253401140118	COMBI SCREW	TATA spare parts
253401140119	PLUG TGH	TATA spare parts
253401140120	ASSY TGH WITH BOTTOM COVER CYL PINS&STUD	TATA spare parts
253401140121	ASSY.TGH WITH BOTTOM COVER	TATA spare parts
253401140124	HOUSING TIMING GEAR	TATA spare parts
253401140131	ASSY.TGH W/BOTTOM COVER CYL.PINS & STUD	TATA spare parts
253401140132	ASSY TGH WITH BOTTOM COVER	TATA spare parts
253401140135	ASSY.TIMING GEAR HSG WITH BOTTOM COVER	TATA spare parts
253401140137	ASSY.PIPE-4SP EURO-II	TATA spare parts
253401140142	ASSY. TGH WITH BOTTOM COVER	TATA spare parts
253401140145	ASSY. TGH NOISE SHIELD (NVH)	TATA spare parts
253401140147	ASSY.TGH COVER WITH RUBBER DAMPING	TATA spare parts
253401140153	ASSY.ISOLATOR(NOISE COVER)	TATA spare parts
253401140156	ASSY. ISOLATOR	TATA spare parts
253401140157	ASSY TGH WITH THREAD INSERTS:4SP BSII/II	TATA spare parts

253401140158	SET ASSY TGH WITH FRONT & BOTTOM COVER	TATA spare parts
253401140166	ASSY.TGH WITH BOTTOM COVER	TATA spare parts
253401140167	ASSY.TIMING GEAR HOUSING COVER (WITH RUB	TATA spare parts
253401140174	ASSY.TGH W/BOTTOM COVER	TATA spare parts
253401140176	ASSY. TGH WITH HELI-COIL THREAD INSERTS	TATA spare parts
253401140202	TIMING GEAR HSG ASSY WITH BOTTOM COVER	TATA spare parts
253401140204	TGH ASSY WITH BOTTOM & FRONT COVER BS6	TATA spare parts
253401140205	TIMING GEAR HSG ASSY WITH PINS & STUD BS	TATA spare parts
253401140206	TIMING GEAR HSG ASSYBS6	TATA spare parts
253401140207	TGH ASSY WITH BOTTOM & FRONT COVER BS6	TATA spare parts
253401140208	TIMING GEAR COVER ASSY WITH DAMPING (4SP	TATA spare parts
253401143702	TIMING GEAR HSG	TATA spare parts
253401143703	HOUSING TIMING GEAR	TATA spare parts
253401143706	TIMING GEAR HOUSING 4SP TC EURO II	TATA spare parts
253401143802	COVER FRONT TIMING GEAR HSG.	TATA spare parts
253401143809	COVER TIMING GEAR HSG FRONT BS6	TATA spare parts
253401145302	GASKET TIMING GEAR HSG	TATA spare parts
253401145304	GASKET PUSH ROD CHAMBER COVER	TATA spare parts
253401145305	GASKET TIMING GEAR HSG BS4	TATA spare parts
253401145307	GASKET- PUSH ROD CHAMBER COVER	TATA spare parts
253401145308	GASKET PUSH ROD CHAMBER COVER	TATA spare parts
253401145309	GASKET (PUSH ROD CHAMBER COVER)	TATA spare parts
253401145310	GASKET-NOISE COVER(L.H)	TATA spare parts
253401145311	GASKET(NOISE COVER L.H)	TATA spare parts
253401147703	OIL SEAL	TATA spare parts
253401148207	PUSH ROD CHAMBER COVER 4SPTCIC BSIII	TATA spare parts
253401148208	ASSY. PUSH ROD CHAMBER COVER	TATA spare parts
253401148708	NOISE COVER LH	TATA spare parts
253401148710	NOISE COVER WITH HOLE SPACIO GOLD +	TATA spare parts
253401148711	NOISE COVER LH (WITH AC)	TATA spare parts
253401148712	NOISE COVER LH (W/O AC)	TATA spare parts
253401150103	CYLINDER HEAD W/VALVES	TATA spare parts
253401150104	ASSY CYL HEAD WITHOUT VALVES 4SP	TATA spare parts
253401150108	COVER CYLINDER HEAD	TATA spare parts
253401150109	COVER CYLINDER HEAD	TATA spare parts
253401150110	COMBI BOLT	TATA spare parts
253401150111	COMBI BOLT	TATA spare parts
253401150113	ELBOW AIR INTAKE	TATA spare parts
253401150115	CYLINDER HEAD W/VALVES	TATA spare parts
253401150116	CYLINDER HEAD W/O VALVES	TATA spare parts
253401150117	ASSY. OIL CAP WITH BREATHING PROVISION	TATA spare parts
253401150118	CYL.HEAD COVER nls0197	TATA spare parts
253401150121	ASSY CYL.HD W/VALVE	TATA spare parts
253401150134	ASSY.CYL.HD.COVER	TATA spare parts
253401150140	COVER CYLINDER HEAD	TATA spare parts
253401150141	ASSY.CYL.HEAD COVER	TATA spare parts
253401150142	CYLINDER HEAD W/VALVES	TATA spare parts

253401150143	CYLINDER HEAD W/O VALVES	TATA spare parts
253401150152	ASSY CYL. HEAD WITH VALVES	TATA spare parts
253401150153	ASSY CYL. HEAD W/O VALVES	TATA spare parts
253401150154	CYL.HEAD WITH VALVES	TATA spare parts
253401150155	CYL.HEAD W/O VALVES	TATA spare parts
253401150158	CYLINDER HEAD W/VALVES	TATA spare parts
253401150159	CYLINDER HEAD W/O VALVES	TATA spare parts
253401150161	CYLINDER HEAD W/VALVES	TATA spare parts
253401150162	CYLINDER HEAD W/O VALVES LP407CMVR TURBO	TATA spare parts
253401150174	ASSY. AIR INTAKE ELBOW	TATA spare parts
253401150175	ASSY.CYL.HEAD WITHOUT VALVES--BSII	TATA spare parts
253401150176	ASSY.CYL.HEAD-WITH VALVES- BSII	TATA spare parts
253401150177	ASSY. ISOLATOR	TATA spare parts
253401150179	ASSY.CYL.HEAD WITH VALVES 4SP BS-III	TATA spare parts
253401150183	ASSY.CYLINDER HEAD COVER.	TATA spare parts
253401150184	ASSY.CYLINDER HEAD COVER	TATA spare parts
253401150185	ASSY.CYLINDER HEAD COVER.	TATA spare parts
253401150187	ASSY.CYLINDER HEAD WITH VALVES.CMVR 2000	TATA spare parts
253401150188	ASSY.CYL.HEAD-WITHOUT VALVES-4SPNA BSII	TATA spare parts
253401150189	ASSY.CYLINDER HEAD WITH VALVES(-BSII)	TATA spare parts
253401150190	ASSY.CYL.HEAD W/O VALVES-CMVR 2000	TATA spare parts
253401150191	ASSY.BREATHER CAP	TATA spare parts
253401150197	ASSY.CYLINDER HEAD COVER 4SP	TATA spare parts
253401150199	ASSY.CYL.HEAD W/ VALVES(4SP/497 CNG)EII	TATA spare parts
253401150201	ASSY MOUNTING BRACKET (LH REAR)ENG COVER	TATA spare parts
253401150203	ASSY AIR INTAKE ELBOW	TATA spare parts
253401150204	ASSY. ENGINE COVER	TATA spare parts
253401150205	ASSY BRACKET (ENG COVER SUPPORT RH REAR)	TATA spare parts
253401150206	ASSY CYLINDER HEAD COVER AL.FRONT	TATA spare parts
253401150207	ASSY CYLINDER HEAD COVER AL.SIDE	TATA spare parts
253401150208	ASSY ISOLATOR T TYPE FOR AL COVER	TATA spare parts
253401150210	ASSY ISOLATOR V TYPE	TATA spare parts
253401150223	ENGINE COVER	TATA spare parts
253401150229	ASSY.CYL.HEAD WITH VALVES(4SP-BSI/BSII)	TATA spare parts
253401150230	ASSY.CYL.HD.W.VALES(60DEG INLET):4SPBS3	TATA spare parts
253401150231	ASSY CYLINDER HEAD W/O VALVES	TATA spare parts
253401150232	ASSY.CYL.HD.W.VALES(60 DEG INLET):4SPBS2	TATA spare parts
253401150233	ASSY CYL. HEAD W/O VALES:4SP/497BS-II	TATA spare parts
253401150235	ASSY AIR INTAKE ELBOW SPACIO 4SPTC BSII	TATA spare parts
253401150237	ASSY BRACKET ENG COV MTG REAR(L'HOOKREAR)	TATA spare parts
253401150239	ASSY BRACKET REAR ENG COV MTG	TATA spare parts
253401150242	ASSY CYL.HEAD W/O VALVES (60 DEG VALVE)	TATA spare parts
253401150244	ASSY.CYL. HEAD WITH VALVES (60 DEGREE)	TATA spare parts
253401150248	ASSY. ENGINE COVER	TATA spare parts
253401150249	ASSY CYL HEAD WITH VALVE-60 DEG	TATA spare parts
253401150250	ASSY CYL HEAD W/O VALVES	TATA spare parts
253401150251	ASSY.CYL.HEAD WITH VALVES-60 DEG	TATA spare parts



253401150253	ASSY. CYL-HEAD W/VALVES (60-DEG INTAKE)	TATA spare parts
253401150254	ASSY. CYL-HEAD W/O VALVES(60-DEG INTAKE)	TATA spare parts
253401150255	ASSY CYLINDER HEAD WITH VALVES(60 DEG)	TATA spare parts
253401150256	ASSY. CYL. HEAD WITHOUT VALVES	TATA spare parts
253401150284	ASSY AIR INTAKE ELBOW.4SPTC CR BSIV	TATA spare parts
253401150295	ASSY AIR INTAKE ELBOW	TATA spare parts
253401150302	ASSY CYLINDER HEAD COVER(WITHOUT BOSS)	TATA spare parts
253401150305	ASSY AIR INTAKE ELBOW XENON 4SPTC BSIII	TATA spare parts
253401150317	ELBOW ASSY AIR INTAKE	TATA spare parts
253401150320	ELBOW ASSY AIR INTAKE	TATA spare parts
253401150321	ASSY. AIR INTAKE ELBOW	TATA spare parts
253401150324	COVER ASSY CYL HEAD	TATA spare parts
253401150326	COVER ASSY CYL HEAD	TATA spare parts
253401150339	SEALING PLUG	TATA spare parts
253401150340	SEALING PLUG	TATA spare parts
253401150345	CYLINDER HEAD ASSY WITH VALVES BS6	TATA spare parts
253401150346	CYLINDER HEAD ASSY WITHOUT VALVES BS6	TATA spare parts
253401150352	CYLINDER HEAD COVER WITH GASKET BS6	TATA spare parts
253401150356	CYLINDER HEAD ASSY WITH VALVES BS6	TATA spare parts
253401150357	CYLINDER HEAD ASSY WITH VALVES BS6	TATA spare parts
253401150359	CYLINDER HEAD ASSY W/O VALVES BS6	TATA spare parts
253401150360	CYLINDER HEAD ASSY WITH VALVES BS6	TATA spare parts
253401153204	SEAT PLUG ON CYL.HEAD	TATA spare parts
253401153301	SUPPORT BRACKET (AIR INTAKE ELBOW)	TATA spare parts
253401153302	SUPPORT BRACKET (VACUUM HOSE)	TATA spare parts
253401153303	SUPPORT BRACKET (FOR VACUUM HOSE)	TATA spare parts
253401153305	SUPPORT BRACKET (FOR VACUUM HOSE)	TATA spare parts
253401153402	VALVE GUIDE(INLET)	TATA spare parts
253401153405	VALVE SEAT RING INLET BS-III NORMAL	TATA spare parts
253401153406	VALVE SEAT RING INLET BS-III NORMAL-I	TATA spare parts
253401153714	CYL.HEAD (60 DEG VALVE)4SP/497BSII	TATA spare parts
253401153801	AIR INTAKE ELBOW	TATA spare parts
253401153802	AIR INTAKE ELBOW	TATA spare parts
253401153806	CYLINDER HEAD COVER	TATA spare parts
253401153822	AIR INTAKE ELBOW	TATA spare parts
253401153825	AIR INLET ELBOW	TATA spare parts
253401153827	AIR INTAKE ELBOW	TATA spare parts
253401153829	AIR INTAKE ELBOW-WITH M16X1.5 HOLE	TATA spare parts
253401153830	AIR INTAKE ELBOW (WITH M16X1.5 HOLE)	TATA spare parts
253401153833	CYL. HEAD COVER ( FRONT ENTRY)	TATA spare parts
253401153835	AIR INTAKE ELBOW EURO-III	TATA spare parts
253401153836	AIR INLET ELBOW FRONT ENTRY COVER CAST	TATA spare parts
253401153845	CYLINDER HEAD COVER	TATA spare parts
253401153846	CYLINDER HEAD COVER(FRONT ENTRY)	TATA spare parts
253401153856	AIR INTAKE ELBOW	TATA spare parts
253401153858	AIR INTAKE ELBOW	TATA spare parts
253401153862	ELBOW AIR INTAKE	TATA spare parts

253401153863	AIR INTAKE ELBOW (FRONT ENTRY COVER)	TATA spare parts
253401153865	AIR INLET ELBOW (FRONT ENTRY COVER)	TATA spare parts
253401153867	ELBOW AIR INTAKE	TATA spare parts
253401153868	ELBOW AIR INTAKE ( FRONT ENTRY COVER )	TATA spare parts
253401153876	CYLINDER HEAD COVER BS6	TATA spare parts
253401155301	GASKET CYLINDER HEAD	TATA spare parts
253401155307	GASKET CYLINDER HEAD	TATA spare parts
253401155308	GASKET CYLINDER HEAD BS2/3/4	TATA spare parts
253401155311	CYLINDER HEAD COVER GASKET (B)	TATA spare parts
253401155312	GASKET CYL HEAD COVER	TATA spare parts
253401155313	GASKET CYLINDER HEAD	TATA spare parts
253401155314	GASKET FOR CYL HEAD COVER	TATA spare parts
253401155316	CYLINDER HEAD GASKET	TATA spare parts
253401155317	CYL. HEAD GASKET NON-RETORQUE BS1/2/3	TATA spare parts
253401155319	CYLINDER HEAD GASKET. NON-RETORQUE	TATA spare parts
253401155320	CYLINDER HEAD GASKET	TATA spare parts
253401155322	CYLINDER HEAD GASKET	TATA spare parts
253401155323	CYLINDER HEAD GASKET NON RETORQUE	TATA spare parts
253401155324	CYLINDER HEAD GASKET	TATA spare parts
253401155327	GASKET(INJ.OUTSIDE COVER)	TATA spare parts
253401155328	GASKET FRONT ENTRY CYL.HEAD COVER BS4	TATA spare parts
253401155329	CYL HEAD COVER GASKET 4 SP	TATA spare parts
253401155330	GASKET (CYL.HEAD COVER)	TATA spare parts
253401155331	GASKET(INTAKE MANI.CUM HEAD COVER)-SSL	TATA spare parts
253401155333	GASKET(CYL.HEAD COV):4SPBS3 BS4	TATA spare parts
253401155335	GASKET (CYL.HEAD COVER INJECTOR INSIDE)	TATA spare parts
253401155336	AIR INTAKE ELBOW GASKET	TATA spare parts
253401155338	GASKET&BS6	TATA spare parts
253401155339	GASKET BS6	TATA spare parts
253401158801	STUD-40.5	TATA spare parts
253401158802	STUD-115	TATA spare parts
253401158808	HEX FLANGE BOLT M8X147L	TATA spare parts
253401158809	HEX FLANGE BOLT M8X 122L BS4	TATA spare parts
253401158810	HEX FLANGE BOLT M8X59L	TATA spare parts
253401159201	WASHER-CYL. HEAD COVER MTG.	TATA spare parts
253401159902	HEX COLLAR BOLT:4SP/497 EURO III	TATA spare parts
253401160102	INJECTOR HARVESTOR	TATA spare parts
253401160104	NOZZLE.	TATA spare parts
253401160105	ASSY INJECTOR	TATA spare parts
253401160108	ASSY.NOZZLE HOLDER WITH NOZZLE & WASHER	TATA spare parts
253401160110	INJECTOR HOLDER	TATA spare parts
253401160111	INJECTOR	TATA spare parts
253401160112	ASSY.INJECTOR (4SP EURO-II)	TATA spare parts
253401160113	ASSY INJECTOR HOLDER WITH NOZZLE	TATA spare parts
253401160114	ASSY.INJECTOR 4SP BS-III NORMAL	TATA spare parts
253401160115	ASSY.INJECTOR 4SP BS-III NBFI TYPE	TATA spare parts
253401160117	ASSY.NOZZLEHOLDERWITHNOZZLE	TATA spare parts

253401160119	INJECTOR	TATA spare parts
253401160121	ASSY.INJECTOR 4SPTC BSII	TATA spare parts
253401160122	ASSY. INJECTOR	TATA spare parts
253401160124	ASSY.INJECTOR (4SPTCIC BS-III)	TATA spare parts
253401160127	ASSY. FUEL INJECTOR 4SPCRBSIV BS3/4	TATA spare parts
253401160128	INJECTORASSY4SPCPCBII	TATA spare parts
253401160135	INJECTOR ASSY BS6	TATA spare parts
253401164202	CLAW INJECTOR	TATA spare parts
253401165101	INJECTOR CLAW (INVESTMENT CASTING)	TATA spare parts
253401168201	CLAW (SINGLE SPRING )	TATA spare parts
253401168202	CLAW (FOR DI.CR. INJECTOR)	TATA spare parts
253401169206	SEALING WASHER 2.5 THICK(4SP BS-III)	TATA spare parts
253401169209	SEALING WASHER (BS-III INJECTOR)	TATA spare parts
253401169211	SEALING WASHER;INJECTOR (1.2MM WASHER)	TATA spare parts
253401169903	NOZZLE	TATA spare parts
253401169905	NOZZLE; BS-III NORMAL INJECTOR	TATA spare parts
253401169907	HEX.FL.BOLT-M8X33.5(12.9PROPERTY CLASS)	TATA spare parts
253401169908	HEX FLANGE BOLT M8X30 (12.9 CLASS) BS4	TATA spare parts
253401169914	NOZZLE; BS-III NBFE TYPE INJ.	TATA spare parts
253401169915	NOZZLE HOLDER BS-III(NBFE)	TATA spare parts
253401170101	TUBE DIPSTICK	TATA spare parts
253401170102	ASSY.TUBE DIPSTICK W/SLIP	TATA spare parts
253401170103	DIPSTICK	TATA spare parts
253401170109	BREATHER	TATA spare parts
253401170110	BREATHER	TATA spare parts
253401170114	BREATHER CAP	TATA spare parts
253401170115	BREATHER	TATA spare parts
253401170116	ASSY SOCKET W TUBE(ALT.VAC.PUMP OIL RTN)	TATA spare parts
253401170117	ASSY BRACKET (BLOW BY OIL RETURN LINE)	TATA spare parts
253401170118	ASSY BRACKET	TATA spare parts
253401170119	BREATHER	TATA spare parts
253401170125	OIL DIPSTICK LP 407	TATA spare parts
253401170126	ASSY.BRACKET (OIL FILLER PIPE MTG.)	TATA spare parts
253401170131	ASSY.SUPPORT (FOR DIPSTICK)	TATA spare parts
253401170135	ASSY.BRACKET(OIL SEPARATOR MOUNTING)	TATA spare parts
253401170136	BREATHER ASSY	TATA spare parts
253401170140	PIPE ASSY OMS TO TC OIL RETURN;BS6	TATA spare parts
253401170141	KIT-OMSASSYWITHHOSES-BRACKETBS6	TATA spare parts
253401170145	ASSY OIL DIPSTICK	TATA spare parts
253401170146	ASSY.BRACKET-DIPSTIC MTG.ON U.C.L	TATA spare parts
253401170151	ASSY OIL RETURN LINE (BLOW BY)	TATA spare parts
253401170156	PIPE ASSY OMS TO TC OIL RETURN BS6	TATA spare parts
253401170157	BLOW BY (AIR INTAKE BS-III)	TATA spare parts
253401170168	ASSY BRACKET-SUPPORT-OIL SEPARATOR PIPE	TATA spare parts
253401170169	ASSY BRACKET OIL SEPARATOR MOUNTING	TATA spare parts
253401170171	ASSY BRACKET(OIL SEP.PIPE CLAMP ON UCL)	TATA spare parts
253401170172	ASSY BRACKET (DIPSTICK TUBE MOUNTING)	TATA spare parts

253401170174	ASSY BRACKET(DIPSTICK MOUNTING)4SPTCBSII	TATA spare parts
253401170178	ASSY.BRACKET (DIPSTICK MTG)	TATA spare parts
253401170180	ASSY. BREATHER	TATA spare parts
253401170186	ASSY.DIPSTICK MTG. BKT.(ON EGR COOLER)	TATA spare parts
253401170193	ASSY BRACKET(FOR OIL SEP.PIPE)	TATA spare parts
253401170196	ASSY BRACKET OIL SEPARATOR MOUNTING	TATA spare parts
253401170199	ASSY OIL RETURN LINE (BLOW BY CIRCUIT) C	TATA spare parts
253401170202	ASSY. PIPE(OIL SEPERATOR TO AIR FILTER)	TATA spare parts
253401170203	ASSY. BRACKET (DIPSTICK MTG.)	TATA spare parts
253401170207	BRACKET DIPSTICK TUBE CLAMPING	TATA spare parts
253401170208	BRACKET DIPSTICK TUBE CLAMPING	TATA spare parts
253401170209	BRACKET ASSY (SUPPORT FOR METAL PIPE)	TATA spare parts
253401170210	PIPE ASSY OIL SEPARATOR TO AIR FILTER	TATA spare parts
253401170228	DIPSTICK LEVEL STRIP	TATA spare parts
253401170233	DIPSTICK TUBE ASSY BS6	TATA spare parts
253401170236	BRACKET ASSY DIPSTICK MTG	TATA spare parts
253401170250	PIPE ASSY WITH CLAMP&BS6	TATA spare parts
253401170257	OIL MIST SEPARATOR ASSY&BS6	TATA spare parts
253401170258	PIPE ASSY WITH CLAMP&BS6	TATA spare parts
253401170261	PIPEASSYWITHCLAMPBS6	TATA spare parts
253401170262	PIPE ASSY WITH CLAMP BS6	TATA spare parts
253401170274	DIPSTICK LEVEL STRIP BS6	TATA spare parts
253401170275	DIPSTICK ASSY BS6	TATA spare parts
253401170289	PIPE ASSY BS6	TATA spare parts
253401170290	KIT-OMS ASSY WITH HOSES & BRACKET BS6	TATA spare parts
253401170377	DIPSTICK TUBE ASSY BS6-PH2	TATA spare parts
253401173305	BRACKET (OIL SEPARATOR MTG.)	TATA spare parts
253401173306	ASSY BRACKET UPPER (BLOWBY RETURN LINE)	TATA spare parts
253401173307	ASSY BRACKET (BLOWBY TO AIR INTAKE SUPT)	TATA spare parts
253401173308	CLAMP SUPPORT TO PIPE	TATA spare parts
253401174201	CLAMP	TATA spare parts
253401174202	CLAMP-BREATHER HOSE	TATA spare parts
253401174203	CLAMP-FOR EGR HOSE	TATA spare parts
253401174205	CLAMP (SUPPORT - BREATHER HOSE)	TATA spare parts
253401174206	CLAMP (BLOEBY RETURN LINE)	TATA spare parts
253401174207	CLAMP RH (BLOWBY AIR INTAKE)	TATA spare parts
253401174208	CLAMP (BLOWBY AIR INTAKE LH)	TATA spare parts
253401174210	CLAMP (SUPPORT - BREATHER HOSE)	TATA spare parts
253401174212	SUPPORT BRACKET&BS6	TATA spare parts
253401175802	HOSE BREATHER	TATA spare parts
253401175805	HOSE (FROM BREATHER TO OIL SEPERATOR)	TATA spare parts
253401175808	HOSE-PIPE TO AIR INTAKE HOSE	TATA spare parts
253401175809	HOSE-OIL SEPARATOR TO PIPE	TATA spare parts
253401175810	HOSE-AIR BREATHER TO OIL SEPARATOR	TATA spare parts
253401175812	RUBBER HOSE(OIL SEP'TOR-TO AIRINTAKEHOSE	TATA spare parts
253401175813	RUBBER HOSE(OIL SEP'TOR TO BREATHER)	TATA spare parts
253401175814	HOSE (BREATHER TO IOL SEPRT)	TATA spare parts

253401175816	HOSE (BREATHER Y1) BS4	TATA spare parts
253401175823	BREATHER HOSE	TATA spare parts
253401176908	PIPE OIL SEPARATOR TO AIR INTAKE	TATA spare parts
253401176923	RUBBER HOSE BS6	TATA spare parts
253401176933	RUBBERHOSE BS6	TATA spare parts
253401177101	FLANGE	TATA spare parts
253401177701	RUB SEAL BREATHER	TATA spare parts
253401177801	'O' RING	TATA spare parts
253401600101	HALF ENG 4SP	TATA spare parts
253401600151	HALF ENG 4SP SFC MOD	TATA spare parts
253401600152	HALF ENG 4SP LP MOD	TATA spare parts
253401600153	HALF ENGINE ASSLY 407TC	TATA spare parts
253401600155	LONG BLOCK 4SP NEW	TATA spare parts
253401600157	SHORT BLOCK CMVR(P/I	TATA spare parts
253401600158	LONG BLK 4SP CMVR96	TATA spare parts
253401600159	SHORT BLK 4SPTC CMVR	TATA spare parts
253401600160	ASSY LONG BLOCK SFC	TATA spare parts
253401600161	SHORT BLK 4SPTC CMVR	TATA spare parts
253401600162	ASSY LONG BLOCK LP/L	TATA spare parts
253401970102	HALF BLOCK ASSY	TATA spare parts
253401970105	KIT-GASKET ENGINE OVERHAUL	TATA spare parts
253401970106	KIT-ENGINE OVERHAUL SEAL	TATA spare parts
253401970107	KIT-DECARBONISING GASKET	TATA spare parts
253401970109	KIT-HALF BLOCK ASSY	TATA spare parts
253401970110	ASSY. LONG BLOCK 4SPCR BS4	TATA spare parts
253401970112	LONG BLOCK ASSY	TATA spare parts
253401970113	KIT-GASKET ENGINE OVERHAUL	TATA spare parts
253401970114	GASKET OVERHAUL KIT WITH SEAL	TATA spare parts
253401970116	LONG BLOCK ASSY	TATA spare parts
253401970117	HALF BLOCK ASSY	TATA spare parts
253401970121	LONG BLOCK ASSY BS6	TATA spare parts
253401970122	HALF BLOCK ASSY BS6	TATA spare parts
253401970126	KIT-ENGINE OVERHAUL GASKET BS6	TATA spare parts
253401970127	KIT-DECARBONISING GASKET BS6	TATA spare parts
253401970128	CYLINDER HEAD ASSY W/O VALVES BS6	TATA spare parts
253401970129	LONG BLOCK ASSY BS6	TATA spare parts
253401970131	HALF BLOCK ASSY BS6	TATA spare parts
253401970134	CYLINDER HEAD ASSY W/O VALVES BS6-PH2	TATA spare parts
253401970147	HALF BLOCK ASSY BS6-PH2	TATA spare parts
253401970148	LONG BLOCK ASSY BS6-PH2	TATA spare parts
253401970149	HALF BLOCK ASSY BS6-PH2	TATA spare parts
253401970150	HALF BLOCK ASSY BS6-PH2	TATA spare parts
253401970151	LONG BLOCK ASSY BS6-PH2	TATA spare parts
253401970153	LONG BLOCK ASSY BS6-PH2	TATA spare parts
253401970155	HALF BLOCK ASSY BS6-PH2	TATA spare parts
253401970159	LONG BLOCK ASSY BS6-PH2	TATA spare parts
253401970166	LONG BLOCK ASSY BS6-PH2	TATA spare parts

253401980104	ASSY LONG BLOCK	TATA spare parts
253401980105	ASSY HALF BLOCK LPK 410 BSIII	TATA spare parts
253401980114	ENG. OVERHAUL GASKET SUBKIT	TATA spare parts
253401980116	ENGINE OVERHAUL GASKET SUBKIT	TATA spare parts
253401980134	SET-INLET & EXHAUST VALVES BS6-PH2	TATA spare parts
253401980145	KIT-DECARBONISING GASKET	TATA spare parts
253401980146	KIT-GASKET ENGINE OVERHAUL	TATA spare parts
253401980150	LONG BLOCK ASSY 4SPTC E-II XENON RX	TATA spare parts
253401980151	KIT-HALF BLOCK ASSY 4SPTC E-II XENON	TATA spare parts
253401980154	DECARBONISING GASKET KIT XENON	TATA spare parts
253401980155	ENGINE OVERHAUL GASKET KIT XENON	TATA spare parts
253401980157	LONG BLOCK ASSY 4SP ENGINE	TATA spare parts
253401980159	ASSY HALF BLOCK (4SPNA BSII)	TATA spare parts
253401980161	ASSY. LONG BLOCK 4SPNA BS2	TATA spare parts
253401980163	KIT-HALF BLOCK ASSY 4SPCR BS-IV XENON RX	TATA spare parts
253401980168	HALF BLOCK ASSY -(4SPTCIC BS-III CLASS)	TATA spare parts
253401980169	LONG BLOCK ASSY -(4SPTCIC BS-III CLASS)	TATA spare parts
253401980172	KIT-AIR INTAKE PIPE GRID HEATER	TATA spare parts
253401980188	KIT-HALF BLOCK ASSY XENON EX/RX BS4	TATA spare parts
253401980192	KIT-GASKET ENGINE OVERHAUL	TATA spare parts
253401980193	KIT-GASKET ENGINE OVERHAUL WITH SEAL	TATA spare parts
253401980234	LONG BLOCK ASSY 4SPNA 207DI EX BS-III	TATA spare parts
253401980236	HALF BLOCK 4SP NA ENG 207 DI EX+PS BSIII	TATA spare parts
253401980252	ASSY. LONG BLOCK 4SPCR BS3/4	TATA spare parts
253401980253	KIT-AIR INTAKE PIPE GRID HEATER	TATA spare parts
253401980254	ENGINE 4SPTC CR BS4+PS	TATA spare parts
253401980255	LONG BLOCK ASSY	TATA spare parts
253401980258	HALF BLOCK ASSY	TATA spare parts
253401980259	KIT-GASKET ENG. OVERHAUL	TATA spare parts
253401980282	LONGBLOCKASSY	TATA spare parts
253401980286	LONG BLOCK ASSY	TATA spare parts
253401980296	LONG BLOCK ASSY	TATA spare parts
253401980298	LONG BLOCK ASSY	TATA spare parts
253401980301	ASSY. LONG BLOCK 4SPCR10 BS4	TATA spare parts
253401980317	HALFBLOCKASSY	TATA spare parts
253401980321	HALF BLOCK ASSY	TATA spare parts
253401980343	HALF BLOCK ASSY	TATA spare parts
253401980344	HALF BLOCK ASSY	TATA spare parts
253401980346	ASSY. HALF BLOCK XENON YODHA BS4	TATA spare parts
253401980347	DECARBURISING GASKET KIT BS4	TATA spare parts
253401980349	ENGINE OVERHAUL GASKET KIT	TATA spare parts
253401980350	ASSY. HALF BLOCK 4SPCR BS3/4	TATA spare parts
253401980357	ASSY. LONG BLOCK 4SPCR BS4	TATA spare parts
253401980358	KIT-HALF BLOCK ASSY	TATA spare parts
253401980360	HALF BLOCK ENGINE	TATA spare parts
253401980362	LONG BLOCK ASSY	TATA spare parts
253401980370	KIT-GASKET ENGINE OVERHAUL	TATA spare parts

253401980374	KIT-DECARBONISING GASKET	TATA spare parts
253401980375	KIT-ENGINE OVERHAUL GASKET	TATA spare parts
253401980382	LONG BLOCK ASSY	TATA spare parts
253401980383	HALF BLOCK ASSY	TATA spare parts
253401980384	LONG BLOCK 4SPCR BS4 BS4	TATA spare parts
253401980386	ASSY. HALF BLOCK 4SPCR BS4	TATA spare parts
253401980394	LONG BLOCK ASSY	TATA spare parts
253401980399	LONG BLOCK ASSY	TATA spare parts
253401990101	KIT ENG OVERHAUL GASKETS	TATA spare parts
253401990102	KIT DECARBONISING GASKETS	TATA spare parts
253401990103	KIT OIL SUMP GASKETS	TATA spare parts
253401990104	LONG BLOCK 4SP	TATA spare parts
253401990112	BARE ENGINE SPACIO	TATA spare parts
253401990115	KIT ENG OVERHAUL GASKETS SUMO SPACIO	TATA spare parts
253401990118	HALF BLOCK 4SP TURBO EURO II	TATA spare parts
253401990119	LONG BLOCK 4SP TURBO EURO II	TATA spare parts
253401990122	LONG BLOCK-207 DI	TATA spare parts
253401990123	HALF BLOCK-207 DI	TATA spare parts
253401990126	HALF BLOCK (207 DI)WITH POWER STRG	TATA spare parts
253401990127	LONG BLOCK (207 DI)WITH POWER STRG	TATA spare parts
253401990128	ASSY.HALF BLOCK-FACELESS-407	TATA spare parts
253401990129	ASSY.LONG BLOCK-FACELESS-407	TATA spare parts
253401990145	ASSY LONG BLOCK 207 DI BSII	TATA spare parts
253401990146	ASSY LONG BLOCK 207 DI BSII	TATA spare parts
253401990165	ENGINE OVERHAUL GASKET + SEAL	TATA spare parts
253401990166	ENGINE GASKET SUBKIT	TATA spare parts
253401990167	ENGINE OVERHAUL SEAL SUBKIT	TATA spare parts
253401990168	DECARBURISING GASKET SUBKIT	TATA spare parts
253401990180	ASSY.LONG BLOCK 4SP BS-III SFC 410	TATA spare parts
253401990182	ASSY HALF BLOCK 4SP SFC 410 BS-III	TATA spare parts
253401990184	LONG BLOCK 3L	TATA spare parts
253401990185	ASSY HALF BLOCK 3L DICOR SAFARI	TATA spare parts
253401990202	HALF BLOCK 207 DI EX BSIII	TATA spare parts
253401990203	LONG BLOCK 207DI EX BSIII	TATA spare parts
253401990218	ASSY LONG BLK 207DI LHD CMVR2000 1136L	TATA spare parts
253401990219	HALF BLK 207DI LHD CMVR2000 1136L	TATA spare parts
253401990222	KIT ENGINE OVERHAULING GASKETS BSII&III	TATA spare parts
253401990223	KIT DECARB GASKETS SPACIO/207DI BSII&III	TATA spare parts
253401990224	207DI HALF BLK BSII	TATA spare parts
253401990228	GASKET KIT (ENG.OVERHOUL)4SPTCIC BS-III	TATA spare parts
253401990229	DECARBURISING GASKET KIT 4SP TCIC BS-III	TATA spare parts
253401990239	ASSY.LONG BLOCK (4SP TCBS-II SFC 407LHD)	TATA spare parts
253401990240	ASSY HALF BLOCK(4SPTC BS-II SFC407 VEH.)	TATA spare parts
253401990242	SET DECARBURISING KIT(4SPTC BS-II SFCLHD	TATA spare parts
253401990245	ASSY.LONG BLOCK(4SP LP 410 BS-III)	TATA spare parts
253401990246	ASSY.HALF BLOCK (4SP LP 410 BS-III)	TATA spare parts
253401990249	GASKET KIT OVERHAULING(4SP LP 410 BSIII)	TATA spare parts

253401990250	KIT ENG OVERHAULING(4SP TC LHD BS-II)	TATA spare parts
253401990251	HALF BLOCK 4SPNA BS-II 207 DI EX	TATA spare parts
253401990253	LONG BLOCK 4SPNA BS-II 207 DI EX	TATA spare parts
253401990255	ASSY HALF BLOCK:LPK407 TIPPER:4SPTCBS-II	TATA spare parts
253401990256	ASSY LONG BLOCK:LPK 407 TIPPER:4SPTCBSI	TATA spare parts
253401990269	HALF BLOCK SPACIO GOLD+BSII AC PSTRG	TATA spare parts
253401990270	HALF BLOCK.SPACIO GOLD+BSII NORMAL	TATA spare parts
253401990274	LONG BLOCK SPACIO GOLD+ AC PSTRG TC	TATA spare parts
253401990275	LONG BLOCK (BARE ENG)SPACIOGOLD PLUS	TATA spare parts
253401990283	LONG BLOCK SFC407 BSII FOR SPIN ON FILTE	TATA spare parts
253401990284	HALF BLOCK SFC407 BSII FOR SPIN ON FILTE	TATA spare parts
253401990287	LONG BLOCK LP/LPT407 BSII FOR SPIN ON FI	TATA spare parts
253401990288	ASSY.HALF BLOCK(LP/LPT 407-BSII)	TATA spare parts
253401990293	LONG BLOCK LPT407EX BSII FOR SPIN ON FIL	TATA spare parts
253401990294	HALF BLOCK LPT407EX BSII FOR SPIN ON FIL	TATA spare parts
253401990297	ASSY.LONG-BLOCK 4SP-LP407-CNG BS-III	TATA spare parts
253401990308	ASSY.HALF BLOCK(SFC 407 BS-II)	TATA spare parts
253401990309	ASSY.LONG BLOCK(SFC 407 BS-II)	TATA spare parts
253401990314	ASSY. LONG BLOCK 4SPCR BS4	TATA spare parts
253401990316	KIT-HALF BLOCK 4SPCR 207 DI BS4	TATA spare parts
253401990322	LONG BLOCK SUMO GOLD CR4 BSIV	TATA spare parts
253401990324	HALF BLOCK SUMO GOLD CR4 BSIV	TATA spare parts
253401990345	DECARBURISING GASKET SUBKIT	TATA spare parts
253401990346	ENGINE OVERHAUL SEAL SUBKIT SUMO GOLD BS	TATA spare parts
253401990350	LONG BLOCK 4SP TCIC BS3 MFIP SFC 407	TATA spare parts
253401990353	HALF BLOCK 4SP TCIC BS3 MFIP SFC 407	TATA spare parts
253401990356	ASSY. LONG BLOCK 4SPNA ENG. 207DI EX CMV	TATA spare parts
253401990362	ASSY. LONG BLOCK 4SP BS-III SK407	TATA spare parts
253401990364	ASSY HALF BLOCK 4SP BS-III SK407	TATA spare parts
253401990366	ASSY LONG BLOCK 4SP BS-III	TATA spare parts
253401990367	ASSY HALF BLOCK 4SP BS-III	TATA spare parts
253401990369	DECARBURISING GASKET	TATA spare parts
253401990370	ENGINE OVERHAUL SEAL SUBKIT 4SP TCIC MFI	TATA spare parts
253401990374	ASSY. LONG BLOCK 4SPTC BS-III XENON RX W	TATA spare parts
253401990375	KIT HALF BLOCK 4SPTC BS-III XENON RX WIT	TATA spare parts
253401990378	ENGINE OVERHAUL SEAL SUBKIT (SUMO VICTA)	TATA spare parts
253401990381	DECARBURISING GASKET SUBKIT BS4	TATA spare parts
253401990382	ENGINE OVERHAUL GASKET SUBKIT 4SPTC NON	TATA spare parts
253401990383	ENGINE OVERHAUL GASKET + SEAL SUB KIT	TATA spare parts
253401990387	ASSY LONG BLOCK/BARE ENGINE 4SP TCIC BSI	TATA spare parts
253401990388	ASSY HALF BLOCK ENGINE 4SP TCIC BSIII MF	TATA spare parts
253401990398	LONG BLOCK ASSY 207DI E-II	TATA spare parts
253401990399	KIT-HALF BLOCK ASSY 207DI E-II W/PS	TATA spare parts
253401990461	LONG BLOCK ASSY 4SP TCIC BSIII MFIE LP70	TATA spare parts
253401990462	HALF BLOCK ASSY 4SP TCIC BSIII MFIE LP70	TATA spare parts
253401990463	LONG BLOCK/BARE ENG 4SP TCIC MF	TATA spare parts
253401990464	HALF BLOCK 4SP TCIC BSIII MFIE	TATA spare parts



253401990465	ENGINE 4SP TCIC BSIII MFIE LP708	TATA spare parts
253401990466	LONG BLOCK ASSY 4SP TCIC BSIII MFIE 407	TATA spare parts
253402990102	LONG BLOCK ASSY (4SP)	TATA spare parts
253403100101	CRANKSHAFT STD W/CWT	TATA spare parts
253403100109	CRANK SFT W/CTR WT	TATA spare parts
253403100132	ASSY.CRANKSHAFT WITH PIN - NOR BSIII	TATA spare parts
253403100157	ASSY.CRANKSHAFT WITH PIN (FOR REAR SEAL)	TATA spare parts
253403100162	ASSY. CRANKSHAFT W/PIN ALLOY NORM BS1- 4	TATA spare parts
253403103101	BALL BEARING	TATA spare parts
253403103102	BALL BEARING 6204	TATA spare parts
253403103103	BALL BEARING	TATA spare parts
253403103203	HEX BOLT	TATA spare parts
253403107801	SEAL CRANKSHAFT FRONT BS1/2/3/4	TATA spare parts
253403107802	OIL SEAL REAR (FOR PTFE SEAL)	TATA spare parts
253403107913	CRANKSHAFT STD INTCWT	TATA spare parts
253403107914	CRANKSHAFT STD1 INTCWT	TATA spare parts
253403107922	CRANKSHAFT STD INTCWT	TATA spare parts
253403107924	CRANKSHAFT - NORMAL-(EURO-III)	TATA spare parts
253403107928	CRANKSHAFT RS1 INTCWT	TATA spare parts
253403107932	CRANKSHAFT-NORMAL(R85 WEB) 4SPTC BSII	TATA spare parts
253403107934	CRANKSHAFT-NORMAL(MICRO) R85 4SPTC 80P	TATA spare parts
253403107949	CRANKSHAFT-MICROALLOY-NORMAL(EURO-III)	TATA spare parts
253403110108	FLYWHEEL W/RING GEAR	TATA spare parts
253403110114	FLYWHEEL W/RING GEAR	TATA spare parts
253403110116	FLYWHEEL W/RING GEAR	TATA spare parts
253403110121	FLYWHEEL W/RING GEAR	TATA spare parts
253403110124	ASSY FLYWHEEL W RING GEAR 4SP CMVR	TATA spare parts
253403110125	ASSY FLYWHEEL WITH RING GEAR	TATA spare parts
253403110128	ASSY FLYWHEEL	TATA spare parts
253403110131	ASSY.FLYWHEEL WITH RING GEAR 14 DEG TMG	TATA spare parts
253403110134	ASSY. FLYWHEEL WITH RING GEAR	TATA spare parts
253403110139	ASSY FLYWHEEL WITH RING GEAR	TATA spare parts
253403110140	ASSY. FLYWHEEL WITH RING GEAR (CNG)	TATA spare parts
253403110143	ASSY. FLYWHEEL WITH RING GEAR.	TATA spare parts
253403110145	FLYWHEEL WITH RING GEAR.	TATA spare parts
253403110148	ASSY.FLYWHEEL WITH RING GEAR	TATA spare parts
253403110150	ASSY. FLYWHEEL WITH RING GEAR	TATA spare parts
253403110153	ASSY.FLY WHEEL W/RING GEAR(TCD RED)207LH	TATA spare parts
253403110154	ASSY FLYWHEEL ,4SP SPACIO BSIII	TATA spare parts
253403110172	ASSY.FLYWHEEL WITH RING GEAR	TATA spare parts
253403110180	ASSY FLYWHEEL WITH RING GEAR	TATA spare parts
253403110192	FLYWHEEL ASSY WITH RING GEAR	TATA spare parts
253403110203	FLYWHEEL ASSY WITH RING GEAR	TATA spare parts
253403110206	FLYWHEEL ASSY WITH RING GEAR	TATA spare parts
253403110208	ASSY FLYWHEEL WITH RING GEAR	TATA spare parts
253403110228	ASSY FLYWHEEL WITH RING GEAR BS6	TATA spare parts
253403110233	FLYWHEEL ASSY WITH RING GEAR BS6-PH2	TATA spare parts

253403110245	FLYWHEEL ASSY WITH RING GEAR BS6-PH2	TATA spare parts
253403113202	H/FL BLTM12X1.5X 33-12.9 ( RR PTFE SEAL)	TATA spare parts
253403113203	HEX BOLT CRANKSHAFT BS6-PH2	TATA spare parts
253403113706	FLYWHEEL HOUSING (EX-40 EXCAVATOR)	TATA spare parts
253403113708	FLYWHEEL HOUSING EURO-III	TATA spare parts
253403113709	FLYWHEEL HOUSING	TATA spare parts
253403113710	FLYWHEEL HOUSING(HPDC)	TATA spare parts
253403113711	FLYWHEEL HOUSING 4SP	TATA spare parts
253403113714	FLYWHEEL HOUSING ASSY	TATA spare parts
253403113717	FLYWHEEL HOUSING (HPDC)	TATA spare parts
253403113723	FLYWHEEL HOUSING BS6	TATA spare parts
253403113726	FLYWHEEL HOUSING BS6	TATA spare parts
253403113803	FLYWHEEL HOUSING (NEW GEN LCV)	TATA spare parts
253403113804	FLYWHEEL HOUSING	TATA spare parts
253403113809	FLYWHEEL HOUSING	TATA spare parts
253403113811	FLYWHEEL HOUSING BS6	TATA spare parts
253403113813	FLYWHEEL HOUSING BS6	TATA spare parts
253403114801	CYLINDRICAL PIN	TATA spare parts
253403114802	CYLINDRICAL PIN (FOR 260 DIA. CLUTCH)	TATA spare parts
253403115401	RING GEAR BS2/3	TATA spare parts
253403116301	PLUG (ON FLYWHEEL HSG.)	TATA spare parts
253403116701	PIN	TATA spare parts
253403116902	BUSH (FOR SPEED SENSOR)	TATA spare parts
253403118801	STUD(M10 X 25)	TATA spare parts
253403120103	SET MAIN BRG 4SP	TATA spare parts
253403120104	SET M.BRNG UPP/LOW NORMAL I	TATA spare parts
253403120105	SET THRUST WASHER U/L STD	TATA spare parts
253403120106	SET THRUST WASHER U/L STD I(MENON)	TATA spare parts
253403120107	MAIN BEARING SET W/O T/W STD	TATA spare parts
253403120110	SET CON ROD BRG STD	TATA spare parts
253403120111	SET CON ROD BRG STD1	TATA spare parts
253403120112	SET CON ROD BRG RS1	TATA spare parts
253403120113	CON.ROD. BRG.R/SII	TATA spare parts
253403120114	SET MAIN BRG UPPER LOWER- NORMAL	TATA spare parts
253403120115	CON.ROD.BRG.R/S IV	TATA spare parts
253403120116	SET-MAIN BRG.UP/LO NORMAL-E-III	TATA spare parts
253403120118	SET MAIN BEARING UPPER/LOWER:NORMAL	TATA spare parts
253403120119	SET MAIN BEARING UPPER/LOWER NORMAL - I	TATA spare parts
253403120127	SET-MAIN BEARING UPPER/LOWER BS6	TATA spare parts
253403123113	MAIN BEARING-UPPER NORMAL	TATA spare parts
253403123115	MAIN BEARING LOWER NORMAL	TATA spare parts
253403123137	MAIN BEARING - UPPER - NORMAL	TATA spare parts
253403123138	MAIN BEARING - LOWER - NORMAL	TATA spare parts
253403123139	MAIN BEARING - UPPER - NORMAL-I	TATA spare parts
253403123140	MAIN BEARING - LOWER - NORMAL-I	TATA spare parts
253403123145	MAIN BRG UPPER - NORMAL (M/S MENON)(B)	TATA spare parts
253403123147	MAIN BEARING LOWER - NORMAL (MENON) (B)	TATA spare parts

253403123401	SET THRUST WASHER STD	TATA spare parts
253403123402	SET THRUST WASHER STD1	TATA spare parts
253403123404	THRUST WASHER-UPPER STD	TATA spare parts
253403123406	THRUST WASHER LOWER STD	TATA spare parts
253403130101	INDICATOR ASSY	TATA spare parts
253403130107	ASSY.VIBRATION DAMPER NON AC	TATA spare parts
253403130108	ASSY. VIBRATION DAMPER	TATA spare parts
253403137004	PULLEY CRANKSHAFT	TATA spare parts
253403137012	PULLEY CRANKSHAFT	TATA spare parts
253403137016	PULLEY-CRANKSHAFT FOR POWER STEERING	TATA spare parts
253403137022	PULLEY - CRANKSHAFT	TATA spare parts
253403137025	CRANKSHAFT PULLEY (162.5 DIA)	TATA spare parts
253403137026	CRANK SHAFT PULLEY	TATA spare parts
253403137035	SHAFT CRANKSHAFT PULLEY BS6	TATA spare parts
253403137041	CRANK SHAFT PULLEY BS6-PH2	TATA spare parts
253403137501	COVER(RUBBER)FOR CRANK SHAFT PULLEY	TATA spare parts
253403137502	CRANK SHAFT PULLEY COVER	TATA spare parts
253403138205	BOTTOM COVER (FLYWHEEL HOUSING)	TATA spare parts
253403140101	PISTON ASSY 96.89D STD	TATA spare parts
253403140174	RING OIL CONTROL GR3	TATA spare parts
253403140175	SET PISTON BARE 4SP 96.90	TATA spare parts
253403140178	SET PISTON BARE 4SP 96.88	TATA spare parts
253403140191	ASSY PISTON	TATA spare parts
253403140192	ASSY.PISTON.	TATA spare parts
253403140193	SET PISTON BARE 4SP 96.90	TATA spare parts
253403140197	SET PISTON RINGS BS-II	TATA spare parts
253403140258	ASSY.OIL CONTROL RING GR-III	TATA spare parts
253403140260	ASSY PISTON(REDCD.COMP.HT)W/ COMMON RIN	TATA spare parts
253403140282	ASSY.OIL RING-III	TATA spare parts
253403140298	ASSY PISTON W RINGS STD-III BS-III	TATA spare parts
253403140299	ASSY PISTON(MENON)+IPL RINGS(W/ R.C.HT)	TATA spare parts
253403140312	ASSY.PISTON W/COMMON RINGS 4SPTC CR BSIV	TATA spare parts
253403140314	ASSY.PISTON(MENON)WITH MENON RINGS	TATA spare parts
253403140315	ASSY. PISTON W/COMMON RINGS 4SPTC BSIII	TATA spare parts
253403140316	ASSY. PISTON W/COMMON RINGS 4SPCR BSIV	TATA spare parts
253403140389	PISTON ASSY WITH RING BS6	TATA spare parts
253403141009	PISTON BARE STD 96.90D	TATA spare parts
253403141024	PISTON 96.9 DIA	TATA spare parts
253403141037	PISTON BARE STD 96.89D	TATA spare parts
253403141045	PISTON BARE STD 96.89D	TATA spare parts
253403141049	PISTON 96.93	TATA spare parts
253403141096	PISTON-96.90	TATA spare parts
253403146701	PIN PISTON	TATA spare parts
253403146703	PIN PISTON	TATA spare parts
253403149905	RING TOP COMP	TATA spare parts
253403149906	II ND RING	TATA spare parts
253403149912	PISTON RING-PLASMA COA.COMP.GR-I	TATA spare parts

253403149913	PISTON RING-TAPER FAC.COMP GR	TATA spare parts
253403149916	PLASMA FILLED KEYSTONE RING-I	TATA spare parts
253403149917	PLASMA FIL TAPER FACED COMP.RING-II	TATA spare parts
253403150107	CONNECTING ROD	TATA spare parts
253403150110	CONNECTING ROD	TATA spare parts
253403150120	CONNECTING ROD	TATA spare parts
253403150159	ASSY. CON-ROD W/BUSH/BOLT NORM BS1-6	TATA spare parts
253403150179	CONNECTING ROD ASSY WITH BUSH & BOLT BS6	TATA spare parts
253403150189	CONNECTING ROD ASSY W/T BUSH & BOLT BS6	TATA spare parts
253403153106	CON.ROD BRG.-NORMAL(EURO III)	TATA spare parts
253403153107	CON.ROD BRG.(BIMETAL)-NORMAL-I	TATA spare parts
253403153108	CON ROD BRG. NORMAL	TATA spare parts
253403153110	CON ROD BEARING NORMAL	TATA spare parts
253403153136	BEARING HALF CONNECTING ROD BS6-PH2	TATA spare parts
253403153202	CONNECTING ROD BOLT	TATA spare parts
253403161001	PISTON WITH PIN&CIRCLIP	TATA spare parts
253403161005	PISTION	TATA spare parts
253403161020	PISTON STD	TATA spare parts
253403161022	PISTON-STD(DIA.96.880)-INDIA PISTONS LTD	TATA spare parts
253403161030	PISTON _STD_III DIA_96_880_M_S MENON_	TATA spare parts
253403161033	PISTON STD 96.88 DIA	TATA spare parts
253403161053	PISTON(RECT.I-GR DIA.96.890)	TATA spare parts
253403161067	PISTON:STD I(DIA 96.880) :EUROIII	TATA spare parts
253403161085	PISTON(STD-IIIDIA 96.880) BS-III	TATA spare parts
253403161088	PISTON(STD-IIIDIA 96.880) BS-II	TATA spare parts
253403990101	SET PISTON W/RINGS STD	TATA spare parts
253403990104	PISTON RING SET STD.	TATA spare parts
253403990113	SET MAIN BRG STD	TATA spare parts
253403990114	SET MAIN BRG STD1	TATA spare parts
253403990115	SET MAIN BRG RS1	TATA spare parts
253403990116	SET MAIN BRG RS2	TATA spare parts
253403990117	SET MAIN BRG RS3	TATA spare parts
253403990118	SET MAIN BRG RS4	TATA spare parts
253403990119	SET PISTON RINGS STD NPR	TATA spare parts
253403990120	SET PISTON W/RINGS STD	TATA spare parts
253403990121	PISTON SET STD	TATA spare parts
253403990123	SET PISTON RINGS STD	TATA spare parts
253403990124	RING SET 4SP NPR	TATA spare parts
253403990128	SET PISTON RINGS STD	TATA spare parts
253403990130	SET M.BRG.HALF U/L.R/S.2	TATA spare parts
253403990133	SET PISTON BARE 4SP	TATA spare parts
253403990134	SET PISTON BARE 4SP	TATA spare parts
253403990140	BARE PISTON SET STD PIC96	TATA spare parts
253403990143	BARE PISTON SET STD PIC96	TATA spare parts
253403990146	BARE PISTON SET STD PIC96	TATA spare parts
253403990148	SET MAIN BRG.UPPER/LOWER REP-I	TATA spare parts
253403990149	SET MAIN BRG.UPPER/LOWER REP-II	TATA spare parts

253403990150	SET MAIN BRG.UPPER/LOWER REP-III	TATA spare parts
253403990151	SET MAIN BRG.UPPER/LOWER REP-IV	TATA spare parts
253403990153	SET CON ROD BEARING REP-I	TATA spare parts
253403990154	SET CON ROD BEARING REP-II	TATA spare parts
253403990155	SET CON ROD BEARING REP-III	TATA spare parts
253403990156	SET CON ROD BEARING REP-IV	TATA spare parts
253403990157	CON ROD BRG SET NORM	TATA spare parts
253403990158	SET CON ROD BEARING STD-I	TATA spare parts
253403990169	BARE PISTON SET STD	TATA spare parts
253403990172	SET PISTON (STD) (96.88) W/O RINGS	TATA spare parts
253403990173	SET PISTON (STD) (96.89) W/O RINGS	TATA spare parts
253403990174	SET PISTON (STD) (96.90) W/O RINGS	TATA spare parts
253403990175	SET PISTON RINGS-STD	TATA spare parts
253403990182	SET PISTON RING	TATA spare parts
253403990183	SET OF BARE PISTON 4SP TC CMVR EURO 2 N	TATA spare parts
253403990184	SET BARE PISTON 4SP TC SLIPPER	TATA spare parts
253403990191	SET OF PISTON RINGS 4SP / 497 NA	TATA spare parts
253403990205	SET PISTON STD.(96.90)	TATA spare parts
253403990207	SET CONROD BRG. NORMAL E-III	TATA spare parts
253403990210	SET OF BARE PISTON 4SP TC BS-III STD	TATA spare parts
253403990211	SET OF PISTON RINGS STD 4SP/497 BS:III	TATA spare parts
253403990212	SET OF CON ROD STD 4SP/497 BS:III	TATA spare parts
253403990215	SET-BARE PISTON 207DI/SPACIO EURO1	TATA spare parts
253403990221	SET-PISTON RING 497EI&II_ 207DI EII&EIII	TATA spare parts
253403990222	SET-PISTON RING 497EI&II_ 207DI EII&EIII	TATA spare parts
253403990227	SET OF BARE PISTON 4SP BS:II	TATA spare parts
253403990228	SET-PISTON RING 4SP BS1/2/3	TATA spare parts
253403990229	SET-PISTON PIN & CIRCLIPS-CNG	TATA spare parts
253403990231	SET-PISTON RINGS -CNG BS-III	TATA spare parts
253403990235	SET OF BARE PISTON 4SP TC BS-III STD	TATA spare parts
253403990236	SET PISTON(REduced COMP HIGHT)W/O RINGS	TATA spare parts
253403990237	SET-PISTON W/O RINGS 3.0 CR4(SPARE) BS4	TATA spare parts
253403990238	SET-PISTON RINGS 3.0CR4 BS2/4	TATA spare parts
253403990243	SET CON ROD BEARING	TATA spare parts
253403990244	SET-CON ROD BUSH	TATA spare parts
253403990263	SET PISTON W/O RINGS 4SP TCIC BSIII MFIE	TATA spare parts
253403990264	SET PISTON RINGS 4SP TCIC BSIII MFIE(SPA	TATA spare parts
253403990280	SET MAIN BEARING U/L REPAIR-I	TATA spare parts
253403990281	SET MAIN BEARING U/L REPAIR-II	TATA spare parts
253403990282	SET MAIN BEARING U/L REPAIR-III	TATA spare parts
253403990283	SET MAIN BEARING U/L REPAIR-IV	TATA spare parts
253403990291	SET-PISTON W/O RINGS 4SPTC XENON BS1/3	TATA spare parts
253403990292	SET-PISTON RINGS 4SPTC BS3 XENON	TATA spare parts
253403990293	SET-PISTON RINGS XENON	TATA spare parts
253403990302	SET PISTON STD	TATA spare parts
253403990313	SET-BEARING CONN ROD REPAIR 1	TATA spare parts
253403990314	SET-BEARING CONN ROD REPAIR 2	TATA spare parts

253403990315	SET-BEARING CONN ROD REPAIR 3	TATA spare parts
253403990316	SET-BEARING CONN ROD REPAIR 4	TATA spare parts
253403990317	SET-MAIN BEARING UPPER/LOWER REPAIR 1	TATA spare parts
253403990318	SET-MAIN BEARING UPPER/LOWER REPAIR 2	TATA spare parts
253403990319	SET-MAIN BEARING UPPER/LOWER REPAIR 3	TATA spare parts
253403990320	SET-MAIN BEARING UPPER/LOWER REPAIR 4	TATA spare parts
253405100101	CAMSHAFT ASSY STD	TATA spare parts
253405100112	ASSY. CAMSHAFT W/CYL PIN BS3	TATA spare parts
253405100115	ASSY.CAMSHAFT WITH CYL PIN NORMAL E II &	TATA spare parts
253405100119	ASSY. CAMSHAFT W/CYL PIN:NORM BS2/3/4/6	TATA spare parts
253405100123	CAMSHAFT ASSY WITH CYL PIN BS6	TATA spare parts
253405106701	CYL PIN CAM SHAFT	TATA spare parts
253405107919	CAM SHAFT NORMAL EII & EIII 207 DI EX	TATA spare parts
253405107921	CAMSHAFT-NORMAL	TATA spare parts
253405107933	CAMSHAFT BS6-PH2	TATA spare parts
253405110102	CAM SHAFT GEAR & DRIVE GEAR(FIP)	TATA spare parts
253405110103	ASSY.CAMSHAFT GEAR WITH RUBBER 4SPTCBSII	TATA spare parts
253405113702	CRANK SHAFT GEAR (REDUCED MODULE)	TATA spare parts
253405113703	CRANKSHAFT GEAR-4SPTC BSII	TATA spare parts
253405115402	CAMSHAFT GEAR (REDUCED MODULE)	TATA spare parts
253405118601	SPACER BS6	TATA spare parts
253405129003	INLET VALVE(EVL)	TATA spare parts
253405129004	EXHAUST VALVE _4SP	TATA spare parts
253405129013	INLET VALVE	TATA spare parts
253405129014	EXHAUST VALVE	TATA spare parts
253405129017	INLET VALVE	TATA spare parts
253405129018	EXHAUST VALVE	TATA spare parts
253405129019	VALVE-INLET EURO-III	TATA spare parts
253405129020	VALVE-EXHAUST EURO-III	TATA spare parts
253405129021	EXH.VALVE (TUFFTRIDED)	TATA spare parts
253405139902	VALVE TAPPET INLET & EXHAUST BS1/2/3/4	TATA spare parts
253405139903	VALVE TAPPET STD1	TATA spare parts
253405139904	VALVE TAPPET RS1	TATA spare parts
253405139905	VALVE TAPPET RS2	TATA spare parts
253405140101	ASSY ROCKER ARM SHAFT WITH ARMS COMPLETE	TATA spare parts
253405140102	ASSY ROCKER ARM SHAFT	TATA spare parts
253405143701	ROCKER ARM SUPPORT NO:1 :BS-III	TATA spare parts
253405143702	ROCKER ARM SUPPORT NO:2 5 6:BS-III	TATA spare parts
253405143703	ROCKER ARM SUPPORT NO:3 4:BS-III	TATA spare parts
253405153402	VALUE GUIDE INLET STD	TATA spare parts
253405153403	VALUE GUIDE INLET STD1	TATA spare parts
253405153404	VALVE GUIDE INLET RS1	TATA spare parts
253405153405	VALVE GUIDE INLET RS2	TATA spare parts
253405153407	VALUE GUIDE EXHAUST STD	TATA spare parts
253405153408	VALUE GUIDE EXHAUST STD1	TATA spare parts
253405153409	VALVE GUIDE EXHAUST RS1	TATA spare parts
253405153410	VALVE GUIDE EXHAUST RS2	TATA spare parts

253405153415	VALVE GUIDE-EXHAUST-STD	TATA spare parts
253405153416	VALVE GUIDE-EXHAUST-STD-I	TATA spare parts
253405155101	LOCK RETAINER VALVE SPG	TATA spare parts
253405158701	VALVE SPRING INNER	TATA spare parts
253405158702	VALVE SPRING OUTER	TATA spare parts
253405159901	OIL SEAL V G-INLET-VITON	TATA spare parts
253405159902	OILSEAL V G-EXHAUST-VITON	TATA spare parts
253405159909	VALVE GUIDE SEAL-INLET	TATA spare parts
253405159910	VALVE GUIDE SEAL-EXHAUST BS4/6	TATA spare parts
253405167901	PUSH ROD INLET AND EXHAUST 4SPCR BS3/4	TATA spare parts
253405990102	SET CAM SHAFT BEARING	TATA spare parts
253405990103	SET-INLET & EXHAUST VALVES 4SP BS2	TATA spare parts
253405990106	SET-VALVE GUIDE SEAL INLET/EXHAUST 4CYL	TATA spare parts
253405990121	SET VALVE SEAT RING	TATA spare parts
253405990122	SET-VALVES-INLET(60 DEG)/EXHAUST	TATA spare parts
253407100106	ASSY. FIP (DICR)	TATA spare parts
253407100114	F I PUMP W/LEVER	TATA spare parts
253407100121	F I PUMP W/LEVER 4SP INDU	TATA spare parts
253407100124	F I PUMP W/LEVER MOD	TATA spare parts
253407100126	FUEL INJ PUMP LP 407	TATA spare parts
253407100140	ASSY FIP	TATA spare parts
253407100141	ASSY FIP	TATA spare parts
253407100146	FUEL INJECTION PUMP 4SP EURO II	TATA spare parts
253407100158	AIR FUEL MIXER	TATA spare parts
253407100160	ASSY FIP AAZAADI 207 DI HI TORQUE	TATA spare parts
253407100164	ASSY. FIP (207 DI SPACIO BSII)	TATA spare parts
253407100170	ASSY. FIP 207DI RX BSIII	TATA spare parts
253407100171	ASSY F I P 4SP BS-III	TATA spare parts
253407100174	AIR FUEL MIXER	TATA spare parts
253407100179	ASSY.FIP 4SPTC SPACIO/207DI BSII	TATA spare parts
253407100181	MIXER ASSY.WITH THROTTLE BODY	TATA spare parts
253407100183	ASSY.FIP WITH LEVER-HIGH TORQUE	TATA spare parts
253407100192	ASSY.FIP 4SPTCIC BS-III	TATA spare parts
253407100196	FIP ASSY WITH LEVER	TATA spare parts
253407100198	FIP ASSY WITH LEVER 25KVA	TATA spare parts
253407100203	FIP ASSY WITH LEVER 35VA GENSET	TATA spare parts
253407100205	SOLENOID VALVE ASSY	TATA spare parts
253407100206	ASSY. FUEL INJECTION PUMP BS3/4	TATA spare parts
253407100209	FUEL INJECTION PUMP ASSY	TATA spare parts
253407100219	FUEL INJECTION PUMP ASSYBS6	TATA spare parts
253407100223	ASSY.FIP(DI.CR)-BLACK IMV	TATA spare parts
253407108201	TIMING DISC	TATA spare parts
253407109901	FLANGE NUT (DELPHI FIP)	TATA spare parts
253407120102	ASSY.BRACKET FIP MTG.ON CYL.CRANKCASE	TATA spare parts
253407120103	ASSY.BRACKET(FIP MTG.ON CYL.CRANKCASE)	TATA spare parts
253407120112	ASSY BRACKET(FOR FIP MTG.ON CYLCRANKCASE)	TATA spare parts
253407120113	CLAMP(FUEL LINE ON CYLINDER HEAD)	TATA spare parts

253407120114	CLAMP(FUEL LINE ON CYLINDER HEAD)	TATA spare parts
253407123701	SUPPORT FUEL INJ PUMP	TATA spare parts
253407123702	SUPPORT (FOR FIP)	TATA spare parts
253407123703	MOUNTING BRACKET FIP FRONT SUPPORT	TATA spare parts
253407123721	ADAPTER FIP BS6	TATA spare parts
253407123723	SUPPORT BRACKET FIP TO BLOCK REAR	TATA spare parts
253407123801	BRACKET (FIP REAR SUPPORT) BS4	TATA spare parts
253407125301	GASKET SUPPORT INJECTION PUMP	TATA spare parts
253407125302	GASKET (FOR SUPPORT)	TATA spare parts
253407125303	GASKET (FIP TO SUPPORT)	TATA spare parts
253407127801	O RING FIP FRONT MOUNT	TATA spare parts
253407130110	PNEUMATIC SHUTOFF DEVICE	TATA spare parts
253407130117	ASSY.BRACKET.	TATA spare parts
253407130118	ASSY.BRACKET SUPPORT FOR CABLE-ENG.STOP	TATA spare parts
253407130124	ASSY VACUUM CYLINDER	TATA spare parts
253407130125	ASSY.DRIVE GEAR WITH COVER 4SPTCBSII	TATA spare parts
253407130126	ASSY.CAMSHAFT GEAR&DRIVE GEAR(FIP)4SPTC	TATA spare parts
253407130127	ASSY BRACKET ( SUPPORT FOR CABLE -ENGINE	TATA spare parts
253407130128	VACUUM CYLINDER (L=141)	TATA spare parts
253407135402	DRIVE GEAR (REDUCED MODULE)	TATA spare parts
253407135403	FIP GEAR(REDUCED MODULE)	TATA spare parts
253407135404	DRIVE GEAR(FUEL INJECTION PUMP)4SPTCBSII	TATA spare parts
253407135405	INJECTION PUMP GEAR	TATA spare parts
253407135411	GEAR FUEL INJECTION PUMP BS6	TATA spare parts
253407139901	BALL END	TATA spare parts
253407140101	SET FUEL PR LINES	TATA spare parts
253407140102	FUEL PR LINE CYL NO 1	TATA spare parts
253407140103	FUEL PR LINE CYL NO 2	TATA spare parts
253407140104	FUEL PR LINE CYL NO 3	TATA spare parts
253407140105	ASSY.FUEL PRESSURE LINE	TATA spare parts
253407140107	FUEL LINE SET HIGH PRESS.	TATA spare parts
253407140117	ASSY FUEL PRESSURE LIME	TATA spare parts
253407140118	ASSY FUEL PRESSURE LINE	TATA spare parts
253407140119	ASSY FUEL PRESURE LINE	TATA spare parts
253407140120	FUEL PRESSURE LINE CYL.NO	TATA spare parts
253407140121	ASSY. HP LINES (FIP TO CR)	TATA spare parts
253407140122	FUEL PRESS LINE SET LP407	TATA spare parts
253407140126	SET FUEL PRESSURE LINE	TATA spare parts
253407140127	ASSY FUEL PRE LINE	TATA spare parts
253407140128	ASSY FUEL PRE LINE	TATA spare parts
253407140129	ASSY FUEL PRE LINE	TATA spare parts
253407140130	ASSY FUEL PRE LINE	TATA spare parts
253407140131	SET OF FUEL PR. LINE	TATA spare parts
253407140132	ASSY FUEL PRE LINE	TATA spare parts
253407140133	ASSY FUEL PRE LINE	TATA spare parts
253407140134	SET- ASSY.H.P.FUEL LINE-EURO-II-LP/LPT	TATA spare parts
253407140135	ASSY.FUEL PRESSURE LINE-BENT-CYL.NO.1	TATA spare parts



253407140136	ASSY.FUEL PRESSURE LINE-BENT-CYL.NO.2	TATA spare parts
253407140137	ASSY. FUEL PRESSURE LINE - BENT CYL. NO.	TATA spare parts
253407140138	ASSY.FUEL PRESSURE LINE-BENT-CYL.NO.4	TATA spare parts
253407140140	SET- ASSY.H.P.FUEL LINES-EURO-II-SFC	TATA spare parts
253407140141	ASSY.FUEL PRESSURE LINE BENT CYL.NO.3	TATA spare parts
253407140142	SET-ASSY.H.P.LINES-BS-III SFC-407	TATA spare parts
253407140143	ASSY. HP LINE (RAIL TO INJECTOR NO.1)	TATA spare parts
253407140144	ASSY. HP LINE (RAIL TO INJECTOR NO.2)	TATA spare parts
253407140145	ASSY. HP LINE (RAIL TO INJECTOR NO.3)	TATA spare parts
253407140146	ASSY. HP LINE (RAIL TO INJECTOR NO.4)	TATA spare parts
253407140147	SET-HP PIPE DICOR BS3/4	TATA spare parts
253407140148	SET BACK LEAK HOSES	TATA spare parts
253407140149	SET.ASSY.HP LINES LP-407 BS-III	TATA spare parts
253407140161	ASSY FUEL RAIL (3L DICOR ENGINE)	TATA spare parts
253407140162	SET ASSY HP PIPE DICOR	TATA spare parts
253407140163	HP PIPE (PUMP TO RAIL DICOR) IMPERIAL	TATA spare parts
253407140164	HP PIPE (RAIL TO INJECTOR 1) IMPERIAL	TATA spare parts
253407140165	HP PIPE (RAIL TO INJECTOR 2) IMPERIAL	TATA spare parts
253407140166	HP PIPE (RAIL TO INJECTOR 3) IMPERIAL	TATA spare parts
253407140167	HP PIPE (RAIL TO INJECTOR 4)IMPERIAL	TATA spare parts
253407140178	KIT-HP LINES CLAMPS & SUPPORT BKT BS3	TATA spare parts
253407140184	ASSY BRACKET (HP LINES) 4SP TCIC BS-III	TATA spare parts
253407140189	SET FUEL PRESSURE PIPE BS1/2/3	TATA spare parts
253407140190	SET- ASSY.H.P.FUEL LINE-DIA.6.35-BS-II	TATA spare parts
253407140191	ASSY.FUEL PRESSURE LINE-BENT-CYL.NO.1-DI	TATA spare parts
253407140192	ASSY.FUEL PRESSURE LINE-BENT-CYL.NO.2-DI	TATA spare parts
253407140193	ASSY.FUEL PRESSURE LINE-BENT-CYL.NO.3-DI	TATA spare parts
253407140194	ASSY.FUEL PRESSURE LINE-BENT-CYL.NO.4-DI	TATA spare parts
253407140228	FUEL PR LINE BENT PUMP TO RAIL BS3/4	TATA spare parts
253407140229	FUEL LINE BENT ASSY RAIL TO INJ-1	TATA spare parts
253407140230	FUEL LINE BENT ASSY RAIL TO INJ-2	TATA spare parts
253407140231	FUEL LINE BENT ASSY RAIL TO INJ-3	TATA spare parts
253407140232	FUEL LINE BENT ASSY RAIL TO INJ-4	TATA spare parts
253407140233	SET ASSY. H.P. LINES BS4	TATA spare parts
253407140247	SET-BACK LEAK HOSE	TATA spare parts
253407140260	SET-HP PIPE ASSY WITH CLAMPS	TATA spare parts
253407140274	SUPPORT BRACKET FIP MTG (WITH WELD NUT)	TATA spare parts
253407140275	HP PIPE ASSY RAIL TO INJECTOR BS6	TATA spare parts
253407140276	HP PIPE ASSY RAIL TO INJECTOR BS6	TATA spare parts
253407140277	HP PIPE ASSY RAIL TO INJECTOR BS6	TATA spare parts
253407140278	HP PIPE ASSY RAIL TO INJECTOR BS6	TATA spare parts
253407140279	HP PIPE ASSY FIP TO RAIL BS6	TATA spare parts
253407140280	KIT-HP LINE BS6	TATA spare parts
253407140284	SUPPORT BRACKET FIP TO BLOCK REAR	TATA spare parts
253407140287	FUEL RAIL ASSY BS6	TATA spare parts
253407140288	BACK LEAK SYSTEM ASSY BS6	TATA spare parts
253407140301	HP PIPE ASSY FIP TO RAIL BS6-PH2	TATA spare parts

253407140302	HP PIPE ASSY RAIL TO INJECTOR BS6-PH2	TATA spare parts
253407140303	HP PIPE ASSY RAIL TO INJECTOR BS6-PH2	TATA spare parts
253407140304	HP PIPE ASSY RAIL TO INJECTOR BS6-PH2	TATA spare parts
253407140305	HP PIPE ASSY RAIL TO INJECTOR BS6-PH2	TATA spare parts
253407143301	SUPPORT (REAR FOR FIP DICR)	TATA spare parts
253407143304	ASSY. BRACKET FOR W/H (COMMON RAIL)	TATA spare parts
253407143309	SUPPORT BRACKET FIP MTG	TATA spare parts
253407145801	HOSE BACK LEAK (120MM LENGTH)	TATA spare parts
253407145802	HOSE BACK LEAK (25MM LENGTH)	TATA spare parts
253407145803	HOSE BACK LEAK (45MM LENGTH)	TATA spare parts
253407145804	HOSE BACK LEAK (275MM LENGTH)	TATA spare parts
253407145805	HOSE BACK LEAK (140 LENGTH)	TATA spare parts
253407145806	HOSE BACK LEAK (30MM LENGTH)	TATA spare parts
253407145808	RUBBER HOSE OVERFLOW LINE	TATA spare parts
253407147501	RUBBER GROMMET(FOR 2PIPES VP37 FIP LINES	TATA spare parts
253407147503	ISOLATOR PLASTIC (TWO HP LINES)	TATA spare parts
253407148203	CLAMP (TWO HP LINES) 4SP TCIC BS-III	TATA spare parts
253407148601	RAIL MOUNTING SPACER	TATA spare parts
253407150101	COLD START PILOT KIT	TATA spare parts
253407150104	QUICK START UNIT(COLD START)	TATA spare parts
253409110101	FUEL FILTER ASSY	TATA spare parts
253409110105	BRACKET FIP MTG SFC	TATA spare parts
253409110107	FUEL FILTER BRACKET	TATA spare parts
253409110108	ASSY. FUEL FILTER	TATA spare parts
253409110110	SPACER 9 ID-FOR ENG. SHUT OFF MTG.BRKT	TATA spare parts
253409110111	SPACER 11 ID FOR ENG.SHUT OFF MTG. BKT	TATA spare parts
253409110113	SEDIMENTER	TATA spare parts
253409110116	ASSY BRACKET (FUEL FILTER) SPRINT	TATA spare parts
253409110117	ASSY. FUEL FILTER DELPHI	TATA spare parts
253409110117AE	FUEL FILTER - XEN DC XEN SC	TATA spare parts
253409110118	ASSY. SEDIMENTOR BS4	TATA spare parts
253409110119	ASSY. PRE FILTER (5 MICRON) BS3	TATA spare parts
253409110120	ASSY PRE FILTER	TATA spare parts
253409110121	ASSY. FUEL PRE FILTER	TATA spare parts
253409113301	ASSY. BRACKET (NO LOSS TANK MTG)	TATA spare parts
253409113701	BRACKET FUEL FILTER	TATA spare parts
253409113703	ASSY.BRACKET-FUEL FILTER MTG.WITH M12	TATA spare parts
253409113705	ASSY BRACKET (FUEL FILTER MOUNTING)	TATA spare parts
253409119901	FILTER	TATA spare parts
253409119902	WATER SENSOR	TATA spare parts
253409120101	OVERFLOW LINE	TATA spare parts
253409120103	FUEL LINE FILTER TO FIP	TATA spare parts
253409120104	FUEL LINE FEEDPUMP-FILTER	TATA spare parts
253409120105	ASSY FUEL LINE F/F TOFIP	TATA spare parts
253409120107	OVERFLOW LINE	TATA spare parts
253409120108	FUEL LINE FILTER TO FIP	TATA spare parts
253409120109	FUEL LINE F/PUMP TO FILTE	TATA spare parts

253409120113	ASSY FUEL LINE FILTER TO FIP	TATA spare parts
253409120114	ASSY FUEL LINE FEED PUMP TO FILTER	TATA spare parts
253409120117	FUELLINE FIL TO FIP LP407	TATA spare parts
253409120118	FUEL LINE FEED TO FIL LP	TATA spare parts
253409120119	OVERFLOW LINE LP 407	TATA spare parts
253409120129	ASSY. OVERFLOW LINE(COMBINED)	TATA spare parts
253409120132	ASSY.FUEL LINE(FEED PUMP TO FILTER) LPT4	TATA spare parts
253409120133	ASSY.FUEL LINE FEED PUMP TO FILTER	TATA spare parts
253409120134	ASSY.FUEL LINE(FILTER TO FIP) LPT407TURB	TATA spare parts
253409120135	ASSY.FUEL LINE FILTER OUTLET TO FIP	TATA spare parts
253409120136	FUEL LINE FUEL FILTER TO FIP	TATA spare parts
253409120137	ASSY.FUEL LINE FEED PUMP TO FILTER	TATA spare parts
253409120138	FUEL LINE F/PUMP TO FUEL FILTER	TATA spare parts
253409120139	FUEL LINE FUEL FILTER TO FIP	TATA spare parts
253409120140	ASSY. FUEL LINE-FEED PUMP TO FILTER	TATA spare parts
253409120141	ASSY. OVERFLOW LINE 4SP RTV	TATA spare parts
253409120143	ASSY. FUEL LINE FILTER TO FIP 4SP SFC	TATA spare parts
253409120146	ASSY.LDA LINE-ELBOW TO FIP	TATA spare parts
253409120147	ASSY FUEL LINE 4SP EURO II SFC/LP/LPT	TATA spare parts
253409120148	ASSY FUEL LINE-FEED PUMP TO FILTER	TATA spare parts
253409120149	ASSY. OVERFLOW LINE (COMBINED)	TATA spare parts
253409120150	ASSY.FUEL LINE(FILTER TO FIP)-SFC/LP	TATA spare parts
253409120152	ASSY. FUEL LINE(FEED PUMP TO FILTER)	TATA spare parts
253409120156	ASSY.FUELLINE FIL.TO FIP SFC BS-III SPIN	TATA spare parts
253409120160	ASSY. FUEL LINE (FILTET TO FIP)	TATA spare parts
253409120172	ASSY OVERFLOW LINE	TATA spare parts
253409120175	ASSY FUEL LINE (F.PUMP TO FILTER)	TATA spare parts
253409120176	ASSY FUEL LINE (FILTER TO FIP)	TATA spare parts
253409120183	FUEL LINE (FUEL FILTER TO FIP)	TATA spare parts
253409120184	FUEL LINE (FEED PUMP TO FUEL FILTER)	TATA spare parts
253409120188	FUEL LINE (FUEL FILTER TO FEED PUMP)	TATA spare parts
253409120189	ASSY FUEL LINE(FUEL FILTER TO FIP)	TATA spare parts
253409124201	CLAMP (OVER FLOW LINE)	TATA spare parts
253409125801	RUBBER HOSE	TATA spare parts
253409125802	RUBBER HOSE 160 MM	TATA spare parts
253409125803	RUBBER HOSE OVERFLOW	TATA spare parts
253409125805	HOSE (OVER FLOW LINE) (380)	TATA spare parts
253409130104	CLAMPING BKT A/FILTER MTG	TATA spare parts
253409130106	AIR FILTER ASSY OIL BATH	TATA spare parts
253409130107	AIR FILTER ASSY OIL BATH	TATA spare parts
253409130108	ASSY STRAP	TATA spare parts
253409130110	AIR FILTER ASSY DRY TYPE	TATA spare parts
253409130111	AIR FILTER W/FILT ELEMENT	TATA spare parts
253409130113	ASSY CARTRIDGE	TATA spare parts
253409130122	AIR FILTER ASSY OIL BATH	TATA spare parts
253409130124	ASSY AIRINTAKE UNIT WITH WATER GUARD	TATA spare parts
253409130127	ASSY.BKT(FOR AIR FILTER MTG.) SFC407TC	TATA spare parts

253409130131	SAFETY CARTRIDGE	TATA spare parts
253409130134	PIPE INTERMEDIATE	TATA spare parts
253409130147	ASSY AIR FILTER	TATA spare parts
253409130150	PIPE AIR LDA UNIT INTAKE	TATA spare parts
253409130161	ASSY.CARTRIDGE	TATA spare parts
253409130162	SAFETY CARTRIDGE	TATA spare parts
253409130176	ASSY.AIR FILTER [OIL BATH]	TATA spare parts
253409130177	ASSY AIR INLET DUCT	TATA spare parts
253409130178	ASSY.CARTRIDGE	TATA spare parts
253409130179	ASSY.SAFETY CARTRIDGE-OFFER DRG	TATA spare parts
253409130183	ASSY SUCTION PIPE	TATA spare parts
253409130184	ASSY.AIR FILTER W/SOUND D-NING PAD	TATA spare parts
253409130190	ASSY.AIR FILTER W/SOUND D-ING PAD	TATA spare parts
253409130201	ASSY AIR FILTER COMPLETE	TATA spare parts
253409130202	ASSY.BRACKET-AIR FILTER MTG.	TATA spare parts
253409130203	ASSY.BRACKET-AIR FILTER MTG.	TATA spare parts
253409130206	ASSY.BRACKET-8M3 AIR FILTER MTG	TATA spare parts
253409130207	ASSY.SHAKLE	TATA spare parts
253409130214	ASSY.PIPE (AIR FILTER TO TC)-LP/LPT	TATA spare parts
253409130222	ASSY. FILTER ELEMENT	TATA spare parts
253409130233	ASSY.AIR FILTER COMPLETE	TATA spare parts
253409130236	ASSY.BRACKET (AIR FILTER MTG.)	TATA spare parts
253409130238	ASSY AIR FILTER WITH PRECLEANER.	TATA spare parts
253409130239	VACUUM INDICATOR BS4	TATA spare parts
253409130241	ASSY. FILTER ELEMENT WINGER BS1/2/3/4	TATA spare parts
253409130242	ASSY BRACKET (AIR FILTER MOUNTING)	TATA spare parts
253409130243	ASSY PRECLEANER WITH MOUNTING.	TATA spare parts
253409130245	ASSY AIR FILTER COMPLETE	TATA spare parts
253409130246	ASSY AIR FILTER DICOR	TATA spare parts
253409130248	ASSY HOSE( AIR FILTER TO INLET ELBOW)	TATA spare parts
253409130251	ASSY AIR FILTER 7M3 DICOR	TATA spare parts
253409130253	ASSY.BRACKET AIR FILTER MOUNTING	TATA spare parts
253409130254	ASSY.AIR FILTER 4SPTC BSIII	TATA spare parts
253409130255	ASSY AIR FILTER (DICOR)_SPRINT	TATA spare parts
253409130257	ASSY.RUBBER HOSE(AIR FILTER-INTAKE ELBOW	TATA spare parts
253409130258	ASSY AIR CLEANER F GUARD 4SPTC BSII	TATA spare parts
253409130266	SET:AIR INTAKE SYS:9M3 A/F SFC410 FLTG	TATA spare parts
253409130268	SET:AIR INTAKE SYS:9M3 A/F SFC407	TATA spare parts
253409130271	ASSY BRACKET AIR FILTER MOUNTING	TATA spare parts
253409130274	ASSY.AIR FILTER 4SPCR BSIV VICTA	TATA spare parts
253409130280	ASSY OULET PIPE WITH BRACKET	TATA spare parts
253409130281	HOSE CLAMP T BOLT	TATA spare parts
253409130283	SET AIR INTAKE SYSTEM M/S FLTG LPT410 EX	TATA spare parts
253409130301	ASSY. AIR CLEANER SFC410 BS2/3/4	TATA spare parts
253409130302	T BOLT TYPE HOSE CLAMP SFC410 BS4	TATA spare parts
253409130303	T-BOLT TYPE HOSE CLAMP SFC410	TATA spare parts
253409130304	AIR CLEANER ASSY BS6	TATA spare parts

253409130305	ELEMENT AIR CLEANER(PRIMARY) BS2/3/4/6	TATA spare parts
253409130306	ELEMENT AIR CLEANER(SAFTY) BS2/3/4/6	TATA spare parts
253409130309	ASSY BRACKET	TATA spare parts
253409130316	T BOLT TYPE HOSE CLAMP SFC410	TATA spare parts
253409130346	ASSY AIR FILTER+PRECLEANER 4SPTC	TATA spare parts
253409130355	ASSY. AIR FILTER XENON	TATA spare parts
253409130356	PRIMARY ELEMENT AIR FILTER BS3/4	TATA spare parts
253409130363	ASSY.HOSE(AIR FILTER TO HFM SENSOR)	TATA spare parts
253409130365	ASSY. AIR INTAKE UNIT	TATA spare parts
253409130368	ELEMENT AIR FILTER(PRIMARY)	TATA spare parts
253409130369	ASSY. BRACKET (AIR FILTER BRACKET)	TATA spare parts
253409130376	ASSY. HOSE (AIR FILTER TO HFM SENSOR)	TATA spare parts
253409130398	ASSYAIR INTAKE UNIT(ON CAB)	TATA spare parts
253409130399	ASSY. AIR FILTER MTG BKT	TATA spare parts
253409131601	ASSY.AIR CLEANER 4SP BSII/BSIIN	TATA spare parts
253409133324	BRACKET CLEAN SIDE PIPE SUPPORT	TATA spare parts
253409133330	BRACKET ASSY BS6-PH2	TATA spare parts
253409133801	ADAPTOR (HFM SENSOR)	TATA spare parts
253409134204	HOSE CLAMP TB 94	TATA spare parts
253409134205	HOSE CLAMP TB 80 BS4	TATA spare parts
253409134207	HOSE CLAMP SFC410	TATA spare parts
253409134209	CLAMP (PRE CLEANER HOSE)	TATA spare parts
253409135301	GASKET SFC410	TATA spare parts
253409135801	RUBBER HOSE	TATA spare parts
253409135802	RUBBER HOSE	TATA spare parts
253409135803	RUBBER HOSE	TATA spare parts
253409135808	HOSE (FROM PIPE TO TC)	TATA spare parts
253409135810	RUB HOSE IN ELBOW TO PIPE	TATA spare parts
253409135811	RUB HOSE A/FILTER TO PIPE	TATA spare parts
253409135820	RUBBER HOSE TC TO PIPE	TATA spare parts
253409135821	RUBBER HOSE	TATA spare parts
253409135822	HOSE NLS AIR SUCTION	TATA spare parts
253409135824	RUBBER HOSE	TATA spare parts
253409135827	RUBBER HOSE	TATA spare parts
253409135831	RUBBER HOSE( AIR FILTER TO INLET ELBOW	TATA spare parts
253409135835	HOSE TC TO INTAKE PIPE MOD.INTAKE	TATA spare parts
253409135836	HOSE-MOD.INTAKE-(PIPE TO TC)-SFC	TATA spare parts
253409135842	HOSE (ELBOW TO AIR FILTER)-FACELESS	TATA spare parts
253409135843	HOSE (AIR FILTER TO ELBOW)	TATA spare parts
253409135844	COBRA HOSE (ON MIXER)	TATA spare parts
253409135845	HOSE AIR FILTER TO ELBOW	TATA spare parts
253409135846	RUBBER HOSE PIPE TO TC	TATA spare parts
253409135847	AIR INLET DUCT (ON RH DUCT)	TATA spare parts
253409135849	HOSE (AIR FILTER TO HFM SENSOR)	TATA spare parts
253409135851	HOSE (HFAM TO PIPE)	TATA spare parts
253409135853	HOSE(PRE-CLEANER TO AIR FILTER)	TATA spare parts
253409135855	RUBBER HOSE AIR FILTER-AIR SCOOP-4SPTC	TATA spare parts

253409135858	RUBBER HOSE (A/F TO TC)LP/LPT 407	TATA spare parts
253409135859	HOSE (AIRFILTER TO MIXER)	TATA spare parts
253409135862	HOSE (AIR FILTER TO HFAM)	TATA spare parts
253409135866	HOSE-AIR INTAKE UNIT TO AIR FILTER.	TATA spare parts
253409135868	RUBBER HOSE (TURBOCHARGER TO PIPE)	TATA spare parts
253409135869	HOSE (AF PIPE TO TC)	TATA spare parts
253409135872	ELBOW HOSE SFC410	TATA spare parts
253409135873	HOSE- DIA 46.5MM-KKK TC:SFC407	TATA spare parts
253409135876	HOSE (SNORKEL TO AIR FILTER)	TATA spare parts
253409135879	REDUCER ELBOW HOSE SFC410	TATA spare parts
253409135891	RUBBER HOSE (HFM SENSOR TO TC)	TATA spare parts
253409135897	RUBBER HOSE(HFM SENSOR TO TC)	TATA spare parts
253409136301	RUBBER SEAL	TATA spare parts
253409136302	RUBBER BELLOW(AIR FILTER TO PIPE)	TATA spare parts
253409136315	FLANGE CONNECTOR	TATA spare parts
253409136316	PIPE FROM AIR FILTER TO TC	TATA spare parts
253409136501	HEX. NUT SFC410	TATA spare parts
253409136502	WING NUT SFC410	TATA spare parts
253409136904	SUCTION PIPE	TATA spare parts
253409136916	PIPE AIR FILTER TO TC	TATA spare parts
253409136923	PIPE(AIR FILTER HOSE TO TURBOCHARGERHOSE	TATA spare parts
253409136926	PIPE AIR FILTER TO TC	TATA spare parts
253409136929	PIPE (AIR FILTER TO TC)	TATA spare parts
253409136933	PIPE-AIR FILTER TO TC	TATA spare parts
253409136941	PIPE-FROM FILTER TO MIXER	TATA spare parts
253409136942	PIPE (HFAM HOSE TO TC HOSE)	TATA spare parts
253409136945	LOCATING PIN AIR FILTER.	TATA spare parts
253409136947	PIPE (AIR FILTER TO TC)	TATA spare parts
253409136952	OUTLET PIPE-1 SFC410	TATA spare parts
253409136954	SUCTION PIPE (AIR FILTER)	TATA spare parts
253409136955	SUCTION PIPE (AIR FILTER)	TATA spare parts
253409136966	AIR PRESSURE PIPE ASSY BS6	TATA spare parts
253409136998	OUTLET PIPE	TATA spare parts
253409136999	PIPE (AIR FILTER TO TC)	TATA spare parts
253409137705	ASSY. AIR INLET DUCT-HDPE	TATA spare parts
253409137706	SEALING RING (HOT FILM AIR MFS)	TATA spare parts
253409137709	PIPE (AIR FILTER TO TC)	TATA spare parts
253409138240	STRAP(25 WIDTH)	TATA spare parts
253409139902	RUBBER STRAP	TATA spare parts
253409139903	RUBBER STRAP	TATA spare parts
253409139904	RUBBER STRAP.	TATA spare parts
253409139905	RUBBER STRAP	TATA spare parts
253409139911	GASKET	TATA spare parts
253409139912	SEALING WASHER	TATA spare parts
253409139913	DUST CAP	TATA spare parts
253409139914	HOSE CLAMP	TATA spare parts
253409139915	GROMMET	TATA spare parts

253409139916	WING NUT	TATA spare parts
253409139918	RUBBER STRAP	TATA spare parts
253409139919	SEALING WASHER	TATA spare parts
253409139920	GASKET	TATA spare parts
253409139921	WING NUT	TATA spare parts
253409139922	DUST CAP SFC410	TATA spare parts
253409139923	INLET PIPE COVER SFC410	TATA spare parts
253409139926	GASKET	TATA spare parts
253409139931	RUBBER STRAP(AIR FILTER MTG.BRACKET)	TATA spare parts
253409139944	SEALING FOAM AIR INTAKE DUCT BS6	TATA spare parts
253409140113	ASSY. AIR INTAKE UNIT (PLASTIC)	TATA spare parts
253409140114	ASSY. AIR FILTER 207DI SOUTHAFRICA B	TATA spare parts
253409140115	ASSY.HOSE - AIR FILTER OUTLET.	TATA spare parts
253409140119	ASSY. AIR FILTER XENON EX B	TATA spare parts
253409140122	ASSY.HOSE(AIR FILTER TO HFM SENSOR)	TATA spare parts
253409140126	ASSY.SUPPORT BRACKET (TC TO IC PIPE )	TATA spare parts
253409140132	ASSY. PRIMARY ELEMENT 8M3 BS2/3	TATA spare parts
253409140133	AIR FILTER ELEMENT- SAFETY BS2/3	TATA spare parts
253409140135	ASSY.PIPE (AIR FILTER TO TC)	TATA spare parts
253409140139	SET AIR INTAKE SYS SFC407 4SPCR BSIV(FG)	TATA spare parts
253409140146	ASSY.AIR CLEANER 4SPCR BSIV	TATA spare parts
253409140149	ASSY. PIPE(AIR FILTER TO TC)	TATA spare parts
253409140153	HOSE CLAMP T BOLT	TATA spare parts
253409140163	AIR INTAKE SYSTEM	TATA spare parts
253409140172	KIT AIR INTAKE SYSTEM	TATA spare parts
253409140173	ASSY PIPE (A/F TO HOSE TC) AND CLAMP	TATA spare parts
253409140179	HOSE ASSY (AIR FILTER OUTLET)	TATA spare parts
253409140184	BRACKET AIR INTAKE SYSTEM	TATA spare parts
253409140197	ASSY PIPE WITH BRACKET	TATA spare parts
253409140201	ISOLATORVIBRATION BS6	TATA spare parts
253409140205	AIR INTAKE SYSTEM	TATA spare parts
253409140206	AIR INTAKE KIT	TATA spare parts
253409140213	AIR PIPE ASSY AIR INTAKE TO LDA	TATA spare parts
253409140218	BRACKET ASSY	TATA spare parts
253409140223	HOSE ASSY	TATA spare parts
253409140225	HOSE AIR FILTER OUTLET	TATA spare parts
253409140230	PIPE ASSY WITH BRACKET	TATA spare parts
253409140237	PIPE ASSY WITH BRACKET	TATA spare parts
253409140244	SUPPORT BRACKET DIRTY SIDE PIPE	TATA spare parts
253409140245	AIR FILTER ASSY	TATA spare parts
253409140246	AIR INTAKE DUCT	TATA spare parts
253409140254	AIR FILTER ASSY	TATA spare parts
253409140256	SUCTION PIPE ASSY BS6	TATA spare parts
253409140271	ASSY.AIR INTAKE SYSTEM	TATA spare parts
253409140274	BRACKET ASSY AIR FILTER MTG	TATA spare parts
253409140276	AIR FILTER ASSY WITH BRACKET	TATA spare parts
253409140285	AIR INTAKE SYSTEM ASSY	TATA spare parts

253409140292	AIR CLEANER ASSY	TATA spare parts
253409140293	AIR CLEANER ASSY	TATA spare parts
253409140294	AIR CLEANER ASSY WITH MTG BRACKET	TATA spare parts
253409140296	Air filter PRIMARY ELEMENT	TATA spare parts
253409140297	Air filter SAFETY ELEMENT	TATA spare parts
253409140299	AIR FILTER ASSY W/O PIPE AIR INTAKE BS6	TATA spare parts
253409140301	T BOLT TYPE HOSE CLAMP SFC407 BS4	TATA spare parts
253409140304	T-BOLT TYPE HOSE CLAMP TB-36.	TATA spare parts
253409140305	HOSE ASSY	TATA spare parts
253409140307	AIR INTAKE SYSTEM WITH BRACKET	TATA spare parts
253409140309	AIR INTAKE SYSTEM ASSY	TATA spare parts
253409140313	AIR INTAKE SYSTEM ASSY BS6	TATA spare parts
253409140314	AIR INTAKE SYSTEM ASSY	TATA spare parts
253409140315	AIR INTAKE SYSTEM ASSY¿BS6	TATA spare parts
253409140316	HOSE BS6	TATA spare parts
253409140317	PIPE ASSY BS6	TATA spare parts
253409140320	BRACKET AIR FILTER MTG BS6	TATA spare parts
253409140321	AIR FILTER ASSY W/O BRACKET (25340914031	TATA spare parts
253409140325	AIR CLEANER ASSY WITH MTG BRACKET	TATA spare parts
253409140326	BRACKET ASSY	TATA spare parts
253409140327	AIR CLEANER ASSY¿ BS6	TATA spare parts
253409140329	PIPE ASSYBS6	TATA spare parts
253409140330	BRACKET ASSY AIR FILTER MTG BS6	TATA spare parts
253409140331	PIPEASSY BS6	TATA spare parts
253409140332	PIPEASSY BS6	TATA spare parts
253409140336	KIT-AIR INTAKE ASSYBS6	TATA spare parts
253409140337	PIPE ASSY AIR FILTER TO TC BS6	TATA spare parts
253409140345	AIR INTAKE PIPE ASSY A/F TO T/C BS6	TATA spare parts
253409140346	AIR INTAKE SYSTEM ASSY (253409140334) 29	TATA spare parts
253409140347	RESTRICTIONINDICATORPIPEASSY BS6	TATA spare parts
253409140348	AIR INTAKE SYSTEM BS6	TATA spare parts
253409140349	KIT-AIR INTAKE PIPE & BRACKET ASSY BS6	TATA spare parts
253409140350	AIR INTAKE PIPE ASSY A/F TO T/C BS6	TATA spare parts
253409140351	HOSE REDUCER ELBOW BS6	TATA spare parts
253409140352	BRACKET ASSY AIR FILTER MTG	TATA spare parts
253409140353	CLAMP PIPE ASSY BS6	TATA spare parts
253409140356	AIR INTAKE SYSTEM ASSY BS6	TATA spare parts
253409140366	BRACKET BS6	TATA spare parts
253409140379	AIR INTAKE SYSTEM ASSY SFC 407 4X4 BS6	TATA spare parts
253409140381	BRACKET BS6	TATA spare parts
253409140382	RESTRICTION INDICATOR PIPE ASSY BS6-PH2	TATA spare parts
253409140397	KITFLASEAIR INTAKE SYSTEM BS6-PH2	TATA spare parts
253409140399	AIR INTAKE SYSTEM ASSY BS6-PH2	TATA spare parts
253409145807	HOSE(PIPE TO AIR INTAKE ELBOW)	TATA spare parts
253409145812	RUBBER HOSE (AIR FILTER TO TC PIPE)	TATA spare parts
253409145813	RUBBER HOSE (AIR FILTER TO TC PIPE)-SFC	TATA spare parts
253409145815	HOSE REDUCER ELBOW (FG)	TATA spare parts



253409145816	RUBBER HOSE (AIR INTK UNT TO AIR FLT)	TATA spare parts
253409145817	RUBBER HOSE (AIR FLTER TO PIPE)	TATA spare parts
253409145820	RUBBER HOSE(PIPE A/F TO TC)	TATA spare parts
253409145821	RUBBER HOSE (AIR FILTER TO PIPE)	TATA spare parts
253409145831	RUBBER HOSE (HFM SENSOR TO TC)	TATA spare parts
253409145832	RUBBER HOSE (AIR FILTER TO PIPE )	TATA spare parts
253409145834	RUBBER HOSE (AIR INT TO AIR FILTER)	TATA spare parts
253409145838	ELBOW HOSE	TATA spare parts
253409145853	RUBBER HOSE (AIR FILTER TO TC PIPE)-SFC	TATA spare parts
253409145854	HOSE (AIR FILTER TO ELBOW)	TATA spare parts
253409145858	HOSE(A/F TO AIR MASS SENSOR) BS4	TATA spare parts
253409145859	HOSE(AIR MASS SENSOR TO TC PIPE) BS4	TATA spare parts
253409145860	RUBBER HOSE (PIPE TO TC) BS4	TATA spare parts
253409145861	RUBBER HOSE (PIPE TO TC)¿	TATA spare parts
253409145863	RUBBER HOSE (PIPE TO AF) M/S FLTG	TATA spare parts
253409145874	RUBBER HOSE(PIPE A/F TO TC)	TATA spare parts
253409145875	RUBBER HOSE (HFM SENSOR TO TC)	TATA spare parts
253409145882	HOSE SIDE ENTRY PIPE TO AIR CLEANER BS4	TATA spare parts
253409145890	REDUCER HOSE (PIPE TO TC)	TATA spare parts
253409146908	ASSY. SUCTION PIPE	TATA spare parts
253409146912	PIPE AIR FILTER TO HOSE	TATA spare parts
253409146926	PIPE ASSY	TATA spare parts
253409146928	PIPE ASSY	TATA spare parts
253409146929	PIPE ASSY WITH BRACKET	TATA spare parts
253409146930	PIPE ASSY AIR INTAKE	TATA spare parts
253409146934	PIPE ASSY AIRINTAKE	TATA spare parts
253409150107	AIR INTAKE SYSTEM ASSY BS6-PH2	TATA spare parts
253409150108	AIR CLEANER ASSY BS6-PH2	TATA spare parts
253409150122	BRACKET AIR FILTER MTG	TATA spare parts
253409155806	HOSE REDUCER	TATA spare parts
253409155815	REDUCER HOSE	TATA spare parts
253409155816	HOSE AIR FILTER TO AIR MASS SENSOR	TATA spare parts
253409155819	HOSE AIR FILTER OUTLET	TATA spare parts
253409155820	HOSE TURBOCHARGER INTAKE	TATA spare parts
253409155821	HOSE BS6	TATA spare parts
253409155823	HOSE REDUCER	TATA spare parts
253409155825	HOSE ASSY	TATA spare parts
253409155828	AIR INTAKE PIPE	TATA spare parts
253409155829	HOSE ASSY	TATA spare parts
253409155830	REDUCER HOSE	TATA spare parts
253409155834	PIPE ASSY AIR FILTER TO TC BS6	TATA spare parts
253409155837	REDUCER HOSE PIPE TO TC BS6	TATA spare parts
253409155838	HOSE BS6	TATA spare parts
253409155844	RUBBER HOSE AIR FILTER TO TC BS6-PH2	TATA spare parts
253412000101	AFTER TREATMENT SYSTEM ASSY BS6	TATA spare parts
253412000102	EXHAUST GAS PROCESSOR ASSY BS6	TATA spare parts
253412000103	AFTER TREATMENT SYSTEM ASSY	TATA spare parts

253412000105	EXHAUST GAS PROCESSOR ASSY	TATA spare parts
253412149902	BRACKET BS6-PH2	TATA spare parts
253413100103	OIL LINE	TATA spare parts
253413100105	ASSY OIL LINE (VACUUM PUMP TO OIL SUMP)	TATA spare parts
253413100106	ASSY OIL LINE (VACUUM PUMP TO OIL SUMP)	TATA spare parts
253413103701	CYLINDER HEAD AIR SUCTION UNIT	TATA spare parts
253413103702	CYLINDER SLEEVE NORMAL	TATA spare parts
253413106802	REDUCER	TATA spare parts
253413106803	REDUCER	TATA spare parts
253413106803_niu1	REDUCER	TATA spare parts
253413120101	CYL HEAD AIR COMP	TATA spare parts
253413130107	AIR SUPPLY PIPE A/F TO AIR COMPRESSOR	TATA spare parts
253413130108	AIR SUPPLY PIPE A/F TO AIR COMPRESSOR	TATA spare parts
253413130111	AIR SUPPLY PIPE ASSY	TATA spare parts
253413130112	ASSY.PIPE (COMPRESSOR TO AIS)	TATA spare parts
253413130113	AIR SUPPLY PIPE ASSY	TATA spare parts
253413130114	AIR SUPPLY PIPE ASSY	TATA spare parts
253413130116	AIR SUPPLY PIPE ASSY BS6	TATA spare parts
253413130117	AIR SUPPLY PIPE ASSY BS6	TATA spare parts
253413130119	AIR SUPPLY PIPE ASSY BS6	TATA spare parts
253413130120	AIR SUPPLY PIPE ASSY BS6	TATA spare parts
253413130121	AIR SUPPLY PIPE ASSY BS6	TATA spare parts
253413130124	PIPE ASSEMBLY BS6	TATA spare parts
253413130129	AIR SUPPLY PIPE ASSY BS6-PH2	TATA spare parts
253413130131	AIR SUPPLY PIPE ASSY BS6-PH2	TATA spare parts
253413130132	AIR SUPPLY PIPE ASSY BS6-PH2	TATA spare parts
253413133301	BRACKET AIR COMPRESSOR PIPE MTG BS6	TATA spare parts
253413133302	BRACKET ASSY AIR COMPRESSOR PIPE SUPPORT	TATA spare parts
253413133303	BRACKET ASSY AIR COMPRESSOR PIPE SUPPORT	TATA spare parts
253413134201	BRACKET	TATA spare parts
253413135804	HOSE	TATA spare parts
253413135806	HOSE (ASSY.PIPE TO AIS)	TATA spare parts
253413135807	HOSE AIR FILTER TO AIR COMPRESSOR BS6	TATA spare parts
253413135808	HOSE AIR INTAKE TO AIR COMPRESSOR BS6	TATA spare parts
253413135809	HOSE AIR FILTER TO AIR COMPRESSOR BS6	TATA spare parts
253413135810	HOSE BS6	TATA spare parts
253413135812	HOSE BS6	TATA spare parts
253413135813	HOSE BS6	TATA spare parts
253413136909	PIPE ASSY AIR COMPRESSOR INTAKE BS6	TATA spare parts
253413136912	PIPE BS6	TATA spare parts
253413136916	PIPE (AIR INTAKE TO AIR COMPRESSOR) BS6	TATA spare parts
253413990101	SET A/C PISTON RINGS STD	TATA spare parts
253413990102	SET A/C PISTON RINGS STD1	TATA spare parts
253414100102	ASSY. CLAMP	TATA spare parts
253414100105	ASSY GRID HEATER 12V	TATA spare parts
253414100109	ADAPTER ASSY HEATER FLANGE	TATA spare parts
253414100110	ADAPTER ASSY HEATER FLANGE	TATA spare parts

253414100111	ELBOW ASSY INTAKE BS6	TATA spare parts
253414103805	ELBOW AIR INTAKE BS6	TATA spare parts
253414103806	ELBOW AIR INTAKEBS6	TATA spare parts
253414103807	HOUSING BS6	TATA spare parts
253414103809	ELBOW AIR INTAKE BS6	TATA spare parts
253414110104	ASSY.INTERMEDIATE PIPE [TC TO EXH.PIPE]	TATA spare parts
253414110109	ASSY.BRACKET SUPPORT FOR INT.PIPE 4SP	TATA spare parts
253414110111	ASSY. EGR TUBE	TATA spare parts
253414110112	ASSY. EGR VALVE-	TATA spare parts
253414110115	ASSY.EGR VALVE	TATA spare parts
253414110119	ASSY.HEAT SHIELD - EURO-III	TATA spare parts
253414110120	SUPPORT BRACKET FOR INTERMEDIATE PIPE	TATA spare parts
253414110121	ASSY.EGR VALVE	TATA spare parts
253414110122	ASSY.EGR VALVE	TATA spare parts
253414110123	VACCUUM MODULATOR	TATA spare parts
253414110124	KIT-DOSER PUMP SERVICE BS6	TATA spare parts
253414110128	EGR VALVE (PROGRESSIVE TYPE)	TATA spare parts
253414110131	ASSY.BRACKET(FOR VACUUM MODULATOR)	TATA spare parts
253414110133	ASSY BRACKET SOLENOID VALVE	TATA spare parts
253414110134	ASSY. HEAT SHIELD	TATA spare parts
253414110137	ASSY EGR TUBE (SENIOR)	TATA spare parts
253414110139	VACUUM MODULATOR W/O FILTER	TATA spare parts
253414110140	ASSY.EGR TUBE-4SPTC BSII	TATA spare parts
253414110142	ASSY EGR VALVE 4SPTC BSII SPACIO GOLD	TATA spare parts
253414110143	ASSY.HEATSHIELD(INTER ELBOW)4SPTC GOLD	TATA spare parts
253414110144	SUPPORT BRACKET(INT.PIPE)4SPTC BSII	TATA spare parts
253414110146	ASSY.EGR VALVE 4SPTC BSIII	TATA spare parts
253414110151	VACUUM MODULATOR WITH FILTER	TATA spare parts
253414110152	ASSY.EGR TUBE(EX M FOLD-EGR VALVE)BS IV	TATA spare parts
253414110153	ASSY.EGR TUBE(EGR COOLER-INT	TATA spare parts
253414110154	ASSY.EGR TUBE(INTAKE ELBOW)4SPTC CR BSIV	TATA spare parts
253414110155	ASSY.EGR COOLER 4SPTC CR BSIV	TATA spare parts
253414110157	ASSY. HEAT SHIELD (TURBO CHARGER)	TATA spare parts
253414110158	ASSY. BRACKET(VACCUUM MODULATOR)	TATA spare parts
253414110162	ASSY. EGR TUBE(EX.MANIFOLD-EGR VALVE)	TATA spare parts
253414110163	SUPPORT BRACKET (FOR INTERMEDIATE PIPE)	TATA spare parts
253414110165	ASSY. EGR VALVE	TATA spare parts
253414110166	ASSY. EGR TUBE (EX. MANIFOLD EGR VALVE)	TATA spare parts
253414110167	ASSY EGR VALVE 4SPTCIC BSIII SFC 407	TATA spare parts
253414110169	ASSY.HEAT-SHIELD(RIVETED)ON TURBOCHARGER	TATA spare parts
253414110170	SUPPORT BRACKET (FOR INTERMEDIATE PIPE)	TATA spare parts
253414110172	ASSY. HOSE(EGR TO VACCUUM MOD	TATA spare parts
253414110173	SUPPORT BRACKET(INT.PIPE)	TATA spare parts
253414110174	ASSY. HOSE(VACCUUM MOD TO AIR FILTER)	TATA spare parts
253414110177	ASSY. HOSE(VACUUM MOD TO AIR FILTER)	TATA spare parts
253414110180	ASSY.EGR COOLER(BEHR) 4SPCR BSIV	TATA spare parts
253414110181	ASSY PIPE (EXHAUST TO EGR VALVE)	TATA spare parts

253414110182	ASSY PIPE (EGR TO INTAKE ELBOW )	TATA spare parts
253414110183	ASSY. HOSE(VACUUM MOD TO AIR FILTER)	TATA spare parts
253414110184	ASSY. BRACKET(VACUUM MODULATOR)	TATA spare parts
253414110185	ASSY.BRACKET(FOR VACUUM MODULATOR)	TATA spare parts
253414110186	ASSY. AFTER TREATMENT SYSTEM BS3/4	TATA spare parts
253414110189	ASSY HOSE(EGR TO VACUUM MOD.)	TATA spare parts
253414110190	ASSY EGR TUBE (IAI JOINFLEX)	TATA spare parts
253414110191	ASSY EGR TUBE (INTAKE ELBOW)	TATA spare parts
253414110194	ASSY. EGR TUBE	TATA spare parts
253414110198	ASSY PIPE EGR COOLER IN (IAI JOINFLEX)	TATA spare parts
253414110199	ASSY PIPE EGR COOLER OUTLET	TATA spare parts
253414110201	ASSY. HOSE(VACCUM MOD TO AIR FILTER)	TATA spare parts
253414110216	ASSY HOSE(VAC. MODULATOR TO A/F)	TATA spare parts
253414110219	VACUUM RESERVOIR	TATA spare parts
253414110221	EGR VALVE ASSY	TATA spare parts
253414110225	HEAT SHIELD TURBOCHARGER	TATA spare parts
253414110248	EGR COOLER ASSY	TATA spare parts
253414110252	BRACKET ASSY RESERVOIR MTG	TATA spare parts
253414110256	CATALYTIC CONVERTOR ASSY	TATA spare parts
253414110258	CLOSE COUPLED CATCON ASSY	TATA spare parts
253414110259	HOSE (VACUUM MODULATOR TO A/F)	TATA spare parts
253414110260	HOSE (VACUUM MODULATOR TO VACUUM PUM)	TATA spare parts
253414110261	ASSY EGR PIPE ( BS III)	TATA spare parts
253414110262	PIPE ASSY EGR	TATA spare parts
253414110263	ASSY EGR PIPE	TATA spare parts
253414110268	PIPE ASSY EGR TO INTAKE ELBOW	TATA spare parts
253414110270	BRACKET ASSY EVRV TUBE MTG	TATA spare parts
253414110286	PIPE ASSY EGR COOLER TO AIR INTAKE ELBOW	TATA spare parts
253414110287	AFTER TREATMENT SYSTEM ASSY	TATA spare parts
253414110290	CLOSE COUPLED CATCON ASSY	TATA spare parts
253414110295	EGR PIPE ASSY COOLER TO AIR INTAKE ELBOW	TATA spare parts
253414110305	PIPE ASSY EGR COOLER TO AIR INTAKE ELBOW	TATA spare parts
253414110307	EGR MODULE ASSY BS6	TATA spare parts
253414110309	AFTER TREATMENT SYSTEM ASSY (25341411032	TATA spare parts
253414110315	UREA INJECTOR BS6	TATA spare parts
253414110317	AIR INTAKE PIPE TURBOCHARGER BS6	TATA spare parts
253414110320	AIR INTAKE PIPE ASSY BS6	TATA spare parts
253414110324	EGR PIPE ASSY EXH MANIFOLD TO EGR PIPE B	TATA spare parts
253414110325	EGR PIPE EGR COOLER TO INT.ELBOW BS6-PH2	TATA spare parts
253414110327	EGR TUBE ASSY BS6	TATA spare parts
253414110330	EXHAUST GAS PROCESSOR ASSY BS6	TATA spare parts
253414110331	EGR COOLER ASSY BS6	TATA spare parts
253414110334	DPF ASSY BS6	TATA spare parts
253414110335	SUPPORT BRACKET ASSY BS6	TATA spare parts
253414110336	VACUUM RESERVOIR	TATA spare parts
253414110337	SCR CATALYST ASSY BS6	TATA spare parts
253414110338	SCR W/MIXER ASSY - SFC/SK/LP 4SPCR BS6	TATA spare parts

253414110339	DPF ASSY - SFC/SK/LP 4SPCR BS6	TATA spare parts
253414110341	HEAT SHIELD (FOR TC AND TC ADAPTOR) BS6	TATA spare parts
253414110344	AIR INTAKE PIPE TURBOCHARGER BS6	TATA spare parts
253414110345	EGR PIPE ASSY EGR COOLER TO INTAKE ELBOW	TATA spare parts
253414110348	SUPPORT BRACKET BS6	TATA spare parts
253414110351	PIPE ASSY BS6	TATA spare parts
253414110352	PIPE ASSY BS6	TATA spare parts
253414110353	EGR TUBE ASSY BS6	TATA spare parts
253414110355	THROTTLE VALVE ASSY BS6	TATA spare parts
253414110365	THROTTLE VALVE ASSY BS6-PH2	TATA spare parts
253414110379	DEF FILTER BS6	TATA spare parts
253414110389	DEF FILTER CARTRIDGE BS6	TATA spare parts
253414111601	VACUUM MODULATOR WITH FILTER	TATA spare parts
253414111601_niu3	VACUUM MODULATOR WITH FILTER	TATA spare parts
253414113301	SUPPORT BRACKET (EXHAUST ELBOW)	TATA spare parts
253414113306	SUPPORT (HFAM SENSOR)	TATA spare parts
253414113313	BRACKET (VACCUME MODULATOR)	TATA spare parts
253414113320	BRACKET-1 (VACUUM RESERVOIR)	TATA spare parts
253414113321	BRACKET-2 (VACUUM RESERVOIR)	TATA spare parts
253414113323	BRACKET ASSY INTERMEDIATE PIPE SUPPORT	TATA spare parts
253414113330	BRACKET CATALYTIC CONVERTER MTG	TATA spare parts
253414113331	BRACKET	TATA spare parts
253414113332	SUPPORT BRACKET INTERMEDIATE PIPE	TATA spare parts
253414113334	BRACKET	TATA spare parts
253414113341	SUPPORT BRACKET PIPE BS6	TATA spare parts
253414113701	EXHAUST MANIFOLD	TATA spare parts
253414113702	EXHAUST MANIFOLD (DICR)	TATA spare parts
253414113703	INTERMEDIATE PIPE (DICR)	TATA spare parts
253414113708	EXHAUST MANIFOLD 4SP	TATA spare parts
253414113709	INTERMEDIATE PIPE TC TO EXH PIPE	TATA spare parts
253414113710	EXHAUST MANIFOLD - CNG	TATA spare parts
253414113712	INTERMEDIATE PIPE(TC TO EXH.PIPE)-CAST	TATA spare parts
253414113713	EXHAUST MANIFOLD	TATA spare parts
253414113714	EXHAUST MANIFOLD 4SP TC BS:III	TATA spare parts
253414113715	INTERMEDIATE PIPE TC TO EXHAUST PIPE	TATA spare parts
253414113716	EXHAUST MANIFOLD.	TATA spare parts
253414113717	EXHAUST MANIFOLD (BS-III)	TATA spare parts
253414113720	INTERMEDIATE ELBOW TC TO EX.4SPTC BSII	TATA spare parts
253414113727	EXHAUST MANIFOLD 4SPTC CR BSIV	TATA spare parts
253414113731	INTERMEDIATE PIPE	TATA spare parts
253414113733	EXHAUST MANIFOLD	TATA spare parts
253414113734	CAST BKT (EGR COOLER & COMMONRAIL MTG)	TATA spare parts
253414113735	EXHAUST MANIFOLD (BSIV)	TATA spare parts
253414113755	EXHAUST MANIFOLD BS6	TATA spare parts
253414113757	EGR CAST PIPE EGR PIPE TO EGR VALVE BS6	TATA spare parts
253414113760	BRACKET CAST EGR COOLER BS6	TATA spare parts
253414113762	ADAPTER INTERMEDIATE BS6	TATA spare parts

253414113763	ELBOW EXHAUST BS6	TATA spare parts
253414113765	ELBOW EXHAUST	TATA spare parts
253414113766	ELBOW EXHAUST BS6	TATA spare parts
253414113768	ADAPTER INTERMEDIATE BS6	TATA spare parts
253414113783	ADAPTER INTERMEDIATE BS6-PH2	TATA spare parts
253414113784	ELBOW EXHAUST BS6-PH2	TATA spare parts
253414113788	ELBOW EXHAUST BS6-PH2	TATA spare parts
253414113791	ELBOW EXHAUST BS6-PH2	TATA spare parts
253414113792	ADAPTER INTERMEDIATE BS6-PH2	TATA spare parts
253414114201	CLAMP (EGR TUBE) ON EGR FLANGE.	TATA spare parts
253414114204	CLAMP ASSY PIPE BS6	TATA spare parts
253414115304	GASKET	TATA spare parts
253414115305	GASKET-EXH.MANIFOLD TO TURBOCHARGER	TATA spare parts
253414115306	GASKET-TC TO INT PIPE	TATA spare parts
253414115307	GASKET-EGR VALVE BS4	TATA spare parts
253414115308	GASKET TC TO INT.PIPE BS-III	TATA spare parts
253414115309	GASKET TURBO CHARGER TO EXH MANIFOLD	TATA spare parts
253414115312	GASKET-TC TO INTERMEDIATE ELBOW 4SPTCBS2	TATA spare parts
253414115321	GASKET	TATA spare parts
253414115328	GASKET TC TO INTERMEDIATE ADAPTER	TATA spare parts
253414115333	GASKET BS6	TATA spare parts
253414115334	GASKET BS6	TATA spare parts
253414115801	HOSE (285) AIR COMP. TO SOLENOID VALVE	TATA spare parts
253414115802	HOSE (915) SOLENOID VALVE TO EGR VALVE	TATA spare parts
253414115803	HOSE(AIR COMPRESSOR TO VACUUM MODULATOR)	TATA spare parts
253414115804	HOSE(VACUUM MODULATOR TO EGR VALVE)	TATA spare parts
253414115805	HOSE-VAC.PUMP TO VAC.SOLENOID VALVE	TATA spare parts
253414115806	HOSE-VAC SOLENOID VALVE TO EGR	TATA spare parts
253414115807	HOSE (410 L) SOLENOID TO EGR	TATA spare parts
253414115818	HOSE (VACUUM MODULATOR TO ALTERNATOR)	TATA spare parts
253414115819	HOSE (VACUUM MODULATOR TO ALTERNATOR )	TATA spare parts
253414115820	HOSE (EGR TO VACUUM MODULATOR)	TATA spare parts
253414115822	HOSE (AIR FILTER TO STEEL TUBE) BS4	TATA spare parts
253414115823	HOSE (STEEL TUBE TO ALTERNATOR) BS4	TATA spare parts
253414115824	VACUUME HOSE (STEEL TUBE TO EVRV) BS4	TATA spare parts
253414115825	VACUUME HOSE (EVRV TO T-CONNECTOR) BS4	TATA spare parts
253414115826	VACUUME HOSE (T-CONNECTOR TO NRV) BS4	TATA spare parts
253414115827	VACUUME HOSE (NRV TO STEEL TUBE) BS4	TATA spare parts
253414115828	VACUUME HOSE (EVRV TO EGR VALVE) BS4	TATA spare parts
253414115829	VAC. HOSE T-CONNECTOR TO STEEL TUBE BS4	TATA spare parts
253414115830	VAC HOSE (STEEL TUBE TO RESERVIOR) BS4	TATA spare parts
253414115831	RUBBER HOSE (L=535) (MODULATOR TO ALT	TATA spare parts
253414115847	HOSE VACUUM MODULATOR TO EGR VALVE	TATA spare parts
253414115848	HOSE VACUUM MODULATOR TO ALTERNATOR	TATA spare parts
253414115866	HOSE (TC TO INTAKE ELBOW)	TATA spare parts
253414115868	HOSE (EVRV TO EGR VALVE)	TATA spare parts
253414115870	HOSE	TATA spare parts

253414115871	HOSE	TATA spare parts
253414115872	HOSE VACUUM MODULATOR TO ALTERNATOR	TATA spare parts
253414115882	EVRV HOSE AIR FILTER END	TATA spare parts
253414115883	AIR INTAKE HOSE EVRV	TATA spare parts
253414115884	AIR INTAKE HOSE EVRV	TATA spare parts
253414115885	HOSE EVRV TO T-CONNECTOR	TATA spare parts
253414115886	HOSE TUBE TO VACUUM RESERVOIR	TATA spare parts
253414115896	RUBBER HOSE BS6	TATA spare parts
253414116906	TUBE (VACUUM PUMP TO EGR VALVE)	TATA spare parts
253414116907	RUBBER TUBE(320L MODULATOR TO EGR)	TATA spare parts
253414116908	RUBBER TUBE (MODULATOR TO AF)	TATA spare parts
253414116911	VACUUME LINE TUBE(AIR FILTER TO EVRV)	TATA spare parts
253414116912	VACUUME LINE TUBE(EVRV TO ALTERNATOR)	TATA spare parts
253414116913	VACUUME LINE TUBE(T-CONN TO RESERVIOR)	TATA spare parts
253414116914	VACUUM LINE (AF TO EVRV)	TATA spare parts
253414116917	PIPE	TATA spare parts
253414116918	TUBE VACUUM LINE AIR FILTER TO EVRV	TATA spare parts
253414116919	PIPE VACUUM MODULATOR TO ALT	TATA spare parts
253414118202	SUPPORT BRACKET	TATA spare parts
253414118204	SUPPORT BRACKET INT.PIPE-CAST	TATA spare parts
253414118217	HEAT SHIELD ASSY EXHAUST ELBOW BS6	TATA spare parts
253414118218	HEAT SHIELD ASSY EXHAUST MANIFOLD BS6	TATA spare parts
253414118219	HEAT SHIELD ASSY TURBOCHARGER BS6	TATA spare parts
253414118220	HEAT SHIELD ASSY EXHAUST ELBOW BS6	TATA spare parts
253414118221	HEAT SHIELD ASSY EXHAUST ELBOW BS6	TATA spare parts
253414118222	HEAT SHIELD ASSY EXHAUST ELBOW BS6	TATA spare parts
253414118230	HEAT SHIELD ASSY TURBOCHARGER	TATA spare parts
253414118231	HEAT SHIELD ASSY EXHAUST MANIFOLD	TATA spare parts
253414118236	HEAT SHIELD ASSY EXHAUST ELBOW BS6	TATA spare parts
253414118237	HEAT SHIELD ASSY WITH CLAMP	TATA spare parts
253414118238	HEAT SHIELD ASSY EXHAUST ELBOW	TATA spare parts
253414118243	HEAT SHIELD ASSY EXHAUST ELBOW BS6	TATA spare parts
253414118244	HEAT SHIELD ASSY WITH CLAMP	TATA spare parts
253414118245	HEAT SHIELD ASSY EXHAUST ELBOW BS6-PH2	TATA spare parts
253414118601	BOSS (ON EXHAUST MANIFOLD)	TATA spare parts
253414119903	FILTER WITH CAP	TATA spare parts
253414119904	FILTER BODY	TATA spare parts
253414119928	BRACKET ASSY WITH SENSOR TABLE DP MTG BS	TATA spare parts
253414130108	ASSY.HEAT SHIELD. FOR STARTER MOTOR	TATA spare parts
253414130110	ASSY.HEAT SHIELD(SHEET METAL)	TATA spare parts
253414130113	ASSY.HEAT SHIELD (SUPER CEMJO)-THL	TATA spare parts
253414130132	ASSY.BRACKET(AC MTG BKT TO EX M'FOLD)	TATA spare parts
253414138201	HEAT SHIELD (EXHAUST MANIFOLD)-CNG	TATA spare parts
253414138202	HEAT SHIELD FOR EXHAUST MANIFOLD	TATA spare parts
253414138204	HEAT SHIELD	TATA spare parts
253414510102	TURBO CHARGER	TATA spare parts
253414510104	TURBO CHARGER	TATA spare parts

253414510105	ASSY TURBOCHARGER W/WASTE GATE CMVR2K	TATA spare parts
253414510107	ASSY.TURBOCHARGER-EURO II	TATA spare parts
253414510108	ASSY.TURBOCHARGER EURO-III	TATA spare parts
253414510110	ASSY TURBOCHARGER TEL LP-407 BS-III	TATA spare parts
253414510112	ASSY TURBOCHARGER (TEL 03)EURO-III DICR	TATA spare parts
253414510116	ASSY.TC BS-II SFC/LP/LPT	TATA spare parts
253414510117	ASSY.TURBOCHARGER 4SP BS-II	TATA spare parts
253414510120	TURBOCHARGER 4SPTC BSII	TATA spare parts
253414510121	ASSY TURBOCHARGER	TATA spare parts
253414510148	ASSY TURBOCHARGER 4SP BS III	TATA spare parts
253414510149	ASSY TURBOCHARGER	TATA spare parts
253414510150	ASSY. TURBOCHARGER 4SPTC BS4	TATA spare parts
253414510151	ASSY. TURBOCHARGER VICTA DI	TATA spare parts
253414510153	TC ASSY W/BOOST PRESS. ACTUATOR BS6-PH2	TATA spare parts
253414510156	ASSY. TURBOCHARGER	TATA spare parts
253414510160	ASSY. TURBOCHARGER 4SPCR BS2/3/4	TATA spare parts
253414510163	TURBOCHARGER ASSY	TATA spare parts
253414510164	TURBOCHARGER ASSY	TATA spare parts
253414510176	TURBOCHARGER	TATA spare parts
253414510184	TURBOCHARGER ASSY BS6	TATA spare parts
253414510186	TC ASSY WITH BOOST PRESSURE ACTUATOR BS6	TATA spare parts
253414510197	TC ASSY W/BOOST PRESS. ACTUATOR BS6-PH2	TATA spare parts
253414600104	ASSY.PIPE INT.COOLER TO ELBOW	TATA spare parts
253414600108	ASSY.PIPE TC OUT TO IC SFC-407 BS-III	TATA spare parts
253414600109	ASSY.PIPE (TC TO INT)LP/LPT 407 BS-III	TATA spare parts
253414600110	ASSY.PIPE (FROM ELBOW TO INTERCOOLER)LP	TATA spare parts
253414600112	ASSY.SUPPORT (ON BRIDGE)IC TO ELBOW	TATA spare parts
253414600120	PIPE ASSY IC TO AIR INTAKE ELBOW	TATA spare parts
253414600129	ASSY. INTERCOOLER BS3/4/6	TATA spare parts
253414600130	ASSY.INTERCOOLER (VAVE)	TATA spare parts
253414600133	ASSY.PIPE (TC OUT TO IC)SFC-407 BS-III	TATA spare parts
253414600144	PIPE ASSY IC TO ELBOW AIR INTAKE	TATA spare parts
253414600148	ASSY.INTERCOOLER (INNER FIN AND PLASTIC	TATA spare parts
253414600150	ASSY PIPE (IC TO AIR INTAKE ELBOW)	TATA spare parts
253414600152	ASSY.BRACKET(INTERCOOLER MTG.LH LOWER)	TATA spare parts
253414600154	ASSY PIPE(TC TO IC)	TATA spare parts
253414600161	PIPE ASSY IC TO ELBOW AIR INTAKE	TATA spare parts
253414600165	PIPE ASSY TURBOCHARGER TO INTERCOOLER	TATA spare parts
253414600183	PIPE ASSY TC TO INTERCOOLER	TATA spare parts
253414600185	PIPE ASSY	TATA spare parts
253414600189	INTERCOOLER ASSY	TATA spare parts
253414600210	INTERCOOLER ASSY	TATA spare parts
253414600214	PIPE TC TO INTERCOOLER BS6	TATA spare parts
253414600215	PIPE ASSY TC OUT TO INTERCOOLER BS6	TATA spare parts
253414600216	PIPE ASSY INTERCOOLER TO AIR INTAKE BS6	TATA spare parts
253414600217	INTERCOOLER ASSY	TATA spare parts
253414600222	PIPE ASSY TC TO INTERCOOLER BS6	TATA spare parts



253414600223	PIPE ASSY WITH CLAMP IC TO INT ELBOW BS6	TATA spare parts
253414600225	PIPE ASSY WITH BRACKET TC TO INTERCOOLER	TATA spare parts
253414600228	PIPE ASSY IC TO AIR INTAKE ELBOW	TATA spare parts
253414600233	PIPE ASSY WITH BRKT TC TO INTERCOOLER BS	TATA spare parts
253414600235	PIPE ASSY IC TO AIR INTAKE ELBOW BS6-PH2	TATA spare parts
253414600242	BRACKET ASSY IC PIPE MTG	TATA spare parts
253414603302	SUPPORT (FOR PIPE FROM ELBOW TO INT)LP	TATA spare parts
253414603305	SUPPORT FOR PIPE FROM TC TO IC SFC-407	TATA spare parts
253414603334	SUPPORT BRACKET	TATA spare parts
253414603335	SUPPORT BRACKET ASSY BS6-PH2	TATA spare parts
253414603817	PIPE (IC TO GRID HEATER )	TATA spare parts
253414603819	PIPE CAST TURBOCHARGER TO INTERCOOLER	TATA spare parts
253414603820	PIPE INTERCOOLER TO AIR INATKE PIPE	TATA spare parts
253414603821	PIPE CAST INTERCOOLER TO ENGINE	TATA spare parts
253414603823	PIPE BS6	TATA spare parts
253414603825	AIR INTAKE PIPE TURBOCHARGER BS6	TATA spare parts
253414603829	PIPE BS6-PH2	TATA spare parts
253414604212	CLAMP (INTERCOOLER PIPE)	TATA spare parts
253414605801	HUMP HOSE PIPE TO AIR INTAKE ELBOW BS4	TATA spare parts
253414605802	REDUCER HOSE TC OUT TO IC PIPE	TATA spare parts
253414605805	HOSE (IC TO TOP PIPE)	TATA spare parts
253414605809	RUBBER HOSE (TC OUT TO IC PIPE)LP-407	TATA spare parts
253414605810	HOSE (TOP PIPE TO INTAKE ELBOW)	TATA spare parts
253414605811	HOSE (PIPE TO INTERCOOLER)	TATA spare parts
253414605818	HOSE (TC TO IC PIPE)	TATA spare parts
253414605819	HOSE(TC OUT TO IC PIPE) SFC407 LHD	TATA spare parts
253414605832	HOSE (PIPE TO INTERCOOLER)	TATA spare parts
253414605833	HOSE (INTERCOOLER TO PIPE)	TATA spare parts
253414605834	HOSE (TC TO PIPE)	TATA spare parts
253414605835	HOSE INTAKE ELBOW TO PIPE	TATA spare parts
253414605838	HOSE (INTERCOOLER TO PIPE)	TATA spare parts
253414605866	REDUCER HOSE (TC TO IC PIPE)	TATA spare parts
253414605867	REDUCER HOSE AIR CLEANER SYSTEM TO TC	TATA spare parts
253414605869	HOSE (PIPE TO INTERCOOLER)	TATA spare parts
253414605875	RUBBER HOSE(TC TO IC PIPE) BS4	TATA spare parts
253414605876	RUBBER HOSE (IC TO AIR INTAKE ELBOW)	TATA spare parts
253414605880	RUBBER HOSE(IC TO PIPE AIR-INTAKE ELBOW)	TATA spare parts
253414605881	RUBBER HOSE (PIPE IC TO ELBOW AIR IN.)	TATA spare parts
253414605882	REDUCER HOSE (TC TO IC PIPE)	TATA spare parts
253414605883	RUBBER HOSE (TC TO PIPE IC)	TATA spare parts
253414605884	RUBBER HOSE (TC PIPE TO IC)	TATA spare parts
253414605885	HOSE (INTERCOOLER TO PIPE)	TATA spare parts
253414605888	RUBBER HOSE (IC TO TC PIPE)	TATA spare parts
253414605889	RUBBER HOSE (AIR INTAKE ELBOW TO PIPE)	TATA spare parts
253414605891	RUBBER HOSE (PIPE TO AIR INTAKE ELBOW)	TATA spare parts
253414605897	RUBBER HOSE (IC TO PIPE) BS6	TATA spare parts
253414605898	RUBBER HOSE (IC PIPE TO ELBOW)	TATA spare parts

253414605901	REDUCER HOSE BS6	TATA spare parts
253414605902	HOSE ASSY TURBOCHARGER TO INTERCOOLER BS	TATA spare parts
253414605903	RUBBER HOSE BS6	TATA spare parts
253414605904	HOSE ASSY IC TO AIR INTAKE ELBOW BS6	TATA spare parts
253414605905	HOSE INTERCOOLER TO INTAKE PIPE BS6	TATA spare parts
253414605906	HOSE ASSY TURBOCHARGER TO INTERCOOLER BS	TATA spare parts
253414605907	HOSE BS6	TATA spare parts
253414605913	HOSE INTERCOOLER TO AIR INTAKE ELBOW	TATA spare parts
253414605918	HOSE HUMP BS6-PH2	TATA spare parts
253414606910	PIPE (TC TO IC)	TATA spare parts
253414606912	PIPE (IC TO ELBOW)	TATA spare parts
253414606928	PIPE TURBOCHARGER TO INTERCOOLER	TATA spare parts
253414606929	PIPE INTERCOOLER TO INTAKE ELBOW	TATA spare parts
253414606930	PIPE(INTERCOOLER TO INTAKE ELBOW)	TATA spare parts
253414606931	PIPE (TURBOCHARGER TO INTERCOOLER)	TATA spare parts
253414606947	PIPE INTERCOOLER TO INTAKE ELBOW	TATA spare parts
253414606948	PIPE (TURBOCHARGER TO INTERCOOLER)	TATA spare parts
253414606953	PIPE (IC TO AIR INTAKE ELBOW)	TATA spare parts
253414606954	PIPE (TURBOCHARGER TO IC)	TATA spare parts
253414606957	PIPE	TATA spare parts
253414606960	PIPE TURBOCHARGER INTAKE	TATA spare parts
253414606964	PIPE ASSY BS6	TATA spare parts
253414606967	PIPE ASSY	TATA spare parts
253414606970	PIPE ASSY BS6-PH2	TATA spare parts
253414606972	PIPE ASSY TURBO TO INTERCOOLER BS6-PH2	TATA spare parts
253414609903	INTERCOOLER(SFC 407-BS-III) BS3	TATA spare parts
253414609904	INTERCOOLER ASSY LP-407 BS-III	TATA spare parts
253414609905	INTERCOOLER	TATA spare parts
253414609906	INTERCOOLER	TATA spare parts
253414609912	INTERCOOLER	TATA spare parts
253414609915	INTERCOOLER 207 DI BSIV	TATA spare parts
253414609916	INTERCOOLER (4SP CR BSIV)VICTA DI	TATA spare parts
253414609919	PIPE (IC TO CYL.HEAD COVER)	TATA spare parts
253414609920	INTERCOOLER XENON RX 4SPTC BSIV	TATA spare parts
253414615805	HOSE (PIPE TO AIR INTAKE ELBOW)	TATA spare parts
253414615806	HOSE IC OUTLET TO PIPE	TATA spare parts
253414615812	HOSE HUMP BS6-PH2	TATA spare parts
253414615814	HOSE (TC TO PIPE)	TATA spare parts
253414615815	HOSE	TATA spare parts
253414615819	HUMP HOSE PIPE TO AIR INTAKE ELBOW	TATA spare parts
253414615823	HUMP HOSE PIPE TO AIR INTAKE ELBOW BS6-P	TATA spare parts
253414615824	RUBBER HOSE AIR INTAKE ELBOW TO PIPE	TATA spare parts
253414615829	HOSE TURBOCHARGER TO INTERCOOLER	TATA spare parts
253414615830	HUMP HOSE IC TO IC PIPE	TATA spare parts
253414615831	HOSE IC PIPE TO AIR INTAKE ELBOW	TATA spare parts
253414615835	REDUCER HOSE BS6	TATA spare parts
253414615837	HOSE INTERCOOLER TO INTAKE PIPE BS6	TATA spare parts

253414615839	RUBBER HOSE¿BS6	TATA spare parts
253414615844	HOSE TURBOCHARGER TO INTERCOOLER BS6	TATA spare parts
253414615848	REDUCER HOSE BS6	TATA spare parts
253414615849	HOSE	TATA spare parts
253414615854	HOSE INTERCOOLER TO INTAKE PIPE BS6	TATA spare parts
253414615855	HOSE TURBOCHARGER TO PIPE BS6	TATA spare parts
253414615857	HOSE IC PIPE TO AIR INTAKE ELBOW BS6-PH2	TATA spare parts
253414615858	HOSE ASSY IC PIPE TO INTAKE ELBOW BS6-PH	TATA spare parts
253414990102	REPAIR KIT	TATA spare parts
253415140102	ASSY. BRACKET( AC & 135A ALT.MOUNTING)	TATA spare parts
253415140104	BRACKET ALTERNATOR MTG	TATA spare parts
253415140107	ASSY BRACKET	TATA spare parts
253415140127	ASSY.CLAMPING ROD 175LG(6G.ALT.NO FIT.VE	TATA spare parts
253415140130	ASSY.TENSIONING ROD COMPLETE	TATA spare parts
253415140131	ASSY. BRACKET(ALTERNATOR MOUNTING)	TATA spare parts
253415140133	ASSY.TENSIONING ROD COMPLETE.	TATA spare parts
253415140143	ASSY. BRACKET-ALTERNATOR MTG.	TATA spare parts
253415140146	ASSY.BRACKET (10S13 AC & 125 ALT)	TATA spare parts
253415140148	ASSY BRACKET TELCOLINE	TATA spare parts
253415140152	ASSEMBLY BRACKET (ALTERNATOR MOUNTING)	TATA spare parts
253415140157	ASSY.BRACKET (ALT. MOUNTING)	TATA spare parts
253415140164	ASSEMBLY CLAMP ROD COMPLETE	TATA spare parts
253415140190	ASSY.BRACKET (AC COMP.&¿ ALT)	TATA spare parts
253415143309	SUPPORT (ALTERNATOR BRACKET)	TATA spare parts
253415143401	BUSH(ALTERNATOR MOUNTING BRACKET)	TATA spare parts
253415143402	BUSH(ALTERNATOR MOUNTING BRACKET)	TATA spare parts
253415143403	BUSH BS6	TATA spare parts
253415143701	ALTERNATOR BRACKET-CAST SFC407	TATA spare parts
253415143703	BRACKET ALTERNATOR MTG	TATA spare parts
253415143704	BRACKET, ALTERNATOR MTG	TATA spare parts
253415143705	BRACKET ALTERNATOR MTG BS6	TATA spare parts
253415144201	CLAMPING PIECE	TATA spare parts
253415146304	BELT BS6-PH2	TATA spare parts
253415148604	SPACER	TATA spare parts
253415150101	ASSY. FAN WITH MOTOR (300 DIA) 4SPDICR	TATA spare parts
253415150102	ASSY. FAN WITH MOTOR (268 DIA)SUMO DICOR	TATA spare parts
253415189903	GLOW PLUG BS6	TATA spare parts
253415210105	ECU HARDWARE & SOFTWARE (SAFARI BS-III)	TATA spare parts
253415210105_niu3	ECU HARDWARE & SOFTWARE (SAFARI BS-III)	TATA spare parts
253415210107	ECU HARDWARE & SOFTWARE (XENON E-III)	TATA spare parts
253415210108	ECU HARDWARE & SOFTWARE (XENON BS-III)	TATA spare parts
253415210109	ECU HARDWARE & SOFTWARE (XENON E-II)	TATA spare parts
253415210113	ECU DCM 2.5(HW+SW)4SPCRBS4 207DI OBD-I	TATA spare parts
253415210116	ECU DCM2.5(HW+SW)4SPCR BSIV-VICTA DI	TATA spare parts
253415210123	ASSY.ECU DCM 2.5(HW+SW) 207DI OBDII	TATA spare parts
253415219902	ECU LOADED W/CALB+F.LOGIC SAFARI BS-III	TATA spare parts
253415400141	TENSIONING ROD COMPLETE	TATA spare parts

253415400143	ASSY.T NING ROD COMP.WITH CLAMPING PIECE	TATA spare parts
253415400144	ASSY TENSIONING ROD COMPLETE	TATA spare parts
253415400146	ASSY.TENSIONING ROD COMPLETE	TATA spare parts
253415400151	NOX SENSOR BS6	TATA spare parts
253415400152	TENSION ROD ASSY WITH CLAMPING PIECE	TATA spare parts
253415400153	SET-UREA LVL ASSY & QLY SENSOR & CABLE A	TATA spare parts
253415400155	TENSIONER ROD ASSY BS6	TATA spare parts
253415400156	UREA QUALITY SENSOR BS6	TATA spare parts
253415400157	UREA LEVEL SENSOR BS6	TATA spare parts
253415400158	CABLE ASSY BS6	TATA spare parts
253415406302	POLY V BELT(6PK)1173 LG	TATA spare parts
253415406303	POLY V BELT(6PK)1273	TATA spare parts
253416101212	CONTAINER ASSY	TATA spare parts
253418100103	OIL PUMP COMPLT	TATA spare parts
253418100117	COVER OIL PUMP	TATA spare parts
253418100121	OIL PUMP ASSY	TATA spare parts
253418100122	ASSY OIL PUMP COMPLETE	TATA spare parts
253418100123	ASSY OIL PUMP 4SP	TATA spare parts
253418100130	OIL PUMP ASSY W/O STRAINER BS6	TATA spare parts
253418100132	OIL PUMP ASSY BS6-PH2	TATA spare parts
253418103701	COVER OIL PUMP	TATA spare parts
253418105402	DRIVE GEAR OIL PUMP	TATA spare parts
253418107901	DRIVE SHAFT OIP PUMP	TATA spare parts
253418130102	HEAD OIL FILTER	TATA spare parts
253418130107	OIL LINE OILFILTER TO FIP	TATA spare parts
253418130116	OIL FILTER ASSY	TATA spare parts
253418130117	HOUSING OIL FILTER	TATA spare parts
253418130118	HEAD OIL FILTER	TATA spare parts
253418130120	OIL LINE OILFILTER TO FIP	TATA spare parts
253418130122	ASSY.OIL LINE	TATA spare parts
253418130128	OIL LINE - FILTER TO FIP	TATA spare parts
253418130129	OIL FILTER CARTRIDGE 207DI BS1/2/3	TATA spare parts
253418130130	ASSY.OIL FILTER HOUSING	TATA spare parts
253418130131	OIL FILTER HEAD	TATA spare parts
253418130132	OIL FILTER	TATA spare parts
253418130134	OIL FILTER ASSY MODIFIED	TATA spare parts
253418130135	OIL FILTER 4SP / 709 ALL	TATA spare parts
253418130138	ASSY.OIL FIL.CARTRIDGE	TATA spare parts
253418130141	ASSY.OIL FIL.CARTRIDGE	TATA spare parts
253418130142	ASSY OIL FILTER COMPLETE-EURO II	TATA spare parts
253418130144	ASSY OIL FILTER HEAD	TATA spare parts
253418130146	OIL FILTER ELEMENT ASSY BS6	TATA spare parts
253418130164	ASSY OIL FILTER COMPLETE	TATA spare parts
253418130165	ASSY OIL FILTER	TATA spare parts
253418130166	LUBE OIL FILTER ASSY:SPINON:4SP BS3	TATA spare parts
253418130168	FILTER HEAD (25INCH ANGULAR POSITION)	TATA spare parts
253418130169	ASSY.OIL FILTER (SPIN ON)	TATA spare parts

253418130172	ASSY.OIL FILTER COMP.4SP BS-III	TATA spare parts
253418130173	FILTER HEAD ASSY:4SP-BSIII:SPINON	TATA spare parts
253418130174	ASSY OIL FILTER COMPLETE 207DI BSIII	TATA spare parts
253418130181	LUBE OIL FILTER ASSY 207DI-LHBSI	TATA spare parts
253418130182	HEAD ASSY 207DI-LH CMVR2000 E'PT	TATA spare parts
253418130187	ASSY OIL FILTER	TATA spare parts
253418130190	ASSY.OIL FILTER HEAD	TATA spare parts
253418130208	ASSY OIL FILTER COMPLETE	TATA spare parts
253418130209	HEAD LUB OIL FILTER	TATA spare parts
253418130224	OIL FILTER HEAD ASSY	TATA spare parts
253418130235	OIL FILTER HEAD ASSY¿BS6	TATA spare parts
253418133202	CENTRE PIN	TATA spare parts
253418133814	OIL FILTER HEAD	TATA spare parts
253418135301	GASKET OIL FILTER TO CYL BLOCK :BS-III	TATA spare parts
253418136301	ADAPTOR	TATA spare parts
253418137201	SCREW PLUG	TATA spare parts
253418137703	O RING MODIFIED	TATA spare parts
253418137704	SEAL	TATA spare parts
253418139906	ADAPTOR (TRANSDUCER)	TATA spare parts
253418139911	ADAPTOR OIL FILTER HEAD	TATA spare parts
253418150102	STRAINER OIL PUMP	TATA spare parts
253418150103	ASSY OIL PUMP STRAINERR	TATA spare parts
253418150107	STRAINER ASSY BS6-PH2	TATA spare parts
253418150109	STRAINER ASSY BS6-PH2	TATA spare parts
253418170107	OIL COOLER ASSY	TATA spare parts
253418170117	HEAT EXCHANGER PLATE TYPE	TATA spare parts
253418170119	ASSY.OIL COOLER	TATA spare parts
253418170122	ASSY.PLATE TYPE HEAT EXCH	TATA spare parts
253418170125	ASSY OIL COOLER W/GASKET	TATA spare parts
253418170126	ASSY OIL LINE	TATA spare parts
253418170127	ASSY.OIL LINE (OIL COOLER TO TC) 4SP	TATA spare parts
253418170128	ASSY.FLANGE-TC OUTLET TO OIL SUMP	TATA spare parts
253418170137	ASSY.FLANGE EURO-III	TATA spare parts
253418170141	COMPACT OIL COOLER(8PLATE)4SPTCBSII	TATA spare parts
253418170142	ASSY RETURN LINE(OIL COOLER- CONNECTOR)	TATA spare parts
253418170143	ASSY. RETURN HOSE (OIL COOLER TO ASSY.	TATA spare parts
253418170144	ASSY. RETURN LINE(OIL COOLER TO ASSY. HO	TATA spare parts
253418170152	ASSY PISTON COOLING NOZZLE	TATA spare parts
253418170154	ASSY.OIL LINE OIL COOLER TO TC -EURO-III	TATA spare parts
253418170155	ASSY OIL COOLER (3 PLATES)	TATA spare parts
253418170161	ASSY. OIL COOLER	TATA spare parts
253418170164	ASSY OIL COOLER	TATA spare parts
253418170165	ASSY OIL LINE (FLEXIBLE) (DICOR TC)	TATA spare parts
253418170171	ASSY. CRIMPED HOSE(W/P TO OIL COOLER)	TATA spare parts
253418170176	ASSY FLANGE W CRIMPED HOSE:4SP TC EUROII	TATA spare parts
253418170187	ASSY OIL COOLER 4SP TCIC BSIII	TATA spare parts
253418170188	ASSY PLATE TYPE OILCOOLER 4SP	TATA spare parts

253418170189	ASSY. HOSE (TC OIL INLINE) BS4	TATA spare parts
253418170190	ASSY OIL LINE (OIL COOLER TO TC)	TATA spare parts
253418170194	ASSY OIL COOLER -M/S POSH	TATA spare parts
253418170205	ASSY. RETURN LINE (OC TO ASSY. HOSE T)	TATA spare parts
253418170206	ASSY. CRIMP HOSE (WATER PUMP TO OIL)	TATA spare parts
253418170207	ASSY. OILCOOLER 4SP TCIC BS3/4	TATA spare parts
253418170209	ASSY. OIL LINE (OIL COOLER TO TC)	TATA spare parts
253418170215	ASSY. RETURN LINE (OC TO ASSY. HOSE T CO	TATA spare parts
253418170216	ASSY RETURN LINE(OILCOOLER TO RAD PIPE)	TATA spare parts
253418170217	COMPACT OILCOOLER(8PLATE)	TATA spare parts
253418170222	COOLANT ASSY RETURN LINE	TATA spare parts
253418170233	RETURN PIPE ASSY OIL COOLER TO T-CONN	TATA spare parts
253418170238	HOSE ASSY. (TC TO SYL BLOCK)	TATA spare parts
253418170241	COOLANT RETURN PIPE ASSY	TATA spare parts
253418170251	OIL PIPE ASSY WITH HOSE OIL COOLER TO TC	TATA spare parts
253418170291	ASSY RETURN LINE(OILCOOLER TO RAD PIPE)	TATA spare parts
253418170295	COOLANT RETURN PIPE ASSY BS6	TATA spare parts
253418170296	PIPEASSY BS6	TATA spare parts
253418170297	OIL RETURN PIPE ASSY TURBOCHARGER BS6	TATA spare parts
253418170298	OIL LINE ASSY BS6	TATA spare parts
253418170302	ASSY. RETURN LINE (OC TO ASSY. HOSE T) B	TATA spare parts
253418170309	OIL COOLER ASSY BS6	TATA spare parts
253418170312	HOSE ASSY	TATA spare parts
253418170318	BRACKET BS6	TATA spare parts
253418170321	OIL COOLER ASSY BS6	TATA spare parts
253418170322	BRACKET BS6	TATA spare parts
253418170327	BRACKET BS6	TATA spare parts
253418170328	RETURN LINE ASSY OIL COOLER BS6-PH2	TATA spare parts
253418170331	SET-PISTON COOLING NOZZLE WITH GASKET BS	TATA spare parts
253418170342	SET-PISTON COOLING NOZZLE BS6	TATA spare parts
253418173201	PIPE UNION BOLT- ALLAN KEY TYPE	TATA spare parts
253418173202	PIPE UNION BOLT M10X1X22LG-4SPTC BSII	TATA spare parts
253418173705	COVER OIL COOLER	TATA spare parts
253418173708	OIL COOLER COVER	TATA spare parts
253418173806	OIL COOLER BACK COVER (AL.)	TATA spare parts
253418175301	GASKET	TATA spare parts
253418175303	GASKET	TATA spare parts
253418175304	GASKET OIL COOLER	TATA spare parts
253418175305	GASKET TURBOCHARGER OUTLET	TATA spare parts
253418175306	GASKET TC OUTLET TEL ECB-582 BS4	TATA spare parts
253418175307	GASKET (OIL FILTER ON CYL BLOCK):EUROIII	TATA spare parts
253418175308	GASKET (MICRO ENGG)4SP EURO III	TATA spare parts
253418175309	GASKET (OIL COOLER W/AL BACK PLATE)	TATA spare parts
253418175312	GASKET-NON ASBESTOS(TC OUTLT)M/S TALB(B)	TATA spare parts
253418175313	GASKET-NON ASBESTOS (TC OUTLET)	TATA spare parts
253418175807	RUBBER HOSE OIL RET.TO BLOCK 4SP BS-III	TATA spare parts
253418175810	RUBBER HOSE-21 OD(VACUUM PUMP-OIL SUMP)	TATA spare parts

253418175812	HOSE (OIL RETURN TO BLK)4SP BSII	TATA spare parts
253418175813	HOSE(OIL RETURN TO BLOCK)4SP BS_II	TATA spare parts
253418175814	HOSE (OIL RETURN TO BLK.)4SP BS_III	TATA spare parts
253418175815	HOSE (TC OIL RETURN TO BLOCK)	TATA spare parts
253418175816	HOSE-21 OD-VACUUM PUMP TO CYLINDER BLOC	TATA spare parts
253418175817	HOSE( OIL RETURN TO CYLINDER BLOCK)	TATA spare parts
253418175823	RUBBER HOSE VACCUM PUMP TO OIL SUMP BS4	TATA spare parts
253418175824	RUBBER HOSE(TC ADAPTER TO CYL.BLOCK) BS4	TATA spare parts
253418175831	VACUUM PUMP OIL DRAIN HOSE IN POLYCRILIC	TATA spare parts
253418175836	RUBBER HOSE	TATA spare parts
253418175837	RUBBER HOSE VACUUM PUMP TO OIL SUMP	TATA spare parts
253418176901	NOZZLE	TATA spare parts
253418177203	SEALING PLUG	TATA spare parts
253418177204	ADAPTOR	TATA spare parts
253418177205	SEALING PLUG M22	TATA spare parts
253418177206	SEALING PLUG	TATA spare parts
253418177208	SEALING PLUG OIL COOLER M/S PN-NJ 4SP	TATA spare parts
253418178001	COLLAR SCREW	TATA spare parts
253418178004	HEX.COLLAR SCREW(FOR PISTON COOL NOZZLE)	TATA spare parts
253418179001	PLUNGER BY PASS	TATA spare parts
253418179906	PIPE UNION BOLT-M10X1.25X25	TATA spare parts
253418179910	ADAPTOR	TATA spare parts
253418179920	ADAPTER BS6	TATA spare parts
253418179923	ADAPTER BS6	TATA spare parts
253420100108	WATER PUMP ASSY	TATA spare parts
253420100110	COOLANT HOSE ASSY	TATA spare parts
253420100111	ASSLY WATER PUMP	TATA spare parts
253420100119	WATER PUMP ASSY	TATA spare parts
253420100120	ASSY. WATER PUMP BS2/3	TATA spare parts
253420100122	ASSY SHAFT-WATER PUMP	TATA spare parts
253420100124	ASSY. WATER PUMP BS1/2/3	TATA spare parts
253420100128	ASSY WATER PUMP	TATA spare parts
253420100129	ASSLY WATER PUMP	TATA spare parts
253420100130	ASSY.WATER PUMP BS2/3/4	TATA spare parts
253420100132	ASSLY WATER PUMP	TATA spare parts
253420100133	ASSY WATER PUMP COMPLETE	TATA spare parts
253420100137	ASSY.CLAMP(OIL COOLER TUBE)4SPTCBS2SPACI	TATA spare parts
253420100140	ASSY. BRACKET(ASSY CRIMPED HOSE) (B)	TATA spare parts
253420100145	ASSY. PIPE (WATER PUMP TO EGR COOLER)	TATA spare parts
253420100147	ASSY. WATER PUMP BS3/4	TATA spare parts
253420100150	ASSEMBLY WATER PUMP	TATA spare parts
253420100152	BACK COVER ASSY. (WATER PUMP)	TATA spare parts
253420100153	ASSY. WATER PUMP(AL)	TATA spare parts
253420100154	ASSY. PIPE (EGR COOLER TO T- CONNECTOR)	TATA spare parts
253420100155	ASSY PIPE (WATER PUMP TO EGR COOLER)	TATA spare parts
253420100156	ASSY PIPE (EGR COOLER TO WATER PUMP)	TATA spare parts
253420100167	WATER PUMP ASSY	TATA spare parts

253420100168	HOSE EGR COOLER TO COOLANT PIPE	TATA spare parts
253420100169	WATER PUMP ASSY	TATA spare parts
253420100178	COOLANT PIPE ASSY BS6	TATA spare parts
253420100179	BRACKET ASSY BS6	TATA spare parts
253420100180	COOLANT HOSE ASSY BS6	TATA spare parts
253420100181	CLAMP ASSY BS6	TATA spare parts
253420100182	BRACKET ASSY BS6	TATA spare parts
253420100183	BRACKET ASSY BS6	TATA spare parts
253420100184	COOLANT HOSE ASSY BS6	TATA spare parts
253420100185	WATER PUMP ASSY BS6	TATA spare parts
253420100187	COOLANT HOSE ASSY BS6	TATA spare parts
253420100188	WATER PUMP ASSY BS6	TATA spare parts
253420100189	BACK COVER ASSY BS6	TATA spare parts
253420100193	PIPE ASSY EGR COOLER TO WATER PUMP BS6	TATA spare parts
253420100195	WATER PUMP ASSY BS6	TATA spare parts
253420100201	WATER PUMP ASSY BS6-PH2	TATA spare parts
253420100220	WATER PUMP ASSY BS6-PH2	TATA spare parts
253420103106	INTEGRAL SHAFT BEARING	TATA spare parts
253420103109	INTEGRAL SHAFT BEARING BS6-PH2	TATA spare parts
253420103301	CLAMP (COOLANT LINE SIDE)	TATA spare parts
253420103302	CLAMP (COOLANT LINE REAR)	TATA spare parts
253420103703	BACK COVER WATER PUMP	TATA spare parts
253420103705	HOUSING WATER PUMP	TATA spare parts
253420103706	IMPELLER WATER PUMP	TATA spare parts
253420103711	IMPELLER	TATA spare parts
253420103712	WATER PUMP HOUSING.	TATA spare parts
253420103806	WATER PUMP HOUSING	TATA spare parts
253420103807	IMPELLER (PLASTIC)	TATA spare parts
253420103808	WATER PUMP BACK COVER	TATA spare parts
253420103815	IMPELLER BS6	TATA spare parts
253420103816	HOUSING WATER PUMP BS6	TATA spare parts
253420103817	BACK COVER WATER PUMP BS6	TATA spare parts
253420103819	HOUSING WATER PUMP BS6-PH2	TATA spare parts
253420104201	CLAMP(ON COMMON RAIL BRACKET)	TATA spare parts
253420104202	CLAMP(P-TYPE)ON CYL.HEAD COVER	TATA spare parts
253420104203	CLAMP(ON CYL.HEAD COVER)	TATA spare parts
253420105103	HUB WATER PUMP	TATA spare parts
253420105108	HUB WATER PUMP BS6-PH2	TATA spare parts
253420105109	HUB	TATA spare parts
253420105301	GASKET BS4	TATA spare parts
253420105302	GASKET	TATA spare parts
253420105305	GASKET BS4	TATA spare parts
253420105307	WATER PUMP GASKET	TATA spare parts
253420105837	RUBBER HOSE (RADIATOR TO W/P)	TATA spare parts
253420106906	COLLER TYPE TUBE( DIA. 16X49L) BS6-PH2	TATA spare parts
253420106907	TUBE BS6	TATA spare parts
253420107702	O RING (FOR ASSY.WATER PUMP)	TATA spare parts



253420107703	RUBBER BUSH (SUPPORT CLAMP COOLANT LINE)	TATA spare parts
253420107801	OIL SEAL	TATA spare parts
253420107902	SHAFT WATER PUMP	TATA spare parts
253420108801	STUD FAN PULLEY BS6-PH2	TATA spare parts
253420108803	BOLT	TATA spare parts
253420110101	PULLEY WATER PUMP	TATA spare parts
253420110102	COOLANT HOSE ASSY BS6-PH2	TATA spare parts
253420117004	PULLEY-WATER PUMP	TATA spare parts
253420117005	PULLEY- WATER PUMP (3 GROOVE)	TATA spare parts
253420120104	ASSY. THERMOSTAT WAX TYPE BS3	TATA spare parts
253420120105	ASSY. UPPER COOLING WATER LINE BS2/3	TATA spare parts
253420120107	ASSY. THERMOSTAT BS2/3	TATA spare parts
253420120108	ASSY.UPPER COOLING WATER LINE	TATA spare parts
253420120111	ASSY THERMOSTAT	TATA spare parts
253420120113	ASSY.THERMOSTAT-OFFER DRG	TATA spare parts
253420120115	UPPER COOL LINE LP 407	TATA spare parts
253420120116	THERMOSTAT	TATA spare parts
253420120117	THERMOSTAT LP 407	TATA spare parts
253420120130	ASSY.THERMOSTAT PLASTIC	TATA spare parts
253420120131	ASSY. UPPER COOLING LINE	TATA spare parts
253420120133	ASSY. THERMOSTAT-WAX TYPE 87 SOT	TATA spare parts
253420120135	ASSY UPPER COOLING WATER LINE	TATA spare parts
253420120137	THERMOSTAT ASSY.	TATA spare parts
253420120139	ASSY.UPPER COOLING LINE-207 DI BSII	TATA spare parts
253420120141	ASSY.THERMOSTAT 76 DEG SOT	TATA spare parts
253420120142	ASSY UPPER COOLING WATER LINE	TATA spare parts
253420120143	ASSY.THERMOSTATE 83 DEG. -EURO-III	TATA spare parts
253420120144	THERMOSTAT ASSEMBLY(CALTHERM) 83DEG SOT	TATA spare parts
253420120149	ASSY. UPPER COOLING WATER LINE	TATA spare parts
253420120150	ASSY.UPPER COOLING LINE 207 DI LHD BSI	TATA spare parts
253420120151	ASSY UPPER COOLING WATER LINE:AL COVER	TATA spare parts
253420120153	ASSY.UPPER COOLING LINE 207DI BSIII	TATA spare parts
253420120156	THERMOSTAT (CALTHERM 120LPH)	TATA spare parts
253420120157	UPPER COOLING LINE	TATA spare parts
253420120158	ASSY UPPER COOLING LINE	TATA spare parts
253420120163	UPPER COOLING LINE 207DI	TATA spare parts
253420120165	ASSY UPPER COOLING LINE	TATA spare parts
253420120168	ASSY.THERMOSTAT 90 SOT 4SPTCBS2	TATA spare parts
253420120169	UPPER COOLING WATER LINE	TATA spare parts
253420120171	ASSY UPPER-WATER-COOLING-LINE LP909 CNG	TATA spare parts
253420120174	ASSY. UWCL LP 407 CNG BS-3 NLT	TATA spare parts
253420120182	ASSY UPPER COOLING WATER LINE (4SP SFC41	TATA spare parts
253420120184	ASSY. UPPER COOLING WATER LINE	TATA spare parts
253420120186	ASSY UPPER COOLING WATER LINE	TATA spare parts
253420120187	ASSY. THERMOSTAT	TATA spare parts
253420120192	ASSY UPPER COOLING WATER LINE(WITH TUBE)	TATA spare parts
253420120194	THERMOSTAT ASSY. (LOW LEAKAGE)	TATA spare parts

253420120195	ASSY UPPER COOLING WATER LINE	TATA spare parts
253420120198	THERMOSTAT ASSY. (LOW LEAKAGE)	TATA spare parts
253420120199	ASSY. UPPER COOLING WATER LINE	TATA spare parts
253420120201	ASSY. UPPER COOLING WATER LINE WITH HVAC	TATA spare parts
253420120204	ASSY.UPPER COOLING WATER LINE(BSIV)	TATA spare parts
253420120210	THERMOSTAT ASSY-LOW LEAKAGE	TATA spare parts
253420120211	THERMOSTAT ASSY-LOW LEAKAGE	TATA spare parts
253420120212	ASSY. UPPER COOLING WATER LINE	TATA spare parts
253420120216	THERMOSTAT ASSY BS4	TATA spare parts
253420120235	UPPER WATER COOLING LINE	TATA spare parts
253420120237	HOSE ASSY. T-BRANCH	TATA spare parts
253420120242	UPPER COOLING WATER PIPE ASSY	TATA spare parts
253420120249	COOLING WATER PIPE ASSY UPPER	TATA spare parts
253420120251	UPPER COOLING WATER PIPE ASSY	TATA spare parts
253420120252	THERMOSTAT ASSY	TATA spare parts
253420120253	THERMOSTAT ASSY	TATA spare parts
253420120254	THERMOSTAT ASSY	TATA spare parts
253420120264	UPPERCOOLINGWATERPIPEASSY BS6	TATA spare parts
253420120267	THERMOSTAT ASSY	TATA spare parts
253420120272	THERMOSTAT ASSY BS6	TATA spare parts
253420123812	UPPER COOLING WATER PIPE BS6	TATA spare parts
253420125802	HOSE THERMO TO W/PUMP	TATA spare parts
253420125806	RUBBER HOSE	TATA spare parts
253420125807	HOSE - THERM TO W/P LP407	TATA spare parts
253420125808	HOSE (THERMOSTAT TO U. C. WATER LINE)	TATA spare parts
253420125809	HOSE-THERMOSTAT TO WATER PUMP	TATA spare parts
253420125810	HOSE-RADIATOR TO WATER PUMP	TATA spare parts
253420125811	RUBBER HOSE U.C.L TO THERMOSTAT.	TATA spare parts
253420125815	HOSE THERMOSTAT TO WATER PUMP	TATA spare parts
253420125816	HOSE-THERMOSTAT TO WATER PUMP	TATA spare parts
253420125817	RUBBER HOSE (UCWL TO THERMOSTAT)	TATA spare parts
253420125818	RUBBER HOSE (THERMOSTAT TO W.P)	TATA spare parts
253420125819	HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
253420125825	HOSE THERMOSTAT TO WPUMP 207 DI LHD BSI	TATA spare parts
253420125827	HOSE THERMOSTAT TO WATER PUMP	TATA spare parts
253420125828	HOSE-U.C.L TO THERMOSTAT	TATA spare parts
253420125834	HOSE (THERMO TO RAD)	TATA spare parts
253420125837	HOSE(UCWL TO THERMOSTAT)	TATA spare parts
253420125838	HOSE(THERMOSTAT TO WATER PUMP)	TATA spare parts
253420125848	RUBBER HOSE (U.C.L. TO THERMOSTAT)	TATA spare parts
253420125849	RUBBER HOSE (THERMOSTAT TO WATER PUMP)	TATA spare parts
253420125850	RUBBER HOSE(EGR TO UCL)	TATA spare parts
253420125851	RUBBER HOSE (U.C.L. TO THERMOSTAT)	TATA spare parts
253420125853	RUBBER HOSE (THERMOSTAT TO WATER PUMP)	TATA spare parts
253420125857	HOSE (THSTAT TO WP)	TATA spare parts
253420125858	HOSE (UCL TO THSTAT)	TATA spare parts
253420125861	HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts

253420125862	HOSE THERMOSTAT	TATA spare parts
253420125863	RUBBER HOSE (THERMOSTAT TO WATER PUMP)	TATA spare parts
253420125864	HOSE (THERMOSTAT TO RADIATOR) BS4	TATA spare parts
253420125865	HOSE (UCL TO THERMOSTAT) BS4	TATA spare parts
253420125899	HOSE,EGR COOLER,INTAKE	TATA spare parts
253420135809	HOSE,UPPER COOLING LINE TO THERMOSTAT	TATA spare parts
253420135815	HOSE THERMOSTAT TO RADIATOR BS6	TATA spare parts
253420135816	HOSE THERMOSTAT TO WATER PUMP BS6	TATA spare parts
253420135817	HOSE UPPER COOLING LINE TO THERMOSTAT BS	TATA spare parts
253420140101	FAN ASSY 400 DIA PLASTIC	TATA spare parts
253420140104	FAN ASSY PLASTIC	TATA spare parts
253420140105	ASSY. FAN	TATA spare parts
253420140106	ASSY. FAN (VISCOUS) BS4	TATA spare parts
253420140107	JET RING ASSY FAN	TATA spare parts
253420140108	VISCOUS CLUTCH	TATA spare parts
253420140110	VISCOUS FAN ASSY BS6	TATA spare parts
253420140116	VISCOUS FAN ASSY	TATA spare parts
253420140146	PULLEY ASSY WATER PUMP(SHEET METAL W/PS)	TATA spare parts
253420140171	VISCOUS FAN ASSY	TATA spare parts
253420143801	FAN SPACER	TATA spare parts
253420143807	FAN SPACER-25	TATA spare parts
253420143813	SPACER FAN	TATA spare parts
253420147003	WATER PUMP PULLEY 4SPNA BSI AC	TATA spare parts
253420147004	WATER PUMP PULLEY-207 DI AC+P/STG BSII	TATA spare parts
253420147005	WATER PUMP PULLEY.207 DI BSII AC+PS	TATA spare parts
253420147006	WATER PUMP PULLEY-207DI BSII AC+W/O PSTG	TATA spare parts
253420147007	PULLEY WP SHEET METAL BS-III SIN.GR.175	TATA spare parts
253420147009	PULLEY WATER PUMP 175 DIA.	TATA spare parts
253420147015	PULLEY (WP) 3GR.SHEETMETAL	TATA spare parts
253420147018	WATER PUMP PULLEY BS6-PH2	TATA spare parts
253420156302	V BELT COGGED 1185MM BS2/3/4	TATA spare parts
253420156304	V BELT COGGED 1235MM	TATA spare parts
253420156309	V BELT COGGED 1135MM	TATA spare parts
253420156310	V BELT COGGED 925MM BS2/3	TATA spare parts
253420156323	COGGED BELT(980 LENGTH)	TATA spare parts
253420156324	COGGED V BELT-1450MM LONG	TATA spare parts
253420156325	V BELT COGGED 1325 MM LONG	TATA spare parts
253420156326	COGGED BELT(1280 LENGTH)	TATA spare parts
253420156327	COGGED BELT(1185 LENGTH)	TATA spare parts
253420156330	V BELT -950 LG	TATA spare parts
253420156332	POLY VEE BELT	TATA spare parts
253420990101	WP REP KIT MAJOR	TATA spare parts
253420990102	WP REP KIT MINOR	TATA spare parts
253420990103	REP KIT WATER PUMP MJR	TATA spare parts
253420990104	REP KIT WATER PUMP MNR	TATA spare parts
253420990105	REP KIT WATER PUMP MJR	TATA spare parts
253422100102	ASSY.LIFTING HOOK(REAR)	TATA spare parts

253422107103	LIFTING HOOK (REAR)	TATA spare parts
253422107104	LIFTING HOOK(FRONT)	TATA spare parts
253422107106	LIFTING HOOK REAR (DICOR)	TATA spare parts
253422107111	LIFTING HOOK (FRONT)	TATA spare parts
253422107113	LIFTING HOOK (REAR) 207DI BS-IV	TATA spare parts
253422107115	LIFTING HOOK (REAR)	TATA spare parts
253422107116	LIFTING HOOK (FRONT)	TATA spare parts
253422107117	LIFTING HOOK (REAR)	TATA spare parts
253422107118	LIFTING HOOK	TATA spare parts
253422107120	LIFTING HOOK	TATA spare parts
253422107123	ENGINE LIFTING HOOK REAR	TATA spare parts
253422107125	LIFTING HOOK FRONT	TATA spare parts
253422107128	LIFTING HOOK FRONT BS6	TATA spare parts
253422107129	LIFTING HOOK FRONT BS6	TATA spare parts
253422107130	LIFTING HOOK BS6	TATA spare parts
253422120113	ASSY.ENGINE MTG.BKT.(FRONT LH) 40KVA GEN	TATA spare parts
253422120114	ASSY.ENGINE MTG.BKT.(FRONT RH) 40KVA GEN	TATA spare parts
253422125104	ENGINE SUPPORT FR RH	TATA spare parts
253422125105	ENGINE SUPPORT FR LH	TATA spare parts
253422125110	FRONT ENGINE SUPPORT LEFT (PAINTED)	TATA spare parts
253422125111	FRONT ENGINE SUPPORT LEFT	TATA spare parts
253422125112	FRONT ENGINE SUPPORT-RIGHT(PAINTED)	TATA spare parts
253422125113	FRONT ENGINE SUPPORT-LEFT (PAINTED)	TATA spare parts
253422125117	ENGINE MOUNT BS6	TATA spare parts
253422125118	ENGINE MOUNT FRONT BS6	TATA spare parts
253422125125	ENGINE SUPPORT FRONT-LH BS6	TATA spare parts
253422125126	ENGINE MTG ARM FRONT-RH BS6	TATA spare parts
253423116301	COGGED V-BELT	TATA spare parts
253423116302	COGGED V-BELT	TATA spare parts
253423116304	COGGED V-BELT	TATA spare parts
253423116305	COGGED V-BELTBS6	TATA spare parts
253423116307	COGGED V-BELT BS6	TATA spare parts
253423116310	COGGED V-BELT BS6	TATA spare parts
253423116701	PIVOT PIN	TATA spare parts
253423117001	PULLEY,POWER STEERING PUMP	TATA spare parts
253423117002	PULLEY POWER STEERING PUMP	TATA spare parts
253423120104	ASSY.IDLER	TATA spare parts
253423120113	ASSY.BRACKET AC MTG	TATA spare parts
253423120115	ASSY.BRACKET(A/C BRACKET SUPPORT) (B)	TATA spare parts
253423123301	BRACKET BS6	TATA spare parts
253423123708	BRACKET AC COMP MTG (253423123705) BS6	TATA spare parts
253423126301	POLY V BELT 6PK 1255L	TATA spare parts
253423126305	EPDM POLY V BELT 1295	TATA spare parts
253423126313	POLY V-BELT BS6	TATA spare parts
253423400107	ASSY. BRACKET CPI POWER STRG.PUMP	TATA spare parts
253423400109	ASSY.BRACKET -LHD	TATA spare parts
253423400110	ASSY.BRACKET P/STG+AC-207DI HI TORQ	TATA spare parts

253423400112	ASSY.BRACKET-P/STG(RHD)207 DI-BSII	TATA spare parts
253423400113	ASSY.TENSIONER-P/STG PUMP-207DI BSII	TATA spare parts
253423400115	ASSY. TENSIONER	TATA spare parts
253423400117	ASSY.BRACKET-ZF CP1 POWER STG.PUMP MTG.	TATA spare parts
253423400122	ASSY BRACKET- POWER STEERING PUMP	TATA spare parts
253423400131	ASSY BRACKET (POWER STEERING MOUNTING)	TATA spare parts
253423400136	ASSY. TENSIONER (P/S-PUMP)	TATA spare parts
253423400137	ASSY. BRACKET (FOR POWER STRG. PUMP)	TATA spare parts
253423400138	ASSY TENSIONER(P/S PUMP):SFC410 BS-IIIH	TATA spare parts
253423400139	ASSY BRACKET(FOR PS PUMP):SFC410 BS-III	TATA spare parts
253423400155	TENSIONER ASSY BS6	TATA spare parts
253423400166	ARRGT.ASSY TENSIONING ROD	TATA spare parts
253423400169	NUT BS6-PH2	TATA spare parts
253423400173	TENSIONER ROD ASSY WITH CLAMP NUT(253423	TATA spare parts
253423401602	V-BELT (COGGED) 935MM SFC410BSIII	TATA spare parts
253423403301	BRACKET (MTG.P/STRG.PUMP)	TATA spare parts
253423403303	BRACKET (RANE POWER STG.)	TATA spare parts
253423403507	ADAPTER BS6	TATA spare parts
253423403703	BRACKET (CAST ZF CPI POWER STRG.PUMP)	TATA spare parts
253423403708	BRACKET,POWER STEERING MTG	TATA spare parts
253423403709	CASTED POWER STEERING BKT	TATA spare parts
253423403710	POWER STEERING BRKT CAST VERSION	TATA spare parts
253423403714	SUPPORT BRACKET POWER STEERING PUMP MTG	TATA spare parts
253423403715	BRACKET POWER STEERING PUMP	TATA spare parts
253423403716	BRACKET POWER STEERING MTG BS6	TATA spare parts
253423403718	BRACKET BS6-PH2	TATA spare parts
253423404208	CLAMPING BOLT (TENSIONER) BS6	TATA spare parts
253423406303	COGGED V BELT-207DI-BSII	TATA spare parts
253423406306	V-BELT (COGGED) 935MM SFC410BSIII	TATA spare parts
253423406308	V-BELT (COGGED) 935MM SFC410BSIII	TATA spare parts
253423407003	PULLEY-CAST	TATA spare parts
253423407004	PULLEY-P/STG.PUMP-207DI BSII	TATA spare parts
253423407005	PULLEY:ZF-CPI POWER STEERING PUMP	TATA spare parts
253423407006	PULLEY ( POWER STEERING PUMP)	TATA spare parts
253424100107	ENGINE MTG. FRT. LH	TATA spare parts
253424100108	ENGINE MTG. FRT. RH	TATA spare parts
253424100109	ASSY. ENGINE MTG. FRONT LH	TATA spare parts
253424100111	ASSY. ENGINE MOUNT (REAR)	TATA spare parts
253424100114	ASSY. ENG. MOUNT FRONT RH	TATA spare parts
253424100115	ASSY. ENG. MOUNT FRONT LH	TATA spare parts
253424100120	ASSY.ENG MTG FRONT LH COMPLETE 4SPTCBSII	TATA spare parts
253424100121	ASSY. ENG. MTG. FRONT RH COMPLETE	TATA spare parts
253424100126	ENGINE MTG ASSY RH	TATA spare parts
253424106701	PIN	TATA spare parts
253424200104	ASSY.ENGINE MTG. REAR (COMPLETE)	TATA spare parts
253424207106	SUPPORT PLATE (REAR MTG.RTV)	TATA spare parts
253425103705	CLUTCH HSG.	TATA spare parts

253425103707	CLUTCH HSG.LOW.PART	TATA spare parts
253425103711	CLUTCH HSG.	TATA spare parts
253425103715	CL. HOUSING (4SP)-nls-3718	TATA spare parts
253425103718	Clutch housing RTV/Azadi	TATA spare parts
253425103720	CLUTCH HOUSING	TATA spare parts
253425103721	CLUTCH HOUSING(G-76 GEAR BOX-OE.TCD REDN	TATA spare parts
253425103722	CLUTCH HOUSING	TATA spare parts
253425103724	CLUTCH HOUSING	TATA spare parts
253425103726	CLUTCH HOUSING (FOR DLC COATED BALL PIN)	TATA spare parts
253425103728	CLUTCH HOUSING (FOR DLC COATED BALL PIN)	TATA spare parts
253425105301	GASKET (INSPECTION WINDOW)	TATA spare parts
253425106702	BALL PIN	TATA spare parts
253425106703	BALL PIN (CLUTCH HOUSING)	TATA spare parts
253425108202	PROTECTIVE COVER	TATA spare parts
253425108203	COVER	TATA spare parts
253425108205	CLUTCH HSG COVER LOWER	TATA spare parts
253425108206	CLUTCH HSG.COVER	TATA spare parts
253425108207	COVER-CLUTCH HOUSING	TATA spare parts
253425108208	COVER-ON CLUTCH HSG	TATA spare parts
253425108209	CLUTCH HOUSING LOWER PART.	TATA spare parts
253425108210	CLUTCH HOUSING (LOWER PART)(BTM COVER)	TATA spare parts
253425108211	PROTECTIVE COVER(CL.HSG.FRONT TCD REDN.)	TATA spare parts
253425108212	CLUTCH HOUSING (LOWER PART)	TATA spare parts
253425108214	COVER (INSPECTION WINDOW)	TATA spare parts
253449100101	ASSY CAT.CONVERTOR	TATA spare parts
253449100103	CATALYTIC CONVERTER BSIII	TATA spare parts
253449100106	ASSY CAT CON (ENGLEHARD)15gm 300cpsi	TATA spare parts
253449100109	ASSY. U.B. CAT.CON(80-25GMS/CFT) 4SPCR B	TATA spare parts
253449100110	ASSY. U.B.CATALYTIC CONVERTER	TATA spare parts
253449100113	CATALYST ASSY UNDER BODY	TATA spare parts
253450000103	RUB MTG PAD RAD BOTTOM BS4	TATA spare parts
253450000106	ASSY.BRACKET-LH-RADIATOR MTG.-BOTTOM	TATA spare parts
253450000107	ASSY.BRACKET-RH-RADIATOR MTG.-BOTTOM	TATA spare parts
253450000110	ASSY.RADIATOR MTG.PAD-TOP-COMP. BS4	TATA spare parts
253450000113	ASSY. RADIATOR & FANAHRUD	TATA spare parts
253450000126	RADIATOR ASSY (ALONG WITH INTERCOOLER AN	TATA spare parts
253450005801	RUB BELLOW THERMO TO PIPE	TATA spare parts
253450005803	RUBBER BELLOW-ON THERMOSTAT	TATA spare parts
253450005804	RUBBER BELLOW (RADIATOR TO THERMOSTAT)	TATA spare parts
253450005805	RUBBER HOSE(38IDX5TH)UCL-T'STAT	TATA spare parts
253450005807	RUBBER BELLOW T'STAT TO RADIATOR	TATA spare parts
253450005808	HOSE(THERMOSTAT VENT TO CFP)LP407:BS2	TATA spare parts
253450005817	HOSE(RAD. VENT TO VENT PIPE)	TATA spare parts
253450005819	HOSE(UWCL TS TO VENT PIPE)	TATA spare parts
253450005822	HOSE (VENT PIPE TO FILLER NECK)	TATA spare parts
253450006901	SPACER TUBE 50MM LONG	TATA spare parts
253450009901	TIE ROD RADIATOR	TATA spare parts

253450100110	ASSY RADIATOR W/CAP & DRAIN COCK	TATA spare parts
253450100112	RADIATOR ASSY	TATA spare parts
253450100113	RADIATOR ASSY 407	TATA spare parts
253450100114	RADIATOR ASSY	TATA spare parts
253450100118	ASSY. HOSE WITH CONNECTOR	TATA spare parts
253450100121	ASSY. RAD WITH CAP & DRAIN COCK	TATA spare parts
253450100124	ASSY. RADIATOR	TATA spare parts
253450100128	RADIATOR ASSY	TATA spare parts
253450100131	RADIATOR ASSY	TATA spare parts
253450100136	ASSY RAD COMP	TATA spare parts
253450100137	ASSY. RAD WITH CAP & DRAIN COCK	TATA spare parts
253450100140	ASSY RETURN PIPE(RAD TO W.PUMP-CAB HEAT)	TATA spare parts
253450100145	ASSY.RADIATOR BLOCK W.DRAIN COCK	TATA spare parts
253450100158	ASSY.RADIATOR-OFFER DRG.	TATA spare parts
253450100159	ASSY.BRACKET-RH-RADIATOR MTG.	TATA spare parts
253450100160	ASSY.BRACKET-LH-RADIATOR MTG.	TATA spare parts
253450100161	FILLER PIPE-RAD TO W/P LP	TATA spare parts
253450100163	ASSY.BRACKET-RH-RADIATOR MTG.	TATA spare parts
253450100164	ASSY.BRACKET-LH-RADIATOR MTG.	TATA spare parts
253450100165	RADIATOR LP 407	TATA spare parts
253450100168	ASSY.RADIATOR	TATA spare parts
253450100173	RADIATOR ASSY	TATA spare parts
253450100181	BRACKET ASSY BS6	TATA spare parts
253450100184	RADIATOR LPT 407	TATA spare parts
253450100185	ASSY.RADIATOR	TATA spare parts
253450100186	ASSY. RAD WITH CAP & DRAIN COCK	TATA spare parts
253450100189	RADIATOR 407 TURBO	TATA spare parts
253450100190	ASSY RADIATOR BLOCK :SFC 407 (OFFER)	TATA spare parts
253450100192	ASSY RADITOR	TATA spare parts
253450100195	ASSY.RADIATOR-OFFER DRG	TATA spare parts
253450100199	RADIATOR BOTTOM GAURD	TATA spare parts
253450100204	TUBE ASSY BS6-PH2	TATA spare parts
253450100205	TUBE ASSY BS6-PH2	TATA spare parts
253450100213	ASSY RADIATOR (ALUMINIUM) WITHOUT TANK	TATA spare parts
253450100222	ASSY RADIATOR LP407	TATA spare parts
253450100223	ASSY RADIATOR LPT407	TATA spare parts
253450100224	ASSY. RADIATOR-AL-CORE PLASTIC TANK BS2	TATA spare parts
253450100225	ASSY RADIATOR LPT407	TATA spare parts
253450100226	ASSY RADIATOR LP407	TATA spare parts
253450100232	ASSY.RADIATOR WITH FAN SHROUD(LP-407)	TATA spare parts
253450100233	ASSY.RADIATOR WITH FAN SHROUD (LPT-407)	TATA spare parts
253450100237	ASSY.RADIATOR-AL-CORE PLASTIC TANK	TATA spare parts
253450100240	ASSY. RADIATOR LP407CNG	TATA spare parts
253450100246	BOTTOM TANK ASSY	TATA spare parts
253450100248	DRAIN COCK	TATA spare parts
253450100251	RADIATOR CORE COMPLETE	TATA spare parts
253450100257	ASSY.RAD.& INT TATA TOYO LP-407 BS-III	TATA spare parts

253450100258	ASSY RADIATOR LP-407 BS-III	TATA spare parts
253450100259	ASSY.RAD.WITH IC BS-III	TATA spare parts
253450100260	ASSEMBLY RADIATOR COMPLETE.	TATA spare parts
253450100261	ASSY. RADIATOR SFC-407 BS2/3	TATA spare parts
253450100263	ASSY BRACKET (FOR RAD MTG LH/RH)	TATA spare parts
253450100265	ASSY.RADIATOR MTG BKT.(LH SIDE)	TATA spare parts
253450100266	ASSY.RADIATOR COMPLETE WITH ELECTRIC FAN	TATA spare parts
253450100267	ASSEMBLY RADIATOR	TATA spare parts
253450100268	ASSY. ELECTRIC FAN 12V 130W	TATA spare parts
253450100270	SET-AUX.W.TANK MTG CLAMPS & FITMENT SFC	TATA spare parts
253450100271	ASSY. BRACKET (RH-BOTTOM)(FOR RAD. MTG.)	TATA spare parts
253450100272	ASSY. BRACKET (LH-BOTTOM)(FOR RAD. MTG.)	TATA spare parts
253450100275	ASSY RADIATOR WITH ELE.FAN & PL SHROUD	TATA spare parts
253450100276	FAN MOTOR ASSY	TATA spare parts
253450100277	ASSY. RADIATOR WITH ELECTRIC FAN	TATA spare parts
253450100280	RADIATOR LP407CNG BS III	TATA spare parts
253450100281	ASSY RADIATOR SFC407CNG BSIII	TATA spare parts
253450100283	ASSY RAD WITH FAN SHROUD LP407 BS2	TATA spare parts
253450100284	ASSY.RADIATOR LP407	TATA spare parts
253450100292	COOLANT LINE ASSY BS6	TATA spare parts
253450100293	ASSY COOLANT FILL PIPE W PR CAP & CHAIN	TATA spare parts
253450100305	ASSY RAD. & I.C.LP410 BS3	TATA spare parts
253450100306	ASSY. RADIATOR LP410 BS2/3	TATA spare parts
253450100312	ASSY RAD.MTG FRAME LP410	TATA spare parts
253450100314	ASSY. RADIATOR & FAN SHROUD BS1/3/4	TATA spare parts
253450100315	RADIATOR BLOCK SPRINT BS1/3/4	TATA spare parts
253450100315DF	RADIATOR W/O FRAME - XENON 4SP BS3/4	TATA spare parts
253450100317	ASSY. RAD WITH FAN SHROUD (NO LOSS TANK)	TATA spare parts
253450100321	COOLANT RECOVERY TANK	TATA spare parts
253450100352	ASSY RADIATOR LP407 CNG BS-3	TATA spare parts
253450100372	TUBE ASSY BS6	TATA spare parts
253450100373	TUBE ASSY BS6	TATA spare parts
253450100394	RADIATOR 4SPTC CR BSIV FOR 207 DI	TATA spare parts
253450103308	BRACKET-AUX.TANK MOUNTING	TATA spare parts
253450103311	BRACKET RADIATOR MTG-RH	TATA spare parts
253450103312	BRACKET RADIATOR MTG-LH	TATA spare parts
253450103313	BRACKET RADIATOR MTG-RH (BOTTOM MTG)	TATA spare parts
253450103314	BRACKET RADIATOR MTG-LH (BOTTOM MTG)	TATA spare parts
253450103315	BRACKET RAD MTG (RH-BOTTOM MTG)	TATA spare parts
253450103316	BRACKET RAD MTG (LH-BOTTOM MTG)	TATA spare parts
253450103336	BRACKET NO LOSS TANK MTG UPPER	TATA spare parts
253450103344	BRACKET BS6-PH2	TATA spare parts
253450103345	BRACKET-RADIATOR FRAME SIDE MTG-LH BS6	TATA spare parts
253450103346	BRACKET RADIATOR FRAME SIDE MTG RH BS6	TATA spare parts
253450103347	BRACKET ASSY RADIATOR MTG BOTTOM-LH BS6	TATA spare parts
253450103348	BRACKET ASSY RADIATOR MTG BOTTOM-RH BS6	TATA spare parts
253450103349	BRACKET ASSY	TATA spare parts



253450104204	CLAMP ASSY BS6	TATA spare parts
253450105805	RUBBER HOSE	TATA spare parts
253450105806	HOSE WATER PUMP TO RADIATOR	TATA spare parts
253450105809	RUBBER HOSE BS4	TATA spare parts
253450105811	RUB HOSE RAD TO W/PUMP	TATA spare parts
253450105812	RUBBER HOSE RAD TO W/PUMP	TATA spare parts
253450105813	HOSE-RAD TO RETN PIPE LP	TATA spare parts
253450105814	HOSE-W/P TO RETN LINE LP	TATA spare parts
253450105815	HOSE-THEM TO RAD LP 407	TATA spare parts
253450105822	HOSE-WATER PUMP TO RADIATOR	TATA spare parts
253450105823	HOSE RADIATOR TO WATER PUMP	TATA spare parts
253450105824	HOSE THERMO. TO RADIATOR	TATA spare parts
253450105825	HOSE WATER PUMP TO RADIATOR	TATA spare parts
253450105826	RUBBER HOSE UCWL TO THERMOSTATE BS4	TATA spare parts
253450105827	RUBBER HOSE THERMOSTAT TO RADIATOR BS4	TATA spare parts
253450105828	RUBBER HOSE THERMOSTAT TO W/PUMP BS4	TATA spare parts
253450105830	HOSE (FROM RADIATOR TO PIPE)	TATA spare parts
253450105831	HOSE (RADIATOR PIPE TO ENGINE)	TATA spare parts
253450105834	RUBBER HOSE RAD TO WP SFC BS-III	TATA spare parts
253450105835	HOSE (WATER PUMP TO RADIATOR)LP 407	TATA spare parts
253450105837	HOSE(THERMOSTAT TO RADIATOR)509M	TATA spare parts
253450105839	HOSE(RADIATOR TO WATER PUMP)	TATA spare parts
253450105840	HOSE(RADIATOR TO WATER PUMP)	TATA spare parts
253450105841	HOSE-RADIATOR TO W PUMP-207 DI LHD BSI	TATA spare parts
253450105845	RUBBER HOSE (RAD TO WP)	TATA spare parts
253450105846	HOSE (RAD TO COOLANT FILLING PIPE)LP407	TATA spare parts
253450105847	HOSE (THERMOSTAT TO COOLANT FILLING PIPE	TATA spare parts
253450105852	HOSE (PIPE TO WP) TELCOLINE	TATA spare parts
253450105863	RUBBER HOSE:F'LER PIPE TO WP:SFC410 MECH	TATA spare parts
253450105874	RUBBER HOSE(RAD TO FP PIPE)	TATA spare parts
253450105886	RUBBER HOSE (RAD TO WP)	TATA spare parts
253450105894	HOSE(T-PIPE TO RAD.)	TATA spare parts
253450105895	HOSE ( TS TO RAD )	TATA spare parts
253450105896	HOSE (RAD. TO WP)	TATA spare parts
253450105899	HOSE (PIPE TO W.P.)	TATA spare parts
253450105906	RUBBER HOSE BS6	TATA spare parts
253450105907	RUBBER HOSE BS6	TATA spare parts
253450105908	RUBBER HOSE BS6	TATA spare parts
253450105909	RUBBER HOSE BS6	TATA spare parts
253450105910	HOSE THERMOSTART TO RADIATOR BS6	TATA spare parts
253450105912	HOSE¿BS6	TATA spare parts
253450105913	HOSE BS6	TATA spare parts
253450105914	HOSE¿BS6	TATA spare parts
253450105915	HOSE (TUBE END TO EGP END) BS6	TATA spare parts
253450105916	HOSE (TUBE TO EGP END) BS6	TATA spare parts
253450105917	HOSE (EGP TUBE TO PIPE) BS6	TATA spare parts
253450105918	HOSE (COOLING HOSE ASSY TO PIPE) BS6	TATA spare parts

253450105924	HOSE EGR TUBE TO TUBE BS6	TATA spare parts
253450105925	HOSE (TUBE TO EGP END) BS6	TATA spare parts
253450105926	HOSE (TUBE TO T-CONNECTOR) BS6	TATA spare parts
253450105929	HOSE REDUCER BS6	TATA spare parts
253450105930	HOSE REDUCER BS6	TATA spare parts
253450105933	HOSE REDUCER BS6	TATA spare parts
253450105934	HOSE REDUCER BS6	TATA spare parts
253450105939	REDUCER HOSE BS6	TATA spare parts
253450105941	RUBBER HOSE BS6	TATA spare parts
253450105942	HOSE REDUCER BS6	TATA spare parts
253450105949	HOSE BS6-PH2	TATA spare parts
253450106304	NO LOSS TANK (RH - PART)	TATA spare parts
253450106308	PIPE	TATA spare parts
253450106906	PIPE(RADIATOR TO ENGINE)	TATA spare parts
253450106909	PIPE(500L 4SP BS-III SFC)RAD TO AUX.	TATA spare parts
253450106946	PIPE (RADIATOR TO WATER PUMP)	TATA spare parts
253450106958	VENT PIPE	TATA spare parts
253450106959	PIPE RADIATOR TO WATER PUMP	TATA spare parts
253450106960	PIPE BS6	TATA spare parts
253450106961	PIPE BS6	TATA spare parts
253450106962	PIPE BS6	TATA spare parts
253450106966	TUBE BS6	TATA spare parts
253450106967	TUBE BS6	TATA spare parts
253450106968	COOLANT PIPE BS6	TATA spare parts
253450106969	COOLANT PIPE BS6	TATA spare parts
253450106970	TUBE BS6	TATA spare parts
253450106973	TUBE BS6	TATA spare parts
253450106974	COOLANT PIPE (ENGINE TO DOSING INJECTOR)	TATA spare parts
253450106975	COOLANT PIPE (ENGINE TO DOSING INJECTOR)	TATA spare parts
253450106976	BENT TUBE BS6	TATA spare parts
253450106977	BENT TUBE BS6	TATA spare parts
253450106978	BENT TUBE BS6	TATA spare parts
253450106979	BENT TUBE BS6	TATA spare parts
253450106980	COOLANT PIPE (DOSING INJECTOR TO ENGINE)	TATA spare parts
253450106981	COOLANT PIPE (DOSING INJECTOR TO ENGINE)	TATA spare parts
253450106986	TUBE BS6	TATA spare parts
253450106987	BENT TUBE BS6	TATA spare parts
253450106989	BENT TUBE BS6	TATA spare parts
253450106990	BENT TUBE BS6	TATA spare parts
253450106991	BENT TUBE BS6	TATA spare parts
253450106992	BENT TUBE BS6	TATA spare parts
253450106993	TUBE BS6	TATA spare parts
253450106994	TUBE BS6	TATA spare parts
253450106995	COOLANT PIPE BS6	TATA spare parts
253450106996	COOLANT PIPE BS6	TATA spare parts
253450106998	VENT TUBE ASSY BS6	TATA spare parts
253450106999	TUBE BS6	TATA spare parts

253450107001	TUBE (DOSING INJECTOR TO ENGIN) BS6	TATA spare parts
253450107002	TUBE BS6	TATA spare parts
253450107004	TUBE BS6	TATA spare parts
253450107005	TUBE BS6	TATA spare parts
253450107009	TUBE BS6-PH2	TATA spare parts
253450107010	TUBE BS6-PH2	TATA spare parts
253450107015	COOLANT PIPE BS6-PH2	TATA spare parts
253450107016	COOLANT PIPE ASSY BS6-PH2	TATA spare parts
253450107018	FLOW TUBE OUTLET	TATA spare parts
253450107019	FLOW TUBE OUTLET	TATA spare parts
253450107502	RUBBER GROMMET (RADIATOR BOTTOM MTG)	TATA spare parts
253450108212	SUPPORT PLATE (FOR NOLOSS TANK)LP407	TATA spare parts
253450108219	BRACKET (RADIATOR MTG.) LOWER LH	TATA spare parts
253450108220	BRACKET (RADIATOR MTG.) LOWER RH	TATA spare parts
253450109902	TANK PACKING	TATA spare parts
253450109905	PRESSURE CAP	TATA spare parts
253450109907	FAN SHROUD-ELECTRIC FAN	TATA spare parts
253450109908	FAN MOTOR SHROUD ASSY	TATA spare parts
253450110104	FAN MOTOR SHROUD ASSY.	TATA spare parts
253450110106	RADIATOR ASSY	TATA spare parts
253450110107	ASSY. HOSE WITH T-CONNECTOR	TATA spare parts
253450110108	NO LOSS TANK ASSY (RH PART)	TATA spare parts
253450110112	ASSY. RADIATOR WITH ELECTRIC FAN:VICTA D	TATA spare parts
253450110117	ASSY.RAD IC W/O FR.(VAVE)	TATA spare parts
253450110118	ASSY RADIATOR (VAVE)	TATA spare parts
253450110122	RADIATOR ASSEMBLY	TATA spare parts
253450110123	RECOVERY BOTTOLE ASSY.	TATA spare parts
253450110148	ASS.RADIATOR & INTERCOOLER SFC410 4X4	TATA spare parts
253450110149	ASSY RADIATOR	TATA spare parts
253450110154	FAN MOTOR ASSY2(BLACK)	TATA spare parts
253450110155	FAN MOTOR ASSY1(RED)	TATA spare parts
253450110158	ASSY. HOSE WITH T-CONNECTOR(RAD TO WP)	TATA spare parts
253450110159	ASSY. RADIATOR BS3/4	TATA spare parts
253450110161	DRAIN COCK ASSY	TATA spare parts
253450110168	ASSEMBLY HOSE WITH T CONNECTER	TATA spare parts
253450110170	ASSY. RADIATOR W/INTERCOOLER BS3	TATA spare parts
253450110171	COOLING SYSYEM RADIATOR & INTERCOOLER BS	TATA spare parts
253450110175	ASSY.FILLER PIPE	TATA spare parts
253450110176	ASSY.T-PIPE	TATA spare parts
253450110192	ASSY.RADIATOR LPT407	TATA spare parts
253450110193	ASSY RADIATOR WITH INTERCOOLER LPT407	TATA spare parts
253450110195	ASSYSEMBLY HOSE WITH T-CONNECTOR	TATA spare parts
253450110199	ASSY. HOSE WITH T-CONNECTOR(RAD TO WP)	TATA spare parts
253450110201	ASSY. HOSE WITH T-CONNECTOR	TATA spare parts
253450110202	ASSY.RADIATOR WITH ELECTRIC FAN 207DI SA	TATA spare parts
253450110203	ASSY RADIATOR WITH I/C	TATA spare parts
253450110210	ASSY RADIATOR (VAVE) M/S ALKRAFT	TATA spare parts

253450110215	HOSE ASSY. WITH T-CONNECTOR	TATA spare parts
253450110216	RADIATOR ASSY. COMPLETE	TATA spare parts
253450110217	RADIATOR ASSY. COMPLETE	TATA spare parts
253450110223	ASSY RADIATOR WITH FANSHROUD	TATA spare parts
253450110229	PRESSURE CAP 0.9BAR BS4	TATA spare parts
253450110239	HOSE ASSY (RADIATOR TO WATER PUMP)	TATA spare parts
253450110240	RADIATOR & INTERCOOLER ASSY	TATA spare parts
253450110243	ASSY. RADIATOR BS3/4	TATA spare parts
253450110244	RADIATOR ASSY. CPL	TATA spare parts
253450110245	MOTOR	TATA spare parts
253450110246	RECOVERY BOTTLE ASSY	TATA spare parts
253450110250	DRAIN COCK	TATA spare parts
253450110251	FAN	TATA spare parts
253450110253	SHROUD	TATA spare parts
253450110256	RADIATOR & INTERCOOLER ASSY BS6	TATA spare parts
253450110257	ASSY. HOSE WITH T-CONNECTOR	TATA spare parts
253450110261	RECOVERY COOLANT TANK ASSY	TATA spare parts
253450110266	RADIATOR ASSY WITH FAN & SHROUD	TATA spare parts
253450110268	RADIATOR & INTERCOOLER ASSY BS6	TATA spare parts
253450110280	HOSE ASSY (RADIATOR TO WATER PUMP)	TATA spare parts
253450110281	HOSE ASSY (RADIATOR TO WATER PUMP)	TATA spare parts
253450110286	PRESSURE CAP	TATA spare parts
253450110287	ASSEMBLY HOSE WITH T-CONNECTOR	TATA spare parts
253450110292	STAY ROD ASSY	TATA spare parts
253450110293	STAY ROD ASSY	TATA spare parts
253450110294	RADIATOR ASSY WITH AWT & FAN SHROUD	TATA spare parts
253450110297	FAN MOTOR SHROUD ASSY	TATA spare parts
253450110298	FAN MOTOR ASSY BS4	TATA spare parts
253450110323	CRIMP HOSE ASSY WITH PIPE (RADIATOR TO N	TATA spare parts
253450110326	FRAME	TATA spare parts
253450110327	FRAME	TATA spare parts
253450110334	RADIATOR & INTERCOOLER ASSY	TATA spare parts
253450110335	RADIATOR ASSY	TATA spare parts
253450110340	BRACKET ASSY RADIATOR BOTTOM MTG BS6	TATA spare parts
253450110351	RADIATOR ASSY BS6	TATA spare parts
253450110352	RADIATOR ASSY BS6	TATA spare parts
253450110355	RADIATOR & INTERCOOLER 36WB BS6	TATA spare parts
253450110358	RADIATOR ASSY BS6	TATA spare parts
253450110359	RADIATOR - INTERCOOLER ASSY BS6	TATA spare parts
253450110367	RADIATORASSY BS6	TATA spare parts
253450115803	HOSE BS6-PH2	TATA spare parts
253450115804	HOSE L90(NO LOSS TANK) BS6	TATA spare parts
253450115810	RUBBER HOSE (THERMOSTAT TO WATER PUMP)	TATA spare parts
253450115814	HOSE (RADIATOR TO T-CONNECTOR	TATA spare parts
253450115815	HOSE (T-CONNECTOT TO W.P)	TATA spare parts
253450115823	HOSE BS6	TATA spare parts
253450115826	RUBBER HOSE (THERMOSTAT TO WATER PUMP)	TATA spare parts

253450115830	HOSE (RADIATOR TO PIPE) BS4	TATA spare parts
253450115831	RUBBER HOSE(T-CONNECTOR TO WATER PUMP)	TATA spare parts
253450115832	RUBBER HOSE(RADIATOR TO T-CONNECTOR)	TATA spare parts
253450115833	RUBBER HOSE( UWCL TO THERMOSTAT )	TATA spare parts
253450115842	RUBBER HOSE (THERMOSTAT)	TATA spare parts
253450115843	RUBBER HOSE( UWCL TO THERMOSTAT )	TATA spare parts
253450115844	HOSE (RADIATOR TO PIPE)	TATA spare parts
253450115845	RUBBER HOSE (THERMOSTAT TO WATER PUMP)	TATA spare parts
253450115847	RUBBER HOSE (UWCL TO THERMOSTAT)	TATA spare parts
253450115850	HOSE L125 (NO LOSS TANK) BS6-PH2	TATA spare parts
253450115854	RUBBER HOSE	TATA spare parts
253450115855	RUBBER HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
253450115871	RUBBER HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
253450115882	HOSE RADIATOR TO PIPE	TATA spare parts
253450115883	HOSE RADIATOR TO VENT PIPE	TATA spare parts
253450115884	HOSE UCL TO VENT TUBE	TATA spare parts
253450115889	HOSE THERMOSTAT TO RADIATOR BS6-PH2	TATA spare parts
253450115890	HOSE¿BS6	TATA spare parts
253450115894	HOSE THERMOSTAT TO RADIATOR	TATA spare parts
253450115895	HOSE THERMOSTAT COVER TO UCL	TATA spare parts
253450115896	HOSE THERMOSTAT TO WATER PUMP	TATA spare parts
253450115898	HOSE RADIATOR WATER PUMP BS6	TATA spare parts
253450115899	HOSE UCWL TO THERMOSTAT BS6	TATA spare parts
253450115904	HOSE RADIATOR WATER PUMP BS6	TATA spare parts
253450116902	COOLANT PIPE BS6-PH2	TATA spare parts
253450116903	COOLANT PIPE BS6-PH2	TATA spare parts
253450116904	COOLANT PIPE BS6-PH2	TATA spare parts
253450116905	COOLANT PIPE BS6-PH2	TATA spare parts
253450116906	PIPE ASSY INTERCOOLER OUTLET BS6	TATA spare parts
253450116907	BENT TUBE	TATA spare parts
253450116908	BENT TUBE	TATA spare parts
253450116912	VENT TUBE ASSY BS6-PH2	TATA spare parts
253450116916	COOLANT PIPE BS6-PH2	TATA spare parts
253450116917	COOLANT PIPE BS6-PH2	TATA spare parts
253450116918	COOLANT PIPE BS6-PH2	TATA spare parts
253450120102	RADIATOR WITH INTERCOOLER SHROUD & BKT B	TATA spare parts
253450120103	COOLANT LINE ASSY BS6	TATA spare parts
253450120104	COOLING PIPE ASSY UPPER BS6-PH2	TATA spare parts
253450120118	STAY ROD ASSY BS6-PH2	TATA spare parts
253450120119	STAY ROD ASSY BS6-PH2	TATA spare parts
253450120120	CRIMP HOSE ASSY WITH PIPE BS6-PH2	TATA spare parts
253450120121	RADIATOR & INTERCOOLER ASSY BS6-PH2	TATA spare parts
253450120122	RADIATOR ASSY BS6-PH2	TATA spare parts
253450120126	BRACKET ASSY BS6-PH2	TATA spare parts
253450120162	COOLANT LINE ASSY BS6-PH2	TATA spare parts
253450120175	STAY ROD ASSY	TATA spare parts
253450120176	STAY ROD ASSY	TATA spare parts

253450125806	RUBBER HOSE BS6	TATA spare parts
253450125807	HOSE BS6	TATA spare parts
253450125815	HOSE BS6-PH2	TATA spare parts
253450125816	HOSE RADIATOR TO THERMOSTAT BS6	TATA spare parts
253450125817	HOSE RADIATOR TO WATER PUMP BS6	TATA spare parts
253450125818	HOSE BS6-PH2	TATA spare parts
253450125819	HOSE BS6-PH2	TATA spare parts
253450125820	HOSE CAC OUTLET BS6	TATA spare parts
253450125821	HOSE RADIATOR TO PIPE BS6-PH2	TATA spare parts
253450125822	HOSE BS6-PH2	TATA spare parts
253450125823	HOSE RADIATOR WATER PUMP BS6-PH2	TATA spare parts
253450125826	RUBBER HOSE BS6-PH2	TATA spare parts
253450125836	RUBBER HOSE BS6-PH2	TATA spare parts
253450125847	HOSE THERMOSTAT TO RADIATOR BS6	TATA spare parts
253450400101	BRACKET RH	TATA spare parts
253450400102	BRACKET LH	TATA spare parts
253450400103	SET-BRACKET W/RAD.MTG.PAD & FASTNERS-RH	TATA spare parts
253450400104	SET-BRACKET W/RAD.MTG.PAD & FASTNERS-LH	TATA spare parts
253450400105	ASSY MTG BRACKET FOR RADIATOR(LH BOTTO	TATA spare parts
253450400106	ASSY MTG BRACKET FOR RADIATOR(UPPER R	TATA spare parts
253450400107	ASSY MTG BRACKET FOR RADIATOR (RH BOTTO	TATA spare parts
253450400108	ASSY MTG BKT FOR RADIATOR (LH UPPER)	TATA spare parts
253450400111	ASSY. MTG BRACKET FOR RADIATOR(UPPER LH)	TATA spare parts
253450400112	ASSY. MTG BRACKET FOR RADIATOR(BOTTOM LH	TATA spare parts
253450400117	BRACKET ASSY RADIATOR MTG LOWER	TATA spare parts
253450403305	BRACKET RADIATOR MTG LOWER-RH	TATA spare parts
253450403306	BRACKET RADIATOR MTG BS6	TATA spare parts
253450407101	ASSY BRACKET R.H.	TATA spare parts
253450500107	FAN SHROUD.	TATA spare parts
253450500108	ASSY. FAN SHROUD	TATA spare parts
253450500109	ASSY. FAN SHROUD	TATA spare parts
253450500111	ASSY.FAN SHROUD(350 DIA.FAN-SPACIO-BSII)	TATA spare parts
253450500114	ASSY FAN SHROUD SFC 407 BS-III	TATA spare parts
253450500115	FAN SHROUD WITH MOTOR (300 DIA)	TATA spare parts
253450500116	ASSY. FAN SHROUD 470 DIA. 4SP LP BS-III	TATA spare parts
253450500117	ASSY FAN SHROUD	TATA spare parts
253450500119	ASSY FAN SHROUD	TATA spare parts
253450500122	FANSHROUD SFC 407 BS-II:418 DIA FAN BS4	TATA spare parts
253450500123	ASSY.HEAT SHIELD (RAD LH SIDE):SFC 407	TATA spare parts
253450500124	ASSY.HEAT SHIELD (RAD R.H SIDE):SFC 407	TATA spare parts
253450500125	ASSY.HEAT SHIELD (RAD TOP SIDE):SFC 407	TATA spare parts
253450500134	ASSY FANSHROUD	TATA spare parts
253450500135	ASSY FAN SHROUD	TATA spare parts
253450500136	FAN SHROUD ASSY BS6	TATA spare parts
253450500137	FAN SHROUD ASSY BS6	TATA spare parts
253450500138	FAN SHROUD ASSY BS6	TATA spare parts
253450500139	FAN SHROUD BS6	TATA spare parts

253450500143	FAN SHROUD ASSY BS6-PH2	TATA spare parts
253450500144	FAN SHROUD ASSY BS6	TATA spare parts
253450500146	FAN SHROUD ASSY BS6-PH2	TATA spare parts
253450500149	FAN SHROUD ASSY BS6-PH2	TATA spare parts
253450500150	FAN SHROUD ASSY BS6-PH2	TATA spare parts
253450500158	FAN SHROUD BS6-PH2	TATA spare parts
253450506301	PLASTIC FAN SHROUD	TATA spare parts
253450506303	FAN SHROUD	TATA spare parts
253450506314	FAN SHROUD	TATA spare parts
253450506320	FAN SHROUD-470 DIA FAN	TATA spare parts
253450506326	FAN SHROUD SFC BS-III (FOR 470 DIA. FAN)	TATA spare parts
253450506345	FAN SHROUD BS6	TATA spare parts
253450507701	INSULATION FOR FANSHROUD BS6	TATA spare parts
253450507712	INSULATION FAN SHROUD BS6	TATA spare parts
253454209901	EGR CONTROLLER	TATA spare parts
253454209902	ECU- 30 KVA	TATA spare parts
253454209903	ECU 4SP 25 KVA	TATA spare parts
253454209904	ECU 35 KVA	TATA spare parts
253454209906	ELECTRONIC TEMPERATURE GAUGE	TATA spare parts
2534N1990101	KIT ENG OVERHAUL GASKETS	TATA spare parts
2534N1990102	DECARB KIT W/OCYL H.GASKT	TATA spare parts
2534N3990113	M.B.SET STD 5+5PCS ONLY	TATA spare parts
2534N3990115	M.B.SET R/SI 5+5PCS ONLY	TATA spare parts
253614170101	TURBO CHARGER	TATA spare parts
253614610105	TURBO CHARGER	TATA spare parts
253614710101	TURBO CHARGER	TATA spare parts
253614710106	ASSY.TURBOCHARGER K27 BACKWARD VANE	TATA spare parts
253720000001	HANDLE - FRONT	TATA spare parts
254001177103	FLANGE	TATA spare parts
254003137101	FLANGE	TATA spare parts
254007100110	WATER SEPERATOR	TATA spare parts
254010160001	FRP DASHBOARD	TATA spare parts
254010170001	DASHBOARD ASSEMBLY	TATA spare parts
254010190001	GLOW BOX	TATA spare parts
254010200001	LID FOR GLOW BOX	TATA spare parts
254010440001	FRP DASHBOARD ZEAL BSVI (LP 7T 8T 4T) BS	TATA spare parts
254010470001	FRP DASHBOARD ZEAL 2340 BSVI STAFF BS6	TATA spare parts
254014110103	EXHAUST MANIFOLD	TATA spare parts
254015100101	ALTERNATOR 24V	TATA spare parts
254015100109	STARTER MOTOR 24 VOLT	TATA spare parts
254015400101	CLAMP ROD ASSY	TATA spare parts
254015400102	STARTER MOTOR 12V	TATA spare parts
254015400107	ALTERNATOR 24V	TATA spare parts
254015400108	ALTERNATOR 24V 35 AMPS SINGLE GROOVE	TATA spare parts
254015400109	ALTERNATOR 24V 35 AMPS	TATA spare parts
254015400110	ALTERNATOR 24V 35 AMPS SINGLE GROOVE	TATA spare parts
254015404201	CLAMPING PIECE	TATA spare parts

254015409906	REGULATOR 12V	TATA spare parts
254015409914	BALL&BEARING	TATA spare parts
254015409924	OVALHEADSCREW BS6	TATA spare parts
254018001001	HAND PUMP	TATA spare parts
254018135302	GASKET	TATA spare parts
254020110103	ASSY SEA WATER PUMP	TATA spare parts
254020130102	HEAT EXCHANGER	TATA spare parts
254020130108	PIPE ASSY	TATA spare parts
254020135306	GASKET	TATA spare parts
254020135307	GASKET	TATA spare parts
254025103701	FLYWHEEL HOUSING CAST	TATA spare parts
254025103703	FLYWHEEL HSG MARINE	TATA spare parts
254025103704	FLY WHEEL HSG	TATA spare parts
254026030003	GEAR BOX 4.81RATIO MARINE	TATA spare parts
254054204601	KIT SPEEDOCABLE COUPLER	TATA spare parts
254054207103	INSTRUMENT PANEL	TATA spare parts
254054209914	AMMETER	TATA spare parts
254054209916	WATER TEMP GAUGE	TATA spare parts
254107100102	F I PUMP RSV W/LEVER 697	TATA spare parts
254120125801	RUBBER HOSE	TATA spare parts
254120125802	RUBBER HOUSE	TATA spare parts
254120135802	RUBBER HOSE	TATA spare parts
254700000149	ASSY. ENG. 4X4 W AC P/S HD AUSTRALIA RHD	TATA spare parts
254700000156	GEN. ASSY. ENG COMP	TATA spare parts
254700000160	ASSY. ENGINE 4X2 HD ITALY	TATA spare parts
254700000164	GEN. ASSY. ENGINE COMPLETE	TATA spare parts
254700000165	ASSY ENG. 4DLTC 4X4 LHD HD PS FIP 0.71EI	TATA spare parts
254700000275	ENG 4DLT 4X4 LHD HDPS EURO-III	TATA spare parts
254700000282	ASSY ENGINE 4DLTC 4X4 AC SPAIN EURO III	TATA spare parts
254700000288	ASSY ENG.4X4 FACELIFT AC HDPS EURO III	TATA spare parts
254700000342	ENG 4DLT WITH CLUTCH.4X4 AC PS HD_ EURO I	TATA spare parts
254700000343	ASSY 4DL TCIC ENGINE COMPLETE WITH CLUTC	TATA spare parts
254700000344	ASSY. ENGINE COMPLETE 4DLTC (MINIBUS)	TATA spare parts
254700000346	ASSY ENG. COMPLETE 4DLNA MINI BUS BS-III	TATA spare parts
254700000348	ASSY ENG. COMPLETE 4DLNA MINI BUS BS-II	TATA spare parts
254700000353	ASSY. ENGINE COMPLETE 4DLTC (MINIBUS)	TATA spare parts
254700000365	ENGINE 4DL TC BSIII AMB STRETCH WINGER	TATA spare parts
254700000367	ENG 4DL TC BS III DUAL AC MINI BUS - WI	TATA spare parts
254700000369	ASSY ENGINE COMPLETE	TATA spare parts
254700000372	4DL TC BSIII ENG W/O AC & HD FOR TM	TATA spare parts
254700000373	ENGINE COMPLETE-TCIC BS-IV WINGER	TATA spare parts
254700990101	KIT ENG OVERHAUL GASKETS	TATA spare parts
254700990102	KIT DECARBONISING GASKETS NLS ALT 0102RZ	TATA spare parts
254700990105	KIT ENG OVERHAUL GASKETS	TATA spare parts
254700990106	KIT ENGINE OVERHAUL SEALS	TATA spare parts
254700990106N	KIT ENGINE OVERHAUL SEALS	TATA spare parts
254700990110	ENGINE OVERHAUL GASKET KIT	TATA spare parts



254700990110N	ENGINE OVERHAUL GASKET KIT	TATA spare parts
254700990111	KIT DECARB GASKETS TC	TATA spare parts
254700990114	ENG.OVERHAUL GASKET KIT (EURO-III)	TATA spare parts
254700990115	ENG.OVERHAUL GASKET KIT (EURO-II)	TATA spare parts
254700990116	DECARB. GASKET KIT- (EURO-II)	TATA spare parts
254700990117	DECARB. GASKET KIT- WITH MLS (EURO-III)	TATA spare parts
254700990118	OVERHAUL GASKET KIT W/O CYL HEAD GASKET	TATA spare parts
254700990121	DECARB. GASKET KIT- W/O CYL HEAD GASKET	TATA spare parts
254700990122	DECARB.GASKET KIT-W/O CYL HEAD GASKET-NA	TATA spare parts
254700990123	OVERHAUL GASKET KIT- W/O CYL HEAD GASKET	TATA spare parts
254700990124	OVERHAUL GASKET KIT W/O CYL HEAD GASKET	TATA spare parts
254701000120	HALF ENG W/O PS AC	TATA spare parts
254701000121	HALF ENG W/PS & AC	TATA spare parts
254701000127	SPD ENGINE WITH PS AND AC	TATA spare parts
254701000129	ENG 4DLNA W/O PS & AC	TATA spare parts
254701000149	BARE ENGINE 4 DL NA	TATA spare parts
254701000218	ASSY. ENG. 4X4 W AC P/S HD AUSTRALIA RHD	TATA spare parts
254701000228	ASSY. ENGINE 4X2 HD ITALY	TATA spare parts
254701000232	ASSY. ENGINE EURO 2 TC AC HD PS	TATA spare parts
254701000233	ASSY ENG. 4DLTC 4X4 LHD HD PS FIP 0.71	TATA spare parts
254701000343	ENG 4DLT 4X4 LHD HDPS EURO-III LUCAS FIP	TATA spare parts
254701000346	ENGINE 4DLT 4X4 ENG.RHD PS HD EURO III	TATA spare parts
254701000350	ASSY ENGINE 4DLTC 4X4 AC SPAIN EURO III	TATA spare parts
254701000356	ASSY ENG.4X4 FACELIFT AC HDPS EURO III	TATA spare parts
254701000363	4DLT ENGINE WITH CLUTCH.4X4 AC PS HD.	TATA spare parts
254701000371	ENGINE SUMO DX W TC BLOCK AC P/S FOR G76	TATA spare parts
254701000387	ENGINE WITH T/C BLOCK T/MOBILE	TATA spare parts
254701001905	4DLT ENG. WITH CLUTCH.4X4 AC PS HD.	TATA spare parts
254701100102	SPACER ASSY	TATA spare parts
254701100120	CYL.BLOCK W/O CL HSG.	TATA spare parts
254701100121	CYL.BLOCK NA	TATA spare parts
254701100172	CYL.BLOCK W/O CL.HSG.SAFARI	TATA spare parts
254701100175	ASSY CRANK CASE W/O CL HSG.	TATA spare parts
254701100176	ASSY CYL. BLOCK BARE 4DLTC (NON A/C)	TATA spare parts
254701100177	ASSY.CYL.CRANKCASE W/O CL.HSG.(A/C)	TATA spare parts
254701100196	CYL.CRANKCASE nls 0226	TATA spare parts
254701100217	ASSY.CYL.CRANKCASE W/O CL.HSG.	TATA spare parts
254701100235	ASSY.CYL.CRANKCASE W/O CL.HSG.	TATA spare parts
254701100243	ASSY.CYL.CRANKCASE W/O CL.HSG.	TATA spare parts
254701100249	ASSY.CYL.CRANKCASE W/O CL.HSG.	TATA spare parts
254701100289	ASSY.CYL.CRANKCASE W/O CL.HSG.	TATA spare parts
254701100292	ASSY.CYL.CC (NONLINERED)W/OCL.HSG.(INT)	TATA spare parts
254701100294	ASSY.CYL.CRANKCASE (NONLINERED) W/O CLH	TATA spare parts
254701100299	ASSY.CYL.CRANKCASE (NONLINERED) W/O CL.H	TATA spare parts
254701103201	BANJO BOLT	TATA spare parts
254701103202	HEX BOLT M B CAP	TATA spare parts
254701103713	CYLINDER LINER (COLLARED)	TATA spare parts

254701103717	LINER CYLINDER	TATA spare parts
254701103726	LINER	TATA spare parts
254701103740	CYLINDER LINER	TATA spare parts
254701105302	GASKET FRONT COVER	TATA spare parts
254701105303	GASKET BREATHER	TATA spare parts
254701105304	GASKET-OIL FILTER ADAPTOR TO CRANKCASE	TATA spare parts
254701105306	GASKET FRONT COVER	TATA spare parts
254701105307	GASKET COVER TO C.R.CASE	TATA spare parts
254701105308	GASKET (COVER TO CRANKCASE)	TATA spare parts
254701105309	GASKET(FILT.COVER TO CRANKCASE)	TATA spare parts
254701105311	GASKET(OIL FIL.COVER TO BLOCK)	TATA spare parts
254701106701	PIN	TATA spare parts
254701106702	GROOVED PIN	TATA spare parts
254701106703	PIN	TATA spare parts
254701106905	TUBE ON CRANKCASE	TATA spare parts
254701106906	TUBE TC OIL RETURN	TATA spare parts
254701107701	SIDE SEAL M.B.CAP-REAR	TATA spare parts
254701107702	SIDE SEAL 5TH MB CAP	TATA spare parts
254701107703	SIDE SEAL	TATA spare parts
254701107804	PTFE SEAL [CRANKSHAFT REAR]	TATA spare parts
254701107806	OIL SEAL CRANKSHAFT FRONT	TATA spare parts
254701107807	OIL SEAL CRANKSHAFT FRONT	TATA spare parts
254701107808	OIL SEAL - CRANKSHAFT (REAR)	TATA spare parts
254701107809	OIL SEAL CRANKSHAFT FRONT	TATA spare parts
254701107810	OIL SEAL CRANKSHAFT FRONT	TATA spare parts
254701107811	OIL SEAL CRANKSHAFT REAR	TATA spare parts
254701107812	OIL SEAL (CRANKSHAFT - FRONT)	TATA spare parts
254701107813	OIL SEAL (CRANKSHAFT - REAR)	TATA spare parts
254701107814	OIL SEAL CRANKSHAFT FRONT	TATA spare parts
254701107817	OIL SEAL CRANKSHAFT FRONT	TATA spare parts
254701107818	OIL SEAL - CRANKSHAFT (REAR)	TATA spare parts
254701107820	OIL SEAL	TATA spare parts
254701107821	OIL SEAL CRANKSHAFT FRONT	TATA spare parts
254701107822	PTFE SEAL (CRANKSHAFT REAR)	TATA spare parts
254701107823	PTFE SEAL (CRANKSHAFT FRONT) (FENNER)	TATA spare parts
254701107824	PTFE SEAL (CRANKSHAFT REAR)	TATA spare parts
254701107825	SEAL (CRANKSHAFT FRONT)	TATA spare parts
254701108203	CORE PLUG [ 32 DIA.]	TATA spare parts
254701108204	CORE PLUG 27D	TATA spare parts
254701108205	CORE PLUG [ 20 DIA.]	TATA spare parts
254701108207	CORE PLUG (32.5 DIA.)	TATA spare parts
254701108208	CORE PLUG (27.5 DIA.)	TATA spare parts
254701108210	CORE PLUG (20.5 DIA)	TATA spare parts
254701108801	STUD CAMSHAFT CAP	TATA spare parts
254701109901	ADAPTER OIL FILTER	TATA spare parts
254701109902	ADAPTER OIL FILTER	TATA spare parts
254701109903	ADAPTER OIL FILTER	TATA spare parts

254701130118	OIL SUMP ASSY	TATA spare parts
254701130126	OIL SUMP ASSY	TATA spare parts
254701130139	OIL SUMP ASSY	TATA spare parts
254701130140	OIL SUMP ASSY	TATA spare parts
254701133802	LADDER FRAME	TATA spare parts
254701133805	LADDER FRAME 4DL NA	TATA spare parts
254701135302	GASKET LADDER FRAME	TATA spare parts
254701135303	OIL SUMP GASKET	TATA spare parts
254701135304	GASKET OIL SUMP NLS CORK	TATA spare parts
254701135307	GASKET OIL SUMP TC	TATA spare parts
254701135309	OIL SUMP GASKET NA 1.00 THK	TATA spare parts
254701135310	OIL SUMP GASKET (1 THK.)	TATA spare parts
254701135320	OIL SUMP GASKET (1 THK.)	TATA spare parts
254701135322	OIL SUMP GASKET (1 THK.)	TATA spare parts
254701135323	OIL SUMP GASKET (1 THK.)	TATA spare parts
254701138203	WASHER	TATA spare parts
254701138204	STIFFENER OIL SUMP RR RH	TATA spare parts
254701138205	STIFFENER OIL SUMP FRT RH	TATA spare parts
254701138211	STIFFENER - FRONT	TATA spare parts
254701138212	STIFFENER - LEFT	TATA spare parts
254701138213	STIFFENER - RIGHT	TATA spare parts
254701138214	STIFFENER - REAR	TATA spare parts
254701139201	SEAL WASHER OS DRAIN PLUG	TATA spare parts
254701140105	COVER BACK TIMING GEAR	TATA spare parts
254701140108	COVER BACK TIMING GEAR	TATA spare parts
254701140109	ASSY. BRACKET	TATA spare parts
254701140110	BRACKET ASSY	TATA spare parts
254701143801	FRONT COVER CRANKCASE	TATA spare parts
254701144201	TOGGLE CLAMP	TATA spare parts
254701144202	CLAMP COVER FRONT	TATA spare parts
254701146701	CYLINDRICAL PIN (FRONT COVER TO BLOCK)	TATA spare parts
254701147501	GROMMET	TATA spare parts
254701147502	GROMMET FR COVER TIM GEAR	TATA spare parts
254701147503	GROMMET FR COVER TIM GEAR	TATA spare parts
254701147713	TIMING GEAR COVER NLS FRT RH	TATA spare parts
254701147714	FRONT COVER (LEFT) (TIMING GEAR)	TATA spare parts
254701147715	TIMING GEAR COVER FRT LOW	TATA spare parts
254701147722	TIMING GEAR COVER FRT RH	TATA spare parts
254701147723	TIMING GEAR COVER FRT LH	TATA spare parts
254701148208	SUPPORT TOGGLE CLAMP	TATA spare parts
254701150111	COVER CYLINDER HEAD	TATA spare parts
254701150114	PRE COMBUSTION CHAMBER NA	TATA spare parts
254701150123	ASSY CAP CYLINDER HEAD COVER	TATA spare parts
254701150128	SEALING WASHER	TATA spare parts
254701150129	CYL. HEAD WITH VALVES 4DL TC	TATA spare parts
254701150130	CYL. HEAD W/O VALVES 4DL TC	TATA spare parts
254701150131	COVER CYLINDER HEAD	TATA spare parts

254701150134	COVER CYL HEAD W/TUBE	TATA spare parts
254701150135	PRE COMBUSTION CHAMBER TC	TATA spare parts
254701150136	ASSY CAP (ON CYL. HEAD COVER)	TATA spare parts
254701150138	CYL. HEAD W/O VALVES 4DLNA	TATA spare parts
254701150139	CYL. HEAD With VALVES 4DLNA	TATA spare parts
254701150139_NIU	CYL. HEAD With VALVES 4DLNA	TATA spare parts
254701150147	ASSY. CYL. HEAD COVER	TATA spare parts
254701150177	BUFFLE PALTE	TATA spare parts
254701150199	ASSY. CORE PLUG WITH TUBE (27.5 DIA.)	TATA spare parts
254701150207	ASSY. CYLINDER HEAD W/O VALVES BS3/4	TATA spare parts
254701150215	ASSY.CYL.HEAD W/O VALVES	TATA spare parts
254701150222	ASSY.CYL.HEAD W/O VALVES	TATA spare parts
254701150228	ASSY.CYL.HEAD W/VALVE INJ .EURO III	TATA spare parts
254701150237	ASSY. CYL. HEAD W/VALVES 4DL NA BS2/3	TATA spare parts
254701150252	ASSY.CYL.HEAD WITH VALVE	TATA spare parts
254701150253	ASSY. CYLINDER HEAD COVER WITH TUBE	TATA spare parts
254701153402	VALVE SEAT INSERT EX STD	TATA spare parts
254701153403	VALVE SEAT INSERT EX STD1	TATA spare parts
254701153414	VALVE SEAT INSERT IN STD	TATA spare parts
254701153415	VALVE SEAT INSERT IN STD1	TATA spare parts
254701153417	VALVE SEAT RING IN STD TC	TATA spare parts
254701153420	VALVE SEAT RING EX STD TC	TATA spare parts
254701154801	HOLLOW DOWEL CYL HD	TATA spare parts
254701154802	HOLLOW DOWEL-CYL.HEAD TO CAMSHAFT CAP	TATA spare parts
254701155303	GASKET CYL HEAD 1.6MM	TATA spare parts
254701155304	GASKET NLS CYL HEAD 1.7MM	TATA spare parts
254701155309	CYLINDER HEAD GASKET ( 1.6 THICK )	TATA spare parts
254701155312	GASKET CYL HEAD COVER	TATA spare parts
254701155313	GASKET CYL HEAD COVER	TATA spare parts
254701155321	GASKET CYL HEAD 1.5MM NLS (5321RZ)	TATA spare parts
254701155322	CYL. HEAD GASKET (1.6 THK.)	TATA spare parts
254701155322RZ	GASKET CYL HEAD 1.6M	TATA spare parts
254701155323	CYL. HEAD GASKET (1.7 THK.)	TATA spare parts
254701155323RZ	GASKET CYL HEAD 1.7MM	TATA spare parts
254701155324	GASKET (CYL.HEAD COVER)	TATA spare parts
254701155325	GASKET CAP CY/HD COVER TC	TATA spare parts
254701155326	CYL.HD.GASKET 1.6	TATA spare parts
254701155349	GASKET (CYL.HEAD COVER)	TATA spare parts
254701155355	GASKET-CYL.HEAD COVER	TATA spare parts
254701155361	CYL.HEAD GASKET-MLS (1.51 THK)	TATA spare parts
254701155362	CYL.HEAD GASKET-MLS (1.63 THK)	TATA spare parts
254701155369	CYL. HEAD GASKET-MLS(1.70 THK.) BS2/3/4	TATA spare parts
254701155812	HOSE TUBE TO BREATHER	TATA spare parts
254701156903	SPACER TUBE 74 MM LONG	TATA spare parts
254701156904	SPACER TUBE (94 MM LONG)	TATA spare parts
254701156906	SPACER TUBE(76 MM)	TATA spare parts
254701156907	SPACER TUBE(95 MM)	TATA spare parts

254701157702	RUBBER SEAL OIL CAP	TATA spare parts
254701157802	OIL SEAL-CAMSHAFT	TATA spare parts
254701157803	OIL SEAL CAMSHAFT REAR	TATA spare parts
254701157807	OIL SEAL CAM FRONT	TATA spare parts
254701157808	OIL SEAL CAMSHAFT FRONT	TATA spare parts
254701157809	OIL SEAL-CAMSHAFT	TATA spare parts
254701157812	OIL SEAL - CAMSHAFT	TATA spare parts
254701157814	OIL SEAL (CAMSHAFT) BS1/2/3/4/6	TATA spare parts
254701157817	PTFE SEAL (CAM SHAFT FRONT)	TATA spare parts
254701157818	PTFE SEAL-CAM SHAFT FRONT	TATA spare parts
254701158001	COLLAR SCREW M12X1.5X120	TATA spare parts
254701158805	STUD M6 X 100	TATA spare parts
254701158806	STUD M6 X 120	TATA spare parts
254701159201	SEALING WASHER	TATA spare parts
254701159203	WASHER CYL HEAD SCREW	TATA spare parts
254701159204	WASHER CYL HEAD COVER	TATA spare parts
254701159901	CAP OIL FILLER 4DL TC	TATA spare parts
254701159905	ADAPTER M8	TATA spare parts
254701159906	ADAPTOR (ON CYL. HEAD)	TATA spare parts
254701160103	INJ NOZZLE W/HOLDER	TATA spare parts
254701160105	INJ NOZZLE W/HOLDER	TATA spare parts
254701160106	INJ NOZZLE W/HOLDER	TATA spare parts
254701160107	INJ NOZZLE W/HOLDER	TATA spare parts
254701160111	ASSY. NOZZLE	TATA spare parts
254701168401	FLAME GUARD	TATA spare parts
254701169201	WASHER INJECTOR NOZZLE	TATA spare parts
254701169202	WASHER FLAME GUARD	TATA spare parts
254701169203	WASHER-FLAME GUARD	TATA spare parts
254701169204	WASHER-FLAME GUARD	TATA spare parts
254701170108	TUBE DIPSTICK	TATA spare parts
254701170119	BREATHER	TATA spare parts
254701170121	DIPSTICK	TATA spare parts
254701170130	ASSY. OIL SEPARATOR	TATA spare parts
254701170132	DIPSTICK	TATA spare parts
254701170133	ASSY. OIL SEPARATOR BS1/2/3/4	TATA spare parts
254701170133AE	ASSY OIL SEPARATOR-XEN DC-XEN SC	TATA spare parts
254701170135	ASSY. OIL SEPARATOR	TATA spare parts
254701170136	TUBE CRANK CASE	TATA spare parts
254701170137	ADAPTER OIL SEPERATOR	TATA spare parts
254701170138	TUBE DIPSTICK 4DLTC	TATA spare parts
254701170143	BKT OIL SEPERATOR MTG	TATA spare parts
254701170145	DIPSTICK	TATA spare parts
254701170146	TUBE DIPSTICK	TATA spare parts
254701170149	DIPSTICK ASSY	TATA spare parts
254701170152	SPIDER HOSE ASSY.	TATA spare parts
254701170156	ASSY HOSE	TATA spare parts
254701170159	ASSY SPIDER HOSE	TATA spare parts

254701170163	ASSY TUBE	TATA spare parts
254701170164	ASSY. SPIDER HOSE (OIL SEP)	TATA spare parts
254701170166	A SPIDER HOSE EXNA	TATA spare parts
254701170170	ASSY SPIDER HOSE FOR TC WITH AC	TATA spare parts
254701170180	ASSY. DIPSTICK (BLUE BAND HANDLE)	TATA spare parts
254701170185	ASSY.DIPSTICK TUBE (EURO-III)	TATA spare parts
254701170186	ASSY.DIPSTICK (4X4-ORANGE HANDLE BAND)	TATA spare parts
254701170187	ASSY.DIPSTICK (4X2-BLUE HANDLE BAND)	TATA spare parts
254701173307	BKT OIL SEPERATOR MTG	TATA spare parts
254701173308	BKT OIL SEPRTOR MTG	TATA spare parts
254701173312	BRACKET (FOR OIL SEPARATOR & EGR COOLER	TATA spare parts
254701173802	ELBOW CRANKCASE BLOWBY	TATA spare parts
254701174209	HOSE CLAMP ( 38 DIA.) BS4	TATA spare parts
254701174210	HOSE CLAMP- 38 DIA.	TATA spare parts
254701174211	HOSE CLAMP- 26 DIA.	TATA spare parts
254701174212	HOSE CLAMP (18 DIA.)	TATA spare parts
254701174213	DIPSTICK TUBE CLAMP	TATA spare parts
254701175301	GASKET	TATA spare parts
254701175302	GASKET ELBOW BLOWBY	TATA spare parts
254701175303	GASKET ELBOW	TATA spare parts
254701175805	HOSE BREATH-SAFETY VALVE	TATA spare parts
254701175813	HOSE BREATH-SAFETY VALVE	TATA spare parts
254701175825	HOSE O.SEP TO Y CON SUMO	TATA spare parts
254701175826	HOSE OIL SEP TO ADAPTOR	TATA spare parts
254701175827	HOSE	TATA spare parts
254701175828	HOSE OIL SEP TO CYL BLOCK	TATA spare parts
254701175829	HOSE	TATA spare parts
254701175837	HOSE BREAHT TO O/SEPERATOR	TATA spare parts
254701175839	RUBBER HOSE (SEPARATOR TO CRANKCASE)	TATA spare parts
254701175841	HOSE SEPARATOR-AIR FILTER	TATA spare parts
254701175849	RUBBER HOSE (SEPARATOR TO BLOCK)	TATA spare parts
254701175851	HOSE OIL SEP TO HOSE	TATA spare parts
254701175866	RUBBER HOSE (SEPARATOR TO BLOCK)	TATA spare parts
254701175867	HOSE REDUCER TO OIL SEP	TATA spare parts
254701175869	HOSE ELBOW TO REDUCER	TATA spare parts
254701175872	HOSE CYL HD COVER-REDUCER	TATA spare parts
254701175875	HOSE REDUCER-OIL SEPARATO	TATA spare parts
254701175880	HOSE OIL SEP TO AIR INLET	TATA spare parts
254701176301	REDUCER OIL SEPARATOR	TATA spare parts
254701176912	T CONNECTOR	TATA spare parts
254701179901	ADAPTER DIPSTICK TUBE	TATA spare parts
254701179902	COUPLING NUT	TATA spare parts
254701195824	RUBBER HOSE (SEPARATOR TO BLOCK)	TATA spare parts
254701195825	RUBBER HOSE-440 (SEPERATOR TO CRANKCASE)	TATA spare parts
254701195827	RUBBER HOSE {SEP.TO AIR INLET HOSE}	TATA spare parts
254701195830	HOSE (SEP. TO MANIFOLD)	TATA spare parts
254701195831	HOSE OIL SEP. TO MANI. EX	TATA spare parts

254701195832	RUBBER HOSE (OIL SEP. TO AIR INLET)	TATA spare parts
254701990123	ASSY. HALF BLOCK- T.C.	TATA spare parts
254701990124	HALF BLOCK (4X2 TC ENG. NON A/C)	TATA spare parts
254701990134	HALF ENG 4X4TC AC	TATA spare parts
254701990142	ENGINE BARE	TATA spare parts
254701990148	BARE ENGINE 4DLTC 4X4 BSIII SAFARI	TATA spare parts
254701990149	HALF BLOCK (4DL TC 4X4)	TATA spare parts
254701990155	ENGINE (W/O ST. MOT. CL. HSG.& TC)	TATA spare parts
254701990160	ENGINE W/AC COMP PS HT TC	TATA spare parts
254701990161	SPD ENGINE (W/O CL. HSG. ST. MOT. & TC)	TATA spare parts
254701990191	SET ASSY.FRONT COVER WITH GROMMETS	TATA spare parts
254701990211	HALF BLOCK 4X4 EURO III HD	TATA spare parts
254701990215	HALF BLOCK	TATA spare parts
254701990341	BARE ENGINE	TATA spare parts
254701990342	ASSY. LONG BLOCK 483DL BS3/4	TATA spare parts
254701990343	HALF BLOCK	TATA spare parts
254701990344	HALF BLOCK	TATA spare parts
254701990348	ASSY ENG COMPLETE W/O ST MOTOR	TATA spare parts
254701990348_niu11	ASSY ENG COMPLETE W/O ST MOTOR	TATA spare parts
254701990354	BARE ENGINE	TATA spare parts
254701990355	HALF BLOCK	TATA spare parts
254701990356	ENGINE TATA WINGER EMRI	TATA spare parts
254701990358	ASSY. ENGINE SUMO JAMMER	TATA spare parts
254703100117	CRANKSHAFT	TATA spare parts
254703100129	ASSY. CRANKSHAFT + CY. PIN (NORMAL)	TATA spare parts
254703100135	ASSY.CRANKSHAFT (NORMAL) WITH PIN	TATA spare parts
254703103102	D.G.BALL BRG.	TATA spare parts
254703103103	D.G.BALL BRG.	TATA spare parts
254703103104	D.G.BALL BRG.	TATA spare parts
254703103105	D.G.BALL BRG.	TATA spare parts
254703103106	D.G.BALL BRG.	TATA spare parts
254703103107	D.G.BALL BRG.	TATA spare parts
254703105901	KEY	TATA spare parts
254703107917	CRANKSHAFT STD 4DL TC	TATA spare parts
254703107922	CRANKSHAFT STD	TATA spare parts
254703108602	SPACER VIBRATION DAMPER	TATA spare parts
254703108603	SPACER (VIB. DAMPER) (40 DIAX19)	TATA spare parts
254703108901	SPROCKET ON CRANKSHAFT	TATA spare parts
254703108906	SPROCKET ON CRANKSHAFT	TATA spare parts
254703108907	SPROCKET WITH OIL THROWER	TATA spare parts
254703110103	FLYWHEEL W/RING GEAR	TATA spare parts
254703110106	ASSY.FLYWHEEL WITH RING GEAR(INCREA.INER	TATA spare parts
254703110109	ASSY FLYWHEEL WITH RING GEAR	TATA spare parts
254703110111	ASSY FLYWHEEL WITH RING GEAR	TATA spare parts
254703114902	FLY WHEEL	TATA spare parts
254703115401	RING GEAR	TATA spare parts
254703116101	LOCKING PLATE	TATA spare parts

254703116102	LOCKING PLATE	TATA spare parts
254703120106	SET THRUST WASHER (2.52)	TATA spare parts
254703120107	SET THRUST WASHER (2.57)	TATA spare parts
254703120108	SET THRUST WASHER 2.62MM	TATA spare parts
254703120109	SET THRUST WASHER (2.67)	TATA spare parts
254703120110	SET THRUST WASHER (2.72)	TATA spare parts
254703120111	SET M.B.SHELL - NORMAL	TATA spare parts
254703123101	MAIN BRG. LOWER (NORMAL)	TATA spare parts
254703123103	MAIN BRG.(UPPER) (NORMAL)	TATA spare parts
254703123408	THRUST WASHER LOW 2.52MM	TATA spare parts
254703123420	SET THRUST WASHER 2.57MM	TATA spare parts
254703123426	MAIN BRG SHELL RS1 UPP	TATA spare parts
254703123428	MAIN BRG SHELL RS1 LWR	TATA spare parts
254703123454	SET THRUST WASHER 2.52MM	TATA spare parts
254703123456	SET THRUST WASHER 2.62MM	TATA spare parts
254703123462	THRUST WASHER LOW 2.52MM	TATA spare parts
254703123468	THRUST WASHER UPPER 2.52MM	TATA spare parts
254703123474	SET MAIN BRG W/O THW STD	TATA spare parts
254703123477	MAIN BRG N1 UPPER	TATA spare parts
254703123479	SET MAIN BRG W/O THW STD	TATA spare parts
254703123481	SET THRUST WASHER 2.52MM	TATA spare parts
254703123482	SET THRUST WASHER 2.57MM	TATA spare parts
254703129205	THRUST WASHER (LOWER) - 2.52	TATA spare parts
254703129210	THRUST WASHER (UPPER) - 2.52	TATA spare parts
254703130113	VIBRATION DAMPER	TATA spare parts
254703130114	VIBRATION DAMPER 6GR	TATA spare parts
254703130115	VIBRATION DAMPER 4GR	TATA spare parts
254703130116	VIBRATION DAMPER 6GR	TATA spare parts
254703130123	ASSY.VIBRATION DAMPER(4 GR.)	TATA spare parts
254703130124	ASSY.VIBRATION DAMPER(6PK+6PK)	TATA spare parts
254703130126	ASSY.VIBRATION DAMPER(6PK+6PK)	TATA spare parts
254703130127	ASSY.VIBRATION DAMPER(6PK+6PK)	TATA spare parts
254703130129	ASSY VIBRATION DAMPER (6+4 GROOVES)	TATA spare parts
254703130130	ASSY VIB. DAMPER (6+4 GR.)	TATA spare parts
254703130131	ASSY VIB. DAMPER(6+4PK)	TATA spare parts
254703130132	ASSY VIB. DAMPER (6PK)	TATA spare parts
254703133201	HEX.FLANGE BOLT M 14X1.5-70	TATA spare parts
254703133203	BOLT (ON CRANKSHAFT)	TATA spare parts
254703140142	OIL RING GR.III R/S1 NLS	TATA spare parts
254703140155	RING OIL STD	TATA spare parts
254703140160	SET PISTON RINGS RS1	TATA spare parts
254703140277	SET PISTON NA STD GR A ESCORTS	TATA spare parts
254703140394	ASSY OIL RING	TATA spare parts
254703143202	CIRCLIP 4DLNA	TATA spare parts
254703144303	CIRCLIP	TATA spare parts
254703144304	CIRCLIP 4DLTC	TATA spare parts
254703146636	PISTON BARE RS2	TATA spare parts



254703146646	PISTON BARESTDC	TATA spare parts
254703146656	PISTON STD 4DLTC	TATA spare parts
254703146666	PISTON GR-B-TC-ESCORTS	TATA spare parts
254703146671	BARE PISTON GR-A	TATA spare parts
254703146704	PISTON PIN FOR 4DLNA	TATA spare parts
254703146707	PIN PISTON TC	TATA spare parts
254703146712	GUDGEON PIN	TATA spare parts
254703149812	RING TOP MOLYCOATED TC	TATA spare parts
254703149813	SECOND RING	TATA spare parts
254703149825	MOLYCOATED TOP RING 4DLTC	TATA spare parts
254703149845	TOP COMPRESSION RING	TATA spare parts
254703149846	SECOND COMPRESSION RING	TATA spare parts
254703149910	COMPR RING GR-1 STD	TATA spare parts
254703149914	COMPR RING GR-2 R/SI	TATA spare parts
254703149917	RING OIL RS1	TATA spare parts
254703149925	MOLY PLATED COMPRESSION RING	TATA spare parts
254703149976	TOP RING STD 207	TATA spare parts
254703149985	II RING STD 207	TATA spare parts
254703150103	CONNECTING ROD	TATA spare parts
254703150111	CONNECTING ROD	TATA spare parts
254703153201	BOLT CONNECTING ROD	TATA spare parts
254703153402	BUSH CON ROD STD	TATA spare parts
254703153403	BUSH CON ROD STD1	TATA spare parts
254703153411	BUSH CON ROD STD	TATA spare parts
254703153417	BUSH CON ROD STD	TATA spare parts
254703153422	BUSH CON ROD STD	TATA spare parts
254703153435	BUSH CONROD STD TC	TATA spare parts
254703153442	CON ROD BUSH	TATA spare parts
254703153443	BUSH CON ROD STD	TATA spare parts
254703153444	BUSH CON ROD STD	TATA spare parts
254703153447	BEARING HALF CON ROD	TATA spare parts
254703153449	BUSH - CON ROD STD TC	TATA spare parts
254703153451	BEARING HALF CON ROD	TATA spare parts
254703153457	BUSH CON ROD STD	TATA spare parts
254703156501	NUT CONNECTING ROD	TATA spare parts
254703156502	FLANGE NUT(CON. ROD)	TATA spare parts
254703166655	PISTON (GRADE A)	TATA spare parts
254703990103	SETMAIN BRG W/THW NLS	TATA spare parts
254703990105	SET CON ROD BRG STD	TATA spare parts
254703990107	SET CON ROD BRG RS1	TATA spare parts
254703990108	SET CON ROD BRG RS2	TATA spare parts
254703990120	SET CON.ROD BRG.HALF NORMAL	TATA spare parts
254703990125	SET M.B.SHELL (UPPER /LOWER) - REP-I	TATA spare parts
254703990126	SET M.B.SHELL (UPP./LOWER) REP-II	TATA spare parts
254703990151	SET PISTON BARE TC GR-A	TATA spare parts
254703990152	SET PISTON TC STD GR-B	TATA spare parts
254703990153	SET PISTON TC GR-C	TATA spare parts

254703990157	SET-PISTON RING STD 4DL TCIC BS2/3/4	TATA spare parts
254703990158	SET CON ROD BRG 4DL TC	TATA spare parts
254703990172	SET CON.ROD BRG.SHELL HALF REP I	TATA spare parts
254703990173	SET CON.ROD BRG.SHELL HALF REPII	TATA spare parts
254703990176	SET PISTON RINGS	TATA spare parts
254703990177	SET PISTON W/O RINGS GRADE A	TATA spare parts
254703990178	SET PISTON W/O RINGS GRADE B	TATA spare parts
254703990179	SET PISTON W/O RINGS GRADE C	TATA spare parts
254703990180	SET PISTON RINGS STD	TATA spare parts
254705105901	KEY	TATA spare parts
254705107918	CAMSHAFT STD 4DLNA	TATA spare parts
254705107933	CAMSHAFT STD 4DLTC	TATA spare parts
254705108601	SPACER	TATA spare parts
254705110110	GEAR CRANKSHAFT	TATA spare parts
254705110116	ASSY IDLER	TATA spare parts
254705110117	ASSY TIMING BELT TENSIONR	TATA spare parts
254705110119	ASSY.BRACKET COMPLETE (IDLER)	TATA spare parts
254705110120	TENSIONER TIMING BELT	TATA spare parts
254705110121	IDLER TIMING BELT	TATA spare parts
254705110122	GEAR CAMSHAFT	TATA spare parts
254705110123	GEAR CRANKSHAFT--NLS--5408	TATA spare parts
254705110126	ASSY.TIMING BELT TENSIONER,COMPLETE	TATA spare parts
254705110138	ASSY.TIMING BELT IDLER	TATA spare parts
254705110139	ASSY.TIMING BELT TENSIONER	TATA spare parts
254705110141	ASSY.BKT.(IDLER)	TATA spare parts
254705110142	ASSY.BRACKET-TENSIONER	TATA spare parts
254705110147	ASSY. TENSIONER	TATA spare parts
254705110148	ASSY. IDLER	TATA spare parts
254705113101	BEARING BALL DEEP GROOVE	TATA spare parts
254705113102	BEARING BALL DEEP GROOVE	TATA spare parts
254705113106	BALL BEARING	TATA spare parts
254705115407	GEAR CAMSHAFT	TATA spare parts
254705115408	GEAR CRANKSHAFT SINTERED	TATA spare parts
254705116301	TIMING BELT BS2/3/4	TATA spare parts
254705116301DF01	TIMING BELT -TATA ACE	TATA spare parts
254705116301DF02	TIMING BELT -TATA ACE	TATA spare parts
254705116302	TIMING BELT NLS	TATA spare parts
254705116303	TIMING BELT	TATA spare parts
254705116305	TIMING BELT NLS	TATA spare parts
254705116308	TIMING BELT	TATA spare parts
254705116310	TIMING BELT	TATA spare parts
254705116312	TIMING BELT	TATA spare parts
254705117002	ROLLER W/FLANGE	TATA spare parts
254705118201	FLANGE CAMSHAFT GEAR	TATA spare parts
254705118401	SPRING CUP	TATA spare parts
254705118603	SPACER CRANK GEAR	TATA spare parts
254705118604	SPACER	TATA spare parts

254705118605	SPACER	TATA spare parts
254705118701	SPRING BELT TENSIONER	TATA spare parts
254705118801	STUD BELT TENSIONER	TATA spare parts
254705119201	WASHER	TATA spare parts
254705124301	VALVE LOCK HALF	TATA spare parts
254705125101	RETAINER VALVE SPRING	TATA spare parts
254705125103	EXHAUST VALVE	TATA spare parts
254705125105	VALVE EXHAUST	TATA spare parts
254705125109	RETAINER VALVE SPRING	TATA spare parts
254705125112	EXHAUST VALVE	TATA spare parts
254705125113	EXHAUST VALVE	TATA spare parts
254705125114	INLET VALVE {}	TATA spare parts
254705125115	INLET VALVE (TUFFTRIDED)	TATA spare parts
254705125116	EXHAUST VALVE (TUFFTRIDED)	TATA spare parts
254705128203	SPRING SEAT	TATA spare parts
254705128701	VALVE SPRING OUTER	TATA spare parts
254705128702	VALVE SPRING INNER	TATA spare parts
254705128706	VALVE SPRING	TATA spare parts
254705129004	INLET VALVE	TATA spare parts
254705129006	INLET VALVE	TATA spare parts
254705138302	SHIM (2.425 THK.)	TATA spare parts
254705138303	SHIM TAPPET 2.500MM	TATA spare parts
254705138304	SHIM (2.575 THK.)	TATA spare parts
254705138305	SHIM TAPPET 2.650MM	TATA spare parts
254705138306	SHIM (2.725 THK.)	TATA spare parts
254705138307	SHIM TAPPET 2.800MM	TATA spare parts
254705138308	SHIM (2.875 THK.)	TATA spare parts
254705138309	SHIM TAPPET 2.950MM	TATA spare parts
254705138310	SHIM (3.025 THK.)	TATA spare parts
254705138311	SHIM TAPPET 3.100MM	TATA spare parts
254705138312	SHIM (3.175 THK.)	TATA spare parts
254705138313	SHIM TAPPET 3.250MM	TATA spare parts
254705138314	SHIM (3.325 THK.)	TATA spare parts
254705138315	SHIM TAPPET 3.400MM	TATA spare parts
254705138316	SHIM (3.475 THK.)	TATA spare parts
254705138317	SHIM TAPPET 3.550MM	TATA spare parts
254705138318	SHIM TAPPET 2.400MM	TATA spare parts
254705138319	SHIM TAPPET 2.450MM	TATA spare parts
254705138320	SHIM TAPPET 2.550MM	TATA spare parts
254705138321	SHIM TAPPET 2.600MM	TATA spare parts
254705138322	SHIM TAPPET 2.700MM	TATA spare parts
254705138323	SHIM TAPPET 2.750MM	TATA spare parts
254705138324	SHIM TAPPET 2.850MM	TATA spare parts
254705138325	SHIM TAPPET 2.900MM	TATA spare parts
254705138326	SHIM TAPPET 3.000MM	TATA spare parts
254705138327	SHIM TAPPET 3.050MM	TATA spare parts
254705138328	SHIM TAPPET 3.150MM	TATA spare parts

254705138329	SHIM TAPPET 3.200MM	TATA spare parts
254705138330	SHIM TAPPET 3.300MM	TATA spare parts
254705138331	SHIM TAPPET 3.350MM	TATA spare parts
254705138332	SHIM TAPPET 3.450MM	TATA spare parts
254705138333	SHIM TAPPET 3.500MM	TATA spare parts
254705138334	SHIM (2.42)	TATA spare parts
254705138335	SHIM (2.44)	TATA spare parts
254705138336	SHIM (2.46)	TATA spare parts
254705138337	SHIM (2.48)	TATA spare parts
254705138338	SHIM-2.52	TATA spare parts
254705138339	SHIM-2.54	TATA spare parts
254705138340	SHIM (2.56)	TATA spare parts
254705138341	SHIM (2.58)	TATA spare parts
254705138342	SHIM-2.62	TATA spare parts
254705138343	SHIM (2.64)	TATA spare parts
254705138344	SHIM-2.66	TATA spare parts
254705138345	SHIM-2.68	TATA spare parts
254705138346	SHIM (2.72)	TATA spare parts
254705138347	SHIM-2.74	TATA spare parts
254705138348	SHIM-2.76	TATA spare parts
254705138349	SHIM-2.78	TATA spare parts
254705138350	SHIM (2.82)	TATA spare parts
254705138351	SHIM (2.84)	TATA spare parts
254705138352	SHIM (2.86)	TATA spare parts
254705138353	SHIM-2.88	TATA spare parts
254705138354	SHIM-2.92	TATA spare parts
254705138355	SHIM-2.94	TATA spare parts
254705138356	SHIM (2.96)	TATA spare parts
254705138357	SHIM-2.98	TATA spare parts
254705138358	SHIM-3.02	TATA spare parts
254705138359	SHIM-3.04	TATA spare parts
254705138360	SHIM (3.06)	TATA spare parts
254705138361	SHIM (3.08)	TATA spare parts
254705138362	SHIM (3.12)	TATA spare parts
254705138363	SHIM (3.14)	TATA spare parts
254705138364	SHIM (3.16)	TATA spare parts
254705138365	SHIM (3.18)	TATA spare parts
254705138366	SHIM (3.22)	TATA spare parts
254705138367	SHIM (3.24)	TATA spare parts
254705138368	SHIM (3.26)	TATA spare parts
254705138369	SHIM (3.28)	TATA spare parts
254705138370	SHIM (3.32)	TATA spare parts
254705138371	SHIM (3.34)	TATA spare parts
254705138372	SHIM (3.36)	TATA spare parts
254705138373	SHIM (3.38)	TATA spare parts
254705138374	SHIM (3.42)	TATA spare parts
254705138375	SHIM (3.44)	TATA spare parts

254705138376	SHIM (3.46)	TATA spare parts
254705138378	SHIM (3.54)	TATA spare parts
254705138379	SHIM (3.56)	TATA spare parts
254705139902	TAPPET STD	TATA spare parts
254705139903	TAPPET STD I	TATA spare parts
254705153402	VALVE GUIDE STD	TATA spare parts
254705153411	VALVE GUIDE STD IN & EXH	TATA spare parts
254705153412	VALVE GUIDE STD1	TATA spare parts
254705153418	VALVE GUIDE ( NORMAL )	TATA spare parts
254705153418_niu2	VALVE GUIDE ( NORMAL )	TATA spare parts
254705157801	SEAL VALVE GUIDE	TATA spare parts
254705157802	SEAL VALVE GUIDE	TATA spare parts
254705157804	VALVE GUDE SEAL	TATA spare parts
254705159902	SEAL VALVE GUIDE	TATA spare parts
254705159908	SEAL VALVE GUIDE	TATA spare parts
254705990103	KIT ENGINE VALVE MNR 60PS	TATA spare parts
254705990106	KIT ENGINE VALVE MAJ 68PS	TATA spare parts
254707100109	F I PUMP	TATA spare parts
254707100114	BOOST LINE FIP SIDE	TATA spare parts
254707100116	F I PUMP W/KSB TC	TATA spare parts
254707100121	PIPE OVER FLOW	TATA spare parts
254707100122	BOOST AIR LINE	TATA spare parts
254707100126	ASSY. BOOST AIR LINE (COMPLETE)	TATA spare parts
254707100135	ASSY. DISTRIBUTOR PUMP-481	TATA spare parts
254707100137	ASSY. FIP EURO II	TATA spare parts
254707100138	ASSY.FUEL INJECTION PUMP-(EURO-III)	TATA spare parts
254707100140	ASSY.DISTRIBUTOR PUMP (NA BS-III)	TATA spare parts
254707100141	ASSY.DISTRIBUTOR PUMP BS-III	TATA spare parts
254707100142	ASSY DISTRIBUTOR PUMP EURO-II	TATA spare parts
254707100143	ASSY DISTRIBUTOR PUMP	TATA spare parts
254707105801	HOSE BOOST LINE TO FIP	TATA spare parts
254707105802	RUBBER HOSE (BOOST AIR LINE TO FIP)	TATA spare parts
254707109969	ADAPTOR (BOOST AIR LINE)	TATA spare parts
254707109970	POTENTIOMETER (DELPHI 9107-235A) (FOR FI	TATA spare parts
254707109971	SOLENOID 16 OHMS (FOR FIP)	TATA spare parts
254707120104	SUPPORT BKT FIP	TATA spare parts
254707120106	SUPPORT BKT FIP	TATA spare parts
254707120110	SUPPORT BKT FIP	TATA spare parts
254707120112	SUPPORT BKT FIP	TATA spare parts
254707123803	SUPPORT BRACKET FIP	TATA spare parts
254707124801	HOLLOW DOWEL FIP SUPPORT	TATA spare parts
254707126501	SELF LOCKING NUT BS4	TATA spare parts
254707128401	LOCKING SLEEVE	TATA spare parts
254707128601	SPACER	TATA spare parts
254707128801	STUD (FOR FIP BKT.)	TATA spare parts
254707129201	HARDENED WASHER	TATA spare parts
254707129202	WASHER FOR FIP MTG	TATA spare parts

254707130103	ASSY.FIP GEAR	TATA spare parts
254707130104	ASSY. FIP GEAR	TATA spare parts
254707135403	GEAR FIP	TATA spare parts
254707135404	GEAR FIP 4DL TC	TATA spare parts
254707136501	ADAPTER FIP GEAR	TATA spare parts
254707136504	ADAPTER FIP GEAR	TATA spare parts
254707136506	ADAPTER (FOR FIP GEAR)	TATA spare parts
254707137101	FLANGE FOR FIP GEAR	TATA spare parts
254707137103	FLANGE (FIP GEAR)	TATA spare parts
254707138201	FLANGE FOR FIP GEAR	TATA spare parts
254707140117	FUEL PR LINE 4TH CYL	TATA spare parts
254707140118	SET FUEL PR LINES	TATA spare parts
254707140125	SET FUEL PR LINES	TATA spare parts
254707140138	SET FUEL PR LINES	TATA spare parts
254707140140	FUEL PR LINE 4CYL TC	TATA spare parts
254707140141	FUEL PR LINE 3CYL TC	TATA spare parts
254707140142	FUEL PR LINE 2CYL TC	TATA spare parts
254707140143	FUEL PR LINE 1CYL TC	TATA spare parts
254707140146	FUEL PR LINE 2ND CYL	TATA spare parts
254707140147	FUEL PR LINE 3RD CYL	TATA spare parts
254707140150	SET FUEL PR LINES	TATA spare parts
254707140152	FUEL PR LINE 2ND CYL	TATA spare parts
254707140154	FUEL PR LINE 4TH CYL	TATA spare parts
254707140156	SET FUEL PR LINES	TATA spare parts
254707140157	ASSY. FUEL PRESSURE LINE (CYL. NO. 1)	TATA spare parts
254707140158	ASSY. FUEL PRESSURE LINE (CYL. NO. 2)	TATA spare parts
254707140159	ASSY. FUEL PRESSURE LINE (CYL. NO. 3)	TATA spare parts
254707140160	ASSY. FUEL PRESSURE LINE (CYL. NO. 4)	TATA spare parts
254707140163	ASSY. FUEL PR. LINE (1 & 2)	TATA spare parts
254707140164	ASSY. FUEL PR. LINE (3 & 4)	TATA spare parts
254707140165	ASSY. FUEL PR. LINE (1 & 2)	TATA spare parts
254707140166	ASSY. FUEL PR. LINE (3 & 4)	TATA spare parts
254707140167	ASSY. HIGH PR. LINE (1 & 2)	TATA spare parts
254707140168	ASSY. HIGH PR. LINE (3 & 4)	TATA spare parts
254707144201	CLAMP	TATA spare parts
254707146902	RUB TUBE 140MM	TATA spare parts
254707146903	RUB TUBE 300MM	TATA spare parts
254707146904	PLUG	TATA spare parts
254707146913	RUBBER TUBE 140	TATA spare parts
254707146914	RUBBER TUBE 190	TATA spare parts
254707146915	RUBBER TUBE-300	TATA spare parts
254709110105	BRACKET FUEL FILTER	TATA spare parts
254709110106	FUEL FILTER ASSY	TATA spare parts
254709110118	ASSY. FUEL FILTER	TATA spare parts
254709110119	FUEL FILTER ELEMENT	TATA spare parts
254709110119DF	FUEL FILTER ELEMENT W/SEALS - ACE BS2/3/	TATA spare parts
254709110130	BKT FUEL FILTER	TATA spare parts

254709110150	FUEL FILTER ASSY WITH WATER SEP.	TATA spare parts
254709110151	ASSY BRACKET (FUEL FILTER MTG)	TATA spare parts
254709110152	ASSY BKT (MICO FUEL FILTER MTG)	TATA spare parts
254709113304	BKT FUEL FILTER	TATA spare parts
254709116301	SPACER (F/F MTG)	TATA spare parts
254709118601	SPACER (FUEL FILTER)	TATA spare parts
254709120102	FUEL RETURN LINE	TATA spare parts
254709120105	FUEL LINE FILTER-FIP	TATA spare parts
254709120106	FUEL RETURN LINE	TATA spare parts
254709120110	FUEL RETURN LINE	TATA spare parts
254709120112	ASSY. FUEL LINE (FILTER TO FIP)	TATA spare parts
254709120117	FUEL RETURN LINE	TATA spare parts
254709120119	FUEL LINE FILTER TO FIP	TATA spare parts
254709120122	FUEL RETURN LINE TC	TATA spare parts
254709120130	FUEL LINE NLS FILTER TO FIP	TATA spare parts
254709120132	FUEL RETURN LINE	TATA spare parts
254709120133	ASSY. FUEL LINE	TATA spare parts
254709120140	FUEL LINE FILTER TO FIP	TATA spare parts
254709120141	ASSY. FUEL RETURN LINE	TATA spare parts
254709120151	ASSY FUEL LINE-FILTER TO FIP	TATA spare parts
254709120152	ASSY FUEL LINE-FILTER TO FIP	TATA spare parts
254709130111	A/FILTER ELEMENT	TATA spare parts
254709130124	ELBOW AIR INLET CAB	TATA spare parts
254709130132	A/FILTER ELEMENT	TATA spare parts
254709130135	ASSY.SERVICE INDICATOR	TATA spare parts
254709130147	BKT AIR FILTER MTG	TATA spare parts
254709130148	AIR FILTER ASSY	TATA spare parts
254709130182	A/FILTER ELEMENT TC	TATA spare parts
254709130201	ASSY.AIR FILTER COMPLETE	TATA spare parts
254709130211	A/F ELEMENT FR. SEP	TATA spare parts
254709130212	SCOOP AIR INTAKE	TATA spare parts
254709130216	BKT AIR FILTER MTG	TATA spare parts
254709130224	ASSY AIR FILTER COMPLETE	TATA spare parts
254709130235	A/F ELEMENT P.P	TATA spare parts
254709130236	AIR FILTER P.PLAST	TATA spare parts
254709130243	A/FILTER ELEMENT NA	TATA spare parts
254709130265	HOSE AIR FILTER	TATA spare parts
254709130296	ASSY. FILTER ELEMENT	TATA spare parts
254709130312	ASSLY AIR FILTER TC	TATA spare parts
254709130323	ASSY.MOUNTING PLATE-AIR INTAKE	TATA spare parts
254709130335	ASSY.AIR FILTER COMPLETE	TATA spare parts
254709130340	ASSY BKT AIR FILTER	TATA spare parts
254709130341	AIR FILTER ASSY	TATA spare parts
254709130345	ASSY. AIR FILTER COMPLETE	TATA spare parts
254709130346	AIR FILTER ELEMENT CARTRIDGE BS2/3	TATA spare parts
254709130358	ASSY.FILTER WITH SOUND DEADENING PADS	TATA spare parts
254709130361	ASSY STRAP WITH RUBBER ST	TATA spare parts

254709130362	ASSY RUBBER HOSE (A/F TO SCOOP)	TATA spare parts
254709130372	ASSY AIR FILTER BKT. WITH RUBBER PAD	TATA spare parts
254709130374	ASSY. AIR INLET DUCT	TATA spare parts
254709130375	ASSY AIR INLET DUCT	TATA spare parts
254709130388	ASSY. AIR FILTER COMPLETE WINGER BS-I	TATA spare parts
254709130399	ASSEMBLY SCOOP WITH TUBE	TATA spare parts
254709131601	ASSY. AIR INLET DUCT	TATA spare parts
254709133203	BANJO BOLT	TATA spare parts
254709133320	AIR FILTER MTG. BKT.	TATA spare parts
254709133321	BRACKET (SCOOP SUPPORT)	TATA spare parts
254709133812	AIR INTAKE SCOOP	TATA spare parts
254709133816	AIR INTAKE SCOOP	TATA spare parts
254709133817	AIR INTAKE SCOOP	TATA spare parts
254709134203	CLAMP AIR FILTER	TATA spare parts
254709134205	CLAMP AIR SUCTION PIPE	TATA spare parts
254709134205_niu3	CLAMP AIR SUCTION PIPE	TATA spare parts
254709134206	HOSE CLAMP-82 DIA.	TATA spare parts
254709134207	HOSE CLAMP (72 DIA.)	TATA spare parts
254709134210	HOSE CLAMP (75 DIA.)	TATA spare parts
254709134211	HOSE CLAMP (84 DIA.)	TATA spare parts
254709134214	HOSE CLAMP 82 DIA	TATA spare parts
254709134215	HOSE CLAMP 72 DIA	TATA spare parts
254709134216	HOSE CLAMP 62	TATA spare parts
254709134217	HOSE CLAMP (58 DIA.)	TATA spare parts
254709134218	HOSE CLAMP-75 DIA.	TATA spare parts
254709134219	HOSE CLAMP (84 DIA.)	TATA spare parts
254709134220	HOSE CLAMP TB 92	TATA spare parts
254709134221	HOSE CLAMP (91 DIA.)	TATA spare parts
254709135804	HOSE A/FILTER-DISTRIBUTOR	TATA spare parts
254709135814	RUB HOSE A/FILTER -SCOOP	TATA spare parts
254709135816	RUB HOSE NLS A/FILTER OUTLET	TATA spare parts
254709135823	HOSE AIR FILTER SUCTION	TATA spare parts
254709135827	RUBBER HOSE	TATA spare parts
254709135828	RUBBER HOSE-SCOOP TO TC	TATA spare parts
254709135829	HOSE SCOOP TO TC WRAPPED	TATA spare parts
254709135841	HOSE AIR INT TO AIR FILT	TATA spare parts
254709135842	RUBBER HOSE (AIR FILTER TO INLET DUCT)	TATA spare parts
254709135843	RUBBER HOSE (AIR FILT.TO INLET MANIFOLD)	TATA spare parts
254709135844	HOSE (AIR FILTER TO INLET DUCT)	TATA spare parts
254709135845	RUBBER HOSE	TATA spare parts
254709136315	FLEX HOSE IN ELBOW-FILTER	TATA spare parts
254709136904	TUBE	TATA spare parts
254709136918	SUCTION PIPE AIR FILTER	TATA spare parts
254709136921	TUBE	TATA spare parts
254709136924	SUCTION PIPE AIR FILTER	TATA spare parts
254709136933	TUBE-AIR FILTER MTG. BKT.	TATA spare parts
254709137206	GROMMET	TATA spare parts



254709137502	GROMMET	TATA spare parts
254709137701	RUBBER SLEEVE	TATA spare parts
254709137707	RUBBER SEAL AIR FILTER	TATA spare parts
254709137711	SEAL TOP COVER AIR FILTER	TATA spare parts
254709138215	STRAP	TATA spare parts
254709138230	STRAP AIR FILTER TC	TATA spare parts
254709139905	RUBBER PLUG	TATA spare parts
254709139913	SERVICE INDICATOR	TATA spare parts
254709139914	RUBBER STRAP	TATA spare parts
254709139918	SERVICE INDICATOR BS1/2/3/4/6	TATA spare parts
254709139918AE	ASSY.SERVICE INDICATOR 713	TATA spare parts
254709139919	BANJO ON AIR FILTER	TATA spare parts
254709139941	RUBBER PAD	TATA spare parts
254709990150	SET AIR FILTER+SERVICE IND.	TATA spare parts
254714100105	SAFETY VALVE	TATA spare parts
254714100117	ASSY AIR INLET MANIFOLD 4DL EURO III	TATA spare parts
254714100118	ASSY. ADAPTOR	TATA spare parts
254714103813	INLET MANIFOLD 4DL TC	TATA spare parts
254714103819	INLET MANIFOLD (EURO-III)	TATA spare parts
254714103821	INTAKE MANIFOLD	TATA spare parts
254714103822	INLET MANIFOLD	TATA spare parts
254714103824	INTAKE MANIFOLD	TATA spare parts
254714104201	CLAMP (INLET SCOOP)	TATA spare parts
254714104207	CLAMP (INLET SCOOP)	TATA spare parts
254714105301	GASKET MANIFOLD IN.CENTRE	TATA spare parts
254714105302	GASKET MANIFOLD IN.SIDE	TATA spare parts
254714105304	GASKET CENTRE IN MANIFOLD	TATA spare parts
254714105305	GASKET SIDES IN MANIFOLD	TATA spare parts
254714106302	HOLDER AIR DISTRIBUTOR	TATA spare parts
254714106307	AIR DISTRIBUTOR	TATA spare parts
254714107501	GROMMET	TATA spare parts
254714108201	ASSY. BRACKET (FOR EVRV MTG. ON MANIFOL	TATA spare parts
254714110104	HEAT SHIELD T. C.	TATA spare parts
254714110108	ASSY. BRACKET (FOR EGR VSV)	TATA spare parts
254714110109	ASSY.EGR TUBE1	TATA spare parts
254714110112	ASSY EXH. MANIFOLD WITH STUD	TATA spare parts
254714110113	ASSY.HEAT SHIELD (EURO III)	TATA spare parts
254714110114	EGR VALVE	TATA spare parts
254714110116	ASSY.BRACKET(SOL.VALVE MTG. ON FIP)	TATA spare parts
254714110117	ASSY. EGR VALVE	TATA spare parts
254714110122	ASSY.EGR VALVE-EURO-III	TATA spare parts
254714110124	ASSY.EGR TUBE	TATA spare parts
254714110127	ASSY HEAT SHIELD	TATA spare parts
254714110130	EGR PIPE	TATA spare parts
254714110133	ASSY. EGR VALVE	TATA spare parts
254714110137	ASSY EGR TUBE(EXH MANIFOLD TO EGR VALVE)	TATA spare parts
254714110138	ASSY EGR TUBE(EGR COOLER TO INT MANIFOLD	TATA spare parts

254714110141	ASSY. NYLON PIPE	TATA spare parts
254714110142	ASSY. CLOSED COUPLED CATCON	TATA spare parts
254714111601	HEAT SHIELD	TATA spare parts
254714111612	GASKET (FOR EGR TUBE TO INTAKE MANIFOLD)	TATA spare parts
254714113301	BRACKET TC	TATA spare parts
254714113305	BRACKET {FOR EXH.ELBOW ON CLUTCH HSG.}	TATA spare parts
254714113306	BRACKET (ON CL. HSG. FOR EX.ELBOW MTG.)	TATA spare parts
254714113307	BRACKET(CCC SUPPORT TOP)	TATA spare parts
254714113308	BRACKET(CCC SUPPORT BOTTOM)	TATA spare parts
254714113309	BRACKET (FOR TC)	TATA spare parts
254714113310	BRACKET (FOR NYLON PIPE)	TATA spare parts
254714113704	EXHAUST MANIFOLD 4DL TC	TATA spare parts
254714113705	EXHAUST ELBOW	TATA spare parts
254714113712	EXHAUST MANIFOLD FOR EGR ENGINE	TATA spare parts
254714113713	EXHAUST MANIFOLD EURO III	TATA spare parts
254714113714	EXHAUST MANIFOLD	TATA spare parts
254714113719	EXHAUST ELBOW	TATA spare parts
254714115302	GASKET EXHAUST MANIFOLD	TATA spare parts
254714115304	GASKET (INLET - EXHAUST)	TATA spare parts
254714115305	GASKET TURBINE INLET	TATA spare parts
254714115308	GASKET (INLET-EX.MANIFOLD)	TATA spare parts
254714115309	GASKET (TURBINE OUTLET)	TATA spare parts
254714115310	GASKET (TURBINE INLET)	TATA spare parts
254714115319	GASKET(TURBINE OUTLET)-SS MATL.	TATA spare parts
254714115334	GASKET (TURBINE INLET)	TATA spare parts
254714115335	GASKET INLET-EXHAUST (SS 304)	TATA spare parts
254714115801	HOSE (750)(SOLENOID VALVE TO E	TATA spare parts
254714115806	HOSE (250)	TATA spare parts
254714115807	HOSE (220)	TATA spare parts
254714115808	HOSE(750) - SOLENOID VALVE TO EGR VALVE	TATA spare parts
254714115809	HOSE (65) CONNECTOR TO VAC. PUMP	TATA spare parts
254714115810	HOSE (1160)SOLENOID VALVE TO EGR VALVE	TATA spare parts
254714115811	HOSE (1100)	TATA spare parts
254714115812	HOSE(EVRV TO SCOOP)	TATA spare parts
254714115813	HOSE (EVRV TO EGR VALVE)	TATA spare parts
254714115816	HOSE(NYLON HOSE TO T CONNECTOR)	TATA spare parts
254714115820	RUBBER HOSE(EVRV TO NYLON PIPE)	TATA spare parts
254714115821	RUBBER HOSE(EVRV TO SCOOP)	TATA spare parts
254714115822	RUBBER HOSE(EVRV TO EGR VALVE)	TATA spare parts
254714116503	CLINCH NUT	TATA spare parts
254714116504	CLINCH NUT	TATA spare parts
254714118202	HEAT SHIELD (TC)	TATA spare parts
254714118803	STUD EXH MANIFOLD	TATA spare parts
254714119905	ADAPTOR (FOR SOL.VALVE MTG.BRACKET)	TATA spare parts
254714119906	TRANSFER LABLE (ABSORP. COEFF.) (1.5)	TATA spare parts
254714135301	GASKET TUBE ASSY TO TC	TATA spare parts
254714135302	GASKET (ASSY. TUBE TO TC)	TATA spare parts

254714135304	GASKET(TUBE TO TC)	TATA spare parts
254714510104	ASSY. TURBOCHARGER BS2/3	TATA spare parts
254714510107	ASSY. TURBOCHARGER	TATA spare parts
254714510123	TURBOCHARGER	TATA spare parts
254714510133	ASSY.TURBOCHARGER	TATA spare parts
254714511601	ASSY. TURBOCHARGER BS3/4	TATA spare parts
254714603313	BRACKET (IC MTG)	TATA spare parts
254714604207	CLAMP (IC BOTTOM PIPE)	TATA spare parts
254714604208	CLAMP FOR IC TOP PIPE	TATA spare parts
254714604210	CLAMP (FOR TC/IC PIPE)	TATA spare parts
254714604214	HOSE CLAMP (77 DIA.)	TATA spare parts
254714604215	HOSE CLAMP 65	TATA spare parts
254714604218	CLAMP (IC BOTTOM PIPE)	TATA spare parts
254714605809	HOSE PIPE TO MANIFOLD	TATA spare parts
254714605811	HOSE INTERCOOLER TOP	TATA spare parts
254714605815	RUBBER HOSE (I.C. TO MANIFOLD)	TATA spare parts
254714605817	HOSE INT COOL-PIPE BOTTOM	TATA spare parts
254714605819	HOSE MOULD INT COOLER BOT	TATA spare parts
254714605824	HOSE IC TO MANIFOLD	TATA spare parts
254714605825	RUBBER HOSE (IC TO MANIFOLD)	TATA spare parts
254714605828	RUBBER HOSE IC BOTTOM	TATA spare parts
254714605829	RUBBER HOSE (IC BOTTOM)	TATA spare parts
254714605852	HOSE TO PIPE TO I.C.	TATA spare parts
254714605853	RUBBER HOSE (TC TO PIPE TO IC)	TATA spare parts
254714605857	RUBBER HOSE (TURBOCHARGER TO PIPE) HOSE	TATA spare parts
254714606919	PIPE INTERCOOLER TO TC	TATA spare parts
254714606922	PIPE (TC TO IC - TOP)	TATA spare parts
254714606923	PIPE (TC TO IC-BOTTOM)	TATA spare parts
254714606925	PIPE (IC TO INLET MANIFOLD)	TATA spare parts
254714606931	PIPE TC TO IC	TATA spare parts
254714606935	PIPE TC TO IC	TATA spare parts
254714606940	PIPE TC TO IC	TATA spare parts
254714606948	PIPE (TC TO IC)	TATA spare parts
254714606949	PIPE (TC TO IC)	TATA spare parts
254714606950	PIPE (IC TO INLET MANIFOLD)	TATA spare parts
254714608601	SPACER IC MTG	TATA spare parts
254714608602	SPACER FOR IC MTG	TATA spare parts
254714609913	INTERCOOLER	TATA spare parts
254714609914	INTERCOOLER MOBILE NLS 9915	TATA spare parts
254714609915	INTERCOOLER MOBILE	TATA spare parts
254714609919	INTERCOOLER SIERRA TC	TATA spare parts
254714609922	INTERCOOLER SAFARI	TATA spare parts
254714609929	INTERCOOLER	TATA spare parts
254714609931	INTERCOOLER	TATA spare parts
254714609936	INTERCOOLER (TELCOLINE)	TATA spare parts
254714609937	INTERCOOLER (TELCOLINE)	TATA spare parts
254714609938	INTERCOOLER (TELCOLINE)	TATA spare parts

254714609939	INTERCOOLER BS3/4	TATA spare parts
254714609941	INTERCOOLER (PLASTIC TANK)	TATA spare parts
254714700101	ASSY. EGR COOLER(TATA TOYO RADIATOR)	TATA spare parts
254714705801	HOSE(EGR COOLER INLET)	TATA spare parts
254714705802	HOSE (EGR COOLER OUTLET)	TATA spare parts
254715130102	SOCKET WITH TUBE	TATA spare parts
254715130109	OIL LINE VAC PUMP INLET	TATA spare parts
254715130110	OIL LINE NLS VAC PUMP INLET	TATA spare parts
254715130112	OIL LINE VAC PUMP TO CYL NLS 0116	TATA spare parts
254715130113	HOSE VACCUM PUMP INLET	TATA spare parts
254715130115	ASSY.OIL LINE WITH SS BRAIDING	TATA spare parts
254715130116	ASSY.OIL LINE-SS BRAIDING	TATA spare parts
254715133201	BOLT PIPE UNION	TATA spare parts
254715133202	PIPE UNION BOLT	TATA spare parts
254715134201	HOSE CLAMP 23 DIA	TATA spare parts
254715134202	HOSE CLAMP ( 23 DIA.)	TATA spare parts
254715135803	HOSE VAC PUMP TO OIL SUMP	TATA spare parts
254715135805	HOSE VAC PUMP TO OIL SUMP	TATA spare parts
254715135806	RUBBER HOSE -VACUUM PUMP TO SUMP	TATA spare parts
254715135811	RUBBER HOSE (VACUUM PUMP TO OIL SUMP)	TATA spare parts
254715138001	HOLLOW SCREW	TATA spare parts
254715140101	CLAMPING PIECE	TATA spare parts
254715140115	IDLER ASSY	TATA spare parts
254715140117	TENSIONING ROD	TATA spare parts
254715140121	TENSIONING ROD COMP	TATA spare parts
254715140127	TENSIONING ROD COMPLT.	TATA spare parts
254715140128	ASSY.TENSIONING ROD+CLAMP NUT+THIN NUT	TATA spare parts
254715140136	CLAMP ROD ALTERNATOR TENSIONER	TATA spare parts
254715143301	BKT ALTERNATOR FABRACATED	TATA spare parts
254715143702	BRACKET ALTERNATOR MTG	TATA spare parts
254715143703	BRACKET ALTERNATOR MTG	TATA spare parts
254715143704	BRACKET ( ALTERNATOR MTG.)	TATA spare parts
254715143707	BRACKET ALTERNATOR MOUNTING SUMO DX	TATA spare parts
254715143713	BRACKET-ALTERNATOR & PUMP MTG.	TATA spare parts
254715143716	BRACKET-ALTERNATOR & CP1 PSTG -SAFARI	TATA spare parts
254715143720	BRACKET (ALTERNATOR MOUNTING)	TATA spare parts
254715146301	POLY V BELT 4 GROOVE	TATA spare parts
254715146305	POLY V BELT 6 GROOVE	TATA spare parts
254715146307	POLY V BELT 6 GROOVE	TATA spare parts
254715146308	POLY V BELT 4 GROOVE	TATA spare parts
254715146310	POLY V - BELT (4 GROOVE)	TATA spare parts
254715146311	POLY V BELT	TATA spare parts
254715146314	POLY V BELT 4 GROOVE 1045	TATA spare parts
254715146315	POLY V BELT 4 GROOVE	TATA spare parts
254715146321	POLY V BELT 4 GRV 1040 LG	TATA spare parts
254715146327	POLY V BELT 6 GRV 1065 LG SAFARI NEW	TATA spare parts
254715146329	V BELT 4 PK 1045 LG	TATA spare parts

254715146332	POLY V BELT 4PK 1037	TATA spare parts
254715147106	PLATE (ALTERNATOR TOP MTG)	TATA spare parts
254715147109	PLATE (ALTERNATOR MTG.TOP)	TATA spare parts
254715147110	PLATE (ALTERNATOR TOP MTG.)	TATA spare parts
254715148001	TENSIONING SCREW- ALTERNATOR BELT	TATA spare parts
254715189901	GLOW PLUG TC	TATA spare parts
254715189902	GLOW PLUG 4DL TC	TATA spare parts
254715189903	GLOW PLUG BS2/3/4	TATA spare parts
254718100115	STRAINER HOUSING ASSY	TATA spare parts
254718100116	OIL PUMP ASSY	TATA spare parts
254718100118	OIL PUMP ASSY UCAL 4DL NA	TATA spare parts
254718100119	ASSY. STRAINER HOUSING	TATA spare parts
254718100125	ASSY. STRAINER HOUSING	TATA spare parts
254718100126	OIL PUMP ASSY	TATA spare parts
254718100132	OIL PUMP ASSY	TATA spare parts
254718103701	VALVE HOUSING	TATA spare parts
254718103801	HOUSING OIL PUMP	TATA spare parts
254718104802	HOLLOW DOWEL OIL PUMP	TATA spare parts
254718104803	HOLLOW DOWEL (ON CRANKCASE-OIL RETURN)	TATA spare parts
254718105401	GEAR OIL PUMP	TATA spare parts
254718105403	OIL PUMP GEAR	TATA spare parts
254718105404	GEAR OIL PUMP SINTERED	TATA spare parts
254718107901	SHAFT DRIVE GEAR	TATA spare parts
254718107902	SHAFT DRIVEN GEAR	TATA spare parts
254718108201	STRAINER PLATE	TATA spare parts
254718108204	STRAINER COVER	TATA spare parts
254718108602	SPACER OIL PUMP CHAIN	TATA spare parts
254718108901	SPROCKET	TATA spare parts
254718108902	SPROCKET OILPUMP DRIVE	TATA spare parts
254718108903	SPROCKET NLS OIL PUMP TC	TATA spare parts
254718109903	PLUG (OIL PRESSURE RELIEF VALVE)	TATA spare parts
254718109904	STEEL ROLLER CHAIN 4DL NA	TATA spare parts
254718109906	CHAIN	TATA spare parts
254718109907	PLUG (OIL PRESSURE RELIEF VALVE)	TATA spare parts
254718109909	ROLLER CHAIN (OIL PUMP)	TATA spare parts
254718109910	STEEL ROLLER CHAIN	TATA spare parts
254718130101	OIL FILTER ASSY	TATA spare parts
254718130102	OIL FILTER ASSY	TATA spare parts
254718130103	OIL FILTER ASSY	TATA spare parts
254718130104	OIL FILTER ASSY	TATA spare parts
254718130105	OIL FILTER ASSY	TATA spare parts
254718130106	ASSY. OIL FILTER	TATA spare parts
254718130106AE	ASSY. OIL FILTER XEN DC XEN SC	TATA spare parts
254718130108	OIL FILTER ASSY	TATA spare parts
254718130109	OIL FILTER ASSY IMPROVED	TATA spare parts
254718130112	OIL FILTER T C	TATA spare parts
254718130115	ASSEMBLY OIL FILTER	TATA spare parts

254718130116	ASSY. OIL FILTER	TATA spare parts
254718130117	ASSY. OIL FILTER REDUCED LENGTH	TATA spare parts
254718133802	ADAPTER OIL FILTER MTG	TATA spare parts
254718170104	HEAT SHIELD ASSY	TATA spare parts
254718170123	OIL COOLER ASSY	TATA spare parts
254718170126	OIL COOLER ASSY	TATA spare parts
254718170127	OIL COLLER ASSY	TATA spare parts
254718170130	OIL LINE O/COOLER TO TC	TATA spare parts
254718170131	NOZZLE PISTON COOLING	TATA spare parts
254718170135	OIL COOLER ASSY	TATA spare parts
254718170139	ASSY.HEAT SHIELD	TATA spare parts
254718170140	ASSY.OIL COOLER (3-DECK)	TATA spare parts
254718170141	ASSY.OIL COOLER WITH COVER 4DL 3 DECK	TATA spare parts
254718170152	ASSY.HEAT SHIELD	TATA spare parts
254718170153	OIL LINE O/COOLER TO TC	TATA spare parts
254718170154	TUBE TC OIL RETURN	TATA spare parts
254718173703	COVER OIL COOLER	TATA spare parts
25471817370321	OIL COOLER COVER SEMIFINISHED 4DL NA	TATA spare parts
254718173704	COVER OIL COLLER 4DL TC	TATA spare parts
254718175304	GASKET OIL COOLER COVER	TATA spare parts
254718175306	GASKET PISTON COOL NOZZLE	TATA spare parts
254718175307	COMBINED GASKET (OIL COOLER/COVER)	TATA spare parts
254718175308	GASKET COMBINED NLS OILCOOLER	TATA spare parts
254718175309	COMBINED GASKET	TATA spare parts
254718175310	COMBINED GASKET (OIL COOLER)	TATA spare parts
254718175311	COMBINED GASKET (OIL COOLER)	TATA spare parts
254718175312	GASKET PISTON COOLING NOZZLE	TATA spare parts
254718175313	COMBINED GASKET (OIL COOLER)	TATA spare parts
254718175801	RUB HOSE OIL RETURN TC	TATA spare parts
254718175805	HOSE TC RE PIPE TO SUMP	TATA spare parts
254718175808	RUBBER HOSE-SILICONE-TC OIL RETURN	TATA spare parts
254718178001	COLLAR HEX SCREW	TATA spare parts
254720100118	WATER PUMP	TATA spare parts
254720100124	ASSLY WATER PUMP W/TH INT SHAFT	TATA spare parts
254720100130	ASSY. WATER PUMP	TATA spare parts
254720100132	WATER PUMP ASSY	TATA spare parts
254720105301	GASKET WATER PUMP	TATA spare parts
254720105303	GASKET (WATER PUMP)	TATA spare parts
254720105304	GASKET (WATER PUMP)	TATA spare parts
254720105305	GASKET (WATER PUMP)	TATA spare parts
254720105306	GASKET (WATER PUMP)	TATA spare parts
254720105307	GASKET (WATER PUMP)	TATA spare parts
254720105401	GEAR WATER PUMP	TATA spare parts
254720120110	THERMOSTAT ASSY 87 DEG	TATA spare parts
254720120112	THERMOSTAT HSG.W/STUDS	TATA spare parts
254720120115	THERMOSTAT ASSY. (78 DEG.S.O.T.)	TATA spare parts
254720120128	THERMOSTAT ASSY 78 DEG	TATA spare parts

254720120136	ASSY. ELBOW (WATER INLET)	TATA spare parts
254720120141	ASSY ELBOW WATER INLET WITH BANJO BODY	TATA spare parts
254720120167	THERMOSTAT HSG.	TATA spare parts
254720120184	ASSY.THERM.HSG.WITH STUD(EURO III)	TATA spare parts
254720120199	ASSY.THERMOSTAT HOUSING WITH ADAPTOR	TATA spare parts
254720120204	ASSY.THERMOSTAT HOUSING WITH ADAPTOR	TATA spare parts
254720120211	ASSY BYPASS PIPE (THERM.HSG. TO ELBOW)	TATA spare parts
254720120219	ASSY. BYPASS PIPE(W/O HEATER)	TATA spare parts
254720120220	ASSY.THERMOSTAT HOUSING	TATA spare parts
254720123303	BKT WATER BYPASS PIPE	TATA spare parts
254720123804	ELBOW WATER INLET	TATA spare parts
254720123810	COVER THERMOSTAT	TATA spare parts
254720123812	THERMOSTAT HSG.	TATA spare parts
254720123816	ELBOW WATER INLET	TATA spare parts
254720123819	THERMOSTAT HSG.CAB HTR.	TATA spare parts
254720124204	CLAMP WATER BYPASS PIPE	TATA spare parts
254720124208	HOSE CLAMP 50	TATA spare parts
254720124212	HOSE CLAMP TB 32	TATA spare parts
254720124213	HOSE CLAMP-50 DIA	TATA spare parts
254720124214	HOSE CLAMP- 32 DIA. BS4	TATA spare parts
254720125301	GASKET THERM HSG - CYL HD	TATA spare parts
254720125302	GASKET COV TO THERM HSG	TATA spare parts
254720125304	GASKET ELBOW - CYL BLOCK	TATA spare parts
254720125306	GASKET (THERMOSTAT HSG.TO CYL.HEAD)	TATA spare parts
254720125307	GASKET (COVER TO THERMOSTAT HSG.)	TATA spare parts
254720125308	GASKET (ELBOW TO CYL.CRANKCASE)	TATA spare parts
254720125309	GASKET (ELBOW TO CYL.CRANKCASE)	TATA spare parts
254720125310	GASKET (COVER TO THERMOSTAT HSG.)	TATA spare parts
254720125311	GASKET (THERMOSTAT HSG.TO CYL.HEAD)	TATA spare parts
254720125312	GASKET (ELBOW TO CYL.CRANKCASE)	TATA spare parts
254720125313	GASKET (THERMOSTAT HSG.TO CYL.HEAD)	TATA spare parts
254720125314	GASKET (COVER TO THERMOSTAT HSG.)	TATA spare parts
254720125315	GASKET (THERMOSTAT HSG.TO CYL.HEAD)	TATA spare parts
254720125316	GASKET (COVER TO THERMOSTAT HSG.)	TATA spare parts
254720125317	GASKET (ELBOW TO CYL.CRANKCASE)	TATA spare parts
254720125318	GASKET (COVER TO THERM. HSG.)	TATA spare parts
254720125319	GASKET (THERMOSTAT HSG.TO CYL.HEAD)	TATA spare parts
254720125320	GASKET (ELBOW TO CYL.CRANKCASE)	TATA spare parts
254720125321	GASKET (COVER TO THERMOSTAT HSG.)	TATA spare parts
254720125322	GASKET (ELBOW TO CYL.CRANKCASE)	TATA spare parts
254720125323	GASKET (THERMOSTAT HSG.TO CYL.HEAD)	TATA spare parts
254720125801	RUBBER HOSE (ELBOW TO BYPASS)	TATA spare parts
254720125802	HOSE NLS BYPASS LINE TO ELBOW	TATA spare parts
254720125806	HOSE RADIATOR TO ELBOW	TATA spare parts
254720125809	HOSE THERM - BYPASS PIPE	TATA spare parts
254720125811	HOSE NLS THERM - BYPASS PIPE	TATA spare parts
254720125812	HOSE MOULDED COVER - PIPE	TATA spare parts

254720125813	RUBBER HOSE (MOULDED) (ELBOW TO BYPASS)	TATA spare parts
254720125818	HOSE THERMO TO BYPAS PIPE	TATA spare parts
254720125821	R HOSE RED TO ELBOW NEW	TATA spare parts
254720125826	RUBBER HOSE(THERMO COVER-PIPE)	TATA spare parts
254720125827	RUBBER HOSE(THERMO.TO BYPASS)	TATA spare parts
254720126917	PIPE (WATER BYPASS) 4DLNA NON AC NON TC	TATA spare parts
254720126919	PIPE WATER BYPASS	TATA spare parts
254720126925	PIPE WATER BYPASS	TATA spare parts
254720128201	BKT WATER BYPASS PIPE	TATA spare parts
254720128502	SOCKET (HEATER INLET HOSE)	TATA spare parts
254720128503	SOCKET	TATA spare parts
254720129901	BANJO BODY	TATA spare parts
254720129904	THERMOSTAT (83 DEG. WITH JIGGLE PINS)	TATA spare parts
254720129907	THERMOSTAT ASSY(78 DEG) WITH JIGGLE PINS	TATA spare parts
254720129908	THERMOSTAT ASSY. (78 DEG.S.O.T.)	TATA spare parts
254720129909	THERMOSTAT(78 DEG.+JIGGLE PINS)	TATA spare parts
254720140101	FAN ASSY 418 DIA	TATA spare parts
254720140104	FAN ASSY 418 DIA BS4	TATA spare parts
254720140107	FAN ASSY 420 DIA TURBO	TATA spare parts
254720140115	FAN SUMO DX TC	TATA spare parts
254720140122	ASSY.FAN WITH VISCOUS CLUTCH	TATA spare parts
254720140123	ASSY. FAN (BORG WARNER)	TATA spare parts
254720140124	VISCOUS CLUTCH	TATA spare parts
254720140127	ASSY.FAN WITH VISCOUS CLUTCH	TATA spare parts
254720143201	HEX BOLT	TATA spare parts
254720143202	SOCKET HEAD BOLT (VISCOUS CLUTCH)	TATA spare parts
254720143203	SOCKET HEAD BOLT (VISCOUS CLUTCH)	TATA spare parts
254720143801	FAN INTERMEDIATE RING	TATA spare parts
254720143803	FAN INTERMEDIATE RING TS	TATA spare parts
254720143807	ADAPTER FAN MOUNTING	TATA spare parts
254720143809	ADAPTER FAN MOUNTING	TATA spare parts
254720143811	INTERMEDIATE RING (FAN MTG.)(36)	TATA spare parts
254720143814	ADAPTOR FAN MTG.	TATA spare parts
254720143819	FAN INTERMEDIATE RING	TATA spare parts
254720143821	FAN SPACER (47.9)	TATA spare parts
254720149903	ADAPTOR (FOR VISCOUS CL MTG )	TATA spare parts
254720150101	BEARING HOUSING ASSY	TATA spare parts
254720150112	BEARING HOUSING ASSY	TATA spare parts
254720150124	ASSY.BEARING HOUSING COMPLETE	TATA spare parts
254720150126	ASSY BEARING HSG COMPL (VISCOUS CLUTCH)	TATA spare parts
254720150127	ASSY COVER WITH BEARING HOUSING	TATA spare parts
254720153106	BEARING SRDG BALL	TATA spare parts
254720153107	BEARING 6204 2RS C3 FAG	TATA spare parts
254720153701	FAN PULLEY 4 GROOVES	TATA spare parts
254720153703	FAN PULLEY 6 GROOVES	TATA spare parts
254720153712	FAN PULLEY 4 GROOVES	TATA spare parts
254720153714	FAN PULLEY	TATA spare parts



254720153720	FAN PULLEY-6PK	TATA spare parts
254720153721	FAN PULLEY (6PK) VISCOUS CLUTCH	TATA spare parts
254720153722	FAN PULLEY(4PK) VISCOUS CLUTCH	TATA spare parts
254720153725	CAP COVER (STUD ASSOCIATES)	TATA spare parts
254720157902	SHAFT	TATA spare parts
254720158601	SPACER OUTER	TATA spare parts
254720158603	SPACER	TATA spare parts
254720159901	LOCKING WIRE	TATA spare parts
254720990109	SET-RUBBER HOSE + CLAMPS	TATA spare parts
254720990110	SET-RUBBER HOSE + CLAMPS	TATA spare parts
254720990114	SET-HOSE + CLAMPS	TATA spare parts
254720999902	COVER (WATER INLET ELBOW OPENING)	TATA spare parts
254722107101	LIFTING HOOK FRONT	TATA spare parts
254722107102	LIFTING HOOK REAR	TATA spare parts
254722107105	LIFTING HOOK(REAR)	TATA spare parts
254722107106	LIFTING HOOK(FRONT)	TATA spare parts
254722107107	LIFTING HOOK(REAR)	TATA spare parts
254722108201	REAR LIFTING HOOK CUM OIL SEP. MTG. BKT.	TATA spare parts
254722123701	ENGINE SUPPORT FRT LH	TATA spare parts
254722123703	ENGINE SUPPORT FRT RH	TATA spare parts
254722123708	ENGINE SUPPORT FRT LH	TATA spare parts
254722123709	ENGINE SUPPORT FRT RH	TATA spare parts
254722123722	ENGINE MOUNTING ARM (LH)	TATA spare parts
254722123723	ENGINE MOUNTING ARM (RH)	TATA spare parts
254723110106	TENSIONING ROD COMPLETE	TATA spare parts
254723110109	TENSIONING ROD COMPLETE	TATA spare parts
254723113703	BKT POWER STRG PUMP	TATA spare parts
254723113707	BRACKET	TATA spare parts
254723116308	V BELT COGGED 980MM	TATA spare parts
254723116309	COGGED V BELT-990	TATA spare parts
254723116311	V BELT NLS COGGED 990MM	TATA spare parts
254723116315	V BELT COGGED 1010MM	TATA spare parts
254723116320	COGGED V BELT 745 MM	TATA spare parts
254723116322	COGGED V BELT (HIGH RIDE) 765	TATA spare parts
254723116330	POLY V BELT	TATA spare parts
254723116332	POLY-V BELT (1045-ALT+PS DRIVE)	TATA spare parts
254723116333	BELT 6PK EPDM (ALT135A+PS PUMP) BS2/3/4	TATA spare parts
254723116334	EPDM BELT 6PK(ALT.135A+PS)	TATA spare parts
254723116335	POLY V BELT 6PK 1050	TATA spare parts
254723116336	POLY V BELT 6PK 1065 {ROULUNDS}	TATA spare parts
254723116337	POLY V BELT 6PK 1050	TATA spare parts
254723116701	PIVOT PIN	TATA spare parts
254723117007	PULLEY POWER STRG PUMP	TATA spare parts
254723117008	PULLEY POWER STRG PUMP	TATA spare parts
254723117020	PULLEY-CP1 PUMP DIRECT DRIVE	TATA spare parts
254723117021	PULLEY-6PK (POWER STG.PUMP)	TATA spare parts
254723117022	PULLEY 6PK- PUMP	TATA spare parts

254723117023	PULLEY-6PK P.STG.PUMP	TATA spare parts
254723118601	SPACER	TATA spare parts
254723120107	BKT A/C COMPRESSOR	TATA spare parts
254723120110	ACTUATOR FICD	TATA spare parts
254723120115	AC COMPRESSOR	TATA spare parts
254723120116	BKT A/C COMPRESSOR	TATA spare parts
254723120117	IDLER ASSY	TATA spare parts
254723120128	ASSY. F.I.C.D.-COMPLETE	TATA spare parts
254723120129	IDLER ASSY	TATA spare parts
254723120131	BRACKET ASSY W/IDLER	TATA spare parts
254723120155	ASSY. BRACKET	TATA spare parts
254723120161	TENSIONING PLATE AC	TATA spare parts
254723120185	TENSIONING PLATE W/IDLER	TATA spare parts
254723120207	ASSY. TENSIONER ROD+CLAMP NUT+THIN NUT	TATA spare parts
254723120215	ASSY. COMPRESSOR	TATA spare parts
254723120219	CLUTCH FOR AC COMP SAFARI	TATA spare parts
254723120237	ASSY.TENSIONER PULLEY	TATA spare parts
254723120241	F.I.C.D. ASSY.	TATA spare parts
254723120245	PULLER IDLER	TATA spare parts
254723120247	ASSY.AC COMPRESSOR(SD7H15) {SVL}	TATA spare parts
254723120248	A/C COMPRESSOR (SINGLE){DELPHI}	TATA spare parts
254723120250	ASSY. A/C COMPRESSOR BS2/3/4	TATA spare parts
254723120251	ASSY. A/C COMPRESSOR {10S13}	TATA spare parts
254723120252	ASSY BRACKET	TATA spare parts
254723121601	POLY V BELT (4PK)	TATA spare parts
254723123101	D.G.BALL BEARING	TATA spare parts
254723123205	SLIDER BOLT	TATA spare parts
254723123301	BKT ACTUATOR	TATA spare parts
254723123304	BRACKET	TATA spare parts
254723123305	BRACKET FOR TENSIONER	TATA spare parts
254723123705	BRACKET-AC COMPRESSOR MTG.	TATA spare parts
254723123707	BRACKET (A/C COMPRESSOR)	TATA spare parts
254723123708	BRACKET (A.C. COMPRESSOR)	TATA spare parts
254723124801	HOLLOW DOWEL	TATA spare parts
254723126308	POLY V BELT 6 GROOVE	TATA spare parts
254723126309	V BELT 6GR.1316MM	TATA spare parts
254723126310	V BELT NLS POLY 6GR.1321MM	TATA spare parts
254723126315	COGGED V BELT	TATA spare parts
254723126316	V BELT COGGED 1070MM	TATA spare parts
254723126320	POLY V BELT 6 GROOVE	TATA spare parts
254723126322	POLY V BELT 6 GROOVE	TATA spare parts
254723126323	POLY V BELT 6 GROOVE	TATA spare parts
254723126324	POLY VEE BELT (6PK) (1295)	TATA spare parts
254723126327	POLY-V BELT A/C+FAN	TATA spare parts
254723126328	POLY V BELT(6PK-1360)	TATA spare parts
254723126329	POLY-V BELT A/C+FAN	TATA spare parts
254723126330	POLY-V BELT(1360-SVL A/C+FAN)	TATA spare parts

254723126331	PROTECTIVE CAP (ON BEARING)	TATA spare parts
254723126336	POLY V BELT	TATA spare parts
254723126337	PROTECTIVE CAP (FOR BEARING)	TATA spare parts
254723126340	POLY-V BELT A/C+FAN	TATA spare parts
254723126341	POLY V BELT	TATA spare parts
254723126343	POLY V BELT	TATA spare parts
254723126344	POLY V BELT 6PK 1375	TATA spare parts
254723126345	POLY V BELT 6PK	TATA spare parts
254723126347	POLY V BELT 6PK 1370	TATA spare parts
254723126348	POLY V BELT 6PK 1370	TATA spare parts
254723126357	POLY V BELT (4PK)	TATA spare parts
254723126358	POLY V BELT(1400)	TATA spare parts
254723126503	DOME NUT	TATA spare parts
254723126510	NUT (FOR TENSIONER PULLEY MTG.)	TATA spare parts
254723126511	SPECIAL NUT (ROLLER)	TATA spare parts
254723126903	STAY ROD	TATA spare parts
254723127014	ROLLER (AC BELT TENSIONER)	TATA spare parts
254723128002	TENSIONING SCREW (A/C COMPRESSOR BELT)	TATA spare parts
254723128003	TENSIONING SCREW	TATA spare parts
254723128203	BRACKET ACTUATOR	TATA spare parts
254723128602	SPACER (BEARING)	TATA spare parts
254723128603	SPACER (BEARING)	TATA spare parts
254723129910	ACTUATOR FICD	TATA spare parts
254723129911	STAY ROD	TATA spare parts
254723129912	CONTROL LINK	TATA spare parts
254723129917	AC COMPRESSOR SUB R134	TATA spare parts
254724100101	ENGINE MOUNTING PAD FRT	TATA spare parts
254724100111	ASSY. ENGINE MOUNT PAD (FRONT)	TATA spare parts
254724103301	STIFFENER BKT. (CRANKCASE TO DIFF.COVER)	TATA spare parts
254724106501	FLANGED CLINCHED NUT	TATA spare parts
254724108202	SUPPORT (FOR ENGINE MOUNTING FRONT)	TATA spare parts
254724200103	ENGINE MOUNTING PAD REAR	TATA spare parts
254724200110	ENG MTG PAD REAR	TATA spare parts
254724200113	ASSY. ENG. MTG. PAD (REAR)	TATA spare parts
254724200117	ASSY. ENGINE MOUNT (REAR)	TATA spare parts
254725100107	CLUTCH HSG.	TATA spare parts
254725103810	CLUTCH HSG.4DL TC	TATA spare parts
254725103813	CLUTCH HOUSING (HIGH PR.DIE CASTING)	TATA spare parts
254725103814	CLUTCH HOUSING (HIGH PR.DIE CASTING)	TATA spare parts
254725104801	HOLLOW DOWEL CL HSG	TATA spare parts
254725108201	COVER CLUTCH HOUSING	TATA spare parts
254725108202	BACK COVER CL HOUSING	TATA spare parts
254725108203	COVER UPPER CL HOUSING	TATA spare parts
254725108801	STUD CL SLAVE CYL MTG	TATA spare parts
254749100108	CATALYTIC CONVERTER EURO-II	TATA spare parts
254749100109	CATALYTIC CONVERTER EURO-II	TATA spare parts
254749100120	CATALYTIC CONVERTER EURO-II	TATA spare parts

254749100122	ASSY CAT CON EURO3	TATA spare parts
254749100123	ASSY CATALYTIC CONVERTER	TATA spare parts
254749100125	ASSY CAT CONVERTER (BS IV)	TATA spare parts
254749100126	ASSY.CATALYTICCONVERTER(BSIII)	TATA spare parts
254750100109	CLAMP W/PVS SLEEVING	TATA spare parts
254750100111	ASSY CAP (RADIATOR)	TATA spare parts
254750100143	RADIATOR ASSY 4ROW	TATA spare parts
254750100171	PIPE ASSY	TATA spare parts
254750100177	RAD.4 ROW BANCO	TATA spare parts
254750100180	ASSY. RADIATOR-	TATA spare parts
254750100182	RADIATOR ASSY 4ROW	TATA spare parts
254750100195	RADIATOR ASSY T C	TATA spare parts
254750100208	PIPE WATER COOLING	TATA spare parts
254750100215	RADIATOR EURO2	TATA spare parts
254750100216	RAD TOYO SUMO DX	TATA spare parts
254750100243	ASSY.RADIATOR	TATA spare parts
254750100256	RADIATOR W/O TH SWITCH PETROL	TATA spare parts
254750100259	ASSY. BRACKET	TATA spare parts
254750100261	ASSY. RADIATOR (ALUMINIUM)	TATA spare parts
254750100270	ASSY.PIPE WITH BRACKET EURO III	TATA spare parts
254750100271	ASSY PIPE WITH BRACKET	TATA spare parts
254750100273	ASSY.U.C.PIPE + HOSE + CLAMP	TATA spare parts
254750100274	ASSY.TUBE WITH SLEEVE (EURO-III)	TATA spare parts
254750100281	RADIATOR ASSY. (4DL NA)	TATA spare parts
254750100284	ASSY. AUX. TANK	TATA spare parts
254750100286	ASSY. RADIATOR WINGER BS2/3/4	TATA spare parts
254750100287	ASSY.U.C.PIPE + HOSE + CLAMP	TATA spare parts
254750100288	ASSY. PIPE WITH BRACKET	TATA spare parts
254750100289	ASSY HOSE(RADIATOR TO WATER INLET ELBOW)	TATA spare parts
254750100290	ASSY HOSE (AUX. TANK TO ELBOW)	TATA spare parts
254750100291	ASSY. RADIATOR BS2/3/4	TATA spare parts
254750100296	ASSY.SEP.CLAMP (VENT HOSE+AC PIPE)	TATA spare parts
254750103201	T BOLT	TATA spare parts
254750103305	BKT AUX WATER TANK	TATA spare parts
254750103315	BKT AUX WATER TANK	TATA spare parts
254750103325	AUX. TANK MTG. BKT.	TATA spare parts
254750104204	CLAMP	TATA spare parts
254750104212	HOSE CLAMP- 56 DIA	TATA spare parts
254750104213	HOSE CLAMP- 56 DIA.	TATA spare parts
254750104216	HOSE CLAMP 50DIA	TATA spare parts
254750104218	HOSE CLAMP 60 DIA	TATA spare parts
254750104220	HOSE CLAMP TB 60	TATA spare parts
254750104221	HOSE CLAMP- 53 DIA BS4	TATA spare parts
254750104222	HOSE CLAMP 50 DIA BS4	TATA spare parts
254750104225	HOSE CLAMP (16 DIA.)	TATA spare parts
254750104227	CLAMP(AUX.TANK TO RADIATOR TUBE CLAMPING)	TATA spare parts
254750104229	CLAMP (VENT HOSE AUX TANK TO RAD)	TATA spare parts

254750105801	HOSE INT PIPE TO RADIATOR	TATA spare parts
254750105807	HOSE PIPE - ELBOW W/INLET	TATA spare parts
254750105811	HOSE PIPE TO RADIATOR TOP	TATA spare parts
254750105813	HOSE ADAPTOR - COOL PIPE	TATA spare parts
254750105821	HOSE RADIATOR TO ELBOW	TATA spare parts
254750105826	RUBBER HOSE (RADIATOR INLET)	TATA spare parts
254750105827	RUB HOSE RADIATOR TO PIPE	TATA spare parts
254750105842	HOSE RADIATOR TO ELBOW	TATA spare parts
254750105846	RUBBER HOSE (RAD. TO ELBOW) (NON A/C)	TATA spare parts
254750105847	HOSE RADIATOR TO ELBOW	TATA spare parts
254750105848	HOSE ADAPTOR TO TUBE	TATA spare parts
254750105850	RUBBER SLEEVE AIR BL TUBE	TATA spare parts
254750105857	HOSE COMMON	TATA spare parts
254750105859	RUBBER HOSE SUMO JAMMER (RAD TO ELBOW)	TATA spare parts
254750105861	HOSE RAD.BOTTOM SUMO DX	TATA spare parts
254750105862	RUBBER HOSE	TATA spare parts
254750105866	RUBBER HOSE (RADIATOR INLET)(4X2)	TATA spare parts
254750105867	HOSE RADIATOR INLET	TATA spare parts
254750105872	RUBBER HOSE(RADIATOR INLET)(GOLD SEAL)	TATA spare parts
254750105873	RUBBER HOSE(RADIATOR TO ELBOW)	TATA spare parts
254750105878	HOSE (RADIATOR INLET)	TATA spare parts
254750105879	RUBBER HOSE (AUX TANK TO RADIATOR)	TATA spare parts
254750105880	RUBBER HOSE (UCL TO AUX TANK)	TATA spare parts
254750105881	VENT HOSE (RADIATOR TO AUX TANK)	TATA spare parts
254750105882	ASSY. RUBBER HOSE (AUX TANK TO RADIATOR)	TATA spare parts
254750105888	RUBBER HOSE(ADAPTOR TO TUBE)	TATA spare parts
254750106305	CAP AUX WATER TANK BS4	TATA spare parts
254750106306	WATER TANK AUX	TATA spare parts
254750106307	ASSY. AUXILIARY WATER TANK BS2/4	TATA spare parts
254750106308	WATER TANK AUX	TATA spare parts
254750106315	BUTTON PLATFORM	TATA spare parts
254750106902	PIPE THERMOSTAT TO RAD	TATA spare parts
254750106904	PIPE 1030MM	TATA spare parts
254750106905	PIPE 650MM	TATA spare parts
254750106915	PIPE	TATA spare parts
254750106923	PIPE AUX TANK TO RADIATOR	TATA spare parts
254750106929	TUBE THERMO HSG- CYL HEAD	TATA spare parts
254750106935	PIPE (790 MM)	TATA spare parts
254750108001	POINTED SCREW CAGE NUT	TATA spare parts
254750109903	PRESSURE CAP ON RADIATOR	TATA spare parts
254750109904	DRAIN COCK	TATA spare parts
254750109923	DRAIN COCK	TATA spare parts
254750109924	PRESSURE CAP	TATA spare parts
254750500103	FAN SHROUD ASSY	TATA spare parts
254750500109	FAN SHROUD ASSY NLS	TATA spare parts
254750500115	FAN SHROUD ASSY	TATA spare parts
254750500121	ASSY FAN SHROUD (TWO PIECE) - EURO-III	TATA spare parts

254750500124	FAN SHROUD LOWER HALF	TATA spare parts
254750500134	FAN SHROUD	TATA spare parts
254750500163	ASSY FAN SHROUD (TWO PIECE) - EURO-II	TATA spare parts
254750500169	ASSY. FAN SHROUD W/ MOTOR BS2/3/4	TATA spare parts
254750500170	ASSY FAN SHROUD THREE PIECE EII & EIII C	TATA spare parts
254750500171	FAN SHROUD	TATA spare parts
254750500172	FAN MOTOR - PANEL VAN - DIA 370, 480W	TATA spare parts
254750500173	FAN MOTOR - PANEL VAN - DIA 305, 300W	TATA spare parts
254750503401	BUSH (ELEC.FAN MTG.)	TATA spare parts
254750506349	FAN SHROUD UPPER HALF	TATA spare parts
254750506901	SLEEVE (ELEC.FAN MTG.)	TATA spare parts
254750509201	WASHER FAN SHROUD	TATA spare parts
254750990114	SET-HOSE + CLAMPS ELBOW TO BYPASS	TATA spare parts
254750990117	SET-HOSE + CLAMPS	TATA spare parts
2547CR103413	CONROD BRG SET 010	TATA spare parts
2547MB100111	MAIN BRG SET 0.010 U/S	TATA spare parts
2547MB103459	SET MAIN BEARING RS1	TATA spare parts
2547MB200111	SET MAIN BRG RS2	TATA spare parts
2547PSEB0277	SET PISTON W/O RINGS	TATA spare parts
254801108201	CORE PLUG [ 42 DIA.]	TATA spare parts
254901103201	HEX.BOLT (M.B.CAP)	TATA spare parts
254901107704	GASKET (CAM COVER INNER)	TATA spare parts
254901140101	ASSY BACK PLATE (EXHAUST SIDE)	TATA spare parts
254901143201	SHOULDER BOLT (TIMING COVER)	TATA spare parts
254901147501	RUBBER BUSH TIMING COVER	TATA spare parts
254901147704	SEALING STRAP (850 +/-5)	TATA spare parts
254901147705	SEALING STRAP (82 +/-1)	TATA spare parts
254901147706	SEALING STRAP (87 +/-1)	TATA spare parts
254901147708	COVER TIMING BELT	TATA spare parts
254901147709	COVER (TIMING BELT)	TATA spare parts
254901153205	PILLAR BOLT (FOR CAMCOVER MTG.)	TATA spare parts
254901153413	VALVE SEAT RING-INTAKE-NORMAL	TATA spare parts
254901153419	VALVE SEAT RING-INTAKE-NORMAL	TATA spare parts
254901153804	CAM COVER	TATA spare parts
254901154202	CLAMP	TATA spare parts
254901154801	DOWEL RING	TATA spare parts
254901155305	CYL HEAD GASKET	TATA spare parts
254901156902	SPACER TUBE	TATA spare parts
254901156904	SPACER (BREATHER BOX)	TATA spare parts
254901156908	NIPPLE (HEATER TAKE OFF)	TATA spare parts
254901157703	RUBBER D SEAL CYL.HEAD	TATA spare parts
254901157705	GASKET (CAM COVER OUTER)	TATA spare parts
254901157706	COVER SPARK PLUG	TATA spare parts
254901157707	RUBBER BUSH (INTAKE MANIFOLD/CAMCOVER)	TATA spare parts
254901157708	RUBBER D SEAL (CYL.HEAD)	TATA spare parts
254901157710	GASKET CAMCOVER OUTER	TATA spare parts
254901157711	RUBBER GASKET (FOR COVER SPARK PLUG)	TATA spare parts

254901158203	DIAMOND MESH (BREATHER BOX CAM COVER)	TATA spare parts
254901158204	BAFFLE PLATE (BREATHER BOX) (B)	TATA spare parts
254901158206	DIAMOND MESH (BREATHER BOX CAM COVER)	TATA spare parts
254901158207	DIAMOND MESH	TATA spare parts
254901159201	WASHER (CYL.HEAD BOLT)	TATA spare parts
254901170103	ASSY.PCV VALVE	TATA spare parts
254901170104	ASSY. PCV VALVE	TATA spare parts
254901170105	ASSY.OIL SEPARATOR	TATA spare parts
254901170108	ASSY.SOCKET WITH TUBE	TATA spare parts
254901170115	ASSY.BLOWBY TUBE (ON BLOCK)	TATA spare parts
254901170119	ASSY.CLAMP	TATA spare parts
254901170122	ASSY.OIL SEPARATOR	TATA spare parts
254901170123	ASSY.PCV VALVE	TATA spare parts
254901175805	RUBBER HOSE (CAMCOVER TO CON.PIPE)	TATA spare parts
254901175806	RUBBER HOSE (OIL SEPARATOR)	TATA spare parts
254901175807	RUBBER HOSE (OIL SEPARATOR)	TATA spare parts
254901175813	RUBBER HOSE (BLOW BY TUBE-OIL SEPARATOR)	TATA spare parts
254901175814	RUBBER HOSE (BLOW BY)	TATA spare parts
254901175815	RUBBER HOSE (BLOWBY TUBE TO PCV VALVE)	TATA spare parts
254901176917	BLOW BY TUBE (OIL SEPARATOR - PCV VALVE)	TATA spare parts
254901176918	BLOW BY TUBE (OIL SEPARATOR TO OIL SUMP)	TATA spare parts
254901176919	BLOW BY TUBE (CYL.BLOCK - OIL SEPARATOR)	TATA spare parts
254901177502	RUBBER GROMMET	TATA spare parts
254901990105	ENGINE OVERHAUL SEAL KIT	TATA spare parts
254903105403	TOOTHED PULLEY(CRANKSHAFT)	TATA spare parts
254903105404	TOOTHED PULLEY (CRANKSHAFT)	TATA spare parts
254903107901	CRANKSHAFT NORMAL	TATA spare parts
254903120101	SET M.B.SHELL HALF(UPPER/LOWER)	TATA spare parts
254903140104	ASSY.PISTON A	TATA spare parts
254903140106	ASSY.PISTON B	TATA spare parts
254903140111	ASSY.PISTON C	TATA spare parts
254903144303	CIRCLIP	TATA spare parts
254903150103	ASSY.CON ROD COMPLETE	TATA spare parts
254903150104	ASSY.CON ROD COMPLETE (WITHOUT BRG SHELL	TATA spare parts
254903153201	CONNECTING ROD BOLT	TATA spare parts
254903153402	CONNECTING ROD BUSH	TATA spare parts
254903153404	CON.ROD BUSH	TATA spare parts
254903153409	BEARING HALF(CON.ROD)NORMAL	TATA spare parts
254903990115	SET OF BRG.HALF (CON. ROD)-NORMAL	TATA spare parts
254905100104	ASSY. CAMCHAIN TENSIONER BS3/4	TATA spare parts
254905100108	CHAIN TENSIONER (DOUBLE OIL JET)	TATA spare parts
254905107702	O-RING 16X2.65	TATA spare parts
254905109201	WASHER (PULLEY CAMSHAFT)	TATA spare parts
254905109902	STEEL ROLLER CHAIN (CAMSHAFT)	TATA spare parts
254905109903	STEEL ROLLER CHAIN SMOOTH (CAMSHAFT)	TATA spare parts
254905115402	PULLEY EXHAUST CAMSHAFT(SINTERED)	TATA spare parts
254905115404	PULLEY (EXHAUST CAMSHAFT)	TATA spare parts

254905116301	TIMING BELT	TATA spare parts
254905116302	TIMING BELT	TATA spare parts
254905116303	TIMING BELT	TATA spare parts
254905118901	SPROCKET ON CAMSHAFT	TATA spare parts
254905124301	VALVE LOCK HALF (M/S TRW)	TATA spare parts
254905124302	VALVE LOCK (HALF)	TATA spare parts
254905124303	VALVE LOCK HALF (M/S INDO SCHOTTLE)	TATA spare parts
254905125107	RETAINER VALVE	TATA spare parts
254905128201	SPRING SEAT VALVE SPRING	TATA spare parts
254905128703	SPRING VALVE	TATA spare parts
254905129001	INTAKE VALVE	TATA spare parts
254905129003	INTAKE VALVE	TATA spare parts
254905129004	EXHAUST VALVE (SODIUM COOLED) EURO2	TATA spare parts
254905129005	EXHAUST VALVE	TATA spare parts
254905129006	INTAKE VALVE	TATA spare parts
254905129007	EXHAUST VALVE (SODIUM COOLED TAPER STEM)	TATA spare parts
254905129008	INLET VALVE	TATA spare parts
254905129009	EXHAUST VALVE	TATA spare parts
254905130101	ASSY. HYDRAULIC TAPPET 4PL	TATA spare parts
254905130102	ASSY.CHECK VALVE ANTI DRAIN	TATA spare parts
254905130103	ASSY.CHECK VALVE(ANTI DRAIN VALVE)	TATA spare parts
254905130104	ASSY. HYDRAULIC TAPPET 4PL	TATA spare parts
254905130105	ASSY.CHECK VALVE(ANTI DRAIN VALVE)	TATA spare parts
254905150101	ASSY.VALVE GUIDE SEAL	TATA spare parts
254905150102	ASSY.VALVE GUIDE SEAL	TATA spare parts
254905153409	VALVE GUIDE NORMAL	TATA spare parts
254907109907	TANK PRESSURE CONTROL VALVE	TATA spare parts
254909110102	ASSY FUEL FILTER	TATA spare parts
254909125302	GASKET-THROTTLE BODY	TATA spare parts
254909130110	ASSY.AIR INLET SNORKEL	TATA spare parts
254909130137	ASSY.AIR INLET SNORKEL	TATA spare parts
254909133314	BRACKET (SNORKEL)	TATA spare parts
254909135808	RUBBER HOSE	TATA spare parts
254909136301	INTAKE PIPE (FLEXIBLE)	TATA spare parts
254909136308	INTAKE HOSE (FLEXIBLE)	TATA spare parts
254909137502	GROMMET (FOR BRACKET SNORKEL)	TATA spare parts
254914103301	SUPPORT (INTAKE MANIFOLD)	TATA spare parts
254914105305	GASKET (INTAKE MANIFOLD)	TATA spare parts
254914106920	NIPPLE	TATA spare parts
254914106924	NIPPLE (INTAKE MANIFOLD)	TATA spare parts
254914107501	RUBBER BUSH (INTAKE MANIFOLD BKT.)	TATA spare parts
254914108204	CORE PLUG 25 DIA	TATA spare parts
254914110119	CAT.CONVERTOR (ECIA)-NLS0132	TATA spare parts
254914110126	ASSY.SPACER (EXH.MANIFOLD HEAT SHIELD)	TATA spare parts
254914110132	ASSY.CAT.CONVERTER	TATA spare parts
254914116503	SELF LOCKING NUT	TATA spare parts
254914118402	RUBBER BUSH SLEEVE(I.MANIFOLD BKT.)	TATA spare parts



254915146302	POLY V BELT 1155 LG	TATA spare parts
254915146306	POLY V BELT 4 GRV 985 LG	TATA spare parts
254915189903	SPARK PLUG-FR 7DC-BOSCH 0	TATA spare parts
254915200104	HEATED LAMBDA SENSOR	TATA spare parts
254915200111	DOUBLE ENDED IGNITION COIL	TATA spare parts
254915200114	EGR VALVE WITH INTEGRATED	TATA spare parts
254915200122	MINI RELAY (EMS RELAY)	TATA spare parts
254915200128	FUEL CIRCUIT INERTIA SWIT	TATA spare parts
254915200129	VEHICLE SPEED SENSOR	TATA spare parts
254915200140	CANISTER PURGE VALVE RB-0	TATA spare parts
254915200147	PHASE SENSOR PG 3.5	TATA spare parts
254915206305	SUPPORT H.T.CABLE	TATA spare parts
254915209937	HIGH TENSION CABLE 530MM	TATA spare parts
254915209938	HIGH TENSION CABLE 620MM	TATA spare parts
254915209940	HIGH TENSION CABLE-810MM	TATA spare parts
254915209951	RUBBER SLEEVE (CPV)	TATA spare parts
254918100103	ASSY.OIL PUMP COMPLETE	TATA spare parts
254918105101	ADAPTOR (FOR OIL PUMP SPROCKET)	TATA spare parts
254918108602	SPACER FOR CHAIN (1.0 THICK)	TATA spare parts
254918108603	SPACER FOR CHAIN (1.5 THICK)	TATA spare parts
254918108607	SPACER FOR CHAIN (0.5 THK.)	TATA spare parts
254918108609	SPACER FOR CHAIN (1.25 THK.)	TATA spare parts
254918108610	SPACER FOR CHAIN (0.32 THK.)	TATA spare parts
254918108902	SPROCKET (OIL PUMP DRIVE)	TATA spare parts
254918109903	STEEL ROLLER CHAIN (OIL PUMP)	TATA spare parts
254918109904	STEEL ROLLER CHAIN (OIL PUMP)	TATA spare parts
254918109905	STEEL ROLLER CHAIN (OIL PUMP)	TATA spare parts
254918109906	STEEL ROLLER CHAIN (OIL PUMP)	TATA spare parts
254918170101	ASSY.NOZZLE (PISTON COOLING)	TATA spare parts
254918175301	GASKET FOR NOZZLE	TATA spare parts
254920100101	ASSY.WATER PUMP	TATA spare parts
254920123804	COVER (THERMOSTAT)	TATA spare parts
254920125301	GASKET (THERMOSTAT COVER)	TATA spare parts
254920125302	GASKET (CYL.HEAD TO COOLANT BYPASS)	TATA spare parts
254920153203	PILLAR BOLT	TATA spare parts
254922103301	BRACKET (H/T CABLE SUPPORT)	TATA spare parts
254922107101	LIFTING HOOK FRONT	TATA spare parts
254922107103	LIFTING HOOK REAR	TATA spare parts
254924103301	HEAT SHIELD (ENGINE MTG.PAD R/H)	TATA spare parts
254950105809	RUBBER HOSE(THERMOSTAT TO RAD.)SAFARI	TATA spare parts
254950105810	RUBBER HOSE(THERMOSTAT TO RADIATOR)	TATA spare parts
254950105816	RUBBER TUBE ( 650 )	TATA spare parts
255030267501	RUBBER BELLOW	TATA spare parts
255720000001	REFLEX REFLECTOR (RED)	TATA spare parts
255720010001	REFLEX REFLECTOR (WHITE)	TATA spare parts
255720040001	LED SIDE MARKER 12V-SHINX BS6-PH2	TATA spare parts
255730000001	SIDE DIRECTION INDICATOR LH(CAT 6)	TATA spare parts

255730010001	SIDE DIRECTION INDICATOR RH(CAT 6)	TATA spare parts
255810000001	HEIGHT MARKER WHITE FIEM 12V	TATA spare parts
255810010001	HEIGHT MARKER RED FIEM 12V	TATA spare parts
255810040001	LED HT.MKR LAPL 12V WHITE BS6	TATA spare parts
255810050001	LED HT. MKR LAPL 12V RED BS6	TATA spare parts
255820020001	HIGH MOUNT STOP LAMP 12V LAPL	TATA spare parts
256010360001	BAGGAGE BOX LAMP 12V BS6	TATA spare parts
256020120001	FLOUROSCENT LAMP 12V PLR 15RA	TATA spare parts
256020130001	CABIN LAMP 12V	TATA spare parts
256020140001	SALOON LED LAMP 12V	TATA spare parts
256020150001	LED CABIN LAMP 12V/24V	TATA spare parts
256020340001	LED CABIN LAMP PARABOLA 12/24V	TATA spare parts
256020350001	LED STEP LAMP-24 V	TATA spare parts
256020450001	EMG LIGHTING SYSTEM 12V 600MA BS6	TATA spare parts
256030260001	ROOF LAMP 1180 MM 12V SERIES	TATA spare parts
256030300001	LED ROOF LAMP 12V WITH N.L 1180MM	TATA spare parts
256030320001	LED ROOF LAMP 12V HIGH DENSITY (1020)	TATA spare parts
256040090001	AIS 140 INFO FITTMENT -LP 909/49 WB	TATA spare parts
256040140001	STOP SWITCH MTG RUBBER COVER GROMMET BS	TATA spare parts
256044100117	BENT TUBE	TATA spare parts
256044105801	HOSE LP 1.5 INCH	TATA spare parts
256044105803	HOSE LP	TATA spare parts
256044106906	BENT TUBE	TATA spare parts
256044106911	BENT TUBE	TATA spare parts
256053227901	PISTON ROD 900M	TATA spare parts
256063106701	PIN TO SUB FRAME	TATA spare parts
256063106703	PIN TIPPER BODY	TATA spare parts
256144106801	PIPE SOCKET	TATA spare parts
256226409901	PULL ROD	TATA spare parts
256260107108	STIFFENER OUTER	TATA spare parts
256261113201	U CLAMP	TATA spare parts
256344100101	TUBE ASSEMBLY	TATA spare parts
256344100106	BENT TUBE	TATA spare parts
256344100113	BENT TUBE	TATA spare parts
256344100123	SOCKET ASSY	TATA spare parts
256344100132	SWIVEL ELBOW	TATA spare parts
256344100133	BENT TUBE	TATA spare parts
256344100134	BENT TUBE UPPER	TATA spare parts
256344100138	BENT TUBE	TATA spare parts
256344100139	BENT TUBE	TATA spare parts
256344105802	HOSE SAE100 R4	TATA spare parts
256344105803	HOSE	TATA spare parts
256344105804	RUBBER HOSE LP	TATA spare parts
256344106802	ADAPTER	TATA spare parts
256344220111	OPERATING LEVER ASSY	TATA spare parts
256344400101	FILTER CARTRIDGE	TATA spare parts
256344400110	HYDRAULIC TANK	TATA spare parts

256344400113	FILTER CARTRIDGE	TATA spare parts
256344407701	RUBBER PACKING	TATA spare parts
256344420102	DIPSTICK ASSY	TATA spare parts
256361500111	SUB FRAME MK1 BOX TIPPER	TATA spare parts
256361503202	U CLAMP	TATA spare parts
256361503204	U CLAMP	TATA spare parts
256361507119	U CLAMP SUPPORT	TATA spare parts
256363506702	PIN	TATA spare parts
256363506703	PIN	TATA spare parts
256444100103	BENT TUBE	TATA spare parts
256561500104	ASSY-TIPPER FRAME	TATA spare parts
256744100005	KIT HYD TEL CYL & APP MK1	TATA spare parts
256744100016	HYD T/KIT W/TWIN CYLINDER	TATA spare parts
256744400101	TANK ASSY	TATA spare parts
256760500101	FRAME ASSY TIPPER	TATA spare parts
256760500125	HOOK ASSY	TATA spare parts
256760506704	PIN	TATA spare parts
256761500101	SUB FRAME	TATA spare parts
256763606701	PIN BS2/3/4	TATA spare parts
257129100106	LEVER CL PEDAL	TATA spare parts
257129500120	ASSY.CONTROLS.MTG.BRACKET.	TATA spare parts
257129500121	CL M/C MTG BRACKETLPO1313	TATA spare parts
257129500122	ASSY SUPPORT PEDAL W/TUBE	TATA spare parts
257129506701	PIN LPT 1613 TC	TATA spare parts
257130107903	SHAFT	TATA spare parts
257131000125	FRAME ASSY W/O FR COUPLIN	TATA spare parts
257131000197	FRAME ASSY LPO 55	TATA spare parts
257131200101	ASSY SHOCK ABS CROSS MEMBER	TATA spare parts
257131200114	CROSS MEMBER ASSY	TATA spare parts
257131207106	REINFORCEMENT	TATA spare parts
257131207147	REINFORCEMENT RH-TOP	TATA spare parts
257131207148	REINFORCEMENT-LH-TOP	TATA spare parts
257131207158	REINFORCEMENT REAR R H BOTTOM	TATA spare parts
257131207159	REINFORCEMENT REAR LH BOTTOM	TATA spare parts
257131208223	END PLATE	TATA spare parts
257131208224	END PLATE	TATA spare parts
257132100101	ASSY FRONT SPRING	TATA spare parts
257132107103	LEAF SPRING 3RD FRT	TATA spare parts
257132107104	LEAF SPRING 4TH FRT	TATA spare parts
257132107105	LEAF SPRING 5TH FRT	TATA spare parts
257132403202	CENTRE BOLT	TATA spare parts
257132407113	THIRD LEAF 1493 MM.	TATA spare parts
257132407115	LEAF SPRING 5TH RR	TATA spare parts
257132407116	LEAF SPRING 6TH RR	TATA spare parts
257132800101	ASSY CONNECTING LINK	TATA spare parts
257132800106	ASSY BRACKET	TATA spare parts
257132800113	ASSY.A.R.B.FRT.WITH CRMP.EYE PIECE	TATA spare parts

257132803401	BUSH HALF BOTTOM	TATA spare parts
257132803402	BUSH HALF TOP	TATA spare parts
257132805102	EYE PIECE	TATA spare parts
257132807904	ANTI ROLL BAR	TATA spare parts
257132808302	SHIM	TATA spare parts
257141100101	ASSY.PROP.SHAFT	TATA spare parts
257141100118	PROP SHAFT FRT 76X4X1276	TATA spare parts
257141100119	PROP SHAFT MID 76X4X1315	TATA spare parts
257141100120	PROP SHAFT FRT LPOM 55	TATA spare parts
257141100137	P/SHAFT MID SP CB 76X1317	TATA spare parts
257141110107	PROP SHAFT FRT W/CB	TATA spare parts
257141110108	PROP SHAFT FRT 70X1197	TATA spare parts
257141110110	PROP SHAFT FRT W/CEN BRG	TATA spare parts
257141110111	PROP SHAFT FRT 70X1317	TATA spare parts
257141120101	PROP SHAFT FR-RR 70X1237	TATA spare parts
257141120114	P/SHAFT AGB-FA 90X3X1083	TATA spare parts
257142800107	BRAKE LINE LPO	TATA spare parts
257142800108	BRAKE LINE	TATA spare parts
257142800112	BRAKE LINE	TATA spare parts
257146100102	SUPPORT STRG COLUMN	TATA spare parts
257146200101	UNIVERSAL JOINT	TATA spare parts
257146207902	STRG SPINDLE TOP	TATA spare parts
257146305103	PITMAN ARM	TATA spare parts
257146305107	PITMAN ARM	TATA spare parts
257146805801	HOSE 3/4 LP 400MM	TATA spare parts
257149206903	EXHAUST PIPE INTER REAR	TATA spare parts
257149206904	EXHAUST PIPE INTER REAR	TATA spare parts
257149210103	EXHAUST PIPE INTERMEDIATE	TATA spare parts
257154200101	BKT FOR RELAY	TATA spare parts
257154607501	PROTECTIVE CAP	TATA spare parts
257315100106	STARTER MOTOR 24V	TATA spare parts
257315100107	ALTERNATOR 12V/65A	TATA spare parts
257315100108	ALTERNATOR 12V/65A BS1/2/3	TATA spare parts
257315100110	BRUSH SPG STARTER	TATA spare parts
257315101303	PINION W/EARING	TATA spare parts
257315101401	DE SHIELD ASSY	TATA spare parts
257315101402	BRUSH CARRIER ASSY	TATA spare parts
257315102803	OIL SEAL	TATA spare parts
257315103402	INSULATOR BUSH	TATA spare parts
257315103403	INSUL BUSH-MAIN	TATA spare parts
257315103404	BEARING BUSH DE	TATA spare parts
257315104600	KIT CLUTCH REPAIR	TATA spare parts
257315104605	KIT END COVER	TATA spare parts
257315104606	KIT SOLENOID CAP	TATA spare parts
257315104607	KIT FOR L S E COIL	TATA spare parts
257315104608	REP KIT SOLENOID BODY	TATA spare parts
257315104610	REP KIT ARMATURE	TATA spare parts

257315104611	KIT C E HOUSING	TATA spare parts
257315104612	KIT FIELD COIL	TATA spare parts
257315104613	KIT SWITCH REPLACEMENT	TATA spare parts
257315104614	REP KIT PINION SLEEVE	TATA spare parts
257315104615	KIT DRIVE END BUSH	TATA spare parts
257315104616	KIT NOSE	TATA spare parts
257315104617	KIT PINION	TATA spare parts
257315104618	KIT H S E COIL	TATA spare parts
257315104619	KIT BRUSH	TATA spare parts
257315104620	KIT TIE BOLT	TATA spare parts
257315104621	KIT PLUNGER	TATA spare parts
257315104624	KIT NEGATIVE TERMINAL	TATA spare parts
257315104625	KIT SOLENOID SWITCH MNR	TATA spare parts
257315104627	KIT FRT PLATE ASSY	TATA spare parts
257315104703	C.E. COVER	TATA spare parts
257315108011	POLE SCREW	TATA spare parts
257315109230	STOP WASHER	TATA spare parts
257315109306	BRUSH STARTER	TATA spare parts
257315109903	CASTLE NUT - STARTER	TATA spare parts
257315109909	KIT REP ARMATURE	TATA spare parts
257315109911	KIT REP FIELD COIL	TATA spare parts
257315109914	KIT REP PINION	TATA spare parts
257315109920	KIT REP L S E COIL	TATA spare parts
257315109932	PINION ASSY	TATA spare parts
257315109933	BEARING BUSH-PINION	TATA spare parts
257315109944	SEALING RING	TATA spare parts
257315109945	ARMATURE ASSY	TATA spare parts
257315109946	C E BUSH ARMATURE	TATA spare parts
257315109948	PLUNGER ASSY	TATA spare parts
257315109951	HALF CLUTCH ASSEMBLY	TATA spare parts
257315109952	SOLENOID TERMINAL	TATA spare parts
257315109953	FIELD COIL MAIN	TATA spare parts
257315109957	TERMINAL -VE	TATA spare parts
257315109958	TERMINAL +VE	TATA spare parts
257315109959	SOLENOID SWITCH	TATA spare parts
257315109960	FIELD COIL AUX	TATA spare parts
257315400103	STARTER MOTOR	TATA spare parts
257315400107	ROTOR ASSY	TATA spare parts
257315400601	DYNAMO ASSY 160W	TATA spare parts
257315401411	BRUSH BOX ASSY	TATA spare parts
257315401414	HEAT SINK ASSY -VE	TATA spare parts
257315401415	DRIVE END SHIELD	TATA spare parts
257315402501	STATOR ASSY 24V	TATA spare parts
257315402808	O RING	TATA spare parts
257315403100	BEARING D.E.	TATA spare parts
257315403300	BEARING-SRE	TATA spare parts
257315403401	INSERT DE.-TOP	TATA spare parts

257315404601	KIT D END BEARING	TATA spare parts
257315404605	KIT C END BEARING	TATA spare parts
257315404606	REP KIT BRUSH	TATA spare parts
257315404607	KIT D END PLATE	TATA spare parts
257315404610	KIT PULLY 160W	TATA spare parts
257315404622	DIODE AUX 24V 65AMPS	TATA spare parts
257315404902	REGULATOR	TATA spare parts
257315404905	SOLENOID SWITCH & MICO	TATA spare parts
257315407004	PULLEY	TATA spare parts
257315408203	FAN	TATA spare parts
257315409306	BRUSH ALTERNATOR	TATA spare parts
257315409904	REGULATOR	TATA spare parts
257315409913	OVER-RUNNING CLUTCH - MICO	TATA spare parts
257315409914	HEAT SINK ASSY +VE	TATA spare parts
257315409915	HEAT SINK ASSY AUX	TATA spare parts
257323100101	STEERING PUMP BS1/2/3/4	TATA spare parts
257323100102	REPAIR KIT NEW PUMP	TATA spare parts
257323100104	SEAL KIT PUMP	TATA spare parts
257324100103	ENGINE MOUNT PAD FRONT	TATA spare parts
257325103711	CL. HSG.GBS40 W/O ANCOR	TATA spare parts
257325200103	CLUTCH DISC 280 DIA	TATA spare parts
257325200104	CLUTCH DISC REIN 4 MM	TATA spare parts
257325200105	CLUTCH DISC 280 DIA	TATA spare parts
257325200106	CLUTCH DISC 280 DIA	TATA spare parts
257325200107	CLUTCH DISC 280 DIA	TATA spare parts
257325200108	CL.DISC 310 DIA GB40	TATA spare parts
257325200110	CLUTCH DISC 310 DIA	TATA spare parts
257325200601	REP KIT CLUTCH DISC 310D	TATA spare parts
257325206302	CLUTCH LINING 280D 4MM	TATA spare parts
257325206303	CLUTCH LINING 310D	TATA spare parts
257325206306	CLUTCH LINING 310D	TATA spare parts
257325206312	CLUTCH LINING SA 45X5 15	TATA spare parts
257325206314	CLUTCH LINING	TATA spare parts
257325207401	RIVET CLUTCH LINING	TATA spare parts
257325207409	RIVET CARRIER PLATE	TATA spare parts
257325400107	CLUTCH PRES. PLATE	TATA spare parts
257325400108	CL PR PLATE 280 DIA 3 FINGURE REINFORCED	TATA spare parts
257325400111	CL PR PLATE 280 DIA	TATA spare parts
257325400112	CL PR PLATE 280 DIA	TATA spare parts
257325400113	CL PR PLATE 280 DIA	TATA spare parts
257325400114	PROTECTIVE HOUSING	TATA spare parts
257325400115	PROTECTIVE HOUSING	TATA spare parts
257325400116	PROTECTIVE HOUSING	TATA spare parts
257325400117	CL PR PLATE 310 DIA COIL	TATA spare parts
257325400118	HSG W/ANTIRATTLE SPRING	TATA spare parts
257325400121	CL PR PLATE 310 DIA DIAPH	TATA spare parts
257325400122	HSG W/DIAPHRAGM SPRING	TATA spare parts

257325400602	REP KIT REL LEVER&PR SPG	TATA spare parts
257325400603	REP KIT REL LEVER COIL	TATA spare parts
257325400604	REP KIT PR SPRING 310D	TATA spare parts
257325400605	REP KIT MAJ 310D DIAPH CL	TATA spare parts
257325403705	HOUSING	TATA spare parts
257325405103	RELEASE LEVER SE	TATA spare parts
257325405109	RELEASE LEVER	TATA spare parts
257325405112	SUPPORT	TATA spare parts
257325405113	RELEASE LEVER	TATA spare parts
257325406504	ADJUSTING NUT FOR 280DIA.	TATA spare parts
257325406701	PIN	TATA spare parts
257325406702	RELEASE LEVER PIN	TATA spare parts
257325407401	RIVET	TATA spare parts
257325408706	PRESSURE SPRING	TATA spare parts
257325408710	CLUTCH PRESSURE SPRING	TATA spare parts
257325408712	PRESSURE SPRING	TATA spare parts
257325408713	SPRING DIAPHRAM	TATA spare parts
257325603101	CLUTCH RELEASE BEARING	TATA spare parts
257325605101	RELEASE FORK	TATA spare parts
257325605102	RELEASE FORK	TATA spare parts
257325605106	RELEASE FORK	TATA spare parts
257326000105	KIT G S LINK G 40 MODI.	TATA spare parts
257326000106	REPAIR KIT-GEAR SHIFT LEVER	TATA spare parts
257326710101	BRACKET ASSY GBC-30	TATA spare parts
257326800110	ASSY.HOUSING BLOCK	TATA spare parts
257326800115	GEAR SHFT LEVER	TATA spare parts
257326800116	GEAR SHIFT LEVER	TATA spare parts
257326800117	SELECTOR & SHIFTER FORK	TATA spare parts
257326800120	ASSY CON. FLANGE	TATA spare parts
257326800125	TURNING TUBE ASSY	TATA spare parts
257326800126	SUB ASSY.TURNING TUBE	TATA spare parts
257326800127	BRACKET ASSY	TATA spare parts
257326800128	ASSY BRACKET	TATA spare parts
257326800145	ASSY TURNING TUBE-W/O BALL JOINT	TATA spare parts
257326800150	ASSY.G.S.L.W/SEL &SHIFTER YOKE	TATA spare parts
257326803401	GUIDE BUSH	TATA spare parts
257326803704	BKT GEAR SHIFT LEVER	TATA spare parts
257326805101	SELEC. & SHIFTER YOKE-FULL REMOTE BS1-6	TATA spare parts
257326807108	GUSSET	TATA spare parts
257326807901	LINK ROD BS6	TATA spare parts
257326808002	FLANGED SCREW WITH SERRATIONS M10	TATA spare parts
257326808701	SPRING RING G S LEVER	TATA spare parts
257326809906	GEAR SHIFT LEVER	TATA spare parts
257326809907	GEAR SHIFT LEVER	TATA spare parts
257329100101	CLUTCH PEDAL LEVER	TATA spare parts
257329100137	ASSY PEDAL PLATE	TATA spare parts
257329100148	CLUTCH PADEL LEVER	TATA spare parts

257329100150	ASSY.MASTER CYL. COMPLETE (M/S B.I)	TATA spare parts
257329100151	CL MASTER CYL	TATA spare parts
257329100153	CLUTCH SLAVE CYLINDER	TATA spare parts
257329100154	CLUTCH SLAVE CYLINDER	TATA spare parts
257329100159	REP KIT CL MASTER CYL MJR	TATA spare parts
257329100160	REP KIT CL MASTER CYL MNR	TATA spare parts
257329100161	REP KIT CL SLAVE CYL 0154	TATA spare parts
257329100172	FORK ASSY WITH ROD MASTER CYLINDER	TATA spare parts
257329106603	PUSH ROD MASTER CYL	TATA spare parts
257329106701	ANCHOR PIN	TATA spare parts
257329106702	ANCHOR PIN	TATA spare parts
257329108701	RETURN SPRING	TATA spare parts
257329108703	RETURN SPRING BRAKE	TATA spare parts
257329200104	BRAKE LEVER ASSY	TATA spare parts
257329200105	DOUBLE LEVER ASSY	TATA spare parts
257329200121	DOUBLE LEVER BRAKE	TATA spare parts
257329207119	PLATE	TATA spare parts
257329209901	CLEVIS PIN	TATA spare parts
257329209904	PIN	TATA spare parts
257329209905	PIN	TATA spare parts
257329300104	CLUTCH PEDAL LEVER	TATA spare parts
257329300105	CLUTCH CONTROL ROD	TATA spare parts
257329300106	CLUTCH CONTROL ROD	TATA spare parts
257329300135	ASSY.CLUTCH ROD	TATA spare parts
257329300140	CLUTCH ROD ASSY	TATA spare parts
257329303206	PUSH ROD	TATA spare parts
257329308701	CLUTCH RELEASE SPRING	TATA spare parts
257329309205	WASHER	TATA spare parts
257329309905	TURNBUCKLE	TATA spare parts
257329400111	CONTROL LEVER BOX ASSY	TATA spare parts
257329500111	BRACKET ASSY RHD	TATA spare parts
257329500117	CL. M/CYLINDER MTG BRKT	TATA spare parts
257329506701	PIN	TATA spare parts
257330100102	LEVER ACCELERATOR RHD	TATA spare parts
257330100109	PEDAL ACCELERATOR RHD	TATA spare parts
257330100125	LEVER ACCELERATOR	TATA spare parts
257330100147	ASSY PULL ROD	TATA spare parts
257330100150	PULL ROD ASSY	TATA spare parts
257330100151	ACCELERATOR ROD ASSY	TATA spare parts
257330100152	ACCELARETOR PULL ROD ASSY	TATA spare parts
257330106005	THRUST ROD	TATA spare parts
257330109901	BALL END 1510	TATA spare parts
257331000110	FRAME WO.FRT.CPLGLP342/36	TATA spare parts
257331000116	FRAME ASSY LP342/52R	TATA spare parts
257331010127	FRAME ASSY 1510LPT W/CPLG	TATA spare parts
257331010128	FRAME ASSY 1510 LPT	TATA spare parts
257331010133	ASSY FRAME LPT 48	TATA spare parts



257331010186	FRAME ASSY LP/52 NL DAOH	TATA spare parts
257331030103	FRAME ASSY 1210LPT/42	TATA spare parts
257331030107	FRAME ASSY LPT/42 NL DAOH	TATA spare parts
257331030108	FRAME ASSY LPT48	TATA spare parts
257331030116	FRAME ASSY 1210LPE/59	TATA spare parts
257331030130	FRAME ASSY	TATA spare parts
257331040109	FRAME ASSY 1210LP52/60%RO	TATA spare parts
257331040197	FRAME ASSY LPT1612/42SCAM	TATA spare parts
257331050103	FRAME ASSY	TATA spare parts
257331050155	FRAME LP/52 LOW DAOH 50%	TATA spare parts
257331050156	FRAME LOW LP/52 60%ROH	TATA spare parts
257331050161	FRAME 1210LPO/55 LE DAOH	TATA spare parts
257331050171	FRAME ASSY LPT/42 DAOH LE	TATA spare parts
257331050172	FRAME ASSY LPT/48 DAOH LE	TATA spare parts
257331050199	FRAME ASSY 1612/32	TATA spare parts
257331060118	ASSY FRAME LPT 42 SCAM	TATA spare parts
257331060119	FRAME ASSY LPT/48 S-CAM	TATA spare parts
257331060120	FRAME COMP LPT1510/52 SCA	TATA spare parts
257331070117	FRAME ASSY LP/52 SCAM 50%	TATA spare parts
257331070118	FRAME ASSY LP/59 SCAM 50%	TATA spare parts
257331070123	FRAME ASSY LP/52 SCAM 60%	TATA spare parts
257331070142	FRAME ASSY COMPL SCAM	TATA spare parts
257331070143	FRAME ASSY COMPL LPO 60%	TATA spare parts
257331070154	FRAME LPO/55 SCAM 60%ROH	TATA spare parts
257331070163	FRAME LP/59 W/55% ROH LOW	TATA spare parts
257331120142	FRAME 1612SK/36/SCAM	TATA spare parts
257331200102	ENG CROSS MEMBER FRONT	TATA spare parts
257331200107	ENG CROSS MEMBER REAR	TATA spare parts
257331200123	ASSY STOPPER BRKT RH	TATA spare parts
257331200130	ASSY RUBBER BUFFER-FOR REAR AXLE	TATA spare parts
257331200139	RUBBER BUFFER REAR	TATA spare parts
257331207101	SUPPORT BOTTOM	TATA spare parts
257331207104	REINF LH FR SPG BKT RR	TATA spare parts
257331207105	REINF RH FR SPG BKT RR	TATA spare parts
257331207108	SUPPORT LH	TATA spare parts
257331207109	SUPPORT RH	TATA spare parts
257331207123	CROSS MEMBER LP 1510	TATA spare parts
257331207134	REINFORCEMENT FRT. RH BOTTOM	TATA spare parts
257331207135	REINFORCEMENT FRONT LH BOTTOM	TATA spare parts
257331207138	REINFORCEMENT REAR RH-BOTTOM	TATA spare parts
257331207139	REINFORCEMENT REAR LH-BOTTOM	TATA spare parts
257331207144	REINFORCEMENT R H(TOP)	TATA spare parts
257331207145	REINFORCEMENT L H(TOP)	TATA spare parts
257331207146	REINFORCEMENT R H BOTTOM	TATA spare parts
257331207147	REINFORCEMENT LH BOTTOM .	TATA spare parts
257331207150	REINFORCEMENT FRONT RH (BOTTOM)	TATA spare parts
257331207151	REINFORCEMENT FRONT LH BOTTOM	TATA spare parts

257331207167	SUPPORT BOTTOM	TATA spare parts
257331207173	SUPPORT LH	TATA spare parts
257331207174	SUPPORT-RH.-LOWERED ENG	TATA spare parts
257331207179	REINFORCEMENT LH LOWERED	TATA spare parts
257331207180	REINFORCEMENT RH LOWERED	TATA spare parts
257331207187	SUPPORT RH	TATA spare parts
257331207188	SUPPORT LH	TATA spare parts
257331208212	CROSS MEMBER RR SPRING	TATA spare parts
257331208214	GUSSET RH	TATA spare parts
257331208215	GUSSET LH	TATA spare parts
257331208216	CROSS MEMBER	TATA spare parts
257331217109	END CROSS MEMBER	TATA spare parts
257331217110	END CROSS MEMBER	TATA spare parts
257331217170	END CROSS MEMBER( 195 DEEP TAIL END )	TATA spare parts
257332100107	SEALING RING RUBBER	TATA spare parts
257332100110	LEAF SPRING 1ST W/BUSH	TATA spare parts
257332100111	LEAF SPRING 1ST W/BUSH	TATA spare parts
257332100113	KIT SPRING PIN 1210LP/LPT	TATA spare parts
257332100115	LINK ROD BOTTOM	TATA spare parts
257332100119	SEALING RING W/SPACER	TATA spare parts
257332104202	SPRING CLIP	TATA spare parts
257332104203	SPRING CLIP	TATA spare parts
257332104204	SPRING CLIP	TATA spare parts
257332106701	SPRING PIN FRT	TATA spare parts
257332107701	SEALING RING	TATA spare parts
257332108601	SPACER	TATA spare parts
257332108605	SPACER	TATA spare parts
257332204203	U- BOLT	TATA spare parts
257332300112	SHOCK ABSORBER FRONT	TATA spare parts
257332300113	SHOCK ABSORBER FRONT	TATA spare parts
257332300117	SHOCK ABSORBER FRONT	TATA spare parts
257332300122	SHOCK ABSORBER FRONT	TATA spare parts
257332300139	SHOCK ABSORBER FRONT	TATA spare parts
257332303401	JOINT BUSH RUBBER TOP	TATA spare parts
257332303402	JOINT BUSH LOWER	TATA spare parts
257332303403	JOINT BUSH RUBBER BOTTOM	TATA spare parts
257332306701	PIN MOUNTING	TATA spare parts
257332307501	JOINT BUSH RUBBER	TATA spare parts
257332307502	RUBBER BUSH M/S GABRIEL(S-850149)	TATA spare parts
257332307710	JOINT BUSH RUBBER TOP	TATA spare parts
257332308201	LOCKING SHEET	TATA spare parts
257332400101	REAR SPRING ASSY W/AUX	TATA spare parts
257332400103	LEAF SPRING 1ST W/BUSH	TATA spare parts
257332400103DF	MAIN LEAF REAR W/BUSH-TATA 1210SE/1612	TATA spare parts
257332400104	REAR SPRING ASSY	TATA spare parts
257332400114	REAR SPRING ASSY	TATA spare parts
257332400115	LEAF SPRING 1ST W/BUSH RR	TATA spare parts

257332400118	REAR SPRING ASSY	TATA spare parts
257332400119	SEALING RING	TATA spare parts
257332400123	KIT SPRING PIN 1210 RR	TATA spare parts
257332403204	CENTRE PIN M12 X 181 X 11	TATA spare parts
257332403205	CENTRE PIN	TATA spare parts
257332403301	SLIDE SUPPORT	TATA spare parts
257332404201	CLAMP OUTER	TATA spare parts
257332404202	SPRING CLAMP FOR AUX SPG	TATA spare parts
257332404205	U CLAMP	TATA spare parts
257332404209	U CLAMP	TATA spare parts
257332404213	SPRING CLAMP (BOTTOM)	TATA spare parts
257332404214	CLAMP	TATA spare parts
257332404223	SPRING CLIP	TATA spare parts
257332404224	SPRING CLIP	TATA spare parts
257332404225	SPRING CLIP BS6	TATA spare parts
257332407101	LEAF SPRING 1ST RR	TATA spare parts
257332407102	LEAF SPRING 2ND RR	TATA spare parts
257332407102DF	SECOND LEAF REAR - TATA 1210SE/1612	TATA spare parts
257332407103	LEAF SPRING 3RD RR	TATA spare parts
257332407103DF	THIRD LEAF REAR - TATA 1210SE/1612	TATA spare parts
257332407104	LEAF SPRING 4TH RR	TATA spare parts
257332407104DF	FOURTH LEAF REAR - TATA 1210SE/1612	TATA spare parts
257332407105	LEAF SPRING 5TH RR	TATA spare parts
257332407106	LEAF SPRING 6TH RR	TATA spare parts
257332407107	LEAF SPRING 7TH RR	TATA spare parts
257332407108	LEAF SPRING 8TH RR	TATA spare parts
257332407109	LEAF SPRING 9TH RR	TATA spare parts
257332407110	LEAF SPRING 10TH RR	TATA spare parts
257332407111	LEAF SPRING 11TH RR	TATA spare parts
257332407112	LEAF SPRING AUX 1ST	TATA spare parts
257332407112DF	MAIN LEAF-AUX HELPER - TATA 1210SE/1612	TATA spare parts
257332407113	LEAF SPRING 2ND AUX	TATA spare parts
257332407113DF	SECOND LEAF-AUX HELPER - TATA 1210SE/161	TATA spare parts
257332407114	LEAF SPRING 3RD AUX	TATA spare parts
257332407114DF	THIRD LEAF-AUX HELPER - TATA 1210SE/1612	TATA spare parts
257332407115	LEAF SPRING 4TH AUX	TATA spare parts
257332407115DF	FOURTH LEAF-AUX HELPER - TATA 1210SE/161	TATA spare parts
257332407116	LEAF SPRING 5TH RR	TATA spare parts
257332407182	LEAF SPRING 2ND RR	TATA spare parts
257332407183	LEAF SPRING 3RD RR	TATA spare parts
257332407184	LEAF SPRING 4TH RR	TATA spare parts
257332407185	LEAF SPRING 5TH RR	TATA spare parts
257332407186	LEAF SPRING 6TH RR	TATA spare parts
257332407187	LEAF SPRING 7TH RR	TATA spare parts
257332407188	LEAF SPRING 8TH RR	TATA spare parts
257332407189	LEAF SPRING 9TH RR	TATA spare parts
257332407190	LEAF SPRING 10TH RR	TATA spare parts

257332407191	LEAF SPRING 3RD RR	TATA spare parts
257332407192	LEAF SPRING 3RD RR	TATA spare parts
257332407193	LEAF SPRING 4TH RR	TATA spare parts
257332407194	LEAF SPRING 5TH RR	TATA spare parts
257332407195	SIXTH LEAF 0114/SEVENTH LEAF 0118	TATA spare parts
257332407196	LEAF SPRING 7TH RR	TATA spare parts
257332407197	EIGHTS LEAF 0114/NINTH LEAF 0118	TATA spare parts
257332407198	NINTH LEAF 0114/TENTH LEAF 0118	TATA spare parts
257332407199	TENTH LEAF 0114/ELEVENTH LEAF 0118	TATA spare parts
257332408601	SPACER	TATA spare parts
257332410105	REAR SPRING ASSY 2 STAGE	TATA spare parts
257332410106	ASSY FIRST LEAF SPRING W/BUSH	TATA spare parts
257332417170	LEAF SPRING 2ND	TATA spare parts
257332417171	LEAF SPRING 3RD	TATA spare parts
257332417172	LEAF SPRING 4TH REAR	TATA spare parts
257332417173	LEAF SPRING 5TH REAR	TATA spare parts
257332417174	LEAF SPRING 6TH REAR	TATA spare parts
257332417175	LEAF SPRING 7TH REAR	TATA spare parts
257332417176	LEAF SPRING 8TH REAR	TATA spare parts
257332417177	LEAF SPRING 9TH REAR	TATA spare parts
257332417178	LEAF SPRING 10TH REAR	TATA spare parts
257332417179	LEAF SPRING 11TH REAR	TATA spare parts
257332417180	LEAF SPRING 12TH REAR	TATA spare parts
257332600102	ASSY. SHOCK ABSORBER BRAC	TATA spare parts
257332600103	ASYSHQCKABSQRBERBRACKET-R	TATA spare parts
257332600106	SHOCK ABSORBER REAR	TATA spare parts
257332600107	SHOCK ABSORBER REAR	TATA spare parts
257332600108	BKT S/ABS RH REAR BOTTOM	TATA spare parts
257332600109	BKT S/ABS LH REAR BOTTOM	TATA spare parts
257332600111	BKT S/ABS RH BOTTOM	TATA spare parts
257332600112	BKT S/ABS LH BOTTOM	TATA spare parts
257332600113	SHOCK ABSORBER REAR	TATA spare parts
257332600114	SHOCK ABSORBER REAR	TATA spare parts
257332600125	RR SHOCK ABSORBER LP/LPO EXTENDED BS1- 4	TATA spare parts
257332600125AE	REAR SHOCK ABSORBER 713	TATA spare parts
257332600130	REAR SHOCK ABSORBER (LP/LPO) EXTENDED LE	TATA spare parts
257332600132	REAR SHOCK ABSORBER (LP/LPO) EXTENDED LE	TATA spare parts
257332600136	REAR SHOCK ABSORBER (LP/LPO) EXTENDED LE	TATA spare parts
257332600145	ASSY. SHOCK ABSORBER BKT. R.H. BOTTOM	TATA spare parts
257332600146	ASSY. SHOCK ABSORBER BKT. L.H. BOTTOM	TATA spare parts
257332603402	JOINT BUSH	TATA spare parts
257332603501	BOSS BS6	TATA spare parts
257332603703	BKT S/ABS RH BOTTOM	TATA spare parts
257332603704	BKT S/ABS LH REAR BOTTOM	TATA spare parts
257332603705	REAR SHOCK ABSORBER BKT. L.H.BOTTOM	TATA spare parts
257332603706	REAR SHOCK ABSORBER BKT. R.H. BOTTOM	TATA spare parts
257332605101	JOINT BUSH RUBBER	TATA spare parts

257332606101	LOCKING PLATE	TATA spare parts
257332607501	JOINT BUSH RUBBER	TATA spare parts
257332607502	JOINT BUSH RUBBER	TATA spare parts
257332608601	SPACER	TATA spare parts
257332800117	ASSY.CONNECTING LINK	TATA spare parts
257332900111	ASSY BRACKET R H	TATA spare parts
257332900112	ASSY. BRACKET L.H.	TATA spare parts
257332900133	ASSY. BRACKET	TATA spare parts
257332900136	ASSY.A.R.B. - REAR WITH CRMP.EYE PIECE	TATA spare parts
257333000102	FRONT AXLE ASSY W/BRK RHD	TATA spare parts
257333000116	FRONT AXLE W/BRK DAOH RHD	TATA spare parts
257333000121	FRONT AXLE ASSY W/BR SCAM	TATA spare parts
257333000123	FRONT AXLE ASSY W/BR SCAM	TATA spare parts
257333200113	STUB AXLE SCAM STD	TATA spare parts
257333200114	STUB AXLE SCAM STD1	TATA spare parts
257333200117	STUB AXLE STD P/STRG	TATA spare parts
257333203101	BEARING NEEDLE CAGE	TATA spare parts
257333203102	TAPER ROLLER THRUST BEARING	TATA spare parts
257333203106	TAPER ROLLER BEARING	TATA spare parts
257333203109	TAPER ROLLER THRUST BRG.	TATA spare parts
257333203116	TAPER ROLLER THRUST BEARING	TATA spare parts
257333203124	TAPER ROLLER BEARING	TATA spare parts
257333203125	TAPER ROLLER BEARING	TATA spare parts
257333403106	TAPER ROLLER BEARING OUTE	TATA spare parts
257333403701	FRONT HUB COVER	TATA spare parts
257333403703	FRONT HUB COVER	TATA spare parts
257333408602	SPACER TUBE	TATA spare parts
257335000103	REAR AXLE ASSY RA108 W/BR	TATA spare parts
257335000118	REAR AXLE ASSY LPT/42	TATA spare parts
257335000142	ASSY.REAR AXLE COMP.RHD.C	TATA spare parts
257335000143	ASSY.REAR AXLE COMP.LHD.C	TATA spare parts
257335100112	RR AXLE HSG LP SALISBURY	TATA spare parts
257335100113	RR AXLE HSG LP SALISBURY	TATA spare parts
257335100134	REAR AXLE HSG RA108 BANJO	TATA spare parts
257335100183	REAR AXLE HSG RA 108	TATA spare parts
257335100192	ASSY COVER	TATA spare parts
257335104212	U CLAMP REAR 325 LG	TATA spare parts
257335104214	U CLAMP	TATA spare parts
257335105008	FLANGE	TATA spare parts
257335105104	SUPPORT BLOCK HAND BR	TATA spare parts
257335105302	GASKET	TATA spare parts
257335105303	GASKET COVER	TATA spare parts
257335105303AE	GSKT (RR AXLE HSG. COVER) -713/5	TATA spare parts
257335108201	OIL SLINGER	TATA spare parts
257335108603	PRESSURE RING RH SERRATIONS-YELLOW MARK	TATA spare parts
257335108604	PRESSURE RING LH SERRATIONS-RED MARK	TATA spare parts
257335108605	PRESSURE RING LH	TATA spare parts

257335110106	ASSY. CARRIER HOUSING BS1/2/3/4	TATA spare parts
257335110106AE	ASSY CARRIER HOUSING 1415 715	TATA spare parts
257335113702	PLUMMER BLOCK COVER	TATA spare parts
257335115302	GASKET RA108 BS4	TATA spare parts
257335115302AE	GASKET (FOR CARRIER) 713 715	TATA spare parts
257335300101	PIN ADJUSTING	TATA spare parts
257335300102	CWP SET 48/7 OERL 1210/1510/1313	TATA spare parts
257335300105	HOUSING DIFFERENTIAL	TATA spare parts
257335300109	DIFFERENTIAL ASSY WITH LOCK	TATA spare parts
257335300110	ASSY DIFFERENTIAL HOUSING	TATA spare parts
257335300122	ASSY. CROWN & PINION (45/7 GLEASON) BS3	TATA spare parts
257335303102	BEARING CYL ROLLER	TATA spare parts
257335303103	BEARING TAPER ROLLER	TATA spare parts
257335303105	BEARING CYL ROLLER	TATA spare parts
257335303106	BEARING CYL ROLLER	TATA spare parts
257335303107	BEARING TAPER ROLLER	TATA spare parts
257335303108	BEARING TAPER ROLLER	TATA spare parts
257335303109	CYL ROLLER BRG? NU307MNW BS1/2/3/4/6	TATA spare parts
257335305401	PINION - CWP:48/7-0102OR	TATA spare parts
257335305410	PINION - CWP:45/7-0122GL	TATA spare parts
257335306501	THREADED RING RH	TATA spare parts
257335307705	OIL SEAL BS1/2/3/4	TATA spare parts
257335307705AE	OIL SEAL DBLE LIP -713-715	TATA spare parts
257335308001	PIN ADJUSTING	TATA spare parts
257335308602	SPACER	TATA spare parts
257335309202	THRUST WASHER 1.95MM	TATA spare parts
257335309203	THRUST WASHER 2.00 MM	TATA spare parts
257335309204	TH WASHER 2.05 MM 102X67	TATA spare parts
257335309205	TH WASHER 2.10 MM 102X67	TATA spare parts
257335600102	HUB REAR ASSY	TATA spare parts
257335600104	ASY RR HUB	TATA spare parts
257335603101	BEARING TAPER ROLLER	TATA spare parts
257335603103	BEARING TAPER ROLLER	TATA spare parts
257335603107	TAPER ROLLER BEARING OUTER	TATA spare parts
257335603111	TAPER ROLLER BRG 32213 BS1/2/3/4	TATA spare parts
257335603111AE	OUTER BRG TAPERED ROLLER -713	TATA spare parts
257335604701	COVER REAR HUB	TATA spare parts
257335605301	GASKET	TATA spare parts
257335606101	LOCKING PLATE	TATA spare parts
257335606506	LOCKING RING	TATA spare parts
257335608202	OIL CATCHER	TATA spare parts
257335608203	LOCK WASHER	TATA spare parts
257335608204	OIL CATCHER	TATA spare parts
257335608601	SPACER TUBE	TATA spare parts
257335608602	SPACER	TATA spare parts
257335608605	SPACER	TATA spare parts
257335707901	REAR AXLE SHAFT	TATA spare parts

257335707902	REAR AXLE SHAFT RA 108	TATA spare parts
257340100103	ASSY.WHEEL DISC & RIM 7 X 20	TATA spare parts
257340107101	SPACER	TATA spare parts
257340300102	MOUNTING BRACKET	TATA spare parts
257340300104	HOLDING BRACKCET	TATA spare parts
257340300106	WIRE ROPE	TATA spare parts
257340300111	SHAFT SPARE WHEEL CARRIER	TATA spare parts
257340300112	WINCH TYPE SP WH CARRIER	TATA spare parts
257340300113	HANDLE SPARE WH CARRIER	TATA spare parts
257340300117	ASSY SPARE WHEEL CARRIER	TATA spare parts
257340306301	FRICTION PAD	TATA spare parts
257340306703	PIN MS 4DX25 SOFT	TATA spare parts
257340306705	PIN	TATA spare parts
257340307103	REINFORCEMENT	TATA spare parts
257340308401	SLEEVE BS6	TATA spare parts
257340309903	FERRULE	TATA spare parts
257341100101	PROPELLER SHAFT	TATA spare parts
257341100104	U JOINT FORK ASSY	TATA spare parts
257341100104AE	ASSY U J FORK LPA 1415/LPA 713	TATA spare parts
257341100106	ASSY PROTECTIVE CAP	TATA spare parts
257341100129	P SHAFT W/C BRG 70X1348	TATA spare parts
257341100331	ASSY.PROP.SHAFT FRONT(76D	TATA spare parts
257341105115	UNIVERSAL JOINT SHORT FORK	TATA spare parts
257341105115AE	UJ SHORT FRK F & R PROP SFT)-715	TATA spare parts
257341110106	PROP SHAFT MIDDLE W/O CB	TATA spare parts
257341110110	COUPLING FLANGE	TATA spare parts
257341110112	PROP SHAFT FR W/O CB	TATA spare parts
257341110115	CENTRE BEARING ASSY	TATA spare parts
257341110117	PROP SHAFT MIDDLE W/C BRG	TATA spare parts
257341110118	PROP SHAFT MIDDLE W/O CB	TATA spare parts
257341110121	PROP SHAFT MIDDLE W/O CB	TATA spare parts
257341110123	P SHAFT FR W/C BRG 70X535	TATA spare parts
257341110124	P SHAFT FR W/O CBR 70X535	TATA spare parts
257341110127	P SHAFT FR W/O CB 70X1135	TATA spare parts
257341110129	P SHAFT MID W/C B 70X1348	TATA spare parts
257341110130	P SHAFT FR W/O CB 70X1348	TATA spare parts
257341110133	PROPELLER SHAFT FRONT	TATA spare parts
257341110161	PROP SHAFT FR W/CEN BRG	TATA spare parts
257341110162	PROP SHAFT FRONT 70X535	TATA spare parts
257341110163	ASSY.PROP.SHAFT TUBE FRON	TATA spare parts
257341110165	ASY.PROP.SHAFT FRT.SPLIT	TATA spare parts
257341110168	P SHAFT FR W/C B 70X585	TATA spare parts
257341110176	P SHAFT FR W/C B 70X1348	TATA spare parts
257341110177	ASSY.PROP.SHAFT FRONT 70X	TATA spare parts
257341110179	ASSY PROP SFT FRONT W/CB	TATA spare parts
257341110180	PROP SHAFT FR 70X1247	TATA spare parts
257341110182	PROP SHAFT W/CEN BRG	TATA spare parts

257341110183	PROP SHAFT FR 70X3X1197	TATA spare parts
257341110285	PROP SHAFT FR G40 70X465	TATA spare parts
257341110291	PROP SHAFT FR G40 70X1127	TATA spare parts
257341110294	PROP SHAFT FR G30 70X1177	TATA spare parts
257341110297	P SHAFT MIDW/CBRG 70X1348	TATA spare parts
257341110298	PROPELLER SHAFT FRONT	TATA spare parts
257341110301	PROP SHAFT FR LE 70X486	TATA spare parts
257341110302	PROPELLER SHAFT FRONT	TATA spare parts
257341110304	PROP SHAFT FR LE 70X1148	TATA spare parts
257341110305	PROP SHAFT FR 70X1148	TATA spare parts
257341110308	PROP SHAFT FRONT	TATA spare parts
257341110310	PROP SHAFT FR LE 70X435	TATA spare parts
257341110311	PROPELLER SHAFT FRONT	TATA spare parts
257341110319	PROP SHAFT W/CBRG 70X1247	TATA spare parts
257341110328	P SHAFT FRT W/CB 76X424	TATA spare parts
257341110331	P SHAFT FR W/CBRG 76X1086	TATA spare parts
257341110340	P SHAFT MIDW/CBRG 76X1317	TATA spare parts
257341110341	PROP SHAFT MID W/C B 76D	TATA spare parts
257341110393	PROP SHAFT FRONT 76X1311	TATA spare parts
257341110394	PROP SHAFT FRONT 76DIA	TATA spare parts
257341110395	ASSY.PROP.SHAFT FRONT	TATA spare parts
257341110396	ASSY.PROP.SHAFT FRONT(76X	TATA spare parts
257341110503	P SHAFT FR W/C BRG 76X398	TATA spare parts
257341110504	P SHAFT FR W/CBRG 76X1057	TATA spare parts
257341110505	P SHAFT MIDW/CBRG 76X1311	TATA spare parts
257341110506	PROP SHAFT FRONT W/C BRG	TATA spare parts
257341110508	PROP SHAFT MID 76X4X1489	TATA spare parts
257341110510	P SHAFT FR W/CBRG 76X1297	TATA spare parts
257341110511	PROP SHAFT FRONT 1297	TATA spare parts
257341110515	PROP SHAFT FRT 76X1057	TATA spare parts
257341120101	PROP SHAFT REAR 70X3X1202	TATA spare parts
257341120109	ASSY. UNIVERSAL JOINT COMP. BS1/2/3/4	TATA spare parts
257341120109AE	UNIVERSAL JOINT LONG FORK 715	TATA spare parts
257341120155	PROP SHAFT RR 70X3X1772	TATA spare parts
257341120159	PROP SHAFT REAR G30 1267L	TATA spare parts
257341120161	PROPELLER SHAFT REAR	TATA spare parts
257341120181	PROPELLER SHAFT REAR	TATA spare parts
257341300108	BKT CENTRE BEARING	TATA spare parts
257341300109	BRACKET ASSY TOP	TATA spare parts
257341300110	COUPLING FLANGE	TATA spare parts
257341300111	BKT CENTRE BEARING CAST	TATA spare parts
257341300112	BKT CENTRE BEARING FABR.	TATA spare parts
257341300114	COUPLING FLANGE	TATA spare parts
257341300115	ASSY. CENTER BEARING COMP. BS1/2/3/4	TATA spare parts
257341300116	SPACER	TATA spare parts
257341300118	CEN BRG ASSY W/DUST SEAL	TATA spare parts
257341300119	COUPLING FLANGE	TATA spare parts



257341303301	BKT CENTRE BEARING	TATA spare parts
257341303306	BKT CENTRE BEARING	TATA spare parts
257341303307	BKT CENTRE BEARING	TATA spare parts
257341303308	BRACKET	TATA spare parts
257341303309	BRACKET C.B.MTG.	TATA spare parts
257341303310	BRACKET	TATA spare parts
257341303311	BKT CENTRE BEARING	TATA spare parts
257341304202	CLAMP	TATA spare parts
257341307105	SPACER	TATA spare parts
257341307106	SPACER PLATE HONEY COMB	TATA spare parts
257341307501	RUBBER CENTRE BEARING	TATA spare parts
257341307503	RUBBER CEN BRG OLD 76D	TATA spare parts
257341307504	RUBBER CEN BRG SPLIT 76D	TATA spare parts
257341307505	RUBBER CEN BRG HONEY COMB BS1/2/3/4	TATA spare parts
257341308201	PROTECTIVE CAP	TATA spare parts
257341308208	PROTECTIVE CAP	TATA spare parts
257341308209	PROTECTIVE CAP	TATA spare parts
257341308210	RETAINER	TATA spare parts
257341308216	DUST SEAL RETAINER	TATA spare parts
257341308217	SPACER PLATE	TATA spare parts
257342100103	ADJUSTER ECCENTRIC FRT	TATA spare parts
257342100123	FRT AXLE BRAKE RH	TATA spare parts
257342100131	FRT AXLE BRAKE LH	TATA spare parts
257342100132	FRT AXLE BRAKE RH	TATA spare parts
257342100133	FRT AXLE BRAKE LH	TATA spare parts
257342100134	BRK ASSY RH WT DUST COVER & MTG FASTENER	TATA spare parts
257342100135	SLACK ADJ FRONT	TATA spare parts
257342100136	BRAKE CHAMBER FRT LH	TATA spare parts
257342100137	BRAKE CHAMBER FRT RH	TATA spare parts
257342100146	ASSY WHEEL CYL 44.45D	TATA spare parts
257342100147	KIT BR O/H MNR FRONT	TATA spare parts
257342100148	KIT BR SER MNR FR/RR	TATA spare parts
257342100149	KIT BR SPRING SCAM FR/RR	TATA spare parts
257342100150	KIT CAMSHAFT SER FRT	TATA spare parts
257342100151	BRAKE SHOE-LINING & ROLLE	TATA spare parts
257342100152	ASSY. BRAKE CHAMBER L.H.	TATA spare parts
257342100153	ASSY. BRAKE CHAMBER R.H.	TATA spare parts
257342100156	FLANGE TUBE & BKT LH	TATA spare parts
257342100157	FLANGE TUBE & BKT RH	TATA spare parts
257342100160	SLACK ADJUSTER. FRT (MANUAL) BS2/3	TATA spare parts
257342100161	SLACK ADJUSTER	TATA spare parts
257342100168	REP KIT SLACKADJUSTER	TATA spare parts
257342100173	ASSY.SLACK ADJUSTER	TATA spare parts
257342100174	SLACK ADJUSTER	TATA spare parts
257342100179	BR SHOE LNG & ROLLER	TATA spare parts
257342100180	SPIDER BRAKE LH	TATA spare parts
257342100181	SPIDER BRAKE RH	TATA spare parts

257342100182	DUST SHIELD	TATA spare parts
257342100183	KIT BR OVERHAUL MNR FR	TATA spare parts
257342100184	KIT BR LINING FRT	TATA spare parts
257342100202	SPIDER ASSY (WITH BUSHES & SEAL) RH	TATA spare parts
257342100203	FRONT BRAKE SPIDER ASSEMBLY WITH SE	TATA spare parts
257342103201	HEX BOLT	TATA spare parts
257342103206	HEX BOLT	TATA spare parts
257342103207	HEX BOLT	TATA spare parts
257342103212	HEX BOLT M16 X 1.5 X 55	TATA spare parts
257342103213	HEX BOLT M16 X 1.5 X 50	TATA spare parts
257342103215	BOLT BRAKE M16X1.5 10.9 41.4	TATA spare parts
257342103216	BOLTBRAKE M16 X1.5 10.9 87.5	TATA spare parts
257342103217	HEX BOLT -M16X1.5X70 IS1364 CLASS 10.9	TATA spare parts
257342103301	BKT C/SHAFT & CHMBER LH	TATA spare parts
257342103302	BKT C/SHAFT & CHMBER RH	TATA spare parts
257342103401	BUSH ANCHOR PIN	TATA spare parts
257342103401AE	BUSHING - ANCHOR PIN 1628 1828	TATA spare parts
257342103402	BUSH C/SHAFT SPIDER & BKT	TATA spare parts
257342103403	PIN BR SHOE RETURN SPRING	TATA spare parts
257342103404	BUSH FULCRUM PIN	TATA spare parts
257342103405	DERLIN BUSH	TATA spare parts
257342103406	BUSH CAM END	TATA spare parts
257342103407	BUSH CAM END	TATA spare parts
257342103408	BRAKE ASSY -BUSH ABUTMENT END BS4	TATA spare parts
257342103701	BRAKE DRUM FRONT	TATA spare parts
257342103702	BRAKE ASSY -TORQUE PLATE FRONT LH	TATA spare parts
257342103703	BRAKE ASSY -TORQUE PLATE FRONT RH	TATA spare parts
257342103704	BRAKE ASSY -TORQUE PLATE FRONT LH	TATA spare parts
257342103705	BRAKE ASSY -TORQUE PLATE FRONT RH	TATA spare parts
257342103711	BRAKE DRUM FRONT	TATA spare parts
257342103712	SPIDER BRAKE LH FRONT	TATA spare parts
257342103713	SPIDER BRAKE RH FRONT	TATA spare parts
257342104301	RETAINER SHOE ROLLER	TATA spare parts
257342104302	CIRCLIP	TATA spare parts
257342104303	CIRCLIP	TATA spare parts
257342105301	GASKET CHAMBER BKT	TATA spare parts
257342106001	LINK BRAKE SHOE	TATA spare parts
257342106003	LINK BRAKE SHOE	TATA spare parts
257342106302	BRAKE LINING	TATA spare parts
257342106702	PIN	TATA spare parts
257342106703	COLLARED PIN	TATA spare parts
257342106704	SPRING PIN	TATA spare parts
257342106706	PIVOT PIN FRONT	TATA spare parts
257342106713	PIN	TATA spare parts
257342106714	PIN	TATA spare parts
257342106718	PIN	TATA spare parts
257342106719	COLLARED PIN STRG SIDE	TATA spare parts

257342106720	COLLARED PIN	TATA spare parts
257342106721	COLLARED PIN	TATA spare parts
257342106722	COLLARED PIN	TATA spare parts
257342106723	ANCHOR PIN BRAKE SHOE	TATA spare parts
257342106724	FULCRUM PIN	TATA spare parts
257342106724AE	FULCRUM PIN 715	TATA spare parts
257342106802	PLUG DUST SHIELD	TATA spare parts
257342106802AE	PLUG-DUST SHIELD 1828	TATA spare parts
257342107401	RIVET S CAM BR LINING	TATA spare parts
257342107404	BRASS RIVET FOR FRONT AND REAR BK ASSY.	TATA spare parts
257342107405	RIVET BRAKE LINING	TATA spare parts
257342107405AE	RIVET BRAKE LINER 2523 1828	TATA spare parts
257342107501	GROMMET DUST COVER	TATA spare parts
257342107701	SEAL CAM SHAFT	TATA spare parts
257342107701AE	SEAL - CAM SHAFT 1628 1828	TATA spare parts
257342107702	O RING	TATA spare parts
257342107702AE	O -RING 715	TATA spare parts
257342107703	DIAPHRAM	TATA spare parts
257342107705	DELTRIN SLEEVE	TATA spare parts
257342107706	DELTRIN BUSH	TATA spare parts
257342107801	OIL SEAL	TATA spare parts
257342107802	OIL SEAL	TATA spare parts
257342107901	CAMSHAFT LH	TATA spare parts
257342107902	CAM SHAFT RH	TATA spare parts
257342107903	ROLLER BRAKE SHOE	TATA spare parts
257342107904	CAM SHAFT FRT LH	TATA spare parts
257342107905	CAM SHAFT FRT RH	TATA spare parts
257342107906	CAM SHAFT FRT LH	TATA spare parts
257342107907	CAM SHAFT FRT RH	TATA spare parts
257342108001	COLLARED PIN	TATA spare parts
257342108005	CAP SCREW DUST SHIELD	TATA spare parts
257342108006	SET SCREW M18 X 1.25	TATA spare parts
257342108007	CAP SCREW CHAMBER BKT	TATA spare parts
257342108008	CAP SCREW DUST SHIELD	TATA spare parts
257342108010	BOLT M12X1.75	TATA spare parts
257342108201	OIL BAFFLE	TATA spare parts
257342108207	DUST SHIELD	TATA spare parts
257342108208	DUST SHIELD	TATA spare parts
257342108210	DUST COVER BOTTOM	TATA spare parts
257342108211	DUST COVER TOP	TATA spare parts
257342108213	DUST SHIELD	TATA spare parts
257342108301	SHIM FOR SCAM SHAFT	TATA spare parts
257342108302	SHIM FOR SCAM SHAFT	TATA spare parts
257342108303	SHIM - 0.3MM	TATA spare parts
257342108304	KTMS FRONT BRAKE CHAMBER BRACKET ASSEMB	TATA spare parts
257342108305	KTMS FRONT BRAKE CHAMBER BRACKET ASSEMB	TATA spare parts
257342108401	SLEEVE ADJ ECC CENTER	TATA spare parts

257342108402	SLEEVE ADJ SCREW	TATA spare parts
257342108405	SLEEVE SLACK ADJ	TATA spare parts
257342108601	SPACER	TATA spare parts
257342108701	THRUST SPRING	TATA spare parts
257342108702	SPRING BRAKE SHOE RETURN	TATA spare parts
257342108703	SPRING BRAKE SHOE RETURN BS1/2/3/4	TATA spare parts
257342108704	RET SPRING FULCRUM END	TATA spare parts
257342108705	RET SPRING CAM END	TATA spare parts
257342108708	SPRING BR SHOE RETAINER	TATA spare parts
257342109203	CAM HEAD WASHER	TATA spare parts
257342109204	WASHER BKT CAP SCREW	TATA spare parts
257342109205	WASHER C/SHAFT 205MM	TATA spare parts
257342109206	WASHER 1.4MM	TATA spare parts
257342109207	WASHER 0.8MM	TATA spare parts
257342109208	WASHER	TATA spare parts
257342109209	WASHER	TATA spare parts
257342109210	SPRING WASHER BI	TATA spare parts
257342109211	WASHER CAM HEAD	TATA spare parts
257342109211AE	WASHER CAM HEAD -1828	TATA spare parts
257342109212	WASHER HARD 2.5 MM	TATA spare parts
257342109214	WASHER	TATA spare parts
257342109901	FITTING GREASE CHAMBER	TATA spare parts
257342109902	ROLLER	TATA spare parts
257342110103	ANCHOR PLATE LH	TATA spare parts
257342110104	ANCHOR PLATE RH	TATA spare parts
257342110105	REP KIT-WORM SHAFT	TATA spare parts
257342110111	ANCHOR PLATE LH FRONT	TATA spare parts
257342110113	ANCHOR PLATE LH FRONT	TATA spare parts
257342110114	ANCHOR PLATE RH FRONT	TATA spare parts
257342110148	BRAKE SHOE LINING & ROLLER ASSY BS1- 4	TATA spare parts
257342110159	SPIDER ASSY W/BUSH & SEAL LH ABS	TATA spare parts
257342110160	SPIDER ASSY W/BUSH & SEAL RH ABS	TATA spare parts
257342110161	MINOR O\H KIT FRONT BRK	TATA spare parts
257342110162	BRAKE LINERS KIT FRONT	TATA spare parts
257342110169	BRACKET MOUNTING FASTENERS KIT-FRONT	TATA spare parts
257342113210	BOLT M14X2	TATA spare parts
257342113301	BKT RETURN SPRING	TATA spare parts
257342113701	TORQUE PLATE LH	TATA spare parts
257342113702	TORQUE PLATE RH	TATA spare parts
257342117101	SUPPORT BRAKE FRT	TATA spare parts
257342118209	REINFORCEMENT	TATA spare parts
257342118210	DUST COVER BOTTOM	TATA spare parts
257342118211	DUST COVER TOP	TATA spare parts
257342118212	DUST COVER TOP	TATA spare parts
257342118213	DUST COVER BOTTOM	TATA spare parts
257342119201	SPRING WASHER 14D	TATA spare parts
257342120102	WHEEL CYL.44.45D	TATA spare parts

257342120103	WHEEL CYL.44.45D	TATA spare parts
257342120108	REP KIT WHEEL CYLINDER	TATA spare parts
257342120109	REP KIT WHEEL CYLINDER	TATA spare parts
257342125609	SLOTTED PIN	TATA spare parts
257342126601	PISTON FR WHEEL CYL	TATA spare parts
257342126602	PUSH ROD	TATA spare parts
257342126603	PISTON	TATA spare parts
257342126606	PLUNGER	TATA spare parts
257342126607	SLOTTED PIN	TATA spare parts
257342127701	BOOT WIDER BRAKE	TATA spare parts
257342127702	DUST COVER	TATA spare parts
257342128201	METAL COVER	TATA spare parts
257342130106	BR SHOE W/LIN STD FRT	TATA spare parts
257342130107	BR SHOE W/LIN RS1 FRT	TATA spare parts
257342130108	BR SHOE W/LIN RS2 FRT	TATA spare parts
257342130110	ASSY BRAKESHOE W LINING	TATA spare parts
257342130116	BR SHOE W/LIN STD FRT	TATA spare parts
257342130117	BR SHOE W/LIN RS1 FRT	TATA spare parts
257342130123	BR SHOE W/LIN FRT SCAM	TATA spare parts
257342130124	KIT-BR LINING FRT STD	TATA spare parts
257342130125	KIT BR LINING RS1 FRT	TATA spare parts
257342130126	KIT BR LINING RS2 FRT	TATA spare parts
257342130131	LINED SHOE ASSY REAR	TATA spare parts
257342130133	LINED SHOE ASSY	TATA spare parts
257342130134	LINED SHOE FRONT	TATA spare parts
257342130136	LINED SHOE ASSY	TATA spare parts
257342130202	BRACKET CAMSHAFT S-CAM	TATA spare parts
257342130205	LINED SHOE FRONT	TATA spare parts
257342130206	ASSY. LINED SHOE	TATA spare parts
257342130207	BRAKE ASSY -KIT LINED SHOE 410X180	TATA spare parts
257342130208	BRAKE ASSY -KIT LINED SHOE 410X180	TATA spare parts
257342130210	BRAKE ASSY -KIT LINED SHOE 410X160	TATA spare parts
257342136302	BRAKE LINING STD FRT	TATA spare parts
257342136303	BRAKE LINING RS1	TATA spare parts
257342136304	BRAKE LINING RS2	TATA spare parts
257342136307	BRAKE LINING STD	TATA spare parts
257342136308	BRAKE LINING RS1	TATA spare parts
257342136309	BRAKE LINING RS2	TATA spare parts
257342136310	BRAKE LINING STD	TATA spare parts
257342136311	BRAKE LINING RS1	TATA spare parts
257342136312	BRAKE LINING RS2	TATA spare parts
257342136327	BRAKE LINING RS2	TATA spare parts
257342136329	BRAKE LINING FRT	TATA spare parts
257342136339	BRAKE LINING (NON-ASBESTO	TATA spare parts
257342136342	BRAKE LINING NON-ASBESTOS	TATA spare parts
257342136352	BRAKE LINING RS2	TATA spare parts
257342136353	BRAKE LINING RS1	TATA spare parts

257342136354	BRAKE LINING STD NASB	TATA spare parts
257342300101	BRAKE ASSY RR LH	TATA spare parts
257342300102	BRAKE ASSY RR RH	TATA spare parts
257342300103	LEVER	TATA spare parts
257342300105	THRUST SHACKLE LH	TATA spare parts
257342300106	THRUST SHACKLE RH	TATA spare parts
257342300116	ADJUSTER ECCENTRIC REAR	TATA spare parts
257342300135	BRAKE ASSY RR RH	TATA spare parts
257342300136	BRAKE ASSY RR LH	TATA spare parts
257342300162	BRAKE ASSY RR LH ASBS	TATA spare parts
257342300163	BRAKE ASSY RR RH	TATA spare parts
257342300164	BRAKE ASSY RR LH	TATA spare parts
257342300165	BRAKE ASSY RR RH	TATA spare parts
257342300166	SLACK ADJ REAR LH	TATA spare parts
257342300167	SLACK ADJ REAR RH	TATA spare parts
257342300179	BRACKET LH	TATA spare parts
257342300180	BRACKET RH	TATA spare parts
257342300181	ASSY WHEEL CYL 50.8D	TATA spare parts
257342300182	KIT BR O/H MNR REAR	TATA spare parts
257342300183	KIT CAM SHAFT REAR	TATA spare parts
257342300184	BR SHOE & ROLLER RR	TATA spare parts
257342300189	BRAKE ACTUATOR RR	TATA spare parts
257342300190	BRACKET CAM SHAFT MTG	TATA spare parts
257342300192	SLACK ADJUSTER LH-OFFER DRG. BS2/3	TATA spare parts
257342300193	SLACK ADJUSTER RH-OFFER DRG. BS2/3	TATA spare parts
257342300194	SLACK ADJUSTER LH (M/S ELGI)	TATA spare parts
257342300195	SLACK ADJUSTER	TATA spare parts
257342300196	ASSY.SPRG.BRAKE ACTUATOR	TATA spare parts
257342300197	SPG BR ACTUATOR	TATA spare parts
257342303207	HEX BOLT RR TORQUE PL MTG	TATA spare parts
257342303401	REAR BRAKE METALLIC BUSH	TATA spare parts
257342303403	BUSH SPIDER & PLUMMER BLK	TATA spare parts
257342303404	DELRIN BUSH	TATA spare parts
257342303701	BRAKE DRUM REAR	TATA spare parts
257342303712	BRAKE DRUM REAR	TATA spare parts
257342303715	SPIDER BRAKE LH REAR	TATA spare parts
257342303716	SPIDER BRAKE RH REAR	TATA spare parts
257342305113	BEARING BLOCK	TATA spare parts
257342305301	WASHER-CAMSHAFT SPACING	TATA spare parts
257342306008	HAND BRAKE LEVER RH	TATA spare parts
257342306009	HAND BRAKE LEVER LH	TATA spare parts
257342306504	NUT FOR BRAKE CHMABER BRACKET	TATA spare parts
257342306701	PIVOT PIN REAR	TATA spare parts
257342306702	PIN	TATA spare parts
257342306706	PIN	TATA spare parts
257342307102	LOCKING PLATE	TATA spare parts
257342307123	PLUMMER BLOCK	TATA spare parts

257342307705	DIAPHRAM	TATA spare parts
257342307801	OIL SEAL	TATA spare parts
257342307906	HAND BRAKE SHAFT	TATA spare parts
257342307907	CAMSHAFT LH 1312 RR	TATA spare parts
257342307908	CAM SHAFT RH 1312 RR	TATA spare parts
257342307926	FAN BRAKE SHAFT	TATA spare parts
257342307964	CAM SHAFT LH	TATA spare parts
257342307965	CAM SHAFT RH	TATA spare parts
257342307966	CAM SHAFT LH RR	TATA spare parts
257342307967	CAM SHAFT RH RR	TATA spare parts
257342307968	CAM SHAFT RH REAR (2518)	TATA spare parts
257342307969	CAM SHAFT LH REAR (2518)	TATA spare parts
257342307970	CAM SHAFT RH LPS4923 RRWD AXLE	TATA spare parts
257342307971	CAM SHAFT LH LPS 4923 RRWD AXLE	TATA spare parts
257342307972	CAM SHAFT RH LPS 4923 RFWD AXLE	TATA spare parts
257342307973	CAM SHAFT LH LPS 4923 RFWD AXLE	TATA spare parts
257342307974	CAMSHAFT-RH	TATA spare parts
257342307975	CAMSHAFT-LH	TATA spare parts
257342307976	CAM SHAFT RH REAR	TATA spare parts
257342307977	CAM SHAFT LH REAR	TATA spare parts
257342308004	HEX SCREW	TATA spare parts
257342308005	HEX SCREW	TATA spare parts
257342308008	SCREW	TATA spare parts
257342308010	NUT	TATA spare parts
257342308011	SCREW	TATA spare parts
257342308204	DUST SHIELD	TATA spare parts
257342308205	DUST SHIELD	TATA spare parts
257342308208	DUST SHIELD	TATA spare parts
257342308209	BRAKE ASSY -DUST SHILED TOP	TATA spare parts
257342308210	BRAKE ASSY -DUST SHILED BOTTOM	TATA spare parts
257342308301	SHIM	TATA spare parts
257342308401	SLEEVE SLACK ADJ END	TATA spare parts
257342308403	SLEEVE FRONT	TATA spare parts
257342308601	GUARD RING	TATA spare parts
257342308608	SPACER	TATA spare parts
257342309204	WASHER	TATA spare parts
257342309205	TAB WASHER	TATA spare parts
257342309208	SPACER CAMSHAFT	TATA spare parts
257342309214	SPACER	TATA spare parts
257342309215	WASHER - 2.5 MM	TATA spare parts
257342309216	WASHER - 0.3 MM	TATA spare parts
257342309217	WASHER 0.5 MM	TATA spare parts
257342309218	WASHER 1 MM	TATA spare parts
257342309219	WASHER 2.5 MM	TATA spare parts
257342309220	WASHER	TATA spare parts
257342309906	FITTING GREASE SPIDER	TATA spare parts
257342309907	REAR SERVICE KIT FOR METALLIC BUSH	TATA spare parts

257342310108	ANCHOR PLATE LH REAR	TATA spare parts
257342310109	ANCHOR PLATE RH REAR	TATA spare parts
257342310116	ANCHOR PLATE LH	TATA spare parts
257342310117	ANCHOR PLATE RH	TATA spare parts
257342310118	ANCHOR PLATE LH REAR	TATA spare parts
257342310119	ANCHOR PLATE RH REAR	TATA spare parts
257342310126	ASSY.SLACK ADJUSTER LH	TATA spare parts
257342310127	ASSY.SLACK ADJUSTER RH	TATA spare parts
257342310134	ASSY.SPRG.BRAKE ACTUATOR	TATA spare parts
257342310148	BR SHOE LNG & ROLLER	TATA spare parts
257342310149	SPIDER BRAKE REAR	TATA spare parts
257342310150	DUST SHIELD	TATA spare parts
257342310151	KIT BRAKE O/H REAR MINOR	TATA spare parts
257342310152	KIT BR LINING RR	TATA spare parts
257342310158	BRAKE SHOE WITHOUT LINING	TATA spare parts
257342310179	BRAKE SHOE	TATA spare parts
257342310180	DUST SHIELD MOUNTING FASTENER KIT	TATA spare parts
257342310181	BRKACET MOUNTING FASTENER KIT	TATA spare parts
257342310182	CAMSHAFT WASHER KIT	TATA spare parts
257342310184	WHEEL MOUNTING FASTENER KIT	TATA spare parts
257342310186	DRUM TO HUB MOUNTING FASTENERS KIT	TATA spare parts
257342310187	ABS KIT	TATA spare parts
257342313701	TORQUE PLATE LH & RH	TATA spare parts
257342318212	DUST COVER TOP	TATA spare parts
257342318213	DUST COVER BOTTOM	TATA spare parts
257342318704	SPIDER ASSY W/BUSH & SEAL LH	TATA spare parts
257342318706	SPIDER ASSY W/BUSH & SEAL RH	TATA spare parts
257342318708	SPIDER ASSY(BUSH+OIL SEAL) AAL BRAKE	TATA spare parts
257342320102	WHEEL CYL.50.80D RR	TATA spare parts
257342320103	WHEEL CYL.50.80D	TATA spare parts
257342320107	PRESSURE SPRING	TATA spare parts
257342320111	REP KIT WHEEL CYLINDER	TATA spare parts
257342320112	REP KIT WHEEL CYLINDER	TATA spare parts
257342326301	PISTON CUP	TATA spare parts
257342326303	PISTON CUP	TATA spare parts
257342326601	PISTON	TATA spare parts
257342326602	PISTON	TATA spare parts
257342326801	ADAPTER SIDE CAP	TATA spare parts
257342327701	PISTON CUP	TATA spare parts
257342327702	BOOT	TATA spare parts
257342328001	BLEEDING SCREW	TATA spare parts
257342328002	BLEEDING SCREW	TATA spare parts
257342328201	METAL COVER	TATA spare parts
257342328701	PRESSURE SPRING	TATA spare parts
257342329201	ADAPTER	TATA spare parts
257342330106	BR SHOE W/LIN STD RR	TATA spare parts
257342330107	BR SHOE W/LIN RS1 RR	TATA spare parts



257342330108	BR SHOE W/LIN RS2 RR	TATA spare parts
257342330110	BR SHOE W/LIN	TATA spare parts
257342330113	ASY BRAKE SHOE W LINING R	TATA spare parts
257342330116	BR SHOE W/LIN STD RR NASB	TATA spare parts
257342330117	BR SHOE W/LIN RS1 RR	TATA spare parts
257342330123	BR SHOE W/LIN STD RR SCAM	TATA spare parts
257342330124	KIT-BRAKE LINING STD RR	TATA spare parts
257342330125	KIT BR LINING RS1 RR	TATA spare parts
257342330126	KIT BR LINING RS2 RR	TATA spare parts
257342336301	BRAKE LINING STD RR	TATA spare parts
257342336302	BRAKE LINING RS1	TATA spare parts
257342336303	BRAKE LINING RS2	TATA spare parts
257342336304	BRAKE LINING STD RR	TATA spare parts
257342336305	BRAKE LINING RS1	TATA spare parts
257342336306	BRAKE LINING RS2	TATA spare parts
257342336317	BRAKE LINING RS2 RR	TATA spare parts
257342336318	BRAKE LINING RR	TATA spare parts
257342336328	BRAKE LINING STD RR	TATA spare parts
257342336329	BRAKE LINING RS1	TATA spare parts
257342336330	BRAKE LINING RS2	TATA spare parts
257342420001	REP KIT HAND BR VALVE	TATA spare parts
257342420101	GRAD.HAND BR VALVE RHD	TATA spare parts
257342420102	GRADUAL HAND CONTROL VALV	TATA spare parts
257342420112	ASSY.BRACKET	TATA spare parts
257342420113	SPRING BRAKE CHAMBER BS1/2/3	TATA spare parts
257342420115	GRAD.HAND BR VALVE	TATA spare parts
257342420116	ASSY.GRADUATED HAND CONTR	TATA spare parts
257342420117	GRAD.HAND BR VALVE	TATA spare parts
257342420118	GRAD.HAND BR VALVE	TATA spare parts
257342700155	PULL ROD	TATA spare parts
257342700156	ASSY LINKAGE	TATA spare parts
257342700157	ASSY FORK	TATA spare parts
257342700158	FORK ASSY	TATA spare parts
257342700159	ASSY.BRACKET RH.	TATA spare parts
257342703303	BRACKET (ZP)	TATA spare parts
257342706901	PIPE AIR 6 X 0.7	TATA spare parts
257342706903	PIPE AIR 6 X 0.7 X 175	TATA spare parts
257342706928	PIPE AIR 15 X 1.5	TATA spare parts
257342706948	PIPE AIR 15 X 1.5	TATA spare parts
257342708202	GUIDE TUBE	TATA spare parts
257342800102	BRAKE TUBE	TATA spare parts
257342800103	BRAKE TUBE	TATA spare parts
257342800104	BRAKE TUBE	TATA spare parts
257342800105	BRAKE TUBE	TATA spare parts
257342800108	BRAKE TUBE	TATA spare parts
257342800109	BRAKE TUBE	TATA spare parts
257342800110	BRAKE TUBE	TATA spare parts

257342800111	BRAKE TUBE	TATA spare parts
257342800112	BRAKE TUBE	TATA spare parts
257342800147	BRAKE LINE	TATA spare parts
257342800149	BRAKE LINE	TATA spare parts
257342800160	BRAKE TUBE ASSY	TATA spare parts
257342800172	BRAKE TUBE RR LH	TATA spare parts
257342800188	BRAKE TUBE	TATA spare parts
257342800190	BRAKE TUBE	TATA spare parts
257342800191	BRAKE TUBE	TATA spare parts
257342803301	BKT BRAKE HOSE FRONT	TATA spare parts
257342806704	PIN ON DUEL BR VALVE	TATA spare parts
257342806804	SOCKET	TATA spare parts
257342808207	BRACKET	TATA spare parts
257342810178	ASSY AIR PIPE	TATA spare parts
257342810180	HYDRAULIC PIPE	TATA spare parts
257342810181	HYDRAULIC PIPE	TATA spare parts
257342810182	HYDRAULIC LINE	TATA spare parts
257342810183	HYDRAULIC LINE	TATA spare parts
257342810184	HYDRAULIC LINE	TATA spare parts
257342810186	HYDRAULIC LINE	TATA spare parts
257342820101	TUBE ASSY	TATA spare parts
257342820104	CONNECTING LINE	TATA spare parts
257342820107	CONNECTING LINE DAOH	TATA spare parts
257342820108	CONNECTING LINE DAOH	TATA spare parts
257342830101	TUBE 15MM OD	TATA spare parts
257342830102	TUBE 6D	TATA spare parts
257342830103	TUBE 6D	TATA spare parts
257342830104	TUBE 6D	TATA spare parts
257342830108	TUBE 6D	TATA spare parts
257342830109	TUBE 12D	TATA spare parts
257342830110	TUBE 12D	TATA spare parts
257342830111	TUBE 12D	TATA spare parts
257342830112	TUBE 12D	TATA spare parts
257342830113	HYDRAULIC PIPE 10MM OD	TATA spare parts
257342830114	HYDRAULIC PIPE 10MM OD	TATA spare parts
257342830116	CONNECTING LINE	TATA spare parts
257342830117	CONNECTING LINE	TATA spare parts
257342830118	HYDRAULIC PIPE 10MM OD	TATA spare parts
257342830142	TUBE 12D	TATA spare parts
257342830143	TUBE 6D X 0.7MM	TATA spare parts
257342830144	TUBE 6D X 0.7MM	TATA spare parts
257342830158	PIPE EXHAUST BRAKE VALVE TO HOSE ON AIR	TATA spare parts
257342900111	PIPE AIR FOOT CON VALVE	TATA spare parts
257342900134	HOSE	TATA spare parts
257342900143	HOSE BRAKE 3/8 REAR	TATA spare parts
257342900144	HOSE 12 OD PIPING	TATA spare parts
257342900157	TUBE ASSEMBLY	TATA spare parts

257342900161	ASSY HOSE 3/8INCH	TATA spare parts
257342900164	PIPE AIR	TATA spare parts
257342903305	BRACKET	TATA spare parts
257342904201	COATED CLAMP ( 6 O.D.)	TATA spare parts
257342904202	CLAMP	TATA spare parts
257342904203	COATED CLAMP ( 12 O.D.)	TATA spare parts
257342904204	CLAMP	TATA spare parts
257342904205	COATED CLAMP (15 DIA.)	TATA spare parts
257342904206	CLAMP	TATA spare parts
257342904207	COATED CLAMP	TATA spare parts
257342905101	THREE WAY CONNECTOR	TATA spare parts
257342905102	JUNCTION BLOCK-OFFER	TATA spare parts
257342906808	T SOCKET	TATA spare parts
257342906809	ELBOW	TATA spare parts
257342906810	DOUBLE SOCKET	TATA spare parts
257342906815	SOCKET	TATA spare parts
257342906816	TEE SOCKET	TATA spare parts
257342906821	ELBOW L6	TATA spare parts
257342906902	PIPE AIR 18 X 1.5 X 1100	TATA spare parts
257342906904	PIPE AIR 15 X 1.5 X 1860	TATA spare parts
257342906905	PIPE 15DIAX1.5	TATA spare parts
257342906911	PIPE AIR 6D	TATA spare parts
257342906912	PIPE AIR 18 X 1.5	TATA spare parts
257342910150	PIPE AIR	TATA spare parts
257342910160	PIPE AIR	TATA spare parts
257342910161	PIPE AIR	TATA spare parts
257342910179	PIPE ASSY	TATA spare parts
257342910193	PIPE ASSY	TATA spare parts
257342910195	TUBE ASSY 12D	TATA spare parts
257342930109	HOSE HIGH PRESSURE 3/8	TATA spare parts
257342930117	ASSY PIPE	TATA spare parts
257342940105	PIPE AIR	TATA spare parts
257342940128	PIPE AIR	TATA spare parts
257342940130	ASSY AIR PIPE 12OD	TATA spare parts
257342940140	PIPE AIR	TATA spare parts
257342940143	ASSY AIR PIPE	TATA spare parts
257342940155	PIPE AIR	TATA spare parts
257342940193	PIPE AIR	TATA spare parts
257342940194	PIPE AIR	TATA spare parts
257342940198	PIPE AIR	TATA spare parts
257342940199	PIPE AIR	TATA spare parts
257342950101	PIPE AIR	TATA spare parts
257342950102	PIPE AIR	TATA spare parts
257342950103	PIPE AIR	TATA spare parts
257342950104	PIPE AIR	TATA spare parts
257342950105	PIPE AIR	TATA spare parts
257342950106	PIPE AIR	TATA spare parts

257342950108	PIPE AIR	TATA spare parts
257342950109	PIPE AIR	TATA spare parts
257342950112	PIPE AIR 6D	TATA spare parts
257342950113	PIPE AIR 6D	TATA spare parts
257342950115	PIPE AIR	TATA spare parts
257342950116	PIPE AIR	TATA spare parts
257342950117	PIPE AIR	TATA spare parts
257342950134	HOSE HIGH PRESSURE 3/8	TATA spare parts
257342950135	HOSE HIGH PRESSURE 3/8	TATA spare parts
257342950136	TUBE 15D A/C TO U/L	TATA spare parts
257342950149	TUBE FROM DUAL BRAKE	TATA spare parts
257342950150	TUBE ASSY	TATA spare parts
257342950151	PIPE TEE TO LH BR ACTUAT	TATA spare parts
257342950152	ASSY TUBE	TATA spare parts
257342950153	ASSY PIPE 150 DIA	TATA spare parts
257342950154	ASSY.TUBE	TATA spare parts
257342950155	TUBE ASSY	TATA spare parts
257342950156	PIPE ASSY	TATA spare parts
257342950157	TUBE ASSY	TATA spare parts
257342950176	HOSE W/END FITTINGS BS1/2/3/4	TATA spare parts
257342950177	HOSE W/END FITTINGS BS1/2/3/4	TATA spare parts
257342950178	PIPE SENS TNK-SP VAL	TATA spare parts
257342950179	TUBE FROM AIR FILTER	TATA spare parts
257342950180	TUBE ASSY	TATA spare parts
257342950181	TUBE FROM TEE TO RR	TATA spare parts
257342950182	TUBE FROM TEE TO RR	TATA spare parts
257342950183	TUBE FROM AIR FILTER	TATA spare parts
257342950184	TUBE ASSY	TATA spare parts
257342950185	TUBE ASSY	TATA spare parts
257342950186	TUBE ASSY	TATA spare parts
257342950187	TUBE FROM SYS PROT	TATA spare parts
257342950188	TUBE FROM GRADUATED	TATA spare parts
257342950190	TUBE FROM TEE TO RR	TATA spare parts
257342950191	TUBE FROM TEE TO RR	TATA spare parts
257342950192	TUBE FROM SYS PROTEC	TATA spare parts
257342950193	ASSY TUBE	TATA spare parts
257342950194	ASSY TUBE	TATA spare parts
257342950195	ASSY TUBE	TATA spare parts
257342950196	ASSY TUBE	TATA spare parts
257342950198	PIPE T-CON TO RH BR CH RR	TATA spare parts
257342950199	ASSY. TUBE	TATA spare parts
257342960101	ASSY PIPE	TATA spare parts
257342960104	ASSY TUBE	TATA spare parts
257342960142	ASSY TUBE	TATA spare parts
257342960150	ASSY TUBE	TATA spare parts
257342960156	ASSY TUBE	TATA spare parts
257342960165	ASSY TUBE	TATA spare parts

257342960167	ASSY TUBE	TATA spare parts
257342970101	ASSY. TUBE	TATA spare parts
257342970102	ASSY TUBE	TATA spare parts
257342990107	CAM SHAFT WASHER KIT	TATA spare parts
257342990109	BRAKE ASSY -MAJOR SPARE KIT REAR BRAKE	TATA spare parts
257342998201	DUST SHEILD- TOP	TATA spare parts
257342998202	DUST SHIELD BOTTOM	TATA spare parts
257342998203	DUST SHIELD -TOP FRONT 410X160	TATA spare parts
257342998204	DUST SHIELD -BOTTOM FRONT 410X160	TATA spare parts
257342998205	SHIELD ASSY TOP	TATA spare parts
257342998206	SHIELD ASSY BOTTOM	TATA spare parts
257342998207	DUST SHIELD TOP	TATA spare parts
257342998208	DUST SHIELD BOTTOM	TATA spare parts
257343100005	BRAKE FLUID CONTAINER	TATA spare parts
257343100102	MASTER CYL 38.10 D X 75	TATA spare parts
257343100103	UNLOADER VALVE	TATA spare parts
257343100107	ASSY BRAKE MASTER CYL 38.1D BRAKES	TATA spare parts
257343100108	ASSY BRAKE MASTER CYL 38.1D BRAKES	TATA spare parts
257343100114	REP KIT-BRK.CHAMBER TY20	TATA spare parts
257343100115	REP KIT-BRK.CHAMBER TY24	TATA spare parts
257343100116	ASSY BRAKE MASTER CYL 38.1D BRAKES	TATA spare parts
257343100117	PRESSURE SPRING	TATA spare parts
257343100118	PLUNGER	TATA spare parts
257343100130	ASSY BRAKE MASTER CYL 38.1D BRAKES	TATA spare parts
257343100142	KIT REP MASTER CYL	TATA spare parts
257343100149	FILT FLUID CONT	TATA spare parts
257343100151	CAP BR FLUID CONTAINER	TATA spare parts
257343100156	BRAKE FLUID CONTAINER	TATA spare parts
257343100157	UNLOADER VALVE	TATA spare parts
257343100159	UNLOADER VALVE	TATA spare parts
257343100160	UNLOADER VALVE	TATA spare parts
257343100166	KIT REP UNLOADER VALVE	TATA spare parts
257343100171	UNLOADER VALVE	TATA spare parts
257343100172	UNLOADER VALVE	TATA spare parts
257343100173	UNLOADER VALVE	TATA spare parts
257343100177	SERVO LEVER TYPE 150 X 75	TATA spare parts
257343100178	SERVO LEVER TYPE	TATA spare parts
257343100184	KIT REP ISOLATOR VALVE	TATA spare parts
257343100185	DIAPHRAM	TATA spare parts
257343100190	KIT REP UNLOADER VALVE	TATA spare parts
257343100191	UNLOADER VALVE	TATA spare parts
257343100192	UNLOADER VALVE	TATA spare parts
257343100193	DIAPHRAGM	TATA spare parts
257343104301	CIRCLIP	TATA spare parts
257343104302	SNAP RING	TATA spare parts
257343104303	SNAP RING	TATA spare parts
257343104701	ADOPTER NUT	TATA spare parts

257343105301	SEALING RING	TATA spare parts
257343106314	CAP FOR B/F/CON	TATA spare parts
257343106501	CONNECTING HEAD	TATA spare parts
257343106603	PISTON W/FILTER WASHAR	TATA spare parts
257343106606	UNLOADER PLUNGER	TATA spare parts
257343106607	PLUNGER	TATA spare parts
257343106704	GOVERNOR PLUNGER	TATA spare parts
257343106804	CONNECTING HEAD	TATA spare parts
257343107502	BUSH	TATA spare parts
257343107701	PRESSURE CUP	TATA spare parts
257343107702	BACK SEAL	TATA spare parts
257343107720	DIAPHRAGM	TATA spare parts
257343107721	VALVE	TATA spare parts
257343107724	EXHAUST FLAP	TATA spare parts
257343107725	VALVE	TATA spare parts
257343107801	PRESSURE CUP	TATA spare parts
257343108212	CUP	TATA spare parts
257343108215	FOLLOWER	TATA spare parts
257343108702	PRESSURE SPRING W/RETAINR	TATA spare parts
257343109201	SEALING RING	TATA spare parts
257343109202	RETAINING WASHER	TATA spare parts
257343109203	STOP WASHER	TATA spare parts
257343109204	FILLER WASHER	TATA spare parts
257343109902	PRESSURE CUP API	TATA spare parts
257343109903	HOLLOWRIVET	TATA spare parts
257343109922	SECONDARY CUP UB	TATA spare parts
257343110114	MASTER CYL 31.75 D DAOH	TATA spare parts
257343110117	ASSY MASTER CYL 31.8D X 62MM	TATA spare parts
257343110118	KIT REP MINOR TMC	TATA spare parts
257343110119	KIT REP MAJOR TMC	TATA spare parts
257343110120	BRAKE FLUID CONTAINER	TATA spare parts
257343110122	UNLOADER VALVE	TATA spare parts
257343110124	BRAKE FLUID RESERVOIR ASSY.W.ELECTRONIC	TATA spare parts
257343110125	TANDEM MASTER CYL 31.80D	TATA spare parts
257343110126	TANDEM MASTER CYL 31.80D	TATA spare parts
257343110127	TANDEM MASTER CYL	TATA spare parts
257343110128	KIT REP SERVO BRVALVE MNR	TATA spare parts
257343110129	KIT REP SERVO BRVALVE MJR	TATA spare parts
257343200101	SUPPORT AIR TANK	TATA spare parts
257343200102	AIR TANK	TATA spare parts
257343200121	AIR TANK	TATA spare parts
257343200122	AIR TANK	TATA spare parts
257343200135	SUPPORT AIR TANK	TATA spare parts
257343200142	ASSY AIR TANK	TATA spare parts
257343200144	AIR TANK	TATA spare parts
257343200148	SENSING TANK 10 LTS	TATA spare parts
257343200151	ASSY AIR TANK	TATA spare parts

257343200152	AIR TANK	TATA spare parts
257343200157	ASSY.BRACKET RH	TATA spare parts
257343200158	ASSY BRACKET LH	TATA spare parts
257343200161	ASSY SENSING TANK	TATA spare parts
257343200176	ASSY AIR TANK WITH SEALIN	TATA spare parts
257343204201	CLAMP 1210 SA/SD	TATA spare parts
257343207701	RUBBER STRAP	TATA spare parts
257343208001	SCREW M12X1.5X38	TATA spare parts
257343210158	ASSY BRAKE SHOE WITHOUT LINING	TATA spare parts
257343300101	MAJOR REP.KIT-S.B.ACTUATOR	TATA spare parts
257343300102	MINOR REP.KIT S.B.ACTUATOR	TATA spare parts
257343406802	DOUBLE SOCKET	TATA spare parts
257343406805	DOUBLE SOCKET	TATA spare parts
257343406806	SOCKET	TATA spare parts
257343406808	SOCKET	TATA spare parts
257343503302	BRACKET (FOR CLAMING FIP OVERFLOW LINE)	TATA spare parts
257343506803	TEE SOCKET	TATA spare parts
257343506805	T SOCKET	TATA spare parts
257343509201	THRUST RING	TATA spare parts
257343700001	KIT REP D TREADLE VALVE	TATA spare parts
257343700003	REPAIR KIT AIR EXHAUST BRAKE VALVE	TATA spare parts
257343700004	AIR FILTER M250440	TATA spare parts
257343700101	EXHAUST BRAKE VALVE	TATA spare parts
257343700102	AIR EXHAUST BR.VALVE	TATA spare parts
257343700106	EXHAUST BRAKE VALVE	TATA spare parts
257343700108	DUAL BRAKE VALVE	TATA spare parts
257343700109	GRAD HAND BRAKE VALVE	TATA spare parts
257343700112	DUAL BRAKE VALVE	TATA spare parts
257343700114	EXHAUST BRAKE VALVE	TATA spare parts
257343700114AE	EXHAUST BRAKE VALVE	TATA spare parts
257343700115	EXHAUST BRAKE VALVE	TATA spare parts
257343700116	EXHAUST BRAKE VALVE	TATA spare parts
257343700117	EXHAUST BRAKE VALVE	TATA spare parts
257343700119	AIR CYLINDER	TATA spare parts
257343700120	AIR CYLINDER	TATA spare parts
257343700123	EXHAUST BRAKE VALVE	TATA spare parts
257343700124	EXHAUST BRAKE VALVE	TATA spare parts
257343700126	SYSTEM PROTECTION VALVE	TATA spare parts
257343700127	UNLOADER VALVE	TATA spare parts
257343700129	GRADUATED HAND CONTROL VALVE	TATA spare parts
257343700130	GRADUATED HAND CONTROL VALVE	TATA spare parts
257343700132	GRAD HAND BRAKE VALVE	TATA spare parts
257343700135	DUAL BRAKE VALVE	TATA spare parts
257343700136	ISOLATOR VALVE	TATA spare parts
257343700137	AIR CYLINDER 150D X 56	TATA spare parts
257343700138	AIR CYLINDER 150D X 56	TATA spare parts
257343700140	OFF DRG ASSY EXH BRK ISOLATOR VALVE	TATA spare parts

257343700141	AIR FILTER	TATA spare parts
257343700143	WATER DRAIN VALVE	TATA spare parts
257343700144	DUAL BRAKE VALVE	TATA spare parts
257343700144AE	DUAL BRAKE VALVE	TATA spare parts
257343700145	SYSTEM PROTECTION VALVE	TATA spare parts
257343700146	GRAD HAND BRAKE VALVE	TATA spare parts
257343700147	GRADUATED HAND CONTROL VALVE	TATA spare parts
257343700148	GRAD HAND BRAKE VALVE	TATA spare parts
257343700150	AIR FILTER	TATA spare parts
257343700151	AIR FILTER M/S ELGI 03 40590	TATA spare parts
257343700152	AIR FILTER	TATA spare parts
257343700153	GRADUATED HAND CONTROL VALVE TELCO PART	TATA spare parts
257343700154	GRADUATED HAND CONTROL VALVE TELCO PART	TATA spare parts
257343700155	GRAD.HAND CONTROL VALVE	TATA spare parts
257343700157	4 WAY SYST PROT VALVE	TATA spare parts
257343700157AE	4 WAY SYSTEM PROTECT VALVE -713	TATA spare parts
257343700160	GRADUATED HAND BRK VALVE	TATA spare parts
257343700161	GRADUATED HAND CONTROL VALVE	TATA spare parts
257343700162	GRADUATED HAND CONTROL VALVE	TATA spare parts
257343700163	REPAIR KIT	TATA spare parts
257343700165	ISOLATOR VALVE EXH BRAKE	TATA spare parts
257343700166	ASSY ISOLATUR VALVE	TATA spare parts
257343700167	ASSY.ISOLATOR VALVE	TATA spare parts
257343700168	ASSY.AIR FILTER	TATA spare parts
257343700170	ASSY UNLOADER VALVE	TATA spare parts
257343700175	ASSY.AIR FILTER	TATA spare parts
257343700181	SYSTEM PROTECTION VALVE	TATA spare parts
257343700182	ASSY.AIR FILTER	TATA spare parts
257343700183	AIR CYLINDER	TATA spare parts
257343700184	AIR CYLINDER	TATA spare parts
257343700187	ASSY AIR FILTER	TATA spare parts
257343700188	GRADUATED HAND CONTROL VALVE	TATA spare parts
257343700189	GRADUATED HAND CONTROL VALVE	TATA spare parts
257343700191	GRADUATED HAND BRK VALVE	TATA spare parts
257343700194	DUAL BRAKE VALVE WITH FILTER BS1/2/3	TATA spare parts
257343700196	REP KIT-S.P.VALVE	TATA spare parts
257343700415	UNLOADWER VALVE ASSY	TATA spare parts
257343707724	DIAPHRAGM-BRK.CHAMBER	TATA spare parts
257343710101	DUAL BRAKE VALVE	TATA spare parts
257343720112	ASSY.AIR FILTER	TATA spare parts
257343730102	AIR FILTER	TATA spare parts
257343908201	BRACKET-BRAKE HOSE CLAMPING	TATA spare parts
257344100136	ASSY. PIPE 18X875	TATA spare parts
257344100137	ASSY.PIPE 15X870 P.STRG	TATA spare parts
257344104203	STRIP	TATA spare parts
257344105803	HOSE ASSY 3/8	TATA spare parts
257344106801	DOUBLE SOCKET	TATA spare parts



257344106802	BANJO BODY	TATA spare parts
257344106803	BANJO BODY	TATA spare parts
257344106804	DOUBLE SOCKET	TATA spare parts
257344118201	BRACKET	TATA spare parts
257344400101	HYDRAULIC OIL TANK	TATA spare parts
257344400108	STRG PUMP	TATA spare parts
257344400109	HYDRAULIC OIL TANK	TATA spare parts
257344400113	ASSY.PIPE	TATA spare parts
257344400114	ASSY.PIPE	TATA spare parts
257344400115	ASSY PIPE 15 MM 1510 P/ST	TATA spare parts
257344400126	DIPSTICK ZF HYD TANK	TATA spare parts
257344400128	OIL FILTER CARTRIDGE BS1/2/3/4	TATA spare parts
257344400128DF	FILTER STEERING HYDRAULIC-ZF METALLIC TA	TATA spare parts
257344400129	STUD ASSY	TATA spare parts
257344400138	PUMP	TATA spare parts
257344403501	CONN PART TANK	TATA spare parts
257344403502	CONN PART TANK	TATA spare parts
257344405301	GASKET	TATA spare parts
257344405302	GASKET TOP COVER	TATA spare parts
257344406501	HEX NUT M8	TATA spare parts
257344406801	INTAKE CONNECTOR	TATA spare parts
257344406802	INTAKE CONNECTOR	TATA spare parts
257344407701	O RING 8 X 3.5	TATA spare parts
257344407702	O RING	TATA spare parts
257344407704	GASKET OIL TANK	TATA spare parts
257344408001	HEX SCREW M8 X16	TATA spare parts
257344408208	FIXING DEVICE	TATA spare parts
257344408209	PROTECTING CAP	TATA spare parts
257344408219	STRAINER - 407	TATA spare parts
257344409202	WASHER	TATA spare parts
257344409901	STICK ON LABEL	TATA spare parts
257344409902	BAYONET CAP	TATA spare parts
257344409903	WASHER	TATA spare parts
257344409905	FILTER CARTRIDGE	TATA spare parts
257344500102	TANK FILTER LONGER	TATA spare parts
257344500104	OIL TANK CAP ASSY.	TATA spare parts
257344500106	SERVICE KIT-TANK	TATA spare parts
257344500107	TANK FILTER ASSY SHORTER	TATA spare parts
257344500107DF	FILTER STEERING HYDRAULIC-RANE MET TANK	TATA spare parts
257344500109	TANK KIT	TATA spare parts
257344500111	DIP STICK ASSY SHORTER	TATA spare parts
257344507703	COVER SEAL	TATA spare parts
257346000101	DRAG LINK ASSY RHD LP	TATA spare parts
257346000105	STRG GEAR BOX LP342M	TATA spare parts
257346000106	ASSY STEERING	TATA spare parts
257346000126	DRAG LINK ASSY RHD	TATA spare parts
257346000134	DRAG LINK ASSY RHD LP	TATA spare parts

257346000135	DRAG LINK LP1510RHD	TATA spare parts
257346000149	ASSY DRAG LINK	TATA spare parts
257346000150	STRG GEAR BOX	TATA spare parts
257346000152	DRAG LINK ASSY LP QHT	TATA spare parts
257346000153	REPAIR KIT FOR DRAG.LINK	TATA spare parts
257346000154	DRAG LINK ASSY LP	TATA spare parts
257346000170	STEERING ASSY LP	TATA spare parts
257346100106	SUPPORT STRG COLUMN	TATA spare parts
257346100107	SUPPORT STRG COLUMN	TATA spare parts
257346100111	SUPPORT STRG COLUMN	TATA spare parts
257346100132	BKT STRG G/BOX MTG RHD	TATA spare parts
257346100134	STRG GEAR BOX POWER	TATA spare parts
257346100135	SUPPORT STRG COLUMN	TATA spare parts
257346100138	STRG GEAR BOX POWER RHD	TATA spare parts
257346100144	ASSY. STEERING GEAR BOX BS1/2/3/4	TATA spare parts
257346100145	ASSY STRG COLUMN SUPPORT	TATA spare parts
257346100147	SUPPORT STRG COLUMN	TATA spare parts
257346100148	SUPPORT STRG COLUMN	TATA spare parts
257346100153	STEERING COLUMN SEL/CAN	TATA spare parts
257346100154	BKT STRG G/BOX MTG	TATA spare parts
257346100156	SUPPORT STRG COLUMN	TATA spare parts
257346100157	SUPPORT STRG COLUMN	TATA spare parts
257346103701	BRACKET STEERING	TATA spare parts
257346106301	RUBBER BELLOW	TATA spare parts
257346106302	RUBBER BELLOW	TATA spare parts
257346106501	ADJUSTING NUT	TATA spare parts
257346106702	PIN MOUNTING SHORT	TATA spare parts
257346106703	PIN MOUNTING LONG	TATA spare parts
257346106704	PIN MOUNTING MEDIUM	TATA spare parts
257346107501	PROTECTIVE COVER STRG	TATA spare parts
257346108002	HEX SCREW M12 X 1.5 X 48	TATA spare parts
257346108209	CLAMPING RING.	TATA spare parts
257346200105	UNIVERSAL JOINT STRG	TATA spare parts
257346200106	UNIVERSAL JOINT (STEERING) BS1/2/3/4	TATA spare parts
257346200106AE	ASSY U J STEERING -1415	TATA spare parts
257346200108	UNIVERSAL JOINT STRG	TATA spare parts
257346200114	PROTECTIVE CAP	TATA spare parts
257346200115	INPUT SHAFT SEAL KIT GRBO	TATA spare parts
257346200115AE	INPUT SHAFT SEAL KIT. 715	TATA spare parts
257346200116	SEAL KIT VALVE SLEEVE	TATA spare parts
257346200117	WORM RACK ASSY RH	TATA spare parts
257346200119	POPPET VALVE KIT(RANE 42 08 11 00)	TATA spare parts
257346200120	SEAL KIT WORM SHAFT	TATA spare parts
257346200121	SEAL KIT PISTON RACK	TATA spare parts
257346200122	SEAL KIT TRUNION COVER	TATA spare parts
257346200123	SECTOR SHAFT ASSY.	TATA spare parts
257346200124	SEAL KIT SIDE COVER	TATA spare parts

257346200125	RELIEF VALVE ASSY.100 BAR	TATA spare parts
257346200126	KIT SEAL P/STRG G/BOX	TATA spare parts
257346200126AE	MAJOR SEAL KIT 715	TATA spare parts
257346200127	SECTOR SHAFT ASSY	TATA spare parts
257346203001	BALL	TATA spare parts
257346203002	ROLLER BEARING HSG COVER	TATA spare parts
257346203101	BEARING ANGULAR CONTACT	TATA spare parts
257346203103	KIT THRUST BEARING	TATA spare parts
257346203201	BOLT 1/2IN-UNC 1.875INLG.()	TATA spare parts
257346203202	BOLT 5/16IN-18 UNC	TATA spare parts
257346203203	BOLT 5/8INUNF 1-1/8IN	TATA spare parts
257346203401	NEEDLE BUSH	TATA spare parts
257346203402	NEEDLE BUSH	TATA spare parts
257346203403	NEEDLE BUSH	TATA spare parts
257346203710	VAVLE HOUSING	TATA spare parts
257346204705	TRUNNION COVER	TATA spare parts
257346204706	SIDE COVER	TATA spare parts
257346205102	CROSS UNIVERSAL JOINT	TATA spare parts
257346205102AE	ASSY U J 1628	TATA spare parts
257346205301	SIDE COVER GASKET	TATA spare parts
257346206504	NUT DROP ARM	TATA spare parts
257346206505	NUT 1/2 INCH UNF ADJ SCR.	TATA spare parts
257346207201	ADJUSTING RING	TATA spare parts
257346207704	O RING V/HSG (RANR )	TATA spare parts
257346207705	O RING	TATA spare parts
257346207707	O RING	TATA spare parts
257346207801	STRG SEAL DOUBLE LIP	TATA spare parts
257346207902	STRG SPINDLE TOP	TATA spare parts
257346207903	STRG SPINDLE BOTTOM	TATA spare parts
257346207906	STEERING SPINDLE-BOTTOM	TATA spare parts
257346207912	STRG SPINDLE BOTTOM	TATA spare parts
257346207915	STRG SPINDLE TOP LHD	TATA spare parts
257346207919	STRG SPINDLE TOP LPT	TATA spare parts
257346208003	ADJ SCREW POPPET V/HSG	TATA spare parts
257346208005	ADJUSTING SCREW-THRUST	TATA spare parts
257346208202	BALL RET.GUIDE-RH 2NO BS6	TATA spare parts
257346209203	WASHER DROP ARM	TATA spare parts
257346210102	KIT-SEAL P/STRG G/BOX BS1/2/3/4	TATA spare parts
257346210102AE	Maj Seal Kit LPT 2523/LPTA 715	TATA spare parts
257346210104	HOUSING COVER ASSY	TATA spare parts
257346210105	HOUSING ASSY	TATA spare parts
257346210106	HOUSING ASSY.	TATA spare parts
257346210107	HOUSING ASSY	TATA spare parts
257346210108	SUPPORT RING	TATA spare parts
257346210109	PISTON ASSY	TATA spare parts
257346210110	WORM & PISTON LHD LPO	TATA spare parts
257346210111	WORM AND PISTON ASSY	TATA spare parts

257346210116	ASSY. POWER STEERING GEAR BOX BS1	TATA spare parts
257346214302	LOCK RING	TATA spare parts
257346216302	GASKET	TATA spare parts
257346216303	O RING 114.3 X 116.3 X 2	TATA spare parts
257346216304	GASKET	TATA spare parts
257346216305	GASKET	TATA spare parts
257346216306	GASKET	TATA spare parts
257346216308	GASKET 99.4 X 102 X 2.6	TATA spare parts
257346216501	HEX NUT M42 X 1.5	TATA spare parts
257346216502	NUT SEALING	TATA spare parts
257346216503	HEX NUT	TATA spare parts
257346216601	VALVE	TATA spare parts
257346217201	SCREW PLUG	TATA spare parts
257346217702	DUST SEAL 48 X 68 X 20	TATA spare parts
257346217704	O RING	TATA spare parts
257346217707	PROTECTIVE CAP	TATA spare parts
257346217712	O RING 11.5 X 2	TATA spare parts
257346217713	SEAL SHAFT BS1/2/3/4/6	TATA spare parts
257346217714	O RING	TATA spare parts
257346217715	O RING	TATA spare parts
257346217716	O RING	TATA spare parts
257346217717	O RING	TATA spare parts
257346217718	O RING	TATA spare parts
257346217902	SECTOR SHAFT ASSY	TATA spare parts
257346217904	STRG SPINDLE TOP	TATA spare parts
257346218004	HEX SCREW	TATA spare parts
257346218005	HEX SCREW	TATA spare parts
257346218006	HEX SCREW	TATA spare parts
257346219201	TAB WASHER	TATA spare parts
257346219203	WASHER	TATA spare parts
257346219901	VALVE INSERT	TATA spare parts
257346305104	PITMAN ARM RHD	TATA spare parts
257346305105	PITMAN ARM LHD	TATA spare parts
257346305112	DROP ARM	TATA spare parts
257346400101	STRG WHEEL 550 DIA	TATA spare parts
257346400102	ASSY STEERING WHEEL 500 DIA	TATA spare parts
257346400103	STRG WHEEL	TATA spare parts
257346400104	STRG WHEEL	TATA spare parts
257346400105	ASSY COVER	TATA spare parts
257346400108	ASSY STEERING WHEEL 500 DIA	TATA spare parts
257346400110	COVER STG WHEEL	TATA spare parts
257346400111	STRG WHEEL 550 DIA	TATA spare parts
257346400112	STRG WHEEL 550 DIA	TATA spare parts
257346400113	COVER STRG WHEEL	TATA spare parts
257346400114	STRG WHEEL	TATA spare parts
257346400115	ASSY STEERING WHEEL 500 DIA	TATA spare parts
257346400116	STRG WHEEL 550 DIA	TATA spare parts

257346400118	ASSY STEERING WHEEL 500 DIA	TATA spare parts
257346400119	ASSY STEERING WHEEL 550 DIA.	TATA spare parts
257346400120	STRG WHEEL 500 DIA NEW	TATA spare parts
257346400121	STRG WHEEL 550 DIA NEW	TATA spare parts
257346406302	COVER FOR STRG WHEEL 0118	TATA spare parts
257346600101	STRG GEAR BOX POWER RHD	TATA spare parts
257346600102	ASSY.POWER STG.GEAR BOX	TATA spare parts
257346600103	KIT POWER STRG	TATA spare parts
257346600105	HOUSING ASSY	TATA spare parts
257346600106	VALVE INSERT ASSY	TATA spare parts
257346600107	PISTON ASSY	TATA spare parts
257346600108	SECTOR SHAFT ASSY	TATA spare parts
257346603701	HOUSING ASSEMBLY BS6	TATA spare parts
257346607801	SHAFT SEAL	TATA spare parts
257346990101	INPUT SHAFT SEAL KIT	TATA spare parts
257346990103	THRUST BEARING KIT ALTERNATE	TATA spare parts
257346990104	WORM RACK ASSY	TATA spare parts
257346990106	VALVE HSG ASSY RH	TATA spare parts
257346993001	ROLLER BEARING	TATA spare parts
257346998201	BALL RETURN GUIDE RH	TATA spare parts
257346999201	SPRING WASHER	TATA spare parts
257347100101	FUEL TANK LH	TATA spare parts
257347100102	FUEL TANK RH	TATA spare parts
257347100104	ASSY FUEL TANK RH - 160 LTR	TATA spare parts
257347100107	FUEL SCREEN FILTER	TATA spare parts
257347100108	SUCTION TUBE	TATA spare parts
257347100109	FUEL SCREEN FILTER	TATA spare parts
257347100161	ASSY. FUEL TANK 160 LTR BS2/3/4	TATA spare parts
257347500104	SUPPORT W/STRAP	TATA spare parts
257347500105	SUPPORT W/STRAP	TATA spare parts
257347500112	SUPPORT FUEL TANK	TATA spare parts
257347500116	ASSY SUPPORT	TATA spare parts
257347500117	ASSY STRAP	TATA spare parts
257347500122	WELDING DRG.OF ASSY.BKT.&ASSY.SUPPORT	TATA spare parts
257347500125	ASSY BRACKET WITH SUPPORT	TATA spare parts
257347506702	PIN	TATA spare parts
257347600104	OVER FLOW RETURN LINE	TATA spare parts
257347600106	FUEL FEED LINE ASSEMBLY	TATA spare parts
257347600107	OVER FLOW RETURN LINE	TATA spare parts
257347600109	OVER FLOW RETURN LINE	TATA spare parts
257347600110	OVER FLOW RETURN LINE	TATA spare parts
257347600116	FUEL LINE	TATA spare parts
257347600117	FUEL LINE	TATA spare parts
257347600118	ASY.FUEL LINE	TATA spare parts
257347600119	OVER FLOW RETURN LINE	TATA spare parts
257347600120	OVER FLOW RETURN LINE	TATA spare parts
257347620102	ASSY.FUEL LINE	TATA spare parts

257347630153	PIPE	TATA spare parts
257347630154	SUCTION LINE	TATA spare parts
257347630157	ASSY SUCTION LINE LPT1613	TATA spare parts
257347630163	ASSY SUCTION LINE	TATA spare parts
257349000101	BRACKET	TATA spare parts
257349000102	BRACKET	TATA spare parts
257349000103	BRACKET SE RHD	TATA spare parts
257349000116	ASSY BRACKET EXHAUST 2213	TATA spare parts
257349007502	RUBBER BUFFER	TATA spare parts
257349008206	BRACKET	TATA spare parts
257349100125	ASSY EXHAUST PIPE FRONT	TATA spare parts
257349100128	ASSY.EXHAUST PIPE FRT.	TATA spare parts
257349108201	SUPPORT	TATA spare parts
257349108203	SUPPORT	TATA spare parts
257349200130	ASSY EXH PIPE FRONT TO SILENCER	TATA spare parts
257349200134	EXHAUST PIPE INTERMEDIATE	TATA spare parts
257349200137	ASSY INT EXH PIPE FRONT	TATA spare parts
257350000101	RADIATOR FRAME W/TOP BKT	TATA spare parts
257350000107	RADIATOR FRAME W/TOP BKT	TATA spare parts
257350000108	BRACKET RH RAD MTG	TATA spare parts
257350000109	BRACKET LH RADIATOR MTG	TATA spare parts
257350000112	BRACKET	TATA spare parts
257350000114	RADIATOR FRAME	TATA spare parts
257350000118	RAD FRAME W/O BKT	TATA spare parts
257350005805	RUBBER HOSE	TATA spare parts
257350005806	RUBBER HOSE	TATA spare parts
257350005810	RUBBER HOSE RAD-THERMO	TATA spare parts
257350006901	SPACER TUBE-90 LONG	TATA spare parts
257350006901AE	SPACER TUBE (90 LONG)LPA 1415/	TATA spare parts
257350006902	SPACER TUBE 60MM LONG	TATA spare parts
257350006904	SPACER TUBE (75 LONG)	TATA spare parts
257350006905	SPACER TUBE 40MM LONG	TATA spare parts
257350006906	SPACER TUBE	TATA spare parts
257350006907	SPACER TUBE 65 LONG	TATA spare parts
257350009903	TIE ROD RAD 160MM LONG	TATA spare parts
257350009904	TIE ROD-185 LONG	TATA spare parts
257350009905	TIE ROD-175 LONG	TATA spare parts
257350009906	TIE ROD RADIATOR	TATA spare parts
257350100101	RADIATOR ASSY	TATA spare parts
257350100106	RADIATOR ASSY	TATA spare parts
257350105801	RUBBER HOSE	TATA spare parts
257352300101	FLOOR PANEL RH	TATA spare parts
257352400136	FACE SIDE LH W/FRAME	TATA spare parts
257352400138	FACE SIDE RH	TATA spare parts
257352408254	BRACKET BS6	TATA spare parts
257352410108	RETAINING SCREW	TATA spare parts
257352410129	CENTRE PANEL	TATA spare parts

257352410146	FACE SIDE LH W/FRAME	TATA spare parts
257352418241	CROSS MEMBER	TATA spare parts
257352700106	ENGINE HOOD ASSY LP	TATA spare parts
257352704201	CLAMP ENG HOOD BEADING	TATA spare parts
257352704202	CLAMP CORNER ENG HOOD BDG	TATA spare parts
257352707702	SEALING RUBBER	TATA spare parts
257354100117	BATTERY CABLE +VE	TATA spare parts
257354100119	BATTERY CABLE +VE	TATA spare parts
257354100129	ASSY TRAY	TATA spare parts
257354100134	BATTERY CABLE +VE	TATA spare parts
257354100135	LINK BATTERY CABLE	TATA spare parts
257354100136	BATTERY CABLE -VE	TATA spare parts
257354100144	BATTERY CABLE +VE	TATA spare parts
257354100150	CABLE PVC 1C 50 RED 1591 LG	TATA spare parts
257354100161	LINK BATTERY CABLE 50MM	TATA spare parts
257354106302	BALATA PACKING	TATA spare parts
257354108801	BENT STUD (FOR BATT CLAMPLING)	TATA spare parts
257354108803	BENT STUD	TATA spare parts
257354108804	BENT STUD (235 LG)	TATA spare parts
257354108806	BENT STUD-250MM.LONG (FOR BATT.CLAMPING)	TATA spare parts
257354108808	BENT STUD [ 320 LG.]	TATA spare parts
257354110108	BATTERY CABLE -VE	TATA spare parts
257354110110	BATTERY CABLE -VE CU	TATA spare parts
257354110112	ASSY COPPER BATTERY CABLE -VE	TATA spare parts
257354110113	BATTERY CABLE -VE CU	TATA spare parts
257354110114	CABLE PVC 1C 50 BLACK 1841 LG	TATA spare parts
257354110115	ASSY.BATTERY CABLE (-VE)	TATA spare parts
257354200104	SPEEDOCABLE LP	TATA spare parts
257354200105	SPEEDOCABLE	TATA spare parts
257354200119	HOSE ASSY	TATA spare parts
257354200127	HOSE ASSY	TATA spare parts
257354200143	PIPE OIL PRESSURE	TATA spare parts
257354200144	ASSY PIPE	TATA spare parts
257354200147	TANK UNIT FUEL GAUGE	TATA spare parts
257354200150	TANK UNIT	TATA spare parts
257354200151	TANK UNIT ASSY	TATA spare parts
257354200152	PIPE OIL PRESSURE GAUGE	TATA spare parts
257354200153	ASSY.PIPE 6DIA.X0.7THK.X1250LG.	TATA spare parts
257354200154	ASSY HORN	TATA spare parts
257354200155	HOSE AIR PR GAUGE L/E	TATA spare parts
257354200156	TANK UNIT SE/1613/SK	TATA spare parts
257354200165	TANK UNIT	TATA spare parts
257354200175	ASSY HOSE	TATA spare parts
257354200602	GAUGE OIL PRESSURE	TATA spare parts
257354200702	GAUGE AIR PRESSURE	TATA spare parts
257354200901	WATER TEMP GAUGE	TATA spare parts
257354201001	AMMETER	TATA spare parts

257354201101	GAUGE FUEL	TATA spare parts
257354201118	FUEL GAUGE	TATA spare parts
257354201201	WATER TEMP GAUGE	TATA spare parts
257354204203	CLAMP	TATA spare parts
257354206901	PIPE 6 X 1	TATA spare parts
257354208205	CLIP	TATA spare parts
257354209905	3.2 DIA SPEEDOCABLE-3000LG.	TATA spare parts
257354209914	GROMMET	TATA spare parts
257354209915	GAUGE AIR PRESSURE	TATA spare parts
257354209916	GAUGE OIL PRESSURE	TATA spare parts
257354209917	AMMETER	TATA spare parts
257354209918	GAUGE FUEL	TATA spare parts
257354209919	WATER TEMP GAUGE	TATA spare parts
257354209920	SPEEDOMETER	TATA spare parts
257354209921	SPEEDOMETER	TATA spare parts
257354209928	SPEEDOCABLE 5.0D	TATA spare parts
257354209932	GAUGE OIL PRESSURE	TATA spare parts
257354209933	BEEPER ALARM UNIT	TATA spare parts
257354209938	SPEEDOCABLE 3000MM	TATA spare parts
257354209939	SPEEDOCABLE 3000MM	TATA spare parts
257354209950	SPEEDOCABLE 3600MM 3.2D	TATA spare parts
257354209953	SPEEDOCABLE 2200MM	TATA spare parts
257354209954	SPEEDOCABLE 3000MM	TATA spare parts
257354209955	SPEEDOCABLE 2750MM	TATA spare parts
257354209958	SPEEDOCABLE 2750 MM LP	TATA spare parts
257354209960	BEEPER ALARM UNIT	TATA spare parts
257354209963	BEEPER ALARM UNIT	TATA spare parts
257354209965	BEEPER ALARM UNIT 24V	TATA spare parts
257354209966	SPEEDO CABLE 2750 LONG.	TATA spare parts
257354209967	SPEEDOCABLE 2750MM JIS	TATA spare parts
257354209968	SPEEDOCABLE2750MM 3.2DIA	TATA spare parts
257354209969	BEEPER ALARM UNIT 12V	TATA spare parts
257354209971	BEEPER ALARM UNIT	TATA spare parts
257354209972	3.2 DIA SPEEDOCABLE-3000LG.	TATA spare parts
257354209973	3.2 DIA SPEEDOCABLE-3000LG.	TATA spare parts
257354209974	TANK UNIT	TATA spare parts
257354242001	HORN 24V	TATA spare parts
257354242002	HORN 24V	TATA spare parts
257354249901	BEEPER ALARM UNIT 24V	TATA spare parts
257354249903	HORN DISC TYPE 24V	TATA spare parts
257354249906	HORN (24V) (M/s.E.D. Telco)	TATA spare parts
257354249910	HORN 24V W/O RIS CAPACITOR BS1/2/3/4	TATA spare parts
257354249910AE	HORN 24V(W/O CAPACITOR)-1628-715	TATA spare parts
257354400101	HEAD LAMP	TATA spare parts
257354400108	HEAD LAMP LH	TATA spare parts
257354400109	HEAD LAMP	TATA spare parts
257354400110	HEAD LAMP LH	TATA spare parts



257354400111	HEAD LAMP RH	TATA spare parts
257354400122	HEAD LAMP LH RHD	TATA spare parts
257354400128	TAIL LAMP RH	TATA spare parts
257354400129	TAIL LAMP LH	TATA spare parts
257354400137	ASSY.RECT.HEAD LAMP RH.CR-51092	TATA spare parts
257354400158	HEAD LAMP RH RHD	TATA spare parts
257354400160	HEAD LAMP LH RHD	TATA spare parts
257354400167	HEAD LAMP RH	TATA spare parts
257354400174	ASSY H/L PC RIM W/HALO BULB 12V RH	TATA spare parts
257354400176	ASSY H/L PC RIM W/HALO BULB 12V LH	TATA spare parts
257354400182	ASSY HD LAMP RH W/HALO BU	TATA spare parts
257354400184	ASSY H/L PC RIM W/HALO BULB 12V LH	TATA spare parts
257354400190	HEAD LAMP RH RHD	TATA spare parts
257354400191	HEAD LAMP LH RHD	TATA spare parts
257354400192	HEAD LAMP LH RHD	TATA spare parts
257354400603	FLASHER KIT 12V	TATA spare parts
257354406300	GLASS	TATA spare parts
257354406302	GLASS	TATA spare parts
257354408201	BRACKET BEEPER MTG	TATA spare parts
257354408203	BRACKET TAIL LAMP	TATA spare parts
257354409501	BLINKER LAMP LH	TATA spare parts
257354409502	BLINKER LAMP RH	TATA spare parts
257354410110	ASSY.H/L W/HALO BULB 12V RH LHD	TATA spare parts
257354410112	ASSY.H/L W/HALO BULB 12V RH LHD	TATA spare parts
257354410127	HEAD LAMP RH	TATA spare parts
257354410128	HEAD LAMP RH	TATA spare parts
257354410129	HEAD LAMP LH	TATA spare parts
257354410130	HEAD LAMP LH	TATA spare parts
257354410131	ASSY ROUND HEAD LAMP W12V BULB	TATA spare parts
257354410136	ASSY REFLEX REFLECTOR-AMBER	TATA spare parts
257354410137	ASSY REFLEX REFLECTOR - WHITE	TATA spare parts
257354410140	ASSY REFLEX REFLECTOR	TATA spare parts
257354410145	HEAD LAMP LH W/BULB 1612	TATA spare parts
257354410147	HEAD LAMP RH W/BULB 1612	TATA spare parts
257354410149	ASSY H/L PC RIM W/HALO BULB 12V LH	TATA spare parts
257354410151	ASSY H/L PC RIM W/HALO BULB 12V RH	TATA spare parts
257354410157	ASSY 4 CH. TAIL LAMP LH	TATA spare parts
257354410158	ASSY 4 CH. TAIL LAMP RH	TATA spare parts
257354410159	ASSY HEAD LAMP W/BULB-LH	TATA spare parts
257354410160	ASSY H/L PC RIM W/BULB RH	TATA spare parts
257354420107	TAIL LAMP RH	TATA spare parts
257354420108	TAIL LAMP LH	TATA spare parts
257354420118	KIT BLINKER LAMP LH & RH WITH BULB	TATA spare parts
257354440101	HEAD LAMP LH 24V	TATA spare parts
257354440102	HEAD LAMP RH 24V	TATA spare parts
257354440103	HEAD LAMP LH 24V	TATA spare parts
257354440104	HEAD LAMP RH 24V	TATA spare parts

257354440105	ASSY.HEAD LAMP W/BULB-24V.LH/RHD	TATA spare parts
257354440106	ASSY.HEAD LAMP W/BULB-24V.RH-RHD	TATA spare parts
257354440113	ASSY.4-CHAMBER TAIL LAMP	TATA spare parts
257354440115	TAIL LAMP RH	TATA spare parts
257354440116	TAIL LAMP LH	TATA spare parts
257354440119	HEAD LAMP RH LHD 24V	TATA spare parts
257354440120	ASSY HALO HD.LAMP W/BULB LH LHD 24V	TATA spare parts
257354440121	HEAD LAMP RH LHD 24V	TATA spare parts
257354440122	HEAD LAMP LH LHD 24V	TATA spare parts
257354440133	ASSY HEAD LAMP RH WITH HALOGEN BULB	TATA spare parts
257354440134	ASSY HEAD LAMP LH WITH HALOGEN BULB	TATA spare parts
257354440135	ASSY HEAD LAMP RH WITH HALOGEN BULB	TATA spare parts
257354440136	ASSY HEAD LAMP LH WITH HALOGEN BULB	TATA spare parts
257354440137	ASSY INDICATOR LAMP-BATTERY	TATA spare parts
257354440138	ASSY INDICATOR LAMP-HAND BRAKE	TATA spare parts
257354440139	ASSY IND LAMP (LOW AIR PR	TATA spare parts
257354440140	ASSY IND.LAMP-EX.BR.ON	TATA spare parts
257354440147	ASSY.HEAD LAMP W/BULB-24V.LH/RHD	TATA spare parts
257354440149	ASSY.HEAD LAMP W/BULB-24V.RH-RHD	TATA spare parts
257354440151	ASSY HEAD LAMP LH WITH HALOGEN BULB	TATA spare parts
257354440153	ASSY HEAD LAMP RH WITH HALOGEN BULB	TATA spare parts
257354500101	COMBI SWITCH	TATA spare parts
257354500105	FUSE BOX	TATA spare parts
257354500107	ASSY. HAZARD WARNING SWITCH	TATA spare parts
257354500110	FUSE BOX	TATA spare parts
257354500111	FUSE BOX BLACK OUT	TATA spare parts
257354500114	HAZARD WARNING SWITCH	TATA spare parts
257354500117	ASSY. HAZARD WARNING SWITCH	TATA spare parts
257354500601	HAZARD WARNING SWITCH	TATA spare parts
257354502401	COMBI SWITCH	TATA spare parts
257354504601	HAZARD WARNING SWITCH	TATA spare parts
257354506901	PIANO KEY SWITCH	TATA spare parts
257354506902	PIANO SWITCH	TATA spare parts
257354506906	PIANO SWITCH BR FAIL IND	TATA spare parts
257354509903	MULTIPLE ADAPTER	TATA spare parts
257354509904	LOW AIR PR IND SWITCH	TATA spare parts
257354509909	FUSE BOX 12 POLE	TATA spare parts
257354509910	COVER DUMMY GAUGE	TATA spare parts
257354509913	MAIN LINE SWITCH	TATA spare parts
257354509914	LOW AIR PR IND SWITCH	TATA spare parts
257354509915	FUSE LINK 8 AMP	TATA spare parts
257354509916	FUSE LINK 10 AMP	TATA spare parts
257354509918	DIODE MODULE	TATA spare parts
257354509926	STARTER PUSH BUTTON	TATA spare parts
257354509927	STARTER PUSH BUTTON	TATA spare parts
257354509928	STARTER PUSH BUTTON	TATA spare parts
257354509931	BATTERY CUT OFF SWITCH	TATA spare parts

257354509931AE	BATTERY CUT OFF SWITCH 1828 715	TATA spare parts
257354509932	BATTERY CUT OFF SWITCH	TATA spare parts
257354509933	BATTERY CUT-OFF SWITCH	TATA spare parts
257354509935	BATTERY CUT OFF SWITCH	TATA spare parts
257354509937	BATTERY CUT OFF SWITCH	TATA spare parts
257354509938	BATT.CUT OFF SWITCH (1-POLE)	TATA spare parts
257354540103	HAZARD WARNING SWITCH 24V	TATA spare parts
257354540106	HAZARD WARNING SWITC 24V	TATA spare parts
257354540108	HAZARD WARNING SWITCH 24V.	TATA spare parts
257354544601	FLASHER KIT 24V 1210	TATA spare parts
257354600107	CABLE SET LPT342/42 R	TATA spare parts
257354600121	MAIN CABLE SET LP/52	TATA spare parts
257354600135	MAIN CABLE SET CR20154	TATA spare parts
257354607504	RUBBER GROMMET (ELLIPTICAL 95X55)	TATA spare parts
257354620137	MAIN CABLE SET	TATA spare parts
257354620161	MAIN CABLE SET RHD	TATA spare parts
257354620197	MAIN CABLE SET RHD	TATA spare parts
257354630101	MAIN CABLE SET LHD	TATA spare parts
257354640151	CABLE	TATA spare parts
257354640182	ASSY CABLE SET GUAGE EARTHING	TATA spare parts
257354660116	MAIN CABLE SET LPTLE DAOH	TATA spare parts
257354660135	MAIN CABLE SET LP RHD	TATA spare parts
257354660144	ASSY CABLE SET HORN	TATA spare parts
257354809901	COVER WARNING LAMP	TATA spare parts
257354820117	ASSY MAIN CABLE SET	TATA spare parts
257354820118	CABLE SET FRT TO TAIL	TATA spare parts
257354820130	MAIN CABLE SET	TATA spare parts
257354820135	ASSY.MAIN CABLE SET(LHD)S-CAM LPO	TATA spare parts
257354820137	ASSY CABLE(FRT TO TAIL)LPO 55/S-CAM LHD	TATA spare parts
257354820141	MAIN CABLE SET	TATA spare parts
257358109901	TOMMY BAR	TATA spare parts
257358900103	SOCKET WRENCH PROT SLEEVE	TATA spare parts
257358900206	DRIFT CYL LINER REMOVAL	TATA spare parts
257358900207	DRIFT CYL LINER REMOVAL	TATA spare parts
257358900501	SWAN NECK TUBE	TATA spare parts
257358901302	SPL TOOL FOR S CAM A/C HD	TATA spare parts
257358902401	ENGINE REPAIR STAND	TATA spare parts
257358903201	PULLER SPG PIN REMOVAL	TATA spare parts
257358903501	DIAL GAUGE HOLDER	TATA spare parts
257358903701	STAND CARRIER HSG	TATA spare parts
257358904201	ADAPTOR	TATA spare parts
257360000171	COWL BARE RHD	TATA spare parts
257360000173	COWL COMPLT W/FIT	TATA spare parts
257360000175	COWL COMPLT W/FIT	TATA spare parts
257360010166	COWL COMPLT RHD 1210LPT	TATA spare parts
257360100111	ASSY SUPPORT RH	TATA spare parts
257360100112	ASSY SUPPORT LH	TATA spare parts

257360100161	COWL BARE RHD S CAM1612	TATA spare parts
257360100163	COWL COMPLT RHD W/FIT	TATA spare parts
257360100165	ASSY COWL COMPLETE 1510	TATA spare parts
257360100171	COWL COMPLT RHD W/FIT	TATA spare parts
257360100177	COWL BARE RHD 1612 LP	TATA spare parts
257360100192	COWL COMPLT LPO/55	TATA spare parts
257360100194	COWL BARE	TATA spare parts
257360100196	ASSY BRACKET-POWER STEERING TANK MTG	TATA spare parts
257360107105	SUPPORT PLATE (DOOR POST BOTTOM) BS6	TATA spare parts
257360108203	GUSSET LH	TATA spare parts
257360108204	GUSSET RH	TATA spare parts
257360110149	ASSY.BRKT.(WIND SHILED WASHER MOUNTING)	TATA spare parts
257360110188	COWL COMPLT RHD 2213/SCAM	TATA spare parts
257360110195	COWL COMPLT LHD W/FIT	TATA spare parts
257360110196	COWL BARE RHD 2213 SCAM	TATA spare parts
257360120121	ASSY BARE COWL LPT 1613	TATA spare parts
257360120131	COWL COMPL. WITH FITMENTS LPT 1613	TATA spare parts
257360120174	ASSY COWL W/FITMENTS 1613 LPT CMVR 2000	TATA spare parts
257360120175	ASSY BARE COWL LPT1613 CMVR2000 697TURBO	TATA spare parts
257360120178	ASSY COWL COMPLETE LP1510 CMVR2K	TATA spare parts
257360120179	BARE COWL LP 1510 CMVR 2000	TATA spare parts
257360120193	ASSY COWL COMPLETE LP1510 E II	TATA spare parts
257360130127	LPT 1613 CMVR PS COWL COMPLETE	TATA spare parts
257360130128	ASSY COWL PAINTED LPT 1613CMVR/48 P STG.	TATA spare parts
257360130131	ASSY.COWL COMPL WITH FITTS-RHD1613 E-II	TATA spare parts
257360130131RF	ASSY.COWL COMPL WITH FITTS-RHD1613 E-II	TATA spare parts
257360130131SJ	ASSY.COWL COMP 1613 LPT BSII SPARE PARTS	TATA spare parts
257361103301	BRACKET TOGGLE CLAMP (E/HOOD)	TATA spare parts
257361200104	ANTI SAGGING BAR	TATA spare parts
257361600109	PEDAL FLOOR RH RHD	TATA spare parts
257361600113	PLATFORM RH RHD	TATA spare parts
257361600114	ASSY PLATFORM LH RHD	TATA spare parts
257361600115	WHEEL ARCH LH RHD	TATA spare parts
257361600141	WHEEL ARCH RH RHD	TATA spare parts
257362500103	FACE SIDE LH W/FRAME LP	TATA spare parts
257362500104	FACE SIDE RH W/FRAME LP	TATA spare parts
257362500122	FACE SIDE LH	TATA spare parts
257362500123	FACE SIDE RH	TATA spare parts
257362500129	FACE SIDE W/FRAME LH LHD	TATA spare parts
257362500130	FACE SIDE W/FRAME RH RHD	TATA spare parts
25736250013035	ASSY.FACE COMP.WITH FRAME-RH+CED+SEALAN	TATA spare parts
257362500133	FACE SIDE COMPLETE	TATA spare parts
25736250013335	ASSY.FACE COMP.WITH FRAME-LH+CED+SEALAN	TATA spare parts
257362500136	FACE SIDE LH LOWERED	TATA spare parts
257362500137	FACE SIDE RH LOWERED	TATA spare parts
257362500140	FACE SIDE LH 1510CNG	TATA spare parts
257362500141	ASSY FACE SIDE COMPLETE W/FRAME RH-LHD	TATA spare parts

257362508204	FACE SIDE LH BS6	TATA spare parts
257362508205	FACE SIDE RH BS6	TATA spare parts
257362508209	FACE SIDE LH	TATA spare parts
257362508210	FACE SIDE RH	TATA spare parts
257368000101	INSTRUMENT PANEL	TATA spare parts
257368900124	INSTRUMENT PANEL WELDED	TATA spare parts
257368900135	INSTRUMENT PANEL WELDED	TATA spare parts
257368900150	ASSY.INSRUMENT PANEL-RHD	TATA spare parts
257368907502	BUTTON	TATA spare parts
257368907703	PROTECTIVE COVER(FOR INSTRUMENT PANEL)	TATA spare parts
257368908231	INSTRUMENT PANEL RHD	TATA spare parts
257369808201	ORNAMENTAL BEADING	TATA spare parts
257369808202	ORNAMENTAL BEADING	TATA spare parts
257370813201	U-CLAMP FRONT	TATA spare parts
257375100101	CENTRE FLAP COMPLT	TATA spare parts
257375100103	HINGE LH CENTRE FLAP	TATA spare parts
257375100104	HINGE RH CENTRE FLAP	TATA spare parts
257375100116	STAY TUBE CENTRE FLAP	TATA spare parts
257375100119	ASSY. CENTRE FLAP COMPLETE BS1/2/3/4/6	TATA spare parts
257375100120	CENTRE FLAP COMPLT	TATA spare parts
257375106906	STAY ROD RH CENTRE FLAP	TATA spare parts
257375108201	PANEL CENTRE FLAP	TATA spare parts
257375108216	PACKING PLATE	TATA spare parts
257375206302	THICK SPACER	TATA spare parts
257381100110	T EMBLEM	TATA spare parts
257381100111	HOUSING COVER LH	TATA spare parts
257381100112	HOUSING COVER RH	TATA spare parts
257381207501	RUBBER GROMMET	TATA spare parts
257381906301	BUTTON PLATFORM	TATA spare parts
257382240101	ELECTRIC WIND SHIELD WASHER KIT 24V	TATA spare parts
257382249901	WIPER MOTOR 17W 24V	TATA spare parts
257382249903	WIPER MOTOR 14W/24V	TATA spare parts
257382400103	WIPER MOTOR	TATA spare parts
257382400112	ASSY WIPER ARM SUPPORT ARM & BLADE	TATA spare parts
257382409901	WIPER BLADE	TATA spare parts
257382409902	WIPER ARM 370 MM	TATA spare parts
257382409905	WIPER MOTOR 14W	TATA spare parts
257383800103	ASSY VENTILATION UNIT (IN	TATA spare parts
257383800104	ASSY VENTILATION UNIT OUTER	TATA spare parts
257383800118	ASSY VENTILATION UNIT COMPLETE OUTER	TATA spare parts
257388500102	ASSY.BUMPER WELDED	TATA spare parts
257388500104	BUMPER COMP NEW	TATA spare parts
257388500105	ASSY.BRACKET RH BUMPER FP	TATA spare parts
257388500106	ASSY.BRACKET LH BUMPER FP	TATA spare parts
257388500112	BUMPER COMP POWDER COATED	TATA spare parts
257388500116	ASSY.BUMPER COMP.WITH REFLECTIVE TAPE	TATA spare parts
257388500116C0	ASSY.BUMPER COMP.WITH REFLECTIVE TAPE	TATA spare parts

257388500119	ASSY.BUMPER COMP.WITH REFLECTOR	TATA spare parts
257388500120	ASSY.SUPPORT-LH-FOR ANTISAGGING BAR	TATA spare parts
257388500121	ASSY.SUPPORT-RH-FOR ANTISAGGING BAR	TATA spare parts
257388700106	ENGINE HOOD COMP RHD L/E	TATA spare parts
257388700116	ENGINE HOOD COMP RHD	TATA spare parts
257388700124	ASSY ENGINE HOOD COMPLETE-RHD	TATA spare parts
257388700160	ENGINE HOOD COMP RHD	TATA spare parts
257388706301	ENGINE HOOD-LOWER ENGINE	TATA spare parts
257388706303	GRAB HANDLE ENG HOOD	TATA spare parts
257388706306	GRAB HANDLE ENG HOOD	TATA spare parts
257388707701	RUBBER MOULD ENG HOOD L/E	TATA spare parts
257389100101	BKT COWL MTG REAR LH	TATA spare parts
257389100102	BKT COWL MTG REAR RH	TATA spare parts
257389100103	BKT COWL MTG REAR LH	TATA spare parts
257389100104	BKT COWL MTG REAR RH	TATA spare parts
257389100105	BKT COWL MTG FRONT LH	TATA spare parts
257389100106	BKT COWL MTG FRONT RH	TATA spare parts
257389100122	ASSY BRKT LH-COWL MTG	TATA spare parts
257389100123	ASSY.BRACKET RH	TATA spare parts
257389100124	ASSY BRACKET LH	TATA spare parts
257389100125	ASSY BRACKET RH	TATA spare parts
257389100128	ASSY BRACKET LH-COWL MTG. REAR	TATA spare parts
257389100129	ASSY BRACKET RH-COWL MTG REAR	TATA spare parts
257389100132	ASSY BRACKET LH COWL MTG.REAR	TATA spare parts
257389100133	ASSY BRACKET RH COWL MTG.REAR	TATA spare parts
257389108216	BRACKET BRAKE HOSE(FRONT AXLE)	TATA spare parts
257389109201	WASHER	TATA spare parts
257391100113	ASSY.BRACKET TOP SAFETY BELT	TATA spare parts
257391206301	PLASTIC SEAT LPT1613	TATA spare parts
257391700108	ASSY MTG BRACKET	TATA spare parts
257391700122	ASSY.SEAT STAND-RHD	TATA spare parts
257398400101	MASCOT 1210D LP PLATED	TATA spare parts
257398400104	MASCOT 1210E PLATED	TATA spare parts
257398809201	CUP WASHER	TATA spare parts
257415000603	HEAT SINK ASSY	TATA spare parts
257415001701	FIXING STUD	TATA spare parts
257415002001	CIRCLIP	TATA spare parts
257415002501	ROTOR ASSY	TATA spare parts
257415002502	STATOR	TATA spare parts
257415002801	SLIP RING END SHIELD	TATA spare parts
257415002802	SLIP RING ASSY	TATA spare parts
257415003001	BEARING DRIVE END	TATA spare parts
257415003002	BEARING SLIP RING END	TATA spare parts
257415004001	DRIVE END SHIELD	TATA spare parts
257415004002	DRIVE END SHIELD	TATA spare parts
257415004601	O RING	TATA spare parts
257415004701	WASHER	TATA spare parts

257415004703	SPRING WASHER	TATA spare parts
257415004704	SPRING WASHER	TATA spare parts
257415004705	SPRING WASHER	TATA spare parts
257415004706	SPRING WASHER -VE TERM	TATA spare parts
257415004801	PLAIN WASHER	TATA spare parts
257415004802	PLAIN WASHER -VE TERMI	TATA spare parts
257415004803	PLAIN WASHER +VE TERMI	TATA spare parts
257415005101	PULLEY NUT	TATA spare parts
257415005102	NUT FIXING STUD	TATA spare parts
257415005103	NUT +VE TERMINAL	TATA spare parts
257415005104	NUT -VE TERMINAL	TATA spare parts
257415005201	SPACER	TATA spare parts
257415005202	FAN SPACER	TATA spare parts
257415005205	FUSE LINK	TATA spare parts
257415005206	FUSE LINK	TATA spare parts
257415005501	POSITIVE TERMINAL	TATA spare parts
257415005502	LEAD ASSY +VE	TATA spare parts
257415005601	TERMINAL -VE	TATA spare parts
257415005602	LAED ASSY NEGATIVE	TATA spare parts
257415006201	INSULATING WASHER	TATA spare parts
257415006202	INSULATING WASHER	TATA spare parts
257415006203	INSULATING BUSH	TATA spare parts
257415006204	BUSH	TATA spare parts
257415007101	FIXING SCREW	TATA spare parts
257415007102	FIXING SCREW	TATA spare parts
257415007104	SCREW	TATA spare parts
257415007601	WOODRUFF KEY	TATA spare parts
257415008001	GASKET	TATA spare parts
257415008201	CLAMP PLATE BEARING	TATA spare parts
257415009301	BRUSH ASSY	TATA spare parts
257415009910	STARTER MOTOR 12V	TATA spare parts
257415009911	STARTER MOTOR 12V	TATA spare parts
257415009912	STARTER MOTOR-12V	TATA spare parts
257415009913	ALTERNATOR	TATA spare parts
257415009914	ALTERNATOR	TATA spare parts
257415019203	JUMP RING	TATA spare parts
257415019206	CUP WASHER	TATA spare parts
257415100101	ALTERNATOR	TATA spare parts
257415100104	STARTER MOTOR-12V	TATA spare parts
257415100106	STARTER MOTOR 12V	TATA spare parts
257415100107	ALTERNATOR 90D PULLEY	TATA spare parts
257415100116	STARTER MOTOR 12V	TATA spare parts
257415100117	STARTER MOTOR	TATA spare parts
257415100601	CE BRACKET	TATA spare parts
257415100603	C E COVER	TATA spare parts
257415100607	DIODE PLATE ASSY	TATA spare parts
257415100608	DIODE PLATE ASSY	TATA spare parts

257415100902	FIELD COIL ASSY	TATA spare parts
257415100903	FIELD COIL ASSY	TATA spare parts
257415100906	FIELD COIL ASSY	TATA spare parts
257415101302	PINION WITH BRG	TATA spare parts
257415101303	DRIVE FOR RING	TATA spare parts
257415101308	FIXING BKT ASSY	TATA spare parts
257415101309	DRIVE ASSY	TATA spare parts
257415101402	CARBON BRUSH	TATA spare parts
257415101403	CARBON BRUSH	TATA spare parts
257415101404	BRUSH GEAR ASSY	TATA spare parts
257415101405	C E BRACKET	TATA spare parts
257415101406	BRUSH HOLDER	TATA spare parts
257415101407	REGULATOR ASSY 12V	TATA spare parts
257415101484	BRUSH GR ASSY	TATA spare parts
257415101501	ARMATURE ASSY	TATA spare parts
257415101502	ARMATURE ASSY	TATA spare parts
257415101503	ARMATURE ASSY	TATA spare parts
257415101504	ARMATURE ASSY	TATA spare parts
257415101602	PULLEY	TATA spare parts
257415101705	BOLT SOL FIXING	TATA spare parts
257415102501	FAN	TATA spare parts
257415102502	ROTOR ASSY 12V	TATA spare parts
257415102503	STATOR ASSY	TATA spare parts
257415102802	DRIVE END BRACKET	TATA spare parts
257415102807	DRIVE END BRACKET	TATA spare parts
257415103002	BEARING REAR	TATA spare parts
257415103401	SOLENOID SWITCH	TATA spare parts
257415103402	SOLENOID SWITCH	TATA spare parts
257415104001	HOUSING FRONT	TATA spare parts
257415104601	BRUSH KIT	TATA spare parts
257415104707	TERMINAL COVER	TATA spare parts
257415104901	C E BEARING	TATA spare parts
257415104903	INNER BRACKET	TATA spare parts
257415104904	INNER BRACKET	TATA spare parts
257415104905	C E BRG BUSH	TATA spare parts
257415105101	NUT PULLEY	TATA spare parts
257415105301	INSULATION STRIP	TATA spare parts
257415105302	SOLENOID SEAL	TATA spare parts
257415105307	SEAL	TATA spare parts
257415105501	TERMINAL	TATA spare parts
257415105503	TERMINAL SHORT	TATA spare parts
257415105504	TERMINAL LONG	TATA spare parts
257415105508	TERMINAL FUSE	TATA spare parts
257415106901	ENGAGING LEVER AXLE	TATA spare parts
257415106902	PIVOT PIN	TATA spare parts
257415107201	BAND COVER NUT	TATA spare parts
257415107205	NUT THIN	TATA spare parts



257415107208	NUT PIVOT PIN	TATA spare parts
257415107301	INNER BRACKET	TATA spare parts
257415107303	TELERIUM CONTACT	TATA spare parts
257415107304	THRUST COLLAR	TATA spare parts
257415107306	THRUST COLLAR	TATA spare parts
257415107384	THRUST COLLAR	TATA spare parts
257415107501	GROMMET	TATA spare parts
257415108401	INSUL BRUSH	TATA spare parts
257415108403	SLEEVE FOR STUD	TATA spare parts
257415109203	JUMP RING	TATA spare parts
257415109204	SHIM	TATA spare parts
257415109206	CUP WASHER	TATA spare parts
257415109209	INSUL WASHER	TATA spare parts
257415109210	INSUL WASHER	TATA spare parts
257415109222	THRUST WASHER	TATA spare parts
257415109223	BRAKE SHOE	TATA spare parts
257415109224	SPRING WASHER	TATA spare parts
257415109225	JUMP RING	TATA spare parts
257415109228	THRUST WASHER STEEL	TATA spare parts
257415109302	SPRING	TATA spare parts
257415109304	SPRING BR SHOE	TATA spare parts
257415109901	BRUSH SPRING	TATA spare parts
257415109912	STARTER MOTOR T-17	TATA spare parts
257415110101	SCREW BRUSH CARRIER ASSY	TATA spare parts
257415110102	C E BRACKET	TATA spare parts
257415110103	BRUSH ASSY	TATA spare parts
257415110104	BRUSH CARRIER	TATA spare parts
257415110105	ARMATURE ASSY	TATA spare parts
257415110107	PLUNGER ASSY	TATA spare parts
257415110108	FIELD COIL ASSY	TATA spare parts
257415110110	LEVER & PEG ASSY	TATA spare parts
257415110111	DRIVE ASSY	TATA spare parts
257415110112	FIXING BKT ASSY	TATA spare parts
257415111904	SOLENOID SWITCH	TATA spare parts
257415113202	THROUGH BOLT	TATA spare parts
257415113301	BEARING BUSH	TATA spare parts
257415113302	BEARING BUSH	TATA spare parts
257415113401	SEALING BUSH	TATA spare parts
257415113402	C E BUSH	TATA spare parts
257415113404	SEALING BUSH	TATA spare parts
257415113405	SEALING BUSH	TATA spare parts
257415114401	THRUST COLLAR	TATA spare parts
257415114601	CONNECTOR	TATA spare parts
257415114801	DOWEL	TATA spare parts
257415114901	FIELD TERMINAL	TATA spare parts
257415114904	SOLENOID SWITCH	TATA spare parts
257415116504	NUT LOCK	TATA spare parts

257415116505	EARTH TERMINAL NUT	TATA spare parts
257415116701	PIVOT PIN	TATA spare parts
257415118001	POLE SCREW	TATA spare parts
257415118701	BRAKE SHOE SPG	TATA spare parts
257415118702	BRUSH SPRING	TATA spare parts
257415119201	THR WASHER STEEL	TATA spare parts
257415119204	INSUL WASHER	TATA spare parts
257415119901	SEAL RING C E	TATA spare parts
257415119902	BRAKE SHOE	TATA spare parts
257415119903	JUMP RING	TATA spare parts
257415119904	SEALING RING D E	TATA spare parts
257415400101	M-127 STARTER/HRND ST.PNN	TATA spare parts
257415400112	STARTER MOTOR 12V	TATA spare parts
257415400113	ALTERNATOR 65A SINGLE GROOVE	TATA spare parts
257415400601	HEAT SINK ASSY +VE	TATA spare parts
257415400602	HEAT SINK ASSY AUX	TATA spare parts
257415400603	HEAT SINK ASSY -VE	TATA spare parts
257415400604	HEAT SINK & DIODE	TATA spare parts
257415400605	DIODE	TATA spare parts
257415401401	BRUSH BOX ASSY	TATA spare parts
257415401402	REGULATOR	TATA spare parts
257415401403	REGULATOR	TATA spare parts
257415401404	BRUSH HOLDER	TATA spare parts
257415401601	PULLEY	TATA spare parts
257415401602	PULLEY	TATA spare parts
257415401701	REG FIXING SCREW	TATA spare parts
257415402303	SRE BEARING INSERT	TATA spare parts
257415402501	FAN ASSY	TATA spare parts
257415402502	STATOR ASSY	TATA spare parts
257415402503	ROTOR ASSY SPR	TATA spare parts
257415402504	FAN	TATA spare parts
257415402802	SRE BKT W/O BRG INSERT	TATA spare parts
257415402805	SRE METAL COWL	TATA spare parts
257415403001	D E BRG FOR SPR	TATA spare parts
257415403002	SRE BRG FOR SPR	TATA spare parts
257415403202	D E BRG CLAMP PLATE	TATA spare parts
257415403802	SRE BRACKET W/O BRG	TATA spare parts
257415404001	D E SHIELD BKT W/BRG	TATA spare parts
257415404002	D E SHIELD BKT W/BRG	TATA spare parts
257415404602	REP KIT FOR GENERATOR	TATA spare parts
257415404620	REP KIT PULL	TATA spare parts
257415404701	WASHER	TATA spare parts
257415404704	COVER ALTERNATOR	TATA spare parts
257415405101	SHAFT NUT	TATA spare parts
257415405102	AUX DIODE ASSY	TATA spare parts
257415405201	FAN SPACER	TATA spare parts
257415405206	FUSE LINK	TATA spare parts

257415405401	DIODE AUX	TATA spare parts
257415405501	TERMINAL POSITIVE	TATA spare parts
257415405601	TERMINAL NEGATIVE	TATA spare parts
257415405902	ALTERNATOR	TATA spare parts
257415407103	THROUGH STUD	TATA spare parts
257415407104	THROUGH STUD	TATA spare parts
257415407601	WOODRUFF KEY	TATA spare parts
257415407801	DUST SEAL	TATA spare parts
257415408201	COVER MOULDED	TATA spare parts
257415409902	ALTERNATOR A115	TATA spare parts
257425400101	CL PR PLATE 310 DIA	TATA spare parts
257425400104	ASSY. CLUTCH PRESSURE PLATE 310 DIA. BS2	TATA spare parts
257425400106	REP KIT MAJOR 3.4MM	TATA spare parts
257425407404	RIVET 3.4 MM DIPHGRAM	TATA spare parts
257425408701	PRESSURE SPRING	TATA spare parts
257425408702	DIPHFRAGM SPRING 3.4MM	TATA spare parts
257428010001	AUX.GEAR BOX W 8-BOLT	TATA spare parts
257428010002	AUX GEAR BOX ASSY	TATA spare parts
257428100102	ASSY. REAR COVER BS6	TATA spare parts
257428103701	COVER RR AUX GR BOX	TATA spare parts
257428150101	BREATHER	TATA spare parts
257428159901	BREATHER	TATA spare parts
257428159902	ADAPTER	TATA spare parts
257428203103	ANGULAR CONTAC T BEARING	TATA spare parts
257428203104	ROLLER CAGE	TATA spare parts
257428207802	OIL SEAL BS1/2/3/4/6	TATA spare parts
257428207802AE	OILSEAL (52-72-12) 1628 1828	TATA spare parts
257428207802DF	OIL SEAL-DRIVE SHAFT-GB1150	TATA spare parts
257428207803	OIL SEAL	TATA spare parts
257428209901	ROLLER 4X12	TATA spare parts
257428250101	COUPLING FLANGE 8 HOLE	TATA spare parts
257428253101	TAPER ROLLER BEARING	TATA spare parts
257428253102	TAPER ROLLER BEARING	TATA spare parts
257428303101	ROLLER CAGE	TATA spare parts
257428303103	ROLLER CAGE	TATA spare parts
257428303104	DEEP GROOVE BALL BEARING	TATA spare parts
257428303105	ROLLER CAGE	TATA spare parts
257428307901	DRIVE SHAFT (REAR AXLE SIDE) BS1/2/3/4	TATA spare parts
257428307901AE	DRVE SFT (RR AXLE SIDE)-1415-715	TATA spare parts
257428308302	SHIM 0.10 MM	TATA spare parts
257428308303	SHIM 0.20 MM	TATA spare parts
257428308304	SHIM 0.40 MM	TATA spare parts
257428308305	SHIM 0.05 MM	TATA spare parts
257428308601	SPACER TUBE DRIVE SHAFT	TATA spare parts
257428308602	SPACER RING (DRIVE SHAFT REAR AXLE SIDE)	TATA spare parts
257428450102	LEVER ASSY	TATA spare parts
257428450103	LINK ROD AUX GR BOX	TATA spare parts

257428450104	LINK ROD AUX GR BOX	TATA spare parts
257428450107	LEVER AUX GEAR BOX	TATA spare parts
257428450116	ASSY LEVER	TATA spare parts
257428450117	LINK ROD AUX GEAR BOX	TATA spare parts
257428457501	RUBBER BELLOW	TATA spare parts
257428458501	SPACER	TATA spare parts
257428556701	PIN MOUNTING	TATA spare parts
257429000106	PEDAL LEVER BRAKE	TATA spare parts
257429000128	SUPPORT PEDAL LEVER CAST	TATA spare parts
257429000129	ASSY.SUP PEDAL LR W CL&BR	TATA spare parts
257429050101	SUPPORT PEDAL LEVER	TATA spare parts
257429100101	CLUTCH PEDAL PLATE	TATA spare parts
257429100107	ASSY CL PEDAL LVR COMP	TATA spare parts
257429100108	CLUTCH PEDAL LEVER	TATA spare parts
257429100128	CLUTCH PEDAL LEVER	TATA spare parts
257429110105	ASSY.LEVER	TATA spare parts
257429119901	SPACER SFC	TATA spare parts
257429200101	BRAKE PEDAL LEVER	TATA spare parts
257429200103	BRAKE PEDAL PLATE	TATA spare parts
257429200113	ASSY DOUBLE BRAKE LEVER	TATA spare parts
257429207901	SHAFT BRAKE LEVER	TATA spare parts
257429210105	BRAKE PEDAL LEVER	TATA spare parts
257429210110	PULL ROD BRAKE	TATA spare parts
257429219901	PULL ROD	TATA spare parts
257429300102	CONTROL ROD CLUTCH	TATA spare parts
257429300107	CONTROL ROD CLUTCH	TATA spare parts
257429300112	CLUTCH ROD 310	TATA spare parts
257429306701	PIN	TATA spare parts
257429309901	FORK HEAD	TATA spare parts
257429309903	FORK	TATA spare parts
257430100106	ACCELERATOR SHAFT	TATA spare parts
257430100107	LEVER ACCELERATOR	TATA spare parts
257430100108	PEDAL ACCELERATOR	TATA spare parts
257430100109	HINGE ASSY	TATA spare parts
257430109901	THRUST ROD	TATA spare parts
257430109902	PULL ROD	TATA spare parts
257430109903	THRUST ROD	TATA spare parts
257430110108	PEDAL ACCELERATOR	TATA spare parts
257431000101	ENG CROSS MEMBER FR SFC	TATA spare parts
257431000108	FRAME WO FRTCPLG & STGBKT	TATA spare parts
257431000113	FRAME ASSY 1210SE/42 RHD	TATA spare parts
257431000116	FRAME W/O FRT CPG W/ST/BR	TATA spare parts
257431000119	FRAMEWSTGBKT&WOFCLG S42R	TATA spare parts
257431000135	ENG CROSS MEMBER FR NLE	TATA spare parts
257431000158	FRAME ASSY 1210SE/42	TATA spare parts
257431000166	FRAME ASSY W/O FR COUPLIN	TATA spare parts
257431000172	FRAME ASSY SE/42 RHD	TATA spare parts

257431000173	FRAME SE36	TATA spare parts
257431000190	FRAME ASSY W/O FRC	TATA spare parts
257431020113	ENG CROSS MEMBER FR	TATA spare parts
257431020161	ENG CROSS MEMBER FR	TATA spare parts
257431040107	FRAME ASSY SE/48	TATA spare parts
257431050117	FRAME ASSY 1210SA/42	TATA spare parts
257431050118	FRAME ASSY W/O FRC	TATA spare parts
257431080124	ASSY FRAME 1210SA/42	TATA spare parts
257431080136	FRAME ASSY W/ST BKT W/O C	TATA spare parts
257431090146	FRAME ASSY SK/36	TATA spare parts
257431090147	FRAME 1210 SE 32/F COUP D	TATA spare parts
257431090153	ASY FRAM W/STG BKT W/O CP	TATA spare parts
257431090154	FRAME ASSY 1210SE/36	TATA spare parts
257431090155	FRAME ASSY SE/42 W/O FRC	TATA spare parts
257431090165	ASSY FRAME COMPLETE	TATA spare parts
257431090166	FRAME ASSY SE/36	TATA spare parts
257431090167	FRAME ASSY 1612/SE/42 RHD	TATA spare parts
257431090168	FRAME	TATA spare parts
257431090173	FRAME ASSY W/ST BKT W/O C	TATA spare parts
257431090174	FRAME ASSY W/ST BKT W/O C	TATA spare parts
257431090175	FRAME ASSY W/ST BKT W/O C	TATA spare parts
257431120111	ASSY. FRAME COMPLETE SK/32 SCAM	TATA spare parts
257431120112	FRAME ASSY 1612/SCAM/SK36	TATA spare parts
257431120113	FRAME ASSY 1612/SE42/SCAM	TATA spare parts
257431120133	FRAME ASSY W/ST BKT W/O C	TATA spare parts
257431120134	FRAME ASSY W/ST BKT W/O C	TATA spare parts
257431120142	FRAME ASSY 1612/SK36/SCAM	TATA spare parts
257431120143	FRAME ASSY 1612/SE42/SCAM	TATA spare parts
257431120148	FRAME ASSY W/O FRC	TATA spare parts
257431170101	FRAME ASSY W/O FRC	TATA spare parts
257431170105	FRAME 1612SE/42 SCAM/WTE	TATA spare parts
257431170110	ASSY.FRAME COMPL 1613 SK/32	TATA spare parts
257431207107	END CROSS MEMBER	TATA spare parts
257431207109	END CROSS MEMBER	TATA spare parts
257431207113	END CROSS MEMBER	TATA spare parts
257431207114	SPACER	TATA spare parts
257431207115	SPACER	TATA spare parts
257431207133	SUPPORT BOTTOM	TATA spare parts
257431207134	SUPPORT TOP	TATA spare parts
257431207142	REINFORCEMENT LH	TATA spare parts
257431250102	CROSS MEMBER AUX GEAR BOX	TATA spare parts
257431253301	SUPPORT BS6	TATA spare parts
257431257101	SUPPORT BOTTOM	TATA spare parts
257431257103	CROSS MEMBER AUX GEAR BOX	TATA spare parts
257431307101	REINFORCEMENT RH TOP	TATA spare parts
257431307102	REINFORCEMENT TOP LH	TATA spare parts
257432100103	FRONT SPRING ASSY	TATA spare parts

257432100104	LEAF SPRING 1ST W/BUSH	TATA spare parts
257432100106	FRONT SPRING ASSY	TATA spare parts
257432100107	ASSY.SEALING RING	TATA spare parts
257432100108	ASSY FIRST LEAF WITH BUSH	TATA spare parts
257432100116	FRONT SPRING ASSY	TATA spare parts
257432100122	KIT SPRING PIN 1210SE FRT	TATA spare parts
257432100123	FRONT SPRING ASSY	TATA spare parts
257432100124	ASSY.FRT.SPRING R.SIDE	TATA spare parts
257432103202	CENTRE BOLT	TATA spare parts
257432104201	SPRING CLAMP INNER	TATA spare parts
257432107114	CASTER PLATE	TATA spare parts
257432107116	LEAF SPRING 3RD FRT	TATA spare parts
257432107118	LEAF SPRING 3RD FRT	TATA spare parts
257432150101	FRONT SPRING ASSY	TATA spare parts
257432150102	FRONT SPRING ASSY	TATA spare parts
257432153201	CENTRE BOLT	TATA spare parts
257432153202	CENTRE BOLT	TATA spare parts
257432203401	BUSH FRT SPRG	TATA spare parts
257432253701	BKT FRT SPRING	TATA spare parts
257432253706	GUIDE PLATE FRT SPRING	TATA spare parts
257432255101	SPRING SADDLE FRONT SPRING	TATA spare parts
257432300101	SHOCK ABSORBER FRONT	TATA spare parts
257432300103	SHOCK ABSORBER FRONT	TATA spare parts
257432300104	BKT S/ABS FRONT	TATA spare parts
257432300105	SHOCK ABSORBER	TATA spare parts
257432308601	MOUNTING SLEEVE	TATA spare parts
257432308602	BUSH FRT S/ABS	TATA spare parts
257432350107	SHOCK ABSORBER FRONT	TATA spare parts
257432350108	SHOCK ABSORBER FRONT	TATA spare parts
257432350109	SHOCK ABSORBER FRONT BS1/2/3/4	TATA spare parts
257432350109AE	SHOCK ABSORBER FRONT 1415 715	TATA spare parts
257432355101	SHOCK ABSR BRKT LOWER (ON FRT AXLE)	TATA spare parts
257432400101	REAR SPRING ASSY	TATA spare parts
257432407101	LEAF SPRING 3RD AUX	TATA spare parts
257432407102	LEAF SPRING 4TH RR AUX	TATA spare parts
257432407103	LEAF SPRING 5TH AUX	TATA spare parts
257432407105	SPACER PLATE	TATA spare parts
257432553701	SPACER REAR AXLE MOUNTING	TATA spare parts
257432650102	CROSS MEMBER RR S/ABS	TATA spare parts
257432650106	CROSS MEMBER RR S/ABS	TATA spare parts
257432658206	END PLATE	TATA spare parts
257432658207	PACKING PLATE	TATA spare parts
257433000109	FRONT AXLE ASSY	TATA spare parts
257433000113	TIE ROD ASSY	TATA spare parts
257433000123	FRONT AXLE ASSY W/BR RHD	TATA spare parts
257433000125	FRONT AXLE ASSY W/BR RHD	TATA spare parts
257433000129	FRONT AXLE ASSY W/BR RHD	TATA spare parts

257433050105	FRONT AXLE ASSY FA104 RHD	TATA spare parts
257433050111	FRONT AXLE HSG W/SUP TUBE	TATA spare parts
257433050112	ASSY F-A COMPLETE 4X4	TATA spare parts
257433050115	ASY FRT AXLE COMP W BRAKE	TATA spare parts
257433050119	ASSY FRT AXLE HSG. W SUPPORT TUBE	TATA spare parts
257433050120	ASSY FRONT AXLE HSG WITH BEARING COVER	TATA spare parts
257433050123	ASSY FRONT AXLE COMP.WITH BRAKES	TATA spare parts
257433050128	ASSY FRONT AXLE	TATA spare parts
257433050130	FRONT HUB ASSY COMPLETE	TATA spare parts
257433050130AE	ASSY HUB COMPLETE 713	TATA spare parts
257433050131	ASSY HUB W/S BOLT	TATA spare parts
257433056001	TIE ROD ASSY	TATA spare parts
257433056002	ASSY. TIE ROD	TATA spare parts
257433150101	ASSY SUPPORT RUBBER BUFFR	TATA spare parts
257433150102	FILTER BREATHER	TATA spare parts
257433150103	ASSY.HOLDER ( FILTER BREATHER )	TATA spare parts
257433150104	ADAPTER W/PLUG	TATA spare parts
257433154201	U CLAMP FR RH SIDE	TATA spare parts
257433154202	U CLAMP FR LH SIDE	TATA spare parts
257433154213	U CLAMP 17R205MM	TATA spare parts
257433154214	U CLAMP	TATA spare parts
257433154215	U CLAMP 17R220MM	TATA spare parts
257433154216	U CLAMP	TATA spare parts
257433154304	LOCKING RING FRONT	TATA spare parts
257433154305	LOCKING RING INNER	TATA spare parts
257433154307	LOCKING WIRE (FILTER BREATHER )	TATA spare parts
257433156901	FRONT AXLE SUPPORTING TUBE-RH BS6	TATA spare parts
257433156902	FRONT AXLE SUPPORTING TUBE-LEFT BS6	TATA spare parts
257433157701	RUBBER RING (FILTER BREATHER)	TATA spare parts
257433158203	CAP (FILTER BREATHER)	TATA spare parts
257433158204	SEAL HOLDER OUTER	TATA spare parts
257433158205	SEAL HOLDER INNER	TATA spare parts
257433158601	SPACER	TATA spare parts
257433200101	STUB AXLE STD	TATA spare parts
257433200104	STUB AXLE	TATA spare parts
257433200109	STUB AXLE STD	TATA spare parts
257433200113	STUB AXLE STD	TATA spare parts
257433253101	BEARING NEEDLE CAGE	TATA spare parts
257433253102	BEARING NEEDLE CAGE	TATA spare parts
257433253103	NEEDLE ROLLER BRG 506525	TATA spare parts
257433253104	AXIAL ROLLER BRG T 126	TATA spare parts
257433253106	BEARING TAPER ROLLER	TATA spare parts
257433255102	KING PIN UPPER	TATA spare parts
257433255102AE	KING PIN UPPER 715	TATA spare parts
257433256501	GROOVED NUT	TATA spare parts
257433258601	THRUST WASHER	TATA spare parts
257433258602	THRUST WASHER	TATA spare parts

257433400101	HUB FRONT W/O MTG BOLT	TATA spare parts
257433400103	HUB FRONT WHEEL	TATA spare parts
257433400105	HUB FRT W/BRG MOD 60 NSPG	TATA spare parts
257433400109	HUB FRONT W/BRG NM 60 SPG	TATA spare parts
257433400110	HUB FR W/O BRG MOD 60 NSP	TATA spare parts
257433400111	HUB FRT W/O BRG M 60 SPG	TATA spare parts
257433400114	HUB FRONTWHEEL	TATA spare parts
257433400115	HUB FRT W/BRG MOD 60 SPG	TATA spare parts
257433403701	COVER FRONT HUB	TATA spare parts
257433405101	HUB FR W/O BRG M 63.5 NSP	TATA spare parts
257433405102	PRESSURE RING	TATA spare parts
257433405103	HUB FR W/O BRG M 63.5 SPG	TATA spare parts
257433405104	FRONT HUB	TATA spare parts
257433406501	CASTLE NUT	TATA spare parts
257433408303	SHIM 1.5MM	TATA spare parts
257433408304	SHIM 1MM THK FRT HUB	TATA spare parts
257433408305	SHIM 0.5 MM THK	TATA spare parts
257433408306	SHIM 0.3 MM THK	TATA spare parts
257433408307	SHIM 0.1 MM THK	TATA spare parts
257433408308	SHIM 0.05 MM THK	TATA spare parts
257433408601	SPACER RING	TATA spare parts
257433409201	THRUST WASHER	TATA spare parts
257433453101	TAPER ROLLER BRG HUB INNER	TATA spare parts
257433453102	TAPER ROLLER BRG HUB INNER	TATA spare parts
257433453103	TAP ROLLER BEARING	TATA spare parts
257433453104	TAPER ROLLER BRG 30214	TATA spare parts
257433453104AE	TAPER RLR BRG LPA 1415	TATA spare parts
257433453105	BEARING TAPER ROLLER	TATA spare parts
257433453106	TAPER ROLLER BRG HUB INNER	TATA spare parts
257433453107	TAPER ROLLER BRG. HUB INNER	TATA spare parts
257433453108	TAPER ROLLER BRG HUB INNER	TATA spare parts
257433455102	HUB (SPIGOTTED)(FRONT AXLE)	TATA spare parts
257433455501	HUB	TATA spare parts
257433457801	SEALING RING FRONT WHEEL HUB	TATA spare parts
257433457801AE	SEALING RING FRT WHEEL HUB-1415	TATA spare parts
257433553101	BEARING CYL ROLLER	TATA spare parts
257433750103	FRONT AXLE DRIVE SHAFT COMP. RH BS2/3/4	TATA spare parts
257433750104	FRONT AXLE DRIVE SHAFT COMP. LH BS2/3/4	TATA spare parts
257433750108	DRIVE SHAFT FRT RH GWB	TATA spare parts
257433750109	DRIVE SHAFT FRT LH GWB	TATA spare parts
257433750111	AXLE SHAFT COMPL RT INNER	TATA spare parts
257433750112	AXLE SHAFT LH INNER	TATA spare parts
257433753701	HOUSING FRT AXLE JOINT RH	TATA spare parts
257433753702	HOUSING FRT AXLE JOINT LH	TATA spare parts
257433754301	SNAP RING	TATA spare parts
257433757901	AXLE DRIVE SHAFT OUT	TATA spare parts
257433758002	SET SCREW	TATA spare parts



25743380002	REP KIT BALL END	TATA spare parts
257433800101	BALL SOCKET JOINT RH	TATA spare parts
257433800102	ASSY BALL JOINT LH	TATA spare parts
257433800104	TIE ROD ASSY	TATA spare parts
257433800105	TIE ROD ASSY	TATA spare parts
257433800106	ASSY.TIE ROD	TATA spare parts
257433846001	STRG ARM 1210 SEA	TATA spare parts
257433856001	STEERING ARM	TATA spare parts
257433856002	STEERING ARM	TATA spare parts
257433856101	LOCKING PLATE LEFT	TATA spare parts
257433856102	LOCKING PLATE RIGHT	TATA spare parts
257435000109	REAR AXLE RA108 W/BR	TATA spare parts
257435000111	ASSY RA 108 COMP FOR LP	TATA spare parts
257435000112	REAR AXLE ASSY W/HUBS	TATA spare parts
257435000113	ASSY R/A 1210 SALISBURY	TATA spare parts
257435000114	ASSY REAR AXLE COMPLETE	TATA spare parts
257435000116	REAR AXLE ASSY BUS SPG	TATA spare parts
257435000118	REAR AXLE ASSY TRUCK SPG	TATA spare parts
257435000139	REAR AXLE ASSY SPIG	TATA spare parts
257435000146	REAR AXLE 108 SCAM 48/7	TATA spare parts
257435000149	REAR AXLE COMP SALISBERY	TATA spare parts
257435000151	REAR AXLE 108 SCAM 47/8	TATA spare parts
257435000152	REAR AXLE 108 41/7 SCAM	TATA spare parts
257435050127	REAR AXLE COMP W/BRAKES	TATA spare parts
257435050128	ASSY.R.A.RA-106-II SINGLE TYRE-WITH D/LO	TATA spare parts
257435050130	REAR AXLE ASSY 1210 SD	TATA spare parts
257435100105	RR AXLE BEAM SE SALISBURY	TATA spare parts
257435100112	RR AXLE BEAM SE SALISBURY	TATA spare parts
257435100113	REAR AXLE BEAM SALISBURY	TATA spare parts
257435100115	ASSY.REAR AXLE BEAM MACHINED	TATA spare parts
257435100122	RR AXLE BEAM 108RR SALISB	TATA spare parts
257435100123	RR AXLE BEAM SCAM BANJO	TATA spare parts
257435100125	RR AXLE BEAM SCAM BANJO	TATA spare parts
257435100131	RR AXLE HSG W/SUPP SALISB	TATA spare parts
257435100132	RR AXLE HSG W/SUPP SALISB	TATA spare parts
257435105102	BRACKET (S-CAM BRG.BLOCK MTG)	TATA spare parts
257435150104	REAR AXLE HSG W/SUP TUBE	TATA spare parts
257435150105	REAR AXLE HSG W/SUP TUBE	TATA spare parts
257435150106	BREATHER	TATA spare parts
257435150112	ASY.R/A BEAM WITH PR.RINGS STUDS	TATA spare parts
257435150130	ASSY R.A W/PRESSURE RING + STUD & DOWELS	TATA spare parts
257435154213	U CLAMP 17D X 425 LONG	TATA spare parts
257435154217	U CLAMP	TATA spare parts
257435154221	U CLAMP RA- 107	TATA spare parts
257435154701	PROTECTIVE COVER	TATA spare parts
257435157904	REAR AXLE SHAFT RH SD D/L	TATA spare parts
257435159901	ADAPTER BREATHER	TATA spare parts

257435300102	ASSY. DIFFERENTIAL HOUSING BS2/3/4/6	TATA spare parts
257435300112	KIT DIFFL GEAR 1210 REVA	TATA spare parts
257435300115	CWP SET 41/6 OREL 1613/2213NEW	TATA spare parts
257435303103	TAPER ROLLER BEARING OUTER	TATA spare parts
257435303104	TAPER ROLLER BEARING OUTER	TATA spare parts
257435303105	BEARING TAPER ROLLER	TATA spare parts
257435303107	BEARING TAPER ROLLER	TATA spare parts
257435303108	TAPER ROLLER BEARING OUTER	TATA spare parts
257435305101	HOUSING DIFFERENTIAL	TATA spare parts
257435305102	DIFFERENTIAL COVER	TATA spare parts
257435305401	GEAR REAR AXLE SHAFT	TATA spare parts
257435305402	DIFFL BEVEL PINION	TATA spare parts
257435305406	DIFFERENTIAL BEVEL PINION	TATA spare parts
257435305407	GEAR RR AXLE SHAFT REVA	TATA spare parts
257435305408	DIFFL BEVEL PINION REVA	TATA spare parts
257435305413	PINION - CWP:41/6-0115OR	TATA spare parts
257435308301	SHIM- 1.0 THICK	TATA spare parts
257435309201	SPHERICAL WASHER	TATA spare parts
257435309201AE	SPHERICAL WASHER 713 715	TATA spare parts
257435600101	HUB REAR W/BRG N SPIG	TATA spare parts
257435600102	HUB REAR W/O BRG SPIG	TATA spare parts
257435600103	HUB REAR W/BRG SPIG	TATA spare parts
257435600104	HUB REAR	TATA spare parts
257435600108	HUB REAR W/BRG	TATA spare parts
257435600109	HUB REAR W/O BRG SPG	TATA spare parts
257435600110	HUB REAR W/O BRG SPG	TATA spare parts
257435600114	HUB REAR SPIGOTTED	TATA spare parts
257435603101	BEARING 1210 HUB INNER	TATA spare parts
257435603102	TAPER ROLLER BRG	TATA spare parts
257435603103	TAPER ROLLER BEARING OUTER	TATA spare parts
257435608601	SPACER OIL SEAL	TATA spare parts
257435650101	HUB RR SINGLE TYRE RA107	TATA spare parts
257435650102	ASSY HUB WITH BEARING	TATA spare parts
257435650103	ASSY HUB REAR	TATA spare parts
257435707901	REAR AXLE SHAFT	TATA spare parts
257435707904	REAR AXLE SHAFT	TATA spare parts
257435707905	REAR AXLE SHAFT	TATA spare parts
257435757901	REAR AXLE SHAFT CR50395	TATA spare parts
257435757903	REAR AXLE SHAFT	TATA spare parts
257435757904	REAR AXLE SHAFT W/DIFF. LOCK	TATA spare parts
257440050101	WHEEL RIM B8.00X20HD	TATA spare parts
257440050102	WHEEL RIM B8.00X20HD	TATA spare parts
257440100119	TUBE(FOR 12X20 TYRE)	TATA spare parts
257440100121	WHEEL DISC & RIM 7.00X20	TATA spare parts
257440100122	WHEEL NUT SPIG M20X2.5	TATA spare parts
257440100130	ASSY TYRE WITH TUBE 12X20-18PR CROSS COU	TATA spare parts
257440100132	WHEEL DISC & RIM B7HDX20	TATA spare parts

257440100140	ASSY. WHEEL RIM 7.0X20	TATA spare parts
257440103201	WHEEL MTG PIN M20X2.5X106	TATA spare parts
257440106302	FLAP(FOR 12X20 TYRE)	TATA spare parts
257440106304	TYRE 12X20X18PR CROSS COUNTRY	TATA spare parts
257440106705	WHEEL MTG PIN FRSPG 20X74	TATA spare parts
257440109905	TUBE 10.00X20 WITH 86 SINGLEBEND-ZA-I	TATA spare parts
257440109908	TUBE 9X20 BUTYL RUBBER	TATA spare parts
257440109909	TYRE,RIB TYPE 9.00X20 14PR	TATA spare parts
257440206702	WHEEL MTG PIN RRSPG 20X86	TATA spare parts
257440256701	WHEEL MOUNTING PIN RR	TATA spare parts
257440300103	HANDLE SPARE WH CARRIER	TATA spare parts
257440300128	SPARE WHEEL CARRIER ASSY	TATA spare parts
257441100101	PROP SHAFT FRONT W/C BRG	TATA spare parts
257441100103	P/SHAFT FR W/C B 70X1185	TATA spare parts
257441100104	PROP SHAFT FRONT 70X585	TATA spare parts
257441100112	P/SHAFT FR W/C B 76X494	TATA spare parts
257441100113	PROP SHAFT FRT 76X4X1156	TATA spare parts
257441100114	PROPELLER SHAFT FRT	TATA spare parts
257441100122	PROP SHAFT FR W/C BRG	TATA spare parts
257441100132	PROP SHAFT W/CEN BRG	TATA spare parts
257441100135	PROP SHAFT W/CEN BRG	TATA spare parts
257441109901	GREASE NIPPLE	TATA spare parts
257441109902	GREASE NIPPLE	TATA spare parts
257441109902AE	GREASE NIPPLE 715	TATA spare parts
257441110101	PROP SHAFT FRT 70X3X585	TATA spare parts
257441110102	PROP SHAFT FRONT 70X535	TATA spare parts
257441110104	PROPELLER SHAFT W/CB	TATA spare parts
257441110105	PROP SHAFT FRT 70X1185 LG	TATA spare parts
257441110107	PROP. SHAFT FRONT	TATA spare parts
257441110108	PROP SHAFT FR 70X1247	TATA spare parts
257441110114	P/SHAFT FR W/C B 90X1338	TATA spare parts
257441110122	P/SHAFT FR W/CB 90X3X1517	TATA spare parts
257441110128	P/SHAFT FR W/CB 90X3X1085	TATA spare parts
257441110131	P/SHAFT FR W/CB 90X3X414	TATA spare parts
257441110137	PROP SHAFT FR 76X465 SK36	TATA spare parts
257441110143	P/SHAFT MID WCB 90X3X1314	TATA spare parts
257441120102	PROP SHAFT RR 90X3X1060	TATA spare parts
257441120103	PROP SHAFT RR 90X3X1119	TATA spare parts
257441120104	PROP SHAFT RR 90X3X718	TATA spare parts
257441120113	PROP SHAFT RR 90X3X1134	TATA spare parts
257441120146	PROP SHAFT RR 90X3X1127	TATA spare parts
257441120152	PROP SHAFT RR 90X3X1189	TATA spare parts
257441120155	PROP SHAFT RR 90X3X1128	TATA spare parts
257441120158	PROP SHAFT RR 90X3X788	TATA spare parts
257441120161	PROP SHAFT RR 90X3X1269	TATA spare parts
257441120164	PROP SHAFT RR 90X3X1154	TATA spare parts
257441120167	PPOP SHAFT RR 90X3X1124	TATA spare parts

257441120182	PROP SHAFT RR 76X4X1335	TATA spare parts
257441150103	PROP SHAFT FR 70X3X789	TATA spare parts
257441150104	PROP SHAFT FR 70X3X1022	TATA spare parts
257441150172	P/SHAFT GB - AGB 90X3X634	TATA spare parts
257441150177	P/SHAFT AGB - FA 90X3X560	TATA spare parts
257441150183	P/SHAFT AGB - RA 90X3X812	TATA spare parts
257441150185	ASSY PROP. SHAFT COMP.	TATA spare parts
257441300101	BRACKET PROP SHAFT	TATA spare parts
257441300102	BKT CEN BRG PROP SHAFT	TATA spare parts
257441303101	BALL BEARING 6208	TATA spare parts
257441303102	BALL BRG	TATA spare parts
257441303103	BEARING BALL DEEP GROOVE	TATA spare parts
257441303104	BALL BEARING 6211 BS1/2/3/4	TATA spare parts
257441303105	S R D G BALL BRG	TATA spare parts
257441303110	S R D G BALL BEARING	TATA spare parts
257441303114	BEARING BALL	TATA spare parts
257441303306	BRACKET-FOR CENTRE BEARING	TATA spare parts
257441303307	BKT CENTRE BEARING	TATA spare parts
257441303308	BRACKET(CENTER BRG)1612	TATA spare parts
257442050101	FRT AXLE BRAKE LH	TATA spare parts
257442050102	FRT AXLE BRAKE RH	TATA spare parts
257442130125	BRAKE LINING KIT FRT R/SI	TATA spare parts
257442150108	BR SHOE W/LIN	TATA spare parts
257442150113	WHEEL CYL.44.45D FRT	TATA spare parts
257442150115	ASSY.BRAKE SHOE W.LINING SA	TATA spare parts
257442150115AE	FRT BRAKE SHOE WITH LNG STD -713	TATA spare parts
257442150118	BR SHOE W/LIN	TATA spare parts
257442153702	BRAKE DRUM FRT	TATA spare parts
257442153703	BRAKE DRUM FA104	TATA spare parts
257442158701	RETURN SPRING LONG	TATA spare parts
257442300109	ASSY. REAR AXLE BRAKE RH	TATA spare parts
257442300110	ASSY. REAR AXLE BRAKE LH	TATA spare parts
257442350112	WHEEL CYL.44.45D	TATA spare parts
257442410101	SPRING BRAKE CHAMBER	TATA spare parts
257442410102	COVER FRONT	TATA spare parts
257442410104	PUSH ROD	TATA spare parts
257442410105	REP KIT SPG BR CHAMBER	TATA spare parts
257442410107	SPRING BRAKE CHAMBER	TATA spare parts
257442410108	SPRING BRAKE CHAMBER	TATA spare parts
257442415301	GASKET	TATA spare parts
257442416601	PUSH ROD	TATA spare parts
257442420101	HAND BRAKE VALVE FLICK	TATA spare parts
257442420102	HAND BRAKE VALVE FLICK	TATA spare parts
257442420104	REP KIT HAND BR VALVE	TATA spare parts
257442420105	HAND BRAKE VALVE FLICK	TATA spare parts
257442420114	HAND BRAKE VALVE FLICK	TATA spare parts
257442420115	HAND BRAKE VALVE FLICK	TATA spare parts

257442420116	HAND BRAKE VALVE FLICK	TATA spare parts
257442420117	HAND BRAKE VALVE FLICK	TATA spare parts
257442420124	REPAIR KIT FLICK VALVE	TATA spare parts
257442420125	FLICK VALVE	TATA spare parts
257442420127	ASSY.FLICK VALVE	TATA spare parts
257442420128	ASSY.FLICK VALVE	TATA spare parts
257442420129	FLICK VALVE	TATA spare parts
257442420131	FLICK VALVE	TATA spare parts
257442420132	HAND BR VALVE FLICK	TATA spare parts
257442420133	HAND BRAKE VALVE FLICK	TATA spare parts
257442420135	HAND BRAKE VALVE FLICK	TATA spare parts
257442420136	HAND BRAKE VALVE FLICK	TATA spare parts
257442420137	REP KIT HAND BR VALVE	TATA spare parts
257442420139	KIT FLICK VALVE	TATA spare parts
257442426301	GAITER	TATA spare parts
257442426302	KNOB	TATA spare parts
257442426601	PLUNGER	TATA spare parts
257442426701	PIVOT PIN	TATA spare parts
257442426702	TENSION PIN	TATA spare parts
257442427701	O RING	TATA spare parts
257442428001	SLOTTED SCREW	TATA spare parts
257442428401	SLEEVE	TATA spare parts
257442428702	SPRING	TATA spare parts
257442429201	WASHER	TATA spare parts
257442429901	VALVE GUIDE	TATA spare parts
257442429902	VALVE	TATA spare parts
257442429904	DIAL	TATA spare parts
257442429905	WIREMESH FILTER	TATA spare parts
257442429914	WIRE MESH FILTER P265/81	TATA spare parts
257442438208	BRACKET (CONTROL VALVE) BS6	TATA spare parts
257442700138	INTERMEDIATE SHAFT RHD	TATA spare parts
257442700145	ROD ASSY	TATA spare parts
257442700147	SUPPORT INTERM SHAFT	TATA spare parts
257442700151	BRACKET CHAMBER MTG	TATA spare parts
257442706014	PULL ROD	TATA spare parts
257442800110	BRAKE TUBE	TATA spare parts
257442800111	BRAKE TUBE	TATA spare parts
257442800112	BRAKE TUBE	TATA spare parts
257442800113	BRAKE TUBE	TATA spare parts
257442800125	BRAKE TUBE	TATA spare parts
257442800127	BRAKE TUBE	TATA spare parts
257442800129	BRAKE TUBE	TATA spare parts
257442800133	BRAKE TUBE	TATA spare parts
257442800144	CONNECTING LINE	TATA spare parts
257442800146	BR FLUID RESERVOIR ON TMC	TATA spare parts
257442800157	BRAKE TUBE M/C	TATA spare parts
257442800167	TUBE ASSY	TATA spare parts

257442805801	RUBBER HOSE	TATA spare parts
257442810109	CONNECTING LINE	TATA spare parts
257442810113	HYD LINE FRONT	TATA spare parts
257442810114	HYD LINE RH SIDE	TATA spare parts
257442810115	HYD LINE LH SIDE	TATA spare parts
257442810116	TUBE ASSY	TATA spare parts
257442810117	TUBE ASSY	TATA spare parts
257442810118	ASSY TUBE	TATA spare parts
257442810119	HYD PIPE	TATA spare parts
257442810120	HYD PIPE	TATA spare parts
257442810121	HYD PIPE	TATA spare parts
257442850103	BRAKE TUBE FRT RH	TATA spare parts
257442850113	BRAKE TUBE	TATA spare parts
257442850124	BRAKE TUBE FRT RH	TATA spare parts
257442853302	BRACKET BRAKE HOSE	TATA spare parts
257442900101	ASY AIR PRESSURE PIPE	TATA spare parts
257442903302	BRACKET	TATA spare parts
257442906808	TEE CONNECTOR	TATA spare parts
257442906809	SOCKET	TATA spare parts
257442906901	PIPE AIR 18 X 1.5 X 2215	TATA spare parts
257442906902	PIPE AIR 18 X 1.5 X 2080	TATA spare parts
257442906911	PIPE AIR 18 X 1.5	TATA spare parts
257442906917	PIPE AIR 15 X 1.5	TATA spare parts
257442906922	PIPE AIR 15 X 1.5	TATA spare parts
257442906936	PIPE AIR 6 X 0.7	TATA spare parts
257442906953	PIPE AIR 15 X 1.5	TATA spare parts
257442906966	PIPE AIR 15 X 1.5	TATA spare parts
257442906971	PIPE AIR 6 X 0.7	TATA spare parts
257442907701	GROMMET	TATA spare parts
257442908203	BRACKET	TATA spare parts
257442908207	BRACKET	TATA spare parts
257442908602	SPACER	TATA spare parts
257442910139	PIPE AIR	TATA spare parts
257442910140	PIPE AIR	TATA spare parts
257442910157	PIPE AIR	TATA spare parts
257442910161	BRAKE HOSE	TATA spare parts
257442910162	BRAKE HOSE	TATA spare parts
257442910163	BRAKE HOSE	TATA spare parts
257442910164	BRAKE HOSE	TATA spare parts
257442910165	HOSE ASSY	TATA spare parts
257442910166	PIPE AIR	TATA spare parts
257442910173	PIPE AIR	TATA spare parts
257442910182	BRAKE TUBE	TATA spare parts
257442910198	TUBE 15D X 1800 LG	TATA spare parts
257442914201	BRACKET	TATA spare parts
257442916940	PIPE AIR 18 X 1.5	TATA spare parts
257442920141	HOSE ASSY	TATA spare parts

257442920142	HOSE BRAKE	TATA spare parts
257442920182	PIPE AIR 15D	TATA spare parts
257442920183	PIPE AIR 12D	TATA spare parts
257442920184	PIPE AIR 6D	TATA spare parts
257442920187	PIPE AIR 6D	TATA spare parts
257442920188	PIPE AIR 12D	TATA spare parts
257442920190	PIPE AIR 12D	TATA spare parts
257442920191	ASSY AIR PIPE 12OD	TATA spare parts
257442920192	ASSY AIR PIPE 120D	TATA spare parts
257442920193	ASSY AIR PIPE 120 D	TATA spare parts
257442920195	PIPE AIR 6D	TATA spare parts
257442920196	PIPE AIR 6D	TATA spare parts
257442920199	PIPE AIR 6D	TATA spare parts
257442930101	PIPE AIR 6D	TATA spare parts
257442930103	PIPE AIR 6D	TATA spare parts
257442930104	ASSY AIR PIPE 60 DIA	TATA spare parts
257442930106	PIPE AIR	TATA spare parts
257442930107	PIPE AIR	TATA spare parts
257442930108	PIPE AIR	TATA spare parts
257442930109	ASSY AIR PR PIPE	TATA spare parts
257442930110	PIPE AIR	TATA spare parts
257442930111	PIPE AIR	TATA spare parts
257442930112	PIPE AIR	TATA spare parts
257442930115	PIPE SENS TANK 2 SPV	TATA spare parts
257442930116	PIPE AIR	TATA spare parts
257442930118	PIPE AIR	TATA spare parts
257442930119	PIPE AIR	TATA spare parts
257442930120	PIPE AIR	TATA spare parts
257442930128	PIPE AIR	TATA spare parts
257442930132	TUBE ASSY	TATA spare parts
257442930133	PIPE AIR	TATA spare parts
257442930136	TUBE ASSY	TATA spare parts
257442930138	ASSY TUBE 12 OD	TATA spare parts
257442930141	ASSY. TUBE	TATA spare parts
257442930142	ASSY TUBE	TATA spare parts
257442930143	ASSY TUBE	TATA spare parts
257442930144	TUBE ASSY	TATA spare parts
257442930145	ASSY TUBE 1210	TATA spare parts
257442930151	ASSY TUBE	TATA spare parts
257442930158	ASSY TUBE	TATA spare parts
257442930160	ASSY TUBE	TATA spare parts
257442930162	ASSY. TUBE	TATA spare parts
257442930163	ASSY TUBE	TATA spare parts
257442930164	TUBE ASSY	TATA spare parts
257442930169	TUBE TEE/FR LH BR CHAMBER	TATA spare parts
257442940121	AIR PIPE(FR/TANK-D/V)1612	TATA spare parts
257442940122	PIPE AIR RR/TANK-D/V 161	TATA spare parts

257442950104	BRACKET	TATA spare parts
257442950140	AIR PRESSURE PIPE LP1510/42	TATA spare parts
257442955101	ELBOW	TATA spare parts
257442956917	PIPE AIR 15 X 1.5	TATA spare parts
257443100108	BRAKE FLUID CONTAINER	TATA spare parts
257443200108	AIR TANK	TATA spare parts
257443200109	BRACKET RH	TATA spare parts
257443200110	BRACKET LH	TATA spare parts
257443200116	ASSY.BRACKET LH.	TATA spare parts
257443200117	ASSY.BRACKET RH.	TATA spare parts
257443400101	PIPE AIR	TATA spare parts
257443500102	SEALING RING	TATA spare parts
257443509201	SEALING RING	TATA spare parts
257443700002	KIT REP ISOLATOR VALVE	TATA spare parts
257443700101	LEV TYPE CONTROL VALVE	TATA spare parts
257443760113	UNLOADER VALVE 1210E	TATA spare parts
257443790124	NON RETURN VALVE	TATA spare parts
257443790125	DOUBLE CHECK VALVE	TATA spare parts
257443790150	WATER DRAIN VALVE	TATA spare parts
257443790151	WATER DRAIN VALVE	TATA spare parts
257443790152	PALM COUP TRAILER CONTROL LINE LPS3015	TATA spare parts
257443790153	PALM COUP TRAILER SUPPLY LINE LPS3015	TATA spare parts
257446000006	KIT REP DRAG LINK END	TATA spare parts
257446000010	KIT REP DRAG LINK END	TATA spare parts
257446000014	STG KIT	TATA spare parts
257446000103	STEERING W/UNIVER JOINT	TATA spare parts
257446000104	BRACKET STEERING	TATA spare parts
257446000105	DRAG LINK ASSY	TATA spare parts
257446000116	ASSY DRAG LINK	TATA spare parts
257446000124	ASSY DRAG LINK	TATA spare parts
257446000129	BKT STRG G/BOX	TATA spare parts
257446000132	DRAG LINK ASSY RHD	TATA spare parts
257446000134	DRAG LINK ASSY RHD	TATA spare parts
257446000137	ASSY DRAG LINK	TATA spare parts
257446000138	DRAG LINK ASSY	TATA spare parts
257446000139	DRAG LINK ASSY RHD SE1210	TATA spare parts
257446000140	BALL & NUT TYPE POWER STG.GEAR SE RHD	TATA spare parts
257446006502	CASTLE NUT	TATA spare parts
257446019901	DRAG LINK ASSY LHD SFC	TATA spare parts
257446050104	DRAG LINK ASSY	TATA spare parts
257446050107	ASSY DRAG LINK LIVE AXLE	TATA spare parts
257446056001	DRAG LINK ASSY RHD	TATA spare parts
257446056701	HEX SCREW	TATA spare parts
257446100102	SUPPORT STRG COLUMN	TATA spare parts
257446100103	SUPPORT STRG COLUMN	TATA spare parts
257446100110	BRACKET STEERING	TATA spare parts
257446100113	SUPPORT STRG COLUMN	TATA spare parts



257446100114	ASSY STRG CLMN SUPT C	TATA spare parts
257446100116	ASSY STG COL SUPPORT	TATA spare parts
257446107902	STRG SPINDLE BOTTOM	TATA spare parts
257446108001	PIN MOUNTING	TATA spare parts
257446110101	BRACKET STEERING	TATA spare parts
257446200101	STRG GEAR BOX RHD	TATA spare parts
257446200102	STEERING HOUSING	TATA spare parts
257446200103	STEERING NUT & WORM	TATA spare parts
257446200104	STEERING SHAFT	TATA spare parts
257446200105	STEERING SHAFT	TATA spare parts
257446200106	HOUSING COVER	TATA spare parts
257446200114	KIT REP STRG GR BOX MNR	TATA spare parts
257446200115	STRG GEAR BOX RHD	TATA spare parts
257446200117	STRG NUT & WORM W/O BRG	TATA spare parts
257446203701	STEERING HOUSING	TATA spare parts
257446206301	CAM	TATA spare parts
257446207901	STRG SPINDLE TOP	TATA spare parts
257446207902	STEERING WORM(SPINDLE) BOTTOM	TATA spare parts
257446207904	STRG SPINDLE BOTTOM	TATA spare parts
257446207907	STEERING SPINDLE - BOTTOM	TATA spare parts
257446207913	STRG. SPINDLE BOTTOM	TATA spare parts
257446207914	STRG SPINDLE TOP	TATA spare parts
257446209902	BALL SOCKET	TATA spare parts
257446210101	STEERING L/LHD-M	TATA spare parts
257446210102	STEERING HOUSING RHD	TATA spare parts
257446210104	HOUSING COVER	TATA spare parts
257446210107	STRG GEAR BOX POWER	TATA spare parts
257446210109	ASSY.POWER STEERING GEAR BOX	TATA spare parts
257446217901	STEERING SPINDLE BOTTOM	TATA spare parts
257446217903	STRG SPINDLE BOTTOM	TATA spare parts
257446217907	SPINDLE-BOTTOM	TATA spare parts
257446306001	PITMAN ARM RHD	TATA spare parts
257446306002	PITMAN ARM	TATA spare parts
257446316002	PITMAN ARM SFC	TATA spare parts
257446316004	PITMAN ARM	TATA spare parts
257446356001	PITMAN ARM RHD	TATA spare parts
257446356002	PITMAN ARM LHD	TATA spare parts
257446356003	PITMAN ARM CR50536	TATA spare parts
257446356004	PITMAN ARM SA 1210 M LHD P/STG.	TATA spare parts
257446356006	SA 1210 RHD PITMAN ARM MECHANICAL	TATA spare parts
257446600101	POWER STG.ASSY.	TATA spare parts
257446800104	ASSY. HP HOSE 3/8INCH W/WIRE GUARD BS2/3	TATA spare parts
257446800104AE	3/8IN HP HOSE W/WIRE GUARD -1415	TATA spare parts
257446805802	HOSE 3/4 LP	TATA spare parts
257447010101	OVER FLOW RETURN LINE	TATA spare parts
257447010103	FUEL TANK	TATA spare parts
257447100103	ASSY FUEL FANK WELDED 200 LTR.	TATA spare parts

257447150137	FUEL TANK 200 LTR	TATA spare parts
257447507702	RUBBER STRAP FUEL TANK	TATA spare parts
257447507704	RUBBER STRAP FUEL TANK	TATA spare parts
257447600101	FUEL LINE	TATA spare parts
257447600103	FUEL LINE	TATA spare parts
257447600124	OVER FLOW RETURN LINE	TATA spare parts
257447600137	FUEL LINE 1210SE	TATA spare parts
257447600163	FUEL SUCTION LINE	TATA spare parts
257447600196	FUEL LINE	TATA spare parts
257447608202	CLIP	TATA spare parts
257447608210	SUPPORT	TATA spare parts
257447650105	SUCTION TUBE 10X0.7X1815	TATA spare parts
257447650106	RETURN LINE10 X 0.7 X1640	TATA spare parts
257447650122	SUCTION TUBE	TATA spare parts
257447650123	SUCTION TUBE	TATA spare parts
257447650125	BRACKET ASSY	TATA spare parts
257449000104	BRACKET ASSY	TATA spare parts
257449000108	BRACKET ASSY	TATA spare parts
257449000109	BRACKET ASSY	TATA spare parts
257449008204	CLAMP	TATA spare parts
257449100101	SILENCER MUFFLER	TATA spare parts
257449100102	SILENCER ASSY SFC	TATA spare parts
257449100108	SILENCER MUFFLER	TATA spare parts
257449100110	SILENCER	TATA spare parts
257449100119	SILENCER	TATA spare parts
257449104201	CLAMP EXHAUST PIPE	TATA spare parts
257449104202	CLAMP EXHAUST PIPE 65.50	TATA spare parts
257449106903	EXHAUST PIPE INTRMEDIATE	TATA spare parts
257449106904	EXHAUST PIPE RR	TATA spare parts
257449106906	EXHAUST PIPE RR	TATA spare parts
257449150110	SILENCER ASSY	TATA spare parts
257449158202	SUPPORT	TATA spare parts
257449200101	EXHAUST PIPE FRONT	TATA spare parts
257449200103	EXHAUST PIPE INTERMEDIATE	TATA spare parts
257449200105	EXHAUST PIPE INTERMEDIATE	TATA spare parts
257449200108	EXHAUST PIPE FRONT	TATA spare parts
257449200109	ASSY EXHAUST PIPE INTERMEDIATE	TATA spare parts
257449200110	ASSY SILENCER	TATA spare parts
257449200122	ASSY BRACKET-HANGER BRACKET	TATA spare parts
257449200132	EXHAUST PIPE INTERMEDIATE	TATA spare parts
257449206902	EXHAUST PIPE INTERM FRT	TATA spare parts
257449206903	EXHAUST PIPE INTERM FRT	TATA spare parts
257449206909	EXHAUST PIPE INTERMEDIATE	TATA spare parts
257449206910	EXHAUST PIPE INTERM FRT	TATA spare parts
257449206922	EXHAUST PIPE REAR	TATA spare parts
257449206929	EXHAUST PIPE REAR	TATA spare parts
257449206942	EXHAUST PIPE REAR	TATA spare parts

257449210101	EXHAUST PIPE FRONT	TATA spare parts
257449210102	ASSY.EXHAUST PIPE FRT.	TATA spare parts
257449210103	EXHAUST PIPE INTERMEDIATE	TATA spare parts
257449216901	EXHAUST PIPE	TATA spare parts
257449250104	EXHAUST PIPE FR CR50100	TATA spare parts
257450000104	ASSY.FRAME RADIATOR	TATA spare parts
257450000106	BRACKET LH RADIATOR MTG	TATA spare parts
257450000118	RADIATOR FRAME	TATA spare parts
257450000119	WASHER	TATA spare parts
257450005801	RADIATOR HOSE SFC	TATA spare parts
257450005805	RADIATOR HOSE	TATA spare parts
257450005806	BELLOW THERMOSTAT	TATA spare parts
257450005807	RUBBER HOSE	TATA spare parts
257450005808	RUBBER HOSE RAD TO W/PUMP	TATA spare parts
257450006301	RUBBER BUFFER BS4	TATA spare parts
257450006904	SPACER TUBE	TATA spare parts
257450006905	SPACER TUBE 120MM	TATA spare parts
257450006906	SPACER TUBE 25.5MM	TATA spare parts
257450006907	SPACER TUBE (125 LONG)	TATA spare parts
257450006910	SPACER TUBE	TATA spare parts
257450009201	WASHER	TATA spare parts
257450009202	WASHER	TATA spare parts
257450009902	TIE ROD RADIATOR 220MM	TATA spare parts
257450009904	TIE ROD RADIATOR 1510	TATA spare parts
257450100106	RADIATOR ASSY	TATA spare parts
257450105801	RADIATOR HOSE	TATA spare parts
257454010126	CABLE SET FRT TO TAIL	TATA spare parts
257454010128	CABLE SET SE/48 RHD	TATA spare parts
257454100101	BATTERY CABLE +VE	TATA spare parts
257454100102	BATTERY CABLE -VE	TATA spare parts
257454100107	PIPE OIL PRESSURE GAUGE	TATA spare parts
257454100108	MAIN CABLE SET	TATA spare parts
257454100109	CABLE SET INSTR PANEL	TATA spare parts
257454100117	ASSY.MAIN CABLE SET/SFC/	TATA spare parts
257454100169	BATTERY CABLE	TATA spare parts
257454100176	ASSY.BATT.CABLE +VE 50 RED 1121 LG	TATA spare parts
257454103301	STUD	TATA spare parts
257454107503	RUBBER CAP	TATA spare parts
257454107504	RUBBER GROMMET	TATA spare parts
257454108202	CLAMP	TATA spare parts
257454108205	DOUBLE CLAMP	TATA spare parts
257454110103	BATTERY CABLE +VE	TATA spare parts
257454110104	BATTERY CABLE -VE	TATA spare parts
257454110146	BATTERY CABLE -VE	TATA spare parts
257454110149	BATTERY CABLE -VE	TATA spare parts
257454110153	CABLE PVC 1C 50 BLACK 1347 LG	TATA spare parts
257454110156	ASSY BATT.CABLE -VE (50 SQ.MM.-1046 LG)	TATA spare parts

257454116902	PIPE AIR	TATA spare parts
257454200101	SPEEDOCABLE	TATA spare parts
257454200106	PIPE ASSY	TATA spare parts
257454200108	ASSY PIPE 1495 LG	TATA spare parts
257454200111	REP KIT DIPHGRAM	TATA spare parts
257454200112	TANK UNIT ASSY	TATA spare parts
257454202002	HORN 12V	TATA spare parts
257454202003	HORN 12V	TATA spare parts
257454202006	HORN (12V) W/RIS CAPACITOR	TATA spare parts
257454202007	HORN 12V W/O CAPACITOR	TATA spare parts
257454204602	ELECTRONIC FLASHER KIT	TATA spare parts
257454204902	HORN TIMER	TATA spare parts
257454204903	HORN TIMER 12V	TATA spare parts
257454206901	PIPE AIR 6 X 0.7 X 1490	TATA spare parts
257454207502	SEAL RING	TATA spare parts
257454207604	BRACKET FOR CLAMPING OF AIR LINES BS6	TATA spare parts
257454208002	SCREW	TATA spare parts
257454208205	CLAMP [SPEEDOCABLE G.BOX END]	TATA spare parts
257454209901	SPEEDOCABLE	TATA spare parts
257454209902	SPEEDOCABLE	TATA spare parts
257454209905	SPEEDOCABLE 2200MM	TATA spare parts
257454209906	SPEEDOCABLE 3600MM 3.2D	TATA spare parts
257454209914	WATER TEMP GAUGE ELEC	TATA spare parts
257454209915	TEMPERATURE TRANSDUCER	TATA spare parts
257454209916	GAUGE OIL PRESSURE	TATA spare parts
257454209917	AMMETER	TATA spare parts
257454209918	GAUGE FUEL	TATA spare parts
257454209919	GAUGE AIR PRESSURE	TATA spare parts
257454209920	SPEEDOMETER 1:1.125	TATA spare parts
257454209921	SPEEDOMETER 1:1	TATA spare parts
257454209935	SPEEDOMETER-1:1.125	TATA spare parts
257454209939	SPEEDOCABLE 3.2D	TATA spare parts
257454209940	SPEEDOMETER 1:1.08	TATA spare parts
257454209941	SPEEDOMETER 1:1.08	TATA spare parts
257454209945	SPEEDOCABLE (JIS) 3200 LG.	TATA spare parts
257454209947	SPEEDOCABLE 2200MM JIS	TATA spare parts
257454209948	SPEEDOCABLE 3600MM 3.2D	TATA spare parts
257454209949	SPEEDOCABLE 4300MM DIN	TATA spare parts
257454209950	SPEEDOCABLE 2200MM JIS	TATA spare parts
257454209951	SPEEDOCABLE 3600MM 3.2D	TATA spare parts
257454209952	SPEEDOCABLE 4300MM DIN	TATA spare parts
257454209964	GAUGE OIL PRESSURE	TATA spare parts
257454209965	GAUGE OIL PRESSURE	TATA spare parts
257454209966	GAUGE AIR PRESSURE MECH	TATA spare parts
257454209967	GAUGE AIR PRESSURE MECH	TATA spare parts
257454209969	HORN 12V	TATA spare parts
257454209970	BUZZER UNIT	TATA spare parts

257454209971	ELECTRIC BUZZER UNIT	TATA spare parts
257454209972	OIL PRESSURE GAUGE	TATA spare parts
257454209979	SPEEDOCABLE 3000MM JIS	TATA spare parts
257454209980	SPEEDO CABLE 3600MM	TATA spare parts
257454209981	SPEEDOCABLE (JIS) 4300 LG.	TATA spare parts
257454209987	HORN 12V W/O RIS CAPACITOR BS1/2/3/4	TATA spare parts
257454209987AE	HORN 12V W/O RIS CAPACITOR	TATA spare parts
257454209994	SPEEDOCABLE JIS 3600LG OFFER	TATA spare parts
257454209995	SPEEDOCABLE (JIS) 4300 LG 4300MM	TATA spare parts
257454209996	SPEEDOCABLE 3600MM JIS	TATA spare parts
257454209997	SPEEDO CABLE -JIS -LG 4300 WITH GROMMET	TATA spare parts
257454209998	SPEEDOCABLE JIS 3000 LG.	TATA spare parts
257454209999	SPEEDOCABLE 3000MM JIS	TATA spare parts
257454219902	SPEEDOMETER 1:1.08) OFFER P.NO.	TATA spare parts
257454219904	SPEEDOMETER 6+1 DIGIT 1 0.95 OFFER	TATA spare parts
257454219906	SPEEDOMETER (6+1 DIGIT)(1:1.0) OFFER	TATA spare parts
257454219907	SPEEDOMETER [1:1.05] OFFER	TATA spare parts
257454219909	SPEEDOMETER[6+1 DIGIT] 1:0.92 -OFFER	TATA spare parts
257454219910	SPEEDOMETER-6+1 DIGIT 1:0.84-OFFER	TATA spare parts
257454219912	SPEEDOMETER-1:0.9	TATA spare parts
257454219933	SPEEDOMETER 1:1.125	TATA spare parts
257454219934	SPEEDOMETER 1:1.125	TATA spare parts
257454219936	SPEEDOMETER 1:1.08 6+1	TATA spare parts
257454219937	SPEEDOMETER 1:1.08 6+1	TATA spare parts
257454219942	SPEEDOMETER 1:0.95 6+1	TATA spare parts
257454219943	SPEEDOMETER 1:0.95 6+1	TATA spare parts
257454219948	SPEEDOMETER 1:1 6+1	TATA spare parts
257454219949	SPEEDOMETER 1:1 6+1	TATA spare parts
257454219951	SPEEDOMETER 1:1.05	TATA spare parts
257454219952	SPEEDOMETER 1:1.05	TATA spare parts
257454219957	SPEEDOMETER 1:0.92 6+1	TATA spare parts
257454219958	SPEEDOMETER (RATIO-1:0.92	TATA spare parts
257454219960	SPEEDOMETER 1:0.84	TATA spare parts
257454219961	SPEEDOMETER RATIO 1:0.84	TATA spare parts
257454219962	SPEEDOMETER (6+1 DIGIT)1:0.84	TATA spare parts
257454219966	SPEEDOMETER 1:0.9 6+1	TATA spare parts
257454219967	SPEEDOMETER 1:0.9 6+1	TATA spare parts
257454219982	SPEEDOCABLE 2200LG.(JIS G.B.END) OFFER	TATA spare parts
257454219983	SPEEDOMETER CABLE	TATA spare parts
257454219984	SPEEDOCABLE JIS 2200 LG.	TATA spare parts
257454219988	AMMETER	TATA spare parts
257454219989	TEMPERATURE TRANSDUCER	TATA spare parts
257454219990	AIR PRESSURE GAUGE	TATA spare parts
257454219991	ELECTRICAL TEMP.GAUGE	TATA spare parts
257454219992	FUEL GAUGE	TATA spare parts
257454219997	SPEEDOMETER 1:1.125	TATA spare parts
257454219999	SPEEDOMETER	TATA spare parts

257454229901	SPEEDOMETER [1:1.125]	TATA spare parts
257454229902	SPEEDOMETER-6+1 DIGIT 1:1.0	TATA spare parts
257454229903	SPEEDOMETER(1:0.95)	TATA spare parts
257454229904	SPEEDOMETER(6+1DIGIT)1:0.92	TATA spare parts
257454229905	SPEEDOMETER 6+1-1:0.9 RATIO	TATA spare parts
257454229906	SPEEDOMETER [1:0.84] [6+1]	TATA spare parts
257454229908	AIR PRESSURE GAUGE	TATA spare parts
257454229909	OIL PRESSURE GAUGE	TATA spare parts
257454229925	SPEEDOMETER (6+1 DIGIT) 1:0.765	TATA spare parts
257454229926	SPEEDOMETER (6+1 DIGIT) 1:0.765	TATA spare parts
257454229927	SPEEDOMETER (6+1 DIGIT) 1:0.765	TATA spare parts
257454229933	SPEEDOMETER (6+1DIGIT)1:0.98	TATA spare parts
257454229934	SPEEDO METER 1:0.98	TATA spare parts
257454229935	SPEEDOMETER 1:0.98	TATA spare parts
257454229939	SPEEDO CABLE 2750 LONG.	TATA spare parts
257454229941	SPEEDOCABLE JIS 3000 LG.	TATA spare parts
257454229942	SPEEDOCABLE (JIS) 3600MM	TATA spare parts
257454229943	SPEEDOCABLE (JIS) 4300 LG.	TATA spare parts
257454229944	SPEEDOCABLE 2200LG. JIS G.B.END	TATA spare parts
257454229957	SPEEDOMETER(6+1 DIGIT) 1:1.04 RATIO	TATA spare parts
257454229958	SPEEDOMETER(6+1 DIGIT)1:0.98	TATA spare parts
257454229959	SPEEDOMETER (6+1 DIGIT) 1:0.765	TATA spare parts
257454249901	WATER TEMP GAUGE 24V ELEC	TATA spare parts
257454249902	GAUGE FUEL 24V	TATA spare parts
257454249903	HORN 24V	TATA spare parts
257454249904	VOLTMETER 24V	TATA spare parts
257454249906	HORN 24V	TATA spare parts
257454249909	GAUGE FUEL 24V	TATA spare parts
257454249910	HORN	TATA spare parts
257454249912	TEMP.GAUGE	TATA spare parts
257454249913	GAUGE FUEL	TATA spare parts
257454249914	VOLTMETER 24V	TATA spare parts
257454400106	RIM SHROUD ASSY	TATA spare parts
257454400109	ASSY TAIL LAMP BRACKET RH	TATA spare parts
257454400110	BRACKET TAIL LAMP LH	TATA spare parts
257454400111	BKT MAP READING LAMP	TATA spare parts
257454400116	HEAD LAMP LH	TATA spare parts
257454400117	HEAD LAMP RH	TATA spare parts
257454400121	BLINKER LAMP RH	TATA spare parts
257454400122	BLINKER LAMP LH	TATA spare parts
257454400134	HEAD LAMP RH RHD	TATA spare parts
257454400138	CAB LAMP ASSY	TATA spare parts
257454400139	INDICATOR LAMP DANDA MAN	TATA spare parts
257454400169	HEAD LAMP RH RHD	TATA spare parts
257454400170	HEAD LAMP LH RHD	TATA spare parts
257454400171	HEAD LAMP RH RHD	TATA spare parts
257454400172	HEAD LAMP LH RHD	TATA spare parts

257454400193	TAIL LAMP LH	TATA spare parts
257454400194	ASSY.TAIL LAMP RH....P-196/87	TATA spare parts
257454400195	TAIL LAMP LH	TATA spare parts
257454400196	TAIL LAMP RH	TATA spare parts
257454408211	DECORATIVE STEEL RIM	TATA spare parts
257454408221	BRACKET	TATA spare parts
257454409001	LENS	TATA spare parts
257454409202	HOUSING TAIL LAMP RH	TATA spare parts
257454409903	TAIL LAMP LH	TATA spare parts
257454409904	TAIL LAMP RH	TATA spare parts
257454409906	TAIL LAMP LH	TATA spare parts
257454409907	TAIL LAMP RH	TATA spare parts
257454409920	TAIL LAMP LENS (RH)	TATA spare parts
257454409921	TAIL LAMP LENS (LH)	TATA spare parts
257454409923	TAIL LAMP RH 3CH	TATA spare parts
257454409924	TAIL LAMP RH	TATA spare parts
257454409925	TAIL LAMP LH	TATA spare parts
257454409926	DOME HEAD LAMP LH	TATA spare parts
257454409927	DOME HEAD LAMP RH	TATA spare parts
257454410111	ASSY H/L PC RIM W/BULB RH	TATA spare parts
257454410113	ASSY HEAD LAMP W/BULB-LH	TATA spare parts
257454410130	ASSY H/L PC RIM W/BULB RH RHD LUCAS	TATA spare parts
257454410138	TAIL LAMP RH	TATA spare parts
257454410139	TAIL LAMP LH	TATA spare parts
257454410142	ASSY 4 CH. TAIL LAMP RH	TATA spare parts
257454410143	ASSY 4 CH. TAIL LAMP LH	TATA spare parts
257454410170	ASSY. TAIL LAMP RH W/BULB BS1/2/3/4	TATA spare parts
257454410172	ASSY. TAIL LAMP LH W/BULB BS1/2/3/4	TATA spare parts
257454410178	TAIL LAMP RH	TATA spare parts
257454410180	TAIL LAMP LH	TATA spare parts
257454420101	TAIL LAMP LH	TATA spare parts
257454420102	TAIL LAMP RH	TATA spare parts
257454420103	TAIL LAMP RH	TATA spare parts
257454420104	TAIL LAMP LH	TATA spare parts
257454420111	TAIL LAMP RH	TATA spare parts
257454420112	TAIL LAMP LH	TATA spare parts
257454420115	INDICATOR LAMP EXH BRAKE	TATA spare parts
257454420116	BRACKET TAIL LAMP RH	TATA spare parts
257454420117	BRACKET TAIL LAMP LH	TATA spare parts
257454420118	ASSY BLINKER LAMP RH WITH BULB	TATA spare parts
257454420119	ASSY BLINKER LAMP LH WITH BULB	TATA spare parts
257454420120	BLINKER LAMP RH	TATA spare parts
257454420121	BLINKER LAMP LH	TATA spare parts
257454420122	BLINKER LAMP RH	TATA spare parts
257454420123	ASSY.BLINKER LAMP LH	TATA spare parts
257454420124	ASSY.TAIL LAMP BKT.LH	TATA spare parts
257454420134	BLINKER LAMP WITH BULB RH SE SK	TATA spare parts

257454420135	BLINKER LAMP WITH BULB LH SE SK	TATA spare parts
257454420138	BLINKER LAMP WITH BULB RH SE SK	TATA spare parts
257454420139	BLINKER LAMP WITH BULB LH SE SK	TATA spare parts
257454440105	TAIL LAMP RH 24V	TATA spare parts
257454440106	TAIL LAMP LH 24V	TATA spare parts
257454440109	TAIL LAMP RH 24V	TATA spare parts
257454440110	TAIL LAMP LH 24V	TATA spare parts
257454500102	HAZARD WARNING SWITCH	TATA spare parts
257454500110	BRACKET TAIL LAMP	TATA spare parts
257454500139	COMBI SWITCH	TATA spare parts
257454500150	BRACKET RH	TATA spare parts
257454500152	FUSE BOX	TATA spare parts
257454500153	ASSY FUSE BOX-12 POLE	TATA spare parts
257454500154	FUSE BOX	TATA spare parts
257454500161	FUSE BOX BLACK OUT	TATA spare parts
257454500163	FUSE BOX	TATA spare parts
257454500165	COVER FUSE BOX W/KNOB	TATA spare parts
257454500172	ASSY TAIL LAMP BKT RH (FOR 32 WB)	TATA spare parts
257454500173	ASSY TAIL LAMP BKT LH (FOR 32 WB)	TATA spare parts
257454500175	FUSE BOX	TATA spare parts
257454500177	ASSY COMBI SW W/IND.TRS & HSG.	TATA spare parts
257454500178	ASSY MAIN LINE SWITCH	TATA spare parts
257454500179	ASSEMBLY TAIL LAMP BRK R.H	TATA spare parts
257454500180	ASSEMBLY TAIL LAMP BRK L.H	TATA spare parts
257454500183	ASSY.REVERSE LIGHT SWITCH	TATA spare parts
257454500184	LOW AIR PRESSURE SWITCH	TATA spare parts
257454500185	COMBI SWITCH	TATA spare parts
257454500186	LOW AIR PRESSURE SWITCH	TATA spare parts
257454500187	COMBI SWITCH HCV	TATA spare parts
257454500188	COMBI SWITCH	TATA spare parts
257454500189	COMBI SWITCH	TATA spare parts
257454500190	ASSY. HAZARD WARNING SWITCH	TATA spare parts
257454500192	LOW AIR PRESSURE SWITCH	TATA spare parts
257454500193	STARTER PUSH BUTTON	TATA spare parts
257454500194	LOW PRESSURE INDICATOR SWITCH	TATA spare parts
257454500199	ASSY.REVERSE LIGHT SWITCH	TATA spare parts
257454500602	REVERSE LIGHT SWITCH	TATA spare parts
257454500901	STOP LIGHT SWITCH	TATA spare parts
257454500902	STOP LIGHT SWITCH	TATA spare parts
257454500903	STOP LIGHT SWITCH	TATA spare parts
257454503501	IGNITION KEYS	TATA spare parts
257454503701	PIANO SWITCH WIPER	TATA spare parts
257454503702	PANEL LAMP SWITCH	TATA spare parts
257454504601	HAZARD WARNING SWITCH	TATA spare parts
257454504602	FLASHER KIT	TATA spare parts
257454504603	FLASHER KIT	TATA spare parts
257454504605	FLASHER KIT 24V	TATA spare parts



257454504607	FLASHER KIT	TATA spare parts
257454504608	FLASHER KIT	TATA spare parts
257454506901	PIANO SWITCH	TATA spare parts
257454506905	PIANO SWITCH	TATA spare parts
257454506906	PIANO SWITCH	TATA spare parts
257454506909	PIANO KEY SWITCH	TATA spare parts
257454506912	PIANO KEY SWITCH	TATA spare parts
257454506913	PIANO KEY SWITCH	TATA spare parts
257454506918	PIANO KEY SWITCH WIPER	TATA spare parts
257454506921	PIANO KEY SWITCH	TATA spare parts
257454506927	PIANO KEY SWITCH	TATA spare parts
257454506928	PIANO KEY SWITCH	TATA spare parts
257454506929	PIANO KEY SWITCH	TATA spare parts
257454506930	PIANO KEY SWITCH	TATA spare parts
257454506939	PIANO KEY SWITCH	TATA spare parts
257454506945	PIANO KEY SWITCH	TATA spare parts
257454509916	STARTER PUSH BUTTON	TATA spare parts
257454509917	FLASHER KIT	TATA spare parts
257454509918	HOUSING ADAPTOR	TATA spare parts
257454509919	FLASHER KIT	TATA spare parts
257454509928	FUSE BOX 10 POLE	TATA spare parts
257454509936	FLASHER KIT 150W	TATA spare parts
257454509939	BATTERY CUT OFF SWITCH	TATA spare parts
257454509943	FLASHER KIT	TATA spare parts
257454509944	FLASHER KIT ROUND	TATA spare parts
257454509948	FUSE LINK 10 AMP	TATA spare parts
257454509950	FUSE LINK 10 AMP	TATA spare parts
257454509953	MECH.STOP LIGHT SWITCH OFF.DRG	TATA spare parts
257454509954	STOP LIGHT SWITCH MECH	TATA spare parts
257454509956	LOW AIR PRESSURE SWITCH	TATA spare parts
257454509956AE	LOW AIR PRESSURE SWITCH	TATA spare parts
257454509957	LOW AIR PR IND SWITCH	TATA spare parts
257454509960	STOP LIGHT SWITCH MECH	TATA spare parts
257454509961	STOP LIGHT SWITCH PNEU	TATA spare parts
257454509962	MAIN LINE SWITCH	TATA spare parts
257454509963	KEY MAIN LINE SWITCH	TATA spare parts
257454509970	LOW AIR PR IND SWITCH	TATA spare parts
257454509977	MECH. STOP LIGHT SWITCH	TATA spare parts
257454509979	MECH STOP LIGHT SWITCH	TATA spare parts
257454509980	MECH STOP LIGHT SWITCH	TATA spare parts
257454509983	ELECTRONIC FLASHER	TATA spare parts
257454509985	LOW AIR PRESSURE SWITCH	TATA spare parts
257454509990	LOW AIR PRESSURE SWITCH	TATA spare parts
257454509996	LOW AIR PRESSURE SWITCH	TATA spare parts
257454510105	HAZARD WARNING SWITCH 12V	TATA spare parts
257454510106	HAZARD WARNING SWITCH	TATA spare parts
257454510107	HAZARD WARNING SWITCH 12V	TATA spare parts

257454510110	HAZARD WARNING SW 12V-PUSH PULL	TATA spare parts
257454510111	REVERSE LAMP SWITCH	TATA spare parts
257454510112	LOW AIR PRESSURE SWITCH	TATA spare parts
257454540104	HAZARD WARNING SWITCH 24V	TATA spare parts
257454540105	HAZARD WARNING SWITCH 24V	TATA spare parts
257454540106	HAZARD WARNING SWITCH 24V	TATA spare parts
257454540108	HAZARD WARNING SWITCH 24V	TATA spare parts
257454600132	CABLE SET	TATA spare parts
257454607501	GROMMET	TATA spare parts
257454607505	RUBBER GROMMET (55 DIA)	TATA spare parts
257454620111	CABLE SET GAUGES EARTHING	TATA spare parts
257454620118	MAIN CABLE SET	TATA spare parts
257454620183	MAIN CABLE SET RHD	TATA spare parts
257454640118	ASSY FRONT TO TAIL CABLE SET RHD 42WB	TATA spare parts
257454640131	ASSY.CABLE SET FRONT TO TAIL	TATA spare parts
257454640133	CABLE SET FRT TO TAIL	TATA spare parts
257454640159	MAIN CABLE SET	TATA spare parts
257454640167	MAIN CABLE SET RHD 1612SE	TATA spare parts
257454820116	ASSY.CABLESET FRONT TO TAIL	TATA spare parts
257454820121	MAIN CABLE SET	TATA spare parts
257454820124	MAIN CABLE SET RHD	TATA spare parts
257454820129	ASSY CABLE SET (FRT.TO TAIL)42W.B.(RHD)	TATA spare parts
257458900104	WHEEL SPANNER 30/32 AF	TATA spare parts
257458900105	PULLER IN VALVE SEAT INSERT	TATA spare parts
257458900106	PULLER - For Exhaust Valve Seat Insert	TATA spare parts
257458900107	BOX SPANNER DE 16 X 18	TATA spare parts
257458900203	SP TOOL 7TH MAIN OIL SEAL	TATA spare parts
257458900204	GAUGE CYL BORE	TATA spare parts
257458900205	ADAPTER STAND ENGINE	TATA spare parts
257458900206	DRIFT LINER REMOVAL	TATA spare parts
257458900207	DRIFT LINER INSTALLATION	TATA spare parts
257458900209	ENGINE STAND	TATA spare parts
257458902501	FIXTURE CL FINGER ADJUST	TATA spare parts
257458903301	PULLER	TATA spare parts
257458903302	PULLER FOR HUB	TATA spare parts
257458903303	DRIFT	TATA spare parts
257458903304	PULLER	TATA spare parts
257458903305	PULLER	TATA spare parts
257458903306	SETTING GAUGE/36 ANGLE OF LOCK/FA104	TATA spare parts
257458903307	PULLER FRONT HUB	TATA spare parts
257458903308	PULLER	TATA spare parts
257458903502	DRIFT	TATA spare parts
257458903503	DRIFT REAR HUB	TATA spare parts
257458903504	PULLER	TATA spare parts
257458903507	PULLER	TATA spare parts
257458903508	PRONGED WRENCH	TATA spare parts
257458903509	PULLER	TATA spare parts

257458903512	DRIFT RR AXLE	TATA spare parts
257458903513	DRIFT RR AXLE	TATA spare parts
257458903514	DRIFT RR AXLE	TATA spare parts
257458903515	DRIFT RR AXLE	TATA spare parts
257458903517	SPECIAL SOCKET SPANNER	TATA spare parts
257458904201	FIXTURE	TATA spare parts
257458904601	PULLER PITMAN ARM	TATA spare parts
257458904602	VICE ASSY STRG GEAR	TATA spare parts
257458904603	DISAMBLER LIMIT VALVE	TATA spare parts
257458904604	TORQUE MEASURING DEVICE	TATA spare parts
257458904605	INSERT TOR MEASURE INSTR	TATA spare parts
257458904606	ENTRY BUSH SHFT SEAL RING	TATA spare parts
257458904607	SLEEVE SHAFT SEAL RING	TATA spare parts
257458904608	ENTRY BUSH OVAL SEAL RING	TATA spare parts
257458904609	PULLER	TATA spare parts
257458904610	TESTER PS GEAR	TATA spare parts
257458904611	ADAPTER LIMIT WHEEL LOCK	TATA spare parts
257458904612	TONGUE PISTON ASSY	TATA spare parts
257458904613	VICE ASSY	TATA spare parts
257458904614	MANDREL	TATA spare parts
257458904615	DRIFT	TATA spare parts
257458909902	DRIFT FRONT HUB	TATA spare parts
257458909904	DRIFT	TATA spare parts
257470000119	ASSY CLIP LOCKING SHOVEL	TATA spare parts
257470000120	ASSY PICK HEAD & BRACKET	TATA spare parts
257470004301	CLIP HELVE END	TATA spare parts
257470004303	BRACKET SHOVEL END	TATA spare parts
257470120173	OIL CAN CARRIER	TATA spare parts
257470120174	JERRICON CARRIER	TATA spare parts
257470520102	CANOPY ASSY 1210 SD/36-FATROLE	TATA spare parts
257470610102	ASSY. HOLDING BRACKET	TATA spare parts
257470813203	U-CLAMP	TATA spare parts
257470813204	U-CLAMP	TATA spare parts
257470813801	PACKING (FOR U CLAMP)	TATA spare parts
257470920127	ASSY.WHEEL CHOCK	TATA spare parts
257482400106	KIT WIPER MOTOR 17W	TATA spare parts
257482400108	ASSY WIPER ARM 14 INCH	TATA spare parts
257482400109	ASSY WIPER ARM	TATA spare parts
257482400110	WIPER ARM RHD	TATA spare parts
257482400111	WIPER BLADE	TATA spare parts
257482400131	ASSY WIPER ARM	TATA spare parts
257482400135	ASSY WIPER ARM RHD	TATA spare parts
257482400136	KIT FOR ELECTRIC W/S WASHER	TATA spare parts
257482400137	NOZZLE	TATA spare parts
257482400138	BRACKET ASSY BS6	TATA spare parts
257482400141	ASSY LINK RH	TATA spare parts
257482400142	ASSY LINK LH	TATA spare parts

257482400144	KIT WIPER MOTOR 17W	TATA spare parts
257482400145	KIT WIPER MOTOR 17W	TATA spare parts
257482409903	WHEEL BOX SINGLE LINK END	TATA spare parts
257482409918	T-CONNECTOR BS6	TATA spare parts
257482409921	WIPER MOTOR	TATA spare parts
257498800101	MASCOT 1210A	TATA spare parts
257523400113	REPAIR KIT STRG PUMP	TATA spare parts
257524200101	RUBBER SUPPORT RR RH	TATA spare parts
257524200102	RUBBER SUPPORT RR LH	TATA spare parts
257524200111	ENGINE MTG RR RH LPT1313	TATA spare parts
257525200108	CLUTCH DISC-DIAPHGM	TATA spare parts
257525400101	CL PR PLATE 310 DIA DIAPH	TATA spare parts
257525400102	CL PR PLATE	TATA spare parts
257525400103	CLUTCH HSG.W/SPRING	TATA spare parts
257525400122	COVER W/DIAPHRAM SPG.	TATA spare parts
257525400601	REP KIT PR SPRING COIL	TATA spare parts
257525400602	REP KIT DIPH CL MAJ 310 D	TATA spare parts
257525400603	REP KIT DIPH CL MNR 310 D	TATA spare parts
257525404301	RING	TATA spare parts
257525407101	GUIDE PLATE	TATA spare parts
257525407401	RIVET	TATA spare parts
257525407402	RIVET	TATA spare parts
257525407403	RIVET	TATA spare parts
257525408701	STRAP	TATA spare parts
257525408702	REP KIT CL DIAPH SPRING	TATA spare parts
257525600104	ASSY COVER RH	TATA spare parts
257525600105	ASSY COVER	TATA spare parts
257525600106	HOSE ASSY	TATA spare parts
257525600109	BEARING OUTER RACE	TATA spare parts
257525600110	CL REL BRG W/SLEEVE	TATA spare parts
257525600111	CL REL BRG W/SLEEVE LHD	TATA spare parts
257525600116	CL REL SLEEVE W/PIN RHD	TATA spare parts
257525600118	ASSY.HOSE	TATA spare parts
257525600121	ASSY. HOSE BS4	TATA spare parts
257525603101	CLUTCH RELEASE BEARING	TATA spare parts
257525603103	CLUTCH RELEASE BEARING	TATA spare parts
257525603106	CLUTCH RELEASE BEARING BS1/2/3/4	TATA spare parts
257525603106AE	CLUTCH RELEASE BEARING - OFFER	TATA spare parts
257525603704	CLUTCH RELEASE SLEEVE	TATA spare parts
257526400101	ASSY LEVER	TATA spare parts
257526406701	PIN	TATA spare parts
257526406702	PIN	TATA spare parts
257526408601	SLEEVE	TATA spare parts
257526800112	TURNING ROD	TATA spare parts
257526800113	ASSY BRACKET	TATA spare parts
257526800114	GEAR SHIFT LEVER SUB ASSY	TATA spare parts
257526800125	ASSY GEAR SHIFT LEVER LH	TATA spare parts

257526803401	BUSH	TATA spare parts
257526803703	SHIFTER YOKE	TATA spare parts
257526805108	SHIFTING YOKE	TATA spare parts
257526805115	GEAR SHIFT LEVER C/S 46	TATA spare parts
257526805116	SHIFTING YOKE	TATA spare parts
257526806701	PIN	TATA spare parts
257526806702	PIN	TATA spare parts
257526807701	PROTECTIVE CAP	TATA spare parts
257526807703	PROTECTIVE CAP	TATA spare parts
257526808601	SPACER	TATA spare parts
257528159901	BREATHER	TATA spare parts
257529100101	CLUTCH PEDAL LEVER	TATA spare parts
257529100106	ASSY.TUBE	TATA spare parts
257529100108	SUPPORT PEDAL LEVER	TATA spare parts
257529100110	INTERMEDIATE LEVER	TATA spare parts
257529106001	PULL ROD	TATA spare parts
257529106006	CLUTCH ROD	TATA spare parts
257529106007	CLUTCH ROD LH	TATA spare parts
257529200106	DOUBLE LEVER BRAKE	TATA spare parts
257529200120	PULL ROD BRAKE	TATA spare parts
257529206901	TUBE BRAKE LEVER	TATA spare parts
257529208601	SPACER	TATA spare parts
257529300101	BRACKET	TATA spare parts
257529300107	BRACKET W/BALL PIN	TATA spare parts
257529300109	ADAPTER	TATA spare parts
257529306301	RUBBER COVER	TATA spare parts
257529309903	ADAPTER	TATA spare parts
257529400101	CONTROL LEVER	TATA spare parts
257529400102	CONTROL LEVER BOX	TATA spare parts
257529406901	TUBE	TATA spare parts
257529606901	TUBE	TATA spare parts
257530100101	TUBE LONG	TATA spare parts
257530100102	ASSY PULL ROD ACCELERATOR	TATA spare parts
257530100104	THRUST ROD RHD	TATA spare parts
257530103804	ACCELERATOR PEDAL	TATA spare parts
257530106004	THRUST ROD	TATA spare parts
257531000101	FRAME LPT 46	TATA spare parts
257531000104	FRAME ASSY LPS	TATA spare parts
257531207122	SUPPORT CROSS MEMBER	TATA spare parts
257531207128	REINFORCEMENT BOT RH	TATA spare parts
257531600115	ASSY SUBSTRUCTURE COMPLETE	TATA spare parts
257532100103	FRONT SPRING ASSY	TATA spare parts
257532100104	LEAF SPRING 1ST W/BUSH	TATA spare parts
257532100113	ASSY FRONT SPRING	TATA spare parts
257532100115	FRONT SPRING ASSY	TATA spare parts
257532100116	ASSY. FRONT SPRING LPT 1615/SE 1613	TATA spare parts
257532100117	ASSY.FIRST LEAF WITH BUSH	TATA spare parts

257532100120	ASSY.FRONT SPRING. HIGHER CAMBER	TATA spare parts
257532100122	ASSY FRONT SPRING	TATA spare parts
257532100124	ASSY FRONT SPRING	TATA spare parts
257532103201	CENTRE PIN	TATA spare parts
257532103301	SHOCK ABSORBER BRACKET BOTTOM	TATA spare parts
257532104201	SPRING CLIP	TATA spare parts
257532104202	SPRING CLIP	TATA spare parts
257532106301	DUST CAP SPRING PIN	TATA spare parts
257532106701	SPRING PIN FRT	TATA spare parts
257532107117	LEAF SPRING 4TH FRT	TATA spare parts
257532107118	LEAF SPRING 5TH FRT	TATA spare parts
257532107119	LEAF SPRING 6TH FRT	TATA spare parts
257532107120	LEAF SPRING 7TH FRT	TATA spare parts
257532107121	LEAF SPRING 8TH FRT	TATA spare parts
257532107122	LEAF SPRING 9TH FRT	TATA spare parts
257532107123	LEAF SPRING 10TH FRT	TATA spare parts
257532107124	LEAF SPRING 12TH FRT	TATA spare parts
257532107125	THIRTEENTH LEAF - FRONT SPRING	TATA spare parts
257532107183	SECOND LEAF.	TATA spare parts
257532107184	THIRD LEAF.	TATA spare parts
257532107185	FOURTH LEAF	TATA spare parts
257532107186	FIFTH LEAF	TATA spare parts
257532107187	SIXTH LEAF	TATA spare parts
257532107188	SEVENTH LEAF	TATA spare parts
257532107189	EIGHTH LEAF	TATA spare parts
257532107190	NINETH LEAF	TATA spare parts
257532107191	TENTH LEAF	TATA spare parts
257532107192	ELEVENTH LEAF	TATA spare parts
257532107193	TWELVETH LEAF	TATA spare parts
257532107194	THIRTEENTH LEAF	TATA spare parts
257532107195	FORTEENTH LEAF	TATA spare parts
257532200101	SHACKLE FRT SPRING	TATA spare parts
257532203401	BUSH	TATA spare parts
257532203403	BUSH	TATA spare parts
257532203701	CASTER PLATE	TATA spare parts
257532204203	U CLAMP	TATA spare parts
257532204204	U BOLT FRONT ( M20 X 1.5 X 250)	TATA spare parts
257532204205	U CLAMP FRONT	TATA spare parts
257532204206	U BOLT	TATA spare parts
257532204207	U-CLAMP-FRONT	TATA spare parts
257532204209	U CLAMP	TATA spare parts
257532303201	PIN MOUNTING TOP	TATA spare parts
257532400103	REAR SPRING ASSY W/AUX	TATA spare parts
257532400104	LEAF SPRING 1ST W/BUSH	TATA spare parts
257532400104DF	MAIN LEAF REAR W/BUSH SA1210/1212	TATA spare parts
257532400106	REAR SPRING ASSY	TATA spare parts
257532403201	CENTRE PIN	TATA spare parts

257532404207	SPRING CLIP	TATA spare parts
257532404210	SPRING CLIP BS6	TATA spare parts
257532405301	SPACER	TATA spare parts
257532407102	SECOND LEAF	TATA spare parts
257532407122	LEAF SPRING 2ND RR	TATA spare parts
257532407123	LEAF SPRING 3RD RR	TATA spare parts
257532407124	LEAF SPRING 4TH RR	TATA spare parts
257532407125	LEAF SPRING 5TH RR	TATA spare parts
257532407126	LEAF SPRING 6TH RR	TATA spare parts
257532407129	LEAF SPRING 9TH RR	TATA spare parts
257532407130	LEAF SPRING 10TH RR	TATA spare parts
257532407131	LEAF SPRING 11TH RR	TATA spare parts
257532407132	LEAF SPRING 12TH RR	TATA spare parts
257532407133	LEAF SPRING AUX 1ST	TATA spare parts
257532407134	LEAF SPRING 2ND AUX	TATA spare parts
257532407135	LEAF SPRING 3RD AUX	TATA spare parts
257532407136	LEAF SPRING 4TH AUX	TATA spare parts
257532407139	LEAF SPRING 7TH AUX	TATA spare parts
257532410101	ASSY.REAR SPG. WITH AUX.S	TATA spare parts
257532410102	ASSY.FIRST LEAF WITH BUSH.	TATA spare parts
257532417103	THIRD LEAF.	TATA spare parts
257532417104	FOURTH LEAF	TATA spare parts
257532417105	FIFTH LEAF	TATA spare parts
257532417106	SIXTH LEAF	TATA spare parts
257532417107	SEVENTH LEAF	TATA spare parts
257532417108	EIGHTH LEAF	TATA spare parts
257532417109	NINETH LEAF	TATA spare parts
257532417110	TENTH LEAF	TATA spare parts
257532417111	ELEVENTH LEAF	TATA spare parts
257532417112	TWELVETH LEAF	TATA spare parts
257532417113	THIRTEENTH LEAF	TATA spare parts
257532417114	FIRST LEAF AUX.SPRING	TATA spare parts
257532417115	SECOND LEAF AUX.SPRING	TATA spare parts
257532417116	THIRD LEAF-AUX SPRING	TATA spare parts
257532417117	FOURTH LEAF-AUX SPRING	TATA spare parts
257532417118	FIFTH LEAF-AUX SPRING	TATA spare parts
257532417119	SIXTH LEAF-AUX SPRING	TATA spare parts
257532417120	SEVENTH LEAF-AUX SPRING	TATA spare parts
257532417121	EIGHTH LEAF-AUX SPRING	TATA spare parts
257532500101	SHACKLE REAR SPRING	TATA spare parts
257532503401	BUSH SPRING SHACKLE	TATA spare parts
257533000102	FRONT AXLE ASSY W/BRAKES	TATA spare parts
257533000107	FRONT AXLE SPIG RHD W/BRK	TATA spare parts
257533000118	FRONT AXLE SCAM SPIG RHD	TATA spare parts
257533000122	ASSY FR AXLE WT BRAKES + SPIGOT + DAOH R	TATA spare parts
257533000136	FRONT AXLE SCAM W/BR	TATA spare parts
257533100105	ASSY.FRONT AXLE COMP.SET-NORMAL	TATA spare parts

257533105107	FRONT AXLE BEAM STD BS1/2/3/4	TATA spare parts
257533200105	STUB AXLE STD	TATA spare parts
257533200113	STUB AXLE STD	TATA spare parts
257533200125	STUB AXLE STD BS1/2/3/4	TATA spare parts
257533203401	BUSH KING PIN BS1/2/3/4	TATA spare parts
257533203401DF	BUSH - KING PIN -6T FA-1613/1618/2518/31	TATA spare parts
257533206301	DUST CAP STUB AXLE	TATA spare parts
257533209203	THRUST WASHER UPPER NORMAL BS2/3/4	TATA spare parts
257533209207	THRUST WASHER LOWER STD BS1/2/3/4/6	TATA spare parts
257533209208	THRUST WASHER LOWER STD1	TATA spare parts
257533400103	HUB FRONT W/O BRG SPIG	TATA spare parts
257533400104	HUB FRONT W/BRG SPIGOTTED	TATA spare parts
257533400106	ASSY FRT HUB W/BRG & BOLT	TATA spare parts
257533403101	BEARING TAPER ROLLER	TATA spare parts
257533403703	WHEEL HUB FRONT	TATA spare parts
257533405102	HUB FRONT W/O BRG NON SPI	TATA spare parts
257533405104	HUB FRONT	TATA spare parts
257533408601	SPACER OIL SEAL	TATA spare parts
257533408602	SPACER ON STUB AXLE	TATA spare parts
257533408603	SPACER TUBE	TATA spare parts
257533409201	THRUST WASHER BS1/2/3/4	TATA spare parts
257535000119	ASSY REAR AXLE 108 RR	TATA spare parts
257535000122	REAR AXLE 108RR 48/7 W/BR	TATA spare parts
257535000171	REAR AXLE RA108RR SCAM	TATA spare parts
257535000172	REAR AXLE 108RR SCAM 1612	TATA spare parts
257535000176	REAR AXLE 108RR SCAM	TATA spare parts
257535000179	REAR AXLE 108RR 45/7 SPIG	TATA spare parts
257535000182	REAR AXLE 108RR 48/7 DAOH	TATA spare parts
257535000191	REAR AXLE 108RR 45X7 W/BR	TATA spare parts
257535000192	ASSY RR AXLE/1312/SP	TATA spare parts
257535000204	REAR AXLE 108RR SCAM 41/7	TATA spare parts
257535000205	ASSY RA WITH HUBS 41/7 OR 47/8 S CAM BR	TATA spare parts
257535100105	R/A HSG.W/AXLETUBE1210A/B	TATA spare parts
257535100111	RR AXLE BEAM W/TUBE BANJO	TATA spare parts
257535100112	R/AXLE BEAM 1312 DAOH BAN	TATA spare parts
257535100144	REAR AXLE BEAM SCAM BANJO	TATA spare parts
257535100145	R/AXLE BEAM SCAM/1612	TATA spare parts
257535100146	R/AXLE BEAM/2213/SCAM	TATA spare parts
257535100167	REAR AXLE BEAM	TATA spare parts
257535100171	REAR AXLE BEAM MACHINED	TATA spare parts
257535104206	U CLAMP	TATA spare parts
257535104208	U CLAMP	TATA spare parts
257535104212	U-CLAMP 20X1.5 485LG.	TATA spare parts
257535105002	COUPLING FLANGE	TATA spare parts
257535105105	SPRING SADDLE BOTTOM	TATA spare parts
257535110103	ASSY.CARRIER COMP (41/7 OERLIKON)1613	TATA spare parts
257535110106	CARRIER HOUSING	TATA spare parts



257535113201	BOLT PLUMMER BLOCK COVER	TATA spare parts
257535300105	DIFFERENTIAL CASE COVER BS1/2/3/4	TATA spare parts
257535300106	DIFFERENTIAL ASSY 1312	TATA spare parts
257535300108	CWP SET 45/7 OREL	TATA spare parts
257535300117	DIFFERENTIAL ASSY 45/7 OR	TATA spare parts
257535300120	END YOKE	TATA spare parts
257535300121	KIT DIFF BEVEL GEAR 108RR	TATA spare parts
257535300123	ASSY ADJUSTING PIN	TATA spare parts
257535300125	GEARS DIFFERENTIAL	TATA spare parts
257535300127	GEARS DIFFERENTIAL	TATA spare parts
257535303101	BEARING TAPER ROLLER	TATA spare parts
257535303102	TAPER ROLLER BRG 47487XL BS1/2/3/4/6	TATA spare parts
257535303103	BEARING TAPER ROLLER	TATA spare parts
257535303104	BEARING TAPER ROLLER	TATA spare parts
257535305101	DIFFERENTIAL SPIDER BS1/2/3/4	TATA spare parts
257535305101AE	DIFFERENTIAL SPIDER 1628	TATA spare parts
257535305401	REAR AXLE SHAFT GEAR-9X16-M/CED	TATA spare parts
257535305402	DIFFERENTIAL BEVEL PINION-9/16-M/CED	TATA spare parts
257535305403	GEAR REAR AXLE SHAFT	TATA spare parts
257535305404	BEVEL GEAR OLD	TATA spare parts
257535305405	GEAR REAR AXLE SHAFT	TATA spare parts
257535305406	BEVEL GEAR NEW	TATA spare parts
257535305408	PINION - CWP:45/7-0108OR	TATA spare parts
25753530541122	1312 REVACYCLE BEVEL GEAR FINISH-TURNED	TATA spare parts
25753530541222	1312 REVACYCLE SHAFT GEAR FINISH-TURNED	TATA spare parts
257535305413	DIFFL BEVEL PINION REVA	TATA spare parts
257535305414	GEAR RA SHAFT-REVA CYCLE	TATA spare parts
257535308001	COLLAR SCREW M14X53	TATA spare parts
257535308602	SPACER	TATA spare parts
257535309201	SPHERICAL WASHER BS1/2/3/4/6	TATA spare parts
257535309901	SLIDER	TATA spare parts
257535600101	HUB REAR W/BRG	TATA spare parts
257535600102	HUB REAR W/O BRG	TATA spare parts
257535600104	HUB REAR W/O BRG SPIG	TATA spare parts
257535600105	HUB REAR W/O BRG SPIG	TATA spare parts
257535600108	HUB REAR W/BEARING	TATA spare parts
257535600109	HUB W/O BRG SPIGOTTED	TATA spare parts
257535603101	BEARING TAPER ROLLER	TATA spare parts
257535603102	BEARING TAPER ROLLER	TATA spare parts
257535603103	BEARING TAPER ROLLER	TATA spare parts
257535603104	BEARING TAPER ROLLER	TATA spare parts
257535603105	TAPER ROLLER BRG	TATA spare parts
257535603106	TAPER ROLLER BRG	TATA spare parts
257535603107	TAPER ROLLER BRG	TATA spare parts
257535603108	TAPER ROLLER BEARING.	TATA spare parts
257535603109	TAPER ROLLER BEARING	TATA spare parts
257535603110	TAPER ROLLER BRG 32214 BS1/2/3/4	TATA spare parts

257535603701	BEARING REAR HUB OUTER	TATA spare parts
257535608314	SHIM 0.05 THICK	TATA spare parts
257535608315	SHIM 0.10 MM	TATA spare parts
257535608316	SHIM 0.15 MM	TATA spare parts
257535608317	SHIM 0.20 MM	TATA spare parts
257535608318	SHIM 0.25 MM	TATA spare parts
257535608319	SHIM 0.30 MM	TATA spare parts
257535608320	SHIM 0.50 MM	TATA spare parts
257535608321	SHIM 1.00 MM	TATA spare parts
257535608322	SHIM 1.50 MM	TATA spare parts
257535608323	SHIM 2.50 MM	TATA spare parts
257535608607	SPACER TUBE	TATA spare parts
257535707901	REAR AXLE SHAFT	TATA spare parts
257535707902	REAR AXLE SHAFT BS1/2/3/4	TATA spare parts
257535707902DF	REAR AXLE SHAFT-RA108-W/1684 TRK	TATA spare parts
257540100101	WHEEL DISC & RIM 10X20HD	TATA spare parts
257540100103	WHEEL DISC & RIM 7X20HD	TATA spare parts
257540100105	TYRE ASSY 10X20 16PR NYLON /RIB FRONT	TATA spare parts
257540100106	WHEEL DISC & RIM 7X20HD	TATA spare parts
257540100109	ASSY. WHEEL DISC & RIM BS2/3/4	TATA spare parts
257540100110	WHEEL NUT SPIG 1313	TATA spare parts
257540100112	WHEEL DISC & RIM 7X20HD	TATA spare parts
257540100116	WHEEL DISC & RIM 7X20HD	TATA spare parts
257540106101	LOCKING RING BS3/4/6	TATA spare parts
257540106501	RING	TATA spare parts
257540106502	NUT	TATA spare parts
257540109201	WHEEL DISC 7X20	TATA spare parts
257540200101	TYRE ASSY 10.0X20 16-PLY/NYLON-LUG REAR	TATA spare parts
257541100101	PROP SHAFT W/CB 76X4X1261	TATA spare parts
257541100102	PROP SHAFT FR 76X1261 8HC	TATA spare parts
257541100104	COUPLING FLANGE	TATA spare parts
257541100106	PROPELLER SHAFT	TATA spare parts
257541100128	PROP SHAFT FR W/CB 90X388	TATA spare parts
257541100129	PROP SHAFT FR W/CB 90X388	TATA spare parts
257541105101	U/J SHORT FORK	TATA spare parts
257541120105	PROP SHAFT RR 90X3X1319	TATA spare parts
257541120106	ASSY.PROP.SHAFT COMP. 90X1319 LG.	TATA spare parts
257541120108	PROP SHAFT RR 90X3X1199	TATA spare parts
257541120111	PROP SHAFT RR 90X3X796	TATA spare parts
257542100103	CUP ASSY	TATA spare parts
257542100104	ASSY WHEEL BRK CYL FRT 44.45D	TATA spare parts
257542100107	BRAKE DRUM LH FRT SCAM	TATA spare parts
257542100108	BRAKE DRUM RH FRT SCAM	TATA spare parts
257542100109	ASSY FRONT BRAKE-LH S-CAM	TATA spare parts
257542100110	ASSY FRONT BRAKE-RH S-CAM	TATA spare parts
257542100119	SPIDER ASSY BRAKE LH	TATA spare parts
257542100120	SPIDER ASSY BRAKE RH	TATA spare parts

257542103206	BOLT NON STG SIDE	TATA spare parts
257542103207	BOLT- AXLE MOUNTING	TATA spare parts
257542103701	BRAKE DRUM	TATA spare parts
257542103702	SPIDER FRT BR LH 1312	TATA spare parts
257542106703	COLLARED PIN	TATA spare parts
257542106704	COLLARED PIN	TATA spare parts
257542108202	HEAT SHIELD	TATA spare parts
257542110101	ANCHOR PLATE LH	TATA spare parts
257542110102	ANCHOR PLATE RH	TATA spare parts
257542110105	ASSY ANCHOR PLATE FRT RH	TATA spare parts
257542110106	ASSY ANCHOR PLATE FRT RH	TATA spare parts
257542113701	TORQUE PLATE LH 1312	TATA spare parts
257542113702	TORQUE PLATE RH 1312	TATA spare parts
257542120101	WHEEL CYL.44.45D FRT	TATA spare parts
257542120102	REP KIT WHEEL CYL 44.45D	TATA spare parts
257542120103	RETURN SPRING	TATA spare parts
257542120104	ASSY WHEEL CYL 44.45D	TATA spare parts
257542120105	REP KIT WHEEL CYL 44.45D	TATA spare parts
257542120106	ASSY.WHEEL CYL.44.450	TATA spare parts
257542120107	WHEEL CYL.44.45D FRT	TATA spare parts
257542120108	ASSY WHEEL CYL 44.45D	TATA spare parts
257542120112	REP KIT W/CYL 44.45D	TATA spare parts
257542124301	CIRCLIP	TATA spare parts
257542126602	PLUNGER	TATA spare parts
257542127701	DUST COVER	TATA spare parts
257542190102	REPAIR KIT	TATA spare parts
257542300104	THRUST SHACKLE LH	TATA spare parts
257542300105	THRUST SHACKLE RH	TATA spare parts
257542300106	HAND BRAKE SHAFT	TATA spare parts
257542300110	BRAKE ASSY RR LH	TATA spare parts
257542300111	BRAKE ASSY RR RH	TATA spare parts
257542300112	BRAKE ASSY RR LH	TATA spare parts
257542300113	BRAKE ASSY RR RH	TATA spare parts
257542300125	ASSY DRUM BRAKE LH NON ASBESTOS	TATA spare parts
257542300126	ASSY DRUM BRAKE RH NON ASBESTOS	TATA spare parts
257542303701	BRAKE DRUM	TATA spare parts
257542303705	BRAKE DRUM SCAM FR & RR BS4 BS1/2/3/4	TATA spare parts
257542303706	BRAKE DRUM	TATA spare parts
257542306701	PIN	TATA spare parts
257542307907	CAM SHAFT REAR LH	TATA spare parts
257542307908	CAM SHAFT REAR RH	TATA spare parts
257542307909	CAM SHAFT REAR LH	TATA spare parts
257542307910	CAM SHAFT REAR RH	TATA spare parts
257542310185	BRAKE MOUNTING FASTENER KIT	TATA spare parts
257542320101	WHEEL CYL.50.80D	TATA spare parts
257542320102	WHEEL CYL.50.80D RR	TATA spare parts
257542320103	WHEEL CYL.50.80D	TATA spare parts

257542320104	REP KIT WHEEL CYL RR 50.8	TATA spare parts
257542320105	PRESSURE SPRING	TATA spare parts
257542320106	ASSY WHEEL CYL 50.8D	TATA spare parts
257542320108	WHEEL CYLINDER	TATA spare parts
257542320109	WHEEL CYL.50.80D	TATA spare parts
257542320110	WHEEL CYLINDER	TATA spare parts
257542320111	ASSY WHEEL CYL 50.8D	TATA spare parts
257542320114	REP KIT W/CYL 50.8D	TATA spare parts
257542324301	CIRCLIP	TATA spare parts
257542326602	PISTON W/CYL REAR	TATA spare parts
257542327701	RUBBER BELLOW	TATA spare parts
257542328002	BLEEDING SCREW	TATA spare parts
257542410102	WHEEL CYLINDER BODY	TATA spare parts
257542410104	CROWN W/SEAL & SPRING	TATA spare parts
257542410105	CROWN & SKIRT ASSY	TATA spare parts
257542417701	RUBBER BELLOW	TATA spare parts
257542417702	WEAR PAD	TATA spare parts
257542418207	SKIRT	TATA spare parts
257542419201	SPHERICAL WASHER	TATA spare parts
257542800117	BRAKE TUBE	TATA spare parts
257542800124	BRAKE FLUID CONTAINER	TATA spare parts
257542800125	BRAKE FLUID CONTAINER	TATA spare parts
257542800126	FILTER FOR TMC	TATA spare parts
257542800127	CON LINE CONT TO SOCKET	TATA spare parts
257542800139	CON LINE FR BRAKE CIRCUIT	TATA spare parts
257542800140	CON LINE RR BRAKE CIRCUIT	TATA spare parts
257542806810	BANJO 3 WAY	TATA spare parts
257543100102	TANDEM MASTER CYL	TATA spare parts
257543100104	KIT REP MAJOR TMC	TATA spare parts
257543100105	KIT REP MINOR TMC	TATA spare parts
257543100106	TANDEM MASTER CYL	TATA spare parts
257543100111	TANDEM MASTER CYL	TATA spare parts
257543100112	TANDEM MASTER CYL	TATA spare parts
257543100120	KIT REP MAJOR TMC	TATA spare parts
257543100121	KIT REP MINOR TMC	TATA spare parts
257543100928	CONNECTOR 3 WAY	TATA spare parts
257543106502	SIDE CUP	TATA spare parts
257543106601	PLUNGER PRIMARY	TATA spare parts
257543106602	PLUNGER SECONDARY	TATA spare parts
257543106613	PRI PISTON TMC	TATA spare parts
257543106801	END CAP	TATA spare parts
257543106802	PLUG	TATA spare parts
257543107701	GLAND SEAL	TATA spare parts
257543108301	SHIM	TATA spare parts
257543108701	SPRING	TATA spare parts
257543108702	SPRING	TATA spare parts
257543108716	PRI SPRING	TATA spare parts

257543109202	HEX SCREW PLUG M10X1	TATA spare parts
257543109203	GASKET	TATA spare parts
257543320111	ASSY WHEEL CYL 50.8D	TATA spare parts
257544110107	LEVER ASSY	TATA spare parts
257544119901	BOSS FOR SHIFT CYLINDER	TATA spare parts
257545200101	ASSEMBLY PNEUMALIC SHIFTING CYL	TATA spare parts
257546000107	DRAG LINK ASSY	TATA spare parts
257546000114	ASSY DRAG LINK	TATA spare parts
257546000116	DRAG LINK ASSY	TATA spare parts
257546000129	DRAG LINK ASSY	TATA spare parts
257546000133	DRAG LINK ASSY RHD	TATA spare parts
257546100101	SUPPORT STRG COLUMN	TATA spare parts
257546100107	UNIVERSAL JOINT	TATA spare parts
257546100117	BKT STRG G/BOX & CON MTG	TATA spare parts
257546100118	ASSY STG.GEAR BOX & CONTROL MTG.BKT.	TATA spare parts
257546100120	ASSY. STEERING COLUMN SUPPORT	TATA spare parts
257546100122	SUPPORT STRG COLUMN	TATA spare parts
257546106301	RUBBER BELLOW	TATA spare parts
257546106302	RUBBER BELLOW	TATA spare parts
257546106303	RUBBER BELLOW	TATA spare parts
257546108202	CLAMPING RING	TATA spare parts
257546108601	SPACER MTG PIN	TATA spare parts
257546207902	STRG SPINDLE TOP	TATA spare parts
257546207910	STRG SPINDLE BOTTOM	TATA spare parts
257546207918	STEERING SPINDLE TOP- 477 MM LPT1616ARMY	TATA spare parts
257546207920	STEERING SPINDLE - BOTTOM	TATA spare parts
257546207921	STEERING SPINDLE BOTTOM	TATA spare parts
257546305102	PITMAN ARM	TATA spare parts
257546306001	PITMAN ARM 1313/1616/1615LPT (RH)	TATA spare parts
257546306003	PITMAN ARM	TATA spare parts
257547100101	FUEL TANK 250 LTR RHD	TATA spare parts
257547100102	FUEL TANK 250 LTR	TATA spare parts
257547100107	FUEL TANK 250 LTRS	TATA spare parts
257547100117	FUEL TANK 250 LTR RHD	TATA spare parts
257549100101	EXHAUST PIPE FRONT	TATA spare parts
257549100102	HEAT SHIELD	TATA spare parts
257549100108	EXHAUST PIPE INTERMEDIATE	TATA spare parts
257549100109	ASSY.EXHAUST PIPE (FRONT MIDDLE)	TATA spare parts
257549100110	EXH PIPE FRT ALUM PAINTED	TATA spare parts
257549100111	EXHAUST PIPE FRONT MIDDLE	TATA spare parts
257549100115	EXHAUST PIPE FRONT	TATA spare parts
257549100116	EXHAUST PIPE FRONT	TATA spare parts
257549203301	BRACKET	TATA spare parts
257549206901	TUBE	TATA spare parts
257549206907	EXHAUST PIPE RR LHD	TATA spare parts
257550000107	RADIATOR FRAME	TATA spare parts
257550005801	RUBBER HOSE	TATA spare parts

257550100106	RADIATOR ASSY	TATA spare parts
257550100108	RADIATOR ASSY 1312	TATA spare parts
257550100110	RADIATOR ASSY	TATA spare parts
257550100118	RADIATOR ASSY	TATA spare parts
257550100198	RADIATORW/FILLER CAP	TATA spare parts
257554100106	POSITIVE CABLE	TATA spare parts
257554100115	ASSY CU BATT CABLE +VE 70MM2	TATA spare parts
257554200101	HOSE ASSY	TATA spare parts
257554200108	HOSE FOR OIL PR GAUGE	TATA spare parts
257554200109	PIPE OIL PRESSURE	TATA spare parts
257554200110	PIPE OIL PRESSURE	TATA spare parts
257554209901	GAUGE FUEL	TATA spare parts
257554209902	GAUGE OIL PRESSURE	TATA spare parts
257554209903	TEMP GAUGE ELEC	TATA spare parts
257554209904	AMMETER	TATA spare parts
257554209906	SPEEDOMETER-1:1.125	TATA spare parts
257554209907	SPEEDOMETER 1:1.08	TATA spare parts
257554209911	TEMPERATURE TRANSDUCER	TATA spare parts
257554209912	3.2D SPEEDO CABLE	TATA spare parts
257554209914	SPEEDOCABLE 2200MM	TATA spare parts
257554209916	TANK UNIT	TATA spare parts
257554209917	SPEEDOCABLE 2750MM	TATA spare parts
257554209955	SPEEDOCABLE	TATA spare parts
257554400111	INDICATOR LAMP BR FAIL	TATA spare parts
257554400112	INDICATOR LAMP BR FLUID	TATA spare parts
257554400118	HEAD LAMP RH	TATA spare parts
257554400120	HEAD LAMP LH	TATA spare parts
257554410106	ASSY H/L PC RIM W/BULB LHD-RH	TATA spare parts
257554410108	ASSY H/L PC RIM W/BULB LH-LHD	TATA spare parts
257554500901	STOP LIGHT SWITCH	TATA spare parts
257554500903	STOP LIGHT SWITCH (C/O CONTACTS)	TATA spare parts
257554509901	MAIN LINE SWITCH	TATA spare parts
257558900201	DRIFT LINER REMOVAL 95D	TATA spare parts
257558900202	DRIFT LINER INSTALLA 95D	TATA spare parts
257558902501	MANDREL	TATA spare parts
257558902502	FIXTURE FOR DIAPH	TATA spare parts
257558903501	DRIFT	TATA spare parts
257558903502	ROCKER	TATA spare parts
257558903503	JAWS	TATA spare parts
257558903504	WRENCH HUB LOCK NUT	TATA spare parts
257562508202	PANEL OUTER TOP W/S BS6	TATA spare parts
257562608204	PANEL INNER TOP W/S BS6	TATA spare parts
257564700101	REAR WALL ASSY	TATA spare parts
257564708203	PANEL OUTER TOP	TATA spare parts
257566500102	ASSY MUDGURD LH REAR	TATA spare parts
257566506908	SUPPORT [MUDGUARD FRT] LH	TATA spare parts
257566506909	SUPPORT(MUDGUARD FRT)RH	TATA spare parts

257566600101	ASSY STEP WELL COMP	TATA spare parts
257566600102	ASSY STEP WELL COMP	TATA spare parts
257567102301	W/S GLASS LH	TATA spare parts
257567102302	W/S GLASS RH	TATA spare parts
257567102501	FILLER PROFILE	TATA spare parts
257567102502	PROFILE SIDE WINDOW	TATA spare parts
257567102503	FILLER PROFILE	TATA spare parts
257567106301	RUBMOULD SIDE WINDOW EPDM	TATA spare parts
257567106302	RUB MOULD RR WINDOW EPDM	TATA spare parts
257567106303	RUB MOULD LH WINDSHIELD	TATA spare parts
257567106304	RUB MOULD RH WINDSHIELD	TATA spare parts
257569200101	ASSY PADDING-DASH BOARD	TATA spare parts
257569400102	ASSY REAR WALL PADDING	TATA spare parts
257569400103	ASSY REAR WALL PADDING	TATA spare parts
257572306304	RUB MOULD DOOR INNER	TATA spare parts
257572306305	RUB MOULD DOOR INNER	TATA spare parts
257572700101	ASSY. DOOR PADDING RH BS1/2/3/4	TATA spare parts
257572700102	ASSY. DOOR PADDING LH BS1/2/3/4	TATA spare parts
257581100101	SUNVISOR RH	TATA spare parts
257581100101AE	ASSY.SUNVISOR RH 1628 1828	TATA spare parts
257581100102	SUNVISOR LH	TATA spare parts
257581100102AE	ASSY.SUNVISOR LH 1628 1828	TATA spare parts
257581708201	COWLç NUMBERç P	TATA spare parts
257588500109	ASSY. BUMPER COMPLETE	TATA spare parts
257588706302	BASE PLATE GEAR SHIFTING	TATA spare parts
257589100101	BKT COWL MTG REAR LH	TATA spare parts
257589100103	BKT MTG FRT LH RHD	TATA spare parts
257589100109	ASSY.BRACKET LH.(REAR MTG.)	TATA spare parts
257589100110	ASSY BRACKET RH(REAR MTG.)	TATA spare parts
257589100111	BKT CAB MTG RH RR SL CAB	TATA spare parts
257589100112	BKT CAB MTG LH RR SL CAB	TATA spare parts
257589108602	SPACER TUBE RR MTG	TATA spare parts
257598800102	MASCOT 1312 PLATED	TATA spare parts
257598800104	MASCOT 1612	TATA spare parts
257598800106	MASCOT 1316	TATA spare parts
257598800107	ASSY MASCOT 1613	TATA spare parts
257599707501	RUBBER GROMMET	TATA spare parts
257615400601	HEAT SINK ASSY -VE	TATA spare parts
257615400602	HEAT SINK ASSY AUX	TATA spare parts
257615400603	HEAT SINK ASSY +VE	TATA spare parts
257615400608	HEAT SINK	TATA spare parts
257615401401	REGULATOR	TATA spare parts
257615401402	BRUSH BOX ASSEMBLY	TATA spare parts
257615401403	REGULATOR 53A	TATA spare parts
257615402501	ROTOR ASSEMBLY	TATA spare parts
257615402503	STATOR ASSEMBLY	TATA spare parts
257615403101	SRE BEARING	TATA spare parts

257615403102	DRIVE END BEARING	TATA spare parts
257615405401	DIODE AUX	TATA spare parts
257615409901	ALTERNATOR 12V/53A	TATA spare parts
257615409903	ALTERNATOR 12V/53A	TATA spare parts
257624100101	ENGINE MOUNT PAD FRONT BS1/2/3/4/6	TATA spare parts
257624100101AE	ASSY RUBBER SUPPORT FRONT 715	TATA spare parts
257624109201	WASHER	TATA spare parts
257624200114	BRACKET ENG MTG RR	TATA spare parts
257624200115	ENGINE MOUNTING RR	TATA spare parts
257624200118	ENGINE MOUNTING REAR BS1/2/3/4	TATA spare parts
257624208201	LOCKING PLATE	TATA spare parts
257625200111	CLUTCH DISC 350 DIA	TATA spare parts
257625200114	CLUTCH DISC 350 DIA	TATA spare parts
257625200119	CLUTCH DISC 350 DIA	TATA spare parts
257625200123	CLUTCH DISC 350D	TATA spare parts
257625206312	CL LINING 350 DIA 3.5MM	TATA spare parts
257625207401	RIVET CL LINING	TATA spare parts
257625207402	RIVET	TATA spare parts
257625400118	CL PR PLATE 350 DIA	TATA spare parts
257625403708	PRESSURE PLATE	TATA spare parts
257625404302	RING	TATA spare parts
257625406103	LOCKING RING	TATA spare parts
257625408201	SLEEVE	TATA spare parts
257625408603	SPACER RING	TATA spare parts
257625408709	SPRING DIAPHRAM	TATA spare parts
257625600107	RELEASE FORK W/BALL PIN	TATA spare parts
257625600108	BRACKET OUTSIDE	TATA spare parts
257625600109	CL REL BRG W/SLEEVE	TATA spare parts
257625600113	HOSE ASSY	TATA spare parts
257625600117	HOSE ASSY	TATA spare parts
257625600127	CL REL BRG W/SLEEVE	TATA spare parts
257625603101	BEARING OUTER RACE	TATA spare parts
257625603104	SPHERICAL BEARING	TATA spare parts
257625603106	CLUTCH RELEASE BEARING	TATA spare parts
257625603703	CLUTC RELEASE SLEEVE CAST	TATA spare parts
257625604301	SNAP RING	TATA spare parts
257625605103	RELEASE FORK	TATA spare parts
257625606801	DOUBLE SOCKET	TATA spare parts
257625607701	RUBBER BELLOW	TATA spare parts
257625608201	BRACKET INSIDE	TATA spare parts
257626800118	TURNING TUBE ASSY	TATA spare parts
257626806103	LOCK PLATE	TATA spare parts
257629100109	CLUTCH LEVER ASSY	TATA spare parts
257629100112	ASSY PEDAL PLATE LHD	TATA spare parts
257629100115	ASSY PEDAL LEVER CLUTCH	TATA spare parts
257629106301	RUBBER COVER	TATA spare parts
257629106701	SHOULDER PIN	TATA spare parts



257629106903	TUBE CLUTCH LEVER	TATA spare parts
257629106904	TUBE CLUTCH LEVER	TATA spare parts
257629203402	BUSH DOUBLE LEVER	TATA spare parts
257629300134	INTERMEDIATE LEVER	TATA spare parts
257629300135	CLUTCH ROD	TATA spare parts
257629303402	BUSH	TATA spare parts
257629303403	BUSH	TATA spare parts
257629306049	CLUTCH ROD	TATA spare parts
257629306050	CLUTCH ROD LH	TATA spare parts
257629306051	PULL ROD CLUTCH	TATA spare parts
257629309201	WASHER	TATA spare parts
257629309202	LOCK WASHER	TATA spare parts
257629309905	TURN BUCKLE	TATA spare parts
257629309906	ADAPTER	TATA spare parts
257629500120	BRACKET ON GEAR BOX	TATA spare parts
257629500121	CONTROL MTG BRACKET	TATA spare parts
257629500133	BRACKET	TATA spare parts
257629507109	LINK	TATA spare parts
257629508602	SPACER	TATA spare parts
257630100130	LEVER ACCELERATOR	TATA spare parts
257630100145	ASSY THRUST ROD	TATA spare parts
257630100148	THRUST ROD	TATA spare parts
257630100149	LEVER ACCL PEDAL	TATA spare parts
257630100150	ACCL PULL ROD	TATA spare parts
257630100153	ASSY LEVER ACCELERATOR	TATA spare parts
257630103802	PEDAL ACCELERATOR	TATA spare parts
257630103803	PEDAL ACCELERATOR	TATA spare parts
257630103804	PEDAL ACCELERATOR	TATA spare parts
257630106038	ACCL PULL ROD	TATA spare parts
257630106705	PIN	TATA spare parts
257630107902	ACCL SHAFT	TATA spare parts
257630107907	SHAFT ACCELERATOR	TATA spare parts
257631000108	ASSY FRAME COMPLETE	TATA spare parts
257631000113	FRAME ASSY LPK1516	TATA spare parts
257631003201	HEX. BOLT (M16X1.5X45)	TATA spare parts
257631010103	FRAME ASSY LPS1616/32	TATA spare parts
257631200103	CROSS MEMBER RR S/ABS	TATA spare parts
257631200105	CROSS MEMBER BUMPER	TATA spare parts
257631200106	ENG CROSS MEMBER FRONT	TATA spare parts
257631200107	ENG CROSS MEMBER REAR	TATA spare parts
257631200108	END CROSS MEMBER	TATA spare parts
257631207105	CROSS MEMBER	TATA spare parts
257631207113	CROSS MEMBER ENGINE MTG FRONT	TATA spare parts
257631207114	OUTER PIECE FRT	TATA spare parts
257631207118	SUPPORT ENG CR MEMBER RR	TATA spare parts
257631207119	END CROSS MEMBER	TATA spare parts
257631207120	SUPPORT ENG CR MEMBER FR	TATA spare parts

257631207123	CROSS MEMBER RR SPRING	TATA spare parts
257631207128	END CROSS MEMBER	TATA spare parts
257631208211	PACKING PLATE 3MM	TATA spare parts
257631208212	PACKING PLATE 1.5MM	TATA spare parts
257631208218	PACKING PLATE 3THK	TATA spare parts
257631208219	PACKING PLATE 1.5MM	TATA spare parts
257631307107	CROSS MEMBER RR SPRING	TATA spare parts
257631307125	REINFORCEMENT PLATE	TATA spare parts
257631307126	REINFORCEMENT RH	TATA spare parts
257631307127	REINFORCEMENT LH	TATA spare parts
257631307128	SUPPORT TOP RH 4TH X MEMBER LPT2515TC	TATA spare parts
257631307129	SUPPORT TOP LH 4TH X MEMBER LPT2515TC	TATA spare parts
257631307130	SUPPORT BOTTOM	TATA spare parts
257631307134	REINFORCEMENT RH	TATA spare parts
257631307135	REINFORCEMENT LH	TATA spare parts
257631307136	REINFORCEMENT	TATA spare parts
257631307137	REINFORCEMENT FRONT SPRING BRACKET FRONT	TATA spare parts
257631307138	SUPPORT TOP	TATA spare parts
257631307603	REINFORCEMENT-RH	TATA spare parts
257631307604	REINFORCEMENT LH SIDE	TATA spare parts
257631307605	REINFORCEMENT-RH-INNER	TATA spare parts
257631307606	REINFORCEMENT INNER LH SIDE	TATA spare parts
257631308222	GUSSET PLATE BOTTOM R H	TATA spare parts
257631308223	GUSSET PLATE BOTTOM L H	TATA spare parts
257631308224	GUSSET PLATE	TATA spare parts
257631308225	GUSSET PLATE	TATA spare parts
257631506701	COUPLING PIN	TATA spare parts
257631600116	ASSY SUBSTRUCTURE COMPLETE	TATA spare parts
257631600121	ASSY RAMP COMPLETE	TATA spare parts
257632100104	FRONT SPRING ASSY	TATA spare parts
257632100105	SPRING SHACKLE FRT SPRING BS1/2/3/4/6	TATA spare parts
257632100106	ASSY SPR.FRT.12LEAF 1516	TATA spare parts
257632100107	LEAF SPRING 1ST W/BUSH	TATA spare parts
257632100110	FRONT SPRING ASSY	TATA spare parts
257632100112	FRONT SPRING HIGH CAMBER	TATA spare parts
257632100113	ASSY.FIRST LEAF W/BUSH	TATA spare parts
257632103203	CENTRE BOLT	TATA spare parts
257632103205	CENTRE PIN	TATA spare parts
257632103304	BKT FRONT SPRING	TATA spare parts
257632103401	BUSH	TATA spare parts
257632103401DF	BUSH-FRONT SPRING-BI METALLIC-1618/2518/	TATA spare parts
257632103701	SPRING SHACKLE	TATA spare parts
257632104204	SPRING CLAMP	TATA spare parts
257632104205	SPRING CLAMP	TATA spare parts
257632104210	SPRING CLIP BS6	TATA spare parts
257632104211	SPRING CLIP	TATA spare parts
257632106701	SPRING PIN	TATA spare parts

257632106702	SPRING PIN	TATA spare parts
257632107134	LEAF SPRING 2ND FRT	TATA spare parts
257632107135	LEAF SPRING 3RD FRT	TATA spare parts
257632107136	LEAF SPRING 4TH FRT	TATA spare parts
257632107137	LEAF SPRING 5TH FRT	TATA spare parts
257632107138	LEAF SPRING 6TH FRT	TATA spare parts
257632107139	LEAF SPRING 7TH FRT	TATA spare parts
257632107140	EIGHT LEAF	TATA spare parts
257632107141	NINTH LEAF	TATA spare parts
257632107142	LEAF SPRING 10TH FRT	TATA spare parts
257632107143	3RD.LEAF FRT.1516-0106	TATA spare parts
257632107146	LEAF SPRING 6TH	TATA spare parts
257632107150	LEAF SPRING 10TH FRT	TATA spare parts
257632107155	LEAF SPRING 3RD FRT	TATA spare parts
257632107157	LEAF SPRING 5TH FRT	TATA spare parts
257632107158	LEAF SPRING 6TH FRT	TATA spare parts
257632107159	LEAF SPRING 7TH FRT	TATA spare parts
257632107160	LEAF SPRING 8TH FRT	TATA spare parts
257632107161	LEAF SPRING 9TH FRT	TATA spare parts
257632107162	LEAF SPRING 10TH FRT	TATA spare parts
257632107163	LEAF SPRING 11TH FRT	TATA spare parts
257632107164	LEAF SPRING 12TH FRT	TATA spare parts
257632107166	2ND LEAF 1313	TATA spare parts
257632107167	THIRD LEAF	TATA spare parts
257632107168	FOURTH LEAF	TATA spare parts
257632107169	FIFTH LEAF	TATA spare parts
257632107170	SIXTH LEAF	TATA spare parts
257632107171	SEVENTH LEAF	TATA spare parts
257632107172	EIGHTH LEAF	TATA spare parts
257632107173	NINETH LEAF	TATA spare parts
257632107174	TENTH LEAF	TATA spare parts
257632203701	GUIDE PLATE	TATA spare parts
257632204201	U CLAMP	TATA spare parts
257632204202	U CLAMP FRONT	TATA spare parts
257632204206	U CLAMP	TATA spare parts
257632204207	U CLAMP FRONT	TATA spare parts
257632204208	U CLAMP FRONT	TATA spare parts
257632204210	U CLAMP	TATA spare parts
257632204211	U CLAMP	TATA spare parts
257632207701	RUBBER BUFFER	TATA spare parts
257632300108	BKT S/ABS LH	TATA spare parts
257632300109	BKT S/ABS RH	TATA spare parts
257632300110	SHOCK ABSORBER FRONT BS1/2/3/4	TATA spare parts
257632300113	BKT S/ABS FRONT	TATA spare parts
257632303308	BKT S/ABS LOWER	TATA spare parts
257632303311	BKT S/ABS	TATA spare parts
257632303401	STEEL BUSH S/ABS FRT	TATA spare parts

257632307501	BUSH FRT S/ABS	TATA spare parts
257632308201	LOCK SHEET	TATA spare parts
257632308604	SPACER	TATA spare parts
257632309201	WASHER	TATA spare parts
257632400105	FRONT SPRING SHACKLE 1516	TATA spare parts
257632400106	REAR SPRING ASSY W/AUX	TATA spare parts
257632400107	SPRING SHACKLE RR	TATA spare parts
257632400108	ASSY REAR SPRING WITH AUX SPRING	TATA spare parts
257632400109	LEAF SPRING 1ST W/BUSH RR	TATA spare parts
257632400110	REAR SPRING ASSY W/O AUX	TATA spare parts
257632400111	AUXILLARY SPRING ASSY	TATA spare parts
257632400117	ASSY REAR SPRING WITH AUX SPRING	TATA spare parts
257632403205	CENTRE BOLT	TATA spare parts
257632403309	HELPER SPRING BRACKET CAST VERSION	TATA spare parts
257632403310	HELPER SPRING BRACKET FORGE VERSION	TATA spare parts
257632403311	BKT FRT REAR SPRING	TATA spare parts
257632403401	BUSH	TATA spare parts
257632403401DF	BUSH-REAR SPRING	TATA spare parts
257632403702	CAST SUPPORT (BETWEEN MAIN & AUX.PACK)	TATA spare parts
257632406701	SPRING PIN REAR	TATA spare parts
257632407134	LEAF SPRING 3RD RR	TATA spare parts
257632407135	LEAF SPRING 4TH RR	TATA spare parts
257632407136	LEAF SPRING 5TH RR	TATA spare parts
257632407137	LEAF SPRING 6TH RR	TATA spare parts
257632407148	LEAF SPRING 2ND RR	TATA spare parts
257632407149	LEAF SPRING AUX 1ST	TATA spare parts
257632407150	LEAF SPRING 2ND AUX	TATA spare parts
257632407151	LEAF SPRING 3RD AUX	TATA spare parts
257632407152	LEAF SPRING 4TH AUX	TATA spare parts
257632408602	SPACER	TATA spare parts
257632408603	SPACER	TATA spare parts
257632503701	GUIDE PLATE RR CAST	TATA spare parts
257632504202	U CLAMP	TATA spare parts
257632505101	GUIDE PLATE	TATA spare parts
257632509201	WASHER SPHERICAL	TATA spare parts
257632509201AE	SPHERICAL WASHER -1415	TATA spare parts
257632600104	SHOCK ABSORBER REAR	TATA spare parts
257632600107	SHOCK ABSORBER REAR	TATA spare parts
257632603401	BUSH RR S/ABS	TATA spare parts
257632607501	BUSH RR S/ABS	TATA spare parts
257632608002	PIN MOUNTING	TATA spare parts
257632608003	PIN MOUNTING	TATA spare parts
257632608004	PIN MOUNTING	TATA spare parts
257632608005	PIN MOUNTING	TATA spare parts
257632800112	CONNECTING ROD	TATA spare parts
257632800131	SUB ASSY. FRONT ANTIROLL BAR BS1/2/3/4	TATA spare parts
257632800132	ASSY ANTI ROLL BAR BS6	TATA spare parts

257632803307	BRACKET	TATA spare parts
257632803311	BRACKET RH	TATA spare parts
257632803312	BRACKET LH	TATA spare parts
257632803402	BUSH HALF BOTTOM	TATA spare parts
257632803403	BUSH HALF TOP	TATA spare parts
257632805104	EYE PIECE ANTIROLLBAR	TATA spare parts
257632805105	EYE PIECE	TATA spare parts
257632806703	PIN MOUNTING	TATA spare parts
257632807103	CLAMP	TATA spare parts
257632807501	RUBBER BUSH BS1/2/3/4/6	TATA spare parts
257632807502	RUBBER BUSH	TATA spare parts
257632807906	ANTI ROLL BAR	TATA spare parts
257632807908	ANTIROLL BAR FORGED VERSION	TATA spare parts
257632808202	SHIM	TATA spare parts
257632808302	SHIM	TATA spare parts
257632808303	SHIM	TATA spare parts
257632808304	SHIM	TATA spare parts
257632808306	SHIM	TATA spare parts
257632808307	SHIM	TATA spare parts
257632808308	SHIM	TATA spare parts
257632808401	SLEEVE	TATA spare parts
257632808402	SLEEVE	TATA spare parts
257633000106	ASSY FRONT AXLE RHD	TATA spare parts
257633105110	FRONT AXLE BEAM STD BS1/2/3/4	TATA spare parts
257633109901	GREASE NIPPLE L TYPE	TATA spare parts
257633200113	STUB AXLE STD	TATA spare parts
257633200117	REP KIT KING PIN STD	TATA spare parts
257633200118	REP KIT KING PIN RS1	TATA spare parts
257633200120	REP KIT-KING PIN STD	TATA spare parts
257633200121	REP KIT KING PIN RS1	TATA spare parts
257633200122	REP KIT KING PIN RS2	TATA spare parts
257633200123	REP KIT KING PIN RS2	TATA spare parts
257633203103	KING PIN THRUST BRG STD	TATA spare parts
257633203109	KING PIN THRUST BRG STD	TATA spare parts
257633203110	KING PIN THRUST BRG STD1	TATA spare parts
257633203111	KING PIN THRUST BRG RS1	TATA spare parts
257633203115	KING PIN THRUST BRG STD	TATA spare parts
257633203120	KING PIN THRUST BRG STD	TATA spare parts
257633203121	KING PIN THRUST BRG STD1	TATA spare parts
257633203122	KING PIN THRUST BRG	TATA spare parts
257633203123	KING PIN THRUST BRG	TATA spare parts
257633203402	BUSH KING PIN	TATA spare parts
257633206703	KING PIN STD	TATA spare parts
257633206705	KING PIN	TATA spare parts
257633206706	KING PIN REP	TATA spare parts
257633206707	COTTER PIN	TATA spare parts
257633206709	KING PIN STD BS1/2/3/4	TATA spare parts

257633206710	KING PIN STD1	TATA spare parts
257633206711	KING PIN RS1	TATA spare parts
257633206712	KING PIN (REPAIR-II)	TATA spare parts
257633206714	COTTER PIN	TATA spare parts
257633207201	PLUG STUB AXLE TOP	TATA spare parts
257633207701	RUBBER BUFFER	TATA spare parts
257633207702	GASKET RING	TATA spare parts
257633208202	SEALING CAP STUB AXLE	TATA spare parts
257633208601	SPACER LH	TATA spare parts
257633208602	SPACER RH	TATA spare parts
257633209212	THRUST WASHER	TATA spare parts
257633209213	THRUST WASHER 0.8MM THK	TATA spare parts
257633209214	THRUST WASHER 0.9MM THK	TATA spare parts
257633209215	THRUST WASHER 1.0MM THK	TATA spare parts
257633209216	THRUST WASHER 1.1MM THK	TATA spare parts
257633209217	THRUST WASHER 1.2MM THK	TATA spare parts
257633209218	THRUST WASHER 1.3MM THK	TATA spare parts
257633209219	THRUST WASHER 1.4MM THK	TATA spare parts
257633209220	THRUST WASHER 1.5MM THK	TATA spare parts
257633209221	THRUST WASHER 1.6MM THK	TATA spare parts
257633209222	THRUST WASHER 1.7MM THK	TATA spare parts
257633400103	HUB FRONT W/BEARINGS	TATA spare parts
257633403101	TAPER ROLLER BRG. 565/562 BS1/2/3/4	TATA spare parts
257633403103	TAPER ROLLER BRG. 32308 BS1/2/3/4	TATA spare parts
257633403104	BRG TAPER ROLLER	TATA spare parts
257633403105	BEARING TAPER ROLLER	TATA spare parts
257633403106	BEARING TAPER ROLLER	TATA spare parts
257633403107	BEARING TAPER ROLLER	TATA spare parts
257633403108	BEARING TAPER ROLLER	TATA spare parts
257633403109	TAPER ROLLER BEARING	TATA spare parts
257633403110	TAPER ROLLER BEARING	TATA spare parts
257633403701	FRONT HUB COVER	TATA spare parts
257633403702	FRONT HUB COVER	TATA spare parts
257633405503	HUB FRONT W/O BEARINGS	TATA spare parts
257633407801	OIL SEAL FRONT HUB BS1/2/3/4	TATA spare parts
257633407801DF	OIL SEAL-FRONT HUB-6T FA-1618/2518/3118	TATA spare parts
257633408601	SPACER	TATA spare parts
257633409201	THRUST WASHER	TATA spare parts
257633800102	BALL JOINT	TATA spare parts
257633800103	TIE ROD ASSY	TATA spare parts
257633800105	ASSLY TIE ROD	TATA spare parts
257633800106	ASSLY TIE ROD	TATA spare parts
257633805104	STEERING ARM LH BS1/2/3/4	TATA spare parts
257633805106	STEERING ARM RH BS1/2/3/4	TATA spare parts
257633805107	STEERING ARM (TOP) BS1/2/3/4	TATA spare parts
257633805108	STEERING ARM TOP LHD	TATA spare parts
257633805109	STEERING ARM	TATA spare parts

257635000101	REAR AXLE RA109 W/O DLOCK	TATA spare parts
257635000119	ASSY RA-109 WITH BR W/O DIFF LOCK 48/7	TATA spare parts
257635000144	ASSY RA 109 COMP 1613/2515 SK HD W48/7	TATA spare parts
257635000147	ASY R A 109 COM (SCAM) BRK 41/7	TATA spare parts
257635000149	REAR AXLE RA 109-2516	TATA spare parts
257635000153	ASSY RA-109 WITH BR W/O DIFF LOCK 48/7	TATA spare parts
257635100126	REAR AXLE BEAM BANJO	TATA spare parts
257635100157	REAR AXLE BEAM BANJO	TATA spare parts
257635100175	R/AXLE BEAM 2416 SCAM BANJO	TATA spare parts
257635100178	ASSY COVER (REAR AXLE HOUSING)	TATA spare parts
257635100196	REAR AXLE BEAM RA109 BANJO	TATA spare parts
257635100204	R/AXLE BEAM RA109 NEW BANJO	TATA spare parts
257635105102	SPRING SADDLE TOP	TATA spare parts
257635105302	GASKET DIFF COVER	TATA spare parts
257635107133	REINF.PLATE-FRONT COILED	TATA spare parts
257635107134	REINF.PLATE-REAR COILED	TATA spare parts
257635108201	SLINGER	TATA spare parts
257635108203	COVER	TATA spare parts
257635108601	PRESSURE RING	TATA spare parts
257635108604	PRESSURE RING	TATA spare parts
257635109901	SUPPORT BLOCK	TATA spare parts
257635110101	CARRIER ASSY 6.857R RA109	TATA spare parts
257635110105	ASSY CARRIER 6.857 RATIO	TATA spare parts
257635110108	CARRIER HOUSING	TATA spare parts
257635110109	ASSY CARRIER 41/7	TATA spare parts
257635113201	BOLT PLUMMER BLOCK COVER	TATA spare parts
257635115302	GASKET CARRIER RA109 BS1/2/3/4	TATA spare parts
257635300104	HOUSING DIFFERENTIAL	TATA spare parts
257635300105	PIN ADJUSTING	TATA spare parts
257635300106	CWP SET 48/7 OLD	TATA spare parts
257635300109	THREADED RING	TATA spare parts
257635300110	COUPLING FLANGE RR AXLE	TATA spare parts
257635300120	DIFFERENTIAL GEAR KIT	TATA spare parts
257635300126	CWP SET 48/7(433MM) RA109 OERL	TATA spare parts
257635300127	HOUSING DIFFERENTIAL	TATA spare parts
257635300128	HOUSING DIFFERENTIAL	TATA spare parts
257635300130	DIFFL ASSY W/LOCK 48/7	TATA spare parts
257635300133	CWP SET 41/7(433MM) RA109	TATA spare parts
257635300147	ASSY. DIFFERENTIAL 41/7	TATA spare parts
257635303101	BEARING TAPER ROLLER	TATA spare parts
257635303102	TAPER ROLLER BRG 77213 BS1/2/3/4	TATA spare parts
257635303104	CYL. ROLLER BRG NS1909 RA 109RR BS1-4	TATA spare parts
257635303105	BEARING TAPER ROLLER	TATA spare parts
257635303106	BEARING TAPER ROLLER	TATA spare parts
257635303107	TAIL PINION BEARING-RA109RR	TATA spare parts
257635303108	TAPER ROLLER BRG	TATA spare parts
257635303109	TAPER ROLLER BRG	TATA spare parts

257635303110	TAIL PINION BEARING-RA109RR	TATA spare parts
257635303112	TAPER ROLLER BRG 32020	TATA spare parts
257635305001	COUPLING FLANGE	TATA spare parts
257635305009	COUPLING FLANGE-150 DIA	TATA spare parts
257635305103	DIFFERENTIAL SPIDER	TATA spare parts
257635305404	GEAR REAR AXLE SHAFT	TATA spare parts
257635305405	BEVEL GEAR	TATA spare parts
257635305406	PINION - CWP:48/7-0126OR	TATA spare parts
257635306104	LOCK PLATE CROWN WHEEL	TATA spare parts
257635306105	LOCK PLATE DIFFL ASSY	TATA spare parts
257635306106	LOCK PLATE	TATA spare parts
257635306501	THREADED RING BS1/2/3/4/6	TATA spare parts
257635306503	THREADED RING	TATA spare parts
257635308003	PIN ADJUSTING	TATA spare parts
257635308004	HEX SCREW CROWN WHEEL	TATA spare parts
257635308005	HEX SCREW	TATA spare parts
257635308201	LOCK PLATE	TATA spare parts
257635308302	SHIM 0.15 MM	TATA spare parts
257635308303	SHIM 0.20 MM	TATA spare parts
257635308304	SHIM 0.25 MM	TATA spare parts
257635308305	SHIM 0.30 MM	TATA spare parts
257635308306	SHIM 0.50 MM	TATA spare parts
257635308307	SHIM 1.00 MM	TATA spare parts
257635308308	SHIM 0.10 MM	TATA spare parts
257635308601	SPACER RING	TATA spare parts
257635308602	SPACER RING	TATA spare parts
257635308604	SPACER RING 7.74 MM THICK	TATA spare parts
257635308605	SPACER RING 7.72 MM THICK	TATA spare parts
257635308606	SPACER RING 7.70 MM	TATA spare parts
257635308607	SPACER RING 7.68 MM	TATA spare parts
257635308608	SPACER RING 7.66 MM	TATA spare parts
257635308609	SPACER RING 7.64 MM	TATA spare parts
257635308610	SPACER RING 7.62 MM	TATA spare parts
257635308611	SPACER RING 7.60 MM	TATA spare parts
257635308612	SPACER RING 7.58 MM	TATA spare parts
257635308613	SPACER RING 7.56 MM	TATA spare parts
257635308614	SPACER RING 7.54 MM	TATA spare parts
257635308615	SPACER RING 7.52 MM	TATA spare parts
257635308616	SPACER RING 7.50 MM	TATA spare parts
257635308617	SPACER RING 7.48 MM	TATA spare parts
257635308618	SPACER RING 7.46 MM	TATA spare parts
257635308619	SPACER RING 7.44 MM	TATA spare parts
257635308620	SPACER RING 7.42 MM	TATA spare parts
257635308621	SPACER RING 7.40 THICK	TATA spare parts
257635308622	SPACER RING 7.38 MM	TATA spare parts
257635308623	SPACER RING 7.76 MM	TATA spare parts
257635308645	SPACER PINION	TATA spare parts



257635309202	THRUST WASHER 1.95 MM	TATA spare parts
257635309203	THRUST WASHER 2.05 MM	TATA spare parts
257635309204	THRUST WASHER 2.10 MM	TATA spare parts
257635309205	THRUST WASHER 2.15 MM	TATA spare parts
257635309206	THRUST WASHER 2.20 MM	TATA spare parts
257635309207	THRUST WASHER 2.25 MM	TATA spare parts
257635309208	SPHERICAL WASHER	TATA spare parts
257635309209	THRUST WASHER 2.00 MM	TATA spare parts
257635309901	SLIDER	TATA spare parts
257635309902	LOCKING WIRE INNER RACE	TATA spare parts
257635309903	LOCKING WIRE OUTER RACE	TATA spare parts
257635600101	REAR HUB RA109 W/BEARING	TATA spare parts
257635600102	REAR HUB RA109 W/O BRG	TATA spare parts
257635600112	ASSY HUB RR(SPIG)LPS3516	TATA spare parts
257635603101	TAPER ROLLER BRG. 33019 BS1/2/3/4	TATA spare parts
257635603101AE	TAPER ROLLER BEARING -1628	TATA spare parts
257635603102	TAPER ROLLER BRG 33215L	TATA spare parts
257635603103	BEARING TAPER ROLLER	TATA spare parts
257635603104	BEARING TAPER ROLLER	TATA spare parts
257635603106	BEARING TAPER ROLLER	TATA spare parts
257635603107	BEARING TAPER ROLLER	TATA spare parts
257635603108	TAPER ROLLER BRG. 75X130X41	TATA spare parts
257635604701	COVER REAR HUB	TATA spare parts
257635605301	GASKET HUB BS1/2/3/4	TATA spare parts
257635606502	LOCKING RING	TATA spare parts
257635607701	OIL SEAL RR HUB 1612	TATA spare parts
257635608201	OIL CATCHER	TATA spare parts
257635608202	LOCKING WASHER	TATA spare parts
257635608301	SHIM 0.05 MM BRG PLAY ADJ	TATA spare parts
257635608302	SHIM 0.1 MM BRG PLAY ADJ	TATA spare parts
257635608303	SHIM 0.15 MM BRG PLAY ADJ	TATA spare parts
257635608304	SHIM 0.20 MM BRG PLAY ADJ	TATA spare parts
257635608305	SHIM 0.25 MM BRG PLAY ADJ	TATA spare parts
257635608306	SHIM 0.30 MM BRG PLAY ADJ	TATA spare parts
257635608307	SHIM 0.50 MM BRG PLAY ADJ	TATA spare parts
257635608308	SHIM 1.00 MM BRG PLAY ADJ	TATA spare parts
257635608309	SHIM 1.50 MM BRG PLAY ADJ	TATA spare parts
257635608310	SHIM 2.50 MM BRG PLAY ADJ	TATA spare parts
257635608601	SPACER	TATA spare parts
257635608602	SPACER	TATA spare parts
257635608603	SPACER	TATA spare parts
257635608609	SPACER TUBE BRG PLAY ADJ.	TATA spare parts
257635707904	AXLE SHAFT	TATA spare parts
257635707905	REAR AXLE SHAFT	TATA spare parts
257635900101	SHIFT CYLINDER DIFF LOCK	TATA spare parts
257635900102	HOSE ASSY	TATA spare parts
257635900105	CONTROL VALVE DIFFL LOCK	TATA spare parts

257635900105AE	LEVER TYPE CONTROL VALVE 715	TATA spare parts
257635900122	ASSY SHIFT CYLINDER(SHORTER)	TATA spare parts
257635905101	FORK DIFFERENTIAL LOCK	TATA spare parts
257635905301	GASKET SHIFT CYLINDER	TATA spare parts
257635905301AE	GSKT (SHIFT CYL&RR COVER) -715	TATA spare parts
257635905401	ENGAGING SLEEVE	TATA spare parts
257635908205	SAFETY PLATE FOR DIFF LOCK LEVER	TATA spare parts
257640100107	WHEEL DISC & RIM 8.00X20	TATA spare parts
257640100116	ASSY.WHEEL DISC & RIM	TATA spare parts
257640106308	TYRE 10X20 16PR	TATA spare parts
257640106501	WHEEL NUT	TATA spare parts
257640106701	HUB BOLT	TATA spare parts
257640109902	FLAP	TATA spare parts
257640109903	TUBE	TATA spare parts
257640109904	FLAP	TATA spare parts
257640109905	TUBE	TATA spare parts
257640109908	FLAP	TATA spare parts
257640109909	TUBE	TATA spare parts
257640109910	FLAP ASSY	TATA spare parts
257640109914	TYRE,RIB TYPE 10X20 16 PR	TATA spare parts
257640109915	TYRE 10X20 16PR	TATA spare parts
257640206302	TYRE 10X20 16PR	TATA spare parts
257640206701	HUB BOLT REAR	TATA spare parts
257640209201	SPHERICAL RING	TATA spare parts
257640209901	TUBE	TATA spare parts
257640209902	TYRE 10X20 16PR	TATA spare parts
257640209903	TYRE,LUG TYPE 10X20 16PR	TATA spare parts
257640209904	TYRE 10X20 16PR	TATA spare parts
257640300109	ASSY HOLDING BRACKET BS6	TATA spare parts
257640300111	SPARE WHEEL CARRIER	TATA spare parts
257640307108	RATCHET WHEEL	TATA spare parts
257640307109	RATCHET ARM	TATA spare parts
257641108001	SCREW	TATA spare parts
257641108002	SCREW	TATA spare parts
257641109901	ADAPTER	TATA spare parts
257641110131	BEARING CUP	TATA spare parts
257641110137	PROP. SHAFT W/DUST CAP	TATA spare parts
257641110139	PROP SHAFT FR 90X3X422	TATA spare parts
257641110140	PROP SHAFT FR 90X3X1375	TATA spare parts
257641110141	UNIVERSAL JOINT CROSS 90D	TATA spare parts
257641110158	PROP SHAFT FRONT	TATA spare parts
257641110160	PROP SHAFT FR 90X3X1354	TATA spare parts
257641113102	BEARING CUP	TATA spare parts
257641113201	BOLT BS1/2/3/4	TATA spare parts
257641114309	SPRING RING 2.975 MM	TATA spare parts
257641114310	SPRING RING 3.000 MM	TATA spare parts
257641114311	SPRING RING 3.025 MM	TATA spare parts

257641114312	SPRING RING 3.050 MM	TATA spare parts
257641114313	SPRING RING 3.075 MM	TATA spare parts
257641114314	SPRING RING 3.100 MM	TATA spare parts
257641114315	SPRING RING 2.900 MM	TATA spare parts
257641114316	SPRING RING 2.925	TATA spare parts
257641114317	SPRING RING 2.950 MM	TATA spare parts
257641114318	SPRING RING 3.125	TATA spare parts
257641114319	SPRING RING 3.150	TATA spare parts
257641114320	SPRING RING 3.175 MM	TATA spare parts
257641115105	COUPLING FLANGE	TATA spare parts
257641115108	CROSS ASSY	TATA spare parts
257641115109	UNIVERSAL JOINT SHORT FORK	TATA spare parts
257641115110	FLANGE YOKE BS1/2/3/4	TATA spare parts
257641116101	LOCKING PLATE	TATA spare parts
257641117702	RUBBER SEAL	TATA spare parts
257641118203	END RING	TATA spare parts
257641118204	SEAL COVER	TATA spare parts
257641120106	RUBBER BOOT	TATA spare parts
257641120120	ASSY. UNIVERSAL JOINT LONG FORK BS2	TATA spare parts
257641120121	UNIVERSAL JOINT FORK LONG BS1/2/3/4	TATA spare parts
257641120122	PROP SHAFT RR 90X3X1240	TATA spare parts
257641120123	PROP SHAFT RR 90X3X600	TATA spare parts
257641120128	ASSY PROP SHAFT	TATA spare parts
257641120139	ASSY PROP SHAFT REAR COMPLETE LPS3015TC	TATA spare parts
257641120142	PROP SHAFT RR 90X3X593	TATA spare parts
257641120145	ASSY. PROP.SHAFT COMPLETE LPK2516TC	TATA spare parts
257641125101	END PIECE RR P/SHAFT 90X3 BS2/3	TATA spare parts
257641127501	RUBBER BOOT 90D	TATA spare parts
257641128201	SEAL RING RETAINER	TATA spare parts
257641129901	SEALING RING	TATA spare parts
257641129902	WIRE RING	TATA spare parts
257641300101	BKT CENTRE BEARING	TATA spare parts
257641303101	CENTRE BEARING 90D	TATA spare parts
257641303301	BKT CENTRE BEARING	TATA spare parts
257641303304	BKT CENTRE BEARING	TATA spare parts
257641303308	BKT CENTRE BEARING	TATA spare parts
257641303401	BUSH	TATA spare parts
257641304201	CLAMP	TATA spare parts
257641304301	SNAP RING	TATA spare parts
257641306301	RUBBER CENTRE BEARING 90D BS1/2/3	TATA spare parts
257641307101	SPACER PLATE	TATA spare parts
257641307801	PROTECTIVE CAP	TATA spare parts
257641308201	PROTECTIVE CAP	TATA spare parts
257642100114	ADJUSTER ECCENTRIC	TATA spare parts
257642103202	BOLT	TATA spare parts
257642103203	BOLT	TATA spare parts
257642103705	BRAKE DRUM	TATA spare parts

257642103708	BRAKE DRUM 1516 SCAM	TATA spare parts
257642105102	ADJUSTER ECCENTRIC	TATA spare parts
257642106002	LINK BRAKE SHOE	TATA spare parts
257642106501	SLOTTED NUT	TATA spare parts
257642106502	SLOTTED NUT M16X1.5 10.9	TATA spare parts
257642106503	CASTLE NUT BRAKE M16X1.5 10.9	TATA spare parts
257642106710	PIVOT PIN	TATA spare parts
257642106713	PIN	TATA spare parts
257642106714	SPRING PIN	TATA spare parts
257642106716	PIN	TATA spare parts
257642107104	LOCK PLATE	TATA spare parts
257642108005	COLLARED PIN	TATA spare parts
257642108006	COLLARED PIN M16X1.5X174	TATA spare parts
257642108203	HEAT SHIELD WHEEL CYL	TATA spare parts
257642108205	LOCK PLATE	TATA spare parts
257642108207	OIL BAFFALE	TATA spare parts
257642108208	HEAT SHIELD	TATA spare parts
257642108702	RETURN SPRING REAR	TATA spare parts
257642108703	RETURN SPRING FRONT	TATA spare parts
257642108704	RETURN SPRING FRONT	TATA spare parts
257642108706	RETURN SPRING SHORT	TATA spare parts
257642108707	RETURN SPRING FRONT	TATA spare parts
257642110111	ANCHOR PLATE RH FRONT	TATA spare parts
257642120102	WHEEL CYL.50.80D	TATA spare parts
257642120103	WHEEL CYL.50.80D	TATA spare parts
257642120105	REP KIT WHEEL CYLINDER	TATA spare parts
257642120108	WHEEL CYL.50.80D	TATA spare parts
257642120109	WHEEL CYL.50.80D	TATA spare parts
257642128201	SHIELD COVER	TATA spare parts
257642130112	BR SHOE W/LIN FRT	TATA spare parts
257642136307	BRAKE LINING	TATA spare parts
257642136308	BRAKE LINING	TATA spare parts
257642136314	BRAKE LINING STD	TATA spare parts
257642300115	WASHER	TATA spare parts
257642300122	ASSY BRACKET RH	TATA spare parts
257642300123	SLACK ADJ REAR LH	TATA spare parts
257642300124	SLACK ADJ REAR RH	TATA spare parts
257642300127	SLACK ADJUSTER LH	TATA spare parts
257642300128	SLACK ADJUSTER RH	TATA spare parts
257642300129	SLACK ADJUSTER LH	TATA spare parts
257642300130	SLACK ADJUSTER RH	TATA spare parts
257642300132	SLACK ADJUSTER RH	TATA spare parts
257642300133	SLACK ADJUSTER LH	TATA spare parts
257642300136	ASSY.SLACK ADJUSTER LH 43 MM OFFSET	TATA spare parts
257642300137	ASSY.SLACK ADJUSTER RH 43 MM OFFSET	TATA spare parts
257642300157	ASSY HANDLE LH W/O LOCK	TATA spare parts
257642303201	BOLT	TATA spare parts

257642303701	BEARING BLOCK	TATA spare parts
257642305105	ADJUSTING BLOCK RH	TATA spare parts
257642306005	BRAKE LEVER RH	TATA spare parts
257642306006	BRAKE LEVER LH	TATA spare parts
257642306704	PIN	TATA spare parts
257642306705	PIN ADJUSTING	TATA spare parts
257642306706	PIN ADJUSTING	TATA spare parts
257642306707	PIN	TATA spare parts
257642308602	SPACER FOR WINDOW REG.	TATA spare parts
257642308608	SPACER	TATA spare parts
257642308701	RETURN SPRING LONG	TATA spare parts
257642308702	RETURN SPRING REAR	TATA spare parts
257642310109	ANCHOR PLATE RH REAR	TATA spare parts
257642410101	ASSY SPRING BRAKE CHAMBER	TATA spare parts
257642700101	ASSY. BRACKET LH	TATA spare parts
257642700105	SUPPORT BRACKET	TATA spare parts
257642703401	BUSH	TATA spare parts
257642706701	PIN	TATA spare parts
257642808204	BRACKET	TATA spare parts
257642808206	BRACKET	TATA spare parts
257642810101	BRAKE TUBE	TATA spare parts
257642810102	BRAKE TUBE	TATA spare parts
257642810117	CONNECTING LINE RR BRAKE	TATA spare parts
257642810134	CONNECTING LINE RR BRAKE	TATA spare parts
257642900169	ASSY TUBE 12 MM OD	TATA spare parts
257642900171	ASSY TUBE 12 MM OD	TATA spare parts
257642900181	ASSY TUBE 12 MM OD	TATA spare parts
257642913301	BRACKET	TATA spare parts
257642913303	BRACKET	TATA spare parts
257642913304	BRACKET	TATA spare parts
257642913306	BRACKET	TATA spare parts
257642913307	BRACKET	TATA spare parts
257642914201	CLAMP	TATA spare parts
257642914202	CLAMP	TATA spare parts
257642914204	CLAMP	TATA spare parts
257642914205	BRACKET	TATA spare parts
257643100001	UNLOADER VALVE WITH TYRE	TATA spare parts
257643100103	UNLOADER VALVE	TATA spare parts
257643100125	TANDEM MASTER CYL 31.80D	TATA spare parts
257643100128	KIT REP UNLOADER VALVE	TATA spare parts
257643100134	UNLOADER VALVE	TATA spare parts
257643100135	UNLOADER VALVE	TATA spare parts
257643100137	ASSY UNLOADER VALVE	TATA spare parts
257643100139	UNLOADER VALVE	TATA spare parts
257643100140	ASSY.UNLODER VALVE	TATA spare parts
257643100141	UNLOADER V.ASSY.COMPL.M/S SUNARAM CLAYT	TATA spare parts
257643100142	UNLOADER VALVE ASSY COMPLETE	TATA spare parts

257643100143	UNLOADER VALVE	TATA spare parts
257643100228	REP.KIT.COMB.UN/VALVE SE	TATA spare parts
257643106802	ADAPTOR	TATA spare parts
257643108601	SPACER	TATA spare parts
257643108602	SPACER	TATA spare parts
257643108703	SPRING	TATA spare parts
257643109901	VALVE STOP SCREW	TATA spare parts
257643200112	AIR TANK	TATA spare parts
257643200113	SENSING TANK	TATA spare parts
257643200117	SUPPORT ASSY	TATA spare parts
257643200118	STRAP ASSY	TATA spare parts
257643200125	ASSY AIR TANK COMPL LH	TATA spare parts
257643200126	AIR TANK RH	TATA spare parts
257643206702	PIN	TATA spare parts
257643208226	BRACKET	TATA spare parts
257643208602	SPACER BLOCK	TATA spare parts
257643208606	SPACER BS6	TATA spare parts
257643208607	SPACER	TATA spare parts
257643500112	HOSE AIR PRESSURE	TATA spare parts
257643500113	TUBE ASSY	TATA spare parts
257643500128	TUBE ASSY	TATA spare parts
257643500143	ASSY TUBE	TATA spare parts
257643500144	SEALING RING	TATA spare parts
257643500145	SEALING RING	TATA spare parts
257643500149	TUBE ASSY	TATA spare parts
257643500168	TUBE ASSY	TATA spare parts
257643500174	TUBE ASSY	TATA spare parts
257643500176	TUBE ASSY	TATA spare parts
257643500177	TUBE ASSY	TATA spare parts
257643500178	TUBE ASSY	TATA spare parts
257643500183	TUBE ASSY	TATA spare parts
257643500185	TUBE ASSY	TATA spare parts
257643500188	TUBE ASSY	TATA spare parts
257643500190	TUBE ASSY	TATA spare parts
257643500196	TUBE ASSY	TATA spare parts
257643500197	TUBE ASSY	TATA spare parts
257643500198	TUBE ASSY	TATA spare parts
257643500199	TUBE ASSY	TATA spare parts
257643506801	ADAPTOR	TATA spare parts
257643506802	DOUBLE SOCKET	TATA spare parts
257643506803	ELBOW	TATA spare parts
257643506804	SOCKET	TATA spare parts
257643506805	SOCKET	TATA spare parts
257643506808	CONNECTOR PR TRANSDUCER	TATA spare parts
257643506810	TEE SOCKET	TATA spare parts
257643506816	ADAPTER	TATA spare parts
257643508210	BRACKET	TATA spare parts

257643509201	THRUST RING	TATA spare parts
257643509202	THRUST RING	TATA spare parts
257643510103	TUBE ASSY	TATA spare parts
257643510105	TUBE ASSY	TATA spare parts
257643520180	TUBE ASSY 12D	TATA spare parts
257643520182	ASSY TUBE	TATA spare parts
257643520194	ASSY TUBE	TATA spare parts
257643700101	UNLOADER VALVE W/HOLES	TATA spare parts
257643720129	AIR CYLINDER 150D	TATA spare parts
257643720130	AIR CYLINDER 150D	TATA spare parts
257643727701	PISTON SEAL	TATA spare parts
257643730115	DUEL TREADLE VALVE	TATA spare parts
257643730123	KIT REP D TREADLE VALVE	TATA spare parts
257643730134	KIT REP D TREADLE VALVE	TATA spare parts
257643730135	VENTING GUIDE ASSY	TATA spare parts
257643740104	SYSTEM PROTECTION VALVE	TATA spare parts
257643740108	SYSTEM PROTECTION VALVE	TATA spare parts
257643740110	KIT REP SYS PROT VALVE	TATA spare parts
257643740116	KIT REP SYS PROT VALVE	TATA spare parts
257643750112	HAND BRAKE VALVE RH	TATA spare parts
257643750123	KIT REP HAND BRAKE VALVE	TATA spare parts
257643760101	UNLOADER VALVE	TATA spare parts
257643760106	KIT REP UNLOADER VALVE	TATA spare parts
257643790101	TRAILER CONTROL VALVE	TATA spare parts
257643790102	PALM COUPLING SERVICE	TATA spare parts
257643790103	PALM COUPLING EMERGENCY	TATA spare parts
257643790108	NON RETURN VALVE	TATA spare parts
257643790110	COILED HOSE	TATA spare parts
257643790111	COILED HOSE	TATA spare parts
257643790112	COILED HOSE SET	TATA spare parts
257643790115	DRAIN VALVE AUTOMATIC	TATA spare parts
257643790118	TRAILER CONTROL VALVE	TATA spare parts
257643790133	KIT COUPLING	TATA spare parts
257643790135	KIT REP TRAILER CON VALVE	TATA spare parts
257643790137	KIT AUTO DRAIN VALVE	TATA spare parts
257643790144	TILT TYPE DRAIN VALVE SC M/S SCL	TATA spare parts
257643790145	DRAIN VALVE TILT TYPE	TATA spare parts
257643790159	WATER DRAIN VALVE TILT TYPE BS1/2/3/4	TATA spare parts
257643790167	DOUBLE CHECK VALVE	TATA spare parts
257643790169	KIT TRAILER CONTROL VALVE	TATA spare parts
257643790176	PALM COUPLING TRACTOR	TATA spare parts
257643790177	PALM COUPLING SUPPLY LINE	TATA spare parts
257643790178	TRAILER CONTROL VALVE	TATA spare parts
257643797708	O RING	TATA spare parts
257643797722	SEALING RING	TATA spare parts
257643798212	DUMMY COUPLING	TATA spare parts
257643798221	BRACKET	TATA spare parts

257646000105	DRAG LINK ASSY	TATA spare parts
257646000113	KIT REP DRAG LINK	TATA spare parts
257646000115	ASSY. DRAG LINK RHD BS1/2/3	TATA spare parts
257646000120	ASSY.DRAG LINK	TATA spare parts
257646000121	DRAG LINK ASSY	TATA spare parts
257646000122	ASSY.DRAG LINK LH LPK LHD	TATA spare parts
257646100118	SUPPORT STRG COLUMN	TATA spare parts
257646100130	BKT STRG G/B & CONTROL RH	TATA spare parts
257646100131	ASSY STG G B & CAB CONTROL MTG BKT LH	TATA spare parts
257646100132	ASSY. STG. GEAR BOX W/MTG BKT RH BS1/2/3	TATA spare parts
257646100133	ASSY.STG.COLUMN SUPPORT LHD	TATA spare parts
257646100134	ASSY.STG.COLUMN SUPPORT RHD	TATA spare parts
257646100135	SUPPORT STRG COLUMN	TATA spare parts
257646106304	RUBBER BELLOW	TATA spare parts
257646106703	PIN MOUNTING LONG	TATA spare parts
257646108206	CLAMPING RING	TATA spare parts
257646203401	NEEDLE BUSH	TATA spare parts
257646207903	STRG SPINDLE BOTTOM	TATA spare parts
257646207905	STRG SPINDLE TOP	TATA spare parts
257646207911	STRG. SPINDLE-BOTTOM	TATA spare parts
257646207913	STRG SPINDLE TOP	TATA spare parts
257646305105	PITMAN ARM	TATA spare parts
257646305106	PITMAN ARM	TATA spare parts
257646305107	PITMAN ARM	TATA spare parts
257646400101	STRG WHEEL 500 DIA	TATA spare parts
257646400102	STRG WHEEL	TATA spare parts
257646400103	ASSY STEERING WHEEL 500 DIA	TATA spare parts
257646400104	STRG WHEEL	TATA spare parts
257646400106	COVER STEERING WHEEL	TATA spare parts
257646800104	ASSY BENT TUBE	TATA spare parts
257646800105	ASSY BENT TUBE	TATA spare parts
257646800114	NIPPLE ASSY	TATA spare parts
257646805802	HOSE LP 3/4	TATA spare parts
257646805807	HOSE LP 3/4	TATA spare parts
257646806801	BANJO BODY	TATA spare parts
257646806802	BANJO BOLT	TATA spare parts
257646806803	ELBOW	TATA spare parts
257646806804	ADAPTER	TATA spare parts
257647100101	FUEL TANK	TATA spare parts
257647100102	FUEL TANK	TATA spare parts
257647100105	SUCTION TUBE	TATA spare parts
257647107201	PLUG	TATA spare parts
257647500108	STRAP	TATA spare parts
257647507101	REINFORCEMENT	TATA spare parts
257647507702	RUBBER PACKING	TATA spare parts
257647508601	SPACER BS6-PH2	TATA spare parts
257647508602	SPACER	TATA spare parts



257647508608	STIFFENER	TATA spare parts
257647600102	SUCTION TUBE	TATA spare parts
257647600120	FUEL FEED LINE	TATA spare parts
257647600122	FUEL RETURN LINE	TATA spare parts
257647610119	FUEL LINE	TATA spare parts
257649000103	ASSY BRACKET	TATA spare parts
257649000115	BRACKET	TATA spare parts
257649000116	CLAMP MASSOP	TATA spare parts
257649000117	BRACKET	TATA spare parts
257649006902	TUBE	TATA spare parts
257649007502	RUBBER BUFFER	TATA spare parts
257649007502AE	RUBBER BUFFER 1628	TATA spare parts
257649008203	BRACKET	TATA spare parts
257649008209	CLAMP.	TATA spare parts
257649009202	WASHER	TATA spare parts
257649100109	SILENCER ASSY 1516	TATA spare parts
257649100110	SILENCER MUFFLER	TATA spare parts
257649100117	SILENCER MUFFLER AL PAINT	TATA spare parts
257649200106	EXHAUST PIPE FRONT	TATA spare parts
257649200107	HEAT SHIELD	TATA spare parts
257649200108	EXHAUST PIPE FRT AL PAINT	TATA spare parts
257649205302	GASKET EXH PIPE FLANGE	TATA spare parts
257649206921	TAIL PIPE	TATA spare parts
257649206923	INTERMEDIATE PIPE 2	TATA spare parts
257649206924	INTERMEDIATE PIPE	TATA spare parts
257649206926	INTERMEDIATE PIPE 1	TATA spare parts
257649206927	INTERMEDIATE PIPE 2	TATA spare parts
257649206928	INTERMEDIATE PIPE 2	TATA spare parts
257649208204	PIPE CLAMP SE 1613TC	TATA spare parts
257649208205	CLAMP EXHAUST PIPE	TATA spare parts
257650000116	RADIATOR FRAME	TATA spare parts
257650000118	BRACKET LH RADIATOR MTG	TATA spare parts
257650000119	BRACKET RH RADIATOR MTG	TATA spare parts
257650005801	RUBBER HOSE	TATA spare parts
257650100123	RADIATOR ASSY	TATA spare parts
257650105804	RUBBER HOSE	TATA spare parts
257652200128	BKT LH WHEEL ARCH REAR	TATA spare parts
257652200129	BKT RH WHEEL ARCH REAR	TATA spare parts
257652200135	ASSY BRACKET LH.	TATA spare parts
257652200136	ASSY BRACKET RH.	TATA spare parts
257652200137	ASSY RR WHEEL ARCH LH	TATA spare parts
257652200138	ASSY RR WHEEL ARCH RH	TATA spare parts
257654100113	ASSY.BATT CABLE COMP -VE	TATA spare parts
257654100115	CABLE POSITIVE	TATA spare parts
257654100149	ASSY. ACID TRAY	TATA spare parts
257654100163	ASSY STUD	TATA spare parts
257654100175	BATTERY CABLE +VE	TATA spare parts

257654100176	BATTERY CABLE -VE	TATA spare parts
257654106710	PIN BS6	TATA spare parts
257654106712	PIN	TATA spare parts
257654207501	RUBBER SLEEVE	TATA spare parts
257654209901	TRANSDUCER OIL PRESSURE	TATA spare parts
257654209903	SPEEDOMETER 1:1.05	TATA spare parts
257654209904	VOLTMETER	TATA spare parts
257654209906	GAUGE AIR PRESSURE ELECT	TATA spare parts
257654209907	GAUGE OIL PRESSURE ELECT	TATA spare parts
257654209908	SPEEDOMETER 1:1.05 24V	TATA spare parts
257654209910	VOLTMETER	TATA spare parts
257654209915	GAUGE OIL PRESSURE ELECT	TATA spare parts
257654209923	SPEEDOMETER 1:0.95	TATA spare parts
257654209924	SPEEDOMETER 1:0.95 24V	TATA spare parts
257654209926	HORN 12V	TATA spare parts
257654209927	PRESSURE TRANSDUCER	TATA spare parts
257654209929	PRESSURE TRANSDUCER	TATA spare parts
257654209930	PRESSURE TRANSDUCER BS4	TATA spare parts
257654209930AE	PRESSURE TRANSDUCER 715	TATA spare parts
257654209931	OIL PRESSURE GAUGE ELECT	TATA spare parts
257654306301	INSTRUMENT PANEL	TATA spare parts
257654400101	HEAD LAMP LH LHD	TATA spare parts
257654400102	HEAD LAMP RH LHD	TATA spare parts
257654400103	HEAD LAMP LH RHD	TATA spare parts
257654400104	HEAD LAMP RH RHD	TATA spare parts
257654400105	BLINKER LAMP LH	TATA spare parts
257654400106	BLINKER LAMP RH	TATA spare parts
257654400107	BLINKER LAMP LH	TATA spare parts
257654400108	SIDE IND LAMP RH	TATA spare parts
257654400109	TOP MARKER LAMP LH	TATA spare parts
257654400110	TOP MARKER LAMP RH	TATA spare parts
257654400111	CAB LAMP ASSY	TATA spare parts
257654400112	LAMP BATTERY INDICATOR	TATA spare parts
257654400113	LAMP FAIL SAFE INDICATOR	TATA spare parts
257654400114	LAMP HAND BRAKE INDICATOR	TATA spare parts
257654400115	ASY.INDICATOR LAMP DIFF.LOCK	TATA spare parts
257654400115AE	ASSY INDCATR LAMP DIFF LOCK-713	TATA spare parts
257654400121	LAMP ENGINE INSPECTION	TATA spare parts
257654400131	SIDE IND LAMP LH	TATA spare parts
257654400132	SIDE IND LAMP RH	TATA spare parts
257654400133	TOP MARKER LAMP LH	TATA spare parts
257654400134	TOP MARKER LAMP RH	TATA spare parts
257654400135	ASSY.BLINKER LAMP LH.WITH BULB.12V.	TATA spare parts
257654400136	ASSY.BLINKER LAMP.RH WITH BULB.12V.	TATA spare parts
257654400137	SIDE IND LAMP LH	TATA spare parts
257654400138	SIDE IND LAMP RH	TATA spare parts
257654400139	ASSY.TOP MARKER LAMP LH WITH BULB 12V	TATA spare parts

257654400141	LAMP ENGINE INSPECTION	TATA spare parts
257654400145	ASY.T/MARK-12V LH`E`CERT W/`E`BULB-	TATA spare parts
257654409001	BLINKER GLASS LH	TATA spare parts
257654409002	BLINKER GLASS RH	TATA spare parts
257654409003	LENS SIDE IND LAMP	TATA spare parts
257654409004	LENS TOP MARKER LAMP	TATA spare parts
257654409201	LIGHT UNIT ILLUMINATION	TATA spare parts
257654409202	LIGHT UNIT RH	TATA spare parts
257654409909	LAMP HOLDER	TATA spare parts
257654500103	COMBI SWITCH	TATA spare parts
257654504601	FLASHER KIT	TATA spare parts
257654507505	RUBBER COVER	TATA spare parts
257654507506	RUBBER CAP	TATA spare parts
257654507507	COVER (FOR STOP LIGHT SW)	TATA spare parts
257654509901	LOW PRESSURE SWITCH	TATA spare parts
257654509902	PIANO SWITCH	TATA spare parts
257654509907	FLASHER KIT	TATA spare parts
257654509909	STOP LIGHT SWITCH BS1/2/3/4/6	TATA spare parts
257654509961	PNEUMATIC SWITCH EXH BR	TATA spare parts
257654600111	JUMPER CABLE	TATA spare parts
257654600133	MAIN CABLE SET RHD	TATA spare parts
257654600197	MAIN CABLE SET	TATA spare parts
257654609901	JUMPER CABLE	TATA spare parts
257654609924	JUMPER CABLE	TATA spare parts
257654609925	JUMPER CABLE	TATA spare parts
257654620107	MAIN CABLE SET DAOH	TATA spare parts
257654620108	CABLE SET INST PANEL DAOH	TATA spare parts
257654620116	CABLE SET CAB READ LAMP	TATA spare parts
257658300102	HYD JACK 12 TON WITH LOCK NUT	TATA spare parts
257658900112	WHEEL SPANNER	TATA spare parts
257658900201	SPANNER	TATA spare parts
257658900202	REAMER	TATA spare parts
257658900203	GO NO GO GAUGE	TATA spare parts
257658900204	ANGLE INDEXING TOOL	TATA spare parts
257658900205	CRANK LOCKING TOOL	TATA spare parts
257658900206	RING PISTON COMPRESSOR	TATA spare parts
257658900207	DRIFT	TATA spare parts
257658900208	PULLER	TATA spare parts
257658900209	PLIER-PISTON RING-AIR COMPRESSOR 70 DIA	TATA spare parts
257658900210	DRIFT	TATA spare parts
257658900211	SLEEVE	TATA spare parts
257658900219	TROLLEY AGG HANDLING	TATA spare parts
257658900220	TOOL 7TH MAIM BRG	TATA spare parts
257658900221	DRIFT EXH VALVE GUIDE REM	TATA spare parts
257658900222	ADAPTOR STAND	TATA spare parts
257658900223	DRIFT	TATA spare parts
257658900224	GUIDE BUSH	TATA spare parts

257658900225	GUIDE BUSH	TATA spare parts
257658902001	DRIFT	TATA spare parts
257658902501	SLEEVE	TATA spare parts
257658902502	MANDREL	TATA spare parts
257658902503	GUIDE SCREW RIVETTING	TATA spare parts
257658902504	FIXURE 350 DIA CLUTCH	TATA spare parts
257658902601	FIXTURE DR SHAFT HOLDING	TATA spare parts
257658902602	SPACER	TATA spare parts
257658902604	C RING	TATA spare parts
257658902605	WRENCH	TATA spare parts
257658902606	DRIFT	TATA spare parts
257658902607	WORK STAND GR BOX GBS-50	TATA spare parts
257658902608	TACKLE	TATA spare parts
257658902609	GAUGE	TATA spare parts
257658902610	TROLLEY GR BOX REMOVAL	TATA spare parts
257658902611	FIXTURE DR SHAFT HOLDING	TATA spare parts
257658903202	PULLER SPG PIN REMOVAL	TATA spare parts
257658903302	ARBOR STUB AXLE INSTAL	TATA spare parts
257658903303	PULLER FRONT HUB	TATA spare parts
257658903304	SPINDLE HUB INSTALLATION	TATA spare parts
257658903305	PULLER	TATA spare parts
257658903306	PULLER	TATA spare parts
257658903307	SPINDLE	TATA spare parts
257658903308	REAMING SET	TATA spare parts
257658903501	DRIFT	TATA spare parts
257658903504	PULLER REAR HUB RA109	TATA spare parts
257658903506	PULLER DIFFL SIDE BRG	TATA spare parts
257658903507	DRIFT	TATA spare parts
257658903509	HOLDER COUPLING FLANGE	TATA spare parts
257658903513	DEPTH MEASUREMENT GAUGE	TATA spare parts
257658903514	DIAL GAUGE HOLDER	TATA spare parts
257658903516	FIXTURE DIFFL ASSY	TATA spare parts
257658903518	SUPPORT	TATA spare parts
257658903519	WRENCH HUB LOCK NUT	TATA spare parts
257658903520	WRENCH	TATA spare parts
257658903521	PRONGED WRENCH	TATA spare parts
257658903522	PULLER	TATA spare parts
257658903523	HOOK CARRIER HSG LIFTING	TATA spare parts
257658903524	DIAL GAUGE HOLDER	TATA spare parts
257658903525	TENSION JAWS	TATA spare parts
257658903528	TROLLEY CARRIER HOUSING	TATA spare parts
257658904101	DRIFT	TATA spare parts
257658904102	SLEEVE	TATA spare parts
257658904104	DRIFT	TATA spare parts
257658904201	PULLER BRAKE PIN REMOVAL	TATA spare parts
257658904401	DRIFT FITTING INNER RACE	TATA spare parts
257658904402	DRIFT FITTING NEEDLE	TATA spare parts

257658904403	DRIFT OIL SEAL	TATA spare parts
257658904404	DRIFT FITTING NEEDLE BUSH	TATA spare parts
257658904602	PRESSURE PIECE POWER STRG	TATA spare parts
257658904603	DRIFT	TATA spare parts
257658904604	SPANNER CAP LOCKING PSTRG	TATA spare parts
257660100116	CAB COMPLT RHD	TATA spare parts
257660100129	COVER STEP SUPPORT LH	TATA spare parts
257660100130	ASSY COVER (STEP SUPPORT) R H	TATA spare parts
257660100144	ASSY PANEL INNER REAR L H	TATA spare parts
257660100145	ASSY.PANEL INNER REAR LH	TATA spare parts
257660100160	CAB COMPLT RHD NON SLEEP	TATA spare parts
257660100176	TIE MEMBER	TATA spare parts
257660108223	SUPPORT TOP RAIL (SIDE REAR) BS6	TATA spare parts
257660108226	PANEL OUTER SIDE LH	TATA spare parts
257660108227	PANEL OUTER SIDE R H	TATA spare parts
257660108228	ANGLE [DOOR SEALING RUBBER] BS6	TATA spare parts
257660108233	GUSSET LH (WHEEL ARCH SUPPORT)	TATA spare parts
257660108234	GUSSET RH (WHEEL ARCH SUPPORT)	TATA spare parts
257660108254	PANEL INNER REAR L H	TATA spare parts
257660108255	PANEL INNER REAR R H	TATA spare parts
257660108256	TIE MEMBER FRONT	TATA spare parts
257660108276	GUSSET BOTTOM LH BS6	TATA spare parts
257660108277	GUSSET BOTTOM RH. BS6	TATA spare parts
257660108284	GUSSET BS6	TATA spare parts
257660110192	CAB COMPLT RHD N/SLEEPER	TATA spare parts
257660120129	COWL BARE RHD	TATA spare parts
257660120158	CAB COMPLT RHD 2416 SLEEP	TATA spare parts
257660120160	CAB COMPLT RHD 2416 N/SL	TATA spare parts
257660130175	BARE CAB LPS1616/LPT2416	TATA spare parts
257660130181	CAB BARE RHD 2416	TATA spare parts
257660140160	ASSY.SUPPORT(BONNET SIDE)	TATA spare parts
257661600113	ASSY REINF FLOOR LH (WHEEL ARCH) BS6	TATA spare parts
257661600114	ASSY REINF R H (FLOOR WHEEL ARCH) BS6	TATA spare parts
257661608213	END SUPPORT FLOOR LH	TATA spare parts
257661608214	END SUPPORT FLOOR RH	TATA spare parts
257661608224	REINF FLOOR L H (WHEEL ARCH)	TATA spare parts
257661608225	REINF FLOOR RH (WHEEL ARCH)	TATA spare parts
257662100130	ASSY FRAME FRONT RH	TATA spare parts
257662100139	ASSY REINFORCEMENT (POST FRONT) BS6	TATA spare parts
257662100147	ASSY DOOR POST L.H. RHD	TATA spare parts
25766210014735	ASSY DOOR POST LH + CED + SEALANT	TATA spare parts
257662100148	ASSY DOOR POST RH RHD	TATA spare parts
25766210014835	ASSY DOOR POST RH + CED + SEALANT	TATA spare parts
257662100149	ASSY DOOR POST L.H. RHD	TATA spare parts
257662108211	COVER CENTRE POST W/S	TATA spare parts
257662108235	GUSSET TOP FRONT L H	TATA spare parts
257662108236	GUSSET TOP FRONT R H	TATA spare parts

257662108238	SUPPORT TOP RAIL FRONT-LH BS6	TATA spare parts
257662108239	SUPPORT TOP RAIL FRONT-RH BS6	TATA spare parts
257662108255	BRACKET DOOR CHECK MTG BS6	TATA spare parts
257662200106	CONTROL MTG BRKT RH	TATA spare parts
257662200120	ASSY BRACKET HORN MTG	TATA spare parts
257662200123	NUT PLATE ASSY STEERING BRACKET SUPPORT	TATA spare parts
257662200130	ASSY.PARTITION WALL-LH	TATA spare parts
257662200131	ASSY.PARTITION WALL-RH	TATA spare parts
257662208218	END SUPPORT WAIST RAIL L H BS6	TATA spare parts
257662208219	END SUPPORT WAIST RAIL RH BS6	TATA spare parts
257662500104	ASSY SUPPORT L H(FACE SIDE PANEL)	TATA spare parts
257662500105	ASSY SUPPORT R H(FACE SIDE PANEL)	TATA spare parts
257662500106	PANEL FACE SIDE BOTTOM LH	TATA spare parts
257662500107	PANEL FACE SIDE BOTTOM RH	TATA spare parts
25766250010735	ASSY PANEL FACESIDE BOTOM RH+CED	TATA spare parts
257662500131	ASSY.PANEL OUTER W/S BOTTOM-RHD	TATA spare parts
257662508208	PANEL FACE SIDE BOTTOM L H	TATA spare parts
257662508209	PANEL FACE SIDE BOTTOM RH	TATA spare parts
257662508216	PANEL OUTER W/S BOTTOM R H D	TATA spare parts
257662508218	PANEL SIDE OUTER W/S L H	TATA spare parts
25766250821835	PANEL SIDE OUTER W/S L H+CED BS1/2/3/4/6	TATA spare parts
257662508219	PANEL SIDE OUTER W/S R H	TATA spare parts
25766250821935	PANEL SIDE OUTER W/S R H+CED BS1/2/3/4/6	TATA spare parts
257662508220	PANEL TOP OUTER W/S	TATA spare parts
257662508221	POST CENTRE W/S	TATA spare parts
257662508236	OUTER PANEL WINDSHIELD BOTTOM BS1/2/3/4	TATA spare parts
257662508237	PANEL OUTER W/S BOTTOM-LHD	TATA spare parts
257662600120	PANEL INNER BOTTOM(W/S)	TATA spare parts
257662600132	ASSY PANEL INNER TOP (W.S)	TATA spare parts
257662608208	PANEL INNER BOTTOM(W/S)	TATA spare parts
257662608210	PANEL INNER SIDE L H W/S	TATA spare parts
25766260821035	PANEL INNER SIDE L H W/S + CED	TATA spare parts
257662608211	PANEL INNER SIDE R H W/S	TATA spare parts
25766260821135	PANEL INNER SIDE R H W/S + CED	TATA spare parts
257662608232	SUPPORT PANEL WINDSHIELD INNER PANEL BS6	TATA spare parts
257662608240	PANEL INNER TOP-W/S	TATA spare parts
257664108204	GUSSET TOP REAR LH BS6	TATA spare parts
257664108205	GUSSET TOP REAR RH BS6	TATA spare parts
257664208205	SUPPORT CENTRE TOP (REAR WALL)	TATA spare parts
257664208206	CORNER SUPPORT L H (REAR WALL)	TATA spare parts
257664208207	CORNOR SUPPORT R H (REAR WALL)	TATA spare parts
257664608215	CORNER PANEL INNER LH	TATA spare parts
257664608216	CORNER PANEL INNER RH-REAR WALL	TATA spare parts
257664700158	ASSY REAR WALL WELDED W/O LOUVERS	TATA spare parts
257664700164	ASSY CORNER PANEL OUTER WITH POST LH	TATA spare parts
257664700166	ASSYCORNERPANELOUTERW/POST&S/PLH	TATA spare parts
257664708223	PANEL OUTER BOTTOM	TATA spare parts

257664708234	CORNER PANEL OUTER LH	TATA spare parts
257665200124	ASSY TOP RAIL COMPLETE RHD	TATA spare parts
257665208209	TOP RAIL SIDE OUTER L H	TATA spare parts
257665208210	TOP RAIL SIDE OUTER R H	TATA spare parts
257665208222	TOP RAIL SIDE INNER LH RHD	TATA spare parts
257665208223	TOP RAIL SIDE INNER RH RHD	TATA spare parts
257665208227	TOP RAIL REAR	TATA spare parts
257665208230	TOP RAIL SIDE INNER LH BS6	TATA spare parts
257665208231	TOP RAIL SIDE INNER RH BS6	TATA spare parts
257665700120	ASSY ROOF WITH TOP RAILS COMPLETE RHD	TATA spare parts
257665700121	ASSY ROOF WELDED SLEEPER CAB	TATA spare parts
25766570012135	ASSY ROOF WELDED(SLEPER CAB)+CED+SEALANT	TATA spare parts
257665700123	ASSY ROOF WITH TOP RAILS COMP RHD	TATA spare parts
257665700124	ASSY ROOF WELDED (NON SLEEPER CAB)	TATA spare parts
257665700129	ASSY REINFORCEMENT COMP ROOF	TATA spare parts
257665707701	RUBBER PAD	TATA spare parts
257665708210	PANEL ROOF REAR(NON SLEEPER CAB)	TATA spare parts
257665708222	GUSSET REAR ROOF REINF	TATA spare parts
257665708223	GUSSET SIDE ROOF REINF BS6	TATA spare parts
257665708254	PANEL ROOF REAR(SLEEPER CAB)	TATA spare parts
257665708255	PANEL ROOF FRONT	TATA spare parts
257666500111	ASSY SUPPORT MUD GUARD REAR LH	TATA spare parts
257666500112	ASSY SUPPORT MUD GUARD REAR RH	TATA spare parts
257666500113	MUDGUARD LH	TATA spare parts
257666500114	MUDGUARD REAR RH	TATA spare parts
257666506304	MUD FLAP REAR	TATA spare parts
257666508205	MUDGUARD FRONT L H	TATA spare parts
257666508206	MUDGUARD FRONT R H	TATA spare parts
257666508209	STRIP	TATA spare parts
257666508238	COVER-MUD FLAP	TATA spare parts
257666600120	ASSY STEP WELL COMPLETE L H	TATA spare parts
257666600121	ASSY STEP WELL COMP RH	TATA spare parts
257666608250	STEP BOARD BOTTOM	TATA spare parts
257666608252	STEP WELL TOP	TATA spare parts
257666608253	STEP WELL TOP	TATA spare parts
257666608263	STEP BOARD	TATA spare parts
257667100119	SIDE WINDOW RH	TATA spare parts
257667100120	SIDE WINDOW LH	TATA spare parts
257667100121	ASSY. REAR WINDOW COMPLETE BS1/2/3/4/6	TATA spare parts
257667100122	ASSY SIDE WINDOW COMPLETE-RH	TATA spare parts
257667100123	ASSY SIDE WINDOW COMPLETE-LH	TATA spare parts
257667102203	FELT STRIP	TATA spare parts
257667102301	W/S GLASS LH	TATA spare parts
257667102302	W/S GLASS RH	TATA spare parts
257667102308	GLASS SIDE WINDOW W/HOLE	TATA spare parts
257667102309	GLASS REAR WINDOW	TATA spare parts
257667102311	GLASS REAR WINDOW W/O HOLE	TATA spare parts

257667102312	WIND SCREEN GLASS LH	TATA spare parts
257667102313	WIND SCREEN GLASS RH	TATA spare parts
257667102316	WINDSHIELD GLASS (1 PIECE) BS1/2/3/4	TATA spare parts
257667102323	GLASS PANE REAR WINDOW	TATA spare parts
257667102501	FILLER PROFILE	TATA spare parts
257667102508	FILLER PROFILE	TATA spare parts
257667106301	RUBBER BEADING LH W/S	TATA spare parts
257667106302	RUBBER BEADING RH W/S	TATA spare parts
257667106303	RUBBER MOULDING LH	TATA spare parts
257667106312	WEATHER STRIP	TATA spare parts
257667106317	WEATHER STRIP	TATA spare parts
257667106324	RUBBER MOULD-WIND SCREEN	TATA spare parts
257667106325	RUBBER MOULDING-LH (WIND SCREEN GLASS)	TATA spare parts
257667106326	RUBBER MOULDING-RH (WIND SCREEN GLASS)	TATA spare parts
257667106327	RUBBER MOULDING LH-W/S GLASS 5.78 THK.	TATA spare parts
257667106328	RUBBER MOULDING RH-W/S GLASS 5.78 THK.	TATA spare parts
257667106331	RUBBER MOULD(W/S GLASS)	TATA spare parts
257667106336	RUBBER MOULD(WIND SCREEN) BS1/2/3/4	TATA spare parts
257667106337	RUBBER MOULD WIND SCREEN	TATA spare parts
257667106338	RUBBER MOULD SIDE WINDOW	TATA spare parts
257667106339	RUBBER MOULD REAR WINDOW	TATA spare parts
257667106339AE	RUBBER MOULD (REAR WINDOW) 1628	TATA spare parts
257668400120	FLOOR MAT RHD	TATA spare parts
257668900111	LID SIDE GLOVE	TATA spare parts
257668900112	ASSY LID CENTRE (GLOVE BOX)	TATA spare parts
257668900118	INSTRUMENT PANEL	TATA spare parts
257668906304	LID SIDE GLOVE BOX	TATA spare parts
257668906305	LID CENTRE GLOVE BOX	TATA spare parts
257668906311	COVER WIPER MOTOR	TATA spare parts
257668906312	COVER WIPER MOTOR	TATA spare parts
257668906313	COVER GLOVE BOX	TATA spare parts
257668906314	COVER GLOVE BOX	TATA spare parts
257668906315	COVER WHEEL BOX	TATA spare parts
257668906316	COVER WHEEL BOX	TATA spare parts
257668906319	COVER-WIPER MOTOR	TATA spare parts
257668906320	COVER GLOVE BOX LH-RHD	TATA spare parts
257668906322	COVER WHEEL BOX	TATA spare parts
257668908224	COVER WIPER MOTOR	TATA spare parts
257668908225	COVER WHEEL BOX	TATA spare parts
257669200108	ASSY.PADDING(DASH BOARD)	TATA spare parts
257669400113	ASSY.SIDE WALL PADDING (BOTTOM) LH	TATA spare parts
257669400115	ASSY. SIDE WALL PADDING (BOTTOM) RH.	TATA spare parts
257669500102	ASSY ROOF LINING	TATA spare parts
257669500103	ASSY ROOF LINING	TATA spare parts
257669502003	INSULATION SIDE FRONT	TATA spare parts
257669502005	INSULATION SIDE REAR	TATA spare parts
257669606010	ROOF BOW MIDDLE	TATA spare parts



257669606012	ROOF BOW CENTRE	TATA spare parts
257672000101	DOOR ASSY COMPLT LH	TATA spare parts
257672000102	DOOR RH	TATA spare parts
257672200116	ASSY PANEL OUTER DOOR R H RHD	TATA spare parts
257672200128	DOOR SHELL LH	TATA spare parts
257672200129	DOOR SHELL RH	TATA spare parts
257672200132	DOOR ASSY.LH	TATA spare parts
257672200133	DOOR ASSY COMPLT RH	TATA spare parts
257672200144	BKT HINGE DOOR LOWER LH	TATA spare parts
257672200145	BKT HINGE DOOR LOWER RH	TATA spare parts
257672200158	DOOR SHEL LH	TATA spare parts
25767220015835	ASSY DOOR SHELL LH LHD+ CED + SEALANT	TATA spare parts
257672200159	DOOR SHEL RH	TATA spare parts
25767220015935	ASSY. DOOR SHELL RH + CED BS1/2/3/4	TATA spare parts
257672200165	ASSY DOOR SHELL LH RHD	TATA spare parts
25767220016535	ASSY. DOOR SHELL LH + CED BS1/2/3/4	TATA spare parts
257672200166	ASSY DOOR SHELL RH LHD	TATA spare parts
257672200167	ASSY PANEL OUTER (DOOR) LH RHD	TATA spare parts
257672200169	ASSY REINF. PROXIMITY MIRROR MTG.	TATA spare parts
257672203306	BRACKET REGULATOR FRAME MTG BS6-PH2	TATA spare parts
257672203316	STOPPER DOOR GLASS FRONT-LH BS6-PH2	TATA spare parts
257672208214	STIFFENER SIDE DOOR LH BS6-PH2	TATA spare parts
257672208239	POST PANEL INNER DOOR LH BS6	TATA spare parts
257672208240	POST PANEL INNER DOOR RH BS6	TATA spare parts
257672208249	CORNER PIECE BS6-PH2	TATA spare parts
257672208257	PANEL OUTER (DOOR) LH RHD CMVR	TATA spare parts
257672300101	PULL ROD DOOR LOCK	TATA spare parts
257672300111	DOOR HANDLE OUTER LH EURO2	TATA spare parts
257672300112	DOOR HANDLE OUTER RH	TATA spare parts
257672300113	LEVER DOOR LOCK	TATA spare parts
257672300114	DOOR RETAINER	TATA spare parts
257672300127	DOOR LOCK LH	TATA spare parts
257672300128	DOOR LOCK RH	TATA spare parts
257672300131	ASSY DOOR HINGE LH 1516	TATA spare parts
257672300132	STRIKER LH DOOR LOCK	TATA spare parts
257672300133	STRIKER RH DOOR LOCK	TATA spare parts
257672300137	REGULATOR LH TURN WINDOW	TATA spare parts
257672300143	DOOR HANDLE INNER RH	TATA spare parts
257672300144	DOOR HANDLE INNER LH	TATA spare parts
257672300146	ASSY HANDLE	TATA spare parts
257672300147	DOOR HANDLE OUT LH W/LOCK	TATA spare parts
257672300152	ASSY DOOR HINGE	TATA spare parts
257672300153	DOOR CHECK ASSY	TATA spare parts
257672300157	DOOR HANDLE OUTER LH	TATA spare parts
257672300159	KIT FOR LOCK-RHD	TATA spare parts
257672300163	ASSY.PULL ROD-LH (FOR INNER HANDLE)	TATA spare parts
257672300164	ASSY.PULL ROD-RH (FOR INNER HANDLE)	TATA spare parts

257672302507	SEALING PROFILE DOOR	TATA spare parts
257672303802	COVER RH LOCK	TATA spare parts
257672306318	DOOR SEALING OUTER	TATA spare parts
257672306320	DOOR SEALING INNER	TATA spare parts
257672306706	PIN (DOOR HINGE) BS6-PH2	TATA spare parts
257672306707	STOPPER PIN (DOOR HINGE) BS6-PH2	TATA spare parts
257672308602	SPACER WASHER	TATA spare parts
257672310110	DOOR LOCK LH	TATA spare parts
257672310111	DOOR LOCK RH	TATA spare parts
257672310125	PULL ROD ASSY	TATA spare parts
257672315602	KNOB	TATA spare parts
257672316707	STEP PIN	TATA spare parts
257672316708	STEP PIN	TATA spare parts
257672316709	STEP PIN	TATA spare parts
257672316710	STEP PIN	TATA spare parts
257672316711	PIN STRIKER MOUNTING	TATA spare parts
257672316712	STEP PIN	TATA spare parts
257672318204	STRIKER LH	TATA spare parts
257672318205	STRIKER RH	TATA spare parts
257672318701	SPRING DOOR LOCK	TATA spare parts
257672318702	TORSION SPG LH INN HANDLE	TATA spare parts
257672318703	TORSION SPG LH P/PULL LEV	TATA spare parts
257672318704	COMPRESSION SPRING	TATA spare parts
257672318705	TORSION SPG RH INN HANDLE	TATA spare parts
257672318706	TORSION SPG RH P/PULL LEV	TATA spare parts
257672318708	TENSION SPRING	TATA spare parts
257672319203	WASHER	TATA spare parts
257672500120	TURN WINDOW RH W/GLASS	TATA spare parts
257672500122	BUFFER DOOR	TATA spare parts
257672500123	WINDOW REGULATOR LH BS2/3	TATA spare parts
257672500124	WINDOW REGULATOR RH BS2/3	TATA spare parts
257672500130	TURN WINDOW LH W/GLASS	TATA spare parts
257672500131	TURN WINDOW RH W/GLASS	TATA spare parts
257672500133	TOGGLE CLAMP LH	TATA spare parts
257672500134	TOGGLE CLAMP RH	TATA spare parts
257672500143	DOOR GLASS HOLDER	TATA spare parts
257672500146	ASSY.TURING WINDOW LH. C	TATA spare parts
257672500147	ASSY TURNING WINDOW COMP R	TATA spare parts
257672500148	ASSY. FRAME COMP. REG.WINDOW BS1/2/3/4/6	TATA spare parts
257672500150	ASSY.WINDOW REGULATOR LH	TATA spare parts
257672500151	ASSY.WINDOW REGULATOR RH	TATA spare parts
257672500152	ASSY.WINDOW REGULATOR LH	TATA spare parts
257672500153	ASSY.WINDOW REGULATOR RH	TATA spare parts
257672500154	ASSY WEATHER STRIP OUTER BOTTOM	TATA spare parts
257672500155	ASSY WEATHER STRIP OUTER TOP	TATA spare parts
257672500156	ASSY WEATHER STRIP INNER	TATA spare parts
257672502303	GLASS PANE REG. WINDOW BS1/2/3/4/6	TATA spare parts

257672502306	GLASS PANE TURNING WINDOW	TATA spare parts
257672502512	RUB PROFILE DOOR GLASS	TATA spare parts
257672502513	VELVET CHANNEL	TATA spare parts
257672506314	RUB MOULD LH TURN WINDOW	TATA spare parts
257672506315	RUB MOULD RH TURN WINDOW	TATA spare parts
257672506319	NYLON ROLLER	TATA spare parts
257672506321	GRIP BEADING DOOR	TATA spare parts
257672506712	SPECIAL PIN	TATA spare parts
257672506716	PIN GLASS HOLDER	TATA spare parts
257672507701	RUB STOPPER REG GLASS	TATA spare parts
257672508238	DOOR GLASS HOLDER BS6-PH2	TATA spare parts
257672700109	PADDING LH DOOR	TATA spare parts
257672700110	PADDING RH DOOR	TATA spare parts
257675100117	CENTRE FLAP WELDED	TATA spare parts
257675100120	CENTRE FLAP COMPLT	TATA spare parts
257675100121	BRACKET CENTRE FLAP STAY	TATA spare parts
257675100126	LOCK CENTRE FLAP	TATA spare parts
257675100127	KNOB CENTRE FLAP	TATA spare parts
257675200101	T EMBLEM	TATA spare parts
257675200109	RUBBER BUFFER	TATA spare parts
257675200114	STAY ROD CENTRE FLAP	TATA spare parts
257675200115	HINGE CENTRE FLAP	TATA spare parts
257675200116	T EMBLEM-1312/1516	TATA spare parts
257675200121	T EMBLEM 1516	TATA spare parts
257675203309	BRACKET (LOCK)	TATA spare parts
257675204201	CLAMP	TATA spare parts
257675206306	BUSH BODY SIDE	TATA spare parts
257675206307	BUSH CENTRE FLAP SIDE	TATA spare parts
257675206308	RUBBER STOPPER	TATA spare parts
257675206309	LETTER T	TATA spare parts
257675206310	LETTER A	TATA spare parts
257675206702	HINGE PIN (CENTRE FLAP) BS6	TATA spare parts
257675206908	STAY ROD-CENTRE FLAP	TATA spare parts
257675207501	BUSH CENTRE FLAP	TATA spare parts
257675208205	BEADING	TATA spare parts
257675208301	SHIM	TATA spare parts
257681100103	ASSY SUN VISOR	TATA spare parts
257681100106	FRAME REAR VIEW MIRROR	TATA spare parts
257681100114	RV MIRROR	TATA spare parts
257681100115	ASSY REAR VIEW MIRROR COMPLETE	TATA spare parts
257681100139	ASSY. HEAD LAMP HOUSING LH	TATA spare parts
257681100140	ASSY. HEAD LAMP HOUSING RH	TATA spare parts
257681100145	ASSY EXTERIOR RVM-DOUBLE CHAMBER	TATA spare parts
257681100146	ASSY CLOSE PROXIMITY MIRROR	TATA spare parts
257681100146AE	ASSY CLOSE PROXIMITY MIRROR	TATA spare parts
257681100147	ASSY CLOSE PROXIMITY MIRROR	TATA spare parts
257681100148	ASSY RVM COMP.WITH FRAME (NORM.VISION)RH	TATA spare parts

257681100151	ASSY RVM OUTER DOUBLE CHAMBER	TATA spare parts
257681100152	ASSY. ORVM RH BS1/2/3/4/6	TATA spare parts
257681100152AE	ASSY RR VIEW MIRR OUTER RH -2523	TATA spare parts
257681100153	ASSY. ORVM LH BS1/2/3/4/6	TATA spare parts
257681100153AE	ASSY RR VIEW MIRR OUTER LH -2523	TATA spare parts
257681100165	ASSY. TANDEM RVM W/FRAME LH RHD BS1- 4	TATA spare parts
257681100167	ASSY REAR VIEW MIRROR OUTER WIDE ANG	TATA spare parts
257681100168	ASSY CLOSE PROXIMITY MIRROR	TATA spare parts
257681100169	ASSY.RVM RH	TATA spare parts
257681100170	ASSY RVM LH	TATA spare parts
257681100171	ASSY REAR VIEW MIRROR OUTER WIDE ANG	TATA spare parts
257681100172	ASSY CLOSE PROXIMITY MIRROR	TATA spare parts
257681100179	ASSY CLOSE PROXIMITY MIRROR	TATA spare parts
257681100180	ASSY RVM-NORMAL RH	TATA spare parts
257681100181	ASSY RVM-NORMAL LH	TATA spare parts
257681102701	PLASTIC STICKER	TATA spare parts
257681103301	BKT ORVM TOP MTG	TATA spare parts
257681103302	BKT ORVM BOTTOM MTG.	TATA spare parts
257681104301	CLIP(FOR OVAL `T'EMBLEM MTG.)	TATA spare parts
257681106309	HEAD LAMP HOUSING	TATA spare parts
257681106322	HEAD LAMP HOUSING	TATA spare parts
257681106331	CLOSING PLUG(WAIST RAIL REINFORCEMENT) B	TATA spare parts
257681106332	REFLECTIVE TAPE-CENTRE	TATA spare parts
257681106333	REFLECTIVE TAPE-SIDE	TATA spare parts
257681106334	REFLECTIVE TAPE SIDE	TATA spare parts
257681106335	REFLECTIVE TAPE SIDE	TATA spare parts
257681106336	REFLECTIVE TAPE-SIDE WALL	TATA spare parts
257681106337	REFLECTIVE TAPE WHITE 520 LG	TATA spare parts
257681106338	REFLECTIVE TAPE CENTER WHITE 240 LG	TATA spare parts
257681108205	HEAD LAMP HOUSING	TATA spare parts
257681108601	SPACER MTG ORVM	TATA spare parts
257681500106	GRAB HANDLE	TATA spare parts
257681500107	GRAB HANDLE FRONT FACE	TATA spare parts
257681500110	ASSY GRAB HANDLE LH [DASH BOARD]	TATA spare parts
257681500111	ASSY GRAB HANDLE RH [DASH BOARD]	TATA spare parts
257681500112	GRAB HANDLE LH DASH BOARD	TATA spare parts
257681500113	GRAB HANDLE RH DASH BOARD	TATA spare parts
257681500116	ASSY.GRAB HANDLE	TATA spare parts
257681500119	ASSY.GRAB HANDLE DASH BOARD	TATA spare parts
257681506301	CAP HANDLE DASH BOARD	TATA spare parts
257681506302	RUBBER PAD GRAB HANDLE	TATA spare parts
257681506305	RUBBER PAD	TATA spare parts
257681506309	RUBBER PAD	TATA spare parts
257681506903	GRAB RAIL LH	TATA spare parts
257681506904	GRAB RAIL RH	TATA spare parts
257681508204	RETAINING PLATE	TATA spare parts
257682400101	WIPER ARM RHD	TATA spare parts

257682400102	WIPER ARM LHD	TATA spare parts
257682400103	WIPER BLADE	TATA spare parts
257682400109	WHEEL BOX	TATA spare parts
257682400110	KIT WIPER MOTOR 17W	TATA spare parts
257682400125	ASSY WIPER ARM (DRIVER)	TATA spare parts
257682400126	ASSY SUPPORT ARM	TATA spare parts
257682400127	ASSY WIPER ARM (RHD)(CO-DRIVER)	TATA spare parts
257682400128	ASSY. WIPER BLADE (DRIVER) BS1/2/3/4/6	TATA spare parts
257682400129	ASSY. WIPER BLADE CO-DRIVER BS1/2/3/4/6	TATA spare parts
257682400136	WIPER ARM RHD 1516/1616	TATA spare parts
257682400137	WIPER ARM LHD 1516/1616	TATA spare parts
257682400138	WIPER BLADE 1516/1616 L&R	TATA spare parts
257682400139	ASSY WIPER ARM & BLADE	TATA spare parts
257682408201	BRACKET	TATA spare parts
257682409901	WIPER MOTOR RHD 17W 12V	TATA spare parts
257682409902	WIPER MOTOR LHD 17W 12V	TATA spare parts
257682409905	LINK ROD 205MM	TATA spare parts
257682409906	LINK ROD 585MM	TATA spare parts
257683800101	ASSY VENTILATION UNIT FRONT	TATA spare parts
257686900103	ASSY BRACKET LH-RHD (W/S WASHER)	TATA spare parts
257688100105	FENDER LH	TATA spare parts
257688100106	FENDER RH	TATA spare parts
257688106302	FENDER RH	TATA spare parts
257688106303	MUD FLAP REAR	TATA spare parts
257688107709	FENDER BEADING	TATA spare parts
257688107711	BEADING FENDER	TATA spare parts
257688108203	FENDER L H (REAR)	TATA spare parts
257688108204	FENDER R H (REAR)	TATA spare parts
257688108205	FENDER LH (MIDDLE)	TATA spare parts
257688108206	FENDER RH (MIDDLE)	TATA spare parts
257688108207	FENDER LH (FRONT)	TATA spare parts
257688108208	FENDER RH FRONT	TATA spare parts
257688300106	FOOT STEP FRONT	TATA spare parts
257688300107	FOOT STEP POWDER COATED	TATA spare parts
257688306906	FOOT STEP FRONT-PAINTED VERSION	TATA spare parts
257688500115	BUMPER LH SIDE PAINTED	TATA spare parts
257688500116	BUMPER RH SIDE PAINTED	TATA spare parts
257688500117	BUMPER CENTRE PAINTED	TATA spare parts
257688500120	ASSY BRACKET-FRT SUPPORT	TATA spare parts
257688500121	BUMPER COMP PAINTED	TATA spare parts
257688500122	SUPPORT BUMPER	TATA spare parts
257688500127	ASSY BUMPER WELDED(ROLLED) LPT 1615 TC	TATA spare parts
257688500127C0	ASSY BUMPER WITH REFLECTOR - BLACK	TATA spare parts
257688500134	ASSY.PROTECTIVE GRILL(FOR HEAD LAMP)	TATA spare parts
257688500135	ASSY. BRACKET RH BUMPER SUPPORT BS1- 4	TATA spare parts
257688500136	BUMPER ASSY 1616/2416	TATA spare parts
257688508219	BUMPER SIDE LH	TATA spare parts

257688508220	BUMPER SIDE RH	TATA spare parts
257688508221	BUMPER CENTRE	TATA spare parts
257688508222	PLATFORM SIDE LH	TATA spare parts
257688508223	PLATFORM SIDE RH	TATA spare parts
257688508224	PLATFORM CENTRE	TATA spare parts
257688508225	REINFORCEMENT LH	TATA spare parts
257688508226	REINFORCEMENT RH	TATA spare parts
257688508242	COVER PLATE BUMPER SIDE	TATA spare parts
257688508246	END PLATE-BUMPER SIDE	TATA spare parts
257688700121	ENGINE HOOD ASSY RHD	TATA spare parts
257688700131	ASSY ENGINE HOOD COMPLETE RHD	TATA spare parts
257688706303	SEALING RUBBER ENG HOOD	TATA spare parts
257688707804	RUBBER BELLOW G S LEVER	TATA spare parts
257688708229	HOOD CATCHER	TATA spare parts
257689100104	BRACKET FRT MTG LH RHD	TATA spare parts
257689100111	MTG BKT RH RR N/SLPR CAB	TATA spare parts
257689100112	BKT CAB MTG LH RR N/SLCAB	TATA spare parts
257689100113	BKT CAB MTG RH RR N/SLCAB	TATA spare parts
257689100115	BRACKET FRT MTG RH LHD	TATA spare parts
257689100116	ASSY.CUP FRT.MTG.	TATA spare parts
257689100122	SPRING ASSY CAB REAR	TATA spare parts
257689100125	RUBBER BUSH	TATA spare parts
257689100135	BRACKET REAR LH	TATA spare parts
257689100136	BRACKET REAR RH	TATA spare parts
257689100149	SHOCK ABSORBER CAB MTG REAR BS1/2/3/4	TATA spare parts
257689103702	MOUNTING CUP FRONT BS1/2/3/4	TATA spare parts
257689106703	PIN-SHOCK ABSORBER	TATA spare parts
257689107112	LEAF SPRING 1ST CAB	TATA spare parts
257689107113	LEAF SPRING 2ND	TATA spare parts
257689107120	CLAMPING PLATE(CAB MTG. SPRING)	TATA spare parts
257689107128	PLATE FRONT MTG	TATA spare parts
257689107701	RUB BUFFER FRONT UPPER	TATA spare parts
257689107704	RUBBER BUFFER LOWER BS1/2/3/4	TATA spare parts
257689107705	RUBBER BUFFER UPPER BS1/2/3/4	TATA spare parts
257689108602	SPACER TUBE FRONT MTG	TATA spare parts
257689108604	SPACER TUBE	TATA spare parts
257691000108	ASSY BOTTOM BERTH	TATA spare parts
257691000109	ASSY TOP BERTH COMPLT	TATA spare parts
257691000115	ASSY DRIVERS SEAT	TATA spare parts
257691000117	KIT FOR SLEEPER BERTHS(NON A.C.)	TATA spare parts
257691000120	ASSY DRIVER SEAT	TATA spare parts
257691100108	BRACKET TOP-SEAT BELT ANCHORAGE	TATA spare parts
257691500102	SAFETY BELT W/TONGUE LH	TATA spare parts
257691500103	LAP SAFETY BELT W/TONGUE	TATA spare parts
257691500104	SAFETY BELT W/TONGUE RH	TATA spare parts
257691500110	ASSY.SEAT BELT COMPLETE DRIVER	TATA spare parts
257691500117	KIT SEAT BELTS COMPLETE	TATA spare parts

257691500122	ASSY.SEAT BELT COMPLETE DRIVER	TATA spare parts
257691500126	ASSY SEAT BELT COMPLETE-DRIVER	TATA spare parts
257691500134	ASSY SEAT BELT COMPLETE-DRIVER	TATA spare parts
257691700103	ASSY HINGE /TOP BEARTH	TATA spare parts
257691700103AE	ASSY HINGE /TOP BEARTH 1628	TATA spare parts
257691700104	ASSY HINGE BOTTOM BERTH	TATA spare parts
257691700104AE	ASSY HINGE BOTTOM BEARTH 1628	TATA spare parts
257691700105	ASSY NUT PLATE (TOP BERTH)	TATA spare parts
257691700106	BRACKET ASSY STAY ROD	TATA spare parts
257691700109	ASSY STAY ROD (SLEEPER BERTH)	TATA spare parts
257691700133	ASSY SEAT STAND RHD(FOR LCV SEAT)	TATA spare parts
257691700134	ASSY SEAT STAND LHD	TATA spare parts
257691700139	ASSY BRACKET (SAFETY BELT)	TATA spare parts
257691702904	HINGE LEAF-BODY SIDE (TOP)	TATA spare parts
257691708221	HOOK(TOP BEARTH)	TATA spare parts
257694000106	CO DRIVER SEAT COMP	TATA spare parts
257694000110	ASSY CO-DRIVER SEAT COMP.	TATA spare parts
257694000114	ASSY.CO-DRIVER'S SEAT COMP-RHD	TATA spare parts
257698706301	RUBBER RING	TATA spare parts
257698800102	MASCOT 1516 TURBO	TATA spare parts
257699100104	PIN W/NYLON INSERT	TATA spare parts
257699100105	HEX SCREW W/NYLON INSERT	TATA spare parts
257699103201	SPECIAL PIN	TATA spare parts
257732107101	CASTER PLATE	TATA spare parts
257732300102	BKT S/ABS LH FRONT	TATA spare parts
257732300103	BKT S/ABS RH FRONT	TATA spare parts
257746000101	DRAG LINK ASSY RHD LPO	TATA spare parts
258235300101	CROWNWHEEL PINION 41/7	TATA spare parts
258742900109	PIPE AIR	TATA spare parts
258742900117	PIPE AIR	TATA spare parts
258742906801	ADAPTER	TATA spare parts
258742906802	ADAPTER	TATA spare parts
258742906918	PIPE AIR 6 X 1	TATA spare parts
258743100102	DOUBLE CHECK VALVE	TATA spare parts
258743103803	SIDE COVER	TATA spare parts
258743107702	SEAL	TATA spare parts
258831208209	CROSS MEMBER	TATA spare parts
258842100112	FORK	TATA spare parts
258842100116	INTERMEDIATE SHAFT	TATA spare parts
258842106003	PULL ROD	TATA spare parts
258842108601	SPACER	TATA spare parts
258842109901	PIN	TATA spare parts
258842109902	PIN	TATA spare parts
258842900141	HOSE	TATA spare parts
258842900145	PIPE AIR	TATA spare parts
258842900157	HOSE PIPE	TATA spare parts
258842900159	PIPE AIR	TATA spare parts

258842900162	HOSE	TATA spare parts
258842900163	HOSE	TATA spare parts
258842900164	HOSE	TATA spare parts
258842900165	ASSY.HOSE-RHD. 42/46/48 W	TATA spare parts
258842900166	HOSE	TATA spare parts
258842900167	HOSE ASSY	TATA spare parts
258843100101	RELAY VALVE	TATA spare parts
258843100111	NON RETURN VALVE	TATA spare parts
258843100113	NON-RETURN VALVE	TATA spare parts
258843100117	KIT REP RELAY EMERG VALVE	TATA spare parts
258843106802	SOCKET	TATA spare parts
258843107704	RUBBER VALVE	TATA spare parts
258843107705	VALVE SEAT	TATA spare parts
258843108602	SPACER	TATA spare parts
258843700101	PALM COUPLING TRACTOR SUPPLY	TATA spare parts
258843700102	PALM COUPLING TRACTOR CONTROL	TATA spare parts
258843700103	TRAILER CONTROL VALVE	TATA spare parts
258843700104	TRAILER CONTROL VALVE	TATA spare parts
258843700105	PALM COUPLING	TATA spare parts
258843700106	PALM COUPLING	TATA spare parts
258854600108	ASSY PLUG SUPORT BKT.	TATA spare parts
258854608201	CLAMP	TATA spare parts
258854609901	7POLE SOCKET	TATA spare parts
258854609902	7-POLE SOCKET	TATA spare parts
258854609903	GROMMET	TATA spare parts
258942306301	BRAKE LINING STD FRT	TATA spare parts
258942306302	BRAKE LINING RS1 FRT	TATA spare parts
258942306303	BRAKE LINING RS2 FRT	TATA spare parts
258942306304	BRAKE LINING STD FRT	TATA spare parts
258942306305	BRAKE LINING RS1 FRT	TATA spare parts
258942306306	BRAKE LINING RS2 FRT	TATA spare parts
259155100101	MASCOT ASSY	TATA spare parts
259155100102	MASCOT ASSY BS6	TATA spare parts
259155100104	MASCOT ASSY	TATA spare parts
259155100105	MASCOT ASSY BS6	TATA spare parts
259155100108	MASCOT ASSY BS6-PH2	TATA spare parts
259160000101	COWL ASSY WITH FITMENT	TATA spare parts
259160000102	COWL ASSY	TATA spare parts
259160000104	COWL ASSY WITH CED COATING	TATA spare parts
259160000109	COWL ASSY WITH FITMENT	TATA spare parts
259160000110	COWL ASSY WITH CED COATING	TATA spare parts
259160003313	BRACKET CLAMP MTG BS6	TATA spare parts
259160100102	ASSY COWL SHELL PAINTED-LHD LPO1316C	TATA spare parts
259160100106	LPO 1316 TC LHD FITTED COWL	TATA spare parts
259160100216	COWL SHELL ASSY IN WHITE W/O FACE	TATA spare parts
259160100252	DRIVER STATION ASSY WITH FITMENT	TATA spare parts
259160100275	BRACKET ASSY AIR FILTER MTG BS6-PH2	TATA spare parts



259160100279	CHANNEL ASSY BS6-PH2	TATA spare parts
259160100281	BRACKET ASSY BS6-PH2	TATA spare parts
259160103304	BRACKET	TATA spare parts
259160103306	BRACKET	TATA spare parts
259160107201	BRACKET FRONT GRILL MTG LH	TATA spare parts
259160107202	BRACKET FRONT GRILL MTG RH	TATA spare parts
259160110111	ASSY.DRIVER STATION PAINTED LHD	TATA spare parts
259160110118	DRIVER STATION ASSY	TATA spare parts
259160110119	ASSY DRIVER STATION PAINTED RHD DIMTC	TATA spare parts
259160110132	ASSY DRIVER STATION PAINTED RHD	TATA spare parts
259160110144	DRIVER STATION ASSY	TATA spare parts
259160110153	DRIVER STATION ASSY	TATA spare parts
259160110160	DRIVER STATION ASSY PAINTED	TATA spare parts
259160110161	DRIVER STATION ASSY	TATA spare parts
259160110169	BRACKET ASSY ECU MTG BS6	TATA spare parts
259160110171	DRIVER STATION ASSY WITH CED COATING BS6	TATA spare parts
259160110172	DRIVER STATION ASSY WITH FITMENT BS6	TATA spare parts
259160110183	DRIVER STATION ASSY WITH CED COATING BS6	TATA spare parts
259160110184	DRIVER STATION ASSY WITH FITMENT BS6	TATA spare parts
259160110202	DRIVER STATION ASSY WITH CED COATING BS6	TATA spare parts
259160118263	BRACKET FRONT GRILL MTG LH BS6	TATA spare parts
259160118264	BRACKET FRONT GRILL MTG RH BS6	TATA spare parts
259160120115	DRIVER STATION ASSY WITH FITMENT BS6	TATA spare parts
259160120117	DRIVER STATION ASSY WITH CED COATING BS6	TATA spare parts
259160120119	BRACKET ASSY ECU MTG BS6	TATA spare parts
259160120133	DRIVER STATION ASSY WITH FITMENT BS6	TATA spare parts
259160120134	DRIVER STATION ASSY WITH CED COATING BS6	TATA spare parts
259160120135	DRIVER STATION ASSY WITH FITMENT BS6	TATA spare parts
259160120173	DRIVER STATION ASSY WITH FITMENT BS6	TATA spare parts
259160120186	DRIVER STATION ASSY WITH CED COATING BS6	TATA spare parts
259160120187	DRIVER STATION ASSY WITH FITMENT BS6	TATA spare parts
259160120196	BRACKET ASSY STG RESERVOIR MTG BS6-PH2	TATA spare parts
259160128201	SUPPORT BRACKET BS6	TATA spare parts
259160128246	SUPPORT BRACKET BS6	TATA spare parts
259160130104	BRACKET ASSY GAS SENSOR MTG BS6-PH2	TATA spare parts
259160130106	PANEL ASSY FRONT BS6	TATA spare parts
259160130108	PANEL ASSY TOP BS6	TATA spare parts
259160130112	KIT-BODY PANEL BS6	TATA spare parts
259160130113	KIT-BODY PANEL BS6	TATA spare parts
259160130115	COVER ASSY LH BS6	TATA spare parts
259160130116	SIDE PANEL ASSY BS6	TATA spare parts
259160130131	COVER ASSY BS6	TATA spare parts
259160130132	PANEL ASSY FRONT BS6	TATA spare parts
259160130135	PANEL ASSY LH BS6	TATA spare parts
259160130136	COVER ASSY BS6	TATA spare parts
259160130138	DRIVER STATION ASSY WITH FITMENT BS6	TATA spare parts
259160130140	DRIVER STATION ASSY BS6	TATA spare parts

259160130144	PANEL ASSY FRONT BS6	TATA spare parts
259160130146	PANEL ASSY TOP BS6	TATA spare parts
259160130147	SIDE PANEL ASSY BS6	TATA spare parts
259160130148	PANEL ASSY FRONT BS6	TATA spare parts
259160130150	PLATE ASSY TOP BS6	TATA spare parts
259160130152	DRIVER STATION ASSY WITH FITMENT BS6	TATA spare parts
259160130155	DRIVER STATION ASSY WITH CED COATING BS6	TATA spare parts
259160130159	PLATE ASSY	TATA spare parts
259160130161	COVER ASSY BS6	TATA spare parts
259160130166	PANEL ASSY LH BS6	TATA spare parts
259160130167	COVER ASSY LH BS6	TATA spare parts
259160130168	COVER ASSY BS6	TATA spare parts
259160130169	COVER ASSY BS6	TATA spare parts
259160130170	COVER ASSY BS6	TATA spare parts
259160130171	PANEL ASSY TOP BS6	TATA spare parts
259160130174	PANEL ASSY LH BS6	TATA spare parts
259160130175	PANEL ASSY FRONT BS6	TATA spare parts
259160130176	PANEL ASSY FRONT BS6	TATA spare parts
259160130181	PANEL ASSY FRONT BS6	TATA spare parts
259160130182	PANEL ASSY LH BS6	TATA spare parts
259160130183	COVER ASSY BS6	TATA spare parts
259160130187	KIT-BOLTED PARTS BS6	TATA spare parts
259160130195	DRIVER STATION ASSY BS6	TATA spare parts
259160130196	DRIVER STATION ASSY WITH CED COATING BS6	TATA spare parts
259160140120	DRIVER STATION ASSY WITH CED COATING	TATA spare parts
259160140132	DRIVER STATION ASSY WITH CED COATING BS6	TATA spare parts
259160140134	DRIVER STATION ASSY WITH FITMENT BS6	TATA spare parts
259160140187	DRIVER STATION ASSY WITH CED COATING	TATA spare parts
259160150152	DRIVER STATION ASSY WITH FITMENT BS6	TATA spare parts
259160168217	FRONT GRILL BS6-PH2	TATA spare parts
259161100103	ASSY.BRACKET-RHD AIR FILTER MTG.	TATA spare parts
259161100133	ASSY_REAR_MTG.(C/MEMBER_REAR)	TATA spare parts
259161200108	ASSY.OUTRIGGER RH	TATA spare parts
259161200109	ASSY.OUTRIGGER LH	TATA spare parts
259161200111	ASSY.SUPPORT FRAME(HEAD LAMP MTG.RH)	TATA spare parts
259161200112	ASSY.SUPPORT FRAME(HEAD LAMP MTG.LH)	TATA spare parts
259161200113	OUTRIGGER ASSY RH	TATA spare parts
259161200114	ASSY OUTRIGGER RH	TATA spare parts
259168700101	KIT-INSULATION BS6	TATA spare parts
259168700109	KIT-INSULATION BS6	TATA spare parts
259168700111	KIT-INSULATION BS6	TATA spare parts
259168700112	KIT-INSULATION BS6	TATA spare parts
259168700113	KIT-INSULATION BS6	TATA spare parts
259168700114	KIT-INSULATION BS6	TATA spare parts
259168700118	KIT-INSULATION BS6	TATA spare parts
259168700120	KIT-INSULATION BS6	TATA spare parts
259168706305	INSULATION BS6	TATA spare parts

259168706310	INSULATION BS6	TATA spare parts
259168706318	INSULATION BS6	TATA spare parts
259168706322	INSULATION BS6	TATA spare parts
259168706324	INSULATION BS6	TATA spare parts
259168706344	INSULATION BS6	TATA spare parts
259168706360	INSULATION BS6	TATA spare parts
259168706361	INSULATION BS6	TATA spare parts
259168706390	INSULATION	TATA spare parts
259168706392	INSULATION BS6-PH2	TATA spare parts
259168706393	INSULATION BS6-PH2	TATA spare parts
259168706395	INSULATION BS6-PH2	TATA spare parts
259168706399	INSULATION BS6-PH2	TATA spare parts
259168716301	INSULATION	TATA spare parts
259168716302	INSULATION BS6-PH2	TATA spare parts
259168716303	INSULATION BS6-PH2	TATA spare parts
259168716305	INSULATION BS6-PH2	TATA spare parts
259168716320	INSULATION BS6-PH2	TATA spare parts
259168716323	INSULATION BS6-PH2	TATA spare parts
259168716326	INSULATION	TATA spare parts
259168716329	INSULATION	TATA spare parts
259168716331	INSULATION BS6-PH2	TATA spare parts
259168900103	ASSY.INSTRUMENT PANEL-RHD	TATA spare parts
259168900107	ASSY INSTRUMENT PANEL-RHD-1510CNG	TATA spare parts
259168900112	INSTRUMENT PANEL ASSY TOP	TATA spare parts
259168900113	ASSY BRACKET(INST.PANEL MTG.)	TATA spare parts
259168900117	ASSY IP TOP	TATA spare parts
259168900118	ASSY IP BOTTOM	TATA spare parts
259168900119	ASSY NACELLE LH	TATA spare parts
259168900122	BRACKET ASSY CLUSTER MTG	TATA spare parts
259168906305	NACALLE RH	TATA spare parts
259168906306	COVER(STEERING COLUMN)	TATA spare parts
259168906308	DASHBOARD DRIVER SIDE LOWER	TATA spare parts
259168908224	CLUSTER MTG BRACKET	TATA spare parts
259175100101	ASSY CENTRE FLAP COMPLETE 1510 CNG	TATA spare parts
259181100101	ASSY.INSULATION-PODEST	TATA spare parts
259181100102	KIT FOR BONNET & PODEST INSULATION	TATA spare parts
259181100103	ASSY.INSULATION-LH(BONNET SIDE)	TATA spare parts
259181100104	ASSY.INSULATION-RH(BONNET SIDE)	TATA spare parts
259181100105	ASSY.INSULATION(BONNET CENTRE)	TATA spare parts
259181100114	KIT FOR ASSY RVM COMP FOR BUS FAMILY COW	TATA spare parts
259181100115	ASSY RVM COMPLETE LH BS6	TATA spare parts
259181100116	ASSY RVM COMPLETE RH BS6	TATA spare parts
259181100117	ASSY TUBULAR FRAME (REAR VIEW MIRROR)	TATA spare parts
259181106305	COVER (STEERING COLOUMN)	TATA spare parts
259181800102	ASSY TATA 1316 CUMMINS MASCOT	TATA spare parts
259181800105	ASSY TATA 1316 C MASCOT	TATA spare parts
259182408201	BKT.(WIPER MOTOR MTG.)	TATA spare parts

259186900120	CANOPYMTGASSYFRONT-LH BS6	TATA spare parts
259186900121	CANOPY MTG ASSY FRONT-RH BS6	TATA spare parts
259186900122	FRAME ASSY FRONT BS6	TATA spare parts
259186900130	CANOPY ASSY BS6	TATA spare parts
259186900134	CANOPY MTG ASSY FRONTFLASELH BS6-PH2	TATA spare parts
259186900141	CANOPY ASSY BS6-PH2	TATA spare parts
259186900143	CANOPY MTG ASSY FRONT-RH BS6-PH2	TATA spare parts
259186900144	COVER ASSY CANOPY BS6-PH2	TATA spare parts
259186902301	WINDSHIELD PANE BS6-PH2	TATA spare parts
259188460101	BUMPER ASSY BS6	TATA spare parts
259188500101	ASSY BUMPER COMPLETE	TATA spare parts
259188500103	ASSY BUMPER SKIRT	TATA spare parts
259188500108	BUMPER ASSY WITH MTG BRACKET	TATA spare parts
259188500109	BUMPER ASSY WITH MTG BRACKET BS6	TATA spare parts
259188500110	BUMPER ASSY LH BS6	TATA spare parts
259188500111	BUMPER ASSY RH BS6	TATA spare parts
259188508228	END COVER BUMPER BS6	TATA spare parts
259188508233	BRACKET BS6	TATA spare parts
259188508234	BRACKET BS6	TATA spare parts
259188700101	ASSY.ENGINE HOOD COMPLETE-RHD	TATA spare parts
259188700102	ASSY COMPOSITE INSULATION GLASS FABRIC	TATA spare parts
259188700121	ENGINE HOOD ASSY WITH INSULATION BS6-PH2	TATA spare parts
259188706313	COVER PLATE HOOD BS6-PH2	TATA spare parts
259188707701	SEALING RUBBER-ENGINE HOOD	TATA spare parts
259189100102	ASSY BKT.RH (COWL MTG.REAR)	TATA spare parts
259189100106	ASSY.COWL MTG. BKT REAR RH	TATA spare parts
259189100109	ASSY BRACKET(AIR FILTER MTG)	TATA spare parts
259189100110	ASSY SPACE PLATE (INNER SIDE)	TATA spare parts
259189100111	ASSY SPACE PLATE (BRACKET SIDE)	TATA spare parts
259189100114	OUTRIGGER ASSY COWL MTG FRONT-LH	TATA spare parts
259189100115	OUTRIGGER ASSY COWL MTG FRONT-RH	TATA spare parts
259189100116	BRACKET ASSY REAR-RH	TATA spare parts
259189100117	OUTRIGGER ASSY COWL MTG FRONT-LH	TATA spare parts
259189100118	OUTRIGGER ASSY COWL MTG FRONT-RH	TATA spare parts
259189100119	BRACKET ASSY REAR-LH	TATA spare parts
259189100120	SUPPORT ASSY RH	TATA spare parts
259189100130	BRACKET ASSY	TATA spare parts
259189100132	BRACKET ASSY REAR-RH BS6	TATA spare parts
259189100136	CAB MOUNT ASSY BS6	TATA spare parts
259189100141	CHANNEL ASSY CAB MTG BS6	TATA spare parts
259189100142	BRACKET ASSY AIR FILTER MTG BS6	TATA spare parts
259189100151	SUPPORT ASSY FRONT-RH&BS6	TATA spare parts
259189100152	SUPPORT ASSY FRONT-LH&BS6	TATA spare parts
259189100154	CAB MOUNT ASSY&BS6	TATA spare parts
259189100155	PLATE ASSY BS6	TATA spare parts
259189100156	CAB MOUNT ASSY&BS6	TATA spare parts
259189100157	BRACKET ASSY	TATA spare parts

259189100164	CAB MOUNT ASSY BS6	TATA spare parts
259189100168	SUPPORT ASSY FRONT-LH BS6-PH2	TATA spare parts
259189100169	SUPPORT ASSY FRONT-RH BS6-PH2	TATA spare parts
259189100171	OUTRIGGER ASSY COWL MTG FRONT-LH BS6	TATA spare parts
259189100172	OUTRIGGER ASSY COWL MTG FRONT-RH BS6	TATA spare parts
259189100177	BRACKET ASSY REAR-RH BS6	TATA spare parts
259189100178	CAB MOUNT ASSY BS6-PH2	TATA spare parts
259189100179	SUPPORT ASSY FRONTFLASELH BS6-PH2	TATA spare parts
259189100186	CAB MOUNT ASSY BS6-PH2	TATA spare parts
259189100191	CHANNEL ASSY CAB MTG BS6-PH2	TATA spare parts
259189100192	CAB MOUNT ASSY BS6-PH2	TATA spare parts
259189100194	CHANNEL ASSY CAB MTG BS6-PH2	TATA spare parts
259189107701	PACKAGING REAR(COWL MTG.REAR RH)	TATA spare parts
259189107707	BALATA PACKING	TATA spare parts
259189107710	BALATA PACKING BS6	TATA spare parts
259189107711	BALATA PACKING BS6	TATA spare parts
259189107712	BALATA PACKING BS6	TATA spare parts
259189107716	BALATA PACKING BS6	TATA spare parts
259189107717	BALATA PACKING BS6	TATA spare parts
259189107723	BALATA PACKING BS6-PH2	TATA spare parts
259189108227	BRACKET REAR BS6	TATA spare parts
259189108259	BRACKET REAR BS6	TATA spare parts
259189108262	BRACKET REAR BS6	TATA spare parts
259189130101	SUPPORT ASSY FRONT-LH BS6	TATA spare parts
259189130102	CHANNEL ASSY CAB MTG BS6	TATA spare parts
259189130103	CAB MOUNT ASSY BS6	TATA spare parts
259191000101	DRIVER SEAT ASSY	TATA spare parts
259191700111	ASSY.SEAT STAND (HYBRID BUS)	TATA spare parts
259191700112	ASSY AUXILIARY PIPE	TATA spare parts
259191700113	BRACKET ASSY SEAT MTG	TATA spare parts
259191700115	BRACKET ASSY SEAT MTG BS6	TATA spare parts
259191758601	SPACER	TATA spare parts
259191980101	CUSHION ASSY BS6	TATA spare parts
259191980102	BACK REST CUSHION BS6	TATA spare parts
259191980103	HEADREST ASSY BS6	TATA spare parts
259191990101	KIT-SEAT	TATA spare parts
259255100103	MASCOT ASSY	TATA spare parts
259255100104	MASCOT ASSY	TATA spare parts
259255100105	MASCOT ASSY	TATA spare parts
259255100108	MASCOT ASSY	TATA spare parts
259255100110	MASCOT ASSY	TATA spare parts
259255100112	MASCOT ASSY	TATA spare parts
259255100114	MASCOT ASSY BS6	TATA spare parts
259255100119	MASCOTASSY BS6	TATA spare parts
259255100121	MASCOT ASSY	TATA spare parts
259255110101	MASCOT ASSY BS6-PH2	TATA spare parts
259260100114	COWL SHELL PAINTED LPT1613TC	TATA spare parts

259260100121	COWL W/FITMENTS LP 1512TC EURO-II	TATA spare parts
259260100122	COWL W/FITMENTS LPT 1512TC P/STR EURO-II	TATA spare parts
259260100125	ASSY COWL COMP WITH FITMENTS RHD	TATA spare parts
259260100126	ASSY COWL SHELL PAINTED RHD	TATA spare parts
259260100133	ASSY.COWL COMPLETE WITH FITMENT-RHD	TATA spare parts
259260100134	ASSY COWL COMPLETE WITH FITMENTS-RHS	TATA spare parts
259260100135	ASSY.COWL SHELL PAINTED-RHD	TATA spare parts
259260100141	ASSY.COWL1512TC COMPL.WITH FIT W/O FACE	TATA spare parts
259260100161	LPT 1613 TC E-II PSTG COMPLETE COWL	TATA spare parts
259260100163	ASSY COWL SHELL PAINTED RHD 1613 EURO-II	TATA spare parts
259260100167	ASSY COWL COMP WITH FITMENTS RHD	TATA spare parts
259260100168	ASSY COWL SHELL PAINTED RHD	TATA spare parts
259260100171	ASSY REINF.COMP (CLUTCH PEDAL_MTG.) BS6	TATA spare parts
259260100180SJ	COWL FOR LP1512TC WITH FITMENTS-RHD	TATA spare parts
259260100181	ASSY COWL SHELL PAINTED-RHD	TATA spare parts
259260100185	COWL COMP LPT 1615/42 697 TCIC BS III	TATA spare parts
259260100187	ASSY COWL COMPFITS W/O FACE-RHD LP 1510	TATA spare parts
259260100188	ASSY COWL COMPLETE WITH FITS.(LP1512-497	TATA spare parts
259260100189	ASSY COWL PAINTED-RHD LP1512/497 BS-III	TATA spare parts
259260106001	STAY ROD-CENTRE FLAP	TATA spare parts
259260108217	GUSSET BS6	TATA spare parts
259260110108	ASSY COWL COMPL WITH FITMENTS (W/O FACE)	TATA spare parts
259260110109	ASSY COWL SHELL PAINTED	TATA spare parts
259260110111	ASSY COWL COMPL WITH FITMENTS 1512 BS3	TATA spare parts
259260110112	ASSY COWL SHELL PAINTED	TATA spare parts
259260110115	ASSY COWL SHELL PAINTED LP 1512 TC	TATA spare parts
259260110119	ASSYCOWL COMP FOR LP 1512 TC/59	TATA spare parts
259260110127	ASSY BRACKET LH(SIDE BLINKER MTG.)	TATA spare parts
259260110128	ASSY BRACKET RH(SIDE BLINKER MTG.)	TATA spare parts
259260110129	ASSY COWL SHELL PAINTED	TATA spare parts
259260110135	ASSY COWL COMP WITH FITMENTS-RHD	TATA spare parts
259260110136	ASSY.COWL COMPLETE WITH FITMENTS-RHD	TATA spare parts
259260110136SJ	COWL COMPLETE& FITMENTS-RHDSPARE PARTS	TATA spare parts
259260110141	ASSY BRACKET ECU MTG (SPEED LIMITER)	TATA spare parts
259260110144	ASSY COWL COMPELETE WITH FITMENTS	TATA spare parts
259260110145	ASSY COWL COMPL WITH FITMENTS	TATA spare parts
259260110151SJ	ASSY COWL CMPL WITH FITMENT 3118TC SPARE	TATA spare parts
259260110160	ASSY COWL COMPLETE WITH FITMENTS	TATA spare parts
259260110161	ASSY COWL SHELL PAINTED (BARE COWL)	TATA spare parts
259260110174	ASSY COWL COMPLETE WITH FITMENTS	TATA spare parts
259260110174SJ	LPT3118TCBS3 ASY COWLCOMP& SPARE PARTS	TATA spare parts
259260110175SJ	COWL COMPLETE& FITMENTS SPAREPART	TATA spare parts
259260110179	ASSY.COWL COMPLETE 2518 TC BSIII-RHD	TATA spare parts
259260110180	ASSY. COWL BARE PAINTED RHD BS2/3	TATA spare parts
259260110185	ASSY.COWL COMP.WITH FITMENTS RHD	TATA spare parts
259260110185SJ	ASSY.COWL COMP.WITH FITMENTS RHD_SPARE P	TATA spare parts
259260110190	CROSS FRAME ASSY FRONT	TATA spare parts

259260110193	ASSY.COWL SHELL PAINTED RHD	TATA spare parts
259260120101	ASSY. COWL BARE RHD BS3/4	TATA spare parts
259260120111	ASSY.COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
259260120111SJ	ASSY.COWL COMPLETE WITH FITMENTS RHD SP	TATA spare parts
259260120124	ASSY.KIT-ASSY.COWL SHELL PANITED FOR SPD	TATA spare parts
259260120125	ASSY.COWL COMP.WITH FITMENTS RHD	TATA spare parts
259260120145	ASSY COWL COMPLETE WITH FITMENT RHD	TATA spare parts
259260120148	ASSY FES SHELL PAINTED RHD	TATA spare parts
259260120150	ASSY COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
259260120150SJ	ASSY COWL COMP WITH FITMENTS RHD_SPARE P	TATA spare parts
259260120151	ASSY. COWL SHELL PAINTED RHD BS3/4	TATA spare parts
259260120155	COWL ASSY WITH FITMENTS	TATA spare parts
259260120155SJ	ASSY COWL COMPLETE WITH FITMENTS RHD SP	TATA spare parts
259260120157	ASSY COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
259260120157SJ	LPT2518BSIII ERGO COWL FITTED_SPARE PART	TATA spare parts
259260120161	ASSY COWL KIT W/PARTIAL FITMENTS LPT2518	TATA spare parts
259260120162	ASSY COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
259260120162SJ	ASSY. COWL COMP. RHD LPT3118TC SP BS3	TATA spare parts
259260120164	ASSY COWL COMPLETE WITH FITMENTS	TATA spare parts
259260120164SJ	ASSY. COWL WITH FITMENTS BS3/4/6	TATA spare parts
259260120176	COWL SHELL ASSY IN WHITE BS6	TATA spare parts
259260120179	ASSY COWL SHELL PAINTED RHD	TATA spare parts
259260120183	ASSY COWL COMPL WITH FITMENT	TATA spare parts
259260120186	ASSY.COWL COMPLETE WITH FITMENTS-RHD	TATA spare parts
259260120186SJ	ASSY. COWL COMPLETE W/FITMENTS-RHD BS3	TATA spare parts
259260120187	COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
259260120187SJ	ASSY. COWL COMP. ERGO PACK SP BS3	TATA spare parts
259260120188	ASSY.COWL COMPLETE WITH FITMENTS R	TATA spare parts
259260120188SJ	ASSY.COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
259260120189	ASSY.COWL SHELL PAINTED -RHD	TATA spare parts
259260120193	COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
259260120193SJ	ASSY.COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
259260130140	ASSY. COWL SHELL PAINTED 2518/3118 RHD	TATA spare parts
259260130150	COWL ASSY WITH FITMENT	TATA spare parts
259260130151	COWL SHELL ASSY PAINTED	TATA spare parts
259260130156	FESASSY PAINTED	TATA spare parts
259260130158SJ	ASSY. COWL COMPLETE W/ FITMENTS-RHD BS3	TATA spare parts
259260130159	FESASSYWITHFITMENT	TATA spare parts
259260130160	FESASSY PAINTED	TATA spare parts
259260130162	FACELESS END STRUCTURE ASSY WITH FITMENT	TATA spare parts
259260130164	COWL SHELL ASSY PAINTED	TATA spare parts
259260130170	FESASSY PAINTED	TATA spare parts
259260130173	CROSS FRAME ASSY FRONT	TATA spare parts
259260130192	ASSY. COWL SHELL PAINTED BS4	TATA spare parts
259260130194	COWL SHELL ASSY PAINTED	TATA spare parts
259260130195	ASSY. COWL SHELL PAINTED BS4/6	TATA spare parts
259260130198	COWL SHELL ASSY PAINTED	TATA spare parts

259260140101	FRONT PANEL ASSY RH	TATA spare parts
259260140119	COWL SHELL ASSY PAINTED	TATA spare parts
259260140122	COWL SHELL ASSY IN WHITE BS6	TATA spare parts
259260140123	BRACKET ASSY ECU MTG BS6	TATA spare parts
259260140127	BRACKET ASSY ECU MTG	TATA spare parts
259261100157	SUBSTRUCTURE ASSY WITH FLOOR	TATA spare parts
259261110114	SUBSTRUCTURE ASSY WITH FLOOR	TATA spare parts
259261110118	SUBSTRUCTURE ASSY WITH FLOOR	TATA spare parts
259261110119	SUBSTRUCTURE ASSY WITH FLOOR	TATA spare parts
259261600111	ASSY.WHEEL ARCH RH-RHD.	TATA spare parts
259261600118	ASSY.BRACKET(HORN MOUNTING)	TATA spare parts
259261600130	ASSY BONNET FRONT COMPLETE-RHD	TATA spare parts
259261600163	ASSY EXTN WHEEL ARCH LH	TATA spare parts
259261600164	ASSY EXTN. WHEEL ARCH RH	TATA spare parts
259261600167	ASSY BONNET FRONT COMPLETE-RHD	TATA spare parts
259261600191	ASSY BONNET FRONT COMPLETE RHD	TATA spare parts
259261608268	EXTN. WHEEL ARCH LH	TATA spare parts
259261608269	EXTN. WHEEL ARCH RH	TATA spare parts
259261610101	ASSY BONNET FRONT COMPLETE RHD	TATA spare parts
259261610136	BONNET ASSY FRONT	TATA spare parts
259261610137	BONNET ASSY FRONT	TATA spare parts
259261610165	COWL ASSY BS6	TATA spare parts
259261618201	REINFORCEMENT(LONG MEMBER & ASSY SUBSTR	TATA spare parts
259262500104	ASSY.CENTER FLAP	TATA spare parts
259262508204	BRACKET (FOR LOCATION) BS6	TATA spare parts
259268400103	ASSY FLOOR MAT	TATA spare parts
259268900101	ASSY INSTRUMENT PANEL	TATA spare parts
259268900103	ASSY INSTRUMENT PANEL LPT2515TC	TATA spare parts
259268900106	ASSY. IP & IP COVER BS2/3/4/6	TATA spare parts
259268900107	ASSY.NACELLE-(1210 FACE)	TATA spare parts
259268900112	NACELLE ASSY REAR	TATA spare parts
259268906302	NACELLE TOP	TATA spare parts
259268906303	NACELLE BOTTOM	TATA spare parts
259268906308	NACELLE FRONT	TATA spare parts
259268906309	NACELLE REAR	TATA spare parts
259268906311	NACELLE FRONT	TATA spare parts
259268906314	CAP DASHBOARDBS6	TATA spare parts
259270000101	KIT ASSY SUPD	TATA spare parts
259270000102	KIT ASSY SUPD	TATA spare parts
259270000103	KIT ASSY SUPD	TATA spare parts
259270000104	KIT ASSY SUPD	TATA spare parts
259270108204	BRACKET FRONT LH	TATA spare parts
259270108205	BRACKET FRONT RH	TATA spare parts
259270108206	BRACKET END LH	TATA spare parts
259270108207	BRACKET END RH	TATA spare parts
259270108208	BRACKET MIDDLE	TATA spare parts
259281100113	ASSY GUARD TIE MEMBER FRONT	TATA spare parts



259281100116	ASSY LID COMP. ELECT. BOX	TATA spare parts
259281100119	WING SCREW BS6	TATA spare parts
259281100120	ASSY REAR VIEW MIRROR OUTER RH	TATA spare parts
259281100120AE	ASSY REAR VIEW MIRROR OUTER RH	TATA spare parts
259281100125	KIT ASSY RVM COMP.FOR LP-1510/LPT1613 CL	TATA spare parts
259281100127	KIT FOR BONNET INSULATION	TATA spare parts
259281100131	ASSY. HEAD LAMP DOME BS1/2/3/4/6	TATA spare parts
259281100137	ASY ARRESTOR SPRAY SUPPRESSION	TATA spare parts
259281100139	ASSY HOUSING(WITH MIRROR) BS6	TATA spare parts
259281100140	ASSY REAR VIEW MIRROR-LH	TATA spare parts
259281100140AE	ASSY RR VIEW MIRROR COMPL. -1415	TATA spare parts
259281100141	ASSY ARRESTOR SPRAY SUPPRESION	TATA spare parts
259281100142	ASSY. HEAD LAMP COVER	TATA spare parts
259281100147	ASSY REAR VIEW MIRROR COMPLETE RH	TATA spare parts
259281100147AE	REAR VIEW MIRROR RH CANOPY 1415	TATA spare parts
259281100148	ASSY PANEL VENTILATION GRILL	TATA spare parts
259281100174	FOAM INSULATION BS6	TATA spare parts
259281100183	KIT-BONNET INSULATION	TATA spare parts
259281101602	STICKER SUPER MILO	TATA spare parts
259281102001	INSULATION LH BONNET	TATA spare parts
259281102002	INSULATION RH BONNET	TATA spare parts
259281102003	INSULATION-RHD BONNET CE	TATA spare parts
259281106301	HEAD LAMP DOME LH-RHD	TATA spare parts
259281106303	AIR FILTER COVER	TATA spare parts
259281106305	CLAMP (CENTRE FLAP STAY ROD)	TATA spare parts
259281106306	COVER (ENGINE HOOD HINGE)	TATA spare parts
259281106308	MUDFLAP LH-SPRAY SUPPRESSION	TATA spare parts
259281106310	SLEEVE(STAY ROD)	TATA spare parts
259281106311	ASSY MUD FLAP(SPRAY SUPPRESION)S.M.AUTO	TATA spare parts
259281106313	REFLECTIVE TAPE-SIDE	TATA spare parts
259281106314	REFLECTIVE TAPE-CENTER	TATA spare parts
259281106316	MUDFLAP SPRAY SUPPRESION	TATA spare parts
259281106317	COVER-WIPER MOTOR	TATA spare parts
259281106318	COVER WIPER MOTOR M/S PACOLINE BS6	TATA spare parts
259281106321	WHEEL ARCH EXTENSION LH	TATA spare parts
259281106322	WHEEL ARCH EXTENSION RH	TATA spare parts
259281106325	CLAMPING ANGLE(COVER WIPER MOTOR)M/S PE	TATA spare parts
259281106326	CLAMPING ANGLE-M/S AUROINCH BS6	TATA spare parts
259281106327	BEADING WHEEL ARCH RH-RHD	TATA spare parts
259281106328	BEADING GUSSET-RH	TATA spare parts
259281106333	WHEEL ARCH EXTENSION LH(M/S PENWEL)	TATA spare parts
259281106334	WHEEL ARCH EXTENSION RH(M/S PENWEL)	TATA spare parts
259281106336	BEADING (SUB-ST)	TATA spare parts
259281106337	MUD FLAP(SPRAY SUPPRESSION)	TATA spare parts
259281106341	MUDFLAP SPRAY SUPPRESSION	TATA spare parts
259281106343	MUDFLAP SPRAY SUPPRESSION BS6	TATA spare parts
259281108201	CLAMPING ANGLE	TATA spare parts

259281108205	BRACKET REAR VIEW MIRROR MTG.	TATA spare parts
259281800101	ASSY.COVER LH-RHD(POWER STRG.TANK)	TATA spare parts
259281800105	TATA 1512 CUMMINS MASCOT	TATA spare parts
259281800106	ASSY MASCOT 1112 W	TATA spare parts
259281800107	ASSY TATA MASCOT	TATA spare parts
259281800111	ASSY TATA 1613 C MASCOT	TATA spare parts
259281800112	ASSY TATA 1512 C MASCOT	TATA spare parts
259281800114	ASSY TATA 1615 MASCOT	TATA spare parts
259281800115	ASSY. TATA 1512 MASCOT	TATA spare parts
259281800116	ASSY. TATA 1613 MASCOT	TATA spare parts
259281800117	ASSY COVER LH-RHD (POWER STRG.TANK.)	TATA spare parts
259281800119	ASSY.MASCOT TATA 1616	TATA spare parts
259281800122	ASSY TATA 2513 C MASCOT	TATA spare parts
259281800124	ASSY MASCOT TATA 3723C	TATA spare parts
259281800128	ASSY MASCOT	TATA spare parts
259281806301	COVER(AIR FILT)LH-RHD(POWERST.WITH C/OUT	TATA spare parts
259281806303	COVER AIR FILTER LH RHD	TATA spare parts
259281806306	COVER PLATE	TATA spare parts
259281900107	ASSY ENGINE SHIELDING LH RHD	TATA spare parts
259281900109	ASSY ENGINE SHIELDING RH RHD	TATA spare parts
259281900113	ASSY ENGINE SHEILDING LH	TATA spare parts
259281900114	ASSY.ENGINE SHEILDING RH	TATA spare parts
259281900119	ASSY ENGINE SHIELDING LH-RHD 2515TC	TATA spare parts
259281900121	ASSY ENGINE SHIELDING RH-RHD	TATA spare parts
259281900123	ASSY.ENGINE SHIELDING RH-RHD	TATA spare parts
259281900124	ASSY.ENGINE SHIELDING LH-RHD	TATA spare parts
259281900129	ASSY.ENGINE SHIELDING LH-RHD	TATA spare parts
259281900131	ASSY.ENGINE SHIELDING RH-RHD	TATA spare parts
259281900135	ASSY ENGINE SHIELDING LH-RHD 2515TC	TATA spare parts
259281900137	ASSY ENGINE SHIELDING RH-RHD	TATA spare parts
259281900141	ENGINE SHIELDING ASSY LH	TATA spare parts
259281900143	ENGINE SHIELDING ASSY RH	TATA spare parts
259281900146	ENGINE SHIELDING ASSY RH BS6	TATA spare parts
259281900147	ENGINE SHIELDING ASSY LH BS6	TATA spare parts
259281906303	FLOOR MAT-DRIVER	TATA spare parts
259281906309	FLOOR MAT-DRIVER	TATA spare parts
259281990102	KIT-FOAM INSULATION BS6	TATA spare parts
259282400102	ASSY.BRACKET(WIPER MOTOR MTG.)	TATA spare parts
259282400103	ASSY LINK ROD (WIPER MOTOR) (204MM LG)	TATA spare parts
259282408202	BRACKET-WIPER MOTOR MTG.	TATA spare parts
259283800107	ASSY FRONT PANEL RH RHD	TATA spare parts
259283800110	ASSY FRONT PANEL COMP.WITH VENT.UNIT RH	TATA spare parts
259283800111	ASSY.FRONT PANEL COMP.WITH VENT.UNIT RHD	TATA spare parts
259283800115	ASSY.BRACKET (ECU MTG.)	TATA spare parts
259283808201	MOUNTING BRACKET HIGH TEMP.BUZZER	TATA spare parts
259286900102	ASSY FRAME FRONT	TATA spare parts
259286900103	ASSY FRAME TOP	TATA spare parts

259286900104	ASSY FRAME REAR	TATA spare parts
259286900125	ASSY FOOT STEP RH	TATA spare parts
259286900125AE	ASSY FOOT STEP RH-1415	TATA spare parts
259286900128	ASSY RETAINER ANGLE SIDE RH BS6	TATA spare parts
259286900130	ASSY.CANOPY COVER	TATA spare parts
259286900134	ASSY FRAME TOP	TATA spare parts
259286900135	ASSY FRAME REAR	TATA spare parts
259286900137	ASSY CANOPY COMPLETE RHD	TATA spare parts
259286900149	SIDE SUPPORT ASSY RH BS6	TATA spare parts
259286900152	COVER ASSY CANOPY	TATA spare parts
259286900157	ASSY CANOPY COMPLETE RHD	TATA spare parts
259286900170	FRAME ASSY REAR BS6	TATA spare parts
259286900174	CANOPY STRUCTURE ASSY BS6	TATA spare parts
259286900177	CANOPY ASSY BS6	TATA spare parts
259286902501	RUBBER PROFILE HORIZONTAL BS6	TATA spare parts
259286902502	RUBBER PROFILE VERTICAL BS6	TATA spare parts
259286906703	WINDSHIELD PANE	TATA spare parts
259286907705	PACKAGING COWL MTG REAR BS6	TATA spare parts
259286907706	PACKAGING COWL MTG FRONT-LH BS6	TATA spare parts
259286907707	PACKAGING COWL MTG FRONT-RH BS6	TATA spare parts
259286907708	PACKAGING COWL MTG FRONT BS6	TATA spare parts
259286908218	RETAINER ANGLE SIDE BS6	TATA spare parts
259286908220	RETAINER ANGLE TOP BS6	TATA spare parts
259288500101	ASSY.ANTISAGGING BAR	TATA spare parts
259288500102	ASSY.SUPPORT LH ANTI SAGGING BAR	TATA spare parts
259288500103	ASSY.SUPPORT RH ANTISAGGING BAR	TATA spare parts
259288500107	ASSY.SUPPORT-LH(FOR BUMPER)	TATA spare parts
259288500108	ASSY.SUPPORT-RH(FOR BUMPER)	TATA spare parts
259288500113	ASSY.BRACKET(BUMPER SUPPORT)	TATA spare parts
259288500114	ASSY BUMPER COMPLETE	TATA spare parts
259288500114C0	ASSY. BUMPER W/BLACK REFLECTOR BS2/3/4	TATA spare parts
259288500126	ASSY BUMPER COMP.WITH REFLECTOR	TATA spare parts
259288500135	ASSY.BUMPER COMPLETE WITH REFLECTOR (W/C	TATA spare parts
259288500138C0	ASSY.BUMPER COMPLETE (WITHOUT END BRACK	TATA spare parts
259288500139C0	ASSY.BUM COMP W/T END BRACKET_PAINTED	TATA spare parts
259288500140	ASSY. FRONT BUMPER BS3/4/6	TATA spare parts
259288500140C0	ASSY BUMPER WITH REFLECTOR - BLACK	TATA spare parts
259288500143	BRACKET ASSY BUMPER SUPPORT MTG LH	TATA spare parts
259288500144	BRACKET ASSY BUMPER SUPPORT MTG RH	TATA spare parts
259288500146	BRACKET ASSY BUMPER SUPPORT	TATA spare parts
259288500148	BRACKET ASSY BUMPER SUPPORT MTG LH	TATA spare parts
259288500149	BRACKET ASSY BUMPER SUPPORT MTG RH	TATA spare parts
259288506301	END COVER(BUMPER)	TATA spare parts
259288506302	BEZEL (HEAD LAMP)	TATA spare parts
259288506305	END COVER BUMPER LH(M/S INOVA)	TATA spare parts
259288506306	END COVER BUMPER RH	TATA spare parts
259288508242	SUPPORT SIDE LH	TATA spare parts

259288508243	SUPPORT SIDE RH	TATA spare parts
259288508251	SUPPORT BUMPER MTG LH	TATA spare parts
259288508252	SUPPORT BUMPER MTG RH	TATA spare parts
259288508259	SUPPORT BUMPER MTG LH BS6	TATA spare parts
259288508260	SUPPORT BUMPER MTG RH BS6	TATA spare parts
259288700103	ASSY TOGGLE CLAMP	TATA spare parts
259288700104	ASSY.BASE PLATE LPT 1613TC BELLOW	TATA spare parts
259288700110	ASSY. ENGINE HOOD COMP. BS4/6	TATA spare parts
259288700111	ASSY ENGINE HOOD COMPLETE	TATA spare parts
259288700115	ASSY ENGINE HOOD COMP.RHD	TATA spare parts
259288700118	ASSY HINGE (ENGINE HOOD)	TATA spare parts
259288700129	ASSY ENGINE HOOD COMPLETE RHD	TATA spare parts
259288700130	ASSY ENGINE HOOD COMPLETE RHD	TATA spare parts
259288706002	STAY ROD(ENGINE HOOD)	TATA spare parts
259288706303	ENGINE HOOD HINGE TYPE-RHD	TATA spare parts
259288707701	SEALING RUBBER-ENG.HOOD	TATA spare parts
259288707702	SEALING RUBBER E/HOOD	TATA spare parts
259288707703	SEALING RUBBER E/HOOD	TATA spare parts
259288707704	SEALING RBR ENGINE HOOD BS1/2/3/4/6	TATA spare parts
259288708203	CLAMPING PLATE(E/HOOD BASE PLATE)	TATA spare parts
259289100103	ASSY.BRACKET LH REAR MTG	TATA spare parts
259289100104	ASSY BRACKET LH(REAR MTG)/RH	TATA spare parts
259289100107	ASST BRACKET LH-COWL REAR MTG	TATA spare parts
259289100108	ASSY BRACKET RH-COWL REAR MTG	TATA spare parts
259289100109	ASSY. BRACKET LH-COWL MTG. REAR	TATA spare parts
259289100110	ASSY BRACKET RH-COWL MTG. REAR	TATA spare parts
259289100111	ASSY.BKT.LH (COWL FRONT MOUNTING)	TATA spare parts
259289100112	ASSY BRACKET LH(COWL MTGFRONT)	TATA spare parts
259289100113	ASSY BRACKET RH(COWL MTG REAR)	TATA spare parts
259289100114	ASSY BRACKET LH(COWL MTG REAR)	TATA spare parts
259289100115	ASSY.BRACKET LH(COWL MTG.FRONT)	TATA spare parts
259289100119	BRACKETASSYCOWLFRONTMTGLH	TATA spare parts
259289100120	BRACKETASSYCABMTGREAR-LH	TATA spare parts
259289100121	BRACKETASSYCABMTGREAR-RH	TATA spare parts
259289100124	BRACKET ASSY COWL MTG FRONT-LH	TATA spare parts
259289100129	BRACKET ASSY COWL MTG FRONT-LH	TATA spare parts
259289100130	BRACKET ASSY COWL MTG FRONT-LH	TATA spare parts
259289100133	BRACKET ASSY COWL MTG FRONT-LH BS6	TATA spare parts
259289100134	MOUNTING BRACKET ASSY FRONT-RH BS6	TATA spare parts
259289103701	BRACKET CAB MTG FRONT-RH	TATA spare parts
259289103702	BRACKET COWL MTG FRONT	TATA spare parts
259289103704	BRACKET COWL MTG FRONT-RH	TATA spare parts
259289107703	PACKING COWL MTG FRONT	TATA spare parts
259289200101	ASSY.BRACKET LH(COWL MTG.REAR)	TATA spare parts
259289200102	ASSY.BRACKET RH(COWL MTG.REAR)	TATA spare parts
259289200103	BRACKET ASSY COWL MTG REAR-LH	TATA spare parts
259289200104	BRACKET ASSY COWL MTG REAR-RH	TATA spare parts

259289200105	BRACKET ASSY CAB MTG REAR-LH BS6	TATA spare parts
259289200106	BRACKET ASSY CAB MTG REAR-RH BS6	TATA spare parts
259291000103	ASSY DRIVER SEAT WEB TYPE W/O BELT	TATA spare parts
259291000104	ASSY DRIVER SEAT CANE TYPE	TATA spare parts
259291000105	ASSY DR.SEAT COMPL.WEB TYPE RHD W/O BELT	TATA spare parts
259291000106	ASSY DR.SEAT COMPL.WEB TYPE RHD	TATA spare parts
259291000106AE	ASSY DR.SEAT COMPL.LPA 1415	TATA spare parts
259291000107	ASSY WEB SEAT WITH RISER	TATA spare parts
259361503204	U BOLT 4TH	TATA spare parts
259443500101	TUBE ASSY	TATA spare parts
259443500103	TUBE ASSY	TATA spare parts
259443500106	TUBE ASSY	TATA spare parts
259443500109	TUBE ASSY	TATA spare parts
259443500110	TUBE ASSY	TATA spare parts
259443500115	TUBE ASSY	TATA spare parts
259443500118	TUBE ASSY	TATA spare parts
259443500122	TUBE ASSY	TATA spare parts
259443500123	TUBE ASSY	TATA spare parts
259443500127	TUBE ASSY	TATA spare parts
259444100102	TUBE ASSY	TATA spare parts
259444100103	TUBE ASSY	TATA spare parts
259444100110	ASSY DOOR HINGE	TATA spare parts
259444100113	TUBE ASSY	TATA spare parts
259444105801	HOSE LP	TATA spare parts
259444110102	LEVER ASSY	TATA spare parts
259444110103	TUBE ASSY	TATA spare parts
259444110104	TUBE ASSY	TATA spare parts
259444110109	ASSY TUBE	TATA spare parts
259444116701	PIVOT PIN	TATA spare parts
259444116702	CLEVIS PIN	TATA spare parts
259444118602	SPACER	TATA spare parts
259444119201	WASHER	TATA spare parts
259444220111	LEVER ASSY	TATA spare parts
259444220112	ASSY LEVER	TATA spare parts
259444220113	LINK ROD ASSY	TATA spare parts
259444226702	PIN	TATA spare parts
259444228211	LEVER FOR MC VALVE	TATA spare parts
259444400103	HYD TANK ASSY	TATA spare parts
259445200102	ASSY. SHIFTING CYLINDER BS1/2/3/4	TATA spare parts
259451300102	PNEUMA DIR CONTROL VALVE	TATA spare parts
259463206702	PIN	TATA spare parts
259530155403	SYNCHRONISING SLEEVE 4TH AND 5TH SPEED	TATA spare parts
259624100101	ENGINE MOUNTING FRONT	TATA spare parts
259625600102	RELEASE FORK W/BALL PIN	TATA spare parts
259625605101	RELEASE FORK	TATA spare parts
259632806901	TUBE	TATA spare parts
259632807701	RUBBER BUSH	TATA spare parts

259931506701	KING PIN	TATA spare parts
259932400109	REAR SPRING ASSY	TATA spare parts
259932407119	LEAF SPRING 2ND	TATA spare parts
259932407120	LEAF SPRING 3RD	TATA spare parts
259932407151	LEAF SPRING 3RD	TATA spare parts
259932407152	LEAF SPRING 4TH	TATA spare parts
259932410102	RADIUS ROD	TATA spare parts
259932416003	RADIOUS ROD	TATA spare parts
259932504201	U CLAMP REAR	TATA spare parts
259932504202	U CLAMP	TATA spare parts
259932504203	U CLAMP	TATA spare parts
259934100113	JAW ASSY	TATA spare parts
259934103401	BUSH	TATA spare parts
259934106707	PIN	TATA spare parts
259934108701	JAW SPRING	TATA spare parts
259934108702	RETURN SPRING	TATA spare parts
259934140001	FIFTH WHEEL COUPLING	TATA spare parts
259934140101	ASSY COUPLING PLATE COMP.	TATA spare parts
259934140103	JAW ASSY	TATA spare parts
259934140104	WEDGE ASSY	TATA spare parts
259934140105	ASSY ROD	TATA spare parts
259934140106	MOUNTING LEG	TATA spare parts
259934140109	LEVER ASSY	TATA spare parts
259934146701	PIVOT PIN	TATA spare parts
259934146703	MOUNTING PIN	TATA spare parts
259934146704	WEDGE PIN	TATA spare parts
259934146705	LEVER PIN	TATA spare parts
259934146706	HANDLE PIN	TATA spare parts
259934146707	ADJUSTING PIN	TATA spare parts
259938605404	BEVEL GEAR	TATA spare parts
259939000104	ASSY.DEAD AXLE LPT 2515TC	TATA spare parts
259939000107	ASSY RA 909 WITH BRAKES W/O PARKING BR	TATA spare parts
259939000109	DEAD AXLE ASSY RA909	TATA spare parts
259939100101	REAR AXLE BEAM RA909	TATA spare parts
259939100120	ASSY RA BEAM	TATA spare parts
259939100121	DEAD AXLE BEAM SCAM RA909	TATA spare parts
259939100124	ASSY R A BEAM TRAILING AXLE LPT2515TC	TATA spare parts
259939100125	ASSY.REAR AXLE BEAM LPT 2515TC	TATA spare parts
259939105110	BRACKET-S-CAM BRG BLOCK MTG	TATA spare parts
259939600102	ASSY RR HUB W/O BRG RA909	TATA spare parts
259942810101	CONNECTING LINE	TATA spare parts
259943506802	ADAPTER	TATA spare parts
259943506803	ADAPTOR	TATA spare parts
259943790103	RELAY VALVE	TATA spare parts
259943790104	KIT REP RELAY EMERG VALVE	TATA spare parts
259943797702	O RING	TATA spare parts
260001175801	HOSE	TATA spare parts

260007100104	LEVER A/CYL W/BALL PIN	TATA spare parts
260007100108	ASSY PULL ROD COMPLETE 697	TATA spare parts
260009120106	FUEL LINE FILT-THERMOSTOP	TATA spare parts
260009120108	FUEL LINE THERMOSTOP-FIP	TATA spare parts
260009120109	FUEL LINE COMP RE	TATA spare parts
260009135803	RUBBER HOSE (AIR FILTER TO AIR INTAKE TU	TATA spare parts
260015240101	ALTERNATOR 24V/29A	TATA spare parts
260015240102	ALTERNATOR-24V 35AMPS D/GROOVE	TATA spare parts
260015240103	ALTERNATOR-24V 35AMPS D/GROOVE BS2/3	TATA spare parts
260015240104	ALTERNATOR-24V 35AMPS D/GROOVE	TATA spare parts
260015400101	ALTERNATOR 12V/53A	TATA spare parts
260015400102	ALTERNATOR 12V 53A(W/DOUBLE GRVD) PULLEY	TATA spare parts
260015400103	ALTERNATOR-12V 55A D/GROOVE PULLEY-OFFER	TATA spare parts
260015400104	ALTERNATOR 12V 53A(W/DOUBLE GRVD) PULLEY	TATA spare parts
260020125802	RUBBER HOSE	TATA spare parts
260020156301	V BELT COGGED 1090MM	TATA spare parts
260020156302	V BELT COGGED 980MM BS1/2/3/4	TATA spare parts
260020600111	FAN BLADE	TATA spare parts
260020600114	SLIDER ASSY RE	TATA spare parts
260020600118	MOUNTING BLOCK	TATA spare parts
260020600120	MTG.BLOCK W/BRG BLK&IDLIN	TATA spare parts
260020600128	IDLER UNIT RE	TATA spare parts
260020600130	BEARING HOUSING	TATA spare parts
260020600131	ASSY SWIVEL LEVER	TATA spare parts
260020603402	SPACER TUBE	TATA spare parts
260020606004	SWIVEL LEVER RE	TATA spare parts
260020607001	IDLER PULLEY	TATA spare parts
260020607002	PULLEY FAN	TATA spare parts
260020607003	PULLEY FAN	TATA spare parts
260020607005	IDLER PULLEY-RE	TATA spare parts
260020607901	PULLEY SHAFT	TATA spare parts
260020607904	SHAFT-BEARING BLOCK 1313 RE	TATA spare parts
260020608206	FAN REVERSE FLOW	TATA spare parts
260020608302	SHIM	TATA spare parts
260025600102	RELEASE FORK W/BALL PIN	TATA spare parts
260026700102	CONNECTING FLANGE SUBASSY	TATA spare parts
260026700105	SPINDLE SMALL SUBASSY	TATA spare parts
260026700106	SPINDLE BIG SUBASSY	TATA spare parts
260026700108	SPINDLE BIG SUBASSY	TATA spare parts
260026700109	SPINDLE MEDIUM SUBASSY	TATA spare parts
260026706302	ROLLER	TATA spare parts
260026706901	CONNECTING TUBE	TATA spare parts
260026707901	SELECTOR & SHIFTER SHAFT	TATA spare parts
260026709901	PIN	TATA spare parts
260026800113	SUB ASSY BRACKET FOR MTG DOME	TATA spare parts
260026800138	ASSY BRACKET PULLEY CROSS MEMBER 3&5	TATA spare parts
260026800159	ASSY.GEAR SHIFT LEVER	TATA spare parts

260026807115	SPACER FLANGE	TATA spare parts
260026807701	RUBBER BELLOW	TATA spare parts
260029100101	CL MASTER CYL	TATA spare parts
260029100102	SLAVE CYLINDER	TATA spare parts
260029100112	LEVER ASSY	TATA spare parts
260029100122	KIT CLUTCH	TATA spare parts
260029100123	REP KIT CL SLAVE CYL	TATA spare parts
260029100149	REP KIT CL MASTERS CYL	TATA spare parts
260029100150	REP KIT MAJ CL SLAVE CYL	TATA spare parts
260029100151	R/KIT(MINOR)CL.SLAVE CYL.	TATA spare parts
260029106802	SOCKET	TATA spare parts
260029306003	CLUTCH ROD 1616 4X4	TATA spare parts
260029500116	BRACKET FOR GEAR BOX	TATA spare parts
260030100133	ASSY PULL ROD COMPLETE	TATA spare parts
260030100154	ASSY THRUST ROD	TATA spare parts
260030100174	ASSY THRUST ROD	TATA spare parts
260030100178	ASSY BELL CRANK COMPLETE RH	TATA spare parts
260030100193	ASSY. PULL ROD	TATA spare parts
260030103404	BUSH	TATA spare parts
260031200111	RUBBER BUFFER	TATA spare parts
260031207104	CROSS MEMBER RR SPRING	TATA spare parts
260031207105	CROSS MEMBER 5 TH	TATA spare parts
260031208205	PACKING	TATA spare parts
260031307110	SUPPORT	TATA spare parts
260032400104	REAR SPRING ASSY	TATA spare parts
260032400107	REAR SPRING ASSY	TATA spare parts
260032400108	MAIN LEAF REAR 1313RE	TATA spare parts
260041120101	PROP SHAFT 90X3X210 RE/59	TATA spare parts
260041120104	RUBBER BOOT	TATA spare parts
260041120120	RUBBER BOOT	TATA spare parts
260041127501	RUBBER BOOT	TATA spare parts
260041127502	RUBBER BOOT	TATA spare parts
260042300110	ASSY.BRACKET LH	TATA spare parts
260042300111	ASSY.BRACKET RH	TATA spare parts
260042903302	BRACKET	TATA spare parts
260042903309	BRACKET	TATA spare parts
260042904201	CLAMP	TATA spare parts
260042906801	TEE SOCKET	TATA spare parts
260043503307	BRACKET BS6-PH2	TATA spare parts
260046100109	ASSY. STG. COL. SUPPORT COMP.	TATA spare parts
260046803301	BRACKET	TATA spare parts
260046804201	CLAMP	TATA spare parts
260046806801	DOUBLE SOCKET RE	TATA spare parts
260046806802	DOUBLE SOCKET	TATA spare parts
260047608201	PLATE	TATA spare parts
260050003308	BRACKET RADIATOR FRAME MTG	TATA spare parts
260050100111	RADIATOR ASSY	TATA spare parts



260050100116	RADIATOR ASSY 1313 RE	TATA spare parts
260050100124	CAP AUX WATER TANK	TATA spare parts
260050100127	PIPE RAD-THERMO TOP RE	TATA spare parts
260050100129	RADIATOR ASSY WITH DRAIN PLUG	TATA spare parts
260050100132	RADIATOR ASSY WITH DRAIN PLUG	TATA spare parts
260050105801	RUBBER HOSE	TATA spare parts
260050105802	RUBBER HOSE	TATA spare parts
260050105803	RUBBER HOSE	TATA spare parts
260050105808	HOSE RADIATOR TO W/PUMP	TATA spare parts
260050105809	RUBBER HOSE	TATA spare parts
260050105810	RUBBER HOSE	TATA spare parts
260050105812	HOSE AUX TANK TO RADIATOR	TATA spare parts
260050105813	HOSE RADIATOR TO AUX TANK	TATA spare parts
260050105814	RUB HOSE PIPE TO W P PIPE	TATA spare parts
260050109902	RUBBER STRAP	TATA spare parts
260050508201	FAN SHROUD	TATA spare parts
260054200112	HOSE 500MM	TATA spare parts
260054209903	WATER TEMP GAUGE ELEC	TATA spare parts
260054509901	STARTER RELAY	TATA spare parts
260058900102	ASSY HOSE 10500MM LONG	TATA spare parts
26010000001	HINGE ASSY (WITHOUT HANDLE) (PC)	TATA spare parts
26010000003	HINGE ASSY(PASS DOOR-W/O HANDLE) (PC)	TATA spare parts
26010000004	HINGE ASSY(PASS DOOR-WITH HANDLE) (PC)	TATA spare parts
26010000009	HINGE ASSY (WITH HANDLE) (PC)	TATA spare parts
260131208202	TABLE PACKING PLATE	TATA spare parts
260140100104	WHEEL DISC RIM B7.0HDX20	TATA spare parts
260141110122	ASSY.PROP.SHAFT WITH CENTRE BRG L=1876	TATA spare parts
260146805801	HOSE LP 3/4	TATA spare parts
260188700103	ASSY NUT PLATE(E/HOOD TOGGLE CLAMP)	TATA spare parts
260232406701	SPRING PIN	TATA spare parts
260425400101	CL PR PLATE 280 DIA	TATA spare parts
260425400102	CL PR PLATE 280 DIA	TATA spare parts
260425400107	REP KIT 280D PR PLATE MNR	TATA spare parts
260426800101	TURNING ROD	TATA spare parts
260426800102	BRACKET ASSY	TATA spare parts
260426803701	SHIFTING YOKE	TATA spare parts
260426807701	PROTECTIVE CAP	TATA spare parts
260429100101	CLUTCH PEDAL LEVER	TATA spare parts
260429300101	CL CONTROL BRACKET	TATA spare parts
260429300104	INTERM LEVER CL CONTROL	TATA spare parts
260429300108	CLUTCH ROD	TATA spare parts
260429306001	PULL ROD	TATA spare parts
260429306003	CLUTCH ROD RH	TATA spare parts
260429306004	CLUTCH ROD LH	TATA spare parts
260429306902	TUBE ASSEMBLY	TATA spare parts
260429307108	PLATE SUPPORT	TATA spare parts
260429308202	LOCK WASHER	TATA spare parts

260429308701	SPRING CLUTCH RETURN	TATA spare parts
260430100101	ACCELERATOR PULL ROD	TATA spare parts
260430100102	THRUST ROD	TATA spare parts
260430100103	LEVER ACCELERATOR	TATA spare parts
260430106002	LINK ROD	TATA spare parts
260430106301	RUBBER PAD ACCL PEDAL	TATA spare parts
260431000101	ASSY.FRAME LP807/36-RHD	TATA spare parts
260431000102	FRAME ASSY LPT807/36	TATA spare parts
260431000103	FRAME ASSY LP807/32 BUS	TATA spare parts
260431000104	FRAME ASSY LPT807/32	TATA spare parts
260431207101	SUPPORT ENG CR MEMBER FR	TATA spare parts
260431500101	TOWING HOOK	TATA spare parts
260431700103	ASSY.BRACKET LH CAB MTG.FR	TATA spare parts
260431700105	ASSY. CAB MOUNTING	TATA spare parts
260431708201	BKT RADIATOR RH	TATA spare parts
260432100101	FRONT SPRING ASSY TRUCK	TATA spare parts
260432100102	FRONT SPRING ASSY BUS	TATA spare parts
260432107101	LEAF SPRING 1ST FRT	TATA spare parts
260432107102	LEAF SPRING 2ND FRT	TATA spare parts
260432107103	LEAF SPRING 3RD FRT	TATA spare parts
260432107104	LEAF SPRING 4TH FRT	TATA spare parts
260432107105	LEAF SPRING 5TH FRT	TATA spare parts
260432107106	LEAF SPRING 6TH FRT	TATA spare parts
260432107107	LEAF SPRING 7TH FRT	TATA spare parts
260432107108	LEAF SPRING 8TH FRT	TATA spare parts
260432107109	LEAF SPRING 9TH FRT	TATA spare parts
260432107110	PLATE	TATA spare parts
260432107112	LEAF SPRING 2ND FRT	TATA spare parts
260432400101	REAR SPRING ASSY W/AUX	TATA spare parts
260432400102	REAR SPRING ASSY	TATA spare parts
260432400104	ASSY.BRACKET REAR SPRING	TATA spare parts
260432403201	GUIDE PLATE	TATA spare parts
260432403701	BRACKET SPRING REAR	TATA spare parts
260432407102	LEAF SPRING 2ND RR	TATA spare parts
260432407103	LEAF SPRING 3RD RR	TATA spare parts
260432407104	LEAF SPRING 4TH RR	TATA spare parts
260432407105	LEAF SPRING 5TH RR	TATA spare parts
260432407106	SIXTH LEAF	TATA spare parts
260432407107	SEVENTH LEAF	TATA spare parts
260432407108	EIGHTH LEAF	TATA spare parts
260432407109	NINETH LEAF	TATA spare parts
260432407110	LEAF SPRING AUX 1ST	TATA spare parts
260432407111	LEAF SPRING 2ND AUX	TATA spare parts
260432407113	LEAF SPRING 4TH AUX	TATA spare parts
260432407114	LEAF SPRING 5TH AUX	TATA spare parts
260432407116	LEAF SPRING 2ND RR	TATA spare parts
260432407117	LEAF SPRING 3RD RR	TATA spare parts

260432407118	LEAF SPRING 4TH RR	TATA spare parts
260432408201	STIFFENER	TATA spare parts
260432500101	SPRING SHACKLE RR SPRING	TATA spare parts
260432500102	LEAF SPRING 1ST FRT	TATA spare parts
260432503402	BUSH	TATA spare parts
260432503403	BUSH RR SPRING SHACKLE	TATA spare parts
260432506701	SPRING PIN REAR	TATA spare parts
260432800101	ASSY SHACKLE	TATA spare parts
260432800103	ASSY ANTI ROLL BAR	TATA spare parts
260432803701	BRACKET	TATA spare parts
260432803801	CLAMP SUPPORT	TATA spare parts
260432804201	U CLAMP	TATA spare parts
260432807103	PLATE	TATA spare parts
260432807704	BEARING BLOCK RUBBER	TATA spare parts
260432809901	ANTI ROLL BAR	TATA spare parts
260433000101	FRONT AXLE ASSY W/BR RHD	TATA spare parts
260433100101	RUBBER BUFFER	TATA spare parts
260433103201	U CLAMP	TATA spare parts
260433105105	FRONT AXLE BEAM	TATA spare parts
260433400101	HUB FRONT WHEEL W/BRG	TATA spare parts
260433400102	HUB FRONT WHEEL W/BRG	TATA spare parts
260433403101	TAPER ROLLER BRG 30312	TATA spare parts
260433405102	HUB FRONT W/O BRG	TATA spare parts
260433405103	HUB FRONT SPIGOTTED	TATA spare parts
260433800101	ASSY TIE ROD	TATA spare parts
260433805101	STEERING ARM RH	TATA spare parts
260433805102	STEERING ARM LH	TATA spare parts
260435000101	REAR AXLE LP807 W/BR 41/7	TATA spare parts
260435000102	REAR AXLE LPT807 W/BR41/6	TATA spare parts
260435000106	REAR AXLE LP807 W/BR 41/7	TATA spare parts
260435000117	REAR AXLE LP807 W/BR 37/7	TATA spare parts
260435000121	REAR AXLE LPT807 W/BR41/7	TATA spare parts
260435000127	REAR AXLE W/BR 100WX408D	TATA spare parts
260435000139	RR AXLE W/BR 41/7 100X400	TATA spare parts
260435000142	REAR AXLE ASSY COMP	TATA spare parts
260435100105	REAR AXLE HOUSING	TATA spare parts
260435100106	REAR AXLE HOUSING LPT	TATA spare parts
260435100112	COVER W/PLUG	TATA spare parts
260435100113	REAR AXLE HOUSING	TATA spare parts
260435100119	REAR AXLE HSG W/STUDS 909	TATA spare parts
260435100121	COUPLING FLANGE	TATA spare parts
260435104201	U CLAMP REAR	TATA spare parts
260435105102	FLANGE ON REAR AXLE	TATA spare parts
260435300101	DIFFERENTIAL ASSY 41/7 GL	TATA spare parts
260435300102	HOUSING DIFFERENTIAL W/CO	TATA spare parts
260435300103	CWP SET 41/7 GLEA LP807	TATA spare parts
260435300103AE	ASSY CROWN -PINION 713 715	TATA spare parts

260435300104	DIFFERENTIAL ASSY GLEASON	TATA spare parts
260435300105	KIT DIFFERENTIAL GEAR	TATA spare parts
260435300106	CWP SET 41/7 OERL LPT909/1009/1109TC	TATA spare parts
260435300107	DIFFERENTIAL ASSY 41/7 OR	TATA spare parts
260435300107AE	DIFF CASE CAST SLOW -1415-713/5	TATA spare parts
260435300108	DIFFERENTIAL ASSY 48/9 GL	TATA spare parts
260435300109	CWP SET 48/9	TATA spare parts
260435300111	CWP SET 37/7 OERL	TATA spare parts
260435300116	DIFFERENTIAL ASSY	TATA spare parts
260435303102	BEARING TAPER ROLLER	TATA spare parts
260435303104	BEARING CYL ROLLER	TATA spare parts
260435303105	TAPER ROLLER BRG	TATA spare parts
260435305401	GLEASON CROWN WHEEL (41/7)	TATA spare parts
260435305402	PINION - CWP:41/7-0103GL	TATA spare parts
260435305403	REAR AXLE SHAFT GEAR 18T	TATA spare parts
260435308307	SHIM 1.00 THICK	TATA spare parts
260435308308	SHIM 0.50MM	TATA spare parts
260435308309	SHIM 0.25MM	TATA spare parts
260435308310	SHIM 0.10MM	TATA spare parts
260435308601	PINION SPACER	TATA spare parts
260435308627	SPACER RING 8.65MM	TATA spare parts
260435308628	SPACER RING 8.67MM	TATA spare parts
260435308629	SPACER RING 8.69 THICK	TATA spare parts
260435308630	SPACER RING 8.71MM	TATA spare parts
260435308631	SPACER RING 8.73 THICK	TATA spare parts
260435308632	SPACER RING 7.75MM	TATA spare parts
260435308633	SPACER RING 8.77 THICK	TATA spare parts
260435308634	SPACER RING - 8.79 THK.	TATA spare parts
260435308635	SPACER RING 8.81MM	TATA spare parts
260435308636	SPACER RING - 8.83 THK	TATA spare parts
260435308637	SPACER RING 8.85 MM	TATA spare parts
260435308641	SPACER RING - 8.93 THK	TATA spare parts
260435308658	SPACER RING 9.11MM	TATA spare parts
260435308659	SPACER BETWEEN BRGS	TATA spare parts
260435308660	SPACER BETWEEN BRGS	TATA spare parts
260435600101	ASY HUB REAR	TATA spare parts
260435600102	REAR HUB W/BEARING	TATA spare parts
260435600103	KITASYREARHUBWITHMTGPINS-SP-PTS	TATA spare parts
260435600104	REAR HUB W/O BEARING	TATA spare parts
260435600105	HUB ASSY REAR	TATA spare parts
260435600107	ASSY REAR HUB W/O BRGS	TATA spare parts
260435600108	ASSY HUB WITH BEARING (REAR WHEEL)	TATA spare parts
260435608201	OIL CATCHER CR50494	TATA spare parts
260435707901	REAR AXLE SHAFT	TATA spare parts
260435707902	REAR AXLE SHAFT	TATA spare parts
260435707903	REAR AXLE SHAFT	TATA spare parts
260435707904	REAR AXLE SHAFT	TATA spare parts

260440300001	DISC WHEEL	TATA spare parts
260440300002	WHEEL DISC & RIM 6X20	TATA spare parts
260440300102	WHEEL DISC & RIM	TATA spare parts
260441100101	PROP SHAFT FR 70X3 W/CB	TATA spare parts
260441100102	PROPELLER SHAFT FRONT	TATA spare parts
260441100108	PROPELLER SHAFT REAR	TATA spare parts
260441100109	PROP SHAFT RR 70DX1273	TATA spare parts
260442103701	BRAKE DRUM FRONT	TATA spare parts
260442300101	ASSEMBLY HAND BRAKE SHAFT	TATA spare parts
260442606001	PULL ROD	TATA spare parts
260443100102	TANDEM MASTER CYL	TATA spare parts
260443100104	KIT REP MAJOR TMC 23.81	TATA spare parts
260443100105	KIT REP MINOR TMC	TATA spare parts
260443100107	TANDEM MASTER CYL	TATA spare parts
260443100108	AIR CYLINDER	TATA spare parts
260443106601	PLUNGER PRIMARY 610	TATA spare parts
260443106602	PLUNGER SECONDARY 610	TATA spare parts
260443107102	BRACKET AIR CYLINDER	TATA spare parts
260443108001	STOP SCREW	TATA spare parts
260443108701	SPRING PRIMARY	TATA spare parts
260443720101	AIR CYLINDER	TATA spare parts
260443720105	PISTON SUB ASSY.	TATA spare parts
260443730103	SINGLE TRADLE VALVE	TATA spare parts
260443760101	UNLOADER VALVE	TATA spare parts
260446000102	ASSY DRAG LINK	TATA spare parts
260446100102	SUPPORT STRG COLUMN	TATA spare parts
260446100103	SUPPORT STRG COLUMN	TATA spare parts
260446106301	RUBBER BELLOW	TATA spare parts
260446305102	PITMAN ARM 807	TATA spare parts
260446400101	STRG WHEEL	TATA spare parts
260446400102	STRG WHEEL	TATA spare parts
260446400103	ASSY COVER	TATA spare parts
260447100105	SUCTION TUBE	TATA spare parts
260447100107	FUEL TANK 90 LTR	TATA spare parts
260447500101	SUPPORT W/STRAP	TATA spare parts
260447500102	SUPPORT	TATA spare parts
260447507701	RUBBER STRAP TOP	TATA spare parts
260447507702	RUBBER STRAP BOTTOM	TATA spare parts
260449100101	SILENCER W/TAIL PIPE	TATA spare parts
260449200101	EXHAUST PIPE	TATA spare parts
260449200102	EXHAUST PIPE FRONT	TATA spare parts
260449200103	BRACKET ASSY	TATA spare parts
260449204203	CLAMP	TATA spare parts
260449205301	GASKET EXHAUST PIPE	TATA spare parts
260450008801	PULL ROD	TATA spare parts
260454017701	COVER BATTERY	TATA spare parts
260454048201	HEAD LAMP RIM	TATA spare parts

260454400101	HEAD LAMP RH RHD	TATA spare parts
260454400102	HEAD LAMP LH RHD	TATA spare parts
260454400103	HEAD LAMP RH RHD	TATA spare parts
260454400109	INDICATOR LAMP ENG OIL	TATA spare parts
260454408201	RIM HEAD LAMP	TATA spare parts
260454509901	OIL PRESSURE SWITCH	TATA spare parts
260462500101	FACE SIDE LH	TATA spare parts
260462500102	FACE SIDE RH	TATA spare parts
260466064701	STEP BOARD	TATA spare parts
260467102301	W/S GLASS LP807	TATA spare parts
260467106301	RUB MOULD W/S GLASS LH	TATA spare parts
260468096301	INSTRUMENT PANEL	TATA spare parts
260468096302	GLOVE BOX LID	TATA spare parts
260468096303	PIN HOLDER LH	TATA spare parts
260468096304	PIN HOLDER RH	TATA spare parts
260469010101	FRONT PANNEL W/VENT LH	TATA spare parts
260469010102	FRONT PANNEL W/VENT RH	TATA spare parts
260475100105	CENTRE FLAP COMPLT	TATA spare parts
260482046001	LINK ROD 100MM	TATA spare parts
260482048201	MTG PLATE WIPER MOTOR	TATA spare parts
260482400102	WIPER ARM 440MM RHD	TATA spare parts
260482400103	ASSY WIPER BLADE	TATA spare parts
260488050101	BUMPER W/O FITMENTS	TATA spare parts
260488050102	BUMPER COMPLETE	TATA spare parts
260488050103	BUMPER SUPPORT	TATA spare parts
260488070105	ENGINE HOOD	TATA spare parts
260488077706	SEALING FRONT	TATA spare parts
260488077707	SEALING BOTTOM	TATA spare parts
260498040101	TATA BADGE	TATA spare parts
260498040102	LETTER A	TATA spare parts
260498040103	LETTER T	TATA spare parts
260539000109	ASSY.REAR AXLE RA908 COMPLETE WITH S'CAM	TATA spare parts
260539100115	RR AXLE BEAM 2213/SCAM	TATA spare parts
260539100116	RR AXLE BEAM 2213/SCAM	TATA spare parts
260640308601	SPACER	TATA spare parts
260825603101	CL RELEASE BRG	TATA spare parts
260825606701	PIN	TATA spare parts
260825608701	LOCKING WIRE	TATA spare parts
260826700102	SPINDLE 319MM L	TATA spare parts
260826800102	GEAR SHIFT LEVER RHD	TATA spare parts
260826803401	BUSH	TATA spare parts
260826807702	PROTECTIVE CAP	TATA spare parts
260829100110	TUBE W/ROD	TATA spare parts
260829100118	ASSY PEDAL	TATA spare parts
260829100121	ASSY CLUTCH LEVER	TATA spare parts
260829106601	PUSH ROD CL MASTER CYL	TATA spare parts
260829109201	WASHER	TATA spare parts

260829300103	CL PULL ROD	TATA spare parts
260829305801	RUBBER HOSE	TATA spare parts
260829308701	REDUAL SPRING	TATA spare parts
260829308702	WRONG PART NUMBER	TATA spare parts
260830100129	BRACKET ASSY	TATA spare parts
260830107903	SHAFT ACCELERATOR-RHD	TATA spare parts
260831000110	FRAME 1313/59 RE ASRTU	TATA spare parts
260832300107	ASSY SHOCK ABSORBER BRKT LH	TATA spare parts
260832300108	ASSY SHOCK ABSORBER BRKT RH	TATA spare parts
260832308001	PIN MOUNTING	TATA spare parts
260832308002	MOUNTING PIN	TATA spare parts
260832308603	SPACER	TATA spare parts
260833000112	FRONT AXLE SCAM 1313 RE	TATA spare parts
260835000130	REAR AXLE 1313RE SCAM47/8	TATA spare parts
260841120101	PROP SHAFT 90X3X390 RE/51	TATA spare parts
260842300108	BRACKET LH	TATA spare parts
260842300109	BRACKET RH	TATA spare parts
260842700108	ROD ASSY	TATA spare parts
260843500127	ASSY SEALING RING BS6	TATA spare parts
260843506801	DOUBLE SOCKET SCAM	TATA spare parts
260843509201	THRUST RING	TATA spare parts
260843720101	AIR CYLINDER 150D X 75	TATA spare parts
260843720102	AIR CYLINDER 150D X 75	TATA spare parts
260843720111	KIT REP AIR CYLINDER	TATA spare parts
260846000109	DRAG LINK ASSY FRONT	TATA spare parts
260846000111	DRAG LINK REAR RE	TATA spare parts
260846000121	KIT REP DRAG LINK	TATA spare parts
260846100103	SUPPORT STRG COLUMN	TATA spare parts
260846108001	HEX SCREW	TATA spare parts
260846300107	INT PITMAN ARM W/BKT	TATA spare parts
260846303101	TAPER ROLLER BEARING	TATA spare parts
260846303103	TAPER ROLLER BEARING	TATA spare parts
260846303104	TAPER ROLLER BEARING	TATA spare parts
260846303701	CAP-MASSOP	TATA spare parts
260846303702	BRACKET	TATA spare parts
260846306002	PITMAN ARM	TATA spare parts
260846306004	PITMAN ARM-RE	TATA spare parts
260846306006	INTERMEDIATE PITMAN ARM	TATA spare parts
260846307901	SHAFT	TATA spare parts
260846308601	SPACER RING	TATA spare parts
260846308602	PRESSURE RING	TATA spare parts
260846309204	TONGUED WASHER	TATA spare parts
260846800155	TUBE ASSY	TATA spare parts
260849200110	EXHAUST PIPE FRONT	TATA spare parts
260854100117	ASSY BATT. CABLE (LINK) (70 MM2)	TATA spare parts
260854200101	DIODE MODULE	TATA spare parts
260854200103	BUZZER UNIT	TATA spare parts

260854200104	BUZZER UNIT	TATA spare parts
260854200105	BUZZER UNIT	TATA spare parts
260854200106	BUZZER UNIT	TATA spare parts
260854200107	BUZZER UNIT	TATA spare parts
260854200108	BUZZER UNIT	TATA spare parts
260854200109	BUZZER UNIT	TATA spare parts
260854203301	BRACKET CABLE	TATA spare parts
260854249901	GAUGE OIL PRESSURE ELECT	TATA spare parts
260854249902	TEMP GAUGE 24V ELEC	TATA spare parts
260854249905	TEMP GAUGE ELEC	TATA spare parts
260854249907	GAUGE OIL PRESSURE ELECT	TATA spare parts
260854249908	VOLT METER	TATA spare parts
260854400101	INDICATOR LAMP TEMP	TATA spare parts
260854449901	RELAY 24 VOLT	TATA spare parts
260854504901	STARTER RELAY 24V	TATA spare parts
260854504901AE	RELAY-TYPE 4ST (24V) 2523-1628	TATA spare parts
260854540101	FUSE BOX 24V 5AMP	TATA spare parts
260854540102	FUSE BOX 24V 5AMP	TATA spare parts
260854540111	HAZARD WARNING SWITCH 24V	TATA spare parts
260854540112	FUSE BOX 24V 5AMP	TATA spare parts
260854544601	FLASHER KIT 24V	TATA spare parts
260854549901	RELAY 24V W/O RESISTOR	TATA spare parts
260854549902	RELAY 24V-E.D.	TATA spare parts
260854600110	CABLE SET INSTRUMENT	TATA spare parts
260858409901	CAUTION PLATE	TATA spare parts
26101337	N TERMINAL	TATA spare parts
261015100101	STARTER MOTOR	TATA spare parts
261015100601	C E BRACKET ASSY	TATA spare parts
261015100901	FIELD COIL ASSY	TATA spare parts
261015101301	FIXING BRKT ASSY	TATA spare parts
261015101302	LEVER & PEG ASSY	TATA spare parts
261015101303	DRIVE ASSY	TATA spare parts
261015101304	PLUNGER ASSY	TATA spare parts
261015101401	BRUSH GEAR ASSY	TATA spare parts
261015101501	ARMATURE ASSY	TATA spare parts
261015101705	TERMINAL BASE ASSY	TATA spare parts
261015101708	SOLENOID TERMINAL	TATA spare parts
261015103301	BUSH FIXING BKT	TATA spare parts
261015103302	BUSH INTER BRACKET	TATA spare parts
261015103401	SOLENOID SWITCH	TATA spare parts
261015104901	C E BUSH	TATA spare parts
261015105302	SEALING RING D E	TATA spare parts
261015105304	INSUL BUSH FIELD TERMINAL	TATA spare parts
261015105305	SEALING RING C E	TATA spare parts
261015105306	SEALING BUSH	TATA spare parts
261015105502	SPINDLE ASSY	TATA spare parts
261015107101	FIELD COIL ASSY	TATA spare parts



261015107301	INTER BRACKET ASSY	TATA spare parts
261015107501	GROMMET	TATA spare parts
261015107502	GASKET	TATA spare parts
261015109204	INSULATION WASHER	TATA spare parts
261015109301	BRUSH SPRING	TATA spare parts
261015109303	PLUNGER SPRING	TATA spare parts
261015109306	BRUSH SET	TATA spare parts
261015401401	D E BRACKET ASSY	TATA spare parts
261015401402	S R E BRACKET ASSY	TATA spare parts
261015401403	BRUSH BOX	TATA spare parts
261015401404	BRUSH SPG STUD & CON ASSY	TATA spare parts
261015402501	STATOR ASSY	TATA spare parts
261015402502	ROTOR ASSY	TATA spare parts
261015402801	SLIP RING	TATA spare parts
261015403301	DE BEARING	TATA spare parts
261015403302	SRE BEARING	TATA spare parts
261015403401	D E INSERT	TATA spare parts
261015404505	KIT COVER MOULD	TATA spare parts
261015404601	KIT BRUSH REPLACEMENT	TATA spare parts
261015404602	KIT BRUSH BOX REPLACEMENT	TATA spare parts
261015404603	KIT SP DIODE	TATA spare parts
261015404604	KIT DE BRG REPLACEMENT	TATA spare parts
261015405901	KEY	TATA spare parts
261015406001	FUSE LINK ASSY	TATA spare parts
261015406501	SHAFT NUT	TATA spare parts
261015407001	PULLEY	TATA spare parts
261015407101	DE BRG RETAINER PLATE	TATA spare parts
261015407801	MOULD DUST SEAL	TATA spare parts
261015407802	SEAL BRUSH BOX	TATA spare parts
261015407803	SEAL BRUSH BOX	TATA spare parts
261015408008	RECTIFIER FIXING SCREW	TATA spare parts
261015409301	BRUSH PLATE ASSY	TATA spare parts
261015409503	REGULATOR	TATA spare parts
261015409901	SURGE PROTECTION DIODE	TATA spare parts
261015409903	REGULATOR	TATA spare parts
261015409904	RECTIFIER	TATA spare parts
261024109201	WASHER	TATA spare parts
261026407502	RUBBER BELLOW	TATA spare parts
261026408202	COVE PLATE	TATA spare parts
261026700101	KNOB	TATA spare parts
261029100101	CLUTCH PEDAL LEVER	TATA spare parts
261029100110	ASSY BRAKE PEDAL	TATA spare parts
261029200101	CLUTCH PEDAL PLATE	TATA spare parts
261029300124	ASSY.BRAKE PEDAL LEVER	TATA spare parts
261029306003	ADJUSTING LINK	TATA spare parts
261030100103	LEVER ACCELERATOR	TATA spare parts
261030103801	PEDAL ACCELERATOR	TATA spare parts

261030107701	RUBBER GROMMET	TATA spare parts
261031000103	FRAME	TATA spare parts
261031000104	FRAME	TATA spare parts
261031000105	ASSY FRAME COMPLETE	TATA spare parts
261031000113	FRAME ASSY LPT807/36 RHD	TATA spare parts
261031200104	ENGINE CROSS MEMBER	TATA spare parts
261031207118	END CROSS MEMBER	TATA spare parts
261032100103	LEAF SPRING 1ST W/BUSH	TATA spare parts
261032100104	LEAF SPRING 1ST FRT	TATA spare parts
261032300101	BRACKET ASSY	TATA spare parts
261032300103	BRACKET ASSY LH	TATA spare parts
261032300104	BRACKET ASSY RH	TATA spare parts
261032400101	LEAF SPRING 1ST RR	TATA spare parts
261032400102	LEAF SPRING 1ST W/BUSH	TATA spare parts
261032400103	LEAF AUX SPG	TATA spare parts
261032400108	REAR SPRING ASSY	TATA spare parts
261033800101	TIE ROD ASSEMBLY	TATA spare parts
261033800103	ASSY TIE ROD	TATA spare parts
261033805101	STEERING ARM RH	TATA spare parts
261033990101	KIT END ASSY LH	TATA spare parts
261033990102	KIT END ASSY RH	TATA spare parts
261035104201	U CLAMP (REAR STRING MOUNTING)	TATA spare parts
261040300116	ASSY CARRIER - SPARE WHEEL	TATA spare parts
261040300401	ASSY.CARRIER FOR SPARE WH	TATA spare parts
261041100101	SPACER ASSY	TATA spare parts
261042100106	INTERMEDIATE SHAFT	TATA spare parts
261042136302	BRAKE LINING STD RR	TATA spare parts
261042136303	BRAKE LINING RS1	TATA spare parts
261042136304	BRAKE LINING RS2	TATA spare parts
261042303701	BRAKE DRUM REAR	TATA spare parts
261042308001	SCREW	TATA spare parts
261042800109	BRAKE TUBE	TATA spare parts
261042800110	BRAKE TUBE	TATA spare parts
261042800111	BRAKE TUBE	TATA spare parts
261042800113	BRAKE TUBE	TATA spare parts
261042800114	BRAKE TUBE	TATA spare parts
261042800115	BRAKE TUBE	TATA spare parts
261042800116	BRAKE TUBE	TATA spare parts
261042800117	BRAKE TUBE	TATA spare parts
261042800118	BRAKE TUBE	TATA spare parts
261042907701	RUBBER STRIP	TATA spare parts
261043100104	BRAKE FLUID CONTAINER	TATA spare parts
261043500101	TUBE ASSY	TATA spare parts
261043500107	TUBE ASSY	TATA spare parts
261043500108	TUBE ASSY	TATA spare parts
261043500116	TUBE ASSY	TATA spare parts
261043500118	HOSE ASSY 3/8	TATA spare parts

261043500119	HOSE ASSY 3/8	TATA spare parts
261043500120	TUBE ASSY	TATA spare parts
261043500121	TUBE ASSY	TATA spare parts
261043500122	TUBE ASSY	TATA spare parts
261043500125	HOSE ASSY 3/8	TATA spare parts
261043500127	TUBE ASSY	TATA spare parts
261043500128	TUBE ASSY	TATA spare parts
261043500129	TUBE ASSY	TATA spare parts
261043508202	BRACKET	TATA spare parts
261043508207	BRACKET	TATA spare parts
261043508208	BRACKET HYD LINE (ON SUPPORT CAB MTG)	TATA spare parts
261043720103	AIR CYLINDER	TATA spare parts
261043720106	PISTON ASSY	TATA spare parts
261043730101	KIT REP D TREDDLE VALVE	TATA spare parts
261043760104	UNLOADER VALVE WITH FILTE	TATA spare parts
261046000103	DRAG LINK ASSY 909 RHD	TATA spare parts
261046035102	PITMAN ARM	TATA spare parts
261046100103	ASSY STRG BRACKET	TATA spare parts
261046106301	RUBBER BELLOW	TATA spare parts
261046106302	RUBBER BELLOW	TATA spare parts
261046107903	STRG SPINDLE BOTTOM	TATA spare parts
261046108601	SPACER MTG PIN	TATA spare parts
261046109201	PLAIN WASHER	TATA spare parts
261046305101	PITMAN ARM	TATA spare parts
261046305102	PITMAN ARM	TATA spare parts
261047600101	FUEL SUCTION LINE	TATA spare parts
261047600102	OVER FLOW RETURN LINE	TATA spare parts
261047600103	FUEL LINE 10 X 0.7 X 220	TATA spare parts
261047600107	OVER FLOW LINE	TATA spare parts
261049100105	SILENCER ASSY	TATA spare parts
261049204205	CLAMP	TATA spare parts
261054100108	BATTERY CABLE -VE	TATA spare parts
261054200104	PIPE OIL PRESSURE GAUGE	TATA spare parts
261054200105	PIPE OIL PRESSURE GAUGE	TATA spare parts
261054209903	SPEEDOCABLE 2600MM	TATA spare parts
261054209904	SPEEDOMETER 0.92	TATA spare parts
261054209907	SPEEDOCABLE 2600MM	TATA spare parts
261054400102	HEAD LAMP LH	TATA spare parts
261054400103	HEAD LAMP RH	TATA spare parts
261054400119	ASSY.HEAD LAMP WITH BULBS	TATA spare parts
261054400120	ASSY HEAD LAMP	TATA spare parts
261054400121	HEAD LAMP RH	TATA spare parts
261054400122	HEAD LAMP LH	TATA spare parts
261054400125	ASSY.HEAD LAMP WITH BULB RH LHD	TATA spare parts
261054400126	ASSY.HEAD LAMP WITH BULB LH LHD	TATA spare parts
261054404301	CLAMP LENS HOLDING	TATA spare parts
261054407702	RUB PACKING-HSG H/LAMP	TATA spare parts

261054409901	LENS HEAD LAMP RH	TATA spare parts
261054409902	LENS HEAD LAMP LH	TATA spare parts
261054409909	COVER FOR 4-CHAMBER TAIL LAMP	TATA spare parts
261054409910	COVER FOR 4-CHAMBER TAIL LAMP	TATA spare parts
261054500103	COMBI SWITCH	TATA spare parts
261054500104	COMBI SWITCH	TATA spare parts
261054500107	HAZARD WARNING SWITCH	TATA spare parts
261054508210	STRIP	TATA spare parts
261054509904	SWITCH DIFFERENTIAL LOCK	TATA spare parts
261054509904AE	DIFFRNTL LCK SW-713/5-1628-1828	TATA spare parts
261054600102	CABLE SET FRT TO TAIL 32	TATA spare parts
261054600103	CABLE SET FRT TO TAIL 32	TATA spare parts
261058900103	ATTACHMENT ENG STAND	TATA spare parts
261058900304	ADAPTER C SHAFT	TATA spare parts
261058902501	FIXTURE DIAPHRAM CL	TATA spare parts
261058902601	CLAMP REMOVAL OF MS & DS	TATA spare parts
261058902602	GAUGE SHIFTER SLEEVE	TATA spare parts
261058904601	PULLER PITMAN ARM	TATA spare parts
261060000120	COWL BARE RHD CR5048701	TATA spare parts
261067102301	W/S GLASS LH	TATA spare parts
261067102302	W/S GLASS RH	TATA spare parts
261067102312	W/S GLASS LH	TATA spare parts
261067102313	W/S GLASS RH	TATA spare parts
261067102315	W/S GLASS LH	TATA spare parts
261067102316	W/S GLASS RH	TATA spare parts
261067102318	W/S GLASS LH LAMINATED	TATA spare parts
261067102319	W/S GLASS RH	TATA spare parts
261067102322	W/S GLASS LH	TATA spare parts
261067102323	W/S GLASS RH	TATA spare parts
261067102324	W/S GLASS LH LAMINATED	TATA spare parts
261067102324AE	W/S GLASS LH LAMINATED	TATA spare parts
261067102325	W/S GLASS RH	TATA spare parts
261067102501	FILLER PROFILE	TATA spare parts
261067102511	FILLER PROFILE	TATA spare parts
261067106301	RUBBER MOULDING LH	TATA spare parts
261067106302	RUBBER MOULDING RH	TATA spare parts
261067106303	RUBBER MOULDING	TATA spare parts
261067106312	RUBBER MOULDING LH	TATA spare parts
261067106313	RUBBER MOULDING RH	TATA spare parts
261067106315	RUBBER MOULDING RH	TATA spare parts
261067106316	RUBBER MOULDING LH	TATA spare parts
261067106317	RUBBER MOULDING RH	TATA spare parts
261068906306	HANDLE GLOVE BOX	TATA spare parts
261068906307	GLOVE BOX LID 610	TATA spare parts
261068906309	STAY BKT./LP909 V-1/	TATA spare parts
261068906310	INSTRUMENT PANEL FR	TATA spare parts
261072000101	DOOR ASSY COMPLT LH	TATA spare parts

261072000102	DOOR ASSY COMPLT RH	TATA spare parts
261072300101	DOOR HINGE LH & RH	TATA spare parts
261072307701	RUBBER STOPPER	TATA spare parts
261072307702	SEALING PROFILE DOOR	TATA spare parts
261072308201	SPACER	TATA spare parts
261072500111	ASSY.GUIDE CHANNEL R.GLASS	TATA spare parts
261072500114	GLASS PANEL LH WINDOW	TATA spare parts
261072500115	GLASS PANEL RH WINDOW	TATA spare parts
261072500116	WINDOW REGULATOR LH	TATA spare parts
261072500117	WINDOW REGULATOR RH	TATA spare parts
261072502302	GLASS PANE	TATA spare parts
261072502501	VELVET CHANNEL	TATA spare parts
261075100104	HINGE LH CENTRE FLAP	TATA spare parts
261075100105	HINGE RH CENTRE FLAP	TATA spare parts
261075106902	STAY ROD LH CEN FLAP	TATA spare parts
261075200101	T EMBLEM	TATA spare parts
261081100112	RV MIRROR	TATA spare parts
261081103302	BKT REAR VIEW MIRROR	TATA spare parts
261081106301	MUD FLAP REAR	TATA spare parts
261081108201	CHANNEL MUD FLAP REAR	TATA spare parts
261081708201	CAB NUMBER PLATE	TATA spare parts
261082046001	LINK ROD RH 100MM	TATA spare parts
261082400102	WIPER BLADE	TATA spare parts
261082400103	KIT WIPER MOTOR	TATA spare parts
261082400104	WIPER ARM	TATA spare parts
261082400107	KIT WIPER MOTOR	TATA spare parts
261082400110	KIT WIPER MOTOR	TATA spare parts
261082400112	WIPER ARM 595 M DRIVE	TATA spare parts
261082400113	WIPER ARM GUIDE	TATA spare parts
261082400114	CLIP	TATA spare parts
261082400115	WIPER BLADE 650	TATA spare parts
261082400124	KIT WIPER MOTOR	TATA spare parts
261082400140	KIT PENTOGRAPH	TATA spare parts
261082406003	LINK ROD 460 LG	TATA spare parts
261082406004	LINK ROD 180 LG	TATA spare parts
261082406005	LINK ROD 440 LG	TATA spare parts
261082406006	LINK ROD 240 LG	TATA spare parts
261082409201	TAPER WASHER LP609/709	TATA spare parts
261082409902	WIPER MOTOR 17W	TATA spare parts
261082409902AE	WIPER MOTOR 17W 713	TATA spare parts
261082409904	WIPER MOTOR 17W HI-POWER	TATA spare parts
261082409905	WIPER MOTOR 17W	TATA spare parts
261088500101	BUMPER COMP 909	TATA spare parts
261088707701	RUBBER BELLOW	TATA spare parts
261088707705	RUBBER PROFILE	TATA spare parts
261088707710	RUBBER BELOW ENG HOOD	TATA spare parts
261089100103	COWL MOUNTING PAD	TATA spare parts

261091700105	BRACKET SEAT MTG RH	TATA spare parts
261091708205	BRACKET SEAT MTG	TATA spare parts
261098080101	MASCOT 807	TATA spare parts
261098080102	T EMBLEM	TATA spare parts
261098080103	MASCOT 807	TATA spare parts
261098080104	T EMBLEM	TATA spare parts
261098080105	T EMBLEM	TATA spare parts
261225600101	RELEASE FORK W/BALL PIN	TATA spare parts
261233403101	THRUST BEARING	TATA spare parts
261233403107	THRUST BEARING STD & STD1	TATA spare parts
261235300103	PIN ADJUSTING	TATA spare parts
261235303101	TAPER ROLLER BRG 32211 BS4	TATA spare parts
261235303101AE	TAPER ROLLER BEARING 1415 715	TATA spare parts
261235308003	HEX SCREW	TATA spare parts
261235308201	LOCKING PLATE	TATA spare parts
261235308202	LOCKING PLATE	TATA spare parts
261235603102	TAPER ROLLER BEARING BS2/3	TATA spare parts
261235606501	LOCKING RING	TATA spare parts
261235608201	OIL CATCHER	TATA spare parts
261235608202	LOCKING PLATE	TATA spare parts
261235608601	SPACER	TATA spare parts
26130317	10MM. NUT	TATA spare parts
261407153301	MTG BKT - COLD STRT PILOT	TATA spare parts
261426800102	ASSY.BRACKET(GEAR SHIFT L	TATA spare parts
261426800106	TURNING ROD RH	TATA spare parts
261426800116	ASSY LTC VALVE	TATA spare parts
261426806301	SPACER G S LEVER	TATA spare parts
261428010101	ASSY. AUX GEAR BOX BS1/2/3	TATA spare parts
261428010101AE	ASSY AUX GEAR BOX 1415 713 715	TATA spare parts
261428010102	HOUSING W/INT FLANGE	TATA spare parts
261428010103	AUX GEAR BOX ASSY	TATA spare parts
261428159901	ADAPTER	TATA spare parts
261428200101	ASSY REAR COVER COMPLT	TATA spare parts
261428203701	COVER REAR FOR LPTA 610/713	TATA spare parts
261428208601	SPACER TUBE LPTA713/1210SD	TATA spare parts
261428450116	LINK ROD AUX GR BOX	TATA spare parts
261428450125	ASSY LEVER	TATA spare parts
261428450129	ASSY LINK ROD	TATA spare parts
261428456702	PIN	TATA spare parts
261428459901	BALL END	TATA spare parts
261429200103	CLUTCH PEDAL LEVER	TATA spare parts
261429300121	CONTROL BRACKET RHD	TATA spare parts
261430100101	PULL ROD ACCELERATOR	TATA spare parts
261430100104	ASY LINK ROD	TATA spare parts
261430100105	ASSY ACCELERATOR LEVER	TATA spare parts
261430100110	ASSY ACCL LEVER (PEDAL)RH	TATA spare parts
261430103801	PEDAL ACCELERATOR	TATA spare parts

261430107701	RUBBER PAD	TATA spare parts
261430108201	RETAINING PLATE	TATA spare parts
261431000103	FRAME ASSY 610	TATA spare parts
261431000115	FRAME ASSY LPTA610/32	TATA spare parts
261431000136	ASSY FRAME	TATA spare parts
261431107116	PLATE (RADIATOR MTG.) LH	TATA spare parts
261431107154	PLATE-RADIATOR MOUNTING	TATA spare parts
261431207143	END CROSS MEMBER	TATA spare parts
261431700108	ASSY.BRACKET LH CAB MTNG.BOTTOM/LPTA610/	TATA spare parts
261431700109	ASSY BRACKET RH CAB MOUNTING	TATA spare parts
261431700110	BKT CAB MTG LH TOP	TATA spare parts
261432100106	FRONT SPRING ASSY	TATA spare parts
261432100107	LEAF SPRING 1ST W/BUSH	TATA spare parts
261432100109	FRONT SPRING ASSY	TATA spare parts
261432103205	PIN MOUNTING	TATA spare parts
261432103701	SPACER	TATA spare parts
261432104201	U CLAMP	TATA spare parts
261432107103	4TH LEAF	TATA spare parts
261432107104	5TH LEAF	TATA spare parts
261432107105	4TH LEAF	TATA spare parts
261432107106	5TH LEAF	TATA spare parts
261432350101	ASSY BRACKET LOWER R H SHK ABSR.FRT	TATA spare parts
261432350102	ASSY BRACKET LOWER L H SHK ABSR.FRT	TATA spare parts
261432400105	REAR SPRING ASSY	TATA spare parts
261432400105AE	ASSY REAR SPRING 1415 713 715	TATA spare parts
261432400108	SPACER ASSY (REAR SPRING)	TATA spare parts
261432400111	ASSY. BRACKET REAR SPG. BUMP STOP	TATA spare parts
261432403203	CENTRE PIN M12X158X11	TATA spare parts
261432403701	SPRING HANGER BKT REAR(CAST)	TATA spare parts
261433050106	FRONT AXLE HOUSING	TATA spare parts
261433050110	FRONT AXLE ASSY FA104	TATA spare parts
261433050112	ASSY FRONT AXLE COMPLETE(LIVE) LPTA 713T	TATA spare parts
261433050113	ASSY. FRONT LIVE AXLE COMPLETE WITH BRAK	TATA spare parts
261433050114	FRONT AXLE ASSY FA104	TATA spare parts
261433050120	ASSY F/A HSG LPTA 713/32	TATA spare parts
261433150102	COVER FR AXLE HOUSING	TATA spare parts
261433154202	U CLAMP	TATA spare parts
261433154204	U CLAMP LH SIDE	TATA spare parts
261433154205	U CLAMP RH SIDE	TATA spare parts
261433156901	FRONT AXLE SUPPORTING TUBE RH	TATA spare parts
261433156902	FRONT AXLE SUPPORTING TUBE LH	TATA spare parts
261433157101	BRACKET FOR BREATHER HOSE FRT AXLE	TATA spare parts
261433750101	FRONT AXLE DRIVE SFT COMP. RH GWB BS1- 4	TATA spare parts
261433750101AE	ASSY DRIVE SFT RIGHT COMPL. -713	TATA spare parts
261433750102	ASSY.DRIVE SHAFT LEFT COM	TATA spare parts
261433750102AE	ASSY. DRIVE SFT LEFT COMPL. -713	TATA spare parts
261433750107	FR AXLE DRIVE SHAFT RH	TATA spare parts

261433750108	FR AXLE DRIVE SHAFT LH	TATA spare parts
261433750109	ASSY.DRIVE SHAFT RIG	TATA spare parts
261433750110	AXLE SHAFT COMPLETE RIGHT INNER	TATA spare parts
261433800102	TIE ROD ASSY	TATA spare parts
261433800103	TIE ROD ASSY	TATA spare parts
261433800103AE	ASSY. TIE ROD 715	TATA spare parts
261433856003	STEERING ARM	TATA spare parts
261435000101	ASSY.REAR AXLE 713 DIFF LOCK 47/8	TATA spare parts
261435100101	ASSY. R.A. BEAM W/PR.RING DOWELS STUDS	TATA spare parts
261435100105	ASSY COVER REAR AXLE HOUSING	TATA spare parts
261435103301	BRACKET	TATA spare parts
261435104202	U CLAMP	TATA spare parts
261435110101	ASSY CARRIER LPT713 4X4	TATA spare parts
261435150101	ASSY. BRACKET (BREATHER HOSE)	TATA spare parts
261435154203	U CLAMP	TATA spare parts
261435159901	ADOPTER ON RA	TATA spare parts
261435300101	CWP SET 41/7 OERL	TATA spare parts
261435300104	CROWN WHEEL W/PINION	TATA spare parts
261435305404	COVER JAW DIFFERANTIAL LOCK	TATA spare parts
261435306101	LOCKING PLATE	TATA spare parts
261435707902	REAR AXLE SHAFT RH SIDE	TATA spare parts
261435707902AE	REAR AXLE SHAFT RH 713 715	TATA spare parts
261435707903	REAR AXLE SHAFT LH SIDE	TATA spare parts
261435900101	ASSY SHIFT CYLINDER	TATA spare parts
261435900101AE	ASSY. SHIFT CYLINDER 715	TATA spare parts
261435905101	FORK-DIFFERENTIAL LOCK	TATA spare parts
261435905403	ENGAGUING SLEEVE	TATA spare parts
261435905403AE	ENGAGING SLEEVE 715	TATA spare parts
261440140101	PRESSURE REGULATOR VALVE	TATA spare parts
261440303201	J-HOOK	TATA spare parts
261441100119	PROP SHAFT GB-AGB 70X199	TATA spare parts
261441100125	PROPELLER SHAFT	TATA spare parts
261441100127	PROP SHAFT AGB-FA 70X637	TATA spare parts
261441100130	PROP SHAFT FT 70X3X586	TATA spare parts
261441100132	ASSY PROPELLER SHAFT LPTA 713/32	TATA spare parts
261442100104	ASSY.FRONT AXLE BRAKE LEFT	TATA spare parts
261442100105	ASSY.FRONT AXLE BRAKE RIGHT	TATA spare parts
261442100114	ASSY FRONT BRAKE LEFT	TATA spare parts
261442100115	ASSY FRONT BRAKE RIGHT	TATA spare parts
261442130101	ASSY BRAKE SHOE WITH LINI	TATA spare parts
261442300102	ASSY REAR WHEEL BRAKE COMPLET RH	TATA spare parts
261442300103	ASSY REAR WHEEL BRAKE COMPLETE LH	TATA spare parts
261442300106	ASSY HAND BRAKE SHAFT	TATA spare parts
261442300107	ASSY.REAR WHEEL BRAKE COMPL.LH.	TATA spare parts
261442300108	ASSY.REAR WHEEL BRAKE COMPL.RH.	TATA spare parts
261442307902	HAND BRAKE SHAFT LPTA 713	TATA spare parts
261442600110	PARKING BRAKE PULL ROD	TATA spare parts



261442700101	ASSY BRACKET	TATA spare parts
261442700112	ASSY INTERMEDIATE SHAFT LH LPTA 713	TATA spare parts
261442700113	ASSY INTERMEDIATE SHAFT RH LPTA 713	TATA spare parts
261442700114	ASSY SUPPORT BRACKET(INTERMEDIATE SHAFT)	TATA spare parts
261442700136	ASSY.PIPE 12DIA.X 590LG.	TATA spare parts
261442800103	TUBE ASSY	TATA spare parts
261442800106	TUBE ASSY	TATA spare parts
261442800137	ASSY CONNECTING LINE LPTA 713	TATA spare parts
261442800153	ASSY PIPE 6DIAX1170 LG LPTA 713/32TC	TATA spare parts
261442800154	ASSY.PIPE 6DIAX740 LONG.	TATA spare parts
261442800157	ASSY PIPE 6DIAX1810 LG LPTA 713/32TC	TATA spare parts
261442800158	ASSY.PIPE 6DIAX590 LONG.	TATA spare parts
261442800162	ASSY BRACKET LPTA 713	TATA spare parts
261442800163	ASSY CONNECTING LINE LPTA 713	TATA spare parts
261442803307	BRACKET (Z-SHAPE)	TATA spare parts
261442803310	BRACKET LPTA 713	TATA spare parts
261442806802	ADAPTER FOR PCRY FITMENT LPTA 713	TATA spare parts
261442806803	SINGLE WAY UNION LPTA 713	TATA spare parts
261442806805	ADAPTER	TATA spare parts
261442806806	ADAPTER	TATA spare parts
261442900132	ASSY.PIPE 12DIA.X 2400LG.	TATA spare parts
261442900137	ASSY.PIPE 12X1X190 LG LPTA 713/32TC	TATA spare parts
261442900138	ASSY.PIPE 12DIA.X1770LG.	TATA spare parts
261442900139	ASSY.PIPE 12DIA.X 705LG.	TATA spare parts
261442900141	ASSY.PIPE 12DIA.X1320LG.	TATA spare parts
261442900143	ASSY.PIPE 12DIA.X2275LG.	TATA spare parts
261442903307	BRACKET (DAUBLE Z SHAPE) BS6	TATA spare parts
261443100102	UNLOADER VALVE	TATA spare parts
261443100103	UNLOADER VALVE	TATA spare parts
261443108201	BRACKET	TATA spare parts
261443200117	PIPE ASSY 6D X 600	TATA spare parts
261443500104	TUBE ASSY	TATA spare parts
261443500110	TUBE ASSY	TATA spare parts
261443500111	TUBE ASSY	TATA spare parts
261443500112	ASSY TUBE	TATA spare parts
261443500127	TUBE ASSY 6D X 670	TATA spare parts
261443500136	SEALING WASHER ASSY BS6-PH2	TATA spare parts
261443500140	HOSE ASSY 3/8	TATA spare parts
261443500141	HOSE ASSY 3/8	TATA spare parts
261443500154	ASSY PIPE 6 DIA X3360	TATA spare parts
261443509201	THRUST RING	TATA spare parts
261444100109	ASSY TUBE 15X1.5X695LG	TATA spare parts
261444110122	ASSY TUBE 15 X 610 LONG	TATA spare parts
261444110128	ASSY.PIPE 18DIAX1335 LONG	TATA spare parts
261446000102	DRAG LINK ASSY RHD	TATA spare parts
261446000105	DRAG LINK ASSY	TATA spare parts
261446100104	SUPPORT STRG COLUMN	TATA spare parts

261446100105	SUPPORT STRG COLUMN	TATA spare parts
261447100108	FUEL TANK 160 LTR	TATA spare parts
261447100205	ASSY.DIP STICK	TATA spare parts
261447500111	FUEL TANK 200 LTR	TATA spare parts
261447500113	ASSY SUPPORT	TATA spare parts
261447600101	FUEL LINE 10 D X 235	TATA spare parts
261447600103	OVER FLOW RETURN LINE	TATA spare parts
261449007110	BRACKET	TATA spare parts
261449007113	BRACKET (AT TAIL PIPE)	TATA spare parts
261449106903	EXHAUST PIPE REAR	TATA spare parts
261449106910	EXHAUST PIPE REAR	TATA spare parts
261449200103	ASSY BRACKET	TATA spare parts
261454048201	RIM HEAD LAMP	TATA spare parts
261454100101	BATTERY CARRIER	TATA spare parts
261454100110	BATTERY CARRIER	TATA spare parts
261454100123	ASSY. BATTERY CARRIER	TATA spare parts
261454100126	TOP COVER ASSY	TATA spare parts
261454100128	ASSY. CHANNEL	TATA spare parts
261454100130	ASSY. ACID TRAY	TATA spare parts
261454100132	ASSY. BATTERY CABLE +VE	TATA spare parts
261454100138	ASSY CU.BATTARY CABLE+ VE COMPL LPTA 7	TATA spare parts
261454100141	ASSY BATTERY CABLE +VE LPTA 713 TC	TATA spare parts
261454108227	MOUNTING PLATE (BATTERY CUT OFF SWITCH)	TATA spare parts
261454108803	STUD	TATA spare parts
261454110103	ASSY. BATTERY CABLE -VE	TATA spare parts
261454110104	ASSY CU.BATTARY CABLE -VE COMPL LPTA 7	TATA spare parts
261454110107	ASSY BATTERY CABLE -VE LPTA 713 TC	TATA spare parts
261454209902	SPEEDOMETER 1:0.84	TATA spare parts
261454209904	SPEEDOMETER 1:0.84	TATA spare parts
261454209904AE	SPEEDOMETER 0.84 M/S PRICOT 713	TATA spare parts
261454400101	LAMP GLOVE BOX	TATA spare parts
261454400108	ASSY TAIL LAMP BKT RH FOR 4 CH TAIL LAMP	TATA spare parts
261454400109	ASSY TAIL LAMP BKT LH	TATA spare parts
261454408201	BRACKET (CONVOY LAMP)	TATA spare parts
261454500107	MAIN LINE SWITCH	TATA spare parts
261454509901	STARTER PUSH BUTTON SWITCH	TATA spare parts
261454509901AE	STARTER PUSH BUTTON SWITCH 1828	TATA spare parts
261454510101	ASSY. HAZARD WARNING SWITCH	TATA spare parts
261454510102	ASSY. HAZARD WARNING SWITCH	TATA spare parts
261454600101	MAIN CABLE SET/LPTA-610 V	TATA spare parts
261454600103	CABLE SET FRT TO TAIL	TATA spare parts
261454600109	CABLE SET FRT TO TAIL	TATA spare parts
261454600113	MAIN CABLE SET	TATA spare parts
261454600118	MAIN CABLE SET	TATA spare parts
261454600137	MAIN CABLE SET	TATA spare parts
261454820103	ASSY. CABLE SET COMP WITH 12 POLE SOCKET	TATA spare parts
261458904001	TYRE PRESSURE GUAGE	TATA spare parts

261460100138	CAB COMPLT RHD	TATA spare parts
261460110155	CAB COMPLT HEATING	TATA spare parts
261461600102	ASSY MUD GUARD FRONT R.H.	TATA spare parts
261461600112	MUDGUARD FR RH	TATA spare parts
261461608212	MUDGUARD REAR RH	TATA spare parts
261465700105	ASSY BUDGET LOCK	TATA spare parts
261465708206	HINGE PLATE	TATA spare parts
261465708207	LID ROOF HATCH	TATA spare parts
261465708208	HANDLE	TATA spare parts
261468906304	INSTRUMENT PANEL	TATA spare parts
261469500103	ASSY ROOF LINING	TATA spare parts
261470000137	CANVAS COVER	TATA spare parts
261470000142	ASSY LOAD BODY	TATA spare parts
261470108234	MUD GUARD	TATA spare parts
261470500119	ASSY CANOPY TUBE REAR & FRT	TATA spare parts
261470514201	CLAMP CANOPY TUBE CENTRE	TATA spare parts
261470610102	ASSY. WATER TANK(INSULATED)	TATA spare parts
261472502301	GLASS PANE REG WINDOW	TATA spare parts
261481100104	ASSY GRAB HANDLE/SD42 V-1	TATA spare parts
261481100110	ASSY FRAME (FOR MUDFLAP) LPTA 713 TC	TATA spare parts
261481106302	ASSY MUDFLAP REAR	TATA spare parts
261483106301	DUCT SUCTION SIDE	TATA spare parts
261483106302	SUCTION PIPE	TATA spare parts
261483106305	T-CONNECTOR	TATA spare parts
261483300101	ASSY. CABLE	TATA spare parts
261488500105	BUMPER ASSY	TATA spare parts
261488500112	BUMPER ASSY	TATA spare parts
261488506301	BEADING 1680 LONG	TATA spare parts
261488506304	FENDER LH	TATA spare parts
261488506305	FENDER RH	TATA spare parts
261488508207	FENDER LH	TATA spare parts
261488700101	ASSY.ENGINE HOOD-RHD	TATA spare parts
261488700102	ASSY.ENGINE HOOD	TATA spare parts
261488700103	ASSY COVE	TATA spare parts
261488706302	ENGINEHOOD FRP	TATA spare parts
261488707705	SEALING MOULD ENG HOOD	TATA spare parts
261489108601	SPACER TUBE	TATA spare parts
261491000105	BACK REST	TATA spare parts
261491400101	SUPPORT ASSY	TATA spare parts
261498800102	ASSY MASCOT 4X4	TATA spare parts
261731000101	FRAME ASSY	TATA spare parts
261731117101	REINFORCEMENT RH	TATA spare parts
261731117102	REINFORCEMENT LH	TATA spare parts
261731307103	CROSS MEMBER	TATA spare parts
261731307107	GUSSET	TATA spare parts
261731307108	GUSSET TOP RH	TATA spare parts
261731307109	GUSSET TOP LH	TATA spare parts

261731307110	GUSSET BOTTOM RH	TATA spare parts
261731307111	GUSSET BOTTOM LH	TATA spare parts
261731307112	GUSSET LH	TATA spare parts
261731307113	GUSSET LH	TATA spare parts
261731307115	GUSSET BOTTOM RH	TATA spare parts
261731307116	GUSSET TOP LH	TATA spare parts
261731703201	THREADED PIN	TATA spare parts
261732400102	ASSY. LINK ROD BS1/2/3/4	TATA spare parts
261732400103	ASSY. LEVER BS1/2/3/4	TATA spare parts
261732400104	REAR SPRING ASSY	TATA spare parts
261732400105	LEAF SPRING 1ST W/BUSH RR	TATA spare parts
261732400105DF	MAIN LEAF REAR W/BUSH TATA2213/2316/2416	TATA spare parts
261732400106	SHACKLE REAR SPRING	TATA spare parts
261732400107	ASSY.REAR SPRING	TATA spare parts
261732400109	ASSY SEALING RING	TATA spare parts
261732400110	ASSY.REAR SPRING	TATA spare parts
261732400111	ASSY.REAR SPRING	TATA spare parts
261732400112	ASSY.REAR SPRING	TATA spare parts
261732400113	ASSY.REAR SPRING	TATA spare parts
261732403201	CENTRE PIN RR SPRING	TATA spare parts
261732403301	BRACKET SPRING CENTRE	TATA spare parts
261732403302	BRACKET SPRING REAR	TATA spare parts
261732403303	BRACKET SPRING	TATA spare parts
261732403401	BUSH LEVER	TATA spare parts
26173240340102DF	BUSH SET FOR BELL CRANK	TATA spare parts
261732403402	BUSH	TATA spare parts
261732406701	LEVER PIN BS1/2/3/4	TATA spare parts
261732406702	PIN BS1/2/3/4/6	TATA spare parts
261732407102	FIRST LEAF FOR REAR SPRING	TATA spare parts
261732407103	LEAF SPRING 2ND RR	TATA spare parts
261732407103DF	SECOND LEAF REAR-TATA2213/2316/2416	TATA spare parts
261732407104	LEAF SPRING 3RD RR	TATA spare parts
261732407105	LEAF SPRING 4TH RR	TATA spare parts
261732407106	LEAF SPRING 5TH RR	TATA spare parts
261732407107	LEAF SPRING 6TH RR	TATA spare parts
261732407108	LEAF SPRING 7TH RR	TATA spare parts
261732407109	LEAF SPRING 8TH RR	TATA spare parts
261732407110	LEAF SPRING 9TH RR	TATA spare parts
261732407111	LEAF SPRING 10TH RR	TATA spare parts
261732407112	LEAF SPRING 11TH RR	TATA spare parts
261732407113	LEAF SPRING 12TH RR	TATA spare parts
261732407114	LEAF SPRING 13TH	TATA spare parts
261732407115	LEAF SPRING 14TH	TATA spare parts
261732407701	SEALING RING	TATA spare parts
261732408602	SPACER	TATA spare parts
261732408603	SPACER	TATA spare parts
261732504201	U CLAMP	TATA spare parts

261732504202	U CLAMP	TATA spare parts
261732504203	U CLAMP LPK 2516TC	TATA spare parts
261733000103	FRONT AXLE ASSY RHD 2416	TATA spare parts
261733800101	TIE ROD ASSY	TATA spare parts
261740308602	SPACER	TATA spare parts
261742700101	ASSY.SUPPORT BKT 2416	TATA spare parts
261742810101	BRAKE TUBE	TATA spare parts
261742810102	BRAKE TUBE	TATA spare parts
261742810103	BRAKE TUBE	TATA spare parts
261742810106	BRAKE TUBE	TATA spare parts
261742810107	BRAKE TUBE	TATA spare parts
261742810108	BRAKE TUBE	TATA spare parts
261742810109	BRAKE TUBE	TATA spare parts
261742900101	ASSY BRACKET	TATA spare parts
261742900105	TUBE ASSY	TATA spare parts
261742900106	ASSY TUBE	TATA spare parts
261742900107	ASSY TUBE	TATA spare parts
261742900109	ASSY TUBE	TATA spare parts
261742900112	TUBE ASSY	TATA spare parts
261742900116	TUBE ASSY	TATA spare parts
261742900119	ASSY TUBE	TATA spare parts
261742900120	ASSY TUBE	TATA spare parts
261742900124	ASSY TUBE	TATA spare parts
261742900128	ASSY TUBE	TATA spare parts
261742900131	ASSY TUBE	TATA spare parts
261742900132	ASSY TUBE	TATA spare parts
261742900133	ASSY TUBE	TATA spare parts
261742900134	1/2 INCH HOSE ASSY	TATA spare parts
261742900151	TUBE ASSY 15D	TATA spare parts
261742903302	BRACKET	TATA spare parts
261742906801	T CONNECTOR	TATA spare parts
261742906802	T CONNECTOR	TATA spare parts
261743100101	RELAY VALVE	TATA spare parts
261743100102	RELAY VALVE	TATA spare parts
261743100103	ASSY. RELAY VALVE	TATA spare parts
261743100104	TELCO OFFER NO.RELAY VALVE	TATA spare parts
261743200101	BRACKET RELAY VALVE MTG	TATA spare parts
261743200102	ASSY BRACKET FOR RELAY VALVE MTG	TATA spare parts
261743500104	PIPE AIR 6D	TATA spare parts
261743500113	PIPE AIR	TATA spare parts
261743500115	PIPE AIR	TATA spare parts
261743500131	PIPE AIR	TATA spare parts
261743500158	PIPE ASSY 12D	TATA spare parts
261743500167	PIPE ASSY	TATA spare parts
261743700101	REP KIT-RELAY VALVE	TATA spare parts
261754820101	MAIN CABLE SET RHD S-CAM	TATA spare parts
261754820104	MAIN CABLE SET RHD DAOH	TATA spare parts

261758903201	PULLER SPRING PIN	TATA spare parts
261815140101	STARTER MOTOR 24 VOLT	TATA spare parts
261815140102	STARTER MOTOR BS1/2/3/4	TATA spare parts
261815140103	STARTER MOTOR 24 VOLT	TATA spare parts
261815140105	STARTER MOTOR 24 VOLT	TATA spare parts
261815240101	ALTERNATOR 24V 45AMPS 2GRV.ZNR.DIOD	TATA spare parts
261815240102	ALTERNATOR 24V 60AMPS 2GRV.ZNR.DIOD	TATA spare parts
261815240103	ALTERNATOR 24V 55AMPS.2GRV ZNR.DIOD.	TATA spare parts
261815400102	ALTERNATOR 24V 75AMP BS1/2/3	TATA spare parts
261826800101	ASSY GEAR SHIFT LEVER W/ YOKE	TATA spare parts
261826800104	ASSY SEL/SHIFTER FORK W/G.S.L-STAKING	TATA spare parts
261829100103	ASSY.REFILING CONT COMPLH	TATA spare parts
261829100104	REFILLING CONTAINER	TATA spare parts
261829100106	ASSY.MASTER CYLINDER- 25.4 DIA.	TATA spare parts
261829100107	CLUTCH MASTER CYL. 25.4X36 DIA. BS1-4	TATA spare parts
261829100107AE	ASSY CL MASTR CY 25.4 D-713-2523	TATA spare parts
261829100109	ASSY.REPAIR KIT MAJOR 25.4 DIA M/CYL	TATA spare parts
261829100110	ASSY.REPAIR KIT MINOR 25.4 DIA M/CYL	TATA spare parts
261829100111	ASSY CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
261829100112	ASSY CONTROL MOUNTING BKT.WITH TUBE	TATA spare parts
261829100114	ASSY CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
261829100117	FORK HEAD W/ PUSH ROD-FOR CMC	TATA spare parts
261829100121	ASSY PIPE-CL.FL.CONT.TO M/CYL	TATA spare parts
261829103301	BRACKET	TATA spare parts
261829103302	BRACKET	TATA spare parts
261829300101	ASSY CLUTCH ROD	TATA spare parts
261829500101	ASSY CONTROLS COMPLETE	TATA spare parts
261829500102	ASSY.CONTROL MTG.BKT.WITH M/C MTG.BKT.	TATA spare parts
261830100102	ASSY LEVER	TATA spare parts
261831000106	ASSY FRAME LP 52 50% _CMVR_ 330 DIA CLUTC	TATA spare parts
261831000107	ASSY FRAME LP 52 60% CMVR 330 DIA CL.	TATA spare parts
261831000109	ASSY. FRAME COMP. LP 59 WB 55 % ROH	TATA spare parts
261831000110	ASSY. FRAME COMPLETE - LP 1510/32	TATA spare parts
261831000112	ASSY. FRAME COMPLETE - LP 1510/42	TATA spare parts
261831000196	ASSY FRAME LP/42 SCAM PSTG CMVR	TATA spare parts
261831000197	FRAME COMPLETE LP1510 52WB 50%ROH P STG	TATA spare parts
261831000198	ASSY FRAME LP1510/52 PSTRG 60% OVERHANG	TATA spare parts
261831060101	ASSY FRAME LPT/42 S-CAM-310 DIA CLUTCH	TATA spare parts
261831207101	REINFORCEMENT RH (TOP)	TATA spare parts
261831207102	REINFORCEMENT LH (TOP)	TATA spare parts
261831208201	GUSSET RH	TATA spare parts
261831208202	GUSSET LH	TATA spare parts
261831307101	REINFORCEMENT RH (FRONT SPRING FRONT BKT	TATA spare parts
261831307102	REINFORCEMENT LH (FRONT SPRING FRONT BKT	TATA spare parts
261832100109	ASSY.FIRST LEAF WITH BUSH	TATA spare parts
261832100110	ASSY.FRONT SPRING	TATA spare parts
261832104201	SPRING CLIP	TATA spare parts

261832104202	SPRING CLIP	TATA spare parts
261832107101	FIFTH LEAF	TATA spare parts
261832107102	SIXTH LEAF	TATA spare parts
261832107103	SEVENTH LEAF	TATA spare parts
261832107104	EIGHTH LEAF	TATA spare parts
261832107105	NINETH LEAF	TATA spare parts
261832107106	TENTH LEAF	TATA spare parts
261832107107	ELEVENTH LEAF	TATA spare parts
261832107108	TWELVETH LEAF	TATA spare parts
261832107109	THIRTEENTH LEAF	TATA spare parts
261832107111	SECOND LEAF	TATA spare parts
261832107112	THIRD LEAF	TATA spare parts
261832107113	FOURTH LEAF	TATA spare parts
261832107114	FIFTH LEAF	TATA spare parts
261832107115	SIXTH LEAF	TATA spare parts
261832107116	SEVENTH LEAF	TATA spare parts
261832107117	EIGHTH LEAF	TATA spare parts
261832107118	NINETH LEAF	TATA spare parts
261832107119	TENTH LEAF	TATA spare parts
261832107120	ELEVENTH LEAF	TATA spare parts
261832300101	ASSY. SHOCK ABSORBER -EXT LENGTH BS1- 4	TATA spare parts
261832300102	SHOCK ABSORBER FRONT	TATA spare parts
261832300103	SHOCK ABSORBER FRT. TELCO OFFER DRG.	TATA spare parts
261832300104	ASSY FRONT SHOCK ABSORBER	TATA spare parts
261832300105	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
261832400101	SEALING RING REAR SPRING	TATA spare parts
261832400102	REAR SPRING ASSY 2 STAGE	TATA spare parts
261832400103	ASSY.REAR SPRING	TATA spare parts
261832400104	ASSY.FIRST LEAF WITH BUSH	TATA spare parts
261832400104DF	MAIN LEAF REAR W/BUSH-LPO1512/1613	TATA spare parts
261832400106	ASSY.REAR SPRING- TWO STAGE	TATA spare parts
261832400106AE	ASSY.REAR SPRING LPA 1415	TATA spare parts
261832400107	ASSY.FIRST LEAF WITH BUSH	TATA spare parts
261832400107DF	MAIN LEAF REAR W/BUSH-LP1512	TATA spare parts
261832403201	CENTRE BOLT	TATA spare parts
261832403202	CENTRE BOLT	TATA spare parts
261832404201	SPRING CLIP	TATA spare parts
261832404202	U CLAMP	TATA spare parts
261832404206	SPRING CLIP	TATA spare parts
261832407101	FIRST LEAF	TATA spare parts
261832407102	SECOND LEAF	TATA spare parts
261832407102DF	SECOND LEAF REAR - LPO1512/1613	TATA spare parts
261832407103	THIRD LEAF	TATA spare parts
261832407104	FOURTH LEAF	TATA spare parts
261832407104DF	FOURTH LEAF REAR - LPO1512/1613	TATA spare parts
261832407105	FIFTH LEAF	TATA spare parts
261832407105DF	FIFTH LEAF REAR - LPO1512/1613	TATA spare parts

261832407106	SIXTH LEAF	TATA spare parts
261832407107	SEVENTH LEAF	TATA spare parts
261832407108	EIGHTH LEAF	TATA spare parts
261832407109	NINETH LEAF	TATA spare parts
261832407110	TENTH LEAF	TATA spare parts
261832407111	ELEVENTH LEAF	TATA spare parts
261832407112	TWELVETH LEAF	TATA spare parts
261832407113	THIRTEENTH LEAF	TATA spare parts
261832407114	FOURTEENTH LEAF	TATA spare parts
261832407115	FIFTEENTH LEAF	TATA spare parts
261832407116	SIXTEENTH LEAF	TATA spare parts
261832407127	SECOND LEAF	TATA spare parts
261832407127DF	SECOND LEAF REAR - LP1512/1613	TATA spare parts
261832407128	THIRD LEAF	TATA spare parts
261832407128DF	THIRD LEAF REAR - LP1512/1613	TATA spare parts
261832407129	FOURTH LEAF	TATA spare parts
261832407129DF	FOURTH LEAF REAR - LP1512/1613	TATA spare parts
261832407130	FIFTH LEAF	TATA spare parts
261832407130DF	FIFTH LEAF REAR - LP1512/1613	TATA spare parts
261832407131	SIXTH LEAF	TATA spare parts
261832407132	SEVENTH LEAF	TATA spare parts
261832407133	EIGHTH LEAF	TATA spare parts
261832407134	NINETH LEAF	TATA spare parts
261832407135	TENTH LEAF	TATA spare parts
261832407136	ELEVENTH LEAF	TATA spare parts
261832407137	TWELVETH LEAF	TATA spare parts
261832506501	NUT	TATA spare parts
261832600101	ASSY.SHOCK ABSORBER BKT.REAR BOTTOM - RH	TATA spare parts
261832600102	REAR SHOCK ABSORBER (LP/LPO) EXTENDED LE	TATA spare parts
261832600103	ASSY.SHOCK ABSORBER BKT.REAR BOTTOM - LH	TATA spare parts
261832600110	REAR SHOCK ABSORBER (LP/LPO) EXTENDED LE	TATA spare parts
261832600111	REAR SHOCK ABSORBER (LP/LPO) EXTENDED LE	TATA spare parts
261832600112	REAR SHOCK ABSORBER (LP/LPO) EXTENDED LE	TATA spare parts
261832608001	MOUNTING PIN	TATA spare parts
261832608002	MOUNTING PIN	TATA spare parts
261832608003	MOUNTING PIN	TATA spare parts
261833000105	ASSY.FR.AXLE 1510 WITH POWER STG.	TATA spare parts
261833203101	TAPER ROLLER THRUST BEARING	TATA spare parts
261833408601	SPACER IN BETWEEN INNER OUTER BRG.	TATA spare parts
261833453101	TAPER ROLLER BRG HUB INNER BS1/2/3/4	TATA spare parts
261833453101AE	TAPER RLR BRG LPA 1415/LPTA 715	TATA spare parts
261833800101	ASSY TIE ROD	TATA spare parts
261835108601	PRESSURE RING LH & RH	TATA spare parts
261835110103	ASSLY. CARRIER (41/7OR47/8) RATIO COMPLE	TATA spare parts
261835300102	CWP SET 46/7 OERL	TATA spare parts
261835300104	CWP SET 46/7 GLEA	TATA spare parts
261835300105	CWP SET 47/8 GLEA LPO1313TC	TATA spare parts



261835603101	TAPER ROLLER BRG	TATA spare parts
261835603102	TAPER ROLLER BRG	TATA spare parts
261835603103	TAPER ROLLER BRG 32216 BS1/2/3/4	TATA spare parts
261835603103AE	INNER BRG TAPERED RLLR -713-1628	TATA spare parts
261835606501	LOCKING RING	TATA spare parts
261835607701	OIL SEAL RR INNER 1210	TATA spare parts
261835607703	OIL SEAL RH INNER	TATA spare parts
261835608201	OIL CATCHER NEW	TATA spare parts
261835608202	LOCKING PLATE	TATA spare parts
261835608302	SHIM 0.05 MM	TATA spare parts
261835608303	SHIM 0.10 MM	TATA spare parts
261835608304	SHIM 0.20 MM	TATA spare parts
261835608305	SHIM 0.30 MM	TATA spare parts
261835608306	SHIM 0.50 MM	TATA spare parts
261835608307	SHIM 1.00 MM	TATA spare parts
261835608308	SHIM 1.50 MM	TATA spare parts
261835608309	SHIM 4.00 MM	TATA spare parts
261835608310	SHIM 0.15 THK	TATA spare parts
261835608311	SHIM 0.25 THK	TATA spare parts
261835608312	SHIM 2.5 THICK	TATA spare parts
261835608601	SPACER RING	TATA spare parts
261835608602	SPACER TUBE	TATA spare parts
261835608603	SPACER HUB OUTER BRG	TATA spare parts
261840100101	ASSY. WHEEL RIM 7.0X20	TATA spare parts
261840100102	ASSY WHEEL NUT M20X30LONG	TATA spare parts
261840100102AE	ASSYWHEEL NUT(M20 LNGTH=33)-715	TATA spare parts
261840106701	HUB BOLT FRONT( M20) 1510	TATA spare parts
261840206701	HUB BOLT REAR( M20) 1510	TATA spare parts
261841100104	PROP SHAFT MID 76X4X1316	TATA spare parts
261841100113	P/SHAFT FR W/CB 76X4X380	TATA spare parts
261841100114	PROP SHAFT FR W/CEN BRG	TATA spare parts
261841110105	P/SHAFT FRT WCB 90X3X378	TATA spare parts
261841110120	PROP.SHAFT FRT.LPO1510/55	TATA spare parts
261841120106	PROP SHAFT RR 90X3X1255	TATA spare parts
261841120120	RR/SHAFT ASSY LPO 1510/55	TATA spare parts
261841303301	BRACKET-CENTER BEARING MOUNTING	TATA spare parts
261842100101	ASSY BRAKE LINING KIT FRT	TATA spare parts
261842100102	BRAKE CHAMBER FRT RH	TATA spare parts
261842100103	SLACK ADJUSTER	TATA spare parts
261842100106	ASSY.BRAKE CHAMBER-LH	TATA spare parts
261842100126	SLACK ADJUSTER	TATA spare parts
261842100127	SLACK ADJUSTER	TATA spare parts
261842100130	ASSY.SLACK ADJUSTER-FRONT	TATA spare parts
261842100131	SLACK ADJUSTER	TATA spare parts
261842100145	R/KIT SLACK ADJ.FRNT	TATA spare parts
261842100146	SLACK ADJUSTER	TATA spare parts
261842104301	LOCK RING	TATA spare parts

261842107901	CAMSHAFT FRONT - RH	TATA spare parts
261842107902	CAMSHAFT FRONT LH	TATA spare parts
261842107903	FRONT S CAM SHAFT-RH	TATA spare parts
261842107904	FRONT S CAM SHAFT-LH	TATA spare parts
261842109202	WASHER	TATA spare parts
261842109203	WASHER	TATA spare parts
261842109204	WASHER-HARDENED	TATA spare parts
261842300101	SLACK ADJUSTER RH	TATA spare parts
261842300102	SLACK ADJUSTER LH	TATA spare parts
261842300104	TYPE 24 BOOSTERS	TATA spare parts
261842300105	SLACK ADJUSTER LH	TATA spare parts
261842300106	SLACK ADJUSTER RH	TATA spare parts
261842300107	SLACK ADJUSTER LH	TATA spare parts
261842300108	SLACK ADJUSTER RH	TATA spare parts
261842300111	ASSY BRAKE LINING KIT RR.	TATA spare parts
261842300112	ASSY.SLACK ADJUSTER- RH- REAR	TATA spare parts
261842300113	ASSY.SLACK ADJUSTER- LH- REAR	TATA spare parts
261842300114	SLACK ADJUSTER LH	TATA spare parts
261842300115	SLACK ADJUSTER RH	TATA spare parts
261842300124	SLACK ADJUSTER RH	TATA spare parts
261842300125	SLACK ADJUSTER LH	TATA spare parts
261842300132	ASSY KIT REAR BRK.CHAMBER	TATA spare parts
261842300133	R/KIT SLACK ADJ.REAR	TATA spare parts
261842300134	ASSY R/KIT HAND BRK VALVE	TATA spare parts
261842307901	CAMSHAFT REAR RH	TATA spare parts
261842307902	CAMSHAFT REAR LH	TATA spare parts
261842900170	ASSY. 3/8 HOSE W/BULK HEAD BS1- 4	TATA spare parts
261842900173	ASSY 3/8 INCH HOSE W/BULK HEAD & ST BODY	TATA spare parts
261842908202	BRACKET	TATA spare parts
261842908204	BRACKET	TATA spare parts
261842910102	ASSY.METAL PIPE 15 O.D.	TATA spare parts
261842910104	ASSY.HOSE(BEND PIPE & END FTGS.BOTH ENDS	TATA spare parts
261842910113	ASSY.CLAMP (69 I.D.)	TATA spare parts
261843700102	DUAL BRAKE VALVE	TATA spare parts
261843700103	EXHAUST BRAKE AIR CYLINDER .	TATA spare parts
261843700105	ISOLATOR VALVE EXH BRAKE	TATA spare parts
261843700106	EXHAUST BRAKE VALVE	TATA spare parts
261843700107	EXHAUST BRAKE VALVE	TATA spare parts
261843700108	ASSY BRACKET-AIR DRYER	TATA spare parts
261843708201	ASSY BRACKET (AIR DRYER)	TATA spare parts
261846000105	ASSY.DRAG LINK.-RHD	TATA spare parts
261846100101	ASSY.STEERING COLUMN SUPPORT	TATA spare parts
261846100104	ASSY.STEERING COLUMN SUPPORT COMPLETE	TATA spare parts
261846100105	ASSY.STEERING COLUMN SUPPORT	TATA spare parts
261846100109	MTG BRACKET STRG G.B. LP1512TC	TATA spare parts
261846100114	ASSY.STEERING COLUMN SUPPORT	TATA spare parts
261846203401	BUSH	TATA spare parts

261846600101	POWER STRG PUMP BS1/2/3/4/6	TATA spare parts
261846600102	ASSY. PWR STG GEAR BOX -PR VLV BS1/2/3/4	TATA spare parts
261846600105	HOUSING SUB ASSEMBLY KIT BS6	TATA spare parts
261846600106	HOUSING SUB ASSY	TATA spare parts
261846600108	SHAFT SUB-ASSEMBLY	TATA spare parts
261846600109	ASSEMBLY CARTRIDGE	TATA spare parts
261846600110	SEAL KIT	TATA spare parts
261846607701	O RING	TATA spare parts
261846608001	M6 SCREW	TATA spare parts
261846800114	ASSY PIPE-18 OD	TATA spare parts
261846803301	BRACKET	TATA spare parts
261846990102	SHAFT ASSY	TATA spare parts
261846990103	SEAL KIT	TATA spare parts
261846990106	PLUG ASSY	TATA spare parts
261846990110	PLUG SUB ASSEMBLY	TATA spare parts
261846994301	RETAINING RING	TATA spare parts
261846994302	RETAINING RING	TATA spare parts
261846994303	RETAINING RING	TATA spare parts
261846995901	WOODRUF KEY	TATA spare parts
261846998601	SPACER	TATA spare parts
261847506701	CLEVIS PIN	TATA spare parts
261847506702	CLEVIS PIN	TATA spare parts
261847600106	ASSY.SUCTION LINE.	TATA spare parts
261847600108	ASSY.BRACKET WATER SEPARATOR MTG.	TATA spare parts
261847606801	HPR OUTLET CONNECTOR	TATA spare parts
261847606802	CONNECTOR-HPR OUT TO HOSE	TATA spare parts
261847606803	ELBOW-FOR GAS SHUT OFF VALVE	TATA spare parts
261847606804	ELBOW-FOR LPR	TATA spare parts
261847606807	BUSHING-ON HPR FOR HEATING	TATA spare parts
261847606808	ELBOW-ON HPR FOR HEATING CONNECTION	TATA spare parts
261847606809	NIPPLE	TATA spare parts
261847606810	EQUAL TEE	TATA spare parts
261847606811	ELBOW MALE ADAPTER	TATA spare parts
261849008202	BRACEKT BS6-PH2	TATA spare parts
261849100101	ASSY BARCKET	TATA spare parts
261849100114	ASSY.SILENCER WITH TAIL PIPE	TATA spare parts
261849100117	ASSY.PIPE	TATA spare parts
261854100101	ASSY CARRIER (METAL)(150 AH 2BATT.)	TATA spare parts
261854100103	ASSY BATTERY COVER (FOR 150 AH BATTERY)	TATA spare parts
261854108202	CLAMPING CHANNEL	TATA spare parts
261854109908	BATTERY 12V/150AH MHD	TATA spare parts
261854200101	3.2 DIA SPEEDOCABLE 3000LG. - OFFER	TATA spare parts
261854206301	COVER-RELAYS 5 NOS & FLASHER	TATA spare parts
261854206302	COVER-RELAYS 8 NOS & FLASHER	TATA spare parts
261854206901	PIANO KEY SWITCH - OFFER	TATA spare parts
261854209901	SPEEDOMETER 6+1-1:0.91	TATA spare parts
261854209904	TANK UNIT (350 LITRE TANK) LPT 2515TC	TATA spare parts

261854209907	TANK UNIT FUEL GAUGE	TATA spare parts
261854209908	TANK UNIT FUEL GAUGE	TATA spare parts
261854209910	TANK UNIT ASSY	TATA spare parts
261854209911	TANK UNIT FUEL GAUGE	TATA spare parts
261854209913	SPEEDOMETER (1:0.88) W/BLADE TR.	TATA spare parts
261854209914	SPEEDOMETER (1:0.80) W/BLADE TR	TATA spare parts
261854209915	SPEEDOMETER (1:0.91) W/BLADE TR.	TATA spare parts
261854209916	INSTRUMENT CLUSTER-1:0.91	TATA spare parts
261854209917	SPEEDOMETER (1:1.04)W/BLADE TR.	TATA spare parts
261854209918	INSTRUMENT CLUSTER-1:0.91	TATA spare parts
261854209925	FUEL GAUGE ASSY.24V	TATA spare parts
261854209926	FUEL GAUGE ASSY.12V	TATA spare parts
261854209927	TEMP.GAUGE ASSY.	TATA spare parts
261854209928	AIR PR.GAUGE ASSY.	TATA spare parts
261854209929	RPM METER 24V 284HZ	TATA spare parts
261854209930	RPM METER 12V 552HZ	TATA spare parts
261854209931	SPEEDOMETER-0.91	TATA spare parts
261854209932	SPEEDOMETER-1.04	TATA spare parts
261854209933	SPEEDOMETER-0.80	TATA spare parts
261854209936	RPM METER 24V 552HZ	TATA spare parts
261854209940	SPEEDOMETER (1:0.88)(01029901013A-MINDA)	TATA spare parts
261854209941	INSTRUMENT CLUSTER 1:0.8	TATA spare parts
261854209942	INSTRUMENT CLUSTER (1:0.91)	TATA spare parts
261854209946	INSTRUMENT CLUSTER (1:0.80)	TATA spare parts
261854209951	INST.CLUSTER(ELECT)(1:0.80)	TATA spare parts
261854209955	INST.CLUSTER(ELECT)(1:0.8)	TATA spare parts
261854209956	INSTRUMENT CLUSTER(ELECT) (1:0.88)	TATA spare parts
261854209957	INSTRUMENT CLUSTER(ELECT.) (1:0.80)	TATA spare parts
261854209960	HORN COVER	TATA spare parts
261854240105	MAGNETIC VALVE W/BACKET 24V	TATA spare parts
261854240105AE	MAG VALVE W/BRT 24V 1415/ 1628	TATA spare parts
261854240106	KIT HORN (24V)	TATA spare parts
261854249902	OIL PRESSURE GAUGE-ELECT	TATA spare parts
261854249903	ELECT.OIL PRESSURE GAUGE -OFFER	TATA spare parts
261854249910	HORN (HIGH TONE) 24V	TATA spare parts
261854249911	HORN (LOW TONE) 24V BS1/2/3/4	TATA spare parts
261854249911AE	¿HORN (LOW ) 24V -1415-1628-1828	TATA spare parts
261854400101	ASSY TAIL LAMP LH - JMA	TATA spare parts
261854400102	ASSY TAIL LAMP RH - JMA	TATA spare parts
261854400103	ASSY BLINKER LAMP LH	TATA spare parts
261854400103AE	ASSY BLINKER LAMP LH	TATA spare parts
261854400104	ASSY.BLINKER LAMP RH W/O BULB	TATA spare parts
261854400105	ASSY. HEAD LAMP WITH 24V BULB - OFFER	TATA spare parts
261854400106	ASSY. HEAD LAMP WITH BULB 24V - OFFER	TATA spare parts
261854400111	ASSY HEAD LAMP LH WITH HALOGEN BULB	TATA spare parts
261854400112	ASSY HEAD LAMP RH WITH HALOGEN BULB	TATA spare parts
261854400120	ASSY H/L PC RIM W/HALO BULB 12V RH	TATA spare parts

261854400121	ASSY H/L PC RIM W/HALO BULB 12V LH	TATA spare parts
261854400133	ASSY H/L PC RIM W/HALO BULB 12V LH	TATA spare parts
261854400134	ASSY H/L PC RIM W/HALO BULB 12V RH	TATA spare parts
261854400138	ASSY H/L PC RIM W/HALO BULB 12V LH	TATA spare parts
261854400139	ASSY H/L PC RIM W/HALO BULB 12V RH	TATA spare parts
261854400146	ASSY. TAIL LAMP LH 24V	TATA spare parts
261854400147	ASSY. TAIL LAMP RH 24V	TATA spare parts
261854400150	ASSY MOTORISED H/L COMPLT.12V LH-RHD	TATA spare parts
261854400151	ASSY MOTORISED H/L 12V COMPLT.RH-RHD	TATA spare parts
261854400154	ASSY MOTORISED H/L COMPLT.12V LH-RHD	TATA spare parts
261854400155	ASSY MOTORISED H/L 12V COMPLT.RH-RHD	TATA spare parts
261854400156	ASSY MOTORISED H/L COMPLT.12V LH-RHD	TATA spare parts
261854400157	ASSY MOTORISED H/L 12V COMPLT.RH-RHD	TATA spare parts
261854400160	ASSY MOTORISED H/L COMPLT.12V LH-RHD	TATA spare parts
261854400161	ASSY MOTORISED H/L 12V COMPLT.RH-RHD	TATA spare parts
261854400166	ASSY ENGINE LAMP(24V 21W W/BULB)	TATA spare parts
261854400167	ASSY ENGINE LAMP(24V 21W W/BLB)	TATA spare parts
261854400168	ASSY ENGINE LAMP (24V 21W W/BLB)	TATA spare parts
261854408201	BRACKET BUZZER AND BEEPER	TATA spare parts
261854440101	ASSY. TAIL LAMP LH BS1/2/3/4	TATA spare parts
261854440102	ASSY. TAIL LAMP RH 24V BS1/2/3/4	TATA spare parts
261854440103	ASSY TAIL LAMP LH 24V	TATA spare parts
261854440104	ASSY TAIL LAMP RH 24V	TATA spare parts
261854440105	ASSY TAIL LAMP LH MSSL 24V	TATA spare parts
261854440106	ASSY TAIL LAMP RH MSSL 24V	TATA spare parts
261854440107	ASSY TAIL LAMP LH MSSL 24V	TATA spare parts
261854440108	ASSY TAIL LAMP RH MSSL 24V	TATA spare parts
261854440110	ASSY.T/L WITH BRACKET 24V RH	TATA spare parts
261854440114	ASSY.T/L WITH BRACKET 24V LH	TATA spare parts
261854440117	ASSY HEAD LAMP LH WITH HALOGEN BULB	TATA spare parts
261854440118	ASSY HEAD LAMP RH WITH HALOGEN BULB	TATA spare parts
261854440121	ASSY HEAD LAMP LH WITH HALOGEN BULB	TATA spare parts
261854440122	ASSY HEAD LAMP RH WITH HALOGEN BULB	TATA spare parts
261854440129	ASSY.RECT.H/L COMPLETE 24V LH RHD	TATA spare parts
261854440131	ASSY.RECT.H/L COMPLETE 24V RH RHD	TATA spare parts
261854440133	ASSY.RECT.H/L COMPLETE 24V LH RHD	TATA spare parts
261854440134	ASSY.RECT.H/L COMPLETE 24V LH RHD	TATA spare parts
261854440137	ASSY.RECT.H/L COMPLETE 24V RH RHD	TATA spare parts
261854440138	ASSY.RECT.H/L COMPLETE 24V RH RHD	TATA spare parts
261854440141	ASSY.RECT.H/L COMPLETE 24V RH RHD	TATA spare parts
261854440142	ASSY.RECT.H/L COMPLETE 24V LH RHD	TATA spare parts
261854440143	BLINKER LAMP ASSY(LH)W/BULB 24V	TATA spare parts
261854440144	BLINKER LAMP ASSY(RH)W/BULB 24V	TATA spare parts
261854440145	BLINKER LAMP ASSY(LH)W/BULB 24V	TATA spare parts
261854440146	BLINKER LAMP ASSY(RH)W/BULB 24V	TATA spare parts
261854440148	KIT BLINKER LAMP LH & RH (24V)	TATA spare parts
261854440149	KIT BLINKER LAMP LH & RH (24V)	TATA spare parts

261854440153	ASSY.H/L E`CERT W/MOTOR RH-RHD 24V	TATA spare parts
261854440154	ASSY.H/L E`CERT W/MOTOR.LH-RHD 24V	TATA spare parts
261854440155	ASSY MOTORISED H/L COMPLT.24V LH-RHD	TATA spare parts
261854440156	ASSY MOTORISED H/L COMPLT.12V RH-RHD	TATA spare parts
261854440159	ASSY. HEAD LAMP LH 24V-RHD BS2/3/4	TATA spare parts
261854440160	ASSY. HEAD LAMP RH 24V-RHD BS2/3/4	TATA spare parts
261854440161	ASSY MOTORISED H/L COMPLT.24V LH-RHD	TATA spare parts
261854440162	ASSY MOTORISED H/L COMPLT.24V RH-RHD	TATA spare parts
261854440165	ASSY T/LAMP W/BKT (E`CERT) 24V-LH	TATA spare parts
261854440170	ASSY T/LAMP W/BKT (E`CERT) 24V-RH	TATA spare parts
261854440175	ASSY MOTORISED H/L COMPLT 24V LH-RHD	TATA spare parts
261854440176	ASSY MOTORISED H/L COMPLT.24V RH	TATA spare parts
261854440179	H/L E/CERT W/MOT RH RHD 24V -1.8PERC-NEO	TATA spare parts
261854440180	LAMP H/L(-1.8PERC)12VHLL RHD 24V-LH	TATA spare parts
261854500101	ASSY. COMBI SWITCH BS1/2/3	TATA spare parts
261854500102	ASSY COMBI WSITCH	TATA spare parts
261854500103	ASSY COMBI SWITCH	TATA spare parts
261854500104	ASSY COMBI SWITCH W/MSSL TERMINALS	TATA spare parts
261854500105	ASSY COMBI SWITCH W/MSSL TERMINALS	TATA spare parts
261854500106	HAZARD WARNING SWITCH 12V W/MSSL TERMIN	TATA spare parts
261854500107	HAZARD WARNING SWITCH	TATA spare parts
261854500108	HAZARD WARNING SWITCH 12V W/MSSL TERMIN	TATA spare parts
261854500109	HAZARD WARNING SWITCH	TATA spare parts
261854500110	ASSY FUSE BOX MTG BRACKET	TATA spare parts
261854500111	ASSY COMBI SWITCH W/MSSL TERMINALS	TATA spare parts
261854509901	STARTER PUSH BUTTON	TATA spare parts
261854509903	STARTER PUSH BUTTON	TATA spare parts
261854509904	BATTERY CUT OFF SWITCH	TATA spare parts
261854540101	HAZARD WARNING SWITCH 24V	TATA spare parts
261854540102	HAZARD WARNING SWITCH 24V	TATA spare parts
261854540103	HAZARD WARNING SWITCH 24V	TATA spare parts
261854540104	HAZARD WARNING SWITCH 24V	TATA spare parts
261854540105	FLASHER KIT 24V	TATA spare parts
261854540106	FLASHER 24V W/- BRACKET	TATA spare parts
261854544603	FLASHER SQ.(24V)	TATA spare parts
261854544604	FLASHER SQ.(24V)	TATA spare parts
261854544605	FLASHER SQ.(24V) BS1/2/3	TATA spare parts
261854544606	TRAILER FLASHER (24V)	TATA spare parts
261854544607	FLASHER SQ.(24V)	TATA spare parts
261854600102	W/H MAIN (LPT/LPS1613)(CMVR2000)-OFFER	TATA spare parts
261854600107	W/H STOP LT.SW.AND LP.SW.	TATA spare parts
261854600108	W/H MAIN (LP1510)(CMVR2000)-OFFER	TATA spare parts
261854600109	W/H TAIL-LP1510/52 CMVR2000	TATA spare parts
261854600111	W/H MAIN-LP 1510	TATA spare parts
261854600113	W/H STOP LT.SW.& LP SW.	TATA spare parts
261854600116	W/H PANEL LAMPS	TATA spare parts
261854600117	W/H MAIN (LP 1510 CMVR2000) OFFER	TATA spare parts

261854600118	W/H MAIN (LP1510_W/CLUSTER)	TATA spare parts
261854600119	W/H TAIL-LP1510/52	TATA spare parts
261854600121	W/H TAIL (LP 1510/59 PUNE MODEL)	TATA spare parts
261854600123	W/H TAIL(LP1510/52 697 BS-II LP 24V)	TATA spare parts
261854600124	W/H MAIN(LP1510 697 BS-II LP 24V)	TATA spare parts
261854600129	W/H TAIL(LP1510/52 BS-II FEEDPUMP)	TATA spare parts
261854600133	W/H MAIN(LP1510 24V BS-II 697)	TATA spare parts
261854608201	SPRING CLIP	TATA spare parts
261854620111	WIRING HARNESS	TATA spare parts
261854620116	WIRING HARNESS	TATA spare parts
261854620124	W/H PANEL LAMPS SK 1613CMVR-/32	TATA spare parts
261854620125	W/H GAUGES EARTHING LPT1613 CMVR 2000	TATA spare parts
261854620127	W/H STOP LT.SW.AND LP.SW	TATA spare parts
261854620128	WIRING HARNESS TAIL LP 1510/52 CMVR 2K	TATA spare parts
261854620133	WIRING HARNESS MAIN LPS/LPT1613	TATA spare parts
261854620137	WIRING HARNESS MAIN LP 1510 CMVR 2K	TATA spare parts
261854620139	W/H MAIN-LPT/LPS1613 CMVR2000	TATA spare parts
261854620148	W/H MAIN-LP 1510 CMVR2000	TATA spare parts
261854620152	W/H STOP LIGHT SWITCH & LOW PRESSURE SWI	TATA spare parts
261854620154	W/H PANEL LAMPS	TATA spare parts
261854620156	W/H MAIN-LP 1510 CMVR2000	TATA spare parts
261854620157	W/H TAIL-LP 1512/52TC	TATA spare parts
261854620158	W/H TAIL-LP 1512/59TC	TATA spare parts
261854620162	W/H TAIL (LP 1510/59 PUNE MODEL)	TATA spare parts
261854620163	W/H MIAN (LP1510 W/CLUSTER)	TATA spare parts
261854620164	W/H MAIN(LP1510 697 BS-II LP 24V)	TATA spare parts
261854620165	W/H TAIL(LP1510/52 697 BS-II LP 24V)	TATA spare parts
261854620168	W/H MAIN (LP1510 BS-II 697)	TATA spare parts
261854620170	W/H TAIL(LP1510/52 BS-II FEED PUMP)	TATA spare parts
261854660101	WIRING HARNESS MAIN (LPT/LPS1613)(CMVR20	TATA spare parts
261854660102	WIRING HARNESS TAIL-LPT1613/42CMVR2000	TATA spare parts
261854660104	W/H GAUGES EARTHING LPT1613 CMVR 2000	TATA spare parts
261854660105	W/HARNES STOP LIGHT SWITCH & L P SWITCH	TATA spare parts
261854660106	W/H MAIN-LP 1510 CMVR 2000	TATA spare parts
261854660108	W/H STOP LIGHT SWITCH & LOW PRESSURE SWI	TATA spare parts
261854660114	W/H WIPER MOTOR	TATA spare parts
261854660116	W/H PANEL LAMPS	TATA spare parts
261854660117	W/H MAIN-LP 1510 CMVR2000	TATA spare parts
261854660118	W/H TAIL-LP 1512/52TC	TATA spare parts
261854660119	W/H TAIL-LP 1512/59TC	TATA spare parts
261854660127	W/H MAIN-LP1510 W/CLUSTER	TATA spare parts
261854660133	W/H TAIL (LP 1510/52)	TATA spare parts
261854660134	W/H TAIL (LP 1510/59 PUNE MODEL)	TATA spare parts
261854660135	W/H MAIN(LP1510 BS-II EXH.W/O BOX)	TATA spare parts
261854660136	W/H TAIL(LP1510/52 BS-II EXH.BR.)	TATA spare parts
261854660137	W/H TAIL (W/EXH.BRK.-LP1510/52)	TATA spare parts
261854660138	W/H TAIL (W/EXH.BRK.-LP1510/59)	TATA spare parts

261854660147	W/H MAIN(LP1510 24V BS-II 697)	TATA spare parts
261854660148	W/H TAIL(LP1510/52 BS-II FEEDPUMP)	TATA spare parts
261854820105	ASSY.MAIN CABLE SET (RHD)(LPO S CAM)	TATA spare parts
261858900101	WHEEL SPANNER 30 A/F	TATA spare parts
261881800101	ASSY.MASCOT 1510	TATA spare parts
261881800103	ASSY 1510 MASCOT	TATA spare parts
261882249901	WIPER MOTOR 17W 24V	TATA spare parts
261882400110	ASSY.WIPER ARM & BLADE	TATA spare parts
261882400111	ASSY WIPER ARM & BLADE	TATA spare parts
261882408201	CLAMP P TYPE	TATA spare parts
261882408203	COVER WIPER MOTOR (LPT COWL)	TATA spare parts
261882409901	WIPER MOTOR	TATA spare parts
261882409902	WIPER MOTOR 17W	TATA spare parts
261882409904	WIPER MOTOR 17W	TATA spare parts
261888700101	ASSY ENGINE HOOD COMP RHD	TATA spare parts
261898800101	ASSY 1510 MASCOT	TATA spare parts
261898800103	MASCOT TATA	TATA spare parts
261942300131	KIT LINING SET-1 O/S	TATA spare parts
262033805101	STEERING ARM LH	TATA spare parts
262033805102	STEERING ARH RH	TATA spare parts
262125605101	CLUTCH RELEASE FORK	TATA spare parts
262126406701	PIN	TATA spare parts
262129100103	CLUTCH PEDAL LEVER	TATA spare parts
262129300104	CLUTCH ROD LHD	TATA spare parts
262129300105	CLUTCH ROD RHD	TATA spare parts
262129300109	CLUTCH ROD	TATA spare parts
262129307701	RUBBER COVER	TATA spare parts
262129308201	COVER PLATE	TATA spare parts
262129309901	BALL END	TATA spare parts
262130100101	PUSH ROD ACCEL CONTROL	TATA spare parts
262130100107	PULL ROD	TATA spare parts
262131000109	ASSY FRAME FOR LP809/36 R	TATA spare parts
262131000110	FRAME ASSY LP36 LHD	TATA spare parts
262131200101	ENGINE CROSS MEMBER FR	TATA spare parts
262131708201	BRACKET RH RADIATOR MTG	TATA spare parts
262131708202	BRACKET LH RADIATOR MTG	TATA spare parts
262133805102	TIE ROD ARM R H FOR L H D	TATA spare parts
262133805103	STEERING ARM TOP	TATA spare parts
26214066	BRACKET ASSY FRONT BUMPER RH	TATA spare parts
262141100107	ASSY PROP SHAFT WITH CENTRE BRG	TATA spare parts
262142903308	BRACKET	TATA spare parts
262143503302	BRACKET	TATA spare parts
262143503304	BRACKET	TATA spare parts
262143503307	BRACKET	TATA spare parts
262143730101	DUAL BRAKE VALVE	TATA spare parts
262144000106	ASSY TUBE 18 DIA X950 LG	TATA spare parts
262146106301	RUBBER BELLOW	TATA spare parts



262146107502	PROTECTIVE COVER	TATA spare parts
262146107908	STRG SPINDLE TOP 310 LONG	TATA spare parts
262146305101	PITMAN ARM	TATA spare parts
262146400103	STRG WHEEL 425 DIA	TATA spare parts
262146800101	HOSE HP 3/8	TATA spare parts
26214714	REGULATOR & BRUSH BOX	TATA spare parts
262149100104	EXHAUST PIPE FRT	TATA spare parts
262149100105	ASSY.EXHAUST PIPE FRONT DIA65X515 LONG.	TATA spare parts
262149106910	EXHAUST PIPE INTERMEDIATE	TATA spare parts
262150105801	HOSE RADIATOR TO W/PUMP	TATA spare parts
262154100107	ASSY COPER BATTERY CABLE+	TATA spare parts
262154100108	ASSY COPER BATTERY CABLE-	TATA spare parts
262154100126	ASSY.BATT.CABLE +VE-3500	TATA spare parts
262154200102	PIPE OIL PRESSURE GAUGE	TATA spare parts
262154200103	HOSE DIFFL LOCK CYL	TATA spare parts
262154249903	LOW AIR PR BEEPER 24V	TATA spare parts
262154500101	REV.LAMP IND.SWITCH	TATA spare parts
262154509902	STARTER PUSH BUTTON SW. 15 AMP	TATA spare parts
262154509903	STOP LIGHT SWITCH MECH	TATA spare parts
262154509904	STOP LIGHT SWITCH	TATA spare parts
262154509905	STOP LIGHT SWITCH	TATA spare parts
262154600101	MAIN CABLE SET	TATA spare parts
26215595	ROTOR	TATA spare parts
262160100108	ASSY.COWL WELDED	TATA spare parts
262160100109	ASSY CAB COMPLETE RHD	TATA spare parts
262170000102	LOAD BODY COMPLT	TATA spare parts
262182409903	WIPER MOTOR 17W 24V	TATA spare parts
262188500119	ASSY BUMPER COMP R H D LP909	TATA spare parts
262198800103	MASCOT 909 PLATED	TATA spare parts
262198800105	MASCOT 909	TATA spare parts
262432650101	CROSS MEMBER (REAR SHOCK ABSORBER)	TATA spare parts
262531000105	ASSY.FRAME COMPL.LPO 1313/47 60% ROH.	TATA spare parts
262532100101	ASSY.FRONT SPRING	TATA spare parts
262532104201	SPRING CLIP	TATA spare parts
262532104202	SPRING CLIP	TATA spare parts
262532504201	U CLAMP M20X1.5X437 LONG	TATA spare parts
262542903305	BRACKET	TATA spare parts
262542903307	BRACKET	TATA spare parts
262542904201	CLAMP 12DIA.X15DIA.	TATA spare parts
262546000101	ASSY DRAG LINK	TATA spare parts
262546000102	ASSY DRAG LINK	TATA spare parts
262546000104	TELCO OFFER NO.ASSY.DRAG LINK.	TATA spare parts
262546800101	TUBE ASSY	TATA spare parts
262546800102	TUBE ASSY	TATA spare parts
262546800104	TUBE ASSY	TATA spare parts
262546800105	TUBE ASSY	TATA spare parts
262546800115	TUBE 430MM	TATA spare parts

262546808203	BRACKET	TATA spare parts
262547100105	ASSY. FUEL TANK (250 LIT)	TATA spare parts
26255204	VALVE GUIDE	TATA spare parts
26255205	BRUSH SET	TATA spare parts
262554100114	ASSY.BATT.CABLE SUPPORT BRACKET	TATA spare parts
262554400106	ASSY CAB LAMP	TATA spare parts
262554440101	ASSY. BLINKER LH WITH BULB 24V BS2/3/4	TATA spare parts
262554440102	ASSY. BLINKER RH WITH BULB 24V BS2/3/4	TATA spare parts
262554440105	ASSY TOP MARKER LAMP LH WITH BULB 24V	TATA spare parts
262554440106	ASSY TOP MARKER LAMP RH WITH BULB 24V	TATA spare parts
262554660103	W/H PANEL LAMPS SK 1613CMVR-/32	TATA spare parts
26255981	PIN SPRING	TATA spare parts
262615405301	GASKET	TATA spare parts
262831000107	FRAME 1613 SK/36	TATA spare parts
262831000132	ASSY FRAME SK1613/ 36 WB CMVR	TATA spare parts
262831000134	ASSY FRAME SK1613/ 36 WB CMVR	TATA spare parts
262831000144	ASSY FRAME SK1613/32 CMVR 330DIA CLUTCH	TATA spare parts
262831200101	ASSY ENGINE CROSS MEMBER REAR SK1612	TATA spare parts
262831200102	ENGINE X MEMBER FRT W/O COUPLING SK1613C	TATA spare parts
262831207103	REINFORCEMENT FRONT TOP - RH	TATA spare parts
262831207116	SUPPORT BOTTOM	TATA spare parts
262832403301	SLIDE SUPPORT-CAST	TATA spare parts
262833000101	ASSY FRONT AXLE COMPLETE	TATA spare parts
262840309201	SPACER (SPARE WHEEL CARRIER)	TATA spare parts
262842900152	ASSY PIPE H. BRAKE TO A T	TATA spare parts
262842900157	ASSY.METAL PIPE-15 O.D.	TATA spare parts
262842900164	ASSY.NYLON PIPE 12 O.D.	TATA spare parts
262842903301	ASSY. BRACKET FOR QUICK RELEASE VALVE	TATA spare parts
262842903302	BRACKET BS6	TATA spare parts
262842908202	BRACKET	TATA spare parts
262847600109	ASSY SUCTION LINE	TATA spare parts
262847600111	ASSY. BRACKET (WATER SEPARATOR MTG.)	TATA spare parts
262847600112	ASSY. SUCTION LINE	TATA spare parts
262847600113	ASSY. SUCTION LINE	TATA spare parts
262847600114	ASSY SUCTION LINE	TATA spare parts
262849200102	ASSY. EXHAUST PIPE FRONT.	TATA spare parts
262852333101	CYL R THRUST CAGE	TATA spare parts
262852333102	CYL.ROLLER THRUST CAGE	TATA spare parts
262854209901	DIGITAL HOUR METER	TATA spare parts
262854209904	INSTRUMENT CLUSTER (1:0 88)	TATA spare parts
262854600104	WIRING HARNESS MAIN SK 1613 CMVR	TATA spare parts
262854600105	WIRING HARNESS FRONT TO TAIL SK 1613 CMV	TATA spare parts
262854600107	W/H TAIL (SK1613/36)--CMVR 697NA SK	TATA spare parts
262854600109	W/H MAIN-SK1613	TATA spare parts
262854600112	W/H MAIN SK1613 BS-II	TATA spare parts
262854600114	W/H TAIL SK1613/36 BS-II	TATA spare parts
262854600115	W/H MAIN(SK1613 BS-II INST.)	TATA spare parts

262854620108	WIRING HARNESS TAIL-SK1613/36	TATA spare parts
262854620110	WIRING HARNESS MAIN SK 1613	TATA spare parts
262854620113	WIRING HARNESS MAIN SK 1613 CMVR	TATA spare parts
262854620114	WIRING HARNESS FRONT TO TAIL SK 1613 CMV	TATA spare parts
262854620116	W/H MAIN-SK1613	TATA spare parts
262854620117	W/H TAIL (SK1613/36)--CMVR 697NA SK	TATA spare parts
262854620125	W/H MAIN(SK1613 BS-II INST.)	TATA spare parts
262854620127	W/H TAIL(SK1613/36 BS-II INST.)	TATA spare parts
262854660101	W/H MAIN-SK1613 CMVR	TATA spare parts
262854660103	WIRING HARNESS GAUGES EARTHING SE/SK 161	TATA spare parts
262854660104	WIRING HARNESS MAIN SK 1613 CMVR	TATA spare parts
262854660105	WIRING HARNESS FRONT TO TAIL SK 1613 CMV	TATA spare parts
262854660107	W/H MAIN-SK1613	TATA spare parts
262854660108	W/H TAIL (SK1613/36)--CMVR 697NA SK	TATA spare parts
262854680104	W/H TAIL (SK1613/36)--CMVR 697NA SK	TATA spare parts
262854680107	W/H MAIN SK1613 BS-II	TATA spare parts
262854680109	W/H TAIL SK1613/36 BS-II	TATA spare parts
262854680113	W/H MAIN(SK1613 BS-II INST.)	TATA spare parts
262858404002	WHEEL CHOCK-ANGLE 18X18X3 (HCVS)	TATA spare parts
262858404003	WHEEL CHOCK-ANGLE 18X18X3 (HCVS)	TATA spare parts
262858404004	WHEEL CHOCK-Angle 18x18x3 (HCVs)	TATA spare parts
262860000102	ASSY.COWL COMPLETE SK1613HD CMVR 2000RH	TATA spare parts
262868900101	ASSY.INSTRUMENT PANEL-RHD	TATA spare parts
262889100101	ASSY.BRACKET (COWL MTG.REAR) R.H.	TATA spare parts
262889100102	ASSY.BRACKET (COWL MTG.REAR) L.H.	TATA spare parts
262954400102	LAMP LOW AIR PR INDICATOR	TATA spare parts
263026700101	CON FLANGE GR SHIFT LEVER	TATA spare parts
263026700102	KNOB GEAR LEVER BS1/2/3/4	TATA spare parts
263026700103	KNOB GR SHIFT LEVER	TATA spare parts
263026700104	CON FLANGE GR SHIFT LEVER	TATA spare parts
263026707901	CONNECTING ROD	TATA spare parts
263026710101	BRACKET REMOT SHIFT RH	TATA spare parts
263026710102	BRACKET REMOT SHIFT LH	TATA spare parts
263026713701	BRACKET	TATA spare parts
263026800102	ASSY GEAR SHIFT LEVER	TATA spare parts
263026800109	ASSY BRACKET	TATA spare parts
263026800110	ASSY SELECTOR & SHIFTER FORK	TATA spare parts
263026800111	ASSY SELECTOR & SHIFTER FORK WITH GSL	TATA spare parts
263026800114	SELECT & SHIFT FORK W/GSL	TATA spare parts
263026800116	ASSLY SELECTOR & SHIFTER FORK WITH GSL	TATA spare parts
263026804201	ASSY CLAMP RUBBER BELLOW	TATA spare parts
263026805101	SELECTOR & SHIFTER YOKE	TATA spare parts
263026805102	SELECTOR & SHIFTER YOKE	TATA spare parts
263026806701	PIN	TATA spare parts
263026806702	PIN SELECT & SHIFT YOKE	TATA spare parts
263026806703	PIN-ASSY SEL.SHIFTER YOKE	TATA spare parts
263026807702	RUB BELLOW G S L TOP	TATA spare parts

263026808601	SPACER	TATA spare parts
263029100103	CLUTCH FLUID CONTAINER RH	TATA spare parts
263029100104	CLUTCH FLUID CONTAINER LH	TATA spare parts
263029105801	RUBBER HOSE	TATA spare parts
263029200101	DOUBLE LEVER BRAKE RHD	TATA spare parts
263031000110	ASSY.FRAME COMPLETE	TATA spare parts
263032800101	ASSY CONNECTING LINK	TATA spare parts
263041100103	ASSY.PROP.SHAFT WITH CENTER BRG.(L=1435)	TATA spare parts
263042800128	TUBE ASSY	TATA spare parts
263042800162	ASSY. PIPE (15 O.D.)	TATA spare parts
263042803301	BRACKET BS6-PH2	TATA spare parts
263042805801	HOSE	TATA spare parts
263042900127	ASSY TUBE	TATA spare parts
263042903302	BRACKET	TATA spare parts
263042903303	BRACKET	TATA spare parts
263042903306	BRACKET	TATA spare parts
263046000101	DRAG LINK ASSY	TATA spare parts
263046600102	ASSY.P.STG.G.BOX WITH PRS.RLF.VALVE	TATA spare parts
263054100101	ASSY BATT CABLE +VE CU 70 MM2	TATA spare parts
263058409901	TRANSFER LABEL - RUNNING IN INSTRUCTIONS	TATA spare parts
263081306301	ASSY 1613 MASCOT	TATA spare parts
263081806301	MASCOT '1613'	TATA spare parts
263115400101	ALTERNATOR 65A SINGLE GROOVE	TATA spare parts
263115400102	ALTERNATOR 65A SINGLE GROOVE	TATA spare parts
263129106001	CLUTCH RELEASE LEVER	TATA spare parts
263132103201	CENTRE BOLT	TATA spare parts
263132808601	SPACER	TATA spare parts
263133203101	TAPER ROLLER THRUST BEARING	TATA spare parts
263133400101	ASSY FRONT HUB 2516 LUG	TATA spare parts
263133400108	ASSY WHEEL HUB WITH BOLTS 2515 TC	TATA spare parts
263133405501	FRT HUB SPG 1516	TATA spare parts
263140100101	ASSY. WHEEL RIM 7.5X20 BS1/2/3/4	TATA spare parts
263140100102	ASSY.WHEEL RIM 7.5X20	TATA spare parts
263140100105	ASSY.WHEEL RIM 7.5X20	TATA spare parts
263140100106	ASSY.WHEEL RIM 7.5X20	TATA spare parts
263140100107	ASSY. WHEEL NUT M22 X 30LONG BS1/2/3/4	TATA spare parts
263140100108	WHEEL RIMS	TATA spare parts
263140100125	ASSYWHEELRIM	TATA spare parts
263140100126	ASSY WHEEL RIM	TATA spare parts
263140100130	ASSY WHEEL RIM 7.5 X 20	TATA spare parts
263140100132	WHEEL RIM ASSY	TATA spare parts
263140100134	WHEEL RIM ASSY	TATA spare parts
263140100135	WHEEL DISC WITHOUT LOCK RING	TATA spare parts
263140100136	ASSY.WHEEL RIM 7.5 X 20	TATA spare parts
263140100143	ASSY WHEEL RIM 7.5X20	TATA spare parts
263140100144	ASSY. WHEEL RIM BS1/2/3/4/6	TATA spare parts
263140106701	HUB BOLT FRONT M22 BS1/2/3/4/6	TATA spare parts

263140107102	SIDE RING FOR WHEEL RIM 0105	TATA spare parts
263140107103	SIDE RING FOR WHEEL RIM 0106	TATA spare parts
263140107104	LOCK RING FOR WHEEL RIM 0106	TATA spare parts
263140109908	WHEEL RIM BASE	TATA spare parts
263140206701	HUB BOLT REAR- M22 BS1/2/3/4	TATA spare parts
263142103701	BRAKE DRUM SPIGOTTED. BS1/2/3/4	TATA spare parts
263142103701AE	BRAKE DRUMS FRONT 2523	TATA spare parts
263142300101	ASSY.SLACK ADJUSTER- RH -REAR	TATA spare parts
263142300102	ASSY.SLACK ADJUSTER -LH -REAR	TATA spare parts
263142300103	SLACK ADJUSTER RH	TATA spare parts
263142300104	SLACK ADJUSTER LH	TATA spare parts
263142303702	BRAKE DRUM SPIGOTTED	TATA spare parts
263142400101	PULL ROD ASSY	TATA spare parts
263142400102	ASSY.CLAMP	TATA spare parts
263142700101	ASSY.BRACKET (H.B.V. MTG.)-R.H.	TATA spare parts
263142900101	ASSY.TUBE	TATA spare parts
263143700101	4 WAY SYSTEM PROTECTION VALVE	TATA spare parts
263146000101	ASSY DRAG LINK	TATA spare parts
263154103201	STUD	TATA spare parts
263154209901	VOLTMETER	TATA spare parts
263154209902	SPEEDOMETER 1:0.95 - OFFER	TATA spare parts
263154209904	VOLTMETER	TATA spare parts
263154209905	3.2 DIA SPEEDOCABLE (3000LG.) - OFFER	TATA spare parts
263154209906	BEEPER UNIT 24V	TATA spare parts
263154400101	HALO. HEAD LAMP W/BULBS RH 12V BS1/2/3	TATA spare parts
263154400102	HEAD LAMP W/BULBS LH(HALO.)RHD 12V BS1-3	TATA spare parts
263154400106	HALO.HEAD LAMP W/BULBS RH RHD 12V	TATA spare parts
263154400107	HALO.HEAD LAMP W/BULBS LH RHD 12V	TATA spare parts
263154400116	HEAD LAMP 12V E-CERT W/BULB RH RHD	TATA spare parts
263154400117	HEAD LAMP 12V E-CERT W/BULB LH RHD	TATA spare parts
263154506901	PIANO KEY SWITCH	TATA spare parts
263154506902	PIANO KEY SWITCH	TATA spare parts
263154506903	PIANO KEY SWITCH	TATA spare parts
263154506904	PIANO KEY SWITCH	TATA spare parts
263154506906	PIANO KEY SWITCH	TATA spare parts
263154540101	HAZARD WARNING SWITCH 24V - OFFER	TATA spare parts
263154600105	ASSY.CABLE SET(FRONT TO TAIL)LPS32 S-CAM	TATA spare parts
263154609901	JUMPER CABLE	TATA spare parts
263154809901	COVER WARNING LAMP	TATA spare parts
263198800101	ASSY.MASCOT 1616	TATA spare parts
263198800102	ASSY MASCOT TURBO	TATA spare parts
263215100101	STARTER MOTOR-12V	TATA spare parts
263215100102	STARTER MOTOR BS1/2/3/4	TATA spare parts
263215100103	ALTERNATOR 12V(SA23-65AMP)-OFFER	TATA spare parts
263215100104	STARTER MOTOR-12V	TATA spare parts
263215100105	STARTER MOTOR-12V	TATA spare parts
263215100106	STARTER MOTOR-12V	TATA spare parts

263215400102	ALTERNATOR (12V 35AMPS.2GRV.PULLEY)	TATA spare parts
263215400103	ALTERNATOR (12V 40AMPS. 2GRV.PULLEY)	TATA spare parts
263224100101	HOUSING ENGINE MTG	TATA spare parts
263224100102	ASSY ENGINE MTG PAD RH (FRONT) SE1613	TATA spare parts
263224100104	ASSY ENG. MTG PAD LH-FRONT	TATA spare parts
263224100106	ASSY ENG MTG PAD (FRONT) RH	TATA spare parts
263224200101	HOUSING RH ENGINE MTG	TATA spare parts
263224200102	HOUSING LH ENGINE MTG	TATA spare parts
263224200103	ASSY. RUBBER SUPPORT REAR RH BS1/2/3/4	TATA spare parts
263224200104	ASSY. RUBBER SUPPORT REAR LH BS1/2/3/4	TATA spare parts
263224200105	ASSY HOUSING RH-ENG MTG PAD RR	TATA spare parts
263224200106	ASSY HOUSING LH-ENG MTG PAD RR	TATA spare parts
263225400101	PR.Plate COIL 310DIA GB40	TATA spare parts
263225400102	SPRING KIT FOR 01 01.	TATA spare parts
263226800105	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
263229100103	SUPPORT PEDAL LEVER	TATA spare parts
263229100104	ASSY.SUPPORT.	TATA spare parts
263229100110	ASSY. LEVER	TATA spare parts
263229100126	ASSY CLUTCH TUBE 6 O.D	TATA spare parts
263229100128	CLUTCH HOSE ASSY	TATA spare parts
263229100132	ASSY PEDAL COMPLETE	TATA spare parts
263229100138	ASSY CONTROL MTG BKT & TUBE	TATA spare parts
263229100139	ASSY BKT WITH STOPPER-VAR STG G. BOX	TATA spare parts
263229100142	ASSY.CLUTCH TUBE-6 O.D.	TATA spare parts
263229100144	ASSY PIPE-M/CYL TO SL.CYL	TATA spare parts
263229100155	ASSY PIPE(M/CYL TO CUTCH BOOSTER)	TATA spare parts
263229100156	ASSY CLUTCH BOOSTER	TATA spare parts
263229100157	ASSY PIPE(M/CYL TO CUTCH BOOSTER)	TATA spare parts
263229100159	ASSY.PIPE MASTER CYLINDER	TATA spare parts
263229103303	BRACKET HOSE MOUNTING	TATA spare parts
263229108702	SPRING FOR CLUTCH PEDAL RETURN	TATA spare parts
263229110108	ASSY TUBE	TATA spare parts
263229200101	ASSY INTEGRAL FORK	TATA spare parts
263229200104	ASSY PEDAL PLATE CLUTCH	TATA spare parts
263229200105	PEDAL PLATE BRAKE	TATA spare parts
263229300104	ASSY. PUSH ROD	TATA spare parts
263229303201	PUSH ROD	TATA spare parts
263229500101	SUPPORT ASSY	TATA spare parts
263229500102	ASSY BRACKET STRG. & PEDALS	TATA spare parts
263229500108	ASSY CONTROL & V STG G BOX & PITMAN ARM	TATA spare parts
263229500114	ASSY CONTROL MTG. BKT. WITH TUBE	TATA spare parts
263230100104	ASSY. SUPPORT BRACKET FOR CABLE HOLDER	TATA spare parts
263230100106	ASSY.ACCELERATOR LEVER (RFOB)	TATA spare parts
263230100119	ASSY. SUPPORT BRACKET FOR CABLE HOLDER	TATA spare parts
263230100120	ASSY PULL ROD COMPLETE (WITH FORK)	TATA spare parts
263230100121	ASSY STOP CABLE MTG BKT.	TATA spare parts
263230100122	ASSY ACCELERATOR LEVER (RFOB)	TATA spare parts

263231000102	FRAME 1612/48	TATA spare parts
263231000120	ASSY FRAME LPT1613/42TUR. 330 DIA CLUTCH	TATA spare parts
263231000121	ASSY.FRAME-LPT 1613/48-47 % ROH	TATA spare parts
263231000123	ASSY FRAME LPT/48 CMVR 330D P/STG.	TATA spare parts
263231000127	ASSY. FRAME LPT1613TURBO_42 TLT CAB BS-2	TATA spare parts
263231000133	ASSY FRAME COMPLETE	TATA spare parts
263231000147	FRAME ASSY LPS1612/32 LE	TATA spare parts
263231000160	ASSY. FRAME- 168 DEEP TAIL END	TATA spare parts
263231000175	ASSY.FRAME COMPLETE	TATA spare parts
263231000178	ASSY FRAME RHD 42SE(SCAM/DAOH)195 DEEP	TATA spare parts
263231000180	ASSY FRAME SE1613/42 TURBO 195 DEEP	TATA spare parts
263231000181	ASSY FRAME COMP RHD 42SE(SCAM)195 DEEP	TATA spare parts
263231000184	ASSY FRAME LPT 1613 W 697 BS-II W/O FUPD	TATA spare parts
263231000187	ASSY FRAME LPT 1613 W 697TCIC BS-II COWL	TATA spare parts
263231000189	ASSY FRAME LPT 1613 W 697 BS-II WITH FUP	TATA spare parts
263231000190	ASSY. FRAME COMPLETE (48WB COWL)	TATA spare parts
263231100101	ASSY. EXTENSION PIECE RH	TATA spare parts
263231100102	ASSY. EXTENTION PIECE LH	TATA spare parts
263231107174	RADIATOR MOUNTING BRACKET R.H.	TATA spare parts
263231107175	RADIATOR MOUNTING BRACKET L.H.	TATA spare parts
263231200101	RUBBER BUFFER	TATA spare parts
263231200103	ASSY. CENTRE BRG. CROSS MEMBER.-SP	TATA spare parts
263231200105	ASSY. CROSS MEMBER.-SP	TATA spare parts
263231200110	ASSY ENG CROSS MEMBER REAR	TATA spare parts
263231200113	ASSY SPACER PLATE ENG CROSS MEMBER	TATA spare parts
263231200114	ASSY SUPPORT RH ENG CROSS MEMBER RR	TATA spare parts
263231200115	ASSY SUPPORT LH ENG CROSS MEMBER RR	TATA spare parts
263231200116	ASSY. BRACKET-LH(AUX WATER TANK BKT MTG)	TATA spare parts
263231200117	ASSY. BRACKET-RH(AUX WATER TANK BKT MTG)	TATA spare parts
263231200118	ASSY SUPPORT (ENG CROSS MEMBER-REAR)	TATA spare parts
263231200119	ASSY. CROSS MEMBER-REAR SPRING	TATA spare parts
263231200120	ASSY. CROSS MEMBER-REAR SPRING	TATA spare parts
263231200122	ASSY SUPPORT RH - ENG CM FRONT	TATA spare parts
263231200123	ASSY SUPPORT LH - ENG CM FRONT	TATA spare parts
263231200124	ASSY BRACKET-RADIATOR MTG RH	TATA spare parts
263231200125	ASSY BRACKET-RADIATOR MTG LH	TATA spare parts
263231200126	ASSY C.B. CROSS MEMBER	TATA spare parts
263231200129	ASSY.CROSS MEMBER WITH REINFORCEMENTS	TATA spare parts
263231200131	ASSY BRACKET-RH (RADIATOR MTG)-CAB	TATA spare parts
263231200132	ASSY BRACKET-LH (RADIATOR MTG)-CAB	TATA spare parts
263231200142	ASSY FRONT CROSS MEMBER WITH TOWING HOC	TATA spare parts
263231207113	SUPPORT-ENGINE CROSS MEMBER REAR	TATA spare parts
263231207130	REINFORCEMENT-REAR C/M	TATA spare parts
263231207138	REINFORCEMENT-TOP LH	TATA spare parts
263231207139	REINFORCEMENT-TOP RH	TATA spare parts
263231207140	REINFORCEMENT - BOTTOM LH	TATA spare parts
263231207141	REINFORCEMENT - BOTTOM RH	TATA spare parts

263231207150	FRAME REINFORCEMENT-BOTTOM-LH	TATA spare parts
263231207151	FRAME REINFORCEMENT-BOTTOM-RH	TATA spare parts
263231606701	STOPPER	TATA spare parts
263231700101	ASSY.REAR UNDERRUN PROTECTIVE DEVICE COM	TATA spare parts
263231700102	ASSY.SUPPORT-LH	TATA spare parts
263231700103	ASSY.SUPPORT-RH	TATA spare parts
263231700104	ASSY. END CROSS MEMBER	TATA spare parts
263231700106	ASSY.BOTTOM SHIELD(ENG)LPT1613CMVR BS-2	TATA spare parts
263231700108	ASSY.SUPPORT BRACKET(ENGINE SIDE)	TATA spare parts
263231700109	ASSY BOTTOM SHIELD.(RAD SIDE)LPT1613 CMV	TATA spare parts
263231700111	ASSY. BOTTOM SHIELD(ENGINE)	TATA spare parts
263231700116	ASSY TRANS.SHIELD(FRT SIDE)LPT1613CMVR	TATA spare parts
263231700117	ASSY TRANSMISSION SHIELD(RR SIDE)	TATA spare parts
263231700130	ASSY.REAR UNDERRUN PROTECTIVE DEVICE COM	TATA spare parts
263231700131	ASSY.BRACKET-LH	TATA spare parts
263231700132	ASSY.BRACKET-RH	TATA spare parts
263231700133	ASSY. CHANNEL (RUPD)	TATA spare parts
263231700134	ASSY.SUPPORT	TATA spare parts
263231700137	ASSY.BRACKET-LH	TATA spare parts
263231700138	ASSY.BRACKET-RH	TATA spare parts
263231700139	ASSY.CHANNEL (RUPD)	TATA spare parts
263231700141	ASSY.REAR UNDERRUN PROTECTIVE DEVICE COM	TATA spare parts
263231703302	SUPPORT BRACKET(TRANSMISSION SIDE)	TATA spare parts
263231706901	TUBE-32 DIA.	TATA spare parts
263231707113	SIDE PLATE	TATA spare parts
263231707115	SPACER	TATA spare parts
263231707126	SPACER	TATA spare parts
263231708801	STUD-M16X1.5	TATA spare parts
263232100105	ASSY FRONT SPRING	TATA spare parts
263232100107	ASSY FRONT SPRING	TATA spare parts
263232100109	ASSY FRONT SPRING	TATA spare parts
263232100110	ASSY FRONT SPRING	TATA spare parts
263232100113	ASSY FRONT SPRING	TATA spare parts
263232100124	ASSY.FIRST LEAF WITH BUSHES	TATA spare parts
263232100124DF	MAIN LEAF FRONT W/BUSH - LPO1512/1613	TATA spare parts
263232100127	ASSY. BRACKET-RH-FRT. AXLE STOPPER	TATA spare parts
263232100128	ASSY. BRACKET-LH-FRT. AXLE STOPPER	TATA spare parts
263232100130	ASSY. FRONT SPRING	TATA spare parts
263232100131	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
263232100137	ASSY. SPRING (FRONT)	TATA spare parts
263232100138	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
263232103201	CENTRE BOLT	TATA spare parts
263232103202	CENTRE BOLT	TATA spare parts
263232104203	SPRING CLIP	TATA spare parts
263232104205	SPRING CLIP	TATA spare parts
263232104210	SPRING CLIP	TATA spare parts
263232104211	SPRING CLIP	TATA spare parts



263232107113	FIRST LEAF	TATA spare parts
263232107114	SECOND LEAF	TATA spare parts
263232107114DF	SECOND LEAF FRONT - LPO1512/1613	TATA spare parts
263232107115	THIRD LEAF	TATA spare parts
263232107116	FOURTH LEAF	TATA spare parts
263232107146	SPACER PLATE	TATA spare parts
263232107148	SECOND LEAF	TATA spare parts
263232107149	THIRD LEAF	TATA spare parts
263232107150	FOURTH LEAF	TATA spare parts
263232107151	FIFTH LEAF	TATA spare parts
263232107152	SIXTH LEAF	TATA spare parts
263232107153	SEVENTH LEAF	TATA spare parts
263232107154	EIGHT LEAF	TATA spare parts
263232107155	NINTH LEAF	TATA spare parts
263232107156	TENTH LEAF	TATA spare parts
263232107157	ELEVENTH LEAF	TATA spare parts
263232107158	PACKING PLATE (FRONT SPRING)	TATA spare parts
263232107159	PACKING PLATE (FRONT SPRING)	TATA spare parts
263232107160	FIFTH LEAF	TATA spare parts
263232107161	SIXTH LEAF	TATA spare parts
263232107176	SECOND LEAF	TATA spare parts
263232107177	THIRD LEAF	TATA spare parts
263232107178	FOURTH LEAF	TATA spare parts
263232107179	FIFTH LEAF	TATA spare parts
263232107180	SIXTH LEAF	TATA spare parts
263232107181	SEVENTH LEAF	TATA spare parts
263232107182	EIGHTH LEAF	TATA spare parts
263232107183	NINTH LEAF	TATA spare parts
263232108601	SPACER TUBE	TATA spare parts
263232108603	SPACER (LEAF SPRING CLIP)	TATA spare parts
263232204201	U CLAMP	TATA spare parts
263232204202	U BOLT ( M20 X 1.5 X 245)	TATA spare parts
263232204203	U BOLT ( M22 X 1.5 X 288)	TATA spare parts
263232208601	SPACER	TATA spare parts
263232300101	ASSY.BRACKET- FRONT SHOCK ABSORBER	TATA spare parts
263232300103	ASSY BRACKET-LH(FRT SHOCK ABSORBER)	TATA spare parts
263232300104	ASSY BRACKET-RH (FRT SHOCK ABSORBER)	TATA spare parts
263232308601	SPACER	TATA spare parts
263232400102	ASSY REAR SPRING WITH AUX.SPRING	TATA spare parts
263232400104	ASSY REAR SPRING WITH AUX.SPRING	TATA spare parts
263232400105	ASSY REAR SPRING WITH AUX.SPRING	TATA spare parts
263232400106	ASSY REAR SPRING WITH AUX.SPRING	TATA spare parts
263232400107	ASSY REAR SPRING WITH AUX.SPRING	TATA spare parts
263232400108	ASSY REAR SPRING WITH AUX.SPRING	TATA spare parts
263232400112	ASSY.REAR SPRING WITH AUXILIARY SPRING	TATA spare parts
263232400113	ASSY.FIRST LEAF WITH BUSH	TATA spare parts
263232400114	ASSY. REAR SPRING-WITH AUX. SPRING	TATA spare parts

263232400115	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
263232400115AE	ASSY FIRST LEAF WITH BUSHES-1628	TATA spare parts
263232400115DF	MAIN LEAF REAR W/BUSH - SK1613/LPK1615	TATA spare parts
263232400116	ASSY. REAR SPRING (W AUX. SPRING) SE/SK	TATA spare parts
263232400118	ASSY REAR SPRING (WITH AUX SPRING)	TATA spare parts
263232400119	ASSY FIRST LEAF WITH BUSH	TATA spare parts
263232403202	CENTRE BOLT	TATA spare parts
263232403203	CENTRE BOLT	TATA spare parts
263232404203	SPRING CLIP	TATA spare parts
263232404204	U CLAMP	TATA spare parts
263232404205	SPRING CLIP	TATA spare parts
263232404209	SPRING CLIP	TATA spare parts
263232404211	SPRING CLIP	TATA spare parts
263232404215	SPRING CLIP (AUX. SPRING)	TATA spare parts
263232404215AE	AUX. SPRING CLIP RR SPRING 1628	TATA spare parts
263232404216	U CLAMP	TATA spare parts
263232404217	U CLAMP (TABLE DRG.)	TATA spare parts
263232404218	SPRING CLIP (MAIN SPRING)	TATA spare parts
263232404219	SPRING CLIP (174 MM X 81 MM)	TATA spare parts
263232404220	SPRING CLIP (114 MM X 81 MM)	TATA spare parts
263232404221	SPRING CLIP (MAIN SPRING)	TATA spare parts
263232404222	SPRING CLIP (MAIN SPRING)	TATA spare parts
263232407135	SECOND LEAF (MAIN PACK)	TATA spare parts
263232407136	THIRD LEAF (MAIN PACK)	TATA spare parts
263232407137	FOURTH LEAF (MAIN PACK)	TATA spare parts
263232407138	FIFTH LEAF (MAIN PACK)	TATA spare parts
263232407139	SIXTH LEAF (MAIN PACK)	TATA spare parts
263232407140	SEVENTH LEAF (MAIN PACK)	TATA spare parts
263232407141	EIGHTH LEAF (MAIN LEAF)	TATA spare parts
263232407142	NINETH LEAF (MAIN PACK)	TATA spare parts
263232407143	TENTH LEAF (MAIN PACK)	TATA spare parts
263232407144	ELEVENTH LEAF (MAIN PACK)	TATA spare parts
263232407145	TWELVETH LEAF (MAIN PACK)	TATA spare parts
263232407146	THIRTEENTH LEAF (MAIN PACK)	TATA spare parts
263232407147	FOURTEENTH LEAF (MAIN PACK)	TATA spare parts
263232407148	FIRST LEAF (AUXILIARY PACK)	TATA spare parts
263232407149	SECOND LEAF (AUXILIARY PACK)	TATA spare parts
263232407150	THIRD LEAF (AUXILIARY PACK)	TATA spare parts
263232407151	FOURTH LEAF (AUXILIARY PACK)	TATA spare parts
263232407152	FIFTH LEAF (AUXILIARY PACK)	TATA spare parts
263232407153	SIXTH LEAF (AUXILIARY PACK)	TATA spare parts
263232407154	SEVENTH LEAF (AUXILIARY PACK)	TATA spare parts
263232407155	FIRST LEAF	TATA spare parts
263232407156	SECOND LEAF	TATA spare parts
263232407156DF	SECOND LEAF REAR - SK1613/LPK1615	TATA spare parts
263232407157	THIRD LEAF (MAIN PACK)	TATA spare parts
263232407157AE	LEAF3 1628	TATA spare parts

263232407157DF	THIRD LEAF REAR - SK1613/LPK1615	TATA spare parts
263232407158	FOURTH LEAF (MAIN PACK)	TATA spare parts
263232407158DF	FOURTH LEAF REAR - SK1613/LPK1615	TATA spare parts
263232407159	FIFTH LEAF (MAIN PACK)	TATA spare parts
263232407159DF	FIFTH LEAF REAR - SK1613/LPK1615	TATA spare parts
263232407160	SIXTH LEAF (MAIN PACK)	TATA spare parts
263232407161	SEVENTH LEAF (MAIN PACK)	TATA spare parts
263232407162	EIGHTH LEAF (MAIN PACK)	TATA spare parts
263232407163	NINETH LEAF (MAIN PACK)	TATA spare parts
263232407164	TENTH LEAF (MAIN PACK)	TATA spare parts
263232407165	ELEVENTH LEAF (MAIN PACK)	TATA spare parts
263232407166	TWELTH LEAF (MAIN PACK)	TATA spare parts
263232407167	THIRTEENTH LEAF (MAIN PACK)	TATA spare parts
263232407168	FIRST LEAF (AUXILIARY PACK)	TATA spare parts
263232407168DF	MAIN LEAF HELPER - SK1613/LPK1615	TATA spare parts
263232407169	SECOND LEAF (AUXILIARY PACK)	TATA spare parts
263232407169DF	SECOND LEAF HELPER - SK1613/LPK1615	TATA spare parts
263232407170	THIRD LEAF (AUXILIARY PACK)	TATA spare parts
263232407170DF	THIRD LEAF HELPER - SK1613/LPK1615	TATA spare parts
263232407171	SECOND LEAF (MAIN PACK)	TATA spare parts
263232407173	SECOND LEAF	TATA spare parts
263232407174	THIRD LEAF	TATA spare parts
263232407175	FOURTH LEAF	TATA spare parts
263232407176	FIFTH LEAF	TATA spare parts
263232407177	SIXTH LEAF	TATA spare parts
263232407178	SEVENTH LEAF	TATA spare parts
263232407179	EIGHT LEAF	TATA spare parts
263232407180	NINTH LEAF	TATA spare parts
263232407181	TENTH LEAF	TATA spare parts
263232407182	AUX.FIRST LEAF	TATA spare parts
263232407183	AUX.SECOND LEAF	TATA spare parts
263232407184	AUX.THIRD LEAF	TATA spare parts
263232408603	SPACER(Spring CLIP)	TATA spare parts
263232408604	SPACER (LEAF SPRING CLIP)	TATA spare parts
263232503701	GUIDE PLATE REAR-CASTING	TATA spare parts
263232503703	GUIDE PLATE-CASTING	TATA spare parts
263232505101	GUIDE PLATE REAR	TATA spare parts
263232506501	NUT U CLAMP LPK 2516TC	TATA spare parts
263233000103	ASSY.FRONT AXLE COMPLETE	TATA spare parts
263233000104	ASSY.FRONT AXLE 1613 SE	TATA spare parts
263233000106	FRONT AXLE SCAM NON SPIG	TATA spare parts
263233000108	ASSY.FRONT AXLE.SK / SE 1613	TATA spare parts
263233000118	ASSY FRONT AXLE WT BRAKES	TATA spare parts
263233000122	ASSY.FRONT AXLE WITH BRAKES	TATA spare parts
263233100105	ASSY. SEALING CAP.	TATA spare parts
263233200101	ASSY STUB AXLE NORMAL	TATA spare parts
263233200105	ASSY. STUB AXLE(ABS)-RH NORMAL BS1/2/3/4	TATA spare parts

263233200107	ASSY. STUB AXLE(ABS)-LH NORMAL BS1/2/3/4	TATA spare parts
263233209201	THRUST WASHER (FOR STUB AXLE)(1.8 THK.)	TATA spare parts
263233209202	THRUST WASHER (FOR STUB AXLE)(1.9 THK)	TATA spare parts
263233209204	THRUSTWASHER(FORSTUBAXLE)(2.1THK) BS6	TATA spare parts
263233209205	THRUSTWASHER(FORSTUBAXLE)(2.2THK) BS6	TATA spare parts
263233209215	THRUST WASHER (FOR STUB AXLE)(1.25 THK.)	TATA spare parts
263233209216	THRUST WASHER (FOR STUB AXLE)(1.35 THK.)	TATA spare parts
263233209217	THRUST WASHER (FOR STUB AXLE)(1.45 THK.)	TATA spare parts
263233209218	THRUST WASHER (FOR STUB AXLE)(1.55 THK.)	TATA spare parts
263233209219	THRUST WASHER (FOR STUB AXLE)(1.65 THK.)	TATA spare parts
263233400101	HUB FRONT W/O BRG NON SPI	TATA spare parts
263233400104	ASSY.WHEEL HUB COMPLETE WITH POLE WHEEL	TATA spare parts
263233400105	ASSY.WHEEL HUB WITH POLE WHEEL W/O BEARI	TATA spare parts
263233403101	TAPER ROLLER BEARING	TATA spare parts
263233403102	TAPER ROLLER BEARING	TATA spare parts
263233405102	FRONT HUB	TATA spare parts
263233405301	PACKING (HUB COVER)	TATA spare parts
263233408201	FRONT HUB COVER	TATA spare parts
263233408301	SHIM 0.15 MM THK.	TATA spare parts
263233408302	SHIM 0.25THK.	TATA spare parts
263233805101	STEERING ARM-TOP	TATA spare parts
263240100102	ASSY WHEEL DISC & RIM 7.00X20	TATA spare parts
263240100102AE	ASSY WHEEL DISC & RIM 7.00X20	TATA spare parts
263240100103	ASSY WHEEL DISC & RIM 7X20	TATA spare parts
263240100104	ASSY WHEEL DISC & RIM 7X20	TATA spare parts
263240100105	ASSY.WH DISC & RIM 7X20 NEW ACC.HOLE	TATA spare parts
263240100107	ASSY. WHEEL RIM 7.0X20-157 OFFSET	TATA spare parts
263240100109	ASSY WHEEL DISC & RIM 7.00X20	TATA spare parts
263240100110	ASSY WHEEL DISC & RIM 7.00X20	TATA spare parts
263240300101	ASSY.SPARE WHEEL CARRIER-RHD	TATA spare parts
263240300111	ASSY.SPARE WHEEL CARRIER	TATA spare parts
263241100101	PROP SHAFT FR W/CEN BRG	TATA spare parts
263241100107	ASSY.KIT-END PIECE+NIPPLE+SET SCR+NUT	TATA spare parts
263241100108	ASSY.KIT (END PIECE+NIPPLE+SET SCR+NUT)	TATA spare parts
263241100111	ASSY.PROP.SHAFT WITH CENTER BRG.(L=1904)	TATA spare parts
263241100117	UNIVERSAL JOINT BS1/2/3	TATA spare parts
263241100118	ASSY. CENTER BEARING BS2	TATA spare parts
263241100128	PROP SHAFT FR 76X4X457	TATA spare parts
263241100131	ASSY PROP SHAFT COMP WT C BRG	TATA spare parts
263241100138	ASSY. PROP. SHAFT WITH C.B.	TATA spare parts
263241100142	ASSY.PROP.SHAFT FRONT	TATA spare parts
263241100146	ASSY PROPSHAFT FRONT	TATA spare parts
263241105103	COUPLING FLANGE	TATA spare parts
263241105105	FLANGE YOKE	TATA spare parts
263241105106	U.J.SHORT FORK	TATA spare parts
263241105107	FRONT END PIECE	TATA spare parts
263241105108	COUPLING FLANGE	TATA spare parts

263241106501	HEX NUT	TATA spare parts
263241109901	SHORT FORK TUBE AND FRT END PIECE SUB AS	TATA spare parts
263241110108	1464 90 DIA ASSY P/SHAFT FRONT WITH C B	TATA spare parts
263241110111	COUPLING FLANGE 8 HOLE	TATA spare parts
263241110115	APSC W CB 1313 FRONT L=685	TATA spare parts
263241110119	PROP SHAFT FR 90X3X378	TATA spare parts
263241110120	PROP SHAFT FR 90X3X1039	TATA spare parts
263241110121	A.P.S.FRT/1612 SK	TATA spare parts
263241110122	ASSY PROP SHAFT FRONT	TATA spare parts
263241110125	COUPLING SHAFT	TATA spare parts
263241110130	KIT CENTRE BRG	TATA spare parts
263241110131	ASSY CENTRE BRG WITH RET.	TATA spare parts
263241110132	PROP SHAFT W/O CB	TATA spare parts
263241110133	UJ CROSS & BRG KIT	TATA spare parts
263241110134	SLIP YOKE ASSEMBLY	TATA spare parts
263241110135	FRONT TEETH 1612	TATA spare parts
263241110136	PROPELLER SHAFT FRONT	TATA spare parts
263241110137	PROP.SHAFT FRT.SE1613/42	TATA spare parts
263241110138	PROPELLER SHAFT MIDDLE	TATA spare parts
263241110143	ASSY.KIT FOR PROP.SHAFTS & END YOKES.	TATA spare parts
263241110150	ASSY.PROP.SHAFT WITH SEALED C.B.(L=1148)	TATA spare parts
263241113201	SCREW 3/8	TATA spare parts
263241114201	BEARING STRAP	TATA spare parts
263241115104	INT END YOKE	TATA spare parts
263241116301	RUBBER CENTRE BEARING	TATA spare parts
263241116501	NUT INT END YOKE	TATA spare parts
263241120101	PPOP SHAFT RR TL 1144	TATA spare parts
263241120104	PROP SHAFT REAR	TATA spare parts
263241120105	PROPEELER SHAFT REAR LP1510/52	TATA spare parts
263241120106	PROP.SHAFT RR.LPT1613/48	TATA spare parts
263241120110	ASSY.PROP.SHAFT REAR COMP.(1677 CLOSED)	TATA spare parts
263241120113	ASSY. UNIV. JOINT LONG FORK	TATA spare parts
263241120114	ASSY.UNIVERSAL JOINT LONG FORK	TATA spare parts
263241120115	ASSY.PROP.SHAFT REAR C.L=1656)	TATA spare parts
263241120121	ASSY PROPSHAFT REAR	TATA spare parts
263241120124	ASSY PROPSHAFT REAR	TATA spare parts
263241120126	ASSY.PROP.SHAFT REAR-L=1624	TATA spare parts
263241120128	ASSY.PROP.SHAFT REAR ( 1613 109RR)	TATA spare parts
263241120132	ASSY. PROP SHAFT REAR (CL-1549)	TATA spare parts
263241125103	LONG FORK	TATA spare parts
263241125106	END PIECE 63 MM SLIP(PROP.SHAFT REAR)	TATA spare parts
263241125109	REAR HOUSING	TATA spare parts
263241127701	DUST SEAL (REAR PROP SHAFT)	TATA spare parts
263241128201	DUST SEAL RETAINER (REAR PROP.SHAFT)	TATA spare parts
263241128202	SHIM	TATA spare parts
263241129903	SHORT FORK TUBE AND REAR HSG SUB ASSY	TATA spare parts
263241300102	CENTRE BEARING W/BKT BS2/3	TATA spare parts

263241300103	ASSY. CENTER BEARING BRACKET. BS1/2/3/4	TATA spare parts
263241300104	ASSY.CENTRE BEARING BRACKET(GREASABLE)	TATA spare parts
263241300105	ASSY.SEALED CENTER BEARING	TATA spare parts
263241300106	ASSY. CENTER BEARING BRACKET BS1/2/3/4	TATA spare parts
263241303101	SRDG BALL BRG	TATA spare parts
263241303102	SRDG BALL BEARING	TATA spare parts
263241303105	SEALED CENTER BEARING	TATA spare parts
263241303302	CENTRE BRG.BRACKET.	TATA spare parts
263241303307	BRACKET CENTER BRG MTG BS6	TATA spare parts
263241303308	BRACKET CENTER BRG MTG BS6	TATA spare parts
263241304201	CLAMP	TATA spare parts
263241307501	RUBBER HOUSING (CENTER BEARING)	TATA spare parts
263241307801	OIL SEAL PROP SHAFT 1612	TATA spare parts
263241308202	DUST COVER	TATA spare parts
263241308204	DUST COVER (SEALED BRG)	TATA spare parts
263241308206	PROP.SHAFT GUARD	TATA spare parts
263241308602	SPACER	TATA spare parts
263242100107	TYPE 20 BOOSTERS-LH	TATA spare parts
263242100108	TYPE 20 BOOSTERS-RH	TATA spare parts
263242100117	ASSY.DRUM BRAKE RH-WITH SL.ADJ	TATA spare parts
263242100118	ASSY.DRUM BRAKE LH-WITH SL.ADJ	TATA spare parts
263242100132	ASSY.DRUM BRAKE RH FRT WT D.C.& M.FS	TATA spare parts
263242100136	ASSY.DRUM BRAKE LH FRT WT D.C.& M.FS	TATA spare parts
263242100153	ASSY F/A BRAKE RH WITH D COVER	TATA spare parts
263242100154	ASSY F/A BRAKE LH WITH D COVER	TATA spare parts
263242100220	ASSY FRONT AXLE BRAKE RH WITH DUST COVER	TATA spare parts
263242100221	ASSY FRONT AXLE BRAKE LH WITH DUST COVER	TATA spare parts
263242100236	ASSY FRONT BRAKE RH WITH D/C RAF7 LINING	TATA spare parts
263242100240	ASSY FRONT BRAKE LH WITH D/C.RAF7 LINING	TATA spare parts
263242100246	ASSY F/A BRAKE RH WITH DUST COVER	TATA spare parts
263242100250	ASSY F/A BRAKE LH WITH DUST COVER	TATA spare parts
263242100261	SPIDER ASSY-LH WITH BUSHES & SEAL	TATA spare parts
263242100262	SPIDER ASSY-RH WITH BUSHES & SEAL	TATA spare parts
263242100263	BRACKET ASSY-LH	TATA spare parts
263242100264	BRACKET ASSY-RH	TATA spare parts
263242103402	SENSOR BUSH(WABCO)-FOR ABS	TATA spare parts
263242103403	SENSOR BUSH-ABS	TATA spare parts
263242103701	BRAKE DRUM ( 8 BOLTS)	TATA spare parts
263242103702	BRAKE DRUM 410X180 BS1/2/3/4	TATA spare parts
263242109201	WASHER -BRACKET ASSY	TATA spare parts
263242130102	KIT-REAR BRAKE LINER BS1/2/3/4	TATA spare parts
263242130102AE	BRAKE LINERS REAR 2523	TATA spare parts
263242130104	BRAKE SHOE LINING	TATA spare parts
263242130104AE	BRAKE LINERS FRT -2523-1628-1828	TATA spare parts
263242300106	SPRING BRAKE ACTUATOR	TATA spare parts
263242300107	ASSY BRAKE CHAMBER	TATA spare parts
263242300136	ASSY REAR BRAKE RH(AF235)WT DCOVER	TATA spare parts

263242300137	ASSY REAR BRAKE LH(AF235)WT DCOVER	TATA spare parts
263242300229	ASSY R/A BRAKE RH WITH DUST COVER	TATA spare parts
263242300230	ASSY R/A BRAKE LH WITH DUST COVER	TATA spare parts
263242300238	ASSY R/A BRAKE WITH DUST COVER RH	TATA spare parts
263242300239	ASSY R/A BRAKE WITH DUST COVER LH	TATA spare parts
263242300360	BRACKET ASSY ACTUATOR MTG REAR-LH	TATA spare parts
263242300361	BRACKET ASSY ACTUATOR MTG REAR-RH	TATA spare parts
263242303303	ABS SENSOR MOUNTING BRACKET	TATA spare parts
263242303702	CHAMBER MTG.BRACKET L.H.	TATA spare parts
263242303703	CHAMBER MTG.BRACKET R.H.	TATA spare parts
263242303704	BRACKET REAR BRAKE CHEMBER MTG LH	TATA spare parts
263242303705	BRACKET REAR BRAKE CHEMBER MTG RH	TATA spare parts
263242303706	BRAKE CHAMBER MOUNTING BRACKET LH	TATA spare parts
263242303707	BRAKE CHAMBER MOUNTIGN BRACKET RH	TATA spare parts
263242303708	BRAKE CHAMBER MOUNTING BRACKET LH	TATA spare parts
263242303709	BRAKE CHAMBER MOUNTING BRACKET RH	TATA spare parts
263242303710	ANCHOR BRACKET (FOR AUTO SLACK ADJUSTER	TATA spare parts
263242303711	ANCHOR BRACKET (FOR AUTO SLACK ADJUSTER	TATA spare parts
263242303712	BRAKE CHMABER MOUNTING BRACKET RH AAL	TATA spare parts
263242303713	BRAKE CHMABER MOUNTING BRACKET LH AAL	TATA spare parts
263242303720	CAST CHAMBER MOUNTING BRACKET.	TATA spare parts
263242303720AE	CAST CHAMBER MNTNG BRKT -1628	TATA spare parts
263242303721	CAST CHAMBER MOUNTING BRACKET RH .	TATA spare parts
263242303721AE	CAST CHMER MNTNG BRKT RH-1628	TATA spare parts
263242303723	BRAKE DRUM BALANCED(FRONT AND REAR)	TATA spare parts
263242303728	BRAKE CHAMBER MOUNTING BRACKET DTC- LH	TATA spare parts
263242303729	BRAKE CHAMBER MOUNTING BRACKET DTC- RH	TATA spare parts
263242303730	BRAKE CHAMBER MOUNTING BRACKET-LH	TATA spare parts
263242303731	BRAKE CHAMBER MOUNTING BRACKET-RH	TATA spare parts
263242303732	BRACKET-LH SBA MTG	TATA spare parts
263242303733	BRACKET-RH SBA MTG	TATA spare parts
263242303734	BRACKET-LH SBA MTG.	TATA spare parts
263242303735	BRACKET-RH SBA MTG.	TATA spare parts
263242307901	CAMSHAFT REAR RH	TATA spare parts
263242307902	CAMSHAFT REAR LH	TATA spare parts
263242308201	ANCHOR BRACKET-L.H VAVE SBA MTG.BRKT	TATA spare parts
263242308202	ANCHOR BRACKTE-R.H VAVE SBA MTG.BRKT	TATA spare parts
263242309901	POLE WHEEL-(FOR ABS BRAKE FITMENT)	TATA spare parts
263242310124	BRAKE ASSY -BRAKE SHOE W/LINING & ROLLER	TATA spare parts
263242310131	BRAKE SPRING KIT¿ BRAKE	TATA spare parts
263242310133	MINOR O/H KIT REAR	TATA spare parts
263242310134	BRAKE ASSY -BRAKE LINER KIT	TATA spare parts
263242310137	BRAKE SPRING KIT	TATA spare parts
263242310139	LINED SHOE KIT AF-235 LINING	TATA spare parts
263242310140	BRAKE SHOE & LINER KIT-AF-235 LINING	TATA spare parts
263242310141	MINOR O/H KIT	TATA spare parts
263242900101	ASSY.BRACKET FOR QUICK RELEASE VALVE	TATA spare parts

263242900109	AIR TANK	TATA spare parts
263242900141	AIR PIPE	TATA spare parts
263242900159	ASSY PIPE	TATA spare parts
263242900165	TUBE AIR FILTER (ON SENSING TANK) TO S.P	TATA spare parts
263242900166	TUBE S.P.V. PORT 22 TO AIR TANK FRONT	TATA spare parts
263242900167	TUBE AIR TANK FRONT TO D.T.V. PORT 12	TATA spare parts
263242900168	TUBE D.T.V. PORT 22 TO T.CONNECTOR ON F.	TATA spare parts
263242900169	TUBE T. CONNECTOR TO HOSE ON BR. CHBR.	TATA spare parts
263242900170	TUBE T. CONNECTOR TO HOSE ON BR. CHBR.	TATA spare parts
263242900171	TUBE AIR TANK REAR TO D.T.V. PORT 11	TATA spare parts
263242900172	TUBE D.T.V. PART 21 TO HOSE ON REAR AXLE	TATA spare parts
263242900173	TUBE T - CONNECTOR TO BRAKE ACTUATOR RH	TATA spare parts
263242900174	TUBE T - CONNECTOR TO BRAKE ACTUATOR LH	TATA spare parts
263242900175	TUBE S.P.V. PORT 23 TO BULK HEAD BODY	TATA spare parts
263242900176	TUBE BULK HEAD BODY TO H.B. VALVE	TATA spare parts
263242900177	TUBE H.B.VALVE TO BULK HEAD BODY	TATA spare parts
263242900178	TUBE BULK HEAD BODY TO HOSE	TATA spare parts
263242900179	TUBE T-CONNECTOR TO BRAKE ACTUATOR RH SI	TATA spare parts
263242900180	TUBE T-CONNECTOR TO BRAKE ACTUATOR LH SI	TATA spare parts
263242900181	TUBE S.P.V. PORT 24 TO BULK HEAD BODY	TATA spare parts
263242900182	TUBE BULK HEAD BODY TO ISOLATOR VALVE	TATA spare parts
263242900183	TUBE INSOLATOR VALVE TO EXHAUST BRAKE VA	TATA spare parts
263242900184	TUBE D.T.V.PORT NO. 12/11 TO AIR GAUGE	TATA spare parts
263242900187	SET ASSY NYLON TUBES	TATA spare parts
263242900190	ASSY.BRACKET ON R.A.FOR T CONNTR.MTG	TATA spare parts
263242900196	QUICK RELEASE VALVE 1613TC	TATA spare parts
263242903307	BRACKET FOR TEE CONR.MTG.OF FRT.BRK.CCT	TATA spare parts
263242903308	BRACKET ( FOR BRK.TUBES BELOW 3 RD.CM.)	TATA spare parts
263242908201	BRACKET	TATA spare parts
263242908601	SPACER	TATA spare parts
263242909901	ABS INSTRUCTION STICKER. BS6	TATA spare parts
263242910104	AIR TANK COMPLETE W/SUPPORT&STRAP	TATA spare parts
263242910106	ASSY.STRAP COMPLETE	TATA spare parts
263242910107	ASSY.STRAP	TATA spare parts
263242910108	ASSY.SUPPORT	TATA spare parts
263242910109	ASSY.METAL PIPE- 15 O.D.	TATA spare parts
263242910110	ASSY.METAL PIPE- 15 O.D.	TATA spare parts
263242910119	ASSY.NYLON PIPE SET CHASSIS-CMVR	TATA spare parts
263242910165	QUICK RELEASE VALVE	TATA spare parts
263242910166	ASSY.HOSE 10MMID W/BLKHDSTBY	TATA spare parts
263242910167	ASSY.HOSE 10MMID W/BLKHDSTBY	TATA spare parts
263242910189	REPAIR KIT-Q.RELEASE VALVE	TATA spare parts
263242990103	DRUM BRAKE ASSY FRONT -MAJOR SPARE KIT	TATA spare parts
263243009901	STICKER(FOR GUIDANCE HANDLING NYLON PIPE	TATA spare parts
263243200112	ASSY.AIR TANK COMPLETE FOR VOSS FITTINGS	TATA spare parts
263243200113	SUB ASSY.AIR TANKS 230STRAP C.D.FOR VOSS	TATA spare parts
263243200114	ASSY. AIR TANK (FOR VOSS)	TATA spare parts



263243200115	ASSY.AIR CONTAINER	TATA spare parts
263243200119	WATER DRAIN VALVE(BRASS VER)	TATA spare parts
263243206501	NUT (FOR AIR TANK SUITABLE FOR VOSS)	TATA spare parts
263243206502	NUT AIR TANK EV	TATA spare parts
263243206503	NUT AIR TANK EV	TATA spare parts
263243207201	SEALING PLUG AM22X1.5 (FOR O-RING)	TATA spare parts
263243207701	O-RING (18X2)	TATA spare parts
263243208602	SPACER 7 MM THICK	TATA spare parts
263243509201	THRUST RING	TATA spare parts
263243700103	DDU HI PR WITH 150 MM MTG PITCH	TATA spare parts
263243700107	REPAIR KIT-QRV	TATA spare parts
263243700109	DUAL BRAKE VAVLE VOSS BS1/2/3/4	TATA spare parts
263243700109AE	DUAL BRAKE VALVE -1415	TATA spare parts
263243700112	GRAD HAND CONTR. VLV(LP SWIT&VOSS)BS1- 4	TATA spare parts
263243700112AE	HAND BRK VALVE - VOSS -1628-1828	TATA spare parts
263243700115	DIAPHRAGM-TY 14 BRAKE CHAMBER R&LH	TATA spare parts
263243700116	DIAPHRAGM-TY 16 BRAKE CHAMBER R&LH	TATA spare parts
263243700117	DESSICANT CARTRIDGE NON-UPGD DDU BS2/3/4	TATA spare parts
263243700118	REPAIR KIT-TY 9/9 SPRG BRKE ACTATOR	TATA spare parts
263243700148	QUICK RELESE VALVE WT SILEN(VOSS)	TATA spare parts
263243700150	RELAY VALVE(VOSS) BS2/3/4	TATA spare parts
263243700151	HAND BRAKE VALVE(VOSS)	TATA spare parts
263243700152	HAND BRAKE VALVE(VOSS)	TATA spare parts
263243700152AE	HAND BRAKE VALVE(VOSS)LPA 1415/	TATA spare parts
263243700153	HAND BRAKE VALVE(VOSS)KB-HBVP06003 BS6	TATA spare parts
263243700154	HAND BRAKE VALVE(VOSS) BS1/2/3/4/6	TATA spare parts
263243700155	FOUR CIRCUIT PROTECTION VALVE BS2/3/4	TATA spare parts
263243700157	SPRNG BRAKE ACTAR T24/24 VOSS RH	TATA spare parts
263243700158	SPRNG BRAKE ACTAR T24/24 VOSS LH	TATA spare parts
263243700159	SPRNG BRAKE ACTAR T20/24 VOSS RH	TATA spare parts
263243700160	SPRNG BRAKE ACTAR T20/24 VOSSLH	TATA spare parts
263243700163	FOOT BRAKE(TREADLE) VALVE VOSS	TATA spare parts
263243700165	FOOT BRAKE VALVE VOSS 74.5MM	TATA spare parts
263243700167	AIR DRYER 8.1BAR 24VHEATER(VOSS)	TATA spare parts
263243700169	AIR DRYER W/O HEATER 8.1BAR BS2/3/4	TATA spare parts
263243700176	DDU LO PR WT TYR INF WO C POR 150MTG	TATA spare parts
263243700182	QUICK RELEASE VALVE (VOSS)	TATA spare parts
263243700188	GRADUATED HAND CONTROL VALVE BS1/2/3/4	TATA spare parts
263243700188AE	GRADUATED HAND CONTROL VALVE-715	TATA spare parts
263243700202	REPAIR KIT	TATA spare parts
263243710101	REPAIR KIT FOR HAND BRAKE VALVE - VOSS	TATA spare parts
263243710102	REPAIR KIT FOR AIR DRYER	TATA spare parts
263243710103	FILTER CARTRIDGE	TATA spare parts
263243710104	REPAIR KIT FOR FCPV -VOSS	TATA spare parts
263243710107	REPAIR KIT FOR BRAKE CHAMBER TYPE 24	TATA spare parts
263243710112	ASSY MOUNTING BRACKET-MODULATOR VALVE-F	TATA spare parts
263243710114	REPAIR KIT FOR SPRING BRAKE ACTUATOR 20/	TATA spare parts

263243710115	REPAIR KIT FOR SPRING BRAKE ACTUATOR 24/	TATA spare parts
263243710116	REPAIR KIT FOR SPRING BRAKE ACTUATOR 20/	TATA spare parts
263243710117	REPAIR KIT FOR SPRING BRAKE ACTUATOR 24/	TATA spare parts
263243710124	REPAIR KIT FOR FOOT BRAKE VALVE PUSH ROD	TATA spare parts
263243710126	REPAIR KIT FOR FOOT BRAKE VALVE WITH PED	TATA spare parts
263243710136	SPRING BRAKE ACTUATOR TYPE 24/24 BS2/3/4	TATA spare parts
263243710136AE	BRAKE ACTUATOR 2523	TATA spare parts
263243710137	SPRING BRAKE ACTUATOR-VOSS+MET	TATA spare parts
263243710138	TY24/24 SPRG BRKE ACT STRGT(KB)-VOS+MET	TATA spare parts
263243710140	TY24/24 SPRG BRKE ACT STRGT	TATA spare parts
263243710142	FOUR CIRCUIT PROT.VALVE	TATA spare parts
263243710143	AIR DRYER(9BAR-VOSS)	TATA spare parts
263243710143AE	AIR DRIER 2523	TATA spare parts
263243710144	SYSTEM PROTECTION VALVE	TATA spare parts
263243710145	MINOR KIT OF 9 BAR SPV	TATA spare parts
263243710149	KIT-DUAL BRAKE VALVE	TATA spare parts
263243710150	MINOR SPARE KIT	TATA spare parts
263243710151	AIR DRYER(8.1BAR-VOSS)	TATA spare parts
263243710152	DISC BRAKE CHAMBER TYPE-22(90DEG.SHIFTED)	TATA spare parts
263243710153	MAJOR SPARE KIT	TATA spare parts
263243710154	MINOR SPARE KIT-SERVICE	TATA spare parts
263243710155	MAJOR SPARE KIT-SERVICE	TATA spare parts
263243710156	MINOR SPARE KIT-PARKING	TATA spare parts
263243710157	MAJOR SPARE KIT-PARKING	TATA spare parts
263243710160	MINOR SPARE KIT	TATA spare parts
263243710161	MAJOR SPARE KIT	TATA spare parts
263243710164	TYPE 22 CHAMBER RH	TATA spare parts
263243710165	TYPE 22 CHAMBER LH	TATA spare parts
263243710167	KIT MINOR SPARE	TATA spare parts
263243710168	KIT MAJOR SPARE	TATA spare parts
263243900103	MADULATOR VALVE (12V) ABS	TATA spare parts
263243900104	MADULATOR VALVE (12V) ABS	TATA spare parts
263243900105	MODULATOR VALVE-12V(ABS)	TATA spare parts
263243900106	ASSY.NYLON PIPE SET FOR CHASSIS-LPT1613	TATA spare parts
263243900127	ASSY.NYLON PIPE COWL SET VOSS	TATA spare parts
263243900128	ASSY.NYLON PIPE SET CHASSIS COMPL. VOSS	TATA spare parts
263243900165	ASSY.METAL PIPE WITH CRIMPED HOSE-1613	TATA spare parts
263243900167	ASSY.METAL PIPE WITH CRIMPED HOSE	TATA spare parts
263243900183	ASSY.NY.PIPE SET CAB COMPL-1613CAB/VOSS	TATA spare parts
263243903301	BRACKET-(BRAKE HOSE MTG. AT FRONT)	TATA spare parts
263243904201	CLAMP	TATA spare parts
263243904301	RETAINING RING NG8-0062009000	TATA spare parts
263243904302	RETAINING RING NG12(VOSS)	TATA spare parts
263243906501	HEX NUT NG12-VOSS	TATA spare parts
263243906502	HEX NUT NG8(0062029900)	TATA spare parts
263243906801	STRAIGHT PLUG NG8 NW4 BS6	TATA spare parts
263243906803	STRAIGHT PLUG NG12 NW9	TATA spare parts

263243906805	FIR TREE TEE 12X12X12(0023935000)	TATA spare parts
263243907701	RUBBER ELEMENT NG8-0062049900	TATA spare parts
263243907702	RUBBER ELEMENT NG12(VOSS)	TATA spare parts
263243910132	ASSY. NYLON. PIPE SET COMPL-LPT 1613	TATA spare parts
263243910143	ASSY. TEFLON HOSE (5/8 ID) BS1- 4	TATA spare parts
263243910152	TEFLON HOSE-(5/8INCH ID M22 END FITT)	TATA spare parts
263243910155	ASSY.NYLON PIPE SET COMPLETE-TML-42WBTC	TATA spare parts
263243910160	ASSY.NY.GAUGE PIPE SET FOR COWL/CAB-VOSS	TATA spare parts
263243910161	REPAIR KIT- TYPE-20/75	TATA spare parts
263243910168	REPAIR KIT-DUAL BREAK VALVE BS1/2/3/4/6	TATA spare parts
263243910169	REPAIR KIT TYPE 24/75 BS1/2/3/4	TATA spare parts
263243910170	REPAIR KIT-PALM COUPLING	TATA spare parts
263243910171	REPAIR KIT-GR HAND BR VALVE	TATA spare parts
263243910172	REPAIR KIT- TYPE-24/24	TATA spare parts
263243910173	REPAIR KIT- TYPE-20/24	TATA spare parts
263243910174	REPAIR KIT-BR CHAMBER TY24	TATA spare parts
263243910176	ASSY.METAL PIPE WITH CRIMPED TEFLON HOSE	TATA spare parts
263243910179	ASSY.METAL PIPE WITH CRIMPED TEFLON HOSE	TATA spare parts
263243910182	ASSY.NYLON PIPE SET COMPTL-TML-42WB-697	TATA spare parts
263243920133	ASSY. METAL PIPE (18OD) COMPR OL WT HOSE	TATA spare parts
263243920134	ASSY.METAL PIPE HOSE TO INT.JOINT(DIA18)	TATA spare parts
263243920135	ASSY. METAL PIPE INT. JOINT (18 O.D.)	TATA spare parts
263243920161	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
263243920162	ASSY.NYLON PIPE SET COMPLETE-TML-42WB697	TATA spare parts
263243920164	ASY CHASSIS SET COMP(PL CON)1613-697-COW	TATA spare parts
263243920173	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
263243920176	ASSY.TEFLON HOSE(18OD)	TATA spare parts
263243920180	ASSY TEFLON HOSE(18 OD)-AIR COMP OUTLET	TATA spare parts
263243920181	ANTI SLAG COILED HOSE BS1/2/3/4/6	TATA spare parts
263243920195	ASSY.METAL PIPE FOR CON PORT OUTLET	TATA spare parts
263243930124	ASSY.NYLON PIPE SET COMPL	TATA spare parts
263243930149	ASSY COMPRESSOR PIPE SECOND	TATA spare parts
263243930150	ASSY. COMPRESSOR PIPE SECOND	TATA spare parts
263243930151	ASSY. COMPRESSOR PIPE THIRD	TATA spare parts
263243930152	ASSY. COMP.PIPE 3RD	TATA spare parts
263243930154	ASSY.COMP.PIPE 2ND	TATA spare parts
263243930155	ASSY.COMP.PIPE 2ND	TATA spare parts
263243930160	ASSY.COMPRESSOR PIPE 2ND(TO DDU)	TATA spare parts
263243930161	ASSY.COMPRESSOR PIPE 3RD(TO DDU)	TATA spare parts
263243930164	ASSY.NYLON PIPE SET COMP-LPT1613 48WB	TATA spare parts
263243930166	ASSY.METAL PIPE COMP. CONTROL PORT	TATA spare parts
263243930167	ASSY.METAL PIPE FOR CONTROL PORT OUTLET.	TATA spare parts
263243930169	SET-NYLON PIPE ASSY CHASSIS	TATA spare parts
263246000101	ASSY DRAG LINK	TATA spare parts
263246000103	DRAG LINK ASSY	TATA spare parts
263246000105	ASSY DRAG LINK	TATA spare parts
263246000108	TELCO OFFER NO ASSY.DRAG LINK.	TATA spare parts

263246000109	DRAG LINK ASSY 1510/1613 MECH STRG	TATA spare parts
263246000110	ASSY DRAG LINK	TATA spare parts
263246000111	SET ASSY VAR. RATIO STG G.B	TATA spare parts
263246100104	ASSY STEERING COLUMN SUPPORT	TATA spare parts
263246100105	ASSY.STEERING COLUMN WITHOUT STG.WHEEL	TATA spare parts
263246100110	ASSY.STEERING COLUMN SUPPORT	TATA spare parts
263246100111	ASSY.STG.GEAR.BOX -V.RATIO	TATA spare parts
263246100117	ASSY VRSTG GB	TATA spare parts
263246100122	BOX SUB ASSY.	TATA spare parts
263246100123	COVER PLATE SUB ASSEMBLY	TATA spare parts
263246106303	RUBBER BELLOWS	TATA spare parts
263246107501	PROTECTIVE COVER	TATA spare parts
263246108202	SPACER PLATE FOR V RATIO G.B. MTG	TATA spare parts
263246108203	CLAMPING RING	TATA spare parts
263246200101	ASSY.VARIABLE RATIO STG.GEAR BOX	TATA spare parts
263246200102	ASSY STRG NUT &. WORM V RATIO TATA	TATA spare parts
263246200104	ASSY.STEERING SPINDLE LPT1613 L=252MM	TATA spare parts
263246200105	ASSY STEERING SPINDLE BS1/2/3/4	TATA spare parts
263246203102	NEEDLE BRG. 50 X 58 X 25	TATA spare parts
263246203103	NEEDLE BRG. 50 X 58 X 25	TATA spare parts
263246203104	ANGULAR.CONTACT BALL BEARING	TATA spare parts
263246203105	ANGULAR.CONTACT BALL BEARING	TATA spare parts
263246203201	ADJUSTING SCREW	TATA spare parts
263246204301	SPRING CLIP-FOR STG. COL. BELLOW	TATA spare parts
263246204302	SPRING CLIP (STG. RUBBER BELLOW)	TATA spare parts
263246204701	SIDE COVER	TATA spare parts
263246204702	COVER BOTTOM	TATA spare parts
263246204703	COVER TOP	TATA spare parts
263246206301	CAM	TATA spare parts
263246206302	RUBBER BELLOW	TATA spare parts
263246206304	RUBBER BELLOW	TATA spare parts
263246207501	RUBBER WASHER	TATA spare parts
263246207702	OIL SEAL	TATA spare parts
263246207902	SECTOR SHAFT	TATA spare parts
263246207905	STEERING SPINDLE TOP LPT1613 COWL	TATA spare parts
263246207906	STEERING SPINDLE TOP SE1613	TATA spare parts
263246207909	STG. SPINDLE BOTTOM LPT1613 L=206 BS1- 4	TATA spare parts
263246208301	SHIM-0.1 MM THICK.	TATA spare parts
263246208302	SHIM-0.15 MM THICK.	TATA spare parts
263246208303	SHIM-0.05 MM THICK.	TATA spare parts
263246208304	SHIM-0.5 MM THICK.	TATA spare parts
263246208305	SHIM- 1 MM THICK.	TATA spare parts
263246208306	SHIM- 1.5 MM THICK.	TATA spare parts
263246208601	SPACER-2.9 MM THICK.	TATA spare parts
263246208602	SPACER-3.1 MM THICK.	TATA spare parts
263246208603	SPACER-3.3 MM THICK.	TATA spare parts
263246208604	SPACER-3.5 MM THICK.	TATA spare parts

263246305101	PITMAN ARM	TATA spare parts
263246305102	PITMAN ARM SE/SK 1613	TATA spare parts
263246305103	PITMAN ARM LPT1613 TILT CAB CD=190MM	TATA spare parts
263246400101	ASSY STEERING WHEEL 550 DIA.	TATA spare parts
263246400102	ASSY STEERING WHEEL 500 DIA	TATA spare parts
263246600107	ASSY DRAG LINK	TATA spare parts
263246600109	ASSY DRAG LINK	TATA spare parts
263246600110	ASSY DRAG LINK	TATA spare parts
263246600111	POWER STG.PUMP	TATA spare parts
263246603101	NEEDLE ROLLER BEARING	TATA spare parts
263246603102	ANGULAR CONTACT BEARING	TATA spare parts
263246603103	NEEDLE ROLLER BEARING	TATA spare parts
263246603201	BOLT	TATA spare parts
263246603202	BOLT	TATA spare parts
263246606501	WORM & NUT ASSEMBLY	TATA spare parts
263246606502	LOCK NUT	TATA spare parts
263246607101	END PLATE	TATA spare parts
263246607801	OIL SEAL	TATA spare parts
263246607802	OIL SEAL	TATA spare parts
263246607803	DUST CAP	TATA spare parts
263246607901	SECTOR SHAFT	TATA spare parts
263246608001	HEX HEAD SCREW	TATA spare parts
263246608301	SHIM-0.075	TATA spare parts
263246608302	SHIM-0.125	TATA spare parts
263246608303	SHIM-0.250	TATA spare parts
263246608304	SHIM (0.036)-GPT FILM	TATA spare parts
263246608601	SPACER	TATA spare parts
263246609201	SPRING WASHER	TATA spare parts
263246609901	OIL FILLER PLUG	TATA spare parts
263246609902	UNIVERSAL JOINT ASSEMBLY	TATA spare parts
263246800110	ASSY.LP HOSE CRIMPED- STG.G.B.TO TANK	TATA spare parts
263246800111	ASSY LP HOSE CRIMPED- STG.TANK TO PUMP	TATA spare parts
263246800116	ASSY.SUCTION PIPE	TATA spare parts
263246800117	ASSY.SUCTION PIPE	TATA spare parts
263246800118	ASSY.RETURN PIPE	TATA spare parts
263246800119	ASSY.RETURN PIPE	TATA spare parts
263246800120	ASSY.PIPELINES CLAMPS & BKTS.	TATA spare parts
263246800121	ASSY.PIPELINES LPT1613/2515CMVR	TATA spare parts
263246800122	ASSY. PIPELINES CLAMPS & BKTS	TATA spare parts
263246800127	ASSY SUCTION LINE	TATA spare parts
263246800128	ASSY PRESSURE LINE	TATA spare parts
263246800129	ASSY RETURN LINE.(P/STG.PUMP END)	TATA spare parts
263246800130	ASSY RETURN LINE.(P/STG.TANK END.)	TATA spare parts
263246800131	ASSY.RETURN PIPE	TATA spare parts
263246800132	ASSY.RETURN PIPE	TATA spare parts
263246900101	DRAG LINK END ASSY	TATA spare parts
263247100102	ASSY. FUEL TANK COMPLETE (160 LIT.)	TATA spare parts

263247100119	ASSY FUEL TANK 350 LTR LPT1613 CMVR2000	TATA spare parts
263247600101	ASSY BRACKET-WATER SEPARATOR MOUNTING	TATA spare parts
263247600103	ASSY SUCTION LINE	TATA spare parts
263247600111	ASSY.SUCTION PIPE (10 OD) 350 LIT.F.TAN	TATA spare parts
263247600112	ASSY.RETURN PIPE (10 OD) 350 LIT F.TANK	TATA spare parts
263247600122	ASSY SUCTION PIPE	TATA spare parts
263247600123	ASSY.SUCTION LINE	TATA spare parts
263247600125	ASSY.BRACKET WATER SEPARATOR MTG.	TATA spare parts
263247600126	ASSY.SUCTION LINE (WATER SEP.TO FIP)	TATA spare parts
263247600127	ASSY. SUCTION LINE	TATA spare parts
263247600128	ASSY. RETURN PIPE (10 OD) 350LIT. F.TAN	TATA spare parts
263247600129	ASSY SUCTION PIPE (FT TO WATER SEPE.)	TATA spare parts
263247600130	ASSY.RETURN LINE	TATA spare parts
263247600152	ASSY SUCTION PIPE	TATA spare parts
263247600154	ASSY NYLON PIPE W/CRIMPED R/HOSE	TATA spare parts
263247600155	ASSY.NYLON PIPE W/CRIMPED R/HOSE	TATA spare parts
263247600156	ASSY.NYLON PIPE W/CRIMPED R/HOSE	TATA spare parts
263247600157	ASSY CRIMPED RUBBER HOSE	TATA spare parts
263247600158	SUCTION PIPE ASSY BABY FILTER TO W/SEP	TATA spare parts
263247600159	ASSY.BRACKET.--WATER SEPARATOR	TATA spare parts
263247607101	SUPPORT BRACKET FOR WATER SEPRATOR	TATA spare parts
263247990101	RETROFIT. KIT FOR FUEL FEED PUMP-LPT1613	TATA spare parts
263247990102	RETROFIT.KIT FOR FUEL FEED PUMP-LPT1613C	TATA spare parts
263249000105	ASSY BRACKET	TATA spare parts
263249100112	ASSY EXHAUST PIPE	TATA spare parts
263249100114	EXHAUST PIPE FRONT LPT1613	TATA spare parts
263249100116	ASSY EX. SEC PIPE	TATA spare parts
263249100119	ASSY.PIPE-651OD X 1.6 THK.	TATA spare parts
263249100121	ASSY MUFFLER	TATA spare parts
263249100122	ASSY.EXHAUST PIPE SE1613CMVR	TATA spare parts
263249100123	EXHAUST PIPE SE1613CMVR	TATA spare parts
263249100133	ASSY.EXHUAUST PIPE -II-FOR TC	TATA spare parts
263249100136	ASSY EXHAUST PIPE SE1613TC 65OD	TATA spare parts
263249100137	ASSY. EXHAUST PIPE 81.2 OD X 1.6 THK	TATA spare parts
263249100138	ASSY.EXHAUST PIPE HOLSET TURBOCHARGER	TATA spare parts
263249100139	ASSY.MUFFLER WITH TAIL PIPE	TATA spare parts
263249100142	ASSY SILENCER WITH TAIL PIPE.	TATA spare parts
263249100144	ASSY.SILENCER WITH TAIL PIPE	TATA spare parts
263249105301	GASKET SE1613	TATA spare parts
263249106903	TAIL PIPE LPT1613CMVR2000	TATA spare parts
263249108208	BRACKET	TATA spare parts
263249200105	INTERMEDIATE EXHAUST PIPE	TATA spare parts
263249200107	ASSY. BRACKET-RHD-EXH. BRK. SUPPORT	TATA spare parts
263249200108	ASSY EXH FIRST PIPE	TATA spare parts
263249200109	ASSY. INTERMEDIATE PIECE	TATA spare parts
263249200120	ASSY. SECOND EXHAUST PIPE.	TATA spare parts
263249200123	ASSY. SECOND PIPE AT SLINCER END	TATA spare parts

263249200124	ASSY. SECOND PIPE AT TURBO-CHARGER	TATA spare parts
263249200125	ASSY FIRST PIPE	TATA spare parts
263249200129	ASSY EXH FIRST PIPE	TATA spare parts
263249200134	ASSY. SILENCER (NT1C)	TATA spare parts
263249206921	TAIL PIPE 81.2 O.D. X 1.6 THK	TATA spare parts
263249208211	BRACKET	TATA spare parts
263249208212	BRACKET	TATA spare parts
263249208213	BRACKET	TATA spare parts
263249208214	BRACKET	TATA spare parts
263249208215	BRACKET AT ENGINE CROSS MEMBER	TATA spare parts
263249208216	BRACKET	TATA spare parts
263249208218	ASSY BRACKET	TATA spare parts
263249208220	BRACKET	TATA spare parts
263249208222	BRACKET	TATA spare parts
263249208223	BRACKET	TATA spare parts
263254108201	BRACKET (BATT.CABLE MTG)	TATA spare parts
263254109912	BATTERY 12V 120AH	TATA spare parts
263254110101	ASSY BATTERY CABLE -VE (350MM LG.)	TATA spare parts
263254110102	ASSY BATT.CABLE -VE (EARTH STRAP)(350LG)	TATA spare parts
263254200102	ASSY OIL PR PIPE-TOP	TATA spare parts
263254200103	ASSY OIL PR PIPE-BOTTOM	TATA spare parts
263254200111	ASSY SOL.VALVE -12V	TATA spare parts
263254200113	INST CLUSTER (0.98) LPT 1613 CNG	TATA spare parts
263254202002	HORN WITH RIS CAPACITOR	TATA spare parts
263254204601	MICRO RELAY 12V NC	TATA spare parts
263254204602	MICRO RELAY 12V,20A,NO W/DIODE (R-ENGG)	TATA spare parts
263254204901	HORN TIMER 12 V	TATA spare parts
263254209901	SPEEDOMETER 6+1-1: 0.88	TATA spare parts
263254209903	TEMPERATURE TRANSDUCER BS1/2/3/4	TATA spare parts
263254209905	3.2 DAI SPEEDOCABLE 2200LG.- OFFER	TATA spare parts
263254209907	SPEEDOMETER (1:1.125) OFFER	TATA spare parts
263254209908	FUEL GAUGE - OFFER	TATA spare parts
263254209908AE	FUEL GAUGE - OFFER	TATA spare parts
263254209909	OIL PRESSURE GAUGE	TATA spare parts
263254209910	ELECTRICAL WATER TEMP. GAUGE - OFFER	TATA spare parts
263254209910AE	ELECTRICAL WATER TEMP. GAUGE - OFFER	TATA spare parts
263254209911	3.2D SPEEDOCABLE 3600 LG.	TATA spare parts
263254209914	3.2D SPEEDOCABLE 4300L(DIN) -OFFER	TATA spare parts
263254209915	AIR PRESSURE GAUGE	TATA spare parts
263254209915AE	AIR PRESSURE GAUGE	TATA spare parts
263254209916	TEMPERATURE TRANSDUCER	TATA spare parts
263254209917	TEMP.TRANSUCER	TATA spare parts
263254209919	RPM METER (12V) BACKLIT	TATA spare parts
263254209920	FUEL GUAGE	TATA spare parts
263254209921	ELECTRICAL WATER TEMP GAUGE	TATA spare parts
263254209922	AIR PRESSURE GAUGE	TATA spare parts
263254209923	RPM METER (12V) BACKLIT	TATA spare parts

263254209924	RPM METER (12V) BACKLIT	TATA spare parts
263254209925	DIGITAL HOUR METER	TATA spare parts
263254209926	DIGITAL HOUR METER	TATA spare parts
263254209927	SPEEDOMETER(1:0.88)(BACKLIT)12V-	TATA spare parts
263254209930	INSTRUMENT CLUSTER-1:0.88	TATA spare parts
263254209935	RPM METER ASSY 12V(420HZ)W/HOUR MTR	TATA spare parts
263254209936	INSTRUMENT CLUSTER(1;0 88)12V	TATA spare parts
263254209937	ERPM W/DGTL H/METER 12V	TATA spare parts
263254209938	INST.CLUSTER(ELECT)(1:0.88)	TATA spare parts
263254209939	INST.CLUSTER(ELECT)(1:0.88)	TATA spare parts
263254209940	ELE. S.M. WI. LCD ODO.M.12V (1:1.04)	TATA spare parts
263254209941	ELE. S.M. WI LCD ODO.M. 24V(1:1.04)	TATA spare parts
263254209942	ELE S M WI LCD ODO M 12V (1:0 88)	TATA spare parts
263254209943	ELET. SPEEDOMETER W/ LCD ODO.M.24V(1:0.8	TATA spare parts
263254209945	WATER IN FUEL SENSOR	TATA spare parts
263254249901	ELECT. TEMP. GAUGE 24V - OFFER	TATA spare parts
263254249902	VOLT METER 24V - OFFER	TATA spare parts
263254249903	FUEL GUAGE-24V	TATA spare parts
263254400101	LAMP ENGINE INSPECTION	TATA spare parts
263254400129	INTERIOR LAMP	TATA spare parts
263254400130	ASSY BLINKER LAMP RH WITH BULB	TATA spare parts
263254400131	ASSY BLINKER LAMP LH WITH BULB	TATA spare parts
263254400142	ASSY HEAD LAMP LH	TATA spare parts
263254400144	ASSY HEAD LAMP RH	TATA spare parts
263254400148	ASSY HEAD LAMP LH	TATA spare parts
263254400149	ASSY HEAD LAMP LH	TATA spare parts
263254400152	ASSY HEAD LAMP RH	TATA spare parts
263254400153	ASSY HEAD LAMP RH	TATA spare parts
263254400156	ASSY HEAD LAMP RH	TATA spare parts
263254400157	ASSY HEAD LAMP LH	TATA spare parts
263254400158	BLINKER LAMP ASSY(LH)W/BULB 12V	TATA spare parts
263254400159	BLINKER LAMP ASSY(RH)W/BULB 12V	TATA spare parts
263254400160	BLINKER LAMP ASSY(LH)W/O BULB	TATA spare parts
263254400161	BLINKER LAMP ASSY(RH)W/O BULB	TATA spare parts
263254400162	BLINKER LAMP ASSY(LH)W/BULB 12V	TATA spare parts
263254400163	BLINKER LAMP ASSY(RH)W/BULB 12V	TATA spare parts
263254400167	KIT BLINKER LAMP LH & RH (12V)	TATA spare parts
263254400169	ASSY.TAIL LAMP BRACKET RH-RHD	TATA spare parts
263254400170	ASSY WARNING LAMP OFFER 12V 7 IND BANK	TATA spare parts
263254400202	LAMP ASSY ENGINE W/SW (BIPOLAR)-24V	TATA spare parts
263254406301	BUTTON (TAIL LAMP BKT.)	TATA spare parts
263254408204	RIM (HEAD LAMP)	TATA spare parts
263254410103	ASSY ENGINE LAMP(12V 21W W/BULB S/W)	TATA spare parts
263254410104	ASSY ENGINE LAMP(12V 21W W/BULB)	TATA spare parts
263254410105	LAMP H/L(-1.8PERC) RHD 12V-RH	TATA spare parts
263254410106	LAMP H/L(-1.8PERC) RHD 12V-LH	TATA spare parts
263254410109	ASSY ENGINE LAMP(12V 21W W/BLB)	TATA spare parts



263254410110	ASSY ENGINE LAMP(12V 21W W/BLB W/SW)	TATA spare parts
263254410111	ASSY ENGINE LAMP (12V 21W W/BLB)	TATA spare parts
263254410112	ASSY ENGINE LAMP(12V 21W W/BLB W/SW)	TATA spare parts
263254410148	ASSY WARNING LAMP	TATA spare parts
263254440101	ASSY HEAD LAMP LH WITH HALOGEN BULB	TATA spare parts
263254440102	ASSY HALO HD.LAMP W/BULB RH LHD 24V	TATA spare parts
263254440103	ASSY HALO HD LAMP W/BULB LH LHD 24V-OFFR	TATA spare parts
263254440104	ASSY HEAD LAMP RH WITH HALOGEN BULB	TATA spare parts
263254440108	BLINKER LAMP 24V LH W/BULB	TATA spare parts
263254440109	BLINKER LAMP 24V RH W/BULB	TATA spare parts
263254487501	BEADING (H/L RIM)	TATA spare parts
263254500101	ASSY MAIN LINE SWITCH	TATA spare parts
263254500102	ASSY COMBI SW W/IND.TRS & HSG.	TATA spare parts
263254500108	ASSY. HAZARD WARNING SWITCH - OFFER	TATA spare parts
263254500111	ASSY.FUSE BOX - OFFER	TATA spare parts
263254500112	ASSY MAIN LINE SWITCH	TATA spare parts
263254500901	STOP LIGHT SWITCH	TATA spare parts
263254504601	ELECTRONIC FLASHER KIT (12V) OFFER	TATA spare parts
263254504601AE	ELECTRONIC FLASHER KIT (12V) OFFER	TATA spare parts
263254504602	FLASHER 12V SE/SK1613 BS2/3/4/6	TATA spare parts
263254506902	PIANO KEY SWITCH	TATA spare parts
263254506903	PIANO KEY SWITCH - OFFER	TATA spare parts
263254509910	STARTER PUSH BUTTON - OFFER	TATA spare parts
263254600105	W/H MAIN (SE1613 CMVR) OFFER	TATA spare parts
263254600107	W/H ENGINE (SE1613 CMVR) OFFER	TATA spare parts
263254600108	W/H GAUGES EARTHING LPT1613 CMVR 2000	TATA spare parts
263254600109	W/H PANEL LAMPS SK 1613CMVR-/32	TATA spare parts
263254600115	W/H MAIN (LPT 1613 CMVR2000) OFFER	TATA spare parts
263254600116	WIRING HARNESS MAIN SE 1613 CMVR	TATA spare parts
263254600118	W/H TAIL (SE1613/42 CMVR) OFFER	TATA spare parts
263254600120	WIRING HARNESS GAUGES EARTHING SE/SK 161	TATA spare parts
263254600123	WIRING HARNESS CONSOLE (LPT 2515 / 1613	TATA spare parts
263254600124	W/H TAIL-LPT1613/42 TILT	TATA spare parts
263254600125	W/H PANEL LAMPS LPT/SE 1613 CMVR2000	TATA spare parts
263254600127	WIRING HARNESS TAIL LPT 1613C 42 WB	TATA spare parts
263254600129	W/H TAIL LPT1613/42	TATA spare parts
263254600130	W/H MAIN-LPT1613 W/INST.CLUST	TATA spare parts
263254600133	W/H TAIL-LPT1613/48	TATA spare parts
263254600135	W/H TAIL-LPT1613/48	TATA spare parts
263254600136	W/H TAIL-SE1613/42	TATA spare parts
263254600139	W/H MAIN-SE1613	TATA spare parts
263254600140	W/H ENGINE-SE1613	TATA spare parts
263254600146	W/H MAIN LPT1613/2515 697 BS-IICOWL	TATA spare parts
263254600147	W/H TAIL-LPT1613/42 697 BS-II	TATA spare parts
263254600148	W/H TAIL LPT1613/48 697 BS-II	TATA spare parts
263254600149	W/H MAIN SE1613 BS-II	TATA spare parts
263254600151	W/H TAIL SE1613/42 BS-II	TATA spare parts

263254600155	W/H MAIN (SE1613 BS-II INST.)	TATA spare parts
263254600159	W/H ENGINE (SE/SK1613 BS-II INST	TATA spare parts
263254600162	WIRING HARNESS FRAME	TATA spare parts
263254601601	W/H MAIN	TATA spare parts
263254608201	PLATE	TATA spare parts
263254620105	WIRING HARNESS TAIL SE1613/42 CMVR2000	TATA spare parts
263254620107	WIRING LOOM	TATA spare parts
263254620114	WIRING HARNESS MAIN CMVR2000	TATA spare parts
263254620119	W/H TAIL-SE1613/42	TATA spare parts
263254620126	W/H MAIN-SE1613 CMVR	TATA spare parts
263254620127	W/H ENGINE-SE1613 CMVR	TATA spare parts
263254620133	W/H MAIN-LPT 1613 CMVR2000	TATA spare parts
263254620134	WIRING HARNESS MAIN SE 1613 CMVR	TATA spare parts
263254620136	W/H TAIL-SE1613/42	TATA spare parts
263254620138	WIRING HARNESS GAUGES EARTHING SE/SK 161	TATA spare parts
263254620139	WIRING HARNESS TAIL LPT 1613C 42 WB	TATA spare parts
263254620140	W/H TAIL-LPT1613/48	TATA spare parts
263254620143	W/H PANEL LAMPS LPT/SE 1613 CMVR2000	TATA spare parts
263254620146	W/H MAIN-LPT1613 W/INST.CLUST.	TATA spare parts
263254620148	W/H MAIN-SE1613	TATA spare parts
263254620149	W/H TAIL-SE1613/42	TATA spare parts
263254620152	W/H ENGINE-SE1613	TATA spare parts
263254620156	W/H MAIN LPT1613/2515 697 BS-IICOWL	TATA spare parts
263254620157	W/H TAIL-LPT1613/42 697 BS-II	TATA spare parts
263254620158	W/H TAIL LPT1613/48 697 BS-II	TATA spare parts
263254620160	W/H ENGINE(LPT1613/2515 697 BS-II TLT)	TATA spare parts
263254620161	W/H TAIL (LPT1613/42 697 BS-II)	TATA spare parts
263254620169	W/H MAIN (SE1613 BS-II INST.)	TATA spare parts
263254620173	W/H ENGINE(SE/SK1613 BS-II INST)	TATA spare parts
263254660101	W/H MAIN-SE1613 CMVR	TATA spare parts
263254660103	W/H ENGINE-SE1613 CMVR	TATA spare parts
263254660108	W/H MAIN-LPT1613 CMVR2000	TATA spare parts
263254660109	WIRING HARNESS MAIN SE 1613 CMVR	TATA spare parts
263254660111	W/H TAIL-SE1613/42 CMVR	TATA spare parts
263254660113	WIRING HARNESS TAIL LPT 1613C 42 WB	TATA spare parts
263254660114	W/H TAIL-LPT1613/48	TATA spare parts
263254660120	W/H TAIL (LPT1613/42)W/TILT CAB	TATA spare parts
263254660123	WIRING HARNESS CONSOLE (LPT 2515 / 1613	TATA spare parts
263254660129	W/H PANEL LAMPS LPT/SE 1613 CMVR2000	TATA spare parts
263254660131	W/H TAIL-LPT1613/42 CMVR	TATA spare parts
263254660132	W/H TAIL-LPT1613/48 CMVR	TATA spare parts
263254660133	W/H MAIN-SE1613	TATA spare parts
263254660134	W/H ENGINE-SE1613	TATA spare parts
263254660135	W/H TAIL-SE1613/42	TATA spare parts
263254660138	W/H MAIN-LPT1613 W/INST.CLUST.	TATA spare parts
263254660140	W/H MAIN LPT1613/2515 697 BS-IICOWL	TATA spare parts
263254660141	W/H TAIL-LPT1613/42 697 BS-II	TATA spare parts

263254660142	W/H TAIL LPT1613/48 697 BS-II	TATA spare parts
263254660145	W/H MAIN LPT1613/2515 697 BS-II LP	TATA spare parts
263254660150	W/H MAIN (SE1613 BS-II INST.)	TATA spare parts
263254680102	W/H TAIL-LPT1613 CMVR /42	TATA spare parts
263254680103	W/H PANEL LAMPS LPT/SE 1613 CMVR2000	TATA spare parts
263254680104	W/H GAUGES EARTHING LPT1613 CMVR 2000	TATA spare parts
263254680105	W/H STOP LIGHT SWITCH & LOW PRESSURE SWI	TATA spare parts
263254680106	W/H MAIN-LPT1613 W/INST.CLUSTER	TATA spare parts
263254680107	W/H TAIL-LPT1613/48	TATA spare parts
263254680121	W/H MAIN LPT1613/2515 697 BS-II LP	TATA spare parts
263254680122	W/H TAIL-LPT1613/42 697 BS-II	TATA spare parts
263254680123	W/H TAIL LPT1613/48 697 BS-II	TATA spare parts
263254680124	W/H MAIN SE1613 BS-II	TATA spare parts
263254680127	W/H TAIL SE1613/42 BS-II	TATA spare parts
263254680134	W/H MAIN (SE1613 BS-II INST.)	TATA spare parts
263254680138	W/H ENGINE(SE/SK1613 BS-II INST)	TATA spare parts
263254820112	ASSY MAIN CABLE SET-LPT S CAM	TATA spare parts
263254820113	ASSY.MAIN CABLE SET (RHD) SE1613	TATA spare parts
263254820114	ASSY.MAIN CABLE SET (RHD) SE1613 53A	TATA spare parts
263254820115	ASSY.CABLE SET(F.TO TAIL)S-CAM SE1613/36	TATA spare parts
263258408201	TR.LABEL C.A.C. (BLUE)(24 HRS)	TATA spare parts
263258408203	STICKER-USER INST.(BRAKE SYSTEM) BS6-PH2	TATA spare parts
263258408204	MANUFACTURER S PLATE(FOR LCV & HCV 2AXLE	TATA spare parts
263258604001	BRACKET JACK MTG BS6	TATA spare parts
263258900102	HYDRAULIC JACK 8T	TATA spare parts
263258900103	HYD JACK 12 TON WITH LOCK NUT	TATA spare parts
263258900105	HYD JACK 12 TON WITH LOCK NUT	TATA spare parts
263258900107	HYDRAULIC JACK ASSY WITH HANDLE BS6	TATA spare parts
263258900108	HYDRAULIC JACK ASSY WITH HANDLE BS6	TATA spare parts
263258900702	SWIVEL SOC 12BI-1/2IN SQ-122.5L / INJECT	TATA spare parts
263258903501	SPANNER FOR HUB END NUT RA-108RR-M	TATA spare parts
263258903502	SPANNER FOR HUB END NUT(RA-108RR)M70X2 5	TATA spare parts
263258904010	VALVE EXTENSION WITH CAP	TATA spare parts
263258904601	PULLER WORM SHAFT BRG OUTER	TATA spare parts
263258904602	PULLER NEEDLE ROLL BRG CAGE/ STRG	TATA spare parts
263258904603	PULLER WORM SHAFT I RACE BRG/ STRG	TATA spare parts
263258904604	DRIFT TATA VAR RATIO STRG GEAR BOX HCV	TATA spare parts
263258904605	DRIFT ISTALL OF OIL SEAL STRG	TATA spare parts
263258905001	TOOL BAG	TATA spare parts
263260000103	ASSY COWL W/FITMENTS 1613 SE CMVR 2000 T	TATA spare parts
263260000104	ASSY COWL BARE 1613 SE CMVR 2000 TURBO	TATA spare parts
263260000108	ASSY COWL COMPLETE RHD 1613 SK	TATA spare parts
263260000109	ASSY.COWL SHELL COMPLT.(PAINTED)-RHD	TATA spare parts
263260000111	ASSY COWL COMPLETE-RHD	TATA spare parts
263260000112	ASSY COWL BARE 1613 SE CMVR	TATA spare parts
263260100101	ASSY TIE MEMBER COMP.TOP(WITH TUB.FRAME)	TATA spare parts
263260100104	ASSY TIE MEMBER COMP.BOTTOM	TATA spare parts

263260100107	ASSY.FRONT TIE MEMBER FRAME COMPLETE	TATA spare parts
263260100108	ASSY BONNET STAY	TATA spare parts
263262608206	SUPPORT CHANNEL 1510CNG	TATA spare parts
263262608207	SUPPORT ANGLE	TATA spare parts
263267102301	WINDSHIELD GLASS LAMINATED SFC	TATA spare parts
263267106301	RUBBER MOULD (WIND SCREEN) SFC	TATA spare parts
263268900101	ASSY.INSTRUMENT PANEL-RHD	TATA spare parts
263268906301	LID CENTRE	TATA spare parts
263281100102	ASSY.TUBULAR FRAME-REAR VIEW MIRROR	TATA spare parts
263281100103	ASSY REAR VIEW MIRROR OUTER WIDE ANG	TATA spare parts
263281100107	ASSY.R.V.M.COMPLETE RH	TATA spare parts
263281100109	ASSY.NUT PLATE (RVM TOP MTG.)	TATA spare parts
263281100110	ASSY.NUT PLATE (RVM BOTTOM MTG.)	TATA spare parts
263281100113	ASSY.TUBULAR FRAME RVM CO-DRIVER SIDE	TATA spare parts
263281100114	ASSY.RVM COMPLETE LH-RHD	TATA spare parts
263281100115	KIT FOR ASSY.RVM COMPL.-SE/SK 1613 COWLS	TATA spare parts
263281100116	OFFER DRG.ASSY.R.V.M.OUTER RH COMPLETE	TATA spare parts
263281200101	ASSY T EMBLEM(OVAL STYLISED) SE/SK	TATA spare parts
263281800101	MASCOT 1613	TATA spare parts
263281800103	ASSY 1613 MASCOT	TATA spare parts
263281900101	ASSY ENGINE SHIELDING LH	TATA spare parts
263281900102	ASSY ENGINE SHIELDING RH	TATA spare parts
263282400104	ASSY.WIPER MOTOR WITH BRACKET(RHD)	TATA spare parts
263282400108	ASSY.WIPER ARM RHD - OFFER	TATA spare parts
263282400109	ASSY. WIPER ARM LHD - OFFER	TATA spare parts
263282409901	WIPER MOTOR W/MSSL TRS.& HSG.	TATA spare parts
263282409902	ASSY WIPER MOTOR 17W-RHD	TATA spare parts
263282409904	WIPER MOTOR 17W	TATA spare parts
263283800101	ASSY.VENTILATION FLAP COMPLETE-LH	TATA spare parts
263283800102	ASSY.VENTILATION FLAP COMPLETE-RH	TATA spare parts
263289100102	ASSY.MOUNTING BRACKET REAR	TATA spare parts
263289100104	ASSY BRACKET (CAB MTG.FRONT)LH	TATA spare parts
263289100105	ASSY BRACKET (CAB MTG.FRONT)RH	TATA spare parts
263289100107	ASSY.BRACKET COMPLT.(COWL MTG.FRT.) LH	TATA spare parts
263289100108	ASSY.BRACKET COMPLT.(COWL MTG.FRT.) RH	TATA spare parts
263289107104	SUPPORT PLATE-FRONT MTG.	TATA spare parts
263291500102	ASSY.SEAT BELT KIT COMPLETE PASSIVE	TATA spare parts
263291500109	ASSY SEAT BELT KIT	TATA spare parts
263330100102	ASSY.THRUST ROD.	TATA spare parts
263615400001	REGULATOR	TATA spare parts
263615400101	BRUSH ASSY	TATA spare parts
263615400102	BRUSH BOX ASSY	TATA spare parts
263615400103	HEAT SINK ASSY +VE	TATA spare parts
263615400104	HEAT SINK ASSY AUX	TATA spare parts
263615400105	HEAT SINK ASSY -VE	TATA spare parts
263615400106	SLIP RING END	TATA spare parts
263615403102	SRE BEARING	TATA spare parts

263615403401	BUSH INSULATION	TATA spare parts
263615404902	INSULATOR	TATA spare parts
263615404904	TERMINAL POSITIVE	TATA spare parts
263615404905	LEAD ASSY POSITIVE	TATA spare parts
263615404909	DIODE AUX	TATA spare parts
263615404910	STATOR ASSY	TATA spare parts
263615404911	ROTOR ASSY	TATA spare parts
263615405301	GASKET	TATA spare parts
263615405901	WOODRUFF KEY	TATA spare parts
263615406504	NUT FOR PULLEY	TATA spare parts
263615407001	PULLEY	TATA spare parts
263615408601	SPACER	TATA spare parts
263615408604	SCREW	TATA spare parts
263615409209	INSULATION WASHER	TATA spare parts
263615409901	MOULDED COVER	TATA spare parts
263615409903	LOCATOR NEGATIVE	TATA spare parts
263615409905	FAN ASSY	TATA spare parts
263615409906	SRE SHIELD	TATA spare parts
263615409907	O' RING	TATA spare parts
263631000102	ASSY FRAME W/STG BKT W/O FRT COUPLING 12	TATA spare parts
263631208201	ASSY. CROSS MEMBER REAR SPRING 5TH	TATA spare parts
263640100101	WHEEL DISC & RIM ASSY	TATA spare parts
263642700101	ASSY. BRACKET RH	TATA spare parts
263643200101	ASSY AIR TANK COMP	TATA spare parts
263654506901	PIANO KEY SWITCH	TATA spare parts
263656300101	ASSY.CENTRE BRG.HSG.COMPL	TATA spare parts
263656304201	U - CLAMP (MECH.WINCH TO CHASSIS FRAME)	TATA spare parts
263656500125	ROLLER MTG BKT ASSY	TATA spare parts
263656500128	ASSY BRKT RR SIDE PULLEY	TATA spare parts
263656500129	ASSY BRACKET TOP (REAR SIDE PULLEY)	TATA spare parts
263656500133	ASSY BRKT ROPE GUIDE COMP	TATA spare parts
263656500134	ASSY BRACKET ROPE GUIDE	TATA spare parts
263656500136	PULLEY	TATA spare parts
263656500141	ASSY CONNECTING BRIDGE (BRKT. REAR TO BR	TATA spare parts
263656506101	LOCK PLATE	TATA spare parts
263656506102	LOCK PLATE	TATA spare parts
263656506702	PIN	TATA spare parts
263656506703	PIVOT PIN	TATA spare parts
263657104203	COATED CLAMP (DIA-25)	TATA spare parts
263683106305	BLOWER CASING.	TATA spare parts
263683106306	DUCT SUCTION SIDE.	TATA spare parts
263683500101	ASSY.BKT.FOR VALVE MTG.	TATA spare parts
263683503303	CLAMP	TATA spare parts
263683506301	SHROUD SUCTION SIDE.	TATA spare parts
263683508201	NOZZLE HOLDER.	TATA spare parts
263688500103	BUMPER ASSY STRAIGHT	TATA spare parts
263688500103B3	BUMPER PAINTED ARMY COLOUR	TATA spare parts

263731000106	ASSY FRAME SA/42 RTH. WTE RHD	TATA spare parts
263815404903	LEAD ASSY POSITIVE	TATA spare parts
263815409210	INSULATION WASHER	TATA spare parts
264015400105	ALTERNATOR 12V 35A	TATA spare parts
264015400106	ALTERNATOR 14V 65 AMP	TATA spare parts
264015400107	ALTERNATOR 14V 65AMP BS1/2/3/4	TATA spare parts
264015400108	ALTERNATOR 12V 65A 1GR PULLY	TATA spare parts
264015404916	RECTIFIER	TATA spare parts
264015404917	REGULATOR ALTERNATOR	TATA spare parts
264015407002	PULLEY	TATA spare parts
264015409921	DRIVE END SHIELD	TATA spare parts
264015409922	SLIP RING END SHIELD	TATA spare parts
264024100101	BKT ENG MTG RH FRT	TATA spare parts
264024100102	BKT ENG MTG LH FRT	TATA spare parts
264024200110	ENGINE MTG PAD REAR	TATA spare parts
264025200101	CLUTCH DISC 280 DIA	TATA spare parts
264025200102	CLUTCH DISC 280 DIA	TATA spare parts
264025200103	ASSY.CLUTCH DISC 280 DIA	TATA spare parts
264025200104	CLUTCH DISC 280 DIA	TATA spare parts
264025200105	CLUTCH DISC 280 DIA	TATA spare parts
264025200106	REP KIT 280DIA CL DISC	TATA spare parts
264025200107	CLUTCH DISC 280 DIA	TATA spare parts
264025200108	280 DIA.CLUTCH DISC ASSY.(WAF405)-CEEKAY	TATA spare parts
264025206302	CLUTCH LINING 4.6MM	TATA spare parts
264025206303	CLUTCH LINING 3.4MM	TATA spare parts
264025400101	CL PR PLATE 280 DIA	TATA spare parts
264025400102	ASSY. CLUTCH PR PLATE 280 DIA. BS2/3/4	TATA spare parts
264025400104	REP KIT CL PR PLATE MJR	TATA spare parts
264025600102	CL REL BRG W/SLEEVE	TATA spare parts
264025600103	CL REL FORK W/BALL PIN	TATA spare parts
264025603101	CLUTCH RELEASE BRG	TATA spare parts
264029100112	HOSE BRAKE 3.2D	TATA spare parts
264029100126	HOSE ASSY	TATA spare parts
264029300102	BRACKET	TATA spare parts
264029300104	THRUST ROD	TATA spare parts
264029300106	THRUST ROD	TATA spare parts
264030100104	PULL ROD	TATA spare parts
264031000108	FRAME ASSY 41 WB BUS	TATA spare parts
264031000110	ASSY.FRAME 3700 WB BUS WITH 1800 ROH.	TATA spare parts
264031000115	FRAME ASSY 37 WB TRUCK	TATA spare parts
264031000129	ASSY.FRAME	TATA spare parts
264031200102	CROSS MEMBER RR S/ABS	TATA spare parts
264031200110	CROSS MEMBER FRT W/T HOOK	TATA spare parts
264031200113	ENGINE CROSS MEMBER RR	TATA spare parts
264031203301	BKT ENG MTG REAR	TATA spare parts
264031208201	REINFORCEMENT RH	TATA spare parts
264031208205	GUSSET TOP RH 608/609	TATA spare parts

264031208206	CROSS MEMBER	TATA spare parts
264031208213	PACKING PLATE 3.15MM	TATA spare parts
264031208297	REINFORCEMENT LH	TATA spare parts
264031208298	REINFORCMENT RH	TATA spare parts
264031208602	SPECIAL WASHER	TATA spare parts
264031218201	GUSSET TOP RH	TATA spare parts
264031218202	GUSSET TOP LH	TATA spare parts
264031400104	CLEAT ASSY	TATA spare parts
264031400105	RUB BUFFER RR AXLE	TATA spare parts
264031400106	RUB BUFFER RR AXLE 41WB	TATA spare parts
264031400107	RUB BUFFER RA STOPPER	TATA spare parts
264031400108	CLEAT ASSY 4/5TH	TATA spare parts
264032100101	BRACKET SPRING FRT	TATA spare parts
264032100104	SHACKLE FRT SPRING W/BUSH	TATA spare parts
264032100105	SHACKLE FRT SPRING W/BUSH	TATA spare parts
264032100113	LEAF SPRING 1ST W/BUSH	TATA spare parts
264032100114	FRONT SPRING ASSY TRUCK	TATA spare parts
264032100117	FRONT SPRING ASSY BUS	TATA spare parts
264032104207	SPRING CLIP	TATA spare parts
264032104208	SPRING CLIP	TATA spare parts
264032104209	LOCK PLATE	TATA spare parts
264032106701	SPRING PIN	TATA spare parts
264032107134	LEAF SPRING 2ND FRT	TATA spare parts
264032107144	LEAF SPRING 3RD FRT	TATA spare parts
264032107145	LEAF SPRING 4TH FRT	TATA spare parts
264032107146	LEAF SPRING 5TH FRT	TATA spare parts
264032107147	LEAF SPRING 6TH FRT	TATA spare parts
264032107148	LEAF SPRING 7TH FRT	TATA spare parts
264032107149	LEAF SPRING 8TH FRT	TATA spare parts
264032107150	LEAF SPRING 9TH FRT	TATA spare parts
264032107151	LEAF SPRING 10TH FRT	TATA spare parts
264032107152	LEAF SPRING 11TH FRT	TATA spare parts
264032107153	LEAF SPRING 12TH FRT	TATA spare parts
264032108201	LOCKING PLATE	TATA spare parts
264032108202	LOCKING PLATE 709	TATA spare parts
264032203703	GUIDE PLATE	TATA spare parts
264032204206	U CLAMP(FRONT SPRING)	TATA spare parts
264032207701	RUBBER BUFFER	TATA spare parts
264032207702	RUBBER BUFFER	TATA spare parts
264032300103	SHOCK ABSORBER FRONT	TATA spare parts
264032300104	SHOCK ABSORBER FRONT	TATA spare parts
264032300113	BKT S/ABS & CAB FRT LH	TATA spare parts
264032300114	BKT S/ABS & CAB FRT RH	TATA spare parts
264032300118	SHOCK ABSORBER FRONT	TATA spare parts
264032300119	SHOCK ABSORBER FRONT	TATA spare parts
264032300120	SHOCK ABSORBER FRONT	TATA spare parts
264032305103	BKT S/ABS BOTTOM FRT	TATA spare parts

264032400104	SEALING RING	TATA spare parts
264032400105	SHACKLE REAR W/BUSH	TATA spare parts
264032400106	SHACKLE REAR W/BUSH	TATA spare parts
264032400108	LEAF SPRING 1ST W/BUSH RR	TATA spare parts
264032400109	REAR SPRING ASSY 2 STAGE	TATA spare parts
264032400115	LEAF SPRING 1ST W/BUSH RR	TATA spare parts
264032400118	REAR SPRING ASSY.	TATA spare parts
264032400143	ASSY. SPRING	TATA spare parts
264032403401	BUSH	TATA spare parts
26403240340120	SPRING BUSH (SEMIFINISH)	TATA spare parts
264032403701	BKT SPRING HANGER RR	TATA spare parts
264032403705	SUPPORT PLATE AUX SPRING	TATA spare parts
264032404203	SPRING CLIP	TATA spare parts
264032404205	SPRING CLIP	TATA spare parts
264032404210	SPRING CLIP	TATA spare parts
264032405301	SPACER	TATA spare parts
264032406702	SPRING PIN SHACKLE RR	TATA spare parts
264032407112	LEAF SPRING 2ND RR	TATA spare parts
264032407113	LEAF SPRING 4TH RR	TATA spare parts
264032407114	LEAF SPRING 5TH RR	TATA spare parts
264032407115	LEAF SPRING 6TH RR	TATA spare parts
264032407116	LEAF SPRING 7TH RR	TATA spare parts
264032407119	LEAF SPRING 3RD RR	TATA spare parts
264032407120	LEAF SPRING 8TH RR	TATA spare parts
264032407121	LEAF SPRING 9TH RR	TATA spare parts
264032407142	LEAF SPRING 2ND	TATA spare parts
264032407143	LEAF SPRING 3RD	TATA spare parts
264032407144	LEAF SPRING 4TH	TATA spare parts
264032407145	LEAF SPRING 5TH	TATA spare parts
264032407146	LEAF SPRING 6TH	TATA spare parts
264032407147	LEAF SPRING 7TH	TATA spare parts
264032407148	LEAF SPRING 8TH	TATA spare parts
264032407149	LEAF SPRING 1ST	TATA spare parts
264032407150	LEAF SPRING 2ND	TATA spare parts
264032407151	LEAF SPRING 3RD	TATA spare parts
264032407152	LEAF SPRING 4TH	TATA spare parts
264032407153	LEAF SPRING 5TH	TATA spare parts
264032408601	SPACER	TATA spare parts
264032503703	SHACKLE (REAR SPRING)	TATA spare parts
264032503705	GUIDE PLATE RR SPRING	TATA spare parts
264032504203	U CLAMP REAR	TATA spare parts
264032504204	U CLAMP REAR	TATA spare parts
264032504206	U CLAMP REAR	TATA spare parts
264032504207	U CLAMP	TATA spare parts
264032600117	ASSY. REAR SHOCK ABSORBER BS2/3	TATA spare parts
264032600119	SHOCK ABSORBER REAR	TATA spare parts
264032600120	ASSY.REAR SHOCK ABSORBER	TATA spare parts



264032600121	SHOCK ABSORBER REAR	TATA spare parts
264032800102	CONNECTING ROD	TATA spare parts
264032800104	CLAMP PLATE	TATA spare parts
264032800105	ANTI ROLL BAR	TATA spare parts
264032803801	CLAMP SUPPORT	TATA spare parts
264032804202	U CLAMP ARB	TATA spare parts
264032807103	CLAMP PLATE	TATA spare parts
264032807701	BEARING BLOCK	TATA spare parts
264032900105	ANTI ROLL BAR REAR	TATA spare parts
264032903301	BRACKET RH	TATA spare parts
264032903302	BRACKET LH	TATA spare parts
264032906702	PIN MOUNTING	TATA spare parts
264032908401	SLEEVE RR ANTI ROLL BAR	TATA spare parts
264033000102	FRONT AXLE ASSY RHD	TATA spare parts
264033000103	FRONT AXLE ASSY LHD	TATA spare parts
264033105107	FRONT AXLE BEAM STD	TATA spare parts
264033105112	FRONT AXLE BEAM STD	TATA spare parts
264033200110	STUB AXLE STD	TATA spare parts
264033200115	TIE ROD.	TATA spare parts
264033200116	TIE ROD ASSY	TATA spare parts
264033200117	KIT-KING PIN STD	TATA spare parts
264033200118	REP KIT KING PIN STD1	TATA spare parts
264033200119	REP KIT KING PIN RS1	TATA spare parts
264033200120	REP KIT KING PIN RS2	TATA spare parts
264033200121	TIE ROD END LH	TATA spare parts
264033200122	TIE ROD END RH	TATA spare parts
264033200124	STUB AXLE ASSY.FRT.	TATA spare parts
264033200128	TIE ROD ASSY.	TATA spare parts
264033200129	TIE ROD ASSY.	TATA spare parts
264033203402	BUSH KING PIN	TATA spare parts
264033203402DF	BUSH - KING PIN - 407/709/909/712/912	TATA spare parts
264033206707	KING PIN STD	TATA spare parts
264033206708	KING PIN NORMAL-I	TATA spare parts
264033206709	KING PIN RS1	TATA spare parts
264033206710	KING PIN RS2	TATA spare parts
264033206711	COTTER PIN	TATA spare parts
264033208302	SHIM 0.8 MM	TATA spare parts
264033208303	SHIM 0.85 MM THICK	TATA spare parts
264033208304	SHIM 0.9 MM THICK	TATA spare parts
264033208305	SHIM 0.95 MM THICK	TATA spare parts
264033208306	SHIM 1.0 MM THICK	TATA spare parts
264033208307	SHIM 1.05 MM THICK	TATA spare parts
264033208308	SHIM 1.10 MM THICK	TATA spare parts
264033208309	SHIM 1.15 MM THICK	TATA spare parts
264033208310	SHIM 1.20 MM THICK	TATA spare parts
264033208311	SHIM 1.25 MM THICK	TATA spare parts
264033208312	SHIM 1.30 MM THICK	TATA spare parts

264033208313	SHIM BS6	TATA spare parts
264033208314	SHIM BS6	TATA spare parts
264033208315	SHIM 1.45 MM THICK	TATA spare parts
264033208316	SHIM 1.50 MM THICK	TATA spare parts
264033208317	SHIM 1.55 MM THICK	TATA spare parts
264033208318	SHIM 1.60 MM THICK	TATA spare parts
264033208319	SHIM 1.65 MM THICK	TATA spare parts
264033208320	SHIM 1.70 MM THICK	TATA spare parts
264033403108	THRUST BRG STD	TATA spare parts
264033403109	THRUST BRG R/S1	TATA spare parts
264033403113	TAPER ROLLER BEARING	TATA spare parts
264033403116	THRUST BRG STD1 TEXPIN	TATA spare parts
264033403705	BRAKE DRUM FRT	TATA spare parts
264033405302	GASKET	TATA spare parts
264033407801	OIL SEAL FRT HUB 407/608	TATA spare parts
264033407802	OIL SEAL HUB	TATA spare parts
264033407803	OIL SEAL	TATA spare parts
264033408201	DUST COVER	TATA spare parts
264033408202	BAFFLE	TATA spare parts
264033408206	HUB COVER FR HUB	TATA spare parts
264033408601	SEAL RACE	TATA spare parts
264033805103	TIE ROD ARM LH	TATA spare parts
264033805105	STEERING ARM LHD	TATA spare parts
264033805108	STEERING ARM RH	TATA spare parts
264040100101	ASSY. WHEEL NUT BS1/2/3/4	TATA spare parts
264040100102	ASSY. WHEEL DISC & RIM 6.0 G X16 BS1/2/3	TATA spare parts
264040100105	WHEEL DISC & RIM 6.00X16	TATA spare parts
264040100116	WHEEL DISC & RIM 608	TATA spare parts
264040100120	WHEEL DISC & RIM 5.5FX16	TATA spare parts
264040100126	ASSY WHEEL RIM	TATA spare parts
264040100127	ASSY WHEEL RIM 6.00X16	TATA spare parts
264040100129	WHEEL RIM ASSY	TATA spare parts
264040106702	WHEEL MTG BOLT RR	TATA spare parts
264040106703	WHEEL MTG BOLT FR	TATA spare parts
264040109916	SIDE RING	TATA spare parts
264040300105	ASSYHANDLE BS6	TATA spare parts
264040300106	SPARE WHEEL CARRIER	TATA spare parts
264040303305	HOLDING BRACKET	TATA spare parts
264040308212	REINFORCEMENT	TATA spare parts
264041100105	COUPLING FLANGE	TATA spare parts
264041100109	PROP SHAFT FRT W/CB 37WB	TATA spare parts
264041108201	DUST COVER	TATA spare parts
264041110107	PROP SHAFT FR 70X3X479	TATA spare parts
264041110110	PROP SHAFT FRT 608/41	TATA spare parts
264041120107	PROP SHAFT RR 70X3X726	TATA spare parts
264041120109	PROP SHAFT RR 70X3X1069	TATA spare parts
264041120111	PROP SHAFT RR 70X3X813	TATA spare parts

264041120113	PROP SHAFT RR 70X3X1227	TATA spare parts
264041300101	BKT CENTRE BEARING	TATA spare parts
264041300107	ASSY BRKT CENTRE BRG	TATA spare parts
264041308201	SPACER PLATE	TATA spare parts
264042100102	FRT AXLE BRAKE RH	TATA spare parts
264042100114	WHEEL CYL 22.22D	TATA spare parts
264042103201	PIN	TATA spare parts
264042103204	COLLARED PIN	TATA spare parts
264042106701	PIN	TATA spare parts
264042108201	OIL BAFFLE	TATA spare parts
264042108701	SPRING (SHOE RETURN -TOP)	TATA spare parts
264042108702	SPRING-SHOE RETURN CENTRE	TATA spare parts
264042108704	SPRING	TATA spare parts
264042108705	RETURN SPRING (CENTRE)	TATA spare parts
264042110103	ANCHOR PLATE RH FRONT	TATA spare parts
264042110104	ANCHOR PLATE LH FRONT	TATA spare parts
264042120101	ASSY. WHEEL CYLINDER 23.81 DIA BS2/3/4	TATA spare parts
264042120102	WHEEL CYL.23.81D RR	TATA spare parts
264042120103	REP KIT WHEEL CYL MNR	TATA spare parts
264042120104	REP KIT WHEEL CYL MJR	TATA spare parts
264042120105	WHEEL CYLINDER 22.22 DIA. BS2/3/4	TATA spare parts
264042120106	WHEEL CYL.22.22D FRT	TATA spare parts
264042120107	MAJOR REPAIR KIT OF 22.22 DIA.W/CYL.	TATA spare parts
264042120108	REP KIT WHEEL CYL MNR	TATA spare parts
264042120109	ASSEMBLY WHEEL CYLINDER 22.22 DIA.	TATA spare parts
264042126601	PLUNGER W CASSLY	TATA spare parts
264042130110	BR SHOE W/LIN RS2 SEC	TATA spare parts
264042130112	BR SHOE W/LIN RS1 PRI	TATA spare parts
264042130113	BR SHOE W/LIN RS2 PRI	TATA spare parts
264042130114	BR SHOE W/LIN STD PRI	TATA spare parts
264042130115	BR SHOE W/LNG PR NABS13.8	TATA spare parts
264042130116	BR SHOE W/LIN STD SEC	TATA spare parts
264042136302	BRAKE LINING STD SEC	TATA spare parts
264042136303	BRAKE LINING RS1 SEC	TATA spare parts
264042136304	BRAKE LINING RS2 SEC	TATA spare parts
264042136306	BRAKE LINING STD PRI	TATA spare parts
26404213630602DF	BRAKE LINING KIT STD - 407 BS1/2 (SET OF	TATA spare parts
264042136307	BRAKE LINING RS1 PRI	TATA spare parts
26404213630703DF	BRAKE LINING KIT OS1 - 407 BS1/2 (SET OF	TATA spare parts
264042136308	BRAKE LINING RS2 PRI	TATA spare parts
26404213630804DF	BRAKE LINING KIT OS2 - 407 BS1/2 (SET OF	TATA spare parts
264042136311	BRAKE LINING RS1 PRI	TATA spare parts
264042136312	BR LNG 13.8 MM PRIM DRG	TATA spare parts
264042136315	BRAKE LINING RS1 SEC	TATA spare parts
264042136316	BRAKE LINING RS2 SEC	TATA spare parts
264042136317	BRAKE LINING RS1 PRI	TATA spare parts
264042136318	BRAKE LINING RS2 PRI	TATA spare parts

264042136319	BRAKE LINING RS1 SEC	TATA spare parts
264042136323	BRAKE LINING STD PRI NASB	TATA spare parts
264042136325	BRAKE LINING STD SEC NASB	TATA spare parts
264042136327	BRAKE LINING RS1 PRI NASB	TATA spare parts
264042136328	BR LINING NABS 13.8 PRIM	TATA spare parts
264042136329	BRAKE LINING RS1 SEC NASB	TATA spare parts
264042136330	BR LINING NABS 13.8 SECO	TATA spare parts
264042136331	BR LINING NABS 12.8 PRIM	TATA spare parts
264042136335	PRIMARY BRAKE LINING ASB SA63SM NORMAL	TATA spare parts
264042136336	SECONDARY BRAKE LINING AS-SA63SM NORMAL	TATA spare parts
264042136341	PRIMARY BRAKE LINING ASB SA63SM NORMAL	TATA spare parts
264042136342	PRIMARY BRAKE LINING ASB SA63SM REPAIR-I	TATA spare parts
264042136343	PRIMARY BRK LINING ASB SA63SM REPAIR-II	TATA spare parts
264042136344	SECONDARY BR LINING AS-AFS2 NORMAL	TATA spare parts
264042136345	SECONDARY BR LINING AS-SA63SM REPAIR-I	TATA spare parts
264042136346	SECONDARY BR LINING AS-SA63SM REPAIR-II	TATA spare parts
264042300105	THRUST ROD LH	TATA spare parts
264042300106	THRUST ROD RH	TATA spare parts
264042300119	ASSY. WHEEL CYLINDER 23.81 DIA.	TATA spare parts
264042306001	BRAKE LEVER RH	TATA spare parts
264042306002	BRAKE LEVER LH	TATA spare parts
264042307401	RIVET	TATA spare parts
264042308701	THRUST SPRING	TATA spare parts
264042700101	LINK ASSY	TATA spare parts
264042700112	HAND BRAKE LEVER	TATA spare parts
264042700113	RATCHET ASSY	TATA spare parts
264042700115	HAND BRAKE LEVER	TATA spare parts
264042700116	COVER HAND BRAKE LEVER	TATA spare parts
264042700118	ASSY PIPE 12 O.D.X1100 LG	TATA spare parts
264042700120	HAND BR CABLE RR 37WB	TATA spare parts
264042700122	HAND BR CABLE FRT 34/37	TATA spare parts
264042700143	HAND BR CABLE RR	TATA spare parts
264042700144	ASSY CABLE REAR- OFFER DRG	TATA spare parts
264042700145	ASSY. CABLE FRONT FOR 4150 W.B.	TATA spare parts
264042700146	DRG H/BR CABLE FRT 37 WB	TATA spare parts
264042700149	HAND BR CABLE FRT/37 3000	TATA spare parts
264042700150	HAND BR CABLE FRT/4150	TATA spare parts
264042700155	ASSY.CABLE REAR-OFFER DRG.	TATA spare parts
264042700159	HAND BR CABLE RR/37 BUS	TATA spare parts
264042700167	HAND BRAKE LEVER	TATA spare parts
264042700174	BRACKET-PARKING BRAKE	TATA spare parts
264042700179	HAND BR CABLE RR 608	TATA spare parts
264042700181	PARKING BRAKE CABLE REAR	TATA spare parts
264042703305	BRACKET	TATA spare parts
264042800109	BANJO BODY	TATA spare parts
264042800111	TUBE ASSY	TATA spare parts
264042800112	TUBE ASSY	TATA spare parts

264042800114	TUBE ASSY	TATA spare parts
264042800115	TUBE ASSY	TATA spare parts
264042800117	TUBE ASSY	TATA spare parts
264042800118	TUBE ASSY	TATA spare parts
264042800119	TUBE ASSY	TATA spare parts
264042800120	BRACKET ASSY	TATA spare parts
264042800121	HOSE M/CYL TO S/CYL 10MM	TATA spare parts
264042800122	TUBE ASSY	TATA spare parts
264042800124	TUBE ASSY	TATA spare parts
264042800126	TUBE ASSY	TATA spare parts
264042800131	TUBE ASSY	TATA spare parts
264042800136	HOSE ASSY	TATA spare parts
264042800161	ASSY TUBE	TATA spare parts
264042803303	BRACKET FRONT BRAKE HOSE	TATA spare parts
264042803307	BRACKET (FRONT BRAKE HOSE )	TATA spare parts
264042804201	CLAMP	TATA spare parts
264042806801	ADAPTER	TATA spare parts
264042806802	ADAPTER	TATA spare parts
264042900150	ASSY PIPE 12 O.D.	TATA spare parts
264042900152	ASSY PIPE 12 OD X 1330 LG	TATA spare parts
264043100101	TANDEM MASTER CYL 23.81D	TATA spare parts
264043100102	TANDEM MASTER CYL	TATA spare parts
264043100103	TANDEM MASTER CYL 23.81D	TATA spare parts
264043100105	KIT REP MAJOR TMC	TATA spare parts
264043100106	KIT REP MINOR TMC 23.81D	TATA spare parts
264043100110	BRAKE FLUID CONTAINER	TATA spare parts
264043100111	KIT REP SEALS T M CYL	TATA spare parts
264043100121	TANDEM MASTER CYL	TATA spare parts
264043500102	VACUUM BRAKE CYLINDER.	TATA spare parts
264043500105	VACCUM BOOSTER	TATA spare parts
264043500108	KIT REP VACCUM CYL	TATA spare parts
264043500110	VACUUM BRAKE CYLINDER.	TATA spare parts
264043505801	HOSE	TATA spare parts
264043505802	HOSE	TATA spare parts
264043507702	DIAPHRAGM	TATA spare parts
264043700101	ASSY.EXHAUST BRAKE VALVE	TATA spare parts
264043700102	VACUUM EXHAUST BRAKE VALVE	TATA spare parts
264043700103	KIT REP EXH BRAKE VALVE	TATA spare parts
264043700106	VACUUM EXHAUST BRAKE VALVE	TATA spare parts
264043700107	EXHAUST BRAKE VALVE	TATA spare parts
264043700108	VACUUM EXHAUST BRAKE VALVE	TATA spare parts
264043700109	ASSY.LEVER TYPE CONTROL VALVE	TATA spare parts
264043700111	EXH.BRAKE ISOLATOR VALVE ASSY	TATA spare parts
264043700112	EXH.BRAKE ISOLATOR VALVE ASSY	TATA spare parts
264043708001	SPECIAL SCREW	TATA spare parts
264046000111	ASSY. POWER STEERING GEAR BOX BS2/3/4	TATA spare parts
264046000113	STRG GEAR BOX POWER LHD	TATA spare parts

264046003701	BKT STRG G/BOX MTG	TATA spare parts
264046200104	STEERING NUT & WORM	TATA spare parts
264046200105	STRG GEAR BOX RHD	TATA spare parts
264046200106	STRG GEAR BOX POWER LHD	TATA spare parts
264046200107	STEERING NUT & WORM LHD	TATA spare parts
264046200119	STRG SPINDLE TOP SFC609	TATA spare parts
264046200126	KIT SEAL P/STRG G/BOX BS2/3/4	TATA spare parts
264046200131	STRG SPINDLE MIDDLE	TATA spare parts
264046200134	ASSY SPINDLE	TATA spare parts
264046203101	BEARING SRDG BALL	TATA spare parts
264046203102	BEARING BALL	TATA spare parts
264046203103	BEARING SRDG BALL	TATA spare parts
264046203105	BEARING BALL	TATA spare parts
264046203108	BALL BEARING	TATA spare parts
264046203804	STRG COLUMN	TATA spare parts
264046204308	SNAP RING	TATA spare parts
264046204309	RETAINING RING	TATA spare parts
264046205901	WOODRUFF KEY	TATA spare parts
264046206311	V RING	TATA spare parts
264046206502	NUT SPECIAL	TATA spare parts
264046206503	HEX NUT-POWER STEERING	TATA spare parts
264046206701	HEX BOLT	TATA spare parts
264046206903	NEEDLE SLEEVE	TATA spare parts
264046207702	RUBBER SUPPORT	TATA spare parts
264046207704	O RING	TATA spare parts
264046207903	STRG SPINDLE BOTTOM	TATA spare parts
264046207909	SLEEVE STRG COLUMN	TATA spare parts
264046207912	STRG SPINDLE BOTTOM	TATA spare parts
264046207916	STRG.SPINDLE-TOP	TATA spare parts
264046207923	STEERING SPINDLE MIDDLE	TATA spare parts
264046209203	TAB WASHER-POWER STEERING	TATA spare parts
264046306003	PITMAN ARM	TATA spare parts
264046306004	PITMAN ARM	TATA spare parts
264046306006	PITMAN ARM LHD	TATA spare parts
264046600107	DRAG LINK ASSY RHD	TATA spare parts
264046600111	DRAG LINK ASSY LHD	TATA spare parts
264046600112	BALL JOINT DRAG LINK	TATA spare parts
264046600113	BALL JOINT DRAG LINK RH	TATA spare parts
264046600114	BALL JOINT DRAG LINK LH	TATA spare parts
264046600120	ASSY DRAG LINK-LHD	TATA spare parts
264046600121	ASSY.DRAG LINK-RHD	TATA spare parts
264046600122	ASSY DRAG LINK	TATA spare parts
264046600123	UNIVERSAL JOINT ASSY	TATA spare parts
264046600124	DRAG LINK	TATA spare parts
264046600126	DRAG LINK ASSY RHD	TATA spare parts
264046600128	DRAG LINK ASSY LHD	TATA spare parts
264046600129	HOUSING ASSY	TATA spare parts

264046607702	RUBBER BOOT	TATA spare parts
264046800101	TUBE HOSE TO ELBOW	TATA spare parts
264046800104	TUBE TANK TO UNION	TATA spare parts
264046800108	STRG MTG BRACKET	TATA spare parts
264046800112	TUBE ST GR BOX TO UNION L	TATA spare parts
264047000106	FUEL TANK	TATA spare parts
264047100104	ASSY FUEL TANK	TATA spare parts
264047100106	FUEL TANK 90 LTR	TATA spare parts
264047500104	BRACKET FUEL TANK MTG	TATA spare parts
264047600101	FUEL SUCTION LINE	TATA spare parts
264047600102	FUEL RETURN LINE	TATA spare parts
264047600103	FUEL SUCTION LINE	TATA spare parts
264049200106	EXHAUST PIPE FRONT	TATA spare parts
264049200109	SHAFT THROTTLE VALVE	TATA spare parts
264049200110	VACUUM CYLINDER ASSY	TATA spare parts
264049200112	EXHAUST BRAKE UNIT	TATA spare parts
264049200113	HEAT SHIELD	TATA spare parts
264049200116	INTERMEDIATE FLANGE	TATA spare parts
264049200130	EXHAUST PIPE FR INTER	TATA spare parts
264049200146	EXH INTER PIPE FRONT LHD	TATA spare parts
264049200157	EXHAUST PIPE FRONT	TATA spare parts
264049203303	BRACKET	TATA spare parts
264049203304	BRACKET	TATA spare parts
264049203701	INTERMEDIATE FLANGE	TATA spare parts
264049206924	EXHAUST PIPE	TATA spare parts
264049208213	BRACKET	TATA spare parts
264049208228	BRACKET	TATA spare parts
264049208231	BRACKET	TATA spare parts
264054100105	BATTERY CABLE +VE	TATA spare parts
264054100114	BATTERY ACID TRAY	TATA spare parts
264054100115	ASSY CU BATTERY CABLE [ - VE]	TATA spare parts
264054100118	BATTERY CABLE -VE RHD	TATA spare parts
264054103202	STUD	TATA spare parts
264054103203	STUD	TATA spare parts
264054106301	BATTERY TRAY	TATA spare parts
264054106303	BATTERY TRAY(PLASTIC)	TATA spare parts
264054107501	GROMMET 1/LP	TATA spare parts
264054107502	GROMMET	TATA spare parts
264054108207	CHANNEL BATTERY COVER	TATA spare parts
264054109901	COVER BATTERY	TATA spare parts
264054200102	ASSY.BRACKET.	TATA spare parts
264054209901	SPEEDOMETER 1:0.84	TATA spare parts
264054209902	SPEEDOMETER 1:0.84	TATA spare parts
264054209903	SPEEDOMETER-1:0.84	TATA spare parts
264054209905	SPEEDOMETER 1:0.935	TATA spare parts
264054209906	SPEEDOMETER 1:0.935	TATA spare parts
264054209908	SPEEDOCABLE 2300MM	TATA spare parts

264054209909	SPEEDO CABLE 2300MM	TATA spare parts
264054209913	TEMP. GAUGE	TATA spare parts
264054209942	SPEEDOCABLE 2200MM JIS	TATA spare parts
264054209944	SPEEDOCABLE 2200MM JIS	TATA spare parts
264054400109	TOP MARKER LAMP	TATA spare parts
264054400110	TOP MARKER LAMP	TATA spare parts
264054400111	KIT ASSY TOP MARKER LAMP	TATA spare parts
264054400112	KIT TOP MARKER LAMP	TATA spare parts
264054400113	KIT ASSY TOP MARKER LAMP	TATA spare parts
264054400115	KIT ASSY TOP MARKER LAMP	TATA spare parts
264054500101	ASSY MAIN LINE SWITCH PEC	TATA spare parts
264054500103	FUSE BOX ASSY. 12 POLE	TATA spare parts
264054500105	COMBI SWITCH LHD	TATA spare parts
264054500107	FUSE BOX ASSY. 12 POLE	TATA spare parts
264054600103	CABLE SET FRT TO TAIL	TATA spare parts
264054600175	MAIN CABLE SET RHD	TATA spare parts
264054700101	TWIN BLOWER W/RESISTOR INDIAN TRS & HSG	TATA spare parts
264058902601	GAUAGE SHIFTER SLEEVE	TATA spare parts
264058903301	PULLER FRONT HUB	TATA spare parts
264058903302	WRENCH SPLIT NUT	TATA spare parts
264058903501	PRONGED WRENCH	TATA spare parts
264058903502	WRENCH HUB LOCK NUT	TATA spare parts
264058903503	DEPTH GAUGE TAILPINION	TATA spare parts
264058903504	CLAMP TAILPINION BRG	TATA spare parts
264058903505	PULLER	TATA spare parts
264058903506	PULLER	TATA spare parts
264058903507	SUPPORT RING	TATA spare parts
264058903508	DRIFT	TATA spare parts
264058903509	DRIFT	TATA spare parts
264058903510	DRIFT	TATA spare parts
264058903511	HANDLE FOR DRIFT	TATA spare parts
264058903512	DRIFT INNER BRG INSTAL	TATA spare parts
264058904201	FIXTURE EXH VAC CYL	TATA spare parts
264060100104	ASSY.COWL WELDED RHD	TATA spare parts
264060100105	ASSY.REINFORCEMENT (BONNET PANEL INNER)	TATA spare parts
264060100107	ASSY. COWL COMPLETE WITH FITMENT	TATA spare parts
264060100115	ASSY.COWL COMPLETE L.H.D.	TATA spare parts
264060100120	ASSY.COWL WITH PARTIAL FITMENTS	TATA spare parts
264060100124	ASSY.COWL WITH CENTRE BONNET LHD	TATA spare parts
264061600116	ASSY.SUPPORT [CLAMP JACK MOUNTING ] BS6	TATA spare parts
264068401802	FLOOR MAT LH TOP	TATA spare parts
264068401803	FLOOR MAT RH TOP	TATA spare parts
264068806330	PADDING POST SIDE R.H.	TATA spare parts
264068806331	PADDING POST SIDE L.H.	TATA spare parts
264068809901	CLIP MASCOT	TATA spare parts
264068809902	PIN	TATA spare parts
264070000113	LOAD BODY COMPLT	TATA spare parts



264070100127	FLOOR PANEL WELDED	TATA spare parts
264070100142	SUPPORT BOT FR END	TATA spare parts
264070108210	MUDGUARD LH	TATA spare parts
264070108211	MUDGUARD RH	TATA spare parts
264070108279	GUSSET FRONT	TATA spare parts
264070108281	SUPPORT FRT END LH	TATA spare parts
264070108285	SUPPORT FRT END RH	TATA spare parts
264070108297	MUDGUARD STAY FRONT	TATA spare parts
264070108298	STAY MUDGUARD REAR	TATA spare parts
264070200116	ASSY FRONT PANEL SFC709	TATA spare parts
264070200120	FRONT PANEL W/LOAD GUARD	TATA spare parts
264070300115	SIDE PANEL LH	TATA spare parts
264070300116	SIDE PANEL RH	TATA spare parts
264070400106	TAIL GATE ASSY	TATA spare parts
264070400107	CHAIN ASSY	TATA spare parts
264070803202	U BOLT	TATA spare parts
264070900103	ASSY.HANDLE-LH	TATA spare parts
264070900104	ASSY.HANDLE-RH	TATA spare parts
264070908202	SUPPORT RH-BOLTED PANEL	TATA spare parts
264081100101	MUD FLAP REAR	TATA spare parts
264081100102	MUD FLAP REAR	TATA spare parts
264082400101	ACCESSORIES KIT FOR WIPER MOTOR	TATA spare parts
264082400107	KIT ELEC W/S WASHER	TATA spare parts
264082400108	ASSY.W/S.WASHER UNIT	TATA spare parts
264082400111	KIT FOR ELECTRICAL W/S WASHER UNIT-OFFER	TATA spare parts
264082400115	KIT FOR ELECTRICAL W/S WASHER UNIT	TATA spare parts
264082406303	NOZZLE ADAPTOR	TATA spare parts
264082409907	NOZZLE UNIT	TATA spare parts
264082409908	NOZZLE ADAPTER	TATA spare parts
264088500104	BUMPER ASSY RHD	TATA spare parts
264088500105	ASSY.COVER(BUMPER)LH	TATA spare parts
264088500106	ASSY.COVER(BUMPER)RH	TATA spare parts
264088500107	ASSY.BUMPER	TATA spare parts
264088507703	RUBBER COVER BUMPER LH	TATA spare parts
264088507704	RUBBER COVER BUMPER LH	TATA spare parts
264088700101	ENGINE HOOD ASSY	TATA spare parts
264088702001	INSULATION	TATA spare parts
264088707702	SEALING ENG HOOD BOTTOM	TATA spare parts
264088707707	SEALING BOTTOM	TATA spare parts
264094000103	CO DRIVER SEAT COMP	TATA spare parts
264094000105	ASSY.CO-DRIVERS SEAT	TATA spare parts
264094000108	CO DRIVER SEAT COMP RHD	TATA spare parts
264094000114	ASSY.CODRIVER SEAT-RHD	TATA spare parts
264094000115	ASSY.CODRIVER SEAT-RHD	TATA spare parts
264094000116	CO DRIVER SEAT COMP RHD	TATA spare parts
264098800101	MASCOT 608	TATA spare parts
264098806301	MASCOT 608	TATA spare parts

26410354	COVER DISTRIBUT-1510 CNG	TATA spare parts
26410435	ROTER ARM-1510 CNG	TATA spare parts
264115100101	ALTERNATOR 12V-65A	TATA spare parts
264115200101	ASSY SOLENOID(FIP SHT OFF)12V	TATA spare parts
264115200102	ASSY SOLENOID 12V	TATA spare parts
264115200104	SOLENOID 12V FIP SHUT OFF	TATA spare parts
264115200106	ASSY.SOLENOID	TATA spare parts
264115200107	ASSY. SOLENOID- INLINE FIP SHUT OFF	TATA spare parts
264115200108	ASSY SOLENOID SWITCH SFC/LP/LPT 709	TATA spare parts
264115200111	ASSY SOLENOID SWITCH SFC/LP/LPT 709	TATA spare parts
264115200112	ASSY. SOLENOID SW. FIP SHUT-OF 12V EURO1	TATA spare parts
264115200113	ASSY CAM-FOR ASSY SOLENOID FIP	TATA spare parts
264115400101	ALTERNATOR 12V 40A	TATA spare parts
264115400113	ALTERNATOR_12_65A	TATA spare parts
264115403101	D.E BEARING	TATA spare parts
264115406501	FLANGE NUT	TATA spare parts
264115409201	PLAIN WASHER BS6	TATA spare parts
264116100103	CONTAINER(ECU 497TC96 BSIII) SFC 712	TATA spare parts
264116109901	STICKER(ECU-497TC BS-III)	TATA spare parts
264124100104	BRACKET ENG MTG FRT	TATA spare parts
264124100109	ENGINE MTG PAD FRT RH BS2/3/4	TATA spare parts
264124100110	ENGINE MTG PAD FRT LH BS2/3/4	TATA spare parts
264124100117	ENGINE MTG ASSY FRONT-RH BS6	TATA spare parts
264124100118	ENGINE MTG ASSY FRONT-LH (RUBBER MOUNT)	TATA spare parts
264124108211	COVER ENG MTG FRONT	TATA spare parts
264124200102	ENGINE MOUNTING REAR	TATA spare parts
264124200105	ASSY. RUBBER SUPPORT BS1/2/3/4	TATA spare parts
264124208202	SUPPORT	TATA spare parts
264125200102	CLUTCH DISC 280 DIA	TATA spare parts
264125200103	CLUTCH DISC 280 DIA	TATA spare parts
264125200104	CLUTCH DISC 280 DIA	TATA spare parts
264125200105	CLUTCH DISC 280 DIA	TATA spare parts
264125200106	CLUTCH DISC 280 DIA	TATA spare parts
264125200107	CLUTCH DISC 280 DIA	TATA spare parts
264125200108	CLUTCH DISC 280 DIA	TATA spare parts
264125200109	CLUTCH DISC 280 DIA	TATA spare parts
264125200110	CLUTCH DISC 280 DIA	TATA spare parts
264125200111	CLUTCH DISC 280 DIA	TATA spare parts
264125200112	CLUTCH DISC 280 DIA	TATA spare parts
264125200113	CLUTCH DISC 280 DIA	TATA spare parts
264125200114	CLUTCH DISC 280 DIA	TATA spare parts
264125200115	CLUTCH DISC 280 DIA	TATA spare parts
264125200117	ASSY 280 D CL DISC WAF405	TATA spare parts
264125200118	CLUTCH DISC 280 DIA	TATA spare parts
264125200119	ASSY 280 D CL DISC WAF405	TATA spare parts
264125200120	ASSY 280 D CL DISC WAF405	TATA spare parts
264125200121	CLUTCH DISC 280 DIA	TATA spare parts

264125200122	CLUTCH DISC 280 DIA	TATA spare parts
264125200123	CLUTCH DISC 280 DIA	TATA spare parts
264125200124	CLUTCH DISC 280 DIA	TATA spare parts
264125200125	CLUTCH DISC 280 DIA	TATA spare parts
264125200126	CLUTCH DISC 280 DIA	TATA spare parts
264125200127	CLUTCH DISC 280 DIA	TATA spare parts
264125200128	ASSY.280 DIA.CL. DISC REINF	TATA spare parts
264125200130	ASSY.280 DIA.CL. DISC REINF	TATA spare parts
264125200131	ASSY.280 DIA.CL. DISC REINF	TATA spare parts
264125200132	ASSY.280 DIA.CL. DISC REINF	TATA spare parts
264125200133	ASSY. DRIVEN PLATE 280DIA. REINF	TATA spare parts
264125200134	CLUTCH DISC 280 DIA. BS2/3/4	TATA spare parts
264125400101	ASSY.280 DIA.PR.PLATE REINF	TATA spare parts
264125400102	ASSY.280 DIA.PR.PLATE REINF	TATA spare parts
264125400103	ASSY.280 DIA.PR.PLATE REINF	TATA spare parts
264125400104	ASSY.280 DIA.PR.PLATE REINF	TATA spare parts
264125400105	ASSY. CLUTCH COVER 280DIA. REINF	TATA spare parts
264125600101	CL REL FORK W/BALL PIN	TATA spare parts
264125600103	CL REL BRG W/SLEEVE	TATA spare parts
264125603701	CLUTCH RELEASE SLEEVE	TATA spare parts
264125605101	CLUTCH RELEASE FORK	TATA spare parts
264126010105	ASSY. LINKAGE LP609RHD ALL WHEEL BASES	TATA spare parts
264126010106	ASSY.LINKAGE LPT609 RHD ALL WHEEL BASES	TATA spare parts
264126400103	FORK ASSY P T O	TATA spare parts
264126400104	LEVER PTO	TATA spare parts
264126400105	ASSY LEVER	TATA spare parts
264126400108	ASSY FORK	TATA spare parts
264126403301	BRACKET P T O	TATA spare parts
264126403302	BRACKET MOUNTING VALVE	TATA spare parts
264126403303	BRACKET	TATA spare parts
264126406701	CLEVIS PIN	TATA spare parts
264126406702	CLEVIS PIN	TATA spare parts
264126406801	STRAIGHT REDUCER	TATA spare parts
264126406803	SPECIAL T CONNECTOR	TATA spare parts
264126407902	FORK PIN	TATA spare parts
264126700102	ASSY.KNOB	TATA spare parts
264126710101	BALL JOINT GBS-27	TATA spare parts
264126710113	SUB ASSY LEVER	TATA spare parts
264126710114	ASSY BRACKET	TATA spare parts
264126716702	BALL PIN THREADED TYPE	TATA spare parts
264126717110	BRACKET LINK ROD ANCHORING	TATA spare parts
264126800101	ASSY BELL CRANK LEVER	TATA spare parts
264126800102	SUB ASSY LEVER	TATA spare parts
264126800103	SELECTOR & SHIFTER ROD	TATA spare parts
264126800104	SELECTOR & SHIFTER SHAFT	TATA spare parts
264126800106	LEVER ENGAGE ENG SIDE	TATA spare parts
264126800108	LEVER INTERMEDIATE ENGAGE	TATA spare parts

264126800110	ASSY GEAR SHIFT LEVER	TATA spare parts
264126800117	CONTROL BOX ASSY	TATA spare parts
264126800120	ASSY RUBBER PAD	TATA spare parts
264126800121	SUB ASSY SUPPORT FLANGE	TATA spare parts
264126800156	GEAR SHIFT LEVER	TATA spare parts
264126800157	SUB ASSY CONTR.BOX COVER	TATA spare parts
264126800171	LINK ROD SELECTION	TATA spare parts
264126800173	LINK ROD SELECTION RHD	TATA spare parts
264126800187	BALL JOINT RH THREAD	TATA spare parts
264126800188	BELLOW BS1/2/3/4	TATA spare parts
264126800189	SPACER PLASTIC	TATA spare parts
264126800190	BRACKET ASSY	TATA spare parts
264126800191	BALL JOINT RH THREAD	TATA spare parts
264126800192	ASSY.BALL JOINT LH THREAD	TATA spare parts
264126800193	BALL JOINT LH THREAD	TATA spare parts
264126800196	GR SHIFT LEVER W/BKT	TATA spare parts
264126800197	ASSY.BRKT.(W/O.P.STRG.LPT	TATA spare parts
264126800202	TURNING TUBE	TATA spare parts
264126800203	FORK ASSY	TATA spare parts
264126800204	SUB ASSY CUP	TATA spare parts
264126800205	GEAR SHIFT LEVER	TATA spare parts
264126800207	SUB ASSY LINK ROD	TATA spare parts
264126800208	ASSY.BRKT. W.P.STRG LPT	TATA spare parts
264126800210	ASSY G.S.L.W/BKT.COMP.(FOR POWER STG.)	TATA spare parts
264126800212	ASSY.TURNING TUBE	TATA spare parts
264126800213	ASSY.BALL JOINT RHT	TATA spare parts
264126800214	ASSY.BALL JOINT LHT	TATA spare parts
264126800215	ASSY BALL JOINT RH THREADS	TATA spare parts
264126800216	ASSY BALL JOINT LH THREADS	TATA spare parts
264126800217	TURNING TUBE W/O BALL JT	TATA spare parts
264126800219	ASSY TURNING TUBE( W/O BALL JOINTS)	TATA spare parts
264126800222	ASSY TURNING TUBE	TATA spare parts
264126800224	ASSY. BALL JOINT RH THREADS BS1/2/3/4	TATA spare parts
264126800225	ASSY. BALL JOINT BS1/2/3/4/6	TATA spare parts
264126800226	ASSY. G.S.LEVER LP 709/407 RHD BS1/2/3/4	TATA spare parts
264126800227	ASSY. GEAR SHIFT LEVER W/BUSHES BS1- 4	TATA spare parts
264126800234	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
264126800235	ASSY BRACKET (GEAR SHIFT LEVER MTG)	TATA spare parts
264126800236	ASSY TURNING TUBE	TATA spare parts
264126800239	BALL JOINT ASSY RH	TATA spare parts
264126800240	BALL JOINT ASSY LH	TATA spare parts
264126800241	ASSY BRACKET(G.S.LEVER MTG.)W/O P/STRG.	TATA spare parts
264126800246	ASSY BRACKET(G.S.LEVER)W/POWER STEERING	TATA spare parts
264126800257	ASSY BRACKET(GEARSHIFT MTG.)W/O P STG.	TATA spare parts
264126800260	ASSY. GEAR SHIFT LEVER BRACKET	TATA spare parts
264126800261	ASSY. TURNING TUBE(WITHOUT BALL JOINT)	TATA spare parts
264126800269	TURNING TUBE ASSY	TATA spare parts

264126800271	ASSY. TURNING TUBE (W/O BALL JOINT)	TATA spare parts
264126800278	ASSLY TURNING TUBE (WITH BALL JOINT)	TATA spare parts
264126800285	ASSY TURNING TUBE RHD	TATA spare parts
264126800291	BALL JOINT ASSY BS6	TATA spare parts
264126800293	LIFTING HOOK ASSY	TATA spare parts
264126800301	GEAR SHIFT LEVER ASSY WITH SELECTOR FORK	TATA spare parts
264126800308	TURNING TUBE ASSY	TATA spare parts
264126800309	GEAR SHIFT LEVER ASSY WITH YOKE	TATA spare parts
264126800310	GEAR SHIFT LEVER ASSY WITH SHIFT YOKE BS	TATA spare parts
264126800311	SUPPORT TUBE ASSY	TATA spare parts
264126800312	BRACKET ASSY	TATA spare parts
264126800313	RUBBER BELLOW	TATA spare parts
264126800316	TURNING TUBE ASSY	TATA spare parts
264126800322	TURNING TUBE ASSY	TATA spare parts
264126800323	TOP PLATE ASSY GSL BRACKET	TATA spare parts
264126800324	SUPPORT TUBE ASSY	TATA spare parts
264126800344	TURNING TUBE ASSY BS6	TATA spare parts
264126800358	BRACKET ASSY SUPPORT TUBE MTG BS6	TATA spare parts
264126800359	SUPPORT TUBE ASSY BS6	TATA spare parts
264126800361	SUPPORT TUBE ASSY BS6	TATA spare parts
264126800362	TURNING TUBE ASSY BS6	TATA spare parts
264126800364	TURNING TUBE ASSY BS6	TATA spare parts
264126800369	GEAR SHIFT LEVER ASSY WITH SELECTOR FORK	TATA spare parts
264126800371	GEAR SHIFT LEVER ASSY WITH SELECTOR FORK	TATA spare parts
264126800374	TOP PLATE ASSY GSL BRACKET BS6	TATA spare parts
264126800386	TURNING TUBE ASSY BS6	TATA spare parts
264126800387	TURNING TUBE ASSY WITH BALL JOINT BS6	TATA spare parts
264126800389	GEAR SHIFT LEVER ASSY WITH SHIFT YOKE BS	TATA spare parts
264126800390	GSL ASSY WITH TURNING TUBE/KNOB BS6	TATA spare parts
264126800391	GEAR SHIFT LINKAGE ASSY BS6	TATA spare parts
264126803401	BUSH SWING ARM BLOCK	TATA spare parts
264126803402	BUSH GEAR SHIFT LEVER	TATA spare parts
264126803403	BUSH	TATA spare parts
264126803404	BUSH BELL CRANK LEVER	TATA spare parts
264126803406	BUSH SELE & SHIFT SHAFT	TATA spare parts
264126803407	BUSH BELL CRANK LEVER	TATA spare parts
264126803408	BUSH SWING ARM BLOCK	TATA spare parts
264126803409	BUSH GEAR SHIFT LEVER	TATA spare parts
264126803411	BUSH	TATA spare parts
264126803412	BUSH SHPERICAL SEAT G.S.LEVER	TATA spare parts
264126803505	BOSS	TATA spare parts
264126805101	SWING ARM BLOCK	TATA spare parts
264126806304	SPACER GR SHIFT LEVER	TATA spare parts
264126806502	HEX BOLT M8 X 47	TATA spare parts
264126806503	HEX BOLT	TATA spare parts
264126806703	THREADED PIN	TATA spare parts
264126806705	THREADED PIECE BS6	TATA spare parts

264126807102	PIVOT	TATA spare parts
264126807153	GS LEVER BRACKETLP/LPT709	TATA spare parts
264126807178	LIFTING HOOK	TATA spare parts
264126807190	TOP PLATE	TATA spare parts
264126807194	LIFTING HOOK BS6	TATA spare parts
264126807704	RUBBER BELLOW	TATA spare parts
264126807705	RUBBER GROMMET	TATA spare parts
264126807706	RUBBER PAD	TATA spare parts
264126807708	RUBBER GASKET	TATA spare parts
264126807712	RUB BELLOW G S L COWL	TATA spare parts
264126807713	RUB BELLOW G S L TOP COWL	TATA spare parts
264126807714	RUBBER PAD	TATA spare parts
264126807715	RUBBER FLAP CAB	TATA spare parts
264126807716	RUBBER BELLOW CAB	TATA spare parts
264126807717	RUBBER SEAL	TATA spare parts
264126807718	RUBBER BELLOW BS6	TATA spare parts
264126807719	REXIN BELLOW	TATA spare parts
264126807721	RUBBER BELLOW¿BS6	TATA spare parts
264126807801	OIL SEAL	TATA spare parts
264126807904	LINK ROD ENGAGE ENG SIDE	TATA spare parts
264126807905	LINK ROD INTER ENGAGE	TATA spare parts
264126807914	LINK ROD 335MM LONG	TATA spare parts
264126807915	LINK ROD 335 MM LONG	TATA spare parts
264126807916	LINK ROD 204 MM LONG	TATA spare parts
264126807921	LINK ROD	TATA spare parts
264126807925	LINK ROD	TATA spare parts
264126807926	LINK ROD (LENGTH 245MM)	TATA spare parts
264126808207	LOCK PLATE	TATA spare parts
264126808214	LOCK PLATE	TATA spare parts
264126808215	LOCK PLATE	TATA spare parts
264126808227	CLAMPING PLATE (G.S.LEVER RUBBER BELLOW)	TATA spare parts
264126808231	ENCLOSURE RUBBER PAD RHD	TATA spare parts
264126808234	BELLOW HOLDER	TATA spare parts
264126808238	FLANGE	TATA spare parts
264126808605	SPACER	TATA spare parts
264126808610	SPACER	TATA spare parts
264126808611	SPACER	TATA spare parts
264126808612	SPACER	TATA spare parts
264126808613	SPACER	TATA spare parts
264126808614	SPACER	TATA spare parts
264126808615	SPACER	TATA spare parts
264126808616	SPACER	TATA spare parts
264126808702	SPRING RING	TATA spare parts
264126808703	SPRING WASHER CURVED	TATA spare parts
264126808801	STUD	TATA spare parts
264126810101	ASSY.BRKT(W.P.STRG.LPTLHD	TATA spare parts
264126810102	ASSY.BRACKET (FOR COWL VERSION)	TATA spare parts

264126810103	ASSY.BRACKET W.P.STRG	TATA spare parts
264126810104	ASSY.BRACKET W/O P.STRG	TATA spare parts
264126810108	ASSY SUPPORT TUBE	TATA spare parts
264126810130	ASSY BRACKET (WITH POWER STG) NO BOSSES	TATA spare parts
264126810132	ASSY. BRACKET(G.S. LEVER MTG.)(WITHOUT P	TATA spare parts
264126810135	ASSY.GEAR SHIFT LEVER BRACKET(LHD)	TATA spare parts
264126810138	SUPPORT TUBE ASSY	TATA spare parts
264126810139	TOP PLATE ASSY GSL BRACKET	TATA spare parts
264126810141	BRACKET ASSY GEAR SHIFT LEVER MTG	TATA spare parts
264126813502	BOSS GEAR SHIFT BRACKETç BS6	TATA spare parts
264126813702	GEAR SHIFT LEVER MTG BKT LPT(W/O PSTRG)	TATA spare parts
264126813703	GEAR SHIFT LEVER MTG BKT LPT(PSTRG)	TATA spare parts
264126813704	GEAR SHIFT LEVER MTG BKT LP(W/O PSTRG)	TATA spare parts
264126813705	GEAR SHIFT LEVER MTG BKT LP (PSTRG)	TATA spare parts
264126813711	BRACKET GEAR SHIFT LEVER MTG	TATA spare parts
264126813712	BRACKET GEAR SHIFT LEVER MTG BS3/4	TATA spare parts
264126813713	BRACKET GEAR SHIFT LEVER MTG	TATA spare parts
264126813716	BRACKET GEAR SHIFT LEVER	TATA spare parts
264126813718	BRACKET GEAR SHIFT LEVER MTG BS6	TATA spare parts
264126813719	BRACKET GEAR SHIFT LEVER MTG BS6	TATA spare parts
264126813720	BRACKET GEAR SHIFT LEVER MTG BS6	TATA spare parts
264126813722	BRACKET GEAR SHIFT LEVER MTG	TATA spare parts
264126813723	BRACKET GEAR SHIFT LEVER MTG BS6	TATA spare parts
264126813724	BRACKET GEAR SHIFT LEVER MTG BS6	TATA spare parts
264129000103	ASSY.BRAKE PEDAL WITH SLEEVE & RUBBER	TATA spare parts
264129000104	ASSY.BRAKE PEDAL WITH SLEEVE & COVER	TATA spare parts
264129100111	SUPPORT BRAKE	TATA spare parts
264129100112	SUPPORT COMP CLUTCH	TATA spare parts
264129100113	CLUTCH PEDAL COMP	TATA spare parts
264129100114	BRAKE PEDAL COMP	TATA spare parts
264129100115	CLUTCH CONTROL COMP	TATA spare parts
264129100116	ASSY BRAKE CONTROLS COMP	TATA spare parts
264129100117	CLUTCH MASTER CYL. 19.05 DIA. BS1/2/3/4	TATA spare parts
264129100117AE	CLUTCH MASTER CYLINDER 715	TATA spare parts
264129100126	CON LINE FLUID CONT - TMC	TATA spare parts
264129100127	CONNECTING LINE LHD	TATA spare parts
264129100131	CL MASTER CYL	TATA spare parts
264129100134	ASSY TUBE	TATA spare parts
264129100136	TUBE ASSY	TATA spare parts
264129100140	TUBE ASSY	TATA spare parts
264129100142	TUBE ASSY	TATA spare parts
264129100149	TUBE ASSY	TATA spare parts
264129100151	ASSY. TUBE	TATA spare parts
264129100153	CLUTCH MASTER CYL. 19.05 DIA.	TATA spare parts
264129100155	MAJOR R/KIT OF 19.05 DIA.CLUTCH M/CYL	TATA spare parts
264129100156	MINOR KIT CLUTCH M/CYL	TATA spare parts
264129100161	ASSY. TUBE	TATA spare parts

264129100173	ASSY FLUID RESERVOIR	TATA spare parts
264129100175	ASSY CONNECTING LINE	TATA spare parts
264129100182	BRAKE FLUID RESERVOIR	TATA spare parts
264129100183	TUBE ASSY	TATA spare parts
264129100184	TUBE ASSY	TATA spare parts
264129100186	ASSY COVER CONTROLS	TATA spare parts
264129100187	ASSY PEDAL LEVER (BRAKE)-RHD	TATA spare parts
264129100189	ASSY BRAKE PEDAL	TATA spare parts
264129100190	ASSY BRAKE PEDAL COMPLETE-LHD	TATA spare parts
264129100191	ASSY TUBE CL MC TO HOSE	TATA spare parts
264129100192	TUBE CLUTCH 6 O.D.X0.7 TH	TATA spare parts
264129100194	ASSY TUBE	TATA spare parts
264129100195	PIPE	TATA spare parts
264129100196	ASSY TUBE	TATA spare parts
264129100198	ASSY.TUBE-60.D.X0.7THK	TATA spare parts
264129100199	ASSY.HOSE CLUTCH	TATA spare parts
264129106301	BUSH CLUTCH PEDAL	TATA spare parts
264129106702	PIN CLUTCH PEDAL BS4	TATA spare parts
264129106703	BRAKE PIN BS4	TATA spare parts
264129106704	CLUTCH PEDAL PIN	TATA spare parts
264129107701	RUBBER GROMMET BS6	TATA spare parts
264129108208	STOPPER CLUTCH PEDAL	TATA spare parts
264129108228	CLAMP (CLUTCH HOSE MTG)	TATA spare parts
264129108229	BRACKET	TATA spare parts
264129108237	CLUTCH PEDAL STOPPER	TATA spare parts
264129108601	SPACER	TATA spare parts
264129108602	SPACER	TATA spare parts
264129108701	TORSION SPRING	TATA spare parts
264129109902	SLEEVE	TATA spare parts
26412910990260	SLEEVE W/O BATH NITRIDING	TATA spare parts
264129110101	ASSY.HOSE CLUTCH	TATA spare parts
264129200101	ASSY. CLUTCH BOOSTER 90DIA	TATA spare parts
264129200102	ASSY BRACKET CLUTCH BOOSTER MTG.	TATA spare parts
264129200107	ASSY.SUPPORT COMPLETE CLUTCH	TATA spare parts
264129200108	ASSY.PEDAL LEVER(CLUTCH)	TATA spare parts
264129200109	ASSY.CLUTCH PEDAL	TATA spare parts
264129200110	ASSY. COVER (CONTROLS)	TATA spare parts
264129200112	ASSY. CLUTCH BOOSTER 90DIA	TATA spare parts
264129200113	ASSY.BRACKET (CLUTCH BOOSTER MTG.)	TATA spare parts
264129200114	ASSY.MAJOR REPAIR KIT (90 DIA BOOSTER)	TATA spare parts
264129200115	ASSY.MINOR REPAIR KIT (90 DIA BOOSTER)	TATA spare parts
264129200121	CLUTCH MASTER CYL. 19.05 DIA.	TATA spare parts
264129200129	ASSY.MAJOR REPAIR KIT (90 DIA BOOSTER)	TATA spare parts
264129208201	BRACKET CLUTCH BOOSTER SUPPORT	TATA spare parts
264129300102	THRUST ROD SLAVE CYL	TATA spare parts
264129300103	BRACKET ASSY	TATA spare parts
264129300104	ASSY. PUSH ROD	TATA spare parts



264129303302	BRACKET CLUTCH PIPE MTG BS6	TATA spare parts
264130100101	ACCELERATOR MODULE ASSY	TATA spare parts
264130100110	ASSY.BRACKET	TATA spare parts
264130100115	CABLE ACCL PULL	TATA spare parts
264130100117	CABLE ACCL PULL	TATA spare parts
264130100126	BKT ACCELERATOR RHD	TATA spare parts
264130100127	PEDEL LEVER ACCL RHD	TATA spare parts
264130100128	PEDAL ACCELERATOR	TATA spare parts
264130100131	ASSY.PEDAL LEVER ACCELERATOR-LHD.	TATA spare parts
264130100133	PEDAL ACCELERATOR W/COVER	TATA spare parts
264130100135	ASSY PEDAL PLATE WITH COVER	TATA spare parts
264130100136	CABLE ACCELERATOR RHD	TATA spare parts
264130100137	CABLE ACCELERATOR LHD	TATA spare parts
264130100138	ASSY.ACCL.CABLE	TATA spare parts
264130100140	ASSY.ACCL.CABLE	TATA spare parts
264130100144	ASSY ACC. PEDAL	TATA spare parts
264130100145	CABLE ACCELERATOR-609-RHD 1821MM	TATA spare parts
264130100147	ASSY ACCL.CABLE-LPT 709 RHD	TATA spare parts
264130100148	CABLE ACCLERATOR RHD	TATA spare parts
264130100149	ASSY ACCL CABLE 609 LHD	TATA spare parts
264130100150	ASSY. PULL CABLE ACCELERATOR	TATA spare parts
264130100151	ASSY.PULL CABLE ACCELERATOR	TATA spare parts
264130100152	ASSY. ACCL & ENGINE STOP CABLE MTG. BKT.	TATA spare parts
264130100153	ASSY.BRACKET WITH PEDAL LEVER	TATA spare parts
264130100155	ACCELERATOR PEDAL MODULE	TATA spare parts
264130100158	ASSY PEDAL LEVER ACCELERATOR (RHD)	TATA spare parts
264130100159	ASSY ACCELERATOR PEDAL WITH BRACKET	TATA spare parts
264130100160	ASSY.PEDAL LEVER ACCELERATOR (RHD)	TATA spare parts
264130100161	ASSY. PEDAL LEVER ACCELERATOR (LHD)	TATA spare parts
264130100169	ACCELERATOR PEDAL ASSY WITH MTG BRACKET	TATA spare parts
264130100171	ACCELERATOR CABLE ASSY	TATA spare parts
264130103301	BRACKET ACCELERATOR CABLE MTG	TATA spare parts
264130103302	SUPPORT BRACKET	TATA spare parts
264130106004	LINK ROD	TATA spare parts
264130107104	SPACER (FLOOR PANEL SIDE LH)	TATA spare parts
264130107701	COVER ACCL PEDAL	TATA spare parts
264130108203	ACCELARATOR SUPPORT	TATA spare parts
264130108229	BRACKET ACCELERATOR CABLE MTG.	TATA spare parts
264130108230	BRACKET ACCL. PEDAL MTG.	TATA spare parts
264130108234	BRACKET (ACCL. PEDAL MTG.)	TATA spare parts
264130108236	SPACER BS6	TATA spare parts
264130109902	FORK	TATA spare parts
264131000101	FRAME ASSY LPT/34WB	TATA spare parts
264131000102	FRAME ASSY LP/34 COWL	TATA spare parts
264131000103	FRAME ASSY LPT/38WB	TATA spare parts
264131000104	FRAME ASSY LP/38WB	TATA spare parts
264131000113	ASSY FRAME LPT709 34WB	TATA spare parts

264131000114	ASSY FRAME W/O CLEATS 38 WB	TATA spare parts
264131000117	ASSY FRAME LPT 709E TURBO	TATA spare parts
264131000118	ASSEMBLY FRAME LP38	TATA spare parts
264131000124	KIT FOR LP 709 CHASIS FRAME	TATA spare parts
264131000127	RETRO KIT FOR ASSY. FRAME (LP 709 - 38WB	TATA spare parts
264131000131	ASSY FRAME LPT 709 BS-III/38WB	TATA spare parts
264131000133	ASSY FRAME LP 709 BS-III/38 WB	TATA spare parts
264131000134	ASSY.FRAME (LPT 712EX BS-III/34 WB)	TATA spare parts
264131000136	ASSY FRAME (LP 712 BS-III/34 WB)	TATA spare parts
264131000139	ASSY.FRAME LPT 712EX BS-III W/O CLEATS	TATA spare parts
264131000142	ASSY. FRAME (LP712/38WB ARMY)	TATA spare parts
264131000143	ASSY. FRAME COMPLETE	TATA spare parts
264131000146	ASSY FRAME COMPLETE LP 709/42	TATA spare parts
264131000147	FRAME ASSY COMP	TATA spare parts
264131000150	FRAME ASSY WITH FITMENT	TATA spare parts
264131107130	LONG MEMBER -RH	TATA spare parts
264131107131	LONG MEMBER -LH	TATA spare parts
264131200102	ASSY CENTRE BRG CROSS MEMBER SFC709TURBO	TATA spare parts
264131200103	ASSY CENTRE BRG CROSS MEMBER LPT709	TATA spare parts
264131200104	ASSY.C.M.REAR SPRING - FRONT SFC 709TC	TATA spare parts
264131200105	CROSS MEMBER	TATA spare parts
264131200106	ASSY CROSS MEMBER¿ REAR SPRING	TATA spare parts
264131200109	FRONT CROSS MEMBER	TATA spare parts
264131200110	CROSS MEMBER FRT W/T HOOK	TATA spare parts
264131200111	SUPPORT ENG CR MEMBER RR	TATA spare parts
264131200112	ASSY.REINFORCEMENT	TATA spare parts
264131200114	ASSY CROSS MEMBER FR	TATA spare parts
264131200115	ASSEMBLY BRACKET (AIR FILTER MTG)	TATA spare parts
264131200116	ASSY CROSS MEMBER (WITH TOWING HOOK)	TATA spare parts
264131200117	ASSY.C.M. R.S.B. REAR	TATA spare parts
264131200118	ASSY.CROSS MEMBER-RSB FRONT	TATA spare parts
264131200119	ASSY.CROSS MEMBER	TATA spare parts
264131200120	ASSY. CROSS MEMBER REAR SA MTG.	TATA spare parts
264131200121	ASSY. SUPPORT - RH ENGINE C.M. REAR	TATA spare parts
264131200122	ASSY. SUPPORT - LH ENGINE C.M. REAR	TATA spare parts
264131200135	ASSY CROSS MEMBER (FRONT)	TATA spare parts
264131200138	ASSY FRONT GUSSET-RH	TATA spare parts
264131200139	ASSY FRONT GUSSET-LH	TATA spare parts
264131200142	ASSY.CENTER BRG.MTG CROSS MEMBER.	TATA spare parts
264131200144	ASSY JOINT GUSSET PLATE-RH	TATA spare parts
264131200145	ASSY JOINT GUSSET PLATE-LH	TATA spare parts
264131207102	SUPPORT (RH) ENGINE C.M. REAR	TATA spare parts
264131207111	PACKING PLATE [ 5 THK.]	TATA spare parts
264131207120	JOINT GUSSET PLATE	TATA spare parts
264131207121	JOINT GUSSET PLATE-RH	TATA spare parts
264131207122	JOINT GUSSET PLATE-LH	TATA spare parts
264131207129	JOINT GUSSET PLATE	TATA spare parts

264131207131	GUSSET PLATE FOR FES	TATA spare parts
264131207134	SUPPORT [ ENGINE C. M.-REAR]	TATA spare parts
264131207140	JOINT GUSSET PLATE-RH	TATA spare parts
264131207141	JOINT GUSSET PLATE	TATA spare parts
264131208204	REINFORCEMENT - RH (BOTTOM)	TATA spare parts
264131208205	REINFORCEMENT - LH (BOTTOM)	TATA spare parts
264131208211	REINF HELPER SPG BKT	TATA spare parts
264131208237	REINFORCEMENT -RH [TOP]	TATA spare parts
264131208238	REINFORCEMENT-LH [TOP]	TATA spare parts
264131208240	PACKING PLATTE [ 1.6 THK]	TATA spare parts
264131208241	PACKING PLATE [3.15 THK]	TATA spare parts
264131208245	REINFORCEMENT	TATA spare parts
264131208250	CROSS MEMBER FRONT	TATA spare parts
264131208255	END CROSS MEMBER	TATA spare parts
264131208256	ENGINE CROSS MEMBER RR	TATA spare parts
264131208260	REINFORCEMENT R.H. BS6	TATA spare parts
264131208261	REINFORCEMENT-L.H. BS6	TATA spare parts
264131208262	REINFORCEMENT TOP (RH)	TATA spare parts
264131208263	REINFORCEMENT TOP (LH)	TATA spare parts
264131208264	REINFORCEMENT BOTTOM (RH)	TATA spare parts
264131208265	REINFORCEMENT BOTTOM (LH)	TATA spare parts
264131208266	REINFORCEMENT (HELPER SPR. BRKT.)	TATA spare parts
264131208269	REINFORCEMENT-RH	TATA spare parts
264131208270	REINFORCEMENT-LH	TATA spare parts
264131208271	REINFORCEMENT - RSB FRONT	TATA spare parts
264131208273	REINFORCEMENT-FRONT	TATA spare parts
264131208276	REINFORCEMENT LH (HELPER SPRING BRACKET)	TATA spare parts
264131208277	REINFORCEMENT (RH)	TATA spare parts
264131208278	REINFORCEMENT (LH) NEAR 7TH CM	TATA spare parts
264131208279	REINFORCEMENT	TATA spare parts
264131208283	REINFORCEMENT -RH (TOP)	TATA spare parts
264131208284	REINFORCEMENT -LH (REAR)	TATA spare parts
264131208288	END CROSS MEMBER	TATA spare parts
264131208299	REINFORCEMENT -RSB REAR	TATA spare parts
26413120M10110	ASSY FRONT CM WITH TOW HOOK BS6-PH2	TATA spare parts
264131300102	BKT FRT SPRING BUMP STOP	TATA spare parts
264131300103	ASSY.REINFORCEMENT	TATA spare parts
264131308201	BRACKET(FRONT SPRG.BUMP STOPPER)	TATA spare parts
264131400111	CLEAT 609/709	TATA spare parts
264131408201	REINFORCEMENT (TOWING HOOK)	TATA spare parts
264131700101	FRAME ASSY WITH FITMENT	TATA spare parts
264131700108	ASSY. FRAME	TATA spare parts
264132100103	BKT FRT SPRING BS1/2/3/4	TATA spare parts
264132100106	FRONT SPRING NOR CAMBER	TATA spare parts
264132100107	LEAF SPRING 1ST W/BUSH FR	TATA spare parts
264132100109	FRONT SPRING ASSY	TATA spare parts
264132100110	LEAF SPRING 1ST W/BUSH	TATA spare parts

264132100110DF	MAIN LEAF FRONT W/BUSH - LP410/712	TATA spare parts
264132100113	FRONT SPRING HIGH CAMBER	TATA spare parts
264132100114	LEAF SPRING 1ST W/BUSH FR	TATA spare parts
264132100115	FRONT SPRING NOR CAMBER	TATA spare parts
264132100116	LEAF SPRING 1ST W/BUSH FR	TATA spare parts
264132100116DF	MAIN LEAF FRONT W/BUSH - LPT407	TATA spare parts
264132100117	FRONT SPRING HIGH CAMBER	TATA spare parts
264132100118	LEAF SPRING 1ST W/BUSH FR	TATA spare parts
264132100131	ASSY. FRONT SPRING (HIGHER CAMBER)	TATA spare parts
264132100132	ASSY. FRONT SPRING (NORMAL CAMBER)	TATA spare parts
264132100133	ASSY. FRONT SPRING (NORMAL CAMBER)	TATA spare parts
264132100134	ASSY. FRONT SPRING (HIGHER CAMBER)	TATA spare parts
264132100135	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
264132100137	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
264132100137DF	MAIN LEAF FRONT W/BUSH - LPT709	TATA spare parts
264132100138	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
264132100151DF	SECOND LEAF FRONT - LP709 BUS	TATA spare parts
264132107123	LEAF SPRING 2ND FRT	TATA spare parts
264132107124	LEAF SPRING 3RD FRT	TATA spare parts
264132107125	LEAF SPRING 4TH FRT	TATA spare parts
264132107126	LEAF SPRING 5TH FRT	TATA spare parts
264132107127	LEAF SPRING 6TH FRT	TATA spare parts
264132107128	LEAF SPRING 7TH FRT	TATA spare parts
264132107129	LEAF SPRING 8TH FRT	TATA spare parts
264132107130	LEAF SPRING 9TH FRT	TATA spare parts
264132107131	LEAF SPRING 1ST	TATA spare parts
264132107132	LEAF SPRING 2ND	TATA spare parts
264132107132DF	SECOND LEAF FRONT - LP410/712 BUS	TATA spare parts
264132107133	LEAF SPRING 3RD	TATA spare parts
264132107133DF	THIRD LEAF FRONT - - LP410/712 BUS	TATA spare parts
264132107134	LEAF SPRING 4TH	TATA spare parts
264132107134DF	FOURTH LEAF FRONT - LP410/712 BUS	TATA spare parts
264132107135	LEAF SPRING 5TH	TATA spare parts
264132107135DF	FIFTH LEAF FRONT - LP410/712 BUS	TATA spare parts
264132107136	LEAF SPRING 6TH	TATA spare parts
264132107137	LEAF SPRING 7TH	TATA spare parts
264132107138	LEAF SPRING 8TH	TATA spare parts
264132107139	LEAF SPRING 9TH	TATA spare parts
264132107140	LEAF SPRING 10TH	TATA spare parts
264132107141	FIRST LEAF FOR 01 13	TATA spare parts
264132107142	LEAF SPRING 2ND FRT	TATA spare parts
264132107143	LEAF SPRING 3RD FRT	TATA spare parts
264132107144	LEAF SPRING 4TH FRT	TATA spare parts
264132107145	LEAF SPRING 5TH FRT	TATA spare parts
264132107146	LEAF SPRING 6TH FRT	TATA spare parts
264132107147	LEAF SPRING 7TH FRT	TATA spare parts
264132107151	LEAF SPRING 2ND	TATA spare parts

264132107152	LEAF SPRING 3RD	TATA spare parts
264132107153	LEAF SPRING 4TH	TATA spare parts
264132107154	LEAF SPRING 5TH	TATA spare parts
264132107155	LEAF SPRING 6TH	TATA spare parts
264132107157	LEAF SPRING 2ND	TATA spare parts
264132107158	LEAF SPRING 3RD	TATA spare parts
264132107159	LEAF SPRING 4TH	TATA spare parts
264132107160	LEAF SPRING 5TH	TATA spare parts
264132107161	LEAF SPRING 6TH	TATA spare parts
264132107162	LEAF SPRING 7TH AUX	TATA spare parts
264132107163	LEAF SPRING 8TH	TATA spare parts
264132107164	LEAF SPRING 9TH	TATA spare parts
264132107195	SECOND LEAF	TATA spare parts
264132107195DF	SECOND LEAF FRONT - LPT709	TATA spare parts
264132107196	THIRD LEAF	TATA spare parts
264132107196DF	THIRD LEAF FRONT - LPT709	TATA spare parts
264132107197	FOURTH LEAF	TATA spare parts
264132107197DF	FOURTH LEAF FRONT - LPT709	TATA spare parts
264132107198	FIFTH LEAF	TATA spare parts
264132107198DF	FIFTH LEAF FRONT - LPT709	TATA spare parts
264132107199	SIXTH LEAF	TATA spare parts
264132107201	SEVENTH LEAF	TATA spare parts
264132107202	EIGHTH LEAF	TATA spare parts
264132107204	NINTH LEAF	TATA spare parts
264132107206	SECOND LEAF	TATA spare parts
264132107207	THIRD LEAF	TATA spare parts
264132107208	FOURTH LEAF	TATA spare parts
264132107209	FIFTH LEAF	TATA spare parts
264132107210	SIXTH LEAF	TATA spare parts
264132107211	SEVENTH LEAF	TATA spare parts
264132107212	EIGHTH LEAF	TATA spare parts
264132107213	NINTH LEAF	TATA spare parts
264132203701	CASTER PLATE	TATA spare parts
264132204206	U CLAMP.(LP/LPT 609 FRONT).	TATA spare parts
264132204208	U CLAMP	TATA spare parts
264132204209	U CLAMP	TATA spare parts
264132207102	CASTER PLATE	TATA spare parts
264132207103	CASTER PLATE	TATA spare parts
264132207104	CASTER PLATE (4.8 DEGREES)	TATA spare parts
264132207105	CASTER PLATE (1.1 DEGREES)	TATA spare parts
264132300101	ASSY. FRONT SHOCK ABSORBER BS1/2/3/4	TATA spare parts
264132300102	ASSY BRACKET TOP SFC 609	TATA spare parts
264132300111	SHOCK ABSORBER FRONT	TATA spare parts
264132300114	SHOCK ABSORBER FRONT	TATA spare parts
264132300116	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
264132300117	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
264132305102	BKT S/ABS BOTTOM FRT	TATA spare parts

264132305103	BKT S/ABS BOTTOM FRT	TATA spare parts
264132308206	WASHER FRT S/ABS MTG	TATA spare parts
264132308602	BUSH FRT S/ABS	TATA spare parts
264132308603	PRESSED WASHER (S/A FITMENT)	TATA spare parts
264132400107	LEAF SPRING 1ST W/BUSH RR	TATA spare parts
264132400107DF	MAIN LEAF REAR W/BUSH LPT407/709	TATA spare parts
264132400110	REAR SPRING ASSY 2 STAGE	TATA spare parts
264132400111	LEAF SPRING 1ST W/BUSH RR	TATA spare parts
264132400111DF	MAIN LEAF REAR W/BUSH - LP407/410	TATA spare parts
264132400112	REAR SPRING ASSY W/AUX	TATA spare parts
264132400116	ASSY FIRST LEAF WITH BUSHES.	TATA spare parts
264132400116DF	MAIN LEAF REAR W/BUSH - LP712	TATA spare parts
264132400117	ASSY. REAR SPRING; VE	TATA spare parts
264132403701	SLIDE SUPPORT	TATA spare parts
264132403702	SLIDE SUPPORT	TATA spare parts
264132406701	SPRING PIN REAR	TATA spare parts
264132407128	SECOND LEAF-MAIN	TATA spare parts
264132407128DF	SECOND LEAF REAR - LPT407/709	TATA spare parts
264132407129	LEAF SPRING 3RD RR	TATA spare parts
264132407129DF	THIRD LEAF REAR - LPT407/709	TATA spare parts
264132407130	FOURTH LEAF-MAIN	TATA spare parts
264132407131	FIFTH LEAF-MAIN	TATA spare parts
264132407139DF	FOURTH LEAF REAR - LPT407/709	TATA spare parts
264132407143	LEAF SPRING 2ND RR	TATA spare parts
264132407143DF	SECOND LEAF REAR - LP407/410/712	TATA spare parts
264132407144	LEAF SPRING 3RD RR	TATA spare parts
264132407144DF	THIRD LEAF REAR - LP407/410/712	TATA spare parts
264132407145	LEAF SPRING 4TH RR	TATA spare parts
264132407145DF	FOURTH LEAF REAR - LP407/410/712	TATA spare parts
264132407146	LEAF SPRING 5TH RR	TATA spare parts
264132407146DF	FIFTH LEAF REAR - LP407/410/712	TATA spare parts
264132407147	LEAF SPRING 6TH RR	TATA spare parts
264132407148	SEVENTH LEAF	TATA spare parts
264132407149	LEAF SPRING 8TH RR	TATA spare parts
264132407150	LEAF SPRING 1ST RR AUX	TATA spare parts
264132407150DF	MAIN LEAF - AUX SPRING - LPT709	TATA spare parts
264132407151	LEAF SPRING 2ND RR AUX	TATA spare parts
264132407151DF	SECOND LEAF - AUX SPRING - LPT709	TATA spare parts
264132407152	LEAF SPRING 3RD RR	TATA spare parts
264132407153	LEAF SPRING 4TH RR AUX	TATA spare parts
264132407153DF	FOURTH LEAF - AUX SPRING - LPT709	TATA spare parts
264132407154	LEAF SPRING 5TH AUX RR	TATA spare parts
264132407155	LEAF SPRING 6TH RR AUX	TATA spare parts
264132407156	LEAF SPRING 7TH RR AUX	TATA spare parts
264132407158	SECOND LEAF	TATA spare parts
264132407158DF	SECOND LEAF REAR - LP709/712	TATA spare parts
264132407159	THIRD LEAF	TATA spare parts

264132407159DF	THIRD LEAF REAR - LP709/712	TATA spare parts
264132407160	FOURTH LEAF	TATA spare parts
264132407160DF	FOURTH LEAF REAR - LP709/712	TATA spare parts
264132407161	FIFTH LEAF	TATA spare parts
264132407161DF	FIFTH LEAF REAR - LP709/712	TATA spare parts
264132407162	SIXTH LEAF	TATA spare parts
264132407162DF	SIXTH LEAF REAR - LP709/712	TATA spare parts
264132407163	SEVENTH LEAF	TATA spare parts
264132407164	SPACER	TATA spare parts
264132409901	GREASE NIPPLE 90 DEG	TATA spare parts
264132504204	U CLAMP-LP 609 REAR SPRG.	TATA spare parts
264132504205	U CLAMP	TATA spare parts
264132504206	U CLAMP	TATA spare parts
264132504207	U -CLAMP	TATA spare parts
264132504208	U-CLAMP	TATA spare parts
264132600102	ASSY.REAR SHOCK ABSORBER	TATA spare parts
264132608209	BRACKET [ L.H.]	TATA spare parts
264132608210	BRACKET RH	TATA spare parts
264132608211	BRACKET RH. REAR SA MTG.BOTTOM	TATA spare parts
264132608212	BRACKET LH. REAR SA MTG.BOTTOM	TATA spare parts
264132800102	BKT ANTI ROLL BAR FRT	TATA spare parts
264132800104	CONNECTING ROD ARB FRT	TATA spare parts
264132800112	ASSY BRACKET LH-A.R.B.MTG.	TATA spare parts
264132800113	ASSY. ANTIROLL BAR COMPLETE	TATA spare parts
264132803801	CLAMP SUPPORT FR ARB	TATA spare parts
264132804201	U CLAMP FRONT ARB MTG	TATA spare parts
264132807103	CLAMPE PLATE FR ARB	TATA spare parts
264132900101	BKT ANTI ROLL BAR RH RR	TATA spare parts
264132900102	BKT LH RR ARB MTG	TATA spare parts
264132900103	CONNECTING ROD ARB RR	TATA spare parts
264132900104	ASSY.REAR ANTIROLL BAR COMPLETE.	TATA spare parts
264132900105	ANTI ROLL BAR REAR	TATA spare parts
264132900107	ASSY.BRACKET R.H.WITH BUSH & SLEEVE	TATA spare parts
264132900108	ASSY.BRACKET.LH.WITH BUSH & SLEEVE(R ARB	TATA spare parts
264132900110	ASSY. CONNECTING ROD(ANTIROLL BAR))	TATA spare parts
264132900111	ASSY. ANTIROLLBAR COMPLETE.	TATA spare parts
264132908204	SHIM (1 THK.)	TATA spare parts
264132908205	SHIM (3.15 THK.)	TATA spare parts
264133000103	ASSY.FRONT AXLE WITH BRAKES RHD	TATA spare parts
264133000105	FRONT AXLE ASSY RHD	TATA spare parts
264133000109	ASSY.FA.709 LP S CAM RHD-N/ASB.	TATA spare parts
264133000110	ASSY FRONT AXLE WITH BRAKES LHD (N/ASB )	TATA spare parts
264133000111	ASSY.FA.709 LP S CAM RHD-ASB	TATA spare parts
264133000118	ASSY.FRONT AXLE WITH BRAKES(ASBESTOS)	TATA spare parts
264133000119	ASSY.FRONT AXLE WITH BRK. NON ASBESTOS	TATA spare parts
264133000120	ASSY. FRONT AXLE WITH BRAKES (NON ASB.)	TATA spare parts
264133000121	FA 712 ABS RHD	TATA spare parts

264133105107	ASSY. FRONT AXLE BEAM STD BS1/2/3/4	TATA spare parts
264133105111	FRONT AXLE BEAM NORMAL	TATA spare parts
264133200102	STUB AXLE W/BUSH STD	TATA spare parts
264133200108	TIE ROD ASSY OFFER	TATA spare parts
264133200111	TIE ROD ASSY	TATA spare parts
264133200112	TIE ROD END LH BS1/2/3/4	TATA spare parts
264133200113	TIE ROD END RH BS1/2/3/4	TATA spare parts
264133200114	ASSY.TIE ROD	TATA spare parts
264133200118	ASSY TIE ROD	TATA spare parts
264133200121	TIE ROD OFFER DRG. BS1/2/3/4	TATA spare parts
264133200122	ASSY.TIE ROD	TATA spare parts
264133200123	TIE ROD ASSY	TATA spare parts
264133200124	ASSY.TIE ROD	TATA spare parts
264133200131	ASSY.STUB AXLE NORMAL	TATA spare parts
264133200133	ASSY.BALL JOINT	TATA spare parts
264133200135	ASSY. BALL JOINT LH BS1/2/3/4	TATA spare parts
264133200136	ASSY. BALL JOINT RH BS1/2/3/4	TATA spare parts
264133200139	ASSY.TIE ROD (WITH GREASE NIPPLE)	TATA spare parts
264133205101	STUB AXLE	TATA spare parts
264133208601	THRUST PAD UPPER NORMAL	TATA spare parts
264133208606	THRUST PAD LOWER NORMAL	TATA spare parts
264133209901	SPACER	TATA spare parts
264133400101	BR DRUM W/HUB & BRG FR	TATA spare parts
264133400102	FRONT HUB ASSY 709 S-CAM	TATA spare parts
264133400103	BRAKE DRUM WITH HUB	TATA spare parts
264133400104	HUB FRONT W/O BEARINGS	TATA spare parts
264133400105	FRONT HUB ASSY BS6	TATA spare parts
264133400106	ASSY. HUB WITH PIN	TATA spare parts
264133400107	FRONTHUBASSYWITHPINS BS6	TATA spare parts
264133400108	SET THRUST PAD (NORMAL)	TATA spare parts
264133400110	FRONTHUBASSY BS6	TATA spare parts
264133403101	TAPER ROLLER BRG 32307	TATA spare parts
264133403102	TAPER ROLLER BRG.	TATA spare parts
264133403103	TAPER ROLLER BRG 32307 BS1/2/3/4	TATA spare parts
264133403104	TAPER ROLLER BRG.	TATA spare parts
264133403105	TAPER ROLLER BEARING	TATA spare parts
264133403109	ASSY THRUST PAD (NORMAL)	TATA spare parts
264133403113	ASSY THRUST PAD-NORMAL(FOR COLD COUNTRY)	TATA spare parts
264133403115	TAPER ROLLER BEARING(CHINA-32307) BS6	TATA spare parts
264133403116	THRUST PAD	TATA spare parts
264133403118	THRUST PAD TEXSPIN (REPAIR-I)	TATA spare parts
264133403119	THRUST PAD TEXSPIN (REPAIR-II)	TATA spare parts
264133403120	THRUST BEARING (NORMAL)	TATA spare parts
264133403122	THRUST BEARING (REPAIR-I)	TATA spare parts
264133403123	THRUST BEARING (REPAIR-II)	TATA spare parts
264133403703	BR DRUM W/HUB W/O BRG FR	TATA spare parts
264133403704	HUB COVER FRONT	TATA spare parts



264133403705	BR DRUM W/HUB W/O BRG FR	TATA spare parts
264133403706	FRONT HUB	TATA spare parts
264133403708	FRONT HUB	TATA spare parts
264133403709	FRONT HUB	TATA spare parts
264133409202	WASHER	TATA spare parts
264133800102	TIE ROD END ȳȳR.H.	TATA spare parts
264133800103	TIE ROD END ȳȳL.H.	TATA spare parts
264133800106	KIT-BALL JOINT RH BS2/3/4	TATA spare parts
264133800107	KIT-BALL JOINT LH BS2/3/4	TATA spare parts
264133800108	TIE ROD END ASSY RH	TATA spare parts
264133800109	TIE ROD END ASSY LH	TATA spare parts
264133805102	TIE ROD ARM L.H.	TATA spare parts
264133805104	STEERING ARM RH	TATA spare parts
264133805105	STEERING ARM LH	TATA spare parts
264133805106	TIE ROD ARM RH	TATA spare parts
264133805107	TIE ROD ARM LH	TATA spare parts
264133805109	TIE ROD ARM LH	TATA spare parts
264133805110	STEERING ARM-RH	TATA spare parts
264133805111	STEERING ARM (LH)	TATA spare parts
264140100103	TUBE	TATA spare parts
264140100110	ASSY WHEEL RIM 6G X 16	TATA spare parts
264140100112	ASSY.WH.RIM&DISC(6.00GX16 123.5O/S)	TATA spare parts
264140100119	ASSY.WH.RIM 123.5 O/S	TATA spare parts
264140100121	ASSY.WHEEL RIM 6GX16 123.5 O/S	TATA spare parts
264140100130	ASSY WHEEL RIM 6G X 16	TATA spare parts
264140106703	HUB PIN REAR S-CAM BS1/2/3/4/6	TATA spare parts
264140106704	HUB PIN FRONT S-CAM	TATA spare parts
264140300102	ASSY.HANDLE	TATA spare parts
264140300104	ASSY.BRACKET	TATA spare parts
264140300105	ASSY.BRKT. SPARE W/MTG.	TATA spare parts
264140300106	SPARE WHEEL CARRIER	TATA spare parts
264140300108	SPARE WHEEL ATTACHMENT SUPPORT ASSEMBLY	TATA spare parts
264140300110	SPARE WHEEL CARRIER LATCH MECHAN ASLY	TATA spare parts
264140300111	ASSY.SPARE WHEEL CARRIER	TATA spare parts
264140300112	ASSY.HANDLE	TATA spare parts
264140306002	SPARE WHEEL CARRIER LOCKING BOLT	TATA spare parts
264140307106	SPARE WHEEL CARRIER LATCH ATTACH. PLATE	TATA spare parts
264140307107	SPARE WHEEL ATTACHMENT PLATE	TATA spare parts
264140308219	REINFORCMENT	TATA spare parts
264141000103	ASSY.KIT FOR END PIECE WITH NUT FRONT	TATA spare parts
264141000108	ASSY.UNITISED PROP.SHAFT	TATA spare parts
264141000114	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
264141000115	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
264141000116	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
264141000117	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
264141000118	ASSY. UNITIZED PROP. SHAFT BS1/2/4	TATA spare parts
264141000119	ASSY. UNITIZED PROP. SHAFT	TATA spare parts

264141000127	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
264141000131	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
264141000132	ASSY.UNITIZED PROP.SHAFT	TATA spare parts
264141000133	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
264141000134	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
264141000135	PROPELLER SHAFT ASSY	TATA spare parts
264141000136	PROPELLER SHAFT ASSY	TATA spare parts
264141000137	PROPELLER SHAFT ASSY UNITISED	TATA spare parts
264141100104	ASSY.UNIVERSAL JOINT LONG FORK	TATA spare parts
264141100105	ASSY.KIT FRT.SHAFT	TATA spare parts
264141100106	PROPELELR SHAFT ASSY MONOTRON	TATA spare parts
264141105101	END PIECE(FRONT)-UNITISED PROP.SHAFT	TATA spare parts
264141105102	UNIVERSAL JOINT LONG FORK	TATA spare parts
264141107701	PACKING RING	TATA spare parts
264141108201	SEAL RETAINER	TATA spare parts
264141109201	SPACER	TATA spare parts
264141110101	PROP SHAFT FR 70X3X661	TATA spare parts
264141110102	ASSY PROP SHAFT FRON	TATA spare parts
264141110105	PROP SHAFT FR W/CEN BRG	TATA spare parts
264141110113	FRONT TEETH 709/1210	TATA spare parts
264141110115	ASSY.PROP.SHAFT FRONT	TATA spare parts
264141110116	ASSY.PROP.SHAFT WITH CENTRE BEARING	TATA spare parts
264141110119	ASSY.PROP.SHAFT FRONT WITH CENTER BRG.	TATA spare parts
264141110122	CENTER BEARING KIT	TATA spare parts
264141110123	SPLIT YOKE ASSY.	TATA spare parts
264141110124	CENTER BRG.& RETAINER	TATA spare parts
264141110125	FRONT PROP SHAFT	TATA spare parts
264141110153	UNIVERSAL JOINT ASSY BS6	TATA spare parts
264141110156	KIT-UNIVERSAL JOINT BS6-PH2	TATA spare parts
264141115101	FLANGE YOKE	TATA spare parts
264141115102	U.J.KIT	TATA spare parts
264141117501	CENTER BRG.RUBBER	TATA spare parts
264141118201	DUST CAP	TATA spare parts
264141118202	CENTER BRG.BRACKET	TATA spare parts
264141118203	SLINGER	TATA spare parts
264141118204	SLINGER	TATA spare parts
264141119201	SPLIT WASHER	TATA spare parts
264141119901	CORK WASHER	TATA spare parts
264141119902	ZERK	TATA spare parts
264141120103	APSC REAR 509 31WB 661	TATA spare parts
264141120107	ASSY. PROP. SHAFT REAR BS1/2/3/4	TATA spare parts
264141120141	REAR PROP SHAFT	TATA spare parts
264141125102	KIT-UNIVERSAL JOINT 1550 BS1/2/3/4	TATA spare parts
264141125102DF	UJ CROSS 30.18X106 - 709/909	TATA spare parts
264141125103	STUB YOKE	TATA spare parts
264141125104	FLANGE YOKE	TATA spare parts
264141125105	SLEEVE YOKE	TATA spare parts

264141125106	STUB YOKE	TATA spare parts
264141300102	ASSY.CENTER BEARING COMPLETE	TATA spare parts
264141300103	ASSY.GUARD	TATA spare parts
264141300105	KIT-CENTRE BEARING BS1/2/3/4	TATA spare parts
264141300106	CENTRE BEARING KIT BS6	TATA spare parts
264141303101	SRDG BALL BEARING	TATA spare parts
264141306901	BEARING PLUG SHAFT	TATA spare parts
264141306902	FLINGER	TATA spare parts
264141307501	RUBBER SEAL	TATA spare parts
264141308202	REINF.CNTRE.BRG	TATA spare parts
264141308207	DUST COVER SHIELD	TATA spare parts
264141308208	DUST CAP	TATA spare parts
264141309201	STEEL WASHER	TATA spare parts
264142100106	FRT AXLE BRAKE LH NASBS	TATA spare parts
264142100108	FRT AXLE BRAKE RH NASBS	TATA spare parts
264142100109	FRT AXLE BRAKE RH NASBS	TATA spare parts
264142100110	FRT AXLE BRAKE LH NASBS	TATA spare parts
264142100118	ASSY.BRAKE SHOE WITH NON ASBESTOS LINING	TATA spare parts
264142100132	SLACK ADJUSTER-AUTO	TATA spare parts
264142100134	ASSY FRT BRAKE RH	TATA spare parts
264142100136	ASSY FRONT BRAKE LH SCAM	TATA spare parts
264142100138	FRONT BRAKE CHAMBER ( LH / RH COMMON ) T	TATA spare parts
264142100139	SLACK ADJUSTER	TATA spare parts
264142100140	SLACK ADJ MANU	TATA spare parts
264142100146	SLACK ADJUSTER-AUTO	TATA spare parts
264142100147	FRONT BRAKE CHAMBER	TATA spare parts
264142100148	FRONT BRAKE CHAMBER	TATA spare parts
264142100158	ASSY. TYPE 9 BRAKE CHAMBER	TATA spare parts
264142100159	FRONT BRAKE CHAMBER	TATA spare parts
264142100160	SLACK ADJUSTER-MECHA	TATA spare parts
264142100162	FRT BRAKE CHAMBER	TATA spare parts
264142100166	REPAIR KIT FR BR CHA	TATA spare parts
264142100168	WORM SHAFT REPAIR KIT	TATA spare parts
264142100169	MAJOR REPAIR KIT	TATA spare parts
264142100170	CHAMBER MTG. BRKT LH SCAM	TATA spare parts
264142100171	CHAMBER MTG. BRKT RH SCAM	TATA spare parts
264142100172	BRAKE SHOE FRT/RR STD	TATA spare parts
264142100173	KIT BR LINING STD	TATA spare parts
264142100174	BRAKE SHOE FRT/RR R/S I	TATA spare parts
264142100175	KIT BR LINING STD1	TATA spare parts
264142100176	BRAKE SHOE FRT/RR R/S II	TATA spare parts
264142100177	KIT BR LINING RS2	TATA spare parts
264142100201	ASLY.BRK.325X120 W-GROMMET & DUSTCOVER-	TATA spare parts
264142100202	ASLY.BRK.325X120 W-GROMMET & DUSTCOVER-	TATA spare parts
264142100203	LINED SHOE ASSY 325X120	TATA spare parts
264142100222	DUST SHIELD ASSY (BOTTOM)	TATA spare parts
264142100223	DUST SHIELD ASSY-BOTTOM	TATA spare parts

264142100224	DUST SHIELD ASSY-TOP	TATA spare parts
264142100225	DUST SHIELD ASSY (TOP)	TATA spare parts
264142100226	TUBE FLANGE AND BRACKET LH	TATA spare parts
264142100227	TUBE FLANGE AND BRACKET RH	TATA spare parts
264142103201	COLLARED PIN	TATA spare parts
264142103202	PIN	TATA spare parts
264142103206	HEX. BOLT (STG. ARM REAR SIDE)	TATA spare parts
264142103207	HEX. BOLT (W/O STG. ARM SIDE)	TATA spare parts
264142103208	HEX. BOLT (STG. ARM FRONT SIDE)	TATA spare parts
264142103210	COLLARED PIN M16X1.5X107.5 IS1367-SS 940	TATA spare parts
264142103211	COLLARED PIN	TATA spare parts
264142103403	CAM BUSH	TATA spare parts
264142103404	BUSH	TATA spare parts
264142103405	FULCRUM PIN BUSH	TATA spare parts
264142103407	BUSH REAR BRAKE CHAMBER MTG BKT	TATA spare parts
264142103701	REAR BRAKE DRUM EURO1	TATA spare parts
264142103704	SPIDER FRONT LH	TATA spare parts
264142103705	SPIDER FRONT RH	TATA spare parts
264142103707	BRAKE DRUM FRONT / REAR	TATA spare parts
264142103708	BRAKE DRUM	TATA spare parts
264142103709	BRAKE DRUM CASTILATED BS1/2/3/4	TATA spare parts
264142104301	CIRCLIP	TATA spare parts
264142105104	CAM SHAFT FRT LH	TATA spare parts
264142105105	CAM SHAFT FRT RH	TATA spare parts
264142105106	CAM SHAFT LH	TATA spare parts
264142105107	CAM SHAFT RH	TATA spare parts
264142106322	KIT-BRAKE LINER SET STD (410 X 180) BS6	TATA spare parts
264142106323	KIT-BRAKE LINER O/S 1 (410 X 180) BS6	TATA spare parts
264142106324	KIT-BRAKE LINER O/S 2 (410 X 180) BS6	TATA spare parts
264142106704	FULCRUM PIN	TATA spare parts
264142107702	DIAPHRAGM FRONT	TATA spare parts
264142107703	OIL SEAL FRONT/REAR	TATA spare parts
264142107704	ADAPTER	TATA spare parts
264142108212	DUST COVER TOP	TATA spare parts
264142108213	DUST COVER BOTTOM	TATA spare parts
264142108301	SHIM	TATA spare parts
264142108302	SHIM	TATA spare parts
264142108303	SHIM	TATA spare parts
264142108304	SHIM 0.50 MM SCAM BS4	TATA spare parts
264142108305	SHIM 0.30 MM SCAM BS4	TATA spare parts
264142108306	SHIM 1.00 MM SCAM	TATA spare parts
264142108601	SPACER	TATA spare parts
264142108602	SLEEVE DELRIN	TATA spare parts
264142108703	SPRING BRAKE CHAMBER FRONT	TATA spare parts
264142108705	SPRING PULL OFF BS1/2/3/4	TATA spare parts
264142108706	SPRING FULCRUM END	TATA spare parts
264142109906	ROLLER	TATA spare parts

264142109910	BR LNG KIT STD (325X120) 709	TATA spare parts
264142109911	BR LNG KIT RS 1 (325X120) 709	TATA spare parts
264142109912	BR LNG KIT RS 2 (325X120) 709	TATA spare parts
264142109913	BR LNG KIT STD (325X140) 909	TATA spare parts
264142109914	BR LNG KIT RS 1 (325X140) 909	TATA spare parts
264142109915	BR LNG KIT RS 2 (325X140) 909	TATA spare parts
264142110101	ANCHOR PLATE RH FRONT	TATA spare parts
264142110102	ANCHOR PLATE LH FRONT	TATA spare parts
264142110109	ASSY.FRONT SLACK ADJUSTER	TATA spare parts
264142110110	ASSY.FRONT SLACK ADJUSTER	TATA spare parts
264142110126	ASSY FA BRK LH WITH DUST COVER & MTG.	TATA spare parts
264142110127	ASSY FA BRK RH WITH DUST COVER & MTG.	TATA spare parts
264142110136	ASSY. BRAKE SHOE WITH LINER	TATA spare parts
264142110140	ASSY.FRONT SLACK ADJUSTER	TATA spare parts
264142110164	ASSY. SLACK ADJ. STRAIGHT BS1/2/3/4/6	TATA spare parts
264142110169	ASSY. LINED SHOE N/ABS LINING BS2/3/4	TATA spare parts
264142110177	ASSY.F/A BRK.RH WITH DC N/ASB	TATA spare parts
264142110179	ASSY.F/A BRK.LH WITH DC N/ASB	TATA spare parts
264142110185	ASSY F/A BRAKE RH WITH DUST COVER-ASB	TATA spare parts
264142110188	ASSY F/A BRAKE LH WITH DUST COVER-ASB	TATA spare parts
264142110198	AUTO.SLACK ADJ. (STRAIGHT-140)	TATA spare parts
264142110199	AUTOMIC SLACK ADJUSTER ASSEMBLY FRONT	TATA spare parts
264142120102	25.4 DIA WHEEL CYLINDER	TATA spare parts
264142120103	25.4 DIA. WHEEL CYL. ASSY	TATA spare parts
264142120104	REP KIT W/CYL 25.4DIA	TATA spare parts
264142120105	LINING KIT (STD)	TATA spare parts
264142120106	LINING KIT (R/S I)	TATA spare parts
264142120107	LINING KIT (R/S II)	TATA spare parts
264142126601	PISTON	TATA spare parts
264142300111	R/AXLE BRAKE LH NASBS LPT	TATA spare parts
264142300112	R/AXLE BRAKE RH NASBS LPT	TATA spare parts
264142300115	ASSY.REAR AXLE BRAKE LH BUS-N/ASBS	TATA spare parts
264142300116	ASSY.REAR AXLE BRAKE RH BUS-N/ASBS	TATA spare parts
264142300127	R/AXLE BRAKE LH NASBS LPT	TATA spare parts
264142300128	R/AXLE BRAKE RH NASBS LPT	TATA spare parts
264142300129	REPAIR KIT-S.BRA.ACTUATOR	TATA spare parts
264142300129AE	REPAIR KIT REAR 715	TATA spare parts
264142300130	ASSY REAR BRAKE CHAMBER	TATA spare parts
264142300144	ASSY BRKT RH RR CHAMB MTG	TATA spare parts
264142300145	ASSY BRKT LH RR CHAMB MTG	TATA spare parts
264142300147	ASSY PLUMBER BLOCK	TATA spare parts
264142300154	AUTO. SLACK ADJUSTER RH BS1/2/3/4/6	TATA spare parts
264142300155	AUTO. SLACK ADJUSTER LH BS1/2/3/4/6	TATA spare parts
264142300157	ASSY BRAKE REAR RH	TATA spare parts
264142300159	ASSY BRAKE REAR LH	TATA spare parts
264142300162	SLACK ADJUSTER L.H.	TATA spare parts
264142300163	SLACK ADJUSTER R.H.	TATA spare parts

264142300164	SLACK ADJ REAR RH MANU	TATA spare parts
264142300165	SLACK ADJ REAR LH MANU	TATA spare parts
264142300172	SPRING BRAKE CHAMBER BS2	TATA spare parts
264142300173	ASSY REAR BRAKE CHAMBER	TATA spare parts
264142300174	AUTOMATIC SLACK ADJUSTER-LH	TATA spare parts
264142300175	AUTOMATIC SLACK ADJUSTER-RH	TATA spare parts
264142300183	SLACK ADJUSTER RH	TATA spare parts
264142300184	SLACK ADJUSTER LH	TATA spare parts
264142300185	PUSH ROD ASSY	TATA spare parts
264142300187	SPRING BRAKE CHAMBER	TATA spare parts
264142300189	REPAIR KIT RR BR. AC	TATA spare parts
264142300191	ASSY CAM SHAFT BRACKET	TATA spare parts
264142300192	ASSY.BRACKET RH (FOR REAR CHAMBER MTG	TATA spare parts
264142300193	ASSY.BRACKET LH (FOR REAR CHAMBER MTG	TATA spare parts
264142300194	ASSY.REAR SLACK ADJUSTER LH	TATA spare parts
264142300195	ASSY.REAR SLACK ADJUSTER RH	TATA spare parts
264142300196	ASSY.REAR SLACK ADJUSTER LH	TATA spare parts
264142300197	ASSY.REAR SLACK ADJUSTER RH	TATA spare parts
264142300198	ASSY. REAR BRAKE LH	TATA spare parts
264142300199	ASSY. REAR BRAKE RH	TATA spare parts
264142300201	LINED SHOE ASSEMBLY 325X120	TATA spare parts
264142300217	AUTO SLACK ADJUSTER -CONTROL UNIT	TATA spare parts
264142303704	SPIDER REAR LH/RH SCAM	TATA spare parts
264142303707	TORQUE PLATE LH	TATA spare parts
264142303708	TORQUE PLATE RH	TATA spare parts
264142305106	CAM SHAFT REAR LH	TATA spare parts
264142305107	CAM SHAFT REAR RH	TATA spare parts
264142307702	DIAPHRAGM	TATA spare parts
264142308001	SCREW-HEX HEAD	TATA spare parts
264142308002	HEX. SCREW	TATA spare parts
264142308210	DUST COVER TOP	TATA spare parts
264142308211	DUST COVER REAR-BOTTOM	TATA spare parts
264142308601	SPACER	TATA spare parts
264142308603	SPACER CAMCHAFT SCAM	TATA spare parts
264142308701	SPRING BRAKE CHAMBER REAR	TATA spare parts
264142310103	ASSY.R/A BRAKE LH (ASBS)	TATA spare parts
264142310104	ASSY.R/A BRAKE RH (ASBS)	TATA spare parts
264142310109	ASSY.REAR SLACK ADJUSTER RH	TATA spare parts
264142310110	ASSY.REAR SLACK ADJUSTER LH	TATA spare parts
264142310111	SPRING BRAKE CHAMBER	TATA spare parts
264142310120	ASSY.SLACK ADJUSTER LH16MM OFFSET	TATA spare parts
264142310121	ASSY.SLACK ADJUSTER RH16MM OFFSET	TATA spare parts
264142310126	ASSY. BRAKE CHAMBER MOUNTING BRACKET RH	TATA spare parts
264142310130	ASSY.BRACKET LH (FOR REAR CHAMBER MTG.)	TATA spare parts
264142310135	ASSY.R/A BRK.RH WITH DC N/ASB	TATA spare parts
264142310137	ASSY.R/A BRK.LH WITH DC N/ASB	TATA spare parts
264142310165	AUTIMATIC SLACK ADJUSTER REAR RH	TATA spare parts

264142310166	AUTIMATIC SLACK ADJUSTER REAR LH	TATA spare parts
264142405805	HOSE	TATA spare parts
264142406001	LEVER	TATA spare parts
264142700101	ASSEMBLY CABLE (REAR)	TATA spare parts
264142700118	ASSEMBLY CABLE-REAR	TATA spare parts
264142700138	HAND BR CABLE RR	TATA spare parts
264142700139	ASSY.PARKING BRAKE CABLE REAR	TATA spare parts
264142700140	ASSY CABLE MIDDLE	TATA spare parts
264142700141	BRACKET PULLEY MTG	TATA spare parts
264142700147	PARKING BRAKE UNIT RHD	TATA spare parts
264142700159	CABLE (CENTRE) 38 WB 709	TATA spare parts
264142700160	ASSY.CABLE (CENTRE).34WB TRUCK.	TATA spare parts
264142700162	ASSY BRACKET	TATA spare parts
264142700164	ASSY CABLE FRONT	TATA spare parts
264142700165	ASSY.CABLE FRONT-TRUCK	TATA spare parts
264142700166	HAND BR CABLE FRT	TATA spare parts
264142700167	ASSY.PARKING BRAKE CABLE FRONT	TATA spare parts
264142700168	CABLE ASSY.CENTRE 38 WB BUS	TATA spare parts
264142700170	CABLE ASSY.CENTRE 38 WB TRUCK	TATA spare parts
264142700171	HAND BR CABLE CEN LPT/34	TATA spare parts
264142700174	ASSEMBLY GUIDE TUBE	TATA spare parts
264142700177	PARKING BRAKE CABLE FRONT	TATA spare parts
264142700180	HAND BR CABLE RR	TATA spare parts
264142700182	PARKING BRAKE CABLE-REAR	TATA spare parts
264142700184	ASSY. CABLE CENTER	TATA spare parts
264142700186	ASSY. CABLE CENTER	TATA spare parts
264142703301	BRACKET BS6	TATA spare parts
264142706704	PIN	TATA spare parts
264142708601	SPACER	TATA spare parts
264142708603	SPACER. SPRG.	TATA spare parts
264142708604	SPACER	TATA spare parts
264142708701	TORSION SPRING	TATA spare parts
264142708702	TORSION SPRING	TATA spare parts
264142800102	ASSY.HYD.LINES & CLAMPS 38 WB-TRUCK	TATA spare parts
264142800114	ASSY TUBE 709	TATA spare parts
264142800115	ASSY TUBE	TATA spare parts
264142800118	ASSY.TUBE	TATA spare parts
264142800119	ASSY.TUBE	TATA spare parts
264142800120	TUBE ASSY	TATA spare parts
264142800121	TUBE ASSY	TATA spare parts
264142800129	TUBE ASSY	TATA spare parts
264142800132	TUBE ASSY	TATA spare parts
264142800135	TUBE ASSY	TATA spare parts
264142800138	ASSY.TUBE	TATA spare parts
264142800139	ASSY.TUBE	TATA spare parts
264142800140	ASSY.TUBE	TATA spare parts
264142800141	TUBE ASSY	TATA spare parts

264142800142	TUBE ASSY	TATA spare parts
264142800144	TUBE ASSY	TATA spare parts
264142800145	TUBE ASSY	TATA spare parts
264142800146	TUBE ASSY	TATA spare parts
264142800147	ASSY.TUBE	TATA spare parts
264142800148	TUBE ASSY	TATA spare parts
264142800149	TUBE ASSY	TATA spare parts
264142800150	ASSY.TUBE	TATA spare parts
264142800151	TUBE ASSY	TATA spare parts
264142800156	TUBE ASSY	TATA spare parts
264142800157	TUBE ASSY	TATA spare parts
264142800172	ASSY.TUBE	TATA spare parts
264142800178	TUBE ASSY	TATA spare parts
264142800179	TUBE ASSY	TATA spare parts
264142800180	TUBE ASSY	TATA spare parts
264142800181	TUBE ASSY	TATA spare parts
264142800182	TUBE ASSY	TATA spare parts
264142800183	TUBE ASSY	TATA spare parts
264142800184	TUBE ASSY	TATA spare parts
264142800185	TUBE ASSY	TATA spare parts
264142800191	ASSY TUBE	TATA spare parts
264142800194	ASSY PIPE	TATA spare parts
264142800197	TUBE ASSY	TATA spare parts
264142800198	TUBE ASSY	TATA spare parts
264142803303	BKT FRT BRAKE HOSE	TATA spare parts
264142803304	BRACKET (FRONT BRAKE HOSE MTG.)	TATA spare parts
264142805803	RUBBER HOSE	TATA spare parts
264142805804	RUBBER HOSE	TATA spare parts
264142805805	RUBBER HOSE	TATA spare parts
264142805807	RUBBER HOSE	TATA spare parts
264142806801	ADAPTER	TATA spare parts
264142806802	ADAPTOR	TATA spare parts
264142806803	ADAPTOR (TUBE TO TUBE)	TATA spare parts
264142807701	HOSE	TATA spare parts
264142808201	BRACKET	TATA spare parts
264142808209	BRACKET	TATA spare parts
264142808214	BRACKET BS6	TATA spare parts
264142808215	MTG BKT CL/BR PIPE LINE	TATA spare parts
264142808218	BRACKET	TATA spare parts
264142808219	BRACKET	TATA spare parts
264142810101	TUBE RH FRONT BRAKE	TATA spare parts
264142810102	TUBE LH FRONT BRAKE	TATA spare parts
264142810103	TUBE ASSY	TATA spare parts
264142810104	TUBE ASSY	TATA spare parts
264142810131	ASSY.TUBE	TATA spare parts
264142810132	ASSY.TUBE	TATA spare parts
264142810133	ASSY TUBE FRONT	TATA spare parts



264142810137	ASSY TUBE REAR	TATA spare parts
264142900101	TUBE ASSY	TATA spare parts
264142900102	HOSE ASSY	TATA spare parts
264142900103	HOSE ASSY	TATA spare parts
264142900104	HOSE ASSEMBLY	TATA spare parts
264142900151	ASSY TUBE	TATA spare parts
264142900152	ASSY TUBE	TATA spare parts
264142900153	ASSY TUBE	TATA spare parts
264142900154	ASSY TUBE	TATA spare parts
264142900155	ASSY TUBE	TATA spare parts
264142900156	ASSY TUBE	TATA spare parts
264142900157	ASSY TUBE-TEE TO FRONT BRK CHAMBER LH	TATA spare parts
264142900158	ASSY TUBE	TATA spare parts
264142900159	ASSY TUBE	TATA spare parts
264142900162	ASSY TUBE	TATA spare parts
264142900163	ASSY TUBE	TATA spare parts
264142900165	ASSY TUBE	TATA spare parts
264142900166	ASSY TUBE	TATA spare parts
264142900169	ASSY TUBE	TATA spare parts
264142900170	ASSY TUBE 709 S-CAM	TATA spare parts
264142900172	ASSY CLAMP	TATA spare parts
264142900173	ASSY NYLON PIPE SET	TATA spare parts
264142900175	ASSY TUBE	TATA spare parts
264142900176	ASSY TUBE	TATA spare parts
264142900177	ASSY TUBE	TATA spare parts
264142900178	ASSY.TUBE	TATA spare parts
264142900179	ASSY TUBE	TATA spare parts
264142900181	ASSY TUBE	TATA spare parts
264142900182	ASSY TUBE	TATA spare parts
264142900185	ASSY.BRACKET-RH(RR HOSE MTG)	TATA spare parts
264142900186	ASSY.BRACKET (FRONT BRAKE HOSE MTG.)	TATA spare parts
264142900187	ASSY BRACKET-LH	TATA spare parts
264142900194	ASSY.NYLON PIPE SET FOR LP 709/38 LHD	TATA spare parts
264142900199	ASSY.BRACKET	TATA spare parts
264142903302	BRACKET	TATA spare parts
264142904202	DOUBLE CLAMP (12 X 12)	TATA spare parts
264142904204	ASSY CLAMP	TATA spare parts
264142904207	CLAMP	TATA spare parts
264142906503	HEXAGONAL NUT	TATA spare parts
264142906803	COUPLING BODY M20 X M22	TATA spare parts
264142908207	BRACKET	TATA spare parts
264142908208	ASSY TUBE	TATA spare parts
264142910104	ASSY.TUBE S.P.VALVE TO EXT.BRK.CYL.	TATA spare parts
264142910107	ASSY.TUBE	TATA spare parts
264142910108	ASSY NYLON PIPES - CAB	TATA spare parts
264142910109	ASSY NYLON PIPES-CHASSIS PIPES	TATA spare parts
264142910124	ASSY.PIPE COUPLING NUT TO EBV	TATA spare parts

264142910129	ASSY NYLON PIPES-CHASSIS PIPES	TATA spare parts
264142990102	LINED SHOE FRONT	TATA spare parts
264142990105	KIT-BRAKE AGGR	TATA spare parts
264142990106	KIT-BRAKE LINE SHOE ASSY BS6	TATA spare parts
264142990107	KIT-BRAKE	TATA spare parts
264142990117	MAJOR KIT-AUTO ADJUSTER ASSY BS6	TATA spare parts
264142990118	BRAKE LINING KIT(OS2)410X180 AF6262N BS6	TATA spare parts
264142990119	BRAKE LINING KIT(OS1)410X180 AF6262N BS6	TATA spare parts
264142990120	BRAKE LINING KIT(STD)410X180 AF6262N BS6	TATA spare parts
264142990125	KIT-BRAKE AGGR	TATA spare parts
264142990126	KIT-BRAKE AGGR	TATA spare parts
264142990133	KIT-BRAKE BS6	TATA spare parts
264142990134	KIT LINED SHOE ASSY	TATA spare parts
264142990135	BRAKE ASSY MAJOR KIT OF TYPE V LH	TATA spare parts
264142990136	BRAKE ASSY MAJOR KIT OF TYPE V RH	TATA spare parts
264142990137	AUTO SLACK ADJUSTER -MAJOR SPARE KIT	TATA spare parts
264142990140	BRAKE ASSY MAJOR KIT OF TYPE IV LH	TATA spare parts
264142990141	BRAKE ASSY MAJOR KIT OF TYPE IV RH	TATA spare parts
264142990150	BRAKE ASSY KIT BUSH(FOR B C)	TATA spare parts
264142990178	CAMSHAFT LH	TATA spare parts
264142990179	CAMSHAFT RH	TATA spare parts
264142990205	AUTO SLACK ADJUSTER -MAJOR KIT (16MM)	TATA spare parts
264142990208	COVERPLATEASSY	TATA spare parts
264142990209	KIT-AUTO SLACK ADJUSTER	TATA spare parts
264143100103	23.81 DIA.TANDEM MASTER CYL.	TATA spare parts
264143100104	TANDEM MASTER CYL	TATA spare parts
264143100108	23.81 DIA.TANDEM MASTER CYL.	TATA spare parts
264143100109	TANDEM MASTER CYLINDER LP 407 TWIN TYRE	TATA spare parts
264143100110	MAST CYL ASSLY 609 LHD	TATA spare parts
264143100112	BRAKE FLUID CONTAINER	TATA spare parts
264143100113	TANDEM MASTER CYL	TATA spare parts
264143100114	TANDEM MASTER CYL 25.40D	TATA spare parts
264143100115	TANDEM MASTER CYL 25.40D	TATA spare parts
264143100116	TANDEM MASTER CYL 25.40D	TATA spare parts
264143100117	TANDEM MASTER CYL 25.40D	TATA spare parts
264143100118	ASSY.TANDEM M/CYLD.25.4 DIA.	TATA spare parts
264143100119	ASSY.TANDEM M/CYLD.25.4 DIA.	TATA spare parts
264143100120	ASSY. WHEEL CYLINDER 23.81 DIA.	TATA spare parts
264143100121	KIT REP MAJOR TMC 25.40D	TATA spare parts
264143100122	KIT REP MINOR TMC 25.40D	TATA spare parts
264143100123	KIT REP MAJOR TMC 25.40D	TATA spare parts
264143100124	KIT REP MINOR TMC 25.40D	TATA spare parts
264143100129	BRAKE FLUID RESERVOIR	TATA spare parts
264143100130	BRAKE FLUID RESERVOIR	TATA spare parts
264143106801	PIPE UNION BOLT	TATA spare parts
264143108203	PLATE	TATA spare parts
264143108204	PLATE	TATA spare parts

264143200113	ASSY. SUPPORT	TATA spare parts
264143200114	AIR TANK ASSY	TATA spare parts
264143200117	SUB ASSY AIR TANKS-110 STRAP CENTRE DIST	TATA spare parts
264143200118	ASSY BRKT LH AIR DRYER MTG	TATA spare parts
264143200119	ASSY.BRACKET RH	TATA spare parts
264143200121	ASSY.AIR TANK-WITH LAPPED JOINTS	TATA spare parts
264143200133	ASSY AIR TANK 15 LTR	TATA spare parts
264143200134	ASSY AIR TANK RHD (15LITRES)	TATA spare parts
264143200135	ASSY AIRTANK (LHD-15LTRS-110 PITCH) VOSS	TATA spare parts
264143200136	ASSY AIRTANK (RHD-15LTRS-110 PITCH) VOSS	TATA spare parts
264143400101	ASSEMBLY BRACKET	TATA spare parts
264143400102	ASSY.BRACKET	TATA spare parts
264143500104	BKT VAC TANK MTG	TATA spare parts
264143500108	VACUUM BRAKE CYLINDER.	TATA spare parts
264143500109	VACUUM BRAKE CYLINDER.	TATA spare parts
264143700101	DUAL BRAKE VALVE-SFC 709-TELCO OFFER	TATA spare parts
264143700102	ASSY. DUAL BRAKE VALVE BS1/2/3/4	TATA spare parts
264143700102AE	DUAL BRAKE VALVE 713	TATA spare parts
264143700105	ASSY. AIR DRIER BS1/2/3	TATA spare parts
264143700105AE	AIR DRIER WITH UNLOAD VALVE -713	TATA spare parts
264143700106	AIR DRIER	TATA spare parts
264143700108	PURGE TANK	TATA spare parts
264143700109	DUAL BRAKE VALVE	TATA spare parts
264143700110	ASSY DUAL BRAKE VALVE	TATA spare parts
264143700111	REPAIR KIT	TATA spare parts
264143700112	PLUNGER ASSY	TATA spare parts
264143700113	DIAPHRAGM ASSY. CONSISTS OF:	TATA spare parts
264143700115	REPAIR KIT FOR PART 264143700110	TATA spare parts
264143700116	MSP 25/3 REPAIR KIT	TATA spare parts
264143700117	BALL SOCKET JOINT ASSY.(SCL NO.M260050)	TATA spare parts
264143700118	ASSY DUAL BRAKE VALVE	TATA spare parts
264143700119	DUAL BRAKE VALVE W/ FILTER	TATA spare parts
264143700120	DRYING AND DISTRIBUTION UNIT	TATA spare parts
264143700123	MAJOR REPAIR KIT-AIR DRYER BS1/2/3/4	TATA spare parts
264143700124	MINOR REP KIT A/DRYER	TATA spare parts
264143700125	REP KIT BRK.CHAMBER	TATA spare parts
264143700126	REPAIR KIT-DUAL BRAKE VALVE BS1/2/3/4	TATA spare parts
264143700126AE	REPAIR KIT DBV 715	TATA spare parts
264143700127	REPAIR KIT-DDU BS1/2/3/4	TATA spare parts
264143700135	AUTOMATIC LOAD SENSING VALVE	TATA spare parts
264143700141	QUADR.SYS. PROT. VALVE (HI PR)	TATA spare parts
264143700147	DUAL BRAKE VAVLE VOSS BS1/2/3/4	TATA spare parts
264143700147AE	DUAL BRAKE VALVE 715	TATA spare parts
264143700148	DUAL BRAKE VAVLE VOSS	TATA spare parts
264143700159	REPAIR KIT-DUAL BRAKE VALVE BS2/3/4	TATA spare parts
264143700160	SPRING BRAKE ACTUATOR TYP 9/9 VOSS	TATA spare parts
264143700163	DDU HI PR VOSS PORT TYRE INFLECTOR 120MM	TATA spare parts

264143700163AE	DDU 1415 715	TATA spare parts
264143700164	KIT-DUAL BRAKE VALVE	TATA spare parts
264143700165	KIT-DUAL BRAKE VALVE	TATA spare parts
264143700166	KIT-DUAL BRAKE VALVE	TATA spare parts
264143703701	BODY	TATA spare parts
264143703702	TOP COVER	TATA spare parts
264143706701	TYRE INFLATOR PLUNGER	TATA spare parts
264143708001	HEXAGONAL SCREW	TATA spare parts
264143708002	PAN HEAD SCREW	TATA spare parts
264143708003	HEX. HEAD SCREW	TATA spare parts
264143708004	ADJUSTMENT SCREW	TATA spare parts
264143708201	HOUSING	TATA spare parts
264143708202	STIFFNER PLATE	TATA spare parts
264143708203	SPRING RETAINER	TATA spare parts
264143708204	CUP	TATA spare parts
264143708501	ADAPTOR	TATA spare parts
264143708701	SPRING	TATA spare parts
264143708702	TYRE INFLATOR SPRING	TATA spare parts
264143708703	COMPRESSION SPRING	TATA spare parts
264143709202	STEEL WASHER	TATA spare parts
264143709901	FILTER RETAINER	TATA spare parts
264143709902	SILENCER	TATA spare parts
264143709903	SPRING GUIDE.	TATA spare parts
264143709905	DESICCANT CARTRIDGE	TATA spare parts
264143709920	MINOR KIT DDU	TATA spare parts
264143709922	MAJOR KIT DDU	TATA spare parts
264143900103	ASSY.NYLON PIPE SET FOR CHASSIS	TATA spare parts
264143900115	ASSY.NYLON PIPE SET FOR CHASSIS-38 WB.	TATA spare parts
264143900119	ASSY. TUBE	TATA spare parts
264143900126	ASSY.NY PIPE SET CHASSIS COMPL-LPT712/34	TATA spare parts
264143900140	ASSY.NY PIPE SET CHASSIS COMPL-LPT712/38	TATA spare parts
264143900144	ASSY.PIPE-SECOND PIPE FROM COMPR. TO DDU	TATA spare parts
264143900145	ASSY.PIPE-THIRD PIPE FROM COMPR. TO DDU	TATA spare parts
264143900148	ASSY.NYLON PIPE SET CHASSIS COMPL-709/34	TATA spare parts
264143900165	ASSY. PIPE SECOND FROM AC TO DDU	TATA spare parts
264143900188	PIPE ASSY BUNCH COMPLETE	TATA spare parts
264143910112	ASSY METAL PIPE DIA 15 COMP TO DDU 42WB	TATA spare parts
264143910113	ASSY NYLON PIPE SET CHASSIS COMPL	TATA spare parts
264143910127	ASSY NYLON PIPE SET CLUTH/EX BRAKE RETRO	TATA spare parts
264143910129	ASSY NYLON PIPE SET CHASSIS COMP	TATA spare parts
264143910133	ASSY NYLON PIPE SET CHASSIS COMPLETE	TATA spare parts
264143910137	ASSY NYLON PIPE CHASSIS COMPL LPT 709 EX	TATA spare parts
264143910142	ASSY NYLON PIPE SET CHASSIS COMP LPT 709	TATA spare parts
264143910146	ASSY NYLON PIPE SET CHASSIS COMPL LP709	TATA spare parts
264143910161	ASSY METAL PIPE DIA15 (FROM COMP TO DDU)	TATA spare parts
264143910183	ASSY NYLON PIPE CHASSIS SET COMPL	TATA spare parts
264143910188	ASSY NYLON PIPE CHASSIS BUNCH COMPL LPT	TATA spare parts

264143920148	PIPE ASSY BUNCH FOR CHASSIS	TATA spare parts
264143990101	REPAIR KIT AIR DRYER	TATA spare parts
264144800103	HYD TANK P/STRG	TATA spare parts
264146000101	STRG GEAR BOX RHD	TATA spare parts
264146000111	KIT FOR STRG. RHD	TATA spare parts
264146000112	KIT FOR STRG.	TATA spare parts
264146106301	RUBBER BELLOW FLOOR	TATA spare parts
264146106302	RUBBER BELOW	TATA spare parts
264146108201	CLAMPING RING	TATA spare parts
264146200102	ASSY STRG.COLUMN	TATA spare parts
264146200115	BKT STRG G/BOX MTG	TATA spare parts
264146200121	STRG SPINDLE TOP	TATA spare parts
264146200122	ASSY SLEEVE	TATA spare parts
264146200146	STRG SPINDLE MIDDLE	TATA spare parts
264146200147	BKT STRG G/BOX MTG RHD	TATA spare parts
264146200179	ASSY STG G.B. MTG. BRKT	TATA spare parts
264146200180	BKT STRG G/BOX LHD	TATA spare parts
264146200181	ASSY. STEERING GEAR BOX BS2/3/4	TATA spare parts
264146200182	ASSY. STEERING GEAR BOX LHD BS1/3	TATA spare parts
264146200184	ASSY STG G.B WITH PIT ARM UJ & BKT-RHD	TATA spare parts
264146200189	STRG SPINDLE TOP	TATA spare parts
264146200190	ASSY BRACKET	TATA spare parts
264146200191	ASSY BRACKET	TATA spare parts
264146200192	ASSY COLUMN WITH SPINDLE W/O STEERING WH	TATA spare parts
264146200195	ASSY.STG.GEAR BOX MTG.BKT-RHD	TATA spare parts
264146203802	STRG COLUMN LP609	TATA spare parts
264146206301	RUBBER BELLOW	TATA spare parts
264146207901	STRG SPINDLE BOTTOM	TATA spare parts
264146207908	STRG SPINDLE TOP	TATA spare parts
264146207913	STRG SPINDLE BOTTOM	TATA spare parts
264146207914	STRG SPINDLE MIDDLE	TATA spare parts
264146207920	SPACER	TATA spare parts
264146207930	STRG SPINDLE BOTTOM	TATA spare parts
264146208230	BRACKET	TATA spare parts
264146210108	ASSY.COVER	TATA spare parts
264146210120	ASSY STG. SPINDLE	TATA spare parts
264146210121	ASSY. POWER STRG GEAR BOX-RH BS2/3/4	TATA spare parts
264146210124	ASSY. SPINDLE(LP709/613 LHD)	TATA spare parts
264146210136	REPAIR KIT MAJOR FOR PR GEAR BOX LCV	TATA spare parts
264146210137	REPAIR KIT MINOR FOR PS GEAR BOX LCV	TATA spare parts
264146210138	HOUSING ASSEMBLY PS GEAR BOX LCV	TATA spare parts
264146210139	VALVE HSG ASSEMBLY PS GEAR BOX LCV	TATA spare parts
264146210140	INPUT SHAFT WORM SHAFT & VALVE ASSY.	TATA spare parts
264146210141	PISTON ASSEMBLY PS GEAR BOX	TATA spare parts
264146210142	SECTOR SHAFT ASSEMBLY PS GEAR BOX	TATA spare parts
264146210143	SIDE COVER ASSEMBLY PS GEAR BOX LCV	TATA spare parts
264146210144	WORM SHAFT AND PISTON ASSY PS GEAR BOX	TATA spare parts

264146210145	SECTOR SHAFT AND SIDE COVER ASSEMBLY	TATA spare parts
264146210149	HOUSING ASSY	TATA spare parts
264146306014	PITMAN ARM RHD	TATA spare parts
264146306015	PITMAN ARM LHD	TATA spare parts
264146306016	PITMAN ARM-RH 613 LP/LPT POWER STRG.	TATA spare parts
264146306018	PITMAN ARM	TATA spare parts
264146306019	PITMAN ARM	TATA spare parts
264146600103	DRAG LINK ASSY RHD	TATA spare parts
264146600107	DRAG LINK ASSY RHD	TATA spare parts
264146600111	DRAG LINK FOR RHD	TATA spare parts
264146600111AE	DRAG LINK FOR RHD	TATA spare parts
264146600112	DRAG LINK FOR LHD	TATA spare parts
264146600114	DRAG LINK ASSY RHD	TATA spare parts
264146600115	DRAG LINK ASSY RHD	TATA spare parts
264146600116	DRAG LINK ASSY LHD	TATA spare parts
264146600117	ASSY DRAG LINK	TATA spare parts
264146600118	ASSY DRAG LINK	TATA spare parts
264146600142	ASSY. DRAG LINK-RHD	TATA spare parts
264146600143	DRAG LINK ASSY LH	TATA spare parts
264146600144	DRAG LINK ASSY-RH LP LPT709	TATA spare parts
264146600145	DRAG LINK ASSY LH	TATA spare parts
264146600146	ASSY DRAG LINK-RHD	TATA spare parts
264146600147	DRAG LINK ASSY LH	TATA spare parts
264146600148	ASSY DRAG LINK	TATA spare parts
264146600149	ASSY DRAG LINK	TATA spare parts
264146600150	ASSY KIT FOR DRAG LINK BALL JOINT	TATA spare parts
264146600153	ASSY KIT FOR DRAG LINK BALL JOINTS	TATA spare parts
264146600158	ASSY.DRAG LINK -RHD	TATA spare parts
264146600159	ASSY. DRAG LINK-LHD BS1	TATA spare parts
264146600160	ASSY. DRAGLINK (GREASING TYPE)	TATA spare parts
264146600161	ASSY. DRAGLINK (GREASING TYPE)	TATA spare parts
264146600164	DRAG LINK ASSEMBLY (GREASELESS-LHD)	TATA spare parts
264146600165	ASSY. DRAG LINK (GREASELESS) RHD BS2/3/4	TATA spare parts
264146600165DF	DRAG LINK ASSY - 407/709/909/712/912	TATA spare parts
264146703301	BRACKET STG GEAR BOX MTG (CAST)	TATA spare parts
264146800114	ASSY. PIPE (PUMP TO GEAR BOX)	TATA spare parts
264146800115	ASSY TUBE	TATA spare parts
264146800121	ASSY TUBE	TATA spare parts
264146800124	TUBE RET LINE TO HYD TANK	TATA spare parts
264146800128	TUBE P/S GR BOX RET LINE	TATA spare parts
264146800138	ASSY RESERVOIR (PSTRG)	TATA spare parts
264146800139	ASSY.TUBE (GEAR BOX TO TANK)	TATA spare parts
264146800140	PLASTIC OIL TANK WITH BRACKET ASSLY	TATA spare parts
264146800141	ASSY.TUBE	TATA spare parts
264146800142	ASSY. RESERVIOR P-STRG LCV	TATA spare parts
264146800143	ASSY. PUMP POWER STRG	TATA spare parts
264146800144	ASSY. STEERING PUMP BS2/3/4	TATA spare parts

264146800145	BRACKET ASSLY WITH NUT & BOLT	TATA spare parts
264146800150	REPAIR KIT FOR RESERVOIR P STRG LCV	TATA spare parts
264146800151	REPAIR KIT MAJOR FOR LCV PS PUMP	TATA spare parts
264146800152	REPAIR KIT MINOR FOR LCV PS PUMP	TATA spare parts
264146800153	STRG PUMP ASSY COMPLETE	TATA spare parts
264146800158	MAJOR REPAIR KIT FOR 0153 PUMP	TATA spare parts
264146800159	MINOR REPAIR KIT FOR 0153 PUMP	TATA spare parts
264146800161	PLASTIC RESERVOIR ASSY.	TATA spare parts
264146805805	RUBBER HOSE	TATA spare parts
264146806803	BANJO BODY	TATA spare parts
264146806804	BANJO	TATA spare parts
264146806805	BANJO BODY	TATA spare parts
264146806806	BANJO	TATA spare parts
264146806807	ELBOW (M16X1.5)	TATA spare parts
264146806808	ELBOW (M18X1.5)	TATA spare parts
264146900102	THREADED BALL JOINT RH	TATA spare parts
264146990102	REPAIR KIT	TATA spare parts
264146990201	BRACKET ASSY	TATA spare parts
264146990202	COVER ASSY	TATA spare parts
264146990203	OIL RESERVOIR ASSY	TATA spare parts
264146990205	PISTON ASSY BS6	TATA spare parts
264146993601	FILTER ELEMENT BS4	TATA spare parts
264146997501	RUBBER BUSH BS4	TATA spare parts
264146997702	SEALING RING	TATA spare parts
264146997703	SEALING RING	TATA spare parts
264146998001	SLOTTED CHEESE HEAD SCREW	TATA spare parts
264146998701	COMPRESSION RING	TATA spare parts
264146999201	WASHER	TATA spare parts
264147000101	ASSY FUEL TANK WITH STRAP & SUPPORT	TATA spare parts
264147100102	ASSY FUEL TANK WITH STRAP & SUPPORT	TATA spare parts
264147100109	FUEL WATER SEPARATOR WITHOUT SENSOR	TATA spare parts
264147100110	FUEL WATER SEPARATOR	TATA spare parts
264147100111	WATER SEPARATOR	TATA spare parts
264147100112	WATER SEPARATOR	TATA spare parts
264147100113	WATER SEPARATOR	TATA spare parts
264147100117	WATER SEPARATOR	TATA spare parts
264147100118	WATER SEPARATOR	TATA spare parts
264147100120	WATER SEPARATOR	TATA spare parts
264147100121	WATER SEPARATOR	TATA spare parts
264147100123	ASSY.WATER SEPARATOR FOR LHD	TATA spare parts
264147100124	ASSY WATER SEPERATOR	TATA spare parts
264147500108	ASSY BKT. FUEL TANK MTG	TATA spare parts
264147500109	ASSY.BRACKET	TATA spare parts
264147500111	ASSY BRACKET	TATA spare parts
264147508208	PLATE BS6	TATA spare parts
264147600101	FUEL SUCTION LINE	TATA spare parts
264147600102	FUEL RETURN LINE	TATA spare parts

264147600107	TUBE SUCTION LINE	TATA spare parts
264147600110	SUCTION TUBE	TATA spare parts
264147600111	ASSY FUEL LINE (SUCTION)	TATA spare parts
264147600113	ASSY.RETURN LINE	TATA spare parts
264147600114	BRACKET(W/SEP)LP/LPT709E	TATA spare parts
264147600115	ASSY.SUCTION LINE (F/TANK TO B/FILTER)	TATA spare parts
264147600118	HOSE-SUCTION	TATA spare parts
264147600124	FUEL SUCTION LINE	TATA spare parts
264147600126	ASSY.BRACKET	TATA spare parts
264147600132	ASSY.SUCTION LINE FUEL TANK TO WATERSEP	TATA spare parts
264147600133	ASSY.SUCTION LINE	TATA spare parts
264147600139	ASSY.RETURN LINE	TATA spare parts
264147600140	ASSY.SUCTION LINE(TANK TO SEP.)NYLON	TATA spare parts
264147600150	ASSY.SUCTION LINE W/O BABY FILTER	TATA spare parts
264147600151	ASSY.SUCTION LINE-160 LITRE FUEL TANK	TATA spare parts
264147600152	ASSY RETURN LINE-160 LITRE FUEL TANK	TATA spare parts
264147600153	ASSY.RETURN LINE-RE-ROUTED	TATA spare parts
264147600154	ASSY.BRACKET (W/SEP.WITH HAND PRIMER)	TATA spare parts
264147600158	ASSY.SUCTION LINE(TANK TO SOCKET)	TATA spare parts
264147600159	ASSY.RETURN LINE(TANK TO SOCKET)	TATA spare parts
264147600161	ASSY.SUCTION LINE(W.SEP TO HOSE)	TATA spare parts
264147600162	ASSY.RETURN LINE(SOCKET TO HOSE)	TATA spare parts
264147600164	ASSY.SUCTION LINE (W/SEP TO F.PUMP)	TATA spare parts
264147600165	ASSY.SUCTION LINE (F.PUMP TO INTAKE)	TATA spare parts
264147600166	ASSY.RETURN LINE (TANK TO HOSE)	TATA spare parts
264147600167	ASSY.SUCTION LINE (TANK TO BABY FILTER)	TATA spare parts
264147600168	ASSY.SUCTION LINE (BABY FILTER TO W/SEP)	TATA spare parts
264147600174	ASSY. SUCTION LINE WATER SEPARATOR TO ME	TATA spare parts
264147600178	ASSY.SUCTION LINE (TANK TO W/SEP.	TATA spare parts
264147600179	ASSY.SUCTION LINE (W/SEP. TO MECH FEED P	TATA spare parts
264147600180	ASSY.RETURN LINE(OVERFLOW TO TANK)-42WB	TATA spare parts
264147600182	ASSY SUCTION LINE (FUEL TANK TO W/SEP)	TATA spare parts
264147600183	ASSY SUCTION LINE (W/SEP TO FEED PUMP)	TATA spare parts
264147600184	ASSY RETURN LINE (ENGINE TO FUEL TANK)	TATA spare parts
264147605802	HOSE	TATA spare parts
264147607701	PIPE CLAMP (NYLON PIPES)13 X 13	TATA spare parts
264149100104	SILENCER ASSY	TATA spare parts
264149100110	ASSY.SILENCER COMPLETE	TATA spare parts
264149200104	EXHAUST PIPE FRONT	TATA spare parts
264149200106	ASSY. BRACKET	TATA spare parts
264149200120	EXHAUST PIPE FR INTERMED	TATA spare parts
264149200121	ASSY PROTECTION SHIELD	TATA spare parts
264149200125	ASSY SHAFT-THRO.VALVE	TATA spare parts
264149200126	EXHAUST BRAKE UNIT	TATA spare parts
264149200133	ASSY.BRACKET	TATA spare parts
264149200134	ASSY.BRACKET	TATA spare parts
264149200135	ASSY.BRACKET	TATA spare parts



264149200136	ASSY.BRACKET	TATA spare parts
264149200143	ASSY EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
264149200146	ASSY SHAFT-THROTTLE VALVE	TATA spare parts
264149200147	ASSY BRACKET	TATA spare parts
264149200148	EXHAUST BRAKE UNIT	TATA spare parts
264149200152	ASSY.EXHAUST TAIL PIPE	TATA spare parts
264149200158	ASSY EXH. PIPE FRT	TATA spare parts
264149200163	ASSY INTERMEDIATE PIPE	TATA spare parts
264149200164	ASSY.INTRERMEDIATE PIPE.(LP 709 LHD)	TATA spare parts
264149200170	ASSY.BRACKET-SILENCER MTG.FRONT	TATA spare parts
264149200171	ASSY.EXHAUST PIPE FRONT	TATA spare parts
264149200172	ASSY.BRACKET-SILENCER MTG.	TATA spare parts
264149200173	ASSY.SILENCER WITH TAIL PIPE	TATA spare parts
264149200174	ASSY.SILENCER WITH TAIL PIPE-LHD	TATA spare parts
264149200175	ASSY.BRACKET	TATA spare parts
264149200176	ASSY. BRACKET	TATA spare parts
264149200177	ASSY.BRACKET	TATA spare parts
264149200183	ASSY.BOTTOM NOISE SHIELD FLAP FRONT-RH	TATA spare parts
264149200184	ASSY.BOTTOM NOISE SHIELD FLAP-FRONT-LH	TATA spare parts
264149200187	ASSY.BRACKET	TATA spare parts
264149200192	ASSY.BRACKET	TATA spare parts
264149200194	ASSY BOTTOM NOISE SHIELD	TATA spare parts
264149200195	ASSY.BOTTOM NOISE SHIELD REAR	TATA spare parts
264149200198	ASSY.BOTTOM NOISE SHIELD FRONT	TATA spare parts
264149200199	ASSY.BOTTOM NOISE SHIELD COMPLT. FRONT	TATA spare parts
264149203301	BRACKET	TATA spare parts
264149203303	BRACKET	TATA spare parts
264149203310	BRACKET-AT CROSSMEMBER MTG	TATA spare parts
264149204201	CLAMP	TATA spare parts
264149204203	SILENCER MOUNTING STRAP	TATA spare parts
264149206925	EXHAUST PIPE	TATA spare parts
264149206942	EXHAUST PIPE	TATA spare parts
264149207101	BRACKET	TATA spare parts
264149208201	BRACKET	TATA spare parts
264149208208	BRACKET	TATA spare parts
264149208213	BRACKET RH LPT/SFC 709	TATA spare parts
264149208214	BRACKET-LH	TATA spare parts
264149208216	BRACKET	TATA spare parts
264149208217	BRACKET	TATA spare parts
264149208219	BRACKET VACCUM CYL MTG	TATA spare parts
264149208220	CLAMP	TATA spare parts
264149208255	STEEL STRIP (EXHAUST MTG.)	TATA spare parts
264149210101	ASSY.FRONT EXHAUST PIPE (BS-II)	TATA spare parts
264149210102	ASSY.BRACKET	TATA spare parts
264149210103	ASSY.FLEXIBLE BELLOW	TATA spare parts
264149210104	ASSY. FRT EXH PIPE W/FLEX BELLOW BS3	TATA spare parts
264149210105	ASSY FRT EXH PIPE WITH FLEX BELLOW-BS-II	TATA spare parts

264149210106	ASSY. STRAP (SILENCER MTG.	TATA spare parts
264149210107	ASSY.BRACKET (EXH.MTG.WITH STRIPS)	TATA spare parts
264149210109	ASSY BRACKET(EXHAUST MTG.WITH STRIPS)	TATA spare parts
264154100107	ASSY SUPPORT	TATA spare parts
264154100115	ASSY BATTERY CABLE - +VE[1.9LG]	TATA spare parts
264154100119	ASSY BATTERY CABLE - VE [1.31 LG]	TATA spare parts
264154100120	BATTERY CABLE -VE 1.48 LG	TATA spare parts
264154100121	BATTERY CABLE +VE 1.40 LG	TATA spare parts
264154100153	ASSY.BATTERY CABLE -VE- 1.83 M LG.	TATA spare parts
264154100192	ASSY.BATTERY CARRIER	TATA spare parts
264154100195	ASSY.BATT.CABLE 2.55LG-70SQ.MM	TATA spare parts
264154100196	ASSY TRAY	TATA spare parts
264154100197	ASSY.BATT.CABLE 2000LG 50SQ.MM	TATA spare parts
264154100198	ASSY.BATT.CABLE +VE 2500MM LG- 70SQ.MM	TATA spare parts
264154100204	ASSY. SUPPORT FRONT	TATA spare parts
264154100205	ASSY. SUPPORT REAR	TATA spare parts
264154100206	ASSY.BATT.CABLE -VE 1.3M W/COT 35SQ.MMN	TATA spare parts
264154100208	ASSY.SIDE BKT.LH WITH M10 NUT	TATA spare parts
264154100209	ASSY. INTERMEDIATE_ZBRKT	TATA spare parts
264154100223	ASSY BATT CABLE_+VE_2.6M_50SQMM_ISO6722	TATA spare parts
264154103201	STUD (260LG.)	TATA spare parts
264154103203	BATTERY CLAMP STUD	TATA spare parts
264154103204	BENT STUD - 300 MM	TATA spare parts
264154106302	BATT. TARY PLASTIC 1109 -100AH BATT	TATA spare parts
264154106303	BATTERY TRAY (PLASTIC)	TATA spare parts
264154108205	BRACKET [BATT CABLE]	TATA spare parts
264154108211	CHANNEL (BATTERY CLAMPING)	TATA spare parts
264154109907	BATTERY 100AH	TATA spare parts
264154109911	BATTERY 12V-100AH	TATA spare parts
264154109912	BATTERY 12V 100AH BS6	TATA spare parts
264154110101	ASSY.BATT.CABLE -VE 2.7LG-70SQ MM	TATA spare parts
264154110102	ASSY.BATT.CABLE -VE 2000MM LG- 70SQ.MM	TATA spare parts
264154110103	ASSY.BATT.CABLE 2600MM 50SQ.MM	TATA spare parts
264154110104	ASSY.BATT.CABLE -VE 1.48M WITH COT TUBE	TATA spare parts
264154110106	ASSY BATT.CABLE +VE 1.4LG W/COT 50SQ MM	TATA spare parts
264154200101	ASSY BRACKET	TATA spare parts
264154200104	INSTRUMENT CLUSTER 0.78 RATIO PTO	TATA spare parts
264154200116	ASSY SPEEDOCABLE 3000 LG-OFFER P NO	TATA spare parts
264154200117	SPEEDOCABLE 3000MM JIS	TATA spare parts
264154200118	SPEEDOCABLE 3000MM JIS	TATA spare parts
264154200123	SPEEDOCABLE 3000MM JIS	TATA spare parts
264154200129	ASSY.COVER STARTER RELAY&FUSE LINK LP709	TATA spare parts
264154200130	ASSY.PLATE-AUX.RELAY & FUSE LINK MTG	TATA spare parts
264154200131	ASSY.BRACKET-AUX.RELAY & FUSE LINK MTG	TATA spare parts
264154200132	ASSY SOLENOID	TATA spare parts
264154200134	SOLENOID	TATA spare parts
264154200144	KITT HORN	TATA spare parts

264154200156	ASSY BRACKET-ENGINE STOP RELAY	TATA spare parts
264154200158	ASSY COVER (STARTER & ENG.STOP RELAY)	TATA spare parts
264154200159	BASE (RELAYS & FUSES MTG.)	TATA spare parts
264154200160	COVER- RELAY & FUSE	TATA spare parts
264154200161	INSTRUMENT CLUSTER 1:0.78	TATA spare parts
264154200162	INSTRUMENT CLUSTER 1:0.78	TATA spare parts
264154200163	ASSY POWER SOCKET	TATA spare parts
264154200164	INSTRUMENT CLUSTER 1:0.78	TATA spare parts
264154200165	INSTRUMENT CLUSTER 1:0.72	TATA spare parts
264154200166	INSTRUMENT CLUSTER (1:0.6)	TATA spare parts
264154200174	INSTRUMENT CLUSTER 1:0.72	TATA spare parts
264154200175	INSTRUMENT CLUSTER 1:0.60	TATA spare parts
264154200176	INSTRUMENT CLUSTER 1:0.72	TATA spare parts
264154200177	INSTRUMENT CLUSTER 1:0.60	TATA spare parts
264154200180	WIRING HARNESS BS-II INST	TATA spare parts
264154200182	WIRING HARNESS BS-II CRPF	TATA spare parts
264154200185	INSTRUMENT CLUSTER (1:0.60) W/PTO	TATA spare parts
264154200189	INSTRUMENT CLUSTER (1:0.60) W/PTO	TATA spare parts
264154200193	WIRING HARNESS (CLUSTER)	TATA spare parts
264154200195	INSTRUMENT CLUSTER 1:0.78 W/PTO	TATA spare parts
264154200196	INSTRUMENT CLUSTER (1:0.60) W/PTO	TATA spare parts
264154200203	INST CLUSTER ESPEEDO 1:0.82 LPK909	TATA spare parts
264154200206	ASSY. COVER-PLASTIC (ELECT.PANEL)	TATA spare parts
264154201601	INSTRUMENT CLUSTER 1:0.64	TATA spare parts
264154206305	COVER (RELAYS & FUSE BOX) LP709 VEH	TATA spare parts
264154206306	COVER (RELAYS & FUSE BOX) LPT/SFC 709	TATA spare parts
264154206307	COVER (RELAYS & FUSE BOX)W/HD LPT709/613	TATA spare parts
264154206320	MAXI FUSE HOLD	TATA spare parts
264154206321	COVER-PLASTIC (ELECT.PANEL)	TATA spare parts
264154208204	BRACKET	TATA spare parts
264154208205	CLAMP	TATA spare parts
264154208207	BRACKET (HORN MOUNTING)	TATA spare parts
264154209903	MAGNETIC VALVE W/IND.TERS & HSG-OFFER	TATA spare parts
264154209905	MAGNETIC VALVE	TATA spare parts
264154209907	SPEEDOMETER 1:0.84 6+1	TATA spare parts
264154209908	GAUGE FUEL	TATA spare parts
264154209909	TEMP GAUGE	TATA spare parts
264154209911	SPEEDOMETER 1:0.84 6+1	TATA spare parts
264154209913	MAGNETIC VALVE	TATA spare parts
264154209914	SPEEDOCABLE 3000MM JIS	TATA spare parts
264154209915	SPEEDOCABLE 3000MM JIS	TATA spare parts
264154209916	SPEEDOCABLE JIS 3000 LG	TATA spare parts
264154209917	MAGNETIC VALVE W/IND.TERS & HSG	TATA spare parts
264154209925	SPEEDOMETER 1:0.78 (6+1)BACKLIT OFFER	TATA spare parts
264154209926	SPEEDOMETER 1:0.78 6+1	TATA spare parts
264154209927	SPEEDOMETER 1:0.78 (6+1)BACKLIT	TATA spare parts
264154209928	SPEEDOMETER 1:0.78 6+1	TATA spare parts

264154209929	SPEEDOCABLE JIS 3000 LG	TATA spare parts
264154209930	HORN LOW TONE NLS	TATA spare parts
264154209937	MAGNETIC VALVE	TATA spare parts
264154209938	MAGNETIC VALVE	TATA spare parts
264154209939	SPEEDOMETER 1:0.935 6+1	TATA spare parts
264154209944	SPEEDOCABLE 3200 LG.[JIS]	TATA spare parts
264154209945	HORNHIGHTONE	TATA spare parts
264154209946	HORN LOW TONE	TATA spare parts
264154209948	MAGNETIC VALVE BS2/3	TATA spare parts
264154209949	MAGNETIC VALVE 24 V DIN TERMINAL BS2/3/4	TATA spare parts
264154209950	MAGNETIC VALVE 12 V	TATA spare parts
264154209951	MAGNETIC VALVE 24 V BS3	TATA spare parts
264154209954	ELECT.TEMP GAUGE 12V BACKLIT	TATA spare parts
264154209955	SPEEDOCABLE JIS 3100 LG	TATA spare parts
264154209956	SPEEDOCABLE JIS 3100LG	TATA spare parts
264154209957	SPEEDOCABLE JIS 3100LG	TATA spare parts
264154209958	SPEEDOCABLE JIS 3100LG	TATA spare parts
264154209959	SPEEDOMETER 1:0.6(6+1DIGIT)BACKLIT	TATA spare parts
264154209960	ECU FOR VP37 EURO3 BS2/3	TATA spare parts
264154209961	BOOST PRESSURE/TEMP SENSOR	TATA spare parts
264154209962	WATER TEMP SENSOR	TATA spare parts
264154209963	ENGINE SPEED SENSOR 497 TCIC BS3/4	TATA spare parts
264154209969	LOAD DUMP MODULE	TATA spare parts
264154209970	FUEL GAUGE	TATA spare parts
264154209971	TEMP GAUGE	TATA spare parts
264154209972	AIR PRESSURE GAUGE	TATA spare parts
264154209973	SPEEDOMETER	TATA spare parts
264154209975	SPEEDO SYSTEM RATIO 1:0.72	TATA spare parts
264154209977	DIAL WITH FUEL AND APG ASSY	TATA spare parts
264154209978	DIAL WITH TEMP AND APG ASSY	TATA spare parts
264154209981	CRYSTAL (GAUGE)	TATA spare parts
264154209984	FUEL GAUGE MOVEMENT	TATA spare parts
264154209985	TEMP GAUGE MOVEMENT	TATA spare parts
264154209990	SPEEDOMETER RATIO 0.78	TATA spare parts
264154209991	AIR PRESSURE GAUGE MOVEMENT	TATA spare parts
264154209992	SPEEDOMETER RATIO 0.60	TATA spare parts
264154209993	SPEEDOMETER RATIO 0.585	TATA spare parts
264154209994	SPEEDOMETER RATIO 0.72	TATA spare parts
264154209997	SPEEDOMETER 0.64 MOVEMENT	TATA spare parts
264154209998	SPEEDOMETER RATIO 0.76	TATA spare parts
264154209999	SPEEDOMETER 1:0.64(6+1DIG)BACKLIT	TATA spare parts
264154210105	WIRING HARNESS (CLUSTER) 1 SERVICEABLE P	TATA spare parts
264154210108	INSTRUMENT CLUSTER 1:0.64	TATA spare parts
264154210109	INSTRUMENT CLUSTER 1:0.64 W/PTO	TATA spare parts
264154210110	INSTRUMENT CLUSTER 1:0.78 W/ABS	TATA spare parts
264154210114	INST CLUST (ELECT) 0.76 EMOS	TATA spare parts
264154210119	INSTRUMENT CLUSTER (1:0.76)	TATA spare parts

264154210121	INST.CLUSTER 0.76 LPT709 MECH.SPEEDO	TATA spare parts
264154210122	WIRING HARNESS (CLUSTER)	TATA spare parts
264154210123	INST CLUSTER 0.80 LPT809 12V	TATA spare parts
264154210125	INST CLUSTER 0.60 LP712 W/ABS 12V	TATA spare parts
264154210129	INST.CLUSTER LP712 BUS 0.70	TATA spare parts
264154210134	INSTRUMENT CLUSTER 1:0.64	TATA spare parts
264154210152	INST CLUSTER ESPEEDO LP/LPT712 0.60	TATA spare parts
264154210155	INST CLUSTER ESPEEDO	TATA spare parts
264154210156	INST CLUST ESPEEDO LPT909 0.72	TATA spare parts
264154210159	INST CLUST ESPEEDO LPT709 0.76	TATA spare parts
264154210162	INST CLUST ESPEEDO LP/LPT712 0.60	TATA spare parts
264154210164	INSTRUMENT CLUSTER ASSY	TATA spare parts
264154210165	INST CLUST ESPEEDO LP/LPT 912 0.64	TATA spare parts
264154210187	INST.CLUSTER 1:0.85 LPT1109	TATA spare parts
264154210196	INST.CLUSTER 0.76 LPT809 EX2	TATA spare parts
264154210198	INST.CLUSTER 0.60 LPT813 EXII W/APP-IND	TATA spare parts
264154219904	SPEEDOMETER RATIO 0.81	TATA spare parts
264154219905	ASSY. MAG.VLV(EX.BRAKE)W/VOSS 12V BS1-4	TATA spare parts
264154219907	SPEEDOMETER RATIO 0.80	TATA spare parts
264154219911	LOAD DUMP TRANSIENT SUPPRESSOR(12V)	TATA spare parts
264154219917	SPEEDOMETER 0.64 ESPEEDO 709	TATA spare parts
264154219918	SPEEDOMETER 0.64 ESPEEDO 709	TATA spare parts
264154219920	SPEEDO METER 0.67 E.SPEEDO 709	TATA spare parts
264154219922	SPEEDOMETER 0.70 ESPEEDO 709	TATA spare parts
264154219924	SPEEDOMETER 0.80 ESPEEDO 709	TATA spare parts
264154219925	SPEEDOMETER 0.85 ESPEEDO 709	TATA spare parts
264154219926	SPEEDOMETER 0.85 ESPEEDO 709	TATA spare parts
264154219928	SPEEDOMETRE CRYSTAL	TATA spare parts
264154219931	CLUSTER FACIA	TATA spare parts
264154219981	CRYSTAL GUAGE	TATA spare parts
264154219982	MAGNETICç SOLENOID VALVE 12 V	TATA spare parts
264154219983	MAGNETIC VALVE 24V	TATA spare parts
264154219992	WASHER (SPECIAL WASHER)	TATA spare parts
264154220101	INST.CLUSTER 0.60 LPT813 EXII	TATA spare parts
264154220102	W/H INSTRUMENT CLUSTER LPT 813 EX-II	TATA spare parts
264154220113	INST CLUSTER ESPEEDO LPK912 1:0.76	TATA spare parts
264154220114	INST CLUSTER ESPEEDO LPT912 0.76 BS-III	TATA spare parts
264154220115	INST CLUSTER ESPEEDO LPT812 1:0.80	TATA spare parts
264154220118	INST CLUSTER ESPEEDO LPT912 0.76 BS-III	TATA spare parts
264154220119	INST.CLUST.ESPEEDO LP712 0.60	TATA spare parts
264154220121	INSTRUMENT CLUSTER LPT712 RATIO 0.60 WIT	TATA spare parts
264154220134	INST.CLUSTER LPT709 0.70 PTO	TATA spare parts
264154249902	AIR PRESSURE GAUGE-24V	TATA spare parts
264154249903	AIR CYLINDER WITH MAGNETIC VALVE BS1- 4	TATA spare parts
264154249903AE	ASSY.MAG.VALVE W/VOSS 24V -715	TATA spare parts
264154400101	ASSY.HEAD LAMP LH	TATA spare parts
264154400102	ASSY.HEAD LAMP RH	TATA spare parts

264154400103	BLINKER LAMP LH	TATA spare parts
264154400103AE	ASSY. BLINKER LAMP LH 1415 715	TATA spare parts
264154400104	BLINKER LAMP RH	TATA spare parts
264154400104AE	ASSY. BLINKER LAMP RH 1415 715	TATA spare parts
264154400105	WARNING IND LAMP	TATA spare parts
264154400107	H/LAMP E CER.W/E-CERT.BULBS-RH LHD	TATA spare parts
264154400107AE	ASSY. HEAD LAMP RH 713	TATA spare parts
264154400108	H/LAMP E-CER.W/E-CERT.BULBS-LH LHD	TATA spare parts
264154400111	TURN INDICATOR LAMP	TATA spare parts
264154400112	ASSY WARNING LAMP	TATA spare parts
264154400113	HEAD LAMP LH RHD	TATA spare parts
264154400114	HEAD LAMP RH RHD	TATA spare parts
264154400116	ENGINE LAMP	TATA spare parts
264154400117	H/LAMP E-CER.W/E-CERT.BULBS-RH LHD	TATA spare parts
264154400118	H/LAMP E-CER.W/E-CERT.BULBS-LH LHD	TATA spare parts
264154400119	BLINKER LAMP LH	TATA spare parts
264154400120	BLINKER LAMP RH	TATA spare parts
264154400121	WARNING IND LAMP	TATA spare parts
264154400122	ASSY WARNING LAMP	TATA spare parts
264154400123	ASSY WARNING LAMP	TATA spare parts
264154400124	ASSY WARNING LAMP	TATA spare parts
264154400125	HEAD LAMP ASSY.LH	TATA spare parts
264154400126	HEAD LAMP ASSY.RH	TATA spare parts
264154400127	HEAD LAMP LH RHD	TATA spare parts
264154400128	H.LAMP609 RHECERT-RHD	TATA spare parts
264154400129	H/L E'CERT W/BLB LH-LHD 12V	TATA spare parts
264154400130	H/L E'CERT W/BLB RH-LHD 12V	TATA spare parts
264154400131	H/LAMP E-CER.W/E-CERT.BULBS-LH RHD OFFER	TATA spare parts
264154400132	H/LAMP E-CER.W/E-CERT.BULBS-RH RHD OFFER	TATA spare parts
264154400133	HEAD LAMP LH RHD	TATA spare parts
264154400134	HEAD LAMP RH RHD	TATA spare parts
264154400135	BLINKER LH E-CERT W/E-CERT BULB -OFFER	TATA spare parts
264154400136	BLINKER RH E CERT W/E-CERT BULB OFFER	TATA spare parts
264154400137	BLINKER LAMP LH	TATA spare parts
264154400138	BLINKER RH ECERT 709	TATA spare parts
264154400139	SIDE INDICATOR LH 709	TATA spare parts
264154400140	SIDE INDICATOR RH 709	TATA spare parts
264154400141	ASSY WARNING LAMP	TATA spare parts
264154400148	ASSY.HEAD LAMP-LH RHD	TATA spare parts
264154400149	ASSY.HEAD LAMP-RH RHD	TATA spare parts
264154400150	H/LAMP E-CER.W/E-CERT.BULBS-RH LHD	TATA spare parts
264154400151	H/LAMP E-CER.W/E-CERT.BULBS-LH LHD	TATA spare parts
264154400152	HEAD LAMP LH RHD	TATA spare parts
264154400153	HEAD LAMP RH RHD	TATA spare parts
264154400158	ASSY. H/L E CERT. W/BULBS RH-RHD BS2/3/4	TATA spare parts
264154400158AE	HEAD LAMP RH 715	TATA spare parts
264154400159	ASSY. H/L E CERT. W/BULBS LH-RHD BS2/3/4	TATA spare parts

264154400159AE	HEAD LAMP LH 715	TATA spare parts
264154400160	ASSY.E CERT.H/L.W/E MARK BULBS RH-LHD	TATA spare parts
264154400161	ASSY.E CERT.H/L.W/E MARK BULBS LH-LHD	TATA spare parts
264154400162	ASSY LAMP WARNING INDICATOR	TATA spare parts
264154400163	WARNING IND LAMP	TATA spare parts
264154400164	ASSY LAMP WARN.IND.	TATA spare parts
264154400165	ASSY.LAMP-WARNING INDICATOR	TATA spare parts
264154400166	ASSY.LAMP-WARNING INDICATOR	TATA spare parts
264154400167	ASSY.LAMP-WARNING INDICATOR	TATA spare parts
264154400168	LAMP WARNING INDICATOR	TATA spare parts
264154400169	ASSY.HEAD LAMP-LH RHD	TATA spare parts
264154400170	ASSY.HEAD LAMP-RH RHD	TATA spare parts
264154400178	ASSY.E'CERT.H/L W/E'MARK BULBS LH-RHD	TATA spare parts
264154400179	ASSY.E'CERT.H/L.W/E'MARK BULBS RH-RHD	TATA spare parts
264154400180	H/L E'CERT W/BLB.LH-LHD.12V -1.3%	TATA spare parts
264154400181	H/L E'CERT W/BLB.RH-LHD.12V -1.3%	TATA spare parts
264154400198	ASSY.TAIL LAMP WITH BKT -RH	TATA spare parts
264154400201	HEAD LAMP LH CLR 1.3PERC LENS 12V BS2/3/	TATA spare parts
264154400202	HEAD LAMP RH CLR 1.3PERC LENS 12V BS2/3/	TATA spare parts
264154400205	LAMP ASSY TAIL LAMP & MTG BRKT (12V)-LH	TATA spare parts
264154400206	LAMP ASSY TAIL LAMP & MTG BRKT (12V)-RH	TATA spare parts
264154400207	LAMP ASSY TAIL LAMP & MTG BRKT (24V)-LH	TATA spare parts
264154400208	LAMP ASSY TAIL LAMP & MTG BRKT (24V)-RH	TATA spare parts
264154401603	ASSY.ENGINE LAMP W/12V BULB(LP709)	TATA spare parts
264154408202	CLIP	TATA spare parts
264154408221	BRACKET-BATTERY CUT-OFF SWITCH-MARCOPOLO	TATA spare parts
264154408229	TAIL LAMP BRACKET RH	TATA spare parts
264154408233	TAIL LAMP BRACKET LH	TATA spare parts
264154408234	MAXI FUSE MTG.BRACKET-MARCOPOLO	TATA spare parts
264154409904	TAIL LAMP LH	TATA spare parts
264154409905	TAIL LAMP RH	TATA spare parts
264154409906	H/L LEVELLING MOTOR 12V	TATA spare parts
264154409912	BULB SPARE KIT - 12V (P21W-3 R10W) BS6	TATA spare parts
264154409914	LAMP LENS TAIL-LAMP (4 CH.) - LH BS6	TATA spare parts
264154409915	LAMP LENS TAIL-LAMP (4 CH.) - RH BS6	TATA spare parts
264154409916	LAMP LENS TAIL-LAMP (4 CH.) - LH BS6	TATA spare parts
264154409917	LAMP LENS TAIL-LAMP (4 CH.) - RH BS6	TATA spare parts
264154409918	LAMP GASKET TAIL-LAMP (4 CH.) BS6	TATA spare parts
264154409919	BULB H1 55W - 12V (HALOGEN)	TATA spare parts
264154409920	BULBH170W-24V BS6	TATA spare parts
264154409921	BULB H11 55W - 12V BS6	TATA spare parts
264154409922	BULBH1170W-24V BS6	TATA spare parts
264154409923	BULB P21W - 12V	TATA spare parts
264154409924	BULB P21W - 24V	TATA spare parts
264154409925	BULB P21/5W - 12V BS6	TATA spare parts
264154409926	BULBP21/5W-24V BS6	TATA spare parts
264154409927	BULB PY21W - 12V	TATA spare parts

264154409929	BULB W5W - 12V (HALOGEN)	TATA spare parts
264154409930	BULB W5W - 24V	TATA spare parts
264154409934	BULB T4W - 12V BS6	TATA spare parts
264154409935	BULB H4 60/55W - 12V BS6	TATA spare parts
264154409936	BULB T4W - 24V BS6	TATA spare parts
264154409937	BULB H4 75/70W - 24V BS6	TATA spare parts
264154409938	BULB R10W - 12V	TATA spare parts
264154409940	BULB H4 60/55W - 12V	TATA spare parts
264154409950	BULB H3 55W-12V	TATA spare parts
264154409952	BULB C10W - 24V BS6	TATA spare parts
264154410101	ASSY.TAIL LAMP WITH BKT -RH	TATA spare parts
264154410103	ASSY TAIL LAMP WITH BKT-LH	TATA spare parts
264154410105	ASSY TAIL LAMP WITH BKT-LH	TATA spare parts
264154410147	ASSY.ENGINE LAMP-OFFER	TATA spare parts
264154410148	ASSY.ENGINE LAMP	TATA spare parts
264154410149	ASSY.ENGINE LAMP	TATA spare parts
264154410165	ASSY. SIDE IND. LAMP LH W.BULB 12V-OFFER	TATA spare parts
264154410165AE	ASSY. SIDE IND. LAMP LH W.BULB 12V-OFFER	TATA spare parts
264154410166	ASSY. SIDE IND. LAMP RH W/BULB 12V	TATA spare parts
264154410166AE	ASSY. SIDE IND. LAMP RH W/BULB 12V	TATA spare parts
264154410168	ASSY.ENGINE LAMP	TATA spare parts
264154410171	ASSY.ENGINE LAMP	TATA spare parts
264154410172	HEAD LAMP LH RHD	TATA spare parts
264154410173	HEAD LAMP RH RHD	TATA spare parts
264154410179	HEAD LAMP LH RHD	TATA spare parts
264154410180	HEAD LAMP RH RHD	TATA spare parts
264154410181	ASSY TAIL LAMP RH W/BULB	TATA spare parts
264154410182	ASSY TAIL LAMP LH W/BULB	TATA spare parts
264154410185	ASSY.TAIL LAMP WITH BKT -RH	TATA spare parts
264154410186	ASSY TAIL LAMP WITH BKT-LH	TATA spare parts
264154410193	ASSY TAIL LAMP RH W/BULB	TATA spare parts
264154410194	ASSY TAIL LAMP LH W/BULB	TATA spare parts
264154420101	ASSY.TAIL LAMP WITH BKT -RH	TATA spare parts
264154420102	ASSY TAIL LAMP WITH BKT-LH	TATA spare parts
264154420109	ASSY.LAMP-WARNING INDICATOR	TATA spare parts
264154420110	ASSY.LAMP-WARNING INDICATOR	TATA spare parts
264154420111	ASSY.LAMP-WARNING INDICATOR	TATA spare parts
264154420112	ASSY.LAMP-WARNING INDICATOR	TATA spare parts
264154420113	ASSY.LAMP-WARNING INDICATOR	TATA spare parts
264154420114	ASSY.LAMP-WARNING INDICATOR	TATA spare parts
264154420115	ASSY.LAMP-WARNING INDICATOR	TATA spare parts
264154420124	ASSY WARNING LAMP 12V 7 IND BANK	TATA spare parts
264154420125	ASSY WARNING LAMP 12V	TATA spare parts
264154420133	ASSY.TAIL LAMP BRACKET RH-RHD	TATA spare parts
264154420134	ASSY WARNING LAMP 12V 7 IND BANK	TATA spare parts
264154420143	ASSY TAIL LAMP BRACKET RH-RHD	TATA spare parts
264154420144	ASSY TAIL LAMP BRACKET LH-RHD	TATA spare parts



264154420146	ASSY TAIL LAMP W/BKT-RH RHD-E'CERT	TATA spare parts
264154420147	ASSY TAIL LAMP W/BKT LH-RHD E'CERT	TATA spare parts
264154420150	ASSY TAIL LAMP W/BKT RH-RHD E'CERT	TATA spare parts
264154420151	ASSY TAIL LAMP W/BKT LH-RHD E'CERT	TATA spare parts
264154420152	ASSY TAIL LAMP W/BKT RH-RHD E'CERT	TATA spare parts
264154420153	ASSY TAIL LAMP W/BKT LH-RHD E'CERT	TATA spare parts
264154420154	ASSY TAIL LAMP W/BKT RH-RHD E'CERT	TATA spare parts
264154420155	ASSY TAIL LAMP W/BKT LH-RHD E'CERT	TATA spare parts
264154420156	H/LAMP E.CER W/E'CERT LAMP LH-LHD-	TATA spare parts
264154420157	H/LAMP E.CER W/E'CERT BULB RH-LHD-	TATA spare parts
264154420158	ASSY WARNING LAMP 12V	TATA spare parts
264154420161	ASSY H/L E CERT W/MOTOR LH-LHD 12V	TATA spare parts
264154420162	ASSY H/L E CERT W/MOTOR RH-LHD 12V	TATA spare parts
264154420163	ASSY.E'CERT.H/L W/E'MARK BULBS LH-RHD	TATA spare parts
264154420164	ASSY.E'CERT.H/L.W/E'MARK BULBS RH-RHD	TATA spare parts
264154420166	ASSY.E'CERT.H/L W/E'MARK BULBS LH-RHD	TATA spare parts
264154420167	ASSY.E'CERT.H/L.W/E'MARK BULBS RH-RHD	TATA spare parts
264154420168	ASSY H/L E CERT MOTO LH-LHD 12V	TATA spare parts
264154420169	ASSY H/L E CERT MOTO RH-LHD 12V	TATA spare parts
264154420170	ASSY H/L ECERT MOTO LH-RHD 12V-1.8%	TATA spare parts
264154420171	ASSY H/L ECERT MOTO RH-RHD 12V-1.8%	TATA spare parts
264154420174	H/L ECERT W/MOT LH-RHD 12V-1.8%	TATA spare parts
264154420175	H/L ECERT W/MOT RH-RHD 12V-1.8%	TATA spare parts
264154420176	H/L ECERT W/MOT LH-RHD 12V-1.8	TATA spare parts
264154420177	H/L ECERT W/MOT RH-RHD 12V-1.8%	TATA spare parts
264154420178	4CH CLR LENS TAIL LAMP W/B-LH12V	TATA spare parts
264154420179	4CH CLR LENS TAIL LAMP W/B-RH12V	TATA spare parts
264154420188	ASSY BLINKER LAMP LH-12V-E'CERT CLEAR	TATA spare parts
264154420189	ASSY BLINKER LAMP RH-12V-E'CERT CLEAR	TATA spare parts
264154420190	SIDE IND LAMP-CLEAR E'CER 12V-LH	TATA spare parts
264154420191	SIDE IND LAMP-CLEAR E'CER 12V-RH	TATA spare parts
264154420194	H/L-ECERT W/MOT - RH RHD 12V -1.8%	TATA spare parts
264154420195	H/L-ECERT W/MOT - LH RHD 12V -1.8%	TATA spare parts
264154420196	H/L E CERT 12V W/MOT RH-RHD -1.3PERC	TATA spare parts
264154420197	H/L E CERT 12V W/MOT LH-RHD -1.3PERC	TATA spare parts
264154420205	ASSY HEAD LAMP WITH BULB LH	TATA spare parts
264154420206	ASSY HEAD LAMP WITH BULB RH	TATA spare parts
264154430107	ASSY SIDE IND LAMP(LH)12V	TATA spare parts
264154430108	ASSY SIDE IND LAMP(RH)12V	TATA spare parts
264154430109	ASSY SIDE IND LAMP(LH)(CLEAR)12V	TATA spare parts
264154430110	ASSY SIDE IND LAMP(RH)(CLEAR)12V	TATA spare parts
264154430111	ASSY SIDE IND.LAMP(LH)(CLEAR)12V	TATA spare parts
264154430112	ASSY SIDE IND LAMP(RH)(CLEAR)12V	TATA spare parts
264154430113	TAIL LAMP W/BKT E'CERT 12V RH-RHD-	TATA spare parts
264154430114	TAIL LAMP W/BKT E'CERT 12V LH-RHD	TATA spare parts
264154430115	TAIL LAMP W/BKT E'CERT 12V RH	TATA spare parts
264154430116	TAIL LAMP W/BKT E'CERT 12V LH	TATA spare parts

264154430117	TAIL LAMP E`CERT W/BKT RH-RHD 12V-	TATA spare parts
264154430118	TAIL LAMP E`CERT W/BKT LH-RHD 12V	TATA spare parts
264154430119	ASSY.4 CH.T/LAMP W/BKT-RH-12V	TATA spare parts
264154430120	ASSY.4 CH.T/LAMP W/BKT-LH-12V	TATA spare parts
264154430126	ASSY H/L LH-RHD CLEAR W/MOT-1.3%	TATA spare parts
264154430127	ASSY H/L RH-RHD CLEAR W/MOT-1.3%	TATA spare parts
264154430128	ASSY H/L LH-RHD CLEAR W/MOT-1.3%	TATA spare parts
264154430129	ASSY H/L E`CERT CLR LENS 12V RH-1.3%-OFF	TATA spare parts
264154430130	ASSY.SIDE IND.LAMPE`CER AMBER 12V-RH	TATA spare parts
264154430131	ASSY.SIDE IND.LAMPE`CER AMBER 12V-LH	TATA spare parts
264154430132	ASSY.SIDE IND.LAMPE`CER WHITE 12V-RH	TATA spare parts
264154430133	ASSY.SIDE IND.LAMPE`CER WHITE 12V-LH	TATA spare parts
264154430134	ASSY.TAIL LAMP(4 CH.)LH-12V	TATA spare parts
264154430135	ASSY.TAIL LAMP(4 CH.)RH-12V	TATA spare parts
264154430138	INSPECTION LAMP 12V	TATA spare parts
264154430141	ASSY.ENGINE LAMP W/12V BULB	TATA spare parts
264154430142	ASSY ENGINE LAMP W/12VBULB	TATA spare parts
264154430145	ASSY. FRONT BLINKER LAMP-LH-12V BS2/3/4	TATA spare parts
264154430146	ASSY.FRONT BLINKER LAMP-RH-12V	TATA spare parts
264154430147	ASSY SIDE REP.LAMP(CLEAR LENS)12V	TATA spare parts
264154430149	ASSY HEAD LAMP & BLINKER MTG-RH	TATA spare parts
264154430150	ASSY.REVERSE LAMP BS4	TATA spare parts
264154430152	ASSY.FRONT TURN SIGNAL LAMP-MARCOPO-FIEM	TATA spare parts
264154430153	ASSY.REAR TURN SIGNAL LAMP BS4	TATA spare parts
264154430154	ASSY.TAIL TAMP BS4	TATA spare parts
264154430155	ASSY. HEAD LAMP LOW BEAM-LH(MARCO)BS1- 6	TATA spare parts
264154430156	HEAD LAMP HIGH BEAM-LH MARCOPOLO BS4	TATA spare parts
264154430158	ASSY.STRUCTURE HEAD LAMP MTG.BKT	TATA spare parts
264154430160	SPACER -TAIL LAMP MTG.BRACKET-MARCOPOLO	TATA spare parts
264154430162	HEAD LAMP HIGH BEAM RH-MARCOPOLO BS4	TATA spare parts
264154430163	ASSY. HEAD LAMP LOW BEAM RH(MARCO)BS1- 6	TATA spare parts
264154430177	LAMP TAIL-LAMP (4 CH.) LH-12V	TATA spare parts
264154430178	LAMP TAIL-LAMP (4 CH.) RH-12V	TATA spare parts
264154430179	LAMP TAIL-LAMP (4 CH.) LH-12V	TATA spare parts
264154430180	LAMP TAIL-LAMP (4 CH.) RH-12V	TATA spare parts
264154430186	SIDE INDICATOR LAMP ASSY LH BS6-PH2	TATA spare parts
264154430187	SIDE INDICATOR LAMP ASSY RH BS6-PH2	TATA spare parts
264154440101	ASSY.H/L E`CERT W/MOTOR.LH-RHD 24V	TATA spare parts
264154440102	ASSY.H/L E`CERT W/MOTOR RH-RHD 24V	TATA spare parts
264154440103	ASSY.H/L E`CERT W/MOTOR.LH-RHD 24V	TATA spare parts
264154440104	ASSY.H/L E`CERT W/MOTOR RH-RHD 24V	TATA spare parts
264154440105	ASSY H/L E`CERT MOTO LH-RHD 24V-1.8%	TATA spare parts
264154440106	ASSY H/L E`CERT MOTO RH-RHD 24V-1.8%	TATA spare parts
264154440107	H/L E`CERT 24V W/MOT LH-RHD -1.8%	TATA spare parts
264154440108	H/L E`CERT 24V W/MOT RH-RHD -1.8%	TATA spare parts
264154440109	ASSY.H/L E`CERT W/MOTOR.LH-RHD 24V	TATA spare parts
264154440110	ASSY.H/L E`CERT W/MOTOR RH-RHD 24V	TATA spare parts

264154440111	H/L E'CERT W/MOT LH-RHD 24V -1.8%	TATA spare parts
264154440112	H/L E'CERT W/MOT RH-RHD 24V(-1.8%)	TATA spare parts
264154440113	ASSY.SIDE REP.LAMP LH-24V-E CERT	TATA spare parts
264154440114	ASSY.SIDE REP.LAMP RH-24V-E CERT	TATA spare parts
264154440115	ASSY BLINKER LAMP LH-24V-E CERT	TATA spare parts
264154440116	ASSY BLINKER LAMP RH-24V-E CERT	TATA spare parts
264154440117	H/L E'CERT 24V W/MOT RH-RHD -1.8%	TATA spare parts
264154440118	H/L E'CERT 24V W/MOT LH-RHD -1.8%	TATA spare parts
264154440121	ASY.MOT.H/L 24V E CERT RH LHD -1.8%	TATA spare parts
264154440121AE	HEAD LAMP RH 2523	TATA spare parts
264154440122	ASY.MOT.H/L 24V E CERT LH LHD -1.8%	TATA spare parts
264154440122AE	HEAD LAMP LH 2523	TATA spare parts
264154440134	ASSY.SIDE IND.LAMP E CER AMBER 24V-RH	TATA spare parts
264154440135	ASSY.SIDE IND.LAMP E CER AMBER 24V-LH	TATA spare parts
264154440138	ASSY.TAIL LAMP(4 CH.)LH-24V	TATA spare parts
264154440139	ASSY.TAIL LAMP(4 CH.)RH-24V	TATA spare parts
264154440142	ASSY.ENGINE LAMP W/24V BULB	TATA spare parts
264154440143	ASSY.ENGINE LAMP W/24V BULB	TATA spare parts
264154440148	LAMP TAIL-LAMP (4 CH.) LH-24V	TATA spare parts
264154440149	LAMP TAIL-LAMP (4 CH.) RH-24V	TATA spare parts
264154441601	ASSY.ENGINE LAMP W/24V BULB(LP709)	TATA spare parts
264154500104	STRG LOCK CUM IGN SWITCH	TATA spare parts
264154500105	ASSY STRG.LOCK CUM IGN.	TATA spare parts
264154500106	STEERING LOCK CUM IGNITION SW BS1/2/3/4	TATA spare parts
264154500106AE	STRG LOCK/ IGN SW	TATA spare parts
264154500108	ASSY.BRACKET	TATA spare parts
264154500110	BKT TAIL LAMP RH RHD	TATA spare parts
264154500111	T/LAMP BKT LH LHD	TATA spare parts
264154500112	BKT TAIL LAMP LH RHD	TATA spare parts
264154500113	T/LAMP BKT RH LHD	TATA spare parts
264154500114	IGNITION CUM STEERING LOCK	TATA spare parts
264154500135	DOUBLE CONTACT BRAKE SW.FOR EMS-	TATA spare parts
264154500136	DOUBLE CONTACT BRAKE SWITCH	TATA spare parts
264154500137	DOUBLE CONTACT BRAKE SWITCH BS4	TATA spare parts
264154500138	STEERING LOCK CUM IGNITION SWITCH	TATA spare parts
264154506305	COVER	TATA spare parts
264154506306	CARRIER PLATE SWITCH	TATA spare parts
264154506901	PIANO KEY SWITCH-EXH.BRAKE	TATA spare parts
264154506904	PIANO SWITCH EX BR ON	TATA spare parts
264154506905	PIANO SWITCH ENG LAMP	TATA spare parts
264154506906	PIANO SWITCH-PTO SOLENOID-OFFER DRG	TATA spare parts
264154506907	PIANO SWITCH [EXHAUST BR.ON]	TATA spare parts
264154506909	PIANO SWITCH PIO	TATA spare parts
264154506910	PIANO KEY SW-PTO..	TATA spare parts
264154506911	PIANO SW.(EXH.BR.ON) W/O CONN.	TATA spare parts
264154506912	PIANO SW.(ENGINE LAMP)W/O CONN.	TATA spare parts
264154506913	PIANO SW.(REAR FOG LAMP)W/O CONN.	TATA spare parts

264154506914	PIANO SW.(POWER TAKE OFF)W/O CONN.-	TATA spare parts
264154506915	PIANO SW. EXH.BR.ON W/O CONN.	TATA spare parts
264154506916	PIANO SW.(ENGINE LAMP)W/O CONN.	TATA spare parts
264154506918	PIANO SW.(POWER TAKE OFF)W/O CONN.-	TATA spare parts
264154506919	PIANO SW. EXH.BR.ON W/O CONN.	TATA spare parts
264154506920	PIANO SW.(ENGINE LAMP)W/O CONN.	TATA spare parts
264154506921	PIANO SW.(POWER TAKE OFF)W/O CONN.-	TATA spare parts
264154506922	PIANO SW.(REAR FOG LAMP)W/O CONN.-ELECT	TATA spare parts
264154506927	PIANO SWITCH (3 TERMINAL) FOG LAMP-	TATA spare parts
264154506929	PIANO SW. EXH.BR.ON W/O CONN.	TATA spare parts
264154506930	PIANO SW.(ENGINE LAMP)W/O CONN.	TATA spare parts
264154506931	PIANO SW POWER TAKE OFF W/O CONN-	TATA spare parts
264154506933	PIANO SW. EXH.BR.ON W/O CONN.	TATA spare parts
264154506934	PIANO SW.(ENGINE LAMP)W/O CONN.	TATA spare parts
264154506935	PIANO SW POWER TAKE OFF W/O CONN-	TATA spare parts
264154506936	PIANO SWITCH (3 TERMINAL) FOG LAMP-	TATA spare parts
264154506937	HEAD LAMP LEVELLING SWITCH	TATA spare parts
264154506940	HEAD LAMP LEVELLING SWITCH	TATA spare parts
264154508209	COVER	TATA spare parts
264154508219	BRACKET STOP SWITCH	TATA spare parts
264154508221	MTG.PLATE (CHANGE OVER SW.BLACK OUT)	TATA spare parts
264154508242	BRACKET (FOR MAXI FUSE MTG.)	TATA spare parts
264154509908	TEMP.SWITCH	TATA spare parts
264154509909	TEMP.SWITCH-497TC EURO-II	TATA spare parts
264154509910	THERMOSTAT SWITCH -100DEG	TATA spare parts
264154509914	TEMP SW FOR 497TC E-II IIL BS6	TATA spare parts
264154600111	RETROFITMENT KIT LP/LPT709 POST-NOV01VEH	TATA spare parts
264154600112	RETROFITMENT KIT LP/LPT709 PRE-NOV01 VEH	TATA spare parts
264154600113	W/H MAIN(LPT 712 BS III)	TATA spare parts
264154600114	W/H MAIN LP 712 BS III	TATA spare parts
264154600115	W/H INST.CONSOLE(LP/LPT 712 BSIII)	TATA spare parts
264154600116	W/H ENGINE(LP/LPT 712 BS III)	TATA spare parts
264154600117	W/H MAIN RHD LPT709BS-II W/MOT H/L	TATA spare parts
264154600118	W/H MAIN RHD LP709 BS-II W/MOT H/L	TATA spare parts
264154600119	W/H INST.CONSOLE W/MOT H/L	TATA spare parts
264154600124	W/H TAIL W/O LB 34WB BS-III	TATA spare parts
264154600125	W/H TAIL W/O LB 38WB BS-III	TATA spare parts
264154600130	W/H MAIN LPT712 BS-III RHD W/CL.	TATA spare parts
264154600131	W/H MAIN LP709 BS-III RHD W/CL.	TATA spare parts
264154600132	W/H MAIN RHD LP 709 W/INST CLUST.	TATA spare parts
264154600133	W/H MAIN RHD LPT 709 W/CLUST.BS-II-	TATA spare parts
264154600134	W/H ENGINE RHD BS-II	TATA spare parts
264154600135	W/H TAIL LPT 709/34WB BS-II	TATA spare parts
264154600136	W/H TAIL LPT709/38WB BS-II-	TATA spare parts
264154600137	W/H TAIL LP709/34WB BS-II	TATA spare parts
264154600138	W/H TAIL LP709/38WB BS-II	TATA spare parts
264154600143	W/H SIDE MARKER LP/T 709/38 BS-II	TATA spare parts

264154600144	W/H SIDE MARKER LP/T 709/34 BS-II	TATA spare parts
264154600145	W/H SIDE MARKER LAMP LPT 709/38WB	TATA spare parts
264154600148	W/H FRAME ASSY LPT709/34 12V II ABS	TATA spare parts
264154600149	W/H FRAME ASSY LPT709/38 12V II ABS	TATA spare parts
264154600157	ASSY BKT ENGINE SPEED SENSOR PARK	TATA spare parts
264154600158	ASSY BKT FOR ENG SPEED CONN PARKING CUM	TATA spare parts
264154600160	ASSY BUFFER UNIT & WATER IN FUEL UNIT MT	TATA spare parts
264154600161	ASSY W/H TAIL CLAMPING BKT	TATA spare parts
264154601601	W/H MAIN LPT709 EX2 RHD BS-II	TATA spare parts
264154601602	W/H TAIL LPT709 38WB EX2 RHD	TATA spare parts
264154601605	W/H MAIN LP709 EX2 CMVR	TATA spare parts
264154601610	W/H ENGINE(W/O STARTER RELAY)	TATA spare parts
264154601617	W/H MAIN LP712/38WB BSIII ARMY BUS	TATA spare parts
264154601618	W/H TAIL LP712/38WB BSIII ARMY BUS	TATA spare parts
264154601627	W/H SENSOR LP/LPT712 BSIII	TATA spare parts
264154601652	W/H TAIL LP 712/42WB EX RHD BUS	TATA spare parts
264154601670	W/H PIG TAIL L.P.SW.AND B/F BOTTLE-OFFER	TATA spare parts
264154601671	WIRING HARNESS PARKING LP/LPT 709-OFFER	TATA spare parts
264154601674	W/H SWITCH OF LP/LPT709 EXII-OFFER	TATA spare parts
264154601694	W/H ENGINE LP/T410/712/912/1112ESP-OFFER	TATA spare parts
264154607502	GROMMET BS6	TATA spare parts
264154607503	GASKET BS6	TATA spare parts
264154608201	CLAMP	TATA spare parts
264154608203	BRACKET	TATA spare parts
264154608204	BRACKET-SOLENOID	TATA spare parts
264154608206	SENSOR W/H MTG CUM NEEDLE MOV.PARK.BRK	TATA spare parts
264154608209	SENSOR W/H MTG.BKT.ON INTAKE SFC709-497	TATA spare parts
264154608210	SENSOR W/H MTG.BKT.ON GEAR BOX	TATA spare parts
264154608212	SEN.W/H MTG.CUM ROTARY FIP CONN.PARK BKT	TATA spare parts
264154608213	SENSOR WH MTG BKT ON CLUTCH HOUSING GBS	TATA spare parts
264154608214	SENSOR W/H MTG.BKT.ON GEAR BOX I-497ENG	TATA spare parts
264154608215	SENSOR W/H MTG.BKT.ON UPER COOLING LINEI	TATA spare parts
264154608217	INTERCONN.CONNECTOR PARK BKT	TATA spare parts
264154608218	SENSOR W/H MTG.BKT.ON CHASSIS LPT709-497	TATA spare parts
264154608225	ENGINE SPEED SENSOR CONN MTG BKT	TATA spare parts
264154608226	NBF SENSOR PARKING BKT	TATA spare parts
264154608231	MAIN WIRING HARNESS MOUNTING BRACKT	TATA spare parts
264154608232	BRACKET TAIL WIREING HARNESS CLAMPING.	TATA spare parts
264154608234	BRACKET TAIL WIREING HARNESS CLAMPING	TATA spare parts
264154608237	CONN MTG BRKT_Z TYPE (7 DIA & SLOT)	TATA spare parts
264154608239	INLINE CONNECTOR MTG BKT FOR LP912	TATA spare parts
264154608253	COVER_FIREWALL_LPT	TATA spare parts
264154609957	CABLE TIE (SFC/LPT 407)-MICROSIGN PRODUC	TATA spare parts
264154610106	WIRING HARNESS ROOF	TATA spare parts
264154610107	WIRING HARNESS SEAT BELT SWITCH	TATA spare parts
264154610110	WIRING HARNESS INSTRUMENT CONSOLE	TATA spare parts
264154610111	W/H ENGINE RHD BS-II	TATA spare parts

264154610112	W/H ENGINE CMVR2000	TATA spare parts
264154610117	W/H TAIL 34WB BS-III W/O LB W/PTO	TATA spare parts
264154610119	W/H MAIN LP712 BSIII TMML WITH CAT	TATA spare parts
264154611663	W/H H/L AND BLINKER LAMP WITH CAT-6	TATA spare parts
264154620104	WIRING HARNESS BLOWER	TATA spare parts
264154620105	WIRING HARNESS SEAT BELT SWITCH	TATA spare parts
264154620126	WIRING HARNESS MAIN - S'CAM-RHD	TATA spare parts
264154620127	WIRING HARNESS ENGINE W/S-CAM	TATA spare parts
264154620128	WIRING HARNESS INST. CONSOLE	TATA spare parts
264154620129	WIRING HARNESS TAIL LPT709TC/34 WB	TATA spare parts
264154620130	WIRING HARNESS TAIL LPT709TC/38 WB	TATA spare parts
264154620131	WIRING HARNESS ROOF	TATA spare parts
264154620137	WIRING HARNESS ENGINE	TATA spare parts
264154620144	WIRING HARNESS MAIN RHD	TATA spare parts
264154620146	W/H.MAIN S CAM - LP/LPT 709 RHD	TATA spare parts
264154620153	WIRING HARNESS ENGINE -LHD	TATA spare parts
264154620171	W/H.INST.CLUST.S'CAM-W/EXH BRK	TATA spare parts
264154620174	WIRING HARNESS ROOF	TATA spare parts
264154620175	W/H DANDA MAN SW.	TATA spare parts
264154620182	WIRING HARNESS ENGINE (LHD) LP709	TATA spare parts
264154620183	W/H MAIN -LHD M/S.MSSL	TATA spare parts
264154620186	W/H TAIL LHD 38WB BUS	TATA spare parts
264154620188	W/H RETROFITMENT KIT ENG STOP SOLENOID	TATA spare parts
264154620189	W/H MAIN RHD CMVR2000 LPT709	TATA spare parts
264154620190	W/H MAIN RHD CMVR2000 LP709	TATA spare parts
264154620191	W/H INSTRUMENT CONSOLE	TATA spare parts
264154620193	W/H TAIL RHD 38WB W/O LOADBODY	TATA spare parts
264154620194	W/H TAIL RHD 34WB W/LOADBODY	TATA spare parts
264154620195	W/H TAIL RHD 38WB LPT709 W/LBODY	TATA spare parts
264154620197	WIR/HARNESS ENGINE-RHD LPT709TURBO EURO	TATA spare parts
264154620198	W/H ENGINE CMVR2000	TATA spare parts
264154620199	W/H INST.CONSOLE W/MOT H/L	TATA spare parts
264154630101	W/H MAIN RHD LP709 BS-II W/MOT H/L	TATA spare parts
264154630102	W/H MAIN RHD LPT709 BSII	TATA spare parts
264154630105	W/H MAIN(LPT 712 BS III)	TATA spare parts
264154630106	W/H MAIN LP 712 BS III	TATA spare parts
264154630107	W/H INST.CONSOLE EURO-III	TATA spare parts
264154630108	W/H ENGINE EURO-III	TATA spare parts
264154630113	W/H TAIL 38WBLPT712BSIII	TATA spare parts
264154630114	W/H TAIL 34 WB LPT712 BSIII	TATA spare parts
264154630117	W/H MAIN LP 709 W/ADDITIONL BLINKER	TATA spare parts
264154630118	W/H MAIN LPT709 W/O ADDIT.BLINKER-	TATA spare parts
264154630121	W/H TAIL LP 709/38 BS-II	TATA spare parts
264154630122	W/H TAIL LP 709/34 BS-II	TATA spare parts
264154630125	W/H TAIL LPT 709/38 BS-II	TATA spare parts
264154630126	W/H TAIL LPT 709/34 BS-II	TATA spare parts
264154630127	W/H SIDE MARKER LP/T 712/38 BS-II	TATA spare parts

264154630128	W/H SIDE MARKER LP/T 712/34 BS-II	TATA spare parts
264154630129	W/H ENGINE LHD W/ENG STOP RELAY	TATA spare parts
264154630130	W/H ELECTRICAL FEED PUMP	TATA spare parts
264154630131	W/H ENGINE LP/T 709 BS-III RHD	TATA spare parts
264154630132	W/H SIDE MARKER LAMP LPT709/34WB	TATA spare parts
264154630133	W/H SIDE MARKER LAMP LPT709/38WB	TATA spare parts
264154630135	W/H TAIL 38WB TRUCK LHD	TATA spare parts
264154630137	W/H MAIN RHD LPT712 W/PTO W/CLUSTER	TATA spare parts
264154630138	W/H MAIN RHD LP712 W/CLUSTER	TATA spare parts
264154630140	W/H TAIL LPT 712/34WB W/PTO BS-III	TATA spare parts
264154630141	W/H MAIN LPK909 TIPPER	TATA spare parts
264154630142	W/H TAIL LPK909 TIPPER	TATA spare parts
264154630143	W/H ENGINE(W/O STARTER RELAY)	TATA spare parts
264154630144	W/H MAIN LP709 EX2 BS-II	TATA spare parts
264154630145	W/H MAIN LPT709 EX2 BS-II	TATA spare parts
264154630146	W/H TAIL LPT709 38WB EX2 BS-II RHD	TATA spare parts
264154630150	W/H MAIN LPT809 EX RHD BS-II	TATA spare parts
264154630154	W/H MAIN (LP712/38WB ARMY BUS)	TATA spare parts
264154630155	W/H TAIL (L712/38WB ARMY BUS)	TATA spare parts
264154630164	W/H TAIL LP 712/42WB EX RHD BUS	TATA spare parts
264154630167	W/H MAIN LP709 909 BSII	TATA spare parts
264154630168	W/H TAIL 709-MARCOPOLO	TATA spare parts
264154630169	W/H ENGINE 709	TATA spare parts
264154630170	W/H HEAD LAMP AND BLINKER LAMP	TATA spare parts
264154630171	W/H PIG TAIL-FIP AND OIL PR.SW.	TATA spare parts
264154630180	W/H PIG TAIL L.P.SW. AND B/F BOTTLE	TATA spare parts
264154630181	WIRING HARNESS PARKING	TATA spare parts
264154630184	W/H SWITCH OF LP/LPT709 EXII	TATA spare parts
264154630185	W/H SWITCH OF LP/LPT709 EX	TATA spare parts
264154630186	W/H MAXIFUSE AND BATT.CUT OFF SW	TATA spare parts
264154630187	W/H SWITCH-MARCOPOLO	TATA spare parts
264154630188	WIRING HARNESS TAIL LP909/49WB	TATA spare parts
264154640106	W/H ENGINE	TATA spare parts
264154640110	W/H TAIL LPT712/912 38WB ESPEED	TATA spare parts
264154640120	W/H TAIL LPT1109 36WB-MSSL	TATA spare parts
264154640121	W/H TAIL LPT1109 42WB	TATA spare parts
264154640125	W/H TAIL LPT 1109 EX2	TATA spare parts
264154640126	W/H MAIN LPT1109 EX2	TATA spare parts
264154640133	W/H SENSOR LP/LPT712 BSIII	TATA spare parts
264154640134	W/H TAIL LPK912/27WB BSIII	TATA spare parts
264154640135	W/H MAIN	TATA spare parts
264154640138	W/H TAIL LP712/42WB MARCOPOLO	TATA spare parts
264154640142	W/H SENSOR LP712/912	TATA spare parts
264154640148	W/H TAIL LPT712/912 BSIII 38WB	TATA spare parts
264154640149	W/H MAIN LPT410/712/912/1112 BSIII	TATA spare parts
264154640151	WIRING HARNESS TAIL	TATA spare parts
264154640152	WIRING HARNESS TAIL	TATA spare parts

264154640157	W/H MAIN LP712 BSIII	TATA spare parts
264154640160	W/H MAIN LP410 BSIII TMML WITH CAT-6	TATA spare parts
264154640162	WIRING HARNESS H/L AND BLINKER LAMP WITH	TATA spare parts
264154660106	WIRING HARNESS ROOF	TATA spare parts
264154660107	WIR/HARNESS MAIN-RHD LPT709TURBO EURO2	TATA spare parts
264154660108	WIR/HARNESS ENGINE-RHD LPT709TURBO EURO	TATA spare parts
264154660109	W/H INST.CONSOLE EURO-II W/EXH.	TATA spare parts
264154660111	WIR/HARNESS TAIL-RHD LPT709TURBO EURO2	TATA spare parts
264154660113	W/H ENGINE W/EXH BRK.RHD	TATA spare parts
264154660120	WIRING HARNESS ENGINE RHD	TATA spare parts
264154660127	W/H ROOF	TATA spare parts
264154660132	W/H MAIN LP709 CMVR2000	TATA spare parts
264154660133	W/H MAIN LPT709 CMVR2000	TATA spare parts
264154660134	W/H INSTRUMENT CONSOLE	TATA spare parts
264154660136	W/H TAIL 38WB LP/LPT709 W/O LB	TATA spare parts
264154660137	W/H TAIL 34WB LPT709 W/LB	TATA spare parts
264154660138	W/H TAIL 38WB LPT709 W/LB	TATA spare parts
264154660143	W/H TAIL 38WB BS-II W/PTO W/O LB	TATA spare parts
264154660144	W/H TAIL 34WB HI-DECK LB	TATA spare parts
264154660148	W/H ENGINE CMVR2000	TATA spare parts
264154660149	W/H MAIN RHD BS-III LPT712	TATA spare parts
264154660150	W/H MAIN LP 712 BS III	TATA spare parts
264154660151	W/H INST.CONSOLE EURO-III	TATA spare parts
264154660152	W/H ENGINE EURO-III	TATA spare parts
264154660153	W/H TAIL BS-III FACELIFT 34WB	TATA spare parts
264154660154	W/H TAIL BS-III FACELIFT 38WB	TATA spare parts
264154660155	W/H MAIN LPT709RHD BS-II	TATA spare parts
264154660156	W/H MAIN RHD LP709 BS-II W/MOT H/L	TATA spare parts
264154660157	W/H INST.CONSOLE W/MOT H/L	TATA spare parts
264154660158	W/H TAIL 38WBLPT712BSIII	TATA spare parts
264154660159	W/H TAIL 34 WB LPT712 BSIII	TATA spare parts
264154660164	W/H MAIN LPT712 BS-IIIRHD W/CL.	TATA spare parts
264154660165	W/H MAIN LP712 BS-III RHD W/CL.	TATA spare parts
264154660167	W/H TAIL-34W.B W/PTO-BS-III	TATA spare parts
264154660168	W/H MAIN WITH PTO & INST.CLUST.	TATA spare parts
264154660170	W/H SIDE MARKER LAMP LPT712/38WB	TATA spare parts
264154660172	W/H ENGINE-BS-II RHD -	TATA spare parts
264154660173	W/H TAIL LPT 709/34WB BS-II	TATA spare parts
264154660174	W/H TAIL LPT 709/38WB BS-II	TATA spare parts
264154660177	W/H SIDE MARKER LAMP LPT709/34WB	TATA spare parts
264154660178	W/H SIDE MARKER LAMP LPT709/38WB	TATA spare parts
264154660179	W/H MAIN RHD LP709 W/CLST BS-II	TATA spare parts
264154660180	W/H MAIN RHD LPT709 W/CLST BS-II	TATA spare parts
264154660181	W/H TAIL LP 709/34WB BS II	TATA spare parts
264154660182	W/H TAIL LP 709/38WB BS II	TATA spare parts
264154660186	WIRING HARNESS MAIN	TATA spare parts
264154660187	WIRING HARNESS	TATA spare parts



264154660189	W/H TAIL (34WB) LP712 BS-III	TATA spare parts
264154660190	W/H TAIL (38WB) LP712 BS-III	TATA spare parts
264154660191	W/H MAIN LP/LPT709 EX2 BS-II	TATA spare parts
264154660192	W/H MAIN LPT709 EX2 BS-II	TATA spare parts
264154660193	W/H TAIL LPT709 38WB EX2 RHD	TATA spare parts
264154660197	W/H ENGINE(W/O STARTER RELAY)	TATA spare parts
264154660199	W/H MAIN (LP712/38WB ARMY BUS)	TATA spare parts
264154670101	W/H TAIL (LP712/38WB ARMY BUS)	TATA spare parts
264154670107	W/H TAIL LP709EX BS-II RHD	TATA spare parts
264154670111	W/H TAIL LP 712/42WB EX RHD BUS	TATA spare parts
264154670124	W/H TAIL LPK909/27WB-TYA	TATA spare parts
264154670125	W/H ENGINE LP/T/K 407/709/809/909/	TATA spare parts
264154670126	W/H PIG TAIL L.P.SW.AND B/F BOTTLE-TYA	TATA spare parts
264154670127	WIRING HARNESS PARKING LP/LPT709	TATA spare parts
264154670129	WIRING HARNESS SWITCH WITH PTO	TATA spare parts
264154670130	W/H SWITCH OF LP/LPT709 EXII-TYA	TATA spare parts
264154670143	WIRING HARNESS TAIL	TATA spare parts
264154670151	W/H ENGINE LP/T410/712/912/1112 ESPD	TATA spare parts
264154670153	W/H TAIL LP712/912 38WB ESPEEDO	TATA spare parts
264154670157	W/H TAIL LPT 712/912 34WB ESPEE	TATA spare parts
264154670163	W/H MAIN LP407/709/809/909/1109-TYA	TATA spare parts
264154670165	W/H TAIL LP/LPT 809EX2 38WB W/OPTO	TATA spare parts
264154670178	W/H MAIN LPT809 EX2 EII W/EMOS	TATA spare parts
264154670179	W/H ENGINE LPT809EX2 EII W/EMOS	TATA spare parts
264154670181	W/H SENSOR LP/LPT712 BSIII	TATA spare parts
264154670198	WIRING HARNESS TAIL	TATA spare parts
264154680101	W/H MAIN LP 709 BS-II	TATA spare parts
264154680102	W/H MAIN LPT 709 BS-II -	TATA spare parts
264154680103	W/H TAIL LPT 709/38WB BS-II-	TATA spare parts
264154680104	W/H TAIL LPT 709/34WB BS-II	TATA spare parts
264154680105	W/H TAIL LP 709/38WB BS-II	TATA spare parts
264154680106	W/H TAIL LP 709/34WB BS-II	TATA spare parts
264154680107	W/H SIDE MARKER LAMP LP/T 712/38	TATA spare parts
264154680109	W/H SIDE MARKER LAMP LPT 709/38WB	TATA spare parts
264154680110	W/H SIDE MARKER LAMP LPT 709/34WB	TATA spare parts
264154680111	W/H ENGINE LP/LPT 709 CMVR BS-II-	TATA spare parts
264154680113	W/H MAIN LPT709 EX2	TATA spare parts
264154680120	W/H ENGINE(W/O STARTER RELAY)	TATA spare parts
264154680144	W/H MAIN LP712 BSIII TMML WITH CAT	TATA spare parts
264154680149	W/H H/L AND BLINKER LAMP WITH CAT-6	TATA spare parts
264154680152	W/H MAIN LPT809EX2 EII W/O EMOS	TATA spare parts
264154680155	W/H TAIL	TATA spare parts
264154680156	W/H ENGINE	TATA spare parts
264154680158	W/H MAIN WITH AUTODRAIN LP712 BSIII TMML	TATA spare parts
264154690103	W/H ENGINE(W/O STARTER RELAY)	TATA spare parts
264154690126	W/H PIG TAIL L.P.SW.AND B/F BOTTLE_SFC-M	TATA spare parts
264154690140	W/H ENGINE LPT410/712/912/1112 ESP	TATA spare parts

264154690151	W/H ENGINE LAMP PIGTAIL LPT1109 SL CAB B	TATA spare parts
264154820101	MAIN CABLE SET RHD BUS	TATA spare parts
264154820102	MAIN CABLE SET RHD TRUCK	TATA spare parts
264154820104	CABLE SET FRT TO TAIL 38	TATA spare parts
264154820105	CABLE SET CAB LAMP	TATA spare parts
264154820112	DIODE W/2POLE CONNECTOR	TATA spare parts
264154820120	MAIN CABLE SET	TATA spare parts
264154820131	ASSY M/CABLE SET RHD	TATA spare parts
264154820132	ASSY MAIN CABLE SET RHD	TATA spare parts
264154820140	ASSY CABLE SET	TATA spare parts
264154820141	CABLE SET(FRT-TAIL) 38WB	TATA spare parts
264155100103	MASCOT ASSY	TATA spare parts
264155100105	MASCOT ASSY	TATA spare parts
264155100106	MASCOT ASSY	TATA spare parts
264155100111	MASCOT ASSY BS6	TATA spare parts
264155100112	MASCOT ASSY BS6	TATA spare parts
264155100113	MASCOT ASSY BS6	TATA spare parts
264155100114	MASCOT ASSY BS6	TATA spare parts
264155100115	T-EMBLEM ASSY BS6	TATA spare parts
264155100116	MASCOT ASSY BS6	TATA spare parts
264158304001	RETROREFLECTIVE TRIANGLE-RED	TATA spare parts
264158304009	RETROREFLECTIVE TRIANGLE-RED	TATA spare parts
264158404004	WHEEL CHOCK-ANGLE 18X18X3(709)	TATA spare parts
264158504202	CLAMP - FOR TOOL BAG	TATA spare parts
264158900101	TROLLEY FOR 497D ENGINE	TATA spare parts
264158900102	ASSY.HYD.JACK -4T WITH HANDLE 709TC	TATA spare parts
264158900105	TOOL KIT - DOMESTIC 609/709	TATA spare parts
264158900106	TOOL KIT - EXPORT(609/709)	TATA spare parts
264158900110	ASSY. HYD.JACK 4T	TATA spare parts
264158900201	SPANNER FOR CRANK SHAFT	TATA spare parts
264158902401	SET ENGINE MTG.BRKT.	TATA spare parts
264158902601	DRIFT	TATA spare parts
264158902602	GAUGE SHIFT SLEEVE	TATA spare parts
264158902604	HOLDER FOR COUP FLANGE	TATA spare parts
264158902605	PULLER M/SHAFT & D/SHAFT	TATA spare parts
264158902606	PULLER REV IDLER GR SHAFT	TATA spare parts
264158903201	PULLER SPG PIN REMOVAL	TATA spare parts
264158903301	PULLER FRONT HUB	TATA spare parts
264158903501	PINION DEPTH GAUGE	TATA spare parts
264158904001	ASSY.HYD.JACK(4T) WITH HANDLE	TATA spare parts
264158904003	HYD JACK 4T W/HANDLE	TATA spare parts
264158904201	CLAMP	TATA spare parts
264158904202	ADAPTOR	TATA spare parts
264158904203	ADAPTOR	TATA spare parts
2641600001R40	PARTIALLY FITTED CAB W/O ELECTRICALS	TATA spare parts
264160000101	CAB COMPLT RHD LPT709	TATA spare parts
264160000102	CAB BARE RHD LPT709	TATA spare parts

264160000104	COWL COMPLT RHD LP609	TATA spare parts
264160000105	COWL BARE RHD LP609	TATA spare parts
264160000160	ASSY.BODY SHELL PAINTED-LHD	TATA spare parts
264160000161	ASSY.COWL COMPLETE-RHD (912EX FACELESS)	TATA spare parts
264160000166	ASSY.CAB COMPLETE-RHD(LPT-407EX2 4.4T)	TATA spare parts
264160000186	ASSY COWL SHELL LHD	TATA spare parts
264160000187	ASSY. COWL SHELL PAINTED. LHD.	TATA spare parts
264160000190	ASSY COWL LP407	TATA spare parts
264160000193	COWL BARE RHD LP407	TATA spare parts
264160000194	ASSY. CAB COMPLETE.RHD LPT-407	TATA spare parts
264160000202	ASSY.CAB COMPLETE-RHD 508	TATA spare parts
264160000205	ASSY.COWL COMPLETE-LHD 509 W PS & HD	TATA spare parts
264160000210	ASSY.COWL COMPLETE LP709 FACELESS RHD	TATA spare parts
264160000212	ASSY.COWL SHELL PAINTED RHD	TATA spare parts
264160000222	ASSY.CAB COMPL.-RHD[WITH DELUXE FEATURE]	TATA spare parts
264160000229	ASSY.BODY SHELL PAINTED-RHD	TATA spare parts
264160000232	ASSY CAB COMPLETE LHD(613) HEATING+DMIST	TATA spare parts
264160000236	ASSY.COWL COMPLETE LP613 LHD	TATA spare parts
264160000240	ASSY.CAB COMPLETE-LHD	TATA spare parts
264160000243	ASSY.COWL SHELL PAINTED-RHD	TATA spare parts
264160000246	ASSY.CAB COMPLETE-613 LPT-LHD	TATA spare parts
264160000248	ASSY.COWL SHELL PAINTED-RHD-407 FACELESS	TATA spare parts
264160000262	ASSY.COWL SHELL PAINTED-RHD	TATA spare parts
264160000263	ASSY.COWL COMPLETE-RHD	TATA spare parts
264160000268	ASSY.BODYSHELL PAINTED-LHD	TATA spare parts
264160000275	ASSY.CAB COMPLETE-RHD LPT909	TATA spare parts
264160000276	ASSY.CAB COMPLETE-LPT709/34 EURO1 RHD	TATA spare parts
264160000279	ASSY BODY SHELL PAINTED.-LHD-613 LPT	TATA spare parts
264160000282	ASSY.BODY SHELL PAINTED-RHD-709HD	TATA spare parts
264160000285	ASSY.CAB COMPLETE-RHD 712 EURO-III	TATA spare parts
264160000286	ASSY. CABIN BARE TCAB BS2/3/4	TATA spare parts
264160000286AWBL	BARE CAB-LPT407/709/909 ARTIC WHITE BL	TATA spare parts
264160000286BLUEBL	BARE CAB-LPT407/709/909 BLUE BLW	TATA spare parts
264160000286BRBL	BARE CAB-LPT407/709/909 BRICK RED BL	TATA spare parts
264160000286GBBL	BARE CAB-LPT407/709/909 GOLDEN BROWN BL	TATA spare parts
264160000286GYBL	BARE CAB-LPT407/709/909 GOLDEN YELLOW BL	TATA spare parts
264160000286NBBL	BARE CAB-LPT407/709/909 NEPTUNE BLUE BLW	TATA spare parts
264160000289	ASSY.COWL LP712 COMPLETE-RHD(EURO-III)	TATA spare parts
264160000290	ASSY.COWL SHELL PAINTED-RH(BSIII)LP712EX	TATA spare parts
264160000294	ASSY.CAB COMPLETE-RHD 912 EURO-III	TATA spare parts
264160000301	ASSY.CAB COMPLETE-RHD (LPT-407EX)	TATA spare parts
264160000303	ASSY.COWL COMPLETE-LHD	TATA spare parts
264160000304	ASSY COWL SHELL PAINTED-LHD	TATA spare parts
264160000307	ASSY.COWL COMPLETE-RHD (FACELESS)	TATA spare parts
264160000312	ASSY.COWL LP 410 COMP RHD	TATA spare parts
264160000313	LP 410 EX T/T BS III COWL PAINTED-RHD	TATA spare parts
264160000316	ASSY.CAB COMPLETE-RHD(LPT-410EX)	TATA spare parts

264160000317	ASSY. CABIN BARE LPT 407 EX TCAB BS2/3	TATA spare parts
264160000317AWNB	BARE CAB LPT 407 ARTIC WHITE NB	TATA spare parts
264160000317ICNB	BARE CAB LPT 407 IRISH CREAM NB	TATA spare parts
264160000321	ASSY.COWL COMPLETE-RHD	TATA spare parts
264160000329	ASSY.BODY SHELL PAINTED- 909/809/709EX2	TATA spare parts
264160000333	ASSY.CAB COMPLETE-RHD (912EX W/P.S.)	TATA spare parts
264160000334	ASSY.BODY SHELL PAINTED-RHD	TATA spare parts
264160000337	BODY SHELL COMP LPT 709 EMOS-RHD	TATA spare parts
264160000338	ASSY.BODY SHELL PAINTED-RHD	TATA spare parts
264160000341	ASSY.CAB COMPLT.-RHD (LPK-407EX)	TATA spare parts
264160000342	ASSY.BODY SHELL PAINTED-RHD	TATA spare parts
264160000346	ASSY.CAB COMPLETE-RHD (LPK-909EX)	TATA spare parts
264160000347	ASSY.BODY SHELL PAINTED-RHD LPK 909EX	TATA spare parts
264160000351	ASSY.CAB COMPLETE-LHD (LPT-613)	TATA spare parts
264160000352	ASSY.BODY SHELL PAINTED-LHD	TATA spare parts
264160000364	ASSY.BODY SHELL PAINTED-RHD	TATA spare parts
264160000380	ASSY.CAB COMPLETE-RHD (LPT-809EX BS-II)	TATA spare parts
264160000381	ASSY.COWL COMPLETE-RHD (LP-407 FBV LKO)	TATA spare parts
264160000382	ASSY.COWL COMPLT.-RHD (LP-410EX FBV LKO)	TATA spare parts
264160000383	ASSY.COWL COMPLETE-RHD (LP-909EX BS-II)	TATA spare parts
264160000384	ASSY.COWL COMPLETE-RHD (LP-909 FACELESS)	TATA spare parts
264160000385	ASSY.CAB COMPLETE-RHD(709EX2)	TATA spare parts
264160000386	ASSY.CAB COMPLETE-RHD(809EX2)	TATA spare parts
264160000387	ASSY.CAB COMP.RHD(909EX2 REGULAR L/BODY)	TATA spare parts
264160000388	ASSY.CAB COMPL.-RHD(909EX2 HIGH DECK LB)	TATA spare parts
264160000389	ASSY.CAB COMPL.-RHD(809EX2 HIGH DECK	TATA spare parts
264160000390	ASSY.COWL COMPLT.-RHD (LP-712 ARMY)	TATA spare parts
264160000392	ASSY.CAB COMPLT.-LHD (613 E-III)	TATA spare parts
264160000394	ASSY.BODY SHELL PAINTED-LHD	TATA spare parts
26416000Z160	ASSY.BODY SHELL PAINTED-LHD	TATA spare parts
26416000Z246	ASSY.CAB COMPLETE 613 LHD WITH H.D.	TATA spare parts
26416000Z337	CAB COMPLETE 709 RHD EMOS WITH H.D.	TATA spare parts
26416000Z338	ASSY.BODY SHELL PAINTED-RHD	TATA spare parts
26416000Z351	ASSY.CAB COMPLETE-LHD (LPT-613 RUSSIA)	TATA spare parts
26416000Z352	ASSY.BODY SHELL PAINTED-LHD	TATA spare parts
26416000Z353	ASSY.BODY SHELL COMPLT.-LHD LPT613 CAB	TATA spare parts
26416000Z361	ASSY.BODY SHELL PAINTED-RHD(BARE CAB)	TATA spare parts
26416000Z364	ASSY.BODY SHELL PAINTED-RHD(COTD SHT)	TATA spare parts
26416000Z391	ASSY.COWL COMPLT.-LHD (613 E-III RUSSIA	TATA spare parts
26416000Z392	ASY.CAB COMPT-LHD(613 E-III RUS)COTD SHT	TATA spare parts
26416000Z393	ASSY.COWL SHELL PAINTED-LHD(COATED SHEET	TATA spare parts
26416000Z394	ASSY.BODY SHELL PAINTED-LHD(COATED SHEET	TATA spare parts
264160010118	ASSY.COWL SHELL PAINTED-LHD 509 PS & HD	TATA spare parts
264160010132	ASSY. CAB COMPL. LPT509M LHD	TATA spare parts
264160010133	ASSY BODY SHELL PAINTED RHD(LPT-407/508)	TATA spare parts
264160010134	ASSY. BODY SHELL PAINTED LHD-LPT-407	TATA spare parts
264160010149	ASSY.COWL COMPLETE LP713 RHD	TATA spare parts

264160010150	ASSY.CAB COMPLETE LPT713 RHD	TATA spare parts
264160010151	ASSY.BODY SHELL PAINTED-RHD LPT713	TATA spare parts
264160010153	ASSY.COWL SHELL PAINTED-RHD	TATA spare parts
264160010168	ASSY.COWL SHELL PAINTED-LHD	TATA spare parts
264160010172	ASSY.COWL COMPLETE-LHD	TATA spare parts
264160010187	ASSY.BODY SHELL PAINTED-RHD LPT713	TATA spare parts
264160010188	ASSY.BODY SHELL COMPLETE RHD	TATA spare parts
264160010194	ASSY.CAB COMPLT.-RHD	TATA spare parts
264160010226	DRIVER STATION ASSY W/O PAINTED BS6	TATA spare parts
264160010228	DRIVER STATION ASSY WITH CED COATING BS6	TATA spare parts
264160010229	DRIVERSTATIONASSYWITHCEDCOATING BS6	TATA spare parts
264160010243	DRIVER STATION ASSY WITH CED COATING BS6	TATA spare parts
264160010260	DRIVERSTATIONASSYWITHCEDCOATING BS6	TATA spare parts
264160010261	DRIVER STATION ASSY W/O PAINTED BS6	TATA spare parts
264160020103	ASSY.COWL SHELL PAINTED-RHD (909 CNG)	TATA spare parts
264160020107	ASSY.CAB COMPLETE-RHD (813EX2 EXPORT)	TATA spare parts
264160020128	ASSY.COWL SHELL PAINTED-RHD (LP407 BSII)	TATA spare parts
264160020136	ASSY.CAB COMPLETE-RHD (LPT-410 EX2)	TATA spare parts
264160020137	ASSY.CAB COMPLETE 913 EX2 WITH H.D. EXPO	TATA spare parts
264160020140	ASSY. CABIN BARE CLB PTOP TCAB BLW BS3/4	TATA spare parts
264160020140AWBL	BARE CAB-LPT407/709/909 PTOP AW BL	TATA spare parts
264160020147	ASSY.CAB COMPLETE-RHD (LPK-912 BS-III)	TATA spare parts
264160020148	ASSY.BODY SHELL PAINTED-RHD	TATA spare parts
264160020158	ASSY.COWL SHELL PAINTED-RHD	TATA spare parts
264160020162	ASSY.BODY SHELL PAINTED-RHD(412EX BS-IV)	TATA spare parts
264160020166	PARTIALLY FITTED CAB W/O ELECTICALS & CO	TATA spare parts
264160020167	CAB COMPLETE-RHD (909 CNG BS-IV)	TATA spare parts
264160020168	ASSY. CABIN BARE CNG TCAB BLW BS4	TATA spare parts
264160020168BRBL	BARE CAB-LPT909CNG BRICK RED BLW	TATA spare parts
264160020168GBBL	BARE CAB-LPT909CNG GOLDEN BROWN BLW	TATA spare parts
264160020173	ASSY.COWL SHELL PAINTED-RHD (407CNG BS4)	TATA spare parts
264160020176	PARTIALLY FITTED CAB W/O ELECT&CONTROLS	TATA spare parts
264160020177	ASSY. BODYSHELL PAINTED-RHD BS4	TATA spare parts
264160020177AWBL	BARE CAB-LPT407CNG ARTIC WHITE BLW	TATA spare parts
264160020182	ASSY CAB COMPLETE-LHD	TATA spare parts
264160020182CJO	ASSY CAB COMPLETE-LHD	TATA spare parts
264160020182SJ	ASSY CAB COMPLETE-LHD SPARE PART	TATA spare parts
264160020183	ASSY BODY SHELL PAINTED-LHD	TATA spare parts
264160020190	ASSY.CAB COMPLETE 407 LHD EX2	TATA spare parts
264160020191	ASSY.BODY SHELL PAINTED LHD(LPT-407)	TATA spare parts
264160020192	ASSY.BODY SHELL COMPLETE-LHD(LPT-407)	TATA spare parts
264160020194	ASSY.CAB COMPL.-RHD(709 CNG BS-IV)	TATA spare parts
264160020199	ASSY.CAB COMPLETE-RHD (EX2 BS-III)	TATA spare parts
26416002Z107	ASSY.CAB COMPLETE-RHD (813EX2 EXPORT)	TATA spare parts
26416002Z109	ASSY.CAB COMPLETE-RHD (813EX2 EXPORT)(CO	TATA spare parts
26416002Z123	ASSY.CAB COMPLETE 809 EX2 WITH H.D. EXPO	TATA spare parts
264160030102	ASSY CAB COMPLETE-RHD(LPT-909EX2 BS-III)	TATA spare parts

264160030103	ASSY.CAB COMPLT.-RHD(LPT-709H EX2 BS-III	TATA spare parts
264160030114	PARTIALLY FITTED CAB W/O ELECT.&CONTROLS	TATA spare parts
264160030115	ASSY CAB COMPLETE-RHD (909 EX2 BS-IV)	TATA spare parts
264160030129	ASSY.COWL SHELL CED COATED-RHD	TATA spare parts
264160030130	ASSY.CAB COMPLT-RHD(LPT-909H EX2 BS-3)	TATA spare parts
264160030147	ASSY.CAB COMPLETE-RHD (MFIP)	TATA spare parts
264160030148	ASSY.BODY SHELL PAINTED-RHD (MFIP)	TATA spare parts
264160030151	CAB COMPLETE-RHD(709EX2 BSIII MFIP	TATA spare parts
264160030152	ASSY.BODY SHELL PAINTED-RHD(709 BS-III M	TATA spare parts
264160030155	CAB COMPLETE-810/910EX2 BS-III MFIP	TATA spare parts
264160030156	ASSY CAB CMPLT-RHD(913EX2 E-II W/HDEMOS)	TATA spare parts
264160030171	ASSY. CABIN KIT W/O ELECT&CONTROLS BS3	TATA spare parts
264160030175	ASSY. CABIN KIT W/O ELECT&CONTROLS BS4	TATA spare parts
264160030175BRBL	CAB PARTIALLY FITTED LPT1109 BR BLW	TATA spare parts
264160030175GBBL	CAB PARTIALLY FITTED LPT1109 GB BLW	TATA spare parts
264160030175GBNB	CAB PARTIALLY FITTED LPT1109 GB NB	TATA spare parts
264160030179	CAB SHELL PAINTED	TATA spare parts
264160030183	ASSY. CABIN BARE LPK 912 BS3/4	TATA spare parts
264160030183BRBL	BARE CAB-LPK912 BRICK RED BLW	TATA spare parts
264160030183RRBL	BARE CAB-LPK912 RUBY RED BLW	TATA spare parts
264160030184	PARTIALLY FITTED CAB W/O ELECT&CONTROLS	TATA spare parts
264160030185	BODY SHELL ASSY PAINTED	TATA spare parts
264160030185AWBL	BARE CAB-LPT/LPK407 ARTIC WHITE BLW	TATA spare parts
264160030189	CAB ASSY 407 LPT BSIV	TATA spare parts
264160030194	CAB ASSY 912 LPK BSIV	TATA spare parts
26416003Z101	ASSY.CAB COMPLETE-LHD	TATA spare parts
264160040125	BODY SHELL ASSY PAINTED BS6	TATA spare parts
264160040125AWBL	BARE CAB LPT 1412 ARTIC WHITE BLW	TATA spare parts
264160040125BRBL	BARE CAB LPT 1412 BRICK RED BLW	TATA spare parts
264160040125NBBL	BODY SHELL ASSY PAINTED NEPT-BLUE BS6	TATA spare parts
264160040125TWBL	BARE CAB LPT 1412 TITANIUM WHITE BLW BS6	TATA spare parts
264160040137	BODY SHELL ASSY PAINTED BS6	TATA spare parts
264160040137BRBL	BARE CAB LPT 1512 BRICK RED BLW	TATA spare parts
264160040137FBBL	BARE CAB LPT 1512 FAWN BEIGE BLOWER BS6	TATA spare parts
264160040137TWBL	BARE CAB LPT 1512 TITANIUM WHITE BLW BS6	TATA spare parts
264160040151	BODY SHELL ASSY PAINTED BS6	TATA spare parts
264160040154	BODY SHELL ASSY PAINTED BS6	TATA spare parts
264160100104	PANEL CORNER BOTTOM LH	TATA spare parts
264160100105	PANEL CORNER BOTTOM RH	TATA spare parts
264160100106	CROSS MEMBER D/BOARD RHD	TATA spare parts
264160100108	SUPPORT FRONT GRILL BS1/2/3/4	TATA spare parts
264160100112	CORNER PANEL FR OUTER LH	TATA spare parts
264160100113	CORNER PANEL FR OUTER RH	TATA spare parts
264160100114	ASSY.PANEL INNER W/S BOTTOM	TATA spare parts
264160100115	ASSY PANEL OUTER W/S BOTTOM	TATA spare parts
264160100126	OUTER PANEL CORNER FR LH	TATA spare parts
264160100127	OUTER PANEL CORNER FR RH	TATA spare parts

264160100129	ASSY GUSSET LH [FRONT REINFORCEMENT]	TATA spare parts
264160100130	ASSY GUSSET RH [FRONT REINFORCEMENT]	TATA spare parts
264160100131	ASSY.PANEL INNER W/S BOTTOM LHD	TATA spare parts
264160100135	ASSY INNER PANEL & FIRE WALL RHD	TATA spare parts
264160100140	ASSY. PANEL INNER TOP	TATA spare parts
264160100145	ASSY. SUPORT (D.B.CROSS MEMBER)	TATA spare parts
264160100178	ASSY.CROSS MEMBER-LHD (DASH BOARD)	TATA spare parts
264160100179	ASSY.INNER PANEL & FIRE WALL-RHD	TATA spare parts
264160100181	ASSY.INNER PANEL TOP WITH REINFORCEMENT	TATA spare parts
264160100182	ASSY_INNER PANEL _ FIRE WALL_RHD	TATA spare parts
264160100185	ASSY FIRE WALL	TATA spare parts
264160100203	BRACKETASSYAUDIOMTGRH BS6	TATA spare parts
264160100204	BRACKETASSYAUDIOMTGLH BS6	TATA spare parts
264160106301	MEL SHEET(FLOOR MIDDLE REAR TOP)	TATA spare parts
264160106303	MEL SHEET (FLOOR MIDDLE FRONT)	TATA spare parts
264160106304	MEL SHEET (FLOOR SIDE RH)	TATA spare parts
264160106305	MEL SHEET (FLOOR SIDE LH)	TATA spare parts
264160106306	MEL SHEET(FLOOR MIDDLE REAR SIDE)	TATA spare parts
264160106307	MEL SHEET(FLOOR MIDDLE CENTRE SIDE)	TATA spare parts
264160106308	MEL SHEET (FLOOR MIDDLE CENTRE TOP)	TATA spare parts
264160106947	ANGLE BS6	TATA spare parts
264160108205	PANEL OUTER(W/S BOTTOM) BS6	TATA spare parts
264160108207	PANEL CORNER BOTTOM LH	TATA spare parts
264160108208	PANEL CORNER BOTTOM RH	TATA spare parts
264160108212	SIDE SUPPORT LH (CROSS MEMBER D.B.)	TATA spare parts
264160108213	SIDE SUPPORT RH (CROSS MEMBER D.B.)	TATA spare parts
264160108217	STEP BOARD	TATA spare parts
264160108218	SUPPORT FRONT(GRILL) BS6-PH2	TATA spare parts
264160108230	GUSSET(PANEL INNER W/S BOTTOM)	TATA spare parts
264160108231	SUPPORT (D.B.CROSS MEMBER)	TATA spare parts
264160108236	PANEL INNER TOP	TATA spare parts
264160108237	PANEL OUTER TOP	TATA spare parts
264160108244	OUTER PANEL CORNER (FRONT) RH	TATA spare parts
264160108255	SUPPORT LH [FRONT REINFORCEMENT]	TATA spare parts
264160108256	SUPPORT RH [FRONT REINFORCEMENT]	TATA spare parts
264160108262	SUPPORT CENTER-REAR BS6-PH2	TATA spare parts
264160108268	SUPPORT CENTRE-END-LH(WITHOUT HOLE)-RW	TATA spare parts
264160108269	SUPPORT CENTRE-END-RH(WITHOUT HOLE)-RW	TATA spare parts
264160108270	SUPPORT CENTRE END L.H.(REAR WALL)	TATA spare parts
264160108271	SUPPORT CENTRE END R.H.(REAR WALL)	TATA spare parts
26416010Z193	ASSY.INNER PANEL & FIRE WALL-RHD	TATA spare parts
264160110105	ASSY.SUPPORT FRONT (GRILL)-613LHD RUSSIA	TATA spare parts
264160110107	SUPPORT ASSY FRONT CANOPY STRUCTURE MTG	TATA spare parts
264160110114	ASSY.STR.COMP.FACELESS WITH AED BS-II	TATA spare parts
264160110115	ASSY.STR.COMPLETE FACELESS BS-II	TATA spare parts
264160110121	ASSY.STRUCTURE WELDED COMPT.FACELESS-LHD	TATA spare parts
264160110123	ASSY.STRUCTURE COMPT.FACELESS-LHD E-II	TATA spare parts

264160110128	ASSY.STRUCTURE COMPLETE FACELESS BS-II	TATA spare parts
264160110135	ASSY.STRUCTURE COMP 410 LP M/POLO BS III	TATA spare parts
264160110140	ASSY.SUPPORT REAR(CANOPY STRUCTURE MTG.)	TATA spare parts
264160110144	ASSY.INNER PANEL & FIRE WALL-RHD	TATA spare parts
264160110147	CROSS MEMBER ASSY DASHBOARD MTG BS6	TATA spare parts
264160110149	ASSY.INNER PANEL & FIRE WALL-RHD	TATA spare parts
264160110153	ASSY.STR.COMPLETE FACELESS BS-IV	TATA spare parts
264160110155	ASSY.STR. WELDED COMP.FACELESS-RHD BS-IV	TATA spare parts
264160110158	ASSY STR.COMPLETE FACELESS RHD EURO-II	TATA spare parts
264160110160	ASSY.STRUCTURE COMPLETE FACELESS BS-IV	TATA spare parts
264160110166	ASSY.CROSS.MEMBER-LHD	TATA spare parts
264160110179	LP909 ASSY.STR.COMP.FACELESS A.E.D BS-IV	TATA spare parts
264160110180	LP909 ASSY.STR.COMP.FACELESS	TATA spare parts
264160110181	ASSY STR COMP FACELESS LHD E1	TATA spare parts
264160110183	ASSY.STR.COMP.FACELESS WITH AED CNG BS-I	TATA spare parts
264160110198	ASSY. STR. WELDED COMPLETE FACELESS RHD	TATA spare parts
264160110227	HEADLAMP ASSY LH BS6	TATA spare parts
264160110228	HEADLAMP ASSY RH BS6	TATA spare parts
264160110230	BRACKET ASSY ACCELERATOR PEDAL MTG BS6	TATA spare parts
264160118203	STEP BOARD	TATA spare parts
264160118205	VERTICAL SUPPORT-DASH BOARD CROSS MEMBE	TATA spare parts
264160118208	BRACKET (HYD.TANK MTG.)	TATA spare parts
264160118221	REINFORCEMENT CONTROLS-BOTTOM BS6	TATA spare parts
26416011Z111	ASSY.INNER PANEL & FIRE WALL-LHD	TATA spare parts
264160120112	ASSY STRUCTURE WELDED FACELESS RHD	TATA spare parts
264160120116	ASSY STRUCTURE COMPLETE FACELESS BS-III	TATA spare parts
264160120117	ASSY STR COMPL F-LESS 4SP MFIP BSIII-CED	TATA spare parts
264160120148	ASSY STR COMPL F-LESS 497 MFIP BSIII-CED	TATA spare parts
264160120177	INNER PANEL & FIREWALL ASSY RHD	TATA spare parts
264160120190	CROSS MEMBER ASSY	TATA spare parts
264160120192	BRACKET ASSY BS6	TATA spare parts
264160120197	FES ASSY	TATA spare parts
264160127106	HEADLAMP PLATE SUPPORT BS6	TATA spare parts
264160127118	HEADLAMP PLATE SUPPORT BS6	TATA spare parts
264160127124	ANGLE SUPPORT BS6-PH2	TATA spare parts
264160128271	COVER PLATE BS6	TATA spare parts
264160128282	BRACKET BS6	TATA spare parts
264160130112	FES	TATA spare parts
264160130114	FES ASSY WITH CED	TATA spare parts
264160130154	INNER PANEL & FIREWALL ASSY BS6	TATA spare parts
264160130159	ANGLE ASSY BS6	TATA spare parts
264160130160	CANOPY MTG STRUCTURE ASSY BS6	TATA spare parts
264160130171	INNER PANEL & FIREWALL ASSY BS6	TATA spare parts
264160133302	BRACKET SNORKEL MTG BS6-PH2	TATA spare parts
264160138213	PLATE STEERING COVER BS6	TATA spare parts
264160138214	FRONT PANEL BS6	TATA spare parts
264160138236	PLATE BS6	TATA spare parts



264160200106	COWL ASSY PAINTED	TATA spare parts
264160CK0199	CAB LPT 709E/34(BS I)-SPD	TATA spare parts
264161000179	ASSY.SUBSTR.WITH FLOOR W/O STEP PNL.-LHD	TATA spare parts
264161000185	ASSY SUB STUCTURE WITH FLOORE & W/O STEP	TATA spare parts
264161000186	ASSY.SUBSTR.WITH FLOOR W/O STEP PNL.-RHD	TATA spare parts
264161000187	ASSY.SUBSTR.WITH FLOOR W/O STEP PNL.-LHD	TATA spare parts
264161000243	ASSY.SUBSTR.WITH FLOOR W/O STEP PANEL	TATA spare parts
264161000247	ASSY SUBSTRUCTURE WITH FLOOR-RHD	TATA spare parts
264161000248	ASSY SUBSTRUCTURE WITH FLOOR-RHD	TATA spare parts
264161000284	SUBSTRUCTURE ASSY WITH FLOOR BS6	TATA spare parts
264161000291	SUBSTRUCTURE ASSY WITH FLOOR BS6	TATA spare parts
264161100101	COVER PLATE ASSY LH	TATA spare parts
264161100102	COVER PLATE ASSY RH	TATA spare parts
264161100123	ASSY. BRACKET BOTTOM LH (MUD FLAP MTG.)	TATA spare parts
264161100125	ASSY. BRACKET BOTTOM RH (MUD FLAP MTG.)	TATA spare parts
264161200123	REINFORCEMENT ASSY SEAT MTG BS6-PH2	TATA spare parts
264161600109	ASSY.FLOOR MIDDLE-RHD	TATA spare parts
264161600111	ASSY FLOOR PANEL SIDE LH	TATA spare parts
264161600112	ASSY.FLOOR PANEL SIDE RH RHD	TATA spare parts
264161600114	ASSY.FLOOR PANEL REAR-VERTICAL	TATA spare parts
264161600136	ASSY. BRKT. STALK MTG.	TATA spare parts
264161600191	ASSY.STEP PANEL INNER-LH	TATA spare parts
264161600192	ASSY.STEP PANEL INNER-RH	TATA spare parts
264161608212	CORNER PANEL INNER REAR BOTTOM-LH	TATA spare parts
264161608213	CORNER PANEL INNER REAR BOTTOM RH BS6	TATA spare parts
264161608216	SIDE PANEL VERTICAL LH	TATA spare parts
264161608217	SIDE PANEL VERTICAL RH	TATA spare parts
264161608218	COVER PLATE	TATA spare parts
264161608219	REINFORCEMENT	TATA spare parts
264161608220	REINFORCEMENT-GEAR SHIFT LEVER BS6	TATA spare parts
264161608255	STEP PANEL INNER LHBS6	TATA spare parts
264161608256	STEP PANEL INNER RH. BS6	TATA spare parts
264161610109	ASSY.BASE SUPPORT	TATA spare parts
264161610115	ASSY.BASE SUPPORT	TATA spare parts
264161620128	ASSY FOOTREST COMPLETE	TATA spare parts
264161628250	REINFORCEMENT FLOOR LH BS6-PH2	TATA spare parts
264161628251	REINFORCEMENT FLOOR RH BS6-PH2	TATA spare parts
264162200101	ASSY.SUPPORT	TATA spare parts
264162200109	BRACKET ASSY STEERING COLUMN TO FIREWALL	TATA spare parts
264162200112	SUPPORT TUBE ASSY CCB BS6-PH2	TATA spare parts
264162600106	ASSY.FIRE WALL COMPLETE-RHD	TATA spare parts
264162608209	COVER (WHEEL BOX)	TATA spare parts
264162608236	PANEL FIRE WALL(RHD)	TATA spare parts
264162608254	REINFORCEMENT CONTROLS-TOP BS6	TATA spare parts
264162610112	PANEL ASSY FIREWALL BS6	TATA spare parts
264163000101	ASSY. SIDE WALL LH RHD CAB BS1/2/3/4	TATA spare parts
26416300010135	CED ASSY.SIDE WALL LH COMPLETE RHD [CAB]	TATA spare parts

264163000102	ASSY. SIDE WALL RH RHD CAB BS1/2/3/4	TATA spare parts
26416300010235	CED ASSY.SIDE WALL RH COMPLETE RHD [CAB]	TATA spare parts
264163000103	SIDE WALL LH RHD COWL	TATA spare parts
26416300010320	ASSY SIDE WALL LH FOR CED COATING COWL	TATA spare parts
264163000104	SIDE WALL RH RHD COWL	TATA spare parts
26416300010420	ASSY SIDE WALL RH FOR CED COATING -COWL	TATA spare parts
264163000105	ASSY.SIDE WALL COMPLETE LH-LHD [CAB]	TATA spare parts
264163000106	ASSY.SIDE WALL COMPLETE RH-LHD [CAB]	TATA spare parts
264163000107	ASSY.SIDE WALL COMPLETE LH-LHD [COWL]	TATA spare parts
264163000108	ASSY.SIDE WALL COMPLETE RH-LHD [COWL]	TATA spare parts
264163000109	ASSY.SIDE WALL COMPLETE LH(RHD) CAB	TATA spare parts
264163000110	ASSY. SIDE WALL COMPLETE-LH (RHD) COWL	TATA spare parts
264163000111	ASSY. SIDE WALL COMPLETE LH	TATA spare parts
264163000112	ASSY. SIDE WALL COMPLETE RH	TATA spare parts
26416300Z115	ASSY.SIDE WALL COMPLETE-LH RHD	TATA spare parts
26416300Z116	ASSY SIDE WALL COMPLETE-RH RHD	TATA spare parts
264163100101	ASSY.REINFORCEMENT - DOOR POST FRONT LH	TATA spare parts
264163100102	ASSY REINFORCEMENT - DOOR POST FRONT RH	TATA spare parts
264163100106	ASSY.DOOR POST FRONT LH RHD [CAB]	TATA spare parts
264163100107	ASSY.DOOR POST FRONT RH RHD [CAB]	TATA spare parts
264163100114	PANEL OUTER LH RHD COWL	TATA spare parts
264163100115	ASSY.PANEL OUTER SIDE RH RHD [COWL]	TATA spare parts
264163100123	FENDER OUTER LH	TATA spare parts
264163100124	FENDER OUTER RH	TATA spare parts
264163100125	FENDER INNER LH	TATA spare parts
264163100126	FENDER INNER RH	TATA spare parts
264163100127	ASSY.FENDER COMPLETE COWL LH	TATA spare parts
264163100128	ASSY. FENDER	TATA spare parts
264163100129	FENDER COMPLETE LH	TATA spare parts
264163100130	FENDER COMPLETE RH	TATA spare parts
264163100131	ASSY FENDER INNER LH	TATA spare parts
264163100132	ASSY FENDER INNER RH	TATA spare parts
264163100136	ASSY NUT PLATE	TATA spare parts
264163100138	ASSY.BRACKET TOP [SEAT BELT]BS6	TATA spare parts
264163100139	ASSY BRACKET BOTTOM LH [SEAT BELT MTG]	TATA spare parts
264163100140	ASSY.BRACKET BOTTOM R.H.[SEAT BELT MTG]	TATA spare parts
264163100151	ASSY DOOR POST REAR WITH STRIKER LH	TATA spare parts
264163100152	ASSY DOOR POST REAR WITH STRIKER RH	TATA spare parts
264163100173	ASSYPILLAR FILLER STEP PANEL BS6-PH2	TATA spare parts
264163100174	ASSYPILLAR FILLER SIDE WALL (REAR) BS6-P	TATA spare parts
264163108201	DOOR POST FRONT LH	TATA spare parts
264163108202	DOOR POST FRONT RH	TATA spare parts
264163108210	REINFORCEMENT COVER LH BS6-PH2	TATA spare parts
264163108211	RAIN CHANNEL FRONT LH	TATA spare parts
264163108212	RAIN CHANNEL FRONT RH	TATA spare parts
264163108213	REINFORCEMENT COVER RH BS6-PH2	TATA spare parts
264163108219	DOOR POST FRONT LH-RHD.	TATA spare parts

264163108220	DOOR POST FRONT RH-RHD.	TATA spare parts
264163108227	CLOSING PLATE BOTTOM LHç BS6	TATA spare parts
264163108228	CLOSING PLATE BOTTOM RHç BS6	TATA spare parts
264163108239	PANEL OUTER TOP DOOR POST LH RHD [COWL]	TATA spare parts
264163108240	PANEL OUTER TOP-DOOR POST RH RHD [COWL]	TATA spare parts
264163108241	PANEL OUTER TOP-DOOR POST LH RHD [CAB]	TATA spare parts
264163108242	PANEL OUTER TOP-DOOR POST RH RHD [CAB]	TATA spare parts
264163108243	DOOR POST REAR-LH	TATA spare parts
264163108244	DOOR POST REAR-RH	TATA spare parts
264163108245	FENDER OUTER LH	TATA spare parts
264163108248	FENDER INNER RH	TATA spare parts
264163108251	STEP PANEL OUTER LH	TATA spare parts
264163108252	STEP PANEL OUTER RH	TATA spare parts
264163108253	FENDER OUTER LH	TATA spare parts
264163108254	FENDER OUTER RH	TATA spare parts
264163108257	SIDE REINFORCEMENT LH BS6-PH2	TATA spare parts
264163108258	SIDE REINFORCEMENT RH BS6-PH2	TATA spare parts
264163108264	RETAINER (NUT PLATE)	TATA spare parts
264163108273	ANCHOR PLATEBS6	TATA spare parts
264163600101	ASSY.PANEL INNER W/S SIDE LH	TATA spare parts
264163600102	ASSY.PANEL INNER W/S SIDE RH	TATA spare parts
264163600103	ASSY.PANEL INNER POST SIDE TOP RH	TATA spare parts
264163600108	ASSY.PANEL INNER W/S SIDE LH	TATA spare parts
264163600109	ASSY.PANEL INNER W/S SIDE RH	TATA spare parts
264163600110	ASSY.PANEL INNER POST SIDE TOP LH LHD	TATA spare parts
264163600112	ASSY.SIDE PANEL LH	TATA spare parts
264163600113	ASSY.SIDE PANEL RH	TATA spare parts
264163600114	BRACKET ASSY LHç BS6	TATA spare parts
264163600115	BRACKET ASSY RHBS6	TATA spare parts
264163600122	ASSY.PANELINNERPOSTSIDETOP-LH(RHD) BS6	TATA spare parts
264163600123	ASSY.PILLAR FILLER BS6	TATA spare parts
264163600127	BRACKET ASSY-LH BS6	TATA spare parts
264163600128	BRACKET ASSY-RH BS6	TATA spare parts
264163608203	SIDE RAIL INNER-LH BS6	TATA spare parts
264163608204	SIDE RAILINNER RH BS6	TATA spare parts
264163608205	PANEL INNER CORNER REAR-LH BS6	TATA spare parts
264163608206	PANEL INNER CORNER REAR-RH BS6	TATA spare parts
264163608211	RAIN CHANNEL CORNER REAR LH	TATA spare parts
264163608212	RAIN CHANNEL CORNER REAR RH	TATA spare parts
264163608214	RAIN CHANNEL-SIDE	TATA spare parts
264163608221	SIDE RAIL OUTER TOP LH	TATA spare parts
264163608222	SIDE RAIL OUTER TOP RH	TATA spare parts
264163608223	PANEL INNER W/S SIDE LH	TATA spare parts
264163608224	PANEL INNER W/S SIDE RH	TATA spare parts
264163608235	ROOF CLIP	TATA spare parts
264163700101	ASSY.PANEL OUTER CORNER REAR-LH	TATA spare parts
264163700102	ASSY.PANEL OUTER REAR RH	TATA spare parts

264163708207	PANEL OUTER CORNER REAR LH	TATA spare parts
264163708208	PANEL OUTER CORNER REAR RH	TATA spare parts
264164200105	BRACKET ASSY BS6-PH2	TATA spare parts
264164200108	BRACKET ASSY STROAGE BIN MTG LH BS6-PH2	TATA spare parts
264164200109	BRACKET ASSY STROAGE BIN MTG RH BS6-PH2	TATA spare parts
264164208202	SUPPORT VERTICAL (REAR WALL) BS6	TATA spare parts
264164208205	BRACKET REAR WALL TRIM MTG UPPER BS6-PH2	TATA spare parts
264164208211	BRACKET REAR WALL TRIM MTG BS6-PH2	TATA spare parts
264164700104	ASSY.REAR WALL(WITHOUT CLIP)	TATA spare parts
264164700105	ASSY.REAR WALL(LPT-613)	TATA spare parts
264164708201	CENTRE PANEL-REAR WALL	TATA spare parts
264164708202	RAIN CHANNEL- REAR WALL	TATA spare parts
264164708207	RAIN CHANNEL (REAR WALL)	TATA spare parts
264165100105	BRACKET ASSY SUN VISOR MTG RH BS6-PH2	TATA spare parts
264165100106	BRACKET ASSY SUN VISOR MTG LH BS6-PH2	TATA spare parts
264165108202	ROOF BOW MEMBER BS6	TATA spare parts
264165700101	ROOF PANEL RHD	TATA spare parts
264165700102	ASSY.ROOF PANEL RHD BS6	TATA spare parts
264165700103	ROOF ASSY WITH ROOF BOW BS6	TATA spare parts
264165708203	ROOF PANEL RHD	TATA spare parts
264167102301	W/S GLASS LPT NON.LAM 5MM	TATA spare parts
264167102302	W/S GLASS LP NON.LAM 5MM	TATA spare parts
264167102303	WIND SHIELD GLASS(5.76 THK.)NON-E CERT.	TATA spare parts
264167102304	WIND SHILD GLASS LAM. NON E CERT.	TATA spare parts
264167102305	WIND SCREEN GLASS (LAM.`E CERT) BS1- 4	TATA spare parts
264167102306	WIND SCREEN GLASS(5.76 THK.)-`E`CERT.	TATA spare parts
264167106301	RUB MOULD W/S GLASS	TATA spare parts
264167106302	RUB MOULD N/LAM W/SHIELD	TATA spare parts
264167106303	RUB MOULD LPT LAM W/SHIEL	TATA spare parts
264167106304	RUB MOULD LP LAM W/SHIELD	TATA spare parts
264167106305	RUBBER MOULD W/S GLASS 5.76THK BS1/2/3/4	TATA spare parts
264167106305AE	RUBBER MLD (W/S GLSS ) -2523	TATA spare parts
264167802301	GLASS REAR WINDOW	TATA spare parts
264167806301	RUB MOULD RR WINDOW LPT	TATA spare parts
264168400107	KIT FLOOR MAT	TATA spare parts
264168400110	ASSY FLOOR MAT-RHD LPT-LCV BS-IV	TATA spare parts
264168400111	FLOOR MAT SET	TATA spare parts
264168400113	ASSY PVC FLOOR MAT-RHD	TATA spare parts
264168400116	ASSY.PVC FLOOR MAT-RHD(709)	TATA spare parts
264168400117	ASSY.PVC FLOOR MAT-RHD(407 BS-	TATA spare parts
264168400118	ASSY.PVC FLOOR MAT-RHD	TATA spare parts
264168400119	ASSY.PVC FLOOR MAT-RHD(1109)	TATA spare parts
264168400157	ASSY PVC FLOOR MAT-LHD	TATA spare parts
264168401801	FLOOR MAT SET RHD LP609	TATA spare parts
264168401803	FLOOR MAT LPT709E RHD	TATA spare parts
264168406321	FLOOR MAT-RHD	TATA spare parts
264168406329	FLOOR MAT-RHD	TATA spare parts

264168406330	FLOOR MAT-LHD	TATA spare parts
264168406341	FLOOR MAT-RHD	TATA spare parts
264168406342	FLOOR MAT-RHD	TATA spare parts
264168406345	FLOOR MAT RH	TATA spare parts
264168406351	FLOOR MAT MIDDLE	TATA spare parts
264168406353	FLOOR MAT LH	TATA spare parts
264168406354	FLOOR MAT RH	TATA spare parts
264168406376	FLOOR MATPERCMIDDLE	TATA spare parts
264168406377	FLOOR MATPERCRH	TATA spare parts
264168406378	FLOOR MATPERCLH	TATA spare parts
264168900112	BRACKET DASH BOARD MTG	TATA spare parts
264168900113	BRACKET DASH BOARD MTG LH	TATA spare parts
264168900114	BRACKET DASH BOARD MTG RH	TATA spare parts
264168900126	DASH BOARD RHD COMPLT	TATA spare parts
264168900127	DASH BOARD LHD	TATA spare parts
264168900128	REINFORCEMENT MIDDLE LH	TATA spare parts
264168900129	REINFORCEMENT MIDDLE RH	TATA spare parts
264168900131	REINF INSIDE GLOVE BOX	TATA spare parts
264168900132	REINF OUTSIDE GLOVE BOX	TATA spare parts
264168900133	REINF COMP INSIDE RHD	TATA spare parts
264168900134	REINF COMP OUTSIDE	TATA spare parts
264168900135	REINFORCEMENT TOP	TATA spare parts
264168900141	GLOVE BOX COMPLETE	TATA spare parts
264168900142	CRASH PAD CENTRE RHD	TATA spare parts
264168900143	CRASH PAD RH RHD	TATA spare parts
264168900146	ASSY CRASH PAD SIDE	TATA spare parts
264168900147	ASSY BRACKET LH [DASH BOARD MTG LHD]	TATA spare parts
264168900151	VENTILATION NOZZLE	TATA spare parts
264168900158	ASSY.REINFORCEMENT (DBOARD) - LHD	TATA spare parts
264168900159	ASSY.REINFORCEMENT (D BOARD) - RHD.	TATA spare parts
264168900160	ASSY.BRACKET DASHBOARD MTG.	TATA spare parts
264168900166	ASSY KIT FOR NACELLE	TATA spare parts
264168900167	ASSY.DASHBOARD COMP. LHD	TATA spare parts
264168900169	BRACKET ASSYPERCDASHBOARD MTGPERCLH	TATA spare parts
264168900176	ASSY.REINFORCEMENT-TOP	TATA spare parts
264168900180	ASSY.DASHBOARD COMPLETE-RHD	TATA spare parts
264168900184	BRACKET ASSY ARMATURE MTG	TATA spare parts
264168900186	ASSY.BRACKET (AIR DISTRIBUTOR TO VENT)	TATA spare parts
264168900188	ASSY.BRACKET (REAR DUCT)	TATA spare parts
264168900194	ASSY. DASHBOARD BS2/3	TATA spare parts
264168900195	ASSY GLOVE BOX COMPLETE GREY PIGMENTED	TATA spare parts
264168900196	ASSY.BKT.(DASHBOARD MTG.)-LH RHD	TATA spare parts
264168900198	ASSY. GLOVE BOX COMPLETE	TATA spare parts
264168900204	GLOVE BOX ASSY	TATA spare parts
264168900205	BRACKET ASSY GLOVE BOX MTG	TATA spare parts
264168900206	BRACKET ASSY GLOVE BOX MTG	TATA spare parts
264168900215	BRACKET ASSY HVAC MTG	TATA spare parts

264168900216	BRACKET ASSY HVAC MTG	TATA spare parts
264168900217	BRACKET ASSY HVAC MTG	TATA spare parts
264168900218	BRACKET ASSY HVAC MTG	TATA spare parts
264168900219	BRACKET ASSY HANDBRAKE VALVE MTG	TATA spare parts
264168900220	BEZEL ASSY	TATA spare parts
264168900222	REINFORCEMENT DASHBOARD FRONT	TATA spare parts
264168900240	DASHBOARD ASSY RH BS6	TATA spare parts
264168900245	DASHBOARD ASSY CENTER BS6	TATA spare parts
264168900246	BEZEL ASSY BS6	TATA spare parts
264168900403	NACELLE SET LP609	TATA spare parts
264168903318	BRACKET DEFROST DUCT MTG INNER	TATA spare parts
264168906309	DASH BOARD RH LHD	TATA spare parts
264168906314	T EMBLEM COVER DASH BOARD	TATA spare parts
264168906315	COVER CENTRE	TATA spare parts
264168906316	INSTRUMENT PANEL LP609	TATA spare parts
264168906317	COVER CENTRE DIN RADIO	TATA spare parts
264168906318	DASH BOARD LH RHD LP609	TATA spare parts
264168906319	DASH BOARD RH LHD	TATA spare parts
264168906320	DASH BOARD RH RHD LP609	TATA spare parts
264168906321	DASH BOARD LH LHD LP	TATA spare parts
264168906322	DASH BOARD CENTRE LP RHD	TATA spare parts
264168906323	COVER BRAKE FLUID BOTTLE	TATA spare parts
264168906324	NACELLE FRONT	TATA spare parts
264168906325	NACELLE REAR	TATA spare parts
264168906326	COVER(DASH MOUNTING)	TATA spare parts
264168906327	PLUG	TATA spare parts
264168906331	SPEAKER GRILL	TATA spare parts
264168906332	DASHBOARDPERCCENTER	TATA spare parts
264168906334	DASH BOARD COVER-RHD	TATA spare parts
264168906336	DASH BOARD CENTRE LHD LP	TATA spare parts
264168906342	T EMBLEM COVER (DASH BOARD)EXPORT VEH.	TATA spare parts
264168906345	COVER (VACUUM BOOSTER)	TATA spare parts
264168906347	COVER-LHD(VACUUM BOOSTER)	TATA spare parts
264168906349	COVER(CLUTCH FLUID BOTTLE).	TATA spare parts
264168906354	DASHBOARD CENTRE GREY PIGMENTED-RHD	TATA spare parts
264168906355	DASHBOARD (GREY PIGMENTED)-LH(RHD)	TATA spare parts
264168906356	DASHBOARD (GREY PIGMENTED)-RH(RHD)	TATA spare parts
264168906357	COVER CLUTCH FLUID BOTTLE-GREY PIGMENTED	TATA spare parts
264168906358	COVER-DASH MTG. GREY PIGMENTED	TATA spare parts
264168906359	DASHBOARD CENTRE (SOFT FEEL)-RHD	TATA spare parts
264168906360	DASHBOARD (SOFT FEEL)-LH(RHD)	TATA spare parts
264168906362	INSTRUMENT PANEL	TATA spare parts
264168906364	COVER CLUTCH BOTTLE	TATA spare parts
264168906365	T EMBLEM COVER DASHBOARD-GREY PIGMENTED	TATA spare parts
264168906366	COVER RHD VACUUM BOOSTER(GREY PIGMENTED)	TATA spare parts
264168906367	SPEAKER GRILL	TATA spare parts
264168906368	GARNISH CENTER FLOW(GREY PIGMENTED)	TATA spare parts

264168906369	GARNISH SIDE FLOW(GREY PIGMENTED)	TATA spare parts
264168906373	DASHBOARD(GREY PIGMENTED) RH-LHD	TATA spare parts
264168906374	DASHBOARD CENTRE(GREY PIGMENTED)-LHD	TATA spare parts
264168906378	COVER BRAKE FLUID BOTTLE(GREY PIGMENTED)	TATA spare parts
264168906379	DASHBOARD CENTRE-RHD(EX-II)	TATA spare parts
264168906380	DASH BOARD R.H.-RHD	TATA spare parts
264168906387	COVER CENTRE-DASH BOARD	TATA spare parts
264168906390	SPEAKER GRILL	TATA spare parts
264168906393	COVER CLUTCH FLUID BOTTLE-GREY PIGMENTED	TATA spare parts
264168906401	DASHBOARD RH	TATA spare parts
264168906402	DASHBOARD CENTER	TATA spare parts
264168906403	DASHBOARD LH	TATA spare parts
264168906407	SPEAKER GRILL LH	TATA spare parts
264168906408	COVER HANDBRAKE	TATA spare parts
264168906415	COVER ECU	TATA spare parts
264168906416	DASHBOARD RH	TATA spare parts
264168906417	DASHBOARD LH	TATA spare parts
264168906418	CAP UREA BEZEL	TATA spare parts
264168906419	CAP HAND BRAKE COVER	TATA spare parts
264168906422	COVER ECU&BS6	TATA spare parts
264168906425	DASHBOARD RH BS6	TATA spare parts
264168906426	SWITCH BEZEL BS6	TATA spare parts
264168906429	DASHBOARD RH	TATA spare parts
264168906437	FLOOR CONSOLE BS6-PH2	TATA spare parts
264168906446	CAP FLOOR CONSOLE BS6-PH2	TATA spare parts
264168906501	CROSS RECESSED RAISED CSK SCREW M6X22	TATA spare parts
264168907702	RUBBER PACKING (WASHER)	TATA spare parts
264168908002	CR PAN HEAD SCREW M6X30	TATA spare parts
264168908003	HEX.FLANGE SCREW-M6X30 BS6	TATA spare parts
264168908211	REINFORCEMENT FRONT LP609	TATA spare parts
264168908236	REINFORCEMENT MIDDLE-LH	TATA spare parts
264168908237	REINFORCEMENT MIDDLE-RH	TATA spare parts
264168910103	ASSY.VENTILATION NOZZLE	TATA spare parts
264168910104	ASSY.DASHBOARD COMPLETE-RHD	TATA spare parts
264168910106	ASSY.DASHBOARD COMP.(GREY PIGMENTED)-RH	TATA spare parts
264168910107	ASSY.DASH BOARD COMPLETE-LHD(LPT-613)	TATA spare parts
264168910108	ASSY.DASHBOARD COMPLETE-RHD (EX-II)	TATA spare parts
264168910109	ASSY.DASHBOARD COMPLETE-RHD (LPK-407)	TATA spare parts
264168910110	ASSY.DASHBOARD COMPLETE-RHD (LPK-909)	TATA spare parts
264168910122	ASSY.KIT FOR DASHBOARD COVERS-RHD	TATA spare parts
264168910124	ASSY.DASH BOARD COMPLT.-RHD(LP-712 ARMY)	TATA spare parts
264168910125	ASSY.CONTROL BRKT.COMPLT-HTR	TATA spare parts
264168910127	ASSY.KIT FOR NACELLE WITH CUT	TATA spare parts
264168910131	ASSY. KIT FOR NACELLE(GREY)	TATA spare parts
264168910138	ASSY DASH BOARD COMPLETE -LHD	TATA spare parts
264168910142	ASSY DASH BOARD LH-RHD	TATA spare parts
264168910143	ASSY.DASH BOARD RH-RHD	TATA spare parts

264168910144	ASSY.DASH-BOARD CENTRE-RHD EX2	TATA spare parts
264168910145	ASSY.DASH BOARD CENTRE-RHD EX	TATA spare parts
264168910148	ASSY.REINFORCEMENT MIDDLE-LH	TATA spare parts
264168910150	ASSY.DASHBOARD CENTRE-RHD EX2 W/HTG	TATA spare parts
264168910151	ASSY.REINFORCEMENT MIDDLE-RH	TATA spare parts
264168910154	ASSY. BRACKET MTG. HVAC CONTROL PANEL	TATA spare parts
264168910157	ASSY. MTG. BKT SIDE	TATA spare parts
264168910162	BOOT RING ASSY BS6-PH2	TATA spare parts
264168910164	DASHBOARD ASSY RH BS6-PH2	TATA spare parts
264168910165	BOOT RING ASSY	TATA spare parts
264168916312	DASHBOARD CENTRE	TATA spare parts
264168916313	HVAC COVER	TATA spare parts
264168916314	COVER¿ HVAC CONTROL PANEL VACCUM FORM	TATA spare parts
264168916315	COVER DASH BOARD HAND BRAKE VALVE MTG.	TATA spare parts
264169100101	ASSY.KIT FOR INSULATION FLR.PNL.SIDE-RHD	TATA spare parts
264169100109	ASY.INSULATION FLOOR MIDDLE-RHD(CNG CAB)	TATA spare parts
264169106313	INSULATION FRONT	TATA spare parts
264169106314	INSULATION SIDE	TATA spare parts
264169106320	INSULATION FIREWALL-LHD(613 RUSSIA)	TATA spare parts
264169106322	INSULATION FIREWALL OUTER-LHD-613 RUSSIA	TATA spare parts
264169106323	INSULATION UNDERBODY-LHD	TATA spare parts
264169106334	INSULATIONPERCFIREWALLPERCINNER	TATA spare parts
264169106335	INSULATIONPERCFIREWALLPERCOUTER	TATA spare parts
264169400101	ASSY.PADDING (REAR WALL)	TATA spare parts
264169506305	SIDE LINING(FRONT)-LH	TATA spare parts
264169506306	SIDE LINING(FRONT)-RH	TATA spare parts
264169506307	REAR WALL TOP LINING-LH	TATA spare parts
264169506308	CORNER PANEL INNER LINING-LH	TATA spare parts
264169506309	CORNER PANEL INNER LINING-RH	TATA spare parts
264169506316	ROOF LINING	TATA spare parts
264169506318	MOULDED ROOF LINING	TATA spare parts
264169506322	ROOF LINING	TATA spare parts
264169506323	ROOF HATCH LINING	TATA spare parts
264170000101	ASSY.LOAD BODY COMP. BOLTED SIDE PANELS	TATA spare parts
264170000102	ASSY.LOAD BODY COMPT. BOLTED SIDE PANEL	TATA spare parts
264170000104	ASSY.LOAD BODY COMPL.(DROP SIDE PANELS)	TATA spare parts
264170000109	ASSY.LOAD BODY COMPL.WITH SUPSTR.&CANOP	TATA spare parts
264170000113	ASSY.LOAD BODY COMPL. BOLTED SIDE PANEL	TATA spare parts
264170000116	ASSY.LOAD BODY COMPLT. FIXED & BOLTED	TATA spare parts
264170000119	ASSY.LOAD BODY COMPLT. FIXED & BOLTED	TATA spare parts
264170000120	ASSY.LOAD BODY COMPLETE-HIGH DECK	TATA spare parts
264170000122	ASSY LOAD BODY LPT 407 - 3400 WB	TATA spare parts
264170000123	ASSY.LOAD BODY COMPLT.(FIXED & BOLTED)	TATA spare parts
264170000125	ASSY.LOAD BODY COMPLT.(HIGH DECK)	TATA spare parts
264170000126	ASSY.LOAD BODY COMPLETE (HIGH DECK)	TATA spare parts
264170000128	ASSY.LOAD BODY COMPLT.(HIGH DECK)	TATA spare parts
264170000130	ASSY.LOAD BODY COMPLT.(REGULAR-809 EX2)	TATA spare parts



264170000131	ASSY.LOAD BODY COMPLT.(REGULAR-709 EX2)	TATA spare parts
264170000133	ASSY.LOAD BODY COMPL.(HIGH DECK-709 EX2)	TATA spare parts
264170000135	ASSY.LOAD BODY COMPLT.(DROP SIDES)-34 WB	TATA spare parts
264170000138	ASSY.LOAD BODY 407 LPT HD EX2	TATA spare parts
264170100154	ASSY SUPPORT	TATA spare parts
264170100176	ASSY.SUPPORT SIDE GUARD	TATA spare parts
264170100178	ASSY.SUPPORT-SIDE GUARD	TATA spare parts
264170100182	ASSY.SIDE GUARD-LH	TATA spare parts
264170100186	ASSY.SIDE GUARD	TATA spare parts
264170100187	ASSY SIDE GUARD-LH	TATA spare parts
264170100188	ASSY SIDE GUARD-LH	TATA spare parts
264170100189	ASSY.SIDE GUARD	TATA spare parts
264170100192	ASSY.SIDE GUARD-RH	TATA spare parts
264170100194	ASSY.SIDE GUARD-RH	TATA spare parts
264170100195	ASSY.SIDE GUARD-RH	TATA spare parts
264170100214	ASSY.SIDE GUARD WITH SUPPORT	TATA spare parts
264170100217	ASSY.SIDE GUARD WITH SUPPORT-LH	TATA spare parts
264170100218	ASSY.SIDE GUARD WITH SUPPORT-RH	TATA spare parts
264170100219	ASSY.SIDE GUARD WITH SUPPORT-LH	TATA spare parts
264170100220	ASSY.SIDE GUARD WITH SUPPORT-RH	TATA spare parts
264170100221	ASSY.SIDE GUARD WITH SUPPORT-LH	TATA spare parts
264170100222	ASSY.SIDE GUARD WITH SUPPORT-RH	TATA spare parts
264170100225	ASSY.SIDE GUARD WITH SUPPORT-LH	TATA spare parts
264170100226	ASSY.SIDE GUARD WITH SUPPORT-RH	TATA spare parts
264170100252	ASSY PLATE (FOR MTG.SUPD)	TATA spare parts
264170100255	PLATE ASSY SUPD MTGBS6	TATA spare parts
264170100256	ASSY PLATE (FOR MTG.SUPD)	TATA spare parts
264170106301	REAR MUDFLAP (SPRAY SUPPRESSION)	TATA spare parts
264170106307	MUDFLAP REAR(SPRAY SUPPRESSION)	TATA spare parts
264170106311	OUTER VALANCE COVER-LH	TATA spare parts
264170106312	OUTER VALANCE COVER-RH	TATA spare parts
264170107105	PLATE (FOR MTG.SUPD)	TATA spare parts
264170107106	PLATE (FOR MTG.SUPD)	TATA spare parts
264170108230	FLOOR PANEL-LH	TATA spare parts
264170108231	FLOOR PANEL-RH	TATA spare parts
264170118265	OUTER VALANCE COVER-LH	TATA spare parts
264170118266	OUTER VALANCE COVER-RH	TATA spare parts
264170200101	ASSY.FRONT PANEL	TATA spare parts
264170200115	ASSY.FRONT PANEL COMPLT.	TATA spare parts
264170300101	ASSY.SIDE PANEL-L.H.	TATA spare parts
264170300102	ASSY.SIDE PANEL-R.H.	TATA spare parts
264170300103	ASSY SIDE PANEL-L.H.(FIXED & BOLTED)	TATA spare parts
264170300104	ASSY SIDE PANEL-R.H.(FIXED & BOLTED)	TATA spare parts
264170300134	ASSY.SIDE PANEL-L.H.	TATA spare parts
264170300135	ASSY.SIDE PANEL-R.H.	TATA spare parts
264170300136	ASSY SIDE PANEL-LH	TATA spare parts
264170300137	ASSY SIDE PANEL-RH	TATA spare parts

264170300138	ASSY.SIDE PANEL-LH	TATA spare parts
264170300139	ASSY.SIDE PANEL-RH	TATA spare parts
264170306302	RETRO-REFLECTIVE TAPE (SIDE)	TATA spare parts
264170308206	TOP PANEL	TATA spare parts
264170308207	BOTTOM PANEL	TATA spare parts
264170400101	ASSY TAIL GATE	TATA spare parts
264170400105	ASSY. TAIL GATE	TATA spare parts
264170400106	ASSY. TAIL GATE	TATA spare parts
264170406301	RETRO-REFLECTIVE TAPE (REAR)	TATA spare parts
264170500105	ASSY.CANOPY	TATA spare parts
264170900101	ASSY.RUBBER PACKING	TATA spare parts
264170900104	ASSY.RUBBER PACKING	TATA spare parts
264172000102	DOOR ASSY COMPLT LH	TATA spare parts
264172000103	DOOR ASSY COMPLT RH	TATA spare parts
264172200101	ASSY.HINGE SUPPORT TOP LH BS6	TATA spare parts
264172200102	ASSY.HINGE SUPPORT TOP RH	TATA spare parts
264172200103	ASSY. HINGE SUPPORT BOTTOM LH	TATA spare parts
264172200104	ASSY.HINGE SUPPORT BOTTOM RH	TATA spare parts
264172200113	GUIDE CHANNEL LH	TATA spare parts
264172200114	GUIDE CHANNEL RH	TATA spare parts
264172200117	DOOR SHELL LH	TATA spare parts
264172200118	DOOR SHELL RH	TATA spare parts
264172200121	ASSY.DOOR PANEL INNER LH BS6	TATA spare parts
264172200122	ASSY.DOOR PANEL INNER RH BS6	TATA spare parts
264172200127	ASSY REINFORCEMENT LH BS6	TATA spare parts
264172200128	ASSY REINFORCEMENT RH BS6	TATA spare parts
264172200131	ASSY. REINF. OUTER LH.	TATA spare parts
264172200132	ASSY.REINF. OUTER RH.	TATA spare parts
264172200135	ASSY. DOOR SHELL LH.	TATA spare parts
264172200136	ASSY. DOOR SHELL RH.	TATA spare parts
264172200136A	ASSY. DOOR SHELL RH BS1/2/3/4	TATA spare parts
264172200142	ASSY.DOOR SHELL-LH	TATA spare parts
264172200143	ASSY. DOOR SHELL RH BS1/2/3/4	TATA spare parts
264172208201	DOOR PANEL OUTER LH	TATA spare parts
264172208202	DOOR PANEL OUTER RH	TATA spare parts
264172208203	PANEL OUTER LH (REAR SASH) BS6	TATA spare parts
264172208204	PANEL OUTER RH (REAR SASH) BS6	TATA spare parts
264172208205	PANEL INNER LH-REAR SASH	TATA spare parts
264172208206	PANEL INNER RH-REAR SASH	TATA spare parts
264172208207	SASH TOP LH BS6	TATA spare parts
264172208208	SASH TOP RH BS6	TATA spare parts
264172208209	SASH FRONT L.H. BS6	TATA spare parts
264172208210	SASH FRONT R.H. BS6	TATA spare parts
264172208211	SASH REAR LH BS6	TATA spare parts
264172208212	SASH REAR RH BS6	TATA spare parts
264172208213	DOOR PANEL INNER LH	TATA spare parts
264172208214	DOOR PANEL INNER RH	TATA spare parts

264172208219	HINGE REINFORCEMENT LH (DOOR INNER PANEL	TATA spare parts
264172208220	HINGE REINFORCEMENT RH (DOOR INNER PANEL	TATA spare parts
264172208239	PANEL OUTER FRONT CORNER LH BS6	TATA spare parts
264172208240	PANEL OUTER FRONT CORNER RH BS6	TATA spare parts
264172208252	RETAINER	TATA spare parts
264172208256	SUPPORT ANGLE [INNER PANEL REINFRCEMNTN	TATA spare parts
264172208257	GUSSET BS6-PH2	TATA spare parts
264172208263	RETAINER FRONT TOP RH BS6	TATA spare parts
264172208264	RETAINER FRONT TOP LH BS6	TATA spare parts
264172208269	RETAINER REAR BOTTOM LH BS6	TATA spare parts
264172208270	RETAINER REAR MIDDLE RH. BS6	TATA spare parts
264172208271	RETAINER REAR MIDDLE LH. BS6	TATA spare parts
264172208272	RETAINER REAR TOP RH. BS6	TATA spare parts
264172208273	RETAINER REAR TOP LH. BS6	TATA spare parts
264172208274	SUPPORT SASH (REAR)-TOP. BS6	TATA spare parts
264172208275	SUPPORT SASH (REAR)-BOTTOM. BS6	TATA spare parts
264172208276	RETAINER REAR BOTTOM RH BS6	TATA spare parts
264172208277	WASHER	TATA spare parts
264172208278	REINFORCEMENT TOP LH-OUTER PANEL DOOR	TATA spare parts
264172208279	REINFORCEMENT TOP RH-OUTER PANEL DOOR	TATA spare parts
264172208282	PANEL OUTER FRONT CORNER LH.	TATA spare parts
264172208283	PANEL OUTER FRONT CORNER RH.	TATA spare parts
264172208284	GUSSET (REAR SASH) BS6	TATA spare parts
26417220Z118	ASSY.DOOR SHELL RH(LHD W/OAC)(COATED SH)	TATA spare parts
26417220Z135	ASSY. DOOR SHELL LH BS2	TATA spare parts
26417220Z136	ASSY. DOOR SHELL RH BS2	TATA spare parts
26417220Z144	ASSY.DOOR SHELL-LH (COLD APPLN.)	TATA spare parts
26417220Z145	ASSY.DOOR SHELL-RH (COLD APPLN.)	TATA spare parts
264172300111	DOOR HINGE TOP LH	TATA spare parts
264172300112	DOOR HINGE TOP RH	TATA spare parts
264172300118	DOOR HINGE BOTTOM LH	TATA spare parts
264172300119	DOOR HINGE BOTTOM RH	TATA spare parts
264172300122	SEALING MOULD LH OUTER	TATA spare parts
264172300123	SEALING MOULD RH OUTER	TATA spare parts
264172300124	ASSY DOVETAIL BOTTOM	TATA spare parts
264172300127	KIT FOR LOCKS	TATA spare parts
264172300128	KIT CAB LOCKS	TATA spare parts
264172300129	SEALING INNER LH	TATA spare parts
264172300130	SEALING INNER RH	TATA spare parts
264172300131	KIT-LOCKS CAB BS1/2/3/4	TATA spare parts
264172300132	KIT FOR LOCKS CAB	TATA spare parts
264172300137	ASSY.SEALING INNER LH	TATA spare parts
264172300138	ASSY.SEALING INNER RH	TATA spare parts
264172300139	KIT FOR LOCKS CAB	TATA spare parts
264172300139AE	KIT FOR LOCKS(CAB)LPT 2523	TATA spare parts
264172300140	ASSY.DOOR STRAP COMPLT.	TATA spare parts
264172300141	KIT FOR LOCKS CAB	TATA spare parts

264172300143	ASSY. DOOR LOCK LH BS1/2/3/4	TATA spare parts
264172300144	ASSY. DOOR LOCK RH BS1/2/3/4	TATA spare parts
264172300164	ASSY.SEALING INNER-RH	TATA spare parts
264172300165	ASSY.KIT FOR POP-UP KNOB-LH	TATA spare parts
264172300166	ASSY.KIT FOR POP-UP KNOB-RH	TATA spare parts
264172300170	ASSY. DOOR HINGE BOTTOM-LH	TATA spare parts
264172300171	ASSY.DOOR HINGE BOTTOM-RH	TATA spare parts
264172300174	ASSY DOOR HANDLE INNER	TATA spare parts
264172300175	ASSY_DOOR_HANDLE_INNER_RH(M/S SANDHAR)	TATA spare parts
264172300177	ASSY. INNER SEAL LH (DOOR) BS6	TATA spare parts
264172300178	ASSY. INNER SEAL RH (DOOR) BS6	TATA spare parts
264172300179	ASSY. OUTER SEAL LH (DOOR)	TATA spare parts
264172300180	ASSY. OUTER SEAL RH (DOOR)	TATA spare parts
264172300184	LOCK ASSY GLOVE BOX BS6	TATA spare parts
264172306001	LEVER LH LOCK CYL TO LATCH	TATA spare parts
264172306002	LEVER RH LOCK CYL TO LATCH	TATA spare parts
264172306003	LINK OUTER HANDLE	TATA spare parts
264172306004	LINK LH INNER HANDLE	TATA spare parts
264172306005	LINK RH INNER HANDLE	TATA spare parts
264172306006	LINK POP UP KNOB LH	TATA spare parts
264172306007	LINK POP UP KNOB RH	TATA spare parts
264172306301	GROMMET	TATA spare parts
264172306302	POP UP KNOB DOOR LOCK	TATA spare parts
264172306303	DOVETAIL BOTTOM BODY SIDE	TATA spare parts
264172306304	WEATHER STRIP INNER	TATA spare parts
264172306305	WEATHER STRIP OUTER	TATA spare parts
264172306308	COVER PANEL INNER(FRONT CORNER)-LH	TATA spare parts
264172306309	COVER PANEL INNER(FRONT CORNER)-RH	TATA spare parts
264172308214	SHIM [DOVETAIL BOTTOM]	TATA spare parts
264172308215	COVER PANEL INNER LH [FRONT CORNER]	TATA spare parts
264172308216	COVER PANEL INNER RH [FRONT CORNER]	TATA spare parts
264172310101	OUTER HANDLE ASSY FRONT DOOR LH	TATA spare parts
264172310102	OUTER HANDLE ASSY FRONT DOOR RH	TATA spare parts
264172320101	LATCH ASSY FRONT DOOR LH	TATA spare parts
264172320102	LATCH ASSY FRONT DOOR RH	TATA spare parts
264172500101	WINDOW REGULATOR LH BS1/2/3/4	TATA spare parts
264172500101AE	ASSY.WINDING REGULATOR LH 2523	TATA spare parts
264172500102	WINDOW REGULATOR RH BS1/2/3/4	TATA spare parts
264172500102AE	ASSY WINDING REGULATOR RH 2523	TATA spare parts
264172500103	WEATHER STRIP RH	TATA spare parts
264172500104	WEATHER STRIP LH	TATA spare parts
264172500105	ASSY.WINDING REGULATOR LH.	TATA spare parts
264172500106	ASSY.WINDING REGULATOR RH.	TATA spare parts
264172500107	ASSY.WINDING REGULATOR LH.	TATA spare parts
264172500108	ASSY.WINDING REGULATOR RH.	TATA spare parts
264172500111	ASSY.WINDOW REGULATOR-LH(LPT-613 RUSSIA)	TATA spare parts
264172500112	ASSY.WINDOW REGULATOR-RH(LPT-613 RUSSIA)	TATA spare parts

264172502301	REGULATOR GLASS LH BS1/2/3/4	TATA spare parts
264172502301AE	LH DOOR GLASS 713 715	TATA spare parts
264172502302	REGULATOR GLASS RH	TATA spare parts
264172502302AE	RH DOOR GLASS 713 715	TATA spare parts
264172502303	REGULATOR GLASS LH	TATA spare parts
264172502304	REGULATOR GLASS RH	TATA spare parts
264172502501	VELVET CHANNEL	TATA spare parts
264172506301	SPACER REGULATING HANDLE	TATA spare parts
264172506303	HOLDER REGULATING GLASS	TATA spare parts
264172506307	WEATHER STRIP LH	TATA spare parts
264172506308	WEATHER STRIP RH	TATA spare parts
264172506314	WEATHER STRIP R.H.	TATA spare parts
264172506315	WEATHER STRIP L.H.	TATA spare parts
264172506316	WEATHER STRIP OUTERBS6	TATA spare parts
264172506317	WEATHER STRIP INNERBS6	TATA spare parts
264172508201	SPRING CLIP W/STRIP 709	TATA spare parts
264172700101	PADDING DOOR LH BS1/2/3/4	TATA spare parts
264172700102	PADDING DOOR RH	TATA spare parts
264172700103	ASSY.PADDING DOOR L.H.	TATA spare parts
264172700104	ASSY.PADDING DOOR R.H.	TATA spare parts
264172700111	PLASTIC COVER L.H.	TATA spare parts
264172700112	PLASTIC COVER R.H.	TATA spare parts
264172700113	ASSY.PADDING DOOR L.H.	TATA spare parts
264172700114	ASSY.PADDING DOOR R.H.	TATA spare parts
264172706308	TRIM UPPER-LH (DOOR INNER PANEL)	TATA spare parts
264172706309	TRIM UPPER-RH (DOOR INNER PANEL)	TATA spare parts
264172980101	KIT-LOCK WITH KEY	TATA spare parts
264175100102	CENTER FLAP	TATA spare parts
264175100103	ASSY.CENTRE FLAP	TATA spare parts
264175106706	PIN CEN FLAP STAY ROD	TATA spare parts
264175200107	LOCK CENTRE FLAP	TATA spare parts
264175200109	ASSY HINGE LEAF-BODY SIDE	TATA spare parts
264175200112	ASSY. REL CABLE COMP.(CENTRE FLAP) BS1-6	TATA spare parts
264175200116	HINGE CENTRE FLAP	TATA spare parts
264175200117	PANEL INNER CEN FLAP	TATA spare parts
264175200119	STAY ROD CEN FLAP	TATA spare parts
264175200122	STRIKER CENTRE FLAP	TATA spare parts
264175200125	CEN FLAP REL CABLE LHD	TATA spare parts
264175200127	ASSY RELEASE CABLE COMPL [C/FLAP]	TATA spare parts
264175200129	CEN FLAP REL CABLE LHD	TATA spare parts
264175200130	ASSY.RELEASE CABLE RHD.	TATA spare parts
264175200137	ASSY HOOD LATCHBS6	TATA spare parts
264175200138	ASSY STRIKER HOOD	TATA spare parts
264175206306	BUSH STAY ROD CEN FLAP	TATA spare parts
264175208208	PANEL CENTER FLAP INNER BS6-PH2	TATA spare parts
264175208210	SHIM (HINGE CENTRE FLAP)	TATA spare parts
264175208218	RAIN CHANNEL CENTER FLAP BS6-PH2	TATA spare parts

264181100103	LID RHD	TATA spare parts
264181100104	COVER LH C/FLAP HINGE	TATA spare parts
264181100105	COVER RH C/FLAP HINGE	TATA spare parts
264181100108	ASSY LID-FUEL PRIMING	TATA spare parts
264181100109	KIT FOR LOCKS FOR COWL	TATA spare parts
264181100110	KIT LOCKS COWL	TATA spare parts
264181100111	SUNVISOR RH	TATA spare parts
264181100112	SUNVISOR LH	TATA spare parts
264181100113	ASSY REAR VIEW MIRROR OUTSIDE LH	TATA spare parts
264181100114	ASSY REAR VIEW MIRROR OUTSIDE RH	TATA spare parts
264181100135	ASSY R.V.M	TATA spare parts
264181100138	ASSY FRAME COMPL LH-R V M	TATA spare parts
264181100139	ASSY FRAME COMP RH-RVM	TATA spare parts
264181100144	ASSY COVER LH FLAP HINGE	TATA spare parts
264181100145	ASSY COVER RH FLAP HINGE	TATA spare parts
264181100150	ASSY REAR VIEW MIRROR OUTER RH	TATA spare parts
264181100164	KIT FOR RVM FOR COWL-RHD	TATA spare parts
264181100165	ASSY.FRAME COMPLETE REAR VIEW MIRROR	TATA spare parts
264181100169	ASSY.KIT FOR RVM WITH FRAME-LH	TATA spare parts
264181100170	ASSY.KIT FOR RVM WITH FRAME-RH	TATA spare parts
264181100171	ASSY.KIT FOR RVM WITH FRAME-LH	TATA spare parts
264181100172	ASSY.KIT FOR RVM WITH FRAME-RH	TATA spare parts
264181100173	KIT FOR LOCKS (FOR COWL)	TATA spare parts
264181100175	ASSY COVER-LH CENTRE FLAP HINGE	TATA spare parts
264181100176	ASSY COVER-RH CENTRE FLAP HINGE	TATA spare parts
264181100178	ASSY.HEAD LAMP DOME	TATA spare parts
264181100181	ASSY.HEAD LAMP DOME-LH(RHD)	TATA spare parts
264181100197	ASSY.FRAME COM.W/REAR VIEW MIRROR & WID	TATA spare parts
264181100203	ASSY.FRAME COMPL.WITH REAR VIEW MIRROR L	TATA spare parts
264181100210	ASSY.COVER REAR (REAR WALL)	TATA spare parts
264181100219	COVER PLATE ASSY BS6	TATA spare parts
264181100225	COVER PLATE ASSY BS6	TATA spare parts
264181102101	SUPPORT LH RV MIRROR	TATA spare parts
264181102102	SUPPORT RH RV MIRROR	TATA spare parts
264181103301	BKT REAR VIEW MIRROR	TATA spare parts
264181103302	BRACKET BS6	TATA spare parts
264181103303	BRACKETASSYMIRRORMTGFRONT BS6	TATA spare parts
264181103304	BRACKET BS6	TATA spare parts
264181103801	BRACKET TOP LH. (R.V.M.)	TATA spare parts
264181103802	BRACKET TOP RH.(R.V.M.)	TATA spare parts
264181103803	BRACKET BOTTOM LH-RVM	TATA spare parts
264181103804	BRACKET BOTTOM RH. R.V.M.	TATA spare parts
264181105302	INSULATION (LID)-RHD	TATA spare parts
264181105304	PACKING PRIMING LID	TATA spare parts
264181106001	LEVER (FUEL PRIMING LID)	TATA spare parts
264181106304	SEALING LID	TATA spare parts
264181106305	CLAMP (SUNVISOR)	TATA spare parts

264181106306	CAP REAR VIEW MIRROR	TATA spare parts
264181106307	WASHER RV MIRROR	TATA spare parts
264181106308	RUBBER PAD RV MIRROR	TATA spare parts
264181106316	BEADING FLOOR PANEL	TATA spare parts
264181106317	FOAM PACKING BS6	TATA spare parts
264181106320	CAP FOR REAR VIEW MIRROR	TATA spare parts
264181106321	BEADING (FIRE WALL)	TATA spare parts
264181106322	INNER BEADING	TATA spare parts
264181106323	BOTTOM BEADING-CENTRE FLAP	TATA spare parts
264181106325	PROTECTIVE COVER-RH (DOOR INNER BEADING)	TATA spare parts
264181106326	PROTECTIVE COVER-LH (DOOR INNER BEADING)	TATA spare parts
264181106330	RUBBER PAD-BKT TOP RVM	TATA spare parts
264181106331	RUBBER PAD-BKT BOTTOM RVM	TATA spare parts
264181106332	SLEEVE-FOR FRAME RVM	TATA spare parts
264181106335	INNER BEADING	TATA spare parts
264181106339	EX DECAL GOLDEN	TATA spare parts
264181106340	EX DECAL SILVER	TATA spare parts
264181106341	INSULATION LID-RHD	TATA spare parts
264181106352	COAT HANGER	TATA spare parts
264181106369	EX2 DECAL	TATA spare parts
264181106370	DRAIN HOLE COVER BS6-PH2	TATA spare parts
264181106371	DRAIN HOLE COVER BS6-PH2	TATA spare parts
264181106372	DRAIN HOLE COVER BS6-PH2	TATA spare parts
264181106374	RETRO REFLECTIVE TAPE	TATA spare parts
264181106375	DECAL DOOR LH	TATA spare parts
264181106376	DECAL DOOR RH	TATA spare parts
264181106381	DOOR DECAL-LH (LPT-909H EX2)	TATA spare parts
264181106382	DOOR DECAL-RH (LPT-909H EX2)	TATA spare parts
264181106383	FRONT DECAL HEX2	TATA spare parts
264181107703	RUBBER WASHER-R.V.M.	TATA spare parts
264181108214	RECTANGULAR RETAINER	TATA spare parts
264181108233	GRILLPERCMESH	TATA spare parts
264181110101	ASSY.SUPPORT COVER REAR WALL	TATA spare parts
264181110125	ASSY.CAP (FOR M6 CR PAN HD SCREW)	TATA spare parts
264181110126	PROXIMITY MIRROR ASSY BS6	TATA spare parts
264181110147	KIT-ORVM LH	TATA spare parts
264181110148	KIT-ORVM RH	TATA spare parts
264181110152	FRONT VIEW MIRROR ASSY	TATA spare parts
264181110166	CLOSE PROXIMITY MIRROR ASSY	TATA spare parts
264181110167	FRONT VIEW MIRROR ASSLY BS6	TATA spare parts
264181110169	KIT-ORVM RH BS6-PH2	TATA spare parts
264181110170	KIT-ORVM LH BS6-PH2	TATA spare parts
264181406301	GROMMET (CAB LIFTING CUT-OUT)	TATA spare parts
264181900101	BAZZEL RH	TATA spare parts
264181900102	BAZZEL LH	TATA spare parts
264181900104	T EMBLEM	TATA spare parts
264181900105	BAZZEL LH	TATA spare parts

264181900106	BAZZEL RH	TATA spare parts
264181900111	COVER SIDE LH	TATA spare parts
264181900112	COVER SIDE RH	TATA spare parts
264181900113	COVER CENTRE	TATA spare parts
264181900114	COVER BAZZLE LH	TATA spare parts
264181900115	COVER BAZZLE	TATA spare parts
264181900117	MASCOT 709 E	TATA spare parts
264181900118	ASSY.MASCOT 713 S	TATA spare parts
264181900119	MASCOT 609E	TATA spare parts
264181900121	ASSY.MASCOT 509M	TATA spare parts
264181900122	ASSY.MASCOT 613	TATA spare parts
264181900123	ASSY.PLASTIC GRILL WITH`T` EMBLEM	TATA spare parts
264181900127	ASSY. T EMBLEM 709 OVAL SHAPE	TATA spare parts
264181900130	ASSY.MASCOT 509 SE	TATA spare parts
264181900132	ASSY 709 TURBO EX MASCOT	TATA spare parts
264181900144	ASSY. 909 EX MASCOT	TATA spare parts
264181900145	ASSY. 712 EX MASCOT	TATA spare parts
264181900147	DOOR CLADDING LH	TATA spare parts
264181900148	DOOR CLADDING RH	TATA spare parts
264181900150	COVER SIDE LH CENTRE FLAP	TATA spare parts
264181900151	COVER SIDE RH CENTRE FLAP	TATA spare parts
264181900152	COVER BAZZLE LH	TATA spare parts
264181900153	COVER BAZZLE RH	TATA spare parts
264181900157	MASCOT 407 EX	TATA spare parts
264181900158	CENTREGRILL WITH T EMBLEM	TATA spare parts
264181900159	ASSY.COVER MIDDLE WITH TATA LETTERS	TATA spare parts
264181900162	ASSY. 912 EX MASCOT	TATA spare parts
264181900163	ASSY. 410 EX MASCOT	TATA spare parts
264181900164	ASSY.BAZZLE-LH (GREY)	TATA spare parts
264181900165	ASSY.BAZZLE-RH (GREY)	TATA spare parts
264181900166	ASSY.813 EX2 MASCOT	TATA spare parts
264181900167	ASSY.GRAB HANDLE (FOR RUSSIA VEH)	TATA spare parts
264181900168	ASSY COVER MIDDLE (C/FLAP)-BLACK	TATA spare parts
264181900169	ASSY COVER SIDE-LH (C/FLAP)-BLACK	TATA spare parts
264181900170	ASSY COVER SIDE-RH (C/FLAP)	TATA spare parts
264181900171	ASSY DOOR CLADDING-LH WITH CLIPS (BLACK)	TATA spare parts
264181900172	ASSY DOOR CLADDING-RH (WITH CLIPS)-BLACK	TATA spare parts
264181900173	ASSY. COVER MIDDLE (C/FLAP)-BLACK BS1- 4	TATA spare parts
264181900175	ASSY COVER BAZZLE-LH (BLACK)	TATA spare parts
264181900176	ASSY COVER BAZZLE-RH (BLACK)	TATA spare parts
264181900178	ASSY. EX 2 MASCOT	TATA spare parts
264181900179	ASSY. 709 EX2 MASCOT	TATA spare parts
264181900180	ASSY. 809 EX2 MASCOT	TATA spare parts
264181900181	ASSY909 EX2 MASCOT	TATA spare parts
264181900183	ASSY.MASCOT 613 EX	TATA spare parts
264181900188	ASSY. 407 EX2 MASCOT	TATA spare parts
264181900193	ASSY GRAB HANDLE	TATA spare parts



264181900195	ASSY.913 EX2 MASCOT	TATA spare parts
264181900199	ASSY. MASCOT 709 EX	TATA spare parts
264181903301	MTG.BRACKET BAZZEL	TATA spare parts
264181903302	MTG.BRACKET BAZZEL	TATA spare parts
264181903401	BUSH - GRAB HANDLE	TATA spare parts
264181906301	GRILL MIDDLE	TATA spare parts
264181906302	GRILL CENTRE FRONT	TATA spare parts
264181906306	GRILL LH	TATA spare parts
264181906308	GRILL RH	TATA spare parts
264181906309	GRILL MIDDLE	TATA spare parts
264181906314	MASCOT 609	TATA spare parts
264181906315	SCREW GROMMET	TATA spare parts
264181906316	T EMBLEM	TATA spare parts
264181906317	FOAM PACKING	TATA spare parts
264181906318	FOAM PACKING	TATA spare parts
264181906319	PACKING GRILL W/S BOTTOM	TATA spare parts
264181906320	MASCOT 709	TATA spare parts
264181906326	COVER STEP BOARD	TATA spare parts
264181906327	PACKING GRILL W/S BOTTOM	TATA spare parts
264181906328	WASHER	TATA spare parts
264181906331	GRILL MIDDLE W/S.	TATA spare parts
264181906332	GRILL SIDE-LH W/S	TATA spare parts
264181906333	GRILL SIDE-RH W/S	TATA spare parts
264181906336	CENTRE GRILL (FRONT)	TATA spare parts
264181906337	STICKER TURBO INTERCOOLER	TATA spare parts
264181906347	PLUG BUTTON BS6	TATA spare parts
264181906350	STICKER `POWER STEERING`	TATA spare parts
264181906361	CENTRE GRILL FRONT	TATA spare parts
264181910101	ASSY.MASCOT 613 EX2	TATA spare parts
264181910112	ASSY 909 HD BS-III MASCOT	TATA spare parts
264181910117	ASSY COVER MIDDLE WITH TATA LETTERS-GREY	TATA spare parts
264181910118	ASSY.909H EX2 BS-III MASCOT	TATA spare parts
264181910119	ASSY.709H EX2 BS-III MASCOT	TATA spare parts
264181910121	ASSY.COVER (STEP BOARD) BS6	TATA spare parts
264181910122	ASSY MASCOT 513 EX2	TATA spare parts
264181910123	ASSY.CENTRE GRILL W/T EMBLM & NET-BLACK	TATA spare parts
264181910127	MASCOT ASSY	TATA spare parts
264181910128	MASCOT ASSY 910 MFIP PS	TATA spare parts
264181910130	BEZEL ASSY LH	TATA spare parts
264181910131	BEZEL ASSY RH	TATA spare parts
264182400108	ASSY BRACKET [W/S WASHER MOUNTING]	TATA spare parts
264182400109	ASSY. WIPER ARM [RHD] BS1/2/3/4	TATA spare parts
264182400110	ASSY WIPER ARM [LHD] OFFER DRG	TATA spare parts
264182400111	ASSY WIPER BLADE	TATA spare parts
264182400112	ASSY WIPER ARM - RHD	TATA spare parts
264182400116	ASSY WIPER ARM [LHD]	TATA spare parts
264182400118	KIT WIPER MOTOR	TATA spare parts

264182400123	BKT WIPER MOTOR MTG	TATA spare parts
264182400124	KIT WIPER MOTOR	TATA spare parts
264182400125	KIT ELEC W/S WASHER	TATA spare parts
264182400138	KIT-WIPER MOTOR W/O CONN. BS1/2/3/4	TATA spare parts
264182400139	KIT FOR WIPER MOTOR W/O 5 P.CONN	TATA spare parts
264182400140	KIT FOR WIPER MOTOR W/O 5 P.CONN	TATA spare parts
264182400141	KIT FOR WIPER MOTOR W/O 5 P.CONN.	TATA spare parts
264182400142	KIT W/S WASHER UNIT (RHD)	TATA spare parts
264182400143	KIT W/S WASHER UNIT (LHD)	TATA spare parts
264182400144	KIT W/S WASHER UNIT (RHD)	TATA spare parts
264182400145	KIT W/S WASHER UNIT (LHD)	TATA spare parts
264182400147	ASSY.WIPER MOTOR W/BKT RHD	TATA spare parts
264182400159	KIT W/S WASHER UNIT (RHD)	TATA spare parts
264182400160	W/S WASHER KIT (12V) LHD	TATA spare parts
264182400162	W/S WASHER KIT (24V) LHD	TATA spare parts
264182400165	PUMP ASSY.-24V BS6	TATA spare parts
264182400166	KIT W/S WASHER UNIT -12V LHD	TATA spare parts
264182400167	KIT W/S WASHER UNIT (RHD)	TATA spare parts
264182400168	KIT W/S WASHER UNIT -24V LHD	TATA spare parts
264182400170	KIT W/S WASHER UNIT 24V LHD	TATA spare parts
264182400172	KIT W/S WASHER UNIT (RHD)	TATA spare parts
264182400173	KIT W/S WASHER UNIT -RHD 24V-PRABHA	TATA spare parts
264182400174	KIT W/S WASHER UNIT LHD 12V-	TATA spare parts
264182400175	KIT W/S WASHER UNIT LHD 24V	TATA spare parts
264182400176	ASSY.WIPER ARM & BLADE(600 MM.)LHD	TATA spare parts
264182400178	ASSY.WIPER ARM & BLADE(550 MM.)LHD	TATA spare parts
264182400179	ASSY.WIPER ARM & BLADE(550 MM.)RHD	TATA spare parts
264182400181	KIT FIT.OF WIPING SYSTEM	TATA spare parts
264182400186	ASSY.MECH.WIPER SYS.COMPLETE	TATA spare parts
264182400194	ASSY. WIPER ARM & BLADE(DRIVERSIDE)-RHD	TATA spare parts
264182400195	ASSY. WIPER ARM & BLADE(CODRIVERSIDE)-RH	TATA spare parts
264182400196	ASSY. WIPER LINKAGE-RHD BS2/3/4	TATA spare parts
264182406302	WASHER BOTTLE BS6	TATA spare parts
264182407501	GASKET BRKT TO FIRE WALL	TATA spare parts
264182408201	BRACKET [WIPER MOTOR]	TATA spare parts
264182409904	ASSY. WIPER BLADE BS1/2/3/4/6	TATA spare parts
264182409904AE	WIPER BLADES 713	TATA spare parts
264182409905	WIPER MOTOR [LHD] OFFER	TATA spare parts
264182409906	HEX SCREW	TATA spare parts
264182409915	17W HI-POWER WIPER MOTOR-RHD	TATA spare parts
264182409916	WIPER MOTOR LHD 17W 12V	TATA spare parts
264182409917	WIPER MOTOR RHD 17W 12V	TATA spare parts
264182409925	WIPER MOTOR 17W HI-POWER	TATA spare parts
264182409926	WIPER MOTOR 17W HI-POWER	TATA spare parts
264182409931	WIPER MOTOR 17W-RHD	TATA spare parts
264182409950	WIPER MOTOR HI-PWR (LHD) W/MSSL EURO1-4	TATA spare parts
264182409952	WIPER MOTOR HI-POWER (LHD) W/MSSL	TATA spare parts

264182409953	WIPER MOTOR HI POWER (RHD) BS2	TATA spare parts
264182409953AE	WIPER MOTOR 1415 715	TATA spare parts
264182409954	WIPER MOTOR HI POWER (RHD) W/TERMINALS	TATA spare parts
264182409955	WIPER MOTOR HI POWER (RHD) W/TERMINALS	TATA spare parts
264182409957	WIPER MOTOR 17W[H/P]-RHD	TATA spare parts
264182409959	WIPER MOTOR HI POWER (RHD) W/TERMINALS	TATA spare parts
264182409963	ARMATURE & BRG.ASSY.- LUCAS BS6-PH2	TATA spare parts
264182409964	GEAR BOX & PEG ASSY. BS6-PH2	TATA spare parts
264182409965	GEAR BOX COVER (W/O.MARK) BS6-PH2	TATA spare parts
264182409966	FINAL GEAR ASSY BS6	TATA spare parts
264182409967	GEAR LOCATION PLATE BS6-PH2	TATA spare parts
264182409968	WORM WHEEL & PINION M/C BS6	TATA spare parts
264182409969	SHAFT LINK AND PIN ASSY. BS6-PH2	TATA spare parts
264182409972	THROUGH BOLT BS6	TATA spare parts
264182409983	NOZZLE UNIT BS6	TATA spare parts
264183100103	ASSY DUCT OUTER LH	TATA spare parts
264183100104	DUCT OUTER RH W/S BOTTOM	TATA spare parts
264183100106	VENTILATION GRILL LEGROOM	TATA spare parts
264183100108	ASSY.BRACKET - LHD-BLOWER MOUNTING	TATA spare parts
264183100110	ASSY.BRACKET (COIL MOUNTING)-LH (SUB.)	TATA spare parts
264183100111	ASSY.BRACKET (COIL MOUNTING)-RH (SUB.)	TATA spare parts
264183100119	ASSY.BRACKET (PLENUM MTG.) LH	TATA spare parts
264183100120	ASSY.BRACKET (PLENUM MTG.) RH	TATA spare parts
264183100124	ASSY.BRKT.LHD [COIL HOUSING MTG.	TATA spare parts
264183100128	ASSY.BRACKET	TATA spare parts
264183100130	ASSY COIL HOUSING	TATA spare parts
264183100134	ASSY.DUCT (HVAC TO DEFROST)	TATA spare parts
264183100137	ASSY LEG VENT LH	TATA spare parts
264183100138	ASSY.LEG DUCT RH	TATA spare parts
264183100140	ASSY.MOUNTING PLATE FOR HEATING UNIT	TATA spare parts
264183100143	ASSY DUCT (HEATER UNIT TO PLENUM)	TATA spare parts
264183100144	ASSY VENTILATION GRILL (LEGROOM)	TATA spare parts
264183106303	DUCT BOT LEGROOM VENT	TATA spare parts
264183106306	DUCT OUTER LH W/S BOTTOM	TATA spare parts
264183106307	DUCT OUTER RH W/S BOTTOM	TATA spare parts
264183106308	DUCT INNER W/S BOTTOM	TATA spare parts
264183106309	ELBOW DUCT LH	TATA spare parts
264183106310	ELBOW DUCT RH	TATA spare parts
264183106311	HOSE VENTILATION	TATA spare parts
264183106316	TOP DUCT LEGROOM VENT	TATA spare parts
264183106318	ELBOW DUCT RH	TATA spare parts
264183106319	BELLOW LEGROOM VENT	TATA spare parts
264183106320	ELBOW DUCT LH	TATA spare parts
264183106321	ELBOW DUCT RH	TATA spare parts
264183106322	ELBOW DUCT LH	TATA spare parts
264183106323	TOP DUCT LEGROOM VENT	TATA spare parts
264183106324	ADAPTOR HOUSING	TATA spare parts

264183106331	ELBOW DUCT LH	TATA spare parts
264183106332	ELBOW DUCT RH	TATA spare parts
264183106334	DUCT (HEATER UNIT TO PLENUM)	TATA spare parts
264183107701	SEALING TOP DUCT	TATA spare parts
264183107702	FOAM PACKING	TATA spare parts
264183108205	CLAMPING PLATE (SUBROS)	TATA spare parts
264183200101	CLOSING PLATE ASSY	TATA spare parts
264183300106	ASSY.PUSH PULL CABLE Z TYPE	TATA spare parts
264183300107	ASSY.PUSH PULL CABLE HEATER	TATA spare parts
264183300108	ASSY.PUSH PULL CABLE Z TYPE	TATA spare parts
264183300109	ASSY.CABLE FOR LEG DUCT	TATA spare parts
264183300110	ASSY.PUSH PULL CABLE(LEG VENT CONTROL)	TATA spare parts
264183300113	ASSY.PUSH PULL CABLE(WATER VALVE CONTROL)	TATA spare parts
264183400103	ASSY.HEATER COIL COMPLETE	TATA spare parts
264183400104	ASSY.HEATER COIL	TATA spare parts
264183500105	ASSY. BRKT.FOR COIL HSG. MTG. RH	TATA spare parts
264183500106	ASSY. BRKT. FOR COIL HSG. MTG. LH	TATA spare parts
264183500107	ASSY. HEATER(WITH TWIN BLOWER)	TATA spare parts
264183500109	ASSY.HEATER(WITH TWIN BLOWER)	TATA spare parts
264183500112	ASSY HEATER DEMISTER WITH TWIN BLWR-24V	TATA spare parts
264183500113	ASSY HOSE DISCHARGE	TATA spare parts
264183500114	ASSY HOSE RECEIVER OUTLET	TATA spare parts
264183500115	ASSY HVAC COMPLETE (24-V)-LHD	TATA spare parts
264183500115AE	ASSY HVAC COMPL. (24-V)-2523	TATA spare parts
264183500116	ASSY.CONDENSER COMPL.	TATA spare parts
264183500116AE	ASSY CONDENSOR COMPL.-2523	TATA spare parts
264183505801	RUBBER HOSE (17IDX880L) - 509M	TATA spare parts
264183505801AE	RUBBER HOSE (17IDX880L) -2523	TATA spare parts
264183505802	RUBBER HOSE [17 ID X L 1450]	TATA spare parts
264183506301	COVER(HEATER COIL)-RHD LPTA 713 TC	TATA spare parts
264183506302	COVER (HEATER COIL)-LHD	TATA spare parts
264183506303	BLOWER CASE UPPER	TATA spare parts
264183506304	BLOWER CASE LOWER	TATA spare parts
264183506306	BLOWER WHEEL	TATA spare parts
264183506307	BLOWER GUARD	TATA spare parts
264184100101	BRACKET ASSY HEADBOX MTG LH BS6-PH2	TATA spare parts
264184100102	BRACKET ASSY HEADBOX MTG RH BS6-PH2	TATA spare parts
264184100103	BRKT ASSY HEADBOX MTG CENTER-LH BS6-PH2	TATA spare parts
264184100104	BRKT ASSY HEADBOX MTG CENTER-RH BS6-PH2	TATA spare parts
264184100105	HEADBOX ASSY LH BS6-PH2	TATA spare parts
264184100106	HEADBOX ASSY RH BS6-PH2	TATA spare parts
264184106301	HEADBOX LH BS6-PH2	TATA spare parts
264184106302	HEADBOX LH BS6-PH2	TATA spare parts
264184106303	CAP HEADBOX UPPER CENTER-LH BS6-PH2	TATA spare parts
264186900107	ASSY. SUPPORT BKT.	TATA spare parts
264186900110	ASSY.BKT (4 NUT)	TATA spare parts
264186900111	ASSY.BKT.(1 NUT)	TATA spare parts

264186900114	ASSY.REAR FRAME COMPL.WITH SEATBELT MTG.	TATA spare parts
264186900115	ASSY.FRAME TOP	TATA spare parts
264186900118	ASSY.CANOPY COVER	TATA spare parts
264186900120	FRAME ASSY FRONT	TATA spare parts
264186900154	ASSY FRAME FRONT	TATA spare parts
264188500101	SUPPORT BUMPER MTG LH	TATA spare parts
264188500102	SUPPORT BUMPER MTG RH	TATA spare parts
264188500104	END COVER LH BUMPER	TATA spare parts
264188500105	END COVER RH BUMPER	TATA spare parts
264188500106	BUMPER WELDED	TATA spare parts
26418850010622	ASSY BUMPER COWL-POWDER COATED	TATA spare parts
264188500108	ASSY BUMPER COMP BLACK POWDER COAT-COW	TATA spare parts
26418850010821	ASSY BUMPER COMPLETE EX PAINTED -COWL	TATA spare parts
26418850010822	ASSY. BUMPER BLACK POWDER COAT BS1/2/3/4	TATA spare parts
264188500110	BKT BUMPER MTG LH FRT	TATA spare parts
264188500111	BKT BUMPER MTG RH P/S	TATA spare parts
264188500114	BUMPER WELDED CAB	TATA spare parts
26418850011422	ASSY BUMPER CAB-POWDER COATED	TATA spare parts
264188500115	BUMPER ASSY COMP CAB	TATA spare parts
26418850011521	ASSY. BUMPER TS7651 EXT.BODY TOP COAT	TATA spare parts
26418850011522	ASY BUMPER COMP.TS7651 EXT.BODY TOP COA	TATA spare parts
264188500118	ASSY END COVER LH-BUMP	TATA spare parts
264188500119	ASSY. END COVER RH-BUMPER	TATA spare parts
264188500123	ASSY.SUPPORT COMPLT.LH	TATA spare parts
264188500124	ASSY.SUPPORT COMPLT.RH	TATA spare parts
264188500133	ASSY.SUPPORT (REGISTRATION PLATE MTG.)	TATA spare parts
264188500146	ASSY.BRACKET-LH (BUMPER MTG.)	TATA spare parts
264188500147	ASSY.BRACKET-RH (BUMPER MTG.)	TATA spare parts
264188500150	ASSY. BUMPER POWDER COATED(FUP) BS1- 4	TATA spare parts
264188500161	ASSY. FRONT BUMPER 709 EX2 BS2/3/4	TATA spare parts
264188500170	BUMPER ASSY	TATA spare parts
264188500175	SUPPORT ASSY LH BS6	TATA spare parts
264188500176	SUPPORT ASSY RH BS6	TATA spare parts
264188500194	FUPD ASSY WITH BRACKET BS6 PH2	TATA spare parts
264188500196	BUMPER ASSY WITH FUP BS6-PH2	TATA spare parts
264188503303	SUPPORT BRACKET LH BS6	TATA spare parts
264188503304	SUPPORT BRACKET RH BS6	TATA spare parts
264188503307	BRACKET BUMPER FUPD MTG LH BS6-PH2	TATA spare parts
264188503308	BRACKET BUMPER FUPD MTG RH BS6-PH2	TATA spare parts
264188506304	STEP PAD LH BUMPER 709	TATA spare parts
264188506305	STEP PAD RH BUMPER 709	TATA spare parts
264188508208	BKT LH BUMPER MTG	TATA spare parts
264188508209	BRACKET RH BUMPER MTG	TATA spare parts
264188508213	BUMPER	TATA spare parts
264188508223	BRACKET-LH-BUMPER MTG.	TATA spare parts
264188508224	BRACKET-RH-BUMPER MTG.	TATA spare parts
264188508260	BUMPER GUARD FRONT	TATA spare parts

264188806301	BEADING FRONT PANEL	TATA spare parts
264189100115	RUB MTG LOWER CAB MTG	TATA spare parts
264189100126	ASSY.MTG.BRACKET HANDLE	TATA spare parts
264189100127	RUB MTG LOWER CABLOCK MEC	TATA spare parts
264189100128	MTG PAD CABLOCK MECHANISM	TATA spare parts
264189100129	ASSY MTG HOOK-CAB LOCKING MECHANISM	TATA spare parts
264189100133	ASSY.BRACKET-UPPER	TATA spare parts
264189100134	CONNECTING LINK SHORT LH	TATA spare parts
264189100135	CONNECTING LINK LONG RH	TATA spare parts
264189100136	ASSY.LEVER	TATA spare parts
264189100137	ASSY.MTG.BRKT.COMPLETE (CHASSIS SIDE) BS	TATA spare parts
264189100139	STAY COMPLETE	TATA spare parts
264189100140	SSY.FINAL LINK	TATA spare parts
264189100141	MTG BKT LH CH SIDE 709	TATA spare parts
264189100142	MTG BKT RH CH SIDE 709	TATA spare parts
264189100143	ASSY.INTERMEDIATE LINK	TATA spare parts
264189100144	ASSY.MTG.BRACKET FRT LH	TATA spare parts
264189100145	ASSY.MTG.BRACKET FRT.RH	TATA spare parts
264189100146	HANDLE MTG CABLOCK MECH	TATA spare parts
264189100147	ASSY.HSG.BRKT.COMPLE	TATA spare parts
264189100148	HSG BRKT COMP RH	TATA spare parts
264189100149	CAB MTG MECHANISM LH 709	TATA spare parts
264189100150	CAB MTG MECHANISM RH 709	TATA spare parts
264189100151	SECONDARY LOCK 709	TATA spare parts
264189100152	ASSY.CAM	TATA spare parts
264189100153	CROSS TUBE RHD TOR BAR	TATA spare parts
264189100154	RUB BUSH FRONT MTG. BS1/2/3/4/6	TATA spare parts
264189100155	NUT PLATE FR MTG 709	TATA spare parts
264189100157	ASSY RUBBER BUSH (FRONT MOUNTING)	TATA spare parts
264189100165	SUP BOT RR MUDGUARD LH	TATA spare parts
264189100166	SUP BOT RR MUDGUARD RH	TATA spare parts
264189100171	MTG BKT RH RR CHA SIDE	TATA spare parts
264189100172	MTG BKT LH RR CHA SIDE	TATA spare parts
264189100173	TIE MEMBER RR MTG	TATA spare parts
264189100174	MTG BRACKET FR LH RHD	TATA spare parts
264189100175	MTG BRACKET RH LHD	TATA spare parts
264189100176	MTG BRACKET FRT RH RHD	TATA spare parts
264189100177	ASSEMBLY MTG. BRACKET FRONT LH-LHD.	TATA spare parts
264189100182	BRACKET UPPER CHAS SIDE	TATA spare parts
264189100184	MTG PAD CAB LOCK MECHANISM	TATA spare parts
264189100185	MTG HOOK CABLOCK MECHANISM	TATA spare parts
264189100187	ASSY.STAY CHANNEL BOTTOM BS6	TATA spare parts
264189100189	ASSY.TIE MEMBER(REAR MTG.)LHD COWL	TATA spare parts
264189100191	ASSY.STAY COMPLETE LPT-407	TATA spare parts
264189100193	ASSY.TIE MEMBER(REAR MTG.) RHD COWL	TATA spare parts
264189100194	ASSY.TIE MEMBER(REAR MTG.)LHD CAB	TATA spare parts
264189100196	ASSY CROSS TUBE (TORSION BAR) LHD	TATA spare parts

264189100198	ASSY.SUPPORT STAY REAR-FOR AUX.TANK	TATA spare parts
264189100199	ASSY.SUPPORT STAY REAR-FOR FLOOR	TATA spare parts
264189103402	BUSH BS6	TATA spare parts
264189103403	SERRATED BUSH RH	TATA spare parts
264189103404	SPACER BUSH 709	TATA spare parts
264189103701	MTG BKT BOT FR LH RHD	TATA spare parts
264189103702	MTG BKT BOT FR RH RHD	TATA spare parts
264189103703	ADJUSTER RH RHD TOR BAR	TATA spare parts
264189103704	ADJUSTER LH LHD TOR BAR	TATA spare parts
264189103705	MTG.BRACKET BOTTOM RH-LHD	TATA spare parts
264189103706	MTG.BRACKET BOTTOM LH LHD-FRONT	TATA spare parts
264189103713	CAB MTG REAR BS6-PH2	TATA spare parts
264189106005	LEVER (STAY) BS6	TATA spare parts
264189106303	MUDGUARD LH	TATA spare parts
264189106304	MUDGUARD RH	TATA spare parts
264189106305	MUDGUARD RR LH 709	TATA spare parts
264189106306	MUDGUARD RR RH 709	TATA spare parts
264189106307	SEALING REAR MUDGUARD	TATA spare parts
264189106308	MUD FLAP FRONT INNER LH	TATA spare parts
264189106309	MUD FLAP FRONT INNER RH	TATA spare parts
264189106310	MUD FLAP FRONT OUTER LH	TATA spare parts
264189106311	MUD FLAP FRONT OUTER RH	TATA spare parts
264189106312	MUD FLAP MIDDLE INNER LH	TATA spare parts
264189106313	MUD FLAP MIDDLE INNER RH	TATA spare parts
264189106314	RUB MTG UPPER CABLOCK MEC	TATA spare parts
264189106318	MUD FLAP FRONT INNER LH-RHD	TATA spare parts
264189106319	MUD FLAP FRONT INNER RH-RHD	TATA spare parts
264189106320	MUDFLAP FRONT INNER-LH LHD	TATA spare parts
264189106321	MUD FLAP FRONT OUTER LH-LHD	TATA spare parts
264189106322	MUDGUARD LH	TATA spare parts
264189106323	MUDGUARD_RH	TATA spare parts
264189106326	MUDFLAP FRONT INNER LH-LHD	TATA spare parts
264189106330	MUDFLAP REAR (SPRAY SUPPRESSION)	TATA spare parts
264189106331	MUDGUARD LH	TATA spare parts
264189106332	MUDGUARD RH	TATA spare parts
264189106337	MUDGUARD LH(BS-IV)	TATA spare parts
264189106338	MUDGUARD RH(BS-IV)	TATA spare parts
264189106705	PIN CABLOCK MECHANISM	TATA spare parts
264189106706	PIN INTERMEDIATE LOCK	TATA spare parts
264189106709	CAM_PIN BS6	TATA spare parts
264189106710	PINTOP&BOTTOM BS6	TATA spare parts
264189106711	PIN CENTRE BS6	TATA spare parts
264189106712	PIN BS6	TATA spare parts
264189106713	CARRIER PIN (RH) BS6	TATA spare parts
264189106907	SPACER REAR MTG 709	TATA spare parts
264189106908	CROSS TUBE (FRONT MOUNTING)	TATA spare parts
264189106909	CROSS TUBE	TATA spare parts

264189106910	SPACER TUBE	TATA spare parts
264189106913	SPACER CAB MOUNTING	TATA spare parts
264189107903	TORSION BAR RHD BS1/2/3/4	TATA spare parts
264189107904	TORSION BAR LHD	TATA spare parts
264189108004	SPECIAL BOLT TOR BAR ADJ	TATA spare parts
264189108006	STUD	TATA spare parts
264189108219	MTG CUP CABLOCK MECHA 709	TATA spare parts
264189108231	STAY CHANNEL TOP BS6	TATA spare parts
264189108257	CLAMP RR MUDGUARD MTG709	TATA spare parts
264189108266	PROTECTION CAP	TATA spare parts
264189108268	SUPPORT-REAR MUDGAURD MTG.	TATA spare parts
264189108270	MOUNTING CUP CABLOCK MECH	TATA spare parts
264189108272	PLATE(CAB LOCK)LPT709	TATA spare parts
264189108701	TORSION SPRING-PIVOT	TATA spare parts
264189108702	TORSION SPRING-LEVER	TATA spare parts
264189108703	TORSION SPRING	TATA spare parts
264189108704	TORSION SPRING-LOCK	TATA spare parts
264189110103	ASSY.CROSS TUBE (TORSION BAR) RHD	TATA spare parts
264189110110	ASSY KIT FOR MUDFLAP-LH	TATA spare parts
264189110111	ASSY KIT FOR MUDFLAP-RH	TATA spare parts
264189110121	ASSY.MUDFLAP FRONT INNER LH-RHD	TATA spare parts
264189110122	ASSY.MUDFLAP FRONT INNER RH-RHD	TATA spare parts
264189110123	ASSY.MUDFLAP FRONT INNER LH-LHD	TATA spare parts
264189110130	ASSY.SUPPORT BOTTOM -LH	TATA spare parts
264189110131	ASSY.SUPPORT BOTTOM -RH	TATA spare parts
264189110148	ASSY SUPPORT MUDGUARD BOTTOM	TATA spare parts
264189110168	MUDFLAP ASSY INNER-LH	TATA spare parts
264189110169	MUDFLAP ASSY INNER-RH	TATA spare parts
264189110170	ASSY.MUDFLAP MIDDLE INNER W/EXTN.COMP-LH	TATA spare parts
264189110171	ASSY.MUDFLAP MIDDLE INNER W/EXTN.COMP-RH	TATA spare parts
264189110175	ASSY MOUTING BRACKET REAR-LH	TATA spare parts
264189110176	ASSY MOUTING BRACKET-RH	TATA spare parts
264189110177	ASSY.MUDGUARD SUPPORT-LH	TATA spare parts
264189110178	ASSY.MUDGUARD SUPPORT-RH	TATA spare parts
264189110190	ASSY TIE MEMBER-REAR (BS-IV)	TATA spare parts
264189110196	ASSY.SUPPORT STAY FRONT (FOR FLOOR)	TATA spare parts
264189110198	ASSY.MUDGUARD SUPPORT-LH 613	TATA spare parts
264189118291	BRACKET-FOR TIE MEMBER MTG	TATA spare parts
264189118292	TIE MEMBER REAR-FOR BS-IV	TATA spare parts
264189120101	TIE MEMBER ASSY BS6	TATA spare parts
264189120145	TUBE ASSY TIE ROD	TATA spare parts
264189120146	CAB MTG ASSY REAR-LH BS6	TATA spare parts
264189120147	CAB MTG ASSY REAR-RH BS6	TATA spare parts
264189120148	TIE MEMBER ASSY REAR MTG BS6	TATA spare parts
264189120149	LEVER ASSY DAMPER BS6	TATA spare parts
264189120162	TIE MEMBER ASSY	TATA spare parts
264189120166	TUBE ASSY TIE ROD	TATA spare parts



264189120167	REAR SUPPORT REAR MTG CHASSIS SIDE BS6	TATA spare parts
264189120168	SPACER PLATE ASSY	TATA spare parts
264189120173	STUD ASSY BS6	TATA spare parts
264189120174	STUD ASSY BS6	TATA spare parts
264189120175	NUT PLATE ASSY CAB MTG REAR BS6	TATA spare parts
264189120177	CROSS TUBE ASSY BS6	TATA spare parts
264189120180	STAY ASSY	TATA spare parts
264191000102	SEAT DRIVER RH RHD	TATA spare parts
264191000103	ASSY DRIVER S SEAT LH LHD	TATA spare parts
264191000104	ASSY.DRIVER'S SEAT RH.RHD.	TATA spare parts
264191000106	ASSY. SEAT -RHD (DRIVER SIDE)	TATA spare parts
264191000108	ASSY. DRIVER SEAT W/HEAD REST-RHD BS1- 4	TATA spare parts
264191000110	ASSY.DRIVER SEAT RHD	TATA spare parts
264191000112	ASSY. DRIVER SEAT WITH HEAD REST-RHD.	TATA spare parts
264191000114	ASSY.DRIVER SEAT COMPLT.RHD	TATA spare parts
264191000117	ASSY. DRIVER SEAT WITH HEAD REST-RHD.	TATA spare parts
264191000118	ASSY. DRIVER SEAT WITH HEAD REST-RHD.	TATA spare parts
264191000120	ASSY.DRIVER SEAT COMPLT.RHD	TATA spare parts
264191000122	ASSY. DRIVER SEAT WITH HEAD REST-RHD.	TATA spare parts
264191000123	ASSY.DRIVER SEAT WITH H/REST-LHD	TATA spare parts
264191000124	ASSY.KNITTED DRIVER SEAT-RHD	TATA spare parts
264191000127	ASSY.DRIVER SEAT COMPLETE-RHD	TATA spare parts
264191000145	ASSY.DRIVER SEAT COMPLT. WEB TYPE-RHD	TATA spare parts
264191000148	ASSY DRIVER SEAT COMPL.WITH HD.REST-RHD	TATA spare parts
264191000149	ASSY. DRIVER'S SEAT RH	TATA spare parts
264191000152	ASSY.DRIVER SEAT COMPLT.WITH H/REST-LHD	TATA spare parts
264191000153	ASSY.DRIVER SEAT COMPLT.WITH H/REST-RHD	TATA spare parts
264191000164	DRIVER SEAT ASSY WITH HEADREST	TATA spare parts
264191001601	ASSY.DRIVER SEAT-RHD(WEB TYPE)	TATA spare parts
264191100110	ASSY.SEAT BOX COMPL.RHD DRIVER SEAT	TATA spare parts
264191100111	ASSY.SEAT BOX COMPL.LHD-DRIVER SEAT	TATA spare parts
264191100112	ASSY.SEAT BOX WITH LID -RHD	TATA spare parts
264191100113	ASSY.SEAT BOX WITH LID (CO-DRIVER SIDE)	TATA spare parts
264191100115	ASSY.SEAT BOX COMPLETE-RHD (DRIVER SEAT)	TATA spare parts
264191100116	ASSY.FRAME TOP (SEAT MTG.)	TATA spare parts
264191100129	RISER ASSY FRONT SEAT RH BS6-PH2	TATA spare parts
264191108601	SPACER	TATA spare parts
264191500101	SEAT BELT KIT COMPL 709	TATA spare parts
264191500109	ASSY. SEAT BELT KIT COMPLT. `E`CERTI.	TATA spare parts
264191500110	ASSY SEAT BELT MIDDLE PASSANGER	TATA spare parts
264191500111	ASSY SEAT BELT KIT CO-DRIVER SIDE	TATA spare parts
264191500112	ASSY SEAT BELT KIT DRIVER SIDE	TATA spare parts
264191500118	ASSY.SEAT BELT KIT COMPLETE	TATA spare parts
264191500119	ASSY.SEAT.BELT KIT DRIVER SIDE.	TATA spare parts
264191500120	ASSYSEAT BELT KIT CO-DRIVER SIDE	TATA spare parts
264191500123	ASSY.SEAT BELT KIT COMPLETE	TATA spare parts
264191500127	ASSY.SEAT BELT COMPLETE-DRIVER	TATA spare parts

264191500130	SEAT BELT KIT DR 709	TATA spare parts
264191500131	SEAT BELT KIT CO-DR 709	TATA spare parts
264191500132	SEAT BELT KIT MIDDLE PASS	TATA spare parts
264191500134	ASSY.SEAT BELT KIT COMPLETE	TATA spare parts
264191500155	ASSY.CABLE BUCKLE(DRIVER SIDE)-ECERT. BS	TATA spare parts
264191500162	ELR TONGUE SEAT BELT ASSY. LH E MARKED B	TATA spare parts
264191500163	ELR TONGUE SEAT BELT ASSY. RH E MARKED B	TATA spare parts
264191500164	ASSY.KIT ELR SEAT BELT-RH E CERT.W/SWITCH	TATA spare parts
264191500165	ASSY.KIT ELR SEAT BELT-LH E CERT.	TATA spare parts
264191500173	ASSY.KIT SEAT BELT COMP. `E`CERT	TATA spare parts
264191500174	ASSY.KIT SEAT BELT COMP. `E`CERT	TATA spare parts
264191500181	ASSY.SEAT BELT KIT COMPLETE	TATA spare parts
264191500182	ASSY.SEAT BELT COMPLETE DRIVER	TATA spare parts
264191500186	ASSY.SEAT BELT KIT COMPLETE	TATA spare parts
264191500190	ASSY.SEAT BELT COMPLETE(DRIVER)	TATA spare parts
264191500196	ASSY.SEAT BELT KIT-DRIV.SIDE(RHD) E CERT	TATA spare parts
264191500197	KIT-SEAT BELT FRONT	TATA spare parts
264191506301	COVER-SEAT BELT ANCHORAGE	TATA spare parts
264191700106	ASSY.STAND DRIVER SEAT MTG.	TATA spare parts
264191700107	ASSY.STAND DRIVER SEAT MTG.	TATA spare parts
264191720101	RISER ASSY FRONT SEAT RH BS6-PH2	TATA spare parts
264194000101	ASSEMBLY CO-DRIVERS SEAT COMPLETE RHD.	TATA spare parts
264194000103	ASSY.CO-DRIVER SEAT COMPLT.RHD.	TATA spare parts
264194000104	ASSY.CO-DRIVER SEAT COMPLT.	TATA spare parts
264194000106	ASSY.CO-DRIVER SEAT COMPLT.	TATA spare parts
264194000109	ASSY.CO-DRIVER SEAT WITH HEAD REST-RHD	TATA spare parts
264194000111	ASSY.CO-DRIVER SEAT COMPLT.	TATA spare parts
264194000112	ASSY.CO-DRIVER SEAT WITH HEAD REST-RHD	TATA spare parts
264194000113	ASSY.CO-DRIVER SEAT WITH HEAD REST-RHD	TATA spare parts
264194000115	ASSY.CO-DRIVER SEAT WITH HEAD REST-RHD	TATA spare parts
264194000116	ASSY.CO-DRIVER SEAT COMPLT.	TATA spare parts
264194000117	ASSY. CO-DRIVER&S SEAT	TATA spare parts
264194000120	ASSY.CO-DRIVER SEAT COMPLT.	TATA spare parts
264194000121	ASSY.CO-DRIVER SEAT COMPL.-LHD	TATA spare parts
264194000122	ASSY.CO-DRIVER SEAT WITH HEAD REST-RHD	TATA spare parts
264194000123	ASSY.CODRIVER SEAT WITH H/REST LHD	TATA spare parts
264194000124	ASSY.CO-DRIVER SEAT COMPLT.	TATA spare parts
264194000125	ASSY.CO-DRIVER SEAT COMPLT.	TATA spare parts
264194000143	ASSY CO-DRIVER SEAT WITH SINGLE H/R-RHD	TATA spare parts
264194000148	STATIC RAISER ASSY CO-DRIVER SEAT BS6-PH	TATA spare parts
264194000151	FOAM BLOCK BS6-PH2	TATA spare parts
264194000159	CO-DRIVER 2-SEATER ASSY BS6-PH2	TATA spare parts
264194100101	ASSY.TOOL BOX (CO-DRIVER SEAT)	TATA spare parts
264194100102	ASSY KNOB (TOOL BOX)	TATA spare parts
264197500111	SEAT BELT ASSY WITH ELR FRONT-LH BS6	TATA spare parts
264197500112	SEAT BELT ASSY WITH ELR FRONT-RH	TATA spare parts
264197500113	KIT-SEAT BELT ASSY ELR WITH MICRO SW FRT	TATA spare parts

264197500114	ASSY. SEAT BELT KIT DRIVER SIDE.	TATA spare parts
264197500117	ASSY. SEAT BELT KIT CO-DRIVER SID	TATA spare parts
264197500118	KIT-SEAT BELT WITH ELR FRONT	TATA spare parts
264197500119	ASSY. SEAT BELT MIDDLE PASSANGER.	TATA spare parts
264197500120	KIT-SEAT BELT WITH ELR & LAP BELT FRONT	TATA spare parts
264197500121	KIT-SEAT BELT W ELR LAP BELT & MS FRONT	TATA spare parts
264197500126	SEAT BELT ASSY WITH ELR FRONT-RH BS6-PH2	TATA spare parts
264197500130	LAP BELT ASSY MIDDLE BS6-PH2	TATA spare parts
264197500131	STEM BUCKLE ASSY FRONT BS6-PH2	TATA spare parts
264197500132	STEM BUCKLE ASSY.DRIVER BS6-PH2	TATA spare parts
264197500133	SEAT BELT ASSY WITH ELR FRONT-LH BS6-PH2	TATA spare parts
264197500134	CABLE BUCKLE ASSY CO-DRIVER BS6-PH2	TATA spare parts
264197500135	CABLE BUCKLE ASSY MIDDLE BS6-PH2	TATA spare parts
264197980101	KIT-SEAT BELT FRONT	TATA spare parts
264215400101	ALTERNATOR 90A INT.FAN W/VP	TATA spare parts
264215400102	ALTERNATOR12V;75AWITHVACUUMPUMP	TATA spare parts
264215403801	VACUUM PUMP ASSEMBLY	TATA spare parts
264215608201	BRACKET_SENSOR_WH_LPT_712_BSIV	TATA spare parts
264215608202	CLIP_ENGINE	TATA spare parts
264216100101	CONTAINER (ECU497 TCIC BSIV-6.34/4.125)	TATA spare parts
264216100102	CONTAINER (ECU497 TCIC BS-III-8.02/3.11)	TATA spare parts
264216100105	CONTAINER(497TCIC BS3-G40-8.02-3.11)	TATA spare parts
264216100108	CONTAINER ECU 497TCIC BS3(8.02/3.875)	TATA spare parts
264216100109	CONTAINER(LP712/LPT709)	TATA spare parts
264216100111	CONTAINER(ECU497TCIC BS4-6.9/4.125)OBDII	TATA spare parts
264216100112	CONTAINER(ECU 497TCIC BS-IV-6.9/4.42)OBD	TATA spare parts
264224100101	BRACKET ASSY ENGINE MTG FRONT-RH BS6	TATA spare parts
264224100102	BRACKET ASSY ENGINE MTG FRONT-LH BS6	TATA spare parts
264224100105	BRACKET ASSY ENGINE MTG FRONT BS6-PH2	TATA spare parts
264224200105	BRACKET ASSY ENGINE MTG REAR BS6-PH2	TATA spare parts
264229100107	ASSY METAL PIPE	TATA spare parts
264229100115	BUNDY TUBE ASSY	TATA spare parts
264229100117	BUNDY TUBE ASSY	TATA spare parts
264229100131	CLUTCH PEDAL ASSY WITH MTG BKT BS6	TATA spare parts
264229100144	TUBE ASSY	TATA spare parts
264229100146	CLUTC PIPE ASSY CMC TO CLUTCH BOOSTER	TATA spare parts
264229100147	SUPPORT BRACKET ASSY (CLUTCH)	TATA spare parts
264229100149	CLUTCH BOOSTER MTG BRACKET ASSY.	TATA spare parts
264229100150	CLUTCH BOOSTER ASSY (70 DIA)	TATA spare parts
264229100151	TUBE ASSY	TATA spare parts
264229100155	LEVER ASSY CLUTCH PEDAL BS6	TATA spare parts
264229100160	CLUTCHPEDALASSYWITHBUSH BS6	TATA spare parts
264229100163	CLUTCH PEDAL ASSY WITH BUSH BS6	TATA spare parts
264229100165	CLUTCH PEDAL ASSY WITH MTG BKTBS6	TATA spare parts
264229100168	CLUTCH PEDAL ASSY WITH BUSH BS6-PH2	TATA spare parts
264229100169	CLUTCH PEDAL ASSY WITH MTG BKT BS6-PH2	TATA spare parts
264229108223	BRACKET BUNDY TUBE MTG	TATA spare parts

264229108224	BRACKET BUNDY TUBE MTG	TATA spare parts
264229200104	CLUTCH PEDAL ASSY WITH RUBBER COVER	TATA spare parts
264229300101	PUSH ROD ASSY	TATA spare parts
264229300102	BUNDY TUBE ASSY CMC TO FIREWALL	TATA spare parts
264229300103	BUNDY TUBE ASSY FIREWALL TO HOSE	TATA spare parts
264229300104	BUNDY TUBE ASSY FROM HOSE TO BOOSTER	TATA spare parts
264229300106	BUNDY TUBE ASSY	TATA spare parts
264229300107	PUSH ROD ASSY	TATA spare parts
264229300108	BUNDY TUBE ASSY BS6	TATA spare parts
264229300109	BUNDY TUBE ASSY BS6	TATA spare parts
264229300120	PUSH ROD ASSY SLAVE CYLINDER BS6	TATA spare parts
264229300121	CLUTCH SLAVE CYLINDER ASSY BS6	TATA spare parts
264229300122	BUNDY TUBE ASSY CMC TO FIREWALL BS6	TATA spare parts
264229300123	CLUTCH PIPE ASSY VACUUM BOOSTER BS6	TATA spare parts
264229300124	VACUUM BOOSTER WITH CMC ASSY BS6	TATA spare parts
264229300128	BUNDY TUBE ASSY-LONG MEMBER BS6	TATA spare parts
264229300130	PIPE ASSY CMC TO BOOSTER BS6-PH2	TATA spare parts
264229500103	BRACKET ASSY CLUTCH PEDAL MTG BS6	TATA spare parts
264229500107	BRACKET ASSY SLAVE CYLINDER MTG BS6	TATA spare parts
264229500108	BRACKET ASSY CLUTCH PEDAL & SENSOR MTG B	TATA spare parts
264229503314	BRACKET-CLUTCH PIPE MTG BS6	TATA spare parts
264229990101	MINOR KIT-CLUTCH BOOSTER ASSY (70 DIA)	TATA spare parts
264229990102	MAJOR KIT-CLUTCH BOOSTER ASSY (70 DIA)	TATA spare parts
264229990126	KIT-MAJOR BS6	TATA spare parts
264229990127	KIT-MINOR BS6	TATA spare parts
264230100101	ASSY ACC. PEDAL WITH BRACKET	TATA spare parts
264230100104	ACCELERATOR CABLE ASSY	TATA spare parts
264230100105	ACCELERATOR PART ASSEMBLY	TATA spare parts
264230100106	ACCELERATOR CABLE ASSY	TATA spare parts
264231000101	ASSEMBLY FRAME COMPLETE	TATA spare parts
264231000103	ASSY FRAME COMPLETE	TATA spare parts
264231000104	FRAME ASSY WITH FITMENT	TATA spare parts
264231000106	FRAME ASSY	TATA spare parts
264231000107	ASSY. FRAME LPT709/34	TATA spare parts
264231000108	FRAME ASSY	TATA spare parts
264231000110	FRAME COMPLETE (W/O CLEATS)	TATA spare parts
264231000111	FRAME ASSY WITH FITMENT	TATA spare parts
264231000112	ASSY. FRAME COMPLETE	TATA spare parts
264231000115	ASSY FRAME COMPLETE	TATA spare parts
264231000116	FRAME ASSY COMP	TATA spare parts
264231000117	ASSY FRAME COMPLETE	TATA spare parts
264231000120	FRAME ASSY WITH FITMENT	TATA spare parts
264231000125	FRAME ASSY WITH FITMENT BS6	TATA spare parts
264231000127	FRAME ASSY WITH FITMENT BS6	TATA spare parts
264231000165	FRAME ASSY WITH FITMENT WITH TOP COAT BS	TATA spare parts
264231000167	FRAME ASSY WITH FITMENT BS6	TATA spare parts
264231000168	FRAME ASSY WITH FITMENT BS6	TATA spare parts

264231000170	FRAME ASSY WITH FITMENT BS6	TATA spare parts
264231000171	FRAME ASSY WITH FITMENT BS6	TATA spare parts
264231000175	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
26423100M10114	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
26423100M10115	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
26423100M10125	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
264231200101	ASSY.CROSS MEMBER (REAR SPRING REAR)	TATA spare parts
264231200102	ASSY SUPPORT CROSS MEMBER	TATA spare parts
264231200105	ASSY. SUPPORT (CROSS MEMBER)	TATA spare parts
264231200107	ASSY. SUPPORT CROSS MEMBER (R.H)	TATA spare parts
264231200108	ASSY. SUPPORT CROSS MEMBER (L.H)	TATA spare parts
264231200109	SUPPORT BRACKET	TATA spare parts
264231400101	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
264231407123	REINFORCEMENT RH BS6-PH2	TATA spare parts
264231407124	REINFORCEMENT LH BS6-PH2	TATA spare parts
264231408204	END CROSS MEMBER BS6-PH2	TATA spare parts
264231505101	TOW HOOK BS6	TATA spare parts
264231505103	TOW HOOK HOLDING BLOCK FRONT BS6-PH2	TATA spare parts
264232100105	ASSY FIRST LEAF WITH BUSH	TATA spare parts
264232100108	FRONT SPRING ASSY PARABOLIC NC	TATA spare parts
264232100109	FRONT SPRING ASSY PARABOLIC HC	TATA spare parts
264232100112	PARABOLIC LEAF SPRING ASSY FRONT NC	TATA spare parts
264232100113	PARABOLIC LEAF SPRING ASSY FRONT HC	TATA spare parts
264232100114	1ST LEAF ASSY	TATA spare parts
264232100115	1ST LEAF ASSY	TATA spare parts
264232107102	SECOND LEAF	TATA spare parts
264232107103	THIRD LEAF	TATA spare parts
264232107104	FOURTH LEAF	TATA spare parts
264232107118	2ND LEAF	TATA spare parts
264232107119	3RD LEAF	TATA spare parts
264232107121	2ND LEAF	TATA spare parts
264232107122	3RD LEAF	TATA spare parts
264232400101	ASSY.FIRST LEAF WITH BUSH	TATA spare parts
264232400103	REAR SPRING ASSY PARABOLIC	TATA spare parts
264232400104	FIRST LEAF ASSY WITH BUSH	TATA spare parts
264232400105	REAR SPRING ASSY	TATA spare parts
264232400106	1ST LEAF ASSY	TATA spare parts
264232400115	REAR SPRING ASSY	TATA spare parts
264232407102	SECOND LEAF	TATA spare parts
264232407103	THIRD LEAF	TATA spare parts
264232407104	FOURTH LEAF	TATA spare parts
264232407105	SPACER	TATA spare parts
264232407112	2ND LEAF	TATA spare parts
264232407113	3RD LEAF	TATA spare parts
264232800102	ANTI ROLL BAR ASSY WITH LINK (COMPLETE)	TATA spare parts
264232800103	LINK ASSY ANTI ROLL BAR BS6	TATA spare parts
264232800104	BRACKET ASSY ANTI ROLL BAR MTG BS6-PH2	TATA spare parts

264232800105	CONNECTING LINK ASSY FRONT BS6-PH2	TATA spare parts
264232800106	ANTI ROLL BAR ASSY WITH LINK BS6-PH2	TATA spare parts
264232803301	BRACKET ANTI ROLL BAR MTG BS6	TATA spare parts
264232803302	BRACKET ANTI ROLL BAR MTG BS6-PH2	TATA spare parts
264232806001	CONNECTING LINK BS6	TATA spare parts
264233000101	ASSY. FRONT AXLE WITH BRAKE	TATA spare parts
264233000102	FRONT AXLE ASSY WITH BRAKES	TATA spare parts
264233000107	FA 712 KMPL ABS RHD	TATA spare parts
264233000112	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
264233000113	FRONT AXLE ASSY BS6	TATA spare parts
264233200103	STUB AXLE ASSY RH BS6-PH2	TATA spare parts
264233200104	STUB AXLE ASSY LH BS6-PH2	TATA spare parts
264233208801	LOCK BOLT BS6-PH2	TATA spare parts
264233400101	FRONT HUB ASSY WITH POLE WHEEL BS6-PH2	TATA spare parts
264233400103	BEARING ASSY FRONT BS6-PH2	TATA spare parts
264233405301	GASKET BS6-PH2	TATA spare parts
264233405501	FRONT HUB ABS	TATA spare parts
264233406501	BEARING NUT FRONT HUB BS6-PH2	TATA spare parts
264233407801	OIL SEAL	TATA spare parts
264233408201	COVER FRONT HUB BS6-PH2	TATA spare parts
264233409201	LOCK WASHER BS6-PH2	TATA spare parts
264233409202	LOCK WASHER BS6-PH2	TATA spare parts
264233800101	TIE ROD ASSY (264233800102) BS6	TATA spare parts
264233800102	TIE ROD ASSY BS6	TATA spare parts
264233800104	TIE ROD ASSY BS6	TATA spare parts
264233800105	TIE ROD END ASSY-LH BS6-PH2	TATA spare parts
264233800106	TIE ROD END ASSY-RH BS6-PH2	TATA spare parts
264233805102	STEERING ARM BS6	TATA spare parts
264241000104	ASSY.UNITISED PROP.SHAFT COMPLETE	TATA spare parts
264241000107	ASSY.UNITISED PROP.SHAFT COMPLETE	TATA spare parts
264241100102	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
264241100106	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
264241100107	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
264241103701	FLANGE YOKE BS6-PH2	TATA spare parts
264241108201	PROPELLER SHAFT GUARD	TATA spare parts
264241108202	GUARD PROPELLER SHAFT BS6	TATA spare parts
264241109901	FLANGE YOKE BS6	TATA spare parts
264241110101	ASSY.PROP.SHAFT WITH CENTER BEARING	TATA spare parts
264241110104	ASSY.PROP.SHAFT (FRONT)	TATA spare parts
264241110112	PROPELLER SHAFT ASSY MONOTRON (36WB) BS6	TATA spare parts
264241110113	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
264241110114	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
264241110115	PROPELLER SHAFT ASSY COUPLING (45WB) BS6	TATA spare parts
264241110116	PROPELLER SHAFT ASSY MONOTRON (45WB) BS6	TATA spare parts
264241110117	PROPELLER SHAFT ASSY MONOTRON (39WB) BS6	TATA spare parts
264241110118	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
264241110119	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts

264241110120	PROPELLER SHAFT ASSY BS6	TATA spare parts
264241110127	PROPELLER SHAFT ASSY BS6-PH2	TATA spare parts
264241110131	PROPELLER SHAFT ASSY BS6-PH2	TATA spare parts
264241120102	ASSY.REAR PROP.SHAFT COMPLETE	TATA spare parts
264241307101	BRACKET CENTER BRG MTG (39 45WB) BS6	TATA spare parts
264241307102	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
264241307103	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
264242100105	AUTO SLACK ADJUSTER LH	TATA spare parts
264242100106	AUTO SLACK ADJUSTER RH	TATA spare parts
264242100116	DRUM BRAKE ASSY WITH DC LH BS6	TATA spare parts
264242100117	DRUM BRAKE ASSY WITH DC RH	TATA spare parts
264242100145	DRUM BRAKE ASSEMBLY WITH DC FR LH (140MM	TATA spare parts
264242100146	DRUM BRAKE ASSEMBLY WITH DC FR RH (140MM	TATA spare parts
264242100149	DRUM BRAKE ASSEMBLY WITH DC FRLH - 5507	TATA spare parts
264242100150	DRUM BRAKE ASSEMBLY WITH DC FRRH - 5507	TATA spare parts
264242103702	BRAKE DRUM BS6	TATA spare parts
264242300135	DRUM BRAKE ASSEMBLY WITH DC RR LH (140M	TATA spare parts
264242300136	DRUM BRAKE ASSEMBLY WITH DC RR LH (140M	TATA spare parts
264242303703	BRACKET ACTUATOR MTG LH	TATA spare parts
264242303704	BRACKET ACTUATOR MTG RH	TATA spare parts
264242308201	ANCHOR BRACKET LH	TATA spare parts
264242308202	ANCHOR BRACKET RH	TATA spare parts
264242990101	MAJOR KIT-AUTO ADJUSTER ASSY BS6	TATA spare parts
264242990103	KIT-BUSH	TATA spare parts
264242990113	MAJORKIT-AUTOADJUSTERASSY BS6	TATA spare parts
264242990114	KIT-BUSH	TATA spare parts
264242990119	KIT BUSH	TATA spare parts
264243200102	AIR TANK	TATA spare parts
264243200110	AIR TANK ASSY WITH MTG BKT (264243201601	TATA spare parts
264243200111	AIR TANK ASSY WITH MTG BKT 264243201602	TATA spare parts
264243500103	PIPE BUNCH ASSY CABIN BS6	TATA spare parts
264243700102	DUAL BRAKE VALVE -PR. SENSOR ARRG BS3/4	TATA spare parts
264243700103	BRAKE CHAMBER TYPE-12 FOR DOUBLE O-RING	TATA spare parts
264243700104	SPRING BRAKE ACTUATOR TYPE-12/12	TATA spare parts
264243700105	BRACKET ASSY HAND BRAKE VALVE MTG	TATA spare parts
264243700106	BRACKET ASSY FOR CONNECTOR MTG	TATA spare parts
264243700116	ANTI COMPOUNDING RELAY VALVE¿BS6	TATA spare parts
264243700118	RELAY VALVE & MODULATOR VALVE ASSY	TATA spare parts
264243700120	DUAL BRAKE VALVE BS6-PH2	TATA spare parts
264243700151	BRAKE CHAMBER BS6	TATA spare parts
264243700172	KIT-ANTI COMPOUNDING RELAY VALVE BS6	TATA spare parts
264243700179	SPRING BRAKE ACTUATOR BS6	TATA spare parts
264243800103	TUBE ASSY T-CONN TO FRONT BRAKE HOSE LH	TATA spare parts
264243800104	TUBE ASSY T-CONN TO FRONT BRAKE HOSE RH	TATA spare parts
264243800107	TUBE ASSY TMC SECONDARY TO ADAPTER BS6	TATA spare parts
264243800108	TUBE ASSY PRIMARY PORT TO REAR ADAPTER B	TATA spare parts
264243800110	HOSE ASSY RESERVOIR TO SECONDARY TMC BS6	TATA spare parts

264243800112	HOSE ASSY RESERVOIR TO PRIMARY TMC BS6	TATA spare parts
264243900129	ASSY METAL PIPE FROM CRIMP HOSE TO DDU	TATA spare parts
264243900155	RETRO KIT FOR LP712 42WB	TATA spare parts
264243900161	ASSY METAL PIPE WITH CRIMP HOSE (O RING	TATA spare parts
264243900164	ASSY.BRACKET (HOSE MTG ON REAR AXLE)	TATA spare parts
264243900182	ASSY NYLON PIPE SET CHASSIS BUNCH COMPL.	TATA spare parts
264243900202	PIPE BUNCH ASSY	TATA spare parts
264243900227	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
264243900228	METAL PIPE ASSY CRIMPED HOSE TO DDU	TATA spare parts
264243900234	PIPE ASSY BUNCH COMPLETE	TATA spare parts
264243900244	PIPE ASSY BUNCH COMPLETE	TATA spare parts
264243900268	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
264243903301	BRACKET(FOR NYLON PIPE BUNCH)	TATA spare parts
264243903302	BRACKET (FOR NYLON PIPE SET)	TATA spare parts
264243903303	BRACKET	TATA spare parts
264243903304	BRACKET (FOR FRONT HOSE MOUNTING)	TATA spare parts
264243903305	PARTITION BRACKET	TATA spare parts
264243903307	BRACKET	TATA spare parts
264243903310	BRACKET (NYLON PIPE ROUTING) BS6	TATA spare parts
264243903311	BRACKET BS6-PH2	TATA spare parts
264243910129	PIPE ASSY BUNCH COMP. W/O GAUGE LINES	TATA spare parts
264243910195	PIPE ASSY COMPLETE BUNCH	TATA spare parts
264243910211	BUNCH PIPE ASSY	TATA spare parts
264243910212	METAL PIPE ASSY JOINT 1 TO JOINT 2	TATA spare parts
264243910213	METAL PIPE ASSY RST TO T-CONN	TATA spare parts
264243910214	METAL PIPE ASSY T-CONN TO DBV	TATA spare parts
264243910215	METAL PIPE ASSY JOINT 1 TO JOINT 2	TATA spare parts
264243910216	METAL PIPE ASSY JOINT TO HOSE	TATA spare parts
264243910228	METAL PIPE ASSY BS6	TATA spare parts
264243910229	METAL PIPE ASSY BS6	TATA spare parts
264243910230	METAL PIPE ASSY BS6	TATA spare parts
264243910231	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
264243910233	PIPE BUNCH ASSY BS6	TATA spare parts
264243910255	PIPE BUNCH ASSY BS6	TATA spare parts
264243910266	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
264243910285	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
264243920153	ADAPTER ASSY	TATA spare parts
264243920161	PIPE ASSY BUNCH COMPLETE	TATA spare parts
264243920293	METAL PIPE ASSY HOSE TO JOINT BS6	TATA spare parts
264243920294	METAL PIPE ASSY JOINT 1 TO JOINT 2 BS6	TATA spare parts
264243920295	METAL PIPE ASSY JOINT TO DDU BS6	TATA spare parts
264243930102	PIPE ASSY BUNCH COMPLETE	TATA spare parts
264243930176	PIPE ASSY BUNCH FOR CHASSIS	TATA spare parts
264243930196	PIPE ASSY BUNCH COMPLETE	TATA spare parts
264243930198	PIPE ASSY BUNCH COMPLETE	TATA spare parts
264243940102	PIPE ASSY BUNCH COMPLETE	TATA spare parts
264243940119	METAL PIPE ASSY CRIMPED HOSE TO DDU	TATA spare parts



264243940120	PIPE ASSY BUNCH FOR CAB	TATA spare parts
264243940121	PIPE ASSY BUNCH FOR CHASSIS	TATA spare parts
264243940137	NYLON PIPE BUNCH ASSY (36WB) BS6	TATA spare parts
264243940159	NYLON PIPE BUNCH ASSY (39WB) BS6	TATA spare parts
264243940169	METAL PIPE ASSY HOSE TO JOINT BS6	TATA spare parts
264243940170	METAL PIPE ASSY BS6	TATA spare parts
264243940171	METAL PIPE ASSY JOINT TO DDU BS6	TATA spare parts
264243940172	METAL PIPE ASSY JOINT 1 TO JOINT 2 BS6	TATA spare parts
264243940177	NYLON PIPE BUNCH ASSY (45WB) BS6	TATA spare parts
264243940183	NYLON PIPE BUNCH ASSY (52WB) BS6	TATA spare parts
264243990101	KIT-BRAKE CHAMBER TYPE 12	TATA spare parts
264246100104	INTERMEDIATE SHAFT ASSY	TATA spare parts
264246100105	STEERING COLUMN ASSY	TATA spare parts
264246100106	RUBBER BELLOW ASSY	TATA spare parts
264246108201	CLAMPING RING	TATA spare parts
264246208001	HEX FL SCREW M14X1.5X22 TS17130 10.9	TATA spare parts
264246305101	PITMAN ARM BS6	TATA spare parts
264246600103	STEERING GEAR BOX ASSY BS6	TATA spare parts
264246600104	WORM & RACK ASSY BS6	TATA spare parts
264246600115	POWER STEERING PUMP ASSY BS6-PH2	TATA spare parts
264246600116	HOUSING ASSEMBLY BS6-PH2	TATA spare parts
264246700101	BRACKET ASSY POWER STEERING PUMP MTG BS6	TATA spare parts
264246703303	BRACKET STG GEAR BOX MTG BS6	TATA spare parts
264246800102	SUCTION LINE ASSY RESR. TO PUMP	TATA spare parts
264246800103	PRESSURE LINE ASSY PUMP TO GB	TATA spare parts
264246800104	RETURN LINE ASSY	TATA spare parts
264246800107	PRESSURE LINE ASSY (PUMP TO GB)	TATA spare parts
264246800108	SUCTION LINE ASSY (RESR.TO PUMP)	TATA spare parts
264246800113	HIGH PRESSURE LINE ASSY BS6	TATA spare parts
264246800120	RETURN LINE ASSY BS6	TATA spare parts
264246800122	SUCTION LINE ASSY BS6	TATA spare parts
264246800124	HIGH PRESSURE LINE ASSY BS6-PH2	TATA spare parts
264246803301	BRACKET L	TATA spare parts
264246900102	DRAG LINK ASSY BS6	TATA spare parts
264246990116	KIT-SEAL INPUT SHAFT BS6	TATA spare parts
264246990117	MAJOR KIT-SEAL BS6	TATA spare parts
264246990118	MAJOR KIT-SEAL BS6	TATA spare parts
264247000101	FUEL TANK ASSY	TATA spare parts
264247000108	ASSY. FUEL TANK COMPLETE WITH MOUNTING B	TATA spare parts
264247000109	ASSY. FUEL TANK COMPLETE WITH MTG. BRACK	TATA spare parts
264247000110	FUEL TANK ASSY WITH STRAP & SUPPORT BS6	TATA spare parts
264247000124	FUEL TANK ASSY (NEW MTG CHANGE) BS6	TATA spare parts
264247500106	ARRESTOR ASSY FRONT CYLINDER LH	TATA spare parts
264247500107	ARRESTOR ASSY FRONT CYLINDER RH	TATA spare parts
264247518201	COMPLIANCE PLATE BS6	TATA spare parts
264247600104	FUEL SUCTION PIPE ASSY	TATA spare parts
264247600105	ASSY. SUCTION LINE. (STRAINER - MECH. FE	TATA spare parts

264247600106	ASSY. FUEL LINE(FUEL TANK TO STRAINER)	TATA spare parts
264247600107	ASSY. FUEL LINE (STRAINER TO WATER SEPAR	TATA spare parts
264247600108	ASSY. FUEL LINE(W/SEP TO ENGINE INTAKE)	TATA spare parts
264247600109	ASSY. RETURN LINE(ENGINE TO FUEL TANK)	TATA spare parts
264247600123	ASSY. SUCTION LINE (TANK TO STRAINER)	TATA spare parts
264247600126	ASSY. RETURN LINE (ENGINE TO FUEL TANK	TATA spare parts
264247600134	ASSY. FUEL LINE (FUEL TANK TO STRAINER)	TATA spare parts
264247600135	ASSY. FUEL LINE (WATER SEPARATOR TO FIP)	TATA spare parts
264247600136	ASSY. FUEL LINE (FEED PUMP TO W/SEP)	TATA spare parts
264247600137	ASSY. FUEL LINE (W/SEP TO ENGINE)	TATA spare parts
264247600138	FUEL PIPE ASSY RETURN LINE	TATA spare parts
264247600140	ASSY. FUEL LINE (STRAINER TO WATER SEPAR	TATA spare parts
264247600141	ASSY. FUEL LINE(W/SEP TO ENGINE INTAKE)	TATA spare parts
264247600142	ASSY. RETURN LINE(ENGINE TO FUEL TANK)	TATA spare parts
264247600154	FUEL SUCTION LINE ASSY TANK TO B. FILTER	TATA spare parts
264247600155	FUEL SUCTION LINE ASSY B. FILTER TO FEED	TATA spare parts
264247600156	FUEL SUCTION LINE ASSY FEED TO FILTER	TATA spare parts
264247600157	FUEL SUCTION LINE ASSY F. FILTER TO FIP	TATA spare parts
264247600162	SUCTION LINE TANK TO B. FILTER	TATA spare parts
264247600163	RETURN LINE ASSY ENGINE TO FUEL TANK	TATA spare parts
264247600164	RETURN LINE ASSY ON TANK	TATA spare parts
264247600165	SUCTION LINE B. FILTER TO PUMP	TATA spare parts
264247600167	SUCTION LINE ASSY TANK TO PROTECT FILTER	TATA spare parts
264247600168	SUCTION LINE PROTECTFILTER TO MAINFILTER	TATA spare parts
264247600169	FUEL SUCTION LINE ASSY FILTER TO FIP	TATA spare parts
264247600170	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
264247600171	BRACKET ASSY BRACKET (MAIN FILTER MTG )	TATA spare parts
264247600173	BRACKET ASSY FUEL FILLER MTG	TATA spare parts
264247600174	SUCTION PIPE ASSY STRAINER TO FEED PUMP	TATA spare parts
264247600184	SUCTION FUEL PIPE ASSY	TATA spare parts
264247600187	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
264247600189	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
264247600190	FUEL RETURN PIPE ASSY BS6	TATA spare parts
264247600191	RETURN FUEL PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
264247600192	FUEL PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
264247600193	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
264247600194	HP PIPE ASSY BS6	TATA spare parts
264247600197	HP PIPE ASSY BS6	TATA spare parts
264247600198	HP PIPE ASSY BS6	TATA spare parts
264247600199	HP PIPE ASSY BS6	TATA spare parts
264247600204	FUEL RETURN PIPE ASSY BS6	TATA spare parts
264247600209	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
264247600225	RETURN FUEL PIPE ASSY (METAL)-FFRL BS6	TATA spare parts
264247600228	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
264247600229	FUEL SUCTION PIPE ASSY (METAL)-FFRL BS6	TATA spare parts
264247600233	HP PIPE ASSY BS6	TATA spare parts
264247600234	HP PIPE ASSY BS6	TATA spare parts

264247600237	VENT PIPE ASSY BS6	TATA spare parts
264247600245	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
264247604203	CLAMP BS6	TATA spare parts
264247606804	UNION	TATA spare parts
264247606805	T-CONNECTOR BS6	TATA spare parts
264247607501	GROMMET BS6-PH2	TATA spare parts
264247607502	GROMMET BS6-PH2	TATA spare parts
264247607701	CLAMP,FUEL LINE M6 STUD MOUNTED	TATA spare parts
264247607702	CLAMP FUEL LINE M6 STUD	TATA spare parts
264247608209	BRACKET FUEL CLAMP	TATA spare parts
264247608213	BRACKET FOR FUEL LINE	TATA spare parts
264247608214	BRACKET FOR STRAINER MOUNTING	TATA spare parts
264247608217	BRACKET BS6	TATA spare parts
264247610101	VENT PIPE ASSY BS6	TATA spare parts
264247610102	VENT PIPE ASSY BS6	TATA spare parts
264247610113	END FITTING BS6-PH2	TATA spare parts
264247610114	END FITTING BS6-PH2	TATA spare parts
264247700101	BANJO BS6	TATA spare parts
264247700102	HP REGULATOR ASSY	TATA spare parts
264247700104	HP REGULATOR ASSY INTEGRATED 24V BS6	TATA spare parts
264247700105	SOLENOID VALVE ASSY BS6	TATA spare parts
264247703301	CONNECTOR BS6	TATA spare parts
264247706101	BRACKET BS6	TATA spare parts
264247706801	CONNECTOR BS6	TATA spare parts
264247706802	CONNECTOR PRV CAP BS6	TATA spare parts
264247706805	HYDROSTAT RELIEF VALVE	TATA spare parts
264247706806	CONNECTOR PRV CAP BS6	TATA spare parts
264247706807	CONNECTOR BS6	TATA spare parts
264247708001	ALLEN BOLT M5X0.75 BS6	TATA spare parts
264247709901	PRESSURE SENSOR	TATA spare parts
264247709902	FILTER ELEMENT	TATA spare parts
264247800101	ASSY VENTING.PIPE-2 (REGULATOR TO EQUAL	TATA spare parts
264247800102	ASSY HP CNG PIPE-1(FRT.RH TO REAR RH CYL	TATA spare parts
264247800103	ASSY VENT.PIPE-1(FROM EQUAL CROSS BODY T	TATA spare parts
264247800104	ASSY VENT.PIPE (FRT.RH CYL.TO EQUAL CROS	TATA spare parts
264247800105	ASSY VENTING.PIPE -1 (FROM EQUAL CROSS B	TATA spare parts
264247800107	ASSY VENT.PIPE-2(FRT.RH TO REAR RH CYL.)	TATA spare parts
264247800119	HP PIPE ASSY	TATA spare parts
264247800121	HP PIPE ASSY	TATA spare parts
264247800122	HP PIPE ASSY FRT LH CYL TO FRT RH CYL	TATA spare parts
264247800123	HP PIPE ASSY	TATA spare parts
264247800124	HP PIPE ASSY 3-WAY VALVE TO FRONT CYL	TATA spare parts
264247800125	VENT PIPE ASSY	TATA spare parts
264247800126	VENT PIPE ASSY	TATA spare parts
264247800127	VENT PIPE ASSY	TATA spare parts
264249000101	KIT-EXHAUST ASSY	TATA spare parts
264249100101	ASSY.SILENCER COMPLETE	TATA spare parts

264249100103	ASSY.FRONT EXHAUST PIPE(WITH FLEX.BELLOW	TATA spare parts
264249100104	ASSY.SILENCER COMPLETE	TATA spare parts
264249100105	ASSY.FRONT EXHAUST PIPE	TATA spare parts
264249100106	EXHAUST PIPE ASSY BS6	TATA spare parts
264249100108	ASSY. MOUNTING STRAP (POC DOC)	TATA spare parts
264249100110	PIPE ASSY-DPS SENSOR-INTAKE BS6	TATA spare parts
264249100111	ASSY.SILENCER COMPLETE	TATA spare parts
264249100115	ASSY.FRONT EXHAUST PIPE	TATA spare parts
264249100116	ASSY FRONT EXHAUST PIPE	TATA spare parts
264249100119	ASSY PIPE EXHAUST	TATA spare parts
264249100120	ASSY. EXHAUST PIPE (SILENCER)	TATA spare parts
264249100123	ASSY.EXHAUST PIPE(WITH FLEX BELLOW)	TATA spare parts
264249100135	ASSY PIPE EXHAUST DPS	TATA spare parts
264249100136	ASSY. EXHAUST PIPE (SILENCER-DPS)	TATA spare parts
264249100137	BRACKET ASSY-EXHAUST CLAMP MTG BS6	TATA spare parts
264249100138	CLAMP ASSY-CATCON BS6	TATA spare parts
264249100141	BRACKET ASSY CATCON MTG	TATA spare parts
264249100142	BRACKET ASSY CATCON MTG	TATA spare parts
264249100146	BRACKET ASSY SILENCER MTG	TATA spare parts
264249100156	STRAP ASSY CATCON MTG	TATA spare parts
264249100159	PIPE ASSY-DPS SENSOR-REAR BS6	TATA spare parts
264249104202	CLAMP CATCON MTG BS6-PH2	TATA spare parts
264249105801	RUBBER HOSE PRE-CATCON	TATA spare parts
264249105802	RUBBER HOSE POST-CATCON	TATA spare parts
264249109901	WIRE ROPE (FOR HEAT SHIELD MOUNTING)	TATA spare parts
264249109902	HEAT SHIELD-EXHAUST PIPE-1ST PIECE	TATA spare parts
264249109903	HEAT SHIELD-EXHAUST PIPE-2ND PIECE	TATA spare parts
264249109904	HEAT SHIELD-EXHAUST PIPE-3RD PIECE	TATA spare parts
264249109905	HEAT SHIELD-EXHAUST PIPE-4TH PIECE	TATA spare parts
264249109906	HEAT SHIELD-POC DOC-1ST PIECE	TATA spare parts
264249109907	HEAT SHIELD-EXHAUST PIPE-2ND PIECE	TATA spare parts
264249109909	HEAT SHIELD OUTER	TATA spare parts
264249109910	HEAT SHIELD CATALYTIC CONVERTER	TATA spare parts
264249109911	HEAT SHIELD OUTER 1	TATA spare parts
264249109912	HEAT SHIELD OUTER 2	TATA spare parts
264249109914	HEAT SHIELD OUTER 4	TATA spare parts
264249200102	ASSY. BRACKET (POC DOC MTG)	TATA spare parts
264249200103	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
264249200112	NOISE SHIELD ASSY BOTTOM REAR	TATA spare parts
264249200113	NOISE SHIELD ASSY BOTTOM FRONT	TATA spare parts
264249200114	NOISE SHIELD ASSY BOTTOM FRONT FLAP-RH	TATA spare parts
264249200115	NOISE SHIELD ASSY BOTTOM FRONT FLAP-LH	TATA spare parts
264249200117	BRACKET ASSY NOISE SHIELD MTG	TATA spare parts
264249200118	BRACKET ASSY NOISE SHIELD MTG	TATA spare parts
264249200119	BRACKET ASSY NOISE SHIELD MTG	TATA spare parts
264249200120	BRACKET ASSY NOISE SHIELD MTG	TATA spare parts
264249200121	BRACKET ASSY DOC POC MTG	TATA spare parts

264249200124	FRONT PIPE ASSY BS6	TATA spare parts
264249200125	BRACKET ASSY UREA TANK MTG BS6	TATA spare parts
264249200126	FRONT PIPE ASSY BS6	TATA spare parts
264249200135	BRACKET ASSY TAIL PIPE MTG BS6	TATA spare parts
264249200136	PIPE ASSY UREA SUPPLY 264249200131 BS6	TATA spare parts
264249200137	UREA PIPE ASSY(SUCTION LINE 1) BS6	TATA spare parts
264249200138	PIPE ASSY UREA SUPPLY (OLD PART - 264249	TATA spare parts
264249200139	PIPE ASSY UREA SUPPLY (OLD PART - 264249	TATA spare parts
264249200140	UREA PIPE ASSY SUPPLY PRESSURE LINE NYLO	TATA spare parts
264249200153	TAIL PIPE ASSY BS6	TATA spare parts
264249203306	BRACKET NOISE SHIELD	TATA spare parts
264249203311	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
264249203312	CLAMP EXHAUST MTG BS6	TATA spare parts
264249203317	BRACKET BS6	TATA spare parts
264249203318	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
264249203319	BRACKET BS6	TATA spare parts
264249203320	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
264249203323	BRACKET BS6	TATA spare parts
264249203340	BRACKET BS6-PH2	TATA spare parts
264249203341	L-BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
264249203344	BRACKET-DPS SENSOR MTG BS6	TATA spare parts
264249204201	MOUNTING STRAP (POC DOC MTG.)	TATA spare parts
264249204204	BRACKET STRAP MTG	TATA spare parts
264249206909	TAIL PIPE BS6	TATA spare parts
264249208202	BRACKET (DPS MTG.)	TATA spare parts
264249208209	BRACKET (EXHAUST MTG.)	TATA spare parts
264249208225	BRACKET EXHAUST PIPE	TATA spare parts
264249208226	BRACKET DOC POC MTG	TATA spare parts
264249208233	BRACKET FOR SILENCER MOUNTING	TATA spare parts
264249208234	BRACKET SILENCER ASSY MTG	TATA spare parts
264249209905	V-BAND CLAMP	TATA spare parts
264249210101	CLAMP ASSY CATCON MTG BS6-PH2	TATA spare parts
264249600105	HEAT SHIELD PIPE ASSY FRONT	TATA spare parts
264249600106	HEAT SHIELD ASSY POC DOC	TATA spare parts
264254100104	ASSY.BATTERY CABLE +VE 50SQ.MM L=2800MM	TATA spare parts
264254100105	ASSY BATT.CABLE +VE 0.65M 50SQ ISO	TATA spare parts
264254100106	ASSY.BATT.CABLE -VE 3.05M ISO6722 CLASS	TATA spare parts
264254100107	ASSY.BATT.CABLE +VE 2.8M_ISO_6722_CLASS	TATA spare parts
264254100108	ASSY BATT CABLE +VE_0.3M_50SQMM_ISO6722	TATA spare parts
264254100110	BATT CABLE +VE_0.35M_ISO 6722 CLASS D	TATA spare parts
264254100111	ASSY.BATT.CABLE ISO6722 W/MEGA FUSE	TATA spare parts
264254100112	ASSY. BATT. CABLE 50SQ.MM W/MEGA FUSE	TATA spare parts
264254100113	BATT CABLE+VE_0.65M_W.COT_50SQMM	TATA spare parts
264254100124	ASSY. BATTERY CABLE+VE_0.35_ISO6722	TATA spare parts
264254100128	BATTERY TRAY ASSY LP708	TATA spare parts
264254100129	BATTERY TRAY ASSY	TATA spare parts
264254100130	BATTERY TRAY ASSY	TATA spare parts

264254100134	BATTERY CUT OFF SWITCH MTG.BKT.	TATA spare parts
264254100135	BATTERY CABLE ISO6722 CLASS D 50SQMM	TATA spare parts
264254100136	BATTERY CABLE POSITIVE 2.1M 50SQMM	TATA spare parts
264254100137	BATTERY CABLE NEGATIVE 2.5 50SQMM	TATA spare parts
264254100138	BATTERY CABLE POSITIVE 0.25M 25SQMM	TATA spare parts
264254100139	BATTERY CABLE POSITIVE 0.28M 25SQMM	TATA spare parts
264254200106	INSTRUMENT CLUSTER BSIV WITH 0.80 RATIO	TATA spare parts
264254200107	INST_CLUSTER_WITH_0.76_RATIO	TATA spare parts
264254200108	INST.CLUSTER 0.94	TATA spare parts
264254200109	INSTRUMENT CLUSTER ASSY 0.90 LPT407	TATA spare parts
264254200110	INSTRUMENT_CLUSTER_(0.80)_LP_712_BSIV	TATA spare parts
264254200111	INST_CLUSTER_BSIV_W/PTO_RATIO 0.80	TATA spare parts
264254200114	INSTUMENT CLUSTER 1:0.88	TATA spare parts
264254200115	INSTRUMENT CLUSTER - MINDA STONERIDGE (0	TATA spare parts
264254200120	ASSY. PLATE FOR CBCU MTG.	TATA spare parts
264254200122	ASSY ELECTRICAL PANEL BOX	TATA spare parts
264254200123	INST CLUSTER 1:0.85 LP712/38WB BSIV	TATA spare parts
264254200132	INSTRUMENT CLUSTER	TATA spare parts
264254200134	INST. CLUSTER LP709 0.76CNG BSIV	TATA spare parts
264254200140	BRACKET ASSY FUSEBOX MTG	TATA spare parts
264254200144	INSTRUMENT CLUSTER ELEC-SPEEDO 0.94	TATA spare parts
264254200145	INSTRUMENT CLUSTER ELEC-SPEEDO 0.80	TATA spare parts
264254200157	TELL-TALE INDICATOR BS6	TATA spare parts
264254204901	RELAY 12V 70A WITH RESISTOR OEN MAKE	TATA spare parts
264254204902	RELAY 12V 70 AMP. WITH DIODE	TATA spare parts
264254206303	COVER CBCU	TATA spare parts
264254206304	COVER ELECTRICAL PANEL	TATA spare parts
264254206305	MAXI FUSE COVER	TATA spare parts
264254206306	COVER VECU & FUSE BOX TOP	TATA spare parts
264254209901	ECU 12V FOR 497 DICORE ENG. BS3/4	TATA spare parts
264254209902	SPEEDO METER 0.9 RATIO	TATA spare parts
264254209903	SPEEDOMETER RATIO -0.94 MOVEMENT (12V)	TATA spare parts
264254209904	DIAL WITH FUEL AND TATA LOGO ASSY	TATA spare parts
264254209905	DIAL WITH TEMP AND TATA LOGO ASSY	TATA spare parts
264254209912	EGR CONTROLLER 497 TCIC ENG	TATA spare parts
264254244901	RELAY 24V 50A WITH DIODE- OEN MAKE	TATA spare parts
264254300103	CAMERA	TATA spare parts
264254300108	MICROPHONE	TATA spare parts
264254300109	ANTENNA	TATA spare parts
264254300110	SPEAKER	TATA spare parts
264254300111	CAMERA	TATA spare parts
264254300113	SINGLE CONTROLLER UNIT	TATA spare parts
264254300114	SPEAKER	TATA spare parts
264254300117	STAND BUS DRIVER CONSOLE	TATA spare parts
264254300118	BUS DRIVER CONSOLE	TATA spare parts
264254304901	RELAY 12V 70A WITH DIODE	TATA spare parts
264254500106	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts

264254501601	SWITCH¿ EMERGENCY HELP	TATA spare parts
264254600116	WIRING HARNESS MAIN	TATA spare parts
264254600117	WIRING HARNESS MAIN	TATA spare parts
264254600120	WIRING HARNESS TAIL	TATA spare parts
264254600134	W/H HEAD LAMP & BLINKER	TATA spare parts
264254600135	W/H ENGINE	TATA spare parts
264254600136	W/H MAXI FUSE	TATA spare parts
264254600137	W/H SENSOR	TATA spare parts
264254600138	W/H TAIL	TATA spare parts
264254600139	W/H MAIN	TATA spare parts
264254600140	W/H SWITCH	TATA spare parts
264254600141	W/H CAN PIGTAIL	TATA spare parts
264254600148	W/H AIR PRESS PIGTAIL	TATA spare parts
264254600189	BATTERY CABLE +VE MEGA FUSE	TATA spare parts
264254600193	WIRING HARNESS MAXI FUSE	TATA spare parts
264254600195	WIRING HARNESS MAXI FUSE	TATA spare parts
264254600196	WIRING HARNESS MAXI FUSE	TATA spare parts
264254600198	WIRING HARNESS TAIL	TATA spare parts
264254601651	W/H ROOF	TATA spare parts
264254601693	W/H TAIL	TATA spare parts
264254601696	W/H ENGINE	TATA spare parts
264254601697	W/H MAIN	TATA spare parts
264254603301	BRACKET WIRING HARNESS INTER CONN MTG	TATA spare parts
264254603306	BRACKET INTERCONNECTION MTG BS6	TATA spare parts
264254603308	BRACKET WIRING HARNESS CLAMP MTG BS6-PH2	TATA spare parts
264254608207	GEAR BOX MTG BRKT (L-TYPE)	TATA spare parts
264254610102	WIRING HARNESS TAIL	TATA spare parts
264254610103	WIRING HARNESS TAIL	TATA spare parts
264254610108	WIRING HARNESS MAIN	TATA spare parts
264254610109	WIRING HARNESS MAIN	TATA spare parts
264254610111	WIRING HARNESS EMS	TATA spare parts
264254610112	WIRING HARNESS EMS	TATA spare parts
264254610114	WIRING HARNESS ABS	TATA spare parts
264254610115	WIRING HARNESS ABS FRAME	TATA spare parts
264254610116	WIRING HARNESS ABS FRAME	TATA spare parts
264254610120	WIRING HARNESS TAIL	TATA spare parts
264254610121	WIRING HARNESS TAIL	TATA spare parts
264254610126	WIRING HARNESS TAIL	TATA spare parts
264254610127	WIRING HARNESS TAIL	TATA spare parts
264254610129	WIRING HARNESS TAIL	TATA spare parts
264254610138	WIRING HARNESS TAIL	TATA spare parts
264254610141	WIRING HARNESS ENGINE	TATA spare parts
264254610143	WIRING HARNESS MAIN	TATA spare parts
264254610149	WIRING HARNESS MAIN	TATA spare parts
264254610151	WIRING HARNESS SIDE MARKER LAMP BS6	TATA spare parts
264254610152	WIRING HARNESS SIDE MARKER LAMP BS6	TATA spare parts
264254610153	WIRING HARNESS SIDE MARKER LAMP BS6	TATA spare parts

264254610158	BATTERY CABLE -VE	TATA spare parts
264254610159	BATTERY CABLE +VE	TATA spare parts
264254610168	WIRING HARNESS TAIL BS6	TATA spare parts
264254610174	WIRING HARNESS EMS BS6	TATA spare parts
264254610175	BATTERY CABLE +VE BS6	TATA spare parts
264254610181	FUSE BOX COVER & STICKER ASSY BS6	TATA spare parts
264254610182	WIRING HARNESS SCR PIGTAL BS6	TATA spare parts
264254610184	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
264254610185	WIRING HARNESS SWITCH BS6	TATA spare parts
264254610187	WIRING HARNESS-EMS BS6	TATA spare parts
264254610192	WIRING HARNESS REVERSE PARK ASSIST BS6	TATA spare parts
264254610193	WIRING HARNESS TAIL BS6	TATA spare parts
264254610194	WIRING HARNESS TAIL BS6	TATA spare parts
264254610199	BATTERY CABLE +VE BS6	TATA spare parts
264254611613	W/H TAIL	TATA spare parts
264254611622	W/H PARKING BRAKE	TATA spare parts
264254611644	WIRING HARNESS EMS	TATA spare parts
264254611653	WIRING HARNESS MAXI FUSE	TATA spare parts
264254611660	WIRING HARNESS MAXI FUSE	TATA spare parts
264254611675	WIRING HARNESS TAIL	TATA spare parts
264254611680	WIRING HARNESS MAIN ABS	TATA spare parts
264254611682	WIRING HARNESS TAIL	TATA spare parts
264254611684	WIRING HARNESS TAIL	TATA spare parts
264254611685	WIRING HARNESS TAIL	TATA spare parts
264254611688	WIRING HARNESS TAIL	TATA spare parts
264254611691	WIRING HARNESS TAIL	TATA spare parts
264254611692	WIRING HARNESS TAIL	TATA spare parts
264254611694	WIRING HARNESS TAIL	TATA spare parts
264254611697	WIRING HARNESS TAIL	TATA spare parts
264254620101	W_H MAIN LPT712BSIV	TATA spare parts
264254620102	W_H_TAIL_LPT712BSIV	TATA spare parts
264254620103	W_H_ENGINE_LPT712_BSIV	TATA spare parts
264254620104	W_H_SENSOR_LPT712_BSIV	TATA spare parts
264254620105	W_H-SWITCH_LPT_712_BSIV	TATA spare parts
264254620106	W/H MAIN LP712/912 497 BS-IV	TATA spare parts
264254620107	W/H ENGINE LP712/912;497;BSIV;TMML	TATA spare parts
264254620108	W/H TAIL LP712;BSIV;TMML	TATA spare parts
264254620110	W/H MAXIFUSE & B.C.S.BS-IV TMML	TATA spare parts
264254620111	W/H SWITCH BS-IV TMML	TATA spare parts
264254620112	W/H TAIL LP912/49 497 BS-IV TMML	TATA spare parts
264254620113	W/H TAIL LP712EX/42	TATA spare parts
264254620115	W_H SWITCH LPT410/712_CR_EX_W/O ABS	TATA spare parts
264254620118	W_H MAIN LPT410/712_CR_EX2	TATA spare parts
264254620124	WIRING HARNESS TAIL	TATA spare parts
264254620126	WH_TAIL_LPT_709_909_ST_BSIV_CR	TATA spare parts
264254620128	WH_ENGINE_LPT_709_BSIV_CR_WITH_PTO_	TATA spare parts
264254620131	W/H PIGTAIL REVERSE S/W FOR LP712 TMML B	TATA spare parts



264254620132	W/H TAIL FOR LP712 BSIV 34WB	TATA spare parts
264254620133	WIRING HARNESS SCR PIGTAL BS6	TATA spare parts
264254620134	W/H MAIN LP712/912 497 BSIV	TATA spare parts
264254620135	W/H MAIN LP410 BSIV	TATA spare parts
264254620139	WIRING HARNESS HEADLAMP LP712/912 BSIV	TATA spare parts
264254620143	WH MAIN LPT BSIVEX W/CAT-6 LAMP	TATA spare parts
264254620144	W/H MAIN LPT EX2 W/CAT-6 LAMP BS3/4	TATA spare parts
264254620151	W/H SENSOR	TATA spare parts
264254620153	WIRING HARNESS HEAD LAMP & BLINKER	TATA spare parts
264254620154	WIRING HARNESS TAIL	TATA spare parts
264254620155	WIRING HARNESS ENGINE	TATA spare parts
264254620156	WIRING HARNESS MAIN	TATA spare parts
264254620157	WIRING HARNESS MAXI FUSE AND BATT.CUT OF	TATA spare parts
264254620158	WIRING HARNESS SWITCH	TATA spare parts
264254620160	W/H MAIN LPT 709 BSIV EX2 EOBD	TATA spare parts
264254620161	WIRING HARNESS EMS LPT BSIV	TATA spare parts
264254620162	W/H TAIL LPT709/34WB BSIV EX2 EOBD	TATA spare parts
264254620163	W/H TAIL LPT 709/38WB EX2 BSIV	TATA spare parts
264254620164	W/H TAIL LPT 709/38WB EX2 W/PTO	TATA spare parts
264254620165	W/H ENGINE LPT 709 BSIV EOBD	TATA spare parts
264254620166	WIRING HARNESS MAIN LP410/712/912 BSIV	TATA spare parts
264254620168	W/H TAIL	TATA spare parts
264254620169	W/H TAIL LP712/38WB BSIV	TATA spare parts
264254620172	TAIL_W/H_LPT709/909_BSIV_34WB_EX2 W/O PT	TATA spare parts
264254620175	TAIL_W/H_LPT709/909_BSIV_34WB_EX_W/O PT	TATA spare parts
264254620193	WIRING HARNESS MAIN BS6	TATA spare parts
264254620194	WIRING HARNESS SWITCH BS6	TATA spare parts
264254620195	BATTERY CABLE -VE BS6	TATA spare parts
264254620196	WIRING HARNESS AEBS FRAME (45WB) (264254	TATA spare parts
264254620197	WIRING HARNESS ABS BS6	TATA spare parts
264254620198	WIRING HARNESS MAIN BS6	TATA spare parts
264254621610	WIRING HARNESS TAIL	TATA spare parts
264254621611	WIRING HARNESS MAIN	TATA spare parts
264254621612	WIRING HARNESS TAIL	TATA spare parts
264254621613	WIRING HARNESS TAIL	TATA spare parts
264254630102	BATTERY CABLE +VE BCS TO MEGA FUSE BS6	TATA spare parts
264254630103	BATTERY CABLE +VE BS6	TATA spare parts
264254630108	WIRING HARNESS-TAIL BS6	TATA spare parts
264254630109	WIRING HARNESS TAIL BS6	TATA spare parts
264254630110	WIRING HARNESS TAIL BS6	TATA spare parts
264254630111	WIRING HARNESS MAIN BS6	TATA spare parts
264254630112	W/H REVERSE PARK ASSIST BS6-PH2	TATA spare parts
264254630113	WIRING HARNESS ABS BS6	TATA spare parts
264254630117	BATTERY CABLE -VE BS6	TATA spare parts
264254630118	STICKER MAXI FUSE BOX BS6	TATA spare parts
264254630132	WIRING HARNESS MAIN BS6	TATA spare parts
264254630133	WIRING HARNESS TAIL BS6	TATA spare parts

264254630148	WIRING HARNESS-EMS BS6	TATA spare parts
264254630166	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
264254630168	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
264254630172	WIRING HARNESS SENSOR BS6-PH2	TATA spare parts
264254630175	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
264254640103	WIRING HARNESS ESC BS6-PH2	TATA spare parts
264254640106	WIRING HARNESS TCU SYSTEM CONN BS6-PH2	TATA spare parts
264254640107	WIRING HARNESS ESC BS6-PH2	TATA spare parts
264254640115	WIRING HARNESS EMERGENCY SWITCH BS6-PH2	TATA spare parts
264254640122	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
264254640125	WIRING HARNESS ABS BS6-PH2	TATA spare parts
264254640127	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
264254660150	WIRING HARNESS ENGINE	TATA spare parts
264254690104	WIRING HARNESS SWITCH	TATA spare parts
264258902601	PULLER GEAR BOX REAR HALF HSG BS6	TATA spare parts
264258902603	KIT-INNER GUT REMOVING & DROPPING BS6	TATA spare parts
264258902604	FITTING TOOL BS6	TATA spare parts
264258902606	REAR HOUSING FITMENT TOOL (FITTING TOOL	TATA spare parts
26426000002R40	ASSEMBLY BODY FITTED	TATA spare parts
26426000004R40	ASSEMBLY BODY FITTED	TATA spare parts
26426000009R40	ASSEMBLY BODY FITTED	TATA spare parts
26426000011R40	ASSEMBLY BODY FITTED	TATA spare parts
26426000081R40	PARTIAL FITTED CAB WITHOUT FITMENT LPT 7	TATA spare parts
26426000085R40	PARTIALLY FITTED CAB W/O ELECTRICALS BS6	TATA spare parts
26426000186R40	712 LPT DCR38HSD 125B6M5_CAB/COWL BS6	TATA spare parts
26426000217R40	PARTIAL FITTED CAB 912 LPT BS6	TATA spare parts
26426000220R40	712 LPT DCR38HSD 125B6M5_CAB/COWL BS6	TATA spare parts
26426000235R40	PARTIAL FITTED CAB W/O FITMENT LPT 912 B	TATA spare parts
26426000239R40	709G LPT DCR38CBC 85B6M5 TT_CAB/COWL BS6	TATA spare parts
264282409904	WIPER MOTOR BS6	TATA spare parts
264282409905	WIPER MOTOR BS6	TATA spare parts
264282409906	WIPER MOTOR BS6	TATA spare parts
264282508208	MAXIFUSE_MTG_BRACKET BS6	TATA spare parts
264282909901	NOZZLE BS6	TATA spare parts
264283106301	DUCT ADAPTER	TATA spare parts
264283400102	BRACKET ASSY HVAC MTG UPPER-LH	TATA spare parts
264283400103	BRACKET ASSY HVAC MTG BOTTOM-RH	TATA spare parts
264283400106	BRACKET ASSY HVAC MTG BOTTOM-LH	TATA spare parts
264283400107	BRACKET ASSY HVAC MTG UPPER-RH	TATA spare parts
264283400108	BRACKET ASSY HVAC MTG BOTTOM-LH	TATA spare parts
264283400112	ASSY. BLOWER UNIT BS4	TATA spare parts
264283400132	FORCED VENTILATION UNIT ASSY BS6	TATA spare parts
264283409906	WIRING HARNESS ASSY	TATA spare parts
264283409908	FRESH AIR DUCT	TATA spare parts
264283409911	BLOWER ASSY	TATA spare parts
264283409916	RESISTOR ASSY	TATA spare parts
264283409917	BLOWER HSG ASSY	TATA spare parts

264283409920	WIRING HARNESS ASSY	TATA spare parts
264283409931	BLOWER MOTOR ASSY	TATA spare parts
264283409934	WIRE HARNESS ASSY MAIN UNIT SIDE BS6	TATA spare parts
264283600126	AC PIPE ASSY	TATA spare parts
264292001603	SINGLE SEAT BS6	TATA spare parts
2642D1A1860001	FES STRUCTURE BS6-PH2	TATA spare parts
2642D1A1860006	FES STRUCTURE BS6-PH2	TATA spare parts
2642D9Z0160002	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2642D9Z0160003	FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
264315140101	GRS MOTOR 24V WITH TCO M/S BOSCH	TATA spare parts
264315200106	SOLENOID FIP SHUT OFF	TATA spare parts
264315200111	ASSY. SOLENOID 12V BS1	TATA spare parts
264315200113	ASSY.SOLENOID FUEL SHUT OFF-12V	TATA spare parts
264315240102	ASSY.SOLENOID FUEL SHUT OFF-24V	TATA spare parts
264315400101	ALTERNATOR 12V/65A	TATA spare parts
264315608201	BRACKET MAIN SENSOR WH	TATA spare parts
264315608202	L BRACKET FOR ENGINE	TATA spare parts
264316100102	CONTAINER (ECU 697 TCIC EURO-III)	TATA spare parts
264316100103	CONTAINER ECU 697 TCIC EURO-IV	TATA spare parts
264316100104	CONTAINER (ECU 697 TCIC EURO-III)	TATA spare parts
264324108801	STUD	TATA spare parts
264326400108	ASSY LEVER	TATA spare parts
264326400109	ASSY. BRACKET(PN.SHIFTING CYLINDER MTG)	TATA spare parts
264326406701	PIN	TATA spare parts
264326800119	ASSY BKT.G.S.L.MTG	TATA spare parts
264326800130	ASSY.TURNING TUBE	TATA spare parts
264326800133	ASSY TURNING TUBE LHD	TATA spare parts
264326800134	ASSY LINK ROD	TATA spare parts
264326800138	ASSY TURNING TUBE	TATA spare parts
264326800146	SUB ASSY GEAR SHIFT LEVER WITH SEL FORK	TATA spare parts
264326800147	GEAR SHIFT LEVER ASSY WITH SHIFT YOKE	TATA spare parts
264326800150	ASSY TURNING TUBE (W/O BALL JOINT)	TATA spare parts
264326800152	ASSY G.S.LEVER WITH TURNING TUBE	TATA spare parts
264326800160	TURNING TUBE ASSY WITH BALL JOINT	TATA spare parts
264326800162	TURNING TUBE ASSY	TATA spare parts
264326800165	GSL ASSY WITH SELECTOR - SHIFTER YOKE	TATA spare parts
264326808206	BRACKET	TATA spare parts
264326810101	ASSY.BRACKET (FOR CAB VERSION)	TATA spare parts
264326810102	ASSY.BRACKET	TATA spare parts
264326810103	BKT FOR P/S VEHICLE	TATA spare parts
264326810105	ASSY BRACKET (CAB VERSION)	TATA spare parts
264326810106	ASSY BRACKET (FOR COWL VERSION)	TATA spare parts
264326810107	SUB ASSY GUSSET (FOR G.S.LEVER BRACKET)	TATA spare parts
264326810108	GUSSET ASSY GSL BRACKET	TATA spare parts
264326810110	ASSY BRACKET (G S L MTG)	TATA spare parts
264326810111	ASSY BRACKET (G S L MTG)	TATA spare parts
264326810114	BRACKET GEAR SHIFT LEVER MTG	TATA spare parts

264329100101	SUPPORT CLUTCH PEDAL	TATA spare parts
264329100104	ASSY FORK WITH ROD-MASTER CYL	TATA spare parts
264329100105	ASSY CL PEDAL LHD 609/613	TATA spare parts
264329100124	ASSY. TUBE	TATA spare parts
264329100125	ASSY TUBE	TATA spare parts
264329100126	ASSY TUBE	TATA spare parts
264329100127	ASSY TUBE	TATA spare parts
264329100129	ASSY TUBE (FIRE WALL TO RADIATOR BRIDGE)	TATA spare parts
264329100130	ASSY TUBE (BRIDGE TO SLAVE CYL)	TATA spare parts
264329100133	ASSY CLUTCH PEDAL COMPLETE(TCIC-EURO-II)	TATA spare parts
264329100135	ASSY BRAKE PEDAL COMPL.(LHD TCIC EUROII)	TATA spare parts
264329200104	ASSY. SUPPORT COMPLETE (CLUTCH)	TATA spare parts
264329200106	ASSY. PEDAL LEVER COMPLETE	TATA spare parts
264329200107	ASSY TUBE (CLUTCH 6 O.D.X0.7 THK)	TATA spare parts
264329200108	ASSY TUBE (CLUTCH 6 O.D.X0.7 THK)	TATA spare parts
264329208202	BRACKET (CLUTCH PIPE MTG.) BS6	TATA spare parts
264329300102	ASSY PUSH ROD	TATA spare parts
264329300103	ASSY BRACKET	TATA spare parts
264330100107	CABLE ACCELERATOR RHD	TATA spare parts
264330100108	ASSY. ACC. CABLE LHD 609	TATA spare parts
264330100117	ASSY.PULL CABLE	TATA spare parts
264330100119	ASSY.ACCELERATOR PEDAL-LHD	TATA spare parts
264330100120	ASSY. PULL CABLE ACCELERATOR	TATA spare parts
264330100121	ASSY PULL CABLE ACCELERATER	TATA spare parts
264330100122	ASSY.PULL CABLE ACCELERATOR	TATA spare parts
264330100126	ASSY. BRACKET ACCL. MODULE MTG.	TATA spare parts
264330100127	ASSY.PEDAL LEVER WITH ACCL. PEDAL	TATA spare parts
264330100131	ASSY.PULL CABLE ACCELERATOR (M/S ACEY)	TATA spare parts
264330107701	COVER (FOR ACCELERATOR PEDAL)	TATA spare parts
264330108204	BRACKET	TATA spare parts
264331000101	ASSY FRAME COMP.(LPT 613/34)	TATA spare parts
264331000102	ASSY.FRAME COMP.(LPT 613/38)	TATA spare parts
264331000104	ASSY FRAME COMP.(LP613/38)	TATA spare parts
264331000106	ASSY FRAME LPT 613/38	TATA spare parts
264331000109	ASSY.FRAME (VERTICAL EXHAUST W/O CLEATS)	TATA spare parts
264331000114	ASSY.FRAME COMPLETE(LP 613/38)	TATA spare parts
264331200101	ASSY.ENGINE C.MEMBER FRT.	TATA spare parts
264331200104	ASSY. END CROSS MEMBER	TATA spare parts
264331200111	ASSY. TUBE (ENG. BLOCK HEATER MTG.)	TATA spare parts
264331207102	SUPPORT R.H.(ENGINE C.MEMBER FRT.)	TATA spare parts
264331207103	SUPPORT L.H(ENGINE C.MEMBER FRT)	TATA spare parts
264331207104	ENGINECROSSMEMBER	TATA spare parts
264331207109	JOINT GUSSET PLATE-RH	TATA spare parts
264331207110	JOINT GUSSET PLATE-LH	TATA spare parts
264331207111	JOINT GUSSET PLATE-RH	TATA spare parts
264331207112	JOINT GUSSET PLATE-LH	TATA spare parts
264331207113	JOINT GUSSET PLATE-RH	TATA spare parts

264331207114	JOINT GUSSET PLATE-LH	TATA spare parts
264331207115	JOINT GUSSET PLATE-RH	TATA spare parts
264331207116	JOINT GUSSET PLATE-LH	TATA spare parts
264331208203	REINFORCEMENT-RH(FRONT SPG.FRONT BKT)	TATA spare parts
264331208204	REINFORCEMENT-LH(FRONT SPG.FRONT BKT)	TATA spare parts
264331403201	EYE BOLT	TATA spare parts
264332100107	ASSY. FRONT SPRING-HIGHER CAMBER	TATA spare parts
264332100108	ASSY FIRST LEAF WITH BUSHES((HIGHER CAMB	TATA spare parts
264332100109	ASSY. FRONT SPRING-NORMAL CAMBER	TATA spare parts
264332100110	ASSY. FIRST LEAF WITH BUSHES (NORMAL CAM	TATA spare parts
264332107109	SECOND LEAF (HIGHER CAMBER)	TATA spare parts
264332107110	THIRD LEAF(HIGHER CAMBER)	TATA spare parts
264332107111	FOURTH LEAF(HIGHER CAMBER)	TATA spare parts
264332107112	FIFTH LEAF(HIGHER CAMBER)	TATA spare parts
264332107113	SIXTH LEAF(HIGHER CAMBER)	TATA spare parts
264332107114	SEVENTH LEAF(HIGHER CAMBER)	TATA spare parts
264332107115	EIGHTH LEAF(HIGHER CAMBER)	TATA spare parts
264332107116	NINETH LEAF(HIGHER CAMBER)	TATA spare parts
264332107117	TENTH LEAF(HIGHER CAMBER)	TATA spare parts
264332107118	ELEVANTH LEAF(HIGHER CAMBER)	TATA spare parts
264332107119	TWELVETH LEAF(HIGHER CAMBER)	TATA spare parts
264332107120	THIRTEENTH LEAF(HIGHER CAMBER)	TATA spare parts
264332107121	FOURTEENTH LEAF(HIGHER CAMBER)	TATA spare parts
264332107123	SECOND LEAF (NORMAL CAMBER)	TATA spare parts
264332107124	THIRD LEAF (NORMAL CAMBER)	TATA spare parts
264332107125	FOURTH LEAF (NORMAL CAMBER)	TATA spare parts
264332107126	FIFTH LEAF (NORMAL CAMBER)	TATA spare parts
264332107127	SIXTH LEAF (NORMAL CAMBER)	TATA spare parts
264332107128	SEVENTH LEAF (NORMAL CAMBER)	TATA spare parts
264332107129	EIGHTH LEAF (NORMAL CAMBER)	TATA spare parts
264332107130	NINETH LEAF (NORMAL CAMBER)	TATA spare parts
264332107131	TENTH LEAF (NORMAL CAMBER)	TATA spare parts
264332107132	ELEVANTH LEAF (NORMAL CAMBER)	TATA spare parts
264332107133	TWELVETH LEAF (NORMAL CAMBER)	TATA spare parts
264332107134	THIRTEENTH LEAF (NORMAL CAMBER)	TATA spare parts
264332107135	FOURTEENTH LEAF (NORMAL CAMBER)	TATA spare parts
264332204201	U BOLT - FRONT SPRING	TATA spare parts
264332300101	ASSY. FRONT SHOCK ABSORBER BS1/2/3/4	TATA spare parts
264332800101	ASSY FRT ANTI ROLL BAR MTG BRACKET R.H	TATA spare parts
264332800102	ASSY FRT ANTI ROLL BAR MTG BKT L.H.	TATA spare parts
264333000102	ASSY.FRONT AXLE WITH BRAKES (ABS)	TATA spare parts
264333000106	FA 613 LHD	TATA spare parts
264333000107	ASSY FRONT AXLE WITH BRK(ABS)	TATA spare parts
264333200101	ASSY TIE ROD ASSY COLD COUNTRY APLN	TATA spare parts
264333200102	ASSY STUB AXLE WITH BUSH -RH (NORMAL)	TATA spare parts
264333200103	ASSY.STUB AXLE WITH BUSH-LH (NORMAL)	TATA spare parts
264333200106	ASSY STUB AXLE RH NORMAL	TATA spare parts

264333200107	ASSY STUB AXLE LH NORMAL	TATA spare parts
264333400102	ASSY.HUB & BOLT	TATA spare parts
264333400104	FRONT HUB ASSY ABS BS6	TATA spare parts
264333403702	FRONT HUB(SLOTTED)	TATA spare parts
264333805104	STEERING ARM (LH)	TATA spare parts
264340100101	ASSY.HUB COVER	TATA spare parts
264340100104	VALVE ASSY	TATA spare parts
264340308201	REINFORCEMENT	TATA spare parts
264341000103	ASSY.UNITISED PROP.SHAFT COMPLETE	TATA spare parts
264341000108	1SSY. UNITIZED PROP. SHAFT	TATA spare parts
264341110101	ASSY.PROPELLER SHAFT WITH CENTRE BEARING	TATA spare parts
264342100105	ASSY F/A BRAKE RH WT DC AF235(ABS)-	TATA spare parts
264342100106	ASSY F/A BRAKE LH WT DC AF235(ABS)-	TATA spare parts
264342100110	ASSY. BRAKE SHOE (STD)	TATA spare parts
264342100122	ASSY. FRONT BRAKE LH	TATA spare parts
264342100124	ASSY. FRONT BRAKE RH	TATA spare parts
264342100171	KIT-BRK LINING STD BS2	TATA spare parts
264342100172	KIT - LINING SET (R/S I)	TATA spare parts
264342100173	KIT - LINING SET (R/S II)	TATA spare parts
264342103401	SENSOR SLEEVE-FRONT	TATA spare parts
264342103702	TORQUE PLATE LH	TATA spare parts
264342103703	TORQUE PLATE RH	TATA spare parts
264342108201	ANCHOR BRACKET FRONT	TATA spare parts
264342108301	SHIM (AUTO SLACK ADJUSTER)	TATA spare parts
264342108601	SPACER	TATA spare parts
264342109902	POLE WHEEL-FRONT	TATA spare parts
264342109903	POLE WHEEL FRONT	TATA spare parts
264342300105	ASSY R/A BRAKE RH WT DC AF235 & ABS-	TATA spare parts
264342300106	ASSY R/A BRAKE LH WT DC AF235 & ABS-	TATA spare parts
264342303301	SENSOR AXLE BRACKET(REAR)-ABS	TATA spare parts
264342303302	SENSOR MTG BRACKET(REAR)-ABS(M/CD VERSN)	TATA spare parts
264342303702	TORQUE PLATE REAR LH	TATA spare parts
264342303703	TORQUE PLATE REAR RH	TATA spare parts
264342308201	ANCHOR BRACKET RH	TATA spare parts
264342308202	ANCHOR BRACKET LH	TATA spare parts
264342309901	POLE WHEEL REAR	TATA spare parts
264342309904	POLE WHEEL REAR	TATA spare parts
264342400101	ASSY.BRACKET-L.C.R.V.MTG.ON REAR AXLE	TATA spare parts
264342400102	ASSY.PULL ROD-FOR L.C.R.V.	TATA spare parts
264342403301	BRACKET	TATA spare parts
264342800117	ASSY.TUBE	TATA spare parts
264342800168	ASSY TUBE	TATA spare parts
264342800172	ASSY.TUBE	TATA spare parts
264342900113	ASSY TUBE	TATA spare parts
264342900114	ASSY TUBE	TATA spare parts
264342900115	ASSY TUBE	TATA spare parts
264342900116	ASSY TUBE	TATA spare parts

264342900117	ASSY. NYLON TUBE (PART. SOCKT TO LCRV)	TATA spare parts
264342900125	ASSY TUBED	TATA spare parts
264342900126	ASSY.BRACKET	TATA spare parts
264342900127	ASSY.TUBE	TATA spare parts
264342900128	ASSY.TUBE	TATA spare parts
264342900129	ASSY.TUBE	TATA spare parts
264342900141	ASSY. TUBE (AIR PRESSURE GAUGE PORT 12)	TATA spare parts
264342900142	ASSY. TUBE (AIR PRESSURE GAUGE PORT 11)	TATA spare parts
264342900143	ASSY. TUBE (HAND BRAKE VALVE TO ELBOW)	TATA spare parts
264342900144	ASSY. TUBE	TATA spare parts
264342900155	ASSY.NYLON PIPES-CAB PIPES	TATA spare parts
264342900157	ASSY. BRACKET ( FRONT HOSE MOUNTING)	TATA spare parts
264342900163	ASSY BRACKET (TEE MOUNTING ON REAR AXLE)	TATA spare parts
264342906801	T SOCKET	TATA spare parts
264342906802	COUPLING BODY	TATA spare parts
264342906803	COUPLING BODY	TATA spare parts
264342906804	T SOCKET	TATA spare parts
264342906805	T SOCKET	TATA spare parts
264342906806	T SOCKET	TATA spare parts
264342990102	DRUM BRAKE LINED SHOE ASSY	TATA spare parts
264342990104	DRUM BRAKE LINED SHOE ASSY	TATA spare parts
264343200109	ASSY.AIRTANK 15 LIT. WITH PLUG	TATA spare parts
264343200114	ASSY AIR TANK 15 LIT. COMPLETE WITH 110	TATA spare parts
264343700103	AUTOMATIC LOAD SENSING VALVE	TATA spare parts
264343700104	AUTOMATIC LOAD SENSING VALVE LPT	TATA spare parts
264343700111	ASSLY. BRACKET HAND BRAKE VALVE MTG.	TATA spare parts
264343700116	GRADUATED HAND CONTROL VALVE	TATA spare parts
264343700117	GRADUATED HAND CONTROL VALVE	TATA spare parts
264343700124	DRYING & DIST HI PR VOSS W/O CNTL BS1- 4	TATA spare parts
264343700126	DDU LOW PR VOSS PORT WO CNTL PORT-120MM	TATA spare parts
264343700131	AIR DRYER-HI PR WT 24VHEATER_SILE VOSS	TATA spare parts
264343700134	FOOT BRAKE VALVE	TATA spare parts
264343709901	PRESSURE TEST CONNECTOR	TATA spare parts
264343900105	ASSY.PIPE(SECOND METAL PIPE FROM COMPR.)	TATA spare parts
264343900106	ASSY.PIPE(THIRD METAL PIPE FROM COMPR.)	TATA spare parts
264343900114	ASSY.NYLON PIPE SET COMPL-LPT613/LHD/34	TATA spare parts
264343900116	ASSY.METAL PIPE W/CRIMPED HOSE-LPT613	TATA spare parts
264343900118	ASSY.NYLON PIPE SET COMPL-LP613/38LHD	TATA spare parts
264343900131	ASSY METAL TUBE	TATA spare parts
264343900134	ASSY.NY.PIPE SET CAB COMPL (LPT613 VOSS)	TATA spare parts
264343900162	ASSY NYLON PIPE SET CHASS COMP LPT 613	TATA spare parts
264343900175	TUBE	TATA spare parts
264343900177	ASSY NYLON PIPE SET CHASS COMP LPT613	TATA spare parts
264343900194	ASSY METAL PIPE DIA 15 (AC TO DDU)	TATA spare parts
264343900195	ASSY NYLON PIPE SET FOR ABS PROVISION	TATA spare parts
264343900202	ASSY NYLON PIPE SET CHASSIS COMPL	TATA spare parts
264343903301	C BRACKET (T CONNECTOR MTG.)	TATA spare parts

264343903302	BRACKET MODULATOR VALVE MTG.RH(REAR)	TATA spare parts
264343903303	BRACKET MODULATOR VALVE MTG.LH(REAR)	TATA spare parts
264343907501	GROMMET (PARKING BRAKE)	TATA spare parts
264343908201	BRACKET (HOSE MTG REAR)	TATA spare parts
264343910101	ASSY METAL PIPE COMPRESSOR TO AIR DRIER	TATA spare parts
264343910103	ASSY METAL PIPE 2ND COMP TO AIR DRIER	TATA spare parts
264343910105	ASSY NYLON PIPE SET CHASSIS COMPL LPT613	TATA spare parts
264343910107	PIPE BUNCH ASSY	TATA spare parts
264343910127	ASSY NYLON PIPE SET CHASSIS COMPLETE	TATA spare parts
264343910140	ASSY METAL PIPE (FROM COMP TO DDU)	TATA spare parts
264343910148	ASSY NYLON PIPE SET CHASSIS COMPL LP613	TATA spare parts
264343910154	ASSY METAL PIPE (FROM COPMPRESSOR TO DDU)	TATA spare parts
264343910161	NYLON PIPE SET CHASS COMP LPT 613 ABS	TATA spare parts
264343910167	NYLON PIPE BUNCH ASSY FOR LPT613 ABS	TATA spare parts
264343910169	NYLON PIPE BUNCH ASSY COMP ABS	TATA spare parts
264343990101	REPAIR KIT-SPRING BRAKE ACTUATOR 12/12	TATA spare parts
264343990102	REPAIR KIT FOR DDU	TATA spare parts
264346200104	ASSY.STRG. SPINDLE	TATA spare parts
264346600101	ASSY.DRAG LINK-LHD(COLD COUNTRY APPLN.)	TATA spare parts
264346600102	ASSY. BALL JOINT RH BS1/3	TATA spare parts
264346700101	BRACKET ASSY STG GEAR BOX MTG	TATA spare parts
264346800113	ASSY. TUBE (HYD. TANK HOSE TO HOSE)	TATA spare parts
264346800116	ASSY TUBE (TANK TO PUMP)	TATA spare parts
264346800120	ASSY TUBE (TANK TO PUMP)	TATA spare parts
264346800125	ASST TUBE (RESERVOIR TO PSTRG GB)	TATA spare parts
264346800127	ASSY HYD FLUID LINE (RESERVOIR TO PUMP)	TATA spare parts
264346800128	ASSY HYD FLUID LINE(RESERVOIR TO GB)	TATA spare parts
264346800129	ASSY HYD FLUID LINE (PUMP TO GEAR BOX)	TATA spare parts
264346800130	ASSY HYD FLUID LINE (PUMP TO GEAR BOX)	TATA spare parts
264346800132	ASSY. CRIMPED HOSE STRG.PUMP TO GEAR BOX	TATA spare parts
264346800133	ASSY. CRIMPED HOSE GEARBOX TO RESERVOIR	TATA spare parts
264346800134	ASSY.SUCTION LINE(CRIMPED-TANK TO PUMP)	TATA spare parts
264346800135	ASSY PIPE (PUMP TO GEAR BOX)	TATA spare parts
264346800142	ASSY.SUCTION.LINE(CRIMPED)RES.TOPUMP	TATA spare parts
264346800143	ASSY.PRESSURE LINE(PUMP TO G.BOX)	TATA spare parts
264346800144	ASSY RETURN LINE(STRG G. BOX TO RES.)	TATA spare parts
264346800167	RETURN LINE ASSY	TATA spare parts
264346800168	PRESSURE LINE ASSY	TATA spare parts
264346800169	SUCTION LINE ASSY	TATA spare parts
264346803301	BRACKET FOR STRG PIPE CLAMPING BS6	TATA spare parts
264346805801	3/4 INCH LP HOSE (250MM LONG APPROX)	TATA spare parts
264346808201	BRACKET (FOR STRG.PIPE CLAMPING)	TATA spare parts
264347000112	ASSY.FUEL TANK COMPLETE WITH MTG BKT.	TATA spare parts
264347100102	ASSY BKT.FUEL TANK MTG.	TATA spare parts
264347500114	SUPPORT BRACKET ASSY FOR CNG COMPONENT	TATA spare parts
264347600109	ASSY. RETURN LINE	TATA spare parts
264347600110	FUEL SUCTION PIPE ASSY	TATA spare parts



264347600113	ASSY FUEL SUCTION PIPE	TATA spare parts
264347600117	ASSY FUEL LINE. (STRAINER TO W.SEPRATOR)	TATA spare parts
264347600118	ASSY SUCTION LINE	TATA spare parts
264347600119	FUEL SUCTION PIPE ASSY	TATA spare parts
264347600120	RETURN FUEL PIPE ASSY	TATA spare parts
264347600124	ASSY. SUCTION LINE (W/SEPARATOR TO HOSE)	TATA spare parts
264347600125	ASSY. SUCTION LINE (WATER SEPARATOR TO H	TATA spare parts
264347600126	ASSY. RETURN LINE ( TANK TO SOCKET)	TATA spare parts
264347600142	ASSY.SUCTION LINE (TANK TO W/SEP) E-II	TATA spare parts
264347600143	ASSY.RETURN LINE (TANK TO SOCKET) E-II	TATA spare parts
264347600144	ASSY.SUCTION LINE (W/SEP TO SOCKET) E-II	TATA spare parts
264347600146	ASSY.RETURN LINE (SOCKET TO HOSE) E-II	TATA spare parts
264347600147	ASSY.SUCTION LINE (PUMP HOSE TO INTAKE)	TATA spare parts
264347600148	ASSY.FUEL SUCTION LINE (TANK TO W/SEP.)	TATA spare parts
264347600149	ASSY.FUEL SUCTION LINE (W/SEP.TO SOCKET)	TATA spare parts
264347600157	ASSY. BRACKET (FEED PUMP MTG.)	TATA spare parts
264347600158	ASSY.NYLON FUEL LINE (TANK TO STRAINER)	TATA spare parts
264347600159	ASSY NYLON FUEL LINE (STRAINER TO MICO W	TATA spare parts
264347600160	PIPE FUEL	TATA spare parts
264347600161	PIPE FUEL	TATA spare parts
264347600162	PIPE FUEL	TATA spare parts
264347600163	ASSY. SUCTION LINE(FEED PUMP TO HEATER)	TATA spare parts
264347600170	BRACKET (WATER SEPARATOR WITH HAND PRIME	TATA spare parts
264347600177	ASSY SUCTION LINE (MICO W/SEP TO MECH.F)	TATA spare parts
264347600180	ASSY.SUCTION LINE(FUEL TANK TO STRAINER)	TATA spare parts
264347600182	ASSY. RETURN LINE	TATA spare parts
264347600184	ASSY.SUCTION LINE(STRAINER TO W/SEP)	TATA spare parts
264347600188	ASSY SUCTION LINE (MICO W/SEP TO MECH F)	TATA spare parts
264347600190	ASSY SUCTION LINE (F.TANK-STRAINER)	TATA spare parts
264347600191	ASSY SUCTION LINE(STRAINER-W/SEP.)	TATA spare parts
264347600192	ASSY SUCTION LINE(W/SEP-MECH.FEED PUMP)	TATA spare parts
264347600193	ASSY RETURN LINE.	TATA spare parts
264347600198	ASSY RETURN LINE	TATA spare parts
264347603302	BRACKET	TATA spare parts
264347605802	FUEL HOSE	TATA spare parts
264347606801	DOUBLE PIPE UNION BOLT	TATA spare parts
264347608201	BRACKET	TATA spare parts
264347608202	BRACKET (ELECT.FUEL PUMP MTG.)	TATA spare parts
264347610107	SINGLE CLAMP ASSY WITH BRACKET BS6	TATA spare parts
264347610113	SUCTIONLINE FUEL TANK TO PREFILTER	TATA spare parts
264347610116	RETURNLINE ENGINE TO FUEL TANK	TATA spare parts
264347618201	L-CLAMP PIPE BS6	TATA spare parts
264347700101	HP REGULATOR INTEGRATED	TATA spare parts
264347700102	SOLENOID VALVE ASSY	TATA spare parts
264347706101	LOCK PLATE	TATA spare parts
264347706801	CONNECTOR	TATA spare parts
264347800109	HP PIPE ASSY	TATA spare parts

264349007501	RUBBER BUFFER	TATA spare parts
264349100102	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
264349100110	ASSY.SILENCER COMP (WITH TAIL PIPE)	TATA spare parts
264349100111	ASSY. SILENCER COMPLETE(WITH TAIL PIPE)	TATA spare parts
264349100112	ASSY SILENCER	TATA spare parts
264349100184	ASSY. EXHAUST PIPE(SILENCER-DPS)	TATA spare parts
264349100185	ASSY PIPE EXHAUST (DPS)	TATA spare parts
264349105801	RUBBER HOSE SILENCER TO DPS	TATA spare parts
264349105802	SILICON HOSE DPS-EXHAUST PIPE	TATA spare parts
264349109901	FRONT EXHAUST PIPE HEAT SHIELD	TATA spare parts
264349109902	HEAT SHIELD COMPLETE	TATA spare parts
264349109903	HEAT SHIELD OUTER	TATA spare parts
264349109904	HEAT SHIELD OUTER	TATA spare parts
264349109905	HEAT SHIELD OUTER	TATA spare parts
264349109906	HEAT SHIELD OUTER	TATA spare parts
264349109907	HEAT SHIELD OUTER	TATA spare parts
264349200102	ASSY. BRACKET	TATA spare parts
264349200105	ASSY EXHAUST PIPE	TATA spare parts
264349200107	ASSY.BRACKET	TATA spare parts
264349200112	ASSY.EXHAUST PIPE-FRONT (REAR EXHAUST)	TATA spare parts
264349200113	ASSY.EXHAUST PIPE INTER-REAR EXHAUST	TATA spare parts
264349200114	ASSY.EXHAUST PIPE AFTER SILENCER-REAR EX	TATA spare parts
264349200115	ASSY.EXHAUST TAIL PIPE-REAR EXHAUST	TATA spare parts
264349200116	ASSY. BRACKET (EXHAUST MTG)	TATA spare parts
264349200117	ASSY.INTERMEDIATE PIPE - AFTER TURBO.	TATA spare parts
264349200122	ASSY.HEAT SHIELD	TATA spare parts
264349200123	ASSY.TAIL PIPE LHD - FLANGE TYPE	TATA spare parts
264349200124	ASSY.INTERMEDIATE PIPE - RHD FLANGE TYPE	TATA spare parts
264349200125	ASSY.TAIL PIPE RHD - FLANGE TYPE	TATA spare parts
264349200126	ASSY.FRONT EXHAUST PIPE (613/713)	TATA spare parts
264349200127	ASSY.INTERMEDIATE PIPE (613/713)	TATA spare parts
264349200131	ASSY.NOISE SHIELD (RH SIDE)	TATA spare parts
264349200132	1SSY.NOISE SHIELD (LH SIDE)	TATA spare parts
264349200135	ASSY.BOTTOM NOISE SHIELD REAR	TATA spare parts
264349200137	ASSY.BRACKET	TATA spare parts
264349200138	ASSY.BRACKET	TATA spare parts
264349200139	ASSY.BRACKET	TATA spare parts
264349200140	ASSY.BRACKET	TATA spare parts
264349200141	ASSY.BRACKET	TATA spare parts
264349200142	ASSY.FRONT EXHAUST PIPE	TATA spare parts
264349200143	EXHAUST PIPE INTERMEDIATE	TATA spare parts
264349200144	ASSY. BOTTOM NOISE SHIELD FR	TATA spare parts
264349200145	ASSY BOTTOM NOISE SHIELD FLAP LH	TATA spare parts
264349200146	ASSY. BOTTOM NOISE SHIELD FLAP RH.	TATA spare parts
264349200148	ASSY. BRACKET	TATA spare parts
264349200168	ASSY. BOTTOM NOISE SHIELD (REAR)	TATA spare parts
264349200169	ASSY. BRACKET	TATA spare parts

264349200171	ASSY.BRACKET (EXHAUST MTG.)	TATA spare parts
264349200172	ASSY.EXHAUST PIPE FRONT	TATA spare parts
264349200173	ASSY. CLAMP (SILENCER MTG.)	TATA spare parts
264349200174	ASSY.BRACKET(NOISE SHIELD MTG)	TATA spare parts
264349200179	ASSY.EXHAUST PIPE (FRONT).	TATA spare parts
264349200180	ASSY.EXHAUST PIPE FRONT (NT6A)	TATA spare parts
264349200182	ASSY. BRACKET (FRONT EXHAUST SUPPORT MT	TATA spare parts
264349200184	ASSY.EXHAUST PIPE FRONT	TATA spare parts
264349200185	ASSY. EXHAUST PIPE	TATA spare parts
264349200186	ASSY EXHAUST PIPE INTERMEDIATE (WITH BOS	TATA spare parts
264349200187	ASSY EXHAUST PIPE (FRONT)	TATA spare parts
264349203304	BRACKET	TATA spare parts
264349203305	BRACKET	TATA spare parts
264349203306	BRACKET	TATA spare parts
264349203702	EXHAUST PIPE-I	TATA spare parts
264349204201	CLAMP	TATA spare parts
264349204202	CLAMP SILENCER MTG.	TATA spare parts
264349208202	BRACKET	TATA spare parts
264349208217	BRACKET (NOISE SHIELD)	TATA spare parts
264349208247	BRACKET (DPS MTG.)	TATA spare parts
264349208249	PLATE	TATA spare parts
264349210106	ASSY.MOUNTING STRAP (POC. DOC MTG)	TATA spare parts
264349218203	MOUNTING STRAP (POC DOC MTG.)	TATA spare parts
264354100101	ASSY BATTERY CABLE [1.15LG] + VE.35 SQMM	TATA spare parts
264354100103	ASSY.BATT.CABLE +VE [1.26 MM. LONG)	TATA spare parts
264354100105	ASSY BATT.CABLE +VE (1.4 LG.)	TATA spare parts
264354100106	ASSY.BATT.CABLE -VE (1.31 LG.)	TATA spare parts
264354100117	ASSY SUPPORT	TATA spare parts
264354100118	ASSY BATT.CABLE -VE (50 SQ.MM.-3.250 LG)	TATA spare parts
264354100128	ASSY.BATT.CABLE +VE 400MM 70SQ.MM	TATA spare parts
264354100129	ASSY.BATT.CABLE -VE 650MM W/COT 70SQ.MM	TATA spare parts
264354100130	ASSY.BATT.CABLE -VE 2.35LG W/COT 50SQ.MM	TATA spare parts
264354100131	ASSY.BATT.CABLE W/COT +VE 70SQ.MM 1.5M	TATA spare parts
264354100132	ASSY.BATT.CABLE -VE W/COT 70SQ.MM 1.8M	TATA spare parts
264354100133	ASSY.BATT.CABLE -VE W/COT 70SQ.MM 1.3M	TATA spare parts
264354100134	ASSY BATT CABLE -VE 1.3M W/COT 70SQMM	TATA spare parts
264354100137	ASSY BATT.CABLE +VE W/COT 455MM 70SQ.M	TATA spare parts
264354100138	ASSY BATT.CABLE -VE W/COT 2275MM 70SQ.MM	TATA spare parts
264354100141	ASSY.BATT.CABLE 1650MM 50SQ.MM BOTH SIDE	TATA spare parts
264354100146	ASSY.BATTERY CABLE 650MM +VE 50SQ.MM	TATA spare parts
264354100147	ASSY.BATTERY CABLE 2800MM -VE COT 50SQ.	TATA spare parts
264354106301	BATTERY TRAY (PLASTIC)	TATA spare parts
264354107701	INSULATOR BASE-BATTERY CUT OFF SW	TATA spare parts
264354109903	BATTERY MHD1800	TATA spare parts
264354200106	ASSY BRACKET-STARTER RELAY MTG.	TATA spare parts
264354200110	ASSY BRACKET (FOR RELAY & FUSE BASE MTG)	TATA spare parts
264354200112	ASSY BRACKET (FOR RESISTOR MTG)	TATA spare parts

264354200116	INSTRUMENT CLUSTER 1:0.70	TATA spare parts
264354200117	INSTRUMENT CLUSTER 1:0.70 W/PTO-	TATA spare parts
264354200119	INST.CLUSTER 1:0.60 LPT613	TATA spare parts
264354200121	INSTRUMENT CLUSTER 1:0.60	TATA spare parts
264354200122	INSTRUMENT CLUSTER 1:0.70	TATA spare parts
264354200124	ASSY.BRACKET (DC-DC 10/18A COVERTOR MTG)	TATA spare parts
264354200145	INSTRUMENT CLUSTER 1:0.70	TATA spare parts
264354200146	INSTRUMENT CLUSTER 1:0.60 LPT613	TATA spare parts
264354200154	FAN OUT UNIT FOR EIII ESPEEDO 12V/24V-M	TATA spare parts
264354200161	TPMS DISPLAY UNIT	TATA spare parts
264354200170	INST.CLUSTER LPT513 0.60 ABS PTO ESPD-II	TATA spare parts
264354206301	COVER (FUSE BOX AND RELAYS)	TATA spare parts
264354208201	BRACKET [HORN MTG]	TATA spare parts
264354208202	BRACKET (SPEEDOCABLE)	TATA spare parts
264354208203	BRACKET (SPEEDOCABLE)	TATA spare parts
264354208217	SPEED SENSOR 12/24V (8 PULSE)	TATA spare parts
264354209901	SPEEDOMETER[1:0.7] 6 + 1 OFFER	TATA spare parts
264354209902	SPEEDOMETER [1:0.7] 6+1DIGIT	TATA spare parts
264354209903	SPEEDOMETER [1:0.7] 6+1DIGIT	TATA spare parts
264354209913	SPEEDO CABLE	TATA spare parts
264354209914	SPEEDO CABLE 3300 MM	TATA spare parts
264354209915	SPEEDOCABLE JIS 3300 LG.	TATA spare parts
264354209916	SPEEDOMETER [1:0.7] 6+1DIGIT	TATA spare parts
264354209917	SPEEDOMETER 1:0.70 (6+1) BACKLIT	TATA spare parts
264354209918	SPEEDOMETER 1:0.70 6+1	TATA spare parts
264354209919	SPEEDOMETER 1:0.70 (6+1) BACKLIT	TATA spare parts
264354209920	SPEEDOMETER 1:0.70 (6+1)BACKLIT	TATA spare parts
264354209921	SPEEDOCABLE (JIS) 3300MM	TATA spare parts
264354209926	SPEEDOMETER 1:0.6(6+1DIGIT)BACKLIT	TATA spare parts
264354209928	ELECTRONIC CONTROL UNIT - 12V	TATA spare parts
264354209929	SENSOR (WHEEL SPEED) BS2/3/4/6	TATA spare parts
264354209932	SPEEDO METER(0.70)MOVEMENT	TATA spare parts
264354209934	FUEL GAUGE 12V	TATA spare parts
264354209935	TEMP.GAUGE LPT 613	TATA spare parts
264354209939	SPPEDOMETER RATIO 0.67 LPT613	TATA spare parts
264354209941	SPEEDO METER(0.64)MOVEMENT -IND.INST.	TATA spare parts
264354209942	SPEEDOMETER (0.85) LPT1116SA	TATA spare parts
264354240102	INSTRUMENT CLUSTER 1:0.60	TATA spare parts
264354240103	INSTRUMENT CLUSTER 1:0.70	TATA spare parts
264354240104	INST.CLUSTER-RATIO:0.6-LPT613-24V	TATA spare parts
264354240105	SEAT BELT & CAB TILT WARNING ALARM	TATA spare parts
264354240109	INSTRUMENT CLUSTER 0.67 24V LPT613	TATA spare parts
264354240140	INST.CLUSTER 1:0.60 ABS 24V	TATA spare parts
264354240143	INST.CLUSTER WITH 1:0.85	TATA spare parts
264354240145	INST.CLUSTER-RATIO-1:0.64-ABS-24V	TATA spare parts
264354249901	ELECTRONIC CONTROL UNIT - 24V	TATA spare parts
264354249902	FLASHER 24V BS2/3/4/6	TATA spare parts

264354249903	TEMPERATURE SENSOR	TATA spare parts
264354249904	ELECTROMAGNETIC VALVE 24V	TATA spare parts
264354249905	RELAY 24V NO/NC	TATA spare parts
264354249906	STARTER RELAY 24V 50A	TATA spare parts
264354249909	FLAME GLOW PLUG (24V)	TATA spare parts
264354249910	FUEL GUAGE 24V	TATA spare parts
264354249911	TEMP. GUAGE 24V	TATA spare parts
264354249912	FUEL GAUGE MOVEMENT 24V ESPEEDO	TATA spare parts
264354249913	TEMP.GAUGE MOVEMENT 24V ESPEEDO	TATA spare parts
264354300106	INST_CLUSTER_0.63_LPT_613_EIII	TATA spare parts
264354300107	INST_CLUSTER_0.63_LPT_613_EIII	TATA spare parts
264354300108	INST_CLUSTER_0.63_LPT_613_EIV	TATA spare parts
264354304902	GRID HEATER RELAY 24V 150 AMP	TATA spare parts
264354309901	FLASHER-12V_CAT-6 BS4	TATA spare parts
264354400109	ASSY TURN INDICATOR LAMP -24 V	TATA spare parts
264354400114	ASSY WARNING LAMP 12V	TATA spare parts
264354400115	ASSY WARNING LAMP 12V 7 IND BANK	TATA spare parts
264354400116	ASSY WARNING LAMP 12V	TATA spare parts
264354400127	TAIL LAMP BRACKET RH 1	TATA spare parts
264354400128	TAIL LAMP BRACKET LH 1	TATA spare parts
264354400129	ASSY FRONT FOG LAMP 12V	TATA spare parts
264354400130	ASSY BRACKET -LH (FRONT FOG LAMP MTG.)	TATA spare parts
264354400131	ASSY BRACKET -RH (FRONT FOG LAMP MTG.)	TATA spare parts
264354400137	ASSY. SIDE INDICATOR LH 12V E CERT BS1-6	TATA spare parts
264354400138	ASSY. SIDE IND.RH 12V E CERT BS1/2/3/4/6	TATA spare parts
264354400151	LAMP ASSY TOP MARKER LH 24V	TATA spare parts
264354400152	LAMP ASSY TOP MARKER RH 24V	TATA spare parts
264354408209	BRACKET-BATTERY CUT OFF SWITCH-LP613 MAR	TATA spare parts
264354409901	BULB R5W-12V BS6	TATA spare parts
264354440101	ASSY H/L ECERT 24V LH-LHD -1.3%	TATA spare parts
264354440102	ASSY H/L ECERT 24V RH-LHD -1.3%	TATA spare parts
264354440105	ASSY H/L ECERT 24V LH-LHD-1.3%	TATA spare parts
264354440106	ASSY H/L ECERT 24V RH-LHD -1.3%	TATA spare parts
264354440107	ASSY H/L ECERT 24V LH-LHD -1.3%	TATA spare parts
264354440108	ASSY H/L ECERT 24V RH-LHD -1.3%	TATA spare parts
264354440109	ASSY H/L ECERT 24V LH-LHD -1.3%	TATA spare parts
264354440110	ASSY H/L ECERT 24V RH-LHD -1.3%	TATA spare parts
264354440113	LAMP H/L(-1.3%)24V LHD-LH	TATA spare parts
264354440114	ASSY.H/L E`CERT EBULB RH-LHD 24V	TATA spare parts
264354440119	ASSY FRONT FOG LAMP 24V	TATA spare parts
264354440120	ASSY FRONT FOG LAMP 24V E`CER	TATA spare parts
264354440121	ASSY FRONT FOG LAMP 24V E`CER	TATA spare parts
264354440122	ASSY FRONT FOG LAMP 24V E`CER	TATA spare parts
264354440123	ASSY.SIDE IND.LH 24V E`CERT(CAT-6)	TATA spare parts
264354440124	ASSY.SIDE IND.RH 24V E`CERT(CAT-6)	TATA spare parts
264354440127	ASSY 5 CH TAIL LAMP W/BKT-RH	TATA spare parts
264354440128	ASSY 5 CH TAIL LAMP W/BKT-LH	TATA spare parts

264354440131	ASSY. HEAD LAMP LOW BEAM LH BS2/4	TATA spare parts
264354440132	HEAD LAMP LOW BEAM RH-LP 613 BS2/4	TATA spare parts
264354440133	HEAD LAMP HIGH BEAM LH BS3/4	TATA spare parts
264354440134	HEAD LAMP HIGH BEAM RH BS3/4	TATA spare parts
264354440135	ASSY.REAR TURN SIGNAL LAMP-LP 613	TATA spare parts
264354440136	ASSY.FRONT TURN SIGNAL LAMP-LP 613 BS4	TATA spare parts
264354440137	ASSY.REVERSE LAMP-LP 613	TATA spare parts
264354440138	ASSY.BRAKE AND PARKING LAMP-LP 613	TATA spare parts
264354440139	LAMP H/L(-1.3PERC )24VHLL 24V LHD-LH	TATA spare parts
264354440140	LAMP H/L(-1.3PERC )24VHLL 24V LHD-RH	TATA spare parts
264354441601	ASSY FRONT FOG LAMP 24V	TATA spare parts
264354441602	ASSY. SIDE IND. LAMP LH 24V BS1/2/3/4/6	TATA spare parts
264354441603	ASSY. SIDE INDICATOR RH 4V(CAT 6) BS2/3	TATA spare parts
264354500101	ASSY COMBI SW-LHD	TATA spare parts
264354506902	PIANO SWITCH ABS W/O CONNECTOR	TATA spare parts
264354506903	PIANO KEY SWITCH(BATT. CUT OFF)	TATA spare parts
264354600103	W/H FRAME ASSY LPT613/34 24V II ABS	TATA spare parts
264354600115	W/H FRAME ASSY LPT613/38 24V II	TATA spare parts
264354600117	WIRING HARNESS FRAME ASSY ABS	TATA spare parts
264354600119	FUSE BOX COVER WITH SCREEN PRINTING	TATA spare parts
264354600131	WIRING HARNESS ABS FRAME	TATA spare parts
264354601610	W/H ENGINE 24V LHD EURO-III	TATA spare parts
264354601611	W/H TAIL W/O LB 38WB EURO-III LHD	TATA spare parts
264354601612	W/H SENSOR LP/LPT613 697TCIC E-III	TATA spare parts
264354601613	W/H SWITCH LHD 24V EURO-III	TATA spare parts
264354608202	BRACKET EMS TO MAIN INT.CONN.PARKING	TATA spare parts
264354608203	WIRING HARNESS MAIN TO ENG INT. CONN.PAR	TATA spare parts
264354611628	BATTERY CABLE -VE	TATA spare parts
264354611629	CABLE MEGAFUSE O/P TO STARTER +VE	TATA spare parts
264354611630	BATTERY CABLE +VE	TATA spare parts
264354611632	WIRING HARNESS MAIN	TATA spare parts
264354611633	WIRING HARNESS TAIL	TATA spare parts
264354611634	WIRING HARNESS EMS	TATA spare parts
264354611635	WIRING HARNESS MAXI FUSE	TATA spare parts
264354620113	W/H.MAIN-LHD	TATA spare parts
264354620120	WIRING HARNESS FRONT TO TAIL	TATA spare parts
264354620123	WIRING HARNESS MAIN -LHD	TATA spare parts
264354620140	W/H BLOWER	TATA spare parts
264354620141	W/H SEAT BELT	TATA spare parts
264354620142	W/H ROOF	TATA spare parts
264354620145	W/H MAIN LHD EURO-II	TATA spare parts
264354620146	W/H ENGINE LHD EURO-II	TATA spare parts
264354620147	W/H INSTRUMENT CONSOLE	TATA spare parts
264354620148	W/H TAIL 38WB CAB TRUCK LHD	TATA spare parts
264354620151	W/H MAIN LHD EURO-II W/HD 24V	TATA spare parts
264354620153	W/H TAIL LHD 38WB LP613	TATA spare parts
264354620155	W/H ENGINE LHD BS-II 24V	TATA spare parts

264354620156	W/H MAIN LPT613 LHD 24V E-II W/ABS	TATA spare parts
264354620157	W/H ENGINE LHD 24V W/BERU CONT	TATA spare parts
264354620158	W/H MAIN LPT 613 W/O HD & PTO 24V	TATA spare parts
264354620160	W/H MAIN LP/LPT613 LHD W/S CAM	TATA spare parts
264354620161	W/H MAIN LP/LPT 613 LHD W/HD & PTO	TATA spare parts
264354620162	WIRING HARNESS (FRONT TO TAIL)	TATA spare parts
264354620163	W/H TAIL LPT 613 LHD 38 WB TRUCK	TATA spare parts
264354620165	WIRING HARNESS TAIL	TATA spare parts
264354620167	W/H TAIL LP 613 LHD 38WB TRUCK	TATA spare parts
264354620170	W/H TAIL LPT613 LHD 38WB 24V BS-II	TATA spare parts
264354620172	W/H ENGINE LHD 24V EURO-III	TATA spare parts
264354620173	W/H TAIL W/O LB 38WB EURO-III LHD	TATA spare parts
264354620174	W/H SENSOR LP/LPT613 697TCIC E-III	TATA spare parts
264354620175	W/H SWITCH LHD 24V EURO-III	TATA spare parts
264354620176	W/H MAIN LHD 24V EURO-III ABS HD	TATA spare parts
264354620177	W/H PARK BRAKE SW.& SEAT BELT SW	TATA spare parts
264354620182	W/H SW.LPT/LPK713 EII W/OABS&W/PTO	TATA spare parts
264354620183	W/H MAIN LPT613 12V E-II W/APP/PTO	TATA spare parts
264354620184	W/H TAIL LPT613/34WB EII APP/PTO	TATA spare parts
264354620185	W/H ENGINE LPT613 12V E-II	TATA spare parts
264354620194	W/H TAIL LPT613 E-II 38WB W/PTO	TATA spare parts
264354620201	W/H MAIN LPT613 ABS PTO EX2	TATA spare parts
264354620202	W/H TAIL LPT613/34WB II PTO ESP	TATA spare parts
264354620204	W/H SWITCH LPT613 EX2 ABS PTO	TATA spare parts
264354630105	W/H MAIN LP613 24V II ABS	TATA spare parts
264354630106	W/H TAIL LP613/38WB 24V II	TATA spare parts
264354630107	W/H ENGINE LP613 24V II	TATA spare parts
264354630108	W/H MAXIFUSE & BATT.CUT OFF SW.-LP 613	TATA spare parts
264354630109	W/H HEAD LAMP AND BLINKER LP 613	TATA spare parts
264354630110	W/H SEAT BELT LP613 MARCOPOLO	TATA spare parts
264354630111	W/H SEAT BELT SW.FOR LP709/909/613	TATA spare parts
264354630121	W/H MAIN LP913 24V EII ABS LHD TMML	TATA spare parts
264354630122	WIRING HARNESS ENGINE	TATA spare parts
264354630125	WIRING HARNESS H/L & BLINKER	TATA spare parts
264354630126	W/H TAIL LP913 24V II ABS	TATA spare parts
264354630134	WIRING HARNESS MAIN	TATA spare parts
264354630135	WIRING HARNESS ENGINE	TATA spare parts
264354630136	WIRING HARNESS TAIL	TATA spare parts
264354630137	WIRING HARNESS MAXIFUSE	TATA spare parts
264354630138	WIRING HARNESS HEAD LAMP AND BLINKER	TATA spare parts
264354630139	WIRING HARNESS MAXIFUSE	TATA spare parts
264354630140	WIRING HARNESS TAIL	TATA spare parts
264354630141	WIRING HARNESS MAIN	TATA spare parts
264354690102	W/H ENGINE LHD 24V EURO-III	TATA spare parts
264354690103	W/H TAIL W/O LB 38WB BSIII LHD	TATA spare parts
264354690104	W/H SENSOR LP/LPT613 697TCIC E-III	TATA spare parts
264354690106	W/H SWITCH LHD 24V EURO-III	TATA spare parts

264354690135	W/H GRID HEATER FOR LP 613	TATA spare parts
264354690136	WIRING HARNESS_MAIN	TATA spare parts
264354690137	WIRING HARNESS CAB TILT SWITCH	TATA spare parts
264354690138	WIRING HARNESS_TAIL	TATA spare parts
264354690139	WIRING HARNESS_SENSOR	TATA spare parts
264354690140	WIRING HARNESS_ENGINE	TATA spare parts
264354690141	WIRING HARNESS_GRID_HEATER	TATA spare parts
264354690142	WH SESNOR EIII IMPROVEMENT	TATA spare parts
264354690143	WIRING HARNESS MAIN 613 IMPROVEMENT	TATA spare parts
264354690144	WIRING HARNESS TAIL 613 EIII	TATA spare parts
264354690146	WIRING HARNESS ENGINE LHD 24V EURO-III	TATA spare parts
264354709903	TPMS SENSOR	TATA spare parts
264354800104	RECEIVER TYRE PRESSURE MONITORING SYSTEM	TATA spare parts
264382400102	KIT FOR FRT WIND SCREEN WASHER UNIT 24V	TATA spare parts
264382400102AE	TWIN JET NOZZLE 715	TATA spare parts
264382400104	ASSY.WIPER BLADE (600 MM.LG)	TATA spare parts
264382400105	ASSY WIPER MOTOR W/BKT LHD 12V	TATA spare parts
264382400107	WIPER MOTOR 24V 17W-LHD(2SPEED)	TATA spare parts
264382400107AE	WIPER MOTR.24V;17W-(2SPEED)-1415	TATA spare parts
264382400109	WIPER MOTOR W/BKT 24V LHD HI-POWER BS1/2	TATA spare parts
264382400109AE	WIPER MOTOR 2523	TATA spare parts
264382400114	WIRING HARNESS WASHER BOTTLE TANK	TATA spare parts
264382409901	WIPER MOTOR HI-POWER (LHD) W/MSSL	TATA spare parts
264382440101	KIT ELECTRIC W/S WASHER UNIT 24V	TATA spare parts
264415400101	ALTERNATOR 12V/40A	TATA spare parts
264420143805	SPACER-FOR FAN	TATA spare parts
264424100101	BRACKET ENG MTG	TATA spare parts
26442640010120	ASSY LEVER PTO RHD	TATA spare parts
264426400104	LEVER ASSY	TATA spare parts
264426406301	RUBBER BELLOW	TATA spare parts
264426406301AE	RUBBER BELLOW	TATA spare parts
264429100101	ASSY TUBE	TATA spare parts
264429100109	ASSY. BRAKE PEDAL LEVER COMPLETE	TATA spare parts
264430100103	LEVER ACCELERATOR	TATA spare parts
264431000101	FRAME ASSY SFC 609/38WB	TATA spare parts
264431000103	FRAME ASSY SFC 609/41WB	TATA spare parts
264431000105	FRAME ASSY SFC609/38 COWL	TATA spare parts
264431208204	REINFORCEMENT TOP (RH)	TATA spare parts
264431208205	REINFORCEMENT TOP (LH)	TATA spare parts
264431208212	REINFORCEMENT-RH	TATA spare parts
264431208213	REINFORCEMENT-LH	TATA spare parts
264431300102	BRACKET RH	TATA spare parts
264431300103	BRACKET LH	TATA spare parts
264431400101	ASSY. RUBBER BUFFER	TATA spare parts
264431400102	ASSY. RUBBER BUFFER	TATA spare parts
264432100101	ASSY.FRONT SPRING-TRUCK	TATA spare parts
264432100102	LEAF SPRING 1ST W/BUSH	TATA spare parts



264432100102DF	MAIN LEAF FRONT W/BUSH - SFC709	TATA spare parts
264432107102	LEAF SPRING 2ND FRT	TATA spare parts
264432107102DF	SECND LEAF FRONT - SFC709	TATA spare parts
264432107103	LEAF SPRING 3RD FRT	TATA spare parts
264432107103DF	THIRD LEAF FRONT - SFC709	TATA spare parts
264432107104	LEAF SPRING 4TH FRT	TATA spare parts
264432107105	LEAF SPRING 5TH FRT	TATA spare parts
264432107108	EIGHTH LEAF	TATA spare parts
264432107109	NINETH LEAF	TATA spare parts
264432107110	TENTH LEAF	TATA spare parts
264432204202	U CLAMP FRONT	TATA spare parts
264432300102	BKT S/ABS FRONT	TATA spare parts
264432400101	ASSY. REAR SPRING WITH AUX. SPRING	TATA spare parts
264432400103	ASSY. REAR SPRING WITH AUX. SPRING	TATA spare parts
264432400104	ASSY.FIRST LEAF W/BUSH	TATA spare parts
264432400104DF	MAIN LEAF REAR W/BUSH - SFC/LPT709	TATA spare parts
264432400107	ASSY. REAR SPRING WITH AUX. SPRING	TATA spare parts
264432400108	ASSY FIRST LEAF WITH BUSH	TATA spare parts
264432400109	ASSY. REAR SPRING WITH AUX. SPRING	TATA spare parts
264432400111	ASSY. REAR SPRING WITH AUX. SPRING	TATA spare parts
264432400113	ASSY. REAR SPRING WITH AUX. SPRING	TATA spare parts
264432404201	SPRING CLIP	TATA spare parts
264432407101	LEAF SPRING 4TH RR	TATA spare parts
264432407102	FIFTH LEAF- MAIN	TATA spare parts
264432407104	FIRST LEAF 8X845	TATA spare parts
264432407105	SECOND LEAF-AUX.SPRING	TATA spare parts
264432407106	THIRD LEAF-AUX.SPRING	TATA spare parts
264432407107	LEAF SPRING 4TH RR AUX	TATA spare parts
264432407108	FIFTH LEAF-AUX.SPRING	TATA spare parts
264432407109	SIXTH LEAF-AUX.SPRING	TATA spare parts
264432407110	7TH LEAF AUX. 8X268	TATA spare parts
264432407111	FIRST LEAF FOR REAR SPRING	TATA spare parts
264432407112	2ND LEAF 11X1437	TATA spare parts
264432407112DF	SECND LEAF REAR SFC - SFC/LPT709	TATA spare parts
264432407113	3RD LEAF 11X1236	TATA spare parts
264432407113DF	THIRD LEAF REAR - SFC/LPT709	TATA spare parts
264432407114	4TH LEAF 11X1002	TATA spare parts
264432407114DF	FOURTH LEAF REAR - SFC/LPT709	TATA spare parts
264432407115	FIFTH LEAF	TATA spare parts
264432407115DF	FIFTH LEAF REAR - SFC/LPT709	TATA spare parts
264432407116	SIXTH LEAF	TATA spare parts
264432407117	SEVENTH LEAF	TATA spare parts
264432407128	FIRST LEAF (AUX. SPRING)	TATA spare parts
264432407129	SECOND LEAF (AUX. SPRING)	TATA spare parts
264432407130	THIRD LEAF (AUX. SPRING)	TATA spare parts
264432407131	FOURTH LEAF (AUX. SPRING)	TATA spare parts
264432407132	FIFTH LEAF (AUX. SPRING)	TATA spare parts

264432407133	SIXTH LEAF (AUX. SPRING)	TATA spare parts
264432407134	SEVENTH LEAF (AUX. SPRING)	TATA spare parts
264432407136	SECOND LEAF	TATA spare parts
264432407137	THIRD LEAF	TATA spare parts
264432407138	FOURTH LEAF	TATA spare parts
264432407139	FIFTH LEAF	TATA spare parts
264432407140	SIXTH LEAF	TATA spare parts
264432504202	U CLAMP REAR SFC	TATA spare parts
264432504203	U CLAMP	TATA spare parts
264432504204	U CLAMP	TATA spare parts
264432504205	U CLAMP	TATA spare parts
264432504206	U-CLAMP BS6	TATA spare parts
264433000101	FRONT AXLE W/BRAKE RHD	TATA spare parts
264440300101	SP/WHEEL CARRIER 709 SFC	TATA spare parts
264442700101	ASSY CABLE-FRONT	TATA spare parts
264442700103	ASSY.PARKING BRAKE COMP. 3800 WB	TATA spare parts
264442700105	HAND BR CABLE FRT 38WB	TATA spare parts
264442800108	ASSY.TUBE	TATA spare parts
264442800111	ASSY. TUBE	TATA spare parts
264442800112	ASSY.TUBE FRONT RH	TATA spare parts
264442800115	TUBE ASSY 609 SFC	TATA spare parts
264442800116	ASSY.TUBE.	TATA spare parts
264442800119	ASSY.TUBE	TATA spare parts
264442800121	ASSY.TUBE	TATA spare parts
264442800122	ASSY.TUBE.	TATA spare parts
264442800125	ASSY.TUBE	TATA spare parts
264442800126	TUBE 3 WAY CONN TO FRT LH	TATA spare parts
264442800127	ASSY.TUBE.	TATA spare parts
264442800132	TUBE ASSY	TATA spare parts
264442800136	ASSY.TUBE	TATA spare parts
264442900101	HOSE ASSY 609 SFC	TATA spare parts
264442900109	ASSY T SOCKET	TATA spare parts
264442900111	ASSY.TUBE-AIR DRIER TO S.P.VALVE	TATA spare parts
264442900112	ASSY.TUBE-REAR AIR TANK TO D.B.VALVE	TATA spare parts
264442900113	ASSY.TUBE-FRONT AIR TANK TO D.B.VALVE	TATA spare parts
264442900114	ASSY.TUBE-D.B.V.TO FRT.BRK.CHAMBER LH	TATA spare parts
264442900116	ASSY.TUBE-H.B.VALVE TO PARTITION	TATA spare parts
264442900120	ASSY.TUBE TO REAR SERVICE CHAMBER RH/LH	TATA spare parts
264442900121	ASSY TUBE-TO PARKING BRK CHAMBER RH/LH	TATA spare parts
264442900127	ASSY CLAMP	TATA spare parts
264442900128	ASSY.TUBE-S.P.VALVE TO EXH.BRAKE CYL	TATA spare parts
264442900129	ASSY.BRACKET (HOSE MTG.ON REAR AXLE)	TATA spare parts
264442900130	NYLON PIPE SET SFC709/38 RHD	TATA spare parts
264442900149	ASSY. TUBE	TATA spare parts
264442900151	ASSY.PIPE	TATA spare parts
264442904201	CLAMP BS6	TATA spare parts
264442906802	T-SOCKET	TATA spare parts

264442907701	GROMMET BS6	TATA spare parts
264442908202	BRACKET (PURGE TANK MTG.)	TATA spare parts
264443100103	TANDEM MASTER CYL 25.40D	TATA spare parts
264443100104	ASSY TANDEM MASTER CYLINDER 25.4 DIA	TATA spare parts
264443500101	ASSY.VACUUM TANK.	TATA spare parts
264443700101	ASSY. HAND BRAKE VALVE MTG. BRACKET	TATA spare parts
264446200105	ASSY STG GEAR BOX MTG BRACKET-RH (FAB)	TATA spare parts
264446200106	ASSY STG GEAR BOX MTG BRACKET-LH	TATA spare parts
264446306003	PITMAN ARM RHD	TATA spare parts
264446306004	PITMAN ARM LHD M/STRG	TATA spare parts
264446600105	DRAG LINK ASSY LHD	TATA spare parts
264446600108	DRAG LINK ASSY RHD	TATA spare parts
264447000101	FUEL TANK(120 LT)-W/STRAP & SUPPORT BS2	TATA spare parts
264447600101	FUEL RETURN LINE SFC	TATA spare parts
264447600102	FUEL SUCTION LINE SFC	TATA spare parts
264447600105	TUBE ASSY	TATA spare parts
264447600118	ASSY FUEL SUCTION LINE 38WB	TATA spare parts
264447600131	ASSY.RETURN PIPE.	TATA spare parts
264447600134	ASSY. SUCTION LINE TANK TO WATSEP-38WB	TATA spare parts
264447600136	ASSY SUCTION LINE WATSEP TO HOSE.	TATA spare parts
264449200106	ASSY BRACKET1	TATA spare parts
264449200114	ASSY EXH. PIPE INTER	TATA spare parts
264449200115	ASSY EXH. BRAKE COVE	TATA spare parts
264449206901	EXHAUST PIPE REAR SFC	TATA spare parts
264454100101	BATTERY CABLE +VE 1.17LG	TATA spare parts
264454100102	BATTERY CABLE -VE	TATA spare parts
264454100103	ASSY BATT.CABLE +VE W/COT 2.4LG-70SQ MM	TATA spare parts
264454100104	ASSY BATT.CABLE -VE W/COT 2.4LG-70SQ MM	TATA spare parts
264454209901	SPEEDOCABLE 2200MM JIS	TATA spare parts
264454209902	SPEEDOCABLE 2200MM JIS	TATA spare parts
264454209903	AIR PRESSURE GAUGE(52 DIA) OFFER DRG.	TATA spare parts
264454209904	AIR PRESSURE GAUGE	TATA spare parts
264454209905	AIR PRESSURE GAUGE 52 DIA	TATA spare parts
264454209906	AIR PRESSURE GAUGE 52 DIA	TATA spare parts
264454209907	AIR PRESSURE GAUGE 52 DIA	TATA spare parts
264454400106	KIT ASSY TOP MARKER LAMP(MSSL)-OFFER	TATA spare parts
264454400108	KIT ASSY TOP MARKER LAMP	TATA spare parts
264454400110	KIT ASSY TOP MARKER LAMP	TATA spare parts
264454400112	KIT ASSY TOP MARKER LAMP	TATA spare parts
264454620101	TAIL CABLE SET- RHD	TATA spare parts
264454620102	WIRING HARNESS-TAIL SFC 609-41 W.B.	TATA spare parts
264454620103	WIRING HARNESS MAIN-LHD	TATA spare parts
264454620104	WIRING HARNESS TAIL (38 W.B) LHD	TATA spare parts
264454620105	WIRING HARNESS TAIL (41 W.B) LHD	TATA spare parts
264454620106	CABLE SET ENG. - LHD	TATA spare parts
264454620107	WIRING HARNESS MAIN W/S-CAM	TATA spare parts
264454620108	WIRING HARNESS INSTRUMENT CONSOLE SFC 70	TATA spare parts

264454620109	WIRING HARNESS ENGINE	TATA spare parts
264454620110	WIRING HARNESS TAIL 3800 WB	TATA spare parts
264454820101	MAIN CABLE SET RHD	TATA spare parts
264454820102	ASSY CABLE SET (FRONT TO TAIL) 38 WB	TATA spare parts
264454820111	MAIN CABLE SET RHD SFC	TATA spare parts
264470000101	ASSY.LOAD BODY COMPLETE	TATA spare parts
264470000107	ASSY.LOAD BODY COMP.WITH SUPSTR.& CANOPY	TATA spare parts
264470000112	ASSY LOAD BODY COMPLETE-HIGH DECK	TATA spare parts
264470000113	ASSY.LOAD BODY COMPLT.(FIXED & BOLTED)	TATA spare parts
264470000119	ASSY.LOAD BODY COMPLETE	TATA spare parts
264470000120	ASSY.LOAD BODY COMPLETE (HIGH DECK)	TATA spare parts
264470100122	ASSY.SUPPORT	TATA spare parts
264470100139	ASSY.PLATE WITH SUPPORT LH	TATA spare parts
264470100140	ASSY.PLATE WITH SUPPORT RH	TATA spare parts
264470100160	ASSY SUPPORT	TATA spare parts
264470200102	ASSY FRONT PANEL SFC709	TATA spare parts
264470300113	ASSY SIDE PANEL LH SFC709	TATA spare parts
264470300114	ASSY SIDE PANEL RH SFC709	TATA spare parts
264470400101	ASSY TAIL GATE 609	TATA spare parts
264470400104	ASSY TAIL GATE SFC709	TATA spare parts
264470500105	ASSY.CANOPY	TATA spare parts
264625200101	DRIVEN PLATE ASSY-310 DIA. (F&S)	TATA spare parts
264625400101	CL PR PLATE 310 DIA	TATA spare parts
264631208201	REINFORCEMENT END CROSS MEMBER	TATA spare parts
264633050101	ASSY.FRONT AXLE COMP.WITH BRAKES-RHD.	TATA spare parts
264642700104	ASSY PULL ROD (ZP)	TATA spare parts
264652703302	BRACKET (RADIATOR SHELL)	TATA spare parts
264659900101	TOWING HOOK-SWIVEL TYPE	TATA spare parts
264661608204	MUDGUARD R H	TATA spare parts
264661608205	MUDGUARD L H	TATA spare parts
264683506302	PACKING	TATA spare parts
264716100101	CONTAINER(ECU 497TC96 BSIII) SFC/LP 712	TATA spare parts
264724100103	BRACKET ASSY ENGINE MTG LH BS6-PH2	TATA spare parts
264724100104	BRACKET ASSY ENGINE MTG RH BS6-PH2	TATA spare parts
264724203701	ENGINE MTG ARM BS6	TATA spare parts
264729100101	ASSY TUBE	TATA spare parts
264729100108	ASSY. REINFORCEMENT	TATA spare parts
264729100116	ASSY. CLUTCH PEDAL WITH RUBBER COVER	TATA spare parts
264729100117	ASSY. BRAKE PEDAL WITH RUBBER COVER	TATA spare parts
264729100121	LEVER ASSY W/BUSH CLUTCH PEDAL BS6-PH2	TATA spare parts
264729100123	BRACKET ASSY CLUTCH & BRAKE PEDAL MTG	TATA spare parts
264729107701	FOAM SEALING BS6	TATA spare parts
264729200101	BRAKE PEDAL ASSY WITH BUSH BS6	TATA spare parts
264729200104	BRAKE PEDAL ASSY WITH BUSH BS6-PH2	TATA spare parts
264729300103	PUSH ROD ASSY	TATA spare parts
264729300106	BUNDY TUBE ASSY CMC TO LONG MEMBER BS6	TATA spare parts
264729300110	BUNDY TUBE ASSY	TATA spare parts

264729300113	BUNDY TUBE ASSY CMC TO LONG MEMBER BS6	TATA spare parts
264729500101	BRACKET ASSY CLUTCH BOOSTER MTG BS6	TATA spare parts
264730100102	ASSY.PEDAL MTG. BRACKET	TATA spare parts
264730100105	ASSY. CONTROL SHAFT WITH BRACKET	TATA spare parts
264730100107	ASSY. CABLE COMPLETE	TATA spare parts
264730100111	BRACKET ASSY ACCELERATOR PEDAL MTG BS6-P	TATA spare parts
264730108701	SPRING	TATA spare parts
264731000104	ASSY. FRAME SFC712 BS-III 38WB	TATA spare parts
264731000105	ASSY. FRAME SFC712EX WITHOUT CLEAT	TATA spare parts
264731000106	ASSY FRAME SFC 712EX/41WB BS-III	TATA spare parts
264731000116	FRAME ASSY WITH FITMENT	TATA spare parts
264731000119	FRAME ASSY WITH FITMENT BS6	TATA spare parts
264731000121	FRAME ASSY WITH FITMENT BS6	TATA spare parts
26473100M10119	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
26473100M10120	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
26473100M10121	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
264731200101	ASSY. CROSS MEMBER	TATA spare parts
264731200104	BRACKET ASSY WITH SPACER BS6	TATA spare parts
264731200106	BRACKET ASSY CROSS MEMBER MTG RH BS6	TATA spare parts
264731200107	BRACKET ASSY CROSS MEMBER MTG LH BS6	TATA spare parts
264731200108	CROSS MEMBER ASSY BS6	TATA spare parts
264731200112	CROSS MEMBER ASSY WITH SUPPORT BS6-PH2	TATA spare parts
264731200114	CROSS MEMBER ASSY RSB FRONT BS6-PH2	TATA spare parts
264731200116	CROSS MEMBER ASSY REAR SPIRNG BS6-PH2	TATA spare parts
264731203301	SUPPORT BRACKET CROSS MEMBER RH BS6	TATA spare parts
264731203302	SUPPORT BRACKET CROSS MEMBER LH BS6	TATA spare parts
264731203303	BASE PLATE BRACKET BS6	TATA spare parts
264731208204	REINFORCEMENT RH	TATA spare parts
264731208205	REINFORCEMENT LH	TATA spare parts
264731208207	REINFORCEMENT - RH	TATA spare parts
264731208208	REINFORCEMENT - LH	TATA spare parts
264731208213	REINFORCEMENT RH BS6	TATA spare parts
264731208214	REINFORCEMENT LH BS6	TATA spare parts
264731208215	REINFORCEMENT RH BS6	TATA spare parts
264731208216	REINFORCEMENT BS6	TATA spare parts
264731208217	REINFORCEMENT BOTTOM RH BS6	TATA spare parts
264731208218	REINFORCEMENT BOTTOM LH BS6	TATA spare parts
264731208228	REINFORCEMENT RH BS6	TATA spare parts
264731208229	REINFORCEMENT RH BS6	TATA spare parts
264731247101	PACKING PLATE BS6	TATA spare parts
264731247102	PACKING PLATE BS6	TATA spare parts
264732100101	FRONT SPRING ASSY	TATA spare parts
264732100105	FRONT SPRING ASSY BS6	TATA spare parts
264732107107	SEVENTH LEAF BS6	TATA spare parts
264732300101	BRACKET ASSY SHOCK ABSORBER MTG FRONT BS	TATA spare parts
264733000101	ASSY.FRT.AXLE WITH S-CAM BRAKES RHD ASB	TATA spare parts
264733000103	FRONT AXLE 712 SFC	TATA spare parts

264733000104	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
264733105101	FRONT AXLE BEAM BS6-PH2	TATA spare parts
264733800101	TIE ROD ASSY BS6	TATA spare parts
264733800102	TIE ROD ASSY BS6	TATA spare parts
264733800103	TIE ROD ASSY BS6-PH2	TATA spare parts
264733805101	STEERING ARM BS6	TATA spare parts
264740300103	ASSY.SPARE WHEEL CARRIER	TATA spare parts
264741100101	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
264741100106	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
264741110101	ASSY.PROP.SHAFT WITH CENTER BEARING	TATA spare parts
264741110104	PROPELELR SHAFT ASSY MONOTRON	TATA spare parts
264741110106	PROPELELR SHAFT ASSY MONOTRON	TATA spare parts
264741110107	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
264741120105	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
264741300101	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
264741303301	BRACKET CENTER BRG MTG	TATA spare parts
264742100101	BRAKE CHAMBER-TYPE 10.5	TATA spare parts
264742100104	BRAKE CHAMBER-TYPE 10.5	TATA spare parts
264742107701	DIAPHRAGM-BRAKE CHAMBER	TATA spare parts
264742300101	SPRING BRAKE ACTUATOR TYPE-10.5/12	TATA spare parts
264742300105	REPAIR KIT-S.BRK.ACTUATOR	TATA spare parts
264742800104	ASSY TUBE	TATA spare parts
264743200108	AIR TANK ASSY WITH BKT BS6-PH2	TATA spare parts
264743203304	BRACKET ASSY AIR TANK MTG	TATA spare parts
264743700106	DUAL BRAKE VALVEBS6	TATA spare parts
264743700116	SPRING BRAKE ACTUATOR BS6	TATA spare parts
264743900105	ASSY.PIPE-COMPR. TO DDU	TATA spare parts
264743900106	ASSY. PIPE (IST PIPE FROM COMPRESSOR TO	TATA spare parts
264743900107	ASSY.NYLON PIPES CAB BUNCH	TATA spare parts
264743900108	ASSY.NYLON PIPE SET CHASSIS COMPL-SFC709	TATA spare parts
264743900129	ASSY.NYLON PIPE SET CHASSIS COMPL-SFC712	TATA spare parts
264743900166	ASSY.NY.PIPE SET CAB COMPL-SFC 709 CAB/V	TATA spare parts
264743900174	ASSY.NYLON PIPE SET CHASSIS COMPL-SFC712	TATA spare parts
264743900191	PIPE BUNCH ASSY CABIN	TATA spare parts
264743906801	ADAPTOR (VOSS)	TATA spare parts
264743910142	METAL PIPE ASSY BS6	TATA spare parts
264743910143	METAL PIPE ASSY BS6	TATA spare parts
264743910144	METAL PIPE ASSY BS6	TATA spare parts
264743910145	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
264743910148	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
264743910164	METAL PIPE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts
264743910165	METAL PIPE ASSY ADAPTER TO APU BS6	TATA spare parts
264743910239	METAL PIPE ASSY BS6-PH2	TATA spare parts
264743910251	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
264746200101	ASSY. SPINDLE	TATA spare parts
264746200102	ASSY. STEERING BRACKET	TATA spare parts
264746200104	ASSY. STEERING GEAR BOX (RHD) 909SFC	TATA spare parts

264746200106	ASSY POWER STRG. GEAR BOX-RH	TATA spare parts
264746305101	PITMANARM BS6	TATA spare parts
264746600101	ASSY.DRAG LINK (RHD)	TATA spare parts
264746600102	ASSY.DRAG LINK (RHD)	TATA spare parts
264746600104	STEERING GEAR BOX ASSY BS6	TATA spare parts
264746600107	HOUSINGASSY BS6	TATA spare parts
264746600108	WORM&RACKASSY BS6	TATA spare parts
264746600110	POWERSTEERINGGEARASSY BS6	TATA spare parts
264746800104	ASSY BKT (RESERVOIR MTG)	TATA spare parts
264746800108	ASSY TUBE (PUMP TO GEAR BOX)	TATA spare parts
264746800111	ASSY CRIMPED HOSE(RESERVOIR TO GEAR BOX)	TATA spare parts
264746800112	ASSY CRIMPED HOSE (GEAR BOX TO PUMP)	TATA spare parts
264746800113	ASSY CRIMPED HOSE (PUMP TO RESERVOIR)	TATA spare parts
264746900101	DRAG LINK ASSY¿BS6	TATA spare parts
264746900103	DRAG LINK ASSY BS6-PH2	TATA spare parts
264746990105	KIT-SEAL BS6	TATA spare parts
264747000101	ASSY.FUEL TANK W/ STRAP,SUPPPORT& RUBBER	TATA spare parts
264747600101	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
264747600102	FUEL RETURN PIPE ASSY BS6	TATA spare parts
264747600107	SUCTION LINE PIPE ASSY BS6	TATA spare parts
264747600108	ASSY.SUCTION LINE (TANK TO W/SEP)-160L	TATA spare parts
264747600109	ASSY.SUCTION LINE (W/SEP TO HOSE)-160L	TATA spare parts
264747600110	ASSY.RETURN LINE-160L	TATA spare parts
264747600117	ASSY.SUCTION LINE(NYLON)TANK TO W/S	TATA spare parts
264747600118	ASSY.SUCTION LINE(NYLON) W/S TO FILT	TATA spare parts
264747600119	ASSY.RETURN LINE(NYLON)	TATA spare parts
264747600120	ASSY.SUCTION LINE(TANK TO STRAINER)	TATA spare parts
264747600121	ASSY.SUCTION LINE(STRAINER TO MICO W/S)	TATA spare parts
264747600122	ASSY.SUCTION LINE(W/SEP.TO FEED PUMP)	TATA spare parts
264747600123	ASSY.SUCTION LINE(FEED PUMP TO INTAKE)	TATA spare parts
264747600124	ASSY.RETURN LINE COMPLETE(TANK TO OVERFL	TATA spare parts
264747600125	ASSY SUCTION LINE (TANK TO W/SEP)	TATA spare parts
264747600126	ASSY SUCTION LINE (W/SEP. TO INTAKE)	TATA spare parts
264747600127	ASSY RETURN LINE (OVERFLOW TO TANK)	TATA spare parts
264747600129	ASSY.SUCTION LINE(STRAINER TO FEED PUMP)	TATA spare parts
264747600130	ASSY SUCTION LINE (FILTER TO FIP)	TATA spare parts
264747600131	ASSY DELIVERY LINE (FEED PUMP TO FILTER	TATA spare parts
264747600139	SUCTION PIPE ASSY TANK TO SEDIMENTER	TATA spare parts
264747600140	SUCTION PIPE ASSY FILTER TO FIP	TATA spare parts
264747600141	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
264747600144	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
264747600145	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
264747600146	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
264747600147	FUEL RETURN PIPE ASSY BS6	TATA spare parts
264747600148	FUEL PIPE ASSY FILTER TO FIP BS6	TATA spare parts
264747600149	FUEL RETURN PIPE ASSY ENGINE TO TANK SEG	TATA spare parts
264747600151	FUEL RETURN PIPE ASSY ENGINE TO TANK SEG	TATA spare parts

264747605801	FUEL HOSE (SUCTION SIDE)	TATA spare parts
264747605802	FUEL HOSE (ENGINE SIDE)	TATA spare parts
264747608201	BRACKET ( W/SEP.MTG)	TATA spare parts
264747608202	BRACKET (FUEL PIPELINE MTG.)	TATA spare parts
264747608204	BRACKET(STRAINER MOUNTING)	TATA spare parts
264749200101	ASSY.EXHAUST BRAKE COVER	TATA spare parts
264749200102	ASSY EXHAUST PIPE FRONT	TATA spare parts
264749200103	ASSY.INTERMEDIATE PIPE SFC 709	TATA spare parts
264749200105	EXH PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
264749200110	ASSY. EXHAUST PIPE FRONT	TATA spare parts
264749200111	PIPE ASSY DPS SENSOR INTAKE	TATA spare parts
264749200112	ASSY FRT EXH PIPE WITH FLEX BELLOW BS-II	TATA spare parts
264749200114	ASSY. FRONT EXHAUST PIPE (WIH FLX.BELLOW	TATA spare parts
264749200116	ASSY.FRONT EXHAUST PIPE WITH FLEX BELLOW	TATA spare parts
264749200117	ASSY.FRONT EXHAUST PIPE WITH FLEX.BELLOW	TATA spare parts
264749200118	ASSY.BRACKET WITH HOOK	TATA spare parts
264749200122	STONE GUARD BS6	TATA spare parts
264749200124	ASSY UREA TANK MTG BS6	TATA spare parts
264749200126	BRACKET ASSY UREA TANK MTG BS6	TATA spare parts
264749200127	BRACKET ASSY UREA TANK MTG BS6	TATA spare parts
264749200128	BRACKET ASSY UREA TANK MTG LH BS6	TATA spare parts
264749200129	BRACKET ASSY UREA TANK MTG BS6	TATA spare parts
264749200133	BRACKET ASSY UREA TANK MTG RH BS6	TATA spare parts
264749200137	UREA TANK ASSY BS6	TATA spare parts
264749200139	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
264749200140	BRACKET ASSY EXHAUST PIPE BS6	TATA spare parts
264749200144	EXH PIPE ASSY ELBOW TO EXH BRAKE BS6-PH2	TATA spare parts
264749200147	BRACKET ASSY BS6	TATA spare parts
264749200148	SHIELD BOTTOM SIDE BS6	TATA spare parts
264749200151	BRACKET ASSY BS6	TATA spare parts
264749200159	PIPE ASSY UREA SUPPLY BS6-PH2	TATA spare parts
264749200161	PIPE ASSY UREA SUPPLY BS6-PH2	TATA spare parts
264749203308	BRACKET UREA&TANK&BASE&MTG& BS6	TATA spare parts
264749203309	BRACKET UREA TANK BS6	TATA spare parts
264749203317	BRACKET UREA&TANK&BASE&MTG& BS6	TATA spare parts
264749203333	SUPPORT BRACKET EXHAUST BRAKE BS6-PH2	TATA spare parts
264749206302	UREA TANK BS6	TATA spare parts
264749207103	EXHAUSTFLANGE BS6	TATA spare parts
264749207702	RUBBER&PACKING UREA&TANK& BS6	TATA spare parts
264749207801	O-RING BS6	TATA spare parts
264749208208	SUPPORT PLATE	TATA spare parts
264749600101	HEAT SHIELD ASSY BS6-PH2	TATA spare parts
264754100101	ASSY.COPPER BATTERY CABLE (+VE) 1.35LG	TATA spare parts
264754100102	ASSY.COPPER BATTERY CABLE (-VE) 1.35LG	TATA spare parts
264754100103	ASSY.BATTERY CABLE -VE 50 SQMM 1.9M LG.	TATA spare parts
264754100111	ASSY.BATT.CABLE +VE 1.55M W/COT 35SQ.MM	TATA spare parts
264754100112	ASSY.BATT.CABLE -VE 1.35M W/COT 35SQ.MM	TATA spare parts



264754100113	ASSY.CHANNEL (BATT.CLAMPING)	TATA spare parts
264754106303	BATTERY COVER (FOR 100AH BATTERY)	TATA spare parts
264754106304	BATTERY TRAY (FOR 100AH BATTERY)	TATA spare parts
264754106305	BATTERY TRAY (PLASTIC)	TATA spare parts
264754108202	CHANNEL [BATTERY CLAMPING]	TATA spare parts
264754200103	INSTRUMENT CLUSTER (1:0.78) SFC709-OFFER	TATA spare parts
264754200105	INSTRUMENT CLUSTER (0.78)SFC709	TATA spare parts
264754200107	INSTRUMENT CLUSTER-1:0.78	TATA spare parts
264754200108	INSTRUMENT CLUSTER-1:0.78	TATA spare parts
264754200109	INSTRUMENT CLUSTER (1:0.78) OFFER	TATA spare parts
264754200113	W/H INST. CLUSTER	TATA spare parts
264754200122	INSTRUMENT CLUSTER ASSY	TATA spare parts
264754200128	W/H INST. CLUST.	TATA spare parts
264754200130	ASSY BRACKET ENG STOP RELAY MTG	TATA spare parts
264754200131	INSTRUMENT CLUSTER (1:0.78)	TATA spare parts
264754200134	INSTRUMENT CLUSTER 1:0.60	TATA spare parts
264754200136	INSTRUMENT CLUSTER 1:0.60	TATA spare parts
264754200138	INSTRUMENT CLUSTER 1:0.60	TATA spare parts
264754200139	INSTRUMENT CLUSTER 1:0.78 CRPF	TATA spare parts
264754200142	INSTRUMENT CLUSTER (1:0.72) SFC909 EX BS	TATA spare parts
264754200143	INSTRUMENT CLUSTER (1:0.64)	TATA spare parts
264754200152	INST.CLUSTER 0.76 SFC709 MECH.SPEEDO	TATA spare parts
264754200156	INST CLUST ESPEEDO SFC712 0.60	TATA spare parts
264754200161	INST CLUST ESPEEDO SFC712 0.60	TATA spare parts
264754209902	FUEL GAUGE 407/709	TATA spare parts
264754209903	TEMPERATURE GAUGE 407/709	TATA spare parts
264754209907	CRYSTAL (SPEEDO METER) SFC407	TATA spare parts
264754209909	SPEEDOMETER (1:0.78)	TATA spare parts
264754209910	SPEEDOSYSTEM 0.78 W/PARKING -IND	TATA spare parts
264754209918	CLUSTER HOUSING	TATA spare parts
264754209919	SPEEDOMETER 0.60 ESPEEDO	TATA spare parts
264754209920	SPEEDOMETER 0.60 ESPEEDO 709	TATA spare parts
264754209921	SPEEDO METER	TATA spare parts
264754209922	SPEEDOMETER 0.72 ESPEEDO 709	TATA spare parts
264754209923	SPEEDOMETER 0.76 ESPEEDO 709	TATA spare parts
264754209924	SPEEDOMETER 0.76 ESPEEDO 709	TATA spare parts
264754303301	BRACKET HORN MTG BS6-PH2	TATA spare parts
264754400101	KIT-ASSY TOP MARKER LAMP	TATA spare parts
264754400103	KIT-ASSY TOP MARKER LAMP	TATA spare parts
264754400105	KIT-ASSY TOP MARKER LAMP	TATA spare parts
264754400107	KIT-ASSY TOP MARKER LAMP	TATA spare parts
264754400109	ASSY.SIDE MARKER LAMP-ECER-12V	TATA spare parts
264754400110	END OUTLINE MARKER LAMP	TATA spare parts
264754400112	KIT ASSY.TOP MARKER LAMP	TATA spare parts
264754400114	KIT-ASSY TOP MARKER LAMP	TATA spare parts
264754400118	END OUTLINE MARKER LAMP	TATA spare parts
264754400119	END OUTLINE MARKER LAMP BS1/2/3/4	TATA spare parts

264754400120	END OUTLINE MARKER LAMP	TATA spare parts
264754400122	END OUTLINE MARKER LAMP	TATA spare parts
264754400123	END OUTLINE MARKER LAMP	TATA spare parts
264754400138	ASSY SIDE MARKER LAMPECERT	TATA spare parts
264754400139	SIDE MARKER LAMP 12V	TATA spare parts
264754400142	END OUTLINE MARKER LAMP	TATA spare parts
264754504901	COMBI SWITCH ASSY BS6-PH2	TATA spare parts
264754600113	W/H DANDA MAN SW.	TATA spare parts
264754600114	RETROFITMENT KIT FOR ENG.STOP SOLENOID	TATA spare parts
264754600116	W/H TAIL 38WB RHD	TATA spare parts
264754600119	W/H SIDE & END OUTLINE MARKER LAMP	TATA spare parts
264754600120	W/H TAIL 38WB RHS W/LB	TATA spare parts
264754600122	W/H TAIL 38WB RHD F.E.W/LB	TATA spare parts
264754600124	W/H MAIN RHD BS-II W/MOT LEVEL	TATA spare parts
264754600125	W/H INST CONSL BS-II W/MOT LEVEL	TATA spare parts
264754600130	W/H MAIN W/INST.CLUSTER	TATA spare parts
264754600136	W/H MAIN SFC709 BS-II W/CLST.	TATA spare parts
264754600137	W/H TAIL SFC709 FE TRUCK/38WB	TATA spare parts
264754600149	BATTERY CABLE +VE	TATA spare parts
264754600180	WIRING HARNESS ENGINE	TATA spare parts
264754600182	WIRING HARNESS MAIN	TATA spare parts
264754600189	WIRING HARNESS TAIL BS6	TATA spare parts
264754600190	WIRING HARNESS PARKING BRAKE BS6	TATA spare parts
264754600192	WIRING HARNESS MAIN BS6	TATA spare parts
264754600196	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
264754600197	BATTERY CABLE +VE BS6-PH2	TATA spare parts
264754600199	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
264754601610	WIRING HARNESS TAIL	TATA spare parts
264754601612	WIRING HARNESS EMS	TATA spare parts
264754601663	W/H PIGTAIL L.P.SW.SFC709	TATA spare parts
264754603303	BRACKET EMS WIRING HARNESS MTG	TATA spare parts
264754608201	CLAMP - (NO PLATE)	TATA spare parts
264754610107	WIRING HARNESS TAIL BS6	TATA spare parts
264754610112	WIRING HARNESS MAIN BS6	TATA spare parts
264754610123	W/H MAIN W/O ENG STOP RELAY	TATA spare parts
264754610145	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
264754610146	WIRING HARNESS EMS BS6-PH2	TATA spare parts
264754610153	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
264754610154	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
264754610157	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
264754610158	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
264754620111	WIRING HARNESS MAIN - RHD	TATA spare parts
264754620120	WIRING HARNESS TAIL-38 WB.- HIDECK LOADB	TATA spare parts
264754620122	WIRING HARNESS INST CONSOLE W/EXH BRK	TATA spare parts
264754620127	WIRING HARNESS MAIN RHD SFC709	TATA spare parts
264754620128	WIRING HARNESS MAIN -RHD	TATA spare parts
264754620136	W/H BACK LIGHTING (12V)	TATA spare parts

264754620146	W/H TAIL 38WB RHD S CAM EURO-II	TATA spare parts
264754620151	W/H MAIN RHD CMVR2000 S CAM	TATA spare parts
264754620152	W/H INSTRUMENT CONSOLE CMVR2000	TATA spare parts
264754620155	W/H TAIL 38WB S CAM HI-DECK LB	TATA spare parts
264754620158	W/H SIDE & END OUTLINE MARKER LAMP	TATA spare parts
264754620159	W/H TAIL RHD 38WB W/LOADBODY	TATA spare parts
264754620161	W/H TAIL 38WB RHD F.E.W/LB	TATA spare parts
264754620162	W/H MAIN RHD CMVR2000	TATA spare parts
264754620164	W/H MAIN RHD BS-II W/MOT LEVEL	TATA spare parts
264754620165	W/H INST CONSL BS-II W/MOT LEVEL	TATA spare parts
264754620166	W/H MAIN W/INST.CLUSTER BS-II	TATA spare parts
264754620177	W/H MAIN SFC709 BS-II W/CLST	TATA spare parts
264754620180	W/H TAIL SFC709 FE TRUCK/38WB	TATA spare parts
264754620186	W/H PIG TAIL L.P.SWITCH SFC709	TATA spare parts
264754660105	WIRING HARNESS SEAT BELT SWITCH	TATA spare parts
264754660118	W/H TAIL 38WB RHD S CAM EURO-II	TATA spare parts
264754660120	W/H MAIN RHD EURO-II W/EXH BRK	TATA spare parts
264754660123	W/H TAIL 38WB WITH HI-DECK LOADBODY	TATA spare parts
264754660128	W/H DANDA MAN SW.	TATA spare parts
264754660130	W/H MAIN RHD BHARAT STAGE-II	TATA spare parts
264754660131	WIRING HARNESS ENGINE STOP SOLENOID	TATA spare parts
264754660132	W/H MAIN W/ADD ENG STOP RELAY	TATA spare parts
264754660137	W/H ENGINE START SOLENOID PIG-TAIL	TATA spare parts
264754660138	W/H HAND BRK. SW.SINGLE POLE	TATA spare parts
264754660139	WIRING HARNESS MAIN RHD BS-II	TATA spare parts
264754660140	W/H MAIN RHD CMVR2000	TATA spare parts
264754660141	WIRING HARNESS MAIN RHD BS-II	TATA spare parts
264754660142	W/H INSTRUMENT CONSOLE	TATA spare parts
264754660143	W/H TAIL 38WB W/LB	TATA spare parts
264754660149	W/H TAIL 38WB RHD F.E.W/LB	TATA spare parts
264754660150	W/H SIDE & END OUTLINE MARKER LAMP	TATA spare parts
264754660153	W/H TAIL 38WB CRPF	TATA spare parts
264754660154	W/H ROOF (ROOF+END OUTLINE) REAR	TATA spare parts
264754660158	W/H MAIN W/O ENG STOP RELAY	TATA spare parts
264754660159	W/H MAIN RHD CMVR2000 CRPF	TATA spare parts
264754660160	W/H MAIN RHD BS-II W/MOT LEVEL	TATA spare parts
264754660161	W/H INST CONSL BS-II W/MOT LEVEL	TATA spare parts
264754660162	W/H MAIN SFC709 BS-II RHD W/CL	TATA spare parts
264754660163	W/H MAIN SFC709 BS-III RHD W/CL.	TATA spare parts
264754660165	W/H MAIN SFC709 BS-II W/CLST	TATA spare parts
264754660168	W/H TAIL SFC709 FE TRUCK/38WB	TATA spare parts
264754660178	WIRING HARNESS SIDE MARKER LAMP	TATA spare parts
264754660183	W/H PIG TAIL L.P.SWITCH SFC709	TATA spare parts
264754680101	W/H MAIN RHD CMVR2000 S'CAM	TATA spare parts
264754680102	W/H INST.CONSOLE	TATA spare parts
264754680103	W/H TAIL W/O LB 38WB	TATA spare parts
264754680105	WIRING HARNESS(HAND BRAKE SWITCH)	TATA spare parts

264754680106	W/H SIDE & END OUTLINE MARKER LAMP	TATA spare parts
264754680107	W/H TAIL RHD F.E.ENG./38WB	TATA spare parts
264754680108	W/H MAIN W/O ENG STOP RELAY	TATA spare parts
264754680109	W/H MAIN RHD BS-II W/MOT LEVEL	TATA spare parts
264754680110	W/H INST CONSL BS-II W/MOT LEVEL	TATA spare parts
264754680111	W/H MAIN W/INST.CLUSTER BS-II	TATA spare parts
264754680114	W/H MAIN SFC709 BS-II W/CLST	TATA spare parts
264754680117	W/H TAIL SFC709 FE TRUCK/38WB	TATA spare parts
264754690101	W/H MAIN SFC709 BS-II	TATA spare parts
264754690103	W/H TAIL SFC709 FE TRUCK/38WB	TATA spare parts
264754690112	W/H TAIL SFC709/38WB EX AD-MINDA	TATA spare parts
264758904215	KIT-TOOLS (ELECTRICAL SAFETY KIT)	TATA spare parts
2647600002R40	ASSEMBLY BODY FITTED	TATA spare parts
2647600003R40	ASSEMBLY BODY FITTED	TATA spare parts
26476000113R40	ASSY CABIN WITH PARTIAL FITMENT 710 SFC	TATA spare parts
26476013M10119	FRONT PANEL BS6-PH2	TATA spare parts
26476060M10115	BONNET ASSY SIDE INNER REAR-LH BS6-PH2	TATA spare parts
26476100M10134	SUBSTRUCTURE ASSY WITH FLOOR BS6-PH2	TATA spare parts
26476200M10152	FRONT WALL ASSY BS6-PH2	TATA spare parts
26476261M10110	FIREWALL PANEL ASSY BS6-PH2	TATA spare parts
264770160101	SUPD ASSY LH BS6-PH2	TATA spare parts
264770160102	SUPD ASSY RH BS6-PH2	TATA spare parts
264782400104	ASSY COVER (FOR WHEEL BOX CUT OUT)	TATA spare parts
264787309203	SPRING WASHER	TATA spare parts
264787309907	MALE CONNECTOR(1/8 IN)	TATA spare parts
26478810M10109	SIDE BONNET ASSY LH BS6-PH2	TATA spare parts
26478810M10110	SIDE BONNET ASSY RH BS6-PH2	TATA spare parts
2647A9Z0170001	LOADBODY FITTED ASSY MFG BS6-PH2	TATA spare parts
2647D9X0160001	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
2647D9Y0160001	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
2647D9Z0160001	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2647D9Z0160002	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2647D9Z0160003	FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2647H9X0233003	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
2647H9X0233005	FRONT AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
265035606501	NUT & LOCK	TATA spare parts
265115100102	STARTER MOTOR	TATA spare parts
265115100103	ALTERNATOR 12V/35A	TATA spare parts
265115100105	STARTER MOTOR -12V	TATA spare parts
265115100107	ALTERNATOR 12V/35A	TATA spare parts
265115100108	ALTERNATOR	TATA spare parts
265115100109	TERMINAL BASE	TATA spare parts
265115100115	DRIVE ASSY W/PINION	TATA spare parts
265115100116	CE BRACKET ASSY	TATA spare parts
265115100117	BRUSH CARRIER ASSY	TATA spare parts
265115100118	FIELD COIL ASSY	TATA spare parts
265115100119	STARTER 12V LP/LPT/SFC 709	TATA spare parts

265115100121	STARTER MOTOR -12V	TATA spare parts
265115100122	ALTERNATOR 12V 35A	TATA spare parts
265115100130	STARTER MOTOR BS1/2/3/4	TATA spare parts
265115100131	STARTER MOTOR -12V	TATA spare parts
265115100132	STARTER MOTOR -12V	TATA spare parts
265115100133	STARTER MOTOR -12V	TATA spare parts
265115100134	ALTERNATOR 12V 35A	TATA spare parts
265115100135	STARTER MOTOR -12V	TATA spare parts
265115100136	ALTERNATOR 12V 35A	TATA spare parts
265115100138	STARTER MOTOR M82 12V	TATA spare parts
265115100139	STARTER MOTOR (GEARED REDUCTION)	TATA spare parts
265115100140	STARTER MOTOR 24V 3KW	TATA spare parts
265115100141	ALTERNATOR 14V 120A 2GR PULLEY	TATA spare parts
265115101019	ARMATURE ASSY	TATA spare parts
265115103401	BEARING BUSH	TATA spare parts
265115103402	BUSH INTER BRACKET	TATA spare parts
265115104901	TERMINAL-SOLONOID	TATA spare parts
265115104902	SOLENOID SWITCH	TATA spare parts
265115104903	CONNECTOR SOLONOID	TATA spare parts
265115104904	EARTH TERMINAL KIT	TATA spare parts
265115104906	POLE SCREW	TATA spare parts
265115107801	OIL SEAL	TATA spare parts
265115109901	ARMATURE ASSEMBLY	TATA spare parts
265115109902	FIXING BRACKET ASSEMBLY	TATA spare parts
265115109903	C.E BRACKET ASSEMBLY	TATA spare parts
265115109904	INTER BRACKET ASSY STARTER MOTOR	TATA spare parts
265115109905	BRUSH SET _262 540 02_	TATA spare parts
265115109906	FIELD COIL ASSEMBLY	TATA spare parts
265115109907	SWITCH ASSEMBLY	TATA spare parts
265115109908	B. G ASSEMBLY	TATA spare parts
265115109909	ENGAGING LEVER ASSEMBLY	TATA spare parts
265115400105	ROTOR ASSY	TATA spare parts
265115400107	RECTIFIER ASSY	TATA spare parts
265115400131	ROTOR ASSY	TATA spare parts
265115400132	STATOR ASSY	TATA spare parts
265115400133	CAPACITOR ASSY	TATA spare parts
265115400134	RECTIFIER ASSY	TATA spare parts
265115400135	S R E BKT ASSY	TATA spare parts
265115400136	REGULATOR & BRUSH BOX ASSY	TATA spare parts
265115400137	D.E.BRACKET ASSY	TATA spare parts
265115400138	RECTIFIER ASSY	TATA spare parts
265115400149	ALTERNATOR_65A	TATA spare parts
265115403101	D E BALL BEARING	TATA spare parts
265115403102	BALL BEARING SRE	TATA spare parts
265115403103	D.E.BALL BEARING	TATA spare parts
265115403105	BALL&BEARING	TATA spare parts
265115404901	REGULATOR	TATA spare parts

265115404902	NUT POS.TERM.	TATA spare parts
265115404903	FUSE	TATA spare parts
265115404904	REGULATOR ALTERNATOR	TATA spare parts
265115404906	PROCTIVE CAP INTEGRATED WITH BUS BAR	TATA spare parts
265115406501	FIXING BOLT	TATA spare parts
265115406502	STUD	TATA spare parts
265115406504	NUT	TATA spare parts
265115406505	CUP WASHER	TATA spare parts
265115406518	FLANGE_NUT_K165A¿ALT_BOSCH(F002G91320)	TATA spare parts
265115407004	PULLY	TATA spare parts
265115407006	PULLEY	TATA spare parts
265115407801	O RING	TATA spare parts
265115407901	ROTOR ALTERNATOR	TATA spare parts
265115408201	FAN	TATA spare parts
265115408602	SPACING COLLAR	TATA spare parts
265115408603	COLLAR	TATA spare parts
265115409901	SLIP RING	TATA spare parts
265115409903	INSERT(TOP) D.E.	TATA spare parts
265115409904	INSERT (BOTTOM)	TATA spare parts
265115409907	INSUL BUSH.	TATA spare parts
265115409908	COVER MOULDING	TATA spare parts
265115409909	INSULATOR BUSH	TATA spare parts
265115409910	BRUSH SET	TATA spare parts
265115409911	INSERT SRE	TATA spare parts
265115409912	INSERT (TOP) D.E.	TATA spare parts
265115409918	DRIVE¿END¿SHIELD_12V_65A_MICO_K1.	TATA spare parts
265115409920	COVER¿PLATE¿ALTERNATOR¿12V¿65A¿MICO¿K1	TATA spare parts
265115409921	COUNTERSUNK¿HEAD¿SCREW¿12V¿65A¿MICO¿K1	TATA spare parts
265115409923	SPACER¿RING¿FOR¿12V¿65A¿ALTERNATOR¿K1.	TATA spare parts
265115409926	RECTIFIER¿FOR¿12V¿65A¿MICO¿K1¿ALTERNATO	TATA spare parts
265115409928	STATOR FOR 12V 65A ALTERNATOR	TATA spare parts
265115409929	CHEES¿HEAD¿SCREW	TATA spare parts
265115409933	FAN¿FOR¿12V¿65A¿MICO¿K1¿ALTERNATOR	TATA spare parts
265115409936	SLIP¿RING¿END¿SHIELD	TATA spare parts
265115409937	STATOR	TATA spare parts
265116100102	CONTAINER 497SPTC (SFC410EX 7.5X16PR)	TATA spare parts
265116100103	CONTAINER 497SPTC (SFC410EX 8.25X16PR)	TATA spare parts
265116100107	ASSY.CONTAINER FOR 497SP-NA-CNG ENGINE	TATA spare parts
265116100113	CONTAINER 497SPTC (SFC410 2750WB PICKUP)	TATA spare parts
265116100115	ASSY CONTAINER SFC407EX/31WB BS-III TWIN	TATA spare parts
265116100116	ASSY CONTAINER SFC407EX/31WB BS-III FES	TATA spare parts
265116100117	CONTAINER 497CNG NA (SFC407CNG/31WB)	TATA spare parts
265116100118	CONTAINER 4SP (SFC 407 / 2750WB PICKUP)	TATA spare parts
265116100119	ASSY CONTAINER SFC407 BS-III/31WB TRUCK	TATA spare parts
265116100120	ASSY. CONTAINER SFC410/31 WB	TATA spare parts
265124100106	ENGINE MTG PAD FRT LH	TATA spare parts
265124100110	ENGINE MTG PAD FRT RH	TATA spare parts

265124100113	KIT-ENGINE MTG PAD BS2/3/4	TATA spare parts
265124103501	BOSS	TATA spare parts
265124109201	TAB WASHER	TATA spare parts
265124200101	ASSY. SUPPORT	TATA spare parts
265124200102	ENGINE MOUNTING REAR BS2/3/4	TATA spare parts
265124208204	OIL BAFFLE	TATA spare parts
265124209201	WASHER	TATA spare parts
265125000101	SET CL DISC & CL PR PLATE	TATA spare parts
265125000102	SET OF CL DISC & PR	TATA spare parts
265125200101	CLUTCH DISC 240 DIA	TATA spare parts
265125200106	ASSY.240 DIA.CLUTCH DISC	TATA spare parts
265125200108	REP KIT CLUTCH DISC 240D	TATA spare parts
265125200109	CLUTCH DISC 240 DIA	TATA spare parts
265125200110	ASSY 240DIA CLUTCH DISC	TATA spare parts
265125200112	ASSY CLUTCH DISC 240 DIA	TATA spare parts
265125200115	ASSY.240 DIA.CLUTCH DISC	TATA spare parts
265125200116	ASSY.240 DIA.CL.DISC	TATA spare parts
265125200117	ASSY.240 DIA.CL.DISC	TATA spare parts
265125200121	ASSY.240 DIA.CL.DISC	TATA spare parts
265125200125	CLUTCH DISC ASSY 240 DIA HIGH CAPACITY	TATA spare parts
265125200126	ASSY.240 DIA.CLUTCH DISC	TATA spare parts
265125200129	CLUTCH DISC ASSY 240 DIA HIGH CAPACITY	TATA spare parts
265125200132	CLUTCH DISC 240 DIA. 407 TUBRO	TATA spare parts
265125200136	CLUTCH DISC 240 DIA.(F510) BS2/3/4	TATA spare parts
265125200137	ASSY 240 DIA.CL.DISC (F510)-CA-HIGH TORQ	TATA spare parts
265125200240DF	CLUTCH FACING 240 DIA ORG-4MM	TATA spare parts
265125200240DFWR	CLUTCH FACING 240 DIA ORG-4MM W/RIVETS	TATA spare parts
265125206301	CLUTCH LINING 4.0MM	TATA spare parts
265125206305	CLUTCH LINING	TATA spare parts
265125206313	CL LINING 4.6MM	TATA spare parts
265125206314	CL LINING 3.4MM	TATA spare parts
265125207403	RIVET CL LINING	TATA spare parts
265125207404	RIVET-DISC TO CARRIER PLATE	TATA spare parts
265125400101	CL PR PLATE 240 DIA	TATA spare parts
265125400104	REP KIT CL PR PLATE MJR	TATA spare parts
265125400105	REP KIT CL PR PLATE MNR	TATA spare parts
265125400106	CL. PRESS. PLATE 240 DIA	TATA spare parts
265125400108	ASSY. 240DIA. PRESSURE PLATE FOR 4SP	TATA spare parts
265125400109	REP KIT CL PR PLATE MAJOR	TATA spare parts
265125400110	REP KIT CL PR PLATE MNR	TATA spare parts
265125400111	ASSY.240 DIA.PRESSUER PLATE _F&S	TATA spare parts
265125400112	CL PR PLATE 240 DIA	TATA spare parts
265125400113	CLUTCH COVER 240 DIA. BS2/3/4	TATA spare parts
265125400114	CLUTCH COVER 407 TUBRO 240 DIA	TATA spare parts
265125400115	CL PR PLATE 240 DIA	TATA spare parts
265125400116	240 DIA. CLUTCH COVER ASSY.(HIGH CAPACIT	TATA spare parts
265125408702	STRAP	TATA spare parts

265125408703	DIPHRAGM SPRING 2.85 THK	TATA spare parts
265125600105	BRACKET OUTSIDE	TATA spare parts
265125600106	BEARING OUTER RACE	TATA spare parts
265125600107	CL REL FORK W/BALL PIN	TATA spare parts
265125600108	CLUTCH RELEASE BRG	TATA spare parts
265125600111	BRACKET OUTSIDE	TATA spare parts
265125600113	CLUTCH RELS.BRG. SELF-CENTERING	TATA spare parts
265125603101	CLUTCH RELEASE BEARING	TATA spare parts
265125603102	BEARING OUTER RACE	TATA spare parts
265125603103	CLUTCH RELEASE BEARING.	TATA spare parts
265125603105	BEARING	TATA spare parts
265125603106	CLUTCH RELEASE BEARING.	TATA spare parts
265125603107	CLUTCH RELEASE BEARING.	TATA spare parts
265125604301	SPRING RING	TATA spare parts
265125605103	CL.RELEASE FORK	TATA spare parts
265125607702	RUBBER BELLOW	TATA spare parts
265125608202	BRACKET INSIDE	TATA spare parts
265126400106	ASSY LEVER RHD	TATA spare parts
265126407102	BRACKET	TATA spare parts
265126408201	COVER PLATE	TATA spare parts
265129100102	ASSY BRACKET	TATA spare parts
265129100112	ASSY.CONTROL MTG.BRKT	TATA spare parts
265129100118	CLUTCH MASTER CYL. 19.05 DIA. BS1/2/3/4	TATA spare parts
265129100122	CL MASTER CYL	TATA spare parts
265129100123	CL SLAVE CYL	TATA spare parts
265129100124	TUBE ASSY	TATA spare parts
265129100125	ASSY.CLUTCH HOSE	TATA spare parts
265129100129	PEDAL LEVER BRAKE	TATA spare parts
265129100130	HOSE ASSY	TATA spare parts
265129100131	PEDAL LEVER CLUTCH	TATA spare parts
265129100132	REP KIT SLAVE CYL MNR	TATA spare parts
265129100135	REP KIT MASTER CYL MNR	TATA spare parts
265129100136	REPAIR KIT (MAJOR) FOR CMC (19.05 MM DIA	TATA spare parts
265129100137	REP KIT SLAVE CYL MJR	TATA spare parts
265129100138	TUBE ASSY	TATA spare parts
265129100144	BR FLUID CONTAINER	TATA spare parts
265129100147	FILLER CAP FL CONTAINER	TATA spare parts
265129100148	REP KIT MASTER CYL MNR	TATA spare parts
265129100153	PEDAL BRAKE/CLUTCH	TATA spare parts
265129100156	PEDAL LEVER W/RUB COVER	TATA spare parts
265129100157	CLUTCH PEDAL W/RUB COVER	TATA spare parts
265129100159	CL MASTER CYL 19D	TATA spare parts
265129100160	CLUTCH SLAVE CYL. 25.4 DIA.	TATA spare parts
265129100161	CL SLAVE CYL 25.4D	TATA spare parts
265129100162	REP KIT SLAVE CYL 25.40D	TATA spare parts
265129100164	REP KIT SLAVE CYL 25.40D	TATA spare parts
265129100167	CLUTCH SLAVE CYLINDER 25.4 DIA. BS2/3/4	TATA spare parts



265129100170	CLUTCH SLAVE CYL. 25.4 DIA.	TATA spare parts
265129100171	CL MASTER CYL 19.05D	TATA spare parts
265129100172	CL MASTER CYL 19.5D	TATA spare parts
265129100173	CLUTCH SLAVE CYL. 25.4 DIA.	TATA spare parts
265129100174	ASSY TUBE 60.0*1.6THICK	TATA spare parts
265129100177	TUBE 60.DX0.7THK.	TATA spare parts
265129100179	ASSY CLUTCH PEDAL	TATA spare parts
265129100181	ASSY.PEDAL LEVER WITH RUBBER COVER	TATA spare parts
265129100184	ASSY.CLUTCH PEDAL WITH RUBBER COVER	TATA spare parts
265129100188	ASSY. TUBE.	TATA spare parts
265129100189	ASSY BRAKE PEDAL	TATA spare parts
265129100190	ASSLY CLUTCH PIPE(FROM MASTER CYL.)	TATA spare parts
265129100191	CLUTCH MASTER CYL. 19.05 DIA.	TATA spare parts
265129100193	ASSY. REINFORCEMENT	TATA spare parts
265129100199	ASSY. BRAKE PEDAL (KAIZEN)	TATA spare parts
265129100604	PLUNGER FOR CMC	TATA spare parts
265129103401	SINTERED BUSH	TATA spare parts
265129103402	SLEEVE	TATA spare parts
265129106004	FORK HEAD	TATA spare parts
265129106303	CAP CL FLUID CONTAINER	TATA spare parts
265129106306	PIVOT BUSH	TATA spare parts
265129106307	BUSH	TATA spare parts
265129106602	PLUNGER	TATA spare parts
265129106604	PISTON	TATA spare parts
265129106606	PLUNGER	TATA spare parts
265129106701	PIN ADJUSTING ECCENTRIC	TATA spare parts
265129107703	RUBBER COVER	TATA spare parts
265129107707	FOAM SEALING	TATA spare parts
265129107709	RUBBER SEAL	TATA spare parts
265129107711	RUBBER BELLOW	TATA spare parts
265129107715	SEAL	TATA spare parts
265129107717	RUBBER GROMMET	TATA spare parts
265129107730	SEALING FOAM (MASTER CYLINDER MTG.)	TATA spare parts
265129108001	BLEEDER SCREW	TATA spare parts
265129108229	BRACEKT BRAKE LIGHT SWITCH MTG.	TATA spare parts
265129108602	SPACER	TATA spare parts
265129108603	SPACER BS6	TATA spare parts
265129108702	SPRING	TATA spare parts
265129108703	SPRING	TATA spare parts
265129108704	SPRING	TATA spare parts
265129200124	BRACKET	TATA spare parts
265129200130	ASSY. CLUTCH PEDAL	TATA spare parts
265129200135	ASSY. BRAKE PRDAL	TATA spare parts
265129300101	ASSY BRACKET SLAVE CYL MNTG	TATA spare parts
265129308702	RETURN SPRING	TATA spare parts
265129400102	THRUST ROD	TATA spare parts
265129400103	BRACKET SLAVE CYL	TATA spare parts

265129400107	BRACKET-SLAVE CYL MTG SFC407	TATA spare parts
265129400108	ASSY SLAVE CYLINDER MOUNTING BRACKET	TATA spare parts
265129408002	PEDAL STOPPER	TATA spare parts
265130100103	ASSY PULL ROD	TATA spare parts
265130100104	BRACKET ASSY	TATA spare parts
265130100106	ASSY ACCELERATOR PEDAL	TATA spare parts
265130100111	LEVER ASSY	TATA spare parts
265130100112	PULL ROD ASSY	TATA spare parts
265130100122	PULL ROD ASSY	TATA spare parts
265130100126	ASSY PUSH ROD	TATA spare parts
265130100130	ACCEL LEVER	TATA spare parts
265130100131	ACCL PEDAL W/COVER RHD	TATA spare parts
265130100132	ASSY ACCEL PEDAL W/RUBBER	TATA spare parts
265130100142	ASSY.LEVER	TATA spare parts
265130100145	ASSY. ACCELERATOR CABLE	TATA spare parts
265130100146	ASSY.ACCL.PEDAL	TATA spare parts
265130100147	ASSY PULL CABLE ACCELERATOR 1622MM	TATA spare parts
265130100149	ASSY. ACCL. PEDAL	TATA spare parts
265130100150	ASSY PULL CABLE ACCELERATOR	TATA spare parts
265130100151	ASSY PULL CABLE ACCELERATOR	TATA spare parts
265130100153	ASSY PULL CABLE ACCELERATOR	TATA spare parts
265130100155	ASSY ACCL.CABLE 1622MM	TATA spare parts
265130100156	ASSY. PULL CABLE ACCEL. 1622MM BS2/3/4	TATA spare parts
26513010015720	SUB ASSY ACCL PEDAL COMP WITH BKT	TATA spare parts
265130100161	ACCELERATOR LEVER ASSY	TATA spare parts
265130100162	ACCELERATOR CABLE ASSY	TATA spare parts
265130100163	ACC PEDAL ASSY WITH BRACKET & SPRING	TATA spare parts
265130103103	SPHERICAL SUPPORT	TATA spare parts
265130106301	RUBBER COVER ACCL PEDAL	TATA spare parts
265130106303	RUBBER COVER ACCL PEDAL	TATA spare parts
265130108203	BRACKET	TATA spare parts
265130108204	ACCELERATOR BKT OUTER	TATA spare parts
265130108205	ACCL BRACKET OUTER-PAINTED	TATA spare parts
265130108208	SHIM 0.5 THK	TATA spare parts
265130108209	SHIM 1.0 THK	TATA spare parts
265130108210	SHIM 2.0 THK	TATA spare parts
265130108232	BRACKET ACCELERATOR PEDAL MTG.	TATA spare parts
265130108238	BRACKET (ACCELERATOR PEDAL MTG.)	TATA spare parts
265130108239	BRACKET (ACCELERATOR PEDAL MTG.)	TATA spare parts
265131000103	FRAME ASSY RHD/31 TRUCK	TATA spare parts
265131000104	FRAME ASSY RHD/27 TRUCK	TATA spare parts
265131000105	FRAME ASSY RHD/31 BUS	TATA spare parts
265131000106	ASSY FRAME 2750 W.B.BUS RHD	TATA spare parts
265131000112	ASSY FRAME 407 SFC TURBO 31 WB TRUCK	TATA spare parts
265131000117	ASSY.FRAME(3100 W.B.TRUCK LHD)	TATA spare parts
265131000138	ASSY FRAME RHD 407/31 COWL WITHOUT CLEAT	TATA spare parts
265131000146	ASSY.FRAME SFC-407/31 WITH TWIN TYRE	TATA spare parts

265131000150	ASSY FRAME -SFC407 W/O COWL-W/O FACE	TATA spare parts
265131000151	ASSY.FRAME	TATA spare parts
265131000171	ASSY FRAME SFC410EX/31 BS-III	TATA spare parts
265131000172	ASSY. FRAME SFC 407 CNG	TATA spare parts
265131000173	ASSY. FRAME TRUCK BS-II W/O CLEATS	TATA spare parts
265131000174	ASSY. FRAME RHD BUS (BS-II)	TATA spare parts
265131000175	ASSY FRAME RHD TRUCK WITH CLEATS BS-II	TATA spare parts
265131000176	ASSY. FRAME SFC407 TT WITH CLEATS -BS-II	TATA spare parts
265131000177	FRAME ASSY WITH FITMENT	TATA spare parts
265131000181	ASSY. FRAME (407/31 CITY RIDE)	TATA spare parts
265131000184	ASSY.FRAME SFC410EX/31WB TWIN TYRE	TATA spare parts
265131000185	ASSY. FRAME FACELESS 410EX BS-III/31WB	TATA spare parts
265131000186	ASSY FRAME SFC 407 CNG WITH RUPD	TATA spare parts
265131000188	ASSY FRAME SFC410EX/31(BS-III)-W/O CLEAT	TATA spare parts
265131000190	ASSY.FRAME SFC410EX BS-III -TRUCK	TATA spare parts
265131000191	ASSY FRAME SFC 407 TT BS-II W/O CLEAT	TATA spare parts
265131000197	ASSY. FRAME SK 407 BS2/3	TATA spare parts
265131108207	REINF RR CAB MTG	TATA spare parts
265131108208	BRACKET	TATA spare parts
265131207104	SUPPORT-RH (CROSS MEMBER REAR)	TATA spare parts
265131207105	SUPPORT-LH (CROSS MEMBER REAR)	TATA spare parts
265131207107	SUPPORT PLATE	TATA spare parts
265131400101	ASSY.CROSS MEMBER(REAR SPRING FRONT)	TATA spare parts
265131400108	FR CROSS MEMBER W/HOOK	TATA spare parts
265131400112	ASSY REAR AXLE STOPPER	TATA spare parts
265131400122	CROSS MEMBER RR SPG FRT	TATA spare parts
265131400128	CROSS MEMBER CENTRE BRG	TATA spare parts
265131400130	REAR X MEMBER	TATA spare parts
265131400133	ASSY FLANGE BS6	TATA spare parts
265131400135	BRACKET ASSY	TATA spare parts
265131400136	ASSY CLEAT	TATA spare parts
265131400137	CROSS MEMBER RR SPG RR	TATA spare parts
265131400138	ASSY SHOCK ABSB & CAB MTG BKT FRT LH	TATA spare parts
265131400139	ASSY SHOCK ABSB & CAB MTG BKT FRT RH	TATA spare parts
265131400140	CROSS MEMBER GB MTG	TATA spare parts
265131400141	BRACKET RR AXLE STOPPER	TATA spare parts
265131400142	ASSY. CROSS MEMBER (ENG.MTG.REAR)	TATA spare parts
265131400145	ASSY.STUD	TATA spare parts
265131400148	ASSY.REINFORCEMENT RH	TATA spare parts
265131400149	ASSY.REINFORCEMENT-LH	TATA spare parts
265131400150	ASSY.BOXING PLATE WITH ENG.MTG.BKT.(RH)	TATA spare parts
265131400151	ASSY.BOXING PLATE WITH ENG.MTG.BKT.(LH)	TATA spare parts
265131400153	ASSY.CROSS MEMBER (REAR SPR.FRONT)	TATA spare parts
265131400163	ASSY CROSS MEMBER (REAR SPRING FRT-RHD)	TATA spare parts
265131400165	ASSY SPARE WHEEL CROSS MEMBER	TATA spare parts
265131400166	ASSY CROSS MEMBER-RHD REAR SPR.FRT	TATA spare parts
265131400167	ASSY.CROSS MEMBER-LHD(REAR SPR.FRT)	TATA spare parts

265131400171	ASSY.CENTRE BRG.CROSS MEMBER-FOR RHD	TATA spare parts
265131400172	ASSY.CENTRE BRG.CROSS MEMBER-FOR LHD	TATA spare parts
265131400176	CROSS MEMBER- SPARE WHEEL MOUNTING	TATA spare parts
265131400178	ASSY REINFORCEMENT -RH (FRT SHOC ABS)	TATA spare parts
265131400179	ASSY REINFORCEMENT -LH	TATA spare parts
265131400187	ASSY. REAR SPRING REAR CROSS MEMBER	TATA spare parts
265131400188	ASSY.CENTRE BRG.CROSS MEMBER (TRUCK)	TATA spare parts
265131400189	ASSY.CENTRE BRG.CROSS MEMBER (BUS)	TATA spare parts
265131400190	ASSY. CROSS MEMBER REAR SPRING FRONT	TATA spare parts
265131400191	ASSY.REINFORCEMENT-RH (REAR)	TATA spare parts
265131400192	ASSY.REINFORCEMENT-LH (REAR)	TATA spare parts
265131400194	ASSY CROSS MEMBER (CENTRE BEARING MTG.)	TATA spare parts
265131400195	ASSY CROSS MEMBER CENTRE BEARING	TATA spare parts
265131400196	ASSY.CROSS MEMBER REAR SPRING FRONT	TATA spare parts
265131400199	ASSY.CROSS MEMBER SPARE WHEEL MTG.	TATA spare parts
265131404401	RUBBER BUFFER	TATA spare parts
265131406701	PIN	TATA spare parts
265131406702	PIN	TATA spare parts
265131407701	RUBBER BUFFER	TATA spare parts
265131408208	BKT CROSS MEMBER MTG RR	TATA spare parts
265131408221	REINFORCEMENT RH	TATA spare parts
265131408222	REINFORCEMENT LH	TATA spare parts
265131408231	GUARD	TATA spare parts
265131408238	REINFORCEMENT - RH	TATA spare parts
265131408239	REINFORCEMENT (LH)	TATA spare parts
265131408252	END CROS MEMBER	TATA spare parts
265131408260	GUSSET RH	TATA spare parts
265131408261	GUSSET LH	TATA spare parts
265131408266	SUPPORT GR BOX MTG	TATA spare parts
265131408267	CROSS MEMBER GB MTG	TATA spare parts
265131408292	BRACKET REINFORCEMENT RH	TATA spare parts
265131408293	BRACKET REINFORCEMENT LH	TATA spare parts
265131409201	SPHERICAL WASHER	TATA spare parts
265131410108	ASSY. C / M REAR SPRING FRONT	TATA spare parts
265131410111	ASSY. CENTER BEARING CROSS MEMBER	TATA spare parts
265131418204	CROSS MEMBER-FRONT	TATA spare parts
265131700117	ASSY TUBE-RUPD	TATA spare parts
265132100111	FRONT SPRING NOR CAMBER	TATA spare parts
265132100113	BKT FRT SPRING W/BUSH RR	TATA spare parts
265132100118	SPRING SHACKLE	TATA spare parts
265132100123	BKT LH FRONT SPRING	TATA spare parts
265132100124	BKT RH FRONT SPRING	TATA spare parts
265132100126	LEAF SPRING 1ST W/BUSH	TATA spare parts
265132100127	LEAF SPRING 1ST W/BUSH	TATA spare parts
265132100128	FRONT SPRING SOFT BUS	TATA spare parts
265132100130	FRONT SPRING ASSY	TATA spare parts
265132100131	LEAF SPRING 1ST W/BUSH	TATA spare parts

265132100132	ASY.SPRING PIN KIT FOR FRONT SPRG.	TATA spare parts
265132100133	SHACKLE FRT SPRING	TATA spare parts
265132100135	LEAF SPRING 1ST W/BUSH	TATA spare parts
265132100136	ASSY.FRONT SPRING	TATA spare parts
265132100137	FIRST LEAF W/BUSH FOR0136	TATA spare parts
265132100146	ASSY. SHACKLE-FRONT SPRING	TATA spare parts
265132100162	ASSY. FRONT SPRING	TATA spare parts
265132100163	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
26513210016420	SUB ASSY RUBBER BUFFER WITH GUIDE PLATE	TATA spare parts
26513210016720	SUBASSY GUIDE PLATE WITH RUBBER LH	TATA spare parts
265132100168	ASSY. FRONT SPRING.	TATA spare parts
265132104209	SPRING CLIP	TATA spare parts
265132104210	SPRING CLIP	TATA spare parts
265132104211	LOCK PLATE	TATA spare parts
265132106701	SPRING PIN FRT	TATA spare parts
265132106704	SPRING PIN SHACKLE END BS1/2/3/4/6	TATA spare parts
265132107105	LEAF SPRING 5TH FRT	TATA spare parts
265132107111	LEAF SPRING 3RD FRT	TATA spare parts
265132107112	LEAF SPRING 4TH FRT	TATA spare parts
265132107113	LEAF SPRING 5TH FRT	TATA spare parts
265132107114	LEAF SPRING 6TH FRT	TATA spare parts
265132107115	LEAF SPRING 7TH FRT	TATA spare parts
265132107116	LEAF SPRING 8TH FRT	TATA spare parts
265132107117	LEAF SPRING 9TH FRT	TATA spare parts
265132107119	LEAF SPRING 2ND FRT	TATA spare parts
265132107129	LEAF SPRING 3RD FRT	TATA spare parts
265132107130	LEAF SPRING 4TH FRT	TATA spare parts
265132107137	SPRING SHACKLE	TATA spare parts
265132107139	PLATE	TATA spare parts
265132107144	FRT.SPRING 4TH LEAF	TATA spare parts
265132107148	SPACER PLATE.	TATA spare parts
265132107150	LEAF SPRING 3RD FRT	TATA spare parts
265132107151	LEAF SPRING 2ND FRT	TATA spare parts
265132107154	LEAF SPRING 2ND FRT	TATA spare parts
265132107155	THIRD LEAF	TATA spare parts
265132107173	LOCK PLATE (FRT. SPRING)	TATA spare parts
265132117124	SECOND LEAF	TATA spare parts
265132117125	THIRD LEAF	TATA spare parts
265132117126	FOURTH LEAF	TATA spare parts
265132117127	FIFTH LEAF	TATA spare parts
265132117128	SIXTH LEAF	TATA spare parts
265132117129	SEVENTH LEAF	TATA spare parts
265132117130	EIGHTH LEAF	TATA spare parts
265132117131	NINTH LEAF	TATA spare parts
265132200101	GUIDE PLATE FRT SPRING	TATA spare parts
265132200102	BUMP STOPPER ASSY	TATA spare parts
265132203705	CASTER PLATE (FOR FRONT SPRING)	TATA spare parts

265132204201	U CLAMP FRONT	TATA spare parts
265132204203	U CLAMP FRONT	TATA spare parts
265132204204	U CLAMP	TATA spare parts
265132204205	U CLAMP FRONT	TATA spare parts
265132204206	U-CLAMP FRONT	TATA spare parts
265132204207	U CLAMP FRONT	TATA spare parts
265132207101	CASTER PLATE	TATA spare parts
265132207704	RUBBER BUFFER FRT SPRING	TATA spare parts
265132208201	GUIDE PLATE	TATA spare parts
265132300103	SHOCK ABSORBER FRONT	TATA spare parts
265132300105	SHOCK ABSORBER FRONT	TATA spare parts
265132300106	SHOCK ABSORBER FRONT	TATA spare parts
265132300108	BKT S/ABS & CAB FRT LH	TATA spare parts
265132300109	BKT S/ABS & CAB FRT RH	TATA spare parts
265132300111	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
265132300114	ASSY BRACKET	TATA spare parts
265132300117	SHOCK ABSORBER-FRONT	TATA spare parts
265132300118	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
265132300124	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
265132300125	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
265132300126	ASSY BRACKET FRT SHOCK ABS & CAB MTG -LH	TATA spare parts
265132300127	ASSY BRACKET LH - CAB & S/A MTG	TATA spare parts
265132300129	ASSY BRACKET RH - CAB & S/A MTG	TATA spare parts
265132300130	ASSY. BRACKET - LH-FRT. S/A & CAB MTG.	TATA spare parts
265132300134	ASSY SHOCK ABSORBER CUM CAB MTG. BKT. FR	TATA spare parts
265132300135	ASSY. BRACKET - FRONT SHOCK ABSORBER & C	TATA spare parts
265132305104	BRACKET BOTTOM FRT SH ABSB	TATA spare parts
265132305107	BKT S/ASB BOTTOM FRT	TATA spare parts
265132305108	BRACKET BOTTOM (FR S/A)	TATA spare parts
265132306702	PIN (FRONT SHOCK ABS.BRACKET TOP) BS6	TATA spare parts
265132306902	SLEEVE	TATA spare parts
265132307105	WASHER	TATA spare parts
265132307702	RUB BUSH S/ABS	TATA spare parts
265132308201	WASHER	TATA spare parts
265132308601	BUSH	TATA spare parts
265132400126	SEALING RING	TATA spare parts
265132400128	REAR SPRING ASSY	TATA spare parts
265132400129	LEAF SPRING 1ST W/BUSH RR	TATA spare parts
265132400130	BKT LH REAR SPRING FRT	TATA spare parts
265132400132	BKT RH REAR SPRING FRT	TATA spare parts
265132400133	ASSY. REAR SPRING BRACKET FRONT-LH	TATA spare parts
265132400134	ASSY. REAR SPRING BRACKET FRONT-RH	TATA spare parts
265132400136	BKT LH REAR SPRING RR	TATA spare parts
265132400137	BKT LH REAR SPRING RR	TATA spare parts
265132400138	SPRING SHACKLE RR SPRING	TATA spare parts
265132400139	ASSY. REAR SPRING BRACKET FRONT -LH	TATA spare parts
265132400140	ASSY REAR SPRING BRACKET FRONT RH	TATA spare parts

265132400141	ASSY.REAR SPG BRACKET - REAR LH	TATA spare parts
265132400142	ASSY.REAR SPG BRACKET - REAR RH	TATA spare parts
265132400143	LEAF SPRING 1ST W/BUSH RR	TATA spare parts
265132400145	REAR SPRING ASSY	TATA spare parts
265132400147	ASSY. REAR SPRING.	TATA spare parts
265132400148	LEAF SPRING 1ST RR	TATA spare parts
265132400151	REAR SPRING ASSY	TATA spare parts
265132400152	REAR SPRING ASSY	TATA spare parts
265132400153	LEAF SPRING 1ST W/BUSH RR	TATA spare parts
265132400155	ASSY.REAR SPG.BRACKET COMP.LH REAR	TATA spare parts
265132400156	ASSY.REAR SPG.BRACKET COMP.RH REAR	TATA spare parts
265132400157	SPRING SHACKLE RR SPRING	TATA spare parts
265132400160	ASSY. REAR SPRING	TATA spare parts
265132400164	BKT LH RR SPRING W/BUSH	TATA spare parts
265132400165	BKT RH RR SPRING W/BUSH	TATA spare parts
265132400166	ASSY. SPRING HANGER BRKT REAR RWD LH	TATA spare parts
265132400167	ASSY. SPRING HANGER BRKT REAR RWD RH	TATA spare parts
265132400183	ASSY. SHACKLE-REAR SPRING	TATA spare parts
265132400185	ASSY. REAR SPRING	TATA spare parts
265132400187	ASSY. REAR SPRING	TATA spare parts
265132400192	ASSY. REAR SPRING	TATA spare parts
265132400194	ASSY. REAR SPRING	TATA spare parts
265132400196	ASSY. REAR SPRING	TATA spare parts
265132403401	BUSH BS1/2/3/4/6	TATA spare parts
265132403401DF	SPRING BUSH FRONT & REAR	TATA spare parts
265132404202	SPRING CLIP	TATA spare parts
265132404206	SPRING CLIP	TATA spare parts
265132404207	SPRING CLIP	TATA spare parts
265132404209	SPRING CLIP	TATA spare parts
265132404211	SPRING CLIP	TATA spare parts
265132404212	SPRING CLIP	TATA spare parts
265132404214	SPRING CLIP	TATA spare parts
265132404215	SPRING CLIP	TATA spare parts
265132404216	SPRING CLIP	TATA spare parts
265132404217	SPRING CLIP	TATA spare parts
265132404219	SPRING CLIP	TATA spare parts
265132404220	SPRING CLIP	TATA spare parts
265132404221	SPRING CLIP	TATA spare parts
265132404222	SPRING CLIP	TATA spare parts
265132404225	SPRING CLIP (NORMAL CAMBER)	TATA spare parts
265132404226	SPRING CLIP	TATA spare parts
265132404227	SPRING CLIP	TATA spare parts
265132404228	SPRING CLIP (HIGHER CAMBER)	TATA spare parts
265132404229	SPRING CLIP	TATA spare parts
265132404230	SPRING CLIP	TATA spare parts
265132407119	LEAF SPRING	TATA spare parts
265132407130	LEAF SPRING 2ND RR	TATA spare parts

265132407131	LEAF SPRING 3RD RR	TATA spare parts
265132407132	LEAF SPRING 4TH RR	TATA spare parts
265132407133	LEAF SPRING 5TH RR	TATA spare parts
265132407134	LEAF SPRING 6TH RR	TATA spare parts
265132407135	LEAF SPRING 7TH RR	TATA spare parts
265132407136	LEAF SPRING 8TH RR	TATA spare parts
265132407137	LEAF SPRING 9TH RR	TATA spare parts
265132407138	LEAF SPRING 10TH RR	TATA spare parts
265132407148	LEAF SPRING 2ND RR	TATA spare parts
265132407149	LEAF SPRING 3RD RR	TATA spare parts
265132407150	LEAF SPRING 4TH RR	TATA spare parts
265132407151	LEAF SPRING 5TH RR	TATA spare parts
265132407161	SIXTH LEAF	TATA spare parts
265132407164	LEAF SPRING 2ND REAR	TATA spare parts
265132407165	LEAF SPRING 3RD REAR	TATA spare parts
265132407166	LEAF SPRING 4TH REAR	TATA spare parts
265132407167	LEAF SPRING 5TH REAR	TATA spare parts
265132407168	LEAF SPRING 6TH REAR	TATA spare parts
265132407169	LEAF SPRING 7TH REAR	TATA spare parts
265132407170	LEAF SPRING 8TH REAR	TATA spare parts
265132407171	LEAF SPRING 9TH REAR	TATA spare parts
265132407175	LEAF SPRING 3RD RR	TATA spare parts
265132407176	LEAF SPRING 4TH RR	TATA spare parts
265132407177	FIFTH LEAF	TATA spare parts
265132407182	REAR SPRING 2ND LEAF	TATA spare parts
265132407183	REAR SPRING 3RD LEAF	TATA spare parts
265132407184	FOURTH LEAF	TATA spare parts
265132407185	FIFTH LEAF	TATA spare parts
265132407186	SIXTH LEAF	TATA spare parts
265132407187	SEVENTH LEAF	TATA spare parts
265132407188	EIGHTH LEAF	TATA spare parts
265132407189	NINETH LEAF	TATA spare parts
265132407190	TENTH LEAF	TATA spare parts
265132407191	ELEVENTH LEAF	TATA spare parts
265132407193	LOCK PLATE	TATA spare parts
265132407199	LOCK PLATE REAR SPRING	TATA spare parts
265132407701	SEALING RING	TATA spare parts
265132408604	SPACER BS6	TATA spare parts
265132410103	REAR SPRING ASSY SFC407TWINTYRE	TATA spare parts
265132410104	ASSY FIRST LEAF WITH BUSH	TATA spare parts
265132410105	ASSY. BRACKET REAR AXLE STOPPER	TATA spare parts
265132410108	ASSY. REAR SPRING	TATA spare parts
265132410109	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
265132410121	ASSY. REAR SPRING 407 MINI	TATA spare parts
265132417193	SECOND LEAF	TATA spare parts
265132417194	THIRD LEAF	TATA spare parts
265132417195	FOURTH LEAF	TATA spare parts



265132417196	FIFTH LEAF	TATA spare parts
265132417197	SIXTH LEAF	TATA spare parts
265132417198	SEVENTH LEAF	TATA spare parts
265132417199	EIGHTH LEAF	TATA spare parts
265132420101	ASSY REAR LEAF SPRING	TATA spare parts
265132420102	ASSY FIRST LEAF WITH BUSH	TATA spare parts
265132427161	SECOND LEAF	TATA spare parts
265132427162	THIRD LEAF	TATA spare parts
265132427163	FOURTH LEAF	TATA spare parts
265132427164	FIFTH LEAF	TATA spare parts
265132427165	SIXTH LEAF	TATA spare parts
265132427166	SEVENTH LEAF	TATA spare parts
265132427167	EIGHTH LEAF	TATA spare parts
265132427168	NINTH LEAF	TATA spare parts
265132503701	GUIDE PLATE RR SPG	TATA spare parts
265132504204	U CLAMP REAR	TATA spare parts
265132504205	U CLAMP REAR	TATA spare parts
265132504207	U CLAMP REAR	TATA spare parts
265132508201	SPACER RR SPRING U BOLT	TATA spare parts
265132600101	SHOCK ABSORBER REAR	TATA spare parts
265132600108	BKT S/ABS LH REAR TOP	TATA spare parts
265132600109	BKT S/ABS RH REAR TOP	TATA spare parts
265132600110	ASSY. BRACKET REAR SHOCK ABSORBER.	TATA spare parts
265132600112	REAR SHOCK ABSORBER	TATA spare parts
265132600113	SHOCK ABSORBER REAR	TATA spare parts
265132600117	SHOCK ABSORBER REAR	TATA spare parts
265132600120	BKT S/ABS RR TOP	TATA spare parts
265132600121	REAR ABSORBER	TATA spare parts
265132600125	SHOCK ABSORBER REAR	TATA spare parts
265132600128	SHOCK ABSORBER REAR	TATA spare parts
265132600130	BKT S/ABS	TATA spare parts
265132600131	REAR SHOCK ABSORBER	TATA spare parts
265132600132	REAR SHOCK ABSORBER	TATA spare parts
265132600133	REAR SHOCK ABSORBER	TATA spare parts
265132603202	HEX BOLT	TATA spare parts
265132603501	BOSS (FOR REAR SHOCK ABSORBER BKT-TOP) B	TATA spare parts
265132606901	METAL SLEEVE S/ABSORBER	TATA spare parts
265132607702	RUBBER BUSH	TATA spare parts
265132608202	WASHER	TATA spare parts
265132608210	WASHER	TATA spare parts
265132608215	REINFORCEMENT RH REAR SHOCKUP.MTG. BKT.	TATA spare parts
265132608216	REINFORCEMENT LH REAR SHOCKUP MTG. BKT.	TATA spare parts
265132800102	ANTI ROLL BAR FRONT	TATA spare parts
265132800103	CONNECTING ROD	TATA spare parts
265132800104	ANTI ROLL BAR FRONT 27D	TATA spare parts
265132800105	CONNECTING ROD ARB FRT	TATA spare parts
265132800110	ANTIROLL BAR COMPLETE LP407	TATA spare parts

265132803201	BOLT	TATA spare parts
265132803801	CLAMP SUPPORT	TATA spare parts
265132803802	CLAMP SUPPORT	TATA spare parts
265132804201	U CLAMP	TATA spare parts
265132804202	U CLAMP	TATA spare parts
265132806902	SPACER TUBE	TATA spare parts
265132806903	SPACER TUBE	TATA spare parts
265132807701	BEARING BLOCK	TATA spare parts
265132807702	RUBBER BUSH	TATA spare parts
265132807703	RUBBER BUFFER	TATA spare parts
265132807705	BEARING BLOCK FRT ARB	TATA spare parts
265132808201	CLAMP PLATE	TATA spare parts
265132808203	CUP	TATA spare parts
265132808210	BKT ANTI ROLL BAR RH FRT	TATA spare parts
265132808211	BKT ANTI ROLL BAR LH	TATA spare parts
265132900101	BKT ANTI ROLL BAR REAR	TATA spare parts
265132900106	CONNECTING ROD ARB RR	TATA spare parts
265132900108	ANTI ROLL BAR REAR	TATA spare parts
265132900112	ASSY REAR ARB WITH LINKS	TATA spare parts
265132900116	ASSY.CLAMP(ARB.REAR)	TATA spare parts
265132907105	REINFORCEMENT REAR ARB.BKT.	TATA spare parts
265132907106	ANTIROLL BAR SADDLE.(REAR ARB.)	TATA spare parts
265132907110	SADDLE-ANTIROLL BAR-REAR	TATA spare parts
265132907701	BEARING BLOCK REAR ARB	TATA spare parts
265132908202	CLAMP ARB REAR	TATA spare parts
265133000103	FRONT AXLE W/BRAKE RHD	TATA spare parts
265133000109	FRONT AXLE W/BRAKE LHD	TATA spare parts
265133000110	FRONT AXLE W/BRAKE RHD	TATA spare parts
265133000112	ASSY FRONT AXLE WITH BRAKES(RHD)	TATA spare parts
265133000116	ASSY FRONT AXLE 407 CMVR 2000	TATA spare parts
265133000117	ASSY.FRONT AXLE WITH BRAKES	TATA spare parts
265133000121	ASSY.FRONT AXLE WITH BRAKES	TATA spare parts
265133000126	ASSY. FRONT AXLE WITH BRAKES	TATA spare parts
265133105106	FRONT AXLE BEAM STD	TATA spare parts
265133105111	FRONT AXLE BEAM STD BS2/3/4/6	TATA spare parts
265133109902	COTTER BOLT	TATA spare parts
265133200108	ASSY.FRT.BRAKE DRUM W/HUB	TATA spare parts
265133200109	REP KIT KING PIN STD	TATA spare parts
265133200110	REP KIT KING PIN STD1	TATA spare parts
265133200111	REP KIT KING PIN RS1	TATA spare parts
265133200112	REP KIT KING PIN RS2	TATA spare parts
265133200113	ASSY.STUB AXLE (NORMAL)	TATA spare parts
265133200131	STUB AXLE ASSY STD	TATA spare parts
265133200147	ASSY.`K.P.CAP;`O'RING & GREASE NIPPLE'	TATA spare parts
265133200148	ASSY.K.P.CAP;`O'RING & NIPPLE(AM8X1)	TATA spare parts
265133200158	SET THRUST PAD (NORMAL)	TATA spare parts
265133203404	STEERING BUSH	TATA spare parts

265133203404DF	BUSH KING PIN - SFC407	TATA spare parts
265133205105	SPLIT NUT	TATA spare parts
265133205113	SPLIT NUT	TATA spare parts
265133205116	STUB AXLE BS6	TATA spare parts
265133205117	SPLIT NUT	TATA spare parts
265133206301	DUST CAP	TATA spare parts
265133206302	DUST CAP	TATA spare parts
265133206304	DUST CAP	TATA spare parts
265133206305	DUST CAP	TATA spare parts
265133206706	KING PIN STD	TATA spare parts
265133206707	KING PIN STD1	TATA spare parts
265133206708	KING PIN (REPAIR-I)	TATA spare parts
265133206709	KING PIN (REPAIR II)	TATA spare parts
265133208203	NAME PLATE	TATA spare parts
265133208601	SEAL RACE	TATA spare parts
265133208603	SPACER	TATA spare parts
265133208604	SHIM 0.1 MM	TATA spare parts
265133208605	SHIM 0.2 MM	TATA spare parts
265133208606	SHIM 0.3 MM	TATA spare parts
265133208607	SHIM 0.4 MM	TATA spare parts
265133208608	SHIM 0.5 MM	TATA spare parts
265133208609	SHIM 0.6 MM	TATA spare parts
265133208610	SHIM 0.7 MM	TATA spare parts
265133208612	SHIM 0.8 MM	TATA spare parts
265133208613	SHIM 0.90 MM	TATA spare parts
265133208614	SHIM 1.00 MM	TATA spare parts
265133208615	SHIM 1.10 MM	TATA spare parts
265133208616	SHIM 1.20 MM	TATA spare parts
265133208617	SHIM 1.30 MM THICK	TATA spare parts
265133208618	SHIM 1.40 MM	TATA spare parts
265133208619	SHIM 1.5 MM THK.	TATA spare parts
265133208620	SHIM	TATA spare parts
265133208621	SHIM BS6	TATA spare parts
265133208622	THRUST PAD UPPER STD	TATA spare parts
265133208623	THRUST PAD UPPER STD1	TATA spare parts
265133208626	THRUST PAD LOWER	TATA spare parts
265133208627	THRUST PAD LOWER	TATA spare parts
265133208630	SHIM FOR FRT AXLE 0.05	TATA spare parts
265133208631	SHIM FOR FRT AXLE 0.10	TATA spare parts
265133208632	SHIM FOR FRT AXLE 0.15	TATA spare parts
265133208633	SHIM FOR FRT AXLE 0.25	TATA spare parts
265133208634	SHIM FOR FRT AXLE 0.35	TATA spare parts
265133208635	SHIM FOR FRT AXLE 0.50	TATA spare parts
265133208636	SHIM FOR FRT AXLE 1.00	TATA spare parts
265133208637	SHIM FOR FRT AXLE 1.50	TATA spare parts
265133208638	SHIM	TATA spare parts
265133208639	SHIM	TATA spare parts

265133208640	SHIM BS6	TATA spare parts
265133208641	SHIM BS6	TATA spare parts
265133208642	SHIM BS6	TATA spare parts
265133208643	SHIM BS6	TATA spare parts
265133208644	SHIM BS6	TATA spare parts
265133208645	SHIM BS6	TATA spare parts
265133208646	SHIM BS6	TATA spare parts
265133208647	SHIM BS6	TATA spare parts
265133208648	SHIM BS6	TATA spare parts
265133209901	KING PIN CAP	TATA spare parts
265133209902	KING PIN CAP	TATA spare parts
265133209905	KING PIN CAP	TATA spare parts
265133209907	SPACER	TATA spare parts
265133400110	ASSY FRT BR DRUM W/HUB	TATA spare parts
265133403102	BEARING TAPER ROLLER	TATA spare parts
265133403105	THRUST BRG KING PIN STD	TATA spare parts
265133403106	BEARING STG PIVOT NORMAL I	TATA spare parts
265133403110	BEARING-REPAIR-II	TATA spare parts
265133403111	THRUST ROLLER BEARING NORMAL	TATA spare parts
265133403112	THRUST ROLLER BEARING NORMAL-1	TATA spare parts
265133403115	THRUST BRG.TAPER ROLLER NORMAL	TATA spare parts
265133403116	THRUST BRG.TAPER ROLLER NORMAL I	TATA spare parts
265133403124	THRUST BRG KING PIN RS1	TATA spare parts
265133403125	ROLLER THRUST BRG.[STEERING PIVOT REPII]	TATA spare parts
265133403127	TAPER ROLLER BEARING-INNER	TATA spare parts
265133403128	BEARING TAPER ROLLER	TATA spare parts
265133403129	TAPER ROLLER BRG 30306	TATA spare parts
265133403130	THRUST ROLLER BEARING-NORMAL	TATA spare parts
265133403132	ASSY THRUST PAD(NORMAL)	TATA spare parts
265133403138	THRUST PAD (NORMAL)	TATA spare parts
265133403142	THRUST BEARING (NORMAL)	TATA spare parts
265133403211	BOLT	TATA spare parts
265133403704	BRAKE DRUM W/HUB FRONT	TATA spare parts
265133403707	HUB COVER FRONT	TATA spare parts
265133403708	BRAKE DRUM W/HUB FRONT	TATA spare parts
265133403711	FRT.BRAKE DRUM W/HUB	TATA spare parts
265133403713	FRONT BRAKE DRUM W/HUB BS2/3/4	TATA spare parts
265133403720	FRONT BRAKE DRUM WITH HUB BS3/4	TATA spare parts
265133407802	OIL SEAL	TATA spare parts
265133407803	OIL SEAL	TATA spare parts
265133407804	OIL SEAL FRONT WHEEL HUB BS1/2/3/4	TATA spare parts
265133407805	OIL SEAL	TATA spare parts
265133407806	OIL SEAL	TATA spare parts
265133407807	OIL SEAL	TATA spare parts
265133408202	BAFFLE	TATA spare parts
265133408204	BAFFLE	TATA spare parts
265133409202	THRUST WASHER	TATA spare parts

265133409203	THRUST WASHER	TATA spare parts
265133409204	THRUST WASHER	TATA spare parts
265133800102	TIE ROD ASSY	TATA spare parts
265133800103	TIE ROD ASSY	TATA spare parts
265133800104	BALL JOINT LH THREAD ASSY	TATA spare parts
265133800105	BALL JOINT RH THREAD	TATA spare parts
265133800106	ASSY TIE ROD 407	TATA spare parts
265133800107	TIE ROD ASSY.	TATA spare parts
265133800108	BALL JOINT	TATA spare parts
265133800109	TIE ROD ASSY.	TATA spare parts
265133800111	TIE ROD ASSY.	TATA spare parts
265133800112	TIE ROD ASSY.	TATA spare parts
265133800115	TIA ROD ASSY.	TATA spare parts
265133800120	ASSY.BALL JOINT KIT R.H.	TATA spare parts
265133800121	ASSY.BALL JOINT KIT L.H.	TATA spare parts
265133800122	TIE ROD END ASSY RH	TATA spare parts
265133800123	TIE ROD END ASSY LH	TATA spare parts
265133800124	ASSY BALL JOINT LH	TATA spare parts
265133800125	ASSY BALL JOINT RH	TATA spare parts
265133803204	BOLT	TATA spare parts
265133803205	BOLT	TATA spare parts
265133803206	FLANGE-BOLT	TATA spare parts
265133803207	FLANGE BOLT	TATA spare parts
265133805109	TIE ROD ARM LH	TATA spare parts
265133805110	TIE ROD ARM RH	TATA spare parts
265133805111	STEERING ARM RHD	TATA spare parts
265133805112	STEERING ARM LHD	TATA spare parts
265133805116	STEERING ARM (RHD)	TATA spare parts
265135000102	REAR AXLE W/BRAKE 31WB	TATA spare parts
265135000103	ASSY.RA.COMP.W/BRK & HAND BRK.CABLE-27WB	TATA spare parts
265135100102	REAR COVER ASSY	TATA spare parts
265135100104	REAR AXLE HOUSING	TATA spare parts
265135100105	REAR AXLE BEAM 407	TATA spare parts
265135100111	ASSY RA HSG WITH SUPPORTING TUBE	TATA spare parts
265135105001	FLANGE (REAR COVER)	TATA spare parts
265135105104	SPRING SADDLE BS6	TATA spare parts
265135105301	GASKET REAR COVER	TATA spare parts
265135106701	CYLINDRICAL PIN	TATA spare parts
265135107101	REINFORCEMENT	TATA spare parts
265135108202	OIL SLINGER	TATA spare parts
265135108601	PRESSURE RING	TATA spare parts
265135108602	PRESSURE RING	TATA spare parts
265135300101	ASSY. DIFFERENTIAL HOUSING BS2/3/4	TATA spare parts
265135300105	COUPLING FLANGE	TATA spare parts
265135300106	CWP SET 41/8 OERL	TATA spare parts
265135300107	KIT DIFFERENTIAL GEAR	TATA spare parts
265135300110	CWP SET 37/8 OERL SFC/LP/LPT407	TATA spare parts

265135300111	DIFFERENTIAL ASSY 37/8	TATA spare parts
265135303101	TAPER ROLLER BRG	TATA spare parts
265135303102	TAPER ROLLER BRG 331257	TATA spare parts
265135303103	CYL ROLLER BRG NJ305EM	TATA spare parts
265135303104	CYL.ROLLER BRG.	TATA spare parts
265135303105	TAPER ROLLER BRG	TATA spare parts
265135303106	TAPER ROLLER BRG	TATA spare parts
265135303107	TAPER ROLLER BRG (40X95X27.25)	TATA spare parts
265135305103	DIFFERENTIAL SPIDER 20 D	TATA spare parts
265135305104	COUPLING FLANGE	TATA spare parts
265135305403	BEVEL GEAR DIFFERENTIAL	TATA spare parts
265135305404	GEAR REAR AXLE SHAFT	TATA spare parts
265135305405	DIFFL BEVEL GEAR REVA	TATA spare parts
265135305406	GEAR REAR AXLE SHAFT REVA	TATA spare parts
265135305411	PINION - CWP:37/8-0110OR	TATA spare parts
265135306101	LOCKING PLATE DIFFL	TATA spare parts
265135306501	THREADED RING TAIL PINION	TATA spare parts
265135306502	THREADED RING DIFFL	TATA spare parts
265135307701	OIL SEAL 48X65X10 BS2/3/4	TATA spare parts
265135307702	OIL SEAL	TATA spare parts
265135308001	HEX COLLAR BOLT CWP	TATA spare parts
265135308002	HEX COLLAR BOLT DIFFL	TATA spare parts
265135308202	LOCKING PLATE	TATA spare parts
265135308303	SHIM 0.10 MM	TATA spare parts
265135308304	SHIM 0.15 MM	TATA spare parts
265135308305	SHIM 0.20 MM	TATA spare parts
265135308306	SHIM 0.25 MM	TATA spare parts
265135308307	SHIM 0.50 MM	TATA spare parts
265135308308	SHIM 1.50 MM	TATA spare parts
265135308309	SHIM 0.30 MM	TATA spare parts
265135308310	SHIM 0.45 MM	TATA spare parts
265135308311	SHIM 1.00 MM	TATA spare parts
265135308601	SPACER RING	TATA spare parts
265135308602	SPACER RING	TATA spare parts
265135308604	SPACER RING 7.56 MM	TATA spare parts
265135308605	SPACER RING TAIL PINION 7.54THK	TATA spare parts
265135308606	SPACER RING 7.52 MM	TATA spare parts
26513530860610	SPACER RING RAW PART	TATA spare parts
265135308607	SPACE RING TAIL PINION 7.50THK	TATA spare parts
265135308608	SPACE RING TAIL PINION 7.48THK	TATA spare parts
265135308609	SPACER RING 7.46 MM	TATA spare parts
265135308610	SPACE RING TAIL PINION 7.44THK	TATA spare parts
265135308611	SPACE RING TAIL PINION 7.42THK	TATA spare parts
265135308612	SPACE RING TAIL PINION 7.40THK	TATA spare parts
265135308613	SPACE RING TAIL PINION 7.38THK	TATA spare parts
265135308614	SPACER RING 7.36 MM	TATA spare parts
265135308615	SPACE RING TAIL PINION 7.34THK	TATA spare parts

265135308616	SPACE RING TAIL PINION 7.32THK	TATA spare parts
265135308617	SPACER RING 7.30 MM	TATA spare parts
265135308619	SPACER RING 7.26 MM	TATA spare parts
265135308620	SPACER RING 7.60 MM	TATA spare parts
265135308621	SPACER RING TAIL PINION 7.70THK	TATA spare parts
265135308622	SPACER RING 7.80 MM	TATA spare parts
265135308623	SPACER RING 7.90 MM	TATA spare parts
265135308626	SPACER RING TAIL PINION 7.72 THK.	TATA spare parts
265135308627	SPACER RING 7.74 MM	TATA spare parts
265135308628	SPACER RING TAIL PINION 7.76 THK	TATA spare parts
265135308629	SPACER RING 7.78 MM	TATA spare parts
265135308630	SPACER RING TAIL PINION 7.82 THK	TATA spare parts
265135308631	SPACER RING 7.84 MM	TATA spare parts
265135308632	SPACER RING TAIL PINION 7.86 THK.	TATA spare parts
265135308633	SPACER RING 7.88 MM	TATA spare parts
265135308634	SPACER RING TAIL PINION 7.58 THK	TATA spare parts
265135308635	SPACER RING TAIL PINION 7.62 THK	TATA spare parts
265135308636	SPACER RING TAIL PINION 7.64 THK.	TATA spare parts
265135308637	SPACER RING TAIL PINION 7.66 THK.	TATA spare parts
265135308638	SPACER RING TAIL PINION 7.68 THK.	TATA spare parts
265135308639	SPACER RING TAIL PINION 7.92 THK	TATA spare parts
265135308640	SPACER RING 7.94 MM	TATA spare parts
265135308641	SPACER RING TAIL PINION 7.96 THK	TATA spare parts
265135308642	SPACER RING TAIL PINION 7.98 THK.	TATA spare parts
265135308643	SPACER RING TAIL PINION 8.00 THK.	TATA spare parts
265135308644	SPACER RING TAIL PINION 8.02 THK.	TATA spare parts
265135308645	SPACER RING TAIL PINION 8.10 THK.	TATA spare parts
265135308646	SPACER RING TAIL PINION 8.20 THK.	TATA spare parts
265135309202	THRUST WASHER 1.25 MM	TATA spare parts
265135309203	THRUST WASHER 1.30 MM	TATA spare parts
265135309204	THRUST WASHER 1.35 MM	TATA spare parts
265135309205	THRUST WASHER 1.40 MM	TATA spare parts
265135309206	THRUST WASHER 1.45 MM	TATA spare parts
265135309207	THRUST WASHER 1.50 MM	TATA spare parts
265135309208	THRUST WASHER 1.55 MM	TATA spare parts
265135309210	SPHERICAL WASHER	TATA spare parts
265135350101	ASSEMBLY END YOKE	TATA spare parts
265135600103	BRAKE DRUM W/BRG REAR	TATA spare parts
265135603101	TAPER ROLLER BRG. 33111 BS1/2/3/4	TATA spare parts
265135603101AE	TAPER ROLLER BRG;HUB OUTER -1628	TATA spare parts
265135603102	TAPER ROLLER BRG	TATA spare parts
265135603103	TAPER ROLLER BRG	TATA spare parts
265135603104	TAPER ROLLER BRG.	TATA spare parts
265135603703	REAR BRAKE DRUM WITH HUB	TATA spare parts
265135605301	GASKET HUB	TATA spare parts
265135606501	LOCKING RING	TATA spare parts
265135607701	OIL SEAL RR INNER 407	TATA spare parts

265135607702	OIL SEAL RR OUTER 407	TATA spare parts
265135607703	OIL SEAL HUB INNER	TATA spare parts
265135607705	OIL SEAL HUB INNER	TATA spare parts
265135607706	OIL SEAL HUB OUTER	TATA spare parts
265135608201	LOCK WASHER	TATA spare parts
265135608601	SPACER BET BRG & LOCKRING	TATA spare parts
265135608602	SPACER BET IN BRG & SEAL	TATA spare parts
265135608603	SPACER BET OUT BRG & SEAL	TATA spare parts
265135608605	SPACER BET BRG & LOCKRING	TATA spare parts
265135608801	STUD	TATA spare parts
265135707901	REAR AXLE SHAFT	TATA spare parts
265140100002	LOCK RING	TATA spare parts
265140100118	WHEEL RIM 6.00 G 16	TATA spare parts
265140100119	WHEEL RIM 6.00 G 16	TATA spare parts
265140100128	WHEEL DISC & RIM 6.00X16	TATA spare parts
265140100145	WHEEL RIM 6.00G X 16	TATA spare parts
265140100151	ASSY.HUB COVER	TATA spare parts
265140100156	ASSY WHEEL RIM 6.00GX16	TATA spare parts
265140100168	ASSY WHEEL RIM 6.00G-16	TATA spare parts
265140100171	ASSY. WHEEL RIM BS2	TATA spare parts
265140100174	ASSY WHEEL RIM SPIGOTTED	TATA spare parts
265140100175	ASSY WHEEL RIM	TATA spare parts
265140100176	ASSY WHEEL RIM	TATA spare parts
265140100179	TUBE	TATA spare parts
265140100192	TYRE TUBE¿ FOR 7.50 X 16 CENT MTD VALV	TATA spare parts
265140100197	TUBE	TATA spare parts
265140100198	WHEEL RIM 6.00GX16	TATA spare parts
265140100199	ASSY WHEEL RIM 6G X 16	TATA spare parts
265140107703	FLAP	TATA spare parts
265140107714	FLAP	TATA spare parts
265140109905	TYRE ,RIB TYPE 7.50X16-16PR 8.25X16-16PR	TATA spare parts
265140109934	BALANCE WEIGHT 10 GMS. BS6	TATA spare parts
265140109978	TYRE 7.50R16-14PR	TATA spare parts
265140109980	TYRE,RIB TYPE 7.00 R16 12PR	TATA spare parts
265140109982	TYRE,LUG TYPE 7.5X16 16PR LUG	TATA spare parts
265140109983	TYRE,RIB TYPE 8.25X16 16PR RIB	TATA spare parts
265140109998	BALANCE WEIGHT BS6	TATA spare parts
265140110107	WHEEL RIM 6.00G-16 SDC	TATA spare parts
265140110127	ASSY.WH.RIM & DISC(6.00GX16 O/S80)	TATA spare parts
265140203206	WHEEL MTG BOLT	TATA spare parts
265140206501	WHEEL NUT	TATA spare parts
265140206502	WHEEL NUT	TATA spare parts
265140300115	SHAFT ASSY	TATA spare parts
265140300116	WIRE ROPE ASSY	TATA spare parts
265140300120	CROSS MEMBER SP WH CARRIER	TATA spare parts
265140300124	ASSY HOLDING BRACKET	TATA spare parts
265140300125	ASSY HANDLE(PAINTED)	TATA spare parts



265140300130	CROSS MEMBER ASSY	TATA spare parts
265140300131	ASSY FERRULE	TATA spare parts
265140300132	ASSY CABLE HOLDER	TATA spare parts
265140300143	ASSY. HANDLE	TATA spare parts
265140300146	ASSY WIRE ROPE	TATA spare parts
26514030014720	ASSY SPARE WHEEL HANDLE WITH SHAFT	TATA spare parts
265140308225	CABLE HOLDER BS6	TATA spare parts
265140308401	SLEEVE	TATA spare parts
265140309905	WIREROPE BS6	TATA spare parts
265141000102	ASSY.UNITISED PROP.SHAFT.	TATA spare parts
265141000103	ASSY.UNITISED PROP.SHAFT COMP.	TATA spare parts
265141000104	ASSY.UNITISED PROP.SHAFT COMPLETE	TATA spare parts
265141000105	ASSY.KIT END PIECE WITH NUT(FRONT)	TATA spare parts
265141000108	ASSY.UNITISED PROP.SHAFT	TATA spare parts
265141000110	ASSY.UNITISED PROP.SHAFT	TATA spare parts
265141000111	ASSY.UNITISED PROP.SHAFT	TATA spare parts
265141000112	ASSY.UNITISED PROP.SHAFT	TATA spare parts
265141005123	1410 U.J.KIT	TATA spare parts
265141005127	1480 U.J.KIT	TATA spare parts
265141005128	SLEEVE YOKE SUB ASSY	TATA spare parts
265141008233	1330 DUST CAP	TATA spare parts
265141100101	ASSY LONG FORK	TATA spare parts
265141100105	UJ CROSS ASSY	TATA spare parts
265141100108	PROP SHAFT RR 1120MM	TATA spare parts
265141100109	PROP SHAFT RR 1030MM	TATA spare parts
265141100122	COUPLING FLANGE	TATA spare parts
265141100123	PROTECTIVE CAP	TATA spare parts
265141100125	UJ LONG FORK	TATA spare parts
265141100126	CENTRE BEARING SPACER RING	TATA spare parts
265141100127	UJ CROSS SUBASSY	TATA spare parts
265141100128	KIT UJ CROSS REPAIR	TATA spare parts
265141100138	PROP SHAFT RR 60X3X654	TATA spare parts
265141100139	PROP SHAFT RR 60X3X744	TATA spare parts
265141100146	KIT-CENTER BEARING BS2/3/4	TATA spare parts
265141100147	CENTER BEARING KIT	TATA spare parts
265141105102	UJ FLANGE	TATA spare parts
265141105103	REAR TEETH 407	TATA spare parts
265141105107	COUPLING FLANGE LCV	TATA spare parts
265141105108	SHORT FORK 407	TATA spare parts
265141105121	1350 FLANGE YOKE	TATA spare parts
265141105122	1350 U.J.KIT	TATA spare parts
265141105122DF	UJ CROSS 34.95X106 - SFC407	TATA spare parts
265141105123	KIT-UNIVERSAL JOINT 1410 BS2/3/4	TATA spare parts
265141105124	SLEEVE YOKE	TATA spare parts
265141105125	1350 STUB YOKE	TATA spare parts
265141105126	BEARING PLUG SHAFT	TATA spare parts
265141105127	KIT-UNIVERSAL JOINT BS2/3/4	TATA spare parts

265141105128	SLEEVE YOKE	TATA spare parts
265141105129	STUB BALL YOKE	TATA spare parts
265141105130	SLEEVE YOKE	TATA spare parts
265141105131	STUB YOKE	TATA spare parts
265141105132	BEARING PLUG SHAFT	TATA spare parts
265141105155	KIT-UNIVERSAL JOINT BS1/2/3/4	TATA spare parts
265141106502	HEX NUT M26X1.5	TATA spare parts
265141107501	CENTER BEARING RUBBER	TATA spare parts
265141107502	CENTER BEARING RUBBER	TATA spare parts
265141107709	PROTECTIVE CAP	TATA spare parts
265141107710	SEAL	TATA spare parts
265141107713	SEAL	TATA spare parts
265141107801	DUST SEAL	TATA spare parts
265141108001	FITTING SCREW	TATA spare parts
265141108230	LOCKING PLATE	TATA spare parts
265141108232	CENTER BEARING BRACKET	TATA spare parts
265141108233	DUST CAP FOR SLEEV YOKE	TATA spare parts
265141108234	FLINGER	TATA spare parts
265141108235	DUST COVER (SHIELD)	TATA spare parts
265141108236	CENTER BEARING BRACKET	TATA spare parts
265141110102	PROP SHAFT FR W/O CB 31W	TATA spare parts
265141110107	PROP SHAFT FR 666MM 27WB	TATA spare parts
265141110108	PROP SHAFT FR 60X3X670	TATA spare parts
265141110110	CENTRE BEARING ASSY	TATA spare parts
265141110129	ASSY.PROP.SHAFT TUBE-FRONT	TATA spare parts
265141110131	ASSY.PROP.SHAFT FRONT	TATA spare parts
265141110133	ASSY.PROP.SHAFT WITH CENTER BEARING	TATA spare parts
265141110139	ASSY.PROP.SHAFT WITH CENTER BEARING	TATA spare parts
265141110147	ASSY FRONT SHAFT	TATA spare parts
265141110148	ASSY SHAFT FRONT	TATA spare parts
265141113101	BALL BEARING 6207	TATA spare parts
265141114311	CIRCLIP	TATA spare parts
265141114312	CIRCLIP 1.25MM	TATA spare parts
265141114313	CIRCLIP 1.30MM	TATA spare parts
265141114314	CIRCLIP 1.35MM	TATA spare parts
265141114315	CIRCLIP	TATA spare parts
265141114316	CIRCLIP	TATA spare parts
265141114320	CIRCLIP 1.275MM	TATA spare parts
265141114321	CIRCLIP	TATA spare parts
265141117501	RUBBER BEARING	TATA spare parts
265141117801	OIL SEAL	TATA spare parts
265141118201	PROTECTIVE CAP	TATA spare parts
265141118206	DUST COVER	TATA spare parts
265141118601	SPACER RING CEN BRG	TATA spare parts
265141118603	SPACER	TATA spare parts
265141120101	PROTECTIVE CAP	TATA spare parts
265141120106	ASSY.REAR PROP SHAFT	TATA spare parts

265141120108	ASSY.PROP SHAFT REAR.	TATA spare parts
265141120109	ASSY.REAR PROP.SHAFT	TATA spare parts
265141120115	ASSY.REAR SHAFT	TATA spare parts
265141120116	ASSY REAR SHAFT	TATA spare parts
265141120117	ASSY REAR SHAFT	TATA spare parts
265141120118	ASSY PROPELLER SHAFT	TATA spare parts
265141120120	ASSY. PROP.SHAFT (REAR)	TATA spare parts
265141120121	TUBULAR SHAFT ASSY	TATA spare parts
265141125101	1410 FLANGE YOKE	TATA spare parts
265141125102	1410 STUB YOKE	TATA spare parts
265141125103	FLANGE YOKE	TATA spare parts
265141125104	STUB YOKE	TATA spare parts
265141125123	1410 U. J. KIT	TATA spare parts
265141125129	1480 STUB YOKE	TATA spare parts
265141125155	1480 U. J. KIT	TATA spare parts
265141300101	CENTRE BEARING BRACKET	TATA spare parts
265141300102	ASSY.CENTER BEARING COMPLETE	TATA spare parts
265141303101	BALL BEARING	TATA spare parts
265141303103	SRDG BALL BEARING	TATA spare parts
265141303301	CENTER BEARING BRACKET	TATA spare parts
265141307501	RUBBER BEARING	TATA spare parts
265142010102	ASSY.VACCUM BOOSTER WITH TMC	TATA spare parts
265142010105	ASSY. VACCUM BOOSTER W/ TMC BS2/3/4	TATA spare parts
265142100120	STAR WHEEL ASSY	TATA spare parts
265142100121	BRAKE ADJUSTER MECHANICAL BS2/4	TATA spare parts
265142100122	ASSY FRONT AXLE BRAKE-LH	TATA spare parts
265142100123	ASSY FRONT AXLE BRAKE-RH	TATA spare parts
265142100124	ASSY FRONT AXLE BRAKE-LH COMPLETE	TATA spare parts
265142100125	ASSY FRONT AXLE BRAKE-RH COMPLETE	TATA spare parts
265142100133	ASSY.FRONT AXLE BRAKE LH N/ASBS	TATA spare parts
265142100137	BRAKE ADJUSTER AUTOMATIC	TATA spare parts
265142100152	BRAKE ADJUSTER MECHANICAL BS2/3/4	TATA spare parts
265142100156	WHEEL CYL ASSY DIA. 22.22	TATA spare parts
265142100157	ASSY FRONT AXLE BRAKE-LH	TATA spare parts
265142100158	ASSY FRONT AXLE BRAKE-RH	TATA spare parts
265142100171	ASSY. FRONT AXLE BRAKE-LH	TATA spare parts
265142100172	ASSY. FRONT AXLE BRAKE-RH	TATA spare parts
265142100173	ASSY FRONT AXLE BRAKE LH	TATA spare parts
265142100174	ASSY FRONT AXLE BRAKE RH	TATA spare parts
265142100177	ASSY FRONT AXLE BRAKE LH	TATA spare parts
265142100178	ASSY FRONT AXLE BRAKE RH	TATA spare parts
265142100179	ASSY FRONT AXLE BRAKE LH	TATA spare parts
265142100180	ASSY FRONT AXLE BRAKE RH	TATA spare parts
265142100181	ASSY FRONT AXLE BRAKE LH (SA63SM)	TATA spare parts
265142100182	ASSY. FRONT AXLE BRAKE RH (SA63SM)	TATA spare parts
265142103202	BOLT	TATA spare parts
265142103203	BOLT	TATA spare parts

265142103204	BOLT	TATA spare parts
265142106303	BRAKE LINING PRIMARY NORMAL	TATA spare parts
265142106304	BRAKE LINING SECONDARY NORMAL	TATA spare parts
265142107101	LOCKING PLATE LH	TATA spare parts
265142107102	LOCKING PLATE RH	TATA spare parts
265142107103	LOCK PLATE	TATA spare parts
265142107707	PLUG	TATA spare parts
265142108001	BLEEDER SCREW	TATA spare parts
265142108002	ADJUSTER SCREW RH	TATA spare parts
265142108003	ADJUSTER SCREW LH	TATA spare parts
265142108004	SCREW	TATA spare parts
265142108602	SHIM 0.30 MM	TATA spare parts
265142108607	SHIM 0.5 THK.	TATA spare parts
265142108608	SHIM 1 THK.	TATA spare parts
265142108610	SHIM 0.2 THK.	TATA spare parts
265142108701	SPRING	TATA spare parts
265142108702	SPRING SHOE RETURN BOTTOM	TATA spare parts
265142108706	RETURN SPRING (BOTTOM)	TATA spare parts
265142109901	POLE WHEEL FRONT - 407/410	TATA spare parts
265142110101	ANCHOR PLATE LH FRONT	TATA spare parts
265142110102	ANCHOR PLATE RH FRONT	TATA spare parts
265142130101	BR SHOE W/LIN STD PRI	TATA spare parts
265142130102	ASSY BRAKE SHOE W/LINING(PRIM) REPAIR-I	TATA spare parts
265142130103	BR SHOE W/LIN RS2 PRI	TATA spare parts
265142130104	BR SHOE W/LIN STD SEC	TATA spare parts
265142130106	BR SHOE W/LIN RS2 SEC	TATA spare parts
265142130107	BR SHOE W/O LINING	TATA spare parts
265142130114	WHEEL CYLINDER ASSY.22.22 DIA.	TATA spare parts
265142130115	MINOR KIT 22.2 DIA.W/CYL	TATA spare parts
265142130124	ASSY.BRAKE SHOE W.T LINING PRIM. NON-ASB	TATA spare parts
265142130125	ASSY.BRAKE SHOE W.T LINING SECO.NON-ASB	TATA spare parts
265142130128	ASY.BRK SHOE W.LINING PRIM	TATA spare parts
265142130129	ASY.BRK SHOE W.LINING SEC	TATA spare parts
265142130132	ASY. BRK SHOE WITH LINING PRIMARY	TATA spare parts
265142130133	ASY. BRK SHOE WITH LINING SEC.	TATA spare parts
265142130134	ASY.BRK SHOE W.LEVER SECONDARY LH	TATA spare parts
265142130135	ASY.BRK SHOE W.LEVER SECONDARY RH	TATA spare parts
265142136301	BRAKE LINING STD PRI	TATA spare parts
265142136302	BRAKE LINING RS1 PRI	TATA spare parts
265142136303	BRAKE LINING PRIMARY-REPAIR II	TATA spare parts
265142136304	BRAKE LINING STD SEC	TATA spare parts
265142136305	BRAKE LINING RS1 SEC	TATA spare parts
265142136306	BRAKE LINING RS2 SEC	TATA spare parts
265142136311	BR LNG NABS 10.8 PRIM DRG	TATA spare parts
265142136312	BRAKE LINING STD PRI NASB	TATA spare parts
265142136314	BRAKE LINING RS2 SEC NASB	TATA spare parts
265142136315	BRAKE LINING RS1 SEC NASB	TATA spare parts

265142136316	BRAKE LINING STD SEC NASB	TATA spare parts
265142136319	BRAKE LINING PRI.REPAIR-I	TATA spare parts
265142136322	BRAKE LINING SEC.NORMAL	TATA spare parts
265142136325	BR LINING NABS 9.8 PRIM	TATA spare parts
265142136326	BR LINING NABS 10.8 PRIM	TATA spare parts
265142136327	BR LINING NABS 11.8 PRIM	TATA spare parts
265142136328	BR LINING NABS 9.8 SECO	TATA spare parts
265142136329	BR LINING NABS 10.8 SECO	TATA spare parts
265142136330	BR LINING NABS 11.8 SECO	TATA spare parts
265142136601	PUSH ROD	TATA spare parts
265142136602	PISTON	TATA spare parts
265142137702	SEAL	TATA spare parts
265142300101	WHEEL CYL.19.05D	TATA spare parts
265142300158	REP KIT W/CYL 19.05MNR	TATA spare parts
265142300161	WHEEL CYL.19.05D	TATA spare parts
265142300165	17.78 DIA.WHEEL CYLINDER BS2	TATA spare parts
265142300166	ASSY WHEEL CYLINDER 17.78 DIA	TATA spare parts
265142300167	REP KIT W/CYL 17.78MNR	TATA spare parts
265142300171	REP KIT W/CYL 17.78MJR	TATA spare parts
265142300179	ASSY WHEEL CYLINDER 17.78 DIA	TATA spare parts
265142300182	ASSY WHEEL CYLINDER 17.78 DIA	TATA spare parts
265142306803	3 WAYCONNECTOR	TATA spare parts
265142307705	PLUG	TATA spare parts
265142308215	COVER	TATA spare parts
265142308233	OIL CATCHER	TATA spare parts
265142308701	SPRING	TATA spare parts
265142310103	ANCHOR PLATE LH REAR	TATA spare parts
265142310104	ANCHOR PLATE RH REAR	TATA spare parts
265142310107	ANCH/PLATE RR LH 709E	TATA spare parts
265142310108	ANCHOR PLATE RH REAR	TATA spare parts
265142310121	ASSY REAR AXLE BRAKE LH	TATA spare parts
265142310122	ASSY REAR AXLE BRAKE RH	TATA spare parts
265142310127	ASSY REAR AXLE BRAKE LH	TATA spare parts
265142310128	ASSY REAR AXLE BRAKE RH	TATA spare parts
265142310129	ASSY.REAR AXLE BRAKE-LH (ASB.)	TATA spare parts
265142310130	ASSY.REAR AXLE BRAKE-RH (ASB.)	TATA spare parts
265142310133	ASSY ANCHOR PLATE REAR-LH	TATA spare parts
265142310134	ASSY ANCHOR PLATE REAR-RH	TATA spare parts
265142310160	ASSY R/A BRK. LH SA63SM	TATA spare parts
265142310161	ASSY R/A BRK. RH SA63SM	TATA spare parts
265142310164	ASSY REAR AXLE BRAKE LH (SFC 406)	TATA spare parts
265142310165	ASSY REAR AXLE BRAKE RH (SFC 406)	TATA spare parts
265142310166	ASSY R/A BRAKE LH(SA63SM)WO OIL CATHCHER	TATA spare parts
265142310167	ASSY R/A BRAKE RH (SA63SM) WO OIL CATCHR	TATA spare parts
265142310168	ASSY R/A BRAKE RH(SA63SM) WO OIL CATCHER	TATA spare parts
265142310169	ASSY R/A BRAKE LH(SA63SM) WO OIL CATCHER	TATA spare parts
265142310170	ASSY RA BRK. LH W/O OIL CAT.	TATA spare parts

265142310171	ASSY RA BRK. RH W/O OIL CAT.	TATA spare parts
265142400101	LOAD CONSCIOUS REDUCING VALVE	TATA spare parts
265142400102	LCRV VALVE	TATA spare parts
265142500162	ASSY.HOSE COMPLETE	TATA spare parts
265142700110	LINK ASSY	TATA spare parts
265142700118	HAND BR CABLE RR 31WB	TATA spare parts
265142700120	HAND BR CABLE FRT	TATA spare parts
265142700121	HAND BR CABLE FRT	TATA spare parts
265142700122	HAND BR CABLE RR 31WB	TATA spare parts
265142700123	HAND BR CABLE RR 27WB	TATA spare parts
265142700126	ASSY.RATCHET	TATA spare parts
265142700129	ASSY.HAND BRAKE COVER	TATA spare parts
265142700130	PAWL ROD ASSY	TATA spare parts
265142700131	HAND BRAKE LEVER ASSY COM	TATA spare parts
265142700150	ASSY.PARKING.BRAKE CABLE FRONT OFFER DRG	TATA spare parts
265142700152	ASSY PARKING BR.CABLE FRONT 27WB	TATA spare parts
265142700153	HAND BR CABLE FRT 31WB	TATA spare parts
265142700154	ASSY.PARKING BR.CABLE FRONT 27WB	TATA spare parts
265142700155	H/BR CABLE FRT 31 WB	TATA spare parts
265142700156	ASSY.PARK.BR CABLE REAR 27 WB OFFER DRG	TATA spare parts
265142700157	ASSY.PARK.BR.CABLE REAR	TATA spare parts
265142700158	ASSY.PARK.BRAKE CABLE REAR 27WB	TATA spare parts
265142700159	ASSY.PARK.BRAKE CABLE REAR 31WB	TATA spare parts
265142700160	ASSY.PARK.BRAKE CABLE REAR 27WB	TATA spare parts
265142700161	ASSY.PARK.BRAKE CABLE REAR 31WB	TATA spare parts
265142700164	HAND BR CABLE FRT 31LHD	TATA spare parts
265142700168	ASSY.PARK.BRAKE CABLE REAR 31WB	TATA spare parts
265142700175	HAND BRAKE CABLE FRONT	TATA spare parts
265142700177	ASSY. PARKING BRAKE CABLE FORNT	TATA spare parts
265142700180	ASSY.PARKING BRAKE CABLE FRONT - OFFER	TATA spare parts
265142700182	ASSY.BRACKET (PARKING BRAKE HANDLE MTG.)	TATA spare parts
265142700183	ASSY.PARKING BRAKE CABLE FRONT	TATA spare parts
265142700185	ASSY.PARKING BRAKE CABLE REAR	TATA spare parts
265142700186	ASSY.PARKING BRAKE CABLE REAR	TATA spare parts
265142704201	CABLE CLAMP	TATA spare parts
265142704301	CLIP	TATA spare parts
265142705601	HANDLE	TATA spare parts
265142705603	KNOB	TATA spare parts
265142706701	PIN	TATA spare parts
265142706706	CLEVIS PIN	TATA spare parts
265142706707	PIN	TATA spare parts
265142707401	RIVET	TATA spare parts
265142708204	BRACKET	TATA spare parts
265142708601	SPACER	TATA spare parts
265142709201	WASHER	TATA spare parts
265142709902	PAWL	TATA spare parts
265142709907	SPHERICAL NUT	TATA spare parts

265142800101	ASSY.HOSE	TATA spare parts
265142800112	TUBE ASSY	TATA spare parts
265142800113	TUBE ASSY	TATA spare parts
265142800116	TUBE ASSY	TATA spare parts
265142800117	TUBE ASSY	TATA spare parts
265142800118	TUBE ASSY.	TATA spare parts
265142800119	TUBE ASSY.	TATA spare parts
265142800120	TUBE ASSY.	TATA spare parts
265142800125	TUBE ASSY	TATA spare parts
265142800126	ASSY TUBE	TATA spare parts
265142800127	TUBE ASSY	TATA spare parts
265142800128	HOSE ASSY	TATA spare parts
265142800134	TUBE ASSY	TATA spare parts
265142800138	TUBE ASSY	TATA spare parts
265142800141	TUBE ASSY.	TATA spare parts
265142800144	TUBE ASSY	TATA spare parts
265142800145	TUBE ASSY	TATA spare parts
265142800148	TUBE ASSY	TATA spare parts
265142800150	TUBE ASSY	TATA spare parts
265142800156	HOSE ASSY	TATA spare parts
265142800162	HOSE VACCUME CYL	TATA spare parts
265142800165	TUBE ASSY	TATA spare parts
265142800168	TUBE ASSEMBLY	TATA spare parts
265142800172	ASSY.BRACKET	TATA spare parts
265142800196	ASSY TUBE	TATA spare parts
265142800198	ASSY.TUBE	TATA spare parts
265142800199	ASSY.TUBE	TATA spare parts
265142803301	BRACKET	TATA spare parts
265142803302	BRACKET	TATA spare parts
265142803303	BRACKET	TATA spare parts
265142803401	THREADED PLUG	TATA spare parts
265142804201	HOLDER BRAKE HOSE	TATA spare parts
265142804202	COATED CLAMP	TATA spare parts
265142804203	COATED DOUBLE CLAMP	TATA spare parts
265142804205	CLAMP	TATA spare parts
265142804211	COATED DOUBLE CLAMP	TATA spare parts
265142806003	LEVER	TATA spare parts
265142806801	CONNECTOR 3 WAY	TATA spare parts
265142806803	THREE WAY UNION	TATA spare parts
265142806804	ADAPTER	TATA spare parts
265142806806	ADAPTER	TATA spare parts
265142806809	PLUG ADAPTOR	TATA spare parts
265142806810	3 WAY 'T' CONNECTOR	TATA spare parts
265142807701	RUBBER BUSH	TATA spare parts
265142810107	ASSY TUBE	TATA spare parts
265142810113	ASSY TUBE	TATA spare parts
265142810114	ASSY TUBE	TATA spare parts

265142810117	ASSY TUBE	TATA spare parts
265142810124	ASSY.TUBE	TATA spare parts
265142810125	ASSY.TUBE	TATA spare parts
265142810126	ASSY.TUBE	TATA spare parts
265142810127	ASSY.TUBE	TATA spare parts
265142810128	ASSY.TUBE	TATA spare parts
265142810131	ASSY.TUBE	TATA spare parts
265142810132	ASSY. TUBE	TATA spare parts
265142810134	ASSY.TUBE	TATA spare parts
265142810135	ASSY.TUBE	TATA spare parts
265142810139	ASSY. TUBE	TATA spare parts
265142810140	ASSY. TUBE	TATA spare parts
265143100103	MASTER CYL.23.81DIA X37 17+20	TATA spare parts
265143100108	TANDEM MASTER CYL	TATA spare parts
265143100110	BRAKE FLUID CONTAINER	TATA spare parts
265143100113	KIT REP MINOR TMC 23.81D	TATA spare parts
265143100117	FILLER CAP	TATA spare parts
265143100120	RESERVOIR (ATE NO.03.3508-8753.3)	TATA spare parts
265143100122	ASSY TANDEM MASTER CYL.23.8 DIA	TATA spare parts
265143100130	ASSY BRAKE FLUID CONTAINER	TATA spare parts
265143100135	TANDEM MAST.CYL23.8	TATA spare parts
265143100136	ASSY. TENDEM MASTER CYL. 25.4DIA BS1- 4	TATA spare parts
265143100136AE	ASSY TENDEM MASTER CYL-XEN DC/SC	TATA spare parts
265143106316	DRIP TRAY	TATA spare parts
265143107709	RECUPERATING SEAL	TATA spare parts
265143208701	SPRING	TATA spare parts
265143400107	ASSY.BRACKET	TATA spare parts
265143400110	ASSY.BRACKET	TATA spare parts
265143400112	ASSY. BRACKET	TATA spare parts
265143400115	ASSY.BRACKET(MAG.VALVE MTG.)	TATA spare parts
265143500101	VACUUM CYLINDER	TATA spare parts
265143500109	VACCUM BOOSTER ASSY	TATA spare parts
265143500111	ASSY VACUUM BOOSTER	TATA spare parts
265143500115	VACUUM BOOSTER	TATA spare parts
265143500116	VACUUM BOOSTER (3.6 RATIO)	TATA spare parts
265143500120	VACUUM BOOSTER ASSY.	TATA spare parts
265143500121	VACUUM BRAKE VALVE	TATA spare parts
265143500122	KIT REP VAC BOOSTER MJR	TATA spare parts
265143500123	KIT REP VAC BOOSTER MNR	TATA spare parts
265143500131	ASSY VACUUM BOOSTER	TATA spare parts
265143500132	VACUUM BRAKE VALVE	TATA spare parts
265143500144	ASSY VACUUM BOOSTER	TATA spare parts
265143500151	ASSY VACUUM BOOSTER	TATA spare parts
265143500152	ASSY VACUUM BOOSTER	TATA spare parts
265143500153	ASSY VACUUM BOOSTER	TATA spare parts
265143500154	ASSY VACUUM BOOSTER	TATA spare parts
265143500155	ASSY. TENDEM BOOSTER 9 +8 BS2/3/4	TATA spare parts



265143505801	RUBBER HOSE	TATA spare parts
265143505802	HOSE	TATA spare parts
265143505804	HOSE VAC PUMP TO BOOSTER	TATA spare parts
265143505805	HOSE	TATA spare parts
265143507501	RUBBER GROMMET	TATA spare parts
265143507706	DIAPHRAM	TATA spare parts
265143507904	SPHERICAL END PIECE	TATA spare parts
265143510109	TUBE ASSY	TATA spare parts
265143800105	ASSY.TUBE	TATA spare parts
265143800106	ASSY.TUBE	TATA spare parts
265143800107	ASSY.TUBE	TATA spare parts
265143800112	ASSY.TUBE	TATA spare parts
265143800116	ASSY.TUBE	TATA spare parts
265143800121	ASSY TUBE	TATA spare parts
265143800122	ASSY.TUBE	TATA spare parts
265143800128	ASSY.TUBE	TATA spare parts
265143800129	ASSY TUBE	TATA spare parts
265143800137	ASSY TUBE (FROM ADAPTOR TO LCRV INLET)	TATA spare parts
265143800138	ASSY TUBE (FROM LCRV OUTLET TO REAR TEE)	TATA spare parts
265143800152	ASSY TUBE	TATA spare parts
265143800153	ASSY TUBE	TATA spare parts
265143810101	ASSY TUBE LCRV TO OUTLET TO REAR TEE	TATA spare parts
265144800101	HOSE HIGH PRESSURE 3/8	TATA spare parts
265146106301	RUBBER BELLOW (ON FLOOR)	TATA spare parts
265146106303	RUBBER BELLOW	TATA spare parts
265146108201	CLAMPING RING	TATA spare parts
265146200101	ASSY STEERING COLUMN	TATA spare parts
265146200108	SUBASSY COVER SECT SHAFT	TATA spare parts
265146200109	ASSY STRG WORM & NUT	TATA spare parts
265146200113	ASSY COVER FOR WORM	TATA spare parts
265146200114	SECTOR SHAFT	TATA spare parts
265146200115	SUPPORT STRG COLUMN	TATA spare parts
265146200118	STRG GEAR BOX RHD	TATA spare parts
265146200120	STRG HSG SUBASSY RHD	TATA spare parts
265146200121	STEERING WORM & NUT	TATA spare parts
265146200123	BKT STRG G/BOX & CAB MTG	TATA spare parts
265146200124	SEAL KIT FOR STEERING G BOX	TATA spare parts
265146200129	SECTOR SHAFT	TATA spare parts
265146200130	ASSY. STRG G BOX	TATA spare parts
265146200137	STEERING WORM & NUT LH	TATA spare parts
265146200140	STRG GEAR BOX LHD	TATA spare parts
265146200143	COVER SECTOR SHAFT	TATA spare parts
265146200146	STRG SPINDLE MIDDLE	TATA spare parts
265146200148	ASSY COVER SECTOR SHAFT	TATA spare parts
265146200156	STRG COLUMN	TATA spare parts
265146200157	STRG COLUMN COMPLT	TATA spare parts
265146200169	ASSY.STEERING GEAR BOX MTG.BRACKET-RHD	TATA spare parts

265146200170	ASSY STEERING GEAR BOX MTG.BRACKET (LHD)	TATA spare parts
265146200182	HSG SUB ASSY STRG GR BOX	TATA spare parts
265146200184	ASSY. STEERING GEAR BOX BS2/3/4	TATA spare parts
265146200186	STRG NUT & WORM ASSY. BS2/3/4	TATA spare parts
265146200191	ASSY COVER SECTOR SHAFT	TATA spare parts
265146200192	COVER SECTOR SHAFT	TATA spare parts
265146200193	SECTOR SHAFT	TATA spare parts
265146200196	HEX SCREW WITH NYLON INSERT	TATA spare parts
265146200197	ASSY SPINDLE 407/709 POWER STEERING	TATA spare parts
265146203103	ANGULAR CONTACT BALL BRG	TATA spare parts
265146203104	ANGULAR CONTACT BALL BRG	TATA spare parts
265146203106	ANGULAR CONTACT BALL BRG	TATA spare parts
265146203107	ANGULAR CONTACT BALL BRG	TATA spare parts
265146203109	ANGULAR CONTACT BALL BEARING	TATA spare parts
265146203201	ADJUSTING SCREW	TATA spare parts
265146203402	BUSH BEARING	TATA spare parts
265146203403	BUSH BEARING	TATA spare parts
265146203405	BUSH	TATA spare parts
265146204201	CLAMP PIECE	TATA spare parts
265146204704	COVER	TATA spare parts
265146205301	GASKET	TATA spare parts
265146205302	GASKET	TATA spare parts
265146206101	LOCKING PLATE	TATA spare parts
265146206301	SLEEVE PVC 10X25 LG IS 1951	TATA spare parts
265146206503	NYLOC NUT	TATA spare parts
265146207701	RUBBER SUPPORT	TATA spare parts
265146207702	RUBBER FLANGE	TATA spare parts
265146207703	RUBBER SUPPORT	TATA spare parts
265146207704	OIL SEAL STRG-BIG	TATA spare parts
265146207705	OIL SEAL 19.6X32X7 PERFECT OIL SEALS	TATA spare parts
265146207706	OIL SEAL	TATA spare parts
265146207707	OIL SEAL	TATA spare parts
265146207710	RUBBER FLANGE.	TATA spare parts
265146207714	OIL SEAL	TATA spare parts
265146207715	OIL SEAL	TATA spare parts
265146207716	OIL SEAL	TATA spare parts
265146207717	OIL SEAL	TATA spare parts
265146207718	O RING 68.7X2.65 (TS 16220)	TATA spare parts
265146207904	STRG SPINDLE BOTTOM	TATA spare parts
265146207905	STRG SPINDLE TOP	TATA spare parts
265146207916	STRG SPINDLE TOP	TATA spare parts
265146207924	STRG.SPINDLE(MID) 4X2	TATA spare parts
265146208201	SUPPORT TOP	TATA spare parts
265146208203	COVER	TATA spare parts
265146208302	SHIM 0.10 MM	TATA spare parts
265146208303	SHIM 0.15 MM	TATA spare parts
265146208304	SHIM 0.05 MM	TATA spare parts

265146208305	SHIM 0.50 MM	TATA spare parts
265146208306	SHIM 1.00 MM	TATA spare parts
265146208602	SPACER 1.85 MM	TATA spare parts
265146208603	SPACER	TATA spare parts
265146208604	SPACER 1.95 MM	TATA spare parts
265146208605	SPACER	TATA spare parts
265146208606	SPACER	TATA spare parts
265146208607	SPACER	TATA spare parts
265146208608	SPACER 2.15 MM THICK	TATA spare parts
265146208609	SPACER 2.20 MM	TATA spare parts
265146208612	SPACER 2.35 MM	TATA spare parts
265146208614	SPACER 2.45 MM	TATA spare parts
265146209201	WASHER (STG.COLUMN).	TATA spare parts
265146209903	FIXING STRAP RH	TATA spare parts
265146209904	BALL GUIDE HALF RH BS6	TATA spare parts
265146210109	ASSY STEERING COLOUMN 709 SFC TURBO	TATA spare parts
265146210111	ASSY COLUMN WITHOUT STEERING WHEEL	TATA spare parts
265146210113	ASSY SPINDLE	TATA spare parts
265146210115	ASSY STRG SPINDLE SLEEVE	TATA spare parts
265146210118	ASSY.STEERING SPINDLE	TATA spare parts
265146210119	ASSY.SPINDLE	TATA spare parts
265146210131	ASSY STEERING MOUNTING BRACKET	TATA spare parts
265146306005	PITMAN ARM	TATA spare parts
265146306007	PITMAN ARM	TATA spare parts
265146306008	PITMAN ARM RHD	TATA spare parts
265146306009	PITMAN ARM LHD	TATA spare parts
265146306012	PITMAN ARM-RHD(SFC407 POWER STRG)	TATA spare parts
265146400101	STRG WHEEL 425 DIA	TATA spare parts
265146400102	COVER ASSY	TATA spare parts
265146400103	STRG WHEEL	TATA spare parts
265146400106	STRG WHEEL 420 DIA	TATA spare parts
265146400108	ASSY STG WHEEL-420 DIA BLACK	TATA spare parts
265146400111	STRG WHEEL 420 DIA	TATA spare parts
265146400113	ASSY STRG.WHEEL W/O T EMBLEM (SFT TCH)	TATA spare parts
265146600102	ASSY. UNIVERSAL JOINT BS1/2/3/4	TATA spare parts
265146600102AE	ASSY U J 1415 2523	TATA spare parts
265146600104	ASSY. DRAG LINK RHD BS2/3/4	TATA spare parts
265146600106	ASSY.DRAG LINK RHD	TATA spare parts
265146600107	CLAMP	TATA spare parts
265146600108	BALL JOINT	TATA spare parts
265146600109	BALL JOINT	TATA spare parts
265146600111	ASSY.DRAG LINK-LHD	TATA spare parts
265146600116	ASSY.DRAG LINK RHD	TATA spare parts
265146600117	ASSY.DRAG LINK RHD	TATA spare parts
265146600119	ASSY.DRAG LINK RHD	TATA spare parts
265146600122	ASSY DRAG LINK (RHD) OFFER DRG.	TATA spare parts
265146600123	ASSY DRAG LINK (LHD)OFFER DRG.	TATA spare parts

265146600124	ASSY DRAG LINK	TATA spare parts
265146600125	ASSY DRAG LINK	TATA spare parts
265146600126	ASSY DRAG LINK	TATA spare parts
265146600127	DRAG LINK ASSY LHD	TATA spare parts
265146600132	ASSY KIT FOR 26 DIA BALL JOINT-THREADED	TATA spare parts
265146600135	ASSY KIT BALL JOINT 26 DIA-CLAMPED	TATA spare parts
265146600172	CARTRIDGE ASSEMBLY	TATA spare parts
265146603201	BOLT	TATA spare parts
265146603401	NEEDLE BUSH CN 1210	TATA spare parts
265146603402	NEEDLE BUSH	TATA spare parts
265146603403	BEARING NEEDLE CAGE	TATA spare parts
265146603404	NEEDLE BUSH	TATA spare parts
265146603405	NEEDLE BUSH	TATA spare parts
265146605102	CROSS	TATA spare parts
265146607702	SEALING RING	TATA spare parts
265146607703	RUBBER BOOT	TATA spare parts
265146800101	3/8 INCH H.P.HOSE	TATA spare parts
265146800107	ASSY.TUBE 15OD (STG GB TO RESERVOIR)	TATA spare parts
265146800108	ASSY. TUBE (18OD)	TATA spare parts
265146800111	ASSY.TUBE 15 OD (STG GB TO RESERVOIR)	TATA spare parts
265146800117	ASSY. RETURN LINE (POWER STRG.)	TATA spare parts
265146800118	ASSY.PRESSURE PIPE (POWER STRG.)	TATA spare parts
265146800128	ASSY RESERVOIR MTG	TATA spare parts
265146800129	ASSY SUCTION LINE	TATA spare parts
265146805801	RUBBER HOSE.	TATA spare parts
265146805802	SUCTION HOSE (POWER STRG. LINES)	TATA spare parts
265146900102	END ASSY RH	TATA spare parts
265146900103	DRAG LINK END ASSY	TATA spare parts
265147000101	ASSY. FUEL TANK W/STRAP & SUP BS2/3/4	TATA spare parts
265147000102	FUEL TANK	TATA spare parts
265147000107	ASSY.FUEL TANK COMP.WITH STRAP N SUPPORT	TATA spare parts
265147000111	FUEL TANK ASSY WITH STRAP AND SUPPORT BS	TATA spare parts
265147000112	FUEL TANK ASSY WITH STRAP & SUPPORT	TATA spare parts
265147000113	FUEL TANK ASSY WITH STRAP & SUPPORT	TATA spare parts
265147000140	FUEL TANK ASSY WITH STRAP & SUPPORT	TATA spare parts
265147100101	SUCTION TUBE	TATA spare parts
265147100104	FUEL TANK ASSY BS6	TATA spare parts
265147100108	CAP FUEL TANK	TATA spare parts
265147100114	SUCTION TUBE	TATA spare parts
265147100117	FUEL TANK RH	TATA spare parts
265147100121	ASSY CAP-FUEL TANK	TATA spare parts
265147100159	ASSY. SUCTION TUBE	TATA spare parts
265147105301	GASKET FUEL TANK CAP	TATA spare parts
265147107710	COATED ALUMINIUM WASHER WATER SEP.	TATA spare parts
265147109909	CNG CYLINDER(M/S RAMA 267DIA 90LTRS) BS6	TATA spare parts
265147109910	CNG CYLINDER(267DIA;90 LTRS)	TATA spare parts
265147500102	STRAP FUEL TANK	TATA spare parts

265147500104	ASSY BRACKET FUEL TANK MTG.	TATA spare parts
265147500108	ASSY BRACKET FUEL TANK MOUNTING	TATA spare parts
265147500122	BRACKET FUEL TANK MTG	TATA spare parts
265147500124	ASSY.SUPPORT WITH STRAP	TATA spare parts
265147500133	ASSY. STRAP	TATA spare parts
265147500134	ASSY. STRUCTURE WITH RUBBER	TATA spare parts
265147500176	ASSY. BRACKET (FRONT) BS6	TATA spare parts
265147500177	ASSY. BRACKET (REAR -LH) BS6	TATA spare parts
265147500193	ASSY.STRAP WITH RUBBER	TATA spare parts
265147503204	SPECIAL SCREW	TATA spare parts
265147507102	PLATE	TATA spare parts
265147507701	RUBBER PACKING	TATA spare parts
265147507702	RUBBER PACKING	TATA spare parts
265147507718	RUBBER GROMMET	TATA spare parts
265147508229	BRACKET HPR MOUNTING	TATA spare parts
265147508237	GUARD (LPR MOUNTING BRACKET)	TATA spare parts
265147508292	CYLINDER ARRESTOR - FRONT	TATA spare parts
265147509901	CNG CYLINDER(316DIA 45 LTRS.)	TATA spare parts
265147509902	CNG CYLINDER(232DIA 22 LTRS)	TATA spare parts
265147509903	BALATA PACKING	TATA spare parts
265147510121	ASSY. BRACKET (REAR -RH) BS6	TATA spare parts
265147510124	ASSY. BRACKET (RECEPTACLE MOUNTING)	TATA spare parts
265147510133	ASSY.BRACKET (RECEPTACLE MOUNTING)	TATA spare parts
265147510137	ASSY.BRT.(HP SOLENOID & HP FILTER MTG.)	TATA spare parts
265147517101	BRACKET (HPR MOUNTING)	TATA spare parts
265147518272	BRACKET (PR.GAUGE MTG.)	TATA spare parts
265147518277	COMPLIANCE PLATE BS6	TATA spare parts
265147518278	BRACKET	TATA spare parts
265147600104	ASSY FUEL SUCTION LINE	TATA spare parts
265147600106	FUEL RETURN LINE	TATA spare parts
265147600107	FUEL SUCTION LINE	TATA spare parts
265147600108	FUEL SUCTION LINE	TATA spare parts
265147600109	FUEL RETURN LINE	TATA spare parts
265147600113	FUEL SUCTION LINE	TATA spare parts
265147600114	FUEL RETURN LINE	TATA spare parts
265147600117	FUEL SUCTION LINE	TATA spare parts
265147600125	FUEL LINE TANK/HOSE LHD B	TATA spare parts
265147600132	ASSY RETURN FUEL LINE	TATA spare parts
265147600136	ASSY. FUEL SUCTION PIPE	TATA spare parts
265147600153	OVERFLOW PIPE	TATA spare parts
265147600154	ASSY FUEL SUCTION PIPE	TATA spare parts
265147600155	ASSY FUEL SUCTION PIPE	TATA spare parts
265147600161	ASSY.SUCTION PIPE-NYLON TANK TO W/SEP	TATA spare parts
265147600162	ASSY.SUCTION PIPE W/SEP.TO INTAKE	TATA spare parts
265147600164	ASSY.SUCTION LINE-INTAKETO HOSE(CMVR I2K	TATA spare parts
265147600165	ASSY.RETURN LINE.	TATA spare parts
265147600166	ASSY.SUCTION LINE 407-EURO-II HOSE TO IN	TATA spare parts

265147600169	ASSY.SUCTION LINE (W/SEP.TO HOSE)	TATA spare parts
265147600170	ASSY.RETURN LINE	TATA spare parts
265147600171	ASSY. SUCTION FUEL PIPE	TATA spare parts
265147600172	ASSY. RETURN LINE	TATA spare parts
265147600176	ASSY.SUCTION LINE(TANK TO MICO W/SEP)NYL	TATA spare parts
265147600178	ASSY.SUCTION LINE(W/SEP.TO HOSE)	TATA spare parts
265147600179	ASSY. PIPE UNION BOLT	TATA spare parts
265147600185	ASSY TUBE (FOR HEATING CIRCUIT)	TATA spare parts
265147600186	ASSY.TUBE (FOR HEATING CIRCUIT)	TATA spare parts
265147600187	ASSY HOSE (VFF TO LPR)	TATA spare parts
265147600188	ASSY.SUCTION LINE TANK-STRAINER	TATA spare parts
265147600189	ASSY.SUCTION LINE STRAINER- W/SEP	TATA spare parts
265147600190	ASSY.SUCTION LINE W.SEP-FEED PUMP	TATA spare parts
265147600191	ASSY.SUCTION LINE FEED PUMP-ENGINE FILTR	TATA spare parts
265147600192	ASSY.RETURN LINE TANK TO ENGINE	TATA spare parts
265147600193	ASSY.BRACKET (STRAINER MTG.)	TATA spare parts
265147600194	ASSY SUCTION LINE (FUEL TANK 2 STRAINER)	TATA spare parts
265147600198	ASSY RETURN LINE	TATA spare parts
265147603301	BRACKET	TATA spare parts
265147606806	CONNECTOR (LPR OUTLET)	TATA spare parts
265147608202	BRACKET WATER/SEP.WITH HAND PRIMER	TATA spare parts
265147608203	BRACKET (W/SEP. MTG.)407 FES STR.	TATA spare parts
265147608204	BRACKET	TATA spare parts
265147608221	BRACKET	TATA spare parts
265147609911	PLUG	TATA spare parts
265147609912	MALE CONNECTOR	TATA spare parts
265147610105	PLATE ASSY BS6	TATA spare parts
265147610115	ASSY.VENTING TUBE	TATA spare parts
265147610118	ASSY. VENTING TUBE	TATA spare parts
265147610121	ASSY. VENTING TUBE.	TATA spare parts
265147610122	ASSY.VENTING TUBE	TATA spare parts
265147610123	ASSY.VENTING TUBE	TATA spare parts
265147610124	ASSY.VAC.LOCK OFF	TATA spare parts
265147610126	LOW PRESSURE REGULATOR	TATA spare parts
265147610142	ASSY.HOSE (VFF TO LPR)	TATA spare parts
265147610145	ASSY.TUBE (LPR TO MIXER)	TATA spare parts
265147610167	ASSY. HOSE (VFF TO LPR)	TATA spare parts
265147610175	ASSY SUCTION LINE (TANK TO W/SEP)	TATA spare parts
265147610176	ASSY HP CNG PIPE(RH TOP TO LH TOP CYL.)	TATA spare parts
265147610185	ASSY SUCTION LINE (W/SEP TO FUEL FILTER)	TATA spare parts
265147610191	ASSY VENT TUBE	TATA spare parts
265147610194	ASSY VENT PIPE(RH SIDE CYL.TO LOAD BODY)	TATA spare parts
265147610196	ASSY. RETURN LINE (ENGINE TO TANK)	TATA spare parts
265147615802	RUBBER HOSE(VAC.LOCK OFF TO MIXER)	TATA spare parts
265147615803	HOSE	TATA spare parts
265147615805	HOSE	TATA spare parts
265147615806	HOSE	TATA spare parts

265147615808	HOSE	TATA spare parts
265147615809	HOSE	TATA spare parts
265147618208	PLATE TOP BS6	TATA spare parts
265147619901	CONNECTOR(1/8INCH NPT / 4.5MM HOSE)	TATA spare parts
265147619902	CONNECTOR	TATA spare parts
265147619903	T CONNECTOR	TATA spare parts
265147619904	ELBOW CONNECTOR	TATA spare parts
265147619905	JET	TATA spare parts
265147619907	T CONNECTOR	TATA spare parts
265147619916	REDUCER (M18X1.5 TO M30X2)	TATA spare parts
265147619918	JET(SFC-407)	TATA spare parts
265147620103	ASSY SINGLE CLAMP WITH BRACKET	TATA spare parts
265147620106	ASSY.DOUBLE CLAMP WITH BRACKET	TATA spare parts
265147620111	ASSY HP CNG PIPE(3 WAY VALVE TO FILTER)	TATA spare parts
265147620112	ASSY HP CNG PIPE(FILTER TO SOLENOID-1)	TATA spare parts
265147620113	ASSY HP CNG PIPE(SOLENOID TO SENSOR)	TATA spare parts
265147620114	ASSY HP CNG PIPE(SENSOR TO SOLENOID)	TATA spare parts
265147620115	ASSY HP CNG PIPE(HP SOLENOID TO HPR)	TATA spare parts
265147620119	HP PIPE ASSY NGV RECP TO 3-WAY VALVE BS6	TATA spare parts
265147620127	ASSY.SUCTION LINE(FUELTANK TO SEDIMENTOR	TATA spare parts
265147620131	ASSY. SUCTION LINE (FUEL FILTER TO FIP)	TATA spare parts
265147620132	ASSY. SUCTION LINE(FT TO WS)	TATA spare parts
265147620133	ASSY.SUCTION LINE(W/S TO MECH FEED PUMP)	TATA spare parts
265147620134	ASSY.RETURN LINE(ENG. OVERFLOW TO TANK)	TATA spare parts
265147620135	ASSY RETURN LINE (COMPLETE)	TATA spare parts
265147620136	ASSY.SUCTION LINE(FUEL FILTER TO FIP)	TATA spare parts
265147620137	ASSY.SUCTION LINE(FUEL TANK TO SEDIMENT)	TATA spare parts
265147620139	ASSY PRIMING PUMP	TATA spare parts
265147620142	ASSY RETURN LINE (COMPLETE)	TATA spare parts
265147700101	ASSY. HIGH.PR.REGULATOR (SFC 407 CNG)	TATA spare parts
265147700105	ASSY. NGV RECEPTACLE	TATA spare parts
265147700106	GAS SOLENOID 12 V	TATA spare parts
265147700107	ASSY.HIGH.PR.REGULATOR (CLH)	TATA spare parts
265147700111	REFILLING VALVE	TATA spare parts
265147706801	CONNECTOR STRAIGHT 1/4IN NPTX1/2-20UNF	TATA spare parts
265147706802	CONNECTOR STRAIGHT 1/4IN NPTX7/8-14UNF	TATA spare parts
265149100106	EXH TAIL PIPE	TATA spare parts
265149100114	ASSY.SILENCER	TATA spare parts
265149100115	ASSEMBLY SILENCER 407	TATA spare parts
265149100130	ASSY.SILENCER WITH BRACKETS	TATA spare parts
265149100131	ASSY.SILENCER WITH BRACKETS.	TATA spare parts
265149100132	ASSY.SILENCER WITH TAIL PIPE (FOR 2750 W	TATA spare parts
265149100138	ASSY EXHAUST PIPE - DPS SENSOR (OUTLET)	TATA spare parts
265149100140	ASSY EXHAUST PIPE - DPS SENSOR (INLET)	TATA spare parts
265149105801	HOSE (DPS SENSOR)	TATA spare parts
265149106907	EXH TAIL PIPE	TATA spare parts
265149200101	EXHAUST HANGER	TATA spare parts

265149200113	EXHAUST PIPE FR 31WB RHD	TATA spare parts
265149200114	EXHAUST PIPE FR 27WB RHD	TATA spare parts
265149200115	HEAT SHIELD ASSY	TATA spare parts
265149200118	ASSY. EXHAUST PIPE FRONT-RHD	TATA spare parts
265149200181	EXHAUST PIPE FRT LP407	TATA spare parts
265149200182	ASSY EXHAUST PIPE	TATA spare parts
265149200184	ASSEMBLY BRACKET	TATA spare parts
265149200186	ASSY SILENCER 407 CMVR	TATA spare parts
265149200189	ASSY EX PIPE FT407 CMVR	TATA spare parts
265149200192	ASSY.SILENCER WITH TAIL PIPE	TATA spare parts
265149200193	ASSY.EX.PIPE FRONT ALUMN PAINT-SS:7345	TATA spare parts
265149200194	ASSY.EX.PIPE-INTER ALUMN PAINT-SS:7345	TATA spare parts
265149200198	ASSEMBLY PLATE	TATA spare parts
265149203309	BRACKET	TATA spare parts
265149203314	BRACKET	TATA spare parts
265149205301	GASKET EXH MANIFOLD ELBOW	TATA spare parts
265149206974	EXHAUST TAIL PIPE	TATA spare parts
265149206978	EXHAUST PIPE REAR	TATA spare parts
265149207108	FLANGE	TATA spare parts
265149208219	CLAMP	TATA spare parts
265149208220	BRACKET FRONT	TATA spare parts
265149208249	BRACKET	TATA spare parts
265149208250	BRACKET	TATA spare parts
265149208274	BRACKET-EXHAUST PIPE AND SILENCER MTG	TATA spare parts
265149208277	CLAMP (68 DIA)	TATA spare parts
265149208289	BRACKET	TATA spare parts
265149210101	ASSY.BRACKET (LH)	TATA spare parts
265149210104	ASSY.SILENCER WITH TAIL PIPE-DOMESTIC	TATA spare parts
265149210105	ASSY.BRACKET-SFC 407 TWIN TYRE	TATA spare parts
265149210106	ASSY.SILENCER-RH (407 TWIN TYRE REAR AXL	TATA spare parts
265149210108	ASSY EXHAUST PIPE FRONT	TATA spare parts
265149210112	ASSY. SILENCER WITH TAIL PIPE	TATA spare parts
265149210128	ASSY.BOTTOM NOISE SHIELD - REAR	TATA spare parts
265149210137	ASSY.BRACKET	TATA spare parts
265149210138	ASSY.BRACKET	TATA spare parts
265149210145	ASSY.BOTTOM NOISE SHIELD FRONT	TATA spare parts
265149210147	ASSY.BOTTOM NOISE SHIELD FLAP FRONT	TATA spare parts
265149210149	ASSY. BRACKET	TATA spare parts
265149210155	ASSY.EXHAUST PIPE FRONT	TATA spare parts
265149210170	ASSY FRONT EXHAUST PIPE	TATA spare parts
265149210172	ASSY.FRONT EXHAUST PIPE (BS-III)	TATA spare parts
265149210173	ASSY.EXHAUST PIPE FRONT (27 W.B.)	TATA spare parts
265149210174	ASSY BRACKET	TATA spare parts
265149210176	ASSY .FRONT PIPE	TATA spare parts
265149210177	ASSY.REDUCER	TATA spare parts
265149210178	ASSY.FRONT EXHAUST PIPE WITH FLEX.BELLOW	TATA spare parts
265149210180	ASSY.FLEXIBLE BELLOW	TATA spare parts



265149210180DF	FLEX CONNECTOR STD-72X152	TATA spare parts
265149210180DFEX	FLEX CONNECTOR STD-72X152 LONG LIFE	TATA spare parts
265149210180DFEXLL	FLEX CONNECTOR STD-73X152 W/EXTENSION	TATA spare parts
265149210180DFLL	FLEX CONNECTOR STD-73X152 W/EXT LONG LIF	TATA spare parts
265149210181	ASSY.FRONT PIPE (2750 W.B. BS-III)	TATA spare parts
265149210182	ASSY.FRONT PIPE WITH FLEX.BELLOW (BS-II)	TATA spare parts
265149210183	ASSY.FRT.PIPE WITH FLEX.BELLOW(BS-II 27)	TATA spare parts
265149210184	ASSY BRACKET	TATA spare parts
265149210185	ASSY. FRONT PIPE	TATA spare parts
265149210186	ASSY PIPE	TATA spare parts
265149210196	ASSY.FRT.EXHAUST PIPE WITH FLEX.BELLOW	TATA spare parts
265149210197	ASSY. FRONT EXHAUST PIPE	TATA spare parts
265149210198	ASSY. FRONT EXHAUST PIPE WITH FLEX. BELL	TATA spare parts
265149210199	ASSY.FRONT EXHAUST PIPE WITH FLEX BELLOW	TATA spare parts
265154100105	ASSY BATT CABLE + VE	TATA spare parts
265154100106	BATTERY CABLE -VE	TATA spare parts
265154100107	BRACKET MAXI FUSE & MIDI FUSE MTG.	TATA spare parts
265154100114	ASSY.BATT.CABLE -VE 2.5LG W/COT 50SQ.MM	TATA spare parts
265154100115	BATTERY CABLE +VE	TATA spare parts
265154100118	ASSY CLAMP	TATA spare parts
265154100122	BATTERY CABLE NEGATIVE	TATA spare parts
265154100124	BATTERY CABLE +VE	TATA spare parts
265154100125	BATTERY CABLE -VE	TATA spare parts
265154100150	ASSY.BATT.CABLE +VE [2100 LG.]50MM.SQ.	TATA spare parts
265154100151	ASSY.BATT.CABLE -VE [2600 LG] 50MM SQ.	TATA spare parts
265154100154	ASSY.BATT.CABLE +VE - SFC 407 CNG	TATA spare parts
265154100155	ASSY.BATT.CABLE -VE SFC 407 CNG.	TATA spare parts
265154100160	ASSY.BATT.CABLE -VE 1.2M W/COT 35SQ.MM	TATA spare parts
265154100162	BATTERY CABLE +VE 50SQMM RED L=650MM	TATA spare parts
265154100165	ASSY.BATT.CABLE +VE 1.8LG W/COT 50SQ.MM	TATA spare parts
265154100166	ASSY.BATT. CABLE -VE 2.3LG W/COT 50SQ.MM	TATA spare parts
265154100167	ASSY. BATT. CABLE -VE 2.1M W/COT TUBE	TATA spare parts
265154100170	ASSY.BATTERY CABLE +VE 1950MM 50SQ MM	TATA spare parts
265154100171	ASSY.BATT.CABLE -VE 1850MM 50SQ MM	TATA spare parts
265154100172	ASSY.BATTERY CABLE -VE 2050MM 50SQ MM	TATA spare parts
265154100175	ASSY.BATTERY CABLE - VE 400MM 35 SQ MM	TATA spare parts
265154100177	ASSY BATTERY CABLE POSITIVE 1950MM 35SQ	TATA spare parts
265154100178	ASSY BATTERY CABLE -VE 335MM LENGTH BOTH	TATA spare parts
265154103201	CLAMPING STUD	TATA spare parts
265154106301	BATTERY TRAY	TATA spare parts
265154107501	CAP FOR BATTERY CLAMP	TATA spare parts
265154107506	GROMMET	TATA spare parts
265154108206	CLAMP	TATA spare parts
265154108233	CLAMP 222	TATA spare parts
265154108801	STUD	TATA spare parts
265154108802	STUD	TATA spare parts
265154108803	STUD	TATA spare parts

265154108804	BENT STUD	TATA spare parts
265154109930	BATTERY COVER	TATA spare parts
265154200101	TANK UNIT	TATA spare parts
265154200104	TANK UNIT	TATA spare parts
265154200117	COOLENT LEVEL SENSOR FOR SFC	TATA spare parts
265154200158	ELECTRIC BUZZER UNIT	TATA spare parts
265154200158AE	ELECTRIC BUZZER HRNSS -1628	TATA spare parts
265154200159	ASSY.INSTR.CLUSTER 1:0.935	TATA spare parts
265154200160	INSTRUMENT CLUSTER-1:0.935 OFFER DRG.	TATA spare parts
265154200161	ASSY.INSTR.CLUSTER 1:0.935	TATA spare parts
265154200164	ASSY.INSTR.CLUSTER 1:0.935	TATA spare parts
265154200173	ASSY.BUZZER UNIT	TATA spare parts
265154200174	ASSY.BUZZER UNIT	TATA spare parts
265154200175	ASSY.BUZZER UNIT	TATA spare parts
265154200176	ASSY.BUZZER UNIT	TATA spare parts
265154200177	ASSY.BUZZER UNIT	TATA spare parts
265154200179	ASSY BUZZER UNIT (REVERSE INDICATOR) IND	TATA spare parts
265154200180	TANK UNIT	TATA spare parts
265154200181	FUEL TANK UNIT	TATA spare parts
265154200182	TANK UNIT	TATA spare parts
265154200188	ASSY.BUZZER UNIT	TATA spare parts
265154200189	FUEL TANK UNIT	TATA spare parts
265154200190	BUZZER UNIT	TATA spare parts
265154200191	ASSY.BUZZER UNIT	TATA spare parts
265154200193	ASSY.BUZZER UNIT	TATA spare parts
265154200194	ASSY.BUZZER UNIT	TATA spare parts
265154200195	ASSY BUZZER UNIT (REVERSE INDICATOR) IND	TATA spare parts
265154200196	ASSY.BUZZER UNIT	TATA spare parts
265154200199	ASSY. HORN MTG.BRACKET	TATA spare parts
265154202001	HORN (Telco) with `RIS' CAPACITOR	TATA spare parts
265154202007	HORN 12V	TATA spare parts
265154202013	HORN 12V WITH PIG TAIL	TATA spare parts
265154202015	HORN 12V W/O RIS CAPACITOR-100DIA	TATA spare parts
265154202016	HORN 12V W/O RIS CAPACITOR	TATA spare parts
265154206304	COVER (RELAY & FUSE BOX)W/HEATING DEMIST	TATA spare parts
265154206305	COVER (RELAYS & FUSE BOX) LPT/SFC407	TATA spare parts
265154206306	COVER (RELAYS & FUSE BOX)SFC/LPT407 BSII	TATA spare parts
265154208270	VEHICLE SPEED SENSOR 12/24V 8PULSE BS3/4	TATA spare parts
265154209901	GAUGE FUEL	TATA spare parts
265154209902	TEMP GAUGE	TATA spare parts
265154209904	SPEEDOMETER 1:1	TATA spare parts
265154209905	SPEEDO METER	TATA spare parts
265154209907	TANK UNIT	TATA spare parts
265154209908	SPEEDOMETER 1:1	TATA spare parts
265154209909	FUEL GAUGE	TATA spare parts
265154209910	TEMP GAUGE	TATA spare parts
265154209915	SPEEDOMETER 1:1.04	TATA spare parts

265154209918	3.2D SPEEDOCABLE 2200 lg.(DIN)M/s.PRICOL	TATA spare parts
265154209927	SPEEDOCABLE 2100MM 3.2D	TATA spare parts
265154209928	SPEEDOCABLE 2100MM 3.2D	TATA spare parts
265154209930	SPEEDOCABLE 2100MM 3.2D	TATA spare parts
265154209932	FUEL GAUGE	TATA spare parts
265154209933	TEMP.GAUGE	TATA spare parts
265154209937	SPEEDOMETER 1:0.78 6+1	TATA spare parts
265154209938	SPEEDOMETER-1:0:935	TATA spare parts
265154209939	SPEEDOMETER 1:0.935 6+1	TATA spare parts
265154209948	SPEEDOMETER-1:0.875-6+1 DIGIT	TATA spare parts
265154209954	SPEEDOMETER 1:0.875 6+1DIGIT	TATA spare parts
265154209955	SPEEDOMETER [1:0.875] 6+1DIGIT	TATA spare parts
265154209956	SPEEDOMETER 1:0.875 6+1DIGIT	TATA spare parts
265154209959	FUEL GAUGE	TATA spare parts
265154209960	TEMP GAUGE	TATA spare parts
265154209986	SPEEDOCABLE [JIS] 2100 LG OFFER	TATA spare parts
265154209987	SPEEDOCABLE JIS 2000 LG	TATA spare parts
265154209988	SPEEDOCABLE JIS 2000 LG.	TATA spare parts
265154209989	SPEEDOCABLE 2000MM JIS	TATA spare parts
265154209995	SPEEDOMETER	TATA spare parts
265154209997	SPEEDOMETER[1:0.875] 6+1DIGIT	TATA spare parts
265154210101	FUEL TANK UNIT	TATA spare parts
265154210119	INSTRUMENT CLUSTER (1:0.935) OFFER-CMVR	TATA spare parts
265154210120	INSTRUMENT CLUSTER-1:0.935	TATA spare parts
265154210122	INSTRUMENT CLUSTER (1:0.935) -OFFER	TATA spare parts
265154210123	INSTRUMENT CLUSTER-1:0.935	TATA spare parts
265154210124	INSTRUMENT CLUSTER-1:0.935	TATA spare parts
265154210125	INSTRUMENT CLUSTER (1:0.935) OFFER	TATA spare parts
265154210129	ASSY.TANK UNIT	TATA spare parts
265154210136	ASSY.TANK UNIT	TATA spare parts
265154210137	ASSY.TANK UNIT	TATA spare parts
265154210139	INST CLUSTER 1:0.95 SOFT-TOP	TATA spare parts
265154210140	INSTRUMENT CLUSTER (1:0.95)	TATA spare parts
265154210143	INSTRUMENT CLUSTER-1:0.935	TATA spare parts
265154210144	INSTRUMENT CLUSTER-1:0.935	TATA spare parts
265154210149	W/H INST. CLUSTER	TATA spare parts
265154210150	INSTRUMENT CLUSTER (1:0.78) OFFER DRG	TATA spare parts
265154210151	INSTRUMENT CLUSTER-1:0.78	TATA spare parts
265154210152	INSTRUMENT CLUSTER-1:0.78	TATA spare parts
265154210154	INSTRUMENT CLUSTER (1:0.8625) OFFER DRG	TATA spare parts
265154210155	INSTRUMENT CLUSTER-1:0.8625	TATA spare parts
265154210156	INSTRUMENT CLUSTER-1:0.8625	TATA spare parts
265154210161	ASSY.TANK UNIT	TATA spare parts
265154210163	INSTRUMENT CLUSTER (1:0.78)	TATA spare parts
265154210169	INSTRUMENT CLUSTER (1:0.78)	TATA spare parts
265154210172	ASSY BRACKET (HORN MTG.)	TATA spare parts
265154210174	INSTRUMENT CLUSTER-1:0.72	TATA spare parts

265154210175	INSTRUMENT CLUSTER-1:0.72	TATA spare parts
265154210176	INSTRUMENT CLUSTER-1:0.72	TATA spare parts
265154210181	INSTRUMENT CLUSTER 1:0.95	TATA spare parts
265154210182	INSTRUMENT CLUSTER 1:0.95	TATA spare parts
265154210183	INSTRUMENT CLUSTER 1:0.95	TATA spare parts
265154210184	INSTRUMENT CLUSTER 1:0.72 EUROIII	TATA spare parts
265154210185	INSTRUMENT CLUSTER (1:0.81)	TATA spare parts
265154210186	INSTRUMENT CLUSTER (1:0.81)	TATA spare parts
265154210187	INSTRUMENT CLUSTER (1:0.81)	TATA spare parts
265154210192	INSTRUMENT CLUSTER 1:0.72 EUROIII	TATA spare parts
265154210193	INSTRUMENT CLUSTER 1:0.72 EUROIII	TATA spare parts
265154210194	ASSY. ECU MOUNTING BRACKET	TATA spare parts
265154210195	INST.CLUSTER-(1:0.72)-SFC407CNG	TATA spare parts
265154210196	ASSY BRACKET FOR FUSE AND RELAYS BASE	TATA spare parts
265154219901	FUEL GAUGE	TATA spare parts
265154219902	TEMP. GAUGE	TATA spare parts
265154219908	MAGNETIC VALVE	TATA spare parts
265154219909	MAGNETIC VALVE	TATA spare parts
265154219910	MAGNETIC VALVE W/TER&HSG	TATA spare parts
265154219911	MAGNETIC VALVE W/TER&HSG	TATA spare parts
265154219913	SPEEDOMETER LP 407	TATA spare parts
265154219915	SPEEDOMETER 1:0.935 (6+1)BACKLIT	TATA spare parts
265154219916	ELECTRIC BUZZER-OFFER	TATA spare parts
265154219923	SPEEDOCABLE (JIS) 2000MM	TATA spare parts
265154219938	SPEEDOCABLE [JIS] 2100 LG	TATA spare parts
265154219939	SPEEDOCABLE [JIS] 2100 LG	TATA spare parts
265154219940	SPEEDOCABLE [JIS] 2100 LG	TATA spare parts
265154219942	MAGNETIC VALVE	TATA spare parts
265154219943	HORN 12V W/O RIS	TATA spare parts
265154219944	HORN 12V W/O RIS	TATA spare parts
265154219945	HORN 12V W/O RIS	TATA spare parts
265154219946	HORN 12V W/O RIS	TATA spare parts
265154219947	HORN 12V W/O RIS	TATA spare parts
265154219948	HORN 12V W/O RIS	TATA spare parts
265154219949	HORN 12V W/O RIS	TATA spare parts
265154219950	ENGINE STOP DELAY TIME	TATA spare parts
265154219952	SPEEDOMETER (1:0.935) (4X2) SFC407	TATA spare parts
265154219954	MAGNETIC VALVE W/TER&HSG	TATA spare parts
265154219958	FUEL GAUGE	TATA spare parts
265154219959	TEMP GAUGE	TATA spare parts
265154219962	SPEEDOMETER RATIO 0.95	TATA spare parts
265154219963	SPEEDOMETER RATIO 0.935	TATA spare parts
265154219964	SPEEDOMETER RATIO 0.8625	TATA spare parts
265154219965	SPEEDOMETER (1:0.8625)	TATA spare parts
265154219969	MAGNETIC VALVE W/TER&HSG	TATA spare parts
265154219970	SPEEDOMETER (1:0.72)	TATA spare parts
265154219983	STICKER FOR ECU - ENGLISH	TATA spare parts

265154219984	STICKER FOR ECU - HINDI	TATA spare parts
265154219985	SPEEDOMETER RATIO 0.66	TATA spare parts
265154219987	SPEEDOMETER RATIO 0.66	TATA spare parts
265154219998	SPEEDOMETER RATIO 0.80	TATA spare parts
265154219999	SPEEDOMETER RATIO - 0.64	TATA spare parts
265154220101	FUEL CONTROL VALVE	TATA spare parts
265154220102	VACUUM CONTROL SOLENOID	TATA spare parts
265154220106	INSTRUMENT CLUSTER 1:0.66 BS-III	TATA spare parts
265154220115	INSTRUMENT CLUSTER 1:0.72 CRPF	TATA spare parts
265154220121	INST.CLUSTER 0.80 SFC407 MECH.SPEEDO	TATA spare parts
265154220125	INST.CLUSTER-(1:0.8625)-SFC 407 CNG	TATA spare parts
265154220134	INSTRUMENT CLUSTER ESPEEDO¿ 0.78	TATA spare parts
265154220139	INST CLUST ESPEEDO SFC407 0.78	TATA spare parts
265154220142	INST CLUST ESPEEDO SFC410 0.78	TATA spare parts
265154220152	INST. CLUSTER 1:0.78 SFC407/27WB-IND	TATA spare parts
265154220153	INST. CLUSTER 1:0.88 SK407/31WB	TATA spare parts
265154220158	INSTRUMENT CLUSTER SFC410 0.68 W/O EXH.	TATA spare parts
265154220159	INSTRUMENT CLUSTER SFC410 0.76 W/O APG.	TATA spare parts
265154220160	INSTRUMENT CLUSTER¿ SK410 0.80 WITH PTO	TATA spare parts
265154220162	INSTRUMENT CLUSTER SFC912 0.64 W/O PTO	TATA spare parts
265154220163	INSTRUMENT CLUSTER¿ SFC912 0.64 WITH PTO	TATA spare parts
265154220166	INSTRUMENT CLUSTER¿ SK410 0.80 WITH PTO	TATA spare parts
265154220176	INSTRUMENT CLUSTER SFC410 0.80 W/O PTO B	TATA spare parts
265154220177	INSTRUMENT CLUSTER SFC410 0.80 W/O PTO B	TATA spare parts
265154220179	INST.CLUSTER 1:0.80 SFC 407 WITH EMOS	TATA spare parts
265154220184	INST CLUSTER ESPEEDO SFC 407CNG 0.72	TATA spare parts
265154220190	INSTRUMENT CLUSTER SFC410 0.65 RATIO BS	TATA spare parts
265154220191	INSTRUMENT CLUSTER SFC410 0.65 RATIO	TATA spare parts
265154220192	INSTRUMENT CLUSTER SFC410(4X4) 0.76 RATI	TATA spare parts
265154220193	INSTRUMENT CLUSTER¿ 0.76	TATA spare parts
265154220196	INSTRUMENT CLUSTER SFC410(4X4)_ WITH PTO	TATA spare parts
265154220198	INST.CLUSTER SFC407 RATIO 0.65 WITH DANDA	TATA spare parts
265154229902	SPEEDOMETER RATIO - 0.78	TATA spare parts
265154229904	SPEEDOMETER RATIO 0.80 MOVEMENT (12V)	TATA spare parts
265154229906	SPEEDOMETER RATIO 0.78-IND	TATA spare parts
265154229908	SPEEDOMETER RATIO 0.68	TATA spare parts
265154229914	SPEEDO METER 0.65 RATIO	TATA spare parts
265154230101	INST.CLUSTER SFC407 RATIO 0.65 WITH DAND	TATA spare parts
265154400101	ENGINE LAMP	TATA spare parts
265154400102	HEAD LAMP RH	TATA spare parts
265154400103	HEAD LAMP LH	TATA spare parts
265154400105	ASSYLAMP-WARNING END	TATA spare parts
265154400106	BLINKER LAMP LH	TATA spare parts
265154400107	BLINKER LAMP RH	TATA spare parts
265154400108	TURN INDICATOR LAMP	TATA spare parts
265154400109	INDICATOR LAMP HI BEAM	TATA spare parts
265154400111	ENGINE LAMP	TATA spare parts

265154400118	BLINKER LAMP RH	TATA spare parts
265154400119	BLINKER LAMP LH	TATA spare parts
265154400122	ASSY HEAD LAMP RH WITH BULB	TATA spare parts
265154400123	ASSY HEAD LAMP LH WITH BULB	TATA spare parts
265154400124	ASSY HEAD LAMP RH WITH BULB	TATA spare parts
265154400125	ASSY HEAD LAMP LH WITH BULB	TATA spare parts
265154400132	ASSY HEADLAMP WITH BULB[RH]	TATA spare parts
265154400133	ASSY HEADLAMP WITH BULB[LH]	TATA spare parts
265154400140	TURN INDICATOR LAMP	TATA spare parts
265154400141	INDICATOR LAMP BATT	TATA spare parts
265154400142	INDICATOR LAMP ENG OIL	TATA spare parts
265154400143	INDICATOR LAMP HI BEAM	TATA spare parts
265154400145	HEAD LAMP RH LHD	TATA spare parts
265154400146	ASSY HEAD LAMP LH LHD-E CERT	TATA spare parts
265154400150	ASSY HEAD LAMP WITH BULB RH	TATA spare parts
265154400152	ASSY HEAD LAMP WITH BULB LH	TATA spare parts
265154400155	ASSY INDICATOR LAMP {BRAKE FLUID}	TATA spare parts
265154400158	ASSY HEAD LAMP RH RHD	TATA spare parts
265154400159	ASSY HEAD LAMP LH RHD	TATA spare parts
265154400169	TAIL LAMP LH	TATA spare parts
265154400170	TAIL LAMP RH	TATA spare parts
265154400173	ASSY BLINKER LAMP WITH BULB RH	TATA spare parts
265154400174	BLINKER LAMP LH	TATA spare parts
265154400175	BLINKER LAMP LH	TATA spare parts
265154400176	ASSY BLINKER LAMP WITH BULB RH	TATA spare parts
265154400181	WARNING IND LAMP	TATA spare parts
265154400182	TURN INDICATOR LAMP	TATA spare parts
265154400186	ASSY HEAD LAMP RH WITH BULB-RHD	TATA spare parts
265154400187	ASSY HEAD LAMP LH WITH BULB-RHD	TATA spare parts
265154400188	ASSY HEAD LAMP WITH BULBS RH-RHD OFFER	TATA spare parts
265154400189	ASSY HEAD LAMP WITH BULBS LH- RHD OFFER	TATA spare parts
265154400190	ASSY HEAD LAMP RH	TATA spare parts
265154400191	ASSY HEAD LAMP LH	TATA spare parts
265154400194	ASSY BLINKER LAMP WITH BULB RH	TATA spare parts
265154400195	BLINKER LAMP LH	TATA spare parts
265154400196	ASSY BLINKER LAMP RH WITH `E' CERTIFCN.	TATA spare parts
265154400197	ASSY BLINKER LAMP LH WITH `E' CERTIFCN.	TATA spare parts
265154400199	ASSY INDICATOR LAMP	TATA spare parts
265154400201	ASSY. COMBI HEAD LAMP LH 12V RHD BS3/4	TATA spare parts
265154400202	ASSY. COMBI HEAD LAMP 12V RH BS3/4	TATA spare parts
265154400205	ASSY.HEAD LAMP COMBI 24V RHD RH BS3/4	TATA spare parts
265154400206	ASSY. LAMP COMBI H/L 24V RHD LH BS3/4/6	TATA spare parts
265154401603	ASSY.SIDE REPEATER LAMP(CLEAR LENS)	TATA spare parts
265154407502	RUBBER BOOT - BLINKER	TATA spare parts
265154407503	RUBBER BOOT - BLINKER	TATA spare parts
265154408213	CLAMP {RELAY}	TATA spare parts
265154408222	BRACKET (FOG LAMP)	TATA spare parts

265154408224	BRACKET-TAIL LAMP	TATA spare parts
265154408230	REAR FOG LAMP MTG.BRACKET	TATA spare parts
265154409902	NYLON BUSH HEADLAMP CATCHER BS6	TATA spare parts
265154409915	REFLEX REFLECTOR-WHITE `E'CERT	TATA spare parts
265154409917	ASSY REFLEX REFLECTOR	TATA spare parts
265154409918	ASSY.REFLEX REFLECTOR-WHITE	TATA spare parts
265154409919	FRONT FOG LAMP 12V E CERT	TATA spare parts
265154409922	REFLEX REFLECTOR WHITE-E'CERT-	TATA spare parts
265154410101	ASSY WARNING INDICATOR	TATA spare parts
265154410102	ASSY WARNING INDICATOR	TATA spare parts
265154410107	ASSY BLINKER LAMP RH WITH `E' CERTIFCN.	TATA spare parts
265154410108	ASSY BLINKER LAMP LH WITH `E' CERTIFCN.	TATA spare parts
265154410113	ASSY HEAD LAMP LH RHD	TATA spare parts
265154410115	ASSY HEAD LAMP RH RHD	TATA spare parts
265154410121	HD LAMP RH RHD	TATA spare parts
265154410123	ASSY HEAD LAMP LH RHD-E CERT	TATA spare parts
265154410136	ASSY.TURN INDICATOR LAMP	TATA spare parts
265154410137	ASSY TURN INDICATOR LAMP	TATA spare parts
265154410138	ASSY. WARNING LAMP	TATA spare parts
265154410139	ASSY. WARNING LAMP	TATA spare parts
265154410140	ASSY. WARNING LAMP	TATA spare parts
265154410141	ASSY. WARNING LAMP	TATA spare parts
265154410150	ASSY BLINKER LAMP LH WITH `E' CERTIFCN.	TATA spare parts
265154410152	ASSY BLINKER LAMP RH WITH `E' CERTIFCN.	TATA spare parts
265154410167	ASSY TURN INDICATOR LAMP	TATA spare parts
265154410168	ASSY. WARNING LAMP	TATA spare parts
265154410170	ASSY. WARNING LAMP	TATA spare parts
265154410174	TURN INDICATOR LAMP	TATA spare parts
265154410175	ASSY. WARNING LAMP	TATA spare parts
265154410180	ASSY. WARNING LAMP	TATA spare parts
265154410185	ASSY WARNING IND LAMP	TATA spare parts
265154410195	ASSY.TURN IND.LAMP	TATA spare parts
265154410196	ASSY. WARNING LAMP	TATA spare parts
265154410198	ASSY. WARNING LAMP	TATA spare parts
265154420105	ASSY ENGINE LAMP	TATA spare parts
265154420106	ASSY HEAD LAMP RH WITH BULB-RHD	TATA spare parts
265154420107	ASSY HEAD LAMP LH WITH BULB-RHD	TATA spare parts
265154420116	ASSY TAIL LAMP WITH BKT RH	TATA spare parts
265154420118	ASSY TAIL LAMP WITH BKT RH	TATA spare parts
265154420120	ASSY TAIL LAMP WITH BKT LH	TATA spare parts
265154420122	ASSY TAIL LAMP WITH BKT LH	TATA spare parts
265154420189	ASSY.T/LAMP W/BKT.RH 12V `E'	TATA spare parts
265154420190	ASSY.T/LAMP W/BKT.LH 12V `E'	TATA spare parts
265154420193	ASSY CAB LAMP	TATA spare parts
265154420198	ASSY CAB LAMP	TATA spare parts
265154430114	ASSY.ENGINE LAMP W/12V BULB	TATA spare parts
265154430117	ASSY. ENGINE LAMP	TATA spare parts

265154430118	ASSY.SIDE REPEATER LAMP(CLEAR LENS)	TATA spare parts
265154430119	ASSY.SIDE REPEATER LAMP(CLEAR LENS)	TATA spare parts
265154440185	ASSY.T/LAMP.W/BKT RH 12V	TATA spare parts
265154440186	ASSY.T/LAMP W/BKT LH 12V	TATA spare parts
265154500103	COMBI SWITCH	TATA spare parts
265154500104	STOP LIGHT SWITCH	TATA spare parts
265154500107	BRACKET TAIL LAMP LH	TATA spare parts
265154500109	FUSE BOX 12 POLE	TATA spare parts
265154500112	ASSY TAIL LAMP BKT.(WELDED)-LH	TATA spare parts
265154500113	ASSY TAIL LAMP BKT.(WELDED)-RH	TATA spare parts
265154500114	PUSH PULL SWITCH	TATA spare parts
265154500116	COMBI SWITCH	TATA spare parts
265154500125	FUSE BOX 12 POLE	TATA spare parts
265154500132	COMBI SWITCH RHD	TATA spare parts
265154500134	STOP LIGHT SWITCH	TATA spare parts
265154500135	STOP LIGHT SWITCH	TATA spare parts
265154500136	STOP LIGHT SWITCH MECH	TATA spare parts
265154500142	ASSY FUSE BOX-12 POLE	TATA spare parts
265154500154	STOP LIGHT SWITCH	TATA spare parts
265154500158	FUSE BOX	TATA spare parts
265154500162	FUSE BOX COVER W/KNOB	TATA spare parts
265154500167	FUSE HOLDER ASSY. 80 A	TATA spare parts
265154500168	ASSY BUZZER UNIT (REVERSE INDICATOR) IND	TATA spare parts
265154500169	ASSY BUZZER UNIT (REVERSE INDICATOR) IND	TATA spare parts
265154500170	ASSY.BUZZER UNIT W/IND.TR	TATA spare parts
265154500171	ASSY.BUZZER UNIT W/IND.TRS CONN-WINT	TATA spare parts
265154500172	ASSY BUZZER UNIT (REVERSE INDICATOR) IND	TATA spare parts
265154500176	ASSY BUZZER UNIT (REVERSE INDICATOR) IND	TATA spare parts
265154500177	ASSY BUZZER UNIT (REVERSE INDICATOR) IND	TATA spare parts
265154500178	2-SPEED BLOWER SWITCH	TATA spare parts
265154500179	ELECTRONIC FLASHER KIT-12 V	TATA spare parts
265154500180	IC.FLASHER.W/MTG.BKT.W/O.CONN.	TATA spare parts
265154500182	FLASHER SQ.12V WITH BKT	TATA spare parts
265154500183	SL SWITCH SAFARI 4X4	TATA spare parts
265154500188	STOP LIGHT SWITCH	TATA spare parts
265154500189	ASSY. COMBI SWITCH RHD	TATA spare parts
265154504601	KIT FOR HAZARD WARNING SW.	TATA spare parts
265154504602	HAZARD WARNING SWITCH[M/S PEC ]	TATA spare parts
265154504603	FLASHER SQ 12V	TATA spare parts
265154504604	HAZARD WARNING SWITCH - OFFER	TATA spare parts
265154504900	FUSE 80A	TATA spare parts
265154506301	FUSE BOX COVER	TATA spare parts
265154506901	PIANO SWITCH	TATA spare parts
265154506902	PIANO SWITCH	TATA spare parts
265154506911	PIANO KEY SWITCH (DIESEL PRE HEAT)	TATA spare parts
265154507501	RUBBER BOOT	TATA spare parts
265154509902	OIL PRESSURE SWITCH	TATA spare parts



265154509906	OIL PRESSURE SWITCH	TATA spare parts
265154509907	MAIN LINE SWITCH	TATA spare parts
265154509908	STARTER PUSH BUTTON[BROWN]	TATA spare parts
265154509914	STARTER PUSH BUTTON	TATA spare parts
265154509916	MAIN LINE SWITCH	TATA spare parts
265154509917	DUMMY COVER BLACK	TATA spare parts
265154509919	LOW OIL PRESSURE SWITCH .	TATA spare parts
265154509920	LOW OIL PRESSURE SWITCH .	TATA spare parts
265154509922	TRAILER FLASHER-12V	TATA spare parts
265154509928	FRAILER-FLASHER 12V INTERFACE	TATA spare parts
265154600102	CABLE SET FRT TO TAIL 31WB	TATA spare parts
265154600105	ASSY MAIN CABLE SET	TATA spare parts
265154600106	ASSY CABLE SET CAB LAMP	TATA spare parts
265154600122	MAIN CABLE SET	TATA spare parts
265154600154	ASSY CABLE SET [FRONT TO TAIL]31 WB	TATA spare parts
265154600165	CABLE SET CAB LAMP	TATA spare parts
265154600196	ASSY MAIN CABLE SET	TATA spare parts
265154600199	ASSY COVER	TATA spare parts
265154601602	W/H MAIN SFC407 EX2 BS-II RHD	TATA spare parts
265154601603	W/H TAIL SFC407 31WB EX2 RHD	TATA spare parts
265154601604	W/H TAIL W/EMOS REAR FOG 31WB	TATA spare parts
265154601610	W/H TAIL SFC407 CNG BSIV 31WB W/NEW HPR	TATA spare parts
265154601626	W/H TAIL SFC407/27WB BSII	TATA spare parts
265154601627	W/H MAIN SFC407/27WB BSII	TATA spare parts
265154601628	W/H TAIL SK407/31WB TIPPER BSII	TATA spare parts
265154601629	W/H MAIN SK407/31WB W/PTO	TATA spare parts
265154601631	W/H ENGINE SFC410 BS-III VEH. W/O PTO	TATA spare parts
265154601637	W/H MAIN SFC410/712/912_EX	TATA spare parts
265154601638	W/H TAIL SFC712/38WB EX BS-III	TATA spare parts
265154601639	W/H MAIN SFC410/712/912_EX_BSIII	TATA spare parts
265154601642	W/H SENSOR SFC 712/912 WITH 497 ENG.W/O	TATA spare parts
265154601643	MAIN_W/H_SFC_407_CNG_BS_IV	TATA spare parts
265154601644	ENGINE W/H SFC 407 CNG BS IV	TATA spare parts
265154601649	W/H MAIN SFC410/712/912_CANOPY	TATA spare parts
265154601652	W/H PIGTAIL OF WIF SENSOR FOR SFC407/31W	TATA spare parts
265154601677	W/H TAIL SFC407 CNG BSIV 31WB W/NEW HPR	TATA spare parts
265154606326	HOUSING	TATA spare parts
265154607501	GROMMET	TATA spare parts
265154607502	GROMMET	TATA spare parts
265154607505	GROMMET	TATA spare parts
265154607506	GROMMET	TATA spare parts
265154607509	GROMMET	TATA spare parts
265154608210	L BRACKET FOR 4SP CRDI SFC 407 BSIV	TATA spare parts
265154608211	BKT ON AIR INTEK FOR SFC 407 BSIV 4SP	TATA spare parts
265154608214	BRACKET SPEED LIMITER DEVICE MOTOR MTG	TATA spare parts
265154610121	WIRING HARNESS TAIL-27 WB -OFFER	TATA spare parts
265154610122	WIRING HARNESS ROOF	TATA spare parts

265154610126	W/H DANDA MAN SWITCH	TATA spare parts
265154610128	W/H MAIN RHD	TATA spare parts
265154610129	WIRING HARNESS TAIL 31WB	TATA spare parts
265154610131	W/H MAIN RHD EURO-II	TATA spare parts
265154610136	W/H.MAIN - SFC 407 CNG -(BS III)	TATA spare parts
265154610137	W/H MAIN RHD BHARAT STAGE-III	TATA spare parts
265154610138	W/H MAIN RHD BS-II W/MOT LEVEL	TATA spare parts
265154610139	W/H MAIN RHD FACELESS BS-II	TATA spare parts
265154610140	W/H.TAIL-SFC 407 CNG (BS III)	TATA spare parts
265154610141	W/H MAIN FACELESS RHD BS-III	TATA spare parts
265154610142	W/H MAIN SFC407 BS-II	TATA spare parts
265154610143	W/H TAIL SFC 407/31WB	TATA spare parts
265154610144	W/H MAIN BS-II RHD EMOS	TATA spare parts
265154610148	W/H PR.GUAGE & LIMIT SW.CNG BSIII	TATA spare parts
265154620106	CABLE SET-ROOF	TATA spare parts
265154620111	CABLE SET ENGINE - RHD	TATA spare parts
265154620115	W/H INSTRUMENT PANEL	TATA spare parts
265154620116	WIRING HARNESS TAIL - 31WB	TATA spare parts
265154620118	ASSY DIODE	TATA spare parts
265154620121	W/H MAIN	TATA spare parts
265154620124	WIRING HARNESS INSTRUMENT CONSOLE	TATA spare parts
265154620127	MAIN CABLE SET - LHD	TATA spare parts
265154620129	CABLE SET ENG. - LHD	TATA spare parts
265154620134	WIRING HARNESS BLOWER	TATA spare parts
265154620140	WIRING HARNESS PARKING BRAKE SW	TATA spare parts
265154620143	MAIN CABLE	TATA spare parts
265154620144	WIRING HARNESS MAIN 407	TATA spare parts
265154620145	WIRING HARNESS MAIN -RHD SFC407TC	TATA spare parts
265154620146	WIRING HARNESS TAIL	TATA spare parts
265154620148	WIRING HARNESS ENGINE SFC407TC	TATA spare parts
265154620152	WIRING HARNESS MAIN	TATA spare parts
265154620154	WIRING HARNESS MAIN RHD	TATA spare parts
265154620158	WIRING HARNESS MAIN RHD CMVR2000	TATA spare parts
265154620159	W/H MAIN RHD CMVR2000 W/O EX. BRAKE	TATA spare parts
265154620166	WIRING HARNESS TAIL-31WB	TATA spare parts
265154620168	WIRING HARNESS MAIN -RHD	TATA spare parts
265154620174	WIRING HARNESS ROOF	TATA spare parts
265154620175	W/H MAIN LHD W/HD CMVR	TATA spare parts
265154620176	W/H MAIN -RHD	TATA spare parts
265154620177	WIRING HARNESS TAIL 31WB	TATA spare parts
265154620180	WIRING HARNESS TAIL-27 WB	TATA spare parts
265154620183	W/H F.I.P.BHARAT STAGE-II	TATA spare parts
265154620184	W/H CAB LAMP-LOADBODY	TATA spare parts
265154620185	W/H MAIN RHD CMVR2000/EX	TATA spare parts
265154620188	W/H TAIL 31WB CMVR2000	TATA spare parts
265154620191	W/H MAIN RHD EURO-II	TATA spare parts
265154620197	W/H MAIN RHD W/HD	TATA spare parts

265154620198	W/H TAIL 31WB RHD	TATA spare parts
265154620199	W/H MAIN RHD BHARAT STAGE-III	TATA spare parts
265154628201	CLAMP	TATA spare parts
265154628202	CLAMP	TATA spare parts
265154630101	W/H MAIN LHD BHARAT STAGE-II	TATA spare parts
265154630102	W/H TAIL LHD 31WB BHARAT STAGE-II	TATA spare parts
265154630103	W/H ROOF	TATA spare parts
265154630104	W/H SEAT BELT	TATA spare parts
265154630105	W/H PARKING BRAKE SWITCH	TATA spare parts
265154630106	W/H FIP	TATA spare parts
265154630107	W/H MAIN RHD BS-II	TATA spare parts
265154630108	W/H MAIN RHD FACELESS BS-II	TATA spare parts
265154630109	W/H MAIN-SFC 407 CRPF BSII W/EXH.BR.	TATA spare parts
265154630110	W/H MAIN SFC 410 FACELESS BS-III	TATA spare parts
265154630113	W/H MAIN SFC407 BS-II	TATA spare parts
265154630114	W/H TAIL SFC407 BS-II	TATA spare parts
265154630115	W/H MAIN SFC407 EX2 BS-II	TATA spare parts
265154630116	W/H TAIL SFC407 31WB EX2 BS-II	TATA spare parts
265154630117	W/H MAIN SFC410 LHD - M/S.MSSL	TATA spare parts
265154630121	W/H.IGNITER (CON.TYPE)--4SP CNG 12V	TATA spare parts
265154630135	W/H TAIL SFC407/27WB BSII	TATA spare parts
265154630136	W/H MAIN SFC407/27WB	TATA spare parts
265154630137	W/H TAIL SK407/31WB TIPPER BSII	TATA spare parts
265154630138	W/H MAIN SK407/31WB W/PTO	TATA spare parts
265154630139	W/H ENGINE SFC410 BS-III WITH PTO WITH E	TATA spare parts
265154630140	W/H ENGINE SFC410 BS-III W/O PTO	TATA spare parts
265154630141	W_H TAIL SFC410_27WB	TATA spare parts
265154630142	W/H TAIL SFC/SK410_31_ BSIII	TATA spare parts
265154630144	W/H SENSOR SFC410_W/O PS	TATA spare parts
265154630145	W/H MAIN SK410	TATA spare parts
265154630146	W/H MAIN SFC410/712/912_EX	TATA spare parts
265154630147	W/H TAIL	TATA spare parts
265154630148	W/H MAIN SFC410/712/912_EX_BSIII	TATA spare parts
265154630151	W/H SENSOR SFC712 BS-III WITH 497ENG.W/O	TATA spare parts
265154630153	WIRING HARNESS MAIN SFC410/712 WITH PTO	TATA spare parts
265154630155	W/H MAIN SFC410/712/912	TATA spare parts
265154630156	W/H TAIL SFC410/31WB BS-III CANOPY WITH	TATA spare parts
265154630157	W/H PIGTAIL OF WIF SENSOR FOR SFC407/31W	TATA spare parts
265154630159	W/H TAIL SFC410/31_EX2	TATA spare parts
265154630160	W/H MAIN SFC410_EX2	TATA spare parts
265154630183	W/H PIGTAIL FRONT FOG LAMP_SFC FACELIFT	TATA spare parts
265154630191	W/H MAIN SFC407/709/909 EX WITH CAT-6 SI	TATA spare parts
265154630193	WIRING HARNESS MAIN	TATA spare parts
265154640101	W/H MAIN RHD EURO-II	TATA spare parts
265154640102	W/H FIP	TATA spare parts
265154640103	WIRING HARNESS ROOF	TATA spare parts
265154660102	WIRING HARNESS TAIL 31WB-RHD	TATA spare parts

265154660104	WIRING HARNESS MAIN	TATA spare parts
265154660105	WIRING HARNESS MAIN -FACELESS VEH	TATA spare parts
265154660107	W/H TAIL -27WB FACELESS	TATA spare parts
265154660108	WIRING HARNESS MAIN-RHD 407EURO-II	TATA spare parts
265154660109	WIRING HARNESS ROOF	TATA spare parts
265154660113	W/H DANDA MAN SWITCH	TATA spare parts
265154660116	W/HARNESS MAIN-RHD BHARAT STAGE-II SFC40	TATA spare parts
265154660117	W/HARNESS FIP-RHD BHARAT STAGE-II SFC407	TATA spare parts
265154660118	WIRING HARNESS TAIL 31WB	TATA spare parts
265154660121	W/H MAIN RHD	TATA spare parts
265154660127	W/H CAB LAMP-LOADBODY	TATA spare parts
265154660128	W/H MAIN RHD CMVR2000/EX	TATA spare parts
265154660129	W/H MAIN RHD CMVR2000 FACELESS	TATA spare parts
265154660130	W/H MAIN RHD DELUXE CMVR2000	TATA spare parts
265154660132	W/H MAIN RHD EURO-II	TATA spare parts
265154660139	W/H MAIN RHD BHARAT STAGE-III	TATA spare parts
265154660140	W/H MAIN RHD BS-II	TATA spare parts
265154660141	W/H MAIN RHD FACELESS BS-II	TATA spare parts
265154660142	W/H MAIN FACELESS BS-III	TATA spare parts
265154660145	W/H MAIN SFC 407 BS-II	TATA spare parts
265154660146	W/H TAIL SFC 407/31WB	TATA spare parts
265154660147	W/H MAIN SFC 407 BS-III CNG-	TATA spare parts
265154660148	W/H TAIL SFC 407 BS-III CNG-	TATA spare parts
265154660149	W/H PR.GUAGE & LIMIT SW.CNG BSIII	TATA spare parts
265154660150	W/H.CYL.EARTHING(TOP MTG)TATA MINI BUS	TATA spare parts
265154660151	W/H.CYL.EARTHING(SIDE MTG)TATA MINI BUS	TATA spare parts
265154660153	W/H MAIN RHD BS-II SFC407/709 EMOS	TATA spare parts
265154660154	W/H TAIL W/EMOS REAR FOG	TATA spare parts
265154660155	W/H MAIN SFC407 EX2 BS-II	TATA spare parts
265154660156	W/H TAIL SFC407 31WB EX2 BS-II	TATA spare parts
265154660170	W/H TAIL SFC407/27WB BSII	TATA spare parts
265154660171	W/H MAIN SFC407/27WB BSII	TATA spare parts
265154660172	W/H TAIL SK407/31WB BSII	TATA spare parts
265154660173	W/H MAIN SK407/31WB W/PTO	TATA spare parts
265154660174	W/H ENGINE SFC410 BS-III WITH PTO WITH E	TATA spare parts
265154660175	W/H ENGINE SFC410 BS-III W/O PTO WITH EX	TATA spare parts
265154660176	W/H TAIL SFC410_27WB	TATA spare parts
265154660177	W/H TAIL SFC/SK410_31_ BSIII	TATA spare parts
265154660179	W/H SENSOR SFC410_ W/O PS	TATA spare parts
265154660181	W/H MAIN SFC410	TATA spare parts
265154660182	W/H TAIL SFC712/38WB EX BS-III	TATA spare parts
265154660183	W/H MAIN SFC410/712/912_EX_BSIII	TATA spare parts
265154660186	W/H SENSOR SFC 712/912 WITH 497 ENG. W/O	TATA spare parts
265154660193	W/H MAIN SFC410/712/912_CANOPY	TATA spare parts
265154660196	W/H PIGTAIL OF WIF SENSOR FOR SFC407/31W	TATA spare parts
265154660219	W/H ENGINE SFC410 W/O EXHAUST BRAKE BS-I	TATA spare parts
265154660232	W/H MAIN SK407 BS-III	TATA spare parts

265154660233	W/H MAIN SFC407/709/909 EX WITH CAT-6 SI	TATA spare parts
265154680101	W/H MAIN RHD CMVR2000	TATA spare parts
265154680102	W/H TAIL 31WB RHD CMVR2000	TATA spare parts
265154680107	W/H MAIN RHD BS-II	TATA spare parts
265154680108	W/H F.I.P. BS-II	TATA spare parts
265154680109	W/H MAIN RHD FACELESS BS-II	TATA spare parts
265154680110	W/H MAIN SFC407 BS-II	TATA spare parts
265154680112	W/H MAIN SFC407/27WB	TATA spare parts
265154680113	W/H MAIN SK407/31WB	TATA spare parts
265154690103	W/H MAIN SFC410/712/912_EX_BSIII	TATA spare parts
265154690106	W/H TAIL SFC712/38WB BS-III	TATA spare parts
265154690110	W/H ENGINE SFC410 BS-III W/O PTO	TATA spare parts
265154690113	W/H SENSOR SFC712(497 ENG) BS-III	TATA spare parts
265154690120	W/H MAIN SFC410/712/912_EX_BSIII	TATA spare parts
265154690123	W/H MAIN SFC410/712/912_CANOPY	TATA spare parts
265154690128	W/H TAIL SFC712/38WB TRUCK	TATA spare parts
265154690135	W/H ENGINE SFC 410_BSIII_W/O_PTO	TATA spare parts
265154690137	W/H SENSOR SFC410_4SP_BSIII	TATA spare parts
265154690138	W/H SENSOR SFC712 BSIII_497ENG	TATA spare parts
265154690195	W/H MAIN SFC407/709/909 EX WITH CAT-6	TATA spare parts
265154690196	W/H MAIN SFC407/709/909 EX WITH PTO_CAT	TATA spare parts
265154700113	ASSY.TWIN BLOWER WITH TERS & HSG.	TATA spare parts
265154700114	MOTOR UNIT SPEED LIMITER BS3/4	TATA spare parts
265154709934	WIRE LEAD	TATA spare parts
265154709935	NUT	TATA spare parts
265154709938	BOLT	TATA spare parts
265154709940	BUSH	TATA spare parts
265154800104	STEREO CASSETTE PLAYER	TATA spare parts
265154809906	SPEAKER	TATA spare parts
265154820101	CABLE SET FRT TO TAIL 31WB	TATA spare parts
265154820103	MAIN CABLE SET RHD	TATA spare parts
265154820131	MAIN CABLE SET RHD	TATA spare parts
265154828202	CLAMP	TATA spare parts
265154990102	KIT-ROAD SPEED LIMITER 12V	TATA spare parts
265158300104	ASSY.ADVANCE WARNING TRIANGLE	TATA spare parts
265158300105	ASSY.ADVANCE WARNING TRIANGLE	TATA spare parts
265158300106	ASSY. ADVANCE WARNING TRIANGLE	TATA spare parts
265158304001	ADVANCE WARNING TRIANGLE 500	TATA spare parts
265158304002	ADVANCE WARNING TRIANGLE	TATA spare parts
265158304003	ADVANCE WARNING TRIANGLE	TATA spare parts
265158304005	ADVANCE WARNING TRIANGLE	TATA spare parts
265158304006	ADVANCE WARNING TRIANGLE	TATA spare parts
265158304007	ADVANCE WARNING TRIANGLE-M/s Pacoline	TATA spare parts
265158304009	ADVANCE WARNING TRIANGLE	TATA spare parts
265158404003	WHEEL CHOCK (ANGLE FABRICATED)-DOMESTIC	TATA spare parts
265158404004	WHEEL CHOCK - R360 BS6-PH2	TATA spare parts
265158405001	WHEEL CHOCK	TATA spare parts

265158409902	TRANSFER LABEL ( RUNNING-IN )	TATA spare parts
265158409915	TRANSFER LABEL (DO'S & DONT'S)	TATA spare parts
265158409933	TRANSFER LABEL (REAR TYRE PRESSURE)	TATA spare parts
265158900101	TROLLEY ENGINE HANDLING	TATA spare parts
265158900104	ASSY.SCREW JACK(3T) WITH HANDLE	TATA spare parts
265158900105	TOOL KIT	TATA spare parts
265158900108	ASSY.SCREW JACK(3T) WITH HANDLE	TATA spare parts
265158900109	ASSY.SCREW JACK(3T)WITH HANDLE	TATA spare parts
265158900112	ASSY.SCREW JACK(3T)WITH HANDLE	TATA spare parts
265158900125	ASSY.SCREW JACK(3T) WITH HANDLE	TATA spare parts
265158900201	DRIFT LINER REMOVAL	TATA spare parts
265158900202	DRIFT LINER INSTALLATION	TATA spare parts
265158900401	CLAMP TAIL PINION BRG	TATA spare parts
265158900501	DRIFT 9DIA INLET VALVE	TATA spare parts
265158900502	DRIFT 10DIA EXH VALVE	TATA spare parts
265158900503	SPACER VALVE GUIDE	TATA spare parts
265158900601	ALIGNING DOLLY - 4SP/497TC/697 ENGINE	TATA spare parts
265158901801	FILLER SPANNER	TATA spare parts
265158902002	SLEEVE W/PUMP IMPELLER	TATA spare parts
265158902501	MANDRIL CLUTCH	TATA spare parts
265158902502	FIXTURE CLUTCH	TATA spare parts
265158902503	PUNCH CL LINING RIVET	TATA spare parts
265158902601	DRIFT OIL SEAL	TATA spare parts
265158902602	PULLER D/S & M/S BRG	TATA spare parts
265158902603	PULLER C/S BRG	TATA spare parts
265158902605	SPANNER D/SHAFT NUT	TATA spare parts
265158902606	GAUGE	TATA spare parts
265158902607	HOLDER 4TH GEAR	TATA spare parts
265158903302	ARBOR	TATA spare parts
265158903304	SUPPORT BRACKET	TATA spare parts
265158903305	SPINDLE FR HUB	TATA spare parts
265158903306	PULLER FR HUB INN BRG	TATA spare parts
265158903307	PULLER FR HUB OUT BRG	TATA spare parts
265158903308	DRIFT	TATA spare parts
265158903309	ALLEN KEY 8MM	TATA spare parts
265158903310	PULLER FRT HUB	TATA spare parts
265158903311	PULLER	TATA spare parts
265158903312	KIT KING PIN EXT DEVICE	TATA spare parts
265158903314	INSTALLER FRONT HUB	TATA spare parts
265158903501	DRIFT	TATA spare parts
265158903502	DRIFT	TATA spare parts
265158903503	DRIFT	TATA spare parts
265158903504	DRIFT	TATA spare parts
265158903505	PULLER	TATA spare parts
265158903506	PULLER DIFFL SIDE BEARING	TATA spare parts
265158903507	THRUST PLATE	TATA spare parts
265158903508	PULLER RR HUB BEARINGS	TATA spare parts

265158903509	PRONGED WRENCH	TATA spare parts
265158903510	WRENCH HUB LOCKNUT	TATA spare parts
265158903511	HOLDER END YOKE	TATA spare parts
265158903512	SUPPORT RING	TATA spare parts
265158903513	TAIL PINION DEVICE	TATA spare parts
265158903514	CLAMP TAIL PINION BRG	TATA spare parts
265158903515	DEPTH GAUGE TAIL PINION	TATA spare parts
265158903518	KIT TAIL PIN DEPTH GAUGE	TATA spare parts
265158904002	HYD JACK 4T W/HANDLE	TATA spare parts
265158904003	WHEEL SPANNER 24AF	TATA spare parts
265158904006	ASSY.SCREW JACK(3T) WITH HANDLE	TATA spare parts
265158904012	ASSY.SCREW JACK(3T) WITH HANDLE	TATA spare parts
265158904015	ASSY.SCREWJACK(3T) W/HANDLE	TATA spare parts
265158904020	WHEEL SPANNER - 27 - 24 A/F	TATA spare parts
265158904201	SEAL GUIDE TMC 23.81 DIA	TATA spare parts
265158904202	GUIDE-PRIMARY PISTON-TMC 23.81 DIA	TATA spare parts
265158904203	GUIDE BUSH PRIMERY BACK SEAL-TMC 23.81	TATA spare parts
265158904204	FIXTURE VACCUME BOOSTER	TATA spare parts
265158904601	DRIFT IN/OUT RACE	TATA spare parts
265158904602	DRIFT	TATA spare parts
265158904603	PULLER IN/OUT RACE	TATA spare parts
265158905001	TOOL BAG	TATA spare parts
265158905401	KEY RING	TATA spare parts
265160100101	PANEL FRONT	TATA spare parts
265160100123	COWL BARE	TATA spare parts
265160100126	CAB COMPLT RHD 407	TATA spare parts
265160100134	COWL COMPLT RHD	TATA spare parts
265160100175	ASSY CAB COMP LHD	TATA spare parts
265160100177	CAB BARE RHD 407	TATA spare parts
265160106301	MEL SHEET FLOOR FRONT-LH	TATA spare parts
265160106302	MEL SHEET FLOOR LH-REAR	TATA spare parts
265160106303	MEL SHEET FLOOR RH-REAR	TATA spare parts
265160106304	MEL SHEET FLOOR FRONT-RH	TATA spare parts
265160108206	FENDER LH	TATA spare parts
265160108207	FENDER RH	TATA spare parts
265160108209	REINF STEP OUTER LH	TATA spare parts
265160108210	REINF STEP OUTER RH	TATA spare parts
265160108213	BRACKET BS6	TATA spare parts
265160108248	REINFORCEMENT R.H. BS6	TATA spare parts
265160108249	REINFORCEMENT L.H. BS6	TATA spare parts
265160108250	REINFORCEMENT LH	TATA spare parts
265160108251	REINFORCEMENT RH	TATA spare parts
265160110132	BRACKET ASSY W/S WASHING BOTTLE MTG BS6	TATA spare parts
265160120116	ASSY CAB COMPLETE RHD BHARAT II	TATA spare parts
265160120191	ASSY.COWL WITH CENTRE BONNET PAINTED RHD	TATA spare parts
265160120193	ASSY BARE CAB	TATA spare parts
265160120197	CAB BARE SFC 407	TATA spare parts

265160130117	ASSY.CAB COMPLETE RHD SPARES W/O ELECT	TATA spare parts
265160130118	ASSY.COWL COMPLETE RHD SPARES W/O ELECT	TATA spare parts
265160130119	ASSY FRT PANEL	TATA spare parts
265160130120	ASSY CAB SFC 407	TATA spare parts
265160130121	CAB BARE SFC 407 CMVR	TATA spare parts
26516013012120	ASSY 407 BODY SHELL COMP CED COATED	TATA spare parts
265160130125	COWL COMPLETE RHD CMVR	TATA spare parts
265160130126	COWL BARE SFC 407 CMVR	TATA spare parts
26516013012620	ASSY 407 BODY COWL COMP CED COATED	TATA spare parts
265160130130	ASSY.COWL COMPLETE RHD BHARAT II	TATA spare parts
265160130132	ASSY.CAB COMPLETE-RHD	TATA spare parts
265160130133	ASSY.COWL SHELL COMPLETE PAINTED RHD	TATA spare parts
265160130150	ASSY.STR.COMPLETE FACELESS WITH AED	TATA spare parts
265160130151	ASSY STRUCTURE COMPLETE FACELESS LP 407	TATA spare parts
265160130157	ASSY.CAB COMPLETE-RHD-WITH EX MASCOT	TATA spare parts
265160130163	ASSY.BODY SHELL COMP PAINTED SFC407EX	TATA spare parts
265160130164	ASSY.CAB COMPLETE WITH FITMENTS-LHD	TATA spare parts
265160130165	ASSY.BODY SHELL COMPLETE PAINTED LHD	TATA spare parts
265160130174	ASSY.CAB COMPLETE RHD	TATA spare parts
265160130181	ASSY.STRUCTURE WELDED FACELESS BS-II	TATA spare parts
265160130182	ASSY.STR.COMP.FACELESS WITH AED BS-II	TATA spare parts
265160130183	ASSY.STR.COMPLETE FACELESS BS-II	TATA spare parts
265160130185	ASSY.CAB COMP-RHD WITH H/D	TATA spare parts
265160130186	ASSY.CAB.PAINTED-RHD 407SFC	TATA spare parts
265160130190	ASSY.CAB COMPLETE-RHD EX BS-II	TATA spare parts
265160130191	ASSY.CAB PAINTED-RHD 407EX EURO-II	TATA spare parts
265160130196	ASSY.CAB COMP 407 SFC LHD	TATA spare parts
265160130197	ASSY.BODY SHELL COMPLETE PAINTED-LHD	TATA spare parts
265160140103	SFC 407 BS III CAB COMPLETE FITTED	TATA spare parts
265160140104	ASSY.BODY SHELL COMP.PAINTED-RHD-BS-III	TATA spare parts
265160140112	ASSY.COWL SHELL COMPLETE PAINTED-RHD	TATA spare parts
265160140113	410 SFC COWL BS-III (FITTED)	TATA spare parts
265160140116	ASSY.STR.COMPLETE FACELESS BS-III	TATA spare parts
265160140117	ASSY.CAB COMPLETE RHD CNG BS-III	TATA spare parts
265160140118	ASSY.BODY SHELL PAINTED RHD CNG SFC 40	TATA spare parts
265160140124	ASSY.CAB COMPLETE-RHD BS-III	TATA spare parts
265160140125	ASSY.BODY SHELL COMP.PAINTED RHD BS-III	TATA spare parts
265160600101	PANEL INNER BONNET LH RR	TATA spare parts
265160600102	PANEL INNER BONNET RH RR	TATA spare parts
265160600103	ASSY REINF HINGE MTG	TATA spare parts
265160600104	SUPPORT ASSY	TATA spare parts
265160600111	MUDGUARD COMP LH RHD	TATA spare parts
265160600112	MUDGUARD COMP RH RHD	TATA spare parts
265160600113	ASSY.MUDGUARD COMP.L.H. L.H.D.	TATA spare parts
265160600114	ASSY.MUDGUARD COMP.R.H. L.H.D.	TATA spare parts
265160600115	ASSY. PANEL INNER BONNET REAR LH	TATA spare parts
265160600116	ASSY.PANEL INNER BONNET REAR RH RHD/LHD	TATA spare parts



265160600123	BRACKET ASSY BS6	TATA spare parts
265160608201	PANEL INNER BONNET REAR L.H. BS6-PH2	TATA spare parts
265160608204	MUDGUARD LH	TATA spare parts
265160608205	MUDGUARD RH	TATA spare parts
265160608207	SUPPORT FIRE WALL TO PANEL BS6	TATA spare parts
265160608216	PANEL INNER BONNET REAR RH RHD/LHD BS6-P	TATA spare parts
265161000137	ASSY.SUBSTRUCTURE RHD BS6	TATA spare parts
265161100116	ASSY LONG MEMBER RH-RHD	TATA spare parts
265161100120	ASSY.LONG MEMBER LH-RHD	TATA spare parts
265161100122	ASSY.NUT PLATE BS6	TATA spare parts
265161100123	ASSY.BRACKET BOTTOM(SEAT BELT)	TATA spare parts
265161100124	ASSY.BRACKET SEAT BELT ANCHORAGE	TATA spare parts
265161100126	ASSY.BRACKET BOTTOM SEAT BELT	TATA spare parts
265161103310	OUTER BKT RH R/KIT	TATA spare parts
265161103311	OUTER BKT LH R/KIT	TATA spare parts
265161200105	ASSY CROSS MEMBER SEAT MTG-RHD	TATA spare parts
265161200115	ASSY GUSSET LH	TATA spare parts
265161208201	FRONT CROSS MEMBER	TATA spare parts
265161208202	MIDDLE CROSS MEMBER	TATA spare parts
265161208205	GUSSET	TATA spare parts
265161600102	STEP WELL LH	TATA spare parts
265161600103	STEP WELL RH	TATA spare parts
265161600110	STEP WELL LH	TATA spare parts
265161600111	STEP WELL RH	TATA spare parts
265161600112	ASSY BKT DIPSTICK TUBE HOLDING BS6	TATA spare parts
265161600123	ASSY.PANEL STEP WELL LH LHD	TATA spare parts
265161600124	ASSY.PANEL STEP WELL RH LHD	TATA spare parts
265161600127	ASSY. BONNET PANEL INNER	TATA spare parts
265161600135	ASSY.SIDE BRACKET(FLOOR) BS6	TATA spare parts
265161608201	FLOOR PANEL CAB	TATA spare parts
265161608211	SUPPORT POST LH BS6	TATA spare parts
265161608212	SUPPORT POST RH BS6	TATA spare parts
265161608214	CLAMP BS6	TATA spare parts
265161608217	FENDER LH	TATA spare parts
265161608218	FENDER RH	TATA spare parts
265161608236	ASSY.SUPPORT LH(MUD-FLAP) BS6	TATA spare parts
265161608237	ASSY.SUPPORT RH(MUD-FLAP) BS6	TATA spare parts
265161608251	REINFORCEMENT LH (STEP WELL) BS6	TATA spare parts
265161608252	REINFORCEMENT RH (STEP WELL) BS6	TATA spare parts
265161608261	COVER LH	TATA spare parts
265161608262	COVER RH	TATA spare parts
265161608274	REINFORCEMENT R.H.[FLOOR PANEL]RHD	TATA spare parts
265161608275	REINFORCEMENT L.H.[FLOOR PANEL]LHD	TATA spare parts
265161608276	REINFORCEMENT RH R/KIT	TATA spare parts
265161608277	REINFORCEMENT LH R/KIT	TATA spare parts
265161608283	REINF.RH-RHD(FLOOR PANEL) BS6	TATA spare parts
265161608285	REINF.LH-RHD(FLOOR PANEL) BS6	TATA spare parts

265162100118	ASSY.DOOR POST FRONT.LH.	TATA spare parts
265162100119	ASSY.DOOR POST FRONT.RH.	TATA spare parts
265162100148	ASSY.SUPPORT RHD INSTRUMENT SHROUD	TATA spare parts
265162100149	ASSY.SUPPORT LHD(INSTRUMENT SHROUD)	TATA spare parts
265162103313	BRACKET STEERING COLUMN MTG	TATA spare parts
265162500103	ASSY.PANEL OUTER W/S COMPLETE RHD	TATA spare parts
265162508207	RAIN CHANNEL BOTTOM W/S BS6	TATA spare parts
265162600114	ASSY BRACKET BS6	TATA spare parts
265162600127	ASSY.BRACKET R.H.(WHEEL BOX MTG) BS6	TATA spare parts
265162600153	ASSY.PANEL INNER WINDSCREEN.	TATA spare parts
265162608204	GUSSET PLATE LH BS6	TATA spare parts
265162608205	GUSSET PLATE RH BS6	TATA spare parts
265162608224	TOP RAIL FRONT	TATA spare parts
265162608235	CLAMP	TATA spare parts
265162608249	REINFORCEMENT(DRY TYPE AIR FILTER) BS6	TATA spare parts
265162608268	INNER PANEL BOTTOM(WIND SCREEN) BS6	TATA spare parts
265162610124	ASSY.POST SIDE PANEL LH BS6	TATA spare parts
265164000111	ASSY.REAR WALL(DOMESTIC)STATIC BELTS	TATA spare parts
265164100105	ASSY.DOOR POST & REINF.TOP RAIL LH	TATA spare parts
265164100106	ASSY DOOR POST & REINF.TOP RAIL RH	TATA spare parts
265164108201	DOOR POST REAR LH	TATA spare parts
265164108202	DOOR POST REAR RH	TATA spare parts
265164200102	ASSY TOP RAIL REAR INNER	TATA spare parts
265164208201	TOP RAIL REAR INNER BS6	TATA spare parts
265164208203	TOP RAIL SIDE LH INNER	TATA spare parts
265164208204	TOP RAIL SIDE RH INNER	TATA spare parts
265164208207	TOP RAIL SIDE OUTER LH BS6	TATA spare parts
265164208208	TOP RAIL SIDE OUTER RH BS6	TATA spare parts
265164208209	REINF LH TOP RAIL SIDE	TATA spare parts
265164208210	TOP RAIL CORNER INNER LH	TATA spare parts
265164208211	TOP RAIL CORNER INNER RH	TATA spare parts
265164208212	REINFORCEMENT RH TOP RAIL	TATA spare parts
265164600105	ASSY.BRACKET LH	TATA spare parts
265164600106	ASSY.BRACKET R.H.	TATA spare parts
265164600114	ASSY.BRACKET COMPLETE L.H. ELR MOUNTING	TATA spare parts
265164600115	ASSY.BRACKET COMPLETE R.H. ELR MOUNTING	TATA spare parts
265164608203	CORNER BOTTOM REAR WALL LH BS6	TATA spare parts
265164608204	CORNER BOTTOM REAR WALL RH BS6	TATA spare parts
265164608208	REINFORCEMENT BS6	TATA spare parts
265164608219	SUPPORT L.H. BS6-PH2	TATA spare parts
265164608220	SUPPORT R.H. BS6-PH2	TATA spare parts
265164708207	PANEL REAR WALL BS6-PH2	TATA spare parts
265165708201	ROOF PANEL	TATA spare parts
265165708207	ROOF PANEL	TATA spare parts
265166400101	SEAT BOX DRIVER SEAT	TATA spare parts
265166400105	KNOB ASSY	TATA spare parts
265166400109	ASSY.LID (SEAT BOX)LHD	TATA spare parts

265166400110	ASSY.SEAT BOX (DRIVERS SEAT)LHD	TATA spare parts
265166400124	ASSY SEAT BOX	TATA spare parts
265166400127	LID SEAT BOX	TATA spare parts
265166400135	ASSY.SEAT BOX RHD [DRIVER'S SEAT]	TATA spare parts
265166400136	ASSY.SEAT BOX LHD [DRIVER'S SEAT]	TATA spare parts
265166400139	LID SEAT BOX RHD	TATA spare parts
265166400141	ASSY.SEAT BOX RHD(DRIVER'S SEAT)	TATA spare parts
265166407503	RUBBER GROMMET	TATA spare parts
265166408209	LEVER FOR LOCK	TATA spare parts
265166408701	TORSION SPRING LH	TATA spare parts
265166408702	TORSION SPRING RH	TATA spare parts
265167100101	ASSY. REAR WINDOW COMPLETE BS1/2/3/4	TATA spare parts
265167100103	REAR WINDOW COMPLT.	TATA spare parts
265167100110	ASSY.REAR WINDOW COMPT.WITH TINTED GLASS	TATA spare parts
265167100112	ASSY.REAR WINDOW COMPL.WITH TINTED GLASS	TATA spare parts
265167102301	W/S GLASS SHEET	TATA spare parts
265167102302	W/S GLASS	TATA spare parts
265167102303	W/S GLASS LAMINATED	TATA spare parts
265167102304	WIND SHIELD GLASS	TATA spare parts
265167102306	WINDSHIELD GLASS (5.76THK) BS2/3/4	TATA spare parts
265167102502	KEY PROFILE	TATA spare parts
265167102504	FILLER PROFILE	TATA spare parts
265167102506	KEY PROFILE(WIND SHIELD)	TATA spare parts
265167102507	KEY PROFILE RR WINDOW	TATA spare parts
265167106301	RUB MOULD W/S GLASS	TATA spare parts
265167106303	RUB MOULD W/S GLASS EPDM	TATA spare parts
265167106304	RUB MOULDING RR WINDOW	TATA spare parts
265167106304AE	RUBBER MOULD-REAR WINDOW 2523	TATA spare parts
265167802301	GLASS REAR WINDOW	TATA spare parts
265167802302	GLASS PANE (REAR WINDOW).	TATA spare parts
265167806301	RUB MOULDING RR WINDOW	TATA spare parts
265167806302	RUBBER MOULD [ R / W ]	TATA spare parts
265168300101	COVER ASSY	TATA spare parts
265168300102	COVER ASSY	TATA spare parts
265168300106	COVER ASSY BS6	TATA spare parts
265168307701	SEALING RUBBER	TATA spare parts
265168307702	RUBBER BELLOW	TATA spare parts
265168307703	RUBBER BELLOW NEOPRENE	TATA spare parts
265168307704	SEALING RUBBER	TATA spare parts
265168308203	COVER PLATE	TATA spare parts
265168400126	ASSY.FLOOR MAT-RHD	TATA spare parts
265168400128	KIT FLOOR MAT TOP.	TATA spare parts
265168400131	ASSY.FLOOR MAT LHD	TATA spare parts
265168400133	ASSY.FLOOR MAT-RHD (PTO BHARAT STG.II)	TATA spare parts
265168400157	ASSY.FLOOR MAT-RHD	TATA spare parts
265168401814	FLOOR MAT RH	TATA spare parts
265168401815	FLOOR MAT L.H.	TATA spare parts

265168401830	FLOOR MAT SET	TATA spare parts
265168401888	FLOOR MAT SET RHD	TATA spare parts
265168600102	ASSY COVER STEP BOARD-LH BS6-PH2	TATA spare parts
265168600103	ASSY COVER STEP BOARD-RH BS6-PH2	TATA spare parts
265168606301	COVER STEP BOARD LH	TATA spare parts
265168606302	COVER STEP BOARD RH	TATA spare parts
265168606308	COVER STEP BOARD-LH	TATA spare parts
265168606309	COVER STEP BOARD-RH	TATA spare parts
265168606310	COVER STEP BOARD-LH	TATA spare parts
265168606311	COVER STEP BOARD-RH	TATA spare parts
265168806301	PADDING POST SIDE R.H.RHD	TATA spare parts
265168806302	PADDING POST SIDE L.H.RHD	TATA spare parts
265168809901	PIN (FLOOR MAT)	TATA spare parts
265168900112	ASSY INST PANEL P P D BOARD	TATA spare parts
265168900113	CENTRE PANEL	TATA spare parts
265168900114	GLOVE BOX ASSY	TATA spare parts
265168900115	SIDE PANEL LH RHD/LHD	TATA spare parts
265168900122	TOP PANEL LH	TATA spare parts
265168900123	ASSY. TOP PANEL R.H.	TATA spare parts
265168900133	GLOVE BOX W/LID	TATA spare parts
265168900143	GLOVE BOX COMPLT SFC	TATA spare parts
265168900145	BKT TOP DASHBOARD MTG	TATA spare parts
265168900147	DASHBOARD RHD COMP 1PIECE	TATA spare parts
265168900148	CRASH PAD LH	TATA spare parts
265168900149	CRASH PAD RH	TATA spare parts
265168900152	VENTILATION NOZZLE	TATA spare parts
265168900156	DASHBOARD LHD COMP 1PIECE	TATA spare parts
265168900170	GLOVE BOX W/LID	TATA spare parts
265168900178	ASSY.BRACKET TOP [DASHBOARD MTG.]	TATA spare parts
265168900185	KIT FOR LOCKS-COWL	TATA spare parts
265168900186	KIT FOR LOCKS COWL RHD	TATA spare parts
265168900188	ASSY.BRKT TOP[D'BOARD MTG.CO-DRVR SIDE]	TATA spare parts
265168900189	KIT LOCKS COWL RHD	TATA spare parts
265168900190	ASSY.DASH BOARD COMPLT.LHD(WITH DEFROST)	TATA spare parts
265168900193	ASSY.DASH BOARD COMPLETE - RHD	TATA spare parts
265168900195	ASSY.CONTROL BRACKET - HEATER	TATA spare parts
265168900197	BKT TOP CEN DASHBOARD MTG	TATA spare parts
265168900198	BKT TOP D/BOARD LH LHD	TATA spare parts
265168900403	NACELLE SET SFC	TATA spare parts
265168906310	CENTRE PANEL	TATA spare parts
265168906311	SIDE PANEL LH	TATA spare parts
265168906312	SIDE PANEL RH	TATA spare parts
265168906315	INSTRUMENT PANEL	TATA spare parts
265168906316	GLOVE BOX	TATA spare parts
265168906317	PLUG DASH BOARD	TATA spare parts
265168906318	TOP PANEL LH P P DASH BOARD	TATA spare parts
265168906320	COVER STEERING COLUMN	TATA spare parts

265168906321	PLUG	TATA spare parts
265168906336	INSTRUMENT PANEL RHD	TATA spare parts
265168906338	PLUG PP DASH BOARD	TATA spare parts
265168906343	DASH BOARD RHD SFC609	TATA spare parts
265168906344	INSTUMENT SHROUD SFC	TATA spare parts
265168906348	STRIKER(GLOVE BOX)	TATA spare parts
265168906354	ELBOW DUCT FRESH AIR LH	TATA spare parts
265168906355	SPEAKER GRILL	TATA spare parts
265168906357	DASH BOARD LHD	TATA spare parts
265168906359	INSTRUMENT PANEL SFC	TATA spare parts
265168906363	ELBOW DUCT FRESH AIR RH	TATA spare parts
265168906372	CENTRE PANEL RHD	TATA spare parts
265168906373	SIDE PANEL LH RHD	TATA spare parts
265168906374	SIDE PANEL RH RHD	TATA spare parts
265168906378	INSTRUMENT PANEL RHD NEW	TATA spare parts
265168906380	TOP PANEL NEW	TATA spare parts
265168906388	GARNISH MIDDLE DEFROST	TATA spare parts
265168906388AE	GARNISH (MIDDLE DEFROST) -1628	TATA spare parts
265168906389	GARNISH SIDE DEFROST	TATA spare parts
265168906399	TOP PANEL DASH BOARD	TATA spare parts
265168908211	SUPPORT	TATA spare parts
265168910103	DASH BOARD LHD COMPLT	TATA spare parts
265168910104	KIT FOR LOCKS RHD COWL	TATA spare parts
265168910114	SET NACELLE FRT/RR	TATA spare parts
265168910118	ASSY.CONTROL BRACKET-HTR.(LP-709)	TATA spare parts
265168910121	SET:NACELLE FRONT AND REAR-DARK GREY	TATA spare parts
265168910122	ASSY.GLOVE BOX COMPL. DARK GREY	TATA spare parts
265168910123	ASSY. DASHBOARD COMPLETE	TATA spare parts
265168910124	ASSY.DASHBOARD COMPL.-RHD	TATA spare parts
265168910127	ASSY. DASHBOARD COMPLETE	TATA spare parts
265168910128	ASSY.CONTROL PANEL HEATER	TATA spare parts
265168916314	COVER FOR RADIO CUT OUT	TATA spare parts
265168916315	DASH BOARD - LHD (FOR HEATING SYSTEM).	TATA spare parts
265168916316	DASH BOARD (RHD) - HEATING SYSTEM.	TATA spare parts
265168916328	GARNISH (MIDDLE DEFROST) BS6	TATA spare parts
265168916329	GARNISH (SIDE DEFROST) BS6	TATA spare parts
265168916330	GARNISH CENTRE	TATA spare parts
265168916331	GARNISH RH	TATA spare parts
265168916332	GARNISH LH	TATA spare parts
265168916333	INSTRUMENT PANEL `S CAM BRAKES	TATA spare parts
265168916334	T EMBLEM COVER-DASH BOARD	TATA spare parts
265168916339	INSTRUMENT SHROUD-DARK GREY	TATA spare parts
265168916344	COVER CENTRE-DARK GREY	TATA spare parts
265168916345	DASH BOARD-DARK GREY	TATA spare parts
265168916346	T EMBLEM COVER-DARK GREY	TATA spare parts
265168916348	DASH BOARD-RHD W/O FITMENTS	TATA spare parts
265168916349	DASH BOARD (RHD)	TATA spare parts

265168916350	DASHBOARD (W/O FITMENTS)	TATA spare parts
265169506318	ROOF LINING LAMINATED	TATA spare parts
265169506334	ROOF LINING SELF STICKING	TATA spare parts
265169506335	MOULDED ROOF LINING (SFC-LCV CAB)	TATA spare parts
265169702509	ROOF BEADING	TATA spare parts
265169704201	CLAMP ROOF BEADING JOINT	TATA spare parts
265169706301	BUTTON(ROOF INNER BEADING)	TATA spare parts
265169806303	BEADING(RAIN CHANNEL)	TATA spare parts
265170000111	LOAD BODY COMPLT BOLTED	TATA spare parts
26517000011121	LOAD BODY COMPLT BOLTED	TATA spare parts
265170000130	ASSY.LOAD BODY COMP.[FOR 31-WB-EXPORT	TATA spare parts
265170000143	ASSY.LOAD BODY COMP. HIGH DECK-SHORTER	TATA spare parts
26517000014321	ASY.LOAD BODY COMP.HI DECK- EX COLOUR	TATA spare parts
265170000144	ASSY.LOAD BODY COMPLT. HUMP FLOOR	TATA spare parts
265170000154	ASSY.LOAD BODY COMPLT.(407EX2 HI DECK)	TATA spare parts
265170100109	FLOOR WELDED COMPLETE	TATA spare parts
265170100135	FLOOR WELDED COMPLETE	TATA spare parts
265170106301	RETRO-REFLECTIVE TAPE	TATA spare parts
265170108212	MUDGUARD LH	TATA spare parts
265170108213	MUDGUARD RH	TATA spare parts
265170108219	STAY MUDGUARD	TATA spare parts
265170110109	ASSY.SUPPORT	TATA spare parts
265170128201	MUDGUARD L.H.	TATA spare parts
265170128202	MUDGUARD R.H.	TATA spare parts
265170128203	MUDGUARD STAY	TATA spare parts
265170200114	ASSY.FRONT PANEL COMPT [WITH LOAD GUARD]	TATA spare parts
265170200124	FRONT PANEL-BOLTED PANEL	TATA spare parts
265170300101	SIDE PANEL LH	TATA spare parts
265170300102	SIDE PANEL RH	TATA spare parts
265170300116	SIDE PANEL LH	TATA spare parts
265170300117	SIDE PANEL RH	TATA spare parts
265170300138	ASSY.SIDE PANEL L.H.	TATA spare parts
265170300139	ASSY SIDE PANEL RH - LONGER LOAD BODY	TATA spare parts
265170300144	ASSY.SIDE PANEL-LH	TATA spare parts
265170300145	ASSY.SIDE PANEL-RH	TATA spare parts
265170308216	CHAIN HOLDER BS6	TATA spare parts
265170400101	ASSY. POST REAR LH	TATA spare parts
265170400102	ASSY. POST REAR RH	TATA spare parts
265170400104	CHAIN LOAD BODY	TATA spare parts
265170400105	TAIL GATE ASSY	TATA spare parts
265170400124	ASSY.TAIL GATE	TATA spare parts
265170900105	STOPPER SIDE AND REAR	TATA spare parts
265170900106	STOPPER FRONT	TATA spare parts
265170900107	RUBBER PACKING	TATA spare parts
265170900108	TOGGLE CLAMP	TATA spare parts
265170900117	PACKING	TATA spare parts
265170900118	RUBBER PACKING RING	TATA spare parts

265170905601	HANDLE LH	TATA spare parts
265170905605	HANDLE RH	TATA spare parts
265170905606	HANDLE LH	TATA spare parts
265170906305	PACKING	TATA spare parts
265170906701	PIN REAR POST HINGE	TATA spare parts
265170906705	PIN HINGE	TATA spare parts
265170906707	PIN (HINGE)	TATA spare parts
265170908205	SUPPORT LH REAR	TATA spare parts
265170908206	SUPPORT RH REAR	TATA spare parts
265172000101	DOOR COMPLT LH	TATA spare parts
265172000102	DOOR ASSY COMPLT RH	TATA spare parts
265172000105	ASSY DOOR COMPL LH LHD	TATA spare parts
265172000106	ASSY.DOOR COMPLETE RH LHD	TATA spare parts
265172200105	ASSY PANEL INNER COMPL LH BS6	TATA spare parts
265172200106	ASSY PANEL INNER COMPL RH BS6	TATA spare parts
265172200109	ASSY. DOOR SHELL LH RHD BS2/3/4	TATA spare parts
265172200110	DOOR SHELL RH RHD BS2/3/4/6	TATA spare parts
265172200129	DOOR SHELL LH LHD	TATA spare parts
265172200130	DOOR SHELL RH LHD	TATA spare parts
265172200141	ASSY.DOOR SHELL LH RHD A/C	TATA spare parts
265172200142	ASSY.DOOR SHELL RH RHD A/C	TATA spare parts
265172200143	ASSY.DOOR SHELL LH LHD A/C	TATA spare parts
265172200144	ASSY.DOOR SHELL RH LHD A/C	TATA spare parts
265172200166	ASSY.NUT PLATE(ORVM MTG) BS6	TATA spare parts
265172208208	ANGLE(TURNING WINDOW) BS6	TATA spare parts
265172300101	HANDLE OUTER LH LHD	TATA spare parts
265172300102	HINGE LH DOOR	TATA spare parts
265172300103	HINGE RH DOOR	TATA spare parts
265172300105	HANDLE OUTER RH RHD	TATA spare parts
265172300106	HANDLE INNER DOOR LH	TATA spare parts
265172300108	PULL ROD ASSY	TATA spare parts
265172300111	ASSY. DOOR LOCK COMP. LH BS1/2/3/4/6	TATA spare parts
265172300112	ASSY. DOOR LOCK COMP. RH BS1/2/3/4/6	TATA spare parts
265172300121	ASSY.NUT PLATE	TATA spare parts
265172300122	DOOR LOCK LH LHD	TATA spare parts
265172300123	DOOR LOCK RH LHD	TATA spare parts
265172300134	DOOR HANDLE OUTER LH RHD	TATA spare parts
265172300135	OUTER HANDLE RH/LHD	TATA spare parts
265172300137	DOOR HANDLE OUTER LH RHD	TATA spare parts
265172300138	ASSY.DOOR HANDLE OUTER W/O LOCK RH-LHD	TATA spare parts
265172300139	ASSY. OUTER DOOR HANDLE RH BS1/2/3/4	TATA spare parts
265172300140	DOOR HANDLE OUTER LH LHD	TATA spare parts
265172300144	ASSY HANDLE INNER	TATA spare parts
265172300146	ASSY.PULL ROD LH(DOOR INNER HANDLE)	TATA spare parts
265172300147	ASSY.PULL ROD RH(DOOR INNER HANDLE)	TATA spare parts
265172300148	HANDLE WINDOW REGULATOR	TATA spare parts
265172300149	DOOR HANDLE INNER LH	TATA spare parts

265172300150	DOOR HANDLE INNER RH	TATA spare parts
265172300157	DOOR HANDLE OUTER LH RHD	TATA spare parts
265172300158	ASSY.DOOR HANDLE OUTER W/LOCK RHRHD	TATA spare parts
265172300159	KEY PAIR	TATA spare parts
265172300160	GLOVE BOX LOCK	TATA spare parts
265172300162	GLOVE BOX LOCK W/O KEY	TATA spare parts
265172300165	KIT FOR LOCKS CAB RHD	TATA spare parts
265172300170	KIT FOR LOCKS CAB RHD	TATA spare parts
265172300171	KIT FOR LOCKS CAB RHD	TATA spare parts
265172300172	ASSY.DOOR LOCK L.H.	TATA spare parts
265172300173	ASSY.DOOR LOCK R.H.RHD	TATA spare parts
265172300175	ASSY.DOOR LOCK R.H.	TATA spare parts
265172300176	ASSY HANDLE INNER DOOR	TATA spare parts
265172300182	KIT FOR LOCKS CAB RHD	TATA spare parts
265172300184	ASSY.DOOR LOCK L.H.	TATA spare parts
265172300185	ASSY.DOOR LOCK R.H.RHD	TATA spare parts
265172300188	KIT FOR LOCKS-CAB [M/S MINDA SWITCH]	TATA spare parts
265172300196	KIT FOR LOCKS CAB RHD	TATA spare parts
265172300199	HANDLE ASSY	TATA spare parts
265172302509	TURING WINDOW BEADING	TATA spare parts
265172303802	DOVETAIL POST S	TATA spare parts
265172305601	KNOB	TATA spare parts
265172305603	KNOB DARK GREY	TATA spare parts
265172306304	SEALING INNER DOOR	TATA spare parts
265172306307	DOVETAIL DOOR SIDE	TATA spare parts
265172306308	BEADING DOOR INNER	TATA spare parts
265172306311	BEADING DOOR INNER	TATA spare parts
265172306320	TOP CORNER PIECE	TATA spare parts
265172306321	BOTTOM CORNER PIECE L.H.	TATA spare parts
265172306322	BOTTOM CORNER PIECE R.H.	TATA spare parts
265172306327	DOVETAIL-POST SIDE	TATA spare parts
265172306328	REFLEX REFLECTOR	TATA spare parts
265172307702	DOOR SEALING LH OUTER	TATA spare parts
265172307703	DOOR SEALING RH OUTER	TATA spare parts
265172307705	REAR END COVER	TATA spare parts
265172307706	FRONT END COVER	TATA spare parts
265172308203	PACKING DOVE TAIL	TATA spare parts
265172308204	PLATE STRIKER	TATA spare parts
265172308601	SPACER	TATA spare parts
265172310107	ASSY.INNER HANDLE-DARK GREY	TATA spare parts
265172310108	ASSY.INNER HANDLE-DARK GREY	TATA spare parts
265172310108AE	ASSY.INNER HANDLE -1628-1828	TATA spare parts
265172310111	ASSY.HANDLE & SPACER-WINDOW WINDING	TATA spare parts
265172310112	ASSY.HANDLE & SPACER-WINDOW WINDING	TATA spare parts
265172310113	KIT FOR LOCKS CAB RHD	TATA spare parts
265172310117	ASSY.DOOR SEALING INNER-LH	TATA spare parts
265172310118	ASSY.DOOR SEALING INNER-RH	TATA spare parts



265172500107	TURNING WINDOW COMP LH	TATA spare parts
265172500108	TURNING WINDOW COMP RH	TATA spare parts
265172500109	HINGE TURN WINDOW	TATA spare parts
265172500111	GLASS PANE LH	TATA spare parts
265172500112	GLASS PANE RH	TATA spare parts
265172500123	GUIDE FRAME LH FRONT	TATA spare parts
265172500124	GUIDE FRAME RH FRONT	TATA spare parts
265172500126	WINDOW REGULATOR LH	TATA spare parts
265172500127	WINDOW REGULATOR RH	TATA spare parts
265172500130	WINDOW REGULATOR LH BS1/2/3/4/6	TATA spare parts
265172500131	WINDOW REGULATOR RH BS1/2/3/4/6	TATA spare parts
265172500144	TOGGLE CLAMP LH	TATA spare parts
265172500145	TOGGLE CLAMP RH	TATA spare parts
265172500146	SUPPORT ROLLER TYPE	TATA spare parts
265172500150	GUIDE FRAME LH FR	TATA spare parts
265172500151	GUIDE FRAME RH FR	TATA spare parts
265172500152	GUIDE FRAME REAR	TATA spare parts
265172500154	ASSY.BRACKET(WINDOW FRAME MTG.)	TATA spare parts
265172500155	TURNING WINDOW COMP LH	TATA spare parts
265172500156	TURNING WINDOW COMP RH	TATA spare parts
265172500157	WINDOW REGULATOR LH	TATA spare parts
265172500158	WINDOW REGULATOR RH	TATA spare parts
265172500159	WINDOW REGULATOR LH	TATA spare parts
265172500164	WEATHER STRIP INNER	TATA spare parts
265172500165	WEATHER STRIP KIT LH 407	TATA spare parts
265172500166	WEATHER STRIP KIT RH 407	TATA spare parts
265172500167	WEATHER STRIP LH	TATA spare parts
265172500168	WEATHER STRIP RH	TATA spare parts
265172500171	KIT WEATHER STRIP L.H. BS6-PH2	TATA spare parts
265172500181	SIDE GUIDE FOR WINDING GLASS	TATA spare parts
265172500182	ASSY.TURNING WINDOW COMP.LH SFC-407 EX	TATA spare parts
265172500183	ASSY.TURNING WINDOW COMP.RH. SFC-407 EX	TATA spare parts
265172500184	ASSY.GLASS PANE(WITH CHANNEL)LH BS6-PH2	TATA spare parts
265172500185	ASSY.GLASS PANE(WITH CHANNEL)RH BS6-PH2	TATA spare parts
265172500191	WINDOW REGULATOR LH	TATA spare parts
265172500192	WINDOW REGULATOR RH	TATA spare parts
265172500193	ASSY ASH TRAY	TATA spare parts
265172502301	GLASS PANE REAR WINDOW	TATA spare parts
265172502302	GLASS PANE TURN WINDOW	TATA spare parts
265172502305	GLASS PANEL (DOOR)	TATA spare parts
265172502307	GLASS PANE(FIXED WINDOW)	TATA spare parts
265172502311	GLASS PANE REGULATING WINDOW GREEN TINT	TATA spare parts
265172502501	RUBBER CHANNEL	TATA spare parts
265172502514	BEADING GUIDE CHANNEL	TATA spare parts
265172502518	STOPPER	TATA spare parts
265172502535	BEADING	TATA spare parts
265172502540	BEADING TURNING WINDOW	TATA spare parts

265172502544	BEADING OUTER REAR	TATA spare parts
265172502557	VELVET CHANNELS	TATA spare parts
265172502558	VELVET CHANNEL	TATA spare parts
265172502559	INNER BEADING	TATA spare parts
265172502560	INNER BEADING	TATA spare parts
265172502562	BEADING TURNING WINDOW	TATA spare parts
265172502571	BEADING TURNING WINDOW	TATA spare parts
265172504201	LOCKING PIN	TATA spare parts
265172506301	RUBBER MOULDING LH	TATA spare parts
265172506302	RUBBER MOULDING RH	TATA spare parts
265172506314	RUBBER MOULD LH (FIXED GLASS)	TATA spare parts
265172506316	GRAB HANDLE DOOR	TATA spare parts
265172506316AE	GRAB HANDLE (DOOR) 1828	TATA spare parts
265172506318	RUBBER MOULD L/H	TATA spare parts
265172506319	RUBBER MOULD R/H	TATA spare parts
265172506321	HOUSING ASH TRAY	TATA spare parts
265172506324	CLIP WEATHER STRIP	TATA spare parts
265172506325	HOUSING (ASH TRAY)	TATA spare parts
265172506703	NYLON PIN GLASS HOLDER	TATA spare parts
265172507501	GROMMET GLASS PANE	TATA spare parts
265172507502	GROMMET(TURNING WINDOW)	TATA spare parts
265172508225	BEADING VERTICAL	TATA spare parts
265172700109	PADDING DOOR RH RHD	TATA spare parts
265172700110	PADDING DOOR LH RHD	TATA spare parts
265172700120	PADDING DOOR RH RHD	TATA spare parts
265172700121	PADDING DOOR LH RHD	TATA spare parts
265172700122	PADDING DOOR RH LHD	TATA spare parts
265172700123	PADDING DOOR LH LHD	TATA spare parts
265172700130	ASSY.PADDING DOOR L.H.LHD	TATA spare parts
265172700131	ASSY.PADDING DOOR R.H.LHD	TATA spare parts
265172700132	ASSY.PADDING DOOR RH-RHD SFC-407 EX	TATA spare parts
265172700133	ASSY.PADDING DOOR LH-RHD SFC-407 EX	TATA spare parts
265172706308	CAP - PANEL INNER DOOR	TATA spare parts
265181000102	T EMBLEM	TATA spare parts
265181000104	ASSY. `T EMBLEM 407 OVAL SHAPE	TATA spare parts
265181006302	LETTER `T'.	TATA spare parts
265181006303	LETTER `A'.	TATA spare parts
265181006304	LETTRR T	TATA spare parts
265181006305	LETTER A	TATA spare parts
265181006306	LETTER `T	TATA spare parts
265181006307	LETTER `A	TATA spare parts
265181100101	ASSY REAR VIEW MIRROR	TATA spare parts
265181100106	SUNVISOR ASSY	TATA spare parts
265181100107	MUD FLAP REAR	TATA spare parts
265181100111	GRAB HANDLE INNER	TATA spare parts
265181100115	SUNVISOR RH	TATA spare parts
265181100117	MUD FLAP REAR	TATA spare parts

265181100118	SUNVISOR LH	TATA spare parts
265181100120	SUNVISOR RH	TATA spare parts
265181100124	ASSY REAR VIEW MIRROR	TATA spare parts
265181100125	RR VIEW MIRROR INNER	TATA spare parts
265181100132	ASSY.SUNVISOR R.H.	TATA spare parts
265181100135	ASSY.R.V.MIRROR COMP.WITH MTG.RH	TATA spare parts
265181100137	ASSY.R.V.MIRROR COMP.WITH MTG.RH	TATA spare parts
265181100139	ASSY.R.V.MIRROR COMP.WITH MTG.RH	TATA spare parts
265181100140	ASSY.R.V.MIRROR COMP.WITH MTG.RH	TATA spare parts
265181100141	ASSY.R.V.MIRROR COMP.WITH MTG.RH	TATA spare parts
265181100143	ASSY.R.V.MIRROR COMP.WITH MTG.RH	TATA spare parts
265181100159	ASSY TUBULAR FRAME (RVM) HIGH DECK	TATA spare parts
265181100160	ASSY TUBULAR FRAME (RVM) NORMAL DECK	TATA spare parts
265181100162	ASSY.RVM COMPLETE RH	TATA spare parts
265181100163	ASSY.RVM COMPLETE LH	TATA spare parts
265181100167	KIT REAR VIEW MIRROR (LH RH) SFC-407 ND	TATA spare parts
265181100168	KIT ORVM LH/RH SFC-407 HD	TATA spare parts
265181100176	SUNVISOR ASSY LH BS6	TATA spare parts
265181100177	SUNVISOR ASSY RH BS6	TATA spare parts
265181100183	CLOSE PROXIMITY MIRROR ASSY BS6	TATA spare parts
265181100187	"KIT-ORVM,LH"	TATA spare parts
265181100188	"KIT-ORVM,RH"	TATA spare parts
265181100189	ORVM FRAME ASSY LH BS6	TATA spare parts
265181100190	ORVM FRAME ASSY RH BS6	TATA spare parts
265181100191	KIT-ORVM LH BS6-PH2	TATA spare parts
265181100192	KIT-ORVM RH BS6-PH2	TATA spare parts
265181102101	SUPPORT LH RV MIRROR	TATA spare parts
265181102102	SUPPORT RH RV MIRROR	TATA spare parts
265181103301	BKT REAR VIEW MIRROR	TATA spare parts
265181104201	SPRING CLAMP	TATA spare parts
265181106301	RUBBER PAD	TATA spare parts
265181106314	RUBBER PAD NEOPRENE	TATA spare parts
265181106317	CLAMP [ SUN VISOR ]	TATA spare parts
265181106318	WASHER R.V.M.MTG	TATA spare parts
265181106325	SPLIT CLIP	TATA spare parts
265181108204	BRACKET (JACK MTG.)	TATA spare parts
265181108701	SPRING RVM MTG	TATA spare parts
265181110102	KIT-ORVM-LH BS6	TATA spare parts
265181110103	KIT-ORVM-RH BS6	TATA spare parts
265181800102	ASSY MASCOT EX	TATA spare parts
265181900109	ASSY.SIDE SHIELDING L.H.RHD	TATA spare parts
265181900110	ASSY.SIDE SHIELDING R.H.RHD	TATA spare parts
265181900111	ASSY.FRONT SHIELDING	TATA spare parts
265181900120	ASSY. SIDE SHIELDING RH RHD (SFC 407 CNG	TATA spare parts
265182400101	WIPER ARM	TATA spare parts
265182400102	WIPER ARM	TATA spare parts
265182400103	WIPER BLADE	TATA spare parts

265182400106	KIT FOR ELECTRIC W/S WASHER	TATA spare parts
265182400107	NOZZLE ASSY	TATA spare parts
265182400110	WIPER ARM	TATA spare parts
265182400111	SUPPORT ARM	TATA spare parts
265182400112	WIPER BLADE	TATA spare parts
265182400113	KIT WIPER MOTOR	TATA spare parts
265182400114	WIPER BLADE	TATA spare parts
265182400115	WIPER ARM	TATA spare parts
265182400116	WIPER ARM	TATA spare parts
265182400118	KIT FOR ELECTRIC W/S WASHER	TATA spare parts
265182400119	PUMP ASSY W/S WASHER	TATA spare parts
265182400122	BRACKET	TATA spare parts
265182400123	WIPER ARM ASSY DR LHD	TATA spare parts
265182400124	ASSY SUPPORT ARM RHD	TATA spare parts
265182400126	ASSY WIPER BLADE	TATA spare parts
265182400127	ASSY WIPER BLADE	TATA spare parts
265182400128	ASSY WIPER ARM	TATA spare parts
265182400129	ASSY WIPER ARM LHD	TATA spare parts
265182400130	WIPER ARM ASSY	TATA spare parts
265182400131	WIPER ARM ASSY CODR RHD	TATA spare parts
265182400132	WIPER ARM SET 407 DS RHD	TATA spare parts
265182400133	ASSY WIPER ARM & BLADE	TATA spare parts
265182400134	ASSY WIPER ARM SUPPORT ARM & BLADE	TATA spare parts
265182400135	ASSY WIPER ARM & BLADE	TATA spare parts
265182400136	ASSY WIPER ARM SUPPORT ARM & BLADE	TATA spare parts
265182400137	ASSY WIPER ARM & BLADE	TATA spare parts
265182400138	KIT WIPER MOTOR	TATA spare parts
265182400139	WIPER MOTOR KIT	TATA spare parts
265182400150	ASSY WIPER ARM & BLADE	TATA spare parts
265182400151	ASSY WIPER ARM BLADE & SUPPORT ARM	TATA spare parts
265182400152	ASSY WIPER ARM & BLADE	TATA spare parts
265182400153	ASSY WIPER ARM BLADE & SUPPORT ARM	TATA spare parts
265182400158	ASSY.WIPER KIT-W/5 P.CONN.	TATA spare parts
265182400165	ACCESSORIES KIT FOR WIPER MOTOR	TATA spare parts
265182400169	KIT FOR W/S.WASHER UNIT-OFFER DRG.	TATA spare parts
265182400170	KIT FOR W/S.WASHER UNIT	TATA spare parts
265182400171	KIT FOR W/S WASHER	TATA spare parts
265182400172	KIT FOR W/S.WASHER UNIT	TATA spare parts
265182400173	ASSY.WIPER KIT-W/5 P.CONN.	TATA spare parts
265182400174	ACCESSORIES KIT FOR WIPER MOTOR	TATA spare parts
265182400176	ASSY WIPER BLADE	TATA spare parts
265182400177	ASSY WIPER ARM	TATA spare parts
265182400178	ASSY WIPER KIT (W/5P CONN) OFFER	TATA spare parts
265182400179	ASSY.WIPER ARM SUPPORT ARM & BLADE	TATA spare parts
265182400180	ASSY WIPER ARM & BLADE -OFFER	TATA spare parts
265182400181	ASSY.WIPER ARM SUPPORT ARM & BLADE	TATA spare parts
265182400182	ASSY WIPER ARM SUPPORT ARM & BLADE	TATA spare parts

265182400182AE	ASSY WIPER ARM SUPPORT ARM & BLADE	TATA spare parts
265182400187	KIT FOR W/S.WASHER UNIT	TATA spare parts
265182400188	ASSY.WIPER MOTOR W/BKT/MSSL LHD	TATA spare parts
265182400189	ASSY.WIPER MOTOR W/BKT/MSSL LHD	TATA spare parts
265182400191	KIT FOR W/S.WASHER UNIT	TATA spare parts
265182400193	ASSY.COVER (FOR WHEEL BOX CUT OUT)	TATA spare parts
265182400194	ASSY.COVER (FOR WHEEL BOX CUT OUT) BS6	TATA spare parts
265182400199	ASSY WIPER ARM SUPPORT ARM & BLADE	TATA spare parts
265182406302	PLASTIC TANK W/S WASHER	TATA spare parts
265182407501	RUBBER WASHER	TATA spare parts
265182408211	BKT WIPER MOTOR MTG	TATA spare parts
265182409901	WIPER MOTOR RHD 17W 12V	TATA spare parts
265182409902	ASSY. NOZZLE OF LPTA 1623	TATA spare parts
265182409905	ELEC MOTOR W/PUMP W/S	TATA spare parts
265182409906	PIPE	TATA spare parts
265182409907	SEAL FOR BRACKET BS6	TATA spare parts
265182409909	BALL PIN	TATA spare parts
265182409911	WIPER MOTOR LHD 17W 12V	TATA spare parts
265182409927	WHEEL BOX	TATA spare parts
265182409928	WIPER MOTOR RHD	TATA spare parts
265182409935	WIPER MOTOR 17W	TATA spare parts
265182409937	WIPER MOTOR 407	TATA spare parts
265182409938	WIPER MOTOR W/MSSL TRS.& HSG.	TATA spare parts
265182409943	WIPER MOTOR (W/MSSL TER & HSG)LHD	TATA spare parts
265182409944	WIPER MOTOR(W/MSSL TER & HSG)LHD	TATA spare parts
265182409945	WIPER MOTOR 17W	TATA spare parts
265182409947	WIPER MOTOR W/MSSL TRS.& HSG.	TATA spare parts
265182409952	BALL PIN	TATA spare parts
265182410105	KIT FOR W/S.WASHER UNIT	TATA spare parts
265182410106	ASSY W/S WASHER UNIT 1.5LIT	TATA spare parts
265183100103	DUCT REAR LH VENT	TATA spare parts
265183100104	DUCT REAR RH VENT	TATA spare parts
265183100105	BRACKET	TATA spare parts
265183100107	DUCT REAR COMP LH	TATA spare parts
265183100108	DUCT REAR COMP RH	TATA spare parts
265183100111	ASSY.PLENUM CHAMBER COMPLETE - RHD	TATA spare parts
265183100120	ASSY.FRESH AIR VALVE COMPLETE- RHD.	TATA spare parts
265183100121	ASSY.FRESH AIR VALVE COMPLETE - LHD	TATA spare parts
265183100123	ASSY.AIR DUCT	TATA spare parts
265183100128	ASSY.BRACKET RH [PLENUM MTG.]	TATA spare parts
265183100129	ASSY.BRACKET LH [PLENUM MTG.]	TATA spare parts
265183100130	ASSY.COIL HOUSING UPPER - RHD.	TATA spare parts
265183100131	ASSY.COIL HOUSING UPPER - LHD	TATA spare parts
265183100132	ASSY.VENTILATION DUCT L.H.	TATA spare parts
265183100133	ASSY.VENTILATION DUCT R.H.	TATA spare parts
265183100148	ASSY.BRKT.[FOR DUCT MTG.]	TATA spare parts
265183100149	ASSY.COIL HOUSING LOWER - RHD.	TATA spare parts

265183100150	ASSY.COIL HOUSING LOWER - LHD	TATA spare parts
265183100153	ASSY.PLENUM CHAMBER COMPLETE - LHD	TATA spare parts
265183100154	ASSY.MOUNTING BRACKET (DEFROST NOZZLE)	TATA spare parts
265183100156	ASSY.BRACKET ( COVER MTG.)	TATA spare parts
265183100161	ASSY.BLOWER (SUBROS)-LHD.	TATA spare parts
265183100162	ASSY.DEFROST DUCT COMPLT (INJ.MOULDED).	TATA spare parts
265183100166	ASSY.DEFROST DUCT COMPLETE	TATA spare parts
265183100169	ASSY.VENT.DUCT-LH BS-III	TATA spare parts
265183106305	CONNECTOR DUCT	TATA spare parts
265183106306	VENTILATION DUCT LH	TATA spare parts
265183106307	VENTILATION DUCT RH	TATA spare parts
265183106308	DUCT FRONT LH VENT	TATA spare parts
265183106309	DUCT FRONT RH VENT	TATA spare parts
265183106316	ADAPTOR COIL HOUSING	TATA spare parts
265183106317	GASKET (ADAPTOR TO COIL HOUSING)	TATA spare parts
265183106333	COVER LHD ( FOR A.C.UNIT )	TATA spare parts
265183106334	COVER RHD (FOR A.C.UNIT)	TATA spare parts
265183106336	ELBOW DUCT (FOR VENT NOZZLE)	TATA spare parts
265183107701	SEALING RR DUCT VENT	TATA spare parts
265183107702	SEALING VENT DUCT DASH PANEL	TATA spare parts
265183108205	BKT VENTILATION DUCT	TATA spare parts
265183108214	COVER(AT PLENUM MTG)	TATA spare parts
265183108217	BRACKET(VENTILATION DUCT)RH	TATA spare parts
265183300101	CABLE VENTILATION	TATA spare parts
265183300102	ASSY CABLE VENTILATION	TATA spare parts
265183300103	ASSY.VENTILATION CABLE	TATA spare parts
265183300104	VENTILATION CABLE	TATA spare parts
265183300117	ASSY.PUSH-PULL CABLE- GREEN	TATA spare parts
265183300121	ASSY.CONTROL COVER	TATA spare parts
265183300122	ASSY.PUSH PULL CABLE 'Z'TYPE.	TATA spare parts
265183300126	ASSY.PUSH PULL CABLE Z TYPE	TATA spare parts
265183300132	ASSY.CONTROL COVER.- HEATER	TATA spare parts
265183300134	ASSY.CABLE VENTILATION	TATA spare parts
265183400135	ASSY.STRIP (TWIN BLOWER MTG.)	TATA spare parts
265183400156	ASSY.HEATER COIL	TATA spare parts
265183406301	GROMMET FOR A/C HOSES	TATA spare parts
265183408203	CLAMP A C HOSES 407	TATA spare parts
265183500119	ASSY.BRKT.-LHD [WATER VALVE MTG.]	TATA spare parts
265183505801	RUB HOSE 17X550 MM LONG	TATA spare parts
265183505802	RUBBER HOSE [ 17 ID X L 1320 ]	TATA spare parts
265183505802AE	RUB HOSE [17IDXL1320 ] LPT 2523	TATA spare parts
265183505805	RUBBER HOSE L2300	TATA spare parts
265183505806	RUBBER HOSE (ENGINE TO HEATING UNIT)	TATA spare parts
265183505807	RUBBER HOSE (RADIATOR TO HEATING UNIT)	TATA spare parts
265183505808	RUBBER HOSE(17 ID X L 1320)	TATA spare parts
265183507503	RUBBER GROMMET(REAR WALL)	TATA spare parts
265183707501	RUBBER GROMMET (RELEASE CABLE)	TATA spare parts

265183800102	GRILLED BOARD VENT	TATA spare parts
265183800104	GRILL VENTILATION	TATA spare parts
265183806307	CONNECTOR VENT DUCT	TATA spare parts
265183807702	CONNECTOR VENTILATION	TATA spare parts
265186900102	ASSY.CANOPY COVER	TATA spare parts
265188100101	BONNET SIDE LH	TATA spare parts
265188100102	BONNET SIDE RH	TATA spare parts
265188100108	ASSY. SIDE BONNET L.H. BS2/3/4	TATA spare parts
265188100109	ASSY. BONNET SIDE RH BS2/3/4	TATA spare parts
265188108203	RAIN CHANNEL L.H.(SIDE BONNET) BS6	TATA spare parts
265188108204	RAIN CHANNEL SIDE RH BONNET BS6	TATA spare parts
265188108210	BONNET SIDE L.H.	TATA spare parts
265188500103	ASSY BUMPER RHD	TATA spare parts
265188500110	BUMPER COMPLETE RHD	TATA spare parts
265188500111	ASSY.BUMPER COMPLETE LHD	TATA spare parts
26518850011821	ASSY BUMPER COMP PAINTED WITH REFLECTOR	TATA spare parts
26518850011822	ASSY. BUMPER POWDER COATED W/REFL BS2-6	TATA spare parts
265188506305	RETRO-REFLECTIVE TAPE FRONT(WHITE)	TATA spare parts
265188506306	END CAP BUMPER LH	TATA spare parts
265188506307	END CAP BUMPER RH	TATA spare parts
265188506308	RETRO-REFLECTIVE TAPE FRT.(WHITE)	TATA spare parts
265188508202	SUPPORT BUMPER MTG	TATA spare parts
265188508213	END COVER LH(BUMPER)407	TATA spare parts
265188508214	END COVER RH(BUMPER)407	TATA spare parts
265188600101	PANEL INN BONNET FR LH	TATA spare parts
265188600102	PANEL INN BONNET FR RH	TATA spare parts
265188700101	ASSY REINF SIDE RH BONNET CENTRE BS6	TATA spare parts
265188700102	ASSY REINF SIDE LH BONNET CENTRE BS6	TATA spare parts
265188700108	HINGE LINKAGE RH BONNET	TATA spare parts
265188700109	HINGE LINKAGE LH BONNET	TATA spare parts
265188700113	RUBBER BUFFER	TATA spare parts
265188700121	RELEASE CABLE COMP RH	TATA spare parts
265188700122	ASSY. CENTRE BONNET BS2/3/4	TATA spare parts
265188700123	CLAMP-TOGGLE-BONNET 407	TATA spare parts
265188700124	ENGINE HOOD	TATA spare parts
265188700126	STAY ROD	TATA spare parts
265188700129	STAY TUBE	TATA spare parts
265188700132	RELEASE CABLE COMP RH	TATA spare parts
265188700134	TOGGLE CLAMP ENG HOOD	TATA spare parts
265188700141	BONNET LOCK BONNET SIDE	TATA spare parts
265188700144	BONNET LOCK COWL SIDE	TATA spare parts
265188700147	BONNET LOCK BONNET SIDE	TATA spare parts
265188700161	ASSY.SPRING CLAMP(RUBBER BUFFER)	TATA spare parts
265188700167	ENGINE HOOD 407	TATA spare parts
265188700170	ASSY BONNET CABLE LHD 407	TATA spare parts
265188700171	CABLE ASSY CENTRE 34 WB	TATA spare parts
265188700175	ASSY.STAY TUBE	TATA spare parts

265188700176	ASSY STAY TUBE LH-RHD	TATA spare parts
265188700177	ASSY.STAY TUBE RH-LHD	TATA spare parts
265188700183	ASSY.BONNET LOCK	TATA spare parts
265188700193	ASSY.BONNET CENTRE FRONT	TATA spare parts
265188703306	BKT DOVETAIL BOTTOM LH	TATA spare parts
265188703401	BUSH BONNET STAY ROD	TATA spare parts
265188704202	SPRING CLAMP	TATA spare parts
265188705801	SLEEVE BONNET STAY ROD BS6	TATA spare parts
265188706302	CLAMP	TATA spare parts
265188706303	END CAP [ STAY ROD ]	TATA spare parts
265188706310	BONNET SEAL REAR	TATA spare parts
265188706903	REINF TUBE (CENTRE BONNET) FRONT BS6	TATA spare parts
265188707701	SEALING FR ENG HOOD	TATA spare parts
265188707702	SEALING BOTTOM ENG HOOD	TATA spare parts
265188707707	SEALING FRONT	TATA spare parts
265188707708	SEALING BOTTOM	TATA spare parts
265188707712	SEALING FRONT	TATA spare parts
265188707715	SEALING BOTTOM-NEOPRENE	TATA spare parts
265188707717	SEALING BOTTOM ENG HOOD	TATA spare parts
265188707718	ENG HOOD SEALING BOTTOM	TATA spare parts
265188708225	BRACKET(CENTRE BONNET) BS6	TATA spare parts
265188708228	SHIM	TATA spare parts
265188708232	SUPPORT BS6	TATA spare parts
265188708704	TENSION SPG RET BONNET	TATA spare parts
265188708706	TENSION SPRING SEC LOCK	TATA spare parts
265188708707	TORSION SPG BONNET LOCK	TATA spare parts
265188800102	GRILL BONNET CENTRE	TATA spare parts
265188800103	GRILL BONNET LH	TATA spare parts
265188800104	GRILL BONNET RH	TATA spare parts
265188800114	ASSY.PLASTIC GRILL LH-SIDE BONNET	TATA spare parts
265188800115	ASSY.PLASTIC GRILL RH-SIDE BONNET	TATA spare parts
265188800116	ASSY. PLASTIC GRILL W/T EMBLEM BS2	TATA spare parts
265188806307	RUBBER WASHER	TATA spare parts
265188806310	GRIP BEADING BONNET CENTRE	TATA spare parts
265188807501	RUBBER GROMMET	TATA spare parts
265188808203	RADIATOR GRILL-FACELESS	TATA spare parts
265189100102	RUBBER MTG TOP BS6-PH2	TATA spare parts
265189100105	TIE MEMBER	TATA spare parts
265189100106	MOUNTING BRACKET RR	TATA spare parts
265189103303	MOUNTING BRACKET LH	TATA spare parts
265189103701	PACKING FOR `U CLAMP	TATA spare parts
265189104201	U CLAMP	TATA spare parts
265189106301	RUBBER MOUNTING TOP	TATA spare parts
265189106303	RUBBER MOUNTING BOTTOM	TATA spare parts
265189106304	RUBBER MOUNT BOTTOM BS6-PH2	TATA spare parts
265189106902	SPACER	TATA spare parts
265189106903	SPACER LONG	TATA spare parts



265189108215	PLATE	TATA spare parts
265189108216	PLATE RUBBER MOUNTING	TATA spare parts
265189506301	BATTERY ACID TRAY	TATA spare parts
265191000101	ASSY DRIVERS SEAT	TATA spare parts
265191000108	SEAT DRIVER RHD	TATA spare parts
265191000110	ASSY.DRIVER'S SEAT LHD	TATA spare parts
265191000114	ASSY.DRIVER SEAT RHD	TATA spare parts
265191000116	SEAT DRIVER LHD	TATA spare parts
265191000117	SEAT DRIVER RHD	TATA spare parts
265191000120	ASSY.DRIVER SEAT W/HEAD REST-LHD	TATA spare parts
265191000121	SEAT DRIVER RHD	TATA spare parts
265191000122	DRIVER SEAT ASSY.LHD	TATA spare parts
265191000131	DRIVER SEAT ASS.WITH HEAD REST-RHD	TATA spare parts
265191000132	ASSY.DRIVER SEAT W/HEAD REST-RHD	TATA spare parts
265191000134	ASSY.DRIVER SEAT W/O H/R	TATA spare parts
265191000135	ASSY.DR.SEAT WITH- HR LHD	TATA spare parts
265191080106	RECLINING BRACKET ASSY	TATA spare parts
265191500101	ASSY.LAP SAFETY BELT WITH BUCKLE	TATA spare parts
265191500103	ASSY.SAFETY BELT WITH BUCKLE FLOOR MTG	TATA spare parts
265191500104	ASSY.SEAT BELT KIT(CO-DRIVER)	TATA spare parts
265191500107	ASSY.SEAT BELT KIT(CO-DRIVER MIDDLE)	TATA spare parts
265191500110	SEAT BELT KIT(DRIVER)W/ MICRO SW.	TATA spare parts
265191500113	SEAT BELT KIT COMPLETE	TATA spare parts
265191500114	SEAT BELT KIT(CO-DR.MIDDLE)NON EC	TATA spare parts
265191500123	SEAT BELT KIT COMPLETE RHD(NON EC)	TATA spare parts
265191500124	SEAT BELT KIT DRIVER RHD(NON EC)	TATA spare parts
265191500135	ASSY.SEAT BELT COMPL.[MIDDLE]	TATA spare parts
265191500142	SEAT BELT KIT DRIVER W/O MC.SW.(EC)	TATA spare parts
265191500154	ASSY.SEAT BELT KIT COMPLETE.	TATA spare parts
265191500155	ASSY.SEAT BELT COMPLETE-DRIVER	TATA spare parts
265191500156	ASSY.SEAT BELT COMPLETE-MIDDLE	TATA spare parts
265191500157	ASSY.SEAT BELT COMPLETE-CODRIVER	TATA spare parts
265191500172	ASSY.SEAT BELT KIT COMPLETE	TATA spare parts
265191500173	SEAT BELT KIT (DRIVER)	TATA spare parts
265191500175	ASSY. SEAT BELT (CO-DRIVER)	TATA spare parts
265191510103	ASSY.SEAT BELT KIT COMPLETE-PASSIVE	TATA spare parts
265194000108	CO DRIVER SEAT ASSY LHD	TATA spare parts
265194000109	BACK SEAT	TATA spare parts
265194000113	ASSY CO-DRIVER S SEAT RHD	TATA spare parts
265194000118	CO DRIVER SEAT ASSY RHD	TATA spare parts
265194000123	ASSY.CO-DRIVER SEAT LHD	TATA spare parts
265194000124	CO DRIVER SEAT RHD	TATA spare parts
265194000126	ASSY.CODRIVER SEAT-RHD	TATA spare parts
265194000127	ASSY.CODRIVER SEAT-RHD	TATA spare parts
265194000131	ASSY.CODRIVER SEAT RHD	TATA spare parts
265194000133	ASSY.CO-DRIVER SEAT W/FOLDABLE GAP SEAT.	TATA spare parts
265194000134	ASSY.CO-DRIVER SEAT W/FOLDABLE GAP SEAT	TATA spare parts

265194000135	ASSY.CO-DRIVER SEAT W/FOLDABLE GAP SEAT.	TATA spare parts
265194000137	ASSY.CO-DRIVER SEAT W/FOLDABLE GAP SEAT.	TATA spare parts
265194000139	ASSY.CO.DR.W/GAP SEAT & HEAD REST-RHD	TATA spare parts
265194000141	ASSY.CO.DR.W/GAP SEAT & HEAD REST-RHD	TATA spare parts
265194000143	ASSY.CO.DR.W/GAP SEAT & HEAD REST-RHD	TATA spare parts
265194000145	ASSY.CO.DR.W/GAP SEAT & HEAD REST-RHD	TATA spare parts
265198400101	ASSY LETTER T	TATA spare parts
265198400102	LETTER A	TATA spare parts
265198406301	LETTER T	TATA spare parts
265198406302	LETTER A	TATA spare parts
265198800102	LOCK ASSY W/KEY	TATA spare parts
265198800103	MASCOT 407	TATA spare parts
265198800104	LOCK ASSY W/KEY	TATA spare parts
265198800106	MASCOT 407	TATA spare parts
265198806302	MASCOT 407 NEW	TATA spare parts
265199000101	HEX SCREW W/NYLON INSERT	TATA spare parts
265199006501	WELD NUT M6.1 BS6	TATA spare parts
265200000101	ASSY KIT FOR COLD START FOR SFC410 ST	TATA spare parts
265200000102	ASSY KIT FOR COLD START COLDSTART-SK410	TATA spare parts
265200000105	ASSY KIT FOR COLD START FOR SFC COWL	TATA spare parts
265215400104	ALTERNATOR 12V 117A WITH VACCUM PUMP	TATA spare parts
265215409901	STATOR WINDING ASSY.	TATA spare parts
265215608207	WH_SENSOR_CLAMPING_BKT_ON_ROCKER_COV	TATA spare parts
265216100103	CONTAINER 4SPCR (SFC407 BS-IV)	TATA spare parts
265216100104	CONTAINER 4SPCR (SFC407TT BS-IV)	TATA spare parts
265216100106	CONTAINER 4SPCR (SFC407 BS-IV 7.0X16PR)	TATA spare parts
265224100103	ASSY.BRACKET-RH (ARB & ENGINE MOUNTING)	TATA spare parts
265224100104	ASSY. BRACKET-LH (ARB & ENGINE MOUNTING)	TATA spare parts
265224100105	ENGINE MTG FRONT RH	TATA spare parts
265224100106	ENGINE MTG FRONT LH	TATA spare parts
265229100107	ASSY.CLUTCH PEDAL COMPLETE	TATA spare parts
265229100119	CLUTCH MASTER CYL. 19.05 DIA.	TATA spare parts
265229100122	ASSY. REINFORCEMENT	TATA spare parts
265229100123	ASSY BRAKE PEDAL	TATA spare parts
265229100124	ASSY. BRAKE PEDAL WITH RUBBER COVER	TATA spare parts
265229100130	ASSY.CLUTCH PIPE (FRONT)	TATA spare parts
265229100138	BRACKET ASSY CLUTCH & BRAKE PEDAL MTG	TATA spare parts
265229100141	CLUTCH PEDAL ASSY WITH RUBBER COVER	TATA spare parts
265229200102	BRAKE PEDAL ASSY WITH RUBBER COVER	TATA spare parts
265230100103	BRACKET ASSY ACCELERATOR PEDAL MTG	TATA spare parts
265231000101	ASSY FRAME 406/27 -TRUCK VERSION	TATA spare parts
265231000102	ASSY FRAME 406/27 - BUS VERSION	TATA spare parts
265231000104	ASSY. FRAME 407NA BUS 2750WB (BS-II)	TATA spare parts
265231000105	ASSY FRAME COMPLETE	TATA spare parts
265231000106	ASSY.FRAME SFC 407/27 EX,BS-II,MECH STG.	TATA spare parts
265231000108	ASSY FRAME WITH CLEATS	TATA spare parts
265231000112	"FRAME COMPLETE (SFC 407 CNG,BS-IV)"	TATA spare parts

265231000113	FRAME ASSY WITH FITMENT	TATA spare parts
265231000114	ASSY. FRAME WITH FITMENT BS3	TATA spare parts
265231000115	ASSY FRAME (SFC407 BS-III/31WB)	TATA spare parts
265231000119	ASSY FRAME (410 FES TMML)	TATA spare parts
265231000122	FRAME ASSY	TATA spare parts
265231000123	ASSY. FRAME WITH FITMENT BS3/4	TATA spare parts
265231000124	ASSY. FRAME	TATA spare parts
265231000125	ASSY. FRAME SFC 407 BS3	TATA spare parts
265231000126	FRAME ASSY.COMPLETE	TATA spare parts
265231000127	FRAME ASSY WITH FITMENT	TATA spare parts
265231000128	FRAME ASSY. COMPLETE	TATA spare parts
265231000130	ASSY. FRAME SFC 407 BS3/4	TATA spare parts
265231000131	ASSY. FRAME SFC407	TATA spare parts
265231000132	FRAME ASSY WITH FITMENT	TATA spare parts
265231000133	ASSY FRAME (SFC 407/31 TT BS-IV RUPD)	TATA spare parts
265231000135	ASSY. FRAME WITH FITMENT SFC 407 BS3/4	TATA spare parts
265231000141	FRAME ASSY WITH FITMENT	TATA spare parts
265231000146	FRAME ASSY WITH FITMENT	TATA spare parts
265231200101	CROSS MEMBER ASSY	TATA spare parts
265231200102	CROSS MEMBER ASSY	TATA spare parts
265231208201	REINFORCEMENT (BOTTOM)-RH	TATA spare parts
265231208202	REINFORCEMENT (BOTTOM)-LH	TATA spare parts
265231208210	REINFORCEMENT (REAR)-RH	TATA spare parts
265231208211	REINFORCEMENT (REAR)-LH	TATA spare parts
265231208212	REINFORCEMENT BS6	TATA spare parts
265231400101	ASSY.REAR SPRING REAR CROSS MEMBER	TATA spare parts
265231400102	ASSY CROSS MEMBER (REAR SPRING FRONT)	TATA spare parts
265231400103	ASSY CROSS MEMBER (CENTER BRG.MTG.)	TATA spare parts
265231400104	ASSY CROSS MEMBER (CENTRE BEARING)	TATA spare parts
265231400106	ASSY. CENTRE BEARING CROSS MEMBER	TATA spare parts
265231400107	ASSY.CROSS MEMBER REAR SPRING FRONT	TATA spare parts
265231400110	ASSY. CENTRE BEARING CROSS MEMBER	TATA spare parts
265231400111	ASSY. CROSS MEMBER REAR SPRING FRONT	TATA spare parts
265231400112	ASSY. CENTRE BEARING CROSS MEMBER	TATA spare parts
265231400113	ASSY. CROSS MEMBER(REAR SPRING FRONT)	TATA spare parts
265231400114	ASSY. REAR SHOCK ABSORBER C.M.	TATA spare parts
265231400115	ASSY. REAR SPRING REAR CROSS MEMBER	TATA spare parts
265231400118	ASSY BRACKET-RH (RADIATOR MOUNTING)	TATA spare parts
265231400119	ASSY BRACKET-LH (RADIATOR MOUNTING)	TATA spare parts
265231400124	ASSY.CROSS MEMBER (REAR SPRING FRONT)	TATA spare parts
265231400125	ASSY. CROSS MEMBER (REAR SPRING FRONT)	TATA spare parts
265231400126	ASSY. CROSS MEMBER (CENTRE/THIRD CM)	TATA spare parts
265231400127	ASSY.CROSS MEMBER	TATA spare parts
265231400128	ASSY CROSS MEMBER	TATA spare parts
265231400129	CROSS MEMBER ASSY.(CENTER BEARING)	TATA spare parts
265231400133	CROSSMEMBERASSY BS6	TATA spare parts
265231400134	CROSS MEMBER ASSY BS6	TATA spare parts

265231400135	CROSS MEMBER ASSY BS6	TATA spare parts
265231400137	CROSSMEMBERASSYBS6	TATA spare parts
265231408201	END CROSS MEMBER	TATA spare parts
265231408213	REINFORCEMENT - RH	TATA spare parts
265231408214	REINFORCEMENT - LH	TATA spare parts
265231408216	REINFORCEMENT - RH	TATA spare parts
265231408217	REINFORCEMENT - LH	TATA spare parts
265231408225	REINFORCEMENT RH BS6	TATA spare parts
265231408226	REINFORCEMENT LH BS6	TATA spare parts
265231500102	ASSY TOWING HOOK	TATA spare parts
265231505103	TOW HOOK	TATA spare parts
265231700101	ASSY. BRACKET - LH	TATA spare parts
265231700102	ASSY. BRACKET - RH	TATA spare parts
265231700106	BRACKET ASSY RUPD MTG LH	TATA spare parts
265231700107	BRACKET ASSY RUPD MTG RH	TATA spare parts
265231700113	BEAM ASSY RUPD	TATA spare parts
265231700114	BEAM ASSY RUPD	TATA spare parts
265231703301	BRACKET RUPD MTG LH	TATA spare parts
265231703302	BRACKET RUPD MTG RH	TATA spare parts
265232100106	ASSY. FRONT SPRING - PARABOLIC	TATA spare parts
265232100108	ASSY. FRONT PARABOLIC SPRING FOR SFC410	TATA spare parts
265232100109	FRONT SPRING ASSY BS6	TATA spare parts
265232100112	ASSY FIRST LEAF WITH BUSH	TATA spare parts
265232100113	ASSY. SPRING HANGER BRKT (FRONT-FRONT)RH	TATA spare parts
265232100114	ASSY. SPRING HANGER BRKT (FRONT-FRONT)LH	TATA spare parts
265232100130	ASSY. FRONT SPRING (TRUCK)	TATA spare parts
265232100131	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
265232103201	CENTRE BOLT M10X65X11	TATA spare parts
265232107105	FIRSTLEAF BS6	TATA spare parts
265232107106	THIRD LEAF	TATA spare parts
265232107107	SECOND LEAF	TATA spare parts
265232107108	FIRST LEAF BS6	TATA spare parts
265232107109	SECOND LEAF	TATA spare parts
265232107110	THIRD LEAF	TATA spare parts
265232107111	FOURTH LEAF	TATA spare parts
265232107112	FIFTH LEAF	TATA spare parts
265232108301	CENTRE PAD	TATA spare parts
265232200101	ASSY. BUMP STOPPER (EMRI AMBULANCE)	TATA spare parts
265232203701	CASTER PLATE BS6	TATA spare parts
265232204201	U CLAMP (FRONT)	TATA spare parts
265232204202	U CLAMP RR SPRING	TATA spare parts
265232300105	FRONT SHOCK ABSORBER	TATA spare parts
265232301601	FRONT SHOCK ABSORBER	TATA spare parts
265232400105	ASSY. REAR SPRING	TATA spare parts
265232400106	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
265232400115	ASSY REAR SPRING	TATA spare parts
265232400116	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts

265232400121	ASSY. SHACKLE REAR SPRING(REVERSE SHACKL	TATA spare parts
265232400132	BRACKET ASSY REAR SPRING FRONT-LH	TATA spare parts
265232400133	BRACKET ASSY REAR SPRING FRONT-RH	TATA spare parts
265232400134	BRACKET ASSY SPRING HANGER REAR-LH	TATA spare parts
265232400135	BRACKET ASSY SPRING HANGER REAR-RH	TATA spare parts
265232403501	PIN	TATA spare parts
265232403701	CASTER PLATE REAR SPRING	TATA spare parts
265232406701	SPRING PIN (REAR)	TATA spare parts
265232407110	SECOND LEAF	TATA spare parts
265232407111	THIRD LEAF	TATA spare parts
265232407112	FOURTH LEAF	TATA spare parts
265232407113	FIFTH LEAF	TATA spare parts
265232407114	SIXTH LEAF	TATA spare parts
265232407115	SEVENTH LEAF	TATA spare parts
265232407116	EIGHTH LEAF	TATA spare parts
265232407117	NINTH LEAF	TATA spare parts
265232407118	TENTH LEAF	TATA spare parts
265232407119	ELEVENTH LEAF	TATA spare parts
265232407120	FIRST LEAF BS6	TATA spare parts
265232407121	SECOND LEAF	TATA spare parts
265232407122	THIRD LEAF	TATA spare parts
265232407123	FOURTH LEAF	TATA spare parts
265232407124	FIFTH LEAF	TATA spare parts
265232407125	SIXTH LEAF	TATA spare parts
265232407126	SEVENTH LEAF	TATA spare parts
265232407127	EIGHTH LEAF	TATA spare parts
265232407128	NINETH LEAF	TATA spare parts
265232407129	TENTH LEAF	TATA spare parts
265232407131	CASTER PLATE REAR SPRING	TATA spare parts
265232407132	LOCK PLATE	TATA spare parts
265232407143	BACK PLATE BS6	TATA spare parts
265232504201	U CLAMP REAR	TATA spare parts
265232504203	U CLAMP REAR	TATA spare parts
265232600105	REAR SHOCK ABSORBER	TATA spare parts
265232600107	ASSY REAR SHOCK ABSORBER	TATA spare parts
265232601601	REAR SHOCK ABSORBER	TATA spare parts
265233000102	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
265233400102	FRONT HUB ASSY BS6	TATA spare parts
265233400103	FRONT HUB ASSY WITH PINS	TATA spare parts
265233405501	FRONT HUB BS6	TATA spare parts
265240100117	ASSY WHEEL RIM 5.5FX16 (6 STUD HOLE)	TATA spare parts
265240109909	TUBE	TATA spare parts
265240109910	TUBE	TATA spare parts
265241000102	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
265241000107	ASSY.UNITISED PROP.SHAFT COMPLETE	TATA spare parts
265241000112	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
265241100101	ASSY. PROP. SHAFT (FRONT)	TATA spare parts

265241110101	ASSY.PROP.SHAFT WITH CENTRE BEARING.	TATA spare parts
265241110106	ASSY FRONT PROP.SHAFT	TATA spare parts
265241120102	ASSY. PROP. SHAFT REAR.407MINI BS3	TATA spare parts
265241120111	ASSY PROP. SHAFT (4X4 FRONT-1)	TATA spare parts
265241120112	ASSY PROP. SHAFT (4X4 FRONT-2).	TATA spare parts
265241120113	ASSY PROP. SHAFT (4X4 REAR).	TATA spare parts
265241120115	ASSY. PROP. SHAFT (REAR)	TATA spare parts
265241120119	ASSY REAR PROP.SHAFT	TATA spare parts
265241120120	SLEEVE YOKE ASSY	TATA spare parts
265241120121	ASSY PROP SHAFT COMPLETE	TATA spare parts
265241125101	SLIP SHAFT	TATA spare parts
265242130101	ASSY PRIMARY SHOE WITH LINING (AFS2)	TATA spare parts
265242130102	ASSY SECONDARY SHOE WITH LINING (AFS2)	TATA spare parts
265242300103	ASSY. REAR AXLE BRAKE LH	TATA spare parts
265242300104	ASSY. REAR AXLE BRAKE RH	TATA spare parts
265242300115	ASSY. REAR AXLE BRAKE RH NON ASB	TATA spare parts
265242300116	ASSY. REAR AXLE BRAKE LH NON-ASB.	TATA spare parts
265242300124	ASSY. RA BRAKE LH	TATA spare parts
265242300130	BRAKE AGGR ASSY REAR-RH	TATA spare parts
265242300131	BRAKE AGGR ASSY REAR-LH	TATA spare parts
265242400101	ASSY BRACKET (L.C.R.V. MTG.)	TATA spare parts
265242400102	L.C.R.V.-INDIGENOUS	TATA spare parts
265242408203	LCRV BRACKET	TATA spare parts
265242700111	REAR PARKING BRAKE CABLE	TATA spare parts
265242700114	FRONT PARKING BRAKE CABLE - OFFER	TATA spare parts
265242700115	ASSY. PARKING BRAKE CABLE FRONT	TATA spare parts
265242700117	ASSY. PARKING BRAKE CABLE FRONT	TATA spare parts
265242700120	REAR PARKING BRAKE CABLE	TATA spare parts
265242700122	ASSY.PARKING BRAKE HANDLE	TATA spare parts
265242700128	ASSY. CUP(PARKING BRAKE HANDLE)	TATA spare parts
265242700129	FRONT PARKING BRAKE CABLE	TATA spare parts
265242700132	ASSY PARKING BRAKE CABLE FRONT	TATA spare parts
265242700133	ASSY COVER (PARKING BRAKE LEVER MTG)	TATA spare parts
265242700136	PARKING BRAKE CABLE ASSY-REAR RH	TATA spare parts
265242700137	PARKING BRAKE CABLE ASSY-REAR LH	TATA spare parts
265242700139	PARKING BRAKE CABLE ASSY-FRONT	TATA spare parts
265242700141	BRACKET ASSY. FOR ABUTMENT REAR CABLE	TATA spare parts
265242700142	HOOK ASSY FOR PARKING CABLE REAR LH	TATA spare parts
265242700150	ASY.PARKING CABLE(407 MINI 27WB)	TATA spare parts
265242700151	PARKING BRAKE CABLE ASSY REAR-LH	TATA spare parts
265242700160	ASSY FRONT PARKING BRAKE CABLE	TATA spare parts
265242700162	ASSY PARKING BRAKE CABLE FRONT	TATA spare parts
265242700192	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
265242706701	CLEVIS PIN	TATA spare parts
265242707501	GROMMET FOR FRONT PARKING CABLE	TATA spare parts
265242708201	LINK (PARKING BRAKE CABLE HOLDING)	TATA spare parts
265242708217	SHEET (PARKING BRAKE HANDLE MTG.)	TATA spare parts

265242708701	RETURN SPRING (PARKING BRAKE CABLE)	TATA spare parts
265242800101	ASSY.TUBE	TATA spare parts
265242810148	ASSY TUBE FROM SECONDARY TO FRONT LH	TATA spare parts
265242810149	ASSY TUBE FROM PRIMARY TO REAR	TATA spare parts
265242990101	NORMAL KIT-BRAKE LINER BS2/3/4	TATA spare parts
265242990102	SPARE KIT - 407 BRAKE ASSY - REPAIR-I	TATA spare parts
265242990103	SPARE KIT - 407 BRAKE ASSY - REPAIR-II	TATA spare parts
265242990104	SPARE KIT - 407 BRK. HOLLOW RIVET 6X10	TATA spare parts
265242990106	DUST SHIELD TOP	TATA spare parts
265243100101	WHEEL CYL ASSY DIA.23.81	TATA spare parts
265243100103	MASTER CYL. VALVE DIA 25.4	TATA spare parts
265243100110	BRACKET ASSY LCRV MTG ON LONG MEMBER	TATA spare parts
265243100114	BRACKET ASSY LCRV MTG ON LONG MEMBER	TATA spare parts
265243108203	BRACKET LCRV MTG ON RE AXLE	TATA spare parts
265243500103	VACUUM BRAKE BOOSTER 10 BS3/4	TATA spare parts
265243500107	VACUUM TANK ASSY WITH MTG BKT	TATA spare parts
265243500108	VACUUM TANK ASSY 6L	TATA spare parts
265243500113	PIPE ASSY VACUUM LINE BUNCH FOR CAB	TATA spare parts
265243500114	PIPE ASSY VACUUM LINE BUNCH FOR CHASSIS	TATA spare parts
265243500115	PIPE BUNCH ASSY CABIN	TATA spare parts
265243500125	PIPE ASSY VACUUM BUNCH ON CAB	TATA spare parts
265243508201	Z-BRACKET FOR VACUUM TANK MTG	TATA spare parts
265243800115	BRACKET ASSY BRAKE TUBE MTG.	TATA spare parts
265243800117	TUBE ASSY TMC SECONDARY TO FRONT-LH	TATA spare parts
265243800118	TUBE ASSY TMC SECONDARY TO FRONT-RH	TATA spare parts
265243800119	TUBE ASSY TMC PRIMARY TO ADAPTER	TATA spare parts
265243800173	ASSY TUBE (TMC OUT TO T CONNECTOR)	TATA spare parts
265243800174	ASSY.TUBE(T CONNECTOR TO RH ADAPTER)	TATA spare parts
265243800175	ASSY. TUBE(T CONNECTOR TO LH ADAPTER)	TATA spare parts
265243800176	ASSY. TUBE (TMC OUT TO ADAPTER)	TATA spare parts
265243800177	ASSY. TUBE (ADAPTER TO LCRV)	TATA spare parts
265243800178	ASSY. TUBE(T CONNECTOR TO HOSE)	TATA spare parts
265243800179	ASSY TUBE (DIA 12 VACUUM PIPE)	TATA spare parts
265243800182	ASSY TUBE (VACUUM LINE BOOSTER TO 3 WAY)	TATA spare parts
265243800183	ASSY TUBE (3 WAY TO MAGNETIC VALVE)	TATA spare parts
265243800188	ASSY TUBE (3 WAY TO VACUUM TANK)	TATA spare parts
265243800196	ASSY PIPE (FROM FR TEE TO FR LH HOSE)	TATA spare parts
265243800197	ASSY PIPE (FROM TMC SECONDARY TO FR RH)	TATA spare parts
265243800198	ASSY PIPE (FROM TMC PRIMARY TO ADAPTOR)	TATA spare parts
265243800199	ASSY PIPE (FROM ADAPTOR TO LCRV IN)	TATA spare parts
265243808201	BRACKET (AIR LINE) BS6	TATA spare parts
265243810101	ASSY PIPE (FROM LCRV OUT TO RE HOSE)	TATA spare parts
265243810102	ASSY VACUUM PIPE (FROM NRV HOSE TO FR TE)	TATA spare parts
265243810103	ASSY VACUUM PIPE (FROM TEE TO ALTERNATOR)	TATA spare parts
265243810104	ASSY VACUUM PIPE (FROM FR TEE TO EQUAL T)	TATA spare parts
265243810105	ASSY VACUUM PIPE (EQUAL TEE TO VACUUM TA)	TATA spare parts
265243810106	ASSY VACUUM PIPE (EQUAL TEE TO MAG VALVE)	TATA spare parts

265243810107	ASSY VACUUM PIPE (MAG VALVE TO EXH. BRAK	TATA spare parts
265243810111	ASSY VACUUM PIPE (FROM NRV HOSE TO FR TE	TATA spare parts
265243810114	TUBE ASSY ADAPTOR TO REAR ADAPTOR	TATA spare parts
265243810115	TUBE ASSY ADAPTOR TO LCRV INLET	TATA spare parts
265243810116	TUBE ASSY LCRV OUTLET TO REAR HOSE	TATA spare parts
265243810117	TUBE ASSY T CONN TO BRAKE REAR LH	TATA spare parts
265243810118	TUBE ASSY T CONN TO BRAKE REAR RH	TATA spare parts
265243810120	TUBE ASSY -ADAPTOR TO REAR HOSE	TATA spare parts
265243810121	TUBE ASSY TMC SECONDARY TO FRONT RH	TATA spare parts
265243810122	TUBE ASSY TMC PRIMARY TO ADAPTOR	TATA spare parts
265243810126	TUBE ASSY TMC PRIMARY TO ADAPTOR	TATA spare parts
265243810127	TUBE ASSY TMC SECONDARY TO FRONT LH	TATA spare parts
265243810133	TUBE ASSY TMC SECONDARY TO FRONT RH	TATA spare parts
265243810134	TUBE ASSY FROM TMC SECONDARY TO FRONT LH	TATA spare parts
265243810135	TUBE ASSY ADAPTOR TO LCRV INLET	TATA spare parts
265243810136	TUBE ASSY TMC PRIMARY TO ADAPTOR	TATA spare parts
265243810139	TUBE ASSY TEE TO RE LH BRAKE	TATA spare parts
265243810140	TUBE ASSY TEE TO RE BRK	TATA spare parts
265243810141	TUBE ASSY TEE TO RE LH BRAKE	TATA spare parts
265243810148	TUBE ASSY ADAPTER TO LCRV INLET	TATA spare parts
265243810149	TUBE ASSY LCRV OUTLET TO REAR HOSE	TATA spare parts
265243900118	PIPE ASSY QFC TO VACUUM TANK	TATA spare parts
265243900121	PIPE ASSY QFC TO VACUUM TANK	TATA spare parts
265243900125	PIPE ASSY BUNCH FOR CHASSIS	TATA spare parts
265243900127	PIPE ASSY	TATA spare parts
265243900135	PIPE ASSY BUNCH FOR CAB	TATA spare parts
265243900137	PIPE ASSY MAGNETIC VALVE TO PTO	TATA spare parts
265243900138	PIPE ASSY MAG. VALVE TO EXHAUST BRK.¿ CY	TATA spare parts
265246106301	RUBBER BELOW	TATA spare parts
265246200105	ASSY BRACKET STRG GEAR BOX MTG	TATA spare parts
265246200110	ASSY STRG GEAR BOX	TATA spare parts
265246306001	PITMAN ARM	TATA spare parts
265246306002	PITMAN ARM	TATA spare parts
265246800107	ASSY PIPE PRESSURE LINE	TATA spare parts
265246800110	ASSY PIPE RETURN LINE	TATA spare parts
265246800114	RETURN LINE ASSY GB TO RESERVOIR	TATA spare parts
265246800115	PRESSURE LINE ASSY PUMP TO GB	TATA spare parts
265246800116	SUCTION LINE ASSY PUMP TO RESERVOIR	TATA spare parts
265246800118	PRESSURE LINE ASSY	TATA spare parts
265246800119	SUCTION LINE ASSY	TATA spare parts
265246800121	RETURN LINE ASSY	TATA spare parts
265247000114	FUEL TANK ASSY WITH BRACKET BS6	TATA spare parts
265247100106	ASSY FUEL CAP & CHAIN - REUTTER	TATA spare parts
265247100109	FUEL TANK ASSY BS6-PH2	TATA spare parts
265247500102	ASSU FUEL TANK MTG BKT	TATA spare parts
265247508201	FUEL TANK MTG. BRACKET	TATA spare parts
265247600114	ASSY. SUCTION LINE (W/SEP TO FEED PUMP)	TATA spare parts



265247600115	ASSY.RETURN LINE (OVERFLOW TO TANK)	TATA spare parts
265247600117	ASSY SUCTION LINE (W/SEP TO FILTER)	TATA spare parts
265247600118	ASSY RETURN LINE(ENGINE TO TANK)	TATA spare parts
265247600120	ASSY.RETURN LINE (OVERFLOW TO TANK)EXOTE	TATA spare parts
265247600126	ASSY.SUCTION LINE(TANK TO STRAINER)	TATA spare parts
265247600127	ASSY.SUCTION LINE(STRAINER TO MECH FP)	TATA spare parts
265247600129	ASSY.SUCTION LINE(STRAINER TO MECH FP)	TATA spare parts
265247600131	ASSY SUCTION LINE (F/P TO FILTER)	TATA spare parts
265247600132	ASSY.SUCTION LINE FILTER TO	TATA spare parts
265247600135	ASSY.SUCTION LINE (FROM MECH.FEED PUMP T	TATA spare parts
265247600136	ASSY.SUCTION LINE (FROM FILTER)	TATA spare parts
265247600139	ASSY.SUCTION LINE(W/SEP TO MECH FEED PUM	TATA spare parts
265247600153	ASSY FUEL LINE F TANK TO W SEP	TATA spare parts
265247600155	ASSY SUCTION LINE W/S TO M/FEED PUMP	TATA spare parts
265247600156	ASSY FUEL RETURN LINE	TATA spare parts
265247600157	SUCTION FUEL PIPE ASSY TANK TO STRAINER	TATA spare parts
265247600158	SUCTION FUEL PIPE ASSY STRNER TO MFPUMP	TATA spare parts
265247600159	SUCTION FUEL PIPE ASSY FEEDPUMP TO FILT	TATA spare parts
265247600160	SUCTION FUEL PIPE ASSY FILTER TO FIP	TATA spare parts
265247600161	RETURN FUEL PIPE ASSY ENG TO TANK	TATA spare parts
265247603301	BRACKET FUEL CLAMP MTG	TATA spare parts
265247603302	BRACKET FUEL CLAMP MTG	TATA spare parts
265247608202	BRACKET	TATA spare parts
265247608206	BRACKET(FUEL LINES CLAMPING)	TATA spare parts
265247610119	ASSY.VENTING LINE(H TOP CYL.TO LOADBODY)	TATA spare parts
265247610120	ASSY HP PIPE(RH TOP CYL.TO 3 WAY VALVE)	TATA spare parts
265247610122	ASSY.VENT PIPE(LH TOP CYL.TO LOAD BODY)	TATA spare parts
265247610123	ASSY HP CNG PIPE(3WAY VALVE TO HP GAUGE)	TATA spare parts
265247703301	BRACKET BS6	TATA spare parts
265247703302	SHIELD BS6	TATA spare parts
265249100101	ASSY.SILENCER WITH TAIL PIPE. 406	TATA spare parts
265249100102	ASSY. SILENCER (WITH TAIL PIPE)	TATA spare parts
265249100114	SILENCER ASSY WITH FLANGE	TATA spare parts
265249100115	CLAMP ASSY CATCON	TATA spare parts
265249100116	PIPE ASSY DPS SENSOR	TATA spare parts
265249100117	PIPE ASSY DPS SENSOR	TATA spare parts
265249100118	PIPE ASSY CATCON INTAKE	TATA spare parts
265249100119	PIPE ASSY DOWNSTREAM	TATA spare parts
265249103301	BRACKET	TATA spare parts
265249103302	BRACKET	TATA spare parts
265249105803	HOSE PIPE	TATA spare parts
265249105804	HOSE PIPE	TATA spare parts
265249200101	ASSY.EXHAUST PIPE-FRONT-406	TATA spare parts
265249200109	ASSY FRONT EXHAUST PIPE	TATA spare parts
265249200110	ASSY.FRONT EXHAUST PIPE (WITH FLEXIBLE B	TATA spare parts
265249200111	FRONT EXHAUST PIPE WITH FLEX BELLOW	TATA spare parts
265249200114	ASSY BRACKET FOR EXHAUST MOUNTING	TATA spare parts

265249200124	EXHAUST PIPE ASSY REAR	TATA spare parts
265249200125	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
265249200126	EXHAUST PIPE ASSY WITH BELLOW	TATA spare parts
265249200127	EXHAUST ASSY REAR	TATA spare parts
265249208212	BRACKET - DPS MOUNTING	TATA spare parts
265249210102	ASSY FRONT EXHAUST PIPE	TATA spare parts
265254100102	ASSY INTERMEDIATE BATTERY BKT RH	TATA spare parts
265254100103	ASSY INTER BATTERY LH	TATA spare parts
265254100111	BATTERY CABLE + VE	TATA spare parts
265254200104	INST.CLUSTER SFC407 1:0.78	TATA spare parts
265254200110	INSTRUMENT CLUSTER 0.76 RATIO	TATA spare parts
265254200116	INST.CLUSTER SFC407 MFIP 1:0.78	TATA spare parts
265254200117	INST.CLUSTER SFC407 MFIP 0.76	TATA spare parts
265254200119	INST.CLUST.SFC407 MFIP TT 0.83	TATA spare parts
265254200121	INSTRUMENT CLUSTER 0.78 RATIO	TATA spare parts
265254200122	INSTRUMENT CLUSTER 0.83 RATIO	TATA spare parts
265254200123	INST.CLUST.SFC407 MFIP 0.65	TATA spare parts
265254200129	INST CLST.SFC407 CNG BSIV	TATA spare parts
265254208203	BACKCOVER SLD MOTOR	TATA spare parts
265254209903	EGR CONTROLLER SFC407 MFIP BSIII-ED	TATA spare parts
265254209904	TEMPRATURE GAUGE-SFC407 MFIP	TATA spare parts
265254209906	SPEEDOMETER RATIO - 0.83	TATA spare parts
265254408801	XYZ LOCATOR_H/L BS6	TATA spare parts
265254409902	NYLON BUSH HEADLAMP CATCHER BS6	TATA spare parts
265254506303	STICKER MAXI FUSE BOX	TATA spare parts
265254509901	MAXI FUSE BOX 1+2 W/O COVER BS4	TATA spare parts
265254600108	ASSEMBLY ECU MTG BKT SFC 407 BSIV 4SP	TATA spare parts
265254600124	WIRING HARNESS MAIN	TATA spare parts
265254600128	WIRING HARNESS TAIL	TATA spare parts
265254600135	BRACKET ASSY FUSE BOX MTG BS6	TATA spare parts
265254600138	WIRING HARNESS ENGINE	TATA spare parts
265254600139	WIRING HARNESS MAIN	TATA spare parts
265254600141	WIRING HARNESS MAIN	TATA spare parts
265254600142	WIRING HARNESS MAIN	TATA spare parts
265254600147	PIGTAIL WIRING HARNESS BS6	TATA spare parts
265254600154	FUSE BOX COVER	TATA spare parts
265254600162	WIRING HARNESS GRID HEATER	TATA spare parts
265254600165	WIRING HARNESS MAIN PIGTAIL	TATA spare parts
265254600168	WIRING HARNESS SENSOR	TATA spare parts
265254600170	WIRING HARNESS MAIN	TATA spare parts
265254601607	W/H MAIN SFC407 MFIP	TATA spare parts
265254601615	W/H PIGTAIL FOR EGR VALVE & SENSORS	TATA spare parts
265254601625	W/H ENGINE	TATA spare parts
265254601639	WIRING HARNESS MAIN	TATA spare parts
265254601657	PIGTAIL FRONT FOG LAMP	TATA spare parts
265254601689	WIRING HARNESS TAIL	TATA spare parts
265254601699	WIRING HARNESS TAIL LAMP	TATA spare parts

265254603301	BRACKET GRID HEATER RELAY	TATA spare parts
265254606305	STICKER MAXI FUSE BOX	TATA spare parts
265254607501	GROMMET BS6	TATA spare parts
265254608211	BKT.FOR MAIN TO ENGINE CONNECTOR PARKING	TATA spare parts
265254608212	EMS INTER CONN. PARK BKT. SFC 407 BSIV B	TATA spare parts
265254608213	WH BRACKET ON CLUTCH HOUSING	TATA spare parts
265254610101	WIRING HARNESS MAIN	TATA spare parts
265254611603	WIRING HARNESS MAIN	TATA spare parts
265254620105	W/H EMS SFC 407 CNG BS-IV WITH FRONT ETB	TATA spare parts
265254620107	W/H MAIN SFC407 MFIP EX	TATA spare parts
265254620110	W/H MAIN SFC407 MFIP EX2--MSSL	TATA spare parts
265254620111	W/H TAIL SFC407/27WB MFIP PICKUP	TATA spare parts
265254620112	WIRING HARNESS TAIL	TATA spare parts
265254620114	W/H ENGINE SFC407/27WB MFIP PICKUP	TATA spare parts
265254620115	W/H PIGTAIL FOR EGR VALVE & SENSORS	TATA spare parts
265254620116	WIRING HARNESS TAIL	TATA spare parts
265254620117	WIRING HARNESS ENGINE	TATA spare parts
265254620118	W/H ENGINE SFC407MFIP W/PTO EXH BR	TATA spare parts
265254620120	W/H MAXIFUSE AND BATT.CUT OFF SW.	TATA spare parts
265254620122	W/H H/L & BLINKER SFC410/31 BS-III	TATA spare parts
265254620124	W/H MAIN SFC407 MFIP EX CAT-6	TATA spare parts
265254620126	W/H MAIN SFC407 MFIP EX2 CAT-6	TATA spare parts
265254620131	W/H TAIL	TATA spare parts
265254620132	W/H EMS	TATA spare parts
265254620134	W/H MAIN SFC407 EX MFIP FACELIFT	TATA spare parts
265254620136	W/H MAIN SFC407 EX2 MFIP FACELIFT	TATA spare parts
265254620139	W/H MAIN	TATA spare parts
265254620142	W/H MAIN SFC407/31 TMML MFIP BSIII	TATA spare parts
265254620143	W/H TAIL SFC407/31WB TMML FES MFIP BSIII	TATA spare parts
265254620144	W/H ENGINE SFC 407 BSIII (MFIP)	TATA spare parts
265254620147	WIRING HARNESS MAIN	TATA spare parts
265254620165	WIRING HARNESS TAIL	TATA spare parts
265254660124	W/H MAIN SFC407 MFIP EX CAT-6-TYA	TATA spare parts
265254690104	W/H MAIN SFC407 MFIP	TATA spare parts
265254690110	WIRING HARNESS ENGINE	TATA spare parts
265254690111	W/H PIGTAIL FOR EGR VALVE & SENSORS	TATA spare parts
265254690115	W/H MAIN SFC407 MFIP EX CAT-6	TATA spare parts
265254690117	W/H MAIN SFC407 MFIP EX2 CAT-6	TATA spare parts
265254690131	WIRING HARNESS TAIL	TATA spare parts
265254690153	W/H MAIN	TATA spare parts
265254690154	W/H MAIN	TATA spare parts
265254990109	WIRING HARNESS COLD START KIT SFC/SK 407	TATA spare parts
265258902601	GAUGE / M-SHAFT SPACER THKNNESS SELECT /G	TATA spare parts
265282908201	BRACKET WASHER BOTTLE MTGç BS6	TATA spare parts
265287304701	FUEL TANK GUARD	TATA spare parts
265287306001	PUSH-PULL CABLE	TATA spare parts
265298800101	MASCOT-307	TATA spare parts

265329100101	ASSY PIPE-6.0.D	TATA spare parts
265329100107	ASSY CTL MTG WITH BRAKE&CLUTCH PEDAL	TATA spare parts
265329100113	ASSY.CTL.MTG.WITH BRAKE&CLUTCH PEDAL	TATA spare parts
265329100117	ASSY CONTROL MTG WITH BRAKE AND CLUTCH	TATA spare parts
265329100120	ASSY.CONTROL MTG.WITH BRAKE AND CLUTCH	TATA spare parts
265331000105	ASSY.FRAME 4X4 FACELIFT	TATA spare parts
265331000106	ASSY.FRAME COMPLETE(2.2L DICR 4X4 28WB)	TATA spare parts
265331000107	ASSY FRAME 4X4 (SPRINT 28WB 3LDICOR)	TATA spare parts
265331000108	FRAME XENON 28WB 2.2LDICOR4*4	TATA spare parts
265331000111	ASSY FRAME 4X4 (SPRINT SC 31WB 2.2LDICR)	TATA spare parts
265331000114	ASSY FRAME	TATA spare parts
265331008201	FRONT SKIRT	TATA spare parts
265331200103	CROSS RUNNER REAR	TATA spare parts
265331200133	ASSY CROSS MEMBER (4DL ENGINE)	TATA spare parts
265331200135	ASSY CROSS MEMBER (4DL ENGINE)	TATA spare parts
265331200137	ASSY. REAR UNDERRUN PROTECTION DEVICE	TATA spare parts
26533120013720	ASSY REAR UNDERRUN PROTECTION WELDED	TATA spare parts
265331200138	ASSY.BRACKET L.H.(TOWING HOOK& RUPD MTG)	TATA spare parts
265331200139	ASSY.BRACKET R.H.(RUPD MTG.)	TATA spare parts
265331200141	ASSY CROSS RUNNER REAR(LOAD BODY MTG)	TATA spare parts
265331200142	ASSY CROSS RUNNER FRONT(LOAD BODY MTG.)	TATA spare parts
265331200143	ASSY END CROSS MEMBER	TATA spare parts
265331200144	ASSY FUEL TANK SUPPORT REAR L.H.	TATA spare parts
265331200145	ASSY FUEL TANK SUPPORT FRONT L.H.	TATA spare parts
265331200146	ASSY.CROSS MEMBER & PLATE (BREATHER MTG)	TATA spare parts
265331200147	ASSY CROSS MEMBER (CENTER BEARING MTG.)	TATA spare parts
265331206301	SIDE COVER	TATA spare parts
265331700103	NOISE SHIELD ASSY	TATA spare parts
265331700104	ASSY.BRACKET (FUEL FILTER & BREATHER)	TATA spare parts
265332100108	ASSY. LOWER WISHBONE COMPLETE RH	TATA spare parts
265332100109	ASSY. LOWER WISHBONE COMPLETE LH	TATA spare parts
265332100114	ASSY. UPPER WISHBONE COMPLETE RH	TATA spare parts
265332100114AE	ASSY UPP WSHBON COMP R-XEN DC/SC	TATA spare parts
265332100115	ASSY. UPPER WISHBONE COMPLETE LH	TATA spare parts
265332100115AE	ASSY UPP WSHBN COMP L-XEN DC/SC	TATA spare parts
265332100136	SUB ASSYUPPER WISHBONE RH(W/BUSHES) BS4	TATA spare parts
265332100137	SUB ASSYUPPER WISHBONE LH(W/BUSHES) BS4	TATA spare parts
265332105101	UPPER WISHBONE RH	TATA spare parts
265332105102	UPPER WISHBONE LH	TATA spare parts
265332107701	RUBBER STOPER (REBOUND)	TATA spare parts
265340100110	ASSY.WHEEL RIM COVER	TATA spare parts
265340109901	TUBELESS TYRE	TATA spare parts
265340109902	VALVE FOR TUBELESS TYRE	TATA spare parts
265340300104	ASSY SUPPORT(SPARE WHEEL MTG.)	TATA spare parts
265340300106	ASSY CLAMP	TATA spare parts
265340300107	ASSY TUBE WITH SUPPORT	TATA spare parts
265340300108	ASSY SUPPORT (SPARE WHEEL)	TATA spare parts

265341000101	ASSY.PRO.SHAFT	TATA spare parts
265341000104	ASSY.PRO.SHAFT	TATA spare parts
265341100104	ASSY.PROP.SHAFT REAR COMPLETE	TATA spare parts
265342800129	ASSY. TUBE	TATA spare parts
265342800130	ASSY. TUBE	TATA spare parts
265342800131	ASSY. TUBE	TATA spare parts
265342800132	ASSY.TUBE	TATA spare parts
265346200108	ASSY. BRACKET (STG. COLUMN MTG.)	TATA spare parts
265346300107	ASSY. IDLER ARM WITH BUSH	TATA spare parts
265346300109	ASSY. IDLER ARM WITH BUSH	TATA spare parts
265346306003	PITMAN ARM RHD	TATA spare parts
265346306005	PITMAN ARM LHD	TATA spare parts
265346600124	ASSY. TIE ROD BS3/4	TATA spare parts
265346600125	ASSY. CENTRE LINK BS3/4	TATA spare parts
265346800101	ASSY. SUCTION HOSE COMPLETE.	TATA spare parts
265346800102	ASSY. HIGH PRESSURE HOSE COMPLETE	TATA spare parts
265347100108	ASSY FUEL TANK COMPLETE 45 LITRES	TATA spare parts
265347100109	ASSY. FUEL FILLER NECK	TATA spare parts
265347100110	BRACKET ASSY FILTER & SEDIMENTOR MTG	TATA spare parts
265347500102	FUEL TANK STRAP ASSY	TATA spare parts
265347507701	RUBBER STRAP	TATA spare parts
265347507702	RUBBER PACKING FUEL TANK	TATA spare parts
265347600101	ASSY.SUCTION LINE(TANK TO HOSE)	TATA spare parts
265347600102	ASSY.TUBE (RETURN LINE)	TATA spare parts
265347600104	ASSY SUCTION LINE (TANK TO HOSE)	TATA spare parts
265347600105	ASSY RETURN LINE (HOSE TO TANK)	TATA spare parts
265347600114	FUEL SUCTION PIPE ASSY TANK TO FIREWALL	TATA spare parts
265347600119	RETURN PIPE ASSY U/B TO TANK	TATA spare parts
265347604201	CLAMP FUEL PIPE	TATA spare parts
265347605801	HOSE BREATHER PIPE	TATA spare parts
265347605803	BREATHER HOSE	TATA spare parts
265347605804	HOSE (FUEL FILLING)	TATA spare parts
265347606901	SUCTION LINE(TUBE 10X0.7SS:4039-20)	TATA spare parts
265347606902	RETURN LINE(TUBE 10X0.7SS:4039-20)	TATA spare parts
265349200114	ASSY.EXHAUST PIPE (REAR)	TATA spare parts
265349200115	ASSY. EXHAUST PIPE (MIDDLE).	TATA spare parts
265349200127	ASSY. EXHAUST PIPE MIDDLE (28WB E-III)	TATA spare parts
265349200136	ASSY. FRONT PIPE-EXHAUST	TATA spare parts
265349200137	ASSY. INTERMEDIATE PIPE-EXHAUST 28 WB	TATA spare parts
265349200139	EXHAUST TAIL PIPE	TATA spare parts
265349200140	ASSY. INTERMEDIATE PIPE-EXHAUST 31 WB	TATA spare parts
265349200144	ASSY SILENCER	TATA spare parts
265354200105	RPM METER 0-6000	TATA spare parts
265354200110	INST.CLUSTER 1:1.0625 W/TRIP ODO	TATA spare parts
265354200111	INST.CLUSTER 1:1.7 W/RTIP ODO	TATA spare parts
265354200114	ELECTR.CONTROL UNIT 1:1.1 RATIO	TATA spare parts
265354209901	SPEEDOMETER 1:1.04 TRIP	TATA spare parts

265354209904	FUEL + TEMP GAUGE WHITE	TATA spare parts
265354209905	ASSY.RPM METER 0-8000 WHITE DIAL [4X4]	TATA spare parts
265354209908	3.2 DIS SPEEDOCABLE 2350 LG JIS	TATA spare parts
265354209910	SPEEDOMETER 1:1.1 W/TRIP ODO	TATA spare parts
265354600141	W/H.CABIN A/C+HEAT & DEMIST	TATA spare parts
265354600149	W/H.ROOF-DOUBLE LAMP & STOP LAMP	TATA spare parts
265354600152	WIRING HARNESS CENTRAL LOCKING	TATA spare parts
265354600153	WIRING HARNESS DRIVER DOOR	TATA spare parts
265354600154	W/H.REAR DOOR-DRIVER SIDE	TATA spare parts
265354600155	W/H.ROOF STOP LAMP & HEAT+DEMIST	TATA spare parts
265354600156	WIRING HARNESS FRONT DOOR CO-DRIVER	TATA spare parts
265354600157	WIRING HARNESS REAR DOOR CO-DRIVER	TATA spare parts
265354600158	W/H FRONT A/C+HD [FACELIFT] EURO-II	TATA spare parts
265354600162	W/H.ROOF STOP LAMP & HEAT+DEMIST	TATA spare parts
265354600163	WIRING HARNESS FRONT-EURO-III	TATA spare parts
265354600165	WIRING HARNESS CABIN LHD EURO-III	TATA spare parts
265354600166	WIRING HARNESS CABIN RHD EURO-III	TATA spare parts
265354600167	WIRING HARNESS CABIN RHD EURO-II	TATA spare parts
265354600168	WIRING HARNESS FRONT EURO-II	TATA spare parts
265354600169	WIRING HARNESS CABIN RHD EURO-II	TATA spare parts
265354600170	WIRING HARNESS FRONT EURO-III	TATA spare parts
265354600172	WIRING HARNESS 4X4 ECU	TATA spare parts
265354600173	WIRING HARNESS CABIN LHD EURO-III	TATA spare parts
265354600179	WIRING HARNESS FRONT EURO-II	TATA spare parts
265354600180	WIRING HARNESS CABIN RHD EURO-II	TATA spare parts
265354600183	W/H ENGINE EURO-II EURO-II W/KSB	TATA spare parts
265354600184	WIRING HARNESS FRONT RHD EURO-II	TATA spare parts
265354600185	WIRING HARNESS CABIN RHD EURO-II	TATA spare parts
265354600186	WIRING HARNESS FRONT LHD EURO-II	TATA spare parts
265354600187	WIRING HARNESS FRONT LHD EURO-II	TATA spare parts
265354600188	WIRING HARNESS CABIN LHD EURO-II	TATA spare parts
265354600189	WIRING HARNESS CABIN LHD EURO-II	TATA spare parts
265354601602	W/H ENGINE EURO-II WITH KSB	TATA spare parts
265354601603	WIRING HARNESS FRONT RHD EURO-II	TATA spare parts
265354601604	WIRING HARNESS CABIN RHD EURO-II	TATA spare parts
265354601605	WIRING HARNESS FRONT LHD EURO-II	TATA spare parts
265354601606	WIRING HARNESS CABIN LHD E-II	TATA spare parts
265358900401	SPACER / VALVE GUIDE / 2.2 DICOR	TATA spare parts
265358900601	SPACER FOR VALVE GUIDE DRIFT	TATA spare parts
265358900602	VALVE SPRING COMPRESSOR/2.2L DICOR XENON	TATA spare parts
265358900603	DRIFT / CAMSHAFT OIL SEAL / 2.2 DICOR	TATA spare parts
265358900604	FLYWHEEL LOCKING PIN	TATA spare parts
265358900605	CAM SHAFT LOCKING PLATE	TATA spare parts
265358900606	120D-50L DRIFT / CRANK SHAFT R-O-SEAL /	TATA spare parts
265358900607	10D--15D-80L FIP GEAR LOCK PIN / 2.2 D	TATA spare parts
265358900608	LOCKING PIN / AUTO TENSIONER/2.2L XENON	TATA spare parts
265358900609	CAMSHAFT LOCKING PIN / 2.2L DICOR	TATA spare parts

265358902401	SUPPORT STAND / 2.2L DICOR ENGINE	TATA spare parts
265358902402	ENGINE MTG BKT / RH / 2.2LDICOR	TATA spare parts
265358902403	ENGINE MTG BKT / RH / 2.2LDICOR ENGINE	TATA spare parts
265358902501	MANDREL /CLUTCH DISC ALIGNMENT/2.2 DICOR	TATA spare parts
265368906307	CONSOLE BODY REAR DARK GRAY SOFT FEEL	TATA spare parts
265370000109	FEN.EXTN.TM L.BODY LH	TATA spare parts
265370000110	FEN.EXTN.TM L. BODY RH	TATA spare parts
265370000121BF	ASSY.LOAD BODY W/FITMENTS LHD ARTIC WHIT	TATA spare parts
265370000121BG	ASSY.LOAD BODY W/FITMENTS LHD MICA B_RED	TATA spare parts
265370000121BM	ASSY.LOAD BODY W/FITMENTS LHD FIJI BLUE	TATA spare parts
265370000121BN	ASSY.LOAD BODY W/FITMENTS LHD RUBY RED	TATA spare parts
265370000121BP	ASSY.LOAD BODY W/FITMENTS LHD METALLIC S	TATA spare parts
265370000121D3	ASSY.LOAD BODY W/FITMENTS LHD ARTIC SILV	TATA spare parts
265370000121D5	ASSY.LOAD BODY W/FITMENTS LHD TIMBER GRE	TATA spare parts
265370000121D7	ASSY.LOAD BODY W/FITMENTS LHD SILVER MIS	TATA spare parts
265370000121DP	ASSY.LOAD BODY W/FITMENTS LHD PASSION RE	TATA spare parts
265370000122BF	ASSY.LOAD BODY COMP. PAINTED LHD ARTIC W	TATA spare parts
265370000122BG	ASSY.LOAD BODY COMP. PAINTED LHD MICA B_	TATA spare parts
265370000122BM	ASSY.LOAD BODY COMP. PAINTED LHD FIJI BL	TATA spare parts
265370000122BN	ASSY.LOAD BODY COMP. PAINTED LHD RUBY RE	TATA spare parts
265370000122BP	ASSY.LOAD BODY COMP. PAINTED LHD METALLI	TATA spare parts
265370000122D3	ASSY.LOAD BODY COMP. PAINTED LHD ARTIC S	TATA spare parts
265370000122D5	ASSY.LOAD BODY COMP. PAINTED LHD TIMBER	TATA spare parts
265370000122D7	ASSY.LOAD BODY COMP. PAINTED LHD SILVER	TATA spare parts
265370000122DP	ASSY.LOAD BODY COMP. PAINTED LHD PASSION	TATA spare parts
265370000125BF	ASSY.LOAD BODY W/FITMENTS RHD ARTIC WHIT	TATA spare parts
265370000125BG	ASSY.LOAD BODY W/FITMENTS RHD MICA B_RED	TATA spare parts
265370000125BM	ASSY.LOAD BODY W/FITMENTS RHD FIJI BLUE	TATA spare parts
265370000125BN	ASSY.LOAD BODY W/FITMENTS RHD RUBY RED	TATA spare parts
265370000125D3	ASSY.LOAD BODY W/FITMENTS RHD ARTIC SILV	TATA spare parts
265370000125D5	ASSY.LOAD BODY W/FITMENTS RHD TIMBER GRE	TATA spare parts
265370000125D7	ASSY.LOAD BODY W/FITMENTS RHD SILVER MIS	TATA spare parts
265370000125DP	ASSY.LOAD BODY W/FITMENTS RHD PASSION RE	TATA spare parts
265370000126BF	ASSY.LOAD BODY COMP. PAINTED RHD ARTIC W	TATA spare parts
265370000126BG	ASSY.LOAD BODY COMP. PAINTED RHD MICA B_	TATA spare parts
265370000126BM	ASSY.LOAD BODY COMP. PAINTED RHD FIJI BL	TATA spare parts
265370000126BN	ASSY.LOAD BODY COMP. PAINTED RHD RUBY RE	TATA spare parts
265370000126D3	ASSY.LOAD BODY COMP. PAINTED RHD ARTIC S	TATA spare parts
265370000126D5	ASSY.LOAD BODY COMP. PAINTED RHD TIMBER	TATA spare parts
265370000126D7	ASSY.LOAD BODY COMP. PAINTED RHD SILVER	TATA spare parts
265370000126DP	ASSY.LOAD BODY COMP. PAINTED RHD PASSION	TATA spare parts
265370006301	LINER INNER LH RR W/ARCH	TATA spare parts
265370006302	LINER INNER RH(REAR WHEEL ARCH)	TATA spare parts
265370006303	MUD FLAP REAR(WITH T)	TATA spare parts
265370006305	FENDER EXTENSION RH(REAR) - BLACK	TATA spare parts
265370006312	FENDER EXT BEADING LH	TATA spare parts
265370006313	FENDER EXTENSION BEADING(L/B) RH-GREY	TATA spare parts

265370006314	FENDER EXTENSION LH (REAR) - GREY	TATA spare parts
265370006315	FENDER EXTENSION RH(REAR) - GREY	TATA spare parts
265370006316	STICKER 4WD TURBO INTERCOOLER	TATA spare parts
265370006318	MUD FLAP REAR(WITH T)	TATA spare parts
265370006320	STICKER-4WD TURBO I/C LH-BLACK	TATA spare parts
265370006324	STICKER 4WD TURBO I/C RH-BLACK	TATA spare parts
265370006325	STICKER 4WD TURBO I/C LH (GOLD)	TATA spare parts
265370006326	STICKER 4WD TURBO I/C RH-GOLD	TATA spare parts
26537000Z130BF	ASSY. LOAD BODY COMPLETE PAINTED LHD AR	TATA spare parts
26537000Z130BM	ASSY. LOAD BODY COMPLETE PAINTED LHD FI	TATA spare parts
26537000Z130D3	ASSY. LOAD BODY COMPLETE PAINTED LHD AR	TATA spare parts
26537000Z130D5	ASSY. LOAD BODY COMPLETE PAINTED LHD TI	TATA spare parts
265370300101	ASSY.SIDE WALL LH	TATA spare parts
265370300102	ASSY.SIDE WALL RH	TATA spare parts
265381100106	ASSY NOISE INS. & MUDGUARD LINER LH	TATA spare parts
265381100108	ASSY NOISE INS. & MUDGUARD LINER LH	TATA spare parts
265381100109	ASSY NOISE INS. & MUDGUARD LINER RH	TATA spare parts
265381100110	ASSY NOISE INSUL.& MUDGUARD LINER RH LHD	TATA spare parts
265381106305	MUD FLAP FRONT LH	TATA spare parts
265381106306	MUDFLAP FRONT RH	TATA spare parts
265381106307	FENDER EXTENSION FRONT LH - GREY	TATA spare parts
265381106308	FENDER EXTENSION FRONT RH - GREY	TATA spare parts
265381106309	MUDGUARD LINER INNER RH LHD(FRT W/A)	TATA spare parts
265381106311	FENDER EXTENSION FRONT-LH	TATA spare parts
265381106312	FENDER EXTENSION FRONT-RH	TATA spare parts
265381800102	ASSY TATA TDI 4X4 MASCOT(CUR/CONN)	TATA spare parts
265381800104	ASSY.MASCOT TATA TDI 4X4	TATA spare parts
265388500103	ASSY.SUPPORT COMPLT.LH[FRONT BUMPER MTG	TATA spare parts
265388500113	ASSY BUMPER FRONT COMPLETE	TATA spare parts
26538850011320	ASSY BUMPER FRONT COMPLETE CED COATED	TATA spare parts
265388500113BJ	ASSY BUMPER FRONT COMPLETE	TATA spare parts
265415100102	STARTER MOTOR	TATA spare parts
265415400104	DRIVE ASSY W/PINION	TATA spare parts
265415400105	ARMATUERE ASSY	TATA spare parts
265415400106	BRUSH BOX ASSY	TATA spare parts
265415400112	BASE MOULDING ASSY	TATA spare parts
265415400113	FIXING BRACKET ASSY	TATA spare parts
265415400114	INTER BRACKET ASSY	TATA spare parts
265415400115	FIELD COIL ASSY	TATA spare parts
265415400116	BRUSH GEAR ASSY	TATA spare parts
265415400117	CE BRACKET ASSY	TATA spare parts
265415400118	KIT EARTH TERMINAL	TATA spare parts
265415400119	DE BRACKET ASSY	TATA spare parts
265415400120	ROTOR ASSY	TATA spare parts
265415400121	STATOR ASSY	TATA spare parts
265415400123	BRUSH ASSY	TATA spare parts
265415400124	RECTIFICER ASSY	TATA spare parts



265415400125	SRE BRACKET ASSY	TATA spare parts
265415400126	VACUUM PUMP ASSY	TATA spare parts
265415400128	ALTERNATOR W-VAC.PUMP 12V 70A 4GR.PULLEY	TATA spare parts
265415400129	ALTERNATOR 4GR 65AMP EXP P/S	TATA spare parts
265415403103	BEARING DRIVE END	TATA spare parts
265415403104	BEARING SRE	TATA spare parts
265415403401	BKT BRG BUSH FIXING	TATA spare parts
265415403402	BUSH INTER BRACKET	TATA spare parts
265415403403	BEARING BUSH CE	TATA spare parts
265415403405	SLIDING BUSH SRE BKT	TATA spare parts
265415404602	CONNECTOR	TATA spare parts
265415404603	SEALING KIT.	TATA spare parts
265415404802	DOWEL PIN	TATA spare parts
265415404803	DOWEL SLEEVE STARTER	TATA spare parts
265415404901	SOLENOID SWITCH	TATA spare parts
265415404903	FUSE LINK ASSY	TATA spare parts
265415405901	KEY	TATA spare parts
265415406001	ENGAGING LEVER ASSY	TATA spare parts
265415406302	CONN.DELIVERY	TATA spare parts
265415406501	SHAFT NUT	TATA spare parts
265415406601	PLUNGER	TATA spare parts
265415406701	PIVOT PIN ASSY	TATA spare parts
265415406802	SCREW SUCTION	TATA spare parts
265415407001	PULLEY	TATA spare parts
265415407101	CONNECTG STRIP GLOW PLUG	TATA spare parts
265415407102	BRG RETAINER PLATE	TATA spare parts
265415407103	CONNECTING STRIP (GLOW PLUG)-EURO-III	TATA spare parts
265415407702	PULLEY SINGLE GROOVE	TATA spare parts
265415407802	O RING SMALL	TATA spare parts
265415407803	OIL SEAL	TATA spare parts
265415407804	O RING LARGE	TATA spare parts
265415407902	SPINDLE ASSY	TATA spare parts
265415408002	POLE SCREW	TATA spare parts
265415408003	SCREW BRUSH PLATE	TATA spare parts
265415408201	FAN	TATA spare parts
265415408601	SPACER PULLEY	TATA spare parts
265415408602	SPACER	TATA spare parts
265415408701	PLUNGER SPRING	TATA spare parts
265415408702	BRUSH SPRING	TATA spare parts
265415409001	CHECK VALVE SUCTION	TATA spare parts
265415409201	STOP WASHER	TATA spare parts
265415409202	THRUST WASHER STEEL	TATA spare parts
265415409203	THRUST WASHER FIBRE	TATA spare parts
265415409204	SPRING WASHER	TATA spare parts
265415409205	WASHER	TATA spare parts
265415409902	STARTER MOTOR 4DL DOM ALL	TATA spare parts
265415409903	ALTERNATOR W/VAC PUMP	TATA spare parts

265415409904	GLOW PLUG	TATA spare parts
265415409906	REGULATOR	TATA spare parts
265415409907	SPRING CONTACT	TATA spare parts
265415409908	BRUSH SET	TATA spare parts
265415409909	DE BRACKET INSERT	TATA spare parts
265415409910	SCREW BRG RETAINER	TATA spare parts
265415409913	GLOW PLUG QUICK START	TATA spare parts
265415409916	STARTER MOTOR-12V	TATA spare parts
265415409918	STARTER MOTOR	TATA spare parts
265415409923	GLOW PLUG TC	TATA spare parts
265415409926	STARTER MOTOR-12V -	TATA spare parts
265415409930	STARTER MOTOR	TATA spare parts
265415409933	ALTERNATOR 12V 40A W/W WL TER-1-GR BS2/3	TATA spare parts
265425200110	CLUTCH DISC 228 DIA	TATA spare parts
265425200118	CL DISC 228D	TATA spare parts
265425200121	228 DIA.CLUTCH DISC ASSY.(4DL NA)	TATA spare parts
265425200127	CLUTCH DISC WITH W/107 FACING	TATA spare parts
265425200133	ASSY.228 DIA.CLUTCH DISC-(F410)	TATA spare parts
265425200136	ASSY.228 DIA.CLUTCH DISC (F410)-VALEO	TATA spare parts
265425400108	CL PR PLATE 228 DIA	TATA spare parts
265425400117	CL PR PLATE 228 DIA GOOSENECK	TATA spare parts
265425400119	ASSY.228 DIA.PRESSURE PLATE(GOOSENECK)	TATA spare parts
265425600102	CL REL BRG W/SLEEVE	TATA spare parts
265425600110	CLUTCH RELEASE FORK	TATA spare parts
265425600111	CL REL BRG W/SLEEVE	TATA spare parts
265425600113	CL REL BRG W/SLEEVE	TATA spare parts
265425600115	CL REL BRG W/SLEEVE	TATA spare parts
265425600117	CL REL BRG W/SLEEVE	TATA spare parts
265425600118	CL.RELEASE BRG.W/ SLEEVE	TATA spare parts
265425603701	CLUTCH RELEASE SLEEVE	TATA spare parts
265425606701	BALL PIN CL REL FORK	TATA spare parts
265425608702	SPRING PLATE CL REL FORK	TATA spare parts
265429100106	CLUTCH MASTER CYL. 19.05 DIA.	TATA spare parts
265429100126	TUBE ASSY	TATA spare parts
265429100136	ASSY. SLAVE CYLINDER.	TATA spare parts
265429100137	CL SLAVE CYL	TATA spare parts
265429100148	CL SLAVE CYL	TATA spare parts
265429100149	REP KIT CL SL CYL MNR	TATA spare parts
265429100155	CL SLAVE CYL	TATA spare parts
265429100156	REP KIT CL SL CYL MNR	TATA spare parts
265429100156AE	REP KIT MNR SLAVE CYL -715	TATA spare parts
265429100157	REP KIT CL SL CYL MJR	TATA spare parts
265429100157AE	REP KIT MJR SLAVE CYL -715	TATA spare parts
265429100160	CL SLAVE CYL M10	TATA spare parts
265429100163	CLUTCH SLAVE CYL. 23.81 DIA.	TATA spare parts
265429100180	ASSY. HOSE	TATA spare parts
265429100184	PEDAL LEVER CLUTCH	TATA spare parts

265429100190	HOSE SLAVE CYL	TATA spare parts
265429100193	ASSY. PIPE (6 O.D)	TATA spare parts
265429100194	ASSY.CLUTCH MASTER CYLINDER	TATA spare parts
265429100195	ASSY.CLUTCH SLAVE CYL	TATA spare parts
265429100197	ASSY.CLUTCH PIPE (6 O.D)	TATA spare parts
265429107702	RUBBER CAP	TATA spare parts
265429107703	RUBBER SPACER	TATA spare parts
265429108705	COMPRESSION SPRING	TATA spare parts
265429110134	ASSY CNTRL MTG BRKT WITH BRAKE & CLUTCH	TATA spare parts
265429110136	ASSY. PEDAL LEVER (BRAKE R.H.D.)	TATA spare parts
265429110137	ASSY. CLUTCH PEDAL LEVER	TATA spare parts
265429110139	ASSY PIPE ( 6 OD )	TATA spare parts
265429200103	ASSY MINOR KIT ( 270)FOR 19.05 CMC	TATA spare parts
265429200104	ASSY MAJOR KIT ( 272) FOR 19.05	TATA spare parts
265429200105	ASSY MINOR KIT ( 276) FOR 23.81	TATA spare parts
265429200106	ASSY MAJOR KIT ( 277) FOR 23.81	TATA spare parts
265430100103	ASSY ENGINE STOP CABLE	TATA spare parts
265430100104	ASSY ENGINE STOP CABLE	TATA spare parts
265430100113	CABLE ACCLELERATOR LHD	TATA spare parts
265430100128	CABLE ACCLELERATOR LHD	TATA spare parts
265430100130	ASSY. ACCELERATOR CABLE	TATA spare parts
265430100134	ASSY ACCELERATOR CABLE-LHD	TATA spare parts
265430100135	ASSY.ACCELERATOR CABLE LHD (FIP)	TATA spare parts
265430100136	ASSY.ACCELERATOR CABLE RHD	TATA spare parts
265430100140	CABLE ACCLELERATOR RHD	TATA spare parts
265430100146	CABLE ACCELERATOR RHD	TATA spare parts
265430100154	ASSY ENGINE STOP CABLE	TATA spare parts
265430100155	BALL END ASSY B10	TATA spare parts
265430107701	RUBBER STOPPER	TATA spare parts
265430107702	RUBBER COVER ACCL PEDAL	TATA spare parts
265430107703	RUBBER SLEEVE	TATA spare parts
265430107704	RUBBER GROMMET	TATA spare parts
265430108202	BRACKET-ENGINE STOP MTG.	TATA spare parts
265430108217	TAB WASHER	TATA spare parts
265430108601	SPACER	TATA spare parts
265430108702	SPRING	TATA spare parts
265430108706	SPRING ACCELERATOR ROD	TATA spare parts
265430109902	CLEVIS PIN ACCL CONTROL	TATA spare parts
265430109903	BALL PIN	TATA spare parts
265431000114	FRAME ASSY P/UP BENCHSEAT	TATA spare parts
265431000117	FRAME ASSY COMP	TATA spare parts
265431000134	ASSY FRAME-PARABOLIC SPRING 4SP ENGINE	TATA spare parts
265431000138	ASSY.FRAME-PARABOLIC SPRING 31WB 4SP	TATA spare parts
265431000145	ASSY FRAME FOR PICKUP	TATA spare parts
265431000146	ASSY.FRAME 4X2 FACELIFT	TATA spare parts
265431000147	ASSY.FRAME 207 DI 28WB	TATA spare parts
265431000148	ASSY.FRAME 207 DI 31 WB	TATA spare parts

265431000151	ASSY FRAME 207 DI 28 WB	TATA spare parts
265431000152	ASSY FRAME 207 DI 31 WB	TATA spare parts
265431000153	ASSY.FRAME (TELCOLINE FL 31WB W/O LB)	TATA spare parts
265431000154	ASSY FRAME KIT-207 DI 31WB	TATA spare parts
265431000157	FRONT SKIRT	TATA spare parts
265431000158	ASSY.FRAME KIT MINOR KIT FOR RETRO	TATA spare parts
265431000162	ASSY,FRAME KIT 207 DI	TATA spare parts
265431000164	ASSY.FRAME (207DI TCD REDUCTION)	TATA spare parts
265431008201	FRONT SKIRT	TATA spare parts
265431100147	MOUNTING PLATE RH P/STRG	TATA spare parts
265431100148	BRACKET WHEEL STOPPER	TATA spare parts
265431100154	BRACKET WHEEL STOPPER	TATA spare parts
265431100187	ASSY. FUEL TANK SUPPORT-REAR	TATA spare parts
265431100188	ASSY. FUEL TANK SUPPORT FRONT-L.H.	TATA spare parts
265431100189	ASSY.TANK SUPPORT - FRONT	TATA spare parts
265431108269	BRACKET (FRONT CROSS MEMBER)	TATA spare parts
265431108277	SUPPORT	TATA spare parts
265431200113	CROSS MEMBER FRONT	TATA spare parts
265431200114	CROSS RUNNER REAR	TATA spare parts
265431200161	ASSY BODY MOUNTING BRACKET	TATA spare parts
265431200170	ASSY. BRACKET	TATA spare parts
265431200171	ASSY.BODY MOUNTING BRACKET	TATA spare parts
265431200175	ASSY. CROSS RUNNER-REAR	TATA spare parts
265431200176	ASSY. BODY MTG. BRACKET	TATA spare parts
265431200177	ASSY. END CROSS MEMBER	TATA spare parts
265431200179	ASSY. CROSS RUNNER FRONT	TATA spare parts
265431200182	ASSY.CROSS MEMBER C.B.	TATA spare parts
265431200185	ASSY. CROSS MEMBER FRONT	TATA spare parts
265431200188	ASSY.BODY MTG.BRACKET R.H.	TATA spare parts
265431200189	ASSY.BODY MTG.BRACKET L.H.	TATA spare parts
265431200190	ASSY.SUPPORT R.H.	TATA spare parts
265431200191	ASSY.SUPPORT L.H.	TATA spare parts
265431206915	TUBE (CROSS MEMBER REAR)	TATA spare parts
265431208218	SUPPORT ENG MTG REAR	TATA spare parts
265431208250	REINFORCEMENT-FUEL TANK SUPPORT	TATA spare parts
265431208251	REINFORCEMENT-FUEL TANK SUPPORT	TATA spare parts
265431210106	ASSY.BRACKET L.H. FRONT SKIRT MTG.	TATA spare parts
265431210107	ASSY.BRACKET R.H. FRONT SKIRT MTG.	TATA spare parts
265431210108	ASSY.SUPPORT L.H. REAR RUNNER	TATA spare parts
265431210109	ASSY.SUPPORT R.H. REAR RUNNER	TATA spare parts
265431210110	ASSY.SUPPORT RUNNER FRONT	TATA spare parts
265431210112	ASSY.BODY MTG.BRACKET	TATA spare parts
265431210113	ASSY.END CROSS MEMBER	TATA spare parts
265431210114	ASSY.TUBE(GEAR BOX EXTN.MTG.)	TATA spare parts
265431210121	ASSY.FUEL TANK SUPPORT (FRONT L.H.)	TATA spare parts
265431210122	ASSY.FUEL TANK SUPPORT (FRONT R.H.)	TATA spare parts
265431210124	ASSY.CROSS RUNNER LOAD BODY MTG.	TATA spare parts

265431210125	ASSY REINFORCEMENT REAR R H	TATA spare parts
265431218232	SUPPORT REINFORCEMENT (REAR R.H.)	TATA spare parts
265431218240	REINFORCEMENT RH	TATA spare parts
265431218241	REINFORCEMENT LH	TATA spare parts
265431218244	REINFORCEMENT R.H.	TATA spare parts
265431218245	REINFORCEMENT L.H.	TATA spare parts
265431218246	REINFORCEMENT REAR	TATA spare parts
265431218259	RETROFITMENT BRACKET L.H.	TATA spare parts
265431218260	RETROFITMENT BRACKET R.H.	TATA spare parts
265431218267	SUPPORT BKT RH	TATA spare parts
265431218268	SUPPORT BKT LH	TATA spare parts
265431300104	ASSY CROSS MEMBER - C.B.	TATA spare parts
265431400105	TOWING HOOK ASSY	TATA spare parts
265431400109	LOAD BODY MTG BKT RR TOP	TATA spare parts
265431400116	ASSY. TOWING HOOK R.H.	TATA spare parts
265431400117	ASSY.TOWING HOOK-FRONT	TATA spare parts
265431408235	SUPPORT ENGINE MTG FRONT	TATA spare parts
265431700104	CROSS RUNNER REAR	TATA spare parts
265431700146	ASSY CROSS RUNNER (TAIL LAMP MTG.)	TATA spare parts
265431700150	ASSY CROSS RUNNER (FOR FIXING LAMPS)	TATA spare parts
26543170015020	ASSY CROSS RUNNER FABRICATED	TATA spare parts
265432000107	KIT RUB BUSH FRT SUSPEN	TATA spare parts
265432100174	PIN WELDED VERSION	TATA spare parts
265432103214	PIN MOUNTING FRT ARB	TATA spare parts
265432105125	SPINDLE TOP LINK	TATA spare parts
265432105135	LOWER ARM---NLS	TATA spare parts
265432106104	LOCK PLATE LOWER ARM	TATA spare parts
265432106106	LOCK PLATE LOWER ARM	TATA spare parts
265432106915	SLEEVE	TATA spare parts
265432107719	SPRING SEAT FRT TOP 16MM	TATA spare parts
265432107746	RUBBER BUSH	TATA spare parts
265432107748	RUBBER LINK	TATA spare parts
265432107753	SPRING SEAT FRT TOP 20MM	TATA spare parts
265432107758	SPRING SEAT FRT TOP 24MM	TATA spare parts
265432107763	RUBBER BUSH BRAKE ROD	TATA spare parts
265432107910	ANTI ROLL BAR	TATA spare parts
265432107912	BRAKE ROD	TATA spare parts
265432108309	SHIM TOP LINK	TATA spare parts
265432108315	SHIM TOP LINK	TATA spare parts
265432108718	COIL SPRING FRONT SUSPN	TATA spare parts
265432108719	SPRING FRONT	TATA spare parts
265432109203	TONGUE WASHER	TATA spare parts
265432109215	WASHER	TATA spare parts
265432109219	WASHER	TATA spare parts
265432110101	BKT SUSPN C/MEMBER MTG	TATA spare parts
265432110107	ASSY. LOW. LINK LH	TATA spare parts
265432110110	PIVOT BUSH ASSY	TATA spare parts

265432110124	TOP LINK ASSY	TATA spare parts
265432110128	RUBBER STOPPER FRT BUMP	TATA spare parts
265432110130	BRACKET ASSY	TATA spare parts
265432110134	CROSS MEMBER ASSY	TATA spare parts
265432110140	BKT RH BRAKE ROD & ARB	TATA spare parts
265432110141	BKT LH BRAKE ROD & ARB	TATA spare parts
265432110162	LOWER LINK 0187	TATA spare parts
265432110187	LOWER LINK - RH	TATA spare parts
265432110189	LOWER LINK - LH	TATA spare parts
265432110194	BALL JOINT UPPER	TATA spare parts
265432110198	ASSY. WASHER	TATA spare parts
265432114202	CLAMP	TATA spare parts
265432118276	TOP LINK	TATA spare parts
265432118601	SPACER	TATA spare parts
265432119201	SPACER (FRONT BUMP STOPPER)	TATA spare parts
265432120102	TOP LINK W/OUT BOLL JOINT	TATA spare parts
265432120103	TOP LINK NEW	TATA spare parts
265432128219	LOCK PLATE	TATA spare parts
265432128221	LOCK PLATE	TATA spare parts
265432130137	ASSY. CROSS MEMBER FRONT-LOWER WB MTG.	TATA spare parts
265432130140	ASSY. CROSS MEMBER REAR-LOWER WB. MTG.	TATA spare parts
265432130157	ASSY. FRONT SPRING & RUBBER SEAT GRASS G	TATA spare parts
265432130158	ASSY. FRONT SPRING & RUBBER SEAT YELLOW	TATA spare parts
265432130159	ASSY. FRONT SPRING & RUBBER SEAT SOL PIN	TATA spare parts
265432130163	KIT-SUSPENSION RUBBER PARTS EURO1	TATA spare parts
265432130164	ASSY LOWER WISHBONE COMP RH MECH STG	TATA spare parts
265432130165	ASSY LOWER WISHBONE COMP LH MECH STG	TATA spare parts
265432130172	ASSY BRACKET COMP LH(SPRING CUP MTG)	TATA spare parts
265432130173	ASSY BRACKET COMP RH(SPRING CUP MTG)	TATA spare parts
265432130175	ASSY.CROSS MEMBER FRONT	TATA spare parts
265432138703	FRONT SPRING (SKY BLUE)	TATA spare parts
265432138704	FRONT SPRING EURO2	TATA spare parts
265432138705	FRONT SPRING	TATA spare parts
265432138716	FRONT SPRING	TATA spare parts
265432138717	FRONT SPRING (RED) EURO2	TATA spare parts
265432138718	FRONT SPRING SALMON PINK	TATA spare parts
265432300121	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
265432300133	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
265432300134	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
265432300135	ASSY. SHOCK ABSORBER	TATA spare parts
265432303402	BUSH FRT S/ABS	TATA spare parts
265432307502	BUSH FRT S/ABS	TATA spare parts
265432307710	BUSH FRT S/ABS	TATA spare parts
265432307718	RUBBER BUSH UPPER	TATA spare parts
265432308211	WASHER FRT S/ABSORBER	TATA spare parts
265432308212	WASHER FRT S/ABSORBER	TATA spare parts
265432308213	WASHER FRT S/ABSORBER	TATA spare parts

265432400108	BKT SPRING HANGER RR	TATA spare parts
265432400110	SADDLE REAR SPRING	TATA spare parts
265432400111	REAR SPRING ASSY	TATA spare parts
265432400113	BKT SPRING HANGER FRT	TATA spare parts
265432400115	ASSY. RUBBER BUSHING BS2/3/4	TATA spare parts
265432400116	SHACKLE REAR SPRING	TATA spare parts
265432400124	REAR SPRING ASSY	TATA spare parts
265432400125	LEAF SPRING 1ST W/BUSH RR	TATA spare parts
265432400127	SPRING CLIP	TATA spare parts
265432400142	ASSY. REAR SPRING PARABOLIC	TATA spare parts
265432400143	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
265432400145	ASSY. REAR SPRING PARABOLIC	TATA spare parts
265432400147	ASSY REAR SPRING	TATA spare parts
265432400149	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
265432400150	ASSY REAR SPRING	TATA spare parts
265432400151	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
265432400152	ASSY. REAR SPRING PARABOLIC	TATA spare parts
265432400153	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
265432404202	SPRING CLIP	TATA spare parts
265432404207	SPRING CLIP.	TATA spare parts
265432404210	SPRING CLIP	TATA spare parts
265432404213	SPRING CLIP	TATA spare parts
265432404215	SPRING CLIP	TATA spare parts
265432404217	CLAMP	TATA spare parts
265432404218	CLAMP	TATA spare parts
265432406703	SPRING PIN REAR	TATA spare parts
265432407142	LEAF SPRING 4TH RR	TATA spare parts
265432407144	LEAF SPRING 6TH RR	TATA spare parts
265432407145	LEAF SPRING 7TH RR	TATA spare parts
265432407147	LEAF SPRING 2ND RR	TATA spare parts
265432407148	LEAF SPRING 3RD RR	TATA spare parts
265432407149	LEAF SPRING 4TH RR	TATA spare parts
265432407150	LEAF SPRING 5TH RR	TATA spare parts
265432407151	LEAF SPRING 6TH RR	TATA spare parts
265432407152	LEAF SPRING 7TH RR	TATA spare parts
265432407177	SECOND LEAF	TATA spare parts
265432407178	THIRD LEAF	TATA spare parts
265432407179	PACKING	TATA spare parts
265432407184	SECOND LEAF	TATA spare parts
265432407185	THIRD LEAF	TATA spare parts
265432407186	PACKING PLATE	TATA spare parts
265432407187	SECOND LEAF	TATA spare parts
265432407188	THIRD LEAF	TATA spare parts
265432407190	PACKING 70X6X100	TATA spare parts
265432407192	SECOND LEAF	TATA spare parts
265432407193	THIRD LEAF	TATA spare parts
265432407194	CENTER PAD	TATA spare parts

265432407703	FRICION PAD	TATA spare parts
265432407705	FRICION PAD	TATA spare parts
265432407706	FRICION PAD	TATA spare parts
265432407709	TIP INSERT	TATA spare parts
265432407710	TIP INSERT	TATA spare parts
265432407712	TIP INSERT	TATA spare parts
265432409206	WASHER REAR SPG BKT FRT	TATA spare parts
265432430107	ASSY. BRACKET-REAR AXLE STOPPER	TATA spare parts
265432500101	STOPPER REAR AXLE	TATA spare parts
265432504205	U CLAMP REAR	TATA spare parts
265432507102	GUIDE PLATE RR SPRING	TATA spare parts
265432600114	SHOCK ABSORBER REAR	TATA spare parts
265432600115	BKT S/ABS RH REAR TOP FRT	TATA spare parts
265432600116	BKT LH RR ARB	TATA spare parts
265432600119	SHOCK ABSORBER REAR	TATA spare parts
265432600122	SHOCK ABSORBER REAR	TATA spare parts
265432800101	BUSH SUPPORT FRT ARB BOT	TATA spare parts
265432803301	BKT ANTI ROLL BAR RH FRT	TATA spare parts
265432803302	BKT ANTI ROLL BAR LH FRT	TATA spare parts
265432803308	MOUNTING BRACKET L.H.	TATA spare parts
265432803801	BUSH SUPPORT FRT ARB TOP	TATA spare parts
265432807702	BEARING BLOCK	TATA spare parts
265432807705	RUB BUSH FRT ARB BOTTOM	TATA spare parts
265432807706	RUB BUSH FRT ARB TOP SLIT	TATA spare parts
265432807901	ANTI ROLL BAR FRONT	TATA spare parts
265432807914	ANTI ROLL BAR FRONT 20D	TATA spare parts
265432808207	CLAMP ARB	TATA spare parts
265432900101	ANTI ROLL BAR REAR 20D	TATA spare parts
265432900117	CONNECTING ROD	TATA spare parts
265432900118	BKT RH ARB & SPARE WHEEL	TATA spare parts
265432900119	ANTI ROLL BAR REAR 24D	TATA spare parts
265432900120	ASSY. ANTIROLLBAR COMPL.(REAR)	TATA spare parts
265432900121	ASSY. ANTIROLLBAR COMPL.(REAR)	TATA spare parts
265432907701	BEARING BLOCK	TATA spare parts
265432907702	RUBBER BUSH ( REAR ARB MTG )	TATA spare parts
265432908224	CLAMP	TATA spare parts
265433000108	FRONT AXLE ASSY RH	TATA spare parts
265433000109	FRONT AXLE ASSY LH	TATA spare parts
265433000112	ASSY FRONT AXLE R H-POWER STRG	TATA spare parts
265433000113	ASSY FRONT AXLE L H-POWER STRG	TATA spare parts
265433000116	ASSY FRONT AXLE WITH BRAKES L.H	TATA spare parts
265433000117	ASSY FRONT AXLE WITH BRAKES R.H	TATA spare parts
265433200104	ASSY. BALL JOINT LOWER	TATA spare parts
265433200105	BALL JOINT STD1 LOW	TATA spare parts
265433200110	STUB AXLE ASSY RH	TATA spare parts
265433200111	STUB AXLE ASSY LH	TATA spare parts
265433200113	ASSY. BALL JOINT LOWER	TATA spare parts



265433200114	ASSY.BALL JOINT NORMAL-I	TATA spare parts
265433200123	ASSY. BALL JOINT LOWER	TATA spare parts
265433200126	ASSY. BALL JOINT LOWER BS2/3/4	TATA spare parts
265433200131	ASSY. BALL JOINT LOWER	TATA spare parts
265433200133	ASSY. BALL JOINT	TATA spare parts
265433205107	SPLIT NUT ON STUB AXLE	TATA spare parts
265433205120	STUB AXLE RH STD	TATA spare parts
265433205121	STUB AXLE LH STD	TATA spare parts
265433208202	DUST SHIELD	TATA spare parts
265433400102	HUB FRONT W/BRG & BR DISC	TATA spare parts
265433403101	TAPER ROLLER BRG LM48548 BS1/2/3/4	TATA spare parts
265433403102	TAPER ROLLER BRG 30205 BS1/2/3/4	TATA spare parts
265433403103	BEARING TAPER ROLLER	TATA spare parts
265433403104	BEARING TAPER ROLLER	TATA spare parts
265433403105	BEARING TAPER ROLLER	TATA spare parts
265433403106	BEARING TAPER ROLLER	TATA spare parts
265433403107	BEARING TAPER ROLLER	TATA spare parts
265433403108	BEARING TAPER ROLLER	TATA spare parts
265433403109	BEARING TAPER ROLLER	TATA spare parts
265433403111	BEARING TAPER ROLLER	TATA spare parts
265433403113	TAPER ROLLER BEARING	TATA spare parts
265433403702	HUB FR W/O BRG & BR DISC	TATA spare parts
265433407701	GASKET FR HUB COVER	TATA spare parts
265433407801	OIL SEAL	TATA spare parts
265433407802	OIL SEAL	TATA spare parts
265433407804	OIL SEAL	TATA spare parts
265433407805	OIL SEAL	TATA spare parts
265433408202	FRONT HUB COVER	TATA spare parts
265433408601	SEAL RACE	TATA spare parts
265433409201	THRUST WASHER	TATA spare parts
265433803209	BOLT STG ARM MTG	TATA spare parts
265433803210	BOLT STG ARM MTG	TATA spare parts
265433805117	TIE ROD ARM RH	TATA spare parts
265433805122	TIE ROD ARM - RH-POWER STG.	TATA spare parts
265433805123	TIE ROD ARM - LH-POWER STG.	TATA spare parts
265440100113	WHEEL RIM 5.5JX15	TATA spare parts
265440100116	WHEEL RIM COVER	TATA spare parts
265440100145	WHEEL RIM COVER TM	TATA spare parts
265440100147	WHEEL RIM COVER MODIFIED T	TATA spare parts
265440100149	ASSY WHEEL DISC & RIM 5 5J X 15	TATA spare parts
265440100153	ASSY WHEEL DISC & RIM 5 5J X 15	TATA spare parts
265440100154	ASSY WHEEL DISC & RIM 5 5J X 15	TATA spare parts
265440100159	SILVER PAINTED WHEEL RIM	TATA spare parts
265440100162	ASSY.TYRE(195R15TUBELESS) WITH VALVE.	TATA spare parts
265440100195	WHEEL RIM COVER CORP T 4 X 2	TATA spare parts
265440106501	WHEEL NUT	TATA spare parts
265440106504	WHEEL NUT	TATA spare parts

265440106702	WHEEL MTG BOLT	TATA spare parts
265440108204	SPARE WHEEL MTG. BRACKET	TATA spare parts
265440109933	TYRE 195R15-8PR LT-'E'CERTIFICATE(RADIAL	TATA spare parts
265440109934	TUBE 195R15 WITH VALVE TR 13 (B 35357)	TATA spare parts
265440300109	TUBE SPARE WHEEL CARRIEER	TATA spare parts
265440300128	ASSY SUPPORT	TATA spare parts
265440300133	ASSY. CLAMP	TATA spare parts
265440300140	ASSY.CHANNEL	TATA spare parts
265440306301	BUSH PLASTIC SP WH CARRIE	TATA spare parts
265440306702	SCREW WITH NYLON INSERT	TATA spare parts
265440306711	HEX.SCR.	TATA spare parts
265440306920	HEX.BOLT M12	TATA spare parts
265440306921	WASHER	TATA spare parts
265440308245	CLAMP	TATA spare parts
265440309205	SPACER	TATA spare parts
265441000106	PROP SHAFT MONOTRON	TATA spare parts
265441000108	ASSY PROPELLER SHAFT	TATA spare parts
265441100101	PROP SHAFT REAR 60X3X560	TATA spare parts
265441100104	KIT BRG STRAP & BOLT	TATA spare parts
265441100108	COUPLING FLANGE	TATA spare parts
265441100112	UJ KIT(COLD FORGED)	TATA spare parts
265441100113	SLIP YOKE ASSY(DANA-2-3-14551X)	TATA spare parts
265441100114	SEAL ASSY	TATA spare parts
265441110104	PROP SHAFT FR W/CEN BRG	TATA spare parts
265441120101	ASSY PROTECTIVE CAP	TATA spare parts
265441120102	PROP SHAFT REAR COMP	TATA spare parts
265441300103	CENTRE BRG COMPLT	TATA spare parts
265441300104	CENTRE BEARING	TATA spare parts
265441303101	SRDG BALL BRG	TATA spare parts
265441303102	SRDG BALL BRG	TATA spare parts
265441303103	BEARING BALL	TATA spare parts
265441303104	SRDG BALL BRG	TATA spare parts
265441303105	BALL BEARING 6207	TATA spare parts
265441303106	SRDG BALL BRG	TATA spare parts
265441303107	SRDG BALL BRG	TATA spare parts
265441303108	SRDG BALL BRG	TATA spare parts
265441303302	BKT CENTRE BEARING	TATA spare parts
265441307503	RUBBER CENTRE BEARING	TATA spare parts
265441307802	DUST SEAL	TATA spare parts
265441308204	DUST CAP	TATA spare parts
265441308205	DUST SEAL RETAINER	TATA spare parts
265441308601	SPACER RING CENTRE BRG	TATA spare parts
265441309201	WASHER	TATA spare parts
265442100101	ASSY.CALIPER BRAKE LH	TATA spare parts
265442100102	ASSY.CALIPER BRAKE RH	TATA spare parts
265442100105	CALIPER BR FRT LH	TATA spare parts
265442100106	CALIPER BR FRT RH	TATA spare parts

265442100107	BRAKE PAD SAFARI ANTISQUEAL	TATA spare parts
265442100108	REP KIT FR CALIPER MJR	TATA spare parts
265442100109	REP KIT FR CALIPER MNR	TATA spare parts
265442100110	REP KIT SLIDING PIN	TATA spare parts
265442100111	ASSY. BRAKE PAD FRONT	TATA spare parts
265442100111DF01	BRAKE PAD KIT - 207DI PICKUP	TATA spare parts
265442100111DF02	BRAKE PAD KIT - 207DI PICKUP	TATA spare parts
265442100125	CALIPER BR FRT LH	TATA spare parts
265442100126	CALIPER BR FRT RH	TATA spare parts
265442100133	MAJOR KIT DISC BRAKE- NO.281	TATA spare parts
265442100134	MINOR KIT DISC BRAKE NO.280	TATA spare parts
265442100135	PAD KIT	TATA spare parts
265442100136	KIT SLIDING PIN	TATA spare parts
265442100137	DISC BRAKE ASSY.LH	TATA spare parts
265442100138	ASSC BRAKE ASSY.RH	TATA spare parts
265442100139	ASY.CALIPER BRAKE-LH	TATA spare parts
265442100140	ASY.CALIPER BRAKE-RH	TATA spare parts
265442100148	ASY.CALIPER BRAKE-LH	TATA spare parts
265442100149	ASY.CALIPER BRAKE-RH	TATA spare parts
265442100162	ASY.CALIPER BRAKE RH	TATA spare parts
265442100170	ASY.CALIPER BRAKE LH	TATA spare parts
265442100177	KIT-PAD WITH ANTISQUEAL SHIM	TATA spare parts
265442100178	MAJOR KIT-TMC 23.81 DIA	TATA spare parts
265442100179	MINOR KIT- TMC23.81 DIA	TATA spare parts
265442100184	ASSY. CALIPER BRAKE -LH	TATA spare parts
265442100185	ASSY. CALIPER BRAKE -RH	TATA spare parts
265442103701	BRAKE DISC	TATA spare parts
265442103704	VENTILATED BRAKE DISC BS1/2/3/4	TATA spare parts
265442108002	BLEEDER-KALYANI BRAKE NO.P7631538	TATA spare parts
265442108202	ANTI RATTLE CLIP	TATA spare parts
265442108704	PAD SPRING	TATA spare parts
265442300108	BR SHOE LEADING ASBS	TATA spare parts
265442300109	BR SHOE TRAILING ASBS	TATA spare parts
265442300110	KIT BR LINING STD RR	TATA spare parts
265442300111	KIT BR LINING RS1 RR	TATA spare parts
265442300112	KIT CAM ADJUSTER RR	TATA spare parts
265442300113	KIT SHOE HOLD DOWN	TATA spare parts
265442300114	ASSY.STRUT BI NO.64272444	TATA spare parts
265442300115	LEVER HAND BRAKE LH	TATA spare parts
265442300116	LEVER HAND BRAKE RH	TATA spare parts
265442300117	REP KIT WHEEL CYL RR	TATA spare parts
265442300118	KIT SCREW & WASHER	TATA spare parts
265442300119	ASSY. WHEEL CYL.(22.22 DIA) BS2/3	TATA spare parts
265442300122	ASSY REAR BRAKE LH(22 DIA W/CYL)	TATA spare parts
265442300123	BRAKE ASSY RR RH	TATA spare parts
265442300128	BRAKE LH RR NASB TM	TATA spare parts
265442300129	BRAKE ASSY RR RH NASBS	TATA spare parts

265442300132	TRAILING SHOE LH N/ASB	TATA spare parts
265442300133	TRAILING SHOE RH N/ASB	TATA spare parts
265442300135	KIT BRLINING NASB	TATA spare parts
265442300145	BACK PLATE COMP LH	TATA spare parts
265442300146	BACK PLATE COMP RH	TATA spare parts
265442300147	WHEEL CYL.22.22D RR	TATA spare parts
265442300150	MAJOR KIT W/C 285	TATA spare parts
265442300151	LINED SHOE KIT	TATA spare parts
265442300152	LINING KIT (STD.)	TATA spare parts
265442300153	KIT BR LINING RS1 NASB	TATA spare parts
265442300158	REP KIT W/CYL MIN	TATA spare parts
265442300159	KIT BRAKE LINING NON-ASB AF2873	TATA spare parts
265442300159AE	KIT BRK LNG N-ASB-SUMO-XEN DC/SC	TATA spare parts
265442300162	LINING SET 0.8 OVERSIZE BI29937143	TATA spare parts
265442303705	BRAKE DRUM REAR	TATA spare parts
265442303706	BRAKE DRUM RR	TATA spare parts
265442304302	U CLIP KBX	TATA spare parts
265442306001	HAND BRAKE LEVER LH NO.P6303726	TATA spare parts
265442306002	HAND BRAKE LEVER RH	TATA spare parts
265442306601	PISTON	TATA spare parts
265442306702	PIN HAND BRAKE LEVER	TATA spare parts
265442306703	SHOE SET PIN	TATA spare parts
265442307101	STRUT NO.P6306459	TATA spare parts
265442307401	RIVET	TATA spare parts
265442308201	ANCHOR PLATE LH	TATA spare parts
265442308202	ANCHOR PLATE RH	TATA spare parts
265442308701	RET SPRING TOP	TATA spare parts
265442308702	RET SPRING BOT	TATA spare parts
265442308705	SHOE RETURN SPRING NO.P6503935	TATA spare parts
265442308706	SHOE RETURN SPRING F/P NO.P6503943	TATA spare parts
265442308707	SPRING SHOE HOLD DOWN NO.6503766	TATA spare parts
265442309204	WASHER CUP	TATA spare parts
265442309903	CUP SHOE HOLD DOWN NO.P6306540	TATA spare parts
265442400103	L.C.R.V.-INDIGENOUS	TATA spare parts
265442700102	TUBE ASSY	TATA spare parts
265442700128	PULL ROD ASSY	TATA spare parts
265442700137	ASSY.LEVER	TATA spare parts
265442700140	PARKING BRAKE UNIT RHD	TATA spare parts
265442700141	LEVER COMPLETE	TATA spare parts
265442700144	ASSY.CLIP WITH PVC SLEEVING	TATA spare parts
265442700145	HANDLE NLS COMP RHD	TATA spare parts
265442700165	ASSY.PARKING BRAKE CABLE LHD	TATA spare parts
265442700168	HOLDING PLATE	TATA spare parts
265442700170	ASSY.PARKING BRAKE CABLE FRONT	TATA spare parts
265442700171	CABLE HAND BRAKE RR RHD	TATA spare parts
265442700172	ASSY.PARKING BRAKE CABLE REAR LHD	TATA spare parts
265442700174	HANDLE PULL & TURN	TATA spare parts

265442700175	ASSY HANDLE COMPLETE	TATA spare parts
265442700177	HAND BR CABLE FRT	TATA spare parts
265442700178	ASSY.BRACKET	TATA spare parts
265442700179	HAND BR CABLE RR	TATA spare parts
265442700186	HAND BR CABLE RR RH	TATA spare parts
265442700187	HAND BR CABLE RR LH	TATA spare parts
265442700189	ASSY.CLIP	TATA spare parts
265442700190	ASSY PARKING BRAKE UNIT-RHD	TATA spare parts
265442700191	ASSY GUIDING TUBE WITH PAWL	TATA spare parts
265442700192	ASSY HANDLE -RHD	TATA spare parts
265442700193	ASSY GUIDING TUBE RHD	TATA spare parts
265442700195	PARKING BRAKE UNIT LHD	TATA spare parts
265442700208	ASSY.PARKING BRAKE CABLE	TATA spare parts
265442700219	ASSY.PARKING BR.CABLE-LHD	TATA spare parts
265442704206	CLIP WITH PVC COATING	TATA spare parts
265442704207	CLIP	TATA spare parts
265442706501	TURN BUCKLE NUT	TATA spare parts
265442706702	CLEVIS PIN	TATA spare parts
265442706704	SCREW	TATA spare parts
265442706706	CLEVIS PIN	TATA spare parts
265442706707	CLEVIS PIN	TATA spare parts
265442706711	PIN	TATA spare parts
265442706714	PIN 5P6 X 17.5	TATA spare parts
265442706715	CYL PIN 5P6 X 20	TATA spare parts
265442706716	PIN 5P6 X 30	TATA spare parts
265442707001	PULLEY	TATA spare parts
265442707101	CAM	TATA spare parts
265442707702	WASHER	TATA spare parts
265442707909	RACHET ROD	TATA spare parts
265442707910	RATCHET ROD	TATA spare parts
265442708201	PAWL	TATA spare parts
265442708601	SPRING GUIDE	TATA spare parts
265442708701	HELICAL SPRING	TATA spare parts
265442708702	HELICAL TORSION SPRING	TATA spare parts
265442708705	TORSION SPRING	TATA spare parts
265442708706	TORSION SPRING	TATA spare parts
265442709906	DISC	TATA spare parts
265442709907	DISC	TATA spare parts
265442709909	CAM SINTERED	TATA spare parts
265442710106	ASSY. BRACKET COMPLETE	TATA spare parts
265442710110	ASSY. HANDLE COMPLETE	TATA spare parts
265442710116	ASSY. HANDLE	TATA spare parts
265442710122	ASSY.PARKING BRAKE CABLE FRONT	TATA spare parts
265442800101	TUBE ASSY	TATA spare parts
265442800103	TUBE ASSY	TATA spare parts
265442800110	ASSY.BRAKE HOSE	TATA spare parts
265442800114	TUBE ASSY	TATA spare parts

265442800119	ASSY.HOSE 3.2 DIA	TATA spare parts
265442800120	TUBE ASSY	TATA spare parts
265442800126	TUBE ASSY	TATA spare parts
265442800128	HOSE BRAKE 3.2D	TATA spare parts
265442800130	TUBE ASSY	TATA spare parts
265442800136	TUBE ASSY	TATA spare parts
265442800144	TUBE ASSY FR BR RH PART2	TATA spare parts
265442800145	TUBE ASSY FR BR LH PART2	TATA spare parts
265442800146	TUBE ASSY	TATA spare parts
265442800147	TUBE ASSY	TATA spare parts
265442800149	TUBE ASSY FR BR LH PART1	TATA spare parts
265442800182	TUBE ASSY	TATA spare parts
265442800185	ASSY. BRACKET RH (FRONT BRAKE HOSE)	TATA spare parts
265442800186	ASSY. BRACKET LH (FRONT BRAKE HOSE)	TATA spare parts
265442800193	ASSY.TUBE.	TATA spare parts
265442800195	ASSY.BANJO BODY	TATA spare parts
265442800196	ASSY. TUBE	TATA spare parts
265442800197	ASSY. TUBE	TATA spare parts
265442800198	ASSY. TUBE TO TEE ON REAR AXLE	TATA spare parts
265442803201	BOLT BRAKE DISC TO HUB	TATA spare parts
265442803202	BANJO BOLT	TATA spare parts
265442803303	BRACKET	TATA spare parts
265442803309	SUPPORT REAR BRAKE UNION	TATA spare parts
265442803312	BRACKET	TATA spare parts
265442803313	BRACKET	TATA spare parts
265442804202	COATED CLAMP	TATA spare parts
265442806302	SLEEVE	TATA spare parts
265442806303	SLEEVE	TATA spare parts
265442806801	BANJO BOLT	TATA spare parts
265442806803	BANJO BOLT M10 X 1	TATA spare parts
265442806806	BANJO BODY	TATA spare parts
265442807705	PIPE CLAMP	TATA spare parts
265442808201	BRACKET	TATA spare parts
265442808601	SPACER	TATA spare parts
265442809201	SEALING WASHER CU 10X14	TATA spare parts
265442810103	ASSY.TUBE	TATA spare parts
265442810114	ASSY.TUBE	TATA spare parts
265442810115	ASSY.TUBE	TATA spare parts
265442810116	ASSY.TUBE	TATA spare parts
265442810120	ASSY.TUBE.	TATA spare parts
265442810121	ASSY. TUBE	TATA spare parts
265442810122	ASSY. TUBE	TATA spare parts
265442810126	ASSY. BRAKE HOSE FRONT	TATA spare parts
265443100101	TANDEM MASTER CYL.	TATA spare parts
265443100104	BRAKE FLUID CONTAINER	TATA spare parts
265443100106	TANDEM MASTER CYL	TATA spare parts
265443100108	KIT REP MAJOR TMC	TATA spare parts

265443100109	KIT MINOR TMC 0108	TATA spare parts
265443100111	BRAKE FLUID CONTAINER	TATA spare parts
265443100112	TANDEM MASTER CYL	TATA spare parts
265443100118	ASSY BRAKE FLUID CONTAINER	TATA spare parts
265443100119	BRAKE FLUID RESERVOIR,MOTH.CON	TATA spare parts
265443100120	TANDEM MASTER CYL NLS 0131	TATA spare parts
265443100121	ASSY BRAKE FLUID CONTAINER	TATA spare parts
265443100122	ASSY BRAKE FLUID CONTAINER	TATA spare parts
265443100124	MAJOR KIT BRAKE NO.	TATA spare parts
265443100125	MINOR KIT NO. 269	TATA spare parts
265443100126	OIL RESERVOIR ASSLY. WITH F.L.W.I.	TATA spare parts
265443100127	BRAKE FLUID RESERVIOR ASSY	TATA spare parts
265443100128	ASSY BRAKE FLUID CONTAINER	TATA spare parts
265443100130	ASSY BRAKE FLUID CONTAINER	TATA spare parts
265443100131	TANDEM MASTER CYL.(M 7001102)ALUMINI	TATA spare parts
265443100132	MAJOR KIT-TANDEM MASTER CYL	TATA spare parts
265443100133	MINOR KIT-TANDEM MASTER CYL	TATA spare parts
265443106301	DRIP TRAY	TATA spare parts
265443500101	VACCUM BOOSTER	TATA spare parts
265443500102	VACCUM BOOSTER	TATA spare parts
265443500118	VACCUM BOOSTER	TATA spare parts
265443500119	ASSY.10 INCH VACUUM BOOSTER	TATA spare parts
265444800101	PIPE ASSY	TATA spare parts
265444800105	PIPE ASSY	TATA spare parts
265446000105	ASSY.STEERING GEAR BOX	TATA spare parts
265446000110	ASSY.STEERING GEAR BOX	TATA spare parts
265446000113	ASSY.STEERING COLUMN	TATA spare parts
265446100101	ASSY TILT STG COLUMN FABRICATED	TATA spare parts
265446100102	ASSY TILT STG COLUMN;FABRICATED STANDARD	TATA spare parts
265446100103	UPPER COLUMN ASSY	TATA spare parts
265446100104	UNIVERSAL JOINT ASSY	TATA spare parts
265446200137	BOLT W/NYLON INSERT	TATA spare parts
265446200162	RATCHET ASSY	TATA spare parts
265446200166	STAY BKT STRG TO FIREWALL	TATA spare parts
265446200181	ASSY SLEEVE	TATA spare parts
265446200183	ASSY. TILT STG.UNIT COMPLETE-STG. LOCK	TATA spare parts
265446200184	ASSY SLEEVE	TATA spare parts
265446200191	HANDLE ASSY	TATA spare parts
265446200193	BRACKET MOUNTING	TATA spare parts
265446200198	ASSY STAY BRACKET-RHD	TATA spare parts
265446200199	ASSY. STAY BRACKET (LHD)	TATA spare parts
265446203201	ADJUSTING SCREW	TATA spare parts
265446203205	FITTING SCREW	TATA spare parts
265446203403	BUSH BEARING	TATA spare parts
265446203404	BUSH BEARING	TATA spare parts
265446203406	BUSH	TATA spare parts
265446204705	COVER	TATA spare parts

265446204707	COVER	TATA spare parts
265446205302	GASKET	TATA spare parts
265446205304	GASKET	TATA spare parts
265446206314	BUSH RUBBER BELLOW	TATA spare parts
265446206315	BUSH CAM PIVOT	TATA spare parts
265446206318	RUBBER BELLOW-BOTTOM	TATA spare parts
265446206508	SLOTTED NUT M22 X 1.5	TATA spare parts
265446206704	PIN	TATA spare parts
265446206706	PIN RETURN SPRING	TATA spare parts
265446207118	SPACER STRG G/BOX MTG	TATA spare parts
265446207701	OIL SEAL 31.76 X 48 X 7	TATA spare parts
265446207935	SECTOR SHAFT V/RATIO	TATA spare parts
265446207936	STEERING SPINDLE BOTTOM	TATA spare parts
265446207940	STEERING SPINDLE BOTTOM	TATA spare parts
265446207941	STEERING SPINDLE BOTTOM	TATA spare parts
265446208253	SPRING SEATING CUP	TATA spare parts
265446208270	STAY BRACKET (RIGID STG. COLUMN MTG.)	TATA spare parts
265446208278	SPRING SEAT CUP	TATA spare parts
265446208281	STIFFENER	TATA spare parts
265446208602	SPACER 2.00 MM	TATA spare parts
265446208603	SPACER 2.05 MM	TATA spare parts
265446208604	SPACER 2.10 MM	TATA spare parts
265446208605	SPACER 2.15 MM	TATA spare parts
265446208606	SPACER 2.20 MM	TATA spare parts
265446208607	SPACER 2.25 MM	TATA spare parts
265446208608	SPACER 2.30 MM	TATA spare parts
265446208609	SPACER 2.35 MM	TATA spare parts
265446208610	SPACER 2.40 MM	TATA spare parts
265446208611	SPACER 2.45 MM	TATA spare parts
265446208612	SPACER 2.50 MM	TATA spare parts
265446208704	TENSION SPRING	TATA spare parts
265446208710	COMP SPRING STRG COLUMN	TATA spare parts
265446208711	COMPRESSION SPRING	TATA spare parts
265446209202	WASHER	TATA spare parts
265446209203	WASHER 1.25 MM	TATA spare parts
265446209911	SPRING SEAT	TATA spare parts
265446209915	SPRING SEAT	TATA spare parts
265446210107	SUB-ASSY.PAWL (WITH BOSS).	TATA spare parts
265446210109	PAWL W/GUIDING PIN	TATA spare parts
265446210118	STAY BRACKET LHD	TATA spare parts
265446300113	IDLER ARM RHD M/STRG	TATA spare parts
265446300115	BKT IDLER ARM RHD M/STRG	TATA spare parts
265446300124	BKT IDLER ARM RHD M/STRG M16	TATA spare parts
265446300135	ASSY BKT IDLER ARM MTG P/STG	TATA spare parts
265446300140	ASSY IDLER ARM WITH BRACKET	TATA spare parts
265446300141	ASSY IDLER ARM WITH BRACKET-P/STG	TATA spare parts
265446300143	ASSY IDLER ARM WITH BUSH-P/STG	TATA spare parts



265446303407	BUSH IDLER ARM	TATA spare parts
265446303409	BUSH IDLER ARM	TATA spare parts
265446303415	BUSH IDLER ARM	TATA spare parts
265446303416	BUSH	TATA spare parts
265446306007	PITMAN ARM	TATA spare parts
265446308602	SHIM IDLER ARM PIN	TATA spare parts
265446308603	SHIM IDLER ARM PIN	TATA spare parts
265446308604	SHIM IDLER ARM PIN	TATA spare parts
265446308606	SHIM IDLER ARM PIN	TATA spare parts
265446309201	THRUST WASHER-IDLER ARM	TATA spare parts
265446309202	WASHER-IDLER ARM	TATA spare parts
265446309212	WASHER	TATA spare parts
265446309213	THRUST WASHER IDLER ARM	TATA spare parts
265446309214	WASHER IDLER ARM	TATA spare parts
265446309216	WASHER IDLER ARM	TATA spare parts
265446400104	ASSY STG WHEEL-420 DIA	TATA spare parts
265446400107	ASSY.TOP COVER	TATA spare parts
265446400112	ASSY STG WHEEL 420 DIA	TATA spare parts
265446400117	STRG WHEEL 400 DIA	TATA spare parts
265446406301	T EMBLEM	TATA spare parts
265446406311	T EMBLEM EUROPE	TATA spare parts
265446406312	T EMBLEM MODIFIED	TATA spare parts
265446600111	CENTRE LINK ASSY	TATA spare parts
265446600114	TIE ROD ASSY	TATA spare parts
265446600115	TIE ROD ASSY	TATA spare parts
265446600116	TIE ROD END LH	TATA spare parts
265446600117	TIE ROD END ASSY.R.H	TATA spare parts
265446600120	CENTRE LINK ASSY	TATA spare parts
265446600121	TIE ROD ASSY	TATA spare parts
265446600137	KIT REP CENTRE LINK MJR	TATA spare parts
265446603201	BOLT	TATA spare parts
265446800107	ASSY BRACKET-P/STG RESERVOIR MTG 4SP	TATA spare parts
265446800108	ASSY LOW PRESSURE HOSE	TATA spare parts
265446800109	ASSY SUCTION PIPE	TATA spare parts
265446800111	ASSY HIGH PRESS. HOSE COMPLETE	TATA spare parts
265446800112	ASSY LOW PRESS. HOSE COMPLETE	TATA spare parts
265446800113	ASSY SUCTION HOSE COMPLETE	TATA spare parts
265446800114	ASSY. RETURN LINE-GEARBOX SIDE	TATA spare parts
265446800115	ASSY. RETURN LINE-RESERVOIR SIDE	TATA spare parts
265446800116	ASSY HIGH PRESS. HOSE COMPLETE	TATA spare parts
265446800117	ASSY.RETURN HOSE (GEAR BOX SIDE)	TATA spare parts
265446800158	ASSY BKT P/STG RESERVOIR MTG 207DI BSII	TATA spare parts
265446805801	SUCTION HOSE-207 - DI	TATA spare parts
265447100119	FUEL TANK	TATA spare parts
265447100121	SUCTION TUBE	TATA spare parts
265447100126	CAP FUEL TANK	TATA spare parts
265447100134	CAP FUEL TANK	TATA spare parts

265447100142	CONTROL VALVE	TATA spare parts
265447100156	SUCTION TUBE	TATA spare parts
265447100161	ASSY. FUEL TANK COMPLETE	TATA spare parts
265447100165	FUEL TANK W/O VALVES	TATA spare parts
265447100180	ASSY.FILLER NECK TOP WITH BRACKET	TATA spare parts
265447100181	ASSY.TUBE	TATA spare parts
265447100187	ASSY FUEL TANK COMPLETE	TATA spare parts
265447100189	ASSY FILLER NECK TOP FOR PLAS CAP + BKT	TATA spare parts
265447100192	ASSY. FILLER NECK TOP WITH BRACKET	TATA spare parts
265447107701	HOSE FUEL TANK NECK	TATA spare parts
265447107705	HOSE FUEL FILLING	TATA spare parts
265447107706	GROMMET FUEL TANK	TATA spare parts
265447107713	RUBBER SUPPORT	TATA spare parts
265447107721	HOSE-FUEL FILLING	TATA spare parts
265447107723	HOSE (FUEL FILLING)	TATA spare parts
265447500109	STRAP FUEL TANK	TATA spare parts
265447500111	STRAP FUEL TANK	TATA spare parts
265447507701	RUBBER PACKING	TATA spare parts
265447507706	RUBBER PACKING	TATA spare parts
265447507710	RUBBER PACKING	TATA spare parts
265447508802	PIN	TATA spare parts
265447600101	SUCTION LINE HOSE-FILLER	TATA spare parts
265447600108	PIPE BREATHER	TATA spare parts
265447600109	PIPE BREATHER	TATA spare parts
265447600110	RETURN LINE HOSE-TANK	TATA spare parts
265447600111	SUCTION LINE TANK TO HOSE	TATA spare parts
265447600121	FUEL RETURN LINE	TATA spare parts
265447600122	SUCTION LINE TANK TO HOSE	TATA spare parts
265447600134	ASSY. SUCTION LINE-TANK TO HOSE	TATA spare parts
265447600135	ASSY. RETURN LINE-HOSE TO TANK	TATA spare parts
265447600144	ASSY. SUCTION LINE-TANK TO HOSE	TATA spare parts
265447600145	ASSY. RETURN LINE-HOSE TO TANK	TATA spare parts
265447600146	ASSY BREATHER TUBE (FILLER NECK TO TANK)	TATA spare parts
265447605801	FUEL HOSE-16.5 OD & 10 ID	TATA spare parts
265447606918	TUBE RETURN LINE 10 X 0.7	TATA spare parts
265447606919	TUBE SUCTION LINE10 X 0.7	TATA spare parts
265447606930	SUCTION TUBE	TATA spare parts
265447606966	BREATHER TUBE	TATA spare parts
265447607702	PIPE CLAMP	TATA spare parts
265447608201	CLIP (15 OD BREATHER TUBE)	TATA spare parts
265449100107	SILENCER W/HOOK	TATA spare parts
265449100108	EXHAUST PIPE FRONT	TATA spare parts
265449100111	ASSY.SILENCER WITH HOOK	TATA spare parts
265449105301	GASKET EXH PIPE	TATA spare parts
265449105302	GASKET	TATA spare parts
265449200126	EXHAUST PIPE CENTRE	TATA spare parts
265449200139	EXHAUST PIPE REAR	TATA spare parts

265449200143	ASSY EXHAUST PIPE FRONT	TATA spare parts
265449200144	ASSY. EXHAUST PIPE MIDDLE	TATA spare parts
265449200155	ASSY. EXHAUST PIPE MIDDLE	TATA spare parts
265449200161	ASSY. EXHAUST PIPE REAR	TATA spare parts
265449200162	ASSY EXHAUST PIPE REAR 207- DI	TATA spare parts
265449200166	GASKET ASSY	TATA spare parts
265449200176	ASSY. EXHAUST PIPE FRONT.	TATA spare parts
265449200180	ASSY EXH PIPE REAR (207-DI)	TATA spare parts
265449205301	GASKET	TATA spare parts
265449205303	GASKET	TATA spare parts
265449205305	GASKET- EXHAUST PIPE	TATA spare parts
265449205306	GASKET- EXHAUST PIPE	TATA spare parts
265449206909	TUBE	TATA spare parts
265449207702	RUBBER SPACER	TATA spare parts
265449207703	RUBBER HANGER	TATA spare parts
265454100103	BATTERY CLAMP	TATA spare parts
265454100114	BATTERY CLAMP RHD	TATA spare parts
265454100115	BATTERY CLAMP LHD	TATA spare parts
265454100118	COPPER BATT.CABLE -NLS	TATA spare parts
265454100123	ASSY.COPPER BATT.CABLE +VE-LHD	TATA spare parts
265454100124	ASSY.BATTERY CABLE +VE & -VE-RHD	TATA spare parts
265454100125	ASSY.BATTERY CABLE +VE & -VE-LHD	TATA spare parts
265454107503	TUBE BATTERY ACID DRAIN	TATA spare parts
265454107506	BATTERY ACID TRAY RHD	TATA spare parts
265454107507	BATTERY ACID TRAY LHD	TATA spare parts
265454107508	BATTERY FOAM	TATA spare parts
265454108205	BATTERY STOPPER	TATA spare parts
265454108801	STUD BATTERY CLAMP	TATA spare parts
265454109930	BATTERY,12V-75AH-75DS31R-(AMARA RAJA)	TATA spare parts
265454110101	ASSY.BATT.CABLE -VE [0.97 MM LONG]	TATA spare parts
265454110104	BATTERY CABLE -VE	TATA spare parts
265454200111	CLUSTER MOUNTING BRKT NEW	TATA spare parts
265454200113	BKT CLUSTER MTG UPPER	TATA spare parts
265454200120	LAMP HOLDER ASSY	TATA spare parts
265454200121	SPEEDOMETER 1:1.3	TATA spare parts
265454200122	RPM METER	TATA spare parts
265454200123	GAUGE FUEL/TEMP PCB TYPE	TATA spare parts
265454200142	INST CLST 1:1.30	TATA spare parts
265454200146	ELECTRIC BUZZER UNIT	TATA spare parts
265454200149	RELAY COVER 6 RELAYS	TATA spare parts
265454200154	ASSY BUZZER	TATA spare parts
265454200155	ELECTRIC BUZZER UNIT	TATA spare parts
265454200161	ELECTRIC BUZZER UNIT	TATA spare parts
265454200162	BUZZER WITH INDIAN TRS.& CONN.HSG.	TATA spare parts
265454200163	BUZZER UNIT	TATA spare parts
265454200164	ELECTRIC BUZZER UNIT	TATA spare parts
265454200170	BUZZER UNIT	TATA spare parts

265454200191	BUZZER W/INDIAN CONN.M/S SNEHA ELECTRO.	TATA spare parts
265454200192	ELECTRIC BUZZER UNIT	TATA spare parts
265454200194	DIGITAL CLOCK	TATA spare parts
265454204303	CLIP	TATA spare parts
265454204901	RELAY	TATA spare parts
265454204902	RELAY BASE	TATA spare parts
265454204904	PCB W/HIGH TEMP C/O & LFU	TATA spare parts
265454204907	GLOW PLUG TIMER	TATA spare parts
265454204909	RELAY AUXILIARIES	TATA spare parts
265454204911	RELAY BOTTOM COVER	TATA spare parts
265454204912	GLOW PLUG TIMER	TATA spare parts
265454204913	RELAY W/SURGE SUPPRESS BS1/2/3/4/6	TATA spare parts
265454204914	RELAY (FOR AUXILIARIES) 12V	TATA spare parts
265454204915	GLOW PLUG TIMER 207 FAMILY	TATA spare parts
265454206304	CASE	TATA spare parts
265454206305	FRONT DIAL INSTRU CLUSTER	TATA spare parts
265454206306	CRYSTAL INSTR.CLUSTER	TATA spare parts
265454206311	PLUG BUTTON (FOR 23DIA.HOLE)	TATA spare parts
265454208219	BRACKET [Reversing Buzzer mtg.]	TATA spare parts
265454208223	TIMER AND RELAY COVER	TATA spare parts
265454209903	SPEEDOCABLE 1300MM 3.2D	TATA spare parts
265454209912	SPEEDOCABLE 2200MM 3.2D	TATA spare parts
265454209914	CAPLESS BULB INST PANEL	TATA spare parts
265454209917	ELECT.BUZZER W/INDIAN TRS.& CONN.	TATA spare parts
265454209921	MULTIFUNCTION MODULE	TATA spare parts
265454209927	MULTIFUNCTION MODULE	TATA spare parts
265454209940	SPEEDOCABLE 1250MM	TATA spare parts
265454209942	TANK UNIT-SOLID FLOAT & 60 LTS.[O.DRG.].	TATA spare parts
265454209943	FUEL TANK UNIT (60 Ltrs)	TATA spare parts
265454209944	FUEL TANK UNIT	TATA spare parts
265454209950	HORN HIGH TONE	TATA spare parts
265454209960	FUEL TANK UNIT	TATA spare parts
265454209968	3.2 DIA SPEEDOCABLE LG-2350-	TATA spare parts
265454209969	SPEEDOMETER 1:0.935 TYPE-A1	TATA spare parts
265454209980	FUEL TANK UNIT	TATA spare parts
265454209982	3.2 DIA SPEEDOCABLE 1100MM	TATA spare parts
265454209983	FUEL TANK UNIT W/O PIGTAIL(50 LTR)	TATA spare parts
265454209985	FUEL TANK UNIT W/O PIGTAIL(60LTR)	TATA spare parts
265454209987	3.2 DIA SPEEDOCABLE 1100MM	TATA spare parts
265454209988	12V,CLEAR HIGH TONE'E'MARK HORN	TATA spare parts
265454209989	12V,CLEAR LOW TONE'E'MARK HORN	TATA spare parts
265454209994	3.2.DIA SPEEDOCABLE 1300 MM-JIS	TATA spare parts
265454209997	3.2DIA SPEEDO CABLE 1300MM JIS(4SP)OFFER	TATA spare parts
265454209998	3.2DIA SPEEDO CABLE 1300MM JIS-4SP	TATA spare parts
265454209999	FUEL AND TEMP GAUGE	TATA spare parts
265454210102	BUZZER UNIT	TATA spare parts
265454210103	ELECTRIC BUZZER UNIT	TATA spare parts

265454210108	ELECTRIC BUZZER UNIT	TATA spare parts
265454210109	BUZZER UNIT	TATA spare parts
265454210112	ELECTRIC BUZZER UNIT	TATA spare parts
265454210113	BUZZER UNIT	TATA spare parts
265454210121	ASSY.MAGNETIC REED SWITCH (JIS)	TATA spare parts
265454210135	ASY.ELEC.CONT UNIT(1:1.04	TATA spare parts
265454210138	CLUSTER 4X2 1:1:04	TATA spare parts
265454210148	RPM METER 0-6000	TATA spare parts
265454210152	FUEL & TEMP W/W PCB	TATA spare parts
265454210156	FUEL & TEMP W/W1 PCB	TATA spare parts
265454210158	SPEEDO MET.160 KM/H1:1.04	TATA spare parts
265454210164	ASSY.INST.CLUSTER [1:0.935]	TATA spare parts
265454400102	TAIL LAMP LH	TATA spare parts
265454400103	BLINKER LAMP LH	TATA spare parts
265454400104	BLINKER LAMP RH	TATA spare parts
265454400165	ENGINE LAMP	TATA spare parts
265454400174	HEAD LAMP LH RHD	TATA spare parts
265454400175	HEAD LAMP RH RHD	TATA spare parts
265454400199	FOG LAMP REAR NLS	TATA spare parts
265454406306	TAIL LAMP LENS L.H.	TATA spare parts
265454406307	TAIL LAMP LENS R.H.	TATA spare parts
265454406312	SPACER	TATA spare parts
265454407503	GASKET REAR FOG LAMP	TATA spare parts
265454409912	BULB BLINKER 21W 12V E CERT.	TATA spare parts
265454409914	LAMP 12V 10W R19/10-BA15 S CAP E MARK	TATA spare parts
265454409916	LAMP NLS 12V 5W	TATA spare parts
265454409922	REFLEX REFLECTOR RED`E`CER	TATA spare parts
265454410103	REGISTRATION PLATE LAMP	TATA spare parts
265454410104	LAMP REGISTRATION PLATE	TATA spare parts
265454410128	ROOF LAMP	TATA spare parts
265454410138	HEAD LAMP LH RHD	TATA spare parts
265454410161	TAIL LAMP RH	TATA spare parts
265454410194	ASSY.ENGINE LAMP	TATA spare parts
265454410195	ASSY.ENGINE LAMP	TATA spare parts
265454420101	ASSY.ENGINE LAMP	TATA spare parts
265454420106	BLINKER LAMP LH	TATA spare parts
265454420107	BLINKER LAMP RH	TATA spare parts
265454420108	SIDE IND LAMP LH	TATA spare parts
265454420109	SIDE IND LAMP RH	TATA spare parts
265454420110	TAIL LAMP LH-MSSL	TATA spare parts
265454420111	TAIL LAMP RH-MSSL	TATA spare parts
265454420112	ROOF LAMP W/`E` MARK BULB	TATA spare parts
265454420113	ASSY READING LAMP	TATA spare parts
265454420140	SIDE INDI LAMP LH-MS HARNESS	TATA spare parts
265454420141	SIDE INDI LAMP RH-MS HARNESS	TATA spare parts
265454420146	TAIL LAMP LH	TATA spare parts
265454420147	TAIL LAMP RH	TATA spare parts

265454420149	SIDE IND LAMP LH	TATA spare parts
265454420150	LAMP READING	TATA spare parts
265454420151	ROOF LAMP	TATA spare parts
265454420165	SIDE INDI.LAMP RH	TATA spare parts
265454420179	ASSY.HEAD LAMP LH LHD WITH BULB	TATA spare parts
265454420180	ASSY. HEAD LAMP RH LHD WITH BULB	TATA spare parts
265454420181	ASSY READING LAMP	TATA spare parts
265454420182	ROOF LAMP W/'E' MARK BULB	TATA spare parts
265454420191	TRAILER INDICATOR LAMP	TATA spare parts
265454420196	ROOF LAMP W/'E' MARK BULB	TATA spare parts
265454420197	ASSY.ENGINE LAMP	TATA spare parts
265454430108	HEAD LAMP RH RHD	TATA spare parts
265454430123	HEAD LAMP LH RHD	TATA spare parts
265454430124	HEAD LAMP RH RHD	TATA spare parts
265454430141	HEAD LAMP RH LHD	TATA spare parts
265454430143	ASSY.FOG LAMP (REAR)	TATA spare parts
265454430144	ASSLY FOG LAMP REAR	TATA spare parts
265454430145	SIDE INDICATOR LAMP LH	TATA spare parts
265454430146	SIDE INDICATOR LAMP RH	TATA spare parts
265454430148	ASSY.REG.PLATE LAMP	TATA spare parts
265454430156	KIT- SPARE BULB-H4-12V	TATA spare parts
265454430157	KIT FOR SPARE BULB	TATA spare parts
265454430159	REGISTRATION PLATE LAMP	TATA spare parts
265454500103	ASSY. CONTACT PLATE	TATA spare parts
265454500104	COMBI SWITCH RHD	TATA spare parts
265454500109	SWITCH REVERSE LIGHT	TATA spare parts
265454500110	MAIN LINE SWITCH	TATA spare parts
265454500111	2-SPEED BLOWER SWITCH	TATA spare parts
265454500121	COVER WITH KNOB ASSY.	TATA spare parts
265454500124	FLASHER KIT ROUND	TATA spare parts
265454500132	ASSY.COMBI SWITCH [RHD]	TATA spare parts
265454500134	ASSY.REVERSE LIGHT SWITCH	TATA spare parts
265454500135	COMBI SWITCH LHD	TATA spare parts
265454500139	OIL PRESSURE SWITCH	TATA spare parts
265454500145	ASSY.REVERSE LIGHT SWITCH	TATA spare parts
265454500184	COMBI SWITCH RHD	TATA spare parts
265454500186	SWITCH PARKING BRAKE	TATA spare parts
265454506305	FUSE BOX COVER	TATA spare parts
265454506901	PIANO SWITCH	TATA spare parts
265454506902	PIANO KEY SWITCH ( BLANK )	TATA spare parts
265454506904	PIANO SWITCH BR FAIL IND	TATA spare parts
265454506905	PIANO SWITCH RR FOG LAMP	TATA spare parts
265454506912	PIANO KEY SWITCH ( BLANK )	TATA spare parts
265454506913	PIANO SWITCH INST ILLUMIN	TATA spare parts
265454506917	PIANO SW.W/O.CONN.BLACK (R.F.LAMP)	TATA spare parts
265454506918	PIANO SW 2 SPEED BLOWER	TATA spare parts
265454506919	PIANO SW 2 SPEED BLOWER	TATA spare parts

265454506920	PIANO KEY SW.W/O CONN.[I.ILL]	TATA spare parts
265454506927	PIANO SW 2 SPEED BLOWER	TATA spare parts
265454506928	PIANO SW 2 SPEED BLOWER	TATA spare parts
265454506929	PIANO SW 2 SPEED BLOWER	TATA spare parts
265454506930	PIANO SW 2 SPEED BLOWER	TATA spare parts
265454506931	PIANO KEY SWITCH	TATA spare parts
265454506932	PIANO KEY SWITCH ( BLANK )	TATA spare parts
265454506933	2-SPEED BLOWER SWITCH	TATA spare parts
265454509908	FUSE LINK 15 AMP	TATA spare parts
265454509909	SWITCH REVERSE LIGHT	TATA spare parts
265454509913	LOW OIL PRESSURE SWITCH BS1/2/3/4/6	TATA spare parts
265454509914	LOW OIL PRESSURE SWITCH	TATA spare parts
265454509916	CONNECTOR FEMALE 2 POLE	TATA spare parts
265454509924	ELECTRONIC FLASHER W/O MTG BKT [O.DRG]	TATA spare parts
265454509924AE	ELEC FLASHER W/O MTG BK XENON	TATA spare parts
265454509927	FLASHER KIT	TATA spare parts
265454510106	ASSY.COMBI.SWITCH	TATA spare parts
265454510108	LOW OIL PRESSURE SWITCH .	TATA spare parts
265454510109	COMBI SWITCH LHD FOR M.S.HARNESS	TATA spare parts
265454510110	SWITCH REVERSE LIGHT	TATA spare parts
265454510112	COMBI SWITCH RHD	TATA spare parts
265454510113	DOOR SWITCH	TATA spare parts
265454510118	COMBI SWITCH RHD	TATA spare parts
265454510119	COMBI SWITCH RHD BS2/3/4	TATA spare parts
265454510120	ASSY. COMBI SWITCH(M.S.HARNESS) BS1/2	TATA spare parts
265454510121	FLASHER SQ.12V WITH BKT	TATA spare parts
265454510123	ASSY REV LT SW P/TAIL MS HARNESS	TATA spare parts
265454510127	COMBI SWITCH RHD	TATA spare parts
265454510128	ASSY COMBI SWITCH (LHD)-	TATA spare parts
265454510131	REVERSE-LIGHT SWITCH	TATA spare parts
265454510151	COMBI SWITCH RHD	TATA spare parts
265454510152	DOOR SWITCH W/PIGTAIL	TATA spare parts
265454510153	COMBI SWITCH RHD	TATA spare parts
265454510154	ASSY.COMBI SWITCH LHD	TATA spare parts
265454510155	ASSY. COMBI SWITCH RHD	TATA spare parts
265454510156	SWITCH REVERSE LIGHT	TATA spare parts
265454510157	DOOR SWITCH	TATA spare parts
265454510159	ASSY.REVERSE LIGHT SWITCH	TATA spare parts
265454510161	SWITCH REVERSE LIGHT	TATA spare parts
265454510162	DOOR SWITCH	TATA spare parts
265454510163	SWITCH REVERSE LIGHT	TATA spare parts
265454510164	REVERSE LIGHT SWITCH	TATA spare parts
265454510165	IC.FLASHER.W/MTG.BKT.W/O.CONN.	TATA spare parts
265454510169	FOG LAMP SWITCH-DOUBLE POLE	TATA spare parts
265454510177	2-SPEED BLOWER SWITCH	TATA spare parts
265454600113	MAIN CABLE SET RHD	TATA spare parts
265454600165	W/H TAIL	TATA spare parts

265454600166	W/H ROOF	TATA spare parts
265454600169	CONT HSG CABLE	TATA spare parts
265454600179	W/H CONTROL HSG W/O PCB	TATA spare parts
265454600183	W/H ENGINE	TATA spare parts
265454600184	FUSIBLE LINK ASSY	TATA spare parts
265454604301	CLIP SMALL	TATA spare parts
265454607504	PVC CAP (STARTER TERMINALS)	TATA spare parts
265454608201	CABLE CONNECTOR	TATA spare parts
265454609801	CONNECTOR FEMALE 8 POLE	TATA spare parts
265454609917	COATED CLAMP LARGE	TATA spare parts
265454609919	SLEEVE ADAPTOR FOR HEAD LAMP	TATA spare parts
265454610112	W/H CABIN RHD	TATA spare parts
265454610113	W/H FRONT RHD	TATA spare parts
265454610117	W/H CONTROL HSG-NLS-0148	TATA spare parts
265454610118	W/H CONTROL HSG W/O PCB	TATA spare parts
265454610119	W/H TAIL RHD	TATA spare parts
265454610157	ASSY.A/C CABLE SET-II(MOBILE)	TATA spare parts
265454610161	W/H FRONT RHD	TATA spare parts
265454620123	WIRING HARNESS MAIN	TATA spare parts
265454620124	WIRING HARNESS TAIL	TATA spare parts
265454620125	WIRING HARNESS ENGINE	TATA spare parts
265454620129	WIRING HARNESS ROOF	TATA spare parts
265454620130	WIRING HARNESS ROOF	TATA spare parts
265454620148	W/H CONTROL HSG AC+HTG	TATA spare parts
265454620161	WIRING HARNESS MAIN BHARAT-II	TATA spare parts
265454620162	WIRING HARNESS ENGINE BHARAT-II	TATA spare parts
265454620164	WIRING HARNESS TAIL-4SP	TATA spare parts
265454620165	WIRING HARNESS ENGINE 4SP	TATA spare parts
265454620167	WIRING HARNESS ROOF	TATA spare parts
265454620169	WIRING HARNESS 2-SPEED BLOWER	TATA spare parts
265454620170	WIRING HARNESS EGR CTRL BHARAT-II	TATA spare parts
265454620173	WIRING HARNESS EGR CTRL BHARAT-II	TATA spare parts
265454700114	BLOWER SWITCH	TATA spare parts
265454700129	ASSY.THERMOAMP W/POT&MTG.BKT	TATA spare parts
265454700151	ASSY BLOWER SWITCH	TATA spare parts
265454700155	ASSY BLOWER SWITCH	TATA spare parts
265454700156	BLOWER MOTOR W/FAN RIS 2S	TATA spare parts
265454700158	BLOWER MOTOR W/FAN 2SPEED	TATA spare parts
265454700159	ASSY BLOWER SWITCH	TATA spare parts
265454706303	BLOWER FAN	TATA spare parts
265454709901	LOW SPEED RESISTOR 1 OHM	TATA spare parts
265454709902	LOW SPEED RESISTOR 0.6 OH	TATA spare parts
265454709904	FAN BLOWER LHD	TATA spare parts
265454709906	RESISTOR WITH 3-POLE CONN	TATA spare parts
265454807503	COVER-ANTENNA MOUNTING HOLE-RH.	TATA spare parts
265454809907	ANTENNA RHD SRICH	TATA spare parts
265454809908	ANTENNA LHD SRICH	TATA spare parts



265454900106	KIT-CENTRAL LOCKING	TATA spare parts
265454900107	KIT CENTRAL LOCKING	TATA spare parts
265454900108	KIT-CENTRAL LOCKING	TATA spare parts
265458408202	TYPE & CHASSIS NO. PLATE	TATA spare parts
265458408204	TYPE & CHASSIS NUMBER PLATE	TATA spare parts
265458409905	TRANSFER LABEL (VEHICLE JACKING POINT)	TATA spare parts
265458409908	TRANSFER LABEL - JACKING INSTRUCTIONS	TATA spare parts
265458409916	TRANS.LBL-NON PETRO.BASE BRK.FLD.	TATA spare parts
265458505801	CHASSIS RECORD BAG	TATA spare parts
265458604001	CLAMP-JACK HANDLE	TATA spare parts
265458900101	ADAPTER ENG COMPR CHECK	TATA spare parts
265458900102	DRIFT LINER INSTALLATION	TATA spare parts
265458900103	DRIFT LINER REMOVAL	TATA spare parts
265458900107	ASSY.TOOL KIT - DOMESTIC 207 FAMILY	TATA spare parts
265458900108	ASSY. TOOL KIT - 207 FAMILY	TATA spare parts
265458900110	TOOL KIT - 207 DI DOMESTIC	TATA spare parts
265458900111	ASSY. TOOL KIT - 207DI EXPORT	TATA spare parts
265458900301	FLYWHEEL LOCKING PIN - 483 DL ENGINE	TATA spare parts
265458900302	SPANNER CRANKSHAFT	TATA spare parts
265458900303	DRIFT CR SHAFT FR OILSEAL	TATA spare parts
265458900304	DRIFT CR SHAFT RR OILSEAL	TATA spare parts
265458900305	PULLER CRANK SHAFT GEAR	TATA spare parts
265458900306	PULLER CR SHAFT SPIG BRG	TATA spare parts
265458900307	FLYWHEEL LOCKING PIN - 483 DL ENGINE	TATA spare parts
265458900308	LOCATING PIN CYL HEAD	TATA spare parts
265458900309	FLYWHEEL LOCKING PIN - 483 DL ENGINE	TATA spare parts
265458900310	FLYWHEEL LOCKING PIN - 483 DL ENGINE	TATA spare parts
265458900501	SPANNER CAMSHAFT & FIP GR	TATA spare parts
265458900502	BOLT CAMSHAFT & FIP GEAR	TATA spare parts
265458900502N	M8-60L BOLT / REF.265458900503/CAM-FIP G	TATA spare parts
265458900504	DRIFT VALVE GUIDE	TATA spare parts
265458900505	SPACER FOR 0504 DRIFT	TATA spare parts
265458900506	SUPPORT RAIL	TATA spare parts
265458900507	VALVE SPRING COMPRESSOR	TATA spare parts
265458900508	DRIFT CAMSHAFT OIL SEAL	TATA spare parts
265458900509	ADAPTER FIP TIMING	TATA spare parts
265458900510	DR SQUARE TMG BELT TENSER	TATA spare parts
265458900601	TIMING ROD FIP	TATA spare parts
265458900602	TIMING BKT STRAIGHT	TATA spare parts
265458900603	TIMING BKT CRANKED	TATA spare parts
265458900604	EXTENSIONROD FIP TIMING	TATA spare parts
265458900605	SPANNER-Holding Camshaft/FIP Gear-4DLeng	TATA spare parts
265458900701	GAUGE ROD PISTON TDC	TATA spare parts
265458901401	SPANNER INLET MANIFOLD	TATA spare parts
265458901801	SPANNER FOR OIL FILTER- 483 DL	TATA spare parts
265458902401	SET ENGINE MTG BRACKETS	TATA spare parts
265458902501	MANDREL CLUTCH PLATE	TATA spare parts

265458902601	MOUNTING PLATE GBS-16	TATA spare parts
265458902602	PULLER	TATA spare parts
265458902603	SLEEVE	TATA spare parts
265458902604	PULLER	TATA spare parts
265458902605	DRIFT	TATA spare parts
265458902606	DRIFT	TATA spare parts
265458902607	DRIFT	TATA spare parts
265458902608	CHECKING GUAGE	TATA spare parts
265458902609	PULLER FOR REMOVAL OF FRONT HALF	TATA spare parts
265458902610	FLANGE DRIVESHAFT FITMENT	TATA spare parts
265458902611	PULLER DRIVESHAFT FITMENT	TATA spare parts
265458902612	PULLER M/S & D/S T R BRGS	TATA spare parts
265458902613	MOUNTING PLATE	TATA spare parts
265458903201	PULLER	TATA spare parts
265458903202	FIXTURE COIL SPRING	TATA spare parts
265458903203	MANDREL	TATA spare parts
265458903205	PULLER	TATA spare parts
265458903301	PULLER FRONT HUB	TATA spare parts
265458903302	ROCKER	TATA spare parts
265458903303	ROCKER	TATA spare parts
265458903304	PULLER FOR TIE ROD BALL JOINT	TATA spare parts
265458903305	DRIFT LOWER BALL JOINT	TATA spare parts
265458903501	DIFFL HOUSING SPREADER	TATA spare parts
265458903502	FIXTURE TAIL PINION	TATA spare parts
265458903503	DRIFT	TATA spare parts
265458903504	DRIFT	TATA spare parts
265458903505	SPANNER GROOVED LOCK NUT	TATA spare parts
265458903506	CHECK DEVICE T P DEPTH	TATA spare parts
265458903507	DRIFT	TATA spare parts
265458903508	PULLER DIFFL SIDE BEARING *	TATA spare parts
265458903510	ROCKER	TATA spare parts
265458903511	HOLDER MAINSHAFT COUPLING FLANGE	TATA spare parts
265458903513	MANDREL	TATA spare parts
265458903515	SPECIAL SCREW SET	TATA spare parts
265458903516	DRIFT	TATA spare parts
265458903517	THRUST PIECE 35 08 PULLER	TATA spare parts
265458903519	CLAMP CWP RUN OUT CHECK	TATA spare parts
265458903520	ADAPTER STAND REAR AXLE	TATA spare parts
265458903521	PULLER BRG CASE REMOVAL	TATA spare parts
265458903522	IMPACT PULLER	TATA spare parts
265458903523	DRIFT OIL SEAL INSTALL	TATA spare parts
265458903524	DRIVE SQUARE - FOR REAR AXLE ONLY	TATA spare parts
265458904001	WHEEL SPANNER 19 A/F	TATA spare parts
265458904009	SPANNER-SPARE WHEEL CARRIER (TM 4SP Eng)	TATA spare parts
265458904101	DRIFT	TATA spare parts
265458904102	SLEEVE / PROP SHAFT CENTRE BRG / 206	TATA spare parts
265458904602	WRENCH	TATA spare parts

265458904603	DRIFT	TATA spare parts
265458904604	PULLER STEERING WHEEL	TATA spare parts
265458904605	PULLER STRG GR BOX 22.5:1	TATA spare parts
265460000103	BODY SHELL WITH DOORS-TATA MOBILE	TATA spare parts
265460000104	CAB COMPLT	TATA spare parts
265460000104BF	TM RHD 4X2 NA BEN NOR	TATA spare parts
265460010160B6	ASSY.BODY SHELL COMPLETE PAINTED-RHD	TATA spare parts
265460020181	CAB COMPL 207 DI SINGLE CAB	TATA spare parts
265460020181BF	CAB COMPL 207 DI SINGLE CAB	TATA spare parts
265460020181BN	CAB COMPL 207 DI SINGLE CAB	TATA spare parts
265460020182	BARE CAB 207 DI SINGLE CAB	TATA spare parts
265460020182BF	BODY SHELL COMPLETE PAINTED RHD WHITE	TATA spare parts
265460020182BL	ASSY.BODY SHELL COMPLETE PAINTED RHD	TATA spare parts
265460020182BN	BODY SHELL COMPLETE PAINTED RHD RUBY RED	TATA spare parts
265460020182BS	BODY SHELL COMPL. PAINTED RHD SOLID GREE	TATA spare parts
265460020182FG	ASSY.BODYSHELLCOMPLETEPAINTEDRHD_MINER	TATA spare parts
265460100105	TIE MEMBER COMPLT	TATA spare parts
265460100115	ASSY.DB X MEMBER W/SIDE SUPP.COM.RHD	TATA spare parts
265460100134	ASSY.SHOTGUN RH	TATA spare parts
265460100186	TIE MEMBER ASSY	TATA spare parts
265460100189	TIE MEMBER COMPLT	TATA spare parts
265460100191	TIE MEMBER COMPLT	TATA spare parts
265460100199	TIE MEMBER COMPLT	TATA spare parts
265460108201	PANEL FRONT HEAD LAMP	TATA spare parts
265460110111	SHOTGUN ASSY.LH	TATA spare parts
265460110113	ASSY.PANEL FRONT (HEAD LAMP)	TATA spare parts
265460110114	ASSY TIE MEMBER COMPLETE	TATA spare parts
265460110118	ASSY SUPPORT BRACKET(BATTERY MTG.)RHD	TATA spare parts
265460118203	REINF LH SIDE BONNET	TATA spare parts
265460118204	REINF RH SIDE BONNET	TATA spare parts
265460118250	REINFORCEMENT (D/P FRAME-S/B INNER)	TATA spare parts
265460118251	REINFORCEMENT RH(D/P FRAME-S/B INNER)	TATA spare parts
265460600101	PANEL INNER TOP W/S	TATA spare parts
265460600120	ASSY. MUDGUARD FRT. LH	TATA spare parts
265460600132	MUDGUARD FRONT RH	TATA spare parts
265460600133	BRACKET W/S WASH.BOTTLE	TATA spare parts
26546060013420	ASSY PNL INR BNT SIDE WITH NUT & SUPPORT	TATA spare parts
26546060013520	ASSY PNL INR BNT SD RH WITH NUT & SUPORT	TATA spare parts
265460600136	ASSY MUDGUARD FRONT LH	TATA spare parts
265460600137	ASSY MUDGUARD FRONT RH	TATA spare parts
265460600140	REINF.ASSY.LH(BONNET SIDE INNER PANEL)	TATA spare parts
265460600141	ASSY MUDGUARD FRONT LH 207DI BS II	TATA spare parts
26546060014220	PANEL INNER SIDE BONNET LH	TATA spare parts
265460600194	ASSY REINFORCEMENT	TATA spare parts
265460600195	ASSY MUDGUARD FRONT LH	TATA spare parts
265460603301	BRACKET L.H.(SIDE BONNET BOLTING)	TATA spare parts
265460603302	BRACKET R.H.(SIDE BONNET BOLTING )	TATA spare parts

265460608205	PANEL INNER TOP W/SHIELD	TATA spare parts
265460608221	REINF MUDGUARD RH	TATA spare parts
265460608225	PANEL INNER BONNET LH	TATA spare parts
265460608235	MUDGUARD FRONT RH	TATA spare parts
265460608236	PANEL INNER SIDE BONNET LH	TATA spare parts
265460608237	PANEL INNER SIDE BONNET RH	TATA spare parts
265461000171	SUB-STRUCTURE WITH FLOOR ASSY.COMPLT RHD	TATA spare parts
265461608263	SPACER PLATE (TOOL BAG BRKT.MTG.)	TATA spare parts
265462500101	ASSY.W/S PANEL OUTER BOTTOM RHD	TATA spare parts
265462500102	ASSY W/S PANEL OUTER BOTTOM LHD	TATA spare parts
265462508201	PANEL W/S OUTER BOTTOM	TATA spare parts
265462600105	ASSY.SUPPORT PANEL W/S.RHD	TATA spare parts
265463000107	ASSY SIDE WALL LH LHD	TATA spare parts
265463000108	ASSY SIDE WALL RH LHD	TATA spare parts
265463000112	ASSY.SIDE WALL LH	TATA spare parts
265463000113	ASSY.SIDE WALL RH	TATA spare parts
265463100106	ASSY.REINFORCEMENT STRIKER BS6	TATA spare parts
265463100108	ASSY. REINF. FRONT POST	TATA spare parts
265463100121	REINF HINGE LH	TATA spare parts
265463100122	REINF HINGE RH	TATA spare parts
265463108202	DOOR POST FRAME LH RHD	TATA spare parts
26546310820220	DOOR POST FRAME LH RHD	TATA spare parts
265463108203	DOOR POST FRAME R.H.	TATA spare parts
26546310820320	DOOR POST FRAME RH (RHD)	TATA spare parts
265463108244	DOOR POST FRAME RH (RHD)	TATA spare parts
265463108245	DOOR POST FRAME L.H.[LHD]	TATA spare parts
265463108257	DOOR POST FRAME LH RHD	TATA spare parts
265463108258	DOOR POST FRAME RH RHD	TATA spare parts
265463108259	DOOR POST FRAME-RH.[LHD]	TATA spare parts
265463108260	DOOR POST FRAME-LH.[LHD]	TATA spare parts
265463108272	BRACKET-DOOR CHECK	TATA spare parts
26546310C259	DOOR POST FRAME RH - LHD	TATA spare parts
26546310C260	DOOR POST FRAME LH - LHD	TATA spare parts
265463600112	ASSY.PANEL INNER CORNER [R/W] L.H.	TATA spare parts
265463600113	ASSY.PANEL INNER CORNER [R/W] R.H.	TATA spare parts
265463600124	ASSY.PANEL POST SIDE LH	TATA spare parts
265463600125	ASSY.PANEL POST SIDE RH	TATA spare parts
265463608204	PANEL POST SIDE LH	TATA spare parts
265463608205	PANEL POST SIDE RH	TATA spare parts
265463608217	PANEL SIDE W/S INNER LH	TATA spare parts
265463608218	PANEL SIDE W/S INNER RH	TATA spare parts
265463608225	PANEL INNER CORNER REAR WALL L.H.	TATA spare parts
265463608226	PANEL INNER CORNER REAR WALL R.H.	TATA spare parts
265463608227	TOP RAIL SIDE LH	TATA spare parts
265463608228	TOP RAIL SIDE RH	TATA spare parts
265463708213	PANEL OUTER CORNER L.H.	TATA spare parts
265463708214	PANEL OUTER CORNER R.H.	TATA spare parts

265463708215	PANEL OUTER CORNER LH R/W SIDE	TATA spare parts
265463708216	PANEL OUTER CORNER RH R/W SIDE	TATA spare parts
265464600103	ASSY PANEL INNER CENTRE TOP (R/WALL)	TATA spare parts
265464600104	ASSY PANEL INNER CENTER BOTTOM (R/WALL)	TATA spare parts
265464608206	PANEL INN CEN TOP RR WALL	TATA spare parts
265464608208	TOP RAIL CORNER RR LH	TATA spare parts
265464608209	TOP RAIL CORNER RR RH	TATA spare parts
265464608210	PANEL INN.CENTRE BOTTOM	TATA spare parts
265464708203	PANEL CENTRE(REAR WALL)	TATA spare parts
265465700101	ROOF PANEL	TATA spare parts
265465706704	PIN END CAP ROOF BEADING	TATA spare parts
265465708202	ROOF PANEL	TATA spare parts
265467102301	W/S GLASS	TATA spare parts
265467102302	WINDSHIELD GLASS BS1/2/3/4	TATA spare parts
265467106301	RUBBER MOULD W/S GLASS	TATA spare parts
265467106303	RUBBER MOULD RR WINDOW	TATA spare parts
265467106305	RUB MOULD W/S GLASS 6.5MM	TATA spare parts
265467802301	GLASS REAR WINDOW	TATA spare parts
265467802302	FIXED TINTED GLASS-LIGHT GREEN-R/WINDOW	TATA spare parts
265467802305	GLASS REAR WINDOW	TATA spare parts
265467802306	GLASS REAR WINDOW HEATING	TATA spare parts
265468306301	BASE PLATE GSL TOP BELLOW	TATA spare parts
265468800155	ASSY.KIT FLOOR MAT-RHD	TATA spare parts
265468800175	ASSY KIT FLOOR MAT(RHD)	TATA spare parts
265468800176	ASSY KIT FLOOR MAT RHD(BUCKT)	TATA spare parts
265468806308	FLOOR MAT	TATA spare parts
265468806385	NOISE INSULATION (F/WALL & FLOOR) RHD	TATA spare parts
265468806390	NOISE INSULATION (FIRE WALL) RHD	TATA spare parts
265468900116	BKT VENTILATION CONTROL	TATA spare parts
265468900117	LINK PLENUM RHD	TATA spare parts
265468900121	GLOVE BOX COMPLETE BLACK	TATA spare parts
265468900122	INSTRUMENT SHROUD	TATA spare parts
265468900125	ASSY. VENTILATION NOZZLE	TATA spare parts
265468900125AE	ASSY. VENTILATION NOZZLE	TATA spare parts
265468900126	DASH BOARD COMPLT	TATA spare parts
265468900132	BKT LH PLENUM CHAMBER MTG	TATA spare parts
265468900133	BKT RH PLENUM CHAMBER MTG	TATA spare parts
265468900135	ASSY.GLOVE BOX LOCK	TATA spare parts
265468900136	FOAM PACKING STIFFNER	TATA spare parts
265468900164	SUPPORT GLOVE BOX	TATA spare parts
265468900167	ASSY.GLOVE BOX LOCK	TATA spare parts
265468900169	REINF PLASTIC DASHBOARD	TATA spare parts
265468900170	ASSY.MOUNTING BRACKET (DRIVER SIDE).	TATA spare parts
265468900172	ASSY.MTG.BRACKET (GLOVE BOX SIDE).	TATA spare parts
265468900173	VENTILATION NOZZLE FRONT	TATA spare parts
265468900174	ASSY.MOUNTING BRACKET(DRIVER SIDE HVAC)	TATA spare parts
265468900175	BKT D/B GLOVE BOX SIDE	TATA spare parts

265468900176	STIFFNER ASSY	TATA spare parts
265468900189	ASH TRAY ASSY	TATA spare parts
265468900196	ASSY.CONTROL BRACKET - A.C.+ HEATER	TATA spare parts
265468906305	NACELLE BOTTOM	TATA spare parts
265468906308	DASH BOARD RHD	TATA spare parts
265468906309	COVER RADIO	TATA spare parts
265468906310	SHROUD VENT CONTROL	TATA spare parts
265468906316	COVER SPEAKER APPERTURE	TATA spare parts
265468906319	HOSE MOUNTING CLIP	TATA spare parts
265468906321	FOAM PACKING [REINF.PLASTIC DASH BOARD]	TATA spare parts
265468906334	SCREW CAP LH	TATA spare parts
265468906335	SCREW CAP RH	TATA spare parts
265468906341	RUBBER SPACER	TATA spare parts
265468906345	GARNISH MIDDLE DEFROST	TATA spare parts
265468906350	CONSOLE FRONT	TATA spare parts
265468906360	COVER - FOR MAP READING CUTOUT	TATA spare parts
265468906371	COVER (A/C CONTROL PANEL)	TATA spare parts
265468906372	COVER-CLOCK CUT OUT DARK GRAY	TATA spare parts
265468906373	COVER (DUMMY) AUTO WINDING SWITCH	TATA spare parts
265468906375	COVER FRONT DARK GREY	TATA spare parts
265468906376	DASH BOARD RHD	TATA spare parts
265468906380	SCREW CAP LH DARK GREY	TATA spare parts
265468906381	SCREW CAP RH DARK GREY	TATA spare parts
265468906393	COVER FRONT-DARK GRAY (SOFT FEEL)	TATA spare parts
265468906395	DASH BOARD RHD - DARK GRAY	TATA spare parts
265468906398	FOAM	TATA spare parts
265468906399	COVER(VENT CONTROL CUT-OUT)	TATA spare parts
265468906501	RD CSK SCREW M6X22	TATA spare parts
265468906502	SLCH SCREW M6X22	TATA spare parts
265468906503	SL CSK SCREW M6X35	TATA spare parts
265468907503	GROMMET (PLENUM CHAMBER FLAP)	TATA spare parts
265468908222	RETAINER	TATA spare parts
265468908250	SUPPORT(DEFROST NOZZLE)-R.H.	TATA spare parts
265468908251	SUPPORT (DEFROST NOZZLE)-L.H.	TATA spare parts
265468910129	ASSY.MOUNTING BRACKET CENTRE DASH BOARD	TATA spare parts
265468910134	ASSY.INSTRUMENT SHROUD-DARK GREY	TATA spare parts
265468910137	ASSY GLOVE BOX COMPLT-DARK GRAY	TATA spare parts
265468910149	ASSY.GLOVE BOX COMPT.DARK GRAY(SOFT FEEL	TATA spare parts
265468910151	ASSY.INSTRUMENT SHROUD D/G (SOFT FEEL)	TATA spare parts
265469106301	COVER -LH	TATA spare parts
265469106302	COVER-RH	TATA spare parts
265469500117	KIT ASSY.ROOF & INSIDE LINING.	TATA spare parts
265469500121	KIT ASSY.ROOF & INSIDE LINING	TATA spare parts
265469504301	SPRING CLIP INNER LINING	TATA spare parts
265469506309	PADDING RR WALL CENTRE	TATA spare parts
265469506381	MOULDED ROOF LINING	TATA spare parts
265469506382	ASSY.REAR WALL PADDING GRAY(W-H/B CUTOUT	TATA spare parts

265470000102	LOAD BODY W/O FITMENT	TATA spare parts
265470000103	MUD FLAP LOAD BODY	TATA spare parts
265470000117BF	ASSY.L. BODY COMPL. PAINTED ARCTIC WHITE	TATA spare parts
265470000117BN	LOAD BODY COMP. RUBY RED PAINTED	TATA spare parts
265470000117BS	LOAD BODY COMP. SOLID GREEN PAINTED	TATA spare parts
265470000119	FUEL LID LOCK	TATA spare parts
265470000129	ASSY LOAD BODY COMPLETE PAINTED RHD	TATA spare parts
265470000129BF	ASSY LOAD BODY COMPLETE PAINTED RHD	TATA spare parts
265470000129BL	LOAD BODY COMP. N. BLUE PAINTED	TATA spare parts
265470000129BN	TM LB RHD-AZADIRUBY RED-PAINTED	TATA spare parts
265470000129BS	LOAD BODY COMP. SOLID GREEN PAINTED	TATA spare parts
265470000129CN	ASSY.LOAD BODY COMPLETE PAINTED CREAM	TATA spare parts
265470000137	ASSY.TELCOLINE MASCOT	TATA spare parts
265470000149BF	ASSY LOAD BODY COMPLETE PAINTED RHD	TATA spare parts
265470000156	ASSY.L/BODY COMPLT.S/W 2825WB	TATA spare parts
265470000157	ASSY.LOAD BODY-SINGLE WALL	TATA spare parts
265470000158	ASSY.LOAD BODY(SINGLE/WALL)T/M 28WB	TATA spare parts
265470000159	ASSY.L/BODY(SINGLE WALL)-T/M 3150WB	TATA spare parts
265470000160	ASSY.L/BODY(SINGLE WALL)T/M 3150WB	TATA spare parts
265470000186	ASSY TELCOLINE MASCOT(CUR/CONN)	TATA spare parts
265470000187	ASSY.TATA TLMASCOT	TATA spare parts
265470006304	PLASTIC COVER CAP	TATA spare parts
265470006305	MUDGUARD LINER LH	TATA spare parts
265470006307	RUB RAIL LOAD BODY FRT LH	TATA spare parts
265470006308	RUB RAIL LOAD BODY FRT RH	TATA spare parts
265470006309	RUB RAIL LOAD BODY RR LH	TATA spare parts
265470006310	RUB RAIL LOAD BODY RR RH	TATA spare parts
265470006313	PLASTIC COVER	TATA spare parts
265470006315	MUDGUARD LINER RH RR	TATA spare parts
265470006322	FENDER EXTENSION LH-NON STYLI.L/B REAR	TATA spare parts
265470006323	FENDER EXTENSION RH-NON STYLI.L/B REAR	TATA spare parts
265470006324	PLUG BUTTON	TATA spare parts
265470006325	STICKER TATA (TAILGATE) BLACK COLOUR	TATA spare parts
265470006901	STAY TUBE FRONT LH	TATA spare parts
265470006902	STAY TUBE FRONT RH	TATA spare parts
265470006903	STAY TUBE REAR LH	TATA spare parts
265470006904	STAY TUBE REAR RH	TATA spare parts
265470100124	ASSY BRACKET (LINER INNER MTG)	TATA spare parts
265470100137	ASSY.PANEL REAR LHD.	TATA spare parts
265470108208	FLOOR PANEL	TATA spare parts
265470108209	WHEEL ARCH PANEL	TATA spare parts
265470108223	PANEL REAR RHD	TATA spare parts
265470108226	BRACKET	TATA spare parts
265470209201	NYLON WASHER	TATA spare parts
265470209202	WASHER	TATA spare parts
265470300103	CORNER PANEL INNER RR LH	TATA spare parts
265470300104	CORNER PANEL INNER RR RH	TATA spare parts

265470300108	SIDE WALL ASSY LH	TATA spare parts
265470300109	SIDE WALL ASSY RH	TATA spare parts
265470300124	HOUSING COMPLETE	TATA spare parts
265470300128	LID FUEL FILLING	TATA spare parts
265470300134	HOOK LH	TATA spare parts
265470300135	HOOK RH	TATA spare parts
265470300136	LOAD GUARD	TATA spare parts
265470300137	LADDER RACK STOPPER	TATA spare parts
265470300182	ASSY.NUT PLATE	TATA spare parts
265470300196	ASSY.BRACKET BS6-PH2	TATA spare parts
265470303401	BUSH	TATA spare parts
265470304201	CLAMP	TATA spare parts
265470306304	STYLING STRIP(SIDE) FRONT	TATA spare parts
265470306306	STYLING STRIP(SIDE) FRONT	TATA spare parts
265470306308	STYLING STRIP(SIDE) REAR	TATA spare parts
265470306310	STYLING STRIP TAIL GATE	TATA spare parts
265470306701	THREADED PIN	TATA spare parts
265470307501	RUBBER CAP	TATA spare parts
265470308201	CORNER PANEL INNER FRT LH	TATA spare parts
265470308205	PANEL INN LH RR WALL HSG	TATA spare parts
265470308206	PANEL INN RH RR WALL HSG	TATA spare parts
265470308214	CORNER PANEL INNER RR LH	TATA spare parts
265470308215	CORNER PANEL INNER RR RH	TATA spare parts
265470309201	WASHER (LOAD GUARD MTG.)	TATA spare parts
265470309202	WASHER	TATA spare parts
265470400118	PLUNGER COMPLETE	TATA spare parts
265470400122	STRIKER ASSY	TATA spare parts
265470400123	HINGE TAIL GATE	TATA spare parts
265470400124	PULL ROD	TATA spare parts
265470400125	ASSY ROPE LH	TATA spare parts
265470400130	TAIL GATE SHELL	TATA spare parts
265470400131	TAIL GATE ASSY	TATA spare parts
265470400133	ASSY ROPE RH	TATA spare parts
265470400142	STAY LINK LH LOAD BODY	TATA spare parts
265470400143	STAY LINK RH LOAD BODY	TATA spare parts
265470400146	CORNER BUMPER RR LH	TATA spare parts
265470400147	CORNER BUMPER RR RH	TATA spare parts
265470400148	CEN LATCH W/O HANDLE T/G	TATA spare parts
265470400158	FOOT REST COMP LOAD BODY	TATA spare parts
265470400162	ASSY CORNER BUMPER LH-GREY	TATA spare parts
265470400163	ASSY CORNER BUMPER RH-GREY	TATA spare parts
265470400167	ASSY.CHAIN WITH SLEEVE	TATA spare parts
265470400169	ASSY.TAIL GATE COMPLT.	TATA spare parts
265470405602	HANDLE CEN LATCH T/G	TATA spare parts
265470406002	HOOK PULL ROD	TATA spare parts
265470406303	COVER	TATA spare parts
265470406306	COVER(T/G INNER PANEL CUTOUT)	TATA spare parts



265470408221	STRIKING STRAP	TATA spare parts
265470408603	SPACER OUTER	TATA spare parts
26547040P118	ASSY.PLUNGER COMPLETE DACROMETED	TATA spare parts
26547040P125	ASSY.ROPE LH DACROTISED	TATA spare parts
26547040P133	ASSY.ROPE RH DACROTISED	TATA spare parts
26547040Z130	ASSY. TAIL GATE SHELL	TATA spare parts
265470500112	STRUCTURE SOFT TOP	TATA spare parts
265470500117	GUARD ASSY RH	TATA spare parts
265470500118	GUARD ASSY LH	TATA spare parts
265470500119	SOFT CANOPY PASS VERSION	TATA spare parts
265470500132	ASSY.CANVAS CANOPY	TATA spare parts
265470506304	SPACER	TATA spare parts
265470506307	REFLECTIVE TAPE	TATA spare parts
265470506308	REFLECTIVE TAPE	TATA spare parts
265470800109	BOLT W/NYLOC INSERT L/B M	TATA spare parts
265470800110	ASSY.BOLT WITH NYLON INSERT	TATA spare parts
265470808601	SPACER	TATA spare parts
265470808602	SPACER	TATA spare parts
265470808603	SPACER(LOAD BODY MTG - 207DI)	TATA spare parts
265470809201	WASHER LOAD BODY MTG	TATA spare parts
265470809203	WASHER	TATA spare parts
265470900102	ASSY.PACKING	TATA spare parts
265470900103	ASSY.PACKING	TATA spare parts
265472000142	ASSY DOOR COMPLETE LH	TATA spare parts
265472000143	ASSY DOOR COMPLETE RH	TATA spare parts
265472200103	DOOR SHELL LH	TATA spare parts
265472200104	DOOR SHELL RH	TATA spare parts
265472200114	GUIDE CHANNEL LH DR GLASS	TATA spare parts
265472200115	GUIDE CHANNEL RH DR GLASS	TATA spare parts
265472200130	DOOR SHELL LH	TATA spare parts
265472200131	DOOR SHELL RH	TATA spare parts
265472206304	REINFORCEMENT PAD LH	TATA spare parts
265472206305	REINFORCEMENT PAD RH	TATA spare parts
265472208237	REIUF. DOOR LH	TATA spare parts
265472208238	REIUF. DOOR RH	TATA spare parts
265472300103	DOOR LOCK RH	TATA spare parts
265472300104	DOOR LOCK LH	TATA spare parts
265472300113	DOOR STRIKER	TATA spare parts
265472300124	ASSY. OUTER DOOR HANDLE LH BS1/2/3/4	TATA spare parts
265472300124AE	ASSY.HANDLE OUTER DOOR L.H.-2523	TATA spare parts
265472300125	ASSY. OUTER DOOR HANDLE RH BS1/2/3/4	TATA spare parts
265472300125AE	ASSY.HANDLE OUTER DOOR R.H.-2523	TATA spare parts
265472300127	ASSY. HANDLE [WINDOW REGULATOR]	TATA spare parts
265472300127AE	ASSY.HANDLE( WINDOW REG) -2523	TATA spare parts
265472300130	INNER HANDLE LH	TATA spare parts
265472300131	ASSY INNER HANDLE	TATA spare parts
265472300136	ARM REST LH RHD	TATA spare parts

265472300137	ARM REST RH LHD	TATA spare parts
265472300138	ARM REST RH RHD	TATA spare parts
265472300139	ARM REST LH LHD	TATA spare parts
265472300145	ASSY.OUTER DOOR HANDLE L.H	TATA spare parts
265472300146	ASSY.OUTER DOOR HANDLE R.H	TATA spare parts
265472300153	LEVER RH POP UP KNOB	TATA spare parts
265472300162	ASSY. HANDLE [WINDOW REGULATOR]	TATA spare parts
265472300186	ASSY.DOOR LOCK SET WITH STG. LOCK	TATA spare parts
265472300190	FRONT DOOR STRIKER	TATA spare parts
265472300191	FUEL LID LOCK MINDA	TATA spare parts
265472300192	KIT DOOR LOCK W/STRG LOCK	TATA spare parts
265472300199	ASSY DOOR LOCK SET WITH SENSOR	TATA spare parts
265472300201	ASSY INNER HANDLE	TATA spare parts
265472300202	ASSY INNER HANDLE	TATA spare parts
265472300203	ASSY INNER HANDLE	TATA spare parts
265472300204	ASSY INNER HANDLE	TATA spare parts
265472300212	ASSY.DOOR STRIKER	TATA spare parts
265472300212AE	ASSY.DOOR STRIKER 2523/LPTA 1628	TATA spare parts
265472306005	LINK DR LOCK HANDLE OUTER	TATA spare parts
265472306006	LINK RH	TATA spare parts
265472306007	LINK LH	TATA spare parts
265472306303	NYLON CLIP NLS LOCK LINKS	TATA spare parts
265472306310	FOAM PACKING	TATA spare parts
265472306313	SSNAP CONNECTOR R.H	TATA spare parts
265472306318	GROMMET	TATA spare parts
265472306323	SNAP CONNECTOR LH	TATA spare parts
265472306324	HOLDER OUTER SEALING	TATA spare parts
265472306325	HOLDER OUTER SEALING LH (REAR)	TATA spare parts
265472306326	HOLDER SEALING RH REAR	TATA spare parts
265472306330	RUBBER BASE (STRIKER)	TATA spare parts
265472306335	SNAP CONNECTOR RH	TATA spare parts
265472306704	SPRING DOWEL SLEEVE(DOOR CHECK)	TATA spare parts
265472308209	BLANK KEY	TATA spare parts
265472308210	BLANK KEY	TATA spare parts
265472308211	SHIM (STRIKER MTG.)	TATA spare parts
265472310101	ASSY. HANDLE [WINDOW REGULATOR]	TATA spare parts
265472310103	ASSY.DOOR LOCK SET	TATA spare parts
265472310104	ARM REST LH DARK GRAY	TATA spare parts
265472310105	ARM REST RH DARK GRAY	TATA spare parts
265472310106	ASSY.DOOR LOCK SET W/OUT STG.LOCK	TATA spare parts
265472310107	ASSY.DOOR LOCK SET W/OUT STG.LOCK	TATA spare parts
265472310108	ASSY.DOOR LOCK SET W/OUT STG.LOCK	TATA spare parts
265472310109	ASSY.DOOR LOCK SET W/OUT STG.LOCK-OFFER	TATA spare parts
265472310110	ARM REST LH DARK GRAY	TATA spare parts
265472310111	ARM REST RH DARK GRAY	TATA spare parts
265472310116	ASSY LOCK KIT T/M	TATA spare parts
265472310118	ASSY LOCK KIT T/M(KEY IN SENSOR)	TATA spare parts

265472310119	ASSY DOOR LOCK COMPLETE RH	TATA spare parts
265472310120	ASSY DOOR LOCK COMPLETE LH	TATA spare parts
265472310126	ASSY.DOOR PULL LH (BLACK)	TATA spare parts
265472310127	ASSY.DOOR PULL RH (BLACK)	TATA spare parts
265472500105	DOOR GLASS HOLDER LH	TATA spare parts
265472500106	DOOR GLASS HOLDER RH	TATA spare parts
265472500115	DOOR GLASS HOLDER LH	TATA spare parts
265472500116	DOOR GLASS HOLDER RH	TATA spare parts
265472500123	W/STRIP NLS FR OUTER RH TM	TATA spare parts
265472500124	WINDOW REGULATOR LH	TATA spare parts
265472500125	WINDOW REG. RH	TATA spare parts
265472500127	ASSY.WINDING REGULATOR RH	TATA spare parts
265472500128	ASSY.WINDING REGULATOR LH	TATA spare parts
265472500131	WIN REGULATOR LH 5PT	TATA spare parts
265472500132	WIN REGULATOR RH 5PT	TATA spare parts
265472500133	ASSY.WINDOW REGULATOR LH	TATA spare parts
265472500134	WIN REGULATOR RH 5PT	TATA spare parts
265472500135	WEATHER STRIP INNER LH	TATA spare parts
265472500137	WEATHER STRIP OUTER LH	TATA spare parts
265472500138	WEATHER STRIP OUTER RH	TATA spare parts
265472502301	DOOR GLASS FR LH	TATA spare parts
265472502302	REGULATING GLASS R.H. FRONT DOOR	TATA spare parts
265472502303	REGULATING GLASS FRONT DOOR LH (TINTED)	TATA spare parts
265472502304	REGULATING GLASS FRONT DOOR-RH.(TINTED).	TATA spare parts
265472502305	DOOR GLASS FR LH EC	TATA spare parts
265472502306	DOOR GLASS FR RH EC	TATA spare parts
265472502307	DOOR GLASS FR LH EC TINT	TATA spare parts
265472502308	DOOR GLASS FR RH EC TINT	TATA spare parts
265472502501	VELVET CHANNEL	TATA spare parts
265472502509	PROFILE GLASS HOLDER	TATA spare parts
265472502514	WEATHER STRIP INNER	TATA spare parts
265472504301	SPRING CLIP	TATA spare parts
265472506302	SPACER HANDLE W R	TATA spare parts
265472506312	BEADING DOOR GLASS HOLDER	TATA spare parts
265472508201	CLIP WEATHER STRIP OUTER	TATA spare parts
265472700103	DOOR PAD CLIP BS1/2/3/4	TATA spare parts
265472700108	PADDING DOOR LH RHD	TATA spare parts
265472700109	PADDING DOOR RH RHD	TATA spare parts
265472700111	PADDING DOOR RH LHD	TATA spare parts
265472700118	PLATE LH	TATA spare parts
265472700119	PLATE RH	TATA spare parts
265472700124	PADDING DOOR LH	TATA spare parts
265472700125	PADDING DOOR RH	TATA spare parts
265472700141	ASSY PADDING DOOR LH	TATA spare parts
265472700142	ASSY.DOOR PADDING RH	TATA spare parts
265472700145	ASSY.PADDING DOOR LH	TATA spare parts
265472700146	ASSY.PADDING DOOR RH	TATA spare parts

265472700151	ASSY PADDING DOOR LH	TATA spare parts
265472700152	ASSY PADDING DOOR RH	TATA spare parts
265472706307	DOOR PAD CLIP [BOTTOM]	TATA spare parts
265472706310	NYLON CLIP TOP	TATA spare parts
265472706315	MAGAZINE POCKET L.H. BLACK	TATA spare parts
265472706316	MAGAZINE POCKET R.H. BLACK	TATA spare parts
265472706317	MAGAZINE POCKET LH DARK GRAY BS1/2/3/4	TATA spare parts
265472706317AE	MAGAZINE POCKET L-1628-1828	TATA spare parts
265472706318	MAGAZINE POCKET RH DARK GRAY BS1/2/3/4	TATA spare parts
265472706318AE	MAGAZINE POCKET R-1628-1828	TATA spare parts
265481000102	TATA BADGE	TATA spare parts
265481000182	TATA BADGE NLS	TATA spare parts
265481100103	PLASTIC GRILL OUTER RR LH	TATA spare parts
265481100104	PLASTIC GRILL OUTER RR RH	TATA spare parts
265481100118	RV MIRROR INNER	TATA spare parts
265481100119	SUNVISOR RH	TATA spare parts
265481100120	SUNVISOR LH	TATA spare parts
265481100129	MUD FLAP ASSY	TATA spare parts
265481100132	DECO BEADING	TATA spare parts
265481100134	COVER SUPPORT PANEL	TATA spare parts
265481100146	WIRE MESH RH LHD	TATA spare parts
265481100153	RV MIRROR OUTER RH	TATA spare parts
265481100159	RV MIRROR OUTER LH	TATA spare parts
265481100160	ASSY INNER R/V MIRROR ANTIGLARE	TATA spare parts
265481100161	PLASTIC GRILL RR INNER	TATA spare parts
265481100165	RV MIRROR INNER	TATA spare parts
265481100166	SUNVISOR RH	TATA spare parts
265481100169	ASSY.REAR VIEW MIRROR (INSIDE)	TATA spare parts
265481100170	ASSY.SEALING INNER LH-FOR FRONT DOOR	TATA spare parts
265481100171	SEALING INN RH FRT DOOR	TATA spare parts
265481100172	COVER SUPPORT PANEL	TATA spare parts
265481100173	ASSY.REAR VIEW MIRROR OUTSIDE RH	TATA spare parts
265481100174	ASSY.REAR VIEW MIRROR OUTSIDE LH	TATA spare parts
265481100175	COVER SUPPORT PANEL LH	TATA spare parts
265481100179	ASSY.INNER REAR VIEW MIRROR.ANTIGLARE	TATA spare parts
265481100181	T EMBLEM TELCOLINE	TATA spare parts
265481100183	COVER ASSY	TATA spare parts
265481100186	DOOR STOPPER	TATA spare parts
265481100187	ASSY.SEALING INNER L.H-FRONT DOOR	TATA spare parts
265481100188	ASSY.SEALING INNER R.H-FRONT DOOR	TATA spare parts
265481104201	BKT TOOL BAG	TATA spare parts
265481104301	SPRING CLIP ROOF BEADING	TATA spare parts
265481106301	BEADING ROOF RAIN CHANNEL	TATA spare parts
265481106314	MUD LINER LH INNER	TATA spare parts
265481106315	MUD LINER RH INNER	TATA spare parts
265481106339	COVER OUTER LH RVM OUTER	TATA spare parts
265481106340	COVER OUTER RH RVM OUTER	TATA spare parts

265481106346	END CAP LH ROOF BEAD RR	TATA spare parts
265481106358	BEADING SIDE CARPET	TATA spare parts
265481106360	ROOF BEADING	TATA spare parts
265481106361	END CAP LH ROOF BEAD RR	TATA spare parts
265481106362	END CAP RH ROOF BEAD RR	TATA spare parts
265481106366	RUBBER PACKING RH	TATA spare parts
265481106367	COVER ELR UNIT	TATA spare parts
265481106370	COVER (REAR VIEW MIRROR MTG.)	TATA spare parts
265481106372	RUB RAIL PANEL OUT.CORNER	TATA spare parts
265481106380	ROOF BEADING LH	TATA spare parts
265481106381	ROOF BEADING RH	TATA spare parts
265481106382	END CAP LH ROOF BEAD FRT	TATA spare parts
265481106383	END CAP RH ROOF BEAD FRT	TATA spare parts
265481106387	DEFLECTOR WATER WADING	TATA spare parts
265481106388	CLIP OUTER GRILL	TATA spare parts
265481106390	MUD FLAP W/O T EMBLEM	TATA spare parts
265481106391	RUBBER PACKING LH.-ROOF BEADING	TATA spare parts
265481106392	RUBBER PACKING RH. ROOF BEADING	TATA spare parts
265481106394	COVER (BONNET STAY ROD)	TATA spare parts
265481106396	MUDGUARD LINER INNER RH	TATA spare parts
265481106501	NUT J SPIRE	TATA spare parts
265481106503	SPRING CLIP MUD.LINER	TATA spare parts
265481107501	GROMMET	TATA spare parts
265481107503	SCREW GROMMET	TATA spare parts
265481107701	SEALING COVER RH SUP PANE	TATA spare parts
265481107702	SEALING COVER SUP PANEL	TATA spare parts
265481108201	COVER PANEL RHD W/S BOTT	TATA spare parts
265481108205	COVER PANEL LHD W/S BOTT	TATA spare parts
265481108237	CLAMP RH SUNVISOR	TATA spare parts
265481108238	CLAMP LH SUNVISOR	TATA spare parts
265481108601	SPACER	TATA spare parts
265481109201	WASHER	TATA spare parts
265481110103	ASSY.INNER RVM ANTIGLARE TYPE-GREY	TATA spare parts
265481110104	ASSY.INNER RVM ANTIGLARE TYPE-GREY	TATA spare parts
265481110105	ASSY.SUNVISOR LH LHD LIGHT GRAY	TATA spare parts
265481110106	ASSY.SUNVISOR RH LHD LIGHT GRAY	TATA spare parts
265481110107	ASSY.SUNVISOR LH RHD LIGHT GRAY	TATA spare parts
265481110108	ASSY.SUNVISOR RH RHD LIGHT GRAY	TATA spare parts
265481110109	ASSY.SUNVISOR LH RHD LIGHT GRAY	TATA spare parts
265481110110	ASSY.SUNVISOR RH RHD LIGHT GRAY	TATA spare parts
265481110112	ASSY.SIDE STEP COMPLETE WITH COVER	TATA spare parts
265481110113	ASSY INNER R/V MIRROR ANTIGLARE	TATA spare parts
265481110114	RV MIRROR INNER	TATA spare parts
265481110129	ASSY.CLOSING PIECE RHD (BLOWER CUT-OUT)	TATA spare parts
265481116307	MUDGUARD LINER INNER LH FRNT.WHEEL ARCH	TATA spare parts
265481116308	MUDGUARD LINER INNER RH FRNT.WHEEL ARCH	TATA spare parts
265481116309	COVER(FOR ELR UNIT)DARK GREY	TATA spare parts

26548116310	SIDE BEADING CARPET-DARK GREY	TATA spare parts
265481300102	ASH TRAY NLS ASSY	TATA spare parts
265481300103	ASH TRAY ASSY	TATA spare parts
265481508201	GUARD (HEAD REST)	TATA spare parts
265481800101	ASSY 207 DI MASCOT	TATA spare parts
265481800103	ASSY 207DI MASCOT 30 MM	TATA spare parts
265481800104	ASSY 3.0L MASCOT 30 MM	TATA spare parts
265481800107	ASSY TATA TDI MASCOT(CUR/CONN)	TATA spare parts
265481800110	ASSY. TATA MASCOT	TATA spare parts
265481800113	ASSY. TATA TDI MASCOT	TATA spare parts
265481800114	ASSY. `EX` MASCOT	TATA spare parts
265481800115	ASSY RX MASCOT	TATA spare parts
265481906301	BUTTON CROSS MEMBER	TATA spare parts
265481906302	BUTTON CROSS MEMBER	TATA spare parts
265481906303	PLUG	TATA spare parts
265482400102	ASSY WIPER BLADE RHD	TATA spare parts
265482400103	LINK ROD 1	TATA spare parts
265482400104	LINK ROD 2	TATA spare parts
265482400105	WHEEL BOX LH	TATA spare parts
265482400106	WHEEL BOX RH	TATA spare parts
265482400109	KIT ELEC W/S WASHER	TATA spare parts
265482400111	KIT WIPER MOTOR	TATA spare parts
265482400113	ASSY WIPER BLADE LHD	TATA spare parts
265482400116	ASSY WHEEL BOX	TATA spare parts
265482400127	BKT WIPER MOTOR MTG	TATA spare parts
265482400131	NOZZLE UNIT TWIN JET	TATA spare parts
265482400132	NOZZLE TWIN JET	TATA spare parts
265482400140	WIPER ARM RH RHD	TATA spare parts
265482400141	WIPER ARM LH LHD	TATA spare parts
265482400143	WIPER ARM RH LHD	TATA spare parts
265482400145	ASSY. BRACKET ( WIPER MOTOR MTG. )	TATA spare parts
265482400146	WIPER ARM LH RHD	TATA spare parts
265482400147	KIT FOR ELECT.W/S.WASHER	TATA spare parts
265482400148	KIT ELEC W/S WASHER 2.5L	TATA spare parts
265482400161	WIPER MTR W/RIS+THER C/O MS-LHD	TATA spare parts
265482400165	WIPER MOTOR RHD W/RIS	TATA spare parts
265482400173	KIT-ELECT W/S WASHER UNIT COMPL	TATA spare parts
265482400176	WIPER LINK ROD & WHEELBOX KIT	TATA spare parts
265482400177	KIT-WIPER COMP. BS1/2/3/4	TATA spare parts
265482400180	WIPER MTR W/RIS+THER C/O LHD	TATA spare parts
265482400182	KIT WIPER MOTOR LHD	TATA spare parts
265482400185	ASSY.WIPER KIT-RHD	TATA spare parts
265482400190	KIT ELEC W/S WASHER [2.5LTR]	TATA spare parts
265482400191	KIT ELE W/S WASHER MSSL.[2.5LTR]	TATA spare parts
265482400195	WIPER MOTOR W/RIS & THER C/O LHD	TATA spare parts
265482400196	ASSY.WIPER KIT-RHD	TATA spare parts
265482406302	COVER WIPER MOTOR	TATA spare parts

265482406303	ADAPTER NOZZLE	TATA spare parts
265482406304	COVER WIPER MOTOR	TATA spare parts
265482407501	GASKET	TATA spare parts
265482407502	RUBBER BOOT WHEEL BOX	TATA spare parts
265482407503	GASKET	TATA spare parts
265482408201	BKT WIPER MOTOR MTG	TATA spare parts
265482409935	WIPER ARM WITH SPOILER DR-LHD	TATA spare parts
265482409936	WIPER ARM WITH SPOILER DR-RHD	TATA spare parts
265482410118	ASSY. WIPER MOTOR & BRACKET BS1/2/3/4/6	TATA spare parts
265482410125	ASSY WIPER ARM RH RHD	TATA spare parts
265482410126	ASSY WIPER ARM RH LHD	TATA spare parts
265482410128	ASSY.WIPER ARM RH LHD [CO-DR]	TATA spare parts
265482410129	ASSY. WIPER ARM RH RHD	TATA spare parts
265482410130	ASSY. WIPER ARM RH LHD	TATA spare parts
265482410131	ASSY.WIPER ARM LH LHD [DR]	TATA spare parts
265482410132	ASSY.WIPER ARM RH LHD [CO-DR]	TATA spare parts
265482410137	ASSY.WIPER ARM & BLADE CO-DR-RHD	TATA spare parts
265482410138	ASSY. WIPER ARM WITH SPOILER RH	TATA spare parts
265482410139	ASSY WIPER ARM & BLADE CO-DR-LHD	TATA spare parts
265482410140	ASSY WIPER ARM & BLADE DR-LHD EX	TATA spare parts
265482410141	ASSY.WIPER ARM & BLADE DR-RHD DOM	TATA spare parts
265482410146	ASSY.WIPER ARM & BLADE DR-RHD DOM	TATA spare parts
265482410147	FRONT W/S WASHER KIT	TATA spare parts
265482410150	GEAR BOX BRUSHPLATE & ASSY	TATA spare parts
265482410151	ARMATURE ASSY	TATA spare parts
265482410153	GEAR & SLIP RING ASSY.	TATA spare parts
265482410154	ROTARY LINK ASSEMBLY	TATA spare parts
265482410155	COVERPLATE& BRUSHPLATE ASSY	TATA spare parts
265482410156	FASTNERS/SEALING KIT	TATA spare parts
265482410157	ROTARY LINK ASSY.	TATA spare parts
265482504901	TIMER INTERMITANT WIPER	TATA spare parts
265483100105	PLENUM CHAMBER RHD	TATA spare parts
265483100111	BLOWER VENTILATION RHD	TATA spare parts
265483100113	DUCT ASSY RHD	TATA spare parts
265483100129	BLOWER RHD VENT	TATA spare parts
265483100143	PLENUM CHAMB COMP 5P RHD	TATA spare parts
265483100148	FLAP FRESH AIR	TATA spare parts
265483100151	ASSY.HOUSING (FRESH AIR).-LHD.	TATA spare parts
265483103307	MTG BKT PLENUM CHAMBER LH	TATA spare parts
265483103308	MTG BKT PLENUM CHAMBER RH	TATA spare parts
265483106301	HOSE(VENTILATION)SIDE	TATA spare parts
265483106310	ELBOW DUCT L.H.	TATA spare parts
265483106311	ELBOW DUCT R.H.	TATA spare parts
265483106318	SEALING RING	TATA spare parts
265483106319	RETAINER VENT CABLE	TATA spare parts
265483106322	HOSE VENTILATION	TATA spare parts
265483106334	HOSE VENTILATION	TATA spare parts

265483106350	DIFFUSER LEG ROOM VENT	TATA spare parts
265483106362	HOSE LEG ROOM CONNECTOR	TATA spare parts
265483106370	CONNECTOR.(FOR BLOWER FRESH AIR).	TATA spare parts
265483106375	ELBOW DUCT LH	TATA spare parts
265483106376	EBLOW DUCT RH	TATA spare parts
265483106385	GROMMET(FOR HEATER HOSES) LPTA 713 TC	TATA spare parts
265483106388	LEG VENT NOZZLE RH	TATA spare parts
265483106389	LEG VENT NOZZLE LH	TATA spare parts
265483108221	CLIP	TATA spare parts
265483108243	CLAMP-HEATER HOSE MTG(ONLY HEATR)TURBO	TATA spare parts
265483108705	TORSION SPRING.	TATA spare parts
265483110108	ADAPTER HEATER	TATA spare parts
265483110116	ASSY.BLOWER HOUSING - LHD.	TATA spare parts
265483110119	ASSY.ADAPTOR	TATA spare parts
265483110124	ASSY.BKT.AC UNIT SUPPORT ON CROSS MEMBER	TATA spare parts
265483110127	ASSY.PLENUM CHEMBER-(5P)-RHD.	TATA spare parts
265483110128	PLENUM CHAMBER 5P LHD	TATA spare parts
265483110154	ASSY BRACKET WATER VALVE	TATA spare parts
265483110169	ASSY.CONDENSER COMPLETE-RHD	TATA spare parts
265483110171	ASSY HOSE DISCHARGE	TATA spare parts
265483110173	KIT FOR AC + HEATER ON CAB-RHD	TATA spare parts
265483110180	KIT FOR AC+HTR ON CAB - LHD	TATA spare parts
265483110182	ASSY.DUCT & COVER DISTRIBUTION DUCT	TATA spare parts
265483116301	PLUG [A.C.ADAPTOR CLOSING FOR REAR VENT]	TATA spare parts
265483116309	PACKING FOAM	TATA spare parts
265483116321	ELBOW DUCT LH	TATA spare parts
265483116322	ELBOW DUCT RH	TATA spare parts
265483116325	SEALING GASKET (BLOWER TO DUCT)	TATA spare parts
265483116326	DUCT FOR WINDOW DEMIST	TATA spare parts
265483120170	ASSY HOSE SUCTION	TATA spare parts
265483120176	ASSY EVAPORATOR	TATA spare parts
265483300101	CABLE ASSY	TATA spare parts
265483300129	ASSY CABLE	TATA spare parts
265483300177	HOSE CLAMP 25	TATA spare parts
265483300184	ASSY.PUSH PULL CABLE -RED COLOUR	TATA spare parts
265483300190	VENTILATION NOZZLE	TATA spare parts
265483300193	ASSY.VENTILATION CABLE	TATA spare parts
265483300194	ASSY.CABLE	TATA spare parts
265483300196	ASSY POTENTIOMETER	TATA spare parts
265483300199	ASSY.PUSH PULL CABLE -PLENUM	TATA spare parts
265483304201	SPRING CLAMP	TATA spare parts
265483306317	COVER (FOR HEATER CUT OUT)	TATA spare parts
265483308210	CLAMP BLOWER CABLE	TATA spare parts
265483309922	KIT A/C RHD W/O COMP SUB	TATA spare parts
265483310101	ASSY.PUSH PULL CABLE - A.C	TATA spare parts
265483310102	ASSY.PUSH PULL CABLE	TATA spare parts
265483310106	ASSY.PUSH PULL CABLE	TATA spare parts



265483400108	ASSY.HEATER COIL	TATA spare parts
265483400195	ASSY.HEATER COIL	TATA spare parts
265483500108	WATER VALVE	TATA spare parts
265483500109	LEVER WATER VALVE	TATA spare parts
265483500110	HEATER WATER VALVE	TATA spare parts
265483500119	ASSY.BRKT.( FOR N.D.WATER VALVE MTG.)	TATA spare parts
265483505802	RUBBER HOSE [ 17 ID X L 800 ] ).	TATA spare parts
265483505803	RUBBER HOSE [ 17 ID X L 1200 ].	TATA spare parts
265483505805	RUBBER HOSE [ 17 ID X L 1085 ]	TATA spare parts
265483505808	HOSE TH/STAT TO W/VALVE	TATA spare parts
265483505811	RUBBER HOSE [17 ID X L 450]	TATA spare parts
265483505813	HOSE W/VALVE TO TH/STAT	TATA spare parts
265483505814	HOSE W/VALVE HT/COIL	TATA spare parts
265483506301	COVER BLOWER MOTOR	TATA spare parts
265483507502	RUBBER GROMMET	TATA spare parts
265483700107	DEFROST NOZZLE LH	TATA spare parts
265483700108	DEFROST NOZZLE RH	TATA spare parts
265486800101	ASSY.FIRE EXTINGUISHER COMPLT.(500GMS)	TATA spare parts
265488100101	SIDE BONNET LH	TATA spare parts
265488100102	SIDE BONNET RH	TATA spare parts
265488100103	ASSY.REINFROCEMENT LH [SIDE BONNET]	TATA spare parts
265488100104	REINF SIDE BONNET RH	TATA spare parts
265488100111	ASSY.REINFORCEMENT LH	TATA spare parts
265488100112	ASSY.REINFORCEMENT RH	TATA spare parts
265488100113	ASSY BONNET SIDE LH	TATA spare parts
265488100114	ASSY BONNET SIDE RH	TATA spare parts
265488100116	BRACKET ASSY. LH (REINF.SIDE BONNET)	TATA spare parts
265488100117	BRACKET ASSY. RH (REINF.SIDE BONNET)	TATA spare parts
265488103301	BRKT.(SIDE BONNET OUTER)	TATA spare parts
265488500104	BUMPER COMP FRONT	TATA spare parts
265488500125	BRACKET BUMPER MTG LH	TATA spare parts
265488500136	ASSY.BUMPER FRONT COMPLETE	TATA spare parts
265488500140	BRACKET FRONT BUMPER MTG	TATA spare parts
265488500142	ASSY BUMPER CENTRE	TATA spare parts
265488500143	ASSY.STOPPER	TATA spare parts
265488500144	ASSY.BRACKET LH (SIDE BUMPER MTG.)	TATA spare parts
26548850014421	BRACKET CED COATED	TATA spare parts
265488500145	ASSY.BRACKET RH (SIDE BUMPER MTG.)	TATA spare parts
26548850014521	BRACKET CED COATED	TATA spare parts
265488500146	ASSY.COVER(FRONT BUMPER)LH-BLACK	TATA spare parts
265488500147	ASSY.COVER(FRONT BUMPER)RH-BLACK	TATA spare parts
265488500149	ASSY. BUMPER FRONT COMP. 16 TYRE BS2/3	TATA spare parts
265488500149BF	ASSY BUMPER FR COMPLETE(16 INCH TYRE)-WH	TATA spare parts
265488500149CN	ASSY BUMPER FRONT COMPLETE(16 TYRE)	TATA spare parts
265488500151	ASSY COVER(FRONT BUMPER)LH - GREY	TATA spare parts
265488500152	ASSY COVER(FRONT BUMPER)RH - GREY	TATA spare parts
265488500156BF	ASSY.BUMPER CTR. COMPL PAINTED ARCTIC WH	TATA spare parts

265488500156BL	ASSY.BUMPER CTR. COMPL PAINTED NEPTUNE B	TATA spare parts
265488500156BS	ASSY.BUMPER CTR. COMPL PAINTED S GREEN	TATA spare parts
265488500156CN	ASSY.BUMPER CTR. COMPL PAINTED IRISH CRE	TATA spare parts
265488506701	SQUARE NECK BOLT	TATA spare parts
265488508210	CORNER BUMPER FR LH	TATA spare parts
265488508211	CORNER BUMPER FR RH	TATA spare parts
265488508213	NUMBER PLATE	TATA spare parts
265488508214	BKT BUMPER MTG LH SIDE	TATA spare parts
26548850821421	BRACKET LH SIDE [BUMP MTG] CED COATED	TATA spare parts
265488508215	BKT BUMPER MTG RH SIDE	TATA spare parts
265488508229	NUT HOLDER	TATA spare parts
265488508255	BUMPER CENTRE	TATA spare parts
265488508601	SPACER-FOR NUMBER PLATE MTG.	TATA spare parts
265488509201	WASHER BUMPER MTG	TATA spare parts
265488606301	SCREW GROMMET	TATA spare parts
265488700101	BONNET HINGE LH	TATA spare parts
265488700102	BONNET HINGE RH	TATA spare parts
265488700117	CABLE BONNET RELEASE RHD	TATA spare parts
265488700123	BONNET CENTRE	TATA spare parts
265488700124	ASSY.RELEASE CABLE COMPLETE L.H.	TATA spare parts
265488700129	BKT BONNET LOCK BOTT	TATA spare parts
265488700133	BONNET LOCK BONNET SIDE	TATA spare parts
265488700137	BKT BONNET LOCK LHD BOTT	TATA spare parts
265488700143	ASSY.BONNET LOCK	TATA spare parts
265488700146	ASSY. RELEASE CABLE COMPLETE-LH(T/O/D)	TATA spare parts
265488700147	CABLE BONNET RELEASE RHD	TATA spare parts
265488700150	ASSY.RELEASE CABLE RH RHD.	TATA spare parts
265488700165	ASSY.BONNET INSULATION	TATA spare parts
265488703401	BUSH STAY ROD	TATA spare parts
265488703402	BUSH BONNET HINGE	TATA spare parts
265488704202	CLAMP BONNET STAY ROD	TATA spare parts
265488706003	BONNET STAY ROD	TATA spare parts
265488706301	BAZZEL LH	TATA spare parts
265488706302	BAZZEL RH	TATA spare parts
265488706304	SEALING BONNET W/S SIDE	TATA spare parts
265488706310	RUBBER BUFFER	TATA spare parts
265488706311	RUBBER BUFFER	TATA spare parts
265488706901	TUBE STAY ROD	TATA spare parts
265488708220	BKT BONNET STAY ROD	TATA spare parts
265488708226	ANGLE (STAY ROD)BONNET	TATA spare parts
265488708236	LINK BONNET LOCK	TATA spare parts
265488708702	TENSION SPG BON LOCK RET	TATA spare parts
265488800106	ASSY.FRONT GRILL	TATA spare parts
265488806301	GRILL CENTRE	TATA spare parts
265488806302	FRONT GRILL	TATA spare parts
265489100101	MOUNTING BRACKET	TATA spare parts
265489100108	RUBBER MOUNTING TOP	TATA spare parts

265489100115	ASSY.MOUNTING BRACKET	TATA spare parts
265489100117	KIT ASSY.RUBBER MOUNTING	TATA spare parts
265489106302	RUBBER MOUNTING BOTTOM	TATA spare parts
265489106303	RUBBER PAD	TATA spare parts
265489106904	SPACER TUBE	TATA spare parts
265489109201	WASHER	TATA spare parts
265491000101	SEAT BENCH	TATA spare parts
265491000108	SEAT BENCH RHD	TATA spare parts
265491000131	SEAT BENCH FOLDABLE	TATA spare parts
265491010151	ASSY.DRIVER SEAT (ADJUSTABLE)-VINYL	TATA spare parts
265491010152	ASSY.CO-DRIVER SEAT-FIXED VINYL	TATA spare parts
265491500125	SEAT BELT MIDDLE	TATA spare parts
265491500132	ASSY.SEAT BELT KIT COMPLETE	TATA spare parts
265491500181	ASSY.SEAT BELT KIT W/O MICRO SW	TATA spare parts
265491500191	ASSY.SEAT BELT KIT W/O MICRO SW	TATA spare parts
265491500197	ASSY.SEAT BELT KIT W/O MICRO SW	TATA spare parts
265491503401	BUSH	TATA spare parts
265491506301	COVER SEAT BELT MTG BKT	TATA spare parts
265491506303	COVER DARK GREY SEAT BELT MTG.BKT.	TATA spare parts
265491706301	PACKING TOP SEAT MTG	TATA spare parts
265491706302	PACKING BOTTOM SEAT MTG	TATA spare parts
265498800106	MASCOT TELCO LINE	TATA spare parts
265498806302	MASCOT 207 NLS	TATA spare parts
265498806304	MASCOT TATA 2.0D	TATA spare parts
265499006501	SQUARE NUT	TATA spare parts
265499006502	NUT RECT M8	TATA spare parts
265499006503	NUT	TATA spare parts
265499009201	RUBBER WASHER	TATA spare parts
2654TEQL0116	TIE ROD END LH	TATA spare parts
2654TEQR0117	TIE ROD END RH	TATA spare parts
265724100103	BRACKET ASSY ENGINE MTG FRONT-RH - BS6	TATA spare parts
265724200101	BRACKET ASSY ENGINE MTG BOTTOM REAR BS6	TATA spare parts
265728450102	LINK ROD ASSY	TATA spare parts
265728450103	ASSY.LEVER	TATA spare parts
265728450107	LEVER ASSY UPPER BS6	TATA spare parts
265728450108	LINKAGE ASSY TRANSFER CASE BS6	TATA spare parts
265728450109	BRACKET ASSY AUX GEAR BOX LEVER MTG BS6	TATA spare parts
265728450110	BRACKET AGB SHIFT LEVER MTG ASSY BS6	TATA spare parts
265728457501	RUBBER BELLOW	TATA spare parts
265728458202	COVER PLATE	TATA spare parts
265728507501	RUBBER BUSH(A/GB)407 4X4	TATA spare parts
265728508601	SPACER	TATA spare parts
265728509201	WASHER	TATA spare parts
265729300105	NYLON PIPE ASSY BS6	TATA spare parts
265730100102	ASSY.PULL ROD COMP.	TATA spare parts
265731000101	FRAME ASSY 4X4 TRUCK 407	TATA spare parts
265731000102	ASSY FRAME COMP	TATA spare parts

265731000109	ASSY.FRAME COMPLETE	TATA spare parts
265731000110	FRAME ASSY WITH FITMENT	TATA spare parts
265731000115	FRAME ASSY WITH FITMENT	TATA spare parts
265731000120	FRAME ASSY WITH FITMENT BS6	TATA spare parts
265731200104	SPRING CROSS MEMBER ASSY BS6	TATA spare parts
265731200105	CROSS MEMBER ASSY WITH BKT BS6	TATA spare parts
265731206901	TUBE	TATA spare parts
265731208201	REINFORCEMENT( L.H.)	TATA spare parts
265731208215	REINFORCEMENT LH BS6	TATA spare parts
265731208217	REINFORCEMENT RH BS6	TATA spare parts
265731208218	REINFORCEMENT LH BS6	TATA spare parts
265731208219	REINFORCEMENTRH BS6	TATA spare parts
265731400101	ASSY.CROSS MEMBER REAR SPRING REAR	TATA spare parts
265731400102	ASSY CROSS MEMBER FRT (T.C MTG)	TATA spare parts
265731400103	ASSY CROSS MEMBER REAR (T.C.MTG)	TATA spare parts
265731400104	ASSY CLEAT	TATA spare parts
265731400111	SPRING CROSS MEMBER ASSY BS6	TATA spare parts
265731400116	ASSY CROSS MEMBER - CENTRE BEARING	TATA spare parts
265731400117	ASSY.REINFORCEMENT R.H.	TATA spare parts
265731400118	ASSY.REINFORCEMENT L.H.	TATA spare parts
265731400120	CROSS MEMBER ASSY (T/C MOUNTING) BS6	TATA spare parts
265731400129	ASSY.REAR SPRING REAR CROSS MEMBER	TATA spare parts
265731400136	CROSS MEMBER ASSY BS6	TATA spare parts
265731407102	END CROSS MEMBER	TATA spare parts
265731407103	GUSSET BS6	TATA spare parts
265731407107	END CROSS MEMBER BS6	TATA spare parts
265731408213	REINFORCEMENT R.H.(TOP)	TATA spare parts
265731408214	REINFORCEMENT L.H.(TOP)	TATA spare parts
265731408217	CROSS MEMBER FRONT BS6	TATA spare parts
265731500101	ASSY.PINTEL HOOK	TATA spare parts
265731700103	ASSY BRACKET LH	TATA spare parts
265731700104	ASSY.BRACKET-RH	TATA spare parts
265732100109	ASSY. SPACER	TATA spare parts
265732100114	FRONT SPRING ASSY TRUCK	TATA spare parts
265732100115	FIRST LEAF W/BUSH (4	TATA spare parts
265732100115DF	MAIN LEAF FRONT W/BUSH - SFC407	TATA spare parts
265732100118	ASSY.SHACKLE WITH BUSH-FRONT	TATA spare parts
265732100119	SHACKLE FABRICATED	TATA spare parts
265732100121	ASSY.FRONT SPRING.	TATA spare parts
265732100122	ASSY.FIRST LEAF WITH BUSHES	TATA spare parts
265732100123	ASSY.SPRING SUPPORT L.H.	TATA spare parts
265732100124	ASSY.SPRING SUPPORT R.H.	TATA spare parts
265732100125	ASSY. FRONT SPRING	TATA spare parts
265732100127	FRONT SPRING ASSY(MECH STEERING)	TATA spare parts
265732100128	1ST LEAF ASSY WITH BUSH	TATA spare parts
265732100131	FRONT SPRING ASSY (POWER STEERING)	TATA spare parts
265732100142	FRONT SPRING ASSY BS6	TATA spare parts

265732100144	1ST LEAF WITH BUSH BS6	TATA spare parts
265732100145	LOWER SADDLE ASSY FRONT FRONT BS6	TATA spare parts
265732103503	PIN	TATA spare parts
265732103701	FRONT SPRING BRACKET	TATA spare parts
265732103702	FRONT SPRING BRACKET	TATA spare parts
265732103703	FRONT SPRING BRACKET	TATA spare parts
265732103705	FRONT SPRING BRACKET (FRONT)-LH SFC4074X	TATA spare parts
265732103706	FRONT SPRING BRACKET (FRONT)-RH SFC4074X	TATA spare parts
265732104201	SPRING CLIP	TATA spare parts
265732106701	DOWEL PIN LOWER SADDLE FRONT BS6	TATA spare parts
265732106702	PIN SPRING FRONT BS6	TATA spare parts
265732107102	2ND LEAF BS6	TATA spare parts
265732107112	3RD LEAF BS6	TATA spare parts
265732107114	4TH LEAF BS6	TATA spare parts
265732107115	5TH LEAF BS6	TATA spare parts
265732107122	FIRST LEAF	TATA spare parts
265732107123	SECOND LEAF	TATA spare parts
265732107124	THIRD LEAF	TATA spare parts
265732107125	FOURTH LEAF	TATA spare parts
265732107126	FIFTH LEAF	TATA spare parts
265732107131	SECOND LEAF	TATA spare parts
265732107132	THIRD LEAF	TATA spare parts
265732107142	2ND LEAF	TATA spare parts
265732107143	3RD LEAF	TATA spare parts
265732107144	4TH LEAF	TATA spare parts
265732107145	5TH LEAF	TATA spare parts
265732107146	6TH LEAF	TATA spare parts
265732107147	CASTER PLATE BS6	TATA spare parts
265732107148	6TH LEAF BS6	TATA spare parts
265732200102	ASSY.GUIDE PLATE (FRONT SPRING)	TATA spare parts
265732203703	GUIDE PLATE FRONT	TATA spare parts
265732204201	U-CLAMP(FRONT SPRING)	TATA spare parts
265732204202	U CLAMP	TATA spare parts
265732300106	BKT S/ABS & CAB FRT RH	TATA spare parts
265732300107	ASSY.BKT.FR.S/A & CAB MTG.COMP. L H.	TATA spare parts
265732300113	BRACKET ASSY FRT SHOCK ABSO. & CABLH BS6	TATA spare parts
265732300115	BRACKET ASSYSHOCK ABSORBER MTG BS6	TATA spare parts
265732300116	BRACKET ASSY SHOCK ABSORBER MTG RH BS6	TATA spare parts
265732308224	BRACKET-SHOCK ABSORBER MTG-FRONT-LOWER	TATA spare parts
265732400107	REAR SPRING ASSY BS6	TATA spare parts
265732400108	ASSY.SPACER (REAR SPRG)	TATA spare parts
265732400113	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
265732400115	BUMP STOPPER ASSY (REAR AXLE STOPPER)BS6	TATA spare parts
265732404204	CLAMP BS6	TATA spare parts
265732406701	PIN	TATA spare parts
265732407102	2ND LEAF BS6	TATA spare parts
265732407108	3RD LEAF BS6	TATA spare parts

265732407112	4TH LEAF BS6	TATA spare parts
265732407113	5TH LEAF BS6	TATA spare parts
265732407117	6TH LEAF BS6	TATA spare parts
265732407119	7TH LEAF BS6	TATA spare parts
265732407120	8TH LEAF BS6	TATA spare parts
265732407123	9TH LEAF BS6	TATA spare parts
265732407124	10TH LEAF BS6	TATA spare parts
265732407126	11TH LEAF BS6	TATA spare parts
265732504201	U-CLAMP REAR SPRING	TATA spare parts
265732504204	U CLAMP	TATA spare parts
265732800105	ASSY.STUD.(FRONT ARB.MTG.)	TATA spare parts
265732800106	ASSY CONNECTING ROD	TATA spare parts
265732800107	ASSY. CONNECTING ROD	TATA spare parts
265732800118	BRACKET ASSY-ANTI ROLL BAR-FRONT-RH BS6	TATA spare parts
265732800119	BRACKET ASSY-ANTI ROLL BAR-FRONT-LH BS6	TATA spare parts
265732800120	BRACKET ARB MTG ASSY LH (FRONT TOP) BS6	TATA spare parts
265732800122	BRACKET ANTI ROLL BAR MTG ASSY RH BS6	TATA spare parts
265732800123	CONNECTING LINK ASSY. BS6	TATA spare parts
265732800124	ANTI ROLL BAR ASSY WITH LINK BS6	TATA spare parts
265732803304	BRACKET ANTI ROLL BAR MTG LOWER-RH BS6	TATA spare parts
265732803306	BRACKET ANTI ROLL BAR MTG LOWER-RH BS6	TATA spare parts
265732806001	CONNECTING LINK - BS6	TATA spare parts
265732807702	BEARING BLOCK-FRONT ANTIROLL BAR	TATA spare parts
265732808208	CLAMP FRONT ARB MTG.	TATA spare parts
265732900102	ASSY.BRACKET.(REAR ARB.MTG ON LONG MEM)	TATA spare parts
265732900103	ASSY REAR ANTI ROLL BAR WITH LINKS	TATA spare parts
265732900108	ANTI ROLL BAR ASSY WITH LINKREAR BS6	TATA spare parts
265732900109	BRACKET ANTI ROLL BAR MTG REAR-LH BS6	TATA spare parts
265732900110	BRACKET ANTI ROLL BAR MTG REAR-RH BS6	TATA spare parts
265732900111	CONN ROD ASSY ANTI ROLL BAR MTG REAR ARB	TATA spare parts
265732907105	REINFORCEMENT BS6	TATA spare parts
265732908201	BRACKET CONNECTING LINK ASSY BS6	TATA spare parts
265733800106	TIE ROD ASSY	TATA spare parts
265733805101	STEERING ARM BS6	TATA spare parts
265733805102	TIE ROD ARMRH BS6	TATA spare parts
265733805103	TIE ROD ARM LH BS6	TATA spare parts
265733855104	STEERING ARM RHD	TATA spare parts
265733855105	STEERING ARM-LHD	TATA spare parts
265733855106	TIE ROD ARM RH	TATA spare parts
265733855107	TIE ROD ARM LH	TATA spare parts
265733990101	BALL JOINT	TATA spare parts
265733990102	BALL JOINT	TATA spare parts
265740100105	WHEEL RIM 6.00G X 16	TATA spare parts
265740106701	WHEEL MOUNTING PIN	TATA spare parts
265740300106	ASSY HANDLE	TATA spare parts
26574030011020	ASSY SPARE WHEEL HANDLE WITH SHAFT BS6	TATA spare parts
265741000101	ASSY PROP.SHAFT	TATA spare parts

265741000102	ASSY PROP.SHAFT (DANA) 407 4X4	TATA spare parts
265741000103	ASSY PROP.SHAFT 407 4X4	TATA spare parts
265741100105	P/SHAFT GB/AGB 70X3	TATA spare parts
265741120104	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
265741120106	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
265741120110	ASSY. PROPELLER SHAFT FRONT (GEAR BOX T	TATA spare parts
265741120116	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
265742100122	ASSY FRONT AXLE BRAKE LH (SA63SM)	TATA spare parts
265742100123	ASSY FRONT AXLE BRAKE RH (SA63SM)	TATA spare parts
265742100134	BRAKE ASSY-FRONT-LH BS6	TATA spare parts
265742100135	BRAKE ASSY FRONT-RH BS6	TATA spare parts
265742103701	BRAKE DRUM	TATA spare parts
265742103702	BRACKET ABS SENSOR MTG BS6	TATA spare parts
265742103703	BRAKE DRUM FRONT BS6	TATA spare parts
265742103710	BRAKE DRUM	TATA spare parts
265742300101	407 4X4 ASSY.RA.BRAKE-LH (3100 WB)	TATA spare parts
265742300102	407 4X4 ASSY.RA.BRAKE-RH (3100 WB)	TATA spare parts
265742700103	ASSY CABLE-FRONT	TATA spare parts
265742700104	ASSY.HAND BRAKE CABLE-FRONT	TATA spare parts
265742700105	CABLE ASSY. FRONT	TATA spare parts
265742700106	CABLE HAND BRAKE REAR	TATA spare parts
265742700109	ASSY. PARKIGN BRAKE CABLE FRONT	TATA spare parts
265742700119	PARKING BRAKE CABLE ASSY-FRONT BS6	TATA spare parts
265742800135	ASSY TUBE 407	TATA spare parts
265742800140	ASSY.TUBE	TATA spare parts
265742800153	ASSY.TUBE	TATA spare parts
265742808204	BRACKET	TATA spare parts
265743100101	PR CONCIIOUS REG VALVE	TATA spare parts
265743100102	BYPASS VALVE ASSY	TATA spare parts
265743100103	PCR VALVE 407 4X4	TATA spare parts
265743500101	PIPE ASSY QFC TO MAG. VALVE	TATA spare parts
265743500110	BOOSTER ASSY BS6	TATA spare parts
265743500112	VACUUM PIPE BUNCH ASSY BS6	TATA spare parts
265743506801	CROSS BODY	TATA spare parts
265743800102	ASSY TUBE	TATA spare parts
265743800103	ASSY.TUBE	TATA spare parts
265743800104	TUBE ASSY T-CONN TO FRONT BRAKE HOSE LH	TATA spare parts
265743800105	TUBE ASSY T-CONN TO FRONT HOSE RH	TATA spare parts
265743800122	TUBE ASSY-TMC SECONDARY TO FRONT-RH BS6	TATA spare parts
265743800123	TUBE ASSY-TMC SECONDARY TO FRONT-LH BS6	TATA spare parts
265743800124	TUBE ASSY-TMC PRIMERY TO ADAPTER BS6	TATA spare parts
265743800125	TUBE ASSY-ADAPTER TO GP VALVE BS6	TATA spare parts
265743800126	TUBE ASSY BS6	TATA spare parts
265743800138	TUBE ASSY ADAPTER TO MV BS6	TATA spare parts
265743800139	TUBE ASSY ADAPTER TO MV BS6	TATA spare parts
265743800140	TUBE ASSY MV TO ADAPTER BS6	TATA spare parts
265743800141	TUBE ADAPTER TO REAR BRAKE HOSE RH BS6	TATA spare parts

265743800142	TUBE ASSY MV TO ADAPTER BS6	TATA spare parts
265743800143	TUBE ADAPTER TO REAR BRAKE HOSE LH BS6	TATA spare parts
265743800144	TUBE ASSY TMC SECONDARY TO ADAPTER BS6	TATA spare parts
265743800145	TUBE ASSY TMC PRIMARY TO ADAPTER BS6	TATA spare parts
265743800146	TUBE ASSY MV TO ADAPTER BS6	TATA spare parts
265743800147	TUBE ASSY MV FR TO FRT BRAKE HOSE LH BS6	TATA spare parts
265743806801	COUPLING NUT BS6	TATA spare parts
265746106301	RUBBER BELLOW BOTTOM	TATA spare parts
265746108201	CLAMPING RING	TATA spare parts
265746200104	ASSY SPINDLE	TATA spare parts
265746200106	ASSY SLEEVE & SPINDLE FOR GL.COAT SPINDL	TATA spare parts
265746207904	STRG SPINDLE BOTTOM	TATA spare parts
265746207907	STRG SPINDLE MIDDLE	TATA spare parts
265747600134	FUEL SUCTION PIPE ASSY TANK TO P/FILTER	TATA spare parts
265747600135	SUCTION PIPE ASSY FUEL FILTER TO FIP	TATA spare parts
265747600136	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
265749100107	HOSE PIPE ASSY DPS TO PIPE DOWN STREAM	TATA spare parts
265749100108	PIPE ASSY UPSTREAM DPS	TATA spare parts
265749106904	TAIL PIPE-LH	TATA spare parts
265749200103	EXHAUST PIPE ASSY FLEX BELLOW FR BS6	TATA spare parts
265749200110	ASSY SILENCER	TATA spare parts
265749200111	EXHAUST PIPE FRONT	TATA spare parts
265749200112	EXHAUST PIPE FRONT	TATA spare parts
265749200113	ASSY.BRACKET-LH	TATA spare parts
265749200114	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
265749200123	ASSY.EXHAUST PIPE-FRONT	TATA spare parts
265749200124	ASSLY. BRACKET	TATA spare parts
265749200125	ASSLY BOTTOM NOISE SHIELD FLAP -LH	TATA spare parts
265749200126	ASSLY BOTTOM NOISE SHIELD FLAP-RH	TATA spare parts
265749200127	ASSY BRACKET	TATA spare parts
265749200128	ASSY BRACKET	TATA spare parts
265749200132	ASSY BOTTOM NOISE SHIELD FLAP LH	TATA spare parts
265749200133	ASSY BOTTOM NOISE SHIELD FRONT	TATA spare parts
265749200134	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
265749200135	ASSY. BRACKET	TATA spare parts
265749200136	ASSY.FLAP(LH)	TATA spare parts
265749200137	ASSY. BRACKET	TATA spare parts
265749200138	ASSY.BRACKET	TATA spare parts
265749200139	ASSY NOISE SHIELD (REAR)	TATA spare parts
265749200140	ASSY.FLAP.(RH)	TATA spare parts
265749200141	ASSY.BRACKET	TATA spare parts
265749200142	ASSY.FRONT EXHAUST PIPE WITH BELLOW	TATA spare parts
265749200143	ASSY.BRACKET (SILENCER MTG.TOP)	TATA spare parts
265749200144	ASSY/PLATE WITH HOOK (FOR SILENCER MTG)	TATA spare parts
265749200145	ASSY.PLATE WITH HOOK	TATA spare parts
265749200147	ASSY.MOUNTING STRAP (SILENCER MTG.)	TATA spare parts
265749200148	ASSY.FRONT EXHAUST PIPE (WITH FLEXIBLE B	TATA spare parts



265749200154	EXHAUST PIPE ASSY WITH FLEX JOINT FRONT	TATA spare parts
265749200155	BRACKET ASSY CATCON MTG	TATA spare parts
265749200156	BRACKET ASSY FRONT PIPE MTG	TATA spare parts
265749203303	BRACKET	TATA spare parts
265749203309	BRACKET SILENCER MTG.	TATA spare parts
265749203312	BRACKET FRONT PIPE MTG BS6	TATA spare parts
265749204210	CLAMP DOC POC	TATA spare parts
265749210142	ASSY.EXHAUST PIPE-FRONT	TATA spare parts
265754100101	BATTERY CABLE +VE	TATA spare parts
265754100102	BATTERY CABLE -VE	TATA spare parts
265754200101	COVER RELAY CLUSTER	TATA spare parts
265754200117	INSTRUMENT CLUSTER (1:0.825)	TATA spare parts
265754200124	INSTRUMENT CLUSTER (1:0.85)	TATA spare parts
265754209952	SPEEDOMETER 1:0.825	TATA spare parts
265754209955	SPEEDOCABLE (JIS) 3000MM	TATA spare parts
265754209959	SPEEDOMETER 1.0825(6+1)BACKLIT	TATA spare parts
265754209963	SPEEDOMETER 1:0.875(6+1)BACKLIT	TATA spare parts
265754400105	CABIN LAMP ASSY BS6	TATA spare parts
265754400133	BRACKET ASSYROOF LAMP MTG BS6	TATA spare parts
265754400152	CABIN LAMP ASSY	TATA spare parts
265754500114	ASSY.COMBI SW.RHD FOR B/O	TATA spare parts
265754500114AE	ASSY.COMBI SW B/O W/ -1415-715	TATA spare parts
265754500116	ASSY.COBI SW.RHD FOR B/O	TATA spare parts
265754500118	ASSY.COMBI SW.RHD FOR B/O	TATA spare parts
265754600130	WIRING HARNESS MAIN	TATA spare parts
265754600133	WIRING HARNESS-MAIN BS6	TATA spare parts
265754600135	PIGTAILVEHICLE SPEED SENSOR BS6	TATA spare parts
265754600138	WIRING HARNESS TAIL BS6	TATA spare parts
265754600139	WIRING HARNESS MAIN BS6	TATA spare parts
265754600148	WIRING HARNESS ABS BS6	TATA spare parts
265754601606	WIRING HARNESS TAIL	TATA spare parts
265754601607	WIRING HARNESS MAIN	TATA spare parts
265754603301	BRACKETFUSE BOX MTG BS6	TATA spare parts
265754620107	W/H DANDA MAN SWITCH	TATA spare parts
265754620130	W/H MAIN RHD W/SUPER STR.	TATA spare parts
265754620131	TAIL CABLE SET B/LHD	TATA spare parts
265754690102	WIRING HARNESS PIGTAIL VEHICLE SPEED SEN	TATA spare parts
265758902801	PULLER	TATA spare parts
265758902803	PULLER	TATA spare parts
265758903301	WRENCH FOR GROOVED NUT	TATA spare parts
265758903302	PULLER FOR REMOVAL OF WHEEL HUB.	TATA spare parts
265758903303	DRIFT	TATA spare parts
265758903304	DRIFT	TATA spare parts
265758903305	SUPT.FOR REMOVAL OF FRT.INNER BRG.SEAL.	TATA spare parts
265758903306	DRIFT	TATA spare parts
265758903307	ASSY.SUPPORT BRACKET	TATA spare parts
265758903308	PULLER FOR REMOVAL OF KING PIN BRG.OUTER	TATA spare parts

265758903309	PULLER TO DRG	TATA spare parts
265758903310	PULLER FOR FRONT HUB BRG. WITH SEAL	TATA spare parts
265758903311	FLANGE	TATA spare parts
265758903312	CLAMPING TOOL	TATA spare parts
265758903313	CLAMPING TOOL	TATA spare parts
265758903314	M62-20L SLEEVE / 407-4X4	TATA spare parts
265758903315	PULLER / DRIVE SHAFT BUSH / 407-4X4	TATA spare parts
2657600003R40	ASSEMBLY BODY FITTED	TATA spare parts
2657600009R40	PARTIALLY FITTED CAB W/O ELECT&CONTROLS	TATA spare parts
265760100104	ASSY.BRACKET(FIRE EXTINGUISHER) BS6	TATA spare parts
265760100115	COWL COMPLT RHD	TATA spare parts
265760100117	ASSY.BRACKET (FENDER EXTEN) BS6	TATA spare parts
265760100123	CAB COMPLT RHD 407 4X4	TATA spare parts
265760100155	CAB COMPLT RHD 407 4X4	TATA spare parts
265760100174	ASSY.BODY PAINTED RHD SFC407 4X4 CAB	TATA spare parts
265760100185	ASSY.CAB COMPLETE-RHD(NON-ARMY FIT)	TATA spare parts
265760100191	SFC407 4X4 CLB BS-II (FITTED)	TATA spare parts
265760100192	SFC407 4X4 CAB BS-II (PAINTED)	TATA spare parts
265760108204	FENDER LH 407 4X4	TATA spare parts
265760108205	FENDER R.H.	TATA spare parts
265760110104	ASSY.CAB COMPLETE-RHD(NON-ARMY FIT)	TATA spare parts
265760110105	ASSY.BODY SHELL COMPLETE PAINTED RHD	TATA spare parts
265761600109	ASSY.SUPPORT LH [MUD FLAP] BS6	TATA spare parts
265761600110	ASSY.SUPPORT RH [MUD FLAP] BS6	TATA spare parts
265768400137	FLOOR MAT SET-RHD	TATA spare parts
265770000103	ASSY.LOAD BODY	TATA spare parts
265770000107	ASSY.LOAD BODY COMPLT.-RHD	TATA spare parts
265770200116	ASSY.TUBE WITH BKT. SPARE WHEEL MTG.	TATA spare parts
265770500105	ASSY CANOPY 407 4X4	TATA spare parts
265770500118	ASSY.CANOPY 407 4x4	TATA spare parts
265781100101	ASSYFRAME(MUD FLAP) BS6	TATA spare parts
265781906303	FENDER EXTENSION PIECE LH	TATA spare parts
265781906304	FENDER EXTENSION PIECE RH	TATA spare parts
265782400103	ASSY WIPER BLADE	TATA spare parts
265788100101	BONNET SIDE LH	TATA spare parts
265788100102	BONNET SIDE RH	TATA spare parts
265788500105	ASSY.SUPPORT (BUMPER MOUNTING)	TATA spare parts
265788500106	BUMPER ASSY WELDED	TATA spare parts
265788500107	BUMPER COMPLETE	TATA spare parts
265788500115	ASSY. BUMPER WELDED COMPLETE	TATA spare parts
265788700102	ASSY STAY TUBE LH RHD	TATA spare parts
265789100101	MOUNTING BRACKET REAR	TATA spare parts
265789106301	HEAT SHIELD(RUBBER MOUNTING BOTTOM) BS6	TATA spare parts
265798800101	ASSY MASCOT 4 X 4	TATA spare parts
265815400101	ALTERNATOR 12V/65A	TATA spare parts
265815400107	ALTERNATOR 3-SA23 12V65A 4GR-P	TATA spare parts
265815400115	FIXING BOLT KIT	TATA spare parts

265815400116	D E BRACKET ASSY	TATA spare parts
265815400117	ROTOR ASSY	TATA spare parts
265815400119	RECTIFIER ASSY.	TATA spare parts
265815400120	BRUSH ASSY	TATA spare parts
265815400125	CAPACITOR ASSY	TATA spare parts
265815400130	ALTERNATOR 12V 65AMP 4GR PULLEY	TATA spare parts
265815401201	TERMINAL STUD	TATA spare parts
265815403401	INSUL BUSH	TATA spare parts
265815403403	INSUL BUSH +VE	TATA spare parts
265815404601	FIXING SCREW	TATA spare parts
265815404901	FUSE LINK	TATA spare parts
265815404902	FUSE LINK	TATA spare parts
265815406801	CONNECTOR SUCTION ASSY	TATA spare parts
265815407501	INSUL BUSH	TATA spare parts
265815407702	PULLEY SINGLE GROOVE	TATA spare parts
265815408202	FAN	TATA spare parts
265815408203	NEGATIVE CONN/ANCHORING PLATE	TATA spare parts
265815408601	BEARING COLLAR	TATA spare parts
265815408602	BRUSH SPRING	TATA spare parts
265815409202	SEALING WASHER	TATA spare parts
265815409203	INSUL CUP WASHER	TATA spare parts
265815409904	REG & BRUSHBOX 65A NLS 9999TV659009	TATA spare parts
265829100107	PEDAL LEVER ASSY	TATA spare parts
265829100114	CLUTCH MASTER CYL. W/BOTTLE BS2/3/4	TATA spare parts
265829107702	RUB COVER CL & BR PEDAL	TATA spare parts
265829107704	RUB COVER CL & BR PEDAL	TATA spare parts
265829308701	RET SPRING CL & BR PEDAL	TATA spare parts
265830100118	ASSY ACCELERATOR CABLE(RHD)	TATA spare parts
265830100119	CABLE RHD IDLING ADJUST	TATA spare parts
265830100126	ACCELERATOR ROD RHD	TATA spare parts
265830100129	CABLE LHD IDLING ADJUST	TATA spare parts
265830100130	CABLE RHD IDLING ADJUST	TATA spare parts
265830107702	RUB SLEEVE ACCL ROD	TATA spare parts
265830108207	BKT ACCELERATOR	TATA spare parts
265830108211	BKT ACCELERATOR	TATA spare parts
265831000106	FRAME ASSY TATA ESTATE	TATA spare parts
265831200108	ASSY END CROSS MEMBER	TATA spare parts
265831200115	CROSS MEMBER FRONT	TATA spare parts
265831200128	CROSS MEMBER CENTRE BRG	TATA spare parts
265831200145	CROSS MEMBER G VALVE	TATA spare parts
265831208210	CROSS MEMBER ENG MTG RR	TATA spare parts
265831208247	SPACER (3.15 THK.)	TATA spare parts
265831400108	ASSY.TOWING HOOK.	TATA spare parts
265832100101	LOWER LINK COMPLT LH	TATA spare parts
265832100102	LOWER LINK COMPLT RH	TATA spare parts
265832100103	LOWER LINK COMPLT LH	TATA spare parts
265832100104	LOWER LINK COMPLT RH	TATA spare parts

265832100105	LOWER LINK COMPLT LH	TATA spare parts
265832100106	LOWER LINK COMPLT RH	TATA spare parts
265832100111	ASSY.LOWER LINK COMPLETE-LH	TATA spare parts
265832100112	LOWER LINK COMPLT RH	TATA spare parts
265832100113	ASSY LOWER LINK LHE NO	TATA spare parts
265832100116	ASSY LOWE4R LINK RH	TATA spare parts
265832100134	ASSY. PIVOT BUSH(FRT.SUSP.LOW LINK)BS1-4	TATA spare parts
265832105101	LOW ARM LH	TATA spare parts
265832408702	COIL SPRING REAR SUSPN	TATA spare parts
265832420152	RUB BUSH PANHARD ROD	TATA spare parts
265832420180	BUSH RUBBER BOTT LINK RR	TATA spare parts
265832420192	UPPER LINK COMPLT	TATA spare parts
265832420193	LOWER LINK COMPLT	TATA spare parts
265832427720	SPRING SEAT RR TOP 16MM	TATA spare parts
265832427721	SPRING SEAT RR TOP 13MM	TATA spare parts
265832430103	AXLE STOPPER RR NEW	TATA spare parts
265832600107	BKT S/ABS LH REAR TOP	TATA spare parts
265832600130	SHOCK ABSORBER REAR	TATA spare parts
265833000101	FRONT AXLE ASSY RH	TATA spare parts
265833000102	FRONT AXLE ASSY LH	TATA spare parts
265833805101	TIE ROD ARM RH	TATA spare parts
265833805102	TIE ROD ARM LH	TATA spare parts
265840300128	TUBE ASSY	TATA spare parts
265840300144	CLAMP ASSY	TATA spare parts
265840300147	SUPPORT COMPLETE	TATA spare parts
265840306305	PLASTIC BUSH	TATA spare parts
265842700101	LEVER PARKING BRAKE	TATA spare parts
265842700110	PARKING BRAKE LEVER COMP	TATA spare parts
265842700113	PARKING BRAKE UNIT	TATA spare parts
265842700136	HAND BR CABLE RR	TATA spare parts
265842700137	HAND BR CABLE FRT	TATA spare parts
265842700138	PAWL ROD ASSY	TATA spare parts
265842700147	BRACKET ASSY	TATA spare parts
265842700150	ASSEMBLY BRACKET (FRONT)	TATA spare parts
265842700154	ASSY.BRACKET	TATA spare parts
265842703201	BOLT (HAND BRAKE LEVER)	TATA spare parts
265842705602	KNOB	TATA spare parts
265842706701	CLEVIS PIN	TATA spare parts
265842707101	RATCHET	TATA spare parts
265842708202	LINK	TATA spare parts
265842708301	SHIM	TATA spare parts
265842708701	COMPRESSION SPRING	TATA spare parts
265842709902	PAWL	TATA spare parts
265842800112	TUBE ADAPTER TO GP VALVE	TATA spare parts
265842800113	TUBE GP VALVE TO BR HOSE	TATA spare parts
265842800115	TUBE ASSY RR BRAKE	TATA spare parts
265842803301	BKT RR BR PIPE R/A COVER	TATA spare parts

265843500102	ASSY. VACUUM BOOSTER 10 BS1/2/3/4	TATA spare parts
265843500110	ASSY.10 INCH VACUUM BOOSTER	TATA spare parts
265843505802	HOSE (VACUUM)	TATA spare parts
265844800120	HOSE PUMP TO GR BOX HI PR	TATA spare parts
265844800122	HOSE GR BOX TO TANK LO PR	TATA spare parts
265844800124	PIPE POWER STRG	TATA spare parts
265844805803	HOSE NLS HIGH PRESSURE 3/8	TATA spare parts
265844805806	HOSE HIGH PRESSURE 3/8	TATA spare parts
265844806817	BANJO	TATA spare parts
265846200101	ASSY. STRG. GEAR BOX	TATA spare parts
265846200117	TILT STRG UNIT COMPLT	TATA spare parts
265846200127	STRG COLUMN W/STRG LOCK	TATA spare parts
265846200128	STRG SPINDLE TOP	TATA spare parts
265846200140	GEAR BOX HOUSING	TATA spare parts
265846200143	STRG GEAR BOX	TATA spare parts
265846200145	ASSY.HSG.STG GEAR BOX (25-28) RATIO LHD	TATA spare parts
265846200146	SLEEVE ASSY	TATA spare parts
265846200147	STRG SPINDLE TOP	TATA spare parts
265846200148	ASSY TILT STRG COLUMN	TATA spare parts
265846203504	BOSS SHUTHAM COMBI SWITCH	TATA spare parts
265846203714	STRG COLUMN W/STRG LOCK	TATA spare parts
265846206306	RUBBER BELLOW TOP	TATA spare parts
265846206307	RUBBER BELLOW BOTTOM	TATA spare parts
265846207905	STRG SPINDLE-NLS-7918	TATA spare parts
265846207910	STRG SPINDLE TOP	TATA spare parts
265846207918	STRG SPINDLE BOTTOM 1X54	TATA spare parts
265846209201	WASHER 1MM	TATA spare parts
265846209202	TAB WASHER	TATA spare parts
265846300107	IDLER ARM RHD P/STRG	TATA spare parts
265846300108	IDLER ARM LHD P/STRG	TATA spare parts
265846300109	BKT IDLER ARM RHD P/S	TATA spare parts
265846300113	ASSY.IDLER ARM BRACKET POWER STG.	TATA spare parts
265846300117	BKT IDLER ARM RHD P/S M16	TATA spare parts
265846300118	BKT IDLER ARM LHD P/STRG M16	TATA spare parts
265846306003	PITMAN ARM RHD	TATA spare parts
265846306005	PITMAN ARM LHD	TATA spare parts
265846600116	STRAINER RESERVOIR	TATA spare parts
265846600118	DIPSTICK ASSY	TATA spare parts
265846600120	SERVICE KIT PT.NO.(RANE NO.30 40 00 05)	TATA spare parts
265846600121	CANNISTER FOR RESERVOIR P/STRG	TATA spare parts
265846600122	VALVE ASSY	TATA spare parts
265846600123	SEAL KIT MAJOR	TATA spare parts
265846600124	WORM & VALVE KIT	TATA spare parts
265846600125	PISTON RACK KIT	TATA spare parts
265846600126	ROLLER SHAFT RHD	TATA spare parts
265846600129	KIT SEAL STRG PUMP	TATA spare parts
265846600132	INPUT SHAFT SEAL KIT NO.69 14 32 00	TATA spare parts

265846600133	SHIM SET-RACE BRG.RANE NO.69 07 28 01	TATA spare parts
265846600136	BALL RING ASSY P/STRG	TATA spare parts
265846600138	PISTON RACK SEAL KIT	TATA spare parts
265846600139	PISTON RACK SEAL KIT NO.69 13 59 00	TATA spare parts
265846600140	PISTON RACK ASSY	TATA spare parts
265846600141	ROLLER SHAFT SEAL KIT	TATA spare parts
265846600159	WORM AND VALVE KIT (1X54 SERRATIONS)RHD	TATA spare parts
265846600163	R/S SEAL KIT WITH TAS 15 SEAL	TATA spare parts
265846600164	SIDE COVER TE/TS RHD	TATA spare parts
265846600165	SIDE COVER LHD	TATA spare parts
265846600166	SEAL KIT MAJOR	TATA spare parts
265846600168	STEERING PUMP 70 BAR	TATA spare parts
265846600173	SEAL KIT V PUMP INDIAN	TATA spare parts
265846600174	CANISTER V PUMP INDIAN	TATA spare parts
265846603101	BEARING NEEDLE CAGE	TATA spare parts
265846603102	NEEDLE BRG.	TATA spare parts
265846603103	NEEDLE BRG-SIDE COVER	TATA spare parts
265846603201	BOLT M8X20	TATA spare parts
265846603703	SIDE COVER -LHD	TATA spare parts
265846606501	WING NUT	TATA spare parts
265846606502	NUT	TATA spare parts
265846606503	STG GEARBOX SPARE BLEEDER SCREW WITH CAP	TATA spare parts
265846606504	NUT SPECIAL	TATA spare parts
265846606801	DISCHARGE ADAPTER	TATA spare parts
265846607703	O RING	TATA spare parts
265846607704	SHAFT SEAL IMP NLS 885526580001	TATA spare parts
265846607705	O RING CANNISTER & BODY	TATA spare parts
265846607706	O RING COVER CANNISTER	TATA spare parts
265846607707	O RING COVER CANNISTER	TATA spare parts
265846607708	O RING WORM COVER	TATA spare parts
265846607709	QUAD RING SEAL	TATA spare parts
265846607710	O RING RACK PAD ADJUSTER	TATA spare parts
265846607712	O RING SIDE COVER	TATA spare parts
265846607713	SHAFT SEAL.RANE NO.69 14 19 01	TATA spare parts
265846608001	RACK PAD ADJUSTER	TATA spare parts
265846608002	LOCK SCREW LEAD PAD	TATA spare parts
265846608201	WORM ADJUSTER COVER	TATA spare parts
265846608204	RACK PAD	TATA spare parts
265846608703	COVER LOCKER WIRE	TATA spare parts
265846608704	SPRING	TATA spare parts
265846609202	TAB WASHER	TATA spare parts
265846609903	LOCKER PIN	TATA spare parts
265846609904	COVER CYLINDER	TATA spare parts
265846609905	RACE BEARING	TATA spare parts
265846609906	SEAL RING VALVE SET	TATA spare parts
265847100109	SUCTION TUBE W/FILTER	TATA spare parts
265847100110	FILLER NECK TOP W/BKT	TATA spare parts

265847100119	FUEL TANK	TATA spare parts
265847100122	FUEL TANK 50 LTR	TATA spare parts
265847105301	SEALING RING SUCT FLANGE	TATA spare parts
265847107704	HOSE FUEL FILLING	TATA spare parts
265847107716	RUBBER PACKING	TATA spare parts
265847107716AE	RUBBER PACKING XEN DC XEN SC	TATA spare parts
265847109901	SUCTION ADAPTOR	TATA spare parts
265847504201	PIPE CLAMP	TATA spare parts
265847508204	BRACKET	TATA spare parts
265847508205	BRACKET	TATA spare parts
265847600103	RETURN LINE HOSE TO TANK	TATA spare parts
265847600104	SUCTION LINE TANK TO HOSE	TATA spare parts
265849200116	RUBBER HANGER SILENCER	TATA spare parts
265849200117	EXHAUST PIPE CENTRE TE	TATA spare parts
265849200120	SILENCER W/HANGER BKT NEW	TATA spare parts
265849200122	SILENCER W/HANGER BKT	TATA spare parts
265849205305	GASKET CAT.CONVERTER BSIII	TATA spare parts
265849205307	GASKET CAT.CONVERTER	TATA spare parts
265849205310	GASKET ( WITH 4 BOLTS)	TATA spare parts
265849205311	GASKET CAT.CONVERTER BSIII	TATA spare parts
265849205312	GASKET CAT.CONVERTER BSIII	TATA spare parts
265849205313	GASKET ( WITH 4 BOLTS)	TATA spare parts
265849205314	GASKET ( WITH 4 BOLTS)	TATA spare parts
265849205316	GASKET CAT.CONVERTER BSIII	TATA spare parts
265849205317	GASKET ( WITH 4 BOLTS)	TATA spare parts
265849205318	GASKET CAT.CONVERTER BSIII	TATA spare parts
265849205319	GASKET ( WITH 4 BOLTS)	TATA spare parts
265849207703	RUB HANGER EXH PIPE	TATA spare parts
265854108801	BATTERY CLAMPING STUD	TATA spare parts
265854108802	STUD BATTERY CLAMP	TATA spare parts
265854200101	INST CLST	TATA spare parts
265854200149	ASSY.RELAY & FUSE BOX COVER-4DL	TATA spare parts
265854209901	FUEL TANK UNIT	TATA spare parts
265854209906	FUEL TANK UNIT 50 LTS	TATA spare parts
265854209918	FUEL TANK UNIT	TATA spare parts
265854209920	FUEL TANK UNIT	TATA spare parts
265854209924	FUEL TANK UNIT[NEW ORINT.]	TATA spare parts
265854400101	ROOF LAMP	TATA spare parts
265854400105	ASSY CAB LAMP SE/SK 1613	TATA spare parts
265854400115	ASSY CAB LAMP SE/SK 1613	TATA spare parts
265854400120	DOOR SAFETY LAMP RED	TATA spare parts
265854400128	BLINKER LAMP RH	TATA spare parts
265854400129	TAIL LAMP LH	TATA spare parts
265854400131	KNOB ASSY	TATA spare parts
265854400132	ASSY CAB LAMP SE/SK 1613	TATA spare parts
265854400184	DOOR SAFETY LAMP	TATA spare parts
265854400193	HEAD LAMP LH	TATA spare parts

265854400194	HEAD LAMP RH	TATA spare parts
265854409201	U WASHER	TATA spare parts
265854410112	BLINKER LAMP LH W/BULB	TATA spare parts
265854410116	BLINKER LAMP LH	TATA spare parts
265854410118	BLINKER LAMP RH	TATA spare parts
265854410124	TAIL LAMP LH	TATA spare parts
265854410126	TAIL LAMP RH	TATA spare parts
265854410167	BLINKER LAMP LH W/BULB	TATA spare parts
265854410179	BLINKER LAMP LH W/BULB	TATA spare parts
265854410195	HEAD LAMP RH RHD	TATA spare parts
265854410196	ASSY.H/L W/E'MARK BULBS LH-RHD	TATA spare parts
265854420116	ASSY.ECERT H/LW/EMRK BULB RH LHD	TATA spare parts
265854420117	ASSY.ECERT.H/LW/EMRK BULB LH-LHD	TATA spare parts
265854500122	A/C SWITCH	TATA spare parts
265854500123	W/W SWITCH 4 PIN RH	TATA spare parts
265854500124	W/W SWITCH 4 PIN LH	TATA spare parts
265854500125	W/W SWITCH 5 PIN RH	TATA spare parts
265854500126	W/W SWITCH 5 PIN LH	TATA spare parts
265854500134	STRG LOCK CUM IGN SWITCH	TATA spare parts
265854500140	ASSY.W/W SWITCH L.H. 4 PIN	TATA spare parts
265854500141	W/W SWITCH 5 PIN LH	TATA spare parts
265854500142	A/C SWITCH	TATA spare parts
265854500165	IC.FLASHER.W/MTG.BKT.W/O.CONN.	TATA spare parts
265854500166	IC.FLASHER.W/MTG.BKT.W/O.CONN.	TATA spare parts
265854509907	PIN SOCKET W/W SWITCH	TATA spare parts
265854509908	CONNECTOR HOUSING	TATA spare parts
265854600134	ASSY.CABLE SET I CAB	TATA spare parts
265854600135	ASSY.CABLE SET II ENG.	TATA spare parts
265854600142	CABLE SET RR WIPER WASHER	TATA spare parts
265854600154	CABLE SET REAR LH DOOR	TATA spare parts
265854600179	W/H ROOF LAMP	TATA spare parts
265854600182	W/H REG PLATE LAMP	TATA spare parts
265854600184	W/H FUEL TANK	TATA spare parts
265854600185	W/H REAR WIPER	TATA spare parts
265854607512	RUBBER GROMMET.	TATA spare parts
265854608202	STRIP (FOR W/H SEC.AIR PUMP)	TATA spare parts
265854610103	W/H CABIN RHD	TATA spare parts
265854610104	W/H FRONT RHD	TATA spare parts
265854610105	W/H TAIL RH RHD	TATA spare parts
265854610106	W/H TAIL LH RHD	TATA spare parts
265854610108	W/H DOOR FRONT RH	TATA spare parts
265854610118	W/H DOOR REAR RH	TATA spare parts
265854610136	CABLE SET AC 1	TATA spare parts
265854610191	ASSY A/C CABLE SET	TATA spare parts
265854620144	W/H CTRL.HSG.A/C W/O HEATING	TATA spare parts
265854700109	BLOCON UNIT	TATA spare parts
265854700112	ASSY.BLOCON UNIT MOUNTING BRACKET-RHD.	TATA spare parts



265854702001	THERMOAMPLIFIER	TATA spare parts
265854704902	VACCUM SOLENOID VALVE SUB	TATA spare parts
265854705502	DUAL PR SWITCH	TATA spare parts
265854705503	DUAL PRESSURE SWITCH	TATA spare parts
265854706001	THERMISTOR	TATA spare parts
265854709901	BLOWER RESISTOR	TATA spare parts
265854709902	VARIABLE RESISTOR SW	TATA spare parts
265854709906	BLOWER RESISTOR 3POLE SUMO	TATA spare parts
265854709908	BULB WEDGE BASE 12V1.4W	TATA spare parts
265854709910	BLOWER MOTOR	TATA spare parts
265854709911	FAN BLOWER SUB RHD	TATA spare parts
265854900127	DRIVE UNIT RH 500MM ED	TATA spare parts
265854900141	MASTER FOLLOWER RR LH	TATA spare parts
265854900142	MASTER FOLLOWER RR RH	TATA spare parts
265854904606	KIT WIN WIND SYSTEM RH	TATA spare parts
265854909903	CABLE W/WINDING 477MM	TATA spare parts
265854909905	DRIVE PINION CENLOCK UNIT	TATA spare parts
265854910105	CONTROL UNIT	TATA spare parts
265854910106	MASTER FOLLOWER B	TATA spare parts
265854910107	MASTER FOLLOWER A	TATA spare parts
265854910108	MASTER FOLLOWER D	TATA spare parts
265854910109	MASTER FOLLOWER C	TATA spare parts
265854910116	KIT CENTRAL LOCK SYSTEM	TATA spare parts
265858903201	PULLER	TATA spare parts
265858903202	PULLER	TATA spare parts
265858904602	INPUT SHAFT OIL SEAL PRESSING TOOL	TATA spare parts
265858904603	S/SHAFT OIL SEAL ASSY. SLEEVE	TATA spare parts
265858904604	SECTOR SHAFT OIL SEAL MANDREL	TATA spare parts
265858904605	SECTOR SHAFT OIL SEAL PRESSING TOOL	TATA spare parts
265858904606	VALVE SEAL MANDREL	TATA spare parts
265858904608	END COVER WRENCH ADAPTOR (VALVE/WORM)	TATA spare parts
265860000130	BODY SHELL WITH DOORS (TATA ESTATE)	TATA spare parts
265860100104	LID ASSY	TATA spare parts
265860100113	TIE MEMBER COMPLT	TATA spare parts
265860100118	PLATE ASSY	TATA spare parts
265860100134	ASSY BRACKET HEAD LAMP	TATA spare parts
265860100140	TIE MEMBER COMPLT RHD	TATA spare parts
265860100144	ASSY.TIE MEMBER FRONT RHD	TATA spare parts
265860100151	ASSY TIE MEMBER COMPLETE	TATA spare parts
265860108239	TIE MEMBER	TATA spare parts
265860108240	TIE MEMBER	TATA spare parts
265860600102	MUDGUARD FRONT LH RHD	TATA spare parts
265860600104	PANEL INNER BONNET LH RHD	TATA spare parts
26586060010420	ASSY PNLINNER S/B LH WITH WELD NUT & SPT	TATA spare parts
265860600105	PANEL INNER BONNET RH RHD	TATA spare parts
26586060010520	ASSY PNL INR S/B RH WITH WELDNUT & SUPRT	TATA spare parts
265860600118	PANEL INNER SIDE BONNET LH	TATA spare parts

265863108202	SIDE PANEL OUTER RH REAR	TATA spare parts
265863108217	REINF LH DOOR HINGE	TATA spare parts
265863108218	REINF RH DOOR HINGE	TATA spare parts
265863108244	REINF LH SIDE PANEL OUTER	TATA spare parts
265863108245	REINF RH SIDE PANEL OUTER	TATA spare parts
265863108252	REINF LH DOOR POST FRAME	TATA spare parts
265863108254	DOOR POST FRAME LH	TATA spare parts
265863108255	DOOR POST FRAME RH	TATA spare parts
265863108257	BRACKET REAR DOOR CHECK	TATA spare parts
265863108259	BKT DOOR CHECK	TATA spare parts
265863108260	DOOR POST FRAME LH LHD	TATA spare parts
265863108261	DOOR POST FRAME RH LHD.	TATA spare parts
26586310C254	DOOR POST FRAME LH	TATA spare parts
26586310C255	DOOR POST FRAME RH	TATA spare parts
26586310C260	DOOR POST FRAME LH	TATA spare parts
26586310C261	DOOR POST FRAME RH	TATA spare parts
265863608219	CORNER PANEL INNER RR LH	TATA spare parts
265863608220	CORNER PANEL INNER RR RH	TATA spare parts
265863608221	INNER PANEL LH B C POST	TATA spare parts
265863608222	INNER PANEL RH B C POST	TATA spare parts
265863608253	TAPPING PLATE	TATA spare parts
265865700104	ROOF STIFFENER FRT CENTRE	TATA spare parts
265865708204	ROOF STIFFENER FRONT	TATA spare parts
265865708207	ROOF STIFFENER CENTRE	TATA spare parts
265867100101	ASSY.RUBBER MOULD L.H.[FIXED WINDOW]	TATA spare parts
265867100102	RUB MOULD NLS FIXED WINDOW RH	TATA spare parts
265867102315	LAMINATED WIND SCREEN GLASS (TINTED)	TATA spare parts
265867106303	RUB MOULD REAR W/SHIELD	TATA spare parts
265868706302	MEL SHEET [DOOR]	TATA spare parts
265868800103	KIT FLOOR FELT	TATA spare parts
265868900114	COVER ASSY	TATA spare parts
265868900118	GLOVE BOX LOCK	TATA spare parts
265868900120	ASSY GLOVE BOX LOCK	TATA spare parts
265868900124	GLOVE BOX LOCK	TATA spare parts
265868900133	HEATER CONTROL WITH TR.IND.LAMP	TATA spare parts
265868900152	NACELL SET DARK GRAY	TATA spare parts
265868900154	NACELL SET RHD DARK GRAY	TATA spare parts
265868900155	ASSY.COVER DARK GRAY (H/B)	TATA spare parts
265868906314	DASH BOARD RHD	TATA spare parts
265868906316	CONSOLE BODY FRONT	TATA spare parts
265868906317	COVER FRONT CONSOLE	TATA spare parts
265868906320	BASE PLATE CONSOLE BLACK	TATA spare parts
265868906326	COVER HAND BRAKE CABLE	TATA spare parts
265868906328	REAR COVER CONSOLE	TATA spare parts
265868906329	LID RR COVER CONSOLE	TATA spare parts
265868906330	LID TOOL BOX	TATA spare parts
265868906345	CONSOLE BODY REAR	TATA spare parts

265868906346	SNAP COVER W/WIND SWITCH	TATA spare parts
265868906357	BODY FRONT (DARK GREY)	TATA spare parts
265868906360	REAR COVER(DARK GREY)	TATA spare parts
265868906361	BASE PLATE DARK GREY	TATA spare parts
265868906362	BODY FRONT-DARK GRAY (SOFT FEEL)	TATA spare parts
265868906363	BODY REAR-DARK GRAY (SOFT FEEL)	TATA spare parts
265868906364	REAR COVER -DARK GRAY (SOFT FEEL)	TATA spare parts
265868906501	SQUARE NUT	TATA spare parts
265869206316	SIDE BEADING CARPET [REAR] L.H.(BLACK)	TATA spare parts
265869206317	SIDE BEADING CARPET [REAR] R.H.(BLACK)	TATA spare parts
265869206380	SIDE BEADING CARPET (REAR)LH DARKER GRAY	TATA spare parts
265869206381	SIDE BEADING CARPET (REAR)RH DARKER GRAY	TATA spare parts
265869209901	PIN	TATA spare parts
265869506307	ROOF LINING	TATA spare parts
265872200122	DOOR SHELL LH	TATA spare parts
265872200123	DOOR SHELL RH	TATA spare parts
265872300107	DOOR LOCK COMP RH	TATA spare parts
265872300108	DOOR LOCK COMP LH	TATA spare parts
265872300111	ASSY DOOR HINGE LH	TATA spare parts
265872300112	ASSY DOOR HINGE RH	TATA spare parts
265872300114	ASSY.DOOR HINGE LH	TATA spare parts
265872300115	ASSY.DOOR HINGE RH	TATA spare parts
265872300116	POP UP KNOB	TATA spare parts
265872300117	ASSY INNER HANDLE	TATA spare parts
265872300119	ARM REST RH RHD	TATA spare parts
265872300125	DOOR CHECK FRONT	TATA spare parts
265872300126	ASSY INNER HANDLE	TATA spare parts
265872300127	ASSY INNER HANDLE	TATA spare parts
265872300127AE	ASSY.INNER HANDLE 2523	TATA spare parts
265872300128	DOOR HANDLE OUTER LH	TATA spare parts
265872300129	DOOR HANDLE OUTER RH	TATA spare parts
265872300130	DOOR LOCK FRT RH	TATA spare parts
265872300132	KEY PAIR CENTRAL LOCK	TATA spare parts
265872300135	STRIKER ASSY FOR FRONT & REAR DOOR LATCH	TATA spare parts
265872300156	DOOR HANDLE OUTER LH	TATA spare parts
265872300157	DOOR HANDLE OUTER RH	TATA spare parts
265872300160	KEY PAIR CENTRAL LOCK	TATA spare parts
265872300173	LINK FR DOOR CEN LOCK	TATA spare parts
265872300180	ASSY.LOCK DOOR FRONT LH.	TATA spare parts
265872300180AE	DOOR LOCK FRONT LH 2523	TATA spare parts
265872300181	ASSY. LOCK DOOR FRONT RH BS1/2/3/4/6	TATA spare parts
265872300181AE	DOOR LOCK FRONT RH 2523	TATA spare parts
265872300182	ASSY.DOOR STRIKER	TATA spare parts
265872300183	KIT DOOR LOCK W/STRG LOCK	TATA spare parts
265872300184	HANDLE OUTER W/O LOCK LH	TATA spare parts
265872300185	HANDLE OUTER W/O LOCK RH	TATA spare parts
265872300188	ASSY.OUTER DOOR HANDLE L.H	TATA spare parts

265872300189	ASSY.OUTER DOOR HANDLE R.H	TATA spare parts
265872300194	FUEL LID LOCK& TWO KEYS	TATA spare parts
265872300199	ASSY.DOOR CHECK FRONT-VENUS	TATA spare parts
265872300206	ASSY INNER HANDLE	TATA spare parts
265872300207	ASSY INNER HANDLE	TATA spare parts
265872300208	ASSY INNER HANDLE	TATA spare parts
265872300209	ASSY INNER HANDLE	TATA spare parts
265872302502	SEALING MOULD DOOR LH	TATA spare parts
265872302503	SEALING MOULD DOOR RH	TATA spare parts
265872306001	LINK LH INNER HANDLE	TATA spare parts
265872306005	LINK POP UP KNOB LH	TATA spare parts
265872306006	LINK POP UP KNOB RH	TATA spare parts
265872306026	LINK POP-UP KNOB LH	TATA spare parts
265872306027	LINK POP-UP KNOB RH	TATA spare parts
265872306309	SNAP COVER SINGLE CUTOUT	TATA spare parts
265872306310	SNAP COVER 4 CUT OUT	TATA spare parts
265872306311	GRIP FOR HANDLE	TATA spare parts
265872306314	HOLDER POP UP KNOB	TATA spare parts
265872308203	SPRING CLAMP INN CEN LOCK	TATA spare parts
265872310103	ASSY.INNER HANDLE LH(FRONT DOOR)	TATA spare parts
265872310104	DOOR HANDLE INNER RH	TATA spare parts
265872310107	POP UP KNOB DARKER GRAY	TATA spare parts
265872500117	WINDOW REGULATOR LH	TATA spare parts
265872500118	WINDOW REGULATOR RH	TATA spare parts
265872500121	WEATHER STRIP OUTER LH	TATA spare parts
265872500122	ASSY.WEATHER STRIP OUTER RH	TATA spare parts
265872500124	WINDOW REGULATOR RH	TATA spare parts
265872508201	SPRINGCLIP IN WEATH STRIP	TATA spare parts
265872508202	SPRINGCLIP OUT WEATH STRI	TATA spare parts
265872508203	SPRINGCLIP IN WEATH STRIP	TATA spare parts
265872700107	DOOR PADDING BLACK LH TE	TATA spare parts
265872700108	DOOR PADDING NLS BLACK RH TE	TATA spare parts
265872706302	COVER PADDING FR LH	TATA spare parts
265872706303	COVER PADDING FR RH	TATA spare parts
265872706308	COVER PADDING LH DOOR	TATA spare parts
265872706309	COVER PADDING RH DOOR	TATA spare parts
265873200102	GUIDE CHANNEL LH	TATA spare parts
265873200103	GUIDE CHANNEL RH	TATA spare parts
265873200112	DOOR SHELL RR LH TE	TATA spare parts
265873200113	DOOR SHELL RR RH TE	TATA spare parts
265873206302	PACKING	TATA spare parts
265873208221	CHANNEL QUARTER GLASS RR	TATA spare parts
265873300105	DOOR LOCK REAR RH	TATA spare parts
265873300107	DOOR HINGE BOTTOM LH	TATA spare parts
265873300108	DOOR HINGE BOTTOM RH	TATA spare parts
265873300109	DOOR HINGE TOP LH REAR	TATA spare parts
265873300110	DOOR HINGE TOP RH REAR	TATA spare parts

265873300114	OUTER SEALING RR LH DOOR	TATA spare parts
265873300115	OUTER SEALING RR RH DOOR	TATA spare parts
265873300124	INNER REAR HANDLE LH	TATA spare parts
265873300125	INNER REAR HANDLE RH	TATA spare parts
265873300130	DOOR CHECK REAR	TATA spare parts
265873300135	INNER HANDLE REAR RH	TATA spare parts
265873300144	KIT DOOR LOCK W/STRG LOCK	TATA spare parts
265873300153	OUTER HANDLE REAR LH	TATA spare parts
265873300154	OUTER HANDLE REAR RH	TATA spare parts
265873300159	DOOR LOCK OUTER LH RR	TATA spare parts
265873300160	DOOR LOCK OUTER RH RR	TATA spare parts
265873300187	DOOR HINGE TOP LH	TATA spare parts
265873300188	DOOR HINGE TOP RH	TATA spare parts
265873300191	DOOR HINGE BOTTOM LH	TATA spare parts
265873300192	DOOR HINGE BOTTOM RH	TATA spare parts
265873306001	PULL ROD POP UP KNOB	TATA spare parts
265873306002	BELL CRANK	TATA spare parts
265873306009	LINK OUTER HANDLE	TATA spare parts
265873306013	LINK POP UP KNOB	TATA spare parts
265873306019	LINK LH POPUP KNOB-LATCH	TATA spare parts
265873306024	BELL CRANK FRT POPUP KNOB	TATA spare parts
265873306301	PIN BELL CRANK POPUP KNOB	TATA spare parts
265873306302	BUSH BELLCRANK POPUP KNOB	TATA spare parts
265873306303	BUTTON B/CRANK POPUP KNOB	TATA spare parts
265873306304	HOLDER	TATA spare parts
265873500121	WINDOW REGULATOR REAR LH	TATA spare parts
265873500122	WINDOW REGULATOR REAR RH	TATA spare parts
265873500125	WEATHER STRIP OUTER LH	TATA spare parts
265873500131	DOOR GLASS HOLDER LH	TATA spare parts
265873500132	DOOR GLASS HOLDER RH	TATA spare parts
265873500135	WEATHER STRIP RR OUTER LH	TATA spare parts
265873500138	WINDOW REGULATOR LH RR	TATA spare parts
265873500139	WINDOW REGULATOR RH RR	TATA spare parts
265873500145	WIN REGULATOR LH MANUAL	TATA spare parts
265873500146	WIN REGULATOR RH MANUAL	TATA spare parts
265873500149	ASSY.WINDOW REGU.LH-MANUAL	TATA spare parts
265873500150	ASSY.WINDOW REGU.RH-MANUAL	TATA spare parts
265873500153	ASSY.WINDOW REGU.LH (MANUAL)TELCO O.DRG	TATA spare parts
265873500154	ASSY.WINDOW REGU.RH (MANUAL) TELCO O.DRG	TATA spare parts
265873500157	WEATHER STRIP RR INNER LH	TATA spare parts
265873502305	QUARTER GLASS RR LH TINT	TATA spare parts
265873502306	QUARTER GLASS RR RH TINT	TATA spare parts
265873502307	REGULAT GLASS RR LH TINT	TATA spare parts
265873502308	REGULAT GLASS RR RH TINT	TATA spare parts
265873502503	VELVET CHANNEL	TATA spare parts
265873506301	MOULD LH QUARTER WINDOW	TATA spare parts
265873506302	MOULD RH QUARTER WINDOW	TATA spare parts

265873506311	PACKING QUARTER WINDOW	TATA spare parts
265873700109	DOOR PADDING NLS BLACK LH TE	TATA spare parts
265873700110	DOOR PADDING BLACK RH TE	TATA spare parts
265873706307	COVER PADDING RR LH TE	TATA spare parts
265873706308	COVER PADDING RR RH TE	TATA spare parts
265874200119	TAIL GATE SHELL	TATA spare parts
265874300111	STRIKER ASSY	TATA spare parts
265874300113	HINGE LH TAIL GATE	TATA spare parts
265874300114	HINGE RH TAIL GATE	TATA spare parts
265874300124	COVER NUMBER PLATE	TATA spare parts
265874300125	HANDLE TAIL GATE TE	TATA spare parts
265874300133	BALANCER TAIL GATE	TATA spare parts
265874300140	BALANCER TAIL GATE	TATA spare parts
265874300141	BRACKET TAIL GATE SIDE	TATA spare parts
265874300142	DOVETAIL LH BODY SIDE	TATA spare parts
265874300143	DOVETAIL RH BODY SIDE	TATA spare parts
265874300144	DOVETAIL LH TAILGATE SIDE	TATA spare parts
265874300146	STOPPER BODY SIDE	TATA spare parts
265874300148	HATCH BACK DOOR LOCK	TATA spare parts
265874300151	ASSY STRIKER HATCH BACK	TATA spare parts
265874300152	HATCH BACK DOOR LOCK	TATA spare parts
265874300154	BALANCER TAIL GATE	TATA spare parts
265874300159	HATCH BACK DOOR LOCK	TATA spare parts
265874300161	STRIKER HATCH BACK	TATA spare parts
265874308301	SHIM DOVETAIL BODY SIDE	TATA spare parts
265874309901	MASCOT ESTATE	TATA spare parts
265874309902	T EMBLEM NLS	TATA spare parts
265874309903	CLIP T EMBLEM	TATA spare parts
265874309904	MASCOT TATA	TATA spare parts
265874309905	BALL PIN	TATA spare parts
265874700105	COVER PADDING HATCH BACK	TATA spare parts
265874700107	DOOR PADDING BLACK TG TE	TATA spare parts
265874706304	COVER	TATA spare parts
265881000101	TATA BADGE	TATA spare parts
265881000106	LOCK FUEL LID	TATA spare parts
265881100105	DECO BEAD LH FRT DOOR	TATA spare parts
265881100106	DECO BEAD RH FRT DOOR	TATA spare parts
265881100107	DECO BEAD LH REAR DOOR	TATA spare parts
265881100108	DECO BEAD RH RR DOOR	TATA spare parts
265881100114	MUD FLAP FRONT LH	TATA spare parts
265881100115	MUD FLAP FRONT RH	TATA spare parts
265881100117	MUD FLAP REAR RH	TATA spare parts
265881100118	HANDLE INNER REAR	TATA spare parts
265881100119	HANDLE INNER FRONT	TATA spare parts
265881100124	COVER INNNER LH RVM OUTER	TATA spare parts
265881100125	COVER INNNER RH RVM OUTER	TATA spare parts
265881100132	SEALING INN LH FRT DR	TATA spare parts

265881100133	SEALING INN RH FRT DR	TATA spare parts
265881100156	ASSY.SEALING INNER-FOR FRONT DOOR	TATA spare parts
265881100157	ASSY.SEALING INNER RH-FOR FRONT DOOR	TATA spare parts
265881106301	SEALING INN T G	TATA spare parts
265881106302	DECO BEAD LH FRT	TATA spare parts
265881106303	DECO BEAD RH FRT	TATA spare parts
265881106308	DECO BEAD LH REAR	TATA spare parts
265881106309	DECO BEAD RH REAR	TATA spare parts
265881106314	ROOF BEADING	TATA spare parts
265881106315	END CAP RH ROOF BEAD FRT	TATA spare parts
265881106316	END CAP LH ROOF BEAD FRT	TATA spare parts
265881106317	END CAP LH RF BEAD RR	TATA spare parts
265881106318	END CAP RH RF BEAD RR	TATA spare parts
265881106324	LINER LH	TATA spare parts
265881106325	LINER RH	TATA spare parts
265881106326	COVER INNER HANDLE	TATA spare parts
265881106330	LINER LH REAR WHEEL ARCH	TATA spare parts
265881106331	LINER RH REAR WHEEL ARCH	TATA spare parts
265881106343	COVER SILL FRONT	TATA spare parts
265881106344	COVER SILL REAR	TATA spare parts
265881106350	END CAP LH FIXED WINDOW	TATA spare parts
265881106351	END CAP RH FIXED WINDOW	TATA spare parts
265881106358	BEADING TIE MEMBER	TATA spare parts
265881106379	DECORATIVE BEADING LH REAR DOOR	TATA spare parts
265881106394	COVER SILL FRONT DARK GRAY	TATA spare parts
265881108202	SPRING CLIP ROOF BEADING	TATA spare parts
265881108206	COVER SHEET.	TATA spare parts
265881110109	COVER INNER LH-GRAY	TATA spare parts
265881110110	COVER INNER RH-GRAY	TATA spare parts
265881110111	ASSY.INTERNAL RVM-GREY	TATA spare parts
265881800102	MASCOT TATA -0110	TATA spare parts
265882400111	WIPER BLADE REAR	TATA spare parts
265882400112	KIT ELEC W/S WASHER REAR	TATA spare parts
265882400124	WIPER MTR REAR-RIS	TATA spare parts
265882400125	WIPER MOTOR REAR W/RIS	TATA spare parts
265882400131	KIT ELECTRICAL W/WASHER UNIT	TATA spare parts
265882406308	EXTENSION PIECE	TATA spare parts
265882409904	TWIN JET NOZZEL	TATA spare parts
265883400137	ASSY BLOWER COMPLETE (3 POLE RESISTOR)	TATA spare parts
265883400138	BLOWER RHD 4POLE SUB	TATA spare parts
265883400139	ASSY.BLOWER CPT.3P.RES.-LHD	TATA spare parts
265883400140	ASSY.BLW'R CPT.4P.RES (SUB)-LHD	TATA spare parts
265883500101	KIT FOR SUB.HTER ALU.HTR COIL-LHD	TATA spare parts
265883500109	KIT SUB.HTR W/HTR COIL RHD.	TATA spare parts
265888100102	SIDE BONNET RH TE	TATA spare parts
265888600102	BUMPER COMP REAR CENTRE	TATA spare parts
265888600105	BRACKET FRONT RH	TATA spare parts

265888600108	CORNER BUMPER RR LH	TATA spare parts
265888600109	CORNER BUMPER RR RH	TATA spare parts
265888700101	ASSY. CENTRE BONNET BS/4/6	TATA spare parts
26588870Z101	ASSY. BONNET CENTRE	TATA spare parts
265888800103	OLD T EMBLEM NLS	TATA spare parts
265888800105	T EMBLEM NLS	TATA spare parts
265888800108	T EMBLEM 207 MODIFIED	TATA spare parts
265888806302	FRONT CEN GRILL MODIFIED	TATA spare parts
265888806303	SPACER GRILL	TATA spare parts
265889100104	RUBBER MOUNTING CAB TOP	TATA spare parts
265889100109	RUBBER MOUNTING	TATA spare parts
265889106301	RUBBER MOUNTING CAB BOT	TATA spare parts
265891000111	SEAT BUCKET W/HD REST LH	TATA spare parts
265891000112	SEAT BUCKET W/HD REST RH	TATA spare parts
265891000115	SEAT BUCKET DR RHD	TATA spare parts
265891500103	BRACKET SEAT BELT	TATA spare parts
265893000102	REAR SEAT W/BACK REST	TATA spare parts
265893706303	COVER LH SEAT BACK REST	TATA spare parts
265915400102	12V 75A ALTERNATOR-W/VCC & 1-GR	TATA spare parts
265915400108	RECTIFIER ASSY	TATA spare parts
265930100102	ASSY.ACCL.PEDAL COMPLETE (LHD)	TATA spare parts
265930100106	ASSY ACCELERATOR CABLE RHD	TATA spare parts
265930100109	ASSY.ACC CABLE-LHD	TATA spare parts
265930100110	CABLE ACCELERATOR RHD	TATA spare parts
265930100111	ASSY. ACCL. CABLE - LHD	TATA spare parts
265930100117	ASSY.ACC.CABLE(RHD)	TATA spare parts
265930100120	ASSY.ACC.CABLE (RHD-4PL)	TATA spare parts
265930100123	ASSY.ACCELE.CABLE	TATA spare parts
265930100126	ACCELERATOR CABLE ARMY AMBU 4X4	TATA spare parts
265930100127	ASSY.ACCELE.ACABLE	TATA spare parts
265930100129	ASSY. ACC. CABLE L.H.D.	TATA spare parts
265930107101	LOCK PLATE	TATA spare parts
265930108201	TAB WASHER	TATA spare parts
265931000101	FRAME ASSY SIERRA	TATA spare parts
265931008202	FRONT SKIRT	TATA spare parts
265931008209	REAR SKIRT SHEET METAL	TATA spare parts
265931200114	RUBBER HANGER	TATA spare parts
265931200137	BRACKET FUEL FILTER	TATA spare parts
265931200143	CROSS MEMBER W/O G VALVE MTG BKT	TATA spare parts
265932100114	ASSY. BALL JOINT -UPPER W/B BS1/2/3/4	TATA spare parts
265932100114AE	ASSY BALL JT WISHBNE-XEN DC/SC	TATA spare parts
265932100115	BALL JOINT UPPER W/B	TATA spare parts
265932108702	COIL SPRING FRONT SUSPN	TATA spare parts
265932110104	CROSS MEMBER	TATA spare parts
265932110106	ASSY LOWER LINK LH	TATA spare parts
265932110108	ASSY LOWER LINK COML RH	TATA spare parts
265932300102	SHOCK ABSORBER FRONT	TATA spare parts



265932400109	PANHARD ROD W/BUSH RR	TATA spare parts
265932400112	LOWER LINK COMPLT	TATA spare parts
265932400116	RUB BUSH TOP LINK	TATA spare parts
265932400117	RUB BUSH BOTTOM LINK NEW	TATA spare parts
265932400118	LOWER LINK COMPLT	TATA spare parts
265932408701	COIL SPRING REAR SUSPN	TATA spare parts
265932600104	SHOCK ABSORBER REAR	TATA spare parts
265932800101	ASSY. ANTI ROLL BAR-COMPLETE	TATA spare parts
265932807701	RUBBER BUSH-FRT. ARB	TATA spare parts
265932900110	ASSY. ANTI ROLL BAR-REAR	TATA spare parts
265932907701	BEARING BLOCK	TATA spare parts
265940109961	VALVE FOR TUBELESS TYRE	TATA spare parts
265940300105	BKT SP WHEEL CARRIER	TATA spare parts
265940300110	ASSY BRACKET	TATA spare parts
265941100101	PROPELLER SHAFT FRONT	TATA spare parts
265941110101	PROPELLER SHAFT FR	TATA spare parts
265941120101	PROPELLER SHAFT REAR-NLS	TATA spare parts
265941300101	BRACKET ASSY	TATA spare parts
265941300102	CENTRE BEARING COMPLETE	TATA spare parts
265942300108	ASSY.WHEEL CYL.(20.64 DIA.)	TATA spare parts
265942300109	REP KIT WH/CYL 20.64D	TATA spare parts
265942300115	BRAKE ASSY RR RH NASBS	TATA spare parts
265942300123	REP KIT W/CYL RR MNR	TATA spare parts
265942300124	REP KIT W/CYL RR MJR	TATA spare parts
265942400103	G CONSCIOUS VALVE	TATA spare parts
265942409917	STICKER (BRAKE FLUID RESERVOIR)	TATA spare parts
265942700101	HAND BR CABLE RR	TATA spare parts
265942800101	TUBE ASSY	TATA spare parts
265942800102	TUBE ASSY	TATA spare parts
265942800106	TUBE ASSY	TATA spare parts
265942800112	BKT G VALVE	TATA spare parts
265942800126	TUBE ASSY	TATA spare parts
265942800127	TUBE ASSY	TATA spare parts
265944800107	PIPE ASSY	TATA spare parts
265944800118	PIPE ASSY	TATA spare parts
265944800141	LOW PRESSURE HOSE P/S	TATA spare parts
265944800148	ASSY HI PR. LINE	TATA spare parts
265944805802	SUCTION HOSE NLS PS NEW	TATA spare parts
265944806804	SOCKET RETURN PORT	TATA spare parts
265944806805	SOCKET	TATA spare parts
265944806810	SOCKET ( RETURN PORT )	TATA spare parts
265944807702	RUBBER CLAMP	TATA spare parts
265944808202	BRACKET HP HOSE CLAMPING	TATA spare parts
265946200109	SEAL KIT V/ PUMP	TATA spare parts
265946200112	KIT SEAL P/STRG	TATA spare parts
265946200113	SMALL COMPONENTS	TATA spare parts
265946200114	P/STRG G/BOX RHD	TATA spare parts

265946200116	HOUSING ASSY	TATA spare parts
265946200118	SECTOR SHAFT ASSY	TATA spare parts
265946200119	PISTON ASSY-RHD	TATA spare parts
265946200122	HOUSING COVER ASSY ZF	TATA spare parts
265946200124	ASSY.BRACKET (STG.COLUMN MTG.)	TATA spare parts
265946200168	ASSY POWER STRG GEAR BOX RHD (4x2)	TATA spare parts
265946200169	ASSY POWER STRG GEARBOX LHD	TATA spare parts
265946206302	BELLOW STRG COL BOTOM	TATA spare parts
265946207705	RUBBER SLEEVE	TATA spare parts
265946207706	O - RING SLEEVE	TATA spare parts
265946207707	O - RING	TATA spare parts
265946207708	SEALING RING	TATA spare parts
265946207710	SEAL SHAFT	TATA spare parts
265946207711	DUST SEAL	TATA spare parts
265946207712	SEALING RING FOR GEAR BOX	TATA spare parts
265946207902	STRG SPINDLE BOTTOM	TATA spare parts
265946207910	DIPSTICK	TATA spare parts
265946207911	HEX SCREW	TATA spare parts
265946208201	COVER SHEET	TATA spare parts
265946209904	WING NUT	TATA spare parts
265946209907	NEEDLE ROLLER BEARING 0635303804	TATA spare parts
265946209908	SNAP RING	TATA spare parts
265946300102	ASSY IDLER ARM COMPLETE (POWER STG LHD)	TATA spare parts
265946400101	ASSY STG WHEEL 400DIA 4SPOKE COL-GREY	TATA spare parts
265946400102	STRG WHEEL WITH T	TATA spare parts
265946400106	STEERING WHEEL	TATA spare parts
265946400107	ASSY STG WHEEL 400DIA 4SPOKE COL-GREY	TATA spare parts
265946400109	ASSY STG WHEEL-400DIA-4SPOK-BLACK	TATA spare parts
265946400110	ASSY STG WHEEL 400DIA 4SPOKE COL-GREY	TATA spare parts
265946406305	HORN PAD -GREY	TATA spare parts
265946600105	CENTRE LINK ASSY	TATA spare parts
265946800107	HIGH.PR.HOSE TM/TE/TS	TATA spare parts
265947100102	FILLER NECK TOP W/BKT	TATA spare parts
265947100106	FUEL TANK	TATA spare parts
265947100111	ASSY.RUBBER BUSH	TATA spare parts
265947100144	ASSY.FUEL TANK COMPLETE.(65LT)W/O VALVE	TATA spare parts
265947106913	SPACER TUBE (FUEL TANK MTG.)	TATA spare parts
265947107702	HOSE FUEL FILLING	TATA spare parts
265947109201	PLAIN WASHER	TATA spare parts
265947508201	BKT FUEL LINE CLAMPING	TATA spare parts
265947600101	PIPE BREATHER	TATA spare parts
265947600102	SUCTION LINE TANK TO HOSE	TATA spare parts
265947600103	RETURN LINE HOSE TO TANK	TATA spare parts
265947600126	ASSY. SUCTION PIPE (HOSE TO FILTER)	TATA spare parts
265947606903	TUBE RETURN LINE 10 X 0.7	TATA spare parts
265949200109	EXHAUST PIPE FRONT TS	TATA spare parts
265949200120	EXHAUST PIPE FRONT	TATA spare parts

265949200139	EXHAUST PIPE REAR	TATA spare parts
265954100103	BATTERY CABLE SUPPORT	TATA spare parts
265954100104	ASSY BATTERY CABLE +VE & -VE	TATA spare parts
265954108802	BATTERY CLAMING STUD	TATA spare parts
265954110101	BATTERY CABLE -VE 35MM	TATA spare parts
265954110102	BATTERY CABLE -VE	TATA spare parts
265954200108	SPEEDOMETER 1:1.10	TATA spare parts
265954200109	GAUGE FUEL/TEMP PCB TYPE	TATA spare parts
265954200110	RPM METER	TATA spare parts
265954200114	RELAY COVER 6 RELAYS	TATA spare parts
265954200116	INST CLST 1:1.0625	TATA spare parts
265954204901	PCB W/LOW FUEL LED	TATA spare parts
265954204903	GLOW PLUG TIMER UNIT T/C	TATA spare parts
265954204905	RELAY AUXILIARIES	TATA spare parts
265954204906	GLOW PLUG TIMER	TATA spare parts
265954204907	RELAY AUXILIARIES 12V	TATA spare parts
265954204908	COLD ADVANCE MODULE	TATA spare parts
265954209904	HORN LOW TONE	TATA spare parts
265954209906	TEMP.TRANSDUCER	TATA spare parts
265954209919	3.2 DIA.SPEEDOCBLE-JIS-TIP 2200	TATA spare parts
265954209920	SPEEDOCABLE 1300MM 3.2D	TATA spare parts
265954209921	SPEEDOCABLE 1250MM JIS	TATA spare parts
265954209928	SPEEDO 1:1:0625	TATA spare parts
265954209937	TEMP TRANSDUCER	TATA spare parts
265954209940	TEMPERATURE TRANSDUCER	TATA spare parts
265954209942	MULTIFUNCTION MODULE	TATA spare parts
265954209961	TANK UNIT(65 LTR)PIG TAIL	TATA spare parts
265954209963	FUEL TANK UNIT[NEW ORITN.] - OFFER	TATA spare parts
265954210114	RELAY BANK COVER	TATA spare parts
265954400103	REG PLATE LAMP	TATA spare parts
265954400106	LAMP READING	TATA spare parts
265954400181	ROOF LAMP W/'E MARK BULB W/O CONN	TATA spare parts
265954400183	ROOF LAMP	TATA spare parts
265954400188	ASSY READING LAMP	TATA spare parts
265954400189	ASSY READING LAMP	TATA spare parts
265954400199	FOG LAMP REAR	TATA spare parts
265954409901	REFLEX REFLECTOR RED VERI	TATA spare parts
265954410106	REV FOG LAMP LH	TATA spare parts
265954410123	5-FUNCT E CERT.T/L.W/ E MK.BULB LH BS1-4	TATA spare parts
265954410124	5-FUNCT E CERT.T/L.W/ E MK.BULB RH BS1-4	TATA spare parts
265954410127	5-FUNCT`E`CERT.T/L.W/`E`MK.BULB LH	TATA spare parts
265954410128	5-FUNCT`E`CERT.T/L.W/`E`MK.BULB RH	TATA spare parts
265954410131	ASSY TAIL LAMP LH	TATA spare parts
265954410132	ASSY TAIL LAMP RH	TATA spare parts
265954410135	ASSY. BLINKER LAMP WITH BULB LH BS1- 4	TATA spare parts
265954410136	ASSY. BLINKER LAMP WITH BULB RH BS1- 4	TATA spare parts
265954410139	`E`CERT.BLINKER /L.W/`E`MK.BULB LH	TATA spare parts

265954410140	'E'CERT.BLINKER/L.W/'E'MK.BULB RH	TATA spare parts
265954410143	ASSY BLINKER LAMP WITH BULB LH	TATA spare parts
265954410144	ASSY BLINKER LAMP WITH BULB RH	TATA spare parts
265954410147	ASSY BLINKER LAMP WITH BULB LH	TATA spare parts
265954410148	ASSY BLINKER LAMP WITH BULB RH	TATA spare parts
265954410161	HEAD LAMP RH RHD AUTO LEV	TATA spare parts
265954410162	HEAD LAMP LH RHD AUTO LEV	TATA spare parts
265954410163	ASY.E'CRT.H/L.W/E'MARK BLB RH-LHD	TATA spare parts
265954410164	HEAD LAMP LH LHD W/MOTOR	TATA spare parts
265954500102	PRESSURE SWITCH	TATA spare parts
265954500103	ASSY.FUSE BOX (12 POLE)	TATA spare parts
265954500108	A/C SWITCH	TATA spare parts
265954500112	SWITCH WINDOW REGULATOR	TATA spare parts
265954500130	COMBI SWITCH	TATA spare parts
265954500132	COMBI SWITCH RHD	TATA spare parts
265954500138	SWITCH REVERSE LIGHT	TATA spare parts
265954500140	DOOR SWITCH	TATA spare parts
265954500141	DOOR SWITCH BULLET	TATA spare parts
265954500142	DOOR SWITCH	TATA spare parts
265954500145	HEAD LAMP LEVELLING SW.[HORIZON]	TATA spare parts
265954500147	COMBI SWITCH	TATA spare parts
265954500148	HEAD LAMP LEVELLING SW.[HORIZON]	TATA spare parts
265954500149	TRANSFER CASE SELECTION SW.	TATA spare parts
265954500151	HEAD LAMP LEVELLING SW.[HORIZON]	TATA spare parts
265954500153	TRANF CASE SEL.SW SHUT SU	TATA spare parts
265954500155	COMBI SWITCH RHD	TATA spare parts
265954500156	COMBI SWITCH RHD	TATA spare parts
265954500163	DOOR SWITCH -	TATA spare parts
265954504602	FLASHER KIT	TATA spare parts
265954504901	RELAY GLOW PLUG 4ST TYPE	TATA spare parts
265954504902	RELAY	TATA spare parts
265954506304	FUSE BOX COVER BLUE	TATA spare parts
265954506907	PIANO KEY SW.DEMISTING(ILLU)	TATA spare parts
265954506909	PIANO KEY SW.DEMISTING (ILLU)	TATA spare parts
265954509907	SWITCH REVERSE LIGHT	TATA spare parts
265954600104	CABLE SET FRT TO TAIL	TATA spare parts
265954600109	CABLE SET A/C 2	TATA spare parts
265954600116	LAMP BACK LIGHTING	TATA spare parts
265954600117	CABLE SET C/LOCK FR-TAIL	TATA spare parts
265954600122	CABLE SET LOUDSPEAKR	TATA spare parts
265954600162	W/H HATCH BACK LAMP	TATA spare parts
265954600163	W/H POWER LOCK RR DOOR	TATA spare parts
265954600168	W/H CONTROL HSG W/O PCB	TATA spare parts
265954600187	W/H CABIN RHD	TATA spare parts
265954606311	CHANNEL [FOR HARNESS]	TATA spare parts
265954606312	COVER [FOR HARNESS CHANNEL]	TATA spare parts
265954610118	CABLE SET A/C 2	TATA spare parts

265954610146	W/H TAILGATE	TATA spare parts
265954610164	W/H ENGINE	TATA spare parts
265954620103	W/H STOP LIGHT SWITCH LHD	TATA spare parts
265954620104	WIRING HARNESS HORN [DOMESTIC]	TATA spare parts
265954700106	THERMOCONTROL ASSY	TATA spare parts
265954700107	LINEAR POTENTIOMETER	TATA spare parts
265954700108	BKT AMPLIFIER SVL	TATA spare parts
265954700110	RESISTOR ASSY	TATA spare parts
265954700124	KIT CONDEN FAN	TATA spare parts
265954700134	RESISTER 4 POLE W/PIGTAIL	TATA spare parts
265954700142	ASSY.COND.FAN UNIT [LARGER]-120W	TATA spare parts
265954705501	VAC SOL VALVE	TATA spare parts
265954709901	BLOWER MOTOR RHD	TATA spare parts
265954709902	FAN	TATA spare parts
265954709905	THERMISTER	TATA spare parts
265954709906	THERMO AMPLIFIER	TATA spare parts
265954709908	LINEAR POTENTIOMETER	TATA spare parts
265954709917	ASSY BLOWER SWITCH	TATA spare parts
265954809905	SPEAKER	TATA spare parts
265954809906	ANTENA RHD	TATA spare parts
265954900117	DRIVE UNIT LH 151.7 ED	TATA spare parts
265954900118	DRIVE UNIT RH 151.7 ED	TATA spare parts
265954900148	W/W MOTOR RH	TATA spare parts
265954900149	W/W MOTOR LH	TATA spare parts
265954900156	KIT CENTRAL LOCK SYSTEM	TATA spare parts
265954900167	TUBE W/WINDING 116.5MM	TATA spare parts
265954904603	KIT CENTRAL LOCK SYSTEM	TATA spare parts
265954904606	KIT WIN WIND SYSTEM RH	TATA spare parts
265954904607	KIT WINWIND LH-NLS	TATA spare parts
265954909904	BUSH DRIVE WIN WINDING	TATA spare parts
265954909906	CABLE W/WINDING 129MM	TATA spare parts
265958409925	TRANSFER LABEL-TURBO CHARGER	TATA spare parts
265958604005	CLAMP NUT	TATA spare parts
265958604005_niu01	CLAMP NUT	TATA spare parts
265958604007	CLAMP NUT	TATA spare parts
265958904003	SCISSORS JACK W/HANDLE	TATA spare parts
265958905001	TOOL BAG	TATA spare parts
265960100116	TIE MEMBER COMPLT	TATA spare parts
265960100131	BODY SHELL WITH DOORS (TATA SIERRA NA)	TATA spare parts
265960100177	ASSY.LID	TATA spare parts
265960108220	REINFORCEMENT LH.	TATA spare parts
265960108221	REINFORCEMENT RH.	TATA spare parts
265960120114	ASSY TIE MEMBER COMPLETE	TATA spare parts
265960600109	MUDGUARD FRONT LH	TATA spare parts
265960600112	ASSY. PANEL INNER SIDE BONNET RH	TATA spare parts
265960600113	MUDGUARD FRONT RH	TATA spare parts
265960600118	ASSY.MUDGUARD FRONT RH -RHD	TATA spare parts

265960600119	ASSY. PANEL INNER SIDE BONNET LH	TATA spare parts
26596060Z113	ASSY.MUDGUARD FRONT RH	TATA spare parts
265963000103	SIDE WALL LH	TATA spare parts
265963000104	SIDE WALL RH	TATA spare parts
265963100111	DOOR POST REAR LH	TATA spare parts
265963108201	PANEL RR BOTTOM OUTER LH	TATA spare parts
265963108202	PANEL RR BOTTOM OUTER RH	TATA spare parts
265963108243	PANEL OUTER CORNER LH	TATA spare parts
265963108244	PANEL OUTER CORNER RH	TATA spare parts
265963600127	BRACKET FENDER EXTN RR	TATA spare parts
265965700116	ASSY. SUPPORT PLATE.	TATA spare parts
265967102301	W/S GLASS	TATA spare parts
265967102302	FIXED GLASS LH GREY	TATA spare parts
265967102303	FIXED GLASS RH GREY	TATA spare parts
265967102304	GLASS TAIL GATE	TATA spare parts
265967102306	FIXED GLASS LH GREEN	TATA spare parts
265967102307	FIXED GLASS RH GREEN	TATA spare parts
265967102310	W/S GLASS	TATA spare parts
265967102311	W/S GLASS CLEAR	TATA spare parts
265967106301	RUB MOULD W/SHIELD GLASS	TATA spare parts
265967106302	RUB MOULD RR W/SHIELD	TATA spare parts
265967106303	RUB MOULD LH FIXED GLASS	TATA spare parts
265967106304	RUB MOULD RH FIXED GLASS	TATA spare parts
265967106308	RUB MOULD W/SHIELD GLASS	TATA spare parts
265968800131	ASSY.KIT-NOISE INSULATIONS (FIRE WALL)	TATA spare parts
265968806314	RUBBER MAT REAR	TATA spare parts
265968900113	VENTILATION NOZZLE REAR	TATA spare parts
265968900122	DASH BOARD RHD COMPLT	TATA spare parts
265968900147	ASSY CONTROL BKT COMPL.(AC)CONSOLE MTG.	TATA spare parts
265968900150	ASSY.CONTROL BKT COMPL.-HEATING	TATA spare parts
265968900151	ASSY CONTROL BKT COMPL(AC+HTR)CONSOL MT	TATA spare parts
265968906301	NACELLE BOTTOM	TATA spare parts
265968906353	BLANKING PIECE CENTRE CONSOLE	TATA spare parts
265968906355	NACELLE BOTTOM DARK GRAY	TATA spare parts
265968906361	DASH BOARD RHD - DARK GRAY	TATA spare parts
265968906368	DASH BOARD RHD D/G(S/F)WITH WIN.DEM C/O	TATA spare parts
265968906369	DASH BOARD LHD D/G (S/F)WITH WIN.DEM C/O	TATA spare parts
265968908004	CR.CSK.SCR.M6X35	TATA spare parts
265969206307	PLAST LINING FRT W/S LH	TATA spare parts
265969206308	PLAST LINING FRT W/S RH	TATA spare parts
265969206309	PLAST LINING WS FR UP CEN	TATA spare parts
265969206311	PLAST LINING BC POST RH	TATA spare parts
265969206312	PLAST LINING BOTT RAIL LH	TATA spare parts
265969206313	PLAST LINING BOTT RAIL RH	TATA spare parts
265969206314	PLAST LINING T/G POST LH	TATA spare parts
265969206316	PLAST LINING RR UP CENTRE	TATA spare parts
265969506327	ROOF LINING CLOTH	TATA spare parts

265972200110	DOOR SHELL RH	TATA spare parts
265972300102	GUIDE CHANNEL RH	TATA spare parts
265972300105	SEALING MOULD DOOR LH	TATA spare parts
265972300106	SEALING MOULD DOOR RH	TATA spare parts
265972300114	KIT DOOR LOCK W/STRG LOCK	TATA spare parts
265972300115	KIT DOOR LOCK W/STRG LOCK	TATA spare parts
265972306304	SNAP COVER DOUBLE CUTOUT	TATA spare parts
265972500103	WEATHER STRIP OUTER LH	TATA spare parts
265972500105	DOOR GLASS HOLDER LH RHD	TATA spare parts
265972500106	DOOR GLASS HOLDER RH RHD	TATA spare parts
265972500109	WINDING REGULATOR LH	TATA spare parts
265972500110	WINDING REGULATOR RH	TATA spare parts
265972500117	WEATHER STRIP OUTER FR LH	TATA spare parts
265972500118	WEATHER STRIP OUTER FR RH	TATA spare parts
265972500121	WIND REGULATOR FRT LH	TATA spare parts
265972500125	WIND REGULATOR FRT LH	TATA spare parts
265972500126	WIND REGULATOR FRT RH	TATA spare parts
265972500135	WEATHER STRIP INN FR LH	TATA spare parts
265972500137	WEATHER STRIP OUT FR LH	TATA spare parts
265972500138	WEATHER STRIP OUT FR RH	TATA spare parts
265972502301	DOOR GLASS FR LH	TATA spare parts
265972502302	DOOR GLASS FR RH	TATA spare parts
265972502502	VELVET CHANNEL	TATA spare parts
265972706301	COVER PADDING LH DOOR	TATA spare parts
265972706302	COVER PADDING RH DOOR	TATA spare parts
265972706303	MAGAZINE POCKET	TATA spare parts
265972706307	PLASTIC SHEET	TATA spare parts
265974000101	TAIL GATE COMP W/FITMENTS	TATA spare parts
265974200102	TAIL GATE SHELL	TATA spare parts
265974208601	WASHER A-10	TATA spare parts
265974208602	WASHER A-10	TATA spare parts
265974300101	HINGE TAILGATE UPPER	TATA spare parts
265974300102	HINGE BOTTOM TAIL GATE	TATA spare parts
265974300105	DOOR CHECK TAILGATE	TATA spare parts
265974300106	PADDING TAIL GATE	TATA spare parts
265974300108	DOVETAIL UPPER T/G SIDE	TATA spare parts
265974300109	DOVETAIL LOWER T/G SIDE	TATA spare parts
265974300118	KIT DOOR LOCK W/STRG LOCK	TATA spare parts
265974306001	LINK INN HANDLE TAIL GATE	TATA spare parts
265974306003	LINK OUT HANDLE TAIL GATE	TATA spare parts
265974306302	DOVETAIL SIDE UPPER	TATA spare parts
265974306303	DOVETAIL SIDE LOWER	TATA spare parts
265974306307	SEALING OUTER (TAIL GATE).	TATA spare parts
265974306309	DOVETAIL UPPER BODY SIDE	TATA spare parts
265974306310	DOVETAIL LOWER BODY SIDE	TATA spare parts
265974306313	GRAB HANDLE-T/GATE	TATA spare parts
265974309901	MASCOT TATA	TATA spare parts

265981100107	ARM REST ASSY	TATA spare parts
265981100108	COVER INNER LH	TATA spare parts
265981100109	COVER INNER RH	TATA spare parts
265981100110	COVER SPARE WHEEL	TATA spare parts
265981100115	SUNVISOR RH	TATA spare parts
265981100122	SUNVISOR LH	TATA spare parts
265981100128	ASSY.SEALING INNER L.H.[FRONT DOOR]	TATA spare parts
265981100129	ASSY.SEALING INNER R.H.[FRONT DOOR]	TATA spare parts
265981100130	FENDER EXT.LH FRT BOTTOM	TATA spare parts
265981100131	FENDER EXT. FRT BOTTOM	TATA spare parts
265981100140	ASSY.R.V.MIRROR OUTSIDE RH(CONVEX)	TATA spare parts
265981100145	RV MIRROR OUTER RH PLAIN	TATA spare parts
265981100146	RV MIRROR OUTER LH PLAIN	TATA spare parts
265981100165	RV MIRROR OUTER RH LHD SP	TATA spare parts
265981100166	RV MIRROR OUTER LH RHD SP	TATA spare parts
265981100167	RV MIRROR OUTER RH PLAIN	TATA spare parts
265981100168	RV MIRROR OUTER LH PLAIN	TATA spare parts
265981100170	ASSY.R.V.MIRROR OUTSIDE LH (FLAT)	TATA spare parts
265981100191	SUNVISOR RH RHD	TATA spare parts
265981100198	COVER SPARE WHEEL	TATA spare parts
265981106301	MUD LINER LH INN FRT W/A	TATA spare parts
265981106302	MUD LINER RH INN FRT W/A	TATA spare parts
265981106303	COVER OUTER LH RVM OUTER	TATA spare parts
265981106304	COVER OUTER RH RVM OUTER	TATA spare parts
265981106315	MUD LINER LH OUTER FRT	TATA spare parts
265981106316	MUD LINER RH OUTER FRT	TATA spare parts
265981106317	ROOF CAP MIDDLE	TATA spare parts
265981106318	END CAP LH REAR	TATA spare parts
265981106333	FENDER EXT.RH REAR	TATA spare parts
265981106334	MUD FLAP FRONT LH	TATA spare parts
265981106335	MUD FLAP FRONT RH	TATA spare parts
265981106336	MUD FLAP REAR LH	TATA spare parts
265981106337	MUD FLAP REAR RH	TATA spare parts
265981106338	END CAP RH REAR	TATA spare parts
265981106346	ROOF BEADING	TATA spare parts
265981106350	ROOF CAP MIDDLE	TATA spare parts
265981106354	SEALING INN TAIL GATE	TATA spare parts
265981106357	FENDER EXT.LH REAR	TATA spare parts
265981106358	FENDER EXT.RH REAR	TATA spare parts
265981106359	FENDER EXT.LH FRT BODY	TATA spare parts
265981106360	FENDER EXT.RH FRT BODY	TATA spare parts
265981106362	ROOF CAP MIDDLE RH	TATA spare parts
265981106368	FENDER EXT.LH REAR	TATA spare parts
265981106369	FENDER EXT.RH REAR	TATA spare parts
265981106372	FENDER EXT.LH FRT	TATA spare parts
265981106388	CLIP FENDER EXTENSION	TATA spare parts
265981106396	DECO BEAD LH FRT	TATA spare parts



265981106398	DECO BEAD MIDDLE	TATA spare parts
265981107502	RUBBER GROMMET	TATA spare parts
265981107503	RUBBER GROMMET	TATA spare parts
265981107701	INSULATION BONNET CENTRE	TATA spare parts
265981108222	BKT CENTRE RR FENDER EXT	TATA spare parts
265981109903	PIN	TATA spare parts
265981110167	ASSY LEVER(FUEL TANK LID)	TATA spare parts
265981110170	ASSY LEVER-FUEL FILLER RHD	TATA spare parts
265981110175	ASSY INNER R/V MIRROR ANTIGLARE	TATA spare parts
265981116309	MUD LINER RH INN FRT W/A	TATA spare parts
265981116345	BEADING FENDER EXT FRT	TATA spare parts
265981116352	FENDER EXTENSION BEADING (FRONT)-GREY	TATA spare parts
265981116354	FENDER EXTENSION BEADING (FRONT) RH-GREY	TATA spare parts
265981116358	GROMMET(CABLE FOR FUEL LID LEVER)	TATA spare parts
265981116359	COVER LH DARK GRAY	TATA spare parts
265981116360	COVER RH DARK GRAY	TATA spare parts
265981300101	DOVETAIL BOTTOM T/GATE	TATA spare parts
265981306301	DOVETAIL BOTTOM BODY SIDE	TATA spare parts
265981306305	FIBRE WASHER ( M6 )	TATA spare parts
265981308201	SHIM-DOVE TAIL BOTTOM	TATA spare parts
265981800102	MASCOT TATA 2.0D	TATA spare parts
265981800103	ASSY 207 MASCOT	TATA spare parts
265981800104	MASCOT TELCO SPORT	TATA spare parts
265981800105	MASCOT TURBO	TATA spare parts
265981800112	ASSY. 'TATA TDI' MASCOT	TATA spare parts
265981806304	MASCOT TATA SIERRA	TATA spare parts
265981903801	BKT ROOF CARRIER LH	TATA spare parts
265981903802	BKT ROOF CARRIER RH	TATA spare parts
265981903803	BKT MIDDLE ROOF CARRIER	TATA spare parts
265981906302	PLUG	TATA spare parts
265981906306	CAP(ROOF CARRIER BRACKET)	TATA spare parts
265981906903	TUBE ROOF CARRIER	TATA spare parts
265981908201	PLATE WASHER	TATA spare parts
265982400102	WIPER ARM LH RHD	TATA spare parts
265982400113	ASSY.WIPER ARM R.H.	TATA spare parts
265982400114	WIPER ARM LH	TATA spare parts
265982400127	WIPER MOTOR REAR W/RIS	TATA spare parts
265982400128	KIT WIPER RHD	TATA spare parts
265982400135	KIT WIPER REAR	TATA spare parts
265982400137	WIPER ARM LH LHD	TATA spare parts
265982400145	KIT FOR ELECT.W/S.WASHER	TATA spare parts
265982400146	KIT FOR ELECT.W/S.WASHER	TATA spare parts
265982400171	ASSY.PLATE [W/S.WASHER BOTTLE]	TATA spare parts
265982400178	ASSY. WIPER ARM RH RHD	TATA spare parts
265982408203	BRACKET [W/S.WASHER BOTTLE MTG.]	TATA spare parts
265982480103	WIPER ARM REAR	TATA spare parts
265982480104	WIPER BLADE REAR	TATA spare parts

265982480105	ASSY.WIPER KIT(REAR WIPER SYSTEM)[O.DRG]	TATA spare parts
265982480110	KIT ELEC W/S WASHER REAR	TATA spare parts
265983100104	RECEVIER DRYER	TATA spare parts
265983100105	BKT RECEVER DRIER MTG	TATA spare parts
265983100108	HOSE SUCTION	TATA spare parts
265983100127	THERMO EXPAN VALVE	TATA spare parts
265983100128	DRAIN VALVE	TATA spare parts
265983100133	VACCUM SOLENOID VALVE	TATA spare parts
265983100135	TUBE LIQUID R/D INLET	TATA spare parts
265983100141	HOSE DISCHARGE	TATA spare parts
265983100142	TUBE W/PR SW R/D OUT	TATA spare parts
265983100143	TANK RECEIVER DRIER	TATA spare parts
265983100144	ASSY BRACKET(FOR RECEIVER DRIER	TATA spare parts
265983100145	VACCUM SOLENOID VALVE	TATA spare parts
265983100146	HOSE SUCTION	TATA spare parts
265983100150	EVAPORATOR ASSY	TATA spare parts
265983100151	ASSY.THERMO EXPANSION VALVE .	TATA spare parts
265983104201	CLAMP VACUUM HOSE	TATA spare parts
265983105804	VACUUM HOSE 250MM	TATA spare parts
265983105806	HOSE VACUUM	TATA spare parts
265983105808	HOSE VACCUM	TATA spare parts
265983106322	SEALING FOAM A	TATA spare parts
265983106323	SEALING FOAM B	TATA spare parts
265983106350	GROMMET (FOR DRAIN TUBE)	TATA spare parts
265983106353	HOSE DRAIN A/C	TATA spare parts
265983106807	DRAIN NIPPLE	TATA spare parts
265983106808	DRAIN NIPPLE (FOR DUCT)	TATA spare parts
265983108205	STAY THERMO SENCER	TATA spare parts
265983108214	PIPE RETAINER 5/8	TATA spare parts
265983108216	CLAMP SUCTION PIPE	TATA spare parts
265983108233	CLAMP DISCHARGE HOSE	TATA spare parts
265983108253	CLAMP EVAPORATOR PIPES	TATA spare parts
265983108254	SUPPORT (MAIN CABLE HARNESS)	TATA spare parts
265983108260	CLAMP SUCTION HOSE	TATA spare parts
265983108262	CLAMP PIPING	TATA spare parts
265983108284	STAY BRACKET	TATA spare parts
265983108297	CLAMP R/D INLET TUBE	TATA spare parts
265983108299	CLAMP (RD OUTLET)	TATA spare parts
265983109915	KIT CONDENSER FAN	TATA spare parts
265983110104	BKT BLOWER MTG RHD	TATA spare parts
265983110107	ASSY AIR DUCT-RHD	TATA spare parts
265983110110	BLOWER RHD	TATA spare parts
265983110124	FRESH AIR VALVE RHD	TATA spare parts
265983110125	FAN CONDENSOR	TATA spare parts
265983110128	AIR DUCT RHD	TATA spare parts
265983110139	BLOWER RHD	TATA spare parts
265983110145	TUBE EVAPORATOR INLET	TATA spare parts

265983110146	SUCTION HOSE ASSY	TATA spare parts
265983110149	AIR DUCT RHD FRP	TATA spare parts
265983110153	DUCT MTG PLATE	TATA spare parts
265983110155	TUBE DISCHARGE	TATA spare parts
265983110156	TUBE LIQUID CONDENSOR	TATA spare parts
265983110157	ASSY COIL HOUSING (AC)(FRP)-RHD (SUB)	TATA spare parts
265983110158	ASSY.COIL HOUSING (A.C)(PLASTIC)-RHD	TATA spare parts
265983110160	ASSY BLOWER HOUSING - RHD	TATA spare parts
265983110165	ASSY.FRESH AIR VALVE (W/O CABLE) - L.H.D	TATA spare parts
265983110171	ASSY BRACKET-LH (FOR INDRAD FAN ON SUBRO	TATA spare parts
265983110172	ASSY BRACKET-RH (FOR INDRAD FAN ON SUBRO	TATA spare parts
265983110181	CONDENCER W/O FAN	TATA spare parts
265983110182	EVAPORATOR ASSY ORT	TATA spare parts
265983110183	INLET PIPE C/UNIT ORT	TATA spare parts
265983110186	RECEIVER DRIER ORT	TATA spare parts
265983110187	PIPE EVPINLET ORT RHD	TATA spare parts
265983110188	HOSE SUCTION ORT	TATA spare parts
265983110189	PIPE R/D INLET ORT	TATA spare parts
265983110190	PIPE R/D OUTLET ORT	TATA spare parts
265983110191	HOSE DISCHARGE ORT	TATA spare parts
265983110192	COOLING UNIT ORT	TATA spare parts
265983116310	DRAIN HOSE	TATA spare parts
265983116317	GROMMET AC SUCTION PIPE	TATA spare parts
265983116318	GROMMET AC LIQUID PIPE	TATA spare parts
265983116338	MOTOR PACKING	TATA spare parts
265983116349	GROMMET AC LIQ PIPE SUB	TATA spare parts
265983116350	GROMMET AC SUC PIPE SUB	TATA spare parts
265983116351	GROMMET PIPE COIL HSG SUB	TATA spare parts
265983116363	O RING 3/8	TATA spare parts
265983116384	HOSE - WINDOW DEMIST	TATA spare parts
265983116386	O RING 8 MM SUB HFC134A	TATA spare parts
265983116387	O RING 8 MM	TATA spare parts
265983116388	O RING 5/8	TATA spare parts
265983116392	DRAIN HOSE WITH GROMMET	TATA spare parts
265983116395	GROMMET DISCHARGE LINE	TATA spare parts
265983116396	GROMMET LIQUID LINE	TATA spare parts
265983116398	CONNECTOR R.H.(PLEN.TO VENT.NOZZLE)	TATA spare parts
265983116399	CONNECTOR L.H.(PLEN.TO VENT.NOZZLE)	TATA spare parts
265983120159	ASSY BRACKET(COIL HOUSING TO DUCT	TATA spare parts
265983120161	ASSY.BRACKET DUCT MTG. LH	TATA spare parts
265983120167	EVAPORATOR HFC134A SUB	TATA spare parts
265983120169	ASSY THERMO EXPAN.VALVE	TATA spare parts
265983120170	TANK R/DRIER HFC134A SUB	TATA spare parts
265983120179	EVAPORATOR RHD HFC134A	TATA spare parts
265983120180	AC+HTR UNIT HFC LHD SUB	TATA spare parts
265983126306	GROMMET FOR THERMISTER CABLE	TATA spare parts
265983126307	CONNECTOR RH(PLENUM CHEMBER TO VENT).	TATA spare parts

265983126308	CONNECTOR LH	TATA spare parts
265983130161	BRACKET BLOWER MTG RHD	TATA spare parts
265983130162	BRACKET BLOWER MTG LHD	TATA spare parts
265983130170	ASSY.BRACKET DUCT MOUTING.	TATA spare parts
265983300111	PUSH PULL CABLE GREEN	TATA spare parts
265983300112	PUSH PULL CABLE YELLOW	TATA spare parts
265983300141	PUSH PULL CABLE H/T WHITE	TATA spare parts
265983300142	ASSY.PUSH-PULL CABLE -PINK	TATA spare parts
265983300156	LINEAR POTENTIOMETER	TATA spare parts
265983300159	ASSY.PUSH PULL CABLE -BLACK	TATA spare parts
265983300161	ASSY.PUSH PULL CABLE -GRAY	TATA spare parts
265983300162	ASSY.PUSH PULL CABLE -SKY BLUE	TATA spare parts
265983300164	PUSH PULL CABLE RED	TATA spare parts
265983300169	ASSY.PUSH-PULL CABLE -PINK	TATA spare parts
265983300170	PUSH PULL CABLE BLACK	TATA spare parts
265983300172	ASSY PUSH PULL CABLE GREY	TATA spare parts
265983300173	ASSY.PUSH PULL CABLE SKY BLUE	TATA spare parts
265983300178	ASSY.PUSH PULL CABLE	TATA spare parts
265983300179	VENTILATION CABLE	TATA spare parts
265983300180	ASSY.PUSH PULL CABLED	TATA spare parts
265983300181	ASSY.PUSH PULL CABLE WHITE	TATA spare parts
265983300184	ASSY PUSH PULL CABLE -DARK BLUE	TATA spare parts
265983300187	ASSY.PUSH-PULL CABLE -PINK	TATA spare parts
265983300192	ASSY.PUSH PULL CABLE WHITE	TATA spare parts
265983300198	ASSY.CONTROL COVER(AC+HTR)	TATA spare parts
265983306301	CONTROL COVER	TATA spare parts
265983306338	CONTROL KNOB	TATA spare parts
265983310130	ASSY.PUSH-PULL CABLE	TATA spare parts
265983400114	ASSY.BRKT.FOR R/D MTG.	TATA spare parts
265983400139	CONDENSER HFC134A SUB	TATA spare parts
265983400180	ASSY TUBE LIQUID (COND OUTLET)-134A	TATA spare parts
265983400181	ASSY TUBE LIQUID(RD INLET)	TATA spare parts
265983400182	TUBE LIQUID R.D.OUT RHD	TATA spare parts
265983409903	AC VALVE CAP (HP)	TATA spare parts
265983410103	ASSY.HOSE DISCHARGE- 134A	TATA spare parts
265983410104	TUBE LIQUID COND OUTLET	TATA spare parts
265983410105	TUBE LIQUID REC DRI INLET	TATA spare parts
265983410106	ASSY.CONNECTOR (R.D.OUTLET)	TATA spare parts
265983410107	TUBE LIQUID REC DRI OUTLE	TATA spare parts
265983410109	ASSY.HOSE SUCTION	TATA spare parts
265983410123	ASSY HOSE SUCTION 4X4 LHD	TATA spare parts
265983410124	ASSY TUBE LQ (RD OUTLET-RHD)	TATA spare parts
265983500112	HEATER UNIT ASSY RHD	TATA spare parts
265983500115	ASSY.COIL HOUSING WITH ALUMINIUM	TATA spare parts
265983500121	ASSY.HEATER COIL	TATA spare parts
265983505802	RUBBER HOSE(HTR OUT-LET TO ENG.ELBOW)	TATA spare parts
265983505805	HOSE HTR OUTLET W/VALVE	TATA spare parts

265983505809	RUBBER HOSE (HEATER OUTLET-ENGINE ELBOW)	TATA spare parts
265988100101	SIDE BONNET LH	TATA spare parts
265988100102	SIDE BONNET RH	TATA spare parts
265988100107	SIDE BONNET LH	TATA spare parts
265988100108	SIDE BONNET RH	TATA spare parts
265988100109	SIDE BONNET LH TSDX	TATA spare parts
265988100110	SIDE BONNET RH TSDX	TATA spare parts
26598810Z109	ASSY.BONNET SIDE LH	TATA spare parts
26598810Z110	ASSY.BONNET SIDE RH	TATA spare parts
265988500106	BUMPER FRONT	TATA spare parts
265988500107	SUPPORT FR LH SKIRT	TATA spare parts
265988500108	SUPPORT FR RH SKIRT	TATA spare parts
265988500119	ASSY.SUPPORT R.H. FRONT BUMPER MTG.	TATA spare parts
265988500125BF	ASSY.BUMPER FRONT LH PAINTED ARCTIC WHIT	TATA spare parts
265988500125BL	ASSY.BUMPER FRONT LH PAINTED NEPTUNE BLU	TATA spare parts
265988500125BS	ASSY.BUMPER FRONT LH PAINTED S GREEN	TATA spare parts
265988500125CN	ASSY.BUMPER FRONT LH PAINTED IRISH CREAM	TATA spare parts
265988500126BF	ASSY.BUMPER FRONT RH PAINTED ARCTIC WHIT	TATA spare parts
265988500126BL	ASSY.BUMPER FRONT RH PAINTED NEPTUNE BLU	TATA spare parts
265988500126BS	ASSY.BUMPER FRONT RH PAINTED S GREEN	TATA spare parts
265988500126CN	ASSY.BUMPER FRONT RH PAINTED IRISH CREAM	TATA spare parts
265988508001	POINTED HEX.SCREW M8X27	TATA spare parts
265988508213	BUMPER FRONT LH	TATA spare parts
26598850821321	BUMPER FRNT LH CED COATED.[W/O P/COAT]	TATA spare parts
265988508214	BUMPER FRONT RH	TATA spare parts
26598850821421	BUMPER FRT RH CED COATED [W/O P/COAT]	TATA spare parts
265988600103	ASSY BRACKET LH	TATA spare parts
265988600104	BRACKET RH	TATA spare parts
265988600142	SIDE BUMPER RH	TATA spare parts
265988606303	RUB MOULD LH RR BUMPER	TATA spare parts
265988606304	RUB MOULD RH RR BUMPER	TATA spare parts
265988606307	CORNER BUMPER RR LH	TATA spare parts
265988606308	CORNER BUMPER RR RH	TATA spare parts
265988606309	CORNER BUMPER RR LH N1	TATA spare parts
265988606310	CORNER BUMPER RR RH N1	TATA spare parts
265988606319	CORNER BUMPER RR LH	TATA spare parts
265988606320	CORNER BUMPER RR RH	TATA spare parts
265988606322	SCREW GROMMET	TATA spare parts
265988606701	SQUARE NECK SCREW.	TATA spare parts
265988608212	SUPP BKT LH CORNER BUMPER	TATA spare parts
265988608213	SUPP BKT RH CORNER BUMPER	TATA spare parts
265988608220	REAR BUMPER CENTRE-LHD	TATA spare parts
265989100101	MTG BRACKET FRONT LH	TATA spare parts
265991000140	KNOB ASSY LH	TATA spare parts
265991000141	BUSH HEAD REST	TATA spare parts
265991000143	KNOB ASSY	TATA spare parts
265991000144	REAR LEVER CABLE	TATA spare parts

265991000145	SLIDER CABLE	TATA spare parts
265991000147	RECLINER RH	TATA spare parts
265991000150	KNOB ASSY RH	TATA spare parts
265991000172	SEAT BUCKET RH RHD	TATA spare parts
265991000196	SEAT BUCKET LH RHD	TATA spare parts
265991006301	VALANCECOVER CODR RHD/DR LHD	TATA spare parts
265991006302	VALANCECOVER CODR RHD CONSOLE SIDE SIERA	TATA spare parts
265991006314	VALANCE COVER CO-DR LHD DOOR SIDE	TATA spare parts
265991006319	VALANCE COVER LH	TATA spare parts
265991006320	VALANCE COVER RH	TATA spare parts
265991110101	RECLINER DRIVER RHD	TATA spare parts
265991110102	RECLINER DRIVER LHD	TATA spare parts
265991110103	KNOB RH DR RHD CO DR LHD	TATA spare parts
265991110104	KNOB LH DR LHD CO DR RHD	TATA spare parts
265991500101	KIT SEAT BELT NLS LH	TATA spare parts
265991500105	ASSY.BRACKET BOTTOM RH (SEAT BELT)	TATA spare parts
265991500107	ASSY.BRACKET BOTTOM LH(SEAT BELT)	TATA spare parts
265991500116	KIT SEAT BELT LH W/O SW 'E'	TATA spare parts
265991500117	KIT SEAT BELT RH W/O SW 'E'	TATA spare parts
265991500131	ASSY.SEAT BELT COMP.M/SWIC.`E RHD-RHW	TATA spare parts
265991500134	ASSY.SEAT BELT COMP.M/SWITCH.`E'LHD-RHW	TATA spare parts
266031200117	BKT BODY MTG LH	TATA spare parts
266031200119	BKT BODY MTG RH FRONT	TATA spare parts
266031200120	BUMPER MTG BKT FR LH	TATA spare parts
266031200121	BKT BODY MTG RH FRONT	TATA spare parts
266031200125	ASSY.FRONT CROSS MEMBER	TATA spare parts
266031400101	ASSY. TOWING HOOK - REAR	TATA spare parts
266031409901	TOWING HOOK - FRONT	TATA spare parts
266031700102	ASSY.NOISE SHIELD	TATA spare parts
266031700103	ASSY.BRACKET-R.H.	TATA spare parts
266031700104	ASSY.BRACKET-L.H.	TATA spare parts
266032100103	ASSY.CROSS MEMBER	TATA spare parts
266032100114	ASSY.CROSS MEMBER FRT.SUSP.	TATA spare parts
266032107903	TORSION BAR LH	TATA spare parts
266032800103	BKT ANTI ROLL BAR LH FRT	TATA spare parts
266032800104	ASSY.BRACKET RH (FRT.ARB.MTG.)	TATA spare parts
266041110101	PROPELLER SHAFT FRONT	TATA spare parts
266046200104	ASSY.SLEEVE	TATA spare parts
266046203102	SPHERICAL SUPPORT ( STEERING SPINDLE )	TATA spare parts
266046203301	Z BRACKET	TATA spare parts
266046207905	STEERING SPINDLE (MIDDLE)	TATA spare parts
266046208204	BRACKET	TATA spare parts
266046208302	SHIM	TATA spare parts
266046208309	SHIM 0.5MM	TATA spare parts
266046208310	SHIM (1.0 THK)	TATA spare parts
266049200112	PRE SILENCER ASSY	TATA spare parts
266049200116	EXHAUST PIPE FRONT	TATA spare parts

266049200128	ASSY EXHAUST PIPE FRT(TC W/O FLEX BELLO)	TATA spare parts
266054200114	CLUSTER 4X4 1:1:04	TATA spare parts
266054209906	SPEEDOCABLE 1900MM 3.2D	TATA spare parts
266054600112	W/H FRONT LHD 4X4	TATA spare parts
266060100126	TIE MEMBER COMPLT	TATA spare parts
266068906319	CONSOLE FRONT RHD DARK GRAY SOFT FEEL	TATA spare parts
266068906320	CONSOLE FRONT LHD DARK GRAY SOFT FEEL	TATA spare parts
266068906321	CONSOLE MIDDLE DARK GRAY SOFT FEEL	TATA spare parts
266068906322	DASH BOARD LHD(DARK GRAY SOFT FEEL)	TATA spare parts
266068906323	DASH BOARD RHD(DARK GRAY SOFT FEEL)	TATA spare parts
266081100108	FENDER EXT. NLS FRT	TATA spare parts
266081100109	FENDER EXT. NLS RH FRT	TATA spare parts
266081106301	FENDER EXT. LH FRT	TATA spare parts
266081106302	FENDER EXT. RH FRT	TATA spare parts
266081106303	MUDGUARD LINER INNER LH FRONT WHEEL ARCH	TATA spare parts
266081106304	MUDGUARD LINER INNER RH-RHD(FRT W/A)	TATA spare parts
266081106305	NOISE INSULATION 4X4	TATA spare parts
266081106307	MUD LINER LH INN FRT W/A	TATA spare parts
266081106308	MUDFLAP FRONT LH	TATA spare parts
266081106309	MUDFLAP FRONT RH	TATA spare parts
266081106314	MUDFLAP FRONT LH	TATA spare parts
266081106315	MUDFLAP FRONT RH	TATA spare parts
266081108201	BKT FRT LH FRT FENDER EXT	TATA spare parts
266081108202	BKT FRT RH FRT FENDER EXT	TATA spare parts
266081108203	BKT CENTRE FRT FENDER EXT	TATA spare parts
266081108204	BKT REAR FRT FENDER EXT	TATA spare parts
266081108205	BKT RR LH FRT FEND EXT	TATA spare parts
266081108206	BKT RR RH FRT FEND EXT	TATA spare parts
266081800102	MASCOT TATA TDI 4X4	TATA spare parts
266088500103	COVER LH FR BUMPER	TATA spare parts
266088500104	COVER RH FR BUMPER	TATA spare parts
266088500107	BUMPER ASSY COMP 4X4	TATA spare parts
266135000102	REAR AXLE ASSY W/BRAKES	TATA spare parts
266135000109	REAR AXLE 31/8 W/BRAKES	TATA spare parts
266135000113	ASSY LPT 709 TRUCK AXLE COMP WITH BRKS	TATA spare parts
266135000116	ASSY RA 709 SFC/LPT-31/8	TATA spare parts
266135000120	RR AXLE ASSY SCAM 31/8	TATA spare parts
266135000121	ASSY.R.A.COMP.WITH ASBESTOS BRKS.(31/9)	TATA spare parts
266135000124	ASSY.R.A.COMP.WITH NON/ASBS BRKS.(31/9)	TATA spare parts
266135000127	ASSY RA.709 NASBS BRKS W/LCRV 31/8.	TATA spare parts
266135000128	ASSY.R.A.COMP W/BRAKES W(28/9) RATIO OUT	TATA spare parts
266135000135	ASSY.R.A.COMP.WITH N/ASBS BRK(31/8)9TG VW	TATA spare parts
266135000137	ASSY.R.A.COMP.31/8 SINGLE TYRE DAOH BRKS	TATA spare parts
266135000138	ASSY.R.A.COMP W/BRAKES 28/9 RATIO BSIII	TATA spare parts
266135000139	ASSY R.A COMP WITH ASBS BRK 28/9 9TG VW	TATA spare parts
266135000140	ASY RA COMP W/BRAKES(28/9)W/O LCRV W/AB	TATA spare parts
266135000142	ASSY.R.A.COMP W/NON ASBESTOS BRAKES (28/	TATA spare parts

266135000143	ASSY.R.A.COMP W/BRAKES 28/9 RATIO BSIII	TATA spare parts
266135000144	ASSY.R.A.COMP.WITH ASBESTOS BRKS (31/8)	TATA spare parts
266135000147	ASSY.REAR AXLE COMPLETE(RAS 104)WITH BRA	TATA spare parts
266135000148	RA LPT 912 (31/9)	TATA spare parts
266135000149	"ASSY R.A COMP (31/8),W/ABS,(9T GVW)."	TATA spare parts
266135000152	ASSY RA COMP (32/7) RE-BREATHER 9T GVW.	TATA spare parts
266135000153	ASSY. REAR AXLE COMPLETE 33/8	TATA spare parts
266135000155	RA LPT 909 EX2 BSII ( 33/8 )	TATA spare parts
266135000157	ASSY. RA COMP (33/8) W/VOSS CONNECTOR	TATA spare parts
266135000158	ASY RA COMP 33/8 LCRV W/VOSS CONNECTOR.	TATA spare parts
266135000169	ASSY 709 RA.COMP 31/8 S-CAM W/VOSS CONT.	TATA spare parts
266135000170	ASSY 909 RA COMP 32/7 W/BIGGER A SHAFT.	TATA spare parts
266135000171	ASY RA COMP W/BRAKES (31/9) 9T W/VOSS C	TATA spare parts
266135000185	ASSY REAR AXLE COMP (31/9) ABS	TATA spare parts
266135000186	ASY RA COMP (31/9) W/O ABS (9T GVW-REIN)	TATA spare parts
266135000187	ASSY RA COMP W/ 33/8 RATIO;OUTER OIL SEA	TATA spare parts
266135000188	ASSY 909 RA COMP 33/8 W/BIGGER A SHAFT O	TATA spare parts
266135000192	ASSY 909 RA COMP W/32/7 NASBS BRKS W/O L	TATA spare parts
266135000202	ASSY RA-1055 COMP 33/8 (4.125) SCAM 1730	TATA spare parts
266135000207	ASSY.RA-1055 COMP 34/7(4.857) TRUCK 1670	TATA spare parts
266135000220	ASSY REAR AXLE COMP. RA-1055 WDAOH BRK34	TATA spare parts
266135000229	ASSY. REAR AXLE COMP. RAS-104 31/8 W/BRK	TATA spare parts
266135000235	ASSY REAR AXLE COMP W/LCRV	TATA spare parts
266135000242	ASSY REAR AXLE COMP (32/7)S.TYRE;SPLIT H	TATA spare parts
266135000243	ASSY. REAR AXLE COMPLETE 33/8	TATA spare parts
266135000245	ASSY REAR AXLE COMP (32/7)	TATA spare parts
266135000248	ASSY RA COMP. 28/9 ABS OUTER OIL SEAL	TATA spare parts
266135000249	REAR AXLE COMP (34/7) SINGLE TYRE .	TATA spare parts
266135000253	REAR AXLE ASSY COMPL.W/O LCRV 33/8 C294	TATA spare parts
266135000266	REAR AXLE ASSY WITH BRAKE	TATA spare parts
266135000268	REAR AXLE ASSY	TATA spare parts
266135000269	REAR AXLE ASSY COMPL 32/7 RATIO 9T C294	TATA spare parts
266135000280	REAR AXLE ASSY ABS	TATA spare parts
266135000281	REAR AXLE ASSY ABS	TATA spare parts
266135000282	REAR AXLE ASSY ABS	TATA spare parts
266135000283	REAR AXLE ASSY ABS	TATA spare parts
266135000284	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
266135000285	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
266135000286	REAR AXLE ASSY ABS	TATA spare parts
266135000287	REAR AXLE ASSY ABS	TATA spare parts
266135000288	REAR AXLE ASSY	TATA spare parts
266135000290	REAR AXLE ASSY WITH BRAKE	TATA spare parts
266135000291	REAR AXLE ASSY	TATA spare parts
266135000292	REAR AXLE ASSY	TATA spare parts
266135000293	REAR AXLE ASSY	TATA spare parts
266135000296	REAR AXLE ASSY	TATA spare parts
266135000301	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts



266135000309	REAR AXLE ASSY	TATA spare parts
266135000324	REAR AXLE ASSY	TATA spare parts
266135000325	REAR AXLE ASSY WITH BRAKE	TATA spare parts
266135000328	REAR AXLE ASSY WITH HUB BS6	TATA spare parts
266135000337	AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135000340	REAR AXLE ASSY WITH BRAKE	TATA spare parts
266135000343	REAR AXLE ASSY BS6	TATA spare parts
266135000351	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135000353	AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135000357	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135000359	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135000360	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135000361	AXLE ASSY WITH HUB BS6	TATA spare parts
266135000362	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135000363	REAR AXLE ASSY WITH HUB BS6	TATA spare parts
266135000364	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135000366	REAR AXLE ASSY BS6	TATA spare parts
266135000367	AXLE ASSY WITH HUB BS6	TATA spare parts
266135000368	REAR AXLE ASSY BS6	TATA spare parts
266135000374	REAR AXLE ASSY BS6	TATA spare parts
266135000382	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135000383	REAR AXLE ASSY BS6	TATA spare parts
266135010102	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135050107	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135050111	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135050123	REAR AXLE ASSY WITH HUB BS6	TATA spare parts
266135050124	AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135050129	REAR AXLE ASSY WITH HUB ABS RA-1055 BANJ	TATA spare parts
266135050137	REAR AXLE ASSY WITH HUB ABS BS6-PH2	TATA spare parts
266135050146	REAR AXLE ASSY WITH HU BS6	TATA spare parts
266135050147	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135050148	RR AXLE ASSY WITH HUB 41/8 S-CAM BS6	TATA spare parts
266135050149	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266135050153	REAR AXLE ASSY WITH HUB BS6-PH2	TATA spare parts
266135050159	REAR AXLE ASSY WITH HUB BS6-PH2	TATA spare parts
266135050161	REAR AXLE ASSY WITH HUB BS6-PH2	TATA spare parts
266135050179	REAR AXLE ASSY WITH HUB BS6-PH2	TATA spare parts
266135050195	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
266135100104	COVER REAR AXLE HSG	TATA spare parts
266135100105	COVER ASSY	TATA spare parts
266135100108	REAR AXLE HOUSING	TATA spare parts
266135100110	REAR AXLE HOUSING	TATA spare parts
266135100116	ASSY RA HSG W/SUPPORT TUB	TATA spare parts
266135100119	CARRIER HOUSING ASSY WITH PLUMMER BLOCK	TATA spare parts
266135100120	ASSY.REAR AXLE HSG.WITH SUPP.TUBE COMP.	TATA spare parts
266135100127	ASSY R.A.HSG. W/SUPPORTING TUBE COMP.	TATA spare parts
266135100129	ASSY R.A HSG WITH SUPP.TUBE COMP 9T GVW	TATA spare parts

266135100130	ASSY REAR AXLE SUPP.TUBE COMP(R.H)9T GVW	TATA spare parts
266135100134	ASSY.R.A.HSG.W/SUPP.TUBE W/LCRV COMP.	TATA spare parts
266135100139	ASSY REAR AXLE HSG+SUPP.TUBE COMP W/ABS.	TATA spare parts
266135100140	ASY RA HSG WITH SUPP.TUBE COMP W/O LCRV	TATA spare parts
266135100154	ASY RA HSG W/SUPP TUBE COM REINFORCED-9T	TATA spare parts
266135100161	ASSY. REAR AXLE HSG. W/SUPPORT BS2/3/4	TATA spare parts
266135100164	ASSY RA BEAM W/PR RING+STUD+DOWEL RA-105	TATA spare parts
266135100165	ASSY RA BEAM MACH(112X110X10)RA1055TRUK	TATA spare parts
266135100168	ASSY RA HSG W/SUP TUBE COMPOUTER OIL SEA	TATA spare parts
266135100171	ASSY R.A BEAM M/CRA10551730 TRACKBUS.N	TATA spare parts
266135100172	ASSY RA BEAM W/P RING+STUD+DOWEL1730 T	TATA spare parts
266135100173	ASY REAR AXLE HSG W/SUPP TUBE COMP.	TATA spare parts
266135100180	ASY RA HSG WITH SUPP.TUBE COMP. WITH LCR	TATA spare parts
266135100183	ASSY REAR COVER (REAR AXLE HSG.) BS6	TATA spare parts
266135100186	ASSY. REAR AXLE HOUSING WITH SUPPORTING	TATA spare parts
266135100189	ASY RA SUPP TUBE COMP(RH) REINFORCED 9T	TATA spare parts
266135100190	ASY RA SUPP TUBE COMP(LH) REINFORCED 9T	TATA spare parts
266135100191	ASY RA HSG W/SUPP TUBE COM REINFORCED-9T	TATA spare parts
266135100192	ASY RA HSG W/SUP TUBE COMP9T-HUBOUTER	TATA spare parts
266135100194	ASY RA HSG W/SUPP TUBE COM ABS REINF-9T	TATA spare parts
266135100212	ASSY RA SUPP TUBE(RH)(REINFORCED)	TATA spare parts
266135100213	ASSY RA SUPP TUBE(LH)(REINFORCED)	TATA spare parts
266135100214	ASSY REAR AXLE HSG WITH SUPPTUBE COMP WI	TATA spare parts
266135100218	ASSY.RA HSG.COMP.W/SUPP.TUBE W/LCRV	TATA spare parts
266135100219	ASSY RA SUPP TUBE COMP SPGT BRK MTG FLNG	TATA spare parts
266135100224	REAR AXLE ASSY HSG W/PLUM BLOCK CVR	TATA spare parts
266135100227	REAR AXLE ASSY HSG W/SUP TUBE CO 9T C294	TATA spare parts
266135100229	REAR AXLE ASSY HSG.W/SUP.TUBE W/LCRV COM	TATA spare parts
266135100235	REAR AXLE ASSY HSG W/SUPP TUBE 9T ABS	TATA spare parts
266135100236	ASSY RA HSG WITH SUPP.TUBE COMP.(ABS)	TATA spare parts
266135100241	REAR AXLE HOUSING ASSY WITH SUPPORT TUBE	TATA spare parts
266135100243	REAR AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
266135100244	REAR AXLE SUPPORT TUBE ASSY RH	TATA spare parts
266135100245	REAR AXLE SUPPORT TUBE ASSY LH	TATA spare parts
266135100246	REAR AXLE HOUSING ASSY WITH SUPPORT TUBE	TATA spare parts
266135100247	REAR AXLE SUPPORT TUBE ASSY RH	TATA spare parts
266135100248	REAR AXLE SUPPORT TUBE ASSY LH	TATA spare parts
266135100249	REAR AXLE HOUSING ASSY WITH SUPPORT TUBE	TATA spare parts
266135100262	AXLE BEAM ASSY WITH SPINDLE BS6	TATA spare parts
266135100263	REAR AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
266135100264	AXLE BEAM ASSY WITH SPINDLE BS6	TATA spare parts
266135100265	REAR AXLE BEAM ASSY WITH RING &STUD BS6	TATA spare parts
266135100266	AXLE BEAM ASSY WITH SPINDLE BS6	TATA spare parts
266135100271	REAR AXLE ASSY WITH PRESSURE RING &STUD	TATA spare parts
266135100274	AXLE BEAM ASSY WITH SPINDLE BS6	TATA spare parts
266135100275	REAR AXLE BEAM ASSY WITH RING &AMP STUD	TATA spare parts
266135100277	REAR AXLE ASSY WITH PRESSURE RING STUD	TATA spare parts

266135100286	REAR AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
266135100288	REAR AXLE BEAM ASSY WITH STUD & DOWEL BS	TATA spare parts
266135100291	AXLE BEAM ASSY WITH SPINDLE BS6	TATA spare parts
266135100293	REAR AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
266135100294	RR AXLE BEAM ASSY WITH RING & STUD . BS6	TATA spare parts
266135100298	REAR AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
266135100301	AXLE BEAM ASSY WITH SPINDLE BS6	TATA spare parts
266135100312	AXLE BEAM ASSY WITH SPINDLE BS6-PH2	TATA spare parts
266135100313	REAR AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
266135100315	REAR AXLE ASSY WITH STUD & DOWEL BS6-PH2	TATA spare parts
266135100325	AXLE BEAM ASSY WITH SPINDLE BS6-PH2	TATA spare parts
266135100326	REAR AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
266135100340	AXLE BEAM ASSY WITH SPINDLE BS6-PH2	TATA spare parts
266135100346	REAR AXLE BEAM ASSY WITH RING - STUD BS6	TATA spare parts
266135100348	REAR AXLE BEAM ASSY WITH RING AND STUD B	TATA spare parts
266135103702	PLUMMER BLOCK COVER	TATA spare parts
266135105003	FLANGE	TATA spare parts
266135105301	GASKET RR AXLE COVER	TATA spare parts
266135107101	REINFORCEMENT	TATA spare parts
266135107103	REINFORCING PLATE FRONT BS6	TATA spare parts
266135108201	REAR COVER	TATA spare parts
266135108202	OIL SLINGER	TATA spare parts
266135108203	REAR AXLE SR.NO.PLATE	TATA spare parts
266135108601	PRESSURE RING	TATA spare parts
266135108602	PRESSURE RING	TATA spare parts
266135108603	PRESSURE RING (SINGLE INNER HUB SEAL)	TATA spare parts
266135108604	PRESSURE RING (SINGLE INNER HUB SEAL)	TATA spare parts
266135108607	PRESSURE RING BS6	TATA spare parts
266135110103	ASSY CARRIER HOUSING 33/8 COMP RA-1055	TATA spare parts
266135110105	ASSY CARRIER HOUSING (33/8).294 DIA CW.	TATA spare parts
266135110106	ASSY CARRIER HSG 34/7 COMP 294 CW DIA	TATA spare parts
266135110109	ASSY CARRIER HOUSING 32/7 COMP	TATA spare parts
266135110124	CARRIER HOUSING ASSY BS6	TATA spare parts
266135110125	CARRIER HOUSING ASSY BS6	TATA spare parts
266135110126	CARRIER HOUSING ASSY BS6	TATA spare parts
266135300101	HOUSING DIFFERENTIAL	TATA spare parts
266135300102	ASSY.DIFF.REAR AXLE (33/8 STD. CW.RATIO)	TATA spare parts
266135300104	ASSY.DIFF.REAR AXLE (31/9 RATIO)	TATA spare parts
266135300107	ASSY. CROWN & PINION (31/8) BS2/3/4	TATA spare parts
266135300108	ASSY. CROWN & PINION (32/7) BS2/3/4	TATA spare parts
266135300110	COUPLING FLANGE	TATA spare parts
266135300111	THREADED RING	TATA spare parts
266135300112	ASSY. DIFFERENTIAL HOUSING? BS1/2/3	TATA spare parts
266135300113	ASSY. CROWN & PINION (31/9) BS1/2/3	TATA spare parts
266135300114	ASSY. DIFFERENTIAL (31/8-OERLIKON)	TATA spare parts
266135300115	ASSY. CROWN & PINION (31/8) BS2/3/4	TATA spare parts
266135300116	ASSY.CROWN WHEEL/PINION-31/8 (GLEASON)	TATA spare parts

266135300119	ASSY. CROWN & PINION (28/9) BS2/3	TATA spare parts
266135300121	ASSY DIFFERENTIAL HSG.	TATA spare parts
266135300125	ASSY DIFF GEAR KIT W/SPIDER-REVA	TATA spare parts
266135300126	ASSY DIFF 32/7 OERLIKON.	TATA spare parts
266135300127	ASSY.COUPLING FLANGE (PRESS FIT DUST CR)	TATA spare parts
266135300128	ASSY.SPACER WITH OIL SLINGER	TATA spare parts
266135300130	ASSY.COUPLING FANGE(130 OD)	TATA spare parts
266135300135	ASSY CROWN WHEEL PINION (34/7)	TATA spare parts
266135300136	ASSY. COUPLING FLANGE(SERRATED FLANGE)	TATA spare parts
266135300137	ASSY. DIFFERENTIAL HOUSING BS2/3/4/6	TATA spare parts
266135300138	ASSY DIFF. 32/7 (W/ONLY WARM F.GEARS)	TATA spare parts
266135300139	ASSY DIFF COMP 32/7-W/WARM F.GEARS ONLY.	TATA spare parts
266135300142	ASSY DIFFERENTIAL (33/8)REINFORCED RA-10	TATA spare parts
266135300143	ASSY DRIVE PINION 33/8 RA-1055	TATA spare parts
266135300147	ASSY CW & PINION 33/8 OER 294 DIA.	TATA spare parts
266135300148	DIFFERENTIAL HOUSING ASSY.(REINFORCED)	TATA spare parts
266135300151	ASSY DRIVE PINION 34/7 C294 RA-1055 BS6	TATA spare parts
266135300152	ASSY DIFF 34/7(4.857) REINFORCED RA-1055	TATA spare parts
266135300155	ASSY CROWN WHEEL & PINION 34/7(4.857) 29	TATA spare parts
266135300161	ASSY.THREADED RING (TAIL PINION) BS6-PH2	TATA spare parts
266135300163	ASSY DIFFERENTIAL (32/7) REINFORCED BS6	TATA spare parts
266135300164	ASSY DRIVE PINION 32/7 RA-1036ST BS6	TATA spare parts
266135300165	ASSY CW & PINION 32/7 OER 294 DIA.	TATA spare parts
266135300166	ASSY WARM FORGED DIFF PINION & GEAR SET	TATA spare parts
266135300174	DIFFRENTIAL HSG ASSY	TATA spare parts
266135300195	DIFFERENTIAL HOUSING ASSY BS6-PH2	TATA spare parts
266135300198	CROWN WHEEL & PINION ASSY	TATA spare parts
266135300199	CROWN WHEEL & PINION ASSY BS6	TATA spare parts
266135300203	CROWN WHEEL & PINION ASSY BS6	TATA spare parts
266135300208	DIFFERENTIAL ASSY BS6-PH2	TATA spare parts
266135300209	CROWN WHEEL & PINION ASSY BS6	TATA spare parts
266135300218	DIFFERENTIAL ASSY BS6	TATA spare parts
266135303102	BEARING CYL ROLLER	TATA spare parts
266135303103	BEARING CYL ROLLER	TATA spare parts
266135303104	BEARING CYL ROLLER	TATA spare parts
266135303105	TAPER ROLLER BRG 724873 BS1/2/3/4/6	TATA spare parts
266135303106	BEARING TAPER ROLLER	TATA spare parts
266135303107	BEARING TAPER ROLLER	TATA spare parts
266135303108	CYL ROLLER BRG TAIL PINI	TATA spare parts
266135303109	TAPER ROLLER BEARING .	TATA spare parts
266135303110	TAPER ROLLER BEARING .	TATA spare parts
266135303111	CYLINDRICAL ROLLER BRG. PINION NOSE	TATA spare parts
266135303112	TAPER ROLLER BEARING .	TATA spare parts
266135303113	CYLINDRICAL ROLLER BRG. PINION NOSE	TATA spare parts
266135303114	TAPER ROLLER BEARING	TATA spare parts
266135303115	CYLINDRICAL ROLLER BRG. PINION NOSE	TATA spare parts
266135303116	CYL ROLLER BRG NJ2305	TATA spare parts

266135303117	CYLINDRICAL ROLLER BRG. PINION NOSE	TATA spare parts
266135303118	TAPER ROLLER BEARING .	TATA spare parts
266135303119	TAPER ROLLER BEARING	TATA spare parts
266135303121	TAPER ROLLER BRG BS6	TATA spare parts
266135303122	TAPER ROLLER BRG BS6	TATA spare parts
266135303123	CYL ROLLER BRG 25X62X24 CAGELESS	TATA spare parts
266135303128	CYLINDRICAL ROLLER BEARING BS6	TATA spare parts
266135305001	COUPLING FLANGE-PRESS FIT DUST COVER	TATA spare parts
266135305002	COUPLING FLANGE 130 OD PRESS FITTED D.C.	TATA spare parts
266135305101	DIFFERENTIAL CASE	TATA spare parts
266135305102	DIFFERENTIAL COVER	TATA spare parts
266135305103	DIFFERENTIAL SPIDER BS1/2/3/4/6	TATA spare parts
266135305403	DIFFL BEVEL PINION	TATA spare parts
266135305404	REAR AXLE SHAFT GEAR	TATA spare parts
266135305407	PINION - CWP:31/8-0116OR	TATA spare parts
266135305409	PINION - CWP:33/8-0107OR	TATA spare parts
266135305410	PINION (OERLIKON) 32/7 OERLIKON	TATA spare parts
266135305417	PINION-31/8 RATIO-(GLEASON)	TATA spare parts
266135305418	CROWN WHEEL 31/8	TATA spare parts
266135305419	DIFFL BEVEL PINION	TATA spare parts
266135305420	REAR AXLE SHAFT GEAR	TATA spare parts
266135305428	REAR AXLE SHAFT GEAR	TATA spare parts
266135305429	DIFFERENTIAL BEVEL PINION WARM FORGED	TATA spare parts
266135305438	REAR AXLE SHAFT GEAR (20MN5CR5)	TATA spare parts
266135305439	BEVEL PINION GEAR (20MN5CR5)	TATA spare parts
266135305440	PINION 34/7(4.857) OER-SPIRAC 294 CW DIA	TATA spare parts
266135305445	PINION BS6	TATA spare parts
266135305459	PINION BS6	TATA spare parts
266135305461	DRIVE PINION BS6	TATA spare parts
26613530546120	DRIVE PINION 34X7(SPIRAC-SPIRON) BS6-PH2	TATA spare parts
266135305471	PINION BS6	TATA spare parts
266135306101	LOCKING PLATE DIFFL CASE	TATA spare parts
266135306103	LOCKING PLATE BS6-PH2	TATA spare parts
266135306501	THREADED RING DIFFL BS4	TATA spare parts
266135306504	HEX NUT (TAIL PINION COUPLING FLANGE)	TATA spare parts
266135306505	THREADED RING	TATA spare parts
266135306506	THREADED RING-TAIN PINION BS4	TATA spare parts
266135307702	OIL SEAL T P 709-VITON	TATA spare parts
266135307703	OIL SEAL TAIL PINION 709	TATA spare parts
266135307704	OIL SEAL TAIL PINION 709	TATA spare parts
266135307705	OIL SEAL TAIL PINION 709	TATA spare parts
266135307706	OIL SEAL TAIL PINION 709	TATA spare parts
266135307707	OIL SEAL-PTFE	TATA spare parts
266135307801	DUST SEAL (MECHANICAL)	TATA spare parts
266135308004	HEX SCREW (CW-DIFF CASE) 80/84 MTG DIST.	TATA spare parts
266135308006	ADJUSTING PIN&BS6	TATA spare parts
266135308201	DUST COVER	TATA spare parts

266135308203	DUST COVER-PRESS FITTED	TATA spare parts
266135308204	OIL SLINGER (FOR TAIL PINION)	TATA spare parts
266135308302	SHIM 0.10 MM	TATA spare parts
266135308303	SHIM 0.15 MM	TATA spare parts
266135308304	SHIM 0.20 MM	TATA spare parts
266135308305	SHIM 0.25 MM	TATA spare parts
266135308306	SHIM 0.30 MM	TATA spare parts
266135308307	SHIM 0.45 THICK BS6	TATA spare parts
266135308308	SHIM 0.50 MM	TATA spare parts
266135308309	SHIM 1.00 MM	TATA spare parts
266135308310	SHIM 1.50 MM	TATA spare parts
266135308605	SPACER RING TAIL PINION 9.10 THICK	TATA spare parts
266135308606	SPACER RING TAIL PINION 9.12 THICK	TATA spare parts
266135308607	SPACER RING TAIL PINION 9.14 THICK	TATA spare parts
266135308608	SPACER RING TAIL PINION 9.16 THICK	TATA spare parts
266135308609	SPACER RING TAIL PINION 9.18 THICK	TATA spare parts
266135308610	SPACER RING TAIL PINION 9.20 THICK	TATA spare parts
266135308611	SPACER RING TAIL PINION 9.22 THICK	TATA spare parts
266135308612	SPACER RING TAIL PINION 9.24 THICK	TATA spare parts
266135308613	SPACER RING,TAIL PINION 9.26 THICK	TATA spare parts
266135308614	SPACER RING TAIL PINION 9.28THICK	TATA spare parts
266135308615	SPACER RING TAIL PINION 9.30THICK	TATA spare parts
266135308616	SPACER RING TAIL PINION 9.32 THICK	TATA spare parts
266135308617	SPACER RING TAIL PINION 9.34 THICK	TATA spare parts
266135308618	SPACER RING TAIL PINION 9.36 THICK	TATA spare parts
266135308619	SPACER RING TAIL PINION 9.38 THICK	TATA spare parts
266135308620	SPACER RING TAIL PINION 9.40 THICK	TATA spare parts
266135308621	SPACER RING TAIL PINION 9.42 THICK	TATA spare parts
266135308622	SPACER RING TAIL PINION 9.44THICK	TATA spare parts
266135308623	SPACER RING TAIL PINION 9.46 THK.	TATA spare parts
266135308624	SPACER RING TAIL PINION 9.48 THK.	TATA spare parts
266135308625	SPACER RING TAIL PINION 8.80 THK.	TATA spare parts
266135308626	SPACER RING TAIL PINION 8.85 THK.	TATA spare parts
266135308627	SPACER RING TAIL PINION 8.90 THK.	TATA spare parts
266135308628	SPACER RING TAIL PINION 8.95 THK.	TATA spare parts
266135308629	SPACER RING TAIL PINION 9.00 THK.	TATA spare parts
266135308630	SPACER RING TAIL PINION 9.05 THK.	TATA spare parts
266135308631	SPACER RING TAIL PINION 9.56 THK.	TATA spare parts
266135308632	SPACER BET PINION & BRG	TATA spare parts
266135308633	SPACER BET PINION & FLANGE	TATA spare parts
266135308635	SPACER RING 7.60 MM	TATA spare parts
26613530863510	SPACER RING TAIL PINION RAW PART BS6-PH2	TATA spare parts
266135308636	SPACER RING,TAIL PINION 7.62 THICK	TATA spare parts
266135308637	SPACER RING 7.64 MM BS4	TATA spare parts
266135308638	SPACER RING TAIL PINION 7.66 THICK	TATA spare parts
266135308639	SPACER RING 7.68 MM	TATA spare parts
266135308640	SPACER RING 7.70 MM	TATA spare parts

266135308641	SPACER RING 7.72 MM	TATA spare parts
266135308642	SPACER RING 7.74 MM	TATA spare parts
266135308643	SPACER RING 7.76 MM	TATA spare parts
266135308644	SPACER RING 7.78 MM	TATA spare parts
266135308645	SPACER RING TAIL PINION 7.80 TICK	TATA spare parts
266135308646	SPACER RING TAIL PINION 7.82 THICK	TATA spare parts
266135308647	SPACER RING 7.84 MM	TATA spare parts
266135308648	SPACER RING 7.86 MM	TATA spare parts
266135308649	SPACER RING 7.88 MM	TATA spare parts
266135308650	SPACER RING 7.90 MM	TATA spare parts
266135308651	SPACER RING 7.92 MM	TATA spare parts
266135308652	SPACER RING 7.94 MM	TATA spare parts
266135308653	SPACER RING TAIL PINION 7.96 THICK	TATA spare parts
266135308654	SPACER RING 7.98 MM	TATA spare parts
266135308655	SPACER RING 8.00 MM	TATA spare parts
266135308656	SPACER RING 8.02 MM	TATA spare parts
266135308657	SPACER RING 8.04 MM	TATA spare parts
266135308658	SPACER RING 8.06 MM	TATA spare parts
266135308659	SPACER RING 8.08 MM	TATA spare parts
266135308660	SPACER RING 8.10 MM	TATA spare parts
266135308663	SPACER RING TAIL PINION 8.12 THICK	TATA spare parts
266135308664	SPACER RING TAIL PINION 8.14 THICK	TATA spare parts
266135308665	SPACER RING TAIL PINION 8.16 THICK	TATA spare parts
266135308666	SPACER RING TAIL PINION 8.18 THICK	TATA spare parts
266135308667	SPACER RING TAIL PINION 8.20 THICK	TATA spare parts
266135308668	SPACER-BET.PINION BRG.& FLANGE	TATA spare parts
266135309202	THRUST WASHER 1.95 MM	TATA spare parts
266135309203	THRUST WASHER 2.00 MM	TATA spare parts
266135309204	THRUST WASHER 2.05 MM	TATA spare parts
266135309205	THRUST WASHER 2.10 MM	TATA spare parts
266135309206	THRUST WASHER 2.15 MM	TATA spare parts
266135309207	THRUST WASHER 2.20 MM	TATA spare parts
266135309208	THRUST WASHER 2.25 MM	TATA spare parts
266135309210	SPHERICAL WASHER	TATA spare parts
266135309212	THRUST WASHER SHAFT GEAR (STEEL)1.95 MM	TATA spare parts
266135309213	THRUST WASHER SHAFT GEAR (STEEL)2.00 MM	TATA spare parts
266135309214	THRUST WASHER SHAFT GEAR (STEEL) 2.05 MM	TATA spare parts
266135309215	THRUST WASHER SHAFT GEAR (STEEL)2.10 MM	TATA spare parts
266135309216	THRUST WASHER SHAFT GEAR (STEEL) 2.15 MM	TATA spare parts
266135309217	THRUST WASHER SHAFT GEAR (STEEL)2.20MM	TATA spare parts
266135309218	THRUST WASHER SHAFT GEAR (STEEL) 2.25 MM	TATA spare parts
266135309227	THRUST WASHER SHAFT GEAR 1.85MM THICK	TATA spare parts
266135309228	THRUST WASHER SIDE GEAR BS6	TATA spare parts
266135600102	RR BR DRUM W/HUB & BRG	TATA spare parts
266135600103	BRAKE DRUM&HUB COMPL 709E	TATA spare parts
266135600104	REAR HUB 709 S-CAM	TATA spare parts
266135600107	HUB REAR W/O BEARINGS	TATA spare parts

266135600114	ASSY.REAR HUB	TATA spare parts
266135600118	ASSY REAR HUB WITH POLE WHEEL	TATA spare parts
266135600119	ASSY REAR HUB COMP W/POLE WHEEL (ABS)	TATA spare parts
266135600126	ASSY REAR HUB COMPW/OUTER SEAL.	TATA spare parts
266135600127	ASSY REAR HUB (7.5 T-Y1)	TATA spare parts
266135600133	ASSY RA HUB COMP(BUS)	TATA spare parts
266135600140	ASSY REAR HUB COMPLETE (NON ABS)	TATA spare parts
266135600141	ASSY REAR HUB WITH PIN (NON ABS)	TATA spare parts
266135600144	REAR HUB ASSY ABS BS6	TATA spare parts
266135600150	ASSY RA HUB COMP RA-1055 ABS BUS(WT.RD)	TATA spare parts
266135600152	ASSY RA HUB COMPRA-1055NON ABS(WGT.RED)	TATA spare parts
266135600163	REAR HUB ASSY BS6	TATA spare parts
266135600164	REAR HUB ASSY WITH BEARING	TATA spare parts
266135600168	REAR HUB ASSY BS6	TATA spare parts
266135600172	REAR HUB ASSY BS6-PH2	TATA spare parts
266135600173	REAR HUB ASSY WITH BEARING BS6-PH2	TATA spare parts
266135600177	REAR HUB ASSY WITH BEARING BS6-PH2	TATA spare parts
266135600180	REAR HUB ASSY WITH BEARING	TATA spare parts
266135601602	OIL SEAL 90X115X10	TATA spare parts
266135601604	CIRCLIP BS6-PH2	TATA spare parts
266135603101	BEARING TAPER ROLLER	TATA spare parts
266135603102	TAPER ROLLER BEARING	TATA spare parts
266135603105	TAPER ROLLER BEARING BS6-PH2	TATA spare parts
266135603703	RR DRUM BR W/HUB W/O BRG	TATA spare parts
266135603705	RR DRUM BR W/HUB W/O BRG	TATA spare parts
266135603707	RR DRUM BR W/HUB W/O BRG	TATA spare parts
266135603709	609 REAR HUB-M 16 STUD S-CAM	TATA spare parts
266135603710	REAR HUB- RAS-104 WITH 'S' CAM	TATA spare parts
266135603711	REAR BRAKE DRUM WITH HUB	TATA spare parts
266135603714	HUB (SPLIT TYPE) FOR 709 SINGLE TYRE.	TATA spare parts
266135603715	BRAKE DRUM (SPLIT TYPE) 709 SIGLE TYRE	TATA spare parts
266135603716	REAR HUB (WITH SINGLE INNER SEAL)	TATA spare parts
266135603718	REAR HUB 245 PCD RA-1055 (CONVENTIONAL)	TATA spare parts
266135603722	REAR BRAKE DRUM WITH HUB OUTER OIL SEAL	TATA spare parts
266135603723	HUB (SPLIT TYPE) OUTER OIL SEAL SINGLE TY	TATA spare parts
266135603724	REAR HUB (CAST VERSION)	TATA spare parts
266135603726	REAR HUB 7.2T SINGLE TYRE BS6	TATA spare parts
266135603728	REAR HUB	TATA spare parts
266135603731	REAR HUB THU BEARING	TATA spare parts
266135603732	REAR HUB BS6-PH2	TATA spare parts
266135605301	GASKET	TATA spare parts
266135605302	GASKET REAR HUB	TATA spare parts
266135605303	GASKET 150 PCD HUB TO AXLE SHAFT FOR RA-	TATA spare parts
266135605304	GASKET HUB TO AXLE SHAFT RA-1055	TATA spare parts
266135605305	GASKET REAR HUB & AXLE SHAFT 131 PCD.	TATA spare parts
266135606501	LOCKING RING (9T-REINFORCED)	TATA spare parts
266135606502	LOCK NUT (M60X2) RA-1055 CON.BRG.	TATA spare parts



266135606503	HEX NUT	TATA spare parts
266135606504	LOCK NUT (M60X2) 16MM	TATA spare parts
266135606505	LOCK NUT BS6-PH2	TATA spare parts
266135607701	OIL SEAL DOUBLE LIP RR INNER BS1/2/3/4	TATA spare parts
266135607703	OIL SEAL INN DOUBLE LEAP	TATA spare parts
266135607705	OIL SEAL DOUBLE LEAP BS2/3/4/6	TATA spare parts
266135607706	OIL SEAL 75X95X8;HUB OUTER	TATA spare parts
266135607707	OIL SEAL (75X95X8) DOU.LIP	TATA spare parts
266135607708	HUB INNER OIL SEAL(95X125X12)	TATA spare parts
266135607710	OIL SEAL HUB OUTER(90X110X10.7)	TATA spare parts
266135607711	OIL SEAL OUTER(75X95X7.7)	TATA spare parts
266135608001	HEX BOLT(AXLE SHAFT TO HUBM14)	TATA spare parts
266135608201	OIL CATCHER (FOR ABS)	TATA spare parts
266135608202	LOCKING PLATE (9T-REINFORCED)	TATA spare parts
266135608203	OIL CATCHER (FOR SINGLE INNER SEAL)	TATA spare parts
266135608204	OIL CATCHER RA-1055 245 PCD CON BRG.	TATA spare parts
266135608205	LOCK PLATE	TATA spare parts
266135608206	LOCK PLATE	TATA spare parts
266135608301	SHIM-0.05 THK. BS4	TATA spare parts
266135608302	SHIM-0.10 THK. BS4	TATA spare parts
266135608303	SHIM-0.15 THK.	TATA spare parts
266135608304	SHIM-0.20 THK.	TATA spare parts
266135608305	SHIM-0.25 THK.	TATA spare parts
266135608306	SHIM-0.30 THK.	TATA spare parts
266135608307	SHIM-0.50 THK.	TATA spare parts
266135608308	SHIM-1.00 THK.	TATA spare parts
266135608309	SHIM-1.50 THK.	TATA spare parts
266135608310	SHIM-2.5 THK.	TATA spare parts
266135608601	SPACER BS4	TATA spare parts
266135608602	SPACER TUBE-BET.HUB BRG.	TATA spare parts
266135608603	SPACER (9T-REINFORCED)	TATA spare parts
266135608605	TONGUE SPACER (FOR 709 HUB OUTER SEAL)	TATA spare parts
266135608606	TONGUE SPACER (M60) RA-1055 OUTER SEAL	TATA spare parts
266135608607	TONGUE SPACER (M60) WITH HOLES RA-1055.	TATA spare parts
266135608610	SPACER TUBE (BET.HUB BRG.)	TATA spare parts
266135608611	SPACER RING	TATA spare parts
266135608613	TONGUE SPACER(HUB OUTER SEAL)	TATA spare parts
266135608614	TONGUE SPACER BS6-PH2	TATA spare parts
266135608801	STUD	TATA spare parts
266135608802	STUD	TATA spare parts
266135707901	REAR AXLE SHAFT	TATA spare parts
266135707902	REAR AXLE SHAFT BS1/2/3/4	TATA spare parts
266135707903	REAR AXLE SHAFT (FOR 9T GVW) BS2/3/4	TATA spare parts
266135707906	REAR AXLE SHAFT (9T-REINFORCED)	TATA spare parts
266135707909	REAR AXLE SHAFT(RA-1055 TRUCK WGT.RED.)	TATA spare parts
266135707910	REAR AXLE SHAFT RA-1055(1730 TRACK) Y1.	TATA spare parts
266135707913	REAR AXLE SHAFT RA-1036ST (1800 TRACK)	TATA spare parts

266135707917	REAR AXLE SHAFT(RA-1055TRUCK WGT.RED.)	TATA spare parts
266135707918	REAR AXLE SHAFT(REINFORCED)	TATA spare parts
266135707923	REAR AXLE SHAFT 7.3T ST.	TATA spare parts
266135707924	REAR AXLE SHAFT	TATA spare parts
266135707926	REAR AXLE SHAFT BS6	TATA spare parts
266135707927	REAR AXLE SHAFT BS6	TATA spare parts
266135707931	REAR AXLE SHAFT BS6-PH2	TATA spare parts
266135707934	REAR AXLE SHAFT BS6-PH2	TATA spare parts
266135707935	REAR AXLE SHAFT BS6-PH2	TATA spare parts
266135707936	REAR AXLE SHAFT BS6-PH2	TATA spare parts
266135905101	FINGER	TATA spare parts
266135905301	GASKET	TATA spare parts
266135905401	ENGAGING SLEEVE	TATA spare parts
2661H9W0135002	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2661H9W0135004	REAR AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
2661H9W0135005	LIVE REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
2661H9W0135007	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2661H9W0135011	LIVE REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
2661H9W0135013	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2661H9W0135016	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2661H9W0135017	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2661H9W0135018	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2661H9W0135021	LIVE REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
2661H9W0135023	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2661H9W0135024	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2661H9W0135028	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2661H9W0135029	LIVE REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
266235000101	REAR AXLE RAS108 45/7 SPI	TATA spare parts
266235100102	REAR AXLE HOUSING	TATA spare parts
266235303101	BEARING TAPER ROLLER	TATA spare parts
266235603101	BEARING TAPER ROLLER	TATA spare parts
266335000102	REAR AXLE W/BR 49/9 TM	TATA spare parts
266335000117	REAR AXLE COMP 4X4 50/11R	TATA spare parts
266335000125	ASSY DANA RA.COMP,W/NASBS BRKS-(45/11)	TATA spare parts
266335000140	RR AXLE 4X4 NASB 50/11	TATA spare parts
266335000142	ASSY RA COMP N.ASBS BRK.(41/9)	TATA spare parts
266335000151	DANA REAR AXLE	TATA spare parts
266335000155	ASSY.RA COMPW/O S.A.BKTLSD41/9	TATA spare parts
266335000167	ASY.RA.W/NASBS BR WO/SHOK ABS W/DY 51/11	TATA spare parts
266335000176	ASY.RA.W/NASBS BR.WO/SHOCK ABS 37/11N	TATA spare parts
266335000183	ASSY RA.COMP44/9LSDNASBSWO/S.ABS	TATA spare parts
266335000187	ASY DANA RA COM,43/8,STD,WO/SH.ABS,A.ADJ	TATA spare parts
266335000193	ASSY RA W/4.55 W/SAFARI C.HSG 207DI	TATA spare parts
266335000209	ASSY RA44/9LSDNASBSWO/S.ABSA.ADJ	TATA spare parts
266335000215	ASSY REAR AXLE WITH 5.37 W/O LSD AUTO AD	TATA spare parts
266335000217	ASSY R.A COMP (41/9) W/A.R.BAR WO/SH.ABS	TATA spare parts
266335000217YA	YELLOW AGGR FOR ASSY R.A COMP (41/9)	TATA spare parts

266335000218	ASSY RA(41/9)STD W/AR.BAR WO/SH.ABS.	TATA spare parts
266335000219	RR AXLE 4.55 LSD W/A.ADJ BRK WO/SH.ABS	TATA spare parts
266335000224	TRANSFER LINE RA.3.73 LSD WO/SH.A	TATA spare parts
266335000225	ASSY RA 3.73(41/11)+REMOTE BREATHER	TATA spare parts
266335000227	ASSY RA.3.73 LSD 1560 TRCK WO/SH.ABS	TATA spare parts
266335000229	ASSY RA.3.36 LSD W/A.ADJ BRK.WO/ARB.	TATA spare parts
266335000236	ASSY RA 41/11 W/YOKE W/A.R.BRKT.	TATA spare parts
266335000248	ASSY DANA RA W/4.1 W/SAFARI C.HSG-207DI	TATA spare parts
266335000258	BANJO RA WITH 3.73(41/11)	TATA spare parts
266335000264	ASSY DANA RA 4.55 STD 1577 TRK 207DI	TATA spare parts
266335000265	SPRINT RA.3.73(41/11),LSD,295 DIA BRK M1	TATA spare parts
266335000270	ASSY RA 4.1 (41/10) 1560 TRACK	TATA spare parts
266335000284	ASSY DANA RA 3.73 LSD W/ABS 1560 TRACK	TATA spare parts
266335000335	ASSY DANA RA WITH 3.73,LSD,XENON CP FL.	TATA spare parts
266335000341	ASSY DANA RA 4.1 (41/10) 1560 TRACK WITH	TATA spare parts
266335000343	ASY DANA RA.3.36 LSD W/A.ADJ BRK.WO/ARB	TATA spare parts
266335000353	REAR AXLE ASSEMBLY	TATA spare parts
266335000354	REAR AXLE COMP.5.375(43/8) STD 1560 TRK	TATA spare parts
266335000362	ASSY DANA RA 3.73 LSD W/ABS 1560 TRACK W	TATA spare parts
266335000364	REAR AXLE 3.73 LSD W/ABS W/CPL FLANGE	TATA spare parts
266335000368	REAR AXLE 4.1 LSD W/ABS 1560 TRACK W/COU	TATA spare parts
266335000373	ASSY DANA RA WITH 5.375 STD ABS CP FL.-	TATA spare parts
266335000375	REAR AXLE 3.73 STD 1577 TRK CP FL	TATA spare parts
266335000382	RA-M4441/10W/ABSM-LOCKW/CPL	TATA spare parts
266335000392	ASSY REAR AXLE	TATA spare parts
266335050105	REAR AXLE W/BR 51/11 TE	TATA spare parts
266335050106	REAR AXLE W/BR 51/11 TS	TATA spare parts
266335050134	ASSY.R.AXLE W/COMPL.BRAKES 5.857 407 AX	TATA spare parts
266335050135	ASSY. REAR AXLE W/BRAKE 35/9 RATIO	TATA spare parts
266335050144	REAR AXLE M44-HD 4.55(41/9) STD DIF	TATA spare parts
266335050147	HD R.AXLE ASSY.W/3.73(41/11) STD 15	TATA spare parts
266335050148	REAR AXLE W/4.1 295DIA.BRK-RX PICK	TATA spare parts
266335050154	REAR AXLE ASSY W/4.1 STD DIFF 295D CF	TATA spare parts
266335050159	REAR AXLE ASSY	TATA spare parts
266335050161	REAR AXLE ASSY	TATA spare parts
266335050163	REAR AXLE ASSY WITH 3.73 RAR STD DIFF (1	TATA spare parts
266335050167	REAR AXLE ASSY	TATA spare parts
266335050171	REAR AXLE ASSY M44-HD.3.73 STD DIFF 1577	TATA spare parts
266335050172	REAR AXLE ASSY	TATA spare parts
266335050175	REAR AXLE ASSY	TATA spare parts
266335050180	AXLE ASSY WITH BRAKE	TATA spare parts
266335050182	REAR AXLE ASSY	TATA spare parts
266335050196	REAR AXLE ASSY	TATA spare parts
266335050197	REAR AXLE ASSY	TATA spare parts
266335050200	REAR AXLE ASSY BS6	TATA spare parts
266335050202	REAR AXLE ASSY BS6	TATA spare parts
266335050204	REAR AXLE ASSY BS6	TATA spare parts

266335050206	REAR AXLE ASSY BS6	TATA spare parts
266335050207	REAR AXLE ASSY BS6	TATA spare parts
266335050208	REAR AXLE ASSY	TATA spare parts
266335050211	REAR AXLE ASSY BS6	TATA spare parts
266335100102	REAR AXLE HOUSING	TATA spare parts
266335100104	REAR COVER	TATA spare parts
266335100134	ASSY.R.A.HSG.+SUPP TUBE & PLUM.BLOCK COV	TATA spare parts
266335100157	ASSY. DANA REAR AXLE HOUSING WITH TUBE	TATA spare parts
266335100158	RA HSG+TUBE WO/SH.ABS WO/ARB	TATA spare parts
266335100160	ASSY RA.HSG(SAF)+SUPP TUBE-ETR-1575 207D	TATA spare parts
266335100170	CW & P ASSLY - HYPOID DRIVE 3.73	TATA spare parts
266335100192	ASY RA.HSG.+SUPP.TUBE & PLUM.BLOCK	TATA spare parts
266335100204	ASY RA.HSG+ TUBE ASY S.SUSP 9.5 THK.TUBE	TATA spare parts
266335100206	ASSY. REAR AXLE SUPPORTING TUBE RH.COMP.	TATA spare parts
266335100208	ASSY. RA HSG W/PLUMMER BLK COVER EURO3	TATA spare parts
266335100209	ASY RA.HSG+ TUBE ASY S.SUSP XENON (NON A	TATA spare parts
266335100210	ASSY. REAR AXLE SUPPORTING TUBE LH.COMP.	TATA spare parts
266335100228	ASY RA.HSG+ TUBE ASY S.SUSP XENON (NON A	TATA spare parts
266335100230	RETAINER ASSY - OIL <sub>2</sub> SEAL <sub>2</sub> (W/O OIL <sub>2</sub> SEA	TATA spare parts
266335100236	RA BEAM ASSLY	TATA spare parts
266335100237	REAR AXLE BEAM	TATA spare parts
266335100239	REAR AXLE SUPPORT TUBE ASSY	TATA spare parts
266335100241	AXLE ASSY-PARTIAL REAR	TATA spare parts
266335100250	AXLE BEAM ASSY	TATA spare parts
266335100255	AXLE ASSY - PARTIAL REAR BS6	TATA spare parts
266335100256	AXLE ASSY - PARTIAL REAR BS6	TATA spare parts
266335103201	HEX COLLER BOLT	TATA spare parts
266335103202	WHEEL BOLT RH	TATA spare parts
266335103203	RETAINER BOLT	TATA spare parts
266335103204	RETAINER BOLT SARETED	TATA spare parts
266335103205	BOLT WHEEL ETR-899	TATA spare parts
266335103206	BOLT HEX	TATA spare parts
266335103207	WHEEL BOLT RH (2009867-1)	TATA spare parts
266335103208	SCREW DRIVE GEAR (RING GEAR BOLT)	TATA spare parts
266335103210	BOLT <sub>2</sub> - <sub>2</sub> BUTTON <sub>2</sub> HEAD	TATA spare parts
266335103211	BOLT - BUTTON HEAD	TATA spare parts
266335103702	PLUMBER BLOCK COVER	TATA spare parts
266335105301	GASKET REAR COVER	TATA spare parts
266335107101	REINFORCEMENT (REAR COVER)	TATA spare parts
266335107201	FILLER PLUG	TATA spare parts
266335107202	DRAIN PLUG DANA-43180	TATA spare parts
266335107203	PLUG - PIPE (INT DRIVE)(MAGNETIC)	TATA spare parts
266335107207	MAGNETIC DRAIN PLUG BS1/2/3/4	TATA spare parts
266335107207AE	MAG DRAIN PLUG 1628/ 1828/ 715/	TATA spare parts
266335108001	SCREW REAR COVER	TATA spare parts
266335108202	OIL SLINGER	TATA spare parts
266335108203	REAR COVER	TATA spare parts

266335108204	COVER CARRIER FIN	TATA spare parts
266335108208	RATIO TAG (3.73) 17627-27	TATA spare parts
266335108209	TAGRATIO4.1	TATA spare parts
266335108301	SHIM ADJUSTMENT	TATA spare parts
266335109901	ADAPTOR	TATA spare parts
266335109902	ADAPTOR - FIN	TATA spare parts
266335150109	REAR AXLE HOUSING	TATA spare parts
266335150131	RUBBER HOSE ASSY (REMOTE BREATHER)	TATA spare parts
266335150132	HOSE ASSY REMOTE BREATHER	TATA spare parts
266335151601	HOSE ASSEMBLY (FOR REMOTE BREATHER)	TATA spare parts
266335300101	COUPLING FLANGE	TATA spare parts
266335300108	ASSY.DIFF.WITHOUT CROWN WHEEL	TATA spare parts
266335300111	CWP SET 49/9 OERL	TATA spare parts
266335300117	CWP SET 49/12	TATA spare parts
266335300120	ASSY DIFF HSG 51/11 RATIO-OERLIKON	TATA spare parts
266335300121	CROWN & PINION 51/11 NLS-35350105	TATA spare parts
266335300132	ASY.RING GEAR/PINION 5.38	TATA spare parts
266335300133	DIFFERENTIAL CASE ASSY	TATA spare parts
266335300134	GEAR & PINION ASSY 4.55 BS1/2/3	TATA spare parts
266335300135	ASSY RING GEAR/PINION 45/11	TATA spare parts
266335300139	ASSY.CW/PINION (44/9)	TATA spare parts
266335300143	LSD CLUTCH PACK KIT	TATA spare parts
266335300144	PINION OILSEAL KIT	TATA spare parts
266335300145	CROWN WHEEL / PINION KIT(43/8=5.38)	TATA spare parts
266335300147	CROWN WHEEL/PINION KIT(45/11=4.09)KIT-6	TATA spare parts
266335300149	DIFF. CASE KIT ( MINOR )	TATA spare parts
266335300150	MAJOR KIT-DIFF. GEAR CASE? BS1/2/3/4/6	TATA spare parts
266335300154	ASSY DIFF GEAR KIT W/SPIDER-REVA	TATA spare parts
266335300156	CROWN WHEEL PINION KIT - ( 37/11 - 3.36	TATA spare parts
266335300157	CROWN WHEEL & PINION KIT(3.36)	TATA spare parts
266335300158	DIFF.ASSLY. (STD)	TATA spare parts
266335300159	LSD DIFF.ASSLY. 3.36 ( DICOR)	TATA spare parts
266335300163	ASSY CROWN WHEEL & PINION 41/11 (3.73)	TATA spare parts
266335300166	C/W AND PINION ASSLY. (3.73 REAR ) 41/11	TATA spare parts
266335300167	CROWN WHEEL PINION KIT( 41/11 - 3.73 )	TATA spare parts
266335300168	END YOKE ASSEMBLY	TATA spare parts
266335300169	DIFF. CASE KIT - T/L	TATA spare parts
266335300170	LSD DIFFCASE GEAR KIT (MAJOR)	TATA spare parts
266335300171	ASSY CW/P 4.1(41/10) RATIO	TATA spare parts
266335300172	KIT CW/P ASSY 4.1(41/10)	TATA spare parts
266335300174	END YOKE ASSEMBLY	TATA spare parts
266335300175	CASE ASSY DIFF (T/L)	TATA spare parts
266335300177	LSD CLUTCH PACK KIT - MINOR	TATA spare parts
266335300181	FINAL DRIVE ASM ( CENTRE ASSLY. )	TATA spare parts
266335300190	LUBRICANT KIT - LUBRICANT	TATA spare parts
266335300202	ASSY.C.WHEEL/PINON 41/7	TATA spare parts
266335300203	COMPANION FLANGE ASSEMBLY ETR-3057	TATA spare parts

266335300204	ASSY.C.WHEEL/PINON 47/8 5.857 SPIROFLEX	TATA spare parts
266335300205	M-LOCKER DIFFERENTIAL	TATA spare parts
266335300206	KIT-DIFFERENTIAL-(M-LOCKER)	TATA spare parts
266335300220	DIFFERENTIAL CASE DIFFERENTIAL CASE	TATA spare parts
266335300224	CROWN WHEEL & PINION ASSY	TATA spare parts
266335300233	DRIVE GEAR WITH PINION	TATA spare parts
266335300234	COMPANION FLANGE ASSY BS6	TATA spare parts
266335300235	KIT-SEAL BS6	TATA spare parts
266335300241	DIFFERENTIAL ASSY BS6-PH2	TATA spare parts
266335303101	BEARING TAPER ROLLER	TATA spare parts
266335303103	TAPER ROLLER BEARING (TAIL PINION )	TATA spare parts
266335303104	BRG ROLLER PINION INNER	TATA spare parts
266335303105	BRG ROLLER PINION OUT D/S	TATA spare parts
266335303201	HEX BOLT CWP	TATA spare parts
266335305003	END YOKE	TATA spare parts
266335305005	COUPLING FLANGE FOR XENON APPLICATION	TATA spare parts
266335305101	HOUSING DIFFERENTIAL	TATA spare parts
266335305102	DIFFERENTIAL CROSS PIN	TATA spare parts
266335305104	DIFFL CASE STD	TATA spare parts
266335305105	PIN ROLLER	TATA spare parts
266335305106	DIFFERENTIAL ASSY	TATA spare parts
266335305108	DIFFCASE FINISH (STD)	TATA spare parts
266335305109	LSD DIFFCASE FINISH 3.36 ( DICOR )	TATA spare parts
266335305110	LSD DIFF CASE FINISHED FOR 4.1 & 4.55	TATA spare parts
266335305111	CASE - FIN (DIFF TL)	TATA spare parts
266335305116	COUPLING FLANGE ( PRESS FIT DUST COVER)	TATA spare parts
266335305415	DIFFL BEVEL GEAR	TATA spare parts
266335305416	GEAR REAR AXLE SHAFT	TATA spare parts
266335305425	GEAR DIFFL	TATA spare parts
266335305426	PINION DIFF	TATA spare parts
266335305427	SHAFT DIFFL STD	TATA spare parts
266335305429	GEAR DIFF	TATA spare parts
266335305430	SHAFT DIFF. STD.	TATA spare parts
266335305452	GEAR DIFF FINISHED (LSD) X52782	TATA spare parts
266335305454	SHAFT - DIFF STD AND TL	TATA spare parts
266335305463	DIFFERENTIAL BEVEL GEAR BS6	TATA spare parts
266335305464	DIFFERENTIAL BEVEL PINION BS6	TATA spare parts
266335305492	DIFF BEVEL PINION GEAR	TATA spare parts
266335305493	SPIDER INTERAXLE DIFFERENTIAL SPIDER	TATA spare parts
266335305496	GEAR - DIFF -PINION MATE BS6	TATA spare parts
266335306101	LOCK PLATE	TATA spare parts
266335306501	NUT LOCK	TATA spare parts
266335307102	PLATE DIFF. DISHED ( 2 NOS.)	TATA spare parts
266335307104	PLATE DIFF. PRESSURE ( 8 NOS.)	TATA spare parts
266335307106	DISC DIFF. CLUTCH STD. ( 8 NOS.)	TATA spare parts
266335307107	RETAINER DIFF.CLUTCH	TATA spare parts
266335307108	RETAINER PLATE ETR-1825	TATA spare parts

266335307109	GUIDE -AXLE SHAFT	TATA spare parts
266335307701	OIL SEAL T P INNER	TATA spare parts
266335307702	OIL SEAL T/PINION OUTER	TATA spare parts
266335307703	OIL SEAL(48x74x8) SINGLE LIP	TATA spare parts
266335307704	OIL SEAL(48x74x8) DOUBBLE LIP	TATA spare parts
266335307705	OIL SEAL T/PINION OUTER	TATA spare parts
266335307706	OIL SEAL(48X74X8) SINGLE LIP	TATA spare parts
266335307707	OIL SEAL(48X74X8) SINGLE LIP	TATA spare parts
266335307708	OIL SEAL TAIL PINION OUTER	TATA spare parts
266335307709	OIL SEAL(48X74X8) SINGLE LIP	TATA spare parts
266335307710	SLINGER PINION O/SEAL OUTER	TATA spare parts
266335307710AE	SLINGER PINION O/SEAL OUTER	TATA spare parts
266335307711	OIL SEAL FRONT HUB	TATA spare parts
266335307712	OIL SEAL(48X74X8) SINGLE LIP	TATA spare parts
266335307713	OIL SEAL TAIL PINION OUTER	TATA spare parts
266335307722	SEAL-OIL BS6	TATA spare parts
266335308001	HEX SCREW CR WHEEL	TATA spare parts
266335308002	SCREW FLANGE HEAD	TATA spare parts
266335308003	SCREW FLANGE HEAD	TATA spare parts
266335308202	DUST COVER (PRESS FIT TYPE)	TATA spare parts
266335308203	DEFLECTOR - END YOKE 50320	TATA spare parts
266335308204	BEARING CAP (DIFF BRG FIN)	TATA spare parts
266335308205	LOCKSTRAP	TATA spare parts
266335308207	DEFLECTOR-COMPANION FLANGE BS6	TATA spare parts
266335308301	SHIM DIFF. BEARING ( 0.003 INCH)	TATA spare parts
266335308302	SHIM DIFF. BEARING ( 0.005 INCH)	TATA spare parts
266335308303	SHIM DIFF. BEARING ( 0.010 INCH)	TATA spare parts
266335308304	SHIM DIFF. BEARING ( 0.030 INCH)	TATA spare parts
266335308305	SHIM ADJUSTMENT ( PINION DEPTH ADJUSTMEN	TATA spare parts
266335308306	SHIM ADJUSTMENT ( PINION DEPTH ADJUSTMEN	TATA spare parts
266335308313	SHIM-58 THOU (PINION) 44453-150	TATA spare parts
266335308322	SPACER BRG PRELOAD-DIFF (46582)	TATA spare parts
266335308323	SPACER BRG PRELOAD-DIFF	TATA spare parts
266335308324	PINION HEAD SHIM	TATA spare parts
266335308601	COLLAPSIBLE SPACER	TATA spare parts
266335308603	COLLAPSIBLE SPACER TAIL PINION 14.9 THK	TATA spare parts
266335308604	THRUST BLOCK	TATA spare parts
266335308606	SPACER BET T/P & FLANGE	TATA spare parts
266335308607	COLLAPSIBLE SPACER 15.2MM	TATA spare parts
266335308608	COLLAPSIBLE SPACER 15.5MM	TATA spare parts
266335308609	FLAT WASHER	TATA spare parts
266335308612	SPACER - COLLAPSIABLE (46925)	TATA spare parts
266335309201	SPHERICAL WASHER	TATA spare parts
266335309206	THRUST WASHER 1.45 MM	TATA spare parts
266335309207	THRUST WASHER 1.50 THK.	TATA spare parts
266335309208	THRUST WASHER 1.55 THK.	TATA spare parts
266335309209	THRUST WASHER 1.60 THK.	TATA spare parts

266335309210	THRUST WASHER 1.65 MM	TATA spare parts
266335309211	THRUST WASHER 1.70 MM	TATA spare parts
266335309214	SELECTION SPACER (DIFF.) 4.90 THK	TATA spare parts
266335309215	SPACER 4.92 MM DIFFL BRG	TATA spare parts
266335309216	SELECTION SPACER (DIFF.) 4.94 THK.	TATA spare parts
266335309217	SPACER 4.96 MM DIFFL BRG	TATA spare parts
266335309218	SELECTION SPACER (DIFF.) 4.98 THK.	TATA spare parts
266335309219	SPACER 5.00 MM DIFFL BRG	TATA spare parts
266335309220	SPACER 5.02 MM DIFFL BRG	TATA spare parts
266335309221	SPACER 5.04 MM DIFFL BRG	TATA spare parts
266335309222	SELECTION SPACER (DIFF.) 5.06 THK.	TATA spare parts
266335309223	SPACER 5.08 MM DIFFL BRG	TATA spare parts
266335309224	SELECTION SPACER (DIFF.) 5.10 THK.	TATA spare parts
266335309225	SPACER 5.12 MM DIFFL BRG	TATA spare parts
266335309226	SELECTION SPACER (DIFF.) 5.14 THK.	TATA spare parts
266335309227	SPACER 5.16 MM DIFFL BRG	TATA spare parts
266335309228	SPACER 5.18 MM DIFFL BRG	TATA spare parts
266335309229	SELECTION SPACER (DIFF.) 5.20 THK.	TATA spare parts
266335309230	SPACER 5.22 MM DIFFL BRG	TATA spare parts
266335309231	SPACER 5.24 MM DIFFL BRG	TATA spare parts
266335309232	SELECTION SPACER (DIFF.) 5.26 THK.	TATA spare parts
266335309233	SELECTION SPACER (DIFF.) 5.28 THK.	TATA spare parts
266335309234	SPACER 5.30 MM DIFFL BRG	TATA spare parts
266335309235	SPACER 5.32 MM DIFFL BRG	TATA spare parts
266335309236	SELECTION SPACER (DIFF.) 5.34 THK.	TATA spare parts
266335309237	SPACER 5.36 MM DIFFL BRG	TATA spare parts
266335309238	SPACER 5.38 MM DIFFL BRG	TATA spare parts
266335309239	SPACER 5.40 MM DIFFL BRG	TATA spare parts
266335309240	SELECTION SPACER (DIFF.) 5.42 THK.	TATA spare parts
266335309241	SPACER 5.44 MM DIFFL BRG	TATA spare parts
266335309242	SPACER 5.46 MM DIFFL BRG	TATA spare parts
266335309243	SPACER 5.48 MM DIFFL BRG	TATA spare parts
266335309244	SELECTION SPACER (DIFF.) 5.50 THK.	TATA spare parts
266335309245	SPACER 5.52 MM DIFFL BRG	TATA spare parts
266335309246	SPACER 5.54 MM DIFFL BRG	TATA spare parts
266335309247	SPACER 5.56 MM DIFFL BRG	TATA spare parts
266335309248	SPACER 5.58 MM DIFFL BRG	TATA spare parts
266335309249	SPACER 5.60 MM DIFFL BRG	TATA spare parts
266335309250	SELECTION SPACER (DIFF.) 5.62 THK.	TATA spare parts
266335309251	SPACER 5.64 MM DIFFL BRG	TATA spare parts
266335309252	SPACER 5.66 MM DIFFL BRG	TATA spare parts
266335309253	SPACER 5.68 MM DIFFL BRG	TATA spare parts
266335309254	SPACER 5.70 MM DIFFL BRG	TATA spare parts
266335309255	SPACER 5.72 MM DIFFL BRG	TATA spare parts
266335309256	SELECTION SPACER (DIFF.) 5.74 THK.	TATA spare parts
266335309257	SPACER 5.76 MM DIFFL BRG	TATA spare parts
266335309258	SPACER 5.78 MM DIFFL BRG	TATA spare parts



266335309259	SPACER 5.80 MM DIFFL BRG	TATA spare parts
266335309260	SPACER 5.82 MM DIFFL BRG	TATA spare parts
266335309261	SPACER 5.84 MM DIFFL BRG	TATA spare parts
266335309262	SPACER 5.86 MM DIFFL BRG	TATA spare parts
266335309263	SPACER 5.88 MM DIFFL BRG	TATA spare parts
266335309264	SELECTION SPACER (DIFF.) 5.90 THK.	TATA spare parts
266335309265	SPACER 5.92 MM DIFFL BRG	TATA spare parts
266335309266	SPACER 5.94 MM DIFFL BRG	TATA spare parts
266335309267	SPACER 5.96 MM DIFFL BRG	TATA spare parts
266335309268	SELECTION SPACER (DIFF.) 5.98 THK.	TATA spare parts
266335309269	SPACER 6.00 MM DIFFL BRG	TATA spare parts
266335309270	SPACER 6.02 MM DIFFL BRG	TATA spare parts
266335309271	SELECTION SPACER (DIFF.) 6.04 THK.	TATA spare parts
266335309272	SELECTION SPACER (DIFF.) 6.06 THK.	TATA spare parts
266335309273	SELECTION SPACER (DIFF.) 6.08 THK.	TATA spare parts
266335309274	SELECTION SPACER (TAIL PINION) 5.10 THK	TATA spare parts
266335309275	SPACER 5.12 MM TL PINION	TATA spare parts
266335309276	SELECTION SPACER (TAIL PINION) 5.14 THK.	TATA spare parts
266335309277	SPACER 5.16 MM TL PINION	TATA spare parts
266335309278	SPACER 5.18 MM TL PINION	TATA spare parts
266335309279	SELECTION SPACER (TAIL PINION) 5.20 THK.	TATA spare parts
266335309280	SPACER 5.22 MM TL PINION	TATA spare parts
266335309281	SPACER 5.24 MM TL PINION	TATA spare parts
266335309282	SELECTION SPACER (TAIL PINION) 5.26 THK.	TATA spare parts
266335309283	SPACER 5.28 MM TL PINION	TATA spare parts
266335309284	SPACER 5.30 MM TL PINION	TATA spare parts
266335309285	SELECTION SPACER (TAIL PINION) 5.32 THK.	TATA spare parts
266335309286	SPACER 5.34 MM TL PINION	TATA spare parts
266335309287	SPACER 5.36 MM TL PINION	TATA spare parts
266335309288	SPACER 5.38 MM TL PINION	TATA spare parts
266335309289	SELECTION SPACER (TAIL PINION) 5.40 THK.	TATA spare parts
266335309290	SPACER 5.42 MM TL PINION	TATA spare parts
266335309291	SPACER 5.44 MM TL PINION	TATA spare parts
266335309292	SPACER 5.46 MM TL PINION	TATA spare parts
266335309293	SELECTION SPACER (TAIL PINION) 5.48 THK.	TATA spare parts
266335309294	SPACER 5.50 MM TL PINION	TATA spare parts
266335309295	SPACER 5.52 MM TL PINION	TATA spare parts
266335309296	SPACER 5.54 MM TL PINION	TATA spare parts
266335309297	SPACER 5.56 MM TL PINION	TATA spare parts
266335309298	SPACER 5.58 MM TL PINION	TATA spare parts
266335309299	SPACER 5.60 MM TL PINION	TATA spare parts
266335319201	SPACER 5.62 MM TL PINION	TATA spare parts
266335319202	SELECTION SPACER (TAIL PINION) 5.64 THK.	TATA spare parts
266335319203	SPACER 5.66 MM TL PINION	TATA spare parts
266335319204	SPACER 5.68 MM TL PINION	TATA spare parts
266335319205	SELECTION SPACER (TAIL PINION) 5.70 THK.	TATA spare parts
266335319206	SPACER 5.72 MM TL PINION	TATA spare parts

266335319207	SPACER 5.74 MM TL PINION	TATA spare parts
266335319208	SPACER 5.76 MM TL PINION	TATA spare parts
266335319209	SPACER 5.78 MM TL PINION	TATA spare parts
266335319210	SPACER 5.80 MM TL PINION	TATA spare parts
266335319211	SPACER 5.82 MM TL PINION	TATA spare parts
266335319212	SPACER 5.84 MM TL PINION	TATA spare parts
266335319213	SPACER 5.86 MM TL PINION	TATA spare parts
266335319214	SPACER 5.88 MM TL PINION	TATA spare parts
266335319215	SPACER 5.90 MM TL PINION	TATA spare parts
266335319216	SPACER 5.92 MM TL PINION	TATA spare parts
266335319217	SPACER 5.94 MM TL PINION	TATA spare parts
266335319218	SPACER 5.96 MM TL PINION	TATA spare parts
266335319219	SPACER 5.98 MM TL PINION	TATA spare parts
266335319220	SELECTION SPACER (TAIL PINION) 6.00 THK.	TATA spare parts
266335319221	SPACER 6.02 MM TL PINION	TATA spare parts
266335319222	SPACER 6.04 MM TL PINION	TATA spare parts
266335319223	SPACER 6.06 MM TL PINION	TATA spare parts
266335319224	SPACER 6.08 MM TL PINION	TATA spare parts
266335319225	SPACER 6.10 MM TL PINION	TATA spare parts
266335319226	SPACER 6.12 MM TL PINION	TATA spare parts
266335319227	SPACER 6.14 MM TL PINION	TATA spare parts
266335319228	SPACER 6.16 MM TL PINION	TATA spare parts
266335319229	SPACER 6.18 MM TL PINION	TATA spare parts
266335319230	SPACER 6.20 MM TL PINION	TATA spare parts
266335319231	SPHERICAL WASHER NYLON	TATA spare parts
266335319232	THRUST WASHER 1.75 MM	TATA spare parts
266335319233	THRUST WASHER 1.80 MM	TATA spare parts
266335319234	THRUST WASHER 1.85 MM	TATA spare parts
266335319235	SELECTION SPACER (TAIL PINION) 4.70 THK.	TATA spare parts
266335319236	SPACER 4.72 MM TL PINION	TATA spare parts
266335319237	SPACER 4.74 MM TL PINION	TATA spare parts
266335319238	SPACER 4.76 MM TL PINION	TATA spare parts
266335319239	SPACER 4.78 MM TL PINION	TATA spare parts
266335319240	SELECTION SPACER (TAIL PINION) 4.80 THK.	TATA spare parts
266335319241	SPACER 4.82 MM TL PINION	TATA spare parts
266335319242	SPACER 4.84 MM TL PINION	TATA spare parts
266335319243	SPACER 4.86 MM TL PINION	TATA spare parts
266335319244	SPACER 4.88 MM TL PINION	TATA spare parts
266335319245	SPACER 4.90 MM TL PINION	TATA spare parts
266335319246	SPACER 4.92 MM TL PINION	TATA spare parts
266335319247	SPACER 4.94 MM TL PINION	TATA spare parts
266335319248	SPACER 4.96 MM TL PINION	TATA spare parts
266335319249	SPACER 4.98 MM TL PINION	TATA spare parts
266335319250	SELECTION SPACER (TAIL PINION) 5.00 THK.	TATA spare parts
266335319251	SPACER 5.02 MM TL PINION	TATA spare parts
266335319252	SPACER 5.04 MM TL PINION	TATA spare parts
266335319253	SPACER 5.06 MM TL PINION	TATA spare parts

266335319254	SPACER 5.08 MM TL PINION	TATA spare parts
266335319255	SPACER 6.10 MM DIFFL BRG	TATA spare parts
266335319256	SELECTION SPACER (DIFF. BRG.) 6.12 THK.	TATA spare parts
266335319257	SELECTION SPACER (DIFF. BRG.) 6.14 THK.	TATA spare parts
266335319258	SELECTION SPACER (DIFF. BRG.) 6.16 THK.	TATA spare parts
266335319259	SELECTION SPACER (DIFF. BRG.) 6.18 THK.	TATA spare parts
266335319260	SPACER 6.20 MM DIFFL BRG	TATA spare parts
266335319261	SELECTION SPACER (DIFF. BRG.) 6.22 THK.	TATA spare parts
266335319262	SELECTION SPACER (DIFF. BRG.) 6.24 THK.	TATA spare parts
266335319263	SELECTION SPACER (DIFF. BRG.) 6.26 THK.	TATA spare parts
266335319264	SELECTION SPACER (DIFF. BRG.) 6.28 THK.	TATA spare parts
266335319265	SELECTION SPACER (DIFF. BRG.) 6.30 THK.	TATA spare parts
266335319266	SELECTION SPACER (DIFF. BRG.) 6.32 THK.	TATA spare parts
266335319267	SELECTION SPACER (DIFF. BRG.) 6.34 THK.	TATA spare parts
266335319268	SELECTION SPACER (DIFF. BRG.) 6.36 THK.	TATA spare parts
266335319269	SELECTION SPACER (DIFF. BRG.) 6.38 THK.	TATA spare parts
266335319270	SELECTION SPACER (DIFF. BRG.) 6.40 THK.	TATA spare parts
266335319271	THRUST WASHER 1.90 MM	TATA spare parts
266335319272	THRUST WASHER 1.95 MM	TATA spare parts
266335319273	THRUST WASHER 2.00 MM	TATA spare parts
266335319274	SELECTION SPACER (DIFF. BRG.) 6.70 THK.	TATA spare parts
266335319275	THRUST WASHER DIFFL	TATA spare parts
266335319276	TH WASHER DIFFL PINION	TATA spare parts
266335350105	ASSEMBLY CR/WH & PINION 41/9 RATIO	TATA spare parts
266335355002	END YOKE.	TATA spare parts
266335355003	END YOKE RR AXLE	TATA spare parts
266335356501	NUT	TATA spare parts
266335356502	PINION NUT	TATA spare parts
266335356504	LOCK NUT	TATA spare parts
266335356505	NUT DRIVE PINION	TATA spare parts
266335603702	BEARING COVER (407 AXLE FOR XENON)	TATA spare parts
266335603703	REAR BRAKE DRUM W/HUB (SPIGOTTED WHEEL)	TATA spare parts
266335605301	GASKET FOR HUB COVER	TATA spare parts
266335606501	NUT & LOCK	TATA spare parts
266335607701	OIL SEAL (75X95X13) INNER	TATA spare parts
266335607703	OIL SEAL (75X90X10) OUTER	TATA spare parts
266335608201	COVER REAR HUB (407 AXLE FOR XENON)	TATA spare parts
266335608602	SPACER BETWEEN OUTER BRG & LOCKING RING	TATA spare parts
266335608801	STUD - DOWEL	TATA spare parts
2663357000164	REAR AXLE SHAFT LH	TATA spare parts
2663357000165	REAR AXLE SHAFT RH	TATA spare parts
266335700102	ASSLY REAR AXLE SHAFT, WITH R.H. THREADING	TATA spare parts
266335700106	REAR AXLE SHAFT 756231X	TATA spare parts
266335700110	KIT-AXLESHAFT BEARING BS1/3/4	TATA spare parts
266335700115	AXLE SHAFT ASSLY (SPRINT)	TATA spare parts
266335700116	AXLE SHAFT ASSLY SPIGOTTED EXTRUDED. (2.	TATA spare parts
266335700119	AXLE SHAFT ASSLY	TATA spare parts

266335700120	AXLE SHAFT BEARING KIT	TATA spare parts
266335700124	RETAINER ASSLY - OIL SEAL	TATA spare parts
266335700136	AXLE SHAFT ASSY. XENON ABS ETR	TATA spare parts
266335700138	AXLE SHAFT ASSLY (SUMO)	TATA spare parts
266335700147	AXLE SHAFT ASSY. M-LOCKER XENON ABS	TATA spare parts
266335700148	SHAFT ASSY - REAR AXLE COMPLETE (LH)	TATA spare parts
266335700149	SHAFT ASSY - REAR AXLE COMPLETE (RH)	TATA spare parts
266335700152	AXLE SHAFT ASSYEMBLY	TATA spare parts
266335700154	REAR AXLE HOUSING ASSY - HD	TATA spare parts
266335700155	TAPER ROLLER BRG BRG KIT	TATA spare parts
266335700156	SHAFT ASSY REAR AXLE LH REAR AXLE(LH)	TATA spare parts
266335700157	SHAFT ASSY REAR AXLE RH REAR AXLE RH	TATA spare parts
266335700158	REAR AXLE SHAFT ASSY	TATA spare parts
266335700159	AXLE ASSY - REAR.	TATA spare parts
266335700160	REAR AXLE BEAM ASSY	TATA spare parts
266335700161	AXLE SHAFT ASSY	TATA spare parts
266335700162	SHAFT ASSY LH BS6	TATA spare parts
266335700163	SHAFT ASSY RH BS6	TATA spare parts
266335700164	REAR AXLE SHAFT LH	TATA spare parts
266335700165	REAR AXLE SHAFT RH	TATA spare parts
266335700166	AXLE ASSY PARTIAL REAR	TATA spare parts
266335700167	ASSY. REAR AXLE SHAFT RH BS3/4/6	TATA spare parts
266335700168	REAR AXLE SHAFT ASSY LH BS3/4/6	TATA spare parts
266335700173	REAR AXLE SHAFT ASSY LH	TATA spare parts
266335700174	REAR AXLE SHAFT ASSY RH	TATA spare parts
266335700178	SHAFT ASSY REAR AXLE COMPLETE RH BS6	TATA spare parts
266335700179	SHAFT ASSY REAR AXLE COMPLETE LH BS6	TATA spare parts
266335700185	REAR AXLE SHAFT ASSY LH BS6	TATA spare parts
266335700186	REAR AXLE SHAFT ASSY RH BS6	TATA spare parts
266335703101	BEARING TAPER ROLLER	TATA spare parts
266335703102	BEARING TAPER ROLLER	TATA spare parts
266335703104	TAPER ROLLER BEARING.	TATA spare parts
266335703105	TAPER ROLLER BEARING.	TATA spare parts
266335703106	BRG ROLLER DIFFL	TATA spare parts
266335703107	ASSY. TAPER ROLLER BRG. 565904 BS1/2/3/4	TATA spare parts
266335703108	RETAINER WH BRG INN D/S	TATA spare parts
266335703109	TAPER ROLLER BRG 30209	TATA spare parts
266335703110	TAPER ROLLER BRG (45X85X20.75)	TATA spare parts
266335703111	KIT BRG	TATA spare parts
266335703112	KIT BRG (PINION OUTER)	TATA spare parts
266335703113	KIT BRG (DIFF BRG)	TATA spare parts
266335703116	ASSY. TAPERED ROLLER BEARING BS2/3/4/6	TATA spare parts
266335703117	RETAINER -RX PICKUP	TATA spare parts
266335703118	RETAINER OIL SEAL (W/O OIL SEAL)	TATA spare parts
266335703120	BEARING ASSY(TAPERED ROLLER)(OPTIONAL) B	TATA spare parts
266335703201	BOLT BEARING CASE	TATA spare parts
266335703204	BRAKE MOUNTING BOLT.	TATA spare parts

266335703205	BOLT,WHEEL BOLT - BUTTON HEAD	TATA spare parts
266335704301	SNAP RING	TATA spare parts
266335704302	SNAP RING 48289	TATA spare parts
266335705102	BEARING CASE	TATA spare parts
266335705105	HOUSINGç -ç BEARINGç FIN	TATA spare parts
266335705106	HOUSING BEARING FIN TBD	TATA spare parts
266335705301	GASKET	TATA spare parts
266335705302	GASKET BEARING CASE	TATA spare parts
266335706101	LOCK WASHER	TATA spare parts
266335706102	L WASHER - LOCKNUT	TATA spare parts
266335706501	GROOVED LOCK NUT-RH THREADS	TATA spare parts
266335706502	GROOVED LOCK NUT WITH LH THREADING	TATA spare parts
266335706503	NUT-BEARING RETAINER (LH)	TATA spare parts
266335706504	NUT-BEARING RETAINER (RH)	TATA spare parts
266335707101	ROIL SEAL RETAINER ,ETR-637	TATA spare parts
266335707701	OIL SEAL SUPP TUBE INNER	TATA spare parts
266335707702	OIL SEAL	TATA spare parts
266335707703	OIL SEAL	TATA spare parts
266335707704	OIL SEAL	TATA spare parts
266335707705	OIL SEAL DOUBLE LIP	TATA spare parts
266335707706	OIL SEAL DOUBLE LIP	TATA spare parts
266335707707	OIL SEAL	TATA spare parts
266335707708	RETAINER OIL SEAL	TATA spare parts
266335707709	OIL SEAL(REAR) AXLE SHAFT BS1/2/3/4	TATA spare parts
266335707711	OIL SEAL (2006254)	TATA spare parts
266335707712	SEAL OIL - AXLE SHAFT (OUTBOARD)	TATA spare parts
266335707714	DEFLECTOR SEAL	TATA spare parts
266335707718	SEAL - OIL ( INBOARD) BS1/2/3/4/6	TATA spare parts
266335707719	O RING	TATA spare parts
266335707720	OIL SEAL	TATA spare parts
266335707721	OIL SEAL	TATA spare parts
266335707901	REAR AXLE SHAFT	TATA spare parts
266335707902	AXLE SHAFT SAFARI LSD	TATA spare parts
266335707905	AXLE SHAFT -SPIGOTTED	TATA spare parts
266335707907	AXLE SHAFT EXTRUDED (2.2 L DICOR)	TATA spare parts
266335707908	R.A. SHAFT (ABS)	TATA spare parts
266335707915	AXLE SHAFT -SPIGOTTED (XENON ABS)	TATA spare parts
266335707916	REAR AXLE SHAFT (407 AXLE FOR XENON)	TATA spare parts
266335707918	SHAFT ASSY SPIGOTTED M-LOCKER(XENON ABS)	TATA spare parts
266335707919	REAR AXLE SHAFT BS1/2/3/4	TATA spare parts
266335707923	SHAFT - FLANGED AXLE FIN (LH)(WITH GROOV	TATA spare parts
266335707924	SHAFT - FLANGED AXLE FIN (RH)	TATA spare parts
266335707927	REAR AXLE SHAFT ASSY RH	TATA spare parts
266335707928	REAR AXLE SHAFT ASSY LH	TATA spare parts
266335707934	SHAFT - FLANGED AXLE FIN SF (LH) BS6	TATA spare parts
266335707935	SHAFT - FLANGED AXLE FIN SF (RH) BS6	TATA spare parts
266335708001	SCREW-FLANG HEAD BS6	TATA spare parts

266335708201	OIL CATCHER	TATA spare parts
266335708303	SHIM HUB REAR 0.10 THK.	TATA spare parts
266335708304	SHIM 0.15 MM RR HUB	TATA spare parts
266335708305	SHIM 0.20 MM RR HUB	TATA spare parts
266335708306	SHIM 0.25 MM RR HUB	TATA spare parts
266335708307	SHIM 0.30 MM RR HUB	TATA spare parts
266335708308	SHIM 0.50 MM RR HUB	TATA spare parts
266335708309	SHIM 1.00 MM RR HUB	TATA spare parts
266335708310	SHIM 1.50 MM RR HUB	TATA spare parts
266335708312	SHIM ADJUSTMENT	TATA spare parts
266335708601	PRESSURE RING	TATA spare parts
266335708603	GUIDE - AXLE SHAFT	TATA spare parts
266335708604	RETAINER PLATE	TATA spare parts
266335709201	WASHER - THRUST	TATA spare parts
266335757901	AXLE SHAFT ( SPIGOTED ) RH THREADS	TATA spare parts
266335757902	AXLE SHAFT	TATA spare parts
266335757904	AXLE SHAFT ( SPIGOTED ) RH THREADS	TATA spare parts
266335757905	AXLE SHAFT (SUMO)	TATA spare parts
266335757906	AXLE SHAFT LH W/LH THREAD	TATA spare parts
266335757908	REAR AXLE SHAFT (SPIG) W/L.H THREADING.	TATA spare parts
266335757909	RR AXLE SHAFT	TATA spare parts
266335759901	FRICTION MODIFIER 40819	TATA spare parts
266354200101	INSTRUMENT CLUSTER RATIO 1:0.9	TATA spare parts
266358903501	HUB BEARING REMOVAL & PRESSING	TATA spare parts
266358903503	AXLE SHAFT HUB BEARING REMOVAL	TATA spare parts
266358903504	SOCKET LOCK NUT TIGHTENING	TATA spare parts
26640891	ENGAGING GEAR 5TH SPEED	TATA spare parts
266433050120	FRONT AXLE HOUSING W/TUBE	TATA spare parts
266433050123	ASSY FR AXLE COMP 407 4*4	TATA spare parts
266433050130	ASSY.FRONT LIVE AXLE COMP.W/BRK(3.88)RHD	TATA spare parts
266433050132	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
266433050136	FRONT AXLE BEAM ASSY BS6	TATA spare parts
266433150102	ASSY PROTECTIVE COVER BS6	TATA spare parts
266433153102	TAPER ROLLER BRG M12649/10	TATA spare parts
266433153103	T.R. BEARING KING PIN	TATA spare parts
266433153104	T.R.BRG.	TATA spare parts
266433153402	BUSH DRIVE SHAFT	TATA spare parts
266433157801	OIL SEAL DRIVE SHAFT	TATA spare parts
266433158203	BEARING COVER LOWER	TATA spare parts
266433158204	BEARING COVER UPPER	TATA spare parts
266433159903	ADAPTER-ON FRONT AXLE HOUSING	TATA spare parts
266433159904	ADAPTER (FOR BREATHER)	TATA spare parts
266433255105	KING PIN-LOWER	TATA spare parts
266433255106	KING PIN-UPPER	TATA spare parts
266433258205	LOCKING PLATE	TATA spare parts
266433258206	LOCKING PLATE	TATA spare parts
266433350101	COUPLING FLANGE	TATA spare parts

266433355101	COUPLING FLANGE	TATA spare parts
266433357801	OIL SEAL	TATA spare parts
266433450108	ASSY.WHEEL HUB BS6	TATA spare parts
266433455103	WHEEL HUB	TATA spare parts
266433455106	FRONT HUB BS6	TATA spare parts
266433457801	DUST SEAL	TATA spare parts
266433458201	DUST SEAL COVER	TATA spare parts
266433750124	ASSY.DRIVE SHFT.OUTER	TATA spare parts
266433750125	DRIVE SHAFT	TATA spare parts
266433750126	ASSY. DRIVE SHAFT LH BS2/3/4	TATA spare parts
266433750127	OUTER SHAFT	TATA spare parts
266433750128	ASSY. DRIVE SHAFT OUTER	TATA spare parts
266433750129	ASSY. DRIVE SHAFT OUTER (NEW)	TATA spare parts
266433750135	BALL HEAD HOUSING ASSY RH BS6	TATA spare parts
266433750136	BALL HEAD HOUSING ASSY LH BS6	TATA spare parts
266433753107	TAPER ROLLER BEARING-HUB OUTER	TATA spare parts
266433753108	TAPER ROLLER BEARING	TATA spare parts
266433753706	BALL HEAD HOUSING	TATA spare parts
266433753707	BALL HEAD HSG. LEFT	TATA spare parts
266433753710	BALL HEAD HOUSING ASSY RH RIGHT BS6	TATA spare parts
266433753711	BALL HEAD HOUSING LH LEFT BS6	TATA spare parts
266433754301	HOSE CLIP BIG	TATA spare parts
266433754302	HOSE CLIP SMALL	TATA spare parts
266433754303	CIRCLIP	TATA spare parts
266433755303	GASKET.	TATA spare parts
266433756102	LOCK WASHER	TATA spare parts
266433756502	GROOVED NUT	TATA spare parts
266433757703	SEALING RING	TATA spare parts
266433757704	RUBBER BELLOW C VJOINT	TATA spare parts
266433757801	OIL SEAL INNER	TATA spare parts
266433757907	DRIVE SHAFT FRT AXLE RH	TATA spare parts
266433757908	FRT.AXLE DR.SHFT INNER L.	TATA spare parts
266433758205	SEAL HOLDER INNER	TATA spare parts
266433758206	SEAL HOLDER OUTER	TATA spare parts
266433758320	SHIM 0.2MM	TATA spare parts
266433758321	SHIM 0.25MM	TATA spare parts
266433758322	SHIM 0.3MM	TATA spare parts
266433758323	SHIM-0.4 THK	TATA spare parts
266433758324	SHIM-0.5 THK.	TATA spare parts
266433758325	SHIM-0.6 THK.	TATA spare parts
266433758326	SHIM-0.8 THK.	TATA spare parts
266433758327	SHIM 1.0 MM THICK	TATA spare parts
266433758328	SHIM 0.1MM THK	TATA spare parts
266433759902	LUBRICATING GREASE TUBE (80 GMS)	TATA spare parts
266435300101	ASSY COUPLING FLANGE	TATA spare parts
266435305425	SIDE GEAR DIFF. ( 2 NOS )	TATA spare parts
266435708312	SHIM ADJ	TATA spare parts

266437533108	DIFFERENTIAL BEARING	TATA spare parts
266535000101	ASSY.RA.407-4X4 37/8-RATIO 31-W.B	TATA spare parts
266535000103	ASSY.RA407 LPT W/PARK HAND BRK CABLE 31W	TATA spare parts
266535000104	ASSY.R.A.COMP.W/STD BRK TURBO ENG (27WB)	TATA spare parts
266535000105	REAR AXLE COMPLETE LP407 35/9	TATA spare parts
266535000114	ASSY RA 407 TRUCK EXP 35/9 RATIO	TATA spare parts
266535000118	ASSY RA.407 BUS STG.II 35/9 W0/LCRV ARB	TATA spare parts
266535000119	ASSLY R.EXLE COMP.WITH BRAKES-31WB	TATA spare parts
266535000121	ASSY RA407 SFC 37/8 T/CF SPG BRK DRUM	TATA spare parts
266535000129	ASSY.RA.407-4X4	TATA spare parts
266535000130	ASY R.A. RATIO-35/9COMP W/BRKS 304 DIA	TATA spare parts
266535000134	ASSY.R.A.COMP.37/8 CNG BSIII VEHICLE	TATA spare parts
266535000137	ASSY RA WITH BRKS 35/9 W/SD	TATA spare parts
266535000153	ASSY RA 410 4.1 RATIO COMPLETE W/BRKS	TATA spare parts
266535000154	ASSY RA WITH 3.36 (37/11) FOR 407 UPGRAD	TATA spare parts
266535000157	RA SFC 407 BSIV ( 35/9 )	TATA spare parts
266535000161	RA 410PICKUP ( 37/11 )	TATA spare parts
266535000163	ASSY REAR AXLE 410 33/8 COMPLETE	TATA spare parts
266535000166	ASSY REAR AXLE WITH 35/9 (3.88) RATIO W/	TATA spare parts
266535000169	RA 410BUS BANJO ( 37/11 )	TATA spare parts
266535000178	ASSY REAR AXLE WITH 35/9 (3.88) RATIO W/	TATA spare parts
266535000181	ASSY RA COMP (410 BANJO) COMPLETE RATIO	TATA spare parts
266535000182	ASSY.REAR AXLE COMP.(35/9 RATIO)	TATA spare parts
266535000185	REAR AXLE ASSY WITH BRAKE 410 BANJO	TATA spare parts
266535000186	REAR AXLE 407 W/35/9(3.88) W/ARB SPI.FLA	TATA spare parts
266535000188	REAR AXLE 407 WITH 35/9 (3.88) RATI	TATA spare parts
266535000190	REAR AXLE ASSY WITH BRAKE 410 BANJO	TATA spare parts
266535000193	REAR AXLE ASSY WITH BRAKE 410 BANJO	TATA spare parts
266535050101	ASSY REAR AXLE COMP W/BRAKES 35/9 RATIO	TATA spare parts
266535050110	REAR AXLE ASSY WITH BRAKE	TATA spare parts
266535050113	REARAXLEASSYWITHHUB410BANJO BS6	TATA spare parts
266535050114	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266535050116	REAR AXLE ASSY ABS	TATA spare parts
266535050119	REAR AXLE ASSY WITH HUB BS6	TATA spare parts
266535050120	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266535050127	REAR AXLE ASSY WITH HUB BS6	TATA spare parts
266535050128	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266535050129	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266535050135	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266535100101	REAR AXLE BEAM 407 4X4	TATA spare parts
266535100103	ASSY RA BEAM 507 W/LCRV BKT FRANCE HSG	TATA spare parts
266535100104	ASSY R A HSG WITH PLUMMER BLOCK COVER	TATA spare parts
266535100105	ASSY.RA.BEAM 407	TATA spare parts
266535100106	ASSY.RA.BEAM 407 TRUCK EXP 35/9	TATA spare parts
266535100114	ASY RA.HSG W/SUPP.TUBE COMP 407 UPGRADE	TATA spare parts
266535100118	ASY RA HSG W/SUP.TUBE W/O LCRV W A/R BAR	TATA spare parts
266535100120	ASSY.REAR AXLE BEAM (MACHINED) SD	TATA spare parts



266535100125	ASSY.R.A.HOUSING WITH SUPPORTING TUBE	TATA spare parts
266535100129	ASSY RA HSG WITH SUPPORTING TUBE	TATA spare parts
266535100131	ASSY REAR AXLE HOUSING WITH SUPPORTING T	TATA spare parts
266535100132	ASSY COVER¿ REAR AXLE HSG.	TATA spare parts
266535100144	ASSY REAR AXLE WITH PRESSURE RING	TATA spare parts
266535100156	ASSY REAR AXLE BEAM WITH PRESSURE RING	TATA spare parts
266535100160	ASSY RA HSG WITH SUPPORTING TUBE (SPI. F	TATA spare parts
266535100164	ASSY REAR AXLE HOUSING WITH SUPPORTING T	TATA spare parts
266535100167	REAR AXLE BEAM MACHINED (WELDED COVER)	TATA spare parts
266535100169	ASY RA HSG W/SUPP.TUBE W/ARB(SPI.FLANGE)	TATA spare parts
266535100170	ASSY RA HSG WITH SUPP. TUBE W/SHO. ABS (	TATA spare parts
266535100172	ASSY REAR AXLE BEAM MACH(WELDED COVER) B	TATA spare parts
266535100173	REAR AXLE BEAM W/ PR RING STUD & DOWEL	TATA spare parts
266535100184	AXLE BEAM ASSY	TATA spare parts
266535100185	REAR AXLE BEAM ASSY WITH PRESSURE RING B	TATA spare parts
266535100208	REAR AXLE BEAM ASSY WITH PRESSURE RING P	TATA spare parts
266535107101	BRACKET-(REMOTE BREATHER)	TATA spare parts
266535108201	OIL SLINGER	TATA spare parts
266535108601	PRESSURE RING (407 UPGRADE )	TATA spare parts
266535108602	PRESSURE RING CASE CARBURIZED	TATA spare parts
266535110103	ASSY.CARRIER HOUSING	TATA spare parts
266535110108	ASSY CARRIER HOUSING (230 DIA CW)	TATA spare parts
266535110110	ASSY CARRIER HOUSING 4.1	TATA spare parts
266535110117	CARRIERHOUSINGASSY BS6	TATA spare parts
266535110119	CARRIERASSY410BANJOREARAXLE BS6	TATA spare parts
266535110127	CARRIER HOUSING ASSY COMP 410 BANJO REAR	TATA spare parts
266535113704	PLUMMER BLOCK COVER BS6	TATA spare parts
266535115301	GASKET (BETWEEN CARRIER & BEAM)	TATA spare parts
266535115302	GASKET (BET'N BEAM & CARRIER)	TATA spare parts
266535300101	ASSY DIFFERENTIAL REAR AXLE BS6	TATA spare parts
266535300102	CWP SET 35/9 OERL 407 EURO II	TATA spare parts
266535300103	CWP SET 37/8 GLEA LPLPTSFC407	TATA spare parts
266535300104	DIFFERENTIAL GEAR KIT W/SPIDER 407	TATA spare parts
266535300108	ASSY SPACER (W/PRESS FIT OIL SLINGER)	TATA spare parts
266535300113	DIFFERENTIAL HOUSING ASSY 407 UPGRADE	TATA spare parts
266535300114	DIFFERENTIAL ASSY WITH CROWN WHEEL BS6	TATA spare parts
266535300115	ASSY CROWN WHEEL & PINION 35/9407-UPGRD	TATA spare parts
266535300117	ASSY CW/PINION (37/11)OER-HN2(407 UPGRAD	TATA spare parts
266535300124	ASSY. CROWN & PINION (GLEASON)35/9 BS2-4	TATA spare parts
26653530012490	ASSY.C.W.P (GLEASON)35/9 W/O BONDERISING	TATA spare parts
266535300154	DIFFERENTIAL ASSY BS6	TATA spare parts
266535300155	ASSY. CROWN & PINION (33/8) 407 BS3/4	TATA spare parts
266535300168	PINIONASSY BS6	TATA spare parts
266535300177	ASSY. DIFF. GEAR W/SPIDER BS2/3/4/6	TATA spare parts
266535303101	CYL.ROLLER BRG	TATA spare parts
266535303103	TAPER ROLLER BEARING	TATA spare parts
266535303104	TAPER ROLLER BRG DIFF	TATA spare parts

266535303105	TAPER ROLLER BRG	TATA spare parts
266535303106	CYL.ROLLER BRG	TATA spare parts
266535303107	TAPER ROLLER BRG	TATA spare parts
266535303108	TAPER ROLLER BRG DIFF	TATA spare parts
266535303109	TAPER ROLLER BRG DIFF	TATA spare parts
266535303110	TAPER ROLLER BEARING	TATA spare parts
266535303111	CYL.ROLLER BRG	TATA spare parts
266535303112	TAPER ROLLER BRG 33010	TATA spare parts
266535303113	CYL.ROLLER BRG	TATA spare parts
266535303114	TAPER ROLLER BRG DIFF	TATA spare parts
266535303115	CYL.ROLLER BRG	TATA spare parts
266535303116	TAPER ROLLER BEARING	TATA spare parts
266535303117	TAPER ROLLER BRG.	TATA spare parts
266535303118	TAPER ROLLER BRG.	TATA spare parts
266535303119	TAPER ROLLER BEARING	TATA spare parts
266535303120	TAPER ROLLER BEARING	TATA spare parts
266535303121	TAPER ROLLER BRG.	TATA spare parts
266535303122	TAPER ROLLER BRG (50X80X24)	TATA spare parts
266535303123	TAPER ROLLER BRG BS6	TATA spare parts
266535303125	TAPER ROLLER BRG BS6	TATA spare parts
266535303126	CYL.ROLLER BEARING 25X62X17 CAGELESS	TATA spare parts
266535303130	TAPER ROLLER BEARING BS6	TATA spare parts
266535305402	CROWN WHEEL (35/9)	TATA spare parts
266535305409	PINIONBS6	TATA spare parts
266535305416	PINION TAIL BS6-PH2	TATA spare parts
266535305418	REAR AXLE SHAFT GEAR (9X14)	TATA spare parts
266535305419	DIFFERENTIAL BEVEL PINION	TATA spare parts
266535305420	TAIL PINION - (33/8) 4.125 SPIROFLEX	TATA spare parts
266535306501	THREADED RING (FOR OIL SLINGER) T.PINIO	TATA spare parts
266535306502	THREADED RING DIFFERENTIAL 407 UPGRADE	TATA spare parts
266535306503	THREADED RING TAIL PINION 407 UPGRADE	TATA spare parts
266535307701	OIL SEAL	TATA spare parts
266535307702	OIL SEAL TAIL PINION 407	TATA spare parts
266535307703	OIL SEAL	TATA spare parts
266535307704	OIL SEAL	TATA spare parts
266535307705	OIL SEAL	TATA spare parts
266535307706	OIL SEAL-PTFE	TATA spare parts
266535307707	OIL SEAL (PTFE-48X65X10)	TATA spare parts
266535307801	DUST SEAL-MECHANICAL	TATA spare parts
266535308201	DUST COVER-PRESS FIT	TATA spare parts
266535308202	OIL SLINGER (PRESS FIT)	TATA spare parts
266535308203	DEFLECTOR & SEAL	TATA spare parts
266535308301	PINION DEPTH SETTING SHIM 0.10 THK.	TATA spare parts
266535308302	PINION DEPTH SETTING SHIM 0.15 THK	TATA spare parts
266535308303	PINION DEPTH SETTING SHIM 0.20 THK	TATA spare parts
266535308304	PINION DEPTH SETTING SHIM 0.25 THK	TATA spare parts
266535308305	PINION DEPTH SETTING SHIM 0.30 THK	TATA spare parts

266535308306	PINION DEPTH SETTING SHIM 0.45 THK	TATA spare parts
266535308307	PINION DEPTH SETTING SHIM 0.50 THK	TATA spare parts
266535308308	PINION DEPTH SETTING SHIM 1.0 THK	TATA spare parts
266535308309	PINION DEPTH SETTING SHIM 1.5 THK	TATA spare parts
266535308601	SPACER FOR OIL SLINGER(BET BRG & C.FLNG	TATA spare parts
266535308602	SPACER BET.HYP-PINION BRG -407-UPGRADE	TATA spare parts
266535309201	THRUST WASHER 1.25 THK	TATA spare parts
266535309202	THRUST WASHER 1.30 THK	TATA spare parts
266535309203	THRUST WASHER 1.35 THK	TATA spare parts
266535309204	THRUST WASHER 1.40 THK	TATA spare parts
266535309205	THRUST WASHER 1.45 THK	TATA spare parts
266535309206	THRUST WASHER 1.50 THK	TATA spare parts
266535309207	THRUST WASHER 1.55 THK	TATA spare parts
266535600101	ASSY.BRAKE DRUM WITH HUB-M16 STUDS	TATA spare parts
266535600106	ASSY.REAR HUB-M16 STUD	TATA spare parts
266535600110	ASSY BRK DRUM W/HUB COMP (407 UPGRADE )	TATA spare parts
266535600125	HUBASSYBS6	TATA spare parts
266535600126	REAR HUB ASSY WITH BEARING BS6	TATA spare parts
266535600127	REARHUBASSYWITHBEARING BS6	TATA spare parts
266535603101	TAPER ROLLER BRG	TATA spare parts
266535603102	TAPER ROLLER BRG	TATA spare parts
266535603103	BEARING TAPER ROLLER	TATA spare parts
266535603104	TAPER ROLLER BEARING	TATA spare parts
266535603105	TAPER ROLLER BEARING	TATA spare parts
266535603106	TAPER ROLLER BEARING	TATA spare parts
266535603107	TAPER ROLLER BEARING	TATA spare parts
266535603108	TAPER ROLLER BRG 32210	TATA spare parts
266535603109	TAPER ROLLER BRG 33112	TATA spare parts
266535603110	TAPER ROLLER BEARING(60X100X30)	TATA spare parts
266535603111	TAPER ROLLER BEARING(60X100X30)	TATA spare parts
266535603112	TAPER ROLLER BRG.(55X95X30)	TATA spare parts
266535603113	TAPER ROLLER BEARING(60X100X30)	TATA spare parts
266535603114	TAPER ROLLER BRG.(50X90X24.75)	TATA spare parts
266535603701	REAR BRAKE DRUM W/HUB M16 STUD BS2/3/4	TATA spare parts
266535603702	BRAKE DRUM SPIGOTTED 407	TATA spare parts
266535603704	BRAKE DRUM W/HUB (709 HUB/407 BRK) BS2/4	TATA spare parts
266535603705	REAR BRAKE DRUM W/HUB 308DIA. BS3/4	TATA spare parts
266535603707	REAR BRAKE DRUM W/HUB CAST 407ST BS2/3/4	TATA spare parts
266535603709	DRUM BRAKE W/HUB REAR BS3/4	TATA spare parts
266535603711	REAR HUB	TATA spare parts
266535605301	GASKET	TATA spare parts
266535607701	OIL SEAL	TATA spare parts
266535607702	OIL SEAL	TATA spare parts
266535607703	OIL SEAL	TATA spare parts
266535607704	OIL SEAL	TATA spare parts
266535607705	OIL SEAL	TATA spare parts
266535607706	OIL SEAL	TATA spare parts

266535607707	OIL SEAL (HUB INNER) 80X100X10	TATA spare parts
266535607708	OIL SEAL (75X95X12)	TATA spare parts
266535608301	SHIM (0.05 THK)	TATA spare parts
266535608302	SHIM-0.1 THK	TATA spare parts
266535608303	SHIM-0.15 THK	TATA spare parts
266535608304	SHIM-0.2 THK	TATA spare parts
266535608305	SHIM-0.25 THK	TATA spare parts
266535608306	SHIM-0.3 THK	TATA spare parts
266535608307	SHIM-0.5 THK	TATA spare parts
266535608308	SHIM-1.0 THK	TATA spare parts
266535608309	SHIM-1.5 THK	TATA spare parts
266535608310	SHIM-2.5 THK	TATA spare parts
266535608601	SPACER TUBE-BETWEEN HUB BEARINGS	TATA spare parts
266535608801	STUD M16 407	TATA spare parts
266535707901	RR AXLE SHAFT 407 4X4	TATA spare parts
266535707902	REAR AXLE SHAFT-4X2-FOR M16 STUDS	TATA spare parts
266535707903	REAR AXLE SHAFT-4X4-FOR M16 STUDS	TATA spare parts
266535708312	SHIM ADJ	TATA spare parts
2665H9W0135003	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2665H9W0135004	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2665H9W0135005	LIVE REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
266733000102	FRONT AXLE ASSY WITH TIE ROD	TATA spare parts
266733050102	FRONT LIVE AXLE DANA 4.1R	TATA spare parts
266733050157	ASSY.FR.LIVE AXLE W/O HUB-4.56(STD)	TATA spare parts
266733050163	AXLE HOUSING ASSY	TATA spare parts
266733050165	ASSY.FR.LIVE AXLE W/O HUB-488(STD)	TATA spare parts
266733050198	ASSY.FR.LIVE AXLE 3.73 W/O HUB-TWIN	TATA spare parts
266733050202	ASSY.FRONT LIVE AXLE RATIO 3.73 W/O HUB	TATA spare parts
266733050205	ASSY.FR.AXLE-3.36-TWIN POT	TATA spare parts
266733050232	ASY.FR.AXLE-3.36-TWIN POT	TATA spare parts
266733050235	ASY.FR.LIVE AXLE-4.1-TWINPOT-1560TR	TATA spare parts
266733050238	ASSY.FRONT AXLE-(RATIO 3.73 -TWIN POT CA	TATA spare parts
266733050247	ASY FR LIVE AXLE 3.73 ABS 1560 TRK XENON	TATA spare parts
266733050266	ASY.FR.LIVE AXLE-4.1-TWINPOT	TATA spare parts
266733050272	ASY.FR.AXLE-3.73 TWIN POT	TATA spare parts
266733050279	ASY FR LIVE AXLE W/O HUB W/4.1 RATIO AB	TATA spare parts
266733050283	ASSY FRONT AXLE¿ LIVE3.73 ABS D.MECH XEN	TATA spare parts
266733050285	ASSY FA LIVE3.73 NABS D.MECH	TATA spare parts
266733050287	ASSY FA LIVE 4.1 ABS D.MECH XENON R.SCRB	TATA spare parts
266733050291	FRONT AXLE ASSY FRONT LIVE AXLE ASSY	TATA spare parts
266733050298	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
266733050302	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
266733050303	FRONT AXLE ASSY	TATA spare parts
266733050308	FRONT AXLE ASSY	TATA spare parts
266733100101	COVER ASSY FRONT AXLE HOUSING	TATA spare parts
266733100125	COVER ASSY FRONT AXLE HOUSING	TATA spare parts
266733107201	FILLER PLUG	TATA spare parts

266733107202	DRAIN PLUG	TATA spare parts
266733108201	COVER CARRIER FIN 46788	TATA spare parts
266733108202	COVER AXLE HOUSING FINISHED - ETR-497	TATA spare parts
266733108204	"COVER,FRONT AXLE HOUSING"	TATA spare parts
266733109901	ADAPTOR	TATA spare parts
266733150109	MOUNTING BRACKET ASSY.- RH	TATA spare parts
266733150110	MOUNTING BRACKET ASSY.- LH	TATA spare parts
266733150111	ASSEMBLY CARRIER HOUSING WITH TUBE	TATA spare parts
266733150112	ASSY TUBE WITH COUPLING NUT	TATA spare parts
266733150113	ASSY CARRIER HOUSING W/ PLUMMER BLOCK	TATA spare parts
266733150116	ASSY FRONT AXLE HSG. W/S.TUBE & YOKE	TATA spare parts
266733150117	BRACKET MOUNTING BRACKET ASSEM (RH)	TATA spare parts
266733150118	BRACKET MOUNTING BRACKET ASSEM (LH)	TATA spare parts
266733150119	SHAFT & JOINT ASSY RH - 2009166	TATA spare parts
266733150120	SHAFT & JOINT ASSY LH - 2009165	TATA spare parts
266733150121	FRONT AXLE DISCONNECT MOTO KIT	TATA spare parts
266733150122	CARRIER HOUSING ASSY CARRIER HSG WTH TUB	TATA spare parts
266733150123	GASKET	TATA spare parts
266733151601	RUBBER HOSE FOR XENON SCRUB FRONT LIVE A	TATA spare parts
266733153302	BRACKET - BRAKE HOSE	TATA spare parts
266733153402	SLEEVE	TATA spare parts
266733155407	DIFFERENTIAL BEVEL PINION BS6	TATA spare parts
266733155408	DIFFERENTIAL BEVEL GEAR BS6	TATA spare parts
266733156905	FRONT AXLE TUBE LH	TATA spare parts
266733156906	FRONT AXLE TUBE-RH	TATA spare parts
266733158212	DUST COVER	TATA spare parts
266733257901	SUPPORT SLEEVE	TATA spare parts
266733259901	ADAPTOR FIN ABS SENSOR	TATA spare parts
266733350101	END YOKE ASSY 248111-1	TATA spare parts
266733350103	CROWN WHEEL/PINION 41/11(3.73) 2007381-A	TATA spare parts
266733350109	CROWN WHEEL/PINION KIT 3.36	TATA spare parts
266733350111	RING GEAR PINION KIT (GEAR RATIO 3.73)	TATA spare parts
266733350113	CROWN WHEEL/PINION KIT 3.73	TATA spare parts
266733357801	SEAL-OIL BS6	TATA spare parts
266733358201	INNER SLINGER PINION OIL	TATA spare parts
266733358202	OUTER SLINGER PINION OIL	TATA spare parts
266733453103	UNITISED TAPER ROLLER BRG	TATA spare parts
266733453104	NEEDLE ROLLER BEARING	TATA spare parts
266733453105	BEARING FRONT HUB	TATA spare parts
266733453701	FOLLOWER	TATA spare parts
266733453702	FRONT HUB	TATA spare parts
266733458201	WHEEL END CAP	TATA spare parts
266733459202	TONGUED WASHER	TATA spare parts
266733500101	KIT DIFFERENTIAL ASSY	TATA spare parts
266733500102	ASSY.BRG.DIFFERENTIAL- 550433/734	TATA spare parts
266733500103	DIFF. CASE GEAR KIT (MAJOR)	TATA spare parts
266733500104	DIFF. CASE KIT ( MINOR )	TATA spare parts

266733500112	DIFFERENTIAL HSG ASSY W/CW- 41/11 RATIO	TATA spare parts
266733500116	CROWN WHEEL & PINION ASSY	TATA spare parts
266733503101	BRG CUP ROLLER (550433/734)	TATA spare parts
266733504301	RING SNAP RH C V SHAFT	TATA spare parts
266733504302	RING SNAP LH AXLE SHAFT	TATA spare parts
266733505101	DIFFL CASE STD 46786	TATA spare parts
266733505401	DIFF.GEAR (SIDE GEAR)	TATA spare parts
266733505402	PINION DIFF FIN 32926	TATA spare parts
266733507901	DIFFERENTIAL SHAFT STD	TATA spare parts
266733508301	SHIM ADJ. 30215	TATA spare parts
266733509201	TH WASHER DIFFL SIDE GEAR	TATA spare parts
266733509202	THRUST WASHER DIFFL 34096	TATA spare parts
266733550101	GEAR & PINION ASSY 4.56	TATA spare parts
266733550102	GR & PIN HYP ASSY FR 4.10	TATA spare parts
266733550103	BRG PINION INNER	TATA spare parts
266733550104	BRG PINION OUTER-550459/754	TATA spare parts
266733550109	GEAR & PINION ASSY-41/10(4.1)-74348 FOR	TATA spare parts
266733550114	RING GEAR/PINION KIT-39/8(4.88)	TATA spare parts
266733550116	PINION OIL SEAL KIT 59	TATA spare parts
266733550119	RING GEAR/PINION KIT-44/9 (4.88)	TATA spare parts
266733550120	GEAR & PINION ASSY-44/9 (4.88)	TATA spare parts
266733550121	KIT-OIL SEAL	TATA spare parts
266733553101	BRG.CONE ROLLER (PINION INNER)550456	TATA spare parts
266733553102	ROLLER BEARING CUP	TATA spare parts
266733553103	ROLLER BRG CONE 550754	TATA spare parts
266733553104	ROLLER BEARING CUP	TATA spare parts
266733557801	PINION OILSEAL BS1/2/3/4/6	TATA spare parts
266733558001	HEX SCREW	TATA spare parts
266733558601	SPACER COLLAPSIBLE	TATA spare parts
266733750101	KIT FOR RZEPPA BOOT	TATA spare parts
266733750102	KIT FOR DOJ JOINT BOOT	TATA spare parts
266733750103	BEARING WHEEL HUB INNER-550430/31	TATA spare parts
266733750103AE	HUB BRG INNER -SUMO-XENON DC/SC	TATA spare parts
266733750104	BRG WHEEL HUB OUTER-550432/33 550759	TATA spare parts
266733750104AE	HUB BRG OUTER -SUMO-XENON DC/SC	TATA spare parts
266733750106	SHAFT AND JOINT ASSY RH-46802	TATA spare parts
266733750107	SHAFT AND JOINT ASSY LH-46803	TATA spare parts
266733750108	NUT & PIN ASSY BRG 75656X	TATA spare parts
266733750111	HUB LOCK ASSY	TATA spare parts
266733750116	HUB LOCK ASSY	TATA spare parts
266733750117	SERVICE KIT-AUTO HUB LOCK 4X4 VEHICLES	TATA spare parts
266733750117AE	SERV KIT HUB LOCK ASSY XEN DC/SC	TATA spare parts
266733750119	ASSY. CV RH BS3/4	TATA spare parts
266733750120	CV ASSEMBLY LH	TATA spare parts
266733750120AE	CV ASSEMBLY LH XEN DC XEN SC	TATA spare parts
266733750126	YOKE ASSY	TATA spare parts
266733750127	FRONT AXLE CV SFT CV ASSM RH - ABS BS3/4	TATA spare parts

266733750128	FRONT AXLE CV SFT CV ASSEM LH-ABS BS3/4	TATA spare parts
266733750129	FRONT AXLE CV SHAFT CV ASSM RH-NON ABS	TATA spare parts
266733750130	FRONT AXLE CV SHAFT CV ASSM LH-NON ABS	TATA spare parts
266733750131	FRONT AXLE SHAFT ASSY WITH UJ RH	TATA spare parts
266733750132	FRONT AXLE SHAFT ASSY WITH UJ LH	TATA spare parts
266733750137	KIT-UNIVERSAL JOINT BS6	TATA spare parts
266733753103	ROLLER BRG CUP	TATA spare parts
266733753104	OUT BRG CONE ROLLER550433	TATA spare parts
266733753105	BEARING ASSY W/O RACE	TATA spare parts
266733753106	BEARING ASSY W/O RACE	TATA spare parts
266733753107	BEARING ASSY W/O RACE	TATA spare parts
266733753108	BEARING FRONT AXLE BRG ASSY (W/O RACE)	TATA spare parts
266733753201	WHEEL BOLT 45842 - 1	TATA spare parts
266733753202	HEX.SOCKET HD.CAP SCR.M10X1.5X25	TATA spare parts
266733754202	CLAMP-00-11-59-3	TATA spare parts
266733754305	SNAP RING	TATA spare parts
266733754306	RING SNAP	TATA spare parts
266733754309	RING SNAP	TATA spare parts
266733755101	HUB WHEEL FIN 46805	TATA spare parts
266733755104	HUB WHEEL FIN FOR ABS	TATA spare parts
266733756101	LOCK WASHER 47107	TATA spare parts
266733756501	NUT SPINDLE 46801	TATA spare parts
266733756502	LOCK BRG ADJ RING 39909	TATA spare parts
266733757701	BOOT	TATA spare parts
266733757801	OIL SEAL	TATA spare parts
266733757802	OIL SEAL-40709	TATA spare parts
266733757803	OIL SEAL IN SPINDLE-45651	TATA spare parts
266733757803AE	OIL SEAL (IN SPNDL) -XENON DC/SC	TATA spare parts
266733757804	OIL SEAL-43085-2	TATA spare parts
266733757901	SPINDLE WHEEL BRG FIN	TATA spare parts
266733757902	AXLE SHAFT FIN-46980-1	TATA spare parts
266733757904	FRONT AXLE CV SHAFT - AXLE FIN	TATA spare parts
266733757905	INTERMEDIATE SHAFT	TATA spare parts
266733757906	FRONT AXLE BEAM SPINDLE FINISH	TATA spare parts
266733758001	HEX SCREW	TATA spare parts
266733758201	SHIELD BRAKE DUST RH46796	TATA spare parts
266733758202	SHIELD BRAKE DUST LH	TATA spare parts
266733758203	DUST COVER DEFLECTOR - END YOKE	TATA spare parts
266733758204	DUST COVER LH	TATA spare parts
266733758205	DUST COVER RH	TATA spare parts
266733759904	BREATHER	TATA spare parts
266733850103	KNUCKLE ARM LH KNUCKLE KIT - LH ABS	TATA spare parts
266733850104	KNUCKLE ARM LH KNUCKLE KIT - RH ABS	TATA spare parts
266733853701	KNUCKLE STRG LH FIN 46791	TATA spare parts
266733853702	KNUCKLE STRG RH FIN 46789-46791	TATA spare parts
266733853703	KNUCKLE - LH,[ETR-561 (LH)].	TATA spare parts
266733853704	KNUCKLE - RH	TATA spare parts

266733853705	KNUCKLE LH (TWIN POT)	TATA spare parts
266733853706	KNUCKLE RH (TWIN POT)	TATA spare parts
266733856501	NUT LOCK	TATA spare parts
266733858001	HEX BOLT 36326 - 1	TATA spare parts
266733859902	TONER RING	TATA spare parts
2667H9X0233001	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
266835000103	ASSY RA108-RR COMP 1512 TC 1613	TATA spare parts
266835000105	ASSY.RA108RR COMP WITH SCAM BRAKES	TATA spare parts
266835000135	ASSY RA.COMP W/REMOTE BRE S-CAM BRK 41/7	TATA spare parts
266835000137	ASSY R.A.COMP W/DAOH BRK DIRECT BRE 41/	TATA spare parts
266835000139	ASSY R.A COMP W/DAOH BRK REMOTE BRE 41/7	TATA spare parts
266835000146	ASSY.RA108 RRM 41/7 LARGER HUB BRG/AIL	TATA spare parts
266835000153	ASSY RA 108 RR COMP WITH BRAKES 37/7	TATA spare parts
266835000161	ASSY R.A. COMPLETE 41/7, HIGH TORQUE	TATA spare parts
266835000199	ASSY.RA-108RR 41/7 AUTO SLACK ADJ.BRKS.	TATA spare parts
266835000204	ASSY RA-108RR-41/7130 C FLAF-235 BRKS	TATA spare parts
266835000205	ASSY.RA-108RR-37/7 130 C.FL AF-235 BRKS	TATA spare parts
266835000206	ASSY.RA-108RR-37/7 130 C.FL AF-235 BRKS	TATA spare parts
266835000208	ASSY RA-108RR-41/7130 C FLAF-235 BRKS	TATA spare parts
266835000209	ASSY.RA-108RR-41/7 AF-235 NEW BRK.DRUM	TATA spare parts
266835000210	ASSY.RA-108RR-41/7 AF-235 NEW BRK.DRUM	TATA spare parts
266835000216	ASSY.RA-108RR-41/7 1044 130 VOSS	TATA spare parts
266835000224	ASSY REAR AXLE RA-108RR COMPLETE-37/7 A	TATA spare parts
266835000232	RA-108RR 37/7 1055 130 AIR SUSPN FAB.BKT	TATA spare parts
266835000234	ASSY REAR AXLE COMP.RA-108RR COMP37.7WIL	TATA spare parts
266835000240	RA-108RR 41/7 1055 S-CAM BRKS D/LOC	TATA spare parts
266835000242	RA-108RR 41/7 130 NGT1055	TATA spare parts
266835000244	ASSY REAR AXLE RA-108RR 37/7 NGT	TATA spare parts
266835000249	ASSY REAR AXLE RA-108RR 41/7MASU BRKS	TATA spare parts
266835000250	ASSY REAR AXLE COMP.RA-108RR;41/7	TATA spare parts
266835000256	ASSY REAR AXLE COMP.RA-108RR 41/7 130 NG	TATA spare parts
266835000264	REARAXLEASSYWITHBRAKEABS BS6	TATA spare parts
266835000265	REAR AXLE ASSY WITH HUB ABS BS6	TATA spare parts
266835000276	REAR AXLE ASSY COMP. 41/7 130 NGT ABS	TATA spare parts
266835000277	REAR AXLE ASSY WITH BRAKE	TATA spare parts
266835000279	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
266835000282	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
266835000285	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
266835000288	REAR AXLE ASSY WITH BRAKE 1055 41/7 130	TATA spare parts
266835000289	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
266835000290	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
266835000294	REAR AXLE ASSY WITH BRAKE	TATA spare parts
266835000296	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
266835000306	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
266835000308	REAR AXLE ASSY WITH BRAKE	TATA spare parts
266835000330	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
266835000331	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts



266835000333	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
266835000343	REAR AXLE ASSY WITH BRAKE	TATA spare parts
266835000348	REAR AXLE ASSY WITH HUB ABS 41/7 1055 T-	TATA spare parts
266835000349	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
266835100124	ASSY R.A W/PRESSURE RING STUD & DOWEL	TATA spare parts
266835100130	ASSY R A BEAM MACHINED	TATA spare parts
266835100142	ASSY.R.A.BEAM MC/ED (TML HOT FORM)	TATA spare parts
266835100145	ASSY.R.A.BEAM WITH PR.RING STUD & DOWEL	TATA spare parts
266835100154	ASSY.RA BEAM W/PR.RING/STUD & DOWEL	TATA spare parts
266835100161	ASSY. REAR AXLE BEAM WITH PR. RING AND S	TATA spare parts
266835100163	ASSY.RA BEAM W/PR.RING STUD & DOWEL	TATA spare parts
266835100168	ASSY RA BEAM W/PR RING STUD & DOWEL ABS	TATA spare parts
266835100175	ASSY.RA BEAM W/PR.RING STUD DOWEL(LCRV)	TATA spare parts
266835100183	ASSY.RA BEAM W/PR.RING STUD & DOWEL	TATA spare parts
266835100187	ASSY REAR AXLE BEAM M/CED.( BMTCL APPL)	TATA spare parts
266835100189	ASSY.R.A.BEAM W/PR.RING STUD & DOWEL	TATA spare parts
266835100196	ASSY R.A.BEAM W.PR.RINGSTUD & DOWEL	TATA spare parts
266835100197	ASSY.RA BEAM (M/CED)-AIR SUSPN	TATA spare parts
266835100203	REAR AXLE BEAM ASSY ABS MACHINED BS6	TATA spare parts
266835100206	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
266835100207	ASSY RA BEAM W/PR RING & DOWEL	TATA spare parts
266835100214	R.A.BEAM WITH PR.RING STUD & DOWEL	TATA spare parts
266835100218	REAR AXLE BEAM W/PR.RING STUD & DOWEL	TATA spare parts
266835100224	REAR AXLE BEAM ASSY BS6	TATA spare parts
266835100225	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
266835100226	REAR AXLE BEAM ASSY WITH PRESSURE RING	TATA spare parts
266835100235	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
266835100239	REAR AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
266835100250	REAR AXLE BEAM ASSY BS6	TATA spare parts
266835100252	REAR AXLE BEAM ASSY	TATA spare parts
266835100256	REAR AXLE BEAM ASSY WITH STUD & DOWEL BS	TATA spare parts
266835100264	AXLE BEAM ASSY WITH RING & STUD BS6-PH2	TATA spare parts
266835105101	SPRING SADDLE BOTTOM (BIGGER U BOLT)	TATA spare parts
266835105107	SPRING SADDLE TOP (AS PRESSED)	TATA spare parts
266835105109	SPRING SADDLE (BOTTOM)	TATA spare parts
266835105111	BRACKET (S-CAM CAST `Z` BKT)	TATA spare parts
266835105112	SPRING SADDLE (BOTTOM)	TATA spare parts
266835106301	SPACER (BETWEEN BRACKET & SLACK ADJ.)	TATA spare parts
266835108601	PRESSURE RING	TATA spare parts
266835108801	STUD	TATA spare parts
266835110101	ASSY.CARRIER 41/6 (GLEASON)	TATA spare parts
266835110102	ASSY.CARRIER-37/7 ORLKN-HN2	TATA spare parts
266835110103	ASSY.CARRER COMP. 41/6 OERLIKON	TATA spare parts
266835110111	ASSY.CARRIER (37/7 ORLKN-SPIRAC),130C.F	TATA spare parts
266835110130	ASY CARRIER 41/7 OER-SPIRAC FOR RA-108RR	TATA spare parts
266835110158	CARRIER & PINION HOUSING ASSY BS6	TATA spare parts
266835110160	CARRIER ASSY	TATA spare parts

266835110176	CARRIER ASSY BS6-PH2	TATA spare parts
266835150102	PRESSURE RELIEF VALVE	TATA spare parts
266835300103	ASSY.CROWN & PINION GLEASON(41/6)	TATA spare parts
266835300106	DIFF. ASSLY COMP (37/7) OERLIKON	TATA spare parts
266835300107	CWP SET 37/7 OERL LP/LPO 1512TC	TATA spare parts
266835300116	CWP SET 45/7 ORELKON SPIRAC	TATA spare parts
266835300127	ASSY.C.WHEEL/PINION (41/7 ORLKN-SPIRAC)	TATA spare parts
266835300130	ASSY. CROWN & PINION (37/7) OER BS2/3/4	TATA spare parts
266835300137	ASSY. CROWN WHEEL PINION-41/7-GLEASON	TATA spare parts
266835300139	DIFF HSG ASSY D/LOCK	TATA spare parts
266835300148	CWP SET 41/7 OERL	TATA spare parts
266835300158	ASSY. CROWN & PINION 41/7 OER-SPIRAC BS4	TATA spare parts
266835300159	CWP SET HD 41/7 OERL	TATA spare parts
266835300164	CWP SET HD 41/6 OERL	TATA spare parts
266835300184	DIFFERENTIAL GEAR KIT W/SPIDER 1210/1510	TATA spare parts
266835300185	DIFFERENTIAL GEAR KIT W/SPIDER	TATA spare parts
266835300197	RA 108 RR DIFFERENTIAL REP KIT	TATA spare parts
266835300198	ASSY CROWN WHEEL & PINION GLEASON (41/6)	TATA spare parts
266835300233	CROWN WHEEL & PINION ASSY	TATA spare parts
266835300255	CROWN WHEEL & PINION ASSY BS6-PH2	TATA spare parts
266835303101	CYL.ROLLER BRG	TATA spare parts
266835303102	CYL.ROLLER BRG	TATA spare parts
266835303104	CYL.ROLLER BRG	TATA spare parts
266835303105	TAPER ROLLER BEARING	TATA spare parts
266835303108	CYL.ROLLER BRG (35X80X23)	TATA spare parts
266835303109	TAPER ROLLER BRG (60X135X33 5)	TATA spare parts
266835303111	CYL ROLLER BRG (35X80X23) BS6-PH2	TATA spare parts
266835303113	CYLINDRICAL ROLLER BEARING BS6	TATA spare parts
266835303115	TAPER ROLLER BEARING BS6	TATA spare parts
266835305402	PINION - CWP:41/6-0103GL	TATA spare parts
266835305403	PINION (37/7) OERLIKON	TATA spare parts
266835305414	PINION 41/7 ORLKN-SPIRAC	TATA spare parts
266835305417	PINION - CWP 41/7-0137GL BS2/3	TATA spare parts
266835305419	PINION - CWP:41/7-0148OR	TATA spare parts
266835305419AE	PINION 41/7 715	TATA spare parts
266835305421	PINION - CWP:41/7-0159OR	TATA spare parts
266835305423	PINION (41/7),OERLIKON-SPRIAC.HEAVY DUTY	TATA spare parts
266835305427	PINION - CWP:41/6-0164OR	TATA spare parts
266835305439	AXLE SHAFT GEAR-9X16-FORGED BS1/2/3/4	TATA spare parts
266835305440	DIFF. BEVEL PINION 9X16 FORGED BS1/2/3/4	TATA spare parts
266835305440AE	DIFF.BEVEL PNIN (9X16) -1628	TATA spare parts
266835305441	REAR AXLE SHAFT GEAR (9X16)	TATA spare parts
266835305442	DIFF BEVEL PINION(9X16)	TATA spare parts
266835305445	AXLE SHAFT GEAR (9X16)	TATA spare parts
266835305446	DIFF.BEVEL PINION (9X16)	TATA spare parts
266835305452	BEVEL GEAR	TATA spare parts
26683530546520	PINION 45/7 (SPIRAC-SPIRON) BS6-PH2	TATA spare parts

266835306501	THREADED RING	TATA spare parts
266835307701	OIL SEAL DOUBLE LIP	TATA spare parts
266835307702	OIL SEAL DOUBLE LIP	TATA spare parts
266835307703	OIL SEAL TAIL PINION 1512TC	TATA spare parts
266835307707	OIL SEAL DOUBLE LIP	TATA spare parts
266835307708	OIL SEAL DOUBLE LIP	TATA spare parts
266835307710	OIL SEAL (68X90X13)DOUBLE LIP	TATA spare parts
266835307711	OIL SEAL (68X90X13)	TATA spare parts
266835308201	OIL SLINGER (TAIL PINION)	TATA spare parts
266835308201AE	OIL SLINGER (TAIL PINION) 715	TATA spare parts
266835308601	SPACER (BET.PINION BRG.& COUP.FLANGE)	TATA spare parts
266835600105	ASSY.HUB COVER (BIGGER HUB)	TATA spare parts
266835600106	ASSY.REAR HUB COMP.W/BRG & POLE WHEEL	TATA spare parts
266835600108	ASSY.REAR HUB COMP.	TATA spare parts
266835600109	ASSY. REAR HUB (W/O BRG & SEAL) BS1/2/3/	TATA spare parts
266835600111	HUB ASSY BS6-PH2	TATA spare parts
266835603101	TAPER ROLLER BRG. INNER 683/72 BS1/2/3/4	TATA spare parts
266835603102	TAPER ROLLER BRG. OUTER 32217 BS1/2/3/4	TATA spare parts
266835603103	TAPER BRG	TATA spare parts
266835603104	TAPER BRG	TATA spare parts
266835603105	TAPER BRG	TATA spare parts
266835603106	TAPER BRG	TATA spare parts
266835603107	TAPER ROLLER BEARING	TATA spare parts
266835603109	TAPER ROLLER BRG.(95X145X39)	TATA spare parts
266835603110	TAPER ROLLER BRG.(70X125X33.25)	TATA spare parts
266835603111	BEARING BS6-PH2	TATA spare parts
266835604701	COVER REAR HUB	TATA spare parts
266835605301	GASKET REAR HUB BS1/2/3/4	TATA spare parts
266835605504	HUB REAR (275 PCD 8 BOLT)	TATA spare parts
266835606501	LOCK NUT	TATA spare parts
266835606502	LOCK NUT (RA-108RR HUB)	TATA spare parts
266835607701	OIL SEAL (REAR INNER) BS1/3/4/6	TATA spare parts
266835607701AE	OIL SEAL (INNER-CASING) -2523	TATA spare parts
266835607701DF	OIL SEAL - REAR INNER - METAL CASING	TATA spare parts
266835607702	OIL SEAL REAR OUTER 2515 BS3/4	TATA spare parts
266835607702AE	OIL SEAL (OUTER-CASING) -2523	TATA spare parts
266835607702DF	OIL SEAL - REAR OUTER - METAL CASING	TATA spare parts
266835607703	OIL SEAL DOUBLE LIP BS1/2/3/4	TATA spare parts
266835607705	OIL SEAL (HUB OUTER) BS1/2/3/4	TATA spare parts
266835607706	OIL SEAL (HUB OUTER)	TATA spare parts
266835607707	OIL SEAL (120X146X15) INNER BS6	TATA spare parts
266835607708	OIL SEAL OUTER (110X128X9)	TATA spare parts
266835608001	PIN-HUB LOCK NUT	TATA spare parts
266835608002	PIN (HUB LOCK NUT-RA-108RR)	TATA spare parts
266835608201	OIL CATCHER-REAR HUB	TATA spare parts
266835608302	SHIM-0.10 THK	TATA spare parts
266835608303	SHIM-0.15 THK.	TATA spare parts

266835608304	SHIM-0.20 THK	TATA spare parts
266835608305	SHIM-0.25 THK.	TATA spare parts
266835608306	SHIM-0.30 THK	TATA spare parts
266835608307	SHIM-0.5 THK.	TATA spare parts
266835608308	SHIM-1.0 THK	TATA spare parts
266835608309	SHIM-1.5 THK.	TATA spare parts
266835608310	SHIM -0.7 THK	TATA spare parts
266835608311	SHIM -0.8 THK	TATA spare parts
266835608312	SHIM -0.9 THK	TATA spare parts
266835608313	SHIM -1.1 THK.	TATA spare parts
266835608314	SHIM -1.2 THK	TATA spare parts
266835608315	SHIM -1.3 THK	TATA spare parts
266835608316	SHIM -1.4 THK	TATA spare parts
266835608317	SHIM	TATA spare parts
266835608318	SHIM	TATA spare parts
266835608319	SHIM	TATA spare parts
266835608320	SHIM	TATA spare parts
266835608321	SHIM	TATA spare parts
266835608322	SHIM	TATA spare parts
266835608323	SHIM	TATA spare parts
266835608324	SHIM	TATA spare parts
266835608325	SHIM	TATA spare parts
266835608326	SHIM	TATA spare parts
266835608601	SPACER RING-HUB OUTER SEAL	TATA spare parts
266835608602	SPACER	TATA spare parts
266835608603	SPACER TUBE BETWEEN HUB BRGS	TATA spare parts
266835608604	TONGUE SPACER-HUB OUTER BEARING	TATA spare parts
266835608605	SPACER (TOUNGE-HUB OUTER BRG) BS4	TATA spare parts
266835608606	SPACER TUBE	TATA spare parts
266835608608	SPACER RING BS6-PH2	TATA spare parts
266835608609	TONGUE SPACER BS6-PH2	TATA spare parts
266835707901	REAR AXLE SHAFT BS1/2/3/4	TATA spare parts
266835707901DF	REAR AXLE SHAFT - RA109RR	TATA spare parts
266835707902	REAR AXLE SHAFT	TATA spare parts
266835707903	AXLE SHAFT D/LOCK	TATA spare parts
266835707904	REAR AXLE SHAFT BS6-PH2	TATA spare parts
266835905401	ENGAGING SLEEVE DIFF LOCK-GLEASON.	TATA spare parts
2668H9W0135002	LIVE REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
2668H9W0135010	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
266935000103	ASSY.R A 109 WITH BRK 41/7-SPIG.HUB 1615	TATA spare parts
266935300109	ASSY CW & PINION (48/7=6.857)OER-SPIRAC	TATA spare parts
266935303101	TAPER ROLLER BRG. 32020 BS1/2/3/4	TATA spare parts
266935305403	PINION - CWP:48/7-0109OR	TATA spare parts
267033508301	SHIM ADJ	TATA spare parts
26710548	WORM WHEEL BIG	TATA spare parts
267131307111	GUSSET BOTTOM LH	TATA spare parts
2672	SOLENOID SWITCH 24V	TATA spare parts

267272303401	DOOR HINGE BUSH	TATA spare parts
267355100102	MASCOT ASSY	TATA spare parts
267355100105	MASCOT ASSY BS6	TATA spare parts
267355100107	MASCOT ASSY BS6	TATA spare parts
267355100109	MASCOT ASSY BS6	TATA spare parts
267355100110	MASCOT ASSY BS6	TATA spare parts
267355100111	MASCOT ASSY BS6	TATA spare parts
267355100112	MASCOT ASSY BS6	TATA spare parts
267355100113	MASCOT ASSY BS6	TATA spare parts
267355100114	MASCOT ASSY BS6	TATA spare parts
267355100122	MASCOT ASSY BS6-PH2	TATA spare parts
267355100123	MASCOT ASSY BS6-PH2	TATA spare parts
267355100127	MASCOT ASSY BS6	TATA spare parts
267355100128	MASCOT ASSY BS6	TATA spare parts
267355100136	MASCOT ASSY BS6-PH2	TATA spare parts
267360000106	ASSY COWL COMPLETE.LHD	TATA spare parts
267360000109	ASSY BARE CAB 407 LPT CMVR NON S CAM	TATA spare parts
267360000123	ASSY COWL COMPLETE RHD 6CYL R/POWER STG	TATA spare parts
267360000131	ASSY. BODY SHELL PAINTED RHD LPT407	TATA spare parts
267360000145	BARE CAB LPT709 S CAM	TATA spare parts
267360000146	ASSY. BODY SHELL PAINTED-LHD	TATA spare parts
267360000148	ASSY. BODY SHELL PAINTED LPT613-LHD SCAM	TATA spare parts
267360000149	CAB COMP LPT709 S CAM	TATA spare parts
267360000150	ASSY. CAB COMPLETE LPT709 LHD(SCAM	TATA spare parts
267360000152	ASSY. CAB COMPLETE LPT613 LHD( S CAM)	TATA spare parts
267360000161	BARE COWL 709 S CAM	TATA spare parts
267360000164	ASSY.COWL SHELL PAINTED SCAM 613LP LHD	TATA spare parts
267360000165	ASSY COWL LP 709 S CAM W/PARTIAL FITMENT	TATA spare parts
267360000168	ASSY.COWL COMPL LP613 PS LHD S-CAM	TATA spare parts
267360100102	ASSY.CROSS MEMBER-RHD D.B.MTG(S-CAM 613)	TATA spare parts
267360100103	ASSY. CROSS MEMBER-RHD(D.B.MTG.)	TATA spare parts
267360100105	ASSY.INNER PANEL & FIREWALL-RHD(S-CAM)	TATA spare parts
267360100106	ASSY SUPPORTING FRT GRILL	TATA spare parts
267361608201	PANEL SIDE LH	TATA spare parts
267361608202	PANEL SIDE RH	TATA spare parts
267361608206	REINFORCEMENT SIDE LH ENGINE CUT-OUT	TATA spare parts
267361608208	PANEL CENTRE -613 COWL	TATA spare parts
267361608210	REINFORCEMENT TOP [MIDDLE FLOOR] 613COWL	TATA spare parts
267361608220	REINFORCEMENT SIDE-RH ENGINE CUTOUT	TATA spare parts
267368700102	KIT-INSULATION	TATA spare parts
267368700107	KIT-INSULATION BS6-PH2	TATA spare parts
267368706301	INSULATION BS6-PH2	TATA spare parts
267368706302	INSULATION BS6-PH2	TATA spare parts
267368706321	INSULATION BS6-PH2	TATA spare parts
267368706322	INSULATION BS6-PH2	TATA spare parts
267368706333	INSULATION BS6-PH2	TATA spare parts
267368706334	INSULATION BS6-PH2	TATA spare parts

267368706335	INSULATION BS6-PH2	TATA spare parts
267368706336	INSULATION BS6-PH2	TATA spare parts
267368706339	INSULATION BS6-PH2	TATA spare parts
267368706340	INSULATION BS6-PH2	TATA spare parts
267368706341	INSULATION	TATA spare parts
267368706360	INSULATION BS6-PH2	TATA spare parts
267368900101	ASSY. DASH BOARD COMP. RHD S CAM BS2	TATA spare parts
267368900102	ASSY. DASH BOARD COMPLETE-LHD(S CAM)	TATA spare parts
267368906301	INSTRUMENT PANEL SCAM LHD	TATA spare parts
267369106301	INSULATION FRONT - 6 CYL	TATA spare parts
267369106304	INSULATION SIDE	TATA spare parts
267375100101	ASSY.CENTRE FLAP BS1/2/3/4	TATA spare parts
267375108201	PANEL CENTER FLAP OUTER BS6-PH2	TATA spare parts
26737510Z101	ASSY. CENTRE FLAP BS2	TATA spare parts
267381100105	LID RHD 613 COWL	TATA spare parts
267381100106	ASSY LID LHD-613 COWL	TATA spare parts
267381105301	INSULATION-LID RHD	TATA spare parts
267381105302	INSULATION LID-LHD [613 COWL]	TATA spare parts
267381105303	PACKING-LID [613 COWL]	TATA spare parts
267381106301	LID SEALING-613 COWL	TATA spare parts
267381906302	MASCOT 613	TATA spare parts
267383100107	ASSY HOSE VENTILATION	TATA spare parts
267388100101	HOOK ASSY BS6-PH2	TATA spare parts
267388106301	FRONT FENDER LH BS6	TATA spare parts
267388106302	FRONT FENDER RH BS6	TATA spare parts
267388106304	ADD ON FRONT FENDER LH BS6-PH2	TATA spare parts
267388106305	ADD ON FRONT FENDER RH BS6-PH2	TATA spare parts
267388106306	FRONT FENDER LH BS6-PH2	TATA spare parts
267388106307	FRONT FENDER RH BS6-PH2	TATA spare parts
267388106308	ADD ON FRONT FENDER LH BS6-PH2	TATA spare parts
267388106309	ADD ON FRONT FENDER RH BS6-PH2	TATA spare parts
267388200101	PIPE ASSY BOTTOM MTG LH BS6	TATA spare parts
267388200102	PIPE ASSY BOTTOM MTG RH BS6	TATA spare parts
267388200105	PIPE ASSY BOTTOM MTG LH BS6-PH2	TATA spare parts
267388200106	PIPE ASSY BOTTOM MTG RH BS6-PH2	TATA spare parts
267388200107	MOUNTING BRACKET ASSY LH BS6-PH2	TATA spare parts
267388200108	MOUNTING BRACKET ASSY RH BS6-PH2	TATA spare parts
267388200110	BRACKET ASSY MUDGUARD MTG BS6-PH2	TATA spare parts
267388206303	MUDGUARD LH BS6	TATA spare parts
267388206304	MUDGUARD RH BS6	TATA spare parts
267388206305	ADD ON REAR FENDER LH BS6-PH2	TATA spare parts
267388206308	FRONT FENDER LH	TATA spare parts
267388206309	FRONT FENDER RH	TATA spare parts
267388206311	MUDGUARD LH BS6-PH2	TATA spare parts
267388206312	MUDGUARD RH BS6-PH2	TATA spare parts
267388206313	MUDFLAP SPRAY SUPPRESSION BS6-PH2	TATA spare parts
267388206315	MUDGUARD LH BS6-PH2	TATA spare parts

267388206316	MUDGUARD RH BS6-PH2	TATA spare parts
267388208201	SUPPORT MUDGUARD MTG LH BS6-PH2	TATA spare parts
267388208202	SUPPORT MUDGUARD MTG RH BS6-PH2	TATA spare parts
267388208203	SUPPORT MUDGUARD MTG LH BS6-PH2	TATA spare parts
267388208204	SUPPORT MUDGUARD MTG LH BS6-PH2	TATA spare parts
267389100101	ASSY CROSS TUBE T/BAR RHD	TATA spare parts
267389100102	ASSY.CROSS TUBE (TORSION BAR) LHD	TATA spare parts
267389100103	CROSS TUBE ASSY TORSION BAR BS6-PH2	TATA spare parts
267389100106	ASSY MTG BRKT RH CH.SIDE	TATA spare parts
267389100107	ASSY SUP BOT RH M/GUARD R	TATA spare parts
267389100110	CONNECTING LINK ASSY RH BS6-PH2	TATA spare parts
267389100111	BRACKET & STOPPER ASSY ADJUSTER BS6-PH2	TATA spare parts
267389100113	BRACKET ASSY BOTTOM-RH BS6-PH2	TATA spare parts
267389100114	BRACKET ASSY CAB MTG BOTTOM BS6-PH2	TATA spare parts
267389100115	CAB STAY ASSY BS6-PH2	TATA spare parts
267389100122	BRACKET ASSY CAB TILT CYLINDER MTG BTM B	TATA spare parts
267389100123	CAB STAY ASSY BS6-PH2	TATA spare parts
267389100124	STAY MOUNTING BRACKET ASSY BS6-PH2	TATA spare parts
267389100128	BRACKET ASSY BOTTOM-LH BS6-PH2	TATA spare parts
267389100129	BRACKET ASSY BOTTOM-RH BS6-PH2	TATA spare parts
267389100130	MOUNTING BRACKET ASSY REAR BS6-PH2	TATA spare parts
267389100132	FRONT MTG ASSY LH BS6-PH2	TATA spare parts
267389100133	FRONT MTG ASSY RH BS6-PH2	TATA spare parts
267389100134	RUBBER BUSH ASSY FRONT MTG BS6-PH2	TATA spare parts
267389100135	FRONT MTG ASSY RH	TATA spare parts
267389100136	SECONDARY HOOK ASSY LOCKING MCH BS6-PH2	TATA spare parts
267389100140	HANDLE MTG ASSY CAB LOCKING MCH BS6-PH2	TATA spare parts
267389100151	SUPPORT ASSY CAB MTG BKT FRONT-LH BS6-PH	TATA spare parts
267389100152	SUPPORT ASSY CAB MTG BKT FRONT-RH BS6-PH	TATA spare parts
267389100155	SUPPORT ASSY REAR MTG	TATA spare parts
267389100157	BRACKET ASSY CAB MTG FRONT-LH BS6-PH2	TATA spare parts
267389103311	BRACKET ASSY DAMPER MTG	TATA spare parts
267389103708	BRACKET CAB MTG REAR-LH	TATA spare parts
267389106301	MUDFLAP MIDDLE INNER LH	TATA spare parts
267389106302	MUDFLAP MIDDLE INNER RH	TATA spare parts
267389106303	SEALING MUDFLAP LH	TATA spare parts
267389106304	SEALING MUDFLAP RH	TATA spare parts
267389107135	PLATE CHASSIS SIDE BS6-PH2	TATA spare parts
267389107136	PLATE CHASSIS SIDE BS6-PH2	TATA spare parts
267389108203	PLATE CAB MTG BKT FRONT BS6	TATA spare parts
267389108601	SPACER BS6-PH2	TATA spare parts
267389300101	HOOK ASSY BS6	TATA spare parts
267389300102	CAB STAY ASSY BS6-PH2	TATA spare parts
2674010399R	CABIN REPAIR KIT -SFC BS6	TATA spare parts
2674010499R	CABIN CROSS CAR BEAM REPAIR KIT -SFC BS6	TATA spare parts
267455100101	MASCOT ASSY BS6	TATA spare parts
267455100102	MASCOT ASSY BS6	TATA spare parts

267455100103	MASCOT ASSY BS6	TATA spare parts
267455100104	407 MASCOT ASSY BS6	TATA spare parts
267455100105	MASCOT ASSY BS6	TATA spare parts
267455100114	MASCOT ASSY BS6	TATA spare parts
267460000110	BODY SHELL ASSY PAINTED	TATA spare parts
267460000111	CAB ASSY	TATA spare parts
267460000116	BODY SHELL ASSY PAINTED	TATA spare parts
267460000139	BODY SHELL ASSY PAINTED	TATA spare parts
267460100101	ASSY. COWL	TATA spare parts
267460100102	ASSY BARE CAB 709 SFC	TATA spare parts
267460100106	ASSY BARE COWL 709 SFC	TATA spare parts
267460100170	CAB BARE SFC 709 NON CMVR	TATA spare parts
267460100180	COWL BARE SFC 709 NON CMVR	TATA spare parts
267460100207	BRACKET ASSY SUNVIOSR MTG LH BS6-PH2	TATA spare parts
267460100208	BRACKET ASSY SUNVIOSR MTG RH BS6-PH2	TATA spare parts
267460100209	BRACKET ASSY SUNVISOR MTG BS6-PH2	TATA spare parts
267460108267	BRACKET LH	TATA spare parts
267460108268	BRACKET RH	TATA spare parts
267460108269	FRONT FENDER SUPPORT BKT LH BS6	TATA spare parts
267460108282	BIW NUMBER PLATE BS6	TATA spare parts
267460108284	GUSSET BS6	TATA spare parts
267460108285	FRONT FENDER SUPPORT BKT RH BS6	TATA spare parts
267460110101	ASSY CAB WITH PARTIAL FITMENTS 709 SFC	TATA spare parts
267460110102	ASSY COWL WITH PARTIAL FITMENTS 709 SFC	TATA spare parts
267460110103	CAB COMPLETE SFC 709 NON CMVR	TATA spare parts
267460110105	COWL COMPLETE SFC 709 NON CMVR	TATA spare parts
267460110116	CAB W/PARTIAL FIT. SFC709	TATA spare parts
267460110117	CAB BARE SFC 709 CMVR SCAM	TATA spare parts
26746011011720	ASSY 709 BODY SHELL COMP CED COATED (SCA	TATA spare parts
267460110121	ASSY COWL COMP. SFC709	TATA spare parts
267460110122	COWL BARE SFC 709 CMVR SCAM	TATA spare parts
26746011012220	ASSY 709 BODY COWL COMP CED COATED (SCAM	TATA spare parts
267460110131	CAB COMPLETE SFC 709 CMVR NON-SCAM	TATA spare parts
267460110132	CAB BARE SFC 709 CMVR NON-SCAM	TATA spare parts
26746011013220	ASSY 709 BODY SHELL COMP CED COATED (VAD	TATA spare parts
267460110136	COWL COMPLETE SFC 709 CMVR NON-SCAM	TATA spare parts
267460110137	COWL BARE SFC 709 CMVR NON-SCAM	TATA spare parts
26746011013720	ASSY 709 COWL SHELL COMP CED COATED (VAD	TATA spare parts
267460110156	ASSY.CAB COMPLETE-RHD SFC 709 EII SCAM	TATA spare parts
267460110157	ASSY BODY SHELL PAINTED R S709 EII SCAM	TATA spare parts
267460110186	ASSY.COWL SHELL COMPLETE PAINTED RHD	TATA spare parts
267460120111	CAB COMP.SFC 709 EX CMVR 2000	TATA spare parts
267460120134	ASSY.CAB COMPLETE-RHD EX BSII	TATA spare parts
267460120136	ASSY.COWL COMPLETE SFC709 EX BSII (TRUCK	TATA spare parts
267460120141	ASSY.CAB COMPLETE-RHD EX BS-III	TATA spare parts
267460120142	ASSY.BODY SHELL .PAINTED-RHDSFC712EX41W	TATA spare parts
267460120155	ASSY.PANEL FRONT COMPLETE	TATA spare parts



267460120157	ASSY. CAB COMP. W/O FITMENTS SFC712 BS3	TATA spare parts
267460120158	ASSY. CABIN BARE SFC 709EX BS2/3	TATA spare parts
267460120164	ASSY.COWL SHELL PAINTED-RHDSFC712EX/38W	TATA spare parts
267460120168	SFC 909 EX BS2 CAB COMPLETE	TATA spare parts
267460120169	ASSY.BODY SHELL COMPL PAINTED-RHSFC909	TATA spare parts
267460120179	ASSY.CAB COMPLETE RHD EX BS-II PTO	TATA spare parts
267460120180	ASSY.CAB COMPLETE-RHD EX BS-II PTO	TATA spare parts
267460120185	SFC709 CAB COMP-RHD EX BS-III PTO	TATA spare parts
267460120187	ASSY.CAB COMP WITH FITMENTS - RHD (WITH	TATA spare parts
267460120188	ASSY.BODY COMP.PAINTED-RHDSFC 407EMOS	TATA spare parts
267460120193	SFC 407 BS2 EX2	TATA spare parts
267460120194	ASSY.BODY SHELL COMP.PAINTED-RHD BS-II	TATA spare parts
267460130111	ASSY.COWL SHELL COMPLETE PAINTED RHD	TATA spare parts
267460130112	ASSY.COWL COMPLETE-RHD BS-III(BUS)	TATA spare parts
267460130117	ASSY BODY SHELL COMPLETE PAINTED-RHD	TATA spare parts
267460130118	ASSY CAB COMPLETE-RHD EX E-II H/D	TATA spare parts
267460130132	ASSY.CAB COMPLETE-LHD	TATA spare parts
267460130133	ASSY.BODY SHELL COMPLETE PAINTED-LHD	TATA spare parts
267460130138	ASSY.COWL COMPLETE LHD E-II	TATA spare parts
267460130139	ASSY.COWL SHELL COMPLETE PAINTED LHD	TATA spare parts
267460130156	ASSY.CAB COMPLETE-RHD EX BS-II PTO PS	TATA spare parts
267460130157	ASSY.BODY SHELL COMPLETE PAINTED-RHD	TATA spare parts
267460130161	ASSY.CAB COMPLETE-RHD	TATA spare parts
267460130162	ASSY.BODY SHELL COMPLETE PAINTED-RHD	TATA spare parts
267460130174	ASSY. CAB COMPLETE-RHD	TATA spare parts
267460130175	ASSY.BODY SHELL COMPLETE PAINTED-RHD	TATA spare parts
267460130186	SK 407 BS III CAB COMPLETE (FITTED)	TATA spare parts
267460130193	CAB COMPLETE RHD CNG BS-IV	TATA spare parts
267460130194	ASSY.BODY SHELL COMPLETE PAINTED RHD	TATA spare parts
267460130199	ASSY CAB COMPLETE RHD BS-III	TATA spare parts
267460140101	ASSY BODY SHELL COMP PAINTED RHD BS-III	TATA spare parts
267460140106	ASSY PANEL FRONT	TATA spare parts
267460140107	ASSY SUPPORT PLATE&BS6	TATA spare parts
267460140113	ASSY. BODY SHELL COMPLETE PAINTED-RHD BS	TATA spare parts
267460140113AWNB	BARE CAB-SFC407 ARTIC WHITE NB	TATA spare parts
267460140114	ASSY.CAB COMPLETE-RHD	TATA spare parts
267460140118	STRUCTURE ASSY WITH CED	TATA spare parts
267460140119	ASSY. CAB W/O FITMENTS RHD BS3	TATA spare parts
267460140120	ASSY. CABIN BARE SFC407EX RHD CLB BS3	TATA spare parts
267460140128	ASSY.STR.WELDED FOR SFC410 BS-III 31WB	TATA spare parts
267460140130	ASSY.STR.COMPLETE FOR SFC410 BS-III	TATA spare parts
267460140131	ASSY CAB COMPLETE RHD BS-III	TATA spare parts
267460140132	ASSY BODY SHELL COMP PAINTED RHD BS-III	TATA spare parts
267460140143	ASSY.CAB COMPLETE-RHD BS-III	TATA spare parts
267460140156	PARTIALLY FITTED CAB W/O ELECT&CONTROLS	TATA spare parts
267460140156ICNB	CAB PARTIALLY FITTED SFC407 IRISH CREAM	TATA spare parts
267460140157	ASSY. BODY SHELL COMPLETE PAINTED-RHD BS	TATA spare parts

267460140157AWBL	BARE CAB SFC 407 ARTIC WHITE BLW	TATA spare parts
267460140157AWNB	BARE CAB-SFC407 ARTIC WHITE NB	TATA spare parts
267460140157BRBL	BARE CAB-SFC407 BRICK RED BLW	TATA spare parts
267460140157ICBL	BARE CAB SFC 407 IRISH CREAM BLW	TATA spare parts
267460140157ICNB	BARE CAB-SFC407 IRISH CREAM NB	TATA spare parts
267460140157TWBL	BARE CAB-SFC407 TITANIUM WHITE BL	TATA spare parts
267460140162	PARTIALLY FITTED CAB W/O ELECT&CONTROLS	TATA spare parts
267460140162ICNB	CAB PARTIALLY FITTED SFC407 PTOP IC NB	TATA spare parts
267460140163	PARTIALLY FITTED CAB W/O ELECT&CONTROLS	TATA spare parts
267460140164	ASSY.BODY SHELL COMPLETE PAINTED-RHD	TATA spare parts
267460140174	ASSY. CAB. COMPLETE - RHD	TATA spare parts
267460140175	ASSY.CAB.COMPLETE-RHD	TATA spare parts
267460140176	ASSEMBLY CAB COMPLETED RHD	TATA spare parts
267460140177	ASSY.BODY SHELL COMPLETE PAINTED-RHD BS4	TATA spare parts
267460140177AWBL	BARE CAB-SFC407 PU ARTIC WHITE BL	TATA spare parts
267460140177AWNB	BARE CAB-SFC407 PU ARTIC WHITE NB	TATA spare parts
267460140177TWBL	BARE CAB-SFC407 PU TITANIUM WHITE BL	TATA spare parts
267460150159	ASSY. BODYSHELL PAINTED BS3/4	TATA spare parts
267460150159AWBL	BARE CAB-SFC/SK407 ARTIC WHITE BLW	TATA spare parts
267460150159BRBL	BARE CAB-SFC/SK407 BRICK RED BLW	TATA spare parts
267460150159ICBL	BARE CAB-SFC/SK407 IRISH CREAM BLW	TATA spare parts
267460150159ICNB	BARE CAB-SFC/SK407 IRISH CREAM NB	TATA spare parts
267460150159TWBL	BARE CAB-SFC/SK407 TITANIUM WHITE BL	TATA spare parts
267460150160	CAB ASSY	TATA spare parts
267460150178	BODY SHELL ASSY WITH PAINT	TATA spare parts
267460150178AWBL	BARE CAB SFC 407 ARTIC WHITE BLW	TATA spare parts
267460150178TWBL	BARE CAB-SFC407 PU TITANIUM WHITE BL	TATA spare parts
267460150190	BODY ASSY WITH ROOF	TATA spare parts
267460150193	ASSY. BODYSHELL PAINTED BS4	TATA spare parts
267460150193BRBL	BARE CAB-SFC709 BRICK RED BLW	TATA spare parts
267460150193GBBL	BARE CAB-SFC709 GOLDEN BROWN BLW	TATA spare parts
267460150193GBNB	BARE CAB-SFC709 GOLDEN BROWN NB	TATA spare parts
267460150194	PARTIALLY FITTED CAB W/O ELECT&CONTROLS	TATA spare parts
267460160101	BODY SHELL ASSY WITH PAINT BS6	TATA spare parts
267460160101AWBL	BARE CAB SFC 407 ARTIC WHITE BLW	TATA spare parts
267460160101TWBL	BARE CAB SFC 407 TITANIUM WHITE BLW	TATA spare parts
267460160109	DRIVER STATION ASSY WITH CED COATING (29	TATA spare parts
267460160115	"BODY SHELL ASSY,PAINTED BS6"	TATA spare parts
267460160115AWBL	BARE CAB SFC 710 ARTIC WHITE BLW BS6	TATA spare parts
267460160115BRBL	BARE CAB SFC 710 BRICK RED BLW BS6	TATA spare parts
267460160115TWBL	BARE CAB SFC 710 TITANIUM WHITE BLW BS6	TATA spare parts
267460160125	BODY SHELL ASSY WITH PAINT BS6	TATA spare parts
267460160125BRBL	BARE CAB-SFC/SK407 BRICK RED BLW BS6	TATA spare parts
267460160125TWBL	BARE CAB-SFC/SK407 TITANIUM WHITE BL BS6	TATA spare parts
267460160130	BODY SHELL ASSY PAINTED BS6	TATA spare parts
267460600115	ASSY PANEL INNER BONNET REAR LH-RHD	TATA spare parts
26746060011535	CED-ASSY.PANEL INNER BONNET REAR LH-RHD	TATA spare parts

267460600116	ASSY PANEL INNER BONNET REAR RH-RHD	TATA spare parts
26746060011635	CED-ASSY.PANEL INNER BONNET REAR RH-RHD	TATA spare parts
267460600117	ASSY.PANEL INNER BONNET REAR LH RHD	TATA spare parts
267460600118	ASSY.PANEL INNER BONNET REAR RH RHD	TATA spare parts
267460600119	ASSY.MUDGUARD COMP.L.H.R.H.D	TATA spare parts
267460600120	ASSY.MUDGUARD COMP.R.H. R.H.D.	TATA spare parts
267460600125	MUDGUARD ASSY WITH REINF & BRACKET RH BS	TATA spare parts
267461100114	NUT PLATE ASSY	TATA spare parts
267461108216	REINFORCEMENT BRACKET LH	TATA spare parts
267461108217	REINFORCEMENT BRACKET RH	TATA spare parts
267461108219	REINFORCEMENT BRACKET FOOT STEP MTG	TATA spare parts
267461600117	ASSY.STEP WELL COMPLETE LH	TATA spare parts
267461600118	ASSY.STEP WELL COMPLETE RH	TATA spare parts
267461600130	ASSY.BONNET PANEL INNER BS6	TATA spare parts
267461608207	PLATE BS6	TATA spare parts
267461608228	FLOOR PANEL CAB-RHD BS6	TATA spare parts
267461608241	FLOOR BS6	TATA spare parts
267462100112	SSY. X MEM.D/B COMP.WITH SIDE SUPP.RHD	TATA spare parts
267462100124	SUPPORT ASSYCROSS MEMBERRH BS6	TATA spare parts
267462100128	BRACKET ASSY CROSS MEMBER TO FIREWALL	TATA spare parts
267462103301	REINFORCEMENT BRACKET	TATA spare parts
267462208203	REINFORCEMENT FIREWALL TOP-LH	TATA spare parts
267462208204	REINFORCEMENT FIREWALL TOP-RH	TATA spare parts
267462500102	ASSY. REINFORCEMENT PLATE	TATA spare parts
267462608209	PANEL FIRE WALL-RHD	TATA spare parts
267462608218	PANEL FIRE WALL-RHD	TATA spare parts
267462608238	FIREWALL BS6	TATA spare parts
267462610106	REINFORCEMENT ASSY BS6	TATA spare parts
267462610107	NUT PLATE ASSY BS6	TATA spare parts
267462610114	BRACKET ASSY LH BS6	TATA spare parts
267464108201	REINFORCEMENT REAR WALL BOTTOM-LH	TATA spare parts
267464108202	REINFORCEMENT REAR WALL BOTTOM-RH	TATA spare parts
267464600102	ASSY.BKT.(GRAB HANDLE MTG.) BS6	TATA spare parts
267465708201	ROOF BS6	TATA spare parts
267466400105	ASSY. SEAT BOX (DRIVER'S SEAT)	TATA spare parts
267466600101	FOOT STEP ASSY BS6	TATA spare parts
267467106301	RUBBER MOULD W/S 6.78THK	TATA spare parts
267467106302	RUBBER MOULD WINDSHIELD GLASS	TATA spare parts
267468300101	ASSY.COVER	TATA spare parts
267468300102	ASSY.COVER(PTO)	TATA spare parts
267468400106	FLOOR MAT ASSY BS6	TATA spare parts
267468400114	FLOOR MAT ASSY LH BS6-PH2	TATA spare parts
267468400125	FLOOR MAT ASSY RH BS6-PH2	TATA spare parts
267468400131	FLOOR MAT	TATA spare parts
267468400138	ASSY.FLOOR MAT-RHD WITH PTO	TATA spare parts
267468400148	ASSY.FLOOR MAT RHD	TATA spare parts
267468400161	FLOOR MAT SET	TATA spare parts

267468406304	CARPET MIDDLE BS6	TATA spare parts
267468706301	INSULATION BS6	TATA spare parts
267468706302	INSULATION BS6	TATA spare parts
267468706305	INSULATION BS6	TATA spare parts
267468706306	INSULATION BS6	TATA spare parts
267468706309	INSULATION BS6	TATA spare parts
267468706310	INSULATION BS6	TATA spare parts
267468800103	ASSY.FLOOR MAT-RHD	TATA spare parts
267468806303	NOISE INSU.FIRE WALL (IN CAB)TOP LH-RHD	TATA spare parts
267468806304	NOISE INSU.FIRE WALL (IN CAB)TOP RH-RHD	TATA spare parts
267468806305	NOISE INSULATION FIREWALL	TATA spare parts
267468806307	PADDING POST SIDE LH RHD	TATA spare parts
267468806316	NOISE INSULATION FIREWALL BOTTOM-RH BS6	TATA spare parts
267468806322	NOISE INSULATION FIREWALL LH BS6	TATA spare parts
267468806323	NOISE INSULATION FIREWALL RH BS6	TATA spare parts
267468806324	NOISE INSULATION FIREWALL BOTTOM-LH BS6	TATA spare parts
267468806325	NOISE INSULATION FIREWALL BOTTOM-RH BS6	TATA spare parts
267468900104	BEZEL ASSY HVAC CONTROL	TATA spare parts
267468900111	ASSY.DASHBOARD COMPLETE.	TATA spare parts
267468900117	DASHBOARD ASSY	TATA spare parts
267468900127	DASHBOARD ASSY	TATA spare parts
267468900142	DASHBOARD ASSY	TATA spare parts
267468900144	DASHBOARD ASSY	TATA spare parts
267468900145	BEZEL ASSY HVAC CONTROL	TATA spare parts
267468900148	SWITCH BEZEL ASSY BS6	TATA spare parts
267468900150	DASHBOARD ASSY BS6	TATA spare parts
267468900152	DASHBOARD ASSY BS6	TATA spare parts
267468900161	NACELLE ASSY UPPER BS6-PH2	TATA spare parts
267468900162	DASHBOARD ASSY BS6-PH2	TATA spare parts
267468906301	INSTRUMENT PANEL RHD('S'CAM W/O IND.BAN	TATA spare parts
267468906303	UTILITY BOX DASHBOARD LOWER-CENTER	TATA spare parts
267468906308	DASH BOARD.(EX-II DIGITAL CLOCK)	TATA spare parts
267468906309	BAZEL DIGITAL CLOCK	TATA spare parts
267468906310	DASH BOARD LHD	TATA spare parts
267468906316	COVER CENTER DASHBOARD	TATA spare parts
267468906325	SPEAKER GRILL	TATA spare parts
267468906347	FOAM CROSS LINK BS6	TATA spare parts
267468906348	ELBOW DUCT LH	TATA spare parts
267468906349	INSTRUMENT SHROUD BS6	TATA spare parts
267468906353	INSTRUMENT SHROUD BS6	TATA spare parts
267468906354	BEZEL BS6	TATA spare parts
267468906355	NACELLE REAR BS6	TATA spare parts
267468906357	NACELLE FRONT BS6	TATA spare parts
267468906358	ELBOW DUCT RH BS6-PH2	TATA spare parts
267468906359	COVER DASHBOARD BOTTOM-LH BS6-PH2	TATA spare parts
267468906362	NACELLE LOWER BS6-PH2	TATA spare parts
267469500103	HANDLE UPPER BS6	TATA spare parts

267469506303	ROOF LINER BS6-PH2	TATA spare parts
267472300109	KIT FOR LOCKS RHD(CAB)1 DOOR	TATA spare parts
267472300118	SEALING ASSY INNER-LH BS6-PH2	TATA spare parts
267472300119	ASSY.SEALING INNER-RH BS6-PH2	TATA spare parts
267472300122	KIT-LOCK FOR CAB RHD(SANDHAR)BS6	TATA spare parts
267472300123	OUTER HANDLE ASSY W/O LOCK FR DOOR LH BS	TATA spare parts
267472300124	OUTER HANDLE ASSY WITH LOCK FR DOOR RH B	TATA spare parts
267472306304	TOP CORNER PIECE	TATA spare parts
267472306305	BOTTOM CORNER PIECE LH	TATA spare parts
267472306306	BOTTOM CORNER PIECE RH	TATA spare parts
267472306311	RUBBER PAD BS6	TATA spare parts
267472306312	RUBBER PAD BS6	TATA spare parts
267472500101	WINDOW REGULATOR LH	TATA spare parts
267472500102	WINDOW REGULATOR RH	TATA spare parts
267472500115	ASSY.WEATHER STRIP OUTER LH	TATA spare parts
267472500116	ASSY.WEATHER STRIP OUTER RH	TATA spare parts
267472500117	ASSY WEATHER STRIP VERTICAL	TATA spare parts
267472500118	ASSYWEATHER STRIP INNER	TATA spare parts
267472500138	TURNING WINDOW ASSY LH	TATA spare parts
267472500139	TURNING WINDOW ASSY RH	TATA spare parts
267472500140	TURNING WINDOW ASSY LH	TATA spare parts
267472500141	TURNING WINDOW ASSY RH	TATA spare parts
267472506301	RUBBER MOULD SEALING LH	TATA spare parts
267472506302	RUBBER MOULD SEALING RH	TATA spare parts
267472700103	PAD ASSY DOOR LH BS6-PH2	TATA spare parts
267472700104	PAD ASSY DOOR RH BS6-PH2	TATA spare parts
267472706302	PLASTIC DOOR MEMBRANE LH BS6	TATA spare parts
267472706303	PLASTIC DOOR MEMBRANE RH BS6	TATA spare parts
267472706304	MAGAZINE POCKET LH BS6-PH2	TATA spare parts
267472706305	MAGAZINE POCKET RH BS6-PH2	TATA spare parts
267472706307	GRAB HANDLE INNER FRONT DOOR LH BS6-PH2	TATA spare parts
267472706308	GRAB HANDLE INNER FRONT DOOR RH BS6-PH2	TATA spare parts
267472716307	DOOR MEMBRANE LH BS6-PH2	TATA spare parts
267472716308	DOOR MEMBRANE RH BS6-PH2	TATA spare parts
267481006301	LETTER T	TATA spare parts
267481006302	LETTER A	TATA spare parts
267481006303	LETTER T	TATA spare parts
267481006304	LETTER A	TATA spare parts
267481100115	ASSY TUBULAR FRAME (RVM) COWL	TATA spare parts
267481100116	ASSY.RVM COMPLETE RH	TATA spare parts
267481100117	ASSY.RVM COMPLETE LH	TATA spare parts
267481100123	ASSY.RVM COMPLETE RH	TATA spare parts
267481100124	ASSY.RVM COMPLETE LH	TATA spare parts
267481100128	KIT-ORVM FOR SFC-709HD/SFC COWLS	TATA spare parts
267481100129	KIT ORVM LH/RH SFC-709	TATA spare parts
267481100132	KIT ORVM LH/RH-712 N/D	TATA spare parts
267481100137	ASSY.SUPPORT VERTICLE(MUDFLAP)	TATA spare parts

267481100142	ASSY.BONNET INSULATION	TATA spare parts
267481100201	SUPPORT ASSY LH	TATA spare parts
267481100202	SUPPORT ASSY RH BS6	TATA spare parts
267481100203	SUPPORT ASSY RH	TATA spare parts
267481100207	SUNVISOR ASSY LH BS6-PH2	TATA spare parts
267481100208	SUNVISOR ASSY RH BS6-PH2	TATA spare parts
267481106301	EXTENSION FENDER-LH	TATA spare parts
267481106302	EXTENSION FENDER-RH	TATA spare parts
267481106303	MUDFLAP FRONT-LH(SPRAY SUPPRESSION)	TATA spare parts
267481106304	MUDFLAP FRONT-RH(SPRAY SUPPRESSION)	TATA spare parts
267481106305	MUDCOVER LH(SPRAY SUPPRESSION)	TATA spare parts
267481106306	MUDCOVER LH(SPRAY SUPPRESSION)	TATA spare parts
267481106307	GRAB HANDLE	TATA spare parts
267481106307C7	GRANIT_BLACK-GRAB HANDLE BS6	TATA spare parts
267481106311	RETRO-REFLECTIVE TAPE FRONT(WHITE)	TATA spare parts
267481106312	RETRO-REFLECTIVE TAPE FRONT SIDE(WHITE)	TATA spare parts
267481106313	RETRO-REFLECTIVE TAPE SIDE(YELLOW)	TATA spare parts
267481106314	RETRO-REFLECTIVE TAPE DOOR(YELLOW)	TATA spare parts
267481106315	RETRO-REFLECTIVE TAPE SIDE REAR(YELLOW)	TATA spare parts
267481107701	INSULATION BONNET CENTRE	TATA spare parts
267481506901	GRAB HANDLE LH	TATA spare parts
267481506902	GRAB HANDLE RH	TATA spare parts
267481506903	GRAB HANDLE BS6-PH2	TATA spare parts
267481506905	GRAB HANDLE BS6-PH2	TATA spare parts
267481800104	ASSY DECORATIVE DECAL LH	TATA spare parts
267481800105	ASSY DECORATIVE DECAL RH	TATA spare parts
267481800106	KIT-DECORATIVE DECAL DOOR & 407 PICK UP	TATA spare parts
267481800107	ASSY.DECAL-DOOR 407 PICK UP	TATA spare parts
267481800112	ASSY MASCOT BSIII	TATA spare parts
267481800120	KIT-DECORATIVE DECAL	TATA spare parts
267481800130	KIT-DECORATIVE DECAL	TATA spare parts
267481900107	ASSY MASCOT 407 EX BS-III	TATA spare parts
267481900108	ASSY MASCOT 709 EX BS-III	TATA spare parts
267481900109	ASSY MASCOT 909 EX BS-III	TATA spare parts
267481906301	FENDER EXTENSION LH	TATA spare parts
267481906302	FENDER EXTENSION RH	TATA spare parts
267481980101	KIT-FITMENT OF GRAB HANDLE BS6	TATA spare parts
267481980102	KIT-FITMENT OF GRAB HANDLE RH BS6	TATA spare parts
267483100102	ASSY.BLOWER RHD(24V)	TATA spare parts
267483100104	ASSY.VENTILATION DUCT(ENGINE HOUSE)LH	TATA spare parts
267483100105	ASSY.VENTILATION DUCT(ENGINE HOUSE)RH	TATA spare parts
267483106304	HOSE LH (LEG ROOM VENTILATION)	TATA spare parts
267483300106	CONTROL ASSY FORCED VENTILATION	TATA spare parts
267483400108	BLOWER UNIT ASSY	TATA spare parts
267483400112	FORCED VENTILATION UNIT ASSY BS6-PH2	TATA spare parts
267483407502	GROMMET HEATER CUTOUT	TATA spare parts
267483409903	RESISTOR ASSY	TATA spare parts

267483409906	WIRING HARNESS BLOWER	TATA spare parts
267483409933	BLOWER SCROLL ASSY	TATA spare parts
267483409950	WIRING HARNESS BLOWER BS6-PH2	TATA spare parts
267483409951	BLOWER ASSY BS6-PH2	TATA spare parts
267483750106	BRACKET ASSY	TATA spare parts
267483750107	BRACKET ASSY	TATA spare parts
267483750112	BRACKET ASSY	TATA spare parts
267483753309	BRACKET AC UNIT MTG	TATA spare parts
267484100101	BRACKET ASSY HEADBOX MTG LH BS6-PH2	TATA spare parts
267484100102	BRACKET ASSY HEADBOX MTG RH BS6-PH2	TATA spare parts
267484100103	BRACKET ASSY HEADBOX MTG CENTER-LH BS6-P	TATA spare parts
267484100104	BRACKET ASSY HEADBOX MTG CENTER-RH BS6-P	TATA spare parts
267484100107	HEADBOX ASSY LH BS6-PH2	TATA spare parts
267484100108	HEADBOX ASSY RH BS6-PH2	TATA spare parts
267484106305	CAP HEADBOX UPPER-LH BS6-PH2	TATA spare parts
267488100105	ASSY. BONNET SIDE LH BS3/4/6	TATA spare parts
267488100106	ASSY.BONNET SIDE RH	TATA spare parts
267488100109	ASSY. SIDE BONNET L.H. BS3/4/6	TATA spare parts
267488100110	ASSY.SIDE BONNET R.H.	TATA spare parts
267488108203	BONNET SIDE LH BS6-PH2	TATA spare parts
267488108204	BONNET SIDE RH BS6-PH2	TATA spare parts
267488108205	BONNET SIDE R.H.	TATA spare parts
267488108206	BONNET SIDE R.H.	TATA spare parts
267488500101	BUMPER ASSY RHD	TATA spare parts
267488500104	RUB COVER BUMPER LH END	TATA spare parts
267488500105	RUB COVER BUMPER RH END	TATA spare parts
267488500107	ASSY BUMPER COMP RHD	TATA spare parts
26748850010721	ASSY BUMPER COMP RHD (PAINTED IN HOUSE)	TATA spare parts
26748850010722	ASSY BUMPER COMP RHD (POWDER COATED)	TATA spare parts
26748850013021	ASSY.BUMPER COMP(S-407 EX-II)PAINTED	TATA spare parts
267488500134	ASSY.SUPPORT BUMPER MTG.LH(FOR FUPD)	TATA spare parts
267488500141	ASSY SUPPORT BUMPER MTG.RH FOR FUPD	TATA spare parts
267488500167	ASSY. BUMPER COMPLETE RHD POWDER COATED	TATA spare parts
267488500172	ASSY.BUMPER COMPLETE RHD POWDER COATED	TATA spare parts
267488500179	ASSY.BUMPER COMPLETE-RHD PAINTED.	TATA spare parts
267488500180	ASSY.BUMPER COMPLETE-RHD PAINTED EX-II	TATA spare parts
267488500181	ASSY.BUMPER COMPLETE-RHD PAINTED	TATA spare parts
267488506307	BUMPER GRILLE FRONT LH BS6-PH2	TATA spare parts
267488506308	BUMPER GRILLE FRONT RH BS6-PH2	TATA spare parts
267488506309	STEP BOARD BS6-PH2	TATA spare parts
267488508217	SUPPORT BUMPER MTG	TATA spare parts
267488510148	ASSY FOOT STEP BRACKET WITH SPACER PLATE	TATA spare parts
267488510150	ASSY FOOT STEP BRACKET-909	TATA spare parts
267488510172	ASSY.SUPPORT BUMPER MTG-LH	TATA spare parts
267488510173	ASSY.SUPPORT BUMPER MTG-RH	TATA spare parts
267488510178	ASSY SUPPORT BUMPER LH	TATA spare parts
267488510179	ASSY SUPPORT BUMPER RH	TATA spare parts

267488518203	ASSY END SUPPORT (BUMPER.)	TATA spare parts
267488520101	BUMPER SUPPORT ASSY LH BS6-PH2	TATA spare parts
267488520102	BUMPER SUPPORT ASSY RH BS6-PH2	TATA spare parts
267488520103	BRKT ASSY BUMPER SUPPORT MTG LH BS6-PH2	TATA spare parts
267488520104	BRKT ASSY BUMPER SUPPORT MTG RH BS6-PH2	TATA spare parts
267488700103	ENGINE HOOD SFC 609	TATA spare parts
267488700106	ASSY.ENGINE HOOD	TATA spare parts
267488700111	ASSY ENGINE HOOD	TATA spare parts
267488700113	ASSY.ENGINE HOOD-RHD	TATA spare parts
267488700120	ASSY ENGINE HOOD W/O H/D	TATA spare parts
267488700121	ASSY.TOGGLE CLAMP(ENGINE HOOD)	TATA spare parts
267488700122	ASSY.ENGINE HOOD WITH H/D FOR LHD	TATA spare parts
267488700126	ASSY.STAY TUBE LH-RHD	TATA spare parts
267488700127	ASSY.STAY TUBE RH-RHD	TATA spare parts
267488700139	ASSY.ENGINE HOOD-RHD	TATA spare parts
267488700147	BONNET RELEASE CABLE ASSY RH	TATA spare parts
267488700162	ENGINE HOOD ASSY BS6-PH2	TATA spare parts
267488700165	STAY TUBE ASSY RH BS6	TATA spare parts
267488707703	SEALING ENGINE HOOD-FLOOR SIDE	TATA spare parts
267488707704	SEALING ENGINE HOOD-FIREWALL SIDE	TATA spare parts
267488708213	BONNET CENTRE FRONT	TATA spare parts
267488800101	ASSY. GRILLE BS3/4/6	TATA spare parts
267488800103	ASSY.BAZZLE LH	TATA spare parts
267488800104	ASSY.BAZZLE RH	TATA spare parts
267488800106	ASSY. BUMPER FACELIFT BS3/4	TATA spare parts
267488806317	BEADING-BONNET CENTRE BS6	TATA spare parts
267489100101	ASSY BRKT FOR FRT CAB LH	TATA spare parts
267489100102	CAB MTG BKT FRT RH	TATA spare parts
267489100105	ASSY BRACKET CAB MOUNTING	TATA spare parts
267489100112	BRACKET ASSY CAB MTG FRONT-RH BS6	TATA spare parts
267489100114	ASSY MTG BKT REAR	TATA spare parts
267489100116	ASSY. BRACKET FOR FRONT CAB MTG. - LH	TATA spare parts
267489100117	ASSY. BRACKET FOR FRONT CAB MTG. - RH	TATA spare parts
267489106901	SPACER TUBE BS6-PH2	TATA spare parts
267491000127	ASSY DR SEAT WITH HEAD REST RHD MELBE VE	TATA spare parts
267491000133	ASSY.CO-DRIVER SEAT W/HEAD REST	TATA spare parts
267491000135	DRIVER SEAT ASSY	TATA spare parts
267491000144	DRIVER SEAT ASSY WITH HEADREST	TATA spare parts
267491000148	DRIVER SEAT ASSY W/O HEADREST	TATA spare parts
267491100105	RISER ASSY BS6-PH2	TATA spare parts
267491700101	ASSY.STAND DRIVER SEAT MTG.	TATA spare parts
267491700102	STAND ASSY DRIVER SEAT MTG	TATA spare parts
267494000107	ASSY.CO-DRIVER SEAT WITH HEAD REST-RHD	TATA spare parts
267494000117	CO-DRIVER SEAT ASSY WITH SINGLE HEADREST	TATA spare parts
267494000118	CO-DRIVER SEAT ASSY W/O HEADREST	TATA spare parts
267494000119	CO-DRIVER SEAT ASSY WITH DOUBLE HEADREST	TATA spare parts
267494000121	STATIC RAISER ASSY CO-DRIVER SEAT BS6-PH	TATA spare parts



267494000123	CO-DRIVER SEAT BS6-PH2	TATA spare parts
267494000127	CO-DRIVER SEAT ASSY BS6-PH2	TATA spare parts
267494000132	ASSY.CO-DR SEAT W/O HR W/GAP VINYL	TATA spare parts
267494000133	ASSY.CO-DR SEAT W/HR W/GAP MELBA	TATA spare parts
267497500109	KIT-SEAT BELT WITH ELR & LAP BELT FRONT	TATA spare parts
267497500123	SEAT BELT ASSY WITH ELR FRONT-LH BS6-PH2	TATA spare parts
267497500124	SEAT BELT ASSY WITH ELR FRONT-RH BS6-PH2	TATA spare parts
267497500125	LAP BELT ASSY MIDDLE BS6-PH2	TATA spare parts
267497500126	STEM BUCKLE ASSY FRONT BS6-PH2	TATA spare parts
267497500128	CABLE BUCKLE ASSY MIDDLE BS6-PH2	TATA spare parts
267497500129	WEBBING BUCKLE ASSY CO-DRIVER BS6-PH2	TATA spare parts
267861100111	LONGITUDINAL REAR RH	TATA spare parts
267861106360	GROMM BREATHERPIPE W/ARCH	TATA spare parts
267861200119	TAILGATE SILL	TATA spare parts
267861300122	REINF GEAR SHIFT LEV MTG	TATA spare parts
267861300133	ASSY. LONGITUDINAL LH	TATA spare parts
267861608801	OFFER DRG.FOR WELD STUD M06 X 20	TATA spare parts
267861800101	ASSY W/ARCH REAR INNER LH	TATA spare parts
267861800125	A. WHL LINER RR RH	TATA spare parts
267861806303	LINER REAR WHEEL ARCH LH	TATA spare parts
267862200104	BRACKET RADIATOR MTG RH	TATA spare parts
267862200117	MBR RAD MTG BOTT COMPLT	TATA spare parts
267862200134	MBR.RAD.SUPPORT TOP	TATA spare parts
267862200147	CROSS MBR BUMPER MTG	TATA spare parts
267862208213	DIAPHRAM PANEL PLENUM	TATA spare parts
267862208215	MBR SUSPN TOWER SUP FR LH	TATA spare parts
267862208216	MBR SUSPN TOWER SUP FR RH	TATA spare parts
267862600105	MBR FR CRASH LH STAGE 1	TATA spare parts
267862600113	PLENUM ASSY	TATA spare parts
267862600116	W/ARCH	TATA spare parts
267862600123	BKT DASH MTG SIDE LOWERLH	TATA spare parts
267862600128	ASSY. CRASH MEMBER RH	TATA spare parts
267863200101	HING REINF A PILLAR LH	TATA spare parts
267863200102	HINGE REINF.A PILLAR RH	TATA spare parts
267863200103	REINF. B PLR COMP LH	TATA spare parts
267863200127	REINF.DPILLAR TOP LH	TATA spare parts
267863200128	REINF.DPILLAR TOP RH	TATA spare parts
267863208201	REINF. A PLR TOP LH	TATA spare parts
267863208202	REINF. A PLR TOP RH	TATA spare parts
267863208207	SIDE SILL REINF. FRONT LH	TATA spare parts
267863208208	SIDE SILL REINF. FRONT RH	TATA spare parts
267863208239	SIDE SILL REINF REAR LH	TATA spare parts
267863208240	SIDE SILL REINF REAR RH	TATA spare parts
267863600103	PANEL B PILLAR INNER LH	TATA spare parts
267863600104	PANEL B PLR INNER RH	TATA spare parts
267863608207	REAR QUARTER INNER LH.	TATA spare parts
267863700103	LID FUEL FILLER HOUSING	TATA spare parts

267863700104	ASSY. FUEL FILLER HOUSING	TATA spare parts
267863700106	D PILLAR OUTER RH	TATA spare parts
267863708201	PANEL BODY SIDE OUTER LH	TATA spare parts
267863708207	DRIP CHANNEL FRONT LH.	TATA spare parts
267865200101	ASSY. ROOF BOW FRONT	TATA spare parts
267867102307	W/S GLASS TNT WITH SHEDBAND NEW	TATA spare parts
267867106308	W/S MOULD	TATA spare parts
267868406361	FOAM PIECE	TATA spare parts
267868900130	STR WHL STD	TATA spare parts
267868900131	STEERING WHEEL LUXURY	TATA spare parts
267868906310	BEZEL INST CLUSTER REAR	TATA spare parts
267868906321	HINGE PIN GLOVE BOX LID.	TATA spare parts
267868906323	STEERING NECELLE BOTTOM	TATA spare parts
267868906330	L FLOOR CONSOLE HSG FRT	TATA spare parts
267868906331	FLOOR CONSOLE HSG RR-L	TATA spare parts
267868906333	COVER FRONT CONSOLE	TATA spare parts
267868906334	COVER HANDBRAKE LEVER-L	TATA spare parts
267868906341	HANDBRAKE TRIM GRIP LUX	TATA spare parts
267868906349	COVER (CENTRAL CLUSTER)	TATA spare parts
267868907703	RUBBER SLEEVE BEZEL	TATA spare parts
267868916334	CONSOLE FRT.(SILVER ARISTO PAINT)	TATA spare parts
267869100105	KIT CARPET STD	TATA spare parts
267869100111	PARCEL SHELF LUXURY	TATA spare parts
267869106301	A PILLAR TRIM UPPER LH	TATA spare parts
267869106302	A PILLAR TRIM UPPER RH	TATA spare parts
267869106303	B PILLAR TRIM UPR LH	TATA spare parts
267869106304	B PILLAR TRIM UPR RH	TATA spare parts
267869106305	'B' PILLAR TRIM LOWER LH LUX.	TATA spare parts
267869106306	B PILLAR TRIM LWR RH	TATA spare parts
267869106309	REAR QUARTER TRIM LH	TATA spare parts
267869106310	REAR QUARTER TRIM RH	TATA spare parts
267869106311	REAR QUART TRIM INNER LH	TATA spare parts
267869106322	FLAP FOR OUTLET VALVE	TATA spare parts
267869106325	SCUFF PLATE FRONT DOOR RH	TATA spare parts
267869106339	PLUG BUTTON G001-(DIA.8 B PILLAR)	TATA spare parts
267869106341	TREE CLIP HEAD LIN	TATA spare parts
267869500101	ASSY GRAB HANDLE (COLLAPSIBLE)	TATA spare parts
267869500102	ASSY GRAB HANDLE (COLLAPSIBLE)	TATA spare parts
267869506302	PLASTICBUTTON GRAB HANDLE	TATA spare parts
267869506303	PLASTICBUTTON HEAD LINING	TATA spare parts
267869506304	HEAD LINING RHD	TATA spare parts
267869506305	TREE CLIP (MICROSIGN)	TATA spare parts
267869506311	GRAB HANDLE	TATA spare parts
267869806302	ROOF BEADING RH MOULD	TATA spare parts
267872200101	FRT DOOR SHELL LH	TATA spare parts
267872200105	INTRU BEAMTUBE FRT DR LH	TATA spare parts
267872200106	INTRU BEAMTUBE FRT DR RH	TATA spare parts

267872300101	UPPER HINGE BODY SIDE LH	TATA spare parts
267872300113	ASSY DOOR STRIKER	TATA spare parts
267872300114	HANDLE WINDOW WINDING	TATA spare parts
267872300114A3	HANDLE ASSY WINDOW WINDING	TATA spare parts
267872300114C7	GRANIT_BLACK-ASSY HANDLE [WINDOW WINDIN	TATA spare parts
267872300116	DOOR HANDLE OUTER RH	TATA spare parts
267872300117	ASSY DOOR STRIKER	TATA spare parts
267872300118	FRONT DOOR LATCH LH	TATA spare parts
267872300120	ASSY HANDLE [WINDOW WINDING]	TATA spare parts
267872300121	ASSY.UPPER HINGE DOOR SIDE LH	TATA spare parts
267872300122	ASSY.UPPER HINGE DOOR SIDE RH	TATA spare parts
267872300123	LOWER HINGE BODY SIDE LH	TATA spare parts
267872300124	LOWER HINGE BODY SIDE RH	TATA spare parts
267872300142	ASSY.CHECK STRAP (FRONT DOOR)	TATA spare parts
267872300146	L/STD KIT LOCK SET	TATA spare parts
267872300151	ASSEMBLY STRIKER	TATA spare parts
267872300164	ASSY DOOR STRIKER	TATA spare parts
267872300180	ASSY. INNER HANDLE FRT DR LUX RH	TATA spare parts
267872300195	ASSY.DOOR HANDLE OUTER LH	TATA spare parts
267872300196	ASSY.DOOR HANDLE OUTER RH	TATA spare parts
267872303201	SPECIAL BOLT HINGE FIX	TATA spare parts
267872305003	LOWER HINGE DOOR SIDE LH	TATA spare parts
267872305004	LOW HINGE D. SIDE RH	TATA spare parts
267872306307	RETAINER FLOWER	TATA spare parts
267872306310	SNAP CONNECTOR	TATA spare parts
267872306311	PLASTIC CAP DOOR STRIKER	TATA spare parts
267872306701	HINGE PIN	TATA spare parts
267872306703	CHECK STRAP PIN	TATA spare parts
267872500103	ASSY REAR GLASS SUPPORT FRT DR LH	TATA spare parts
267872500104	RR GLASS SUPP FRT DR RH	TATA spare parts
267872500115	W/W UNIT POWER FRT DR LH	TATA spare parts
267872500116	W/W UNIT POWER FRT DR RH	TATA spare parts
267872500117	W/ WINDER MANUAL FR DR LH	TATA spare parts
267872500119	WINDOW REGULATOR FR DR LH	TATA spare parts
267872500130	DRIP BEADING SIDE DOOR RH	TATA spare parts
267872500131	GLASS WITH SUPPORT LH	TATA spare parts
267872500132	GLASS WITH SUPPORT RH	TATA spare parts
267872500133	WINDING GLASS CLEAR LH	TATA spare parts
267872500134	WINDING GLASS CLEAR RH	TATA spare parts
267872500135	ASSY DUST SEAL FRT DR LH	TATA spare parts
267872500139	DUST SEAL FRT DR LH	TATA spare parts
267872500140	DUST SEAR FRT RH	TATA spare parts
267872500181	ASSY.W/W REGUL.UNIT LH(MOD.SLIDER)	TATA spare parts
267872500182	ASSY.W/W REGUL.UNIT RH(MOD.SLIDER)	TATA spare parts
267872500183	ASSY. PWR W/W UNIT LH	TATA spare parts
267872506303	INNER BELT FRONT LH MOULD	TATA spare parts
267872506305	OUTER BELT FRONT LH MOULD	TATA spare parts

267872506306	OUTER BELT FRONT RH MOULD	TATA spare parts
267872506307	PRIMARY SEAL FRT DOOR LH	TATA spare parts
267872506308	PRIMARY SEAL FRT DOOR RH	TATA spare parts
267872506321	PRIMARY SEAL FRT DR LH	TATA spare parts
267872506329	OUTER BELT FRT DR LH	TATA spare parts
267872506330	OUTER BELT FRT DR RH	TATA spare parts
267872506335	GLASS RUN FRT LH MLDP)	TATA spare parts
267872506336	GLASS RUN FRT RH MLDP)	TATA spare parts
267872508003	SPECIAL SCR.PAN HD M6X16 (SUNDRAM FAST)	TATA spare parts
267872700107	DOOR PULL LH	TATA spare parts
267872700108	DOOR PULL RH	TATA spare parts
267872700110	A TRIM FRT DR STD RH EURO I	TATA spare parts
267872700111	A TRIM FRT DR LH LUX EURO I	TATA spare parts
267872700120	SPEAKER GRILL LH MPFI	TATA spare parts
267872700121	SPEAKER GRILL RH MPFI	TATA spare parts
267872700132	TRIM FRT DR LH LXI MPFI	TATA spare parts
267872700133	TRIM FRT DR RH LXI MPFI	TATA spare parts
267872704301	CLIP FOR SPEAKER GRILL FRONT DOOR	TATA spare parts
267872706301	MAGAZINE POCKET FRTRDLH-L	TATA spare parts
267872706302	MAGAZINE POCKET FRTRDRRH	TATA spare parts
267872706303	SPEAKER GRILL LH	TATA spare parts
267872706307	HOUSING INNER HANDLE	TATA spare parts
267872706319	PLASTIC MEMB FRT DR LH	TATA spare parts
267873300113	RR DR LATCH LH (STD)	TATA spare parts
267873300114	RR DR LATCH RH (STD)	TATA spare parts
267873300121	ASSY.CHECK STRAP (REAR DOOR)	TATA spare parts
267873300147	ASSY REAR DOOR LATCH LH STD	TATA spare parts
267873300148	ASSY REAR DOOR LATCH RH STD	TATA spare parts
267873500105	CHANNEL DIVISION RRDR LH	TATA spare parts
267873500106	CHANNEL DIVISION RRDR RH	TATA spare parts
267873500116	W/W UNIT POWER RR DR RH	TATA spare parts
267873500129	GLASS WITH SUPPORT LH	TATA spare parts
267873500130	GLASS WITH SUPPORT RH	TATA spare parts
267873500136	DUST SEAL RR DR LH	TATA spare parts
267873500146	ASSY.W/W REGUL.UNIT LH(MOD.SLIDER)	TATA spare parts
267873500148	ASSY. PWR W/W UNIT LH	TATA spare parts
267873500149	ASSY. PWR W/W UNIT RH	TATA spare parts
267873502308	FIXED GLASS RR DR RH TINT	TATA spare parts
267873502314	WINDING GLASS REAR DOOR-TINTED RH	TATA spare parts
267873503401	BUSH DIVISION CHLN RRDR	TATA spare parts
267873506301	GLASS RUN REAR MOULD LH	TATA spare parts
267873506302	GLASS RUN REAR MOULD RH	TATA spare parts
267873506305	OUTER BELT REAR LH MOULD	TATA spare parts
267873506308	RRDR FIXED GLASS MOULD RH	TATA spare parts
267873506312	PRIMARY SEAL REAR DOOR RH	TATA spare parts
267873506338	GLASS RUN RR LH MLD	TATA spare parts
267873506339	GLASS RUN RR RH MLD	TATA spare parts

267873506348	DR SEAL RR LH	TATA spare parts
267873700104	ASH TRAY REAR DOOR	TATA spare parts
267873700109	A TRIM RR DR STD LH	TATA spare parts
267873700112	TRIM RR DR RH STD EURO I	TATA spare parts
267874200117	TAIL GATE SHELL WIPER	TATA spare parts
267874200127	TAILGATE SHELL(WIPER BKT.&SPOILER HOLES)	TATA spare parts
267874300105	T/GATE STOPPER MOBILE LH	TATA spare parts
267874300106	ASSY.TAIL GATE STOPPER MOBILE RH.	TATA spare parts
267874300108	TAILGATE HINGE	TATA spare parts
267874300141	ASSY TAIL GATE STOPPER BODY SIDE LH	TATA spare parts
267874300142	ASSY.TAIL GATE STOPPER BODY SIDE RH	TATA spare parts
267874300144	STRIKER TAILGATE LATCH	TATA spare parts
267874300146	TAIL GATE LATCH	TATA spare parts
267874300153	TAILGATE BALANCER	TATA spare parts
267874303401	BUSH-T/G HINGE	TATA spare parts
267874500101	TINTED BAKELITE GLASS	TATA spare parts
267874500102	BAKELITE GLASS GREEN DEFO	TATA spare parts
267874500103	BAKELITE GLASS CLEAR	TATA spare parts
267874506302	TAILGATE GLASS MOULD NLS	TATA spare parts
267874506304	END BEAD TAILGATE GLASS	TATA spare parts
267874506306	PIN GLASS LOCATION	TATA spare parts
267874700106	TAILGATE TRIM	TATA spare parts
267874706331	REAR WIPER MOTOR COVER	TATA spare parts
267881100123	ASSY.LATCH FUEL LID	TATA spare parts
267881100126	ASSY. REAR VIEW MIRROR -	TATA spare parts
267881100127	ASSLY RVM ANTIGLARE	TATA spare parts
267881100141	TAILGATE CABLE DIESEL+PET	TATA spare parts
267881100142	SUNVISOR LH	TATA spare parts
267881100160	ASSY LATCH FUEL LID	TATA spare parts
267881100181	KEY BLANK	TATA spare parts
267881100182	ASSY.ORVM WITH ADJUSTER LH-LHD	TATA spare parts
267881100183	ASSY.ORVM WITH ADJUSTER RH-LHD	TATA spare parts
267881100190	HEAT SHIELD BKT	TATA spare parts
267881100193	ASSY.TAILGATE LATCH CABEL LHD	TATA spare parts
267881100195	ASSY.MIRROR(RIGHT)WITH BACK PLATE	TATA spare parts
267881106301	HINGE CLIP SUNVISOR	TATA spare parts
267881106304	COVER INSPECTN FUEL TANK	TATA spare parts
267881106305	REFLEX REFLECTOR-FRONT DOOR	TATA spare parts
267881106306	REFLEX REFLECTOR RR DR	TATA spare parts
267881106319	COVER TAILGATE SILL	TATA spare parts
267881106323	EXTENSION PIECE ORVM LH	TATA spare parts
267881106324	EXTENSION PIECE ORVM RH -	TATA spare parts
267881106329	TAPE REAR BUMPER LH	TATA spare parts
267881106333	FUEL LID STOP	TATA spare parts
267881106337	MASCOT TATA	TATA spare parts
267881106338	MASCOT INDICA	TATA spare parts
267881106345	T EMBLEM TAILGATE	TATA spare parts

267881106351	3M TAPE (30X30)	TATA spare parts
267881106352	SURFF PLATE IN LH	TATA spare parts
267881106353	SURFF PLATE IN RH	TATA spare parts
267881106366	SIDE MOULDING LH (FRONT DOOR)	TATA spare parts
267881106367	SIDE MOULDING RH (FRONT DOOR)	TATA spare parts
267881106368	SIDE MOULDING LH (REAR DOOR)	TATA spare parts
267881106369	SIDE MOULDING RH (REAR DOOR)	TATA spare parts
267881106379	MASCOT LXI	TATA spare parts
267881106383	MASCOT INDICA LSI-MPFI	TATA spare parts
267881108202	HEAT SHIELD BKT	TATA spare parts
267881116325	TURBO MASCOT	TATA spare parts
267883100116	BLOWER COMPLT W/ RIS	TATA spare parts
267883100126	RECEIVER DRIER-V.AIG	TATA spare parts
267883100133	COND.SHROUD WITH FAN	TATA spare parts
267883100172	ASSY.HOSE SUCTION	TATA spare parts
267883106319	KNOB BLOWER CONTROL	TATA spare parts
267883106322	DRAIN HOSE (V.AIG)	TATA spare parts
267883106323	GROMMET-DRAIN HOSE V.AIG	TATA spare parts
267883106330	COOLING FAN SUB	TATA spare parts
267883106345	KNOB - (BLOWER CONTROL)-	TATA spare parts
267883106349	KNOB-MODE CONTROL	TATA spare parts
267883108203	L BRACKET (FOR BLWR UNIT TO EVAP.UNIT)	TATA spare parts
267883108303	CLAMP HOSE DISCHARGE-V.AI	TATA spare parts
267883110120	BACKPLATE CONTROLS HVAC	TATA spare parts
267883110123	FACIA CONTROLS HVAC	TATA spare parts
267883110128	ASSY.RECEIVER DRIER BOTTLE	TATA spare parts
267883110188	ASSY.BLOWER CASE (EVAPORATOR SIDE)	TATA spare parts
267883110189	ASSY.BLOWER CASE (RESISTOR SIDE)	TATA spare parts
267883116301	DRAIN HOSE WITH GROMMET	TATA spare parts
267883120152	ASSY EVAP HOUSING UPPER RHD	TATA spare parts
267883120175	ASSY. HOSE SUCTION MODIFIED	TATA spare parts
267883120176	HOSE DISCHARGE 130CC FLAT BKT	TATA spare parts
267883130168	ASSY.CONDENSER FAN WITH SHROUD	TATA spare parts
267883400120	ASSY BLOWER MOTOR	TATA spare parts
267883400125	ASSY EVAPORATOR HOUSING LOWER RHD	TATA spare parts
267888100103	PANEL FRONT FENDER LH	TATA spare parts
267888100104	PANEL FRONT FENDER RH	TATA spare parts
267888100106	A LINER FRT WHL HSG RH	TATA spare parts
267888500116	MOULDING FRT BUMPER	TATA spare parts
267888506311	MUD FLAP FRONT LH	TATA spare parts
267888506313	MUD FLAP REAR LH	TATA spare parts
267888506314	MUD FLAP REAR RH	TATA spare parts
267888506316	SPLASH GUARD FRONT BUMPER	TATA spare parts
267888506320	BONNET SEAL	TATA spare parts
267888508601	SPACER SPECIAL SCREW	TATA spare parts
267888606303A8	REAR BUMPER W/O PAINT	TATA spare parts
267888700104	REINF HOOD LATCH MTG	TATA spare parts

267888700105	REINF.HOOD HINGE MTG LH	TATA spare parts
267888700106	REINF.HOOD HINGE MTG RH	TATA spare parts
267888700108	ASSY.HOOD HINGE RH.	TATA spare parts
267888700109	ASSY LEVER HOOD RELEASE	TATA spare parts
267888700110	A.LEVER HOOD REALIR	TATA spare parts
267888706001	STAY ROD HOOD	TATA spare parts
267888706301	STAY ROD BEARING BRACKET	TATA spare parts
267888706302	CLIP-STAY ROD LOCK.	TATA spare parts
267888706303	CLIP STAY ROD CLAMP	TATA spare parts
267888706311	HOOD INSULATION	TATA spare parts
267888706314	CLIP HOOD INSULATION	TATA spare parts
267888706328	STOPPER FOR HOOD BUMPER	TATA spare parts
267891300101	HEADREST SLEEVE ASSY.	TATA spare parts
267891300102	HEAD RESTRAINT	TATA spare parts
267891909901	SIDE VALANCE OUT BOARD RH	TATA spare parts
267891909902	SIDE VALANCE LH	TATA spare parts
267891909903	RECLINER COVER OUTBOARD CO-DRIVER	TATA spare parts
267891909904	RECLINER COVER INBOARD DRIVER SEAT	TATA spare parts
267891909905	HANDWHEEL RECLINER MECHAN	TATA spare parts
267891909915	RECLINER COVER O/B LH	TATA spare parts
267891909916	RECLINER COVER I/B LH	TATA spare parts
267891909917	RECLINER HANDLE CAP	TATA spare parts
267891909927	RECLINER O/B LH	TATA spare parts
267891909928	RECLINER O/B RH	TATA spare parts
267892300105	LATCH REAR SEAT BACK LH	TATA spare parts
267892300106	LATCH REAR SEAT BACK RH	TATA spare parts
267899000102	KNOB SPARE WHEEL	TATA spare parts
267899006304	FOAM CVR MBR FRT CRASHBTM	TATA spare parts
267899006501	SPECIAL NUT (7/16IN)	TATA spare parts
267899006502	SQ.RIVET NUT.	TATA spare parts
267899006509	WELD STUD M6X16	TATA spare parts
267899006510	WELD STUD M6X25 BS6	TATA spare parts
267899006522	CAGE NUT	TATA spare parts
267899006523	MSA DIA.3.5 SCREW SPRING (J-SPIRE BIG)	TATA spare parts
267899006524	MSA DIA.4.2 SCREW SPRING (J-SPIRE SMALL)	TATA spare parts
267899006536	WELD STUD M8 X 20	TATA spare parts
267899500101	ASSY.PLASTIC RIVET (VIPUL).	TATA spare parts
267899500102	ASSY.CLIP (PUSH & TURN)	TATA spare parts
267899504301	CLIP-F	TATA spare parts
267899506301	DOOR TRIM CLIP	TATA spare parts
267899506304	CLIPS FOR BOWDEN & ELECT.CABLE	TATA spare parts
267899506305	TREE CLIP	TATA spare parts
267899506306	PIPING CLIP NLS (6328)	TATA spare parts
267899506308	TREE CLIP	TATA spare parts
267899506312	FENDER PROT NLS CLIP	TATA spare parts
267899506316	X TREE CLIP	TATA spare parts
267899506317	X TREE CLIP(NIFCO-3S64)BLACK	TATA spare parts

267899506327	CLIP-DOOR TRIM	TATA spare parts
267899506328	PIPING CLIP-FRONT DOOR	TATA spare parts
267899506329	PIPING CLIP (REAR DOOR)	TATA spare parts
267899506330	TREE CLIP (CAB INSULATION) [JAIHIND].	TATA spare parts
267899506335	TREE CLIP(SEAT BELT ANCHORAGE) [VIPUL].	TATA spare parts
267899506336	FENDER PROTECTION CLIP(DOOR PULL)	TATA spare parts
267899506340	X TREE CLIP	TATA spare parts
267899506342	X TREE CLIP BLACK	TATA spare parts
267899506343	INSULATION CLIP	TATA spare parts
267899706301	SCREW GROMMET 2-2	TATA spare parts
267899706302	SCREW GROMMET	TATA spare parts
267899706304	SCREW GROMMET	TATA spare parts
267899706309	PLASTIC RIVET NLS	TATA spare parts
267899706329	RUBR GRMT (MBR T/G SILL)	TATA spare parts
267899706336	SCREW GROMMET (REAR WIPER MOTOR COVER)	TATA spare parts
267899706341	SCREW GROMMET M4	TATA spare parts
267899706341_niu01	SCREW GROMMET M4	TATA spare parts
267899706342	SCREW GROMMET	TATA spare parts
267899706343	SCREW GROMMET	TATA spare parts
267899706345	HOLE PLUG DIA.16	TATA spare parts
267899706351	HOLE PLUG FOR DIA.20.	TATA spare parts
267899706353	HOLE PLUG 13.3 DIA.(FOR DR.SWITCH HOLE)	TATA spare parts
267899706354	HOLE PLUG FOR DIA.30 (G-001) [VIPUL]	TATA spare parts
267955100103	MASCOT ASSY	TATA spare parts
267955100104	MASCOT ASSY	TATA spare parts
267955100107	MASCOT ASSY	TATA spare parts
267955100109	MASCOT ASSY	TATA spare parts
267955100110	MASCOT ASSY	TATA spare parts
267955100114	MASCOT ASSY	TATA spare parts
267955100118	MASCOT ASSY	TATA spare parts
267955100119	MASCOT ASSY BS6	TATA spare parts
267955100120	MASCOT ASSY	TATA spare parts
267955100121	MASCOT ASSY BS6	TATA spare parts
267955100123	MASCOT ASSY BS6	TATA spare parts
267955100124	MASCOT ASSY BS6	TATA spare parts
267955100134	MASCOT ASSY BS6	TATA spare parts
267955100135	MASCOT ASSY BS6-PH2	TATA spare parts
267960000101	BODY SHELL ASSY PAINTED BS6	TATA spare parts
267960100105	ASSY BODY SHELL PAINTED RHD	TATA spare parts
267960100107	ASSY BARE CAB LPK 2516TC-NON SLEEPER	TATA spare parts
267960100108	LPK2516TC 6X4 NS CAB-LHD PAINTED	TATA spare parts
267960100111	ASSY BARE CAB LPK 2516TC 6X4	TATA spare parts
267960100133	ASSY.CAB COMPLT.RHD 2516 NON-SLEEPER	TATA spare parts
267960100136	ASSY CAB COMPLETE LPK 2516TC 6X4	TATA spare parts
267960100136A	LPK 2516 RHD CAB 24V COMPLETE .	TATA spare parts
267960100138	ASSY CAB COMP RHD FOR LPK 2516 TC	TATA spare parts
267960100139	ASSY BARE CAB LPK 2516TC-NON SLEEPER	TATA spare parts



267960100147	LPK 2516TC LHD N/S CAB COMPLETE	TATA spare parts
267960100154	LPK 2516TC NS CAB PAINTED-LHD	TATA spare parts
267960100164	ASSY BODY SHELL PAINTED-RHD	TATA spare parts
267960100170	ASSY CAB COMPLETE-RHD LPK 2518	TATA spare parts
267960100170SJ	ASSY CAB COMP-RHD LPK 2518 SPARE PARTS	TATA spare parts
267960100171	ASSY CAB COMPLETE-RHD	TATA spare parts
267960100171SJ	ASSY. CAB COMP. RHD LPK2516? NSLPR BS2	TATA spare parts
267960100184	ASSY CAB COMPLETE - RHD	TATA spare parts
267960100184SJ	ASSY. CAB COMP. LPK 2518 NSLPR BS3	TATA spare parts
267960100185	ASSY. CABIN BARE NSLPR RHD BS1/2/3	TATA spare parts
267960100191	ASSY CAB COMPLETE LHD	TATA spare parts
267960100192	ASSY BODY SHELL PAINTED LHD	TATA spare parts
267960110107	ASSY CAB COMPLETE RHD	TATA spare parts
267960110115	BODY SHELL COMPLETE LPK 1615 RHD EXPORT	TATA spare parts
267960110115SJ	ASSY. CAB COMP. LPK1615 NSLPR BS1/3	TATA spare parts
267960110117	ASSY CAB COMP LPK1618TC-36/BSIII 1516 FI	TATA spare parts
267960110117SJ	ASSY CAB COMPLETE RHD SPARE LPK 1618	TATA spare parts
267960110119	ASSEMBLY CAB COMPLETE	TATA spare parts
267960110119SJ	ASSY CAB COMPLETE LPK 1616 SPARE PARTS	TATA spare parts
267960110120	ASSEMBLY BODY SHELL PAINTED	TATA spare parts
267960110126	ASSY.COWL COMPLETE WITH FITMENTS-RHD	TATA spare parts
267960110126SJ	COWL COMPLETE WITH FITMENTS-RHDSPARE	TATA spare parts
267960110127	ASSY.COWL SHELL PAINTED-RHD	TATA spare parts
267960110133	ASSY BODY SHELL PAINTED LHD	TATA spare parts
267960110140	ASSY CAB COMPLETE RHD	TATA spare parts
267960110140SJ	ASSY. CAB COMPLETE RHD	TATA spare parts
267960110141SJ	CAB COMPLETE RHD LPK 2518	TATA spare parts
267960110143	ASSY. BODY SHELL PAINTED -RHD BS3/4	TATA spare parts
267960110149SJ	ASSY CAB COMPLETE RHD SPARE LPK 2518 RMC	TATA spare parts
267960110150	ASSY CAB COMPLETE - RHD	TATA spare parts
267960110150SJ	ASSY. CABIN KIT COMP LPK2518 NON R&C BS3	TATA spare parts
267960110151SJ	ASSY. CAB COMP. LPK2523 ERGO NON R&C BS3	TATA spare parts
267960110153SJ	ASSY. CAB COMP. LPK1618 ERGO NSLPR BS3	TATA spare parts
267960110154	ASSY CAB COMP WITH FITMENTS	TATA spare parts
267960110154SJ	ASSY. CAB COMP. LPK 3118 W/FITMENT BS3	TATA spare parts
267960110169SJ	ASSY COWL COMP WITH FITMENTS RHDSPARE	TATA spare parts
267960110170	ASSY COWL SHELL PAINTED	TATA spare parts
267960110179	ASSY CAB COMPLETE - RHD	TATA spare parts
267960110179SJ	ASSY CAB COMPLETE - RHD Spare	TATA spare parts
267960110180SJ	ASSY COWL COMP WITH FITMENTS RHD SPARE	TATA spare parts
267960110192	ASSY CAB COMPLETE - RHD	TATA spare parts
267960110192SJ	ASSY. CAB COMP. NSLPR R&C BS3	TATA spare parts
267960110193	ASSY. BODY SHELL PAINTED RHD BS3/4	TATA spare parts
267960120102	ASSY BODY SHELL PAINTED	TATA spare parts
267960120107	ASSY CAB COMPLETE - RHD	TATA spare parts
267960120107SJ	CAB COMPLETE - RHD SPARE	TATA spare parts
267960120115	ASSY. CAB W/O FITMENTS LPK 2518NSLPR BS4	TATA spare parts

267960120131	ASSY. BARE CABIN LPK NON SLPR BS4	TATA spare parts
267960120135	BODY SHELL ASSY PAINTED BS6	TATA spare parts
267960120135CJ5	ASSY CAB TRIMMED	TATA spare parts
267960120141	BODY SHELL ASSY PAINTED	TATA spare parts
267961000115	SUBSTRUCTURE ASSY BS6	TATA spare parts
267961000121	ASSY SUBSTRUCTURE -RHD	TATA spare parts
267961000125	ASSY.SUBSTRUCTURE-RHD	TATA spare parts
267961000133	ASSY SUBSTRUCTURE	TATA spare parts
267961000135	ASSY SUBSTRUCTURE	TATA spare parts
267961108204	GUSSET REAR MUDGUARD(AIR FILTER MTG.)	TATA spare parts
267961108215	GUSSET REAR MUDGUARD-LH	TATA spare parts
267961600101	ASSY. FLOOR PANEL LH RHD	TATA spare parts
267961600102	ASSY.FLOOR PANEL RH-RHD	TATA spare parts
267961600107	ASSY.MUDGUARD-RH(REAR)	TATA spare parts
267961600110	ASSY.FLOOR PANEL-CENTRE BS6	TATA spare parts
267961600111	ASSY FLOOR PANEL LH RHD	TATA spare parts
267961600114	MUDGUARD ASSY REAR-LH BS6	TATA spare parts
267961600115	MUDGUARD ASSY REAR-RH BS6	TATA spare parts
267961600116	ASSY FLOOR PANEL LH RHD	TATA spare parts
267961600117	ASSY.FLOOR PANEL RH	TATA spare parts
267961600120	MUDGUARD EXTENSION REAR-LH BS6	TATA spare parts
267961600121	ASSY MUDGURD LH REAR	TATA spare parts
267961600122	ASSY.MUDGUARD-RH(REAR)	TATA spare parts
267961600123	ASSY MUDGURD LH REAR	TATA spare parts
267961600124	MUDGUARD ASSY REAR-RH	TATA spare parts
267961608207	FLOOR PANEL CENTRE	TATA spare parts
267961608216	FLOOR PANEL LH BS6-PH2	TATA spare parts
267961608217	FLOOR PANEL RH BS6-PH2	TATA spare parts
267961608223	REINFORCEMENT MUDGUARD REAR-LH	TATA spare parts
267961608224	REINFORCEMENT MUDGUARD REAR-RH	TATA spare parts
267961608234	REINFORCEMENT MUDGUARD REAR BS6	TATA spare parts
267962200119	ASSY BKT FUSE BOX MOUNTING REAR BS6	TATA spare parts
267962600116	PILLAR FILLER ASSY TOP HINGE TOP-LH BS6	TATA spare parts
267962600117	PILLAR FILLER ASSY TOP HINGE TOP-RH BS6	TATA spare parts
267964700101	BRACKET ASSY FIRE EXTINGUISHER MTG BS6	TATA spare parts
267964700111	ASSY REAR WALL WELDED(WITHOUT LOUVERS)	TATA spare parts
267964700116	REAR WALL ASSY BS6	TATA spare parts
267964700118	CORNER PANEL ASSY OUTER-LH	TATA spare parts
267964700120	REAR WALL ASSY WELDED(WITHOUT LOUVERS)	TATA spare parts
267964700132	CORNER PANEL ASSY WITH POST OUTER-RH BS6	TATA spare parts
267964700135	CORNER PANEL ASSY OUTER-LH BS6	TATA spare parts
267965200108	TOP RAIL ASSY REAR	TATA spare parts
267965208207	REAR WALL MTG BRKT LH BS6	TATA spare parts
267965208209	REAR WALL CORNER MTG BRKT LH BS6	TATA spare parts
267965208211	BRACKET BS6-PH2	TATA spare parts
267965700108	ROOF ASSY WITH TOP RAIL	TATA spare parts
267965700109	ASSY REINFORCEMENT ROOF BS6	TATA spare parts

267965708203	PANEL ROOF NON-SLEEPER CAB BS6	TATA spare parts
267968400101	ASSY.FLOOR MAT RHD	TATA spare parts
267968400102	ASSY.FLOOR MAT-RHD	TATA spare parts
267968400105	ASSY COMPOSITE FLOOR MAT RHD	TATA spare parts
267968400106	ASSY COMPOSITE FLOOR MAT LHD	TATA spare parts
267968400107	ASSY COMPOSITE FLOOR MAT RHD	TATA spare parts
267968400108	ASSY COMPOSITE FLOOR MAT RHD	TATA spare parts
267968406301	CARPET FLOOR LH	TATA spare parts
267968406302	CARPET FLOOR RH	TATA spare parts
267969100102	ASSY REAR WALL TRIM	TATA spare parts
267969106305	REAR WALL LINING TOP	TATA spare parts
267969106306	REAR WALL LINING BOTTOM	TATA spare parts
267969400101	REAR WALL TRIM ASSY BS6-PH2	TATA spare parts
267969400102	REAR WALL TRIM ASSY BS6	TATA spare parts
267969506301	MOULDED ROOF(HEADLINER)NON SLP	TATA spare parts
267969506302	MOULDED ROOF LINING NON SLPR CAB	TATA spare parts
267969506305	MOULDED ROOF LINING BS6	TATA spare parts
267969506306	MOULDED ROOF LINING BS6-PH2	TATA spare parts
267972300101	ASSY.NUT PLATE BS6	TATA spare parts
267972300102	ASSY.DOVE TAIL-BOTTOM(DOOR SIDE)	TATA spare parts
267972306303	DOVE TAIL-BOTTOM(FLOOR SIDE)	TATA spare parts
267972308203	SPACER(DOVE TAIL TOP)	TATA spare parts
267972706301	COVER (CORNER PANEL INNER)	TATA spare parts
267981100101	BRACKET ASSY BS6	TATA spare parts
267981100104	AIR DEFLECTOR BS6	TATA spare parts
267981106311	REFLECTIVE TAPE SIDE BS6-PH2	TATA spare parts
267981800103	HEAT SHIELD ASSY BS6	TATA spare parts
267981800104	ASSY TATA 1618 C MASCOT	TATA spare parts
267981800105	ASSY.TATA 2518 C 6X4 MASCOT	TATA spare parts
267981800107	ASSY MASCOT TATA 2523C	TATA spare parts
267981800109	MASCOT ASSY	TATA spare parts
267981800110	MASCOT TATA 1615 C	TATA spare parts
267981800111	HEAT SHIELD ASSY BS6	TATA spare parts
267981800113	HEAT SHIELD ASSY BS6 PH2	TATA spare parts
267981900109	ASSY ENGINE SHIELDING LH RHD	TATA spare parts
267981900110	ASSY ENGINE SHIELDING RH RHD	TATA spare parts
267981900115	ASSY ENGINE SHIELDING RH-LHD	TATA spare parts
267981900116	ASSY ENGINE SHIELDING LH-LHD	TATA spare parts
267981900120	ENGINE SHIELDING ASSY LH	TATA spare parts
267981900121	ENGINE SHIELDING ASSY RH	TATA spare parts
267981900126	ENGINE SHIELDING ASSY RH BS6	TATA spare parts
267981900127	ENGINE SHIELDING ASSY LH BS6	TATA spare parts
267981900128	ENGINE SHIELDING ASSY RH BS6	TATA spare parts
267981900129	AIR DEFLECTOR BS6	TATA spare parts
267981900134	ENGINE SHIELDING ASSY LH BS6	TATA spare parts
267981900135	ENGINE SHIELDING ASSY RH BS6	TATA spare parts
267981900136	ENGINE SHIELDING ASSY RH BS6	TATA spare parts

267988100101	ASSY BASE PLATE (HINGE TYPE STEP) BS6	TATA spare parts
267988100102	ASSY HINGE TYPE STEP	TATA spare parts
267988100103	ASSY FOOT STEP MTG FRAME FENDER PLATE LH	TATA spare parts
267988100104	ASSY FOOT STEP MTG FRAME FENDER PLATE RH	TATA spare parts
267988200101	ASSY BODY SIDE ADD ON LH(NON SLPR)	TATA spare parts
267988200102	ASSY BODY SIDE ADD ON RH(NON SLPR)	TATA spare parts
267988300101	BRACKET ASSY BS6	TATA spare parts
267988300102	FOOT STEP ASSY LOWER-LH BS6	TATA spare parts
267988300103	FOOT STEP ASSY LOWER-RH BS6	TATA spare parts
267988500101	ASSY.BUMPER COMPLETE	TATA spare parts
267988500101B0	BUMPER PAINTED BLACK	TATA spare parts
267988500101C0	ASSY BUMPER WITH REFLECTOR - BLACK	TATA spare parts
267988500101C1	ASSY BUMPER WITH REFLECTOR -RUBY RED	TATA spare parts
267988500103	ASSY BRKT NUMBER PLATE MTG	TATA spare parts
267988500104	ASSY BRACKET BUMPER MTG-FRONT WELDED LH	TATA spare parts
267988500105	ASSY BRACKET BUMPER MTG-FRONT WELDED RH	TATA spare parts
267988500106	ASSY OUTRIGGER CHASSIS SIDE WELDED LH BS	TATA spare parts
267988500107	ASSY OUTRIGGER CHASSIS SIDE WELDED RH BS	TATA spare parts
267988500110	ASSY FOOT STEP (BUMPER FOR LPK)	TATA spare parts
267988503301	BRKT REFLEX REFLECTOR MTG LH (LPK)	TATA spare parts
267988503304	BRKT REFLEX REFLETOR MTG RH (LPK)	TATA spare parts
267988508601	SPACER BS6	TATA spare parts
267988700101	ASSY.ENGINE HOOD COMPLETE-LHD	TATA spare parts
267988707701	SEAL ENGINE HOOD	TATA spare parts
267989100101	BRACKET REAR CAB & S/ABSORBER MTG LH LPK	TATA spare parts
267989100102	BRACKET REAR CAB & S/ABSORBER MTG RH LPK	TATA spare parts
267989100110	ASSY BRACKET REAR LH	TATA spare parts
267989100111	ASSY BRACKET REAR RH	TATA spare parts
267989100113	ASSY. SPRING CAB MTG. REAR BS1/2/3	TATA spare parts
267989100114	ASSY BRACKET REAR LH (CAB MTG & S/ABSORB	TATA spare parts
267989100115	ASSY BRACKET REAR RH(CAB MTG & S/ABSORBE	TATA spare parts
267989100118	ASSY BRKT REAR LH (CAB MTG.& SHOCK AB.)	TATA spare parts
267989100119	ASSY BRKT REAR RH (CAB MTG.& SHOCK AB.)	TATA spare parts
267989100120	ASSY BRKT REAR LH (CAB & SHOCK ABSORBER)	TATA spare parts
267989100121	ASSY BRKT REAR RH (CAB & SHOCK ABSORBER)	TATA spare parts
267989100122	ASSY FRONT MTG BKT LH RHD	TATA spare parts
267989103201	`U' BOLT (REAR CENTER MTG.)	TATA spare parts
267989108601	PACKING PIECE FOR `U' BOLT	TATA spare parts
267989200102	LATERAL SHOCK ABSORBER BS3/4/6	TATA spare parts
267989200103	ASSY. REAR STRUT BS3/4	TATA spare parts
267989200107	REAR STRUT ASSY	TATA spare parts
267989200108	ASSY. BRACKET CAB MTG REAR-LH BS1/2/3	TATA spare parts
267989200109	ASSY BRKT REAR RH(CAB MTG)	TATA spare parts
267989200110	ASSY BRKT REAR (CAB MTG)	TATA spare parts
267989200111	ASSY BRKT REAR RH (CAB MTG)	TATA spare parts
267989200123	ASSY. MTG.BRKT.REAR LH BS3/4	TATA spare parts
267989200124	ASSY. MTG.BRKT.REAR RH BS3/4	TATA spare parts

267989200125	MOUNTING BRACKET ASSY REAR-LH	TATA spare parts
267989200126	MOUNTING BRACKET ASSY REAR-RH	TATA spare parts
267989206701	PIN LATERAL (SHOCK ABSORBER) BS3/4/6	TATA spare parts
267989208206	HEX FLANGE NUT M10	TATA spare parts
267989208207	HEX FLANGE NUT M12	TATA spare parts
267991000103	DRIVER SEAT ASSY	TATA spare parts
268035108301	SHIM ADJ	TATA spare parts
268054829901	GEAR & SLIP RING ASSY BS6-PH2	TATA spare parts
268055100101	ASSY. MASCOT (SIGNA) BS3/4/6	TATA spare parts
268055100102	MASCOT ASSY LETTER - TATA	TATA spare parts
268055100106	MASCOT ASSY	TATA spare parts
268055100109	MASCOT ASSY	TATA spare parts
268055100110	MASCOT ASSY	TATA spare parts
268055100120	MASCOT ASSY	TATA spare parts
268055100126	MASCOT ASSY	TATA spare parts
268055100127	MASCOT ASSY	TATA spare parts
268055100129	MASCOT ASSY	TATA spare parts
268055100130	MASCOT ASSY FOR 2823 K	TATA spare parts
268055100131	MASCOT ASSY	TATA spare parts
268055100132	MASCOT ASSY	TATA spare parts
268055100133	MASCOT ASSY BS6	TATA spare parts
268055100138	MASCOT ASSY	TATA spare parts
268055100139	MASCOT ASSY	TATA spare parts
268055100144	MASCOT ASSY	TATA spare parts
268055100146	MASCOT ASSY	TATA spare parts
268055100148	MASCOT ASSY BS6	TATA spare parts
268055100151	MASCOT ASSY BS6	TATA spare parts
268055100152	MASCOT ASSY BS6	TATA spare parts
268055100153	MASCOT ASSY BS6	TATA spare parts
268055100154	MASCOT ASSY BS6	TATA spare parts
268055100155	MASCOT ASSY BS6	TATA spare parts
268055100160	MASCOT ASSY BS6	TATA spare parts
268055100161	MASCOT ASSY BS6	TATA spare parts
268055100162	MASCOT ASSY SIGNA BS6-PH2	TATA spare parts
268055100163	MASCOT ASSY BS6	TATA spare parts
268055100168	MASCOT ASSY BS6	TATA spare parts
268055100171	MASCOT ASSY BS6	TATA spare parts
268055100174	MASCOT ASSY BS6	TATA spare parts
268055100182	MASCOT ASSY BS6	TATA spare parts
268055100186	MASCOT ASSY - 4830.TK BS6-PH2	TATA spare parts
268055100187	MASCOT ASSY BS6	TATA spare parts
268055100191	MASCOT ASSY BS6-PH2	TATA spare parts
268055100192	MASCOT ASSY BS6	TATA spare parts
268055100193	MASCOT ASSY BS6	TATA spare parts
268055100194	MASCOT ASSY BS6	TATA spare parts
268055100195	MASCOT ASSY BS6	TATA spare parts
268055100196	MASCOT ASSY BS6-PH2	TATA spare parts

268055100199	MASCOT ASSY INCH1923.TINCH BS6-PH2	TATA spare parts
268055106304	MASCOT BS6	TATA spare parts
268055110102	MASCOT ASSY BS6-PH2	TATA spare parts
268055110107	MASCOT ASSY BS6-PH2	TATA spare parts
268055110111	MASCOT ASSY BS6-PH2	TATA spare parts
268055110115	MASCOT ASSY BS6-PH2	TATA spare parts
268055110122	MASCOT ASSY BS6	TATA spare parts
268055110131	MASCOT ASSY INCH1923.TKINCH BS6-PH2	TATA spare parts
268055110154	MASCOT ASSY BS6	TATA spare parts
268055110165	MASCOT ASSY BS6	TATA spare parts
268055156301	DECAL FRONT DOOR LH BS6	TATA spare parts
268055156302	DECAL FRONT DOOR RH BS6	TATA spare parts
268060000109	BODY ASSY PAINTED BS6	TATA spare parts
268060000109BL	ASSY BODY SHELL PAINTED BLUE	TATA spare parts
268060000109IP	SUNRISE_ORAG-ASSY BODY SHELL PAINTED-SIG	TATA spare parts
268060000109JS	TITANIUM_WH-ASSY BODY SHELL PAINTED-SIGN	TATA spare parts
268060000116	BODY ASSY PAINTED BS6	TATA spare parts
268060000136	SUPPORT ASSY DASHBOARD CROSS MEMBER BS6	TATA spare parts
268060000137	DASHBOARD CROSS CAR BEAM ASSY MIDDLE BS6	TATA spare parts
268060000139	SUPPORT ASSY DASHBOARD MTG BS6 PH2	TATA spare parts
268060100103	ASSY.CAB COMPLETE - RHD. 4021 TC	TATA spare parts
268060100105	ASSY BODY SHELL PAINTED-RHD	TATA spare parts
268060100107	ASSY. BARE CAB - RHD. 4021 TC	TATA spare parts
268060100140	ASSY CAB COMP LPS 3516 TC	TATA spare parts
268060100148	LPS3516 TC-RHDSL A/C CAB COMPLETE	TATA spare parts
268060100149	ASSY.SL A/C CAB PAINTED-LPS 3516TC RHD	TATA spare parts
268060100173	ASSY TIE MEMBER FRONT	TATA spare parts
268060100178	ASSY CAB COMPLETE	TATA spare parts
268060100178SJ	ASSY CAB COMPLETE SPARE PARTS	TATA spare parts
268060100195	ASSY CAB COMPLETE - RHD	TATA spare parts
268060100195SJ	ASSY. CAB COMP.W/FITMENTS LPT2516 SP BS1	TATA spare parts
268060103303	HINGE LEAF CENTER FLAP	TATA spare parts
268060108219	GUSSET BS6	TATA spare parts
268060108222	PANEL INNER REAR LH BS6-PH2	TATA spare parts
268060108223	PANEL INNER RH BS6-PH2	TATA spare parts
268060108601	SPACER BS6	TATA spare parts
268060110104	ASSY BODY SHELL PAINTED-RHD	TATA spare parts
268060110118SJ	ASSY.COWL COMP.4018TC-R/EX BS3 (SPARE)	TATA spare parts
268060110119	ASSY CAB COMPLETE LPS-3518TC BS-III	TATA spare parts
268060110119SJ	ASSY CAB COMP.LPS-3518TC BS-III SPARE	TATA spare parts
268060110120	ASSY. COWL COMP. WITH FITMENTS 3518	TATA spare parts
268060110125	ASSY CAB COMPLETE RHD	TATA spare parts
268060110125SJ	ASSY. CAB COMP RHD (ERGO R&C SPARE)	TATA spare parts
268060110126	ASSY. BODY SHELL PAINTED RHD BS1/3/4	TATA spare parts
268060110139SJ	ASSY CAB COMPLETE - LPT 2518-SPARE	TATA spare parts
268060110140	ASSY CAB COMPLETE	TATA spare parts
268060110140SJ	ASSY CAB COMPLETE SPARE PARTS	TATA spare parts

268060110143	ASSY CAB COMPLETE-RHD	TATA spare parts
268060110143SJ	LPS4018TCBS-III SLPR ERGO_ SPARE PARTS	TATA spare parts
268060110144	ASSY BODY SHELL PAINTED-RHD	TATA spare parts
268060110155SJ	ASSY.CAB COMPLETE-RHD SPARE LPS 4923 TC	TATA spare parts
268060110156	ASSY BODY SHELL IN WHITE RHD	TATA spare parts
268060110160	ASSY COWL SHELL PAINTED	TATA spare parts
268060110164SJ	ASSY.COWL COMP. ERGO.4018TC BS3 (SPARE)	TATA spare parts
268060110169	ASSY CAB COMP.LPS-3518TC BS-III	TATA spare parts
268060110174SJ	ASSY. CAB COMP. LPS4923 R&C ERGO BS3	TATA spare parts
268060110175	ASSY BODY SHELL PAINTED RHD	TATA spare parts
268060110189	ASSY CAB COMPLETE RHD	TATA spare parts
268060110189SJ	ASSY. CAB COMP. LPS3518 ERGO R&C BS3	TATA spare parts
268060110190SJ	ASSY CAB COMP ERGO R & C LPS 4923(SPARE)	TATA spare parts
268060110191	ASSY BODY SHELL PAINTED RHD	TATA spare parts
268060118205	SPACER BS6	TATA spare parts
268060120102	PANEL INNER REAR LH	TATA spare parts
268060120103	PANEL INNER REAR RH	TATA spare parts
268060120106	ASSY BODY SHELL IN WHITE	TATA spare parts
268060120107	ASSY. BODY SHELL PAINTED LPS4923 FL BS3	TATA spare parts
268060120107BL	ASSY BODY SHELL PAINTED_BLUE SIGNA BS3/B	TATA spare parts
268060120107IP	ASSY. BARE CABIN SUNRISE_ORANGE BS3/4	TATA spare parts
268060120107JS	TITANIUM WHITE BARE CABIN BS3/4	TATA spare parts
268060120112	ANGLE SUPPORT BIRTH BOX	TATA spare parts
268060120116	ASSY COVER [STEP SUPPORT] LH. BS6	TATA spare parts
268060120117	ASSY COVER [STEP SUPPORT] RH BS6	TATA spare parts
268060120132	ASSY.DASH CROSS CAR BEAM LH	TATA spare parts
268060120133	ASSY DASH CROSS CAR BEAM RH	TATA spare parts
268060120134	ASSY DASH CROSS CAR BEAM MIDDLE	TATA spare parts
268060120136	ASSY. CABIN BARE SLPR BS4/6	TATA spare parts
268060120148SJ	ASSY CAB COMPLETE RHD	TATA spare parts
268060120150	BIRTH BOX	TATA spare parts
268060120151	ASSY COWL SHELL PAINTED	TATA spare parts
268060120155SJ	ASSY CAB COMPLETE RHD	TATA spare parts
268060120162	BRACKET ASSY	TATA spare parts
268060120164	CAB ASSY WITH FITMENTS	TATA spare parts
268060120169	ANGLE ASSY SUPPORT BERTH BOX BS6	TATA spare parts
268060120176	ASSY. CABIN BARE SLPR BS4	TATA spare parts
268060120183	ASSY. COWL PAINTED BS6	TATA spare parts
268060120189	PANEL INNER REAR LH BS6	TATA spare parts
268060120190	PANEL INNER REAR RH BS6	TATA spare parts
268060130109	COWL ASSY PAINTED BS6	TATA spare parts
268060130113	TIE MEMBER ASSY BS6-PH2	TATA spare parts
268060130155	COWL ASSY PAINTED BS6	TATA spare parts
268060138201	HEADLAMP COVER LH BS6-PH2	TATA spare parts
268060138203	HEADLAMP COVER RH BS6-PH2	TATA spare parts
268061000110	ASSY SUBSTRUCTURE-RHD	TATA spare parts
268061000113	SUBSTRUCTURE ASSY BS6	TATA spare parts

268061000119	CABIN FLOOR STRUCTURE-COMPLETE	TATA spare parts
268061000120	SUBSTRUCTURE ASSY BS6	TATA spare parts
268061000121	SUBSTRUCTURE ASSEMBLY (Y)	TATA spare parts
268061100123	ASSY TOP FOOT STEP MTG FRAME FENDER LH	TATA spare parts
268061100124	ASSY TOP FOOT STEP MTG FRAME FENDER RH	TATA spare parts
268061100129	BRACKET ASSY SEAT BELT MTG BOTTOM-LH BS6	TATA spare parts
268061100130	BRACKET ASSY SEAT BELT MTG BOTTOM-RH BS6	TATA spare parts
268061108220	REINFORCEMENT BRACKET RH BS6	TATA spare parts
268061108221	REINFORCEMENT BRACKET LH BS6	TATA spare parts
268061160105	BRACKET ASSY CAB MTG FRONT-LH BS6	TATA spare parts
268061160106	BRACKET ASSY CAB MTG FRONT-RH BS6	TATA spare parts
268061200107	ASSY SUPPORT CROSS MEMBER BS6	TATA spare parts
268061200114	ASSY SUPPORT CROSS MEMBER	TATA spare parts
268061200116	BRACKET ASSY FENDER MTG REAR-LH	TATA spare parts
268061200117	BRACKET ASSY FENDER MTG REAR-RH	TATA spare parts
268061203301	BRACKET (FENDER MTG BODY SIDE FRT)	TATA spare parts
268061300102	ASSY REINFORCEMENT BRACKET (SEAT MTG) BS	TATA spare parts
268061308202	REINFORCEMENT_BRACKET BS6-PH2	TATA spare parts
268061600111	ASSY.MUDGUARD LH (REAR)	TATA spare parts
268061600112	ASSY.MUDGUARD RH (REAR)	TATA spare parts
268061600124	ASSEMBLY FLOOR PANEL-LH	TATA spare parts
268061600125	ASSEMBLY FLOOR PANEL-RH	TATA spare parts
268061600130	REINFORCEMENT FLOOR-LH (WHEEL ARCH)	TATA spare parts
268061600131	REINFORCEMENT FLOOR-RH (WHEEL ARCH)	TATA spare parts
268061600132	ASSY EXTN. MUDGUARD REAR LH	TATA spare parts
268061600133	ASSY. EXTN. MUDGUARD REAR RH	TATA spare parts
268061600140	BRACKET ASSY FENDER MTG REAR-LH	TATA spare parts
268061600141	BRACKET ASSY FENDER MTG REAR-RH	TATA spare parts
268061600142	BRACKET ASSY	TATA spare parts
268061606301	EXTENSION MUDGUARD REAR LH	TATA spare parts
268061606302	EXTENSION MUDGUARD REAR RH	TATA spare parts
268061608227	SCUFF PLATE MOUNTING BRACKET BS6-PH2	TATA spare parts
268061608228	FLOOR PANEL REAR LH BS6-PH2	TATA spare parts
268061608229	FLOOR PANEL REAR RH BS6-PH2	TATA spare parts
268061608230	FLOOR PANEL FRONT LH BS6-PH2	TATA spare parts
268061608231	FLOOR PANEL FRONT RH BS6-PH2	TATA spare parts
268061608238	REINFORCEMENT RH (DOOR SEALING RUBBER) B	TATA spare parts
268061608239	REINFORCEMENT LH (DOOR SEALING RUBBER) B	TATA spare parts
268061990101	KIT-MAJOR BIW ITEMS BS6	TATA spare parts
268061990104	KIT-MAJOR BIW ITEMS	TATA spare parts
268062000141	FRONT WALL ASSY	TATA spare parts
268062000160	FRONT WALL ASSY BS6	TATA spare parts
268062100114	ASSY.FRAME FRONT-LH	TATA spare parts
268062100115	ASSY.FRAME FRONT-RH	TATA spare parts
268062100119	DOOR POST RH	TATA spare parts
268062100120	DOOR POST LH	TATA spare parts
268062100121	ASSY GUSSET BOOTTOM L.H. (DOOR POST) BS6	TATA spare parts



268062100122	ASSY GUSSET BOTTOM RH DOOR POST BS6	TATA spare parts
268062100124	ASSEMBLY FRAME FRONT LH	TATA spare parts
268062100127	ASSEMBLY FRAME FRONT RH	TATA spare parts
268062100145	DOOR POST ASSY LH BS6	TATA spare parts
268062100146	DOOR POST ASSY RH BS6	TATA spare parts
268062100154	FRAME ASSY FRONT-LH BS6	TATA spare parts
268062100155	FRAME ASSY FRONT-RH BS6	TATA spare parts
268062108217	GUSSET TOP REAR RH BS6	TATA spare parts
268062108218	GUSSET TOP REAR LH BS6	TATA spare parts
268062108233	DASH LOWER CO-DRIVER SIDE MTG BRKT LH BS	TATA spare parts
268062108234	FOOT DUCT BIW PANEL MTG BRKT RH BS6	TATA spare parts
268062108235	DB LOWER DRIVER SIDE MGT BKT BS6	TATA spare parts
268062108236	DB LOWER DRIVER SIDE MTG BRKT RH BS6	TATA spare parts
268062108237	END COVER LOWER MTG BRKT LH BS6	TATA spare parts
268062108238	END COVER UPPER MTG BRKT LH BS6	TATA spare parts
268062108239	END COVER LOWER MTG BRKT RH BS6-PH2	TATA spare parts
268062108240	DASH END COVER UPR MTG BRKT RH BS6	TATA spare parts
268062108247	BRACKET ASSY DUCT MTG LH BS6-PH2	TATA spare parts
268062108256	BRACKET DEMIST MTG MIDDLE-RH BS6	TATA spare parts
268062108261	BRACKET ASSY DUCT MTG RH BS6-PH2	TATA spare parts
268062108262	DASH LOWER DRIVER SIDE CTR BKT BS6	TATA spare parts
268062200106	SUPPORT ASSY BONNET SIDE BS6-PH2	TATA spare parts
268062200119	KIT FOR RETRO FITMENT 1516 CAB(GUSSETS)	TATA spare parts
268062200121	ASSY WAIST RAIL COMPLETE RHD BS6	TATA spare parts
268062200123	ASSY PARTITION WALL BS6	TATA spare parts
268062200124	REINFORCEMENT ASSY WAIST RAIL BS6	TATA spare parts
268062200127	ASSY SUPPORT (BONNET SIDE) BS6	TATA spare parts
268062200129	BRACKET ASSY GPS UNIT MTG BS6	TATA spare parts
268062200138	TUBE ASSY FRONT FRAME STRUCTURE BS6-PH2	TATA spare parts
268062200144	WAIST RAIL	TATA spare parts
268062200148	REINFORCEMENT WAIST RAIL	TATA spare parts
268062200152	BRACKET ASSY HVAC MTG BS6-PH2	TATA spare parts
268062200153	BRACKET ASSY HVAC MTG BS6-PH2	TATA spare parts
268062200164	ASSY CCB MTG BKT LH BS6	TATA spare parts
268062200166	ASSY_BKT_TOE_TRIMS_UPPER_MTG BS6	TATA spare parts
268062200181	BRACKET ASSY HVAC MTG RH BS6-PH2	TATA spare parts
268062200182	ASSY CCB MTG BKT RH BS6	TATA spare parts
268062200183	ASSY DASH UPR MTG BKT LH	TATA spare parts
268062200186	ASSY DASH UPPER MIDDLE MTG BKT	TATA spare parts
268062200189	ASSY DASH UPR MTG BKT RH	TATA spare parts
268062200197	BRACKET ASSY WIPER MOTOR	TATA spare parts
268062208215	WATER TANK MTG.BRKT.	TATA spare parts
268062208218	REINFORCEMENT WINDSHIELD BOTTOM INEER-LH	TATA spare parts
268062208219	REINFORCEMENT WINDSHIELD BOTTOM INEER-RH	TATA spare parts
268062208220	GUSSET WAIST RAIL LH BS6	TATA spare parts
268062208221	GUSSET WAIST RAIL RH BS6	TATA spare parts
268062208224	WAIST RAIL RHD	TATA spare parts

268062208226	REINFORCEMENT E/RAIL RHD BS6	TATA spare parts
268062208231	REINF BKT BONNET SIDE LH BS6	TATA spare parts
268062208232	REINF BKT BONNET SIDE RH BS6	TATA spare parts
268062208233	REINFORCEMENT SUPPORT (BONNET SIDE) BS6	TATA spare parts
268062208234	REINFORCEMENT BRACKET BONNET SIDE BS6	TATA spare parts
268062208235	REINFORCEMENT BRACKET BONNET SIDE LH BS6	TATA spare parts
268062208237	REINFORCEMENT COVER PANEL BS6	TATA spare parts
268062208238	REINFORCEMENT BRACKET BONNET SIDE RH BS6	TATA spare parts
268062208241	COVER DOOR POST BOTTOM-LH BS6	TATA spare parts
268062208243	WATER TANK MTG BKT LH	TATA spare parts
268062208244	REINFORCEMENT LH (DOOR POST) BS6	TATA spare parts
268062208246	COVER DOOR POST BOTTOM-RH BS6	TATA spare parts
268062208247	WATER TANK MTG BKT RH	TATA spare parts
268062208257	REINFORCEMENT SUPPORT BONNET SIDE BS6-PH	TATA spare parts
268062208273	WAIST RAIL RHD BS6	TATA spare parts
268062208274	WAIST RAIL REINF. SUPPORT BRKT BS6	TATA spare parts
268062208276	REINFORCEMENT RH (DOOR POST) BS6	TATA spare parts
268062210103	ASSY BKT TOE TRIMS UPPER MTG Z TYPE BS6	TATA spare parts
268062210111	BRKT ASSY GRAB HANDLE MTG LH BS6-PH2	TATA spare parts
268062500128	OUTER PANEL WINDSHIELD BOTTOM BS3/4	TATA spare parts
268062500133	SUPPORT (FACE SIDE PANEL) RH	TATA spare parts
268062500134	ASSY FACE PANEL BOTTOM LH	TATA spare parts
268062500135	ASSY PANEL FACE SIDE BOTTOM RH	TATA spare parts
268062500155	PANEL ASSY FACE SIDE BOTTOM-LH BS6	TATA spare parts
268062500156	PANEL ASSY FACE SIDE BOTTOM-RH BS6	TATA spare parts
268062508212	BRACKET FRONT SIDE PANEL LH(DOOR SIDE) B	TATA spare parts
268062508213	BRACKET FRONT SIDE PANEL LH (CENTER FLAP	TATA spare parts
268062508214	BRACKET FRONT SIDE PANEL LH(BOTTOM SIDE)	TATA spare parts
268062508220	OUTER PANEL WINDSHIELD BOTTOM BS6-PH2	TATA spare parts
268062508221	PANEL FACE SIDE BOTTOM LH BS6	TATA spare parts
268062508238	OUTER PANEL SIDE WINDSHIELD LH BS6	TATA spare parts
268062508239	OUTER PANEL SIDE WINDSHIELD RH BS6	TATA spare parts
268062508240	OUTER PANEL WINDSHIELD BOTTOM BS6	TATA spare parts
268062508242	PLATE LH BS6-PH2	TATA spare parts
268062508243	PLATE RH BS6-PH2	TATA spare parts
268062508258	BRACKET BS6-PH2	TATA spare parts
268062600108	A-PILLAR ASSY INNER-LH	TATA spare parts
268062600111	A-PILLAR ASSY INNER-RH	TATA spare parts
268062600130	INNER PANEL ASSY WINDSHIELD BOTTOM BS6	TATA spare parts
268062600131	ASSY TOE PANEL RH RHD	TATA spare parts
268062600133	ASSY COVER PANEL RHD	TATA spare parts
268062600140	PANEL INNER SIDE W/S LH (A PILLAR LH)	TATA spare parts
268062600141	PANEL INNER SIDE W/S RH (A PILLAR RH)	TATA spare parts
268062600144	TOE PANEL RH (Y)	TATA spare parts
268062600145	TOE PANEL LH (Y)	TATA spare parts
268062600148	ASSEMBLY BONNET COMPLETE BS6	TATA spare parts
268062600149	COVER PANEL	TATA spare parts

268062600152	ASSEMBLY BONNET COMPLETE	TATA spare parts
268062600154	ASSY FUSE BOX MTG BRKT	TATA spare parts
268062600157	PANEL INNER BOTTOM WIND SCREEN (Y)	TATA spare parts
268062600166	ASSY CCB SUPPORTING BRKT LH RHD BS6-PH2	TATA spare parts
268062600168	ASSY BRACKET(WHEEL BOX MTG AT Y=240) BS6	TATA spare parts
268062600169	ASSY BRACKET(WHEEL BOX MTG AT Y=720) BS6	TATA spare parts
268062600170	BAFFLE SUPPORT FIREWALL-LH BS6	TATA spare parts
268062600171	BAFFLE SUPPORT FIREWALL-RH BS6	TATA spare parts
268062600174	BRACKET ASSY	TATA spare parts
268062600181	BONNET ASSY BS6	TATA spare parts
268062600182	TOE PANEL ASSY RH BS6	TATA spare parts
268062600183	BRACKET ASSY LH BS6	TATA spare parts
268062600184	BRACKET ASSY RH BS6	TATA spare parts
268062600185	BRACKET ASSY LH BS6	TATA spare parts
268062600186	BRACKET ASSY RH BS6	TATA spare parts
268062600187	BRACKET ASSY LH BS6	TATA spare parts
268062600188	BRACKET ASSY RH BS6	TATA spare parts
268062600196	PANEL ASSY WINDSHIELD INNER-BOTTOM BS6	TATA spare parts
268062608203	A-PILLAR INNER-LH BS6-PH2	TATA spare parts
268062608204	A-PILLAR INNER-RH BS6-PH2	TATA spare parts
268062608226	PANEL INNER BOTTOM(W/S)	TATA spare parts
26806260822635	PANEL INNER BOTTOM(W/S) + CED	TATA spare parts
268062608227	SUPPORT PANEL WINDSHIELD INNER PANEL BS6	TATA spare parts
268062608256	COVER PANEL RHD BS6	TATA spare parts
268062608260	PANEL INNER BOTTOM WIND SCREEN BS6-PH2	TATA spare parts
268062608267	SUPPORT PANEL (PANEL INNER W/S) BS6	TATA spare parts
268062608278	GUSSET CENTER (COVER PANEL) BS6	TATA spare parts
268062608279	GUSSET RH(COVER PANEL) BS6	TATA spare parts
268062608280	BRKT INNER(COVER PANEL) BS6	TATA spare parts
268064200101	MAP POCKET & QTR TRIM MTG.BKT LH	TATA spare parts
268064200103	ASSY BRACKET ARM REST POCKET LH BS6-PH2	TATA spare parts
268064208208	REAR WALL MTG BRKT BS6	TATA spare parts
268064208212	REAR WALL CORNER MTG BRKT BS6	TATA spare parts
268064208226	BRACKET REAR WALL TRIM MTG BS6-PH2	TATA spare parts
268064700111	ASSY.REAR WALL WELDED(WITHOUT LOUVERS)	TATA spare parts
268064700115	ASSY CORNER PANEL OUTER WITH POST RH	TATA spare parts
268064700119	CABIN REAR WALL STRUCTURE-COMP. BS3/4/6	TATA spare parts
268064700123	ASSY. CORNER PANEL OUTER W/POST LH BS3-6	TATA spare parts
268064700125	ASSY. CORNER PANEL OUTER W/POST RH BS3-6	TATA spare parts
268064700147	REAR WALL ASSY BS6	TATA spare parts
268064700150	ASSY. CORNER PANEL OUTER W/POST LH BS3-6	TATA spare parts
268064700151	ASSY. CORNER PANEL OUTER W/POST RH BS3-6	TATA spare parts
268064708205	PANEL OUTER BOTTOM	TATA spare parts
268064708206	PANEL OUTER TOP	TATA spare parts
268064708211	OUTER PANEL REAR WALL BS6	TATA spare parts
268065200107	ASSY TOP RAIL REAR	TATA spare parts
268065200109	ASSY ROOF COMPLETE BS2/3/4	TATA spare parts

268065200115	ASSY ROOF COMPLETE BS6	TATA spare parts
268065200117	REINFORCEMENT ASSY ROOF BS6	TATA spare parts
268065200141	BRACKET ASSY HEADBOX MTG LH BS6	TATA spare parts
268065200142	BRACKET ASSY HEADBOX MTG RH BS6	TATA spare parts
268065208205	REINFORCEMENT PLATEBS6	TATA spare parts
268065208207	TOP RAIL REAR BS6	TATA spare parts
268065208211	BRACKET ROOF LINER MTG BS6-PH2	TATA spare parts
268065208214	BRACKET ROOF LINER MTG BS6-PH2	TATA spare parts
268065708204	GUSSET ROOF REINFORCEMENT FRT BS6-PH2	TATA spare parts
268065708216	PANEL ROOF SLEEPER CAB BS6	TATA spare parts
268066500101	ASSEMBLY MUDGUARD-LH (Y)	TATA spare parts
268066500102	ASSEMBLY MUDGUARD-RH (Y)	TATA spare parts
268066600107	ASSY STEP WELL COMPLETE LH	TATA spare parts
268066600108	ASSY STEP WELL COMP RH	TATA spare parts
268066608217	STEP BS6	TATA spare parts
268067100109	REAR WINDOW ASSY BS6	TATA spare parts
268067102302	GLASS PANE REAR WINDOW	TATA spare parts
268067102303	GLASS PANE SIDE WINDOW	TATA spare parts
268067102304	WINDSHIELD GLASS BS3/4/6	TATA spare parts
2680671023040F	WINDSHIELD GLASS FRONT	TATA spare parts
268067102306	WINDSHIELD GLASS FRONT	TATA spare parts
268067102308	CANOPY GLASS BS6	TATA spare parts
268067102501	FILLER PROFILE WIND-SHIELD GLASS	TATA spare parts
268067106301	RUBBER MOULD (WIND SCREEN) BS3	TATA spare parts
268067106302	RUBBER MOULD;REAR WINDOW	TATA spare parts
268067106303	RUBBER MOULD SIDE WINDOW	TATA spare parts
268067106304	RUBBER MOULD WINDSHIELD GLASS BS3/4	TATA spare parts
268067106305	RUBBER MOULD WINDSCREEN GLASS	TATA spare parts
268067400101	SIDE WINDOW ASSY RH BS6	TATA spare parts
268067400102	SIDE WINDOW ASSY LH BS6	TATA spare parts
268068206301	FLOOR ADH MELT SHEET LH	TATA spare parts
268068206302	FLOOR ADH MELT SHEET RH	TATA spare parts
268068206303	FLOOR ADH MELT SHEET (BERTH BOX)	TATA spare parts
268068206304	FLOOR ADH MELT SHEET (BERTH BOX)	TATA spare parts
268068206305	MEL SHEET REAR FLOOR CENTER BS6	TATA spare parts
268068400102	ASSY COMPOSITE FLOOR MAT-RHD	TATA spare parts
268068406304	CARPET ENGINE BONNET	TATA spare parts
268068406307	CARPET_LH	TATA spare parts
268068406308	CARPET_RH	TATA spare parts
268068406309	CARPET_ENGINE HOOD	TATA spare parts
268068406311	CARPET REAR LH	TATA spare parts
268068406312	CARPET CENTER	TATA spare parts
268068406313	CARPET FLOOR RH	TATA spare parts
268068406316	CARPET REAR RH	TATA spare parts
268068406323	CARPET LH BS6 PH2	TATA spare parts
268068406325	CARPET RH BS6 PH2	TATA spare parts
268068406327	CARPET CENTER BS6 PH2	TATA spare parts

268068406328	CARPET REAR BS6-PH2	TATA spare parts
268068700101	ASSY TOE PANEL TRIM LH OUTBOARD	TATA spare parts
268068706301	TOE PANEL TRIM LH OUTBOARD	TATA spare parts
268068706302	TOE PANEL TRIM LH INBOARD	TATA spare parts
268068706303	FUSE BOX LID	TATA spare parts
268068706304	BONNET CENTER TRIM	TATA spare parts
268068706305	TOE PANEL TRIM RH INBOARD	TATA spare parts
268068706306	TOE PANEL TRIM RH OUTBOARD	TATA spare parts
268068900108	ASSY DASHBOARD LID(GLOVE BOX)	TATA spare parts
268068900109	ASSY DASHBOARD LID-CENTRE	TATA spare parts
268068900110	ASSY. INSTRUMENT PANEL & COVER BS1/3/4	TATA spare parts
268068900111	ASSY D/BOARD LID CENTRE(G/B)	TATA spare parts
268068900112	ASSY D/BOARD LID SIDE(G/BOX)	TATA spare parts
268068900115	ASSY DASHBOARD LID-CENTRE(GLOVE BOX)	TATA spare parts
268068900116	ASSY DASHBOARD LID SIDE(GLOVE BOX)	TATA spare parts
268068900117	PRE-ASSY. DASHBOARD FACELIFT AC BS4	TATA spare parts
268068900118	ASSY CENTRAL AIRVENT BEZEL AC	TATA spare parts
268068900119	ASSY CENTER FINISHER	TATA spare parts
268068900123	ASSY GLOVE BOX BEZEL	TATA spare parts
268068900124	ASSY UREA GAUGE BEZEL	TATA spare parts
268068900125	ASSY. DASH UPPER DRIVER SIDE BS3/4/6	TATA spare parts
268068900126	ASSY DASH UPPER CO-DRIVER SIDE	TATA spare parts
268068900127	ASSY TOP UTILITY BIN	TATA spare parts
268068900130	PRE ASSY. DASHBOARD FACELIFT BS3/4	TATA spare parts
268068900131	ASSY CENTRAL AIRVENT BEZEL NON AC	TATA spare parts
268068900132	ASSY DASHBOARD END COVER LH NON AC	TATA spare parts
268068900133	ASSY DASHBOARD END COVER RH NON AC	TATA spare parts
268068900135	ASSY.KIT LOCKS (DOM) COWL BS6	TATA spare parts
268068900139	CENTER FINISHER ASSY	TATA spare parts
268068900140	INSTRUMENT PANEL ASSY BS6	TATA spare parts
268068900141	DASHBOARD ASSY	TATA spare parts
268068900145	DASHBOARD ASSY BS6	TATA spare parts
268068900149	CENTER FINISHER ASSY	TATA spare parts
268068900151	STEERING WHEEL ASSY WITH SWITCH BS6	TATA spare parts
268068900152	ASSY. STEERING WHEEL BS6	TATA spare parts
268068900153	DASHBOARD PRE ASSY BS6	TATA spare parts
268068900154	STEERING WHEEL ASSY BS6	TATA spare parts
268068900158	CENTER FINISHER ASSY BS6	TATA spare parts
268068900159	CENTER FINISHER ASSY BS6	TATA spare parts
268068900160	SWITCH BEZEL ASSY BS6	TATA spare parts
268068900301	HORN PAD ASSY	TATA spare parts
268068906305	LID CENTRE(HEATING)	TATA spare parts
268068906309	NACELLE FRONT	TATA spare parts
268068906310	NACELLE REAR	TATA spare parts
268068906316	INSTRUMENT_PANEL_LPS_1516_BS4	TATA spare parts
268068906320	DASHBOARD LOWER CO-DRIVER SIDE BS6-PH2	TATA spare parts
268068906323	SWITCH PLATE UPPER BS6	TATA spare parts

268068906324	SWITCH PLATE LOWER BS6	TATA spare parts
268068906329	1 DIN BLANK COVER BS6	TATA spare parts
268068906335	GLOVE BOX CAP	TATA spare parts
268068906336	UREA BEZEL CAP	TATA spare parts
268068906343	DUMMY¿AIR¿VENT¿CAP	TATA spare parts
268068906344	RUBBER MAT TOP UTILITY BIN	TATA spare parts
268068906345	FOAM BS6-PH2	TATA spare parts
268068906348	FOAM BS6-PH2	TATA spare parts
268068906357	SEAL INSTRUMENT PANEL	TATA spare parts
268068906362	COVER BLOWER UNIT BS6	TATA spare parts
268068906365	CENTRAL DASHBOARD ADD ON BS6-PH2	TATA spare parts
268068906368	BEZEL BS6	TATA spare parts
268068906375	NACELLE TOP BS6	TATA spare parts
268068906376	NACELLE BOTTOM BS6	TATA spare parts
268068906503	CROSS RECESSED RASIED CSK SCREW M6X35	TATA spare parts
268069100106	ASSY A PLR TRIM LH	TATA spare parts
268069100107	ASSY A PLR TRIM RH	TATA spare parts
268069106314	REAR WALL LINING	TATA spare parts
268069106315	CORNER LINING LH	TATA spare parts
268069106316	CORNER LINING RH	TATA spare parts
268069106321	QUARTER TRIM SLEEPER CAB RH BS6-PH2	TATA spare parts
268069106334	QUARTER TRIM SLPR CAB LH	TATA spare parts
268069106335	QUARTER TRIM SLPR CAB RH	TATA spare parts
268069106336	MAP POCKET QUARTER TRIM	TATA spare parts
268069106341	QUARTER TRIM SLEEPER CAB LH BS6-PH2	TATA spare parts
268069106343	QUARTER TRIM SLPR CAB LH BS6	TATA spare parts
268069106344	QUARTER TRIM SLPR CAB RH BS6	TATA spare parts
268069106354	COVER HINGE BS6-PH2	TATA spare parts
268069306301	COVER HAND BRAKE VALVE BS6	TATA spare parts
268069306302	COVER HAND BRAKE VALVE BS6	TATA spare parts
268069400101	ASSY SCUFF PLATE LH	TATA spare parts
268069400102	ASSY SCUFF PLATE RH	TATA spare parts
268069400103	ASSY REAR WALL TRIM	TATA spare parts
268069400104	REAR WALL TRIM ASSY BS6	TATA spare parts
268069400106	REAR WALL TRIM ASSY BS6 PH2	TATA spare parts
268069406303	EXIT VENT INNER	TATA spare parts
268069406304	FOAM BS6	TATA spare parts
268069406305	FOAM BS6	TATA spare parts
268069406306	FOAM REAR WALL BS6-PH2	TATA spare parts
268069408201	RING¿BEZEL¿(AIR¿EXTRACTOR¿GRILL) BS6	TATA spare parts
268069506301	MOULDED ROOF LINING SLEEPER BS1/3/4	TATA spare parts
268069506302	MOULDED ROOF LINING SLEEPER BS3/4/6	TATA spare parts
268069506305	MOULDED ROOF LINING BS6	TATA spare parts
268069506306	MOULDED ROOF LINING BS6	TATA spare parts
268069506319	ROOF LINING FRONT BS6-PH2	TATA spare parts
268069506320	ROOF LINING REAR BS6-PH2	TATA spare parts
268069806301	SEAL BS6	TATA spare parts

268072200116	ASSY. DOOR SHELL LH RHD BS3/4/6	TATA spare parts
26807220011635	CED PRT FOR DOOR SHELL ASSY FRONT-LH BS6	TATA spare parts
268072200117	ASSY PANEL DOOR INNER LH	TATA spare parts
268072200118	ASSY. DOOR SHELL RH RHD BS3/4/6	TATA spare parts
26807220011835	CED PRT FOR DOOR SHELL ASSY FRONT-RH BS6	TATA spare parts
268072200119	ASSY PANEL DOOR INNER RH	TATA spare parts
268072208210	BRACKET DOOR PULL MTG LH BS6	TATA spare parts
268072208211	BRACKET DOOR PULL MTG RH BS6	TATA spare parts
268072300106	ASSY DOOR CHECK	TATA spare parts
268072300108	ASSY.KIT.FOR LOCKS (DOMESTIC)	TATA spare parts
268072300109	KIT-LOCKS BS1/2/3/4	TATA spare parts
268072300110	ASSY HANDLE DOOR OUTER LH	TATA spare parts
268072300111	ASSY.HANDLE DOOR OUTER RH	TATA spare parts
268072300112	ASSY LOCK GLOVE BOX	TATA spare parts
268072300113	ASSY KEY COMPLETE	TATA spare parts
268072300116	ASSY DOOR TRIM LH	TATA spare parts
268072300117	ASSY DOOR TRIM RH	TATA spare parts
268072300118	ASSY. DOOR TRIM LH(NON-AC) BS3/4/6	TATA spare parts
268072300119	ASSY. DOOR TRIM RH(NON-AC) BS3/4/6	TATA spare parts
268072300124	STRIKER ASSY BS6-PH2	TATA spare parts
268072300126	HINGE ASSY BS6	TATA spare parts
268072300127	HINGE LEAF ASSY DOOR SIDE BS6-PH2	TATA spare parts
268072300131	DOOR TRIM ASSY LH BS6 PH2	TATA spare parts
268072300132	DOOR TRIM ASSY RH BS6 PH2	TATA spare parts
268072300140	KIT-LOCK SET ASSY	TATA spare parts
268072300141	KIT-LOCK SET ASSY BS6	TATA spare parts
268072300146	LATCH ASSY LH BS6-PH2	TATA spare parts
268072300147	LATCH ASSY RH BS6-PH2	TATA spare parts
268072300148	HINGE ASSY BS6-PH2	TATA spare parts
268072300150	DOOR CHECK ASSY BS6-PH2	TATA spare parts
268072300152	HINGE ASSY BS6-PH2	TATA spare parts
268072300153	LINK LOCK BARREL TO LATCH LH BS6-PH2	TATA spare parts
268072300154	LINK LOCK BARREL TO LATCH RH BS6-PH2	TATA spare parts
268072300157	BELL CRANK ASSY BS6-PH2	TATA spare parts
268072301602	INNER HANDLE ASSY LH	TATA spare parts
268072301603	INNER HANDLE ASSY RH	TATA spare parts
268072303303	BRACKET	TATA spare parts
268072303402	BUSH (HINGE DOOR) M/S SAINT GOBAIN BS6-P	TATA spare parts
268072305601	KNOB	TATA spare parts
268072306301	STEP RAIL DOOR	TATA spare parts
268072306303	SEALING OUTER DOOR	TATA spare parts
268072306304	RUBBER BEADING-TURNING WINDOW	TATA spare parts
268072306306	RUBBER MOULD FIXED QUARTER GLASS BS1- 6	TATA spare parts
268072306307	DOOR SEALING INNER	TATA spare parts
268072306323	DOOR SEAL PRIMARY	TATA spare parts
268072306324	CROSS LINK FOAM (DOOR REGULATOR MTG)	TATA spare parts
268072306325	CROSS LINK FOAM	TATA spare parts

268072306326	CROSS LINK FOAM	TATA spare parts
268072306327	SECONDARY SEAL LH	TATA spare parts
268072306328	SECONDARY SEAL RH	TATA spare parts
268072306332	DOOR PRIMARY SEALING INNER LH	TATA spare parts
268072306333	DOOR PRIMARY SEALING INNER RH	TATA spare parts
268072306336	PRIMARY SEAL DOOR INNER-LH	TATA spare parts
268072306337	PRIMARY SEAL DOOR INNER-RH	TATA spare parts
268072306339	RUBBER PAD OUTER DOOR	TATA spare parts
268072306340	RUBBER PAD OUTER DOOR	TATA spare parts
268072310101	ASSY HANDLE¿ (SERRATION WINDOW	TATA spare parts
268072310107	OUTER HANDLE ASSY WITH BEZEL LH BS6 PH2	TATA spare parts
268072310108	OUTER HANDLE ASSY WITH BEZEL RH BS6 PH2	TATA spare parts
268072310109	LINK LH OUT.HANDLE -LATCH FRT.DR.BS6-PH2	TATA spare parts
268072310110	LINK RH OUT.HANDLE -LATCH FRT DR.BS6-PH2	TATA spare parts
268072330107	INNER HANDLE ASSY FRONT DOOR LH BS6 PH2	TATA spare parts
268072330108	INNER HANDLE ASSY FRONT DOOR RH BS6 PH2	TATA spare parts
268072331607	INNER HANDLE ASSY FRONT DOOR LH BS6 PH2	TATA spare parts
268072331608	INNER HANDLE ASSY FRONT DOOR RH BS6 PH2	TATA spare parts
268072336005	LINK KNOB TO LATCH FRT DR LH BS6-PH2	TATA spare parts
268072336006	LINK KNOB TO LATCH FRT DR RH BS6-PH2	TATA spare parts
268072336007	LINK LH INN.HANDLE -LATCH FRT DR.BS6-PH2	TATA spare parts
268072336008	LINK RH INN.HANDLE -LATCH FRT DR.BS6-PH2	TATA spare parts
268072336009	LINK KNOB TO LATCH FRT DR LH BS6-PH2	TATA spare parts
268072336010	LINK KNOB TO LATCH FRT DR RH BS6-PH2	TATA spare parts
268072500112	ASSY DOOR BEADING OUTER	TATA spare parts
268072500114	ASSY WEATHER STRIP INNER LH	TATA spare parts
268072500115	ASSY WEATHER STRIP INNER RH	TATA spare parts
268072502302	GLASS PANE(QUARTER WINDOW)	TATA spare parts
268072502303	GLASS PANE(QUARTER WINDOW)-CLEAR BS1- 6	TATA spare parts
268072502502	RUBBER PROFILE	TATA spare parts
268072506301	RUBBER MOULD LH(QUARTER WINDOW)	TATA spare parts
268072506302	RUBBER MOULD RH(QUARTER WINDOW)	TATA spare parts
268072506303	RUBBER MOULD FIXED QUARTER GLASS	TATA spare parts
268072536301	PRIMARY DOOR SEAL FRONT DOOR LH BS6	TATA spare parts
268072536302	PRIMARY DOOR SEAL FRONT DOOR RH BS6	TATA spare parts
268072537703	PRIMARY SEAL FRONT DOOR LH BS6-PH2	TATA spare parts
268072537704	PRIMARY SEAL FRONT DOOR RH BS6-PH2	TATA spare parts
268072546301	SECONDARY SEAL LH BS6-PH2	TATA spare parts
268072546302	SECONDARY SEAL RH BS6-PH2	TATA spare parts
268072700113	ASSY PLASTIC MEMBRANE LH	TATA spare parts
268072700114	ASSY PLASTIC MEMBRANE RH	TATA spare parts
268072700118	ASSY PLASTIC COVER UPPER FRONT LH	TATA spare parts
268072700119	ASSY PLASTIC COVER UPPER FRONT RH	TATA spare parts
268072700120	ASSY PLASTIC COVER UPPER BACK LH	TATA spare parts
268072700121	ASY PLASTIC COVER UPPER BACK RH	TATA spare parts
268072700122	ASSY PLASTIC COVER DOOR¿ MIDDLE FRONT	TATA spare parts
268072700123	ASSY PLASTIC COVER MIDDLE BACK	TATA spare parts



268072700124	ASSY PLASTIC COVER LOWER FRONT LH	TATA spare parts
268072700125	ASSY PLASTIC COVER LOWER FRONT RH	TATA spare parts
268072700126	ASSY PLASTIC COVER LOWER CENTER LH	TATA spare parts
268072700127	ASSY PLASTIC COVER LOWER CENTER RH	TATA spare parts
268072700128	ASSY PLASTIC COVER DOOR LOWER BACK LH	TATA spare parts
268072700129	ASSY PLASTIC COVER DOOR LOWER BACK RH	TATA spare parts
268072700130	ASSY PLASTIC COVER UPPER FRONT LH	TATA spare parts
268072700131	ASSY PLASTIC COVER UPPER FRONT RH	TATA spare parts
268072700132	ASSY PLASTIC COVER UPPER BACK LH	TATA spare parts
268072700133	ASSY PLASTIC COVER UPPER BACK RH	TATA spare parts
268072700134	ASSY PLASTIC COVER DOOR MIDDLE FRONT	TATA spare parts
268072700135	ASSY PLASTIC COVER DOOR MIDDLE BACK	TATA spare parts
268072700136	ASSY PLASTIC COVER LOWER FRONT LH	TATA spare parts
268072700137	ASSY PLASTIC COVER LOWER FRONT RH	TATA spare parts
268072700138	ASSY PLASTIC COVER LOWER CENTRE LH	TATA spare parts
268072700139	ASSY PLASTIC COVER LOWER CENTRE RH	TATA spare parts
268072700140	ASSY PLASTIC COVER DOOR LOWER BACK LH	TATA spare parts
268072700141	ASSY PLASTIC COVER DOOR LOWER BACK RH	TATA spare parts
268072700143	DOOR PAD ASSY LH	TATA spare parts
268072700144	DOOR PAD ASSY RH	TATA spare parts
268072700145	PLASTIC SKIRT MEMBRANE BS6	TATA spare parts
268072710101	PLASTIC MEMBRANE ASSY FRONT DOOR LH	TATA spare parts
268072710102	PLASTIC MEMBRANE ASSY FRONT DOOR RH	TATA spare parts
268072980105	KIT-LOCK SET ASSY BS6-PH2	TATA spare parts
268075100118	ASSY. CENTRE FLAP INNER BS3/4/6	TATA spare parts
268075100119	ASSY BRKT LOCK MEC(CENTRE FLAP) BS6-PH2	TATA spare parts
268075106901	STAY ROD CENTER FLAP	TATA spare parts
268075108212	PANEL CENTRE FLAP INNER BS6-PH2	TATA spare parts
268075108214	BRKT HINGE SUPPORT(CENTRE FLAP) BS6-PH2	TATA spare parts
268075200105	ASSY T EMBLEM(OVAL STYLISED) LP VER.	TATA spare parts
268075206302	PLATE BS6	TATA spare parts
268075206306	T-EMBLEM BS6	TATA spare parts
268081100104	ASSY.SUN SHADE.	TATA spare parts
268081100112	ASSY REAR VIEW MIRROR OUTER RH	TATA spare parts
268081100117	ASSY REAR VIEW MIRROR OUTER LH	TATA spare parts
268081100118	PROXIMITY MIRROR ASSY BS6	TATA spare parts
268081100125	ASSY. CLOSE PROXIMITY MIRROR BS1/2/3/4	TATA spare parts
268081100125AE	ASSY PROXIMITY MIRROR 1628 1828	TATA spare parts
268081100130	ASSY. FRONT ADD ON PANEL LH BS3/4/6	TATA spare parts
268081100130ZY	CLRPRT_ASY_1-ASSY FRONT SIDE ADD ON PANE	TATA spare parts
268081100130ZZ	ASSY FRONT SIDE ADD ON PANE	TATA spare parts
268081100131	ASSY. FRONT ADD ON PANEL RH BS3/4/6	TATA spare parts
268081100131ZY	CLRPRT_ASY_1-ASSY FRONT SIDE ADD ON PANE	TATA spare parts
268081100131ZZ	ASSY. FRONT SIDE ADD ON PANE	TATA spare parts
268081100132	DANGLER 9 SPEED DECAL LH	TATA spare parts
268081100133	DANGLER 9 SPEED DECAL RH	TATA spare parts
268081100134	ASSY. CENTER FLAP OUTER BS3/4/6	TATA spare parts

268081100134ZY	CLRPRT_ ASY_1-ASSY CENTER FLAP OUTER COMP	TATA spare parts
268081100134ZZ	ASSY. CENTER FLAP OUTER COMP_ CLRPART	TATA spare parts
268081100135	ASSY CENTER FLAP OUTER BS6-PH2	TATA spare parts
268081100136	ASSY. AIR GRILL OUTER W/CLIP BS3/4/6	TATA spare parts
268081100136IP	SUNRISE_ ORAG-ASSY FRESH AIR GRILL OUTER	TATA spare parts
268081100136JS	TITANIUM_ WHITE ASSY FRESH AIR GRILL OUT	TATA spare parts
268081100137	ASSY FRONT SIDE ADD ON PANEL & CLIPS LH	TATA spare parts
268081100138	ASSY FRONT SIDE ADD ON PANEL RH	TATA spare parts
268081100139	ASSY. AIR GRILL INNER BS3/4/6	TATA spare parts
268081100139IP	SUNRISE_ ORAG-ASSY FRESH AIR GRILL INNER	TATA spare parts
268081100139JS	ASSY. FRESH AIR GRILL INNE TITAN_ WHITE	TATA spare parts
268081100140	ASSY GRAB HANDLE LH	TATA spare parts
268081100141	ASSY GRAB HANDLE RH	TATA spare parts
268081100149	FRONT VIEW MIRROR ASSY	TATA spare parts
268081100150	MIRRORHOUSINGASSYFRONT BS6	TATA spare parts
268081100157	KIT-ORVM LH	TATA spare parts
268081100158	KIT-ORVM RH	TATA spare parts
268081100159	FRAME ASSY LH BS6	TATA spare parts
268081100160	MAIN MIRROR ASSY BS6	TATA spare parts
268081100161	WIDE ANGLE MIRROR ASSY BS6	TATA spare parts
268081100162	CLOSE PROXIMITY MIRROR ASSY	TATA spare parts
268081100163	FRAME ASSY RH BS6	TATA spare parts
268081100182	FRAME ASSY LH BS6	TATA spare parts
268081100183	FRAME ASSY RH BS6-PH2	TATA spare parts
268081100185	KIT-ORVM LH BS6	TATA spare parts
268081100186	KIT-ORVM RH BS6	TATA spare parts
268081100187	MAIN MIRROR ASSY BS6	TATA spare parts
268081100188	WIDE ANGLE MIRROR ASSY BS6	TATA spare parts
268081100189	KIT-FITMENT OF ORVM	TATA spare parts
268081100193	ADD ON PANEL ASSY FRONT-LH BS6	TATA spare parts
268081100194	ADD ON PANEL ASSY FRONT-RH BS6	TATA spare parts
268081100199	GRILL ASSY FRONT BS6	TATA spare parts
268081101605	FRONT VIEW MIRROR-OFFER DRG	TATA spare parts
268081103304	BRACKET TAIL LAMP MTG	TATA spare parts
268081106301	CENTRE GRILL LPS 4021	TATA spare parts
268081106302	SIDE GRILL LH LPS 4021	TATA spare parts
268081106303	GRILL RH SIDE LPS 4021	TATA spare parts
268081106311	FENDER TRIM LH	TATA spare parts
268081106312	FENDER TRIM RH	TATA spare parts
268081106316	DECAL LH (LIGHT BODY COLOUR)	TATA spare parts
268081106317	DECAL RH (LIGHT BODY COLOUR)	TATA spare parts
268081106318	DECAL LH (DARK BODY COLOUR)	TATA spare parts
268081106319	DECAL RH (DARK BODY COLOUR)	TATA spare parts
268081106322	PLUG(HANDLE)M/S AURO BS6	TATA spare parts
268081106324	FRONT SIDE ADD ON PANEL LH BS6	TATA spare parts
268081106325	FRONT SIDE ADD ON PANEL RH BS6	TATA spare parts
268081106326	AERO CORNER LH BS6	TATA spare parts

268081106327	AERO CORNER RH BS6	TATA spare parts
268081106331	GRILL_SPEAKER_REARWALL	TATA spare parts
268081106338	PLUG (FOR HANDLE)	TATA spare parts
268081106350	REFLECTIVE TAPE CENTRE	TATA spare parts
268081106351	REFLECTIVE TAPE SIDE LH	TATA spare parts
268081106352	REFLECTIVE TAPE SIDE RH	TATA spare parts
268081106353	REFLECTIVE TAPE SIDE LH	TATA spare parts
268081106354	REFLECTIVE TAPE SIDE RH	TATA spare parts
268081106373	AERO CORNER LH BS6-PH2	TATA spare parts
268081106374	AERO CORNER RH BS6-PH2	TATA spare parts
268081107501	GROMMET FOR GPS CUTOUT	TATA spare parts
268081110101	FLAP ASSY CENTER-OUTER BS6	TATA spare parts
268081110150	FRONT VIEW MIRROR ASSY BS6 PH2	TATA spare parts
268081209901	TAPE BS6	TATA spare parts
268081506301	GRAB RAIL LH	TATA spare parts
268081506302	GRAB RAIL RH	TATA spare parts
268081507701	BEADING BS6-PH2	TATA spare parts
268081507702	RUBBER BEADING FRONT DOOR BS6-PH2	TATA spare parts
268081507703	RUBBER BEADING REAR COVER BS6-PH2	TATA spare parts
268081800101	ASSY MASCOT 4021 TC	TATA spare parts
268081800107	ASSY MASCOT TATA 4923C 6X4	TATA spare parts
268081800109	ASSY TATA 3518C MASCOT	TATA spare parts
268081800112	ASSY MASCOT 3118.TK	TATA spare parts
268081800114	ASSY MASCOT 2518.TK	TATA spare parts
268081800115	ASSY MASCOT 4018.S	TATA spare parts
268081800116	ASSY MASCOT 2518 K	TATA spare parts
268081800118	MASCOT ASSY	TATA spare parts
268081800119	MASCOT ASSY 3718.T	TATA spare parts
268081806301	MASCOT 4021TC	TATA spare parts
268081900114	ENGINE SHIELDING ASSY LH	TATA spare parts
268081900115	ENGINE SHIELDING ASSY RH	TATA spare parts
268081900118	ENGINE SHIELDING ASSY RH	TATA spare parts
268081900119	ENGINE SHIELDING ASSY LH	TATA spare parts
268081900123	ENGINE SHIELDING ASSY LH BS6	TATA spare parts
268081900124	ENGINE SHIELDING ASSY RH BS6	TATA spare parts
268081900125	ENGINE SHIELDING ASSY LH BS6	TATA spare parts
268081900128	ENGINE SHIELDING ASSY LH BS6	TATA spare parts
268081900129	ENGINE SHIELDING ASSY LH BS6	TATA spare parts
268081900130	ENGINE SHIELDING ASSY RH BS6	TATA spare parts
268081900131	ENGINE SHIELDING ASSY LH BS6	TATA spare parts
268081900132	ENGINE SHIELDING ASSY RH BS6	TATA spare parts
268081906301	PLUG BUTTON $\varnothing$ (DIA.20)	TATA spare parts
268081906302	PLUG GROMMET (DIA.50)	TATA spare parts
268081906303	PLUG BUTTON $\varnothing$ (DIA.25)	TATA spare parts
268081906304	PLUG GROMMET (DIA.29)	TATA spare parts
268081906305	PLUG BUTTON $\varnothing$ (DIA.12.5)	TATA spare parts
268081906306	PLUG BUTTON (DIA.12) BS6	TATA spare parts

268081906307	PLUG BUTTON $\phi$ (DIA.30)	TATA spare parts
268081906308	PLUG BUTTON $\phi$ (DIA.16)	TATA spare parts
268081906309	PLUG BUTTON (FOR SLOT 20X50) BS6	TATA spare parts
268081906310	PLUG BUTTON (FOR SLOT 30X155)	TATA spare parts
268081906311	PLUG BUTTON (FOR SLOT 45X65) BS6	TATA spare parts
268081906312	PLUG BUTTON (25X15 SLOT) BS6	TATA spare parts
268081906313	PLUG-(M6 NUT) BS6	TATA spare parts
268081906320	CROSS LINK FOAM 40X40	TATA spare parts
268081906321	CROSS LINK FOAM 40X40WITH SLIT	TATA spare parts
268081906322	CROSS LINK FOAM $\phi$ 25X25	TATA spare parts
268081906323	FOAM PACKING	TATA spare parts
268081906324	FOAM CROSS LINK	TATA spare parts
268081906325	FOAM PACKING MIDDLE	TATA spare parts
268081906326	COVER CROSS LINK FOAM RH	TATA spare parts
268081906327	COVER CROSS LINK FOAM(SPINDLE CUTOUT RH)	TATA spare parts
268081908201	COVER WIPER MOTOR	TATA spare parts
268081908202	COVER PLATE	TATA spare parts
268081908203	COVER LH	TATA spare parts
268081908206	COVER LH BS6	TATA spare parts
268082400105	KIT-ACCESSORY WIPER MOTOR BS1/3/4	TATA spare parts
268082400116	KIT-WIPER ACCESSORIES BS3/4/6	TATA spare parts
268082400117	LINK ASSY DRIVER SIDE	TATA spare parts
268082400118	LINK ASSY CO-DRIVER SIDE	TATA spare parts
268082400119	SPINDLE UNIT ASSY DRIVER SIDE BS6	TATA spare parts
268082400120	ASSY.WIPER MOTOR BS3/4/6	TATA spare parts
268082400121	WIPER MOTOR BS6-PH2	TATA spare parts
268082400122	SPINDLE UNIT ASSY CO-DRIVER SIDE BS6	TATA spare parts
268082400135	KIT-FRONT WIPER SYSTEM BS6	TATA spare parts
268082403302	BRACKET WIPER MOTOR MTG	TATA spare parts
268082406301	TAPER WASHER	TATA spare parts
268082409901	GEAR BOX BRUSH PLATE & ARMATURE ASSEMBLY	TATA spare parts
268082409902	ROTARY LINK ASSEMBLY	TATA spare parts
268082900101	KIT-WASHER SYSTEM BS3/4/6	TATA spare parts
268082900107	NOZZLE ASSY BS6-PH2	TATA spare parts
268083100102	KIT FOR AC UNIT LPK2516TC CAB	TATA spare parts
268083100104	CONDENSOR CORE W/ BRACKET	TATA spare parts
268083100108	ASSY.TUBE LIQUID (GLOVE BOX)	TATA spare parts
268083100110	TUBE SUCTION-C/U OUT	TATA spare parts
268083100114	HOSE SUCTION	TATA spare parts
268083100115	HOSE DISCHARGE	TATA spare parts
268083100119	ASSY.BRACKET CONDENSER MTG.-LH	TATA spare parts
268083100120	ASSY.BRACKET CONDENSER MTG.-RH	TATA spare parts
268083100129	ASSY.CONDENSER FAN W/MOTOR	TATA spare parts
268083100134	ASSY. BRACKET (COIL HSG.) INNER	TATA spare parts
268083100135	ASSY. BRACKET (COIL HSG) OUTER	TATA spare parts
268083100136	RESISTOR BLOWER	TATA spare parts
268083100146	CONDENSOR ASSY	TATA spare parts

268083106302	GROMMET (DRAIN HOSE)	TATA spare parts
268083200101	CLOSING PLATE ASSY	TATA spare parts
268083400101	EVAPORATOR SUB ASSY	TATA spare parts
268083400106	AC CONDENSER KIT 24 V	TATA spare parts
268083406301	CASE COOLING UNIT UPPER	TATA spare parts
268083406302	CASE COOLING UNIT LOWER	TATA spare parts
268083505801	RUBBER HOSE [ID 17 X L1000]	TATA spare parts
268083505802	RUBBER HOSE [ID 17 X L 80 ]	TATA spare parts
268083505803	RUBBER HOSE [ID 17 X L 1500]	TATA spare parts
268083800101	ASSY.VENTILLATION GRILLE	TATA spare parts
268083800102	ASSY.VENT.GRILL COMPLETE	TATA spare parts
268084100102	HEADBOX ASSY BS6	TATA spare parts
268084100110	BRACKET ASSY SPEAKER HEADBOX LH BS6	TATA spare parts
268084100111	BRACKET ASSY SPEAKER HEADBOX RH BS6	TATA spare parts
268084100112	HANDLE ASSY LID HEAD BOX OUTER BS6	TATA spare parts
268084103303	BRACKET HEADBOX MTG LH BS6	TATA spare parts
268084103304	BRACKET HEADBOX MTG RH BS6	TATA spare parts
268084106309	HEADBOX INNER BS6	TATA spare parts
268084106310	HEADBOX OUTER BS6	TATA spare parts
268084106311	GRILL SPEAKER HEADBOX LH BS6	TATA spare parts
268084106312	GRILL SPEAKER HEADBOX RH BS6	TATA spare parts
268084106319	LID HEADBOX OUTER-LH BS6	TATA spare parts
268084106320	LID HEADBOX OUTER-RH BS6	TATA spare parts
268086900102	ASSY BRACKET LH-RHD (W/S WASHER)	TATA spare parts
268088100102	ASSY LOWER FOOT STEP SUPPORT LH	TATA spare parts
268088100103	ASSY LOWER FOOT STEP SUPPORT RH	TATA spare parts
268088100105	ASSY. PIPE MIDDLE FRAME SUPPORT BS3/4/6	TATA spare parts
268088100106	ASSY PIPE MIDDLE FRAME SIDE SUPPORT LH	TATA spare parts
268088100107	ASSY PIPE MIDDLE FRAME SIDE SUPPORT RH	TATA spare parts
268088100115	ASSY FOOT STEP MTG FRAME FENDER LH	TATA spare parts
268088100116	FENDER FRONT LH BS3/4/6	TATA spare parts
268088100117	FENDER FRONT RH BS3/4/6	TATA spare parts
268088100118	ASSY FRONT STEP LH	TATA spare parts
268088100119	ASSY FRONT STEP RH	TATA spare parts
268088100120	ASSY FOOT STEP MTG FRAME FENDER RH	TATA spare parts
268088100121	ASSY BRACKET CORNER FRONT FENDER MTG LH	TATA spare parts
268088100122	ASSY BRACKET CORNER FRONT FENDER MTG RH	TATA spare parts
268088103301	BRACKET ADDON FENDER MTG FRONT LH	TATA spare parts
268088103302	BRACKET ADDON FENDER MTG MIDDLE LH	TATA spare parts
268088103303	BRACKET ADDON FENDER MTG REAR LH	TATA spare parts
268088103310	BRACKET FENDER MTG FRONT LOWER LH	TATA spare parts
268088103311	BRACKET ADDON FENDER MTG FRONT RH	TATA spare parts
268088103312	BRACKET ADDON FENDER MTG MIDDLE RH	TATA spare parts
268088103313	BRACKET ADDON FENDER MTG REAR RH	TATA spare parts
268088103322	BRACKET FENDER MTG FRONT LOWER RH	TATA spare parts
268088103344	BRACKET ADD ON FENDER MTG REAR-LH BS6-PH	TATA spare parts
268088103345	BRACKET ADD ON FENDER MTG REAR-RH BS6-PH	TATA spare parts

268088106303	MUDGUARD FRONT L H	TATA spare parts
268088106304	MUDGUARD FRONT R H	TATA spare parts
268088106305	MUDFLAP REAR	TATA spare parts
268088106310	FRONT FENDER CAP	TATA spare parts
268088106311	MUDGUARD FRONT LH	TATA spare parts
268088106312	MUDGUARD FRONT RH	TATA spare parts
268088106313	MUDFLAP REAR-RH	TATA spare parts
268088106314	MUDGUARD FRONT-LH	TATA spare parts
268088106315	MUDGUARD FRONT-RH	TATA spare parts
268088106912	MUDGUARD SUPPORT LH	TATA spare parts
268088106913	MUDGUARD SUPPORT RH	TATA spare parts
268088108201	FOOT STEP UPPER	TATA spare parts
268088108202	FOOT STEP MIDDLE	TATA spare parts
268088108221	BRACKET FENDER MTG BOTTOM-LH BS6-PH2	TATA spare parts
268088108222	BRACKET FENDER MTG BOTTOM-RH BS6-PH2	TATA spare parts
268088200101	ASSY. BODY SIDE ADD ON LH BS3/4/6	TATA spare parts
268088200102	ASSY. BODY SIDE ADD ON RH BS3/4/6	TATA spare parts
268088200103	ASSY. REAR FENDER LH BS3/4/6	TATA spare parts
268088200104	ASSY. REAR FENDER RH BS3/4/6	TATA spare parts
268088200109	ADD ON ASSY BODY SIDE LH BS6 PH2	TATA spare parts
268088206305	MUDFLAP REAR LH(SPRAY SPPRESION)	TATA spare parts
268088206306	MUDFLAP REAR RH(SPRAY SUPPRESION)	TATA spare parts
268088206309	"EXTENSION,MUDGUARD,REAR-LH BS6"	TATA spare parts
268088500101	BUMPER ASSY COMPLETE	TATA spare parts
268088500107	ASSY.SUPPORT FRONT LH(STYLISED BUMPER)	TATA spare parts
268088500120	ASSY.BUMPER LAMINATED WITH MTG.BRKTS	TATA spare parts
268088500121	FOOT STEP ASSY BUMPER MTG	TATA spare parts
268088500125	ASSY BUMPER COMP	TATA spare parts
268088500125C0	ASSY. BUMPER W/ REFLECT. BLACK BS1/2/3/4	TATA spare parts
268088500131	ASSY. BUMPER ADD-ON MIDDLE BS3/4	TATA spare parts
268088500132	ASSY BUMPER MIDDLE	TATA spare parts
268088500133	ASSY BUMPER LH	TATA spare parts
268088500134	ASSY BUMPER RH	TATA spare parts
268088500135	ASSY. BUMPER MIDDLE WELDED BS3/4	TATA spare parts
268088500139	ASSY BUMPER SIDE MTG LH	TATA spare parts
268088500140	ASSY BUMPER SIDE MTG RH	TATA spare parts
268088500141	ASSY OUTRIGGER CHASSIS SIDE LH	TATA spare parts
268088500142	ASSY OUTRIGGER CHASSIS SIDE RH	TATA spare parts
268088500143	ASSY BKT ADD-ON MTG LH (SIDE MTG)	TATA spare parts
268088500145	ASSY FOOT STEP (BUMPER TOP)	TATA spare parts
268088500146	ASSY FOOT STEP (BUMPER)	TATA spare parts
268088500147	ASSY BRACKET BUMPER MTG-FRONT LH	TATA spare parts
268088500148	ASSY BRACKET BUMPER MTG-FRONT RH	TATA spare parts
268088500149	ASSY BRACKET BUMPER ADD-ON MTG FRONT LH	TATA spare parts
268088500150	ASSY BRACKET BUMPER ADD-ON MTG FRONT RH	TATA spare parts
268088500153	ASSY BKT ADD ON MTG RH (SIDE MTG)	TATA spare parts
268088500160	ASSYBRACKETBUMPERGRILLMTG BS6	TATA spare parts

268088500162	ASSY. BUMPER WELDED LH BS3/4/6	TATA spare parts
268088500163	ASSY. BUMPER WELDED RH BS3/4/6	TATA spare parts
268088500167	ASSY. BUMPER ADD ON LH BS3/4	TATA spare parts
268088500168	ASSY. BUMPER ADD ON RH BS3/4	TATA spare parts
268088500183	BRACKET ASSY FRONT BUMPER LH	TATA spare parts
268088500184	BRACKET ASSY FRONT BUMPER RH	TATA spare parts
268088500185	OUTRIGGER ASSY CHASSIS SIDE LH	TATA spare parts
268088500186	OUTRIGGER ASSY CHASSIS SIDE RH	TATA spare parts
268088500201	BUMBER ASSY CENTER	TATA spare parts
268088500204	BUMBER ASSY BS6	TATA spare parts
268088500212	BRACKET ASSY BUMPER SUPPORT LH BS6	TATA spare parts
268088500213	BRACKET ASSY BUMPER SUPPORT RH BS6	TATA spare parts
268088500214	OUTRIGGER ASSY CHASSIS SIDE LH BS6	TATA spare parts
268088500215	OUTRIGGER ASSY CHASSIS SIDE RH BS6	TATA spare parts
268088503314	HEAD LAMP MTG BKT LH	TATA spare parts
268088503315	HEAD LAMP MTG BKT RH	TATA spare parts
268088503338	MOUNTING BRACKET LH	TATA spare parts
268088503339	MOUNTING BRACKET RH	TATA spare parts
268088503396	FOOT STEP BUMPER BS6	TATA spare parts
268088504301	METAL CLIP FOR GRILL	TATA spare parts
268088506307	BUMPER GRILL (FACELIFT)	TATA spare parts
268088506308	CAP FOR FOG LAMP CUTOFF	TATA spare parts
268088506314	END COVER BUMPER LH BS6	TATA spare parts
268088506315	END COVER BUMPER RH BS6	TATA spare parts
268088508236	BUMPERMIDLETOP BS6	TATA spare parts
268088508239	BUMPERMIDDLE BS6	TATA spare parts
268088510131	BUMPER ASSY	TATA spare parts
268088510136	BRACKET ASSY SIDE BUMPER MTG LH BS6	TATA spare parts
268088510137	BRACKET ASSY SIDE BUMPER MTG RH BS6	TATA spare parts
268088510138	BRACKET ASSY BUMPER MTG UPPER-LH BS6	TATA spare parts
268088510139	BRACKET ASSY SIDE BUMPER MTG RH BS6	TATA spare parts
268088700102	ENGINE HOOD INSULATION ASSY BS6	TATA spare parts
268088700103	ASSY. ENGINE HOOD COMPLETE RHD BS3/4	TATA spare parts
268089100103	CABIN BKT BS1/3	TATA spare parts
268089100104	ASSY BKT FRONT BOTTOM LH PIVOT MTG	TATA spare parts
268089100107	FRONT DAMPER BS1/3/4/6	TATA spare parts
268089100112	ASSY. PIVOT RUBBER BUSH LH BS1/3/4/6	TATA spare parts
268089100113	ASSY. PIVOT RUBBER BUSH RH BS1/3/4/6	TATA spare parts
268089100114	ASSY. PIVOT.BRKT LH (CAB MTG.FRT) BS3/4	TATA spare parts
268089100115	ASSY BKT FRONT BOTTOM LH PIVOT MTG	TATA spare parts
268089100117	BRACKET ASSY PIVOT MTG FRONT BOTTOM-LH	TATA spare parts
268089100118	ASSY. BKT. PIVOT MTG FRT BOTTOM-LH BS3/4	TATA spare parts
268089100119	BRACKET ASSY PIVOT MTG BOTTOM FRONT-LH	TATA spare parts
268089100120	BRACKET ASSY PIVOT MTG FRONT TOP-LH	TATA spare parts
268089100122	MOUNTING BRACKET ASSY REAR BS6	TATA spare parts
268089100125	MOUNTING BRACKET ASSY FRONT BS6	TATA spare parts
268089100126	MOUNTING BRACKET ASSY REAR-LH BS6	TATA spare parts

268089100127	MOUNTING BRACKET ASSY REAR-RH BS6	TATA spare parts
268089100131	PIVOT ARM ASSY CAB MTG FRONT-LH BS6	TATA spare parts
268089100132	PIVOT ARM ASSY CAB MTG FRONT-RH BS6	TATA spare parts
268089100133	MOUNTING BRACKET ASSY FRONT BS6	TATA spare parts
268089100134	MOUNTING BRACKET ASSY FRONT-LH BS6	TATA spare parts
268089100136	CATCHER ASSY LH BS6	TATA spare parts
268089100138	PIVOT ARM ASSY CAB MTG FRONT-RH BS6	TATA spare parts
268089100139	REAR STRUT ASSY BS6	TATA spare parts
268089100140	RUBBER MOUNT ASSY BS6	TATA spare parts
268089100141	PIVOT ARM ASSY CAB MTG FRONT-LH BS6	TATA spare parts
268089100142	PIVOT ARM ASSY CAB MTG FRONT-RH BS6	TATA spare parts
268089103701	PIVOT MTG BKT UPPER LH (CAB FRONT MTG)	TATA spare parts
268089103702	PIVOT MTG BKT UPPER RH (CAB FRONT MTG)	TATA spare parts
268089106701	HEX BOLT(M16) CAB FRONT MOUNTING	TATA spare parts
268089106702	HEX BOLT(M16) CAB FRONT MTG. BS1/3/4/6	TATA spare parts
268089107702	PACKING COWL MTG REAR BS6	TATA spare parts
268089107703	PACKING COWL MTG FRONT BS6	TATA spare parts
268089108275	BRACKET CAB MTG FRONT BS6	TATA spare parts
268089110101	PIPE ASSY CROSS MEMBER REAR	TATA spare parts
268089200101	ASSY SUSPENSION BUSH(CAB MTG.FRONT)	TATA spare parts
268089200102	ASSY.MTG.BRKT.FRONT UPPER INNER	TATA spare parts
268089200103	MOUNTING BRACKET ASSY REAR-LH	TATA spare parts
268089200104	MOUNTING BRACKET ASSY REAR-RH	TATA spare parts
268089200105	ASSY. MTG. BRACKET REAR STRUT LH BS1/3	TATA spare parts
268089200106	ASSY. MTG. BRACKET REAR STRUT RH BS1/3	TATA spare parts
268089200109	ASSY. DAMPER MTG. BKT. LH	TATA spare parts
268089200110	ASSY.TIE MEMBER MTG. BKT.LH	TATA spare parts
268089200111	ASSY. TIE MEMBER MTG. BKT RH	TATA spare parts
268089200112	ASSY.DAMPER MTG. BKT. RH	TATA spare parts
268089200113	MOUNTING BRACKET ASSY REAR-LH	TATA spare parts
268089200114	MOUNTING BRACKET ASSY REAR-RH	TATA spare parts
268089200117	MOUNTING BRACKET ASSY REAR-LH	TATA spare parts
268089200118	MOUNTING BRACKET ASSY REAR-RH	TATA spare parts
268089200119	BRACKET ASSY CAB MTG BOTTOM REAR-LH	TATA spare parts
268089200120	RUBBER BUSH (ROLL STOPPER) BS1/3	TATA spare parts
268089200124	ASSY. DAMPER MTG. BKT. LH	TATA spare parts
268089200125	ASSY.DAMPER MTG. BKT. RH	TATA spare parts
268089200128	ASSY. MTG.BRACKET REAR LH BS3/4	TATA spare parts
268089200129	ASSY. MTG.BRACKET REAR RH BS3/4	TATA spare parts
268089200130	ASSY MTG.BRACKET REAR LH	TATA spare parts
268089200131	ASSY MTG.BRACKET REAR RH	TATA spare parts
268089200134	BRACKET ASSY CAB MTG BOTTOM REAR-RH	TATA spare parts
268089200135	BRACKET ASSY DAMPER MTG REAR-LH	TATA spare parts
268089200137	BRACKET ASSY DAMPER MTG REAR-RH	TATA spare parts
268089200140	BRACKET ASSY CAB MTG CHASSIS SIDE LH BS6	TATA spare parts
268089200141	BRACKET ASSY CAB MTG CHASSIS SIDE RH BS6	TATA spare parts
268089200142	BRACKET ASSY CAB MTG REAR BS6	TATA spare parts



268089200143	BRACKET ASSY BOTTOM-LH BS6	TATA spare parts
268089200144	BRACKET ASSY BOTTOM-RH BS6	TATA spare parts
268089203701	MOUNTING BRACKET(FRONT UPPER INNER)	TATA spare parts
268089206701	SUSPENSION PIN(CAB MTG.FRONT)	TATA spare parts
268089206904	SLEEVE (TIE MEMBER MTG)	TATA spare parts
268089207102	CAB REAR SUSPENSION LEAF SPRING BS6	TATA spare parts
268089208211	TIE MEMBER REAR	TATA spare parts
268089208601	SPACER BS6	TATA spare parts
268091000107	ASSY. DRIVER SEAT BS3/4/6	TATA spare parts
268091000108	DRIVER SEAT ASSY BS6	TATA spare parts
268091000109	DRIVER SEAT ASSY BS6	TATA spare parts
268091000110	ASSY DR.SEAT COMP RH WITH NANO FABRIC (L	TATA spare parts
268091000111	CO-DRIVER SEAT WITH HEAD REST	TATA spare parts
268091000112	ASSY TOP BERTH COMPLETE	TATA spare parts
268091000115	ASSY CO-DRIVER SEAT WITH GLOVEBOX	TATA spare parts
268091000117	ASSY CODRIVER SEAT WITH GLOVEBOX	TATA spare parts
268091000121	ASSY CUSHION FOAM COMPLETE	TATA spare parts
268091000122	ASSY TRIM COMP FOR FSC(FOAM NANO FABRIC)	TATA spare parts
268091000123	ASSY TRIM COMP FOR FSB(FOAM NANO FABRIC)	TATA spare parts
268091000124	RING HOG	TATA spare parts
268091000125	SUPPORT PLATE	TATA spare parts
268091000126	FOAM ASSY FSB BACK FOAM COMPLETE	TATA spare parts
268091000129	DRIVER SEAT ASSY BS6	TATA spare parts
268091000135	DRIVER SEAT ASSY BS6	TATA spare parts
268091000150	DRIVER SEAT ASSY	TATA spare parts
268091000153	DRIVER SEAT ASSY BS6-PH2	TATA spare parts
268091000154	DRIVER SEAT ASSY BS6-PH2	TATA spare parts
268091000156	DRIVER SEAT ASSY BS6-PH2	TATA spare parts
268091000162	DRIVER SEAT ASSY BS6-PH2	TATA spare parts
268091000174	KIT TRACK COVER ASSEMBLY BS6-PH2	TATA spare parts
268091000176	KIT ASSEMBLY PLASTIC HANDLE AND GUIDE SC	TATA spare parts
268091000192	KIT SUSPENSION ASSEMBLY BS6-PH2	TATA spare parts
268091000196	KIT ASSEMBLY PLASTIC RECLINER COVER AND	TATA spare parts
268091000197	KIT ASSEMBLY RISER AND WELD NUT BS6-PH2	TATA spare parts
268091008001	SCREW SELF TAPPING M5X10	TATA spare parts
268091500101	ASSY SEAT BELTS COMP	TATA spare parts
268091500102	SEAT BELT ASSY WITH ELR FRONT-RH BS6	TATA spare parts
268091500103	CABLE BUCKLE ASSY DRIVER SEAT BS6	TATA spare parts
268091500104	ASSY. SEAT BELT COMPLETE DRIVER	TATA spare parts
268094000101	ASSY CO-DRIVER SEAT	TATA spare parts
268094000105	CO-DRIVER SEAT ASSY BS6	TATA spare parts
268094000109	CO-DRIVER SEAT ASSY	TATA spare parts
268094000125	CO-DRIVER SEAT ASSY BS6-PH2	TATA spare parts
268097500107	KIT-SEAT BELT WITH ELR FRONT BS6	TATA spare parts
268097500114	KIT-SEAT BELT WITH ELR FRONT	TATA spare parts
268097500127	SEAT BELT ASSY WITH ELR FRONT-LH BS6-PH2	TATA spare parts
268097500128	SEAT BELT ASSY WITH ELR FRONT-RH BS6-PH2	TATA spare parts

268097500129	STEM BUCKLE ASSY FRONT BS6-PH2	TATA spare parts
268098400101	TEMPORARY STRUCTURE ASSY WITH CANOPY BS6	TATA spare parts
268098410101	BERTH STRUCTURE ASSY LOWER-LH BS6-PH2	TATA spare parts
268098410102	ASSY TOP BERTH COMPLETE	TATA spare parts
268098410105	ASSY BOTTOM BERTH COMPLETE	TATA spare parts
268098410107	CUSHION ASSY BERTH LOWER-LH BS6-PH2	TATA spare parts
268098410108	BERTH ASSY LOWER-LH BS6-PH2	TATA spare parts
268098410109	BERTH STRUCTURE ASSY LOWER-MIDDLE BS6-PH	TATA spare parts
268098410110	CUSHION ASSY BERTH LOWER-MIDDLE BS6-PH2	TATA spare parts
268098410111	BERTH ASSY LOWER-MIDDLE	TATA spare parts
268098410116	BERTH STRUCTURE ASSY LOWER-RH BS6-PH2	TATA spare parts
268098410117	CUSHION ASSY BERTH LOWER-RH BS6-PH2	TATA spare parts
268098410119	BERTH ASSY LOWER-RH BS6-PH2	TATA spare parts
268098410121	COVER LOWER BERTH CENTER BS6-PH2	TATA spare parts
268098410123	COVER ASSY LOWER BERTH CENTER BS6-PH2	TATA spare parts
268098410125	NUT PLATE ASSY BERTH STRAP MTG BS6-PH2	TATA spare parts
268098410131	STAY ROD LOWER BERTH BS6-PH2	TATA spare parts
268098410138	MATTRESS ASSY BERTH ENGINE HOOD BS6	TATA spare parts
268098410143	BERTH ASSY LOWER-MIDDLE BS6	TATA spare parts
268098410148	MATTRESS ASSY BERTH ENGINE HOOD BS6-PH2	TATA spare parts
268098410150	NUT PLATE ASSY BOTTOM BERTH BS6-PH2	TATA spare parts
268098410151	HINGE ASSY LOWER BERTH BS6-PH2	TATA spare parts
268098410152	BRACKET ASSY BS6-PH2	TATA spare parts
268098410153	HINGE ASSY LOWER BERTH BS6-PH2	TATA spare parts
268098410154	BERTH ASSY LOWER BS6-PH2	TATA spare parts
268098413301	BRACKET TOGGLE CLAMP MTG BS6-PH2	TATA spare parts
268098413401	BUSH HINGE BS6-PH2	TATA spare parts
268098413501	SCREW BS6-PH2	TATA spare parts
268098416707	HINGE PIN BS6-PH2	TATA spare parts
268098418222	HINGE LEAF BERTH SIDE BOTTOM BS6-PH2	TATA spare parts
268098418224	HINGE LEAF BERTH SIDE TOP BS6-PH2	TATA spare parts
268098707702	COVER	TATA spare parts
268098900101	FRAME ASSY FRONT BS6	TATA spare parts
268098900111	ANGLE STRUCTURE ASSY BS6	TATA spare parts
268098907701	BALLATA PACKING BS6-PH2	TATA spare parts
268098908203	ANGLE CANOPY SUPPORT BS6	TATA spare parts
268098908206	BRACKET CANOPY MTG BS6	TATA spare parts
268098908211	L-BRACKET BS6	TATA spare parts
268098908212	ANGLE CANOPY MTG BS6-PH2	TATA spare parts
268098908213	ANGLE CANOPY MTG BS6	TATA spare parts
268099506301	SCRIVET LINER BS6	TATA spare parts
268099506303	SCRIVET LINER	TATA spare parts
268128000101	AUX GEAR BOX ASSY 407	TATA spare parts
268128000104	ASSY.TRANSFERCASE COMP. BS6	TATA spare parts
268128100103	ASSY TRANSFER HOUSING 407 4X4	TATA spare parts
268128100104	HOUSING & COVER ASSY TRANSFER CASE BS6	TATA spare parts
268128103703	TRANSFERCASE HOUSING	TATA spare parts

268128103705	TRANSFER CASE COVER BS6	TATA spare parts
268128105301	GASKET TRANSFER CASE HSG	TATA spare parts
268128106701	PIN MTG	TATA spare parts
268128109902	ADAPTER BS6	TATA spare parts
268128200101	DRIVE SHAFT ASSY BS6	TATA spare parts
268128200102	HELICAL GEAR ASSY BS6	TATA spare parts
268128200103	ASSY COUPLING FLANGE (DUST COVER-PRESS F	TATA spare parts
268128205401	HELICAL GR AUX GR BOX	TATA spare parts
268128207901	DRIVE SHAFT AUX GR BOX	TATA spare parts
268128207903	DRIVE SHAFT-MODIFIED	TATA spare parts
268128208601	SPACER INPUT SHAFT	TATA spare parts
268128208602	SPACER	TATA spare parts
268128208604	SPACER FOR MODI. SHAFT	TATA spare parts
268128300101	OUTPUT SHAFT ASSY GEARED BS6	TATA spare parts
268128300102	COVER ASSY REAR-TOP BS6	TATA spare parts
268128300103	OUTPUT SHAFT AGB 407 4X4	TATA spare parts
268128303102	SRDG BALL BEARING	TATA spare parts
268128303103	SRDG BALL BEARING	TATA spare parts
268128303104	SRDG BALL BEARING	TATA spare parts
268128303701	REAR COVER TOP	TATA spare parts
268128303702	REAR COVER BOTTOM	TATA spare parts
268128303802	REAR COVER TOP	TATA spare parts
268128304601	SHIFTER SLEEVE	TATA spare parts
268128305301	GASKET REAR COVER	TATA spare parts
268128305302	GASKET REAR COVER BOTTOM	TATA spare parts
268128305401	OUTPUT GEAR AGB 407 4X4	TATA spare parts
268128307801	OIL SEAL	TATA spare parts
268128307802	OIL SEAL	TATA spare parts
268128307803	OIL SEAL	TATA spare parts
268128307901	OUT PUT SHAFT REAR	TATA spare parts
268128307902	OUT PUT SHAFT-FRONT AXLE	TATA spare parts
268128308601	SPACER	TATA spare parts
268128308602	SPACER	TATA spare parts
268128308603	SPACER	TATA spare parts
268128313102	BALL BRG	TATA spare parts
268128350101	INTERMEDIATE SHAFT ASSY BS6	TATA spare parts
268128355401	DOUBLE GEAR	TATA spare parts
268128356101	LOCKING PLATE	TATA spare parts
268128356501	HEX NUT	TATA spare parts
268128357701	O RING	TATA spare parts
268128357702	O RING	TATA spare parts
268128357901	SHAFT DOUBLE GEAR 407 4X4	TATA spare parts
268128358302	SHIM 0.1 MM THK	TATA spare parts
268128358303	SHIM 0.15 MM THK.	TATA spare parts
268128358304	SHIM 0.20THK	TATA spare parts
268128358601	SPACER	TATA spare parts
268128358607	SPACER	TATA spare parts

268128358608	SPACER	TATA spare parts
268128404701	COVER FRONT	TATA spare parts
268128405101	SHIFTER FORK UPPER	TATA spare parts
268128405102	SHIFTER FORK BOTTOM	TATA spare parts
268128405301	GASKET	TATA spare parts
268128406701	BEARING PIN	TATA spare parts
268128407701	SLEEVE SHIFTER SHAFT	TATA spare parts
268128407901	SHIFTER SHAFT	TATA spare parts
268128407902	GUIDE SHAFT	TATA spare parts
268128407903	SHIFTER SHAFT BS6	TATA spare parts
268128800101	AUXILIARY GB FOR SFC407 4X4 BSVI VEHICLE	TATA spare parts
268135108301	SHIM ADJ	TATA spare parts
268226253102	THRUST BEARING DRIVE SHAFT	TATA spare parts
268226258601	SPACER TH BRG 4.00 MM	TATA spare parts
268226258602	SPACER TH BRG 4.41 MM	TATA spare parts
268226258603	SPACER TH BRG 4.20 MM	TATA spare parts
268226258604	SPACER TH BRG 4.30 MM	TATA spare parts
268226258605	SPACER TH BRG 4.40 MM	TATA spare parts
268226258606	SPACER TH BRG 4.50 MM	TATA spare parts
268226258607	SPACER TH BRG 4.60 MM	TATA spare parts
268226258608	SPACER TH BRG 4.70 MM	TATA spare parts
268226258609	SPACER TH BRG 4.80 MM	TATA spare parts
268226258610	SPACER TH BRG 4.90 MM	TATA spare parts
268226258611	SPACER TH BRG 5.00 MM	TATA spare parts
268226258612	SPACER TH BRG 5.10 MM	TATA spare parts
268226258701	COMPRESSION SPRING	TATA spare parts
268426010101	GEAR BOX G76 3.87 TS RH	TATA spare parts
268426010109	ASSY G76-5/3.86 G.BOX COMPL.(SUMO-4X4)	TATA spare parts
268426010111	GEAR BOX G76 3.87 4X4 LHD	TATA spare parts
268426010190	ASSY G76 (4.1 RATIO)COMP.W/ADAPTOR PLATE	TATA spare parts
268426010191	ASSY G76(4.1) DI SH TATA AZADI W/O ADOPT	TATA spare parts
268426010198	ASSY G-76 G.BOX COMP SAFARI 4DL 4X4	TATA spare parts
268426010279	ASSYG-76 COMP TELCOLINE FACELIFT 4X2 4DL	TATA spare parts
268426010296	ASSY G76 TM/CC 4DL 4X4 BUCKET SEAT.	TATA spare parts
268426010352	ASSY G-76 T-MOBILE F/L 4PL 4X2 4.1 RAT	TATA spare parts
268426010355	ASSY G-76/4.1 207DI WITH ADAPTOR PLATE	TATA spare parts
268426010356	ASSY G76-5/4.1 COMP.WITH G.S.LINKAGE	TATA spare parts
268426010356YA	YELLOW AGGR FOR ASSY G76-5/4.1 COMPL	TATA spare parts
268426010364	ASSY G76-5/4 1 W/ADPT PLATE207DI	TATA spare parts
268426010395	ASSYG76-5/3.87 W/ADPT.PLATE SPACIO GOLD+	TATA spare parts
268426010397	ASSY G-76 TELCOLINE F/L 4DLTC 4X2 BU NVH	TATA spare parts
268426010399	ASSY G-76 TELCOLINE F/L 4DLTC 4X4 BU NVH	TATA spare parts
268426020107	ASSY G76/4.1 TELCOLINEF/L 4DL 4X2 BU NVH	TATA spare parts
268426020109	ASSY G76/4.1 TELCOLINEF/L 4DL 4X4 BU NVH	TATA spare parts
268426020111	ASSY G76/4.1 TELCOLINE 2.2L DICR 4X2	TATA spare parts
268426020113	ASSY G76/4.1 TELCOLINE 2.2L DICR 4X4 BU	TATA spare parts
268426020117	GEAR BOX G76/4.1 TELCOLINE W/T-CASE BU N	TATA spare parts

268426020135	ASSY G76-5/4.1 SPRINT 3LDICOR 4X4 BU NVH	TATA spare parts
268426020136	ASSY G76-5/4.1 SPRINT 3LDICOR 4X2 BU NVH	TATA spare parts
268426020158	ASSY GEAR BOX-76/4.1 207DI WITH ADA PL	TATA spare parts
268426020198	ASSY G76/4.1 XENON THAILAND 2.2L DICOR	TATA spare parts
268426020201	ASSY G76/4.1XENON THAILAND 2.2L DIR 4X4	TATA spare parts
268426020201AE	GEAR BOX ASSY XEN DC XEN SC	TATA spare parts
268426020205	ASSY G76 SPRINT 3L DICR 4X2 BU W/ADPT.PL	TATA spare parts
268426020206	ASSY G76-5/4.1 SPRINT 3LDICOR 4X2 BU NVH	TATA spare parts
268426020207	GEAR BOX G76 XENON 3L DICR 4X4 BU W/T-CA	TATA spare parts
268426020208	ASSY G76-5/4.1 SPRINT 3LDICOR 4X4 BU NVH	TATA spare parts
268426020211	ASSY G76/4.1 XENON TURKEY 2.2L DICR 4X2	TATA spare parts
268426020212	ASSY G76/4.1 XENON TURKEY W/T-CASE 2.2L	TATA spare parts
268426020236	GEAR BOX G76/4.1 XENON CNG 4X2 BU NVH	TATA spare parts
268426020251	ASSY G76/4.1 XENON 2.2L DICOR 4X2	TATA spare parts
268426020252	ASSY. GEAR BOX G76/4.1 4X4 EURO2/4	TATA spare parts
268426020253	ASSY G76/4.1 XENON 2.2L DICOR 4X4 BU	TATA spare parts
268426020272	ASSY G76 207DI BSIV 3L DICOR 4X2 BU SEAT	TATA spare parts
268426020276	ASSY G76-5/4.1 SAFARI 4X2 2.2L BS-IV	TATA spare parts
268426020277	ASSY G76-5/4.1 XENON MARKII 4X2 2.2L DI	TATA spare parts
268426020278	ASSY G76-5/4.1 XENON 4X4 2.2L DICOR MAR	TATA spare parts
268426020279	ASSY G76-5/4.1 XENON 4X4 2.2L DICOR MARK	TATA spare parts
268426020280	ASSY G76-5/4.1 XENON 3L DICOR 4X2	TATA spare parts
268426020281	ASSY G76 XENON 3L DICR 4X2 BU W/ADPT.PLN	TATA spare parts
268426020290	ASSY G76/4.1 XENON TURKEY 2.2L DICR 4X2	TATA spare parts
268426020294	ASSY. G76-5/4.1 XENON CNG 4X2 MK-II	TATA spare parts
268426020295	GEAR BOX XENON MK-II 3LDICR 4X2 BU W/ADP	TATA spare parts
268426020297	GEAR BOX G76-5/4.1 XENON 3LDICOR 4X4 BU	TATA spare parts
268426020314	ASSY G76 SUMO VICTA, BS-IV,3L DICOR,4X2,	TATA spare parts
268426020322	GEAR BOX G76-5/41 XENON CNG 4X2	TATA spare parts
268426020326	ASSY G76-5/4.1 W/ADPT 207DI (EGYPT)	TATA spare parts
268426020328	GEAR BOX G76-5/4.1 207DI WITH ADA PL AIS	TATA spare parts
268426020329	G-76-5/4.1 ASSY XENON CNG 4X2 (LARGER	TATA spare parts
268426020331	ASSY G76-5/4.1 XENON RX WITH ADA PL	TATA spare parts
268426020337	ASSY G-76 KIT FOR XENON CNG (GEAR SHIFT	TATA spare parts
268426020338	ASSY G-76 KIT FOR XENON CNG (WIDER THRU	TATA spare parts
268426020339	ASSY G-76 KIT FOR XENON 2.2L 4X2 (GEAR S	TATA spare parts
268426020341	ASSY G-76/4.1 207DI WITH ADA	TATA spare parts
268426020350	GEAR BOX G76/4.1 TELCOLINEF/L 4DL 4X2 BU	TATA spare parts
268426020351	ASSY. G76-5/4.1 XENON CNG 4X2 MK-II (0.	TATA spare parts
268426020377	ASSY. GEAR BOX G76/5/4.1 W/ADA PL BS1-3	TATA spare parts
268426020387	GEAR BOX G76-5/4.1 XENON 4X2	TATA spare parts
268426020390	GEAR BOX G76-5/4.1 XENON MK-II4X2 2.2L D	TATA spare parts
268426030102	GEAR BOX XENON RX 4X2 3L 0.82OD W/ADPT P	TATA spare parts
268426030103	ASSY XENON RX,4X2,3L,0.82 OD,MK-II GUTS	TATA spare parts
268426030112	GEARBOX G76 TM/CC 4DL 4X4 BUCKET SEAT	TATA spare parts
268426030121	ASSY G76 XENON COMPACT;4X2;W/ADPT.PL	TATA spare parts
268426030126	GEAR BOX ASSY WITH LINKAGE	TATA spare parts

268426030144	GEAR BOX ASSY BS6	TATA spare parts
268426030145	GEAR BOX ASSY WITH LINKAGE BS6	TATA spare parts
268426030163	GEAR BOX ASSY BS6-PH2	TATA spare parts
268426030164	GEAR BOX ASSY BS6-PH2	TATA spare parts
268426100105	GEAR BOX HSG SUB ASSY	TATA spare parts
268426100106	GEAR BOX HSG SUB ASSY	TATA spare parts
268426100129	GEARBOX HOUSING G76	TATA spare parts
268426100133	ASSY HSG.(FRONT+REAR)4DL 4X2	TATA spare parts
268426100134	ASSY. GEAR BOX HOUSING (FRONT+REAR) 4X4	TATA spare parts
268426100137	SUB ASSY G.BOX HOUSING (FRONT & REAR)	TATA spare parts
268426100138	SUB ASSY G.BOX HOUSING (FRONT & REAR)	TATA spare parts
268426100143	ASSY HSG.(FRONT+REAR) 4X4	TATA spare parts
268426100144	ASSY HSG.(FRONT+REAR) 4X2	TATA spare parts
268426100145	SUB ASSY G.BOX HSG.(FRONT & REAR)4X4 4X2	TATA spare parts
268426103101	NEEDLE BEARING	TATA spare parts
268426103102	BEARING LINEAR	TATA spare parts
268426103103	NEEDLE BEARING	TATA spare parts
268426103401	BUSH SHIFTER SHAFT	TATA spare parts
268426103402	BUSH	TATA spare parts
268426103813	G.BOX HOUSING REAR HALF (NEW INHIBITOR)	TATA spare parts
268426103814	ADAPTOR PLATE (FOR 4SP CR DI)	TATA spare parts
268426103815	GEARBOX HSG.FRONT HALF(PLASTIC SL CYL)	TATA spare parts
268426103817	G-76 G.BOX HOUSING REAR HALF	TATA spare parts
268426105301	GASKET	TATA spare parts
268426106502	HEX FIT BOLT	TATA spare parts
268426106701	PIN (GEARBOX HOUSING JOINT)	TATA spare parts
268426108201	SEALING CUP	TATA spare parts
268426108204	CAP	TATA spare parts
268426108205	CAP (SHIFTER SHAFT)	TATA spare parts
268426108207	CAP (SELECTOR SHIFTER SHAFT) BS6-PH2	TATA spare parts
268426108802	STUD TRANSPORTATION BKT MTG	TATA spare parts
268426108803	STUD (ASSY G.BOX HSG.FRONT & REAR) 4PL	TATA spare parts
268426159901	ASSY BREATAER SRICH	TATA spare parts
268426200101	SUB ASSLY FIRST SP.GR( 7 DIG.RING)GB 76	TATA spare parts
268426200102	GEAR 2ND-0196	TATA spare parts
268426200103	GEAR 3RD	TATA spare parts
268426200105	GEAR REV SPEED	TATA spare parts
268426200109	ASSLY. ENGAGING GEAR[3RD/DR.SH.]	TATA spare parts
268426200113	ASSY GEAR-SPEEDOMRTER DRIVE	TATA spare parts
268426200115	GEAR O/D-0150	TATA spare parts
268426200117	ASSY MAIN SHAFT	TATA spare parts
268426200120	END YOKE ASSY	TATA spare parts
268426200146	SUB ASSY FIRST SPEED GEAR-9 DIG	TATA spare parts
268426200147	SUB ASSY 2ND SPEED GEAR (9 DIG )	TATA spare parts
268426200148	SUB ASSY 3RD SPEED GEAR 9DG RING	TATA spare parts
268426200149	SUB ASSY REV SPEED GEAR-9 DIG	TATA spare parts
268426200150	O.D.GEAR-9 DIG	TATA spare parts

268426200151	ASSY.HELICAL GEAR (1ST SPEED) 4.1 RATIO	TATA spare parts
268426200160	ASSY.DOUBLE CONE SYNCHRO	TATA spare parts
268426200161	SUB ASSY.HELICAL GEAR (1ST SPEED) 3.87	TATA spare parts
268426200164	SUB ASSY HELICAL GEAR (2ND SPEED) 2.22	TATA spare parts
268426200165	ASSY ENGAGING GEAR (1ST/2ND SPEED)	TATA spare parts
268426200190	ASSY REAR COVER	TATA spare parts
268426200193	ASSY ENGAGING GEAR (3/4TH SPEED)	TATA spare parts
268426200194	ASSY ENGAGING GEAR (REV/OD SPEED)	TATA spare parts
268426200195	GEAR 1ST SPEED-9DEG	TATA spare parts
268426200196	ASSY 2ND GEAR NON SAF 9 DIG RING	TATA spare parts
268426200197	SUB ASSY HELICAL GEAR O. D.	TATA spare parts
268426200207	ASSY OVER DRIVE GEAR (0.73 RATIO)	TATA spare parts
268426200210	ASSY 2ND GEAR 2.22 RATIO UNEQUAL DACH	TATA spare parts
268426200212	ASSY 3RD GEAR-UNEQUAL DACH CHAMFER	TATA spare parts
268426200215	ASSY 3RD SPEED GEAR (MAIN SHAFT) EN353	TATA spare parts
268426200217	ASSY HELICAL GEAR(1ST SPEED)3 87	TATA spare parts
268426200218	ASSY HELICAL GEAR 3RD SPEED 1.37 NVH	TATA spare parts
268426200219	ASSY OVER DRIVE GEAR (0.82 RATIO)	TATA spare parts
268426200220	ASSY REVERSE GEAR	TATA spare parts
268426200223	ASSY O.D. GEAR (0.77 RATIO)	TATA spare parts
268426200228	ASSY KIT FOR D/CONE 1/2 SPEED(3.87/2.22)	TATA spare parts
268426200230	ASSY HELICAL GEAR 1ST SPEED(4.1RATIO)NVH	TATA spare parts
268426200236	Assy Engaging Gear (3/4Th)Larger Thrust	TATA spare parts
268426200241	ASSY 1ST SPEED GEAR (4.1)DEEPER REV 3.75	TATA spare parts
268426200242	ASSY REV.SPEED GEAR REV 3.75 RATIO	TATA spare parts
268426200263	ASSY 1ST SPEED GEAR (4.1) SAFARI 2.2L	TATA spare parts
268426200264	ASSY 3RD GEAR (M/SHAFT 1.37) 2.05 MODULE	TATA spare parts
268426200285	ASSY REVERSE GEAR (MATL.EN36C)3.75 RATIO	TATA spare parts
268426200305	ASSY COUPLING FLANGE WITH DUST COVER	TATA spare parts
268426200308	ASSY REVERSE GEAR 3.75 RATIO	TATA spare parts
268426200311	ASSY REVERSE GEAR	TATA spare parts
268426200334	ASY.1ST SPEED GEAR (4.1 RATIO)	TATA spare parts
268426200335	ASSY. HELICAL GEAR (2ND SPEED GEAR)	TATA spare parts
268426200336	SUB ASSY 3RD SPEED GEAR(LASER WELDED)NVH	TATA spare parts
268426200337	REVERSEGEAR(REV3.75RATIO)	TATA spare parts
268426200338	ASSY. OVER DRIVE GEAR	TATA spare parts
268426200341	ASSY.1ST SPEED GEAR (LASER WELDING)	TATA spare parts
268426200342	SUB ASY OVER DRIVE GEAR NVH LASER WELDED	TATA spare parts
268426200348	ASSY.OVER DRIVE GEAR (MAIN SHAFT; 0.82 O	TATA spare parts
268426203103	NEEDLE CAGE 2/3 SPEED	TATA spare parts
268426203107	NEEDLE CAGE [2ND/3RD SPEED]	TATA spare parts
268426203110	NEEDLE CAGE OD GEAR	TATA spare parts
268426203111	NEEDLE CAGE (OD GEAR MAIN SHAFT)	TATA spare parts
268426203112	NEEDLE CAGE	TATA spare parts
268426203113	NEEDLE CAGE	TATA spare parts
268426203114	NEEDLE CAGE	TATA spare parts
268426203115	NEEDLE CAGE	TATA spare parts

268426203118	AXIAL THRUST BRG.WITH THRUST WASHER	TATA spare parts
268426203119	AXIAL THRUST BRG.W/THRUST WASHER	TATA spare parts
268426203123	NEEDLE CAGE 1/R,M/S KCI (50X55X30)STANYL	TATA spare parts
268426203124	NEEDLE CAGE 2/3 (45X55X27)	TATA spare parts
268426203125	NEEDLE CAGE OD (35X40X18.5)	TATA spare parts
268426203131	LINEAR BEARING (INA)	TATA spare parts
268426203401	BUSH 3RDSPEED--	TATA spare parts
268426203406	BUSH BS6	TATA spare parts
268426203407	INNER RING ( RMP BRGS.LTD)	TATA spare parts
268426203802	SYNCHROCONC [3RD/DR.SH.]	TATA spare parts
268426203804	SYNCHROCONC-2ND/OD GEAR BS1/2/3/4	TATA spare parts
268426203808	SYNCHRO CONE-3/4 SPEED	TATA spare parts
268426203809	SYNCHRO CONE-2ND/OD SPEED	TATA spare parts
268426203810	SYNCHRO CONE-2ND/OD SPEED	TATA spare parts
268426203811	SYNCHROCONC 1ST/REV GEAR	TATA spare parts
268426203812	SYNCHROCONC 2ND GEAR	TATA spare parts
268426203813	SYNCHROCONC 3RD GEAR D/S	TATA spare parts
268426203814	SYNCHROCONC 2ND O/D GEAR	TATA spare parts
268426203816	ADAPTER HSG GB 4X4	TATA spare parts
268426203821	SYNCHROCONC-1/REV.GEAR	TATA spare parts
268426203824	SYNCHROCONC-2ND/OD	TATA spare parts
268426203825	SYNCHROCONC-3RD/D-SHAFT	TATA spare parts
268426203828	INNER CONE-1/2 DOUBLE CONE SYNCHRO	TATA spare parts
268426203829	INTERMEDIATE CONE (1/2 DUALCONC)	TATA spare parts
268426203830	SYNHRO CONE (OUTER),1/2 DOUBLE CONE SYN.	TATA spare parts
268426203833	INTERMEDIATE CONE (1/2 DUALCONC)	TATA spare parts
268426203835	GEAR CASE COVER REAR	TATA spare parts
268426203837	ADAPTOR HOUSING (SAFARI 4SP CR DI 4X4)	TATA spare parts
268426203844	INTERMEDIATE CONE (DUALCONC)	TATA spare parts
268426204302	SNAP RING	TATA spare parts
268426204303	SNAP RING	TATA spare parts
268426204304	SNAP RING	TATA spare parts
268426204305	SNAP RING	TATA spare parts
268426204306	SNAP RING	TATA spare parts
268426204308	SNAP RING	TATA spare parts
268426204309	SNAP RING	TATA spare parts
268426204310	SNAP RING	TATA spare parts
268426204311	SNAP RING	TATA spare parts
268426204312	SNAP RING 2.4 -0.04THK	TATA spare parts
268426204313	SNAP RING 1.7-0.04MM	TATA spare parts
268426204314	SNAP RING	TATA spare parts
268426204315	SNAP RING	TATA spare parts
268426204323	SNAP RING-2.10 THK.	TATA spare parts
268426204324	SNAP RING-2.20 THK.	TATA spare parts
268426204325	SNAP RING (2.15 -0.04 THK)	TATA spare parts
268426204327	SNAP RING (REV/OD) 1.7 THK. NVH	TATA spare parts
268426204328	SNAP RING (REV/OD) 1.8 THK. NVH	TATA spare parts



268426204329	SNAP RING (REV/OD) 1.85 THK. NVH	TATA spare parts
268426204330	SNAP RING (REV/OD) 1.9 THK. NVH	TATA spare parts
268426204331	SNAP RING (REV/OD) 1.95 THK NVH	TATA spare parts
268426204332	SNAP RING (REV/OD) 2.0 THK. NVH	TATA spare parts
268426204333	SNAP RING (REV/OD) 2.05 THK. NVH	TATA spare parts
268426204334	SNAP RING (REV/OD) 2.1 THK. NVH	TATA spare parts
268426204335	SNAP RING (REV/OD) 2.15 THK. NVH	TATA spare parts
268426204336	SNAP RING (REV/OD) 2.20 THK. NVH	TATA spare parts
268426204610	GEAR ENGAGING 3RD D/S	TATA spare parts
268426204611	GEAR ENGAGING 1/2/REV&OD	TATA spare parts
268426204613	SHIFTER SLEEVE	TATA spare parts
268426204614	SHIFTER SLEEVE	TATA spare parts
268426204615	SHIFTER SLEEVE	TATA spare parts
268426204617	SYNCHRO RING (1ST SPEED)	TATA spare parts
268426204622	SHIFTER SLEEVE-1/2- 9 DEGREES BS1/2/3/4	TATA spare parts
268426204623	GB 76 SHIFTER SLEEVE 3/4-9 DIG	TATA spare parts
268426204624	GB 76 SHIFTER SLEEVE REV/OD- 9 DIG	TATA spare parts
268426204625	ENGAGING GEAR (3RD/4TH)	TATA spare parts
268426204626	ENGAGING GEAR (REV/OD SPEED)	TATA spare parts
268426204627	SYNCHRO RING (1ST SPEED)	TATA spare parts
268426204628	ENGAGING GEAR-1ST/2ND SPEED	TATA spare parts
268426204629	SHIFTER SLEEVE-1ST/2ND SPEED	TATA spare parts
268426204630	SYNCHRO RING (2ND SPEED)	TATA spare parts
268426204633	SYNCHRO RING (2ND SPEED)UNEQUAL DACH CHF	TATA spare parts
268426204634	SYNCHRO RING (3RD SPEED)UNEQUAL DACH CHF	TATA spare parts
268426204639	SYNCHRO RING(OD GEAR) NVH	TATA spare parts
268426204640	ENGAGING GEAR (3/4TH) LARGER THRUST BRG.	TATA spare parts
268426204641	ENGAGING GEAR(1/2)SINTERED	TATA spare parts
268426204653	ENGAGING GEAR (3/4TH)	TATA spare parts
268426205105	END YOKE GBS76 DANA	TATA spare parts
268426205301	GASKET GR CASE COVER RR	TATA spare parts
268426205302	GASKET RR COVER ADP HSG	TATA spare parts
268426205407	GEAR SPEEDO DRIVE	TATA spare parts
268426205443	HELICAL GEAR 1ST SPEED (4.1 RATIO)	TATA spare parts
268426205449	REVERSE GEAR M/SHAFT (EN36C) 3.75 RATIO	TATA spare parts
268426207802	OIL SEAL MAIN SHAFT	TATA spare parts
268426207903	MAIN SHAFT	TATA spare parts
268426207904	MAIN SHAFT BORG WARNER	TATA spare parts
268426207915	MAIN SHAFT (4SP CR DI - 4X2)	TATA spare parts
268426207916	MAIN SHAFT (SAFARI 4SP CR DI 4X4)	TATA spare parts
268426207917	MAIN SHAFT 4X4(LARGER THRUSTBRG)2.2 DIC	TATA spare parts
268426207918	MAIN SHAFT FOR CROSSOVER W/DMF (4X4)	TATA spare parts
268426208601	SPACER BET 2ND/3RD GEAR	TATA spare parts
268426208602	SPACER ENG GEAR 3RD SPEED	TATA spare parts
268426208604	SPACER BET OD GEAR & TRB	TATA spare parts
268426208605	SPACER OIL SEAL	TATA spare parts
268426208622	SPACER (BELLEVILLE SPRING-OD GEAR)	TATA spare parts

268426208701	COMPRESSION SPRING	TATA spare parts
268426208702	BELLEVILLE SPRING (OD GEAR)	TATA spare parts
268426209901	CARRIER 1/2/3/4/OD/REV	TATA spare parts
268426250101	SUB ASSLY DRIVE SHAFT	TATA spare parts
268426250103	SUB ASSY DRIVE SHAFT 9 DG RING	TATA spare parts
268426250104	ASSY FRONT COVER (HPDC)	TATA spare parts
268426250106	DRIVE SHAFT	TATA spare parts
268426250113	DRIVE SHAFT- 9 DEG	TATA spare parts
268426250114	ASSY DRIVE SHAFT (INCREASED OIL HOLES)	TATA spare parts
268426250115	SUB ASSY DRIVE SHAFT(UNEQUAL DACH CHMF.)	TATA spare parts
268426250116	ASSY. DRIVE SHAFT BS2/3	TATA spare parts
268426250117	ASSY DRIVE SHAFT (CLUTCH) NVH	TATA spare parts
268426250119	ASSY BEARING TUBE (SAFARI 4SP CR DI)	TATA spare parts
268426250121	ASSY BEARING TUBE 207DI W/240 DIA.CLUTCH	TATA spare parts
268426250123	ASSY BEARING TUBE (2.2 DICR ENG)	TATA spare parts
268426250124	ASSY DRIVE SHAFT (2.05 MODULE) 2.2L DICR	TATA spare parts
268426250125	ASSY DRIVE SHAFT(2.05MOD FOR 3L DICOR)	TATA spare parts
268426250130	ASSY DRIVE SHAFT 2.2L DICRN (LARGER THRU	TATA spare parts
268426250131	ASSY DRIVE SHAFT	TATA spare parts
268426250133	ASSY DRIVE SHAFT	TATA spare parts
268426250134	SUB ASSY DRIVE SHAFT	TATA spare parts
268426250135	ASSY DRIVE SHAFT (LARGER THRUST BRG)	TATA spare parts
268426250136	ASSY DRIVE SHAFT (LARGER THRUST BRG)	TATA spare parts
268426250138	ASSY DRIVE SHAFT (LARGER THRUST BRG)	TATA spare parts
268426250144	ASSY.DRIVE SHAFT (1.8 MODULE) FOR 4SPTC	TATA spare parts
268426250145	ASSY BEARING TUBE	TATA spare parts
268426250151	BEARING TUBE ASSY BS6-PH2	TATA spare parts
268426253104	NEEDLE CAGE	TATA spare parts
268426253105	THRUST BEARING	TATA spare parts
268426253107	THRUST NEEDLE CAGE 21259	TATA spare parts
268426253801	GEAR CASE COVER FRONT	TATA spare parts
268426253804	GEAR CASE COVER FRONT	TATA spare parts
268426254601	SYNCHRO RING DRIVE SHAFT	TATA spare parts
268426254605	SYNCHRO RING (D/SHAFT)UNEQUAL DACH CHMF	TATA spare parts
268426254606	SYNCHRO RING (D/SHAFT) NEW THRUST BRG.	TATA spare parts
268426255301	GASKET GEAR CASE COVER FR	TATA spare parts
268426257912	DRIVE SHAFT (2.05 MODULE) W.A.D. 2.2L	TATA spare parts
268426257917	DRIVE SHAFT ,CROSSOVER W/DMF,(4X4/4X2)	TATA spare parts
268426257919	DRIVE SHAFT	TATA spare parts
268426258701	COMPRESSION SPRING DRIVE SHAFT	TATA spare parts
268426300130	ASSY C/SHAFT (4.1 1ST/3.75 REV)SAF-2.2L	TATA spare parts
268426300158	COUNTER SHAFT ASSYBS6	TATA spare parts
268426305401	DOUBLE GEAR-NLS5419&20	TATA spare parts
268426305404	O/D GEAR COUNTER SHAFT	TATA spare parts
268426305411	OVER DRIVE GEAR (C/SHAFT) EN353	TATA spare parts
268426305412	DOUBLE GEAR-CM/3RD -EN353 MATL	TATA spare parts
268426305413	OVER DRIVE GEAR C/SHAFT (0.73 RATIO)	TATA spare parts

268426305416	OVER DRIVE GEAR (C/SHAFT) NVH	TATA spare parts
268426305417	OVER DRIVE GEAR (COUNTERSHAFT)0.77 RATIO	TATA spare parts
268426305418	CONSTANT MESH GEAR (COUNTER SHAFT) EN353	TATA spare parts
268426305419	CONSTANT MESH GEAR-C/SHAFT	TATA spare parts
268426305420	3RD GEAR-COUNTER SHAFT	TATA spare parts
268426305421	3RD GEAR C/SHAFT (SAFARI 4SP CR DI)EN353	TATA spare parts
268426305423	CONSTANTMESH GEAR (C/SHAFT) 2.05 MODULE	TATA spare parts
268426305424	3RD GEAR (COUNTER SHAFT 1.37)2.05 MODUL	TATA spare parts
268426305426	GEAR 3RD SPEED	TATA spare parts
268426305427	CONSTANT MESH GEAR	TATA spare parts
268426307901	COUNTER SHAFT	TATA spare parts
268426307905	COUNTER SHAFT (4.1 RATIO)	TATA spare parts
268426307910	COUNTER SHAFT DEEPER REV. 3.75 RATIO	TATA spare parts
268426308601	SPACER C/SHAFT RR COVER	TATA spare parts
268426350101	SUBASSLY. R.I.SHAFT	TATA spare parts
268426353102	NEEDLE CAGE R.I.GEAR	TATA spare parts
268426353103	ROLLER CAGE POLYAMIDE CAGE	TATA spare parts
268426353107	ROLLER CAGE (REVERSE IDLER BEARING	TATA spare parts
268426354301	SNAP RING REV IDLER GEAR	TATA spare parts
268426355401	REVERSE IDLER GEAR	TATA spare parts
268426355403	REVERSE IDLER GEAR REV. 3.75 RATIO	TATA spare parts
268426355405	REVERSE IDLER GEAR(MATL.EN36C)3.75 RATIO	TATA spare parts
268426356501	HEXAGON BOLT-REV IDLER GEAR	TATA spare parts
268426357901	REVERSE IDLER SHAFT	TATA spare parts
268426358202	RETAINER PLATE	TATA spare parts
268426510101	SELECTOR LEVER	TATA spare parts
268426510102	DETENT ASSY	TATA spare parts
268426510112	ASSY INHIBITER	TATA spare parts
268426510114	ASSEMBLY OF INHIBITOR	TATA spare parts
268426513001	NEEDLE ROLLER INTERLOCK.	TATA spare parts
268426513002	ROLLER [INTER LOCK DEVICE]	TATA spare parts
268426513003	ROLLER [CENTRAL DETENT]	TATA spare parts
268426513004	ROLLER-CENTRAL DETENT	TATA spare parts
268426513005	ROLLER	TATA spare parts
268426513401	ROLLER SLECTOR LEVER	TATA spare parts
268426513402	ROLLER SELE & SHIFT SHAFT	TATA spare parts
268426513403	DETENT	TATA spare parts
268426513404	PLUNGER REV GEAR DETENT	TATA spare parts
268426513405	ROLLER	TATA spare parts
268426513407	BUSH SHIFTING YOKE	TATA spare parts
268426513408	ROLLER SELE & SHIFT SHAFT	TATA spare parts
268426513409	BUSH SHIFTING YOKE	TATA spare parts
268426513410	BUSH SHIFTING YOKE	TATA spare parts
268426513414	CENTRAL DETENT-SPHERICAL	TATA spare parts
268426513415	CENTRAL DETENT (SPHERICAL)	TATA spare parts
268426513416	CENTRAL DETENT-SPHERICAL	TATA spare parts
268426513417	CENTRAL DETENT SPHERICAL	TATA spare parts

268426513702	SHIFTER DOG 1ST/2ND	TATA spare parts
268426513703	SHIFT YOKE SEL&SHFT SHAFT	TATA spare parts
268426513705	SHIFTING YOKE	TATA spare parts
268426513706	SHIFTING YOKE (FLAT END VERSION)	TATA spare parts
268426513707	SHIFTING YOKE-FLAT END VERSION	TATA spare parts
268426513801	SHIFTER FORK 1ST/2ND	TATA spare parts
268426513802	SHIFTER FORK 3RD/4TH	TATA spare parts
268426513803	SHIFTER FORK REV/OD	TATA spare parts
268426515106	SELECTOR SHIFT FINGER	TATA spare parts
268426515301	GASKET DETENT COVER	TATA spare parts
268426516001	SELECTOR LEVER	TATA spare parts
268426516501	THREADED PLUG (CENTRAL DETENT)	TATA spare parts
268426516701	PIN SELECTOR LEVER.	TATA spare parts
268426516702	PLUG	TATA spare parts
268426516703	PIN SWING LEVER	TATA spare parts
268426516704	SPIRAL PIN 6 X 28	TATA spare parts
268426516705	SPIRAL PIN-6X24	TATA spare parts
268426516706	PIN CYLINDRICAL	TATA spare parts
268426517101	DETENT COVER	TATA spare parts
268426517201	THREADED PLUG OD PR PLATE	TATA spare parts
268426517202	ADAPTER (FILLER PLUG)	TATA spare parts
268426518201	PRESSURE PLATE OD GEAR	TATA spare parts
268426518202	PRESSURE PLATE-REVERSE GEAR	TATA spare parts
268426518203	SWING LEVER	TATA spare parts
268426518204	PRESSURE PLATE REV GEAR	TATA spare parts
268426518602	TUBULAR SPACER	TATA spare parts
268426518701	DETENT SPRING CENTRAL	TATA spare parts
268426518702	DETENT SPRING 1/2/3/4TH	TATA spare parts
268426518703	DETENT SPRING [REV/O.D.SHIFTER SHAFT]	TATA spare parts
268426518704	SPRING PLUNGER	TATA spare parts
268426518709	SPRING DET PLATE OD GEAR	TATA spare parts
268426518710	TORSION SPRING	TATA spare parts
268426518714	TORSION SPRING	TATA spare parts
268426518715	SPRING-DETENT PLATE OD GEAR	TATA spare parts
268426518717	SPRING-CENTRAL DETENT SPHERICAL	TATA spare parts
268426518718	SPRING ( REAR HALF)	TATA spare parts
268426518719	SPRING (SHIFTER SHAFT DETENT) SPACIO	TATA spare parts
268426518720	SPRING (DENTENT SHIFTER SHAFT)	TATA spare parts
268426518721	DETENT SPRING	TATA spare parts
268426518722	SPHERICAL DETENT SPRING	TATA spare parts
268426519901	LOCATING PIECE [REV.SHIFTER SHAFT]	TATA spare parts
268426519903	SELECTOR & SHIFTER FINGER	TATA spare parts
268426519905	BEARING BLOCK-SWING LEVER	TATA spare parts
268426519906	BEARING BLOCK-SWING LEVER	TATA spare parts
268426700117	SHIFTING LINK	TATA spare parts
268426700173	ASSY SHIFT LINK (WELD VERSION)SIERRA 4X4	TATA spare parts
268426706701	PIN SELECT & SHIFT SHAFT	TATA spare parts

268426707804	OIL SEAL	TATA spare parts
268426707807	2507LE LIP OIL SEAL	TATA spare parts
268426707807AE	DOUBLE LIP OIL SEAL -XENON DC/SC	TATA spare parts
268426707811	DUST SEAL (SEL.& SHIFT SHAFT)	TATA spare parts
268426707814	DOUBLE LIP OIL SEAL	TATA spare parts
268426707901	SHIFTER SHAFT 1ST/2ND SPD	TATA spare parts
268426707903	SHIFTER SHAFT REV/OD SPD	TATA spare parts
268426707909	SHIFTER SHAFT REV SPEED	TATA spare parts
268426707910	SHIFTER SHAFT 3RD/4TH SPD	TATA spare parts
268426707913	SELECTOR & SHIFTER SHAFT	TATA spare parts
268426707916	SHIFTER SHAFT-3/4 SPEED	TATA spare parts
268426707917	SHIFTER SHAFT REVERSE/OD 407 4X4	TATA spare parts
268426707918	SELECTOR & SHIFTER SHAFT G 76	TATA spare parts
268426707920	SELECTOR SHIFTER SHAFT 4X2 (FLAT END)	TATA spare parts
268426707921	SEL.SHIFTER SHAFT 4X4-FLAT END	TATA spare parts
268426707922	SELECTOR & SHIFTER SHAFT FLAT END	TATA spare parts
268426707923	ROUND END SHIFTER SHAFT	TATA spare parts
268426707924	SELECTOR SHIFTER SHAFT 4X4	TATA spare parts
268426707925	SELECTOR SHIFTER SHAFT 4X2	TATA spare parts
268426707925_NIU	SELECTOR SHIFTER SHAFT 4X2	TATA spare parts
268426707926	SELECTOR SHIFTER SHAFT 4X4	TATA spare parts
268426707927	SHIFTER SHAFT 1ST/2ND	TATA spare parts
268426707928	SHIFTER SHAFT (3/4 SPEED)	TATA spare parts
268426707929	SHIFTER SHAFT (5/R SPEED)	TATA spare parts
268426708207	RETAINER PLATE	TATA spare parts
268426708601	O/SEAL SPACER S & S SHAFT	TATA spare parts
268426710102	SHIFTING LINK	TATA spare parts
268426710127	BKT W/BUSH EXTN ARM	TATA spare parts
268426710133	ASSY SHIFT LINK	TATA spare parts
268426710154	ASSY BRACKET WITH BUSH (EXTN.ARM SUPPORT)	TATA spare parts
268426710158	ASSY SHIFT LINK	TATA spare parts
268426710161	ASSY SHIFT LINK (FABRICATED VERSION)4X4	TATA spare parts
268426710163	ASSY SHIFT LINK (FABRICATED VERSION)4X2	TATA spare parts
268426710165	ASSY SHIFT LINK (TELCOLINE 2.2L DICR)4X2	TATA spare parts
268426710166	ASSY SHIFT LINK (TELCOLINE 2.2L DICR)4X4	TATA spare parts
268426710190	ASSY SHIFT LINK 4X2	TATA spare parts
268426710191	ASSY SHIFT LINK 4X4	TATA spare parts
268426710197	ASSYSTUDANDTUBE BS6	TATA spare parts
268426710199	ASSY EXTENSION BOXSUPPORT	TATA spare parts
268426710201	SHIFT LINK	TATA spare parts
268426710202	ASSY SHIFT LINK (3L 4X2 NORGLIDE LINKAGE)	TATA spare parts
268426710203	ASST SHIFT LINK (3L 4X4 NORGLIDE LINKAGE)	TATA spare parts
268426710209	ASSY BRACKET (EXT ARM SUPPORT)	TATA spare parts
268426710216	BRACKET ASSY EXTENSION ARM SUPPORT	TATA spare parts
268426713403	BUSH EXTENSION ARM	TATA spare parts
268426713701	SHIFT LINK	TATA spare parts
268426713702	C CLAMP (YOKE SIDE)	TATA spare parts

268426713703	C CLAMP (GSL SIDE)	TATA spare parts
268426713801	BKT EXTENSION ARM	TATA spare parts
268426713802	EXTENSION ARM TS/TE	TATA spare parts
268426713804	EXTENSION ARM	TATA spare parts
268426713805	EXTENSION ARM	TATA spare parts
268426713806	EXTENSION ARM -SUMO 4X4	TATA spare parts
268426713807	EXTENSION ARM 4X4	TATA spare parts
268426713811	EXTENSION ARM	TATA spare parts
268426713817	EXTENSION ARM	TATA spare parts
268426713820	EXTENSION ARM	TATA spare parts
268426713821	EXTENSION ARM (TELCOLINE 3LDICOR 4X2/4X4	TATA spare parts
268426713822	EXTENSION ARM(TELCOLINE 2.2LDICR)	TATA spare parts
268426713836	EXTENSION ARM	TATA spare parts
268426713838	EXTENSION ARM	TATA spare parts
268426713840	EXTENSION ARM BS6	TATA spare parts
268426716301	COLLAR BUSH (SHIFT LINK)	TATA spare parts
268426716302	COLLAR BUSH (EXTENSION ARM)	TATA spare parts
268426716702	PIN EXTENSION ARM BKT	TATA spare parts
268426717704	RUBBER BUSH (EXTENSION ARM)	TATA spare parts
268426719905	SHIFT LINK ROD	TATA spare parts
268426719906	SHIFT LINK ROD	TATA spare parts
268426719914	SHIFT LINK ROD	TATA spare parts
268426719920	ASSY¿ BRACKET (EXT ARM SUPPORT)	TATA spare parts
268426719921	SHIFT LINK ROD	TATA spare parts
268426719922	SHIFT LINK ROD	TATA spare parts
268426719924	SHIFT LINK ROD	TATA spare parts
268426800103	GEAR SHIFT LEVER W/KNOB	TATA spare parts
268426800107	GEAR SHIFT LEVER SUBASSY	TATA spare parts
268426800108	GEAR SHIFT LEVER KNOB	TATA spare parts
268426800114	GEAR SHIFT LEVER	TATA spare parts
268426800115	KNOB GEAR SHIFT LEVER	TATA spare parts
268426800123	SUB ASSY G S LEVER	TATA spare parts
268426800177	ASSY G.S.LEVER KNOB(GREY COLOUR) SIERRA	TATA spare parts
268426800193	ASSY G.S.LEVER(UPPER & LOWER) TATAMOBILE	TATA spare parts
268426800208	ASSY G.S.LEVER KNOB BLACK-207 DI	TATA spare parts
268426800212	ASSY G.S.LEVER KNOB BLACK 3-GATE SHIFIN	TATA spare parts
268426800226	ASSY GEAR SHIFT LEVER KNOB-SAFARI	TATA spare parts
268426800230	ASSY. G S LEVER KNOB LIMITED EDITION	TATA spare parts
268426800234	ASSY GEAR SHIFT LEVER (UPPER&LOWER)207DI	TATA spare parts
268426800250	ASSY G.S.LEVER-UPPER+LOWER	TATA spare parts
268426800253	ASSY GAITER WITH KNOB	TATA spare parts
268426800262	ASSY G.SHIFT KNOB,M/S JAIHIND,SAFARI F/L	TATA spare parts
268426800265	ASSY G.S.LEVER (UPPER+LOWER)207DI	TATA spare parts
268426800290	ASSY GEAR SHIFT KNOB (SPRINT) SILVER	TATA spare parts
268426800297	ASSY G.S.LEVER W/RUBBER DAMPNERS(SAF2.2L	TATA spare parts
268426800304	ASSY GEAR SHIFT LEVER (WITH RUBBER DAMP)	TATA spare parts
268426800324	ASSY G.S.LEVER(UPPER+LOW) 207 DI	TATA spare parts

268426800342	ASSY CLAMP BRACKET WITH FOAM XENON.	TATA spare parts
268426800350	ASSY GEAR SHIFT KNOB (XENON)THAILAND	TATA spare parts
268426800352	ASSY GEAR SHIFT(WITH RUBBER DAMPNER)	TATA spare parts
268426800359	ASSY GEAR SHIFT LEVER (WITH RUBBER DAMP)	TATA spare parts
268426800367	ASSY GEAR SHIFT KNOB (SAFARI FACELIFT) B	TATA spare parts
268426800369	ASSY GEAR SHIFT LEVER (WITH RUBBER DAMP)	TATA spare parts
268426800394	ASSLY GSL	TATA spare parts
268426800398	ASSY GEAR SHIFT LEVER (LOWER+UPPER)207 D	TATA spare parts
268426803401	BUSH BALL SEAT G S LEVER	TATA spare parts
268426803402	BUSH GEAR SHIFT LEVER BOTTOM	TATA spare parts
268426803408	BUSH-GEAR SHIFT LEVER-LOWER	TATA spare parts
268426803409	BUSH-SHIFTING ARM	TATA spare parts
268426803703	BRACKET-SHIFTING ARM	TATA spare parts
268426803707	SHIFT LINK YOKE	TATA spare parts
268426803708	SHIFT LINK	TATA spare parts
268426803802	SHIFTING ARM-PRESSED BUSH VERSION	TATA spare parts
268426806303	BASE PLATE-G.S.L.BELLOW	TATA spare parts
268426806305	BASE PLATE (CONSOLE)	TATA spare parts
268426806306	BASE PLATE (G.S.LEVER TOP-BELLOW),SUMO	TATA spare parts
268426806311	BASE PLATE (G.S.LEVER AT TUNNEL)207 DI	TATA spare parts
268426806313	BASE PLATE (G.S.LEVER AT TUNNEL)207 DI	TATA spare parts
268426806315	BUSH GSL	TATA spare parts
268426806501	HEX BOLT-SHIFTING YOKE TO G.S.L.BOTTOM	TATA spare parts
268426806702	PIN (YOKE SIDE)	TATA spare parts
268426806703	PIN (GSL SIDE)	TATA spare parts
268426807701	RUB SEAL EXTN ARM	TATA spare parts
268426807704	RUBBER BELLOW	TATA spare parts
268426807705	SEALING BELLOW ON TUNNEL	TATA spare parts
268426807708	RUBBER SEALING (EXT.ARM TO TUNNEL)	TATA spare parts
268426807712	RUBBER BELLOW-G.S.LEVER	TATA spare parts
268426807715	RUBBER BELLOW-G S LEVER	TATA spare parts
268426807716	RUBBER BELLOW-BRACKET TO SHIFT ARM	TATA spare parts
268426807717	RUBBER BELLOW-SHIFTING ARM	TATA spare parts
268426807721	GAITER (SUMO FACE LIFT)GX VERSION_HCBS B	TATA spare parts
268426807722	GAITER (TELCOLINE FACELIFT)	TATA spare parts
268426807724	BELLOW (G.S.L.TOP)SUMO/SPACIO	TATA spare parts
268426807731	BELLOW (G.S.L.TOP) 207DI	TATA spare parts
268426807732	RUBBER BELLOW (AT TUNNEL) SPRINT BUCKET	TATA spare parts
268426807741	ELLOW	TATA spare parts
268426807742	PU FOAM(CLAMP BRACKET-ON TUNNEL) XENON	TATA spare parts
268426807744	RUBBER BELLOW	TATA spare parts
268426807751	BELLOW	TATA spare parts
268426808203	CLAMPING PLATE	TATA spare parts
268426808205	CLAMPING PLATE (FOR SEALING ON TUNNEL)	TATA spare parts
268426808208	CLAMPING PLATE (AT TUNNEL) SPRINT	TATA spare parts
268426808601	SPACER	TATA spare parts
268426808602	SPACER PLASTIC-SHIFT ARM	TATA spare parts

268426809928	TRANSFER LABEL (REV/OD INLINE SHIFTING)	TATA spare parts
268426810118	ASSY GEAR SHIFT LEVER-WITH RUBBER DAMPN	TATA spare parts
268426810127	ASSY G.S.LEVER (UPPERLOWER)207DI	TATA spare parts
268426810130	ASSY GEAR SHIFT LEVER WITH RUBBER DAMPNE	TATA spare parts
268426810188	ASSY GEAR SHIFT LEVER (WITH RUBBER DAMP	TATA spare parts
268426810218	GEAR SHIFTER LEVER ASSY	TATA spare parts
268426810219	EXTENSION ARM ASSY WITH GSL LINKAGEBS6	TATA spare parts
268426810224	GEAR SHIFTER LEVER ASSY BS6	TATA spare parts
268426817701	RUBBER BELLOW (FROM TUNNEL TO GSL)	TATA spare parts
268426818201	CLAMPING PLATE (FOR SEALING BELLOW ON TU	TATA spare parts
268725150101	COVER ASSY.4554539001	TATA spare parts
268725157801	SEAL OIL 13000044001	TATA spare parts
268728000105	TRANSFER CASE ELECT.SHIFT	TATA spare parts
268728000227	T/ CASE WITH ECU(SAFARI)	TATA spare parts
268728000228	TRANSFER CASE (ELECT.SHIFT)	TATA spare parts
268728000229	T/CASE(ELEC.SHIFT)-MOBILE	TATA spare parts
268728000252	ASSY MECHANICAL SHIFT TRANSFER CASE	TATA spare parts
268728000258	TRANSFER CASE WITH ECU (SAFARI)	TATA spare parts
268728000265	DIVGI WARNER T/CASE E-SOF (LH DROP) WITH	TATA spare parts
268728000269	TRANSFER CASE ASSY WITH STORME ECU	TATA spare parts
268728000282	BRACKET ASSY	TATA spare parts
268728000287	LEVER ASSY UPPER	TATA spare parts
268728000288	KNOB	TATA spare parts
268728000290	LEVER ASSY UPPER	TATA spare parts
268728008204	PROTECTIVE COVER (FOR ELECTRICAL MOTOR)	TATA spare parts
268728008227	SHIELD ON TRANSFER CASE	TATA spare parts
268728100104	ASSY COVER (45-57-539-001)	TATA spare parts
268728100105	ASSY ELECTRIC COIL (44-00-645-025)	TATA spare parts
268728100106	ASSY CONNECTOR-RETAINER (45-57-640-001)	TATA spare parts
268728100107	ASSY CASE (45-57-565-001)	TATA spare parts
268728100112	ADAPTER ASSY	TATA spare parts
268728103202	HEX. HEAD BOLT	TATA spare parts
268728103203	BOLT - HEX. CAP SCREW (45-00-183-004)	TATA spare parts
268728103204	BOLT	TATA spare parts
268728103805	COVER-TRANSFER (TOD) (45-57-039-001)	TATA spare parts
268728103806	CASE TRANSFER (45-57-065-001)	TATA spare parts
268728103807	ADAPTER	TATA spare parts
268728104901	CONNECTOR - THREE TERMINAL	TATA spare parts
268728106301	BRACKET-RELAY MOUNTING	TATA spare parts
268728106302	CONNECTOR-COIL (44-00-640-079)	TATA spare parts
268728106303	LOCKING CLIP (44-00-640-080)	TATA spare parts
268728106502	BOLT-SELF TAPPING (19-00-183-039)	TATA spare parts
268728106503	NUT - HEX	TATA spare parts
268728107201	PLUG	TATA spare parts
268728107801	OIL SEAL	TATA spare parts
268728108204	BRACKET-CONNECTOR MOUNTING (45-57-185-001)	TATA spare parts
268728109901	ASSLY - BREATHER	TATA spare parts



268728150101	COVER ASSY TRANSFER CASE (45-54-539-001)	TATA spare parts
268728150102	COIL CLUTCH 4554645001	TATA spare parts
268728150103	CASE ASSY TRANSFER	TATA spare parts
268728153101	BEARING ANGULAR 1000130008	TATA spare parts
268728153102	BEARING NEEDLE CAGE 1000132039	TATA spare parts
268728153103	NEEDLE BEARING	TATA spare parts
268728153201	BOLTHEX HEAD	TATA spare parts
268728153401	BEARING SLEEVE 1300127002	TATA spare parts
268728153801	COVERTRANSFER CASE	TATA spare parts
268728154301	J - CLIP 90	TATA spare parts
268728154302	RING SNAP	TATA spare parts
268728154304	LOCKING CLIP	TATA spare parts
268728156501	NUT HEX 1300149002	TATA spare parts
268728156701	PIN DOWEL	TATA spare parts
268728157801	SEAL OIL	TATA spare parts
268728159901	MAGNET 1000012002	TATA spare parts
268728159902	BREATHER 1900072007	TATA spare parts
268728159903	ADAPTER BREATHER 1900072006	TATA spare parts
268728159905	BREATHER ASSEMBLY	TATA spare parts
268728200101	ADAPTOR FRONT 4554672001	TATA spare parts
268728200102	SHAFT INPUT 4554689001	TATA spare parts
268728200104	CARRIER PLANET 1354659001	TATA spare parts
268728200105	SPEEDO GEAR & SHAFT DW-00610008	TATA spare parts
268728200112	ASSY. SPEEDO GEAR (DRIVEN)#45-54-610-001	TATA spare parts
268728200122	ASSY CLUTCH PACK (44-11-625-001)	TATA spare parts
268728200124	ASSY - OUTPUT SHAFT	TATA spare parts
268728200126	INPUT SHAFT ASSY	TATA spare parts
268728200127	ASSY FRONT ADAPTOR BS6	TATA spare parts
268728203101	BEARING ANGULAR 1000130011	TATA spare parts
268728203102	BEARING,SLEEVE (13-45-127-002)	TATA spare parts
268728203103	NEEDLE BEARING, (19-00-132-013)	TATA spare parts
268728203109	ANNULAR BEARING	TATA spare parts
268728203201	BOLT 1300183021	TATA spare parts
268728203401	SLEEVE BEARING	TATA spare parts
268728203801	BODY SPEEDO 4554074001	TATA spare parts
268728204301	RING SNAP 1000139039	TATA spare parts
268728204302	RING SNAP 1000139040	TATA spare parts
268728204303	SNAP RING 1000139043	TATA spare parts
268728204701	ADAPTOR FRONT 4554172001	TATA spare parts
268728205401	GEAR SPEEDO 8T DW-00110030	TATA spare parts
268728205402	GEAR SUN 1350165001	TATA spare parts
268728206701	PIN SPIRAL 1000043017	TATA spare parts
268728207701	O RING 1900141115	TATA spare parts
268728207801	SEAL OIL 1900044009	TATA spare parts
268728207802	SEAL SPEEDO 1352016003	TATA spare parts
268728208601	WASHER THRUST 1350193001	TATA spare parts
268728208602	PLATE THRUST 1350014001	TATA spare parts

268728208614	SPACER (45-57-053-001)	TATA spare parts
268728208801	STUD - MOUNTING	TATA spare parts
268728208802	STUD MTG	TATA spare parts
268728209904	BODY-SPEEDO ADAPTOR #45-54-074-002	TATA spare parts
268728250101	LOCKUP ASSY.2W-4W - 1350589003	TATA spare parts
268728250102	SHAFT & PUMP ASSY 4554671001	TATA spare parts
268728250108	ASM -YOKE	TATA spare parts
268728250109	ASSY SHAFT AND PUMP (45-57-671-002)	TATA spare parts
268728250110	ASSY OUTPUT SHAFT (45-57-671-001)	TATA spare parts
268728250111	ASSY YOKE BS6	TATA spare parts
268728253001	BALL (19-00-109-002)	TATA spare parts
268728253106	ANNULAR BEARING	TATA spare parts
268728253701	HOUSING CLUTCH 1354212001	TATA spare parts
268728254201	CLAMP HOSE	TATA spare parts
268728254202	CLAMP-HOSE (13-45-056-005)	TATA spare parts
268728254301	RING SNAP 1000139041	TATA spare parts
268728254302	RING SNAP 1000139038	TATA spare parts
268728254303	RING -RETAINING (19-00-139-039)	TATA spare parts
268728254304	SNAP RING	TATA spare parts
268728254305	RING RETAINING (19-00-139-007)	TATA spare parts
268728254601	CHAIN DRIVE 1350143001	TATA spare parts
268728254602	COUPLING 1350034002	TATA spare parts
268728254605	ASSY CHAIN DRIVE (44-00-143-014)	TATA spare parts
268728254606	CHAIN	TATA spare parts
268728255101	COLLAR LOCK UP 4400055001	TATA spare parts
268728255102	ARMATURE (44-05-147-004)	TATA spare parts
268728255103	ASSY CAM & COIL HOUSING (44-00-712-001)	TATA spare parts
268728255501	HUBLOCKUP	TATA spare parts
268728255502	HUB REDUCTION 1354089002	TATA spare parts
268728256302	STRAINER-OIL (44-00-238-002)	TATA spare parts
268728256501	LOCKNUT (19-00-149-014)	TATA spare parts
268728256801	HOSE-SUMP PUMP (45-57-034-001)	TATA spare parts
268728257901	OUTPUT SHAFT	TATA spare parts
268728257902	SHAFT FRONT 4554171004	TATA spare parts
268728257905	SHAFT-LOWER OUTPUT (45-00-171-002)	TATA spare parts
268728258201	STAINER OIL 4400238005	TATA spare parts
268728258601	SPACER	TATA spare parts
268728258609	SPACER (45-56-053-001)	TATA spare parts
268728258701	SPRING SLEEVE RETURN 1350156007	TATA spare parts
268728258702	SPRING-WAVE (19-00-156-006)	TATA spare parts
268728258901	SPROCKET DRIVE 1354144002	TATA spare parts
268728258902	SPROCKET DRIVEN 1354144003	TATA spare parts
268728258903	ASSY SPROCKET (44-12-644-001)	TATA spare parts
268728258904	SPROCKET-DRIVEN (45-57-144-001)	TATA spare parts
268728258905	SPROCKET - DRIVE	TATA spare parts
268728258906	SPROCKET - DRIVEN	TATA spare parts
268728259201	WASHER (19-00-047-007)	TATA spare parts

268728259202	WASHER-THRUST (19-00-193-020)	TATA spare parts
268728259901	GEROTOR PUMP 4400508010	TATA spare parts
268728259902	CAM - APPLY (44-00-099-001)	TATA spare parts
268728259903	ASSY GEROTOR PUMP (45-57-508-001)	TATA spare parts
268728350101	YOKE ASSY.DOUBLE CARDEN 1300531005	TATA spare parts
268728350102	YOKE ASSY.SINGLE CARDEN 4400531014	TATA spare parts
268728356501	NUT 1900149001	TATA spare parts
268728357801	SEAL OIL 1000044012	TATA spare parts
268728358201	DEFLECTOR-DUST	TATA spare parts
268728359201	WASHER 1000047016	TATA spare parts
268728400101	FORK ASSY.REDUCT.SHIFT 4554596001	TATA spare parts
268728403401	FACING LOCK UP FORK	TATA spare parts
268728403402	FACING REDUCTION FORK 1356235001	TATA spare parts
268728403702	LEVER	TATA spare parts
268728403703	SHIFT LEVER	TATA spare parts
268728403704	STOPPER	TATA spare parts
268728403705	SHIFT LEVER	TATA spare parts
268728403706	SHIFT LEVER	TATA spare parts
268728404601	FORK LOCK UP 4554596002	TATA spare parts
268728405201	CAM ELECRC SHIF 1354099002	TATA spare parts
268728406303	BUSH	TATA spare parts
268728406304	BUSH	TATA spare parts
268728406706	PIN	TATA spare parts
268728406707	PIN	TATA spare parts
268728407703	COVER	TATA spare parts
268728407704	RUBBER BELLOW	TATA spare parts
268728407705	RUBBER BELLOW BS6	TATA spare parts
268728407901	SHAFT RAIL 1350100001	TATA spare parts
268728407902	SHAFT SHIF 4554122001	TATA spare parts
268728408206	CLAMP	TATA spare parts
268728408601	SPACER 1350053002	TATA spare parts
268728408701	SPRING RETURN 4400156001	TATA spare parts
268728408702	SPRING TORSION 1350156008	TATA spare parts
268728408704	SPRING	TATA spare parts
268728409901	TRANSFER LABEL	TATA spare parts
268728700101	SENSOR ASSY 4408640001	TATA spare parts
268728700102	MOTOR ASSY 4554648001	TATA spare parts
268728703201	CAP SCREW, HEX.HD. ( METRIC )	TATA spare parts
268728703202	BOLT - METRIC HEX. HEAD	TATA spare parts
268728703301	BRACKET SENSOR/HARNESS 4554185002	TATA spare parts
268728707201	PULG PIPE 1900052010	TATA spare parts
268728980101	CASE HALF ASSY FRONT	TATA spare parts
268728980102	BREATHER ASSY	TATA spare parts
268728980103	ENGAGING SLEEVE ASSY	TATA spare parts
268728980104	CASE HALF ASSY REAR	TATA spare parts
268728980105	CARRIER ASSY	TATA spare parts
268728983101	NEEDLE BEARING	TATA spare parts

268728983401	PAD SHIFTER FORK	TATA spare parts
268728983801	COVER REAR	TATA spare parts
268728984301	CIRCLIP	TATA spare parts
268728984601	SHIFTER SLEEVE	TATA spare parts
268728984602	CHAIN FRONT OUTPUT	TATA spare parts
268728984701	ADAPTER	TATA spare parts
268728985401	SUN GEAR	TATA spare parts
268728985402	SPEEDO GEAR	TATA spare parts
268728985501	ENGAGING GEAR	TATA spare parts
268728985502	ENGAGING GEAR	TATA spare parts
268728986501	LOCK NUT	TATA spare parts
268728987101	CAM	TATA spare parts
268728987201	ADAPTER BREATHER	TATA spare parts
268728987801	OIL SEAL	TATA spare parts
268728987901	SHIFTER SHAFT	TATA spare parts
268728987902	RAIL	TATA spare parts
268728988001	SCREW	TATA spare parts
268728988201	DUST COVER	TATA spare parts
268728988601	THRUST WASHER	TATA spare parts
268728988602	PLATE	TATA spare parts
268728988701	SPRING	TATA spare parts
268728988702	SPRING POPPET	TATA spare parts
268728988801	STUD MTG	TATA spare parts
268728989901	SWITCH	TATA spare parts
268728989902	ROLLER	TATA spare parts
268728989903	PLUNGER DETENT HSG	TATA spare parts
268728989904	PUMP ASSY	TATA spare parts
268729985502	HUB-SHIFT COLLAR BS6	TATA spare parts
268738987902	RAIL BS6	TATA spare parts
268826108201	PLUG	TATA spare parts
268826204608	SHIFTER SLEEVE G-600 BS1/2/3/4	TATA spare parts
268826205407	SPEEDO GEAR-M/SHAFT	TATA spare parts
268826206501	LOCK NUT BS1/2/3/4	TATA spare parts
268826206702	RETENTION PIN-3/4	TATA spare parts
268826209901	CARRIER	TATA spare parts
268928000101	ASSY TRANSFER CASE PTO LPT1615TC	TATA spare parts
268928010101	ASSY. AUXILIARY GEARBOX(1.43 LOW RATIO)	TATA spare parts
268928100101	HOUSING & INTERMEDIATE FLANGE ASSY	TATA spare parts
268928100102	ASSY OIL CATCHER (PTO)	TATA spare parts
268928100106	ASSY TUBE (REAR COVER TO HSG.)	TATA spare parts
268928100108	ASSY TUBE 10 O D (INLET/OUTLET)	TATA spare parts
268928100109	ASSY COPPER TUBE 10 O D X 1.5THIK (COIL)	TATA spare parts
268928103702	REAR COVER (PTO)	TATA spare parts
268928107201	ADAPTER (PTO)	TATA spare parts
268928107701	GASKET (3.25 THICK) PTO	TATA spare parts
268928150101	ASSEMBLY BEARING HALF BS6	TATA spare parts
268928200103	ASSY. DRIVE SHAFT COMPLETE BS6	TATA spare parts

268928203701	COVER PTO	TATA spare parts
268928205401	GEAR WHEEL (FRONT DRIVESHAFT) BS6	TATA spare parts
268928258601	SPACER PTO	TATA spare parts
268928307901	COUNTER SHAFT	TATA spare parts
269026100104	SPEEDO PINION	TATA spare parts
269026103805	HOUSING (REAR HALF)-nls-3811	TATA spare parts
269026104802	DOWEL SLEEVE	TATA spare parts
269026104803	CYL.PIN (HSG.FRT.HALF TO HSG.REAR HALF)	TATA spare parts
269026107202	MAGNETIC DRAIN PLUG	TATA spare parts
269026107203	FILLER PLUG	TATA spare parts
269026107701	RUBBER SEAL NLS (RR COVER)	TATA spare parts
269026107702	OIL SEAL-SPEEDO SHAFT	TATA spare parts
269026107703	OIL SEAL (SPEEDO SHAFT)	TATA spare parts
269026107704	OIL SEAL-SPEEDO SHAFT	TATA spare parts
269026107705	OIL SEAL-SPEEDO SHAFT	TATA spare parts
269026107706	OIL SEAL-SPEEDO SHAFT	TATA spare parts
269026107707	OIL SEAL-SPEEDO SHAFT	TATA spare parts
269026107709	OIL SEAL-SPEEDO SHAFT	TATA spare parts
269026107710	OIL SEAL-SPEEDO SHAFT	TATA spare parts
269026200131	ASSYBRGWITH SNAP RING-L/S REAR END	TATA spare parts
269026203106	CYLINDRICAL ROLLER BEARING-L/S	TATA spare parts
269026203109	N/CAGE 5TH GEAR	TATA spare parts
269026203110	CYLINDRICAL ROLLER BEARING-L/S	TATA spare parts
269026203112	CYLINDRICAL ROLLER BEARING-L/S	TATA spare parts
269026203116	DEEP GR. BALL BRG NRB	TATA spare parts
269026203118	CYLINDRICAL ROLLER BEARING-L/S	TATA spare parts
269026203120	BALL BRG.WITH SNAP RING (L/S REAR)	TATA spare parts
269026203121	BALL BRG.WITH SNAP RING (L/S REAR)	TATA spare parts
269026203122	BALL BRGWITH SNAP RING (L/S REAR),	TATA spare parts
269026203123	CYLINDRICAL ROLLER BEARING-L/S	TATA spare parts
269026203401	BUSH 5TH GEAR L/S	TATA spare parts
269026203803	SYNCHROCONE 1/2 SPEED	TATA spare parts
269026203804	SYNCHROCONE 3/4/5 SPEED BRASS VERSION.	TATA spare parts
269026203805	SYNCHROCONE-3RD/4TH & 5TH SPEED	TATA spare parts
269026204607	ENGAGING GEAR 3/4 SPEED	TATA spare parts
269026204609	ENGAGING GEAR 1/2 SPEED	TATA spare parts
269026204611	SHIFTER SLEEVE-3RD/4TH SPEED	TATA spare parts
269026204612	SHIFTER SLEEVE (5TH SPEED)	TATA spare parts
269026204613	ENGAGING GEAR (1/2) SINT SOFT VERSION	TATA spare parts
269026204617	SHIFTER SLEEVE 3RD/4TH SPEED	TATA spare parts
269026205415	2nd gear lay shaft-NLS-5426	TATA spare parts
269026205416	LAYSHAFT1ST GEAR(DEEPER RATIO-3.64) MP	TATA spare parts
269026207801	CAP LAYSHAFT	TATA spare parts
269026208001	SCREW SPEEDO LOCK PLATE	TATA spare parts
269026208204	LOCK PLATE SPEEDO GEAR	TATA spare parts
269026208601	CIRCLIP-L/S	TATA spare parts
269026208613	SPACER L/S	TATA spare parts

269026208701	SPRING (SYNCHRO)	TATA spare parts
269026209901	CARRIER (1/2 SPEED)	TATA spare parts
269026209902	CARRIER (3/4/5 SPEED)	TATA spare parts
269026209905	SPEEDO ADAPTOR	TATA spare parts
269026209906	SLEEVE 1/2 SYNCHRO	TATA spare parts
269026257706	OIL SEAL (INPUT SHAFT)	TATA spare parts
269026257709	OIL SEAL-INPUTSHAFT	TATA spare parts
269026257710	OIL SEAL (INPUT SHAFT) BS1/2/3/4/6	TATA spare parts
269026257711	OIL SEAL (INPUT SHAFT)	TATA spare parts
269026258201	INPUTSHAFT COVER	TATA spare parts
269026300107	SUB ASSY. DIFFERENTIAL	TATA spare parts
269026300110	B.J. SET -GKN (RUBBER)	TATA spare parts
269026300111	T.J.SET LH -GKN	TATA spare parts
269026300112	T.J.SET RH GKN	TATA spare parts
269026300114	TJ BOOT SET	TATA spare parts
269026300120	ASSY FRT STRUT COMP-LH ABS	TATA spare parts
269026300122	SERVICE KIT SEAL BJ	TATA spare parts
269026300123	SERVICE KIT SEAL TJ	TATA spare parts
269026300131	BJ BOOT SET TPE	TATA spare parts
269026300135	DRIVE SHAFT - RH	TATA spare parts
269026303201	COLLARED SCREW	TATA spare parts
269026305102	SPIDER	TATA spare parts
269026305104	DIFFERENTIAL RING	TATA spare parts
269026305411	SPEEDO GEAR	TATA spare parts
269026307710	O/S DRIIVE SHAFT	TATA spare parts
269026308201	WASHER (DIFFERENTIAL )	TATA spare parts
269026308202	WASHER (DIFFERENTIAL)	TATA spare parts
269026308203	WASHER (DIFFERENTIAL)	TATA spare parts
269026308204	WASHER (DIFFERENTIAL)	TATA spare parts
269026308205	WASHER (DIFFERENTIAL)	TATA spare parts
269026308301	SHIM	TATA spare parts
269026308302	SHIM	TATA spare parts
269026308303	SHIM	TATA spare parts
269026308304	SHIM	TATA spare parts
269026353104	NEEDLE BUSH SKEWED	TATA spare parts
269026510105	SHAFT SELECTOR/SHIFTING	TATA spare parts
269026513201	LOCKING SCREW	TATA spare parts
269026513701	SHIFTER DOG (REV SPEED)	TATA spare parts
269026513703	SHIFTER DOG (3/4)	TATA spare parts
269026515102	SHIFTER DOG (1/2)	TATA spare parts
269026515108	LEVER SELECTION/SHIFTING	TATA spare parts
269026515301	GASKET DETENT PLATE	TATA spare parts
269026516703	PIN INTERLOCK FINGER	TATA spare parts
269026516705	SPIRAL PIN	TATA spare parts
269026517701	RUBBER BELLOW SHIFT SHAFT	TATA spare parts
269026517706	O/S -SEL/SHIFTER SHAFT	TATA spare parts
269026517709	O/S INTE. SEL & SHIFTER SHAFT	TATA spare parts

269026518203	BELLOW HOLDER	TATA spare parts
269026518704	SPRING-DETENT	TATA spare parts
269026518705	SPRING WASHER (CRINKLED)	TATA spare parts
269026518710	SPRING DETENT 5/REV	TATA spare parts
269026519901	INTERLOCK PIECE	TATA spare parts
269026800103	BRACKET GEARBOX END	TATA spare parts
269026800108	SHIFT LINK	TATA spare parts
269026800110	ASSY SHIFTING YOKE	TATA spare parts
269026800112	GEAR SHIFT LEVER KNOB	TATA spare parts
269026800113	G SHIFT LEVER KNOB 4SPEED	TATA spare parts
269026800118	MTG.PLATE G.S.LEVER GUIDE	TATA spare parts
269026800122	ASSY. YOKE (EXT.ARM)	TATA spare parts
269026800133	ASSY.PIN-G.S.LINKAGE	TATA spare parts
269026803401	SPACER (EXTENTION ARM)	TATA spare parts
269026803404	BUSH SHIFTING YOKE	TATA spare parts
269026803405	BUSH (SHIFTING YOKE)	TATA spare parts
269026806303	BUSH G.S.LEVER BALL SEAT	TATA spare parts
269026806310	COLLAR BUSH (SHIFT LINK,LEVER SIDE)	TATA spare parts
269026806313	BASE PLATE (CONSOLE BELLOW)	TATA spare parts
269026806703	PIN	TATA spare parts
269026806708	PIN (EXTENSION ARM)	TATA spare parts
269026807701	RUB BUSH EXTN ARM G.B END	TATA spare parts
269026807706	BELLOW SHIFTING BLOCK	TATA spare parts
269026807708	RUB BOOT G.S.LEVER GUIDE	TATA spare parts
269026808218	WASHER	TATA spare parts
269026808603	SPACER (SHIFTING BLOCK)	TATA spare parts
269026809907	BALL (GEAR SHIFT LEVER)	TATA spare parts
269125100101	SUB.ASSY.CLUTCH HOUSING LPS 3516TC	TATA spare parts
269125100102	ASSY CLUTCH HSG W/REL YOKE COMPLETE	TATA spare parts
269125108201	COVER	TATA spare parts
269126000110	KIT-GASKET G600 GEAR BOX	TATA spare parts
269126010105	ASSY GEAR BOX GB60 - 3516 TC	TATA spare parts
269126010108	ASSY GBS60-6/9.19 F/REM COMP-RHD	TATA spare parts
269126010109	ASSY GBS60-5/7.58 RHD COMP WITH 30 DEG	TATA spare parts
269126010115	ASSY GBS60 6/6.58 GEAR BOX COMP. RH	TATA spare parts
269126010115AE	ASSY GEAR BOX G 600 715	TATA spare parts
269126010119	ASSY GBS600-6/9.19 RHD LPS3015TC	TATA spare parts
269126010121	ASSY GBS600-6/8.47 RHD LPT2516TC	TATA spare parts
269126010122	ASSY GBS600-6/8.47 RHD LPT2515TC	TATA spare parts
269126010128	ASSY G600-6/8.47 GBOX WITH APP MK-III	TATA spare parts
269126010129	ASSY G600-6/8.47 TWIN SPLIT GEAR 165D/CF	TATA spare parts
269126010134	ASSY G600-6/9.19 WITH 150DIA C/FLANGE RH	TATA spare parts
269126010137	ASSY G600-6/8.47 GEARBOX W/PTO	TATA spare parts
269126010144	ASSY GBS60-6/8.47 RHD COMP.WITH 30DEG	TATA spare parts
269126010146	ASSY G600-6/8.47 GBOX WTH65R SHT.LEV O/S	TATA spare parts
269126010148	GEAR BOX G600-6/8.47 WTH65R SHT.LVR I/S	TATA spare parts
269126010150	ASSY. GEAR BOX (G600-6/6.58) RHD BS2/3	TATA spare parts

269126010151	ASSY G600-6/8.47 CABLESHIFT RE SL.LVERUP	TATA spare parts
269126010152	ASSY.G600-6/6.58 LHD OD W*30DEG.SL.LEVER	TATA spare parts
269126010153	ASSY G600-6/8.47 GEARBOX WITH PTO.COMPL	TATA spare parts
269126010154	ASSY G600-6/8.47 SUIT PTO W/SOFT REV.SPR	TATA spare parts
269126010155	ASSY. GEAR BOX COMP. G600-6/8.47 BS1/2/3	TATA spare parts
269126010156	ASSY G600-6/9.19 GBOX W/SOFT REV.SPRING	TATA spare parts
269126010159	ASSY. GEAR BOX G600-6/6.58 W/150D BS2	TATA spare parts
269126010162	ASSY G600-6/9.19 RE BUS.CABLE SHIF 165CF	TATA spare parts
269126010165	ASSY G600-6/6.58W/150D.C/FL.SOFT REV SPR	TATA spare parts
269126010166	ASSY G600-6/9.19 GEAR BOX COMPL.	TATA spare parts
269126010167	G600-6/8.47 GBOX.W/150DIA C/FLG W/O PTO	TATA spare parts
269126010168	ASSY G750-6/8.47 WITH APP MK-III COMPL.	TATA spare parts
269126010172	ASSY G600-6/6.58 W/150D C/FLG.30DEG.SEL.	TATA spare parts
269126010173	ASSY G600-6/9.19 W/150D CF.SHT LV 65R OS	TATA spare parts
269126010175	ASSY G750-6/8.47 W/150D SER/FLG SUT APP3	TATA spare parts
269126010177	ASSY G600-6/9.19 C/F 150D REV SOFT SPR.	TATA spare parts
269126010180	ASSY G600-6/8.47 D165 C/F RE LPO1615 BUS	TATA spare parts
269126010182	ASSY G600-6/6.58 150C/F D/SHIFT PROV/APP	TATA spare parts
269126010183	ASSY G600-6/6.58 150D C/FLG DIRECT SHIFT	TATA spare parts
269126010186	ASSY G600-6/6.58 SUIT CABLE SHIFT HIGHDK	TATA spare parts
269126010187	ASSY. GEAR BOX COMP.LHD(G600-6/8.47)E1/2	TATA spare parts
269126010188	ASSY G600-6/6.58 W 130D C/FLG 30DEG.SEL	TATA spare parts
269126010189	ASSY G600-6/6.58W 130D.FL.SOFT.REV.SPR.	TATA spare parts
269126010190	ASSY G600-6/6.58 W/150D C/FLG & 30D.SL	TATA spare parts
269126010194	ASSY. GEAR BOX G750 6/8.47 BS2/3	TATA spare parts
269126010197	ASSY G600-6/6.58 150D/CF SUIT APPMK-III	TATA spare parts
269126010199	ASSY G680-6/9.19 D150 C/FLG 30DEG.SEL.LV	TATA spare parts
269126010201	ASSY G600-6/6.58 NO.C/FLG.30D SEL LEVER	TATA spare parts
269126010202	ASSY G600-6/8.47 NO.C/FLG CABLE SHIFT RE	TATA spare parts
269126010206	GEAR BOX ASSY G600-6/8.47 APP FR	TATA spare parts
269126010210	ASSY G600-6/6.58 POWER SHIFT SUIT CABLE	TATA spare parts
269126010213	ASSY G600-6/8.47 W150D SERR.FLG.30SL.LEV	TATA spare parts
269126010214	ASSY GEAR BOX G600-6/8.47 W/150D.SER	TATA spare parts
269126010217	ASSY G600-6/6.58 GEAR BOX COMPLETE LHD W	TATA spare parts
269126010222	G/BOX G600-6/9.19150D/SER.C/FLG.85R/30DE	TATA spare parts
269126010231	ASSY G600-6/9.19 GBOX WITH PTO COMPL.	TATA spare parts
269126010232	ASSY G600-6/9.19 SUIT PTO D130F 30D SOFT	TATA spare parts
269126010233	GEAR BOX G600-6/6.58 LPT 1618 LHD PTO(0.	TATA spare parts
269126010237	GEAR BOX G600-6/6.58 LHD PTO(0.890)RUSSI	TATA spare parts
269126010239	ASSY G600-6/8.47 LHD GBOX WITH PTO(0.890	TATA spare parts
269126010242	ASSY GEAR BOX G750-9.19 COMPLETE	TATA spare parts
269126010246	GEARBOX ASSY G600-6/8.47	TATA spare parts
269126010255	ASSY G600-6/6.58D/SHIFT 150SER CF SUITAP	TATA spare parts
269126010256	ASSY G600-6/6.58 150SER CFL.DIRECT SHIFT	TATA spare parts
269126010258	ASSY. GEAR BOX G600-6/8.47 D150SER BS2	TATA spare parts
269126010271	ASSY G600-6/8.47 DIRECT SHIFT GEARBOX WI	TATA spare parts
269126010273	GEAR BOX G600 / 8.47R	TATA spare parts



269126010278	GEAR BOX ASSY G600-6/6.58 LHD	TATA spare parts
269126010283	ASSY G600-6/8.47 DIRECTSHIFT NEW DIA 150	TATA spare parts
269126010285	GEARBOX ASSY G600/6 SP 7.61	TATA spare parts
269126010286	GEAR BOX ASSY G600-6/8.47 WITH PTO PUMP	TATA spare parts
269126010288	GEARBOX ASSY G600/6-DB DI/SHIFT	TATA spare parts
269126010293	ASSY GEAR BOX G600-6/8.47	TATA spare parts
269126010295	GEARBOX ASSY G600-6/8.47	TATA spare parts
269126010297	G600-6/7.61 WITH D150 ORG.CL MOD TOP	TATA spare parts
269126010300	GEAR BOX TUBLER COVER G600-6.6.58 D150FL	TATA spare parts
269126010304	GEARBOXASSY.G600-6/7.61PTO(IPH)	TATA spare parts
269126010308	GEARBOX ASSY G600-6/7.61 D150 SER. C/FL	TATA spare parts
269126010309	GEAR BOX G600-6/7.61 352DIA. ORGA	TATA spare parts
269126010316	GEAR BOX G600-6.7.61 130D C.FLG WITH 30	TATA spare parts
269126010318	GEAR BOX ASSY G600-6/7.61 NON PNEUMATIC	TATA spare parts
269126010330	GEAR BOX ASSY	TATA spare parts
269126010337	GEAR BOX ASSY WITH PTO	TATA spare parts
269126010339	ASSY. GEAR BOX G600-6-6.58 LHD BS2	TATA spare parts
269126010349	GEAR BOX ASSY	TATA spare parts
269126010350	GEAR BOX ASSY	TATA spare parts
269126010352	GEAR BOX ASSY	TATA spare parts
269126010355	GEAR BOX ASSY	TATA spare parts
269126010357	GEAR BOX ASSY	TATA spare parts
269126010364	GEAR BOX ASSY	TATA spare parts
269126010379	GEAR BOX ASSY	TATA spare parts
269126010386	GEAR BOX ASSY	TATA spare parts
269126010392	GEAR BOX ASSY	TATA spare parts
269126010394	GEAR BOX ASSY	TATA spare parts
269126020101	G750/6-DA GEARBOX W/150 SERRATED C/F	TATA spare parts
269126020103	ASSY G600-6/6.58 W/150DIA.SER C/F R85/30	TATA spare parts
269126020109	ASSY. GEAR BOX COMP. LHD (G600-6/6.58)	TATA spare parts
269126020110	ASSY G750-6/9.19 WITH PTO (RATIO-0.637)	TATA spare parts
269126020117	ASSY G750-6/8.47 TWINCON150SER R85VER U	TATA spare parts
269126020118	ASSY GEAR BOX G750-6/9.19 TWINCONE SUIT	TATA spare parts
269126020119	ASSY. GEARBOX COMP. G750-6/6.58 BS2/3/4	TATA spare parts
269126020124	ASSY G750-6/9.19 TWIN CONE R105 VER UP	TATA spare parts
269126020125	ASSY G600-6/8.47 LHD D150SER D/FLG	TATA spare parts
269126020126	GEAR BOX G750/6-8.47 TWINCONE	TATA spare parts
269126020127	ASSY G750-6/6.58GBOX WITH D150SER C/FLG	TATA spare parts
269126020129	ASSY G750-6/6.58TWINCONE POWERSHIFT RETA	TATA spare parts
269126020130	ASSY. GEAR BOX G750 W/TWIN CONE BS3/4	TATA spare parts
269126020132	ASSY GEAR BOX G750/6-8.47 TWINCONE C/FLG	TATA spare parts
269126020136	ASSY.G600-6/6.58GBOX WITH D130 C/FLG POW	TATA spare parts
269126020138	ASSY G600-6/6.58 W/150D SER.C/FLG. SUIT	TATA spare parts
269126020140	GEARBOX ASSY G600-6/8.47 LHD	TATA spare parts
269126020142	GEARBOX ASSY G600-6/6.58 DI/SHIFT	TATA spare parts
269126020143	ASSY G750-6/9.19 TWINCONE GEARBOX	TATA spare parts
269126020149	ASSY G600-6/6.58 DIRECT SHIFT GEARBOX	TATA spare parts

269126020151	GEARBOX ASSY G600-6/8.47 LHD	TATA spare parts
269126020152	ASSY G600-6/6.58 DIRECT SHIFT GEARBOX WI	TATA spare parts
269126020154	ASSY. GEAR BOX G600 W/150D SER C/FLG BS1	TATA spare parts
269126020155	G 750 GEAR BOX	TATA spare parts
269126020157	GEAR BOX G600-6/6.58 LPT 1116 LHD W/130D	TATA spare parts
269126020158	G/BOX G750-6/6.58TWINCONE NO C/FLG R105/	TATA spare parts
269126020159	ASSY G600-5/6.58(5SPEED GBOX)W/130D C/FL	TATA spare parts
269126020160	G600/6-OA WITH D150 C/FLG LONG M/SHAFT	TATA spare parts
269126020166	GEAR BOX G750/6-6.58 TWINCONE GBOX SUIT	TATA spare parts
269126020169	ASSY GEAR BOX G750.6-8.47 TWINCONE C.FLG	TATA spare parts
269126020173	ASSY G600-6/8.47 GBOX D150 SER.C/FLG R85	TATA spare parts
269126020175	ASSY G600-6/6.58 GEAR BOX COMPLETE	TATA spare parts
269126020188	ASSY G600-6/9.19 W/150D SER.FLG.TOP COVE	TATA spare parts
269126020197	ASSY. GEAR BOX G750 6/6.58 BS4	TATA spare parts
269126020205	ASSY G 600-6/7.61 GEAR BOX WITH REAR PTO	TATA spare parts
269126020209	ASSY G750-6.9.17 HELICAL 1.REV(2.3SHALLO	TATA spare parts
269126020211	ASSY GEAR BOX G750-6/8.45 SUIT APP	TATA spare parts
269126020212	GEAR BOX G750-6/8.45 HEL. 1/REV(2/3SHALL	TATA spare parts
269126020213	GEAR BOX ASSY	TATA spare parts
269126020217	ASSY G750-6/9.19 WITH APP/SHIFT LEV R85	TATA spare parts
269126020218	GEARBOX ASSY G750-9.19 1518 ULTRA	TATA spare parts
269126020219	ASSY G750-6/8.45 HELICAL/LEVR85/V.UP	TATA spare parts
269126020222	G750-6/9.17 HEL. 1/REV(2/3SHALLOW) IPH	TATA spare parts
269126020227	GEAR BOX TWINCN G750/6-9.19SHORT TOPCOVE	TATA spare parts
269126020228	GEAR BOX ASSY	TATA spare parts
269126020229	GEAR BOX ASSY WITH AMT	TATA spare parts
269126020237	GEAR BOX ASSY BS6	TATA spare parts
269126020238	GEAR BOX ASSY BS6	TATA spare parts
269126020242	GEAR BOX ASSY	TATA spare parts
269126020248	GEAR BOX ASSY	TATA spare parts
269126020250	GEAR BOX ASSY	TATA spare parts
269126020252	GEAR BOX ASSY	TATA spare parts
269126020255	GEAR BOX ASSY BS6	TATA spare parts
269126020260	GEAR BOX ASSY	TATA spare parts
269126020262	GEAR BOX ASSY	TATA spare parts
269126020265	GEAR BOX ASSY BS6	TATA spare parts
269126020268	GEAR BOX ASSY BS6	TATA spare parts
269126020271	GEAR BOX ASSY BS6	TATA spare parts
269126020272	ASSY GEAR BOX COMPLETE( G750-6/9.19 TWIN	TATA spare parts
269126020273	GEAR BOX ASSY BS6	TATA spare parts
269126020275	GEAR BOX ASSY BS6	TATA spare parts
269126020276	GEAR BOX ASSY BS6	TATA spare parts
269126020278	GEAR BOX ASSY BS6	TATA spare parts
269126020282	GEAR BOX ASSY BS6	TATA spare parts
269126020283	GEAR BOX ASSY BS6	TATA spare parts
269126020285	GEAR BOX ASSY BS6	TATA spare parts
269126020286	GEAR BOX ASSY WITH PTO BS6	TATA spare parts

269126020288	GEAR BOX ASSY BS6	TATA spare parts
269126020290	GEAR BOX ASSY BS6	TATA spare parts
269126020293	GEAR BOX ASSY BS6	TATA spare parts
269126020296	GEAR BOX ASSY BS6-PH2	TATA spare parts
269126020300	GEAR BOX ASSY BS6-PH2	TATA spare parts
269126020303	GEAR BOX ASSY BS6-PH2	TATA spare parts
269126100104	ASSY. GEAR BOX HSG. FRT+RR HALF BS1-4	TATA spare parts
269126100106	ASSY HSG-OVER DRIVE	TATA spare parts
269126100109	ASSY GBOX HSG.FRONT+REAR(OVERDRIVE)REBUS	TATA spare parts
269126100110	ASSY GEAR BOX HOUSING FRONT+REAR HALF	TATA spare parts
269126100113	ASSY HOUSING FRONT+REAR HALF (G750)	TATA spare parts
269126100117	ASSY GEARBOX HOUSING REAR+FRONT HALF	TATA spare parts
269126100118	ASSY HOUSING FRONT+REAR HALF(OVER DRIVE)	TATA spare parts
269126100121	ASSY HOUSING FRONT+REAR(HIGHDECK P/SHIFT	TATA spare parts
269126100129	ASSY. GEAR BOX HSG. FRT & RR HALF BS1-4	TATA spare parts
269126100130	ASSY. HOUSING FRONT+REAR HALF	TATA spare parts
269126100131	ASSY HOUSING REAR & FRONT HALF OVERDRIVE	TATA spare parts
269126100137	ASSY HSG FRONT & REAR SUIT RETARDER(OD)	TATA spare parts
269126100139	GEAR BOX HOUSING ASSY FRONT & REAR-HALF	TATA spare parts
269126100147	ASSY HOUSING REAR & FRONT HALF OVERDRIVE	TATA spare parts
269126100151	GEAR BOX HOUSING ASSY FRONT & REAR-HALF	TATA spare parts
269126100152	GEAR BOX HOUSING ASSY FRONT & REAR-HALF	TATA spare parts
269126100154	GEAR BOX HOUSING ASSY FRONT & REAR-HALF	TATA spare parts
269126100161	GEAR BOX HOUSING ASSY FRONT & REAR-HALF	TATA spare parts
269126100166	GEAR BOX HOUSING ASSY FRONT & REAR-HALF	TATA spare parts
269126100167	ASSY HOUSING REAR & FRONT HALF-G600.OD.W	TATA spare parts
269126100169	ASSY HSG-G600/DD/W/OBALLPIN	TATA spare parts
269126100170	HOUSING ASSY FRONT & REAR /DD/NO M10	TATA spare parts
269126100175	GEAR BOX HOUSING ASSY FRONT & REAR-HALF	TATA spare parts
269126100177	ASSY HOUSING REAR & FRONT G750/DD	TATA spare parts
269126100179	GEAR BOX HOUSING ASSY FRONT - REAR-HALF	TATA spare parts
269126100187	GEAR BOX HOUSING ASSY FRONT & REAR-HALF	TATA spare parts
269126100190	GEAR BOX HOUSING ASSY FRONT & REAR-HALF	TATA spare parts
269126100197	GEAR BOX HOUSING ASSY FRONT & REAR-HALF	TATA spare parts
269126100199	GEAR BOX HOUSING ASSY FRONT & REAR	TATA spare parts
269126100202	GEAR BOX HOUSING ASSY FRONT & REAR	TATA spare parts
269126100203	GEAR BOX HOUSING ASSY FRONT & REAR-HALF	TATA spare parts
269126103706	GEARBOX HOUSING FRONT HALF (G600-DD MAT	TATA spare parts
269126103709	HOUSING REAR HALF (FOR R.E. BUS)	TATA spare parts
269126103714	GEARBOX HOUSING REAR HALF	TATA spare parts
269126103717	HOUSING REAR HALF (FG300)W/O HOLE BALL/P	TATA spare parts
269126103719	HOUSING FRONT HALF (G600-DD MAT-FG300)	TATA spare parts
269126103812	AL GEARBOX HOUSING FRONT HALF(G600-MK II	TATA spare parts
269126103813	AL GBOX HSG FRONT HALF(G600-MK II)/DD	TATA spare parts
269126103820	AL GEARBOX HOUSING REAR HALF G600	TATA spare parts
269126105302	GASKET G600	TATA spare parts
269126105303	GASKET-HOUSING FRONT & REAR	TATA spare parts

269126106301	OIL CATCHER	TATA spare parts
269126106701	PIN-GEAR BOX HOUSING	TATA spare parts
269126107202	SEALING PLUG	TATA spare parts
26912610720290	SEALING PLUG - LOCTITE COATED	TATA spare parts
269126107204	SEALING PLUG	TATA spare parts
269126108201	PLUG-SHIFTER SHAFT-REAR	TATA spare parts
269126108202	COVER-OIL CATCHER	TATA spare parts
269126108203	GEARBOX NUMBER PLATE BS6	TATA spare parts
269126108204	GEARBOX NUMBER PLATE	TATA spare parts
269126159901	ADAPTOR	TATA spare parts
269126200118	ASSY COUPLING FLANGE	TATA spare parts
269126200130	ASSY.ENGAGING GEAR (4/5)	TATA spare parts
269126200133	ASSY. HELICAL GEAR 2ND SPEED(36T) BS2/3	TATA spare parts
269126200134	ASSY.ENGAGING GEAR 1/2 GEAR)	TATA spare parts
269126200135	1ST GEAR MAIN SHAFT(43T) BS2/3	TATA spare parts
269126200136	3RD GEAR MAIN SHFT(30T)6SP BS2/3	TATA spare parts
269126200137	4TH GEAR MAIN SHFT(24 IT) BS2	TATA spare parts
269126200138	ASSY.5TH GEAR MAIN SHAFT	TATA spare parts
269126200142	ASSY. NEEDLE CAGE-1ST/2ND/3RD GEAR BS1-6	TATA spare parts
269126200143	ASSY. NEEDLE CAGE-4TH GEAR BS1/2/3/4/6	TATA spare parts
269126200145	ASSY ENGAGING GEAR (3RD/4TH SPEED)	TATA spare parts
269126200146	ASY OVR DRIVE GEAR-M/SHFT(18T)	TATA spare parts
269126200147	ASSY. 4 TH SPEED GEAR ON MAIN SHAFT BS3	TATA spare parts
269126200153	ASSY ENGAGING GEAR (3RD/4TH)	TATA spare parts
269126200162	ASSY ENGAGING GEAR (5TH / 6TH SPEED) BS6	TATA spare parts
269126200163	ASY 5TH SP.GEAR-MOD ANG(19T)	TATA spare parts
269126200164	ASSY COUPLING FLANGE-150 DIA	TATA spare parts
269126200165	ASSY COUPLING FLANGE-165 DIA	TATA spare parts
269126200166	ASSY SPEEDO PINION (NYLON)	TATA spare parts
269126200167	ASSY SPEEDO GEAR [NYLON](MAIN SHAFT)	TATA spare parts
269126200171	ASSY ENGAGING GEAR(5TH/DS)[THRUST BRG.AG	TATA spare parts
269126200172	ASSY. COUPLING FLANGE (130 DIA)BS1/2/3/4	TATA spare parts
269126200173	ASSY COUPLING FLANGE (150 DIA)	TATA spare parts
269126200174	ASSY COUPLING FLANGE (165 DIA)	TATA spare parts
269126200180	ASSY ENGAGING GEAR (1ST/2ND SPEED)	TATA spare parts
269126200182	SYNCHRO KIT-G600 GEARBOX	TATA spare parts
269126200184	ASSY. GEAR (1ST SPEED) BS1/2/3/4	TATA spare parts
269126200184AE	ASSY. GEAR (1ST SPEED) 715	TATA spare parts
269126200185	ASSY. HELICAL GEAR (2ND SPEED) BS1/2/3/4	TATA spare parts
269126200186	ASSY. HELICAL GEAR (3RD SPEED) BS1/2/3/4	TATA spare parts
269126200187	ASSY. HELICAL GEAR (4TH SPEED) BS1/2/3/4	TATA spare parts
269126200188	ASSY.HELICAL GEAR 4TH SPEED OVER DRIVE	TATA spare parts
269126200189	ASSY HELICAL GEAR (5TH SPEED) BS1/2/3/4	TATA spare parts
269126200190	ASSY OVER DRIVE GEAR (MAIN SHAFT)	TATA spare parts
269126200191	ASSY ENGAGING GEAR (1ST/2ND SPEED)	TATA spare parts
269126200192	ASSY ENGAGING GEAR (3RD/4TH SPEED)	TATA spare parts
269126200193	ASSY COUPLING FLANGE(DIA 150 SERRATED)	TATA spare parts

269126200211	ASSY KIT MAINSHAFT DRIVE SHAFT(9.19RATIO	TATA spare parts
269126200212	KIT-MAINSHAFT & DRIVE SHAFT(8.47) BS2/3	TATA spare parts
269126200217	ASSY ENGAGING GEAR (1ST / 2ND SPEED) BS6	TATA spare parts
269126200220	ASSY SYNCHRO CONE (TWIN CONE VERSION)	TATA spare parts
269126200232	ASSY ENGAGING GEAR(D/SHAFT)G600 5SPEED.	TATA spare parts
269126200240	ASSY.SYNCHRO CONE(NEW TWINCONE VERSION)	TATA spare parts
269126200242	ASSY 4TH GEAR M/S G600 (RATIO:7.61)	TATA spare parts
269126200246	ASSY.RETRO KIT M.S.WITH WIDER SNAP RING	TATA spare parts
269126200250	ASSY. RETRO KIT M/SHAFT WIDER SNAP RING	TATA spare parts
269126200258	ASSY 4TH SPEED GEAR MAIN SHAFT	TATA spare parts
269126200259	ASSY OVER DRIVE GEAR MAIN SHAFT	TATA spare parts
269126200260	ASSY. SYNCHRO CONE(TWINCONE)BS1/2/3/4	TATA spare parts
269126200268	ASSY. SYNCHRO CONE(NEW TWIN)	TATA spare parts
269126200271	ASSY ENGAGING GEAR (3RD / 4TH SPEED) BS6	TATA spare parts
269126200278	COVER ASSY REAR BS6	TATA spare parts
269126200286	MAIN SHAFT ASSY (G750-8.47 DD) BS6	TATA spare parts
269126203103	TAPER ROLLER BRG. 28580/521 BS1/2/3/4	TATA spare parts
269126203104	NEEDLE CAGE (1ST/2ND/3RD GEAR)	TATA spare parts
269126203105	NEEDLE CAGE-4TH GEAR	TATA spare parts
269126203106	NEEDLE CAGE (REV.GEAR) BS1-6	TATA spare parts
269126203107	TAPER ROLLER BEARING	TATA spare parts
269126203110	NEEDLE CAGE-REV.GEAR	TATA spare parts
269126203111	NEEDLE CAGE 1ST SPEED BS1/2/3/4/6	TATA spare parts
269126203111AE	NEEDLE CAGE 1ST SPEED 715	TATA spare parts
269126203113	NEEDLE CAGE-1ST/2ND/3RD GEAR	TATA spare parts
269126203115	NEEDLE CAGE-REV.GEAR	TATA spare parts
269126203117	NEEDLE CAGE DOUBLE ROW 4TH GEAR	TATA spare parts
269126203118	TAPER ROLLER BEARING	TATA spare parts
269126203119	TAPER ROLLER BEARING	TATA spare parts
269126203120	NEEDLE CAGE DOUBLE ROW BS1/2/3/4/6	TATA spare parts
269126203120AE	NEEDLE CAGE DOUBLE ROW 715	TATA spare parts
269126203121	NEEDLE CAGE DOUBLE ROW 1ST SPEED	TATA spare parts
269126203122	NEEDLE CAGE DOUBLE ROW	TATA spare parts
269126203123	NEEDLE GAGE DOUBLE ROW	TATA spare parts
269126203124	NEEDLE CAGE DOBULE ROW	TATA spare parts
269126203125	NEEDLE CAGE DOBULE ROW	TATA spare parts
269126203126	NEEDLE CAGE DOBULE ROW	TATA spare parts
269126203127	NEEDLE CAGE 1ST SPEED	TATA spare parts
269126203128	NEEDLE CAGE DOBULE ROW	TATA spare parts
269126203129	NEEDLE CAGE DOBULE ROW	TATA spare parts
269126203130	NEEDLE CAGE DOUBLE ROW	TATA spare parts
269126203131	NEEDLE CAGE DOUBLE ROW	TATA spare parts
269126203132	NEEDLE CAGE DOBULE ROW	TATA spare parts
269126203133	NEEDLE CAGE DOUBLE ROW	TATA spare parts
269126203134	TAPER ROLLER BEARING	TATA spare parts
269126203135	TAPER ROLLER BEARING	TATA spare parts
269126203140	NEEDLE CAGE 1ST SPEED	TATA spare parts

269126203141	NEEDLE CAGE 2ND SPEED	TATA spare parts
269126203142	NEEDLE CAGE 3RD SPEED	TATA spare parts
269126203143	NEEDLE CAGE 4TH/REV SPEED	TATA spare parts
269126203144	NEEDLE CAGE 5TH SPEED	TATA spare parts
269126203420	SPEEDO ADAPTER	TATA spare parts
269126203426	SPEEDO ADAPTOR (REAR COVER (UPPER))	TATA spare parts
269126203703	REAR COVER-GEAR BOX HOUSING-LOWER	TATA spare parts
269126203707	REAR COVER-UPPER	TATA spare parts
269126203708	REAR COVER GEAR BOX HOUSING COVER-LOWER	TATA spare parts
269126203709	REAR COVER (UPPER) G750 BS1/2/3/4	TATA spare parts
269126203710	REAR COVER (UPPER)	TATA spare parts
269126203711	INTEGRAL REAR COVER CUM ADAPTOR(RETARDE	TATA spare parts
269126203712	INTEGRAL REAR COVER CUM ADAPTOR	TATA spare parts
269126203714	COVER REAR	TATA spare parts
269126203802	SYNCHRO CONE	TATA spare parts
269126203804	COVER REAR UPPER (G600)	TATA spare parts
269126203805	COVER REAR UPPER (G750)	TATA spare parts
269126203806	COVER REAR UPPER (G750 AMT)	TATA spare parts
269126203807	COVER REAR-UPPER	TATA spare parts
269126204301	CIRCLIP-1.8 THK.	TATA spare parts
269126204302	CIRCLIP-1.9 THK.	TATA spare parts
269126204303	CIRCLIP-2.0 THK.	TATA spare parts
269126204304	CIRCLIP-2.1 THK.	TATA spare parts
269126204305	CIRCLIP 2.2 THK.	TATA spare parts
269126204306	CIRCLIP-2.4 THK	TATA spare parts
269126204307	CIRCLIP 2.5 THK	TATA spare parts
269126204308	CIRCLIP 2.6 THK	TATA spare parts
269126204309	CIRCLIP-2.7 THK	TATA spare parts
269126204310	CIRCLIP-2.3 THK.	TATA spare parts
269126204311	CIRCLIP-2.4 THK	TATA spare parts
269126204312	CIRCLIP-2.8 THK.	TATA spare parts
269126204313	CIRCLIP-2.3 THK	TATA spare parts
269126204314	CIRCLIP-2.4 THK	TATA spare parts
269126204315	CIRCLIP-2.5 THK	TATA spare parts
269126204316	CIRCLIP-2.6 THK	TATA spare parts
269126204317	CIRCLIP-2.7 THK	TATA spare parts
269126204321	CIRCLIP-2.8 THK	TATA spare parts
269126204322	CIRCLIP-2.9 THK	TATA spare parts
269126204326	CIRCLIP THK - 3.9 MM	TATA spare parts
269126204327	CIRCLIP THK - 4.0 MM	TATA spare parts
269126204328	CIRCLIP THK - 4.1 MM	TATA spare parts
269126204329	CIRCLIP (REV) THICK 2.8	TATA spare parts
269126204330	CIRCLIP (REV) THICK 2.9	TATA spare parts
269126204331	CIRCLIP (REV) THICK 3.0	TATA spare parts
269126204332	CIRCLIP (REV) THICK 3.1	TATA spare parts
269126204333	CIRCLIP (REV) THICK 3.2	TATA spare parts
269126204334	SNAP RING(THK- 2.80)	TATA spare parts

269126204335	SNAP RING(THK.- 2.85)	TATA spare parts
269126204336	SNAP RING(THK.- 2.90)	TATA spare parts
269126204337	SNAP RING(THK.- 2.95)	TATA spare parts
269126204338	SNAP RING(THK.- 3.00)	TATA spare parts
269126204339	SNAP RING(THK.- 3.05)	TATA spare parts
269126204340	SNAP RING(THK.- 3.10)	TATA spare parts
269126204341	SNAP RING(THK.- 3.15)	TATA spare parts
269126204342	SNAP RING(THK.- 3.20)	TATA spare parts
269126204343	SNAP RING(THK.- 3.25)	TATA spare parts
269126204344	SNAP RING (THK-2.80)	TATA spare parts
269126204345	SNAP RING (THK-2.85)	TATA spare parts
269126204346	SNAP RING (THK-2.90)	TATA spare parts
269126204347	SNAP RING (THK-2.95)	TATA spare parts
269126204348	SNAP RING (THK-3.00)	TATA spare parts
269126204349	SNAP RING (THK-3.05)	TATA spare parts
269126204350	SNAP RING (THK-3.10)	TATA spare parts
269126204351	SNAP RING (THK-3.15)	TATA spare parts
269126204352	SNAP RING (THK-3.20)	TATA spare parts
269126204353	SNAP RING (THK-3.25)	TATA spare parts
269126204609	SYNCHRO CONE(51T)	TATA spare parts
269126204612	ENGAG GEAR-4TH.D/SH 5&6 SP(34 IT)	TATA spare parts
269126204615	ENGAG GEAR-1/2GR 6SP(38 IS)	TATA spare parts
269126204616	ENGAG GEAR-REVERSE(32 T/26 IS)	TATA spare parts
269126204617	SYNCHRO RING (4TH GEAR_6SP)	TATA spare parts
269126204618	SHIFTER SLEEVE (51T)(1/2 & 3/4TH) BS1-4	TATA spare parts
269126204621	ENG. GEAR (3/4/6TH SP) (51T/26T) BS1/2/3	TATA spare parts
269126204622	SYNCHRO CONE STEEL	TATA spare parts
269126204623	SYNCHRO CONE (51T) BS1/2/3	TATA spare parts
269126204624	ENGAGING GEAR (REVERSE)	TATA spare parts
269126204625	ENGAGING GEAR (1ST/2ND SPEED)	TATA spare parts
269126204626	ENG. GEAR (3/4TH SP)(51T/26T)(51V/42A)	TATA spare parts
269126204627	ENGAGING GEAR (51T) 5TH/6TH SPEED BS1-4	TATA spare parts
269126204628	SYNCHRO RING (42T/51T)(1/2/3RD SPD)BS1-4	TATA spare parts
269126204629	SYNCHRO RING-4TH SPEED(51T)	TATA spare parts
269126204630	SYNC RING (23T/51T)(5/6TH SPD) BS1/2/3/4	TATA spare parts
269126204631	SHIFTER SLV-1/2 3/4 5/6 SPD(51T)	TATA spare parts
269126204631AE	"SHFTR SLEEVE (1/2,3/4,5/6) -1628"	TATA spare parts
269126204632	INNER CONE (1/2 3/4 SPEED)	TATA spare parts
269126204633	INTERMEDIATE CONE (1/2 3/4 SPEED)	TATA spare parts
269126204635	SYNCHRO CONE 5TH/6TH SPEED BS2/3	TATA spare parts
269126204637	SYNCHRO RING (5TH SPEED)	TATA spare parts
269126204638	SYNCHRONISING CONE(1/2/3 SPEED FORGED)	TATA spare parts
269126204639	INTERMEDIATE CONE (1/2 & 3/4 SPEED)	TATA spare parts
269126204640	ENG. GEAR (48T/48T/34T)(5TH/DS)BS1/2/3/4	TATA spare parts
269126204641	ENGAGING GEAR(1ST/2ND) LOOSE SYN.RING.	TATA spare parts
269126204642	ENG. GEAR(3RD/4TH) LOOSE SYN. RING BS1-4	TATA spare parts
269126204643	SYNCHRO RING(1ST/2ND/3RD)LOOSE RIG BS2/3	TATA spare parts

269126204644	SYNCHRO RING (45T) (4TH SPD) LOOSE BS2/3	TATA spare parts
269126204645	SYNCHRO RING (5TH SPEED) BS2/3	TATA spare parts
269126204646	SYNCHRO CONE (51T)(CARBON) (1/2 3/4) E2	TATA spare parts
269126204647	SYNCHRO CONE (48T)(5/6 CARBON)	TATA spare parts
269126204648	SYNCHRO RING (1/2/3-CARBON LINING)	TATA spare parts
269126204649	SYNCHRO RING(4TH-CARBON LINING)	TATA spare parts
269126204650	SYNCHRO CONE 1/2/3/4 (CARBON) BS1/2/3/4	TATA spare parts
269126204650AE	SYNCHRO-CONE 1/2-3/4.(CARBON) 715	TATA spare parts
269126204650DF	SYNCHRO CONE CARBON - 1/2-3/4	TATA spare parts
269126204651	SYNCHRO CONE (5/6 SPEED) BS1/2/3/4	TATA spare parts
269126204651DF	SYNCHRO-CONE CARBON - 5/6	TATA spare parts
269126204652	SYNCHRO RING 5TH SPEED(48T) BS1/2/3/4	TATA spare parts
269126204653	SYNCHRO RING (3RD SPEED) BS1/2/3/4	TATA spare parts
269126204654	SYNCHRO RING (45T/51T)(4TH SP) BS1/2/3/4	TATA spare parts
269126204655	SYNCHRO CONE (132 DIA.) BS1/2/3/4/6	TATA spare parts
269126204656	SYNCHRO CONE (51T)CARBON LINING BS2/3	TATA spare parts
269126204657	INNER CONE (1/2 CARBON LINING) BS2/3	TATA spare parts
269126204658	ENGAGING GEAR-1ST/2ND (32T)G750 BS1/2/3/4	TATA spare parts
269126204659	ENGAGING GEAR(REVERSE) BS1/2/3/4	TATA spare parts
269126204660	ENGAGING GEAR (1ST/2ND SPEED)TWINCONE	TATA spare parts
269126204661	ENGAGING GEAR(3RD/4TH )TWINCONE BS1- 4	TATA spare parts
269126204663	INTERMEDIATE CONE (1/2/&3/4 SPEED)	TATA spare parts
269126204664	ENGAGING GEAR (REVERSE) G750	TATA spare parts
269126204666	SYNCHRONISING CONE (135DIA WITH NEW TWIN	TATA spare parts
269126204668	INNER CONE (NEW TWINCONE VERSION)	TATA spare parts
269126204669	INTERMEDIATE CONE 1/2/3 SPEED (NEW TWIN	TATA spare parts
269126204670	SHIFTER SLEEVE (1/2/3/4/5/6) BS2/3/4/6	TATA spare parts
269126204674	SYNCHRO CONE (132 DIA.)	TATA spare parts
269126204675	ENGAGING GEAR(3RD/4TH)	TATA spare parts
269126204676	ENGAGING GEAR (3RD/4TH SPEED) BS4	TATA spare parts
269126205101	COUPLING FLANGE	TATA spare parts
269126205108	COUPLING FLANGE (150DIA SERRATED G750)	TATA spare parts
269126205109	COUPLING FLANGE (DIA 150 SERRATED)	TATA spare parts
269126205110	COUPLING FLANGE (180 DIA SERRATED)	TATA spare parts
269126205112	COUPLING FLANGE (DIA 150 SERRATED)	TATA spare parts
269126205302	GASKET-REAR COVER UPPER	TATA spare parts
269126205303	GASKET REAR COVER- LOWER	TATA spare parts
269126205304	GASKET-REAR COVER LOWER	TATA spare parts
269126205305	GASKET (REAR COVER UPPER)	TATA spare parts
269126205306	GASKET (INTEGRAL REAR COVER CUM ADAPTOR)	TATA spare parts
269126205307	GASKET INTEGRAL REAR COVER ADAPTOR G750	TATA spare parts
269126205309	GASKET REAR COVER	TATA spare parts
269126205310	GASKET REAR COVER	TATA spare parts
269126205311	GASKET INTEGRAL REAR COVER	TATA spare parts
269126205411	HELICAL GEAR 2ND SPEED	TATA spare parts
269126205412	1ST GEAR (MAIN SHAFT)	TATA spare parts
269126205413	REV.GEAR M/SHAFT(37T/32T) 6SP) BS1/2/3/4	TATA spare parts



269126205414	3RD GEAR MAIN SHAFT (6 SPEED)	TATA spare parts
269126205415	4TH GEAR MAIN SHAFT	TATA spare parts
269126205420	OVER DRIVE GEAR (MAIN SHAFT)	TATA spare parts
269126205421	4TH GEAR MAIN SHAFT (6SP/O/D)	TATA spare parts
269126205425	1ST SPEED GEAR MAIN SHAFT	TATA spare parts
269126205426	2ND GEAR MAIN SHAFT(36T) G750 BS2/3/4	TATA spare parts
269126205427	3RD GEAR MAIN SHAFT (29T) BS2/3/4	TATA spare parts
269126205428	4TH SPEED GEAR MAIN SHAFT(23T) BS2/3/4	TATA spare parts
269126205429	5TH GEAR MAIN SHAFT (G750 ) BS2/3/4	TATA spare parts
269126205430	REVERSE GEAR M/SHAFT (38T/32T) BS2/3/4	TATA spare parts
269126205433	OVER DRIVE GEAR [MAIN SHAFT](G900-OD)	TATA spare parts
269126205434	SPEEDO GEAR	TATA spare parts
269126205436	1ST SPEED GEAR[M/SHAFT](LOOSE SYN.RING)	TATA spare parts
269126205437	2ND SPEED GEAR[M/SHAFT](LOOSE SYN.RING)	TATA spare parts
269126205438	3RD SPEED GEAR[M/SHAFT](LOOSE SYN.RING)	TATA spare parts
269126205439	4TH SPEED GEAR[M/SHAFT](LOOSE SYN.RING)	TATA spare parts
269126205440	5TH SPEED GEAR[M/SHAFT](LOOSE SYN.RING)	TATA spare parts
269126205441	OVER DRIVE GEAR (LOOSE SYN.)	TATA spare parts
269126205442	4TH SPEED GEAR(6.58 RATIO-LOOSE SYN.RING)	TATA spare parts
269126205444	REV GEAR NON WIDER (MAIN SHAFT) G750	TATA spare parts
269126205445	REVERSE GEAR MAIN SHAFT BS2/3/4	TATA spare parts
269126205446	1ST GEAR MAIN SHAFT(43T) G750 BS2/3/4	TATA spare parts
269126205451	1ST GEAR MAIN SHAFT (G750) BS1/2/3/4	TATA spare parts
269126205452	2ND GEAR MAIN SHAFT (G750) BS1/2/3/4	TATA spare parts
269126205453	REVERSE GEAR M/SHAFT (38T/32T)BS1/2/3/4	TATA spare parts
269126205454	1ST GEAR MAIN SHAFT G750 BS3/4	TATA spare parts
269126205457	HELICAL REVERSE GEAR M/SHAFT BS3/4	TATA spare parts
269126205458	OVER DRIVE GEAR (M/SHAFT-EN353)	TATA spare parts
269126205459	4TH SPEED GEAR	TATA spare parts
269126205460	3RD GEAR MAIN SHAFT(G750) BS1/2/3/4	TATA spare parts
269126205461	4TH GEAR MAIN SHAFT(G750) BS1/2/3/4	TATA spare parts
269126205462	5TH GEAR MAIN SHAFT BS1/3/4	TATA spare parts
269126205463	4TH SPEED GEAR (RATIO-7.61)	TATA spare parts
269126205465	SENSING WHEEL CONTACTLESS SPEEDO (G600)	TATA spare parts
269126205466	SENSING WHEEL CONTACTLESS SPEEDOMETER	TATA spare parts
269126205467	SENSING WHEEL CONTACTLESS SPEEDOMETER	TATA spare parts
269126205468	SENSING WHEEL CONTACTLESS SPEEDOMETER	TATA spare parts
269126205470	SENSING WHEEL CONTACTLESS SPEEDOMETER	TATA spare parts
269126205475	1ST GEAR MAIN SHAFT BS6	TATA spare parts
269126205476	HELICAL REV.GEAR M/SHAFT (34T/35T) BS3/4	TATA spare parts
269126206501	LOCK NUT BS1/2/3/4	TATA spare parts
269126206702	RETENTION PIN	TATA spare parts
269126207802	OIL SEAL-M/SHAFT	TATA spare parts
269126207804	OIL SEAL-M/SHAFT	TATA spare parts
269126207805	OIL SEAL BS1/2/3/4	TATA spare parts
269126207805DF	OIL SEAL MAIN SHAFT - GB750	TATA spare parts
269126207806	OIL SEAL-PTFE	TATA spare parts

269126207807	DUST SEAL (REAR COVER)	TATA spare parts
269126207813	OIL SEAL[PTFE]	TATA spare parts
269126207814	OIL SEAL BS1/2/3/4	TATA spare parts
269126207816	OIL SEAL (CR SEALS)	TATA spare parts
269126207821	OIL SEAL (MAIN SHAFT) M/S-SIGMA NOK [80X	TATA spare parts
269126207822	OIL SEAL (G750 M/SHAFT)	TATA spare parts
269126207904	SPEEDO PINION	TATA spare parts
269126207905	MAIN SHAFT (6SP) (34T/26T/38T/18T) BS2/3	TATA spare parts
269126207907	MAIN SHAFT	TATA spare parts
269126207909	MAIN SHAFT (THRUST BRG.ARRGMT)	TATA spare parts
269126207910	SPEEDO PINION(REAR COVER (UPPER))	TATA spare parts
269126207911	MAIN SHAFT(RAT 9.19) BS1/2/3/4	TATA spare parts
269126207912	MAIN SHAFT (G680-9.19)	TATA spare parts
269126207913	MAIN SHAFT (G750) BS1/2/3/4	TATA spare parts
269126207916	MAIN SHAFT G750(SUIT RETARDER MTG.COVER)	TATA spare parts
269126207917	MAIN SHAFT G750 (LONGER)	TATA spare parts
269126207918	MAIN SHAFT G600 (LONGER) BS3	TATA spare parts
269126207919	MAIN SHAFT	TATA spare parts
269126208201	DUST COVER	TATA spare parts
269126208202	OIL SLINGER (REAR COVER)	TATA spare parts
269126208203	OIL SLINGER-REAR COVER	TATA spare parts
269126208204	DUST COVER	TATA spare parts
269126208206	OIL SLINGER BS6	TATA spare parts
269126208301	SHIM 0.5 THK.	TATA spare parts
269126208302	SHIM 0.25THK.	TATA spare parts
269126208303	SHIM 0.125 THK.	TATA spare parts
269126208304	SHIM 005 THK	TATA spare parts
269126208601	SPACER	TATA spare parts
269126208611	STOPPER RING.	TATA spare parts
269126208612	SPACER-MAIN SHAFT 11.4 THK	TATA spare parts
269126208613	SPACER-MAIN/SHAFT 11.3 THK	TATA spare parts
269126208614	SPACER-MAIN SHAFT 11.2 THK	TATA spare parts
269126208615	SPACER-MAIN SHAFT 11.1 THK	TATA spare parts
269126208616	SPACER-MAIN SHAFT 11 THK	TATA spare parts
269126208617	SPACER-MAIN SHAFT 10.9 THK	TATA spare parts
269126208618	SPACER-MAIN SHAFT 10.8 THK	TATA spare parts
269126208619	SPACER-MAIN SHAFT 10.7 THK	TATA spare parts
269126208620	SPACER-MAIN SHAFT 10.5 THK	TATA spare parts
269126208624	SPACER-MAIN SHAFT 11.6 THK	TATA spare parts
269126208625	SPACER-MAIN SHAFT 11.5 THK	TATA spare parts
269126208626	SPACER-MAIN SHAFT 10.5 THK	TATA spare parts
269126208627	SPACER-MAIN SHAFT 10.4 THK	TATA spare parts
269126208628	SPACER MAIN SHAFT RATIO 6.58 BS2/3	TATA spare parts
269126208629	SPACER (MAIN SHAFT) BS1/2/3/4	TATA spare parts
269126208630	SPACER (M/SHAFT) 4TH SPEED GEAR BS2/3	TATA spare parts
269126208632	SPACER M/SHAFT THK-10.4	TATA spare parts
269126208633	SPACER M/SHAFT THK-10.5	TATA spare parts

269126208634	SPACER M/SHAFT THK-10.6	TATA spare parts
269126208635	SPACER M/SHAFT THK-10.7	TATA spare parts
269126208636	SPACER M/SHAFT THK-10.8	TATA spare parts
269126208637	SPACER M/SHAFT THK-10.9	TATA spare parts
269126208638	SPACER M/SHAFT THK-11.0	TATA spare parts
269126208639	SPACER M/SHAFT THK-11.1	TATA spare parts
269126208640	SPACER M/SHAFT THK-11.2	TATA spare parts
269126208641	SPACER M/SHAFT THK-11.3	TATA spare parts
269126208642	SPACER M/SHAFT THK-11.4	TATA spare parts
269126208643	SPACER M/SHAFT THK-11.5	TATA spare parts
269126208644	SPACER M/SHAFT THK-11.6	TATA spare parts
269126208647	SPACER G600 M/SHAFT (THK=22.4)	TATA spare parts
269126208648	SPACER G600 M/SHAFT (THK=22.6)	TATA spare parts
269126208649	SPACER G600 M/SHAFT (THK=22.8)	TATA spare parts
269126208650	SPACER G600 M/SHAFT (THK=23MM)	TATA spare parts
269126208651	SPACER(19.6 THICK)	TATA spare parts
269126208652	SPACER(19.8 THICK)	TATA spare parts
269126208653	SPACER(20.0 THICK)	TATA spare parts
269126208657	SPACER 4TH GEAR M/SHAFT(G600_OD)	TATA spare parts
269126208658	SPACER 4TH GEAR M/SHAFT(G600_DD)	TATA spare parts
269126208659	SPACER (M/SHAFT) 4TH SPEED GEAR BS1-6	TATA spare parts
269126208660	SPACER MAIN SHAFTBS6	TATA spare parts
269126208661	SPACER MAIN SHAFT OIL SEAL	TATA spare parts
269126208662	SPACER MAIN SHAFT OIL SEAL	TATA spare parts
269126208663	SPACER MAIN SHAFT OIL SEAL	TATA spare parts
269126208664	SPACER MAIN SHAFT OIL SEAL	TATA spare parts
269126208665	SPACER MAIN SHAFT OIL SEAL	TATA spare parts
269126208701	COMPRESION SPRING	TATA spare parts
269126208702	COMPRESION SPRING	TATA spare parts
269126250105	ASSY.DRIVE SHAFT	TATA spare parts
269126250109	ASSY.DRIVE SHAFT	TATA spare parts
269126250110	ASY DRIVE SHAFT-19T(6SP-O/D)	TATA spare parts
269126250112	ASSY DRIVE SHAFT COMP. (RATIO-6.58)	TATA spare parts
269126250117	ASSY. DRIVE SHAFT(18T)RAT-8.47	TATA spare parts
269126250118	ASSY. DRIVE SHAFT(17 T)RAT-9.19)	TATA spare parts
269126250121	ASSY.DRIVE SHAFT (G750)	TATA spare parts
269126250126	ASSY. DRIVE SHAFT (18T) G600 BS1/2/3/4	TATA spare parts
269126250135	ASSY. DRIVE SFT (G600-6.58)THR BRG BS1-4	TATA spare parts
269126250136	ASSY. DRIVE SFT(17T)G600 THR BRG BS2/3/4	TATA spare parts
269126250138	ASSY DRIVE SHAFT(6.58 RATIO THRUST BRG)	TATA spare parts
269126250140	ASSY. DRIVE SHAFT-(17 T)G750/9.19 BS2/3	TATA spare parts
269126250143	ASSY FRONT COVER UPPER BS6	TATA spare parts
269126250144	ASSY. MAIN & DRIVE SHAFT KIT 9.19 RATIO	TATA spare parts
269126250145	ASSY. THRUST BRG 8.47 RATIO GEAR BOX	TATA spare parts
269126250146	ASSY Main & Drive shaft KIT 6.58 RATIO	TATA spare parts
269126250147	KIT FOR ASSY DRIVE SHAFT (RATIO-8.47)	TATA spare parts
269126250148	KIT FOR ASSY DRIVE SHAFT (RATIO-6.58)	TATA spare parts

269126250149	ASSY. DRIVE SHAFT-(18T)G750 /8.47	TATA spare parts
269126250154	ASSY. DRIVE SFT(18T)G750 380 DCL BS2/3/4	TATA spare parts
269126250156	ASSY. DRIVE SHAFT(19T) HI-DK R.E BS2/3/4	TATA spare parts
269126250160	ASSY. DRIVE SHAFT (G750-9.19) BS3/4	TATA spare parts
269126250162	ASSY DRIVE SHAFT (RATIO-8.47) [ MAT-EN35	TATA spare parts
269126250166	ASSY. DRIVE SHAFT (RATIO 7.61) BS3/4	TATA spare parts
269126250173	ASSY. DRIVE SHAFT (RAT 9.19) BS1/3/4	TATA spare parts
269126250175	ASSY DRIVE SHAFT (G750-8.47)	TATA spare parts
269126253101	TAPER ROLLER BEARING-DRIVE SHAFT	TATA spare parts
269126253102	TAPER ROLLER BRG 3659	TATA spare parts
269126253103	TAPER ROLLER BEARING-DRIVE SHAFT	TATA spare parts
269126253104	TAPER ROLLER BEARING	TATA spare parts
269126253105	CYL ROLLER BRG. AR 7.5 75 100 BS1/2/3/4	TATA spare parts
269126253106	ROLLER CAGE (DRIVE SHAFT)	TATA spare parts
269126253107	ROLLER CAGE (DRIVE SHAFT)	TATA spare parts
269126253108	CYLINDRICAL ROLLER THRUST BEARING	TATA spare parts
269126253109	CYLINDRICAL ROLLER THRUST BEARING	TATA spare parts
269126253110	ROLLER CAGE (DRIVE SHAFT)	TATA spare parts
269126253112	CYLINDRICAL ROLLER THRUST BEARING	TATA spare parts
269126253113	ROLLER [THRUST BRG.ARRGMT] BS1/2/3/4	TATA spare parts
269126253115	ROLLER (THRUST BRG.ARRANGEMENT)	TATA spare parts
269126253704	FRONT COVER-UPPER	TATA spare parts
269126253705	FRONT COVER (UPPER)	TATA spare parts
269126253706	FRONT COVER UPPER (HIGH DECK R.E.BUS)	TATA spare parts
269126253707	FRONT COVER-UPPER(G750) BS1/2/3/4	TATA spare parts
269126254604	SYNCHRORING (DRIVE SHAFT)	TATA spare parts
269126254605	SYNCHRORING (D/SHAFT)[THRUST.BRG.ARRGMT]	TATA spare parts
269126255302	GASKET-FRONT COVER-UPPER	TATA spare parts
269126255303	GASKET-FRONT COVER LOWER	TATA spare parts
269126255304	GASKET (FRONT COVER UPPER)	TATA spare parts
269126257805	OIL RETAINER- DRIVE SHAFT	TATA spare parts
269126257806	OIL RETAINER-DRIVE SHAFT	TATA spare parts
269126257807	OIL RETAINER-DRIVE SHAFT	TATA spare parts
269126257808	OIL SEAL BS1/2/3/4/6	TATA spare parts
269126257808AE	OIL SEAL (CR SEALS) 715	TATA spare parts
269126257809	OIL SEAL (D/SHAFT)[65X48X10]	TATA spare parts
269126257912	DRIVE SHAFT (G600 9.19 W/THRU.BRG MATL-2	TATA spare parts
269126257913	DRIVE SHAFT(G600 6.58	TATA spare parts
269126257921	DRIVE SHAFT (RATIO-6.58) BS6	TATA spare parts
269126257922	DRIVESHAFTG750/6.58SUIT380DIACLUTCHN BS6	TATA spare parts
269126257926	DRIVE SHAFT (G600-6.58 MAT-EN353)	TATA spare parts
269126257928	DRIVE SHAFT G750-8.47 380DCL BS6	TATA spare parts
269126257930	DRIVE SHAFT (RATIO:7.61)	TATA spare parts
269126258203	OIL DAM-FRONT COVER	TATA spare parts
269126258204	OIL DAM (FRONT COVER) G750	TATA spare parts
269126258205	OIL SLINGER-FRONT COVER	TATA spare parts
269126300107	ASSY COUNTER SHAFT (6SP-O/D)	TATA spare parts

269126300118	ASSY KIT FOR 3RD/4TH GEAR(COUNTER SHAFT)	TATA spare parts
269126300142	ASSY COUNTER SHAFT (6SP TWIN CONE) BS6	TATA spare parts
269126303104	TAPER ROLLER BRG. 25572/25520 BS1/2/3/4	TATA spare parts
269126303105	TAPER ROLLER BEARING-C/SHAFT	TATA spare parts
269126303106	TAPER ROLLER BEARING-C/SHAFT	TATA spare parts
269126303107	TAPER ROLLER BEARING-C/SHAFT	TATA spare parts
269126303108	TAPER ROLLER BRG. K-3585/25 BS1/2/3/4	TATA spare parts
269126303108AE	TAPER ROLLER BRG 1628	TATA spare parts
269126303110	TAPER ROLLER BEARING-C/SHAFT	TATA spare parts
269126303112	TAPER ROLLER BEARING	TATA spare parts
269126303114	TAPER ROLLER BEARING (G750 -C/S FRONT)	TATA spare parts
269126303115	TAPER ROLLER BEARING	TATA spare parts
269126303702	REAR COVER-G.B.HSG LOWER - INTEGRAL	TATA spare parts
269126303703	FRONT COVER-LOWER	TATA spare parts
269126303704	FRONT COVER (LOWER)	TATA spare parts
269126303705	COVER REAR LOWER (G.B.HSG)INTEGRAL	TATA spare parts
269126305301	GASKET FOR REAR COVER LOWER-INTIGRAL	TATA spare parts
269126305302	GASKET (FRONT COVER LOWER)	TATA spare parts
269126305302AE	GASKET (FRONT COVER LOWER) 1828	TATA spare parts
269126305303	GASKET REAR COVER LOWER(INTEGRAL)	TATA spare parts
269126305405	C M GEAR G600 , 5SP.	TATA spare parts
269126305406	TWIN GEAR G600 , 5 SP	TATA spare parts
269126305410	5TH GEAR COUNTER SHAFT (32T) BS1/2/3/4	TATA spare parts
269126305411	CONST. MESH GEAR 40T (C/SHAFT) BS2/3/4	TATA spare parts
269126305412	TWIN GEAR-COUNTER SHAFT	TATA spare parts
269126305413	CONST.MESH GEAR (C/SHAFT)(32T) BS1/2/3/4	TATA spare parts
269126305414	OVER DRIVE GEAR (C/SHAFT)(39T) BS1/2/3/4	TATA spare parts
269126305415	TWIN GEAR-6SP-O/D	TATA spare parts
269126305419	3RD GEAR COUNTER SHAFT (G750-23T)BS2/3/4	TATA spare parts
269126305420	4TH GEAR COUNTER SHAFT(28T) BS1/2/3/4	TATA spare parts
269126305421	5TH GEAR COUNTER SHAFT(32T ) BS1/2/3/4	TATA spare parts
269126305422	CONSTANTMESH GEAR (C/SHAFT) (39T)BS2/3/4	TATA spare parts
269126305423	CONST.MESH GEAR (C/SHAFT)(39T) BS1/2/3/4	TATA spare parts
269126305424	3RD GEAR COUNTER SHAFT (22T) BS1/2/3/4	TATA spare parts
269126305425	4TH GEAR COUNTER SHAFT(27T) BS1/2/3/4	TATA spare parts
269126305426	OVER DRIVE GEAR (COUNTER SHAFT) BS2/3	TATA spare parts
269126305427	CONSTANTMESH GEAR (G900-OD) BS2/3/4	TATA spare parts
269126305428	4TH GEAR COUNTER SHAFT BS2/3/4	TATA spare parts
269126305431	CONSTANT MESH GEAR (G750 9.19) BS2/3/4	TATA spare parts
269126305433	4TH SPEED GEAR C/SHAFT	TATA spare parts
269126305434	5TH SPEED GEAR C/SHAFT (G600 MATL-EN353)	TATA spare parts
269126305435	3RD SPEED GEAR C/SHAFT (G600 MATL-EN353)	TATA spare parts
269126305436	3RD GEAR COUNTER SHAFT(G750)BS1/2/3/4	TATA spare parts
269126305438	CONST.MESH GEAR (40T) G750-9.19 BS1/3/4	TATA spare parts
269126305439	CONSTANT MESH GEAR (COUNTER SHAFT- RATIO	TATA spare parts
269126305440	4TH SPEED GEAR C/S RATIO-7.61	TATA spare parts
269126305441	CONSTANT MESH GEAR C/SHAFT G750-8.47	TATA spare parts

269126307903	COUNTER SHAFT	TATA spare parts
269126307904	COUNTER SHAFT-16T/11S (6 SPEED)	TATA spare parts
269126307906	COUNTER SHAFT (17 T/11S) BS1/2/3/4	TATA spare parts
269126307909	COUNTER SHAFT (G600) BS1/2/3/4	TATA spare parts
269126307911	COUNTER SHAFT(RR PTO/APP)(G600) BS3/4	TATA spare parts
269126307913	COUNTER SHAFT HELICAL BS3/4	TATA spare parts
269126307914	COUNTER SHAFT(RR PTO/APP)(G750) BS3/4	TATA spare parts
269126308305	SHIM 0.5 THK.	TATA spare parts
269126308306	SHIM 0.25THK.	TATA spare parts
269126308307	SHIM 0.125HK.	TATA spare parts
269126308308	SHIM(0.05THK.)	TATA spare parts
269126308310	SHIM 0.05 THK.	TATA spare parts
269126308311	SHIM 0.125 THK	TATA spare parts
269126308312	SHIM 0.25 THK	TATA spare parts
269126308313	SHIM 0.5 THK.	TATA spare parts
269126350103	ASSY.REVERSE IDLER GEAR	TATA spare parts
269126350104	REVERSE IDLER GEAR ASSY BS6	TATA spare parts
269126353101	ROLLER CAGE BRASS	TATA spare parts
269126353102	ROLLER CAGE NYLON	TATA spare parts
269126353103	STEEL ROLLER CAGE	TATA spare parts
269126353104	ROLLER CAGE	TATA spare parts
269126353105	ROLLER CAGE	TATA spare parts
269126353701	COVER-R.I.WINDOW	TATA spare parts
269126353803	COVER RI WINDOW	TATA spare parts
269126355301	GASKET-R.I.GEAR COVER	TATA spare parts
269126355302	GASKET- R I GEAR COVER	TATA spare parts
269126355303	GASKET R.I.COVER(AL HOUSING)	TATA spare parts
269126355403	REVERSE IDLER GEAR (21T) BS1/2/3/4	TATA spare parts
269126355404	REVERSE IDLER GEAR (21T) TWIN CONE BS1-4	TATA spare parts
269126355405	HELICAL GEAR REVERSE IDLER	TATA spare parts
269126355407	REVERSE IDLER GEAR	TATA spare parts
269126355408	HELICAL REV IDLER GEAR (19T)(G750) BS3/4	TATA spare parts
269126357101	LOCKING PLATE-R.I.SHAFT	TATA spare parts
269126357102	LOCK PLATE RI SHAFT	TATA spare parts
269126357103	COVER PLATE (R.I.WINDOW)	TATA spare parts
269126357902	REVERSE IDLER SHAFT	TATA spare parts
269126358201	COVER-R. I GEAR	TATA spare parts
269126358202	COVER-R.I.WINDOW	TATA spare parts
269126358601	SPACER	TATA spare parts
269126358602	SPACER BS6	TATA spare parts
269126400103	SUB ASSY. AXIAL PISTON PUMP BS1/2/3/4	TATA spare parts
269126400112	ASSY HOUSING-SIDE MOUNTED APP	TATA spare parts
269126400113	ASSY HOUSING-SIDE MOUNTED PTO	TATA spare parts
269126400114	ASSY APP MK-III WITH DRIVE UNIT SIDE MTG	TATA spare parts
269126400115	ASSY DRIVE UNIT FOR APP MK-III SIDE MTG	TATA spare parts
269126400116	ASSY. POWER TAKE OFF-RH SIDE MOUNT BS2/3	TATA spare parts
269126400118	ASSY SHIFTING LEVER (SIDE MOUNTED PTO/ A	TATA spare parts

269126400119	ASSY APP MK-3 W/DRIVE UNIT SIDE MTG.G750	TATA spare parts
269126400120	ASSY. DRIVE UNIT, APP (SIDE MTG) BS2/3	TATA spare parts
269126400121	ASSY POWER TAKE OFF(RATIO-0.637) G750	TATA spare parts
269126400122	ASSY POWER TAKE OFF(RATIO-1.02) G750	TATA spare parts
269126400123	SUB ASSY AXIAL PISTON PUMP	TATA spare parts
269126400124	ASSY CO-AXIAL PTO	TATA spare parts
269126400127	ASSY KIT-FASTNERS OF PTO/PUMP(G600)	TATA spare parts
269126400128	GB-600 INLINE PTO	TATA spare parts
269126400129	DRIVE UNIT FOR SIDE MTG APP MK3	TATA spare parts
269126400130	ASSY REAR MTG AXLE PIS.PUMP G750 BS3/4	TATA spare parts
269126400132	ADAPTOR APP MOUNTING IPH	TATA spare parts
269126400133	REAR MOUNTED PTO UNIT	TATA spare parts
269126400134	ASSY.KIT-FASTNERS OF REAR APP/PTO (G750-	TATA spare parts
269126403706	HOUSING-SIDE MOUNTED APP/PTO	TATA spare parts
269126403707	HOUSING REAR (SIDE MOUNTED APP)	TATA spare parts
269126403708	HOUSING HALF OUTER-SIDE MOUNTED PTO	TATA spare parts
269126403709	GEARBOX MTG ADAPTOR CUM COVER	TATA spare parts
269126403711	ADAPTER PLATEGEARBOX	TATA spare parts
269126404601	COUPLER SLEEVE (AXIAL PISTON PUMP	TATA spare parts
269126405303	GASKET-APP/PTO MOUNTING FACE	TATA spare parts
269126405304	GASKET-HOUSING JOINT FACE	TATA spare parts
269126405305	GASKET	TATA spare parts
269126405306	GASKET M/S-IPH(BETWEEN GEARBOX & PTO PUM	TATA spare parts
269126405307	GASKET M/S-IPH(BETWEEN DRIVE UNIT & ADAP	TATA spare parts
269126405401	SLIDING GEAR	TATA spare parts
269126405402	G600 SLIDING GEAR-Z=18	TATA spare parts
269126405403	SLIDING GEAR (Z=14)	TATA spare parts
269126406301	PROTECTIVE COVER-APP/PTO	TATA spare parts
269126406702	DOWEL PIN-DRIVE UNIT APP/PTO	TATA spare parts
269126407903	SHAFT AXIAL PISTON PUMP	TATA spare parts
269126407906	INPUT SHAFT	TATA spare parts
269126407907	OUTPUT SHAFT-SIDE MOUNTED APP	TATA spare parts
269126407908	INPUT SHAFT-Z2=27	TATA spare parts
269126407909	OUTPUT SHAFT-SIDE MOUNTED PTO	TATA spare parts
269126407911	INPUT SHAFT (Z2=25) APP MKIII G750	TATA spare parts
269126407912	INPUT SHAFT PTO G750	TATA spare parts
269126407913	INPUT SHAFT (Z2=31)	TATA spare parts
269126407914	INPUT SHAFT (G750-HELICAL VERSION)	TATA spare parts
269126408201	COVER (APP DRIVE UNIT)	TATA spare parts
269126408601	SPACER-OIL SEAL	TATA spare parts
269126409901	BRASS PAD-SIDE MOUNTED APP/PTO	TATA spare parts
269126409905	SEAL	TATA spare parts
269126510108	ASSY DOWEL SLEEVE LPT2515TC	TATA spare parts
269126510110	ASSY.FROK DOG BRASS PAD & SHAFT(3RD/4TH)	TATA spare parts
269126510111	ASSY.FORK DOG BRASS PAD & SHAFT(1ST/2ND)	TATA spare parts
269126510112	ASSY.FORK DOG & SHAFT (REV.)	TATA spare parts
269126510116	ASSY SHAFT/FINGER (6SPEED 5TH/OD)	TATA spare parts

269126510117	ASSY SWING FORK & PAD	TATA spare parts
269126510120	ASSY. DETENT BS1/2/3/4	TATA spare parts
269126510120AE	ASSY DETENT 1628	TATA spare parts
269126510132	ASSY KIT FORK BRASS PAD(1ST/2ND 3RD/4TH)	TATA spare parts
269126510133	ASSY KIT FOR FORK BRASS PAD (5TH/6TH)	TATA spare parts
269126510146	SHIFTER PAD BS6	TATA spare parts
269126513001	ROLLER	TATA spare parts
269126513401	DETENT BODY	TATA spare parts
269126513402	BUSH-SWING FORK	TATA spare parts
269126515106	SHIFTER FORK 4TH/5TH SPEED	TATA spare parts
269126515108	"SHIFTER FORK 1/R,2/3 GBS 60 FINISH 5 SP	TATA spare parts
269126515112	SHIFTER FORK 1/2&3/4 - G600	TATA spare parts
269126515113	SHIFTER FORK- REVERSE BS1/2/3/4/6	TATA spare parts
269126515115	SHIFTER DOG [1ST/2ND SPEED]	TATA spare parts
269126515116	SHIFTER DOG [3RD/4TH SPEED]	TATA spare parts
269126515117	SHIFTER DOG [5TH/6TH SPEED]	TATA spare parts
269126515118	SHIFTER DOG [REVERSE]	TATA spare parts
269126515120	SWING FORK-5TH/O.D.	TATA spare parts
269126515123	SHIFTER DOG FINGER-5TH/6TH SPEED	TATA spare parts
269126515125	SHIFTER FORK (1ST/2ND & 3RD/4TH) BS1-6	TATA spare parts
269126515126	SHIFTER FORK (5TH/6TH) BS1/2/3/4/6	TATA spare parts
269126515127	SHIFTER FORK 5/6 SPEED	TATA spare parts
269126515128	SHIFTER FORK [5TH/OD SPEED](G900-OD)	TATA spare parts
269126515136	SHIFTER DOG 1ST/2ND SPEED BS6	TATA spare parts
269126515137	SHIFTER DOG 3RD/4TH SPEED BS6	TATA spare parts
269126515138	SHIFTER DOG 5TH/6TH SPEED BS6	TATA spare parts
269126515139	SHIFTER DOG REVERSE SPEED BS6	TATA spare parts
269126516701	THREADED PIN (SWING FORK)	TATA spare parts
269126516703	INTERLOCK PIN	TATA spare parts
269126516704	PIN	TATA spare parts
269126516705	DOWELING PIN	TATA spare parts
269126516706	SPRIAL PIN 8X36	TATA spare parts
269126516707	THREADED PIN (SWING FORK)	TATA spare parts
269126517907	SHIFTER SHAFT- 5TH/6TH	TATA spare parts
269126517908	SHIFTER SHAFT-1ST/2ND	TATA spare parts
269126517909	SHIFTER SHAFT- REVERSE	TATA spare parts
269126517910	SHIFTER SHAFT-3/4	TATA spare parts
269126517914	SHIFTER SHAFT (1ST/2ND SPEED) BS1-6	TATA spare parts
269126517915	SHIFTER SHAFT (3RD/4TH SPD) BS1/2/3/4/6	TATA spare parts
269126517916	SHIFTER SHAFT (5TH/6TH SPEED) BS1-6	TATA spare parts
269126517917	SHIFTER SHAFT (REVERSE)	TATA spare parts
269126517918	SHIFTER SHAFT (REVERSE)	TATA spare parts
269126517919	SHIFTER SHAFT (1ST/2ND)(WITH HOLE)	TATA spare parts
269126517920	SHIFTER SHAFT (3RD/4TH)(WITH HOLE)	TATA spare parts
269126517921	SHIFTER SHAFT(1ST/2ND G750)(WITH HOLE)	TATA spare parts
269126517922	SHIFTER SHAFT(3RD/4TH G750)(WITH HOLE)	TATA spare parts
269126517927	SHIFTER SHAFT (REVERSE SPEED) BS6	TATA spare parts



269126518703	COMPRESSION SPRING DETENT BS1/2/3/4/6	TATA spare parts
269126518704	COMPRESSION SPRING (DETENT)[RE.BUS]	TATA spare parts
269126519901	BRASS PAD BS1/2/3/4	TATA spare parts
269126700103	SUB ASSY G.S.LEVER	TATA spare parts
269126700107	ASSY. TOP COVER COMP. RHD[6 SPEED] BS3/4	TATA spare parts
269126700111	ASSY.SELECTOR SHAFT	TATA spare parts
269126700112	ASSY.GEAR SHIFTING LEVER (UPPER PART)	TATA spare parts
269126700113	ASSY TOP COVER DIRECT SHIFT COMPL.(G750	TATA spare parts
269126700117	ASSY.GEAR SHFITING LEVER LHD (UPPER PAR)	TATA spare parts
269126700118	SELECTION LEVER & SELECTOR SHAFT ASSY	TATA spare parts
269126700121	GEAR SHIFT LEVER ASSY UPPER & LOWER PART	TATA spare parts
269126700123	COVER ASSY WITH GSL GEAR BOX TOP BS6	TATA spare parts
269126703802	TOP COVER UPPER HALF	TATA spare parts
269126703803	TOP COVER LOWER HALF	TATA spare parts
269126705102	HOUSING BLOCK	TATA spare parts
269126705103	SHIFTER FINGER (POWER SHIFT)	TATA spare parts
269126705104	HOUSING BLOCK	TATA spare parts
269126705301	GASKET (BETWEEN TOP COVER & HSG.FRONT)	TATA spare parts
269126705302	GASKET BET'N COVER TOP & BOTTOM	TATA spare parts
269126706001	SELECTION & SHIFTING LEVER 65R	TATA spare parts
269126706002	SELECTION LEVER	TATA spare parts
269126706003	SELECTOR & SHIFTER LEVER BS2/3/4/6	TATA spare parts
26912670600350	G.S.LEVER LOWER (RAW-PART) 105R	TATA spare parts
269126706004	SELECTOR & SHIFT LEVER(85R OPP TAPER HOL	TATA spare parts
269126706005	SHIFTING LEVER (R-105)	TATA spare parts
269126706006	SELECTION LEVER	TATA spare parts
269126706007	SHIFTING LEVER R-75 (MODULAR TOP COVER)	TATA spare parts
269126706501	RETAINER BOLT (HSG BLK SPRING)	TATA spare parts
269126706502	RETAINER BOLT (NEEDLE BRG)	TATA spare parts
269126706503	HEX BOLT	TATA spare parts
269126706703	RETAINER PIN (HSG BLK SPRING)	TATA spare parts
269126706704	PIN GEARSHIFT LEVER	TATA spare parts
269126706705	PLUNGER	TATA spare parts
269126707701	BELLOW INNER (G.S.LEVER)	TATA spare parts
269126707702	BELLOW OUTER (G.S.LEVER)	TATA spare parts
269126707902	SELECTOR SHIFTER SHAFT-6 SPEED	TATA spare parts
269126707903	SELECTOR & SHIFTER SHAFT-RHD BS1/2/3/4	TATA spare parts
269126707904	SELECTOR & SHIFTER SHAFT (LHD) RE BUS.	TATA spare parts
269126707906	SELECTOR & SHIFTER SHAFT LHD 30DEG.NOTCH	TATA spare parts
269126707908	SELECTOR & SHIFTER SHAFT	TATA spare parts
269126707909	SELECTOR AND SHIFTER SHAFT	TATA spare parts
269126707910	SELECTOR & SHIFTER SHAFT (SHORT.VER)	TATA spare parts
269126708601	SPACER 2.9 THK	TATA spare parts
269126708602	SPACER 3.0 THK	TATA spare parts
269126708603	SPACER 3.1 THK	TATA spare parts
269126708604	SPACER 3.2 THK	TATA spare parts
269126708605	SPACER 3.3 THK	TATA spare parts

269126708606	SPACER 3.4 THK	TATA spare parts
269126708701	SPRING RING (BELLOW)	TATA spare parts
269126708702	TORSION SPRING	TATA spare parts
269126709901	GEARSHIFT LEVER LOWER PART	TATA spare parts
269126709902	GEARSHIFT LEVER UPPER ST.CONDITION	TATA spare parts
269126709904	GEAR SHIFT LEVER (LOWER PART)	TATA spare parts
269126710109	ASSY BRACKET	TATA spare parts
269126710113	ASSY TOP COVER (6 SP)WITH 30 DEG SHAFT	TATA spare parts
269126710119	ASSY TOP COVER LHD SEL.SHAFT NOTCH AT BO	TATA spare parts
269126710120	ASSY.TOP COVER LHD 30 DEG.SEL.SHIFT LEVR	TATA spare parts
26912671012090	SUBASSY TOP COVER	TATA spare parts
269126710121	ASSY BRACKET LHD (SHIFT LINK)	TATA spare parts
269126710122	ASSY TOP COVER W/SOFTER REV SELE SPRING	TATA spare parts
269126710123	ASSY TOP COVER(SL LEVER 65R OPP TAPER HO	TATA spare parts
26912671012390	SUBASSY TOP COVER	TATA spare parts
269126710124	ASSY TOP COVER LHD SEL.LEV.65R.VERT.UP)	TATA spare parts
269126710126	ASSY TOP COVER(SL.LEVER UP 85R)	TATA spare parts
269126710127	ASSY TOP COVER (SEL LEVER @ 30DEG.R85)	TATA spare parts
26912671012790	SUBASSY TOP COVER	TATA spare parts
269126710128	ASSY TOP COVER(SEL.LEVER UP R65 OUTSIDE)	TATA spare parts
269126710130	ASSY TOP COVER COMPLETE BS2/3/4	TATA spare parts
269126710132	ASSY BRACKET POWER SHIFT	TATA spare parts
269126710133	ASSY.TOP COVER (POWER SHIFT)	TATA spare parts
269126710134	ASSY TOP COVER(WITH SEL LEVER 30DEG/105)	TATA spare parts
269126710135	ASSY TOP COVER(W/SOFT SPR.30DEG/R105 LEV	TATA spare parts
269126710138	ASSY TOP COVER(SL.LEVER R105 VER.UP)	TATA spare parts
269126710139	ASSY. SELECTION CABLE MOUNTING BRACKET	TATA spare parts
269126710140	ASSY. SHIFTER CABLE MTG. BRACKET	TATA spare parts
269126710141	ASSY TOP COVER (WITH ASSY CABLESHIFT B	TATA spare parts
269126710142	ASSY TOP COVER (LEVER R85 VER.UP)	TATA spare parts
269126710144	COVER ASSY WITH SHIFTING LEVER TOP	TATA spare parts
269126710148	ASSY BOTTOM PLATE BRACKET(POWER SHIFT)	TATA spare parts
269126710149	ASSY TOP COVER (SL.LEVER UP 105R OPP/TAP	TATA spare parts
269126710152	BRACKET(FOR CABLE CLAMP)	TATA spare parts
269126710154	ASSY TOP COVER(LEV R85 VER UP OPP.HOLE	TATA spare parts
269126710159	ASSY TOP COVER HOUSING WITH BUSH	TATA spare parts
269126710161	ASSY BRACKET(MODULAR TOP COVER)	TATA spare parts
269126710162	COVER ASSY TOP	TATA spare parts
269126710164	ASSY. FIL/PRESS REGULATOR(4 BAR)	TATA spare parts
269126710168	CABLE CLAMP BRACKET	TATA spare parts
269126710171	ASSY. TOP COVER (CABLE SHIFT NON PNEUMAT	TATA spare parts
269126710176	COVER ASSY TOP(SHORTER VERSION)	TATA spare parts
269126710181	SHAFT ASSY WITH BUSH SELECTION/SHIFTING	TATA spare parts
269126710183	SELECTOR & SHIFTER SHAFT ASSY	TATA spare parts
269126710188	COVER ASSY TOP BS6	TATA spare parts
269126710192	COVER ASSY TOP	TATA spare parts
269126710195	COVER ASSY TOP BS6	TATA spare parts

269126710201	BRACKET LINK ROD MTG BS6	TATA spare parts
269126710212	SELECTOR & SHIFTER SHAFT ASSY BS6-PH2	TATA spare parts
269126710214	COVER ASSY TOP BS6	TATA spare parts
269126710223	COVER ASSY TOP BS6	TATA spare parts
269126710225	COVER ASSY TOP BS6	TATA spare parts
269126710236	BRACKET LINK ROD MTG BS6	TATA spare parts
269126713702	GEAR CASE COVER TOP	TATA spare parts
269126713703	INTERLOCK FINGER	TATA spare parts
269126713704	TOP COVER (POWER SHIFT LHD)	TATA spare parts
269126713802	SIDE COVER (GEAR CASE COVER TOP) LHD	TATA spare parts
269126713803	COVER SIDE(SHORTER VERSION)	TATA spare parts
269126715101	SHIFTER FINGER-G600	TATA spare parts
269126715102	ADAPTOR (POWER SHIFT CYLINDER)	TATA spare parts
269126715102AE	ADPTR ( PWR SHIFT CYL ) -1628	TATA spare parts
269126715103	ADAPTOR (POWERSHIFT CYLINDER)	TATA spare parts
269126715105	COUNTER WEIGHT	TATA spare parts
269126715107	COUNTER WEIGHT BS6-PH2	TATA spare parts
269126716702	PRESSURE PIECE REV.DETENT-POWERSHIFT)	TATA spare parts
269126717201	SEALING PLUG	TATA spare parts
269126718701	COMPRESSION SPRING-OUTER	TATA spare parts
269126718702	COMPRESSION SPRING-INNER	TATA spare parts
269126718703	COMPRESSION SPRING (REVERSE)_	TATA spare parts
269126718704	COMPRESSION SPRING (OUTER)	TATA spare parts
269126718705	COMPRESSION SPRING (INNER)	TATA spare parts
269126800101	ASSY CABLE SHIFTING MECH	TATA spare parts
269126800102	ASSY SHIFTING PIVOT LEVER(POWER SHIFT)	TATA spare parts
269126800103	ASSY LINK ROD	TATA spare parts
269126800104	ASSY BRACKET (SHIFTER UNIT MOUNTING)	TATA spare parts
269126800105	ASSY SHIFTER BRACKET (DRIVER END)	TATA spare parts
269126800106	ASSY BEARING BLOCK (SELECT & SHIFT)	TATA spare parts
269126800107	ASSY GEAR SHIFT LEVER	TATA spare parts
269126800108	SUB ASSY BELL CRANK LEVER (WELDED)	TATA spare parts
269126800110	ASSY CABLE SHIFT & SELECT GBOX TO DRIVER	TATA spare parts
269126800117	PRESSURE REGULATOR(WITH DIAL INDICATOR)	TATA spare parts
269126800121	PRESSURE REGULATOR(W/O DIAL)	TATA spare parts
269126800123	ASSY. GEAR SHIFTER UNIT WITH CABLE	TATA spare parts
269126800128	ASSY. GEAR SELECT CABLE COMPLETE	TATA spare parts
269126800129	ASSY. GEAR SHIFT CABLE BS4	TATA spare parts
269126800130	ASSY. GEARSHIFT UNIT WITH CABLES	TATA spare parts
269126800130_NIU	ASSY. GEARSHIFT UNIT WITH CABLES	TATA spare parts
269126800131	ASSY. BRACKET (SHIFTER MOUNTING)	TATA spare parts
269126800132	GEAR SHIFT ASSY WITH CABLE ASSY	TATA spare parts
269126800134	GEAR SHIFT LINKAGES CABLE TYPE ASSY	TATA spare parts
269126800135	GEAR SHIFT LINKAGES CABLE TYPE ASSY	TATA spare parts
269126800138	CABLE ASSY GEAR SHIFT UNIT	TATA spare parts
269126800140	BRACKET ASSY	TATA spare parts
269126800149	BRACKET ASSY WITH BOSS BS6	TATA spare parts

269126800151	GEAR SHIFT UNIT ASSY WITH CABLE	TATA spare parts
269126800152	GEAR SHIFT UNIT ASSY WITH CABLE BS6-PH2	TATA spare parts
269126803101	NEEDLE BEARING	TATA spare parts
269126803201	HEX BOLT (SHIFTING BLOCK)	TATA spare parts
269126804201	CABLE CLAMP(LPT1613/LPT2521 BS4	TATA spare parts
269126804203	CABLE CLAMP(LPT1613/LPT2521 BS4)	TATA spare parts
269126805101	SLIDING LEVER (SELECTION)	TATA spare parts
269126805601	GEAR SHIFTER LEVER KNOB	TATA spare parts
269126806702	THREADED PIN (SELECTION LEVER)	TATA spare parts
269126806703	PIVOT PIN (POWER SHIFT)	TATA spare parts
269126807701	BELLOW(LPT1613/LPT2521 BS4)	TATA spare parts
269126807902	SHAFT (SELECTION PIVOT)	TATA spare parts
269126808601	SPACER	TATA spare parts
269126808602	SPACER (SHIFTING LEVER)	TATA spare parts
269126808603	SPACER (SELECTION)	TATA spare parts
269126820102	ASSY SELECTION LEVER MOUNTING	TATA spare parts
269126820104	SELECTION LEVER AND MOUNTING BRACKET	TATA spare parts
269126820105	BRACKET CABLE ANCHORING	TATA spare parts
269126820107	BRACKET ASSY CABLE ANCHORING (SELECTION)	TATA spare parts
269126820109	ASSY.¿ ANCHORING SELECTION BRACKET	TATA spare parts
269126821601	ASSY. GEAR SHIFT KNOB (G750-6SPEED)	TATA spare parts
269126826003	SHIFTER LEVER	TATA spare parts
269126826004	SHIFTING LEVER R120	TATA spare parts
269126843801	ADAPTOR PLATE(X-Y ACTUATOR AMT FITMENT)	TATA spare parts
269133358201	INNER SLINGER	TATA spare parts
269226518701	DETENT SPRING	TATA spare parts
269233358201	INNER SLINGER	TATA spare parts
269235108301	SHIM ADJ	TATA spare parts
269333358201	INNER SLINGGER	TATA spare parts
26938063A	REGULATOR 24V	TATA spare parts
269428000101	ASSY TRANSFER CASE COMPLETE	TATA spare parts
269428000102	ASSY TRANSFER CASE	TATA spare parts
269428000107	ASSY TRANSFER CASE VG 1600/396 W/O DIFFE	TATA spare parts
269428000109	ASSY. TRANSFER CASE	TATA spare parts
269428000109AE	ASSY TRANSFER CASE 1628 1828	TATA spare parts
269428000110	ASSY. TRANSFER CASE W/O DIFFERENTIAL	TATA spare parts
269428000112	ASSY TRANSFER CASE W/O DIFF	TATA spare parts
269428990122	TRANSFER BOX HOUSING	TATA spare parts
269428990123	HEXAGON SCREW	TATA spare parts
269428990124	HEXAGON SCREW	TATA spare parts
269428990125	SCREW PLUG	TATA spare parts
269428990126	SCREW PLUG	TATA spare parts
269428990127	SCREW PLUG	TATA spare parts
269428990128	SCREW PLUG	TATA spare parts
269428990129	INPUT SHAFT	TATA spare parts
269428990130	OIL DAM	TATA spare parts
269428990131	GEAR SHIFT SLEEVE	TATA spare parts

269428990132	INPUT GEAR	TATA spare parts
269428990133	INPUT GEAR	TATA spare parts
269428990134	BEARING COVER	TATA spare parts
269428990135	CYLINDRICAL PIN	TATA spare parts
269428990136	HEXAGON SCREW	TATA spare parts
269428990137	SHAFT SEAL	TATA spare parts
269428990137AE	SHAFT SEAL 1628 1828	TATA spare parts
269428990138	SHAFT SEAL	TATA spare parts
269428990138AE	SHAFT SEAL 1628 1828	TATA spare parts
269428990139	TA.ROLLER BEARING	TATA spare parts
269428990140	SLOTTED NUT	TATA spare parts
269428990141	INTERMEDIATE PLATE	TATA spare parts
269428990142	BEARING HOUSING	TATA spare parts
269428990143	SLOT.PIN	TATA spare parts
269428990145	OIL PUMP COVER	TATA spare parts
269428990146	BALL	TATA spare parts
269428990147	OIL PUMP HOUSING	TATA spare parts
269428990148	GEAR	TATA spare parts
269428990149	GEAR RING	TATA spare parts
269428990151	CAP SCREW	TATA spare parts
269428990152	CAP SCREW	TATA spare parts
269428990153	COVER	TATA spare parts
269428990154	HEXAGON SCREW	TATA spare parts
269428990155	COVER	TATA spare parts
269428990156	HEXAGON SCREW	TATA spare parts
269428990157	BALL	TATA spare parts
269428990158	SEALING RING	TATA spare parts
269428990159	HOLLOW/UNION SCREW	TATA spare parts
269428990160	OIL TUBE	TATA spare parts
269428990161	SEALING RING	TATA spare parts
269428990162	SOCKET	TATA spare parts
269428990163	UNION NUT	TATA spare parts
269428990164	SOCKET	TATA spare parts
269428990165	HEXAGON NUT	TATA spare parts
269428990166	UNION NUT	TATA spare parts
269428990167	SEALING RING	TATA spare parts
269428990168	PRESSURE RING	TATA spare parts
269428990169	CUTTING RING	TATA spare parts
269428990170	SEALING RING	TATA spare parts
269428990171	SCREW PLUG	TATA spare parts
269428990172	DOUBLE GEAR	TATA spare parts
269428990173	COVER PLATE	TATA spare parts
269428990174	SLOT PIN	TATA spare parts
269428990175	CENTERING RING	TATA spare parts
269428990176	SPEEDOMETER HOUSING	TATA spare parts
269428990177	HEXAGON SCREW	TATA spare parts
269428990178	HEXAGON SCREW	TATA spare parts

269428990179	CIRCLIP	TATA spare parts
269428990180	PUMP CARRIER	TATA spare parts
269428990181	IMPULSTAR	TATA spare parts
269428990182	PULSE SENSOR	TATA spare parts
269428990183	COVER	TATA spare parts
269428990184	CAP SCREW	TATA spare parts
269428990185	CAP SCREW	TATA spare parts
269428990186	COVER	TATA spare parts
269428990187	HEXAGON SCREW	TATA spare parts
269428990188	BEARING HOUSING	TATA spare parts
269428990189	GEAR SHIFT FORK	TATA spare parts
269428990190	COVER	TATA spare parts
269428990191	COVER	TATA spare parts
269428990192	HEXAGON SCREW	TATA spare parts
269428990193	HEXAGON NUT	TATA spare parts
269428990194	CAP NUT	TATA spare parts
269428990195	SCREW PLUG	TATA spare parts
269428990196	BUSH	TATA spare parts
269428990197	WASHER	TATA spare parts
269428990198	PISTON	TATA spare parts
269428990199	COMPRESSION SPRING	TATA spare parts
269428990200	SEALING COLLAR	TATA spare parts
269428990201	BALL BEARING	TATA spare parts
269428990202	CIRCLIP	TATA spare parts
269428990203	GEAR SHIFT SLEEVE	TATA spare parts
269428990204	POT	TATA spare parts
269428990205	SHAFT SEAL	TATA spare parts
269428990206	SHAFT SEAL	TATA spare parts
269428990207	STUD	TATA spare parts
269428990208	STUD	TATA spare parts
269428990209	HEXAGON NUT	TATA spare parts
269428990210	SHIM PLATE	TATA spare parts
269428990211	BEARING COVER	TATA spare parts
269428990212	HEXAGON SCREW	TATA spare parts
269428990213	WASHER	TATA spare parts
269428990214	FLANGE	TATA spare parts
269428990215	COLLAR NUT	TATA spare parts
269428990216	HEXAGON SCREW	TATA spare parts
269428990217	FLANGE	TATA spare parts
269428990218	COLLAR NUT	TATA spare parts
269428990219	GEAR SHIFT FORK	TATA spare parts
269428990220	SCREW	TATA spare parts
269428990221	SLIDING PAD	TATA spare parts
269428990222	SHIFTER ROD	TATA spare parts
269428990223	SHIFT CYLINDER	TATA spare parts
269428990224	SEALING RING	TATA spare parts
269428990225	PISTON	TATA spare parts

269428990226	COVER	TATA spare parts
269428990227	HEXAGON SCREW	TATA spare parts
269428990228	HEXAGON NUT	TATA spare parts
269428990229	REDUCTION PIECE	TATA spare parts
269428990230	SEALING RING	TATA spare parts
269428990231	FLANGE	TATA spare parts
269428990232	HEXAGON SCREW	TATA spare parts
269428990233	SETTING SCREW	TATA spare parts
269428990234	STUD SCREW	TATA spare parts
269428990235	SEALING RING	TATA spare parts
269428990236	PISTON	TATA spare parts
269428990237	SEALING RING	TATA spare parts
269428990238	PISTON	TATA spare parts
269428990239	SEALING RING	TATA spare parts
269428990240	BALL	TATA spare parts
269428990241	SPRING	TATA spare parts
269428990242	BALL VALVE GUIDE	TATA spare parts
269428990243	SET SCREW	TATA spare parts
269428990244	PIN	TATA spare parts
269428990245	SNAP RING	TATA spare parts
269428990246	PRESSURE SWITCH	TATA spare parts
269428990247	COUPLING SLEEVE	TATA spare parts
269428990248	BREATHER	TATA spare parts
269428990249	PRESSURE SWITCH	TATA spare parts
269428990371	HOUSING	TATA spare parts
269428990372	HOUSING	TATA spare parts
269428990373	CYLINDRICAL PIN	TATA spare parts
269428990375	HEXAGON SCREW	TATA spare parts
269428990376	KERNL VERSCHLUSS	TATA spare parts
269428990377	OIL TUBE	TATA spare parts
269428990379	PLUG	TATA spare parts
269428990380	INPUT SHAFT	TATA spare parts
269428990383	CY.ROLL.BEARING	TATA spare parts
269428990384	SNAP RING	TATA spare parts
269428990385	THRUST WASHER	TATA spare parts
269428990386	INPUT GEAR	TATA spare parts
269428990387	G.SHIFT SLEEVE	TATA spare parts
269428990388	INPUT GEAR	TATA spare parts
269428990390	ANTI-ROTATION DEVICE	TATA spare parts
269428990391	SLOTTED NUT	TATA spare parts
269428990392	SHIM	TATA spare parts
269428990393	SHIM	TATA spare parts
269428990394	SHIM	TATA spare parts
269428990395	SHIM	TATA spare parts
269428990396	SHIM	TATA spare parts
269428990397	SHIM	TATA spare parts
269428990398	END COVER	TATA spare parts

269428990399	HEXAGON SCREW	TATA spare parts
269428990400	DOUBLE GEAR (Z19/25)	TATA spare parts
269428990401	CY. ROLL. BEARING	TATA spare parts
269428990403	BEARING COVER	TATA spare parts
269428990404	SCREW PLUG	TATA spare parts
269428990405	SEALING RING (M18X1 5)	TATA spare parts
269428990406	IMPULS STERN	TATA spare parts
269428990407	COUNTER S. SCREW (M16X35)	TATA spare parts
269428990409	OUTPUT SHAFT	TATA spare parts
269428990410	RETAINING RING (95X4)	TATA spare parts
269428990412	G.SHIFT SLEEVE	TATA spare parts
269428990413	GEAR SHIFT FORK	TATA spare parts
269428990414	PISTON ROD	TATA spare parts
269428990415	PISTON	TATA spare parts
269428990416	SHIM RING (30X42X0 1)	TATA spare parts
269428990417	SHIM RING (30X42X0 2)	TATA spare parts
269428990418	SHIM RING (30X42X0 5)	TATA spare parts
269428990419	SHIM RING (30X42X1)	TATA spare parts
269428990420	SET SCREW (M10X12)	TATA spare parts
269428990421	SEALING RING (18X3)	TATA spare parts
269428990423	COMPR.SPRING	TATA spare parts
269428990424	BUSH	TATA spare parts
269428990425	PIN	TATA spare parts
269428990426	PRESSURE SWITCH	TATA spare parts
269428990427	TA.ROLL.BEARING	TATA spare parts
269428990429	INTERNAL RING	TATA spare parts
269428990430	SNAP RING	TATA spare parts
269428990431	OUTPUT SHAFT	TATA spare parts
269428990433	SHIM	TATA spare parts
269428990434	SHIM	TATA spare parts
269428990435	SHIM	TATA spare parts
269428990436	SHIM	TATA spare parts
269428990437	SHIM	TATA spare parts
269428990438	SHIM	TATA spare parts
269428990439	BEARING COVER	TATA spare parts
269428990440	FLANGE	TATA spare parts
269428990441	COLLAR NUT	TATA spare parts
269428990442	HEXAGONAL SCREW	TATA spare parts
269428990443	GEAR SHIFT FORK	TATA spare parts
269428990444	GEAR SHIFT ROD	TATA spare parts
269428990446	PRESSURE SWITCH	TATA spare parts
269428990447	FLANGE	TATA spare parts
269428990448	SET SCREW	TATA spare parts
269428991001	TRANSM. HOUSING	TATA spare parts
269428992001	OUTPUT SHAFT	TATA spare parts
269428992002	OUTPUT SHAFT	TATA spare parts
269428993101	TA. ROLLER BEARING	TATA spare parts



269428993102	CYL. ROLLER BEARING	TATA spare parts
269428993103	CYL. ROLLER BEARING	TATA spare parts
269428993104	TA. ROLLER BEARING	TATA spare parts
269428993701	COVER PLATE	TATA spare parts
269428994301	CIRCLIP	TATA spare parts
269428996501	SLOTTED NUT	TATA spare parts
269428996701	CYL. PIN	TATA spare parts
269428997701	O-RING	TATA spare parts
269428998201	TYPE PLATE (50X35X0.5)	TATA spare parts
269428998202	CLOSURE	TATA spare parts
269428998301	SHIM PLATE	TATA spare parts
269428998302	SHIM PLATE	TATA spare parts
269428998303	SHIM PLATE	TATA spare parts
269428998304	SHIM PLATE	TATA spare parts
269428998305	SHIM PLATE	TATA spare parts
269428998306	SHIM PLATE	TATA spare parts
269428998307	SHIM PLATE	TATA spare parts
269428998308	SHIM PLATE	TATA spare parts
269428998309	SHIM PLATE	TATA spare parts
269428998310	SHIM PLATE	TATA spare parts
269428998311	SHIM PLATE	TATA spare parts
269428998312	SHIM PLATE	TATA spare parts
269428998313	SHIM PLATE	TATA spare parts
269428998314	SHIM PLATE	TATA spare parts
269428998315	SHIM PLATE	TATA spare parts
269428998316	SHIM PLATE	TATA spare parts
269428998317	SHIM PLATE	TATA spare parts
269428998318	SHIM PLATE	TATA spare parts
269428998801	GROOVED STUD	TATA spare parts
269433358201	INNER SLINGER	TATA spare parts
269435108301	SHIM ADJ	TATA spare parts
26948052	RECTIFIER ASSLY.	TATA spare parts
269532400119	ASSY.PIVOT BUSH (INNER)	TATA spare parts
269532400120	ASSY. PIVOT BUSH-OUTER	TATA spare parts
269533358201	INNER SLINGER	TATA spare parts
269533403101	TAPER ROLLER BRG 30204	TATA spare parts
269533403102	TAPER ROLLER BEARING-OUTER	TATA spare parts
269533403103	TAPER ROLLER BEARING-OUTER	TATA spare parts
269533403104	TAPER ROLLER BEARING-OUTER	TATA spare parts
269626806301	WASHER	TATA spare parts
269629108601	SPACER-CLUTCH PEDAL	TATA spare parts
269630107703	RUB CAP ACCL PEDAL STOPER	TATA spare parts
269630108207	PLATE (FOR ACCELERATOR STOPPER) BS6-PH2	TATA spare parts
269632404201	U CLAMP REAR	TATA spare parts
269632807502	RUBBER BUSH FRT ARB	TATA spare parts
269632808204	CUP FRONT ANTIROLL BAR	TATA spare parts
269632808205	CUP FRONT ANTIROLL BAR	TATA spare parts

269633358201	INNER SLINGER	TATA spare parts
269644806801	SOCKET	TATA spare parts
269654504902	FUSE 10A WEDGE TYPE RED	TATA spare parts
269654504903	FUSE 15A WEDGE TYPE BLUE	TATA spare parts
269654504904	FUSE 25A WEDGE TYPE WHITE	TATA spare parts
269654506301	FUSE BOX HOUSING	TATA spare parts
269658900101	ASSY.SCR.JACK(1.6T)WITH HANDLE( SURI)	TATA spare parts
269668900108	ASSY.VENT. HOSE.[ D59 X 755]	TATA spare parts
269669206333	SNAP	TATA spare parts
269672306309	CLIP BOTTOM DOOR SEALING	TATA spare parts
269672506302	CLIP WEATHER STRIP	TATA spare parts
269672526305	CLIP-WEATHER STRIP	TATA spare parts
269729100103	PIPE ASSY	TATA spare parts
269729100106	PEDAL LEVER BRAKE LHD	TATA spare parts
269730100106	PEDAL PLATE ACCL	TATA spare parts
269730100109	ACCL PEDAL ROD COMP RHD	TATA spare parts
269730100112	ACCL PEDAL ROD COML LHD	TATA spare parts
269746600103	RESERVOIR P/STRG	TATA spare parts
269760100105	ASSY.BRAKT.(CLUTCH SLAVE CYLINDER)	TATA spare parts
269815400112	VACCUM PUMP ASSEMBLY KIT	TATA spare parts
269815400113	FASTENERS & SUNDRIES PARTS KIT	TATA spare parts
269815400114	BEARING ASSEMBLY KIT	TATA spare parts
269815400115	CHECK VALVE KIT	TATA spare parts
269815400116	REGULATOR & BRUSH BOX ASSY	TATA spare parts
269815400117	STATOR WINDING FINAL ASSY	TATA spare parts
269815400118	ROTOR ASSYç FINAL	TATA spare parts
269815409906	ALTERNATOR W/6GR.PULLEYV PUMP 75A	TATA spare parts
269815409907	ALTERNATOR 12V 40A W/6GR PULLEY	TATA spare parts
269815409909	12V 75A 6-GR.ALTERNATOR W/VAC PUMP	TATA spare parts
269815409911	VANES	TATA spare parts
269815409912	CENTER PLATE	TATA spare parts
269815409913	ROTOR	TATA spare parts
269815409914	HOUSING M/C FINAL	TATA spare parts
269815409915	S.R.E.BRACKET M/C	TATA spare parts
269815409916	RECTIFIER ARRANGEMENT	TATA spare parts
269815409917	D.E.BRACKET M/C	TATA spare parts
269815409918	PULLEY	TATA spare parts
269824107701	RUBBER BUFFER-FOR OIL FILTER	TATA spare parts
269824200101	ASSY.ENGINE MOUNTING-REAR	TATA spare parts
269829100101	TUBE CLUTCH CYLINDER	TATA spare parts
269829100102	ASSY.CLUTCH HOSE (4.76 I.D)	TATA spare parts
269829100103	ASSLY CLUTCH SLAVE CYL	TATA spare parts
269829100107	ASSY.CLUTCH SLAVE CYL	TATA spare parts
269829100108	P002-49UTCH SLAVE CYLINDER( P7015303)	TATA spare parts
269829100120	ASSY CONNECTING LINE-CLUTCH	TATA spare parts
269829100123	ASSY CLUCH PIPE ( 6 O.D )	TATA spare parts
269829100140	ASSY. STOPPER BOLT WITH RUBBER CAP	TATA spare parts

269829100154	ASSY.SLAVE CYLINDER 23.8 DIA	TATA spare parts
269829100155	ASSY.SLAVE CYLINDER 23.8 DIA	TATA spare parts
269829100156	ASSY.CLUTCH SLAVE CYLINDER	TATA spare parts
269829106705	PIN (FOR CLUTCH PEDAL MTG.)	TATA spare parts
269829207702	RUBBER SEALING	TATA spare parts
269830100104	ASSLY ACC CABLE ACEY ENG	TATA spare parts
269830100105	ASSY ACC.PEDAL ROD COMP RHD	TATA spare parts
269830100107	ASSY.ENGINE STOP CABLE-OFFER DRWG.	TATA spare parts
269830100112	ASSY. BRACKET (ACCL. PEDAL MTG.)	TATA spare parts
269830100113	ASSY. ACCELERATOR ROD-R.H.D.	TATA spare parts
269830100118	ASSY. BRACKET (ACCL PEDAL MTG.)	TATA spare parts
269830100120	ASSY ENGINE STOP CABLE	TATA spare parts
269830100128	ASSY. ACCL. CABLE	TATA spare parts
269830100130	ASSY ENGINE STOP CABLE	TATA spare parts
269830100132	ASSY. ACCL. ROD WITH BRACKET COMPLETE	TATA spare parts
269830107703	RUBBER COVER (PEDAL PLATE)	TATA spare parts
269830108205	BRACKET	TATA spare parts
269830108207	BRACKET ACCL.CABLE MTG.ON ENGINE	TATA spare parts
269830108701	SPRING-FOR ACCELERATOR ROD	TATA spare parts
269831000103	FRAME ASSY COMP NLS-0106	TATA spare parts
269831200110	FRONT CROSS MEMBER SUMO	TATA spare parts
269831200131	ASSY.BRACKET R.H. WHEEL STOPPER	TATA spare parts
269831200132	ASSY.BRACKET - L.H. FOR WHEEL STOPPER	TATA spare parts
269831200145	BKT RR SKIRT SIDE SUPPORT	TATA spare parts
269831200183	ASSY BKT.	TATA spare parts
269831200187	ASSY.JACK LOCATOR	TATA spare parts
269831200199	ASSY.BODY MTG. BRACKET	TATA spare parts
269831208281	ASSY CROSS MEMBER	TATA spare parts
269831210106	ASSY. CROSS MEMBER(FUEL TANK MOUNTING).	TATA spare parts
269831300106	ASSY.CROSS MEMBER FRONT(SPACIO SOFT TOP)	TATA spare parts
269831300107	ASSY BODY MTG.BRACKET (L.H.)	TATA spare parts
269831300110	ASSY. FRONT CROSS MEMBER	TATA spare parts
269831300117	ASSY SUPPORT BRACKET (NOISE SHIELD REAR)	TATA spare parts
269831300119	ASSY NOISE SHIELD	TATA spare parts
269831300123	ASSY BRACKET(NOISE SHEILD MTG)	TATA spare parts
269832100118	ASSY TOP WISHBONE COMP RH	TATA spare parts
269832100119	ASSY TOP WISHBONE COMP LH	TATA spare parts
269832100120	ASSY. TOP WISHBONE	TATA spare parts
269832100136	SUB ASSY LOWER WISHBONE RH	TATA spare parts
269832100137	SUB ASSY LOWER WISHBONE LH	TATA spare parts
269832100138	LOWER WISHBONE RH-MECH STRG.	TATA spare parts
269832100139	ASSY LOWER WISHBONE W/O PIVOT BUSHES RH	TATA spare parts
269832100140	ASSY LOWER WISHBONE W/O PIVOT BUSHES LH	TATA spare parts
269832100141	AS.LOWER WISHBONE COMP LH	TATA spare parts
269832100144	LOWER WISHBONE RH POWER S	TATA spare parts
269832100145	LOWER WISHBONE LH POWER S	TATA spare parts
269832100148	ASSY LOWER WISHBONE RH W/O PIVOT BUSHES	TATA spare parts

269832100149	ASSY LOWER WISHBONE LH W/O PIVOT BUSHES	TATA spare parts
269832100161	ASSY PIN	TATA spare parts
269832100163	ASSY TOP WISHBONE	TATA spare parts
269832100164	ASSY TOP WISHBONE	TATA spare parts
269832100165	ASSY. PIVOT BUSH	TATA spare parts
269832105101	LOWER ARM RH (POWER STG.)	TATA spare parts
269832105102	LOWER ARM LH (POWER STG.)	TATA spare parts
269832107101	STOPPER	TATA spare parts
269832107705	SPRING SEAT TOP	TATA spare parts
269832107706	SPRING SEAT TOP	TATA spare parts
269832107707	SPRING SEAT TOP	TATA spare parts
269832107901	BRAKE ROD-DIA. 20	TATA spare parts
269832120122	ASSY BRACKET COMPLETE-SPG TOP MTG	TATA spare parts
269832120131	ASSY BKT. R H COMP	TATA spare parts
269832120144	ASSY. PIN	TATA spare parts
269832123202	HEXAGONAL BOLT-TOP SPINDLE	TATA spare parts
269832128257	SPECIAL NUT (M12)	TATA spare parts
269832300103	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
269832300104	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
269832300105	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
269832320105	ASSY.BRACKET RH SHOCK ABS MTG. TOP	TATA spare parts
269832320106	ASSY.BRACKET LH-SHOCK ABS MTG.TOP	TATA spare parts
269832400104	ASSY. REAR SPRING	TATA spare parts
269832400126	ASSY SPG.HANGER BKT.	TATA spare parts
269832400128	ASSY BKT. SPG HANGER	TATA spare parts
269832400129	ASSY BKT. SPG HANGER FRT RH	TATA spare parts
269832400134	ASSY GUIDE PLATE L H	TATA spare parts
269832400135	ASSY GUIDE PLATE R H	TATA spare parts
269832400143	ASSY. GUIDE PLATE - LH-REAR SPRING	TATA spare parts
269832400144	ASSY. GUIDE PLATE - RH (REAR SPRING)	TATA spare parts
269832400148	ASSY.SPRING HANGER BRACKET FRONT L.H.	TATA spare parts
269832400149	ASSY.SPRING HANGER BRACKET FRONT R.H.	TATA spare parts
269832403401	MAIN SPRING BUSH	TATA spare parts
269832406701	SPRING PIN	TATA spare parts
269832406702	SPRING PIN	TATA spare parts
269832406703	SPRING PIN	TATA spare parts
269832407124	CENTER PAD	TATA spare parts
269832407149	CENTER PAD	TATA spare parts
269832407701	TIP INSERT	TATA spare parts
269832409204	WASHER	TATA spare parts
269832409207	WASHER NYLON	TATA spare parts
269832409208	WASHER	TATA spare parts
269832600105	SHOCK ABSORBER REAR	TATA spare parts
269832600108	ASSY BKT. R H	TATA spare parts
269832600109	ASSY BKT. L H	TATA spare parts
269832600111	ASSY. BRACKET REAR S/A (LH)PARABOLIC SPG	TATA spare parts
269832600112	ASSY. BRACKET REAR S/A RH PARABOLIC SPG	TATA spare parts

269832600116	ASSY. BRACKET - LH (REAR S/A MTG.)	TATA spare parts
269832600117	ASSY. BRACKET - RH (REAR S/A MTG.)	TATA spare parts
269832600118	ASSY. REAR SHOCK ABSORBER	TATA spare parts
269832600119	ASSY REAR SHOCK ABSORBER	TATA spare parts
269832600120	ASSY. SHOCK ABSORBER REAR BS2/3/4	TATA spare parts
269832608204	WASHER	TATA spare parts
269832800102	CLAMP ARB FRT BRG LOWER	TATA spare parts
269832800106	ASSY.CLAMP (FRT.ARB.MTG)	TATA spare parts
269832800108	ASSY BKT- FRT. ANTIROLL BAR	TATA spare parts
269832800109	ASSY. SLEEVE-FRT. ANTI ROLL BAR	TATA spare parts
269832807701	RUBBER BUSH FRT ARB TOP	TATA spare parts
269832807702	RUBBER BUSH FRT ARB TOP	TATA spare parts
269832807703	RUBBER BUSH(FRT.ARB 28 DIA)	TATA spare parts
269832807901	ANTI ROLL BAR FRONT 24D	TATA spare parts
269833000102	ASSY FRONT AXLE L H-MECH STRG	TATA spare parts
269833000103	ASSY FRONT AXLE R H-MECH STRG	TATA spare parts
269833208302	SHIM 0.1 THICK.	TATA spare parts
269833208303	SHIM 0.15 THICK.	TATA spare parts
269833208304	SHIM 0.2 THICK.	TATA spare parts
269833208305	SHIM 0.25 THICK.	TATA spare parts
269833208306	SHIM 0.3 THICK.	TATA spare parts
269833208307	SHIM 0.4 THICK.	TATA spare parts
269833208308	SHIM 0.5 THICK.	TATA spare parts
269833208309	SHIM 0.7 THICK.	TATA spare parts
269833208601	SPACER TUBE	TATA spare parts
269833805101	TIE ROD ARM RH	TATA spare parts
269833805102	TIE ROD ARM LH	TATA spare parts
269840100110	ASSY. WHEEL RIM 4.50E16	TATA spare parts
269840100120	ASSY.WHEEL RIM 5.5JX16	TATA spare parts
269840300105	HEX BOLT	TATA spare parts
269840309902	NYLON SPACER	TATA spare parts
269841100101	KIT-UNIVERSAL JOINT BS1/2/3/4	TATA spare parts
269841105101	INTERM END YOKE	TATA spare parts
269841106501	NUT	TATA spare parts
269841109201	WASHER	TATA spare parts
269841110116	ASSY.C.B.BRACKET	TATA spare parts
269841110118	KIT FOR SLIP YOKE ASSY	TATA spare parts
269841110120	ASSY.CENTRE BRG (W/O EXTN) KIT	TATA spare parts
269841113101	BEARING	TATA spare parts
269841115101	KIT FOR MIDSHIP TUBE SHAFT	TATA spare parts
269841117701	C.B.RUBBER	TATA spare parts
269841118201	DUST SEAL RETAINER	TATA spare parts
269841118202	DUST SEAL	TATA spare parts
269841118203	BRACKET	TATA spare parts
269841118204	SLINGER	TATA spare parts
269841119901	L'TYPE SPACER	TATA spare parts
269841120101	ASSY. PROPELLER SHAFT REAR	TATA spare parts

269841300101	CENTRE BEARING COMP.-NLS	TATA spare parts
269841304201	CLAMP	TATA spare parts
269841308202	RETAINER	TATA spare parts
269841308203	DUST COVER	TATA spare parts
269842100160	ASSY.CALIPER BRAKE LH WITH AF3771	TATA spare parts
269842100161	ASSY.CALIPER BRAKE RH WITH AF3771	TATA spare parts
269842228203	CENTER BEARING BRACKET	TATA spare parts
269842700104	PARKING BRAKE UNIT	TATA spare parts
269842700109	HAND BR CABLE RR	TATA spare parts
269842700110	HAND BR CABLE RR	TATA spare parts
269842700111	LEVER ASSY	TATA spare parts
269842700117	ASSY LEVER LH	TATA spare parts
269842700118	BRACKET PARKING BRAKE	TATA spare parts
269842700131	P.B.CABLE REAR	TATA spare parts
269842700158	ASSY.PARK.BRAKE LEVER MTG.BRKT.(ON FLOOR	TATA spare parts
269842700160	ASSY.PARKING BRAKE CABLE - FRONT(OFFER)	TATA spare parts
269842700161	ASSY.PARKING BRAKE CABLE REAR I	TATA spare parts
269842700165	ASSY.PARKING BRAKE LEVER	TATA spare parts
269842700180	ASSY SEALING PLATE	TATA spare parts
269842706705	PIN (FOR PARKING LEVER)	TATA spare parts
269842707102	PARKING BRAKE BRACKET MOUNTING PLATE	TATA spare parts
269842708601	SPACER	TATA spare parts
269842800102	TUBE ASSY	TATA spare parts
269842800106	TUBE ASSY	TATA spare parts
269842800107	TUBE ASSY	TATA spare parts
269842800118	ASSY. CLAMP	TATA spare parts
269842800119	ASSY. CLAMP	TATA spare parts
269842800127	ASSY. TUBE	TATA spare parts
269842800129	ASSY. BRACKET-FOR REAR TEE CLAMPING	TATA spare parts
269842800130	ASSY PIPE	TATA spare parts
269842800131	ASSY PIPE	TATA spare parts
269842800134	ASSY.BRACKET(PIPE CLAMPING )	TATA spare parts
269842800136	ASSY. CLAMP BS6	TATA spare parts
269842800146	ASSY.TUBE	TATA spare parts
269842800150	ASSY TUBE	TATA spare parts
269842800151	ASSY.TUBE	TATA spare parts
269842800152	ASSY BKT REAR BRAKE PIPE CLAMPING	TATA spare parts
269842800153	ASSY. BRACKET-REAR BRAKE TEE CLAMPING	TATA spare parts
269842804201	CLAMP	TATA spare parts
269842804202	CLAMP SINGLE COATED	TATA spare parts
269842804204	CLAMP	TATA spare parts
269843000106	ASSY SERVO UNIT 10 BOOSTER AL	TATA spare parts
269843000108	SERVO UNIT WITH 10 INCH ZDS BOOSTER	TATA spare parts
269843000109	ASSY.SERVO UNIT WITH 10 ZDS BOOSTER	TATA spare parts
269843000116	ASSY SERVO UNIT-10INCH ZDS-BR6.7 FOR LHD	TATA spare parts
269843100101	TANDEM MASTER CYL.DIA.23.81 BS1/2/3/4	TATA spare parts
269843100102	TANDAM MASTER CYL	TATA spare parts

269843100104	TANDEM MASTER CYL.DIA.23.81	TATA spare parts
269843100105	BRAKE FLUID RESERVOIR	TATA spare parts
269843100107	TMC W/O RESV ALUMINIUM	TATA spare parts
269843100108	ASSY.TANDEM MASTER CYL.DIA.23.81 .	TATA spare parts
269843100109	ASSY. BRAKE FLUID CONTAINER	TATA spare parts
269843100110	TANDEM MASTER CYL.DIA.23.81	TATA spare parts
269843100113	SERVICE KIT	TATA spare parts
269843100116	LEVEL INDICATOR	TATA spare parts
269843100117	10 BOOSTER ASSEMBLY	TATA spare parts
269843109001	NON RETURN VALVE ASSEMBLY	TATA spare parts
269843109201	WASHER SAFETY	TATA spare parts
269843500103	BOOSTER 10 IN DIA. ZDS 6.5 BOOST RATIO	TATA spare parts
269846200101	SLEEVE ASSY -L164	TATA spare parts
269846200135	ASSY. SLEEVE.	TATA spare parts
269846200140	STRG GEAR BOX RHD--NEW	TATA spare parts
269846200142	ASSY STRG NUT AND WORM WITHOUT BEARING	TATA spare parts
269846203102	BALL BEARING	TATA spare parts
269846206301	RUBBER BELLOW BOTTOM	TATA spare parts
269846207906	STRG SPINDLE BOTTOM	TATA spare parts
269846207913	STEERING SPINDLE BOTTOM	TATA spare parts
269846207916	STEERING SPINDLE - BOTTOM	TATA spare parts
269846207922	SECTOR SHAFT (RATIO: 32.5 TO 36.5)	TATA spare parts
269846209902	FIXING STRAP L H	TATA spare parts
269846300101	IDLER ARM	TATA spare parts
269846300107	ASSY. IDLER ARM-RHD MECH. STG.	TATA spare parts
269846300108	IDLER ARM (NEW SUSP) MECH STGSPACIO	TATA spare parts
269846300110	ASSY.IDLER ARM COMPLETE-RHD POWER STG.	TATA spare parts
269846306001	PITMAN ARM	TATA spare parts
269846306005	PITMAN ARM NEW M.STRG.	TATA spare parts
269846306007	PITMAN ARM NEW	TATA spare parts
269846400102	ASY.STG.WHEEL (420 DIA.GRAY)	TATA spare parts
269846400103	ASSY.STEERING WHEEL-420 DIA.GRAY	TATA spare parts
269846400104	ASSY.STEERING WHEEL-420 DIA.GRAY	TATA spare parts
269846400108	A. STR. WHEEL EZI-BLK	TATA spare parts
269846400113	ASSY.STG.WHEEL(380 DIA.BLACK )	TATA spare parts
269846600112	ASSLY CENTRE LINK	TATA spare parts
269846600125	ASSY CENTRE LINK QH TALBROS-0149CLACROc2	TATA spare parts
269846600131	ASSY CENTRE LINK (M/S RANE) 113083410C	TATA spare parts
269846600132	ASSY P/STG PUMP 70 BAR TRW 30220054	TATA spare parts
269847100106	CAP FUEL TANK	TATA spare parts
269847100120	ASSY FUEL TANK CAP COMPLETE-DIESEL	TATA spare parts
269847100178	ASSY FUEL FILLER NECK TOP WITH BRACKET	TATA spare parts
269847107701	HOSE FUEL FILLING	TATA spare parts
269847508203	CLAMP ( 10 OD PIPE)	TATA spare parts
269847508204	CLAMP (8 OD PIPE)	TATA spare parts
269847508206	BRACKET	TATA spare parts
269847508209	CLAMPING PLATE BS6	TATA spare parts

269847508210	BRACKET BS6	TATA spare parts
269847508211	CLAMP (15 DIA HOSE)	TATA spare parts
269847508211AE	CLAMP 1628	TATA spare parts
269847508212	CLAMP (15 DIA HOSE)	TATA spare parts
269847600101	FUEL SUCTION PIPE	TATA spare parts
269847600102	FUEL RETURN LINE	TATA spare parts
269847600103	PIPE BREATHER	TATA spare parts
269847600104	COATED CLAMP(13X13)	TATA spare parts
269847600112	ASSY.BREATHER PIPE	TATA spare parts
269847600117	ASSY SUCTION LINE-HOSE TO FILTER	TATA spare parts
269847600130	ASSY NYLON PIPE FILTER TO PUMP	TATA spare parts
269847606917	RETURN LINE (HOSE TO HOSE)	TATA spare parts
269849100103	SIENCER WITH BKT.	TATA spare parts
269849100104	SILENCER ASSY	TATA spare parts
269849100105	ASSY. MAIN SILENCER	TATA spare parts
269849100106	SILENCER ASSY	TATA spare parts
269849100129	OFER PART NO.ASSY SILENCER	TATA spare parts
269849100131	ASSY. MAIN SILENCER	TATA spare parts
269849200134	EXHAUST PIPE FRONT	TATA spare parts
269849200139	EXH.PIPE FRONT SUMO4X2	TATA spare parts
269849200144	ASSY.BRACKET(SILENCER MTG.)	TATA spare parts
269849200155	ASSY GASKET(SANKAR SEALING-SS/TL/1194/1)	TATA spare parts
269849200172	ASSY.GASKET EXH.MANIFOLD PIPE	TATA spare parts
269849204203	HOOK C/BRG CROSS MEMBER	TATA spare parts
269849204208	HOOK C/BRG CROSS MEMBER	TATA spare parts
269849207702	RUBBER HANGER BS1/2/3/4	TATA spare parts
269849207702AE	RUBBER HANGER(EXH)-XEN DC/SC	TATA spare parts
269849207703	RUBBER HANGER-EXHAUST	TATA spare parts
269854100103	ASSY.BATTERY CABLE +VE & -VE RHD	TATA spare parts
269854109901	EARTH STRAP	TATA spare parts
269854200127	BKT ECU MTG RHD 4X4	TATA spare parts
269854200129	BRACKET ASSY	TATA spare parts
269854200185	ASSY SEAT BELT & DOOR AJAR BEPPER	TATA spare parts
269854204902	HIGH TEMP CUT OFF MODULE	TATA spare parts
269854207501	SEAL RING (FUEL TANK UNIT)	TATA spare parts
269854209903	SPEEDOMETER 1:1.3 6+1	TATA spare parts
269854209907	SPEEDO CABLE 1350MM	TATA spare parts
269854209908	SPEEDOMETER 1:1.3 (BACKLIT)	TATA spare parts
269854209909	FUEL GAUGE (BACKLIT) .	TATA spare parts
269854209910	TEMPERATURE GAUGE (BACKLIT) .	TATA spare parts
269854209912	GAUGE FUEL BACKLIT	TATA spare parts
269854209913	TEMPERATURE GAUGE-BACKLIT	TATA spare parts
269854209914	FUEL GAUGE (BACKLIT) OFFER DRG.	TATA spare parts
269854209915	TEMPERATURE GAUGE-BACKLIT	TATA spare parts
269854209918	GAUGE FUEL BACKLIT	TATA spare parts
269854209919	TEMP GAUGE BACKLIT	TATA spare parts
269854209926	SPEEDOMETER 1:1.26 BACKLIT	TATA spare parts



269854209935	3.2 DIA.SPEEDOCABLE 1900 LG.JIS.	TATA spare parts
269854209951	FUEL GAUGE	TATA spare parts
269854209953	TEMP GAUGE W/ A/C C/O	TATA spare parts
269854209968	HORN 12V LOW TONE	TATA spare parts
269854209973	TANK UNIT 65 LTRS. .	TATA spare parts
269854209980	HORN 12V	TATA spare parts
269854209981	HORN MOUNTING BRACKET	TATA spare parts
269854209982	ASSY.HORN-(100DIA)12V LOW TONE	TATA spare parts
269854209983	HORN 12V DC	TATA spare parts
269854400107	ASSY TAIL LAMP LH MSSL 12V	TATA spare parts
269854400108	ASSY TAIL LAMP RH MSSL 12V	TATA spare parts
269854400109	TAIL LAMP LH	TATA spare parts
269854400110	TAIL LAMP RH	TATA spare parts
269854400111	ASSY TAIL LAMP LH MSSL 12V	TATA spare parts
269854400112	ASSY TAIL LAMP RH MSSL 12V (FIEM)	TATA spare parts
269854400126	REG PLATE LAMP RH	TATA spare parts
269854400131	BLINKER LAMP W/'E'CERT.BULB LH	TATA spare parts
269854400132	BLINKER LAMP W/'E' CERT.BULB RH	TATA spare parts
269854400135	REG PLATE LAMP LH	TATA spare parts
269854400136	REG PLATE LAMP RH	TATA spare parts
269854400140	REG. PL LAMP RH ELECT	TATA spare parts
269854400151	TAIL LAMP LH W/BEADING	TATA spare parts
269854400152	TAIL LAMP RH W/BEADING	TATA spare parts
269854400171	ROOF LAMP JAY	TATA spare parts
269854400175	ASSY.REVOLVING LAMP (BLUE)	TATA spare parts
269854400176	ASSY.ROUND HEAD LAMP	TATA spare parts
269854400182	T/L E-CER W/E-CER BULBS W/BEADING- OFFER	TATA spare parts
269854400183	T/L E-CER W/E-CER BULBS W/BEADING-OFFER	TATA spare parts
269854400184	ASSY.ROUND HEAD LAMP	TATA spare parts
269854400185	ASSY. ROUND HEAD LAMP	TATA spare parts
269854400188	ASSY.ROUND HEAD LAMP	TATA spare parts
269854408201	PLATE [ENGINE LAMP CUT-OUT]	TATA spare parts
269854409903	HOUSING CFLT	TATA spare parts
269854410110	ASSY. REVOLVING LAMP (BLUE) OFFER.	TATA spare parts
269854410117	TAIL LAMP RH SUMO RINDER	TATA spare parts
269854410121	ASSY.HIGH MOUNTED STOP LAMP	TATA spare parts
269854410123	ASSY.BRACKET FOR HIGH MOUNTED STOP LAMP	TATA spare parts
269854500111	HEAD LAMP LEVELLING SW[VERTICAL]	TATA spare parts
269854500112	HEAD LAMP LEVELLING SW[VERTICAL]	TATA spare parts
269854500113	HEAD LAMP LEVELLING SW[VERTICAL]	TATA spare parts
269854500126	ASSY.COMBI SW.18P W/2 STALKS	TATA spare parts
269854500128	STOP LIGHT SWITCH	TATA spare parts
269854500134	STEERING LOCK CUM IGNITION SW.	TATA spare parts
269854500135	PRESSURE SWITCH	TATA spare parts
269854500140	ASSY.REV.LT.SW.	TATA spare parts
269854500144	2-SPEED BLOWER SWITCH	TATA spare parts
269854500145	PIANO KEY SWITCH-REAR FOG	TATA spare parts

269854506303	DUMMY PIANO SWITCH COVER	TATA spare parts
269854509901	REVERSE LIGHT SWITCH	TATA spare parts
269854509906	FLASHER	TATA spare parts
269854600110	WIRING HARNESS FRONT	TATA spare parts
269854620106	WIRING HARNESS ENGINE	TATA spare parts
269854620179	W\H ROOF SUMO DLX	TATA spare parts
269854700109	SWITCH FRESH/RECOND.AIR	TATA spare parts
269854704901	AMPLIFIRE RELAY	TATA spare parts
269854709906	LOW SPEED RESISTOR-FUSIBLE	TATA spare parts
269854709908	LOW SPEED RESISTOR-FUSIBLE	TATA spare parts
269854807502	GROMMET ANTENNA HOLE 2.5 DIA.	TATA spare parts
269854900110	KIT IMMOBILISER KEYLESS ENTRY	TATA spare parts
269854900112	ASSY.MASTER ACTUATOR (NEW)MINDA HUF	TATA spare parts
269854909913	REMOTE . HUF	TATA spare parts
269854909914	OWNERS MANUAL	TATA spare parts
269858408208	MANUFACTURERS PLATE	TATA spare parts
269858900102	SCISSORS JACK W/3P HANDLE	TATA spare parts
269858900114	ASSY.SCISS.JACK WITH 3PC. HANDLE	TATA spare parts
269858900701	ADAPTOR / CHECKING ENGINE COMPRESSION /	TATA spare parts
269858903504	REMOVER YOKE	TATA spare parts
269858903506	HANDLE UNIVERSAL	TATA spare parts
269858903507	PULLER SLIDE HAMMER	TATA spare parts
269858903508	INSTALLER FRONT PIN BRG. CUP	TATA spare parts
269858903509	INSTALLER RR. PIN. BRG. CUP	TATA spare parts
269858903510	REMOVER FRONT PIN. BRG. CUP	TATA spare parts
269858903511	REMOVER RR PIN. BRG. CUP	TATA spare parts
269858903512	INSTALLER DIFFL. SIDE BRG	TATA spare parts
269858903513	INSTALLER PINION OIL SEAL	TATA spare parts
269858903514	MASTER BEARING.DIFF.	TATA spare parts
269858903515	PRESS	TATA spare parts
269858903517	SPREADER AXLE HOUSING	TATA spare parts
269858903519	INSTALLER REAR PINION BEARING CONE	TATA spare parts
269858903520	PINION HEIGHT SET (INCLUDES MASTER BLOCK	TATA spare parts
269858903524	UNITIZED BRG. PULLER	TATA spare parts
269858903525	HANDLE / REMOVE PINION I-O CUP / SPRINT	TATA spare parts
269858903526	EXPANDER / CARRIER HSG / SPRINT	TATA spare parts
269858903527	PINION HEIGHT SETTING GAUGE / SPRINT	TATA spare parts
269858903528	PINION HEIGHT MASTER BLOCK / SPRINT	TATA spare parts
269858903529	DUMMY BRG / DIFF. CASE / BACKLASH/SPRINT	TATA spare parts
269858903530	P-DOLLEY / PINION INNER CUP / SPRINT	TATA spare parts
269858903531	P-DOLLEY / PINION OUTER CUP / SPRINT	TATA spare parts
269858903532	P-DOLLEY / PINION INNER CONE / SPRINT	TATA spare parts
269858903533	P-DOLLEY / DIFF CASE BRGS / SPRINT	TATA spare parts
269858903534	ADAPTOR / REMOVE DIFF CASE BRGS / SPRINT	TATA spare parts
269858903535	ADAPTOR / R-PINION INNER BRGS / SPRINT	TATA spare parts
269858903536	ADAPTOR / R-PINION OUTER CUP / SPRINT	TATA spare parts
269858903537	ADAPTOR / R-PINION INNER CUP / SPRINT	TATA spare parts

269858903538	P-DOLLEY / PINION OIL SEAL / SPRINT	TATA spare parts
269858903539	P-DOLLEY / T-F INBOARD OIL SEAL / SPRINT	TATA spare parts
269858903540	PULLER/P- & BM FLNGE INBO O-SEAL/SPRINT	TATA spare parts
269858903541	HOLDER/END YOKE/R & I PINION NUT/SPRINT	TATA spare parts
269858903542	PRESS /R- PINION & DIFF CASE BRG /SPRINT	TATA spare parts
269858903543	PLUNGER DIAL / SPRINT	TATA spare parts
269858903544	TOMMY BARS / R-DIFF CASE ASSY / SPRINT	TATA spare parts
269858903545	TRACK LOCK TOOL KIT/R-CLUTCH PACK/SPRINT	TATA spare parts
269858903546	PULLER / REMOVE AXLE SHAFT BRG / SPRINT	TATA spare parts
269858904101	SOCKET FOR COUPLING FLANGE NUT	TATA spare parts
269858904102	HOLDER	TATA spare parts
269858904103	SOCKET FOR COUPLING FLANGE NUT.	TATA spare parts
269858905001	TOOL BAG BS6	TATA spare parts
269860000101	BODY SHELL WITH DOORS PAINTED(0142)	TATA spare parts
269860100102	TIE MEMBER	TATA spare parts
269860100118	BKT FRT RH SIDE BONNET	TATA spare parts
269860100125	ASSY. TOP RAIL RR OUTER	TATA spare parts
269860108299	RAIN CHANNEL REAR	TATA spare parts
269860110135	ASSY.SUPPORT BRACKET (BATTERY MTG) RHD	TATA spare parts
269860128235	RAIN CHANNEL REAR	TATA spare parts
269860600101	ASSY PANEL INNER W/S TOP	TATA spare parts
269860600103	ASSY PANEL INNER SIDE BONNET COMP. RH	TATA spare parts
269860600108	MUDGUARD FRONT LH--0115	TATA spare parts
269860600119	ASSY REINFORCEMENT RH (MUD GUARD)	TATA spare parts
269860600135	ASSY MUD GUARD WITH REINFORCEMENT LH	TATA spare parts
269860600141	ASSY.PANEL INNER SIDE BONNET LH	TATA spare parts
269860600142	ASSY.PANEL INNER SIDE BONNET RH	TATA spare parts
269860600147	ASSY.PANEL INNER TOP RAIL REAR	TATA spare parts
269860600176	ASSY MUDGUARD WITH REINFORCEMENT LH (TC)	TATA spare parts
269860600177	ASSY MUDGUARD WITH REINF.& BRACKET RH	TATA spare parts
269860608205	REINF LH INN SIDE BONNET	TATA spare parts
269860608206	REINF RH INN SIDE BONNET	TATA spare parts
269861010162	ASSY.SUBSTRUCTURE WITH REAR FLOOR	TATA spare parts
269861600130	ASSY BRACKET FRONT LH (CAB LIFTING)	TATA spare parts
269861600131	ASSY BRACKET FRONT RH (CAB LIFTING)	TATA spare parts
269862500107	ASSY PANEL W/S OUTER BOTTOM COMPLETE RH	TATA spare parts
269862508208	PANEL W/S OUT BOTTOM	TATA spare parts
269862600103	SUPPORT PANEL W/S	TATA spare parts
269863100132	ASSY.DOOR POST FRONT COMP.RH RHD.	TATA spare parts
269863100138	ASSY.SUPPORT SIDE RH [D/ BOARD C/ MEMBER	TATA spare parts
269863100139	ASSY.SUPPORT SIDE LH [D/ BOARD C/ MEMBER	TATA spare parts
269863100142	ASSY BRACKET BOTTOM LH (SEAT BELT MTG)	TATA spare parts
269863100158	ASSY REINFORCEMENT RH (TAIL GATE POST)	TATA spare parts
269863100178	ASSY TAIL GATE POST WITH REINF.RH	TATA spare parts
269863108202	SIDE PANEL OUTER RH	TATA spare parts
269863108204	DOOR POST FRONT RH	TATA spare parts
269863108205	SILL LH	TATA spare parts

269863108206	SILL RH	TATA spare parts
269863108208	DOOR POST MIDDLE RH	TATA spare parts
269863108209	TAIL GATE POST LH	TATA spare parts
269863108211	FENDER OUTER RR LH	TATA spare parts
269863108212	FENDER OUTER RR RH	TATA spare parts
269863108213	TOP RAIL SIDE OUTER L.H.	TATA spare parts
269863108214	TOP RAIL SIDE OUTER R.H.	TATA spare parts
269863108215	REINFORCEMENT DOOR POST FRONT LH	TATA spare parts
269863108216	REINF DOOR POST FRONT RH	TATA spare parts
269863108221	REINF TAIL GATE INNER LH	TATA spare parts
269863108225	RAIN CHANNEL FRONT LH	TATA spare parts
269863108226	RAIN CHANNEL FRONT RH	TATA spare parts
269863108232	RAIN CHANNEL RH CORN SIDE	TATA spare parts
269863108277	REINF TOP LH DR POST FRT	TATA spare parts
269863108278	REINFORCEMENT TOP RH [DOOR POST FRONT]	TATA spare parts
269863110174	DOOR POST MIDDLE	TATA spare parts
269863110175	DOOR POST MIDDLE RH	TATA spare parts
269863118216	SILL LH (W/O HOLES)	TATA spare parts
269863118217	SILL RH (W/O HOLES)	TATA spare parts
269863120150	ASSY REINFORCEMENT LH	TATA spare parts
269863120167	ASSY RAIN CHANNEL SIDE LH (WITH REINF.	TATA spare parts
269863120168	ASSY RAIN CHANNEL SIDE RH (WITH REINF.	TATA spare parts
269863600109	ASSY.PANEL INER FR POSTLH	TATA spare parts
269863600110	ASY.PANEL INNER FR POSTRH	TATA spare parts
269863600112	WHEEL ARCH LH REAR	TATA spare parts
269863600123	PANEL L.H.	TATA spare parts
269863600124	PANEL R.H.	TATA spare parts
269863608207	PANNEL INNER SIDE LH	TATA spare parts
269863608215	PANEL SIDE W/S INNER LH	TATA spare parts
269863608216	PANEL SIDE W/S INNER RH	TATA spare parts
269865700101	ROOF BOW MIDDLE	TATA spare parts
269865708201	ROOF PANEL	TATA spare parts
269865708203	ROOF BOW	TATA spare parts
269867100106	SIDE WINDOW LH	TATA spare parts
269867100107	SIDE WINDOW RH	TATA spare parts
269867100112	ASSY SIDE WINDOW WITH RUBBER MOULD LH	TATA spare parts
269867100113	ASSY SIDE WINDOW WITH RUBBER MOULD RH	TATA spare parts
269867102301	WIND SHIELD GLASS	TATA spare parts
269867102302	REAR WIND SHIELD GLASS	TATA spare parts
269867102303	SLIDING GLASS LH FRONT	TATA spare parts
269867102304	SLIDING GLASS RH FRONT	TATA spare parts
269867102305	SLIDING GLASS LH REAR	TATA spare parts
269867102306	SLIDING GLASS RH REAR	TATA spare parts
269867102313	W/S GLASS CLEAR LAMINATED	TATA spare parts
269867102314	SLIDING GLASS LH FRONT	TATA spare parts
269867102315	SLIDING GLASS FRT RH (TINTED)	TATA spare parts
269867102316	SLIDING GLASS LH REAR	TATA spare parts

269867102317	SLIDING GLASS RH REAR	TATA spare parts
269867102318	REAR WIND SHIELD GLASS(TINTED)	TATA spare parts
269867102319	W/S GLASS TINTED	TATA spare parts
269867102320	REAR WIND SHIELD GLASS.	TATA spare parts
269867106302	RUBBER MOULD RR W/S GLASS	TATA spare parts
269867106303	VELVET CHANNEL RR FIX WIN	TATA spare parts
269867106305	SUPPORT VELVET CHANNEL	TATA spare parts
269867106307	RUBBER MOULD	TATA spare parts
269867106316	RUBBER MOULD (W/S GLASS)	TATA spare parts
269867108201	FRAME OUT RR WINDOW LH	TATA spare parts
269867108202	FRAME OUT RR WINDOW RH	TATA spare parts
269868406307	MEL SHEET FLOOR FRONT	TATA spare parts
269868406309	MEL SHEET TUNNEL FRONT	TATA spare parts
269868406313	MEL SHEET FIRE WALL LH	TATA spare parts
269868800101	KIT FLOOR MAT	TATA spare parts
269868900105	GLOVE BOX ASSY	TATA spare parts
269868900118	ASSY KIT FOR NACELLE	TATA spare parts
269868900121	ASSY GLOVE BOX LOCK	TATA spare parts
269868900134	ASSY KIT FOR NACELLE	TATA spare parts
269868900142	GLOVE BOX COMPLETE	TATA spare parts
269868906301	DASHBOARD SKIN RHD BLACK	TATA spare parts
269868906306	DASHBOARD LHD	TATA spare parts
269868906325	NACELLE FRONT	TATA spare parts
269868906326	NACELLE REAR	TATA spare parts
269868906330	COVER (D/B VENT.CUT OUT)	TATA spare parts
269868906366	CAP (SELF TAPPING SCR.)	TATA spare parts
269868906366C7	GRANIT_BLACK-CAP (SELF TAPPING SCR.) [VI	TATA spare parts
269868906366D3	JDR_MID_GREY-CAP (SELF TAPPING SCR.) [VI	TATA spare parts
269868906367	WASHER (SELF TAPPING SCR.)	TATA spare parts
269868908001	CR.PAN.HD.SCR.M6 X 22	TATA spare parts
269868908002	CR.RD.CSK.SCR.M6 X 16	TATA spare parts
269868908003	SELF TAPPING SCREW (PAN HEAD)	TATA spare parts
269869506308	INSULATION FRONT SUMO EX	TATA spare parts
269869506309	INSULATION SECOND	TATA spare parts
269869506310	INSULATION THIRD SUMO EX	TATA spare parts
269869509902	PIN (ROOF LINING)	TATA spare parts
269869509904	PIN (ROOF LINING)	TATA spare parts
269872200101	ASSY.DOOR SHELL FRONT LH	TATA spare parts
269872200102	DOOR SHELL FRONT RH	TATA spare parts
269872200111	ASSY.GUIDE CHANNEL FRONT LH	TATA spare parts
269872200112	ASSY.GUIDE CHANNEL FRONT RH	TATA spare parts
269872200171	DOOR SHELL FRONT LH DX	TATA spare parts
269872200172	DOOR FRONT RH DX-10121	TATA spare parts
269872300102	ASSY. OUTER DOOR HANDLE LH BS2/3/4/6	TATA spare parts
269872300102C7	GRANIT_BLACK-ASSY OUTER HANDLE LH BS6	TATA spare parts
269872300103	ASSY. OUTER DOOR HANDLE RH BS2/3/4/6	TATA spare parts
269872300103C7	GRANIT_Black-ASSY OUTER HANDLE RH BS6	TATA spare parts

269872300109	KIT LOCKS	TATA spare parts
269872300110	LOCKBARRELFRONTDOOR(JAI) BS6	TATA spare parts
269872300112	LOCK BARREL FRONT DOOR	TATA spare parts
269872300115	ASSY DOOR HINGE LH	TATA spare parts
269872300116	DOOR HINGE RH	TATA spare parts
269872300117	DOOR STRAP FRT RH NLS	TATA spare parts
269872300128	ASSY KIT FOR LOCKS	TATA spare parts
269872300129	ASSY INNER HANDLE	TATA spare parts
269872300138	A. HANDLE WIN. WINDING SUMO IMP.	TATA spare parts
269872300149	ASSY INNER HANDLE	TATA spare parts
269872300150	ASSY INNER HANDLE LH	TATA spare parts
269872300151	ASSY INNER HANDLE RH (JAY INDUSTRIES)	TATA spare parts
269872300190	ASSY. KIT FOR LOCKS . HUF	TATA spare parts
269872306001	LINK POP UP KNOB LH	TATA spare parts
269872306002	LINK POP UP KNOB RH	TATA spare parts
269872306004	LINK INNER HANDLE RH	TATA spare parts
269872306005	LINK OUTER HANDLE LH	TATA spare parts
269872306006	LINK OUTER HANDLE RH	TATA spare parts
269872306009	CONNECTING PIN OUT HANDLE	TATA spare parts
269872306013	LINK FR LOCK BARREL-LATCH	TATA spare parts
269872306014	LINK FRONT DOOR	TATA spare parts
269872306025	LINK LH (BELL CRANK TO LATCH) FR DOOR	TATA spare parts
269872306026	LINK RH (BELL CRANK TO LATCH) FR DOOR	TATA spare parts
269872306027	LINK LH (BELL CRANK CLU) FR DOOR	TATA spare parts
269872306028	LINK RH (BELL CRANK TO CLU) FR DOOR	TATA spare parts
269872306303	STRAP (FRONT DOOR)	TATA spare parts
269872306319	GROMMET(POP UP KNOB)	TATA spare parts
269872500101	WEATHER STRIP LH NLS 0136	TATA spare parts
269872500102	WEATHER STRIP RH	TATA spare parts
269872500106	ASSY WINDING REGULATOR RH	TATA spare parts
269872500110	WINDOW REGULATOR FRT RH	TATA spare parts
269872500126	ASSY.DOOR GLASS HOLDER FRONT LH	TATA spare parts
269872500127	DOOR GLASS HOLDER RH	TATA spare parts
269872500136	WEATHER STRIP OUTER LH	TATA spare parts
269872500137	WEATHER STRIP OUTER RH	TATA spare parts
269872500138	WEATHER STRIP INNER LH	TATA spare parts
269872500139	WEATHER STRIP INNER RH	TATA spare parts
269872500140	ASSY.POWER WINDOW REGULATOR LH	TATA spare parts
269872500141	ASSY WINDOW REGU. RH	TATA spare parts
269872502301	DOOR GLASS FR LH	TATA spare parts
269872502302	DOOR GLASS FR RH	TATA spare parts
269872502303	DOOR GLASS FR LH SUMO DX	TATA spare parts
269872502304	DOOR GLASS FR RH SUMO DX	TATA spare parts
269872502501	VELVET CHANNEL	TATA spare parts
269872502504	VELVET CHANNEL FRONT	TATA spare parts
269872506307	GRAB HANDLE (DOOR) [GREY COLOUR]	TATA spare parts
269872700101	PADDING FR DOOR LH BLK	TATA spare parts

269872700102	PADDING FR DOOR RH BLK	TATA spare parts
269872706301	PLASTIC COVER [FRONT DOOR]	TATA spare parts
269873200111	ASSY GUIDE CHANNEL LH	TATA spare parts
269873200112	ASSY GUIDE CHANNEL RH	TATA spare parts
269873200154	DOOR SHELL REAR RH DX	TATA spare parts
269873300106	HINGE RR DOOR TOP RH	TATA spare parts
269873300140	DOOR HINGE TOP RH	TATA spare parts
269873300141	ASSLY DOOR HINGE BOT.LH	TATA spare parts
269873300145	ASSY.BRACKET LH (C.L.U.MTG.)	TATA spare parts
269873300146	ASSY.BRACKET RH (C.L.U.MTG.)	TATA spare parts
269873306001	PULL ROD LH INNER HANDLE	TATA spare parts
269873306003	LINK OUTER HANDLE	TATA spare parts
269873306004	LINK LH BELL CRANK-LATCH	TATA spare parts
269873306005	LINK RH BELL CRANK-LATCH	TATA spare parts
269873306006	PULL ROD POP UP KNOB	TATA spare parts
269873306007	LINK BELL CRANK LEVER	TATA spare parts
269873306017	LINK LH (BELL CRANK TO LATCH) RR DOOR	TATA spare parts
269873306018	LINK RH (BELL CRANK TO LATCH) RR DOOR	TATA spare parts
269873500105	WEATHER STRIP LH	TATA spare parts
269873500106	WEATHER STRIP RH NLS 0167	TATA spare parts
269873500114	WINDOW REGULATOR LH	TATA spare parts
269873500115	ASSY. WINDOW REG.RH	TATA spare parts
269873500156	ASSY.DOOR GLASS HOLDER REAR LH	TATA spare parts
269873500157	ASSY.DOOR GLASS HOLDER REAR RH	TATA spare parts
269873500166	WEATHER STRIP OUTER LH	TATA spare parts
269873500167	WEATHER STRIP OUTER RH	TATA spare parts
269873500168	WEATHER STRIP INNER LH	TATA spare parts
269873500169	WEATHER STRIP INNER RH	TATA spare parts
269873502301	REGULATING GLASS RR LH	TATA spare parts
269873502302	REGULATING GLASS RR RH	TATA spare parts
269873502303	GLASS QUARTER WINDOW LH	TATA spare parts
269873502304	GLASS QUARTER WINDOW RH	TATA spare parts
269873502305	GLASS QTR WIND LH SUMO DX	TATA spare parts
269873502306	GLASS QUARTER WINDOW RH	TATA spare parts
269873502307	REGULATING GLASS LH (REAR WINDOW)	TATA spare parts
269873502308	REGULATING GLASS RR RH DX	TATA spare parts
269873502501	VELVET CHANNEL	TATA spare parts
269873502503	VELVET CHANNEL REAR	TATA spare parts
269873506301	RUB MOULD LH QTR WINDOW	TATA spare parts
269873506302	RUB MOULD RH QTR WINDOW	TATA spare parts
269873506303	SEALING BOTTOM RR DOOR LH	TATA spare parts
269873506304	SEALING BOTTOM RR DOOR RH NLS ALT 0123	TATA spare parts
269873700101	PADDING BLK RR DR LH	TATA spare parts
269873700102	PADDING RR DR RH BLK	TATA spare parts
269873706301	PLASTIC COVER [REAR DOOR]	TATA spare parts
269874200101	TAIL GATE SHELL	TATA spare parts
269874208216	SUPPORT [TAILGATE STRAP]	TATA spare parts

269874300101	SPARE WHEEL CARRIER MTG	TATA spare parts
269874300109	ASSY. COVER LOCK	TATA spare parts
269874300115	DOOR STRAP ASSY	TATA spare parts
269874300125	A. DOVETAIL UPPER (TG SIDE) SUMO EX	TATA spare parts
269874300181	ASSY HINGE TAILGATE	TATA spare parts
269874306001	LINK OUTER HANDLE	TATA spare parts
269874306005	LINK [POP UP KNOB] TAILGATE	TATA spare parts
269874306013	LINK TAIL GATE ( BELL CRANK TO LATCH)	TATA spare parts
269874306304	RUBBER PACKING	TATA spare parts
269874306305	DOOR STRAP TAIL GATE	TATA spare parts
269874306308	COVER HINGE(PLASTIC TYPE)	TATA spare parts
269874306312	DOVETAIL SIDE UPPER (BODY SIDE) SUMO EX	TATA spare parts
269881100117	DOOR GRAB HANDLE	TATA spare parts
269881100121	SUNVISOR LH	TATA spare parts
269881100126	SEALING INN LH FRT DR STD	TATA spare parts
269881100127	SEALING INN RH FRT DR STD	TATA spare parts
269881100128	SEALING INN LH RR DR STD	TATA spare parts
269881100129	SEALING INN RH RR DR STD	TATA spare parts
269881100132	COVER FIRE WALL	TATA spare parts
269881100150	ASSY REAR VIEW MIRROR (INSIDE)	TATA spare parts
269881100199	ASSY.GRAB HANDLE	TATA spare parts
269881106313	COVER BOTTOM MIDDLE POST	TATA spare parts
269881106314	COVER BOTTOM RH FRT POST	TATA spare parts
269881106315	COVER REAR INNER	TATA spare parts
269881106317	SPACER INN RV MIRROR	TATA spare parts
269881106318	VENT GRILL OUTER LH	TATA spare parts
269881106319	VENT GRILL OUTER RH	TATA spare parts
269881106331	COVER BOTTOM LH FRT POST	TATA spare parts
269881106332	SEALING INN TAIL GATE	TATA spare parts
269881106333	COVER INNNER LH RVM OUTER	TATA spare parts
269881106334	COVER INNNER RH RVM OUTER	TATA spare parts
269881106335	COVER OUTER LH RVM OUTER	TATA spare parts
269881106340	COVER NLS OUTER RH	TATA spare parts
269881106350	COVER SILL FRONT	TATA spare parts
269881106351	COVER SILL REAR	TATA spare parts
269881106369	COVER (SUPPORT PANEL W/S) RHD	TATA spare parts
269881106397	MUD FLAP REAR RH	TATA spare parts
269881106398	COVER FRONT GRILL	TATA spare parts
269881106701	SQUARE NECK SCREW	TATA spare parts
269881108002	CR.PAN.HD.SCR. M6 X 30	TATA spare parts
269881109903	CLIP	TATA spare parts
269881110103	SEALING INNER FRONT LH	TATA spare parts
269881110104	SEALING INNER FRONT RH	TATA spare parts
269881110105	SEALING INNER REAR LH	TATA spare parts
269881110106	SEALING INNER REAR RH	TATA spare parts
269881110127	MUDGUARD LINER LH WITH INSULATION	TATA spare parts
269881110128	MUDGUARD LINER RH WITH INSULATION	TATA spare parts



269881110129	GRAB HANDLE (SUMO IMPROVED)	TATA spare parts
269881110130	ASSY.SEALING INNER FRT.LH-	TATA spare parts
269881110131	ASSY.SEALING INNER FRT.RH	TATA spare parts
269881110132	ASSY.SEALING INNER REAR LH	TATA spare parts
269881110133	ASSY.SEALING INNER REAR RH	TATA spare parts
269881110164	ASSY OUTER SEALING FRONT LH	TATA spare parts
269881110165	ASSY OUTER SEALING FRONT RH	TATA spare parts
269881110166	ASSY OUTER SEALING REAR LH	TATA spare parts
269881110167	ASSY OUTER SEALING REAR RH	TATA spare parts
269881110176	SIDE FOOT STEP COMPLETE	TATA spare parts
269881110185	ASSY GRAB HANDLE (GREY)	TATA spare parts
269881116305	SEALING INNER TAILGATE	TATA spare parts
269881116309	MUD FLAP FRT LH (SUMO IMPROVED)	TATA spare parts
269881116310	MUD FLAP FRT RH (SUMO IMPROVED)	TATA spare parts
269881116316	STOPPER	TATA spare parts
269881116326	STICKER BHARAT STG 2	TATA spare parts
269881116337	MUDGAURD LINER OUTER FRT LH	TATA spare parts
269881116338	MUDGAURD LINER OUTER FRT RH	TATA spare parts
269881116386	SELF ADHESIVE FOAM (IN FR POST LH)	TATA spare parts
269881116390	SELF ADHESIVE FOAM (FIRE WALL)SUMO EX	TATA spare parts
269881116391	HOLE PLUG ELLIPTICAL SUMO EX	TATA spare parts
269881116393	ASSY KIT AMBULANCE	TATA spare parts
269881116394	HOLE PLUG (30 DIA)	TATA spare parts
269881126322	SEALING SEAT BELT ANCHORAGE	TATA spare parts
269881126323	SEALING DASHBOARD	TATA spare parts
269881126325	SEALING FRONT DOOR RH	TATA spare parts
269881126326	SEALING SEAT BELT	TATA spare parts
269881126380	TAIL LAMP ACCESS COVER	TATA spare parts
269881126387	LIP BEADING	TATA spare parts
269881136314	PACKING	TATA spare parts
269881303801	STRIKER TAILGATE	TATA spare parts
269881306301	STRIKER PLATE - TAILGATE	TATA spare parts
269881308203	SHIM (T/G. STRIKER)	TATA spare parts
269881800110	MASCOT TATA	TATA spare parts
269881800111	MASCOT SUMO DX	TATA spare parts
269881800130	STICKER TURBO INTERCOOLER BLACK	TATA spare parts
269881806301	MASCOT TATA SUMO	TATA spare parts
269881900101	PLS CLIP LARGE	TATA spare parts
269881900102	DOOR CLIP	TATA spare parts
269881900103	ASSY.CLIP(HARYANA INDUSTRIE)BLACK 17DIA.	TATA spare parts
269881900105	ASSY.CLIP DARK GREY 17DIA	TATA spare parts
269881900106	ASSY.DOOR CLIP SUMO EX	TATA spare parts
269881900107	ASSY.CLIP DARK GREY 17DIA.	TATA spare parts
269881900111	ASSY.CLIP DARK GREY 17DIA	TATA spare parts
269881906308	BUTTON CROSS MEMBER	TATA spare parts
269881906309	PLUG BUTTON FOR 30 DIA	TATA spare parts
269881906311	PLUG BUTTON SUMO EX	TATA spare parts

269881906312	PLUG BUTTON	TATA spare parts
269881908001	CROSS RECESSED PAN HEAD SCREW [M8]	TATA spare parts
269882400102	WIPER MTR.W/RIS W/O THER.	TATA spare parts
269882400110	ASSY.WHEEL BOX I	TATA spare parts
269882400111	ASSY.WHEEL BOX II	TATA spare parts
269882400112	ASSY.LINK ROD I	TATA spare parts
269882400113	LINK ROD 2 SHORT	TATA spare parts
269882400114	ASSY.WIPER KIT RHD	TATA spare parts
269882400119	ASSY.WIPER KIT LHD	TATA spare parts
269882400129	KIT ELEC W/S WASHER	TATA spare parts
269882400143	ASSY.WIPER MOTOR-RHD	TATA spare parts
269882400164	ASSY.WIPER ARM & BLADE REAR REAR	TATA spare parts
269882400166	ASSY REAR W/SYS INRAD	TATA spare parts
269882400183	KIT FOR ELE.W/S WASHER UNIT	TATA spare parts
269882400186	KIT FOR ELEC.W/S WASHER UNIT	TATA spare parts
269882400192	KIT FOR WINDSHIELD WASHER UNIT	TATA spare parts
269882400193	ELEC.MOTOR WITH PUMP ASSY.	TATA spare parts
269882400199	REAR WIPER SYSTEM	TATA spare parts
269882406311	RESERVIOR(1.5LITS.) M/S.PRABHA. BS6	TATA spare parts
269882407502	RUBBER BOOT WHEEL BOX	TATA spare parts
269883100138	ASSY.SOLENOID VALVE W/BRACKET CPT	TATA spare parts
269883100162	ASSY.SOLENOID VALVE - SVL(WITHOUT BKT)	TATA spare parts
269883106301	ELBOW DUCT SIDE	TATA spare parts
269883106302	ELBOW DUCT CENTRE	TATA spare parts
269883106303	DUCT	TATA spare parts
269883106305	HOSE CENTRE VENTILATION	TATA spare parts
269883106338	O RING 15.54 MM SUCTION	TATA spare parts
269883400163	CONDE CORE PARALLEL WALL	TATA spare parts
269883400169	ASSY HOSE SUCT/DISCHARGE	TATA spare parts
269883400180	ASSY. AIR DISTRIBUTION BOX TOUNGE	TATA spare parts
269883400181	ASSY. BLOWER WITH RIS (MOTOR WITH WHEEL)	TATA spare parts
269883400182	ASSY.MOTOR RHD	TATA spare parts
269883400185	COIL ASSEMBLY EVAPORATOR LHD	TATA spare parts
269883400186	ASSY BLOCK VALUE CPT	TATA spare parts
269883406307	GROMMET FOR HEATER PIPES ON FIRE WALL	TATA spare parts
269883406308	GROMMET FOR THE DRAIN HOSE ON FIRE WALL	TATA spare parts
269883406312	DRAIN HOSE FOR H.V.A.C. UNIT	TATA spare parts
269883406313	HOUSING H.V.A.C.UNIT (RHD)	TATA spare parts
269883410115	ASSY VACUM HARNESS COMPLT	TATA spare parts
269883410118	ASSY.TANK RECEIVER DRIER	TATA spare parts
269883410187	ASSY.COIL HSG - PAD TYPE	TATA spare parts
269883410190	ASSY.EVAPORATOR COIL -RHD	TATA spare parts
269883500104	ASSY.HEATER DAMPERS (RHD)	TATA spare parts
269883500107	ASSY.HEATER COIL -RHD	TATA spare parts
269885100101	BKT RR LH LUGGAGE CARRIER	TATA spare parts
269885100102	BKT RR RH LUGGAGE CARRIER	TATA spare parts
269885100103	BKT FR LH LUGGAGE CARRIER	TATA spare parts

269885100104	BKT FR RH LUGGAGE CARRIER	TATA spare parts
269885100105	FRAME LUGGAGE CARRIER	TATA spare parts
269885100106	BKT RR LH LUGGAGE CARRIER	TATA spare parts
269885100107	BKT RR RH LUGGAGE CARRIER	TATA spare parts
269885100108	BKT FR LH LUGGAGE CARRIER	TATA spare parts
269885100109	BKT FR RH LUGGAGE CARRIER	TATA spare parts
269888100103	SIDE BONNET LH W/O SLOT SE-SA-SPACIO	TATA spare parts
269888100108	BONNET SIDE LH WITH IND. SLOT DX	TATA spare parts
269888500101	BUMPER FRONT COMPLETE	TATA spare parts
269888500110	BKT RH FRT BUMP MTG	TATA spare parts
269888500114	FRONT GUARD LH SIDE	TATA spare parts
269888500118	SUPPORT RH FRONT GUARD	TATA spare parts
269888500150	ASSY SUPPORT COMP.(FRONT BUMPER MTG) LH	TATA spare parts
269888506301	CORNER BUMPER FR LH	TATA spare parts
269888506302	CORNER BUMPER FRONT RH	TATA spare parts
269888506303	RUBBER PAD	TATA spare parts
269888506314	CAP FRONT BUMPER (FOR M8 SCR)	TATA spare parts
269888506315	CAP (FOR M8 BOLT)	TATA spare parts
269888508201	BUMPER FRONT CENTRE	TATA spare parts
269888606301	CORNER BUMPER REAR LH	TATA spare parts
269888606302	CORNER BUMPER REAR RH	TATA spare parts
269888606303	BUMPER CORNER REAR LH	TATA spare parts
269888606312	REAR BUMPER CENTRE (BLACK)	TATA spare parts
269888608202	CENTRE BUMPER REAR	TATA spare parts
269888700109	BONNET HINGE LH	TATA spare parts
269888700110	BONNET HINGE RH	TATA spare parts
269888700113	ASSY BONNET CENTRE	TATA spare parts
269888700117	ASSY SEALING BONNET-WITH END CAPS	TATA spare parts
269888706301	RUBBER BUFFER BONNET	TATA spare parts
269888706302	RUBBER BUFFER BONNET	TATA spare parts
269888706303	BONNET SEALING	TATA spare parts
269888706305	MLD. INSULATION (CEN. BON.) SUMO IMPR	TATA spare parts
269888706306	CLIP STAY ROD CLAMP	TATA spare parts
269888800107	T EMBLEM MODIFIED	TATA spare parts
269888806301	GRILL CENTRE	TATA spare parts
269888806302	BAZZEL LH	TATA spare parts
269888806303	BAZZEL RH	TATA spare parts
269888806310	GRILL CENTRE	TATA spare parts
269888806311	BAZEL RH	TATA spare parts
269888806312	BAZEL LH	TATA spare parts
269889100101	RUBBER MTG TOP	TATA spare parts
269889100102	KIT ASSY RUBBER MTG	TATA spare parts
269891000131	SEAT BUCKET RH DX	TATA spare parts
269891000142	SEAT BUCKET RH	TATA spare parts
269891500112	ASSY.BRACKET (SEAT BELT MTG.) FRONT LH	TATA spare parts
269891500114	ASSY BRACKET (SEAT BELT MTG) FRONT RH	TATA spare parts
269891506303	COVER	TATA spare parts

269891706301	CAP (M8 BOLT A/F 12)	TATA spare parts
269893000101	CO DRIVER BENCH SEAT SE/SA	TATA spare parts
269915100102	STOP RING-SPARE	TATA spare parts
269915100103	OVER RUNNING CLUTCH DRIVE	TATA spare parts
269915100104	FORK LEVER-SPARE	TATA spare parts
269915100105	BEARING PEDESTAL-SPARE	TATA spare parts
269915100106	SOLENOID SWITCH-SPARE	TATA spare parts
269915100107	EPICYCLOIDAL GEAR TRAIN	TATA spare parts
269915100108	ARMATURE	TATA spare parts
269915100109	STATOR FRAME	TATA spare parts
269915100110	BRUSH HOLDER-SPARE	TATA spare parts
269915100111	COMMUTATOR END SHIELD	TATA spare parts
269915100112	CLOSURE CAP-SPARE	TATA spare parts
269915100114	GROMMET-SPARE	TATA spare parts
269915100122	PLANETARY GEAR ASSY.-SPARE	TATA spare parts
269915103100	BUSH BEARING-SPARE	TATA spare parts
269915103101	C.E.BEARING-SPARE	TATA spare parts
269915103200	FIXING BOLT-SPARE	TATA spare parts
269915103700	DRIVE END SHIELD-SPARE	TATA spare parts
269915104400	RETAINER-SPARE	TATA spare parts
269915106700	THURST COLLAR-SPARE	TATA spare parts
269915107700	SEALING RING-SPARE	TATA spare parts
269915107800	SEAL-SPARE	TATA spare parts
269915108000	COUNTER SUNK SCREWS-SPARE	TATA spare parts
269915108001	SCREW-SPARE	TATA spare parts
269915108002	HEXAGON SCREW M5	TATA spare parts
269915108003	SOLENOID FIXING SCREW-SPARE	TATA spare parts
269915108004	B.G.FIXING SCREW-SPARE	TATA spare parts
269915108300	SHIM-SPARE	TATA spare parts
269915109200	RETAINER WASHER-SPARE	TATA spare parts
269915109202	BLADE TERMINAL	TATA spare parts
269915109907	NUT (26 13 0976)ST.MOTOR	TATA spare parts
269915109909	TERMINAL MAIN ST.MOTOR	TATA spare parts
269915109910	O RING ST.MOTOR	TATA spare parts
269915109917	BEARING BUSH (FIXING BKT)	TATA spare parts
269915109918	NUT PIVOT (26 13 1256)ST.MOTOR	TATA spare parts
269915109919	PIVOT PIN (26 25 2001)ST.MOTOR	TATA spare parts
269915109920	JUMP RING	TATA spare parts
269915109924	OIL SEAL	TATA spare parts
269915109926	SEALING RING DE	TATA spare parts
269915109927	FIELD COIL ASSY.	TATA spare parts
269915109932	SEALING BUSH (26 25 2000)ST.MOTOR	TATA spare parts
269915109934	INSUL WASHER ST.MOTOR	TATA spare parts
269915109937	NUT ST.MOTOR	TATA spare parts
269915109939	BRUSH CARRIER ASSY.	TATA spare parts
269915109941	BRG.BUSH CE	TATA spare parts
269915109942	THRUST WASHER ST.MOTOR	TATA spare parts

269915109947	EARTH STUD (26 25 3810)ST.MOTOR	TATA spare parts
269915109949	SPRING WASHER	TATA spare parts
269915200102	INTANK FUEL PUMP	TATA spare parts
269915400102	ALTERNATOR	TATA spare parts
269915400104	ALTERNATOR 12V/135A 3SA45	TATA spare parts
269915400113	ALTERNATOR 3SA45 VP 6GR.PULLEY	TATA spare parts
269915400116	ALTERNATOR INT.FAN-125A	TATA spare parts
269915400117	STARTER MOTOR	TATA spare parts
269915400118	STARTER MOTOR	TATA spare parts
269915400118AE	STARTER MOTOR -XENON DC/SC	TATA spare parts
269915400119	SELF STARTER BS3/4	TATA spare parts
269915400119AE	STARTER MOTOR MICO-XEN DC-XEN SC	TATA spare parts
269915400121	ALTERNATOR INT.FAN 120A-PULL-58	TATA spare parts
269915400122	ALTERNATOR INT.FAN-120A-PULL-64	TATA spare parts
269915400126	FITTING RING-SPARE [F 00M 146 900]	TATA spare parts
269915400128	WASHER & SCREW ASSY.	TATA spare parts
269915400129	WASHER & SCREW ASSY.	TATA spare parts
269915400130	FIXING BRACKET ASSY	TATA spare parts
269915400132	INT FAN 120A B3 ALTERNATOR M/S BOSCH	TATA spare parts
269915403100	DEEP GROOVE BALL BEARING [F 00M 990 410]	TATA spare parts
269915404700	COVER PLATE-SPARE	TATA spare parts
269915404901	RECTIFIER-SPARE [F 002 G10 829]	TATA spare parts
269915406500	HEXAGON NUT M16-SPARE	TATA spare parts
269915406501	FLANGE NUT M8-SPARE	TATA spare parts
269915406502	HEXAGON NUT M4-SPARE	TATA spare parts
269915406503	HEXAGON NUT M8-SPARE	TATA spare parts
269915408000	COUNTERSUNK HEAD SCREW-SPARE	TATA spare parts
269915408001	OVAL-HEAD SCREW-SPARE	TATA spare parts
269915408002	HEXAGON SCREW-SPARE	TATA spare parts
269915408600	SPACER RING-SPARE	TATA spare parts
269915409200	SPRING WASHER-SPARE	TATA spare parts
269915409913	ROTOR ASSY.ALTERNATOR	TATA spare parts
269915409914	SRE BALL BEARING-ALTERNATOR	TATA spare parts
269915409915	STATOR ASSY ALTERNATOR	TATA spare parts
269915409916	RECTIFIER ASSY	TATA spare parts
269915409943	KNOCK SENSOR	TATA spare parts
269915409944	CRANK POS SENS.(CPS)DRG-25375918	TATA spare parts
269915409945	CAM SENSOR 25372484	TATA spare parts
269915409946	EMS-ECU-UNLOADED DICOR	TATA spare parts
269915409948	T-MAP SEN( BOOST PR SEN)0261230133	TATA spare parts
269915409949	HOT FILM AIRMASS METER	TATA spare parts
269915409954	DE BRKT ASSY	TATA spare parts
269915409955	ROTOR FOR ALTERNATOR 125A-57D	TATA spare parts
269915409956	STATOR FOR ALTERNATOR 125A - 57D	TATA spare parts
269915409957	RECTIFIER ASSY	TATA spare parts
269915409958	SRE BRKT ASSY	TATA spare parts
269915409959	REGULATOR & BRUSH SET FOR ALTERNATOR	TATA spare parts

269915409960	PULLEY	TATA spare parts
269915409964	DRIVE	TATA spare parts
269915409967	BRUSH SET	TATA spare parts
269915409973	DE FAN	TATA spare parts
269915409974	REG AND CONNECTOR MOULDING ASSY	TATA spare parts
269915409975	BRUSH ASSY	TATA spare parts
269915409976	REAR COVER MOULDING	TATA spare parts
269915409977	BEARING KIT	TATA spare parts
269915409978	FASTENERS KIT	TATA spare parts
269915409980	PULLEY FOR ALTERNATOR 125A	TATA spare parts
269915409981	D.E BRACKET M/C FOR ALTERNATOR 125A	TATA spare parts
269915409982	ROTOR FOR ALTERNATOR 125A	TATA spare parts
269915409983	STATOR WINDING ASSY FINAL	TATA spare parts
269915409984	RECTIFIER ARRANGEMENT	TATA spare parts
269915409985	SRE BKT FOR ALTERNATOR-125A	TATA spare parts
269915409987	FASTENERS & SUNDRIES PARTS KIT	TATA spare parts
269925108201	BACK COVER CLUTCH HSG	TATA spare parts
269925200101	CLUTCH DISC 228 DIA	TATA spare parts
269925200102	ASSY.228 DIA.CLUTCH DISC	TATA spare parts
269925200103	ASSY.228 DIA.CLUTCH DISC	TATA spare parts
269925200104	ASSY.228 DIA.CLUTCH DISC	TATA spare parts
269925200105	ASSY.228 DIA.CLUTCH DISC	TATA spare parts
269925200106	ASSY.228 DIA.CLUTCH DISC	TATA spare parts
269925200111	ASSY.228 DIA.CLUTCH DISC	TATA spare parts
269925200114	ASSY.228 DIA.DRIVEN PLATE(WAD)Luk India	TATA spare parts
269925400101	CL PR PLATE 228 DIA TC	TATA spare parts
269925400103	ASSY. CLUTCH PRESSURE PLATE 228 DIA. BS1	TATA spare parts
269925400105	CL COVER ASY.228 DIA(LOW R/LOAD)	TATA spare parts
269925400106	CL.COVER ASY.228 DIA LOW REL.LOAD	TATA spare parts
269925400107	CL.COVER ASSY. 228 DIA.(LOW REL.LOAD)	TATA spare parts
269925400111	ASSY.228 DIA.CLUTCH COVER	TATA spare parts
269929100122	SUPPLY TANK CMC	TATA spare parts
269929100167	CL MASTER CYL	TATA spare parts
269929100169	ASSY. HOSE	TATA spare parts
269929100173	HOSE ASSY	TATA spare parts
269929100177	MAJOR REP KIT-CL. MASTER CYL. BS1/2/3/4	TATA spare parts
269929100177AE	REP KIT MJR MASTER CYL -715	TATA spare parts
269929100188	ASSY HOSE	TATA spare parts
269929100193	FLUID RESERVOIR ASSY.	TATA spare parts
269929100283	ASSY.HOSE (CLUTCH BLEEDING)	TATA spare parts
269929100293	MAJOR KIT FOR AL CMC	TATA spare parts
269929100294	MINOR KIT FOR AL CMC	TATA spare parts
269929100295	ASSY. SLAVE CYLINDER BS2/3/4	TATA spare parts
269929100296	SLAVE CYLINDER	TATA spare parts
269929100297	MAJOR KIT FOR CSC	TATA spare parts
269929100298	MINOR KIT FOR CSC	TATA spare parts
269929103402	PIVOT BUSH	TATA spare parts

269929106710	BRAKE PIN	TATA spare parts
269929107704	STAY ROD-FOR CLUTCH ASSISTANCE	TATA spare parts
269929108233	CLAMP (CLUTCH FLUID CONTAINER)	TATA spare parts
269929108278	BRACKET(CLUTCH BLEEDING HOSE SUPPORT)	TATA spare parts
269929108708	COMPRESSION SPRING(FOR CLUTCH ASSISTANCE)	TATA spare parts
269929109908	PIVOT PIN	TATA spare parts
269930100109	CABLE RHD IDLING ADJUST	TATA spare parts
269930100124	BRACKET (ACC CABLE MTG)	TATA spare parts
269930100138	ASSY. ACCELERATOR PEDAL COMP.	TATA spare parts
269930100142	ASSY.BRACKET(ACC.CABLE MTG.)	TATA spare parts
269930108701	SPRING-ACCLERATOR PEDAL RETURN	TATA spare parts
269931000101	FRAME ASSY SAFARI 2650	TATA spare parts
269931200108	BODY MOUNTING BRACKET	TATA spare parts
269931200117	FUEL FILTER MTG BKT	TATA spare parts
269931200134	ASSY CROSS MEMBER	TATA spare parts
269931200139	ASSY CROSS MEMBER FRT SUP	TATA spare parts
269931200146	BRACKET ENG MTG RR	TATA spare parts
269931208280	CROSS MEMBER ENG MTG RR	TATA spare parts
269931408201	SUPPORT ENG MTG FRONT	TATA spare parts
269931700108	ENGINE STONE GUARD ASSY	TATA spare parts
269931708601	SPACER (GEAR BOX GUARD MOUNTING)	TATA spare parts
269932100101	ASSY. LOWER BALL JOINT. UPPER WISHBONE	TATA spare parts
269932100116	LEVER ASSY RH	TATA spare parts
269932100128	LEVER ASSY LH	TATA spare parts
269932100142	WISHBONE UPPER COMPLT LH	TATA spare parts
269932100143	WISHBONE UPPER COMPLT RH	TATA spare parts
269932100146	PIVOT BUSH W/SLEEVE	TATA spare parts
269932100150	ASSY. LOWER BALL JOINT. UPPER WISHBONE	TATA spare parts
269932100151	ASSY.BRACKET REAR RH (LOWER W/BONE)	TATA spare parts
269932100152	ASSY.BRACKET REAR LH (LOWER W/B MTG.)	TATA spare parts
269932100153	BKT FRT LH LOW WISHBONE	TATA spare parts
269932100154	BKT FRT RH LOW WISHBONE	TATA spare parts
269932100155	WISHBONE LOWER RH---NLS	TATA spare parts
269932100156	WISHBONE LOWER LH---NLS	TATA spare parts
269932100157	WISHBONE W/O B/JOINT &BKT. RH	TATA spare parts
269932100158	WISHBONE W/O B/JOINT &BKT. LH	TATA spare parts
269932100159	BKT LH UPPER WISHBONE MTG	TATA spare parts
269932100160	BKT RH UPPER WISHBONE MTG	TATA spare parts
269932100178	LEVER TORSION BAR RH	TATA spare parts
269932100179	LEVER TORSION BAR LH	TATA spare parts
269932100184	PIVOT BUSH NEW BS2/3/4	TATA spare parts
269932100184AE	ASSY.PIVOT BSH(UPP WSHBNE-XENDC	TATA spare parts
269932100185	ASSY. LOWER BALL JOINT. UPPER WISHBONE	TATA spare parts
269932100188	LOWER WISHBONE-RH	TATA spare parts
269932100189	LOWER WISHBONE-LH	TATA spare parts
269932100190	ASSY. LOWER BALL JOINT. UPPER WISHBONE	TATA spare parts
269932100193	ASSY BALL JOINT(UPPER WISHBONE)	TATA spare parts

269932100194	ASSY BALL JOINT(UPPER WISHBONE)	TATA spare parts
269932103201	ANCHOR BOLT TORSION BAR	TATA spare parts
269932103202	PIN LOW/WISHBONE RR	TATA spare parts
269932103203	MOUNTING PIN (LOWER WISHBONE FRONT)	TATA spare parts
269932105102	BRACKET TORSION BAR	TATA spare parts
269932105104	TOP SPINDLE FRT SUSPN	TATA spare parts
269932107501	RUBBER CAP TORSION BAR	TATA spare parts
269932107701	REBOUND STOP	TATA spare parts
269932107902	TORSION BAR RH 26.30 DIA	TATA spare parts
269932107904	TORSION BAR LH 26.30 DIA	TATA spare parts
269932107907	TORSION BAR RH 28.00 DIA	TATA spare parts
269932107908	TORSION BAR LH 28.00 DIA	TATA spare parts
269932107909	TORSION BAR-RH (PMO)	TATA spare parts
269932107910	TORSION BAR-LH (PMO)	TATA spare parts
269932108234	COVER TORSION BAR	TATA spare parts
269932108239	BRACKET REBOUND STOP	TATA spare parts
269932108297	CLOSING PLATE RH	TATA spare parts
269932108298	CLOSING PLATE LH	TATA spare parts
269932108303	SHIM 1.6 THK.	TATA spare parts
269932108304	SHIM.2.0 THK.	TATA spare parts
269932108306	SHIM 2.00 MM THK	TATA spare parts
269932108307	SHIM 3.15 MM THK	TATA spare parts
269932108308	SHIM 4.00 MM THK	TATA spare parts
269932108309	SHIM (CASTOR ADJUSTMENT)	TATA spare parts
269932109201	SPACER TORSION BAR	TATA spare parts
269932109204	WASHER SPHERICAL	TATA spare parts
269932300101	ASSY. FRONT SHOCK ABSORBER BS2/3/4	TATA spare parts
269932300103	BRACKET LH	TATA spare parts
269932300104	BRACKET RH	TATA spare parts
269932300105	SHOCK ABSORBER FRONT	TATA spare parts
269932300111	FR SHOCK ABSORBER HYD SAFARI	TATA spare parts
269932400120	RUBBER BUSH TOP LINK	TATA spare parts
269932400122	LOWER LINK WITH BUSH	TATA spare parts
269932400124	UPPER LINK COMPLT	TATA spare parts
269932407710	SEAT REAR SPRING TOP 13MM	TATA spare parts
269932407711	SPRING SEAT TOP RR 16MM	TATA spare parts
269932407712	SPRING SEAT TOP RR 20MM	TATA spare parts
269932408714	SPRING REAR SUSPENSION	TATA spare parts
269932600108	ASSY.REAR SHOCK AB.W/RB STOP	TATA spare parts
269932800103	ASSY SLEEVE [FRONT ANTIROLL BAR]	TATA spare parts
269932800106	ASSY.FRONT ANTI-ROLL BAR COMPLETE	TATA spare parts
269932807701	BEARING BLOCK ARB	TATA spare parts
269932807904	ANTI ROLL BAR FRONT	TATA spare parts
269932808201	CLAMP ARB FRT	TATA spare parts
269933000101	ASSY.FR.AXLE RH SAFARI	TATA spare parts
269933000102	ASSY.FR.AXLE LH SAFARI	TATA spare parts
269933000115	AXLE ASSY FRT	TATA spare parts



269933100122	BKT LH FRONT AXLE MTG	TATA spare parts
269933100123	BRACKET RH	TATA spare parts
269933106901	SPACER SLEEVE	TATA spare parts
269933107701	RUBBER BUSH	TATA spare parts
269933108224	CUP	TATA spare parts
269933108230	BRACKET (REAR) (FRONT AXLE MOUNTING)	TATA spare parts
269933200101	ASSY.STUB AXLE WITH SEAL RACE - RH	TATA spare parts
269933200102	ASSY.STUB AXLE WITH SEAL RACE - LH	TATA spare parts
269933205101	STUB AXLE-RH	TATA spare parts
269933205102	STUB AXLE-LH	TATA spare parts
269933407801	SEALING CUP	TATA spare parts
269933408201	HUB COVER DANA ETR-36	TATA spare parts
269933805103	TIE ROD ARM RH	TATA spare parts
269933805103AE	TIE ROD ARM - RH XEN DC XEN SC	TATA spare parts
269933805104	TIE ROD ARM LH	TATA spare parts
269933805104AE	TIE ROD ARM - LH XEN DC XEN SC	TATA spare parts
269940100102	ASSY ALUMINIUM WHEEL RIM (6JX15)	TATA spare parts
269940100116	ASSY.WHEEL RIM 6Jx15 LP 1072 WIL	TATA spare parts
269940100137	COVER ALUMINIUM WHEEL	TATA spare parts
269940106501	DOMED WHEEL NUT	TATA spare parts
269940106502	WHEEL NUT	TATA spare parts
269940107719	WHL CVR (ALUMINIUM) MODIFIED	TATA spare parts
269940107721	COVER (ALLOY WHEEL RIM)	TATA spare parts
269940109994	VALVE	TATA spare parts
269941103201	CAP SCREW	TATA spare parts
269941103202	BOLT	TATA spare parts
269941109901	BEARING STRAP DANA	TATA spare parts
269941110109	PROP SHAFT FRONT DANA	TATA spare parts
269941110110	PROP SHAFT REAR	TATA spare parts
269941110139	ASSY PROPELLER SHAFT-4X4 - 28 WB	TATA spare parts
269941110145	ASSY.PROP SHAFT CREW CAB4X4.SPRINT	TATA spare parts
269941160101	PROPELLER SHAFT FRONT	TATA spare parts
269941170101	PROPELLER SHAFT REAR	TATA spare parts
269942103706	BRAKE DISC (VENTILATED) ETR-127-	TATA spare parts
269942300103	ASSY.REAR BRAKE LH	TATA spare parts
269942300104	ASSY.REAR BRAKE RH	TATA spare parts
269942300105	ASSY. REAR BRAKE LH	TATA spare parts
269942300106	ASSY. REAR BRAKE RH	TATA spare parts
269942300107	REAR BRAKE LH	TATA spare parts
269942300108	REAR BRAKE RH	TATA spare parts
269942303702	BRAKE DRUM REAR BS1/2/3/4	TATA spare parts
269942303702AE	BRAKE DRUM RR -SUMO-XENON DC/SC	TATA spare parts
269942303704	BRAKE DRUM	TATA spare parts
269942400101	L C R VALVE	TATA spare parts
269942400102	LCRV INDIGENOUS	TATA spare parts
269942700110	ASSY PARKING BRAKE LEVER COMPLETE	TATA spare parts
269942700124	ASSY PARKING BRAKE CABLE FRONT	TATA spare parts

269942700128	ASSY PARKING BRAKE CABLE REAR RH	TATA spare parts
269942700129	ASSY PARKING BRAKE CABLE REAR LH	TATA spare parts
269942700143	MICRO SWITCH W/BKT NLS	TATA spare parts
269942700144	ASSY HOOK-INNER (PARKING BRAKE CABLE)	TATA spare parts
269942700146	ASSY HOOK -OU1ER (PARKING BRAKE)	TATA spare parts
269942800101	TUBE ASSY	TATA spare parts
269942800104	TUBE ASSY	TATA spare parts
269942800114	TUBE ASSY	TATA spare parts
269942800117	TUBE ASSY	TATA spare parts
269942800126	TUBE ASSY	TATA spare parts
269942800142	ASSY.CLAMP	TATA spare parts
269942800173	ASSY. BRACKET (FOR BRAKE PIPE LINE)	TATA spare parts
269942804201	SPRING CLIP	TATA spare parts
269942804204	SPRING CLIP	TATA spare parts
269942807705	CLAMP	TATA spare parts
269942807706	CLAMP	TATA spare parts
269942807707	CLAMP (PIPE 4.75X4.75X4.75X4.75)	TATA spare parts
269942808206	BKT PIPE CLAMPING	TATA spare parts
269942808207	CLAMPING PLATE	TATA spare parts
269943100103	BRAKE FLUID RESERVOIR	TATA spare parts
269943100105	TANDEM MASTER CYLINDER 23.81DX33	TATA spare parts
269943100115	TANDEM MASTER CYL 23.81D NEW	TATA spare parts
269943100132	BRAKE FLUID RESERVOIR	TATA spare parts
269943100138	T M C KIT MINOR	TATA spare parts
269943100139	T M C KIT MAJOR	TATA spare parts
269943500101	VACCUM BOOSTER	TATA spare parts
269943500106	MAJOR KIT VACUUM BRAKE VALVE S/C	TATA spare parts
269943500107	MINOR KIT VACUUM BRAKE VALVE	TATA spare parts
269943505802	HOSE	TATA spare parts
269943505804	HOSE	TATA spare parts
269943507701	DIAPHRAGM S/C	TATA spare parts
269944800138	HOSE HIGH PRESSURE	TATA spare parts
269944800184	ASSY HIGH PRESSURE LINE-4DL-LHD	TATA spare parts
269944800192	ASSY RETURN LINE	TATA spare parts
269944800226	ASSY.HIGH PRESSURE HOSE(120 BAR)RHD	TATA spare parts
269944804202	PIPE CLAMP (POWER STG. LINE)	TATA spare parts
269944804203	HOSE CLAMP 21 (STAINLESS STEEL)	TATA spare parts
269944804205	HOSE CLAMP 30 (STAINLESS STEEL)	TATA spare parts
269944805802	HOSE SUCTION	TATA spare parts
269944805804	HOSE LOW PRESSURE	TATA spare parts
269944806806	PIPE UNION BOLT (HIGH PRESSURE LINE)	TATA spare parts
269944808201	BRACKET	TATA spare parts
269946000114	ASSY.POWER STG.GEAR BOX	TATA spare parts
269946000118	ASSY.STEERING GEAR BOX-RHD- TRW	TATA spare parts
269946000119	ASSY.POWER STG.GEAR BOX	TATA spare parts
269946000121	ASSY.STEERING GEAR BOX-LHD	TATA spare parts
269946000123	ASSY.POWER STG.GEAR BOX	TATA spare parts

269946208212	BRACKET	TATA spare parts
269946300102	IDLER ARM MTG BKT RH RHD	TATA spare parts
269946300103	IDLER ARM MTG BKT LH LHD	TATA spare parts
269946300116	IDLER ARM RHD	TATA spare parts
269946300117	IDLER ARM LHD	TATA spare parts
269946300119	ASSY IDLER ARM BRACKET-RH-RHD	TATA spare parts
269946300120	ASSY IDLER ARM BRACKET-LH-LHD	TATA spare parts
269946300123	ASSY IDLER ARM WITH BUSH-RHD	TATA spare parts
269946300124	ASSY IDLER ARM WITH BUSH-LHD	TATA spare parts
269946300126	ASSY.IDLER ARM WITH BRACKET-LHD	TATA spare parts
269946306001	PITMAN ARM RHD	TATA spare parts
269946306002	PITMAN ARM LHD	TATA spare parts
269946309210	THRUST WASHER (IDLER ARM)	TATA spare parts
269946407702	FLAP LH STRG	TATA spare parts
269946600110	ASSY.TIE ROD LH	TATA spare parts
269946600111	ASSY.TIE ROD RH	TATA spare parts
269946600113	ASSY.TIE ROD RH	TATA spare parts
269946600114	ASSY.TIE ROD LH	TATA spare parts
269946600119	P/STRG RHD PARTS	TATA spare parts
269946600121	ASSY.TIE ROD LH	TATA spare parts
269946600122	ASSY.TIE ROD RH	TATA spare parts
269946600126	RESERVOIR P/STRG	TATA spare parts
269946600131	TANK BODY & BRACKET ASSY	TATA spare parts
269946600132	FILTER & END COVER ASSY	TATA spare parts
269946600133	COVER ASSY	TATA spare parts
269946600134	DIPSTICK	TATA spare parts
269946600135	SERVICE KIT	TATA spare parts
269946600140	ROLLER SHAFT SEAL KIT	TATA spare parts
269946600141	SEAL KIT (MAJOR SEAL) BS2/3/4	TATA spare parts
269946600156	UNIVERSAL JOINT NLS 0268	TATA spare parts
269946600158	UNIVERSAL JOINT	TATA spare parts
269946600178	POWER STG PUMP 80BAR PT No.30220034	TATA spare parts
269946600179	DIPSTICK ASSY	TATA spare parts
269946600181	OIL TANK SAFARI ZF	TATA spare parts
269946600189	ROLLER SHFT ASSY 80BARRHD	TATA spare parts
269946600190	PISTON RACK KIT	TATA spare parts
269946600196	STEEL & RUBBER WASHER	TATA spare parts
269946600197	SPECIAL SCREW ASSY	TATA spare parts
269946600201	FSSY.POWER STG.RESERVOIR COMP.	TATA spare parts
269946600207	POWER STG. PUMP 90 BAR	TATA spare parts
269946600209	ASSY.POWER STG.RESERVOIR WITH BKT.	TATA spare parts
269946600215	ASSY.POWER STG.RESERVOIR	TATA spare parts
269946600216	ASSY. STG. RESERVOIR BKT	TATA spare parts
269946600228	SHAFT STG COLUMN NLS269946000117	TATA spare parts
269946600242	VANE PUMP ASSY	TATA spare parts
269946600243	ASSY. P/STG PUMP (85+15 BAR)	TATA spare parts
269946600244	WORM & VALVE ASSY	TATA spare parts

269946600245	WORM AND VALVE ASSY RHD 6 SLOTS	TATA spare parts
269946600247	PISTON RACK ASSY.	TATA spare parts
269946600248	ROLLER SHAFT ASSY.	TATA spare parts
269946600251	HOUSING	TATA spare parts
269946600253	SEAL PROTECTOR	TATA spare parts
269946600254	WORM & VALVE KIT RHD SAFARI	TATA spare parts
269946600255	WORM & VALVE KIT	TATA spare parts
269946600256	PISTON RACK KIT LHD	TATA spare parts
269946600266	SLEEVE & SPINDLE ASSEMBLY	TATA spare parts
269946600268	U. J. STEERING	TATA spare parts
269946600284	ASSY.P/STG.PUMP(113+5 BAR)-DICOR	TATA spare parts
269946600306	WORM & VALVE ASSY	TATA spare parts
269946600307	WARM & VALVE ASSY	TATA spare parts
269946600308	ROLLER SHAFT ASSY	TATA spare parts
269946600309	ROLLER SHAFT ASSY	TATA spare parts
269946600310	HOUSING SUB ASSY	TATA spare parts
269946600311	HOUSING SUB ASSY	TATA spare parts
269946600312	WORM & VALVE KIT	TATA spare parts
269946600313	WORM & VALVE KIT	TATA spare parts
269946600315	BOWL ASSY	TATA spare parts
269946600316	COVER ASSY	TATA spare parts
269946603202	HEX BOLT	TATA spare parts
269946606301	STRAINER	TATA spare parts
269946606501	HEX NUT	TATA spare parts
269946607501	RUBBER BUSH	TATA spare parts
269946607701	VALVE SEAT	TATA spare parts
269946607702	SEAL-BOTTOM	TATA spare parts
269946607703	COVER SEAL	TATA spare parts
269946607707	SEALING RING	TATA spare parts
269946608002	SLOTTED CHEESE HEAD SCREW	TATA spare parts
269946608701	SPRING	TATA spare parts
269946608708	COMP. SPRING	TATA spare parts
269946609201	PLAIN WASHER	TATA spare parts
269946609202	SPRING WASHER	TATA spare parts
269946609203	WASHER	TATA spare parts
269946609907	FILTER ELEMENT	TATA spare parts
269946609907AE	STEERING CARTRIDGE-XEN DC-XEN SC	TATA spare parts
269947100117	SCREW CAP FUEL TANK	TATA spare parts
269947100128	ASSY BKT(FUEL FILTER MTG)	TATA spare parts
269947100132	HOSE	TATA spare parts
269947100150	FULE TANK SAFARI	TATA spare parts
269947508206	BRACKET	TATA spare parts
269947508207	BRACKET	TATA spare parts
269947508208	BRACKET FUEL LINE CLAMP	TATA spare parts
269947600101	SUCTION LINE TANK TO HOSE	TATA spare parts
269947600106	ASSY.PRIMING PUMP	TATA spare parts
269947600106AE	PUMP FUEL TRANSFER-XEN DC-XEN SC	TATA spare parts

269947600157	ASSY. STRAP (SEDIMENTOR MOUNTING)	TATA spare parts
269947602707	QUICK CONNECTER (ELBOW 10X8)	TATA spare parts
269947602742	QUICK CONNECTOR (ELBOW 8X8) BS6	TATA spare parts
269947606902	TUBE SUCTION LINE 10 X0.7	TATA spare parts
269947606905	TUBE RETURN LINE 10 X 0.7	TATA spare parts
269947607703	CLAMP	TATA spare parts
269947607704	CLAMP (PRIMING PUMP)	TATA spare parts
269947607707	CLAMP-FUEL LINE (PIPE 12.5X10)	TATA spare parts
269947608234	BRACKET ( FOR FUEL LINE MTG.)	TATA spare parts
269949100144	CAT.CON	TATA spare parts
269949107702	RUBBER HANGER	TATA spare parts
269949200119	ASSY.GASKET (EXHAUST MANIFOLD PIPE)	TATA spare parts
269949200133	EXHAUST PIPE ASSY	TATA spare parts
269949200135	REAR PIPE REAR ASSY	TATA spare parts
269949200137	EXHAUST PIPE	TATA spare parts
269949200147	ASSY EXHANST PIPE W SILEO	TATA spare parts
269949200172	ASSY. GASKET (EXHAUST MANIFOLD PIPE) BS4	TATA spare parts
269949200177	ASSY.GASKET	TATA spare parts
269949200178	ASSY.GASKET	TATA spare parts
269949200179	ASSY.GASKET	TATA spare parts
269949200183	ASSY GASKET (EXHAUST PIPE)	TATA spare parts
269949200189	ASSY GASKET (EXHAUST PIPE)	TATA spare parts
269949200199	ASSY. GASKET	TATA spare parts
269949207701	RUBBER HANGER (FOR 8	TATA spare parts
269954108801	BATTERY STUD	TATA spare parts
269954109908	EARTH STRAP.	TATA spare parts
269954109910	BATTERY STUD 140 MM	TATA spare parts
269954200165	BORG WARNER ECU 4450000017	TATA spare parts
269954200185	KIT-HORN CLEARSTONE .	TATA spare parts
269954200194	ELECT.CONTROL UNIT (4PL)	TATA spare parts
269954200198	ASSY.MAGNETIC REED SWITCH (DIN)	TATA spare parts
269954200199	ASSY.MAGNETIC REED SWITCH (JIS)	TATA spare parts
269954209908	WIPER CONTROLLER	TATA spare parts
269954209928	WIPER CONTROLLER ED	TATA spare parts
269954209929	HEATED REAR WINDOW CONTROLLER	TATA spare parts
269954209939	BR FAIL LAMP CHEK TIMER	TATA spare parts
269954209940	SPEEDOCABLE (2050)	TATA spare parts
269954209944	INST CLST 1:1.00 4X4	TATA spare parts
269954209949	DIODE MODULE	TATA spare parts
269954209955	RPM METER	TATA spare parts
269954209957	TEMP GAUGE	TATA spare parts
269954209966	BULB TS 12V1.4W CLUSTER	TATA spare parts
269954209968	TEMPERATURE TRANSDUCER-	TATA spare parts
269954209969	CIGARATE LIGHTER	TATA spare parts
269954209972	SPEEDOCABLE (2900) LHD	TATA spare parts
269954209989	HORN HIGH TONE W/RIS CAPACITOR	TATA spare parts
269954209990	HORN LOW TONE W/RIS CAPACITOR	TATA spare parts

269954209997	CIGAR LIGHTER	TATA spare parts
269954210103	ASSY ECU HSG. AND CLIP	TATA spare parts
269954219905	REAR WIPER CONTROL	TATA spare parts
269954219911	CIGAR LIGHTER	TATA spare parts
269954219917	FOG LAMP UNIT	TATA spare parts
269954219982	POWER RELAY 12 V,70 A-WITH RESISTOR	TATA spare parts
269954219990	MINIATURE RELAY 1 NO/ 1NC M/S TYCO (AIR	TATA spare parts
269954400140	ENGINE LAMP	TATA spare parts
269954400169	KIT-REAR LAMP & REFLECTOR LHS(LHD)	TATA spare parts
269954400181	KIT REAR LAMP & REFLT.RHS	TATA spare parts
269954400182	KIT-REAR LAMP & REFLECTOR LHS	TATA spare parts
269954400183	ASSY FRONT FOG LAMP -LH	TATA spare parts
269954400184	ASSY FRONT FOG LAMP - RH	TATA spare parts
269954409914	HEAD LAMP RH (RHD) W/O LVL MOTOR-	TATA spare parts
269954409915	HEAD LAMP LH (RHD) W/O LVL MOTOR-	TATA spare parts
269954409916	REAR CLUSTER LAMP RHD RH	TATA spare parts
269954409917	REAR CLUSTER LAMP RHD LH	TATA spare parts
269954409918	REAR CLUSTER LAMP LHD RH	TATA spare parts
269954409920	FRONT DIR IND LH	TATA spare parts
269954409921	27ONT DIR IND RH	TATA spare parts
269954409923	REFLEX REFLECTOR-LH	TATA spare parts
269954409926	FOG LAMP RH FRONT 0184	TATA spare parts
269954409929	ROOF LAMP .	TATA spare parts
269954409930	ENGINE LAMP	TATA spare parts
269954409931	GLOVE BOX LAMP M/S LUMAX	TATA spare parts
269954409932	DOOR AJAR LAMP .	TATA spare parts
269954409933	STOP LAMP HIGH MOUNTED	TATA spare parts
269954409934	SIDE REPEATER LAMP-.	TATA spare parts
269954409935	REAR REGISTRATION PLATE LAMP	TATA spare parts
269954409939	HEAD LAMP LH (LHD) W/ LVL MOTOR	TATA spare parts
269954409967	HIGH MOUNTED STOP LAMP	TATA spare parts
269954409992	HIGH MOUNTED STOP LAMP	TATA spare parts
269954409993	DOOR AJAR LAMP (LED TYPE)	TATA spare parts
269954409994	DOOR AJAR LAMP (LED TYPE)	TATA spare parts
269954409995	DOOR AJAR LAMP (LED TYPE)	TATA spare parts
269954419907	PUDDLE LAMP -	TATA spare parts
269954419925	ENGINE LAMP	TATA spare parts
269954419927	HIGH MOUNTED STOP LAMP	TATA spare parts
269954419929	PUDDLE LAMP	TATA spare parts
269954419930	ENGINE LAMP	TATA spare parts
269954500172	KIT WIN WIND SWITCH RHD	TATA spare parts
269954500173	KIT WIN WIND SWITCH LHD	TATA spare parts
269954509901	OIL PRESSURE TRANSDUCER & SWITCH	TATA spare parts
269954509925	STEERING LOCK CUM IGN.SW.	TATA spare parts
269954509926	GLOVE BOX SWITCH	TATA spare parts
269954509930	WINDOW WINDING SW.PACK DRI-DOOR-RH	TATA spare parts
269954509931	WINDOW WINDING SW.PACK DRI.DOOR-LH	TATA spare parts

269954509932	SWITCH H/L LEVELLING	TATA spare parts
269954509936	SWITCH FRONT FOG LAMP-	TATA spare parts
269954509938	SWITCH FUEL FLAP SOLENOID	TATA spare parts
269954509941	SWITCH REAR WIPER-	TATA spare parts
269954509951	W/W SWITCH RH PASS DOOR LHD	TATA spare parts
269954509955	SWITCH TRANSFER CASE	TATA spare parts
269954509959	SQUARE FLASHER	TATA spare parts
269954509960	SQUARE FLASHER	TATA spare parts
269954509962	FUEL FLAP SOLENOID	TATA spare parts
269954509963	COMBI SW.(DOMESTIC)W/O CLK.SPR.	TATA spare parts
269954509967	TEMPERATURE SWITCH -90 DEG.	TATA spare parts
269954509971	MIRROR SWITCH 7 WIRE TYPE	TATA spare parts
269954509973	ADAPTER OIL PR TRANSDUCER	TATA spare parts
269954509977	CENTRAL HOUSING	TATA spare parts
269954509985	CAP(RED)-HAZARD WARNING SWITCH-	TATA spare parts
269954509993	TEMP.SW.82+/-3 DEG.	TATA spare parts
269954509996	SWITCH MODULE WITH MICRO-SW.	TATA spare parts
269954510141	KIT FOR LHD (W.W.SW.-PAINT)	TATA spare parts
269954510142	KIT WINDOW WINDING LTD EDN	TATA spare parts
269954519966	HAND BRAKE SWITCH	TATA spare parts
269954519973	HAZARD WARNING SWITCH	TATA spare parts
269954519985	ADAPTOR -OIL PRESSURE SWITCH	TATA spare parts
269954529921	FLASHER FOR SAFARI	TATA spare parts
269954529922	THERMOSTAT SWITCH (93 DEG. C)	TATA spare parts
269954529923	THERMOSTAT SWITCH(100 DEG. C)	TATA spare parts
269954529955	CLUTCH SWITCH-2NC	TATA spare parts
269954600117	RELAY BANK COVER 4DL TC	TATA spare parts
269954600185	HIT MATING CANNECTOR	TATA spare parts
269954604301	CABLE CLIP	TATA spare parts
269954604302	CABLE CLIP	TATA spare parts
269954606307	CABLE CLAMP 4PL	TATA spare parts
269954606308	FUSE BOX MAXI	TATA spare parts
269954608214	CLAMP -WSS CCONNECTOR MTG.	TATA spare parts
269954609937	FUSE 60 AMP MALE YELLOW	TATA spare parts
269954609938	FUSE 60 AMP FEMALE YELLOW	TATA spare parts
269954609939	FUSE 80 AMP MALE BLACK	TATA spare parts
269954619930	ADHESIVE FOAM TAPE	TATA spare parts
269954619964	W/H PIGTAIL FOR KNOCK SENSOR,M/s TYCO	TATA spare parts
269954619985	MOUNTING BRACKET EMS W/H-RAIL	TATA spare parts
269954619986	MOUNTING BRACKET EMS W/H-LIFTING HOOK	TATA spare parts
269954619987	MOUNTING BRACKET EMS W/H-LIFTING HOOK	TATA spare parts
269954629956	PIGTAIL FOR TRANSFER CASE ECU	TATA spare parts
269954629971	FERN TREE TYPE CABLE TIE-T1470059	TATA spare parts
269954639908	PIGTAIL FOR FUEL TEMP.SENSOR (FTS & IMV)	TATA spare parts
269954800118	KIT INTERNAL ANTENNA	TATA spare parts
269954807502	GROMMET ANTENNA CABLE	TATA spare parts
269954807503	GROMMET ANTENNA LH	TATA spare parts

269954808202	BRACKET SPAEKER 4 MTG.	TATA spare parts
269954809915	MUSIC SYSTEM ALPINE	TATA spare parts
269954900122	KIT CENTRAL LOCKING SYSTEM	TATA spare parts
269954909909	MASTER CUM FOLLOWER-	TATA spare parts
269954909909AE	MASTER CUM FOLLOWER -XENON DC/SC	TATA spare parts
269954909910	FOLLOWER UNIT	TATA spare parts
269954909911	CONTROL UNIT	TATA spare parts
269954909912	MASTER C FOLL. INDICA	TATA spare parts
269954909915	C/LOCK CONTROL IND MOD N	TATA spare parts
269958900601	CAMSHAFT ALIGN & TIMING SET TOOL/4PL XE	TATA spare parts
269958900602	CAMSHAFT COMPRESSOR L / 4PL	TATA spare parts
269958900603	VALVE SPRING COMPRSSOR / 4PL	TATA spare parts
269958900604	DRIFT / VALVE STEM O-SEAL / 483 PL	TATA spare parts
269958900605	PULLER / SPARK PLUG CABLE / HT CABLE / 4	TATA spare parts
269958900606	DRIFT / VALUE GUIDE / 4PL	TATA spare parts
269958900607	SPACER / VALVE GUIDE / 4PL	TATA spare parts
269958900608	SUPPORT/VALVE GUIDE/4PL+483PL XENON CNG	TATA spare parts
269958900609	16BI-1/2SQ-80L SOC / SPARK PLUG / 4PL	TATA spare parts
269958900610	VALVE RESTING PLATE / 4PL	TATA spare parts
269958901801	19A/F-196L BEND TYPE SPNR/OIL P-SWICH/4D	TATA spare parts
269958901803	SPANNER FOR OIL FILTER	TATA spare parts
269958901804	TRAY / OIL FILTER / DICOR 4X4	TATA spare parts
269958902501	MANDREL-CLUTCH DISC ALIGNMENT(DIA 228)	TATA spare parts
269958904003	WHEEL SPANNER 19A/F	TATA spare parts
269958904101	ADAPTOR FOR LOWER WISHBONE MTG.	TATA spare parts
269958904102	ADAPTOR FOR UPPER WISHBONE MTG.	TATA spare parts
269961100143	ASSY.FRONT SEAT FIXING PLATE. BS6	TATA spare parts
269962200106	RADIATOR SUPPORT COMPLT	TATA spare parts
269962700103	WHEEL HOUSE ASSY INNER RH	TATA spare parts
269962700114	SHOT GUN RH	TATA spare parts
269963200127	REINF STRIKER TAILGATE	TATA spare parts
269963608222	C PILLAR CORN.INN.TOP RH	TATA spare parts
269963708231	GLASS SURROUND EXT LH	TATA spare parts
269963708232	GLASS SURROUND EXT RH	TATA spare parts
269967100101	W/S GLASS	TATA spare parts
269967102301	W/S GLASS	TATA spare parts
269967102302	GLASS TAILGATE W/HEATER	TATA spare parts
269967102303	SIDE WINDOW GLASS L.H.	TATA spare parts
269967102304	SIDE WINDOW GLASS R.H.	TATA spare parts
269967106301	RUBBER MOULD W/S	TATA spare parts
269967106304	TAILGATE FIXED WIND MOULD	TATA spare parts
269967106306	SUPPORT BOT WINDSHIELD	TATA spare parts
269967106307	RUBBER MOULD W/S	TATA spare parts
269968804302	INSULATION CLIP	TATA spare parts
269968900101	D/BOARD RHD W/O AIR BAG	TATA spare parts
269968900105	AIR VENT CENTRE CLUSTER	TATA spare parts
269968900159	ASH TRAY W/HOUSING	TATA spare parts



269968900194	CONSOLE NLS HOUSING REAR	TATA spare parts
269968900199	CAP SCREW M6 X 16	TATA spare parts
269968906301	DUCT DEMIST DASH BOARD	TATA spare parts
269968906306	BUSH-DASH TOP LOCATION	TATA spare parts
269968906323	NACELLE STRG COLUMN UPPER	TATA spare parts
269968906331	CENTER CLUSTER FRAME	TATA spare parts
269968906345	BEZEL INSTRUMENT CLUSTER	TATA spare parts
269968906348	FINISHER GLOVE BOX	TATA spare parts
269968906361	BELLOW DOOR VENTILATION	TATA spare parts
269968906362	BELLOW DOOR DEMIST	TATA spare parts
269968906364	HINGE GLOVE BOX	TATA spare parts
269968906369	DUCT CONSOLE REAR VENT	TATA spare parts
269968906386	COVER FOR SWITCH	TATA spare parts
269968906389	SUPPORT COLAR GR SH LEVER	TATA spare parts
269968906390	GAITOR GEAR SHIFT LEVER	TATA spare parts
269968910101	CAP SCREW M6 X 30	TATA spare parts
269968910109	SUPPORT COLLAR W/BEADING	TATA spare parts
269968910189	CONSOLE MOUNTING BRACKET	TATA spare parts
269969100101	A. CAP (ROOF AC SIDE TRIM MTG)SUMO EX	TATA spare parts
269969100102	ASSY CABIN AIR EXTRACTOR VALVE	TATA spare parts
269969104301	PLASTIC CLIP TRIM FIXING	TATA spare parts
269969106301	A PILLAR TRIM UPPER LH	TATA spare parts
269969106302	A PILLAR TRIM UPPER RH	TATA spare parts
269969106307	B PILLAR TRIM LOWER LH	TATA spare parts
269969106310	B PILLAR TRIM UPPER RH	TATA spare parts
269969106311	C PILLAR TRIM LH	TATA spare parts
269969106312	C PILLAR TRIM RH	TATA spare parts
269969106313	D PILLAR TRIM LH	TATA spare parts
269969106314	D PILLAR TRIM RH	TATA spare parts
269969106316	FRT HALF RR QUART TRIM RH	TATA spare parts
269969106323	SCUFF PLATE LH FRT DOOR	TATA spare parts
269969106325	TREAD PLATE FRONT DOOR	TATA spare parts
269969106327	ACCESS COVER TAIL LAMP	TATA spare parts
269969106330	RR HALF RR QTR TRIM RH	TATA spare parts
269969106331	RR WINDOW CENT TRIM LH	TATA spare parts
269969106332	RR WINDOW CENT TRIM RH	TATA spare parts
269969106333	REAR HEADER TRIM	TATA spare parts
269969106335	SCUFF PLATE LH REAR DOOR	TATA spare parts
269969106338	NUT PLAST SCUFF/TREAD FIX	TATA spare parts
269969106339	NUT PLASTIC	TATA spare parts
269969106340	SCUFF PLATE RH FRT DOOR	TATA spare parts
269969106371	HOUSING FOR AIR EXTRACTOR VALVE	TATA spare parts
269969106372	SEAL FOR AIR EXTRACTOR VALVE	TATA spare parts
269969500101	HEAD LINING ASSY RHD	TATA spare parts
269969500102	ASSEMBLY GRAB HANDLE	TATA spare parts
269969500108	HEADLINING ASSY LHD	TATA spare parts
269969504302	PRESSURE SENSITIVE DUAL LOCK FASTENER	TATA spare parts

269969504303	SUPER DUAL LOCK FASTENER	TATA spare parts
269969506303	TRIM CLIP FOR HEADLINING	TATA spare parts
269969506304	HOUSING FOR CLIP	TATA spare parts
269969506308	SUNVISOR MOULDING FRONT	TATA spare parts
269972200149	SAFARI FR DOOR NEW RH	TATA spare parts
269972208230	SUPPORT PLATE GLASS FRT D	TATA spare parts
269972300111	HINGE LOWER FR DOOR RH	TATA spare parts
269972300116	ASSY FRONT DOOR HANDLE OUTER LH	TATA spare parts
269972300117	Y FRONT DOOR HANDLE OUTER RH	TATA spare parts
269972300118	DOOR HANDLE INNER LH	TATA spare parts
269972300119	DOOR HANDLE INNER RH	TATA spare parts
269972300120	HINGE UPPER ASSY	TATA spare parts
269972300129	ASSY.CHECK STRAP DOORS LH	TATA spare parts
269972300130	ASSY.CHECK STRAP DOORS RH	TATA spare parts
269972300137	LATCH FRONT DOOR LH	TATA spare parts
269972300138	LATCH FRONT DOOR RH	TATA spare parts
269972300139	CHECK STRAP DOOR LH	TATA spare parts
269972300140	CHECK STRAP DOOR RH	TATA spare parts
269972300141	ASSY.BLANK KEY	TATA spare parts
269972300156	ASSY BLANK KEY W TRANSPON	TATA spare parts
269972303401	METLOPLAST BUSH UPPER HIN	TATA spare parts
269972306301	OFFER DRG.ESCUTCHEON INNER HANDLE L.H.	TATA spare parts
269972306302	OFFER DRG.ESCUTCHEON INNER HANDLE R.H.	TATA spare parts
269972306311	GROMMET (GLASS PANE).	TATA spare parts
269972306321	RUBBER BUFFER (WINDOW WINDER)	TATA spare parts
269972306325	ESCUTCHEON INNER HANDLE LH	TATA spare parts
269972306326	ESCUTCHEON INNER HANDLE RH	TATA spare parts
269972500111	PIN GLASS PANE	TATA spare parts
269972500166	ASSY.WINDOW REGULATOR FRONT LH - IFB	TATA spare parts
269972500167	ASSY.WINDOW REGULATOR FRONT RH - IFB	TATA spare parts
269972502301	GLASS FR DOOR WINDING LH	TATA spare parts
269972502302	GLASS FR DOOR WINDING RH	TATA spare parts
269972506301	PRIMARY MOULD FRONT DOOR	TATA spare parts
269972506304	OUTER BELT FR MOULD LH	TATA spare parts
269972506305	OUTER BELT FR MOULD RH	TATA spare parts
269972506309	GLASS RUN FRONT MOULD RH	TATA spare parts
269972506310	UPPER AUXILIARY MOULD LH	TATA spare parts
269972506317	PRIMARY MOULD FRONT DOOR	TATA spare parts
269972506319	INNER BELT FRONT MOULD LH	TATA spare parts
269972506322	OUTER BELT FR MOULD RH	TATA spare parts
269972506323	UPPER AUXILIARY MOULD LH	TATA spare parts
269972506324	UPPER AUXILIARY MOULD RH	TATA spare parts
269972506325	GLASS RUN FRONT MOULD LH	TATA spare parts
269972506326	GLASS RUN FRONT MOULD RH	TATA spare parts
269972700106	DOOR VENT RH RHD	TATA spare parts
269972700112	TRIM FRONT RH W/PADDING	TATA spare parts
269972700113	TRIM FRONT LH W/PADDING	TATA spare parts

269972700114	DOOR PULL LH	TATA spare parts
269972700115	DOOR PULL RH	TATA spare parts
269972700124	DR VENT LH RHD	TATA spare parts
269972706301	MAGAZINE POCKET FR DR LH	TATA spare parts
269972706304	GRILLE SPEAKER FRONT DOOR R.H.	TATA spare parts
269972706305	DUCT DOOR VENT LH	TATA spare parts
269972706306	DUCT DOOR VENT RH	TATA spare parts
269972706307	VENT DOOR DEMIST RH	TATA spare parts
269972706308	DUCT DOOR DEMIST LH	TATA spare parts
269972706309	DUCT DOOR DEMIST RH	TATA spare parts
269972706311	PLAST MEMBRANE FR DR LH	TATA spare parts
269972706312	VENT DOOR DEMIST LH	TATA spare parts
269972706335	PLS MEMBRENE FRT RH NEW	TATA spare parts
269972706336	PLS MEMBRENE FRT LH NEW	TATA spare parts
269973200102	SHELL COMP RR DOOR RH	TATA spare parts
269973300115	HINGE LOWER ASSY	TATA spare parts
269973300119	ASSY REAR DOOR OUTER HANDLE RH	TATA spare parts
269973300122	ASSY LATCH RR DR LH	TATA spare parts
269973300123	ASSY LATCH RR DR RH (MICRO)	TATA spare parts
269973306004	LINK LOCK KNOB RR DR RH	TATA spare parts
269973306014	LINK ACTUATOR-LATCH LH RR	TATA spare parts
269973306301	CAP CHILD SAFETY LEVER	TATA spare parts
269973500103	ASSY CHANNEL GLASS DIVISION LH RR DR	TATA spare parts
269973500104	CHANNEL GLASS DIVISION RH	TATA spare parts
269973500143	ASSY.WINDOW REGULATOR REAR LH	TATA spare parts
269973500144	ASSY.WINDOW REGULATOR REAR RH	TATA spare parts
269973502301	GLASS REAR DOOR FIXED L.H.	TATA spare parts
269973502302	GLASS RR DOOR FIXED RH	TATA spare parts
269973502303	GLASS RR DOOR WINDING LH	TATA spare parts
269973502304	GLASS REAR DOOR WINDING R.H.	TATA spare parts
269973506305	MOULD LH RR OUTER BELT	TATA spare parts
269973506311	MOULD REAR DOOR PRIMARY	TATA spare parts
269973506319	MOULD GLASS RUN RR LH	TATA spare parts
269973506320	MOULD GLASS RUN RR RH	TATA spare parts
269973700109	TRIM REAR LH W/PADDING	TATA spare parts
269973700110	TRIM REAR RH W/PADDING	TATA spare parts
269973700112	ASSY.TRIM REAR WITH PADDING RH	TATA spare parts
269973706303	MAGAZINE POCKET LH	TATA spare parts
269973706305	GRILLE SPEAKER	TATA spare parts
269974200102	SHELL TAIL GATE WELDED	TATA spare parts
269974208225	SPACER PLATE LOWER T/GATE	TATA spare parts
269974208252	SHIM DOVETAIL BOTTOM DOOR SIDE-TAILGATE	TATA spare parts
269974300108	ASSY TAILGATE HANDLE OUTER	TATA spare parts
269974300109	ASSY. LATCH T/G WITH LINK	TATA spare parts
269974300111	CHECK STRAP T/GATE	TATA spare parts
269974300112	HINGE TAILGATE UPPER	TATA spare parts
269974300113	HINGE TAILGATE LOWER	TATA spare parts

269974300114	LINK ADJ.LOCK BARREL	TATA spare parts
269974300118	CHECK STRAP TAILGATE	TATA spare parts
269974300124	ASSY.HINGE TAILGATE LOWER	TATA spare parts
269974306001	LINK INN HANDLE TAILGATE	TATA spare parts
269974306003	LINK LOCK KNOB TAILGATE	TATA spare parts
269974306012	LINK ACTUAT- LATCH T/GATE	TATA spare parts
269974306302	DOVETAIL BODY SIDE	TATA spare parts
269974306306	DOVETAIL BODY SIDE	TATA spare parts
269974306315	STICKER CHILD LOCK-LH	TATA spare parts
269974506302	MOULD TAILGATE PRIMARY	TATA spare parts
269974700101	TAILGATE TRIM PRIMER	TATA spare parts
269974700104	DOOR PULL TAILGATE	TATA spare parts
269974706301	TRIM TAILGATE TOP	TATA spare parts
269981100121	ASSY.RVM INTERNAL W/O BASE	TATA spare parts
269981100124	ASSY.RVM INTERNAL W/O BASE	TATA spare parts
269981100133	RV MIRROR OUTER RH RHD	TATA spare parts
269981100148	RV MIRROR OUTER RH RHD	TATA spare parts
269981100149	RV MIRROR OUTER LH RHD	TATA spare parts
269981100156	TATA BADGE ON BONNET	TATA spare parts
269981100158	SPARE WHEEL COVER	TATA spare parts
269981100160	TATA BADGE NLS	TATA spare parts
269981100171	ORVM RHD RH W/TH HEATER LTD & EX	TATA spare parts
269981100173	RV MIRROR OUTER LH RHD HEATER LTD & EX	TATA spare parts
269981100176	ASSY R.V.M.RH-LHD WITH HEATER	TATA spare parts
269981100177	ASSY R.V.M.LH-LHD WITH HEATER	TATA spare parts
269981100205	FOOT STEP - LH	TATA spare parts
269981100241	KIT DECALS(DARK COLOUR-(LIM .EDN.)	TATA spare parts
269981100242	KIT SIDE DECALS (LIGHT COLOUR - LIM EDN)	TATA spare parts
269981100288	ASSY.REAR VIEW MIRROR INR BLACK	TATA spare parts
269981106303	COVER INTERNAL LH RVM	TATA spare parts
269981106313	LEAF SCREEN LHD	TATA spare parts
269981106314	GASKET FUEL FILLER CAP	TATA spare parts
269981106315	SEAL NLS FUEL FILLER CUP	TATA spare parts
269981106316	STYLING STRIP LH FRT DOOR	TATA spare parts
269981106328	HSG.TRIM FIXING	TATA spare parts
269981106329	CLIP TRIM FIXING	TATA spare parts
269981106339	STICKER 4 X 4	TATA spare parts
269981106341	MASCOT SAFARI	TATA spare parts
269981106344	PLUG (FOR ELL HOLE ON `A' PILLER LOWER)	TATA spare parts
269981106350	MUD COVER RH FRT BUMPER	TATA spare parts
269981106354	PLUG H/L WASHER ON BUMPER	TATA spare parts
269981106355	TRIM SPARE WHEEL CORNER	TATA spare parts
269981106363	DRAIN TUBE MID PLENUM	TATA spare parts
269981106364	DRAIN TUBE SIDE PLEN PANL	TATA spare parts
269981106366	PLUG LEAF SCR MTG SIDE	TATA spare parts
269981106367	PLUG LEAF SCR MTG MIDDLE	TATA spare parts
269981106385	T EMBLEM BONNET	TATA spare parts

269981106907	END PIECE-FOOT STEP SUMO EX LH	TATA spare parts
269981106908	END PIECE FOOT STEP SUMO EX RH	TATA spare parts
269981116307	HOUSING TRIM FIXING-GREY COLOUR	TATA spare parts
269981116308	CLIP TRIM FIXING-GREY COLOUR	TATA spare parts
269981116327	MASCOT 2.1L	TATA spare parts
269981116332	STICKER 4X4 - 3M	TATA spare parts
269981116338	T EMBLEM TATA ACE	TATA spare parts
269981504301	PLASTIC CLIP	TATA spare parts
269981506304	SIDE MOULD RR DOOR RH	TATA spare parts
269981506310	SIDE MOULD RR W/ARCH RH	TATA spare parts
269981506313	TRIM SPARE WHEEL MIDDLE	TATA spare parts
269981506314	TRIM SPARE WHEEL CORNER	TATA spare parts
269981506336	BSM FRT DR LH W/O PAINT	TATA spare parts
269981506337	BSM FRT DR RH W/O PAINT	TATA spare parts
269981506338	BSM REAR DR LH W/O PAINT	TATA spare parts
269981506343	BSM REAR QTR RH W/O PAINT	TATA spare parts
269981506344	BSM REAR W/ARCH LH W/O PAINT	TATA spare parts
269981506347	BODY SIDE MOULD LH W/O PAINT	TATA spare parts
269981506348	BODY SIDE MOULDING RH W/O PAINT	TATA spare parts
269981906301	PLUG BUTTON 12 DIA	TATA spare parts
269981906302	PLUG BUTTON FOR 16DIA.	TATA spare parts
269981906305	PLUG BUTTON 12X16 SLOT	TATA spare parts
269981906308	PLUG BUTTON 10 DIA	TATA spare parts
269981906309	PLUG BUTTON FOR 10 DIA.HOLE	TATA spare parts
269981906310	PLUG BUTTON FOR 12 DIA.HOLE	TATA spare parts
269981906311	PLUG BUTTON FOR 16 DIA.HOLE	TATA spare parts
269981906312	PLUG BUTTON FOR 20 DIA.HOLE	TATA spare parts
269981906313	PLUG BUTTON 25/26 DIA	TATA spare parts
269981906315	PLUG BUTTON FOR 12X16 SLOT	TATA spare parts
269981906316	PLUG BUTTON FOR 16X20 SLOT	TATA spare parts
269981906318	PLUG BUTTON (30 DIA.HOLE)	TATA spare parts
269981906322	PLUG BUTTON FOR 27 DIA.HOLE	TATA spare parts
269981906324	PLUG BUTTON (DASH PANEL)	TATA spare parts
269981906325	RUBBER PLUG BUTTON (DASH PANEL) BS6-PH2	TATA spare parts
269982400161	ASSY.LINKROD [SMALL]	TATA spare parts
269982400163	ASSY.WIPER MOTOR [REAR] ..	TATA spare parts
269982400169	CENTRAL VALVE	TATA spare parts
269982400171	NOZZLE LH	TATA spare parts
269982400172	NOZZLE RH	TATA spare parts
269982400173	WASH PUMP CONTROLLER	TATA spare parts
269982400175	MOTOR H/L POWER WASH	TATA spare parts
269982406302	WASHER TANK	TATA spare parts
269982406310	WASHER PIPE-CLAMP.	TATA spare parts
269982409905	DRIVER WIPER ARM RHD -600 ( B.C.S.)	TATA spare parts
269982409906	CO-DRIVER WIPER ARM RHD	TATA spare parts
269982409907	WIPER BLADE FRONT-600 (DRIVER)	TATA spare parts
269982409908	WIPER BLADE FR CODR SIDE	TATA spare parts

269982409910	WIPER ARM REAR	TATA spare parts
269982409911	WIPER MOTOR	TATA spare parts
269982409914	DRIVER WIPER ARM-LHD	TATA spare parts
269982409916	NOZZLE UNIT	TATA spare parts
269982409922	PUMP	TATA spare parts
269982409923	FLUID LEVEL SENSOR ASSY	TATA spare parts
269982409932	WIPER ARM DRIVER -LHD	TATA spare parts
269982409959	MOUTH CAP	TATA spare parts
269982410104	KIT ELEC W/S WASHER	TATA spare parts
269982410105	KIT FRONT WIPER SYSTEM (LHD)	TATA spare parts
269982410108	FRONT WIPER SYSTEM-LHD	TATA spare parts
269983100125	HVAC UNIT COMPLETE	TATA spare parts
269983100128	TUBE LIQUID	TATA spare parts
269983100137	TUBE LIQUID 3	TATA spare parts
269983100144	HOSE SUCTION RR AC	TATA spare parts
269983100146	ASSY.CONTROLS (HVAC UNIT) -	TATA spare parts
269983100147	CONTROLS AUX AC	TATA spare parts
269983100153	BKT HVAC BOT MTG TUNNEL	TATA spare parts
269983100154	SUPPORT TUBE LIQUID	TATA spare parts
269983100155	CABLE A/M MODE	TATA spare parts
269983100157	TUBE LIQUID RR AC	TATA spare parts
269983100160	TUBE SUNCTION	TATA spare parts
269983100162	TUBE LIQUID W/ACC	TATA spare parts
269983100169	TUBE LIQUID 2	TATA spare parts
269983100176	CONDENSER FAN COMP	TATA spare parts
269983100179	ASSY.EXPANSION VALVE-(4475000370)-	TATA spare parts
269983100180	THERMOSTAT SAFARI/INDICA	TATA spare parts
269983100185	ASSY.SERVO MOTOR -	TATA spare parts
269983100186	ASSY.PRESSURE SWITCH	TATA spare parts
269983100187	Assy Blower Resistor	TATA spare parts
269983100189	EVAPORATOR ASSY	TATA spare parts
269983106301	DUCT REAR AC UNIT	TATA spare parts
269983106304	GROMMET HTR.PIPES F/WALL	TATA spare parts
269983106306	GROMMET TUBE LIQ.LAMP PAN	TATA spare parts
269983106307	HOSE HVAC - DUCT CONSOLE	TATA spare parts
269983106319	O RING	TATA spare parts
269983106348	KNOB SUBROS	TATA spare parts
269983106349	KNOB-FAN SWITCH-(D99850-00-12)-	TATA spare parts
269983108204	CLAMP TUBE LIQUID	TATA spare parts
269983108212	BRACKET SOLENOID VALVE	TATA spare parts
269983108213	CLAMP PIPE LINES AUX AC	TATA spare parts
269983110119	ASSY.SWITCH-RECIR.	TATA spare parts
269983110123	A/C SWITCH	TATA spare parts
269983110184	ASSY.EXPANSION VALVE-2TON	TATA spare parts
269983110189	EXPANSION VALVE ASSY	TATA spare parts
269983400109	COMPRESSOR ASSY W/CLUTCH	TATA spare parts
269983400112	ASSY.MAIN CONDENSER COMPLETE -	TATA spare parts

269983400113	ASSY.SUB CONDENSER COMPLETE -	TATA spare parts
269983400126	ASSY. RECEIVER/DRIER -	TATA spare parts
269983400190	ASSY MF CONDENSER CPT(SINGLE FAN)	TATA spare parts
269983505802	HOSE ENG TO HVAC UNIT	TATA spare parts
269983505804	HOSE WATER - 1	TATA spare parts
269983505805	HOSE WATER - 2	TATA spare parts
269985100104	MOUNTING ROOF RAIL RH.-nls	TATA spare parts
269985100105	REAR MTG END ROOF RAIL LH	TATA spare parts
269985100106	MOUNTING ROOF RAIL RH-nls	TATA spare parts
269985100107	ROOFHEADER MLD NEW W/PAINT PMG LH	TATA spare parts
269985106903	PIPE-ROOF RAIL-nls0167/8	TATA spare parts
269985107701	GASKET FR LH ROOF RAIL	TATA spare parts
269985107702	GASKET FR RH ROOF RAIL	TATA spare parts
269985107703	GASKET RR LH ROOF RAIL	TATA spare parts
269985107704	GASKET RR RH ROOF RAIL	TATA spare parts
269988108214	FENDER FRONT RH	TATA spare parts
269988400104	BKT EXTENSION LID FUEL FI	TATA spare parts
269988500106	BUMPER FRONT W\O PAINT	TATA spare parts
269988500121	BKT FRT BUMPER MTG LH	TATA spare parts
269988506305	COVER LH FRT BUMPER	TATA spare parts
269988506309	TAIL PIECE NLS LH GRILL	TATA spare parts
269988506309C4	TAIL PIECE LH W\O PAINT	TATA spare parts
269988506310	TAIL PIECE R.H (GRILL SURROUND)	TATA spare parts
269988506310C4	TAIL PIECE RH W\O PAINT	TATA spare parts
269988506317	SPACER FR BUMPER END FIX	TATA spare parts
269988506323C4	GRILL FRT WITH SURR. W\O PAINT	TATA spare parts
269988506701	ADJUSTING SCREW	TATA spare parts
269988506702	CR TAPPING SCREW ST4.2X16	TATA spare parts
269988506703	CR TAPPING SCREW ST4.8X16	TATA spare parts
269988506706	CR.TAPPING SCREW ST4.8X26	TATA spare parts
269988507501	BUSH GRILLE MTG.	TATA spare parts
269988508602	WASHER FRT BUMPER MTG	TATA spare parts
269988600108	RR BUMPER BEAM COMPLT	TATA spare parts
269988606310	TOW HOOK COVER	TATA spare parts
269988606701	ADJUSTING SCREW	TATA spare parts
269988608603	WASHER 6.8	TATA spare parts
269988608605	WASHER 10.5 BS6	TATA spare parts
269988700101	HOOD SHELL COMPLETE	TATA spare parts
269988700104	HINGE RH HOOD	TATA spare parts
269988700121	CABLE BONNET RELEASE RHD	TATA spare parts
269988700122	RELEASE CABLE COMPLT LHD	TATA spare parts
269988700128	ASSY.HOOD STRIKER-RHD	TATA spare parts
269988700130	HOOD STRIKER LHD	TATA spare parts
269988700131	ASSY.HOOD LATCH RHD	TATA spare parts
269988700133	ASSY.HOOD BALANCER	TATA spare parts
269988700135	ASSY.HOOD LATCH LHD EXPORT	TATA spare parts
269988700136	HOOD LATCH RHD	TATA spare parts

269988700140	ASSY HOOD INSULATION.	TATA spare parts
269988704301	BUTTON CLIP	TATA spare parts
269988706302	HOOD INSULATION	TATA spare parts
269988706304	CENTERING WEDGE HOOD	TATA spare parts
269988706311	T EMBLEM	TATA spare parts
269988706312	CLAMP HOOD RELEASE CABLE	TATA spare parts
269988706316	MOULD HOOD TO COWL FR	TATA spare parts
269988706317	MOULD HOOD TO COWL RR	TATA spare parts
269988706318	EDGE BEADING HOOD MOULD	TATA spare parts
269989100106	ASSY BODY MOUNT COMPL.(FIRST ROW)	TATA spare parts
269989100107	ASSY BODY MOUNT COMPL.(IInd TO 5th ROW)	TATA spare parts
269989100108	ASSY BODY MOUNT COMPL.(IInd & 4th ROW)	TATA spare parts
269991500105	SEAT BELT FRT LH	TATA spare parts
269991500106	SEAT BELT FRT RH	TATA spare parts
269991506316	HANDLE LUMBAR RH	TATA spare parts
269991506317	HANDLE LUMBAR LH	TATA spare parts
269991506329	RECLINER KNOB RH	TATA spare parts
269991909905	CAP RECLINER KNOB	TATA spare parts
269991909909	CLIP RECLINER COVER	TATA spare parts
269991909912	RECLINER COVER O/B LH	TATA spare parts
269991909913	RECLINER COVER O/B RH	TATA spare parts
269992500111	KIT RR SEAT BELT W/ELR LH	TATA spare parts
269992909907	KNOB DUMP RELEASE LH RR-SEAT SAFARI	TATA spare parts
269996000103	JUMP SEAT SINGLE 0118	TATA spare parts
269996409902	CLIP TRAY J/SET CUSHION	TATA spare parts
269999706302	ROOF HDR MOULD.WHYTE	TATA spare parts
269999706304	CORN RF MLD RH ARC WHITE	TATA spare parts
269999706332	RF SD MLD CAP LH PEA BLUE	TATA spare parts
269999706333	ROOF HDR MOULD PEARL BLUE	TATA spare parts
269999706363	RF SD MLD C PILL LH BLACK	TATA spare parts
269999706366	CORNER ROOF MLD RH BLACK	TATA spare parts
269999716379	ROOF HDR MOULD LH PMG	TATA spare parts
269999716382	COVER FRT.BUMPER LH PMG	TATA spare parts
269999716383	COVER FRT.BUMPER RH PMG	TATA spare parts
269999716384	TOW HOOK CVR RR BUMP	TATA spare parts
269999716387	TAIL PIECE LH AR.SILVER	TATA spare parts
269999716390	SPARE WHEEL NLS TRIM MID PMG	TATA spare parts
269999716392	SPARE WH.TRIM LOWER PMG	TATA spare parts
269999716394	SIDE MLD FRT DOOR LH	TATA spare parts
269999716396	SIDE MOULD QUAR RR LH	TATA spare parts
269999716398	SIDE MOULD FENDER RH	TATA spare parts
269999726302	SIDE MOULD QUAR RR RH	TATA spare parts
269999726303	SIDE MOULD W/ARCH RH	TATA spare parts
269999726314	TAIL PIECE RH BURN RED	TATA spare parts
269999726327	SIDE MLD FRT DOOR LH	TATA spare parts
269999726329	SIDE MOULD QUAR RR LH	TATA spare parts
269999726330	SIDE MOULD W/ARCH LH	TATA spare parts



269999726331	SIDE MOULD FENDER RH	TATA spare parts
269999726343	COVER FRT.BUMPER LH PMG	TATA spare parts
270029100101	PULL ROD BRAKE 2213	TATA spare parts
270029100107	CONTROL MOUNTING BRACKET	TATA spare parts
270029100109	PIPE 6 DIA	TATA spare parts
270029100111	ASSY CONNECTING LINE	TATA spare parts
270029100113	CL MASTER CYL 23.81D	TATA spare parts
270029100115	CLUTCH M/CYL	TATA spare parts
270029100118	ASSY CLUTCH M/CYL.1312TC	TATA spare parts
270029103301	BRACKET	TATA spare parts
270029300101	CLUTCH ROD ASSY	TATA spare parts
270029500101	ASSY CONTROL MOUNTING BRACKET 2515TC	TATA spare parts
270029500105	BKT CL MASTER CYL MTG	TATA spare parts
270029500108	ASSY CONTROL MOUNTING BRACKET 2515TC	TATA spare parts
270031000102	FRAME ASSY LPT2213/56	TATA spare parts
270031200101	BUMPER CROSS MEMBER	TATA spare parts
270031207102	CROSS MEMBER 8TH	TATA spare parts
270031207103	PLATE	TATA spare parts
270031207105	CROSS MEMBER 6TH	TATA spare parts
270031207106	END CROSS MEMBER	TATA spare parts
270031207107	CROSS MEMBER 4/5TH	TATA spare parts
270031307101	REINFORCEMENT RH-FRT.SPR.BKT.REAR	TATA spare parts
270031307102	REINFORCEMENT LH BOTTOM	TATA spare parts
270031307103	SUPPORT RR SPRING	TATA spare parts
2700320037	BUSH	TATA spare parts
270032300105	SHOCK ABS MTG BRACKET	TATA spare parts
270032303302	BKT S/ABS ON F/A	TATA spare parts
270035108301	SHIM ADJ	TATA spare parts
270041110101	PROP SHAFT FR W/CEN BRG	TATA spare parts
270041110102	ASSY PROP SHAFT FRONT	TATA spare parts
270041120101	PROP SHAFT REAR COMP	TATA spare parts
270042808201	BRACKET (HOSE MOUNTING)	TATA spare parts
270042900101	TUBE ASSY	TATA spare parts
270042900102	TUBE ASSY	TATA spare parts
270042900105	TUBE ASSY	TATA spare parts
270042900106	TUBE ASSY	TATA spare parts
270042900107	ASSY PIPE	TATA spare parts
270042900109	ASSY TUBE	TATA spare parts
270042900111	TUBE ASSY	TATA spare parts
270042900138	TUBE ASSY	TATA spare parts
270042900141	TUBE ASSY	TATA spare parts
270042900142	TUBE ASSY	TATA spare parts
270042900143	TUBE ASSY	TATA spare parts
270042900144	TUBE ASSY	TATA spare parts
270042900145	TUBE ASSY	TATA spare parts
270042903301	BRACKET	TATA spare parts
270042906801	CROSS BODY	TATA spare parts

270042910105	3/8INCH HOSE ASSY W/END FITT	TATA spare parts
270044400104	ASSY PIPE 15 O.D.	TATA spare parts
270044400105	TUBE ASSY	TATA spare parts
270044400107	TUBE ASSY	TATA spare parts
270044400111	TUBE ASSY	TATA spare parts
270044400112	TUBE ASSY	TATA spare parts
270044400113	TUBE ASSY	TATA spare parts
270044400114	ASSY.TUBE	TATA spare parts
270044400115	TUBE ASSY-18 O.D.	TATA spare parts
270044403301	BRACKET BS6	TATA spare parts
270044403302	BRACKET¿BS6	TATA spare parts
270046100101	BKT STRG G/BOX & CON MTG	TATA spare parts
270046100104	BKT STRG G/BOX & CON MTG	TATA spare parts
270046106301	PROTECTIVE RUBBER CAP.	TATA spare parts
270046106302	PROTECTIVE RUBBER CAP	TATA spare parts
270046207905	STRG. SPINDLE-BOTTOM	TATA spare parts
270046800101	ASSY.TUBE	TATA spare parts
270046800104	ASSY.TUBE	TATA spare parts
270046800106	ASSY PIPE 15 O.D.	TATA spare parts
270046803302	BRACKET	TATA spare parts
270046806801	BANJO M16 X 1.5	TATA spare parts
270046806802	BANJO	TATA spare parts
270047600101	FUEL FEED LINE	TATA spare parts
270047600103	ASSY FUEL RETURN LINE	TATA spare parts
270047600106	ASSY FUEL SUCTION LINE	TATA spare parts
270049100102	ASSY.EXH.PIPE FRT.MIDDLE	TATA spare parts
270054600103	ASSY CABLE SET-FRONT TO TAIL LIGHT	TATA spare parts
270054600104	ASSY MAIN CABLE SET RHD	TATA spare parts
270054820101	ASSY CABLE SET (FRONT TO TAIL) S-CAM	TATA spare parts
270060100105	BARE COWL LPT2213	TATA spare parts
270081806301	MASCOT 2213	TATA spare parts
270088500101	BUMPER COMP	TATA spare parts
270088500102	ASSY BUMPER SUPPORT	TATA spare parts
270088500104	BUMPER ASSY WELDED	TATA spare parts
270088500104C0	ASSY BUMPER WITH REFLECTOR - BLACK	TATA spare parts
270088500104C1	ASSY BUMPER WITH REFLECTOR - RUBY RED	TATA spare parts
270089100103	ASSY BRACKET LH-FRT MTG	TATA spare parts
270089100105	ASSY BKT LH(COWL MTG)2213	TATA spare parts
270098800101	ASSY 2213 MASCOT	TATA spare parts
270131000103	FRAME ASSY CREW CAB	TATA spare parts
270131000105	ASSY FRAME(BUCKET SEATWITH LCRV)	TATA spare parts
270131000120	ASSY.FRAME-PARABOLIC SPRING 4SP ENGINE	TATA spare parts
270131000128	ASSY.FRAME FACELIFT	TATA spare parts
270131000130	ASSY FRAME CREWCAB DI	TATA spare parts
270131000131	ASSY FRAME 207 DI CREWCAB	TATA spare parts
270131000132	ASSY FRAME KIT FOR RETROFITMENT	TATA spare parts
270131000134	KIT - MINOR-FRAME RETRO FITMENT	TATA spare parts

270131000139	FRAME RETRO KIT 207DI CREW CAB	TATA spare parts
270131000141	ASY.FRAME 207DICC(TCD REDUCTION)	TATA spare parts
270131000142	ASSY FRAME TELCOLINE 4PL	TATA spare parts
270131100149	ASSY.BRACKET CAB MTG.	TATA spare parts
270131200105	CROSS MEMBER REAR	TATA spare parts
270131200114	ASSY.CROSS RUNNER-W/O SILENCER MTG.	TATA spare parts
270131200119	ASSY.CROSS MEMBER	TATA spare parts
270131200120	ASSY. CROSS RUNNER	TATA spare parts
270131200124	ASSY.CROSS MEMBER	TATA spare parts
270131200125	ASSY.CROSS RUNNER-LOAD BODY MTG.	TATA spare parts
270131200126	ASSY.PLATE RETROFITMENT	TATA spare parts
270131208211	SUPPORT R.H. REAR RUNNER	TATA spare parts
270131208212	SUPPORT L.H.-REAR RUNNER	TATA spare parts
270131208213	FUEL TANK SUPPORT	TATA spare parts
270131208224	PLATE	TATA spare parts
270131208225	STIFFENER	TATA spare parts
270131208226	STIFFENER	TATA spare parts
270131208231	REINFORCEMENT L.H.	TATA spare parts
270131208232	REINFORCEMENT R.H.	TATA spare parts
270140100103	ASSY BRACKET SPARE WHEEL MTG.	TATA spare parts
270140300104	ASSY. SPARE WHEEL CARRIER.	TATA spare parts
270140306501	SPARE WHEEL NUT-A/F 19	TATA spare parts
270140308701	SPRING-CASING	TATA spare parts
270141000103	ASSY PROPELLER SHAFT	TATA spare parts
270141110103	APSC (FRONT) 836	TATA spare parts
270142700107	ASSY.PARKING BRAKE CABLE REAR	TATA spare parts
270142700109	ASSY.PARKING BRAKE CABLE REAR	TATA spare parts
270142700115	ASSY.PARKING BRAKE CABLE REAR	TATA spare parts
270142700118	ASSY.PARKING BRAKE CABLE REAR	TATA spare parts
270142700121	ASSY.PARKING BRAKE CABLE REAR	TATA spare parts
270142800105	TUBE ASSY	TATA spare parts
270142800160	ASSY.TUBE	TATA spare parts
270142800162	ASSY.TUBE	TATA spare parts
270142800164	ASSY TUBE RH FRONT	TATA spare parts
270142800165	ASSY TUBE LH FRONT	TATA spare parts
270142800166	ASSY. TUBE	TATA spare parts
270142800167	ASSY TUBE	TATA spare parts
270142803308	BRACKET	TATA spare parts
270142808201	PLATE BS6	TATA spare parts
270146800106	HOSE PUMP TO GR BOX HI PR	TATA spare parts
270146808201	BRACKET	TATA spare parts
270146808601	SPACER STG RESERVOIR MTG	TATA spare parts
270147100109	FILLER NECK TOP W/BKT	TATA spare parts
270147100118	ASSY.BRACKET (FUEL TANK MTG.FRONT	TATA spare parts
270147100125	ASSY. FUEL TANK COMPLETE.	TATA spare parts
270147100130	ASSY. FILLER NECK WITH BRACKET.	TATA spare parts
270147100131	ASSY.PIPE-FUEL FILLING	TATA spare parts

270147100136	ASSY FUEL TANK COMPLETE	TATA spare parts
270147100142	ASSY FILLER NECK TOP FOR PLAS CAP(+ BKT)	TATA spare parts
270147100144	ASSY FILLER NECK TOP FOR PLAS CAP + BKT	TATA spare parts
270147100148	ASSY BRACKET FUEL FILTER MTG	TATA spare parts
270147107707	RUBBER HOSE-FUEL FILLING	TATA spare parts
270147107708	RUBBER HOSE-FUEL FILLING	TATA spare parts
270147108226	CLAMP-FUEL FILLING PIPE	TATA spare parts
270147108231	BRACKET	TATA spare parts
270147503301	BRACKET	TATA spare parts
270147508201	BRACKET	TATA spare parts
270147600105	ASSY. BREATHER TUBE.	TATA spare parts
270147600108	ASSY. SUCTION LINE-TANK TO HOSE	TATA spare parts
270147600109	ASSY. RETURN LINE-HOSE TO TANK	TATA spare parts
270147600110	ASSY SUCTION PIPE (HOSE TO FEED PUMP)	TATA spare parts
270147606901	SUCTION LINE FUEL	TATA spare parts
270147606902	RETURN LINE FUEL	TATA spare parts
270147606909	PIPE 8 DIA. (HOSE TO HOSE)	TATA spare parts
270147606916	PIPE 8 DIA. (HOSE TO HOSE)	TATA spare parts
270147606921	RETURN LINE (TUBE 10X0.7 SS:4040-20)	TATA spare parts
270147608201	BRACKET (FUEL LINES)	TATA spare parts
270149200118	ASSY.REAR PIPE COMPLETE.	TATA spare parts
270149200121	ASSY.EXHAUST PIPE ( FRONT )	TATA spare parts
270149200124	EXH.PIPE FRONT CCAB	TATA spare parts
270149200125	EXH.PIPE INTERM 4X2	TATA spare parts
270154500104	DOOR SWITCH	TATA spare parts
270154600103	W/H TAIL	TATA spare parts
270154600106	W/H ROOF	TATA spare parts
270154600107	W/H DOOR REAR	TATA spare parts
270154600126	W/H ROOF	TATA spare parts
270154600127	W/H DOOR REAR	TATA spare parts
270154600134	WIRING HARNESS CABIN RHD W/O A/C	TATA spare parts
270154600135	WIRING HARNESS FRONT W/O A/C	TATA spare parts
270154600136	WIRING HARNESS TAIL 3100LG	TATA spare parts
270154600145	WIRING HARNESS TAIL 31WB 4SP	TATA spare parts
270154600147	WIRING HARNESS ROOF	TATA spare parts
270154600149	WIRING PIG TAIL EARTH	TATA spare parts
270154600151	WH TAIL TMCC 31W/B 4X2LHD	TATA spare parts
270154600152	W/H BLOWER(3POLE)TMCC(4X2LHD)EXPORT	TATA spare parts
270154600153	W/H BLOWER(4POLE)TMCC(4X2LHD)EXPORT	TATA spare parts
270154600154	W/H BELT TMCC 4X2LHD EXPORT	TATA spare parts
270154600165	WIRING HARNESS ROOF	TATA spare parts
270154600171	WIRING HARNESS-ENGINE	TATA spare parts
270154600188	WIRING HARNESS CO-DRIVER DOOR	TATA spare parts
270154600189	WIRING HARNESS DRIVER DOOR	TATA spare parts
270154600190	WIRING HARNESS CENTRAL LOCKING	TATA spare parts
270154600193	W/H.ROOF LAMP+HT.DEMIS[2-ROOF LAMP]	TATA spare parts
270154600197	W/H.DRIVER SIDE REAR DOOR	TATA spare parts

270154600198	W/H.CO-DRIVER SIDE REAR DOOR	TATA spare parts
270154610101	W/H.ROOF-DOUBLE LAMP & STOP LAMP	TATA spare parts
270154900101	KIT-CENTRAL LOCKING	TATA spare parts
270154900102	CENTRAL LOCKING MASTER MTG.PLATE LH DOOR	TATA spare parts
270154900103	CENTRAL LOCKING MASTER MTG.PLATE RH DOOR	TATA spare parts
270154900105	KIT-CENTRAL LOCKING	TATA spare parts
270154900106	KIT-CENTRAL LOCKING	TATA spare parts
270160000142	BODY SHELL WITH DOORS-TATA CREW CAB	TATA spare parts
270160010196BF	CAB COMPL. PAINTED RHD WHITE	TATA spare parts
270160010196BN	CAB COMPL. PAINTED RHD RUBY RED	TATA spare parts
270160010196BS	CAB COMPL. PAINTED RHD SOLID GREEN	TATA spare parts
270160010197BF	BODY SHELL COMPLETE PAINTED RHD WHITE	TATA spare parts
270160010197BN	BODY SHELL COMPLETE PAINTED RHD RUBY RED	TATA spare parts
270160010197BS	BODY SHELL COMPLETE PAINTED SOLID GREEN	TATA spare parts
270160010198	ASSY BODY SHELL COMPLETE RHD	TATA spare parts
270163000101	ASSY.SIDE WALL LH TM CREW	TATA spare parts
270163000102	ASSY.SIDE WALL RH TM CREW	TATA spare parts
270163000105	ASSY.SIDE WALL LH RHD	TATA spare parts
270163000106	ASSY.SIDE WALL RH RHD	TATA spare parts
270163000107	SIDE WALL LH LHD	TATA spare parts
270163000108	ASSY.SIDE WALL RH LHD	TATA spare parts
270163000109	ASSY SIDE WALL LH RHD	TATA spare parts
270163000110	ASSY.SIDE WALL LH.	TATA spare parts
27016300Z107	ASSY.SIDE WALL LH LHD	TATA spare parts
27016300Z108	ASSY.SIDE WALL RH LHD	TATA spare parts
270163108213	REINF. REAR LH DOOR PART	TATA spare parts
270163108214	REINF REAR RH DOOR POST	TATA spare parts
270163108215	DOOR POST FRAME RR LH DC	TATA spare parts
270163108216	DOOR POST FRAME RR RH DC	TATA spare parts
27016310C215	DOOR POST FRAME REAR LH	TATA spare parts
27016310C216	DOOR POST FRAME REAR RH	TATA spare parts
270163600102	TOP RAIL MIDDLE RH	TATA spare parts
270163608201	PANEL INN CORNER LH R/W	TATA spare parts
270163608202	PANEL INNER CORNER RH R/W	TATA spare parts
270163708203	PANEL OUT CORNER LH R/W	TATA spare parts
270163708204	PANEL OUTER CORNER RH	TATA spare parts
270164608202	TOP RAIL CORNER REAR RH	TATA spare parts
270164708201	PANEL CENTRE REAR WALL	TATA spare parts
270165700101	ASSY.ROOF PANEL. CREW CAB	TATA spare parts
270165708201	ROOF PANEL CREW CAB	TATA spare parts
270168800122	ASSY.MOULDED CARPET KIT RHD	TATA spare parts
270169206378	LINING BOTTOM LH (BC POST)DARK GRAY	TATA spare parts
270169206379	LINING BOTTOM RH (BC POST)DARK GRAY	TATA spare parts
270169500103	KIT ASSY.ROOF & INSIDE LINING	TATA spare parts
270169500112	ASSY.REAR WALL PADDING GRAY	TATA spare parts
270169506304	MOULDED ROOF LINING	TATA spare parts
270170000150	ASSY.LOAD BODY COMPL.WITH FIT.	TATA spare parts

270170000151	ASSY.LOAD BODY SINGLE WALL	TATA spare parts
270170000153	ASSY.LOAD BODY PAINTED	TATA spare parts
270170000153BF	ASSY.LOAD BODY PAINTED	TATA spare parts
270170000153BL	LOAD BODY COMP. N. BLUE PAINTED	TATA spare parts
270170000153BN	LOAD BODY COMP. RUBY RED PAINTED	TATA spare parts
270170000153BS	LOAD BODY COMP. SOLID GREEN PAINTED	TATA spare parts
270170000153CN	ASSY.LOAD BODY PAINTED ARCTIC WHITE	TATA spare parts
270170006303	LINER INNER LH RR W/ARCH	TATA spare parts
270170006304	LINER INNER RH RR W/ARCH	TATA spare parts
270170006305	MUDGUARD LINER LH	TATA spare parts
270170006306	MUDGUARD LINER RH	TATA spare parts
270170006311	FENDER EXTENSION LH	TATA spare parts
270170006312	FENDER EXTENSION RH	TATA spare parts
270170108217	FLOOR PANEL(LONGER LOAD BODY)	TATA spare parts
270170300112	SIDE WALL ASSY RH 28WB	TATA spare parts
270170300124	END PIECE PANEL	TATA spare parts
270170300125	END PIECE PANEL	TATA spare parts
270170300129	SIDE WALL ASSY LH 28WB	TATA spare parts
270170300147	SIDE WALL ASSY RH	TATA spare parts
270170300148	SIDE WALL ASSY LH	TATA spare parts
270170308211	END PIECE LH(SIDE PANEL INNER CENTRE)	TATA spare parts
270170308212	END PIECE R.H.(SIDE PANEL INNER CENTRE)	TATA spare parts
270170308229	SIDE PANEL OUTER LH.	TATA spare parts
270170308230	SIDE OUTER PANEL RH.	TATA spare parts
270170500104	ASSY STRUCTURE(SOFT TOP)	TATA spare parts
270170500105	ASSY SOFT CANOPY	TATA spare parts
270173200101	DOOR SHELL REAR LH	TATA spare parts
270173200102	DOOR SHELL REAR RH	TATA spare parts
270173200109	GUIDE CHANNEL LH	TATA spare parts
270173200110	GUIDE CHANNEL RH	TATA spare parts
27017320Z101	ASSY. DOOR SHELL LH	TATA spare parts
27017320Z102	ASSY. DOOR SHELL RH	TATA spare parts
270173300101	DOOR SEALING RR LH OUTER	TATA spare parts
270173300102	DOOR SEALING RR RH OUTER	TATA spare parts
270173300103	OUTER DOOR HANDLE LH RR	TATA spare parts
270173300104	OUTER DOOR HANDLE RH RR	TATA spare parts
270173300107	ASSY.DOOR CHECK REAR.	TATA spare parts
270173300108	DOOR OUTER HANDLE LH RR	TATA spare parts
270173300109	DOOR OUTER HANDLE RH RR	TATA spare parts
270173300110	DOOR CHECK REAR	TATA spare parts
270173300111	REAR DOOR HANDLE OUTER W/O LOCK LH	TATA spare parts
270173300112	REAR DOOR HANDLE OUTER W/O LOCK RH.	TATA spare parts
270173300118	ASSY.OUTER HANDLE LH(REAR DOOR)	TATA spare parts
270173300119	ASSY.OUTER HANDLE RH(REAR DOOR)	TATA spare parts
270173306001	LINK LH LOCK - BELL CRANK	TATA spare parts
270173306002	LINK RH LOCK- BELL CRANK	TATA spare parts
270173306003	PULL ROD LH INNER HANDLE	TATA spare parts

270173306004	PULL ROD RH INNER HANDLE	TATA spare parts
270173306005	PULL ROD LH POP UP KNOB	TATA spare parts
270173306006	PULL ROD RH POP UP KNOB	TATA spare parts
270173306009	LINK POP UP KNOB	TATA spare parts
270173500107	WEATHER STRIP RR INN LH	TATA spare parts
270173500108	WEATHER STRIP RR INN RH	TATA spare parts
270173500109	WEATHER STRIP RR OUT LH	TATA spare parts
270173500110	WEATHER STRIP RR OUT RH	TATA spare parts
270173502301	REGULATING GLASS RR LH	TATA spare parts
270173502302	REGULATING GLASS RR RH	TATA spare parts
270173502303	REG GLASS REAR LH TINTED	TATA spare parts
270173502304	REGULATING GLASS TINTED-REAR DOOR RH	TATA spare parts
270173502503	VELVET CHANNEL	TATA spare parts
270173700109	PADDING REAR DOOR LH	TATA spare parts
270173700110	ASSY PADDING REAR DOOR RH	TATA spare parts
270173700117	ASSY.PADDING DOOR LH	TATA spare parts
270173700118	ASSY.PADDING DOOR RH	TATA spare parts
270173706301	COVER PADDING REAR LH	TATA spare parts
270173706302	COVER PADDING-R.H.	TATA spare parts
270173706305	COVER PADDING LH-DARKER GRAY	TATA spare parts
270173706306	COVER PADDING RH-DARKER GRAY	TATA spare parts
270173706307	CAP(COVER PADDING SCREWED TYPE)GRAY	TATA spare parts
270181100101	PLASTIC GRILL RR INNER	TATA spare parts
270181100102	PLASTIC GRILL RR OUTER LH	TATA spare parts
270181100103	PLASTIC GRILL RR OUTER RH	TATA spare parts
270181100112	SEALING INN NLS RR DOOR	TATA spare parts
270181100114	SEALING INNER FRT DR.LH TM & CREW	TATA spare parts
270181100115	SEALING INNER FRT DR.RH TM & CREW	TATA spare parts
270181100116	SEALING INNER RR DR TM & CREW	TATA spare parts
270181100118	ASSY.ROOF BEADING REAR	TATA spare parts
270181106302	ROOF BEADING LH	TATA spare parts
270181106303	ROOF BEADING RH	TATA spare parts
270181106304	DECO BEAD REAR	TATA spare parts
270181106308	END CAP REAR LH(ROOF BEADING)	TATA spare parts
270181106309	END CAP REAR RH(ROOF BEADING)	TATA spare parts
270181106310	ROOF BEADING FRONT	TATA spare parts
270181106312	COVER (FOR ELR COVER)DARK GREY	TATA spare parts
270181110102	ASSY SIDE STEP COMPLT WITH COVER	TATA spare parts
270181906302	ROOF CARRIER BRACKET REAR LH	TATA spare parts
270181906303	ROOF CARRIER BRACKET REAR RH	TATA spare parts
270181906304	ROOF CARRIER BRACKET FRONT LH	TATA spare parts
270181906305	ROOF CARRIER BRACKET FRONT RH	TATA spare parts
270181906901	TUBE(ROOF CARRIER)	TATA spare parts
270188100101	SIDE BONNET LH CREW CAB	TATA spare parts
270188100102	SIDE BONNET RH CREW CAB	TATA spare parts
270191000134	FOLDABLE BENCH SEAT	TATA spare parts
270191000137	ASSY.FRT.SEAT COMP.LH(R/T)4X2	TATA spare parts

270191000148	ASSY.FRT.SEAT COMP.RH(R/T)4X2	TATA spare parts
270191500107	ASSY.SEAT BELT KIT W/O.SW 3 SEATER	TATA spare parts
270191706301	PACKING BOTTOM SEAT MTG	TATA spare parts
270193000110	B/SEAT REAR 4X2 CREW CAB	TATA spare parts
270193000111	ASSY.REAR SEAT WITH THREE HEADRESTS	TATA spare parts
270193000112	ASSY.REAR SEAT WITH THREE HEADRESTS	TATA spare parts
270193000113	ASSY.REAR SEAT WITH THREE HEADRESTS	TATA spare parts
270193000115	ASSY.REAR SEAT WITH THREE HEADRESTS	TATA spare parts
270193000116	ASSY.REAR SEAT WITH THREE HEADRESTS	TATA spare parts
270193000117	ASSY.REAR SEAT WITH THREE HEADRESTS	TATA spare parts
270193500104	ASSY.SEAT BELT KIT COMPLETE	TATA spare parts
270193500105	ASSY.SEAT BELT KIT COMPLETE	TATA spare parts
270193500109	TONGUE ASSY LH BS6-PH2	TATA spare parts
270193500110	TONGUE ASSY RH BS6-PH2	TATA spare parts
270193500111	WEBBING BUCKLE ASSY BS6-PH2	TATA spare parts
270193500116	ASSY.SEAT BELT KIT COMPLETE	TATA spare parts
270215103202	HEX FLANGED BOLT M8 X 65	TATA spare parts
270215109901	STARTER MOTOR	TATA spare parts
270215200101	KIT HIGH TENSION CABLE	TATA spare parts
270215200107	HEATED LAMBDA SENSOR- (L=560)	TATA spare parts
270215200110	KIT H.T. CABLE - MPFI	TATA spare parts
270215409901	GLOW PLUG	TATA spare parts
270215409903	ALT.12V 75A W/O VACUUM PUMP	TATA spare parts
270215409912	GLOW PLUG BS1/2/3/4	TATA spare parts
270215409912DF	GLOW PLUG - ACE	TATA spare parts
270215409922	GLOW PLUG STRIP	TATA spare parts
270215409924	SPARK PLUG	TATA spare parts
270215409930	GLOW PLUG STRIP	TATA spare parts
270224100101	BRACKET-ENGINE STOPPER.	TATA spare parts
270225103401	BUSH LOWER ON HOUSING	TATA spare parts
270225103402	BUSH UPPER ON HOUSING	TATA spare parts
270225103403	BUSH UPPER (ON HOUSING) BS1/2/3/4	TATA spare parts
270225107701	COVER INSP.WINDOW	TATA spare parts
270225107702	COVER (INSP.WINDOW)PETROL-INJECTED VERS	TATA spare parts
270225107703	COVER	TATA spare parts
270225108201	BACK COVER TRANSAXLE	TATA spare parts
270225108202	BACK COVER (ON TA65 WITH 475IDI TC ENG)	TATA spare parts
270225200109	190 DIA CLUTCH DISC ASSY.-DIESEL	TATA spare parts
270225200114	CL.DISC ASSY.-INDIGO PETROL-VALEO	TATA spare parts
270225200119	190 DIA.CLUTCH DISC ASSY-PETROL	TATA spare parts
270225400103	90 DIA COVER ASSEMBLY	TATA spare parts
270225408002	HEX FL SCREW PR PL MTG	TATA spare parts
270225600101	ASSY.CL.RELS.BRG.WITH SLEEVE	TATA spare parts
270225600103	CLUTCH RELEASE LEVER	TATA spare parts
270225600104	CLUTCH RELEASE YOKE	TATA spare parts
270225600105	ASSY.CLUTCH REL.BRG.WITH SLEEVE	TATA spare parts
270225600108	ASSY.CL.RELS.BRG.WITH SLEEVE	TATA spare parts



270225600110	CLUTCH RELEASE LEVER	TATA spare parts
270225600112	ASSY.CLUTCH RELEASE BEARING-VALEO(INDIG)	TATA spare parts
270225605103	CLUTCH RELEASE YOKE (FORGED) BS6	TATA spare parts
270229100148	CLUTCH CABLE DIESEL+PETRO	TATA spare parts
270229106504	NUT CLUTCH CABLE LOCK	TATA spare parts
270229106703	PIN CLUTCH CABLE GUIDE	TATA spare parts
270229107704	RUBBER STOPPER-CLUTCH PEDAL	TATA spare parts
270229107709	RUBBER COVER (PEDAL PLATE)	TATA spare parts
270229108707	CL.PEDAL ASSIST SPRING	TATA spare parts
270229206703	PIN (BOOSTER END TO PEDAL	TATA spare parts
270230100155	ACCELERATOR CABLE	TATA spare parts
270230100156	ASSY.ACCELERATOR CABLE PETROL	TATA spare parts
270230100184	ASSY.ACCELERATOR CABLE (MPFI)	TATA spare parts
270230103403	BUSH	TATA spare parts
270230104302	CLAMP (FOR ACC.CABLE DIESEL)	TATA spare parts
270230107501	GROMMET	TATA spare parts
270230107703	RUBBER COVER (ACC.PEDAL)	TATA spare parts
270232100139	PIVOT BUSH	TATA spare parts
270232100160	BALL JOINT DLE RANE	TATA spare parts
270232106917	TIE MEMBER FR SUSPN INDICA	TATA spare parts
270232110105	ASSY BALL JOINT LH (POWER STG)	TATA spare parts
270232110106	ASSY BALL JOINT RH (POWER STG)	TATA spare parts
270232110121	FR STRUT LH 0138	TATA spare parts
270232110122	ASSY.FRONT STRUT DAMPER RH	TATA spare parts
270232110123	ASSY.FRONT STRUT LH	TATA spare parts
270232110147	ASSLY LOWER LINK LH MANUAL	TATA spare parts
270232110148	ASSLY LOWER LINK RH MANUAL	TATA spare parts
270232420175	SEMI TRAILING ARM LH--NLS	TATA spare parts
270232420177	TRAILING ARM W/BUSH LH	TATA spare parts
270232420182	OTR BKT SEMI TRAIL ARM LH	TATA spare parts
270232420183	OTR BKT SEMI TRAIL ARM RH	TATA spare parts
270232420196	REARSHOX RH SOFT NLS 0197	TATA spare parts
270232427703	RUBBER COVER RR SHOCK ABS	TATA spare parts
270232430130	ASSY INNER BKT LH	TATA spare parts
270232430131	ASSY INNER BKT RH	TATA spare parts
270232430155	ASSY.REAR S/A & SPRING LH(GABRIEL-KAYABA	TATA spare parts
270232430156	REAR SH-ABSORBER RH	TATA spare parts
270232600114	ASSY.REAR SHOCK-ABS	TATA spare parts
270232807501	BUSH ANTIROLL BAR MTG	TATA spare parts
270232807703	BEARING BLOCK A.R.BAR	TATA spare parts
270232807907	ANTIROLL BAR	TATA spare parts
270232808201	CLAMP	TATA spare parts
270232808401	SLEEVE ANTI ROLL BAR	TATA spare parts
270233103106	ANGULAR CONTACT BALL BRG	TATA spare parts
270233103206	HEX FL BOLT	TATA spare parts
270233106505	LOCK NUT	TATA spare parts
270233109201	WASHER	TATA spare parts

270235107905	SPINDLE	TATA spare parts
270235108301	SHIM ADJ	TATA spare parts
270235603706	HUB CUM BRAKE DRUM (REAR) (180 DIA.)	TATA spare parts
270235607801	OIL SEAL REAR HUB NLS(7805)	TATA spare parts
270235608201	HUB COVER	TATA spare parts
270235608304	SHIM-1.00 THK	TATA spare parts
270235608305	SHIM-0.50 THK	TATA spare parts
270235608306	SHIM-0.40 THK	TATA spare parts
270235608308	SHIM-0.30 THK	TATA spare parts
270235608311	SHIM-0.15 THK	TATA spare parts
270235608312	SHIM (0.100 THK)	TATA spare parts
270235608603	SPACER (FOR OIL SEAL)	TATA spare parts
270240100110	WH RIM	TATA spare parts
270240100114	ASSLY WHEEL RIM 4.5J * 13	TATA spare parts
270240103201	WHEEL MOUNTING PIN	TATA spare parts
270240109971	VALVE TR-414 FOR TUBELESS TYRE	TATA spare parts
270242100108	CALLIPER ASSYLH	TATA spare parts
270242100109	CALLIPER ASSYRH	TATA spare parts
270242100116	DISC BRAKE ASSY LH	TATA spare parts
270242100117	DISC BR RH KBX	TATA spare parts
270242100138	KIT CALIPPER MAJOR	TATA spare parts
270242100139	KIT SLIDING PIN	TATA spare parts
270242100146	KIT CALIPER MINOR	TATA spare parts
270242100149	CALLIPER ASSYLH	TATA spare parts
270242100150	CALLIPER ASSYRH	TATA spare parts
270242100153	CALLIPER ASSYLH	TATA spare parts
270242100154	CALLIPER ASSYRH	TATA spare parts
270242100155	KIT BR PAD BI NLS	TATA spare parts
270242100157	CALLIPER ASSYLH	TATA spare parts
270242100158	CALLIPER ASSYRH	TATA spare parts
270242100163	KIT-DISC BRAKE (MINOR) 414	TATA spare parts
270242100164	KIT SLIDING PIN KBX	TATA spare parts
270242100165	KIT PAD ASSY KBX	TATA spare parts
270242100166	KIT CALIPER MAJOR KBX	TATA spare parts
270242100168	CALIPER ASSY RH W/DP-23 PAD	TATA spare parts
270242100169	CALLIPER ASSYLH	TATA spare parts
270242100170	CALLIPER ASSYRH	TATA spare parts
270242100173	CALIPER ASSY.LH DP23 GREY	TATA spare parts
270242100174	CALIPER ASSY.RH DP23 GREY	TATA spare parts
270242100183	CALLIPER ASSYLH	TATA spare parts
270242100184	CALLIPER ASSYRH	TATA spare parts
270242100185	KIT BRAKE PADS	TATA spare parts
270242103704	FRONT BRAKE DISC 12 THK	TATA spare parts
270242300129	KIT LINED SHOE LH/RH	TATA spare parts
270242300131	WHEEL CYL ASSLY	TATA spare parts
270242300139	STRUT ASSEMBLY LH- P60 1134 5	TATA spare parts
270242300140	STRUT ASSEMBLY RH- P60 1135 3	TATA spare parts

270242300141	WHEEL CYLINDER ASSEMBLY-P70 3850 8	TATA spare parts
270242300146	KIT-LINED SHOE- 415	TATA spare parts
270242308701	SPRING SH RETURNW/C END	TATA spare parts
270242308702	SPRINGSHOERETURN ABUT END	TATA spare parts
270242308703	SPRING STRUT RETURN RH	TATA spare parts
270242308704	SPRING STRUT RETURN LH	TATA spare parts
270242308706	RETURN SPRING D - P65 0013 6	TATA spare parts
270242308707	SHOE RETURN SPRING LOWER-P65 0055 0	TATA spare parts
270242700119	ASSY SEALING PLATE.	TATA spare parts
270242700123	PARKING BRAKE LEVER- L	TATA spare parts
270242704203	CLIP (PARKING CABLE)	TATA spare parts
270242706701	PIN (PULLEY MOUNTING)	TATA spare parts
270242707001	PULLEY	TATA spare parts
270242800146	TUBE FR BRAKE LH PART-I	TATA spare parts
270242800151	HOSE FRONT	TATA spare parts
270242800152	ASSY REAR BRAKE HOSE	TATA spare parts
270242800153	BRACKET-PCR V MOUNTING	TATA spare parts
270242800154	TUBE RR BRAKE LH PART-II	TATA spare parts
270242800164	TUBE REAR BRAKE-RH PT-III	TATA spare parts
270242800180	A. VAC PIPE LHD (BOOST PUMP) LHD EUROII	TATA spare parts
270242800186	VACC PIPE BSTR PUMP	TATA spare parts
270242800193	TUBE RR BRAKE	TATA spare parts
270242804202	CLAMP	TATA spare parts
270242804301	CLIP-BRAKE HOSE	TATA spare parts
270242806803	3-WAY CONNECTOR	TATA spare parts
270242806806	ADAPTOR (BRAKE CIRCUIT)	TATA spare parts
270242806807	3 WAY UNION (T CONNECTOR)	TATA spare parts
270243100129	P.C.R.V ASSY	TATA spare parts
270243100130	PCR V ASSY	TATA spare parts
270243100135	SERVO & MC ASSY 7 INCH	TATA spare parts
270243100142	KIT TMC MAJOR DIESEL	TATA spare parts
270243100149	T M C ASSLY DIESEL	TATA spare parts
270243100153	KIT - NON RETURN VALVE	TATA spare parts
270244800139	HOSE HIGH PRESSURE	TATA spare parts
270244800145	A HOSE POWER STR. RETURN LINE	TATA spare parts
270244800148	ASSY. RETURN PIPE LINE	TATA spare parts
270244805802	HOSE	TATA spare parts
270246600120	POWER RACK & PINION STG.GEAR (RHD)	TATA spare parts
270246600133	PLASTIC RESERVIOR ASSY	TATA spare parts
270246600134	RESERVOIR W/TH STRAP	TATA spare parts
270246600152	FILTER&END COVER FOR TANK	TATA spare parts
270246600165	ASSY. OUTER BALL JOINT W/NUT BS3/4	TATA spare parts
270246603405	RUBBER BUSHING	TATA spare parts
270246603511	INNER BALL JOINT (59 60 04 03)	TATA spare parts
270246606506	NYLOCK NUT	TATA spare parts
270246607803	O-RING	TATA spare parts
270246607804	O RING (I.D.7.0X1.5 DIA.)	TATA spare parts

270246608213	MOUNTING STRAP ( RESRERVOIR)	TATA spare parts
270246608404	COLLAR GEAR MOUNTING	TATA spare parts
270247100124	FILLER NECK WITH BRACKET	TATA spare parts
270247100125	ASSY FUEL TANK SCREW CAP(VENTD	TATA spare parts
270247100127	ASSY FILLER NECK WITH BRACKET (22.7 DIA)	TATA spare parts
270247100148	HOSE PIPE FUEL FILLING NLS (0206)	TATA spare parts
270247100150	ASSY.FUEL TANK SCREW CAP-VENTED	TATA spare parts
270247100191	ASSY FUEL TANK SCREW CAP	TATA spare parts
270247600115	ASSY. SUCTION LINE	TATA spare parts
270247600122	ASSY HOSE-SUCTION LINE	TATA spare parts
270247600125	RETURN LINE	TATA spare parts
270247600141	ASSY SUCTION LINE	TATA spare parts
270247600142	ASSY SUCTION LINE	TATA spare parts
270247600144	PIPE RETURN LINE	TATA spare parts
270247600160	ASSY PIPE MPFI	TATA spare parts
270247604202	SPRING CLIP (DIA 19)	TATA spare parts
270247604203	SPRING CLIP	TATA spare parts
270247604205	SPRING CLIP (DIA 20)	TATA spare parts
270247604206	SPRING BAND CLAMP 25DX15W TS17665	TATA spare parts
270247604211	SPRING BAND CLAMP 14*12*0.8	TATA spare parts
270247604213	SPRING CLAMP (22)	TATA spare parts
270247605824	HOSE	TATA spare parts
270247606940	TUBE (4.75 O.D. X 0.7 THK.)	TATA spare parts
270247606941	TUBE (4.75 O.D. X 0.7 THK)	TATA spare parts
270249200126	GASKET EXH MANIFOLD NLS ALT 0137	TATA spare parts
270249200129	SPHERICAL JOINT KIT	TATA spare parts
270249200133	ASSY REAR PIPE (PETROL)	TATA spare parts
270249200137	GASKET EXH MANIFOLD PIPE	TATA spare parts
270249200146	ASSY FRONT PIPE	TATA spare parts
270249200151	ASSY REAR PIPE WITH SI	TATA spare parts
270249200158	GASKET EXH. MANIFOLD	TATA spare parts
270254100107	KIT-BATTERY CABLES DSL	TATA spare parts
270254106301	BATTERY TRAY	TATA spare parts
270254108201	BATTERY CLAMP	TATA spare parts
270254108801	BATTERY STUD	TATA spare parts
270254109913	BATTERY_FOR_ONETONNER_06NOV	TATA spare parts
270254200113	KIT TANK UNIT W/O LL SENS	TATA spare parts
270254200120	BKT.HORN MOUNTING	TATA spare parts
270254207502	RUBBER GASKET	TATA spare parts
270254209913	TEMPERATURE SENSOR	TATA spare parts
270254209919	INST CLUST STD PETROL	TATA spare parts
270254209922	CIGAR LIGHTER - 12V	TATA spare parts
270254209928	DUAL RELAY 12V 30A	TATA spare parts
270254209930	DUAL RELAY 12V 30A	TATA spare parts
270254209931	GLOW PLUG TIMER	TATA spare parts
270254209932	TEMPERATURE SENSOR	TATA spare parts
270254209936	DUAL RELAY 12V 30A	TATA spare parts

270254209939	REVERSING BUZZER -	TATA spare parts
270254209942	DIGITAL CLOCK	TATA spare parts
270254209958	RPM METER	TATA spare parts
270254209960	CHIME UNIT	TATA spare parts
270254209966	BEEPER UNIT	TATA spare parts
270254209968	INTERIOR LIGHT DELAY UNIT	TATA spare parts
270254209984	EGR CONTOLLER-NLS-229906	TATA spare parts
270254219903	HORN 12V W/O RIS	TATA spare parts
270254219909	DUAL TEMPERATURE TRANSDUCER	TATA spare parts
270254219914	SPEEDOCABLE 1100mm	TATA spare parts
270254219915	SP CABLE LHD	TATA spare parts
270254219927	DUAL TEMPERATURE TRANSDUCER	TATA spare parts
270254219936	R.P.M. METER - 0-8000 WHITE DIAL PRICOL	TATA spare parts
270254219939	ASSY. TEMP. & FUEL GAUGE- WHITE DIAL PRI	TATA spare parts
270254229906	EGR II -NLS-284354209963	TATA spare parts
270254400132	ASSLY ENGINE LAMP LUMAX	TATA spare parts
270254400146	KIT- SPARE BULB-H4-12V	TATA spare parts
270254406301	CLIP - HEAD LAMP	TATA spare parts
270254406302	CLIP - TAIL LAMP	TATA spare parts
270254407501	CAP HEAD LAMP	TATA spare parts
270254409912	HEADLAMP WITH BLINKER RH	TATA spare parts
270254409913	HEADLAMP WITH BLINKER LH	TATA spare parts
270254409914	REAR CLUSTER RH (WHITE LENSE)	TATA spare parts
270254409929	COMB H/L WITH BLK. WLM LH RHD	TATA spare parts
270254409938	RR CLUSTER LAMP RH LUMA-L	TATA spare parts
270254409942	SIDE REPEATER LAMP	TATA spare parts
270254409943	REGISTRATION PLATE LAMP	TATA spare parts
270254409946	REGISTRATION PLATE LAMP	TATA spare parts
270254409947	REGISTRATION PLATE LAMP	TATA spare parts
270254409950	ADAPTOR	TATA spare parts
270254409951	PLASTIC NUT (REAR CLUSTER LAMP)	TATA spare parts
270254419903	REAR CLUSTER LAMPLH DLX(IJL) MOD.	TATA spare parts
270254500115	PIGTAIL FOR NEW R.I.SWITCH	TATA spare parts
270254500116	KIT REVERSE LIGHT SWITCH	TATA spare parts
270254509905	REAR FOG LAMP SWITCH.	TATA spare parts
270254509909	HAND BRAKE SWITCH	TATA spare parts
270254509930	STOP LIGHT SWITCH M10 X 1.25	TATA spare parts
270254509931	BRAKE LIGHT SWITCH	TATA spare parts
270254509932	DOOR SWITCH	TATA spare parts
270254509934	STOP LAMP SWITCH	TATA spare parts
270254509935	HAZARD WARNING SWITCH	TATA spare parts
270254509936	W/W SWITCH PACK - FRONT	TATA spare parts
270254509937	W/W SWITCH REAR	TATA spare parts
270254509939	DIMMER UNIT	TATA spare parts
270254509942	RHD STALLK LIGHT SWITCH	TATA spare parts
270254509943	RHD CENTRAL HOUSING	TATA spare parts
270254509947	W/W SWITCH REAR RH	TATA spare parts

270254509950	REVERSE LIGHT SWITCH BS1/2/3/4	TATA spare parts
270254509950AE	REV LITE SWT LPTA 1628/LPTA 1828	TATA spare parts
270254509955	STOP LIGHT SWITCH	TATA spare parts
270254509959	OIL PRESSURE SWITCH	TATA spare parts
270254509960	REVERSE LIGHT SWITCH MODIFIED	TATA spare parts
270254509961	OIL PRESSURE SWITCH	TATA spare parts
270254509968	REVERSE LIGHT SWITCH	TATA spare parts
270254509976	COMBI SW.RD.LEV.INDICA DOMESTIC	TATA spare parts
270254600106	KIT W/H DLX EURO I	TATA spare parts
270254600109	W/H ROOF-DL & DLE NLS	TATA spare parts
270254600130	W/H ENG - PET STD	TATA spare parts
270254600131	KIT W/H DIESEL STD. A.C.	TATA spare parts
270254606358	BATTERY CABLE CLAMP DIA 19-22 -MICROSIGN	TATA spare parts
270254608204	CLAMP -DIA 8.5 W/H.	TATA spare parts
270254609908	MID MAXI FUSE 60A(YELLOW)	TATA spare parts
270254609913	MAXI FUSE-60A FEMALE	TATA spare parts
270254609914	FUSE-80A (BOLT TYPE)	TATA spare parts
270254609927	FUSE 40A FEMALE	TATA spare parts
270254610112	W/H FRT DR RH- LUX NLS	TATA spare parts
270254610183	W/H RR. DR. LH EURO II DLX & MPFI LXI	TATA spare parts
270254709902	COND MOTOR SUB	TATA spare parts
270254709908	BLOWER SWITCH-	TATA spare parts
270254800108	KIT ANTENNA	TATA spare parts
270254900102	KIT CENTRAL LOCK SYSTEM	TATA spare parts
270254900110	KIT IMMOBILISER FOR DELUXE	TATA spare parts
270254900115	KIT CENTRAL LOCKING UNIT - (NEW)	TATA spare parts
270254909920	USER REMOTE-IMMOBILISER ED	TATA spare parts
270254909920AE	USER RMTE-IMOBILISR -XEN DC/SC	TATA spare parts
270258400103	ASSY.FIRST AID KIT-DOMESTIC	TATA spare parts
270258408218	TRANSFER LABEL-BHARAT STAGE II	TATA spare parts
270258408225	TR.LBL.-BHARAT STAGE-II CNG	TATA spare parts
270258408229	TRANSFER LABEL (BHARAT STAGE - III)	TATA spare parts
270258900107	DOLLEY	TATA spare parts
270258900110	PRESSING FIXTURE-BUSH IN	TATA spare parts
270258900201	DRIFT / INSTALL LINER / 475 IDI	TATA spare parts
270258900202	DRIFT FOR REMOVAL OF LINER (475 IDI)	TATA spare parts
270258900601	BOX SPANNER - 16 A/F (FOR SPARK PLUG)	TATA spare parts
270258900603	EXTENDED SOCKET(10A/F)OIL SUMP MTG.SCREW	TATA spare parts
270258900604	PIN	TATA spare parts
270258900604N	CAM SHAFT LOCK PIN	TATA spare parts
270258900605	FLYWHEEL LOCKING PIN / DIESEL PETROL/CUB	TATA spare parts
270258900605N	TDC FLYWHEEL LOCK PIN	TATA spare parts
270258900606	LOCKING PLATE / CAM SHAFT / CUB	TATA spare parts
270258900607	LOCKING PLATE / CAM SHAFTGR WASHER / CUB	TATA spare parts
270258900608	DRIFT - CRANK SHAFT OIL SEAL-R*COVER-CUB	TATA spare parts
270258900609	PIN / FIP GEAR LOCKING / CUB	TATA spare parts
270258900610	SUPPORT RAIL	TATA spare parts

270258900611	DRIFT / VALVE GUIDE-INLET&EXHAUST / CUB	TATA spare parts
270258900612	SPACER / VALVE GUIDE DRIFT / CUB	TATA spare parts
270258900613	HANDLE FOR BOX SPANNER (FORGED)	TATA spare parts
270258900614	DRIFT / P-VALVE GUIDE SEAL / CUB	TATA spare parts
270258900615	VALVE SPRING COMPRESSOR	TATA spare parts
270258900616	SUPPORT RAIL	TATA spare parts
270258900617	DRIFT-Pressing Valve Guide Seal(475 SIC)	TATA spare parts
270258900619	SUPPORT RAIL / 475IDI & 475SI CUB CNG	TATA spare parts
270258900622	TOOL F MTG OF STRETCH BELT I8399SF002CI	TATA spare parts
270258900701	SPANNER	TATA spare parts
270258900702	22 HEX SOC / INJECTOR / CUB	TATA spare parts
270258900703	ADAPTOR/CHECKING ENGINE COMPRESSION/CUB	TATA spare parts
270258900704	27HEX-1/2SQ-120L SOC / REMOVE 4TH INJ	TATA spare parts
270258901801	DRIFT- OIL PUMP OIL SEAL / CUB	TATA spare parts
270258901802	SPANNER / OIL FILTER / CUB	TATA spare parts
270258902401	SUPPORT STAND ENGINE	TATA spare parts
270258902402	MOUNTING 475IDI ENG.ON STAND	TATA spare parts
270258902403	BRACKET(RH)-MOUNTING 475IDI ENG ON STAND	TATA spare parts
270258902404	ENGINE REPAIR STAND	TATA spare parts
270258902501	MANDREL FOR CLUTCH DISC	TATA spare parts
270258902601	DRIFT DRIVE SHAFT OILSEAL	TATA spare parts
270258902602	DRIFT INPUT SHAFT BRG	TATA spare parts
270258902603	DRIFT LAY SHAFT BRG.FRT.	TATA spare parts
270258902604	PULLER	TATA spare parts
270258902606	HOLDER INPUT SHAFT RR BRG	TATA spare parts
270258902607	HOLDER LAY SHAFT REAR BRG	TATA spare parts
270258902608	DIFFERENTIAL BRG INN.RACE	TATA spare parts
270258902609	FIXTURE GR ON DIFF.CASING	TATA spare parts
270258902610	MTG PLATE TRANSAXLE	TATA spare parts
270258902612	REST PAD	TATA spare parts
270258903201	OFFSET SOCKET SPANNER	TATA spare parts
270258903202	SPRING COMPRESSOR SUSPEN	TATA spare parts
270258903217	OFFSET SOCKET SPANNER 12MM	TATA spare parts
270258903301	HOLDER-TORQ DR/SHAFT NUT	TATA spare parts
270258903302	PULLER FRT HUB ASSY	TATA spare parts
270258903303	PULLER FRT HUB BRG	TATA spare parts
270258903304	STRIKER FRT HUB ASSY	TATA spare parts
270258903502	PULLER-REMOVAL OF HUB INNER BRG.OUTER RC	TATA spare parts
270258903503	PULLER HUB OUTER BRG	TATA spare parts
270258903504	DRIFT REAR HUB INNER	TATA spare parts
270258903505	DRIFT REAR HUB OIL SEAL	TATA spare parts
270258904001	WHEEL SPANNER - 18 A/F	TATA spare parts
270258904009	CORD - FOR JACK CLAMPING	TATA spare parts
270258904010	GRIP - FOR JACK CORD	TATA spare parts
270258904017	REVERSIBLE SCREW DRIVER DIA 8X200	TATA spare parts
270258904602	TIE ROD END PULLER	TATA spare parts
270258904607	HOLDER-Removing Power Stg Pump Pulley	TATA spare parts

270258905007	VEHICLE RECORD BAG	TATA spare parts
270282400131	ASSLY NOZZLE UNIT	TATA spare parts
270282400141	REAR WIPER MOTOR -	TATA spare parts
270282404203	CLAMPS FOR FLEXIBLE PIPE	TATA spare parts
270282406307	FILLER NECK WITH CAP	TATA spare parts
270282406313	WIPER ARM CAP Dr.SIDE	TATA spare parts
270282406314	WIPER ARM CAR CO_Dr SIDE	TATA spare parts
270282406315	WIPER ARM CAP REAR	TATA spare parts
270282406328	TANK 1.5LTR-MOD.LOC	TATA spare parts
270282407505	RUBBER GROMMET LOCATING PIN	TATA spare parts
270282407509	T CONNECTOR JOINT	TATA spare parts
270282409908	WIPER ARM (DRIVER) RHD	TATA spare parts
270282409909	WIPERARM CO-DRIVER	TATA spare parts
270282409910	WIPER BLADE	TATA spare parts
270282409916	WIPER ARM (REAR)	TATA spare parts
270282409917	REAR WIPER BLADE 12	TATA spare parts
270282409934	ELECTRIC MOTOR WITH CAP	TATA spare parts
270282409939	WIPER BLADE - REAR	TATA spare parts
270282409950	WIPER BLADE CLIP DR/CO DR	TATA spare parts
270282409951	WIPER BLADE CLIP REAR	TATA spare parts
270282409965	WIPER ARM CO DRIVER SIDE	TATA spare parts
270282409972	WIPER BLADE(500)	TATA spare parts
270282409977	WIPER BLADE (500)-EXPORT BCS	TATA spare parts
270335108301	SHIM ADJ	TATA spare parts
270415189901	INTAKE MANIFOLD HEATER (COLD START)	TATA spare parts
270415400101	ALTERNATOR	TATA spare parts
270429100105	CLUTCH PEDAL LEVER COMPLT	TATA spare parts
270431200103	BKT BODY MTG LH	TATA spare parts
270431200116	ASSY.CROSS MEMBER-FRONT	TATA spare parts
270431500102	ASSY OF PINTLE TOW HOOK 3T	TATA spare parts
270432100108	ASSY BRACKET LH (UPPER W/B MTG.)	TATA spare parts
270432100109	ASSY BRACKET RH (UPPER W/B MOUNTING)	TATA spare parts
270432100126	ASSY. BALL JOINT LOWER BS3/4	TATA spare parts
270432103201	HEX BOLT (TOP SPINDLE)	TATA spare parts
270432103202	HEX FLANGE BOLT(FRONT TORSION BAR MTG.)	TATA spare parts
270432108219	BRACKET	TATA spare parts
270432108301	SHIM 1.6 MM	TATA spare parts
270432108302	SHIM 2.5 MM	TATA spare parts
270432108303	SHIM 3.15 MM	TATA spare parts
270432108304	SHIM 4.00 MM	TATA spare parts
270432109201	WASHER	TATA spare parts
270432900101	ASSY. ANTIROLLBAR COMPLETE (REAR)	TATA spare parts
270440100103	ASSY. WHEEL RIM BS2/3/4	TATA spare parts
270440100108	ASSY WHEEL RIM 5.50FX16	TATA spare parts
270440100109	ASSY TUBE 700 X 16 WITH VALVE	TATA spare parts
270440100120	ASSY.WHEEL DISC & RIM 5.5FX16	TATA spare parts
270440100122	ASSY.WHEEL DISC & RIM 5.5FX16	TATA spare parts



270440100154	ASSY WHEEL RIM 6.5JX16	TATA spare parts
270442800116	FRONT BRAKE HOSE	TATA spare parts
270442805801	VACUUM HOSE 75MM. LONG	TATA spare parts
270442807101	PLATE	TATA spare parts
270444800104	PIPE HIGH PR LINE	TATA spare parts
270444800105	ASSY.PIPE WITH BANJO BODY.	TATA spare parts
270444800106	PIPE RETURN LINE	TATA spare parts
270446203201	HEX BOLT M10 X 140, IS1364P1-10.9	TATA spare parts
270446203202	HEX BOLT M12X140	TATA spare parts
270446600102	ASSY.CENTRE LINK	TATA spare parts
270446600103	STEERING DAMPER	TATA spare parts
270446600104	STEERING DAMPER	TATA spare parts
270446600105	ASSY CENTRE LINK	TATA spare parts
270446600106	ASSY CENTRE LINK	TATA spare parts
270446600107	STEERING DAMPER	TATA spare parts
270446600112	STEERING DAMPER	TATA spare parts
270446800105	ASSY. HOSE (LHD STG. GEAR BOX TO TANK)	TATA spare parts
270446800106	ASSY. HOSE (STG GEAR BOX TO TANK)	TATA spare parts
270446800108	ASSY HIGH PRESS HOSE P/S PUMP TO G.B	TATA spare parts
270446800109	ASSY LOW PRESS HOSE STG G.B TO TANK	TATA spare parts
270446808202	BRACKET	TATA spare parts
270447605801	BREATHER HOSE (15 ID) BS6	TATA spare parts
270447607701	CLAMP-FUEL LINE	TATA spare parts
270449100102	ASSY PRE-SILENCER	TATA spare parts
270449100104	ASSY PRE-SILENCER	TATA spare parts
270449100105	ASSY PRE-SILENCER	TATA spare parts
270454209906	ECU UNIT TRANSFER CASE	TATA spare parts
270454209924	ECU (TRANSFER CASE)	TATA spare parts
270454209932	GRID HEATER RELAY	TATA spare parts
270454400115	ASSY. TUBE LIGHT	TATA spare parts
270454500116	ASSY SWITCH-TRANSFER CASE	TATA spare parts
270454500119	TRANSFER CASE SELECTION SWITCH VERTICAL	TATA spare parts
270454600108	W/H ECU	TATA spare parts
270454600109	WIRING HARNESS TRANSFER CASE	TATA spare parts
270454600114	W/H 4X4 ECU UNIT	TATA spare parts
270454600120	WIRING HARNESS TRANSFER CASE	TATA spare parts
270454600153	W/H ECU TRANSFER CASE	TATA spare parts
270454610111	PIG TAIL -FOR CHANGE OVER SW.	TATA spare parts
270454610144	W/H FOR MODIFIED ECU(TRANSFER CASE)	TATA spare parts
270454700105	ASSY. CAR FAN	TATA spare parts
270458900103	ASSY.SCISS.JACK WITH 3PC HANDLE	TATA spare parts
270458900104	ASSY.SCISS.JACK WITH 3PC HANDLE	TATA spare parts
270458900107	ASSY.SCISS.JACK WITH 3PC HANDLE	TATA spare parts
270458900108	ASSY.SCISS.JACK WITH 3PC HANDLE	TATA spare parts
270458902801	SEAL DRIVER	TATA spare parts
270458902802	YOKE HOLDER	TATA spare parts
270458902804	OIL SEAL FITTING TOOL	TATA spare parts

270458903301	DOLLEY OIL SEAL IN HUB	TATA spare parts
270458903302	DOLLEY OIL SEAL CARRIER	TATA spare parts
270458903303	DOLLEY BRG CUP IN HUB	TATA spare parts
270458903304	DOLLEY BRG CUP IN HUB INN	TATA spare parts
270458903305	DOLLEY NR BRG TUBE FLANGE	TATA spare parts
270458903306	DOLLEY CYL BRG CARR HSG	TATA spare parts
270458903307	PLATE BRG CUP REMOVAL	TATA spare parts
270458903308	PLATE BRG CUP REMOVAL	TATA spare parts
270458903309	DUMMY BRG / DIFF.CASE	TATA spare parts
270458903310	ADAPTOR / R-PINION OUTER CUP	TATA spare parts
270458903311	HANDLE PRSSING DOLLEY	TATA spare parts
270458903312	EXPANDER FOR M30 CARRIER	TATA spare parts
270458903313	GAUGE PINION POSITION	TATA spare parts
270458903314	P-DOLLEY / PINION OUTER CUP	TATA spare parts
270458903315	ADAPTOR / R-PINION INNER CUP	TATA spare parts
270458903316	P-DOLLEY / PINION INNER CONE	TATA spare parts
270458903317	MASTER BLOCK	TATA spare parts
270458903318	SPANNER SPINDLE NUT TORQUE	TATA spare parts
270458903319	DOLLEY OIL SEAL SPINDLE	TATA spare parts
270458903320	DOLLEY BRG CONE SPINDLE	TATA spare parts
270458903321	P DOLLEY / PINION OUTER CUP	TATA spare parts
270458903322	ADAPTOR / R-DIFF.CASE BRG	TATA spare parts
270458903323	ADAPTOR / R-PINION INNER BRG	TATA spare parts
270458903324	PULLER	TATA spare parts
270458903325	P-DOLLEY / DIFF. CASE BRG	TATA spare parts
270458903326	ADAPTOR	TATA spare parts
270458903327	DOLLY	TATA spare parts
270458903328	BEARING PULLER	TATA spare parts
270458903330	PLIER PLAIN	TATA spare parts
270458903331	PLIER TANG	TATA spare parts
270458903332	CLAMP CRIMPER	TATA spare parts
270458904601	1/2"SQ M-F-250L "L" SPNR/CASTER CAMBER/A	TATA spare parts
270458904602	24BI-1/2"SQ Z SPNR/CASTER CAMBER/SUM0 AR	TATA spare parts
270473200102	ASSY.DOOR SHELL REAR RH RHD	TATA spare parts
270473208203	FENDER EXTENSION LH	TATA spare parts
270473208204	FENDER EXTENSION RH	TATA spare parts
270481100111	FENDER EXT.RH FRT NLS (6324)	TATA spare parts
270481103301	BKT FRONT FRT W/A	TATA spare parts
270481103302	BKT MIDDLE FRONT FRT W/A	TATA spare parts
270481103303	BKT MIDDLE REAR FRT W/A	TATA spare parts
270481106304	FENDER EXT. NLS LH RR DOOR	TATA spare parts
270481106326	FENDER EXTN RR RH ARMY AMBULANCE	TATA spare parts
270481800101	ASSY. 4X4 MASCOT	TATA spare parts
270481800103	ASSY `SUMO 4X4' MASCOT	TATA spare parts
270488100103	SIDE BONNET LH 4X4 W/SLOTS (IND & FENDER	TATA spare parts
270488100104	SIDE BONNET RH X4 W/SLOTS (IND & FENDER	TATA spare parts
270488500106	BUMPER FRONT - NLS -0110	TATA spare parts

270488706001	STAY ROD (BONNET)	TATA spare parts
270516100102	CONTAINER 497SPTC (LP410EX TT BS-III)	TATA spare parts
270516100106	CONTAINER 497SPTC (LP410EX TT BS-III)	TATA spare parts
270516100111	CONTAINER 497SPTC (LPK410EX/BS-III)	TATA spare parts
270516100118	ASSY CONTAINER SFC407EX/31WB BS-III SING	TATA spare parts
270516100119	CONTAINER 497SPTC (LPT410/34WB BS-III)	TATA spare parts
270516100120	CONTAINER 497CNG NA (LP407CNG/34WB BS-IV)	TATA spare parts
270516100123	ASSY. CONTAINER LP 410EX/31WB BS-III TW	TATA spare parts
270516100124	CONTAINER 4SPTC (LPT 410EX/34WB BS-III)	TATA spare parts
270516100125	CONTAINER NO.LPT410EX2 (4SP TCIC)	TATA spare parts
270516100128	CONTAINER (LPT 407)	TATA spare parts
270516100129	CONTAINER (LP 410)	TATA spare parts
270524100101	ASSY.BRACKET-RH (ENGINE MOUNTING)	TATA spare parts
270524100102	ASSY.BRACKET-LH (ENGINE MOUNTING)	TATA spare parts
270524100107	ASSY.BRACKET(ENG.MTG.FRONT) -RH	TATA spare parts
270524100108	ASSY.BRACKET (ENG.MTG.FRONT) -LH	TATA spare parts
270526800101	ASSY TURNING TUBE LP 407	TATA spare parts
270526800110	ASSY BRACKET (WITH POWER STG)	TATA spare parts
270526800113	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
270526800122	ASSY BRACKET W/O POWER STG LP CNG	TATA spare parts
270526800129	ASSY BRACKET-CAB W/O POWER STG.	TATA spare parts
270526800131	ASSY BRACKET-COWL W/O POWER STG.	TATA spare parts
270526800138	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
270526807901	LINK ROD	TATA spare parts
270526808001	FLANGED BOLT (WITH SERRATIONS)	TATA spare parts
270526810102	ASSY BRACKET (CAB)	TATA spare parts
270526810103	ASSY BRACKET (COWL)	TATA spare parts
270529100108	ASSY TUBE 6.0 OD X 0.7 THK	TATA spare parts
270529100116	ASSY.PEDAL LEVER COMPLETE	TATA spare parts
270529100120	ASSY.BRAKE PEDAL COMPLETE-LHD	TATA spare parts
270529100127	ASSY.TUBE-CLUTCH LINES.	TATA spare parts
270529100128	ASSY.TUBE-CLUTCH LINES	TATA spare parts
270529100130	ASSY.TUBE	TATA spare parts
270529100131	ASSY.TUBE	TATA spare parts
270529100133	ASSY.TUBE	TATA spare parts
270529100135	ASSY. CLUTCH PEDAL COMPLETE	TATA spare parts
270529100138	ASSY. PEDAL LEVER COMPLETE	TATA spare parts
270529100140	ASSY. SUPPORT COMPLETE BRAKE	TATA spare parts
270529100142	ASSY. TUBE (CLUTCH LINES)	TATA spare parts
270529100164	ASSY. TUBE (CLUTCH LINES)	TATA spare parts
270529200102	ASSY. BRACKET(SLAVE CYL.MTG.)	TATA spare parts
270529205101	CLUTCH RELEASE LEVER	TATA spare parts
270529300101	ASSY. PUSH ROD.	TATA spare parts
270529300102	ASSY. BRACKET (SLAVE CYL.)	TATA spare parts
270530100103	ASSY.BRACKET-ACCL.RETURN SPRING	TATA spare parts
270530100104	ASSY PULL CABLE ACCELERATOR 3117MM	TATA spare parts
270530100107	ASSY.PEDAL WITH COVER	TATA spare parts

270530100108	ASSY.ACCELERATOR PEDAL WITH BRACKET	TATA spare parts
270530100110	ASSY.PULL CABLE ACCELERATOR	TATA spare parts
270530100111	ASSY. PULL CABLE ACCELERATOR	TATA spare parts
270530100112	ACCELERATOR CABLE 2072MM BS2/3	TATA spare parts
270530100114	ASSY PULL CABLE ACCELERATOR	TATA spare parts
270530106001	LINK ROD	TATA spare parts
270530108214	ACCELERATOR PEDAL MTG. BKT.	TATA spare parts
270531000101	ASSY FRAME LP 407	TATA spare parts
270531000108	ASSY.FRAME LHD WITHOUT RUPD	TATA spare parts
270531000109	ASSY FRAME LP 407 TURBO	TATA spare parts
270531000110	ASSY FRAME LPT 407 TURBO	TATA spare parts
270531000111	ASSY FRAME LP 407 TWIN TYRE	TATA spare parts
270531000117	ASSEMBLY FRAME LPT-407-RHD	TATA spare parts
270531000118	ASSEMBLY FRAME LP 509M LHD.	TATA spare parts
270531000123	ASSEMBLY FRAME COMPLETE	TATA spare parts
270531000126	ASSY. FRAME LPT 509SE (34)	TATA spare parts
270531000127	ASSY. FRAME (LPT 407EX 34WB) BS-II	TATA spare parts
270531000129	ASSY.FRAME LP 410EX TWIN TYRE BS-III	TATA spare parts
270531000130	ASSY.FRAME LP 407 (BS-II)	TATA spare parts
270531000131	ASSY.FRAME LPT 407 W/O CLEATS (BS-II)	TATA spare parts
270531000132	ASSY.FRAME LPT 407 WITH CLEATS (BS-II)	TATA spare parts
270531000133	ASSY.FRAME LP 407 TWIN TYRE (BS-II)	TATA spare parts
270531000137	ASSY. FRAME LPT407EX BS2/3	TATA spare parts
270531000140	ASSY. FRAME LP 407 CNG (BS-III)	TATA spare parts
270531000144	ASSY.FRAME LPK407EX/27WB BS-II	TATA spare parts
270531000145	ASSY.FRAME LPK410EX/27WB BS-III	TATA spare parts
270531000147	ASSY. FRAME COMPLETE (LP407/34WB TT)	TATA spare parts
270531000148	FRAME ASSY WITH FITMENT	TATA spare parts
270531000149	FRAME ASSY WITH FITMENT	TATA spare parts
270531000152	ASSY.FRAME COMPLETE	TATA spare parts
270531000155	ASSLY.FRAME COMPLETE (LP407 TMML)	TATA spare parts
270531000156	FRAME ASSY	TATA spare parts
270531000157	FRAME ASSY WITH FITMENT	TATA spare parts
270531000158	ASSY FRAME COMPLETE LP410EX/34WB BS-IV	TATA spare parts
270531000159	ASSY.FRAME COMPLETE (LPT407CNG/34WB BS-I	TATA spare parts
270531000160	FRAME ASSY WITH FITMENT	TATA spare parts
270531000164	FRAME ASSY COMPLETE	TATA spare parts
270531000166	FRAME ASSY WITH FITMENT	TATA spare parts
270531000167	FRAME ASSY WITH FITMENT	TATA spare parts
270531108201	FRONT EXTENSION L.MEMBER-RH LP407	TATA spare parts
270531108202	FRONT EXTENSION L.MEMBER-LH LP 407	TATA spare parts
270531108207	EXRT FRT LONG MEMBER RH	TATA spare parts
270531108208	EXRT FRT LONG MEMBER LH	TATA spare parts
270531200102	ASSY.SUPPORT L.H.(ENG.C.M.-REAR)	TATA spare parts
270531200103	ASSY.SUPPORT R.H.(ENG.C.M.REAR)	TATA spare parts
270531200104	ASSY.CROSS MEMBER-FRONT	TATA spare parts
270531207105	JOINT GUSSET PLATE-RH	TATA spare parts

270531207108	JOINT GUSSET PLATE-RH	TATA spare parts
270531207109	JOINT GUSSET PLATE -LH	TATA spare parts
270531207111	SUPPORT (ENG.MTG.CROSS MEMBER)	TATA spare parts
270531207116	SUPPORT (ENGINE C.M. -REAR)	TATA spare parts
270531208208	REINFORCEMENT (RH)	TATA spare parts
270531208209	REINFORCEMENT (LH)	TATA spare parts
270531208210	ENG.MTG.CROSS MEMBER	TATA spare parts
270531208212	PACKING PLATE	TATA spare parts
270531208214	REINFORCEMENT - RH (FSB REAR)	TATA spare parts
270531208215	REINFORCEMENT - LH (FSB REAR)	TATA spare parts
270531247101	PACKING PLATE BS6-PH2	TATA spare parts
270531400101	ASSY.CROSS MEMBER	TATA spare parts
270531400102	ASSY .REAR SPRING FRONT CROSS MEMBER-RHD	TATA spare parts
270531400109	ASSY.CENTRE BEARING CROSS MEMBER-RH	TATA spare parts
270531400112	ASSY.CENTRE BEARING CROSS MEMBER-LH	TATA spare parts
270531400113	ASSY.CENTRE BRG.CROSS MEMBER	TATA spare parts
270531400114	ASSY CROSS MEMBER	TATA spare parts
270531400115	ASSY. CENTRE BEARING CROSS MEMBER	TATA spare parts
270531400116	ASSY REINFORCEMENT -R.H. FRT SHOC ABS	TATA spare parts
270531400117	ASSY REINFORCEMENT -L.H.	TATA spare parts
270531400118	ASSY. CROSS MEMBER-REAR SPRING FRONT	TATA spare parts
270531400119	ASSY BRACKET (ENG-MTG) RH	TATA spare parts
270531400120	ASSY BRACKET (ENG-MTG) LH	TATA spare parts
270531400121	ASSY.REAR SHOCK ABSORBERC.M.	TATA spare parts
270531400122	ASSY. CENTRE BEARING CROSS MEMBER	TATA spare parts
270531400136	ASSY. CROSS MEMBER	TATA spare parts
270531400138	ASSY.REINFORCEMENT LH (CENTRE)	TATA spare parts
270531408207	GUSSET-R.H.	TATA spare parts
270531408208	GUSSET-L.H.	TATA spare parts
270531408215	GUARD (FOR PROP.SHAFT)	TATA spare parts
270531408221	CROSS MEMBER-RADIATOR MOUNTING	TATA spare parts
270531408257	REINFORCEMENT - RH	TATA spare parts
270531408258	REINFORCEMENT - LH	TATA spare parts
270531408260	REINFORCEMENT REAR - RH	TATA spare parts
270531408261	REINFORCEMENT REAR - LH	TATA spare parts
270531700104	ASSEMBLY BRACKET L.H.	TATA spare parts
270531700105	ASSEMBLY BRACKET R.H.	TATA spare parts
270531700106	ASSEMBLY TUBE 709-RUPD	TATA spare parts
270531700108	ASSY TUBE (RUPD)	TATA spare parts
270531700112	ASSY.RUPD	TATA spare parts
270531700114	ASSY.CHANNEL	TATA spare parts
270531700118	ASSY.BRACKET-LH	TATA spare parts
270531700119	ASSY.BRACKET - RH	TATA spare parts
270531707702	RUBBER CAP	TATA spare parts
270532100101	ASSY.BRACKET LH FRT.SPRG	TATA spare parts
270532100102	ASSY FRONT SPG BRACKETFRT-RH	TATA spare parts
270532100106	ASSY. FRONT SPRING-NORMAL CAMBER	TATA spare parts

270532100111	ASSY FRONT SPRING-HIGHER CAMBER	TATA spare parts
270532100112	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
270532100113	ASSY. FRONT SPRING (HIGHER CAMBER)	TATA spare parts
270532100119	ASSY. BUMP STOP BRACKET - RH	TATA spare parts
270532100120	ASSY. BUMP STOP BRACKET - LH	TATA spare parts
270532100125	ASSY. BRACKET - LH-FRONT SPRING HANGER	TATA spare parts
270532100126	ASSY. BRACKET - RH-FRONT SPRING HANGER	TATA spare parts
270532100130	ASSY. FRONT SRPRING-NORMAL CAMBER	TATA spare parts
270532100131	ASSY. FRONT SPRING-HIGHER CAMBER	TATA spare parts
270532100132	ASSY FIRST LEAF WITH BUSH(NORMAL CAMBER)	TATA spare parts
270532100132DF	MAIN LEAF FRONT W/BUSH-NORM CAMBER-SFC	TATA spare parts
270532100134	ASSY. FRONT SPRING (NORMAL CAMBER)	TATA spare parts
270532100135	ASSY. FRONT SPRING (HIGHER CAMBER)	TATA spare parts
270532100138	ASSY. FRONT SPRING(HIGHER CAMBER)	TATA spare parts
270532100140	ASSY. FRONT SPRING (NORMAL CAMBER)	TATA spare parts
270532100151	ASSY. LEAF SPRING FRONT (HIGHER CAMBER)	TATA spare parts
270532100152	ASSY. LEAF SPRING FRONT (NORMAL CAMBER)	TATA spare parts
270532100153	ASSY FIRST LEAF WITH BUSHES	TATA spare parts
270532100153DF	MAIN LEAF FRONT W/BUSH-LPT407/709/909/11	TATA spare parts
270532100154	ASSY FIRST LEAF WITH BUSHES	TATA spare parts
270532107120	SECOND LEAF	TATA spare parts
270532107121	THIRD LEAF	TATA spare parts
270532107122	FOURTH LEAF	TATA spare parts
270532107123	FIFTH LEAF	TATA spare parts
270532107124	SIXTH LEAF	TATA spare parts
270532107125	SEVENTH LEAF	TATA spare parts
270532107126	EIGHTH LEAF	TATA spare parts
270532107127	NINTH LEAF	TATA spare parts
270532107163	SECONT LEAF	TATA spare parts
270532107164	THIRD LEAF	TATA spare parts
270532107165	FOURTH LEAF	TATA spare parts
270532107166	FIFTH LEAF	TATA spare parts
270532107167	SIXTH LEAF	TATA spare parts
270532107168	SEVENTH LEAF	TATA spare parts
270532107169	EIGHTH LEAF	TATA spare parts
270532107170	NINTH LEAF	TATA spare parts
270532107171	TENTH LEAF	TATA spare parts
270532107172	ELENENTH LEAF	TATA spare parts
270532117132	SECOND LEAF	TATA spare parts
270532117132DF	SECOND LEAF FRONT-LPT407/709/909/1109	TATA spare parts
270532117133	THIRD LEAF	TATA spare parts
270532117133DF	THIRD LEAF FRONT-LPT407/709/909/1109	TATA spare parts
270532117134	FOURTH LEAF	TATA spare parts
270532117135	FIFTH LEAF	TATA spare parts
270532117135DF	FIFTH LEAF FRONT-LPT407/709/909/1109	TATA spare parts
270532117136	SIXTH LEAF	TATA spare parts
270532117137	SEVENTH LEAF	TATA spare parts

270532117138	EIGHTH LEAF	TATA spare parts
270532117139	NINETH LEAF	TATA spare parts
270532117140	TENTH LEAF	TATA spare parts
270532117142	SECOND LEAF	TATA spare parts
270532117143	THIRD LEAF	TATA spare parts
270532117144	FOURTH LEAF	TATA spare parts
270532117145	FIFTH LEAF	TATA spare parts
270532117146	SIXTH LEAF	TATA spare parts
270532117147	SEVENTH LEAF	TATA spare parts
270532117148	EIGHTH LEAF	TATA spare parts
270532117149	NINETH LEAF	TATA spare parts
270532117150	TENTH LEAF	TATA spare parts
270532200101	ASSY. GUIDE PLATE	TATA spare parts
270532200102	BUMP STOPPER ASSY BS6	TATA spare parts
270532203701	CASTER PLATE-2.6 DEG.	TATA spare parts
270532300101	BRKT-S/ABS MTG TOP LH LP	TATA spare parts
270532300102	BRKT-S/ABS MTG TOP RH LP	TATA spare parts
270532300103	ASSY. FRONT SHOCK ABS. MTG. BRACKET - LH	TATA spare parts
270532300104	ASSY. FRONT SHOCK ABS. MTG. BRACKET - RH	TATA spare parts
270532300105	SHOCK ABSORBER FRONT	TATA spare parts
270532400105	REAR SPRING LP 407	TATA spare parts
270532400107	ASSY RR SPRING BRACKET REAR LH	TATA spare parts
270532400108	ASSY RR SPRING BRACKET REAR RH	TATA spare parts
270532400109	ASSY SHACKLE REAR	TATA spare parts
270532400110	ASSY RR SPRING BRACKET FRONT LH	TATA spare parts
270532400111	ASSY RR SPRING BRACKET FRONT RH	TATA spare parts
270532400112	ASSY. REAR SPRING	TATA spare parts
270532400114	ASSY. BUMP STOP BRACKET	TATA spare parts
270532400119	ASSY.REAR SPRING BRACKET-(FRONT)-LH LP40	TATA spare parts
270532400120	ASSY.REAR SPRING BRACKET-(FRONT)-RH LP40	TATA spare parts
270532400121	ASSY.REAR SPRING BRACKET-(REAR)-LH LP407	TATA spare parts
270532400122	ASSY.REAR SPRING BRACKET-(REAR)-RH LP407	TATA spare parts
270532400123	ASSY REAR SPRING BRACKET - (FRONT)-LH	TATA spare parts
270532400124	ASSY REAR SPRING BRACKET - (FRONT)-RH	TATA spare parts
270532400130	ASSY BRACKET	TATA spare parts
270532400131	ASSY. REAR SPRING BRACKET FRONT LH	TATA spare parts
270532400132	ASSY. REAR SPRING BRACKET FRONT RH	TATA spare parts
270532400133	ASSY. REAR SPRING WITH AUX. SPRING	TATA spare parts
270532400134	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
270532403701	SUPPORT(REAR SPG ASSY WITH AUX SPG)	TATA spare parts
270532404204	SPRING CLIP	TATA spare parts
270532404207	SPRING CLIP REAR SPRING (AUX)	TATA spare parts
270532406701	SPRING PIN REAR	TATA spare parts
270532407119	LOCK PLATE	TATA spare parts
270532407150	SECOND LEAF	TATA spare parts
270532407151	THIRD LEAF	TATA spare parts
270532407152	FOURTH LEAF	TATA spare parts

270532407153	FIFTH LEAF	TATA spare parts
270532407154	SIXTH LEAF	TATA spare parts
270532407155	SEVENTH LEAF	TATA spare parts
270532407156	FIRST LEAF (AUX. SPRING)	TATA spare parts
270532407157	SECOND LEAF (AUX. SPRING)	TATA spare parts
270532407158	THIRD LEAF (AUX. SPRING)	TATA spare parts
270532407159	FOURTH LEAF (AUX. SPRING)	TATA spare parts
270532504202	U CLAMP REAR	TATA spare parts
270532600101	ASSY BRACKET SHOCK ABSORBER	TATA spare parts
270532608206	BRACKET RH REAR S/A BOTTOM	TATA spare parts
270532608207	BRACKET LH REAR S/A BOTTOM	TATA spare parts
270532800101	ASSY. BRACKET FRONT ARB MTG TOP-RH	TATA spare parts
270532800102	ASSY. BRACKET FRONT ARB MTG TOP-LH	TATA spare parts
270532900102	ASSY BRACKET REAR-ANTI ROLL BAR	TATA spare parts
270532900104	ASSY. ANTIROLL BAR REAR-WITH EYE	TATA spare parts
270532900107	ASSY ANTI ROLL BAR	TATA spare parts
270532900108	ASSY REAR ANTIROLL BAR WITH LINK	TATA spare parts
270532903201	HEX BOLT-ANTI ROLL BAR	TATA spare parts
270533000101	ASSY.FA.407 LP/LPT RHD	TATA spare parts
270533000105	ASSY.FRONT AXLE WITH BRAKES (NON ASBS.)	TATA spare parts
270533000106	ASSY FRONT AXLE LHD	TATA spare parts
270533000107	AXLE ASSY FRONT LP407	TATA spare parts
270533000108	ASSY.FRONT AXLE WITH BRAKES RHD(N/ASB)	TATA spare parts
270533000109	ASSY FRONT AXLE WITH BRAKES	TATA spare parts
270533000110	ASSY FRONT AXLE WITH BRAKES(N/ASBS)	TATA spare parts
270533000111	ASSY.FRONT AXLE WITH BRAKES	TATA spare parts
270533000112	ASSY FRONT AXLE WITH BRAKES	TATA spare parts
270533000117	ASSY.FRONT AXLE WITH BRAKES	TATA spare parts
270533000118	ASSY FRONT AXLE WITH BRAKES (LHD) (NON A	TATA spare parts
270533200107	ASSY. STUB AXLE NORMAL	TATA spare parts
270533400107	ASSY.HUB WITH PIN.	TATA spare parts
270533403701	FRT.BRAKE DRUM WITH HUB	TATA spare parts
270533403702	FRONT BRAKE DRUM WITH HUB	TATA spare parts
270533403703	FRONT HUB	TATA spare parts
270533403706	FRONT HUB	TATA spare parts
270533403723	BRAKE DRUM WITH HUB.	TATA spare parts
270533805101	STEERING ARM RHD	TATA spare parts
270533805102	STEERING ARM (LHD)	TATA spare parts
270533805105	STEERING ARM RHD	TATA spare parts
270540100105	WHEEL RIM 6 G X 16	TATA spare parts
270540100107	6.00GX16 WHEEL RIM	TATA spare parts
270540100108	WHEEL RIM (6GX16) LP 407 TWIN TYRE	TATA spare parts
270540100112	ASSY. WHEEL RIM BS2/3/4/6	TATA spare parts
270540100127	ASSY WHEEL RIM 6G X 16	TATA spare parts
270540106701	HUB PIN FRONT	TATA spare parts
270540106702	HUB PIN	TATA spare parts
270540106703	HUB PIN (REAR) 18X68	TATA spare parts



270540109902	TUBE	TATA spare parts
270540300101	ASSY.HANDLE	TATA spare parts
270540300104	ASSY.SPAREWHEELCARRIER	TATA spare parts
270541000101	ASSY PROP.SHAFT	TATA spare parts
270541000104	ASSY.UNITISED PROP.SHAFT 407 LPT 34	TATA spare parts
270541000105	ASSY.UNITISED PROP.SHAFT	TATA spare parts
270541000107	ASSY. UNITIZED PROP SHAFT	TATA spare parts
270541000108	ASSY UNITIZED PROP SHAFT	TATA spare parts
270541000114	ASSY.PROP SHAFT LPT 407	TATA spare parts
270541100105	FRONT PROP SHAFT ASSY	TATA spare parts
270541110101	ASSY.PROP.SHAFT WITH CENTRE BEARING.	TATA spare parts
270541110104	ASSY KIT FRONT PROP SHAFT LP407	TATA spare parts
270541110107	ASSY.PROP.SHAFT WITH CENT BRG 34 W B	TATA spare parts
270541120103	ASSY KIT REAR PROP SHAFT LP407	TATA spare parts
270541120104	KIT-UNIVERSAL JOINT BS2/3/4	TATA spare parts
270541120105	ASSY.PROPELLER SHAFT COMPLETE(REAR)	TATA spare parts
270541120108	ASSY.PROP.SHAFT(REAR)34 W B	TATA spare parts
270541120110	ASSY PROP SHAFT(REAR)62(LP410)	TATA spare parts
270541120111	ASSY REAR PROPELLER SHAFT COMPLETE	TATA spare parts
270541120117	ASSY. PROP. SHAFT (REAR)	TATA spare parts
270541120120	PROPELELR SHAFT ASSY DRIVE BS6	TATA spare parts
270541999901	SLIP YOKE BS6	TATA spare parts
270542010101	ASSY. VACCUM BOOSTER W/ TMC BS2/3/4	TATA spare parts
270542100107	ASSY. FRONT AXLE BRAKE LH	TATA spare parts
270542100108	ASSY. FRONT AXLE BRAKE RH	TATA spare parts
270542100113	ASSY FRONT AXLE BRAKE LH	TATA spare parts
270542100114	ASSY FRONT AXLE BRAKE RH	TATA spare parts
270542100132	ASSY ANCHOR PLATE FRONT-LH	TATA spare parts
270542100133	ASSY ANCHOR PLATE FRONT-RH	TATA spare parts
270542100136	ASSY ANCHOR PLATE FRONT WITH PLATE-LH	TATA spare parts
270542100137	ASSY ANCHOR PLATE FRONT WITH PLATE-RH	TATA spare parts
270542100138	ASSY ANCHOR PLATE FRONT WITH PLATE-LH	TATA spare parts
270542100139	ASSY ANCHOR PLATE FRONT WITH PLATE-RH	TATA spare parts
270542100154	ASSY FR AXLE BRK LH	TATA spare parts
270542100155	ASSY FR AXLE BRK RH	TATA spare parts
270542103701	FRONT BRAKE DRUM	TATA spare parts
270542103702	BRAKE DRUM WITH 308 DIA FOR EURO-III	TATA spare parts
270542103703	BRAKE DRUM 308 DIA. BS2/3/4	TATA spare parts
270542103704	BRAKE DRUM (LPT 407 4.4T PAYLOAD)	TATA spare parts
270542300107	407 ASSY.REAR AXLE BRAKE LH	TATA spare parts
270542300108	407 ASSY.REAR AXLE BRAKE RH	TATA spare parts
270542300130	ASSY REAR AXLE BRAKE LH.	TATA spare parts
270542300139	ASSY.R/A BRAKE LH W/O OIL CATCH-NON-ASB.	TATA spare parts
270542300140	ASSY.R/A BRAKE RH W/O OIL CATCH-NON-ASB.	TATA spare parts
270542300150	ASSY REAR AXLE BRAKE LH	TATA spare parts
270542300151	ASSY REAR AXLE BRAKE RH	TATA spare parts
270542300152	ASSY REAR AXLE BRAKE - LH (NON-ASB)	TATA spare parts

270542300153	ASSY REAR AXLE BRAKE - RH (NON-ASB)	TATA spare parts
270542300154	ASSY REAR AXLE BRAKE - LH (NON-ASB)	TATA spare parts
270542300155	ASSY REAR AXLE BRAKE - RH (NON-ASB)	TATA spare parts
270542300156	ASSY REAR AXLE BRAKE - LH (NON-ASB)	TATA spare parts
270542300157	ASSY REAR AXLE BRAKE - RH (NON-ASB)	TATA spare parts
270542300158	ASSY REAR AXLE BRAKE - LH (NON-ASB)	TATA spare parts
270542300159	ASSY REAR AXLE BRAKE - RH (NON-ASB)	TATA spare parts
270542300161	ASSY. REAR AXLE BRAKE-LH	TATA spare parts
270542300162	ASSY. REAR AXLE BRAKE-RH	TATA spare parts
270542308234	OIL CATCHER.	TATA spare parts
270542400101	ASSY LCRV & LINKAGE	TATA spare parts
270542400120	ASSY BRACKET L.C.R.V. MOUNTING	TATA spare parts
270542400125	ASSY. BRACKET(ANTI ROLL BAR & LCRV MTG.)	TATA spare parts
270542400126	ASSY. BRACKET(ARB & LCRV LOWER LINK MTG)	TATA spare parts
270542400127	ASSY BRACKET (L.C.R.V. LOWER LINK AND AR	TATA spare parts
270542400128	ASSY BRACKET (L.C.R.V. MOUNTING)	TATA spare parts
270542700103	ASSY.CABLE CENTRE	TATA spare parts
270542700104	ASSY.CABLE FRT.	TATA spare parts
270542700105	ASSY. PARKING BRAKE CABLE REAR	TATA spare parts
270542700107	ASSY.PARKING BRAKE CABLE FRONT	TATA spare parts
270542700108	ASSY.PARKING BRAKE CABLE CENTRE	TATA spare parts
270542700109	ASSY. PARKING BRAKE CABLE REAR	TATA spare parts
270542700110	ASSY. CABLE FRONT	TATA spare parts
270542700114	ASSY. CABLE CENTER	TATA spare parts
270542700115	ASSY.PARKING BRAKE CABLE FRONT	TATA spare parts
270542700116	ASSY. CABLE FRONT	TATA spare parts
270542700117	ASSY. PARKING BRAKE CABLE REAR	TATA spare parts
270542700122	ASSY. PARKING BRAKE CABLE FRONT	TATA spare parts
270542700124	PARKING BRAKE CABLE REAR	TATA spare parts
270542700133	ASSY CABLE FRONT	TATA spare parts
270542700134	ASSY CABLE CENTRE	TATA spare parts
270542700135	ASSY PARKING CABLE CENTRE	TATA spare parts
270542700136	ASSY CABLE CENTRE	TATA spare parts
270542700146	ASSY. CABLE CENTRE	TATA spare parts
270542700149	ASSY.PARKING BRAKE CABLE	TATA spare parts
270542700150	ASSY BRACKET (REAR CABLE)	TATA spare parts
270542700151	ASSY. BRACKET (FRONT CABLE)	TATA spare parts
270542700153	ASSY PARKING BRAKE CABLE FRONT	TATA spare parts
270542700155	ASSY BRACKET (LEVER MTG.)	TATA spare parts
270542700160	ASSY CENTRE CABLE	TATA spare parts
270542700161	ASSY REAR PARKING BRAKE CABLE	TATA spare parts
270542700165	ASSY FRONT PARKING BRAKE CABLE	TATA spare parts
270542700169	ASSY LEVER (PARKING BRAKE)	TATA spare parts
270542700170	PARKING BRAKE CABLE CENTRE (L=635)	TATA spare parts
270542700179	ASSY PARKING BRAKE UNIT	TATA spare parts
270542700185	ASSY FRONT PARKING BRAKE CABLE	TATA spare parts
270542700188	ASSY PARKING BRAKE UNIT (RHD)	TATA spare parts

270542700192	ASSY PARKING BRAKE LEVER MTG BKT BS6	TATA spare parts
270542700194	ASSY FRONT PARKING BRAKE CABLE	TATA spare parts
270542706701	PIN	TATA spare parts
270542800106	ASSY.PIPE	TATA spare parts
270542800107	ASSY.TUBE.	TATA spare parts
270542800111	ASSY.TUBE	TATA spare parts
270542800112	ASSY.TUBE	TATA spare parts
270542800113	ASSY.TUBE	TATA spare parts
270542800115	ASSY.TUBE	TATA spare parts
270542800125	ASSY.TUBE	TATA spare parts
270542800130	ASSY. TUBE	TATA spare parts
270542800141	ASSY.TUBE	TATA spare parts
270542800142	ASSY.TUBE	TATA spare parts
270542800143	ASSY.TUBE	TATA spare parts
270542800144	ASSY.TUBE	TATA spare parts
270542800145	ASSY.TUBE	TATA spare parts
270542800147	ASSY.TUBE	TATA spare parts
270542800148	ASSY.TUBE	TATA spare parts
270542800149	ASSY.TUBE	TATA spare parts
270542800150	ASSY.TUBE	TATA spare parts
270542800167	ASSY.TUBE	TATA spare parts
270542800169	ASSY.TUBE	TATA spare parts
270542800170	ASSY.TUBE	TATA spare parts
270542800189	ASSY.TUBE	TATA spare parts
270542800191	ASSY.TUBE	TATA spare parts
270542800192	ASSY.TUBE	TATA spare parts
270542800194	ASSY.TUBE	TATA spare parts
270542800195	ASSY.TUBE	TATA spare parts
270542800198	ASSY.TUBE (6 DIA.)	TATA spare parts
270542803302	BRACKET(FRT HOSE MTG)-ANCHOR PLATE ASSY.	TATA spare parts
270542803303	BRACKET BS6	TATA spare parts
270542805801	RUBBER HOSE	TATA spare parts
270542806001	LEVER	TATA spare parts
270542810101	ASSY.TUBE	TATA spare parts
270542810103	ASSY.TUBE	TATA spare parts
270542810104	ASSY.TUBE	TATA spare parts
270542810105	ASSY.TUBE	TATA spare parts
270542810106	ASSY.TUBE	TATA spare parts
270542810107	ASSY.TUBE	TATA spare parts
270542810108	ASSY.TUBE	TATA spare parts
270542810109	ASSY.TUBE	TATA spare parts
270542810110	ASSY.TUBE	TATA spare parts
270542810122	ASSY.TUBE	TATA spare parts
270542810123	ASSY.TUBE	TATA spare parts
270542810131	ASSY.TUBE	TATA spare parts
270542810134	ASSY.TUBE	TATA spare parts
270542810135	ASSY.TUBE	TATA spare parts

270542810136	ASSY.TUBE	TATA spare parts
270542810142	ASSY TUBE	TATA spare parts
270542810143	ASSY.TUBE	TATA spare parts
270543100101	ASSY. TENDEM MASTER CYL 25.4 DIA BS2/3/4	TATA spare parts
270543100103	ASSY. MASTER CYLINDER (AL) 23.81	TATA spare parts
270543500101	ASSY. TENDEM BOOSTER 9 +8 BS2/3/4	TATA spare parts
270543500120	MAJOR KIT-MASTER CYLINDER	TATA spare parts
270543500121	MINOR KIT-MASTER CYLINDER	TATA spare parts
270543800111	ASSY TUBE	TATA spare parts
270543800112	ASSY TUBE	TATA spare parts
270543800115	ASSY TUBE	TATA spare parts
270543800116	ASSY.TUBE	TATA spare parts
270543800122	ASSY TUBE	TATA spare parts
270543800123	ASSY.TUBE	TATA spare parts
270543800124	ASSY.TUBE	TATA spare parts
270543800125	ASSY.TUBE	TATA spare parts
270543800126	ASSY.TUBE	TATA spare parts
270543800127	ASSY TUBE	TATA spare parts
270543800128	ASSY TUBE	TATA spare parts
270543800129	ASSY.TUBE	TATA spare parts
270543800130	ASSY.TUBE	TATA spare parts
270543800131	ASSY.TUBE	TATA spare parts
270543800134	ASSY TUBE	TATA spare parts
270543800135	ASSY TUBE	TATA spare parts
270543800137	ASSY.TUBE	TATA spare parts
270543800138	ASSY.TUBE	TATA spare parts
270543800139	ASSY.TUBE	TATA spare parts
270543800140	ASSY.TUBE	TATA spare parts
270543800141	ASSY.TUBE	TATA spare parts
270543800142	ASSY.TUBE	TATA spare parts
270543800170	ASSY TUBE	TATA spare parts
270543800172	ASSY TUBE	TATA spare parts
270543800173	ASSY TUBE (VACUUM LINE FROM FIRE WALL)	TATA spare parts
270543800180	TUBE (4 WAY UNION TO VAC TANK)	TATA spare parts
270543800183	ASSY TUBE 6X0.7 THK SS:4040-20	TATA spare parts
270543800186	TUBE ASSY ADAPTER TO VACUUM HOSE	TATA spare parts
270543800188	ASSY TUBE (PRIMARY PORT TO ADAPTOR)	TATA spare parts
270543800189	ASSY TUBE	TATA spare parts
270543800190	ASSY TUBE	TATA spare parts
270543800192	ASSY TUBE (ADAPTOR TO T-CONNECTOR)	TATA spare parts
270543800194	ASSY TUBE (LCRV TO HOSE)	TATA spare parts
270543800195	ASSY TUBE	TATA spare parts
270543800196	ASSY TUBE (4 WAY TO T-CONNECTOR)	TATA spare parts
270543800197	ASSY TUBE (T-TO SOLONOIDE VALVE)	TATA spare parts
270543800198	ASSY TUBE (VALVE TO VACUUM TANK)	TATA spare parts
270543800199	ASSY TUBE ((T- TO ENG STOP HOSE)	TATA spare parts
270543808205	BRACKET FOR TEE CONNECTOR MTG	TATA spare parts

270543808207	BRKE PIPE LINES MTG BKT	TATA spare parts
270543808211	BRACKET FOR BRAKE PIPE (ON FRAME)	TATA spare parts
270543808220	BRACKET FOR FIRE WALL MTG PIPE	TATA spare parts
270543810101	ASSY TUBE (VACUUM PIPE FROM BOOSTER)	TATA spare parts
270543810102	ASSY TUBE (TMC PRIMARY TO TEE)	TATA spare parts
270543810103	ASSY TUBE	TATA spare parts
270543810106	ASSY TUBE (FR TEE TO RH)	TATA spare parts
270543810107	ASSY TUBE (FR TEE TO LH)	TATA spare parts
270543810109	ASSY TUBE (4 WAY TO VACUUM TANK)	TATA spare parts
270543810110	ASSY VACUUM LINE TUBE	TATA spare parts
270543810111	ASSY TUBE (TMC SEC. TO FIRE WALL)	TATA spare parts
270543810112	ASSY TUBE (TMC PRIMARY TO FIRE WALL)	TATA spare parts
270543810113	ASSY TUBE(T-CONNECTOR TO FRONT LH)	TATA spare parts
270543810114	ASSY TUBE (PARTITION BKT TO REAR ADAPTOR	TATA spare parts
270543810115	ASSY TUBE (FOUR WAY TO VACUUM TANK)	TATA spare parts
270543810120	ASSY TUBE (PARTITION BKT TO FOUR WAY)	TATA spare parts
270543810121	ASSY. TUBE (FOUR WAY TO MAG. VALVE)	TATA spare parts
270546200101	S/G BOX MTG BRKT RH LP407	TATA spare parts
270546200104	ASSY STG GEAR BOX MTG BRACKET-LHD	TATA spare parts
270546305101	PITMAN ARM RHD	TATA spare parts
270546305102	PITMAN ARM RH LP 407	TATA spare parts
270546305107	PITMAN ARM-RHD	TATA spare parts
270546305108	PITMAN ARM-LHD	TATA spare parts
270546305110	PITMAN ARM (LHD)	TATA spare parts
270546400101	ASSY STEERING WHEEL DIA 426-BLACK	TATA spare parts
270546600101	DRAG LINK RHD LP 407	TATA spare parts
270546600102	ASSY DRAG LINK	TATA spare parts
270546600105	ASSY DRAG LINK	TATA spare parts
270546600112	ASSY DRAG LINK -RHD	TATA spare parts
270546600113	ASSY DRAG LINK-LHD	TATA spare parts
270546600114	ASSY DRAG LINK COST REDN.	TATA spare parts
270546600115	ASSY.DRAG LINK-RHD-ADJUSTABLE	TATA spare parts
270546600116	DRAG LINK ASSY	TATA spare parts
270546600122	ASSY. DRAG LINK (RHD) GREASELESS BS2/3/4	TATA spare parts
270546600159	COVER ASSY	TATA spare parts
270546600160	CAP ASSY	TATA spare parts
270546600171	KIT-SEALING	TATA spare parts
270546600172	POWER STEERING PUMP ASSY	TATA spare parts
270546600173	KIT-HOUSING ASSY	TATA spare parts
270546606801	CONNECTOR PRESSURE PORT	TATA spare parts
270546607901	SHAFT	TATA spare parts
270546608801	STUD	TATA spare parts
270546800101	ASSY TUBE (TANK TO PUMP)	TATA spare parts
270546800103	ASSY TUBE (TANK TO PUMP)	TATA spare parts
270546800113	ASSY.TUBE	TATA spare parts
270546800115	ASSY.TUBE	TATA spare parts
270546800118	ASSY. TUBE.	TATA spare parts

270546800125	ASSY TUBE(RESERVOIR TO PUMP)	TATA spare parts
270546800126	ASSY. HYD. PIPE (PUMP TO STRG. GEAR BOX)	TATA spare parts
270546800133	ASSY PRESSURE LINE-CRIMPED(PUMP TO GB)	TATA spare parts
270546800136	ASSY.VANE PUMP	TATA spare parts
270546800139	ASSY SUCTION LINE-CRIMPED (RESERVOIR TO	TATA spare parts
270546800142	ASSY PIPE SUCTION LINE (RESERVIOR TO PUM	TATA spare parts
270546800143	ASSY PIPE PRESSURE LINE PUMP TO G. BOX	TATA spare parts
270546800144	ASSY SUCTION LINE (RESERVOIR TO PUMP)	TATA spare parts
270546800146	ASSY RETURN LINE (GEAR BOX TO RESERVIOR)	TATA spare parts
270546800147	ASSY STRG OIL RESERVIOR-INCREASED VOL	TATA spare parts
270546800151	ASSY PIPE PRESSURE LINE	TATA spare parts
270546800153	SUCTION LINE ASSY	TATA spare parts
270546800154	PRESSURE LINE ASSY	TATA spare parts
270546800155	RETURN LINE ASSY	TATA spare parts
270546805801	RUBBER HOSE	TATA spare parts
270546900101	END ASSY RH	TATA spare parts
270546900102	ASSY. BALL JOINT END RH BS2/3/4	TATA spare parts
270546900104	DRAG LINK END ASSY	TATA spare parts
270547000127	ASSY.FUEL TANK COMPLETE WITH MNTG BKT.	TATA spare parts
270547100106	ASSY. BRACKET-LPR AND SOLENOIDS MTG.	TATA spare parts
270547100107	ASSY. BRACKET-HPR MOUNTING	TATA spare parts
270547100113	ASSY. PLATE-FRONT ARRESTOR	TATA spare parts
270547100114	ASSY. BKT. REAR ARRESTOR - LH	TATA spare parts
270547100115	ASSY.BRACKET-GAS SHUT OFF MTG	TATA spare parts
270547100117	ASSY. BRACKET-RH	TATA spare parts
270547100118	ASSY. BRACKET-LH	TATA spare parts
270547100186	ASSY.BRACKET (LPR MOUNTING)	TATA spare parts
270547100187	ASSY BRACKET FCV	TATA spare parts
270547103201	SPECIAL SCREW	TATA spare parts
270547106901	TUBE	TATA spare parts
270547108209	COMPLIANCE PLATE	TATA spare parts
270547108215	HOLDING BRACKET GAS SHUT OFF VALVE	TATA spare parts
270547109903	CNG CYLINDER 90LIT 316 DIA	TATA spare parts
270547109904	CNG CYLINDER 50LT 267 OD.	TATA spare parts
270547109905	CNG CYLINDER	TATA spare parts
270547109906	CNG CYLINDER	TATA spare parts
270547109907	CNG CYLINDER 406DIA 90 LTRS	TATA spare parts
270547109908	CNG CYLINDER 406 DIA.¿ (90 LTRS) FRONT	TATA spare parts
270547109909	CNG CYLINDER 356 DIA. RAMA (65 LTRS)	TATA spare parts
270547109910	CNG CYLINDER 356 DIA.¿ (65 LTRS) REAR	TATA spare parts
270547109913	CNG CYLINDER ( DIA.406 120 LITERS)	TATA spare parts
270547109919	CYLINDER	TATA spare parts
270547109920	CYLINDER BS6	TATA spare parts
270547200101	ASSY. HEAT SHIELD R.H.	TATA spare parts
270547200102	ASSY.HEATSHIELD.(LH).	TATA spare parts
270547208203	BRACKET-HEAT SHIELD	TATA spare parts
270547208204	BRACKET-HEAT SHIELD	TATA spare parts

270547208205	BRACKET-HEAT SHIELD	TATA spare parts
270547500111	ASSY.BRACKET (RECEPTACLE MTG.)	TATA spare parts
270547500134	ASSY. SUPPORT U BOLT	TATA spare parts
270547500144	ASSY STRAP	TATA spare parts
270547500145	ASSY RECT BOX	TATA spare parts
270547500152	ASSY BOX LH	TATA spare parts
270547500155	ASSY STUD	TATA spare parts
270547500157	ASSY CAGE RH	TATA spare parts
270547500158	ASSY CAGE LH	TATA spare parts
270547500159	ASSY.BOX SLOW FILLING RECEPTACLE MTG.	TATA spare parts
270547500160	ASSY STRAP	TATA spare parts
270547500161	ASSEMBLY BRACKET	TATA spare parts
270547500162	ASSEMBLY BRACKET	TATA spare parts
270547500164	ASSY. BOX-RH	TATA spare parts
270547500165	ASSY STUD	TATA spare parts
270547500167	ASSY.BOX-LH	TATA spare parts
270547500170	ASSY BRACKET-RECEPTACLE MTG.	TATA spare parts
270547500173	ASSY. BOX	TATA spare parts
270547500174	ASSY BOX RH	TATA spare parts
270547500175	ASSY.STUD	TATA spare parts
270547500176	ASSY SUPPORT	TATA spare parts
270547500180	ASSY. BRACKET-RECEPTACLE	TATA spare parts
270547500185	ASSY.BRACKET-GAS LOCK OFF VALVE MOUNTING	TATA spare parts
270547500187	BRACKET ASSY CYLINDER MTG BS6	TATA spare parts
270547500191	ASSY.BRACKET WITH RUBBER (CYL.MTG.FRONT)	TATA spare parts
270547500193	ASSY.BRACKET WITH RUBBER (CYL.MTG.REAR)	TATA spare parts
270547500196	ASSY.STRAP WITH RUBBER (CYL.MTG.FRONT)	TATA spare parts
270547500199	ASSY. STRAP WITH RUBBER (CYL.MTG.REAR)	TATA spare parts
270547503201	U CLAMP	TATA spare parts
270547503501	BUSH (FOR WEH RECEPTACLE)	TATA spare parts
270547504201	CLAMP-HIGH PR. REGULATOR MTG.	TATA spare parts
270547506101	LOCK WASHER	TATA spare parts
270547506102	LOCK WASHER	TATA spare parts
270547507616	TIE MEMBER	TATA spare parts
270547507617	TIE MEMBER	TATA spare parts
270547507619	TIE MEMBER	TATA spare parts
270547507620	TIE MEMBER	TATA spare parts
270547507701	BALATTA PACKING	TATA spare parts
270547507714	BALATTA PACKING	TATA spare parts
270547507727	RUBBER PACKING BS6	TATA spare parts
270547507729	RUBBER PACKING BS6	TATA spare parts
270547507730	RUBBER PACKING BS6	TATA spare parts
270547508209	BRACKET	TATA spare parts
270547508216	BRACKET- HP FILTER MTG	TATA spare parts
270547508252	BEND PLATE	TATA spare parts
270547508267	BRACKET-FILTER MTG.	TATA spare parts
270547508275	PACKING BEND PLATE	TATA spare parts

270547508276	PACKING PLATE	TATA spare parts
270547508280	BRACKET -RH	TATA spare parts
270547508281	BRACKET -LH	TATA spare parts
270547508297	BRACKET (PIPE CLAMP MTG.)	TATA spare parts
270547509901	DECAL (THREE WAY VALVE)	TATA spare parts
270547510109	ASSY. REAR ARRESTOR	TATA spare parts
270547510113	ASSY. ARRESTOR -RH (FRONT CYLINDER)	TATA spare parts
270547510114	ASSY. ARRESTOR -LH (FRONT CYLINDER)	TATA spare parts
270547510115	ASSY.ARRESTOR -RH (REAR CYLINDER)	TATA spare parts
270547510116	ASSY. ARRESTOR - LH (REAR CYLINDER)	TATA spare parts
270547510121	ASSY. HEAT SHIELD - LH	TATA spare parts
270547510122	ASSY.BRACKET (HP SOLENOID & HP SENSOR)	TATA spare parts
270547510135	ASSY.COVERING DISC(FOR RECEPTACLE - OPW)	TATA spare parts
270547510139	ASSY.CONTROL PANEL	TATA spare parts
270547518213	BASE PLATE (REAR ARRESTOR) BS6	TATA spare parts
270547600110	ASSY. VALVE	TATA spare parts
270547600121	ASSY.SUCTION LINE-TANK TO W/SEP (NYLON)	TATA spare parts
270547600122	ASSY.RETURN LINE (NYLON)	TATA spare parts
270547600125	ASSY.SUCTION LINE (W/S TO TANK)NYLON	TATA spare parts
270547600126	ASSY.RETURN LINE (NYLON)	TATA spare parts
270547600130	ASSY HOSE-FOR HEATING CIRCUIT	TATA spare parts
270547600131	ASSY. HOSE-HPR TO GAS SHUT OFF	TATA spare parts
270547600132	ASSY. HOSE-GAS SHUT OFF TO LPR.	TATA spare parts
270547600133	ASSY. SUCTION LINE(TANK TO STRAINER)	TATA spare parts
270547600135	ASSY. GAS PIPE 1/4INCH OD.	TATA spare parts
270547600136	ASSY. GAS PIPE 1/4INCH OD	TATA spare parts
270547600138	ASSY. GAS PIPE 1/4INCH OD	TATA spare parts
270547600139	ASSY. GAS PIPE 1/4INCH OD	TATA spare parts
270547600140	ASSY. GAS PIPE 1/4 INCH OD.	TATA spare parts
270547600141	ASSY. GAS PIPE 1/4INCH OD.	TATA spare parts
270547600145	ASSY. HOSE-HPR TO GAS SHUT OFF VALVE	TATA spare parts
270547600146	ASSY.HOSE FOR HEATING CIRCUIT	TATA spare parts
270547600152	ASSY.SUCTION LINE (HOSE TO INTAKE)	TATA spare parts
270547600153	ASSY.SUCTION LINE (W/SEP.TO HOSE)	TATA spare parts
270547600154	ASSY.RETURN PIPE	TATA spare parts
270547600161	HP TUBE ASSY WITH PVC SLEEVE	TATA spare parts
270547600165	ASSY.SUCTION LINE (NYLON) LPT 407EX(3.4T	TATA spare parts
270547600174	ASSY. FUEL LINE(FUEL TANK TO W.SEP)	TATA spare parts
270547600175	ASSY FUEL LINE (W.SEP TO ENGINE)	TATA spare parts
270547600176	ASSY FUEL LINE (RETURN).	TATA spare parts
270547600184	ASSY SUCTION LINE ( W/SEP TO ENGINE)	TATA spare parts
270547600185	ASSY RETURN LINE	TATA spare parts
270547605801	RUBBER TUBE GREEN	TATA spare parts
270547605802	RUBBER HOSE	TATA spare parts
270547605835	HOSE	TATA spare parts
270547605836	HOSE	TATA spare parts
270547605837	HOSE	TATA spare parts



270547605838	HOSE(1500 L.)	TATA spare parts
270547605840	HOSE PIPE (1750 L.)	TATA spare parts
270547606810	COUPLING NUT	TATA spare parts
270547606811	CONNECTOR	TATA spare parts
270547606812	ELBOW-LPR OUTLET	TATA spare parts
270547606813	CONNECTOR-GAS SHUT OFF VALVE INLET	TATA spare parts
270547606814	HEX.NUT	TATA spare parts
270547606817	FEMALE CONNECTOR 1/4 INCH INCH OD X 1/2	TATA spare parts
270547608207	BRACKET (WATER SEP.)	TATA spare parts
270547608212	BRACKET PRE FILTER MTG	TATA spare parts
270547608601	SPACER BS6	TATA spare parts
270547609901	NIPPLE	TATA spare parts
270547610102	ASSY VALVE(BURSTING DISC & FUSIBLE VALVE	TATA spare parts
270547610103	ASSY.LOW PRESSURE HOSE	TATA spare parts
270547610104	ASSY.TUBE (FOR CNG VENTING)	TATA spare parts
270547610107	GAS HOSE (LPR - MIXER)	TATA spare parts
270547610108	GAS HOSE	TATA spare parts
270547610120	ASSY SUCTION LINE(FUEL TANK TO W/SEP)	TATA spare parts
270547610122	ASSY RETURN LINE	TATA spare parts
270547610127	ASSY. RETURN LINE	TATA spare parts
270547610129	ASSY.SUCTION LINE (TANK TO STRAINER)	TATA spare parts
270547610130	ASSY.SUCTION LINE (STRNR TO FEED PUMP)	TATA spare parts
270547610132	ASSY.SUCTION LINE (TANK TO STRAINER)	TATA spare parts
270547610133	ASSY.SUCTION LINE (STRAINER TO MECH.FEED	TATA spare parts
270547610134	ASSY.RETURN LINE (OVERFLOW TO TANK)	TATA spare parts
270547610135	ASSY.SUCTION LINE (STRAINER TO FUEL FILT	TATA spare parts
270547610138	ASSY. RETURN LINE (OVERFLOW TO TANK)	TATA spare parts
270547610140	ASSY. FUEL LINE (TANK TO W/S)	TATA spare parts
270547610141	ASSY. FUEL LINE W/S TO ENGINE	TATA spare parts
270547610142	ASSY. RETURN LINE	TATA spare parts
270547610144	ASSY.SUCTION LINE (FUEL TANK TO W/SEP)	TATA spare parts
270547610145	ASSY.RETURN LINE(OVERFLOW TO TANK)	TATA spare parts
270547610146	ASSY.FUEL LINE (W/SEP TO ENGINE)	TATA spare parts
270547610147	ASSY.SUCTIO LINE (W/SEP TO MECH. FIP)	TATA spare parts
270547610148	FUEL SUCTION PIPE ASSY	TATA spare parts
270547610149	FUEL RETURN PIPE ASSY	TATA spare parts
270547610150	FUEL SUCTION PIPE ASSY TANK TO PRE	TATA spare parts
270547610151	FUEL SUCTION PIPE ASSY PRE TO FINAL	TATA spare parts
270547610152	FUEL SUCTION PIPE ASSY F.FILTER TO FIP	TATA spare parts
270547700103	ASSY HIGH PR REGULATOR	TATA spare parts
270547700108	ASSY.THREE WAY VALVE	TATA spare parts
270547700113	ASSY. NGV RECEPTACLE	TATA spare parts
270547800118	ASSY HP CNG PIPE-1(FRT.RH TO FRT.LH CYL)	TATA spare parts
270547800119	ASSY HP CNG PIPE-2(FRT.RH TO FRT.LH CYLN	TATA spare parts
270547800121	ASSY HP CNG PIPE-2(FRT.RH TO REAR RH CYL	TATA spare parts
270547800123	ASSY HP CNG PIPE(REAR RH TO REAR LH CYLN	TATA spare parts
270547800125	ASSY.HP CNG PIPE-2(3 WAY TO FRT.RH CYL.)	TATA spare parts

270547800130	ASSY.VENT.PIPE-1(REAR RH CYL.TO REAR END	TATA spare parts
270547800131	ASSY.VENT.PIPE-1(REAR LH CYL.TO REAR END	TATA spare parts
270547800132	ASSY.VENT.PIPE-2(FRT.RH TO REAR RH CYL.)	TATA spare parts
270547800133	ASSY.VENT.PIPE-2(REAR RH CYL.TO REAR END	TATA spare parts
270547800134	ASSY VENT.PIPE(REAR RH TO REAR LH CYL.)	TATA spare parts
270547800135	ASSY.VENT.PIPE (REAR LH CYL.TO REAR END)	TATA spare parts
270547800137	ASSY.VENTING.PIPE-2 (REGULATOR TO EQUAL	TATA spare parts
270547800138	ASSY.VENT.PIPE (FRT.RH CYL.TO EQUAL CROS	TATA spare parts
270547800139	ASSY.VENTING.PIPE -1 (FROM EQUAL CROSS B	TATA spare parts
270547800140	ASSY.VENTING PIPE -2 (FROM EQUAL CROSS B	TATA spare parts
270547800141	ASSY.VENT.PIPE-1(FROM EQUAL CROSS BODY T	TATA spare parts
270547800143	ASSY.VENTING PIPE (EQUAL TEE TO LOAD BOD	TATA spare parts
270547800155	ASSY HP CNG PIPE(HP SENSOR TO HP SOLENOI	TATA spare parts
270547800156	ASSY HP CNG PIPE(HP SOLENOID-2 TO HPR)	TATA spare parts
270547800157	ASSY VENTING PIPE (HPR TO EQUAL TEE)	TATA spare parts
270547800158	ASSY.VENTING PIPE (T-CONNECTOR TO FRT.RH	TATA spare parts
270547800165	ASSY HP CNG PIPE (RECEPTACLE TO THREE WA	TATA spare parts
270547800166	ASSY HP CNG PIPE-1(3 WAY TO RH FRT.CYL.)	TATA spare parts
270547800167	ASSY HP CNG PIPE (3 WAY VALVE TO HP GAUG	TATA spare parts
270547800168	ASSY HP CNG PIPE (THREE WAY VALVE TO HP	TATA spare parts
270547800169	ASSY HP CNG PIPE(HP FILTER TO SOLENOID)	TATA spare parts
270547800170	ASSY HP CNG PIPE (HP SOLENOID TO HP SENS	TATA spare parts
270549100101	ASSEMBLY SILENCER-FLANGE TYPE-50.8 DIA	TATA spare parts
270549100105	ASSY. SILENCER WITH TAIL PIPE	TATA spare parts
270549200104	ASSY EXHAUST PIPE REAR	TATA spare parts
270549200109	ASSY BRACKET	TATA spare parts
270549200110	ASSY EXHAUST PIPE FRONT	TATA spare parts
270549200112	ASSY.PIPE (INTERMEDIATE)	TATA spare parts
270549200119	ASSY.EXHAUST PIPE (REAR END)	TATA spare parts
270549200122	ASSY.FRONT PIPE (LPT 508)	TATA spare parts
270549200123	ASSY.INTERMEDIATE PIPE (LPT 508)	TATA spare parts
270549200124	ASSY.EXHAUST PIPE FRONT-LP407-CNG	TATA spare parts
270549200127	ASSY.EXHAUST PIPE REAR	TATA spare parts
270549200128	ASSY.BRACKET CAT-CONVERTOR MTG.	TATA spare parts
270549200130	ASSY.BRACKET-TAIL PIPE MTG.	TATA spare parts
270549200131	ASSY.BRACKET-CAT-CONVERTOR MTG.	TATA spare parts
270549200132	ASSY.BRACKET-TAIL PIPE MTG.	TATA spare parts
270549200137	ASSY.FRONT EXHAUST PIPE	TATA spare parts
270549200138	ASSY.REDUCER	TATA spare parts
270549200139	ASSY.NOISE SHIELD BOTTOM (FRONT)	TATA spare parts
270549200143	ASSY.FRONT EXHAUST PIPE WITH FLEX.BELLOW	TATA spare parts
270549200144	ASSY .REDUCER.	TATA spare parts
270549200145	ASSY.EXHAUST FRONT PIPE.	TATA spare parts
270549200154	ASSY FRT.EXH.PIPE WITH FLEX.BELOW	TATA spare parts
270549200161	ASS. FRONT EXHAUST PIPE	TATA spare parts
270549200172	ASSY.FRONT EXHAUST PIPE (WITH FLEXIBLE B	TATA spare parts
270549200174	ASSY. INTERMEDIATE PIPE (WITH BOSS)	TATA spare parts

270549200177	ASSY. EXHAUST PIPE WITH FLEX BELLOW	TATA spare parts
270549200178	ASSY. BRACKET (SILENCER MTG. TOP)	TATA spare parts
270549203307	BRACKET-SILENCER MTG.	TATA spare parts
270549210108	ASSY. FRONT EXHAUST PIPE	TATA spare parts
270554100102	ASSY BATTERY TRAY	TATA spare parts
270554100107	ASSY.BATTERY CABLE--VE-1.7 LG	TATA spare parts
270554100108	ASSY.BATTERY CABLE+VE 1.85 LG	TATA spare parts
270554100111	ASSY.BATT.CABLE +VE [1.31 LG]	TATA spare parts
270554100113	ASSY.SUPPORT	TATA spare parts
270554100117	ASSY.EARTHING CHAIN WITH BRT.-LP 407 CNG	TATA spare parts
270554100130	ASSY.CU.BATT.CABLE +VE - LPT 407 CNG	TATA spare parts
270554100132	ASSY BATT.CABLE(+VE) 1.6LG LPT407EX-3.T	TATA spare parts
270554100133	ASSY BATT.CABLE(-VE) 2.03LG LPT407EX3.4T	TATA spare parts
270554100135	ASSY.EARTHING CHAIN-WITH MTG.BKT-407CNG	TATA spare parts
270554100136	ASSY.BATT.CARRIER	TATA spare parts
270554100141	EARTHING CABLE (CAB EARTH)400MM BS4	TATA spare parts
270554100142	ASSY BATT CABLE +VE W/COT 35 SQM (BATT +	TATA spare parts
270554100143	ASSY BATT CABLE -VE W/COT 35 SQM (BATT -	TATA spare parts
270554100193	ASSY. BATTERY CARRIER	TATA spare parts
270554100194	ASSY. TRAY	TATA spare parts
270554100196	ASSY.BOTTOM PLATE WITH STUD (75AH)	TATA spare parts
270554100198	ASSY.SIDE BKT.RH WITH NUT	TATA spare parts
270554100199	ASSY.SIDE BKT.LH WITH NUT	TATA spare parts
270554100201	ASSY BATTERY CABLE +VE 1000 MM	TATA spare parts
270554100202	ASSY BATTERY CABLE -VE 3050MM	TATA spare parts
270554100203	ASSY BATTERY CABLE +VE1400MM 35 SQMM	TATA spare parts
270554100204	ASSY.BATTERY CABLE -VE1400MM;35 SQ.MM	TATA spare parts
270554101601	EARTHING CABLE (CAB EARTH) 400MM	TATA spare parts
270554108234	L-CLAMP BATTERY SUPPORT 90MM(LPK407) BS6	TATA spare parts
270554108252	BEND STUD	TATA spare parts
270554108253	LOCATING PIN BS6	TATA spare parts
270554108255	CLAMP STRAP 75AMP	TATA spare parts
270554110101	ASSY.BATT.CABLE -VE W/CORR.TUBE 70SQ.MM	TATA spare parts
270554200105	ASSY.BRACKET (FOR FUSE BOX & RELAY)	TATA spare parts
270554200111	SOLENOID -12V-AIR/FUEL	TATA spare parts
270554200112	SOLENOID -12V OVER SPEED	TATA spare parts
270554200114	ASSY.CLAMP	TATA spare parts
270554200116	W/H.FOR IGNITOR - 12V SYSTEM.	TATA spare parts
270554200117	ASSY.MTG.BKT.(F/BOX & RELAYS)LP 407 CNG	TATA spare parts
270554200120	ASSY.MTG.BRACKET (IGNITER)	TATA spare parts
270554200122	TEMP INDICATOR - 12V	TATA spare parts
270554200123	TEMP.SENSOR - 12V	TATA spare parts
270554200129	INSTRUMENT CLUSTER-1:0.935	TATA spare parts
270554200130	TEMP.SENSOER (4.3 METE CABLE)	TATA spare parts
270554200131	INSTRUMENT CLUSTER-1:0.935	TATA spare parts
270554200132	INSTRUMENT CLUSTER-1:0.935	TATA spare parts
270554200133	INSTR.CLUSTER-1:0.78	TATA spare parts

270554200134	INSTR.CLUSTER-1:0.95	TATA spare parts
270554200135	INSTR.CLUSTER-1:0.81	TATA spare parts
270554200136	INST.CLUSTER (1:0 72)	TATA spare parts
270554200137	INSTRUMENT CLUSTER(1:0.64)	TATA spare parts
270554200138	INSTRUMENT CLUSTER ASSY	TATA spare parts
270554200139	W/H FOR INST CLUSTER	TATA spare parts
270554200140	W/H FOR IGNITOR 12V-4SP CNG	TATA spare parts
270554200142	ASSY MTG.BRACKET-ECU (CDP-OZ)	TATA spare parts
270554200144	ASSY.MTG.BRACKET (IGN.COIL)	TATA spare parts
270554200147	W/H INST. CLUST.	TATA spare parts
270554200148	INST.CLUSTER (1:0.90)	TATA spare parts
270554200151	W/H.IGNITER (CON.TYPE)--4SP CNG 12V	TATA spare parts
270554200152	H.T.COIL (CONN.TYPE)-E.D	TATA spare parts
270554200158	INSTRUMENT CLUSTER 0.76	TATA spare parts
270554200159	INSTRUMENT CLUSTER 0.70	TATA spare parts
270554200161	INSTRUMENT CLUSTER ASSY	TATA spare parts
270554200162	INST.CLUSTER LP407EX2 1:0.85	TATA spare parts
270554200167	INST CLUST ESPEEDO LPT410 0.72	TATA spare parts
270554200173	INST CLUST ESPEEDO LPT410 0.72	TATA spare parts
270554200186	INST. CLUSTER 0.80 LP407	TATA spare parts
270554200192	INST. CLUSTER 0.67 LP410 BSIII	TATA spare parts
270554200196	INST CLUSTER ESPEEDO 0.80_LPK410	TATA spare parts
270554200209	INST.CLUSTER 0.76 LP407 CNG BSIV	TATA spare parts
270554200213	INST.CLUSTER 0.70 LP410	TATA spare parts
270554200218	INST.CLUSTER ESPEEDO 0.85 LPT407 CNG BSI	TATA spare parts
270554200227	INST.CLUSTER ESPEEDO 0.90 LP407 NIGERIA	TATA spare parts
270554200234	INSTRUMENT CLUSTER	TATA spare parts
270554200235	INST.CLUSTER ESPEEDO 0.85	TATA spare parts
270554200238	INSTRUMENT CLUSTER ASSY	TATA spare parts
270554201602	W/H.IGNITER (CON.TYPE)--4SP CNG 12V	TATA spare parts
270554206304	COVER (FOR F/BOX & RELAYS BKT.)LP407-CNG	TATA spare parts
270554208211	HORN MTG. CLAMP	TATA spare parts
270554209908	SPEEDOMETER (1 : 0.81)	TATA spare parts
270554209909	SPEEDOMETER 1:0.95 (6+1DIG)BACKLIT-OFFER	TATA spare parts
270554209910	SPEEDOMETER 1:0.95(6+1DIG)BACKLIT	TATA spare parts
270554209911	SPEEDOMETER 1:0.95(6+1DIG)BACKLIT-	TATA spare parts
270554209912	GAS SHUT OFF SOLENOID-12V	TATA spare parts
270554209913	AFR CONTROLLER ES GOVERNER - 12VOLT	TATA spare parts
270554209914	H.T.CABLE 300 MM LONG	TATA spare parts
270554209916	IGNITOR - 12V.	TATA spare parts
270554209917	INST.CLUSTER SPEEDO RATIO-0.80 MOVEMENT	TATA spare parts
270554209919	SPEEDOMETER RATIO 0.935	TATA spare parts
270554209920	SPEEDOMETER RATIO 0.95	TATA spare parts
270554209921	SPEEDOMETER RATIO 0.81	TATA spare parts
270554209924	IMPCO-(CDP-OZ)-ECU	TATA spare parts
270554209926	H.T.CABLE - 200MM LONG	TATA spare parts
270554209927	H.T.CABLE - 200MM LONG	TATA spare parts

270554209928	H.T.CABLE - 200MM LONG	TATA spare parts
270554209929	IGNITOR-GP6 LB-12V-BSIII-407 CNG	TATA spare parts
270554209930	SPEEDOMETER RATIO 0.90	TATA spare parts
270554209933	GAS SHUT-OFF SOLENOID-1/2INCH NPT THREAD	TATA spare parts
270554209934	CNG GAS PRE.INDICATOR-12V	TATA spare parts
270554209936	SPEEDOMETER RATIO 0.76	TATA spare parts
270554209944	SPEEDOMETER 0.72 ESPEEDO 407	TATA spare parts
270554209948	SPEEDOMETER 0.78 ESPEEDO	TATA spare parts
270554209954	SPEEDO MOMENT 0.80 RATIO	TATA spare parts
270554209961	SPEEDOMETER 0.80 ESPEEDO LP407 BSII	TATA spare parts
270554210102	INST CLUSTER WITH 0.76 RATION FOR LPT410	TATA spare parts
270554210109	INSTRUMENT CLUSTER	TATA spare parts
270554210110	INS CLUSTER(0.88) LP410 BSIV	TATA spare parts
270554210111	INST CLUSTER LPT407 EX2 II LHD 0.80	TATA spare parts
270554300101	INSTRUMENT CLUSTER ASSY	TATA spare parts
270554400108	ASSY WARNING LAMP-OFFER 12V 7 IND BANK	TATA spare parts
270554400109	ASSY LAMP WARNING 7 IND 12V-	TATA spare parts
270554400110	ASSY. 5 CH TAIL LAMP RH WITH BRKT	TATA spare parts
270554400111	ASSY. 5 CH TAIL LAMP LH WITH BRKT.	TATA spare parts
270554506901	PIANO SW REAR ILLU LAMP W/O CONN	TATA spare parts
270554506902	PIANO SW REAR ILLU LAMP W/O CONN-	TATA spare parts
270554506903	PIANO SW REAR ILLU LAMP W/O CONN	TATA spare parts
270554600101	CYLINDER EARTHING CABLE SET-LP/LPT407CNG	TATA spare parts
270554600102	WIRING HARNESS MAIN CMVR2000	TATA spare parts
270554600103	W/H INSTRUMENT CONSOLE CMVR2000	TATA spare parts
270554600104	W/H TAIL CMVR2000 W/O LOADBODY	TATA spare parts
270554600105	W/H TAIL WITH LOADBODY CMVR2000	TATA spare parts
270554600106	ASSY BRACKET-FOR W/H CLAMPING	TATA spare parts
270554600107	W/H MAIN RHD EURO-II	TATA spare parts
270554600108	W/H ENGINE RHD EURO-II	TATA spare parts
270554600109	W/H TAIL W/LB EURO-II	TATA spare parts
270554600110	W/H TAIL W/O LB EURO-II	TATA spare parts
270554600111	W/H MAIN RHD CMVR2000	TATA spare parts
270554600112	W/H MAIN BS-II RHD	TATA spare parts
270554600115	W/H MAIN RHD W/EXH BS-II W/MOT H/L	TATA spare parts
270554600116	W/H TAIL 34WB W/OR W/O LB BS-I & II	TATA spare parts
270554600117	W/H MAIN LP407 CNG BS-III	TATA spare parts
270554600118	W/H ENGINE LP407 CNG BS-III	TATA spare parts
270554600119	W/H INST.CONSOLE LP407CNG BS-III	TATA spare parts
270554600121	W/H MAIN LP/LPT 407 BS-II	TATA spare parts
270554600122	W/H ENGINE LP/LPT 407 BSII	TATA spare parts
270554600126	ASSY.CLAMP	TATA spare parts
270554600132	ASSY. BATT CUT OFF MTG BKT_LH	TATA spare parts
270554601601	W/H MAIN LPK407 TIPPER BS-II	TATA spare parts
270554601602	W/H ENINE LPK407 TIPPER	TATA spare parts
270554601603	W/H TAIL 27WB TPK407 TIPPER -	TATA spare parts
270554601615	W/H TAIL LP 407/34WB BS-II	TATA spare parts

270554601616	W/H.MAIN-LP407CNG-BSIII	TATA spare parts
270554601635	WIRING HARNESS TAIL	TATA spare parts
270554601703	W/H_TAIL_LPT407 34WB EX2_CNG_BSIV	TATA spare parts
270554601707	W/H TAIL LP407 34WB CNG BSIV	TATA spare parts
270554608206	BRACKET FOR NBF PARKING & W/H CLAMPING	TATA spare parts
270554608209	EMS MAIN INTER CONN PARKING BRKT	TATA spare parts
270554608211	BRACKET FOR MAXI FUSE ANDMIDI FUSE MTG .	TATA spare parts
270554608224	STARTER FUSE MTG BKT SINGLE MTG HOLE	TATA spare parts
270554611619	W/H MAIN LPT407/709/909/1109 EX WITH WIL	TATA spare parts
270554611620	WIRING HARNESS MAIN BS3	TATA spare parts
270554611631	W/H MAIN LPT407/709/909/1109EX BS-III WI	TATA spare parts
270554611632	W/H MAIN LPT407/709/909/1109 EX2 BS-III	TATA spare parts
270554620105	WIRING HARNESS-TAIL	TATA spare parts
270554620110	WIRING HARNESS TAIL -CMVR 2000 LP 407	TATA spare parts
270554620111	WIRING HARNESS ENGINE -CMVR 2000 LP 407	TATA spare parts
270554620116	WIRING HARNESS TAIL 31 WB LPT 507	TATA spare parts
270554620117	WIRING HARNESS MAIN-RHD CMVR 2000 LP 407	TATA spare parts
270554620118	WIRING HARNESS INSTRUMENT CONSOLE	TATA spare parts
270554620122	WIRING HARNESS MAIN -LPT 509 RHD S-CAM	TATA spare parts
270554620123	WIRING HARNESS MAIN RHD LP407	TATA spare parts
270554620124	WIRING HARNESS INST.CONSOLE W/O EXH. BRA	TATA spare parts
270554620129	WIRING HARNESS MAIN LHD	TATA spare parts
270554620134	WIRING HARNESS ENGINE	TATA spare parts
270554620146	W/H ENGINE RHD S CAM BRAKES	TATA spare parts
270554620147	W/H MAIN LHD W/O H & D	TATA spare parts
270554620148	WIRING HARNESS MAIN CMVR2000	TATA spare parts
270554620149	W/H INSTRUMENT CONSOLE CMVR2000	TATA spare parts
270554620150	W/H TAIL WITH LOADBODY CMVR2000	TATA spare parts
270554620151	W/H TAIL CMVR2000 W/O LOADBODY	TATA spare parts
270554620152	W/H ENGINE LPT509 LHD 497TC ENG	TATA spare parts
270554620153	W/H TAIL LP/LPT 509 LHD 31WB	TATA spare parts
270554620154	W/H INSTRUMENT CONSOLE	TATA spare parts
270554620155	W/H ENGINE LP509 LHD 497TC ENG	TATA spare parts
270554620156	W/H MAIN RHD CMVR2000	TATA spare parts
270554620157	W/H MAIN RHD BS-II	TATA spare parts
270554620158	W/H TAIL W/LB EURO-II	TATA spare parts
270554620159	W/H TAIL W/O LB EURO-II	TATA spare parts
270554620160	W/H ENGINE RHD EURO-II	TATA spare parts
270554620162	W/H TAIL 34WB RHD	TATA spare parts
270554620163	W/H MAIN W/EXH.BR.BSII RHD	TATA spare parts
270554620166	W/H MAIN LP/LPT 407 BS-II	TATA spare parts
270554620167	W/H ENGINE LP/LPT 407 BS-II	TATA spare parts
270554620169	W/H TAIL LP/LPT 407/31WB BS-II	TATA spare parts
270554620171	W/H MAIN RHD BS-II LPK407	TATA spare parts
270554620172	W/H ENGINE RHD BS-II LPK407	TATA spare parts
270554620173	W/H TAIL 27WB BS-II LPK407	TATA spare parts
270554620182	W/H MAIN LP/LPT 407 EX2 BS-II	TATA spare parts

270554620183	W/H TAIL LPT407 34WB EX2	TATA spare parts
270554620185	W/H TAIL LP 407/34WB BS-II	TATA spare parts
270554620207	W/H MAIN LPT407 EX2 LHD BSII PTO	TATA spare parts
270554620208	W/H TAIL LPT407/34WB EX2 PTO	TATA spare parts
270554620209	W/H SWITCH LPT407 EX2 BSII PTO 12V	TATA spare parts
270554620210	W/H ENGINE LPT407 BSII EX2 12V LHD	TATA spare parts
270554620221	W/H TAIL LP407 EX NIGERIA	TATA spare parts
270554620222	WIRING HARNESS MAIN	TATA spare parts
270554630110	W/H TAIL LPT410/34WB EX2 BSIII	TATA spare parts
270554630128	W/H MAIN LP/LPT410/712 EX BSIII	TATA spare parts
270554630129	W/H MAIN	TATA spare parts
270554630130	W/H MAIN LPK 410/912 BSIII	TATA spare parts
270554630131	W/H SENSOR LP/LPT 410 BSIII	TATA spare parts
270554630132	W/H TAIL LPK410/27WB BSIII	TATA spare parts
270554630135	W/H TAIL LP410/34WB BSIII MARCOPOLO	TATA spare parts
270554630137	W/H TAIL LPT410/34WB EX BS-III	TATA spare parts
270554630138	W/H TAIL LP410/34 497 BS-IV	TATA spare parts
270554630139	W/H ENGINE LP410/34 4SP BS-III	TATA spare parts
270554630146	W/H MAIN LP410/34WB WITH BSIII IMPROVEME	TATA spare parts
270554630147	W/H MAIN LP410/34 497 BS-IV	TATA spare parts
270554630152	W/H TAIL	TATA spare parts
270554630159	W/H MAIN LPT407/709/909/1109 EX	TATA spare parts
270554630160	W/H MAIN LPT407/709/909/1109 EX2	TATA spare parts
270554630161	WIRING HARNESS MAIN WITH WILLIAM CONTRO	TATA spare parts
270554630163	W/H MAIN LPT407/709/909/1109EX BS-III WI	TATA spare parts
270554630164	W/H MAIN LPT407/709/909/1109 EX2 BS-III	TATA spare parts
270554630170	WIRING HARNESS SWITCH	TATA spare parts
270554630172	W/H SENSOR LPT407 BS-III AD-MSSL	TATA spare parts
270554630173	WIRING HARNESS TAIL LP410/34WB BS-IV	TATA spare parts
270554640101	W/H MAIN RHD EURO-II	TATA spare parts
270554640102	W/H ENGINE RHD EURO-II	TATA spare parts
270554640103	W/H INSTRUMENT CONSOLE CMVR2000	TATA spare parts
270554640104	W/H TAIL W/LB EURO-II	TATA spare parts
270554640105	W/H TAIL W/O LB EURO-II	TATA spare parts
270554660101	WIRING HARNESS MAIN -RHD 407LP TURBO	TATA spare parts
270554660103	WIRING HARNESS ENGINE	TATA spare parts
270554660105	WIRING HARNESS MAIN EUROII LP407	TATA spare parts
270554660106	W/H ENGINE RHD BHARAT STAGE-II	TATA spare parts
270554660107	W/H TAIL W/O LB EURO-II	TATA spare parts
270554660108	W/H MAIN-LP407CNG	TATA spare parts
270554660109	W/H TAIL-LP407CNG	TATA spare parts
270554660110	W/H ENGINE-LP407CNG	TATA spare parts
270554660111	W/H INST. CONSOLE-LP407CNG	TATA spare parts
270554660113	WIRING HARNESS MAIN CMVR2000	TATA spare parts
270554660114	W/H MAIN RHD BS-II	TATA spare parts
270554660115	W/H INSTRUMENT CONSOLE CMVR2000	TATA spare parts
270554660116	W/H TAIL CMVR2000 W/O LOADBODY	TATA spare parts

270554660117	W/H TAIL W/LB BS-II	TATA spare parts
270554660118	W/H TAIL WITH LOADBODY CMVR2000	TATA spare parts
270554660119	W/H MAIN RHD CMVR2000	TATA spare parts
270554660120	W/H MAIN RHD BS-II	TATA spare parts
270554660121	W/H MAIN (LP410EX) BS-III	TATA spare parts
270554660122	W/H ENGINE (BS-III)	TATA spare parts
270554660123	W/H MAIN RHD BS-II	TATA spare parts
270554660124	W/H TAIL LP 410 BS III	TATA spare parts
270554660125	W/H TAIL 34WB W/OR W/O LB BS-I & II	TATA spare parts
270554660126	W/H TAIL LPT410EX/34WB	TATA spare parts
270554660127	W/H MAIN-LP407 CNG BS-III	TATA spare parts
270554660128	W/H ENGINE (LP407 CNG BS-III)	TATA spare parts
270554660129	W/H INST.CONSOLE (LP407 CNG BS-III)	TATA spare parts
270554660130	W/H MAIN LP/LPT 407 BS-II	TATA spare parts
270554660131	W/H ENGINE LP/LPT 407 BSII	TATA spare parts
270554660133	W/H TAIL LP/LPT 407/31WB BS-II	TATA spare parts
270554660134	W/H TAIL LP/LPT 407/34WB BS-II	TATA spare parts
270554660139	W/H TAIL LP 407/34WB BS-II	TATA spare parts
270554660145	W/H MAIN LP/T407/709/809/909/1109	TATA spare parts
270554660146	W/H MAIN LPK 407/909 TIPPER BS-II	TATA spare parts
270554660150	WIRING HARNESS PARKING	TATA spare parts
270554660178	W/H MAIN LP/LPT410/712 BSIII EX	TATA spare parts
270554660179	W/H MAIN LP/LPT410/712 BSIII EX2	TATA spare parts
270554660180	W/H MAIN LPK410/912 BSIII	TATA spare parts
270554660181	W/H SENSOR LP/LPT410 BSIII	TATA spare parts
270554660182	W/H TAIL LPK410/27WB BSIII	TATA spare parts
270554660189	W/H ENGINE LP410/34 4SP BS-II	TATA spare parts
270554670110	W/H MAIN LPT407/709/909/1109 EX WITH WIL	TATA spare parts
270554670111	W/H MAIN LPT407/709/909/1109 EX2	TATA spare parts
270554670113	W/H MAIN LPT407/709/909/1109EX BS-III WI	TATA spare parts
270554670114	W/H MAIN LPT407/709/909/1109 EX2 BS-III	TATA spare parts
270554670115	W/H MAIN LPK407/909 BS-III WITH CAT-6	TATA spare parts
270554680101	W/H MAIN LP/LPT 407 BS-II	TATA spare parts
270554680102	W/H ENGINE LP/LPT 407 BS-II	TATA spare parts
270554680105	W/H MAIN LPK407 TIPPER BS-II-	TATA spare parts
270554680106	W/H TAIL 27WB LPK407 TIPPER	TATA spare parts
270554680107	W/H ENINE LPK407 TIPPER-	TATA spare parts
270554690120	W/H SENSOR LPT410 BSIII	TATA spare parts
270554690137	W/H MAIN LPT407/709/909/1109 EX WITH WIL	TATA spare parts
270554690138	W/H MAIN LPT407/709/909/1109 EX2	TATA spare parts
270554690140	W/H MAIN LPT407/709/909/1109EX BS-III WI	TATA spare parts
270554690141	W/H MAIN LPT407/709/909 EX2 BS-III WITH	TATA spare parts
270554690142	W/H MAIN LPK407/909	TATA spare parts
270554820101	ASSY MAIN CABLE SET-RHD 3100 W.B.	TATA spare parts
270554820102	ASSY.CABLE SET FRT-TAIL	TATA spare parts
270554820105	ASSY MAIN CABLE SET RHD	TATA spare parts
270558408201	TEMPORARY NO.PLATE-PAPER STICKER (LKN)	TATA spare parts



270558409905	TRANSFER LABEL (FRONT TYRE PRESSURE)	TATA spare parts
270558900601	16 HEX BOX SPNR / SPARK PLUG/ 407 LP CNG	TATA spare parts
270558904002	WHEEL SPANNER 24X27	TATA spare parts
270560CK0196	ASSY CABIN KIT COMPLETE	TATA spare parts
270582990101	WIPER MOTOR 12V	TATA spare parts
270587304901	ROOF LAMP	TATA spare parts
270587304902	STEP LAMP	TATA spare parts
270587304903	WIRE HARNESS	TATA spare parts
270587304904	SIDE MARKER	TATA spare parts
270587304905	INDICATOR	TATA spare parts
270587304906	HEIGHT MARKER (RED)	TATA spare parts
270587304907	HEIGHT MARKER (WHITE)	TATA spare parts
270587304908	NUMBER PLATE LIGHT	TATA spare parts
270587305001	CURTAIN SECTION	TATA spare parts
270587306901	WINDOW GUARD RAIL	TATA spare parts
270587306902	GRABRAIL	TATA spare parts
270587306903	STEP PARTITION	TATA spare parts
270587306904	DRIVER PARTITION	TATA spare parts
270587307702	HANDLE	TATA spare parts
270587307703	HAMMER	TATA spare parts
270587307704	RUBBER BEADING	TATA spare parts
270587307705	LOCK	TATA spare parts
270587308201	PASSANGER DOOR	TATA spare parts
270587308202	DRIVER DOOR	TATA spare parts
270587308203	FUEL TANK ASSY	TATA spare parts
270587308204	BATTERY BOX	TATA spare parts
270587309902	REAR WINDSHIELD	TATA spare parts
270587309904	SUNVISOR	TATA spare parts
270587309905	REAR VIEW MIRROR	TATA spare parts
270587309906	FRONT BUMPER	TATA spare parts
270587309907	REAR BUMPER	TATA spare parts
270587309908	SEAT BELT	TATA spare parts
270587309909	DRIVER SEAT	TATA spare parts
270587309910	CO DRIVER SEAT	TATA spare parts
270587309911	PASSENGER SEAT	TATA spare parts
270587309912	FULL BODY STICKER	TATA spare parts
270587309913	DRIVER DOOR WINDOW GLASS 1	TATA spare parts
270587309914	DRIVER DOOR WINDOW GLASS 2	TATA spare parts
270624200101	ASSEMBLY RUBBER SUPPORT-REAR	TATA spare parts
270630100102	ASSY.PULL ROD	TATA spare parts
270632100103	ASSY.BRACKET FRONT FOR FRONT SPRING	TATA spare parts
270635108301	SHIM ADJ	TATA spare parts
270641110101	ASSY.PROPELLAR SHAFT WITH CENTRE BEARING	TATA spare parts
270641120104	ASSY.PROPELLAR SHAFT REAR	TATA spare parts
270642107701	GROMMET	TATA spare parts
270642906801	SOCKET	TATA spare parts
270642906801AE	SOCKET	TATA spare parts

270647600110	DIESEL RETURN PIPE	TATA spare parts
270649200101	ASSY.EXHAUST PIPE FRONT	TATA spare parts
270649200102	EXHAUST PIPE(INTERMEDIATE)	TATA spare parts
270654100106	ASSY.BATTERY CABLE +VE 2.85 (50 SQ.MM)	TATA spare parts
270654100109	ASSY BATTERY CABLE -VE 2.25 (50 SQ.MM.)	TATA spare parts
270654110101	ASSY.BATTERY CABLE -VE 3.05 (50 SQ.MM)	TATA spare parts
270654200104	ASSY BRACKET (HORN MTG)	TATA spare parts
270654200105	ASSY.RELAY COVER FOR 6 RELAYS	TATA spare parts
270654200106	INST. CLUSTER 1:0.7(SFC/713)	TATA spare parts
270654209901	TRIP SPEEDOMETER-RATIO-0.7	TATA spare parts
270654244901	ACC RELAY (NO CONTACT) 24V	TATA spare parts
270654244902	ACC RELAY 24 V	TATA spare parts
270654249901	SPEEDOMETER 1:0.7 BACKLIT 24V	TATA spare parts
270654249902	SPEEDOMETER 1:0.7 BACKLIT W/TRIPODO	TATA spare parts
270654249903	SPEEDOCABLE (JIS TYPE) -2600 MM -	TATA spare parts
270654249904	SPEEDOMETER (1:0.7) 24V	TATA spare parts
270654249905	SPEEDOCABLE (JIS TYPE)	TATA spare parts
270654249906	SPEEDOCABLE (JIS TYPE) 2600MM	TATA spare parts
270654440115	ASSY TURN INDICATOR LAMP 24V	TATA spare parts
270654440116	ASSY.TURN INDICATOR LAMP 24V	TATA spare parts
270654440117	ASSY.TURN INDICATOR LAMP 24V	TATA spare parts
270654440118	ASSY.TURN INDICATOR LAMP 24V	TATA spare parts
270654440119	ASSY.TURN IND.LAMP 24V	TATA spare parts
270654440120	ASSY.TURN IND.LAMP 24V	TATA spare parts
270654506901	PIANO SWITCH (3 TERMINAL) FOG LAMP-	TATA spare parts
270654506902	PIANO SWITCH (3 TERMINAL) FOG LAMP-	TATA spare parts
270654620114	W/H BACK LIGHTING (24V)	TATA spare parts
270654620115	W/H MAIN RHD SFC713 FACELESS	TATA spare parts
270654620116	WIRING HARNESS(FRONT TO TAIL)	TATA spare parts
270654640106	WIRING HARNESS BLOWER	TATA spare parts
270682409902	WIPER MOTOR W/MSSL TERS & HSG -RHD 24V	TATA spare parts
270715200101	ASSY.SOLENOID (24V)	TATA spare parts
270715200102	ASSY.SOLENOID (24V)	TATA spare parts
270729200103	ASSY. SUPPORT COMPLETE (CLUTCH)	TATA spare parts
270731000101	ASSY FRAME COMPLETE	TATA spare parts
270731000102	ASSY FRAME COMPLETE(LP713/38WB E-II TMML)	TATA spare parts
270731200101	ASSY JOINT GUSSET PLATE LH	TATA spare parts
270731200102	ASSY JOINT GUSSET PLATE RH	TATA spare parts
270731700101	ASSEMBLY BRACKET - LH	TATA spare parts
270731700102	ASSEMBLY BRACKET - RH	TATA spare parts
270731700103	ASSY. BRACKET-LH	TATA spare parts
270731700104	ASSY .BRACKET-RH	TATA spare parts
270731700105	ASSEMBLY FRAME LPT713S/38	TATA spare parts
270733000101	ASSY FRONT AXLE WITH BRAKES(NON ASBS)	TATA spare parts
270735108301	SHIM ADJ	TATA spare parts
270740100104	ASSY RIM TYRE & BALANACE WEIGHTS	TATA spare parts
270740100119	WHEEL RIM ASSY	TATA spare parts

270740100120	WHEEL RIM ASSY	TATA spare parts
270740100121	WHEEL RIM ASSY	TATA spare parts
270742300101	SPRING BRK ACTUATOR(T-12/12) BS1/2/3/4	TATA spare parts
270742300102	REPAIR KIT (TYPE12/12 SBA)	TATA spare parts
270742307702	DIAPHRAGM	TATA spare parts
270743200101	SUB ASSY AIR TANKS FOR VOSS-LPT713	TATA spare parts
270743200102	SUB ASSY AIR TANK VOSS (15 LTR) LPT 713	TATA spare parts
270743700107	AUTO.LOAD SENSING VALVE FOR VOSS	TATA spare parts
270743700108	AUTO.LOAD SENSING VALVE FOR VOSS-(LP)	TATA spare parts
270743900120	ASSY NYLON PIPE SET CHASS COMP LP 713	TATA spare parts
270743900128	ASSY TUBE SECOND COMPRESSOR TO DDU	TATA spare parts
270743900129	ASSY METAL PIPE DIA 15 COMP TO DDU 38WB	TATA spare parts
270743900131	ASSY NYLON PIPE SET CHASSIS COMPL 713	TATA spare parts
270743900151	ASSY NYLON PIPE SET CHASSIS COMPL	TATA spare parts
270743900164	ASSY. NYLON PIPE SET CHASSIS COMPLETE	TATA spare parts
270743906802	STRAP (CABLE TIE 4.5X150 BLACK TS29360)	TATA spare parts
270743908204	BRACKET	TATA spare parts
270743910114	PIPE ASSY DBV TO GAUGE FRONT	TATA spare parts
270743910115	PIPE ASSY DBV TO GAUGE FRONT	TATA spare parts
270746800104	ASSY PIPE (RES TANK TO PUMP)	TATA spare parts
270746800105	ASSY. PIPE (PUMP TO GEAR BOX)	TATA spare parts
270746800106	ASST TUBE ( POWER STRG GEAR BOX TO RESE	TATA spare parts
270746800107	ASSY TUBE (STEERING TANK TO PUMP)	TATA spare parts
270747600101	SUCTION LINE	TATA spare parts
270747600102	SUCTION LINE	TATA spare parts
270747600103	RETURN LINE	TATA spare parts
270747600106	ASSY NYLON FUEL LINE(TANK TO STRAINER)	TATA spare parts
270747600110	ASSY RETURN LINE-OVER FLOW LINE TO TANK	TATA spare parts
270747600111	ASY.NYLON FUEL LINE-TANK TO STRAINER	TATA spare parts
270747600115	ASY.RETURN LINE	TATA spare parts
270747600116	ASSY FUEL LINE (WAT.SEP TO MECH FEED PU)	TATA spare parts
270747600117	ASSY FUEL LINE (STRAINER TO W/S)	TATA spare parts
270747600118	ASSY RETURN LINE	TATA spare parts
270747600119	ASSY SUCTION LINE (F.TANK-STRAINER)	TATA spare parts
270747600120	ASSY SUCTION LINE(STRAINER TO FEED PUMP)	TATA spare parts
270747600125	ASSY SUCTION LINE(STRAINER TO FEED PUMP)	TATA spare parts
270754100101	ASSY.BATTERY CABLE (LINK) 50SQMM (150MM)	TATA spare parts
270754200107	EMOS CONTROLLER 12V	TATA spare parts
270754200111	ASSY BRACKET (ENG STOP & STARTER RELAY)	TATA spare parts
270754200112	ASSY.BRACKET (STARTER & ENG.STOP RELAY)	TATA spare parts
270754200119	INST.CLUSTER 0.70 12V W/APP	TATA spare parts
270754200120	EMOS CONTROLLER 12V/24V	TATA spare parts
270754200123	INSTRUMENT CLUSTER 0.64 LPT 913 EX2	TATA spare parts
270754200124	INST.CLUSTER WITH 0.62 LP713 SA 24V	TATA spare parts
270754200126	INST CLUSTER ESPEEDO LP713 WITH RATIO 1:	TATA spare parts
270754206301	COVER FOR RELAY & FUSE BOX MTG	TATA spare parts
270754208203	EMOS MTG.BRACKET	TATA spare parts

270754209903	VEHICLE SPEED SENSOR	TATA spare parts
270754209904	VEHICLE SPEED SENSOR	TATA spare parts
270754209905	RPM METER (1200 TO 2000 G.B.)	TATA spare parts
270754209906	VEHICLE SPEED SENDOR	TATA spare parts
270754244901	ACC RELAY -24V (WITH RESISTOR)	TATA spare parts
270754249901	AIR PRESSURE GAUGE (BACKLIT)24V	TATA spare parts
270754249902	RPM.METER (24V) BACKLIT	TATA spare parts
270754249903	AIR PRESSURE GAUGE (BACKLIT) 24V	TATA spare parts
270754249904	FUEL GAUGE (BACKLIT) 24V	TATA spare parts
270754249907	WIPER TIMER-LPT-916 TC 24 VOLTS	TATA spare parts
270754249907AE	WIPER TIMER 24V 715	TATA spare parts
270754249910	R.P.M.METER 24V (BACKLIT)	TATA spare parts
270754249911	ELECT.TEMP GAUGE 24V (BACKLIT)	TATA spare parts
270754249912	FUEL GAUGE 24V (BACKLIT)	TATA spare parts
270754249913	R.P.M.METER 24V (BACKLIT)	TATA spare parts
270754249914	ELECT.TEMP GAUGE 24V (BACKLIT)	TATA spare parts
270754249915	FUEL GAUGE 24V (BACKLIT)	TATA spare parts
270754249916	WIPER TIMER-LPT-916 TC 24 VOLTS	TATA spare parts
270754249919	FLAME GLOW PLUG 24V	TATA spare parts
270754249920	FLAME GLOW PLUG CONTROLLER 24V	TATA spare parts
270754400109	FRONT FOG LAMP 12V E'CERT	TATA spare parts
270754440101	ASSY.WARNING LAMP -24V	TATA spare parts
270754440102	ASSY.WARNING LAMP - 24V	TATA spare parts
270754440103	REAR FOG LAMP W/BULB & PIG TAIL24V	TATA spare parts
270754440114	BLINKER RH E CERT W/E MARK BULB-24V	TATA spare parts
270754440115	BLINKER LH E CERT.W/E MARK BULB-24V	TATA spare parts
270754440118	SIDE IND.LAMP LH E CER W/E BULB-24V	TATA spare parts
270754440119	SIDE IND.LAMP RH E CER W/E BULB-24V	TATA spare parts
270754440124	ASSY TAIL LAMP LH (E CERT)24V	TATA spare parts
270754440125	ASSY TAIL LAMP RH (E CERT)24V	TATA spare parts
270754440144	ASSY.4-CH.T/LAMP 24V RH'E'CE	TATA spare parts
270754440145	ASSY.4-CH.T/LAMP 24V LH'E'CE	TATA spare parts
270754440148	ASSY WARNING LAMP 24V 7 IND BANK	TATA spare parts
270754440149	ASSY WARNING LAMP 24V 7 IND	TATA spare parts
270754440154	ASSY WARNING LAMP 24V 7 IND BANK	TATA spare parts
270754440155	ASSY WARNING LAMP 24V 7 IND	TATA spare parts
270754506901	PIANO SW (APP) W/O CONN	TATA spare parts
270754600106	WIRING HARNESS BLOWER	TATA spare parts
270754600107	WIRING HARNESS ENGINE	TATA spare parts
270754620115	W/H ENGINE EURO-I	TATA spare parts
270754620118	W/H ENGINE CMVR2000	TATA spare parts
270754620121	WIRING HARNESS BLOCK HEATER	TATA spare parts
270754620127	WIRING HARNESS SW.W/O ABS	TATA spare parts
270754620136	W/H MAXIFUSE & BCS FOR LP 713/38WB E-II	TATA spare parts
270754620137	W/H H/L AND BLINKER FOR LP 713/38WB E-II	TATA spare parts
270754660101	W/H TAIL 38 WB RHD	TATA spare parts
270754660103	W/H INSTRUMENT CONSOLE	TATA spare parts

270754660105	W/H MAIN RHD	TATA spare parts
270754660106	WIRING HARNESS BLOWER	TATA spare parts
270754660112	WIRING HARNESS	TATA spare parts
270754660113	W/H ENGINE	TATA spare parts
270754660117	W/H ENGINE CMVR2000	TATA spare parts
270754660120	W/H MAIN W/CLUST.LP/LPT713 BS-I	TATA spare parts
270754660127	W/H TAIL LP/LPT 813/38WB W/O PTO/APP	TATA spare parts
270754660129	WIRING HARNESS TAIL	TATA spare parts
270754660131	W/H ENGINE LPT/LPK 713RHD 12V II	TATA spare parts
270754660133	W/H MAIN LPT813 12V EII SUPER	TATA spare parts
270754660137	W/H TAIL WITH EMOS FOR LP 713/38WB E-II	TATA spare parts
270754660138	W/H ENGINE WITH EMOS FOR LP 713/38WB E-I	TATA spare parts
270754740101	ASSY.TWIN BLOWER W/RESIST.W TER 24V	TATA spare parts
270782400102	KIT W/S WASHER RHD 24V	TATA spare parts
270782400105	ASSY. WIPER MOTOR BS1/2/3/4	TATA spare parts
270782400106	ASSY WIPER MOTOR W/BKT	TATA spare parts
270829100101	ASSY BRACKET CLUTCH BOOSTER MTG	TATA spare parts
270831000101	ASSY.FRAME COMPLETE.	TATA spare parts
270831200101	ASSY END CROSS MEMBER	TATA spare parts
270833000101	FRT AXLE LPT1918 S.AFR (840CD/BIL/180/70	TATA spare parts
270841110101	ASSY FRONT PROP SHAFT COMPLETE WITH C/B	TATA spare parts
270841120101	ASSY PROP SHAFT COMPLETE REAR	TATA spare parts
270843200101	SUB ASSY.AIR TANKS 305STRAP C.D.FOR VOSS	TATA spare parts
270843700104	ALSV VOSS WITH 75MM LEVER	TATA spare parts
270843700110	ASSY BRACKET FOR CONNECTOR MTG	TATA spare parts
270843700111	ASSY BRACKET FOR HAND BRAKE VALVE MTG.	TATA spare parts
270843703305	BRACKET FOR LSV MTG	TATA spare parts
270843900103	ASSEMBLY LINK - (LPT 1918)	TATA spare parts
270843900104	ASSEMBLY LCRV LEVER (LPT 1918)	TATA spare parts
270843900107	ASSY NYLON PIPE SET CHASS 1918TC	TATA spare parts
270843900108	ASSY.THIRD METAL PIPE	TATA spare parts
270931000101	ASSY. FRAME COMPLETE	TATA spare parts
270935108301	SHIM ADJ	TATA spare parts
270942800104	ASSY.NYLON PIPE SET COMP.LPT-509 RHD	TATA spare parts
271035108301	SHIM ADJ	TATA spare parts
271060100101	ASSY.COWL COMPLETE WITH FITMENTS-RHD.	TATA spare parts
271081800101	MASCOT 2213A	TATA spare parts
271126000102	GEAR BOX	TATA spare parts
271126000118	ASSY 9SP G.B. W/SIDE & RR PTO	TATA spare parts
271126000122	ASSY.GEARBOX EATON FSO10309 ODSAE1 FR RH	TATA spare parts
271126000123	ASSY. GEARBOX ( FSO 10209 ) WITH REAR PT	TATA spare parts
271126000124	ASSY GEAR BOX FULL REM180DIA W/O PS	TATA spare parts
271126000127	GEAR BOX LPS4038	TATA spare parts
271126000135	GEARBOX RHD	TATA spare parts
271126000139	ASSY GEAR BOX SINGLE	TATA spare parts
271126000143	ASSY EATON FSO 8406 A GEAR BOX	TATA spare parts
271126000145	ASSY. GEAR BOX EATON ES150409 A DD E3	TATA spare parts

271126000150	ASSY GEAR BOX EATON FSO-10309 OD D BLE H	TATA spare parts
271126000151	GEAR BOX RHD	TATA spare parts
271126000154	ASSY.GEARBOX (9.01)SUIT FOR PTO	TATA spare parts
271126000157	ASSY. GEARBOX 2523.T M0	TATA spare parts
271126000160	GEAR BOX OD(7.05) PTO PROV	TATA spare parts
271126000172	ASSY GEARBOX ESO-11206 AE W/O PTO (7.05)	TATA spare parts
271126000179	GEAR BOX ASSY	TATA spare parts
271126100101	LRC HOUSING ASSY	TATA spare parts
271126100102	INTERMEDIATE CASE	TATA spare parts
271126103701	CLUTCH HOUSING	TATA spare parts
271126103801	SPEEDO HOUSING MECHANICAL	TATA spare parts
271126103803	FRONT CASE	TATA spare parts
271126103804	REAR CASE	TATA spare parts
271126103805	INTERMEDIATE CASE	TATA spare parts
271126103806	FRONT CASE	TATA spare parts
271126106701	PLUNGER - NEUTRAL	TATA spare parts
271126200102	OIL STRAINER ASSEMBLY	TATA spare parts
271126200103	NEEDLE BEARING PACK ASSY	TATA spare parts
271126200104	FILTER REGULATOR ASSY	TATA spare parts
271126200105	OIL SPRAY BAR REAR	TATA spare parts
271126200106	OUTPUT SHAFT & PLANET	TATA spare parts
271126203001	ROLLER SYNCHRO ASSY	TATA spare parts
271126203002	ROLLER SYNCHRO ASSY	TATA spare parts
271126203102	BEARING OUTPUT	TATA spare parts
271126203103	NEEDLE BEARING ASSY	TATA spare parts
271126203104	NEEDLE BEARING ASSY	TATA spare parts
271126203105	NEEDLE BEARING ASSY	TATA spare parts
271126203106	NEEDLE ROLLER BEARING	TATA spare parts
271126203107	NEEDLE BEARING ASSY	TATA spare parts
271126203108	BEARING REAR - MAINSHAFT	TATA spare parts
271126203201	SOCKET HD CAP SCREW	TATA spare parts
271126203401	ADAPTER SPEEDO	TATA spare parts
271126203402	BUSH	TATA spare parts
271126203403	OIL MUFF	TATA spare parts
271126203404	SLEEVE-MAINSHAFT BEARING	TATA spare parts
271126203405	SLEEVE-MAINSHAFT BEARING	TATA spare parts
271126203408	BUSHING - CROSS SHAFT	TATA spare parts
271126204201	HOSE CLAMP	TATA spare parts
271126204301	CIRCLIP	TATA spare parts
271126204302	CIRCLIP	TATA spare parts
271126204310	CIRCLIP-GR.DIA.60 X 2.05MM	TATA spare parts
271126204311	CIRCLIP-GR.DIA.60 X 2.00MM	TATA spare parts
271126204316	GRADED CIRCLIP PACK	TATA spare parts
271126204317	GRADED CIRCLIP PACK	TATA spare parts
271126204322	CIRCLIP	TATA spare parts
271126204601	SLIDING SLEEVE SYNCHRO	TATA spare parts
271126204602	HUB-FIXED RANGE SYNCHRO	TATA spare parts

271126204603	FIXED HUB 3RD/4TH	TATA spare parts
271126204604	SYNCHRO FLANGE	TATA spare parts
271126204605	SYNCHRO FLANGE	TATA spare parts
271126204606	HUB-FIXED CRAW/REV	TATA spare parts
271126204607	FIXED HUB 1ST/2ND	TATA spare parts
271126204608	SYNCHRO RING-CONE	TATA spare parts
271126204609	SLIDING 1ST/2ND/3RD/4TH	TATA spare parts
271126204610	SLIDING SLEEVE CRAWLER	TATA spare parts
271126204611	SYNCHRO RING-RANGE	TATA spare parts
271126204612	RING CONE	TATA spare parts
271126204613	FLANGE SYNCHRO CRAWLER	TATA spare parts
271126204614	SYNCHRO FLANGE -REVE (SAE 8617 )	TATA spare parts
271126204615	SLIDING SLEEVE	TATA spare parts
271126204617	SLID. SLEEVE	TATA spare parts
271126204619	FIXED HUB 1/2 - 8875571	TATA spare parts
271126204622	RING SYNCHRO	TATA spare parts
271126204624	SYNCHRO FLNAGE 1/2/3/4	TATA spare parts
271126204625	FLNAGE SYNCHRO	TATA spare parts
271126204626	FLANGE SYNCHRO	TATA spare parts
271126204628	RING SYNCHRO FLANGE	TATA spare parts
271126204629	SYNCHRO CONE ASSY 1ST/2ND SPEED	TATA spare parts
271126204630	SYNCHRO RING 1ST/2ND/CRAWLER SPEED	TATA spare parts
271126205101	COUPLING FLANGE DIN180	TATA spare parts
271126205102	COUPLING FLANGE	TATA spare parts
271126205103	SELECTOR FORK - RANGE	TATA spare parts
271126205104	COUPLING FLANGE	TATA spare parts
271126205401	SPEEDO DRIVEN GEAR	TATA spare parts
271126205402	GEAR MAINSHAFT 2ND	TATA spare parts
271126205403	GEAR MAINSHAFT 3RD	TATA spare parts
271126205404	PLANET GEAR	TATA spare parts
271126205405	SPINDLE PLANET	TATA spare parts
271126205406	GEAR MAINSHAFT CRAWLER	TATA spare parts
271126205407	GEAR MAINSHAFT REV	TATA spare parts
271126205408	GEAR MAINSHAFT 1ST	TATA spare parts
271126205409	GEAR-SUN	TATA spare parts
271126205410	GEAR MAINSHAFT 2ND	TATA spare parts
271126205411	GEAR MAINSHAFT REV	TATA spare parts
271126205413	GEAR - SPEEDO DRIVE 9T	TATA spare parts
271126205414	GEAR MAINSHAFT 3RD	TATA spare parts
271126205417	GEAR MAINSHAFT	TATA spare parts
271126205418	GEAR MAINSHAFT	TATA spare parts
271126205419	ANNULAS	TATA spare parts
271126206101	WASHER - SPEEDO ADAPTER	TATA spare parts
271126206501	NUT MOX 5	TATA spare parts
271126206502	NUT M6	TATA spare parts
271126206503	NYLOC NUT	TATA spare parts
271126206601	PISTON RANGE CYLINDER	TATA spare parts

271126206701	PLUNGER SYNCHRO ASSY	TATA spare parts
271126206702	DOWEL	TATA spare parts
271126206801	STRAIGHT ADAPTOR(BSP-TUBE 6MM)	TATA spare parts
271126206901	BUSHING PEDAL S/HOLE	TATA spare parts
271126206902	NYLON TUBE 6MM	TATA spare parts
271126207701	O RING	TATA spare parts
271126207702	O RING	TATA spare parts
271126207703	O RING	TATA spare parts
271126207704	PISTON O RING AY BAR	TATA spare parts
271126207705	O-RING	TATA spare parts
271126207708	PLATE LAYSHAFT BEARING	TATA spare parts
271126207801	OIL SEAL	TATA spare parts
271126207802	REAR COVER - OIL SEAL	TATA spare parts
271126207803	OIL SEAL - OIL PUMP 60 X 75 X 8	TATA spare parts
271126207805	OILSEAL	TATA spare parts
271126207806	OIL SEAL REAR COVER	TATA spare parts
271126207901	SPEEDO WORM	TATA spare parts
271126207902	MAINSHAFT	TATA spare parts
271126208001	SCREW M6X15 SKT HD SET	TATA spare parts
271126208002	SCREW M10X23HEXHD	TATA spare parts
271126208004	SCREW M16X45 HEX HD	TATA spare parts
271126208301	SHIM PACK	TATA spare parts
271126208302	CIRCLIP ASSY	TATA spare parts
271126208601	SPACER	TATA spare parts
271126208603	RETAINER - SUN GEAR	TATA spare parts
271126208701	SPRING COMPRESSION	TATA spare parts
271126209201	WASHER M10 PLAIN	TATA spare parts
271126209202	WASHER	TATA spare parts
271126209901	FITTING GREASE STRAIGHT	TATA spare parts
271126253101	BEARING INPUT SHAFT	TATA spare parts
271126253401	BUSHING	TATA spare parts
271126253701	FRONT BEARING COVER	TATA spare parts
271126254301	CIRCLIP	TATA spare parts
271126254302	CIRCLIP	TATA spare parts
271126254303	CIRCLIP	TATA spare parts
271126254304	CIRCLIP	TATA spare parts
271126254305	CIRCLIP	TATA spare parts
271126256901	PIN-DIA14	TATA spare parts
271126257801	OILSEAL FRONT COVER	TATA spare parts
271126257901	INPUTSHAFT	TATA spare parts
271126300101	LAYSHAFT & BEARING ASSY	TATA spare parts
271126303101	BEARING-ASSY LAYSHAFT	TATA spare parts
271126353101	NEEDLE ROLLER BEARING ASSY	TATA spare parts
271126354301	CIRCLIP	TATA spare parts
271126355401	GEAR REVERSE IDLER	TATA spare parts
271126355402	GEAR IDLER (REV)	TATA spare parts
271126357901	REVERSE IDLER SHAFT	TATA spare parts



271126358601	THRUST WASHER-REV.IDL	TATA spare parts
271126400101	ASSY SIDE MOUNTED POWER TAKE OFF	TATA spare parts
271126400102	ASSY REAR MOUNTED POWER TAKE OFF	TATA spare parts
271126400103	ASSY. PTO- EATON BS2/3	TATA spare parts
271126400104	ASSY REAR PTO LOCALISED	TATA spare parts
271126400106	ASSY. PTO	TATA spare parts
271126514801	DOWEL ODIAX 6	TATA spare parts
271126515101	FORK 1ST/2ND	TATA spare parts
271126515102	FORK CRAWLER/REVERSE	TATA spare parts
271126515103	FORK 3RD/4TH	TATA spare parts
271126515105	SELECTOR BLOCK	TATA spare parts
271126515106	FORK 3RD/4TH HH	TATA spare parts
271126515107	FORK CRAWLER/REV HH	TATA spare parts
271126515108	FORK 1ST/2ND HH	TATA spare parts
271126515109	SELECTOR BLOCK	TATA spare parts
271126515901	KEY-SELECTOR	TATA spare parts
271126515902	INTERLOCK KEY	TATA spare parts
271126517901	PIN INTERLOCK	TATA spare parts
271126517902	SELECTOR SHAFT	TATA spare parts
271126517903	HIGH/LOW RANGE SHIFT ROD	TATA spare parts
271126517905	SELECTOR SHAFT H	TATA spare parts
271126705102	YOKE SHAFT	TATA spare parts
271126710101	BREATHER	TATA spare parts
271126710102	ASSY LRC KIT LHD COMP	TATA spare parts
271126716001	OUTER LEVER	TATA spare parts
271126716002	INN STR. LEVER HH MKIV	TATA spare parts
271126716301	PLASTIC CUP FOR SERVO	TATA spare parts
271126717701	SEALING	TATA spare parts
271126717801	BOOT	TATA spare parts
271126717802	SEAL	TATA spare parts
271126717803	SEAL-LRC TO CASE	TATA spare parts
271126718701	SPRING - RANGE DETENT	TATA spare parts
271126718702	SPRING - REVERSE DETENT	TATA spare parts
271126806801	BANJO ADAPTOR	TATA spare parts
271126809901	TRANSFER LABLE (GEARSHIFT PATTERN USAGE)	TATA spare parts
271126900101	OIL PUMP ASSY	TATA spare parts
271126900102	SUCTION PIPE ASSY	TATA spare parts
271126900107	OIL PUMP ASSY	TATA spare parts
271126906101	WASHER - FILL / DRAIN FL	TATA spare parts
271126906301	BUSH	TATA spare parts
271126906901	OIL SPRAY BAR FRONT	TATA spare parts
271126906902	OIL SPRAY TUBE	TATA spare parts
271126906903	PIPE ASSY	TATA spare parts
271126907201	PLUG OIL STRAINER	TATA spare parts
271126907701	O-RING	TATA spare parts
271126907702	O-RING	TATA spare parts
271126909201	WASHER-OIL STRNIDRIN	TATA spare parts

271126980122	POWERSHIFT CYLINDER ASSY	TATA spare parts
271126980123	SYNCHRO PACK ASSY 1ST/2ND SPEED	TATA spare parts
271126980124	MAIN SHAFT ASSY	TATA spare parts
271126980125	PLANET GEAR ASSY	TATA spare parts
271126990101	SWITCH - REVERSE	TATA spare parts
271126990102	NEUTRAL SWITCH	TATA spare parts
271126990103	INTEGRATED AIR VALVE ELECTRIC BS2/3	TATA spare parts
271126990104	GASKET/SEAL KIT	TATA spare parts
271126990105	NEEDLE ROLLER BRG KIT - PLANETARY ASSY	TATA spare parts
271126990106	O RING KIT	TATA spare parts
271126990107	SYNCHRO KIT RANGE	TATA spare parts
271126990108	SYNCHRO KIT - FLANGE/RING - MAIN SECTION	TATA spare parts
271126990109	SYNCHRO KIT-FLANGE/RING-HI/LO RANGE	TATA spare parts
271126990110	SYNCHRO KIT - FLANGE/RING - HI RANGE	TATA spare parts
271126990111	SYNCHRO KIT - FLANGE/RING - LO RANGE	TATA spare parts
271126990113	SYNCHRO ASSY KIT 3RD/4TH	TATA spare parts
271126990114	HSG REVERSE GATE SWITCH	TATA spare parts
271126990115	KIT REGULATOR COVER	TATA spare parts
271126990116	RANGE INDICATOR SWITCH/NEUTRAL SWITCH	TATA spare parts
271126990117	ASSYSHAFT&LEVER	TATA spare parts
271126990119	HOUSINGASSYSHIFTBAR	TATA spare parts
271126990120	SYNCHROASSY.5/6	TATA spare parts
271126990121	SYNCHROASSY.3/4	TATA spare parts
271126990122	YOKEASSY.1ST/2ND	TATA spare parts
271126990123	CONTROL HOUSING ASSY	TATA spare parts
271126990124	CLUTCH HOUSING ASSY.	TATA spare parts
271126990125	SYNCHRONIZER ASSY. 1/2	TATA spare parts
271126990126	PTO ADAPTION KIT	TATA spare parts
271126990127	SCREW & WASHER ASSY	TATA spare parts
271126990128	AIR FILTER / REGULATOR ASSEMBLY	TATA spare parts
271126990129	CONNECTOR(12880)	TATA spare parts
271126990130	HOSE ASSY AIR (55523)	TATA spare parts
271126990131	HOSE ASSY AIR (55508)	TATA spare parts
271126990132	T CONNECTOR (22870)	TATA spare parts
271126990133	SCREW (1009773)	TATA spare parts
271126990134	GASKET CONTROL VALVE(1009733)	TATA spare parts
271126990135	WASHER PLAIN(1010442)	TATA spare parts
271126990136	O-RING(15114)	TATA spare parts
271126990137	BEARING(4302074)	TATA spare parts
271126990138	GEAR C/S AUX DRIVE(4303937)	TATA spare parts
271126990139	COUNTERSHAFT AUX(4303914)	TATA spare parts
271126990140	SPACER(21342)	TATA spare parts
271126990141	AUXILIARY COUNTERSHAFT ASSY (A-6843)	TATA spare parts
271126990142	GEAR ASSY AUX REDUCTION (A-5197)	TATA spare parts
271126990143	ROTOR/SLINGER ASSY (A-7422)	TATA spare parts
271126990144	SYNCHRONIZER ASSY HIGH(A-7331)	TATA spare parts
271126990145	SPRING(14897)	TATA spare parts

271126990146	SLIDING CLUTCH(20323)	TATA spare parts
271126990147	SYNCHRONIZER ASSY LOW SIDE(A-7254)	TATA spare parts
271126990148	SYNCHRONIZER HIGH AND LOW	TATA spare parts
271126990149	RETAINING WASHER(21350)	TATA spare parts
271126990150	RANGE GEAR	TATA spare parts
271126990151	NUT(21365)	TATA spare parts
271126990152	WASHER(21347)	TATA spare parts
271126990153	ROLL PIN	TATA spare parts
271126990154	BUSHING	TATA spare parts
271126990155	PIN	TATA spare parts
271126990156	DRIVE SHAFT(A-5156)	TATA spare parts
271126990157	SLIDING CLUTCH	TATA spare parts
271126990158	DEEP RANGE GEAR(21361)	TATA spare parts
271126990159	AUXILIARY MAINSHAFT(4303359)	TATA spare parts
271126990160	SPACER(21354)	TATA spare parts
271126990161	WASHER(21358)	TATA spare parts
271126990162	BEARING(5556503)	TATA spare parts
271126990163	SLINGER(4302323)	TATA spare parts
271126990164	O RING(5568511)	TATA spare parts
271126990165	SPEEDOMETER ROTOR(5501544)	TATA spare parts
271126990166	DIRT SHIELD(4304653)	TATA spare parts
271126990167	FLANGE COMPANION(5505629)	TATA spare parts
271126990168	OUTPUTSHAFT NUT	TATA spare parts
271126990169	HOUSING CLUTCH(1010255)	TATA spare parts
271126990170	SCREW HEX HD/WASHER ASSY (X-8C-1209M)	TATA spare parts
271126990171	SCREW HEX HD/WASHER ASSY (X-8C-1210M)	TATA spare parts
271126990172	COVER BEARING FRONT(1009577)	TATA spare parts
271126990173	SCREW(X-8-1004M)	TATA spare parts
271126990174	GASKET(14311)	TATA spare parts
271126990175	COVER HAND HOLE CLUTCH HOUSING(1009562)	TATA spare parts
271126990176	SCREW(X-8-0801M)	TATA spare parts
271126990177	SCREW HEX HEAD(X-7-1601M)	TATA spare parts
271126990178	RETAINER(1009608)	TATA spare parts
271126990179	CIRCLIP(19198)	TATA spare parts
271126990180	BEARING(4306027)	TATA spare parts
271126990181	DRIVE GEAR COUNTERSHAFT RIGHT(1009519)	TATA spare parts
271126990182	DRIVE GEAR COUNTERSHAFT LEFT(1009613)	TATA spare parts
271126990183	SLEEVE(1009541)	TATA spare parts
271126990184	3RD GEAR COUNTERSHAFT RIGHT(1009520)	TATA spare parts
271126990185	3RD GEAR COUNTERSHAFT LEFT(1009614)	TATA spare parts
271126990186	2ND GEAR COUNTERSHAFT(1009521)	TATA spare parts
271126990187	2ND GEAR COUNTERSHAFT LEFT(1009615)	TATA spare parts
271126990188	1ST GEAR COUNTERSHAFT RIGHT(1009522)	TATA spare parts
271126990189	1ST GEAR COUNTERSHAFT LEFT(1009616)	TATA spare parts
271126990190	KEY(1009539)	TATA spare parts
271126990191	KEY WOODRUFF(X-6-E)	TATA spare parts
271126990192	COUNTERSHAFT RIGHT SIDE(1009525)	TATA spare parts

271126990193	BEARING(4306029)	TATA spare parts
271126990194	CIRCLIP(4302082)	TATA spare parts
271126990195	COUNTERSHAFT LEFT SIDE(1009524)	TATA spare parts
271126990196	COVER ASSY SHIFT CYL(A-6024)	TATA spare parts
271126990197	SHIFT YOKE ASSY - RANGE(A-7931)	TATA spare parts
271126990198	SHIFT YOKE ASSY - DEEP RANGE(A-5160)	TATA spare parts
271126990199	GASKET	TATA spare parts
271126990200	CYLINDER SHIFT	TATA spare parts
271126990201	O RING	TATA spare parts
271126990202	PISTON(1010162)	TATA spare parts
271126990203	NUT(X-1-1010)	TATA spare parts
271126990204	CONNECTOR(85003)	TATA spare parts
271126990205	COVER CYLINDER(21329)	TATA spare parts
271126990206	GASKET	TATA spare parts
271126990207	NUT(X-1-803)	TATA spare parts
271126990208	SCREW HEX HD FLANGE(X-8-1027M)	TATA spare parts
271126990209	O RING	TATA spare parts
271126990210	PISTON	TATA spare parts
271126990211	O RING	TATA spare parts
271126990212	O RING(14644)	TATA spare parts
271126990213	PLUG(15719)	TATA spare parts
271126990214	PLUNGER(19974)	TATA spare parts
271126990215	GASKET	TATA spare parts
271126990216	FRONT HOUSING(1010195)	TATA spare parts
271126990217	DOWEL(5575515)	TATA spare parts
271126990218	STUD(5577504)	TATA spare parts
271126990219	NUT HEX SELF LOCKING(X-1-1606M)	TATA spare parts
271126990220	GUIDE PIN(18128)	TATA spare parts
271126990221	FILLER / DRAIN PLUG(1009587)	TATA spare parts
271126990222	GASKET(4305310)	TATA spare parts
271126990223	SCREW(X-8-1200M)	TATA spare parts
271126990224	PLUG PIPE 1/2(X12-802)	TATA spare parts
271126990225	STUD(5577509)	TATA spare parts
271126990226	OIL DEFLECTOR(1010029)	TATA spare parts
271126990227	GASKET(4305309)	TATA spare parts
271126990228	COVER PTO(14575)	TATA spare parts
271126990229	SCREW(X-8-1002M)	TATA spare parts
271126990230	CIRCLIP(16980)	TATA spare parts
271126990231	BEARING(4301417)	TATA spare parts
271126990232	SPACER(16463)	TATA spare parts
271126990233	CIRCLIP(14750)	TATA spare parts
271126990234	MAIN DRIVE GEAR(1009512)	TATA spare parts
271126990235	INPUT SHAFT(1009661)	TATA spare parts
271126990236	BUSHING(16566)	TATA spare parts
271126990237	SNAP RING(4303336)	TATA spare parts
271126990238	REVERSE IDLER SHAFT(1009580)	TATA spare parts
271126990239	THRUST WASHER(4302982)	TATA spare parts

271126990240	NEEDLE ROLLER BEARING(4306028)	TATA spare parts
271126990241	REVERSE IDLER GEAR(16757)	TATA spare parts
271126990242	SEAL(23559)	TATA spare parts
271126990243	SCREW (1009709)	TATA spare parts
271126990244	COVER TOP LRC (1009704)	TATA spare parts
271126990245	GASEKT TOP COVER (1009705)	TATA spare parts
271126990246	SHAFT SELECT (1009706)	TATA spare parts
271126990247	O-RING (1009778)	TATA spare parts
271126990248	KEY (1009835)	TATA spare parts
271126990249	FINGER SELECT (1009703)	TATA spare parts
271126990250	WASHER SELECT SHAFT (1009708)	TATA spare parts
271126990251	SCREW (1009822)	TATA spare parts
271126990253	LOCKWASHER (1009858)	TATA spare parts
271126990255	GASKET FENCE SPRING CAP (1009744)	TATA spare parts
271126990256	SPRING COMPRESSION (1009743)	TATA spare parts
271126990258	BREATHER (4304602)	TATA spare parts
271126990259	SCREW (1009770)	TATA spare parts
271126990260	PLATE END (1009751)	TATA spare parts
271126990261	GASKET END PLATE (1009754)	TATA spare parts
271126990262	SPRING COMPRESSION (1009741)	TATA spare parts
271126990264	PIN ROLL (1009774)	TATA spare parts
271126990268	SPRING COMPRESSION (1009765)	TATA spare parts
271126990270	BUSHING (1009732)	TATA spare parts
271126990273	SLEEVE SPLINED CROSS SHAFT (1009697)	TATA spare parts
271126990275	SEAL OIL (1009734)	TATA spare parts
271126990276	GASKET END COVER (1009702)	TATA spare parts
271126990278	LEVER OUTER (1009738)	TATA spare parts
271126990279	NUT (1009825)	TATA spare parts
271126990280	SCREW (1009767)	TATA spare parts
271126990282	PIN RETAINING (1009696)	TATA spare parts
271126990283	SWITCH NEUTRAL (1009665)	TATA spare parts
271126990284	SWITCH REVERSE (1009666)	TATA spare parts
271126990285	WASHER REVERSE SWITCH (1009595)	TATA spare parts
271126990286	WASHER NEUTRAL SWITCH (1009594)	TATA spare parts
271126990287	LOCKWASHER (1009856)	TATA spare parts
271126990288	STUD (5577508)	TATA spare parts
271126990289	NUT HEX SPECIAL (X-1-1005M)	TATA spare parts
271126990290	NUT JAM (X-1-1004M)	TATA spare parts
271126990292	KEY (1009538)	TATA spare parts
271126990293	SYNCHRO CUP (1009537)	TATA spare parts
271126990294	SYNCHRONIZER (A-7716)	TATA spare parts
271126990295	LOW GEAR MAINSHAFT (1009516)	TATA spare parts
271126990296	SLIDING CLUTCH (1009518)	TATA spare parts
271126990297	REVERSE GEAR MAINSHAFT (1009517)	TATA spare parts
271126990298	WASHER (1009540)	TATA spare parts
271126990299	SPACER (1009548)	TATA spare parts
271126990300	CIRCLIP (1009549)	TATA spare parts

271126990301	SPACER (1009550)	TATA spare parts
271126990302	3RD GEAR MAINSHAFT (1009513)	TATA spare parts
271126990303	2ND GEAR MAINSHAFT (1009514)	TATA spare parts
271126990304	1ST GEAR MAINSHAFT (1009515)	TATA spare parts
271126990305	SYNCHRONIZER ASSY (A-8204)	TATA spare parts
271126990306	BEARING ASSEMBLY AUX DRIVE (A-7699)	TATA spare parts
271126990307	BEARING HUB (1009543)	TATA spare parts
271126990308	BEARING (5566507)	TATA spare parts
271126990309	RETAINER PLATE (1009563)	TATA spare parts
271126990310	SCREW (X-8-1003M)	TATA spare parts
271126990311	AUXILIARY DRIVE GEAR (1010089)	TATA spare parts
271126990312	CIRCLIP (1009542)	TATA spare parts
271126990313	PTO ASSY (E-1064-074)	TATA spare parts
271126990314	COVER ASSEMBLY REAR BEARING(3002106)	TATA spare parts
271126990315	GASKET	TATA spare parts
271126990316	REAR HOUSING (1010223)	TATA spare parts
271126990317	SCREW HEX HD WASHER ASSY (X-8C-1043M)	TATA spare parts
271126990318	PLUG (21073)	TATA spare parts
271126990319	SCREW HEX HD/WASHER ASSY (X-8C-1038M)	TATA spare parts
271126990320	SHIM 0.915 / 0.939 MM	TATA spare parts
271126990321	SHIM 0.991 / 1.016 MM	TATA spare parts
271126990322	SHIM 1.067 / 1.092 MM	TATA spare parts
271126990323	SHIM 1.143 / 1.168 MM	TATA spare parts
271126990324	SHIM 1.296 / 1.320 MM	TATA spare parts
271126990325	SHIM 1.372 / 1.397 MM	TATA spare parts
271126990326	SHIM 1.448 / 1.473 MM	TATA spare parts
271126990327	SHIM 1.524 / 1.549 MM	TATA spare parts
271126990328	SHIM 1.601 / 1.625 MM	TATA spare parts
271126990329	SHIM 1.677 / 1.701 MM	TATA spare parts
271126990330	SHIM 1.753 / 1.778 MM	TATA spare parts
271126990331	SHIM (23151)	TATA spare parts
271126990332	SHIM 0.838 / 0.863 MM	TATA spare parts
271126990333	GASKET	TATA spare parts
271126990334	REAR COVER AUXILIARY COUNTERSHAFT(430232)	TATA spare parts
271126990335	LIFTING EYE (20815)	TATA spare parts
271126990336	GASKET	TATA spare parts
271126990337	COVER REAR BEARING (3002107)	TATA spare parts
271126990338	SPEDO PICKUP (X8880925)	TATA spare parts
271126990339	O RING(14142)	TATA spare parts
271126990340	ELECTRONIC SENSOR MODULE(A-7449)	TATA spare parts
271126990341	OIL SEAL	TATA spare parts
271126990343	HOUSING SHIFT BAR(1009501)	TATA spare parts
271126990344	GASKET	TATA spare parts
271126990345	SCREW HEX HD WASHER ASSY (X-8C-1030M)	TATA spare parts
271126990346	GASKET(4305294)	TATA spare parts
271126990347	BALL STEEL 3/4 (X14-1200)	TATA spare parts
271126990348	INTERLOCK PIN (1634)	TATA spare parts

271126990349	BALL STEEL 1/2 (X14-800)	TATA spare parts
271126990350	SPRING POS FINDER (1069)	TATA spare parts
271126990351	BAR YOKE(1009502)	TATA spare parts
271126990352	SCREW(1009569)	TATA spare parts
271126990353	YOKE (1009506)	TATA spare parts
271126990354	PLUG (1009556)	TATA spare parts
271126990355	SPRING (8774)	TATA spare parts
271126990356	PLUNGER SHIFT DETENT (F99671)	TATA spare parts
271126990357	YOKE PAD (2770138)	TATA spare parts
271126990358	SHIFT YOKE 3RD / 4TH (1009510)	TATA spare parts
271126990359	BAR YOKE (1009504)	TATA spare parts
271126990360	BLOCK (1009554)	TATA spare parts
271126990361	YOKE (1009508)	TATA spare parts
271126990362	BAR YOKE (1009503)	TATA spare parts
271126990363	ELBOW (12845)	TATA spare parts
271126990365	RING SYNCHRO 1ST/2ND	TATA spare parts
271126990372	SYNCHRONIZER ASSY. 5/6 (A-6608)	TATA spare parts
271126990392	GASKET	TATA spare parts
271126990396	RANGE ACTUATOR	TATA spare parts
271126990401	GASKET	TATA spare parts
271126990470	4/2 AIR ACTUATING VALVE (X8880844)	TATA spare parts
271126990603	SYNCHRO CONE ASSY	TATA spare parts
271126990609	CONTROL BOX ASSY	TATA spare parts
271126993001	DETENT BALL	TATA spare parts
271126993002	SWITCH BALL	TATA spare parts
271126993003	INA DETENT M16	TATA spare parts
271126993004	STEELBALL	TATA spare parts
271126993005	RETAINERBALL	TATA spare parts
271126993006	STEEL BALL	TATA spare parts
271126993101	BEARING-SYNCHRO HUB	TATA spare parts
271126993102	FRONT BEARING COVER	TATA spare parts
271126993104	NEEDLE ROLLER BEARING	TATA spare parts
271126993105	CONEBEARING	TATA spare parts
271126993106	CONEBRG	TATA spare parts
271126993107	CUPBRG	TATA spare parts
271126993108	BEARINGNEEDLE	TATA spare parts
271126993109	BEARINGNEEDLE	TATA spare parts
271126993110	BEARINGROLLER	TATA spare parts
271126993111	BEARING CONE	TATA spare parts
271126993112	BEARING	TATA spare parts
271126993113	BEARING	TATA spare parts
271126993114	BEARING	TATA spare parts
271126993115	CONE BEARING	TATA spare parts
271126993116	BEARING CUP	TATA spare parts
271126993117	BEARING CONE	TATA spare parts
271126993118	BEARING CUP	TATA spare parts
271126993119	BEARING	TATA spare parts

271126993120	BEARING	TATA spare parts
271126993121	CONE BEARING	TATA spare parts
271126993122	CUP BEARING	TATA spare parts
271126993127	NEEDLE ROLLER BEARING	TATA spare parts
271126993128	NEEDLE BEARING	TATA spare parts
271126993201	BOLT M10X65HEX FLG HD	TATA spare parts
271126993202	BOLT M10X45 HEX FLG HD	TATA spare parts
271126993203	BOLT M10X58 FLG HD	TATA spare parts
271126993204	BOLT M10X70 HEX FLG HD	TATA spare parts
271126993205	BOLT M10X45 HEX FLG HD	TATA spare parts
271126993207	SCREW (BOLT) M8X65 HEX FLG HD	TATA spare parts
271126993208	BOLT M10X40 HEX HD	TATA spare parts
271126993210	BOLT (M10X40)	TATA spare parts
271126993211	BANJO BOLT G1/4	TATA spare parts
271126993212	BOLT (M10X60)	TATA spare parts
271126993213	BOLT M18X90 HEX FLANGE HEAD	TATA spare parts
271126993214	BOLT FLG HD (M18X75) C/HSG	TATA spare parts
271126993215	BOLT M14X45 HEX HD	TATA spare parts
271126993216	BOLT	TATA spare parts
271126993217	BOLT	TATA spare parts
271126993218	BOLT	TATA spare parts
271126993219	BOLT	TATA spare parts
271126993226	BOLT	TATA spare parts
271126993401	BUSH	TATA spare parts
271126993402	BUSH	TATA spare parts
271126993403	BUSH ADAPTOR	TATA spare parts
271126993404	ADAPTOR BUSH	TATA spare parts
271126993405	BUSH FLANGED	TATA spare parts
271126993406	BUSH	TATA spare parts
271126993407	BUSH	TATA spare parts
271126993408	BUSH FLANGED	TATA spare parts
271126993409	BUSH	TATA spare parts
271126993701	COVER	TATA spare parts
271126993702	CONTROLHOUSING	TATA spare parts
271126993802	SPEEDO HOUSING ELECTRONIC	TATA spare parts
271126993803	CROSS GATE HOUSING	TATA spare parts
271126993804	CLUTCH HOUSING	TATA spare parts
271126993805	LRC HOUSING	TATA spare parts
271126993806	CROSS GATE HOUSING	TATA spare parts
271126993808	REAR CASE	TATA spare parts
271126993810	FRONT CASE	TATA spare parts
271126993812	FRONT CASE ASSY	TATA spare parts
271126993813	PTO & QUILL SHAFT ASSY	TATA spare parts
271126993814	PTO ASSY	TATA spare parts
271126993815	QUILL SHAFT ASSY	TATA spare parts
271126993816	FRONT CASE	TATA spare parts
271126993818	CUP PLUG	TATA spare parts



271126993819	INTERMEDIATE CASE ASSY	TATA spare parts
271126993820	OIL STRAINER ASSEMBLY	TATA spare parts
271126993821	FRONT CASE	TATA spare parts
271126993822	INTERMEDIATE CASE	TATA spare parts
271126993824	SPEEDO HOUSING ELEC.	TATA spare parts
271126993830	SPEEDO HOUSING MECH.( REAR COVER-HORIZ.S	TATA spare parts
271126994201	CLAMP	TATA spare parts
271126994202	CLAMP(11665)	TATA spare parts
271126994301	GRADED CIRCLIP PACK	TATA spare parts
271126994302	GRADED CIRCLIP PACK	TATA spare parts
271126994303	CIRCLIP-GRADED PACK	TATA spare parts
271126994304	CIRCLIP	TATA spare parts
271126994305	CIRCLIP M90	TATA spare parts
271126994306	CIRCLIP M5	TATA spare parts
271126994307	CIRCLIP PACK GRADED	TATA spare parts
271126994308	CIRCLIP PACK GRADED	TATA spare parts
271126994309	CIRCLIP	TATA spare parts
271126994310	PIPE CLIP - TWIN PIPE	TATA spare parts
271126994311	PIPE CLIP	TATA spare parts
271126994313	CIRCLIP	TATA spare parts
271126994328	CIRCLIP	TATA spare parts
271126994329	SNAPRING	TATA spare parts
271126994330	SNAPRING	TATA spare parts
271126994331	SNAP RING	TATA spare parts
271126994332	SNAP RING	TATA spare parts
271126994333	SNAP RING	TATA spare parts
271126994334	SNAP RING	TATA spare parts
271126994601	SLIDE RING	TATA spare parts
271126994602	PPA ASSY 55/20 LIFTER24	TATA spare parts
271126994603	FLANGE SYNCH. CRWL/REVERSE	TATA spare parts
271126994604	SYNCHRO RING BS3	TATA spare parts
271126994605	SYNCHRO FLANGE	TATA spare parts
271126994606	CLUTCHSLG(REV)	TATA spare parts
271126994607	HUBCLUTCH(REV)	TATA spare parts
271126994608	HUBCLUTCH3RD&4TH	TATA spare parts
271126994609	HUBCLUTCH5TH&6TH	TATA spare parts
271126994610	CLUTCH HUB REVERSE	TATA spare parts
271126994611	POWERSHIFT CYLINDER ASSY	TATA spare parts
271126994702	COVER C.H	TATA spare parts
271126994703	DETENT COVER	TATA spare parts
271126994704	LAYSHAFT REAR COVER	TATA spare parts
271126994705	REVERSE GEAR COVER	TATA spare parts
271126994706	REVISION WINDOW COVER	TATA spare parts
271126994707	INSPECTION COVER CLUTCHHSG	TATA spare parts
271126994708	COVER	TATA spare parts
271126994709	PTO COVER	TATA spare parts
271126994710	DETENT COVER	TATA spare parts

271126994713	CASE	TATA spare parts
271126994714	COVERBEARINGFRONT	TATA spare parts
271126994716	COVER PTO	TATA spare parts
271126994717	REARBEARINGCOVER	TATA spare parts
271126994718	PTOPROVISIONCOVER	TATA spare parts
271126994719	RETAINER PLATE	TATA spare parts
271126994720	COVER BEARING	TATA spare parts
271126994801	DOWEL	TATA spare parts
271126994802	DOWEL	TATA spare parts
271126994803	DOWELL	TATA spare parts
271126994904	PIN - REVERSE GATE SWITCH	TATA spare parts
271126994905	IMPULSE TRANSMITTER	TATA spare parts
271126995101	LIFTING EYE 15 MM	TATA spare parts
271126995102	CLUTCH RELEASE FORK ASSY	TATA spare parts
271126995103	SELECTOR BLOCK ASSY	TATA spare parts
271126995104	FORK 3RD/4TH	TATA spare parts
271126995105	SELECTOR OVERDRIVE	TATA spare parts
271126995106	FORK OVERDRIVE	TATA spare parts
271126995108	INNER STRIKING FINGER	TATA spare parts
271126995110	SELECTOR BLOCK	TATA spare parts
271126995111	SELECTOR OVERDRIVE	TATA spare parts
271126995112	FORK OVERDRIVE	TATA spare parts
271126995114	COIL ASSY	TATA spare parts
271126995115	INNER STRIKING FINGER	TATA spare parts
271126995116	CUPSYN	TATA spare parts
271126995117	EYELIFTING	TATA spare parts
271126995118	FINGERINNERSHIFT	TATA spare parts
271126995119	COUPLING FLANGE	TATA spare parts
271126995120	SYNCHRO CUP 5/6	TATA spare parts
271126995121	COUPLING FLANGE	TATA spare parts
271126995123	ANNULUS ASSY	TATA spare parts
271126995124	SCREW	TATA spare parts
271126995126	INNER SHIFT LEVER	TATA spare parts
271126995130	WEIGHT SELECTER SHIFTER SHAFT ASSY	TATA spare parts
271126995131	SELECTIOR SHIFTER SHAFT ASSY	TATA spare parts
271126995132	SELECTOR BLOCK	TATA spare parts
271126995301	GASKET	TATA spare parts
271126995302	GASKET	TATA spare parts
271126995303	GASKET	TATA spare parts
271126995304	GASKET	TATA spare parts
271126995305	GASKETFRONTBRGCOVER	TATA spare parts
271126995306	GASKETSHIFTSHAFTBAR	TATA spare parts
271126995307	GASKETSHIFTLEVERHSG	TATA spare parts
271126995401	GEAR MAINSHAFT- REVERSE	TATA spare parts
271126995402	GEAR MAINSHAFT- CRAWLER	TATA spare parts
271126995403	GEAR REVERSE IDLER	TATA spare parts
271126995404	REVERSE GEAR APERTURE COVER	TATA spare parts

271126995405	3RD GEAR M.S	TATA spare parts
271126995406	DRIVEN GEAR	TATA spare parts
271126995407	DRIVE GEAR	TATA spare parts
271126995408	GEAR4TH	TATA spare parts
271126995409	GEAR 5TH	TATA spare parts
271126995411	GEARC/S3RD	TATA spare parts
271126995412	GEARC/S4TH	TATA spare parts
271126995413	GEARC/SDRIVE	TATA spare parts
271126995414	GEAR1ST	TATA spare parts
271126995415	GEAR 2ND	TATA spare parts
271126995416	GEAR 3RD	TATA spare parts
271126995417	GEARREVERSEIDLER	TATA spare parts
271126995418	5TH GEAR C/S	TATA spare parts
271126995423	5TH GEAR M/S (OVERDRIVE) (4304543)	TATA spare parts
271126995424	REVERSE GEAR M.S	TATA spare parts
271126995501	FIXED HUB 1ST/2ND	TATA spare parts
271126995502	HUB FIXED CRAWLER/REVERSE	TATA spare parts
271126995801	HOSE ASSY AIR (55526)	TATA spare parts
271126995901	KEY SELECTOR	TATA spare parts
271126995902	KEY INTERLOCK	TATA spare parts
271126995903	KEY SELECTOR	TATA spare parts
271126995904	KEY INTERLOCK	TATA spare parts
271126996001	LEVER OUTPUT PPA	TATA spare parts
271126996002	LEVER INPUT	TATA spare parts
271126996003	LEVER INNER CROSS GATE	TATA spare parts
271126996004	INNER STRIKING FINGER 2 LEVER SINGLE H	TATA spare parts
271126996005	OUTER LEVER DUAL TAPER	TATA spare parts
271126996006	LEVER OUTER NFG	TATA spare parts
271126996007	INNER STRIKING LEVER	TATA spare parts
271126996009	LEVER GEAR SHIFT	TATA spare parts
271126996301	PAD	TATA spare parts
271126996302	PAD	TATA spare parts
271126996303	PLASTIC CUP FOR SERVO	TATA spare parts
271126996501	NUT	TATA spare parts
271126996503	NUTJAM1/2-20	TATA spare parts
271126996504	NUT NYLOC M39	TATA spare parts
271126996505	LOCK NUT	TATA spare parts
271126996601	PISTON	TATA spare parts
271126996602	PISTON	TATA spare parts
271126996701	SPRING COMPRESSION	TATA spare parts
271126996702	PARALLEL GROOVED PIN	TATA spare parts
271126996703	PIN ROLL	TATA spare parts
271126996704	ROTATION PIN	TATA spare parts
271126996705	PLUNGER	TATA spare parts
271126996706	PININTLKCROSS	TATA spare parts
271126996707	PLUNGERLATCH(REV)	TATA spare parts
271126996708	RETAINERSHIFTBAR	TATA spare parts

271126996801	SWIVEL ELBOW ADAPTOR 45DEG	TATA spare parts
271126996802	ELBOW ARTICULATED	TATA spare parts
271126996803	SWIVEL ELBOW ADAPTOR 90DEGREE	TATA spare parts
271126996804	BANJO ADAPTOR G1/4 TO 8MMTUBE	TATA spare parts
271126996805	BANJO FITTING	TATA spare parts
271126996806	SWIVEL ELBOW ADAPTOR	TATA spare parts
271126996807	SWIVEL ELBOW ADAPTOR 90 DEGREE	TATA spare parts
271126996809	AIR ADAPTOR PTO	TATA spare parts
271126996901	PIPE-OILSUCTION	TATA spare parts
271126996902	OIL SUCTION PIPE	TATA spare parts
271126997101	PLATE-RETAINER	TATA spare parts
271126997102	REACTION PLATE	TATA spare parts
271126997103	RETENTION PLATE	TATA spare parts
271126997105	OIL TUBE REAR	TATA spare parts
271126997201	OIL FILLER PLUG	TATA spare parts
271126997202	PLUG CORE OIL RESTRIC	TATA spare parts
271126997206	MAGNETIC PLUG (M24)	TATA spare parts
271126997209	PLUGEXPANSION1	TATA spare parts
271126997210	PLUGFRONTC/	TATA spare parts
271126997211	PLUGMAGCDRAIN3/4	TATA spare parts
271126997212	PLUGPIPE3/4MAGD	TATA spare parts
271126997213	PLUG	TATA spare parts
271126997701	O-RING	TATA spare parts
271126997702	O-RING	TATA spare parts
271126997705	PISTON SEALING	TATA spare parts
271126997706	OIL SEAL OIL PUMP 60X75X8	TATA spare parts
271126997707	OIL SEAL	TATA spare parts
271126997708	O RING	TATA spare parts
271126997709	O RING	TATA spare parts
271126997710	O RING	TATA spare parts
271126997711	SEALING	TATA spare parts
271126997712	BOOT	TATA spare parts
271126997713	SEALOIL-SHIFTBARHSG	TATA spare parts
271126997714	SEALOIL(FRONTBRGCVR)	TATA spare parts
271126997715	SEAL BUSHING CLUTCH HOUSING	TATA spare parts
271126997716	BUSHING	TATA spare parts
271126997801	OILSEAL-CROSSSHAFT	TATA spare parts
271126997802	O-RING	TATA spare parts
271126997803	OILSEAL	TATA spare parts
271126997807	OIL SEAL BEARING COVER REAR	TATA spare parts
271126997808	OIL SEAL LRC TOWER	TATA spare parts
271126997901	CROSS SHAFT	TATA spare parts
271126997902	LAYSHAFT ASSY	TATA spare parts
271126997903	MAINSHAFT	TATA spare parts
271126997904	SELECTOR SHAFT	TATA spare parts
271126997905	INPUT SHAFT	TATA spare parts
271126997906	REVERSE IDLER SHAFT	TATA spare parts

271126997907	SELECTOR SHAFT	TATA spare parts
271126997908	CROSS SHAFT INPUT	TATA spare parts
271126997909	SHAFT CROSS GATE	TATA spare parts
271126997910	INPUT SHAFT	TATA spare parts
271126997911	LAY SHAFT	TATA spare parts
271126997912	SELECTOR SHAFT	TATA spare parts
271126997913	SELECTOR SHAFT	TATA spare parts
271126997914	SELECTOR SHAFT	TATA spare parts
271126997915	YOKE SHAFT	TATA spare parts
271126997916	LAYSHAFT	TATA spare parts
271126997917	SELECTOR SHAFT	TATA spare parts
271126997918	BLOCKSHIFT(REV)	TATA spare parts
271126997919	GEARMAINSHAFT(REV)-UNQ-DOM	TATA spare parts
271126997920	MAINSHAFT	TATA spare parts
271126997921	INPUT SHAFT	TATA spare parts
271126997922	REVERSEIDLERSHAFT	TATA spare parts
271126997923	SHIM0.508	TATA spare parts
271126997926	COUNTERSHAFT	TATA spare parts
271126997927	BARYOKE	TATA spare parts
271126997928	BLOCKSHIFT(1ST/2ND)	TATA spare parts
271126997929	YOKESHIFT(REV)	TATA spare parts
271126997930	YOKE PAD	TATA spare parts
271126997931	YOKE BAR 3RD/4TH	TATA spare parts
271126997932	YOKE BAR 5TH/6TH	TATA spare parts
271126997933	YOKE BAR 1ST/2ND	TATA spare parts
271126997934	INPUTSHAFT	TATA spare parts
271126997935	PIN	TATA spare parts
271126997936	PIN	TATA spare parts
271126997937	YOKEASSY.5TH/6TH	TATA spare parts
271126997938	YOKE ASSY. 3RD/4TH	TATA spare parts
271126997952	SHIFTER SHAFT	TATA spare parts
271126997953	COUNTER SHAFT	TATA spare parts
271126997954	PLANET CARRIER	TATA spare parts
271126998001	SCREW M12X60HEXFLGHD	TATA spare parts
271126998002	SCREW M8X25HEXHD	TATA spare parts
271126998003	SCREW M8X20	TATA spare parts
271126998004	SCREW	TATA spare parts
271126998005	SCREW	TATA spare parts
271126998006	SCREW	TATA spare parts
271126998007	SCREW M10X30 HEX FLG HD	TATA spare parts
271126998008	SCREW M12X25 HEX HD	TATA spare parts
271126998009	SCREW M12X35	TATA spare parts
271126998010	SCREW M8X30 CTSK HD	TATA spare parts
271126998011	SCREW M10X35 CTSK HD	TATA spare parts
271126998012	SCREW	TATA spare parts
271126998013	SCREW HEX FLG HD (M12X25)	TATA spare parts
271126998014	SCREW M8X12	TATA spare parts

271126998015	SCREW M6X20	TATA spare parts
271126998016	SCREW M16X45	TATA spare parts
271126998017	SCREW	TATA spare parts
271126998018	SCREW	TATA spare parts
271126998019	SOCKET HD CAP SCREW	TATA spare parts
271126998023	SCREW	TATA spare parts
271126998028	SCREWLOCK3/8-24	TATA spare parts
271126998029	WIRELOCKSCREW	TATA spare parts
271126998030	CAPSCREW	TATA spare parts
271126998031	SCREW	TATA spare parts
271126998032	CAPSCREW	TATA spare parts
271126998033	SCREW	TATA spare parts
271126998034	CAPSCREW	TATA spare parts
271126998035	CAPSCREW	TATA spare parts
271126998036	SCREW	TATA spare parts
271126998037	SCREW	TATA spare parts
271126998043	HEX SCREW	TATA spare parts
271126998044	SCREW	TATA spare parts
271126998201	SHIELD DIRT	TATA spare parts
271126998202	SHIELD DIRT	TATA spare parts
271126998203	LIFTING EYE 15 MM	TATA spare parts
271126998208	RETAINER	TATA spare parts
271126998305	SHIM	TATA spare parts
271126998306	SHIM PACK	TATA spare parts
271126998307	SHIM 0.102	TATA spare parts
271126998308	SHIM 0.178	TATA spare parts
271126998309	SHIM 0.254	TATA spare parts
271126998310	SHIM 0.508	TATA spare parts
271126998311	SHIM 0.102	TATA spare parts
271126998312	SHIM 0.178	TATA spare parts
271126998313	SHIM 0.254	TATA spare parts
271126998314	SHIM 1.016	TATA spare parts
271126998315	SHIM 1.016	TATA spare parts
271126998401	SLEEVE MAINSHAFT	TATA spare parts
271126998402	SLEEVE-SLIDING 1ST/2ND AND 3RD	TATA spare parts
271126998403	SLEEVE MAINSHAFT BEARING	TATA spare parts
271126998404	SLIDING SLEEVE	TATA spare parts
271126998601	SPACER-REV.IDLER BRG	TATA spare parts
271126998602	SPACER DIA 79.5X6.1	TATA spare parts
271126998603	SPACER	TATA spare parts
271126998604	SPACER	TATA spare parts
271126998605	SPACER	TATA spare parts
271126998627	SCREWHEXHEAD(5/8-11X3)	TATA spare parts
271126998628	SPACER	TATA spare parts
271126998629	SPACER	TATA spare parts
271126998631	SPACER	TATA spare parts
271126998701	SPRING-COMPRESSION	TATA spare parts

271126998702	SPRING RETAINER-BOOST	TATA spare parts
271126998703	SPRING RETAINER	TATA spare parts
271126998704	WASHER SPRING	TATA spare parts
271126998705	SPRING WASHER	TATA spare parts
271126998706	SPRING COMPRESSION	TATA spare parts
271126998707	BOOSTER SPRING	TATA spare parts
271126998708	SPRING-COMPRESSION	TATA spare parts
271126998709	SPRING REV DETENT	TATA spare parts
271126998710	SPRING COMPRESSION	TATA spare parts
271126998711	SPRING	TATA spare parts
271126998712	SPRING COMPRESSION	TATA spare parts
271126998714	SPRING	TATA spare parts
271126998715	SPRING COMPRESSION	TATA spare parts
271126998716	SPRING RANGE DETENT	TATA spare parts
271126998717	SPRING-REVERSE DETENT	TATA spare parts
271126998718	SPRING	TATA spare parts
271126998719	SPRINGCOMPRESSION	TATA spare parts
271126998720	SHIFTBARRETAINER	TATA spare parts
271126998721	SPRING	TATA spare parts
271126998722	SPRING	TATA spare parts
271126998801	STUD	TATA spare parts
271126998802	STUD	TATA spare parts
271126998806	STUD	TATA spare parts
271126999001	RANGE VALVE (F96387)	TATA spare parts
271126999201	THRUST WASHER HSHAF	TATA spare parts
271126999202	THRUST WASHER	TATA spare parts
271126999203	WASHER	TATA spare parts
271126999204	THRUST WASHER M SHAFT REAR BEARING	TATA spare parts
271126999206	FINGER SPRING WASHER	TATA spare parts
271126999207	SPRING WASHER	TATA spare parts
271126999208	WASHER G 1/4	TATA spare parts
271126999209	WASHER M6 SPRING	TATA spare parts
271126999210	FINGER SPRING WASHER(ZX8878908)	TATA spare parts
271126999212	WASHER	TATA spare parts
271126999213	CENTERING RING	TATA spare parts
271126999214	SPRING WASHER	TATA spare parts
271126999216	WASHER	TATA spare parts
271126999217	WASHER1-5/8	TATA spare parts
271126999218	WASHERLATCHPLUNGER	TATA spare parts
271126999219	WASHERMAINSHAFT	TATA spare parts
271126999220	WASHERSPRINGBRACKET	TATA spare parts
271126999222	WASHER	TATA spare parts
271126999223	THRUST WASHER	TATA spare parts
271126999401	KEYWOODRUFF(C/S)	TATA spare parts
271126999601	LOCKWASHER5/8PLAIN	TATA spare parts
271126999602	WASHER	TATA spare parts
271126999901	DISC MAGNET	TATA spare parts

271126999903	INNER STRIKING FINGER	TATA spare parts
271126999904	END CAP	TATA spare parts
271126999905	DETENT PLUNGER	TATA spare parts
271126999906	LIFTING EYE	TATA spare parts
271126999907	CUP PLUG	TATA spare parts
271126999908	EXPANSION PLUG	TATA spare parts
271126999909	PLUG M6	TATA spare parts
271126999910	PLUGDETENT	TATA spare parts
271126999911	SELECTOR BLOCK ASSY.	TATA spare parts
271126999912	PLANET GEAR ASSY	TATA spare parts
271126999914	SERVIVE KIT	TATA spare parts
271126999915	DIRT SHIELD	TATA spare parts
271126999916	STRAINER-OIL	TATA spare parts
271126999917	REATINER	TATA spare parts
271126999918	OIL PUMP ASSY FOR OIL COOLER	TATA spare parts
271126999919	TACHOGRAPH ROTOR	TATA spare parts
271126999920	LRC SUBASSY LH	TATA spare parts
271126999921	ADAPTOR CROSS GATE	TATA spare parts
271126999925	LRC ASSY	TATA spare parts
271126999926	STUD KIT	TATA spare parts
271126999927	PTO HSG. KIT	TATA spare parts
271126999931	POWER TAKE OFF ASSY	TATA spare parts
271126999934	BREATHER (7935)	TATA spare parts
271126999935	ROTORSPEEDOMETER	TATA spare parts
271126999938	REVERSESWITCH	TATA spare parts
271126999939	ADAPTOR	TATA spare parts
271126999940	FITTING	TATA spare parts
271126999941	SPEEDOSENSOR	TATA spare parts
271126999942	SCREW HEX HD/WASHER ASSY (X-8C-412)	TATA spare parts
271126999944	INTEGRATED AIR VALVE ELECTRIC	TATA spare parts
271126999946	SPEEDO SENSOR	TATA spare parts
271126999947	SPEED SENSOR	TATA spare parts
271126999950	OIL PUMP ASSY	TATA spare parts
271126999953	COVER TOP	TATA spare parts
271126999954	TACHOGRAPH ROTOR	TATA spare parts
271433358201	INNER SLINGER	TATA spare parts
271526010110	ASSY. GEAR BOX G1400 PTO W/O P/S BS3	TATA spare parts
271526010112	ASSY. GEARBOX COMP. G1150-9/12.86 BS3/4	TATA spare parts
271526010114	ASSY COMP G1400-9/9.371 OD 1-3/4IN SAE-1	TATA spare parts
271526010116	GB-1150/12.86-1.75-LS-NPS-PTO-150CF-NC	TATA spare parts
271526010120	GB-1150/12.86/9 DD 2INCHDRSH PTON	TATA spare parts
271526010125	ASSY. G1150-9/9.37 1.75INC SAE-1 DIA 150	TATA spare parts
271526010127	GEAR BOX (FOR RTA1624) G1150/12.86 2	TATA spare parts
271526010129	ASSY GEAR BOX G1150-9 SPEED DIRECT DRIVE	TATA spare parts
271526010129AE	GEAR BOX G1400-9/12.86 PTO 1828	TATA spare parts
271526010132	ASSY. GEAR BOX G1150-9 SPEED PTO BS2	TATA spare parts
271526010133	ASSY. GEAR BOX G1150-9 SPEED BS2	TATA spare parts



271526010134	ASSY GEARBOX G1150/12.86 2 IN D/S W/O	TATA spare parts
271526010135	ASSY GEARBOX G1150/12.86 2 D/S W/O P/S 1	TATA spare parts
271526010139	ASSY GEARBOX G1150/9.371 2 D/S W/O P/S	TATA spare parts
271526010147	GEAR BOX G1150-9 SPEED DD 12.86;1.75IN;D	TATA spare parts
271526010149	GEAR BOX G1150-9SPEED OD 9.371 2 DIA150	TATA spare parts
271526010150	12.86 2INCH 180C/F CS-NPS-PTO-NC	TATA spare parts
271526010151	GEAR BOX G1150-9 SPEED DD	TATA spare parts
271526010152	GEAR BOX G1150-9SPEED OD 9.37 2 DIA180 C	TATA spare parts
271526010153	ASSY. GEAR BOX G1150 9S DD 12.86 BS3	TATA spare parts
271526010154	GEAR BOX G11509SPEED DD12.86 2IN180DIACF	TATA spare parts
271526010156	GEAR BOX-1150/12.86-1.75IN-LS-NPS-PTO-18	TATA spare parts
271526010162	GEAR BOX ASSY	TATA spare parts
271526010166	GEAR BOX ASSY	TATA spare parts
271526010167	GEAR BOX ASSY	TATA spare parts
271526010168	GEAR BOX ASSY	TATA spare parts
271526010176	GEAR BOX ASSY	TATA spare parts
271526010177	ASSY. GEARBOX COMPLETE- G1150/12.86-1.75	TATA spare parts
271526010182	GEAR BOX ASSY BS6	TATA spare parts
271526010183	GEAR BOX ASSY BS6	TATA spare parts
271526010190	GEAR BOX ASSY BS6	TATA spare parts
271526010191	GEAR BOX ASSY BS6	TATA spare parts
271526010207	GEARBOXASSY	TATA spare parts
271526010220	GEAR BOX ASSY	TATA spare parts
271526010225	GEAR BOX ASSY	TATA spare parts
271526010226	GEAR BOX ASSY BS6	TATA spare parts
271526010229	GEAR BOX ASSY BS6	TATA spare parts
271526010231	GEAR BOX ASSY BS6	TATA spare parts
271526010232	GEAR BOX ASSY	TATA spare parts
271526010239	GEAR BOX ASSY BS6	TATA spare parts
271526010240	GEAR BOX ASSY BS6	TATA spare parts
271526010251	GEAR BOX ASSY BS6	TATA spare parts
271526010259	GEAR BOX ASSY BS6	TATA spare parts
271526010266	GEAR BOX ASSY BS6	TATA spare parts
271526010270	GEAR BOX ASSY WITH PTO BS6	TATA spare parts
271526100115	ASSY GB HSG FRT+INTER+REAR - OD NON P/S	TATA spare parts
271526100121	ASSY. GEAR BOX HSG. FRT+INT+RR BS2/3/4	TATA spare parts
271526100122	ASSY GB HSG FRT+INTER+REAR - DD P/S	TATA spare parts
271526100126	ASSY GB HSG FRT+INTER+REAR-DD, NON P/SN	TATA spare parts
271526100132	ASSY GB HSG FRT+INTER+REAR - DD	TATA spare parts
271526100151	ASSY GB HSG FRT+INTER+REAR ĳ DD BS6	TATA spare parts
271526103401	COUPLING BODY	TATA spare parts
271526103737	GEAR BOX G1150 HOUSING - REAR	TATA spare parts
271526105301	GASKET(INTERMEDIATE TO REAR HSG)	TATA spare parts
271526105301AE	GSKT(INTER TO RR HSG) -1628	TATA spare parts
271526105303	GASKET (INTER-REAR HSG)	TATA spare parts
271526107202	SEALING PLUG BS6	TATA spare parts
271526107701	STOPPER BS6	TATA spare parts

271526200113	ASSY. PLANET CARRIER BS2/3/4	TATA spare parts
271526200113AE	ASSY PLANET CARRIER 1628	TATA spare parts
271526200114	ASSY PLANET CARRIER HOUSING	TATA spare parts
271526200124	ASSY COUPLING FLANGE(180DIA. X-SERRATED)	TATA spare parts
271526200124AE	ASSY COUPLING FLANGE(180D)-1628	TATA spare parts
271526200126	ASSY. COUPLING FLANGE(150DIA. X-SERRATED)	TATA spare parts
271526200131	ASSY. ENGAGING GEAR BS6	TATA spare parts
271526200135	ASSY CYLINDER	TATA spare parts
271526200142	ASSY PLANET CARRIER	TATA spare parts
271526200179	PLANET CARRIER ASSY BS6-PH2	TATA spare parts
271526203001	PLANET ROLLER	TATA spare parts
271526203101	NEEDLE CAGE ASSY(1ST/5TH AND 2ND/6TH)	TATA spare parts
271526203102	DEEP GROOVE BALL BEARING (ANNULUS)	TATA spare parts
271526203102AE	DEEP GROOVE BALL BRG -1628	TATA spare parts
271526203103	DEEP GROOVE BALL BEARING(PLANET CARRIER)	TATA spare parts
271526203103AE	DEEP GRVE BAL BG(PLT CARRIER-1628	TATA spare parts
271526203104	NEEDLE ROLLER AND CAGE ASSY	TATA spare parts
271526203105	BALL BEARING - NRB (PLANET CARRIER) BS6	TATA spare parts
271526203106	DEEP GROOVE BALL BEARING - NRB (ANNULUS)	TATA spare parts
271526203107	DEEP GROOVE BALL BEARING (NBC)(ANNULUS)	TATA spare parts
271526203110	CAGE	TATA spare parts
271526203112	DEEP GROOVE BALL BEARING BS6	TATA spare parts
271526203113	DEEP GROOVE BALL BEARING BS6	TATA spare parts
271526203114	DEEP GROOVE BALL BEARING BS6	TATA spare parts
271526203201	SCREW (SPACER LOCK-SUN GEAR)	TATA spare parts
271526203202	HEX COLLER BOLT (RECTION PLATE)	TATA spare parts
271526203203	LOCKING SCREW (SHAFT PLANET)	TATA spare parts
271526203401	MUFF RING (MAINSHAFT) BS2/3/4/6	TATA spare parts
271526203402	SPEEDO ADAPTOR	TATA spare parts
271526203402AE	SPEEDO ADPT LPTA 1628/LPTA 1828	TATA spare parts
271526203701	PISTON COVER	TATA spare parts
271526203701AE	PISTON COVER 1628	TATA spare parts
271526203702	CYLINDER COVER	TATA spare parts
271526204301	CIRCLIP (2.3 THK)	TATA spare parts
271526204302	CIRCLIP (2.4 THK)	TATA spare parts
271526204303	CIRCLIP (2.5 THK)	TATA spare parts
271526204304	CIRCLIP (2.6 THK)	TATA spare parts
271526204305	CIRCLIP (2.7 THK)	TATA spare parts
271526204306	CIRCLIP (1.6 THK)	TATA spare parts
271526204307	CIRCLIP (1.7 THK)	TATA spare parts
271526204308	CIRCLIP (1.8 THK)	TATA spare parts
271526204309	CIRCLIP (3.2 THK)	TATA spare parts
271526204310	CIRCLIP (3.1 THK)	TATA spare parts
271526204311	CIRCLIP (3.0 THK)	TATA spare parts
271526204312	CIRCLIP (2.9 THK)	TATA spare parts
271526204313	CIRCLIP (2.8 THK)	TATA spare parts
271526204314	CIRCLIP (3.1 THK)	TATA spare parts

271526204315	CIRCLIP (3.0 THK)	TATA spare parts
271526204316	CIRCLIP (2.9 THK)	TATA spare parts
271526204317	CIRCLIP (2.8 THK)	TATA spare parts
271526204318	CIRCLIP (3.1 THK)	TATA spare parts
271526204319	CIRCLIP (3.0 THK)	TATA spare parts
271526204320	CIRCLIP (2.9 THK)	TATA spare parts
271526204321	CIRCLIP (2.8 THK)	TATA spare parts
271526204322	CIRCLIP (2.7 THK)	TATA spare parts
271526204323	CIRCLIP (2.6 THK)	TATA spare parts
271526204324	CIRCLIP (2.5 THK)	TATA spare parts
271526204325	CIRCLIP (2.4 THK)	TATA spare parts
271526204326	CIRCLIP (2.3 THK)	TATA spare parts
271526204327	CIRCLIP (2.2 THK)	TATA spare parts
271526204328	CIRCLIP (4.2 THK)	TATA spare parts
271526204329	CIRCLIP (4.1 THK)	TATA spare parts
271526204330	CIRCLIP (4.0 THK)	TATA spare parts
271526204331	CIRCLIP (3.9 THK)	TATA spare parts
271526204332	CIRCLIP (3.8 THK)	TATA spare parts
271526204333	CIRCLIP (2.7 THK)	TATA spare parts
271526204334	CIRCLIP (3.8 THK)	TATA spare parts
271526204335	CIRCLIP (3.9 THK)	TATA spare parts
271526204336	CIRCLIP (4.0 THK)	TATA spare parts
271526204337	CIRCLIP (4.1 THK)	TATA spare parts
271526204338	CIRCLIP (4.2 THK)	TATA spare parts
271526204339	CIRCLIP (2.9 THK)	TATA spare parts
271526204340	CIRCLIP (3.0 THK)	TATA spare parts
271526204341	CIRCLIP (3.1 THK)	TATA spare parts
271526204342	CIRCLIP (3.2 THK)	TATA spare parts
271526204343	CIRCLIP (3.3 THK)	TATA spare parts
271526204344	CIRCLIP (3.4 THK)	TATA spare parts
271526204345	CIRCLIP (3.4 THK)	TATA spare parts
271526204346	CIRCLIP (3.5 THK)	TATA spare parts
271526204347	CIRCLIP (3.6 THK)	TATA spare parts
271526204348	CIRCLIP (3.7 THK)	TATA spare parts
271526204349	CIRCLIP (3.8 THK)	TATA spare parts
271526204350	CIRCLIP (3.9 THK)	TATA spare parts
271526204351	CIRCLIP (4.0 THK)	TATA spare parts
271526204601	ENGAGING GEAR (CRAWLER/REV)	TATA spare parts
271526204601AE	ENGAGING GEAR (CRAWLER/REV)-1628	TATA spare parts
271526204602	ENGAGING GEAR (1ST/2ND)	TATA spare parts
271526204602AE	ENGAGING GEAR (1ST/2ND) 1628	TATA spare parts
271526204603	ENGAGING GEAR (3RD/4TH) BS2/3/4/6	TATA spare parts
271526204603AE	ENGAGING GEAR (3RD/4TH) 1628	TATA spare parts
271526204604	ENGAGING RING (REVERSE) BS2/3/4/6	TATA spare parts
271526204604AE	ENGAGING RING (REVERSE) 1628	TATA spare parts
271526204605	SYNCHRO RING (CRAWLER/1ST/2ND) BS2/3/4	TATA spare parts
271526204605AE	SYN RING (CRAWLER/1ST/2ND) -1628	TATA spare parts

271526204606	SYNCHRO RING (3RD/4TH SPEED) BS2/3/4	TATA spare parts
271526204607	SYNCHRO RING (LOW RANGE) BS2/3/4	TATA spare parts
271526204608	ENGAGING GEAR (RANGE SELECTION) BS2/3/4	TATA spare parts
271526204608AE	ENGING GR (RANGE SELECTION)-1628	TATA spare parts
271526204610	SHIFTER SLEEVE (RANGE SELECTION) BS2/3/4	TATA spare parts
271526204610AE	SHFTR SLEEVE (RANGE SELECT)-1628	TATA spare parts
271526204611	SYNCHRO RING (HIGH RANGE) BS2/3/4	TATA spare parts
271526204611AE	SYNCHRO RING (HIGH RANGE) 1628	TATA spare parts
271526204612	SHIFTER SLEEVE (CRAWLER/REVERSE)	TATA spare parts
271526204612AE	SHFTR SLEEVE (CRAW/REVERSE)-1628	TATA spare parts
271526204613	SYNCHRO CONE (C/1/2/3/4)THREADED BS2/3/4	TATA spare parts
271526204613AE	SYNNISING CONE(C/1/2/3/4)-1628	TATA spare parts
271526204614	SYNCHRO CONE (RANGE)THREAED BS2/3/4	TATA spare parts
271526204620	ENGAGING GEAR (CRAWLER/REV)	TATA spare parts
271526204621	SHIFTER SLEEVE-CRAWLER/REVERSE BS2/3/4/6	TATA spare parts
271526204622	SYNCHRO RING LOW RANGE BS4/6	TATA spare parts
271526204623	SHIFTER SLEEVE (RANGE) BS4/6	TATA spare parts
271526204624	SYNCHRO CONE (RANGE) THREADED BS4/6	TATA spare parts
271526204625	SYNCHRO RING (HIGH RANGE) BS4/6	TATA spare parts
271526204630	SYNCHRO RING 3RD/4TH SPEED CARBON LINING	TATA spare parts
271526204631	SYNCHRO RING CRAWLER/1ST/2ND BS6	TATA spare parts
271526204632	ENGAGING GEAR (RANGE SELECTION)	TATA spare parts
271526204635	SHIFTER SLEEVE BS2/3/4/6	TATA spare parts
271526204636	SYNCHRO CONE 1ST/2ND/3RD/4TH SPEED BS6	TATA spare parts
271526204639	SYNCHRO CONE 1ST/2ND/3RD/4TH SPEED BS6	TATA spare parts
271526204640	SYNCHRO RING BS6	TATA spare parts
271526204641	SYNCHRO RING BS6	TATA spare parts
27152620464664	SHIFTER SLEEVE BS6	TATA spare parts
271526205102	CARRIER (ANNULUS)	TATA spare parts
271526205105	COUPLING FLANGE ( 150 DIA ) BS6	TATA spare parts
271526205109	CARRIER BS6	TATA spare parts
271526205401	REVERSE SPEED GEAR MAIN SHAFT BS2/3	TATA spare parts
271526205401AE	REVERSE SPD GEAR (MN SFT) -1628	TATA spare parts
271526205402	CRAWLER GEAR (MAIN SHAFT) BS2/3/4/6	TATA spare parts
271526205402AE	CRAWLER GEAR (MAIN SHAFT) 1628	TATA spare parts
271526205406	SUN GEAR BS2/3/4/6	TATA spare parts
271526205407	PLANET GEAR	TATA spare parts
271526205407AE	PLANET GEAR 1628	TATA spare parts
271526205408	ANNULUS GEAR	TATA spare parts
271526205408AE	ANNULUS GEAR 1628	TATA spare parts
271526205409	GEAR (SPEEDOMETER DRIVE)	TATA spare parts
271526205410	1ST / 5TH GEAR ( MAIN SHAFT ) BS2/3/4/6	TATA spare parts
271526205410AE	1ST/5TH SPEED GR(MAIN SFT)-1628	TATA spare parts
271526205411	2ND / 6TH GEAR ( MAIN SHAFT ) BS2/3/4/6	TATA spare parts
271526205412	3RD / 7TH GEAR ( MAIN SHAFT ) BS2/3/4/6	TATA spare parts
271526205412AE	3RD/7TH SPEED GR(MAIN SFT)-1628	TATA spare parts
271526205413	4TH/8TH SPEED GEAR MAINSHFT(OVERDRIVE)	TATA spare parts

271526206101	LOCKWASHER(SHAFT(PLANET)-PLANET CARRIER)	TATA spare parts
271526206501	LOCK NUT (COUPLING FLANGE)	TATA spare parts
271526206601	PISTON	TATA spare parts
271526206602	PISTON (RANGE SELECTION)	TATA spare parts
271526206603	PISTON BS6-PH2	TATA spare parts
271526206604	PISTON BS6	TATA spare parts
271526206701	RETENTION PIN (RANGE) BS2/3/4	TATA spare parts
271526206701AE	RETENTION PIN (RANGE)	TATA spare parts
271526206702	RETENTION PIN(RANGE)	TATA spare parts
271526207101	REACTION PLATE	TATA spare parts
271526207102	REACTION PLATE	TATA spare parts
271526207103	REACTION PLATE	TATA spare parts
271526207701	SEALING RING (LUBRICATION PUMP)BS2/3/4/6	TATA spare parts
271526207702	O-RING (66.04X5.3) VITON	TATA spare parts
271526207704	O-RING (9.3X1.8) VITON	TATA spare parts
271526207705	O-RING (21.69X2.65) VITON	TATA spare parts
271526207706	O-RING (66.27X3.53) VITON	TATA spare parts
271526207707	O-RING (17.17X1.8) VITON	TATA spare parts
271526207708	O-RING (82.27X1.8) VITON	TATA spare parts
271526207709	O-RING (12.37X2.65) VITON	TATA spare parts
271526207711	O RING 91.44X5.30 TS 16220	TATA spare parts
271526207712	O RING 107.67X1.8 TS 16220	TATA spare parts
271526207713	O RING (70X1.5) VITON	TATA spare parts
271526207715	O-RING	TATA spare parts
271526207717	O-RING	TATA spare parts
271526207719	OIL RING BS6-PH2	TATA spare parts
271526207720	OIL RING BS6-PH2	TATA spare parts
271526207801	OIL SEAL (REAR HOUSING)	TATA spare parts
271526207804	OIL SEAL(95-125-12) BS2/3/4/6	TATA spare parts
271526207804DF	OIL SEAL MAIN SHAFT (95-125-12) - GB1150	TATA spare parts
271526207805	OILSEAL (52-72-12)	TATA spare parts
271526207806	OIL SEAL (52-72-12)	TATA spare parts
271526207807	OIL SEAL (95-125-12)	TATA spare parts
271526207901	MAIN SHAFT BS2/3/4/6	TATA spare parts
271526207901AE	MAIN SHAFT 1628	TATA spare parts
271526207903	SHAFT (PLANET)	TATA spare parts
271526207905	SPEEDO PINION (JIS TYPE)	TATA spare parts
271526207905AE	SPEEDO PINION(JIS TYP)-1628-1828	TATA spare parts
271526207906	PLANET CARRIER HOUSING-INTEGRAL	TATA spare parts
271526207907	PLANET CARRIER HOUSING (INTEGRAL)	TATA spare parts
271526207908	SHAFT PLANET	TATA spare parts
271526207913	PLANET CARRIER ASSY BS6-PH2	TATA spare parts
271526208201	DUST SHIELD BS6	TATA spare parts
271526208601	SPACER 12.4 THK (M/SHAFT)	TATA spare parts
271526208602	SPACER 17.7 THK (M/SHAFT)	TATA spare parts
271526208603	SPACER 17.6 THK (M/SHAFT)	TATA spare parts
271526208604	SPACER 17.5 THK (M/SHAFT)	TATA spare parts

271526208605	SPACER 17.4 THK (M/SHAFT)	TATA spare parts
271526208606	SPACER 17.3 THK (M/SHAFT)	TATA spare parts
271526208607	SPACER 17.2 THK (M/SHAFT)	TATA spare parts
271526208608	SPACER 17.1 THK (M/SHAFT)	TATA spare parts
271526208609	SPACER 17.0 THK (M/SHAFT)	TATA spare parts
271526208610	SPACER 16.9 THK (M/SHAFT)	TATA spare parts
271526208611	SPACER 16.8 THK (M/SHAFT)	TATA spare parts
271526208612	SPACER 16.7 THK (M/SHAFT)	TATA spare parts
271526208613	SPACER 16.6 THK (M/SHAFT)	TATA spare parts
271526208614	SPACER (MAIN SHAFT)	TATA spare parts
271526208615	SPACER LOCK (SUN GEAR)	TATA spare parts
271526208616	SPACER (ROLLER BRG. - PLANET GEAR)	TATA spare parts
271526208617	SPACER (PLANET CARRIER)	TATA spare parts
271526208619	SPACER	TATA spare parts
271526208620	SPACER LOCK (FLANGE)	TATA spare parts
271526208621	SPACER BS6	TATA spare parts
271526208701	COMPRESSION SPRING(RANGE SYNCHRONISER)	TATA spare parts
271526209201	THRUST WASHER (PLANET)	TATA spare parts
271526209202	THRUST WASHER (PLANET)	TATA spare parts
271526209203	THRUST WASHER (PLANET)	TATA spare parts
271526250115	ASSY. DRIVE SHAFT 1-3/4 SAE-1 BS2/3/4	TATA spare parts
271526250119	ASSY DRIVESHAFT 2INCSPLINE SAE-1 CH HSG.	TATA spare parts
271526250119AE	ASSY DRVESFT 2SPLNE CH HSG-1628	TATA spare parts
271526250129	ASSY DRIVESHAFT BS6	TATA spare parts
271526253103	TAPER ROLLER BEARING BS2/3/4/6	TATA spare parts
271526253103AE	TAPER ROLLER BEARING 1628	TATA spare parts
271526253104	TAPER ROLLER BEARING (TIMKEN) BS6	TATA spare parts
271526253702	FRONT COVER UPPER SAE-1 CL HSG	TATA spare parts
271526253702AE	FRONT COVER ( UPPER ) 1628	TATA spare parts
271526253703	FRONT COVER ( UPPER ) BS2/3/4	TATA spare parts
271526254601	SYNCHRO RING ( DRIVESHAFT) BS2/3/4	TATA spare parts
271526254604	SYNCHRO RING ( DRIVESHAFT) BS2/3/4 BS6	TATA spare parts
271526255301	GASKET (FRONT COVER UPPER)	TATA spare parts
271526255301AE	GASKET (FRONT COVER UPPER) 1828	TATA spare parts
271526257909	DRIVE SHAFT (2INC SPLINE SAE-1 CL HSG)	TATA spare parts
271526257911	DRIVE SHAFT-1-3/4INCH SAE-1 CH HSG. BS2/	TATA spare parts
271526257912	DRIVE SHAFT 1-3/4 INC SPLINE SAE-1 CH HS	TATA spare parts
271526257915	DRIVE SHAFT 2 IN SPLINE SAE-1 CH HSG.	TATA spare parts
271526305405	1ST / 5TH SPEED GEAR ( COUNTER SHAFT )	TATA spare parts
271526305406	2ND/6TH SPEED GEAR(C/S) BS2/3/4/6	TATA spare parts
271526305407	3RD/7TH GEAR (COUNTER SHAFT) BS2/3/4/6	TATA spare parts
271526305408	CONST. MESH GEAR (COUNT SHAFT) BS2/3/4/6	TATA spare parts
271526305408AE	CNSTNTMESH GR(COUNTER SFT)-1628	TATA spare parts
271526305409	CONSTANTMESH GEAR ( COUNTER SHAFT )	TATA spare parts
271526305410	4TH/8TH SPEED GEAR FOR COUNTER SHAFT(OD)	TATA spare parts
271526307902	COUNTER SHAFT (G1150) BS2/3/4/6	TATA spare parts
271526307902AE	COUNTER SHAFT 1628	TATA spare parts

271526353701	COVER (REV IDLER)	TATA spare parts
271526353701AE	COVER (REV IDLER) 1628	TATA spare parts
271526355301	GASKET (R.I.COVER)	TATA spare parts
271526355401	REVERSE IDLER GEAR	TATA spare parts
271526357901	SHAFT (REVERSE IDLER GEAR)	TATA spare parts
271526358202	REVERSE IDLER COVER (SHEETMETAL)	TATA spare parts
271526400101	ASSY ADAPTOR SHAFT WITH OIL PUMP & PTO	TATA spare parts
271526400102	ASSY ADAPTOR SHAFT WITH OIL PUMP & PTO	TATA spare parts
271526400106	REAR MOUNTED PTO BS6	TATA spare parts
271526400108	ASSY. PTO IPH BS2/3/4/6	TATA spare parts
271526400108AE	ASSY PTO IPH 1628	TATA spare parts
271526400110	ASSY. PUMP PTO BS3/4	TATA spare parts
271526400111	PUMP PTO ASSY	TATA spare parts
271526400117	PTO ASSY BS6	TATA spare parts
271526403706	ADAPTOR PTO (INTERPUMP)	TATA spare parts
271526403706AE	ADAPTOR PTO (INTERPUMP) 1628	TATA spare parts
271526404603	CLUTCH PTO (INTERPUMP)	TATA spare parts
271526405301	GASKET ( REAR PTO TO OIL PUMP )	TATA spare parts
271526405301AE	GASKET PTO TO OIL PUMPLPTA 1828	TATA spare parts
271526406801	AIR ADAPTOR M12X1.5	TATA spare parts
271526407901	ADAPTOR SHAFT (OIL PUMP AND REAR PTO)	TATA spare parts
271526407904	SHAFT ADAPTOR (FOR PTO) BS6	TATA spare parts
271526408606	SPACER LOCK (CLUTCH PTO)	TATA spare parts
271526408801	STUD (FOR OIL PUMP AND PTO)	TATA spare parts
271526408801AE	STUD (FOR OIL PUMP AND PTO)-1628	TATA spare parts
271526409901	ASSY. KIT FOR PTO	TATA spare parts
271526510116	ROTATION LOCKING BOLT	TATA spare parts
271526513201	ROTATION LOCKING BOLT	TATA spare parts
271526513202	ROTATION LOCKING BOLT BS6	TATA spare parts
271526515101	SHIFTER DOG (CRAWLER/REV)	TATA spare parts
271526515102	SHIFTER DOG (1ST/2ND GEAR)	TATA spare parts
271526515103	SHIFTER DOG (3RD/4TH GEAR)	TATA spare parts
271526515104	SHIFTER FORK( 3RD/4TH)	TATA spare parts
271526515105	SHIFTER FORK (1ST/2ND SPEED)	TATA spare parts
271526515106	SHIFTER FORK (RANGE) BS2/3/4	TATA spare parts
271526515106AE	SHIFTER FORK (RANGE) 1628	TATA spare parts
271526515107	SWING FORK FOR 3/4 OVER DRIVE	TATA spare parts
271526515108	SHIFTER DOG 3/4 OVER DRIVE	TATA spare parts
271526515109	SHIFTER FORK (REVERSE/CRAWLER)	TATA spare parts
271526515109AE	SHFTR K (REVERSE/CRAWLER) -1628	TATA spare parts
271526515112	SHIFTER FORK (RANGE)	TATA spare parts
271526516701	THREADED PIN ( FOR SWING FORK )	TATA spare parts
271526516702	CYLINDRCAL PIN (HARDENED)	TATA spare parts
271526516704	CYLINDRICAL PIN	TATA spare parts
271526516705	CYL PIN BS6	TATA spare parts
271526517901	SHIFTER SHAFT (REV / CRAWLER SPEED)	TATA spare parts
271526517902	SHIFTER SHAFT (1ST/2ND SPEED)	TATA spare parts

271526517902AE	SHFTR SFT (1ST/2ND SPEED) -1628	TATA spare parts
271526517903	SHIFTER SHAFT (3RD/4TH SPEED)	TATA spare parts
271526517903AE	SHFTR SFT (3RD/4TH SPEED) -1628	TATA spare parts
271526517904	SHIFTER SHAFT (RANGE) BS2/3/4	TATA spare parts
271526517904AE	SHIFTER SHAFT (RANGE) 1628	TATA spare parts
271526517905	SHIFTER SHAFT (3 RD / 4 TH)	TATA spare parts
271526517906	INTER LOCK SHAFT	TATA spare parts
271526517911	SHIFTER SHAFT (RANGE)	TATA spare parts
271526517915	SHIFTER SHAFT BS6	TATA spare parts
271526517920	SHIFTER SHAFT BS6	TATA spare parts
271526518701	COMPRESSION SPRING (INTERLOCK SHAFT)	TATA spare parts
271526519901	BRASS PAD	TATA spare parts
271526700103	TURNING TUBE ASSY	TATA spare parts
271526700104	TURNING TUBE ASSY BS6	TATA spare parts
271526700110	BALL JOINT ASSY BS6 PH2	TATA spare parts
271526706003	SHIFTING LEVER BS6	TATA spare parts
271526710101	ASSY GEAR CASE COVER TOP	TATA spare parts
271526710104	ASSY. NYLON PIPE(FPR TO 5/2 VALVE)	TATA spare parts
271526710105	ASSY. NYLON PIPE(5/2 VALVE TO HSG.)	TATA spare parts
271526710106	ASSY. NYLON PIPE(5/2 VALVE TO CYLINDER)	TATA spare parts
271526710107	ASSY TOP COVER (POWER SHIFT) LHD	TATA spare parts
271526710109	ASSEMBLY POWERSHIFT CYLINDER	TATA spare parts
271526710109AE	ASSY POWER SHIFT CYLINDER -1628	TATA spare parts
271526710110	ASSY SHIFTER SHAFT ( POWER SHIFT )	TATA spare parts
271526710116	ASSY NYLON PIPE (5/2 VALVE TO HSG)	TATA spare parts
271526710117	ASSY NYLON PIPE (5/2 VALVE TO CYL)	TATA spare parts
271526710122	ASSY. PNEUMATIC VALVE 4/2 BS2/3/4	TATA spare parts
271526710126	ASSY. 4/2 VALVE-COMplete (M/S REXROTH)	TATA spare parts
271526710127	ASSY. FIL/PR.REGULATOR(5.5BAR) BS2-6	TATA spare parts
271526710127AE	ASSY FIL/PRES REGLATR(5.5B)-1628	TATA spare parts
271526710128	ASSY. FIL/PRESS REGULATOR(2	TATA spare parts
271526710129	ASSY HOUSING TOP COVER P/S WITH BUSH	TATA spare parts
271526710135	POWER SHIFT CYLINDER BS6-PH2	TATA spare parts
271526710136	ASSY GEAR CASE COVER TOP BS6	TATA spare parts
271526710139	ASSY. BRACKET-LHD(LINK ROD)	TATA spare parts
271526710140	ASSY. BRACKET-RHD (LINK ROD)	TATA spare parts
271526710141	ASSY GEAR CASE COVER TOP	TATA spare parts
271526710142	ASSY SELECTOR & SHIFTER SHAFT	TATA spare parts
271526710146	ASSY. INTERLOCK BS2/3/4/6	TATA spare parts
271526710149	ASSY NYLON PIPE (5/2 VALVE TO CYL)	TATA spare parts
271526710150	ASSY NYLON PIPE (5/2 VALVE TO CYL)	TATA spare parts
271526710158	ASSY. TOP COVER ( POWER SHIFT )	TATA spare parts
271526710160	ASSY GEAR CASE COVER TOP	TATA spare parts
271526710161	ASSY SELECTOR SHIFTER SHAFT	TATA spare parts
271526710171	VALVE BODY	TATA spare parts
271526710172	4/2 VALVE ASSY	TATA spare parts
271526710173	COVER ASSY TOP	TATA spare parts



271526710177	PRESSURE REGULATOR ASSY BS6	TATA spare parts
271526710186	GEAR CASE COVER ASSY TOP BS6	TATA spare parts
271526710187	ASSY SHIFTER SELECTOR SHAFT	TATA spare parts
271526710217	GEAR CASE COVER ASSY TOP	TATA spare parts
271526711601	OFFER DRG QUICK FIX CONNECTOR	TATA spare parts
271526711601AE	OFFER DRG QUICK FIX CONNECTOR	TATA spare parts
271526711602	QUICK FIX CONNECTOR-1/8IN(6 OD)	TATA spare parts
271526713101	NEEDLE BEARING SHIFTER SHAFT	TATA spare parts
271526713203	LOCKING BOLT - SHIFTER SHAFT(POWERSHIFT)	TATA spare parts
271526713401	HOUSING-REVERSE DETENT (POWER SHIFT)	TATA spare parts
271526713409	BUSH SELECTOR/SHIFTER SHAFT BS6	TATA spare parts
271526713410	BUSH SELECTOR/SHIFTER SHAFT BS6-PH2	TATA spare parts
271526713413	BUSH BS6	TATA spare parts
271526713701	GEAR CASE COVER TOP	TATA spare parts
27152671370199	TOP COVER 1150 W/O RANGE INHIBITOR HOLE	TATA spare parts
271526713702	TOP COVER (POWER SHIFT)LHD.	TATA spare parts
271526713702AE	TOP COVER (POWER SHIFT)LHD.-1628	TATA spare parts
271526713703	GEAR CASE TOP COVER (LHD)	TATA spare parts
271526713707	GEAR CASE COVER TOP TOP	TATA spare parts
271526713708	GEAR CASE COVER TOP	TATA spare parts
271526713711	COVER HOUSING TOPTOP	TATA spare parts
271526713801	SIDE COVER (TOP COVER)	TATA spare parts
271526713803	SIDE COVER (TOP COVER)	TATA spare parts
271526713814	COVER BS6-PH2	TATA spare parts
271526713815	COVER TOP UPPER-HALF BS6-PH2	TATA spare parts
271526714201	COATED CLAMP (FOR PNEUMATIC PIPES) BS6	TATA spare parts
271526714302	CIRCLIP BS6-PH2	TATA spare parts
271526715101	SELECTOR & SHIFTER FINGER	TATA spare parts
271526715102	SHIFTER FINGER ( POWER SHIFT )	TATA spare parts
271526715112	SELECTOR AND SHIFTER FINGER	TATA spare parts
271526715117	POWER SHIFT FINGER BS6-PH2	TATA spare parts
271526715118	SHIFTER FINGER BS6-PH2	TATA spare parts
271526715301	GASKET SIDE COVER (POWER SHIFT)	TATA spare parts
271526715302	GASKET TOP COVER (POWERSHIFT)	TATA spare parts
271526715305	GASKET BS6-PH2	TATA spare parts
271526715306	GASKET BS6-PH2	TATA spare parts
271526715307	GASKET BS6-PH2	TATA spare parts
271526715309	GASKET BS6	TATA spare parts
271526715310	GASKET BS6	TATA spare parts
271526715311	GASKET HSG & TOP COVER BS6-PH2	TATA spare parts
271526716002	SHIFTING LEVER ( POWER SHIFT )	TATA spare parts
271526716003	SELECTION FINGER - POWERSHIFT	TATA spare parts
271526716004	SELECTION LEVER P/S (LPS4027)	TATA spare parts
271526716004AE	SELECTION LEVER 1628	TATA spare parts
271526716010	SHIFTING LEVER BS6	TATA spare parts
271526716101	SPRING RETAINER BS6-PH2	TATA spare parts
271526716102	SPRING RETAINER BS6-PH2	TATA spare parts

271526716701	PRESSURE PIECE (REV.DETENT-POWERSHIFT)	TATA spare parts
271526716701AE	PRSSR PC(REVDTNT PWRSHIFT)-1628	TATA spare parts
271526716703	PRESSURE PIECE	TATA spare parts
271526716706	PRESSURE PIECE	TATA spare parts
271526716707	PRESSURE PIECE	TATA spare parts
271526716711	PIN BS6-PH2	TATA spare parts
271526716712	PIN INTERLOCK/SHIFT FINGER BS6-PH2	TATA spare parts
271526716713	DETENT SELECTOR/SHIFTER SHAFT BS6-PH2	TATA spare parts
271526716714	PIN BS6-PH2	TATA spare parts
271526716802	CONNECTOR	TATA spare parts
271526716803	CONNECTOR	TATA spare parts
271526716804	CONNECTOR	TATA spare parts
271526716906	OIL PUMP HOSE	TATA spare parts
271526716907	PNEUMATIC PIPE(6X1-PR.REG VALVE)	TATA spare parts
271526716911	NYLON PIPE 6X1 (PR.REG. TO 4/2 VALVE)	TATA spare parts
271526717125	COVER PLATE BS6	TATA spare parts
271526717201	SCREW PLUG BS6-PH2	TATA spare parts
271526717202	DETENT PLUG BS6-PH2	TATA spare parts
271526717703	STOPPER	TATA spare parts
271526717801	OIL SEAL (POWER SHIFT SHIFTER SHAFT)	TATA spare parts
271526717802	OIL SEAL (POWER SHIFT SELECTION SHAFT)	TATA spare parts
271526717803	OIL SEAL (POWERSHIFT SHIFTER SHAFT)	TATA spare parts
271526717806	OIL SEAL 25X35X7 - SKF BS6	TATA spare parts
271526717807	SEAL 32X45X7 - SKF BS6	TATA spare parts
271526717812	OIL SEAL BS6-PH2	TATA spare parts
271526717901	SELECTOR & SHIFTER SHAFT	TATA spare parts
271526717902	SHIFTER SHAFT (POWERSHIFT)	TATA spare parts
271526717902AE	SHIFTER SHAFT (POWERSHIFT) 1628	TATA spare parts
271526717903	SELECTOR SHAFT ( POWERSHIFT )	TATA spare parts
271526717907	SELECTOR AND SHIFTER SHAFT	TATA spare parts
271526717908	SELECTOR AND SHIFTER SHAFT (LHD)	TATA spare parts
271526717909	SELECTOR & SHIFTER SHAFT	TATA spare parts
271526718201	CUP (SELECTOR SHIFTER SHAFT)	TATA spare parts
271526718202	BRACKET (FILTER & PRESSURE REGULATOR)	TATA spare parts
271526718203	SIDE COVER (TOP COVER POWER SHIFT)	TATA spare parts
271526718206	BRACKET LH (PRESSURE REGULATOR)	TATA spare parts
271526718207	BRACKET RH (PRESSURE REGULATOR)	TATA spare parts
271526718208	BAFFLE-TOP COVER (POWERSHIFT)	TATA spare parts
271526718209	BAFFLE-PLATE (NON-POWERSHIFT)	TATA spare parts
271526718210	BAFFLE PLATE (NON POWER SHIFT)	TATA spare parts
271526718211	BRACKET	TATA spare parts
271526718212	BRACKET	TATA spare parts
271526718213	COVER PLATE BS6-PH2	TATA spare parts
271526718217	BRACKET BS6	TATA spare parts
271526718218	BRACKET BS6	TATA spare parts
271526718402	SLEEVE BS6-PH2	TATA spare parts
271526718602	SPACER SELECTION LEVER ( POWER SHIFT )	TATA spare parts

271526718603	STOPPER COMP. SPRING (POWER SHIFT)	TATA spare parts
271526718608	SPACER (TOP COVER RHD)	TATA spare parts
271526718701	COMPRESSION SPRING (OUTER)	TATA spare parts
271526718702	COMPRESSION SPRING (INNER)	TATA spare parts
271526718703	COMPRESSION SPRING RIGHT (POWER SHIFT)	TATA spare parts
271526718704	COMPRESSION SPRING LEFT ( POWER SHIFT )	TATA spare parts
271526718704AE	COMPRSSN SPRNG-L(PWR SHIFT)-1628	TATA spare parts
271526718706	COMPRESSION SPRING (OUTER)	TATA spare parts
271526718707	COMPRESSION SPRING	TATA spare parts
271526718708	COMPRESSION SPRING (INNER)	TATA spare parts
271526718709	COMPRESSION SPRING (OUTER)	TATA spare parts
271526718711	COMPRESSION SPRING BS6	TATA spare parts
271526718712	COMPRESSION SPRING BS6	TATA spare parts
271526718713	COMPRESSION SPRING BS6-PH2	TATA spare parts
271526718714	COMPRESSION SPRING BS6-PH2	TATA spare parts
271526718716	COMPRESSION SPRING BS6-PH2	TATA spare parts
271526800110	TURNING TUBE ASSY BS6	TATA spare parts
271526800111	GEAR SHIFT LEVER ASSY WITH YOKE BS6	TATA spare parts
271526800118	TURNING TUBE ASSY BS6	TATA spare parts
271526800121	TURNING TUBE ASSY BS6	TATA spare parts
271526800131	TURNING TUBE ASSY BS6	TATA spare parts
271526800143	TURNING TUBE ASSY BS6	TATA spare parts
271526800158	TURNING TUBE ASSY BS6	TATA spare parts
271526800174	BELLOW ASSY BS6-PH2	TATA spare parts
271526800176	TURNING TUBE ASSY	TATA spare parts
271526800182	TURNING TUBE ASSY BS6-PH2	TATA spare parts
271526800186	TURNING TUBE ASSY BS6-PH2	TATA spare parts
271526800218	PNEUMATIC PIPE ASSY BS6	TATA spare parts
271526800220	PNEUMATIC PIPE ASSY BS6-PH2	TATA spare parts
271526800223	TURNING TUBE ASSY BS6	TATA spare parts
271526800225	PNEUMATIC PIPE ASSY BS6	TATA spare parts
271526800226	PNEUMATIC PIPE ASSY BS6-PH2	TATA spare parts
271526800227	PNEUMATIC PIPE ASSY BS6-PH2	TATA spare parts
271526803701	WEIGHT SELECTER SHIFTER SHAFT ASSY BS6	TATA spare parts
271526803702	BRACKET BS6	TATA spare parts
271526803703	BRACKET BS6 PH2	TATA spare parts
271526803704	BRACKET BS6-PH2	TATA spare parts
271526805102	SELECTOR & SHIFTER YOKE BS6-PH2	TATA spare parts
271526806304	RETAINER RING BS6-PH2	TATA spare parts
271526806305	RETAINER RING BS6-PH2	TATA spare parts
271526806801	PNUEMATIC FIT.(45 DEG) G 1/8IN X 6 BS2-6	TATA spare parts
271526806903	TURNING TUBE BS6	TATA spare parts
271526807113	RETAINER PLATE BS6	TATA spare parts
271526807701	BASE BELLOW BS6	TATA spare parts
271526807704	RUBBER SEAL BS6	TATA spare parts
271526807902	LINK ROD	TATA spare parts
271526807907	LINK ROD BS6-PH2	TATA spare parts

271526807908	LINK ROD	TATA spare parts
271526807910	LINK ROD BS6	TATA spare parts
271526809906	BALL JOINT ASSY BS6 PH2	TATA spare parts
271526810100	BRACKET ASSY BS6	TATA spare parts
271526810101	BRACKET ASSY BS6	TATA spare parts
271526810103	CLAMPING PLATE ASSY BS6	TATA spare parts
271526810104	CLAMPING PLATE ASSY (TOP)- BELLOW BS6	TATA spare parts
271526813403	BUSH BS6	TATA spare parts
271526813704	BRACKET BS6	TATA spare parts
271526813707	BRACKET BS6-PH2	TATA spare parts
271526813708	BRACKET	TATA spare parts
271526817101	PLATE BS6	TATA spare parts
271526817105	TOP PLATE BS6-PH2	TATA spare parts
271526820101	ASSY BRACKET	TATA spare parts
271526820102	ASSY SELECTOR LEVER WITH MOUNTING BRACKET	TATA spare parts
271526820103	ASSY SELECTION LEVER	TATA spare parts
271526820104	ASSY SELECTION LEVER AND MOUNTING BRACKET	TATA spare parts
271526820107	ASSY SEL LEVER AND MTG BKT	TATA spare parts
271526820119	BRACKET ASSY WITH BOSS	TATA spare parts
271526826001	LEVER	TATA spare parts
271526826009	ANCHORBRACKET	TATA spare parts
271526840102	X-Y ACTUATOR(AMT)	TATA spare parts
271526900101	ASSY STRAINER WITH MAGNET	TATA spare parts
271526900104	SUB ASSY. OIL PUMP BS2/3/4/6	TATA spare parts
271526900107	OIL SPRAY TUBE (RANGE)	TATA spare parts
271526900107AE	OIL SPRAY TUBE (RANGE) 1628	TATA spare parts
271526900107TM	OIL SPRAY TUBE-TEMP	TATA spare parts
271526900108	ASSY STRAINER	TATA spare parts
271526900110	ASSY OIL SPRAY TUBE (RANGE)	TATA spare parts
271526900111	ASSY OIL CUP	TATA spare parts
271526900112	SUB ASSY OIL PUMP	TATA spare parts
271526900114	ASSY OIL COOLER HOSE (OUTLET FROM OIL CO	TATA spare parts
271526900115	ASSY OIL COOLER HOSE (INLET FROM OIL COO	TATA spare parts
271526903101	DEEP GROOVE BALL BEARING (ADAPTOR SHAFT)	TATA spare parts
271526903101AE	DEEP GRVE BALL BRG(ADP SFT)-1628	TATA spare parts
271526903105	DEEP GROOVE BALL BEARING BS6	TATA spare parts
271526903201	COUNTERSUNK BOLT (SPRAY BAR)	TATA spare parts
271526903402	COUPLING BODY	TATA spare parts
271526903504	BOSS BS6	TATA spare parts
271526903701	COVER (OILPUMP)	TATA spare parts
271526903701AE	COVER (OILPUMP) 1628	TATA spare parts
271526903801	HOUSING OIL PUMP.	TATA spare parts
271526903802	OIL PUMP HOUSING (OIL COOLING)	TATA spare parts
271526903803	OIL PUMP HSG. (OIL COOL & REAR PTO)BS2-6	TATA spare parts
271526903803AE	OIL PUMP HSG. (PTO) -1628-1828	TATA spare parts
271526903805	COVER BS6	TATA spare parts
271526904301	CIRCLIP ( 1.4 THK )	TATA spare parts

271526904302	CIRCLIP ( 1.5 THK )	TATA spare parts
271526904303	CIRCLIP ( 1.6 THK )	TATA spare parts
271526904304	CIRCLIP ( 1.7 THK )	TATA spare parts
271526905301	GASKET (OIL COOLING )	TATA spare parts
271526905301AE	GASKET (OIL COOLING )LPTA 1828/	TATA spare parts
271526905302	GASKET OIL PUMP HOUSING (REAR OIL PUMP)	TATA spare parts
271526905302AE	GASKET(REAR OIL PUMP)LPTA 1828	TATA spare parts
271526906901	INLET TUBE (OIL PUMP)	TATA spare parts
271526906902	SLEEVE (OIL PUMP)	TATA spare parts
271526906902AE	SLEEVE (OIL PUMP) 1628	TATA spare parts
271526907101	COVER (OIL PUMP)	TATA spare parts
271526907702	PLATE OIL PUMP (OIL COOLING)	TATA spare parts
271526907702AE	PLATE OIL PUMP 1628/ 1828	TATA spare parts
271526907901	ADAPTOR SHAFT ( FOR OIL PUMP)	TATA spare parts
271526908202	CAP (PRESSURE RELIEF VALVE) OIL PUMP	TATA spare parts
271526908701	COMPRESSION SPRING(OIL PUMP)	TATA spare parts
271526909901	INNER ROTOR	TATA spare parts
271526909901AE	INNER ROTOR 1628	TATA spare parts
271526909902	OUTER ROTOR	TATA spare parts
271526909902AE	OUTER ROTOR 1628	TATA spare parts
271526909903	INNER ROTOR (OILPUMP)	TATA spare parts
271526909904	OUTER ROTOR (OILPUMP)	TATA spare parts
271526909905	INNER ROTOR	TATA spare parts
271526909906	OUTER ROTOR	TATA spare parts
271526990101	KIT FOR RANGE SYNCHRONISER G1150	TATA spare parts
271526994701	PTO COVER	TATA spare parts
271526999901	KIT-GEAR BOX	TATA spare parts
271781800102	ASSY.MASCOT SUMO-EX 4X4	TATA spare parts
271929100112	HOSE ASSY.	TATA spare parts
271932300101	ASSY.BRACKET LH (FRT.SHOCK ABS.BKT.TOP)	TATA spare parts
271932300102	ASSY.BRACKET RH (FRT.SHOCK ABS.MTG.TOP)	TATA spare parts
271933000105	ASSY.FA-RH-TWIN POT-4X2-SAFARI	TATA spare parts
271933000106	ASSY.FA-LH-TWIN POT-4X2-SAFARI	TATA spare parts
271933200103	ASSY.STUB AXLE W.SEAL RACE-RH-TWIN POT	TATA spare parts
271933200104	ASSY.STUB AXLE W.SEAL RACE-LH-4X2-TWIN	TATA spare parts
271933205103	STUB AXLE-RH	TATA spare parts
271933205104	STUB AXLE - LH	TATA spare parts
271933400102	ASSY.HUB W.BRAKE DISC-4X2 TWIN POT	TATA spare parts
271933400103	SUB ASSY HUB WITH BOLT-4X2-ABS	TATA spare parts
271933403701	HUB (FRONT)-4X2- ABS	TATA spare parts
271940100114	ALLOY WHEEL RIM 6.5JX16	TATA spare parts
271940109912	BALANCE WEIGHT-10 GMS	TATA spare parts
271940109913	BALANCE WEIGHT-20 GMS	TATA spare parts
271940109914	BALANCE WEIGHT-30 GMS	TATA spare parts
271940109915	BALANCE WEIGHT-40 GMS	TATA spare parts
271940109916	BALANCE WEIGHT-50 GMS	TATA spare parts
271940109917	BALANCE WEIGHT-60 GMS	TATA spare parts

271940109918	BALANCE WEIGHT-70 GMS	TATA spare parts
271940109919	BALANCE WEIGHT- 80 GMS	TATA spare parts
271940109920	BALANCE WEIGHT- 90 GMS	TATA spare parts
271940109921	BALANCE WEIGHT- 100 GMS	TATA spare parts
271940109922	BALANCE WEIGHT-110 GMS	TATA spare parts
271940109923	BALANCE WEIGHT-120 GMS	TATA spare parts
271942100103	ASSY.TWIN POT CALIPER LH-	TATA spare parts
271942100104	SY.TWIN POT CALIPER RH	TATA spare parts
271942100111	MAJOR KIT FOR CALIPER ( BI 29932094)	TATA spare parts
271942100112	MINOR KIT FOR CALIPER ( BI 29932095)	TATA spare parts
271942100113	SLIDIING PIN KIT FOR CALIPER	TATA spare parts
271942100114	KIT PAD ASSY TWIN POT SAFARI	TATA spare parts
271942100115	KIT-PAD ASSY. W/PACKING EURO 2/4	TATA spare parts
271942100116	PAD ASSY	TATA spare parts
271942103701	BRAKE DISC (VENTILATED) TWIN POT CALIPER	TATA spare parts
271942103702	BRAKE DISC (VENTILATED)-FIN TYPE-TWINPOT	TATA spare parts
271942103704	BRAKE DISC (VENT)-TELCO-TWIN POT-4X2	TATA spare parts
271942104301	ANTI RATTLE CLIP	TATA spare parts
271942105402	TONER RING (F/WHL) 4X2-ABS	TATA spare parts
271942108001	CALIPER BLEED SCREW	TATA spare parts
271942109902	SHIM	TATA spare parts
271942300116	ASSY.REAR BRAKE-LH(2873 LINING AUTO ADJ)	TATA spare parts
271942300117	ASSY.REAR BRAKE-RH(2873 LINING AUTO ADJ)	TATA spare parts
271942300118	MAJOR KIT FOR W.C.25.4 DIA.	TATA spare parts
271942300119	MINOR KIT FOR W.C.25.4DIA.	TATA spare parts
271942300120	LINING SET KIT 1ST O/S	TATA spare parts
271942300121	WHEEL CYL.ASSY.Dia.25.4( BI 29665515)	TATA spare parts
271942300121AE	WHL CYL ASSY DIA 25.4 -XEN DC/SC	TATA spare parts
271942300122	LINED SHOE KIT (STD)	TATA spare parts
271942300123	KIT LINING SET FRONT STD (Sumo Gold)	TATA spare parts
271942300124	BACK PLATE ASSY-LH	TATA spare parts
271942300124_NIU	BACK PLATE ASSY-LH	TATA spare parts
271942300125	BACK PLATE ASSY-RH	TATA spare parts
271942300126	PUSH ROD ASSY-LH	TATA spare parts
271942300127	PUSH ROD ASSY-RH	TATA spare parts
271942300130	KIT LINING SET(STD)	TATA spare parts
271942300131	KIT LINING SET(1ST O/S)	TATA spare parts
271942300132	KIT LINED SHOE	TATA spare parts
271942300133	KIT LINED SHOE	TATA spare parts
271942300133AE	KIT LINED SHOE	TATA spare parts
271942305401	TONER RING (REAR AXLE) FOR ABS SPARE KIT	TATA spare parts
271942306001	LEVER PAWL-LH	TATA spare parts
271942306002	LEVER PAWL-RH	TATA spare parts
271942307701	GROMMET(COLLAPSING)	TATA spare parts
271942307702	GROMMET-HAND BRAKE LEVER	TATA spare parts
271942308001	BLEED SCREW-REAR BRAKE	TATA spare parts
271942308701	SHOE RETURN SPRING-W/C END	TATA spare parts

271942308702	SPRING SHOE RETURN-ABT-END	TATA spare parts
271942308703	SPRING FOR LEVER PAWL	TATA spare parts
271942800148	BRAKE HOSE ASSY. REAR	TATA spare parts
271943500106	TANDEM BOOSTER KIT-MAJOR	TATA spare parts
271943500107	TANDEM BOOSTER KIT-MINOR	TATA spare parts
271949200108	ASSY EXHAUST PIPE REAR COMPLETE	TATA spare parts
271954606302	WSS CONNECTOR MTG.CLAMP M/s TYCO	TATA spare parts
271958900701	ADAPTOR/CHECK ENG. COMPRESSOR	TATA spare parts
271958900702	PULLER/REMOVER INJECTOR	TATA spare parts
271958902502	WING NUT 10SQ/CLUTH BLEEDING CYL/ 2.2/C	TATA spare parts
271969106302	REAR HALF REAR QTR TRIM LH (W/K COVERS)	TATA spare parts
271969106303	FRONT HALF REAR QTR TRIM RH (W/K COVERS)	TATA spare parts
271969106304	REAR HALF REAR QTR TRIM RH (W/K COVERS)	TATA spare parts
271973700107	ASSY TRIM REAR DOOR RH (W/O A/LAMP)	TATA spare parts
271973700108	ASSY TRIM REAR DOOR LH (W/O A/LAMP)	TATA spare parts
271981100102	MASCOT SAFARI EX	TATA spare parts
271981100103	COVER SPARE WHEEL	TATA spare parts
271985100101BM	A SPOILER COMP FIJI BLUE NLS	TATA spare parts
271988506332	FRONT BUMPER GUARD	TATA spare parts
271988506333	CEN. CVR. FRT BUMP (EX) LH	TATA spare parts
271988506334	CEN. CVR. FRT BUMP (EX) RH	TATA spare parts
272129101601	CLUTCH M. CYL.WITH BOTTLE	TATA spare parts
272130100101	ASSY. ACCELERATOR CABLE - TL 4PL	TATA spare parts
272131000104	ASSY.FRAME FACELIFT	TATA spare parts
272131000106	ASSY.FRAME (2.2L DICR 4X4 31WB)	TATA spare parts
272131000107	FRAME XENON 4X4 2.2LDICR CREWCAB	TATA spare parts
272131000108	ASSY FRAME 4X4 (SPRINT 3L DICOR CREWCAB)	TATA spare parts
272131100101	ASSY. BODY MTG. BRACKET	TATA spare parts
272131200102	ASSY. CROSS MEMBER(FUEL TANK MTG.REAR)	TATA spare parts
272131200108	ASSY.CROSS RUNNER (LOAD BODY MTG.)	TATA spare parts
272131200110	ASSY CROSS MEMBER (CENTER BEARING MTG.)	TATA spare parts
272131200111	TOWING HOOK	TATA spare parts
272131200112	ASSY CROSS MEMBER (CENTER BEARING MTG.)	TATA spare parts
272131206901	CROSS MEMBER	TATA spare parts
272141000101	ASSY.PRO.SHAFT	TATA spare parts
272141000103	ASSY.PRO.SHAFT	TATA spare parts
272141100103	ASSY.PROP.SHAFT REAR COMPLETE - SINGLE C	TATA spare parts
272142800107	ASSY.TUBE	TATA spare parts
272142800108	ASSY. TUBE	TATA spare parts
272142800109	ASSY.TUBE	TATA spare parts
272142800111	ASSY.BRACKET (LCRV MTG.)	TATA spare parts
272142800112	ASSY. TUBE	TATA spare parts
272142800114	ASSY. TUBE	TATA spare parts
272142800116	ASSY. FRONT BRAKE HOSE(BIL A 2904664 TL)	TATA spare parts
272142800133	ASSY. TUBE	TATA spare parts
272142800134	ASSY. TUBE	TATA spare parts
272142800135	ASSY. TUBE	TATA spare parts

272142800136	ASSY. TUBE	TATA spare parts
272146600201	ASSY.POWER STG.RESERVOIR WITH BKT.	TATA spare parts
272146800113	ASSY. SUCTION HOSE (TANK TO PUMP)	TATA spare parts
272146800114	ASSY. HIGH PRESS HOSE (PUMP TO SOCKET)	TATA spare parts
272146800115	ASSY. HIGH PRESS LINE (SOCKET TO G. BOX)	TATA spare parts
272146800116	ASSY. LOW PRESS HOSE (G/BOX TO TANK)	TATA spare parts
272146800117	ASSY.SUCTION LINE (RESERVOIR TO PUMP)	TATA spare parts
272146800118	ASSY.RETURN LINE (G/BOX TO RESERVOIR)	TATA spare parts
272146800119	ASSY.HIGH PRESSURE LINE (PUMP TO G/BOX)	TATA spare parts
272146800120	ASSY.SUCTION LINE (RESERVOIR TO PUMP)	TATA spare parts
272146800121	ASSY.HIGH PRESSURE LINE (PUMP TO G/BOX.)	TATA spare parts
272146800122	ASSY.RETURN LINE (G/BOX.TO RESERVOIR)	TATA spare parts
272146800123	ASSY SUCTION LINE (RESERVOIR TO PUMP)	TATA spare parts
272146800124	ASSY.RETURN LINE (G/BOX.TO RESERVOIR)	TATA spare parts
272147100103	ASSY. BRACKET (FUEL TANK MTG. FRONT)	TATA spare parts
272147100107	ASSY FILLER NECK TOP(+ BKT) FOR PLAS CAP	TATA spare parts
272147100108	ASSY FILLER NECK TOP(+ BKT)FOR METAL CAP	TATA spare parts
272147600101	SUCTION LINE ASSY	TATA spare parts
272147600102	ASSY.RETURN LINE (HOSE TO TANK)	TATA spare parts
272147600103	ASSY BREATHER TUBE (FILLER NECK TO TANK)	TATA spare parts
272147600104	ASSY BREATHER TUBE (FILLER NECK TO TANK)	TATA spare parts
272149200101	EXHAUST PIPE INTERMEDIATE	TATA spare parts
272149200105	EXH.PIPE INTERM.31WB	TATA spare parts
272149200109	ASSY EXHAUST PIPE REAR.	TATA spare parts
272149200120	ASSY. EXHAUST PIPE FRONT	TATA spare parts
272149200124	ASSY EXHAUST PIPE FRONT.(28/31WB E-III)	TATA spare parts
272149200125	ASSY EXHAUST PIPE MIDDLE.(31WB E-III)	TATA spare parts
272149200127	ASSY EXH PIPE REAR(FACELIFT- E II/E III)	TATA spare parts
272149200128	ASSY. EXHAUST PIPE FRONT (EURO-II)	TATA spare parts
272149200129	ASSY EXH PIPE REAR(SS ADAPT,FACE/L-E2/3)	TATA spare parts
272154108205	BATT.CABLE SUPPORT ANGLE	TATA spare parts
272154200110	ASSY.INSTRUMENT CLUSTER 1:0.812 WITH TRI	TATA spare parts
272154400101	ASSY.HEAD LAMP LH LHD	TATA spare parts
272154400102	ASSY.HEAD LAMP RH LHD	TATA spare parts
272154400103	ASSY.HEAD LAMP LH RHD	TATA spare parts
272154400104	ASSY.HEAD LAMP RH RHD	TATA spare parts
272154600103	W/H CABIN RHD	TATA spare parts
272154600137	WIRING HARNESS CABIN LHD EURO-II	TATA spare parts
272154600139	WIRING HARNESS FRONT EURO-II	TATA spare parts
272154600140	WIRING HARNESS FRONT EURO-III	TATA spare parts
272154600143	WIRING HARNESS CABIN RHD EURO-III	TATA spare parts
272154600148	WIRING HANESS TAIL 2.2L TL - 4X4	TATA spare parts
272154600149	WIRING HARNESS FRONT 2.2L E-IV - 4X4	TATA spare parts
272154600150	WIRING HARNESS CABIN LHD E-IV - 4X4	TATA spare parts
272154600151	WIRINGB HARNESS EMS 2.2L E-IV	TATA spare parts
272170000115BF	ASSY.LOAD BODY COMP.PAINTED.RHD ARTIC WH	TATA spare parts
272170000115BG	ASSY.LOAD BODY COMP.PAINTED.RHD MICA B_R	TATA spare parts



272170000115BM	ASSY.LOAD BODY COMP.PAINTED.RHD FIJI BLU	TATA spare parts
272170000115BN	ASSY.LOAD BODY COMP.PAINTED.RHD RUBY RED	TATA spare parts
272170000115BP	ASSY.LOAD BODY COMP.PAINTED.RHD METALLIC	TATA spare parts
272170000115D3	ASSY.LOAD BODY COMP.PAINTED.RHD ARTIC SI	TATA spare parts
272170000115D5	ASSY.LOAD BODY COMP.PAINTED.RHD TIMBER G	TATA spare parts
272170000115D7	ASSY.LOAD BODY COMP.PAINTED.RHD SILVER M	TATA spare parts
272170000115DP	ASSY.LOAD BODY COMP.PAINTED.RHD PASSION	TATA spare parts
272170000115DU	ASSY.LOAD BODY COMP.PAINTED.RHD QUARTZ B	TATA spare parts
272170000118BF	ASSY.LOAD BODY COMP.PAINTED. LHD ARTIC W	TATA spare parts
272170000118BG	ASSY.LOAD BODY COMP.PAINTED. LHD MICA B_	TATA spare parts
272170000118BM	ASSY.LOAD BODY COMP.PAINTED. LHD FIJI BL	TATA spare parts
272170000118BN	ASSY.LOAD BODY COMP.PAINTED. LHD RUBY RE	TATA spare parts
272170000118C3	ASSY.LOAD BODY COMP.PAINTED. LHD MICA BL	TATA spare parts
272170000118D3	ASSY.LOAD BODY COMP.PAINTED. LHD ARTIC S	TATA spare parts
272170000118D5	ASSY.LOAD BODY COMP.PAINTED. LHD TIMBER	TATA spare parts
272170000118D7	ASSY.LOAD BODY COMP.PAINTED. LHD SILVER	TATA spare parts
272170000118DP	ASSY.LOAD BODY COMP.PAINTED. LHD PASSION	TATA spare parts
272170000118DU	ASSY.LOAD BODY COMP.PAINTED. LHD QUARTZ	TATA spare parts
272170000119BF	ASSY.LOAD BODY COMP.W/FITMENTS LHD ARTIC	TATA spare parts
272170000119BG	ASSY.LOAD BODY COMP.W/FITMENTS LHD MICA	TATA spare parts
272170000119BM	ASSY.LOAD BODY COMP.W/FITMENTS LHD FIJI	TATA spare parts
272170000119BN	ASSY.LOAD BODY COMP.W/FITMENTS LHD RUBY	TATA spare parts
272170000119BP	ASSY.LOAD BODY COMP.W/FITMENTS LHD META	TATA spare parts
272170000119D3	ASSY.LOAD BODY COMP.W/FITMENTS LHD ARTIC	TATA spare parts
272170000119D5	ASSY.LOAD BODY COMP.W/FITMENTS LHD TIMBE	TATA spare parts
272170000119D7	ASSY.LOAD BODY COMP.W/FITMENTS LHD SILVE	TATA spare parts
272170000119DP	ASSY.LOAD BODY COMP.W/FITMENTS LHD PASSI	TATA spare parts
272170000119DU	ASSY.LOAD BODY COMP.W/FITMENTS LHD QUAR	TATA spare parts
272170000120BF	ASSY.LOAD BODY COMP.W/FITMENTS RHD ARTIC	TATA spare parts
272170000120BG	ASSY.LOAD BODY COMP.W/FITMENTS RHD MICA	TATA spare parts
272170000120BM	ASSY.LOAD BODY COMP.W/FITMENTS RHD FIJI	TATA spare parts
272170000120BN	ASSY.LOAD BODY COMP.W/FITMENTS RHD RUBY	TATA spare parts
272170000120D3	ASSY.LOAD BODY COMP.W/FITMENTS RHD ARTIC	TATA spare parts
272170000120D5	ASSY.LOAD BODY COMP.W/FITMENTS RHD TIMBE	TATA spare parts
272170000120DP	ASSY.LOAD BODY COMP.W/FITMENTS RHD PASSI	TATA spare parts
272170000121BF	ASSY.LOAD BODY COMPL.W/FITMENTS(PASS) AR	TATA spare parts
272170000121BG	ASSY.LOAD BODY COMPL.W/FITMENTS(PASS) MI	TATA spare parts
272170000121BM	ASSY.LOAD BODY COMPL.W/FITMENTS(PASS) FI	TATA spare parts
272170000121BN	ASSY.LOAD BODY COMPL.W/FITMENTS(PASS) RU	TATA spare parts
272170000121C3	ASSY.LOAD BODY COMPL.W/FITMENTS(PASS) MI	TATA spare parts
272170000121D3	ASSY.LOAD BODY COMPL.W/FITMENTS(PASS) AR	TATA spare parts
272170000121D5	ASSY.LOAD BODY COMPL.W/FITMENTS(PASS) TI	TATA spare parts
272170000121D7	ASSY.LOAD BODY COMPL.W/FITMENTS(PASS) SI	TATA spare parts
272170000121DU	ASSY.LOAD BODY COMPL.W/FITMENTS(PASS) QU	TATA spare parts
272170000130BF	ASSY.L/BODY COMP.PAINTED(W/O.CANOPY PROV	TATA spare parts
272170000130D3	ASSY.L/BODY COMP.PAINTED(W/O.CANOPY PROV	TATA spare parts
27217000Z127BF	ASSY. LOAD BODY COMPLETE PAINTED LHD AR	TATA spare parts

27217000Z127BM	ASSY. LOAD BODY COMPLETE PAINTED LHD FI	TATA spare parts
27217000Z127D3	ASSY. LOAD BODY COMPLETE PAINTED LHD AR	TATA spare parts
27217000Z127D5	ASSY. LOAD BODY COMPLETE PAINTED LHD TI	TATA spare parts
272170300103	SIDE WALL ASSY LH	TATA spare parts
272170300104	SIDE WALL ASSY RH	TATA spare parts
272170308201	SIDE PANEL OUTER LH	TATA spare parts
272170308202	SIDE PANEL OUTER RH	TATA spare parts
27217030C201	SIDE PANEL OUTER LH	TATA spare parts
27217030C202	SIDE PANEL OUTER RH	TATA spare parts
272191000105	ASSY.FRT.SEAT COMP RH(R/T)4X4	TATA spare parts
272254200106	INSTRUMENT CLUSTER ASSY	TATA spare parts
272254660101	W/H MAIN LP 713 24V RHD	TATA spare parts
27238	PINION BRG CUP INNER	TATA spare parts
27239	PINION BRG CONE INNR	TATA spare parts
2724110825R	380 DIA. (PUSH TYPE)CLUTCH FOR LPT1918 W	TATA spare parts
272425000102	CLUTCH KIT 330 DIA.COIL/ORGANIC	TATA spare parts
272425000130	ASSY. KIT 330DIA. COIL/CERAMIC CL	TATA spare parts
272425000134	ASSY .CLUTCH DISC COVER 200 DIA. BS1/3/4	TATA spare parts
272425000135	ASSY CLUTCH DISC & COVER ASSY 200 DIA	TATA spare parts
272425000158	ASSY. CLUTCH DISC & COVER 190 DIA. BS3/4	TATA spare parts
272425000160	260 DIA.SAC CLUTCH SET(2.2LTR 320NM SMF)	TATA spare parts
272425000190	CLUTCH RELEASE BEARING A	TATA spare parts
272425000223	SET-CLUTCH ASSY DIA 190	TATA spare parts
272425000224	SET-CLUTCH ASSY,DIA 260 SAC	TATA spare parts
272425000234	SET-CLUTCH ASSY,DIA 260 SAC	TATA spare parts
272425000235	CLUTCH DISC ASSY (DIA. 215) BS6	TATA spare parts
272425000245	SET-CLUTCH&ASSY&DIA&200	TATA spare parts
272425100103	ASSY.CLUTCH HOUSING WITH INSERT	TATA spare parts
272425100107	SUB ASSY. CLUTCH HOUSING. (LHD)	TATA spare parts
272425100117	SUB ASSY. CLUTCH HOUSING-RHD(G600/G750)	TATA spare parts
272425100118	SUB ASSY.CLUTCH HOUSING-LHD(G600/G750)	TATA spare parts
272425100135	ASSY CLUTCH HSG WITH RELEASE YOKE	TATA spare parts
272425100164	ADAPTER PLATE ASSY WITH DOWEL SLEEVE BS6	TATA spare parts
272425100174	ADAPTER PLATE ASSY WITH DOWEL SLEEVE BS6	TATA spare parts
272425103705	CLUTCH HOUSING (SAE-4)	TATA spare parts
272425103708	CLUTCH HOUSING - RHD	TATA spare parts
272425103709	CLUTCH HOUSING (SAE 1)	TATA spare parts
272425103710	CLUTCH HOUSING (SAE 2/G 600) BS1/2/3/4	TATA spare parts
272425103712	ADAPTOR-SAE1 TO SAE2(FW HSG& CLUTCH HSG)	TATA spare parts
272425103713	ADAPTER - SAE1 TO SAE2 (FW HSG & CLUTCH)	TATA spare parts
272425103714	ADAPTOR (FW.HSG & CL.HSG)	TATA spare parts
272425103720	CLUTCH HSG. RH BOOSTER-G750 BS3/4/6	TATA spare parts
272425103721	CL.HSG - LH SIDE BOOSTER FOR G750	TATA spare parts
272425103722	CLUTCH HSG. RH-BOOSTER-G1150 BS3/4/6	TATA spare parts
272425103724	CLUTCH HOUSING BS6	TATA spare parts
272425103729	CLUTCH HOUSING	TATA spare parts
272425103730	CLUTCH HOUSING	TATA spare parts

272425103738	ADAPTER PLATE BS6-PH2	TATA spare parts
272425103739	CLUTCH HOUSING BS6-PH2	TATA spare parts
272425103801	CLUTCH HOUSING SAE 4	TATA spare parts
272425103805	CLUTCH HOUSING (20 DEGREE INCLINATION)	TATA spare parts
272425103809	CLUTCH HOUSING	TATA spare parts
272425103811	CLUTCH HOUSING-HPDC (SAE-4)	TATA spare parts
272425103815	CLUCH HOUSING(2.2LTR 0 DEG DMF CSC G76 M	TATA spare parts
272425103822	CLUTCH HOUSING BS6	TATA spare parts
272425103823	CLUTCH HOUSING BS6	TATA spare parts
272425103824	CLUTCH HOUSING BS6	TATA spare parts
272425103825	CLUTCH HOUSING	TATA spare parts
272425103827	CLUTCH HOUSING&BS6	TATA spare parts
272425103828	CLUTCH HOUSING	TATA spare parts
272425103830	CLUTCH HOUSING BS6	TATA spare parts
272425103831	ADAPTER PLATE BS6-PH2	TATA spare parts
272425105302	SEALING STRIP (ON STARTER COVER)	TATA spare parts
272425107701	RUBBER BELLOW	TATA spare parts
272425107702	RUBBER BELLOW	TATA spare parts
272425107703	RUBBER BELLOW (ON CLUTCH HOUSING)	TATA spare parts
272425108004	HEX FLANGE BOLT (CLUTCH HSG MNTG)	TATA spare parts
272425108203	BACK COVER (ON CLUTCH HOUSING)	TATA spare parts
272425108204	CLUTCH HSG. BOTTOM COVER (SAE 1)	TATA spare parts
272425108205	BACK COVER-CL.HSG.20 DEG.ENG.INCLINATION	TATA spare parts
272425108206	BASE PLATE (ON RUBBER BELLOW)	TATA spare parts
272425108207	BACK COVER (ON G- 65 G/BOX)	TATA spare parts
272425108208	BASE PLATE (ON RUBBER BELLOW)	TATA spare parts
272425108210	BACK COVER (ON CLUTCH HOUSING)	TATA spare parts
272425108212	BACK COVER BS6-PH2	TATA spare parts
272425108213	COVER (INSPECTION WINDOW) FOR GEAR BOX H	TATA spare parts
272425108214	STARTER COVER (ON CLUTCH HSG)	TATA spare parts
272425108219	BACK COVER(NEW 0.75T)	TATA spare parts
272425108220	BACK COVER (ON G65 GEARBOX) BS6	TATA spare parts
272425108222	COVER (SAE-2 CLUTCH HOUSING)	TATA spare parts
272425108225	COVER ON CLUTCH RELEASE LEVER	TATA spare parts
272425108226	COVER (CLUTCH HOUSING SIDE)	TATA spare parts
272425108227	COVER CLUTCH HSG BS6	TATA spare parts
272425108228	COVER CLUTCH HSG BS6	TATA spare parts
272425108229	BACK COVER BS6	TATA spare parts
272425108230	BACK COVER BS6	TATA spare parts
272425108232	BACK COVER BS6	TATA spare parts
272425108233	BACK COVER BS6	TATA spare parts
272425108235	BACK COVER BS6	TATA spare parts
272425108236	BACK COVER BS6	TATA spare parts
272425108237	BACK COVER UPPER BS6	TATA spare parts
272425108238	BACK COVER LOWER BS6	TATA spare parts
272425108239	BACK COVER BS6	TATA spare parts
272425108240	BACK COVER BS6	TATA spare parts

272425108243	COVER CLUTCH HSG UPPER BS6	TATA spare parts
272425108801	STUD	TATA spare parts
272425113201	SCREW BS6-PH2	TATA spare parts
272425200101	CLUTCH DISC 310 DIA. BS2/3	TATA spare parts
272425200103	CL.DISC 310 DIA GB40	TATA spare parts
272425200104	ASSY.228 DIA.CLUTCH DISC SPACIO	TATA spare parts
272425200105	CLUTCH DISC ASSY 228 DIA	TATA spare parts
272425200107	CLUTCH DISC CERAMIC 330 DIA LPT1613	TATA spare parts
272425200108	CLUTCH DISC 330 DIA CERAMIC	TATA spare parts
272425200110	CLUTCH DISC 228 DIA. BS1	TATA spare parts
272425200111	KIT FACING 330 DIA CLUTCH DISC	TATA spare parts
272425200113	CLUTCH DISC 170 DIA. BS2/3/4	TATA spare parts
272425200118	ASSY CLUTCH DISC 170DIA	TATA spare parts
272425200125	ASSY 240DIA.DRIVEN PLATE - DICOR	TATA spare parts
272425200126	DISC ASSLY CLUTCH (DIA 330)	TATA spare parts
272425200127	ASSY. 240 DIA. CLUTCH DISC	TATA spare parts
272425200128	CLUTCH DISC 240 DIA.(F510) BS2/3	TATA spare parts
272425200132	ASSY CLUTCH DISC 170DIA	TATA spare parts
272425200134	CLUTCH DISC 380 DIA. BS1/2/3/4	TATA spare parts
272425200137	ASSY. CLUTCH DISC-(7SPRING) 330 DIA	TATA spare parts
272425200138	CLUTCH DISC 215 DIA. BS3/4	TATA spare parts
272425200139	CLUTCH DISC 215 DIA. BS2/3	TATA spare parts
272425200143	CLUTCH DISC 240 DIA	TATA spare parts
272425200144	ASSY. CLUTCH DISC-330 DIA	TATA spare parts
272425200145	ASSY.240 DIA.CL.DISC-REINF.FLANGE	TATA spare parts
272425200146	KIT-CLUTCH DISC 330 DIA. BS1/2/3/4	TATA spare parts
272425200147	CLUTCH DISC 200 DIA. BS1/3/4	TATA spare parts
272425200148	380 DIA CERAMIC CLUTCH DISC ASSLY	TATA spare parts
272425200149	CLUTCH DISC 170 DIA. (CNG)	TATA spare parts
272425200151	CLUTCH DISC 330 DIA. BS1/2/3/4/6	TATA spare parts
272425200152	CLUTCH DISC ASSEMBLY 170 DIA	TATA spare parts
272425200154	CLUTCH FACING KIT 380 DIA	TATA spare parts
272425200161	ASSY 240 DIA CL.DISC- (F810 DS)	TATA spare parts
272425200163	CLUTCH DISC 330 DIA. (2 RINGS) BS1/2/3/4	TATA spare parts
272425200164	CLUTCH DISC 160 DIA. BS2/3/4	TATA spare parts
272425200165	CLUTCH DISC 310 DIA. (REINF) BS3/4	TATA spare parts
272425200167	170 DIA. NEW DISC ASSEMBLY (CNG)	TATA spare parts
272425200170	ASSY 240 DIA CL.DISC(START/STOP NOISE)	TATA spare parts
272425200170DF	CLUTCH FACING 170 DIA ORG-3MM	TATA spare parts
272425200170DFWR	CLUTCH FACING 170 DIA ORG-3MM W/RIVETS	TATA spare parts
272425200171	CLUTCH DISC 190 DIA.(F510) BS3/4/6	TATA spare parts
272425200173	330 DIA.CLUTCH DISC FACING KIT	TATA spare parts
272425200176	CLUTCH DISC 380 DIA. BS3/4/6	TATA spare parts
272425200177	CLUTCH DISC 230 DIA.(WAD) BS2	TATA spare parts
272425200179	CLUTCH DISC 170 DIA	TATA spare parts
272425200180	CLUTCH DISC 310 DIA. WITH B4088 LIN	TATA spare parts
272425200181	CLUTCH DISC 330 DIA.WITH B8070 LIN	TATA spare parts

272425200182	CLUTCH DISC 280 DIA.WITH B8070 LIN	TATA spare parts
272425200183	CLUTCH DISC 240 DIA. WITH B8070 LIN	TATA spare parts
272425200184	CLUTCH DISC 240 DIA.(F810 DS) BS3/4	TATA spare parts
272425200184AE	ASSY 240 DIA CLUTCH DISC SMF	TATA spare parts
272425200186	CLUTCH DISC 380 DIA.(CERAMIC) BS1/2/3/4	TATA spare parts
272425200188	ASSLY 260 DIA CLUTCH DISC WITH B-8080LIN	TATA spare parts
272425200190	ASSY. CLUTCH DISC 280DIA. (HIGHER HYST)	TATA spare parts
272425200191	CLUTCH DISC ASSY DIA 310	TATA spare parts
272425200192	CLUTCH DISC ASSY 280NA (HIGH HYST.)	TATA spare parts
272425200196	CLUTCH DISC ASSY DIA 330	TATA spare parts
272425200198	CLUTCH DISC ASSY DIA 310	TATA spare parts
272425200200DF	CLUTCH FACING 200 DIA ORG-3MM	TATA spare parts
272425200200DFWR	CLUTCH FACING 200 DIA ORG-3MM W/RIVETS	TATA spare parts
272425200210	CLUTCH DISC ASSY,DIA 260	TATA spare parts
272425200213	ASSY. CLUTCH DISC 280 DIA. BS2/3/4	TATA spare parts
272425200215	CLUTCH DISC 380 DIA. BS2/3/4/6	TATA spare parts
272425200216	ASSY. CLUTCH DISC 280 DIA. BS2/3/4/6	TATA spare parts
272425200220	CLUTCH DISC 260 DIA. BS1/3/4	TATA spare parts
272425200221	CLUTCH DISC ASSY DIA 240 BS6	TATA spare parts
272425200232	CLUTCH DISC ASSY DIA 280 BS6	TATA spare parts
272425200235	CLUTCH DISC DIA 215 BS6	TATA spare parts
272425200237	CLUTCH DISC ASSY DIA 215	TATA spare parts
272425200238	CLUTCH DISC ASSY DIA 215 BS6-PH2	TATA spare parts
272425200246	CLUTCH DISC ASSY DIA 380 BS6	TATA spare parts
272425200247	CLUTCH DISC ASSY DIA 395 BS6	TATA spare parts
272425200249	CLUTCH DISC ASSY DIA 395 BS6 PH2	TATA spare parts
272425200251	CLUTCH DISC ASSY DIA 330 BS6	TATA spare parts
272425200264	CLUTCH DISC ASSY DIA 200 BS6	TATA spare parts
272425200265	CLUTCH DISC ASSY DIA 330 BS6-PH2	TATA spare parts
272425200267	CLUTCH DISC ASSY DIA 380 BS6-PH2	TATA spare parts
272425200274	CLUTCH DISC ASSY DIA 380 BS6-PH2	TATA spare parts
272425200280DF35	CLUTCH FACING 280 DIA ORG-3.5MM	TATA spare parts
272425200280DF35WR	CLUTCH FACING 280 DIA ORG-3.5MM W/RIVETS	TATA spare parts
272425200280DF40	CLUTCH FACING 280 DIA ORG-4MM	TATA spare parts
272425200280DF40WR	CLUTCH FACING 280 DIA ORG-4MM W/RIVETS	TATA spare parts
272425200310DF	CLUTCH FACING 310 DIA ORG-4.2MM	TATA spare parts
272425200310DFWR	CLUTCH FACING 310 DIA ORG-4.2MM W/RIVETS	TATA spare parts
272425200325DFWR	CLUTCH FACING 325 DIA ORG-W/RIVETS	TATA spare parts
272425200330DF	CLUTCH FACING 330 DIA ORG-4.2MM	TATA spare parts
272425200330DFWR	CLUTCH FACING 330 DIA ORG-4.2MM W/RIVETS	TATA spare parts
272425200380DF	CLUTCH FACING 380 DIA ORG	TATA spare parts
272425200380DFWR	CLUTCH FACING 380 DIA ORG-W/RIVETS	TATA spare parts
272425400102	CLUTCH COVER 330 DIA COIL TYPE LPT1613	TATA spare parts
272425400104	CLUTCH COVER 330 DIA COIL TYPE	TATA spare parts
272425400105	330DIA.CL.PR.PL.ASSY-DIAP CERAMIC	TATA spare parts
272425400106	LEVER KIT MINOR 330DIA	TATA spare parts
272425400107	LEVER KIT MAJOR 330DIA	TATA spare parts

272425400108	SPRING KIT 330DIA	TATA spare parts
272425400109	KIT-PRESSURE PLATE 330 DIA. BS1/2/3/4	TATA spare parts
272425400111	RELEASE LEVER KIT 330 DIA BS1/2/3/4	TATA spare parts
272425400112	ASSY RELEASE LEVER WITH EYE BOLT	TATA spare parts
272425400113	CLUTCH COVER 170 DIA. BS2/3/4	TATA spare parts
272425400114	ASSY CLUTCH COVER 170DIA	TATA spare parts
272425400118	ASSY CLUTCH COVER 170DIA	TATA spare parts
272425400121	240DIA.CLUTCH COVER ASY--DICOR	TATA spare parts
272425400125	ASSY. CLUTCH PR PLATE 240DIA. BS2/3	TATA spare parts
272425400129	CLUTCH COVER 380 DIA. BS1/2/3/4	TATA spare parts
272425400132	CLUTCH COVER 215 DIA.4DLTC BS3/4	TATA spare parts
272425400133	CLUTCH COVER 215 DIA. BS2/3	TATA spare parts
272425400137	CLUTCH COVER 240 DIA.	TATA spare parts
272425400138	CLUTCH COVER 330 DIA. BS1/2/3/4	TATA spare parts
272425400140	CLUTCH COVER 200 DIA. BS1/3/4	TATA spare parts
272425400141	CLUTCH COVER 170 DIA. (CNG)	TATA spare parts
272425400143	CLUTCH COVER 330 DIA. (COIL) BS1/2/3/4/6	TATA spare parts
272425400144	ASSY. CLUTCH COVER 170 DIA. BS2/3/4	TATA spare parts
272425400146	KIT-PRESSURE PLATE BS1/2/3/4	TATA spare parts
272425400147	RELEASE LEVER SERVICE KIT BS1/2/3/4	TATA spare parts
272425400148	KIT-RELEASE LEVER W/EYE BOLT BS1/2/3/4	TATA spare parts
272425400150	HOLD DOWN BOLT KIT	TATA spare parts
272425400151	CLUTCH COVER 380 DIA. BS2/3	TATA spare parts
272425400157	ASSY 240 DIA CL.COVER	TATA spare parts
272425400157AE	PRSSR CLUTCH PLATE -XENON DC/SC	TATA spare parts
272425400159	CLUTCH COVER 160 DIA. BS2/3/4	TATA spare parts
272425400160	CLUTCH COVER 310 DIA. (REINF) BS3/4/6	TATA spare parts
272425400164	CLUTCH COVER 190 DIA. BS3/4	TATA spare parts
272425400166	CLUTCH COVER 330 DIA. BS3/4	TATA spare parts
272425400167	CL COVER 330 DIA (CERAMIC-SHEET METAL)	TATA spare parts
272425400168	CLUTCH RELEASE LEVER KIT (FULL) 330 DIA	TATA spare parts
272425400169	CLUTCH RELEASE LEVER KIT (HALF) 330 DIA	TATA spare parts
272425400171	CLUTCH COVER 190 DIA. BS3/4	TATA spare parts
272425400175	ASSY. CLUTCH COVER 380 DIA. BS3/4/6	TATA spare parts
272425400185	CLUTCH COVER 380 DIA. CERAMIC BS1/2/3/4	TATA spare parts
272425400188	CLUTCH COVER 260 DIA. BS1/3/4	TATA spare parts
272425400193	CLUTCH COVER ASSY DIA 330	TATA spare parts
272425400194	ASSY.280 DIA. PRESSURE PLATE 497 ALL	TATA spare parts
272425400197	CLUTCH COVER ASSY DIA 190	TATA spare parts
272425400198	CLUTCH COVER ASSY DIA 200	TATA spare parts
272425400211	CLUTCH COVER ASSY DIA 240 BS6	TATA spare parts
272425400213	ASSY. CLUTCH COVER 280 DIA. BS2/3/4	TATA spare parts
272425400215	CLUTCH COVER 380 DIA. BS2/3/4/6	TATA spare parts
272425400216	ASSY. CLUTCH COVER 280DIA.	TATA spare parts
272425400222	CLUTCH COVER ASSY DIA 240 BS6	TATA spare parts
272425400232	CLUTCH COVER ASSY DIA 280 BS6	TATA spare parts
272425400235	CLUTCH COVER ASSY DIA 215 BS6	TATA spare parts

272425400237	CLUTCH COVER ASSY DIA 215 BS6-PH2	TATA spare parts
272425400247	CLUTCH COVER ASSY DIA 395 BS6	TATA spare parts
272425400249	CLUTCH COVER ASSY DIA 395 BS6 PH2	TATA spare parts
272425400252	CLUTCH COVER ASSY DIA 330 BS6	TATA spare parts
272425400265	CLUTCH COVER ASSY DIA 330 BS6-PH2	TATA spare parts
272425400267	CLUTCH COVER ASSY DIA 380 BS6-PH2	TATA spare parts
272425400274	CLUTCH COVER ASSY DIA 380 BS6-PH2	TATA spare parts
272425403701	COVER FINISHED	TATA spare parts
272425403704	CLUTCH COVER 380 DIA.	TATA spare parts
272425406706	COTTER PIN	TATA spare parts
272425408601	COLLECTOR RING BS1/2/3/4	TATA spare parts
272425408602	CLUTCH COLLECTOR RING BS1/2/3/4	TATA spare parts
272425408704	KIT-PRESSURE SPRING 330 DIA. BS2/3	TATA spare parts
272425408706	PRESSURE SPRING 380 DIA. BS1/2/3/4	TATA spare parts
272425600102	ASSY BRACKET OUTSIDE	TATA spare parts
272425600103	ASSY OUTER RACE	TATA spare parts
272425600106	ASSY CLUTCH RELEASE FORK	TATA spare parts
272425600107	ASSY. CLUTCH RELEASE FORK WITH BEARING	TATA spare parts
272425600108	ASSY. CL.REL. BRG.-SELF CENTERING	TATA spare parts
272425600109	ASSY.CL.REL.BRG. SELF CENTERING	TATA spare parts
272425600110	ASLY CLUTCH RELEASE BRG	TATA spare parts
272425600114	ASSY BRACKET OUT SIDE	TATA spare parts
272425600115	ASSY. BRACKET OUTSIDE-RHD	TATA spare parts
272425600121	ASSY CLUTCH RELEASE FORK WITH BALL PIN	TATA spare parts
272425600122	ASSY.CL.REL.BRG.(SELF CENTRING)	TATA spare parts
272425600125	ASSY. CLUTCH RELEASE BEARING BS2/3/4/6	TATA spare parts
272425600127	ASSY CLUTCH RELEASE BEARING	TATA spare parts
272425600130	ASSY.CLUTCH RELEASE FORK WITH BEARING	TATA spare parts
272425600131	ASSY.CLUTCH RELEASE BEARING WITH SLEEVE	TATA spare parts
272425600134	ASSY. CLUTCH RELEASE BRG WITH SLEEVE	TATA spare parts
272425600136	ASSY. CLUTCH RELEASE YOKE BS2/3/4/6	TATA spare parts
272425600137	ASY.CL.RELS.BRG SELF-CENTERED	TATA spare parts
272425600141	ASSY. CLUTCH RELEASE BRG. BS1/2/3	TATA spare parts
272425600141DF	CLUTCH RELEASE BEARING 380 DIA-GB750	TATA spare parts
272425600142	ASSY.CL.REL.BRG(SELF CENTERING)	TATA spare parts
272425600145	ASSY CROSS SHAFT WITH LEVER	TATA spare parts
272425600151	ASSY.CL.REL.BRG SELF CENT-LHS-48.5	TATA spare parts
272425600153	ASSY. COVER - RHS	TATA spare parts
272425600157	ASSY.CL.REL.BRG.W/PLASTIC SLEEVE	TATA spare parts
272425600159	ASY.CL.RELEASE BRG-RHS(SELF CENT)	TATA spare parts
272425600160	ASSY. CLUTCH REL BRG LHS(SELF CENT)BS1-4	TATA spare parts
272425600161	ASY.CLUTCH RELEASE BRG(SELF CENT)	TATA spare parts
272425600162	ASSY CLUTCH RELEASE BEARING	TATA spare parts
272425600163	ASSY.CL.RELS.BRG-SELF CENT-TEXSPIN(36MM)	TATA spare parts
272425600164	ASSY. CLUTCH RELEASE YOKE FRGD BS1/3/4	TATA spare parts
272425600167	ASSY. BRACKET OUTSIDE	TATA spare parts
272425600168	ASSY.CL.REL.BRG W/PLASTIC SLEEVE-TEXSPIN	TATA spare parts

272425600168AE	CLUTCH BEARING XEN DC XEN SC	TATA spare parts
272425600173	CLUTCH RELEASE BRG. 380 DIA. LPS49 BS3/4	TATA spare parts
272425600176	ASSY.COVER-LHS	TATA spare parts
272425600179	ASSY.CL.REL.BRG-W/PL.SLEEVE	TATA spare parts
272425600181	ASSY. CLUTCH RELEASE YOKE	TATA spare parts
272425600183	ASSY.CL.REL.BRG-SELF CENT-INA(36MM)	TATA spare parts
272425600187	ASSY. CROSS SHAFT WITH LEVER	TATA spare parts
272425600188	380 DIA. ASSY. CLUTCH RELEASE BEARING.	TATA spare parts
272425600189	CL. REL. BRG 380 DIA CLUTCH FOR LPT2523	TATA spare parts
272425600189AE	CLUTCH BEARING 2523	TATA spare parts
272425600191	ASSY COVER (310 DIA. CLUTCH)	TATA spare parts
272425600193	CLUTCH RELEASE BEARING ASSY	TATA spare parts
272425600195	ASSY. CROSS SHAFT WITH LEVER	TATA spare parts
272425600197	ASSY. CROSS SHAFT WITH RELEASE LEVER	TATA spare parts
272425600198	ASSY. CROSS SHAFT WITH LEVER	TATA spare parts
272425600199	ASSY. CLUTCH RELEASE BRG BS3	TATA spare parts
272425600201	ASSY. CLUTCH RELEASE BEARING BS3/4	TATA spare parts
272425600205	ASSY.CL.REL.BRG W/PLASTIC SLEEVE-TEXSPI	TATA spare parts
272425600207	ASSY. CLUTCH REL BRG. (SELF CENT) BS1- 4	TATA spare parts
272425600208	ASSY CLUTCH RELEASE LEVER	TATA spare parts
272425600209	NEEDLE ROLLER BEARING	TATA spare parts
272425600211	ASSY BRACKET (PCA MOUNTING)	TATA spare parts
272425600212	CROSS SHAFT ASSY WITH LEVER	TATA spare parts
272425600213	ASSY PUSH ROD	TATA spare parts
272425600217	ASSY.CLUTCH REL. BEARING	TATA spare parts
272425600220	ASSY. CLUTCH RELEASE YOKE WITH DOWEL. BS	TATA spare parts
272425600221	ASSY. CROSS SHAFT WITH LEVER	TATA spare parts
272425600225	ASSY. CLUTCH RELEASE BRG. 380 DIA. BS2/3	TATA spare parts
272425600227	ASSY CLUTCH RELEASE BEARING	TATA spare parts
272425600236	ASSY. CROSS SHAFT WITH LEVER	TATA spare parts
272425600241	ASSY. CROSS SHAFT WITH LEVER	TATA spare parts
272425600242	CROSS SHAFT ASSY WITH REL LEVER	TATA spare parts
272425600244	CLUTCH RELEASE BRG W/PL.SL.(34.5)	TATA spare parts
272425600245	CLUTCH RELEASE BRG W/PL.SL(36.0) BS1/3/4	TATA spare parts
272425600246	CLUTCH RELEASE BRG W/PL.SL.(51.6)	TATA spare parts
272425600249	KIT-CLUTCH ASSY RETRO-LPO 1613 CNG BSIV	TATA spare parts
272425600251	CLUTCH RELEASE BRG	TATA spare parts
272425600252	BALL PIN ASSY WITH ADAPTOR	TATA spare parts
272425600260	CLUTCH RELEASE BEARING(80.75 MM)	TATA spare parts
272425600265	CLUTCH RELEASE BEARING WITH SLEEVE	TATA spare parts
272425600266	CLUTCH RELEASE BEARING (60 MM STANDOUT)	TATA spare parts
272425600267	CLUTCH RELEASE BEARING	TATA spare parts
272425600273	CLUTCH RELEASE BEARING ASSY BS6-PH2	TATA spare parts
272425600274	HOSE ASSY	TATA spare parts
272425600275	CROSS SHAFT ASSY WITH LEVER	TATA spare parts
272425600278	CLUTCH RELEASE FORK ASSY BS6	TATA spare parts
272425600284	CLUTCH RELEASE BEARING ASSY BS6	TATA spare parts



272425600285	CLUTCH RELEASE BEARING ASSY BS6	TATA spare parts
272425600287	CLUTCH RELEASE BEARING ASSY BS6	TATA spare parts
272425600289	CLUTCH RELEASE BEARING ASSY BS6	TATA spare parts
272425600303	BRACKET ASSY PCA MTG BS6	TATA spare parts
272425600305	CLUTCH RELEASE BEARING ASSY	TATA spare parts
272425600308	CLUTCH RELEASE LEVER ASSY BS6-PH2	TATA spare parts
272425601602	ASSY. CLUTCH RELEASE BEARING	TATA spare parts
272425601611	ASSY CLUTCH RELEASE BEARING	TATA spare parts
272425603102	NEEDLE ROLLER BRG.-(HOUSING)	TATA spare parts
272425603401	BUSH - CLUTCH RELEASE FORK	TATA spare parts
272425603403	BUSH¿UPPER	TATA spare parts
272425605101	CLUTCH RELEASE FFORK	TATA spare parts
272425605101AE	RELEASE FORK 713	TATA spare parts
272425605102	CLUTCH RELEASE FORK BS1/2/3	TATA spare parts
272425605105	CLUTCH RELEASE FORK(REINFORCED)-156MM.	TATA spare parts
272425605106	CLUTCH RELEASE FORK (REINFORCED)	TATA spare parts
272425605107	CLUTCH RELEASE FORK	TATA spare parts
272425605108	CLUTCH RELEASE YOKE BS1/2/3/4	TATA spare parts
272425605109	CLUTCH RELEASE YOKE	TATA spare parts
272425605110	CLUTCH RELEASE FORK (REINFORCED)	TATA spare parts
272425605111	CLUTCH RELEASE FORK (156)	TATA spare parts
272425605113	CLUTCH RELEASE YOKE	TATA spare parts
272425605114	CLUTCH RELEASE FORK	TATA spare parts
272425605116	CLUTCH RELEASE YOKE	TATA spare parts
272425605119	CLUTCH RELEASE YOKE	TATA spare parts
272425605121	CLUTCH RELEASE FORK	TATA spare parts
272425605122	CLUTCH RELEASE FORK - 164 MM	TATA spare parts
272425605123	CLUTCH RELEASE FORK (RATIO -2) BS3/4/6	TATA spare parts
2724256051230C	CLUTCH RELEASE FORK W/O LOCK ARRANGEMEN	TATA spare parts
272425605128	CLUTCH RELEASE FORK	TATA spare parts
272425605129	CLUTCH RELEASE FORK	TATA spare parts
272425605130	CLUTCH RELEASE FORK BS6	TATA spare parts
272425606001	CLUTCH RELEASE LEVER	TATA spare parts
272425606003	CLUTCH RELEASE LEVER	TATA spare parts
272425606004	CLUTCH RELEASE LEVER BS1/3/4	TATA spare parts
272425606005	CLUTCH RELEASE LEVER	TATA spare parts
272425606007	CLUTCH RELEASE LEVER	TATA spare parts
272425606012	CLUTCH RELEASE LEVER	TATA spare parts
272425606023	CLUTCH RELEASE LEVER BS6	TATA spare parts
272425606031	CLUTCH RELEASE LEVER BS6	TATA spare parts
272425606701	BALL PIN (CLUTCH RELEASE FORK PIVOT)	TATA spare parts
272425606703	ADJUSTER (CLUTCH REL.LEVER)	TATA spare parts
272425606704	BALL PIN(CLUTCH REL.YOKE PIVOT)	TATA spare parts
272425606705	BALL PIN (ADJUSTER TYPE) BS3/4/6	TATA spare parts
272425606707	BALL PIN BS6-PH2	TATA spare parts
272425607701	RUBBER BELLOW	TATA spare parts
272425607702	DUST SEAL	TATA spare parts

272425607704	BELLOW (ON CL.REL.YOKE)	TATA spare parts
272425607901	CROSS SHAFT	TATA spare parts
272425607905	CROSS SHAFT	TATA spare parts
272425607910	CROSS SHAFT	TATA spare parts
272425607917	CLUTCH RELEASE SHAFT BS6	TATA spare parts
272425608001	SET SCREW	TATA spare parts
272425608201	BRACKET INSIDE	TATA spare parts
272425608202	BRACKET OUTSIDE	TATA spare parts
272425608203	INSERT	TATA spare parts
272425608206	ASSY BRACKET INSIDE	TATA spare parts
272425608208	COVER CL HSG SIDE	TATA spare parts
272425608209	BRACKET INSIDE-RHD.	TATA spare parts
272425608701	LOCKING WIRE	TATA spare parts
272425608703	RETURN SPRING-CLUTCH RELEASE FORK	TATA spare parts
272425608705	SPRING RING (CLUTCH RELEASE FORK PIVOT)	TATA spare parts
272425608706	LOCKING WIRE	TATA spare parts
272425608708	LOCKING WIRE	TATA spare parts
272425609201	SPRING WASHER	TATA spare parts
272425990105	CLUTCH RELEASE BRG (352 DIA)	TATA spare parts
272425990106	KIT-CLUTCH REL MECH FITTED ON TRAN	TATA spare parts
272533050103	SHAANXI HANDE LIVE FRT AXLE W/O SADDLES	TATA spare parts
272533050104	ASSY FRONT AXLE LIVE COMP.W/BRAKES	TATA spare parts
272533159901	ADAPTOR (ON FRONT AXLE)M12X1.5	TATA spare parts
272535000109	REAR AXLE ASSY W/BRAKES - 4021	TATA spare parts
272535000125	ASSY BOGIE AXLE REAR NO 2 LPK2516TC-6X4	TATA spare parts
272535000155	ASSY BOGIE REAR AXLE FRONT LPK2516TC	TATA spare parts
272535000157	ASSY BOGIE REAR AXLE REAR LPK2516TC	TATA spare parts
272535000159	ASSY.BOGIE-REAR FRONT W/O HUB B.SADDLE	TATA spare parts
272535000160	ASY.BOGIE AXLE WITH BRK&HUB COMP. FRONT	TATA spare parts
272535000161	ASSY.BOGIE-REAR REAR W/O HUB B.SADDLE	TATA spare parts
272535000162	ASY.BOGIE AXLE WITH BRKS&HUB COMP. REAR	TATA spare parts
272535000163	ASY.TANDEM BOGIE-FRT.REAR+REAR REAR COMP	TATA spare parts
272535000177	ASSY.MERITOR BOGIE AXLE (REAR FRONT)6.17	TATA spare parts
272535000178	ASSY.MERITOR BOGIE AXLE (REAR REAR)6.17	TATA spare parts
272535000180	ASSY.BOGIE-REAR FRT W/O BRAKES HUB	TATA spare parts
272535000181	ASSY BOGIE AXLE REAR-FRT W/BRAKES HUB	TATA spare parts
272535000182	ASSY TANDEM AXLE COMPL WITH 165 DIA C/F	TATA spare parts
272535000185	ASSY. T.BOGIE AXLE (REAR FRONT)	TATA spare parts
272535000186	ASSY. T.BOGIE AXLE (REAR REAR)	TATA spare parts
272535000187	ASSY REAR AXLE T.BOGIE COMP.W/BRAKES	TATA spare parts
272535000193	TANDEM BOGIE MT28-1495 6.17 TML HUB BRKS	TATA spare parts
272535000194	ASSY.REAR AXLE FWD REAR COMPLETE	TATA spare parts
272535000195	ASSY AXLE FWD REAR W/O SHFT HUB BRK	TATA spare parts
272535000196	ASSY.REAR AXLE RWD REAR COMPLETE	TATA spare parts
272535000197	ASSY AXLE RWD REAR W/O SHFT HUB BRK	TATA spare parts
272535000198	AXLE BOGIE(MT26-108NX)6.83 1044 150SE	TATA spare parts
272535000199	AXLE MT26-108NX COMP REAR FWD 6.83 1044	TATA spare parts

272535000201	AXLE REAR FWD W/O HUB BRK 6.83 150	TATA spare parts
272535000202	AXLE MT26-108NX COMP REAR RWD 6.83 1044	TATA spare parts
272535000203	AXLE REAR RWD W/O HUB BRK 6.83 150	TATA spare parts
272535000206	ASY AXLE R/FWD W/AXLE SHAFT W/O HUB	TATA spare parts
272535000208	ASY AXLE R/RWD W/AXLE SHAFT W/O HUB	TATA spare parts
272535000210	ASY MERITOR T.BOGIE AXLE (REAR FRONT)	TATA spare parts
272535000211	ASY MERITOR T.BOGIE AXLE (REAR REAR)	TATA spare parts
272535000212	ASSY REAR AXLE MT28-1495 REAR FWD 1905	TATA spare parts
272535000213	ASSY REAR AXLE MT28-1495 REAR FWD W/AXL	TATA spare parts
272535000214	ASSY REAR AXLE MT28-1495 REAR RWD 1905	TATA spare parts
272535000215	ASSY REAR AXLE MT28-1495 REAR RWD W/AXL	TATA spare parts
272535000228	ASSY AXLE R/FWD 1905 6.83 180SER TML HUB	TATA spare parts
272535000230	ASSY RA COMP WITH RATIO 6.2 DISC BRK WI	TATA spare parts
272535000236	ASSY TANDEM BOGIE -FWD REAR - RWD WITH	TATA spare parts
272535000238	REAR AXLE 1495 R/FWD 6.83 W/O RA SHAFT H	TATA spare parts
272535000240	AXLE ASSY 1495 R/RWD 6.83 W/O RA SHAFT	TATA spare parts
272535000246	ASSY REAR AXLE 4.56/6.21 W/TML HUB END B	TATA spare parts
272535000247	ASSY SPEED AXLE 1814 4.56/6.21 T	TATA spare parts
272535000253	ASSY RWD AXLE COMP W/BRKS	TATA spare parts
272535000255	REAR AXLE S14-245 2-SPEED 1814 4.56/6.2	TATA spare parts
272535000282	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272535000283	REAR AXLE ASSY W/O BRAKES HUBS & SHAFTS	TATA spare parts
272535000289	REAR AXLE ASSY REAR-FWD	TATA spare parts
272535000290	REAR AXLE ASSY REAR-FWD	TATA spare parts
272535000292	REAR AXLE ASSY REAR-RWD	TATA spare parts
272535000296	REAR AXLE ASSY WITH PNEUMATIC SUSP	TATA spare parts
272535000297	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272535000299	REARAXLEASSYWITHBRAKEABS	TATA spare parts
272535000303	REAR AXLE ASSY W/O BRAKES HUBS & SHAFTS	TATA spare parts
272535000305	REAR AXLE ASSY W/O BRAKES HUBS & SHAFTS	TATA spare parts
272535000306	REAR AXLE ASSY W/O BRAKES HUBS & SHAFTS	TATA spare parts
272535000307	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272535000308	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272535009901	KIT-SPACER DRIVE PINION	TATA spare parts
272535009902	KIT-SHIM PINION	TATA spare parts
272535009903	KIT-THRUST WASHER	TATA spare parts
272535009904	KIT-GEAR HARDWARE	TATA spare parts
272535009905	KIT-DIFFERENTIAL CASES HARDWARE	TATA spare parts
272535009906	KIT-FASTENER CARRIER MTG	TATA spare parts
272535009907	KIT-PINION CAGE HARDWARE	TATA spare parts
272535009908	KIT-CARRIER & CAP HARDWARE	TATA spare parts
272535009909	KIT-THRUST SCREW WITH JAM NUT	TATA spare parts
272535009910	KIT-SPIDER DIFFERENTIAL	TATA spare parts
272535009911	KIT-OIL SEAL WITH PINION NUT	TATA spare parts
272535100101	HOUSING KIT	TATA spare parts
272535100102	PUSH ROD KIT LPK2516TC 6X4	TATA spare parts
272535100103	THRUST SCREW & JAM NUT KIT LPK2516TC 6X4	TATA spare parts

272535100104	BEAM ASY FWD/R	TATA spare parts
272535100105	BEAM ASY R/RR	TATA spare parts
272535100110	BEAM ASSY.REAR-FWD MERITOR	TATA spare parts
272535100111	BEAM ASY.REAR-REAR MERITOR	TATA spare parts
272535100112	BREATHER ASSY	TATA spare parts
272535100113	HOUSING ASSY REAR FWD (2518)	TATA spare parts
272535100114	HOUSING ASSY REAR REAR (2518)	TATA spare parts
272535100115	HOUSING ASSY REAR FWD (4923)	TATA spare parts
272535100116	HOUSING ASSY REAR REAR (4923)	TATA spare parts
272535100117	CARRIER MOUNTING FASTENERS KIT	TATA spare parts
272535100118	BEAM ASY.REAR-FWD	TATA spare parts
272535100119	BEAM ASY.REAR-RWD	TATA spare parts
272535100120	BEAM ASY.REAR FWD 2518	TATA spare parts
272535100121	BEAM ASY.REAR RWD 2518	TATA spare parts
272535100123	BEAM ASY.REAR-RWD MERITOR	TATA spare parts
272535100124	AXLE BEAM HOUSING - NON ABS	TATA spare parts
272535100127	BEAM ASY.REAR-FWD	TATA spare parts
272535100128	BEAM ASY.REAR-RWD	TATA spare parts
272535100129	BREATHER ASSY	TATA spare parts
272535100130	AXLE BEAM PARTS	TATA spare parts
272535100131	AXLE BEAM PARTS	TATA spare parts
272535100132	BEAM ASSY.REAR-RWD	TATA spare parts
272535100134	AXLE HOUSING ASSY FWD REAR	TATA spare parts
272535100135	AXLE HOUSING ASSY REAR RWD	TATA spare parts
272535100138	AXLE HOUSING ASSY	TATA spare parts
272535100139	AXLE HOUSING ASSY	TATA spare parts
272535100140	CARRIER HOUSING	TATA spare parts
272535100141	AXLE HOUSING ASSY	TATA spare parts
272535100142	CARRIER HOUSING	TATA spare parts
272535100143	AXLE HOUSING ASSY	TATA spare parts
272535100147	AXLE HOUSING ASSY	TATA spare parts
272535100148	AXLE HOUSING ASSY	TATA spare parts
272535105110	SPRING SADDLEBOTTOM-LOOSE	TATA spare parts
272535105301	SILASTIC LIQUID GASKET LPK2516TC 6X4	TATA spare parts
272535105302	GASKET-THRU SHAFT BRG CAGE LPK2516TC 6X4	TATA spare parts
272535106502	HEXAGON NUT (0637.006.092)	TATA spare parts
272535106701	COTTER PIN LPK2516TC 6X4	TATA spare parts
272535106902	HUB CARRIER	TATA spare parts
272535107201	MAGNETIC DRAIN PLUG	TATA spare parts
272535107202	FILLER PLUG	TATA spare parts
272535107203	PLUG FILLER LPK2516TC 6X4	TATA spare parts
272535107204	PLUG MAGNETIC LPK2516TC 6X4	TATA spare parts
272535107205	PLUG BREATHER LPK2516TC 6X4	TATA spare parts
272535107206	PLUG BREATHER HOLE	TATA spare parts
272535107207	MAGNETIC DRAIN PLUG	TATA spare parts
272535107208	FILLER PLUG	TATA spare parts
272535107216	PLUG BREATHER HOLE	TATA spare parts

272535108001	CAP SCREW-AIR SHIFT CHAMBER LPK2516TC 6X	TATA spare parts
272535108201	TYPE PLATE	TATA spare parts
272535108502	VENT SOCKET	TATA spare parts
272535108601	OIL SEAL RING-INNER	TATA spare parts
272535108601AE	OIL SEAL RING-INNER LPT 2523/	TATA spare parts
272535108802	STUD (0636.611.231)	TATA spare parts
272535109201	WASHER FLAT	TATA spare parts
272535109202	WASHER A=3.00	TATA spare parts
272535110104	CARRIER & CAP ASSY-REAR REAR LPK2516TC 6	TATA spare parts
272535110105	CARRIER & CAP ASSY-FWD REAR LPK2516TC 6X	TATA spare parts
272535110106	HOUSING ASSY RR LPK2516TC 6X4	TATA spare parts
272535110107	HOUSING ASSY FWD REAR LPK2516TC 6X4	TATA spare parts
272535110108	CARRIER MTG.FASTENERS KIT LPK2516TC 6X4	TATA spare parts
272535110109	CARRIER & CAP MTG FAST KIT LPK2516TC 6X	TATA spare parts
272535110110	CARRIER AND CAP ASSY.	TATA spare parts
272535110111	DIFF CARRIER & CAP ASSY	TATA spare parts
272535110112	DIFF.CARRIER & CAP	TATA spare parts
272535110113	2 SPEED CARRIER ASSY 4.56 RATIO	TATA spare parts
272535110114	DRIVE HEAD ASY	TATA spare parts
272535110124	WASHER FLAT & CAP SCREW	TATA spare parts
272535110125	RING - SNAP	TATA spare parts
272535110131	BEARING CAGE ASSY - INPUT SHAFT	TATA spare parts
272535110141	SNAP RING	TATA spare parts
272535110146	PINION CAGE ASSY.- THRU SHAFT	TATA spare parts
272535110149	CARRIER ASSY REAR FWD 6.83 RH T150	TATA spare parts
272535110161	CARRIER ASSY WITH CAP	TATA spare parts
272535110261	CARRIER ASSY DIFFERENTIAL	TATA spare parts
272535110262	CARRIER ASSY DIFFERENTIAL	TATA spare parts
272535110263	PINION CAGE ASSY	TATA spare parts
272535110265	DRIVE HEAD ASSY	TATA spare parts
272535110266	DRIVE HEAD ASSY	TATA spare parts
272535110267	DRIVE HEAD ASSY	TATA spare parts
272535113701	SHIFT HOUSING	TATA spare parts
272535113704	SHIFT HOUSING - FIN R1495 FWD CARR-	TATA spare parts
272535114801	DOWEL-COVER TO CARRIER LPK2516TC 6X4	TATA spare parts
272535114802	DOWEL PIN	TATA spare parts
272535159902	ADAPTOR (ON REAR AXLE HOUSING)	TATA spare parts
272535300101	DIF CASE ASSY-MAIN DIFF LPK2516TC 6X4	TATA spare parts
272535300102	ASSY. CROWN & PINION RR(SA-2-C0044)BS1/2	TATA spare parts
272535300102DF	CROWN & PINION ASSY 6.83-RR RWD-2516BS2	TATA spare parts
272535300102DFPN	PINION OF CWP 41/6-6.83-RR RWD-LPK2516	TATA spare parts
272535300103	ASSY. CROWN & PINION FWD RR BS1/2	TATA spare parts
272535300103DF	CROWN & PINION ASSY 6.83-RR FWD-2516BS2	TATA spare parts
272535300103DFPN	PINION OF CWP 41/6-6.83-RR FWD-LPK2516	TATA spare parts
272535300104	FLANGE.ASSY COMPANION-FWD.R LPK2516TC 6X	TATA spare parts
272535300105	DIF CASE ASSY-INTER AXLE LPK2516TC 6X4	TATA spare parts
272535300106	FLANGE ASSY COMPANION-REAR REAR LPK2516	TATA spare parts

272535300107	DIF CASE & NEST ASSY-IA LPK2516TC 6X4	TATA spare parts
272535300108	DIF CASE & NEST ASSY LPK2516TC 6X4	TATA spare parts
272535300109	DRIVE HEAD ASSY-RR LPK2516TC 6X4	TATA spare parts
272535300110	DRIVE HEAD ASSY-FWD R. LPK2516TC 6X4	TATA spare parts
272535300111	SNAP RING KIT LPK2516TC 6X4	TATA spare parts
272535300112	SPACER KIT LPK2516TC 6X4	TATA spare parts
272535300113	SHIM KIT-D.PINION/I.PUT S.FWD LPK2516TC	TATA spare parts
272535300114	AIR CHAMBER ASSY.W/HARDWARE LPK2516TC 6	TATA spare parts
272535300115	HARDWARE KIT-INTER A.DIFF LPK2516TC 6X4	TATA spare parts
272535300116	DIFF SPIDER KIT-MAIN DIF. LPK2516TC 6X4	TATA spare parts
272535300117	THRUST WASHER KIT LPK2516TC 6X4	TATA spare parts
272535300118	INPUT SHAFT KIT-REAR REAR LPK2516TC 6X4	TATA spare parts
272535300119	PINION CAGE MTG.FAST.KIT.FWD INNER LPK25	TATA spare parts
272535300120	PINION CAGE MTG FAST.KIT.RR LPK2516TC 6X	TATA spare parts
272535300121	PINION.CAGE MTG.FAST KIT.FW.IP LPK2516TC	TATA spare parts
272535300122	DIFF CASE MTG FASTNERS KIT LPK2516TC 6X	TATA spare parts
272535300123	SHIM KIT DRIVE PINION RR LPK2516TC 6X4	TATA spare parts
272535300124	HELICAL COVER MTG FAST.KIT LPK2516TC 6X4	TATA spare parts
272535300125	THRU SHAFT MTG FASTNERS KIT LPK2516TC 6X	TATA spare parts
272535300126	THRUST WASHER KIT-INTER AXLE LPK2516TC 6	TATA spare parts
272535300127	GEAR HARDWARE KIT LPK2516TC 6X4	TATA spare parts
272535300130	ASY COUP FLANGE	TATA spare parts
272535300131	COMPANION FLANGE ASSY FWD INPUT (2518)	TATA spare parts
272535300132	COMPANION FLANGE ASSY FWD OUTPUR (2518)	TATA spare parts
272535300133	DRIVE GEAR & PINION 6.17 R	TATA spare parts
272535300133DF	CROWN & PINION ASSY 6.17-RR RWD-4923	TATA spare parts
272535300133DFNG	CROWN & PINION ASSY 6.17-RR RWD-4923 NG	TATA spare parts
272535300133DFPN	PINION OF CWP 37/6-6.16-RR RWD-2523/4923	TATA spare parts
272535300133DFPNLN	PINION OF CWP 37/6-6.16 LONGER-RR RWD-25	TATA spare parts
272535300134	DIFF.CASE & NEST ASSY	TATA spare parts
272535300135	DIFF.CASE ASSY	TATA spare parts
272535300136	DIFFERENTIAL CASE & NEST ASSY	TATA spare parts
272535300137	DRIVE GEAR & PINION ASSY	TATA spare parts
272535300137DF	CROWN & PINION ASSY 6.17-RR FWD-4923	TATA spare parts
272535300137DFNG	CROWN & PINION ASSY 6.17-RR FWD-4923 NG	TATA spare parts
272535300137DFPN	PINION OF CWP 37/6-6.16-RR FWD-2523/4923	TATA spare parts
272535300137DFPNLN	PINION OF CWP 37/6-6.16 LONGER-RR FWD-25	TATA spare parts
272535300138	PINION CAGE ASSY.	TATA spare parts
272535300139	COMPANION FLANGE ASSY FWD INPUT (4923)	TATA spare parts
272535300140	COMPANION FLANGE ASSY FWD OUTPUT (4923)	TATA spare parts
272535300141	DIFF CASE & NEST ASSY- INTER AXLE	TATA spare parts
272535300142	BEARING CAGE ASSY - INPUT SHAFT	TATA spare parts
272535300143	CAGE & CUP & CONE ASSY THRU SHAFT	TATA spare parts
272535300144	DIFF SPIDER KIT	TATA spare parts
272535300145	THRUST WASHER KIT	TATA spare parts
272535300146	INPUT SHAFT KIT	TATA spare parts
272535300148	PINION CAGE MOUNTING FASTENERS KIT	TATA spare parts

272535300149	DIFF.CASE MOUNTING FASTENERS KIT	TATA spare parts
272535300150	FASTENER KIT	TATA spare parts
272535300151	SHIM KIT	TATA spare parts
272535300152	GEAR HARDWARE KIT	TATA spare parts
272535300153	SPACER KIT	TATA spare parts
272535300154	SHIM KIT	TATA spare parts
272535300155	SPACER KIT	TATA spare parts
272535300156	SNAP RING KIT	TATA spare parts
272535300157	CARRIER ASSY.DIFFERENTIAL	TATA spare parts
272535300158	CARRIER ASSY DIFFERENTIAL REAR REAR	TATA spare parts
272535300159	SHIM KIT	TATA spare parts
272535300160	GEAR SET-6.83 (REAR FWD-2518)	TATA spare parts
272535300160DF	CROWN & PINION 6.83-RR FWD-LPK2518BS3	TATA spare parts
272535300160DFNG	CROWN & PINION 6.83-RR FWD-LPK2518BS3 NG	TATA spare parts
272535300160DFPN	PINION OF CWP 41/6-6.83 RR FWD-LPK2518	TATA spare parts
272535300160DFPNLN	PINION OF CWP 41/6-6.83 LONGER-RR FWD-LP	TATA spare parts
272535300161	GEAR SET-6.83 (REAR RWD-2518)	TATA spare parts
272535300161DF	CROWN & PINION 6.83-RR RWD-LPK2518BS3	TATA spare parts
272535300161DFNG	CROWN & PINION 6.83-RR RWD-LPK2518BS3 NG	TATA spare parts
272535300161DFPN	PINION OF CWP 41/6-6.83-RR RWD-LPK2518	TATA spare parts
272535300161DFPNLN	PINION OF CWP 41/6-6.83 LONGER-RR RWD-LP	TATA spare parts
272535300164	COMPANION FLANGE ASSY - T180 FWD INPUT	TATA spare parts
272535300175	COMPANION FLANGE & DEFLECTOR ASSY	TATA spare parts
272535300176	DRIVE HEAD ASY	TATA spare parts
272535300177	INPUT SHAFT ASSY MTG FASTENERS KIT	TATA spare parts
272535300178	COMPANION FLANGE ASSY	TATA spare parts
272535300179	CARRIER MOUNTING FASTENERS KIT	TATA spare parts
272535300180	DRIVE HEAD ASY	TATA spare parts
272535300181	COMPANION FLANGE ASSY. I/P REAR REARWARD	TATA spare parts
272535300185	CARRIER ASSY DIFFERENTIAL - REAR FWD	TATA spare parts
272535300186	DIFFERENTIAL ASSY REAR AXLE	TATA spare parts
272535300187	DRIVE GEAR & PINION ASSY - 6.83 RATIO	TATA spare parts
272535300189	CARRIER ASSY. DIFFERENTIAL REAR RWD - 6	TATA spare parts
272535300190	CARRIER ASSY DIFFERENTIAL REAR FWD -6.83	TATA spare parts
272535300191	CARRIER ASSY. DIFFERENTIAL REAR REARWARD	TATA spare parts
272535300192	CARRIER ASSY DIFFERENTIAL - REAR FORWAR	TATA spare parts
272535300193	CARRIER ASSY. DIFFERENTIAL- REAR REARWA	TATA spare parts
272535300195	DRIVE GEAR & PINION REAR REARWARD LH	TATA spare parts
272535300200	COUPLING FLANGE ASSY T 150 RWD	TATA spare parts
272535300202	PINION CAGE ASSY	TATA spare parts
272535300203	DRIVE GEAR WITH PINION	TATA spare parts
272535300209	DIFFERENTIAL CASE & NEST ASSY	TATA spare parts
272535300210	DIFFERENTIAL CASE	TATA spare parts
272535300211	DRIVE GEAR WITH PINION	TATA spare parts
272535300212	DIFFERENTIAL CASE	TATA spare parts
272535300213	DIFFERENTIAL CASE & NEST ASSY	TATA spare parts
272535300214	FLANGE ASSY COMPANION-FWD REAR	TATA spare parts

272535300215	DIFFERENTIAL CASE & NEST ASSY	TATA spare parts
272535300216	COUPLING FLANGE ASSY	TATA spare parts
272535300217	DIFFERENTIAL CASE & NEST ASSY	TATA spare parts
272535300218	DIFFERENTIAL CASE	TATA spare parts
272535300220	KIT-GEAR HARDWARE	TATA spare parts
272535300222	DRIVE GEAR WITH PINION	TATA spare parts
272535300223	DRIVE GEAR WITH PINION	TATA spare parts
272535300224	DRIVE GEAR WITH PINION	TATA spare parts
272535300225	DRIVE GEAR WITH PINION	TATA spare parts
272535300227	KIT-OIL SEAL WITH PINION NUT	TATA spare parts
272535300228	KIT-THRUST SCREW WITH JAM NUT	TATA spare parts
272535300229	KIT-SPIDER DIFFERENTIAL	TATA spare parts
272535300230	KIT-GEAR HARDWARE	TATA spare parts
272535300237	KIT-SPIDER DIFFERENTIAL	TATA spare parts
272535303001	BALL-SHIFT FORK	TATA spare parts
272535303101	BEARING DRIVE PINION LPK2516TC 6X4	TATA spare parts
272535303102	CAGE CUP& CONE ASSY INPUT SHAFT LPK2516T	TATA spare parts
272535303103	CAGE CUP CONE ASSY MAIN DIFF FWD REAR L	TATA spare parts
272535303104	CAGE CUP CONE ASSY THRUSHAFT LPK2516TC	TATA spare parts
272535303105	CAGE CUP CONE ASSY MAIN DIFF REAR REAR	TATA spare parts
272535303106	BEARING INPUT SHAFT LPK2516TC 6X4	TATA spare parts
272535303107	BEARING DIFF LPK2516TC 6X4	TATA spare parts
272535303108	BEARING-INPUT SHAFT LPK2516TC 6X4	TATA spare parts
272535303109	BEARING-THRUSHAFT LPK2516TC 6X4	TATA spare parts
272535303110	CUP & CONE BRG	TATA spare parts
272535303111	CUP & CONE -BEARING OUTER	TATA spare parts
272535303113	PILOT BEARING	TATA spare parts
272535303114	CUP & CONE BRG INNER H715311	TATA spare parts
272535303115	CUP & CONE- BEARING OUTER	TATA spare parts
272535303116	CUP & CONE BRG JH211710	TATA spare parts
272535303117	CUP & CONE BRG JLM104910	TATA spare parts
272535303118	CUP& CONE - BEARING	TATA spare parts
272535303121	TA. ROLLER BEARING (0750.117.860)	TATA spare parts
272535303122	TA. ROLLER BEARING (0750.117.875)	TATA spare parts
272535303128	PINION BRG.CAGE	TATA spare parts
272535303129	CONE-DRIVE PINION OUTER BRG	TATA spare parts
272535303130	CUP-DRIVE PINION INNER BRG.	TATA spare parts
272535303131	CUP-DRIVE PINION OUTER BRG	TATA spare parts
272535303132	CONE-DRIVE PINION INNER BRG.	TATA spare parts
272535303133	BRG.DRIVE PINION SPIGOT	TATA spare parts
272535303134	CUP-SUPPORT CASE FLANGE BRG	TATA spare parts
272535303135	CONE-SUPPORT CASE FLANGE BRG.	TATA spare parts
272535303136	NEEDLE BRG.	TATA spare parts
272535303137	CONE-SUPPORT CASE PLAIN HALF BRG.	TATA spare parts
272535303138	CUP-SUPPORT CASE PLAIN HALFT BRG	TATA spare parts
272535303139	BEARING-CUP & CONE	TATA spare parts
272535303156	BEARING DRIVE PINION TAIL OUTER	TATA spare parts



272535303157	BEARING DRIVE PINION HEAD INNER	TATA spare parts
272535303158	BEARING DIFFERENTIAL	TATA spare parts
272535303159	TAPER ROLLER BEARING	TATA spare parts
272535303160	TAPER ROLLER BEARING	TATA spare parts
272535303161	TAPER ROLLER BEARING	TATA spare parts
272535303162	BEARING	TATA spare parts
272535303702	DIFFERENTIAL CASE	TATA spare parts
272535303703	DIFF.CASE PLANETARY HALF	TATA spare parts
272535303704	SUPPORT CASE-PLAIN HALF	TATA spare parts
272535303705	COVER	TATA spare parts
272535303708	COVER	TATA spare parts
272535304302	SNAP RING- DRIVE PINION	TATA spare parts
272535304323	SNAP RING	TATA spare parts
272535304601	COLLAR CLUTCH	TATA spare parts
272535304602	COLLAR CLUTCH- IAD 1495	TATA spare parts
272535304701	COVER-HELICAL GEAR LPK2516TC 6X4	TATA spare parts
272535304702	COVER - PINION DRIVE	TATA spare parts
272535304703	SILASTIC LIQUID	TATA spare parts
272535304705	SILASTIC LIQUID	TATA spare parts
272535305001	FLANGE OUTPUT-THRU SHAFT LPK2516TC 6X4	TATA spare parts
272535305003	FLANGE	TATA spare parts
272535305004	COUPLING FLANGE	TATA spare parts
272535305101	SPIDER-INTER AXLE LPK2516TC 6X4	TATA spare parts
272535305102	SPIDER-DIFFERENTIAL LPK2516TC 6X4	TATA spare parts
272535305103	SHIFT FORK LPK2516TC 6X4	TATA spare parts
272535305107	YOKE INPUT SHAFT-FF	TATA spare parts
272535305108	YOKE THROUGH SHAFT-FF	TATA spare parts
272535305109	YOKE D/PINION-R/REAR	TATA spare parts
272535305110	SPIDER -DIFF.	TATA spare parts
272535305111	SPIDER. DIFF - INTER AXLE	TATA spare parts
272535305118	SHIFT FORK	TATA spare parts
272535305119	SUPPORT CASE- PLANETARY HALF	TATA spare parts
272535305120	SPIDER-DIFF	TATA spare parts
272535305121	COUPLING FLANGE T-150	TATA spare parts
272535305401	PINION - CWP:-0103LPK2516 6X4	TATA spare parts
272535305402	PINION - CWP:-0102LPK2516 6X4	TATA spare parts
272535305403	SIDE GEAR-INTER AXLE LPK2516TC 6X4	TATA spare parts
272535305404	SIDE GEAR-MAIN DIFF LPK2516TC 6X4	TATA spare parts
272535305405	GEAR HELICAL DRIVE(INT) LPK2516TC 6X4	TATA spare parts
272535305406	GEAR HELICAL DRIVEN LPK2516TC 6X4	TATA spare parts
272535305407	PINION DIFF	TATA spare parts
272535305408	PINION DIFF- INTER AXLE	TATA spare parts
272535305409	SIDE GEAR - INTER AXLE	TATA spare parts
272535305410	SIDE GEAR MAIN DIFF	TATA spare parts
272535305411	GEAR INTEGRAL	TATA spare parts
272535305412	GEAR DRIVEN- HELICAL	TATA spare parts
272535305420	CLUTCH PLATE	TATA spare parts

272535305421	SUN GEAR	TATA spare parts
272535305422	CAP SCREW- SUPPORT CASE	TATA spare parts
272535305423	DRIVE GEAR & PINION	TATA spare parts
272535305424	PLANETARY GEAR	TATA spare parts
272535305425	SIDE GEAR-DIFF	TATA spare parts
272535305426	GEAR-DIFF.PINION	TATA spare parts
272535305427	SIDE GEAR-DIFF.(LONG HUB)	TATA spare parts
272535305430	SIDE GEAR MAIN DIFF	TATA spare parts
272535305431	PINION DIFF	TATA spare parts
272535305436	DIFFERENTIAL ASSY -KIT	TATA spare parts
272535305439	DIFFERENTIAL BEVEL GEAR	TATA spare parts
272535305440	DIFFERENTIAL SPIDER	TATA spare parts
272535305441	DIFFERENTIAL BEVEL PINION	TATA spare parts
272535305447	DIFFERENTIAL BEVEL GEAR	TATA spare parts
272535305448	DIFFERENTIAL BEVEL PINION	TATA spare parts
272535306301	CLUTCH-COLLER INPUT SHAFT LPK2516TC 6X4	TATA spare parts
272535306401	CYL.ROLLER BRG DRIVE PINION LPK2516TC 6X	TATA spare parts
272535306402	PILOT BEARING	TATA spare parts
272535306501	NUT-DRIVE PINION/INPUT SHAFT LPK2516TC 6	TATA spare parts
272535306502	NUT DRIVE PINION FWD REAR LPK2516TC 6X4	TATA spare parts
272535306503	NUT-THRU SHAFT LPK2516TC 6X4	TATA spare parts
272535306504	ADJ.RING-DIFF BRG LPK2516TC 6X4	TATA spare parts
272535306508	NUT- INPUT SHAFT	TATA spare parts
272535306509	NUT-DRIVE PINION	TATA spare parts
272535306510	RING -BEARING ADJ	TATA spare parts
272535306511	NUT	TATA spare parts
272535306516	NUT-DRIVE PINION	TATA spare parts
272535306517	LOCK NUT	TATA spare parts
272535306518	ADJUSTING RING-SUP T CASE FLANGE HALF	TATA spare parts
272535306519	ADJUSTING RING-SUP T CASE PLAIN HALF	TATA spare parts
272535306520	NUTSHIFT UNIT STUD	TATA spare parts
272535306521	NUT LPT 3118	TATA spare parts
272535306522	NUT	TATA spare parts
272535306528	WASHER HEAD BEARING & PINION	TATA spare parts
272535306529	LOCKING RING	TATA spare parts
272535306530	NUT	TATA spare parts
272535306531	SCREW	TATA spare parts
272535306706	COTTER PIN-ADJUSTING RING R.H	TATA spare parts
272535306707	PIN-SHIFT FORK	TATA spare parts
272535306708	PIN PLANETARY SHAFT	TATA spare parts
272535307201	PLUG FILLER	TATA spare parts
272535307202	PLUG DRAIN MAGNETIC	TATA spare parts
272535307203	PLUG	TATA spare parts
272535307204	SCREW-THRUST	TATA spare parts
272535307205	CAP SCREW LH (CLUTCH PLATE)	TATA spare parts
272535307206	CAP SCREW-DIFF.CASE	TATA spare parts
272535307207	CAP SCREW	TATA spare parts

272535307215	FILLER PLUG	TATA spare parts
272535307216	SCREW	TATA spare parts
272535307701	OIL SEAL ASSY-INPUT SHAFT LPK2516TC 6X4	TATA spare parts
272535307702	OIL SEAL ASSY-THRU SHAFT LPK2516TC 6X4	TATA spare parts
272535307703	OIL SEAL ASSY-DRIVE PINION LPK2516TC 6X4	TATA spare parts
272535307704	SILASTIC- SHIFT HSG & COVER TO HSG	TATA spare parts
272535307705	O' RING	TATA spare parts
272535307706	OIL SEAL	TATA spare parts
272535307707	OIL SEAL ASSY	TATA spare parts
272535307708	OIL SEAL	TATA spare parts
272535307708AE	OIL SEAL 2523	TATA spare parts
272535307709	SHAFT SEAL(0734.319.589)	TATA spare parts
272535307710	OIL SEAL- PINION CAGE ASSY	TATA spare parts
272535307711	ORING	TATA spare parts
272535307712	OIL SEAL	TATA spare parts
272535307713	SLEEVE - OIL SEAL	TATA spare parts
272535307714	OIL SEAL ASSY - FLANGE	TATA spare parts
272535307715	OIL SEAL ASSY	TATA spare parts
272535307716	COMPANION FLANGE DEFLECTOR ASSY	TATA spare parts
272535307717	OIL SEAL THRU SHAFT	TATA spare parts
272535307718	OIL SEAL ASSY	TATA spare parts
272535307803	OIL SEAL	TATA spare parts
272535307901	THRU SHAFT LPK2516TC 6X4	TATA spare parts
272535307902	INPUT SHAFT LPK2516TC 6X4	TATA spare parts
272535307903	THRU SHAFT	TATA spare parts
272535307904	INPUT SHAFT	TATA spare parts
272535307906	SHAFT-PLANETARY PINION	TATA spare parts
272535307907	SHIFT SHIFT	TATA spare parts
272535307909	INPUT SHAFT	TATA spare parts
272535307910	INPUT SHAFT	TATA spare parts
272535308001	ADJUSTING SCREW	TATA spare parts
272535308006	CAP SCREW	TATA spare parts
272535308007	LOCKING SCREW (0750.108.012)	TATA spare parts
272535308012	CAP SCREW- DIFF.BRG.CAP	TATA spare parts
272535308013	CAP SCREW-PINION BRG.CAGE	TATA spare parts
272535308201	SCREEN SHEET ZFN410-FU270 (4460.311.206)	TATA spare parts
272535308202	OIL SLEEVE THRU SHAFT	TATA spare parts
272535308333	SHIM A=0.63 (0730.110.446)	TATA spare parts
272535308334	SHIM A=0.66	TATA spare parts
272535308335	SHIM A=0.69	TATA spare parts
272535308336	SHIM A=0.72	TATA spare parts
272535308337	SHIM A=0.75	TATA spare parts
272535308338	SHIM A=0.78	TATA spare parts
272535308339	SHIM A=0.81	TATA spare parts
272535308340	SHIM A=0.84	TATA spare parts
272535308341	SHIM A=0.87	TATA spare parts
272535308342	SHIM A=0.90	TATA spare parts

272535308343	SHIM A=0.93	TATA spare parts
272535308344	SHIM A=0.96	TATA spare parts
272535308345	SHIM A=0.99	TATA spare parts
272535308346	SHIM A=1.02	TATA spare parts
272535308347	SHIM A=1.05	TATA spare parts
272535308348	SHIM A=1.08	TATA spare parts
272535308349	SHIM A=1.11	TATA spare parts
272535308350	SHIM A=1.14	TATA spare parts
272535308351	SHIM A=1.17	TATA spare parts
272535308352	SHIM A=1.20	TATA spare parts
272535308353	SHIM A=1.23	TATA spare parts
272535308354	SHIM A=1.26	TATA spare parts
272535308355	SHIM A=1.29	TATA spare parts
272535308356	SHIM A=1.32	TATA spare parts
272535308357	SHIM A=1.35	TATA spare parts
272535308358	SHIM A=1.38	TATA spare parts
272535308359	SHIM A=1.41	TATA spare parts
272535308360	SHIM A=1.44	TATA spare parts
272535308361	SHIM A=1.47	TATA spare parts
272535308362	SHIM A=1.50	TATA spare parts
272535308363	SHIM A=1.53	TATA spare parts
272535308364	SHIM A=1.56	TATA spare parts
272535308365	SHIM A=1.59	TATA spare parts
272535308366	SHIM A=1.62	TATA spare parts
272535308393	SHIMS- PINION BRG.CAGE	TATA spare parts
272535308394	SHIMS- PINION BRG.CAGE	TATA spare parts
272535308395	SHIMS- PINION BRG.CAGE	TATA spare parts
272535308396	SHIM SPACER PINION BRG	TATA spare parts
272535308397	SHIM SPACER PINION BRG	TATA spare parts
272535308398	SHIM SPACER PINION BRG	TATA spare parts
272535308399	SHIM SPACER PINION BRG	TATA spare parts
272535308401	SHIM SPACER PINION BRG	TATA spare parts
272535308402	SHIM SPACER PINION BRG	TATA spare parts
272535308403	SHIM SPACER PINION BRG	TATA spare parts
272535308404	SHIM SPACER PINION BRG	TATA spare parts
272535308405	SHIM SPACER PINION BRG	TATA spare parts
272535308406	SHIM SPACER PINION BRG	TATA spare parts
272535308407	SHIM SPACER PINION BRG	TATA spare parts
272535308408	SHIM SPACER PINION BRG	TATA spare parts
272535308409	SHIM SPACER PINION BRG	TATA spare parts
272535308410	SHIM SPACER PINION BRG	TATA spare parts
272535308411	SHIM SPACER PINION BRG	TATA spare parts
272535308412	SHIM SPACER PINION BRG	TATA spare parts
272535308413	SHIM SPACER PINION BRG	TATA spare parts
272535308414	SHIM SPACER PINION BRG	TATA spare parts
272535308415	SHIM SPACER PINION BRG	TATA spare parts
272535308416	SHIM SPACER PINION BRG	TATA spare parts

272535308417	SHIM SPACER PINION BRG	TATA spare parts
272535308418	SHIM SPACER PINION BRG	TATA spare parts
272535308419	SHIM SPACER PINION BRG	TATA spare parts
272535308420	SHIM SPACER PINION BRG	TATA spare parts
272535308421	SHIM SPACER PINION BRG	TATA spare parts
272535308422	SHIM SPACER PINION BRG	TATA spare parts
272535308423	SHIM SPACER PINION BRG	TATA spare parts
272535308424	SHIM SPACER PINION BRG	TATA spare parts
272535308425	SHIM SPACER PINION BRG	TATA spare parts
272535308426	SHIM SPACER PINION BRG	TATA spare parts
272535308427	SHIM SPACER PINION BRG	TATA spare parts
272535308428	SHIM SPACER PINION BRG	TATA spare parts
272535308429	SHIM SPACER PINION BRG	TATA spare parts
272535308430	SHIM SPACER PINION BRG	TATA spare parts
272535308601	SPACER-THRU SHAFT LPK2516TC 6X4	TATA spare parts
272535308602	SPACER	TATA spare parts
272535308627	RING A=11.00 (0730.161.128)	TATA spare parts
272535308628	RING A=10.95	TATA spare parts
272535308629	RING A=10.90	TATA spare parts
272535308630	RING A=10.85	TATA spare parts
272535308631	RING A=10.80	TATA spare parts
272535308632	RING A=10.75	TATA spare parts
272535308633	RING A=10.70	TATA spare parts
272535308634	RING A=10.65	TATA spare parts
272535308635	RING A=10.60	TATA spare parts
272535308636	RING A=10.55	TATA spare parts
272535308637	RING A=10.50	TATA spare parts
272535308638	RING A=10.45	TATA spare parts
272535308639	RING A=10.40	TATA spare parts
272535308640	RING A=10.35	TATA spare parts
272535308641	RING A=10.30	TATA spare parts
272535308642	RING A=10.25	TATA spare parts
272535308643	RING A=10.20	TATA spare parts
272535308644	RING A=10.15	TATA spare parts
272535308645	RING A=10.10	TATA spare parts
272535308646	RING A=10.05	TATA spare parts
272535308647	RING A=10.00	TATA spare parts
272535308648	RING A=9.95	TATA spare parts
272535308649	RING A=9.90	TATA spare parts
272535308650	RING A=9.85	TATA spare parts
272535308651	RING A=9.80	TATA spare parts
272535308652	RING A=9.75	TATA spare parts
272535308653	RING A=9.70	TATA spare parts
272535308654	RING A=9.65	TATA spare parts
272535308655	RING A=9.60	TATA spare parts
272535308656	RING A=9.55	TATA spare parts
272535308657	RING A=9.50	TATA spare parts

272535308660	SPACER- NEEDLE BRG.	TATA spare parts
272535308701	SPRING	TATA spare parts
272535308801	STUDSHIFT UNIT TO CARRIER	TATA spare parts
272535309201	THRUST WASHER-SIDE GEAR INTERAXLE LPK251	TATA spare parts
272535309202	WASHER-DRIVE PINION NUT LPK2516TC 6X4	TATA spare parts
272535309203	WASHER-THRU SHAFT LPK2516TC 6X4	TATA spare parts
272535309204	WASHER-INPUT SHAFT NUT LPK2516TC 6X4	TATA spare parts
272535309205	WASHER-CHAMBER TO HOUSING	TATA spare parts
272535309206	WASHER FLAT	TATA spare parts
272535309207	WASHER-FLAT	TATA spare parts
272535309208	WASHER	TATA spare parts
272535309209	WASHER-CARRIER AND CAP	TATA spare parts
272535309210	WASHER-DRIVE PINION NUT	TATA spare parts
272535309211	THRUST WASHER	TATA spare parts
272535309218	THRUST WASHER	TATA spare parts
272535309220	WASHER FLAT	TATA spare parts
272535309221	WASHER	TATA spare parts
272535309263	WASHER- PINION BRG.CAGE	TATA spare parts
272535309264	WASHER-DIFF.BRG.CAP	TATA spare parts
272535309265	THRUST WASHER- PLANETARY	TATA spare parts
272535309266	THRUST WASHER- SIDE GEAR	TATA spare parts
272535309267	THRUST WASHER-DIFF.	TATA spare parts
272535309269	WASHERSHIFT UNIT STUD	TATA spare parts
272535309273	WASHER-BEARING CAGE	TATA spare parts
272535309275	WASHER-CARRIER AND CAP	TATA spare parts
272535309288	WASHER	TATA spare parts
272535309401	LOCK RING-DRIVE PINION LPK2516TC 6X4	TATA spare parts
272535309901	COTTER	TATA spare parts
272535309902	RETAINER -BRG	TATA spare parts
272535309903	RING SNAP	TATA spare parts
272535309904	RETAINER- INPUT SHAFT	TATA spare parts
272535309905	RING LOCK	TATA spare parts
272535309917	HOUSING-SHIFT FIN 2 SPEED AXLE	TATA spare parts
272535309918	SWITCH & CONNECTOR ASSY	TATA spare parts
272535310103	DIFFERENTIAL	TATA spare parts
272535310104	AXLE CASING	TATA spare parts
272535310106	SET-BEVEL GEAR	TATA spare parts
272535318607	SPACER	TATA spare parts
272535318608	SPACER	TATA spare parts
272535600102	SPACER (SHIM) SPACER KIT	TATA spare parts
272535600103	WHEEL BEARING ADJ.FASTENERS KIT	TATA spare parts
272535600104	AXLE SHAFT MOUNTING FASTENERS KIT	TATA spare parts
272535600105	OIL SLINGER KIT	TATA spare parts
272535600106	SCREW PLUG ASSY M24X1.5	TATA spare parts
272535600107	ASSY.SCREW PLUG KPL.	TATA spare parts
272535600112	NUT	TATA spare parts
272535600113	CAP SCREW/WASHER FLAT	TATA spare parts

272535603103	HUB BEARING-OUTER	TATA spare parts
272535603104	HUB BRG.-INNER	TATA spare parts
272535603105	TA.ROLLER BEARING (0735.371.966)	TATA spare parts
272535603107	ROLLER CAGE (0750.115.555)	TATA spare parts
272535603108	ROLLER BEARING (0750.117.785)	TATA spare parts
272535603109	TA.ROLLER BEARING (0750.117.141)	TATA spare parts
272535603110	RING AXIAL ROLLER	TATA spare parts
272535603402	BUSH	TATA spare parts
272535603403	BUSH	TATA spare parts
272535603709	GANTRY HOUSING	TATA spare parts
272535603710	GANTRY HOUSING	TATA spare parts
272535604301	CIRCLIP SR.803750(0501.322.160)	TATA spare parts
272535604302	CIRCLIP	TATA spare parts
272535605404	INPUT SHAFT	TATA spare parts
272535605405	IDLER GEAR	TATA spare parts
272535605406	OUTPUT GEAR	TATA spare parts
272535605407	INPUT GEAR	TATA spare parts
272535605501	WHEEL HUB	TATA spare parts
272535605502	WHEEL HUB	TATA spare parts
272535605505	HUB(4472.298.186)	TATA spare parts
272535606503	SLOTTED NUT (0637.504.082)	TATA spare parts
272535606702	BRACKET	TATA spare parts
272535606703	BEARING PIN	TATA spare parts
272535607101	TAB WASHER	TATA spare parts
272535607104	SCREEN SHEET	TATA spare parts
272535607702	HUB OIL SEAL-INNER	TATA spare parts
272535607702AE	HUB OIL SEAL-INNER 2523	TATA spare parts
272535607703	OIL SEAL ASSY OUTER	TATA spare parts
272535607703AE	OIL SEAL ASSY.-OUTER 2523	TATA spare parts
272535607705	O-RING(0634.313.029)	TATA spare parts
272535607708	O-RING (0634.313.574)	TATA spare parts
272535607709	O-RING (0634.303.266)	TATA spare parts
272535607710	O-RING (0634.304.654)	TATA spare parts
272535607713	SHAFT SEAL	TATA spare parts
272535607715	O-RING	TATA spare parts
272535607716	RETAINING RING	TATA spare parts
272535607717	O-RING	TATA spare parts
272535607718	SEAL SHAFT	TATA spare parts
272535607908	STUB SHAFT	TATA spare parts
272535607909	FLANGE SHAFT	TATA spare parts
272535608001	CAP SCREW-GREASE HOLE	TATA spare parts
272535608012	SCREW	TATA spare parts
272535608013	SCREW	TATA spare parts
272535608016	SCREW	TATA spare parts
272535608017	SCREW	TATA spare parts
272535608018	CAP SCREW	TATA spare parts
272535608201	OIL SLINGER-HUB	TATA spare parts

272535608203	SHAFT PLATE (4472.335.681)	TATA spare parts
272535608204	OIL SLINGER - HUB	TATA spare parts
272535608208	SHAFT PLATE	TATA spare parts
272535608354	SHIM (0730.007.916)	TATA spare parts
272535608355	SHIM	TATA spare parts
272535608356	SHIM	TATA spare parts
272535608357	SHIM	TATA spare parts
272535608358	SHIM	TATA spare parts
272535608359	SHIM	TATA spare parts
272535608360	SHIM	TATA spare parts
272535608361	SHIM	TATA spare parts
272535608362	SHIM	TATA spare parts
272535608363	SHIM	TATA spare parts
272535608364	SHIM	TATA spare parts
272535608365	SHIM	TATA spare parts
272535608366	SHIM	TATA spare parts
272535608367	SHIM	TATA spare parts
272535608368	SHIM	TATA spare parts
272535608369	SHIM	TATA spare parts
272535608370	SHIM	TATA spare parts
272535608371	SHIM	TATA spare parts
272535608372	SHIM	TATA spare parts
272535608373	SHIM	TATA spare parts
272535608374	SHIM	TATA spare parts
272535608375	SHIM	TATA spare parts
272535608376	SHIM	TATA spare parts
272535608377	SHIM	TATA spare parts
272535608378	SHIM	TATA spare parts
272535608379	SHIM	TATA spare parts
272535608380	SHIM	TATA spare parts
272535608381	SHIM	TATA spare parts
272535608382	SHIM	TATA spare parts
272535608383	SHIM	TATA spare parts
272535608384	SHIM	TATA spare parts
272535608385	SHIM	TATA spare parts
272535608386	SHIM	TATA spare parts
272535608387	SHIM	TATA spare parts
272535608388	SHIM	TATA spare parts
272535608389	SHIM	TATA spare parts
272535608390	SHIM	TATA spare parts
272535608391	SHIM	TATA spare parts
272535608392	SHIM	TATA spare parts
272535608393	SHIM	TATA spare parts
272535608394	SHIM	TATA spare parts
272535608395	SHIM	TATA spare parts
272535608396	SHIM	TATA spare parts
272535608397	SHIM	TATA spare parts



272535608398	SHIM	TATA spare parts
272535608399	SHIM	TATA spare parts
272535608601	DISTANCE PIECE	TATA spare parts
272535608602	OIL SEAL RING-OUTER	TATA spare parts
272535608602AE	OIL SEAL RING-OUTER 2523	TATA spare parts
272535608604	WASHER (0750.101.164)	TATA spare parts
272535608702	CUP SPRING	TATA spare parts
272535608703	CUP SPRING	TATA spare parts
272535609906	REVOLUTION COUNTER	TATA spare parts
272535609907	REVOLUTION COUNTER	TATA spare parts
272535618301	SHIM	TATA spare parts
272535618302	SHIM	TATA spare parts
272535618303	SHIM	TATA spare parts
272535618304	SHIM	TATA spare parts
272535618305	SHIM	TATA spare parts
272535618306	SHIM	TATA spare parts
272535618307	SHIM	TATA spare parts
272535618308	SHIM	TATA spare parts
272535618309	SHIM	TATA spare parts
272535618310	SHIM	TATA spare parts
272535618311	SHIM	TATA spare parts
272535618312	SHIM	TATA spare parts
272535618313	SHIM	TATA spare parts
272535618314	SHIM	TATA spare parts
272535618315	SHIM	TATA spare parts
272535618316	SHIM	TATA spare parts
272535618317	SHIM	TATA spare parts
272535618318	SHIM	TATA spare parts
272535618319	SHIM	TATA spare parts
272535618320	SHIM	TATA spare parts
272535618321	SHIM	TATA spare parts
272535618322	SHIM	TATA spare parts
272535618323	SHIM	TATA spare parts
272535618324	SHIM	TATA spare parts
272535618325	SHIM	TATA spare parts
272535618326	SHIM	TATA spare parts
272535618327	SHIM	TATA spare parts
272535618328	SHIM	TATA spare parts
272535618329	SHIM	TATA spare parts
272535618330	SHIM	TATA spare parts
272535618331	SHIM	TATA spare parts
272535618332	SHIM	TATA spare parts
272535618333	SHIM	TATA spare parts
272535618334	SHIM	TATA spare parts
272535618335	SHIM	TATA spare parts
272535618336	SHIM	TATA spare parts
272535618337	SHIM	TATA spare parts

272535618338	SHIM	TATA spare parts
272535618339	SHIM	TATA spare parts
272535618340	SHIM	TATA spare parts
272535618341	SHIM	TATA spare parts
272535618342	SHIM	TATA spare parts
272535618343	SHIM	TATA spare parts
272535618344	SHIM	TATA spare parts
272535618345	SHIM	TATA spare parts
272535618346	SHIM	TATA spare parts
272535618347	SHIM	TATA spare parts
272535618348	SHIM	TATA spare parts
272535618349	SHIM	TATA spare parts
272535618350	SHIM	TATA spare parts
272535618351	SHIM	TATA spare parts
272535618352	SHIM	TATA spare parts
272535618353	SHIM	TATA spare parts
272535618354	SHIM	TATA spare parts
272535618355	SHIM	TATA spare parts
272535618356	SHIM	TATA spare parts
272535618357	SHIM	TATA spare parts
272535618358	SHIM	TATA spare parts
272535618359	SHIM	TATA spare parts
272535618360	SHIM	TATA spare parts
272535618361	SHIM	TATA spare parts
272535618362	SHIM	TATA spare parts
272535618363	SHIM	TATA spare parts
272535618364	SHIM	TATA spare parts
272535618365	SHIM	TATA spare parts
272535618366	SHIM	TATA spare parts
272535618367	SHIM	TATA spare parts
272535618368	SHIM	TATA spare parts
272535618369	SHIM	TATA spare parts
272535618370	SHIM	TATA spare parts
272535618371	SHIM	TATA spare parts
272535618372	SHIM	TATA spare parts
272535618373	SHIM	TATA spare parts
272535618374	SHIM	TATA spare parts
272535618375	SHIM	TATA spare parts
272535618376	SHIM	TATA spare parts
272535618377	SHIM	TATA spare parts
272535618378	SHIM	TATA spare parts
272535618379	SHIM	TATA spare parts
272535618380	SHIM	TATA spare parts
272535618381	SHIM	TATA spare parts
272535618382	SHIM	TATA spare parts
272535618383	SHIM	TATA spare parts
272535618384	SHIM	TATA spare parts

272535618385	SHIM	TATA spare parts
272535618386	SHIM	TATA spare parts
272535618387	SHIM	TATA spare parts
272535618388	SHIM	TATA spare parts
272535618389	SHIM	TATA spare parts
272535618390	SHIM	TATA spare parts
272535618391	SHIM	TATA spare parts
272535618392	SHIM	TATA spare parts
272535618393	SHIM	TATA spare parts
272535618394	SHIM	TATA spare parts
272535618395	SHIM	TATA spare parts
272535618396	SHIM	TATA spare parts
272535618397	SHIM	TATA spare parts
272535618398	SHIM	TATA spare parts
272535618399	SHIM	TATA spare parts
272535628301	SHIM	TATA spare parts
272535628302	SHIM	TATA spare parts
272535628303	SHIM	TATA spare parts
272535628304	SHIM	TATA spare parts
272535628305	SHIM	TATA spare parts
272535628306	SHIM	TATA spare parts
272535628307	SHIM	TATA spare parts
272535628308	SHIM	TATA spare parts
272535628309	SHIM	TATA spare parts
272535628310	SHIM	TATA spare parts
272535628311	SHIM	TATA spare parts
272535628312	SHIM	TATA spare parts
272535628313	SHIM	TATA spare parts
272535628314	SHIM	TATA spare parts
272535628315	SHIM	TATA spare parts
272535628316	SHIM	TATA spare parts
272535628317	SHIM	TATA spare parts
272535628318	SHIM	TATA spare parts
272535707901	AXLE SHAFT SHORT LPK2516 6X4	TATA spare parts
272535707902	AXLE SHAFT LONG LPK2516 6X4	TATA spare parts
272535707903	REAR AXLE SHAFT SHORT	TATA spare parts
272535707904	REAR AXLE SHAFT LONG	TATA spare parts
272535707905	AXLE SHAFT-LONG	TATA spare parts
272535707906	AXLE SHAFT-SHORT	TATA spare parts
272535707907	AXLE SHAFT LONG (4923)	TATA spare parts
272535707908	AXLE SHAFT SHORT (4923)	TATA spare parts
272535707913	AXLE SHAFT REAR (968 LENGTH) LPK-2518	TATA spare parts
272535707914	AXLE SHAFT,REAR (1098 LENGTH) LPK-2518	TATA spare parts
272535707915	AXLE SHAFT REAR (1013 LENGTH) LPS4923	TATA spare parts
272535707916	AXLE SHAFT REAR (1143 LENGTH) LPS-4923	TATA spare parts
272535707917	REAR AXLE SHAFT -SHORT (955 MM)	TATA spare parts
272535707918	REAR AXLE SHAFT-LONG (1060 MM)	TATA spare parts

272535707919	REAR AXLE SHAFT-SHORT (932 MM)	TATA spare parts
272535707920	REAR AXLE SHAFT-LONG (1102 MM)	TATA spare parts
272535707921	LONGER AXLE SHAFT 1102MM LH	TATA spare parts
272535707922	SHORTER AXLE SHAFT 932MM RH	TATA spare parts
272535707925	AXLE SHAFT	TATA spare parts
272535707928	REAR AXLE SHAFT	TATA spare parts
272535707929	REAR AXLE SHAFT	TATA spare parts
272535900101	SHIFT FORK & YOKE ASSY	TATA spare parts
272535900102	SHIFT FORK & YOKE ASSY	TATA spare parts
272535900104	FORK- SHIFT R1495 FWD	TATA spare parts
272535900105	INTER AXLE DIFF LOCK KIT SPARES	TATA spare parts
272535900106	SHIFT ASSY.AIR	TATA spare parts
272535900107	SHIFTER ASSY	TATA spare parts
272535903201	CAP SCREW	TATA spare parts
272535903202	BOLT SHIFT FORK	TATA spare parts
272535903204	BOLT-SOCKET HEAD	TATA spare parts
272535903205	BOLT HEX HEAD	TATA spare parts
272535903208	SCREW	TATA spare parts
272535906501	NUT-JAM	TATA spare parts
272535906502	NUT-SHIFT FORK BOLT	TATA spare parts
272535908701	SPRING	TATA spare parts
272535908702	SPRING	TATA spare parts
272535993601	FILTER	TATA spare parts
272535999901	BREATHER	TATA spare parts
272635000103	ASSY.RA-110 41/7 COMP WITH BRKS T150 SCD	TATA spare parts
272635000129	ASSY RA-110 41/8 W/BRKS SCD-1026 T-150	TATA spare parts
272635000138	REAR AXLE 110 1044 43/7 T-150W/BRKS 1905	TATA spare parts
272635000140	ASSY.REAR AXLE RA-110	TATA spare parts
272635000157	AXLE BEAM ASSY RA-110LD 41/6 T150 1044 S	TATA spare parts
272635000160	AXLE ASSY WITH BRAKE	TATA spare parts
272635000163	ASSY REAR AXLE RA-110	TATA spare parts
272635000166	REAR AXLE ASSY WITH BRAKE RWD ABS	TATA spare parts
272635000169	ASSY. RA-109RR COMP. 43-7 1055 T-150	TATA spare parts
272635000186	ASSY REAR AXLE RA-110 1044 43/7 T-150 AB	TATA spare parts
272635000192	ASSY REAR AXLE RA110 39/7 T-150 SCD1026	TATA spare parts
272635000197	ASSY RA-110 39/7 W/ABS BRKS SCD-1026 T-1	TATA spare parts
272635000204	AXLE ASSY WITH BRAKE	TATA spare parts
272635000210	AXLE ASSY WITH BRAKE	TATA spare parts
272635000229	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635000243	REAR AXLE ASSY WITH BRAKE	TATA spare parts
272635000249	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635000251	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635000253	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635000271	AXLE ASSY WITH HUB RWD BS6	TATA spare parts
272635000273	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635000288	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635000293	REAR AXLE ASSY WITH BRAKE	TATA spare parts

272635000295	AXLE ASSY WITH BRAKE	TATA spare parts
272635000296	REAR AXLE ASSY WITH BRAKE	TATA spare parts
272635000297	AXLE ASSY WITH BRAKE RWD	TATA spare parts
272635000298	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635000303	REAR AXLE ASSY WITH BRAKE	TATA spare parts
272635000309	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635000312	AXLE ASSY WITH BRAKE	TATA spare parts
272635000314	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635000315	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635000320	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635000322	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635000324	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635000329	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635000330	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635000333	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635000336	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635000338	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635000342	REAR AXLE ASSY WITH BRAKE WITH 150DIA FL	TATA spare parts
272635000347	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635000352	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635000363	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635000376	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635000381	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635000383	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635000387	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635000394	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635000397	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635010112	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635010114	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
272635010117	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635010119	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635010139	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635010142	REAR AXLE ASSY WITH LSD ABS BS6	TATA spare parts
272635010144	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
272635010155	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635010167	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272635010195	REAR AXLE ASSY WITH BRAKE WITH 150DIA FL	TATA spare parts
272635010315	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
272635100106	ASSY.REAR AXLE BEAM (MACHINED)	TATA spare parts
272635100107	ASSY.R.AXLE BEAM WITH PR.RING STUDS	TATA spare parts
272635100108	ASSY.R.AXLE BEAM WITH PR.RING STUDS	TATA spare parts
272635100110	ASSY.RA BEAM WITH PR.RING STUDS	TATA spare parts
272635100112	ASSY RA BEAM WITH PRESSURE RING & STUD	TATA spare parts
272635100113	ASSY RA BEAM M/CED 1055 LCRV BS6	TATA spare parts
272635100117	RA BEAM WITH PR. RING & STUD SCD1044	TATA spare parts
272635100119	ASSY RA. BEAM W/PR.RING & STUDS	TATA spare parts
272635100121	ASSY.R.AXLE BEAM WITH PR.RING STUDS.	TATA spare parts

272635100124	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
272635100127	REAR AXLE BEAM ASSY BS6	TATA spare parts
272635100128	REAR AXLE BEAM W/STUD/P RING/DOWEL BS3/4	TATA spare parts
272635100131	COVER ASSY REAR BS6	TATA spare parts
272635100141	REAR AXLE ASSY WITH PRESSURE RING & STUD	TATA spare parts
272635100142	REAR AXLE BEAM ASSY	TATA spare parts
272635100144	AXLE BEAM ASSY BS6	TATA spare parts
272635100147	REAR AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
272635100153	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
272635100157	REAR AXLE BEAM ASSY WITH STUD & DOWEL	TATA spare parts
272635100162	REAR AXLE BEAM ASSY BS6	TATA spare parts
272635100163	REAR AXLE ASSY WITH PRESSURE RING & STUD	TATA spare parts
272635100173	REAR AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
272635100174	AXLE BEAM ASSY BS6	TATA spare parts
272635100175	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
272635100181	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
272635100182	REAR AXLE BEAM ASSY BS6	TATA spare parts
272635100183	AXLE BEAM ASSY WITH STUD BS6	TATA spare parts
272635100184	REAR AXLE BEAM ASSY BS6	TATA spare parts
272635100185	REAR AXLE BEAM ASSY BS6	TATA spare parts
272635100190	REAR AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
272635100191	REAR AXLE BEAM ASSY WITH STUD & DOWEL BS	TATA spare parts
272635100198	REAR AXLE BEAM ASSY WITH STUD & DOWEL BS	TATA spare parts
272635100203	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
272635100204	REAR AXLE BEAM ASSY BS6	TATA spare parts
272635100216	REAR AXLE BEAM ASSY WITH STUD & DOWEL BS	TATA spare parts
272635100234	REAR AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
272635100244	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
272635110104	ASSY.CARRIER & PINION HSG COMPLETE,41/7	TATA spare parts
272635110105	ASSY. CARRIER HSG.W/ PLMR BLOCK BS3/4/6	TATA spare parts
272635110106	ASSY. CARRIER & PINION HSG. (41/6)BS3/4	TATA spare parts
272635110107	ASY.CARRIER & PIN.HSG COMP 45/7 SPI T150	TATA spare parts
272635110110	ASSY.CARRIER & PINION HSG COMP.41/8 T150	TATA spare parts
272635110111	ASSY.CARRIER&PINIONHSG 39/7 T150	TATA spare parts
272635110112	ASSY. DRIVE HEAD BS3/4	TATA spare parts
272635110116	CARRIER & PINION HOUSING ASSY	TATA spare parts
272635110118	ASSY. DRIVE HEAD BS3/4	TATA spare parts
272635110119	CARRIER & PINION HOUSING ASSY BS6	TATA spare parts
272635110120	DRIVE HEAD ASSY	TATA spare parts
272635110125	CARRIER HOUSING ASSY	TATA spare parts
272635110127	DRIVE HEAD ASSY	TATA spare parts
272635110128	DRIVE HEAD ASSY	TATA spare parts
272635110129	CARRIER HOUSING ASSY BS6	TATA spare parts
272635110132	DRIVE HEAD ASSY BS6	TATA spare parts
272635110134	DRIVE HEAD ASSY	TATA spare parts
272635110136	DRIVE HEAD ASSY BS6	TATA spare parts
272635110138	DRIVE HEAD ASSY BS6	TATA spare parts

272635110139	DRIVE HEAD ASSY	TATA spare parts
272635110140	DRIVE HEAD ASSY	TATA spare parts
272635110141	DRIVE HEAD ASSY BS6	TATA spare parts
272635110142	DRIVE HEAD ASSY	TATA spare parts
272635110145	DRIVE HEAD ASSY BS6	TATA spare parts
272635110146	DRIVE HEAD ASSY BS6	TATA spare parts
272635113704	PLUMMER BLOCK COVER BS6	TATA spare parts
272635300113	ASSY. DIFF. HOUSING (9X14 GEARS) BS3/4/6	TATA spare parts
272635300114	ASSY. CROWN & PINION (41/7) SPIRAC BS3/4	TATA spare parts
272635300119	ASSY. CROWN & PINION (41/6) BS3/4	TATA spare parts
272635300122	ASSY CROWN WHEEL-PINION 45/7-SPIRAC	TATA spare parts
272635300124	ASSY CROWN WHEEL-PINION 41/8 LH SPIRAC	TATA spare parts
272635300128	ASSY.CROWN WHEEL & PINION 39/7	TATA spare parts
272635300130	ASSY. CROWN & PINION (43/7) BS3/4	TATA spare parts
272635300138	CROWN WHEEL & PINION ASSY	TATA spare parts
272635300144	DIFFERENTIAL HOUSING ASSY	TATA spare parts
272635300148	DIFFERENTIAL ASSY	TATA spare parts
272635300166	ASSY. CROWN & PINION (43/7) BS3/4	TATA spare parts
272635300167	CROWN WHEEL & PINION ASSY	TATA spare parts
272635300174	CROWN WHEEL & PINION ASSY BS6	TATA spare parts
272635300177	CROWN WHEEL & PINION ASSY	TATA spare parts
272635300181	ASSY. CROWN & PINION BS6	TATA spare parts
272635303102	DIFFERENTIAL BRG FOR RA110	TATA spare parts
272635303103	TAPER ROLLER BRG.(100X155X36) BS3/4	TATA spare parts
272635303104	TAPER ROLLER BEARING BS6 PH2	TATA spare parts
272635303106	TAPER ROLLER BEARING BS6	TATA spare parts
272635303702	PINION HOUSING BS3/4/6	TATA spare parts
272635303703	OIL SEAL HOUSING	TATA spare parts
272635303704	PINION HOUSING BS3/4/6	TATA spare parts
272635305106	DIFFERENTIAL COVER (9X14 GEARS)	TATA spare parts
272635305108	DIFFERENTIAL SPIDER	TATA spare parts
272635305425	BEVEL PINION	TATA spare parts
272635305438	PINION 41/6 SPIRAC-KIMOS	TATA spare parts
272635306503	THREADED RING(M160X1.5) BS3/4/6	TATA spare parts
272635308003	ASSY.ADJUSTING PIN BS6	TATA spare parts
272635308306	SHIM (0.10 THK.)PINION DEPTH SETTING	TATA spare parts
272635308307	SHIM (0.15 THK.)PINION DEPTH SETTING	TATA spare parts
272635308308	SHIM (0.2 THK.)PINION DEPTH SETTING	TATA spare parts
272635308309	SHIM (0.25 THK.)PINION DEPTH SETTING	TATA spare parts
272635308312	SHIM (0.5 THK.)PINION DEPTH SETTING	TATA spare parts
272635308313	SHIM (1.0 THK.)PINION DEPTH SETTING	TATA spare parts
272635308314	SHIM (1.5 THK.)PINION DEPTH SETTING	TATA spare parts
272635308617	SPACER B/W PINION BEARING(18.475 THK.)FO	TATA spare parts
272635308618	SPACER B/W PINION BEARING(18.500 THK.)FO	TATA spare parts
272635308619	SPACER B/W PINION BEARING (18.575 THK.)F	TATA spare parts
272635308620	SPACER B/W PINION BEARING(18.550 THK.)FO	TATA spare parts
272635308621	SPACER B/W PINION BEARING(18.575 THK.)FO	TATA spare parts

272635308622	SPACER B/W PINION BEARING(18.600 THK.)FO	TATA spare parts
272635308623	SPACER B/W PINION BEARING(18.625 THK.)FO	TATA spare parts
272635308624	SPACER B/W PINION BEARING(18.650 THK.)FO	TATA spare parts
272635308625	SPACER B/W PINION BEARING(18.675 THK.)FO	TATA spare parts
272635308626	SPACER B/W PINION BEARING(18.700 THK.)FO	TATA spare parts
272635308627	SPACER B/W PINION BEARING(18.725 THK.)FO	TATA spare parts
272635308628	SPACER B/W PINION BEARING(18.750 THK.)FO	TATA spare parts
272635308629	SPACER B/W PINION BEARING(18.775 THK.)FO	TATA spare parts
272635308630	SPACER B/W PINION BEARING(18.800 THK.)FO	TATA spare parts
272635308631	SPACER B/W PINION BEARING(18.825 THK.)FO	TATA spare parts
272635308632	SPACER B/W PINION BEARING(18.850 THK.)FO	TATA spare parts
272635308633	SPACER B/W PINION BEARING(18.875 THK.)FO	TATA spare parts
272635308634	SPACER PINION BEARING	TATA spare parts
272635308635	SPACER PINION BEARING	TATA spare parts
272635308636	SPACER PINION BEARING	TATA spare parts
272635600104	REAR HUB ASSY WITH BRG & POLE WHEEL ABS	TATA spare parts
272635707902	REAR AXLE SHAFT BS3/4/6	TATA spare parts
272635707902DF	REAR AXLE SHAFT	TATA spare parts
272635707903	REAR AXLE SHAFT BS3/4	TATA spare parts
272635707903DF	REAR AXLE SHAFT	TATA spare parts
272635707907	REAR AXLE SHAFT BS6	TATA spare parts
272635707912	REAR AXLE SHAFT BS4/6	TATA spare parts
272635707916	REAR AXLE SHAFT BS6	TATA spare parts
272635707919	REAR AXLE SHAFT BS6	TATA spare parts
272635707920	REAR AXLE SHAFT BS6	TATA spare parts
272635707921	REAR AXLE SHAFT BS6	TATA spare parts
272635707922	REAR AXLE SHAFT	TATA spare parts
272635903701	SHIFT CYLINDER HOUSING BS6	TATA spare parts
272635907901	PISTON ROD BS6	TATA spare parts
2726H9W0135016	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2726H9W0135021	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2726H9W0135023	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2726H9W0135025	LIVE REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
2726H9W0135026	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2726H9W0135028	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2726H9W0135036	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2726H9W0135041	LIVE REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
272735000129	ASSY REAR AXLE WITH BRAKES 6.72 WTRK 190	TATA spare parts
272735000133	ASSY REAR AXLE W/BRKS 6.49,PNE SUSP 1860	TATA spare parts
272735000152	ASSY RA-210HR AXLE COMP W/BRKS 7.24 1860	TATA spare parts
272735000154	ASSY RA-210HR COMP W/6.72 (29/15) W/WABC	TATA spare parts
272735000163	RA-210HR COMP W/BRKS 6.138,1860,W/O ABS	TATA spare parts
272735000171	RA-210HR W/BRKS 6.49(28/15) 850/950FRAME	TATA spare parts
272735000184	ASSY REAR AXLE RA-210HR W/4.30 BRKS DIFF	TATA spare parts
272735000186	REAR AXLE	TATA spare parts
272735000188	ASSY RA-210HR W/4.64 BRKS T180 DIFF 1900	TATA spare parts
272735000204	AXLE ASSY WITH BRAKE	TATA spare parts



272735100128	ASSY REAR AXLE BEAM W/PR.RING/STUD/DOWEL	TATA spare parts
272735100129	ASSY REAR AXLE BEAM TML(M/CED) 1900 TRAC	TATA spare parts
272735100140	ASSY REAR AXLE BEAM W/PR.RING/STUD/DOWEL	TATA spare parts
272735100143	ASSY RWD AXLE BEAM W/PR.RING/STUDS/DOWEL	TATA spare parts
272735100148	ASSY REAR AXLE BEAM TML(M/CED) W/DIFF LO	TATA spare parts
272735104701	COVER PLATE (DIFF.LOCK CYLINDER)	TATA spare parts
272735107701	OIL SEAL (REAR AXLE SHAFT)	TATA spare parts
272735107704	OIL SEAL (REAR AXLE SHAFT)	TATA spare parts
272735107704AE	OIL SEAL (RR AX SFT)1628/ 1828/	TATA spare parts
272735107705	OIL SEAL DOUBLE LIP (AXLE SHAFT)	TATA spare parts
272735110104	ASSY.CARRIER HSG.WITH PLUMMER BLOCK	TATA spare parts
272735110104AE	ASSY.CARR HSG.W/ PLUMMER -1628	TATA spare parts
272735110117	ASY CARRIER & PINION HSG.COMP29/15-SPIRO	TATA spare parts
272735110127	ASSY CARI & PI HSG DIFF LOCK 30/19 SPIRO	TATA spare parts
272735110134	CARRIER & PINION HOUSING ASSY BS6	TATA spare parts
272735110147	ASSY CARRIER HOUSING AND PLUMMER BLOCK	TATA spare parts
272735113704	PLUMMER BLOCK COVER	TATA spare parts
272735118306	SHIM (0.1 THK)	TATA spare parts
272735118307	SHIM (0.15 THK)	TATA spare parts
272735118308	SHIM (0.4 THK)	TATA spare parts
272735118309	SHIM (1.0 THK)	TATA spare parts
272735118310	SHIM (2.0 THK)	TATA spare parts
272735300101	DIFF.HOUSING ASSY.	TATA spare parts
272735300103	CROWN WHEEL & PINION (28/15)	TATA spare parts
272735300115	DIFFERENTIAL HOUSING ASSY.(DIFF.LOCK)	TATA spare parts
272735300115AE	DIFF HSG. ASSY.(DIFF.LOCK) -1628	TATA spare parts
272735300117	ASSY.C.W.& PINION (28/15-SPIROFLEX)	TATA spare parts
272735300117AE	ASSY CWP (28/15) -1628	TATA spare parts
272735300120	DIFF HSG ASY R-TANDEM DIFF-LOCK MTG	TATA spare parts
272735300129	ASSY DIFF COMP 28/15(OER-SPIRO)DIFF-LOCK	TATA spare parts
272735300130	ASY CW & PINION 29/19 OERLIKON-SPIROFLEX	TATA spare parts
272735300133	ASSY.COUPLING FLANGE (SAE TYPE-SERRATED)	TATA spare parts
272735300133AE	ASSY.COUPLING FLANGE -1628-1828	TATA spare parts
272735300137	ASSY.COUPLING FLG 150 DIA(SAE-SERRATED)	TATA spare parts
272735300140	ASSY CROWN WHEEL PINION (29/15)SPIROFLEX	TATA spare parts
272735300143	ASSY CROWN WHEEL PINION (25/12)SPIROFLEX	TATA spare parts
272735300146	CROWN WHEEL PINION (28/19)SPIROFLEX	TATA spare parts
272735300156	ASSY CROWN WHEEL PINION (30/17)SPIROFLEX	TATA spare parts
272735300160	ASSY CROWN WHEEL AND PINION 30/19	TATA spare parts
272735300167	ASSY CROWN WHEEL & PINION 28/21 SPIRO	TATA spare parts
272735300177	ASSY CROWN WHEEL & PINION 28/15 SPIRO-KI	TATA spare parts
272735303102	TAPER ROLLER BRG 32315	TATA spare parts
272735303702	PINION HOUSING	TATA spare parts
272735303703	PINION HOUSING	TATA spare parts
272735305002	COUPLING FLANGE (SERRATED) - 180 DIA.	TATA spare parts
272735305003	COUPLING FLANGE (SERRATED) - 150 DIA.	TATA spare parts
272735305102	DIFFERENTIAL COVER	TATA spare parts

272735305102AE	DIFFERENTIAL COVER 1628	TATA spare parts
272735305103	INTERMEDIATE RING	TATA spare parts
272735305103AE	INTERMEDIATE RING 1628	TATA spare parts
272735305107	INTERMEDIATE RING	TATA spare parts
272735305403	REAR AXLE SHAFT GEAR	TATA spare parts
272735305403AE	REAR AXLE SHAFT GEAR 1628	TATA spare parts
272735305404	DIFFERENTIAL BEVEL PINION	TATA spare parts
272735305404AE	DIFFERENTIAL BEVEL PINION 1628	TATA spare parts
272735305425	REAR AXLE SHAFT GEAR	TATA spare parts
272735305425AE	RR AXLE SFT GEAR -1628	TATA spare parts
272735306101	LOCKING PLATE	TATA spare parts
272735306102	LOCKING PLATE	TATA spare parts
272735306501	THREADED RING (DIFFERENTIAL)	TATA spare parts
272735306503	HEX COLLER NUT (COUPLING FLANGE)	TATA spare parts
272735307701	OIL SEAL (TAIL PINION INNER SINGLE LIP)	TATA spare parts
272735307701AE	TAIL PINION INNER 1628/ 1828	TATA spare parts
272735307702	OIL SEAL (TAIL PINION -OUTER DOUBLE LIP)	TATA spare parts
272735307702AE	OIL SEAL (TAIL PNIN -OUTER)-1628	TATA spare parts
272735307709	OIL SEAL (85X105X10.7)	TATA spare parts
272735307710	OIL SEAL (85X105X8)	TATA spare parts
272735308001	HEX SCREW ( CROWN WHEEL)	TATA spare parts
272735308201	DUST COVER	TATA spare parts
272735308601	SPACER (2.00 THK)	TATA spare parts
272735308602	SPACER (2.05 THK)	TATA spare parts
272735308603	SPACER (2.10 THK)	TATA spare parts
272735308604	SPACER (2.15 THK)	TATA spare parts
272735308605	SPACER (2.30 THK)	TATA spare parts
272735308606	SPACER (2.35 THK)	TATA spare parts
272735308607	SPACER (2.40 THK)	TATA spare parts
272735308608	SPACER (2.45 THK)	TATA spare parts
272735308609	SPACER (2.50 THK)	TATA spare parts
272735308610	SPACER (2.55 THK)	TATA spare parts
272735308611	SPACER (3.0 THK)	TATA spare parts
272735308612	SPACER (3.10 THK)	TATA spare parts
272735308613	SPACER (3.30 THK)	TATA spare parts
272735308614	SPACER (3.40 THK)	TATA spare parts
272735309201	SIDE GEAR WASHER (5.1 THK)	TATA spare parts
272735309202	SIDE GEAR WASHER (5.2 THK)	TATA spare parts
272735309203	SIDE GEAR WASHER (5.3 THK)	TATA spare parts
272735309204	SIDE GEAR WASHER (5.4 THK)	TATA spare parts
272735309205	SIDE GEAR WASHER (5.5 THK)	TATA spare parts
272735600104	ASSY. BELL HOUSING COMPLETE BS3/4	TATA spare parts
272735600105	ASSY.PLANNET CARRIER & BELL HSG.	TATA spare parts
272735600106	ASSY COVER (BELL HOUSING)	TATA spare parts
272735600108	ASSY BELL HOUSING COMP	TATA spare parts
272735600109	ASSY.PLANNET CARRIER & BELL HSG.( M/C)	TATA spare parts
272735600111	ASSY BELL HOUSING COMP. FOR CTIS	TATA spare parts

272735600111AE	ASSY BELL HSG. COMP. CTIS -1628	TATA spare parts
272735600112	ASSY. PLANNET CARRIER & BELL HSG (M/C)FO	TATA spare parts
272735603101	TAPER ROLLER BRG 32222	TATA spare parts
272735603103	NEEDLE ROLLER BEARING	TATA spare parts
272735603104	TAPER ROLLER BRG (INNER & OUTER)	TATA spare parts
272735603701	BELL HOUSING	TATA spare parts
272735603702	HUB END COVER	TATA spare parts
272735603702AE	HUB END COVER 1628	TATA spare parts
272735604301	CIRCLIP IN RING GEAR	TATA spare parts
272735604302	CIRCLIP IN CTIS HUB ASSEMBLY	TATA spare parts
272735605401	SUN GEAR	TATA spare parts
272735605401AE	SUN GEAR 1628	TATA spare parts
272735605402	PLANET PINION	TATA spare parts
272735605403	RING GEAR	TATA spare parts
272735605403AE	RING GEAR 1628	TATA spare parts
272735605404	SUN GEAR (FOR HUB RATIO 3.226)	TATA spare parts
272735605405	PLANET PINION (FOR HUB RATIO 3.226)	TATA spare parts
272735605406	RING GEAR (FOR HUB RATIO 3.226)	TATA spare parts
272735605503	ADAPTOR-RING GEAR	TATA spare parts
272735605504	ADAPTOR RING GEAR FOR CTIS	TATA spare parts
272735605504AE	ADAPTOR RING GEAR FOR CTIS 1628	TATA spare parts
272735606301	GUIDE RING FOR CTIS SEALS	TATA spare parts
272735606301AE	GUIDE RING FOR CTIS SEALS 1628	TATA spare parts
272735606502	HUB LOCK NUT	TATA spare parts
272735606503	HUB LOCK NUT M80X1.5 M80X1.5	TATA spare parts
272735606701	PIN (PLANET PINION)	TATA spare parts
272735606702	THRUST PIN (BELL HSG. COVER)	TATA spare parts
272735606703	HUB MOUNTING PIN.	TATA spare parts
272735606704	HUB MOUNTING PIN FOR ARMY SINGLE TYRE	TATA spare parts
272735606704AE	HUB MNTNG PIN SINGLE TYRE -1628	TATA spare parts
272735608001	PIN-HUB LOCK NUT	TATA spare parts
272735608202	OIL CATCHER (RING GEAR END)	TATA spare parts
272735608202AE	OIL CATCHER (RING GEAR END)-1628	TATA spare parts
272735608301	SHIM-0.1 THK.	TATA spare parts
272735608302	SHIM-0.15 THK.	TATA spare parts
272735608303	SHIM-0.2 THK.	TATA spare parts
272735608304	SHIM-0.25 THK.	TATA spare parts
272735608305	SHIM-0.3 THK.	TATA spare parts
272735608306	SHIM-0.5 THK.	TATA spare parts
272735608307	SHIM-1.0 THK.	TATA spare parts
272735608308	SHIM-1.5 THK.	TATA spare parts
272735608601	SUN GEAR WASHER (OUTER)	TATA spare parts
272735608602	SUN GEAR WASHER (INNER)	TATA spare parts
272735608603	SPACER (BET NEEDLE ROLLER BRG)	TATA spare parts
272735608604	PLANET WASHER (FOR LUBRICATION)	TATA spare parts
272735608606	ADAPTOR SPACER	TATA spare parts
272735608608	TONGUE WASHER (HUB OUTER BRG.)	TATA spare parts

272735608609	SPACER TUBE (BET.HUB INNER & OUTER BRG.)	TATA spare parts
272735608610	PLANET WASHER FOR LUBRICATION	TATA spare parts
272735608611	SUN GEAR WASHER (INNER)	TATA spare parts
272933050102	ASSY.FRONT LIVE AXLE COMPLETE SD 1015TC	TATA spare parts
272933050103	ASSY.FRONT LIVE AXLE COMP.WITH BRK.-LHD	TATA spare parts
272933050104	ASSY FRONT AXLE HSG WITH SUPPORT TUBE	TATA spare parts
272933050109	ASSY. FRONT AXLE COMP SA1212 4 X4	TATA spare parts
272933050111	ASSY. HUB-COMPLETE	TATA spare parts
272933050112	ASSY HUB FRONT(WITHOUT BEARING)	TATA spare parts
272933050119	ASSY.FRONT AXLE HSG.WITH SUPPORT TUBES	TATA spare parts
272933050122	ASSY. FRONT AXLE(FA-104)COMPLETE W/BRAKE	TATA spare parts
272933050124	ASSY FA-104 LIVE WITH BRK RHD(41/7)S-CAM	TATA spare parts
272933050127	ASSY FA-104 COMP WITH BRK LHD(41/7)S-CAM	TATA spare parts
272933050128	ASSY FRONT AXLE COMP WITH BRK LHD(41/7)	TATA spare parts
272933050129	ASSY FA-104 41/6 COMP W/BRKS S-CAM RHD	TATA spare parts
272933050131	AASY FA-104 41/7 COMP WITH S-CAM BRKS LH	TATA spare parts
272933050134	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
272933050136	FRONT AXLE ASSY WITH BRAKE & SADDLE	TATA spare parts
272933050143	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272933050147	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
272933159901	ADAPTOR FOR GREASE NIPPLE	TATA spare parts
272933257901	SUPPORTING SLEEVE	TATA spare parts
272933257902	SUPPORTING SLEEVE	TATA spare parts
272933300103	ASSY CROWN WHEEL/PINION 41/6	TATA spare parts
272933455101	HUB (SPIGOTTED) FRONT AXLE BS6	TATA spare parts
272933750102	ASSY. DRIVE SHAFT LEFT COMPLETE	TATA spare parts
272933750104	ASSY. DRIVE SHAFT RIGHT COMPLETE	TATA spare parts
272933753701	HOUSING FRONT AXLE JOINT CROSS RH	TATA spare parts
272933753702	HOUSING FRONT AXLE JOINT CROSS LH	TATA spare parts
272933800101	ASSY.TIE ROD	TATA spare parts
272933856101	LOCKING PLATE	TATA spare parts
273035000102	ASSY.REAR AXLE COMP.WITH BRK.41/7	TATA spare parts
273035000107	ASSY REAR AXLE COMP W/S-CAM BRKS 41/11	TATA spare parts
273035000112	ASSY R.A.COMP W/DAOH BRK DIRECT BRE 41/7	TATA spare parts
273035000113	ASSY R.A. COMP W/DAOH BRK DIRECT BRE	TATA spare parts
273035000116	ASSY.RA COMP.W/LCRV AFBRKS.	TATA spare parts
273035000118	ASSY R A COMP 37/7 S-CAM 6 BOLT FLANGE	TATA spare parts
273035000120	ASSY.RA-104 R.AXLE W/DIFF LOCK SPIG HUB	TATA spare parts
273035000122	ASSY.R.AXLE COMP.W/BRKS S-CAM (49/11)	TATA spare parts
273035000126	RA-1009 COMP.37/7 W/LCRV 6 BOLT C.FLANG	TATA spare parts
273035000136	¿ASSY.RA-1109RR COMP.49/11 WABCO-ABS	TATA spare parts
273035000139	ASSY REAR AXLE COMP. WITH DIFFERENTIAL L	TATA spare parts
273035000139AE	ASSY REAR AXLE COMPLETE-1415-715	TATA spare parts
273035000141	ASSY REAR AXLE RA-106 II WITH DIFF LOCK	TATA spare parts
273035000150	RA-1109 COMP 37/7 130 ASA	TATA spare parts
273035000156	ASSY. RA-106 II WITH D/LO 41/6 S-CAM BRK	TATA spare parts
273035000164	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts

273035000166	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273035000169	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273035000171	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273035000177	AXLE ASSY WITH BRAKE	TATA spare parts
273035000178	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273035000193	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
273035000195	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
273035000206	REAR AXLE ASSY WITH HUB BS6-PH2	TATA spare parts
273035100105	REAR AXLE BEAM LPT1109TC	TATA spare parts
273035100108	ASSY R.A BEAM WITH PR.RING STUD & DOWLES	TATA spare parts
273035100113	ASSY.R.A.BEAM WITH PR.RING STUD & DOWELS	TATA spare parts
273035100116	ASSY.RA BEAM MACHINED	TATA spare parts
273035100123	ASSY R.A. BEAM W/PR.RING DOWELS STUDS	TATA spare parts
273035100124	ASSY. R.A. BEAM W/PR.RING DOWELS STUDS	TATA spare parts
273035100125	ASSY R/A BEAM WITH PR.RINGS STUDS ETC	TATA spare parts
273035100144	ASSY.RA BEAM W/PR.RING STUD & DOWEL	TATA spare parts
273035100150	REAR AXLE BEAM ASSY WITH PRESSURE RING	TATA spare parts
273035100152	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
273035100153	AXLE BEAM ASSY WITH SPINDLE BS6	TATA spare parts
273035100157	REAR AXLE BEAM ASSY M/CED 135X150 1004 B	TATA spare parts
273035100169	REAR AXLE BEAM ASSY WITH STUD & DOWEL BS	TATA spare parts
273035100171	AXLE BEAM ASSY WITH RING & STUD BS6-PH2	TATA spare parts
273035108601	PRESSURE RING	TATA spare parts
273035110101	ASSY CARRIER HOUSING.	TATA spare parts
273035110141	CARRIER ASSY BS6	TATA spare parts
273035110147	DRIVE HEAD ASSY BS6	TATA spare parts
273035113702	PLUMMER BLOCK COVER (L.H) BS6	TATA spare parts
273035113703	PLUMMER BLOCK COVER (R.H) BS6	TATA spare parts
273035115301	GASKET (CARRIER TO BEAM)	TATA spare parts
273035300104	DIFFERENTIAL HOUSING ASSEMBLY.	TATA spare parts
273035300108	ASSLY ADJUSTING PIN	TATA spare parts
273035300124	ASSY CW & PINION 41/11 OER-SPIRAC.	TATA spare parts
273035300126	ASSY.CROWN WHEEL & PINION (49/11-ORLKN)	TATA spare parts
273035300130	ASSY.COUPLING FLANGE (6 BOLT 120 OD)	TATA spare parts
273035300138	ASSY CROWN WHEEL & PI 49/11	TATA spare parts
273035300163	ASSY COUPLING FLANGE T-120	TATA spare parts
273035300180	DIFFERENTIAL ASSY BS6-PH2	TATA spare parts
273035303101	TAPER ROLLER BRG 32212	TATA spare parts
273035303102	TAPER ROLLER BRG.(60X110X29.75) BS6	TATA spare parts
273035303103	TAPERED ROLLER BEARING (65X120X32.75) BS	TATA spare parts
273035305002	COUPLING FLANGE T-120	TATA spare parts
273035305101	DIFFERENTIAL CASE (FOR FAST RATIO)	TATA spare parts
273035305418	DIFF. BEVEL PINION-FORGED BS1/2/3/4/6	TATA spare parts
273035305418AE	DIFF.BEVEL PINION-FORGED 715	TATA spare parts
273035305419	AXLE SHAFT GEAR-FORGED	TATA spare parts
273035305419AE	REAR AXLE SHAFT GEAR 715	TATA spare parts
273035307701	OIL SEAL (TAIL PINION) LPT 909	TATA spare parts

273035600105	ASSY.REAR HUB COMP.(ABS)	TATA spare parts
273035600112	REAR HUB ASSY ABS	TATA spare parts
273035603102	TAPERED ROLLER BEARING(80X140X35.25)	TATA spare parts
273035604701	COVER REAR HUB	TATA spare parts
273035605301	GASKET REAR HUB	TATA spare parts
273035605503	HUB REAR (TWIN TYRE SPIGOTTED)	TATA spare parts
273035605506	HUB REAR (ABS)	TATA spare parts
273035605509	HUB REAR	TATA spare parts
273035605511	REAR HUB ABS	TATA spare parts
273035605513	REAR HUB BS6-PH2	TATA spare parts
273035606501	NUT (HUB LOCKING)	TATA spare parts
273035606502	LOCKING RING	TATA spare parts
273035607701	OIL SEAL-HUB OUTER BS4	TATA spare parts
273035607702	OIL SEAL (110X140X13)	TATA spare parts
273035608201	OIL CATCHER (ABS)	TATA spare parts
273035608202	OIL CATCHER	TATA spare parts
273035608601	SPACER TUBE (BETN.HUB BRGS.)	TATA spare parts
273035608602	SPACER (OIL SEAL MTG)	TATA spare parts
273035608603	TONGUE SPACER (WITH HOLES)	TATA spare parts
273035608604	TONGUE SPACER	TATA spare parts
273035608605	SPACER TUBE	TATA spare parts
273035707901	REAR AXLE SHAFT 1109 BS2/3/4	TATA spare parts
273035707907	REAR AXLE SHAFT BS6-PH2	TATA spare parts
2730H9W0135002	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2730H9W0135008	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
273135603103	DOUBLE ROW ANG CONTACT BRG	TATA spare parts
273232107159DF	FOURTH LEAF FRONT-LPT2515EX	TATA spare parts
273232107160DF	FIFTH LEAF FRONT-LPT2515EX	TATA spare parts
273235000101	ASSY.REAR AXLE COMPLT (41	TATA spare parts
273235000111	REAR AXLE ASSY	TATA spare parts
273235000153	ASSY.R.A.COMP.W/41/7 LARGER HUB BRG	TATA spare parts
273235000158	ASSY REAR AXLE COMPLETE 41/6	TATA spare parts
273235000160	ASSY REAR AXLE COMPLETE	TATA spare parts
273235000162	ASSY REAR AXLE COMPLETE LPT/LPK 1615TC	TATA spare parts
273235000177	RA-109RR 43/7 1055 130 AF-235 VOSS BRKS	TATA spare parts
273235000196	RA.109RR COMP W/CAST `Z` BRKT 41/6 1055	TATA spare parts
273235000213	RA-109RR COMP W/CAST Z BRKT 41/7 1055	TATA spare parts
273235000215	ASSY.RA COMP.41/7 1044 SCD 150 OD FLANGE	TATA spare parts
273235000221	ASSY RA-109RR REAR AXLE COMP 41/6 165 O.	TATA spare parts
273235000225	ASSY.RA COMP.41/7 1055 SCD 150 OD FLANG	TATA spare parts
273235000227	ASSY.RA COMP.41/6,1055 SCD 150 OD FLANG	TATA spare parts
273235000229	ASSY.RA COMP.41/6 1044 SCD 150 OD FLANG	TATA spare parts
273235000231	ASSY.REAR AXLE COMPLETE 41/7 1044 SC 150	TATA spare parts
273235000233	ASSY RA-109RR COMP 41/7 PNEU.SUSP RE BUS	TATA spare parts
273235000235	ASSY.R.A.COMP.W/PNEU.SUSP 41/7 150 FLNG	TATA spare parts
273235000240	ASSY.RA-109RR 41/7 RAF-7 BRK RE BUS	TATA spare parts
273235000241	ASSY.RA-109RR COMP,41/6,1044,150,AF-235	TATA spare parts

273235000243	ASSY.RA-109RR COMP.(41/7 HIGH DECK BUS)	TATA spare parts
273235000245	RA-109RR COMP.41/7 1055 130 AF-235 MANU	TATA spare parts
273235000254	RA-109RR COMP.41/7 1055 130 AF-235 BRKS	TATA spare parts
273235000257	REAR AXLE RA 109 RR (41/7) 1044 MM VASS	TATA spare parts
273235000258	ASSY. REAR AXLE RA-109RR COMPLETE(41/7)-	TATA spare parts
273235000262	ASSY.RA-109RR COMP.41/7 1055 130 AF-235	TATA spare parts
273235000264	ASSY.RA-109RR COMP.41/6 1044 150-SER.FL	TATA spare parts
273235000268	REAR AXLE RA-109RR COMP 41/7 ABS	TATA spare parts
273235000270	RA-109RR COMP.41/6 1055 130 MANUAL-VOSS	TATA spare parts
273235000271	ASSY REAR AXLE RA-109RR COMPLETE (43/7)	TATA spare parts
273235000273	RA-109RR COMP:41/6 1055 130	TATA spare parts
273235000280	ASSY REAR AXLE RA-109RR COMP. 41/6 1044	TATA spare parts
273235000285	RA-109RR 41/6 1055 150 SER MSA-VOSS	TATA spare parts
273235000287	RA-109RR COMP.41/6 165 RE PNUE ABS	TATA spare parts
273235000289	RA-109RR 41/7 1055 150 ASA-VOSS	TATA spare parts
273235000292	ASSY REAR AXLE COMPLETE RA-109RR COMP 4	TATA spare parts
273235000294	ASSY REAR AXLE RA-109RR COMPLETE(41/6 10	TATA spare parts
273235000295	RA-3516 COMP 41/6 1044 150 ABS	TATA spare parts
273235000298	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235000314	RA-109RR COMP.41/6 1055 150 ASA-VOSS	TATA spare parts
273235000321	ASSY REAR AXLE COMPLETE RA-109RR COMPLET	TATA spare parts
273235000324	RA-109RR COMP 41/7 1055 150 SER ASA-VOS	TATA spare parts
273235000333	ASSY REAR AXLE(RA-109RR41/7VOSSABS)	TATA spare parts
273235000335	RA-109RR COMP 41/8 1055 150 SER ASA	TATA spare parts
273235000338	RA-109RR COMP.41/6 1044 150SER RAF-7	TATA spare parts
273235000352	ASSY RA-109RR COMP W/BRKS 41/6 W/D.LOCKN	TATA spare parts
273235000356	RA-109RR 41/7 1000 150 SER PNE SU NGT BR	TATA spare parts
273235000358	RA-109RR 43/7 1055 150-SER ASA-VOSS RAF7	TATA spare parts
273235000364	ASSY REAR AXLE COMP.RA-109RX 41/6 1055 1	TATA spare parts
273235000368	RA-109RR 41/6 1000 150 SER PNE SU NGT	TATA spare parts
273235000372	RA-109RR 41/6 150 SER AIR SUSPN NGT BRK.	TATA spare parts
273235000374	RA-109RX COMP 41/7 1044 150 SER ASA VOSS	TATA spare parts
273235000376	RA-109RX 41/7 1044 T-150 1860 ABS NGT.	TATA spare parts
273235000378	ASSY.REAR AXLE RA-109RX 41/7 W/O ABS	TATA spare parts
273235000384	ASSY REAR AXLE RA-109RR COMPLETE(45/7 10	TATA spare parts
273235000386	ASSY REAR AXLE RA-109RR 41/6 PNE SUS NGT	TATA spare parts
273235000390	REAR AXLE RA-109RX 41/7 1055 150 SERTD	TATA spare parts
273235000396	RA109RR 43/7 1055 T150 ASA VOSS RAF7	TATA spare parts
273235000397	RA-109RR 43/7 1055 T-150 HUB BRG ABS	TATA spare parts
273235000399	RA-109RR 41/7 1055 T-150 MASU BRAKES	TATA spare parts
273235010102	ASSY REAR AXLE RA-109RR COMP.W/NGT BRKS	TATA spare parts
273235010112	RA-109RR 41/6 T-150 AIR SUSPEN NGT ABS	TATA spare parts
273235010126	ASSY RA-109RR 41/7 940 T-150 JBM NGT	TATA spare parts
273235010131	RA-109RR 41/6 1000 130 PNEU SUSP	TATA spare parts
273235010141	"RA109RR,41/6,1044,T-150,ABS,THU1"	TATA spare parts
273235010144	RA-109RR COMP 41-7 1055 130 CF	TATA spare parts
273235010146	RA-109RR COMP W/O ABS 41/7 1055 130 CF	TATA spare parts

273235010151	ASSY REAR AXLE COMP.RA-109RR 41/7 W/NGT	TATA spare parts
273235010159	RA-109RR 41/7 1000 T-150 PNE SUS NGT	TATA spare parts
273235010165	RA-109RR COMP.41/7 1055 T-150 0 DEG	TATA spare parts
273235010184	REAR AXLE ASSY COMP 40/9 T-150 WABCO	TATA spare parts
273235010186	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010207	REAR AXLE ASSY COMPLETE 43.7 T-150	TATA spare parts
273235010208	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010210	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010213	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010216	REAR AXLE ASSY WITH BRAKE	TATA spare parts
273235010217	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010220	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010222	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
273235010225	AXLE ASSY WITH BRAKE	TATA spare parts
273235010228	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010229	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010231	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010233	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010235	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010242	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010244	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
27323501024490	LPK 1212 RA W/O BRAKE CHAMBER	TATA spare parts
273235010246	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010248	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010251	REAR AXLE ASSY WITH BRAKE	TATA spare parts
273235010255	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010259	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
273235010264	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
273235010280	REAR AXLE ASSY WITH BRAKE	TATA spare parts
273235010296	REAR AXLE ASSY WITH BRAKE	TATA spare parts
273235010297	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010302	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010305	REAR AXLE ASSY WITH BRAKE	TATA spare parts
273235010326	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010328	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010333	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010347	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010356	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010361	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
273235010366	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010377	REAR AXLE ASSY BS6	TATA spare parts
273235010381	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
273235010383	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
273235010385	REAR AXLE ASSY WITH BRAKE	TATA spare parts
273235010387	REAR AXLE ASSY WITH BRAKE	TATA spare parts
273235010389	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
273235010390	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts



273235010391	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235010393	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235020101	REAR AXLE ASSY WITH BRAKE	TATA spare parts
273235020102	REAR AXLE ASSY WITH BRAKE	TATA spare parts
273235020112	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
273235020134	REAR AXLE ASSY WITH BRAKE & HUB BS6	TATA spare parts
273235020136	REAR AXLE ASSY WITH BRAKE	TATA spare parts
273235020144	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
273235020206	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235020210	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
273235020223	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
273235020238	REAR AXLE ASSY WITH BRAKE	TATA spare parts
273235020248	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
273235020263	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
273235020271	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
27323502027190	REAR AXLE ASSY W/O BRAKE CHAMBER BS6	TATA spare parts
273235100105	ASSY.R.A.BEAM WITH PR.RINGS STUD & DOWEL	TATA spare parts
273235100126	ASSY RA BEAM WITH PRRING STUD & DOWEL	TATA spare parts
273235100127	REAR AXLE BEAM ASSY BS6	TATA spare parts
273235100136	ASSY REAR AXLE BEAM 2515TC/3015TC/SK1613	TATA spare parts
273235100137	ASSY.R.A.BEAM WITH PRE RING STUD & DOWEL	TATA spare parts
273235100160	ASSY RA W/PRE.RING+STUD+DOWEL CAST Z BRK	TATA spare parts
273235100161	ASSY RA BEAM	TATA spare parts
273235100165	ASSY. RA BEAM W/RING STUD/DOWEL BS1/2/3	TATA spare parts
273235100175	ASSY RA W/PRE.RING/STUD/DOWEL CAST Z BRK	TATA spare parts
273235100176	ASSY.R.A.BEAM-1044 CAST-Z BKT	TATA spare parts
273235100178	ASSY RA BEAM (MC/ED)H.D.BUS	TATA spare parts
273235100183	ASSY.RA BEAM W/PR.RING/STUD & DOWEL-1055	TATA spare parts
273235100185	ASSY RA W/PRE.RING/STUD/DOWEL(ABS)-1055	TATA spare parts
273235100193	ASSY. RA BEAM W/PR.RING/STUD/DOWEL BS2/3	TATA spare parts
273235100196	ASSY. REAR AXLE BEAM WITH RINGS & STUDS	TATA spare parts
273235100198	ASSY. RA BEAM W/RING/STUD DOWEL BS1- 4	TATA spare parts
273235100202	REAR AXLE BEAM ASSY ABS	TATA spare parts
273235100209	REAR AXLE BEAM W/STUD/P RING/DOWEL BS3/4	TATA spare parts
273235100212	ASSY R AXLE W/PR.RING STUD DOWEL	TATA spare parts
273235100227	ASY.RA BEAM (M/C-TML)1055 0 DEG.ABS F/W	TATA spare parts
273235100230	ASSY RA BEAM W/PRE.RING/STUD & DOWEL	TATA spare parts
273235100231	ASSY RA BEAM (M/CED)RE BUS AIR SUSPN.	TATA spare parts
273235100232	ASSY. RA BEAM W/PR.RING STUD BS1/2/3/4	TATA spare parts
273235100233	ASSY.RA BEAM W/PR.RING STUD	TATA spare parts
273235100239	ASSY. REAR AXLE BEAM W.PR.RING.STUD & DO	TATA spare parts
273235100240	REAR AXLE BEAM ASSY(M/CED)1044	TATA spare parts
273235100241	ASSY.RA BEAM W/PR.RING STUD & DOWEL	TATA spare parts
273235100249	ASSY.RA BEAM WITH STUD & DOWEL	TATA spare parts
273235100254	ASY RA.BEAM W/P.RING STUD & DOWEL PNEU S	TATA spare parts
273235100256	ASSY RA BEAM WITH STUD PRESS RING	TATA spare parts
273235100257	ASSY RA BEAM M/CED 1055	TATA spare parts

273235100272	REAR AXLE BEAM WITH P/RING STUD DOWEL	TATA spare parts
273235100276	ASSY.REAR COVER	TATA spare parts
273235100283	REAR AXLE BEAM W/STUDS & PR. RING BS1- 4	TATA spare parts
273235100288	ASSY BEAM WITH P/RING STUDS & DOWEL	TATA spare parts
273235100307	ASSY. RR AXL BEAM W/PR RING & STUD BS3/4	TATA spare parts
273235100309	REAR AXLE BEAM W/PRESS RING STUD & DOWEL	TATA spare parts
273235100315	REAR AXLE ASSY WITH PRESSURE RING & STUD	TATA spare parts
273235100320	REAR AXLE ASSY WITH PRESSURE RING & STUD	TATA spare parts
273235100341	REAR AXLE ASSY WITH PR RING STUD & DOWEL	TATA spare parts
273235100347	REAR AXLE BEAM ASSY	TATA spare parts
273235100358	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
273235100368	REAR AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
273235100369	AXLE BEAM	TATA spare parts
273235100377	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
273235100384	REAR AXLE ASSY WITH PRESSURE RING & STUD	TATA spare parts
273235100391	REAR AXLE BEAM ASSY	TATA spare parts
273235100394	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
273235100396	REAR AXLE BEAM ASSY BS6	TATA spare parts
273235100397	REAR AXLE BEAM ASSY BS6	TATA spare parts
273235100398	REAR AXLE BEAM ASSY	TATA spare parts
273235105113	SPRING SADDLE BOTTOM	TATA spare parts
273235105118	SPRING SADDLE (BOTTOM) L.H. 9 DEG.	TATA spare parts
273235105119	SPRING SADDLE (BOTTOM) R.H. 9 DEG.	TATA spare parts
273235107103	BASE PLATE	TATA spare parts
273235108201	OIL SLINGER (HOT FORM BEAM)	TATA spare parts
273235110101	ASSY CARRIER HOUSING LPT2515TC-RA109R	TATA spare parts
273235110102	ASSLY. CARRIER (41/6) RATIO COMPLETE W/C	TATA spare parts
273235110107	ASSY. CARRIER HSG (RA 109RR) BS1/2/3/4	TATA spare parts
273235110110	ASSY CARRIER RA 109 RR	TATA spare parts
273235110111	ASSY.CARRIER-41/7-ORLKN	TATA spare parts
273235110114	ASSY CARRIER 130 (41/7) OER-SPIRAC.	TATA spare parts
273235110125	ASSY. CARRIER (41/6) OERLIKON-SPIRAC.	TATA spare parts
273235110137	ASSY CARRIER(41/6) OER-SPIRAC(150 OD CF)	TATA spare parts
273235110138	ASSY CARRIER 41/6 OERLIKON 150 OD CF	TATA spare parts
273235110140	"ASY CARRIER,41/6,SPIRAC,130 CF"	TATA spare parts
273235110142	ASSY.CARRIER(41/7-ORLKN)150 OD C.FLANGE	TATA spare parts
273235110147	ASSY CARRI 41/7 OERLIKON W/165 OD C.FLNG	TATA spare parts
273235110148	ASSY CARRI 41/7 OER-SPIRAC 165 OD C.FLNG	TATA spare parts
273235110150	ASSY.CARRIER (41/6-SPIRAC) 165 OD.C.FLNG	TATA spare parts
273235110153	ASSY CARRIER (41/7-SPIRAC) T-150	TATA spare parts
273235110157	ASSY.CARRIER (43/7-SPIRAC) 150 FLANGE	TATA spare parts
273235110159	ASSY.CARRIER (41/6-SPIRAC)150 SERRATED	TATA spare parts
273235110160	ASSY.CARRIER (43/7-SPIRAC)150 SERRATED	TATA spare parts
273235110162	ASSY.CARRIER (41/8-SPIRAC)150 SER	TATA spare parts
273235110171	ASSY CARRIER 41/6 180SRE SPIRAC.	TATA spare parts
273235110173	ASSY CARRIER (45/7) OER-SPIRAC 150 SERRA	TATA spare parts
273235110174	ASSY CARRIER (39/7) OER-SPIRAC T150 COUP	TATA spare parts

273235110178	ASSY. CARRIER COMP 40/9 T 150 BS4	TATA spare parts
273235110179	CARRIER ASSY BS6	TATA spare parts
273235110182	CARRIER HOUSING ASSY BS6-PH2	TATA spare parts
273235110185	CARRIER HOUSING ASSY BS6	TATA spare parts
273235110192	CARRIER HOUSING ASSY BS6-PH2	TATA spare parts
273235110194	CARRIER ASSY BS6	TATA spare parts
273235110197	CARRIER ASSY BS6	TATA spare parts
273235110198	DRIVE HEAD ASSY BS6-PH2	TATA spare parts
273235113201	HEX.BOLT-PLUMMER BLOCK COVER	TATA spare parts
273235113704	PLUMMER BLOCK COVER	TATA spare parts
273235115301	GASKET (CARRIER)	TATA spare parts
273235130113	REAR AXLE BEAM ASSY BS6	TATA spare parts
273235130114	REAR AXLE BEAM ASSY	TATA spare parts
273235130120	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
273235130204	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
273235130206	REAR AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
273235130208	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
273235130218	REAR AXLE BEAM ASSY WITH STUD & DOWEL BS	TATA spare parts
273235300101	ASSY DIFFERENTIAL HOUSING 2515/3015/1615	TATA spare parts
273235300102	ASSLY. CROWN WHEEL & PINION (41/6) OERL.	TATA spare parts
273235300106	CWP SET 41/7 2515/3015	TATA spare parts
273235300117	ASSY.ADJUSTING PIN	TATA spare parts
273235300124	ASSY DIFFRENTIAL-41/6-ORLKN	TATA spare parts
273235300130	ASSY. CROWN WHEEL PINION 41/6 BS1/2/3/4	TATA spare parts
273235300131	ASSY. CROWN & PINION (41/7) BS1/2/3/4	TATA spare parts
273235300138	DIFFERENTIAL HOUSING ASSY	TATA spare parts
273235300139	DIFF.HOUSING ASSY.SLOW RATIO-CAST	TATA spare parts
273235300145	DIFF.HOUSING ASSY.(DIFF.LOCK)	TATA spare parts
273235300149	ASSY DIFFERENTIAL-41/6-OER-SPIRAC	TATA spare parts
273235300162	ASY CW/PI 41/6 OER-SPIRAC(PINION-EN-353)	TATA spare parts
273235300166	CWP 41/6 SPIROFELX DIA 440	TATA spare parts
273235300168	ASSY. COUPLING FLANGE-165 OD	TATA spare parts
273235300175	ASSY DIFF GEAR KIT W/SPIDER (CONI) RA109	TATA spare parts
273235300176	ASSY DIFF GEAR KIT W/SPIDER (CONI) RA109	TATA spare parts
273235300179	CWP SET 41/6 (440MM) HD RA109RR OERL	TATA spare parts
273235300180	ASY COUPLING FLNG W/PRESS DUST C 150 OD	TATA spare parts
273235300183	ASSY. DIFF. HSG (9X14 GEARS) BS1/2/3/4	TATA spare parts
273235300184	ASSY. DIFFERENTIAL-9X14 DIFF GEARS	TATA spare parts
273235300187	ASSY COUPLING FLNG. PRESS TYPE DUST COV	TATA spare parts
273235300188	ASSY SPACER WITH OIL SLINGER (PRESS TYPE	TATA spare parts
273235300189	ASSY CW & PINION 41/6 OERLIKON-SPIRAC	TATA spare parts
273235300191	THREADED RING ASSY BS6	TATA spare parts
273235300193	ASSY.DIFFERENTIAL GEARS BS6	TATA spare parts
273235300203	ASSY. CROWN & PINION (43/7) BS1/2/3/4	TATA spare parts
273235300211	DIFF HOUSING ASSY(FAST-9X14 GEARS)	TATA spare parts
273235300214	ASSY. COUP. FLANGE-150 DIA. SERR. BS1- 4	TATA spare parts
273235300215	KIT-DIFFERENTIAL GEAR BS1/2/3/4	TATA spare parts

273235300215DF	DIFFERENTIAL GEAR KIT WORM FORGED-RA109	TATA spare parts
273235300216	RA 109 RR DIFFERENTIAL REP KIT	TATA spare parts
273235300227	ASSY .CROWN WHEEL & PINION (41/8)	TATA spare parts
273235300233	ASSY. CROWN & PINION (45/7)OER BS3/4	TATA spare parts
273235300246	ASSY.COUPLING FLANGE-180 OD SERRATED	TATA spare parts
273235300249	ASSY. CROWN & PINION(39/7)LH OER BS3/4	TATA spare parts
273235300253	ASSY BRG (TAIL PINION) BS6	TATA spare parts
273235300254	ASSY. MATCHED BRG (TAIL PINION) BS1/3/4	TATA spare parts
273235300263	CROWN WHEEL & PINION ASSY (40/9=4.444)	TATA spare parts
273235300266	CROWN WHEEL & PINION ASSY	TATA spare parts
273235300267	TAPER ROLLER BEARING ASSY.	TATA spare parts
273235300268	TAPER ROLLER BEARING BS6	TATA spare parts
273235300290	BEARING ASSY TAIL PINION BS6	TATA spare parts
273235300302	CROWN WHEEL - PINION ASSY BS6-PH2	TATA spare parts
273235303101	TAPER ROLLER BRG DIFFERENTIAL 2515/3015/	TATA spare parts
273235303103	TAIL PINION BEARING (RA109RR) STEEL CAGE	TATA spare parts
273235303105	TAIL PINION BEARING (RA109RR) STEEL CAGE	TATA spare parts
273235303108	TAIL PINION BEARING (RA109RR) STEEL CAGE	TATA spare parts
273235303109	TAIL PINION BEARING (RA109RR) STEEL CAGE	TATA spare parts
273235303110	TAPER ROLLER BEARING	TATA spare parts
273235303111	TAIL PINION BEARING (RA109RR) STEEL CAGE	TATA spare parts
273235303113	CYLINDRICAL ROLLER BEARING(45X95X32) BS6	TATA spare parts
273235303114	TAPER ROLLER BRG.(145X65X39.75) BS6	TATA spare parts
273235303117	CYLINDRICAL ROLLER BEARING BS6	TATA spare parts
273235303702	PINION HOUSING BS6-PH2	TATA spare parts
273235305003	COUPLING FLANGE-PRESS DUST COVER	TATA spare parts
273235305004	COUPLING FLANGE-150 OD SERRATED.	TATA spare parts
273235305103	SPIDER DIFFERENTIAL 2515/3516/3015	TATA spare parts
27323530510660	DIFF CASE FASTER RATIO (9 X 14) BS6-PH2	TATA spare parts
273235305109	SPIDER DIFFERENTIAL	TATA spare parts
273235305111	DIFF.CASE CAST SLOW RATIO(9X14 GEARS)	TATA spare parts
273235305112	DIFFERENTIAL COVER (9X14 GEARS)	TATA spare parts
273235305113	DIFF. SPIDER(LOCKABLE SPH WASHER) BS1-4	TATA spare parts
273235305401	AXLE SHAFT GEAR 2515/3516/3015	TATA spare parts
273235305402	BEVEL PINION DIFFERENTIAL 2515/3516/3015	TATA spare parts
273235305404	PINION (41/6)	TATA spare parts
273235305406	PINION - CWP:41/7-0106OR	TATA spare parts
273235305418	PINION (41/6=6.83) OER-SPIRAC BS1/2/3/4	TATA spare parts
273235305420	PINION (41/7=5.857) OER-SPIRAC BS1/2/3/4	TATA spare parts
273235305432	PINION 41/6 OER-SPIRAC (IN EN-353 MATL)	TATA spare parts
273235305434	PINION 41/6 SPIROFLEX DIA 440	TATA spare parts
273235305437	REAR AXLE SHAFT GEAR (9X14)	TATA spare parts
273235305438	DIFFERENTIAL BEVEL PINION (9X14)	TATA spare parts
273235305441	PINION 41/6 OER-SPIRAC (FOR OIL SLINGER)	TATA spare parts
273235305442	REAR AXLE SHAFT GEAR (9X14)BS1/2/3/4/6	TATA spare parts
273235305443	DIFF. BEVEL PINION 9X14(CONIFLEX) BS1- 4	TATA spare parts
273235305444	PINION 43/7 (6.142) OER-SPIRAC/SPIROFLEX	TATA spare parts

273235305449	PINION (41/8)	TATA spare parts
273235305451	PINION (45/7 ) OER SPIRAC BS3	TATA spare parts
273235305485	DIFFERENTIAL SHAFT GEAR BS6	TATA spare parts
273235305486	DIFFERENTIAL BEVEL GEAR BS6	TATA spare parts
273235306101	LOCK PLATE DIFF COVER&CASE	TATA spare parts
273235307701	DUST SEAL-MECHANICAL FACE SEAL	TATA spare parts
273235307703	O-RING BS6-PH2	TATA spare parts
273235308002	HEX BOLT SERRATED CASE&COVER 2515/3015	TATA spare parts
273235308003	HEX BOLT SERRATED CROWN WHEEL 2515/3015/	TATA spare parts
273235308201	DUST COVER-PRESS TYPE FOR DUST SEAL	TATA spare parts
273235308202	OIL SLINGER-PRESS TYPE	TATA spare parts
273235308302	SHIM PINION DEPTH SETTING BS6	TATA spare parts
273235308303	SHIM PINION DEPTH SETTING BS6	TATA spare parts
273235308304	SHIM PINION DEPTH SETTING BS6	TATA spare parts
273235308305	SHIM PINION DEPTH SETTING BS6	TATA spare parts
273235308306	SHIM PINION DEPTH SETTING BS6	TATA spare parts
273235308307	SHIM PINION DEPTH SETTING BS6	TATA spare parts
273235308308	SHIM PINION DEPTH SETTING BS6	TATA spare parts
273235308601	SPACER BET.PINION BRG & C.FLNG OIL SLIN	TATA spare parts
273235309201	SPHERICAL WASHER 2515/3015/1615/3516	TATA spare parts
273235309202	THRUST WASHER 1.95MM 2515/3015/1615/3516	TATA spare parts
273235309203	THRUST WASHER 2.00MM 2515/3015/1615/3516	TATA spare parts
273235309204	THRUST WASHER 2.05MM 2515/3015/1615/3516	TATA spare parts
273235309205	THRUST WASHER 2.10MM 2515/3015/1615/3516	TATA spare parts
273235309206	THRUST WASHER 2.15MM 2515/3015/1615/3516	TATA spare parts
273235309207	THRUST WASHER 2.20MM 2515/3015/1615/3516	TATA spare parts
273235309208	THRUST WASHER 2.25MM 2515/3015/1615/3516	TATA spare parts
273235309209	WASHER SPHERICAL LOCKABLE	TATA spare parts
273235309210	THRUST WASHER- 1.95 THK. BS1/2/3/4	TATA spare parts
273235309211	THRUST WASHER- 2.00 THK.	TATA spare parts
273235309212	THRUST WASHER-2.05 THK.	TATA spare parts
273235309213	THRUST WASHER-2.10 THK.	TATA spare parts
273235309214	THRUST WASHER-2.15 THK.	TATA spare parts
273235309215	THRUST WASHER-2.2 THK.	TATA spare parts
273235309216	THRUST WASHER- 2.25 THK.	TATA spare parts
273235309217	SPHERICAL WASHER BS1/2/3/4	TATA spare parts
273235309218	THRUST WASHER SHAFT GEAR BS6 PH2	TATA spare parts
273235309219	THRUST WASHER SHAFT GEAR BS6 PH2	TATA spare parts
273235309220	THRUST WASHER SHAFT GEAR BS6 PH2	TATA spare parts
273235309221	THRUST WASHER SHAFT GEAR BS6 PH2	TATA spare parts
273235309222	THRUST WASHER SHAFT GEAR BS6 PH2	TATA spare parts
273235309223	THRUST WASHER SHAFT GEAR BS6 PH2	TATA spare parts
273235309224	THRUST WASHER SHAFT GEAR BS6 PH2	TATA spare parts
273235600102	ASSY. REAR HUB (BIGGER BRG.)109 RR BS1-6	TATA spare parts
273235600103	ASSY. REAR HUB (W/O BRG/SEAL) BS1/2/3/4/	TATA spare parts
273235600107	ASSY. REAR HUB COMP.(BRG/ABS RING) BS2-6	TATA spare parts
273235600116	ASSY REAR HUB COMP.(ABS & SINGLE TYRE)	TATA spare parts

273235600120	ASSY REAR HUB COMP. (BIGGER BRGS)	TATA spare parts
273235600134	ASSY.REAR HUB (W/O BRGS.- OIL SEALS) BS6	TATA spare parts
273235600135	REAR HUB ASSY WITH BRG & POLE WHEEL ABS	TATA spare parts
273235603101	TAPER ROLLER BRG. 75X130X41	TATA spare parts
273235603102	TAPER ROLLER BEARING	TATA spare parts
273235603103	TAPER ROLLER BEARING	TATA spare parts
273235603104	TAPER ROLLER BEARING	TATA spare parts
273235603105	TAPER ROLLER BEARING	TATA spare parts
273235603106	TAPER ROLLER BRG-75X130X41	TATA spare parts
273235603107	TAPER ROLLER BRG(95.25X168X41.275)	TATA spare parts
273235603108	TAPER ROLLER BRG (85X150X38.5)	TATA spare parts
273235603111	TR BRG (95.25X168.275X41.275)	TATA spare parts
273235603112	TAPER ROLLER BRG.(85X150X38.5)	TATA spare parts
273235603113	INSERT BEARING (140X165X100)	TATA spare parts
273235603116	BEARING BS6	TATA spare parts
273235605501	HUB REAR 335 PCD	TATA spare parts
273235605506	HUB REAR FOR INSERT UNIT BEARING	TATA spare parts
273235605517	REAR HUB BS6	TATA spare parts
273235606502	HUB LOCK NUT	TATA spare parts
273235607701	OIL SEAL 135X170X15	TATA spare parts
273235607702	OIL SEAL 125X150X12	TATA spare parts
273235607707	OIL SEAL (135X170X15) DOUBLE LIP	TATA spare parts
273235607708	OIL SEAL (125X150X12)	TATA spare parts
273235607709	OIL SEAL (135X170X15)	TATA spare parts
273235607710	OIL SEAL (125X150X12)	TATA spare parts
273235607711	OIL SEAL (135X170X15) BS1/2/3/4/6	TATA spare parts
273235607712	OIL SEAL (125X150X12) BS1/2/3/4/6	TATA spare parts
273235607713	OIL SEAL (135X170X15)	TATA spare parts
273235607714	OIL SEAL (125X150X12)	TATA spare parts
273235607715	O-RING-ID 85X5.33	TATA spare parts
273235607716	O-RING-ID 85X5.33	TATA spare parts
273235607718	O-RING	TATA spare parts
273235608201	OIL CATCHER (ABS)	TATA spare parts
273235608602	TONGUE SPACER (HUB OUTER BEARING)	TATA spare parts
273235608603	SPACER (HUB OUTER BEARING)	TATA spare parts
273235608604	SPACER B/W BEARING TO AXLE SHAFT	TATA spare parts
273235707901	REAR AXLE SHAFT (WITH DIFF.LOCK SPLINES)	TATA spare parts
273235707904	REAR AXLE SHAFT BOLTED (ATMU)	TATA spare parts
273235707905	REAR AXLE SHAFT (966 LONG)	TATA spare parts
273235707906	REAR AXLE SHAFT (1106 LONG)	TATA spare parts
2732H9W0135009	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2732H9W0135014	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2732H9W0135015	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
273335000101	ASSY RA.COMP W/35/9 (509 M)	TATA spare parts
273335000102	ASSY R A COMP W/37/8 RATIO SP HUB T C F	TATA spare parts
273335000107	ASSY.RA.(509M)35/9 LHD SPG.HUB TWIN TYR	TATA spare parts
273335000108	ASSY REAR AXLE COMPLETE	TATA spare parts

273335000112	ASSY 709 RA COMP W/BRKS (32/7)W/ARB-407T	TATA spare parts
273335000113	ASSY 709 RA COMP W/BRK 32/7 WO/ARB-407TT	TATA spare parts
273335000114	ASY RA COMP W/BRKS 31/8 W/LCRV (509 M)	TATA spare parts
273335000115	ASSY. RA COMPLETE WITH BRK 32/7 RATIO WI	TATA spare parts
273335000118	ASY.709 RA COMP 32/7 W/LCRV WO/A.R.BAR.	TATA spare parts
273335000119	ASY.709 RA COMP 31/8 W/O LCRV W/O AR.BA	TATA spare parts
273335000120	ASY 709 RA COMP W/BRK 28/9 W/ARB WO/LCRV	TATA spare parts
273335000123	ASY RA COMP 32/7 RATIO W/LCRV WO/AR.BAR	TATA spare parts
273335000124	ASSY R.A COMP W/LCRV BRAKES 31/8 RATIO	TATA spare parts
273335000126	ASSY REAR AXLE COMP WITH 31/8 RATIO W/A.	TATA spare parts
273335000128	ASSY 709 RA COMP W/BRK 31/9 W/ARB WO/LCR	TATA spare parts
273335000132	ASSY REAR AXLE COMP WITH 33/8 RATIO	TATA spare parts
273335000133	ASSY RA COMP WITH 31/9 RATIO W/O AR.BAR	TATA spare parts
273335000134	ASSY REAR AXLE COMP 33/8 RATIO W/LCRVWO/A	TATA spare parts
273335000135	RA SK 407 BSIII ( 33/8 )	TATA spare parts
273335000138	ASSY REAR AXLE COMP WITH 32/7 RATIO W/O	TATA spare parts
273335000139	RA LHD 407 ( 33/8 )	TATA spare parts
273335000142	REAR AXLE 410 SFC QRY ( 31/8 )	TATA spare parts
273335000144	ASSY RA COMP WITH 33/8 RATIO W/AR.BAR	TATA spare parts
273335000145	ASSY REAR AXLE COMP WITH 31/9 RATIO	TATA spare parts
273335000146	REAR AXLE COMP 33/8 RATIO;W/LCRV;WO/AR.B	TATA spare parts
273335000147	ASSY REAR AXLE COMP WITH 33/8 RATIO W/O	TATA spare parts
273335000148	ASSY RA COMP WITH 32/7 RATIO W/O AR.BAR	TATA spare parts
273335000149	RA 407 QRY M.FIP (33/8)	TATA spare parts
273335000150	ASSY REAR AXLE COMP WITH 31/8 RATIO	TATA spare parts
273335000155	ASY RA COMP 33/8 RATIO W/LCRV WO/AR.BAR	TATA spare parts
273335000156	ASY RA COMP 32/7 RATIO W/LCRV WO/AR.BAR(	TATA spare parts
273335000161	REAR AXLE ASSY COMP 31/8 W/LCRV BRAKES	TATA spare parts
273335000163	REAR AXLE ASSY	TATA spare parts
273335100102	ASSY RA.BEAM (509 M ).	TATA spare parts
273335100104	ASSY REAR AXLE HOUSING LP 407 TWIN TYRE	TATA spare parts
273335100105	ASSY.R.A.HSG.WITH SUPP.TUBE COMP.	TATA spare parts
273335100106	ASSY RA BEAM SFC407 TWIN TYRE W/ SUPPTUB	TATA spare parts
273335100110	ASSY RA.HSG W/SUPP TUBE COMP W/ANTI ROLL	TATA spare parts
273335100111	ASSY RA HSG W/SUPP TUBE COMP WO/ANTI ROL	TATA spare parts
273335100112	ASY.RA.HSG W/SUP TUBE COMP W/LCRV.WO/AR	TATA spare parts
273335100113	ASY RA.HSG+SUPP TUBE W/LCRV 17 C.B HOLE.	TATA spare parts
273335100121	ASSY RA HSG W/SUPP TUBE COMP WO/ANTI ROL	TATA spare parts
273335100123	ASSY RA.HSG+SUPP TUBE W/LCRV 17 C.B HOLE	TATA spare parts
273335100126	ASSY RA.HSG+SUPP TUBE W/O LCRV W/O ARB(H	TATA spare parts
273335100127	ASSY RA.HSG W/SUPP TUBE COMP W/ARB	TATA spare parts
273335100128	ASSY RA HSG W/SUPP TUBE COMP WO/ANTI ROL	TATA spare parts
273335100129	ASSY.RA.HSG W/SUP TUBE COMP W/LCRV.WO/A	TATA spare parts
273335100130	ASSY RA.HSG+SUPP TUBE W/LCRV 17 C.B HOLE	TATA spare parts
273335100131	ASSY REAR AXLE HSG W/SUPP TUBE COMP	TATA spare parts
273335100135	REAR AXLE HOUSING ASSY WITH SUPPORT TUBE	TATA spare parts
273335108201	BRACKET (FOR REMOTE BREATHER)	TATA spare parts

273335108601	PRESSURE RING.	TATA spare parts
273335159901	ADAPTER (M10-ON HSG & M10X1 FOR HOSE)	TATA spare parts
273335603101	TAPER ROLLER BRG 33211	TATA spare parts
273335603102	TAPER ROLLER BRG 33210	TATA spare parts
273335603103	TAPER ROLLER BRG. HUB-INNER BS2/3/4/6	TATA spare parts
273335603104	TAPER ROLLER BRG.HUB-OUTER	TATA spare parts
273335603105	TAPER ROLLER BRG 33211	TATA spare parts
273335603106	TAPER ROLLER BRG 33210	TATA spare parts
273335603701	RR BRAKE DRUM WITH HUB LP 407 TWIN TYRE	TATA spare parts
273335603702	REAR BRAKE DRUM WITH HUB-M16 STUD	TATA spare parts
273335603704	ASSY. REAR BRAKE DRUM W/HUB BS2/3	TATA spare parts
273335603705	REAR BRAKE DRUM W/HUB OUT OILSEAL BS2-4	TATA spare parts
273335607701	OIL SEAL HUB INNER	TATA spare parts
273335608201	OIL CATCHER REAR HUB LP407 TWIN TYRE	TATA spare parts
273335608601	SPACER BETWEEN OIL SEAL & INNER BRG	TATA spare parts
273335608603	SPACER OUTER OIL SEAL	TATA spare parts
273335608605	SPACER TUBE FOR LARGER I.HUB BRG.	TATA spare parts
273335707901	REAR AXLE SHAFT LP 407 TWIN TYRE	TATA spare parts
273335707902	REAR AXLE SHAFT-TWIN TYRE-M16 STUDS	TATA spare parts
273639000105	ASSY TRAILING AXLE RA 909-2516	TATA spare parts
273639000115	ASY RA COMP TRAILING 1055 TELCO CAST Z	TATA spare parts
273639000121	RA909RR DUMMY AXLE (BARE)	TATA spare parts
273639000123	ASSY.RA-909RR COMP(DEAD) W/O TOP SADDLE	TATA spare parts
273639000130	RA-909RR,1950 TRACK,NON-VEH BUSINESS	TATA spare parts
273639000134	RA-909RR WO/TOP SADDLE-135X140X12	TATA spare parts
27363900013490	ASSY WHEEL END KIT (CAR CARRIER KIT)	TATA spare parts
273639000136	ASSY.DA-909RR 1055 AF235 VOSS BRKS	TATA spare parts
273639000137	RA-909RR COMP.1055 ABS	TATA spare parts
273639000139	ASSY REAR AXLE(TRAILING)RA-909RR COMPLET	TATA spare parts
273639000141	RA-909RR COMP.1055 ASA-VOSS	TATA spare parts
273639000145	ASSY.RA-910 COMP.(NVB)WITH BRAKES	TATA spare parts
273639000153	ASSY RA-909RR COMP.W/BRKS 1055	TATA spare parts
273639000155	ASSY REAR AXLE (TRAILING) RA-909RR WITH	TATA spare parts
273639000160	ASSY.RA-909RR COMP.W.BRK 1055 1860 TRACK	TATA spare parts
273639000164	RA-909RR COMPL WITH BRAKES 1055	TATA spare parts
273639000172	ASSY RA-909 COMP W/BRKS BANJO 1026 SCD 1	TATA spare parts
273639000180	REAR AXLE ASSY 910 COMP 1055 LSV BKT	TATA spare parts
273639000182	REAR AXLE ASSY 910 COMP 1044 LSV BKT	TATA spare parts
273639000190	REAR AXLE ASSY WITH BRAKES	TATA spare parts
273639000208	REAR AXLE ASSY WITH BRAKES	TATA spare parts
273639000229	REAR AXLE ASSY WITH BRAKES	TATA spare parts
273639000237	REAR AXLE ASSY WITH BRAKES	TATA spare parts
273639000241	REAR AXLE ASSY WITH BRAKES	TATA spare parts
273639000242	REAR AXLE ASSY	TATA spare parts
273639000247	REAR AXLE ASSY WITH BRAKES BS6	TATA spare parts
273639000248	REAR AXLE ASSY WITH BRAKES BS6	TATA spare parts
273639000252	REAR AXLE ASSY WITH BRAKES BS6	TATA spare parts



273639000255	REAR AXLE ASSY WITH BRAKES BS6	TATA spare parts
273639000256	REAR AXLE ASSY WITH BRAKES BS6	TATA spare parts
273639000267	REAR AXLE ASSY WITH BRAKES BS6	TATA spare parts
273639000280	REAR AXLE ASSY WITH BRAKES BS6	TATA spare parts
273639000284	REAR AXLE ASSY WITH BRAKES BS6	TATA spare parts
273639000297	REAR AXLE ASSY WITH BRAKES RA-909RR BS6	TATA spare parts
273639100111	ASSY R A BEAM W/PRESSURE RING 1044 S.C	TATA spare parts
273639100112	ASSY DEAD BEAM W/PRE.RING (1055)109RR	TATA spare parts
273639100114	ASSY RA.BEAM-M/CD DEAD-1055 S.CEN	TATA spare parts
273639100125	ASY RA BEAM W/PRESSURE RING TELCO CAST	TATA spare parts
273639100141	1817 - 14 MM BARE AXLE BEAM	TATA spare parts
273639100150	ASSY.R.A.BEAM 1950 TRACK W/PR.RING	TATA spare parts
273639100151	1950 - 14 MM BARE AXLE BEAM	TATA spare parts
273639100157	1817 - 12 MM BARE AXLE BEAM	TATA spare parts
273639100159	ASSY.REAR AXLE BEAM W/PR.RING (LPT 3118-	TATA spare parts
273639100167	ASSY RA-910 BEAM M/CED(NVB)(135X140X12)	TATA spare parts
273639100172	ASSY REAR AXLE BEAM WITH PRESSURE RING	TATA spare parts
273639100175	ASSY. REAR AXLE BEAM W/PR.RING BS2/3/4	TATA spare parts
273639100179	ASSY.RA BEAM W.PR.RING 1860 TRACK	TATA spare parts
273639100183	ASSY REAR AXLE BEAM WITH PRESSURE RING	TATA spare parts
273639100192	ASSY RA BANJO BEAM M/CED 1026 SCD	TATA spare parts
273639100195	AXLE BEAM ASSY BS6	TATA spare parts
273639100196	ASSY R.A.BEAM M/CED FR.WELD 1055 150 SL.	TATA spare parts
273639100203	REAR AXLE ASSY W/T PR RING LSV BKT	TATA spare parts
273639100204	REAR AXLE ASSY M/CED F/W 1055 LSV BKT	TATA spare parts
273639100205	REAR AXLE ASSY 1044 W/T PR RING LSV BKT	TATA spare parts
273639100220	REAR AXLE ASSY WITH PRESSURE RING	TATA spare parts
273639100240	REAR AXLE BEAM ASSY WITH PRESSURE RING B	TATA spare parts
273639100243	REAR AXLE ASSY WITH PRESSURE RING	TATA spare parts
273639100244	AXLE BEAM ASSY BS6	TATA spare parts
273639100247	REAR AXLE ASSY WITH PRESSURE RING	TATA spare parts
273639100250	AXLE BEAM ASSY BS6	TATA spare parts
273639100251	REAR AXLE ASSY WITH PRESSURE RING	TATA spare parts
273639100252	AXLE BEAM ASSY BS6	TATA spare parts
273639100253	REAR AXLE BEAM ASSY WITH PRESSURE RING	TATA spare parts
273639100256	REAR AXLE BEAM ASSY BS6	TATA spare parts
273639100260	REAR AXLE BEAM ASSY BS6	TATA spare parts
273639100261	AXLE BEAM ASSY BS6	TATA spare parts
273639100267	AXLE BEAM ASSY BS6	TATA spare parts
273639100268	REAR AXLE BEAM ASSY WITH PRESSURE RING B	TATA spare parts
273639100271	REAR AXLE BEAM ASSY BS6	TATA spare parts
273639100282	AXLE BEAM ASSY BS6	TATA spare parts
273639105101	BRACKET (CAST `Z` BRKT.BRKS)	TATA spare parts
273639105105	SPRING SADDLE (BOTTOM)(1055)	TATA spare parts
273639106901	SPINDLE AXLE BEAM (14 THK.BEAM)	TATA spare parts
273639107110	COVER PLATE (FOR NON DRIVING AXLE)	TATA spare parts
273639600102	RA909RR KIT +TYPE 20 BOOSTERS	TATA spare parts

273639600104	RA909RR KIT +TYPE 24 BOOSTERS	TATA spare parts
273639600106	ASSY. REAR HUB (W/O BRG./OIL SEAL) BS2/3	TATA spare parts
273639600107	ASSY.HUB COVER (SHORTER HUB)	TATA spare parts
273639600114	ASSY REAR HUB COMPLETE	TATA spare parts
273639600116	ASSY. REAR HUB COMP. (NON DRIVE) BS2-6	TATA spare parts
273639600117	REAR HUB ASSY WITH WHEEL BOLT	TATA spare parts
273639600118	ASSY HUB COVER(SHORTER HUB)	TATA spare parts
273639600120	REAR HUB ASSY WITH BEARING BS6	TATA spare parts
273639600126	REAR HUB ASSY WITH BEARING BS6	TATA spare parts
273639604701	COVER (SHORTER HUB)	TATA spare parts
273639604703	COVER(REAR HUB)	TATA spare parts
273639604704	COVER (SHORTER HUB)FOR NVB	TATA spare parts
273639604705	COVER REAR HUB BS6	TATA spare parts
273639605302	GASKET(REAR HUB)	TATA spare parts
273639605504	HUB REAR (108RR BEARINGS)	TATA spare parts
273639605505	RA-909RR HUB REAR(CAST.SPIGOTTED)	TATA spare parts
273639605506	HUB REAR FOR INSERT UNIT BEARING BS6	TATA spare parts
273639605508	REAR HUB	TATA spare parts
273639605509	REAR HUB	TATA spare parts
273639606501	HUB LOCKING NUT	TATA spare parts
273639608601	SPACER WITH HOLES (HUB LOCKNUT BRG)	TATA spare parts
2736H9W0239010	DEAD REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2736H9W0239011	DEAD RR AXLE ASSY WITH BRAKES-MFG BS6-PH	TATA spare parts
2736H9W0239012	DEAD REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
2736H9W0239015	DEAD REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
273733000103	ASSY FA-106 (41/6)WITH BRAKES COMPLETE	TATA spare parts
273733000110	FA-106 41/6 COMP W/BAKS(ABS)AND SU.SADDL	TATA spare parts
273733153101	CYL.ROLLER BEARING-60X110X22	TATA spare parts
273733153101AE	CYL.ROLLER BRG -60X110X22 -1628	TATA spare parts
273733153102	THRUST ROLLER BEARING	TATA spare parts
273733153102AE	THRUST ROLLER BRG 47X78X22 -1628	TATA spare parts
273733153103	THRUST ROLLER BEARING	TATA spare parts
273733153701	FA -106 AXLE BEAM HOUSING.	TATA spare parts
273733155101	JOINT FLANGE	TATA spare parts
273733156701	KING PIN (TOP)	TATA spare parts
273733156702	KING PIN (BOTTOM)	TATA spare parts
273733158601	SPACER (BET.CYL.ROLLER BRG.& CIRCLIP)	TATA spare parts
273733158602	DUST COVER	TATA spare parts
273733158602AE	DUST COVER 1628	TATA spare parts
273733158603	SPACER	TATA spare parts
273733158801	STUD (JOINT FLANGE TO BEAM)	TATA spare parts
273733159901	ADAPTOR(ON AXLE HOUSING)	TATA spare parts
273733250104	ASSY.KING PIN SUPPORT (TOP)	TATA spare parts
273733250105	ASSY.SUPPORT SLEEVE	TATA spare parts
273733253102	NEEDLE ROLLER BEARING-55X68X35	TATA spare parts
273733253401	BUSH - TOP	TATA spare parts
273733253402	BUSH - BOTTOM	TATA spare parts

273733254801	HOLLOW DOWEL	TATA spare parts
273733257101	COVER PLATE	TATA spare parts
273733257101AE	COVER PLATE 1628	TATA spare parts
273733257702	OIL SEAL (55X70X8)-FENNER INDIA MAKE	TATA spare parts
273733257901	SUPPORT SLEEVE	TATA spare parts
273733258301	SHIM-0.50 THK.	TATA spare parts
273733258302	SHIM-0.15 THK.	TATA spare parts
273733258303	SHIM-1.00 THK.	TATA spare parts
273733258304	SHIM-0.10 THK.	TATA spare parts
273733258305	SHIM-1.50 THK.	TATA spare parts
273733258306	SHIM-0.20 THK.	TATA spare parts
273733258307	SHIM-0.25 THK.	TATA spare parts
273733258308	SHIM 2.50 THK	TATA spare parts
273733258601	SPACER (SUPPORT SLEEVE)	TATA spare parts
273733450101	ASSY.HUB COMP.WITH BRG. & OIL SEAL	TATA spare parts
273733456501	LOCKING RING	TATA spare parts
273733458201	LOCKING PLATE	TATA spare parts
273733458601	SPACER RING (BET.OIL SEAL & HUB BRG.)	TATA spare parts
273733458602	TOUNGE WASHER	TATA spare parts
273733750102	ASSY.DRIVE SHAFT COMPLETE	TATA spare parts
273733750103	ASSY DRIVE SHAFT (HUB END)	TATA spare parts
273733750104	ASSY DRIVE SHAFT (DIFF.END)	TATA spare parts
273733750105	ASSY.NEEDLE HOUSING(DRIVE SHAFT YOKE)	TATA spare parts
273733750105AE	ASSY NDLE HSG(DRVE SFT YKE)-1628	TATA spare parts
273733750106	ASSY.NEEDLE HOUSING (UJ HOUSING)	TATA spare parts
273733750106AE	ASSY.NEEDLE HSG. (UJ HSG.) -1628	TATA spare parts
273733753401	NEEDLE HOUSING0-UJ	TATA spare parts
273733753401AE	NEEDLE HOUSING0-UJ 1628	TATA spare parts
273733753402	NEEDLE HOUSING-UJ	TATA spare parts
273733754301	CIRCLIP (FOLLOWER)	TATA spare parts
273733754304	CIRCLIP-2.00 THK.(UJ)	TATA spare parts
273733754305	CIRCLIP-2.25 THK.(UJ)	TATA spare parts
273733754306	CIRCLIP-1.95 THK.(UJ)	TATA spare parts
273733754307	CIRCLIP-2.05 THK.(UJ)	TATA spare parts
273733754308	CIRCLIP-2.10 THK.(UJ)	TATA spare parts
273733755101	FOLLOWER	TATA spare parts
273733755102	HOUSING-UJ	TATA spare parts
273733755102AE	HOUSING-UJ 1628	TATA spare parts
273733755103	DRIVE SHAFT YOKE-UJ	TATA spare parts
273733755103AE	DRIVE SHAFT YOKE-UJ 1628	TATA spare parts
273733756501	LOCK NUT (DRIVE SHAFT)	TATA spare parts
273733756701	PIN-UJ	TATA spare parts
273733756701AE	PIN-UJ 1628	TATA spare parts
273733757201	TAPER PLUG (M12X1.5) UJ	TATA spare parts
273733757701	OIL SEAL-UJ	TATA spare parts
273733757701AE	OIL SEAL-UJ 1628	TATA spare parts
273733757901	DRIVE SHAFT (HUB END)	TATA spare parts

273733757902	DRIVE SHAFT (DIFF.END)	TATA spare parts
273733758601	SPACER (FOLLOWER END)	TATA spare parts
273828500101	ASSY.BRACKET (AUX.GEAR BOX MOUNTING)	TATA spare parts
273828500102	ASSY.BRACKET (AUX.GEAR BOX MOUNTING )	TATA spare parts
273828503501	SPACER (AUX.GEAR BOX MOUNTING)	TATA spare parts
273831200104	ASSY.3RD CROSS MEMBER	TATA spare parts
273831200105	ASSY END CROSS MEMBER	TATA spare parts
273831207110	SUPPORT RH	TATA spare parts
273831207111	SUPPORT LH	TATA spare parts
273831207114	REINFORCEMENT RH (ENG MTG BKT.REAR)	TATA spare parts
273831207115	REINFORCEMENT LH (ENG MTG BKT.REAR)	TATA spare parts
273831207118	REINFORCEMENT	TATA spare parts
273831208207	SHIM 3.15 THK	TATA spare parts
273831208208	SHIM 1 THK	TATA spare parts
273831300101	ASSY.REINFORCEMENT BRACKET	TATA spare parts
273832204201	U CLAMP (FRONT)	TATA spare parts
273832300101	ASSY.BKT.-R.H.(SHOCK ABSORBER FRT.LOWER)	TATA spare parts
273832300102	ASSY.BKT.-L.H.(SHOCK ABSORBER FRT.LOWER)	TATA spare parts
273832300103	ASSY.BKT.(SHOCK AHSORBER FRONT UPPER)	TATA spare parts
273841120101	ASSY.PROPELLER SHAFT(GEAR BOX TO AUX GEA	TATA spare parts
273841120102	ASSY.PROPELLER SHAFT( AUX GEAR BOX TO RE	TATA spare parts
273841120103	ASSY.PROPELLER SHAFT (AUX GEAR BOX TO LI	TATA spare parts
273841120104	ASSY.PROP.SHAFT (100 DIA.X 3 THK)	TATA spare parts
273846306001	PITMAN ARM	TATA spare parts
273854400101	ASSY BRACKET RH.(TAIL & BLACK OUT LAMP M	TATA spare parts
273854400106	ASSY BRACKET LH.(TAIL & BLACK OUT LAMP M	TATA spare parts
273935000181	ASSY RA-210HRT REAR FWD AXLE COMP W/KB B	TATA spare parts
273935000182	ASSY RA-210HRT RWD AXLE W/KB BRAKES COMP	TATA spare parts
273935000184	ASSY RA FWD AXLE W/24 BRKS	TATA spare parts
273935000186	ASSY RWD REAR AXLE COMPLETE RA-2106.49 R	TATA spare parts
273935000193	ASSY RA-210HRT FWD AXLE 24 BRKS W/5.49 R	TATA spare parts
273935000194	REAR AXLE 210HRT RWD AXLE W/BRKS 5.49 19	TATA spare parts
273935000197	RA-210HRT RWD W/BRKS 6.49 1860 CAST T150	TATA spare parts
273935000199	RA-210HRT FWD AXLE W/BRKS 6.49 2085 CAST	TATA spare parts
273935000201	RA-210HRT RWD AXLE W/BRKS.6.49 2085 CAST	TATA spare parts
273935000207	RA-210HRT RWD AXLE W/BRKS 6.49 2085 T150	TATA spare parts
273935000209	ASSY RA-210HRT FWD AXLE COMPLETE W/KB B	TATA spare parts
273935000211	ASSY RA-210HRT RWD AXLE W/KB BRAKES COMP	TATA spare parts
273935000219	ASSY.RA-210HRT CTIS THRO' DRIVE AXLE	TATA spare parts
273935000221	ASSY.RA210HRT CTIS REAR REARWARD AXLE	TATA spare parts
273935000223	ASSY RA-210HRT FWD AXLE W/4.30 BRKS 3.22	TATA spare parts
273935000225	ASSY RA-210HRT RWD AXLE W/4.30 BRKS 3.22	TATA spare parts
273935000231	ASSY.RA210HRT CTIS REAR RWD AXLE W/BRK	TATA spare parts
273935000243	ASSY RA-210HRT FWD AXLE W/BRKS 5.49	TATA spare parts
273935000245	ASSY RA-210HRT RWD AXLE W/BRKS 5.49	TATA spare parts
273935000247	ASSY RA-210HRT FWD AXLE W/BRKS 4.92	TATA spare parts
273935000249	ASSY RA-210HRT RWD AXLE W/BRKS 4.92	TATA spare parts

273935000259	REAR AXLE W/BRK CAST 210HRT FWD 7.24 BS6	TATA spare parts
273935000260	RERA AXLE W/BRK CAST 210HRT RWD 7.24 BS6	TATA spare parts
273935000261	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
273935000262	REAR AXLE ASSY WITH BRAKE RWD BS6	TATA spare parts
273935000272	REAR AXLE W/BRK CAST 210HRT FWD 7.24 BS4	TATA spare parts
273935000274	RERA AXLE W/BRK CAST 210HRT RWD 7.24 BS4	TATA spare parts
273935000282	AXLE ASSY W/7.24 RATIO W/1900 TRK	TATA spare parts
273935000284	AXLE ASSY W/7.24 RATIO W/1900 TRK WTRK	TATA spare parts
273935000322	ASSY.RA-210HRT 7.24 CTIS T180	TATA spare parts
273935000324	ASSY.RA-210HRT 7.24 ABS CTIS T180	TATA spare parts
273935000334	TANDEM BOGIE AXLE ASSY WITH BRAKE	TATA spare parts
273935000335	REAR AXLE ASSY WITH HUB FWD	TATA spare parts
273935000336	AXLE ASSY WITH BRAKE RWD	TATA spare parts
273935000337	REAR AXLE ASSY WITH HUB RWD	TATA spare parts
273935000338	AXLE ASSY WITH BRAKE FWD	TATA spare parts
273935000340	REAR AXLE ASSY WITH BRAKE RWD	TATA spare parts
273935000356	AXLE ASSY WITH BRAKE RWD	TATA spare parts
273935000358	REAR AXLE ASSY WITH BRAKE FWD ABS	TATA spare parts
273935000359	REAR AXLE ASSY WITH BRAKE RWD ABS	TATA spare parts
273935000384	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
27393500038490	ESCORTS RA ASSY WITH CAST BEAM	TATA spare parts
273935000394	REAR AXLE ASSY WITH BRAKE FW BS6	TATA spare parts
273935000395	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
273935000398	REAR AXLE ASSY WITH BRAKE RWD	TATA spare parts
273935000399	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
273935010131	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
273935010133	REAR AXLE ASSY WITH BRAKE RWD BS6	TATA spare parts
273935010151	REAR AXLE ASSY WITH BRAKE & DIFF LOCK BS	TATA spare parts
273935010153	REAR AXLE ASSY WITH BRAKE FWD BS6-PH2	TATA spare parts
273935100123	ASSY FWD AXLE BEAM W/PR.RING/STUDS/DOWE	TATA spare parts
273935100124	ASSY FWD AXLE BEAM (M/CED)1900 TRK RA-21	TATA spare parts
273935100125	ASSY RWD AXLE BEAM W/PR.RING/STUDS/DOWE	TATA spare parts
273935100135	ASSY. FWD AXLE BEAM W/RING/STUD/DOWL BS3	TATA spare parts
273935100136	ASSY FWD AXLE BEAM (M/CED) TML RA-210HR	TATA spare parts
273935100137	ASSY RWD AXLE BEAM W/PR.RING/STUDS/DOWE	TATA spare parts
273935100138	ASSY RWD AXLE BEAM (M/CED) TML RA-210HR	TATA spare parts
273935100141	RWD AXLE BEAM W/PR.RING STUDS DOWELS	TATA spare parts
273935100142	ASSY RWD AXLE BEAM - WITH CAST BEAM	TATA spare parts
273935100145	ASY RWD BEAM W/PR. RING STUDS DOWELS	TATA spare parts
273935100148	ASSY FWD AXLE BEAM W/PR.RING/STUDS/DOW	TATA spare parts
273935100150	ASSY RWD AXLE BEAM W/PR.RING/STUDS/DOWE	TATA spare parts
273935100153	ASSY REAR REARWARD AXLE BEAM W.PR.RING S	TATA spare parts
273935100155	ASSY THRO DRIVE AXLE BEAM W/PR.RING ST	TATA spare parts
273935100178	ASSY. RR FWD AXLE BEAM W/RING&STUD BS2/4	TATA spare parts
273935100179	AXLE BEAM ASSY WITH SPINDLE FWD	TATA spare parts
273935100180	ASSY. RR RWD AXLE BEAM W/RING STUD BS4/6	TATA spare parts
273935100188	ASSY FWD AXLE BEAM W/PR.RING/STUDS	TATA spare parts

273935100190	ASSY RWD AXLE BEAM W/PR.RING/STUDS/DOWE	TATA spare parts
273935100214	AXLE BEAM ASSY WITH RING & AMP STUD RR F	TATA spare parts
273935100223	AXLE BEAM ASSY WITH RING & STUD RWD	TATA spare parts
273935100234	REAR AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
273935100235	REAR AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
273935100245	AXLE BEAM ASSY WITH RING & STUD FWD BS6-	TATA spare parts
273935100247	AXLE BEAM ASSY WITH SPINDLE ASSY AXLE BE	TATA spare parts
273935103103	SRDG BALL BEARING OUTPUT SHAFT	TATA spare parts
273935103401	SPINDLE BUSH	TATA spare parts
273935103711	AXLE BEAM HOUSING	TATA spare parts
273935103712	ASSY FORWARD AXLE BEAM HOUSING	TATA spare parts
273935103713	AXLE BEAM HOUSING (FOR THROUGH DRIVE AXL	TATA spare parts
273935103714	AXLE BEAM HOUSING-REAR REARWARD	TATA spare parts
273935103718	AXLE BEAM HOUSING FWD BS6	TATA spare parts
273935103719	RWD AXLE BEAM HOUSING- 1900TRK- 48T SUSP	TATA spare parts
273935106702	CYLINDRICAL PIN	TATA spare parts
273935106902	SPINDLE ( CAST BEAM)	TATA spare parts
273935106903	SPINDLE FOR CTIS	TATA spare parts
273935107902	OUTPUT SHAFT (FRONT TANDEM)	TATA spare parts
273935107902AE	OUTPUT SHAFT (FRONT TANDEM)-1628	TATA spare parts
273935108207	OIL DEFLECTOR	TATA spare parts
273935108207AE	OIL DEFLECTOR 1628	TATA spare parts
273935108601	PRESSURE RING	TATA spare parts
273935110101	ASSY.DRIVE HEAD COMPLETE	TATA spare parts
273935110102	ASSY. CARRIER HSG.WITH PLUMMER BLOCK	TATA spare parts
273935110102AE	ASSY CARR HSG.W/ PLMMR BLK -1628	TATA spare parts
273935110123	ASSY DRIVE HEAD COMP (25/12)	TATA spare parts
273935110125	ASSY CARI HSG W/STUDS FRT-TAN 25/12	TATA spare parts
273935110129	ASSY DRIVE HEAD COMP (25/12) W/IAD BUSH	TATA spare parts
273935110133	CARRIER HOUSING WITH PLUMMER BLOCK	TATA spare parts
273935110144	ASSY DRIVE HEAD COMP 30/17 IAD BUSH	TATA spare parts
273935110162	ASSY. CARRIER HOUSING AND PLUMMER BLOCK	TATA spare parts
273935110163	ASSY CARRIER HOUSING AND PLUMMER BLOCK	TATA spare parts
273935110166	DRIVE HEAD ASSY (31/11) W/IAD BUSH BS6-P	TATA spare parts
273935110167	CARRIER HOUSING ASSY WITH PINION XXX BS6	TATA spare parts
273935113702	INTERMEDIATE HOUSING (FRONT TANDEM)	TATA spare parts
273935113703	DROP GEAR HOUSING (FRONT TANDEM)	TATA spare parts
273935113703AE	DROP GEAR HSG (FRT TANDEM) -1628	TATA spare parts
273935113704	PLUMMER BLOCK COVER (FRT TANDEM AXLE)	TATA spare parts
273935118201	COVER OIL GALLERY (DROP GEAR HOUSING)	TATA spare parts
273935118801	STUD BM 12X30	TATA spare parts
273935120101	ASSY. OIL PUMP BS1/2/3/4	TATA spare parts
273935120102	ASSY. STRAINER	TATA spare parts
273935123701	OIL PUMP HOUSING	TATA spare parts
273935125301	GASKET (OIL PUMP HSG.)	TATA spare parts
273935125401	OIL PUMP GEAR (DRIVE SHAFT)	TATA spare parts
273935125402	OIL PUMP GEAR (DRIVEN)	TATA spare parts

273935125402AE	OIL PUMP GEAR (DRIVEN) 1628	TATA spare parts
273935126701	PIN (DRIVEN GEAR)	TATA spare parts
273935126701AE	PIN (DRIVEN GEAR) 1628	TATA spare parts
273935126702	PIN (DRIVING GEAR - PINION AXIS)	TATA spare parts
273935127101	COVER (OIL PUMP)	TATA spare parts
273935127101AE	COVER (OIL PUMP) 1628	TATA spare parts
273935128701	COMPRESSION SPRING (OIL PUMP)	TATA spare parts
273935300105	ASSY INTERAXLE DIFFERENTIAL HOUSING.	TATA spare parts
273935300110	ASSY. COUPLING FLANGE (INPUT SHAFT)	TATA spare parts
273935300110AE	ASSY.COUPLING FLNGE(IN SFT)-1628	TATA spare parts
273935300111	ASSY. COUPLING FLANGE (THROUGH SHAFT)	TATA spare parts
273935300111AE	ASSY COPLING FLNGE THRU SFT-1628	TATA spare parts
273935300115	DIFFERENTIAL HOUSING ASSY.(DIFF. LOCK)	TATA spare parts
273935300118	ASSY CW & PINION (29/17) OER-SPIROFLEX.	TATA spare parts
273935300124	ASSY CROWN & PINION 28/15 OER-SPIROFLEX(	TATA spare parts
273935300124AE	ASSY CWP 28/15(RH) -1628-1828	TATA spare parts
273935300129	ASSY.DROP GEAR HSG.& INTERMEDIATE HSG.	TATA spare parts
273935300130	ASSY COUPLING FLANGE (150 OD)	TATA spare parts
273935300132	ASSY CW & PINION 30/17 OER-SPIRO	TATA spare parts
273935300143	ASSY DIFFERENTIAL COMP 25/12 SPIRO	TATA spare parts
273935300144	ASSY CROWN WHEEL & PINION 25/12	TATA spare parts
273935300146	ASSY.COUPLING FLANGE T-150 DIA (INPUT SH	TATA spare parts
273935300171	ASSY CROWN WHEEL & PINION 31/11 SPIRO	TATA spare parts
273935303401	BUSH (I/P SHAFT)	TATA spare parts
273935303402	BUSH (O/P SHAFT)	TATA spare parts
273935303404	BUSH INPUT SHAFT	TATA spare parts
273935303405	BUSH OUTPUT SHAFT	TATA spare parts
273935303408	BUSH INPUT SHAFT	TATA spare parts
273935303409	BUSH OUTPUT SHAFT	TATA spare parts
273935305001	COUPLING FLANGE (INPUT SHAFT)	TATA spare parts
273935305101	SPIDER (INTERAXLE DIFFERENTIAL)	TATA spare parts
273935305101AE	SPIDER (INTERAXLE DIFF)-1628	TATA spare parts
273935305102	INTERAXLE DIFFERENTIAL CASE	TATA spare parts
273935305103	INTERAXLE DIFFERENTIAL COVER	TATA spare parts
273935305104	COVER (DROP GEAR HOUSING)	TATA spare parts
273935305401	HELICAL GEAR (INPUT AXIS) 36/36	TATA spare parts
273935305401AE	HELICAL GR (INPUT AXIS)-1628	TATA spare parts
273935305402	HELICAL GEAR (PINION AXIS -FRONT TANDEM)	TATA spare parts
273935305402AE	HELICAL GR (PN AXIS-F TNDM)-1628	TATA spare parts
273935305403	SHAFT GEAR (INPUT AXIS INTERAXLE DIFF)	TATA spare parts
273935305403AE	SFT GR(IN AXIS INAXLE DIFF)-1628	TATA spare parts
273935305404	SHAFT GEAR (THRO SHAFT-INTERAXLE DIFF)	TATA spare parts
273935305404AE	SFT GR(THRO SFT-INTAX DIFF)-1628	TATA spare parts
273935305413	HELICAL GEAR INPUT AXIS (34/38)	TATA spare parts
273935305414	HELICAL GEAR PINION AXIS (34/38)	TATA spare parts
273935305414AE	HELICAL GR PNIN AXIS(34/38)-1628	TATA spare parts
273935305434	SHAFT GEAR INPUT SHAFT MOD. - INTERAXLE	TATA spare parts

273935305435	SHAFT GEAR- OUT PUT SHAFT-MOD. INTERAXLE	TATA spare parts
273935305436	SHAFT GEAR (INPUT AXIS IAD DIFF) FORGED	TATA spare parts
273935305437	SHAFT GEAR(THRO-SHAFT-IAD DIFF) FORGED	TATA spare parts
273935305438	SHAFT GEAR (I/P SHAFT)	TATA spare parts
273935305439	SHAFT GEAR (O/P SHAFT)	TATA spare parts
273935305440	SHAFT GEAR I/P FORGED BUSH	TATA spare parts
273935305441	SHAFT GEAR (O/P) FORGED BUSH	TATA spare parts
273935306101	LOCKING PLATE (THRO'SHAFT THREADED RING)	TATA spare parts
273935306102	LOCKING PLATE (INTERAXLE DIFF. ASSY)	TATA spare parts
273935306501	THREADED RING (THROUGH SHAFT)	TATA spare parts
273935306501AE	THREADED RING (THRO SFT) -1628	TATA spare parts
273935306502	PINION LOCK NUT	TATA spare parts
273935306701	SPECIAL PIN	TATA spare parts
273935306702	DRIVING PIN	TATA spare parts
273935307701	OIL SEAL SINGLE LIP(I/P SFT) BS1/2/3/4/6	TATA spare parts
273935307701AE	OIL SEAL(I/P SFT)-1628-1828	TATA spare parts
273935307702	OIL SEAL OUTER (I/P SHAFT) BS1/2/3/4/6	TATA spare parts
273935307702AE	OIL SEAL OUT(IN SFT-1628-1828	TATA spare parts
273935307703	OUTPUT SHAFT DUST SEAL (MECH FACE SEAL)	TATA spare parts
273935307703AE	OUTPUT SFT DUST SEAL-1628	TATA spare parts
273935307704	DUST SEAL(MECH FACE SEAL)	TATA spare parts
273935307715	OIL SEAL	TATA spare parts
273935307715AE	OIL SEAL 1628 1828	TATA spare parts
273935307717	OIL SEAL (90X110X10.7)	TATA spare parts
273935307718	OIL SEAL (90X110X8)	TATA spare parts
273935307901	INPUT SHAFT (FRONT TANDEM)	TATA spare parts
273935307902	DRIVE INPUT SHAFT 12X12	TATA spare parts
273935307903	INPUT SHAFT (IAD BUSH ARRANGEMENT)	TATA spare parts
273935308002	HEX. BOLT (INTERAXLE DIFF. ASSY.)	TATA spare parts
273935308201	OIL CATCHER (INTERAXLE DIFF. ASSY.)	TATA spare parts
273935308202	THRUST BLOCK (PINION OUTER BEARING)	TATA spare parts
273935308203	DUST COVER (INPUT COUPLING FLANGE)	TATA spare parts
273935308204	DUST COVER -(THRO'SHAFT COUPLING FLANGE)	TATA spare parts
273935308301	SHIM-0.10 THK.(PINION DEPTH SETTING)	TATA spare parts
273935308302	SHIM-0.15 THK.(PINION DEPTH SETTING)	TATA spare parts
273935308303	SHIM-0.20 THK.(PINION DEPTH SETTING)	TATA spare parts
273935308304	SHIM-0.25 THK.(PINION DEPTH SETTING)	TATA spare parts
273935308305	SHIM-0.30 THK.(PINION DEPTH SETTING)	TATA spare parts
273935308306	SHIM-0.50 THK.(PINION DEPTH SETTING)	TATA spare parts
273935308307	SHIM-1.00 THK.(PINION DEPTH SETTING)	TATA spare parts
273935308308	SHIM (INPUT BEARING PRELOAD) - 0.10 THK	TATA spare parts
273935308309	SHIM (INPUT BEARING PRELOAD) - 0.15 THK	TATA spare parts
273935308310	SHIM (INPUT BEARING PRELOAD) - 0.20 THK	TATA spare parts
273935308311	SHIM (INPUT BEARING PRELOAD) - 0.25 THK	TATA spare parts
273935308312	SHIM (INPUT BEARING PRELOAD) - 0.30 THK.	TATA spare parts
273935308313	SHIM (INPUT BEARING PRELOAD) - 0.50 THK	TATA spare parts
273935308314	SHIM (INPUT BEARING PRELOAD) - 1.00 THK	TATA spare parts



273935308315	SHIM (INPUT BEARING PRELOAD) - 1.5 THK	TATA spare parts
273935308601	SPACER-1.00 THK (PINION BRGS.PRELOADING)	TATA spare parts
273935308602	SPACER-1.50 THK.(PINION BRGS.PRELOADING)	TATA spare parts
273935308603	SPACER-1.55 THK.(PINION BRGS.PRELOADING)	TATA spare parts
273935308604	SPACER-1.60 THK.(PINION BRGS.PRELOADING)	TATA spare parts
273935308605	SPACER-1.65 THK.(PINION BRGS.PRELOADING)	TATA spare parts
273935308606	SPACER-1.70 THK.(PINION BRGS.PRELOADING)	TATA spare parts
273935308607	SPACER-1.75 THK.(PINION BRGS.PRELOADING)	TATA spare parts
273935308608	SPACER-1.80 THK.(PINION BRGS.PRELOADING)	TATA spare parts
273935308609	SPACER-1.85 THK.(PINION BRGS.PRELOADING)	TATA spare parts
273935308610	SPACER-1.90 THK.(PINION BRGS.PRELOADING)	TATA spare parts
273935308611	SPACER-1.95 THK.(PINION BRGS.PRELOADING)	TATA spare parts
273935308612	SPACER-2.00 THK.(PINION BRGS.PRELOADING)	TATA spare parts
273935308614	TONGUE WASHER	TATA spare parts
273935309201	THRUST WASHER (SHAFT GEAR) 2.5 THK	TATA spare parts
273935309202	THRUST WASHER (SHAFT GEAR) 2.6 THK	TATA spare parts
273935309203	THRUST WASHER (SHAFT GEAR) 2.7 THK	TATA spare parts
273935309204	THRUST WASHER (SHAFT GEAR) 2.8 THK	TATA spare parts
273935309205	THRUST WASHER (SHAFT GEAR) 2.9 THK	TATA spare parts
273935309206	THRUST WASHER (SHAFT GEAR) 3.0 THK	TATA spare parts
273935309207	THRUST WASHER (SHAFT GEAR) 3.1 THK	TATA spare parts
273935309208	THRUST WASHER (SHAFT GEAR) 3.2 THK	TATA spare parts
273935309209	THRUST WASHER (SHAFT GEAR) 3.3 THK	TATA spare parts
273935309210	THRUST WASHER (SHAFT GEAR) 3.4 THK	TATA spare parts
273935309211	THRUST WASHER (SHAFT GEAR) 3.5 THK	TATA spare parts
273935309212	THRUST WASHER (SHAFT GEAR) 3.6 THK	TATA spare parts
273935309213	THRUST WASHER (SHAFT GEAR) 3.7 THK	TATA spare parts
273935309214	THRUST WASHER (SHAFT GEAR) 3.8 THK	TATA spare parts
273935309215	THRUST WASHER (SHAFT GEAR) 3.9 THK	TATA spare parts
273935309216	THRUST WASHER (SHAFT GEAR) 4.0 THK	TATA spare parts
273935309217	THRUST WASHER SHAFT GEAR 4.05 THK	TATA spare parts
273935309218	THRUST WASHER SHAFT GEAR 4.1 THK	TATA spare parts
273935309219	THRUST WASHER SHAFT GEAR 4.15 THK	TATA spare parts
273935309220	THRUST WASHER SHAFT GEAR 4.2 THK	TATA spare parts
273935309221	THRUST WASHER SHAFT GEAR 4.25 THK	TATA spare parts
273935309222	THRUST WASHER SHAFT GEAR 4.3 THK	TATA spare parts
273935600101	ASSY REAR HUB COMP W/BEARINGS (ABS)	TATA spare parts
273935600102	ASSY REAR HUB W/O BRG AND OIL SEAL	TATA spare parts
273935600103	ASSY REAR HUB COMP W/BEARINGS W/O ABS	TATA spare parts
273935600104	ASSY. REAR HUB W/ BRG & OIL SEAL (ABS)	TATA spare parts
273935600108	ASY REAR HUB COMP W/BRGS(ABS)	TATA spare parts
273935600110	ASSY REAR HUB W/O BRG & OIL SEAL FOR CTI	TATA spare parts
273935601601	OIL SEAL-SINGLE LIP HUB INNER	TATA spare parts
273935605501	REAR HUB (WITH 202 DIA OIL SEAL)	TATA spare parts
273935605502	REAR HUB - FOR CTIS	TATA spare parts
273935605502AE	REAR HUB - FOR CTIS 1628	TATA spare parts
273935606503	HUB LOCK NUT	TATA spare parts

273935607705	OIL SEAL-SINGLE LIP HUB INNER	TATA spare parts
273935607706	OIL SEAL-DOUBLE LIP HUB OUTER	TATA spare parts
273935607707	SCOT SEAL BS3/4	TATA spare parts
273935607708	CTIS SEAL 105X125X12	TATA spare parts
273935607708AE	CTIS SEAL 105X125X12 1628 1828	TATA spare parts
273935608201	OIL CATCHER (FOR ABS BRAKES)	TATA spare parts
273935608601	LOCKING PLATE	TATA spare parts
273935707903	REAR AXLE SHAFT (WITH DIFFLOCK)	TATA spare parts
273935707903AE	RR AXLE SFT(WITH DIFFLOCK) -1628	TATA spare parts
273935707904	REAR AXLE SHAFT	TATA spare parts
273935707904AE	REAR AXLE SHAFT 1628	TATA spare parts
273935707905	REAR AXLE SHAFT(WITH DIFFLOCK)TRACK1900	TATA spare parts
273935707906	REAR AXLE SHAFT (FOR 1900 TRACK)	TATA spare parts
273935903401	BUSH (DIFFLOCK CYLINDER)	TATA spare parts
273935903701	DIFF LOCK CYLINDER	TATA spare parts
273935903701AE	SHIFT CYLINDER HOUSING 1628	TATA spare parts
273935904301	DIFF LOCK CLIP	TATA spare parts
273935904601	ENGAGING SLEEVE (INTERAXLE DIFF LOCK)	TATA spare parts
273935904601AE	ENG SLEEVE(INAXLE DIFF LCK)-1628	TATA spare parts
273935904602	ENGAGING SLEEVE (MAIN DIFF LOCK)	TATA spare parts
273935904602AE	ENGAGING SLEEVE (DIFF LOCK)-1628	TATA spare parts
273935904701	DIFF LOCK COVER	TATA spare parts
273935904702	COVER PLATE-(DIFFLOCK CYLINDER)	TATA spare parts
273935904702AE	COVER PLATE-(DIFFLOCK CYL) -1628	TATA spare parts
273935905101	FORK (INTERAXLE DIFF LOCK)	TATA spare parts
273935905101AE	FORK (INTERAXLE DIFF LOCK) 1628	TATA spare parts
273935905102	SHIFTER FORK (MAIN DIFF. LOCK)	TATA spare parts
273935905102AE	SHFTR K (MAIN DIFF. LOCK) -1628	TATA spare parts
273935905103	BRASS-PAD ( DIFF LOCK FORK)	TATA spare parts
273935905103AE	BRASS-PAD ( DIFF LOCK FORK)-1628	TATA spare parts
273935905401	COVER JAW (MAIN DIFF. LOCK)	TATA spare parts
273935905401AE	COVER JAW (MAIN DIFF. LOCK)-1628	TATA spare parts
273935906601	PISTON(INTERAXLE DIFF. LOCK)	TATA spare parts
273935906601AE	PISTON (INTERAXLE DIFFLOCK)-1628	TATA spare parts
273935906602	PISTON (MAIN DIFFERENTIAL LOCK)	TATA spare parts
273935906602AE	PISTON (MAIN DIFF LOCK) -1628	TATA spare parts
273935906701	PIN (MAIN DIFF LOCK)	TATA spare parts
273935906702	PISTON ROD (INTERAXLE DIFFLOCK)	TATA spare parts
273935908001	SCREW (CENTRAL DIFF LOCK PISTON)	TATA spare parts
273935908601	SPACER (FOR MAIN DIFFLOCK)	TATA spare parts
273935908701	COMPRESSION SPRING(INTERAXLE DIFF. LOCK)	TATA spare parts
273935908703	TORSIONAL SPRING (MAIN DIFFLOCK)	TATA spare parts
2739H9W0135003	REAR FWD AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
2739H9W0135004	REAR RWD AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
274025600101	ASSY.CLUTCH RELEASE FORK WITH BALL PIN	TATA spare parts
274025600102	ASSY.COVER.	TATA spare parts
274025600104	ASSY.HOSE	TATA spare parts

274025600105	ASSY. CLUTCH RELEASE FORK WITH BALL PIN	TATA spare parts
274033100101	SUB ASSY FRONT AXLE COMPONENT SET NORMA	TATA spare parts
274033105102	FRONT AXLE BEAM NORMAL	TATA spare parts
274033200105	ASSY.STUB AXLE WITH BUSH- NORMAL	TATA spare parts
274033203402	STEERING BUSH	TATA spare parts
274033203403	BUSH-STUB AXLE	TATA spare parts
274033800101	ASSY.TIE ROD	TATA spare parts
274033800102	TIE ROD ASSY.	TATA spare parts
274033800103	TIE ROD ASSY.	TATA spare parts
274033800110	TIE ROD ASSY	TATA spare parts
274040106701	HUB BOLT	TATA spare parts
274042103206	HEX.BOLT	TATA spare parts
274042103207	COLLERED PIN	TATA spare parts
274042108201	OIL BAFFLE	TATA spare parts
274191700101	ASSY. MTG. BRACKET (TO SUIT`LCV' SEAT.)	TATA spare parts
274191700102	ASSY.SEAT STAND	TATA spare parts
274260100131	ASSY. CAB COMPLETE (SLEEPER CAB)	TATA spare parts
274260100144	ASSY CAB COMPLETE-RHD-LPT 1313	TATA spare parts
274260100145	ASSY BODY SHELL PAINTED-RHD-LPT 1313	TATA spare parts
274260100165	ASSY CAB COMPLETE -RHD	TATA spare parts
274260100165SJ	ASSY CAB COMPLETE -RHD SPARE PART	TATA spare parts
274260100166	ASSY BODY SHELL PAINTED - RHD	TATA spare parts
274260100173	ASSY COWL COMPL WITH FITMENT	TATA spare parts
274260100174	ASSY COWL SHELL PAINTED	TATA spare parts
274260100186	ASSY CAB COMPLETE	TATA spare parts
274260100186SJ	ASSY. CAB COMP. LPT 1615 SLPR BS1	TATA spare parts
274260100187	ASSY BARE CABIN PAINTED	TATA spare parts
274261108201	FLOOR REINFORCEMENT (AIR FILTER MTG.) BS	TATA spare parts
274261600118	ASSY FLOOR PANEL RH-RHD	TATA spare parts
274264700102	ASSY.CORNER PANEL OUTER W/POST & S/P RH	TATA spare parts
274268400102	ASSY COMPOSITE FLOOR MAT - RHD	TATA spare parts
274269400101	ASSY SIDE WALL PADDING RH	TATA spare parts
274275200101	ASSY. `T'EMBLEM(OVAL STYLISED)	TATA spare parts
274275200102	ASSY`TEMBLEM COMPLETE	TATA spare parts
274275206301	LETTER`T (NEW STYLISED) W/O PLATING	TATA spare parts
274275206302	LETTER`A (NEW STYLISED) W/O PLATING	TATA spare parts
274281105601	GRAB HANDLE(DASH BOARD)	TATA spare parts
274281800103	ASSY TATA 1615 C MASCOT	TATA spare parts
274288500105	ASSY BRACKET -BUMPER SUPPORT	TATA spare parts
274288500106B0	BUMPER; BLACK LPT 1615 TFF	TATA spare parts
274288500109C0	ASSY BUMPER WITH REFLECTOR - BLACK	TATA spare parts
274289100103	ASSY FRONT MTG BRACKET LH	TATA spare parts
274289100104	ASSY.BRACKET LH (REAR MTG.)	TATA spare parts
274289100105	ASSY.BRACKET RH (REAR MTG.)	TATA spare parts
274291000102	ASSY.BOTTOM BERTH	TATA spare parts
274291000103	ASSY TOP BERTH COMPLETE	TATA spare parts
274291700102	ASSY CHAIN(TOP BERTH)	TATA spare parts

274291707501	RUBBER STOPPER(FOR TOP BERTH)	TATA spare parts
274560100114	ASSY.CAB COMPLETE WITH FITMENTS	TATA spare parts
274560100115	ASSY.BODY SHELL PAINTED(BARE CAB)	TATA spare parts
274560100154SJ	ASSY.CAB COMPLETE WITH FITMENTS-RHD	TATA spare parts
274560100155	ASSY.BODY SHELL PAINTED-RHD	TATA spare parts
274560106901	STAY ROD (CENTRE FLAP)	TATA spare parts
274560108224	REINFORCEMENT BKT.LH	TATA spare parts
274560108225	ANGLE REINFORCEMENT	TATA spare parts
274560108228	REINFORCEMENT BKT.RH	TATA spare parts
274560108229	BKT.REINFORCEMENT INNER LH	TATA spare parts
274560108230	BKT.REINFORCEMENT INNER RH	TATA spare parts
274562600102	ASSY.BONNET COMPLETE OF LPTA 1623	TATA spare parts
274565200101	ASSY BRKT(Spring CLAMP/RUBBER PAD MTG.)	TATA spare parts
274565208201	CLIP ROOF HATCH	TATA spare parts
274565208202	STRIKER BRACKET (BUGGET LOCK)	TATA spare parts
274565208203	HINGE BRACKET (ROOF HATCH)	TATA spare parts
274565700109	ASSY RING BOTTOM (ROOF OBSERVATION HATCH)	TATA spare parts
274565707703	RUBBER PACKING BUDGET LOCK	TATA spare parts
274565707704	SEALING-ROOF OBSERVATION HATCH	TATA spare parts
274565707704AE	SEALING-ROOF OBSERVATION HATCH-1628	TATA spare parts
274565707705	LID SEALING-ROOF HATCH	TATA spare parts
274565707705AE	LID SEALING-ROOF HATCH -1628	TATA spare parts
274565707706	LID SEALING M/S PULSAR (ROOF OBS. HATCH)	TATA spare parts
274565707707	TRIM (ROOF OBS. HATCH)	TATA spare parts
274565708203	LID ROOF HATCH	TATA spare parts
274565708205	HANDLE (ROOF OBSERVATION HATCH)	TATA spare parts
274566600101	ASSY FOOT STEP LH	TATA spare parts
274566600102	ASSY FOOT STEP RH	TATA spare parts
274566600108	ASSY FOOT STEP COMPLETE (ROPE TYPE)	TATA spare parts
274568400101	ASSY.COMPOSITE FLOOR MAT	TATA spare parts
274568400103	ASSY.COMPOSITE FLOOR MAT-RHD	TATA spare parts
274569500101	ASSY ROOF LINING	TATA spare parts
274569502001	INSULATION CENTRE FRONT	TATA spare parts
274569502002	INSULATION CENTRE REAR	TATA spare parts
274569502003	INSULATION SIDE FRONT LH	TATA spare parts
274569502005	INSULATION SIDE REAR LH/RH	TATA spare parts
274581800103	ASSY.TATA 1623 6X6 MASCOT	TATA spare parts
274581800106	ASSY 4X4 MASCOT	TATA spare parts
274581900101	ASSY ENGINE SHIELDING RH-RHD	TATA spare parts
274581900102	ASSY ENGINE SHIELDING LH-RHD	TATA spare parts
274583100102	ASSY GUARD (EXHAUST SILENCER)	TATA spare parts
274583800111	KIT FOR HEATER-ARMY	TATA spare parts
274583800112	KIT AT2005T HIGH ALTITUDE	TATA spare parts
274583800130	KIT AIRTOP HEATER 2KW	TATA spare parts
274588106301	MUD FLAP REAR	TATA spare parts
274588108201	COVER MUD FLAP	TATA spare parts
274588500104B0	ASSY.BUMPER COMPLETE	TATA spare parts

274588500108	ASSY PROTECTIVE GRILL (HEAD LAMP)ARMY	TATA spare parts
274588500119	ASSY FOOT STEP (BUMPER)	TATA spare parts
274588506901	FOOT STEP(BUMPER)	TATA spare parts
274589100101	ASSY PIVOT MTG.BRKT LH(CAB MTG FRONT)	TATA spare parts
274589100104	ASSY.STAY COMPLETE	TATA spare parts
274589100106	ASSY METAL PIPE(PUMP TO 3 WAY)	TATA spare parts
274589100107	ASSY.METAL PIPE(3 WAY TO HOSE)	TATA spare parts
274589100108	ASSY.METAL PIPE(PUMP TO HOSE)	TATA spare parts
274589100109	ASSY METAL PIPE(3 WAY TO HOSE)	TATA spare parts
274589100110	ASSY METAL PIPE(HOSE TO 3 WAY)	TATA spare parts
274589100111	ASSY METAL PIPE(3 WAY TO HOSE LHS)	TATA spare parts
274589100112	ASSY METAL PIPE(3 WAY TO HOSE RHS)	TATA spare parts
274589100117	ASSY.BKT.FRONT BOTTOM LH PIVOT MTG.	TATA spare parts
274589100135	ASSY BKT FRONT TOP LH (PIVOT MTG)	TATA spare parts
274589106301	BALATA PACKING - CAB MTG REAR	TATA spare parts
274589200112	ASSY.CYLINDER MTG.BRACKET (BOTTOM)	TATA spare parts
274589200115	ASSY BASE PLATE LOWER (CYL. PIVOT TOP)	TATA spare parts
274589200116	ASSY MTG.BRACKET REAR LH (CAB SUSPENSIO	TATA spare parts
274589200117	ASSY MTG.BRACKET REAR RH (CAB SUSPENSION	TATA spare parts
274589200119	HYD.CYLINDER (CAB TILT)	TATA spare parts
274589200126	ASSY BASE PLATE LOWER(CYL.PIVOT TOP)	TATA spare parts
274589200130	ASSY MTG.BRACKET REAR LH(CAB SUSPENSION)	TATA spare parts
274589200131	ASSY MTG.BRACKET REAR RH(CAB SUSPENSION)	TATA spare parts
274589200132	ASSY BKT.CYLINDER MTG.(BOTTOM)	TATA spare parts
274589206705	PIN(CYL.MTG. ON CAB)	TATA spare parts
274589208205	TIE MEMBER REAR(REAR MTG.)	TATA spare parts
274591000101	ASSY CO-DRIVER SEAT COMPLETE	TATA spare parts
274591700101	ASSY CHAIN (TOP BERTH)	TATA spare parts
274760000102	ASSY BODY SHELL COMPLETE RHD SLPR CAB	TATA spare parts
274760000103	BODY SHELL PAINTED SLPR TILT LPT1613TC	TATA spare parts
274760000104	ASSY.CAB COMPLETE RHD 1613 SLPR TILT CAB	TATA spare parts
274760000121	ASSY.CAB COMPLETE-RHD 2515 SLEEPER	TATA spare parts
274760000123	ASSY.CAB COMPLETE-RHD 3015 SLEEPER TILT	TATA spare parts
274760000132	ASSY BODYSHELL PAINTED-LHD	TATA spare parts
274760000133	ASSY CAB COMPLETE-LHD	TATA spare parts
274760000133SJ	CAB COMPLETE-LHD SPARE PART	TATA spare parts
274760000137	ASSY.CAB COMPLETE-RHD 1613LPT/52	TATA spare parts
274760000138	ASSY.CAB COMPLETE-RHD	TATA spare parts
274760000139	ASSY.CAB COMPLETE-3015TILT PSTG	TATA spare parts
274760000142	ASSY.BODYSHELL PAINTED-RHD-1518	TATA spare parts
274760000145	ASSY. CABIN BARE SLPR TCAB BS2/3	TATA spare parts
274760000149	ASSY.CAB COMPLETE (SLPR.)2515TCE II	TATA spare parts
274760000150	ASSY.CAB PAINTED SLPR LPT2515TC E-II	TATA spare parts
274760000153	ASSY CAB COMPLETE-RHD	TATA spare parts
274760000153SJ	ASSY CAB COMPLETE-RHD LPT 1613 TC-SPARE	TATA spare parts
274760000154	ASSY CAB COMP. NON SLEEPER LPK 1613 TILT	TATA spare parts
274760000155	ASSY.BODYSHELL PAINTED NON S/L LPK 1613	TATA spare parts

274760000158	ASSY.CAB COMPLETE-RHD 1518	TATA spare parts
274760000159	ASSY.CAB COMPLETE-RHD (SLPR.CAB)	TATA spare parts
274760000161SJ	ASSY.CAB COMPLETE-RHD(SPARE CAB)	TATA spare parts
274760000165	ASSY.CAB COMPLETE (SLPR.)2515TCIC BSII	TATA spare parts
274760000166	ASSY CAB COMPLETE-RHD	TATA spare parts
274760000166SJ	ASSY CAB COMPLETE-RHD SPARE LPT 2518	TATA spare parts
274760000167SJ	ASSY CAB COMPLETE-RHD	TATA spare parts
274760000168	ASSY CAB COMPLETE-RHD 1613	TATA spare parts
274760000169	ASSY CAB COMPLETE-RHD 2518 TC TILT CAB	TATA spare parts
274760000170	ASSY CAB COMPLETE-RHD 1618 N/SLP TILT	TATA spare parts
274760000171	ASSY BODYSHELL PAINTED-RHD 1618	TATA spare parts
274760000174	ASSY. CAB COMPLETE RHD NON SLEEPER	TATA spare parts
274760000176	ASSY CAB COMPLETE-RHD SLPR.CAB (W/HTING)	TATA spare parts
274760000177	ASSY CAB PAINTED-RHD 1518 SLPR.CAB(W/H)	TATA spare parts
274760000178	ASSY BODYSHELL COMPL-RHD SLPR.CAB (1518)	TATA spare parts
274760000184	BODY SHELL ASSY PAINTED	TATA spare parts
27476000Z132	ASSY BODYSHELL PAINTED	TATA spare parts
27476000Z158	ASSY.CAB COMPLETE 1518 NON SLPR NORMAL C	TATA spare parts
274760010104	ASSY.CAB COMPLETE-RHD (SLPR.CAB)	TATA spare parts
274760010104SJ	ASSY. CAB WITH FITMENT 3118 SLP TCAB BS2	TATA spare parts
274760010105	ASSY CAB COMPLETE-RHD NON-SLEEPER TILT C	TATA spare parts
274760010105SJ	CAB COMPLETE-RHD_SPARE PARTS	TATA spare parts
274760010106	ASSY CAB COMPLETE-RHD (SLPR CAB W/HTNG.)	TATA spare parts
274760010114	ASSY BODYSHELL PAINTED-LHD	TATA spare parts
274760010117	ASSY CAB COMPLETE-LHD	TATA spare parts
274760010117SJ	ASSY CAB COMPLETE-LHD SPARE PARTS	TATA spare parts
274760010126	ASSY CAB COMPLETE-RHD 2516 SLP TILT	TATA spare parts
274760010145SJ	ASSY.CAB COMPL-LHD (SLP CAB W/HTG-E3-RU)	TATA spare parts
274760010146	ASSY.BODYSHELL PAINTED LHD-SLP.W/HTG.E-3	TATA spare parts
274760010153	ASSY.CAB COMPLETE-RHD	TATA spare parts
274760010153SJ	ASSY.CAB COMPLETE-RHD SPARE PARTS	TATA spare parts
274760010154	ASSY.CAB COMPLETE-RHD	TATA spare parts
274760010154CK	CAB COMPL.-RHD(2523-MECH.SUS.SEAT)	TATA spare parts
274760010154SJ	ASSY.CAB COMPLETE-RHD SPARE PARTS	TATA spare parts
274760010155	ASSY. CABIN BARE LPT 3118 SLP TCAB BS2/3	TATA spare parts
274760010156	ASSY.BODYSHELL COMPLETE-RHD	TATA spare parts
274760010170	ASSY. CAB COMP. W/O FITMENTS LPK2523 NSL	TATA spare parts
274760010170SJ	ASSY. CAB COMP. LPK2523 RHD SP BS2	TATA spare parts
274760010171	COWL PAINTED-RHD	TATA spare parts
274760010173	ASSY.CAB COMPL. LPK2523 NSLPR-LHD	TATA spare parts
274760010174	ASSY.BODYSHELL PAINTED LPK2523 N SLPR LH	TATA spare parts
274760010175	ASSY.BODYSHELL COMPLETE-LHD	TATA spare parts
274760010189	ASSY.CAB COMPL.-RHD(1918-MECH.SUS.SEAT)	TATA spare parts
274760010190SJ	CAB COMPLETE RHD 1518 LPT SPARE PART	TATA spare parts
274760010192	ASSY.CAB COMP-RHD 1518 LPT EX2 SLPR	TATA spare parts
274760010198	ASSY.BODYSHELL PAINTED-RHD (LPT2523 SLP)	TATA spare parts
27476001Z130	ASSY BODY SHELL PAINTED-LHD COATED	TATA spare parts

27476001Z131	ASSY CAB COMPLT-LHD_ MIDDLE EAST_ CTD	TATA spare parts
27476001Z131SJ	ASSY CAB COMPLT-LHD	TATA spare parts
274760020101SJ	ASSY.CAB COM-RHD (LPT1613 SLP.BSIV)SPARE	TATA spare parts
274760020102	ASSY.BODYSHELL PAINTED-RHD(LPT1613 BSIV)	TATA spare parts
274760020106	BODYSHELL PAINTED-RHD(LPT2521-BSIV)	TATA spare parts
274760020128SJ	ASSY.CAB COMPLETE-LHD	TATA spare parts
274760020140	ASSY.BODYSHELL PAINTED-RHD	TATA spare parts
274760020150	ASSY.BODYSHELL PAINTED-RHD	TATA spare parts
274760020150CJO	ASSY.CAB FITTED	TATA spare parts
274760020159	ASSY.BODYSHELL PAINTED-RHD	TATA spare parts
274760020165SJ	ASSY. CAB WITH FITMENTS LPT1613 TCAB BS3	TATA spare parts
274760020170	ASSY.CAB COMPT-RHD_ LPT1613 SLP.BSIV_ ERGO	TATA spare parts
274760020173	CAB COMPLETE-RHD ERGO	TATA spare parts
274760020175	CAB COMPLETE-RHD (SLPR.CAB)ERGO	TATA spare parts
274760020176	ASSY.CAB COMPT-RHD (LPT2521 SLP-BS4)ERGO	TATA spare parts
274760020192	ASSY. CABIN BARE SLPR TCAB BLW BS4	TATA spare parts
274760020194	CAB ASSY	TATA spare parts
274760020195	BODY ASSY PAINTED	TATA spare parts
27476002Z121	BARE CAB PAINTED-RHD(FOR COATED SHTS)	TATA spare parts
27476002Z124	COWLSHELL PAINTED-RHD(SLPR) (FOR COATED	TATA spare parts
27476002Z141	ASSY.CAB COMP-RHD(1618 E-II NON AC)	TATA spare parts
27476002Z142	ASSY BODYSHELL PAINTED-RHD	TATA spare parts
27476002Z145	ASSY CAB COMPLETE-RHD (FOR COATED SHEETS	TATA spare parts
27476002Z145SJ	ASSY CAB COMPLETE-RHD SPARE PART	TATA spare parts
27476002Z146	ASSY BODYSHELL PAINTED-RHD (FOR COATED S	TATA spare parts
27476002Z157	ASSY CAB COMP RHD1518HTGMECSUS.CTD_ ERGO	TATA spare parts
27476002Z173CK	ASSY.CAB COMP-LPT1623TC RHD NS TILT ERGO	TATA spare parts
274760100101	ASSY.PANEL CORNER BOTTOM-LH	TATA spare parts
274760100102	ASSY.PANEL CORNER BOTTOM-RH	TATA spare parts
274760100103	ASSY SUPPORT FRONT GRILL	TATA spare parts
274760100105	ASSY.PANEL OUTER W/S BOTTOM	TATA spare parts
274760100106	ASSY.CROSS MEMBER-RHD (DASHBOARD)	TATA spare parts
274760100107	ASSY.PANEL INNER TOP BS6	TATA spare parts
274760100109	ASSY.INNER PANEL & FIREWALL-RHD	TATA spare parts
274760100118	ASSY.PANEL OUTER CORNER FRONT-LH	TATA spare parts
274760100119	ASSY.PANEL OUTER CORNER FRONT-RH	TATA spare parts
274760100120	PANEL OUTER CORNER FRT LH	TATA spare parts
274760100121	PANEL OUTER CORNER FRT RH	TATA spare parts
274760100122	SUPPORT ASSYBS6	TATA spare parts
274760100133	ASSY.REINFORCEMENT (STEERING COLUMN)	TATA spare parts
274760100134	ASSY.SUPPORT TUBE (DASH CROSS MEMBER)	TATA spare parts
274760100146	ASSY.PANEL INNER TOP WITH REINFORCEMENT	TATA spare parts
274760100147	ASSY INNER PANEL & FIREWALL -RHD	TATA spare parts
274760100152	ASSY PANEL OUTER CORNER FRONT-LH	TATA spare parts
274760100153	ASSY PANEL OUTER CORNER FRONT-RH	TATA spare parts
274760100155	ASSY CORNER PANEL BOTTOM -LH	TATA spare parts
274760100156	ASSY PANEL CORNER BOTTOM -RH	TATA spare parts

274760100162	ASSY.SUPPORT FRONT GRILL COMPLETE	TATA spare parts
274760106302	MEL SHEET (FLOOR SIDE RH) BS6	TATA spare parts
274760106305	CAP (FOR M10 BOLT) BS6	TATA spare parts
274760106308	WASHER	TATA spare parts
274760108215	ROOF BOW BS6-PH2	TATA spare parts
274760108232	CONNECTOR (FIREWALL TO SUBST.LONGMEMBER)	TATA spare parts
274760108235	SHIM (CROSS MEMBER SUPPORT) BS6	TATA spare parts
274760108240	COVER TOP-LH (DOOR POST FRONT)	TATA spare parts
274760108241	COVER TOP-RH (DOOR POST FRONT)	TATA spare parts
274760108254	SUPPORT CENTRE	TATA spare parts
274760108256	SUPPORT ANGLE	TATA spare parts
274760108263	SUPPORT FRONT (GRILL)	TATA spare parts
27476010Z147	ASSY INNER PANEL & FIREWALL -RHD (FOR CO	TATA spare parts
274761000114	ASSY.SUB-STRUCTURE WITH FLOOR	TATA spare parts
274761000115	ASSY.SUB-STRUCTURE W/O FLOOR	TATA spare parts
274761010108	SUBSTRUCTURE ASSY WITH FLOOR BS6	TATA spare parts
274761010111	SUBSTRUCTURE ASSY WITH FLOOR BS6	TATA spare parts
274761100109	ASSY.PLATE TOP-LH-CAB MTG.REAR	TATA spare parts
274761100110	ASSY.PLATE TOP-RH-CAB MTG.REAR	TATA spare parts
274761100111	ASSY.HORIZONTAL REINFORCEMENT BS6	TATA spare parts
274761108201	REINFORCEMENT FLOOR LH BS6	TATA spare parts
274761108202	REINFORCEMENT FLOOR RH BS6	TATA spare parts
274761108213	GUSSET-LH (VERTICAL FLOOR) BS6	TATA spare parts
274761108214	GUSSET-RH (VERTICAL FLOOR) BS6	TATA spare parts
274761108221	GUSSET REAR-LH (VERTICAL FLOOR) BS6	TATA spare parts
274761108222	GUSSET REAR-RH (VERTICAL FLOOR) BS6	TATA spare parts
274761108230	REINFORCEMENT-LH RHD	TATA spare parts
274761108231	REINFORCEMENT-RH RHD	TATA spare parts
274761200114	ASSY.REINFORCEMENT BKT. SECONDARY LOCK	TATA spare parts
274761208232	REINFORCEMENT VERTICAL RR-LH (RR SUSPN)	TATA spare parts
274761208233	REINFORCEMENT VERTICAL RR-RH (RR SUSPN)	TATA spare parts
274761208236	GUSSET REAR SUSPENSION -LH	TATA spare parts
274761208237	GUSSET REAR SUSPENSION-RH	TATA spare parts
274761600104	ASSY.SIDE FLOOR-LH	TATA spare parts
274761600105	ASSY.SIDE FLOOR-RH	TATA spare parts
274761600107	ASSY.FLOOR MIDDLE FRONT WITH `T CLIPS	TATA spare parts
274761600110	ASSY.FLOOR PANEL SIDE-RH	TATA spare parts
274761600111	ASSY.FLOOR REAR	TATA spare parts
274761600112	ASSY.CORNER PANEL INNER BOTTOM-LH	TATA spare parts
274761600113	ASSY.CORNER PANEL INNER BOTTOM-RH	TATA spare parts
274761600114	ASSY.FLOOR PANEL SIDE-LH	TATA spare parts
274761600116	ASSY.FLOOR PANEL (REAR VERTICAL)	TATA spare parts
274761600117	ASSY STEP PANEL INNER-LH BS6	TATA spare parts
274761600118	ASSY STEP PANEL INNER-RH BS6	TATA spare parts
274761600131	ASSY.NUTPLATE (FLOOR MIDDLE FRONT) BS6	TATA spare parts
274761600145	ASSY FLOOR PANEL (REAR VERTICAL) BS6	TATA spare parts
274761608223	FLOOR	TATA spare parts



274762600102	ASSY.FIREWALL COMPLETE-RHD	TATA spare parts
274762600107	ASSY.MTG.BKT.(STEERING COLUMN)	TATA spare parts
274762600108	ASSY.FIREWALL COMPLETE-LHD	TATA spare parts
274762608207	REINFORCEMENT (FIREWALL) BS6	TATA spare parts
274763000101	ASSY.SIDEWALL COMPLETE-LH	TATA spare parts
274763000102	ASSY.SIDEWALL COMPLETE-RH	TATA spare parts
274763000103	ASSY.SIDEWALL-LH	TATA spare parts
274763000104	ASSY.SIDEWALL-RH	TATA spare parts
274763000105	ASSY.SIDEWALL COMPLETE-LH (LHD)	TATA spare parts
274763000106	ASSY.SIDEWALL COMPLETE-RH (LHD)	TATA spare parts
274763000116	SIDE WALL ASSY LH BS6	TATA spare parts
274763000118	SIDE WALL ASSY RH BS6	TATA spare parts
27476300Z108	ASSY.SIDEWALL COMPLETE-LH (LHD ( FOR COA	TATA spare parts
27476300Z112	ASSY.SIDEWALL COMPLETE-RH (LHD)(FOR COAT	TATA spare parts
274763100109	ASSY.MTG.BKT.(FRONT CORNER PANEL)-LH BS6	TATA spare parts
274763100110	ASSY.MTG.BKT.(FRONT CORNER PANEL)-RHBS6	TATA spare parts
274763100126	ASSY.STEP PANEL OUTER-LH	TATA spare parts
274763100127	ASSY.STEP PANEL OUTER-RH	TATA spare parts
274763100130	ASSY.DOOR POST REAR-LH	TATA spare parts
274763100131	ASSY.DOOR POST REAR-RH	TATA spare parts
274763100132	ASSY.PANEL OUTER CORNER RR.TOP COMP.LH	TATA spare parts
274763100133	ASSY.PANEL OUTER CORNER RR.TOP COMP.RH	TATA spare parts
274763100134	ASSY.SIDEWALL OUTER-LH	TATA spare parts
27476310013435	ASSY.SIDE WALL LH + CED + SEALANT	TATA spare parts
274763100135	ASSY.SIDEWALL OUTER-RH	TATA spare parts
27476310013535	ASSY.SIDE WALL RH + CED + SEALANT	TATA spare parts
274763100142	ASSY.OUTER PANEL WELDED-LH	TATA spare parts
274763100143	ASSY.OUTER PANEL WELDED-RH	TATA spare parts
274763100144	ASSY.SIDEWALL OUTER-LH	TATA spare parts
274763100145	ASSY.SIDEWALL OUTER-RH	TATA spare parts
274763100150	ASSY.DOORPOST FRONT COMPLETE-LH	TATA spare parts
274763100151	ASSY.DOOR POST FRONT COMPLETE-RH	TATA spare parts
274763108213	SUPPORT-LH-PANEL OUTER REAR	TATA spare parts
274763108214	SUPPORT-RH-PANEL OUTER REAR	TATA spare parts
274763108215	DOOR POST (REAR)-LH	TATA spare parts
274763108216	DOOR POST (REAR)-RH	TATA spare parts
274763108254	REINFORCEMENT BS6-PH2	TATA spare parts
274763108256	BOXING PLATE TOP-LH BS6-PH2	TATA spare parts
274763108257	BOXING PLATE TOP-RH BS6-PH2	TATA spare parts
274763108262	FENDER MTG.BKT.(NON-SLPR)	TATA spare parts
274763600105	ASSY.PANEL INNER W/S SIDE-LH	TATA spare parts
274763600106	ASSY.PANEL INNER W/S SIDE-RH	TATA spare parts
274763600107	ASSY.PANEL INNER CORNER REAR-LH	TATA spare parts
274763600108	ASSY.PANEL INNER CORNER REAR-RH	TATA spare parts
274763600109	ASSY.PANEL INNER CORNER REAR-LH	TATA spare parts
274763600110	ASSY.PANEL INNER CORNER REAR-RH	TATA spare parts
274763600144	ASSY.PANEL INNER POST SIDE-LH-RHD	TATA spare parts

274763608203	RAIN CHANNEL EXTENSION-LH	TATA spare parts
274763608204	RAIN CHANNEL EXTENSION-RH	TATA spare parts
274763608219	GUSSET FRT LH	TATA spare parts
274763608220	GUSSET FRT LH	TATA spare parts
274763708205	PANEL OUTER CORNER REAR TOP -LH	TATA spare parts
274763708206	PANEL OUTER CORNER REAR TOP-RH	TATA spare parts
274763708209	PANEL SIDE OUTER EXTENSION-LH	TATA spare parts
274763708210	PANEL SIDE OUTER EXTENSION-RH	TATA spare parts
274763708214	PANEL OUTER REAR-LH	TATA spare parts
274763708215	PANEL OUTER REAR-RH	TATA spare parts
274763708216	PANEL SIDE OUTER EXTENSION-LH	TATA spare parts
274763708217	PANEL SIDE OUTER EXTENSION-RH	TATA spare parts
274764208204	SUPPORT REAR WALL BS6-PH2	TATA spare parts
274764600102	ASSY.BKT.-HINGE BODY SIDE TOP BS6-PH2	TATA spare parts
274764700103	ASSY.REARWALL-SLEEPER	TATA spare parts
274764700106	ASSY.REARWALL (NON-SLEEPER W/O CLIP)	TATA spare parts
274764700107	ASSY.REARWALL-SLEEPER CAB W/O CLIP	TATA spare parts
274764708204	CENTER PANEL REAR WALL BS6-PH2	TATA spare parts
274765100105	ASSY.ROOF	TATA spare parts
274765100106	ROOF BOW ASSY MIDDLE BS6-PH2	TATA spare parts
274765700103	ASSY.ROOF PANEL-RHD	TATA spare parts
274765708208	ROOF PANEL	TATA spare parts
274766600101	ASSY.STEPWELL-L.H.	TATA spare parts
274766600102	ASSY.STEPWELL-R.H.	TATA spare parts
274766600108	ASSY STEPWELL-LH	TATA spare parts
274766600109	ASSY STEPWELL-RH	TATA spare parts
274766600110	ASSY STEPWELL-LH	TATA spare parts
274766600111	ASSY STEPWELL-RH	TATA spare parts
274766608207	STEP BOARD	TATA spare parts
27476660820735	STEPBOARD_UNPAINTED	TATA spare parts
274766608208	STEP BOARD BOTTOM	TATA spare parts
274766608210	BRACKET UPPER-LH (STEP BOARD MTG.)	TATA spare parts
274766608213	BKT FRONT-LH (STEP BOARD MTG-TOP)	TATA spare parts
274766608214	BKT FRONT-RH (STEP BOARD MTG-TOP)	TATA spare parts
274766608215	BRACKET UPPER-RH (STEP BOARD MTG)	TATA spare parts
274766610108	ASSY.STEP COMPLETE-BUMPER	TATA spare parts
274766619001	CLAMP (BUMPER STEP MTG)	TATA spare parts
274767102301	WINDSHIELD GLASS 5.7THK E-CERT BS1/2/3/4	TATA spare parts
274767102301AE	WINDSHLD GLSS -E' CERTIFIED-2523	TATA spare parts
274767300103	ASSY.SIDE WINDOW COMPLETE-LH	TATA spare parts
274767300103AE	ASSY.SIDE WINDOW COMPL.-LH -2523	TATA spare parts
274767300104	ASSY.SIDE WINDOW COMPLETE-RH	TATA spare parts
274767300104AE	ASSY.SIDE WINDOW COMPL.-RH -2523	TATA spare parts
274767300105	ASSY.FIXED SIDE WINDOW (A.C)	TATA spare parts
274767300107	ASSY.SIDE WINDOW COMPLETE-LH	TATA spare parts
274767300108	ASSY.SIDE WINDOW COMPLETE-RH	TATA spare parts
274767806301	RUBBER MOULD (REAR WINDOW)	TATA spare parts

274768400101	FLOOR MAT SET-RHD-SLEEPER	TATA spare parts
274768400111	CARPET FELT KIT-LHD (A.C.)	TATA spare parts
274768400116	GEAR COVER FLAP	TATA spare parts
274768400118	ASSY PVC FLOOR MAT-RHD	TATA spare parts
274768400119	ASSY PVC FLOOR MAT-LHD	TATA spare parts
274768406304	FLOOR MAT LH	TATA spare parts
274768406305	FLOOR MAT MIDDLE	TATA spare parts
274768406314	FLOOR MAT SIDE LH	TATA spare parts
274768406316	FLOOR MAT SIDE RH	TATA spare parts
274768406318	FLOOR MAT MIDDLE	TATA spare parts
274768406321	FLOOR MAT SIDE RH	TATA spare parts
274768406329	FLOOR MAT MIDDLE	TATA spare parts
274768406331	FLOOR MAT MIDDLE BS6	TATA spare parts
274768406332	FLOOR MAT LH BS6	TATA spare parts
274768406334	FLOOR MAT RH BS6	TATA spare parts
274768406335	FLOOR MAT RHBS6	TATA spare parts
274768406336	FLOOR MAT ASSY RH BS6	TATA spare parts
274768406339	FLOOR MAT LH BS6	TATA spare parts
274768406340	FLOOR MAT MIDDLE BS6	TATA spare parts
274768406341	FLOOR MAT MIDDLE BS6	TATA spare parts
274768406342	FLOOR MAT CENTER BS6-PH2	TATA spare parts
274768406343	FLOOR MAT LH BS6-PH2	TATA spare parts
274768406344	FLOOR MAT RH BS6-PH2	TATA spare parts
274768406345	FLOOR MAT RH BS6-PH2	TATA spare parts
274768406346	NOISE INSULATION FRONT-LH BS6-PH2	TATA spare parts
274768406347	NOISE INSULATION FRONT-RH BS6-PH2	TATA spare parts
274768406350	FLOOR MAT CENTER BS6-PH2	TATA spare parts
274768406351	FLOOR MAT CENTER	TATA spare parts
274768706301	INSULATION TUNNEL	TATA spare parts
274768706302	INSULATION TUNNEL BS6	TATA spare parts
274768706303	INSULATION TUNNEL BS6	TATA spare parts
274768706305	INSULATION TUNNEL BS6	TATA spare parts
274768706306	INSULATION TUNNEL BS6-PH2	TATA spare parts
274768900101	ASSY.KIT FOR NACELLE.	TATA spare parts
274768900102	ASSY.BAZEL-INDICATOR BANK	TATA spare parts
274768900103	ASSY.DASH BOARD COMPLETE RHD	TATA spare parts
274768900104	ASSY.BAZEL INDICATOR BANK	TATA spare parts
274768900105	ASSY.BAZEL INDICATOR BANK	TATA spare parts
274768900107	NACELLE ASSY BS6	TATA spare parts
274768900112	ASSY.BAZEL INDICATOR BANK (GREY PIGMNTD)	TATA spare parts
274768900117	ASSY.DASHBOARD CENTRE ATTACHMENT-(GREY)	TATA spare parts
274768900118	ASSY DASHBOARD COMPLETE-RHD	TATA spare parts
274768900120	NACELLE ASSY BS6	TATA spare parts
274768900122	ASSY KIT FOR NACELLE (GREY)	TATA spare parts
274768900137	ASSY ECU & CONTROL COVER MTG BKT BS6	TATA spare parts
274768900138	ASSY ECU COVER MTG BKT ON PANEL INNER PO	TATA spare parts
274768900139	ASSY D.B.RH RHD WITH CRASH PADS	TATA spare parts

274768900143	DASHBOARD ASSY WITH CRASH PAD RH	TATA spare parts
274768906301	DASHBOARD-RH-RHD	TATA spare parts
274768906307	DASHBOARD -RH (RHD) (GREY PIGMENTED)	TATA spare parts
274768906309	DASHBOARD CENTRE CUTOOUT (GREY)	TATA spare parts
274768906310	DASHBOARD-LH (LHD)	TATA spare parts
274768906315	DASHBOARD RH (SOFT FEEL)	TATA spare parts
274768906318	NACELLE FRONT BS6	TATA spare parts
274768906319	NACELLE REAR BS6	TATA spare parts
274768906320	NACELLE REAR BS6-PH2	TATA spare parts
274768906321	NACELLE UPPER BS6-PH2	TATA spare parts
274768906322	GAP HIDER BS6-PH2	TATA spare parts
274768906349	NACELLE_FRONT	TATA spare parts
274768906350	NACELLE_REAR	TATA spare parts
274768906351	BAZZLE RH RHD(SW CARRIER PLATE MTG)	TATA spare parts
274768906353	COVER CONTROL PADELS RH RHD	TATA spare parts
274768906354	COVER LH(DASHBOARD ECU & FUSE BOX)	TATA spare parts
274768906391	PLUG BUTTON(D'BOARD)	TATA spare parts
274768908201	BKT.INNER-DEFROST DUCT MTG	TATA spare parts
274768908202	BKT.OUTTER-DEFROST DUCT MTG	TATA spare parts
274768908205	REINFORCEMENT-FRONT-DASHBOARD	TATA spare parts
274768908206	INSTRUMENT PANEL	TATA spare parts
274769000101	ASSY.KIT FOR ROOF AND SIDE LINNING	TATA spare parts
274769000104	ASSY.KIT FOR ROOF AND SIDE LINNING	TATA spare parts
274769100105	ASSY KIT FOR INSULTN.(FLR-MID)ENG.SD-LHD	TATA spare parts
274769100106	ASSY KIT FOR INSLTN.(FLR-MID)ENG.SD-RHD	TATA spare parts
274769106301	INSULATION MIDDLE FRONT	TATA spare parts
274769106302	INSULATION FRONT SIDE	TATA spare parts
274769106304	INSULATION MIDDLE REAR-RHD	TATA spare parts
274769106305	INSULATION REAR SIDE	TATA spare parts
274769106307	FIREWALL INSULATION-A.C (RHD)	TATA spare parts
274769106321	MOULDED A PILLAR LINING-LH	TATA spare parts
274769106322	MOULDED A PILLAR LINNING-RH	TATA spare parts
274769106323	INSULATION FIREWALL INNER-LHD (RUSS) E-3	TATA spare parts
274769106324	INSULATION FIREWALL-OUTER LHD (RUSS) E-3	TATA spare parts
274769106327	INSULATION (BS-4 )-RHD	TATA spare parts
274769406301	REAR WALL LINING BS6-PH2	TATA spare parts
274769500101	ASSY.ROOF & SIDE LINNG.WITH BOWS & TUBE	TATA spare parts
274769506302	MOULDED ROOF LINING (HCV-SLEEPER CAB)	TATA spare parts
274769506303	MOULDED ROOF LINING (HCV-NON SLPR CAB)	TATA spare parts
274769506304	MOULDEDROOFLININGASSY BS6	TATA spare parts
274769506306	MOULDED ROOF LINING BS6-PH2	TATA spare parts
274770000102	ASSY.LOADBODY-HIGH DECK	TATA spare parts
274770100101	ASSY SUPD-LH	TATA spare parts
274770100102	ASSY SUPD-RH	TATA spare parts
274770108201	MOUNTING BRACKET (SUPD)	TATA spare parts
274770108202	MOUNTING BRACKET (SUPD)	TATA spare parts
274770108203	MOUNTING PLATE (SUPD)	TATA spare parts

274772200102	ASSY.MTG.BRACKET-L.H-PROXIMITY MIRROR	TATA spare parts
274772200103	ASSY.DOOR SHELL-LH	TATA spare parts
274772200104	ASSY MTG BKT-RH (LHD) (PROXIMITY MIRROR)	TATA spare parts
274772200105	ASSY DOOR SHELL-RH (LHD)	TATA spare parts
27477220Z103	ASSY.DOOR SHELL LH(FOR COATED SHEETS)	TATA spare parts
27477220Z105	ASSY DOOR SHELL-RH (LHD)	TATA spare parts
274772300102	ASSY. SEALING INNER LH	TATA spare parts
274772300103	ASSY. SEALING INNER RH	TATA spare parts
274772306301	MAGAZINE POCKET LH BS6	TATA spare parts
274772306302	MAGAZINE POCKET RH BS6	TATA spare parts
274772306303	MAGAZINE POCKET LH	TATA spare parts
274772306304	MAGAZINE POCKET RH	TATA spare parts
274772502301	REGULATING GLASS -LH BS1/2/3/4/6	TATA spare parts
274772502301AE	REGLTR GLSS L(E' CERTIFIED)-2523	TATA spare parts
274772502302	REGULATING GLASS-RH BS1/2/3/4	TATA spare parts
274772502302AE	REGLTR GLSS R(E' CERTIFIED)-2523	TATA spare parts
274772502501	VELVET CHANNEL	TATA spare parts
274775200101	ASSY.RELEASE CABLE-SECONDARY LOCK	TATA spare parts
274781100101	ASSY.FRAME COMPLETE-LH	TATA spare parts
274781100102	ASSY.FRAME COMPLETE-RH	TATA spare parts
274781100107	ASSY.GRAB HANDLE	TATA spare parts
274781100108	ASSY. COVER LH-PANEL CORNER FRT BS1- 4	TATA spare parts
274781100109	ASSY.COVER-RH-PANEL OUTER CORNER FRONT	TATA spare parts
274781100111	ASSY.BKT.INNER-HEAD BOX MTG	TATA spare parts
274781100112	ASSY.BKT.OUTER-HEAD BOX MTG	TATA spare parts
274781100116	ASSY FRAME COMPLETE RVM	TATA spare parts
274781100119	ASSY. ORVM WIDE ANGLE BS1/2/3/4	TATA spare parts
274781100119AE	ASSY RR VIEW MIRR OUTER -1628	TATA spare parts
274781100128	ASSY.FRAME COMPL.RH (W/RVM)-RHD	TATA spare parts
274781100134	ASSY.REAR VIEW MIRROR KIT FOR HCV-LH RHD	TATA spare parts
274781100135	ASSY.REAR VIEW MIRROR KIT FOR HCV-RH RHD	TATA spare parts
274781100140	ASSY FRAME COMPL.LH-W/RVM & WA	TATA spare parts
274781100144	ASSY FRAME COMPL.RH (W/RVM)-RHD	TATA spare parts
274781100154	ASSY.FRAME COMPL.LH-W/RVM & WA-RHD	TATA spare parts
274781100166	ASSY SELF TAPPING SCR.WITH CAP	TATA spare parts
274781100167	ASSY.FRAME COMPL-LH(W/RVM & WA)-RHD	TATA spare parts
274781100168	ASSY.FRAME COMPL-RH-RHD	TATA spare parts
274781100178	ASSY COVER LH(CENTRE FLAP HINGE)(GREY)	TATA spare parts
274781100179	ASSY COVER RH(CENTRE FLAP HINGE)(GREY)	TATA spare parts
274781100182	ASSY.COVER(GREY)-LH(PANEL OUTER CORNER F	TATA spare parts
274781100183	ASSY.COVER(GREY)-RH(PANEL OUTER CORNER F	TATA spare parts
274781106302	MOULDED LINING REAR	TATA spare parts
274781106305	MOULDED LINING SIDE REAR-LH	TATA spare parts
274781106306	MOULDED LINING SIDE REAR-RH	TATA spare parts
274781106323	COVER REAR MTG-LH	TATA spare parts
274781106324	COVER REAR MTG-RH	TATA spare parts
274781106332	RETRO-REFLECTIVE TAPE	TATA spare parts

274781106333	RETRO-REFLECTIVE TAPE	TATA spare parts
274781106334	RETRO-REFLECTIVE TAPE	TATA spare parts
274781106335	RETRO-REFLECTIVE TAPE-YELLOW 440 LG	TATA spare parts
274781106336	DECAL-LH	TATA spare parts
274781106337	DECAL-RH	TATA spare parts
274781106340	DECAL-LH	TATA spare parts
274781106341	DECAL-RH	TATA spare parts
274781106343	FRONT DECAL_LPT_709	TATA spare parts
274781106351	CAP(BLACK)(FOR FLANGE M8 BOLT) BS6	TATA spare parts
274781106352	MOULDED ROOF LINING	TATA spare parts
274781106363	WHITE REFLEX REFLECTOR	TATA spare parts
274781110105	ASSY COVER ELR UNIT	TATA spare parts
274781110149	KIT-ORVM LH	TATA spare parts
274781110150	KIT-ORVM RH	TATA spare parts
274781110151	FRONT VIEW MIRROR ASSY	TATA spare parts
274781110157	KIT-ORVM LH BS6-PH2	TATA spare parts
274781110158	KIT-ORVM RH BS6-PH2	TATA spare parts
274781400110	ASSY.HEAD BOX COMPLETE	TATA spare parts
274781406304	COAT HANGER	TATA spare parts
274781500101	ASSY GRAB HANDLE-LH	TATA spare parts
274781500102	ASSY GRAB HANDLE-RH	TATA spare parts
274781506301	RUBBER BUSH	TATA spare parts
274781506901	GRAB HANDLE	TATA spare parts
274781506902	GRAB HANDLE (DOOR POST) LH	TATA spare parts
274781506903	GRAB HANDLE (DOOR POST) RH	TATA spare parts
274781506904	GRAB HANDLE	TATA spare parts
274781800106	ASSY TATA 1518 MASCOT	TATA spare parts
274781800112	ASSY.MASCOT TATA 3118	TATA spare parts
274781800130	ASSY MASCOT 'TATA 1623 C	TATA spare parts
274781800142	ASSY MASCOT TATA 2523 C EX2	TATA spare parts
274781806301	STICKER BS-4	TATA spare parts
274781806302	MASCOTINCHCRIGINCH	TATA spare parts
274781900103	ASSY.BKT.-LH-BAZZLE MTG	TATA spare parts
274781900104	ASSY.BKT.-RH-BAZZLE MTG	TATA spare parts
274781900107	CENTRE GRILLE FRONT WITH T EMBLEM-BLACK	TATA spare parts
274781900108	ASSY.BAZZLE COMPLETE-LH	TATA spare parts
274781900109	ASSY.BAZZLE COMPLETE-RH	TATA spare parts
274781900112	ASSY COVER BAZZLE-LH	TATA spare parts
274781900113	ASSY COVER BAZZLE-RH	TATA spare parts
274781900114	ASSY BAZZLE-LH	TATA spare parts
274781900115	ASSY BAZZLE-RH	TATA spare parts
274781900129	ASSY.CENTRE GRILLE(GREY) FRONT WITH T	TATA spare parts
274781900130	ASSY COVER BAZZLE-LH(GREY)	TATA spare parts
274781900131	ASSY COVER BAZZLE-RH(GREY)	TATA spare parts
274781900133	ASSEMBLY COVER BAZEL RH(GREY)	TATA spare parts
274781906301	CORNER COVER-LH	TATA spare parts
274781906302	CORNER COVER-RH	TATA spare parts

274781906305	CENTRE GRILL FRONT	TATA spare parts
274781906310	COVER STEPBOARD BOTTOM-LH	TATA spare parts
274781906311	COVER STEPBOARD BOTTOM-RH	TATA spare parts
274781906313	CLIP (FOR 8 DIA HOLE)¿ BS6	TATA spare parts
274781906314	ASSY DOOR CLIP BS6	TATA spare parts
274781906321	GRILL MIDDLE (W/S BOTTOM)(GREY)	TATA spare parts
274781906322	GRILL SIDE-LH (W/S BOTTOM)(GREY)	TATA spare parts
274781906323	GRILL SIDE-RH (W/S BOTTOM)(GREY)	TATA spare parts
274782400101	ASSY. WIPER LINKAGE	TATA spare parts
274783100102	ASSY FACE DUCT 1618	TATA spare parts
274783100111	ASSY FOOT DUCT	TATA spare parts
274783106303	COVER-LHD (HVAC UNIT)	TATA spare parts
274783106305	AIR DFLECTOR (LEGROOM VENTILATION)	TATA spare parts
274783108204	AIR DEFLECTOR-LEG ROOM VENTILATION	TATA spare parts
274783300101	ASSY.SWITCH FOR A/C ON/OFF	TATA spare parts
274783400108	ASSY.CONDENSER SHROUD WITH FAN	TATA spare parts
274783400109	ASSY. RECEIVER DRIER MTG.BRACKET	TATA spare parts
274783400112	ASSY TUBE LIQUID RD INLET	TATA spare parts
274783400115	ASSY.BRACKET HVAC MTG ON CR.MEMBER	TATA spare parts
274783400116	ASSY.BRACKET HVAC MTG ON TUNNEL	TATA spare parts
274783400117	ASSY.BRACKET HVAC MTG ON FIREWALL	TATA spare parts
274783400122	ASSY CONDENSOR COMPLETE-LHD	TATA spare parts
274783400127	ASSY HVAC CONTROL COMPLETE -24V	TATA spare parts
274783400127AE	ASSY HVAC CNTRL COMPL-24V -2523	TATA spare parts
274783400128	ASSY WATER VALVE SOLENOID COMPL.	TATA spare parts
274783400150	ASSY.CONTROL PANAL 24V	TATA spare parts
274783400241	BLOWER MOTOR ASSY.COMPL	TATA spare parts
274783400242	RESISTER BLOWER	TATA spare parts
274783400243	MOTOR ACTUATOR 2-STEP	TATA spare parts
274783400244	MOTOR ACTUATOR 1-STEP	TATA spare parts
274783400245	HEATER COIL ASSY	TATA spare parts
274783400246	WIRE HARNESS	TATA spare parts
274783400247	CLAMP CONTROL CABLE	TATA spare parts
274783400248	COIL COOLING WITH TXV	TATA spare parts
274783400249	HOSE DRAIN LHD	TATA spare parts
274783400250	RELAY MODULE 6P	TATA spare parts
274783400251	RELAY MODULE 9P	TATA spare parts
274783400252	MICRO SWITCH ASSY	TATA spare parts
274783400253	THERMOSTAT	TATA spare parts
274783500105	ASSY HOSE SUCTION	TATA spare parts
274783505801	RUBBER HOSE (17ID X 1800L)	TATA spare parts
274783505801AE	RUBBER HOSE (17ID X 1800L) 2523	TATA spare parts
274783505802	RUBBER HOSE(HEATING)	TATA spare parts
274783505803	RUBBER HOSE(HEATING)	TATA spare parts
274788200101	ASSY.FENDER-LH	TATA spare parts
274788200102	ASSY.FENDER-RH	TATA spare parts
274788200103	ASSY.FENDER-LH	TATA spare parts

274788200104	ASSY.FENDER-RH	TATA spare parts
274788200105	ASSY.FENDER-LH (SLEEPER CAB)	TATA spare parts
274788200106	ASSY.FENDER-RH (SLEEPER CAB)	TATA spare parts
274788200107	ASSY.FENDER-LH (SMC-NON-SLPR CAB)	TATA spare parts
274788200108	ASSY.FENDER-RH (SMC-NON-SLPR CAB)	TATA spare parts
274788200109	FENDER-LH GREY (SLEEPER CAB)	TATA spare parts
274788200110	FENDER-RH GREY (SLEEPER CAB)	TATA spare parts
274788200123	ASSY.FENDER-LH(GREY)	TATA spare parts
274788200124	ASSY.FENDER-RH(GREY)	TATA spare parts
274788200126	ASSY FENDER-LH(GREY)(SMC-SLPR)	TATA spare parts
274788200127	ASSY FENDER-RH(GREY)(SMC-SLPR)	TATA spare parts
274788200128	FENDER ASSY LH 7.5 T	TATA spare parts
274788200129	FENDER ASSY RH 7.5 T	TATA spare parts
274788206301	FENDER OUTER-LH (SLEEPER CAB)	TATA spare parts
274788206302	FENDER OUTER-RH (SLPR CAB)	TATA spare parts
274788500104	ASSY.BUMPER	TATA spare parts
274788500105	ASSY.BRACKET SIDE MTG.(FRONT BUMPER)	TATA spare parts
274788500106	ASSY.SUPPORT FRONT BUMPER MTG.COMPL.-LH	TATA spare parts
274788500107	ASSY.SUPPORT FRONT BUMPER MTG.COMPL.-RH	TATA spare parts
274788500111	ASSY.BKT.CENTRE COMPLETE (BUMPER MTG).	TATA spare parts
274788500115	ASSY BRACKET CENTRE COMPLT BUMPER MTG	TATA spare parts
274788500116	ASSY SUPPORT FR BUMPER MTG COMPLT LH	TATA spare parts
274788500117	ASSY SUPPORT FR BUMPER MTG COMPLT RH	TATA spare parts
274788500119	ASSY. BUMPER BS/2/4/6	TATA spare parts
274788500130	ASSY. SUPPORT BUMPER MTG. BKT. LH	TATA spare parts
274788500131	ASSY. SUPPORT BUMPER MTG. BKT. RH	TATA spare parts
274788500136	ASSY BUMPER(EXPORT VERSIONS)	TATA spare parts
274788500139	ASSY BUMPER MTG BRACKET LH	TATA spare parts
274788500140	ASSY BUMPER MTG BRACKET RH	TATA spare parts
274788500143	ASSY SUPPORT BUMPER¿ MTG.BKT.LH	TATA spare parts
274788500144	ASSY SUPPORT BUMPER MTG.BKT.RH	TATA spare parts
274788500147	ASSY. FRT BUMPER COMP. BLK BS2/3/4	TATA spare parts
274788500151	ASSY SUPPORT BKT LH FOR BUMPER SUPPORT	TATA spare parts
274788500152	ASSY SUPPORT BKT RH FOR BUMPER SUPPORT	TATA spare parts
274788500157	BUMPER	TATA spare parts
274788500163	ASSY FRONT BUMPER COMPLT(GREY)	TATA spare parts
274788503305	BRACKET SIDE-BUMPER MTG	TATA spare parts
274788506302	END COVER-LH-BUMPER FRONT	TATA spare parts
274788506303	END COVER-RH-BUMPER FRONT	TATA spare parts
274788508215	SPACER PLATE	TATA spare parts
274788508216	BOTTOM SUPPORT BUMPER MTG.	TATA spare parts
274788508220	SPACER (BUMPER MTG.)	TATA spare parts
274788508252	SPACER PLATE	TATA spare parts
274788706301	AIR DEFLECTOR BS6-PH2	TATA spare parts
274788806301	BEADING (FRONT PANEL).	TATA spare parts
274789100101	ASSY.CAB MTG.BKT.REAR-LH-CHASSIS SIDE	TATA spare parts
274789100102	ASSY.CAB MTG.FRONT-RH	TATA spare parts



274789100105	ASSY.CROSS TUBE	TATA spare parts
274789100113	ASSY.SUPPORT FRONT-LH (MUDGUARD MTG)	TATA spare parts
274789100116	ASSY.SUPPORT REAR-MUDGUARD MTG	TATA spare parts
274789100120	ASSY.CAB MTG.BKT.REAR-RH-CHASSIS SIDE	TATA spare parts
274789100121	ASSY.TIE MEMBER-REAR MTG	TATA spare parts
274789100122	ASSY.HANDLE MTG. CAB LOCKING MECHANISM	TATA spare parts
274789100126	ASSY.SECONDARY LOCK-LOCKING MECHANISM	TATA spare parts
274789100127	ASSY.SUPPORT FRONT-RH-MUDGUARD MTG.	TATA spare parts
274789100128	ASSY CAB MTG FRONT-RH-RHD	TATA spare parts
274789100129	ASSY.MTG.HOOK-CAB LOCKING MECHANISM	TATA spare parts
274789100133	ASSY.KIT FOR CAB LOCK-REAR	TATA spare parts
274789100134	ASSY CAB MTG FRONT-LH-RHD	TATA spare parts
274789100137	ASSY.MTG.BKT.BOTTOM-LH-HYD.CYLINDER	TATA spare parts
274789100139	ASSY.SUPPORT REAR (MUDGUARD MTG.)-RH	TATA spare parts
274789100140	ASSY.SUPPORT FRONT LH	TATA spare parts
274789100142	ASSY MUDGUARD MTG BRACKET-LH	TATA spare parts
274789100145	ASSY.STAY COMPLETE	TATA spare parts
274789100155	ASSY.MTG.PAD (CAB LOCKING MECHANISM)-LH	TATA spare parts
274789100156	ASSY.MTG.PAD-CAB LOCKING MECHANISM	TATA spare parts
274789100158	ASSY.NUTPLATE-FRONT MTG.	TATA spare parts
274789100161	ASSY.STAY COMPLETE	TATA spare parts
274789100167	ASSY.MUDFLAP SIDE INNER-LH	TATA spare parts
274789100168	ASSY.MUDFLAP SIDE INNER-RH.	TATA spare parts
274789100169	ASSY.MUDFLAP FRONT INNER-LH	TATA spare parts
274789100170	ASSY.MUDFLAP FRONT INNER-RH	TATA spare parts
274789100171	ASSY.MUDFLAP FRONT OUTER-LH	TATA spare parts
274789100172	ASSY.MUDFLAP FRONT OUTER-RH	TATA spare parts
274789100173	ASSY.MUDFLAP INNER REAR-LH	TATA spare parts
274789100174	ASSY.MUDFLAP INNER REAR-RH	TATA spare parts
274789100191	ASSY.CAB MTG.BKT.FRONT-RH	TATA spare parts
274789100193	ASSY.ARRESTOR (SPRAY SUPPRESSION)	TATA spare parts
274789103202	STEP PIN-STRIKER MTG	TATA spare parts
274789103328	CLAMP(ON CHASSIS)	TATA spare parts
274789103329	HOSE SUPPORT CLAMP(LATCH SIDE)	TATA spare parts
274789103403	BUSH PIN SUPPORT	TATA spare parts
274789103407	SLEEVE-LOCK SEATING	TATA spare parts
274789103702	MTG.BKT.BOTTOM-RH (CAB MTG.FRONT)	TATA spare parts
274789104202	CLAMP-LEVER SUPPORT	TATA spare parts
274789106301	MUDGUARD -LH	TATA spare parts
274789106302	MUDGUARD-RH	TATA spare parts
274789106303	PACKING UPPER	TATA spare parts
274789106304	PACKING LOWER	TATA spare parts
274789106312	BALATA PACKING-CAB MTG.REAR	TATA spare parts
274789106331	RUBBER SEAL (SPRAY SUPPRESSION)	TATA spare parts
274789106333	MUDFLAP-LH (SPRAY SUPPRESSION)	TATA spare parts
274789106334	MUDFLAP-RH (SPRAY SUPPRESSION)	TATA spare parts
274789106335	MUDGUARD-LH	TATA spare parts

274789106336	MUDGUARD-RH	TATA spare parts
274789106338	MUDGUARD-LH	TATA spare parts
274789106339	MUDGUARD-RH	TATA spare parts
274789106345	MUDGUARD-LH (NON-SLPR.CAB 7.5T F.A.)	TATA spare parts
274789106346	MUDGUARD-RH (NON-SLPR CAB 7.5T F.A.)	TATA spare parts
274789106706	PIN-DAMPER & SHOCK ABSORBER MTG	TATA spare parts
274789106707	CLEVIS PIN-LINK MTG.	TATA spare parts
274789106708	PIN DAMP.MTG & S/A MTG.	TATA spare parts
274789106709	PIN-CYL.MTG.ON CAB	TATA spare parts
274789107501	SLEEVE(SECONDARY LOCK)	TATA spare parts
274789107901	TORSION BAR RHD	TATA spare parts
274789108233	PLATE UPPER-CAB LOCKING MECHANISM	TATA spare parts
274789108234	PLATE LOWER-CAB LOCKING MECHANISM	TATA spare parts
274789108241	PLATE MIDDLE-CAB LOCKING MECHANISM	TATA spare parts
274789108242	SHIM	TATA spare parts
274789108263	TIE MEMBER-CAB MTG.REAR	TATA spare parts
274789108274	SPACER PLATE (CAB MTG.BKT FRONT)	TATA spare parts
274789108277	SPACER PLATE (REAR MTG.)	TATA spare parts
274789108278	SPACER PLATE (MUDGUARD MTG.REAR)	TATA spare parts
274789108294	SPACER PLATE STAY MTG.	TATA spare parts
274789108601	SPACER	TATA spare parts
274789109201	STEP WASHER	TATA spare parts
274789110101	ASSY.SECONDARY LOCKING MECHANISM	TATA spare parts
274789110108	SHOCK ABSORBER CAB MTG BS1/2/3/4	TATA spare parts
274789110109	ASSY.LATCH WITH LATCH CYL.	TATA spare parts
274789110112	ASSY.CAB MTG.BKT.RR COMPL-LH-COIL SUSN	TATA spare parts
274789110113	ASSY.CAB MTG.BKT.RR COMPL-RH-COIL SUSN	TATA spare parts
274789110114	ASSY.SHOCKABSORBER LINK COMPL.	TATA spare parts
274789110118	ASSY.BKT.PIN SUPPORT COMPLETE LH	TATA spare parts
274789110122	ASSY.SHOCK ABSORBER	TATA spare parts
274789110126	ASSY.LATCH WITH LATCH CYL - LH	TATA spare parts
274789110127	ASSY PLATE BOTTOM LATCH MTG WELDED	TATA spare parts
274789110131	ASSY.TIE MEMBER-REAR MTG	TATA spare parts
274789110139	ASSY.BKT. CYL.MTG.BOTTOM	TATA spare parts
274789110140	ASSY.HYD.PUMP	TATA spare parts
274789110141	ASSY.SLEEVE & BUSH-CABIN LATCH MTG	TATA spare parts
274789110142	ASSY.SIDE BRACKET-LATCH MOUNTING	TATA spare parts
274789110143	ASSY.LATCH MTG.BKT.COMPLETE WITH BUSH	TATA spare parts
274789110144	ASSY.LATCH MTG.BKT.COMPL.WITH BUSH	TATA spare parts
274789110145	ASSY LEVER DAMPER GUIDE COMPLETE	TATA spare parts
274789110146	ASSY BRACKET CYLINDER MTG BOTTOM	TATA spare parts
274789110147	ASSY BKT.(CYLINDER MTG.BOTTOM)	TATA spare parts
274789110149	ASSY.HYD.PUMP	TATA spare parts
274789110151	HYD. CYLINDER FOR CAB TILTING BS1/2/3/4	TATA spare parts
274789110153	ASSY.HYD.CYLINDER	TATA spare parts
274789110154	ASSY. HYD. PUMP 1613TC BS1/2/3/4	TATA spare parts
274789110156	ASSY HYDRAULIC PUMP WITHOUT ADAPTER	TATA spare parts

274789110157	ASSY.TIE MEMBER (REAR MTG)	TATA spare parts
274789110158	ASSY.SHOCK ABSORBER FOR NON-SLPR	TATA spare parts
274789110160	ASSY.BKT.CYLINDER MTG.(BOTTOM)	TATA spare parts
274789110169	ASSY. HYDRAULIC PUMP BS2/3/4	TATA spare parts
274789110172	ASSY.BRACKET.(CYLINDER MTG.BOTTOM)	TATA spare parts
274789110173	ASSY. SHOCK ABSORBER (NON-SLPR) BS2/3/4	TATA spare parts
274789110177	ASSY.LATCH WITH LATCH CYL.-RH	TATA spare parts
274789110180	ASSY.NUTPLATE	TATA spare parts
274789110181	ASSY.MUDFLAP FRONT INNER COMPLETE-LH	TATA spare parts
274789110182	ASSY.MUDFLAP FRONT INNER COMPLETE-RH	TATA spare parts
274789110184	ASSY.HYD PUMP (W/ADPTR.& W/O BASE PLATE)	TATA spare parts
274789110187	ASSY.INSULATION SIDE RR.MTG-CHAS.SIDE-LH	TATA spare parts
274789110189	ASSY.MUDGUARD MTG.BRACKET COMPLETE-LH	TATA spare parts
274789110190	ASSY.MUDGUARD MTG.BRACKET COMPLETE-RH	TATA spare parts
274789110203	SUPPORT BRACKET RH	TATA spare parts
274789118201	REINFORCEMENT (SPRAY SUPPRESSION)	TATA spare parts
274789118202	REINFORCEMENT (SPRAY SUPPRESSION)	TATA spare parts
274789118204	SPACER PLATE (CAB MTG.BKT.FRONT)	TATA spare parts
274789118206	SPACER PLATE (REAR MTG)	TATA spare parts
274789118208	PLATE (CAB MTG.BKT.FRT) (WITH FUPD FIT)	TATA spare parts
274789120101	ASSY MOUNTING BRACKET (SIDE INSULATION R	TATA spare parts
274789120102	ASSY INSULATION SIDE RR MTG CHAS.SIDE-RH	TATA spare parts
274789120103	ASSY TIE MEMBER (CAB MTG REAR)-LHD	TATA spare parts
274789120104	ASSY TIE MEMBER (CAB MTG REAR)-RHD	TATA spare parts
274789120106	MUDFLAP FRONT-LH (SPRAY SUPPRESSION) BS6	TATA spare parts
274789120107	MUDFLAP FRONT-RH (SPRAY SUPPRESSION) BS6	TATA spare parts
274789120108	MUDFLAP FRONT-LH (SPRAY SUPPRESSION)	TATA spare parts
274789120109	MUDFLAP FRONT-RH (SPRAY SUPPRESSION)	TATA spare parts
274789120110	ASSY HYD.PUMP FOR CAB TILTING (LPT 2523)	TATA spare parts
274789120110AE	HYD PUMP FOR CAB TILT 2523	TATA spare parts
274789120112	ASSY.BKT HYDRAULIC PUMP MTG	TATA spare parts
274789120115	ASSY.CAB MTG.FRONT-LH (RHD)	TATA spare parts
274789120116	ASSY.CAB MTG.BKT.FRONT-RH	TATA spare parts
274789120117	ASSY.STAY COMPLETE	TATA spare parts
274789120119	ASSY.CAB MTG.BKT.RR COMPL.-LH (COIL SUS)	TATA spare parts
274789120120	ASSY.CAB MTG.BKT.RR.COMPL.-RH (COIL SUS)	TATA spare parts
274789120121	ASSY.BKT.CYLINDER MTG.(BOTTOM)	TATA spare parts
274789120127	ASSY.HYD.PUMP COMPLETE (FOR CAB TILTING)	TATA spare parts
274789120133	ASSY. HYD. KIT FOR CAB TILTING	TATA spare parts
274789120135	ASSY. HYD. KIT FOR CAB TILTING	TATA spare parts
274789120137	ASSY. HYD. KIT FOR CAB TILTING	TATA spare parts
274789120193	ASSY.MUDGUARD MTG.BKT.COMPL.-LH(7.5T-FA)	TATA spare parts
274789120195	ASSY.MUDGRD.MTG.BKT.COMPL.-RH(7.5T FA)	TATA spare parts
274789130117	BRACKET ASSY CAB MTG REAR-LH BS6	TATA spare parts
274789130118	BRACKET ASSY CAB MTG REAR-RH BS6	TATA spare parts
274789130129	MUDFLAP ASSY FRONT INNER-LH	TATA spare parts
274789130130	MUDFLAP ASSY FRONT INNER-RH	TATA spare parts

274789130141	BRACKETASSYMUDGUARDMTGLH BS6	TATA spare parts
274789900101	ASSY METAL PIPE (T-BODY TO HOSE).	TATA spare parts
274789900102	ASSY.METAL PIPE-HOSE TO T-BODY	TATA spare parts
274789900103	ASSY METAL PIPE-T-BODY TO HOSE	TATA spare parts
274789900104	ASSY.METAL TUBE-T-BODY TO HOSE	TATA spare parts
274789900105	ASSY METAL TUBE-PUMP TO HOSE	TATA spare parts
274789900106	ASSY METAL TUBE-T-BODY TO HOSE	TATA spare parts
274789900107	ASSY.METAL TUBE (PUMP TO T-BODY).	TATA spare parts
274789900108	ASSY HOSE-LATCH TO 3 WAY CONNECTOR	TATA spare parts
274789900109	ASSY HOSE-CYLINDER TO 3 WAY CONNECTOR	TATA spare parts
274789900110	ASSY HOSE-BETWEEN 3 WAY CONNECTOR	TATA spare parts
274789900113	ASSY METAL PIPE (PUMP TO 3-WAY BEF.CYD)	TATA spare parts
274789900114	ASSY METAL PIPE (AFTER 3-WAY TO HOSE)	TATA spare parts
274789900115	ASSY METAL PIPE (PUMP TO HOSE BEF.CYL.)	TATA spare parts
274789900116	ASSY METAL PIPE (3-WAY TO HOSE)	TATA spare parts
274789900117	ASSY METAL PIPE(3-WAY TO LHS LATCH HOSE)	TATA spare parts
274789900118	ASSY METAL PIPE(3-WAY TO RHS LATCH HOSE)	TATA spare parts
274789900119	ASSY METAL PIPE(3-WAY TO RHS LATCH HOSE)	TATA spare parts
274789900128	HOSE ASSY. LH LATCH TOç T SOCKET	TATA spare parts
274789900129	HOSE ASSY. RH LATCH TOç T SOCKET (CYL	TATA spare parts
274789900130	HOSE ASSY. T SOCKET (LATCH SIDE) TO T	TATA spare parts
274789900131	HOSE ASSY. HYD. CYLINDER TO 'T' SOCKET	TATA spare parts
274789900132	HOSE ASSY. HYD. CYLINDER TO PUMP	TATA spare parts
274789900133	HOSE ASSY. PUMP TO 'T' SOCKET (CYL. SIDE	TATA spare parts
274789900134	MALE ADAPTOR WITH O RING	TATA spare parts
274789900135	MALE ADAPTOR WITH O RING	TATA spare parts
274789900136	HOSE ASSY. HYD. CYLINDER TO PUMP	TATA spare parts
274789900137	HOSE ASSY. PUMP TO T SOCKET	TATA spare parts
274789900138	HOSE ASSY. HYD. CYLINDER TO PUMP	TATA spare parts
274789900139	HOSE ASSY. PUMP TO T SOCKET (CYL. SIDE	TATA spare parts
274789900140	HOSE ASSY. HYD. CYLINDER TO PUMP (CYL. S	TATA spare parts
274789900141	HOSE ASSY. PUMP TO T SOCKET (CYL. SIDE	TATA spare parts
274791000102	ASSY DRIVER SEAT COMPLT.RH WITH FAB.	TATA spare parts
274791000103	ASSY DRIVER MECH.SUSPENDE SEAT COM- LHD	TATA spare parts
274791000104	ASSY DRIVER MECHANICAL SUSPENDE SEAT CO	TATA spare parts
274791000105	DRIVER SEAT MECHANICAL SUSPENDE COM- RH	TATA spare parts
274791000107	ASSY DRIVER MECHANICAL SUSPENDE SEAT CO	TATA spare parts
274791100109	ASSY.SEAT BOX COMPLETE (DRIVER SEAT)-RHD	TATA spare parts
274791100110	ASSY.SEAT BOX COMPLETE (DRIVER SEAT)-LHD	TATA spare parts
274791100124	ASSY. SEAT BOX COMPLETE (DRIVER SEAT)	TATA spare parts
274791106301	COVER_HBV PIPES BS6	TATA spare parts
274791500107	CABLE BUCKLE ASSY.W/O M.SWITCH BS6	TATA spare parts
274791500108	ASSY. SEAT BELT KIT CO-DRIVER SIDE.	TATA spare parts
274791500109	ASSY. SEAT BELT KIT CO-DRIVER SIDE.	TATA spare parts
274794000106	ASSY CO- DRIVER SEAT COMPL.LH (WITH FAB)	TATA spare parts
274797980102	KIT-SEAT BELT FRONT	TATA spare parts
274798410108	ASSY.BOTTOM BERTH	TATA spare parts

274798410109	ASSY.TOP BERTH	TATA spare parts
274798410115	BERTH ASSY LOWER	TATA spare parts
274798416703	STEP PIN-POST SIDE	TATA spare parts
274799500101	ASSY PLASTIC RIVET( FOR 7 DIA.HOLE)	TATA spare parts
274960100101	ASSY COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
274960100102	ASSY COWL SHELL PAINTED RHD	TATA spare parts
274960100106	ASSY COWL COMPRHD	TATA spare parts
274960100106SJ	ASSY COWL COMP.RHD SK1613BSII SPARE PART	TATA spare parts
274960100107	ASSY COWL SHELL PAINTED RHD	TATA spare parts
274961600101	ASSY FLOOR CENTRE RHD	TATA spare parts
274966608204	STEP WELL BOTTOM LH	TATA spare parts
274966608205	STEP WELL BOTTOM RH	TATA spare parts
274988106301	FENDER LH-SPRAY SUPPRESSION	TATA spare parts
274988106302	FENDER RH-SPRAY SUPPRESSION	TATA spare parts
274988106303	MUDFLAP-SPRAY SUPPRESSION	TATA spare parts
2750025531R	FRAME ASSY LPO1316/55LMTC	TATA spare parts
275024100101	ASSY ENG MTG BKT FRON	TATA spare parts
275024200101	ASSY.BRACKET TOP LH(ENG.MTG.REAR)	TATA spare parts
275024200103	BRACKET RH (ENGINE CROSS MEMBER REAR)	TATA spare parts
275024200104	ASSY BRACKET LH-ENG.MTG.REAR ON FRAME	TATA spare parts
275024200105	ASSY BRACKET RH ON ENG MTG.REAR	TATA spare parts
275026800106	ASSY TURNING TUBE	TATA spare parts
275026800111	ASSY. BRACKET	TATA spare parts
275026800112	ASSY. TURNING TUBE	TATA spare parts
275026800113	ASSY. BRACKET (BALL JOINT TYPE)	TATA spare parts
275026800114	ASSY. TURNING TUBE (W/O BALL JOINT)	TATA spare parts
275026800117	ASSY. G.S. LEVER W/SEL & SHIFTER FORK	TATA spare parts
275026800118	TURNING TUBE ASSY (W-O BALL JOINT)	TATA spare parts
275026800125	SELECTOR & SHIFTER YOKE	TATA spare parts
275026800126	BRACKET ASSY BALL JOINT	TATA spare parts
275026805301	GASKET 1316	TATA spare parts
275026805302	GASKET	TATA spare parts
275026805303	GASKET 1316	TATA spare parts
275026809901	GEAR SHAFT LEVER	TATA spare parts
275026809902	GEAR SHIFT LEVER	TATA spare parts
275026809906	GEAR SHIFT LEVER	TATA spare parts
275029100101	ASSY CL PEDAL LEVER COMP	TATA spare parts
275029100102	CLUTCH MASTER CYL. 19.05X36 DIA. BS1- 4	TATA spare parts
275029100107	NIPPLE & PIPE UNION	TATA spare parts
275029100108	ASSY PEDAL PLATE (CL	TATA spare parts
275029100111	ASSY CONNECTING LINE FOR HYD CLUTCH	TATA spare parts
275029100112	ASSY PEDAL PLATE CLUTCH	TATA spare parts
275029100113	ASSY CONNECTING LINE	TATA spare parts
275029100114	ASSY.CLUTCH MASTER CYLINDER (19.05 MM DI	TATA spare parts
275029100115	ASSY. PEDAL PLATE	TATA spare parts
275029100117	ASSY BRACKET (CLUTCH BOOSTER MTG.)	TATA spare parts
275029200101	ASSY.CLUTCH PEDAL LEVER COMPLETE LHD	TATA spare parts

275029200103	ASSY CLUTCH PEDAL LEVER	TATA spare parts
275029200105	ASSY CLUTCH PADEL LEVER COMPLETE	TATA spare parts
275029300107	BUNDY TUBE ASSY CMC TO LONG MEMBER	TATA spare parts
275029300110	BUNDY TUBE ASSY LONG MEMBER	TATA spare parts
275029300111	BUNDY TUBE ASSY CMC TO LONG MEMBER	TATA spare parts
275029305801	HOSE CMC TO RESERVOIR	TATA spare parts
275029350101	ASSY. BRACKET (FOR SLAVE CYLINDER MOUNTI	TATA spare parts
275029350102	ASSY. BRACKET (FOR SLAVE CYLINDER MOUNTI	TATA spare parts
275029500101	ASSY.SUPPORT PEDAL WITH TUBE.	TATA spare parts
275029500102	ASSY.BEARING TUBE	TATA spare parts
275029500104	ASSY SUPPORT PEDAL WITH TUBE	TATA spare parts
275029500110	ASSY. BRACKET (CLUTCH MASTER CYLINDER MO	TATA spare parts
275029500114	ASSY SUPPORT PEDAL WITH TUBE	TATA spare parts
275029500116	ASSY CLUTCH BOOSTER MTG. BRACKET(70 DIA)	TATA spare parts
275029500117	ASSY.PEDAL SUPPORT WITH TUBE LHD	TATA spare parts
275029500121	ASSY. SUPPORT PEDAL WITH TUBE	TATA spare parts
275029500123	BRACKET ASSY CLUTCH PEDAL MTG	TATA spare parts
275030100101	ASSY LEVER ACC PEDAL (RHD	TATA spare parts
275030100102	ASSY. ACCELERATOR LEVER	TATA spare parts
275030100117	ASSY PULL ROD	TATA spare parts
275030100124	ASSY PULL ROD	TATA spare parts
275030100129	THRUST ROD RHD	TATA spare parts
275030100131	ASSY PULL ROD	TATA spare parts
275030100132	ASSY BRACKET	TATA spare parts
275030100133	ASSY LEVER	TATA spare parts
275030100134	ASSY CONTRO SHAFT	TATA spare parts
275030100138	ASSY. LEVER ACCELERATOR PEDAL LHD	TATA spare parts
275030100139	ASSY LEVER	TATA spare parts
275030100140	ASSY LINK ROD	TATA spare parts
275030100143	ASSY.PULL ROD LHD	TATA spare parts
275030100145	ACCELERATOR CABLE ASSY	TATA spare parts
275030100146	ASSY. ACCELERATOR LEVER LHD	TATA spare parts
275030100150	ASSY.PEDAL PLATE WITH COVER	TATA spare parts
275030100152	LEVER ASSY INLINE FIP	TATA spare parts
275030100153	BRACKET ASSY WITH PEDAL LEVER	TATA spare parts
275030100154	BRACKET ASSY ACCELERATOR PEDAL	TATA spare parts
275030100155	ACCELERATOR PEDAL ASSY	TATA spare parts
275030103306	BRACKET	TATA spare parts
275030107903	CONTROL SHAFT	TATA spare parts
275030200101	ASSY. PULL CABLE ENG STOP 2455MM BS1/2/3	TATA spare parts
275030200105	ASSY. CABLE ENGINE STOP	TATA spare parts
275030203301	BRACKET (RETURN SPRING HOLDING)	TATA spare parts
275030207501	GROMMET	TATA spare parts
275031000101	ASSY FRAME LPO1316TC_5545_60%W/O FACE	TATA spare parts
275031000105	ASSY FRAME LPO1316TC-55-50%	TATA spare parts
275031000107	ASSY.FRAME COMPLETE- LPO 1316TC	TATA spare parts
275031000111	ASSY FRAME	TATA spare parts

275031000112	ASSY FRAME- WEVELLER SUSPENSION	TATA spare parts
275031000113	ASSY FRAME- WEVELLER SUSPENSION	TATA spare parts
275031000126	FRAME ASSY WITH FITMENT	TATA spare parts
275031200101	ASSY ENGINE CROSS MEMBER	TATA spare parts
275031200102	ASSY BRACKET RH	TATA spare parts
275031200103	ASSY BRACKET LH	TATA spare parts
275031200104	ASSY.CROSS MEMBER.	TATA spare parts
275031207101	BRACKET	TATA spare parts
275031207113	SUPPORT LH	TATA spare parts
275031207114	SUPPORT TOP RH	TATA spare parts
275031207115	REINFORCEMENT	TATA spare parts
275031207116	REINFORCEMENT LH	TATA spare parts
275031207125	REINF.REAR RH (BOTTOM)	TATA spare parts
275031207126	REINF.REAR LH (BOTTOM)	TATA spare parts
275031208203	SPACER	TATA spare parts
275031208204	SPACER	TATA spare parts
275031208209	GUSSET R.H.	TATA spare parts
275031208210	GUSSET L.H.	TATA spare parts
275031208211	GUSSET-TOP R.H (BUMPER CROSS MEMBER)	TATA spare parts
275031208212	GUSSET-TOP L.H (BUMPER CROSS MEMBER)	TATA spare parts
275032100103	ASSY. FRONT SPRING LPO BS1/2/3/4	TATA spare parts
275032204201	U-CLAMP	TATA spare parts
275032600101	ASSY.SHOCK ABSORBER BRACKET RH BOTTOM T	TATA spare parts
275032600102	ASSY SHOCK ABSORBER MTG.BKT.LH BOTTOM	TATA spare parts
275032600105	ASSY SHOCK ABSORBER BKT BOTTOM RH	TATA spare parts
275032600106	ASSY SHOCK ABSORBER BKT BOTTOM LH	TATA spare parts
275032600107	ASSY. BRACKET RH BOTTOM SHOCK MTG.	TATA spare parts
275032600108	ASSY. BRACKET LH BOTTOM SHOCK MTG.	TATA spare parts
275032600109	ASSY. BRACKET RH BOTTOM SHOCK MTG.	TATA spare parts
275032600110	ASSY. BRACKET LH BOTTOM SHOCK MTG.	TATA spare parts
275032800101	ASSY.ANTI ROLL BAR WITH EYE PIECE COMP	TATA spare parts
275033000102	ASSY. FRONT AXLE COMP. WITH BRAKES	TATA spare parts
275033000103	ASSY.FRONT AXLE(LHD)W-BRAKES COMP	TATA spare parts
275033000104	ASSY.FRONT AXLE(LHD)W-BRAKES COMP(RAF 7)	TATA spare parts
275033000106	FRONT AXLE LPO1316/1318	TATA spare parts
275033000109	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
275033000110	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
275033000113	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
275033000116	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
275033805102	STEERING ARM	TATA spare parts
275041100101	ASSY.PROP.SHAFT WITH CEN.BRG.FRONT	TATA spare parts
275041100103	P S MIDDLE 90X3X808 W/CB	TATA spare parts
275041100106	ASSY PROP SHAFT WITH C/B MIDDLE 519LG	TATA spare parts
275041100114	ASSY PROPELLER SHAFT WITH CENTRE	TATA spare parts
275041100119	ASSY PROP SHAFT-FRONT	TATA spare parts
275041100120	ASSY PROP SHAFT MIDDLE	TATA spare parts
275041100122	PROP SHAFT-HONEYCOMB CB/130 FLANGE/1740	TATA spare parts

275041100123	PROP SHAFT DOUBLE HONEYCOMB CB/1126L	TATA spare parts
275041103203	HEX BOLT M12X1.5	TATA spare parts
275041106102	LOCK PLATE	TATA spare parts
275041110101	ASSY. UNIVERSAL JOINT BS3/4	TATA spare parts
275041110102	ASSY. UNIVERSAL JOINT COMP. BS1/2/3/4	TATA spare parts
275041110103	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
275041110108	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
275041110109	PROPELLER SHAFT ASSY	TATA spare parts
275041115101	FLANGE YOKE	TATA spare parts
275041115102	COMPANION FLANGE	TATA spare parts
275041115103	FLANGE YOKE	TATA spare parts
275041115104	COUPLING FLANGE ASSY	TATA spare parts
275041116502	NUT	TATA spare parts
275041120101	ASSY. PROP. SHAFT REAR COMP. BS3	TATA spare parts
275041120104	ASSY PROP SHAFT(REAR)	TATA spare parts
275041120106	ASSY PROPELLER SHAFT REAR-1720L	TATA spare parts
275041120110	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
275041120201	WELCH PLUG ASSEMBLY	TATA spare parts
275041125101	SLIP YOKE	TATA spare parts
275041127801	SEAL	TATA spare parts
275041300101	KIT-CENTER BEARING (M/S DANA) BS1/3/4	TATA spare parts
275041300102	LONG FORK SUB ASSY.(GB TO AGB)	TATA spare parts
275041303301	BRACKET FOR CENTRE B	TATA spare parts
275041303302	BRACKET FOR CENTRE BEARING-2	TATA spare parts
275041303305	BRACKET (PROP.SHAFT CENTRE BEARING BKT-1	TATA spare parts
275041303312	BRACKET(FOR 1ST CENTRE BEARING)	TATA spare parts
275041303313	BRACKET(FOR 2ND CENTRE BEARING)	TATA spare parts
275041303314	BRACKET(FOR 2ND CENTRE BEARING)	TATA spare parts
275041303315	BRACKET(FOR 1ST CENTRE BEARING)	TATA spare parts
275041303316	BRACKET(FOR 2ND CENTRE BEARING	TATA spare parts
275041303319	BRACKET(FOR 2ND CENTER BEARING	TATA spare parts
275041303320	BRACKET(FOR 1ST CENTER BEARING )	TATA spare parts
275041303321	BRACKET(FOR 2ND CENTRE BEARING	TATA spare parts
275041303322	CENTRE BEARING BRACKET	TATA spare parts
275041303323	BRACKET(FOR 1ST CENTRE BEARING)	TATA spare parts
275041303324	MTG. BRACKET ( FOR CENTRE BEARING-1)	TATA spare parts
275041303325	MTG. BRACKET ( FOR CENTRE BEARING-2)	TATA spare parts
275041304301	SLINGER	TATA spare parts
275041304302	CENTRE BEARING & RETAINER ASSY.	TATA spare parts
275041304303	CENTER BEARING W/HONEYCOMB BS1/3/4	TATA spare parts
275041306301	CENTRE BEARING RUBBER	TATA spare parts
275041307110	BRACKET CENTER BRG MTG BS6	TATA spare parts
275041307111	BRACKET CENTER BRG MTG BS6	TATA spare parts
275041307112	BRACKET CENTER BRG MTG	TATA spare parts
275041400122	SHORT FORK TUBE & FRONT END PEICE ASSY.	TATA spare parts
275041400123	PROP SHAFT DOUBLE HONEY COMB CB/833L	TATA spare parts
275041500106	SHORT FORK TUBE REAR HOUSING ASSY.	TATA spare parts



275042100109	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
275042100110	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
275042106301	KIT-BRAKE LINER STANDARD SIZE(410X160)	TATA spare parts
275042106302	KIT-BRAKE LINER STANDARD SIZE(410X180)	TATA spare parts
275042106303	KIT-BRAKE LINER 1ST OVERSIZE(410X160)	TATA spare parts
275042106304	KIT-BRAKE LINER 1ST OVERSIZE(410X180)	TATA spare parts
275042106305	KIT-BRAKE LINER 2ND OVERSIZE(410X160)	TATA spare parts
275042106306	KIT-BRAKE LINER 2ND OVERSIZE(410X180)	TATA spare parts
275042300108	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
275042300109	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
275042900120	SET ASSY NYLON TUBE COMPLETE	TATA spare parts
275042900135	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
275042900136	SET ASSY.NYL PIPE COMP PACO (LPO1318/55)	TATA spare parts
275042900138	ASSY TUBE WITH CRIMPED RUB HOSE 18 INLET	TATA spare parts
275042906804	COUPLING BODY(ON AIR COMPRESSOR OUTLET	TATA spare parts
275042910101	ASSY. PIPE 18 DIA FROM COMPRESSOR	TATA spare parts
275042910103	ASSY. PIPE- 18 DIA TO AIR DRYER	TATA spare parts
275042990116	KIT-BRAKE	TATA spare parts
275043100101	DUAL BRAKE VALVE-RHD	TATA spare parts
275043100103	DUAL BRAKE VALVE (LHD)	TATA spare parts
275043700106	ASSY BKT - ABS MODULATOR VALVE FRONT-LH	TATA spare parts
275043700107	ASSY BKT - ABS MODULATOR VALVE FRONT-RH	TATA spare parts
275043700124	DRYING & DISTRIBUTION UNIT	TATA spare parts
275043900101	AIR DUCT. TO COMPRESSURE INLET	TATA spare parts
275043900102	3/8 INCH HOSE ASSY.	TATA spare parts
275043900109	SET ASSY NYL PIPE COMP LPO1316 WITH DDU	TATA spare parts
275043900113	KIT ASSY.AIR TANK COMP-VOSS(220)-LHD	TATA spare parts
275043900114	SUB ASSY.AIR TANK COMP-VOSS-RHD	TATA spare parts
275043900115	SET ASSY NYL PIPE COMP LPO1316-CL.BOOST	TATA spare parts
275043900116	SET ASSY NYL PIPE COMP LPO1316-CL.BOOST	TATA spare parts
275043900121	SET ASSY NYL PIPE COMP	TATA spare parts
275043900122	SET ASSY NYL PIPE COMP LPO1316 RHD	TATA spare parts
275043900185	PIPE BUNCH ASSY	TATA spare parts
275043900201	PIPE ASSY	TATA spare parts
275043903301	BRACKET (FOR T-SOCKET)	TATA spare parts
275043910101	PIPE ASSY	TATA spare parts
275043910124	PIPE ASSY COMPRESSOR TO AIR DRYER	TATA spare parts
275043910125	PIPE ASSY AIR DRYER TO COMPRESSOR	TATA spare parts
275043910126	PIPE ASSY 1ST METAL PIPE (TEFLON HOSE)	TATA spare parts
275043910130	PIPE ASSY COMPRESSOR TO AIR DRYER	TATA spare parts
275043910135	PIPE ASSY	TATA spare parts
275043910137	PIPE ASSY COMPRESSOR OUTLET	TATA spare parts
275043910166	PIPE ASSLY NYLON BUNCH	TATA spare parts
275043910169	INTAKE PIPE ASSY	TATA spare parts
275043920109	PIPE ASSY	TATA spare parts
275043920121	METAL PIPE ASSY	TATA spare parts
275043920127	PIPE ASSY	TATA spare parts

275043990101	KIT-COMPRESSOR 230CC PISTON RING PACK	TATA spare parts
275046000101	ASSY. DRAG LINK	TATA spare parts
275046000106	ASSY DRAG LINK (WEVELLER SUSPENSION)	TATA spare parts
275046000107	ASSY. DRAG LINK(WEVELLER SUSP.) EURO1	TATA spare parts
275046000108	DRAG LINK ASSY	TATA spare parts
275046100101	ASSY BRKT STRG GR BOX MTG	TATA spare parts
275046100103	ASSY BKT STEERING G/BOX MTG	TATA spare parts
275046100104	ASSY BRACKET FOR STEERING G/BOX MTG	TATA spare parts
275046100105	ASSY. BRACKET (STEERING GEAR BOX MTG.)	TATA spare parts
275046100107	ASSY STEERING COLUMN SUPPORT	TATA spare parts
275046100110	ASSY BRACKET FOR STEERING G/BOX MTG	TATA spare parts
275046100111	ASSY. COLUMN SUPPORT (STEERING) LHD	TATA spare parts
275046150101	KIT ASSY PIPES(TAU NIPP)LPO1512TC-LH	TATA spare parts
275046150102	KIT ASSY PIPES LPO1318TC-LH	TATA spare parts
275046200101	ASSY.STEERING SPINDLE.	TATA spare parts
275046200102	ASSY STEERING SPINDLE	TATA spare parts
275046304101	RELAY ARM	TATA spare parts
275046305101	PITMAN ARM	TATA spare parts
275046305102	PITMAN ARM	TATA spare parts
275046305103	PITMAN ARM BS6-PH2	TATA spare parts
275046305104	PITMAN ARM	TATA spare parts
275046400101	ASSEMBLY STG. WHEEL	TATA spare parts
275046600109	ASSY. STG. GEAR BOX.[LHD] BS2	TATA spare parts
275046600109AE	ASSY PWR STRING GR BOX-1415-2523	TATA spare parts
275046600115	HOUSING ASSY	TATA spare parts
275046600116	HOUSING COVER ASSY	TATA spare parts
275046600117	SECTOR SHAFT ASSY	TATA spare parts
275046700103	COVER PLATE ASSY	TATA spare parts
275046703301	BRACKET STG GEAR BOX MTG	TATA spare parts
275046703302	BRACKET IDLER ARM MTG	TATA spare parts
275046703303	BRACKET STG GEAR BOX MTG	TATA spare parts
275046703304	BRACKET STG GEAR BOX MTG BS6-PH2	TATA spare parts
275046800101	SUCTION LINE ASSY	TATA spare parts
275046800102	PRESSURE LINE ASSY	TATA spare parts
275046800103	RETURN LINE ASSY	TATA spare parts
275046800104	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
275046800105	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
275046800106	ASSY TUBE WITH CRIMPED R/HOSE	TATA spare parts
275046800107	RETURN LINE HOSE ASSY	TATA spare parts
275046800108	SUCTION LINE HOSE ASSY	TATA spare parts
275046800109	SUCTION LINE HOSE ASSY	TATA spare parts
275046800114	PRESSURE LINE ASSY	TATA spare parts
275046800115	RETURN LINE ASSY	TATA spare parts
275046800116	SUCTION LINE ASSY	TATA spare parts
275046900102	DRAG LINK ASSY	TATA spare parts
275046900103	DRAG LINK ASSY	TATA spare parts
275046900104	DRAG LINK ASSY	TATA spare parts

275046990114	HOUSING ASSY	TATA spare parts
275046990131	PISTON ASSY	TATA spare parts
275047600102	NYLON PIPE ASSY FUEL SUCTION	TATA spare parts
275047600103	FUEL PIPE ASSY RETURN LINE	TATA spare parts
275047600104	FUEL SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
275047600105	DIESEL TANK TO INTERMEDIATE JOINT	TATA spare parts
275047600106	INTERMEDIATE JOINT TO BABY FILTER	TATA spare parts
275047600107	INTERMEDIATE JOINT TO DIESEL TANK	TATA spare parts
275047600108	ENGINE TO INTERMEDIATE JOINT	TATA spare parts
275047600113	ASSY FUEL SUCTION LINE-1 DIA 10	TATA spare parts
275047600114	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
275047600115	FUEL SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
275047600116	ASSY FUEL RETURN LINE DIA 06	TATA spare parts
275047600117	ASSY FUEL SUCTION LINE-2 DIA 10	TATA spare parts
275047600125	FUEL SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
275047600126	FUEL SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
275047600127	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
275047600129	NYLON PIPE ASSY FUEL SUCTION	TATA spare parts
275047600130	FUEL PIPE ASSY RETURN LINE	TATA spare parts
275047707101	PLATE FUEL FILTER MTG BS6	TATA spare parts
275049000101	ASSY. TWISTED BRACKET	TATA spare parts
275049000102	ASSY. EXHAUST HANGER MTG. BKT	TATA spare parts
275049008203	CLAMP	TATA spare parts
275049100111	ASSY. SILENCER WITH PIPE FOR LHD	TATA spare parts
275049108209	SUPPORT BRACKET	TATA spare parts
275049108210	SUPPORT BRACKET	TATA spare parts
275049200105	ASSY. BRACKET COMPLETE (FOR EXHAUST BRAK	TATA spare parts
275049200108	EXHAUST SILENCER ASSY WITH TAIL PIPE	TATA spare parts
275049200109	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
275049200111	EXHAUST BRAKE UNIT	TATA spare parts
275049200112	ASSY INT FLANGE W/BUSHES	TATA spare parts
275049200116	EXH PIPE INTERMEDIATE	TATA spare parts
275049200120	ASSY.EXHAUST PIPE LP 1512 TC-ON ENGINE	TATA spare parts
275049200121	ASSY. EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
275049200123	ASSY. EXHAUST PIPE	TATA spare parts
275049200124	ASSY. EXHAUST PIPE(INTERMEDIATE)	TATA spare parts
275049200126	ASSY BRACKET LPO1512TC	TATA spare parts
275049200130	ASSY EXHAUST PIPE AT EXH.MANIFOLD	TATA spare parts
275049200131	ASSY EXH.PIPE INTERMEDIATE	TATA spare parts
275049200140	ASSY. EXHAUST PIPE INTERMEDIATE	TATA spare parts
275049200143	ASSY EXHAUST PIPE BEHIND SILENCER	TATA spare parts
275049200145	ASSY EXHAUST PIPE (AT EXHAUST MANIFOLD)	TATA spare parts
275049200146	ASSY SUPPORT BRACKET	TATA spare parts
275049200149	EXHAUST PIPE ASSY FLEX BELLOW FRONT	TATA spare parts
275049200152	EXHAUST PIPE ASSY	TATA spare parts
275049200153	EXHAUST PIPE ASSY	TATA spare parts
275049203303	SUPPORT BRACKET	TATA spare parts

275049203304	SUPPORT BRACKET (ON ENGINE)	TATA spare parts
275049203317	BRACKET	TATA spare parts
275049203318	L-CLAMP	TATA spare parts
275049203319	BRACKET EXHAUST PIPE MTG	TATA spare parts
275049204202	CLAMP	TATA spare parts
275049206941	EXHAUST PIPE AT REAR	TATA spare parts
275049208206	L-BRACKET EXHAUST	TATA spare parts
275049208207	L-BRACKET EXHAUST	TATA spare parts
275054100105	ASSY.BATTERY CARRIER STEEL- 24VX180 AH	TATA spare parts
275054100107	ASSY BRACKET MAXI MEGA CUT-OFF SW	TATA spare parts
275054108202	CLAMP TOP BATTERY	TATA spare parts
275054109905	BATTERY 12V-180AH	TATA spare parts
275054200103	INDICATOR BANK	TATA spare parts
275054203301	BRACKET	TATA spare parts
275054209901	RPM METER 24V	TATA spare parts
275054209902	RPM METER 24V	TATA spare parts
275054209921	INSTRUMENT CLSTR(1:0.88)ABS ESPDO	TATA spare parts
275054209922	INSTRUMENT CLUSTER(1:0.88)	TATA spare parts
275054400101	ASSY ROUND HEAD LAMP 24V LPO-LHD	TATA spare parts
275054504901	RELAY	TATA spare parts
275054509901	STARTER SOLENOID SWITCH 24V	TATA spare parts
275054509902	BATTERY CUT OFF SWITCH	TATA spare parts
275054509903	HAZARD WARNING SWITCH 24 VOLTS	TATA spare parts
275054600103	ASSY.MAIN CABLE SET LHD.	TATA spare parts
275054600105	CABLE SET ST/MOTOR-RELAY	TATA spare parts
275054600109	W/H MAIN -LPO 1316TC/1512TC LHD	TATA spare parts
275054600110	W/H TAIL LPO 1316TC/1512TC -W.B 55 LHD	TATA spare parts
275054600112	W/H MAIN-LPO-1316TC/LHD-INST CLUST	TATA spare parts
275054600113	WIRING HARNESS PIGTAIL TPMS	TATA spare parts
275054600114	W/H TAIL LPO-1316TC/55	TATA spare parts
275054600115	W/H-FRAME LHD 55WB ABS	TATA spare parts
275054600117	WIRING HARNESS MAIN	TATA spare parts
275054600121	MAIN WIRING HARNESS	TATA spare parts
275054600122	WIRING HARNESS P-CAN	TATA spare parts
275054600132	WIRING HARNESS MAIN	TATA spare parts
275054600144	WIRING HARNESS MAXI FUSE	TATA spare parts
275054600145	WIRING HARNESS MAIN	TATA spare parts
275054600146	WIRING HARNESS TAIL	TATA spare parts
275054601605	PIGTAIL EXHAUST BRAKE SOLENOID	TATA spare parts
275054601608	MAIN WIRING HARNESS	TATA spare parts
275054620101	W/H-MAIN LPO-1316TC LHD ABS	TATA spare parts
275054620102	W/H-MAIN LPO-1316TC LHD INT F/B	TATA spare parts
275054620110	PIGTAIL EXHAUST BRAKE SOLENOID	TATA spare parts
275054803302	BRACKET TPMS RECEIVER MTG	TATA spare parts
275059206105	REINFORCEMENT	TATA spare parts
275060100101	ASSY BARE COWL 1512 LPO	TATA spare parts
275081806301	MASCOT 1316TC	TATA spare parts

275081900101	ASSY ENGINE SHIELDING LH RHD	TATA spare parts
275081900103	ASSY. ENGINE SHIELDING RH RHD	TATA spare parts
275081900104	ASSY.ENGINE SHIELDING LH-LHD	TATA spare parts
275082400101	LINK ROD-530MM	TATA spare parts
275083800103	ASSY.FRONT PANEL COMPLT.RH-RHD VENT.UNIT	TATA spare parts
275088500101	BUMPER ASSY COMPLETE	TATA spare parts
275088500101C0	ASSY BUMPER WITH REFLECTOR - BLACK	TATA spare parts
275088500102	ASSY.ANTISAGGING BAR	TATA spare parts
27508850010292	ASSY ANTISAGIG BAR BKTS(FOR2.4 MT)TIERED	TATA spare parts
275088700101	ASSY ENGINE HOOD COMP RHD	TATA spare parts
275088700102	ASSY.ENGINE HOOD COMPLETE-LHD	TATA spare parts
275088700103	TOGGLE CLAMP ENG HOOD	TATA spare parts
275088706301	ENGINE HOOD 1510CNG	TATA spare parts
275089100105	ASSY.BRACKET LH-RHD(COWL	TATA spare parts
275089100106	ASSY. BRACKET RH-LHD COWL MTG.FRONT	TATA spare parts
275089100107	ASSY.BRACKET LH COWL MTG.REAR	TATA spare parts
275089100108	ASSY.BRACKET-RH COWL MTG.REAR	TATA spare parts
275124100101	BRACKET ENG MTG FRT	TATA spare parts
275124100102	ASSY BRKT ENG. MTG. FRT	TATA spare parts
275124100103	ASSY.BRACKET-RH-ENGINE MOUNTING FRONT	TATA spare parts
275124100104	ASSY.BRACKET-LH-ENGINE MOUNTING FRONT	TATA spare parts
275124105101	ENGINE MOUNTING ARM-RH FRONT	TATA spare parts
275124105102	ENGINE MOUNTING ARM-LH FRONT	TATA spare parts
275124108201	LOCKING BRACKET	TATA spare parts
275124200101	ASSY.BRACKET(ENGINE MOUNTING REAR PAD)	TATA spare parts
275124200103	BRACKET ENG MTG RR LH	TATA spare parts
275124200104	BRACKET ENG MTG RR RH	TATA spare parts
275124207110	REINFORCEMENT LH	TATA spare parts
275124207111	REINFORCEMENT RH	TATA spare parts
275124207112	SUPPORT PLATE 2516TC	TATA spare parts
275125108201	COVER	TATA spare parts
275126800103	TURNING TUBE ASSY	TATA spare parts
275126800104	GEAR SHIFT LEVER W/BKT	TATA spare parts
275126800105	HOUSING BLOCK	TATA spare parts
275126800106	ASSY GEAR SHIFT LEVER KNOB	TATA spare parts
275126800109	ASSY HOUSING BLOCK	TATA spare parts
275126800110	ASSY TURNING TUBE-W/O BALL JOINT	TATA spare parts
275126800112	ASSY TURNING TUBE (W/O BALL JOINT)	TATA spare parts
275126800121	SUB.ASSY.GEAR SHIFT LEVER	TATA spare parts
275126800125	TURNING TUBE	TATA spare parts
275126800126	ASSY TURNING TUBE-WITH BALL JOINT	TATA spare parts
275126800128	ASSY LINK ROD	TATA spare parts
275126800133	TURNING TUBE-WITHOUT BALL JOINT	TATA spare parts
275126800134	ASSY GEAR SHIFT LEVER KNOB	TATA spare parts
275126800146	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
275126800152	ASSY BASE PLATE	TATA spare parts
275126800154	ASSY. HOUSING BLOCK BS1/2/3/4	TATA spare parts

275126800155	ASSY. BASE PLATE	TATA spare parts
275126805101	HOUSING BLOCK GEAR SHIFT	TATA spare parts
275126805102	FORK	TATA spare parts
275126805106	SELECTOR & SHIFTER FORK (WITH FLANGE)	TATA spare parts
275126806001	SHIFT LINK ROD	TATA spare parts
275126806302	BASE PLATE BS6	TATA spare parts
275126807701	RUBBER BELLOW	TATA spare parts
275126807702	REXENE BELLOW BS1/2/3/4	TATA spare parts
275126809901	GEAR SHIFTER LEVER	TATA spare parts
275126809903	GEAR SHIFT LEVER BENT	TATA spare parts
275126809906	GEAR SHIFT LEVER	TATA spare parts
275126810101	BRACKET G B LEVER MTG	TATA spare parts
275126810103	ASSY BRACKET	TATA spare parts
275126810105	ASSY BRACKET-G.S.LEVER MTG	TATA spare parts
275126815101	FORK	TATA spare parts
275129100103	ASSY CONNECTING LINE	TATA spare parts
275129100107	LEVER ASSEMBLY CLUTCH	TATA spare parts
275129106002	CLUTCH RELEASE LEVER	TATA spare parts
275129106902	TUBE CLUTCH LEVER	TATA spare parts
275129106905	ROD-CLUTCH LEVER	TATA spare parts
275129500101	CONTROL MTG BRACKET	TATA spare parts
275129500103	ASSY CONTROL MOUNTING BRACKET	TATA spare parts
275129500106	CONTROL MOUNTING BRACKET WITH CYL.MTG.B	TATA spare parts
275129506301	BUSH	TATA spare parts
275130100101	THRUST ROD	TATA spare parts
275130100102	LEVER ACCELERATOR	TATA spare parts
275130100103	PULL ROD ACCELERATOR	TATA spare parts
275130100104	LEVER ASSY	TATA spare parts
275130100106	ASSY BRACKET	TATA spare parts
275130100108	PULL ROD ASSY	TATA spare parts
275130100114	ASSY. CONTROL SHAFT	TATA spare parts
275130100115	BRACKET ASSY	TATA spare parts
275130100116	PULL ROD ACCELERATOR	TATA spare parts
275130100118	BRACKET ASSY	TATA spare parts
275130100119	PULL ROD ASSY	TATA spare parts
275130100120	CONTROL SHAFT ASSY	TATA spare parts
275130100121	ASSY.BRACKET	TATA spare parts
275130100122	ACCELERATOR STOPPER	TATA spare parts
275130100124	ASSY.PULL ROD-ACC. 415MM LENGTH	TATA spare parts
275130100125	ASSY PULL ROD-L=922	TATA spare parts
275130100126	SUB ASSY PULL ROD	TATA spare parts
275130100127	SUB ASSY THRUST ROD	TATA spare parts
275130100128	ASSY. BRACKET	TATA spare parts
275130100132	ASSY.PULL ROD-ACC	TATA spare parts
275130103303	BRACKET	TATA spare parts
275130103304	BRACKET	TATA spare parts
275131000101	FRAME ASSY 2516TC	TATA spare parts

275131000103	CHASSIS FRAME LPK 2516TC	TATA spare parts
275131000105	ASSY FRAME LPT 2516/48 TC LM CAB VERSION	TATA spare parts
275131000110	ASSY.FRAME	TATA spare parts
275131200101	ENG CROSS MEMBER FRONT	TATA spare parts
275131200102	ENGINE CROSS MEMBER RR	TATA spare parts
275131200103	SUPPORT ENG CROSS MEMBER	TATA spare parts
275131200104	ASSY.SUPPORT. ENGINE CROSS MEMBER FRONT	TATA spare parts
275131200110	OIL TANK MOUNTING BRACKET	TATA spare parts
275131200119	ASSY. 6 TH CROSS MEMBER & BOM. SUPPORT	TATA spare parts
275131207105	END CROSS MEMBER.	TATA spare parts
275131207159	END CROSS MEMBER	TATA spare parts
275131208202	PACKING SHEET	TATA spare parts
275131208203	PACKING SHEET	TATA spare parts
275131307101	REINFORCEMENT RH	TATA spare parts
275131307102	REINFORCEMENR LH	TATA spare parts
275131307108	SUPPORT	TATA spare parts
275131307123	REINFORCEMENT -RH (FRONT SPR.BKT.-FRONT)	TATA spare parts
275131307124	REINFORCEMENT -LH (FRONT SPR.BKT- FRONT)	TATA spare parts
275131308201	GUSSET TOP BUMPER CR MEM	TATA spare parts
275131308202	GUSSET BOT BUMPER CR MEM	TATA spare parts
275132100102	ASSY FRT. SPRING	TATA spare parts
275132100104	ASSY FRONT SPRING	TATA spare parts
275132104201	SPRING CLIP	TATA spare parts
275132300101	ASSY.BRACKET-FRONT SHOCK ABS.-UPPER	TATA spare parts
275132300102	ASSY.BRACKET (FRONT S/A MTG.UPPER)	TATA spare parts
275132508601	SPACER U CLAMP LPK 2516TC	TATA spare parts
275132800103	ASSY. CONNECTING LINK	TATA spare parts
275133203101	TAPERED ROLLER BEARING (INNER)¿BS6	TATA spare parts
275141100101	PROP SHAFT W/CEN BRG FR	TATA spare parts
275141100107	ASSY.PROP.SHAFT FRONT WITH C.B	TATA spare parts
275141100108	PROP SHAFT FRONT	TATA spare parts
275141100115	ASSY.PROPELLER SHAFT WITH CENTER BEARING	TATA spare parts
275141100122	CENTRE BEARING ASSY.	TATA spare parts
275141100126	ASSY.PROP.SHAFT FRONT WITH C.B. L=1407	TATA spare parts
275141109901	GREASE NIPPLE ASSY	TATA spare parts
275141110101	ASSY PROPELLER SHAFT FRONT WITH CENTRE	TATA spare parts
275141110102	COUPLING FLANGE ASSY	TATA spare parts
275141110104	SHORT FORK TUBE & FRONT END PIECE ASSY.	TATA spare parts
275141110106	ASSY. PROP. SHAFT FRONT (L=1434)	TATA spare parts
275141110108	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
275141110109	SHORT FORK TUBE&FRONT END PIECE ASSY	TATA spare parts
275141115102	COUPLING FLANGE	TATA spare parts
275141115104	FRONT END PIECE	TATA spare parts
275141120101	PROP SHAFT REAR COMP	TATA spare parts
275141120105	ASSY PROPELLER SHAFT REAR LPT2516-6X4	TATA spare parts
275141120108	ASSY PROP SHAFT COMPLETE REAR 2516	TATA spare parts
275141120120	ASSY PROPELLER SHAFT L666	TATA spare parts

275141120121	ASSY PROPELLER SHAFT L1520	TATA spare parts
275141120122	ASSY PROP SHAFT LPK 2516 TC	TATA spare parts
275141120123	ASSY.PROP.SHAFT REAR COMP CLOSED L=1172	TATA spare parts
275141120127	ASSY PROPELLER SHAFT LPK2516TC L666	TATA spare parts
275141120134	ASSY PROP SHAFT REAR	TATA spare parts
275141120135	ASSY PROP SHAFT INTER AXLE	TATA spare parts
275141120136	SHORT FORK TUBE & REAR HSG SUB ASSY	TATA spare parts
275141120139	ASSY. PROP. SHAFT REAR (L=1000)	TATA spare parts
275141120141	REAR HOUSING ASSY TUBE & SHORT FORK TUBE	TATA spare parts
275141120142	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
275141120144	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
275141300101	CENTER BEARING ASSY	TATA spare parts
275141303301	BRACKET-FOR CEN.BRG.FRT.P/SHAFT	TATA spare parts
275142106801	ADAPTER (M10X1 & M12X1.5)	TATA spare parts
275142900101	HOSE ASSY 1/2	TATA spare parts
275142900101AE	HOSE ASSY. -1415	TATA spare parts
275143200103	ASSY.AIR TANK	TATA spare parts
275143200104	ASSY.BRACKET-AIR TANK MTG.	TATA spare parts
275143900101	ASSY.NYLON PIPE SET COMPLETE.	TATA spare parts
275144100110	ASSY.HYD.TIPPING KIT	TATA spare parts
275144100112	HYDRAULIC TANK LPK 2516TC 6X4	TATA spare parts
275144100113	TIPPING VALVE LPK 2516TC 6X4	TATA spare parts
275144100114	HYDRAULIC CYLINDER LPK 2516TC 6X4	TATA spare parts
275144100115	AIR CONTROL VALVE LPK 2516TC 6X4	TATA spare parts
275144100116	ASSY FILTER-RETURN LINE ON HYD TANK LPK	TATA spare parts
275144100117	ASSY FILTER-BREATHER ON HYD TANK LPK 251	TATA spare parts
275144110102	REPAIR KIT 3DHMP VALVE	TATA spare parts
275144120101	PACKING KIT HYD CYLINDER LPK2516TC	TATA spare parts
275144120103	PACKSET141DIA WITH 6PARTS	TATA spare parts
275144120104	BASE TUBE	TATA spare parts
275144120105	PACKSET120DIA WITH6PARTS	TATA spare parts
275144120106	PACKSET099DIA.WITH 6PARTS	TATA spare parts
275144124301	CIRCLIP FOR 50.8 DIA	TATA spare parts
275144126901	STAGE	TATA spare parts
275144126902	STAGE	TATA spare parts
275144126903	PISTON WITH EYE	TATA spare parts
275144127101	BOTTOM PLATE141DIA.	TATA spare parts
275144127102	LOCKING PLATE FOR CYL	TATA spare parts
275144127701	O RING BASE141DIA.	TATA spare parts
275144127702	SLIDER 120 DIA.	TATA spare parts
275144127703	SNAP RING 120 DIA.	TATA spare parts
275144127704	SLIDER 099DIA.WITH2PARTS	TATA spare parts
275144127705	SNAP RING 099DIA.	TATA spare parts
275144127706	SLIDER 078 DIA.	TATA spare parts
275144129901	CIRCLIP FOR DIA 50.8	TATA spare parts
275144129902	GREASE NIPPLE - STRAIGHT	TATA spare parts
275144130101	KIT-AIR CONTROL VALVE LPK 2516TC 6X4	TATA spare parts



275144134201	NYLON TIE 4X 254	TATA spare parts
275144134601	STRAIGHT COUPLING 1/8INCH	TATA spare parts
275144136901	AIR TUBE 6X4 [25 M]	TATA spare parts
275144150102	RLF SEAL KIT	TATA spare parts
275144153701	BODY	TATA spare parts
275144157401	FILTER CAP	TATA spare parts
275144158701	SPRING	TATA spare parts
275144159901	FILTER ELEMENT (RETURN LINE) BS1/2/3/4	TATA spare parts
275144159901DF	FILTER ELEMENT RETURN LINE-HYDRAULIC	TATA spare parts
275144163201	BOLT - BREATHER	TATA spare parts
275144164701	COVER	TATA spare parts
275144167701	SEAL	TATA spare parts
275144168201	AIR BREATHER FILTER HOUSING	TATA spare parts
275144169201	AIR BREATHER SLEEVE/ STRAINER	TATA spare parts
275144169901	AIR BREATHER FILTER ELEMENT BS1/2/3/4	TATA spare parts
275144175801	HOSE 1IN ID X1150 R1 1 7/16 UNF	TATA spare parts
275144175802	PRESSURE HOSE LPK 2516TC 6X4-1950	TATA spare parts
275144175803	PRESSURE HOSE LPK 2516TC 6X4-1100	TATA spare parts
275144176802	ADAPTOR 1INCH BSP MALE X M39	TATA spare parts
275144176805	ADAPTOR 1.25 INCH BSP	TATA spare parts
275144177701	DOWTY SEAL 1 1/4INCH	TATA spare parts
275144177702	DOWTY SEAL 3/4INCH	TATA spare parts
275144177703	TIPPING VALVE O RING	TATA spare parts
275144177704	DOWTY SEAL 1INCH	TATA spare parts
275144179001	BALL VALVE 1_1/2IN BSP LP	TATA spare parts
275144179201	COPPER WASHER 38X 44X 2.5	TATA spare parts
275144179901	TIPPING VALVE MOUNTING BLOCK	TATA spare parts
275144179902	FLUID LEVEL GAUGE LPK 2516TC 6X4	TATA spare parts
275146100101	BKT STRG GB & CON MTG RH	TATA spare parts
275146100102	ASSY.STG.GEAR BOX MTG.BRACKET & CAB MTG.	TATA spare parts
275146100104	ASSY STEERING COLUMN SUPPORT	TATA spare parts
275146106301	RUBBER BELLOW	TATA spare parts
275146150101	ASSY. KIT PIPES	TATA spare parts
275146207901	STRG SPINDLE BOTTOM	TATA spare parts
275146207902	STRG SPINDLE BOTTOM	TATA spare parts
275146207903	STEERING SPINDLE TOP	TATA spare parts
275146600101	STRG.PUMP 3516/2516	TATA spare parts
275146600103	SHAFT SUB ASSY	TATA spare parts
275146604301	RETAINING RING	TATA spare parts
275146607701	O RING	TATA spare parts
275146607702	O RING	TATA spare parts
275146609201	SEALING WASHER	TATA spare parts
275146800106	SUCTION LINE HOSE ASSY	TATA spare parts
275146800107	PRESSURE LINE HOSE ASSY	TATA spare parts
275146800108	RETURN LINE HOSE ASSY	TATA spare parts
275146800109	RETURN HOSE ASSY	TATA spare parts
275147100101	FUEL TANK 250 LTR	TATA spare parts

275147100103	FUEL TANK 160 LTR	TATA spare parts
275147100106	ASSY. SUCTION TUBE	TATA spare parts
275147100107	ASSY.FUEL TANK COMPLETE (160 LTR)	TATA spare parts
275147100109	ASSY.FUEL TANK COMPLETE(250LTR) 1 PIECE	TATA spare parts
275147600103	PIPE UNION BOLT	TATA spare parts
275149100105	SILENCER WITH PIPES	TATA spare parts
275149100110	SILENCER WITH PIPES	TATA spare parts
275149100114	ASSY.MUFFLER WITH TAIL PIPE	TATA spare parts
275149200104	ASSY BRACKET	TATA spare parts
275149200105	EXHAUST PIPE	TATA spare parts
275149200107	ASSY.BRACKET	TATA spare parts
275149200109	ASSY.THROTTLE VALVE.	TATA spare parts
275149200110	ASSY.LEVER (THROTTLE VALVE)	TATA spare parts
275149200113	ASSY EXH. PIPE FRT.	TATA spare parts
275149200115	ASSY.BRACKET	TATA spare parts
275149200116	EXHAUST PIPE INTERMEDIATE	TATA spare parts
275149200118	EXHAUST PIPE ASSY LPK 2516TC	TATA spare parts
275149200120	ASSY.EXHAUST PIPE	TATA spare parts
275149204202	EXHAUST CLAMP	TATA spare parts
275149206908	TAIL PIPE	TATA spare parts
275149208204	SUPPORT BRACKET	TATA spare parts
275149208205	BRACKET	TATA spare parts
275149208212	SUPPORT BRACKET	TATA spare parts
275149208214	CLAMP	TATA spare parts
275154100112	ASSY.BATTERY CABLE LINK 70 SQMM	TATA spare parts
275154107701	INSULATOR BASE BAT CUT-OFF SWITCH	TATA spare parts
275154200101	ASSY.BRACKET [FOR ST.RELAY]	TATA spare parts
275154208204	BRACKET (RELAY MOUNTING)	TATA spare parts
275154209907	SPEEDOMETER 6+1DIGIT RATIO 1:0.80 OFFER	TATA spare parts
275154209908	SPEEDOMETER-1 :0:8	TATA spare parts
275154209909	SPEEDOMETER 6+1DIGIT RATIO 1:0.80	TATA spare parts
275154209919	SPEEDOMETER(6+1)1:1.04 BIPOLAR	TATA spare parts
275154209921	TANK UNIT 12V/24V BIPOLAR	TATA spare parts
275154400110	ASSY ENGINE LAMP BIPOLAR	TATA spare parts
275154400120	HEADLAMP LH	TATA spare parts
275154400121	HEADLAMP RH	TATA spare parts
275154509901	OIL PRESSURE SWITCH BI-POLAR	TATA spare parts
275154600101	MAIN CABLE SET RHD ROTARY	TATA spare parts
275154600102	CABLE SET FRT TO TAIL	TATA spare parts
275154600110	ASSY MAIN CABLE SET	TATA spare parts
275154607501	PROTECTIVE BOOT (AT STARTER MOTOR TR.)	TATA spare parts
275154620101	MAIN CABLE SET LPK 2516 TC	TATA spare parts
275158404004	WHEEL CHOCK-ANGLE 18X18X3(TWIN RA HCV)	TATA spare parts
275158900601	KIT TAPPET REPLACEMENT	TATA spare parts
275158900604	DIAL INDICATOR & SLEEVE	TATA spare parts
275158900605	GAUGE TORQUE ANGLE	TATA spare parts
275158900606	DIAL GAUGE ATTACHMENT	TATA spare parts

275158900607	FUEL PUMP TIMING TOOL	TATA spare parts
275158900609	TIMING PIN EXTENDER	TATA spare parts
275158900610	PULLER GEAR	TATA spare parts
275158900611	VALVE SPRING COMPRESSOR	TATA spare parts
275158900613	HOLDING FIXTURE	TATA spare parts
275158900614	ENGINE BARRING TOOL NEW	TATA spare parts
275158900628	GAUGE CYL HD CAP SCREW	TATA spare parts
275158900629	INSTALLER EXPANSION PLUG	TATA spare parts
275158900701	INJECTOR PULLER	TATA spare parts
275158900902	FUEL PUMP WRENCH	TATA spare parts
275158900903	PULLER FUEL PUMP GEAR	TATA spare parts
275158901401	WASTE GATE PR TEST KIT	TATA spare parts
275158901402	PR GAUGE IN/MANIFO W/HOSE	TATA spare parts
275158901403	GAUGE VACUUM	TATA spare parts
275158901407	FITTING	TATA spare parts
275158901408	GAUGE VACUUM	TATA spare parts
275158901801	KIT LUBE OIL COOLER TEST	TATA spare parts
275158901802	KIT BLOW BY MEASUREMENT	TATA spare parts
275158901803	LAMP BLACK LIGHT 230V/50H	TATA spare parts
275158901805	WRENCH-OIL FILTER	TATA spare parts
275158902002	CUP PLUG DRIVER	TATA spare parts
275158902006	VISCOSIMETER	TATA spare parts
275158902202	STAND ENG REBUILD	TATA spare parts
275158902203	PLATE-ENGINE STAND ADAPTER	TATA spare parts
275158902621	DRIFT-FRONT COVER OIL SEAL INSTAL.	TATA spare parts
275158902622	DRIFT-TAPER ROLLER BEARING INSTAL.	TATA spare parts
275158902623	PULLER - R I SHAFT	TATA spare parts
275158902625	PULLER-DRIVE SHAFT TAPER ROLLER BEARING	TATA spare parts
275158902626	DRIFT-OUTER RACE TRB DRIVE & MAIN SHAFT	TATA spare parts
275158902627	DRIFT-OUTER RACE TRB COUNTER SHAFT	TATA spare parts
275158902628	PULLER-PILOT T R BEARING MAIN SHAFT	TATA spare parts
275158902629	MANDREL-CLUTCH DISC ALIGNMENT	TATA spare parts
275158902630	MOUNTING PLATE FOR GBS 60	TATA spare parts
275158902631	SPACER-PILOT T.R.BRG.MAIN SHAFT G-60	TATA spare parts
275160100101	COWL COMPL. WITH FITMENTS 2516TC SLEEPER	TATA spare parts
275160100102	ASSY COWL COMPLETE RHD (SP PART)	TATA spare parts
275160100103	COWL BARE RHD 2516TC	TATA spare parts
275160100108	BODY SHELL LPT 2516 RHD SLEEPER COMPLETE	TATA spare parts
275160100110	COWL BARE RHD 2516TC/3516TC	TATA spare parts
275160100114	ASSY COWL COMPLETE RHD 2516 TC	TATA spare parts
275160100120	ASSY.COWL COMPL. LOW MT SL FOR 2516 TC/4	TATA spare parts
275160100121	LPT 2516 LOW MT. S/L COWL	TATA spare parts
275160100125	ASSY.HINGE COMPLETE LH CENTRE FLAP	TATA spare parts
275160100127	LPT 2516 RHD SLLEPER CAB COMPLETE	TATA spare parts
275160100128	BARE CAB LPT2516TC EUROII L/M S/L	TATA spare parts
275160100135	LPS 3516 SL CAB FITTED-RHD LOW MT.	TATA spare parts
275160100135SJ	LPS 3516 SL CAB FITTED-RHLOW MT(SPARE)	TATA spare parts

275160100143	BARE CAB SL RHD LOW MNT LPS 3516 EX	TATA spare parts
275160100148	ASSY.SLEEPER COWL FITTED-3516TC E-II LM	TATA spare parts
275160100157	ASSY CAB COMPLETE RHD 3516 ABS	TATA spare parts
275160100157SJ	ASSY CAB COMPLETE RHD SPARE PART	TATA spare parts
275160100158	ASSY CAB COMPLETE WITH FITMENTS-RHD	TATA spare parts
275160102902	HINGE LEAF CENTRE FLAP	TATA spare parts
275160103401	BUSH(CENTRE FLAP)	TATA spare parts
275160105601	GRAB HANDLE-FRONT FACE	TATA spare parts
275160106701	HINGE PIN	TATA spare parts
275160106901	STAY ROD (CENTRE FLAP)	TATA spare parts
275160107702	PLUG(FOR HANDLE) BS6	TATA spare parts
275161100107	ASSY BRKT-POWER STRG TANK MTG	TATA spare parts
275161103307	BRACKET(POWER STEERING TANK MTG.)	TATA spare parts
275161108205	COVER FRONT LH-LONG MEMBER	TATA spare parts
275161108206	COVER FRONT RH-LONG MEMBER	TATA spare parts
275161600103	ASSY.FLOOR PANEL CENTRE	TATA spare parts
275161600111	ASSY.FLOOR PANEL RH-RHD	TATA spare parts
275162100101	ASSY DOOR POST LH RHD BS6	TATA spare parts
275162100102	ASSY DOOR POST RH RHD BS6	TATA spare parts
275162100104	ASSY.FRAME FRONT-LH	TATA spare parts
275162100105	ASSY.FRAME FRONT-RH	TATA spare parts
275162200106	ASSY.SUPPORT WAIST RAIL	TATA spare parts
275162200120	ASSY BRKT.(FUSE BOX & RELAY MTG.)	TATA spare parts
275162500102	PANEL FACE SIDE BOTTOM LH	TATA spare parts
275162500103	PANEL FACE SIDE BOTTOM RH	TATA spare parts
275162500111	ASSY.NUT PLATE(GRAB HANDLE) BS6	TATA spare parts
275162508210	PANEL FACE SIDE BOOTOM-LH	TATA spare parts
275162508211	PANEL FACE SIDE BOTTOM-RH	TATA spare parts
275162600101	ASSY TOE PANEL RH RHD	TATA spare parts
275162600102	ASSY TOE PANEL LH RHD	TATA spare parts
275162600103	ASSY BONNET COMPLETE	TATA spare parts
275162600124	ASSY HINGE(DASH BOARD LIDS)	TATA spare parts
275168900105	ASSY.DASHBOARD LID SIDE(GLOVE BOX)	TATA spare parts
275168900106	ASSY DASHBOARD LID CENTRE(GLOVE BOX)	TATA spare parts
275168906301	INSTRUMENT PANEL	TATA spare parts
275175100101	CENTRE FLAP COMPLT	TATA spare parts
275175100102	CENTRE FLAP WELDED 2516TC	TATA spare parts
275175100103	ASSY.CENTRE FLAP WELDED	TATA spare parts
275181100106	ASSY.INSULATION(FOR BONNET)	TATA spare parts
275181108201	STEP-ADDITIONAL	TATA spare parts
275181108202	RETAINER-FOR INSULATION	TATA spare parts
275181800104	TATA 2516 CUMMINS MASCOT	TATA spare parts
275181800106	ASSY MASCOT 6 X 4	TATA spare parts
275181800110	ASSY MASCOT TATA 2516 C	TATA spare parts
275181800112	ASSY TATA 2516 C 6X4 MASCOT	TATA spare parts
275181806301	MASCOT 2516TC	TATA spare parts
275181900101	ASSY. ENGINE SHIELDING LH RHD	TATA spare parts

275181900102	ASSY ENGINE SHIELDING RH	TATA spare parts
275187000101	ASSY.TIPPING KIT	TATA spare parts
275187100101	ASSY SUB FRAME	TATA spare parts
275187300101	ASSY.TIPPING BODY COMPLETE.	TATA spare parts
275188100101	FENDER COMPLETE LH	TATA spare parts
275188100102	FENDER COMPLETE RH	TATA spare parts
275188106303	MUDGUARD FRONT LH	TATA spare parts
275188106304	MUDGUARD FRONT RH	TATA spare parts
275188106305	MUDFLAP REAR	TATA spare parts
275188106306	MUD FLAP REAR	TATA spare parts
275188108201	EXTENSION(FENDER)	TATA spare parts
275188500115	ASSY.BUMPER COMPLETE	TATA spare parts
275188500115B0	BUMPER PAINTED BLACK	TATA spare parts
275188500115B9	BUMPER PAINTED REV BLUE	TATA spare parts
275188500115BA	BUMPER PAINTED SUPER WHITE	TATA spare parts
275188500115C0	ASSY. BUMPER W/BLACK REFLECT. BS1/2/3/4	TATA spare parts
275188500115C9	ASSY BUMPER WITH REFLECTOR - REV. BLUE	TATA spare parts
275188500115CA	ASSY BUMPER WITH REFLECTOR - SUPER WHITE	TATA spare parts
275188508209	FOOT STEP BUMPER	TATA spare parts
275188700101	ENGINE HOOD COMP RHD	TATA spare parts
275188706301	ENG HOOD RHD LPT2516TC	TATA spare parts
275188706302	BASE PLATE	TATA spare parts
275188707701	SEALING RUB ENGINE HOOD	TATA spare parts
275188708201	CLAMPING PLATE (HEAT INSULATION)	TATA spare parts
275189100101	ASSY FRONT MTG BRACKET LH	TATA spare parts
275224200101	ASSY ENGINE MTG BKT REAR BOTTOM (LH)	TATA spare parts
275224200102	ASSY ENGINE MTG BKT REAR BOTTOM (RH)	TATA spare parts
275224200103	ASSY. BRACKET-LH (ENG. MTG.REAR TOP)	TATA spare parts
275224200104	ASSY. BRACKET-RH (ENG.MTG.REAR TOP)	TATA spare parts
275225000102	CLUTCH ASSY 352D TWINDISC	TATA spare parts
275225000105	ASSY. CLUTCH DISC & COVER 352 DIA. BS3/4	TATA spare parts
275225200105	CLUTCH DISC ASSY 1.75 SPLINE 352 DIA	TATA spare parts
275225200106	CLUTCH DISC 352 DIA. BS1/2/3/4	TATA spare parts
275225200107	ASSY. CLUTCH DISC 352 DIA.(1.75")BS1- 4	TATA spare parts
275225400104	CLUTCH COVER ASSY 1.75 SPLINE 352 DIA	TATA spare parts
275225400105	CLUTCH COVER 352 DIA. BS1/2/3/4	TATA spare parts
275225400110	ASSY. RELEASE BEARING 1.75 BS1/2/3/4	TATA spare parts
275225400110DF	CLUTCH RELEASE BEARING - 352 DIA	TATA spare parts
275225400111	CLUTCH COVER ASSY 1.75 SPLINE 352 DIA	TATA spare parts
275225400112	DRIVE STRAP KIT-BOLTED DESIGN	TATA spare parts
275225400114	ASSY. CLUTCH COVER 352DIA. (1.75IN)	TATA spare parts
275225408001	HEX.BOLT-FOR CLUTCH MTG.- TWIN DISC	TATA spare parts
275229100102	CLUTCH SLAVE CYLINDER	TATA spare parts
275229100105	ASSY.SUPPORT	TATA spare parts
275229100106	ASSY.CLUTCH PEDAL COMPLETE	TATA spare parts
275229100108	ASSY PIPE (CLUTCH BOOSTER)	TATA spare parts
275229300101	MINOR KIT-SLAVE CYLINDER	TATA spare parts

275229300103	MAJOR KIT-SLAVE CYLINDER	TATA spare parts
275230100103	ASSY.CONTROL SHAFT	TATA spare parts
275230100104	ASSY.PULL ROD	TATA spare parts
275230100105	ASSY.PEDAL LEVER	TATA spare parts
275230100111	ASSY BRACKET (ELECTRONIC ACCL.PEDAL MTG)	TATA spare parts
275230100113	ASSEMBLY BOTTOM LEVER ACCELERATOR	TATA spare parts
275231000101	CHASSIS FRAME LPK 2521TC	TATA spare parts
275231000102	ASSY.FRAME COMP-LPT 2521 TC BS IV TILT C	TATA spare parts
275231200101	ASSY SUPPORT (ENGINE CROSS MEMBER FRONT)	TATA spare parts
275231200102	ASSY SUPPORT (ENGINE CROSS MEMBER FRONT)	TATA spare parts
275231307101	REINFORCEMENT RH -FSB REAR BTM	TATA spare parts
275231307102	REINFORCEMENT LH -FSB REAR BTM	TATA spare parts
275231707101	BRKT FOR GEAR SHIFT SOLENOID VALVE	TATA spare parts
275233000101	ASSY.FRONT AXLE COMPLETE WITH BRAKES	TATA spare parts
275233000103	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
275241100106	PROPELLER SHAFT ASSY FRONT	TATA spare parts
275241103201	HEX BOLT	TATA spare parts
275241106101	LOCKING PLATE	TATA spare parts
275241300101	ASSY.BRACKET RH (PROP.SHAFT GUARD MTG.)	TATA spare parts
275241303304	BRACKET CENTER BEARING	TATA spare parts
275242100105	ASSY FRONT BRAKE RH WITH DUST COVER	TATA spare parts
275242100108	ASSY AUTO SLACK ADJ RH	TATA spare parts
275242100111	ASSY FRONT BRAKE LH WITH DUST COVER	TATA spare parts
275242100114	ASSY AUTO SLACK ADJ LH	TATA spare parts
275242100118	ASSY FRONT BRAKE RH WITH D/C.	TATA spare parts
275242100122	ASSY FRONT BRAKE LH WITH D/C.	TATA spare parts
275242100141	BRAKE ASSY -LH FRONT 410X180 150/16	TATA spare parts
275242100142	BRAKE ASSY -RH FRONT 410X180 150/16	TATA spare parts
275242100143	ASSY. FRONT BRAKE LH W/T D/C	TATA spare parts
275242100144	ASSY.FRONT BRAKE RH W/T D/C	TATA spare parts
275242100157	BRAKE ASSY -LH FRONT 410X180 150/16	TATA spare parts
275242100158	BRAKE ASSY -RH FRONT 410X180 150/16	TATA spare parts
275242100159	BRACKET LH	TATA spare parts
275242100160	BRACKET RH	TATA spare parts
275242100161	BRAKE ASSY -BRAKE SHOE W/LINING & ROLLER	TATA spare parts
275242107401	BRASS RIVET	TATA spare parts
275242108201	ANCHOR BRACKET-RH	TATA spare parts
275242108202	ANCHOR BRACKET-LH	TATA spare parts
275242108203	ANCHOR BRACKET RH FRONT	TATA spare parts
275242108204	ANCHOR BRACKET LH FRONT	TATA spare parts
275242108205	ANCHOR BRACKET-LH	TATA spare parts
275242108206	ANCHOR BRACKET-RH	TATA spare parts
275242109901	SPARE KIT FOR FRONT BRAKE LINER WITH RI	TATA spare parts
275242109902	SPARE KIT FRT BRK LNG (1ST O/S)	TATA spare parts
275242109903	SPARE KIT FRT BRK LNG (2ND O/S)	TATA spare parts
275242109906	MINOR O/H KIT-REAR	TATA spare parts
275242109907	BRAKE LINERS KIT MASU NA-1707	TATA spare parts

275242109908	BRAKE ASSY-LINER SHOE KIT	TATA spare parts
275242300123	DRUM BRAKE ASSY REAR -LH DIA 410X180	TATA spare parts
275242300124	DRUM BRAKE ASSY REAR -RH DIA 410X180	TATA spare parts
275242309901	SPARE KIT FOR FOR REAR BRAKE LINER WITH	TATA spare parts
275242309902	SPARE KIT REAR BRK LNG (1ST O/S)	TATA spare parts
275242309903	SPARE KIT REAR BRK LNG (2ND O/S)	TATA spare parts
275243200101	SUB.ASSY.AIRTANKS15LTRS(120X120)	TATA spare parts
275243200103	SUB ASSY AIR TANK 15L (150 X 150)	TATA spare parts
275243700107	SPRING BRK. ACTUATOR 24/24 BS1/2/3/4	TATA spare parts
275243700108	SPRING BRAKE ACTUATOR TYPE 24/24 BS3/4/6	TATA spare parts
275243709201	SPECIAL WASHER	TATA spare parts
275243900101	ASSY NYLON PIPE COMPLETE FOR LPT 2521 BS	TATA spare parts
275243900131	ASSY METAL PIPE FIRST COMPRESSOR END	TATA spare parts
275243900132	ASSY METAL PIPE 2ND DDU END	TATA spare parts
275243900145	BUNCH ASSY PIPE	TATA spare parts
275246150104	KIT ASSY PIPES POWER STG LPT2521TC BSIV	TATA spare parts
275246603001	NEEDLE ROLLER BEARING	TATA spare parts
275246800104	ASSY. SUCTION LINE (FROM REV. TANK TO ST	TATA spare parts
275246800105	ASSY. PRESSURE LINE (FROM GEAR BOX TO HY	TATA spare parts
275246800110	ASSY. RETURN LINE (GEAR BOX TO REV. TANK	TATA spare parts
275247600102	ASSY.SUCTION LINE FL.TANK TO WTR. SPTR	TATA spare parts
275247600103	ASSY PIPELINE WATER SEPARATOR TO ENGINE	TATA spare parts
275247600104	ASSY. RETURN LINE	TATA spare parts
275247707101	BRACKET (WATER SEPARATOR MTG.)	TATA spare parts
275249100103	BRACKET ASSY SUPPORT EXHAUST BRAKE MTG	TATA spare parts
275249200101	ASSY EXHAUST PIPE FRONT	TATA spare parts
275249200102	ASSY.EXH.PIPE- INTERMEDIATE	TATA spare parts
275249200107	EXHAUST BRAKE UNIT	TATA spare parts
275249200128	ASSEMBLY EXHAUST PIPE	TATA spare parts
275249200135	ASSY.BRACKET FOR I PIPE MTG	TATA spare parts
275249200140	ASSEMBLY INTERMEDIATE PIPE(TO EGP)	TATA spare parts
275249200141	ASSY BRACKET (EGP MTG.)	TATA spare parts
275249200142	ASSY.L CLAMP FOR EGP MTG.	TATA spare parts
275249200143	ASSY BRACKET (TAIL PIPE MTG.)	TATA spare parts
275249200149	AUS 32 AIR MIX LINE FOR 30 LTR TANK	TATA spare parts
275249200152	ASSEMBLY EXHAUST SECOND PIPE	TATA spare parts
275249200153	ASSY TAIL PIPE	TATA spare parts
275249203307	CLAMP(EXHAUST THIRD PIPE MTG.)	TATA spare parts
275249204201	PIPE CLAMP	TATA spare parts
275249204202	V BAND CLAMP FOR EGP & INTERMEDIATE PIPE	TATA spare parts
275249205301	GASKET	TATA spare parts
275249206918	ASSY TAIL PIPE	TATA spare parts
275249207502	RUBBER GRROMET	TATA spare parts
275249208212	CIRCULAR CLAMP(FOR EGP.MTG.)	TATA spare parts
275249208218	CLAMP PIPE	TATA spare parts
275249208236	L CLAMP FOR TAIL PIPE MTG	TATA spare parts
275249208237	L CLAMP FOR I PIPE MTG	TATA spare parts

275249208241	BRACKET AIR OIL SEPERATOR MTG	TATA spare parts
275249208245	BRACKET	TATA spare parts
275249208246	BRACKET NOX SENSOR MTG	TATA spare parts
275249990101	INSULATION EXHAUST PIPE ASSY	TATA spare parts
275254100102	ASSY PVC BATTERY CABLE -VE(95SQMM)	TATA spare parts
275254100105	ASSY. BATT CABLE +VE 70 SQMM LG 2500MM	TATA spare parts
275254208201	MOUNTING PLATE FOR AUS32 GAUGE	TATA spare parts
275254209905	DELAY TIMER RELAY 24V-INTERFACE	TATA spare parts
275254249902	R.P.M.METER 24V (BACKLIT)	TATA spare parts
275254440101	ASSY WARNING LAMP IND.(24V)	TATA spare parts
275254440102	ASSY WARNING LAMP IND.(24V)	TATA spare parts
275254606301	3-WAY CONNECTOR	TATA spare parts
275254660101	W/H MAIN LPT2521TC BSIV 24V	TATA spare parts
275254660102	W/H TAIL LPT2521TC BSIV 24V	TATA spare parts
275254660103	W/H INST CONSOLE BSIV TC 24	TATA spare parts
275254660104	W/H ENGINE	TATA spare parts
275254660105	W/H SCR PIGTAIL LPT 2521TC BSIV 24V-YAZ	TATA spare parts
275254660108	W/H SCR PIGTAIL	TATA spare parts
275254660109	W/H ASSY MAIN	TATA spare parts
275254660111	WIRING HARNESS MAIN	TATA spare parts
275258604001	ASSY. PLASTIC RIVET-WHITE	TATA spare parts
275281800107	ASSY MASCOT 6 X 4	TATA spare parts
275281800108	MASCOT TATA 2521 C	TATA spare parts
275281800110	ASSY 6X4 MASCOT	TATA spare parts
275326800101	TURNING TUBE	TATA spare parts
275326800102	CONN FLANGE SUB ASSY	TATA spare parts
275326800103	GEAR SHIFT LEVER KNOB	TATA spare parts
275326800104	ASSY GEAR SHIFT LEVER KNOB	TATA spare parts
275326800110	ASSY HOUSING BLOCK	TATA spare parts
275326810101	ASSY BRACKET	TATA spare parts
275331000101	FRAME LPS 3516/32	TATA spare parts
275333000103	ASSY.FR.AXLE COMPL.WITH BRAKES(SPIGOTTED	TATA spare parts
275341120101	ASSY PROP SHAFT LPS 4021	TATA spare parts
275342100101	BRAKE CHAMBER-RH (TYPE 24)	TATA spare parts
275342100102	BRAKE CHAMBER-LH (TYPE 24)	TATA spare parts
275342100103	BRAKE CHAMBER-RH (TYPE 24)	TATA spare parts
275342100104	BRAKE CHAMBER-LH (TYPE 24)	TATA spare parts
275349100103	SILENCER ASSY W/PIPE	TATA spare parts
275354209901	SPEEDOMETER 1:1.04 6+1	TATA spare parts
275354209902	SPEEDOMETER(6+1 DIGIT) 1:1.04	TATA spare parts
275354209903	SPEEDOMETER(6+1 DIGIT) 1:1.04	TATA spare parts
275354209904	3.2D SPEEDOCABLE 4300L	TATA spare parts
275354600102	ASSY CABLE SET-FRT. TO TAIL	TATA spare parts
275360100106	ASSY BARE CAB	TATA spare parts
275361000102	ASSY.SUB-STRUCTURE RHD.	TATA spare parts
275361600101	ASSY.FLOOR PANEL LH RHD.	TATA spare parts
275368400101	ASSY.FLOOR MAT RHD.	TATA spare parts



275372306301	MASCOT 3521 TC	TATA spare parts
275389100101	BKT LH CAB MTG RR	TATA spare parts
275389100102	BKT CAB MTG RH RR	TATA spare parts
275400990101	SPARE KIT OF ASSY COWL	TATA spare parts
275400990103	SPARE KIT OF ASSY COWL FORç VC 27548442R	TATA spare parts
27540156000RCK	CABIN KIT FOR LPT 1615 TC BS3 56WB SIGNA	TATA spare parts
275409135801	RUBBER HOSE (REDUCER)	TATA spare parts
275415400101	ALTERNATOR 12V	TATA spare parts
275416262002	INSTRUMENT CLUSTER INTERFACE HARDWARE BS	TATA spare parts
275416262003	INST CLUSTER INTERFACE HARDWARE BS6-PH2	TATA spare parts
275416262004	INSTRUMENT CLUSTER INTERFACE HARDWARE BS	TATA spare parts
275416262005	INSTRUMENT CLUSTER INTERFACE HARDWARE BS	TATA spare parts
275424100101	ASSY SPACER	TATA spare parts
275424200101	ASSY BRACKET ENGINE MTG-REAR BOTTOM	TATA spare parts
275424200102	ASSY.BRACKET-ENGINE MTG REAR TOP	TATA spare parts
275424200106	ASSY BRACKET-RH (ENG.MTG.-REAR)	TATA spare parts
275424200107	ASSY BRACKET-LH (ENG.MTG.-REAR)	TATA spare parts
275424200108	BRACKET ASSY CHASSIS RH	TATA spare parts
275424200109	BRACKET ASSY CHASSIS LH	TATA spare parts
275424207105	BRACKET-ON FLYWHEEL HSG	TATA spare parts
275425000001	352 DIA.DISC ASSY.& COVER ASSY	TATA spare parts
275425000104	SET-DRIVEN DISC 352DIA/COVER 1.5 SPL BS3	TATA spare parts
275425100103	CLUTCH HSG.W/BUSH 6B	TATA spare parts
275425103401	BUSH CLUTCH HOUSING	TATA spare parts
275425103701	HOUSING CLUTCH	TATA spare parts
275425108201	COVER(CLUTCH HOUSING LOWER) LPT 2516TC	TATA spare parts
275425200101	PRESSURE PLATE ASSY. 1414	TATA spare parts
275425200107	CLUTCH DISC ASSY 1.5 SPLINE 352 DIA	TATA spare parts
275425200108	CLUTCH DISC 352 DIA. (1.5 SPLINE) BS2	TATA spare parts
275425200109	KIT-DISC FACING (AKN-L1909) BS1/2/3/4	TATA spare parts
275425200109DF	CLUTCH FACING 352 DIA-CERAMIC	TATA spare parts
275425206303	DISC PAD KIT 12 NOS PADS&RIVETS	TATA spare parts
275425400101	CLUTCH COVER 352 DIA LPT1615TC/LPT 2515T	TATA spare parts
275425400107	CLUTCH PRESSUR PLATE 352 DIA	TATA spare parts
275425400108	CLUTCH COVER 352 DIA.(1.5INCHSPLINE) BS2	TATA spare parts
275425400109	ADJUSTING PINION	TATA spare parts
275425400110	KIT-RELEASE LEVER BS1/2/3/4	TATA spare parts
275425400111	KIT-PRESSURE SPRING BS1/2/3/4	TATA spare parts
275425400112	RELEASE BRG CASTING SERVICE KIT	TATA spare parts
275425400113	FULL RELEASE LEVER ASSY SERVICE KIT	TATA spare parts
275425400114	KIT- PR. PLATE & NEEDLE ROLLER BS1/2/3/4	TATA spare parts
275425400115	KIT-EYE BOLT & NEEDLE ROLLER BS1/2/3/4	TATA spare parts
275425400116	RELEASE SPIDER SERVICE KIT	TATA spare parts
275425400118	RELEASE BEARING ASSY	TATA spare parts
275425400119	RELEASE SLEEVE SERVICE KIT	TATA spare parts
275425400120	HOLD DOWN BOLT KIT	TATA spare parts
275425400125	COVER SUB ASSY.	TATA spare parts

275425400126	PRESSURE PLATE SUB ASSY.	TATA spare parts
275425400127	CLUTCH COVER ASSY 1.5 SPLINE 352 DIA	TATA spare parts
275425403001	NEEDLE BEARING	TATA spare parts
275425408001	HEX SCREW	TATA spare parts
275425408002	HEX.BOLT(FOR CLUTCH MOUNT	TATA spare parts
275425408706	DIAPHRAGM	TATA spare parts
275425409201	FLAT WASHER-CLUTCH MTG	TATA spare parts
275425409202	FLAT WASHER CLUTCH MTG	TATA spare parts
275425600102	RELEASE BEARING SUB ASSY.	TATA spare parts
275425600103	BEARING SUB ASSY.	TATA spare parts
275425605101	CLUTCH RELEASE YOKE 6BT BS1/2/3/4	TATA spare parts
275425605901	KEY 6.35 THK 28.5X14.5	TATA spare parts
275425606701	WEAR PAD	TATA spare parts
275425607901	CROSS SHAFT LH SIDE	TATA spare parts
275425607902	CROSS SHAFT KNURLED RHS	TATA spare parts
275426800103	ASSY BRACKET RHD	TATA spare parts
275426800105	SUB ASSY G S LEVER	TATA spare parts
275426800106	SUB ASSY G S LEVER	TATA spare parts
275426800107	ASSY. TURNING TUBE WITH BUSH	TATA spare parts
275426800111	BASE PLATE G S L TOP	TATA spare parts
275426800115	ASSY TURNING TUBE WITH BUSH	TATA spare parts
275426800133	ASSY G.S.LEVER W/SELECT SHIFTER FORK LHD	TATA spare parts
275426800139	ASSY G.S.LEVER W/SELECT SHIFTER FORK RHD	TATA spare parts
275426800141	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
275426800144	ASSY BRACKET (G.S.LEVER)	TATA spare parts
275426800146	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
275426800153	TURNING TUBE ASSY	TATA spare parts
275426800157	GEAR SHIFT LEVER YOKE ASSY	TATA spare parts
275426800159	TURNING TUBE ASSY	TATA spare parts
275426803701	BRACKET BS6	TATA spare parts
275426803704	BRACKET BS6	TATA spare parts
275426804201	CLAMP G S L RUB BELLOW	TATA spare parts
275426807701	RUB BELLOW GR LEVER TOP	TATA spare parts
275426808202	BASE PLATE	TATA spare parts
275426809901	GEAR SHIFT LEVER	TATA spare parts
275426810101	ASSY BRACKET	TATA spare parts
275426813701	BRACKET	TATA spare parts
275428400101	ASSY BRACKET (CRANK SHAFT MTG.)	TATA spare parts
275428400102	ASSY.BRACKET (CRANK SHAFT MTG.)	TATA spare parts
275428400103	ASSY. SHAFT (WITH CRANK)	TATA spare parts
275428400104	ASSY. FORK SHIFTER	TATA spare parts
275428400105	ASSY BRACKET (PNEUMATIC CYLINDER MTG.)	TATA spare parts
275428400106	ASSY. RELEASE FORK WITH SHAFT	TATA spare parts
275428400107	ASSY. RELEASE FORK WITH SLEEVE	TATA spare parts
275428400109	ASSY. LOCKER (FOR PTO LEVER)	TATA spare parts
275428403301	BRACKET FOR PTO SWITCH	TATA spare parts
275428500103	ASSY.AUX.GEAR BOX.MTG BRACKET COMPLETE	TATA spare parts

275428507105	SUPPORT (PUMP DRIVE G.B.MTG)	TATA spare parts
275429100101	PULL ROD BRAKE	TATA spare parts
275429100106	CLUTCH SLAVE CYLINDER BS1/2/3/4	TATA spare parts
275429100106E	CLUTCH SLAVE CYLINDERLPTA 715/	TATA spare parts
275429100112	ASSY CLUTCH PEDAL LEVER	TATA spare parts
275429100117	ASSY TUBE LPT1615TC	TATA spare parts
275429100127	CL SLAVE CYL	TATA spare parts
275429100128	CLAMP COATED 10DIA	TATA spare parts
275429100129	ASSY. TUBE	TATA spare parts
275429100132	ASSY TUBE LPT1615TC	TATA spare parts
275429100133	ASSY TUBE LPT1615TC	TATA spare parts
275429100136	ASSY.TUBE (6 O.D.)	TATA spare parts
275429100137	ASSY.TUBE (6 O.D.)	TATA spare parts
275429100143	ASSY.TUBE 6 OD	TATA spare parts
275429103302	BRACKET	TATA spare parts
275429106005	CLUTCH RELEASE LEVER	TATA spare parts
275429106007	CLUTCH RELEASE LEVER	TATA spare parts
275429106702	CLUTCH PEDAL PIN	TATA spare parts
275429300101	BUNDY TUBE ASSY LONG MEMBER	TATA spare parts
275429300102	ASSY BRACKET(CLUTCH MASTER CYL MTG)	TATA spare parts
275429300103	BUNDY TUBE ASSY MIDDLE	TATA spare parts
275429300112	BUNDY TUBE ASSY MIDDLE	TATA spare parts
275429303301	BRACKET CLUTCH PIPE MTG	TATA spare parts
275429303302	BRACKET BUNDY TUBE MTG	TATA spare parts
275429350101	BKT RH CL SLAVE CYL MTG	TATA spare parts
275429350102	ASSY BKT LHD	TATA spare parts
275429500101	BRACKET ASSY BOOSTER MTG LH	TATA spare parts
275430100102	ASSY PULL ROD ACCELARTOR	TATA spare parts
275430100116	ASSY. CONTROL SHAFT	TATA spare parts
275430100117	ASSY.PULL ROD	TATA spare parts
275430100118	ASSY.PULL ROD	TATA spare parts
275430100119	ASSY LEVER	TATA spare parts
275430106301	RUBBER PLATE(ACCL. PADEL)	TATA spare parts
275430108204	RETAINER PLATE(ACCL. PEDAL)	TATA spare parts
275431000101	ASSY FRAME COMP -NON SLEEPER CAB	TATA spare parts
275431000103	ASSY FRAME LPK1615/36	TATA spare parts
275431000118	ASSLY FRAME COMPLETE	TATA spare parts
275431000119	"ASSY FRAME(42WB,TRUCK FIRE FIGHTER)"	TATA spare parts
275431000124	ASSY FRAME COMPLETE	TATA spare parts
275431000124CJO	ASSY FRAME COMPLETE	TATA spare parts
275431000125	ASSY FRAME RETRO KIT	TATA spare parts
275431000126	ASSY FRAME COMPLETE	TATA spare parts
275431000130	FRAME ASSY	TATA spare parts
275431000141CJO	FRAME ASSY WITH FITMENT	TATA spare parts
275431000145	ASSY. FRAME LPT 1618 (CAST BRKT) BS4	TATA spare parts
275431000148	FRAME ASSY WITH FITMENT	TATA spare parts
275431000152	FRAME ASSY WITH FITMENT	TATA spare parts

275431000154	FRAME ASSY WITH FITMENT	TATA spare parts
275431000161	FRAME ASSY WITH FITMENT	TATA spare parts
275431107144	LONG MEMBER RH RIVIGO	TATA spare parts
275431107145	LONG MEMBER LH	TATA spare parts
275431107150	LONG MEMBER RH	TATA spare parts
275431107151	LONG MEMBER LH	TATA spare parts
275431107153	REINFORCEMENT RH	TATA spare parts
275431107154	REINFORCEMENT LH	TATA spare parts
275431108203	REINFORCEMENT	TATA spare parts
275431200101	ASSY.ENGINE CROSS MEMBER	TATA spare parts
275431200109	ASSY CROSS MEMBER (FRONT)	TATA spare parts
27543120010935	ASSY CROSS MEMBER (FRONT)_UNPAINTED	TATA spare parts
275431200111	ASSLY SUPPORT ENGINE CROSS MEMBER	TATA spare parts
275431200113	ASSY CENTRE BEARING CROSS MEMBER	TATA spare parts
275431200114	ASSY CROSS MEMBER (REAR SPRING)	TATA spare parts
275431200115	ASSY CROSS MEMBER WITH SUPPORT	TATA spare parts
275431200116	ASSY.CROSS MEMBER (REAR SPRING-REAR)	TATA spare parts
275431200124	CROSS MEMBER ASSY BUMPER	TATA spare parts
275431200126	CROSS MEMBER ASSY ENGINE MTG REAR	TATA spare parts
275431200129	CROSS MEMBER ASSY	TATA spare parts
275431200131	CROSS MEMBER ASSY WITH GUSSET	TATA spare parts
275431200133	CROSS MEMBER ASSY WITH GUSSET	TATA spare parts
275431200134	CROSS MEMBER ASSY WITH SUPPORT ENG MTG	TATA spare parts
275431200137	BRACKET ASSY LH	TATA spare parts
275431200138	BRACKET ASSY RH	TATA spare parts
275431200140	ASSY BRACKET- RADIATOR MTG RH	TATA spare parts
275431200141	ASSY BRACKET- RADIATOR MTG LH	TATA spare parts
275431200142	ASSY. SUPPORT RH (ENG. MTG. FRONT)	TATA spare parts
275431200146	ASSY SUPPORT (ENGINE CROSS MEMBER REAR)	TATA spare parts
275431200148	CROSS MEMBER ASSY(REAR SPRING-FRONT BKT)	TATA spare parts
275431200149	CROSS MEMBER ASSY(REAR SPRING-FRONT BKT)	TATA spare parts
275431200151	ASSY 4TH CROSS MEMBER	TATA spare parts
275431200152	ASSY. SUPPORT LH (ENG. MTG. FRONT)	TATA spare parts
275431207101	SUPPORT RH	TATA spare parts
275431207102	SUPPORT LH	TATA spare parts
275431207103	REINFORCEMENT LH	TATA spare parts
275431207104	REINFORCEMENT RH	TATA spare parts
275431207105	SUPPORT RH(BUMPER CROSS MEMBER)	TATA spare parts
275431207106	SUPPORT LH (BUMPER CROSS MEMBER)	TATA spare parts
275431207107	ENGINE CROSS MEMBER FORNT	TATA spare parts
275431207109	BRACKET RH(ENGINE C.M.FRONT REAR MTG)	TATA spare parts
275431207110	BRACKET LH ENG CM FRT REAR MTG	TATA spare parts
275431207111	BRACKET RH (ENGINE C.M.FRONT FT.MTG)	TATA spare parts
275431207112	BRACKET LH ENG CMFRT MTG	TATA spare parts
275431207115	SUPPORT -LH	TATA spare parts
275431207116	SUPPORT -RH	TATA spare parts
275431207126	REINFROCEMENT LH	TATA spare parts

275431207134	END CROSS MEMBER-195 DEEP TAIL END	TATA spare parts
275431207173	REINFORCEMENT BOTTOM REAR-RH	TATA spare parts
275431207174	REINFORCEMENT BOTTOM REAR-LH	TATA spare parts
275431207175	REINFORCEMENT BOTTOM REAR-RH	TATA spare parts
275431207176	REINFORCEMENT BOTTOM REAR-LH	TATA spare parts
275431207178	SPACER (REAR)	TATA spare parts
275431207186	REINFORCEMENT RH (SHOCK ABS. FRONT)	TATA spare parts
275431207187	REINFORCEMENT LH (SHOCK ABS. FRONT)	TATA spare parts
275431207190	REINFORCEMENT BOTTOM RH	TATA spare parts
275431207191	REINFORCEMENT BOTTOM LH	TATA spare parts
275431207192	REINFORCEMENT RH	TATA spare parts
275431207193	REINFORCEMENT LH	TATA spare parts
275431207194	SPACER (FRONT)	TATA spare parts
275431207199	REINFROCEMENT RH	TATA spare parts
275431208207	END CROSS MEMBER	TATA spare parts
27543120820735	END CROSS MEMBER UNPAINTED	TATA spare parts
275431217101	END CROSS MEMBER( 195 DEEP TAIL END)	TATA spare parts
275431217102	SPACER PLATE FRONT	TATA spare parts
275431217103	SPACER PLATE REAR	TATA spare parts
275431307102	REINFORCEMENT TOP RH	TATA spare parts
275431307103	REINFORCEMENT TOP LH	TATA spare parts
275431307104	REINFORCEMENT BOTTOM RH	TATA spare parts
275431307105	REINFORCEMENT BOTTOM LH	TATA spare parts
275431307111	GUSSET PLATE TOP-RH	TATA spare parts
275431307112	GUSSET PLATE TOP-LH	TATA spare parts
275431307115	REINFORCEMENT BUMPER CROSS MEMBER RH	TATA spare parts
275431307116	REINFORCEMENT BUMPER CROSS MEMBER LH	TATA spare parts
275431307127	GUSSET SPRING CROSS MEMBER REAR	TATA spare parts
275431308201	SPACER PLATE	TATA spare parts
275431506701	COUPLING PIN	TATA spare parts
275431700101	ASSY. GUARD	TATA spare parts
275431700113	BRACKET ASSY RADIATOR MTG RH	TATA spare parts
275431700114	BRACKET ASSY RADIATOR MTG LH	TATA spare parts
275431700115	BRACKET ASSY RADIATOR MTG LH	TATA spare parts
275431700116	BRACKET ASSY RAIDATOR MTG RH	TATA spare parts
275431700118	BRACKET ASSY RADIATOR MTG	TATA spare parts
275431707111	SUPPORT PLATE	TATA spare parts
275432100106	PARABOLIC LEAF SPRING ASSY	TATA spare parts
275432100107	1ST LEAF WITH BUSH	TATA spare parts
275432100108	FRONT SPRING ASSY	TATA spare parts
275432100120	LEAF SPRING ASSY FRONT	TATA spare parts
275432100121	1ST LEAF ASSY WITH BUSH	TATA spare parts
275432100130	PARABOLIC LEAF SPRING ASSY	TATA spare parts
275432103201	CENTER BOLT	TATA spare parts
275432103202	CENTER BOLT	TATA spare parts
275432103701	BRACKET FRONT SPRING HANGER	TATA spare parts
275432107101	CASTER PLATE	TATA spare parts

275432107103	2ND LEAF	TATA spare parts
275432107104	3RD LEAF	TATA spare parts
275432107105	4TH LEAF	TATA spare parts
275432107106	5TH LEAF	TATA spare parts
275432107107	6TH LEAF	TATA spare parts
275432107108	7TH LEAF	TATA spare parts
275432107109	8TH LEAF	TATA spare parts
275432107110	9TH LEAF	TATA spare parts
275432107111	10TH LEAF	TATA spare parts
275432107112	11TH LEAF	TATA spare parts
275432107113	12TH LEAF	TATA spare parts
275432107129	5TH LEAF	TATA spare parts
275432107130	9TH LEAF	TATA spare parts
275432107131	4TH LEAF	TATA spare parts
275432107132	10TH LEAF	TATA spare parts
275432107133	3RD LEAF	TATA spare parts
275432107134	6TH LEAF	TATA spare parts
275432107135	8TH LEAF	TATA spare parts
275432107136	7TH LEAF	TATA spare parts
275432107137	2ND LEAF	TATA spare parts
275432107138	11TH LEAF	TATA spare parts
275432300101	BRACKET LH	TATA spare parts
275432300102	BRACKET RH	TATA spare parts
275432300105	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
275432300108	BRACKET ASSY FRONT SHOCK ABSORBER MTG	TATA spare parts
275432400104	1ST LEAF ASSY WITH BUSH	TATA spare parts
275432400105	REAR SPRING ASSY	TATA spare parts
275432400111	1ST LEAF ASSY WITH BUSH	TATA spare parts
275432400112	REAR SPRING ASSY	TATA spare parts
275432403201	CENTER BOLT	TATA spare parts
275432403203	CENTER BOLT	TATA spare parts
275432404201	U-CLAMP	TATA spare parts
275432404203	U-CLAMP	TATA spare parts
275432404204	U-CLAMP	TATA spare parts
275432407102	2ND LEAF	TATA spare parts
275432407103	3RD LEAF	TATA spare parts
275432407104	4TH LEAF	TATA spare parts
275432407105	5TH LEAF	TATA spare parts
275432407106	6TH LEAF	TATA spare parts
275432407107	7TH LEAF	TATA spare parts
275432407108	8TH LEAF	TATA spare parts
275432407109	9TH LEAF	TATA spare parts
275432407110	10TH LEAF	TATA spare parts
275432407111	11TH LEAF	TATA spare parts
275432407112	12TH LEAF	TATA spare parts
275432407113	13TH LEAF	TATA spare parts
275432407114	1ST LEAF AUX SPRING	TATA spare parts

275432407115	2ND LEAF AUX SPRING	TATA spare parts
275432407116	3RD LEAF AUX SPRING	TATA spare parts
275432407117	4TH LEAF AUX SPRING	TATA spare parts
275432407118	5TH LEAF AUX SPRING	TATA spare parts
275432407119	6TH LEAF AUX SPRING	TATA spare parts
275432407120	7TH LEAF AUX SPRING	TATA spare parts
275432407124	2ND LEAF	TATA spare parts
275432407125	6TH LEAF	TATA spare parts
275432407126	3RD LEAF AUX SPRING	TATA spare parts
275432407127	4TH LEAF	TATA spare parts
275432407128	3RD LEAF	TATA spare parts
275432407129	6TH LEAF AUX SPRING	TATA spare parts
275432407130	7TH LEAF AUX SPRING	TATA spare parts
275432407131	2ND LEAF AUX SPRING	TATA spare parts
275432407132	10TH LEAF	TATA spare parts
275432407133	5TH LEAF	TATA spare parts
275432407134	7TH LEAF	TATA spare parts
275432407135	9TH LEAF	TATA spare parts
275432407136	11TH LEAF	TATA spare parts
275432407137	12TH LEAF	TATA spare parts
275432407138	5TH LEAF AUX SPRING	TATA spare parts
275432407139	8TH LEAF	TATA spare parts
275432407140	4TH LEAF AUX SPRING	TATA spare parts
275432407141	1ST LEAF AUX SPRING	TATA spare parts
275433000103	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
275433000104	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
275433000105	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
275433000108	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
275433105102	FRONT AXLE BEAM BS6 PH2	TATA spare parts
275433800101	ASSY. TIE ROD STRAIGHT BS1/2/3/4	TATA spare parts
275433800102	ASSY TIE ROD STRAIGHT	TATA spare parts
275433800103	ASSY TIE ROD STRAIGHT	TATA spare parts
275433805101	STEERING ARM	TATA spare parts
275440100104	WHEEL RIM ASSY	TATA spare parts
275441100101	ASSY.PROP.SHAFT FRONT	TATA spare parts
275441100103	ASSY.PROP.SHFT.WITH CNTR.BRG	TATA spare parts
275441100104	GUARD ASSY PROPELLER SHAFT	TATA spare parts
275441100106	CENTER BEARING ASSY	TATA spare parts
275441100107	U.J.ASSY	TATA spare parts
275441100108	ASSY. COUPLING FLANGE BS2/3/4	TATA spare parts
275441100114	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
275441100116	SHORT FORK TUBE & REAR HSG SUB ASSY	TATA spare parts
275441100117	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
275441100118	PROPELLER SHAFT ASSY FRONT	TATA spare parts
275441100119	PROPELLER SHAFT ASSY MIDDLE	TATA spare parts
275441107101	SPACER(FOR PROP.SHAFT CENTRE BEARING)	TATA spare parts
275441109801	SHORT FORK TUBE AND FRT END PIECE SUB AS	TATA spare parts

275441109802	SHORT FORK TUBE AND FRT END PIECE SUB AS	TATA spare parts
275441109901	HEX NUT	TATA spare parts
275441110101	APSC 1615LPT48 90X3 1255 WITH CENT. BRG.	TATA spare parts
275441110104	P/SHAFT FRT WCB 90X3X160	TATA spare parts
275441110109	830 90 DIA ASSY P/SHAFT WITH C BEARING	TATA spare parts
275441110122	ASSY PROPELLER SHAFT WITH CENTRE BEARING	TATA spare parts
275441110125	ASSY PROPELLER SHAFT MIDDLE	TATA spare parts
275441110126	ASSY PROP SHAFT WITH C.B.	TATA spare parts
275441110127	ASSY PROPELLER SHAFT FRONT	TATA spare parts
275441110128	ASSY PROPELLER SHAFT FRONT	TATA spare parts
275441110129	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
275441110140	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
275441110146	SHORT FORK	TATA spare parts
275441110147	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
275441110148	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
275441110153	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
275441110163	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
275441110164	PROPELLER SHAFT ASSY WITH CB FRONT	TATA spare parts
275441115101	FLANGE YOKE	TATA spare parts
275441120103	1074 90 DIA ASSY P/SHAFT REAR COMP	TATA spare parts
275441120104	ASSY.PROP.SHAFT REAR	TATA spare parts
275441120106	ASSY.REAR PROPELLER SHAFT	TATA spare parts
275441120108	CROSS ASSY	TATA spare parts
275441120109	REAR HOUSING	TATA spare parts
275441120110	DUST COVER	TATA spare parts
275441120111	ASSY PROPELLER SHAFT REAR	TATA spare parts
275441120112	SHORT FORK TUBE & REAR HSG SUB ASSY	TATA spare parts
275441120119	PROPELLER SHAFT ASSY REAR	TATA spare parts
275441120121	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
275441120128	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
275441120129	PROPELLER DRIVE SHAFT ASSY	TATA spare parts
275441125101	FLANGE YOKE REAR	TATA spare parts
275441129801	SHORT FORK TUBE AND REAR HSG SUB ASSY	TATA spare parts
275441200101	ASSY PROPELLER SHAFT REAR	TATA spare parts
275441303301	BRACKET(FOR CENTRE BEARING)	TATA spare parts
275441303302	BRACKET(CENTRE BEARING) BS6	TATA spare parts
275441303306	BRACKET (CENTRE BEARING )	TATA spare parts
275441303307	BRACKET (CENTRE BEARING )	TATA spare parts
275441303311	BRACKET ASSY CENTRE BEARING MTG REAR	TATA spare parts
275441303312	BRACKET ASSY CENTRE BEARING MTG FRONT	TATA spare parts
275441303313	BRACKET CENTER BEARING	TATA spare parts
275441303314	BRACKET CENTER BRG MTG	TATA spare parts
275441303315	BRACKET CENTER BRG MTG	TATA spare parts
275441308201	PROPELLER SHAFT GUARD	TATA spare parts
275441308202	PROPELLER SHAFT GUARD SUPPORT BRACKET	TATA spare parts
275441308203	PROPELLR SHAFT GUARD	TATA spare parts
275441990104	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts



275441990105	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
275441990106	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
275441995101	FLANGE YOKE	TATA spare parts
275441995102	COUPLING FLANGE ASSY	TATA spare parts
275441995103	FLANGE YOKE	TATA spare parts
275442300106	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
275442300107	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
275442303706	PLUMMER BLOCK BS6	TATA spare parts
275442400101	ASSY.BRACKET	TATA spare parts
275442400102	ASSY. BRACKET	TATA spare parts
275442403301	BRACKET.	TATA spare parts
275442900106	PIPE A/TANK TO C/BODY	TATA spare parts
275442900129	COATED CLAMP-DOUBLE 12 X 12	TATA spare parts
275442900130	COATED CLAMP-DOUBLE 6 X 6	TATA spare parts
275442900131	ASSY. TUBE	TATA spare parts
275442900132	ASSY. TUBE	TATA spare parts
275442900134	PIPE ISO VALVE TO BODY	TATA spare parts
275442900136	ASSY. TUBE	TATA spare parts
275442900137	ASSY. TUBE	TATA spare parts
275442900140	ASSY. TUBE ( 12 O.D.)	TATA spare parts
275442900142	ASSY. TUBE	TATA spare parts
275442900143	ASSY. TUBE	TATA spare parts
275442900145	ASSY. TUBE	TATA spare parts
275442900150	TUBE ASSY	TATA spare parts
275443200103	ASSY SUPPORT-AIR TANK MOUNTING	TATA spare parts
275443700101	L C R VALVE	TATA spare parts
275443700110	RELAY VALVE (VOSS)	TATA spare parts
275443700112	RELAY VALVE (VOSS)	TATA spare parts
275443700113	RELAY VALVE BS6	TATA spare parts
275443700115	RELAY VALVE (VOSS)(ON REAR SIDE)	TATA spare parts
275443700132	GRAD HAND CONTROL VALVE SELF RET-BIPOLAR	TATA spare parts
275443703301	BRACKET FOR RELAY AND MODULATOR VALVE	TATA spare parts
275443900110	ASSY TUBE(15 O.D. X 2520 LG)	TATA spare parts
275443900111	ASSY TUBE(15 O.D. X 2170 LG)	TATA spare parts
275443900113	ASSY. NYLON PIPE SET COMPLETE	TATA spare parts
275443900127	ASSY.COMP.PIPE 2ND	TATA spare parts
275443900128	ASSY. COMP PIPE - 3RD	TATA spare parts
275443900132	ASSY.COMP.PIPE 2ND	TATA spare parts
275443900133	ASSY.COMP.PIPE 3RD	TATA spare parts
275443900139	ASSY. COMP PIPE - 2ND	TATA spare parts
275443900140	ASSY. COMP PIPE - 3RD	TATA spare parts
275443900141	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
275443900144	ASSY. COMPRESSOR 3RD PIPE	TATA spare parts
275443900145	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
275443900147	SET-NYLON PIPE ASSY CHASSIS LPT1615 BS-I	TATA spare parts
275443900192	METAL PIPE ASSY	TATA spare parts
275443900193	METAL PIPE ASSY	TATA spare parts

275443900225	PIPE BUNCH ASSY FOR LPT1615 ABS	TATA spare parts
275443900226	METAL PIPE ASSY JOINT-2 TO DDU	TATA spare parts
275443910106	ASSY COMP INLET PIPE	TATA spare parts
275443910107	ASSY COMP OUTLET 3RD PIPE	TATA spare parts
275443910111	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
275443910115	PIPE BUNCH ASSY	TATA spare parts
275443910167	NYLON PIPE BUNCH ASSY	TATA spare parts
275443910171	NYLON PIPE BUNCH ASSY	TATA spare parts
275443920101	ASSY KIT FOR PRESSURE TEST CONNECTOR	TATA spare parts
275443920103	METAL PIPE ASSY	TATA spare parts
275443920104	METAL PIPE ASSY	TATA spare parts
275443920105	METAL PIPE ASSY JOINT 1 TO JOINT 2	TATA spare parts
275443920127	PIPE BUNCH ASSY	TATA spare parts
275443920135	METAL PIPE ASSY JOINT 1 TO JOINT 2	TATA spare parts
275443920136	METAL PIPE ASSY JOINT TO DDU	TATA spare parts
275443920153	PIPE BUNCH ASSY	TATA spare parts
275443920161	METAL PIPE ASSY	TATA spare parts
275443920165	PIPE BUNCH ASSY	TATA spare parts
275443920191	PIPE BUNCH ASSY	TATA spare parts
275443930121	METAL PIPE ASSY	TATA spare parts
275446000108	ASSY.STEERING KIT RHD	TATA spare parts
275446100106	ASSY STG. GEAR BOX & CONTROL MTG. BKT.	TATA spare parts
275446100114	ASSY.STG.GEAR BOX & CONTROL MTG.BKT.	TATA spare parts
275446150102	ASSY.KIT P/STG.LINES & CONNECTORS	TATA spare parts
275446600101	ASSLY.POWER STEERING PUMP BS1/2/3/4	TATA spare parts
275446600102	VANE PUMP DIRECT DRIVE	TATA spare parts
275446600103	ASSY. VANE PUMP BS1/2/3/4	TATA spare parts
275446600103AE	STEERING PUMP 1415 713 2523 715	TATA spare parts
275446600104	KIT-HOUSING ASSY	TATA spare parts
275446600105	PLUG ASSY	TATA spare parts
275446600106	STEERING GEAR BOX ASSY	TATA spare parts
275446600108	PISTON ASSY BS6	TATA spare parts
275446600109	SET STEERING COMPONENT SET BS6	TATA spare parts
275446600111	STEERING GEAR BOX ASSY	TATA spare parts
275446600112	STEERING GEAR BOX ASSY	TATA spare parts
275446600114	HOUSING ASSY	TATA spare parts
275446603702	HOUSING	TATA spare parts
275446609912	SHAFT	TATA spare parts
275446609913	BALL BEARING	TATA spare parts
275446609914	SNAP RING	TATA spare parts
275446609915	RETAINING RING	TATA spare parts
275446609916	SHAFT SEAL	TATA spare parts
275446609917	HOUSING ASSLY.	TATA spare parts
275446609920	NEEDLE SLEEVE	TATA spare parts
275446609921	DOWEL PIN	TATA spare parts
275446609922	PRESSURE PLATE-R	TATA spare parts
275446609923	PRESSURE PLATE	TATA spare parts

275446609924	ROTOR SET ASSLY	TATA spare parts
275446609925	FRONT PLATE - R	TATA spare parts
275446609926	FRONT PLATE - L	TATA spare parts
275446609927	COMPRESSION SPRING	TATA spare parts
275446609928	COVER	TATA spare parts
275446609929	HOOK SNAP SPRING	TATA spare parts
275446609930	SEALING RING	TATA spare parts
275446609931	SCREW PLUG M16X1.5	TATA spare parts
275446609932	SCREW PLUG M26X1.5	TATA spare parts
275446609933	SCREW PLUG	TATA spare parts
275446609934	FLOW LIMITING PISTON	TATA spare parts
275446609935	COMPRESSION SPRING	TATA spare parts
275446609936	MAJOR SEAL KIT	TATA spare parts
275446609937	SMALL COMPONENT KIT	TATA spare parts
275446609938	COUPLING	TATA spare parts
275446609939	PROFILE SEALING RING	TATA spare parts
275446609940	O RING	TATA spare parts
275446609941	O RING	TATA spare parts
275446609942	SUPPORT RING	TATA spare parts
275446609943	ROTOR SET KIT	TATA spare parts
275446609944	ROTOR SET KIT	TATA spare parts
275446800113	COATED CLAMP(13X13)	TATA spare parts
275446800114	ASSY.CLAMP.(FOR 18 O.D.PIPE)	TATA spare parts
275446800121	ASSY.TUBE	TATA spare parts
275446800142	ASSY.SUCTION LINE.(P/STG.TANK TO PUMP)	TATA spare parts
275446800143	ASSY.PRESSURE LINE.(PUMP TO G.B)	TATA spare parts
275446800144	ASSY.RETURN LINE (G.B TO TANK)	TATA spare parts
275446800156	ASSY PIPES & CLAMPS COMPLETE	TATA spare parts
275446804201	CLAMP	TATA spare parts
275446804203	CLAMP	TATA spare parts
275446808203	BRACKET	TATA spare parts
275446990103	HOUSING ASSY	TATA spare parts
275446990104	SHAFT ASSY	TATA spare parts
275446990105	CARTRIDGE ASSY	TATA spare parts
275446990108	BALL JOINT ASSY RH	TATA spare parts
275446990109	BALL JOINT ASSY LH	TATA spare parts
275446990146	SHAFT ASSY BS6	TATA spare parts
275446990147	KIT-SEAL BS6	TATA spare parts
275446990148	WORM & VALVE HSG WITH RACK ASSY BS6	TATA spare parts
275446990149	HOUSING ASSY BS6	TATA spare parts
275446994601	DRIVE COUPLING DISC	TATA spare parts
275446998001	ALLEN SCREW	TATA spare parts
275447600136	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
275447600137	SUCTION PIPE ASSY TANK TO FILTER	TATA spare parts
275447600149	ASSY SUCTION LINE-BABY FILT.TO FUEL TANK	TATA spare parts
275447600150	ASSY.RETURN LINE ( FUEL TANK TO FIP )	TATA spare parts
275447600151	ASSY. TUBE WITH CRIMPED RUBBER HOSE	TATA spare parts

275447600152	ASSY.TUBE WITH CRIMPED R/HOSE	TATA spare parts
275447600153	ASSY.TUBE WITH CROMPED R/HOSE	TATA spare parts
275447600157	ASSY SUCTION LINE(F/TANK TO F/ HEATER)	TATA spare parts
275447600158	ASSY SUCTION LINE(F/HEATER-BABY/FIL)	TATA spare parts
275447600159	ASSY RETURN LINE ( FUEL TANK TO FIP )	TATA spare parts
275447600160	ASSY. SUCTION LINE	TATA spare parts
275447600161	ASSY. SUCTION LINE	TATA spare parts
275447600162	ASSY. RETURN LINE	TATA spare parts
275447600164	FUEL PIPE LINE ASSY TANK TO WS	TATA spare parts
275447600165	FUEL PIPE LINE ASSY WS TO ENGINE	TATA spare parts
275447600166	FUEL PIPE LINE ASSY RETURN LINE ASSY	TATA spare parts
275447600171	FUEL RETURN PIPE ASSY	TATA spare parts
275447600172	SUCTION PIPE FILTER TO ENGINE RIVIGO	TATA spare parts
275447600173	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
275447600174	SUCTION PIPE ASSY TANK TO FILTER	TATA spare parts
275447600176	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
275447600177	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
275447600178	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
275447605801	HOSE A/C-18DIA X 200L	TATA spare parts
275447608202	BRACKET BS6	TATA spare parts
275447608203	BRACKET	TATA spare parts
275447700102	BRACKET ASSY	TATA spare parts
275449100105	SILENCER W/TAIL PIPE	TATA spare parts
275449100106	ASSY.SILENCER	TATA spare parts
275449100110	ASSY.SILENCER WITH TAIL PIPE	TATA spare parts
275449100111	ASSY.SILENCER WITH TAIL PIPE (LHD)	TATA spare parts
275449100116	ASSY. INTERMEDIATE PIPE	TATA spare parts
275449100118	ASSY THIRD PIPE (AT SILENCER PORT)	TATA spare parts
275449100119	ASSY.EXHAUST.PIPE SECOND(81.2ODX1.6THK)	TATA spare parts
275449100121	ASSY EXHAUST PIPE SECOND (81.2 O.D.)	TATA spare parts
275449100133	SPARK ARRESTER ASSY	TATA spare parts
275449105301	GASKET	TATA spare parts
275449200102	EXHAUST PIPE FRONT	TATA spare parts
275449200103	ASSY BRACKET	TATA spare parts
275449200107	ASSY.EXHAUST PIPE	TATA spare parts
275449200108	TAIL PIPE ASSY	TATA spare parts
275449200109	ASSY BRACKET	TATA spare parts
275449200116	ASSY BRACKET	TATA spare parts
275449200129	ASSY. EXHAUST PIPE (LHD)	TATA spare parts
275449200131	ASSY.BRACKET	TATA spare parts
275449200132	EXHAUST PIPE ASSY	TATA spare parts
275449200138	ASSY. INT. FLANGE 2516	TATA spare parts
275449200139	ASSY. SHAFT THROTTLE VALVE	TATA spare parts
275449200146	ASSY.EXHAUST PIPE (76.2 OD X 1.6 THK.)	TATA spare parts
275449200148	EXH PIPE INTERMEDIATE	TATA spare parts
275449200149	ASSY.EXHAUST PIPE (76.2 OD X 1.6 THK)	TATA spare parts
275449200150	ASSY.EXHUAST PIPE (76.2 OD X 1.6 THK.)	TATA spare parts

275449200157	ASSY. PIPE	TATA spare parts
275449200159	ASSY EXHAUST FIRST PIPE	TATA spare parts
275449200160	ASSY. BRACKET (EXHAUST -TAIL PIPE MTG.)	TATA spare parts
275449200161	ASSY EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
275449200162	ASSY. EXHAUST PIPE	TATA spare parts
275449200163	PIPE ASSY T-CONNECTOR TO AIR OIL FILTER	TATA spare parts
275449200164	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
275449200170	BRACKET ASSY (TAIL PIPE MTG)	TATA spare parts
275449200171	EXHAUST PIPE ASSY (THIRD)	TATA spare parts
275449200172	EXHAUST PIPE ASSY (SECOND)	TATA spare parts
275449200173	BRACKET ASSY TAIL PIPE MTG	TATA spare parts
275449200180	BRACKET ASSY EGP MTG	TATA spare parts
275449200181	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
275449200182	EXHAUST PIPE ASSY SECOND	TATA spare parts
275449203301	BRACKET	TATA spare parts
275449203304	BRACKET	TATA spare parts
275449203306	BRACKET	TATA spare parts
275449203307	BRACKET	TATA spare parts
275449203316	BRACKET	TATA spare parts
275449203317	BRACKET	TATA spare parts
275449203318	BRACKET	TATA spare parts
275449203323	BRACKET (EXHAUST PIPE MTG. ON C/M)	TATA spare parts
275449203324	BRACKET	TATA spare parts
275449203334	BRACKET EXHAUST PIPE MTG	TATA spare parts
275449203335	BRACKET TAIL PIPE	TATA spare parts
275449203704	THROTTLE VALVE	TATA spare parts
275449203705	FLANGE INTERMED W/O BUSH	TATA spare parts
275449204201	CLAMP	TATA spare parts
275449206701	PIN	TATA spare parts
275449206932	EXHAUST PIPE	TATA spare parts
275449208206	BRACKET	TATA spare parts
275449208207	BRACKET	TATA spare parts
275449208208	BRACKET	TATA spare parts
275449208209	STOPPER PLATE	TATA spare parts
275449208214	BRACKET	TATA spare parts
275449208221	SUPPORT BRACKET	TATA spare parts
275449208223	BKACKET- TFF BS6	TATA spare parts
275449990101	KIT HEAT SHIELD FOR SILENCER &EXH PIPE	TATA spare parts
275450000101	ASSY.RADIATOR FRAME	TATA spare parts
275450000104	BRACKET-LH (RAD.FRAME SIDE MTG.)	TATA spare parts
275450000105	BRACKET-RH (RAD.FRAME SIDE MTG.)	TATA spare parts
275450100102	KIT ENGINE COOLING SYSTEM	TATA spare parts
275450105801	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
275450506301	FANSHROUD	TATA spare parts
275454100101	ASSY COPPER BATTERY CABLE	TATA spare parts
275454100102	ASSY COPPER BATTERY CABLE	TATA spare parts
275454100109	BATT CABLE	TATA spare parts

275454100120	ASSY BATTERY CABLE CU +VE (50 MM) BS6	TATA spare parts
275454108227	W/H POWER CABLE	TATA spare parts
275454108228	W/H POWER CABLE-2	TATA spare parts
275454108232	ASSY BATTERY CABLE VE	TATA spare parts
275454109902	BATT.12V 180AH EXIDE PP DRY CHARGED	TATA spare parts
275454200101	ASSY BRACKET-STARTER RELAY	TATA spare parts
275454200102	ASSY BRACKET [BUZZER & BEEPER]	TATA spare parts
275454200120	INSTRUMENT CLUSTER INT. HARDWARE BS4	TATA spare parts
275454200128	INSTRUMENT CLUSTER INTERFACE HARDWARE BS	TATA spare parts
275454200129	INSTRUMENT CLUSTER INTERFACE HARDWARE&B	TATA spare parts
275454200130	INSTRUMENT CLUSTER INTERFACE HARDWARE BS	TATA spare parts
275454200131	INSTRUMENT CLUSTER INTERFACE HARDWARE BS	TATA spare parts
275454208204	BRACKET (RELAY MOUNTING)	TATA spare parts
275454209901	SPEEDOMETER 6+1 (1:0.88) OFFER	TATA spare parts
275454209902	SPEEDOMETER 6+1-1:0.88	TATA spare parts
275454209903	SPEEDOMETER 6+1-1:0.88	TATA spare parts
275454209904	SPEEDOCABLE 3200MM BS1/2/3	TATA spare parts
275454209905	SPEEDOCABLE (JIS) 3200 LG.	TATA spare parts
275454209906	SPEEDOCABLE (JIS) 3200 LG.	TATA spare parts
275454209907	SPEEDOMETER 6+1 DIGIT 0.91 RATIO-OFFER	TATA spare parts
275454209908	SPEEDOMETER 6+1 DIGIT 0.91 RATIO	TATA spare parts
275454209909	SPEEDOMETER 6+1-1:0.91	TATA spare parts
275454209912	ELECTRICAL TEMP.GAUGE 12V-OFFER	TATA spare parts
275454209915	ELECTRICAL TEMP GAUGE-12V	TATA spare parts
275454209938	WATER-IN-FUEL IND-12V/24V	TATA spare parts
275454309901	TEMPERATURE TRANSDUCER BS1/2/3/4	TATA spare parts
275454309901AE	TEMPERATURE TRANSDUCER 715	TATA spare parts
275454309902	TEMP TRANSDUCER	TATA spare parts
275454309903	TEMPERATURE TRANSDUCER	TATA spare parts
275454400105	ASSY H/LAMP-LH(RHD)E-CERT W/BULB	TATA spare parts
275454400106	ASSY H/LAMP-RH(RHD)E-CERT W/BULB	TATA spare parts
275454400116	ASSY FRONT FOG LAMP	TATA spare parts
275454400125	ASSY.MOTORISED H/L 12V E BLB LH-RHD	TATA spare parts
275454400126	ASSY.MOTORISED H/L 12V E BLB RH-RHD-	TATA spare parts
275454400127	ASSY MOTORISED H/L COMPLT.12V LH-RHD-	TATA spare parts
275454400128	ASSY MOTORISED H/L COMPLT.12V RH-RHD	TATA spare parts
275454400133	ASSY.MOTORISED H/L 12V E CERT LH-RHD	TATA spare parts
275454400134	ASSY.MOTORISED H/L 12V E CERT RH-RHD	TATA spare parts
275454400141	ASSY.H/L N/MOTRSD 12V W/O RIM RHD LH	TATA spare parts
275454400142	ASSY.H/L N/MOTRSD 12V W/O RIM RHD RH	TATA spare parts
275454440109	ASSY MOTORISED H/L COMPLT.24V LH-RHD	TATA spare parts
275454440110	ASSY MOTORISED H/L COMPLT.24V RH-RHD	TATA spare parts
275454440113	ASSY MOTORISED H/L COMPLT.24V LH-RHD	TATA spare parts
275454440114	ASSY MOTORISED H/L 24V COMPLT.RH-RHD	TATA spare parts
275454504901	STARTER RALAY	TATA spare parts
275454506906	PIANO KEY SWITCH	TATA spare parts
275454506907	PIANO KEY SW- FRONT FOG LAMP	TATA spare parts

275454506918	PIANO KEY SW.- FRONT FOG LAMP	TATA spare parts
275454600105	CABLE SET ENGINE STOP SOL	TATA spare parts
275454600120	ASSY MAIN CABLE SET-LHD IN-LINE FIP	TATA spare parts
275454600127	WIRING HARNESS MAIN	TATA spare parts
275454600134	WIRING HARNESS ABS FRAME	TATA spare parts
275454600137	WIRING HARNESS ASSY MAIN	TATA spare parts
275454600141	BRACKET MEGA FUSE BOX MTG	TATA spare parts
275454600165	WIRING HARNESS TAIL	TATA spare parts
275454600166	WIRING HARNESS SCR UNIT	TATA spare parts
275454600169	WIRING HARNESS ABS FRAME	TATA spare parts
275454600170	WIRING HARNESS TAIL	TATA spare parts
275454600171	WIRING HARNESS TAIL	TATA spare parts
275454600178	BATTERY CABLE +VE	TATA spare parts
275454600179	WIRING HARNESS TAIL BS6	TATA spare parts
275454601639	BATTERY CABLE ASSY	TATA spare parts
275454607501	RUBBER SLEEVE	TATA spare parts
275454620109	W/H MAIN(LPT1615TC F/FIGHTER)	TATA spare parts
275454620111	W/H MAIN LPT-1615TC BSII 12V	TATA spare parts
275454620112	WIRING HARNESS TAIL	TATA spare parts
275454620113	WIRING HARNESS ROOF	TATA spare parts
275454620116	WIRING HARNESS MAIN	TATA spare parts
275454620124	WIRING HARNESS ABS FRAME	TATA spare parts
275454640118	ASSY CABLE SET-FRT TO TAIL	TATA spare parts
275454660105	WIRING HARNESS ENGINE	TATA spare parts
275454660109	W/H MAIN-LHD (LPT1615TC)	TATA spare parts
275458900101	SET-ENGINE SUPPORT BRACKET	TATA spare parts
275460100101	CAB COMPLETE RHD LPT1615TC NSLPR	TATA spare parts
275460100117	ASSY. CAB COMPLETE LHD 1615 TC PTO	TATA spare parts
275460100126	ASSY.CAB COMPLETE RHD LPT1615TC	TATA spare parts
275460100137	ASSY BARE CAB 1615TC LHD	TATA spare parts
275460100140	BARE CAB RHD LPT1615TC NSLPR	TATA spare parts
275460100141	ASSY.BODY SHELL PAINTED LPT1615-LHD	TATA spare parts
275460100144	BODY SHELL PAINTED RHD	TATA spare parts
275460100145	ASSY NON SLEEPER BARE CAB LPK 1615TC LHD	TATA spare parts
275460100146	ASSY BARE CAB LPK1615	TATA spare parts
275460100167	ASSY LIFTING HOOK-REAR	TATA spare parts
275460100168	ASSY CAB COMPLETE-RHD	TATA spare parts
275460100169	ASSY BODY SHELL PAINTED-RHD	TATA spare parts
275461000102	ASSY.SUBSTRUCTURE-RHD	TATA spare parts
275461100116	ASSY.BRACKET POWER STEERING TANK MTG.	TATA spare parts
275462000112	FRONT WALL ASSY	TATA spare parts
275462208204	SUPPORT WAIST RAIL BS6-PH2	TATA spare parts
275462508201	PANEL OUTER W/S TOP BS6	TATA spare parts
275464700103	ASSY CORNER PANEL OUTER WITH POST RH LHD	TATA spare parts
275464708201	CORNER PANEL OUTER RH	TATA spare parts
275468400101	ASSY FLOOR MAT RHD	TATA spare parts
275468906301	INSTRUMENT PANEL	TATA spare parts

275472306301	MASCOT 1615TC	TATA spare parts
27548042000RCK	ASSY COWL KIT W/FITMENTS LPT 1615	TATA spare parts
27548052000R40	ASSY COWL COMPLETE W/O FITMENT	TATA spare parts
275481800102	ASSY TATA 1615 MASCOT	TATA spare parts
275481900101	ASSY ENGINE SHIELDING LH RHD	TATA spare parts
275481900103	ASSY ENGINE SHIELDING RH RHD	TATA spare parts
275482400101	ASSY WIPER ARM & BLADE (LHD)	TATA spare parts
275482400102	ASSY WIPER ARM (LHD)(CO-DRIVER)	TATA spare parts
275482409901	WIPER MOTOR 17W 12V(LHD)SINGLE W/S	TATA spare parts
275488700108	NUT PLATE GRAB HANDLE	TATA spare parts
275488700109	ASSY ENGINE HOOD COMPLETE RHD	TATA spare parts
275488700110	ASSY ENGINE HOOD COMPL LHD	TATA spare parts
275488700111	ASSY.NUT PLATE(GRAB HANDLE)	TATA spare parts
275488702003	COMPOSITE INSULATION RH-RHD(E/HOOD)	TATA spare parts
275488706301	ENGINE HOOD RHD	TATA spare parts
275488707703	SEALING RUBBER(ENGINE HOOD)	TATA spare parts
275488708206	PLATE ENGINE HOOD	TATA spare parts
275489100101	ASSY BRKT REAR LH-CAB MTG & SHOCK ABSORB	TATA spare parts
275489100102	ASSY BRKT REAR RH-CAB MTG & SHOCK ABSORB	TATA spare parts
275489100103	ASSY.BRKT.COWL MTG.& SHOCK ABSORBER LH-R	TATA spare parts
275489100104	ASSY.BRKT.COWL MTG.& SHOCK ABSORBER-RH-R	TATA spare parts
275489100107	ASSY.BRACKET REAR-LH	TATA spare parts
275489100108	ASSY.BRACKET REAR-RH	TATA spare parts
275491500108	KIT SEAT BELTS COMPLETE	TATA spare parts
275491500116	ASSY. SEAT BELT COMPLETE DRIVER BS1-6	TATA spare parts
275491500119	SEAT BELT ASSY WITH ELR FRONT-RH BS6-PH2	TATA spare parts
275491500122	CABLE BUCKLE ASSY DRIVER SEAT BS6-PH2	TATA spare parts
275525103701	CLUTCH HOUSING LP1312TC BS1/2/3/4	TATA spare parts
275525108201	COVER	TATA spare parts
275525108202	COVER (CL. HSG-LOWER)	TATA spare parts
275526706001	SHIFT LEVER SEL&SH SHAFT	TATA spare parts
275526707901	LINK ROD	TATA spare parts
275526710101	BRACKET ASSY	TATA spare parts
275526710103	ASSY BRACKET	TATA spare parts
275526800101	ASSY.TURNING ROD RHD	TATA spare parts
275526800103	SEL & SHIFT FORK W/LEVER	TATA spare parts
275526800105	BRACKET ASSY	TATA spare parts
275529100104	CLUTCH SLAVE CYLINDER ASSY	TATA spare parts
275529100105	PULL ROD ASSY	TATA spare parts
275529100111	ASSY TUBE	TATA spare parts
275529100113	BUNDY TUBE	TATA spare parts
275529106001	PUSH ROD	TATA spare parts
275529106901	TUBE	TATA spare parts
275531207106	SUPPORT ENGINE X MEMBER	TATA spare parts
275541110107	PROP SHAFT ASSY 90 DIA	TATA spare parts
275541110108	PROP SHAFT MIDDLE 1312TC	TATA spare parts
275541120101	PROP SHAFT REAR COMP	TATA spare parts



275541303302	CENTRE BRG. BRACKET	TATA spare parts
275546600101	VANE PUMP DIR DRIVE	TATA spare parts
275546604601	COUPLING	TATA spare parts
275549207102	PLATE	TATA spare parts
275554209905	SPEEDOMETER (1:1.0625) OFFER	TATA spare parts
275554209906	SPEEDOMETER-1:1.0625	TATA spare parts
275554209907	SPEEDOMETER-1:1.0625	TATA spare parts
275554209908	RPM METER-12V (1600-2200 RPM G.B.) OFFER	TATA spare parts
275554209909	R.P.M.METER	TATA spare parts
275554209910	RPM METER-12V-1600-2200 RPM	TATA spare parts
275554209911	RPM METER 24V-1400-2200 RPM	TATA spare parts
275554209912	SPEEDOMETER-1:1.0625	TATA spare parts
275554506901	PIANO KEY SWITCH	TATA spare parts
275554506902	PIANO KEY SWITCH	TATA spare parts
275554506903	PIANO KEY SWITCH	TATA spare parts
275554506904	PIANO SWITCH	TATA spare parts
275554820101	MAIN CABLE SET RHD LP1312	TATA spare parts
275554820102	CABLE SET FRT TO TAIL 52	TATA spare parts
275554820104	ASSY.CABLE SET [PANEL LAMP]	TATA spare parts
275554820111	ASSY CABLE SET(FRT TO TAIL	TATA spare parts
275554820114	CABLE SET GAUGE EARTH	TATA spare parts
275554820115	ASSY CABLE SET-PANEL LAMPS	TATA spare parts
275554820116	CABLE SET ENG STOP SOLENOID	TATA spare parts
275568900101	INSTRUMENT PANEL RHD	TATA spare parts
275581806301	MASCOT 1312TC	TATA spare parts
275581900101	ASSY ENGINE SHIELDING RH RHD	TATA spare parts
275583800103	ASSY.FRONT PANEL COMPL.WITH VENT.UNIT-RH	TATA spare parts
275583806303	COVER AIR FILTER LH RHD	TATA spare parts
275588707701	SEALING RUBBER ENG HOOD	TATA spare parts
275641120102	ASSY. PROP.SHAFT REAR L=1738	TATA spare parts
275642900117	ASSY. TUBE	TATA spare parts
275642900181	ASSY.TUBE-15 O.D.	TATA spare parts
275642900183	ASSY.TUBE- 15 O.D.	TATA spare parts
275644100111	ASSY.SWIVEL ELBOW	TATA spare parts
275644106001	FORK HEAD LPK1615TC	TATA spare parts
275644220103	ASSY BRACKETD RHD CONTROL VALVE LINKAGE	TATA spare parts
275644220106	LEVER ASSY	TATA spare parts
275644220110	ASSY.LINK ROD-WITHOUT BALL PIN	TATA spare parts
275647600105	CLAMP	TATA spare parts
275647600111	ASSY. SUCTION LINE	TATA spare parts
275647600114	ASSY.RETURN LINE.	TATA spare parts
275649200101	ASSY.EXHAUST PIPE	TATA spare parts
275654100101	COPPER BATT CABLE +VE	TATA spare parts
275654100102	COPPER BATT CABLE -VE	TATA spare parts
275654660101	WIRING HARNESS MAIN	TATA spare parts
275654660102	WIRING HARNESS TAIL	TATA spare parts
275658900102	TOOL KIT - HCV (DOM)LPT1615/2516/3516/40	TATA spare parts

275658905001	TOOL BAG - HCV EXPORT	TATA spare parts
275725103701	CLUTCH HOUSING	TATA spare parts
275726807901	LINK ROD	TATA spare parts
275754200102	ASSY.BKT.COMPLT.-H/T S/B BUZZ.& WIF.IND	TATA spare parts
275754209904	ELECT.TEMP.GAUGE 12V-BACKLIT	TATA spare parts
275754209905	ELECT.TEMP.GAUGE 12V-BACKLIT	TATA spare parts
275854209901	SPEEDOMETER 1:0.6(6+1DIGIT)BACKLIT	TATA spare parts
275854209902	SPEEDOMETER 1:0.6(6+1DIGIT)BACKLIT	TATA spare parts
276054209903	RPM METER 24V-1400-2200 RPM G.B.	TATA spare parts
276054209906	RPM METER 24V(W/O GREEN BAND)	TATA spare parts
276054209907	RPM METER 24V-1400-2200 RPM	TATA spare parts
276054400102	ASSY HATCH BACK LAMP 24V	TATA spare parts
276324200105	BKT ENG MTG LH TOP LP1312	TATA spare parts
276324200106	BKT ENG MTG RH TOP LP1312	TATA spare parts
276324200107	BKT ENG MTG RH RR BOT LP	TATA spare parts
276324200108	BKT ENG MTG LH RR BOT LP	TATA spare parts
276325000101	310DIA CL DISC & PR PLATE	TATA spare parts
276325200102	CLUTCH DISC 310D 697 1512 CNG 1613C	TATA spare parts
276325200105	CLUTCH DISC 310 DIA.(REINF) CK BS1/2/3/4	TATA spare parts
276325200106	DRIVEN PLATE ASSY 310DIA	TATA spare parts
276325200107	CLUTCH DISC 310 DIA.PH-III BS1/3	TATA spare parts
276325200107AE	DRIVEN PLATE ASSY. 310 DIA 713	TATA spare parts
276325200110	330 DIA. ASSY. CLUTCH DISC	TATA spare parts
276325200112	330 DIA. ASSY. CLUTCH DISC	TATA spare parts
276325200113	KIT - FACING & RIVET 2+40	TATA spare parts
276325200116	CLUTCH DISC 330 DIA CERAMIC TYPE	TATA spare parts
276325200117	CLUTCH DISC 330 DIA CERAMIC TYPE	TATA spare parts
276325200119	CLUTCH DISC 310D 697 1512 CNG 1613C	TATA spare parts
276325400102	PR. PLATE 310D 697 1512 CNG 1613C	TATA spare parts
276325400105	CLUTCH COVER 310 DIA. BS1/2/3/4	TATA spare parts
276325400106	CLUTCH COVER ASSY 310DIA	TATA spare parts
276325400107	CLUTCH COVER 310 DIA (PH-III) BS1/3	TATA spare parts
276325400107AE	ASSY. COVER PLATE 310 DIA 713	TATA spare parts
276325400110	330 DIA. COVER ASSY.	TATA spare parts
276325400112	330 DIA. Clutch COVER ASSY.(COIL)	TATA spare parts
276325400114	COVER & DIAPHRAGM SUB ASSY	TATA spare parts
276325400115	KIT - STRAP & RIVETS 8+4+4	TATA spare parts
276325400120	PRESSURE PLATE 330 DIA COIL TYPE	TATA spare parts
276325400121	PRESSURE PLATE 330 DIA COIL TYPE	TATA spare parts
276325403701	PRESSURE PLATE MACHINED	TATA spare parts
276325407401	RIVET-DIAPHRAGM	TATA spare parts
276325408701	FULCRUM PLATE	TATA spare parts
276325408702	DIAPHRAGM SPRING	TATA spare parts
276325600101	CLUTCH RELS.BRG.(SELF-CENTERING)	TATA spare parts
276326010104	ASSY GEAR SHIFT LINKAGES	TATA spare parts
276326800105	HOUSING BLOCK LP1312	TATA spare parts
276326800106	ASSY LINK ROD	TATA spare parts

276326800108	TURNING TUBE ASSY	TATA spare parts
276326800109	ASSY.LINK ROD	TATA spare parts
276326800110	ASSY. HOUSING BLOCK 1512/3015 BS1/2/3/4	TATA spare parts
276326800112	ASSY RUBBER BELLOW	TATA spare parts
276326800113	ASSY SPACER	TATA spare parts
276326800114	ASSY CLAMP RUBBER BELLOW	TATA spare parts
276326800116	ASSY TURNING TUBE	TATA spare parts
276326800118	ASSY CARRIER	TATA spare parts
276326800120	ASSY BRACKET-G.S.LEVER MTG.	TATA spare parts
276326800121	ASSY SUPPORT TUBE	TATA spare parts
276326806101	STAR WASHER	TATA spare parts
276326806301	CLAMPING PLATE	TATA spare parts
276326806302	SPACER (GEAR SHIFT LEVER) BS6	TATA spare parts
276326806304	LOCATOR	TATA spare parts
276326807121	FLANGE (SUPPORT TUBE)	TATA spare parts
276326807703	FLAP	TATA spare parts
276326807704	BELLOW-INNER	TATA spare parts
276326807705	BELLOW-OUTER	TATA spare parts
276326807901	LINK ROD BS4	TATA spare parts
276326808002	FLANGED BOLT WITH SERRATIONS	TATA spare parts
276326808003	FLANGED BOLT WITH SERRATIONS	TATA spare parts
276326808201	ANCHOR PLATE	TATA spare parts
276326808202	CARRIER BS6	TATA spare parts
276326808701	SPRING	TATA spare parts
276326809901	GEAR SHIFT LEVER	TATA spare parts
276326809903	GEAR SHIFT LEVER	TATA spare parts
276326809904	GEAR SHIFT LEVER	TATA spare parts
276326809906	GEAR SHIFT LEVER	TATA spare parts
276326810101	BRACKET ASSY	TATA spare parts
276326810102	ASSY BRACKET	TATA spare parts
276326810103	ASSY.BRACKET	TATA spare parts
276329108701	RETURN SPRING	TATA spare parts
276330100102	PULL ROD ACCELERATOR	TATA spare parts
276330100108	THRUST ROD ASSY	TATA spare parts
276330100111	STOPPER ASSY	TATA spare parts
276330100120	THRUST ROD	TATA spare parts
276330103301	BRACKET-ON TIMING G.B.COVER FOR ACC.	TATA spare parts
276331000101	FRAME COMP 52WB 50% ROH	TATA spare parts
276331000102	ASSY FRAME COMPLETE 1512 TC 52 M.STG	TATA spare parts
276331000103	ASSY FRAME LP 1312/1512 TC 59 WB 50% ROH	TATA spare parts
276331000104	FRAME 1312/59 W/B	TATA spare parts
276331000117	FRAME ASSY 42WB P/S	TATA spare parts
276331000118	ASSY FRAME LP/42 BUS TC	TATA spare parts
276331000119	ASSY FRAME LP1312/52TC P/STRG 50%ROH	TATA spare parts
276331000120	ASSY.FRAME - 52 W.B LP 1312 TC W/P.STRG.	TATA spare parts
276331000121	ASSY.FRAME - 1512 TC 59 W.B. 55% ROH	TATA spare parts
276331200102	ENG CROSS MEMBER FR 1312	TATA spare parts

276331200104	ASSY. CROSS MEMBER 3RD/4TH	TATA spare parts
276331200105	ASSY. CROSS MEMBER	TATA spare parts
276331203301	BRACKET	TATA spare parts
276331207104	SUPPORT LH RR ENG CR MEM	TATA spare parts
276331207105	SUPPORT RH RR ENG CR MEM	TATA spare parts
276331207108	REINFORCEMENT LH	TATA spare parts
276331207109	REINFORCEMENT RH	TATA spare parts
276331207110	SUPPORT L H REAR-ENGINE CM	TATA spare parts
276331207111	SUPPORT R H REAR-ENGINE CM	TATA spare parts
276331207112	SUPPORT LH FRONT ENGINE	TATA spare parts
276331207113	SUPPORT L H FRONT-ENGINE CM	TATA spare parts
276331207114	SUPPORT RH FRONT ENGINE	TATA spare parts
276331207115	SUPPORT R H FRONT-ENGINE CM	TATA spare parts
276341110103	PROP SHAFT FRONT 1312TC	TATA spare parts
276341110105	PROP SHAFT ASSY 90 DIA	TATA spare parts
276341110106	PROP SHAFT W/CEN BRG	TATA spare parts
276341110108	ASSY KIT PROPELLER SHAFT LP1312TC	TATA spare parts
276341303301	BKT CENTRE BEARING	TATA spare parts
276341303302	BKT CENTRE BEARING	TATA spare parts
276342700101	ASSY.BRACKET HAND BRAKE VALVE	TATA spare parts
276342900105	ASSY. TUBE (15 O.D.)METAL.	TATA spare parts
276342900106	ASSY.TUBE (15 O.D.)METAL	TATA spare parts
276346600101	STRG.PUMP 1613/1512 LPT R	TATA spare parts
276349000101	BRACKET ASSY	TATA spare parts
276349100104	SILENCER ASSY W/TAIL PIPE	TATA spare parts
276349200108	EXHAUST PIPE FRONT	TATA spare parts
276349200110	EXH PIPE W/FLANGE	TATA spare parts
276349200111	EXHAUST PIPE INTERMEDIATE	TATA spare parts
276349200114	ASSY EXHAUST PIPE	TATA spare parts
276349200115	ASSY EXHUAST PIPE	TATA spare parts
276349200115AE	ASSY.EXHAUST PIPE -1415	TATA spare parts
276349200119	EXHAUST PIPE	TATA spare parts
276349200120	ASSY.EXHAUST PIPE	TATA spare parts
276349200122	ASSY EXHAUST PIPE	TATA spare parts
276349200123	ASSY. EXHAUST BRAKE UNIT BS1/2/3/4	TATA spare parts
276349200124	ASSY.INTERMEDIATE FLANGE WITH BUSH.	TATA spare parts
276349200125	ASSY EXH PIPE 81DIA X L 290	TATA spare parts
276349200126	ASSY.BRACKET.	TATA spare parts
276349200128	ASSY BRACKET	TATA spare parts
276349200131	ASSY.BRACKET	TATA spare parts
276349203301	BRACKET	TATA spare parts
276349203308	BRACKET LPT1613TC	TATA spare parts
276349203309	BRACKET MOUNTED ON ENGINE BLOCK	TATA spare parts
276349204202	EXHAUST CLAMP	TATA spare parts
276349205301	GASKET EXHAUST PIPE FLANGE BS1/2/3/4/6	TATA spare parts
276349207104	BRACKET	TATA spare parts
276349208201	SUPPORT BRACKET	TATA spare parts

276354209901	ELECT.TEMP GAUGE 24 V	TATA spare parts
276354209902	TEMP GAUGE	TATA spare parts
276354820101	ASSY MAIN CABLE SET	TATA spare parts
276360100101	COWL BARE RHD 1312TC	TATA spare parts
276360100102	ASSY BARE COWL LP1512TC59	TATA spare parts
276360100105	BARE COWL - RHD LP1512TC	TATA spare parts
276360100115	COWL COMPLT W/FIT	TATA spare parts
276388700101	ENGINE HOOD RHD 1312TC	TATA spare parts
276388706301	ENGINE HOOD RHD 1312TC	TATA spare parts
276624200101	ASSY ENG MTG ARM LH	TATA spare parts
276624200102	ASSY ENG MTG ARM RH	TATA spare parts
276631207105	REINFORCEMENT RH.	TATA spare parts
276632900104	ASSY.SHOCK ABS.& ANTIROLL BAR BRACKET RH	TATA spare parts
276632900105	ASSY.SHOCK ABS.& ANTIROLL BAR BRACKET LH	TATA spare parts
276641120101	ASSY PROP SHAFT	TATA spare parts
276649200102	ASSY.EXHAUST PIPE.	TATA spare parts
276649206901	EXHAUST PIPE INTERMEDIATE	TATA spare parts
276724200101	ASSY. BRACKET-ENG.MTG. - REAR BOTTOM	TATA spare parts
276725000103	ASY.KIT 352 DIA.1.75 INCH TWIN DISC CL	TATA spare parts
276725200101	352 DIA.CL.DISC ASSY.(1.75SPLINE)-FRO	TATA spare parts
276725200102	352 DIA.CL.DISC ASSY.(1.75SPLINE)-REA	TATA spare parts
276725400101	352 DIA.COVER ASSY.(TWIN DISC CL.)-SOLO	TATA spare parts
276725400102	INTERMEDIATE PLATE (TWIN DISC CL)- SOLO	TATA spare parts
276729108401	SLEEVE BS6	TATA spare parts
276731200102	ASSY.SUPPORT-ENG.C.M. FRONT	TATA spare parts
276731200103	ASSY. SUPPORT- ENG.C.M.REAR	TATA spare parts
276731200105	ASSY.REINFORCEMENT RH (FRT.SPRG.BKT.)	TATA spare parts
276731200106	ASSY.REINFORCEMENT LH (FRT.SPRG.BKT.)	TATA spare parts
276731207114	RENFORCEMENT RH ( FRT.SPRG.BKT.REAR)	TATA spare parts
276731207115	REINFORCEMENT LH ( FRT.SPRG.BKT.REAR)	TATA spare parts
276742903305	BRACKET	TATA spare parts
276744000105	LATCH ASSY WITH LATCH CYLINDER	TATA spare parts
276747100101	ASSY FUEL TANK COMP 225LT	TATA spare parts
276747603301	BRACKET.	TATA spare parts
276749200101	ASSY.EXHAUST PIPE-LOW MOUNT TURBO	TATA spare parts
276754400101	KIT FOR SPARE BULB	TATA spare parts
276754400102	KIT FOR SPARE BULB	TATA spare parts
276782400101	KIT-ACCESSORIES WIPER BS1/2/3	TATA spare parts
276782400102	ASSY. WIPER BLADE & SUP. ARM(RHD) BS1- 6	TATA spare parts
276782400103	ASSY. WIPER ARM & BLADE (CODRIVER) BS1-6	TATA spare parts
276782400104	ASSY WIPER ARM (DRIVER)	TATA spare parts
276782400105	ASSY WIPER ARM (RHD)(CO-DRIVER)	TATA spare parts
276782408201	BRACKET (MOTOR MOUNTING)	TATA spare parts
276782409901	WIPER MOTOR 17W 12V(RHD)SINGLE W/S	TATA spare parts
276782409902	LINK ROD (440MM)	TATA spare parts
276814990205	TURBOCHARGER	TATA spare parts
276824105101	ENGINE MOUNTING ARM RH-FRONT	TATA spare parts

276824105102	ENGINE MOUNTING ARM LH-FRONT	TATA spare parts
276824200101	ASSY. BRACKET-LH-ENG.MTG.- REAR BOTTOM	TATA spare parts
276824200102	ASSY. BRACKET-RH-ENG.MTG.- REAR BOTTOM	TATA spare parts
276824200103	ASSY.BRACKET-LH ENG.MTG.-REAR BOTTOM	TATA spare parts
276824200104	ASSY.BRACKET-RH ENG.MTG.-REAR BOTTOM	TATA spare parts
276824200106	ASSY.BRACKET ENGINE MOUNTING REAR PAD	TATA spare parts
276824200109	BRACKET ASSY ENGINE MTG TOP REAR	TATA spare parts
276826800103	ASSY SHIFT LINK	TATA spare parts
276826800109	ASSY. BKT.	TATA spare parts
276826809901	GEAR SHIFT LEVER	TATA spare parts
276829100105	ASSY.CLUTCH MASTER CYL.-19.05 DIA	TATA spare parts
276830100102	ASSY PULL ROD (ACCELERATOR)	TATA spare parts
276830100107	ASSY. PULL ROD (L=760) .	TATA spare parts
276831000104	ASSY FRAME LPS3516/32TC	TATA spare parts
276831000106	ASSY FRAME - LPS 3516 1 DEG INCL ENG	TATA spare parts
276831200101	ASSY.SUPPORT-ENGINE C.M.FRONT	TATA spare parts
276831200102	ASSY.SUPPORT-ENGINE C.M. REAR	TATA spare parts
276831200103	ASSY.ENGINE CROSS MEMBER- REAR	TATA spare parts
27683120010335	ASSY.ENGINE CROSS MEMBER_UNPAINTED	TATA spare parts
276831200108	ASSY.SUPPORT-ENGINE C.M. REAR	TATA spare parts
276831200109	ASSY REINFORCEMENT RH FRT SPR BRACKET	TATA spare parts
276831200110	ASSY REINFORCEMENT LH FRT SPR BKT	TATA spare parts
276831200111	ASSY.SUPPORT LH-ENG. CROSS MEMBER FRT	TATA spare parts
276831200112	ASSY.SUPPORT RH-ENG. CROSS MEMB FRT	TATA spare parts
276831200113	ASSY. CROSS MEMBER WITH SUPPORT	TATA spare parts
276831200114	ASSY. RR SPRING CROSS MEMBER WITH SUPPOR	TATA spare parts
276831200115	ASSY END CROSS MEMBER WITH GUSSET	TATA spare parts
276831200118	ASSY.END CROSS MEMBER WITH GUSSET	TATA spare parts
276831207109	SPACER PLATE (ENG.C.M.FRONT)	TATA spare parts
276831207116	BRACKET (RETURN SPG.FOR D.T.V.) BS6	TATA spare parts
276831207117	SUPPORT TOP RH-FOR 4TH CROSS MEMBER	TATA spare parts
276831207118	SUPPORT TOP LH-FOR 4TH CROSS MEMBER	TATA spare parts
276831207119	SUPPORT RH	TATA spare parts
276831207120	SUPPORT LH	TATA spare parts
276831207121	REINFORCEMENT RH-SUB STRUCTURE MIDDLE	TATA spare parts
276831207122	REINFORCEMENT RH-INNER	TATA spare parts
276831207123	REINFORCEMENT LH-INNER	TATA spare parts
276831207124	REINFORCEMENT RH FRONT SPRG. BKT. REAR	TATA spare parts
276831207125	REINFORCEMENT LH FRT. SPRG. BKT. REAR	TATA spare parts
276831207126	REINFORCEMENT RH-SUB STRUCTURE REAR	TATA spare parts
276831207127	REINFORCEMENT RH-INNER REAR	TATA spare parts
276831207128	REINFORCEMENT LH-INNER REAR	TATA spare parts
276831207129	REINFORCEMENT RH-SUB STRUCTURE FRONT	TATA spare parts
276831207135	REINFORCEMENT LH ( SUB STRUCTURE REAR )	TATA spare parts
276831207139	REINFORCEMENT RH (INNER REAR)	TATA spare parts
276831207140	REINFORCEMENT LH (INNER REAR)	TATA spare parts
276831208206	PACKING PLATE	TATA spare parts

276831208207	PACKING PLATE	TATA spare parts
276831307105	GUSSET TOP - RH (END CROSS MEMBER)	TATA spare parts
276831307106	GUSSET TOP - LH (END CROSS MEMBER)	TATA spare parts
276831307107	GUSSET BOTTOM - RH (END CROSS MEMBER)	TATA spare parts
276831307108	GUSSET BOTTOM - LH (END CROSS MEMBER)	TATA spare parts
276831307109	REINFORCEMENT (END CROSS MEMBER)	TATA spare parts
276831308601	SPECIAL WASHER	TATA spare parts
276831309901	HEX. BOLT	TATA spare parts
276831600109	ASSY. MOUNTING PLATE-V WHEEL COUPLING	TATA spare parts
276831600111	ASSY. RAMP RH-V WHEEL COUPLING	TATA spare parts
276831600112	ASSY. RAMP LH-V WHEEL COUPLING	TATA spare parts
276831608203	SHIM 1 THICK	TATA spare parts
276831608204	SHIM 1.6 THICK	TATA spare parts
276831700101	ASSY. BOTTOM SHIELD RADIATOR SIDE	TATA spare parts
276831700102	ASSY SUPPORT BKT.(TRANS.SIDE)-RH	TATA spare parts
276831700103	ASSY SUPPORT BKT(TRANS. SIDE)-LH	TATA spare parts
276832400101	ASSY REAR SPRING	TATA spare parts
276832403201	CENTRE BOLT	TATA spare parts
276832404201	SPRING CLIP	TATA spare parts
276832404202	SPRINGCLIP BS6	TATA spare parts
276832404203	SPRING CLIP	TATA spare parts
276832404204	U CLAMP	TATA spare parts
276832408601	SPACER TUBE	TATA spare parts
276832800101	ASSY.ANTIROLL BAR WITH EYE PIECE COMPLTE	TATA spare parts
276832800102	ASSY CONNECTING LINK	TATA spare parts
276833000102	ASSY. KIT FOR FRONT AXLE (10 BOLTS)	TATA spare parts
276833000103	ASSY. KIT FOR FRONT AXLE (8 BOLTS)	TATA spare parts
276834100105	ASSY. FIFTH WHEEL COUPLING COMPLETE	TATA spare parts
276834100106	ASSY MTG LEG COMPLETE	TATA spare parts
276841120103	ASSY PROP SHAFT	TATA spare parts
276842400101	ASSY PULL ROD	TATA spare parts
276843200101	ASSY. BRACKET-AIR TANK MTG	TATA spare parts
276843207102	SPACER	TATA spare parts
276843700102	PURGE TANK	TATA spare parts
276843700103	PURGE TANK	TATA spare parts
276843700104	PURGE TANK	TATA spare parts
276843700105	PURGE TANK	TATA spare parts
276843703301	BRACKET-DDU MOUNTING	TATA spare parts
276846803301	BRACKET	TATA spare parts
276849100102	ASSY.SILENCER	TATA spare parts
276849100106	ASSY.SILENCER WITH TAIL PIPE	TATA spare parts
276849100107	ASSY SILENCER WITH TAIL PIPE.LPS3516 BS2	TATA spare parts
276849108201	BRACKET.	TATA spare parts
276849108203	BRACKET	TATA spare parts
276849200103	ASSY.EXHAUST PIPE	TATA spare parts
276849200108	ASSY. EXHAUST PIPE (FRONT)LPS-3516	TATA spare parts
276849206901	TAIL PIPE-81.2 OD X 1.6THK	TATA spare parts

276849208203	BRACKET (ON CROSS MEMBER)	TATA spare parts
276849208204	BRACKET	TATA spare parts
276849208205	BRACKET	TATA spare parts
276849208208	MUFFLER SUPPORT BRACKET	TATA spare parts
276852200111	ASSY.SPACER REAR LH-REAR WH. ARCH MTG	TATA spare parts
276852200112	ASSY.SPACER REAR RH-REAR WH ARCH MTG	TATA spare parts
276852200115	ASSY BKT LH REAR COMPLETE	TATA spare parts
276852200116	ASSY BKT RH REAR COMPLETE	TATA spare parts
276854209901	TEMP GAUGE	TATA spare parts
276854209902	HIGH TEMP. WARNING BUZZER UNIT 12V	TATA spare parts
276854600101	ASSY MAIN CABLE SET 3516	TATA spare parts
276854620102	ASSY JUMPER CABLE	TATA spare parts
276854620110	WIRING HARNESS FR. TO TAIL	TATA spare parts
276860100101	ASSY.BRACKET LH-RHD(AIR FILTER MOUNTING)	TATA spare parts
276860100106	ASSY COWL COMP.WITH FITMENTS-RHD	TATA spare parts
276881800101	ASSY MASCOT 3516 TC	TATA spare parts
276881800102	ASSY TATA 3516 CUMMINS MASCOT	TATA spare parts
276881800105	ASSY TATA 3516 C EX MASCOT	TATA spare parts
276888700101	ASSY ENGINE HOOD COMP	TATA spare parts
276888706301	ENGINE HOOD	TATA spare parts
276889100101	ASSY BRACKET LH RR MTG	TATA spare parts
276889100102	ASSY BRACKET RH RR MTG	TATA spare parts
277001000102	ASSY. ENGINE COMP. 130HP H-TORQUE BS3	TATA spare parts
277001000107	ENGINE 130HP AUTO DRAIN	TATA spare parts
277014606901	AIR INTAKE PIPE-102 OD X 515L	TATA spare parts
277024104101	ENGINE MOUNTING ARM -FRONT LPK1615TC	TATA spare parts
277024105101	ENGINE MOUNTING ARM RH-FRONT	TATA spare parts
277024105102	ENGINE MOUNTING ARM LH-FRONT	TATA spare parts
277024200101	ASSY.BRACKET RH-ENG.MTG. BOTTOM	TATA spare parts
277024200102	ASSY.BRACKET LH-ENG.MTG.BOTTOM	TATA spare parts
277024200103	ASSY.BRACKET LH -ENG.MTG.TOP	TATA spare parts
277024200104	ASSY.BRACKET RH -ENG.MTG.TOP	TATA spare parts
277024200113	ASSY BRACKET RH-ENG.MTG.REAR	TATA spare parts
277024200114	ASSY. BRACKET LH-ENG.MTG. REAR	TATA spare parts
277024200118	ASSY BKT ENG.MTG-RR	TATA spare parts
277024200119	ASSY.BRACKET LH ENG.MTG.TOP	TATA spare parts
277024200120	ASSY.BRACKET RH.ENGINE MTG TOP	TATA spare parts
277024200121	ASSY BRACKET-ENGINE MTG.- REAR BOTTOM	TATA spare parts
277024200125	ASSY BRACKET RH ENG.MTG.REAR	TATA spare parts
277024200126	ASSY BRACKET LH-ENG.MTG.REAR	TATA spare parts
277024200127	ASSY ENGINE MTG. REAR BOTTOM - RH	TATA spare parts
277024200128	ASSY ENGINE MTG. REAR BOTTOM - LH	TATA spare parts
277024207145	BRACKET - ON FLYWHEEL HOUSING.LH SIDE	TATA spare parts
277026010107	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
277026800102	ASSY TURNING TUBE-WITHOUT BALL JOINT	TATA spare parts
277026800103	ASSY BRACKET-G S LEVER MTG	TATA spare parts
277026800107	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts



277026800108	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
277026808001	FLANGED SERRATED BOLT	TATA spare parts
277026808002	FLANGED SERRATED BOLT L=140	TATA spare parts
277026809901	GEAR SHIFT LEVER	TATA spare parts
277026810101	ASSY BRACKET (GEAR SHIFT LEVER MTG.)	TATA spare parts
277029100103	ASSY. CONNECTING LINE	TATA spare parts
277029100104	ASSY CONTROL MOUNTING BKT.WITH TUBE	TATA spare parts
277029100106	ASSY.CONNECTING LINE (WITH 2 RUBBER HOSE	TATA spare parts
277029100112	ASSY.PIPE (6 O.D.)[ON SLAVE CYL.	TATA spare parts
277029100122	MASTER CYLINDER DIA25.4X45	TATA spare parts
277029100132	ASSY. PIPE (CL.FLUID.RESERVOIR.TO M\CYL.	TATA spare parts
277029100142	ASSY. CONTROL MTG BRACKET WITH TUBE	TATA spare parts
277029100151	HYD CLUTCH PIPE ASSY	TATA spare parts
277029103303	BRACKET-HOSE MTG.	TATA spare parts
277029106002	PULL ROD LP1512TC	TATA spare parts
277029106702	PIN	TATA spare parts
277029203304	BRACKET	TATA spare parts
277029300103	BUNDY¿ TUBE¿ ASSYBS	TATA spare parts
277029500102	ASSY.CONTROLS COMPLETE - RHD - MECH.STG.	TATA spare parts
277030100101	ASSY BRKT.-LOW MOUNT TC	TATA spare parts
277030100103	ASSY. CONTROL SHAFT-LOW MOUNT TC	TATA spare parts
277030100104	ASSY CONTROL SHAFT-LOW MOUNT TC	TATA spare parts
277030100105	ASSY PULL ROD	TATA spare parts
277030100110	ASSY ACCERATOR PEDAL	TATA spare parts
277030100114	ASSY.PULL ROD-ACC.CONTROL L=885	TATA spare parts
277030100115	ASSY LEVER	TATA spare parts
277030100116	ASSY CONTROL SHAFT	TATA spare parts
277030100117	ASSY PULL ROD-L=735	TATA spare parts
277030100126	ASSY. ACCELERATOR CABLE 678.5MM BS2/3	TATA spare parts
277030100131	ASSY BRACKET WITH CABLE HOLDER BKT	TATA spare parts
277030100138	ACCELERATOR CABLE ASSY	TATA spare parts
277030990103	RETRO KIT PARTIAL CABLE WITH BKT LP1512	TATA spare parts
277031000102	ASSY FRAME LP/32 TC P/STG-195 DEEP LM	TATA spare parts
277031000103	ASSY FRAME 36WB (MECH STG) 195 DEEP L.M.	TATA spare parts
277031000104	ASSY FRAME 36WB (POWER STG) 195 DEEP LM	TATA spare parts
277031000107	FRAME W B 52 LP1512TC	TATA spare parts
277031000110	ASSY. FRAME 59 W.B.	TATA spare parts
277031000114	ASSY FRAME LP1512TC/59 60% 330DIA CLUTCH	TATA spare parts
277031000115	ASSY. FRAME COMP. LP1512TC/59 55% ROH	TATA spare parts
277031000116	ASSY. FRAME COMP. LP1512TC/59 50% ROH	TATA spare parts
277031000117	ASSY FRAME COMP-50% ROH POWER STG	TATA spare parts
277031000118	ASSY FRAME COMP. 60% ROH -POWER STG.	TATA spare parts
277031000120	ASSY FRAME COMPLETE 1512TC/52 E-III 60%	TATA spare parts
277031000121	ASSY FRAME COMPLETE 1512TC/42 E-II	TATA spare parts
277031000122	ASSY FRAME COMPLETE (55% ROH)	TATA spare parts
277031000123	ASSY FRAME LP 1512TC/52 60% ROH BHARAT S	TATA spare parts
277031000125	ASSLY FRAME COMPLETE-60% ROH	TATA spare parts

277031000127	ASSY FRAME 42WB(TILT ENG)	TATA spare parts
277031000129	ASSY FRAME 52WB(TILT ENG)	TATA spare parts
277031000130	ASSY FRAME 59WB(TILT ENG)	TATA spare parts
277031000131	ASSY FRAME 48 WB(TILT ENGINE)- 60% OVERH	TATA spare parts
277031000136	ASSY FRAME COMPLETE (55% ROH) FOR LP1512	TATA spare parts
277031000137	FRAME ASSY WITH FITMENT	TATA spare parts
277031000149	FRAME ASSY WITH FITMENT	TATA spare parts
277031000153	FRAME ASSY WITH FITMENT	TATA spare parts
277031000155	FRAME ASSY WITH FITMENT	TATA spare parts
277031000156	FRAME ASSY WITH FITMENT	TATA spare parts
277031000159	FRAME ASSY WITH FITMENT	TATA spare parts
277031000165	FRAME ASSY WITH FITMENT	TATA spare parts
277031200104	ENGINE CROSS MEMBER FRONT 1512 / 1613TC	TATA spare parts
277031200108	ASSY CROSS MEMBER	TATA spare parts
277031200109	ASSY SUPPORT-ENGINE C.M.FRONT	TATA spare parts
277031200113	ASSY.ENGINE CROSS MEMBER-REAR	TATA spare parts
277031200114	ASSY SPACER-ENGINE CROSS MEMBER REAR	TATA spare parts
277031200115	ASSY ENGINE CROSS MEMBER-FRONT	TATA spare parts
277031200116	ASSY. SUPPORT-ENG. CROSS MEMBER FRONT	TATA spare parts
277031200121	ASSY CROSS MEMBER	TATA spare parts
277031200124	ASSY. GUSSET-RH	TATA spare parts
277031200125	ASSY. GUSSET-LH	TATA spare parts
277031200128	CROSS MEMBER ASSY WITH SUPPORT	TATA spare parts
277031207120	REINFORCEMENT RH	TATA spare parts
277031207121	REINFORCEMENT LH	TATA spare parts
277031207122	SUPPORT LH	TATA spare parts
277031207123	SUPPORT RH	TATA spare parts
277031207124	REINFORCEMENT LH	TATA spare parts
277031207125	REINFORCEMENT RH	TATA spare parts
277031207128	SUPPORT ENGINE CROSS MEMBER-REAR	TATA spare parts
277031207131	SUPPORT ENGINE CROSS MEMBER-REAR	TATA spare parts
277031300101	BRACKET ASSY BUMP STOPPER FRONT-RH	TATA spare parts
277031300102	BRACKET ASSY BUMP STOPPER FRONT-LH	TATA spare parts
277031308201	REINFORCEMENT BOTTOM LH	TATA spare parts
277031308202	REINFORCEMENT BOTTOM RH	TATA spare parts
277031308205	L-REINFORCEMENT TOP-RH	TATA spare parts
277031308206	L-REINFORCEMENT TOP-LH	TATA spare parts
277032100101	ASSY.FRT.PARABOLIC SPRING 1510	TATA spare parts
277032100102	ASSY.FIRST LEAF WITH BUSHES	TATA spare parts
277032100108	ASSY. FRT SPRING (PARABOLIC FOR LP)	TATA spare parts
277032100111	ASSY. FRONT SPRING	TATA spare parts
277032103202	CENTER BOLT M12X180	TATA spare parts
277032103401	SPRING BUSH - BI-METALLIC	TATA spare parts
277032103402	SHACKLE BUSH - BI METALLIC	TATA spare parts
277032103701	FRONT SPRING BRACKET	TATA spare parts
277032104202	SPRING CLIP	TATA spare parts
277032107102	SECOND LEAF	TATA spare parts

277032107103	THIRD LEAF	TATA spare parts
277032107104	FOURTH LEAF	TATA spare parts
277032107105	PACKING PLATE (19 THK.)	TATA spare parts
277032107106	PACKING PLATE (13 THK.)	TATA spare parts
277032107107	CENTER PAD (3 THK.)	TATA spare parts
277032204201	U CLMAP (310 LENGTH - M20X1.5)	TATA spare parts
277032204202	U CLAMP M20X1.5X300	TATA spare parts
277032204203	U BOLT (L=280)	TATA spare parts
277032300101	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
277032300102	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
277032300102AE	ASSY. FRONT SHOCK ABSORBER 1415	TATA spare parts
277032300103	ASSY. BRACKET FRONT SHOCK ABSORBER	TATA spare parts
277032400101	ASSY.REAR PARABOLIC SPRING	TATA spare parts
277032400102	ASSY.FIRST LEAF WITH BUSHES	TATA spare parts
277032403201	CENTER BOLT M12X183	TATA spare parts
277032403202	HEX.BOLT M10X1.5X25	TATA spare parts
277032403203	HEX.BOLT M12X1.5X35MM	TATA spare parts
277032403204	HEX.BOLT M14X1.5X40MM	TATA spare parts
277032403206	HEX.BOLT M16X1.5X60MM	TATA spare parts
277032403401	SPRING BUSH - BI-METALLIC	TATA spare parts
277032403402	SHACKLE BUSH - BI METALLIC	TATA spare parts
277032404202	SPRING CLIP	TATA spare parts
277032406501	HEX.NUT M12X1.5	TATA spare parts
277032407102	SECOND LEAF	TATA spare parts
277032407103	THIRD LEAF	TATA spare parts
277032407104	FOURTH LEAF	TATA spare parts
277032407105	PACKING PLATE (15 THK.)	TATA spare parts
277032407106	CENTER PAD (3 THK.)	TATA spare parts
277032409201	SPRG WASHER M12	TATA spare parts
277032600101	ASSY. REAR SHOCK ABSORBER BS1/2/3/4	TATA spare parts
277032600101AE	ASSY. REAR SHOCK ABSORBER -1415	TATA spare parts
277041100101	ASSY. PROP. SHAFT WITH CEN. BRG.(L=452)	TATA spare parts
277041100123	ASY.PROP.SHAFT WITH GREASABLE CB(L=452)	TATA spare parts
277041100125	ASY.PROP.SHAFT WITH GREASABLE CB(L=1560)	TATA spare parts
277041100139	ASSY FRONT PROP SHAFT WITH C.B.L-947	TATA spare parts
277041100145	ASSY. PROP.SHAFT FRONT(CL=1734)	TATA spare parts
277041100146	ASSY.FRONT PROP.SHAFT W CENT BRG.(L=951	TATA spare parts
277041100154	ASSY FRONT PROP SHAFT	TATA spare parts
277041100173	PROPELLER SHAFT ASSY	TATA spare parts
277041100174	PROPELLER SHAFT ASSY WITH CB FRONT	TATA spare parts
277041100175	PROPELLER SHAFT ASSY WITH CB FRONT	TATA spare parts
277041108202	SUPPORT PROPELLER SHAFT GUARD	TATA spare parts
277041110108	ASSY. PROP. SHAFT MIDDLE	TATA spare parts
277041120102	ASSY. PROP. SHAFT REAR	TATA spare parts
277041120110	ASSY PROP SHAFT REAR	TATA spare parts
277041120115	PROPELLER SHAFT ASSY REAR	TATA spare parts
277041120116	PROPELLER SHAFT ASSY REAR	TATA spare parts

277041303301	SPACER BRACKET (CENTER BRG.MTG.FRONT)	TATA spare parts
277041303302	SPACER BRACKET (CENTER BRG.MTG. REAR)	TATA spare parts
277041303307	CENTRE BEARING MOUNTING BRACKET	TATA spare parts
277041303308	CENTRE BEARING MTG BKT 1ST (NEW RECIPE)	TATA spare parts
277041303309	CENTRE BEARING MTG BKT 2ND (NEW RECIPE)	TATA spare parts
277041303310	CENTRE BEARING MTG BKT (NEW RECIPE)	TATA spare parts
277041303319	BRACKET(FOR 1ST CENTRE BEARING	TATA spare parts
277041303320	CENTRE BEARING MOUNTING BRACKET	TATA spare parts
277041303321	CENTRE BEARING MOUNTING BRACKET	TATA spare parts
277041303322	BRACKET(FOR 1ST CENTRE BEARING)	TATA spare parts
277041303323	BRACKET(FOR 2ND CENTRE BEARING)	TATA spare parts
277041990114	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
277041990119	ASSY SHORT FORK TUBE & FRT END PIECE	TATA spare parts
277041990123	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
277041990124	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
277042300101	ASSY.SPRING BRAKE ACTUATOR	TATA spare parts
277042300102	AUTOMATIC SLACK ADJ. RH 45 OFFSET	TATA spare parts
277042300103	NP-3-B72C SLACK ADJ. LH 45 OFFSET	TATA spare parts
277042300104	ASSY AUTO SLK ADJ RR 43MM	TATA spare parts
277042300105	ASSY AUTO SLK ADJ RR 43MM	TATA spare parts
277042308201	ANCHOR BRACKET RH	TATA spare parts
277042308202	ANCHOR BRACKET LH	TATA spare parts
277042700102	ASSY BKT. FOR FLICK VALVE	TATA spare parts
277042900102	ASSY PIPE LINES(COWL + CHASSIS)COMPLETE	TATA spare parts
277042900110	TUBE AIR DRYER TO PURGE TANK	TATA spare parts
277042900112	TUBE D.T.V. PORT 22 TO FRONT BRAKE	TATA spare parts
277042900124	TUBE S.P.V. PART 11/12 TO AIR PRESSURE	TATA spare parts
277042900129	ASSY.TUBE (15 O.D.)	TATA spare parts
277042900130	ASSY.TUBE (15 O.D.)	TATA spare parts
277042900133	ASSY.TUBE (12 O.D.)	TATA spare parts
277042900140	ASSY.TUBE-6 O.D.	TATA spare parts
277042900141	ASSY.TUBE-6 O.D.	TATA spare parts
277042900144	ASSY.TUBE-6 O.D.	TATA spare parts
277042900167	ASSY.METAL PIPE - 15 O.D.	TATA spare parts
277042903304	BRACKET	TATA spare parts
277042910161	ASSY.NYLON PIPES CHASSIS(LP1512TC 330CLU	TATA spare parts
277042910171	ASSY.NYLON PIPE SET COMP COWL	TATA spare parts
277042910177	ASSY.NYLON PIPES CHASSIS(LP 1512 330 DIA	TATA spare parts
277042910178	ASSY.PIPE - 15 O.D.	TATA spare parts
277043200101	ASSY 20 LIT. AIR TANK 226MM PITCH	TATA spare parts
277043200102	ASSY 20LIT.AIR TANK 200 MM CD	TATA spare parts
277043200103	ASSY AIR TANK 30 LTR. 240 CD WITH STRAP	TATA spare parts
277043200104	ASSY AIR TANK 30 LTR. 240 CD WITH STRAP	TATA spare parts
277043700113	PURGE TANK (SUITABLE FOR VOSS)	TATA spare parts
277043700210	QUICK RELEASE VALVE	TATA spare parts
277043706801	COUPLING BODY (M36X1 M26X1.5)	TATA spare parts
277043900104	ASSY.PIPE(FIRST METAL PIPE ON COMPRESSOR	TATA spare parts

277043900105	ASSY.PIPE(SECOND METAL PIPE ON COMPRESS.	TATA spare parts
277043900107	ASSY.PIPE(SECOND METAL PIPE ON COMPRESSO	TATA spare parts
277043900108	ASSY.PIPE(THIRD METAL PIPE ON COMPRESSOR	TATA spare parts
277043900112	ASSY.NY.PIPE SET CHASSIS COMPL-LP1512/52	TATA spare parts
277043900184	ASSY NYLON PIPE SET COMPL.CONSISTS	TATA spare parts
277043900213	SET ASY NYL W/PLASTIC VOSS LP1512/52	TATA spare parts
277043900215	SET ASSY NYLON PIPE W/PLASTIC	TATA spare parts
277043900216	SET ASY NYL W/PLASTIC VOSS LP1512/59	TATA spare parts
277043900222	ASSY.METAL PIPE 18 O.D SECOND M/S PRITAM	TATA spare parts
277043900228	METAL PIPELINE CRIMPED TEFLON HOSE-230CC	TATA spare parts
277043900230	ASSY METAL PIPE W/HOSE COMP INLET -230CC	TATA spare parts
277043900242	ASSY BKT OIL SEPERATOR/CONSEP UNIT	TATA spare parts
277043900243	ASSY METAL PIPE (18 DIA)-SECOND	TATA spare parts
277043900244	ASSY METAL PIPE (18 DIA)- THIRD	TATA spare parts
277043900249	ASSY.PIPE SECOND METAL PIPE DIA 18	TATA spare parts
277043900250	ASSY.PIPE THIRD METAL PIPE DIA 18	TATA spare parts
277043900252	ASSY METAL PIPE (18 DIA)-THIRD	TATA spare parts
277043900253	ASSY METAL PIPE (18 DIA)-FOURTH	TATA spare parts
277043900264	SET ASSY NYLON PIPE WITH REAR QRV EXH.VO	TATA spare parts
277043900272	SECOND& METAL PIPE 18-DIA	TATA spare parts
277043900281	ASSY.NYLON PIPE BUNCH FOR LP1512/59	TATA spare parts
277043900282	ASSY.18DIA PIPE OIL SEP.TO DRYER	TATA spare parts
277043900292	ASSY.NYLON PIPE BUNCH FOR LP1512/52	TATA spare parts
277043900294	ASSY METAL PIPE (18 DIA)- FOURTH	TATA spare parts
277043900296	ASSY.NYLON PIPE BUNCH FOR LP1512/59	TATA spare parts
277043900298	ASSY.NYLON PIPE BUNCH	TATA spare parts
277043900300	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
277043900305	ASSY METAL PIPE (18 DIA)- FOURTH	TATA spare parts
277043900307	SET ASSY NYLON PIPE FOR LP 1512	TATA spare parts
277043900309	ASSY.25 DIA PIPE COMPRESSOR INLET-1	TATA spare parts
277043900310	ASSY.25 DIA PIPE. COMP. INTAKE PIPE-2	TATA spare parts
277043900318	ASSY METAL PIPE (18 DIA)- FOURTH	TATA spare parts
277043900323	ASSY METAL PIPE (18 DIA)- FOURTH	TATA spare parts
277043900325	PIPE ASSY COMPRESSOR FOURTH METAL PIPE	TATA spare parts
277043900336	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
277043900345	PIPE ASSY COMPRESSOR OUTLET-2	TATA spare parts
277043900346	PIPE ASSY COMPRESSOR OUTLET-3	TATA spare parts
277043900353	PIPE ASSY COMPRESSOR OUTLET-2	TATA spare parts
277043900354	PIPE ASSY COMPRESSOR OUTLET-3	TATA spare parts
277043900355	PIPE ASSY COMPRESSOR OUTLET-4	TATA spare parts
277043900365	METAL PIPE ASSY THIRD	TATA spare parts
277043900367	PIPE ASSY COMPRESSOR OUTLET-4	TATA spare parts
277043900368	PIPE ASSY FIRST METAL PIPE WITH HOSE	TATA spare parts
277043900370	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
277043900386	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
277043900389	PIPE ASSY COMPRESSOR OUTLET-2	TATA spare parts
277043900390	METAL PIPE ASSY THIRD METAL PIPE	TATA spare parts

277043903301	BRACKET BS6	TATA spare parts
277043906801	COUPLING BODY (M26X1.5-M36X2)	TATA spare parts
277043906802	COUPLING BODY (M26X1.5-M26X1.5)	TATA spare parts
277043907101	ASSY CONSEP MTG. BRACKET	TATA spare parts
277043910135	PIPE ASSY FIRST METAL PIPE WITH HOSE	TATA spare parts
277043910136	PIPE ASSY SECOND METAL PIPE 18 DIA	TATA spare parts
277043910137	PIPE ASSY FOURTH METAL PIPE 18 DIA	TATA spare parts
277043910140	PIPE ASSY THIRD METAL PIPE 18 DIA	TATA spare parts
277043910210	METAL PIPE ASSY THIRD	TATA spare parts
277043910211	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
277043920101	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
277043920124	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
277043920155	PIPE BUNCH ASSY COMPLETE	TATA spare parts
277043920166	PIPE ASSY COMPRESSOR OUTLET-4	TATA spare parts
277043920198	PIPE BUNCH ASSY	TATA spare parts
277043930131	PIPE ASSY SECOND METAL PIPE 18 DIA	TATA spare parts
277043930132	PIPE ASSY FIRST METAL PIPE WITH HOSE	TATA spare parts
277043930133	PIPE ASSY THIRD METAL PIPE 18 DIA	TATA spare parts
277043930141	PIPE ASSY COMPRESSOR OUTLET-2	TATA spare parts
277043930142	PIPE ASSY COMPRESSOR OUTLET-3	TATA spare parts
277043930156	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
277043930159	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
277043930171	PIPE ASSY METAL 25.4 OD X 1.6 THK	TATA spare parts
277043930205	PIPE ASSY BUNCH	TATA spare parts
277043930208	PIPE ASSY	TATA spare parts
277043930210	PIPE BUNCH ASSY	TATA spare parts
277043930212	INTAKE PIPE AIR COMPRESSOR	TATA spare parts
277043950104	PIPE ASSY COMPRESSOR OUTLET-2	TATA spare parts
277046000101	ASSY DRAG LINK	TATA spare parts
277046000102	ASSY.DRAG LINK	TATA spare parts
277046000109	ASSY.STG.GEAR BOX STEERING SYSTEM	TATA spare parts
277046000110	P.STG.PUMP WITH FITTINGS STG SYS.	TATA spare parts
277046000111	ASSY.STG.TANK- STEERING SYSTEM	TATA spare parts
277046000118	SEALED DRAG LINK LP1512 RHD	TATA spare parts
277046000123	SEALED DRAG LINK LP1512 RHD	TATA spare parts
277046000124	DRAGLINK ASSY	TATA spare parts
277046100101	ASSY STRG GEAR BOX VAR.RATIO LPT1613TC	TATA spare parts
277046100102	ASSY BRACKET LP 1512 TC	TATA spare parts
277046100103	ASSY BRACKET STRG G.B.MTG	TATA spare parts
277046100104	BOX SUB ASSEMBLY VAR/RATIO STEERING	TATA spare parts
277046100105	WORM & NUT ASSEMBLY VAR/RATIO STEERING	TATA spare parts
277046100106	COVER PLATE SUB ASSEMBLY VAR/RATIO STEER	TATA spare parts
277046100107	WORM & NUT ASSEMBLY VAR/RATIO STEERING	TATA spare parts
277046100110	ASSY STEERING COLUM	TATA spare parts
277046103101	NEEDLE ROLLER BEARINGS VAR/RATIO STEERIN	TATA spare parts
277046103102	NEEDLE ROLLER BEARINGS VAR/RATIO STEERIN	TATA spare parts
277046103103	ANGULAR CONTACT BEARINGS VAR/RATIO STEER	TATA spare parts

277046103201	HEX BOLT LPT 1613 TC	TATA spare parts
277046103202	HEX BOLT LPT 1613 TC	TATA spare parts
277046103203	BOLT BOTTOM E/C PLATE VAR/RATIO STEERING	TATA spare parts
277046103204	BOLT - TOP E.PLATE VAR/RATIO STEERING	TATA spare parts
277046103205	BOLT VAR/RATIO STEERING	TATA spare parts
277046104701	END PLATE - TOP VAR/RATIO STEERING	TATA spare parts
277046104702	END PLATE - BOTTOM VAR/RATIO STEERING	TATA spare parts
277046104703	END PLATE - TOP VAR/RATIO STEERING	TATA spare parts
277046104704	END PLATE - BOTTOM VAR/RATIO STEERING	TATA spare parts
277046105101	SECTOR SHAFT VAR/RATIO STEERING	TATA spare parts
277046105102	UNIVERSAL JOINT VAR/RATIO STEERING	TATA spare parts
277046106501	LOCK NUT - ADJUSTER VAR/RATIO STEERING	TATA spare parts
277046107201	OIL FILLER /DRAIN PLUG VAR/RATIO STEERIN	TATA spare parts
277046107801	DUST CAP VAR/RATIO STEERING	TATA spare parts
277046107802	OIL SEAL -WORM VAR/RATIO STEERING	TATA spare parts
277046107803	OIL SEAL - SECTOR SHAFT VAR/RATIO STEERI	TATA spare parts
277046108001	ADJUSTER VAR/RATIO STEERING	TATA spare parts
277046108301	SHIM - 0.075MM VAR/RATIO STEERING	TATA spare parts
277046108302	SHIM - 0.125MM VAR/RATIO STEERING	TATA spare parts
277046108303	SHIM - 0.250MM VAR/RATIO STEERING	TATA spare parts
277046108304	SHIM - 0.036MM VAR/RATIO STEERING	TATA spare parts
277046108601	SPACER VAR/RATIO STEERING	TATA spare parts
277046109201	WASHER - ADJUSTER VAR/RATIO STEERING	TATA spare parts
277046109202	SPRING WASHER C/E PLATE VAR/RATIO STEER	TATA spare parts
277046109203	TAB WASHER VAR/RATIO STEERING	TATA spare parts
277046109901	BREATHER PLUG VAR/RATIO STEERING	TATA spare parts
277046150151	POWER STG PIPE	TATA spare parts
277046200101	ASSY.UNIVERSAL JOINT(3/4INX48/1X79 SER.)	TATA spare parts
277046200103	ASSY INTERMEDIATE SHAFT	TATA spare parts
277046207902	STEERING SPINDLE BOTTOM LPT 1613 TC	TATA spare parts
277046207903	STRG SPINDLE BOTTOM LP1512TC	TATA spare parts
277046600102	ASSY.STG.TANK(PLASTIC VERSION)	TATA spare parts
277046609901	CARTRIDGE PLASTIC RESERVOIR BS1/2/3/4	TATA spare parts
277046609901DF	FILTER STEERING HYDRAULIC-RANE PLASTIC T	TATA spare parts
277046800101	ASSY PIPE	TATA spare parts
277046800102	ASSY PIPE ( 15 OD )	TATA spare parts
277046800103	ASSY PIPE	TATA spare parts
277046800104	ASSY PIPE 15 OD	TATA spare parts
277046800105	ASSY PIPE- 15 OD	TATA spare parts
277046800117	ASSY PIPE 15 OD	TATA spare parts
277047100106	ASY.FUEL RET.LINE WITH RUBBER HOSE(6DIA)	TATA spare parts
277047100113	ASSY TUBE(DIESEL TANK TO INTE.JOINT) 15	TATA spare parts
277047100114	ASSY TUBE (INTERMEDIAT.JOINT TO BABY FIL	TATA spare parts
277047100115	ASSY TUBE (EJECTOR TO INTERM. JOINT 10 O	TATA spare parts
277047100116	ASSY TUBE (INTER.JOINT TO DIESEL TANK 10	TATA spare parts
277047100127	FUEL SUCTION LINE 15 O.D.	TATA spare parts
277047100128	RETURN LINE 10 O.D.	TATA spare parts

277047500101	FUEL TANK STRAP ASSY LOWERED BRACKET	TATA spare parts
277047600101	ASSY TUBE SUCTION	TATA spare parts
277047600102	ASSY TUBE SUCTION	TATA spare parts
277047600104	ASSY.RETURN LINE.	TATA spare parts
277047600108	ASSY.SUCTION PIPE.	TATA spare parts
277047600109	ASSY.RETURN LINE	TATA spare parts
277047600112	ASSY.RETURN LINE-10 O.D.	TATA spare parts
277047600117	FUEL SUCTION PIPE ASSY W/SEP TO TANK	TATA spare parts
277047600118	FUEL SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
277047600119	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
277047600120	FUEL NYLON PIPE ASSY(TANK TO FWS)	TATA spare parts
277047600121	SUCTION LINE ASSY FWS TO ENGINE	TATA spare parts
277047600122	FUEL RETURN LINE ASSY ENGINE TO TANK	TATA spare parts
277047600123	FUEL LINES ASSY (TANK TO FWS)	TATA spare parts
277047600124	FUEL LINES ASSY (FWS TO ENGINE)	TATA spare parts
277047600125	FUEL LINES ASSY (ENGINE TO TANK)	TATA spare parts
277047600126	FUEL LINES ASSY (ENGINE TO TANK)	TATA spare parts
277047600127	FUEL LINES ASSY (FWS TO ENGINE)	TATA spare parts
277047600128	FUEL LINES ASSY (TANK TO FWS)	TATA spare parts
277047600132	FUEL PIPE ASSY SUCTION TANK TO W/SEP	TATA spare parts
277047600133	FUEL SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
277047600134	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
277047700101	BRACKET ASSY FUEL WATER SEPARATOR	TATA spare parts
277047700102	BRACKET FUEL W/SEP MTG -LH	TATA spare parts
277049100102	ASSY.EXHUAUST PIPE-76.2 OD X 1.6 THK	TATA spare parts
277049100103	ASSY.EXHAUST PIPE 76.2 OD X 1.6 THK.	TATA spare parts
277049100105	ASSY.EXHAUST PIPE - II	TATA spare parts
277049100106	ASSY.EXHAUST PIPE - III	TATA spare parts
277049100107	ASSY.PIPE-76.2 OD X 1.6 THK.	TATA spare parts
277049100108	ASSY MUFFLER WITH TAIL PIPE	TATA spare parts
277049100114	ASSY.SILENCER WITH TAIL PIPE	TATA spare parts
277049100118	ASSY. SILENCER WITH TAIL PIPE(LPT1613/42	TATA spare parts
277049100119	ASSY SILENCER	TATA spare parts
277049100121	ASSY EXHAUST PIPE	TATA spare parts
277049100122	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
277049100124	ASSY.EXHAUST PIPE	TATA spare parts
277049103301	BRACKET	TATA spare parts
277049106912	TAIL PIPE	TATA spare parts
277049106917	TAIL PIPE	TATA spare parts
277049108201	BRACKET	TATA spare parts
277049200104	ASSY.EXHAUST PIPE	TATA spare parts
277049200105	ASSY EXHAUST PIPE LPK2516 76OD	TATA spare parts
277049200112	ASSY.EXHAUST PIPE	TATA spare parts
277049200113	ASSY SECOND EXHAUST PIPE	TATA spare parts
277049200114	ASSY EXHAUST SECOND PIPE (WITH FLEXI)	TATA spare parts
277049200115	EXHAUST PIPE ASSY	TATA spare parts
277049200116	ASSY. SECOND EXHAUST PIPE	TATA spare parts



277049200117	ASSY BRACKET EXHAUST BRAKE MTG	TATA spare parts
277049200118	ASSY BRACKET EXH.MTG.	TATA spare parts
277049200119	FLEX PIPE ASSY	TATA spare parts
277049200120	BRACKET ASSY EGP MTG	TATA spare parts
277049200121	UREA AIR MIX PIPE ASSY	TATA spare parts
277049200124	DECOMP PIPE ASSY	TATA spare parts
277049200127	BRACKET ASSY EGP MTG	TATA spare parts
277049203301	EXHAUST BRACKET	TATA spare parts
277049205801	AIR PIPE LINE AIR OIL FILTER TO DU	TATA spare parts
277049206923	EXHAUST TAIL PIPE	TATA spare parts
277049206928	EXHAUST TAIL PIPE	TATA spare parts
277049208201	CLAMP	TATA spare parts
277049208202	BRACKET	TATA spare parts
277049208203	BRACKET	TATA spare parts
277049208204	BRACKET	TATA spare parts
277049208205	BRACKET EGP MTG	TATA spare parts
277049208211	BRACKET EXHAUST PIPE MTG	TATA spare parts
277049609901	HEAT SHIELD ASSY	TATA spare parts
277049609902	HEAT SHIELD ASSY	TATA spare parts
277049609903	HEAT SHIELD ASSY	TATA spare parts
277049609904	HEAT SHIELD ASSY	TATA spare parts
277049609905	HEAT SHIELD ASSY	TATA spare parts
277049609906	HEAT SHIELD ASSY	TATA spare parts
277049609907	HEAT SHIELD ASSY	TATA spare parts
277049609908	HEAT SHIELD ASSY	TATA spare parts
277054110101	ASSY BATTERY CABLE (-VE) 1200 MM.LG.	TATA spare parts
277054110102	ASSY BATTERY CABLE (- VE)	TATA spare parts
277054200101	ASSY KIT WATER-IN-FUEL UNIT(IND)24V	TATA spare parts
277054200103	ASSY BRACKET (HORN MTG.)	TATA spare parts
277054209903	ELECT.HIGH TEMP GAUGE-24V	TATA spare parts
277054209904	SPEEDOMETER 6+1DIGIT RATIO 1:0.80	TATA spare parts
277054209905	HIGH TEMP. WARNING BUZZER UNIT 12V	TATA spare parts
277054209906	HIGH TEMP. WARNING BUZZER UNIT 12V	TATA spare parts
277054209907	SPEEDOCABLE JIS 2900 LG OFFER	TATA spare parts
277054209908	SPEEDOCABLE JIS 2900 LONG	TATA spare parts
277054209909	SPEEDOCABLE JIS 2900 LONG	TATA spare parts
277054209910	SPEEDOCABLE JIS 2900 LG	TATA spare parts
277054209911	SPEEDOMETER 6+1 DIGIT-1:0.80	TATA spare parts
277054209912	R.P.M.METER-1600-2200 RPM	TATA spare parts
277054209913	R.P.M.METER-1600-2200 RPM	TATA spare parts
277054209914	R.P.M.METER (1600-2200 RPM G.B.	TATA spare parts
277054209917	R.P.M.METER-1200-2000 RPM G.B.	TATA spare parts
277054209918	ELECTRIC ACTUATOR (12V)	TATA spare parts
277054209919	SPEEDO CHECK	TATA spare parts
277054209920	ASSY BRACKET	TATA spare parts
277054209921	INSTRUMENT CLUSTER-1:0.80	TATA spare parts
277054209922	WIRING HARNESS INSTRUMENT CLUSTER	TATA spare parts

277054209930	INST. CLUSTER (1:0.80)BS-II 1512TC	TATA spare parts
277054209934	INST.CLUSTER(ELECT)(1:0.80)	TATA spare parts
277054209937	INST.CLUSTER(ELECT)(1:0.80)	TATA spare parts
277054209938	INST.CLUSTER(ELECT)(1:0.80)	TATA spare parts
277054209942	INST.CLUSTER(ELECT)(1:0.80)	TATA spare parts
277054240101	ASSY. KIT WATER IN FUEL UNIT 24V	TATA spare parts
277054240102	ASSY HORN-24 VOLTS	TATA spare parts
277054244601	MICRO RELAY 24V 10A BS1/2/3/4/6	TATA spare parts
277054244602	MICRO RELAY 24V 10A NO W/DIODE	TATA spare parts
277054244603	MICRO RELAY 24V 10A NC	TATA spare parts
277054244901	RELAY 24V 40A	TATA spare parts
277054244902	RELAY 24V	TATA spare parts
277054249901	HIGH TEMP.BUZZER UNIT(24V)	TATA spare parts
277054249902	ELECT TEMP GAUGE-24V	TATA spare parts
277054249904	ASSY. MAGNETIC VALVE-24V-EXH.BRAKE BS1-4	TATA spare parts
277054249905	MAG.VALVE W/SEALED CONN(24V)(EXH.BRK)	TATA spare parts
277054440105	ASSY INDICATOR LAMP-LOW OIL PR	TATA spare parts
277054506901	PIANO KEY SWITCH	TATA spare parts
277054509901	ELECT.SERVICE IND.SWITCH	TATA spare parts
277054600101	ASSY MAIN CABLE SET	TATA spare parts
277054600102	ASSY CABLE SET-STARTER MOTOR TO ST.RLY	TATA spare parts
277054600103	ASSY CABLE SET FRT TO TAIL	TATA spare parts
277054600108	W/H MAIN (LP 1512TC) OFFER	TATA spare parts
277054600117	W/H TAIL (LP1512/59 TC)OFFER	TATA spare parts
277054600119	W/H MAIN LP1512TC INST.CLSTR.	TATA spare parts
277054600121	W/H TAIL-LP1512TC/52_CMVR	TATA spare parts
277054600123	W/H TAIL-LP1512TC/59	TATA spare parts
277054600126	W/H MAIN(LP1512TC BS-II EXH.BRK.PUNE MOD	TATA spare parts
277054600127	W/H ENGINE (LP1512TC BS-II)	TATA spare parts
277054600132	W/H TAIL(LP1512TC/52 BS-II 60% ROH PUNE	TATA spare parts
277054600133	W/H TAIL(LP1512TC/59 BS-II 55%ROH PUNE M	TATA spare parts
277054600142	WIRING HARNESS FRAME ASSY ABS	TATA spare parts
277054600146	MAIN WIRING HARNESS	TATA spare parts
277054600154	W/H ABS	TATA spare parts
277054600157	WIRING HARNESS ABS	TATA spare parts
277054600158	WIRING HARNESS ABS FRAME	TATA spare parts
277054600159	WIRING HARNESS RSL MOTOR	TATA spare parts
277054600161	WIRING HARNESS RSL MOTOR	TATA spare parts
277054600163	WIRING HARNESS MAIN	TATA spare parts
277054600165	WIRING HARNESS MAXI FUSE	TATA spare parts
277054600167	WIRING HARNESS ENGINE	TATA spare parts
277054600169	WIRING HARNESS AFTER TREATMENT	TATA spare parts
277054600171	WIRING HARNESS P-CAN	TATA spare parts
277054600173	PIGTAIL OIL PRESSURE GAUGE	TATA spare parts
277054600175	WIRING HARNESS ABS SPLIT	TATA spare parts
277054600177	WIRING HARNESS TAIL	TATA spare parts
277054600179	WIRING HARNESS TAIL	TATA spare parts

277054600181	WIRING HARNESS TAIL	TATA spare parts
277054600183	WIRING HARNESS ENGINE	TATA spare parts
277054601663	WIRING HARNESS MAIN	TATA spare parts
277054601667	WIRING HARNESS ENGINE	TATA spare parts
277054601668	WIRING HARNESS MAIN	TATA spare parts
277054601671	WIRING HARNESS TAIL	TATA spare parts
277054601672	WIRING HARNESS TAIL	TATA spare parts
277054610109	WIRING HARNESS MAIN	TATA spare parts
277054620101	WIRING HARNESS	TATA spare parts
277054620102	W/HARNESS CONSOLE LP 1512TC	TATA spare parts
277054620103	W/HARNESS ST.RELAY LP 1512TC	TATA spare parts
277054620104	W/HARNESS TAIL LP 1512/52 TC	TATA spare parts
277054620105	W/HARNESS HORN	TATA spare parts
277054620108	WIRING HARNESS ENGINE LP1512 TC	TATA spare parts
277054620114	W/H MAIN-LP 1512TC	TATA spare parts
277054620119	ENGINE CABLE 2515	TATA spare parts
277054620127	W/H TAIL-LP1512/59 TC	TATA spare parts
277054620131	W/H TAIL-LP1512TC/52_CMVR	TATA spare parts
277054620132	W/H TAIL-LP1512TC/59	TATA spare parts
277054620134	W/H MAIN LP1512TC INST.CLSTR.	TATA spare parts
277054620135	W/H MAIN(LP1512TC BS-II EXH.BRK.PUNE MOD	TATA spare parts
277054620136	W/H ENGINE (LP1512TC BS-II)	TATA spare parts
277054620141	W/H TAIL(LP1512TC/52 BS-II 60% ROH PUNE	TATA spare parts
277054620142	W/H TAIL(LP1512TC/59 BS-II 55%ROH PUNE M	TATA spare parts
277054620146	W/H MAIN LP1512TC WITH OIL PR.GAU	TATA spare parts
277054620164	W/H MAIN LP-1512 TC BS-II AMMETER & SPEE	TATA spare parts
277054620167	W/H ENGINE WITH OPG	TATA spare parts
277054620168	W/H TAIL53/55	TATA spare parts
277054620169	W/H TAIL/62	TATA spare parts
277054620170	WIRING HARNESS TAIL	TATA spare parts
277054620173	W/H MAIN LPO 1512/1618 WITH ERGOPACK	TATA spare parts
277054620178	WIRING HARNESS MAIN	TATA spare parts
277054620180	WIRING HARNESS ENGINE	TATA spare parts
277054620181	MAIN WIRING HARNESS	TATA spare parts
277054620182	WIRING HARNESS TAIL	TATA spare parts
277054620183	WIRING HARNESS TAIL	TATA spare parts
277054620184	WIRING HARNESS TAIL	TATA spare parts
277054620201	WIRING HARNESS AUTO DRAIN	TATA spare parts
277054660101	W/H MAIN-LP 1512TC	TATA spare parts
277054660102	WIRING HARNESS TAIL-LP 1512TC/52	TATA spare parts
277054660110	W/H ENGINE-LP1512/LPT1613TC	TATA spare parts
277054660111	W/HARNESS MAIN LP1512TC	TATA spare parts
277054660113	W/H PANEL LAMPS	TATA spare parts
277054660114	W/H EARTHING GAUGES	TATA spare parts
277054660115	W/HARNESS TAIL W B 52 LP1512TC	TATA spare parts
277054660116	W/H TAIL-LP1512/59 TC	TATA spare parts
277054660117	W/H MAIN-LP1512 TC-MSRTC	TATA spare parts

277054660118	WIRING HARNESS ENGINE-LP1512TC-MSRTC	TATA spare parts
277054660123	WIRING HARNESS MAIN LP1512TC	TATA spare parts
277054660126	W/H MAIN-LP1512TC-CMVR	TATA spare parts
277054660127	W/H TAIL-LP1512TC-CMVR 52WB	TATA spare parts
277054660128	W/H TAIL-LP1512TC/59	TATA spare parts
277054660130	W/H MAIN LP1512TC INST.CLSTR.	TATA spare parts
277054660133	W/H ENGINE (LP1512TC BS-II)	TATA spare parts
277054660134	W/H TAIL(LP1512TC/52 BS-II 60% ROH PUNE	TATA spare parts
277054660135	W/H TAIL(LP1512TC/59 BS-II 55%ROH PUNE M	TATA spare parts
277054660136	W/H MAIN(LP1512TC BS-II EXH.BRK.PUNE MOD	TATA spare parts
277054660138	WIRING HARNESS TAIL	TATA spare parts
277054660145	W/H ENGINE LP1512TC WITH OIL P.GAUGE	TATA spare parts
277054660162	W/H MAIN LP-1512 TC BS-II	TATA spare parts
277054660165	W/HENGINEWITHOPG.	TATA spare parts
277054700101	PLATE ASSY MOTOR MTG	TATA spare parts
277060100101	ASSY COWL COMP.W/FITMENTS	TATA spare parts
277060100102	ASSY COWL COMP W/P. STRG.	TATA spare parts
277081800101	ASSY MASCOT 1512 TC	TATA spare parts
277082400103	ASSY BRACKET (WIPER MOTOR MTG.)	TATA spare parts
277082400106	ASSY WIPER ARM & BLADE	TATA spare parts
277082409902	WHEEL BOX (60MM CRANK LG.)	TATA spare parts
277126010101	ASSY.GEAR SHIFT LINKAGES 1615TC RE BUS	TATA spare parts
277126800101	GEAR SHIFT LEVER	TATA spare parts
277126800106	ASSY TUBE	TATA spare parts
277126800107	ASSY TUBE	TATA spare parts
277126810101	ASSY. ANGLE PIECE (ON L.M. TO SUPPORT CO	TATA spare parts
277126810105	ASSY BRACKET	TATA spare parts
277129100101	ASSY. CLUTCH CONNECTING LINE (10 DIA.) (	TATA spare parts
277129100102	ASSY.CLUTCH PIPE (6 O.D.)	TATA spare parts
277129100103	ASSY.CLUTCH PIPE (6 O.D.)	TATA spare parts
277129100104	ASSY.CLUTCH PIPE (6 O.D.)	TATA spare parts
277130100103	ASSY. ACCELERATOR LEVER	TATA spare parts
277130100109	ASSY. PULL ROD COMPLETETE	TATA spare parts
277130100115	ASSY. PULL ROD	TATA spare parts
277130100118	ASSY. PULL ROD COMPLETE.	TATA spare parts
277130200101	ASSY. PULL CABLE ENG STOP	TATA spare parts
277131000101	ASSY. FRAME COMPLT. / 59 WB.	TATA spare parts
277132100101	ASSY SPRING MTG BKT FR	TATA spare parts
277132100102	SPRING MTG BKT LH REAR	TATA spare parts
277132100103	SPRING MTG BKT RH REAR	TATA spare parts
277132400101	ASSY.REAR SPRING	TATA spare parts
277132504201	U CLAMP	TATA spare parts
277132800102	ASSY.CONNECTING LINK	TATA spare parts
277132800103	ANTIROLL BAR BRACKET - FRONT	TATA spare parts
277142900102	NYLON BRAKE PIPE SET COMPLETE COWL+CHASS	TATA spare parts
277142900106	ASSY.METAL PIPE (15 O.D.)	TATA spare parts
277146800102	ASSY.STG.PIPE-18 O.D.	TATA spare parts

277146800103	ASSY.STG.PIPE (18 O.D.)	TATA spare parts
277146800104	ASSY.STG.PIPE (15 O.D.)	TATA spare parts
277146800105	ASSY.STG.PIPE (15 O.D.)	TATA spare parts
277146800106	ASSY.STG.PIPE (15 O.D.)	TATA spare parts
277146800107	ASSY.STG.PIPE (15 O.D.)	TATA spare parts
277146800108	ASSY.STG.PIPE-15 O.D.	TATA spare parts
277146800112	ASSY.STG.PIPE- 15 O.D.	TATA spare parts
277146800113	ASSY.STG.PIPE ( 15 O.D.)	TATA spare parts
277146800119	ASSY.STG.PIPE ( 22 O.D.)	TATA spare parts
277146800120	ASSY.STG.PIPE ( 22 O.D.)	TATA spare parts
277146800121	ASSY.STG.PIPE( 22 O.D.)	TATA spare parts
277147600104	ASSY RETURN PIPE.	TATA spare parts
277147600105	ASSY RETURN PIPE.	TATA spare parts
277154100102	BATT CABLE	TATA spare parts
277154100103	ASSY BATT.CABLE +VE-950 MM LG.	TATA spare parts
277154100104	ASSY BATT.CABLE -VE-800 MM LG.	TATA spare parts
277154200101	KIT FOR SPEEDOCABLE COUPLER (JIS)& CLAMP	TATA spare parts
277154209902	SPEEDOCABLE-JIS 3600 LG. OFFER	TATA spare parts
277154209903	SPEEDOCABLE-JIS 3000 LG. OFFER	TATA spare parts
277154820101	ASSY MAIN CABLE SET (RHD) LPO1615/59 RE	TATA spare parts
277154820102	ASSY CABLE SET (FRT TO TAIL)59W.B.RE RHD	TATA spare parts
277154820103	ASSY CABLE SET-INST.PANEL-RHD	TATA spare parts
277446306001	PITMAN ARM RHD	TATA spare parts
277454100102	ASSY BATTERY CABLE -VE 2000MM	TATA spare parts
277454240101	EMOS CONTROLLER 24V	TATA spare parts
277454440120	LAMP SIDE MARKER - 24V	TATA spare parts
277454700101	ASSY BLOWER MOTOR W/BKT-24V	TATA spare parts
277454700103	ASSY BLOWER MOTOR W/BACKET 12V	TATA spare parts
277515400107	ALTERNATOR 12V 90A W/VP W/ZENER	TATA spare parts
277554206301	CAP W/RETAINER RING-GREY	TATA spare parts
277554206302	CAP W/RETAINER RING-BLACK JAIHIND	TATA spare parts
277554209922	ILLUMINATING RING-PRIOL	TATA spare parts
277554209924	SOCKET W/O ILLUMINATING RING	TATA spare parts
277565108602	SPECIAL WASHER FOR ROOF RAIL MOUNTING	TATA spare parts
277615219901	GAS PRESSURE SENSOR CNG BS4	TATA spare parts
277615219903	GAS TEMPERATURE SENSOR CNG BS-IV	TATA spare parts
277615400104	ALTERNATOR 24V 80A LIN BS6-PH2	TATA spare parts
277615408801	HEX STUD	TATA spare parts
277615608201	BRACKET FOR CIGAR COIL BUNDLE SUPPROT	TATA spare parts
277615608202	BRACKET FOR CIGAR COIL BRANCH SUPPORT	TATA spare parts
277615608206	BRACKET FOR W/H BRANCH CAM SENSOR 697/49	TATA spare parts
277615608207	BRACKET FOR W/H SUPPORT AT WATER INLET	TATA spare parts
277615608209	BRACKET-1 FOR W/H SUPPORT ON INTAKE MANI	TATA spare parts
277615608210	BRACKET-2 FOR W/H SUPPORT ON INTAKE MANI	TATA spare parts
277615608211	BRACKET FOR SENSOR BRANCH SUPPORT ON CO	TATA spare parts
277615608212	BRACKET FOR W/H BRANCH SUPPORT ON TGH	TATA spare parts
277615608215	BRACKET W/H SUPPORT ON CHASSIS	TATA spare parts

277615608216	BKT FOR INTERCONN CONNECTOR PARKING ON C	TATA spare parts
277615608217	BRACKET W/H SUPPORT AT ETB 697 CNG BSIV	TATA spare parts
277616204902	ECU BS6	TATA spare parts
277624200109	ASSY BOTTOM BKT-RH (ENGINE MTG REAR)	TATA spare parts
277624200110	ASSY BOTTOM BKT-LH (ENGINE MTG REAR)	TATA spare parts
277624200111	ASSY BRACKET-RH (ENG MTG REAR TOP)	TATA spare parts
277624200112	ASSY BRACKET-LH (ENG MTG REAR TOP)	TATA spare parts
277624203701	ENGINE MTG ASSY REARFLASELH BS6-PH2	TATA spare parts
277624203702	ENGINE MTG ASSY REARFLASELH BS6-PH2	TATA spare parts
277626800102	ASSY TURNING TUBE (W/O BALL JOINT)	TATA spare parts
277626800104	ASSY TURNING TUBE (W/O BALL JOINT)	TATA spare parts
277626800108	ASSY. TURNING TUBE W/O BALL JOINT	TATA spare parts
277626800119	TURNING TUBE ASSY BS6	TATA spare parts
277626800122	GEAR SHIFT LEVER BS6	TATA spare parts
277626809901	GEAR SHIFT LEVER (LPO 1613 CNG BSIV)	TATA spare parts
277626809903	GEAR SHIFT LEVER BS6	TATA spare parts
277626810101	ASSY BRACKET (G.S.L.MTG.)	TATA spare parts
277626810102	ASSY SUPPORT BRACKET	TATA spare parts
277626810103	ASSY BRACKET (G.S.L.MTG.)	TATA spare parts
277626810105	ASSY. BRACKET (G.S.L. MOUNTING)	TATA spare parts
277626810106	BRACKET ASSY BS6	TATA spare parts
277629100106	PIPE ASSY.-CLUTCH M/CYL. TO CL. BOOSTER	TATA spare parts
277629100114	PIPING CLUTCH BOOSTER	TATA spare parts
277629100121	PIPING MASTER CYLINDER TO SLAVE CYLINDER	TATA spare parts
277629100123	ASSY HYD PIPE(M/CYL TO BOOSTER)	TATA spare parts
277629100124	ASSY_RUBBER_HOSE	TATA spare parts
277629100125	ASSY HYD PIPE(2ND PIPE)	TATA spare parts
277629100129	HYDRAULIC PIPE	TATA spare parts
277629100138	CLUTCH HOSE ASSY BS6	TATA spare parts
277629106924	HOSE MASTER CYLINDER TO FLUID CONTAINER	TATA spare parts
277629300102	ASSY. PUSH ROD	TATA spare parts
277629300106	NYLON PIPE ASSY T-CONN TO CLUTCH BOOSTER	TATA spare parts
277629300107	NYLON PIPE ASSY T-CONN TO CLUTCH BOOSTER	TATA spare parts
277629300108	BUNDY TUBE ASSY BS6	TATA spare parts
277629300110	NYLON PIPE ASSY T-CONN TO CLUTCH BOOSTER	TATA spare parts
277629300111	NYLON PIPE ASSY T-CONN TO CLUTCH BOOSTER	TATA spare parts
277629300112	CLUTCH BOOSTER ASSY	TATA spare parts
277629300114	CLUTCH MASTER CYLINDER WITH RESERVOIR BS	TATA spare parts
277629350101	ASSY BRACKET CLUTCH BOOSTER MTG	TATA spare parts
277629500103	ASSY CONTROLS COMPLETE	TATA spare parts
277629500108	BRACKET ASSY CLUTCH PEDAL - SENSOR MTG B	TATA spare parts
277629500109	BRACKET ASSY CLUTCH BOOSTER MTG BS6-PH2	TATA spare parts
277630100104	ASSY ACCELARATOR LEVER WITHOUT BALL PIN	TATA spare parts
277630100106	ASSY. PULL ROD	TATA spare parts
277630100108	ASSY. BRACKET -ACCLERATOR CONTROL	TATA spare parts
277630100118	ASSY. PULL ROD	TATA spare parts
277630100121	ASSY. PULL ROD	TATA spare parts

277630100124	ASSY. PULL ROD	TATA spare parts
277630100136	ASSY.LEVER ACCELERATOR PEDAL	TATA spare parts
277630107107	RETURN SPRING BRACKET	TATA spare parts
277630108702	RETURN SPRING	TATA spare parts
277631000101	ASSY FRAME COMPLETE	TATA spare parts
277631000104	FRAME ASSY WITH FITMENT	TATA spare parts
277631000105	ASSY. FRAME - 900MM FLOOR HEIGHT (RAS)	TATA spare parts
277631000106	ASSY. FRAME - 900MM FLOOR HEIGHT	TATA spare parts
277631000107	ASSY.FRAME 900MM FLOOR HT	TATA spare parts
277631000109	ASSY. FRAME - 900 FLOOR HEIGHT	TATA spare parts
277631000126	FRAME ASSY WITH FITMENT BS6	TATA spare parts
277631000129	FRAME ASSY WITH FITMENT BS6	TATA spare parts
277631107111	LONG MEMBER - REAR PART RH	TATA spare parts
277631107112	LONG MEMBER - REAR PART LH	TATA spare parts
277631108201	GUSSET RH	TATA spare parts
277631108202	GUSSET LH	TATA spare parts
277631108203	REINFORCEMENT-RH	TATA spare parts
277631108204	REINFORCEMENT-LH	TATA spare parts
277631108205	REINFORCEMENT RH BS6	TATA spare parts
277631108206	REINFORCEMENT LH BS6	TATA spare parts
277631200101	ASSY.SUPPORT RH -ENG.MTG.CM FRONT	TATA spare parts
277631200102	ASSY.SUPPORT LH -ENG.MTG.CM FRONT	TATA spare parts
277631200103	ASSY.SUPPORT RH -ENG.MTG.CM REAR	TATA spare parts
277631200104	ASSY.SUPPORT LH -ENG.MTG.CM REAR	TATA spare parts
277631200105	ASSY.SUPPORT -ENG.MTG.CM FRONT	TATA spare parts
277631200108	ASSY. CROSS MEMBER.	TATA spare parts
277631200109	ASSY. CROSS MEMBER	TATA spare parts
277631200114	ASSY CROSS MEMBER	TATA spare parts
277631200116	ASSY. SUPPORT CROSS MEMBER	TATA spare parts
277631200117	ASSY. CROSS MEMEBR	TATA spare parts
277631200121	ASSY.ENGINE CROSS MEMBER (REAR)	TATA spare parts
277631200122	ASSY. SUPPORT BRACKET	TATA spare parts
277631200130	GUSSET ASSY WITH RIB	TATA spare parts
277631200141	CROSS MEMBER ASSY BUMPER BS6	TATA spare parts
277631200144	BRKT ASSY CROSS MEMBER MTG FRT-RH BS6-PH	TATA spare parts
277631200145	BRKT ASSY CROSS MEMBER MTG FRT-LH BS6-PH	TATA spare parts
277631200146	BRKT ASSY CROSS MEMBER MTG FRT-RH BS6-PH	TATA spare parts
277631200147	BRKT ASSY CROSS MEMBER MTG FRT-LH BS6-PH	TATA spare parts
277631207137	SUPPORT -LH (ENG. CM FRONT )	TATA spare parts
277631207140	BRACKET SUPPORT CROSS MEMBER	TATA spare parts
277631207141	REINFORCEMENT- RH	TATA spare parts
277631207142	REINFORCEMENT- LH SIDE	TATA spare parts
277631207146	C-CHANNEL-RH	TATA spare parts
277631207147	C-CHANNEL-LH	TATA spare parts
277631207148	SUPPORT BRACKET	TATA spare parts
277631208208	PACKING SHEET BS6	TATA spare parts
277631307103	REINFORCEMENT RH	TATA spare parts

277631307104	REINFORCEMENT LH	TATA spare parts
277631307105	REINFORCEMENT - RH FRONT SPRING BKT REAR	TATA spare parts
277631307106	REINFORCEMENT - LH FRONT SPRING BKT REAR	TATA spare parts
277631307107	REINFORCEMENT-RH	TATA spare parts
277631307108	REINFORCEMENT-LH	TATA spare parts
277631307124	SPACER PLATE	TATA spare parts
277631700101	ASSY. OUTRIGGER COMPLETE	TATA spare parts
277631700102	ASSY. OUTRIGGER COMPLETE	TATA spare parts
277631700106	ASSY. OUTRIGGER	TATA spare parts
277631700107	ASSY. OUTRIGGER	TATA spare parts
277631700109	ASSY. OUTRIGGER COMPLETE (REAR-FIRST)	TATA spare parts
277631700110	ASSY. OUTRIGGER COMPLETE REAR	TATA spare parts
277631700112	ASSY. OUTRIGGER REAR	TATA spare parts
277631700113	ASSY. OUTRIGGER REAR	TATA spare parts
277631700114	ASSY OUTRIGGER COMPLETE	TATA spare parts
277631700116	ASSY OUTRIGGER COMPLETE	TATA spare parts
277631700118	ASSY. OUTRIGGER (FRONT RH SIDE)	TATA spare parts
277631700119	ASSY. OUTRIGGER (FRONT LH SIDE)	TATA spare parts
277631700122	ASSY. OUTRIGGER COMPLETE WHEEL ARCH RH	TATA spare parts
277631700123	ASSY. OUTRIGGER COMPLETE WHEEL ARCH LH	TATA spare parts
277631700125	ASSY. OUTRIGGER - REAR LH	TATA spare parts
277631700130	ASSY BRACKET - RH SIDE	TATA spare parts
277631700131	ASSY BRACKET - LH SIDE	TATA spare parts
277631700143	ASSY.OUTRIGGER(WHEEL ARCH SIDE FRT-RH)	TATA spare parts
277631700144	ASSY.OUTRIGGER(WHEEL ARCH SIDE FRT-LH)	TATA spare parts
277631700145	ASSY.OUTRIGGER-RH FIRST	TATA spare parts
277631700146	ASSY. OUTRIGGER - FIRST LH SIDE	TATA spare parts
277631700150	ASSY OUTRIGGER COMPLETE (SHORTEN LENGTH)	TATA spare parts
277631700167	OUTRIGGER ASSY	TATA spare parts
277631700170	OUTRIGGER ASSY	TATA spare parts
277631700172	ASSY. OUTRIGGER COMPLETE BS6	TATA spare parts
277631700173	ASSY. OUTRIGGER COMPLETE (REAR-FIRST) BS	TATA spare parts
277631700174	ASSY. OUTRIGGER COMPLETE REAR BS6	TATA spare parts
277631700175	OUTRIGGER ASSY BS6	TATA spare parts
277631700176	ASSY. OUTRIGGER - FIRST LH SIDE BS6	TATA spare parts
277631700177	ASSY.OUTRIGGER(WHEEL ARCH SIDE FRT-RH) B	TATA spare parts
277631707157	SPACER PLATE	TATA spare parts
277631707158	SUPPORT BRACKET	TATA spare parts
277631707162	SUPPORT BRACKET	TATA spare parts
277632100103	ASSY. FRONT SPRING	TATA spare parts
277632100107	ASSY FRONT SPRING	TATA spare parts
277632100108	ASSY FRONT SPRING	TATA spare parts
277632100109	ASSY. FIRST LEAF WITH END CLIPS	TATA spare parts
277632100109DF	MAIN LEAF FRONT W/END CLIPS-LPO1613/1618	TATA spare parts
277632100110	ASSY. SECOND LEAF WITH END CLIPS	TATA spare parts
277632100110DF	SECOND LEAF FRONT W/END CLIPS-LPO1613/16	TATA spare parts
277632100120	KIT-RETRO FITMENT SUSPENSION FRONT	TATA spare parts



277632103201	CENTER BOLT	TATA spare parts
277632103203	CENTER BOLT	TATA spare parts
277632103204	CENTER BOLT	TATA spare parts
277632104201	SPRING CLIP	TATA spare parts
277632107103	THIRD LEAF	TATA spare parts
277632107103DF	THIRD LEAF FRONT--LPO1613/1618	TATA spare parts
277632107104	FOURTH LEAF	TATA spare parts
277632107104DF	FOURTH LEAF FRONT-LPO1613/1618	TATA spare parts
277632107105	FIFTH LEAF	TATA spare parts
277632107106	SIXTH LEAF	TATA spare parts
277632107107	SEVENTH LEAF	TATA spare parts
277632107108	EIGHTH LEAF	TATA spare parts
277632107109	NINENTH LEAF	TATA spare parts
277632107110	SPACER	TATA spare parts
277632204203	U BOLT M20X1.5X305	TATA spare parts
277632300101	ASSY. BRACKET (FRONT SHOCK ABSORBER)	TATA spare parts
277632300103	BRACKET ASSY SHOCK ABSORBER	TATA spare parts
277632400116	LEVELLING VALVE MAJOR ASSY - LH	TATA spare parts
277632400117	LEVELLING VALVE MAJOR ASSY - RH	TATA spare parts
277632400129	LEVELLING VALVE MAJOR ASSY. LH	TATA spare parts
277632400130	LEVELLING VALVE MAJOR ASSY. RH	TATA spare parts
277632400136	ASSY. FIRST LEAF WITH END CLIPS	TATA spare parts
277632400137	ASSY. SECOND LEAF WITH CLIP ENDS	TATA spare parts
277632403402	SPHERILASTIC BUSH FOR RADIUS ROD	TATA spare parts
277632404204	U CLAMP M22X2.5X380	TATA spare parts
277632407103	LINK CHANNEL	TATA spare parts
277632407114	THIRDLEAF BS6	TATA spare parts
277632407115	FOURTHLEAF BS6	TATA spare parts
277632407116	FIFTHLEAF BS6	TATA spare parts
277632407117	SIXTHLEAF BS6	TATA spare parts
277632407118	SEVENTHLEAF BS6	TATA spare parts
277632407119	EIGHTHLEAF BS6	TATA spare parts
277632407120	NINENTHLEAF BS6	TATA spare parts
277632407121	TENTHLEAF BS6	TATA spare parts
277632407122	ELEVENTHLEAF BS6	TATA spare parts
277632407123	TWELFTHLEAF BS6	TATA spare parts
277632407124	THIRTEENTHLEAF BS6	TATA spare parts
277632407125	FOURTEENTHLEAF BS6	TATA spare parts
277632600101	ASSY. REAR SHOCK ABSORBER	TATA spare parts
277632600103	ASSY. REAR SHOCK ABSORBER	TATA spare parts
277632603201	HEX.BOLT M24X1.5	TATA spare parts
277632800101	ASSY CONNECTING LINK	TATA spare parts
277632803401	BUSH HALF ( BOTTOM )	TATA spare parts
277632803402	BUSH HALF ( TOP )	TATA spare parts
277633000102	ASSY. FRONT AXLE WITH BRAKES COMPLETE	TATA spare parts
277633000105	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
277641100107	ASSY.PROP SHAFT FRONT (L=1926)	TATA spare parts

277641100126	ASSY PROPELLER SHAFT FRONT	TATA spare parts
277641100127	ASSY PROPELLER SHAFT MIDDLE	TATA spare parts
277641100132	ASSY PROPELLER SHAFT FRONT & MIDDLE	TATA spare parts
277641100133	CENTRE BEARING ASSEMBLY	TATA spare parts
277641100142	SHORT FORK TUBE ASSEMBLY	TATA spare parts
277641100143	SHORT FORK TUBE ASSEMBLY	TATA spare parts
277641100147	ASSY PROP SHAFT L-1802 DIA 100 325HSDRHC	TATA spare parts
277641100148	ASSY PROP SHAFT FRONT L-1817 DIA 100 325	TATA spare parts
277641100161	PROPELLER SHAFT ASSY WITH CB L-1512 325H	TATA spare parts
277641105101	COMPANION FLANGE	TATA spare parts
277641107101	PROPELLER SHAFT GUARD	TATA spare parts
277641107102	GUARD PROP SHAFT	TATA spare parts
277641107103	PROP SHAFT GUARD FRT TOP	TATA spare parts
277641109901	SLINGER	TATA spare parts
277641110104	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
277641110105	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
277641110106	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
277641110107	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
277641110108	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
277641110109	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
277641110110	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
277641110111	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
277641110112	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
277641110117	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
277641110118	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
277641110130	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
277641120101	ASSY PROPELLER SHAFT REAR	TATA spare parts
277641120108	ASSY REAR PROP SHAFT L-1566 DIA 100 325H	TATA spare parts
277641120113	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
277641120114	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
277641120115	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
277641120116	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
277641120117	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
277641120121	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
277641300102	CENTRE BEARING RETAINER ASSEMBLY	TATA spare parts
277641300103	BRACKET ASSY-CENTER BRG MTG BS6	TATA spare parts
277641300104	BRACKET ASSY-CENTER BRG MTG BS6	TATA spare parts
277641303301	CENTER BEARING BRACKET	TATA spare parts
277641303302	CENTER BEARING BRACKET	TATA spare parts
277641303305	CENTER BEARING BRACKET	TATA spare parts
277641303306	CENTER BEARING BRACKET	TATA spare parts
277641303308	CENTER BEARING BRACKET	TATA spare parts
277641303311	CENTER BEARING BRACKET	TATA spare parts
277641303312	CENTER BEARING ASEMBLY	TATA spare parts
277641303314	CENTER BEARING & RETAINER ASEMBLY	TATA spare parts
277641303321	CENTER BRG. MTG. BRKT	TATA spare parts
277641303322	CENTER BRG. MTG. BRKT	TATA spare parts

277641990102	ASSY SHORT FORK TUBE & FRT END PIECE(FOR	TATA spare parts
277642100114	SLEEVE FOR DTC STONE GUARD	TATA spare parts
277642100117	ASSEMBLY STONE GUARD LH FOR DTC	TATA spare parts
277642100118	ASSEMBLY STONE GUARD RH FOR DTC.	TATA spare parts
277642100122	KIT OF DISC BRAKE PAD	TATA spare parts
277642100143	PAD ASSEMBLY FOR DISC BRAKE	TATA spare parts
277642100145	DISC BRAKE PAD ASSEMBLY FOR MER	TATA spare parts
277642103701	BRAKE DRUM FRONT BS3/4	TATA spare parts
277642103702	BRAKE DRUM FRONT BS3/4	TATA spare parts
277642103703	BRAKE DRUM FRONT	TATA spare parts
277642103705	BRAKE DRUM E3	TATA spare parts
277642103706	BRAKE DRUM-REAR	TATA spare parts
277642103707	BRAKE DRUM - FRONT BS4	TATA spare parts
277642103709	BRAKE DRUM	TATA spare parts
277642103713	BRAKE DRUM	TATA spare parts
277642106301	BRAKE LINER STD 410X200	TATA spare parts
277642106302	BRKAE LINER STD 410X220	TATA spare parts
277642107901	S CAM SHAFT FRONT BRAKE - LH	TATA spare parts
277642107902	S CAM SHAFT FRONT BRAKE - RH	TATA spare parts
277642109901	FRONT BRAKE LINER KIT STD SIZE	TATA spare parts
277642130101	BRAKE LINING KIT	TATA spare parts
277642130102	LINING BRAKE KIT FRONT	TATA spare parts
277642300141	CAMSHAFT BUSHING AND SEAL DRIVER	TATA spare parts
277642300142	ASSY BRAKE LH W/DC (W /BRASS BUSH)	TATA spare parts
277642300143	ASSY BRAKE RH W/DC (W /BRASS BUSH)	TATA spare parts
277642300181	AUTO SLACK ADJ 150 CD 16 OFFSET LH	TATA spare parts
277642300182	AUTO SLACK ADJ 150 CD 16 OFFSET RH	TATA spare parts
277642300183	REAR BRAKE ASSY. FOR LPO1613 DT	TATA spare parts
277642300184	REAR BRAKE ASSY. FOR LPO1613 DT	TATA spare parts
277642300190	AUTO SLACK ADJUSTER -LH 150CD 16 OFFSET	TATA spare parts
277642300191	AUTO SLACK ADJUSTER -RH 150CD 16 OFFSET	TATA spare parts
277642300192	REAR BRAKE ASSEMBLY LH	TATA spare parts
277642300193	REAR BRAKE ASSEMBLY RH	TATA spare parts
277642300194	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
277642300195	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
277642300229	ASSEMBLY GREASE NIPPLE WITH ADAPTOR ELB	TATA spare parts
277642300230	AUTO SLACK ADJUSTER 43 MM OFFSET LH	TATA spare parts
277642300231	AUTO SLACK ADJUSTER 43 MM OFFSET RH	TATA spare parts
277642300246	GREASE NIPPLE	TATA spare parts
277642300247	ASSY. REAR BRAKE LH W/T D/C	TATA spare parts
277642300248	ASSY. REAR BRAKE RH W/T D/C	TATA spare parts
277642300258	DRUM BRAKE ASSY REAR LH W/T D/C	TATA spare parts
277642300259	DRUM BRAKE ASSY REAR RH W/T D/C	TATA spare parts
277642300260	DRUM BRAKE ASSY REAR LH W/T D/C.	TATA spare parts
277642300261	DRUM BRAKE ASSY REAR RH W/T D/C	TATA spare parts
277642300265	ASSY.R/A BRAKE WITH D/C-LH	TATA spare parts
277642300266	ASSY.R/A BRAKE WITH D/C-RH	TATA spare parts

277642303701	BRAKE DRUM(410X220) FOR BUSES BS3/4	TATA spare parts
277642303702	BRACKET ASSY,ACTUATOR MTG,REAR-LH	TATA spare parts
277642303703	CAST CHMABER MTG BKT AAL RH	TATA spare parts
277642303704	CAST CHMABER MTG BKT LH	TATA spare parts
277642303705	CAST CHMABER MTG BKT RH	TATA spare parts
277642303706	BRAKE DRUM REAR (108RR NGT )BS3/4	TATA spare parts
277642303707	CAST CHAMBER MOUNTING BRACKET LH	TATA spare parts
277642303708	CAST CHAMBER MOUNTING BRACKET RH	TATA spare parts
277642303709	BRAKE DRUM SPIGOTTED BS3/4	TATA spare parts
277642303710	BRACKET ACTUATOR MTG LH	TATA spare parts
277642303711	BRACKET ACTUATOR MTG RH	TATA spare parts
277642303714	REAR BRAKE DRUM BS3/4	TATA spare parts
277642305102	CAM SHAFT LH FOR REAR BRAKE	TATA spare parts
277642305103	CAM SHAFT RH FOR REAR BRAKE	TATA spare parts
277642305111	CAM SHAFT - LH	TATA spare parts
277642305112	CAM SHAFT - RH	TATA spare parts
277642308201	ANCHOR BRACKET FOR 60OFFSET SLACK	TATA spare parts
277642308601	SPACER FOR CAST BRACKET FOR BUSES	TATA spare parts
277642308602	SPACER FOR REAR BRAKE ASSEMBLY	TATA spare parts
277642308603	SPACER FOR ASA	TATA spare parts
277642309902	REAR BRAKE LINER KIT STD SIZE	TATA spare parts
277642990103	KIT TORQUE PLATE	TATA spare parts
277642990104	KIT BUSH	TATA spare parts
277642990105	KIT-BRAKE BUSH BS6	TATA spare parts
277642990109	LINED SHOE ASSY	TATA spare parts
277642990130	KIT SHIM	TATA spare parts
277642990140	KIT-BRAKE	TATA spare parts
277642990141	KIT-BRAKE	TATA spare parts
277642993701	DRUM BRAKE ASSY REAR TORQUE PLATE M/CING	TATA spare parts
277643200101	ASSY.20LIT AIR TANK METRIC PORT	TATA spare parts
277643200102	ASSY.30LIT AIR TANK WITH 240PITCH	TATA spare parts
277643200103	ASSY. 20 LIT. AIR TANK 240 PITCH	TATA spare parts
277643200104	ASSY. 30 LIT. AIR TANK 240 PITCH (METRIC	TATA spare parts
277643200105	ASSY. 20 LIT. AIR TANK 240 PITCH- RH	TATA spare parts
277643200106	AIR TANK ASSY 30 LIT. 240 PITCH- LH	TATA spare parts
277643200107	AIR TANK ASSY 20 LIT. 240 PITCH- RH	TATA spare parts
277643200108	AIR TANK ASSY 20 LIT. 240 PITCH- LH	TATA spare parts
277643200109	AIR TANK ASSY 30 LIT. 240 PITCH- RH	TATA spare parts
277643700103	ASSY.230CC WITHOUT FLANGE AIR COMPRESSOR	TATA spare parts
277643700107	ASSY.160 CC WATER COOLED COMPRESSOR.	TATA spare parts
277643700108	AIR DRYER WITH 6.9/8.1 PRESSURE	TATA spare parts
277643700110	AIR COMPRESSOR 230CC GEAR DRIVEN	TATA spare parts
277643700115	PURGE TANK MOUNTING BRACKET.	TATA spare parts
277643700116	ASSY. QRV & RELAY VALVE MTG. BRACKET.	TATA spare parts
277643700121	ASSY BKT FOR OIL SEP/CONSEP UNIT	TATA spare parts
277643700122	SYSTEM PROTCTION VALVE -METRIC	TATA spare parts
277643700134	BRACKET ASSY RELAY-MODULATOR VALVE	TATA spare parts

277643700141	AIR COMPRESSOR BS6	TATA spare parts
277643700197	ASSY. CONSEP MTG. BRACKET	TATA spare parts
277643703201	BOLT	TATA spare parts
277643703305	BRACKET BS6	TATA spare parts
277643703308	BRACKET BS6-PH2	TATA spare parts
277643703309	BRACKET SOLENOID VALVE MTG BS6-PH2	TATA spare parts
277643703310	BRACKET BS6-PH2	TATA spare parts
277643703311	BRACKET BS6-PH2	TATA spare parts
277643703312	BRACKET BS6-PH2	TATA spare parts
277643703313	BRACKET BS6-PH2	TATA spare parts
277643703701	CYLINDER BLOCK	TATA spare parts
277643704705	CYLINDER HEAD COVER	TATA spare parts
277643707801	OIL SEAL (M134350)	TATA spare parts
277643708003	ALLEN HEAD SCREW	TATA spare parts
277643708201	PURGE TANK MOUNTING BRACKET.	TATA spare parts
277643708204	SPV. MOUNTING BRACKET	TATA spare parts
277643708212	FR.CIRCUIT RELAY MTG.BKT.FOR LPO1613	TATA spare parts
277643708217	BRACKET QRV MOUNTING	TATA spare parts
277643708219	BRACKET¿ RELAY-MODULATOR VALVE	TATA spare parts
277643709916	FILTER ELEMENT- AIR FILTER	TATA spare parts
277643709917	INSULATION PIPE	TATA spare parts
277643709918	TIP SEAL SET	TATA spare parts
277643709919	GREASE CARTRIDGE	TATA spare parts
277643709920	MAIN BODY MAINTENANCE	TATA spare parts
277643709924	AIR FILTER ASSY COMPLETE	TATA spare parts
277643900128	ASSY.18 OD PIPE COMPLETE.	TATA spare parts
277643900129	ASSY.18 OD PIPE COMPLETE.	TATA spare parts
277643900131	ASSY 6 OD PIPE COMPLETE	TATA spare parts
277643900135	ASSY.6 O.D.PIPE COMPLETE.	TATA spare parts
277643900163	OD12 PURGE TANK TO AIR DRIER	TATA spare parts
277643900171	ASSY.12DIA PIPE TEE TO FR BRK CHAMBER RH	TATA spare parts
277643900172	ASSY.12DIA PIPE TEE TO FR BRAKE CHAM.HOS	TATA spare parts
277643900188	ASSY.6DIA PIPE PARKING BKT TO HBV INLET	TATA spare parts
277643900189	ASSY.12 DIA PIPE HBV TO INTERMEDIAT JONT	TATA spare parts
277643900199	ASSY.6DIA PIPE INTERMEDTE JT TO COMP.HEA	TATA spare parts
277643900201	BRACKET ASSY. Z SECTION PIPING MTG.	TATA spare parts
277643900208	METAL PIPE ASSY COMP TO AIR DRYER(FORTH	TATA spare parts
277643900209	METAL PIPE ASSY COMP TO AIR DRYER(THIRD	TATA spare parts
277643900212	PIPE ASSY BS6	TATA spare parts
277643900218	METAL PIPE ASSY COMP TO AIR DRYER(SECOND	TATA spare parts
277643903317	BRACKET BS6-PH2	TATA spare parts
277643910104	ASSY. 6DIA NYLON PIPE BUNCH COMPL.(SUSP)	TATA spare parts
277643910113	ASSY.6OD PIPE AIR DRYER TO INTERMEDTE JT	TATA spare parts
277643910132	ASSY. NYLON PIPE BUNCH FOR LPO1613 REAR	TATA spare parts
277643910140	PIPE ASSY BS6	TATA spare parts
277643910211	PIPE BUNCH ASSY NYLON BS6	TATA spare parts
277643920109	ASSY.METAL PIPE WITH CRIMPED HOSES	TATA spare parts

277643920110	ASSY.METAL PIPE WITH CRIMPED HOSES	TATA spare parts
277643920111	PARTING BKT TO INTERMEDIATE JOINT	TATA spare parts
277643920112	ASSY.METAL PIPE WITH CRIMPED HOSES	TATA spare parts
277643920119	ASSY. Z SECTION PIPING MTG. BRACKET	TATA spare parts
277643920191	ASSY 18 DIA PIPE FROM COMPRESSOR OUTLET	TATA spare parts
277643920197	ASSY 12 DIA PIPE FROM AIR DRYER TO PURGE	TATA spare parts
277643930101	ASSY 6 DIA PIPE FROM COWL MOUNTE	TATA spare parts
277643930102	ASSY 15 DIA PIPE FROM ELBOW OUTL	TATA spare parts
277643930104	ASSY 12 DIA PIPE FROM PARTITION BRACKET	TATA spare parts
277643930105	ASSY 12 DIA PIPE FROM INTERMEDIATE JOINT	TATA spare parts
277643930113	ASSY 6 DIA PIPE FROM INTERME.JOINT NEAR	TATA spare parts
277643930125	ASSY 12 DIA PIPE FROM INTERMEDIATE TEE	TATA spare parts
277643930126	ASSY 12 DIA PIPE FROM INTERMEDIATE JOINT	TATA spare parts
277643930138	ASSY 18DIA PIPE COMP. OUTLET TO HOSE	TATA spare parts
277643930139	ASSY 6DIA PIPE COMP.TO INTERMEDIATE BKT.	TATA spare parts
277643930140	ASSY 12DIA PIPE WITH CRIMPED HOSE BETWEE	TATA spare parts
277643930141	ASSY.12DIA PIPE WITH CRIMPED HOSE IM TEE	TATA spare parts
277643930142	ASSY 12DIA PIPE CRIMPED WITH HOSE CROMPE	TATA spare parts
277643930151	ASSY.12DIA PIPE SAP PORT24 TO IM JOINT	TATA spare parts
277643930152	ASSY.6 DIA METAL PIPE PORT 23 TO IM JOIN	TATA spare parts
277643930153	ASSY.12 DIA PIPE SPV PORT22 TO FRONT AIR	TATA spare parts
277643930154	ASSY.12 DIA PIPE SPV PORT 21 TO IM JOINT	TATA spare parts
277643930156	ASSY.12 DIA PIPE RELAY OUTLET TO LH CHAM	TATA spare parts
277643930157	ASSY.12 DIA PIPE RELAY OUTLET TO RH CHAM	TATA spare parts
277643930158	ASSY 6 DIA PIPE FROM DTV PORT 22	TATA spare parts
277643930159	IM STOP LIGHT TEE OF PORT 22 TO RELAY SI	TATA spare parts
277643930160	NYLON PIPE	TATA spare parts
277643930165	PIPE ASSY	TATA spare parts
277643930166	ASSY.12 DIA PIPE IM TEE RO RELAY INLET P	TATA spare parts
277643930168	ASSY.6DIA PIPE BETWEEN TWO IM JT	TATA spare parts
277643930188	ASSY.12DIA PIPE BETN 2 INTRM JT FR CIR	TATA spare parts
277643930189	ASSY.12DIA PIPE BETN 2 INTRM JT RR CIR	TATA spare parts
277643930190	ASSY.12DIA PIPE BETN 2 INTRM JT PARK CIR	TATA spare parts
277643930192	6OD PIPE FRM DTV PORT 21 TO PART	TATA spare parts
277643930193	6OD PIPE FRM PARTION BKT TO IT J	TATA spare parts
277643930194	6OD PIPE IT.JTS NEAR TANK TO NEA	TATA spare parts
277643930195	6OD PIPE IT.JTS NEAR DRYER TO RE	TATA spare parts
277643930196	6OD PIPE FRM DTV PORT22 TO SUSP.	TATA spare parts
277643930197	12OD PIPE COWL PARTN BKT TO DTV	TATA spare parts
277643930198	12OD PIPE FRM INT TEE TO PARTION	TATA spare parts
277643930199	12OD PIPE FRM REAR TANK O/L TO I	TATA spare parts
277643940101	12OD PIPE COWL MTD BKT TO DTV PO	TATA spare parts
277643940102	12OD PIPE FRM AIR TANK O/L TO PA	TATA spare parts
277643940103	12 OD PIPE FRM IT JT NEAR HUMPT	TATA spare parts
277643940104	12 DIA PIPE IM JOINTS BETN.SPV T	TATA spare parts
277643940105	12 DIA PIPE FRM TEE TO AUX CIRCU	TATA spare parts
277643940106	PIPE ASSY.6DIA NYLON FOR CTRL	TATA spare parts

277643940108	18OD PIPE FRM HOSE TO LH MFG.BKT	TATA spare parts
277643940109	18OD PIPE LH MTG. BKT TO TANK IN	TATA spare parts
277643940111	6OD PIPE FRM AUX TANK OUTLET TO	TATA spare parts
277643940112	6OD PIPE INT JT NEAR OIL SEP.TO	TATA spare parts
277643940113	ASSY 15DIA PIPE AIR DRYER TO SPV	TATA spare parts
277643940114	ASSY 18DIA CRIMPED PIPE WITH TEFLON HOSE	TATA spare parts
277643940115	RETRO KIT FOR DOMESTIC BUS LPO1512 1618	TATA spare parts
277643940123	COMPRESSOR HEAD KIT MINOR	TATA spare parts
277643940124	COMPRESSOR RING KIT STANDARD	TATA spare parts
277643940125	COMPRESSOR CRANK CASE KIT	TATA spare parts
277643940126	COMPRESSOR HEAD KIT MAJOR	TATA spare parts
277643940127	COMPRESSOR PR REPAIR KIT	TATA spare parts
277643940128	COMPRESSOR GASKET & SEALING RING KIT	TATA spare parts
277643940129	COMPRESSOR MAJOR OVERHAUL KIT	TATA spare parts
277643940130	COMPRESSOR CRANK CASE & PISTON ASSY.KIT	TATA spare parts
277643940131	PIPE BUNCH ASSY FOR LPO1613/55	TATA spare parts
277643940147	PIPE ASSY SPV 22 TO RH TANK-1ST PIPE	TATA spare parts
277643940148	PIPE ASSY SPV 22 TO RH TANK-2ND PIPE	TATA spare parts
277643940149	PIPE ASSY RH TANK O/L TO PARTITION BKT	TATA spare parts
277643940150	PIPE ASSY SPV 21 TO LH TANK-2	TATA spare parts
277643940151	PIPE ASSY LH AIR TANK O/L TO TEE	TATA spare parts
277643940152	PIPE ASSY TEE TO PARTITION BKT	TATA spare parts
277643940154	PIPE ASSY PARTITION BKT TO RE R/V SIGNAL	TATA spare parts
277643940155	PIPE ASSY SPV 23 TO PARTITION BKT	TATA spare parts
277643940156	PIPE ASSY PARTITION BKT TO QRV I/L-1ST	TATA spare parts
277643940157	PIPE ASSY PARTITION BKT TO QRV I/L-2ND	TATA spare parts
277643940160	PIPE ASSY SPV 24 TO TEE - 1ST PIPE	TATA spare parts
277643940161	PIPE ASSY SPV 24 TO TEE - 2 ND PIPE	TATA spare parts
277643940162	PIPE ASSY TEE TO LH AIR TANK	TATA spare parts
277643940163	PIPE ASSY TEE TO AIR TANK RH	TATA spare parts
277643940164	PIPE ASSY TANK O/L TO PARTITION BKT-1ST	TATA spare parts
277643940165	PIPE ASSY TANK O/L TO PARTITION BKT-2ND	TATA spare parts
277643940166	PIPE ASSY COMP TO AIR DRYER(FIRST PIPE)	TATA spare parts
277643940167	PIPE ASSY COMP TO AIR DRYER(SECOND PIPE)	TATA spare parts
277643940168	PIPE ASSY COMP TO AIR DRYER(FORTH PIPE)	TATA spare parts
277643940169	PIPE ASSY AIR DRYER TO PURGE TANK	TATA spare parts
277643940170	PIPE ASSY TEE TO RELAY RES PORT	TATA spare parts
277643940171	PIPE ASSY COMP TO AIR DRYER(THIRD PIPE)	TATA spare parts
277643940174	PIPE ASSY SPV 21 TO LH TANK-1	TATA spare parts
277643940175	PIPE ASSY TANK O/L TO PARTITION BKT-1ST	TATA spare parts
277643940176	PIPE ASSY PARTITION BKT TO RE R/V SIGNAL	TATA spare parts
277643940177	PIPE ASSY SPV 23 TO PARTITION BKT	TATA spare parts
277643940182	PIPE ASSY SUSP.AIR TANK TO I/M JOINT	TATA spare parts
277643940184	PIPE ASSY	TATA spare parts
277643940204	PIPE ASSY	TATA spare parts
277643940209	PIPE ASSY	TATA spare parts
277643940210	PIPE ASSY	TATA spare parts

277643940224	PIPE ASSY BS6	TATA spare parts
277643950114	PIPE ASSY BS6	TATA spare parts
277643950117	PIPE ASSY BS6	TATA spare parts
277643950146	PIPE ASSY BS6	TATA spare parts
277643950191	METAL PIPE ASSY COMP TO AIR DRYER(FIRST	TATA spare parts
277643950194	PIPE ASSY BS6-PH2	TATA spare parts
277643950195	PIPE ASSY BS6-PH2	TATA spare parts
277643950196	PIPE ASSY BS6-PH2	TATA spare parts
277643960161	PIPE ASSY BS6-PH2	TATA spare parts
277643960162	PIPE ASSY BS6-PH2	TATA spare parts
277643970165	PIPE ASSY BS6-PH2	TATA spare parts
277643970176	BRACKET ASSY BS6-PH2	TATA spare parts
277643970177	BRACKET ASSY BS6-PH2	TATA spare parts
277643970183	PIPE ASSY BS6-PH2	TATA spare parts
277643970184	PIPE ASSY BS6-PH2	TATA spare parts
277643980103	AIR COMPRESSOR MAOJR KIT 230CC	TATA spare parts
277643980104	PISTON RING KIT 230 CC COMP	TATA spare parts
277643980105	AIR COMPRESSOR HEAD ASSY 230 CC	TATA spare parts
277643988002	SCREW	TATA spare parts
277643990105	MINOR REPAIT KIT FOR 230CC COMP	TATA spare parts
277643990106	MAJOR REPAIR KIT FOR 230CC COMP	TATA spare parts
277643990107	KIT-PISTON RING 230CC COMP BS2/3	TATA spare parts
277643990108	PISTON REPAIT KIT 230CC COMP	TATA spare parts
277645000101	PNEUMATIC KIT FOR ALL DOORS	TATA spare parts
277645000102	PNEUMATIC SYS ASSY FRONT PASSENGER DOOR	TATA spare parts
277645000103	PNEUMATIC SYS ASSY REAR & MIDDLE DOOR	TATA spare parts
277646000102	ASSY DRAG LINK REAR	TATA spare parts
277646000103	ASSY DRAG LINK FRONT	TATA spare parts
277646000105	DRAGLINK ASSY	TATA spare parts
277646000106	DRAGLINK ASSY	TATA spare parts
277646100101	ASSY. BRACKET STEERING GEAR BOX MTG.	TATA spare parts
277646100102	ASSY STEERING COLUMN BRACKET	TATA spare parts
277646100105	ASSY BKT STEERING GEAR BOX MTG	TATA spare parts
277646100120	STEERING GEAR BOX MOUNTING BRACKET	TATA spare parts
277646100122	STEERING COLUMN ASSY TILT & TELESCOPICBS	TATA spare parts
277646100125	STEERING COLUMN ASSY TILT & TELESCOPIC	TATA spare parts
277646100126	INTERMEDIATE SHAFT ASSY	TATA spare parts
277646100127	STEERING COLUMN ASSY BS6	TATA spare parts
277646305103	PITMAN ARM BS6	TATA spare parts
277646305104	RELAY ARM BS6	TATA spare parts
277646703304	BRACKET STG GEAR BOX MTG BS6	TATA spare parts
277646800136	SUCTION LINE ASSY	TATA spare parts
277646800138	HIGH PRESSURE LINE ASSY	TATA spare parts
277646800140	RETURN LINE ASSY	TATA spare parts
277646800149	PRESSURE LINE ASSY BS6	TATA spare parts
277646800150	RETURN LINE ASSY BS6	TATA spare parts
277646800153	PRESSURE LINE ASSY BS6-PH2	TATA spare parts



277646800154	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
277646800158	SUCTION LINE ASSY BS6-PH2	TATA spare parts
277646800165	RETURN LINE ASSY BS6-PH2	TATA spare parts
277646800166	RETURN LINE ASSY BS6-PH2	TATA spare parts
277646990105	WORM & RACK ASSY	TATA spare parts
277646990106	HOUSING ASSY	TATA spare parts
277646990107	KIT-STEERING GEAR BOX	TATA spare parts
277646990108	MAJOR KIT-SEAL	TATA spare parts
277646990109	SCREW	TATA spare parts
277646990110	KIT-SEAL	TATA spare parts
277646990111	MAJOR KIT-SEAL	TATA spare parts
277646990112	SIDE COVER	TATA spare parts
277647000111	HP - LP PIPE ASSY BS6	TATA spare parts
277647100102	ASSY.CYLINDER (M/S EKC) 406 O.D. 198L BS	TATA spare parts
277647100123	ASSY. BRACKET HPR MTG. - LM LH SIDE	TATA spare parts
277647100124	ASSY. BRACKET SOLENOID VALVE MTG	TATA spare parts
277647100126	ASSY BRACKET - HPR MOUNTING	TATA spare parts
277647100127	ASSY.BRACKT - SOLENOID MTG.	TATA spare parts
277647107103	BRACKET CONOFLOW MOUNTING	TATA spare parts
277647109901	CNG CYLINDER - 356 OD 1655L 135LITERS	TATA spare parts
277647109902	CNG CYLINDER-OD356 1380L 110LITERS	TATA spare parts
277647109903	CNG CYLINDER-356 OD;1380L;110LITERS	TATA spare parts
277647109904	CNG CYLINDER-356 OD 1655L 135LITERS(EK	TATA spare parts
277647109905	CYLINDER BS6	TATA spare parts
277647109906	CYLINDER BS6	TATA spare parts
277647500104	ASSY. SUPPORT (RECP PR.GAUGE FILTER)MTG.	TATA spare parts
277647500108	ASSY BRACKET(HP LINE SOLENOID VALVE MTG)	TATA spare parts
277647500110	ASSY END RESTRAINT RH(SECOND CYL REAR)	TATA spare parts
277647500111	ASSYEND RESTRAINT RH (FIFTH CYL REAR)	TATA spare parts
277647500112	ASSY END RESTRAINT LH(FOURTH CYL REAR)	TATA spare parts
277647500113	ASSY.END RESTRAINT RH(FIRST CYL.FRONT)	TATA spare parts
277647500115	ASSY.END RESTRAINT RH (SECOND CYL.FRONT)	TATA spare parts
277647500118	ASSY.STOPPER	TATA spare parts
277647500121	ASSY. STRAP ( CNG CYL. MOUNTING FRONT)	TATA spare parts
277647500122	ASSY. BRACKET- CNG CYLINDER MOUNTING	TATA spare parts
277647500125	ASSY. BRACKET CNG CYLINDER MOUNTING	TATA spare parts
277647500126	ASSY SUUPPORT (RECP PR GAUGEMTG)	TATA spare parts
277647500127	ASSY.END RESTRAINT LH-FRONT( REAR CYL)	TATA spare parts
277647500128	ASSY.END RESTRAINT LH-REAR( REAR CYL)	TATA spare parts
277647500130	ASSYFRONT END RESTRAINT (RH-FIRST)	TATA spare parts
277647500131	ASSY FRONT END RESTRAINT (RH-SECOND)	TATA spare parts
277647500132	ASSY FRONT END RESTRAINT (LH-FIRST)	TATA spare parts
277647500133	ASSY .FRONT END RESTRAINT (LH-SECOND)	TATA spare parts
277647500134	ASSY FRONT END RESTRAINT (RH-THIRD)	TATA spare parts
277647500142	ASSY. END RESTRAINT (REAR SIDE)	TATA spare parts
277647500145	ASSY.SUPPORT(RECP.PR.GAUGE FILTER MTG.)	TATA spare parts
277647500168	BRACKET ASSY CYLINDER MTG BS6	TATA spare parts

277647500169	BRACKET ASSY CYLINDER MTG BS6	TATA spare parts
277647500185	ARRESTOR ASSY REAR BS6	TATA spare parts
277647500187	END RESTRAINT CYLINDER FRONT-LH BS6	TATA spare parts
277647500188	END RESTRAINT CYLINDER FRONT-RH (LH-FIRS	TATA spare parts
277647507107	CLEVIS PIN	TATA spare parts
277647507144	BRACET STONE GUARD MTG	TATA spare parts
277647507145	END RESTRAINT (REAR SIDE)	TATA spare parts
277647507158	PLATE BS6	TATA spare parts
277647507163	PLATE BS6-PH2	TATA spare parts
277647507702	RUBBER GROMMET	TATA spare parts
277647508207	STONE GUARD-LH	TATA spare parts
277647508208	STONE GUARD-RH	TATA spare parts
277647508227	STONE GUARD RH BS6	TATA spare parts
277647508228	STONE GUARD LH - BS6	TATA spare parts
277647510101	RECEPTACLE CAP BS6	TATA spare parts
277647510105	END RESTRAINT CYLINDER REAR-LH BS6	TATA spare parts
277647510106	END RESTRAINT CYLINDER REAR-RH BS6	TATA spare parts
277647510131	RUBBER PAD CYLINDER STOPPER BS6-PH2	TATA spare parts
277647600116	RECEPTICLE- 1/2 INC NPT	TATA spare parts
277647600119	HP GAS TUBE ASSY	TATA spare parts
277647600120	HP GAS TUBE ASSY WITH PVC SLEEVE	TATA spare parts
277647600123	SINGLE CLAMP ASSY WITH BRACKET BS6	TATA spare parts
277647600135	SUPPORT ASSY BS6	TATA spare parts
277647600139	HP GAS TUBE ASSY WITH PVC SLEEVE	TATA spare parts
277647600142	NON RETURN VALVE ASSY BS6	TATA spare parts
277647600144	INTEGRATED FILLING UNIT ASSY	TATA spare parts
277647600220	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600232	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600233	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600234	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600235	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600236	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600237	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600238	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600239	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600240	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600241	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600242	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600243	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600244	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600245	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600246	VENT TUBE ASSY BS6	TATA spare parts
277647600247	VENT TUBE ASSY BS6	TATA spare parts
277647600248	VENT TUBE ASSY BS6	TATA spare parts
277647600249	VENT TUBE ASSY BS6	TATA spare parts
277647600251	VENT TUBE ASSY BS6	TATA spare parts
277647600252	VENT TUBE ASSY BS6	TATA spare parts

277647600253	VENT TUBE ASSY BS6	TATA spare parts
277647600254	VENT TUBE ASSY BS6	TATA spare parts
277647600255	VENT TUBE ASSY BS6	TATA spare parts
277647600256	CLAMP ASSY HP PIPE BS6	TATA spare parts
277647600259	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600260	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600261	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600262	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600263	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600277	VENT TUBE ASSY BS6	TATA spare parts
277647600278	SINGLE CLAMP ASSY WITH BRACKET BS6	TATA spare parts
277647600284	VENT TUBE ASSY BS6	TATA spare parts
277647600285	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600288	CLAMP ASSY BS6	TATA spare parts
277647600289	CLAMP ASSY BS6	TATA spare parts
277647600290	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600291	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600292	BOX ASSY BS6-PH2	TATA spare parts
277647600293	CLAMP ASSY BS6-PH2	TATA spare parts
277647600296	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600297	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600298	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647600312	VENT TUBE ASSY BS6-PH2	TATA spare parts
277647600313	VENT TUBE ASSY BS6-PH2	TATA spare parts
277647600314	VENT TUBE ASSY BS6-PH2	TATA spare parts
277647600335	VENT TUBE ASSY BS6-PH2	TATA spare parts
277647600336	VENT TUBE ASSY BS6-PH2	TATA spare parts
277647600337	VENT TUBE ASSY BS6-PH2	TATA spare parts
277647600338	VENT TUBE ASSY BS6-PH2	TATA spare parts
277647603202	BOLT BS6	TATA spare parts
277647603302	BRACKET FUEL LINE CLAMP MTG	TATA spare parts
277647603308	BRACKET MICRO-SWITCH BS6	TATA spare parts
277647605601	KNOB BS6	TATA spare parts
277647605603	MANUAL SHUT OFF ASSY BS6	TATA spare parts
277647605801	WATER HOSE - INLET	TATA spare parts
277647605802	WATER HOSE - OUTLET	TATA spare parts
277647605803	LP HOSE - 3/4INCH I.D.	TATA spare parts
277647606804	ADAPTOR -LP HOSE OUTLET	TATA spare parts
277647606837	ADAPTER HOSE	TATA spare parts
277647607105	CLAMP PLATE BS6-PH2	TATA spare parts
277647607106	CLAMP PLATE BS6	TATA spare parts
277647607123	CLAMP PLATE BS6-PH2	TATA spare parts
277647609201	BRIGHT WASHER (AT SOLENOID VALVE OUTLET)	TATA spare parts
277647610102	ASSY. SINGLE CLAMP WITH BRACKET	TATA spare parts
277647610105	ASSY. SINGLE CLAMP WITH BRACKET	TATA spare parts
277647610107	ASSY. CLAMP PVC COATED	TATA spare parts
277647610122	ASSY. TUBE 12 O.D.	TATA spare parts

277647610141	ASSY. HP GAS TUBE 1/4IN OD WITH PVC	TATA spare parts
277647610142	ASSY. HP GAS TUBE 1/4IN OD WITH PVC SLEE	TATA spare parts
277647610143	ASSY. HP GAS TUBE 1/4IN OD WITH PVC	TATA spare parts
277647610144	ASSY. HP GAS TUBE 1/4IN OD WITH PVC SLEE	TATA spare parts
277647610145	ASSY. HP GAS TUBE 1/4IN OD WITH PVC SLEE	TATA spare parts
277647610146	HP GAS TUBE ASSY WITH PVC SLEEVE	TATA spare parts
277647610147	ASSY. HP GAS TUBE 1/4IN OD WITH PVC SLEE	TATA spare parts
277647610148	ASSY. HP GAS TUBE 1/4IN OD WITH PVC SLEE	TATA spare parts
277647610149	ASSY.HP GAS TUBE 1/4IN OD WITH PVC SLEEVE	TATA spare parts
277647610150	ASSY. HP TUBE 1/4IN OD WITH PVC SLEEVE	TATA spare parts
277647610155	ASSY. TUBE 12 OD	TATA spare parts
277647610156	ASSY. TUBE 12 OD	TATA spare parts
277647610158	ASSY. TUBE 12 OD	TATA spare parts
277647610159	ASSY. TUBE 12 OD	TATA spare parts
277647610160	ASSY. TUBE 12 OD	TATA spare parts
277647610173	ASSY. HP GAS TUBE 1/4IN OD WITH PVC SLEE	TATA spare parts
277647610174	ASSY.HP GAS TUBE 1/4IN OD WITH PVC SLEEVE	TATA spare parts
277647610175	ASSY.HP GAS TUBE 1/4IN OD WITH PVC SLEEVE	TATA spare parts
277647610176	ASSY.HP GAS TUBE 1/4IN OD WITH PVC SLEEVE	TATA spare parts
277647610177	ASSY DOUBLE CLAMP WITH BRACKET	TATA spare parts
277647610178	ASSY DOUBLE CLAMP WITH BRACKET	TATA spare parts
277647610179	ASSY.DOUBLE CLAMP WITH BRACKET	TATA spare parts
277647610183	ASSY. HP GAS TUBE 1/4IN OD WITH PVC	TATA spare parts
277647610184	ASSY. HP GAS TUBE 1/4IN OD WITH PVC	TATA spare parts
277647610185	ASSY. HP GAS TUBE 1/4IN OD WITH PVC	TATA spare parts
277647610187	ASSY. TUBE 12 OD	TATA spare parts
277647610188	ASSY. TUBE 12 OD	TATA spare parts
277647610189	ASSY. TUBE 12 OD	TATA spare parts
277647610190	ASSY. TUBE 12 OD	TATA spare parts
277647610191	ASSY. TUBE 12 OD	TATA spare parts
277647610192	ASSY. TUBE 12 OD	TATA spare parts
277647610193	ASSY. TUBE 12 OD	TATA spare parts
277647610194	ASSY. TUBE 12 OD	TATA spare parts
277647610195	ASSY. HP GAS TUBE 1/4IN OD WITH PVC	TATA spare parts
277647610202	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647610203	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647610208	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647610209	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647610219	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647610223	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
277647610226	CLAMP PLATE BS6	TATA spare parts
277647620102	ASSY. TUBE 12 OD - VENTING LINE	TATA spare parts
277647620107	ASSY VALVE	TATA spare parts
277647620122	ASSY. HP GAS TUBE 1/4IN OD WITH PVC	TATA spare parts
277647620123	ASSY. TUBE 12 OD	TATA spare parts
277647620124	ASSY. TUBE 12 OD	TATA spare parts
277647620137	ASSY.TUBE 12 O.D.	TATA spare parts

277647620138	ASSY.TUBE 12 O.D.	TATA spare parts
277647620139	ASSY.TUBE 12 O.D.	TATA spare parts
277647620143	ASSY.TUBE 12 O.D.	TATA spare parts
277647620144	ASSY.TUBE 12 O.D.	TATA spare parts
277647620145	ASSY.TUBE 22 O.D.	TATA spare parts
277647620146	ASSY.TUBE 22 O.D.	TATA spare parts
277647620147	HP GAS TUBE ASSY WITH PVC SLEEVE	TATA spare parts
277647620153	ASSY.HP GAS TUBE 1/4 INCH OD WITH PVC SL	TATA spare parts
277647620154	ASSY.HP GAS TUBE 1/4 INCH OD WITH PVC SL	TATA spare parts
277647620155	ASSY.HP GAS TUBE 1/4 INCH OD WITH PVC SL	TATA spare parts
277647620156	ASSY. TUBE 12 O.D.	TATA spare parts
277647620161	ASSY.TUBE 12 OD	TATA spare parts
277647620162	ASSY.TUBE 12 OD	TATA spare parts
277647620163	ASSY.TUBE 12 OD	TATA spare parts
277647620164	ASSY. TUBE 12 OD	TATA spare parts
277647620177	ASSY.TUBE 22 O.D.	TATA spare parts
277647620178	ASSY.TUBE 22 O.D.	TATA spare parts
277647620201	VENT TUBE ASSY BS6	TATA spare parts
277647620202	VENT TUBE ASSY BS6	TATA spare parts
277647620204	VENT TUBE ASSY BS6	TATA spare parts
277647620205	VENT TUBE ASSY - BS6	TATA spare parts
277647620206	VENT TUBE ASSY BS6	TATA spare parts
277647620207	VENT TUBE ASSY BS6	TATA spare parts
277647620208	VENT TUBE ASSY BS6	TATA spare parts
277647620209	VENT TUBE ASSY BS6	TATA spare parts
277647620210	VENT TUBE ASSY BS6	TATA spare parts
277647620211	VENT TUBE ASSY BS6	TATA spare parts
277647620212	VENT TUBE ASSY BS6	TATA spare parts
277647620213	VENT TUBE ASSY - BS6	TATA spare parts
277647620214	VENT TUBE ASSY BS6	TATA spare parts
277647620215	VENT TUBE ASSY BS6	TATA spare parts
277647620216	VENT TUBE ASSY BS6	TATA spare parts
277647700101	ASSY. COMBINED UNIT	TATA spare parts
277647700102	ASSY HP FILTER WITH CARTRIDGE	TATA spare parts
277647700103	ASSY HP FILTER W/CARTRIDGE	TATA spare parts
277647700104	ASSY.HIGH PRESSURE REGULATOR-CLH	TATA spare parts
277647700105	PARTICULATE FILTER	TATA spare parts
277647700106	HP REGULATOR ASSY INTEGRATED	TATA spare parts
277647700107	INTEGRATED FILLING UNIT ASSY BS6	TATA spare parts
277647700108	INTEGRATED FILLING UNIT ASSY BS6	TATA spare parts
277647700109	SOLENOID COIL ASSY	TATA spare parts
277647700112	INTEGRATED FILLING UNIT ASSY BS6	TATA spare parts
277647700113	INTEGRATED FILLING UNIT ASSY BS6	TATA spare parts
277647700114	NGV RECEPACLE BS6	TATA spare parts
277647703301	BRACKET BS6	TATA spare parts
277647706801	CONNECTOR	TATA spare parts
277647706802	CONNECTOR TUBE W/O FERULE BS6	TATA spare parts

277647707703	O- RING CNG FILTER	TATA spare parts
277647707704	O-RING BS6	TATA spare parts
277647708001	SCREW BS6	TATA spare parts
277647709001	FILTER ASSY	TATA spare parts
277647709902	FILTER CARTRIDGE CNG	TATA spare parts
277647709930	FILTER ELEMENT	TATA spare parts
277647709931	PRESSURE SENSOR	TATA spare parts
277647994901	SOLENOID VALVE ASSY. 24 V BS6	TATA spare parts
277649100101	ASSY. SILENCER WITH TAIL PIPE	TATA spare parts
277649100106	ASSY. BRACKET	TATA spare parts
277649100107	ASSY BRACKET (FOR SILENCER)	TATA spare parts
277649100108	ASSY. CATCON WITH FLANGE	TATA spare parts
277649100111	ASSY. SILENCER-CIRCULAR	TATA spare parts
277649100117	ASSY EXH. PIPE I	TATA spare parts
277649100126	ASSY. EXHAUST PIPE	TATA spare parts
277649100128	ASSY. EXHAUST PIPE (CATCON TO SILENCER)	TATA spare parts
277649100129	ASSY. BRACKET (FOR CATCON MTG)	TATA spare parts
277649100130	ASSY. HEAT SHIELD	TATA spare parts
277649100140	ASSY SILENCER - NG5B(CIRCULAR)	TATA spare parts
277649100148	SUPPORT ASSY CATCON	TATA spare parts
277649100150	ASSY. HEAT SHIELD (EXHAUST FRONT SIDE)	TATA spare parts
277649100157	SUPPORT CHANNEL FOR SILENCER MTG BKT	TATA spare parts
277649100160	ASSY EXHAUST PIPE	TATA spare parts
277649100164	ASSY EXHAUST PIPE (CATCON TO SILENCER)	TATA spare parts
277649100165	SILENCER MTG BRACKET	TATA spare parts
277649100166	ASSY HEAT SHEILD FOR SILENCER	TATA spare parts
277649100168	ASSY HEAT SHIELD FOR CATCON	TATA spare parts
277649100169	ASSY SUPPORT BRACKET FOR CATCON	TATA spare parts
277649100171	CATCON CLAMP ASM	TATA spare parts
277649100179	ASSY KIT HEAT SHIELD-EXHAUST FIRST PIPE	TATA spare parts
277649100180	KIT HEAT SHIELD-EXHAUST TAIL PIPE SIDE	TATA spare parts
277649100181	FIRST PIPE POST SILENCER ASSY	TATA spare parts
277649100184	EXHAUST PIPE ASSY CATCON TO SILENCER	TATA spare parts
277649100185	EXHAUST PIPE ASSY	TATA spare parts
277649100187	SUPPORT CHANNEL BS6	TATA spare parts
277649100192	SUPPORT ASSY SILENCER MTG	TATA spare parts
277649100194	HEAT SHIELD ASSY BS6	TATA spare parts
277649104202	CLAMP (CATCON MTG)	TATA spare parts
277649104203	CLAMP(SILENCER MTG.)	TATA spare parts
277649104204	CLAMP (CATCON MTG.)	TATA spare parts
277649104205	CLAMP (CATCON MTG)	TATA spare parts
277649107114	SUPPORT PLATE FOR SILENCER MTG BKT.-1	TATA spare parts
277649108216	CLAMP	TATA spare parts
277649108224	BRACKET FOR MTG OF ASSY EXHAUST PIPE	TATA spare parts
277649109905	HEAT SHIELD - EXHAUST FIRST PIPE	TATA spare parts
277649110101	HEAT SHIELD ASSY BS6	TATA spare parts
277649110104	SILENCER ASSY BS6	TATA spare parts

277649200103	EXHAUST PIPE ASSY CATCON TO SILENCER	TATA spare parts
277649200104	EXHAUST PIPE ASSY MANIFOLD TO CATCON	TATA spare parts
277649200106	EXHAUST PIPE ASSY BS6	TATA spare parts
277649200107	EXHAUST PIPE ASSY CATCON TO SILENCER BS6	TATA spare parts
277649200111	CLAMP ASSY CATCON BS6	TATA spare parts
277649200112	FRONT PIPE ASSY BS6	TATA spare parts
277649200114	PIPE ASSY INTERMEDIATE BS6	TATA spare parts
277649200115	TAIL PIPE ASSY BS6	TATA spare parts
277649200116	BRACKET ASSY BS6	TATA spare parts
277649200118	HEAT SHIELD ASSY BS6	TATA spare parts
277649200122	EXHAUST PIPE ASSY WITH BELLOW BS6-PH2	TATA spare parts
277649200123	EXHAUST PIPE ASSY INTERMEDIATE BS6-PH2	TATA spare parts
277649200124	EXHAUST PIPE ASSY INTERMEDIATE BS6-PH2	TATA spare parts
277649200125	BRACKET ASSY EXHAUST MTG BS6-PH2	TATA spare parts
277649200126	BRACKET ASSY EXHAUST MTG BS6-PH2	TATA spare parts
277649200127	BRACKET ASSY BS6	TATA spare parts
277649200128	BRACKET ASSY BS6-PH2	TATA spare parts
277649200129	TUBE ASSY BS6-PH2	TATA spare parts
277649200130	TUBE ASSY BS6-PH2	TATA spare parts
277649200132	CLAMP ASSY BS6-PH2	TATA spare parts
277649200133	CLAMP ASSY SILENCER MTG BS6-PH2	TATA spare parts
277649200135	BRACKET ASSY BS6-PH2	TATA spare parts
277649200136	BRACKET ASSY BS6-PH2	TATA spare parts
277649200140	EXHAUST ASSY WITH FLEX PIPE BS6	TATA spare parts
277649200155	CLAMP ASSY CATCON BS6-PH2	TATA spare parts
277649203302	BRACKET BS6	TATA spare parts
277649203304	BRACKET BS6	TATA spare parts
277649203306	BRACKET BS6	TATA spare parts
277649203310	MTG BRACKET BS6	TATA spare parts
277649203312	BRACKET SUPPORT BS6	TATA spare parts
277649203318	L-BRACKET	TATA spare parts
277649203319	L-BRACKET	TATA spare parts
277649203320	L-CLAMP BS6-PH2	TATA spare parts
277649203322	BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
277649203323	BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
277649203324	BRACKET	TATA spare parts
277649205302	GASKET ASSY BS6-PH2	TATA spare parts
277649207104	SPACER PLATE BS6	TATA spare parts
277649207105	SPACER PLATE BS6	TATA spare parts
277649207107	SPACER PLATE BS6	TATA spare parts
277649207108	SPACER PLATE BS6	TATA spare parts
277649208201	CLAMP BS6	TATA spare parts
277649600101	HEAT SHIELD ASSY CATCON	TATA spare parts
277649600102	KIT-HEAT SHIELD FOR SILENCER - EXH PIPE	TATA spare parts
277649600103	HEAT SHIELD ASSY	TATA spare parts
277649600113	HEAT SHIELD COVER	TATA spare parts
277649600115	HEAT SHIELD COVER	TATA spare parts

277649600116	HEAT SHIELD COVER	TATA spare parts
277649600119	HEAT SHIELD ASSY	TATA spare parts
277649600125	HEAT SHIELD ASSY	TATA spare parts
277649600126	HEAT SHIELD ASSY	TATA spare parts
277649605302	HEAT SHIELD TAIL PIPE BS6	TATA spare parts
277649605303	HEAT SHIELD ASSY BS6	TATA spare parts
277649605304	HEAT SHIELD ASSY BS6	TATA spare parts
277649605305	HEAT SHIELD DOC POC BS6	TATA spare parts
277649605307	HEAT SHIELD BEND BS6	TATA spare parts
277649605309	HEAT SHILED ASSY BS6	TATA spare parts
277649605310	HEAT SHIELD ASSY BS6	TATA spare parts
277649605316	HEAT SHIELD SILENCER BS6	TATA spare parts
277649605317	HEAT SHIELD SILENCER BS6	TATA spare parts
277649980101	KIT-EXHAUST PIPE HEAT SHIELD ASSY	TATA spare parts
277649990101	EXAHUST PIPE	TATA spare parts
277649990108	HEAT SHIELD ASSY BS6	TATA spare parts
277654000113	KIT FIRE DETECTION SYSTEM	TATA spare parts
277654100101	ASSY.EARTHING CHAIN WITH BRACKET	TATA spare parts
277654100104	ASSY.COPPER BATTERY CABLE +VE 70SQ MM	TATA spare parts
277654100105	ASSY.COPPER BATTERY CABLE -VE 70SQ MM	TATA spare parts
277654100106	ASSY.BATTERY COVER - 150 AH	TATA spare parts
277654100109	ASSY.BATTERY CABLE +VE(70MM2)-3800MM	TATA spare parts
277654100110	ASSY BATTERY CABLE -VE (70SQMM)-3600MM	TATA spare parts
277654100111	ASSY.BATTERY CABLE +VE (70SQMM)-450MM	TATA spare parts
277654100112	ASSY.HDPE BATTERY CABLE +VE(70MM2)-3800M	TATA spare parts
277654100113	ASSY HDPE BATTERY CABLE -VE (70SQMM)-360	TATA spare parts
277654100114	ASSY.HDPE BATTERY CABLE +VE (70SQMM)-450	TATA spare parts
277654100118	ASSY BATTERY LINK (PVC 95 SQ.MM)	TATA spare parts
277654100120	BATT CABLE FROM BATT.TO MEGA FUSE INPUT	TATA spare parts
277654100121	ASSY.BATT CABLE +VE	TATA spare parts
277654100123	ASSY. BATT. CABLE +VE (FROM BATT.TO MEGA	TATA spare parts
277654100124	ASSY.BATT CABLE +VE (FROM CUTOFF TO STAR	TATA spare parts
277654100125	ASSY PVC BATTERY CABLE -VE(95SQMM)2950 M	TATA spare parts
277654100126	ASSY BATTERY CABLE +VE	TATA spare parts
277654100127	ASSY BATTERY CABLE +VE (FROM MEGA FUSE O	TATA spare parts
277654200101	ASSY.PRESSURE REGULATOR	TATA spare parts
277654200102	TEMPERATURE SENSOR CATCON(168DIA)	TATA spare parts
277654200104	KIT-ASSY.CNG GAS SENSOR-LPO1613CNG	TATA spare parts
277654200105	W/H CNG GAS INDICATOR-ED-LPO1613CNG	TATA spare parts
277654200106	ASSY.SUPPORT(INSTR.CLUSTER)-LPO1613 CNG	TATA spare parts
277654200107	KIT-GAS LEAK INDICATOR-SINGLE SENSOR-ED	TATA spare parts
277654200108	ASSY.BKT.(GAS PR./CAT.TEMP IND/DECT)1613	TATA spare parts
277654200110	ASSY.BKT-GAS LK.DET.SENSOR-LPO1613CNG	TATA spare parts
277654200112	ASSY.SOLENOID VALVE-24V	TATA spare parts
277654200114	INSTRUMENT CLUSTER (0.98)DTC	TATA spare parts
277654200119	USB INTERFACE CABLE WITH SOFTWARE	TATA spare parts
277654200120	GILL SERIAL INTERFACE CABLE WITH SOFTWARE	TATA spare parts



277654200121	ASSY BRACKET III FOR INST.CLUSTER MTG	TATA spare parts
277654200122	ASSY BKACKET I FOR INST.CLUSTER MTG	TATA spare parts
277654200123	ASSY BKACKET II FOR INST.CLUSTER MTG.	TATA spare parts
277654200125	ASSY CATCON TEMP INDICATOR MTG. BKT.	TATA spare parts
277654200127	INSTRUMENT CLUSTER MOUNTING PLATE	TATA spare parts
277654200136	INSTRUMENT CLUSTER MOUNTING PLATE-OB2	TATA spare parts
277654201601	INST.CLUSTER-ELECT-0.98 LPO 1613 CNG	TATA spare parts
277654201605	ASSY. INSTRUMENT CLUSTER MIDLINE BS4	TATA spare parts
277654204902	CBCU3-E(MULTIPLEX UNIT) BS3/4	TATA spare parts
277654204902C	CBCU3-ECORE	TATA spare parts
277654206301	COVER HOUSING	TATA spare parts
277654206302	HOUSING BOTTOM	TATA spare parts
277654208202	CNG.PR.IND.MTG.BKT.-LPO1613 CNG VEHICLE.	TATA spare parts
277654208203	W/H SUPPORT CLAMP	TATA spare parts
277654208204	W/H SUPPORT CLAMP FOR 2 CYLINDER	TATA spare parts
277654209902	IGNITER 697 CGS BSIII ENG.	TATA spare parts
277654209903	EMS-ECU-MONOFUEL	TATA spare parts
277654209904	GAS FLOW CONTROL VALVE-STEPPER	TATA spare parts
277654209905	GAS LEVEL SENSOR	TATA spare parts
277654209906	HIGH PR.SOLENOID	TATA spare parts
277654209907	LOW PR.SOLENOID	TATA spare parts
277654209908	GAS PR.INDICATOR	TATA spare parts
277654209909	CIGAR COIL(WITH TOP CONN) BS3/4	TATA spare parts
277654209919	CAP-VEHICLE SPEED SENSOR	TATA spare parts
277654209922	RUBBER BOOT FOR CIGAR COIL BS3/4	TATA spare parts
277654209923	SPRING FOR CIGAR COIL	TATA spare parts
277654209925	EMS ECU 697 CNG HARDWARE BS4	TATA spare parts
277654209927	RUBBER BOOT FOR CIGAR COIL	TATA spare parts
277654209934	ECU-560 5.7SGI OBD-II BS4	TATA spare parts
277654209938	ECU EMS 580 FOR 5.7 SGI ENG BS4	TATA spare parts
277654300102	ASSY BRACKET (CBCU UNIT MTG)	TATA spare parts
277654300105	CONTROL PANEL ASM(3 ZONE)	TATA spare parts
277654300106	HORN STROBE ASM	TATA spare parts
277654300107	REVERSE HORN(24V)	TATA spare parts
277654300108	ROOF HARNESS	TATA spare parts
277654306301	COVER FOR CBCU UNIT MOUNTING	TATA spare parts
277654309901	EOL BOX	TATA spare parts
277654309902	JUNCTION BOX WITH PIGTAIL	TATA spare parts
277654309903	HORN CUM STROBE WITH SKIRT	TATA spare parts
277654309904	HORN STROBE BACK-BOX WITH PIGTAIL	TATA spare parts
277654400102	HEIGHT MARKER LAMP (WHITE)	TATA spare parts
277654400103	HEIGHT MARKER LAMP (RED)	TATA spare parts
277654400104	NUMBER PLATE LAMP	TATA spare parts
277654400105	SIDE MARKER LAMP 24 V	TATA spare parts
277654400106	FLUORESCENT LAMP TWO POLE	TATA spare parts
277654400107	CABIN LAMP DOUBLE PARABOLA 24V	TATA spare parts
277654400108	SIDE DIRECTION INDICATOR LH	TATA spare parts

277654400109	SIDE DIRECTION INDICATOR RH	TATA spare parts
277654401602	ASSY.MIL LAMP-24V	TATA spare parts
277654401603	ASSY.LOW AIR PRESSURE IND.FOR SUSPENSION	TATA spare parts
277654401604	ASSY.CATCON OVER TEMP IND.	TATA spare parts
277654401605	ASSY LOW COOLENT LEVEL INDICATOR	TATA spare parts
277654401606	ASSY AIR FILTER CLOGGED(SERVICE) INDIC	TATA spare parts
277654401608	ASSY MIL LAMP - 24V	TATA spare parts
277654401609	ASSY CEL LAMP - 24V	TATA spare parts
277654408801	HEX STUD CIGAR COIL MTG	TATA spare parts
277654409901	SPARE KIT FOR BULB	TATA spare parts
277654500102	BKT ASSY (FUZE BOX MTG BKT)	TATA spare parts
277654500104	CHANNEL FOR MOUNTING MAXI FUSE BOX ETC	TATA spare parts
277654500105	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
277654503304	BRACKET BS6-PH2	TATA spare parts
277654503305	BRACKET BS6-PH2	TATA spare parts
277654504902	ALARM RESET SWITCH BS6	TATA spare parts
277654506301	SPEAKER COVER	TATA spare parts
277654509902	RELAY 24V10ANO(MICRO RELAY)	TATA spare parts
277654509903	SALOON LAMP SWITCH	TATA spare parts
277654509904	STOP REQUEST RESET SWITCH	TATA spare parts
277654509905	INDICATOR SWITCH& LIGHT(DRIVER CABIN)	TATA spare parts
277654509906	SPARE SWITCH (DVD/TV)	TATA spare parts
277654509907	STOP SWITCH PANEL MOUNTED	TATA spare parts
277654509908	SALOON LAMP SWITCH	TATA spare parts
277654509909	TOGGLE SWITCH (2P-ON/OFF)	TATA spare parts
277654509910	PASSENGER BELL	TATA spare parts
277654600106	ASSY ECU MTG BRKT LPO1613 BSIV TMML	TATA spare parts
277654600114	W/H BRAKE WEAR SENSOR	TATA spare parts
277654600115	DASHBOARD HARNESS	TATA spare parts
277654600116	W/H BRAKE TEMP SENSOR	TATA spare parts
277654600125	ASSY. BRKT FOR MOUNTING ENGINE WIRING HA	TATA spare parts
277654600126	ASSY. BRKT FOR MOUNTING ENGINE WIRING HA	TATA spare parts
277654601601	W/H.EMS - LPO1613-697CGS-BSIII	TATA spare parts
277654601602	W/H.MAIN-LPO1613-697BSIII	TATA spare parts
277654601603	W/H.ENGINE-LPO1613-697BSIII-CGS	TATA spare parts
277654601604	W/H.MAXI FUSE-LPO1613-697BSIII	TATA spare parts
277654601611	W/H.TAIL-LPO/LPT 1613 CNG	TATA spare parts
277654601672	PIGTAIL-FILLING RECEP. SWITCH	TATA spare parts
277654601683	WH MAIN LPO1613 CNG BSIV MUX OBD-II	TATA spare parts
277654601684	W/H TAIL LPO1613 _MUX OBD-II	TATA spare parts
277654601685	W/H ENGINE POWER LPO1613BS4 _MUX OBD-II	TATA spare parts
277654601686	W/H EMS ECU PIGTAIL MUX OBD BS4	TATA spare parts
277654601687	WH HEAD LAMP LPO1613 BS-IV CNG _MUX OD-II	TATA spare parts
277654601688	W/H SWITCH LPO 1613 _MUX OBD-II	TATA spare parts
277654601689	WH MAXI FUSE LPO 1613 _MUX OBD-II	TATA spare parts
277654601690	WH CAN BACKBONE LPO 1613BS4 _MUX OBD-II	TATA spare parts
277654601691	WH MCAN FOR LPO 1613 _MUX OBD-II	TATA spare parts

277654606305	FUSE BOX COVER BS6	TATA spare parts
277654608202	WIRING HARNESS SUPPORT BRACKET	TATA spare parts
277654608210	SUPPORTING BRKT. FOR ENGINE W/H	TATA spare parts
277654608213	L-SHAPE BKT USED AT FRONT CROSS MEMBER	TATA spare parts
277654608216	BKT FOR MEGA FUSE BOX	TATA spare parts
277654609901	CABLE LHDS 138 DEG	TATA spare parts
277654609902	CABLE LHDS 88 DEG	TATA spare parts
277654609903	PIG TAIL ASSY	TATA spare parts
277654610122	WIRING HARNESS EMS SIGNAL	TATA spare parts
277654610124	WIRING HARNESS EMS	TATA spare parts
277654610137	WIRING HARNESS TAIL	TATA spare parts
277654610142	MAIN WIRING HARNESS	TATA spare parts
277654610146	WIRING HARNESS P-CAN	TATA spare parts
277654610148	WIRING HARNESS MAXI FUSE	TATA spare parts
277654610160	WIRING HARNESS TAIL BS6	TATA spare parts
277654610161	WIRING HARNESS MAIN BS6	TATA spare parts
277654610164	WIRING HARNESS PANEL BS6	TATA spare parts
277654610166	WIRING HARNESS EMS SIGNAL BS6	TATA spare parts
277654610175	WIRING HARNESS TAIL BS6	TATA spare parts
277654610176	WIRING HARNESS MAIN BS6	TATA spare parts
277654610177	WIRING HARNESS PANEL BS6	TATA spare parts
277654610183	WIRING HARNESS EMS BS6	TATA spare parts
277654610188	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
277654610189	WIRING HARNESS-GROUND BS6	TATA spare parts
277654610191	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
277654610192	WIRING HARNESS PANEL BS6-PH2	TATA spare parts
277654611602	W/H WIPER PIGTAIL	TATA spare parts
277654611640	PIGTAIL VEHICLE SPEED SENSOR	TATA spare parts
277654611662	WIRING HARNESS MAIN	TATA spare parts
277654611663	WIRING HARNESS POWER CABLE	TATA spare parts
277654611664	WIRING HARNESS FRONT CAN	TATA spare parts
277654611665	WIRING HARNESS TAIL	TATA spare parts
277654616302	FUSE BOX ASSY WITH STICKER BS6	TATA spare parts
277654620111	W/H MAIN LPO1613CNG W/MULTIFLEXING	TATA spare parts
277654620112	W/H ENGINE LPO1613 CNG W/MULTIPLEX	TATA spare parts
277654620113	W/H EMS LPO1613CNG 24V W/MULTIPLEX	TATA spare parts
277654620114	W/H MAXI FUSE LPO1613CNG MULTIPLX	TATA spare parts
277654620115	W/H TAIL LPO1613/55CNG W/MULTIPLX	TATA spare parts
277654620116	MCAN W/H MULTIPLEXING SYSTEM	TATA spare parts
277654620117	W/H MAIN LPO1613CNG W/MULTIPLEXING BSIV	TATA spare parts
277654620118	W/H TAIL LPO1613CNG W/MULTIPLEXING BSIV	TATA spare parts
277654620119	W/H ENGINE LPO1613CNG W/MULTIPLEXING BSIV	TATA spare parts
277654620125	W/H EMS LPO 1613 CNG W/FRONT ET BS4	TATA spare parts
277654620126	W/H MAXI FUSE LPO1613/55 BS IV	TATA spare parts
277654620128	W/H EMS ECU PIGTAIL BS3/4	TATA spare parts
277654620129	PIGTAIL FOR BATTERY CHARGING	TATA spare parts
277654620134	PIGTAIL FOR HP SOLENOID	TATA spare parts

277654620135	PIGTAIL FOR ECU GROUNDING	TATA spare parts
277654620143	W/H SWITCH FOR LPO1613CNG BSIV	TATA spare parts
277654620144	W/H MAXIFUSE LPO1613CNG BSIV	TATA spare parts
277654620145	W/H MAIN LPO 1613 CNG BSIV	TATA spare parts
277654620146	W/H TAIL LPO 1613 CNG BSIV	TATA spare parts
277654620147	W/H ENGINE LPO 1613 CNG BSIV	TATA spare parts
277654620148	W/H EMS PIGTAIL LPO 1613 CNG BSIV	TATA spare parts
277654620150	W/H HEAD LAMP & BLINKER	TATA spare parts
277654620151	WIRING HARNESS EMS BS4	TATA spare parts
277654620157	WIRING HARNESS EMS BS6-PH2	TATA spare parts
277654620158	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
277654620168	W/H BRAKE TEMPERATURE INDICATOR	TATA spare parts
277654620169	W/H BRAKE WEAR SENSOR	TATA spare parts
277654620170	W/H FIRE DETECTION SYSTEM	TATA spare parts
277654620173	WIRING HARNESS ENGINE	TATA spare parts
277654620178	W/H BATTERY -VE TO STARTER -VE BS6-PH2	TATA spare parts
277654620182	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
277654620183	WIRING HARNESS POWER CABLE BS6-PH2	TATA spare parts
277654700101	CABIN FAN	TATA spare parts
277654706301	COVER BS6-PH2	TATA spare parts
277654900102	BRACKET ASSY ECU MTG	TATA spare parts
277654900104	BRACKET ASSY ECU MTG	TATA spare parts
277654903701	ADAPTER BS6	TATA spare parts
277654904902	IGNITION COIL BS6	TATA spare parts
277654907502	IGNITION COIL BS6	TATA spare parts
277654990101	KIT-FIRE DETECTION SYSTEM	TATA spare parts
277654990102	KIT-FIRE DETECTION SYSTEM	TATA spare parts
277654999901	REAR ENGINE FDS KIT	TATA spare parts
277658505001	BAG - PULLER CIGAR COIL REMOVAL BS6	TATA spare parts
277658900702	INJECTOR PULLING TOOL	TATA spare parts
277667050101	PEEP GLASS	TATA spare parts
277667050102	HOOPER TYPE WINDOW	TATA spare parts
277667050103	PEEP GLASS	TATA spare parts
277667057701	WEATHER STRIP (EMG.ACR.WINDOW)	TATA spare parts
277667100101	WINDOW ASSEMBLY-DRIVER	TATA spare parts
277667102301	FRONT WINDSHIELD RH	TATA spare parts
277667102302	FRONT WINDSHIELD LH	TATA spare parts
277667107701	WEATHER STRIP (WINDSHILD FRONT)	TATA spare parts
277667107702	WEDGE (KEY) BEADING (W/S.BIG-FRT/RE)	TATA spare parts
277667107704	WEDGE (KEY) BEADING(SMALL-REAR/DEST)	TATA spare parts
277667200101	VERTICAL SLIDING WINDOW	TATA spare parts
277667300101	SIDE WINDOW ASSEMBLY	TATA spare parts
277667400101	SIDE WINDOW ASSEMBLY	TATA spare parts
277667500101	SIDE WINDOW ASSEMBLY	TATA spare parts
277667700101	DESTINATION GLASS (L=1966)	TATA spare parts
277667700102	TOP FIXED GLASS	TATA spare parts
277667700103	TOP FIXED GLASS	TATA spare parts

277667700104	TOP FIXED GLASS	TATA spare parts
277667700105	TOP FIXED GLASS	TATA spare parts
277667800101	SIDE WINDOW ASSEMBLY	TATA spare parts
277667802301	REAR GLASS WIND SHIELD	TATA spare parts
277667807701	RUBBER BEADING FOR WINDOWS	TATA spare parts
277667980101	LOCK & CATCHER	TATA spare parts
277668706301	HANDLE - FRONT	TATA spare parts
277668906301	DASHBOARD	TATA spare parts
277668906302	DASHBOARD INSPECTION COVER	TATA spare parts
277672300102	HINGE ASSY FOR DRIVER DOOR	TATA spare parts
277672300103	DOOR HINGE WITH HANDLE	TATA spare parts
277672300104	HINGE ASSY(PASS DOOR-W/O HANDLE)	TATA spare parts
277672300105	LATCH ASSY (TOWER BOLT)	TATA spare parts
277672307701	WEATHER STRIP	TATA spare parts
277672307702	WEATHER STRIP	TATA spare parts
277672307703	WEATHER STRIP	TATA spare parts
277672307704	MOULDED WEATHER STRIP	TATA spare parts
277672307705	WEDGE STRIP	TATA spare parts
277672500101	DOOR GLASS	TATA spare parts
277672560101	ASSY INNER HANDLE RH	TATA spare parts
277672560102	DOOR HANDLE WITH KEY (RH)	TATA spare parts
277672980101	DRIVER DOOR ASSY	TATA spare parts
277672980102	PASSENGER DOOR ASSEMBLY - FRONT	TATA spare parts
277673300101	HINGE ASSY(PASS DOOR-W/O HANDLE)	TATA spare parts
277673307701	WEATHER STRIP	TATA spare parts
277673307702	WEATHER STRIP	TATA spare parts
277673307703	WEATHER STRIP	TATA spare parts
277673307704	MOULDED WEATHER STRIP	TATA spare parts
277673307705	WEATH.STRIP (PASS.DOOR-GLASS KEY)	TATA spare parts
277673307706	WEATHER STRIP	TATA spare parts
277673500101	DOOR GLASS	TATA spare parts
277673500102	DOOR GLASS	TATA spare parts
277673980101	DOOR ASSEMBLY - TOWARDS FRONT END	TATA spare parts
277673980102	DOOR ASSEMBLY - TOWARDS REAR END	TATA spare parts
277673980103	DOOR ASSEMBLY - TOWARDS FRONT END	TATA spare parts
277673980104	DOOR ASSEMBLY - TOWARDS REAR END	TATA spare parts
277675100101	FRP FRONT FLAP	TATA spare parts
277675100102	LAMP BAZZEL	TATA spare parts
277675100103	LAMP BAZZEL	TATA spare parts
277675106301	ALUMINIUM MESH	TATA spare parts
277675200101	HINGE ASSEMBLY	TATA spare parts
277675408201	SKIRT PANEL COMPL.B.B	TATA spare parts
277675408202	SKIRT PANEL COMPL	TATA spare parts
277675408203	SKIRT PANEL COMPL	TATA spare parts
277675408204	SKIRT PANEL COMPL	TATA spare parts
277675408205	SKIRT PANEL COMPL	TATA spare parts
277675408206	SKIRT PANEL COMPL	TATA spare parts

277675408207	SKIRT PANEL COMPL	TATA spare parts
277675408208	SKIRT PANEL COMPL	TATA spare parts
277675408209	SKIRT PANEL COMPL	TATA spare parts
277675408210	SKIRT PANEL COMPL	TATA spare parts
277675408211	SKIRT PANEL COMPL	TATA spare parts
277675408212	SKIRT PANEL COMPL./S.T	TATA spare parts
277675408213	SKIRT PANEL COMPL	TATA spare parts
277675408214	SKIRT PANEL COMPL	TATA spare parts
277675408215	SKIRT PANEL COMPL	TATA spare parts
277675408216	SKIRT PANEL COMPL	TATA spare parts
277675408217	SKIRT PANEL COMPL	TATA spare parts
277675408218	SKIRT PANEL COMPL	TATA spare parts
277675408219	SKIRT PANEL COMPL	TATA spare parts
277675408220	SKIRT PANEL COMPL	TATA spare parts
277675500101	LOCK ASSEMBLY	TATA spare parts
277675505001	AL-EXTRUSION (RUB-RAIL)	TATA spare parts
277675505002	END CAP FOR RUB RAIL	TATA spare parts
277675505201	RUBBER BEADING (WHEEL ARCH)	TATA spare parts
277675505202	RUBBER EXTRUSION (RUB-RAIL)	TATA spare parts
277675505601	PLASTIC BUDGET LOCK COVER	TATA spare parts
277675505901	KEY FOR BUDGET LOCK	TATA spare parts
277675506301	FRP FOOT STEP	TATA spare parts
277675506302	PLASTIC FOOT STEP COVER	TATA spare parts
277681100101	SALOON MIRROR	TATA spare parts
277681100102	REAR VIEW MIRROR¿ ARM ASSEMBLY	TATA spare parts
277681100103	ARM FOR UNDERVIEW MIRROR	TATA spare parts
277681100104	UNDER VIEW MIRROR(PARK)	TATA spare parts
277681100105	REAR VIEW MIRROR¿ RH	TATA spare parts
277681100106	MIRROR ARM COMPLETE (DRIVER SIDE)	TATA spare parts
277681100107	REAR VIEW MIRROR¿ LH	TATA spare parts
277681105601	HAND STRAP WITH ADVERSTISEMENT PROV	TATA spare parts
277681106301	SUNVISOR	TATA spare parts
277681503301	PLASTIC PIPE BRACKET (38X32)	TATA spare parts
277681503302	PLASTIC PIPE BRACKET (38X32) (4 -WAY)	TATA spare parts
277681503303	PIPE BRACKET	TATA spare parts
277681503304	GUARD RAIL BRACKET	TATA spare parts
277681503305	BRACKET	TATA spare parts
277681503306	PIPE BKT(38 DIA) BOTTOM	TATA spare parts
277681503307	PIPE BKT.COVER(38 DIA)(GREY)	TATA spare parts
277681503308	PLASTIC PIPE BRACKET (32 X32)	TATA spare parts
277681503309	PIPE BRACKET-BASE(32 DIA)(PC)	TATA spare parts
277681503310	PIPE HOLDER (32 DIA)	TATA spare parts
277681503311	PIPE BRACKET COVER (DIA 32) GREY	TATA spare parts
277681503401	END BUSH	TATA spare parts
277681506901	PIPE/ERW (32 DIA X 2 THK) (PC)	TATA spare parts
277681506902	PIPE/ERW (25.4 DIA X 1.2 THK) (PC)	TATA spare parts
277681506903	PIPE/ERW (38 DIA X 2 THK)(PC) L=2500 MM	TATA spare parts

277681506904	PIPE/ERW (32 DIA X 2 THK)(PC)	TATA spare parts
277681507701	RUBBER PAD (74X56)(GREY)	TATA spare parts
277681507702	RUBBER PAD (70X48)(GREY)	TATA spare parts
277682400101	WIPER SYSTEM 24V	TATA spare parts
277682400102	ASSY. WIPER BLADE BS1/2/4	TATA spare parts
277682400103	WIPER ARM ASSEMBLY	TATA spare parts
277682400104	WIPER MOTOR 24V/120W/65NM	TATA spare parts
277682400105	WIPER SYSTEM LINKAGE	TATA spare parts
277682906301	WIPER WASHER TANK	TATA spare parts
277688500101	FRONT BUMPER COMPLETE	TATA spare parts
277688600101	REAR BUMPER ASSEMBLY	TATA spare parts
277688700101	ENGINE HOOD	TATA spare parts
277688700102	HINGE ASSEMBLY FOR ENGINE HOOD	TATA spare parts
277688700103	BELLOW FOR ENGINE HOOD	TATA spare parts
277688707701	BEADING FOR ENGINEHOOD (L=5MTR)	TATA spare parts
277692000102	SEAT ASSY MOULDED	TATA spare parts
277692000103	SEAT ASSY PLATIC MOULDED	TATA spare parts
277692000104	SEAT ASSY PLATIC MOULDED	TATA spare parts
277692000105	SEAT ASSY PLATIC MOULDED	TATA spare parts
277692000106	SEAT ASSY PLATIC MOULDED	TATA spare parts
277692000107	SEAT ASSY PLATIC MOULDED	TATA spare parts
277692000108	SEAT ASSY PLATIC MOULDED	TATA spare parts
277692000109	SEAT ASSEMBLY	TATA spare parts
277697980101	2 POINT SEAT BELT	TATA spare parts
277698800101	FIRE EXTINGUISHER	TATA spare parts
277698805601	GRAB HANDLE (PLASTIC)	TATA spare parts
277698805602	INNER GRAB HANDLE	TATA spare parts
277698806001	SAFETY LATCH FOR EMERGENCY DOOR	TATA spare parts
277698806901	GRAB HANDLE PIPE (L=420 - 25.4 DIA)	TATA spare parts
277698807101	CLUSTER & BASE PANEL	TATA spare parts
277730100108	SUB ASSY PULL ROD	TATA spare parts
277731200105	ASSY.FRONT CM WITH COUPLING MOUTH	TATA spare parts
277742900109	ASSY.PIPE ( 12 O.D. )	TATA spare parts
277742900110	ASSY.PIPE ( 12 O.D. )	TATA spare parts
277742900113	ASSY.PIPE ( 12 O.D. )	TATA spare parts
277742900116	ASSY.PIPE ( 12 O.D. )	TATA spare parts
277742900117	ASSY.PIPE ( 12 O.D. )	TATA spare parts
277742900118	ASSY PIPE-12 OD	TATA spare parts
277742900123	ASSY PIPE 1510CNG	TATA spare parts
277742900124	ASSY PIPE 1510CNG	TATA spare parts
277742900126	ASSY.PIPE ( 12 O.D. )	TATA spare parts
277742900127	ASSY.PIPE ( 12 O.D. )	TATA spare parts
277747500111	ASSY. SHIELD SUPPORT-625MM	TATA spare parts
277747500115	ASSY SHIELD SUPPORT 1510CNG	TATA spare parts
277747503304	BRACKET ( LOW PR. FILTER MTNG )1515CNG	TATA spare parts
277747504201	CLAMP	TATA spare parts
277747507701	RUBBER PACKING 1510CNG LH/RH SIDE	TATA spare parts

277747507702	RUBBER PACKING 1510CNG	TATA spare parts
277747507703	RUBBER PACKING 1510CNG LH/RH SIDE	TATA spare parts
277747507704	RUBBER PACKING 1510CNG SEAL	TATA spare parts
277747507706	RUBBER PACKING 1510CNG	TATA spare parts
277747606802	1/4INCHNPTX1/4INCHODT MALE CONNECTOR	TATA spare parts
277747606813	BUSHING 1/2 INCH NPT TO 1/4 INCH NPT	TATA spare parts
277747606814	EQUAL ELBOW 1/4 INCH NPT FOR HOSE	TATA spare parts
277747606818	INLET HOSE	TATA spare parts
277747606819	OUTLET HOSE.	TATA spare parts
277747700104	RECEPTACLE.	TATA spare parts
277747700106	ELECTRIC FUEL SHUT OFF - 12V	TATA spare parts
277747700107	HIGH PRESSURE REGULATOR	TATA spare parts
277747700110	ASSY.FILTER CARTRIDGE.	TATA spare parts
277747707701	O RING	TATA spare parts
277754249902	DC TO DC CONVERTER:24-12VDC	TATA spare parts
277754249903	DC TO DC CONVERTER:24-12VDC	TATA spare parts
277754249904	DC TO DC CONVERTER:24-12VDC	TATA spare parts
277754249905	DC TO DC CONVERTER:24-12VDC -ED	TATA spare parts
277754249906	DC TO DC CONVERTER:24-12VDC -ED	TATA spare parts
277754506904	PIANO SW.(CHECK ENGINE)W/O CONN.	TATA spare parts
277754506905	PIANO SW.(CHECK ENGINE)W/O CONN.	TATA spare parts
277754506906	PIANO SW-(CHECK ENGINE) W/O CONN	TATA spare parts
277754506907	PIANO KEY S/W-DC-DC FAULT	TATA spare parts
277754506908	PIANO SW-CHECK ENGINE W/O CONN	TATA spare parts
277754620101	W/H MAIN LPO 1515 CNG	TATA spare parts
277754620102	W/H CONSOLE LPO 1515 CNG	TATA spare parts
277754620103	W/H TAIL LPO 1515/55 CNG	TATA spare parts
277815408201	BRACKET (H/T CABLE SUPPORT)-LP 1510 CNG	TATA spare parts
277815408202	BRACKET (H/T CABLE SUPPORT)-CNG	TATA spare parts
277815990101	IGNITER	TATA spare parts
277815990103	COIL IGNITION	TATA spare parts
277815999901	COVER DISTRIBUTOR-1510 CNG	TATA spare parts
277815999904	DISTRIBUTOR ARM ASSY.	TATA spare parts
277824200101	ASSY. BRACKET(ENGINE MTG. -REAR BOTTOM)R	TATA spare parts
277824200102	ASSY. BRACKET(ENGINE MTG. -REAR BOTTOM)L	TATA spare parts
277826800101	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
277826800103	ASSY BRACKET-G.S.LEVER MTG.	TATA spare parts
277826803701	BRACKET (HOUSING BLOCK MOUNTING)	TATA spare parts
277826809901	GEAR SHIFT LEVER (LPO1510CGS)	TATA spare parts
277829100102	ASSY TUBE ( 6 O D )	TATA spare parts
277829100103	ASSY CONNECTING LINE	TATA spare parts
277829500101	ASSY BRACKET (MASTER CYL MOUNTING)	TATA spare parts
277830100104	ASSY CONTROL SHAFT	TATA spare parts
277830100106	ASSY BRACKET	TATA spare parts
277830100114	SUBASSY.PULL ROD W/O BALL PIN & NUT	TATA spare parts
277830108203	BRACKET ( RSL CONTROLLER)	TATA spare parts
277831000101	ASSY FRAME COMPLETE	TATA spare parts



277831000104	ASSY.FRAME COMPL. LPO1510 CNG 55 WB	TATA spare parts
277831200103	ASSY. BRACKET RH	TATA spare parts
277831200104	ASSY. BRACKET LH	TATA spare parts
277831200114	BRACKET ASSY RH	TATA spare parts
277831200115	BRACKET ASSY LH	TATA spare parts
277831207107	SUPPORT RH (ENG.CM.FRONT 4 POINT)	TATA spare parts
277831207108	SUPPORT LH (ENG.CM.FRONT 4 POINT)	TATA spare parts
277831207112	REINFORCEMENT - RH	TATA spare parts
277831207113	REINFORCEMENT -LH	TATA spare parts
277831208201	GUSSET RH	TATA spare parts
277831208202	GUSSET LH	TATA spare parts
277832100108	ASSY. FRONT SPRING	TATA spare parts
277832100109	ASSEMBLY MAIN LEAF WITH BRACKET	TATA spare parts
277832100115	ASSY. SECOND LEAF WITH BRACKET	TATA spare parts
277832100139	ASSY. FRONT SPRING (WEWELLER)	TATA spare parts
277832100140	FIRST LEAF	TATA spare parts
277832100141	SECONDLLEAFASSY BS6	TATA spare parts
277832100145	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
277832100146	ASSY. FRONT SPRING LH	TATA spare parts
277832100147	ASSY. FRONT SPRING RH	TATA spare parts
277832103204	CENTER BOLT	TATA spare parts
277832103205	CENTER BOLT M12X235	TATA spare parts
277832103701	FRONT SPRING BRACKET FRONT - LH	TATA spare parts
277832103702	FRONT SPRING BRACKET FRONT - RH	TATA spare parts
277832103703	FRONT SPRING BKT REAR - LH BS1/3/4	TATA spare parts
277832103704	FRONT SPRING REAR BRACKET - RH BS1/3/4	TATA spare parts
277832103705	FRONT SPRING BRACKET - LOWER CAP	TATA spare parts
277832103707	FRONT SPRING HANGER BKT RH REAR & LH FRT	TATA spare parts
277832103708	FRONT SPRING HANGER BKT LH REAR & RH FRT	TATA spare parts
277832104201	SPRING CLIP	TATA spare parts
277832104202	SPRING CLIP	TATA spare parts
277832104203	U-CLAMP (M20X1.5-345 LENGTH)	TATA spare parts
277832104204	U-CLAMP M20X1.5X208 BS6	TATA spare parts
277832104205	U-BOLT BS6-PH2	TATA spare parts
277832104206	U-BOLT BS6-PH2	TATA spare parts
277832104207	U-BOLT	TATA spare parts
277832104208	U-BOLT&BS6	TATA spare parts
277832104209	U-BOLT	TATA spare parts
277832104210	U-BOLT	TATA spare parts
277832107127	THIRD LEAF	TATA spare parts
277832107128	FOURTH LEAF	TATA spare parts
277832107129	FIFTH LEAF	TATA spare parts
277832107130	SIXTH LEAF	TATA spare parts
277832107131	SEVENTH LEAF	TATA spare parts
277832107132	EIGHTH LEAF	TATA spare parts
277832107133	NINTH LEAF	TATA spare parts
277832107134	TENTH LEAF	TATA spare parts

277832107135	ELEVENTH LEAF	TATA spare parts
277832107136	SPACER PLATE/PP	TATA spare parts
277832107137	SPRING COLLAR BRACKET FRT 70 WIDE	TATA spare parts
277832107164	FIRST LEAF	TATA spare parts
277832107165	SECOND LEAF	TATA spare parts
277832107166	THIRD LEAF	TATA spare parts
277832107167	FOURTH LEAF	TATA spare parts
277832107168	FIFTH LEAF	TATA spare parts
277832107169	SIXTH LEAF	TATA spare parts
277832107170	SEVENTH LEAF	TATA spare parts
277832107171	EIGHTH LEAF	TATA spare parts
277832107172	NINTH LEAF	TATA spare parts
277832107173	TENTH LEAF	TATA spare parts
277832107174	ELEVENTH LEAF	TATA spare parts
277832107176	2ND LEAF	TATA spare parts
277832107177	3RD LEAF	TATA spare parts
277832107178	4TH LEAF	TATA spare parts
277832107179	5TH LEAF	TATA spare parts
277832107180	6TH LEAF	TATA spare parts
277832107181	7TH LEAF	TATA spare parts
277832107182	8TH LEAF	TATA spare parts
277832107183	9TH LEAF	TATA spare parts
277832107184	10TH LEAF	TATA spare parts
277832107185	SPACER LEAF SPRING	TATA spare parts
277832107701	WEWELLER RUBBER-FRONT SPRING BS1/2/3/4	TATA spare parts
277832203702	GUIDE PLATE	TATA spare parts
277832203703	GUIDE PLATE	TATA spare parts
277832204201	U CLAMP M20X1.5X355	TATA spare parts
277832207702	RUBBER BUFFER	TATA spare parts
277832207702AE	RUBBER BUFFERLPA 1415/	TATA spare parts
277832300102	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
277832300108	ASSY. BRACKET FRONT SHOCK ABSORBER	TATA spare parts
277832300109	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
277832301602	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
277832303302	COMBINED ARB AND SHOCK ABS MTG BKT-RH	TATA spare parts
277832303303	COMBINED ARB AND SHOCK ABS MTG. BKT - LH	TATA spare parts
277832400115	ASSY. REAR SPRING	TATA spare parts
277832400116	1ST LEAF WEVELLER SPRING	TATA spare parts
277832400117	2ND LEAF WEVELLER SPRING	TATA spare parts
277832400128	ASSY REAR SPRING	TATA spare parts
277832400134	FRONT AIR SPRING BKT -LH	TATA spare parts
277832400135	FRONT AIR SPRING BKT - RH	TATA spare parts
277832400136	REAR AIR SPRING BKT- LH	TATA spare parts
277832400137	REAR AIR SPRING BKT- RH	TATA spare parts
277832400138	PARALLEL LINK BKT ASSY -LH	TATA spare parts
277832400139	PARALLEL LINK BKT ASSY -RH	TATA spare parts
277832400142	FRONT AIR SPRING MTG BKT	TATA spare parts

277832400143	REAR AIR SPRING MTG BKT	TATA spare parts
277832400146	PARRALLEL LINK ASSY -LH	TATA spare parts
277832400147	PARRALLEL LINK ASSY -RH	TATA spare parts
277832400148	RADIUS ROD ASSY.	TATA spare parts
277832400149	CONNECTING ROD ASSY	TATA spare parts
277832400150	LEVELLING VALVE MAJOR ASSY LH	TATA spare parts
277832400151	LEVELLING VALVE MAJOR ASSY RH	TATA spare parts
277832400152	COWHORN ASSY LH	TATA spare parts
277832400153	COWHORN ASSY RH	TATA spare parts
277832400156	ASSY. COW HORN - LH	TATA spare parts
277832400157	ASSY. COW HORN - RH	TATA spare parts
277832400164	ASSY. AIR SPRING MTG. BRACKET FRONT - LH	TATA spare parts
277832400165	ASSY. AIR SPRING MTG. BRACKET FRONT - RH	TATA spare parts
277832400166	ASSY. AIR SPRING MTG. BRACKET REAR - LH	TATA spare parts
277832400167	ASSY. AIR SPRING MTG. BRACKET REAR - RH	TATA spare parts
277832400169	ASSY. CROSS MEMBER FRONT (REAR SUSP)	TATA spare parts
277832400171	ASSY. CROSS MEMBER REAR (WITH GUSSET)	TATA spare parts
277832400176	SUPPORT BKT LH	TATA spare parts
277832400177	SUPPORT BKT RH	TATA spare parts
277832400178	FRONT AIR SPRING C/M	TATA spare parts
277832400179	REAR AIR SPRING C/M	TATA spare parts
277832400185	ASSY. LEVELLING VALVE	TATA spare parts
277832400186	ASSY. REAR AIR SPRING BS3/4	TATA spare parts
277832400191	ASSY. V ROD M/S VIBRACOUSTIC	TATA spare parts
277832400192	ASSY. TORQUE ROD - LH M/S VIBRACOUSTIC	TATA spare parts
277832400193	ASSY. TORQUE ROD - RH M/S VIBRACOUSTIC	TATA spare parts
277832400194	ASSY BRACKET ARB MTG ON FRAME	TATA spare parts
277832400196	ASSY. TORQUE ROD REAR - LH	TATA spare parts
277832400197	ASSY. TORQUE ROD REAR - RH	TATA spare parts
277832400198	ASSY. V ROD REAR	TATA spare parts
277832403203	M10X1.5X35MM HEX BOLT	TATA spare parts
277832403204	HEX. BOLT M14X1.5X55	TATA spare parts
277832403205	HEX. BOLT M14X1.5X65	TATA spare parts
277832403206	HEX. BOLT M14X1.5X70	TATA spare parts
277832403207	HEX. BOLT M14X1.5X90	TATA spare parts
277832403208	HEX. BOLT M16X1.5X55	TATA spare parts
277832403209	M16 X 1.5 X 65MM HEX BOLT	TATA spare parts
277832403210	M16 X 1.5 X 80MM HEX BOLT	TATA spare parts
277832403211	HEX. BOLT M16X2X100	TATA spare parts
277832403212	HEX. SCREW M20X2.5X55	TATA spare parts
277832403213	HEX. BOLT M20X2.5X130	TATA spare parts
277832403214	HEX SCREW M20X1.5X70	TATA spare parts
277832403215	HEX. BOLT M20X2.5X35	TATA spare parts
277832403216	HEX. FL. BOLT M8X65 - 8.8	TATA spare parts
277832403217	HEX. FL. BOLT M14X1.5X45 - 10.9 BS6	TATA spare parts
277832403218	HEX FL BOLT M14X1.5X50	TATA spare parts
277832403219	HEX. FL. BOLT M14X1.5X60 - 10.9	TATA spare parts

277832403220	HEX. FL. BOLT M14X1.5X75 - 10.9	TATA spare parts
277832403221	HEX. FL. BOLT M16X1.5X50 - 10.9	TATA spare parts
277832403222	HEX. FL. BOLT M16X1.5X70 - 10.9	TATA spare parts
277832403223	HEX. FL. BOLT M18X1.5X80 - 10.9	TATA spare parts
277832403224	HEX. FL. BOLT M20X1.5X70 - 10.9	TATA spare parts
277832403225	HEX. FL. BOLT M20X1.5X170 - 10.9	TATA spare parts
277832403226	EX FL BOLT M20X1.5X85 - 10.9	TATA spare parts
277832403227	HEX. FL. BOLT M20X1.5X40 - 10.9	TATA spare parts
277832403228	HEX. FL. BOLT M16X1.5X80 - 10.9	TATA spare parts
277832403229	HEX. FL. BOLT M16X1.5X90 - 10.9	TATA spare parts
277832403230	CENTRE BOLT M12X180	TATA spare parts
277832403231	CENTRE BOLT M12X190	TATA spare parts
277832403233	HEX FLANGE BOLT M12X1.5X100-10.9	TATA spare parts
277832403234	HEX. FL. BOLT M20X1.5X90-10.9	TATA spare parts
277832403235	HEX FLANGE BOLT M20X1.5X135-10.9	TATA spare parts
277832403307	RADIUS ROD AXLE BRK	TATA spare parts
277832403308	V ROD MTG. BRACKET - LH (ON FRAME)	TATA spare parts
277832403309	V ROD MTG. BRACKET - RH (ON FRAME)	TATA spare parts
277832403310	V ROD MTG BRACKET (ON AXLE)	TATA spare parts
277832403311	PARALLEL LINK BRACKET LH	TATA spare parts
277832403312	PARALLEL LINK BRACKET RH	TATA spare parts
277832403701	REAR SPRING BKT. LH FRONT & RH REAR	TATA spare parts
277832403702	REAR SPRING BKT. RH FRONT & LH REAR	TATA spare parts
277832403703	REAR SPG. LOWER CAP LH FRONT & RH REAR	TATA spare parts
277832403704	REAR SPG. LOWER CAP RH REAR & LH FRONT	TATA spare parts
277832403707	REAR SPRING BKT. LH FRONT & RH RR BS1-6	TATA spare parts
277832403708	REAR SPRING BKT. RH FRT & LH RR BS1-6	TATA spare parts
277832403711	CASTER PLATE	TATA spare parts
277832403712	RADIUS ROD AXLE BRACKET	TATA spare parts
277832404201	SPRING CLIP	TATA spare parts
277832404205	U BOLT M24X1.5X410	TATA spare parts
277832405102	SPRING SADDLE BOTTOM BS6	TATA spare parts
277832406001	PENDULUM ROD	TATA spare parts
277832406002	CONNECTING ROD	TATA spare parts
277832406501	M10X1.5 HEX NUT	TATA spare parts
277832406502	M14X1.5 HEX NUT	TATA spare parts
277832406503	M16X1.5 HEX NUT	TATA spare parts
277832406504	NYLOC NUT M16X2	TATA spare parts
277832406505	NYLOC NUT M20X2.5	TATA spare parts
277832406506	M24 X 3 CASTLE NUT	TATA spare parts
277832406507	NYLOC NUT M24X1.5	TATA spare parts
277832406508	HEX. FL. NUT M8X1.25 - 8 ISO7044	TATA spare parts
277832406509	HEX. FL. NUT M10X1.5 - 10 ISO7044	TATA spare parts
277832406510	HEX. FL. NUT M14X1.5 - 10 ISO12126	TATA spare parts
277832406511	HEX. FL. NUT M16X1.5 - 10 ISO12126	TATA spare parts
277832406512	HEX. FL. NUT M20X1.5 - 10 ISO12126	TATA spare parts
277832406515	FLANGE NUT(U BOLT REAR)	TATA spare parts

277832406601	PISTON	TATA spare parts
277832406701	SPLIT PIN	TATA spare parts
277832407122	THIRD LEAF	TATA spare parts
277832407123	FOURTH LEAF	TATA spare parts
277832407124	FIFTH LEAF	TATA spare parts
277832407125	SIXTH LEAF	TATA spare parts
277832407126	SEVENTH LEAF	TATA spare parts
277832407127	EIGHTH LEAF	TATA spare parts
277832407128	NINTH LEAF	TATA spare parts
277832407129	TENTH LEAF	TATA spare parts
277832407130	SPRING COLLAR BRACKET RR 80 WIDE	TATA spare parts
277832407143	BRACKET SUSPENSION PIPE INLET CONNECTOR	TATA spare parts
277832407701	WEWELLER RUBBER-REAR SPRING	TATA spare parts
277832407702	WEWELLER RUBBER BS1/2/3/4	TATA spare parts
277832407704	RUBBER BOTTOM	TATA spare parts
277832407705	RUBBER TOP	TATA spare parts
277832407706	SPRING ASSY AIR BELLOW	TATA spare parts
277832407707	BUMP STOPPER	TATA spare parts
277832408301	SHIM -2 MM	TATA spare parts
277832408302	SHIM -3 MM	TATA spare parts
277832408306	SHIM-1THK.	TATA spare parts
277832408307	SHIM-2THK.	TATA spare parts
277832408308	SHIM - 3 THK	TATA spare parts
277832409201	M10 SPRING WASHER	TATA spare parts
277832409202	M14 SPRING WASHER	TATA spare parts
277832409203	M16 SPRING WASHER	TATA spare parts
277832409204	HARD WASHER M16	TATA spare parts
277832409205	HARD WASHER M20	TATA spare parts
277832409206	HARD WASHER M24	TATA spare parts
277832410103	ASSY. REAR SPRING	TATA spare parts
277832410104	ASSY. REAR SPRING	TATA spare parts
277832410105	12INCH AIR SPRING ASSY.	TATA spare parts
277832410108	ASSY LEVELLING VALVE	TATA spare parts
277832410109	HANGER LINK ASSEMBLY	TATA spare parts
277832410110	ASSY. REAR SPRING WEWELLER	TATA spare parts
277832410111	KIT FOR REAR WEWELLER SUSP. OF LPO 1512	TATA spare parts
277832410112	TAPER PIN BUSH ASSY	TATA spare parts
277832410113	ASSY. BAR PIN BUSH	TATA spare parts
277832410115	FRAME COMPONENTS ASSY AIR SUSPENSION BS6	TATA spare parts
277832410116	LEVELLING VALVE ASSY	TATA spare parts
277832410119	AIR SUSPENSION ASSY AXLE COMPONENT BS6	TATA spare parts
277832410120	AIR SUSPN ASSY ZERO STATION COMPONENT BS	TATA spare parts
277832413201	M12X1.75X25 MM HEX BOLT	TATA spare parts
277832413701	ASSY COMPOUND LINK BKT	TATA spare parts
277832416601	12IN STEEL PISTON	TATA spare parts
277832417114	RETAINING PLATE	TATA spare parts
277832417115	12INCH STEEL CLAMP PLATE	TATA spare parts

277832417116	TOP PLATE	TATA spare parts
277832417701	12INCH ROLLING DIAPRAM	TATA spare parts
277832417702	BUMP STOP	TATA spare parts
277832417703	RUBBER WASHER M12	TATA spare parts
277832419201	M12 MACHINED WASHER	TATA spare parts
277832500101	ASSY BUMP STOPPER (REAR)	TATA spare parts
277832500101AE	ASSY BUMP STOPPER (REAR)	TATA spare parts
277832500102	ASSY. BUMP STOP BRACKET (REAR SPRING)	TATA spare parts
277832500103	ASSY.REAR BUMP STOP BRACKET(REAR SPRING)	TATA spare parts
277832500109	ASSY. RUBBER BUFFER (FOR REAR AXLE STOPP	TATA spare parts
277832500110	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
277832500111	ASSY. REAR SPRING	TATA spare parts
277832504202	U CLAMP	TATA spare parts
277832507111	SECOND LEAF	TATA spare parts
277832507112	THIRD LEAF	TATA spare parts
277832507113	FOURTH LEAF	TATA spare parts
277832507114	FIFTH LEAF	TATA spare parts
277832507115	SIXTH LEAF	TATA spare parts
277832507116	SEVENTH LEAF	TATA spare parts
277832507117	EIGHTH LEAF	TATA spare parts
277832507118	NINTH LEAF	TATA spare parts
277832600102	ASSY. REAR SHOCK ABSORBER	TATA spare parts
277832600117	ASSY. REAR SHOCK ABSORBER BS3/4	TATA spare parts
277832600120	ASSY. BRACKET LH (REAR S/A MTG )	TATA spare parts
277832600121	ASSY. BRACKET RH (REAR S/A MTG )	TATA spare parts
277832600122	ASSY BKT LH REAR SHOCK ABSORBER MTG	TATA spare parts
277832600123	ASSY BKT RH REAR SHOCK ABSORBER MTG	TATA spare parts
277832800104	ASSY. CONNECTING LINK	TATA spare parts
277832800112	CONNCTING LINK ASSY FRONT ANTI ROLL BAR	TATA spare parts
277832800113	CONN LINK ASSY FRT ANTI ROLL BAR BS6-PH2	TATA spare parts
277832806701	MOUNTING PIN	TATA spare parts
277832900101	ANTI ROLL BAR ASSY	TATA spare parts
277832900102	HANGER LINK ASS	TATA spare parts
277832900107	ASSY. BUSH (REAR ANTI ROLL BAR)	TATA spare parts
277832900110	ASSY. ANTI ROLL BAR REAR (DIA 50)	TATA spare parts
277832900113	ASSY RUBBER BUSH ARB (DIA 50)	TATA spare parts
277832907101	HANGER LINK	TATA spare parts
277832907102	HANGER LINK BOTTOM CUP	TATA spare parts
277832907110	CLAMP PLATE ARB MTG. (DIA 50)	TATA spare parts
277832907701	MR SPLIT BUSH - SET	TATA spare parts
277832907702	RUBBER MOUNTING	TATA spare parts
277832907706	ARB BUSH BS6	TATA spare parts
277832908601	SHOCK WASHER	TATA spare parts
277832908602	SHOCK WASHER	TATA spare parts
277832950101	PIPE BUNCH ASSY	TATA spare parts
277832990103	MINOR KIT-LEVELLING VALVE	TATA spare parts
277832990104	MAJOR KIT-LEVELLING VALVE	TATA spare parts

277832990105	MINOR KIT-LEVELLING VALVE	TATA spare parts
277832990106	MINOR KIT-LEVELLING VALVE	TATA spare parts
277832990107	MAJOR KIT-LEVELLING VALVE	TATA spare parts
277833000101	LPT1613 FRONT AXLE COMPL.WITH BRAKES	TATA spare parts
277833000136	ASSY.FRONT AXLE COMPL.WITH BRAKES	TATA spare parts
277833000137	ASSY. FRONT AXLE COMP. WITH BRAKES	TATA spare parts
277841100104	ASSY.PROP.SHAFT WITH C.B. MIDDLE COMP.	TATA spare parts
277841100109	ASSY.PROP.SHAFT MIDDLE ( L=1126)	TATA spare parts
277841100110	ASSY.PROP.SHAFT FRONT ( L=1904)	TATA spare parts
277841120101	ASSY.PROP.SHAFT REAR (C.L=1663)	TATA spare parts
277841303301	BRACKET FOR CENTRE BEARING-1	TATA spare parts
277841303302	BRACKET FOR CENTRE BEARING-2	TATA spare parts
277841500101	ASSY. GUARD (FOR PROPELLOR SHAFT)	TATA spare parts
277841506901	GUARD-PROPELLER SHAFT	TATA spare parts
277842100101	ASSY. SLACK ADJUSTER FRONT(AUTO) BS1- 6	TATA spare parts
277842100102	SLACK ADJUSTER	TATA spare parts
277842100131	ASSY. FRONT BRAKE LH	TATA spare parts
277842100132	ASSY. FRONT BRAKE RH	TATA spare parts
277842100140	ASSY SLACK ADJUSTER FRONT(AUTO)	TATA spare parts
277842100148	ASSY.FRT.DRUM BRAKE W/DUST COVER RH	TATA spare parts
277842100149	ASSY.FRT.DRUM BRAKE W/DUST COVER LH	TATA spare parts
277842100159	ASSY SLACK ADJUSTER FRONT(AUTO)	TATA spare parts
277842100171	AUTO SLACK ADJUSTER -140CD 0 OFFSET	TATA spare parts
277842100199	AUTO SLACK ADJUSTER -140CD/0 OFFSET	TATA spare parts
277842100215	AUTO SLACK ADJUSTER -140CD O OFF BS1- 6	TATA spare parts
277842100216	AUTO SLACK ADJUSTER -LH 140CD/16 OFFSET	TATA spare parts
277842100217	AUTO SLACK ADJUSTER-RH 140CD 16 OFFSET	TATA spare parts
277842100218	AUTO SLACK ADJUSTER -LH 150CD/16 OFFSET	TATA spare parts
277842100219	AUTO SLACK ADJUSTER -RH 150CD/16 OFFSET	TATA spare parts
277842106701	PIN -FULCRUM	TATA spare parts
277842108201	ANCHOR BRACKET-LH	TATA spare parts
277842108202	ANCHOR BRACKET-RH	TATA spare parts
277842108203	ANCHOR BRACKET -LH AUTO SLACK ADJ FRT	TATA spare parts
277842108204	ANCHOR BRACKET -RH AUTO SLACK ADJ 3118	TATA spare parts
277842108205	ANCHOR BRACKET FOR ASA LH	TATA spare parts
277842108206	ANCHOR BRACKET FOR ASA RH	TATA spare parts
277842108301	SHIM	TATA spare parts
277842108302	SHIM 0.8 MM ID 38.5	TATA spare parts
277842108303	SHIM 0.5MM ID 38.5	TATA spare parts
277842108306	SHIM-2MM FOR HALDEX AUTOADJUSTER ID 38.5	TATA spare parts
277842108601	SPACER	TATA spare parts
277842108702	SPRING ABUTMENT END	TATA spare parts
277842108704	SPRING ABUTMENT END	TATA spare parts
277842130101	KIT-BRAKE LINING FRONT	TATA spare parts
277842130101AE	KIT-BRAKE LNG FRT STD -1415-715	TATA spare parts
277842130102	KIT-BRAKE LINING REAR	TATA spare parts
277842130103	BRAKE ASSY -KIT LINING 160 OS1	TATA spare parts

277842130104	BRAKE ASSY -KIT LINING 160 OS2	TATA spare parts
277842130105	ASSY.LINED SHOE(AF)	TATA spare parts
277842130106	ASSY. LINED SHOE BS1/2/3/4	TATA spare parts
277842130107	KIT FIRST OVER SIZE RAF7	TATA spare parts
277842130108	KIT SECOND OVER SIZE RAF7	TATA spare parts
277842130109	KIT LINING SET STD	TATA spare parts
277842130114	ASSY. BRAKE SHOE WITH NASB(REAR)	TATA spare parts
277842130115	ASSY. BRAKE LINED SHOE FRONT BS1/2/3	TATA spare parts
277842130115AE	LINED SHOE FRONT	TATA spare parts
277842130128	BRAKE ASSY -KIT LINING 180 STD	TATA spare parts
277842130129	BRAKE ASSY -KIT LINING 180 OS1	TATA spare parts
277842130130	BRAKE ASSY -KIT LINING 180 OS2	TATA spare parts
277842130134	KIT-BRAKE LINING FRONT O/S I (PER AXLE)	TATA spare parts
277842130135	KIT-BRAKE LINING FRONT O/S II (PER AXLE)	TATA spare parts
277842133301	ASSY. FLANGE TUBE & BRACKET LH	TATA spare parts
277842133302	ASSY. FLANGE TUBE & BRACKET RH	TATA spare parts
277842133303	ASSY. FLANGE TUBE & BRACKET LH	TATA spare parts
277842133304	ASSY. FLANGE TUBE & BRACKET RH	TATA spare parts
277842133306	BRAKE ASSY -TUBE FALNGE BRKT LH	TATA spare parts
277842133307	BRAKE ASSY -TUBE FLANGE BRKT RH	TATA spare parts
277842133308	BRAKE ASSY -TUBE FALNGE BRKT LH	TATA spare parts
277842133309	BRAKE ASSY -TUBE FALNGE BRKT RH	TATA spare parts
277842133701	TORQUE PLATE RH	TATA spare parts
277842133702	TORQUE PLATE LH	TATA spare parts
277842133703	TORQUE PLATE LH / RH	TATA spare parts
277842133705	TORQUE PLATE LH ABS BRAKE	TATA spare parts
277842133706	TORQUE PLATE RH ABS BRAKE	TATA spare parts
277842133707	KIT TORQUE PLATE	TATA spare parts
277842133708	TORQUE PLATE LH / RH	TATA spare parts
277842133709	KIT TORQUE PLATE RH	TATA spare parts
277842135101	ROLLER	TATA spare parts
277842135101AE	ROLLER 715	TATA spare parts
277842135102	CAM SHAFT LH	TATA spare parts
277842135103	CAM SHAFT RH	TATA spare parts
277842135104	ROLLER	TATA spare parts
277842135105	CAMSHAFT LH	TATA spare parts
277842135106	CAMSHAFT RH	TATA spare parts
277842135109	CAMSHAFT LH FOR 1312 BRAKE	TATA spare parts
277842135110	CAMSHAFT RH	TATA spare parts
277842135111	CAM SHAFT LH	TATA spare parts
277842135112	CAM SHAFT RH	TATA spare parts
277842135113	CAMSHAFT LH& BRAKE REAR TAG AXLE	TATA spare parts
277842135114	CAMSHAFT RH& REAR BRAKE TAG AXLE	TATA spare parts
277842135115	S CAM SHAFT LH	TATA spare parts
277842135116	S CAM SHAFT RH	TATA spare parts
277842135117	BOLT M8 X 1.25 X 20	TATA spare parts
277842135118	S CAM SHAFT RH	TATA spare parts



277842135119	CAM SHAFT LH	TATA spare parts
277842135120	CAM SHAFT RH	TATA spare parts
277842135123	CAMSHAFT LH	TATA spare parts
277842135124	CAMSHAFT RH	TATA spare parts
277842136309	KIT-BRAKE LINER SET STD (410 X 180) BS6	TATA spare parts
277842136310	KIT-BRAKE LINER O/S 1 (410 X 180) BS6	TATA spare parts
277842136311	KIT-BRAKE LINER O/S 2 (410 X 180) BS6	TATA spare parts
277842138701	SPRING PULL OFF CAM END BS1/2/3/4	TATA spare parts
277842138701AE	SPRING CAM END 715	TATA spare parts
277842138702	SPRING PULL OFF CAM END	TATA spare parts
277842300101	ASSY SLACK ADJUSTER REAR-LH(AUTO)	TATA spare parts
277842300102	ASSY SLACK ADJUSTER REAR-RH(AUTO)	TATA spare parts
277842300110	ASSY.DRUM BRAKE LH N/ASB.	TATA spare parts
277842300111	ASSY.DRUM BRAKE RH N/ASB	TATA spare parts
277842300116	ASSY SLACK ADJUSTER REAR-RH(AUTO)	TATA spare parts
277842300125	ASSY SLACK ADJUSTER REAR-LH(AUTO)	TATA spare parts
277842300134	ASSY REAR BRAKE RH(AF235)WT DCOVER	TATA spare parts
277842300135	ASSY REAR BRAKE LH(AF235)WT DCOVER	TATA spare parts
277842300138	ASSY SLACK ADJUSTER REAR-RH(AUTO)	TATA spare parts
277842300139	ASSY SLACK ADJUSTER REAR-LH(AUTO)	TATA spare parts
277842300153	ASSY SLACK ADJUSTER REAR-RH(AUTO)	TATA spare parts
277842300154	ASSY.AUTO SLACK ADJ. 43MM OFFSSET	TATA spare parts
277842300155	AUTO SLACK ADJ. 43MM OFFSET LH	TATA spare parts
277842300156	ASSY SLACK ADJUSTER REAR-LH(AUTO)	TATA spare parts
277842300160	ASSY CHAMBER MOUNTING BRACKET LH	TATA spare parts
277842300161	ASSY CHAMBER MOUNTING BRACKET RH	TATA spare parts
277842300162	ASSY CHAMBER MOUNTING BRACKET LH	TATA spare parts
277842300163	ASSY CHAMBER MOUNTING BRACKET RH	TATA spare parts
277842300164	KIT-AUTOMATIC SLACK ADJUSTER	TATA spare parts
277842300165	KIT-AUTOMATIC SLACK ADJUSTER	TATA spare parts
277842300168	MAJOR KIT-AUTO. SLACK ADJUSTER	TATA spare parts
277842300170	REFERENCE UNIT ASSY SPARE KIT	TATA spare parts
277842300172	MINOR KIT-AUTO.SLACK ADJUSTER	TATA spare parts
277842300177	AUTO SLACK ADJSUTER -140CD 0 OFF 30 CRK	TATA spare parts
277842300182	SLACK ADJUSTER STRAIGT BS1/2/3/4	TATA spare parts
277842300183	AUTO. SLACK ADJUSTER LH 16-OFF BS2/3/4	TATA spare parts
277842300184	AUTO. SLACK ADJUSTER RH-16 OFF BS2/3/4	TATA spare parts
277842300188	LINING WEAR SENSOR LH	TATA spare parts
277842300189	LINING WEAR SENSOR-RH	TATA spare parts
277842300190	AUTO SLK. ADJ. 140CD BS1/2/3/4	TATA spare parts
277842300197	WEAR SENSOR-CABLE ASSEMBLY L.H	TATA spare parts
277842300198	WEAR SENSOR-CABLE ASEEMBLY R.H	TATA spare parts
277842300210	AUTO SLACK ADJUSTER-RH 140CD 43 OFFSET	TATA spare parts
277842300217	CAMSHAFT BRACKET	TATA spare parts
277842300219	AUTO SLACK ADJUSTER-LH 140CD 43 OFFSET	TATA spare parts
277842300220	AUTO SLACK ADJUSTER-140CD 0 OFFSET	TATA spare parts
277842301601	AUTO SLACK ADJUSTER STRIGHT	TATA spare parts

277842301602	AUTO SLACK ADJUSTER LH 43MM OFFSET	TATA spare parts
277842301603	AUTO SLACK ADJUSTER RH 43MM OFFSET	TATA spare parts
277842303701	BRACKET LH	TATA spare parts
277842303702	BRACKET RH	TATA spare parts
277842305107	BRAKE CAM SHAFT RH	TATA spare parts
277842305108	BRAKE CAM SHAFT LH	TATA spare parts
277842305109	CAMSHAFT REAR BRAKE RH	TATA spare parts
277842308201	ANCHOR BRACKET-LH (AUTO ADJ.REAR)	TATA spare parts
277842308202	ANCHOR BRACKET-RH (AUTO ADJ.REAR)	TATA spare parts
277842308601	SHIM OF LINING WEAR SENSOR	TATA spare parts
277842308603	SLEEVE SPACER	TATA spare parts
277842900102	ASSY. PIPE ( 15 O.D.)	TATA spare parts
277842900103	ASSY. PIPE ( 15 O.D.)	TATA spare parts
277842900106	ASSY. PIPE ( 15 O.D.)	TATA spare parts
277842900108	ASSY. PIPE ( 6 O.D.)	TATA spare parts
277842900109	ASSY. PIPE ( 6 O.D.)	TATA spare parts
277842900118	ASSY PIPE (15 O.D.)	TATA spare parts
277842900119	ASSY PIPE (SPV PORT21 - FRT AIR TANK)	TATA spare parts
277842900121	ASSY PIPE (12 O.D.)	TATA spare parts
277842908601	SPACER	TATA spare parts
277842910103	ASSY.AIR TANK COMPLETE-LH	TATA spare parts
277842910104	ASSY.AIR TANK COMPLETE-RH	TATA spare parts
277842990103	BRAKE LINING KIT FRONT	TATA spare parts
277842990105	MAJOR SPARE KIT	TATA spare parts
277842990107	AUTO SLACK ADJUSTER -MAJOR SPARE KIT	TATA spare parts
277842990108	AUTO SLACK ADJUSTER -MAJOR SPARE KIT	TATA spare parts
277842990111	KIT-AUTO SLACK ADJUSTER	TATA spare parts
277842990112	KIT-AUTO SLACK ADJUSTER WORMSHAFT	TATA spare parts
277842990113	COVER PLATE KIT BS6-PH2	TATA spare parts
277842990114	KIT-TORQUE PLATE - FRONT LH	TATA spare parts
277842990115	KIT-TORQUE PLATE - FRONT RH	TATA spare parts
277842990124	KIT-BRAKE SPRING	TATA spare parts
277842990125	KIT-BRAKE SPRING	TATA spare parts
277842990126	SPRING - CAM END	TATA spare parts
277842990127	KIT-BRAKE DUST SHIELD	TATA spare parts
277842990129	KIT-BRAKE BUSH	TATA spare parts
277842990130	KIT-BRAKE SHIM	TATA spare parts
277842990131	KIT-BOLT & WASHER (BRACKET)	TATA spare parts
277842990132	KIT-BOLT & WASHER (DUST SHIELD ASSY)	TATA spare parts
277842990133	KIT-BRAKE BS6	TATA spare parts
277842990134	KIT-BRAKE LINE SHOE ASSY	TATA spare parts
277842990141	AUTO SLACK ADJUSTER MAJOR SPARE KIT	TATA spare parts
277842990142	KIT-BRAKE	TATA spare parts
277842990143	KIT-BRAKE	TATA spare parts
277842990144	BRACKET LH	TATA spare parts
277842990145	BRACKET RH	TATA spare parts
277842990146	KIT-BRAKE	TATA spare parts

277842990153	KIT-BRAKE	TATA spare parts
277842990154	KIT-BRAKE	TATA spare parts
277842990155	KIT-BRAKE	TATA spare parts
277843000019	SPRING COMPRESSION	TATA spare parts
277843700102	ASSY. AIR DRIER	TATA spare parts
277843700103	SYSTEM PROTECTION VALVE	TATA spare parts
277843700106	CONDENSATE SEPERATOR 24V	TATA spare parts
277843700107	ASSY.BRACKET (CONDENSATE SEPERATOR)	TATA spare parts
277843700108	AIR DRYER ASSY	TATA spare parts
277843700108C	AIR DRYER ASSYCORE	TATA spare parts
277843700119	AIR DRYER(9BAR-VOSS)	TATA spare parts
277843700120	FOUR CIRCUIT PROT VALVE 8.1-WTIL BS2/3/4	TATA spare parts
277843700122	REPAIR KIT FOR SPV	TATA spare parts
277843700123	REPAIR KIT FOR AIR DRYER	TATA spare parts
277843700125	PRESSURE REDUCTION VALVE 9 TO 7.5BAR	TATA spare parts
277843700126	PRESSURE REDUCTION VALVE 9 TO 6.0BAR	TATA spare parts
277843700127	PRESSURE REDUCTION VALVE 9 TO 4.5BAR	TATA spare parts
277843700129	PRESSURE REDUCTION VALVE 10TO 4.5BAR	TATA spare parts
277843700130	PRESSURE REDUCTION VALVE 10TO 6.0BAR	TATA spare parts
277843700131	PRESSURE REDUCTION VALVE 10TO 7.5BAR	TATA spare parts
277843700145	AIR DRYER	TATA spare parts
277843700146	DUAL TREADLE VALVE	TATA spare parts
277843700147	TYPE 24 DISC BRAKE CHAMBER (PORT SHIFTER	TATA spare parts
277843700148	TYPE 24 DISC BRAKE CHAMBER (PORT SHIFTER	TATA spare parts
277843700149	ASSY HAND BRAKE VALVE WITHOUT VOSS CONN	TATA spare parts
277843700150	DUAL TREADLE VALVE WITH AUX. INLET PORTS	TATA spare parts
277843700151	AIR DRYER(9BAR-METRIC)	TATA spare parts
277843700153	ASSY. HAND BRAKE VALVE	TATA spare parts
277843700156	HELDEX CONSEP(3100430002)	TATA spare parts
277843700157	REPAIR KIT CONSEP UNIT	TATA spare parts
277843700158	ASSY.100 DIA EXHAUST BRAKE COMPL WITH 40	TATA spare parts
277843700159	REPAIR KIT FOR PRESSURE REDUCTION VALVE	TATA spare parts
277843700160	RELAY VALVE SPARE KIT	TATA spare parts
277843700165	AIR DRYER 9 BAR OSC CARTRIDGE & W/O CTRL	TATA spare parts
277843900102	ASSY.METAL PIPE 12 O.D.	TATA spare parts
277843900103	ASSY.METAL PIPE 6 O.D.	TATA spare parts
277843900109	ASSY.METAL PIPE-DIA.12(QRV TO FBC RH)	TATA spare parts
277843900110	ASSY.METAL PIPE-DIA.12(QRV TO FBC LH)	TATA spare parts
277843900127	STRAIGHT PLUG NG12 NW9	TATA spare parts
277843900128	ASSY HOSE 3/8 INCH	TATA spare parts
277843900129	STRAIGHT PLUG NG12 NW12 (SUIT FOR 15 O.D	TATA spare parts
277843900130	ELB PLUG NG12 NW9	TATA spare parts
277843906801	FIRTEE 12X12X12 BS6	TATA spare parts
277843910107	ASSY.18OD PIPE+TEFLON HOSE WITH O RING	TATA spare parts
277843999901	SCREW HOLDER	TATA spare parts
277843999903	ROD WIND OFF ASY	TATA spare parts
277843999905	DUAL BRAKE VALVE UPPER PART MACHINING	TATA spare parts

277843999909	BAFFLE	TATA spare parts
277843999912	VALVE BODY	TATA spare parts
277843999913	DUAL BRAKE VALUE LOWER BODY	TATA spare parts
277843999915	AIR DRYER ASSY BODY	TATA spare parts
277843999916	FLANGE	TATA spare parts
277843999917	CYLINDER BLOCK ASSEMBLY	TATA spare parts
277843999918	HOUSING	TATA spare parts
277843999920	SCREW PRESSURE SETTING	TATA spare parts
277843999921	PISTON PRIMARY	TATA spare parts
277843999922	COVER TOP	TATA spare parts
277843999923	PISTON SECONDARY	TATA spare parts
277846000101	DRAG LINK ASSEMBLY - RHD (WEVELLER SUSP)	TATA spare parts
277846000107	ASSY DRAG LINK	TATA spare parts
277846000108	DRAGLINK ASSY	TATA spare parts
277846000109	ASSY BALL JOINT (SEALED TYPE)	TATA spare parts
277846800120	REPAIR KIT TIE ROD	TATA spare parts
277846800121	REPAIR KIT-DRAG LINK BS1/2/3/4	TATA spare parts
277847009901	STICKER (FOR CNG CYLINDER)	TATA spare parts
277847100108	ASSY CYL. VALVE	TATA spare parts
277847100109	ASSY BURST DISC WITH FUSIBLE ALLOY	TATA spare parts
277847100111	ASSY.BULL NOSE W/O NUT & COUPLING SCR	TATA spare parts
277847100112	ASSY.BULL NOSE WITH NUT & COUPLING SC	TATA spare parts
277847106805	ASSY. BULL NOSE WITH EXCESS FLOW VALVE	TATA spare parts
277847106806	ASSY. BULL NOSE WITH EXCESS FLOW VALVE	TATA spare parts
277847109201	WASHER (FIBRE/NYLON) 1510CNG	TATA spare parts
277847109202	BURST DISC (COPPER WASHER) 1510CNG	TATA spare parts
277847109901	CNG CYLINDER 80 LIT.	TATA spare parts
277847109907	CNG CYLINDER(80 LIT)	TATA spare parts
277847109910	CNG CYLINDER 198L	TATA spare parts
277847109911	CNG CYLINDER 198L	TATA spare parts
277847500102	ASSY SUPPORT FRONT 1510CNG	TATA spare parts
277847500103	ASSY SUPPORT REAR 1510CNG	TATA spare parts
277847500113	ASSY. COVERING DISC-FAST FILLING VALVE	TATA spare parts
277847500119	ASSY SUPPORT 1510 CNG	TATA spare parts
277847500131	ASSY SUPPORT RH-CYLINDER GUARD VALVE	TATA spare parts
277847500132	ASSY CYLINDER GUARD VALVE	TATA spare parts
277847500136	ASSY SUPPORT LH-CYLINDER GUARD VALVE	TATA spare parts
277847500142	ASSY.RETROFITMENT KIT - 3 WAY VLV	TATA spare parts
277847500144	ASSY.BRACKET-HOSE CLAMPING	TATA spare parts
277847500146	VALVE GUARD ARM FRONT	TATA spare parts
277847500147	ASSY.CLAMP-PVC COATED	TATA spare parts
277847500148	VALVE GUARD ARM REAR	TATA spare parts
277847500149	ASSY. CYL. VALVE GUARD	TATA spare parts
277847500152	ASSY SUPPORT-GAS CYLINDERS	TATA spare parts
277847500153	ASSY SUPPORT-FOR GAS CYLINDERS	TATA spare parts
277847500154	ASSY STRAP-RUBBERISED	TATA spare parts
277847500156	ASSY STRAP-RUBBERISED	TATA spare parts

277847500158	ASSY STRAP-RUBBERISED	TATA spare parts
277847500160	ASSY CROSS MEMBER	TATA spare parts
277847500164	ASSY.BRACKET (HPR MTG.)	TATA spare parts
277847500167	ASSY BENT ANGLE RH	TATA spare parts
277847500168	ASSY BENT ANGLE LH	TATA spare parts
277847500173	ASSY PLATE RH	TATA spare parts
277847500174	ASSY PLATE LH	TATA spare parts
277847500175	ASSY T BKT RH	TATA spare parts
277847500176	ASSY T BKT LH	TATA spare parts
277847500177	ASSY STRAP	TATA spare parts
277847500187	ASSY SUPPORT RECEPTACLE PR.GUAGE MTG	TATA spare parts
277847500188	ASSY BKT FOR HPR MTG	TATA spare parts
277847500191	ASSY STRAP FOR CYLINDER MTG	TATA spare parts
277847500194	ASSY. SUPPORT (INSIDE LONG MEMBER)	TATA spare parts
277847500197	ASSY SUPPORT TUBE-CENTRE	TATA spare parts
277847503201	U' BOLT (CROSS MEMBER TO LM MOUNTING)	TATA spare parts
277847503204	HEX SCREW M12X1.5X40	TATA spare parts
277847503206	HEX SCREW M10X40	TATA spare parts
277847503208	U BOLT (FOR CYLINDER CLAMPING)	TATA spare parts
277847503210	U BOLT (FOR CYLINDER CLAMPING)	TATA spare parts
277847503309	BRACKET-FOR LPR HOSE CLAMPING	TATA spare parts
277847504201	U BOLT 1510CNG	TATA spare parts
277847505005	L ANGLE	TATA spare parts
277847505007	L ANGLE-CROSS-WISE	TATA spare parts
277847505009	L ANGLE	TATA spare parts
277847505010	CHANNEL	TATA spare parts
277847505012	STAY ANGLE RH	TATA spare parts
277847505013	STAY ANGLE LH	TATA spare parts
277847505301	O RING	TATA spare parts
277847506101	LOCK WASHER (STRAP TO BEAM)	TATA spare parts
277847506105	LOCK PLATE (48.5 CD)	TATA spare parts
277847506106	LOCK PLATE (83CD)	TATA spare parts
277847506107	LOCK PLATE (38CD)	TATA spare parts
277847506110	LOCK PLATE-FOR VENTING PIPE CLAMPING	TATA spare parts
277847506707	CLEVIS PIN-CYL. SUPPORT	TATA spare parts
277847506708	THREADED PIN	TATA spare parts
277847506710	PIPE NUT (G1/2-IS:3468-BRASS)	TATA spare parts
277847506801	HEX NUT M36X1.5	TATA spare parts
277847507110	PLATE 1510CNG	TATA spare parts
277847507127	PLATE-SUPPORT CONN ACROSS FRAME	TATA spare parts
277847507128	ANGLE LH	TATA spare parts
277847507129	ANGLE RH	TATA spare parts
277847507130	ANGLE LH	TATA spare parts
277847507131	ANGLE RH	TATA spare parts
277847507132	PLATE-SUPPORT CONNECTION	TATA spare parts
277847507140	SUPPORT-CROSS MEMBER	TATA spare parts
277847507141	WASHER-FOR CASTLE NUT	TATA spare parts

277847507707	RUBBER STRIP-CYL. SUPPORT	TATA spare parts
277847507708	BALATA PACKING	TATA spare parts
277847507710	RUBBER SHEET	TATA spare parts
277847507714	RUBBER SHEET-FOR LPR HOSE CLAMING	TATA spare parts
277847507717	RUBBER PACKING-VENTING ON BUS BODY	TATA spare parts
277847508253	CROSS PIECE	TATA spare parts
277847508260	SPACER 1.6 THK	TATA spare parts
277847508261	SPACER 3.15 THK	TATA spare parts
277847508601	SPACER	TATA spare parts
277847509801	PACKING PIECE (FOR 'U' BOLT)	TATA spare parts
277847509902	COMPLIANCE PLATE	TATA spare parts
277847509906	BALATA PACKING (L - ANGLE)	TATA spare parts
277847509907	BALATA PACKING (I - BEAM)	TATA spare parts
277847509911	IDENTIFICATION LABEL (FOR CNG)	TATA spare parts
277847509912	DECAL FOR VALVE	TATA spare parts
277847509915	SAFETY INSTRUCTIONS (FOR CNG BUS)	TATA spare parts
277847510101	ASSY CROSS MEMBER(FOR CYLINDER MTG)	TATA spare parts
277847510104	ASSY TIE MEMBER(B/W I3 AND C2)	TATA spare parts
277847510105	ASSY.BRACKET HPR MTG.	TATA spare parts
277847510114	ASSY.SUPPORT TUBE - FRONT RESTRAINT	TATA spare parts
277847510125	ASSY FRAME COMPLETE - REAR	TATA spare parts
277847510127	ASSY FRAME COMPLETE - FABER	TATA spare parts
277847510128	ASSY FRAME COMPLETE - FRONT	TATA spare parts
277847510130	ASSY FRAME COMPLETE - FABER	TATA spare parts
277847510147	ASSY FRAME SUPPORT-FRONT COMP(FOR C2)	TATA spare parts
277847510148	ASSY FRAME SUPPORT FRONT COMP(FOR C1)	TATA spare parts
277847510151	ASSY. SUPPORT (INSIDE LONG MEMBER)	TATA spare parts
277847510155	ASSY. PLATE (FOR CYLINDER MOUNTING)	TATA spare parts
277847510157	ASSY.COVERING DISC-FOR RECEPACLE	TATA spare parts
277847510161	ASSY. TIE MEMBER (CRANKED)	TATA spare parts
277847510167	ASSY. BRACKET-HPR MTG.	TATA spare parts
277847518204	PACKING 10 THK.	TATA spare parts
277847518216	PACKING 4 THK	TATA spare parts
277847518217	PACKING 1 THK	TATA spare parts
277847518224	CLAMP-VENTING CLAMP ON BUS BODY	TATA spare parts
277847518225	SHEET-VENTING CLAMP ON BUS BODY	TATA spare parts
277847518254	SUPPORT(STONE GUARD)	TATA spare parts
277847518255	CNG CYL VALVE GUARD	TATA spare parts
277847520105	ASSY. CROSS MEMBER (CYL. MTG.)	TATA spare parts
277847520107	ASSY. PLATE(CYL. MOUNTING)	TATA spare parts
277847520108	ASSY. C.M. -FRONT RESTRAINT(ANGLE)	TATA spare parts
277847520109	ASSY. FRAME SUPPORT-FRONT REST. COMPLETE	TATA spare parts
277847520114	ASSY. FRAME COMP.( END RESTRAINT)	TATA spare parts
277847520125	ASSY. SUPPORT FOR RESTRAINT	TATA spare parts
277847520128	ASSY. TIE MEMBER(CRANKED)	TATA spare parts
277847600101	ASSY.HOSE WITH FITTINGS - 1	TATA spare parts
277847600103	HOSE FOR GAS ID 25.4MM X 47 INCH LONG	TATA spare parts

277847600190	THREE WAY VALVE 1/2 INCH NPTMX1/4 INCH O	TATA spare parts
277847600192	ASSY.CLAMP (FOR HP TUBE WITH PVC COAT	TATA spare parts
277847600199	THREE WAY VALVE	TATA spare parts
277847603301	BRACKET-FOR HP TUBE CLAMPING	TATA spare parts
277847603801	CAP-FOR VENTING	TATA spare parts
277847604301	HOSE CLIP	TATA spare parts
277847606801	1/4INCH NPT X 1/2INCH ODT MALE CONNECTOR	TATA spare parts
277847606802	1/2 ODT EQUAL TEE	TATA spare parts
277847606803	1/2 ODT BALL VALVE	TATA spare parts
277847606804	1/2ODT X 1/4BSP FEMALE BR UNEQUAL	TATA spare parts
277847606805	1/8 NPT X 1/2 ODT MALE CONNECTOR	TATA spare parts
277847606806	1/2 ODT UNION	TATA spare parts
277847606811	NUT 1/2	TATA spare parts
277847606812	BACK FERRULE - 1/2	TATA spare parts
277847606813	FRONT FERRULE - 1/2	TATA spare parts
277847606814	1/2ODT X M12 X 1 MALE CONNECTOR	TATA spare parts
277847606816	ADAPTOR (FOR RECEPTACLE) 1510CNG	TATA spare parts
277847606817	MALE RUN TEE 1510CNG	TATA spare parts
277847606819	ADAPTOR	TATA spare parts
277847606820	ELBOW	TATA spare parts
277847606823	NIPPLE	TATA spare parts
277847606824	TEE	TATA spare parts
277847606825	ELBOW MALE ADAPTOR	TATA spare parts
277847606834	PLUG 1/4 INCH OD SS	TATA spare parts
277847606835	MALE CONNECTOR 1/4INCH OD X 1/8 INCH	TATA spare parts
277847606836	BULK HEAD EQUAL TEE 1/4 INCH	TATA spare parts
277847606837	FEMALE ADAPTOR 1/4INCH OD X 1/4 INCH B	TATA spare parts
277847606838	PLUG 1/4INCH NPT (FOR BULL NOSE CONNECTO	TATA spare parts
277847606839	UNION 1/4 INCH OD	TATA spare parts
277847606840	1/4 INCH NPTX1/4 INCH ODT MALE CONNECT	TATA spare parts
277847606858	FRONT FERRULE 1/4 INCH	TATA spare parts
277847606862	COUPLING NUT 1/4 INCH	TATA spare parts
277847606864	MALE CONNECTOR 1/4IN.OD X 1/4IN.NPT	TATA spare parts
277847606866	UNION 1/4 INCH ODX1/4 INCH OD	TATA spare parts
277847606868	EQUAL TEE 1/4IN. OD	TATA spare parts
277847606884	FEMALE BRANCH TEE 1/4 INCH ODXM12X1	TATA spare parts
277847606885	STRAIGHT ADAPTOR (FOR LPR INLET)	TATA spare parts
277847606888	ELBOW HPR OUTLET BSIII	TATA spare parts
277847606897	ADAPTOR	TATA spare parts
277847606898	ELBOW 3WAY VALVE OUTLET	TATA spare parts
277847606899	HANDLE-PARKER 3WAYVALVE(8F-B8XS2-BN-SSP)	TATA spare parts
277847606908	HOSE-SOL. TO MANIFOLD	TATA spare parts
277847606922	NYLON TUBE	TATA spare parts
277847606923	NYLON TUBE	TATA spare parts
277847606924	HOSE-SOL.TO CARBURETOR	TATA spare parts
277847608212	L-BRACKET (HOSE CLAMPING)	TATA spare parts
277847608214	CLAMP (FOR VENTING)	TATA spare parts

277847608215	TOP & BOTTOM PLATE	TATA spare parts
277847609905	PVC SLEEVE 6.5 ID 8 OD.	TATA spare parts
27784760990590	PVC SLEEVE 1/4 INCH BS6-PH2	TATA spare parts
277847610103	ASSY HP GAS TUBE 1/4INCHO.D	TATA spare parts
277847610104	ASSY HP GAS TUBE 1/4INCHO.D	TATA spare parts
277847610105	ASSY HP GAS TUBE 1/4INCHO.D	TATA spare parts
277847610106	ASSY HP GAS TUBE 1/4 INCH O.D	TATA spare parts
277847610113	ASSY. BULL NOSE WITH EXCESS FLOW VALVE	TATA spare parts
277847610115	HOSE GAS SHUT OFF TO LP FILTER	TATA spare parts
277847610118	ASSY PIPE	TATA spare parts
277847610121	ASSY. HOSE-FOR VENTING	TATA spare parts
277847610122	3 WAY VALVE 1/2INCHNPTX1/2INCHODX1/4INCH	TATA spare parts
277847610124	HOSE ASSY- HPR VENTING	TATA spare parts
277847610125	HOSE LPR TO GAS SHUTOFF	TATA spare parts
277847610126	HOSE LPR TO GAS AIR MIXER CARBURATOR	TATA spare parts
277847610127	HOSE LP FILTER TO HPR	TATA spare parts
277847610130	ASSY TUBE 12 OD	TATA spare parts
277847610132	ASSY. TUBE 12 O.D.	TATA spare parts
277847610134	ASSY TUBE 22 OD	TATA spare parts
277847610135	ASSY PIPE	TATA spare parts
277847610136	ASSY. TUBE 22 OD.	TATA spare parts
277847610138	ASSY TUBE 1/4INCH OD WITH PVC SLEEVE	TATA spare parts
277847610140	ASSY.HOSE 1/2 INCH-HPR TO LPF	TATA spare parts
277847610141	ASSY.HP GAS TUBE 1/4INCHOD.	TATA spare parts
277847610142	ASSY HP GAS TUBE 1/4INCH O.D WITH PVC SL	TATA spare parts
277847610143	ASSY HP GAS TUBE 1/4INCH O.D WITH PVC SL	TATA spare parts
277847610144	ASSY HP GAS TUBE 1/4INCH O.D WITH PVC SL	TATA spare parts
277847610191	ASSY. SINGLE CLAMP WITH BRACKET	TATA spare parts
277847616803	MALE CONNECTOR-1/4INCHNPT X M18 X 1.5	TATA spare parts
277847616805	ASSY REDUCER	TATA spare parts
277847616806	EQUAL ELBOW L22 IS 9388 SS8451-8C	TATA spare parts
277847616807	FEM.CONNECT.1/4 INCHODX3/8 INCH NPT	TATA spare parts
277847616808	MALE BRANCH TEE	TATA spare parts
277847616815	END CONNECTOR	TATA spare parts
277847616820	MALE BRANCH TEE 1/4IN.NPT-1/4IN.ODT	TATA spare parts
277847616821	MALE CONNECTOR 1/2IN.NPTX1/4IN.ODT	TATA spare parts
277847616823	FEMALE CONNECTOR 3/8IN.NPT(F)X1/4IN.OD	TATA spare parts
277847616826	B. HEAD FEMALE CONN.-1/4IN.NPT X1/4IN.OD	TATA spare parts
277847616829	MALE BRANCH TEE 1/2IN.NPTX1/4IN.OD TUBE	TATA spare parts
277847616830	PORT CONNECTOR	TATA spare parts
277847616831	FEMALE TUBE ADAPTOR 1/4IN.NPTX1/4IN.OD	TATA spare parts
277847616833	LP FILTER OUT. CONN.	TATA spare parts
277847616845	MALE CONNECTOR 1/4 OD X M12 X 1.0RS T	TATA spare parts
277847616846	PLUG M12 X 1.0RS THREAD	TATA spare parts
277847616850	FEMALE BRANCH TEE 1/4IN NPT X1/4IN OD	TATA spare parts
277847616852	MALE CONNECTOR 1/4 OD (SSP) BS6	TATA spare parts
277847616864	MALE CONNECTOR 1/4 NPTX 1/4 OD SWG	TATA spare parts



277847617706	BLOCK-SINGLE CL	TATA spare parts
277847619901	PVC CORRUGATED SLEEVE	TATA spare parts
277847620115	ASSY. TUBE 12 OD	TATA spare parts
277847620116	ASSY. TUBE 12 OD	TATA spare parts
277847620118	ASSY VALVE-BURSTING DISC & FUSIBLE VALVE	TATA spare parts
277847620122	ASSY TUBE 12 OD	TATA spare parts
277847620123	ASSY TUBE 12 OD	TATA spare parts
277847700101	VALVE SHUTOFF	TATA spare parts
277847700102	LOW PRESSURE REGULATOR	TATA spare parts
277847700103	SOL. VAL. OVERSPEED	TATA spare parts
277847700105	GAS FILLING RECEPTICAL 1510CNG	TATA spare parts
277847700106	ASSY HIGH PRESSURE FILTER HOUSING 1510CN	TATA spare parts
277847700110	LP FILTER-COALESCE	TATA spare parts
277847700116	HIGH PRESSURE REGULATOR	TATA spare parts
277847700134	ASSY.HPR	TATA spare parts
277847700135	ASSY.HPR W/O CONNECTORS	TATA spare parts
277847700136	REPAIR KIT GAS SHUT OFF VALVE	TATA spare parts
277847700142	HP LINE PRESSURE GAUGE	TATA spare parts
277847700143	HIGH PRESSURE FILTER	TATA spare parts
277847700145	LOW PRESSURE FILTER	TATA spare parts
277847700146	LP LINE PRESSURE GAUGE	TATA spare parts
277847700149	VALVE SHUTOFF	TATA spare parts
277847700152	LP FILTER 1510 CNG	TATA spare parts
277847700159	AFC GSOV 1/2INCH NPT	TATA spare parts
277847700160	ASSY.MOUNTING BRACKET (FOR AFC GSOV)	TATA spare parts
277847700161	ASSY.MOUNTING BRACKET	TATA spare parts
277847700163	ASSY. BRACKET IGNITION COIL MOUNTING.	TATA spare parts
277847700165	ASSY. RECEPTACLE	TATA spare parts
277847706801	ADAPTOR	TATA spare parts
277847706807	CONNECTOR 7/8IN -14UNFX1/4IN NPT	TATA spare parts
277847706808	CONNECTOR 1/2IN -20UNFX1/4IN NPT	TATA spare parts
277847706809	CONNECTOR ST.PRIV CAP	TATA spare parts
277847706810	HYDROSTAT.RELIEF VALVE	TATA spare parts
277847706811	CONNECTOR PRV CAP TOP	TATA spare parts
277847706812	CONN. ST. 1/2IN NPT X 7/8IN UNF	TATA spare parts
277847706816	ADAPTOR	TATA spare parts
277847707702	O RING	TATA spare parts
277847707704	O RING	TATA spare parts
277847707710	O RING	TATA spare parts
277847707711	DIAPHRAM	TATA spare parts
277847708704	SPRING CONICAL	TATA spare parts
277847709927	COIL ELECTRICAL	TATA spare parts
277847709929	O RING	TATA spare parts
277847709931	LP FILTER CARTRIDGE	TATA spare parts
277849000105	ASSY.RETRO FITMENT KIT (HEAT SLD. & ELC)	TATA spare parts
277849100102	ASSY EXHAUST PIPE-I-81.2ODX1.6TH	TATA spare parts
277849100104	ASSY EXHAUST PIPE-II-81.2ODX1.6TH	TATA spare parts

277849100106	ASSY RUBBER HANGER	TATA spare parts
277849100112	ASSY HEAT SHIELD	TATA spare parts
277849100116	INTERMEDIATE PIPE	TATA spare parts
277849100117	ASSY TAIL PIPE-AT SILENCER OUTLET	TATA spare parts
277849100120	ASSY. EXHAUST PIPE - II	TATA spare parts
277849100123	ASSY. TAIL PIPE FOR ASSY. SILENCER	TATA spare parts
277849100124	ASSY. HEAT SHIELD	TATA spare parts
277849100129	ASSY.EXH.PIPE-I	TATA spare parts
277849100131	ASSY.SILENCER	TATA spare parts
277849100134	ASSY. SILENCER	TATA spare parts
277849100136	ASSY. TAIL PIPE	TATA spare parts
277849100139	ASSY. HEAT SHIELD SIDE	TATA spare parts
277849100140	ASSY. HEAT SHIELD UPPER	TATA spare parts
277849100141	ASSY. BRACKET HEAT SHIELD	TATA spare parts
277849104203	CLAMP 205.5 ID	TATA spare parts
277849104204	CLAMP 215.5 ID	TATA spare parts
277849104205	CLAMP (202.5 ID)	TATA spare parts
277849108203	CLAMP	TATA spare parts
277849108204	CLAMP-88ID	TATA spare parts
277849108212	CLAMP 77 DIA	TATA spare parts
277849108213	CLAMP (77-DIA) - II	TATA spare parts
277849208201	CLAMP	TATA spare parts
277849208214	CLAMP	TATA spare parts
277849208218	EXHAUST CLAMP	TATA spare parts
277854100120	ASSY.BRACKET	TATA spare parts
277854100127	ASSY EARTHING STRAP WITH MTG PLATE	TATA spare parts
277854100129	ASSY BATTERY CABLE (LINK) (70MM2) 305MM	TATA spare parts
277854100131	ASSY BATTERY CABLE +VE(70MM2)	TATA spare parts
277854100132	ASSY BATTERY CABLE +VE(70MM2)	TATA spare parts
277854100136	ASSY.BATT.CABLE LINK -70 MM SQ.- 305 LG.	TATA spare parts
277854100140	ASSY.EARTHING CHAIN WITH BKT.-LPO1510CGS	TATA spare parts
277854100142	ASSY.EARTHING CHAIN WITH BRACKET	TATA spare parts
277854100143	ASSY BATTERY CARRIER(2X12V 150AH)	TATA spare parts
277854108214	CLAMP TOP	TATA spare parts
277854108220	BRACKET (BATT.CABLE MTG)	TATA spare parts
277854108226	MOUNTING BRACKET (FOR CHAIN) BS6	TATA spare parts
277854108227	END PLATE (FOR CHAIN) - LPO 1510 CGS BS6	TATA spare parts
277854108601	SPACER (FOR EARTH STRAP MTG.)	TATA spare parts
277854109901	BATTERY 6V 150AH	TATA spare parts
277854109909	CHAIN - LPO 1510 CGS BS6	TATA spare parts
277854110101	ASSY.BATT.CABLE -VE	TATA spare parts
277854110105	ASSY BATTERY CABLE -VE(70MM2)	TATA spare parts
277854110106	ASSY BATTERY CABLE -VE(70MM2)	TATA spare parts
277854200101	KIT CNG INDICATOR	TATA spare parts
277854200104	CNG INDICATOR KIT 1510CNG	TATA spare parts
277854200107	ASSY KIT ROAD SPEED LIMITER 24V	TATA spare parts
277854200109	TEMP INDICATOR CATCON TERMINALS 1510CNG	TATA spare parts

277854200110	TEMP SENSOR 1510CNG -ED	TATA spare parts
277854200111	W/HARNESS TEMP INDICATOR	TATA spare parts
277854200113	CNG.INDICATOR KIT	TATA spare parts
277854200121	TEMPE.INDICATOR 12V/24V-3PIN	TATA spare parts
277854200122	DC-DC CONVERTER	TATA spare parts
277854200123	ASSY.BRACKET (HORN MTG.)	TATA spare parts
277854200126	TEMP.SENSOR (202 DIA)	TATA spare parts
277854200127	ASSY.MTG.BKT.(DC-DC CONVERTER)	TATA spare parts
277854200129	ASSY.BKT-FUSE/RELAY BOX MTG-1510CGS-BSII	TATA spare parts
277854200130	ASSY.MTG.CLAMP(FOR RUTER)LPO1510CGS-BSII	TATA spare parts
277854200131	IGN.COIL PARTITION	TATA spare parts
277854200132	ASSY.BRACKET(CLUSTER EXTN)-LPO1510CNG	TATA spare parts
277854200134	ASSY.SUPPORT(CATCON TEMP.IND.MTG.BKT)CNG	TATA spare parts
277854200135	ASSY.MTG.BKT(ABS-ECU & DIG.CONN)-1510CNG	TATA spare parts
277854200136	BASE PLATE	TATA spare parts
277854200140	INST CLUSTER 0.88 (552)LPO1510 CNG	TATA spare parts
277854200141	TEMPE.INDICATOR CATCON 12V/24V-3PIN-ED	TATA spare parts
277854206301	H.T.CABLES RUTER-LPO1510CGS-BSII-RETRO	TATA spare parts
277854206302	RUTER COVER-LPO1510CGS-BSII-DTC RETRO	TATA spare parts
277854206303	SOCKET CAP WITH RETAINER RING-24V.	TATA spare parts
277854208211	IGN.COIL PARTITION BKT.	TATA spare parts
277854209906	ELECTRONIC CONTROL UNIT	TATA spare parts
277854209907	ELECTRIC ACTUATOR 24V	TATA spare parts
277854209908	SPEED SENSOR	TATA spare parts
277854209909	BOWDEN CABLE	TATA spare parts
277854209914	H.T.COIL	TATA spare parts
277854209916	ENGINE POSITION SENSOR	TATA spare parts
277854209917	MAGNETIC PICK UP	TATA spare parts
277854209918	SPEEDOMETER-0.9 RATIO-W/BLA.TER	TATA spare parts
277854209919	H.T.CABLE - 200MM LONG	TATA spare parts
277854209922	FUSE HOLDER	TATA spare parts
277854209923	FUSE 10A	TATA spare parts
277854209924	TERMINAL	TATA spare parts
277854209925	DISTRIBUTOR CAP	TATA spare parts
277854400104	INSPECTION LAMP-24V	TATA spare parts
277854500101	ASSY.BRACKET (FOR STARTER RELAY MTG.)	TATA spare parts
277854506901	PIANO SWITCH-CHANGE OVER	TATA spare parts
277854506902	PIANO KEY SWITCH-CHANGE OVER	TATA spare parts
277854506903	PIANO KEY SWITCH-CHANGE OVER	TATA spare parts
277854600101	WIRING HARNESS MAIN-LPO 1510 CGS	TATA spare parts
277854600102	W/H TAIL -LPO1520 CGS-OFFER	TATA spare parts
277854600103	WIRING HARNESS ENGINE 1510 CNG BUS	TATA spare parts
277854600116	EARTHING CABLE SET	TATA spare parts
277854600117	EARTHING CABLE SET	TATA spare parts
277854600118	EARTHING CABLE SET	TATA spare parts
277854600125	W/H.CYLINDER EARTHING	TATA spare parts
277854600127	W/H.DC-DC CONVERTER	TATA spare parts

277854600130	PIG TAIL FOR CONDENSATE SEPARATOR - CNG	TATA spare parts
277854601601	W/H.SLOW/FAST FILLING RECEPTACLE	TATA spare parts
277854601606	W/H.TAIL-W/COND.SEP.LPO 1510 CNG	TATA spare parts
277854601609	W/H.MAIN-LPO1510CGS-BSII-OFFER-DTC RETRO	TATA spare parts
277854601610	W/H.INST-LPO1510CGS-BSII-OFFER-DTC RETRO	TATA spare parts
277854601611	W/H.ENGINE-LPO1510CGS-BSII	TATA spare parts
277854601614	WIRING HARNESS.MAIN-LPO 1510 CGS BS-III	TATA spare parts
277854601616	W/H.ENGINE	TATA spare parts
277854601617	W/H.TAIL	TATA spare parts
277854601624	W/H.SLOW FILLING RECEPTACLE	TATA spare parts
277854606301	BASE PLATE TERMINAL STRIP	TATA spare parts
277854608202	STRIP-0.8 X 150 X 5MTRS.	TATA spare parts
277854609902	WIRING HARNESS	TATA spare parts
277854609904	RUBBER CAP	TATA spare parts
277854609906	PVC TUBE(FIRE RETARDANT-FOR HT CABLE)	TATA spare parts
277854620102	WIRING HARNESS CONSOLE 1510 CNG BUS	TATA spare parts
277854620103	W/H ENGINE -LPO 1510 CGS	TATA spare parts
277854620104	WIRING HARNESS MAIN-LPO 1510 CGS	TATA spare parts
277854620105	WIRING HARNESS CONSOLE-LPO 1510 CGS	TATA spare parts
277854660101	WIRING HARNESS MAIN -LPO1510CGS	TATA spare parts
277854660102	W/H TAIL - LPO1510 CGS	TATA spare parts
277854660103	W/H ENGINE - LPO1510 CGS	TATA spare parts
277854660104	WIRING HARNESS INSTUMENT -LPO1510CGS	TATA spare parts
277854660116	W/H INSTRUMENT CONSOLE	TATA spare parts
277854660119	W/H MAIN-LPO 1510 CNG	TATA spare parts
277854660120	W/H TAIL-LPO 1510/55 CNG	TATA spare parts
277854660121	W/H ENGINE-LPO 1510 CNG	TATA spare parts
277854660122	W/H CNG PR.GAUGE LPO1510 CNG	TATA spare parts
277854660123	W/H CYLINDER EARTHING-1510CNG	TATA spare parts
277854660125	W/H ENGINE	TATA spare parts
277854660126	W/H.INSTRUMENT PANEL	TATA spare parts
277854660127	W/H MAIN - BS III - LPO 1510 CGS	TATA spare parts
277854660128	W/H ENGINE-BS III-LPO 1510 CGS	TATA spare parts
277854660129	W/H MAXI FUSE-BS III-LPO 1510 CGS	TATA spare parts
277854660132	W/H.MAIN-BSIII-LPO1510CGS	TATA spare parts
277854660135	W/H.CYLINDER EARTHING-LPO1510CNG	TATA spare parts
277854660136	W/H.INSTRUMENT-LPO 1510 CNG	TATA spare parts
277854660137	W/H.ENGINE-LPO 1510 CNG	TATA spare parts
277854660138	W/H.PRESSURE GAUGE-LPO 1510 CNG	TATA spare parts
277854660140	W/H.MAIN-LPO 1510 CNG	TATA spare parts
277854660141	W/H.MAXI FUSE-LPO 1510 CNG	TATA spare parts
277860100101	ASSY COWL W/FITMENT LPO1510	TATA spare parts
277860100102	ASSY COWL BARE 1510CNG	TATA spare parts
277860100112	ASSY BRKT (POWER STRG. TANK MTG.)	TATA spare parts
277881100111	KIT FOR INSULATING PIECE	TATA spare parts
277881108201	ASSY CLOSING PIECE LH	TATA spare parts
277881108202	ASSY CLOSING PIECE RH	TATA spare parts

277881108203	ASSY CLOSING PIECE TOP	TATA spare parts
277881800101	ASSY.TATA 1510 CUMMINSMASCOT	TATA spare parts
277881900108	ASSY. ENGINE SHIELDING COMPLETE LH	TATA spare parts
277888700103	ASSY ENGINE HOOD COMP RHD	TATA spare parts
277888700105	ASSY. TOGGLE CLAMP (ENGINE HOOD)	TATA spare parts
277888700107	ASSY CLAMPING PLATE-E/HOOD INSULATION	TATA spare parts
277888700108	INSULATIONASSYENGINEHOOD BS6	TATA spare parts
277888700112	ASSY ENGINE HOOD COMP.WITH INSULATION	TATA spare parts
277888707701	SEALING RUBBER ENGINE HOOD	TATA spare parts
277888707706	SEALING RUBBER	TATA spare parts
277899700102	ASSY VENT GRILLE-BUS SKIRT PANEL	TATA spare parts
277899700103	ASSY VENT GRILLE-BUS SKIRT PANEL	TATA spare parts
277899708201	BACK PLATE MEDIUM 1510CNG	TATA spare parts
277899708202	BACK PLATE LONG 1510CNG	TATA spare parts
277899708203	BACK PLATE SHORT 1510CNG	TATA spare parts
277915100103	ASSY JUNCTION BOX (BASE & COVER)	TATA spare parts
277915100104	ASSY.SPEEDOCABLE CLAMP	TATA spare parts
277915100105	ASSY.BASE WITH STUDS-(JUNCT.BOX)	TATA spare parts
277915106302	COVER JUNCTION BOX (STARTER BOX)	TATA spare parts
277930108201	ACCELERATOR CABLE HOLDING BRACKET	TATA spare parts
277930108204	BRACKET (FOR ACCELERATOR CABLE MOUNTING)	TATA spare parts
277932103206	STRUT MOUNTING PIN ( ECCENTRIC)	TATA spare parts
277932807705	BEARING BLOCK (ANTI ROLL BAR-28 DIA.)	TATA spare parts
277935603701	HUB CUM BRAKE DRUM REAR (200 DIA)	TATA spare parts
277942300124	KIT SHOE HOLD DOWN	TATA spare parts
277942300128	STRUT AND QUADRANT	TATA spare parts
277942300134	MINOR KIT-WHEEL CYLINDER ASSY-KBX 497	TATA spare parts
277942300135	MAJOR KIT-WHEEL CYLINDER ASSY-KBX 496	TATA spare parts
277942307501	GROMMET	TATA spare parts
277942308002	BLEED SCREW	TATA spare parts
277942308701	SPRING SHOE RETURN	TATA spare parts
277942308702	SPRING SHOE RETURN	TATA spare parts
277942308703	SPRING STRUT RETURN	TATA spare parts
277942704203	R CLAMP (PARKING BRAKE CABLE)	TATA spare parts
277943100105	ASSY PCRV - (24/2.5)	TATA spare parts
277943100107	PCRV ASSY - -(24/2.5) -ORANGE	TATA spare parts
277943100150	ASSY PCRV - (24/2.5)	TATA spare parts
277943104302	LOCKING RING	TATA spare parts
277943106503	HEX NUT	TATA spare parts
277943107101	STOP PISTON	TATA spare parts
277943107502	SEAL CHECK VALVE	TATA spare parts
277943107709	GASKET	TATA spare parts
277943109205	SPRING WASHER	TATA spare parts
277946600107	ASSY POWER STEERING PUMP	TATA spare parts
277947604201	SPRING CLIP (10)	TATA spare parts
277949200110	ASSY RUBBER HANGER	TATA spare parts
277954200118	KIT SOCKET-W/ILLUMINATING RING	TATA spare parts

277954209911	HEATED REAR WINDOW CONTROLLER	TATA spare parts
277954209918	HIGH TONE HORN W/O RIS CAP	TATA spare parts
277954209919	TEMPERATURE SENSOR-M16	TATA spare parts
277954209920	TEMPERATURE SENSOR-M16	TATA spare parts
277954209921	TEMPERATURE SENSOR	TATA spare parts
277954209923	TEMPERATURE SENSOR -PRICOL	TATA spare parts
277954509913	HAND BRAKE SWITCH-INDIGO	TATA spare parts
277954608206	CLIP-(W/H ENG. CLAMPING)	TATA spare parts
277954608207	BRACKET-(W/H ENG. CLAMPING)	TATA spare parts
277958901801	SPANNER - OIL FILTER (475 TC ENGINE)	TATA spare parts
277958903301	DRIFT	TATA spare parts
277958904601	PULLER/4 SPOKES STRG WHEEL/ACE1T,IND,CO	TATA spare parts
277969106369	PLUG (GRAB HANDLE) LUX B-001	TATA spare parts
277969500101	ASSY GRAB HANDLE LUX	TATA spare parts
277969506305	PLASTIC BUTTON GRAB HANDLE LUX B-001	TATA spare parts
277981103801	MIRROR MOUNTING BASE	TATA spare parts
277983400116	ASSY.TRINARY PRESSURE SWITCH	TATA spare parts
277988706305	HOOD STRIP	TATA spare parts
277C88	PRESSURE SPRING KIT	TATA spare parts
278003999981	FLY WHEEL BRG	TATA spare parts
278029103301	BRACKET BS6	TATA spare parts
278032100101	ASSY. FRONT SPRING LH	TATA spare parts
278032100102	ASSY. FIRST LEAF WITH CLIP	TATA spare parts
278032100104	ASSY. FRONT SPRING RH	TATA spare parts
278032100106	ASSY. FRONT SPRING - CO - DRIVER SIDE	TATA spare parts
278032100107	ASSY. FIRST LEAF WITH CLIP	TATA spare parts
278032100108	ASSY. SECOND LEAF WITH CLIPS	TATA spare parts
278032100109	ASSY. FRONT SPRING - DRIVER SIDE	TATA spare parts
278032103202	CENTER BOLT(M12X210)	TATA spare parts
278032103203	CENTER BOLT	TATA spare parts
278032103204	CENTER BOLT	TATA spare parts
278032103701	FRONT SPRING BKT.RH REAR & L.H. FRONT	TATA spare parts
278032103702	FRONT SPRING BKT. RH FRONT & LH REAR	TATA spare parts
278032103703	FRONT SPRING HANGERBKT REAR & LH FRT	TATA spare parts
278032103704	FRONT SPRING HANGERBKT FRT & LH REAR	TATA spare parts
278032104201	U CLAMP (M20X1.5-325 LENGTH)	TATA spare parts
278032104202	AUX. CLIP	TATA spare parts
278032107103	THIRD LEAF	TATA spare parts
278032107104	FOURTH LEAF	TATA spare parts
278032107105	FIFTH LEAF	TATA spare parts
278032107106	SIXTH LEAF	TATA spare parts
278032107107	SEVENTH LEAF	TATA spare parts
278032107108	EIGHTH LEAF	TATA spare parts
278032107109	NINENTH LEAF	TATA spare parts
278032107110	TENTH LEAF	TATA spare parts
278032107111	ELEVENTH LEAF	TATA spare parts
278032107112	TWELTH LEAF	TATA spare parts

278032107113	SPACER	TATA spare parts
278032107114	SPACER (180X70X15 THK.)	TATA spare parts
278032107117	THIRD LEAF	TATA spare parts
278032107118	FOURTH LEAF	TATA spare parts
278032107119	FIFTH LEAF	TATA spare parts
278032107120	SPRING CLIP (WEWELLER)	TATA spare parts
278032107121	CASTER PLATE	TATA spare parts
278032107122	SIXTH LEAF	TATA spare parts
278032107123	SEVENTH LEAF	TATA spare parts
278032107124	EIGHTH LEAF	TATA spare parts
278032107125	NINENTH LEAF	TATA spare parts
278032108601	SPACER	TATA spare parts
278032400101	ASSY. REAR SPRING	TATA spare parts
278032400104	ASSY.REAR PNEUMATIC SUSPENSION	TATA spare parts
278032400111	COMPOUND LINK BKT - LH	TATA spare parts
278032400112	COMPOUND LINK BKT -RH	TATA spare parts
278032400114	ASSY. AIR SPRING REAR BS2/3/4	TATA spare parts
278032400123	FRONT AIR SPRING CROSS MEMBER	TATA spare parts
278032403307	RADIUS ROD AXLE BKT	TATA spare parts
278032404201	U BOLT M24X1.5X378MM	TATA spare parts
278032404801	COWHORN DOWEL	TATA spare parts
278032406701	SPLIT PIN	TATA spare parts
278032407122	SPRINGCLIP BS6	TATA spare parts
278032500101	ASSY. BUMP STOPPER	TATA spare parts
278032600102	ASSY. SHOCK ABSORBER REAR	TATA spare parts
278032600103	ASSY. REAR SHOCK ABSORBER BS2/3/4	TATA spare parts
278042100103	BRAKE DISC-VENTILATED (434X45) BS3/4	TATA spare parts
278042100104	BRAKE ASSY. ELS	TATA spare parts
278042100105	BRAKE ASSY. ELS	TATA spare parts
278042100106	KIT-PAD ( DISC BRAKE) BS3/4	TATA spare parts
278042100107	KIT PAD RETAINER-DISC BRAKE	TATA spare parts
278042100108	KIT-ADJUSTER STEM CAP-DISC BRK.	TATA spare parts
278042100109	KIT-PISTON EXCLUDER-DISC BRK.	TATA spare parts
278042100110	KIT-GUIDE SLEEVE EXCLUDER-DISC BRAKE	TATA spare parts
278042100111	KIT-GUIDE SLEEVE-DISC BRAKE	TATA spare parts
278042100112	KIT-SERVICE HOUSING-LH(DISC BRK)	TATA spare parts
278042100113	KIT-SERVICE HOUSING-RH(DISC BRK)	TATA spare parts
278042100114	KIT-BRIDGE (DISC BRAKE)	TATA spare parts
278042100115	KIT-CARRIER (DISC BRAKE)	TATA spare parts
278042100116	AIR DISC BRAKE-LH	TATA spare parts
278042100117	AIR DISC BRAKE-RH	TATA spare parts
278042100118	KIT-PWWI (DISC BRAKE)	TATA spare parts
278042300106	BRAKE ASSY REAR LH WT DUST COVER	TATA spare parts
278042300107	BRAKE ASSY REAR RH WT DUST COVER	TATA spare parts
278042900108	TUBE AIR DRYER TO S.P.V.	TATA spare parts
278042900112	TUBE FRONT AIR TANK TO D.T.V. PORT 12	TATA spare parts
278042900113	TUBE TEE TO FRONT BRAKE CHAMBER RH	TATA spare parts

278042900114	TUBE TEE TO FRONT BRAKE CHAMBER LH	TATA spare parts
278042900116	TUBE REAR AIR TANK TO D.T.V. PORT 11	TATA spare parts
278042900117	TUBE D.T.V. PORT 21 TO HOSE ON REAR AXLE	TATA spare parts
278042900120	TUBE H.B.V. TO HOSE ON REAR AXLE (PART I	TATA spare parts
278042900121	TUBE H.B.V. TO HOSE ON REAR AXLE (PART I	TATA spare parts
278042900122	TUBE S.P.V. PORT 23 TO HAND BRAKE VALVE(	TATA spare parts
278042900124	TUBE S.P.V. PORT 24 TO EXHAUST BRAKE CYL	TATA spare parts
278042900127	NYLON PIPE SET-1613	TATA spare parts
278042900143	PIPE AIR COMPRESSOR TO AIR DRYER (PART I	TATA spare parts
278042900145	ASSY.NYLON PIPE SET COMPLETE 1613TC	TATA spare parts
278042900150	ASSY NYLON PIPE - PRESSURE GAUGES	TATA spare parts
278042900151	TUBE AIR DRYER TO PURGE TANK	TATA spare parts
278042900152	TUBE AIR DRYER TO S.P.V.	TATA spare parts
278042900153	TUBE FRONT AIR TANK TO D.T.V. PORT 12	TATA spare parts
278042900154	TUBE D.T.V. PORT 22 TO FRONT BRAKE	TATA spare parts
278042900155	TUBE TEE TO FRONT BRAKE CHAMBER RH	TATA spare parts
278042900156	TUBE TEE TO FRONT BRAKE CHAMBER LH	TATA spare parts
278042900157	TUBE REAR AIR TANK TO D.T.V. PORT 11	TATA spare parts
278042900158	TUBE D.T.V. PART 21 TO HOSE ON REAR AXLE	TATA spare parts
278042900159	TUBE S.P.V. PORT 23 TO HAND BRAKE VALVE	TATA spare parts
278042900160	TUBE H.B.V. TO HOSE ON REAR AXLE	TATA spare parts
278042900161	TUBE S.P.V. PORT 24 TO EXHAUST BRAKE CYL	TATA spare parts
278042900162	TUBE S.P.V. PORT 12 TO AIR PRESSURE GAUG	TATA spare parts
278042900163	TUBE S.P.V. PORT 11 TO AIR PRESSURE GAUG	TATA spare parts
278042900184	ASSY.NYLON PIPES[BRK]SET COWL-AIRPRGAUGE	TATA spare parts
278042903302	BRACKET	TATA spare parts
278043200101	SUB ASSY.AIR TANKS (WITH SUPPORT & STRAP	TATA spare parts
278054200102	ASSY KIT WATER-IN-FUEL UNIT 12V FLD	TATA spare parts
278054200104	ASSY.SPEEDOCABLE JIS 3600 LG OFFER	TATA spare parts
278054200105	ASSY.SPEEDOCABLE JIS 3600 LG	TATA spare parts
278054200106	ASSY.SPEEDOCABLE JIS 3600 LG	TATA spare parts
278054200107	ASSYS.SEEDOCABLE JIS 3600 LG	TATA spare parts
278054200108	ASSY BRACKET (HORN MTG)	TATA spare parts
278054200124	INSTRUMENT CLUSTER ASSY	TATA spare parts
278054200126	INSTRUMENT CLUSTER ASSY	TATA spare parts
278054200127	ASSY. INSTRUMENT CLUSTER BS4	TATA spare parts
278054200134	TEMP GAUGE AP(RE)GAUGE ASSY GAUGE	TATA spare parts
278054200135	FUEL GAUGE AP(RE)GAUGE ASSY GAUGE	TATA spare parts
278054206301	COVER-FOR RELAY AND FUSE BOX MTG	TATA spare parts
278054209905	SPEEDOCABLE(JIS)3600 LG.	TATA spare parts
278054209906	SPEEDOMETER (1:0.9)(BACKLIT)12V	TATA spare parts
278054209907	R.P.M.METER 12V-BACKLIT	TATA spare parts
278054209908	R.P.M.METER (12V) BACKLIT	TATA spare parts
278054209909	R.P.M.METER (12V) BACKLIT OFFER	TATA spare parts
278054209911	WATER-IN-FUEL IND.UNIT 12V/24V	TATA spare parts
278054209912	SPEEDOMETER (1:0.9)(BACKLIT)12V	TATA spare parts
278054209913	SPEEDOMETER (1:0.9)(BACKLIT)12V-	TATA spare parts



278054209915	R.P.M.METER 12V (BACKLIT)	TATA spare parts
278054209916	R.P.M.METER 12V	TATA spare parts
278054209918	INSTRUMENT CLUSTER (1:0.88)	TATA spare parts
278054209924	ELCTRO.SPEED SENSOR 12/24V(8 PULSES)-II	TATA spare parts
278054209925	INSTRUMENT CLUSTER(12V W/HOURMTR TLT)	TATA spare parts
278054209934	INST.CLUSTER(ELECT)(1:0.88)	TATA spare parts
278054209936	INST.CLUSTER(ELECT)(1:0.88)	TATA spare parts
278054209938	SPEED SENSOR 12V/24V (8 PULSES) BS1-4	TATA spare parts
278054209938AE	SPEED SENSOR 12V/24V (8 PULSES)	TATA spare parts
278054209971	BULB (24V)	TATA spare parts
278054209972	BULB 12V	TATA spare parts
278054240108	INSTRUMENT CLUSTER ASSY	TATA spare parts
278054240109	INSTRUMENT CLUSTER ASSY	TATA spare parts
278054240114	INSTRUMENT CLUSTER (24V)	TATA spare parts
278054240116	INSTRUMENT CLUSTER (24V)(41/6)W/HM	TATA spare parts
278054240119	INSTRUMENT CLUSTER 24V (41/7)W/HM	TATA spare parts
278054240121	INSTRUMENT CLUSTER 24V (41/7)W/HM	TATA spare parts
278054240122	ASSY. INSTRUMENT CLUSTER BS3/4	TATA spare parts
278054240124	ASSY. INSTRUMENT CLUSTER BS3/4	TATA spare parts
278054240131	INSTRUMENT CLUSTER ASSY	TATA spare parts
278054240139	INSTRUMENT CLUSTER ASSY	TATA spare parts
278054240141	INST. CLUSTER 24V(614HZ)	TATA spare parts
278054240141AE	INST. CLSTR 24V(614HZ)-1628-1828	TATA spare parts
278054240142	INST.CLUSTER-24V(41/7 438)WITH HM	TATA spare parts
278054240148	INSTRUMENT CLUSTER ASSY	TATA spare parts
278054240165	INSTRUMENT CLUSTER ASSY	TATA spare parts
278054240166	INSTRUMENT CLUSTER ASSY	TATA spare parts
278054240169	INSTRUMENT CLUSTER ASSY	TATA spare parts
278054240199	ASSY. INSTRUMENT CLUSTER BS4	TATA spare parts
278054249904	INSTRUMENT CLUSTER ASSY	TATA spare parts
278054300101	OLD fleetman scrap- N	TATA spare parts
278054300102	Assy. Bracket GPS mounting	TATA spare parts
278054306301	GPS cover for MM telematics unit	TATA spare parts
278054400105	ASSY INDICATOR LAMP-LOW OIL PR	TATA spare parts
278054400108	ASSY LAMP-WARNING INDICATOR	TATA spare parts
278054400109	ASSY WARNING LAMP OFFER 12V 7	TATA spare parts
278054400110	ASSY WARNING LAMP OFFER 12V 7	TATA spare parts
278054400115	H/L W/MOT 12V LH-RHD CLEAR -1.8%	TATA spare parts
278054400116	H/L W/MOT 12V RH-RHD CLEAR -1.8%	TATA spare parts
278054400117	ASSY MTG BRACKET(BEEPER & WIF CONTROLLER)	TATA spare parts
278054500102	ASSY.COMBI SW.RHD W/HORN SW.ON STALK	TATA spare parts
278054500103	ASSY.COMBI.SW.RHD W/HORN SW.ON STALK	TATA spare parts
278054500104	ASSY.COMBI SW.RHD W/HORN SW.ON STALK	TATA spare parts
278054500105	ASSY. COMBI SWITCH (W/HORN SW) BS1/2/3/4	TATA spare parts
278054501627	KNOB FACIA SWITCH	TATA spare parts
278054501634	COMBINATION SWITCH RH BS6	TATA spare parts
278054504902	COMBINATION SWITCH RH	TATA spare parts

278054504903	COMBINATION SWITCH RH	TATA spare parts
278054506301	CARRIER PLATE-FACIA SW(16 NOS)	TATA spare parts
278054506302	CARRIER PLATE-FACIA SW(12 NOS.)	TATA spare parts
278054506901	PIANO KEY SWITCH	TATA spare parts
278054506909	COMBI SWITCH TWO LEVER(470 STG) BS1-4	TATA spare parts
278054509975	WIPER STALK LEVER BS6	TATA spare parts
278054509976	SWITCH EXHAUST BRAKE	TATA spare parts
278054509977	SWITCH ABS DIAGNOSTIC	TATA spare parts
278054509978	FRONT FOG LAMP SWITCH	TATA spare parts
278054509988	ENGINE LAMP SWITCH	TATA spare parts
278054509989	BATTERY CUT OFF ELECTRICAL SWITCH	TATA spare parts
278054509996	BODY COMBINATION SWITCH BS6	TATA spare parts
278054509997	WIPER STALK LEVER BS6	TATA spare parts
278054509999	HAZARD WARNING SWITCH	TATA spare parts
278054519901	SWITCH HEADLAMP LEVELLING SWITCH (12V)	TATA spare parts
278054519903	LIGHT & TURN MODULE COMBI SWITCH BS6	TATA spare parts
278054519904	BODY COMBINATION SWITCH BS6	TATA spare parts
278054519906	LIGHT & TURN MODULE COMBI SWITCH BS6	TATA spare parts
278054600101	WIRING HARNESS MAIN	TATA spare parts
278054600103	WIRING HARNESS PANEL LAMPS	TATA spare parts
278054600104	WIRING HARNESS GAUGE EARTHING	TATA spare parts
278054600105	WIRING HARNESS FRONT TO TAIL (LPT1613 C/	TATA spare parts
278054600106	WIRING HARNESS FRONT TO TAIL (LPT1613 C/	TATA spare parts
278054600109	W/H MAIN (LPT1613TC)12V	TATA spare parts
278054600110	W/H MAIN (LPT1613TC TILT SLPR CAB)OFFER	TATA spare parts
278054600112	W/H ENGINE (LPT1613TC TILT) OFFER	TATA spare parts
278054600113	W/H ROOF(LPT1613TC-709TLT SLPR CAB)OFFER	TATA spare parts
278054600114	W/H CONSOLE (LPT1613TC TILT) OFFER	TATA spare parts
278054600115	W/H PARK BR.SW.(LPT1613TC TILT CAB)OFFER	TATA spare parts
278054600121	W/H ENGINE(LPT1613TC-W/709TLTE-II	TATA spare parts
278054600125	W/H ENGINE LPT1613 BS-II LPFACE	TATA spare parts
278054600130	W/H MAIN (LPT1613/2515TC SLPR TILT CAB)	TATA spare parts
278054600132	Pigtail for telematics after market	TATA spare parts
278054620101	W/HARNESS MAIN LPT1613TC 12V	TATA spare parts
278054620102	W/HARNESS TAIL LPT 1613/42 TC	TATA spare parts
278054620103	W/HARNESS TAIL LPT 1613/48 TC	TATA spare parts
278054620104	W/H MAIN-SE 1613TC	TATA spare parts
278054620105	W/H TAIL-SE 1613TC/42	TATA spare parts
278054620106	WIRING HARNESS	TATA spare parts
278054620107	WIRING HARNESS MAIN	TATA spare parts
278054620111	W/H MAIN (LPT1613TC)12V	TATA spare parts
278054620112	W/H MAIN-W/709 TY TLT NS CAB	TATA spare parts
278054620114	W/H ENGINE(709 TY TILT CAB-HCV	TATA spare parts
278054620115	W/H ROOF (LPT 1613TC)SLPR CAB (TILT	TATA spare parts
278054620116	W/H CONSOLE 709 TYPE TILT CAB-HCV	TATA spare parts
278054620118	W/H PARKING BRK.SW.(709TY T/CAB HCV	TATA spare parts
278054620125	W/H MAIN-W/709 TY TLT SLPR CAB	TATA spare parts

278054620127	WIRING HARNESS CONSOLE (LPT 2515 / 1613	TATA spare parts
278054620128	W/H TAIL-LPT1613TC/42_TLT_CMVR	TATA spare parts
278054620129	W/H MAIN (LPT1613/2515TC SLPR TILT CAB)	TATA spare parts
278054620131	W/H ENGINE(LPT1613TC-W/709TLTE-II	TATA spare parts
278054620134	WIRING HARNESS TAIL	TATA spare parts
278054620136	W/H MAIN LPT1613TC BS-I EXH.BR.TLT	TATA spare parts
278054620148	W/H ENGINE LPT1613TC BS-II LPFACE	TATA spare parts
278054620149	W/H MAIN(LPT1613/2515TC II CAB ABS)	TATA spare parts
278054660101	WIRING HARNESS MAIN	TATA spare parts
278054660102	WIRING HARNESS ENGINE	TATA spare parts
278054660103	WIRING HARNESS PANEL LAMPS	TATA spare parts
278054660104	WIRING HARNESS GAUGE EARTHING	TATA spare parts
278054660105	WIRING HARNESS FRONT TO TAIL (LPT1613 C/	TATA spare parts
278054660106	WIRING HARNESS FRONT TO TAIL (LPT1613 C/	TATA spare parts
278054660109	W/H MAIN (LPT1613TC)12V	TATA spare parts
278054660111	WIRING HARNESS MAIN-LPT1613TC SLPR CAB	TATA spare parts
278054660113	W/H ENGINE-LPT1613TC TILT	TATA spare parts
278054660114	W/H ROOF-LPT1613TC TILT SLPR.CAB	TATA spare parts
278054660115	W/H CONSOLE-LPT1613TC TILT	TATA spare parts
278054660116	W/H PARK BR.SW. LPT1613TC 709TILT	TATA spare parts
278054660120	W/H MAIN (LPT1613/2515TC SLPR TILT CAB)	TATA spare parts
278054660121	W/H ENGINE LPT1613TC BS-II LPFACE	TATA spare parts
278054660148	W/H TAIL LPT1613TC/42 BS-I&II W/EX	TATA spare parts
278054660149	WIRING HARNESS TAIL LPT1613TC.48 BS-I&II	TATA spare parts
278054660150	W/H TAIL	TATA spare parts
278054680101	W/H ENGINE(LPT2515TC BS-II LP 12V)	TATA spare parts
278082400101	ASSY. WIPER BLADE BS1/2/3/4	TATA spare parts
278082400101AE	WIPER BLADES 2523 715	TATA spare parts
278133000101	ASSLY.FRT. AXLE WITH ABS BRK 3516	TATA spare parts
278133000104	ASSY. FRONT AXLE COMPLETE WITH BRAKES	TATA spare parts
278133000105	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
278133000107	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
278133000108	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
278149208201	CLAMP	TATA spare parts
278149208203	CLAMP	TATA spare parts
278149208204	CLAMP	TATA spare parts
278224200101	ASSY. ENGINE MOUNTING BRACKET REAR	TATA spare parts
278224200103	ASSY. BRACKET-LH (ENGINE MTG. REAR)	TATA spare parts
278224200104	ASSY. BRACKET-RH (ENGINE MTG. REAR)	TATA spare parts
278226010101	ASSY GBS50 GEAR BOX W/GEAR SHIFT LINKAGE	TATA spare parts
278226800101	TURNING TUBE WITH BALL JOINT 2515 TC	TATA spare parts
278226800102	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
278226800104	ASSY LINK ROD LPT2515TC	TATA spare parts
278226800107	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
278226800109	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
278226809901	GEAR SHIFT LEVER	TATA spare parts
278226810101	ASSY BRACKET-TO CLAMP AIR INTAKE PIPE	TATA spare parts

278229100101	ASSY CONTROLS COMPLETE	TATA spare parts
278229100102	ASSY. CONTROL MOUNTING BRACKET WITH TUBE	TATA spare parts
278229100103	ASSY. CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
278229100105	ASSY. CONNECTING LINE (10 O.D.) LPT2515	TATA spare parts
278229100110	CLUTCH MASTER CYL. 19.05 DIA. BS2/3	TATA spare parts
278229100111	CLUTCH MASTER CYLINDER-WITHOUT BOTTLE	TATA spare parts
278229100112	ASSY CLUTCH PIPE 6 O.D.	TATA spare parts
278229100115	ASSY CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
278229100117	ASSY PEDAL PLATE CLUTCH	TATA spare parts
278229100118	ASSY CONTROL MTG BRACKET	TATA spare parts
278229100119	CLUTCH MASTER CYLINDER ASSY.-19.05	TATA spare parts
278229100120	CLUTCH MASTER CYL 19.05X50 STK	TATA spare parts
278229100122	ASSY. CONTROLS COMPLETE	TATA spare parts
278229100123	ASSY.CLUTCH PIPE-6 OD	TATA spare parts
278229100125	MAJOR KIT	TATA spare parts
278229100126	MINOR KIT	TATA spare parts
278229100128	SUB ASSY.CLUTCH PEDAL PLATE+RUBBER COVER	TATA spare parts
278229100129	SUB ASSY.CLUTCH PEDAL PLATE+RUBBER COVER	TATA spare parts
278229106002	CLUTCH RELEASE LEVER	TATA spare parts
278229150104	ASSY.CONNECTING LINE-HYD.CLUTCH	TATA spare parts
278229308701	RETURN SPRING-CLUTCH CONTROL	TATA spare parts
278229350101	ASSY.BKT. SL.CYL MTG	TATA spare parts
278229500101	ASSY BEARING TUBE	TATA spare parts
278229500103	ASSY MASTER CYLINDER MOUNTING BRACKET	TATA spare parts
278229500104	ASSY MASTER CYLINDER MOUNTING BRACKET	TATA spare parts
278229506701	PIN	TATA spare parts
278230100101	ASSY.ACC.COMPONENT SET-ON COWL	TATA spare parts
278230100103	ASSY. CONTROL SHAFT	TATA spare parts
278230100105	ASSY. LEVER ACCELERATOR PEDAL	TATA spare parts
278230100106	ASSY. THRUST ROD (L=251)	TATA spare parts
278231000101	ASSY.FRAME COMPLETE LPT 2515 TC	TATA spare parts
278231000102	ASSY FRAME COMPLETE EX MODEL	TATA spare parts
278231000103	ASSY.FRAME COMPLETE- SPECIAL VEHICLE	TATA spare parts
278231000104	ASSY FRAME COMPLETE EX MODEL	TATA spare parts
278231000106	ASSY.FRAME COMPLETE (1210 COWL)	TATA spare parts
278231000107	ASSY.FRAME COMPLETE	TATA spare parts
278231116101	LOCKING PLATE	TATA spare parts
278231200101	ASSY.BRACKET - RH-RADIATOR MOUNTING	TATA spare parts
278231200102	ASSY GUSSET RH BUMPER X MEMBER LPT2525TC	TATA spare parts
278231200103	ASSY GUSSET LH BUMPER X MEMBER LPT2525TC	TATA spare parts
278231200105	ASSY. SUPPORT-ENG.C M. REAR	TATA spare parts
278231200107	ASSY CROSS MEMBER REAR	TATA spare parts
278231200109	ASSY.BRACKET - LH-RADIATOR MOUNTING	TATA spare parts
278231200110	ASSY ENGINE CROSS MEMBER FRONT LPT2515TC	TATA spare parts
278231200111	ASSY SUPPORT ENGINE C/M	TATA spare parts
278231200112	ASSY SPACER PLATE	TATA spare parts
278231200113	ASSY GUSSET RH (EXTN PIECE)	TATA spare parts

278231200114	ASSY GUSSET LH (EXTN PIECE)	TATA spare parts
278231200115	ASSY. 4TH CROSS MEMBER	TATA spare parts
278231200116	ASSY. 5TH CROSS MEMBER	TATA spare parts
278231200118	ASSY SPACER PLATE (ENGINE C/M REAR)	TATA spare parts
278231200119	ASSY. 6 TH CROSS MEMBER & BTM. SUPPORT	TATA spare parts
278231200122	ASSY.6 TH CROSS MEMBER & BOTTOM SUPPORT	TATA spare parts
278231200123	ASSY. BRACKET-RH AUX WATER TANK BKT MTG	TATA spare parts
278231200124	ASSY. BRACKET-LH AUX WATER TANK BKT MTG	TATA spare parts
278231200126	ASSY.4TH CROSS MEMBER (WITH SUPPORT)	TATA spare parts
278231200129	ASSY. GUSSET -RH	TATA spare parts
278231200130	ASSY. GUSSET -LH	TATA spare parts
278231200131	ASSY. CROSS MEMBER (8TH C/M)	TATA spare parts
278231200132	ASSY. CROSS MEMBER (6A C/M)	TATA spare parts
278231200133	ASSY. CAGE (WITH M16X1.5 HEX. NUT)	TATA spare parts
278231200134	ASSY. CLEAT (FRONT -BOTTOM)	TATA spare parts
278231200135	ASSY. CLEAT (MIDDLE - BOTTOM)	TATA spare parts
278231200136	ASSY. CLEAT (REAR -BOTTOM)	TATA spare parts
278231200141	ASSY. RADIATOR MTG. BRACKET	TATA spare parts
278231200144	ASSY. CROSS MEMBER 7TH	TATA spare parts
278231200145	ASSY SUPPORT CROSS MEMBER	TATA spare parts
278231207121	CROSS MEMBER- 6 TH	TATA spare parts
278231207123	REINFORCEMENT	TATA spare parts
278231207124	BEND PLATE	TATA spare parts
278231207140	REINFORCEMENT -RH (SHOCK ABS.FRONT)	TATA spare parts
278231207141	REINFORCEMENT -LH	TATA spare parts
278231208203	PACKING PLATE - 1.6THK (ENGINE C/M REAR)	TATA spare parts
278231208204	PACKING PLATE-3.15 THK (ENGINE C/M REAR)	TATA spare parts
278231208205	PACKING PLATE - 1 THK.	TATA spare parts
278231208206	PACKING PLATE - 1.6 THK.	TATA spare parts
278231300101	ASSY. GUSSET LH(60WB)	TATA spare parts
278231300102	ASSY. GUSSET RH(60WB)	TATA spare parts
278231307101	SUPPORT LPT2515TC	TATA spare parts
278231307102	REINFORCEMENT	TATA spare parts
278231307105	GUSSET (TOP) - RH	TATA spare parts
278231307106	GUSSET (TOP) - LH	TATA spare parts
278231307109	GUSSET	TATA spare parts
278231307110	REINFORCEMENT - RH	TATA spare parts
278231307111	REINFORCEMENT - LH	TATA spare parts
278231307112	SUPPORT (REAR SPR. C/M)	TATA spare parts
278231307113	SUPPORT TOP-RH-4 TH CROSS MEMBER	TATA spare parts
278231307114	SUPPORT TOP-LH	TATA spare parts
278231307116	SUPPORT BKT. (6A-CROSS MEMBER)	TATA spare parts
278231307119	SUPPORT (ENG. C/M REAR)	TATA spare parts
278231307120	GUSSET BOTTOM -RH	TATA spare parts
278231307121	GUSSET BOTTOM -LH	TATA spare parts
278231307123	REINFORCEMENT ENG.FRONT CM -RH	TATA spare parts
278231307124	REINFORCEMENT ENG.FRONT CM -LH	TATA spare parts

278231307135	REINFORCEMENT BOTTOM-RH	TATA spare parts
278231307136	REINFORCEMENT BOTTOM-LH	TATA spare parts
278231307137	REINFORCEMENT TOP -RH	TATA spare parts
278231307138	REINFORCEMENT TOP -LH	TATA spare parts
278231307139	REINFORCEMENT-RH	TATA spare parts
278231307140	REINFORCEMENT-LH	TATA spare parts
278231307141	SUPPORT RH(CROSS MEMBER)	TATA spare parts
278231307142	SUPPORT LH (CROSS MEMBER)	TATA spare parts
278231307143	REINFORCEMENT	TATA spare parts
278231307144	REINFORCEMENT TOP-RH	TATA spare parts
278231307145	REINFORCEMENT TOP -LH	TATA spare parts
278231307146	REINFORCEMENT BOTTOM RH	TATA spare parts
278231307147	REINFORCEMENT BOTTOM LH	TATA spare parts
278231700101	ASSY.REAR UNDERRUN PROTECTIVE DEVICE COM	TATA spare parts
278231700102	ASSY. SUPPORT-LH	TATA spare parts
278231700103	ASSY. SUPPORT-RH	TATA spare parts
278231700106	ASSY.BRACKET-RH	TATA spare parts
278231700107	ASSY.BRACKET-LH	TATA spare parts
278231700111	ASSY.TUBE-RUPD	TATA spare parts
278231700114	ASSY.BRACKET-RH	TATA spare parts
278231700115	ASSY.BRACKET-LH	TATA spare parts
278231700116	ASSY. END CROSS MEMBER (LPT 2515)	TATA spare parts
278231700117	ASSY BOTTOM SHIELD RADIATOR SIDE	TATA spare parts
278231700119	ASSY.REAR UNDERRUN PROTECTIVE DEVICE COM	TATA spare parts
278231700120	ASSY. BRACKET-LH	TATA spare parts
278231700121	ASSY. BRACKET-RH	TATA spare parts
278231700122	ASSY. TUBE(RUPD)	TATA spare parts
278231700123	ASSY.SUPPORT	TATA spare parts
278231700127	ASSY BOTTOM SHIELD (ENGINE SIDE)	TATA spare parts
278231700128	ASSY TRANSMISSION SHIELD (FRT SIDE)	TATA spare parts
278231700129	ASSY TRANSMISSION SHIELD (REAR SIDE)	TATA spare parts
278231700130	ASSY BRACKET SHIELD MTG.	TATA spare parts
278231700131	ASSY BRACKET - RH	TATA spare parts
278231700132	ASSY BRACKET - LH	TATA spare parts
278231700133	ASSY SUPPORT BRACKET-RH	TATA spare parts
278231700134	ASSY SUPPORT BRACKET-LH	TATA spare parts
278231700136	ASSY.R.U.P.D( FOR 903 FRAME WIDTH )	TATA spare parts
278231700137	ASSY. MAIN BARCKET-LH FOR RUPD	TATA spare parts
278231700138	ASSY. MAIN BARCKET-RH FOR RUPD	TATA spare parts
278231700139	ASSY.CHANEEL WELDED COMPLETE	TATA spare parts
278231703201	HEX. BOLT (M16X1.5X58)	TATA spare parts
278231703202	HEX. BOLT (M16X1.5X52)	TATA spare parts
278231706902	TUBE-32DIA	TATA spare parts
278231707122	PLATE	TATA spare parts
278231707137	SPACER	TATA spare parts
278231707138	PLATE	TATA spare parts
278231707145	SPACER	TATA spare parts

278231707146	SIDE PLATE	TATA spare parts
278231707170	SIDE PLATE FOR ASSY. MAIN BRACKET	TATA spare parts
278231708602	WASHER-13 ID X 25 OD	TATA spare parts
278231708603	WASHER-17 ID X 36 OD	TATA spare parts
278231708604	SPACER FOR RUPD	TATA spare parts
278231708801	STUD-M16X1.5	TATA spare parts
278232100101	ASSY FRONT SPRING	TATA spare parts
278232100104	ASSY.FRONT SPRING	TATA spare parts
278232100106	ASSY FRONT SPRING	TATA spare parts
278232100107	ASSY FIRST LEAF WITH BUSH	TATA spare parts
278232100108	ASSY.FRONT SPRING	TATA spare parts
278232100130	ASSY. FRONT SPRING BS2/3	TATA spare parts
278232100131	ASSY.FIRST LEAF WITH BUSH	TATA spare parts
278232100131DF	MAIN LEAF FRONT W/BUSH-2518/2523 MOD	TATA spare parts
278232100132	ASSY FRONT SPRING	TATA spare parts
278232100133	ASSY. FRONT SPRING	TATA spare parts
278232100134	ASSY. FIRST LEAF	TATA spare parts
278232100134DFHC	MAIN LEAF FRONT W/BUSH HIGH CAMB-2518/31	TATA spare parts
278232100134DFNC	MAIN LEAF FRONT W/BUSH NORM CAMB-2518/31	TATA spare parts
278232100135	ASSY. FRONT SPRING	TATA spare parts
278232100136	ASSY. FRONT SPRING	TATA spare parts
278232100138	ASSY. FRONT SPRING (BI-METALLIC BUSH)	TATA spare parts
278232100143	ASSY.FRONT SPRING(JAI PARABOLIC)	TATA spare parts
278232100144	ASSY. FIRST LEAF W/BUSH BS1/2/3/4/6	TATA spare parts
278232100144DF	MAIN LEAF FRONT PARABOLIC W/BUSH-2518/31	TATA spare parts
278232100152	ASSY PARABOLIC SPRING-FRONT	TATA spare parts
278232103202	CENTRE BOLT	TATA spare parts
278232103204	CENTRE BOLT	TATA spare parts
278232103205	CENTRE BOLT	TATA spare parts
278232103208	CENTRE BOLT	TATA spare parts
278232103301	SPRING BRACKET- FRONT	TATA spare parts
278232103401	SPRING BUSH	TATA spare parts
278232103402	SPRING BUSH (BI - METALLIC)	TATA spare parts
278232103403	SPRING BUSH(FRONT-BI-METALLIC)	TATA spare parts
278232104201	SPRINGCLIP BS6	TATA spare parts
278232104202	SPRING CLIP	TATA spare parts
278232104203	SPRING CLIP	TATA spare parts
278232104206	SPRING CLIP	TATA spare parts
278232104210	SPRING CLIP	TATA spare parts
278232107119	FIRST LEAF	TATA spare parts
278232107120	SECOND LEAF	TATA spare parts
278232107121	THIRD LEAF	TATA spare parts
278232107122	FOURTH LEAF	TATA spare parts
278232107123	FIFTH LEAF	TATA spare parts
278232107124	SIXTH LEAF	TATA spare parts
278232107125	SEVENTH LEAF	TATA spare parts
278232107126	EIGHTH LEAF	TATA spare parts

278232107127	NINETH LEAF	TATA spare parts
278232107128	TENTH LEAF	TATA spare parts
278232107129	ELEVENTH LEAF	TATA spare parts
278232107148	SECOND LEAF	TATA spare parts
278232107148DF	SECOND LEAF FRONT-2518/2523 MOD	TATA spare parts
278232107149	THIRD LEAF	TATA spare parts
278232107149DF	THIRD LEAF FRONT-2518/2523 MOD	TATA spare parts
278232107150	FOURTH LEAF	TATA spare parts
278232107150DF	FOURTH LEAF FRONT-2518/2523 MOD	TATA spare parts
278232107151	FIFTH LEAF	TATA spare parts
278232107151DF	FIFTH LEAF FRONT-2518/2523 MOD	TATA spare parts
278232107152	SIXTH LEAF	TATA spare parts
278232107153	SEVENTH LEAF	TATA spare parts
278232107154	EIGHTH LEAF	TATA spare parts
278232107155	SPACER FRONT SPR	TATA spare parts
278232107156	FIRST LEAF	TATA spare parts
278232107157	SECOND LEAF	TATA spare parts
278232107157DFHC	SECOND LEAF FRONT HIGH CAMB-2518/3118	TATA spare parts
278232107157DFNC	SECOND LEAF FRONT NORM CAMB-2518/3118	TATA spare parts
278232107158	THIRD LEAF	TATA spare parts
278232107158DF	THIRD LEAF FRONT-2518/3118	TATA spare parts
278232107159	FOURTH LEAF	TATA spare parts
278232107160	FIFTH LEAF	TATA spare parts
278232107161	SIXTH LEAF	TATA spare parts
278232107162	SEVENTH LEAF	TATA spare parts
278232107163	EIGHTH LEAF	TATA spare parts
278232107170	SECOND LEAF	TATA spare parts
278232107170DF	SECOND LEAF FRONT PARA-2518/3118/4018	TATA spare parts
278232107171	THIRD LEAF	TATA spare parts
278232107172	PACKING PLATE	TATA spare parts
278232107173	CENTRE PAD	TATA spare parts
278232107174	SPACER PLATE	TATA spare parts
278232107178	FOURTH LEAF BS2/3/4/6	TATA spare parts
278232107179	THIRD LEAF BS2/3/4/6	TATA spare parts
278232107179DF	THIRD LEAF FRONT PARA-2518/3118/4018	TATA spare parts
278232108601	SPACER(SPRING CLIP)	TATA spare parts
278232108604	SPACER	TATA spare parts
278232204201	U-CLAMP(PARABOLIC)	TATA spare parts
278232300101	ASSY.BRACKET- FRONT SHOCK ABSORBER	TATA spare parts
278232300102	ASSY FRONT SHOCK ABSORBER	TATA spare parts
278232300103	ASSY. FRONT SHOCK ABSORBER BS2/3/4	TATA spare parts
278232300104	ASSY. BRACKET-FRONT SHOCK ABSORBER	TATA spare parts
278232300105	ASSY. BRACKET LH (FRONT SHOCK ABSORBER)	TATA spare parts
278232300108	ASSY. BRACKET LH (SHOCK ABSORBER UPPER)	TATA spare parts
278232300109	ASSY. BRACKET-RH (SHOCK ABSORBER UPPER)	TATA spare parts
278232308601	SPACER	TATA spare parts
278232400101	ASSY REAR SPRING	TATA spare parts



278232400103	KIT-BELL CRANK LEVER	TATA spare parts
278232400104	ASSY.BELL CRANK LEVER COMPLETE	TATA spare parts
278232400106	ASSY.REAR SPRING	TATA spare parts
278232400107	ASSY FIRST LEAF WITH BUSH	TATA spare parts
278232400108	ASSY.REAR SPRING	TATA spare parts
278232400110	ASSY.REAR SPRING	TATA spare parts
278232400111	ASSY.FIRST LEAF WITH BUSH	TATA spare parts
278232400112	ASSY. REAR SPRING	TATA spare parts
278232400114	ASSY. REAR SPRING BS1/2/3/4/6	TATA spare parts
278232400115	ASSY. FIRST LEAF BS1/2/3/4	TATA spare parts
278232400115DF	MAIN LEAF REAR W/BUSH-2518/3118	TATA spare parts
278232400118	ASSY. SHACKLE COMP. REAR BS1/2/3/4	TATA spare parts
278232400121	ASSY. REAR SPRING (BI -METALLIC BUSH)	TATA spare parts
278232400123	ASSY. LEVER (BELL CRANK)	TATA spare parts
278232400132	ASSY. LINK ROD	TATA spare parts
278232400133	KIT-BELL CRANK LEVER LINK ROD SHACKLE.	TATA spare parts
278232403201	CENTRE BOLT	TATA spare parts
278232403202	CENTRE BOLT	TATA spare parts
278232403203	CENTRE BOLT	TATA spare parts
278232403301	REAR SPRING BRACKET-FRONT LPT2515TC	TATA spare parts
278232403302	REAR SPRING BRACKET-CENTRE	TATA spare parts
278232403303	REAR SPRING BRACKET-REAR	TATA spare parts
278232403304	REAR SPRING BRACKET-FRONT	TATA spare parts
278232403401	SPRING BUSH(REAR)	TATA spare parts
278232403402	SPRING BUSH (BI - METALLIC) BS1/2/3/4/6	TATA spare parts
278232404201	U CLAMP	TATA spare parts
278232404204	SPRING CLIP	TATA spare parts
278232404206	SPRING CLIP	TATA spare parts
278232404208	U BOLT ( M22 X 2.5 X 418)	TATA spare parts
278232404209	U BOLT ( M22 X 2.5 X 400)	TATA spare parts
278232404210	U BOLT ( M20 X 1.5 X 435)	TATA spare parts
278232404211	U CLAMP	TATA spare parts
278232404214	U BOLT ( M22 X 2.5 X 460)	TATA spare parts
278232404215	SPRING CLIP	TATA spare parts
278232404217	U CLAMP	TATA spare parts
278232405102	BOTTOM SADDLE(REAR AXLE)	TATA spare parts
278232406701	SPRING PIN	TATA spare parts
278232406702	PIN	TATA spare parts
278232406703	SPRING PIN	TATA spare parts
278232407118	FIRST LEAF	TATA spare parts
278232407119	SECOND LEAF	TATA spare parts
278232407120	THIRD LEAF	TATA spare parts
278232407120DF	THIRD LEAF REAR - 2515/2416	TATA spare parts
278232407121	FOURTH LEAF	TATA spare parts
278232407121DF	FOURTH LEAF REAR - 2515/2416	TATA spare parts
278232407122	FIFTH LEAF	TATA spare parts
278232407123	SIXTH LEAF	TATA spare parts

278232407124	SEVENTH LEAF	TATA spare parts
278232407125	EIGHTH LEAF	TATA spare parts
278232407126	NINETH LEAF	TATA spare parts
278232407127	TENTH LEAF	TATA spare parts
278232407128	ELEVENTH LEAF	TATA spare parts
278232407129	TWELVETH LEAF	TATA spare parts
278232407130	THIRTEENTH LEAF	TATA spare parts
278232407131	FOURTEENTH LEAF	TATA spare parts
278232407132	FIFTEENTH LEAF	TATA spare parts
278232407133	SIXTEENTH LEAF	TATA spare parts
278232407135	SECOND LEAF	TATA spare parts
278232407136	THIRD LEAF	TATA spare parts
278232407137	FOURTH LEAF	TATA spare parts
278232407138	FIFTH LEAF	TATA spare parts
278232407139	SIXTH LEAF	TATA spare parts
278232407140	SEVENTH LEAF	TATA spare parts
278232407141	EIGHTH LEAF	TATA spare parts
278232407142	NINETH LEAF	TATA spare parts
278232407143	TENTH LEAF	TATA spare parts
278232407144	ELEVENTH LEAF	TATA spare parts
278232407145	TWELVETH LEAF	TATA spare parts
278232407146	THIRTEENTH LEAF	TATA spare parts
278232407147	FOURTEENTH LEAF	TATA spare parts
278232407148	FIFTEENTH LEAF	TATA spare parts
278232407149	SPACER REAR SPRING	TATA spare parts
278232407156	SECOND LEAF	TATA spare parts
278232407156DF	SECOND LEAF REAR - 2516/2518/3118	TATA spare parts
278232407157	THIRD LEAF	TATA spare parts
278232407157DF	THIRD LEAF REAR - 2516/2518/3118	TATA spare parts
278232407158	FOURTH LEAF	TATA spare parts
278232407158DF	FOURTH LEAF REAR - 2516/2518/3118	TATA spare parts
278232407159	FIFTH LEAF	TATA spare parts
278232407159DF	FIFTH LEAF REAR - 2516/2518/3118	TATA spare parts
278232407160	SIXTH LEAF	TATA spare parts
278232407161	SEVENTH LEAF	TATA spare parts
278232407162	EIGHTH LEAF	TATA spare parts
278232407163	NINTH LEAF	TATA spare parts
278232407164	TENTH LEAF	TATA spare parts
278232407165	ELEVENTH LEAF	TATA spare parts
278232407166	TWELVETH LEAF	TATA spare parts
278232408601	SPACER(SPRING CLIP)	TATA spare parts
278232503701	GUIDE PLATE-CASTING	TATA spare parts
278232503702	GUIDE PLATE-CASTING	TATA spare parts
278232505101	GUIDE PLATE-FORGING	TATA spare parts
278232800101	ASSY.ANTIROLLBAR(CRIMPED) BS6	TATA spare parts
278232800102	SUB-ASSY ANTIROLL BAR(CRIMPED)	TATA spare parts
278233000101	ASSY.FA 2515 (SPG)	TATA spare parts

278233403101	TAPERED ROLLER BEARING	TATA spare parts
278233403102	TAPERED ROLLER BEARING	TATA spare parts
27823648 COWL	COWL LPT 2515/48TC BS-II	TATA spare parts
278240100101	ASSY.WHEEL RIM 7.5X20	TATA spare parts
278240100102	ASSY.WHEEL RIM(7.5 V5 DEG.X20)	TATA spare parts
278240100103	ASSY.- ASSY.TYRE + WHEEL RIM	TATA spare parts
278240100105	ASSY WHEEL RIM	TATA spare parts
278240100111	ASSY.WHEEL RIM 7.5 X 20 (SINGLE LOCK)	TATA spare parts
278240100111AE	ASSY WHEEL DISC & RIM 7X20 -1415	TATA spare parts
278240100112	ASSY WHEEL RIM	TATA spare parts
278240100113	ASSY WHEEL RIM 7 X 20	TATA spare parts
278240100114	ASSY WHEEL RIM 7.5X20	TATA spare parts
278240100115	ASSYWHEELRIM(M/SWIL)7.5X20-CT105	TATA spare parts
278240100126	LOCK RING	TATA spare parts
278240100127	FLANGE	TATA spare parts
278240100128	KIT-ASSY.TYRE TUBE FLAP(LUG TYPE) & WHEE	TATA spare parts
278240100129	KIT-ASSY.TYRE TUBE FLAP(RIB TYPE) & WHEE	TATA spare parts
278240100152	ASSY WHEEL RIM 7.0 X 20	TATA spare parts
278240106101	LOCK RING	TATA spare parts
278240109907	LOCK RING	TATA spare parts
278240109908	SIDE RING	TATA spare parts
278240990101	ASSY KIT SET FOR WHEEL RIM & LUG TYRE.	TATA spare parts
278241100101	PROPELLER SHAFT FRONT WITH C/B	TATA spare parts
278241100105	ASSY. PROP.SHAFT FRONT	TATA spare parts
278241100108	ASSY.PROP.SHAFT FRONT ( L=1394)	TATA spare parts
278241100111	ASSY PROPSHAFT FRONT	TATA spare parts
278241100112	ASSY PROPSHAFT MIDDLE	TATA spare parts
278241100117	ASSY.PROP.SHAFT FRONT	TATA spare parts
278241110101	ASSY.PROP.SHAFT.WITH C.B.MIDDLE	TATA spare parts
278241120101	ASSY PROPSHAFT REAR	TATA spare parts
278241120102	ASSY.PROP.SHAFT REAR	TATA spare parts
278241120103	ASSY.PROP.SHAFT REAR ( C.L=1138)	TATA spare parts
278241120104	ASSY PROPSHAFT REAR	TATA spare parts
278241129901	PROPELLER SHAFT TUBE ASSY	TATA spare parts
278241129903	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
278241303301	BRACKET-SPACER	TATA spare parts
278241303303	CENTRE BEARING MOUNTING BRACKET	TATA spare parts
278241303304	CENTRE BEARING MOUNTING BRACKET	TATA spare parts
278241308201	PROPELLER SHAFT GUARD	TATA spare parts
278241308204	SPACER PLATE	TATA spare parts
278242100101	RE VALVE	TATA spare parts
278242100102	BRAKE CHAMBER RH TYPE 20	TATA spare parts
278242100103	BRAKE CHAMBER LH TYPE 20	TATA spare parts
278242100106	BRAKE CHAMBER TYPE 24 BS1/2/3/4	TATA spare parts
278242100106AE	BRAKE CHAMBER 2523	TATA spare parts
278242107101	BRACKET-RELAY VALVE MTG.	TATA spare parts
278242109901	FRONT BRAKE OVERHAUL KIT (MINOR)	TATA spare parts

278242109902	BRAKE LINERS KIT- FRONT	TATA spare parts
278242300101	ASSY.SLACK ADJUSTER STRAIGHT	TATA spare parts
278242300102	ASSY.SLACK ADJUSTER STRAIGHT	TATA spare parts
278242300104	ASSY.REAR BRAKE	TATA spare parts
278242300105	REAR BRAKE ASSY.-RH	TATA spare parts
278242300106	ASSY. BRAKE CHAMBER CAST MTG BKT-LH	TATA spare parts
278242300107	ASSY. BRAKE CHAMBER CAST MTG BKT-RH	TATA spare parts
278242300108	SPRING BRAKE ACTUATOR	TATA spare parts
278242300109	ASSY.DR.BRK.REAR LH N/ASBS WT DC&MF	TATA spare parts
278242300110	ASSY.DR.BRK.REAR RH N/ASBS WT DC&MF	TATA spare parts
278242300111	SPRING BRAKE ACTUATOR-TYPE 24X24-	TATA spare parts
278242300124	S.B.ACTUATOR RH TY.24/24	TATA spare parts
278242300125	S.B.ACTUATOR LH TY.24/24	TATA spare parts
278242300128	SLACK ADJUSTER (TATA MOTORS BS2/3	TATA spare parts
278242300139	S.B.ACTUATOR RH TY.20/24	TATA spare parts
278242300140	S.B.ACTUATOR LH TY.20/24	TATA spare parts
278242300141	TORQUE PLATE REAR-LH	TATA spare parts
278242300142	TORQUE PLATE REAR-RH	TATA spare parts
278242303402	BUSH CHAMBER MOUNTING BRACKET	TATA spare parts
278242303701	BRAKE CHAMBER MOUNTING BRACKET - LH	TATA spare parts
278242303702	BRAKE CHAMBER MOUNTING BRACKET - RH	TATA spare parts
278242305103	CAMSHAFT RH	TATA spare parts
278242305104	CAMSHAFT LH	TATA spare parts
278242305105	CAM SHAFT RH	TATA spare parts
278242305106	CAM SHAFT LH	TATA spare parts
278242307802	GREASE SEAL(BRAKE CHAMBER MTG BRACKET)	TATA spare parts
278242307802AE	GRSE SEAL(BRK CHMBR MTG)-1628	TATA spare parts
278242307803	OIL SEAL	TATA spare parts
278242706801	CONNECTOR M14XM18	TATA spare parts
278242706802	CONNECTOR M16XM22 BS6	TATA spare parts
278242707704	O'RING M16 BS6	TATA spare parts
278242708604	THRUST RING M16 BS6	TATA spare parts
278242900105	ASSY.NYLON TUBE LINES CHASSIS 2515 TC	TATA spare parts
278242900107	ASSY TUBE 15 DIA	TATA spare parts
278242900108	ASSY.TUBE-6 DIA.	TATA spare parts
278242900109	ASSY.TUBE-15 DIA.	TATA spare parts
278242900110	ASSY.TUBE-12 DIA.	TATA spare parts
278242900111	ASSY.TUBE-15 DIA.	TATA spare parts
278242900112	ASSY.TUBE-12 DIA.	TATA spare parts
278242900113	ASSY.TUBE-12 DIA.	TATA spare parts
278242900114	ASSY TUBE-12 DIA.	TATA spare parts
278242900115	ASSY.TUBE- 12 DIA.	TATA spare parts
278242900116	ASSY.TUBE-12 DIA.	TATA spare parts
278242900117	ASSY.TUBE- 12 DIA.	TATA spare parts
278242900118	ASSY.TUBE-12 DIA.	TATA spare parts
278242900119	ASSY.TUBE- 12 DIA.	TATA spare parts
278242900120	ASSY.TUBE- 12 DIA.	TATA spare parts

278242900121	ASSY TUBE 15 DIA	TATA spare parts
278242900122	ASSY.TUBE-12 DIA.	TATA spare parts
278242900123	ASSY.TUBE- 12 DIA.	TATA spare parts
278242900125	ASSY.TUBE- 12 DIA.	TATA spare parts
278242900126	ASSY.TUBE-6 DIA.	TATA spare parts
278242900128	ASSY.TUBE-6 DIA.	TATA spare parts
278242900129	ASSY.TUBE- 6 DIA.	TATA spare parts
278242900130	ASSY.TUBE- 6 DIA.	TATA spare parts
278242900131	ASSY.TUBE-6 DIA.	TATA spare parts
278242900132	ASSY.TUBE- 12 DIA.	TATA spare parts
278242900133	ASSY.TUBE- 12 DIA.	TATA spare parts
278242900134	ASSY.TUBE- 12 DIA.	TATA spare parts
278242900135	ASSY.NYLON PIPE 6-DIA -2655 LG.	TATA spare parts
278242900136	ASSY.NYLON PIPE 6-DIA - 2790 LG.	TATA spare parts
278242900137	ASSY. NYLON PIPE 12-DIA-2135-LG.	TATA spare parts
278242900138	ASSY. NYLON PIPE 6-DIA-2190 LG.	TATA spare parts
278242900139	ASSY. NYLON PIPE 12-DIA- 2195 LG.	TATA spare parts
278242900140	ASSY.NYLON PIPE 12-DIA-2195 LG.	TATA spare parts
278242900141	NYLON PIPE 6DIA 1420 LONG	TATA spare parts
278242900142	NYLON PIPE 6DIA 1420 LONG	TATA spare parts
278242900144	SUB. ASSY. NYLON PIPE COWL 2515 TC	TATA spare parts
278242900145	SUB ASSY NYLON PIPE GAUGE LINES2515 TC	TATA spare parts
278242900146	SUB ASSY.CHASSIS TUBE LINESLHLM	TATA spare parts
278242900147	SUB ASSY.CHASSIS TUBES PRTG.BKT	TATA spare parts
278242900148	SUBASSY.CHASSIS TUBES A.T.SIDE	TATA spare parts
278242900149	SUBASSY.CHASSIS TUBES [RHLM]	TATA spare parts
278242900150	ASSY.PIPE - 15 DIA. METAL	TATA spare parts
278242900151	ASSY.BASE PLATE RHD (DUAL TRDLE.VLV.MTG)	TATA spare parts
278242900153	ASSY. NYLON PIPE 2515 TC	TATA spare parts
278242900154	NYLON TUBE FST TO TEE-1 LPT 2515TC	TATA spare parts
278242900155	NYLON TUBE TEE-1 TO REL VALVE RH LM LPT	TATA spare parts
278242900156	NYLON TUBE TEE-1 TO PART BKT LPT 2515TC	TATA spare parts
278242900158	NYLON TUBE RST TO TEE-2 LPT 2515TC	TATA spare parts
278242900159	NYLON TUBE TEE-2 TO LH LM LPT 2515TC	TATA spare parts
278242900160	NYLON TUBE TEE-2 TO PART BKT LPT 2515TC	TATA spare parts
278242900161	NYLON TUBE PART BKT TO LH LM LPT 2515TC	TATA spare parts
278242900162	NYLON TUBE LH LM TO ST.CONNECTOR LPT 251	TATA spare parts
278242900163	NYLON TUBE PART BKT TO CROSS LPT 2515TC	TATA spare parts
278242900164	NYLON TUBE CROSS TO FBC LH LPT 2515TC	TATA spare parts
278242900165	NYLON TUBE CROSS TO FBC RH LPT 2515TC	TATA spare parts
278242900166	NYLON TUBE SPV-22 TO RST LPT 2515TC	TATA spare parts
278242900167	NYLON TUBE RH LM TO ST.CONNECTOR LPT 251	TATA spare parts
278242900168	NYLON TUBE SPV-23 TO TEE-3 LPT 2515TC	TATA spare parts
278242900169	NYLON TUBE TEE-3 TO PART BKT LPT 2515TC	TATA spare parts
278242900170	NYLON TUBE TEE-3 TO DACM REL VALVE LPT 2	TATA spare parts
278242900171	NYLON TUBE PART BKT TO DACM LPT 2515TC	TATA spare parts
278242900172	NYLON TUBE DACM TO 6TH CM LPT 2515TC	TATA spare parts

278242900173	NYLON TUBE LH LM TO 6TH CM LPT 2515TC	TATA spare parts
278242900174	NYLON TUBE TEE-5 TO RBC RH LPT 2515TC	TATA spare parts
278242900175	NYLON TUBE TEE-6 TO RBC RH LPT 2515TC	TATA spare parts
278242900176	NYLON TUBE TEE-6 TO RBC LH LPT 2515TC	TATA spare parts
278242900178	ASSY.NYLON PIPE- 15 O.D.	TATA spare parts
278242900179	ASSY.NYLON PIPE- 15 O.D.	TATA spare parts
278242900180	ASSY.NYLON PIPE- 12 O.D.	TATA spare parts
278242900184	ASSY.NYLON PIPES COWL/CAB COMPLETE	TATA spare parts
278242900187	ASSY.CLAMP(12X12 O.D.NYL.PIPE WITH COVER	TATA spare parts
278242900189	ASSY.CLAMP(15OD NYLON PIPE WITH COVER)	TATA spare parts
278242900198	ASSY.NYLON PIPE 12 O.D.	TATA spare parts
278242900199	ASSY.NYLON PIPE 6 O.D.	TATA spare parts
278242903301	BRACKET (FOR FIT.ON R.A.109 )	TATA spare parts
278242903302	BRACKET (ON RA 909)	TATA spare parts
278242903306	C BRACKET	TATA spare parts
278242903308	QUICK RELEASE VALVE MTG. BRACKET (ON LIV	TATA spare parts
278242903310	BRACKET QUICK RELEASE VLV (ON DEAD AXLE)	TATA spare parts
278242903501	BOSS ( FOR R.A.109 AXLE)	TATA spare parts
278242904201	METAL CLAMP(12X12 O.D.NYL.PIPE W/COVER)	TATA spare parts
278242904203	METAL CLAMP (15 O.D NYL.PIPE WITH COVER)	TATA spare parts
278242910101	ASSY.NYLON PIPE 12 O.D.	TATA spare parts
278242910102	ASSY.NYLON PIPE 12 O.D.	TATA spare parts
278242910103	ASSY.NYLON PIPE 6 O.D.	TATA spare parts
278242910104	ASSY.NYLON PIPE 6 O.D.	TATA spare parts
278242910109	3/8 INCH HOSE ASSY	TATA spare parts
278242910121	ASSY.PIPE- 6 O.D.	TATA spare parts
278242910137	ASSY.PIPE- 6 O.D.	TATA spare parts
278242910149	ASSY. PIPE	TATA spare parts
278242910150	ASSY.PIPE	TATA spare parts
278242990104	CAMSHAFT WASHER KIT	TATA spare parts
278242990109	KIT-TORQUE PLATE LH	TATA spare parts
278242990110	KIT-TORQUE PLATE RH	TATA spare parts
278243200105	ASSY.AIR CONTAINER (SUITABLE FOR VOSS)	TATA spare parts
278243200106	SUB ASSY AIR TANK (15 LTR) FOR ABS.	TATA spare parts
278243200107	ASSY.AIR TANK WITH FITTINGS (FOR VOSS)	TATA spare parts
278243200108	ASSY.BRACKET - (AIR TANK MTG.15LTR)	TATA spare parts
278243208203	BRACKET (15 LTR AIR TANK MTG. ABS)	TATA spare parts
278243700101	ASSY DUAL TREADLE VALVE RHD LPT2515TC	TATA spare parts
278243700105	DUAL BRAKE VALVE W/ FILTER	TATA spare parts
278243700106	REPAIR KIT-RELAY VALVE TYPE RG2	TATA spare parts
278243700107	REPAIR KIT-D.TREADLE VALVE	TATA spare parts
278243700116	PALM COUPLING TRACTOR SUPPLY LINE	TATA spare parts
278243700116AE	PALM COUPLING TRACTOR LPTA 1828	TATA spare parts
278243700117	SPRING BRAKE ACTUATOR TYPE 24/75 BS2/3	TATA spare parts
278243700117AE	SPRING BRAKE ACTUATOR 24/75 1415	TATA spare parts
278243700123	DUAL TREADLE VALVE	TATA spare parts
278243700127	PALM COUPLING-TRAILER CONTROL LINE	TATA spare parts

278243700130	PALM COUPLING-TRAILER SUPPLY LINE	TATA spare parts
278243700131	QUICK RELEASE VALVE	TATA spare parts
278243700132	PALM COUPLING-TRACTOR CONTROL LINE	TATA spare parts
278243700132AE	PALM CPLING(TRLR SUPPLY LN)-1828	TATA spare parts
278243700135	DUAL BRAKE VAVLE	TATA spare parts
278243700141	AIR DRYER W/O HEATER (HI PR)	TATA spare parts
278243700143	DRYING & DIST. HI PR VOSS BS1/2/3/4	TATA spare parts
278243700144	DDU HI PR WT CO PT VOSS BS2/3/4	TATA spare parts
278243700144AE	DRY & DIST.UNIT HI PR VOSS 1415	TATA spare parts
278243700145	BRAKE ACTUATOR(VOSS-LH)24/75 BS1/2/3	TATA spare parts
278243700146	SPRING BRK. ACTUATOR RH 24/75 BS1/2/3	TATA spare parts
278243700147	RELAY VALVE BS2/3/4/6	TATA spare parts
278243700147AE	RELAY VALVE ALL VOSS PORTS 1415	TATA spare parts
278243700147C	RELAY VALVE-RG2(DEL1- VOSS&DEL2-VOSS)COR	TATA spare parts
278243700148	DUAL BRAKE VAVLE VOSS	TATA spare parts
278243700149	QUICK RELEASE VALVE VOSS-WT ADAPTOR	TATA spare parts
278243700152	BRAKE CHAMBER (TYPE-14)	TATA spare parts
278243700154	RG2 RELAY VAVLE	TATA spare parts
278243700159	D.B.VALVE SFC 1109 713	TATA spare parts
278243700161	BRAKE CHAMBER-LH (TYPE-20)	TATA spare parts
278243700162	BRAKE CHAMBER-RH (TYPE-20)	TATA spare parts
278243700163	DDU HI PR WITH 150 MM MTG PITCH	TATA spare parts
278243700167	DUAL THRADLE VLV WITH SWTCH.	TATA spare parts
278243700170	REPAIR KIT FOR LCRV	TATA spare parts
278243700172	SPRING BRAKE CHAMBER RH	TATA spare parts
278243700173	SPRING BRAKE CHAMBER LH	TATA spare parts
278243700174	BRAKE ACTUATOR(VOSS-LH)24/75 BS1/2/3	TATA spare parts
278243700188	REPAIR KIT-DDU (MINOR) BS1/2/3/4	TATA spare parts
278243700189	REPAIR KIT(RELAY VALVE)	TATA spare parts
278243700190	REPAIR KIT GRADUATED HAND BRAKE VALVE	TATA spare parts
278243700193	DRYNG & DISTR UNT WT CON POT M26	TATA spare parts
278243700195	REPAIR KIT BRAKE CHAMBER	TATA spare parts
278243700197	REPAIR KIT-BRAKE CHAMBER TYPE 24	TATA spare parts
278243700198	KIT-BRAKE CHAMBER	TATA spare parts
278243703301	PALM COUPLING - SUPPLY LINE (RED)	TATA spare parts
278243707720	SPECIAL WASHER	TATA spare parts
278243707738	DIAPHRAGM	TATA spare parts
278243707760	DIAPHRAGM	TATA spare parts
278243900114	STRAIGHT PLUG	TATA spare parts
278243900115	STRAIGHT PLUG NG12 NW6	TATA spare parts
278243900116	ELB PLUG NG12 NW6	TATA spare parts
278243900117	ELB. PLUG NG12 NW12	TATA spare parts
278243900118	L CONNECTOR NG8 (0230115000)	TATA spare parts
278243900160	ASSY.NY.PIPE SET CHASSIS COMPL-VOSS	TATA spare parts
278243900169	ASSY.NY.PIPE SET COMPL-2515TC/VOSS	TATA spare parts
278243900174	ASSY.NYLON PIPE SET COMPLETE LPT2515C	TATA spare parts
278243901601	ASSY.NYLON PIPE SET COMPLETE LPT2515C	TATA spare parts

278243903301	BRACKET-TEE MTG. ON RA AXLE	TATA spare parts
278243906801	FIRTEE 12X8X12 BS6	TATA spare parts
278243906802	TCONNECTOR NG12X12X12 VOSS(0023835000)	TATA spare parts
278243906803	T CONNECTOR NG8X3	TATA spare parts
278243910139	ASSY.NYLON PIPE SET COMPLETE LPT2515C	TATA spare parts
278243910155	ASSY.NY.PIPE SET COMPL-2515/KB/VOSS	TATA spare parts
278243910156	ASSY.NYLON PIPE SET COMPL-KB/VOSS	TATA spare parts
278243910166	ASSY.NY.PIPE SET COMPL-2515/60WB	TATA spare parts
278243910181	ASY.NY.PIP SET CHAS/2515/VOS/CLUT	TATA spare parts
278243910184	ASSY.METAL PIPE HOSE TO INT.JOINT	TATA spare parts
278243920104	ASSY CHASSIS SET COMP	TATA spare parts
278243920112	ASSY. NYLON PIPE SET COMPLETE	TATA spare parts
278243920114	ASSY. METAL PIPE (18OD) COMPR OL WT HOSE	TATA spare parts
278243920116	ASY CHASSIS SET COMP(PL CON)2515-TC-COWL	TATA spare parts
278243920122	ASSY.TUBE WITH CRIMPED TEFLON HOSE	TATA spare parts
278243920123	ASSY.TUBE.	TATA spare parts
278243920124	ASSY.TUBE.	TATA spare parts
278243920126	ASSY.COMP.PIPE 2ND	TATA spare parts
278243920127	ASSY.COMP.PIPE 3RD	TATA spare parts
278243920129	ASSY. NYLON PIPE SET FOR CHASSIS	TATA spare parts
278243920135	ASSY.METAL PIPE COMP.CONTROL PORT.	TATA spare parts
278244100105	ASSY PUMP DOUBLE ACTING	TATA spare parts
278244100106	ASSY.HYD.CYL.&P.O.CHECK VALVE	TATA spare parts
278244100111	ASSY BRACKET - CYLINDER MOUNTING	TATA spare parts
278244400101	ASSY. HYDRAULIC STG. TANK-PLASTIC BS1- 4	TATA spare parts
278244400102	HYD.STEERING TANK ASSY	TATA spare parts
278244400103	PLASTIC HYDRAULIC RESERVOIR	TATA spare parts
278244900101	ASSY METAL PIPE(6 O.D.)-PUMP TO CYLINDER	TATA spare parts
278244900102	ASSY METAL PIPE(6 O.D.)-CYLINDER TO PUMP	TATA spare parts
278246000117	ASSY DRAG LINK-RHD	TATA spare parts
278246100101	ASSY. BRACKET-STEERING GEAR BOX MOUNTING	TATA spare parts
278246100103	ASSY STG GEAR BOX MTG BRACKET.	TATA spare parts
278246100106	ASSY.BRACKET(POWER STG.TANK MOUNTING)	TATA spare parts
278246100109	ASSY BRACKET (POWER STG TANK MTG.)	TATA spare parts
278246100112	ASSY BRACKET STEERING G/BOX MOUNTING	TATA spare parts
278246106301	RUBBER BELLOW	TATA spare parts
278246106302	RUBBER BELLWS	TATA spare parts
278246108201	CLAMPING RING	TATA spare parts
278246200103	ASSY STEERING SPINDLE	TATA spare parts
278246200104	ASSY STEERING SPINDLE	TATA spare parts
278246200105	ASSY.STEERING SPINDLE COMPLETE	TATA spare parts
278246200106	ASSY.STEERING SPINDLE COMPLETE	TATA spare parts
278246400101	BOWL ASSY BS6	TATA spare parts
278246400103	STRAINER	TATA spare parts
278246406501	LOCK NUT	TATA spare parts
278246408801	STUD	TATA spare parts
278246600101	ASSY. DRAG LINK 2515 TILT CAB BS1/2/3/4	TATA spare parts



278246600102	DRAG LINK	TATA spare parts
278246600103	ASSY.STEERING OIL RESERVOIR	TATA spare parts
278246600104	ASSY.KIT.MAJOR-DIRECT DRIVE PUMP	TATA spare parts
278246600105	ASSY.KIT MINOR-DIRECT DRIVE PUMP	TATA spare parts
278246600106	ASSY.SEALING KIT FOR STG.GEAR BOX	TATA spare parts
278246600108	ASSY. KIT FOR STG. RESERVOIR	TATA spare parts
278246600112	HOUSING ASSEMBLY	TATA spare parts
278246600113	VALVE HOUSING ASSEMBLY	TATA spare parts
278246600114	SECTOR SHAFT COVER ASSEMBLY	TATA spare parts
278246600115	VALVE SLEEVE ASSEMBLY	TATA spare parts
278246600116	INPUT SHAFT AND TORSION BAR ASSEMBLY	TATA spare parts
278246600117	WORM SHAFT ASSEMBLY	TATA spare parts
278246600118	PISTON ASSEMBLY	TATA spare parts
278246600119	SECTOR SAHFT ASSEMBLY	TATA spare parts
278246600120	HOUSING COVER ASSEMBLY	TATA spare parts
278246600121	INPUT SHAFT ASSEMBLY	TATA spare parts
278246600122	SECTOR SHAFT AND HOUSING COVER ASSEMBLY	TATA spare parts
278246600123	WORM SHAFT AND VALVE ASSEMBLY	TATA spare parts
278246600124	WORM SHAFT AND PISTON ASSEMBLY	TATA spare parts
278246600125	FILTER ELEMENT ASSEMBLY	TATA spare parts
278246600126	ASSY.KIT.MAJOR-PULLEY DRIVEN PUMP	TATA spare parts
278246600128	ASSY. STEERING GEAR BOX BS1/2/3/4	TATA spare parts
278246600130	ASSY STG.GEAR BOX	TATA spare parts
278246609901	CARTRIDGE - PLASTIC RESERVOIR BS1/2/3/4	TATA spare parts
278246609901AE	CARTRIDGE ZF 715	TATA spare parts
278246609901DF	FILTER STEERING-HYDRAULIC-ZF PLASTIC TAN	TATA spare parts
278246800103	ASSY.TUBE-15 O.D.	TATA spare parts
278246800104	ASSY TUBE	TATA spare parts
278246800105	ASSY TUBE	TATA spare parts
278246800110	INLET PIPE ASSY-15 MM O.D.	TATA spare parts
278246800111	ASSY OUTLET PIPE	TATA spare parts
278246800112	ASSY.PIPE-15 O.D. GEAR BOX TO STG. PUMP	TATA spare parts
278246800113	ASSY.PIPE-15 O.D. TANK TO GEAR BOX	TATA spare parts
278246800114	ASSY.PIPE-15 O.D. TANK TO GEAR BOX	TATA spare parts
278246800115	ASSY.HOSE-CRIMPED STG.TANK TO STG.PUMP	TATA spare parts
278246800116	ASSY.HOSE-CRIMPED STG.TANK TO GEAR BOX	TATA spare parts
278246800117	ASSY TUBE WITH CRIMPED RUBBER HOSE TANK	TATA spare parts
278246800118	ASSY TUBE WITH CRIMPED RUBBER HOSE GB TO	TATA spare parts
278246800121	ASSY HOSE PIPE SUCTION	TATA spare parts
278246800122	ASSY HOSE PRESSURE LINE	TATA spare parts
278246800123	ASSY RETURN LINE (TANK END)	TATA spare parts
278246800124	ASSY RETURN LINE (STG GEAR BOX END)	TATA spare parts
278246800126	KIT ASSY.P/STG.PIPE LINES & CONNECTOR	TATA spare parts
278247100101	ASSY. FUEL TANK COMP. 350 LTR BS1/2/3/4	TATA spare parts
278247105801	HOSETANKTOTPV BS6	TATA spare parts
278247500101	ASSY.SUPPORT WITH STRAP	TATA spare parts
278247500103	ASSY SUPPORT-FUEL TANK 500 DIA	TATA spare parts

278247500103AE	SUPPORT.FUEL TANK 500 DIA 1415	TATA spare parts
278247500104	ASSY STRAP FOR FUEL TANK 350 LTR	TATA spare parts
278247500104AE	ASSY.STRAPLPA 1415/	TATA spare parts
278247507701	RUBBER PACKING PROFILED	TATA spare parts
278247507702	RUBBER PACKING	TATA spare parts
278247600102	ASSY SUCTION PIPE	TATA spare parts
278247600103	ASSY SUCTION PIPE	TATA spare parts
278247600105	ASSY RETURN PIPE	TATA spare parts
278247600106	TUBE SUCTION WITH STRAINER	TATA spare parts
278247600107	ASSY.FUEL SUCTION LINE	TATA spare parts
278247600109	ASSY.SUCTION PIPE.	TATA spare parts
278247600110	ASSY.RETURN PIPE	TATA spare parts
278247600114	ASSY SUCTION LINE-CRIMPED HOSE	TATA spare parts
278247600115	ASSY RETURN LINE-CRIMPED HOSE	TATA spare parts
278247600117	ASSY SUCTION LINE (CRIMPED HOSE)	TATA spare parts
278247600118	ASSY RETURN LINE (CRIMPED HOSE)	TATA spare parts
278247605801	REDUCER FUEL HOSE (10 O.D. - 6 O.D.)	TATA spare parts
278249100103	ASSY.MUFFLER WITH TAIL PIPE	TATA spare parts
278249100109	ASSY. MUFFLER WITH TAIL PIPE(LPT2515/56)	TATA spare parts
278249100111	ASSY MUFFLER TAIL PIPE	TATA spare parts
278249100116	ASSY MUFFLER (NT6A) WITH TAIL PIPE	TATA spare parts
278249200102	ASSY. BRACKET	TATA spare parts
278249200103	ASSY. EXHAUST PIPE	TATA spare parts
278249200104	ASSY. EXHAUST PIPE	TATA spare parts
278249200105	ASSY INTERMEDIATE PIPE	TATA spare parts
278249200107	ASSY PIPE 81.2 OD	TATA spare parts
278249200108	ASSY INTERMEDIATE PIPE 81.2 OD	TATA spare parts
278249200109	ASSY.EXHAUST PIPE.	TATA spare parts
278249200110	ASSY BRACKET(TAIL PIPE)	TATA spare parts
278249200112	ASSY BRACKET SILENCER	TATA spare parts
278249203302	CLAMP (TAIL PIPE)	TATA spare parts
278249208201	CLAMP (SILENCER MTG)	TATA spare parts
278254100101	ASSY.SUPPORT (COMPLETE)	TATA spare parts
278254100102	ASSY TRAY (SHEET METAL)	TATA spare parts
278254100103	ASSY.BATT CABLE +VE 50MM2	TATA spare parts
278254100104	ASSY BATTERY CABLE +VE-50 SQ.MM	TATA spare parts
278254100105	ASSY.BATTERY CABLE +VE	TATA spare parts
278254100109	ASSEMBLY BATTERY CARRIER	TATA spare parts
278254103201	CLAMPING STUD	TATA spare parts
278254106301	BATTERY TRAY (PLASTIC)	TATA spare parts
278254107701	PE FOAM MAT (FOR 180 AH BATTERY)	TATA spare parts
278254107703	RUBBER MAT (FOR 150AH BATTERY)	TATA spare parts
278254108201	CHANNEL (BATTERY CLAMPING)	TATA spare parts
278254108207	BRACKET(MAXI FUSE AND STARTER RELAY TC)	TATA spare parts
278254110101	ASSY BATT CABLE -VE 50mm2	TATA spare parts
278254110102	ASSY BATTERY CABLE -VE 50MM	TATA spare parts
278254200101	SPEEDOMETER(1:1.04)(BACKLIT)12V	TATA spare parts

278254208201	BRACKET(MAXI FUSE MTG.FRAME MOUNTED)	TATA spare parts
278254209901	SPEEDOMETER(1:1.04)(BACKLIT)12V	TATA spare parts
278254209902	SPEEDOMETER(1:1.04)(BACKLIT)12V-OFFER	TATA spare parts
278254209905	INSTRUMENT CLUSTER-1:1.04	TATA spare parts
278254209906	HIGH TEMP BUZZER UNIT(12V/24V)	TATA spare parts
278254209907	INSTRUMENT CLUSTER-1:0.88	TATA spare parts
278254209910	BUZZER ASSY	TATA spare parts
278254209911	TEMP. GAUGE WITH BUZZER ASSY	TATA spare parts
278254209915	WIPER CONTROLLER 12V BS4	TATA spare parts
278254209916	INSTRUMENT CLUSTER (1:1.04)	TATA spare parts
278254209917	INSTRUMENT CLUSTER (1;1.04)	TATA spare parts
278254209918	SPEEDOCABLE(JIS) 3100LG.	TATA spare parts
278254209937	INST.CLUSTER(ELECT)(1:1.04)	TATA spare parts
278254209938	INST.CLUSTER(ELECT)(1.04)	TATA spare parts
278254209941	INST.CLUSTER(ELECT)(1:1.04)	TATA spare parts
278254209942	TEMP TRANSDUCER	TATA spare parts
278254400105	ASSY.ECER.H/L EMARK BLB.LH/RHD-12V-OFF	TATA spare parts
278254400106	ASSY.E.CER.H/L EMARK BLB RH-RHD-12V-OFF	TATA spare parts
278254440101	ASSY H/L LH (RHD)24V W/O HLL MOT;COWL	TATA spare parts
278254440102	ASSY H/L RH (RHD)24V W/O HLL MOT;COWL	TATA spare parts
278254600103	W/H MAIN-LPT2515TC/LPS3015TC	TATA spare parts
278254600104	W/H PANEL LAMPS-LP FACE	TATA spare parts
278254600105	W/H GAUGES EARTHING-LP FACE	TATA spare parts
278254600106	WIRING HARNESS ENGINE LPT 1613C	TATA spare parts
278254600107	W/H STOP LT.SW.AND LP SW.	TATA spare parts
278254600108	ASSY.CLAMP	TATA spare parts
278254600113	W/H MAIN-LPT2515TC-CMVR	TATA spare parts
278254600114	W/H MAIN-LPT1613/2515TC CLSTR	TATA spare parts
278254600115	W/H ENGINE LPT1613/2515/LPS3015TC	TATA spare parts
278254600116	W/H TAIL-LPT2515TC_CMVR	TATA spare parts
278254600119	W/H MAIN LPT1613/2515TC BS-II MTR.LP	TATA spare parts
278254620101	WIRING HARNESS MAIN LPT2515TC 6 X 2	TATA spare parts
278254620102	WIRING HARNES TAIL LPT2515TC-6X2	TATA spare parts
278254620103	MAIN CABLE 2515	TATA spare parts
278254620104	LOOP CABLE 2515	TATA spare parts
278254620105	LOOP CABLE 2515	TATA spare parts
278254620106	WIRING HARNESS ENGINE LPT 2515TC/LPT1613	TATA spare parts
278254620108	W/H MAIN-LPT2515TC-CMVR	TATA spare parts
278254620120	W/H STOP LT.SW. AND LP SW.	TATA spare parts
278254620122	W/H ENGINE LPT1613/2515/LPS3015TC	TATA spare parts
278254620123	W/H TAIL-LPT2515TC_CMVR	TATA spare parts
278254620124	W/H MAIN-LPT1613/2515TC CLSTR	TATA spare parts
278254620125	W/H MAIN LPT1613/2515TC BS-II MTR.LP	TATA spare parts
278254620130	W/H TAIL(LPT2515TC/60 BS-II LP FACE)	TATA spare parts
278254660101	WIRING HARNESS MAIN LPT 2515TC	TATA spare parts
278254660102	WIRING HARNESS TAIL-LPT2515TC	TATA spare parts
278254660103	WIRING HARNESS ENGINE LPT 1613C	TATA spare parts

278254660106	W/H ENGINE LPT1613/2515/LPS3015TC	TATA spare parts
278254660107	W/H MAIN-LPT2515TC-CMVR	TATA spare parts
278254660108	W/H TAIL-LPT2515TC-CMVR	TATA spare parts
278254660110	W/H MAIN-LPT1613/2515TC CLSTR	TATA spare parts
278254660113	W/H MAIN LPT1613/2515TC BS-II MTR.LP	TATA spare parts
278254680101	W/H MAIN-LPT1613/2515TC CLSTR	TATA spare parts
278254680102	W/H ENGINE LPT1613/2515/LPS3015TC	TATA spare parts
278254680103	W/H TAIL-LPT2515TC_CMVR	TATA spare parts
278254680104	W/H MAIN LPT1613/2515TC BS-II MTR.LP	TATA spare parts
278258902501	ADJUSTMENT CHECKING GAUGE	TATA spare parts
278258902502	DRIFT FOR LOCKNUT ADJUSTMENT	TATA spare parts
278258902601	352 CERRAMIC PAD RIVETING TOOL	TATA spare parts
278258903501	DEPTH MEASUREMENT GAUGE-TAIL PINION	TATA spare parts
278258903502	DRIFT-INSTA.OUTER RACE OF HUB INNER BRG.	TATA spare parts
278258903503	PULLER-COUPPLING FLANGE & HUB ASSY.	TATA spare parts
278258903504	PULLER-OUTER RACE OF HUB OUTER TR BRG.	TATA spare parts
278258903505	PULLER- REMOVAL OF AXLE SHAFT	TATA spare parts
278258903506	DRIFT-INSTA. INNER RACE OF HUB OUTER BRG	TATA spare parts
278258903507	PULLER-REAR HUB INNER BRG WITH SEAL	TATA spare parts
278258903508	DRIFT-TAIL PINION OIL SEAL INSTALLATION	TATA spare parts
278258903509	PULLER-REMOVAL OF SPACER RA109RR HUB OUT	TATA spare parts
278260100101	ASSY COWL COMP WITH FITMENTS-RHD LPT2515	TATA spare parts
278260100102	ASSY BARE COWL 2515 TC-PAINTED	TATA spare parts
278260100103	ASSY COWL SHELL IN WHITE-RHD	TATA spare parts
278260100105	COWL COMPL WITH FITMENTS	TATA spare parts
278260100106	ASSY BARE COWL LPT2515TC	TATA spare parts
278260100110	ASSY COWL COMP. WITH FITTS RH2515 BS-II	TATA spare parts
278260100111	ASSY COWL SHELL PAINTED RHD-2515 BS-II	TATA spare parts
278260100114	ASSY COWL COMPL WITH FITMENTS-RHD2515	TATA spare parts
278260100115	ASSY COWL SHELL PAINTED-RHD	TATA spare parts
278260100118	ASSY COWL COMP. WITH FITMENTS RHD	TATA spare parts
278260100119	ASSY COWL SHELL PAINTED RHD	TATA spare parts
278260100122	ASSY COWL COMP WITH FITTS RH2518 BSIII	TATA spare parts
278260100123	ASSY COWL SHELL PAINTED RHD	TATA spare parts
278260100132	ASSY COWL COMP. WITH FITTS RH2515 BS-II	TATA spare parts
278260100132RF	ASSY COWL COMP. WITH FITTS RH2515 BS-II	TATA spare parts
278260100133	ASSY COWL SHELL PAINTED RHD-2515 BS-II	TATA spare parts
278260100137	ASSY COWL COMP. WITH FIT.-LPT2515TC BS2	TATA spare parts
278260100137SJ	ASSY COWL COMP 2515 TC BSII SPARE PARTS	TATA spare parts
278260100138	ASSY. COWL COMP. WITH FITMENTS	TATA spare parts
278260100139	ASSY. COWL SHELL PAINTED	TATA spare parts
278260100143	ASSY COWL COMPL. WITH FITMENTS-RHD	TATA spare parts
278260100143SJ	ASSY COWL COMPL.WITH FITMENTS-RHD(SPARE)	TATA spare parts
278260100145	ASSY.COWL COMPLETE WITH FITMENTS -RHD	TATA spare parts
278260100146	ASSY COWL COMPLETE WITH FITMENTS - RHD	TATA spare parts
278261600101	ASSY.PEDAL FLOOR RH-RHD(TO SUIT DTV)	TATA spare parts
278261600106	ASSY WHEEL ARCH RH-RHD	TATA spare parts

278261600113	ASSY BONNET FRONT COMPLETE RHD	TATA spare parts
278261600116	ASSY PEDAL FLOOR RH RHD	TATA spare parts
278270000102	KIT ASSY SUPD	TATA spare parts
278270108206	BRACKET FRONT	TATA spare parts
278270108207	BRACKET REAR	TATA spare parts
278270108208	BRACKET TOP	TATA spare parts
278281100108	KIT FOR ASSY REAR VIEW MIRROR COMPLETE	TATA spare parts
278281100109	ASSY T EMBLEM COMP.WITH GRILLE(OVAL STYL	TATA spare parts
278281106301	GRILLE PLATE(T EMBLEM)	TATA spare parts
278281106303	STICKER TURBO-INTERCOOLER	TATA spare parts
278281800101	ASSY TATA 2515 MASCOT	TATA spare parts
278281800104	ASSY TATA 2515 C EX MASCOT	TATA spare parts
278281800105	ASSY TATA 2515 EX MASCOT	TATA spare parts
278281800106	ASSY EX MASCOT	TATA spare parts
278281800107	ASSY TATA MASCOT	TATA spare parts
278281800108	ASSY TATA 2518 C MASCOT	TATA spare parts
278281800109	ASSY TATA 2518 MASCOT	TATA spare parts
278281800110	ASSY TATA 2516 MASCOT	TATA spare parts
278281900101	ASSY ENGINE SHIELDING LH-RHD	TATA spare parts
278281900102	ASSY ENGINE SHIELDING-RH-RHD	TATA spare parts
278281900105	ASSY ENGINE SHIELDING LH RHD	TATA spare parts
278281900108	ASSY ENGINE SHIELDING RH RHD	TATA spare parts
278281900109	ASSY. ENGINE SHIELDING RH RHD	TATA spare parts
278281900110	ASSY. ENGINE SHIELDING LH -RHD	TATA spare parts
278282406301	COVER WIPER MOTOR (LPT COWL)	TATA spare parts
278286900101	ASSY. CANOPY COMPLETE RHD	TATA spare parts
278288500108	ASSY DOUBLE BUMPER COMPLETE	TATA spare parts
278288500112	ASSY.BUMPER COMP.W/REFLECTOR&TAPE2515	TATA spare parts
278288500112C0	ASSY.BUMPER COMP.W/REFLECTOR & REF.TAPE	TATA spare parts
278288508205	SUPPORT SIDE LH	TATA spare parts
278288508206	SUPPORT SIDE RH	TATA spare parts
278288700101	ASSY. ENGINE HOOD COMP. BS1/2/3/4	TATA spare parts
278289100101	ASSY.BRACKET LH COWL MTG. FRONT	TATA spare parts
278289100102	ASSY.BRACKET LH COWL MTG.REAR	TATA spare parts
278289100103	ASSY. BRACKET RH COWL MTG. REAR	TATA spare parts
278289100107	ASSY. BRACKET LH (COWL MTG. REAR)	TATA spare parts
278289100108	ASSY. BRACKET RH (COWL MTG. REAR)	TATA spare parts
278291700101	ASSY MOUNTING BRACKET	TATA spare parts
278324200103	ASSY BRACKET LH-ENGINE MTG REAR TOP	TATA spare parts
278329100101	ASSY CONTROLS COMPLETE LPS3015/LPT1613	TATA spare parts
278329100102	ASSY. CONTROL MTG. BKT & TUBE	TATA spare parts
278329100110	ASSY. TUBE	TATA spare parts
278329100112	ASSY. TUBE	TATA spare parts
278329100113	ASSY. TUBE	TATA spare parts
278329100115	ASSY BKT-VRSGB MTG & CMC MTG	TATA spare parts
278329100116	ASSY PIPE	TATA spare parts
278329100117	ASSY CONTROL MTG BKT & TUBE	TATA spare parts

278329100121	ASSY.PIPE	TATA spare parts
278329100128	ASSY BRAKE PEDAL COMPLETE	TATA spare parts
278329100132	ASSY.PIPE	TATA spare parts
278329108201	BRACKET	TATA spare parts
278329500101	ASSY. M/CYL MTG BKT.	TATA spare parts
278330100101	ASSY PULL ROD-ACCELERATOR	TATA spare parts
278330100105	ASSY.ACCELERATOR CABLE MTG.BRACKET	TATA spare parts
278330100106	ASSY ACCELERATOR PEDAL WITH BRACKET	TATA spare parts
278330100107	ASSY PEDAL PLATE WITH COVER	TATA spare parts
278330100108	ASSY ACCELERATOR PEDAL	TATA spare parts
278330200101	ASSY.PULL CABLE-ENGINE STOP	TATA spare parts
278331000101	ASSY. FRAME COMPLETE 3015 LPS TC	TATA spare parts
278331000102	ASSY FRAME COMPLETE LPS3015TC 195 DEEP	TATA spare parts
278331000103	ASSY FRAME COMPLETE EX MODEL	TATA spare parts
278331000104	ASSY FRAME COMPLETE. 195 DEEP TAIL END	TATA spare parts
278331000105	ASSY.FRAME(2 DEG.INCLINED ENG.)709 TILT	TATA spare parts
278331000108	ASSY FRAME COMPLETE	TATA spare parts
278331100101	EXTENTION PIECE RH	TATA spare parts
278331100102	EXTENTION PIECE LH	TATA spare parts
278331200103	ASSY.ENGINE CROSS MEMBER (FRONT)	TATA spare parts
278332407101	CASTER PLATE RETRO FITMENT LPS3015TC	TATA spare parts
278341000101	KIT RETROFITMENT P/SHAFT LPS 3015TC	TATA spare parts
278341100101	ASSY PROP.SHAFT WITH CENTRE BRG FRONT	TATA spare parts
278341100107	ASSY PROP SHAFT W/CBRG FRONT LPS3015TC	TATA spare parts
278341113201	HEX. BOLT	TATA spare parts
278341116101	LOCKING PLATE	TATA spare parts
278341120101	ASSY PROP SHAFT COMPLETE REAR	TATA spare parts
278341120102	ASSY PROP SHAFT REAR LPS3015TC	TATA spare parts
278341120108	ASSY PROPELLER SHAFT COMPLETE	TATA spare parts
278341120110	ASSY.PROP.SHAFT CLOSED L=1775	TATA spare parts
278341120111	ASSY PROP SHAFT COMPLETE REAR	TATA spare parts
278341303301	BRACKET-CENTRE BEARING	TATA spare parts
278342100115	AUTO SLACK ADJUSTER WITH STRAIGHT ARM	TATA spare parts
278342100116	ASSY.F/A BRAKE WITH D/C-L.H AF23	TATA spare parts
278342100117	ASSY.F/A BRAKE WITH D/C-R.H AF23	TATA spare parts
278342100127	DRUM BRAKE ASSY FRONT -LH W/FASTN	TATA spare parts
278342100128	DRUM BRAKE ASSY FRONT -RH W/FASTN	TATA spare parts
278342100166	DRUM BRAKE ASSY F/A BRAKE LH (410X180)	TATA spare parts
278342100167	DRUM BRAKE ASSY F/A BRAKE RH (410X180)	TATA spare parts
278342300107	ASSY DRUM BRAKE RH W/DC.	TATA spare parts
278342300108	ASSY DRUM BRAKE LH W/DC.	TATA spare parts
278342300126	BRAKE ASSY REAR-LH	TATA spare parts
278342300127	BRAKE ASSY REAR-RH	TATA spare parts
278342400101	ASSY. PULL ROD	TATA spare parts
278342900129	ASSY.NYLON PIPE SET CHASSIS COMPLETE.	TATA spare parts
278342900130	SET OF NYLON PIPES COWL LP1512TC	TATA spare parts
278342900133	ASSY.NYLON PIPE-12 O.D.	TATA spare parts

278342900134	ASSY.NYLON PIPE-12 O.D.	TATA spare parts
278342900135	ASSY.NYLON PIPE 12 O.D.	TATA spare parts
278342900136	ASSY.NYLON PIPE 6 O.D.	TATA spare parts
278342900137	ASSY.NYLON PIPE-12 O.D.	TATA spare parts
278342900139	ASSY.METAL PIPE 15 O.D.	TATA spare parts
278342900140	ASSY.METAL PIPE 15 O.D.	TATA spare parts
278342900141	ASSY.METAL PIPE 15 O.D.	TATA spare parts
278342900144	NYLON TUBE AIR DRIER TO PURGE TANK LPS 3	TATA spare parts
278342900146	NYLON TUBE SPV TO RR AIR TANK LPS 3015TC	TATA spare parts
278342900148	NYLON TUBE RR AIR TANK TO PART BKT LPS 3	TATA spare parts
278342900150	NYLON TUBE TEE-5 TO RBC RH LPS 3015TC	TATA spare parts
278342900153	NYLON TUBE TEE-2 TO TCV BP LPS 3015TC	TATA spare parts
278342900154	NYLON TUBE FST TO PART BKT LPS 3015TC	TATA spare parts
278342900155	NYLON TUBE TEE-1 TO TEE-4 LPS 3015TC	TATA spare parts
278342900156	NYLON TUBE TEE-4 TO FBC RH LPS 3015TC	TATA spare parts
278342900157	NYLON TUBE TEE-4 TO FBC LH LPS 3015TC	TATA spare parts
278342900158	NYLON TUBE TEE-1 TO TCV TP LPS 3015TC	TATA spare parts
278342900159	NYLON TUBE SPV-23 TO TEE-3 LPS 3015TC	TATA spare parts
278342900160	NYLON TUBE TEE-3 TO TCV SP LPS 3015TC	TATA spare parts
278342900164	NYLON TUBE TEE-4 TO TCV MP LPS 3015TC	TATA spare parts
278342900165	NYLON TUBE TCV TO COILED HOSE RH LPS 301	TATA spare parts
278342900166	NYLON TUBE TCV TO COILED HOSE LH LPS 301	TATA spare parts
278342900172	ASSY.NYLON PIPE SET CAB COMPLETE	TATA spare parts
278342900181	ASSY.HOSE-SUPPLY LINE -RED	TATA spare parts
278342900182	ASSY.HOSE-CONTROL LINE-BLUE	TATA spare parts
278342903302	BRACKET	TATA spare parts
278342903303	BRACKET	TATA spare parts
278342906801	T SOCKET	TATA spare parts
278342906804	TEE CONNECTOR (PARTITION TYPE)	TATA spare parts
278342907701	GROMMET	TATA spare parts
278342950101	3/8 INCH HOSE ASSY	TATA spare parts
278342990101	BRACKET MACHNING LH	TATA spare parts
278342990102	BRACKET MACHNING RH	TATA spare parts
278342990105	DRUM BRAKE ASSY FRONT -MAJOR SPARE KIT	TATA spare parts
278342990133	BRAKE ASSY -KIT TORQUE PLATE FRONT LH	TATA spare parts
278342990134	BRAKE ASSY - KIT TORQUE PLATE FRONT RH	TATA spare parts
278342990135	KIT TORQUE PLATE LH	TATA spare parts
278342990136	KIT TORQUE PLATE RH	TATA spare parts
278342990137	KIT-BRAKE	TATA spare parts
278342990138	KIT-BRAKE RH	TATA spare parts
278342990140	KIT-BRAKE BRACKET ASSY LH	TATA spare parts
278342990141	KIT-BRAKE BRACKET ASSY RH	TATA spare parts
278342990142	KIT-CAMSHAFT LH	TATA spare parts
278342990143	KIT-CAMSHAFT RH	TATA spare parts
278342990144	KIT-BRAKE DUST SHIELD BS6	TATA spare parts
278342990146	KIT-BRAKE LINE SHOE ASSY	TATA spare parts
278343200101	ASSY. AIR TANK	TATA spare parts

278343200104	ASSY. AIR TANK	TATA spare parts
278343200106	ASSY.BKT (AIR TANK & PURGE TANK MTG).	TATA spare parts
278343700101	AUTOMATIC LOAD SENSING VALVE	TATA spare parts
278343700106	AUTOMATIC LOAD SENSING VALVE	TATA spare parts
278344100102	ASSY PUMP DOUBLE ACTING	TATA spare parts
278344100103	ASSY HYD CYLINDER-CAB TILTING	TATA spare parts
278344100104	ASSY PUMP DOUBLE ACTING	TATA spare parts
278344100105	ASSY.HYD.CYL.-CAB TILTING	TATA spare parts
278344103401	NYLON BUSH	TATA spare parts
278344106701	PIN-CYL MTG ON CAB	TATA spare parts
278344108601	SPACER	TATA spare parts
278346100101	ASSY. BRACKET-STG G.BOX MTG	TATA spare parts
278346200103	ASSY.COLUMN WITHOUT STEERING WHEEL	TATA spare parts
278346200104	ASSY. STEERING SPINDLE	TATA spare parts
278346200105	ASSY. STEERING COLOUM	TATA spare parts
278346200106	ASSY. STEERING SPINDLE	TATA spare parts
278346200110	ASSY.STEERING SPINDLE	TATA spare parts
278346207901	STEERING SPINDLE BOTTOM	TATA spare parts
278346207902	STEERING SPINDLE BOTTOM	TATA spare parts
278346207908	STEERING SPINDLE BOTTOM	TATA spare parts
278346305101	PITMAN ARM	TATA spare parts
278346400101	ASSY. STEERING WHEEL-550 DIA	TATA spare parts
278346400104	ASSY. STG.WHEEL DIA 550	TATA spare parts
278346600101	DRAG LINK	TATA spare parts
278346600102	DRAG LINK	TATA spare parts
278346600103	DRAG LINK	TATA spare parts
278347100104	ASSY. FUEL TANK COMP. 225 LTR RD BS1- 4	TATA spare parts
278347600105	ASSY FUEL RETURN LINE.	TATA spare parts
278347600106	ASSY FUEL PIPE SUCTION	TATA spare parts
278347600110	ASSY FUEL RETURN LINE	TATA spare parts
278347600112	ASSY.SUCTION PIPE	TATA spare parts
278347600113	ASSY RETURN LINE.	TATA spare parts
278349100106	ASSY.SILENCER WITH TAIL PIPE	TATA spare parts
278349100107	ASSY MUFFLER	TATA spare parts
278349200107	ASSY.EXHAUST PIPE. 81.2DIA.	TATA spare parts
278349208203	CLAMP	TATA spare parts
278349208211	BRACKET	TATA spare parts
278354100101	ASSY.FRAME-FOR BATT.CARRIER	TATA spare parts
278354100102	ASSY.BATTERY CABLE +VE CU	TATA spare parts
278354110101	ASSY.BATTERY CABLE -VE CU	TATA spare parts
278354209901	INSTRUMENT CLUSTER-1:1.04	TATA spare parts
278354209905	INSTRUMENT CLUSTER (1:1.04)	TATA spare parts
278354400101	ASSY.TAIL LAMP BRACKET RH	TATA spare parts
278354600102	W/H JUMPER CABLE-OFFER	TATA spare parts
278354600106	W/H TAIL (LPS3015TC W/709 TLT CAB)OFFER	TATA spare parts
278354600107	W/H MAIN-LPS3015TC_INST.CLUSTER	TATA spare parts
278354600108	W/H TAIL-LPS3015TC_CMVR	TATA spare parts



278354600109	W/H MAIN LPS3015TC BS-II	TATA spare parts
278354600110	W/H MAIN(LPS3015TC BS-II LP MOTH/L)	TATA spare parts
278354600111	W/H CONSOLE (LPS3015TC BS-II TLT MH/L)	TATA spare parts
278354600112	W/H TAIL (LPS3015TC/32 BS-II TLT)	TATA spare parts
278354600115	W/H TAIL (LPS3015TC/32 BS-II LP)	TATA spare parts
278354609901	JUMPER CABLE	TATA spare parts
278354620101	LOOP CABLE 2515	TATA spare parts
278354620102	LOOP CABLE 2515	TATA spare parts
278354620103	W/H TAIL-LPS3015/32TC	TATA spare parts
278354620109	W/H MAIN(LPS3015TC TLT_SLR_CMVR_RLY)	TATA spare parts
278354620110	W/H TAIL-LPS3015TC_CMVR	TATA spare parts
278354620111	W/H MAIN-LPS3015TC_INST.CLUSTER	TATA spare parts
278354620112	W/H MAIN(LPS3015TC BS-II LP MOT.H/L)	TATA spare parts
278354620113	W/H TAIL (LPS3015TC/32 BS-II LP)	TATA spare parts
278354620114	W/H MAIN LPS3015TC BS-II	TATA spare parts
278354620115	W/H CONSOLE (LPS3015TC BS-II TLT MH/L)	TATA spare parts
278354620116	W/H TAIL (LPS3015TC/32 BS-II TLT)	TATA spare parts
278354660102	ASSY JUMPER CABLE	TATA spare parts
278354660103	W/H TAIL-LPS3015/32TC	TATA spare parts
278354660105	W/H TAIL-LPS3015TC_CMVR	TATA spare parts
278354660110	W/H MAIN-LPS3015TC_INST.CLUSTER	TATA spare parts
278354660111	W/H MAIN(LPS3015TC BS-II LP MOTH/L)	TATA spare parts
278354660112	W/H TAIL (LPS3015TC/32 BS-II LP)	TATA spare parts
278360100101	ASSY COWL COMPLETE WITH FITMENTS	TATA spare parts
278360100102	ASSY BARE COWL LPS 3015TC	TATA spare parts
278360100110	ASSY COWL COMP. WITH FITMENTS 3015PS	TATA spare parts
278360100113	ASSY.COWL COMPL.WITH FITS.3015 RHD	TATA spare parts
278360100114	ASSY.COWL SHELL PAINTED-LPT2515 BS2	TATA spare parts
278388500107	ASSY DOUBLE BUMPER COMPLETE	TATA spare parts
278389100101	ASSY MTG BRACKET COWL LH LP1512TC	TATA spare parts
278389100102	ASSY MTG BRACKET COWL RH LP1512TC	TATA spare parts
278454100103	ASSY SUPPORT	TATA spare parts
278454100108	ASSY SUPPORT BATTERY MTG.	TATA spare parts
278454108201	CLAMP TOP (BATTERY CLAMPING)	TATA spare parts
278501170104	ASSY.OIL FILLER PIPE	TATA spare parts
278501173302	BRACKET	TATA spare parts
278501174201	CLAMP	TATA spare parts
278503114701	BOTTOM COVER-FLYWHEEL HSG	TATA spare parts
278503118001	SCREW-FLYWH HSG	TATA spare parts
278509113301	BRACKET-FUEL FILTER MTG	TATA spare parts
278509114201	CLAMP-FUEL FILTER	TATA spare parts
278509118001	SCREW-FUEL FILTER MTG	TATA spare parts
278509130101	STRAP W/SHACKLE	TATA spare parts
278509130108	ASSY.PIPE WITH FLANGE.	TATA spare parts
278509130117	PIPE W/FLANGE	TATA spare parts
278509130129	AIR FILTER ASSY	TATA spare parts
278509130149	BRACKET	TATA spare parts

278509134201	CLAMP	TATA spare parts
278509135801	HOSE A/FILTER OUTLET	TATA spare parts
278509135805	HOSE-TC INLET	TATA spare parts
278509135806	HOSE A/FILTER OUTLET	TATA spare parts
278509135807	L HOSE.	TATA spare parts
278509135823	HOSE-114 I.D.X 130 L	TATA spare parts
278509135826	HOSE	TATA spare parts
278509139901	RUBBER STRAP	TATA spare parts
278509139902	AIR FILTER ELEMENT-PRIMARY	TATA spare parts
278509139903	AIR FILTER ELEMENT-SAFETY	TATA spare parts
278513136802	COUPLING BODY ON AIR COMP	TATA spare parts
278513136901	BEND TUBE-FROM AIR INTAKE PIPE	TATA spare parts
278513136902	TUBE-ON A.COMP SUCTION	TATA spare parts
278513136903	BEND TUBE-LHD	TATA spare parts
278514603802	PIPE-ALUMINIUM	TATA spare parts
278514603803	PIPE ALU IC TO ENGINE	TATA spare parts
278514605801	HOSE AIR INTAKE	TATA spare parts
278514605802	HOSE INTER TC TO IC	TATA spare parts
278514605803	HOSE INLET MANIFOLD	TATA spare parts
278514606901	L PIPE-76.2 X 1.63 THK.	TATA spare parts
278514609902	INTERCOOLER	TATA spare parts
278550105801	HOSE RAD TO WATER PUMP	TATA spare parts
278550105802	HOSE ENG TO RADIATOR	TATA spare parts
278550105803	HOSE RADIATOR	TATA spare parts
278550105804	HOSE-8 ID X 90 L	TATA spare parts
278550406901	TUBE -RAD.MTG. 59 L	TATA spare parts
278550406902	SPACER TUBE-15 L	TATA spare parts
278600999908	BALL BEARING	TATA spare parts
278600999909	COMPOUND	TATA spare parts
278601000110	ASSY.6BTAA(160HP)-ENG.OPTION DETAILS 12V	TATA spare parts
278601000111	ASSY.6BTAA(210HP)ENG-12V OPTION DETAILS.	TATA spare parts
278601000138	ENGINE 6BT 24V 125 HP	TATA spare parts
278601000147	ASSY.6BTAA 160HPENG.OPTION DETAILS 24V	TATA spare parts
278601000148	ENGINE 6BTAA 12V 160HP	TATA spare parts
278601000150	ASSY.6BTAA(160HP)24V W/O CLUTCH&CL.HSG.	TATA spare parts
278601000173	ENGINE 6BTAA(160 HP)3516	TATA spare parts
278601000176	ASSY 6BT CUMMINS ENG.24V	TATA spare parts
278601000179	ASSY.6BTAA(160HP)ENG OPTION LIST(LPO1316	TATA spare parts
278601000188	ENGINE LPT1615 145HP 12V	TATA spare parts
278601000195	ASSY 6B5.9 100HP CNG(STOICH)ENGINE1510CN	TATA spare parts
278601000196	ASSY6BT 145HPENG OPT.DETAILS LPS2615TC	TATA spare parts
278601000199	2515/3015 ENGINE 6BT 145HP 12V CUMMINS	TATA spare parts
278601000220	ASSY.6BTAA ENGINE-160HP 4PT.ENG MTG	TATA spare parts
278601000223	ASSY.6BT(145HP) 4PT ENG MT	TATA spare parts
278601000224	ASSY. ENGINE 6BT 125HP 24V LMRO BS2/3	TATA spare parts
278601000225	ASSY.6BTAA ENGINE-210HP 4PT.ENG MTG	TATA spare parts
278601000285	ASSY ENGINE 1510 CNG	TATA spare parts

278601000301	CYL HEAD ASSY W/ VALVES 1510CNG	TATA spare parts
278601000302	KIT ENGINE PISTON	TATA spare parts
278601000303	ASSY CORBURETTOR	TATA spare parts
278601000306	DRIVE DISTRIBUTOR	TATA spare parts
278601000307	DISTRIBUTOR	TATA spare parts
278601000309	IGNITION CABLE	TATA spare parts
278601000310	MANIFOLD EXHAUST	TATA spare parts
278601000312	PROBE	TATA spare parts
278601000313	COIL IDNITION	TATA spare parts
278601000314	MIXER AIR FUEL	TATA spare parts
278601000315	SPEED CONTROLLER	TATA spare parts
278601000316	SENSOR OXYGEN	TATA spare parts
278601000317	VALVE SOLENOID	TATA spare parts
278601000318	VALVE SHUTOFF	TATA spare parts
278601000319	HARNES WIRING	TATA spare parts
278601000322	LPR REGULATOR	TATA spare parts
278601000326	CATALYTIC CONVERTER	TATA spare parts
278601000327	SPRING - THROTTLE RETURN	TATA spare parts
278601000337	ENG 6BTAA-160HP-12V-LMFO	TATA spare parts
278601000341	ENGINE 6BT 125HP 12V-LMFO-VISCOUSFAN	TATA spare parts
278601000344	ENG 6BTA LPT2516TC-LMFO-VISCOUS EURO-I	TATA spare parts
278601000351	ENGINE 6BT-125HP24V.V.FAN W CL&CL.HSG-LP	TATA spare parts
278601000357	ENG 6BT-160HP LMFO FIX.FAN 12 V LPK2516	TATA spare parts
278601000372	ENG 6BTALPS3516-LMFO-VISCOUS-AC-EURO I	TATA spare parts
278601000375	ENGINE 6BTA-160HP-24V-LMFO-VISCOUS FAN	TATA spare parts
278601000385	ASSY ENGINE 2515/LPT3015 7 BLADE FAN	TATA spare parts
278601000389	ASSY ENG 125 HP 310 DCL W/O P STRG PU	TATA spare parts
278601000390	ASSY ENG 125 HP 310 DCL	TATA spare parts
278601000391	ASSY ENG 125 HP 310 DCL	TATA spare parts
278601000398	ASSY.ENG.160HP E-II NONLOWD 24V LMFO	TATA spare parts
278601000399	ASSY ENGINE 6BTAA 160HP EII 24V LMFO NON	TATA spare parts
278601010103	ASSY 6B5.9 CNG CONTACTLESS DISTRI.ENG.	TATA spare parts
278601010105	ENGINE OPTION LIST 6BT 125HP 24V LMRO	TATA spare parts
278601010108	ENGINE 6BT 145HP 12V LMRO-V.FAN	TATA spare parts
278601010109	ENG.OPT.LIST 6BT 145HP 12V LMRO-7BLADEFF	TATA spare parts
278601010116	ENGINE-6BT-125HP-EURO-II.V.FAN 1613	TATA spare parts
278601010124	OPTION LIST-145HP-12V-V.FAN(LPK1615TC)	TATA spare parts
278601010129	ASSY.ENGINE COMPLETE 180 HP 24V BIPOLAR	TATA spare parts
278601010130	ENGINE LPT1613TC 125HP 6BTAA 12V EII	TATA spare parts
278601010135	ENGINE ASSY B5.9 CNG GAS STOICHIOMETRIC	TATA spare parts
278601010156	ENGINE ASSY-180HP-24V-LMFO(1518)	TATA spare parts
278601010158	ASSY. ENGINE COMPLETE 6 BTAA 180 HP EUR	TATA spare parts
278601010160	ENGINE ASSY 6BTAA 180HP 24V-LMRO.	TATA spare parts
278601010163	ASSY ENGINE 6BTAA-145HP-12V LMRO LPT2515	TATA spare parts
278601010164	ENGINE OPTION LIST-6BTAA-145HP-12V-LMFO.	TATA spare parts
278601010173	ENG. OPTION LIST 6BT 180HP 24V LMFO BS2	TATA spare parts
278601010175	ASSY ENGINE 6BTAA-235HP-24V-LMFO	TATA spare parts

278601010176	ASSY ENGINE 130HP BS3 24V-VP14-LMRO	TATA spare parts
278601010177	ENGINE ASSY B5.9 CNG GAS STOICH. BSIII	TATA spare parts
278601010178	ASSY. 6BTAA (235 HP) ENGINE	TATA spare parts
278601010190	ENGINE 180HPE-II LMFO 24V 45AMP ALTERNAT	TATA spare parts
278601010194	ENGINE 6BTAA-145HP-12V-LMFO BS2	TATA spare parts
278601010197	ENGINE 6BTAA-125HP-12V-LMFO LPT1613	TATA spare parts
278601010200	ENG.OPT.LIST6BTAA-145HP-12V-LMFO LPT2515	TATA spare parts
278601010206	CAB LPT 2515 T E II.145HP-12V-LMFO - NEW	TATA spare parts
278601010208	ASSY. ENGINE COMPLETE 6BTAA 180HP 24V-LM	TATA spare parts
278601010209	ENGINE 6BTAA-160HP-24V-LMFO	TATA spare parts
278601010212	ENGINE 6B5.9TAA-235HP-BSII(LPS4923)	TATA spare parts
278601010214	ENGINE 6BTAA-235HP-24V-LMRO	TATA spare parts
278601010223	ENGINE ASSY. 6B5.9CNG-110HP-STOIC.	TATA spare parts
278601010230	ENGINE COMPLETE-235HP-BS II 45 AMP.ALTER	TATA spare parts
278601010233	ASSY ENGINE COMPLETRE LPS 4018 BS3 LMFO	TATA spare parts
278601010235	ENGINE LPT 2518TC BS3 COWL	TATA spare parts
278601010236	ASSY ENGINE COMPLETE LPS 4018 BS3 LMFO U	TATA spare parts
278601010239	ENGINE LPT2518TC BS3 TILTCAB	TATA spare parts
278601010240	ENGINE LPT3118TC BS2 COWL NONAC	TATA spare parts
278601010242	ENGINE LPT2518 TC BS 2 COWL	TATA spare parts
278601010247	ENGINE 6BTTA 180HP-24V-LMFO-BS3	TATA spare parts
278601010248	ASSY ENGINE COMPLETE 6BTTA-180HP-24V-LMR	TATA spare parts
278601010252	ASSY ENGINE COMPLETE LPT 2513C BS3 130 H	TATA spare parts
278601010255	ENGINE 180HP BS2 LMFO(380CL)	TATA spare parts
278601010256	ENGINE 6BT 180HP BS2 380D CL.LMFO(1518-S	TATA spare parts
278601010259	ENGINE LPT/LPK1618 BSII T/CAB	TATA spare parts
278601010289	ENGINE LPT2518TC BS3 COWL	TATA spare parts
278601010290	2518ç BS3 -1210 COWL 180HPç - 352 DIA CL	TATA spare parts
278601010296	ENGINE HYBRID CNG	TATA spare parts
278601010307	ENG. OPTION LIST 4018 NEW RECIPE BS3	TATA spare parts
278601010308	ASSY ENGINE COMPLETE-215HP-BS III	TATA spare parts
278601010309	ENGINE LPT2518TC BS3 TILTCAB	TATA spare parts
278601010310	ENGINE 6BTTA-180HP-24V-LMFO-BS3	TATA spare parts
278601010314	ENGINE LPT 2518TC BS3 NEW RCP	TATA spare parts
278601010325	ENGINE OPTION LIST 6BTAA-130HP-24V	TATA spare parts
278601010326	ENGINE LPT1613TC BS3 COWL	TATA spare parts
278601010327	ENGINE 6BTAA-125HP-24V-LMFO NEW REC	TATA spare parts
278601010348	ENGINE LPT2518TC BS3 COWL	TATA spare parts
278601010350	ENGINE LPT3118TC BS3 COWL	TATA spare parts
278601010353	ASSY. ENGINE COMP. 6BT 180HP BS1/2	TATA spare parts
278601010354	ASSY ENG COMPLETE LPS 4018 UNIPOLAR BS3	TATA spare parts
278601010362	ENGINE	TATA spare parts
278601010366	ENGINE	TATA spare parts
278601010371	ENGINE ASSY	TATA spare parts
278601010373	6BTAA-180HP-24V-LMFO-EII	TATA spare parts
278601010375	ENGINE ASSY	TATA spare parts
278601010378	ENGINE LPT 1615	TATA spare parts

278601010381	ENGINE TC BS3 215HP LPT1623TC	TATA spare parts
278601010386	ENGINE LPT 1615/62 BS3	TATA spare parts
278601010398	ASSY. ENGINE COMP. 6BT 180HP LMRO BS3	TATA spare parts
278601020103	ASSY. ENGINE COMP.6BT LPK 2518 BS3	TATA spare parts
278601020205	ENGINE LPT2518TC BS3 COWL	TATA spare parts
278601020206	ENGINE LPT 3118 BS3 NEW RECIPE	TATA spare parts
278601020207	ASSY. ENGINE COMP. ISBE5.9-230HP BS3	TATA spare parts
278601020209	ENGINE LIST 2523.T LCCR	TATA spare parts
278601020210	ASSY ENGINE COMPLETE(2523.T LCCR NON AC)	TATA spare parts
278601020216	ASSY. ENGINE ISBE5.9 BS3	TATA spare parts
278601020217	ENGINE ASSY COMPLETE (2523.T AC LCCR)	TATA spare parts
278601020237	ASSY. ENGINE COMP. ISBE5.9 180 HP 40 BS4	TATA spare parts
278601020239	ENGINE OPTION LIST	TATA spare parts
278601020241	ENGINE OPTION LIST	TATA spare parts
278601020243	ASSY. ENGINE COMP. 6BT BS3	TATA spare parts
278601020253	ASSY. ENGINE COMP. 6BT BS3	TATA spare parts
278601020261	ENGINE COMPLETE-(OPTION LIST)	TATA spare parts
278601020275	ENGINE OPTION LIST	TATA spare parts
278601020298	ASSY. ENGINE COMP.6BT LPK 2518 BS3	TATA spare parts
278601020299	ENGINE ASSY	TATA spare parts
278601020301	ENGINE OPTION LIST	TATA spare parts
278601020311	ENGINE-OPTION DRG	TATA spare parts
278601020316	ENGINE OPTION LIST	TATA spare parts
278601020345	ENGINE COMPLETE (OPTION LIST)	TATA spare parts
278601020348	ENGINE - OPTION LIST	TATA spare parts
278601020360	ENGINE OPTION LIST	TATA spare parts
278601020361	ENGINE OPTION LIST	TATA spare parts
278601020365	ENGINE SIGNA LPS 4923 TC BS4	TATA spare parts
278601020367	ENGINE OPTION LIST	TATA spare parts
278601020369	ENGINE OPTION LIST	TATA spare parts
278601020382	ENGINE OPTION LIST	TATA spare parts
278601020383	ENGINE OPTION LIST	TATA spare parts
278601020385	ENGINE OPTION LIST	TATA spare parts
278601020387	ENGINE OPTION LIST	TATA spare parts
278601020393	ENGINE OPTION LIST	TATA spare parts
278601020397	ENGINE OPTION LIST	TATA spare parts
278601020399	ENGINE-OPTION LIST	TATA spare parts
278601020402	COVER VALVE	TATA spare parts
278601030101	ASSY. ENGINE COMP. ISBE5.9 UMB BS4	TATA spare parts
278601030103	ENGINE OPTION LIST	TATA spare parts
278601030110	ENGINE COMPLETE-OPTION LIST	TATA spare parts
278601030115	ENGINE OPTION LIST	TATA spare parts
278601030119	ENGINE OPTION LIST	TATA spare parts
278601030121	ENGINE OPTION LIST	TATA spare parts
278601030123	ENGINE OPTION LIST	TATA spare parts
278601030124	ENGINE OPTION LIST	TATA spare parts
278601030125	ENGINE OPTION LIST	TATA spare parts

278601030131	ENGINE OPTION LIST	TATA spare parts
278601030135	ENGINE OPTION LIST	TATA spare parts
278601030146	ENGINE OPTION LIST	TATA spare parts
278601030149	ENGINE OPTION LIST	TATA spare parts
278601030159	ENGINE-OPTION LIST	TATA spare parts
278601030162	ENGINE COMPLETE (OPTION LIST)	TATA spare parts
278601030167	ENGINE-OPTION LIST	TATA spare parts
278601030187	ENGINE-OPTION LIST	TATA spare parts
278601030188	ENGINE-OPTION LIST	TATA spare parts
278601030191	ENGINE-OPTION LIST	TATA spare parts
278601030193	ENGINE-OPTION LIST	TATA spare parts
278601030197	ENGINE-OPTION LIST	TATA spare parts
278601030207	ENGINE-OPTION LIST	TATA spare parts
278601030222	ENGINE-OPTION LIST	TATA spare parts
278601030224	ENGINE-OPTION LIST	TATA spare parts
278601030231	ENGINE-OPTION LIST	TATA spare parts
278601030243	ENGINE-OPTION LIST	TATA spare parts
278601030301	ASSY. ENGINE ISBE5.9 180 HP 40 BS4	TATA spare parts
278601030303	ENGINE OPTION LIST	TATA spare parts
278601153801	AIR INTAKE ELBOW	TATA spare parts
278601153804	AIR INTAKE ELBOW(LPT2523TC)	TATA spare parts
278601170028	DIPSTICK BRACKET ASM	TATA spare parts
278601170105	ASSY PIPE OIL FILLER	TATA spare parts
278601170106	PIPE OIL FILLER	TATA spare parts
278601170107	PIPE OIL FILLER	TATA spare parts
278601170112	ASSY OIL FILLER PIPE LPT 2515TC	TATA spare parts
278601170113	ASSY.BRACKET (FOR OIL FILLER CLAMPING)	TATA spare parts
278601170117	ASSY. BRACKET (FOR OIL FILLER CLAMPING)	TATA spare parts
278601170119	ASSY.OIL FILLER PIPE COMPLETE	TATA spare parts
278601170121	ASSY OIL FILLER PIPE	TATA spare parts
278601170129	ASSY. BRACKET(FOR DIPSTICK MTG.)	TATA spare parts
278601173302	BRACKET FOR DIPSTICK TUBE CLAMPING	TATA spare parts
278601173306	BRACKET-FOR DIPSTICK TUBE CLAMPING	TATA spare parts
278601173309	BRACKET	TATA spare parts
278601173310	BRACKET(DIPSTICK MTG-LPS3516TC)	TATA spare parts
278601173319	BRACKET(FOR DIPSTICK TUBE	TATA spare parts
278601173323	BRACKET(FOR OIL FILLER TUBE MTG.)	TATA spare parts
278601173326	BRACKET DIP STICK MOUNTING	TATA spare parts
278601173327	BRACKET-DIPSTIC TUBE MTG.	TATA spare parts
278601173330	BRACKET(DIPSTICK MOUNTING)	TATA spare parts
278601173331	SUPPORT-DIPSTICK TUBE MTG.	TATA spare parts
278601173334	BRACKET(FOR DIPSTICK TUBE MTG)	TATA spare parts
278601173336	BRACKETDIPSTICK TUBE CLAMPING	TATA spare parts
278601173337	BRACKET	TATA spare parts
278601174203	CLAMP-OIL FILLING PIPE	TATA spare parts
278601174204	CLAMP (FOR DIPSTICK TUBE).	TATA spare parts
278601174208	CLAMP	TATA spare parts

278601174211	CLAMP FOR OIL FILING PIPE	TATA spare parts
278601174213	CLAMP (FOR DIPSTICK TUBE)	TATA spare parts
278601174215	CLAMP(FOR OIL FILL PIPE ON RAD FRAME)	TATA spare parts
278601989902	COVER GEAR	TATA spare parts
278601989903	ISOLATOR VALVE BS1/2/3/4	TATA spare parts
278601989905	CNG LONG BLOCK BSIII	TATA spare parts
278601989906	GASKET CYLINDER HEAD	TATA spare parts
278601989907	ASSLY CYLINDER HEAD	TATA spare parts
278601989909	PLUG EXPANSION	TATA spare parts
278601989910	PLUG EXPANSION	TATA spare parts
278601989911	PLUG EXPANSION	TATA spare parts
278601989912	GASKET INT MANIFOLD COVER	TATA spare parts
278601989914	HEAD,CYLINDER B5.9 CNG	TATA spare parts
278601989915	COVER INTAKE MANIFOLD	TATA spare parts
278601989916	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278601989918	GASKET VALVE COVER (3930906) BS1/3	TATA spare parts
278601989919	COVER VALVE	TATA spare parts
278601989920	SCREW CPT ISOLATOR CAP	TATA spare parts
278601989921	CONNECTION MALE BS1/3	TATA spare parts
278601989922	CLAMP INJECTOR	TATA spare parts
278601989923	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278601989924	TUBE INJECTOR FUEL SUPPLY BS1/3	TATA spare parts
278601989925	TUBE INJECTOR FUEL SUPPLY BS1/3	TATA spare parts
278601989926	INJECTOR	TATA spare parts
278601989927	COVER PUSH ROD	TATA spare parts
278601989928	LONG BLOCK 130 HP BSIII	TATA spare parts
278601989929	LINER CYLINDER COLLERED	TATA spare parts
278601989929DFFF	CYLINDER LINER SET 6BT STD FF COL BS2/3/	TATA spare parts
278601989929DFSF	CYLINDER LINER SET 6BT STD SF COL BS2/3/	TATA spare parts
278601989929DFSF10	CYLINDER LINER SET 6BT OS10 SF COL BS2/3	TATA spare parts
278601989929DFSF20	CYLINDER LINER SET 6BT OS20 SF COL BS2/3	TATA spare parts
278601989929DFSF30	CYLINDER LINER SET 6BT OS30 SF COL BS2/3	TATA spare parts
278601989929DFSF40	CYLINDER LINER SET 6BT OS40 SF COL BS2/3	TATA spare parts
278601989929DFSF50	CYLINDER LINER SET 6BT OS50 SF COL BS2/3	TATA spare parts
278601989929DFSF60	CYLINDER LINER SET 6BT OS60 SF COL BS2/3	TATA spare parts
278601989931	BREATHER CRANK CASE	TATA spare parts
278601989932	NAME PLATE	TATA spare parts
278601989933	RING RETAINING	TATA spare parts
278601989934	BREATHER CRANKCASE BS1/2/3/4	TATA spare parts
278601989935	NIPPLE PLAIN HEXAGON BS4	TATA spare parts
278601989936	PLUG EXPANSION	TATA spare parts
278601989936AE	PLUG EXPANSION 1628	TATA spare parts
278601989940	PLUG EXPANSION	TATA spare parts
278601989941	HOUSING THERMOSTAT	TATA spare parts
278601990107	ASSY LONG BLOCK-LPO1510CGS	TATA spare parts
278601990110	BLOCK CYLINDER 6BT BS1/2/3	TATA spare parts
278601990112	ASSY. CYLINDER HEAD W/VALVES BS1/2/3	TATA spare parts

278601990117	LONG BLOCK 6BT EURO2 BS2/3 EURO2	TATA spare parts
278601990118	GASKET CYLINDER HEAD 6BT BS1/2/3/4	TATA spare parts
278601990118DF	GASKET CYLINDER HEAD-6BT TC BS2	TATA spare parts
278601990124	INJECTOR BS1/3	TATA spare parts
278601990125	KIT-LOWER ENGINE GASKET BS3	TATA spare parts
278601990126	FULL ENGINE GASKET KIT BS1	TATA spare parts
278601990127	HOUSING GEAR	TATA spare parts
278601990128	LONG BLOCK 180 HP BS3 MECH NEW RECIPE	TATA spare parts
278601990129	LONG BLOCK 180 HP BS3 MECH NEW RECIPE	TATA spare parts
278601990143	DIPSTICK	TATA spare parts
278601990145	LONG BLOCK - LPS 4923 BS III	TATA spare parts
278601990194	LONG BLOCK 4V MECH BSIII	TATA spare parts
278601990194AE	LONG BLOCK 4V MECH BSIII	TATA spare parts
278601990195	LONG BLOCK - LPO1612 TC BS III	TATA spare parts
278601990196	CAP FILLER BS1/3/4/6	TATA spare parts
278601990197	SET-UPPER ENGINE GASKET 6BT BS3	TATA spare parts
278601990197AE	UPPER ENGINE GASKET KIT	TATA spare parts
278601990197DF	GASKET KIT-UPPER 6BT TC BS3	TATA spare parts
278601990198	SET-GASKET LOWER ENGINE 6BT BS1/3	TATA spare parts
278601990198AE	LOWER ENGINE GASKET KIT	TATA spare parts
278601990198DF	GASKET KIT-LOWER 6BT TC BS3	TATA spare parts
278601990200	KIT-BREATHER BS1/2/3	TATA spare parts
278601990207	INJECTOR	TATA spare parts
278601990211	LONG BLOCK 6BT BS3 (REAR SUMP)	TATA spare parts
278601990212	LONG BLOCK 6BT BS3 (FRONT SUMP) BS1/3	TATA spare parts
278601990213	ASSY. CYLINDER HEAD	TATA spare parts
278601990216	TURBOCHARGER	TATA spare parts
278601990217	KIT FRONT SEAL SERVICE	TATA spare parts
278601990222	BLOCK CYLINDER ISBE 5.9 BS3/4	TATA spare parts
278601990226	KIT-GASKET UPPER BS3	TATA spare parts
278601990227	KIT-GASKET LOWER BS3/4	TATA spare parts
278601990228	LONG BLOCK ISBE 5.9 LPS 4923 BS3	TATA spare parts
278601990234	CYLINDER HEAD	TATA spare parts
278601990235	HEAD CYLINDER W/O VALVES ISBe5.9 BS4	TATA spare parts
278601990236	HEAD CYLINDER	TATA spare parts
278601990237	KIT-GASKET ENGINE ISBE5.9 BS4	TATA spare parts
278601990238	KIT- GASKET UPPER ISBE5.9 BS4	TATA spare parts
278601990268	SET-GASKET FULL ENGINE BS3/4	TATA spare parts
278601990269	ASSY. LONG BLOCK 6BT 235 HP 24V BS2	TATA spare parts
278601990270	LONG BLOCK ISBe5.9 BS3 (LPO1618)	TATA spare parts
278601990281	HEAD CYLINDER	TATA spare parts
278601990282	CYLINDER HEAD ASSY	TATA spare parts
278601990284	CYLINDER HEAD ASSY	TATA spare parts
278601990285	CYLINDER HEAD ASSY	TATA spare parts
278601990286	LONG BLOCK ISBE5.9 NORMAL/FRONT SUMP BS4	TATA spare parts
278601990289	HEAD,CYLINDER B5.9 BS1/BS2	TATA spare parts
278601990290	ASSY. CYLINDER HEAD ISB5.9 BS3	TATA spare parts



278601990299	LONG BLOCK ASSY	TATA spare parts
278601990301	OIL SUMP	TATA spare parts
278601990302	HEAD CYLINDER 6BT BS1/3	TATA spare parts
278601990304	CYLINDER HEAD ASSY	TATA spare parts
278601990305	HEAD CYLINDER WITH VALVES ISBe5.9 BS4	TATA spare parts
278601990306	ASSY. LONG BLOCK 5.9 CNG BS4 230HP	TATA spare parts
278601990310	LONG BLOCK ISBE5.9AJKNY DEEP/FRT SUM BS4	TATA spare parts
278601990311	SHORT BLOCK ASSY 180 HP 6BT	TATA spare parts
278601990312	KIT GASKET	TATA spare parts
278601990313	ASSY. LONG BLOCK ISBE5.9 BS4	TATA spare parts
278601990314	LONG BLOCK ISBE5.9 UMB 4HOLE CRANK BS4	TATA spare parts
278601990315	KIT-UPPER GASKET BS4	TATA spare parts
278601990316	LOWER GASKET KIT	TATA spare parts
278601990317	BLOCK CYLINDER	TATA spare parts
278601990318	LONG BLOCK ASSY	TATA spare parts
278601990319	BLOCK CYLINDER	TATA spare parts
278601990328	HEAD CYLINDER	TATA spare parts
278601990329	LONG BLOCK ISBE5.9 UMB W/BRAKE 5HOLE BS4	TATA spare parts
278601990336	HEAD CYLINDER	TATA spare parts
278601990354	LONG BLOCK ISBE5.9 5HOLE DEEP/FRT BS4	TATA spare parts
278601990355	LONG BLOCK ISBE5.9 UMB 5 HOLE CRANK BS4	TATA spare parts
278601993301	BRACKET SHIPPING	TATA spare parts
278601993303	BRACKET TIMING	TATA spare parts
278601993401	BUSHING REDUCING PIPE	TATA spare parts
278601993402	BUSHING BS4	TATA spare parts
278601993402DF	CAM BUSH - B5.9 TC BS2/3/4	TATA spare parts
278601993701	CYLINDER BLOCK BS3	TATA spare parts
278601993704	BLOCK,CYLINDER B5.9 CNG BS3/BS4	TATA spare parts
278601993705	BLOCK CYLINDER	TATA spare parts
278601993706	BLOCK CYLINDER ISBE6.7 BS3/4/6	TATA spare parts
278601993706AE	BLOCK CYLINDER	TATA spare parts
278601993707	ASSY CYLINDER HEAD	TATA spare parts
278601993711	HEAD CYLINDER	TATA spare parts
278601993714	BLOCK CYLINDER	TATA spare parts
278601993716	HEAD CYLINDER	TATA spare parts
278601994201	CLIP	TATA spare parts
278601994202	CLAMP SPRING HOSE	TATA spare parts
278601994204	CLAMP HOSE (3/4 - 1-1/8 INCH)	TATA spare parts
278601994205	CLAMP HOSE	TATA spare parts
278601994301	CLIP	TATA spare parts
278601994302	CLIP	TATA spare parts
278601994303	CLIP	TATA spare parts
278601994304	CLIP	TATA spare parts
278601994701	PLATE COVER	TATA spare parts
278601994702	CONNECTION SPACER	TATA spare parts
278601994703	PLATE COVER	TATA spare parts
278601994801	DOWEL PIN	TATA spare parts

278601995302	GASKET OIL PAN	TATA spare parts
278601995303	GASKET SUPPORT	TATA spare parts
278601995304	CYLINDER HEAD GASKET 6BT BS3	TATA spare parts
278601995305	GASKET-CYLINDER HEAD ISBE5.9 BS3	TATA spare parts
278601995306	GASKET CYLINDER HEAD ISBE5.9 BS4	TATA spare parts
278601995308	GASKET FLANGE	TATA spare parts
278601995310	KIT UPPER ENGINE GASKET ISBE5.9 UMB BS4	TATA spare parts
278601995311	KIT-GASKET LOWER	TATA spare parts
278601995312	GASKET CYLINDER HEAD	TATA spare parts
278601995313	KIT UPPER ENGINE GASKET ISBE5.9 UMB BS4	TATA spare parts
278601995314	GASKET CYLINDER HEAD	TATA spare parts
278601995801	HOSE ELBOW	TATA spare parts
278601995802	HOSE HUMP	TATA spare parts
278601995803	HOSE FLEXIBLE	TATA spare parts
278601995804	HOSE PLAIN	TATA spare parts
278601995805	HOSE ELBOW	TATA spare parts
278601995806	HOSE HUMP	TATA spare parts
278601995808	JUMPER PIPE FROM GAS MASS FLOW SENSOR TO	TATA spare parts
278601995809	HOSE PLAIN	TATA spare parts
278601995812	HOSE PLAIN	TATA spare parts
278601995817	HOSE FLEXIBLE	TATA spare parts
278601995818	HOSE FLEXIBLE	TATA spare parts
278601995819	HOSE FLEXIBLE	TATA spare parts
278601995820	HOSE PLAIN	TATA spare parts
278601995821	HOSE PLAIN	TATA spare parts
278601995823	HOSE FLEXIBLE	TATA spare parts
278601995825	HOSE MOULDED	TATA spare parts
278601995828	HOSE	TATA spare parts
278601995829	HOSE FLEXIBLE	TATA spare parts
278601995830	HOSE	TATA spare parts
278601995831	HOSE MOLDED	TATA spare parts
278601996501	NUT REGULAR HEXAGON	TATA spare parts
278601996502	NUT REGULAR HEXAGON	TATA spare parts
278601996503	NUT REGULAR HEXAGON	TATA spare parts
278601996504	NUT REGULAR HEXAGON	TATA spare parts
278601996801	TEE MALE BRANCH PIPE	TATA spare parts
278601996901	TUBE COUPLING	TATA spare parts
278601996902	TUBE INJECTOR FUEL SUPPLY BS4	TATA spare parts
278601996903	TUBE INJECTOR FUEL SUPPLY BS4	TATA spare parts
278601996904	TUBE VENT	TATA spare parts
278601996906	TUBE¿ OIL GAUGE	TATA spare parts
278601996907	TUBE BREATHER	TATA spare parts
278601996908	TUBE OIL GAUGE	TATA spare parts
278601996909	CLIP	TATA spare parts
278601996910	BRACE TUBE	TATA spare parts
278601996911	TUBE CPR WATER OUTLET	TATA spare parts
278601996912	TUBE CPR WATER INLET	TATA spare parts

278601996913	TUBE CPR WATER INLET	TATA spare parts
278601996916	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278601996917	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278601996918	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278601996919	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278601996920	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278601996921	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278601997201	PLUG PIPE	TATA spare parts
278601997202	PLUG THREADED	TATA spare parts
278601997203	PLUG THREADED	TATA spare parts
278601997701	SEAL RECTANGULAR RING	TATA spare parts
278601997702	WASHER SEALING	TATA spare parts
278601997703	SEAL O RING	TATA spare parts
278601997704	SEAL O RING	TATA spare parts
278601997705	SEAL O RING	TATA spare parts
278601997706	SEAL O RING	TATA spare parts
278601997707	SEAL O RING	TATA spare parts
278601997709	SEAL RECTANGULAR RING	TATA spare parts
278601997713	SEAL O RING	TATA spare parts
278601997715	SEAL O RING	TATA spare parts
278601998001	SCREW DRIVE	TATA spare parts
278601998002	SCREW H.FM8X1.25X25 BS4	TATA spare parts
278601998003	SCREW HEXAGON HEAD CAP	TATA spare parts
278601998004	SCREW HEXAGON HEAD CAP	TATA spare parts
278601998005	SCREW FLAT HEAD CAP	TATA spare parts
278601998006	SCREW HEXAGON HEAD CAP	TATA spare parts
278601998007	SCREW SOCKET HEAD CAP	TATA spare parts
278601998008	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278601998009	STUD	TATA spare parts
278601998010	SCREW HEXAGON HEAD CAP	TATA spare parts
278601998011	SCREW HEXAGON HEAD CAP	TATA spare parts
278601998012	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278601998013	SCREW HEX HEAD CAP	TATA spare parts
278601998014	SCREW HEX FLANGE HEAD	TATA spare parts
278601998015	SCREW HEX FLANGE	TATA spare parts
278601998016	SCREW STUDDED	TATA spare parts
278601998017	SCREW HEX FLANGE HEAD CAP BS4	TATA spare parts
278601998018	SCREW SOCKET HEAD CAP BS4	TATA spare parts
278601998019	SCREW SOCKET HEAD CAP BS4	TATA spare parts
278601998020	SCREW HEX FLANGE HEAD CAP BS4	TATA spare parts
278601998021	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278601998022	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278601998023	SCREW HEXAGON HEAD CAP	TATA spare parts
278601998024	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278601998033	SCREW STUDDED FLANGE CAP	TATA spare parts
278601998034	SCREW HEXAGON HEAD CAP	TATA spare parts
278601998035	HEX FLANGE HEAD CAP SCREW	TATA spare parts

278601998036	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278601998037	SCREW BANJO CONNECTOR	TATA spare parts
278601998038	SCREW HEXAGON HEAD CAP	TATA spare parts
278601998039	SCREW STUDDER FLANGE CAP	TATA spare parts
278601998040	SCREW STUDDER FLANGE CAP	TATA spare parts
278601998041	SCREW BANJO CONNECTOR	TATA spare parts
278601998042	SCREW BANJO CONNECTOR	TATA spare parts
278601998043	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278601998045	SCREW	TATA spare parts
278601998047	"SCREW,STUDDER FLANGE CAP"	TATA spare parts
278601998048	SCREW STUDDER FLANGE CAP	TATA spare parts
278601998050	SCREW STUDDER FLANGE CAP	TATA spare parts
278601998051	SCREW HEX FLANGE HEAD CAP BS6	TATA spare parts
278601998052	SCREW BANJO CONNECTOR	TATA spare parts
278601998202	PAN OIL	TATA spare parts
278601998302	SHIM FRICTION ENHANCING	TATA spare parts
278601998303	SHIM FRICTION ENHANCING	TATA spare parts
278601998601	SPACER MOUNTING	TATA spare parts
278601998801	STUD	TATA spare parts
278601998802	STUD	TATA spare parts
278601998803	STUD	TATA spare parts
278601998807	STUD DOUBLE END PLAIN	TATA spare parts
278601998808	STUD DOUBLE END PLAIN	TATA spare parts
278601999201	WASHER LOCK	TATA spare parts
278601999202	WASHER LOCK	TATA spare parts
278601999203	WASHER LOCK	TATA spare parts
278601999204	WASHER PLAIN	TATA spare parts
278601999205	WASHER PLAIN	TATA spare parts
278601999206	WASHER LOCK	TATA spare parts
278601999207	WASHER¿ PLAIN	TATA spare parts
278601999208	WASHER LOCK	TATA spare parts
278601999218	WASHER SEALING	TATA spare parts
278601999219	WASHER PLAIN	TATA spare parts
278601999220	WASHER SEALING	TATA spare parts
278601999701	ELBOW¿ PLAIN UNION	TATA spare parts
278601999703	CONNECTOR MALE	TATA spare parts
278601999705	SPACER MOUNTING	TATA spare parts
278601999708	CONNECTOR QCK DISCONNECT	TATA spare parts
278601999710	ISOLATOR NOISE	TATA spare parts
278601999711	DATA PLATE	TATA spare parts
278601999717	COMBUSTION GAS LEAK TESTER	TATA spare parts
278601999718	DIPSTICK	TATA spare parts
278601999719	ENGINE STAND ADAPTOR PLATE	TATA spare parts
278601999720	ENGINE REBUILD STAND	TATA spare parts
278601999721	ENGINE REBUILD STAND	TATA spare parts
278601999722	DIPSTICK	TATA spare parts
278601999724	CLAMP TUBE	TATA spare parts

278601999728	DIPSTICK	TATA spare parts
278601999732	DIPSTICK	TATA spare parts
278601999733	DIPSTICK	TATA spare parts
278601999734	DIPSTICK DEEP OIL SUMP 20 LIT	TATA spare parts
278601999735	DIPSTICK DEEP OIL SUMP 20 LIT	TATA spare parts
278601999736	ADAPTER SENSOR	TATA spare parts
278601999738	DIPSTICK	TATA spare parts
278601999739	HOUSING THERMOSTAT	TATA spare parts
278601999740	ELBOW PLAIN ADAPTER	TATA spare parts
278601999741	HOSE MOLDED	TATA spare parts
278601999742	ELBOW PLAIN ADAPTER	TATA spare parts
278601999743	ELBOW PLAIN ADAPTER	TATA spare parts
278601999744	DECAL SAFETY	TATA spare parts
278601999745	DIPSTICK	TATA spare parts
278601999746	HOSE MOLDED	TATA spare parts
278601999753	NAMEPLATE	TATA spare parts
278601999754	DIPSTICK	TATA spare parts
278601999757	CONNECTION SPACER	TATA spare parts
278601999801	SET-MAIN BRG STD BS1/2/3/4	TATA spare parts
278601999802	SET-MAIN BEARING RS1 6BT BS1/2/3	TATA spare parts
278601999802DF	MAIN BEARING SET-6BT TC BS3 RS1 10 THOU	TATA spare parts
278601999803	CLAMP TUBE	TATA spare parts
278601999804	CONNECTION AIR INTAKE	TATA spare parts
278601999805	TUBE DIPSTICK	TATA spare parts
278601999806	TUBE DIPSTICK	TATA spare parts
278601999807	TUBE DIPSTICK BS1/2/3/4/6	TATA spare parts
278601999808	DIPSTICK	TATA spare parts
278601999809	DIPSTICK BS1/2/3/4	TATA spare parts
278601999810	DIPSTICK	TATA spare parts
278601999813	ELBOW MALE ADAPTER	TATA spare parts
278601999814	PLUG PIPE	TATA spare parts
278601999815	SUPPORT FRONT ENGINE	TATA spare parts
278601999816	SUPPORT FRONT ENGINE	TATA spare parts
278601999817	SUPPORT BEARING	TATA spare parts
278601999818	ELBOW MALE ADAPTER	TATA spare parts
278601999819	BOOT PLIER	TATA spare parts
278601999820	BLOWBY CHECKING TOOL - TO BE USED WITH S	TATA spare parts
278601999821	WEATHER PACK TERMINAL REMOVAL TOOL	TATA spare parts
278601999822	FRONT SEAL INSTALLER	TATA spare parts
278601999823	ELBOW MALE UNION	TATA spare parts
278601999824	CONNECTION ADAPTOR	TATA spare parts
278601999825	ELBOW MALE UNION	TATA spare parts
278601999826	DATAPLATE	TATA spare parts
278601999827	CONDUIT	TATA spare parts
278601999828	SKID SHIPPING	TATA spare parts
278601999829	FLANGE	TATA spare parts
278601999830	ADAPTER PLAIN	TATA spare parts

278601999831	PLUG PIPE	TATA spare parts
278601999832	DRAINCOCK	TATA spare parts
278601999833	ELBOW PLAIN FEMALE PIPE	TATA spare parts
278601999834	ELBOW PLAIN STREET PIPE	TATA spare parts
278601999835	PLUG PIPE	TATA spare parts
278601999836	ISOLATOR NOISE	TATA spare parts
278601999838	BAR TOOL	TATA spare parts
278601999839	CONNECTOR FEMALE	TATA spare parts
278601999840	ENGINE COOLANT AND FUEL FILTER WRENCH	TATA spare parts
278601999841	TEE PLAIN ADAPTER	TATA spare parts
278601999842	UNION MALE	TATA spare parts
278601999843	COUPLING PLAIN HOSE	TATA spare parts
278601999844	CONNECTOR MALE	TATA spare parts
278601999845	PIN ROLL	TATA spare parts
278601999846	RING	TATA spare parts
278601999847	PLUG PIPE	TATA spare parts
278601999848	ELBOW MALE ADAPTER	TATA spare parts
278601999849	CLAMP SPRING HOSE (1/2 INCH ID)	TATA spare parts
278601999850	PLUG EXPANSION	TATA spare parts
278601999851	ELBOW PLAIN ADAPTER	TATA spare parts
278601999852	CREW HEXAGON HEAD CAP	TATA spare parts
278601999853	DATA PLATE	TATA spare parts
278601999854	MANOMETER	TATA spare parts
278601999856	DRAINCOCK	TATA spare parts
278601999857	PLUG THREADED	TATA spare parts
278601999858	PLUG THREADED	TATA spare parts
278601999859	PLUG THREADED	TATA spare parts
278601999860	VALVE INTAKE	TATA spare parts
278601999861	VALVE EXHAUST	TATA spare parts
278601999862	EXHAUST VALVE BSIII OS1 (3 THOU)	TATA spare parts
278601999863	EXHAUST VALVE BSIII OS2 (5 THOU)	TATA spare parts
278601999864	INTAKE VALVE BSIII OS1 (3 THOU)	TATA spare parts
278601999865	INTAKE VALVE BSIII OS2 (5 THOU)	TATA spare parts
278601999866	HEAD CYLINDER	TATA spare parts
278601999867	CYLINDER HEAD	TATA spare parts
278601999870	CAPSCREW LENGTH GAUGE	TATA spare parts
278601999871	SLEEVE REAR INSTALLER (B)	TATA spare parts
278601999872	PLUG EXPANSION	TATA spare parts
278601999873	PLUG EXPANSION	TATA spare parts
278601999874	KIT-TACHOMETER OPTICAL	TATA spare parts
278601999876	COUPLING PLAIN HOSE	TATA spare parts
278601999885	UNION MALE	TATA spare parts
278601999887	CONNECTION ADAPTER	TATA spare parts
278601999888	BREATHER CRANKCASE	TATA spare parts
278601999890	END OIL GAUGE TUBE	TATA spare parts
278601999891	TUBE BRACE	TATA spare parts
278601999893	DIPSTICK	TATA spare parts

278601999899	TUBE COUPLING	TATA spare parts
278601999902	BUSH	TATA spare parts
278601999903	SCREW HEX HEAD CAP M14X2.0X119	TATA spare parts
278601999904	CAP MAIN BEARING	TATA spare parts
278601999905	PLUG EXPANSION	TATA spare parts
278601999906	PLUG EXPANSION	TATA spare parts
278601999906AE	PLUG EXPANSION	TATA spare parts
278601999907	PLUG EXPANSION	TATA spare parts
278601999907AE	PLUG EXPANSION 17.73 MM 715	TATA spare parts
278601999908	DOWEL RING M16X10	TATA spare parts
278601999910	PLUG EXPANSION	TATA spare parts
278601999911	DOWEL PIN	TATA spare parts
278601999912	SPRING COMPRESSION	TATA spare parts
278601999913	PLUG PIPE	TATA spare parts
278601999914	DOWEL RING	TATA spare parts
278601999915	PLUG EXPANSION BS4	TATA spare parts
278601999916	CYLINDER LINER W/COLLAR B5.9 BS2/3/4	TATA spare parts
278601999916DFFF	CYLINDER LINER SET 6BT STD FF W/O COL BS	TATA spare parts
278601999916DFSF	CYLINDER LINER SET 6BT STD SF W/O COL BS	TATA spare parts
278601999916DFSF10	CYLINDER LINER SET 6BT OS10 SF W/O COL B	TATA spare parts
278601999916DFSF20	CYLINDER LINER SET 6BT OS20 SF W/O COL B	TATA spare parts
278601999916DFSF30	CYLINDER LINER SET 6BT OS30 SF W/O COL B	TATA spare parts
278601999916DFSF40	CYLINDER LINER SET 6BT OS40 SF W/O COL B	TATA spare parts
278601999916DFSF50	CYLINDER LINER SET 6BT OS50 SF W/O COL B	TATA spare parts
278601999916DFSF60	CYLINDER LINER SET 6BT OS60 SF W/O COL B	TATA spare parts
278601999917	COVER	TATA spare parts
278601999918	SEAL RECT RING	TATA spare parts
278601999918AE	SEAL RECT RING	TATA spare parts
278601999919	HEAD,CYLINDER B5.9 CNG	TATA spare parts
278601999920	PLUG EXPANSION	TATA spare parts
278601999921	SPRING VALVE	TATA spare parts
278601999922	RETAINER VALVE SPRING	TATA spare parts
278601999923	SEAL VALVE STEM	TATA spare parts
278601999924	SEAL VALVE STEM	TATA spare parts
278601999925	COLLET VALVE	TATA spare parts
278601999926	VALVE INTAKE 6BT BS1/2/3	TATA spare parts
278601999927	PLUG PIPE	TATA spare parts
278601999928	VALVE EXHAUST 6BT 125/230HP BS1/2/3	TATA spare parts
278601999929	SCREW HEX FLANGE HEAD CAP (M 12 X 1.75 X	TATA spare parts
278601999930	SCREW HEX FLANGE HD CAP	TATA spare parts
278601999931	GASKET CYLINDER HEAD	TATA spare parts
278601999932	GASKET,CYL. HEAD RS1 0.25MM 6BT BS2/BS3	TATA spare parts
278601999933	GASKET,CYLINDER HEAD 6BT BS1/BS2	TATA spare parts
278601999934	INSERT VALVE EXHAUST	TATA spare parts
278601999935	INSERT VALVE INLET	TATA spare parts
27860199993534DF	VALVE SEAT SET-IN/EX INSERT-6BT TC BS2	TATA spare parts
278601999936	GUIDE VALVE STEM INTAKE	TATA spare parts

278601999937	GUIDE VALVE STEM EXHAUST	TATA spare parts
278601999938	GUIDE VALVE STEM	TATA spare parts
278601999939	CONNECTOR ENGINE VENT	TATA spare parts
278601999939AE	TEE HOSE CONNECTOR 2523	TATA spare parts
278601999941	KIT-DIPSTICK SE/SK 1613/1615TC	TATA spare parts
278601999942	KIT-DIPSTICK LPT1615TC/2516TC	TATA spare parts
278601999943	KIT-DIPSTICK LP/LPO 1512TC	TATA spare parts
278601999944	PLUG PIPE BS4	TATA spare parts
278601999945	PLUG PIPE	TATA spare parts
278601999946	HOSE PLAIN BS2/3	TATA spare parts
278601999947	HOSE PLAIN	TATA spare parts
278601999948	BRACKET	TATA spare parts
278601999949	ADAPTOR AIR INLET	TATA spare parts
278601999950	DIPSTICK	TATA spare parts
278601999951	TUBE OIL GAUGE	TATA spare parts
278601999952	TUBE OIL GAUGE	TATA spare parts
278601999953	TUBE DIPSTICK	TATA spare parts
278601999954	INJECTOR	TATA spare parts
278601999955	GASKET OIL PAN	TATA spare parts
278601999956	CONNECTOR AIR INTAKE	TATA spare parts
278601999957	PIPE AIR TRANSFER	TATA spare parts
278601999958	PLUG SPARK	TATA spare parts
278601999959	HEAD CYLINDER-1510 CNG W/O VALVES	TATA spare parts
278601999960	INSERT VALVE INTAKE	TATA spare parts
278601999961	COVER INTAKE MANIFOLD	TATA spare parts
278601999962	HOUSING GEAR	TATA spare parts
278601999963	CLIP	TATA spare parts
278601999964	SCREW HEX HEAD CAP	TATA spare parts
278601999965	TUBE INJ FUEL SUPPLY	TATA spare parts
278601999966	TUBE INJ FUEL SUPPLY	TATA spare parts
278601999967	HOSE PLAIN	TATA spare parts
278601999968	COUPLING PLAIN HOSE	TATA spare parts
278601999969	PIPE AIR TRANSFER BS4	TATA spare parts
278601999970	PIPE AIR INLET	TATA spare parts
278601999971	CYLINDER BLOCK R/S I	TATA spare parts
278601999972	HOSE PLAIN	TATA spare parts
278601999973	LIQUID GASKET	TATA spare parts
278601999974	DIPSTICK	TATA spare parts
278601999975	DIPSTICK	TATA spare parts
278601999977	TUBE OIL FILLER	TATA spare parts
278601999978	COVER & INTAKE MANIFOLD	TATA spare parts
278601999979	COVER INTAKE MANIFOLD	TATA spare parts
278601999980	INJECTOR	TATA spare parts
278601999981	SEAL INJECTOR	TATA spare parts
278601999982	KIT BREATHER CRANKCASE	TATA spare parts
278601999983	INJECTOR-125HP	TATA spare parts
278601999984	STUD	TATA spare parts



278601999985	INJECTOR-125HP	TATA spare parts
278601999986	INJECTOR	TATA spare parts
278601999987	CAP MAIN BRG	TATA spare parts
278601999988	BEARING MAIN	TATA spare parts
278601999989	BEARING MAIN	TATA spare parts
278601999990	GASKET CYLINDER HEAD	TATA spare parts
278601999991	THREAD INSERT KIT METRIC	TATA spare parts
278601999992	ELEMENT BREATHER	TATA spare parts
278601999993	SET-LOWER ENGINE GASKET BS1/2/3	TATA spare parts
278601999993DF	GASKET KIT-LOWER 6BT TC BS2	TATA spare parts
278601999994	COVER GEAR	TATA spare parts
278601999995	COVER GEAR	TATA spare parts
278601999996	COVER INTAKE MANIFOLD	TATA spare parts
278601999997	HOSE PLAIN	TATA spare parts
278601999998	HOSE ELBOW	TATA spare parts
278601999999	HOSE FLEXIBLE	TATA spare parts
278603114701	BOTTOM COVER-FLYWHEEL HOUSING	TATA spare parts
278603118001	BOLT 3/8-16 UNC	TATA spare parts
278603990102	CONNECTING ROD	TATA spare parts
278603990103	CRANKSHAFT ASSEMBLY	TATA spare parts
278603990104	SET MAIN BEARING STD	TATA spare parts
278603990105	SET MAIN BEARING RS-1	TATA spare parts
278603990106	SET-MAIN BEARING RS2 BS1/2/3	TATA spare parts
278603990106DF	MAIN BEARING SET-6BT TC BS2/3 RS2 20THOU	TATA spare parts
278603990107	SET MAIN BEARING RS3	TATA spare parts
278603990107DF	MAIN BEARING SET-6BT TC BS2/3 RS3 30THOU	TATA spare parts
278603990108	SET MAIN BEARING RS-4	TATA spare parts
278603990108DF	MAIN BEARING SET-6BT TC BS2/3 RS4 40THOU	TATA spare parts
278603990110	FLYWHEEL GB-60	TATA spare parts
278603990113	SET PISTON BARE EURO II RS-I	TATA spare parts
278603990114	VIBRATION DAMPER	TATA spare parts
278603990121	DAMPER VIBRATION	TATA spare parts
278603990121AE	DAMPER VIBRATION 715	TATA spare parts
278603990123	SET PISTON (NEW RECIPE)	TATA spare parts
278603990126	BELT V RIBBED BS1/2/3/4	TATA spare parts
278603990126DF	BELT V RIBBED - 6BT TC BS2/3	TATA spare parts
278603990127	KIT CONVERSION BS3 MECH 180 HP	TATA spare parts
278603990133	FLYWHEEL	TATA spare parts
278603990136	FLYWHEEL	TATA spare parts
278603990147	ASSY. CRANKSHAFT	TATA spare parts
278603990148	CRANKSHAFT ENGINE	TATA spare parts
278603990150	KIT-ENG. PISTON STD 6BT (SET OF 6) BS3	TATA spare parts
278603990150DF	PISTON SET KIT - 6BT TC BS3	TATA spare parts
278603990150DFLL	PISTON SET KIT - 6BT TC BS3 LONG LIFE	TATA spare parts
278603990150DFR1	PISTON SET KIT - 6BT TC BS3 RS1-0.5MM	TATA spare parts
278603990150DFR2	PISTON SET KIT - 6BT TC BS3 RS2-1MM	TATA spare parts
278603990151	SET-PISTON OS 0.5 BS1/3	TATA spare parts

278603990152	KIT ENGINE PISTON (O/S 1)	TATA spare parts
278603990153	SET-PISTON RING STD (SET OF 6) 6BT BS3	TATA spare parts
278603990153DF	PISTON RING SET STD - 6BT TC BS3	TATA spare parts
278603990154	SET-PISTON RING RS-0.5MM 6BT BS1/3	TATA spare parts
278603990155	SET PISTON RING (O/S 1)	TATA spare parts
278603990158	DAMPER TUNED VIBRATION	TATA spare parts
278603990160	FLYWHEEL (WITH WEAR PLATE)	TATA spare parts
278603990161	DAMPER VIBRATION BS1/3/4	TATA spare parts
278603990162	KIT ENG PISTON	TATA spare parts
278603990163	CON ROD BEARING SET(STANDARD)	TATA spare parts
278603990167	BARE SET PISTON(STANDARD)	TATA spare parts
278603990169	RING SET(1ST OVERSIZE)	TATA spare parts
278603990171	HOUSING FLYWHEEL	TATA spare parts
278603990172	CRANKSHAFT ENGINE WITH GEAR	TATA spare parts
278603990173	FLYWHEEL	TATA spare parts
278603990174	DAMPER TUNED VIBRATION	TATA spare parts
278603990175	CONNECTING ROD ISBe5.9/6.7 BS1/2/3/4/6	TATA spare parts
278603990176	KIT-CONN ROD BEARING STD 6BT BS1/2/3/4	TATA spare parts
278603990176DF	CON ROD BEARING SET-FRAC STD-6BT TC BS2/	TATA spare parts
278603990177	SET PISTON RING	TATA spare parts
278603990182	KIT,CONN ROD BRG. RS1 0.25MM BS1/2/3/4	TATA spare parts
278603990182DF	CON ROD BRG SET-FRAC RS1 10TH-6BT BS2/3	TATA spare parts
278603990183	CON ROD BEARING 0.50 (FRACTURE)	TATA spare parts
278603990183DF	CON ROD BRG SET-FRAC RS2 20TH-6BT BS2/3	TATA spare parts
278603990184	CON ROD BEARING 0.75 (FRACTURE)	TATA spare parts
278603990184DF	CON ROD BRG SET-FRAC RS3 30TH-6BT BS2/3	TATA spare parts
278603990185	CON ROD BEARING 1.00 (FRACTURE)	TATA spare parts
278603990185DF	CON ROD BRG SET-FRAC RS4 40TH-6BT BS2/3	TATA spare parts
278603990192	CRANKSHAFT ENG. W/O GEAR ISBe5.9 BS3/4	TATA spare parts
278603990196	FLYWHEEL 138T B5.9 BS1/2/3/4	TATA spare parts
278603990196DFCI	FLYWHEEL CI 138T-6BT/GB600-HIGHWAY APP	TATA spare parts
278603990196DFSG	FLYWHEEL SG 138T-6BT/GB600-TIPPER APP	TATA spare parts
278603990197	BEARING KIT STD FRACTURE CONNECTING ROD	TATA spare parts
278603990202	KIT-MAIN BEARING ISBE5.9 BS1/2/3/4	TATA spare parts
278603990202DF	MAIN BEARING SET STD-6BT BS2/3	TATA spare parts
278603990202DFTHK	MAIN BEARING SET STD- THK COL-6BT BS2/3	TATA spare parts
278603990203	CRANK SHAFT THRUST BEARING SET (1OS)	TATA spare parts
278603990204	CRANK SHAFT THRUST BEARING SET (2OS)	TATA spare parts
278603990217	PULLEY CRANKSHAFT	TATA spare parts
278603990236	VIBRATION DAMPER BS3/4	TATA spare parts
278603990238	KIT-BEARING (0.25 UNDERSIZE)	TATA spare parts
278603990239	KIT-BEARING (0.5 UNDERSIZE)	TATA spare parts
278603990240	KIT-BEARING (0.75 UNDERSIZE)	TATA spare parts
278603990241	KIT-BEARING (1 UNDERSIZE)	TATA spare parts
278603990242	KIT-PISTON RING ISBe5.9 AJNKY & UMB BS4	TATA spare parts
278603990243	SET-PISTON ISBE5.9 AJINKYA BS4	TATA spare parts
278603990244	SET-PISTON RING ISBE5.9 UMB BS4	TATA spare parts

278603990245	SET-PISTON W/O RINGS BS4	TATA spare parts
278603990246	CRANKSHAFT ENGINE W/GEAR 6BT BS1/2/3/4	TATA spare parts
278603990250	SET PISTON (1OS) 5.9 BS4	TATA spare parts
278603990251	SET PISTON (2OS) 5.9 BS4	TATA spare parts
278603990253	DAMPER VIBRATION	TATA spare parts
278603990254	PULLEY CRANKSHAFT	TATA spare parts
278603990259	VISCOUS VIBRATION DAMPER BS4	TATA spare parts
278603990260	KIT-BEARING	TATA spare parts
278603990272	SET PISTON (1OS) 5.9 BS4	TATA spare parts
278603990273	SET PISTON (2OS) 5.9 BS4	TATA spare parts
278603990274	SET PISTON (1OS) 5.9 BS4	TATA spare parts
278603990275	SET PISTON (2OS) 5.9 BS4	TATA spare parts
278603993101	BEARING CRANK SHAFT THRUST	TATA spare parts
278603993102	BEARING MAIN	TATA spare parts
278603993103	BEARING MAIN	TATA spare parts
278603993104	BEARING MAIN	TATA spare parts
278603993105	BEARING THRUST	TATA spare parts
278603993106	BEARING MAIN	TATA spare parts
278603993107	BEARING CONNECTING ROD	TATA spare parts
278603993108	BEARING CRANK SHAFT THRUST (0.25 MM)	TATA spare parts
278603993109	BEARING CRANK SHAFT THRUST (0.50 MM)	TATA spare parts
278603993110	BEARING CRANK SHAFT THRUST (0.75 MM)	TATA spare parts
278603993112	BEARING CONNECTING ROD	TATA spare parts
278603993133	BEARING BALL	TATA spare parts
278603993134	BEARING CONNECTING ROD	TATA spare parts
278603993136	BEARING CRANK	TATA spare parts
278603993145	BEARING CONNECTING ROD	TATA spare parts
278603993146	BEARING CONNECTING ROD	TATA spare parts
278603993147	BEARING MAIN	TATA spare parts
278603993148	BEARING MAIN	TATA spare parts
278603993149	BEARING THRUST	TATA spare parts
278603993151	BEARING THRUST	TATA spare parts
278603993152	BEARING CONNECTING ROD (0.25 UNDERSIZE)	TATA spare parts
278603993153	BEARING CONNECTING ROD (0.5 UNDERSIZE)	TATA spare parts
278603993154	BEARING CONNECTING ROD (0.75 UNDERSIZE)	TATA spare parts
278603993156	BEARING CON ROD BS6	TATA spare parts
278603993157	BEARING CON ROD BS6	TATA spare parts
278603993201	HEX FLANGE BOLT BS4	TATA spare parts
278603993401	BUSHING BS1/2/3/4	TATA spare parts
278603993401DF	CON ROD BUSH STD - 6BT TC BS2/3	TATA spare parts
278603993401DFR1	CON ROD BUSH RS1 - 6BT TC BS2/3	TATA spare parts
278603993401DFR2	CON ROD BUSH RS2 - 6BT TC BS2/3	TATA spare parts
278603993703	HOUSING GEAR	TATA spare parts
278603993704	HOUSING FLYWHEEL BS3	TATA spare parts
278603993705	HOUSING FLYWHEEL	TATA spare parts
278603993706	BLOCK CYLINDER	TATA spare parts
278603993713	HEAD CYLINDER WITH VALVE	TATA spare parts

278603993714	HEAD CYLINDER WITHOUT VALVE	TATA spare parts
278603993802	FLYWHEEL HOUSING BS3	TATA spare parts
278603994302	CLIP	TATA spare parts
278603994702	COVER REAR BS1/2/3/4	TATA spare parts
278603994703	COVER REAR	TATA spare parts
278603994706	COVER GEAR	TATA spare parts
278603994707	GASKET REAR COVER BS6	TATA spare parts
278603994708	PLATE COVER BS4	TATA spare parts
278603994709	PLATE BS4	TATA spare parts
278603994901	HOUSING FLYWHEEL BS4	TATA spare parts
278603995301	GASKET BS4	TATA spare parts
278603995402	GEAR FLYWHEEL RING BS1/2/3	TATA spare parts
278603995402AE	GEAR FLYWHEEL RING	TATA spare parts
278603995403	PULLEY CRANK SHAFT	TATA spare parts
278603996603	PISTON,ENGINE B5.9 CNG BS3/BS4	TATA spare parts
278603996607	PISTON,ENGINE 6BT BS2	TATA spare parts
278603996610	PISTON ENGINE	TATA spare parts
278603996613	RING COMPRESSION PISTON	TATA spare parts
278603996615	RING COMPRESSION PISTON	TATA spare parts
278603996619	PISTON,ENGINE ISBe5.9 BS4	TATA spare parts
278603996701	PIN PISTON	TATA spare parts
278603997001	PULLEY CRANKSHAFT	TATA spare parts
278603997002	PULLEY CRANKSHAFT	TATA spare parts
278603997004	PULLEY CRANKSHAFT	TATA spare parts
278603997005	PULLEY CRANKSHAFT BS3/4	TATA spare parts
278603997006	PULLEY CRANKSHAFT	TATA spare parts
278603997702	SEAL OIL BS1/2/3/4	TATA spare parts
278603997702AE	SEAL OIL 1828	TATA spare parts
278603997704	SEAL O RING	TATA spare parts
278603997901	CRANKSHAFT ENGINE	TATA spare parts
278603998001	SCREW HEXAGON HEAD CAP	TATA spare parts
278603998002	SCREW CONNECTING ROD CAP	TATA spare parts
278603998004	SCREW HEXAGON HEAD CAP	TATA spare parts
278603998005	SCREW DRIVE	TATA spare parts
278603998006	SCREW HEX HEAD CAP	TATA spare parts
278603998007	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278603998008	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278603998009	SCREW CONNECTING ROD	TATA spare parts
278603998010	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278603998011	SCREW	TATA spare parts
278603998012	SCREW HEX FLANGE HEAD CAP	TATA spare parts
27860399838	SET-PISTON RING RSI (BSII)	TATA spare parts
27860399840	SET-PISTON RING RSII (BSII)	TATA spare parts
278603998601	SPACER CRANKSHAFT	TATA spare parts
278603999801	FLYWHEEL-LPS4923-380D CL	TATA spare parts
278603999802	BEARING BALL(CLUTCH REAR)	TATA spare parts
278603999804	RING COMPRESSION PISTON	TATA spare parts

278603999806	PISTON ENGINE BS III ( Single Piston)	TATA spare parts
278603999809	RING COMPRESSION PISTON	TATA spare parts
278603999810	CRANKSHAFT SEAL REPLACER	TATA spare parts
278603999811	CRANKSHAFT SEAL REPLACER REAR	TATA spare parts
278603999812	GAUGE COMPRESSION	TATA spare parts
278603999814	RING COMPRESSION	TATA spare parts
278603999815	RING COMPRESSION PISTON	TATA spare parts
278603999816	RING COMPRESSION PISTON	TATA spare parts
278603999817	RING COMPRESSION PISTON	TATA spare parts
278603999818	SPACER CRANKSHAFT BS4	TATA spare parts
278603999820	ADAPTER CRANKSHAFT	TATA spare parts
278603999821	SPACER CRANKSHAFT	TATA spare parts
278603999824	FLYWHEEL	TATA spare parts
278603999825	FLYWHEEL 138T 6BT BS2/3/4/6	TATA spare parts
278603999825DFCI	FLYWHEEL CI 138T-6BT/GB750-HIGHWAY APP	TATA spare parts
278603999825DFSG	FLYWHEEL SG 138T-6BT/GB750-TIPPER APP	TATA spare parts
278603999826	ADAPTER CRANKSHAFT	TATA spare parts
278603999827	RING GEAR FLYWHEEL	TATA spare parts
278603999828	GEAR FLYWHEELRING	TATA spare parts
278603999829	RINGCOMPRESSION PISTON	TATA spare parts
278603999830	RING SPEED INDICATOR	TATA spare parts
278603999831	RING OIL PISTON	TATA spare parts
278603999832	RING COMPRESSION PISTON	TATA spare parts
278603999834	RING COMPRESSION PISTON	TATA spare parts
278603999835	PISTON ENGINE	TATA spare parts
278603999836	BARE PISTON (STD) ISBE5.9 UMB SCR BS4	TATA spare parts
278603999837	RING COMPRESSION PISTON	TATA spare parts
278603999838	SET,PISTON RING RS1 6BT BS1/BS2	TATA spare parts
278603999840	SET-PISTON RING RSII (BSII)	TATA spare parts
278603999841	KIT,ENGINE PISTON 6BT BS1/BS2	TATA spare parts
278603999842	RING	TATA spare parts
278603999843	STARTING MOTOR	TATA spare parts
278603999845	CRANKSHAFT ENGINE ISBE5.9 BS4	TATA spare parts
278603999846	SHIM FRICTION ENHANCING	TATA spare parts
278603999847	ADAPTER CRANKSHAFT	TATA spare parts
278603999848	UNION MALE BS6	TATA spare parts
278603999849	UNION MALE BS6	TATA spare parts
278603999850	PLATE CLAMPING	TATA spare parts
278603999901	SCREW CON ROD CAP	TATA spare parts
278603999902	SET BEARING CON ROD STD	TATA spare parts
278603999903	BUSH CON.ROD	TATA spare parts
278603999905	GEAR CRANKSHAFT	TATA spare parts
278603999906	DOWEL PIN	TATA spare parts
278603999907	SLEEVE WEAR-FRONT BS1/2/3	TATA spare parts
278603999908	SLEEVE WEAR BS1/2/3	TATA spare parts
278603999909	GEAR FLYWHEEL RING	TATA spare parts
278603999910	SCREW HEXAGON HD CAP	TATA spare parts

278603999911	WASHER PLAIN	TATA spare parts
278603999912	SCREW SELF TAP METAL	TATA spare parts
278603999913	PLUG THREADED	TATA spare parts
278603999914	PLATE COVER	TATA spare parts
278603999915	PLUG O RING	TATA spare parts
278603999916	SEAL O RING	TATA spare parts
278603999918	COVER REAR	TATA spare parts
278603999919	KIT OIL SEAL	TATA spare parts
278603999920	SEAL RECTANGULAR RING	TATA spare parts
278603999921	GASKET REAR COVER BS4	TATA spare parts
278603999922	SCREW HEX FLANGE HD CAP	TATA spare parts
278603999923	HOUSING FLYWHEEL	TATA spare parts
278603999924	HOUSING GEAR	TATA spare parts
278603999926	SCREW HEX FLANGE HEAD	TATA spare parts
278603999927	SCREW HEX HEAD CAP	TATA spare parts
278603999928	SEAL RECT RING	TATA spare parts
278603999930	SEAL O RING	TATA spare parts
278603999930AE	SEAL O RING	TATA spare parts
278603999931	PIN TIMING	TATA spare parts
278603999932	RING RETAINING	TATA spare parts
278603999933	HOUSING TIMING PIN	TATA spare parts
278603999934	COVER GEAR	TATA spare parts
278603999935	SEAL OIL	TATA spare parts
278603999936	DAMPER VIBRATION	TATA spare parts
278603999937	SCREW HEX FLANGE HD CAP	TATA spare parts
278603999938	SET PISTON BARE STD	TATA spare parts
278603999939	SET PISTON BARE RS-I	TATA spare parts
278603999940	SET-BARE PISTON RS-II BS1/2/3	TATA spare parts
278603999941	NUT	TATA spare parts
278603999942	GEAR FLYWHEEL RING	TATA spare parts
278603999943	HOUSING FLYWHEEL GB-60	TATA spare parts
278603999944	PILOT BEARING BS1/2/3/4	TATA spare parts
278603999945	FLY WHEEL BEARING GB-60 BS4	TATA spare parts
278603999946	PIN PISTON	TATA spare parts
278603999947	VIBRATION DAMPER BS1/2/3/4	TATA spare parts
278603999948	ASSY FLYWHEEL	TATA spare parts
278603999949	PULLEY CRANK	TATA spare parts
278603999950	SEAL O RING	TATA spare parts
278603999951	SEAL O RING	TATA spare parts
278603999952	SET PISTON RINGS 1.00MM	TATA spare parts
278603999953	SET PISTON RINGS 0.50MM	TATA spare parts
278603999954	SET PISTON RINGS STD	TATA spare parts
278603999955	ISOLATOR VIBRATION	TATA spare parts
278603999957	SET-PISTON RING (STD) ISBE5.9 CNG BS3/4	TATA spare parts
278603999958	SET,ENG PISTON (STD.) B5.9 CNG BS3/BS4	TATA spare parts
278603999958DF	PISTON SET B5.9 CNG BS3/4	TATA spare parts
278603999959	SET PISTON BARE STD-210HP	TATA spare parts

278603999960	HOUSING FLYWHEEL	TATA spare parts
278603999961	HOUSING FLYWHEEL(C.I)125HP	TATA spare parts
278603999962	HOUSING FLYWHEEL	TATA spare parts
278603999963	ROD ENGINE CONNECTING	TATA spare parts
278603999965	RING GEAR FLYWHEEL	TATA spare parts
278603999966	FLYWHEEL	TATA spare parts
278603999967	PISTON ENGINE EURO-II	TATA spare parts
278603999968	RING GEAR - FLYWHEEL	TATA spare parts
278603999969	RING GEAR - FLYWHEEL	TATA spare parts
278603999970	FLYWHEEL 6BT BS1 159 TEETH RING GEAR	TATA spare parts
278603999971	CON ROD MANDRELS	TATA spare parts
278603999972	FLYWHEEL HOUSING BS1/2/3/4	TATA spare parts
278603999972AE	FLYWHEEL HOUSING	TATA spare parts
278603999973	KIT-BARE PISTON STD 6BT(SET OF 6)BS1/2/3	TATA spare parts
278603999974	SET PISTON BARE STD-210HP	TATA spare parts
278603999975	KIT-PISTON BARE RS1 6BT BS2/3/4	TATA spare parts
278603999976	RING SET STD 210 HP	TATA spare parts
278603999977	SET-PISTON RING STD BS1/2/3	TATA spare parts
278603999977DF	PISTON RING SET STD - 6BT TC BS2	TATA spare parts
278603999978	SET-PISTON RINGS RS1 BS1/2/3	TATA spare parts
278603999979	SET PISTON RINGS RS2	TATA spare parts
278603999980	SET-CON ROD BEARING (STD) 6BT BS1/2/3	TATA spare parts
278603999980DF	CON ROD BEARING SET - 6BT BS2	TATA spare parts
278603999982	FLYWHEEL	TATA spare parts
278603999983	FLYWHEEL GBS-60 BS2/3	TATA spare parts
278603999984	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278603999985	BRACE TUBE	TATA spare parts
278603999987	SCREW SOCKET HEAD CAP	TATA spare parts
278603999988	PLUG EXPANSION	TATA spare parts
278603999989	RING GEAR-4.9THK BS1/2/3/4	TATA spare parts
278603999989AE	GEAR FLYWHEEL RING 713	TATA spare parts
278603999991	SET-BARE PISTON-R/SII EURO II	TATA spare parts
278603999995	RING OIL PISTON	TATA spare parts
278603999996	RING COMPRESSION	TATA spare parts
278603999997	RING COMPRESSION	TATA spare parts
278603999998	PISTON ENGINE	TATA spare parts
278603999999	FLYWHEEL WITH WEAR PLATES	TATA spare parts
278605990108	HOUSING GEAR BS1/2/3	TATA spare parts
278605990109	ASSY. ROCKER LEVER BS1/3/4	TATA spare parts
278605990114	SET INSERT VALVE (INTAKE)	TATA spare parts
278605990115	SET INSERT VALVE (EXHAUST)	TATA spare parts
278605990117	HOUSING GEAR	TATA spare parts
278605990118	TAPPET REMOVAL TOOL KIT	TATA spare parts
278605990122	CAMSHAFT	TATA spare parts
278605990141	COVER VALVE	TATA spare parts
278605990142	CAMSHAFT	TATA spare parts
278605993301	BRACKET BELT TENSIONER	TATA spare parts

278605993302	BRACKET IDLER	TATA spare parts
278605993701	HOUSING GEAR	TATA spare parts
278605993703	HOUSING ROCKER LEVER	TATA spare parts
278605993704	HOUSING GEAR ISBe5.9 BS4	TATA spare parts
278605994701	COVER VALVE	TATA spare parts
278605994704	PLATE COVER	TATA spare parts
278605994705	COVER GEAR	TATA spare parts
278605994707	COVER PUSH ROD	TATA spare parts
278605994708	COVER VALVE	TATA spare parts
278605994709	COVER VALVE	TATA spare parts
278605994710	COVER VALVE	TATA spare parts
278605994713	COVER VALVE	TATA spare parts
278605994715	COVER FRONT	TATA spare parts
278605994716	COVER PUSH ROD	TATA spare parts
278605994717	COVER PUSH ROD	TATA spare parts
278605994720	COVER VALVE	TATA spare parts
278605994721	COVER PUSH ROD	TATA spare parts
278605994722	COVER VALVE	TATA spare parts
278605995301	GASKET HYDRAULIC PUMP	TATA spare parts
278605995302	GASKET PUSH ROD COVER	TATA spare parts
278605995304	GASKET COVER PLATE	TATA spare parts
278605995305	GASKET RKR LEVER	TATA spare parts
278605995307	GASKET GEAR HOUSING	TATA spare parts
278605995308	GASKET VALVE COVER	TATA spare parts
278605995401	GEAR CAMSHAFT	TATA spare parts
278605995402	GEAR CAMSHAFT	TATA spare parts
278605995403	GEAR CAMSHAFT	TATA spare parts
278605995901	KEY PLAIN WOODRUFF	TATA spare parts
278605996501	NUT HEXAGON FLANGE	TATA spare parts
278605997401	RIVET	TATA spare parts
278605997701	SEAL RECTANGULAR RING	TATA spare parts
278605997702	SEAL O RING	TATA spare parts
278605997703	SEAL O RING	TATA spare parts
278605997704	SEAL O-RING	TATA spare parts
278605997705	SEAL VALVE STEM	TATA spare parts
278605997706	SEAL ROCKER LEVER COVER	TATA spare parts
278605997801	SEAL VALVE STEM	TATA spare parts
278605997902	CAMSHAFT ISBe5.9 BS1/3/4	TATA spare parts
278605997905	CAMSHAFT ISBe 5.9 CNG BS1/2/3/4	TATA spare parts
278605998001	SCREW STUDDED FLANGE CAP	TATA spare parts
278605998002	SCREW RKR LEVER ADJUSTING	TATA spare parts
278605998601	SLEEVE	TATA spare parts
278605998701	SPRING VALVE	TATA spare parts
278605998702	SPRING VALVE	TATA spare parts
278605998706	SPRING VALVE	TATA spare parts
278605999002	VALVE KIT BS II	TATA spare parts
278605999003	VALVE KIT BS III	TATA spare parts



278605999004	VALVE EXHAUST BS3/4	TATA spare parts
278605999005	EXHAUST VALVE BSII OS1 (3 THOU)	TATA spare parts
278605999006	EXHAUST VALVE BSII OS2 (5 THOU)	TATA spare parts
278605999007	INTAKE VALVE BSII OS1 (3 THOU)	TATA spare parts
278605999008	INTAKE VALVE BSII OS2 (5 THOU)	TATA spare parts
278605999801	VALVE STEM SEAL INSTALLER	TATA spare parts
278605999802	VALVE SEAT EXTRATOR COLLET	TATA spare parts
278605999803	RING RETAINING	TATA spare parts
278605999804	RING RETAINING	TATA spare parts
278605999805	INSERT VALVE	TATA spare parts
278605999806	TENSIONER,BELT BS2/BS3/BS4	TATA spare parts
278605999806AE	TENSIONER BELT 713 2523	TATA spare parts
278605999807	INSERT VALVE	TATA spare parts
278605999808	RETAINER VALVE SPRING	TATA spare parts
278605999809	INSERT VALVE	TATA spare parts
278605999810	INSERT VALVE INTAKE	TATA spare parts
278605999811	INSERT VALVE EXHAUST	TATA spare parts
278605999816	ASSEMBLY ROCKER LEVER	TATA spare parts
278605999817	HOUSING GEAR	TATA spare parts
278605999818	ROTATOR VALVE	TATA spare parts
278605999819	CAP FILLER BS4	TATA spare parts
278605999820	SUPPORT CAMSHAFT	TATA spare parts
278605999822	TENSIONER BELT BS4	TATA spare parts
278605999823	CLAMP TUBE	TATA spare parts
278605999824	CAMSHAFT	TATA spare parts
278605999825	CROSSHEAD VALVE	TATA spare parts
278605999827	SUPPORT ROCKER LEVER	TATA spare parts
278605999828	LEVER ROCKER	TATA spare parts
278605999829	LEVER ROCKER	TATA spare parts
278605999830	SUPPORT ROCKER ARM	TATA spare parts
278605999832	DUST SHIELD	TATA spare parts
278605999833	GASKET INTEGRATED WIRING BS6	TATA spare parts
278605999901	GASKET PUSH ROD COVER BS1/2/3/4	TATA spare parts
278605999901AE	GASKET PUSH ROD COVER	TATA spare parts
278605999902	COVER PUSH ROD BS1/2/3	TATA spare parts
278605999903	COVER PUSH ROD	TATA spare parts
278605999904	SEAL GROMMET	TATA spare parts
278605999905	SCREW HEX FLANGE HEAD	TATA spare parts
278605999906	HOSE PLAIN	TATA spare parts
278605999906AE	HOSE PLAIN 1628	TATA spare parts
278605999907	CLAMP SPRING HOSE	TATA spare parts
278605999908	CAMSHAFT	TATA spare parts
278605999909	KEY PLAIN WOODRUFF	TATA spare parts
278605999909AE	KEY PLAIN WOODRUFF	TATA spare parts
278605999910	GEAR CAMSHAFT	TATA spare parts
278605999911	SCREW HEX HEAD CAP	TATA spare parts
278605999912	SUPPORT CAMSHAFT THRUST BS2/3/4	TATA spare parts

278605999913	TAPPET VALVE BS1/2/3/4	TATA spare parts
278605999914	SUPPORT ROCKER LEVER	TATA spare parts
278605999915	SUPPORT ROCKER LEVER	TATA spare parts
278605999916	SHAFT ROCKER LEVER	TATA spare parts
278605999917	RETAINING RING	TATA spare parts
278605999918	LEVER ROCKER	TATA spare parts
278605999920	SCREW SLOTTED SET	TATA spare parts
278605999921	LEVER ROCKER	TATA spare parts
278605999923	PLAIN WASHER	TATA spare parts
278605999924	SCREW HEXAGON HD CAP	TATA spare parts
278605999925	SCREW HEX FLANGE HD CAP	TATA spare parts
278605999926	ROD PUSH BS1/2/3/4	TATA spare parts
278605999927	VALVE COVER	TATA spare parts
278605999928	GASKET VALVE COVER (3930906) BS1/2/3/4	TATA spare parts
278605999928AE	GASKET VALV COV LPA 713/LPT 2523	TATA spare parts
278605999929	SCREW HEX FLANGE HD CAP	TATA spare parts
278605999930	ISOLATOR NOISE	TATA spare parts
278605999931	NUT	TATA spare parts
278605999932	VALVE COVER	TATA spare parts
278605999933	INSERT VALVE EXHAUST	TATA spare parts
278605999934	CAM BUSH NO 1 OVER SIZE	TATA spare parts
278605999935	PLATE COVER BS4	TATA spare parts
278605999936	SCREW 12PT CAP	TATA spare parts
278605999937	PLUG EXPANSION	TATA spare parts
278605999938	INSERT ROCKER BS1/2/3/4	TATA spare parts
278605999939	SCREW HEX HEAD CAP	TATA spare parts
278605999940	SCREW HEX FLANGE HEAD	TATA spare parts
278605999941	NUT HEXAGON FLANGE	TATA spare parts
278605999942	SEAL O RING	TATA spare parts
278605999943	GASKET VALVE COVER	TATA spare parts
278605999945	CAMSHAFT	TATA spare parts
278605999946	CAMSHAFT	TATA spare parts
278605999947	KIT INSERT EXHAUST VALVE	TATA spare parts
278605999948	KIT INSERT INTAKE VALVE	TATA spare parts
278605999949	KIT GUIDE VALVE STEM INTAKE	TATA spare parts
278605999950	KIT GUIDE VALVE STEM EXHAUST	TATA spare parts
278605999951	VALVE ASSY.	TATA spare parts
278605999952	KIT ADOPTOR	TATA spare parts
278605999953	BLIND THREAD INS KIT METR	TATA spare parts
278605999954	VALVE SEAT INSERT TOOL	TATA spare parts
278605999955	ROCKER LEVER	TATA spare parts
278605999956	CLAMP	TATA spare parts
278605999957	RETAINER VALVE SPRING	TATA spare parts
278605999958	CAMSHAFT	TATA spare parts
278605999959	OIL SEAL (VALVE STEM) BS1/2/3/4	TATA spare parts
278605999960	VALVE RETAINER	TATA spare parts
278605999961	STUD M10X1.5X67	TATA spare parts

278605999962	KIT OIL SEALS	TATA spare parts
278605999963	SET,GASKET FULL ENGINE B5.9 CNG	TATA spare parts
278605999964	COVER GEAR EURO II	TATA spare parts
278605999966	INSERT VALVE BS1/3/4/6	TATA spare parts
27860599996667DF	VALVE SEAT INSERT SET-IN/EX 6BT BS3/4	TATA spare parts
278605999967	INSERT VALVE BS1/3/4	TATA spare parts
278605999968	VALVE EXHAUST	TATA spare parts
278605999969	VALVE INTAKE BS1/3/4	TATA spare parts
278605999970	COLLECT VALVE BS1/3/4/6	TATA spare parts
278605999971	RETAINER VALVE SPRING	TATA spare parts
278605999972	SPRING VALVE	TATA spare parts
278605999973	SEAL VALVE STEEM BS1/3/4	TATA spare parts
278605999974	SEAL VALVE STEM	TATA spare parts
278605999975	SCREW HEX FLANGE HEAD CAP BS1/3/4/6	TATA spare parts
278605999976	PLUG THREADED M 14X1.5	TATA spare parts
278605999977	CAMSHAFT	TATA spare parts
278605999978	TAPPET VALVE BS1/3/4	TATA spare parts
278605999979	ROD PUSH BS1/3/4/6	TATA spare parts
278605999979AE	ROD PUSH 1828	TATA spare parts
278605999980	CROSSHEAD VALVE BS1/3/4/6	TATA spare parts
278605999981	ASSLY ROCKER LEVER	TATA spare parts
278605999994	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278605999995	CAP FILLER	TATA spare parts
278605999997	CAP FILLER	TATA spare parts
278605999998	POINTER TIMING	TATA spare parts
278605999999	VALVE SPRING COMPRESSOR	TATA spare parts
278607150102	ASSY.BRACKRT (COLD START PILOT MTG)	TATA spare parts
278607989901	TUBE INJECTOR FUEL SUPPLY BS2/3	TATA spare parts
278607989902	TUBE INJECTOR FUEL SUPPLY BS2/3	TATA spare parts
278607989903	BRACE FUEL PUMP EURO II BS1/2/3	TATA spare parts
278607989904	GASKET FUEL PUMP BS1/2/3	TATA spare parts
278607989905	SCREW BANJO CONNECTOR	TATA spare parts
278607989906	FIP (ROTARY) 125HP	TATA spare parts
278607989907	FIP (ROTARY) 160HP	TATA spare parts
278607989908	TEE MALE UNION	TATA spare parts
278607989909	PUMP FUEL INJECTION	TATA spare parts
278607989910	SCREW BANJO CONNECTOR	TATA spare parts
278607989914	ASSY. WATER SEPERATOR W/VALVE BS1/2/3	TATA spare parts
278607989914AE	WATER SEPERATOR W/VALVE LPA 1415	TATA spare parts
278607989914CS	DEMO CUT SECTION MODEL FOR 278607989914	TATA spare parts
278607989915	DRAIN VALVE WATER SEPERATOR BS1/2/3	TATA spare parts
278607989916	FUEL FILTER (FWS) ELEMENT SPINON BS1/2/3	TATA spare parts
278607989916AE	WATER SEPERATOR PA 713/LPTA 715/	TATA spare parts
278607989917	FEED PUMP 210 HP	TATA spare parts
278607989917AE	PUMP FUEL TRANSFER 2523	TATA spare parts
278607989918	PUMP FUEL TRANSFER FOR EURO II ROTARY FI	TATA spare parts
278607989920	BUSHING PIPE	TATA spare parts

278607989921	GASKET GEAR COVER BS2/3/4	TATA spare parts
278607989922	HOUSING GEAR EURO-II	TATA spare parts
278607989923	TUBE FUEL SUPPLY	TATA spare parts
278607989924	HARNESS WIRING	TATA spare parts
278607989925	FLYWHEEL (127 T) 6BT/ISBE5.9 BS1/2/3/4	TATA spare parts
278607989925AE	ASSY. FLYWHEEL 713	TATA spare parts
278607989926	STARTER MOTOR 12V BS2	TATA spare parts
278607989926AE	STARTER MOTOR 1415 713	TATA spare parts
278607989927	FLYWHEEL 145/160 HP	TATA spare parts
278607989928	GEAR FLYWHEEL RING ISBe B5.9 BS1/2/3/4/6	TATA spare parts
278607989929	SET HT CABLE	TATA spare parts
278607989933	CONNECTOR MALE	TATA spare parts
278607989935	GASKET FLANGE	TATA spare parts
278607989939	GOVERNER ELECTRIC	TATA spare parts
278607989941	COIL IGNITION	TATA spare parts
278607989942	FUEL WATER SEPARATOR	TATA spare parts
278607989944	TUBE FUEL SUPPLY	TATA spare parts
278607989945	TUBE FUEL SUPPLY	TATA spare parts
278607989946	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278607989947	TUBE FUEL DRAIN	TATA spare parts
278607989948	TUBE FUEL DRAIN	TATA spare parts
278607989949	TUBE FUEL DRAIN	TATA spare parts
278607989950	FITTING ORIFICE	TATA spare parts
278607989951	WASHER LOCK	TATA spare parts
278607989952	FUEL FILTER	TATA spare parts
278607989953	SEPARATOR FUEL WATER	TATA spare parts
278607989954	FUEL FILTER BS3	TATA spare parts
278607989956	FILTER FUEL	TATA spare parts
278607989958	ADAPTER FILTER HEAD	TATA spare parts
278607989959	ELBOW MALE ADAPTER	TATA spare parts
278607989960	SWITCH PRESSURE	TATA spare parts
278607989961	SWITCH PRESSURE	TATA spare parts
278607989965	FUEL FILTER (FWS) BS3	TATA spare parts
278607989966	NOZZLE 130 HP NRE	TATA spare parts
278607989967	FUEL FILTER BS3	TATA spare parts
278607989968	CONNECTOR TUBE	TATA spare parts
278607990106	HEAD FUEL FILTER	TATA spare parts
278607990117	FUEL INJECTION PUMP UNIPOLAR SYSTEM BS3	TATA spare parts
278607990121	PUMP FUEL INJECTION	TATA spare parts
278607990134	PUMP FUEL TRANSFER BS1/2/3	TATA spare parts
278607990137	INJECTOR	TATA spare parts
278607990145	PUMP FUEL INJECTION	TATA spare parts
278607990147	INJECTOR	TATA spare parts
278607990155	FUEL INJECTION PUMP ISBE5.9 BS3/4	TATA spare parts
278607990156	MANIFOLD FUEL ISBe5.9 BS3/4	TATA spare parts
278607990157	INJECTOR ISBE5.9 AJINKYA BS3/4	TATA spare parts
278607990158	HOUSING FUEL CONTROL	TATA spare parts

278607990159	HOUSING FUEL CONTROL	TATA spare parts
278607990160	HOUSING FUEL CONTROL	TATA spare parts
278607990162	PUMP FUEL INJECTION	TATA spare parts
278607990163	INJECTOR	TATA spare parts
278607990164	PUMP FUEL TRANSFER	TATA spare parts
278607990169	PUMP FUEL INJECTION (ROTARY)	TATA spare parts
278607990170	FUEL INJECTION PUMP (ROTARY) BS2/3	TATA spare parts
278607990171	PUMP FUEL INJECTION 230HP ENGINE	TATA spare parts
278607990171AE	FIP 230HP ENGINE LPT 2523/	TATA spare parts
278607990173	FUEL WATER SEPARATOR	TATA spare parts
278607990173AE	WATER SEPERATOR 2523	TATA spare parts
278607990174	FUEL WATER SEPARATOR	TATA spare parts
278607990178	FUEL INJECTION PUMP (ROTARY) BS1/3	TATA spare parts
278607990214	PUMP FUEL INJECTION BS3	TATA spare parts
278607990218	PUMP FUEL INJECTION	TATA spare parts
278607990224	TUBE FUEL SUPPLY	TATA spare parts
278607990225	FUEL INJECTION PUMP	TATA spare parts
278607990240	PUMP FUEL INJECTION	TATA spare parts
278607990241	INJECTOR	TATA spare parts
278607990317	SOLENOID VALVE	TATA spare parts
278607993101	BEARING CYD ROLLER	TATA spare parts
278607993301	BRACKET MODULE	TATA spare parts
278607993302	BRACKET SENSOR	TATA spare parts
278607993303	BRACKET MODULE	TATA spare parts
278607993304	BRACKET MODULE	TATA spare parts
278607993305	BRACKET FUEL PLUMBING	TATA spare parts
278607993306	BRACKET GMFS	TATA spare parts
278607993307	BRACKET FUEL PLUMBING BS4	TATA spare parts
278607993309	BRACKET FUEL PLUMBING	TATA spare parts
278607993310	BRACKET FUEL PLUMBING	TATA spare parts
278607993311	BRACE FUEL PUMP	TATA spare parts
278607993312	BRACKET SOLENOID	TATA spare parts
278607993701	CLAMP TUBE	TATA spare parts
278607993702	BRACKET FUEL PLUMBING	TATA spare parts
278607993801	HEAD FUEL FILTER	TATA spare parts
278607994201	CLAMP HOSE	TATA spare parts
278607994202	CLAMP TUBE BS4	TATA spare parts
278607994203	CLAMP INJECTOR	TATA spare parts
278607994701	COVER FUEL CO	TATA spare parts
278607994702	PLATE COVER	TATA spare parts
278607994703	COVER FUEL CONTROL	TATA spare parts
278607995301	GASKET PRESSURE MODULE	TATA spare parts
278607995302	GASKET CONNECTION	TATA spare parts
278607995401	GEAR FUEL PUMP	TATA spare parts
278607995402	GEAR FUEL PUMP	TATA spare parts
278607995403	GEAR FUEL PUMP	TATA spare parts
278607995403AE	GEAR FUEL PUMPLPA 1415/LPTA 715/	TATA spare parts

278607995404	GEAR FUEL PUMP	TATA spare parts
278607995405	GEAR FUEL PUMP	TATA spare parts
278607995802	HOSE PLAIN	TATA spare parts
278607995803	HOSE PLAIN	TATA spare parts
278607995804	HOSE FLEXIBLE	TATA spare parts
278607995805	HOSE FLEXIBLE	TATA spare parts
278607995806	HOSE FLEXIBLE	TATA spare parts
278607995808	HOSE FLEXIBLE	TATA spare parts
278607996001	LEVER THROTTLE	TATA spare parts
278607996501	NUT HEXAGON FLANGE	TATA spare parts
278607996502	NUT LOCK	TATA spare parts
278607996901	TUBE FUEL DRAIN BS1/3	TATA spare parts
278607996902	TUBE INJ FUEL SUPPLY	TATA spare parts
278607996903	TUBE AIR FUEL CONTROL	TATA spare parts
278607996904	TUBE FUEL SUPPLY BS3	TATA spare parts
278607996905	TUBE FUEL SUPPLY	TATA spare parts
278607996910	TUBE FUEL SUPPLY	TATA spare parts
278607996911	TUBE FUEL DRAIN	TATA spare parts
278607996912	TUBE AIR FUEL CONTROL	TATA spare parts
278607996913	TUBE PRESSURE SENSING	TATA spare parts
278607996914	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278607996915	TUBE FUEL SUPPLY	TATA spare parts
278607996916	TUBE FUEL SUPPLY	TATA spare parts
278607996917	TUBE FUEL DRAIN	TATA spare parts
278607996918	TUBE FUEL SUPPLY BS3/4	TATA spare parts
278607996919	TUBE FUEL SUPPLY	TATA spare parts
278607996920	TUBE FUEL SUPPLY BS4	TATA spare parts
278607996921	TUBE FUEL DRAIN BS4	TATA spare parts
278607996922	TUBE FUEL DRAIN BS4	TATA spare parts
278607996923	TUBE FUEL DRAIN	TATA spare parts
278607996924	TUBE FUEL DRAIN	TATA spare parts
278607996925	TUBE FUEL DRAIN	TATA spare parts
278607996927	TUBE AIR FUEL CONTROL	TATA spare parts
278607996930	TUBE FUEL SUPPLY	TATA spare parts
278607996931	TUBE FUEL SUPPLY	TATA spare parts
278607996932	TUBE FUEL SUPPLY	TATA spare parts
278607996933	TUBE FUEL SUPPLY BS4	TATA spare parts
278607996934	TUBE FUEL DRAIN BS3/4	TATA spare parts
278607996935	TUBE FUEL SUPPLY BS3/4	TATA spare parts
278607996936	TUBE FUEL SUPPLY	TATA spare parts
278607996937	TUBE FUEL SUPPLY	TATA spare parts
278607996941	TUBE FUEL DRAIN	TATA spare parts
278607996942	TUBE FUEL DRAIN	TATA spare parts
278607996943	TUBE FUEL SUPPLY	TATA spare parts
278607996945	TUBE FUEL SUPPLY	TATA spare parts
278607996948	TUBE FUEL SUPPLY	TATA spare parts
278607996949	TUBE FUEL SUPPLY	TATA spare parts

278607996950	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278607996951	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278607996952	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278607996953	TUBE FUEL SUPPLY	TATA spare parts
278607996954	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278607996955	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278607996957	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278607996958	TUBE FUEL SUPPLY	TATA spare parts
278607996959	TUBE OIL GAUGE	TATA spare parts
278607996960	TUBE FUEL SUPPLY	TATA spare parts
278607996961	TUBE FUEL DRAIN	TATA spare parts
278607996962	TUBE FUEL DRAIN	TATA spare parts
278607996963	TUBE FUEL DRAIN	TATA spare parts
278607996964	TUBE FUEL SUP	TATA spare parts
278607996965	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278607996966	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278607996967	TUBE FUEL DRAIN	TATA spare parts
278607996968	TUBE INJECTOR FUEL	TATA spare parts
278607996969	TUBE INJECTOR FUEL	TATA spare parts
278607996970	TUBE FUEL SUPPLY	TATA spare parts
278607997201	PLUG THREADED	TATA spare parts
278607997701	SEAL O RING	TATA spare parts
278607997702	SEAL O RING	TATA spare parts
278607997704	SEAL O RING	TATA spare parts
278607997705	SEAL O RING	TATA spare parts
278607997706	SEAL O RING	TATA spare parts
278607997707	SEAL O RING	TATA spare parts
278607997708	SEAL O RING	TATA spare parts
278607997709	O RING	TATA spare parts
278607997710	O RING	TATA spare parts
278607997711	SEAL O RING	TATA spare parts
278607997712	SEAL O RING	TATA spare parts
278607997713	SEAL O RING	TATA spare parts
278607997714	SEAL O RING	TATA spare parts
278607997715	SEAL O RING	TATA spare parts
278607997716	SEAL BANJO CONNECTOR	TATA spare parts
278607997717	SEAL O RING	TATA spare parts
278607997718	SEAL O RING	TATA spare parts
278607998001	SCREW FLANGE HEAD CAP	TATA spare parts
278607998002	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278607998003	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278607998004	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278607998005	SCREW HEX FLANGE HEAD CAP BS4	TATA spare parts
278607998006	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278607998008	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278607998009	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278607998010	SCREW STUDDED FLANGE CAP	TATA spare parts

278607998011	SCREW HEX FLA	TATA spare parts
278607998012	SCREW BANJO CONNECTOR	TATA spare parts
278607998601	SPACER	TATA spare parts
278607998801	STUD	TATA spare parts
278607999004	VALVE FUEL FLOW	TATA spare parts
278607999005	VALVE WASTEGATE CONTROL-LEAN BURN ENGIN	TATA spare parts
278607999007	VALVE FUEL FL	TATA spare parts
278607999008	VALVE PRESSURE REGULATOR	TATA spare parts
278607999010	VALVE¿ PRESSURE REGULATOR	TATA spare parts
278607999201	WASHER PLAIN	TATA spare parts
278607999801	CARBURATOR ASSY.	TATA spare parts
278607999802	KIT CONVERSION ROT-INLINE	TATA spare parts
278607999803	KIT CONVER MANUAL SHUTOFF	TATA spare parts
278607999804	CONVERSION KIT F/PUMP	TATA spare parts
278607999805	MOD.CON.KIT FEED PUMP	TATA spare parts
278607999806	GEAR FUEL PUMP	TATA spare parts
278607999807	INLINE FIP LONG BLOCK	TATA spare parts
278607999808	INLINE FIP LONG BLOCK 210HP	TATA spare parts
278607999809	TIMER	TATA spare parts
278607999810	BRACE FUEL PUMP	TATA spare parts
278607999811	BRACE FUEL PUMP	TATA spare parts
278607999812	GEAR FUEL PUMP	TATA spare parts
278607999813	SEAL O RING	TATA spare parts
278607999814	CONTROL FUEL-ADOPTION CAPSULE	TATA spare parts
278607999818	FUEL CLENAER	TATA spare parts
278607999820	NIPPLE COUPLING	TATA spare parts
278607999821	NIPPLE COUPLING	TATA spare parts
278607999822	ELBOW MALE UNION BS3/4	TATA spare parts
278607999823	ELEMENT FUEL FILTER	TATA spare parts
278607999824	SENSOR KNOCK	TATA spare parts
278607999825	SCREEN	TATA spare parts
278607999826	ISOLATOR VIBRATION BS4	TATA spare parts
278607999826AE	ISOLATORVIBRATIONLPTA 1828/	TATA spare parts
278607999827	ISOLATOR VIBRATION BS4	TATA spare parts
278607999827AE	ISOLATOR VIBRATION 1828	TATA spare parts
278607999828	ACTUATOR	TATA spare parts
278607999829	COUPLING ELBOW HOSE	TATA spare parts
278607999830	COUPLING ELBOW HOSE	TATA spare parts
278607999832	FUEL CONNECTOR REMOVER	TATA spare parts
278607999833	Injector Terminal Tightening Tool	TATA spare parts
278607999834	ADAPTER FILTER HEAD	TATA spare parts
278607999835	VALVE SHUTOFF	TATA spare parts
278607999836	COUPLING ELBO	TATA spare parts
278607999837	CONNECTOR QCK	TATA spare parts
278607999838	CONNECTOR MALE	TATA spare parts
278607999839	TEE STREET PIPE	TATA spare parts
278607999840	INJECTOR	TATA spare parts



278607999840AE	INJECTOR 2523	TATA spare parts
278607999842	INJECTOR ASSY.	TATA spare parts
278607999843	ACTUATER THROTTLE	TATA spare parts
278607999844	ADAPTER SENSOR BS4	TATA spare parts
278607999845	FUEL FILTER ELEMENT SPINON BS3/4	TATA spare parts
278607999846	CONNECTOR QCK DISCONNECT BS4	TATA spare parts
278607999847	UNION MALE	TATA spare parts
278607999849	CARBURATOR ASSY	TATA spare parts
278607999854	ADAPTER FUEL CONNECTOR	TATA spare parts
278607999855	UNION MALE	TATA spare parts
278607999856	CONNECTOR	TATA spare parts
278607999857	CONNECTOR QCK DISCONNECT BS4	TATA spare parts
278607999858	CONNECTION ADAPTER	TATA spare parts
278607999860	INJECTOR TERMINAL TIGHTENING TOOL	TATA spare parts
278607999862	Rail Plug ISBe 5.6L & 5.9Umb BS4	TATA spare parts
278607999865	PUMP FUEL TRANSFER	TATA spare parts
278607999867	INJECTOR ISBE5.9 UMB BS4	TATA spare parts
278607999868	PUMP FUEL ISBe5.9 UMB BS4 BS4	TATA spare parts
278607999869	SUPPORT FUEL PUMP	TATA spare parts
278607999870	BRACE FUEL PUMP	TATA spare parts
278607999871	ACCUMMULATOR BS4	TATA spare parts
278607999872	INJECTOR	TATA spare parts
278607999873	PRESSURE SENSOR	TATA spare parts
278607999874	PRESSURE LIMITING VALVE	TATA spare parts
278607999875	CONNECTOR	TATA spare parts
278607999876	CONNECTOR MALE	TATA spare parts
278607999877	ADAPTER FUEL PUMP	TATA spare parts
278607999878	RING RETAINING	TATA spare parts
278607999879	SOLENOID FUEL PUMP	TATA spare parts
278607999880	LEVER SHUTOFF VALVE	TATA spare parts
278607999881	TIMER OVERCRANK	TATA spare parts
278607999883	PUMP FUEL TRANSFER	TATA spare parts
278607999901	ADAPTER BRAKE OVER LEVER	TATA spare parts
278607999902	NIPPLE PLAIN HEXAGON	TATA spare parts
278607999903	STUD	TATA spare parts
278607999904	PIN THROTTLE LEVER PIVOT	TATA spare parts
278607999906	SCREW HEX FLANGE HEAD	TATA spare parts
278607999907	NUT HEXAGONAL FLANGE	TATA spare parts
278607999908	SCREW BANJO CONNECTOR	TATA spare parts
278607999909	SEAL BANJO CONNECTOR	TATA spare parts
278607999910	SEAL O RING BIG	TATA spare parts
278607999911	SEAL O RING SMALL	TATA spare parts
278607999912	SCREW HEX FLANGE HD CAP	TATA spare parts
278607999913	SEAL RECT RING	TATA spare parts
278607999914	CONNECTOR BANJO	TATA spare parts
278607999915	SCREW HEX FLANGE HEAD	TATA spare parts
278607999916	SPACER MOUNTING	TATA spare parts

278607999917	GASKET LIFT PUMP	TATA spare parts
278607999918	GASKET GEAR HSG BS1/2/3/4	TATA spare parts
278607999918AE	GASKET GEAR HSG	TATA spare parts
278607999919	SCREW BANJO CONNECTOR	TATA spare parts
278607999920	COVER GEAR	TATA spare parts
278607999921	SCREW BANJO CONNECTOR	TATA spare parts
278607999922	WASHER SEALING	TATA spare parts
278607999923	WASHER SEALING	TATA spare parts
278607999924	WASHER SEALING	TATA spare parts
278607999925	WASHER SEALING BS1/2/3/4	TATA spare parts
278607999926	GASKET GEAR COVER BS1/2/3/4	TATA spare parts
278607999927	INJECTOR	TATA spare parts
278607999928	CONNECTOR BANJO	TATA spare parts
278607999929	TEE FEMALE BRANCH BS4	TATA spare parts
278607999930	SCREW	TATA spare parts
278607999931	HOSE FLEXIBLE BS4	TATA spare parts
278607999931AE	HOSE FLEXIBLE 2523	TATA spare parts
278607999932	PUMP	TATA spare parts
278607999933	TUBE FUEL DRAIN	TATA spare parts
278607999935	TUBE AIR FUEL CONTROL	TATA spare parts
278607999936	HEAD FUEL FILTER	TATA spare parts
278607999937	BRACE FUEL PUMP	TATA spare parts
278607999938	BRACE FUEL PUMP	TATA spare parts
278607999939	TUBE FUEL SUPPLY	TATA spare parts
278607999940	HOUSING GEAR	TATA spare parts
278607999941	GEAR FUEL PUMP	TATA spare parts
278607999942	FUEL INJ PUMP 160HP INLIN	TATA spare parts
278607999943	BRACKET SOLENIOD	TATA spare parts
278607999944	BRACE AIR COMPRESSOR BS4	TATA spare parts
278607999945	SPACER PUMP SUPPORT	TATA spare parts
278607999946	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278607999946AE	TUBE INJECTOR FUEL SUPPLY 713	TATA spare parts
278607999947	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278607999947AE	TUBE INJECTOR FUEL SUPPLY 713	TATA spare parts
278607999948	HOSE FLEXIBLE	TATA spare parts
278607999949	TUBE FUEL SUPPLY	TATA spare parts
278607999950	SEAL INJECTOR	TATA spare parts
278607999951	STUD(AIR COMPRESSOR-3905371)	TATA spare parts
278607999952	VALVE CHECK	TATA spare parts
278607999953	PLUG PIPE	TATA spare parts
278607999954	SCREW ROUND HEAD CAP BS4	TATA spare parts
278607999955	LEVER THROTTLE	TATA spare parts
278607999956	SCREW HEX HEAD CAP	TATA spare parts
278607999957	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278607999958	NUT HEXAGON FLANGE	TATA spare parts
278607999959	PIN THROTTLE LEVER PIVOT	TATA spare parts
278607999960	SCREW HEX FLANGE HEAD CAP	TATA spare parts

278607999961	LONG BLOCK FOR 4021 TC	TATA spare parts
278607999962	FUEL INJ PUMP 125HP INLIN	TATA spare parts
278607999963	GEAR FUEL PUMP	TATA spare parts
278607999964	TUBE FUEL DRAIN	TATA spare parts
278607999965	KIT MANUAL FUEL SHUT OFF	TATA spare parts
278607999966	MANIFOLD FUEL	TATA spare parts
278607999967	CLAMP HOSE	TATA spare parts
278607999968	CLAMP HOSE	TATA spare parts
278607999969	TUBE FUEL SUPPLY	TATA spare parts
278607999970	TUBE	TATA spare parts
278607999971	PUMP FUEL TRANSFER	TATA spare parts
278607999972	PUMP	TATA spare parts
278607999973	LIFT PUMP CONVERSION KIT	TATA spare parts
278607999974	KIT CONVERSION ROTARY TO INLINE	TATA spare parts
278607999975	HOSE FLEXIBLE	TATA spare parts
278607999976	LONG BLOCK INLINE FIP BS1/2/3	TATA spare parts
278607999977	BRACE FUEL PUMP	TATA spare parts
278607999978	LEVER THROTTLE	TATA spare parts
278607999979	SEAL O RING	TATA spare parts
278607999979AE	SEAL RECTANGULAR RING 715	TATA spare parts
278607999980	BUSHING CAM BORE O/S FOR2.5	TATA spare parts
278607999981	SCREW HEX FLANGE HD CAP	TATA spare parts
278607999982	SEAL RECT RING	TATA spare parts
278607999983	SCREW HEX FLANGE HEAD CAP BS4	TATA spare parts
278607999984	CAP FILLER	TATA spare parts
278607999985	SCREW HEX FLANGE	TATA spare parts
278607999986	SCREW HEX FLANGE HEAD	TATA spare parts
278607999987	BRACE FUEL PUMP	TATA spare parts
278607999988	CLAMP V BAND	TATA spare parts
278607999989	CLIP	TATA spare parts
278607999990	PLUG PIPE	TATA spare parts
278607999991	PUMP FUEL INJECTION	TATA spare parts
278607999992	SCREW DRIVE	TATA spare parts
278607999993	SCREW HEX FLANGE HD CAP	TATA spare parts
278607999994	SCREW TWELVE POINT	TATA spare parts
278607999995	TUBE FUEL SUPPLY	TATA spare parts
278607999996	WASHER LOCK	TATA spare parts
278607999997	COIL IGNITION	TATA spare parts
278607999998	DISTRIBUTOR	TATA spare parts
278607999999	VALVE CARBURATOR	TATA spare parts
278609110101	ASSY BKT F/FILTER MTG	TATA spare parts
278609110104	ASSY. FUEL WATER SEPARATOR BS1/2/3	TATA spare parts
278609110105	BRACKET ASSLY FUEL FILTER MOUNTING	TATA spare parts
278609110106	FUEL FILTER (FWS) W/DRAIN VALVE BS1/2/3	TATA spare parts
278609110110	ASSY. FUEL WATER SEPARATOR BS4/6	TATA spare parts
278609110111	FUEL WATER SEPARATOR ASSY	TATA spare parts
278609113001	FUEL WATER SEPARATOR HEAD ASSY	TATA spare parts

278609113002	FUEL WATER SEPARATOR FILTER ELEMENT	TATA spare parts
278609113301	BRACKET FUEL FILTER MTG.	TATA spare parts
278609114201	CLAMP FUEL SUCTION LINE	TATA spare parts
278609117703	O-RING	TATA spare parts
278609117704	O-RING	TATA spare parts
278609117706	O-RING	TATA spare parts
278609117707	GASKET	TATA spare parts
278609117708	GASKET BS6	TATA spare parts
278609117709	ORING BS6	TATA spare parts
278609119001	VALVE AASY	TATA spare parts
278609119903	FUEL FILTER (FWS) ELEMENT EURO1	TATA spare parts
278609119904	FUEL FILTER ELEMENT SPINON BS1/2/3	TATA spare parts
278609119904AE	ASSY FUEL FLTR -1415-713/5-2523	TATA spare parts
278609119904CS	DEMO CUT SECTION MODEL FOR 278609119904	TATA spare parts
278609119909	FUEL FILTER (FWS) ELEMENT SPINON BS1/2/3	TATA spare parts
278609119910	FUEL FILTER ELEMENT BS4/6	TATA spare parts
278609119914	ASSY. CARTRIDGE BS4	TATA spare parts
278609119916	ASSY. PRIMING PUMP WITH HEAD BS4/6	TATA spare parts
278609119917	ADAPTER	TATA spare parts
278609119918	AIR BLEED ASSY	TATA spare parts
278609119919	SHELL ASSY	TATA spare parts
278609119920	SHELLASSY BS6	TATA spare parts
278609119921	SHELL ASSY BS6	TATA spare parts
278609130102	ASSY STRAP WITH SHACKLE	TATA spare parts
278609130104	CLAMP ASSY	TATA spare parts
278609130105	CLAMP ON CAB REAR WALL	TATA spare parts
278609130119	DUCT AIR INLET FRP	TATA spare parts
278609130120	STRAP W/SHACKLE	TATA spare parts
278609130122	ASSY. PROTECTIVE COVER	TATA spare parts
278609130124	ASSY.BRACKET AIR INTAKE CLAMPING	TATA spare parts
278609130125	ASSY.AIR INLET DUCT(LPT2515BS2 TILT CAB)	TATA spare parts
278609130126	ASSY.AIR FILTER (OFFER DRG).	TATA spare parts
278609130131	ASSEMBLY STRAP WITH SHACKLE	TATA spare parts
278609130134	ASSY. AIR FILTER. OFFER DRG BS1/2/3/4/6	TATA spare parts
278609130136	ASSY.CLAMP	TATA spare parts
278609130137	ASSY STRAP WITH SHACKLE	TATA spare parts
278609130142	PIPE W/STOPPER	TATA spare parts
278609130147	PIPE AIR INLET	TATA spare parts
278609130148	ASSY.AIR FILTER	TATA spare parts
278609130149	ASSY AIR FILTER	TATA spare parts
278609130150	AIR FILTER	TATA spare parts
278609130152	ASSY AIR FILTER LPT2516 EUROII	TATA spare parts
278609130157	ASSY AIR FILTER-OFFER DRG-LPT/LPK1921	TATA spare parts
278609130162	BKT AIR FILTER MTG	TATA spare parts
278609130168	PIPE AIR INLET	TATA spare parts
278609130170	ASSY.AIR FILTER	TATA spare parts
278609130172	ASSY AIR FILTER LPT1615 SLEEPER-OFF.DRG	TATA spare parts

278609130173	ASSEMBLY AIR FILTER MOUNTING BRACKET	TATA spare parts
278609130174	ASSY CLAMP	TATA spare parts
278609130176	ASSY AIR INLET DUCT	TATA spare parts
278609130177	ASSY AIR INLET DUCT	TATA spare parts
278609130180	BKT AIR FILTER MTG	TATA spare parts
278609130181	ASSY.ADAPTOR-FOR SERVICE INDICATOR	TATA spare parts
278609130182	ASSY. ADAPTOR	TATA spare parts
278609130184	ASSY.AIR FILTER MTG.BRACKET.	TATA spare parts
278609130187	ASSY.BRACKET-AIR FILTER MTG.	TATA spare parts
278609130190	ASSY.AIR FILTER -LPT1615 SLEEPER.	TATA spare parts
278609130194	ASSY.AIR FILTER MTG.BRACKET (RHD/LHD)	TATA spare parts
278609130197	ASSY AIR FILTER	TATA spare parts
278609130202	ASSY.AIR FILTER-LP1512TC	TATA spare parts
278609130204	ASSY.PIPE WITH FLANGE.	TATA spare parts
278609130205	ASSY PIPE WITH FLANGE	TATA spare parts
278609130206	ASSY.STRAP WITH SHACKLE	TATA spare parts
278609130207	ASSY.AIR INLET DUCT-LPK 1615TC	TATA spare parts
278609130208	ASSY.BRACKET-FOR DUCT MTG ON CAB REAR	TATA spare parts
278609130209	ASSY.STRAP WITH SHACKLE.	TATA spare parts
278609130213	ASSY.PRE-CLEANER	TATA spare parts
278609130232	ASSY BRACKET-TO CLAMP AIR INTAKE PIPE	TATA spare parts
278609130235	ASSEMBLY AIR CLEANER COMPLETE.	TATA spare parts
278609130247	STUD WING ASSY	TATA spare parts
278609130250	ASSY.AIR FILTER MTG BRACKET	TATA spare parts
278609130257	ASSY.CLAMP-TOP-ON CAB REAR WALL	TATA spare parts
278609130258	ASSY.BRACKET-BOTTOM FOR DUCT MTG ON CAB	TATA spare parts
278609130263	ASSY.AIR FILTER-1512TC	TATA spare parts
278609130275	ASSY.AL PIPE (AIR FILTER TO TC) LPK2516T	TATA spare parts
278609130276	ASSY.AIR FILTER-OFFER DRG LPK2516 LMTC	TATA spare parts
278609130285	ASSY.CLAMP TOP(ON CAB REAR WALL)	TATA spare parts
278609130289	ASSY.BRACKET-AIR INLET DUCT MTG.BOTTOM	TATA spare parts
278609130292	ASSEMBLY AIR FILTER	TATA spare parts
278609130293	ASSY.BRACKET-AIR INLET PIPE SUPPORT	TATA spare parts
278609130294	ASSY.AIR INTAKE PIPE SNORKEL TO A/F	TATA spare parts
278609130295	ASSY.BRACKET(FOR AIR INLET DUCT ON CAB)	TATA spare parts
278609130297	ASSY.STRAP WITH SHACKLE COMPLETE.	TATA spare parts
278609130303	ASSY.AIR CLEANER	TATA spare parts
278609130305	ASSY.AIR FILTER MOUNTING BRACKET	TATA spare parts
278609130307	ASSY.BRACKET (FOR AIR INLET DUCT ON CAB)	TATA spare parts
278609130311	ASSEMBLY AIR INLET DUCT	TATA spare parts
278609130315	ASSY.BRACKET	TATA spare parts
278609130316	ASSY.AIR INLET DUCT	TATA spare parts
278609130320	ASSY.AIR FILTER(W/STOPPER CONE & GUIDE W	TATA spare parts
278609130322	ASSY.BRACKET-AIR INLET DUCT MTG.TOP	TATA spare parts
278609130323	ASSY.AIR INTAKE PIPE	TATA spare parts
278609130324	ASSY.CLAMP	TATA spare parts
278609130325	ASSY AIR FILTER LPT2516 EUROII	TATA spare parts

278609130330	ASSY.AIR FILTER MOUNTING BRACKET	TATA spare parts
278609130333	ASSY AIR INLET DUCT SIDE ENTRY	TATA spare parts
278609130336	ASSY.AIR INTAKE PIPE SNORKEL TO AIR FIL	TATA spare parts
278609130344	ASSY.AIR FILTER 15M3	TATA spare parts
278609130345	ASSEMBLY BRACKET AIR INLET PIPE SUPPORT	TATA spare parts
278609130346	ASSEMBLY BRACKET(AIR INLET DUCT LWR MTG)	TATA spare parts
278609130348	ASSY.AIR FILTER.	TATA spare parts
278609130352	ASSY.AIR FLT MTG.BKT LPT2515/LPS3015 TC	TATA spare parts
278609130353	ASSEMBLY BRACKET AIR FILTER MOUNTING	TATA spare parts
278609130354	ASSY. AIR FILTER MOUNTING BRACKET	TATA spare parts
278609130355	ASSY. AIR INLET DUCT BS1/2/3/4	TATA spare parts
278609130364	ASSY AIR INLET DUCT(SIDE ENTRY) 4018	TATA spare parts
278609130376	ASSY AIR INLET DUCT	TATA spare parts
278609130384	ASSY.AIR FILTER MTG BRACKET	TATA spare parts
278609130385	ASSY.PROTECTIVE COVER	TATA spare parts
278609130397	ASSY.BRACKET(AIR INLET PIPE SUPPORT)	TATA spare parts
278609130398	ASSY.BRACKET(FOR AIR FILTER)	TATA spare parts
278609130399	SET-STRAP ASSY WITH SHACKLE+RUBBER STRPN	TATA spare parts
278609133304	BRACKET BS6	TATA spare parts
278609133318	BRACKET (FOR AIR INTAKE PIPING)	TATA spare parts
278609133342	BRACKET-AIR FILTER MOUNTING	TATA spare parts
278609133347	BRACKET(SNORKEL MOUNTING)	TATA spare parts
278609133353	BRACKET MOUNTING ASSEMBLY	TATA spare parts
278609133354	BRACKET ASSEMBLY	TATA spare parts
278609133360	ASSY BRACKET (AIR FILTER MTG)M0	TATA spare parts
278609133377	BRACKET AIR INTAKE PIPE MTG	TATA spare parts
278609133381	BRACKET AIR FILTER PIPE MTG	TATA spare parts
278609133384	BRACKET	TATA spare parts
278609133804	AL.CAST PIPE	TATA spare parts
278609133805	ALUMINIUM CAST PIPE	TATA spare parts
278609133807	TURBO AIR INLET PIPE	TATA spare parts
278609133814	AIR INTAKE PIPE LPT 2515 TC BS-2	TATA spare parts
278609133815	AIR INTAKE PIPE 2516	TATA spare parts
278609133818	AIR INTAKE PIPE(AIR FILTER TO TC)	TATA spare parts
278609133820	AIR INLET PIPE	TATA spare parts
278609133829	BEND PIPE-CAST	TATA spare parts
278609133830	PIPE ALUMINIUM	TATA spare parts
278609133835	AIR INTAKE CAST PIPE	TATA spare parts
278609133849	CAST PIPE (FROM AIR FILTER OUTLET)RHD	TATA spare parts
278609133852	CAST PIPE AIR FILTER TO MIXER	TATA spare parts
278609133855	AIR INTAKE PIPE-ON TC INLET	TATA spare parts
278609133860	AIR INTAKE PIPE. AIR FILTER TO TC	TATA spare parts
278609133864	ASSY.AL.PIPE-AIR FILTER TO T.C.	TATA spare parts
278609133866	AIR INTAKE PIPE AIR FILTER TO TC	TATA spare parts
278609133867	AIR INTAKE PIPE	TATA spare parts
278609133869	AIR INTAKE PIPE(AIR FILTER TO TC)	TATA spare parts
278609133870	AIR INTAKE PIPE(AIR FLT.TO TC)LPT1418TC	TATA spare parts

278609133872	AIR INTAKE PIPE	TATA spare parts
278609133873	AIR INTAKE PIPE	TATA spare parts
278609133875	AIR INTAKE PIPE(AF TO TC)	TATA spare parts
278609133876	PIPE(AIR INTAKE)	TATA spare parts
278609134203	CLAMP	TATA spare parts
278609134204	CLAMP-FOR ASSY. PIPE	TATA spare parts
278609134210	CLAMP	TATA spare parts
278609134211	CLAMP - DUST VALVE	TATA spare parts
278609134214	CLAMP	TATA spare parts
278609134215	CLAMP	TATA spare parts
278609134216	CLAMP	TATA spare parts
278609134221	CLAMP	TATA spare parts
278609134227	HOSE CLAMP T BOLT.(8140083)	TATA spare parts
278609134228	HOSE CLAMP T BOLT	TATA spare parts
278609134232	CLAMP ( DUST HOSE 40 OD)	TATA spare parts
278609134235	CLAMP	TATA spare parts
278609134236	CLAMP	TATA spare parts
278609135806	HOSE	TATA spare parts
278609135807	HOSE AIR FILTER OUTLET	TATA spare parts
278609135808	HOSE(ON AIR FILTER OUTLET)	TATA spare parts
278609135809	REDUCER BELLOW (ON TC)	TATA spare parts
278609135810	HOSE A/IN DUCT - A/FILTER	TATA spare parts
278609135811	RUBBER ELBOW	TATA spare parts
278609135812	RUBBER HOSE REDUCER	TATA spare parts
278609135813	RUBBER HOSE 102 ID X 80 L	TATA spare parts
278609135814	HOSE-76 ID X 90 LONG	TATA spare parts
278609135815	HOSE (ON AIR FILTER OUTLET)-RH	TATA spare parts
278609135816	HOSE AL PIPE TO PIPE 1312	TATA spare parts
278609135817	HOSE ST PIPE TO PIPE RHD	TATA spare parts
278609135819	HOSE-AIR FILTER OUTLET	TATA spare parts
278609135820	HOSE AIR FILTER OUTLET	TATA spare parts
278609135822	HOSE REDUCER 76X100	TATA spare parts
278609135824	HOSE A/IN DUCT TO A/FILTE	TATA spare parts
278609135825	STRAIGHT HOSE	TATA spare parts
278609135826	HOSE PIPE TO AL PIPE	TATA spare parts
278609135828	REDUCER HOSE LP1312	TATA spare parts
278609135830	HOSE REDUCER PIPE TO TC	TATA spare parts
278609135833	HOSE-DUCT TO FILTER	TATA spare parts
278609135834	REDUCER HOSE (ON AIR FILTER OUTLET)	TATA spare parts
278609135836	HOSE	TATA spare parts
278609135837	REDUCER HOSE (127 TO 102 ID-ELBOW).	TATA spare parts
278609135838	HOSE TC OUTLET	TATA spare parts
278609135840	HOSE-DUCT TO AIR FILTER	TATA spare parts
278609135841	HOSE AIR INLET DUCT TO AIR FILTER	TATA spare parts
278609135845	HOSE (PRECLEANER TO AIR FILTER) LPK 2516	TATA spare parts
278609135846	HOSE BS6	TATA spare parts
278609135847	REDUCER HOSE-127 ID TO 102 ID-150 LONG	TATA spare parts

278609135848	RUBBER BELLOW AIR INLET SNORKEL TO PIPE	TATA spare parts
278609135849	HOSE ON A/F OUTLET LPK 2516TC 6X4	TATA spare parts
278609135852	RUBBER HOSE-AIR INTAKE PIPE TO TC	TATA spare parts
278609135853	COBRA TYPE HOSE-LPO1616TC	TATA spare parts
278609135856	RUBBER HOSE	TATA spare parts
278609135857	HOSE-FLEXIBLE	TATA spare parts
278609135858	FLEXIBLE HOSE	TATA spare parts
278609135860	HOSE(DUCT TO PRECLEANER)	TATA spare parts
278609135861	COBRA HOSE 110DEG.	TATA spare parts
278609135861AE	COBRA HOSE 110DEG.LPA 1415/	TATA spare parts
278609135862	RUBBER ELBOW	TATA spare parts
278609135865	STRAIGHT HOSE(140ID X 100L)	TATA spare parts
278609135866	REDUCER HOSE(140ID TO 127ID)	TATA spare parts
278609135867	HOSE REDUCER	TATA spare parts
278609135868	HOSE DEGREE	TATA spare parts
278609135870	HOSE	TATA spare parts
278609135871	HOSE(102IDX140LONG)	TATA spare parts
278609135872	HOSE REDUCER (BENT) BS3/4/6	TATA spare parts
278609135877	HOSE(152 IDX100LONG)	TATA spare parts
278609135881	RUBBER HOSE (FROM AIR FILTER OUTLET)	TATA spare parts
278609135882	HOSE-FLEXIBLE	TATA spare parts
278609135884	HOSE(TC TO AIR FILTER PIPE)	TATA spare parts
278609135885	REDUCER HOSE (AF BREATHER)	TATA spare parts
278609135886	HOSE (28.6 ID)	TATA spare parts
278609135889	HOSE-FLEXIBLE BS1/2/3/4	TATA spare parts
278609135895	HOSE(102X80) LPO1925	TATA spare parts
278609135897	ELBOW&HOSE&(LPO&1620)	TATA spare parts
278609135898	HOSE	TATA spare parts
278609136316	BEND PIPE - FRP	TATA spare parts
278609136337	ASSY. DUCT AIR INTAKE BS3/4/6	TATA spare parts
278609136501	NUT	TATA spare parts
278609136502	WING NUT	TATA spare parts
278609136905	AIR INTAKE PIPE 127 OD X 3THK X 470 L	TATA spare parts
278609136911	AL.PIPE-400 LG.	TATA spare parts
278609136913	PIPE	TATA spare parts
278609136923	PIPE AIR INTAKE	TATA spare parts
278609136924	PIPE AIR FILTER TO TC	TATA spare parts
278609136925	PIPE (101.6 DIA X 270 LONG).	TATA spare parts
278609136926	PIPE	TATA spare parts
278609136927	BEND PIPE	TATA spare parts
278609136933	AIR INTAKE PIPE-102 OD X 515L	TATA spare parts
278609136938	PIPE ALUMINIUM	TATA spare parts
278609136940	PIPE ALUMINIUM	TATA spare parts
278609136941	ALUMINUM PIPE 475MM LONG	TATA spare parts
278609136945	AIR INTAKE PIPE 101.6 OD	TATA spare parts
278609136947	AL.PIPE-127 ID X 295 LONG	TATA spare parts
278609136950	PIPE(127 O.DX 315 LONG)	TATA spare parts



278609136952	AIR INTAKE PIPE	TATA spare parts
278609136954	ASSY. PIPE PLASTIC BS3/4	TATA spare parts
278609136957	PIPE (127 O.D. X 250 LONG)	TATA spare parts
278609136969	AIR INTAKE PIPE	TATA spare parts
278609136974	PIPE( AIR INTAKE)	TATA spare parts
278609136975	PIPE ELBOW (28.6 OD)	TATA spare parts
278609136979	PIPE (102 OD)	TATA spare parts
278609136984	PIPE AIR INTAKE	TATA spare parts
278609136989	PIPE AIR INTAKE	TATA spare parts
278609136990	PIPE AIR INTAKE	TATA spare parts
278609137701	RUBBER PACKING 160 X 130 X 2.5	TATA spare parts
278609137706	GASKET IRRG-	TATA spare parts
278609137707	U SEAL	TATA spare parts
278609137713	GASKET (U SEAL)	TATA spare parts
278609138293	PLATE POWDER COATED(8391221)	TATA spare parts
278609138601	RUBBER SPACER	TATA spare parts
278609138602	RUBBER SPACER	TATA spare parts
278609138605	RUBBER BUFFER	TATA spare parts
278609139101	SEAL¿ASY¿(BOLT¿SEAL)	TATA spare parts
278609139901	ADAPTOR	TATA spare parts
278609139905	AIR FILTER ELEMENT-PRIMARY	TATA spare parts
278609139906	AIR FILTER ELEMENT-SAFETY	TATA spare parts
278609139908	AIR FILTER PRIMARY ELEMENT BS1/2/3/4/6	TATA spare parts
278609139908AE	AIR FILTER -PRIMARY 1415/ 715	TATA spare parts
278609139908CS	DEMO CUT SECTION MODEL FOR 278609139908	TATA spare parts
278609139909	AIR FILTER ELEMENT SAFETY BS1/2/3/4/6	TATA spare parts
278609139909AE	A/FILTER ELEMENT SAFETY	TATA spare parts
278609139910	AIR FILTER ELEMENT-PRIMARY BS1/2/3/4	TATA spare parts
278609139911	AIR FILTER ELEMENT SAFETY BS1/2/3/4	TATA spare parts
278609139911AE	FILTER ELEMENT SAFETY 713 715	TATA spare parts
278609139912	DUST VALVE	TATA spare parts
278609139914	ADAPTER SERVICE INDICATOR	TATA spare parts
278609139918	ADAPTER	TATA spare parts
278609139920	ADAPTOR (M10X1 FEMALE TO 1/8INCH FEMALE)	TATA spare parts
278609139921	ADAPTOR LPTA 713 TC	TATA spare parts
278609139922	ADAPTOR	TATA spare parts
278609139923	ADAPTOR-1/8NPTF X 1/8NPTF	TATA spare parts
278609139931	AIR FILTER ELEMENT-PRIMARY BS2/3/4	TATA spare parts
278609139932	ELEMENT AIR CLEANER(SAFETY) BS2/3/4	TATA spare parts
278609139934	RESTRICTION INDICATOR ELECTROMECHANICAL	TATA spare parts
278609139935	AIR FILTER ELEMENT SAFETY BS3/4/6	TATA spare parts
278609139936	AIR FILTER PRIMARY ELEMENT BS1/2/3/4/6	TATA spare parts
278609139941	HOSE CLAMP SFC410	TATA spare parts
278609140105	ASSY. AIR FILTER	TATA spare parts
278609140107	PRE CLEANER BS1/3/4/6	TATA spare parts
278609140109	ASSY.PIPE WITH FLANGE	TATA spare parts
278609140110	ASSY.PIPE(AF TO TC)	TATA spare parts

278609140112	ASSY PIPE WITH FLANGE	TATA spare parts
278609140120	ASSY.AIR FILTER MTG.BRACKET	TATA spare parts
278609140126	ASSY.AIR CLEANER	TATA spare parts
278609140129	BRACKET ( FOR SNORKEL SUPPORT)	TATA spare parts
278609140130	ASSY. AIR INLET DUCT(SIDE ENTRY) BS2/3/4	TATA spare parts
278609140134	ASSY. AIR FILTER (M/S FLEETGUARD)BS2/3/4	TATA spare parts
278609140136	ASSY PRE CLEANER	TATA spare parts
278609140137	ASSY AIR INLET DUCT(SIDE ENTRY)	TATA spare parts
278609140138	ASSY.AIR INLET DUCT(COSMOS)	TATA spare parts
278609140139	ASSY. SUPPORT(FOR SNORKEL)	TATA spare parts
278609140140	DAMPER ASSEMBLY	TATA spare parts
278609140141	BRACKET MOUNTING ASSEMBLY	TATA spare parts
278609140142	ASSY. PRECLEANER,PLASTIC BS3/4	TATA spare parts
278609140149	ASSY. AIR CLEANER BS3/4/6	TATA spare parts
278609140152	BRACKET ASY(8359218)	TATA spare parts
278609140153	BRACKET ASSEMBLY	TATA spare parts
278609140157	ASSY.SUPPORT (AIR INTAKE PIPE)	TATA spare parts
278609140159	ASSY PIPE	TATA spare parts
278609140160	ASSY BRACKET (AIR FILTER MOUNTING)	TATA spare parts
278609140164	ASSY.AIR CLEANER(LPT2523TC)	TATA spare parts
278609140165	DAMPER ASSY.(8090376)	TATA spare parts
278609140168	ASSY. AIR FILTER LPS 4018 BS1/3/4/6	TATA spare parts
278609140169	PRE CLEANER METAL	TATA spare parts
278609140170	ASSY AIR INTAKE PIPE SNORKEL TO AIR FIL	TATA spare parts
278609140171	ASSY. AIR FILTER LPT 2518 TC BS3 TILT C	TATA spare parts
278609140172	ASSY.BRACKET(PRECLEANER MTG.)	TATA spare parts
278609140173	ASSY.AIR INTAKE PIPE BRACKET	TATA spare parts
278609140177	ASSY BRACKET (AIR INLET DUCT MTG-TOP)	TATA spare parts
278609140178	ASSY BRACKET(AIR.INLET DUCT MTG BOTTOM)	TATA spare parts
278609140179	ASSY. PROTECTIVE COVER	TATA spare parts
278609140181	ASSY.AIR FILTER	TATA spare parts
278609140185	ASSY BRACKET SNORKEL MTG UPPER SIDE (M0)	TATA spare parts
278609140186	ASSY BRACKET PIPE SUPPORT TOP SIDE (M0)	TATA spare parts
278609140188	ASSY BRACKET	TATA spare parts
278609140191	ASSY.BRACKET-PRECLEANER MTG	TATA spare parts
278609140192	ASSY.BRACKET (FOR AIR INLET DUCT TOP)	TATA spare parts
278609140194	SUPPORT BKT	TATA spare parts
278609140201	ASSY AIR FILTER MTG.BRACKET.	TATA spare parts
278609140202	ASSY AIR FILTER MTG.BRACKET.	TATA spare parts
278609140210	ASSY AIR FILTER MTG BRACKET	TATA spare parts
278609140215	ASSY STRAP WITH SHACKLE	TATA spare parts
278609140217	ASSY.PRE CLEANER-PLASTIC	TATA spare parts
278609140234	ASSY. COVER TOP BS3/4/6	TATA spare parts
278609140243	ASSY.AIR FILTER MOUNTING BRACKET	TATA spare parts
278609140247	AIR FILTER ASSY	TATA spare parts
278609140250	BRACKET ASSY AIR INTAKE DUCT	TATA spare parts
278609140251	AIR INTAKE SYSTEM ASSY	TATA spare parts

278609140258	SUPPORT BRACKET AIR INTAKE PIPE	TATA spare parts
278609140261	BRACKET PRE FILTER MTG	TATA spare parts
278609140262	BRACKET	TATA spare parts
278609140267	DAMPER ASSY BS6	TATA spare parts
278609140309	AIR FILTER ASSY WITH PRE CLEANER	TATA spare parts
278609140314	KIT-AIR INTAKE ASSY	TATA spare parts
278609145807	GASKET IRRG	TATA spare parts
278609145808	HOSE TC INTAKE	TATA spare parts
278609145809	RUBBER HOSE PIPE TO TC	TATA spare parts
278609145810	REDUCER HOSE	TATA spare parts
278609145811	REDUCER HOSE	TATA spare parts
278609145812	HOSE REDUCER HUMP	TATA spare parts
278609145815	HOSE HUMP WITH ELBOW	TATA spare parts
278609145816	HOSE TC INTAKE	TATA spare parts
278609145817	REDUCER HOSE	TATA spare parts
278609145818	HOSE TC INTAKE	TATA spare parts
278609145820	HOSE	TATA spare parts
278609989901	NUT WELD	TATA spare parts
278609989902	WASHER PLAIN	TATA spare parts
278609989903	BRACKET FUEL FILTER	TATA spare parts
278609989905	BUSHING REDUCING PIPE	TATA spare parts
278609989906	SET OF 2516 AIR FILTER CARTRIDGES	TATA spare parts
278609989907	SET OF 1613 AIR FILTER CARTRIDGES	TATA spare parts
278609990118	PIPE AIR TRANSFER BS4	TATA spare parts
278609990120	CONNECTION AIR INTAKE	TATA spare parts
278609990122	COVER INTAKE MANIFOLD	TATA spare parts
278609990126	CONNECTION AIR INTAKE	TATA spare parts
278609990141	FUEL FILTER SPINON BS4	TATA spare parts
278609993301	BRACKET PUMP	TATA spare parts
278609993302	BRACKET FUEL PLUMBING	TATA spare parts
278609993303	BRACKET PUMP	TATA spare parts
278609993701	CONNECTION AIR INTAKE	TATA spare parts
278609993702	CONNECTION AIR INTAKE	TATA spare parts
278609994201	CLAMP V BAND	TATA spare parts
278609995301	GASKET CONNECTION	TATA spare parts
278609995302	GASKET CONNECTION	TATA spare parts
278609995303	GASKET FILTER	TATA spare parts
278609995802	COUPLING PLAIN HOSE	TATA spare parts
278609996901	PIPE AIR TRANSFER	TATA spare parts
278609996902	TUBE AIR TRANSFER	TATA spare parts
278609996903	TUBE AIR FUEL CONTROL	TATA spare parts
278609996905	PIPE AIR TRANSFER	TATA spare parts
278609996906	PIPE AIR TRANSFER	TATA spare parts
278609996907	PIPE AIR TRANSFER	TATA spare parts
278609998001	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278609998002	SCREW BANJO CONNECTOR	TATA spare parts
278609998003	SCREW STUDED FLANGE CAP	TATA spare parts

278609998004	SCREW BANJO CONNECTOR	TATA spare parts
278609998005	SCREW STUDDED FLANGE CAP	TATA spare parts
278609998006	SCREW STUDDED FLANGE CAP	TATA spare parts
278609998007	SCREW CAPTIVE WASHER CAP	TATA spare parts
278609998601	CONNECTION SPACER	TATA spare parts
278609998602	SPACER MOUNTING	TATA spare parts
278609999001	VALVE AIR FUEL THROTTLE	TATA spare parts
278609999002	VALVE AIR FUEL THROTTLE	TATA spare parts
278609999801	ADAPTER AIR INLET	TATA spare parts
278609999802	VENTURI AIR FUEL MIXER	TATA spare parts
278609999803	NIPPLE PLAIN PIPE	TATA spare parts
278609999804	CONNECTION AIR INTAKE	TATA spare parts
278609999808	PUMP FUEL TRANSFER	TATA spare parts
278609999809	GASKET CONNECTION	TATA spare parts
278609999812	CONNECTION AIR INTAKE	TATA spare parts
278609999817	AIR FILTER ELEMENT PRIMARY	TATA spare parts
278609999818	AIR FILTER ELEMENT SAFETY	TATA spare parts
278609999819	AIR FILTER ELEMENT PRIMARY	TATA spare parts
278609999820	AIR FILTER ELEMENT SAFETY	TATA spare parts
278609999822	FUEL FILTER ELEMENT BS3/4	TATA spare parts
278609999823	PUMP FUEL TRANSFER	TATA spare parts
278609999826	CLEANER AIR	TATA spare parts
278609999827	SEPARATOR FUEL WATER	TATA spare parts
278609999828	FUEL FILTER ELEMENT BS4/6	TATA spare parts
278609999829	HEAD FUEL FILTER	TATA spare parts
278609999830	BRACKET FILTER	TATA spare parts
278609999831	COUPLING ELBOW HOSE	TATA spare parts
278609999833	PIPE AIR TRANSFER	TATA spare parts
278609999835	HEAD FUEL FILTER	TATA spare parts
278609999901	SCREW HEX FLANGE HD CAP	TATA spare parts
278609999902	NUT	TATA spare parts
278609999903	ADAPTER FILTER HEAD	TATA spare parts
278609999904	HEAD FUEL FILTER	TATA spare parts
278609999907	SEPARATOR FUEL WATER	TATA spare parts
278609999908	HEAD FUEL FILTER	TATA spare parts
278609999908AE	HEAD FUEL FILTER	TATA spare parts
278609999909	HOSE PLAIN	TATA spare parts
278609999910	CLAMP HOSE	TATA spare parts
278609999911	SCREW BANJO CONNECTOR	TATA spare parts
278609999912	SCREW BANJO CONNECTOR	TATA spare parts
278609999913	MANIFOLD FUEL	TATA spare parts
278609999914	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278609999915	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278609999916	TUBE FUEL SUPPLY	TATA spare parts
278609999917	NIPPLE PLAIN HEXAGON	TATA spare parts
278609999918	FUEL INJ PUMP 145HP INLIN	TATA spare parts
278609999919	WASHER M10	TATA spare parts

27860999920	FUEL STRAINER BS1/2/3	TATA spare parts
27860999920AE	STRAINER FUEL	TATA spare parts
27860999921	HOSE PLAIN	TATA spare parts
27860999922	CLAMP HOSE BS1/2/3	TATA spare parts
27860999924	TUBE	TATA spare parts
27860999925	SCREW	TATA spare parts
27860999926	LEVER FUEL SHUT-OFF	TATA spare parts
27860999927	BRACKET	TATA spare parts
27860999928	SCREW HEX FLANGE HEAD CAP	TATA spare parts
27860999929	SCREW	TATA spare parts
27860999930	BRACKET	TATA spare parts
27860999931	COTTER PIN	TATA spare parts
27860999932	INJECTOR	TATA spare parts
27860999933	SEAL INJECTOR	TATA spare parts
27860999934	COVER INTAKE MANIFOLD	TATA spare parts
27860999935	WASHER SEALING	TATA spare parts
27860999936	PLUG THREADED	TATA spare parts
27860999937	GASKET INTAKE MANIFOLD	TATA spare parts
27860999938	ELBOW MALE ADAPTER	TATA spare parts
27860999939	TUBE AIR FUEL CONTROL	TATA spare parts
27860999940	SEAL O RING	TATA spare parts
27860999941	HOSE FLEXIBLE	TATA spare parts
27860999942	TUBE FUEL DRAIN	TATA spare parts
27860999943	PUMP FUEL LIFT ROTARY	TATA spare parts
27860999944	GASKET FUEL PUMP	TATA spare parts
27860999945	GEAR FUEL PUMP	TATA spare parts
27860999946	TUBE AIR FUEL CON	TATA spare parts
27860999947	TUBE FUEL SUPPLY	TATA spare parts
27860999948	TUBE FUEL DRAIN	TATA spare parts
27860999949	TUBE FUEL DRAIN	TATA spare parts
27860999950	TUBE FUEL SUPPLY	TATA spare parts
27860999951	FUEL STRAINER BS1/2/3/4	TATA spare parts
27860999952	TUBE FUEL SUPPLY	TATA spare parts
27860999953	SEPERATOR FUEL WATER	TATA spare parts
27860999954	PUMP LIFT	TATA spare parts
27860999955	PUMP FUEL TRANSFER	TATA spare parts
27860999956	PUMP FUEL TRANSFER INLINE	TATA spare parts
27860999957	VALVE DRAIN FUEL WATER EURO1	TATA spare parts
27860999958	FUEL FILTER SEC ELEMENT	TATA spare parts
27860999959	SENSOR FUEL FLOW BS3/4	TATA spare parts
27860999960	VALVE FUEL CONTROL	TATA spare parts
27860999961	VALVE FUEL SHUT OFF	TATA spare parts
27860999962	GASKET FILTER HEAD BS4	TATA spare parts
27860999962AE	GASKET FILTER HEAD 1415/715	TATA spare parts
27860999963	HEAD FUEL FILTER	TATA spare parts
27860999964	HOSE FOR GAS ID 15.9MM X 20INCH LONG	TATA spare parts
27860999965	HOSE FOR GAS ID 25.4MM X 47 INCH LONG	TATA spare parts

27860999966	HOSE FOR GAS ID 15.9MM X 20INCH LONG	TATA spare parts
27860999967	HOSE GAS SHUT OFF TO LP FILTER	TATA spare parts
27860999968	HOSE FOR GAS ID 25.4MM X 47 INCH LONG	TATA spare parts
27860999972	WIRING HARNESS	TATA spare parts
27860999973	HOSE FLEXIBLE	TATA spare parts
27860999974	HOSE FLEXIBLE	TATA spare parts
27860999975	MIXER AIR FUEL	TATA spare parts
27860999976	ELBOW	TATA spare parts
27860999977	ADAPTOR PLAIN	TATA spare parts
27860999978	OXIGEN SENSOR	TATA spare parts
27860999979	BRACKET SOLENOID	TATA spare parts
27860999980	BRACKET MODULE	TATA spare parts
27860999981	BKT MNTG	TATA spare parts
27860999982	VALVE SOLENOID	TATA spare parts
27860999984	TEE CONNECTOR	TATA spare parts
27860999985	HOSE	TATA spare parts
27860999986	CONNECTOR-A/F CNTROLR TO CARBU	TATA spare parts
27860999987	CLAMPS	TATA spare parts
27860999988	STEP CONNECTION	TATA spare parts
27860999989	STEP CONNECTION	TATA spare parts
27860999990	LP FILTER OUT. CONN.	TATA spare parts
27860999991	HOSE	TATA spare parts
27860999993	COVER GEAR BS1/2/3/4	TATA spare parts
27860999996	CAP SCREW (M4X20)	TATA spare parts
27860999998	CAP SCREW(M8X40)	TATA spare parts
27860999999	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278613103301	BRACKET	TATA spare parts
278613103303	BRACKET	TATA spare parts
278613103304	BRACKET AIR COMPRESSOR INTAKE PIPE MTG	TATA spare parts
278613130103	ASSY TUBE W/FITTINGS ON A/C TO A/F LPT25	TATA spare parts
278613130104	ASSY TUBE W/FITTINGS ON A/C INLET LPT251	TATA spare parts
278613130109	ASSY. BENT TUBE	TATA spare parts
278613130110	ASSY TUBE	TATA spare parts
278613130120	ASSY TUBE WITH FERRULE & COUPLING NUT.	TATA spare parts
278613130123	ASSY.TUBE WITH FERRULE AND CAP NUT	TATA spare parts
278613130124	ASSY TUBE W/FITTINGS ON A/C INLET LPT251	TATA spare parts
278613130127	ASSY.TUBE WITH FERRULE & CAP NUT	TATA spare parts
278613130129	ASSY.TUBE WITH FERRULE & CAP NUT.	TATA spare parts
278613130130	ASSY.TUBE WITH FERRULE & CAP NUT.	TATA spare parts
278613130135	ASSY.SUCTION HOSE(AIR COMP)	TATA spare parts
278613130141	ASSY.TUBE WITH CRIMPED RUBBER HOSE(COMP.	TATA spare parts
278613130144	ASSY.TUBE WITH FERRULE & CAP NUT.	TATA spare parts
278613130149	ASSY.TUBE WITH CRIPPED RUBBER HOSE	TATA spare parts
278613130150	ASSY CRIPPED HOSE	TATA spare parts
278613130152	ASSY TUBE WITH CRIPPED RUBBER HOSE	TATA spare parts
278613130159	COUPLING BODY AIR COMPRESSOR	TATA spare parts
278613130160	HOSE CRIMP AIR INTAKE TO AIR COMPRESSOR	TATA spare parts

278613130165	PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
278613130166	PIPE ASSY WITH CRIMPED HOSE AIR COMP	TATA spare parts
278613130167	HOSE AIR COMPRESSOR INTAKE	TATA spare parts
278613130168	PIPE ASSY WITH CRIMPED HOSE AIR COMP	TATA spare parts
278613130170	PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
278613130171	PIPE ASSY WITH CRIMPED HOSE AIR COMP	TATA spare parts
278613133303	BRACKET	TATA spare parts
278613134201	CLAMP(FORCOMPRESSOR INLET PIPE)	TATA spare parts
278613134203	CLAMP	TATA spare parts
278613135801	HOSE 18 ID	TATA spare parts
278613135802	HOSE AIR COMPRESSOR	TATA spare parts
278613135803	HOSE	TATA spare parts
278613135804	HOSE(AIR COMP)	TATA spare parts
278613135805	HOSE AIR COMPRESSOR	TATA spare parts
278613135807	HOSE RUBBER	TATA spare parts
278613136301	COUPLING BODY	TATA spare parts
278613136801	COUPLING BODY	TATA spare parts
278613136802	COUPLING BODY (ON A.COMP.INLET)	TATA spare parts
278613136804	COUPLING BODY	TATA spare parts
278613136905	TUBE AIR COMPRESSOR	TATA spare parts
278613136907	BENT TUBE A/C INLET 1312	TATA spare parts
278613136912	TUBE	TATA spare parts
278613136913	TUBE	TATA spare parts
278613136916	TUBE LP1312	TATA spare parts
278613136917	TUBE A.F.OUTLET TO AIR COMP.	TATA spare parts
278613136920	AIR PIPE	TATA spare parts
278613136929	TUBE	TATA spare parts
278613136952	TUBE-18 O.D.X1.5 THK.MASTER	TATA spare parts
278613990102	AIR COMPRESSOR	TATA spare parts
278613990103	REED VALVE KIT	TATA spare parts
278613990110	COMPRESSOR AIR	TATA spare parts
278613990112	COMPRESSOR AIR BS3	TATA spare parts
278613990114	COMPRESSOR AIR	TATA spare parts
278613990116	COMPRESSOR AIR	TATA spare parts
278613990117	COMPRESSOR AIR	TATA spare parts
278613990118	TUBE CPR	TATA spare parts
278613990119	TUBE CPR WATER INLET BS3	TATA spare parts
278613990120	TUBE CPR WATER OUTLET BS2/3/4	TATA spare parts
278613990122	COMPRESSOR AIR	TATA spare parts
278613990123	AIR COMPRESSOR	TATA spare parts
278613990124	COMPRESSOR AIR BS2/3/4	TATA spare parts
278613990125	TUBE CPR WATER OUTLET	TATA spare parts
278613990128	TUBE CPR WATER OUTLET	TATA spare parts
278613990131	COMPRESSOR AIR	TATA spare parts
278613990132	COMPRESSOR AIR	TATA spare parts
278613990133	KIT AIR COMPRESSOR REPAIR	TATA spare parts
278613990136	COMPRESSOR AIR	TATA spare parts

278613990136AE	COMPRESSOR AIR	TATA spare parts
278613990137	COMPRESSOR AIR	TATA spare parts
278613990153	COMPRESSOR AIR BS2/3/4	TATA spare parts
278613990154	AIR COMPRESSOR BS1/3/4	TATA spare parts
278613990155	AIR COMPRESSOR	TATA spare parts
278613990156	COMPRESSOR AIR BS2/3	TATA spare parts
278613990159	KIT-AIR COMPRESSOR PISTON	TATA spare parts
278613990161	COMPRESSOR AIR	TATA spare parts
278613990162	CYLINDER HEAD ASSEMBLY	TATA spare parts
278613990163	CYLINDER HEAD REPAIR KIT	TATA spare parts
278613990164	CYLINDER HEAD ASSEMBLY	TATA spare parts
278613990165	PRç REPAIR KIT	TATA spare parts
278613990166	VALVE PLATE ASSEMBLY	TATA spare parts
278613990167	PISTON ASSY REPAIR KIT (STD) 85 DIA	TATA spare parts
278613990168	CRANK CASE KIT	TATA spare parts
278613990169	RING KIT	TATA spare parts
278613990170	KIT COMPR. 318CC CRANKCASE&PISTON ASSY	TATA spare parts
278613990171	VALVE PLATE ASSEMBLY	TATA spare parts
278613990173	PISTON ASSEMBLY DIA 80MM	TATA spare parts
278613990176	CYLINDER HEAD KIT	TATA spare parts
278613990177	VALVE PLATE KIT	TATA spare parts
278613990178	HEAD MINOR KIT	TATA spare parts
278613990179	HEAD MAJOR KIT	TATA spare parts
278613990180	CRANK CASE KIT	TATA spare parts
278613990181	MAJOR OVERHAUL KIT	TATA spare parts
278613990182	GASKET AND SEALING RING KIT	TATA spare parts
278613990183	RING KIT-STD	TATA spare parts
278613990184	RING KIT-1ST O/S	TATA spare parts
278613990185	RING KIT-2ND O/S	TATA spare parts
278613990186	CRANK CASE & PISTON ASSEMBLY KIT	TATA spare parts
278613990187	ASSY. CYLINDER HEAD BS1/3/4	TATA spare parts
278613990188	VALVE PLATE ASSEMBLY	TATA spare parts
278613990189	PISTON ASSEMBLY	TATA spare parts
278613990190	AIR COMPRESSOR	TATA spare parts
278613990199	AIR COMPRESSOR ASSY	TATA spare parts
278613990201	KIT PISTON AND ROD BS6	TATA spare parts
278613990202	KIT - LOCK NUT AND COVER SCREW BS6	TATA spare parts
278613990301	CONNECTING ROD	TATA spare parts
278613990302	CRANK SHAFT	TATA spare parts
278613993301	BRACE AIR COMPRESSOR	TATA spare parts
278613993302	BRACE TUBE	TATA spare parts
278613993303	BRACE AIR COMPRESSOR	TATA spare parts
278613993304	BRACKET MOUNTING	TATA spare parts
278613993401	BUSHING REDUCING PIPE	TATA spare parts
278613993801	ELBOW PLAIN STREET PIPE	TATA spare parts
278613993802	CYLINDER HEAD (M/C)	TATA spare parts
278613993803	CYLINDER BLOCK MACHINED	TATA spare parts



278613993804	CYLINDER HEAD	TATA spare parts
278613993805	MANIFOLD	TATA spare parts
278613993806	CRANKCASE	TATA spare parts
278613994201	CLAMP SPRING HOSE	TATA spare parts
278613994202	CLAMP RETAINING	TATA spare parts
278613994301	CLIP	TATA spare parts
278613994302	CLIP	TATA spare parts
278613994303	CLIP	TATA spare parts
278613994304	CLIP	TATA spare parts
278613994305	CLIP	TATA spare parts
278613994306	CLIP	TATA spare parts
278613994307	CLIP	TATA spare parts
278613994701	COVER AIR COMPRESSOR	TATA spare parts
278613994702	COVER AIR COMPRESSOR	TATA spare parts
278613994703	COVER AIR COMPRESSOR	TATA spare parts
278613994704	CYLINDER HEAD COVER	TATA spare parts
278613994707	COVER	TATA spare parts
278613994708	REAR END COVER	TATA spare parts
278613994709	FRONT END COVER	TATA spare parts
278613994710	REAR END COVER	TATA spare parts
278613995301	GASKET ACC DRIVE COVER	TATA spare parts
278613995310	GASKET KIT	TATA spare parts
278613995401	GEAR ACCESSORY DRIVE	TATA spare parts
278613995402	GEAR ACCESSORY DRIVE	TATA spare parts
278613995403	TOOTHED GEAR	TATA spare parts
278613995801	HOSE FLEXIBLE	TATA spare parts
278613995802	HOSE PLAIN	TATA spare parts
278613995802AE	HOSE PLAIN	TATA spare parts
278613995803	HOSE PLAIN BS2/3/4	TATA spare parts
278613995804	HOSE PLAIN	TATA spare parts
278613995805	HOSE FLEXIBLE	TATA spare parts
278613995806	HOSE FLEXIBLE	TATA spare parts
278613995807	HOSE PLAIN	TATA spare parts
278613995808	HOSE FLEXIBLE	TATA spare parts
278613995809	HOSE PLAIN 1150 MM	TATA spare parts
278613995810	HOSE FLEXIBLE	TATA spare parts
278613995811	FLEXIBLE HOSE	TATA spare parts
278613995812	HOSE FLEXIBLE	TATA spare parts
278613996501	NUT HEXAGON FLANGE	TATA spare parts
278613996601	PISTON	TATA spare parts
278613996603	PISTON ASSEMBLY	TATA spare parts
278613996605	PISTON ASSEMBLY	TATA spare parts
278613996609	PISTON ENGINE	TATA spare parts
278613996801	ELBOW PLAIN STREET PIPE	TATA spare parts
278613996802	COUPLING ELBOW HOSE	TATA spare parts
278613996803	COUPLING PLAIN HOSE	TATA spare parts
278613996804	CONNECTOR QCK DISCONNECT BS4	TATA spare parts

278613996805	CONNECTOR MALE	TATA spare parts
278613996806	CONNECTOR TUBE	TATA spare parts
278613996901	TUBE CPR WATER OUTLET	TATA spare parts
278613996902	TUBE CPR WATER INLET	TATA spare parts
278613996903	TUBE CPR WATER INLET	TATA spare parts
278613996904	TUBE CPR WATER OUTLET)	TATA spare parts
278613996908	TUBE CPR WATER OUTLET	TATA spare parts
278613996909	BRACE TUBE	TATA spare parts
278613996910	TUBE CPR WATER INLET	TATA spare parts
278613996911	TUBE CPR WATER OUTLET BS4	TATA spare parts
278613996912	TUBE CPR WATER OUTLET	TATA spare parts
278613996913	TUBE CPR WATER OUTLET	TATA spare parts
278613996914	TUBE CPR WATER INLET	TATA spare parts
278613996916	TUBE CPR WATER OUTLET	TATA spare parts
278613996917	TUBE CPR WATER INLET	TATA spare parts
278613996918	TUBE CPR WATER OUTLET	TATA spare parts
278613997701	SEAL AIR COMPRESSOR	TATA spare parts
278613997701AE	SEAL AIR COMPRESSOR 1828 715	TATA spare parts
278613997702	SEAL O RING	TATA spare parts
278613997703	SEAL RECTANGULAR RING	TATA spare parts
278613997709	SEAL O RING	TATA spare parts
278613998001	SCREW HEX FLANGE HEAD	TATA spare parts
278613998002	SCREW HEX FLANGE HEAD	TATA spare parts
278613998003	SCREW BANJO CONNECTOR	TATA spare parts
278613998004	SCREW BANJO CONNECTOR	TATA spare parts
278613998009	SCREW HEXAGON HEAD CAP M5X0.8	TATA spare parts
278613998010	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278613998601	SPACER MOUNTING	TATA spare parts
278613998801	STUD	TATA spare parts
278613998802	STUD DOUBLE END PLAIN	TATA spare parts
278613999004	VALVE	TATA spare parts
278613999101	WASHER SEALING	TATA spare parts
278613999102	WASHER SEALING	TATA spare parts
278613999803	ELBOW PLAIN ADAPTER	TATA spare parts
278613999804	COMPRESSOR AIR BS4	TATA spare parts
278613999805	STRAIGHT ADAPTOR	TATA spare parts
278613999807	CONNECTING ROD AIR COMPRESSOR	TATA spare parts
278613999901	BEARING CON ROD 1.00 MM OVERSIZE	TATA spare parts
278613999902	BEARING CON ROD 0.75 MM OVERSIZE	TATA spare parts
278613999903	SET BEARING CON ROD RS2	TATA spare parts
278613999904	SET-CON ROD BEARING RS1 6BT BS1/2/3	TATA spare parts
278613999905	AIR COMPRESSOR TOP PORT	TATA spare parts
278613999906	COVER AIR COMPRESSOR	TATA spare parts
278613999907	BRACE AIR COMPRESSOR	TATA spare parts
278613999908	COMPRESSOR AIR	TATA spare parts
278613999909	REP KIT MINOR A/COMP	TATA spare parts
278613999910	REP KIT MAJOR A/COMP	TATA spare parts

278613999911	PISTON ASSY AIR COMP	TATA spare parts
278613999912	PISTON RING R/KIT - A/COM	TATA spare parts
278613999914	AIR COMPRESSOR BS1/2/3	TATA spare parts
278613999914AE	COMPRESSOR AIR 713	TATA spare parts
278613999915	AIR COMPRESSOR BS1/2/3	TATA spare parts
278613999915AE	COMPRESSOR AIR TOP PORT 1415	TATA spare parts
278613999916	CYL HEAD GASKET KIT	TATA spare parts
278613999917	MAJOR REPAIR KIT	TATA spare parts
278613999918	REPAIR KIT PISTON RING STD BS1/2/3	TATA spare parts
278613999919	PISTON RING REPAIR KIT O S 1	TATA spare parts
278613999920	PISTON RING REPAIR KIT O S 2	TATA spare parts
278613999921	CYL HEAD AIR COMP	TATA spare parts
278613999922	REED VALVE	TATA spare parts
278613999923	BRACE AIR COMPRESSOR	TATA spare parts
278613999925	BRACE HOSE	TATA spare parts
278613999926	BRACE HOSE	TATA spare parts
278613999927	HOSE FLEXIBLE	TATA spare parts
278613999928	COUPLING PLAIN HOSE	TATA spare parts
278613999930	BRACE AIR COMPRESSOR	TATA spare parts
278613999932	PLUG PIPE	TATA spare parts
278613999933	SUPPORT AIR COMPRESSOR	TATA spare parts
278613999934	COUPLING ELBOW HOSE	TATA spare parts
278613999935	BRACE AIR COMPRESSOR	TATA spare parts
278613999936	COUPLING ELBOW HOSE BS4	TATA spare parts
278613999937	BRACE TUBE BS4	TATA spare parts
278613999939	BRACE AIR COMPRESSOR BS4	TATA spare parts
278613999940	ADAPTER	TATA spare parts
278613999941	ADAPTER	TATA spare parts
278613999942	ADAPTER	TATA spare parts
278613999943	CRANK SHAFT	TATA spare parts
278613999944	CONNECTING ROD	TATA spare parts
278613999945	CONNECTOR	TATA spare parts
278613999946	CONNECTING ROD ASSY	TATA spare parts
278613999947	CRANKSHAFT	TATA spare parts
278613999948	CONNECTING ROD	TATA spare parts
278613999949	CRANK SHAFT	TATA spare parts
278613999966	KIT-AIR COMPRESSOR	TATA spare parts
278613999967	TUBE CPR WATER INLET	TATA spare parts
278613999968	SEAL O RING	TATA spare parts
278613999969	SUPPORT AIR COMPRESSOR	TATA spare parts
278614000101	INTERCOOLER ASSY	TATA spare parts
278614000103	INTERCOOLER ASSY	TATA spare parts
278614110101	ASSY. DOSER PUMP UNIT BS4	TATA spare parts
278614110103	NOZZLE DOSER BS4	TATA spare parts
278614110104	EXHAUST GAS PROCESSOR (210-300 HP)	TATA spare parts
278614110106	SET AFTER TREATMENT SYSTEM (LPO 1623TC)	TATA spare parts
278614110107	EXHAUST GAS PROCESSOR BS4	TATA spare parts

278614110110	EXHAUST GAS PROCESSOR BS4	TATA spare parts
278614110114	AFTER TREATMENT SYSTEM ASSY	TATA spare parts
278614110115	AFTER TREATMENT SYSTEM ASSY	TATA spare parts
278614110116	EXHAUST GAS PROCESSOR	TATA spare parts
278614110118	EXHAUST GAS PROCESSOR	TATA spare parts
278614110124	EXHAUST GAS PROCESSOR	TATA spare parts
278614110126	EXHAUST GAS PROCESSOR BS4	TATA spare parts
278614110127	SET-AFTER TREATMENT SYSTEM	TATA spare parts
278614110128	ASSY. DOSER PUMP UNIT BS4	TATA spare parts
278614110129	UREA TANK ASSY	TATA spare parts
278614110130	ASSY. UREA TANK BS4	TATA spare parts
278614110131	ASSY. PIPE BS4	TATA spare parts
278614110132	PIPE ASSY	TATA spare parts
278614110134	PIPE ASSY	TATA spare parts
278614110135	ASSY. PIPE BS4	TATA spare parts
278614110136	ASSY. PIPE BS4	TATA spare parts
278614110141	PIPE ASSY	TATA spare parts
278614110142	PIPE ASSY	TATA spare parts
278614110143	PIPE ASSY	TATA spare parts
278614110144	ASSY. PIPE BS4	TATA spare parts
278614110145	PIPE ASSY	TATA spare parts
278614110150	RESERVOIR ASSY	TATA spare parts
278614110162	PIPE ASSY	TATA spare parts
278614110174	PIPE ASSY	TATA spare parts
278614110175	PIPE ASSY	TATA spare parts
278614110176	PIPE ASSY	TATA spare parts
278614110182	EXHAUST GAS PROCESSOR	TATA spare parts
278614110187	EXHAUST GAS PROCESSOR	TATA spare parts
278614110190	PIPE ASSY	TATA spare parts
278614110191	PIPE ASSY	TATA spare parts
278614110192	PIPE ASSY	TATA spare parts
278614110194	PIPE ASSY	TATA spare parts
278614110197	PIPE ASSY	TATA spare parts
278614110198	EXHAUST GAS PROCESSOR BS4	TATA spare parts
278614110201	ASSY. PIPE BS4	TATA spare parts
278614110203	EXHAUST GAS PROCESSOR	TATA spare parts
278614110207	UREA TANK ASSY	TATA spare parts
278614110208	DOSER PUMP UNIT ASSY	TATA spare parts
278614110209	DOSER PUMP UNIT ASSY	TATA spare parts
278614113201	SCREW BS4	TATA spare parts
278614113202	SCREW BS4	TATA spare parts
278614116501	NOZZLE RETAINER NUT BS4	TATA spare parts
278614117701	O-RING BS4	TATA spare parts
278614117702	O-RING BS4	TATA spare parts
278614117704	GASKET	TATA spare parts
278614117705	GASKET	TATA spare parts
278614119001	ASSY. VALVE AIR SHUTOFF BS4	TATA spare parts

278614119901	CAP ASSY FILLER BS4	TATA spare parts
278614119902	FILTER BODY AND DAMPER SERVICE KIT BS4	TATA spare parts
278614119903	CONNECTOR FITTING BS4	TATA spare parts
278614119904	CONNECTOR FITTING BS4	TATA spare parts
278614119912	TANK AIR VENT BS4	TATA spare parts
278614119914	FILING NECK CONNECTOR BS4	TATA spare parts
278614119916	DEF TANK CAP BS4	TATA spare parts
278614119917	SENSOR VENTED FILTER BS4	TATA spare parts
278614119918	SENSOR SERVICE KITS BS4	TATA spare parts
278614119919	SENSOR O RING BS4	TATA spare parts
278614119920	FILLING NECK FILTER BS4	TATA spare parts
278614119921	DRAIN PLUG BS4	TATA spare parts
278614119923	ASSY. CAP BS4	TATA spare parts
278614119924	ASSY CONNECTOR FITTING	TATA spare parts
278614119925	ASSY CONNECTOR FITTING	TATA spare parts
278614580101	HEAT SHIELD	TATA spare parts
278614580102	ASSY. HEAT SHIELD.	TATA spare parts
278614580104	ASSY HEAT SHIELD	TATA spare parts
278614580105	ASSY HEAT SHIELD	TATA spare parts
278614580106	ASSY TWISTED BRCKET	TATA spare parts
278614600102	ASSY BKT (FOR IC PIPE SUPPORT)	TATA spare parts
278614600107	INTERCOOLER ASSY	TATA spare parts
278614603301	BRACKET	TATA spare parts
278614603302	BRACKET	TATA spare parts
278614603303	BRACKET(FOR TC TO IC PIPE CLAMPING)	TATA spare parts
278614603310	BRACKET (TC TO IC PIPE SUPPORT)	TATA spare parts
278614603311	BRACKET	TATA spare parts
278614603314	SUPPORT PIPE TC TO IC 2523.T PRIMA LX	TATA spare parts
278614603317	SUPPORT BRACKET TC TO IC PIPE	TATA spare parts
278614603318	SUPPORT BRACKET TC TO INTERMEDIATE PIPE	TATA spare parts
278614603320	BRACKET TURBOCHARGER TO INTERCOOLER PIPE	TATA spare parts
278614603321	BRACKET PIPE TC TO INTERCOOLER SUPPORT	TATA spare parts
278614603323	BRACKET	TATA spare parts
278614603328	BRACKET PIPE TC TO INTERCOOLER SUPPORT	TATA spare parts
278614603803	BEND PIPE IC TO CYL HEAD	TATA spare parts
278614603804	BEND PIPE TC TO IC	TATA spare parts
278614603806	PIPE IN.COOLER - IN MANIF	TATA spare parts
278614603815	CAST ELBOW-ON TC COMPRESSOR OUTLET	TATA spare parts
278614603821	CAST PIPE-ON ENG INLET	TATA spare parts
278614603822	CAST PIPE ON IC OUTLET	TATA spare parts
278614603823	CAST PIPE ON IC INLET FOR LP1512C	TATA spare parts
278614603824	CAST PIPE-ON TC OUTLET	TATA spare parts
278614603826	BENT PIPE INTER COOLER TO ENGINE	TATA spare parts
278614603828	CAST PIPE TC TO IC	TATA spare parts
278614603836	PIPE (TC TO IC)	TATA spare parts
278614603837	PIPE (IC TO CYL. HEAD COVER)	TATA spare parts
278614603840	CAST PIPE LPS 3516 BS-2	TATA spare parts

278614603841	CAST PIPE(TC TO IC) BS1/2/3	TATA spare parts
278614603844	CAST PIPE(IC TO INTAKE MANIFOLD)	TATA spare parts
278614603845	CAST PIPE (TURBOCHARGER TO INTERCOOLER)	TATA spare parts
278614603846	CASTPIPE(IC TO INTAKE MANIFOLD)	TATA spare parts
278614603847	CAST PIPE(TC TO IC)	TATA spare parts
278614603848	INTERCOOLER PIPE-RH	TATA spare parts
278614603849	INTERCOOLER PIPE-LH	TATA spare parts
278614603850	CAC PIPE	TATA spare parts
278614603865	PIPE INTERCOOLER LH	TATA spare parts
278614603866	PIPE INTERCOOLER	TATA spare parts
278614603867	PIPE INTERCOOLER OUTLET	TATA spare parts
278614604202	CLAMP (FOR IC PIPE)	TATA spare parts
278614604203	BRACKET CAC PIPE	TATA spare parts
278614605802	HOSE HUMP BS1/2/3/4	TATA spare parts
278614605802AE	HOSE HUMP 2523 715	TATA spare parts
278614605803	TURBO HOSE	TATA spare parts
278614605804	HOSE HUMP-EPDM(IC TO ENG)	TATA spare parts
278614605805	HOSE HUMP (M/S POLYBOND) BS6	TATA spare parts
278614605807	HOSE HUMP	TATA spare parts
278614605808	HOSE HUMP - INLET	TATA spare parts
278614605810	INTERCOOLER HOSE INLET	TATA spare parts
278614605811	INTERCOOLER HOSE OUTLET	TATA spare parts
278614605812	HOSE-CAC INLET	TATA spare parts
278614605813	HOSE-CAC OUTLET	TATA spare parts
278614605817	HOSE INTERCOOLER INLET	TATA spare parts
278614605818	HOSE INTERCOOLER OUTLET	TATA spare parts
278614605819	HOSE CAC OUT	TATA spare parts
278614605820	HOSE CAC OUT	TATA spare parts
278614605822	HOSE	TATA spare parts
278614605823	HOSE HUMP	TATA spare parts
278614605826	HOSE INTERCOOLER INTAKE	TATA spare parts
278614605827	HOSE INTERCOOLER INTAKE	TATA spare parts
278614605836	HOSE ASSY	TATA spare parts
278614606803	PIPE ASSY INTERCOOLER OUTLET	TATA spare parts
278614606804	PIPE ASSY IC INTAKE	TATA spare parts
278614606811	PIPE	TATA spare parts
278614606812	PIPE	TATA spare parts
278614606813	PIPE ASSY WITH BRACKET	TATA spare parts
278614606814	PIPE CAC TO INTAKE	TATA spare parts
278614606815	PIPE	TATA spare parts
278614606905	PIPE-TC TO IC	TATA spare parts
278614606906	EXTRUDED PIPE TC TO IC	TATA spare parts
278614606907	EXTRUDED PIPEIC TO ENG	TATA spare parts
278614606908	PIPE IC INTAKE	TATA spare parts
278614606910	AIR INTAKE PIPE	TATA spare parts
278614606911	PIPE(IC TO INTAKE MANIFOLD)	TATA spare parts
278614606912	PIPE(IC TO ENGINE)	TATA spare parts

278614606915	PIPE(IC TO INTAKE MANIFOLD)	TATA spare parts
278614606916	PIPE(IC TO ENG)	TATA spare parts
278614606917	PIPE(TC TO IC)	TATA spare parts
278614606918	PIPE(IC TO ENG)	TATA spare parts
278614606922	PIPE TURBOCHARGER TO IC	TATA spare parts
278614606923	PIPE TURBOCHARGER TO IC	TATA spare parts
278614606930	PIPE(IC TO ENG)	TATA spare parts
278614606931	PIPE(TC TO IC)	TATA spare parts
278614606934	AIR INTAKE PIPE TC TO INTERCOOLER	TATA spare parts
278614606940	PIPE (TC TO IC)(M0)	TATA spare parts
278614606942	PIPE (TC TO IC)	TATA spare parts
278614606944	PIPE	TATA spare parts
278614606945	PIPE	TATA spare parts
278614606950	PIPE (IC TO ENG)	TATA spare parts
278614606954	PIPE(IC TO INTAKE MANIFOLD)	TATA spare parts
278614606958	PIPE (ENGINE TO I.COOLER)	TATA spare parts
278614606959	PIPE (TC TO IC)	TATA spare parts
278614606961	PIPE (IC TO INTAKE MANIFOLD)	TATA spare parts
278614606962	PIPE (IC TO ENGINE)	TATA spare parts
278614606974	PIPE IC OUT TO AIR INTAKE ELBOW	TATA spare parts
278614606986	PIPE CAC IN	TATA spare parts
278614606987	PIPE CAC OUT	TATA spare parts
278614606988	PIPE TC TO IC CAC IN	TATA spare parts
278614606989	PIPE ASSY IC TO ELBOW AIR INTAKE CAC OUT	TATA spare parts
278614606990	PIPE ( TC TO IC )	TATA spare parts
278614606991	PIPE INTERCOOLER TO ENGINE	TATA spare parts
278614606992	PIPE INTERCOOLER TO ENGINE	TATA spare parts
278614606995	PIPE IC OUTLET	TATA spare parts
278614607501	RUBBER BUFFER	TATA spare parts
278614609201	WASHER IC MTG	TATA spare parts
278614609901	INTER COOLER	TATA spare parts
278614609902	INTER COOLER	TATA spare parts
278614609903	INTER COOLER	TATA spare parts
278614609906	INTERCOOLER LPT2516 EUROII	TATA spare parts
278614609907	INTERCOOLER 2516/3516.	TATA spare parts
278614609908	INTERCOOLER	TATA spare parts
278614609910	INTERCOOLER (LP1512C /LPT1613C -EURO-II)	TATA spare parts
278614609911	INTERCOOLER-LP1512TC/LPT1613TC-EUROII	TATA spare parts
278614609912	INTERCOOLER LP1512TC BS2 & BS3)	TATA spare parts
278614609913	INTERCOOLER LPT2516 EUROII	TATA spare parts
278614609915	INTERCOOLER-2518TC BS2-COWL	TATA spare parts
278614609916	INTERCOOLER-2516TC HIGH MOUNT	TATA spare parts
278614609917	INTERCOOLER	TATA spare parts
278614609919	INTERCOOLER LPT2516 EUROII	TATA spare parts
278614609922	INTERCOOLER	TATA spare parts
278614609930	INTERCOOLER(LPS4923)	TATA spare parts
278614609931	INTERCOOLER LPT 1613 EURO II SLPR TILT	TATA spare parts

278614609933	INTERCOOLER-(LPT1418)	TATA spare parts
278614609934	INTERCOOLER-LPS4018	TATA spare parts
278614609935	INTERCOOLER LPT 1613 EURO II SLPR TILT	TATA spare parts
278614609936	INTERCOOLER-2518TC BS2-COWL	TATA spare parts
278614609937	INTERCOOLER-OFFER 3015/2515 EII COWL	TATA spare parts
278614609938	INTERCOOLER TATA 3015/2515 COWL	TATA spare parts
278614609939	INTERCOOLER-2518TC BS2-COWL	TATA spare parts
278614609940	INTERCOOLER 2515/3015 BS2 COWL	TATA spare parts
278614609942	INTERCOOLER-2518TC BS2-COWL	TATA spare parts
278614609944	INTERCOOLER (LPT 2515/3015 COWL)	TATA spare parts
278614609949	INTERCOOLER ASSEMBLY.	TATA spare parts
278614609951	INTERCOOLER ASSY	TATA spare parts
278614609960	INTERCOOLER (LPS 3516)	TATA spare parts
278614609961	INTERCOOLER BS2/3/4	TATA spare parts
278614609962	INTERCOOLER ASSY.	TATA spare parts
278614609964	INTERCOOLER-LPT2518TC-BS3-COWL	TATA spare parts
278614609965	INTERCOOLER-LPT2518TC-BS3-COWL	TATA spare parts
278614609966	INTERCOOLER ASSEMBLY	TATA spare parts
278614609970	INTERCOOLER ASSY	TATA spare parts
278614609972	INTERCOOLER ASSY	TATA spare parts
278614609973	INTER COOLER (LPS 4018 TC) BS3/4	TATA spare parts
278614609974	INTER COOLER (LPS 4018 TC) BS3	TATA spare parts
278614609975	INTERCOOLER (LPS 4018 BS3)	TATA spare parts
278614609977	INTER COOLER 2518TC BS3 COWL	TATA spare parts
278614609980	IC ASSY-LPT1613 TC BS3 COWL	TATA spare parts
278614609984	ASSY. INTERCOOLER BS1/3/4	TATA spare parts
278614609985	ASSY.INTERCOOLER	TATA spare parts
278614609986	INTERCOOLER LPT 3721	TATA spare parts
278614609992	INTERCOOLER LPT2518TC BS3	TATA spare parts
278614609996	INTERCOOLER ASSY	TATA spare parts
278614609997	INTERCOOLER LPS4018TC BS1/3	TATA spare parts
278614610101	INTERCOOLER ASSY	TATA spare parts
278614610105	INTERCOOLER ASSY	TATA spare parts
278614610109	ASSY. INTERCOOLER BS4	TATA spare parts
278614610110	INTERCOOLER ASSY	TATA spare parts
278614610111	INTERCOOLER	TATA spare parts
278614610116	INTERCOOLER	TATA spare parts
278614616909	PIPE TC TO IC	TATA spare parts
278614616917	PIPE TC TO IC	TATA spare parts
278614616918	PIPE INTERCOOLER TO INTAKE MANIFOLD	TATA spare parts
278614616922	PIPE	TATA spare parts
278614616923	PIPE IC OUT TO AIR INTAKE ELBOW	TATA spare parts
278614616929	PIPE	TATA spare parts
278614616930	PIPE	TATA spare parts
278614616936	PIPE	TATA spare parts
278614616937	PIPE	TATA spare parts
278614616942	PIPE INTERCOOLER TO TURBOCHARGER	TATA spare parts



278614616946	PIPE	TATA spare parts
278614619901	INTERCOOLER ASSY	TATA spare parts
278614990107	TURBOCHARGER	TATA spare parts
278614990111	ASSY. TURBOCHARGER BS3	TATA spare parts
278614990114	ASSY. TURBOCHARGER BS3/4	TATA spare parts
278614990116	TURBOCHARGER	TATA spare parts
278614990118	TURBOCHARGER	TATA spare parts
278614990124	TURBOCHARGER	TATA spare parts
278614990127	TURBOCHARGER	TATA spare parts
278614990129	TURBOCHARGER	TATA spare parts
278614990140	TURBOCHARGER	TATA spare parts
278614990141	TURBOCHARGER	TATA spare parts
278614990142	TURBOCHARGER	TATA spare parts
278614990143	TURBOCHARGER	TATA spare parts
278614990146	TURBOCHARGER	TATA spare parts
278614990154	CONVERTER CATALYTIC	TATA spare parts
278614990155	CONVERTOR CATALYTIC	TATA spare parts
278614990156	CONVERTER CATALYTIC	TATA spare parts
278614990157	TURBOCHARGER	TATA spare parts
278614990158	CATALYTIC CONVERTER	TATA spare parts
278614990160	TURBOCHARGER	TATA spare parts
278614990163	TURBOCHARGER	TATA spare parts
278614990166	TURBOCHARGER ASSY (CORE ASSY)	TATA spare parts
278614990168	TURBOCHARGER	TATA spare parts
278614990170	ASSY. TURBOCHARGER 6BT BS2	TATA spare parts
278614990170AE	TURBOCHARGER 2523	TATA spare parts
278614990173	TURBOCHARGER	TATA spare parts
278614990174	CATALYTIC CONVERTOR	TATA spare parts
278614990175	ASSY. TURBOCHARGER ISBE 5.9 BS2/3/4	TATA spare parts
278614990186	TURBOCHARGER	TATA spare parts
278614990187	ASSY. TURBOCHARGER BS1/3	TATA spare parts
278614990200	TURBOCHARGER	TATA spare parts
278614990201	TURBOCHARGER	TATA spare parts
278614990202	MINOR KIT	TATA spare parts
278614990203	KIT ACTUATOR ASSY	TATA spare parts
278614990204	TURBOCHARGER	TATA spare parts
278614990205	TURBOCHARGER	TATA spare parts
278614990206	ASSY. TURBOCHARGER ISBE5.9 BS3/4 BS4	TATA spare parts
278614990207	TURBOCHARGER	TATA spare parts
278614990208	CONNECTION EXHAUST OUTLET	TATA spare parts
278614990209	TURBOCHARGER	TATA spare parts
278614990210	TURBOCHARGER	TATA spare parts
278614990226	HEADER DIESEL EXHAUST FLUID TANK	TATA spare parts
278614990227	RESERVOIR ASSY	TATA spare parts
278614990228	HEADER DIESEL EXHAUST FLUID TANK	TATA spare parts
278614993301	BRACKET EXH CONNECTION	TATA spare parts
278614993401	BUSHING REDUCING PIPE	TATA spare parts

278614993402	BUSHING	TATA spare parts
278614993403	BUSHING REDUCING PIPE	TATA spare parts
278614993701	MANIFOLD EXHAUST	TATA spare parts
278614993703	MANIFOLD EXHAUST	TATA spare parts
278614993703AE	MANIFOLD EXHAUST 1628	TATA spare parts
278614993704	MANIFOLD EXHAUST BS3	TATA spare parts
278614993705	MANIFOLD EXHAUST	TATA spare parts
278614993707	MANIFOLD,EXHAUST 6BT BS1/2/3/4	TATA spare parts
278614993712	MANIFOLD EXHAUST	TATA spare parts
278614993713	MANIFOLD EXHAUST	TATA spare parts
278614993715	MANIFOLD EXHAUST BS1/3/4	TATA spare parts
278614993716	MANIFOLD EXHAUST	TATA spare parts
278614993717	MANIFOLD EXHAUST	TATA spare parts
278614993718	MANIFOLD EXHAUST	TATA spare parts
278614993719	MANIFOLD EXHAUST	TATA spare parts
278614994201	CLAMP HOSE	TATA spare parts
278614994202	CLAMP V BAND	TATA spare parts
278614994203	CLAMP HOSE	TATA spare parts
278614994204	NUT LOCK	TATA spare parts
278614994205	CLAMP V BAND	TATA spare parts
278614994701	COVER INTAKE MANIFOLD	TATA spare parts
278614994702	COVER INTAKE MANIFOLD	TATA spare parts
278614994703	COVER INTAKE MANIFOLD	TATA spare parts
278614994704	COVER INTAKE	TATA spare parts
278614994707	COVER INTAKE MANIFOLD	TATA spare parts
278614994708	COVER INTAKE MANIFOLD	TATA spare parts
278614994709	COVER INTAKE MANIFOLD	TATA spare parts
278614994710	COVER INTAKE MANIFOLD	TATA spare parts
278614995301	GASKET EXHAUST MANIFOLD BS1/3/4	TATA spare parts
278614995301AE	GASKET EXH MNFLD LPA1415/LPTA715	TATA spare parts
278614995302	GASKET TURBOCHARGER	TATA spare parts
278614995302AE	GASKET TURBOCHARGER	TATA spare parts
278614995303	GASKET INTAKE MANIFOLD BS4	TATA spare parts
278614995304	GASKET EXH MANIFOLD	TATA spare parts
278614995305	GASKET TURBOCHARGER	TATA spare parts
278614995306	GASKET INT MANIFOLD COVER	TATA spare parts
278614995307	GASKET EXHAUST MANIFOLD	TATA spare parts
278614995308	GASKET EXHAUST MANIFOLD	TATA spare parts
278614995309	GASKET CONNECTION	TATA spare parts
278614995313	GASKET CONNECTION	TATA spare parts
278614995314	GASKET TURBOCHARGER	TATA spare parts
278614995801	HOSE PLAIN COMPRESSOR COOLANT	TATA spare parts
278614995804	HOSE PLAIN	TATA spare parts
278614995805	TUBE AIR FUEL CONTROL	TATA spare parts
278614995807	HOSE PLAIN TURBO COOLANT	TATA spare parts
278614995808	HOSE PLAIN 1100 MM	TATA spare parts
278614995809	HOSE FLEXIBLE	TATA spare parts

278614995810	HOSE PLAIN TURBO COOLANT	TATA spare parts
278614995811	HOSE FLEXIBLE	TATA spare parts
278614996901	TUBE WATER OUTLET	TATA spare parts
278614996902	TUBE AIR FUEL CONTROL	TATA spare parts
278614996903	TUBE TUR OIL DRAIN	TATA spare parts
278614996904	TUBE TUR OIL SUPPLY	TATA spare parts
278614996905	TUBE TUR OIL	TATA spare parts
278614997101	PLATE	TATA spare parts
278614997201	PLUG THREADED	TATA spare parts
278614998001	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278614998002	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278614999201	WASHER SEALING	TATA spare parts
278614999801	FILTER BODY ELEMENT -DOSER BS4	TATA spare parts
278614999802	DIAPHRAGM DOSER	TATA spare parts
278614999805	DOSER UNIT AIR SIDE SCREEN FILTER	TATA spare parts
278614999807	PIPE AIR TRANSFER	TATA spare parts
278614999808	ASSY. CAP	TATA spare parts
278614999809	ASSY. TURBOCHARGER ISBE 5.9 BS4	TATA spare parts
278614999810	TURBOCHARGER	TATA spare parts
278614999811	TURBOCHARGER	TATA spare parts
278614999812	SUPPORT EXH GAS RCN MDL	TATA spare parts
278614999813	GASKET EXH GAS RCN VALVE	TATA spare parts
278614999814	SENSOR DFN PRESSURE	TATA spare parts
278614999815	SENSOR PRESSURE	TATA spare parts
278614999817	VALVE EXH GAS RCN	TATA spare parts
278614999818	SENSOR TEMPERATURE	TATA spare parts
278614999819	TUBE AIR TRANSFER	TATA spare parts
278614999820	BRACE TUBE	TATA spare parts
278614999821	TUBE VENT	TATA spare parts
278614999822	ADAPTER REDUCING PIPE	TATA spare parts
278614999823	CONNECTION AIR INTAKE	TATA spare parts
278614999824	CONNECTION AIR INTAKE	TATA spare parts
278614999825	COOLER EXH GAS	TATA spare parts
278614999826	TURBOCHARGER	TATA spare parts
278614999827	TUBE VENT	TATA spare parts
278614999828	TUBE VENT	TATA spare parts
278614999829	TURBOCHARGER	TATA spare parts
278614999835	TURBOCHARGER	TATA spare parts
278614999836	TURBOCHARGER	TATA spare parts
278614999837	SOLENOID	TATA spare parts
278614999838	EGR VAVLE	TATA spare parts
278614999901	TURBOCHARGER 1615TC	TATA spare parts
278614999902	GASKET TURBOCHARGER BS4	TATA spare parts
278614999903	GASKET OIL DRAIN	TATA spare parts
278614999904	STUD	TATA spare parts
278614999905	NUT HEX FLANGE	TATA spare parts
278614999907	KIT LOWER GASKET	TATA spare parts

278614999909	CLAMP HOSE	TATA spare parts
278614999910	HOSE ELBOW	TATA spare parts
278614999911	TUBE AIR	TATA spare parts
278614999912	HOSE PLAIN	TATA spare parts
278614999913	BRACE TUBE	TATA spare parts
278614999914	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278614999915	GASKET MANIFOLD-CNG BS1/2/3/4	TATA spare parts
278614999916	CLIP	TATA spare parts
278614999917	MANIFOLD EXHAUST BS1/2/3	TATA spare parts
278614999918	SCREW HEX FLANGE HD CAP	TATA spare parts
278614999919	CLAMP HOSE	TATA spare parts
278614999920	SEAL O RING	TATA spare parts
278614999921	CONNECTION TUR OIL DRAIN	TATA spare parts
278614999922	TUBE TURBO OIL DRAIN	TATA spare parts
278614999923	HOSE FLEXIBLE BS1/2/3/4	TATA spare parts
278614999923AE	HOSE FLEXIBLE 2523	TATA spare parts
278614999926	WASHER SEALING	TATA spare parts
278614999927	CLIP	TATA spare parts
278614999928	CONNECTION EXHAUST OUTLET BS1/2/3	TATA spare parts
278614999929	GASKET EXHAUST MANIFOLD	TATA spare parts
278614999930	MANIFOLD EXHAUST	TATA spare parts
278614999931	CLAMP VBAND BS1/2/3/4	TATA spare parts
278614999931AE	CLAMP V BAND 715	TATA spare parts
278614999932	EXHAUST MANIFOLD	TATA spare parts
278614999933	CONNECTION OIL DRAIN TC BS4	TATA spare parts
278614999934	HOSE PLAIN BS1/2/3	TATA spare parts
278614999935	COUPLING ELBOW HOSE	TATA spare parts
278614999936	TURBO CHARGER BS1/2	TATA spare parts
278614999936AE	TURBOCHARGER(3594310)LPA 1415/	TATA spare parts
278614999937	TURBOCHARGER BS2	TATA spare parts
278614999938	ASSY. TURBOCHARGER BS1/3	TATA spare parts
278614999939	TURBOCHARGER	TATA spare parts
278614999940	TURBOCHARGER LPS4021TC	TATA spare parts
278614999941	TURBO CHARGER FOR 100HP	TATA spare parts
278614999942	CLAMP V BAND BS1/2/3/4	TATA spare parts
278614999942AE	CLAMP V BAND 715	TATA spare parts
278614999943	MANIFOLD FUEL	TATA spare parts
278614999944	BRACKET HEAT SHIELD	TATA spare parts
278614999945	TURBOCHARGER LP1312TC	TATA spare parts
278614999946	KIT-TURBOCHARGER (MINOR REP) BS1/2/3/4	TATA spare parts
278614999947	TURBO CHARGER FOR EURO II ENGINE TIPPER	TATA spare parts
278614999948	TURBO CHARGER FOR 6BT SE/SK	TATA spare parts
278614999949	TURBO CHARGER FOR 100HP REAR ENG BUS APP	TATA spare parts
278614999950	DETECTOR COMDUSTIBLE GAS	TATA spare parts
278614999951	SENSOR OXYGEN.	TATA spare parts
278614999952	TURBO CHARGER CORE ASSY-CHRA	TATA spare parts
278614999953	TURBOCHARGER ACTUATOR KIT	TATA spare parts

278614999954	EXHAUST MANIFOLD	TATA spare parts
278614999955	COVER INTAKE MANIFOLD	TATA spare parts
278614999956	GASKET EXHAUST PIPE CNG	TATA spare parts
278614999958	ASSY. TURBOCHARGER BS2/3	TATA spare parts
278614999959	TURBOCHARGER BS2	TATA spare parts
278614999960	TURBOCHARGER 180 HP BS2	TATA spare parts
278614999961	MANIFOLD EXHAUST	TATA spare parts
278614999962	MANOFOLD EXHAUST	TATA spare parts
278614999963	SCREW HEX FLANGE HEAD CAP BS1/3/4/6	TATA spare parts
278614999964	SCREW HEAD FLANGE HEAD CAP	TATA spare parts
278614999965	SPACER MOUNTING	TATA spare parts
278614999966	GASKET EXHAUST MANIFOLD	TATA spare parts
278614999967	ASSY. TURBOCHARGER BS3	TATA spare parts
278614999971	SENSOR POSITION BS3/4	TATA spare parts
278614999972	SENSOR OXYGEN	TATA spare parts
278614999974	SENSOR PRESSURE	TATA spare parts
278614999975	SENSOR PRS TEMPERATURE	TATA spare parts
278614999977	PLUG PIPE	TATA spare parts
278614999978	CONNECTOR FEMALE	TATA spare parts
278614999979	COUPLING ELBOW HOSE (3/4-16 (INT) X 1/2	TATA spare parts
278614999980	COUPLING PLAIN HOSE	TATA spare parts
278614999984	CONNECTION EX	TATA spare parts
278614999985	GASKET CONNECTION BS4	TATA spare parts
278614999986	SUPPORT CONNECTION	TATA spare parts
278614999987	SHIELD HEAT	TATA spare parts
278614999988	UNION MALE	TATA spare parts
278614999990	SHIELD HEAT	TATA spare parts
278614999991	CONNECTION EXHAUST OUTLET	TATA spare parts
278614999993	CONNECTION¿ EXHAUST OUTLET	TATA spare parts
278614999995	CONNECTION TUR OIL DRAIN	TATA spare parts
278614999996	CONNECTION TURBO OIL DRAIN	TATA spare parts
278614999997	CONNECTOR	TATA spare parts
278614999999	ASSY. TURBOCHARGER BS4	TATA spare parts
278615989902	KIT SPARK PLUG	TATA spare parts
278615989903	BRACE ALTERNATOR	TATA spare parts
278615989904	HARNESS ETR CNT MDL WR	TATA spare parts
278615990102	ALTERNATOR 24V 90AMP BS1/2/3/4	TATA spare parts
278615990105	MODULE IGNITION CONTROL	TATA spare parts
278615990107	STARETR MOTOR	TATA spare parts
278615990113	ALTERNATOR 24 VOLTS 45AMP BS1/2/3/4	TATA spare parts
278615990113AE	ALTERNATOR 2523	TATA spare parts
278615990118	STARTER MOTOR BS1/2/3/4	TATA spare parts
278615990128	KIT DATA LINK ADOPTER	TATA spare parts
278615990129	KIT DATA LINK ADOPTER	TATA spare parts
278615990135	MODULE ELECTRONIC CONTROL	TATA spare parts
278615990138	WIRING HARNESS BS3	TATA spare parts
278615990140	STARTER MOTOR	TATA spare parts

278615990141	WIRING REPAIR KIT	TATA spare parts
278615990142	GAS MASS FLOW SENSOR	TATA spare parts
278615990143	HARNESS WIRING	TATA spare parts
278615990144	COIL IGNITION	TATA spare parts
278615990145	MODULE IGNITION CONTROL	TATA spare parts
278615990146	KIT DATALINK ADAPTER	TATA spare parts
278615990147	ALTERNATOR	TATA spare parts
278615990148	HARNESS WIRING	TATA spare parts
278615990149	HARNESS WIRING	TATA spare parts
278615990150	MODULE ELECTRONICS CONTROL	TATA spare parts
278615990151	MODULE ETR	TATA spare parts
278615990152	HARNESS WIRING	TATA spare parts
278615990153	HARNESS ETR CNT MDL WRG	TATA spare parts
278615990154	HARNESS WIRING	TATA spare parts
278615990157	ALTERNATOR	TATA spare parts
278615990159	HARENESS WIRING	TATA spare parts
278615990160	ALTERNATOR BS1/3	TATA spare parts
278615990161	MODULE ELECTRONIC CONTROL	TATA spare parts
278615990162	IGNITION COIL	TATA spare parts
278615990163	HARNESS ETR CNT MDL WRG	TATA spare parts
278615990175	ALTERNATOR BS3/4/6	TATA spare parts
278615990185	MODULE IGNITION CONTROL	TATA spare parts
278615990188	MODULE ELECTRONIC CONTROL	TATA spare parts
278615990192	STARTER MOTOR BS1/3/4	TATA spare parts
278615990195	MODULE IGNITION CONTROL BS3/4	TATA spare parts
278615990198	ELECTRONIC CONTROL MODULE BS4	TATA spare parts
278615990206	ELECTRONIC CONTROL MODULE BS4	TATA spare parts
278615990210	HARNESS ETR CNT MDL WRG	TATA spare parts
278615990211	ARMATURE ASSY.	TATA spare parts
278615990212	INTER BRACKET ASSY.	TATA spare parts
278615990213	DRIVE ASSY	TATA spare parts
278615990214	FIXING BRACKET ASSY.	TATA spare parts
278615990215	FIELD CILS ASSY.	TATA spare parts
278615990216	BRUSH GEAR ASSY.	TATA spare parts
278615990217	CE BRACKET ASSY.	TATA spare parts
278615990218	ARMATURE ASSY. KIT	TATA spare parts
278615990219	BRUSH ASSY. KIT	TATA spare parts
278615990220	BEARING BUSH ASSY. KIT	TATA spare parts
278615990221	FASTENERS ASSY KIT	TATA spare parts
278615990222	SEALING ASSY. KIT	TATA spare parts
278615990223	DE BRACKET ASSY.	TATA spare parts
278615990224	ROTOR FINAL ASSY.	TATA spare parts
278615990225	STATOR WINDING FINAL ASSY.	TATA spare parts
278615990226	STATOR WINDING FINAL ASSY.	TATA spare parts
278615990227	RECTIFIER ASSY	TATA spare parts
278615990228	SRE BRACKET ASSY.	TATA spare parts
278615990229	PULLY ASSY. KIT	TATA spare parts

278615990230	DE BEARING ASSY. KIT	TATA spare parts
278615990231	RECTIFIER ASSY KIT	TATA spare parts
278615990232	HARNESS WIRING BS4	TATA spare parts
278615990234	HARNESS ETR CNT MDL WRG BS4	TATA spare parts
278615990236	MODULE ETR INTERFACE	TATA spare parts
278615990237	HARNESS ETR CNT MDL WRG	TATA spare parts
278615990245	HARNESS ETR CNT MDL WRG	TATA spare parts
278615990246	HARNESS ETR CNT MDL WRG	TATA spare parts
278615990247	HARNESS ETR CNT MDL WRG	TATA spare parts
278615990257	ALTERNATOR	TATA spare parts
278615990258	KIT-DATA LINK ADOPTER	TATA spare parts
278615990259	DRIVE ASSY BS6-PH2	TATA spare parts
278615990260	ENGAGING LEVER ASSY BS6-PH2	TATA spare parts
278615990261	INTER BRACKET ASSY BS6-PH2	TATA spare parts
278615990262	ARMATURE & BEARING ASSY BS6-PH2	TATA spare parts
278615990264	BRUSH GEAR ASSY BS6-PH2	TATA spare parts
278615990265	GE BRACKET ASSY BS6-PH2	TATA spare parts
278615990266	BRUSH ASSY KIT BS6-PH2	TATA spare parts
278615990267	FASTENER AND WH ASSY KIT BS6-PH2	TATA spare parts
278615993101	BEARING ASSEMBLY KIT	TATA spare parts
278615993102	BALL BEARING BS6-PH2	TATA spare parts
278615993302	BRACE ALTERNATOR	TATA spare parts
278615993303	BRACKET BELT	TATA spare parts
278615993304	BRACKET MODULE	TATA spare parts
278615993305	BRACKET ETR CNT MODULE	TATA spare parts
278615993306	SUPPORT ETR CNT MODULE	TATA spare parts
278615993307	BRACKET CABLE	TATA spare parts
278615993308	BRACKET CABLE	TATA spare parts
278615993309	BRACKET CABLE	TATA spare parts
278615993310	BRACKET IGNITION COIL	TATA spare parts
278615993311	BRACKET SENSOR	TATA spare parts
278615993312	BRACKET SENSOR	TATA spare parts
278615993314	BRACKET ETR CNT MODULE	TATA spare parts
278615993315	BRACKET WIRING RETAINER	TATA spare parts
278615993318	D.E. BRACKET ASSEMBLY	TATA spare parts
278615993319	S.R.E. BRACKET ASSEMBLY	TATA spare parts
278615993321	BRACE ALTERNATOR	TATA spare parts
278615993322	FIXING BRACKET ASSY BS6-PH2	TATA spare parts
278615994201	CLAMP HOSE	TATA spare parts
278615994701	REAR COVER	TATA spare parts
278615994702	GEAR COVER PLATE BS6-PH2	TATA spare parts
278615995301	GASKET COONCTION BS4	TATA spare parts
278615995302	GASKET STARTER	TATA spare parts
278615995303	GASKET INTEGRATED WIRING BS4	TATA spare parts
278615995304	GASKET INTEGRATED WIRING BS3/4	TATA spare parts
278615996302	BELT V RIBBED BS4	TATA spare parts
278615996302AE	BELT V RIBBEDLPT 2523/	TATA spare parts

278615996901	TUBE PRESSURE SENSING	TATA spare parts
278615996902	BRACE TUBE BS4	TATA spare parts
278615997001	PULLEY ALTERNATOR	TATA spare parts
278615997003	PULLEY ALTERNATOR	TATA spare parts
278615997004	PULLEY	TATA spare parts
278615997005	PULLY(8GROOVE)	TATA spare parts
278615997701	SEAL O RING	TATA spare parts
278615998001	SCREW HEX. FLANGE HEAD CAP M10X1.5X100	TATA spare parts
278615998002	SCREW HEX FLANGE	TATA spare parts
278615998003	SCREW FLAT HEAD	TATA spare parts
278615998004	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278615998005	HEX FLANGE HEAD CAP SCREW	TATA spare parts
278615998006	SCREW SOCKET HEAD CAP	TATA spare parts
278615998601	SPACER MOUNTING	TATA spare parts
278615999801	REMOVER WIRE INSULATION	TATA spare parts
278615999802	INJECTOR PULLER	TATA spare parts
278615999803	INSITE LITE/PRO	TATA spare parts
278615999804	ACTUATOR	TATA spare parts
278615999805	CABLE ELECTRICAL	TATA spare parts
278615999806	ACTUATOR	TATA spare parts
278615999807	CABLE	TATA spare parts
278615999808	CONNECTOR FEMALE	TATA spare parts
278615999809	IGNITION DIAGNOSTIC TESTER KIT	TATA spare parts
278615999810	BOOT SPARK PLUG	TATA spare parts
278615999811	SUPPORT ALTERNATOR	TATA spare parts
278615999812	SENSOR POSITION LEAN BURN ENGINE	TATA spare parts
278615999813	IGNITION COIL TESTING KIT	TATA spare parts
278615999814	SENSOR POSITION	TATA spare parts
278615999815	SPARK PLUG	TATA spare parts
278615999816	SWITCH THERMO	TATA spare parts
278615999817	WIRING HARNESS BS3	TATA spare parts
278615999818	BRACE ALTERNATOR	TATA spare parts
278615999819	HARNESS WIRING BS4	TATA spare parts
278615999820	SUPPORT ETR CNT MODULE BS4	TATA spare parts
278615999821	ADAPTER SENSOR	TATA spare parts
278615999824	SENSOR COOLANT TEMPERATURE-LEAN BURN EN	TATA spare parts
278615999831	SOLENOID SWITCH ASSEMBLY	TATA spare parts
278615999832	WIRE STRIPPING TOOL	TATA spare parts
278615999833	POSITION SENSOR	TATA spare parts
278615999835	PRESSURE SENSOR BS3/4	TATA spare parts
278615999837	PRESSURE SENSOR	TATA spare parts
278615999839	SPARK PLUG	TATA spare parts
278615999843	WIRING HARNESS	TATA spare parts
278615999845	CAMSHAFT POSITION SENSOR BS4	TATA spare parts
278615999846	WIRING HARNESS BS4	TATA spare parts
278615999847	STATOR ASSEMBLY	TATA spare parts
278615999848	RECTIFIER ARRANG.	TATA spare parts



278615999849	FASTENERS ASSEMBLING KIT	TATA spare parts
278615999850	BRACE ALTERNATOR	TATA spare parts
278615999852	SENSOR POSITION	TATA spare parts
278615999853	BRACE WIRING	TATA spare parts
278615999855	THROUGH BOLT	TATA spare parts
278615999856	WIRING HARNESS	TATA spare parts
278615999857	ALTERNATOR	TATA spare parts
278615999858	BRACE ALTERNATOR	TATA spare parts
278615999859	ALTERNATOR BS3/4	TATA spare parts
278615999860	HARNESS WIRING	TATA spare parts
278615999861	HARNESS ETR CNT MDL WRG	TATA spare parts
278615999862	MODULE ELECTRONIC CONTROL	TATA spare parts
278615999863	SENSOR KNOCK	TATA spare parts
278615999864	TUBE PRESSURE SENSING	TATA spare parts
278615999865	MODULE ELECTRONIC CONTROL	TATA spare parts
278615999866	BRACE WIRING	TATA spare parts
278615999867	SOLENOID ENGINE BRAKE	TATA spare parts
278615999869	SENSOR POSITION	TATA spare parts
278615999874	OUTPUT SHAFT ASSY BS6-PH2	TATA spare parts
278615999875	PLANETARY GEAR ASSY BS6-PH2	TATA spare parts
278615999902	TENSIONER BELT BS1/2/3/4	TATA spare parts
278615999902AE	TENSIONER BELT LPA 713/LPT 2523	TATA spare parts
278615999903	SUPPORT ALTERNATOR	TATA spare parts
278615999904	MOTOR STARTING 24 VOLTS	TATA spare parts
278615999905	MOTOR STARTING 12V BS1/3	TATA spare parts
278615999906	ALTERNATOR 24V BS2/3	TATA spare parts
278615999907	CONNECTION FEMALE	TATA spare parts
278615999908	HARNESS WIRING	TATA spare parts
278615999908AE	HARNESS WIRING LPA 1415/	TATA spare parts
278615999909	SUPPORT ALTERNATOR	TATA spare parts
278615999910	AUTOMOTIVE METER	TATA spare parts
278615999914	CLAMP DISTRIBUTOR	TATA spare parts
278615999915	ESDN KIT	TATA spare parts
278615999916	COIL INJECTION	TATA spare parts
278615999917	HARNESS WIRING	TATA spare parts
278615999918	HARNESS WIRING	TATA spare parts
278615999919	MODULE ELECTRONIC CONTROL	TATA spare parts
278615999920	MODULE IGNITION CONTROL	TATA spare parts
278615999921	WIRE SPARK PLUG	TATA spare parts
278615999922	COIL IGNITION BS3/4	TATA spare parts
278615999923	BUSHING	TATA spare parts
278615999924	DISTRIBUTOR CONTACT LESS	TATA spare parts
278615999925	HARNESS WIRING ENGINE & TIMER	TATA spare parts
278615999926	SET HT CABLE	TATA spare parts
278615999927	HOSE GATES ID 7.9MM X 146 INCH LONG	TATA spare parts
278615999928	HARNESS WIRING TIMER	TATA spare parts
278615999929	ALTERNATOR 12 VOLTS	TATA spare parts

278615999930	MOTOR STARTING 12VOLTS	TATA spare parts
278615999931	MOTOR STARTING 12V	TATA spare parts
278615999932	ALTERNATOR 12VOLT FOR AC VEH	TATA spare parts
278615999933	ALTERNATOR 12V 55 A BS1/2/3	TATA spare parts
278615999934	SUPPORT ALTERNATOR BS2	TATA spare parts
278615999935	SPACER FOR AC VEH	TATA spare parts
278615999936	SPACER FOR AC VEH	TATA spare parts
278615999937	SCREW HEX FL.HD CAP FOR AC VEH	TATA spare parts
278615999938	BRACE ALTERNATOR FOR AC VEH	TATA spare parts
278615999939	PULLEY ACCESSORY DRIVE AC VEH	TATA spare parts
278615999940	BELT - LPK 2516 AC MODEL	TATA spare parts
278615999941	BRACE ALTERNATOR	TATA spare parts
278615999942	ADAPTOR	TATA spare parts
278615999943	CONNECTOR	TATA spare parts
278615999944	ELBOW MALE VALVE SHUT-OFF /LPR	TATA spare parts
278615999945	CONNECTOR MALE	TATA spare parts
278615999946	ELBOW MALE HPR	TATA spare parts
278615999947	CONNECTOR MALE CARBURETTOR/LPR	TATA spare parts
278615999948	CAP SCREW	TATA spare parts
278615999949	NUT	TATA spare parts
278615999950	CAP SCREW	TATA spare parts
278615999951	CAP SCREW	TATA spare parts
278615999952	NUT HEXAGON	TATA spare parts
278615999953	ELBOW MALE-ASSY	TATA spare parts
278615999954	ELBOW MALE-ASSY	TATA spare parts
278615999955	HOSE	TATA spare parts
278615999956	HOSE	TATA spare parts
278615999957	HOSE	TATA spare parts
278615999958	HOSE	TATA spare parts
278615999959	HOSE	TATA spare parts
278615999960	HOSE	TATA spare parts
278615999961	NIPPLE PIPE	TATA spare parts
278615999962	NIPPLE	TATA spare parts
278615999963	ELBOW PIPE	TATA spare parts
278615999964	ELBOW PLAIN	TATA spare parts
278615999965	WIRING HARNESS ENGINE	TATA spare parts
278615999966	STARTER 24 VOLTS BS1/2/3/4	TATA spare parts
278615999966AE	STARTER MOTOR 24 VOLTS 2523 715	TATA spare parts
278615999967	SUPPORT-ALTERNATOR	TATA spare parts
278615999968	O RING DISTRIBUTOR CNG	TATA spare parts
278615999969	GASKET FILTER	TATA spare parts
278615999970	STARTER MOTOR 24 VOLTS	TATA spare parts
278615999971	ALTERNATOR 12 VOLTS	TATA spare parts
278615999972	BRACE ALTERNATOR	TATA spare parts
278615999973	ALTERNATOR 24V 75 AMP BS 2	TATA spare parts
278615999974	SUPPORT ALTERNATOR BS2	TATA spare parts
278615999975	BELT	TATA spare parts

278615999976	COIL IGNITION	TATA spare parts
278615999977	SPARK PLUG	TATA spare parts
278615999978	HEATER INTAKE AIR	TATA spare parts
278615999979	BRACE ALTERNATOR	TATA spare parts
278615999980	SUPPORT ALTERNATOR	TATA spare parts
278615999981	SUPPORT ALTERNATOR	TATA spare parts
278615999982	BRACE ALTERNATOR	TATA spare parts
278615999983	SENSOR POSITION LEAN BURN ENGINE	TATA spare parts
278615999984	GAS INLET SENSOR PRESSURE	TATA spare parts
278615999986	SENSOR PRS TEMPERATURE	TATA spare parts
278615999987	SENSOR HUMID	TATA spare parts
278615999988	SENSOR MASS FLOW	TATA spare parts
278615999989	SENSOR PRESSURE	TATA spare parts
278615999990	UNION MALE	TATA spare parts
278615999994	RING SPEED INDICATOR	TATA spare parts
278615999996	SENSOR PRESSURE	TATA spare parts
278615999997	CABLE	TATA spare parts
278615999998	CABLE	TATA spare parts
278615999999	REPLACER ELC TERMINAL	TATA spare parts
278616996916	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278616996917	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278616996918	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278616996919	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
278618137701	O-RING	TATA spare parts
278618139902	OIL FILTER ELEMENT SPINON BS1/2/3/4	TATA spare parts
278618139902AE	LUBE FILTER	TATA spare parts
278618139902CS	DEMO CUT SECTION MODEL FOR 278618139902	TATA spare parts
278618179901	ADAPTER OIL PR TRANSDUCER	TATA spare parts
278618990117	PUMP LUBRICATING KIT BS4	TATA spare parts
278618990127	SET OIL SEALS	TATA spare parts
278618990129	OIL PUMP BS3/4/6	TATA spare parts
278618993301	BRACKET OIL TUBE	TATA spare parts
278618994201	CLAMP HOSE	TATA spare parts
278618994202	CLAMP HOSE	TATA spare parts
278618994301	CLIP	TATA spare parts
278618995303	GASKET FLANGE	TATA spare parts
278618995802	BREATHERHOSE	TATA spare parts
278618995803	HOSE ELBOW	TATA spare parts
278618995804	HOSE PLAIN	TATA spare parts
278618995805	HOSE ELBOW	TATA spare parts
278618995806	HOSE BREATHER	TATA spare parts
278618996901	TUBE OIL GAUGE	TATA spare parts
278618996906	TUBE OIL GAUGE	TATA spare parts
278618997701	SEAL O RING	TATA spare parts
278618997702	OIL SEAL	TATA spare parts
278618997703	SEAL O RING	TATA spare parts
278618997704	OIL SEAL BS4	TATA spare parts

278618997705	SEAL OIL	TATA spare parts
278618997706	FRONT OIL SEAL BS2/3/4/6	TATA spare parts
278618997707	OIL SEAL	TATA spare parts
278618997801	SEAL O RING	TATA spare parts
278618999201	WASHER SEALING BS4	TATA spare parts
278618999803	DIPSTICK	TATA spare parts
278618999804	CONNECTOR	TATA spare parts
278618999902	SPRING COMPRESSION	TATA spare parts
278618999903	HEAD OIL FILTER W/ADAPTOR BS1/2/3/4	TATA spare parts
278618999905	CORE COOLER BS1/2/3/4	TATA spare parts
278618999906	GASKET LUB FILTER HEAD	TATA spare parts
278618999907	PLUG THREADED	TATA spare parts
278618999908	SEAL O RING	TATA spare parts
278618999908AE	SEAL O RING 713	TATA spare parts
278618999909	PLUNGER PRESSURE REGULATOR	TATA spare parts
278618999910	GASKET LUG COOLER BS1/2/3/4	TATA spare parts
278618999913	SCREW HEX.M8X1.25X30	TATA spare parts
278618999914	KIT OIL SEAL	TATA spare parts
278618999917	SCREW HEX.FLANGE HEAD CAP	TATA spare parts
278618999918	PAN OIL FOR CNG ENGINE	TATA spare parts
278618999919	PLUG THREADED	TATA spare parts
278618999920	WASHER SEALING	TATA spare parts
278618999921	CONNECTION OIL SUCTION	TATA spare parts
278618999922	CONNECTION OIL SUCTION	TATA spare parts
278618999923	PLUG THREADED	TATA spare parts
278618999923AE	PLUG THREADED	TATA spare parts
278618999924	GASKET FLANGE	TATA spare parts
278618999925	Screw H.F.M8x1.25x25	TATA spare parts
278618999926	PLATE CYL BLOCK STIFFENER	TATA spare parts
278618999927	PLATE CYL.BLOCK STIFFNER	TATA spare parts
278618999931	GASKET LUB COOLER	TATA spare parts
278618999932	TUBE OIL FILLER	TATA spare parts
278618999933	PUMP LUBRICATING OIL BS1/2/3/4	TATA spare parts
278618999933AE	OIL PUMP	TATA spare parts
278618999934	NOZZLE PISTON COOLING	TATA spare parts
278618999935	PAN OIL BS1/2/3/4	TATA spare parts
278618999936	HOSE PIPE	TATA spare parts
278618999937	BANJO CONNECTOR	TATA spare parts
278618999938	SCREW HEX FLANGE HD CAP	TATA spare parts
278618999939	CONNECTION OIL FILTER	TATA spare parts
278618999940	CAP TUBE	TATA spare parts
278618999941	CONNECTOR MALE	TATA spare parts
278618999942	PLUG THREADED	TATA spare parts
278618999943	CLAMP HOSE	TATA spare parts
278618999944	PLUG EXPANSION	TATA spare parts
278618999945	RING RETAINING	TATA spare parts
278618999946	TURBO SUPPLY LINE	TATA spare parts

278618999947	CONNECTION TUR OIL	TATA spare parts
278618999948	SPACER MOUNTING	TATA spare parts
278618999949	VALVE BYPASS	TATA spare parts
278618999950	TUBE TURBO OIL DRAIN BS4	TATA spare parts
278618999951	TUBE OIL FILTER	TATA spare parts
278618999952	NOZZLE PISTON COOLING	TATA spare parts
278618999953	GEAR FUEL PUMP	TATA spare parts
278618999954	PUMP LUBRICATING OIL	TATA spare parts
278618999955	WASHER PLAIN	TATA spare parts
278618999956	ADAPTOR FILTER HEAD	TATA spare parts
278618999957	CARTRIDGE SINGLE TYPE	TATA spare parts
278618999958	CORE ASSY	TATA spare parts
278618999959	CORE ASSY	TATA spare parts
278618999960	OIL FILTER CARTRIDGE	TATA spare parts
278618999961	ELEMENT STRAINER	TATA spare parts
278618999962	VALVE PRESSURE	TATA spare parts
278618999963	ELEMENT LUB OIL	TATA spare parts
278618999964	TUBE OIL FILTER	TATA spare parts
278618999965	SEAL OIL	TATA spare parts
278618999965AE	SEAL OIL	TATA spare parts
278618999966	CONNECTION TURBO OIL DRAIN	TATA spare parts
278618999967	SEAL O RING BS4	TATA spare parts
278618999969	TUBE OIL GAUGE	TATA spare parts
278618999970	TUBE OIL GAUGE	TATA spare parts
278618999971	GASKET RECTANGULARF/FILTER E-II	TATA spare parts
278618999971AE	GSKT RECTANGULARF/FLTR2523-715	TATA spare parts
278618999972	CAP FILLER	TATA spare parts
278618999974	SEAL O RING	TATA spare parts
278618999976	OIL FILTER ELEMENT (SPINON) ESI BS2/3	TATA spare parts
278618999977	CARTRIDGE LUB OIL FILTER	TATA spare parts
278618999978	OIL FILTER (3937743)	TATA spare parts
278618999978AE	ASSY OIL FILTER 1415 713 2523	TATA spare parts
278618999980	CONNECTION TUR OIL DRAIN	TATA spare parts
278618999982	DIPSTICK	TATA spare parts
278618999983	CONNECTION OIL SUCTION	TATA spare parts
278618999984	PLUG PIPE	TATA spare parts
278618999985	COUPLING PLAIN HOSE	TATA spare parts
278618999986	PLUG THERADED	TATA spare parts
278618999987	PLUG THREADED	TATA spare parts
278618999988	ADAPTER FILTER HEAD	TATA spare parts
278618999989	CONNECTION OIL SUCTION	TATA spare parts
278618999990	CONNECTION TUR OIL DRA	TATA spare parts
278618999991	CONNECTION OIL	TATA spare parts
278618999992	OIL SUCTION CONNECTION	TATA spare parts
278618999993	ADAPTER FILTER HEAD BS4	TATA spare parts
278618999994	OIL FILTER ELEMENT SPINON BS4	TATA spare parts
278618999995	PAN OIL ISBE5.9 AJINKYA BS4	TATA spare parts

27861899996	CONNECTION OIL SUCTION	TATA spare parts
278620140106	ASSY.BRACKET-RH(TOP)FOR FAN RING MTG.	TATA spare parts
278620140107	ASSY.BRACKET-LH(TOP)FOR FAN RING MTG.	TATA spare parts
278620140108	ASSY.BRACKET-RH(BOTTOM)FOR FAN RING MTG.	TATA spare parts
278620140109	ASSY.BRACKET-LH(BOTTOM)FOR FAN RING MTG.	TATA spare parts
278620140110	ASSY FAN RING MTG BKT TOP - LH	TATA spare parts
278620140111	ASSY FAN RING MTG BKT TOP - RH	TATA spare parts
278620140114	ASSY.BRACKET LH-TOP(FAN RING MTG)	TATA spare parts
278620140115	ASSY.BRACKET LH-TOP(FAN RING MTG)	TATA spare parts
278620140116	ASSY.BRACKET RH-TOP(FAN RING MTG)	TATA spare parts
278620140117	ASSY BRACKET LH-BOTTOM(FAN RING MTG)	TATA spare parts
278620140118	ASSY.BRACKET RH-BOTTOM(FAN RING MTG)	TATA spare parts
278620140119	ASSY.BRACKET LH-BOTTOM(FAN RING MTG)	TATA spare parts
278620140120	ASSY.BRACKET RH-BOTTOM(FAN RING MTG)	TATA spare parts
278620140121	ASSY.BRACKET LH-TOP(FAN RING MTG)	TATA spare parts
278620140122	ASSY.BRACKET RH-TOP(FAN RING MTG)	TATA spare parts
278620140132	ASSY.BRACKET LH-TOP(FAN RING MTG)	TATA spare parts
278620140138	ENGINE CLUTCH FAN	TATA spare parts
278620140139	CLUTCH FAN	TATA spare parts
278620140140	FAN ENGINE	TATA spare parts
278620143301	BRACKET-RH (FOR FAN RING BOTTOM MTG)	TATA spare parts
278620143302	BRACKET-LH (FOR FAN RING BOTTOM MTG)	TATA spare parts
278620143303	BRACKET-LH FOR FAN RING BOTTOM MTG	TATA spare parts
278620143304	BRACKET-LH FOR FAN RING BOTTOM MTG	TATA spare parts
278620143801	FAN SHROUD RING LPT2515/LPS4018 BS1/2/3	TATA spare parts
278620143802	FAN SHROUD RING(LPT1613TC)	TATA spare parts
278620143804	FAN SHROUD RING	TATA spare parts
278620143805	FAN RING(LPS4923TC)	TATA spare parts
278620143808	FAN RING	TATA spare parts
278620150101	ASSY MOUNTING BLOCK	TATA spare parts
278620150103	ASSY IDLER UNIT	TATA spare parts
278620150104	ASSY BRG HOUSING	TATA spare parts
278620150106	ASSY SLIDER BLOCK	TATA spare parts
278620150107	MTG BLK W/BRG BLK &IDLR UNIT 1615TC RE	TATA spare parts
278620150108	ASSY IDLER PULLEY	TATA spare parts
278620150112	ASSY.IDLER UNIT XEE BRGS	TATA spare parts
278620150118	ASSY BRACKET	TATA spare parts
278620150119	ASSY. BRACKET (FAN PULLEY MTG.)	TATA spare parts
278620153101	SRDG BRG	TATA spare parts
278620153301	BRACKET	TATA spare parts
278620153303	BRACKET	TATA spare parts
278620155503	HUB	TATA spare parts
278620156302	V BELT COGGED	TATA spare parts
278620156303	V BELT COGGED	TATA spare parts
278620156306	RAW EDGE BELT 1190 LONG	TATA spare parts
278620156307	RAW EDGE BELT 1715 LONG	TATA spare parts
278620156318	COGGED V BELT TWIN GROOVE	TATA spare parts

278620157001	PULLEY 4 GROOVE	TATA spare parts
278620157002	PULLEY	TATA spare parts
278620157004	PULLEY- FAN DRIVE. (ON ENGINE)	TATA spare parts
278620157005	PULLEY (FAN)	TATA spare parts
278620157006	IDLER PULLEY (FAN DRIVE)	TATA spare parts
278620157901	SHAFT	TATA spare parts
278620158701	COMPRESSION SPRING	TATA spare parts
278620164201	CLAMP HOSE	TATA spare parts
278620990101	KIT FIXED FAN	TATA spare parts
278620990103	REPAIR KIT WATER PUMP	TATA spare parts
278620990110	THERMOSTAT	TATA spare parts
278620990111	FAN ENGINE 6BT/ISBE5.9 22INCH 7 BLD BS1/	TATA spare parts
278620990112	FAN ENGINE WITH VISCOUS CLUTCH	TATA spare parts
278620990113	WATER PUMP BS4	TATA spare parts
278620990114	SUPPORT FAN	TATA spare parts
278620990150	CONNECTION WATER OUTLET	TATA spare parts
278620990153	WATER PUMP	TATA spare parts
278620990153AE	WATER PUMP	TATA spare parts
278620990159	KIT WATER PUMP	TATA spare parts
278620990160	THERMOSTAT	TATA spare parts
278620990161	FAN ENGINE	TATA spare parts
278620990162	WATER PUMP? KIT BS4	TATA spare parts
278620990163	FAN ENGINE	TATA spare parts
278620990192	SUPPORT FAN	TATA spare parts
278620990193	FAN ENGINE	TATA spare parts
278620990195	FAN ENGINE ISBE5.9 24INCH 9 BLADE BS4	TATA spare parts
278620990196	PUMP WATER	TATA spare parts
278620990198	FAN ENGINE BS4/6	TATA spare parts
278620990199	KIT-WATER PUMP	TATA spare parts
278620990201	BELT V RIBBED BS4	TATA spare parts
278620990202	CONNECTION WATER INLET	TATA spare parts
278620990203	CONNECTION WATER INLET	TATA spare parts
278620990220	WATER PUMP (HIGH FLOW) 6BT BS1/2/3/4	TATA spare parts
278620990220DF	WATER PUMP HIGH FLOW MOD - 6BT TC BS3	TATA spare parts
278620993301	BRACE TUBE	TATA spare parts
278620993302	BRACE TUBE	TATA spare parts
278620993303	BRACKET BELT TENSIONER	TATA spare parts
278620993304	BRACKET BELT TENSIONER	TATA spare parts
278620993305	BRACE TUBE	TATA spare parts
278620993306	BRACE TUBE	TATA spare parts
278620993307	BRACE TUBE	TATA spare parts
278620993308	BRACKET BELT TENSIONER	TATA spare parts
278620995301	GASKET THM HOUSING COVER	TATA spare parts
278620995302	GASKET THERMOSTATE HOUSING	TATA spare parts
278620996301	BELT V RIBBED	TATA spare parts
278620996302	BELT V RIBBED	TATA spare parts
278620996303	BELT V RIBBED	TATA spare parts

278620996304	V BELT RIBBED BS4	TATA spare parts
278620996305	BELT V RIBBED BS4	TATA spare parts
278620996901	TUBE BS4	TATA spare parts
278620996902	TUBE CPR WATER INLET	TATA spare parts
278620996903	BRACE TUBE	TATA spare parts
278620996904	CONNECTION WATER INLET	TATA spare parts
278620996905	TUBE EXHUAST COOLER WATER OUTLET	TATA spare parts
278620997003	SUPPORT FAN BS4	TATA spare parts
278620997004	PULLEY CRANKSHAFT BS4	TATA spare parts
278620997201	PLUG THREADED	TATA spare parts
278620999801	HUB FAN	TATA spare parts
278620999802	PUMP WATER	TATA spare parts
278620999803	HOUSING THERMOSTAT	TATA spare parts
278620999804	CONNECTION ADAPTER BS4	TATA spare parts
278620999805	FAN ENGINE BS4	TATA spare parts
278620999806	CLUTCH FAN BS4	TATA spare parts
278620999807	FAN ENGINE BS3/4	TATA spare parts
278620999808	CONNECTION WATER INLET	TATA spare parts
278620999809	CLUTCH VISCOUS FAN	TATA spare parts
278620999810	SPACER MOUNTING	TATA spare parts
278620999811	CONNECTION WATER	TATA spare parts
278620999814	THERMOSTAT	TATA spare parts
278620999816	RESISTOR CORROSION	TATA spare parts
278620999817	FAN ENGINE	TATA spare parts
278620999818	CONNECTION WATER INLET	TATA spare parts
278620999820	CONNECTION WATER INLET	TATA spare parts
278620999821	CLUTCH FAN	TATA spare parts
278620999822	WATER PUMP	TATA spare parts
278620999823	ADAPTER ENGINE VENT BS4	TATA spare parts
278620999824	THERMOSTAT	TATA spare parts
278620999825	SUPPORT FAN? ISBe5.9 BS1-4	TATA spare parts
278620999826	CLUTCH FAN	TATA spare parts
278620999828	THERMOSTAT B5.9 BS3/BS4	TATA spare parts
278620999829	CLUTCH FAN	TATA spare parts
278620999830	FAN ENGINE	TATA spare parts
278620999831	COUPLING ELBOW HOSE	TATA spare parts
278620999832	BRACE TUBE	TATA spare parts
278620999833	BRACE TUBE	TATA spare parts
278620999834	BRACE TUBE	TATA spare parts
278620999835	BRACE TUBE	TATA spare parts
278620999836	BRACE TUBE	TATA spare parts
278620999837	FAN ENGINE ISBE5.9 24INCH 9 BLADE BS4	TATA spare parts
278620999838	CLUTCH FAN BS4	TATA spare parts
278620999839	FAN ENGINE	TATA spare parts
278620999840	CLUTCH VISCOUS FAN	TATA spare parts
278620999841	V-BELT RIBBED ISBe5.9 BS4/6	TATA spare parts
278620999841DF	BELT V RIBBED - 1443MM L - B5.9 BS4	TATA spare parts



278620999842	CONNECTION WATER TRANSFER	TATA spare parts
278620999844	TUBE EXH CLR WATER INLET	TATA spare parts
278620999845	CONNECTION WATER OUTLET	TATA spare parts
278620999846	TUBE EXH CLR	TATA spare parts
278620999847	SPACER MOUNTING	TATA spare parts
278620999848	TUBE EXH CLR WATER OUTLET	TATA spare parts
278620999849	TUBE EXH CLR WATER OUTLET	TATA spare parts
278620999850	TUBE	TATA spare parts
278620999851	FAN ENGINE W/O CLUTCH	TATA spare parts
278620999852	CLUTCH FAN	TATA spare parts
278620999858	ELBOW PLAIN ADAPTER	TATA spare parts
278620999859	CONNECTION WATER INLET	TATA spare parts
278620999860	TENSIONER BELT	TATA spare parts
278620999861	SUPPORT FAN	TATA spare parts
278620999862	CONNECTION WATER INLET	TATA spare parts
278620999901	SCREW HEX FLANGE HEAD	TATA spare parts
278620999902	SUPPORT FAN	TATA spare parts
278620999903	PULLEY FAN BS1/2/3/4	TATA spare parts
278620999904	SCREW HEX FLANGE HD CAP	TATA spare parts
278620999905	FAN ENGINE	TATA spare parts
278620999908	HOUSING THERMOSTAT	TATA spare parts
278620999909	SCREW HEX.CAP M8X1.25X90	TATA spare parts
278620999910	SEAL RECTANGULAR RING	TATA spare parts
278620999911	BRACKET LIFTING	TATA spare parts
278620999912	BRACKET LIFTING	TATA spare parts
278620999913	SCREW HEX.FLANGE HEAD CAP BS4	TATA spare parts
278620999919	CONNECTION WATER INLET	TATA spare parts
278620999920	SCREW M10X1.5X75	TATA spare parts
278620999921	CONNECTION WATER OUTLET	TATA spare parts
278620999922	GASKET CONNECTION	TATA spare parts
278620999923	TENSOR BELT NEW LPT2515TC	TATA spare parts
278620999924	BRACE TUBE	TATA spare parts
278620999925	THERMOSTAT 6BT BS1/2/3/4	TATA spare parts
278620999925AE	THERMOSTAT 713	TATA spare parts
278620999926	SPACER FAN PILOT BS4	TATA spare parts
278620999927	SCREW HEX FLANGE HD CAP	TATA spare parts
278620999928	PLUG THREADED	TATA spare parts
278620999929	HOSE FLEXIBLE BS1/2/3/4	TATA spare parts
278620999930	CONNECTION WATER OUT	TATA spare parts
278620999931	SPACER FAN PILOT	TATA spare parts
278620999932	KIT VISCOUS FAN	TATA spare parts
278620999933	SET-UPPER ENGINE GASKET BS1/2/3	TATA spare parts
278620999933AE	UPPER ENG GSKT KIT -713	TATA spare parts
278620999933DF	GASKET KIT UPPER - 6BT BS2	TATA spare parts
278620999934	FAN ENGINE	TATA spare parts
278620999935	PULLEY FAN	TATA spare parts
278620999936	FAN	TATA spare parts

278620999937	FAN DRIVE VISCOUS	TATA spare parts
278620999939	FAN ENGINE BS1	TATA spare parts
278620999940	CONNECTION SPACER	TATA spare parts
278620999941	GASKET CONNECTION	TATA spare parts
278620999942	BELT V RIBBED	TATA spare parts
278620999943	FAN ENGINE	TATA spare parts
278620999944	SUPPORT FAN	TATA spare parts
278620999945	SCREW H.F.HC	TATA spare parts
278620999946	BRACKET BELT TENSION	TATA spare parts
278620999947	SWITCH THERMO	TATA spare parts
278620999948	CONNECTION WATER OUTLET	TATA spare parts
278620999950	THERMOSTAT	TATA spare parts
278620999951	SPEACER FAN PILOT	TATA spare parts
278620999952	FAN CLUTCH ASSY 12V	TATA spare parts
278620999953	FAN ENGINE	TATA spare parts
278620999954	FAN BS1/3	TATA spare parts
278620999955	FAN ENGINE 22 ISBe5.9 BS2/3/4	TATA spare parts
278620999955AE	FAN VISCOUS 22 INCH -1415-715	TATA spare parts
278620999956	VISCOUS FAN 20 BS1/2/3	TATA spare parts
278620999957	WATER PUMP BRG SEPARATOR	TATA spare parts
278620999958	ELBOW MALE ADAPTER	TATA spare parts
278620999959	WATER PUMP (LOW FLOW) 6BT BS1/2/3/4	TATA spare parts
278620999959DF	WATER PUMP - 6BT BS2	TATA spare parts
278620999960	CONVERSION KIT VISCOUSFAN	TATA spare parts
278620999961	SUPPORT FAN	TATA spare parts
278620999962	V BELT	TATA spare parts
278620999962AE	FAN BELT 713 715	TATA spare parts
278620999963	KIT CONVE FIXED FAN DRIVE	TATA spare parts
278620999964	FAN 7BLADES	TATA spare parts
278620999965	SCREW M10X1.5X55	TATA spare parts
278620999967	FAN PULLEY 1:2 RATIO	TATA spare parts
278620999968	PULLEY FAN	TATA spare parts
278620999970	STUD	TATA spare parts
278620999971	FAN ENGINE	TATA spare parts
278620999972	PUMP WATER	TATA spare parts
278620999973	THERMOSTAT	TATA spare parts
278620999973AE	THERMOSTAT 715	TATA spare parts
278620999974	CONNECTION WATER OUTLET	TATA spare parts
278620999976	FAN ENGINE 22INCH 7 BLADE 6BT BS1/3	TATA spare parts
278620999977	CLUTCH VISCOUS 22 INCH BS1/3	TATA spare parts
278620999978	FAN,ENGINE 22" 7 BLADE 6BT BS3	TATA spare parts
278620999979	CLUTCH VISCOUS 22 INCH BS4	TATA spare parts
278620999981	FAN ENGINE 24 INCH	TATA spare parts
278620999982	FAN ENGINE BS1/2/3	TATA spare parts
278620999982AE	FAN ENGINE 715	TATA spare parts
278620999983	FAN ENGINE 6BT/ISBE5.9 BS2/3/4	TATA spare parts
278620999984	CONNECTOR WATER INLET	TATA spare parts

278620999985	CONNECTION WATER INLET	TATA spare parts
278620999986	CONNECTION WATER INLET	TATA spare parts
278620999987	CONNECTION WATER INLET	TATA spare parts
278620999989	PLUG PIPE (3/4 NPT) BS4	TATA spare parts
278620999990	HOUSING THERMOSTAT	TATA spare parts
278620999991	SUPPORT THERMOSTAT HOUSING	TATA spare parts
278620999992	FAN ENGINE	TATA spare parts
278620999993	CLUTCH FAN BS2/3/4	TATA spare parts
278620999994	CONNECTION VENT	TATA spare parts
278620999995	FAN ENGINE	TATA spare parts
278620999996	CLUTCH? FAN BS1/2/3/4	TATA spare parts
278620999996AE	CLUTCH FAN	TATA spare parts
278620999997	DRIVE FAN	TATA spare parts
278620999998	CONNECTION WATER OUTLET	TATA spare parts
278620999999	CONNECTION WATER INLET	TATA spare parts
278621999901	HUMP HOSE	TATA spare parts
278621999902	TUBE AIR	TATA spare parts
278621999903	HOSE	TATA spare parts
278621999904	PRESSURE VACUUM MODULE	TATA spare parts
278621999905	RESTRICTION INDICATOR	TATA spare parts
278621999906	HOSE FLEXIBLE	TATA spare parts
278621999907	HOSE FLEXIBLE BS1/2/3/4	TATA spare parts
278621999907AE	HOSE FLEXIBLE	TATA spare parts
278622993301	BRACKET ENGINE LIFTING	TATA spare parts
278622993302	BRACKET LIFTING	TATA spare parts
278622999901	SUPPORT FRONT ENGINE	TATA spare parts
278622999902	SUPPORT FRT ENGINE ASSY	TATA spare parts
278622999903	BRACKET LIFTING	TATA spare parts
278622999904	GREASE	TATA spare parts
278622999906	NIPPLE PLAIN HEX	TATA spare parts
278622999907	BRACKET LIFTING	TATA spare parts
278622999908	BRACKET LIFTING	TATA spare parts
278622999909	SCREW HEX FLANGE HEAD CAP	TATA spare parts
278622999910	SPACER	TATA spare parts
278622999911	SUPPORT ACCESSORY DRIVE	TATA spare parts
278623116301	V-BELT COGGED	TATA spare parts
278623120101	ASSY.TENSIONER-A.C.BELT TENSIONER	TATA spare parts
278623120109	BRACKET(A/C COMP MTG & BELT TENSIONER)	TATA spare parts
278623120111	BRACKET (A/C COMP MTG)	TATA spare parts
278623120112	ASSY.A/C COMPRESSOR(LPT1618 LHD)	TATA spare parts
278623120113	BRACKET(AC COMPRESSOR MOUNTING)	TATA spare parts
278623120114	CARRIER AC COMPRESSOR(TM16 MODEL)	TATA spare parts
278623120121	ASSY BRACKET (AC COMPRESSOR MOUNTING)	TATA spare parts
278623123307	BRACKET-FOR A/C COMP.MOUNTING ON ENG	TATA spare parts
278623123312	BRACKET	TATA spare parts
278623123313	BRACKET	TATA spare parts
278623995401	GEAR ACCESSORY DRIVE	TATA spare parts

278623998601	SPACER MOUNTING BS4	TATA spare parts
278623998602	SPACER MOUNTING	TATA spare parts
278624200101	ASSY.RUBBER SUPPORT REAR.	TATA spare parts
278624200102	ASSY. RUBBER SUPPORT REAR	TATA spare parts
278633106702	SPLIT PIN	TATA spare parts
278650000102	FRAME RADIATOR MTG	TATA spare parts
278650000108	ASSY RAD. MOUNTING FRAME	TATA spare parts
278650000115	ASSY.RADIATOR FRAME(2518 BS2 COWL)	TATA spare parts
278650000122	ASSY RADI.MTG.FRME 1615	TATA spare parts
278650000124	FRAME RADIATOR MTG	TATA spare parts
278650000129	ASSY. RADIATOR MTG. FRAME LPO 1615TC RE	TATA spare parts
278650000147	ASSY RADIATOR MTG FRAME(LP1512TC-EURO-II	TATA spare parts
278650000152	ASSY FRAME FOR RADIATOR	TATA spare parts
278650000154	ASSY RADIATOR MTG FRAME	TATA spare parts
278650000157	ASSY.RADIATOR MOUNTING FRAME.	TATA spare parts
278650000160	ASSY.RADIATOR MOUNTING FRAME.	TATA spare parts
278650000165	ASSY.RADIATOR MOUNTING FRAME	TATA spare parts
278650000166	ASSY RADIATOR FRAME LPO1510CNG_55	TATA spare parts
278650000167	ASSY BRIDGE LPT2515 SL/TILT CAB	TATA spare parts
278650000177	ASSY.RADIATOR MOUNTING FRAME.	TATA spare parts
278650000181	ASSY.RADIATOR MTG FRAME(LPT2516TC)	TATA spare parts
278650000186	ASSY.RADIATOR FRAME(LPT/LPK1615TC)	TATA spare parts
278650000191	ASSY BRIDGE-FOR LPT1613TC & LPS3015TC	TATA spare parts
278650000192	ASSY RADIATOR MTG.FRAME(LPT2516-80MM LIF	TATA spare parts
278650000196	ASSY.RADIATOR FRAME 3015TC S.PROP SHAFT	TATA spare parts
278650000199	RADIATOR FRAME LPT 2515	TATA spare parts
278650000206	ASSY.RAD.FRAME-75MM 1512/2515-TRNS TANK	TATA spare parts
278650000208	ASSY.TIE MEMBER-TOP	TATA spare parts
278650000209	BRACKET-LH(ON LM)	TATA spare parts
278650000210	BRACKET-RH(ON LM)	TATA spare parts
278650000211	ASSY.BRACKET-LH(ON LONG MEMBER)	TATA spare parts
278650000212	ASSY.RADIATOR FRAME LP1512/LPT2515TC	TATA spare parts
278650000216	ASSY.BRIDGE(FOR RADIATOR TOP MTG.)	TATA spare parts
278650000217	ASSY. SUPPORT (AUX. WATER TANK MTG.)	TATA spare parts
278650000218	ASSY RADIATOR MTG FRAME	TATA spare parts
278650000225	ASSY.RADIATOR FRAME.	TATA spare parts
278650000226	ASSY.RADIATOR FRAME	TATA spare parts
278650000227	ASSY. BRACKET	TATA spare parts
278650000228	BRACKET-LH(RAD. FRAME SIDE MTG.)	TATA spare parts
278650000229	ASSY BRACKET-RH	TATA spare parts
278650000231	ASSY. BRACKET-LH	TATA spare parts
278650000232	ASSY. BRACKET-RH	TATA spare parts
278650000235	ASSY.BRACKET-RH(ON LONG MEMBER)	TATA spare parts
278650000237	ASSY.RADIATOR FRAME(2515 BS2 COWL)	TATA spare parts
278650000238	ASSY.RAD.FRAME WITH TIE MEMBER(2518COWL)	TATA spare parts
278650000239	ASSY.RAD.FRAME WITH TIE MEMBER(2515COWL)	TATA spare parts
278650000242	ASSY BRACKET-LH RAD FRAME SIDE MTG	TATA spare parts

278650000243	ASSY BRACKET-RH RAD FRAME SIDE MTG	TATA spare parts
278650000244	ASSY BRACKET-LH (RAD FRAME SIDE MTG)	TATA spare parts
278650000245	ASSY BRACKET-RH (RAD. FRAME SIDE MTG)	TATA spare parts
278650000247	ASSY.BRACKET(ON LONG MEMBER)	TATA spare parts
278650000250	ASSY RUBBER BUSH RAD FRAME SIDE MTG	TATA spare parts
278650000252	ASSY.SHIELD(FOR SEALING)	TATA spare parts
278650000260	BRACKET FAN MTG	TATA spare parts
278650000261	ASSY.BRACKET-RH	TATA spare parts
278650000262	ASSY.BRACKET-LH	TATA spare parts
278650000263	ASSY. BRACKET (FOR AUX TANK MTG.)	TATA spare parts
278650000264	ASSY.BRACKET ON L.M.(RAD FRAME SIDE MTG)	TATA spare parts
278650000265	ASSY RUBBER BUSH(208 LONG)	TATA spare parts
278650000266	BRACKET LH(RAD FRAME SIDE)LPT2518/3015	TATA spare parts
278650000267	BRACKET RH(RAD FRAME SIDE)LPT2518/3015	TATA spare parts
278650000268	ASSY RADIATOR FRAME	TATA spare parts
278650000270	ASSY.BRACKET ON L.M (RAD FRAME FRONT MTG)	TATA spare parts
278650000271	ASSY.BRACKET(ON LONG MEMBER)	TATA spare parts
278650000273	BRACKET-LH(RAD.FRAME SIDE MTG)	TATA spare parts
278650000274	ASSY.BRACKET-RH(RAD.FRAME SIDE MTG)	TATA spare parts
278650000285	BRACKET-LH (RAD.FRAME SIDE MTG)	TATA spare parts
278650000286	BRACKET-RH (RAD.FRAME SIDE MTG)	TATA spare parts
278650000287	ASSY.BRACKET-RH(ON LONG MEMBER)	TATA spare parts
278650000288	ASSY.BRACKET-LH(ON LONG MEMBER)	TATA spare parts
278650000290	BRACKET -LH (RAD.FRAME SIDE MTG)	TATA spare parts
278650000291	BRACKET-RH(RAD.FRAME SIDE MTG)	TATA spare parts
278650000292	ASSY RAD MTG BKT RH (LM TOP SIDE)	TATA spare parts
278650000293	ASSY RAD MTG BKT LH (LM TOP SIDE)	TATA spare parts
278650000294	ASSY RAD MTG BKT RH (BOTTOM SIDE)	TATA spare parts
278650000295	ASSY RAD MTG BKT LH (BOTTOM SIDE)	TATA spare parts
278650000296	ASSY RAD MTG BKT RH (TOP SIDE)(M0)	TATA spare parts
278650000297	ASSY RAD MTG BKT LH (TOP SIDE)(M0)	TATA spare parts
278650000299	BRACKET ON LM	TATA spare parts
278650000302	AIR PROTECTOR (RADIATOR RH SIDE)	TATA spare parts
278650000303	AIR PROTECTOR (RADIATOR LH SIDE)	TATA spare parts
278650000309	ASSY.RADIATOR FRAME LPT2518TC	TATA spare parts
278650000310	BRACKET RH RADIATOR FRAME SIDE MTG AND B	TATA spare parts
278650000311	BRACKET LH RADIATOR FRAME SIDE MTG AND B	TATA spare parts
278650000312	ASSY. RADIATOR BS3/4	TATA spare parts
278650000315	RADIATOR ASSY FLAP	TATA spare parts
278650000316	RADIATOR MTG PAD SIDE	TATA spare parts
278650000318	BRACKET ASSEMBLY-LH(ON LM)	TATA spare parts
278650000319	BRACKET ASSEMBLY-RH(ON LM)	TATA spare parts
278650000320	RADIATOR MTG BRACKET ASSY TOP SIDE LH	TATA spare parts
278650000321	RADIATOR MTG BRACKET ASSY TOP SIDE RH	TATA spare parts
278650000324	BRACKET (ON LONG MEMBER)	TATA spare parts
278650000325	BRACKET (RH ON LONG MEMBER)	TATA spare parts
278650000336	ASSY. RADIATOR BS2/4	TATA spare parts

27865000337	RADIATOR ASSY	TATA spare parts
27865000338	ASSY. RADIATOR BS4	TATA spare parts
27865000343	BRACKET ASSY LH	TATA spare parts
27865000344	BRACKET ASSY RH	TATA spare parts
278650003308	BRACKET-BETWEEN BRIDGE & RAD.FRAME	TATA spare parts
278650003309	BRACKET-ON BRIDGE	TATA spare parts
278650003319	SLIDER BRACKET (FOR FAN DRIVE ARRGT.)	TATA spare parts
278650003320	BRACKET-LH(ON LONG MEMBER) RAD. BOTTOM	TATA spare parts
278650003321	BRACKET-RH RAD. TOP MTG.	TATA spare parts
278650003322	BRACKET-RH SIDE RAD.BOTTOM MTG.	TATA spare parts
278650003323	BRACKET-RH	TATA spare parts
278650003328	BRACKET ON BRIDGE (RADIATOR TOP MTG.)	TATA spare parts
278650003331	SUPPORT(FLAP)	TATA spare parts
278650003333	BRACKET (WTER FILL PIPE)	TATA spare parts
278650003347	BRACKET(RH)	TATA spare parts
278650003348	BRACKET(LH)	TATA spare parts
278650003359	BRACKET	TATA spare parts
278650005802	REDUCER HOSE	TATA spare parts
278650006301	RUBBER BUFFER-40 OD X 24	TATA spare parts
278650006302	RUBBER BUFFER 38D X12	TATA spare parts
278650006303	FOAM INSULATION (BETWEEN RADIATOR & INTE	TATA spare parts
278650007705	FLAP	TATA spare parts
278650008261	SUPPORT PLATE(FOR RUBBER FLAP)LPS4018TC	TATA spare parts
278650008601	SPACER(RAD.BOTTOM MTG)	TATA spare parts
278650009202	WASHER-20 IDX 30 OD X 2THK	TATA spare parts
278650009203	WASHER (40 ODX20 IDX1.6 T	TATA spare parts
278650009903	ELBOW CONNECTOR ON RETARDER LINE	TATA spare parts
278650009904	CONNECTOR RETARDER	TATA spare parts
278650010103	ASSY.BRACKET.(FOR AUX.WATER TANK MTG)	TATA spare parts
278650010104	ASSY.SUPPORT(FOR AUX.WATER TANK MTG)	TATA spare parts
278650010105	ASSY. RADIATOR 697CRDI/6BT BS1/2/3/4	TATA spare parts
278650010105DF	RADIATOR ASSY-LPK2518-LPS3516/3518/4018	TATA spare parts
278650010106	ASSY.RADIATOR	TATA spare parts
278650010107	ASSY. SUPPORT (FOR AUX. WATER TANK MOUN)	TATA spare parts
278650010115	ASSY.WATER FILL PIPE.	TATA spare parts
278650010126	ASSY.BRACKET-RH(AUX.WATER TANK MTG)	TATA spare parts
278650010127	ASSY.BRACKET-LH(AUX.WATER TANK MTG)	TATA spare parts
278650010129	ASSY WATER FILL PIPE	TATA spare parts
278650010130	ASSY.BRACKET-LH(RAD.TOP MTG)	TATA spare parts
278650010131	ASSY.BRACKET-RH(RAD.TOP MTG)	TATA spare parts
278650010133	ASSY HOSE WITH CORRUGATED TUBE	TATA spare parts
278650010134	ASSY WATER FILL PIPE	TATA spare parts
278650010138	ASSY WATER FILL PIPE (LPT3721)	TATA spare parts
278650010144	PIPE WATER FILL	TATA spare parts
278650010149	AUX WATER TANK ASSY WITH LEVEL SENSOR	TATA spare parts
278650010151	WATER FILLER PIPE AWT TO RADIATOR	TATA spare parts
278650100104	BKT AUX WATER TANK	TATA spare parts

278650100121	RADIATOR ASSY	TATA spare parts
278650100128	ASSU RAD LP1512 FR MOUNTE	TATA spare parts
278650100129	ASSY RADIATOR COMPLETE	TATA spare parts
278650100133	ASSY RADIATOR BLOCK COMPLETE	TATA spare parts
278650100135	ASSY AUXILIARY WATER TANK	TATA spare parts
278650100147	RADIATOR 2516	TATA spare parts
278650100149	RADIATOR ASSY	TATA spare parts
278650100151	AUX. WATER TANK LPK 2516TC	TATA spare parts
278650100152	ASSY.BRACKET.	TATA spare parts
278650100156	RADIATOR ASSY	TATA spare parts
278650100157	ASSY.BRACKET	TATA spare parts
278650100161	RADIATOR ASSY	TATA spare parts
278650100163	ASSY.RAD.COMPLETE(3521/2521/1921).	TATA spare parts
278650100167	ASSY.RADIATOR COMPLETE LPO1316	TATA spare parts
278650100169	RADIATOR ASSY	TATA spare parts
278650100170	RADIATOR LPK 2516TC	TATA spare parts
278650100179	ASSY.RADIATOR COMPLETE	TATA spare parts
278650100182	ASSY RADIATOR	TATA spare parts
278650100184	ASSY.RADIATOR COMPLETE	TATA spare parts
278650100190	ASSY.RADIATOR COMPLETE-2516	TATA spare parts
278650100192	ASSY.RADIATOR COMPLETE-2516	TATA spare parts
278650100194	ASSY RADIATOR COMPLETE	TATA spare parts
278650100202	ASSY RADIATOR BLOCK COMPLETE	TATA spare parts
278650100205	SET RADIATOR- LP1312	TATA spare parts
278650100216	SET AUX.WATER TANK WITH BRACKET.	TATA spare parts
278650100220	ASSY AUX WATER TANK 2516 LOW MT TC	TATA spare parts
278650100225	ASSY.RADIATOR- OFFER DRG	TATA spare parts
278650100228	ASSY RAD.LP1512 FR.MOUNTE	TATA spare parts
278650100229	ASSY.WATER FILL PIPE	TATA spare parts
278650100231	ASSY RADIATOR- LP 1512 FRAME MOUNTED	TATA spare parts
278650100235	RADIATOR ASSY	TATA spare parts
278650100236	ASSY.RADIATOR COMPLETE	TATA spare parts
278650100247	ASSY.RADIATOR-LP 1512 FRAME MTD.	TATA spare parts
278650100248	ASSY RADIATOR BLOCK COMPLETE	TATA spare parts
278650100249	ASSY.RADIATOR COMPLETE-2516	TATA spare parts
278650100250	ASSY.RADIATOR LPS3015/LPT2515	TATA spare parts
278650100252	ASSY.RADIATOR COMPLETE	TATA spare parts
278650100255	RADIATOR COMPLETE LPT2516TC-4PT ENG MTG	TATA spare parts
278650100257	ASSY RADIATOR- LP 1512 FRAME MOUNTED	TATA spare parts
278650100258	T CONNECTOR (FOR ENG & EXH VENT)	TATA spare parts
278650100260	ASSY RADIATOR COMPLETE(4PT ENG MTG 3521)	TATA spare parts
278650100261	ASSY RADIATOR LPT 2515 TC/LPS 3015 TC	TATA spare parts
278650100263	ASSY RADIATOR LPT 2515 TC/LPS 3015 TC	TATA spare parts
278650100270	ASSY.RADIATOR LPK2516 6X4	TATA spare parts
278650100271	ASSY PIPE - RADIATOR BOTTOM TO ASSY PIPE	TATA spare parts
278650100272	ASSY RADIATOR	TATA spare parts
278650100277	RADIATOR SUB ASSY.COMPLETE	TATA spare parts

278650100278	RESERVE TANK ASSY.COMPLETE	TATA spare parts
278650100280	TOP TANK COMPLETE	TATA spare parts
278650100281	BOTTOM TANK COMPLETE.	TATA spare parts
278650100282	RESERVE TANK ASSY	TATA spare parts
278650100283	ASSY. RADIATOR (ALUMINIUM)W/O TANK BS2/3	TATA spare parts
278650100287	ASSY.RADIATOR- CORE 740X537	TATA spare parts
278650100289	ASSY.BRACKET-AUX.WATER TANK MOUNTING	TATA spare parts
278650100294	ASSY.PIPE-RADIATOR TO WATER PUMP	TATA spare parts
278650100297	ASSY RADIATOR- LP 1512 FRAME MOUNTED	TATA spare parts
278650100298	ASSY.AUXILARY TANK(PLASTIC)	TATA spare parts
278650100298AE	TRANLUCENT TANK --1628-1828	TATA spare parts
278650100301	ASSY. RESERVE TANK	TATA spare parts
278650100303	ASSY.BRACKET AUX.WATER TANK MTG.LPT2515	TATA spare parts
278650100306	ASSY. RADIATOR-560 CORE HEIGHT BS1/2/3	TATA spare parts
278650100306DF	RADIATOR ASSY-SE/SK1613 BS2 (22X21)	TATA spare parts
278650100307	ASSY.RADIATOR LPK2516 6X5	TATA spare parts
278650100312	RADIATOR ASSY W/O SURGE TANK	TATA spare parts
278650100313	ASSY. RADIATOR BS2/3	TATA spare parts
278650100313DF	RADIATOR ASSY-LPT2518/3118/3718 BS3	TATA spare parts
278650100314	ASSY.CLAMP WITH SLEEVE-FOR VENT TUBE	TATA spare parts
278650100316	ASSY.CLAMP-FOR WATER FILL PIPE	TATA spare parts
278650100317	ASSY.BRACKET-FOR WATER FILL PIPE	TATA spare parts
278650100319	ASSY.BRACKET WITH SLEEVE.	TATA spare parts
278650100320	ASSY.BRACKET-FOR VENT TUBE CLAMPING	TATA spare parts
278650100326	RADIATOR ASSY 3015TC BSII TILT CAB	TATA spare parts
278650100329	ASSY. RADIATOR BS1/2/3	TATA spare parts
278650100330	ASSY RADIATOR (ALUMINIUM) WITH PLASTIC T	TATA spare parts
278650100331	ASSY. RESERVE TANK BS1/2/3/4	TATA spare parts
278650100333	ASSY RADIATOR 3 POINT MTG	TATA spare parts
278650100335	ASSY.WATER FILL PIPE-3015TC	TATA spare parts
278650100336	ASSY.WATER FILL PIPE(1615TC-RAD)	TATA spare parts
278650100337	ASSY. RADIATOR	TATA spare parts
278650100338	ASSY.WATER FILL PIPE 1512/2515 TRS TANK	TATA spare parts
278650100339	AUXILLARY WATER TANK	TATA spare parts
278650100341	RADIATOR-LPT2516 80MM LIFTED BS2/3/4	TATA spare parts
278650100344	RADIATOR-LPT 2516 TC	TATA spare parts
278650100348	ENGINE COOLING SYSTEM-LP1512TC/1613TC	TATA spare parts
278650100349	ENGINE COOLING SYSTEM-LPT2515TC	TATA spare parts
278650100358	ASSY. BRACKET COMPLETE AUX W TANK MTG	TATA spare parts
278650100359	ASSY.RADIATOR BLOCK COMPLETE	TATA spare parts
278650100360	ASSY.BRACKET(VENT TUBE CLAMPING REAR)	TATA spare parts
278650100361	ASSY. AUXILLIARY WATER TANK BS3	TATA spare parts
278650100366	ASSY.BRACKET RH RAD.FRAME SIDE MTG	TATA spare parts
278650100367	ASSY.BRACKET-LH. RAD.FRAME SIDE MTG	TATA spare parts
278650100368	ASSY. RADIATOR BS2/3	TATA spare parts
278650100369	ENGINE COOLING SYSTEM 2518-EII-T.CAB	TATA spare parts
278650100370	ENGINE COOLING SYSTEM(3015 E-II TILT CAB	TATA spare parts



278650100374	ENGINE COOLING SYSTEM(2515TC BS2 T.CAB)	TATA spare parts
278650100375	ASSY. RADIATOR(LP1512TC E-3) BS1/2/3/4	TATA spare parts
278650100377	RADIATOR ASSY 2515TC BSII TILT CAB	TATA spare parts
278650100379	RAD. ASSY LPO1510CNG BSIII W/SS RES TANK	TATA spare parts
278650100385	ASSY.RADIATOR LPT2518 TC BS2COWL)	TATA spare parts
278650100386	AUX WATER TANK	TATA spare parts
278650100387	ASSY. PIPE (RADIATOR TO ENGINE)	TATA spare parts
278650100390	RADIATOR ( LPT 2515/LPS 3015 COWL)	TATA spare parts
278650100392	ASSY RADIATOR	TATA spare parts
278650100395	RAD.BLOCK COMPLETE(1623ARMY)	TATA spare parts
278650100396	SET ASSY.AUX W.TANK & MTG CLAMPS	TATA spare parts
278650100398	ASSY.RAD.SHUTTER	TATA spare parts
278650100399	ASSY.TOP SUPPORT BKT(RAD.SHUTTER MTG)	TATA spare parts
278650103307	BRACKET (FOR WATER FILL PIPE)	TATA spare parts
278650103309	BRACKET-WATER FIL PIPE CLAMPING	TATA spare parts
278650103803	CONNECTION WATER INLET	TATA spare parts
278650104204	CLAMP	TATA spare parts
278650104205	CLAMP	TATA spare parts
278650104207	CLAMP	TATA spare parts
278650104211	CLAMP	TATA spare parts
278650104213	CLAMP(WATER FILL PIPE) SE1613TC	TATA spare parts
278650104214	CLAMP (FOR WATER FILL PIPE)	TATA spare parts
278650104219	CLAMP(WATER FILL PIPE)	TATA spare parts
278650104228	CLAMP PIPE	TATA spare parts
278650105802	HOSE RADIATOR TO ENG	TATA spare parts
278650105803	RUBBER HOSE	TATA spare parts
278650105804	HOSE VENT TUBE TO RAD	TATA spare parts
278650105805	RUBBER HOSE FROM VENTTUBE	TATA spare parts
278650105806	RUBBER HOSE	TATA spare parts
278650105808	RUB HOSE RAD BOT TO ENG	TATA spare parts
278650105811	HOSE RADIATOR TO ENG	TATA spare parts
278650105815	RUBBER HOSE FROM RADIATOR	TATA spare parts
278650105818	RUBBER HOSE	TATA spare parts
278650105819	HOSE RAD TO ENG LP1312	TATA spare parts
278650105821	RUBBER HOSE	TATA spare parts
278650105822	RUBBER HOSE	TATA spare parts
278650105823	RUBBER HOSE	TATA spare parts
278650105824	RUBBER HOSE	TATA spare parts
278650105827	RUBBER HOSE	TATA spare parts
278650105828	HOSE (ENGINE WATER OTLET) 1510CNG	TATA spare parts
278650105829	HOSE (RADIATOR BOTTOM TANK) 1510CNG	TATA spare parts
278650105829AE	HOSE (RDTR BTTM TANK) -1628-1828	TATA spare parts
278650105830	RUBBER HOSE	TATA spare parts
278650105832	RUBBER HOSE	TATA spare parts
278650105832AE	RUBBER HOSE -1415	TATA spare parts
278650105835	HOSE RADOATOR INLET	TATA spare parts
278650105836	RUB HOSE AUX TANK- F/PIPE	TATA spare parts

278650105837	RUBBER HOSE	TATA spare parts
278650105838	RUBBER HOSE	TATA spare parts
278650105839	RUBBER HOSE	TATA spare parts
278650105840	HOSE ENG OUTLET	TATA spare parts
278650105842	HOSE(RAD TO WATER PUMP)	TATA spare parts
278650105843	VENT HOSE UNIVERSAL RAD	TATA spare parts
278650105844	RUB HOSE ENG OUTLET	TATA spare parts
278650105845	RUB HOSE 6 ID X 55MM	TATA spare parts
278650105845AE	HOSE (6 ID x 55 LONG)LPA 1415/	TATA spare parts
278650105846	RUB HOSE 28.6 ID X 100MM	TATA spare parts
278650105848	HOSE-20 I.D. 50X50	TATA spare parts
278650105849	VENT HOSE RADIATOR TO WATER TANK	TATA spare parts
278650105850	VENT HOSE ENGINE TO AUX WATER TANK	TATA spare parts
278650105851	HOSE-RADIATOR TO W/PUMP BS4	TATA spare parts
278650105852	VENT.HOSE	TATA spare parts
278650105854	HOSE AUX WATER TANK TO WATER FILL PIPE	TATA spare parts
278650105856	RUBBER HOSE (AUX.TANK TO W.FILL PIPE)	TATA spare parts
278650105858	HOSE (ENGINE TO RADIATOR)	TATA spare parts
278650105859	HOSE (ENGINE TO RADIATOR INLET)	TATA spare parts
278650105860	RUBBER HOSE - RAD.TO ENG.	TATA spare parts
278650105861	HOSE-FROM ENGINE OUTLET	TATA spare parts
278650105862	RUBBER HOSE-RADIATOR TO ENGINE	TATA spare parts
278650105863	HOSE	TATA spare parts
278650105864	HOSE	TATA spare parts
278650105866	RUBBER HOSE 1510CNG	TATA spare parts
278650105867	HOSE (RADIATOR TO WATER PUMP) 2516TC	TATA spare parts
278650105868	HOSE-RAD. TOP TANK TO FILL PIPE	TATA spare parts
278650105869	HOSE-RAD BOTTOM TANK TO FILL PIPE	TATA spare parts
278650105870	HOSE RADIATOR TO WATER PUMP	TATA spare parts
278650105871	HOSE(RAD TO ENG)	TATA spare parts
278650105872	RUBBER HOSE TO RADIATOR INLET	TATA spare parts
278650105873	HOSE-WATER PUMP TO ASSY PIPE 1510CNG	TATA spare parts
278650105874	HOSE RADIATOR TO ENGINE	TATA spare parts
278650105875	HOSE ENGINE OUTLET	TATA spare parts
278650105876	HOSE ENGINE TO RADIATOR	TATA spare parts
278650105883	RUBBER HOSE-RADIATOR TO ENGINE	TATA spare parts
278650105884	RUBBER HOSE-FROM ENGINE TO RADIATOR	TATA spare parts
278650105886	RUBBER HOSE RAD TO ENG-LP1512-TRNS TANK	TATA spare parts
278650105887	RUBBER HOSE RAD TO ENG-2515 TRS TANK	TATA spare parts
278650105888	HOSE RAD.TO W.PUMPLPT/LPK1615TC	TATA spare parts
278650105889	REDUCER HOSE FOR ENG.& RADIATOR VENTING	TATA spare parts
278650105890	RUBBER HOSE-FOR VENTING ON AUX.W.TANK	TATA spare parts
278650105891	HOSE WATER FILL PIPE TO RAD	TATA spare parts
278650105893	RUBBER HOSE-WATER FILL PIPE	TATA spare parts
278650105898	RUBBER HOSE(WATER FILL PIPE TO RAD)	TATA spare parts
278650105899	RUBBER HOSE(AUX.TO WATER FILL PIPE)	TATA spare parts
278650106354	FAN SHROUD	TATA spare parts

278650106907	ASSY RADIATOR PIPE	TATA spare parts
278650106920	PIPE WATER FILLER	TATA spare parts
278650106921	VENT TUBE	TATA spare parts
278650106936	VENT TUBE-RADIATOR TO AWTANK	TATA spare parts
278650106937	VENT TUBE-ENGINE TO AWTANK	TATA spare parts
278650106938	PIPE ENG TO RADIATOR	TATA spare parts
278650106949	PIPE WATER FILLER	TATA spare parts
278650106951	PIPE ENG OUTLET-RAD INLET	TATA spare parts
278650106951AE	PIPE (ENG TO RAD)LPA 1415	TATA spare parts
278650106952	VENT TUBE RAD- A/TANK RHD	TATA spare parts
278650106953	VENT TUBE T- A/TANK RHD	TATA spare parts
278650106957	WATER FILL PIPE AUX	TATA spare parts
278650106964	VENT TUBE(RADIATOR)2516	TATA spare parts
278650106968	VENT TUBE LP1312	TATA spare parts
278650106969	PIPE WATER FILLER LP1312	TATA spare parts
278650106974	VENT PIPE ENGINE TO WATER TANK	TATA spare parts
278650106976	VENT TUBE (ENGINE TO RADIATOR)	TATA spare parts
278650106977	WATER FILL PIPE	TATA spare parts
278650106981	PIPE-ENGINE TO RADIATOR	TATA spare parts
278650106982	PIPE (ENG.OUTLET TO RAD.INLET)-300 LONG	TATA spare parts
278650106983	VENT TUBE-ENGINE TO RADIATOR	TATA spare parts
278650106987	WATER FILL PIPE	TATA spare parts
278650106994	WATER FILL PIPE 28.6 ODX1.22THK.	TATA spare parts
278650106997	FILL PIPE-AUXWATER TO ASSYPIPE	TATA spare parts
278650106998	VENT TUBE(LPT1615TC-TOYO RAD)	TATA spare parts
278650108262	PRESSURE CAP (0.5 BAR)	TATA spare parts
278650108263	PRESSURE CAP (0.9 BAR)	TATA spare parts
278650108301	SHIM 1MM THICK	TATA spare parts
278650108302	SHIM 2MM THICK	TATA spare parts
278650108303	SHIM 5MM THICK	TATA spare parts
278650108307	WASHER	TATA spare parts
278650109901	RADIATOR CORE- 537.2X525X48	TATA spare parts
278650109902	RADIATOR CORE- 537.2 X 560 X 48	TATA spare parts
278650109905	WATER FILLING PIPE	TATA spare parts
278650109906	TANK PACKING	TATA spare parts
278650109908	DRAIN COCK	TATA spare parts
278650109909	PRESSURE CAP SURGE TANK BS2	TATA spare parts
278650109913	ASSY COUPLING BODY (CAB HEATING)	TATA spare parts
278650109936	DRAIN COCK(ALKRAFT)	TATA spare parts
278650109969	PRESSURE CAP (0.5 BAR)	TATA spare parts
278650110102	ASSY.SUPPORT BKT(RAD.SHUTTER MTG)	TATA spare parts
278650110105	ASSY.BRACKET(TRANSLUCENT TANK)	TATA spare parts
278650110121	ASSY.AUX.WATER TANK(PLASTIC)	TATA spare parts
278650110121DF	WATER RESERVE TANK-1615/2518/3118	TATA spare parts
278650110131	SET COOLING PACKAGE	TATA spare parts
278650110133	SET COOLING PACKAGE	TATA spare parts
278650110143	SET COOLING PACKAGE	TATA spare parts

278650110144	SET COOLING PACKAGE	TATA spare parts
278650110150	SET-ENG.COOLING SYSTEM-LPS4923	TATA spare parts
278650110151	ASSY. RADIATOR ISBE5.9/6BT BS2/3/4	TATA spare parts
278650110155	ENG.COOLING SYSTEM	TATA spare parts
278650110156	RADIATOR ASSY.	TATA spare parts
278650110160	SET-ENGINE COOLING SYSTEM BS3	TATA spare parts
278650110161	SET-COOLING SYSTEM 6BT BS3	TATA spare parts
278650110162	SET COOLING PACKAGE LPT 2518 BS 3 COWL	TATA spare parts
278650110165	SET-ENG.COOLING SYSTEM-LPS4018	TATA spare parts
278650110175	SET COOLING PACKAGE LPT2518 BS3 COWL	TATA spare parts
278650110177	ASSY PIPE ( RAD TO ENG)	TATA spare parts
278650110183	ASSY ENGINE COOLING PACKAGE (LPO 1620 CN	TATA spare parts
278650110185	SET-COOLING SYSTEM 6BT BS3	TATA spare parts
278650110187	RADIATOR ASSY	TATA spare parts
278650110188	AUXILIARY TANK ASSY	TATA spare parts
278650110189	RADIATOR ASSY WITH FRAME	TATA spare parts
278650110191	SET COOLING PACKAGE	TATA spare parts
278650110192	SET-COOLING SYSTEM 6BT BS3	TATA spare parts
278650110195	SET COOLING SYSTEM	TATA spare parts
278650110202	BRACKET-RH (ON LONG MEMBER LPT2518 TC CO	TATA spare parts
278650110203	ASSY.BRACKET (RAD FRAME SIDE MTG)	TATA spare parts
278650110204	BRACKET-LH	TATA spare parts
278650110205	BRACKET-RH	TATA spare parts
278650110206	RADIATOR ASSY-LPT1613 TC BS3 COWL	TATA spare parts
278650110214	ASSY.BRACKET (RAD FRAME SIDE MTG)	TATA spare parts
278650110215	RAD MTG BKT-FRAME SIDE-RH	TATA spare parts
278650110216	RAD MTG BKT-FRAME SIDE-LH	TATA spare parts
278650110217	RAD MTG BKT-RAD SIDE-RH	TATA spare parts
278650110218	RAD MTG BKT-RAD SIDE-LH	TATA spare parts
278650110219	ASSY.STUD-RAD MTG	TATA spare parts
278650110221	ASSY.RUBBER BUSH	TATA spare parts
278650110223	ASSY.RAD MTG BKT-FRAME SIDE-RH	TATA spare parts
278650110226	ASSY.RAD MTG BKT-FRAME SIDE-LH	TATA spare parts
278650110234	ASSY MOUNTING BRACKET	TATA spare parts
278650110235	ASSY CLAMPING BRACKET	TATA spare parts
278650110236	BRACKET-LH (ON LM)	TATA spare parts
278650110263	BRACKET RADIATOR MTG RH TOP SIDE	TATA spare parts
278650110264	BRACKET RADIATOR MTG LH TOP SIDE	TATA spare parts
278650110268	STUD ASSY RADIATOR MOUNTING	TATA spare parts
278650110272	STUD ASSY	TATA spare parts
278650110274	STUD ASSY RADIATOR MTG	TATA spare parts
278650110275	ASSY. RADIATOR BS3	TATA spare parts
278650110278	BRACKET ASSY RH	TATA spare parts
278650110279	BRACKET ASSY LH	TATA spare parts
278650110280	STAY ROD ASSY	TATA spare parts
278650110281	STAY ROD ASSY	TATA spare parts
278650110289	TIE ROD ASSY WITH BUSH	TATA spare parts

278650110293	PIPE ASSY ENGINE INTAKE	TATA spare parts
278650110301	ASSY. RADIATOR (LPS4018TC) BS1/2/3/4	TATA spare parts
278650110311	SET COOLING PACKAGE LPS4018TC	TATA spare parts
278650110312	SET COOLING PACKAGE LPS4018TC	TATA spare parts
278650110313	SET COOLING PACKAGE LPS4018TC	TATA spare parts
278650110314	RADIATOR ASSY-FRAME LESS BANCO(LPS4018TC)	TATA spare parts
278650110315	LPS4018TC BS3-FRAMELESS COOLING SYSTEM	TATA spare parts
278650110360	ASSY. WATER FILL PIPE LPS 3516 BS-2	TATA spare parts
278650110361	ASSY.D.A.TANK	TATA spare parts
278650110363	ENGINE COOLING SYSTEM LPS4923	TATA spare parts
278650110367	ENGINE COOLING SYSTEM(2515TC-FRAMELESS)	TATA spare parts
278650110376	ASSY.PLASTIC RESERVE TANK	TATA spare parts
278650110379	ENGINE COOLING SYSTEM BS3	TATA spare parts
278650110385	ENGINE COOLING SYSTEM	TATA spare parts
278650110387	SET COOLING SYSTEM LPS 4018TC BS3	TATA spare parts
278650110388	ASSY.RADIATOR (LPS4018 TC BS3)	TATA spare parts
278650110389	SET-COOLING SYSTEM LPS 4018TC BS3	TATA spare parts
278650110399	D.A.TANK (DIA28.6)	TATA spare parts
278650114217	CLAMP(FOR WATER FILL PIPE)	TATA spare parts
278650115801	RAD. BOTTOM HOSE	TATA spare parts
278650115802	RUBBER HOSE AUX.W.TANK TO FILL PIPE	TATA spare parts
278650115803	RADIATOR BOTTOM HOSE	TATA spare parts
278650115804	HOSE(RAD TO WATER PUMP)	TATA spare parts
278650115805	HOSE (ON WATER PUMP INLET)	TATA spare parts
278650115806	HOSE(TRANSLUCENT TANK TO FILL PIPE)	TATA spare parts
278650115807	BOTTOM HOSE(RAD TO ENG)	TATA spare parts
278650115808	REDUCER HOSE(RAD.TO FILL PIPE)	TATA spare parts
278650115809	HOSE	TATA spare parts
278650115810	HOSE (RADIATOR BOTTOM TANK)	TATA spare parts
278650115812	RUBBER HOSE(AUX.W.TANK TO W.FILL PIPE)	TATA spare parts
278650115815	HOSE (RADIATOR TO ENGINE)	TATA spare parts
278650115816	REDUCER HOSE (RAD. TO ENGINE)	TATA spare parts
278650115817	RUBBER HOSE RAD AUX WT VENTING	TATA spare parts
278650115819	HOSE (RAD.TO ENG)	TATA spare parts
278650115820	HOSE-WATER FILL PIPE(ON RAD.INLET)	TATA spare parts
278650115821	HOSE(ON RAD.INLET)	TATA spare parts
278650115825	HOSE PIPE TO WATER PUMP	TATA spare parts
278650115828	REDUCER HOSE (28.6 TO 20 DIA)	TATA spare parts
278650115836	RUBBER HOSE (OD 14X ID 6X 620L)	TATA spare parts
278650115840	RUBBER HOSE	TATA spare parts
278650115841	HOSE (RADIATOR TO ENGINE)	TATA spare parts
278650115842	HOSE-WATER FILL PIPE(ON RAD.INLET)	TATA spare parts
278650115844	HOSE (RADIATOR TO ENGINE)	TATA spare parts
278650115844AE	HOSE (RAD TO ENG)LPT 2523/	TATA spare parts
278650115846	HOSE (RADIATOR INLET)	TATA spare parts
278650115847	RUBBER HOSE(WATER FILL PIPE TO AUX TANK)	TATA spare parts
278650115849	HOSE(HEAT EXCHAGER PIPE)	TATA spare parts

278650115852	RUBBER HOSE(VENT-720MM LONG)	TATA spare parts
278650115853	RUBBER HOSE(VENT-1000MM LONG)	TATA spare parts
278650115859	RAD. BOTTOM HOSE	TATA spare parts
278650115860	RUBBER HOSE (28.6 TO 20 DIA)	TATA spare parts
278650115862	RUBBER HOSE	TATA spare parts
278650115863	HOSE	TATA spare parts
278650115864	HOSE	TATA spare parts
278650115871	REDUCER HOSE (ID28.6 TO ID20)	TATA spare parts
278650115873	HOSE (RAD TO ENG)	TATA spare parts
278650115874	HOSE (RAD TO ENG) LPO1925	TATA spare parts
278650115876	REDUCER HOSE(ENG TO RAD)	TATA spare parts
278650115877	HOSE	TATA spare parts
278650115878	HOSE (28.6IDX100 LONG)	TATA spare parts
278650115885	HOSE(RAD TO WATER PUMP)	TATA spare parts
278650115890	HOSE (RAD. TO WATER PUMP)	TATA spare parts
278650115892	HOSE (ID6 X 780L)	TATA spare parts
278650115895	VENT HOSE (645L)	TATA spare parts
278650115896	VENT HOSE (1060L)	TATA spare parts
278650116906	WATER FILL PIPE	TATA spare parts
278650116907	WATER FILL PIPE	TATA spare parts
278650116910	VENT TUBE	TATA spare parts
278650116911	VENT TUBE(ENG.TO AUX.TANK)	TATA spare parts
278650116913	PIPE-ENGINE OUTLET TO RADIATOR INLET	TATA spare parts
278650116915	VENT TUBE(RAD.TO AUX TANK)	TATA spare parts
278650116917	VENT TUBE-10 O.D.X 0.7 THK.BUNDY TUBE	TATA spare parts
278650116918	VENT TUBE-10 O.D.X 0.7 THK.BUNDY TUBE	TATA spare parts
278650116923	WATER FILL PIPE-28.6 O.D.X 1.22 THK	TATA spare parts
278650116924	VENT TUBE-FROM RADIATOR TO AUX.W.TANK	TATA spare parts
278650116925	VENT TUBE	TATA spare parts
278650116927	PIPE(ENG TO RAD) LPT 2515 TC BS-2	TATA spare parts
278650116928	WATER FILL PIPE(ON AUX.TANK)	TATA spare parts
278650116929	WATER FILL PIPE(ON RADIATOR)	TATA spare parts
278650116939	PIPE(ENG TO RAD)	TATA spare parts
278650116947	VENT TUBE(ENG TO RAD)	TATA spare parts
278650116950	WATER FILLER PIPE	TATA spare parts
278650116951	PIPE ENGINE TO RAD.	TATA spare parts
278650116953	VENT TUBE(RAD. TO AUX. TANK) LPS3516BS-2	TATA spare parts
278650116954	VENT TUBE(ENG. TO AUX. TANK) LPS3516BS-2	TATA spare parts
278650116956	WATER FILL PIPE.	TATA spare parts
278650116957	VENT TUBE(RAD.TO AUX.TANK)	TATA spare parts
278650116959	VENT TUBE(ENG.TO AUX.TANK)	TATA spare parts
278650116961	VENT TUBE(ENG TO AUX.TANK)	TATA spare parts
278650116962	VENT TUBE (RAD TO AUX.TANK)	TATA spare parts
278650116963	WATER FILL PIPE	TATA spare parts
278650116965	PIPE -ON RAD. BOTTOM	TATA spare parts
278650116968	VENT TUBE (RAD. TO AUX. TANK)	TATA spare parts
278650116970	PIPE (ENG TO RAD)	TATA spare parts

278650116971	VENT TUBE ( ENG. TO AUX. TANK)	TATA spare parts
278650116972	PIPE(ENG TO RAD)	TATA spare parts
278650116978	ASSY. PIPE	TATA spare parts
278650116980	PIPE (ENG TO RAD)	TATA spare parts
278650116982	WATER FILL PIPE.	TATA spare parts
278650116983	VENT TUBE ENG TO AUX WATER TANK	TATA spare parts
278650116984	VENT TUBE RAD AUX WATER TANK	TATA spare parts
278650116998	VENT TUBE(RADIATOR TO AUX.WATER TANK)	TATA spare parts
278650120105	SET COOLING SYS LPT3118 BS3 COWL/STRAIGH	TATA spare parts
278650120106	SET-COOLING SYSTEM	TATA spare parts
278650120109	RADIATOR WATER FILL	TATA spare parts
278650120111	ASSY. RADIATOR WITH INTERCOOLER BS1/3	TATA spare parts
278650120112	ASSY. RADIATOR WITH INTERCOOLER BS1/3	TATA spare parts
278650120114	SET COOLING PACAKGE LPT3118 BS3	TATA spare parts
278650120117	KIT COOLING SYS LPT2518 BS3	TATA spare parts
278650120124	SET-COOLING SYSTEM	TATA spare parts
278650120128	SET COOLING SYSTEM LPS 4018TC BS3	TATA spare parts
278650120130	ASSY. RADIATOR 6BT BS3	TATA spare parts
278650120141	ASSY. RADIATOR WITH INTERCOOLER BS1/3	TATA spare parts
278650120142	PIPE ASSY.CRIMPED	TATA spare parts
278650120143	COOLING SYSTEM	TATA spare parts
278650120160	ENGINE COOLING SYSTEM(1623-EIII-T.CAB)	TATA spare parts
278650120170	COOLING SYSTEM KIT	TATA spare parts
278650120171	KIT-ENGINE COOLING SYSTEM BS3	TATA spare parts
278650120185	WATER FILLER PIPE ASSY	TATA spare parts
278650120186	ASSY COOLING SYSTEM BS3/4	TATA spare parts
278650120187	COOLING SYSTEM ASSY	TATA spare parts
278650120193	COOLING SYSTEM ASSY	TATA spare parts
278650120194	COOLING SYSTEM ASSY	TATA spare parts
278650120195	COOLING SYSTEM ASSY	TATA spare parts
278650120198	ENGINE COOLING SYSTEM	TATA spare parts
278650120199	ENGINE COOLING SYSTEM BS1/3/4	TATA spare parts
278650120230	ENGINE COOLING SYSTEM BS4	TATA spare parts
278650120231	ASSY. RADIATOR BS4	TATA spare parts
278650120232	PIPE ASSY	TATA spare parts
278650120239	ASSY. COOLING SYSTEM BS4	TATA spare parts
278650120240	ASSY. COOLING SYSTEM BS4	TATA spare parts
278650120250	SET-COOLING SYSETM ISBE5.9 BS4	TATA spare parts
278650120251	ASSY. RADIATOR W/FRAME BS4	TATA spare parts
278650120252	FILLER PIPE RADIATOR TO WATER PUMP	TATA spare parts
278650120253	SET-COOLING SYSTEM BS4	TATA spare parts
278650120256	ASSY. RADIATOR BS4	TATA spare parts
278650120257	BRACKET ASSY	TATA spare parts
278650120258	BRACKET ASSY	TATA spare parts
278650120260	ENGINE COOLING SYSTEM BS4	TATA spare parts
278650120261	ASSY. RADIATOR BS4	TATA spare parts
278650120263	ENGINE COOLING SYSTEM BS4	TATA spare parts

278650120264	FILLER PIPE ASSY	TATA spare parts
278650120266	KIT-ENGINE COOLING SYSTEM	TATA spare parts
278650120267	RADIATOR ASSY	TATA spare parts
278650120268	COOLING SYSTEM	TATA spare parts
278650120270	RADIATOR ASSY	TATA spare parts
278650120285	COOLING SYSTEM	TATA spare parts
278650120287	RADIATOR ASSY	TATA spare parts
278650120288	COOLING SYSTEM	TATA spare parts
278650120290	RADIATOR ASSY	TATA spare parts
278650120295	PIPE ASSY	TATA spare parts
278650120296	ASSY. RADIATOR BS4	TATA spare parts
278650120297	FILLER PIPE HOSE	TATA spare parts
278650120299	BRACKET ASSY	TATA spare parts
278650120313	RESERVE TANK ASSY	TATA spare parts
278650120315	ENG.COOLING SYSTEM LPT3721 BS3 COWL	TATA spare parts
278650120325	SET 6LDAT+REDUCER HOSE BS2/3/4	TATA spare parts
278650120330	ASSY. RADIATOR BS3	TATA spare parts
278650120330DF	RADIATOR ASSY-LP1515-LPT1615/2518/3118	TATA spare parts
278650120332	ASSY. AUXILIARY WATER TANK BLACK BS1/3/4	TATA spare parts
278650120336	ASSY RESERVE TANK	TATA spare parts
278650120337	ASSY.RADIATOR	TATA spare parts
278650120338	ASSY.RADIATOR-FRAMELESS	TATA spare parts
278650120345	ASSY.AUX.WATER LPT2518TC	TATA spare parts
278650120346	AUXILIARY WATER TANK ASSY	TATA spare parts
278650120347	AUXILIARY WATER TANK ASSY	TATA spare parts
278650120350	ASSY. RADIATOR BS1/3	TATA spare parts
278650120351	ASSY. RADIATOR BS1/3	TATA spare parts
278650120352	ASSY. RESERVE TANK BS3/4/6	TATA spare parts
278650120361	ASSY. RADIATOR BS1/3/4	TATA spare parts
278650120365	ASSY. COOLING SYSTEM BS4	TATA spare parts
278650120367	COOLING SYSTEM ASSY	TATA spare parts
278650120368	ASSY. RADIATOR BS4	TATA spare parts
278650120370	COOLING SYSTEM	TATA spare parts
278650120371	RADIATOR ASSY	TATA spare parts
278650120373	COOLING SYSTEM	TATA spare parts
278650120376	ASSY. RADIATOR BS3/4	TATA spare parts
278650120377	ENGINE COOLING SYSTEM BS3	TATA spare parts
278650120382	SET-ENGINE COOLING SYSETM	TATA spare parts
278650120384	RADIATOR ASSY	TATA spare parts
278650120385	CRIMP WATER FILLER PIPE ASSY	TATA spare parts
278650120398	SET-COOLING SYSETM ISBE5.9 BS4	TATA spare parts
278650125812	HOSE-FILL PIPE TOP	TATA spare parts
278650125813	HOSE (ENGINE TO RAD)	TATA spare parts
278650125817	HOSE (RAD TO ENG)	TATA spare parts
278650125818	HOSE RAD BOTTOM	TATA spare parts
278650125819	HOSE WATER FILL	TATA spare parts
278650125823	HOSE RADIATOR BOTTOM TANK TO ENGINE	TATA spare parts



278650125827	HOSE	TATA spare parts
278650125828	VENT HOSE	TATA spare parts
278650125830	HOSE RADIATOR BOTTOM TANK TO ENGINE	TATA spare parts
278650125831	HOSE RADIATOR TO ENGINE INTAKE	TATA spare parts
278650125837	HOSE	TATA spare parts
278650125841	HOSE RADIATOR BOTTOM TANK TO ENGINE	TATA spare parts
278650125846	HOSE	TATA spare parts
278650125855	HOSE ASSY RADIATOR TO WATER PUMP	TATA spare parts
278650125861	REDUCER HOSE	TATA spare parts
278650125865	HOSE	TATA spare parts
278650125866	HOSE RADIATOR TANK LOWER	TATA spare parts
278650125867	HOSE	TATA spare parts
278650125868	HOSE	TATA spare parts
278650125871	HOSE	TATA spare parts
278650125872	HOSE RADIATOR BOTTOM TANK TO ENGINE	TATA spare parts
278650125875	RUBBER HOSE	TATA spare parts
278650126903	WATER FILL PIPE(ON AUX.WATER TANK)	TATA spare parts
278650126907	VENT TUBE(ENG TO PLASTIC AUX.WATER TANK)	TATA spare parts
278650126909	PIPE(ENG TO RADIATOR)	TATA spare parts
278650126921	PIPE (ENGINE TO RADIATOR)	TATA spare parts
278650126927	WATER FILL PIPE(LPT3118TC-CAB)	TATA spare parts
278650126928	WATER FILL PIPE(LPT3118TC-CAB)	TATA spare parts
278650126929	WATER FILL PIPE(LPT3118TC-CAB)	TATA spare parts
278650126936	VENT TUBE (RAD. TO AUX. TANK)	TATA spare parts
278650126937	VENT TUBE (ENG. TO AUX. TANK)	TATA spare parts
278650126938	VENT TUBE (ENGINE TO AUX. WATER TANK)	TATA spare parts
278650126942	PIPE (ENG TO RADIATOR)	TATA spare parts
278650126944	PIPE (ENG TO RADIATOR UPPER SIDE)	TATA spare parts
278650126945	PIPE (RAD TO WATER INLET)(M0)	TATA spare parts
278650126946	VENT TUBE (RAD TO AUX TANK)DIA.6.0(M0)	TATA spare parts
278650126947	VENT TUBE (AUX TANK TO ENG)DIA.6.0	TATA spare parts
278650126950	PIPE	TATA spare parts
278650126952	WATER FILL PIPE	TATA spare parts
278650126965	PIPE ENG TO RAD	TATA spare parts
278650126968	WATER FILLER PIPE	TATA spare parts
278650126998	PIPE WATER FILL	TATA spare parts
278650130101	DEAERATION TANK ASSY	TATA spare parts
278650130151	SET-COOLING SYSTEM BS4	TATA spare parts
278650130154	ASSY. RADIATOR BS4	TATA spare parts
278650130156	AUX WATER TANK ASSY	TATA spare parts
278650130157	FILLER PIPE	TATA spare parts
278650130158	COOLING SYSTEM	TATA spare parts
278650130168	ASSY. RADIATOR BS4	TATA spare parts
278650130170	ENGINE COOLING SYSTEM BS4	TATA spare parts
278650130171	RADIATOR ASSY	TATA spare parts
278650130173	COOLING SYSTEM	TATA spare parts
278650130177	ENGINE COOLING SYSTEM	TATA spare parts

278650130178	ENGINE COOLING SYSTEM	TATA spare parts
278650130180	SET-COOLING SYSTEM	TATA spare parts
278650130190	RADIATOR ASSY	TATA spare parts
278650136904	PIPE(TC TO IC)	TATA spare parts
278650136905	PIPE(IC TO ENGINE)	TATA spare parts
278650136906	WATER FILL PIPE (DA TANK END)	TATA spare parts
278650136907	WATER FILL PIPE (RH MIDDLE PIECE)	TATA spare parts
278650136908	TUBE VENT (ENG TO AUX WATER TANK)	TATA spare parts
278650136909	TUBE VENT (DA TANK TO RADIATOR)	TATA spare parts
278650136913	WATER FILLER PIPE	TATA spare parts
278650136914	VENT PIPE AUX WATER TANK TO RADIATOR	TATA spare parts
278650136915	VENT PIPE AUX WATER TANK TO ENGINE	TATA spare parts
278650136918	VENT TUBE	TATA spare parts
278650136919	VENT TUBE	TATA spare parts
278650136920	PIPE (RAD TO ENG)	TATA spare parts
278650136931	PIPE RADIATOR BOTTOM	TATA spare parts
278650136941	PIPE ENGINE TO RADIATOR	TATA spare parts
278650136942	FILLER PIPE AUX WATER TANK TO RADIATOR	TATA spare parts
278650136943	FILLER PIPE AUX WATER TANK TO RADIATOR	TATA spare parts
278650136944	PIPE ENGINE TO RADIATOR	TATA spare parts
278650136947	PIPE RADIATOR BOTTOM	TATA spare parts
278650136948	FILLER PIPE AUXbs	TATA spare parts
278650400103	BRACKET ASSY LH	TATA spare parts
278650400104	BRACKET ASSY RH	TATA spare parts
278650400111	STUD ASSY RADIATOR MOUNTING	TATA spare parts
278650400117	RUBBER BUSH ASSY	TATA spare parts
278650400121	STUD ASSY RADIATOR MTG	TATA spare parts
278650400124	BRACKET TOP	TATA spare parts
278650400126	BRACKET BOTTOM	TATA spare parts
278650400137	BRACKET ASSY RADIATOR FRAME MTG RH	TATA spare parts
278650400138	BRACKET ASSY RADIATOR FRAME MTG LH	TATA spare parts
278650400139	BRACKET ASSY RADIATOR MTG BOTTOM-RH	TATA spare parts
278650400140	BRACKET ASSY,RADIATOR MTG,BOTTOM-LH	TATA spare parts
278650400141	STUD ASSY RADIATOR MTG	TATA spare parts
278650400144	CLAMP ASSY	TATA spare parts
278650400149	BRACKET ASSY	TATA spare parts
278650400150	BRACKET ASSY	TATA spare parts
278650400151	RUBBER BUFFER ASSY RADIATOR MTG SUPPORT	TATA spare parts
278650400161	BRACKET ASSY	TATA spare parts
278650400162	BRACKET	TATA spare parts
278650400167	BRACKET ASSY RADIATOR MTG BOTTOM-RH	TATA spare parts
278650400168	BRACKET ASSY RADIATOR MTG BOTTOM-LH	TATA spare parts
278650403215	BOLT ASSY	TATA spare parts
278650403216	BOLT ASSY	TATA spare parts
278650403217	BRACKET ASSY	TATA spare parts
278650403218	BOLT ASSY	TATA spare parts
278650403305	BRACKET RADIATOR MTG RH TOP	TATA spare parts

278650403306	BRACKET RADIATOR MTG LH TOP	TATA spare parts
278650403320	BRACKET LH	TATA spare parts
278650403321	BRACKET RH	TATA spare parts
278650404201	CLAMP (FOR 20 MM OD	TATA spare parts
278650406903	TUBE SPACER	TATA spare parts
278650406904	SPACER TUBE (32.5 LONG)	TATA spare parts
278650406905	SPACER TUBE-63 LONG	TATA spare parts
278650406906	SPACER TUBE 220 LONG	TATA spare parts
278650500101	FAN SHROUD ASSY	TATA spare parts
278650500102	FAN SHROUD ASSY	TATA spare parts
278650500103	FAN SHROUD ASSY	TATA spare parts
278650500109	FAN SHROUD ASSY LP1312	TATA spare parts
278650500110	FAN SHROUD ASSY 22 FAN	TATA spare parts
278650500113	ASSY FAN SHROUD-22INCH FAN	TATA spare parts
278650500115	ASSY FAN SHROUD	TATA spare parts
278650500120	ASSY FAN SHROUD-LPT 2516TC-4PT ENG MTG	TATA spare parts
278650500121	FAN SHROUD LPK 2516TC	TATA spare parts
278650500122	ASSY FAN SHROUD	TATA spare parts
278650500123	ASSY. FAN SHROUD	TATA spare parts
278650504201	HOSE CLAMP(560 ID)	TATA spare parts
278650504202	HOSE CLAMP(FAN RING)-CLAMP DIA 678 MAX	TATA spare parts
278650504204	CLAMP HOSE	TATA spare parts
278650506315	FAN SHROUD(LPT2518TC-1210 FACE)	TATA spare parts
278650506316	FAN SHROUD 3015/2515 EII COWL	TATA spare parts
278650506317	FAN SHROUD(LP1512TC E3)	TATA spare parts
278650506323	FAN SHROUD(LPS4923TC)	TATA spare parts
278650506324	ASSY. FAN SHROUD	TATA spare parts
278650506333	FAN SHROUD	TATA spare parts
278650506340	FAN SHROUD 1510CNG	TATA spare parts
278650506344	FAN SHROUD LPT/LPK 1615TC	TATA spare parts
278650506346	FAN SHROUD 4PT. ENG. MTG-LPS 3521 TC	TATA spare parts
278650506348	FAN SHROUD-LPS 3015/LPT 2515	TATA spare parts
278650506350	FAN SHROUD	TATA spare parts
278650506351	JET RING FAN SHROUD 24 INCH	TATA spare parts
278650506352	FAN SHROUD-LPS3015TC/LPT2515TC	TATA spare parts
278650506354	FAN SHROUD	TATA spare parts
278650506358	FAN SHROUD-FOR 560 MM CORE	TATA spare parts
278650506359	FAN SHROUD (FOR 20 INCH FAN & WITH CUTOU	TATA spare parts
278650506361	FAN SHROUD(LPT 1615 (ARMY)	TATA spare parts
278650506363	FAN SHROUD-FRP LPO 1615RE	TATA spare parts
278650506364	ASSY FAN SHROUD (LPT 2516)80 MM LIFTED.	TATA spare parts
278650506365	FAN SHROUD LPS3015TC-S.PROP SHAFT	TATA spare parts
278650506366	FAN SHROUD LP1512-FRAME 75MM-TRS TANK	TATA spare parts
278650506367	FAN SHROUD LPT2525-FRAME 75MM TRNS TANK	TATA spare parts
278650506369	FAN SHROUD(LPT1613 EUROII SLPR TILT CAB)	TATA spare parts
278650506371	FAN SHROUD(LPT1418)	TATA spare parts
278650506373	FAN SHROUD	TATA spare parts

278650506376	FAN SHROUD(100MM WIDTH)	TATA spare parts
278650506378	FAN SHROUD	TATA spare parts
278650506381	FAN SHROUD	TATA spare parts
278650506384	FAN SHROUD	TATA spare parts
278650506389	JET RING FAN SHROUD	TATA spare parts
278650506390	FAN SHROUD(FOR JET RING FAN)	TATA spare parts
278650506391	FAN SHROUD(LPS4021)(M0)	TATA spare parts
278650506392	FAN SHROUD (FOR 22INC JET RING FAN)	TATA spare parts
278650506394	FAN SHROUD(FOR1613 COWL)	TATA spare parts
278650506397	JET RING FAN SHROUD (DIA22IN)	TATA spare parts
278650507720	RUBBER FLAP	TATA spare parts
278650507721	RUBBER RING (BETWEEN SHROUD TO FAN RING)	TATA spare parts
278650507722	RUBBER RING(BETWEEN SHROUD AND FAN RING)	TATA spare parts
278650507723	RUBBER RING(BETWEEN SHROUD & FAN RING)	TATA spare parts
278650507724	RUBBER RING.	TATA spare parts
278650507725	RUBBER RING(125MM)	TATA spare parts
278650516301	FAN SHROUD (LPT2518TC BS3 VA/VE)	TATA spare parts
278650516302	FAN SHROUD	TATA spare parts
278650516304	FAN SHROUD (LPT3721)	TATA spare parts
278650516308	FAN SHROUD	TATA spare parts
278650516310	FAN SHROUD-LPT2518COWL-BANCO	TATA spare parts
278650516312	FAN SHROUD	TATA spare parts
278650516315	FAN SHROUD LPT2518TC BS3	TATA spare parts
278650516318	FAN SHROUD RING TYPE	TATA spare parts
278650516320	FAN SHROUD LPS4018TC BS1/3	TATA spare parts
278650516331	FAN SHROUD	TATA spare parts
278650516332	FAN SHROUD	TATA spare parts
278650516335	FAN SHROUD	TATA spare parts
278650516336	FAN SHROUD LPS 4923	TATA spare parts
278650516338	FAN SHROUD	TATA spare parts
278650516355	FAN SHROUD	TATA spare parts
278650516358	FAN SHROUD	TATA spare parts
278650516359	FAN SHROUD	TATA spare parts
278650516360	FAN SHROUD	TATA spare parts
278650516361	FAN SHROUD	TATA spare parts
278650516362	FAN SHROUD	TATA spare parts
278650516369	FAN SHROUD	TATA spare parts
278650516372	FAN SHROUD	TATA spare parts
278650516373	FAN SHROUD	TATA spare parts
278650516374	FAN SHROUD	TATA spare parts
278650999901	HOSE GATES ID 7.9MM X 116 INCH LONG	TATA spare parts
278650999902	HOSE COOLANT ID 7.9 X 130 INCH LONG	TATA spare parts
278650999903	HOSE COOLANT ID 7.9 X 173INCH LONG	TATA spare parts
278650999904	HOSE GATES ID 7.9MM X 173 INCH LONG	TATA spare parts
27865890091M	STAND ENGINE REPAIR-6BTAA	TATA spare parts
278681800101	ASSY MASCOT 3516 TC	TATA spare parts
278701000101	ENG ASSY 6CTAA-300HP-24V-LMFO-E-II	TATA spare parts

278709135809	RUBBER HOSE AIR INTAKE PIPE TO TC	TATA spare parts
278709135809AE	RBBR HSE(AIR IN PIPE TO TC)-1628	TATA spare parts
278709139201	SEALING WASHER	TATA spare parts
278714605801	HUMP HOSE(101 ID)	TATA spare parts
278714605803	HOSE HUMP	TATA spare parts
27876	DIFF BRG CONE RH	TATA spare parts
278800000107	ENGINE (BIGGER AIR FILTER) W/O CLUTCH	TATA spare parts
278800000126	ENGINE ASSY W/O CLUTCH	TATA spare parts
278800000129	ENGINE ASSY	TATA spare parts
278800000133	ENGINE ASSY/275 IDI NA BS IV ENGINE	TATA spare parts
278800000137	ENGINE ASSEMBLY	TATA spare parts
278800000140	ENGINE ASSY W/O CLUTCH	TATA spare parts
278800000141	275 IDI ENGINE ASSY W/O CLUTCH	TATA spare parts
278801000101	ASSY.ENGINE COMPLETE WITH CLUTCH BSII	TATA spare parts
278801000102	ASSY ENGINE COMPLETE WITH CLUTCH(BS III)	TATA spare parts
278801000104	ASSY.ENGINE COMPLETE(BS-II) WITH CLUTCH	TATA spare parts
278801000105	ASSY.ENGINE COMPLETE(BS-III) WITH CLUTCH	TATA spare parts
278801000107	ASSY. ENGINE COMPLETE WITH CLUTCH	TATA spare parts
278801000108	ASSY. ENGINE COMP. W/CLUTCH BS3	TATA spare parts
278801000111	ASSY. ENGINE COMP.WITH CLUTCH 275IDI BS2	TATA spare parts
278801000112	ASSY. ENGINE COMP. W/CLUTCH BS2/3	TATA spare parts
278801000113	ENGINE COMPL.WITH CLUTCH (ELECTRONIC STA	TATA spare parts
278801000114	ASSY. ENGINE COMPLETE WITH CLUTCH (ELECT	TATA spare parts
278801000119	ENGINE 275 IDI ENGINE BS-IV COMP. WITH C	TATA spare parts
278801000120	ENGINE 275 IDI ENGINE BS-IV COMP. WITH C	TATA spare parts
278801000121	ASSY 275 IDI BSIV ENG COMP. WITH CLUTCH	TATA spare parts
278801000123	ASSY.ENGINE COMPLETE WITH CLUTCH BS-II	TATA spare parts
278801000124	ASSY. ENG EX BSIV WITH CLUTCH (W/O ESS)	TATA spare parts
278801000125	ENGINE 275 IDI EX COMPLETE BS-III W/O EL	TATA spare parts
278801000126	ASSY. ENGINE WITH CLUTCH	TATA spare parts
278801000127	ENGINE ASSY COMPL WITH CLUTCH	TATA spare parts
278801000128	ENGINE ASSY WITH CLUTCH	TATA spare parts
278801000130	ENGINE ASSY WITH CLUTCH	TATA spare parts
278801100101	ASSY.CYLINDER CRANKCASE (BSII & BSIII)	TATA spare parts
278801100102	ASSY. CYLINDER CRANKCASE BS2/3/4	TATA spare parts
278801100110	ASSY CYLINDER CRANKCASE (BS-IV)	TATA spare parts
278801130103	ASSY. OIL SUMP COMPLETE	TATA spare parts
278801130105	ASSY OIL SUMP COMPLETE (CORK GASKET)	TATA spare parts
278801130109	OIL SUMP ASSY WITH DRAIN PLUG	TATA spare parts
278801130111	OIL SUMP ASSY WITH DRAIN PLUG	TATA spare parts
278801135301	OIL SUMP GASKET	TATA spare parts
278801135303	OIL SUMP GASKET	TATA spare parts
278801135304	GASKET-OIL SUMP BS2/3/4/6	TATA spare parts
278801140102	ASSY. COVER (TIMING BELT - FRONT)	TATA spare parts
278801143801	COVER CRANKCASE REAR	TATA spare parts
278801150101	ASSY.CYLINDER HEAD WITH VALVES & NOZZLE.	TATA spare parts
278801150102	ASSY. CYLINDER HEAD W/O VALVES BS2/3/4	TATA spare parts

278801150103	ASSY.CYL.HD.COVER WITH T.COVER & GASKET	TATA spare parts
278801150104	ASSY. CYLINDER HEAD COVER COMP. BS2/3/4	TATA spare parts
278801150108	ASSY. PRE.COMBUSTION CHAMBER WITH BALL	TATA spare parts
278801150109	ASSY CYLINDER HEAD COVER COMPLETE	TATA spare parts
278801150110	ASSY CYL HEAD W/ VALVES & NOZZLE BSIII	TATA spare parts
278801150125	COVER ASSY CYL HEAD WITH GASKET	TATA spare parts
278801155301	GASKET CYL HEAD 1.6THK	TATA spare parts
278801155302	GASKET CYL HEAD 1.7THK BS2/3/4	TATA spare parts
278801155303	GASKET CYLINDER HEAD 1.8MM BS2/3/4	TATA spare parts
278801155304	GASKET CYL. HEAD COVER BS2/3/4	TATA spare parts
278801155305	GASKET BAFFLE-CYL HEAD COVER	TATA spare parts
278801155306	GASKET BAFFLE (CYL. HEAD COVER)	TATA spare parts
278801155307	GASKET CYL HEAD 1.6THK	TATA spare parts
278801155308	GASKET CYL HEAD 1.7THK	TATA spare parts
278801155309	GASKET CYL HEAD 1.8THK	TATA spare parts
278801155310	GASKET BAFFLE CYL. HEAD COVER	TATA spare parts
278801155311	GASKET CYL HEAD 1.6THK	TATA spare parts
278801155312	GASKET CYL HEAD 1.7THK	TATA spare parts
278801155313	GASKET CYL HEAD 1.8THK	TATA spare parts
278801155318	GASKET - CYLINDER HEAD (MLS)(1.6 THK.)	TATA spare parts
278801155319	GASKET CYL. HEAD (MLS)(1.7 THK.) BS4	TATA spare parts
278801155320	GASKET-CYLINDER HEAD (MLS)(1.8 THK.) BS4	TATA spare parts
278801160101	ASSY INJ WITH NOZZLE HOLDER	TATA spare parts
278801160102	ASSY INJ WITH NOZZLE HOLDER	TATA spare parts
278801170101	ASSY DIPSTICK TUBE	TATA spare parts
278801170102	ASSY. DIPSTICK	TATA spare parts
278801170105	OIL RETURN TUBE ASSY	TATA spare parts
278801170106	BRACKET ASSY OIL SEPARATOR MTG	TATA spare parts
278801170117	RETURN PIPE ASSY OIL SEPARATOR	TATA spare parts
278801170119	OIL MIST SEPARATOR ASSY	TATA spare parts
278801175803	HOSE BLOWBY	TATA spare parts
278801175804	RUBBER HOSE	TATA spare parts
278801175818	HOSE BLOWBY	TATA spare parts
278801175819	RUBBER HOSE	TATA spare parts
278801175820	RUBBER HOSE	TATA spare parts
278801176901	DIPSTICKTUBE BS6	TATA spare parts
278801178207	BRACKET	TATA spare parts
278801990101	KIT-ENGINE OVERHAUL GASKET+SEAL BS2/3/4	TATA spare parts
278801990102	ENG.O/H GASKET SUB-KIT (BS-II) W/- 1.6 T	TATA spare parts
278801990103	SUB KIT-SEAL ENG.OVERHAUL BS2/4	TATA spare parts
278801990105	ASSY. LONG BLOCK - ACE BS2/3	TATA spare parts
278801990106	HALF BLOCK(BSII) W/O CYL.HD&CYL.HD COVER	TATA spare parts
278801990108	SET INLET AND EXHAUST VALVE BS2/3/4	TATA spare parts
278801990108DF	VALVE SET W/SEAT STD - ACE BS2/3	TATA spare parts
278801990109	ASSY. CYL HEAD W/VALVES W/O INJ. BS2/3/4	TATA spare parts
278801990114	ENG.OVERHAUL GASKET+SEAL KIT (BS-II)	TATA spare parts
278801990115	ASSY. HALF BLOCK BS-II/III	TATA spare parts

278801990116	ASSY. LONG BLOCK 275 IDI BS2/3	TATA spare parts
278801990117	ENG.OVERHAUL GASKET SUB-KIT (BS-II)	TATA spare parts
278801990125	HALF BLOCK W/O CYL.HD & CYL.HD COVER BS-	TATA spare parts
278801990127	ASSY. BARE ENGINE 275IDI BS4	TATA spare parts
278801990131	ASSY. LONG BLOCK 275IDI BS3	TATA spare parts
278801990133	ASSY. LONG BLOCK 275IDI BS4	TATA spare parts
278801990136	HALF BLOCK ASSY - BS IV	TATA spare parts
278801990139	HALF BLOCK ASSY - BS II & BS III	TATA spare parts
278801990141	BARE ENGINE ASSY	TATA spare parts
278801990142	KIT-OMS ASSY WITH HOSES & BRACKET	TATA spare parts
278803100108	ASSY. CRANKSHAFT W/PIN NORMAL BS2/3/4	TATA spare parts
278803100136	CRANKSHAFT ASSY WITH PIN & CW	TATA spare parts
278803100144	CRANKSHAFT ASSY WITH PIN & CW	TATA spare parts
278803110101	ASSY. FLYWHEEL W/RING GEAR & DWL BS2/3/4	TATA spare parts
278803110103	FLYWHEEL ASSY WITH RING GEAR & DOWEL	TATA spare parts
278803114801	DOWEL PIN (FOR FLYWHEEL) BS6	TATA spare parts
278803138201	PULLEY CRANKSHAFT	TATA spare parts
278803140105	ASSY.PISTON GRADE A (74.940DIA)	TATA spare parts
278803140118	PISTON ASSY GRADE A	TATA spare parts
278803150104	ASSY. CONNECTING ROD	TATA spare parts
278803153102	BEARING HALF	TATA spare parts
278803990102	SET-MAIN BRG HALF(UPP/LOW)NORMAL BS2/3/4	TATA spare parts
278803990102DF	MAIN BEARING SET STD - 275IDI ACE/MAGIC	TATA spare parts
278803990102DFR3	MAIN BEARING SET RS3 - 275IDI ACE/MAGIC	TATA spare parts
278803990102DFR4	MAIN BEARING SET RS4 - 275IDI ACE/MAGIC	TATA spare parts
278803990103	SET THRUST WASHER(KOEL) BS6	TATA spare parts
278803990104	SET-THRUST WASHER(BIMETAL) BS1/2/3/4/6	TATA spare parts
278803990104DF	THRUST WASHER SET STD - ACE/SUPER ACE	TATA spare parts
278803990104DFR1	THRUST WASHER SET RS1 - ACE/SUPER ACE	TATA spare parts
278803990104DFR2	THRUST WASHER SET RS2 - ACE/SUPER ACE	TATA spare parts
278803990104DFR3	THRUST WASHER SET RS3 - ACE/SUPER ACE	TATA spare parts
278803990110	SET-PISTON W/O RINGS GRADE-A BS2/3/4	TATA spare parts
278803990113	SET-PISTON RINGS BS2/3/4	TATA spare parts
278803990113DF	PISTON RING SET - 275IDI ACE/MAGIC BS3	TATA spare parts
278803990118	SET-CON. ROD BUSH(BIMETAL) BS2/3/4	TATA spare parts
278803990118DF	CON ROD BUSH SET - 275IDI ACE/MAGIC	TATA spare parts
278803990118DFR1	CON ROD BUSH SET RS1 - 275IDI ACE/MAGIC	TATA spare parts
278803990118DFR2	CON ROD BUSH SET RS2 - 275IDI ACE/MAGIC	TATA spare parts
278803990118DFR3	CON ROD BUSH SET RS3 - 275IDI ACE/MAGIC	TATA spare parts
278803990118DFR4	CON ROD BUSH SET RS4 - 275IDI ACE/MAGIC	TATA spare parts
278803990120	SET-BRG HALF CON.ROD NORMAL BS2/3/4	TATA spare parts
278803990120DF	CON ROD BEARING SET - 275IDI ACE/MAGIC	TATA spare parts
278803990120DFR3	CON ROD BEARING SET RS3-275IDI ACE/MAGIC	TATA spare parts
278803990120DFR4	CON ROD BEARING SET RS4-275IDI ACE/MAGIC	TATA spare parts
278803990121	SET-BRG.HALF R-I (CON.ROD) BS2/3/4	TATA spare parts
278803990121DF	CON ROD BEARING SET RS1-275IDI ACE/MAGIC	TATA spare parts
278803990122	SET-BRG.HALF R-II (CON.ROD) BS2/3/4	TATA spare parts

278803990122DF	CON ROD BEARING SET RS2-275IDI ACE/MAGIC	TATA spare parts
278803990123	SET MAIN BRG.HALF RS-I (C/SHAFT) BS2/3/4	TATA spare parts
278803990123DF	MAIN BEARING SET RS1 - 275IDI ACE/MAGIC	TATA spare parts
278803990124	SET-MAIN BRG.HALF R-II (CR.SHAFT)BS2/3/4	TATA spare parts
278803990124DF	MAIN BEARING SET RS2 - 275IDI ACE/MAGIC	TATA spare parts
278803990125	SET BRG.HALF R-I (CON.ROD)	TATA spare parts
278803990126	SET BRG.HALF R-II (CON.ROD)	TATA spare parts
278803990129	SET- CON ROD BEARING - STD	TATA spare parts
278803990131	SET- CON ROD BEARING - REPAIR I	TATA spare parts
278803990132	SET- CON ROD BEARING - REPAIR II	TATA spare parts
27880510410120	S/F CAM SHAFT BEARING CAP NO 1	TATA spare parts
27880510410220	S/F CAM SHAFT BEARING CAP NO 2	TATA spare parts
278805107801	OIL SEAL (CAMSHAFT-FRONT)	TATA spare parts
278805107902	CAMSHAFT (CRANKSHAFT 180 DEG) BS2/3/4	TATA spare parts
278805110101	IDLER&ASSY&TIMING&BELT	TATA spare parts
278805110105	IDLER ASSY BS6	TATA spare parts
278807100101	ASSY. DISTRIBUTOR PUMP BS2	TATA spare parts
278807100102	ASSY. DISTRIBUTOR PUMP BSII	TATA spare parts
278807100103	ASSY. DISTRIBUTOR PUMP BS-III	TATA spare parts
278807100104	ASSY DISTRIBUTOR PUMP BS-III	TATA spare parts
278807100106	ASSY. DISTRIBUTOR PUMP W/METER BS4	TATA spare parts
278807100110	DISTRIBUTOR PUMPASSY	TATA spare parts
278807109901	POTENTIOMETER	TATA spare parts
278807123701	FIP BRACKET (REAR)-CAST	TATA spare parts
278807140101	ASSY. FUEL PR LINES 1 & 2 W/CLMP BS2/3/4	TATA spare parts
278809110101	ASSY BRACKET (FUEL FILTER MTG)	TATA spare parts
278809110103	ASSY. FUEL FILTER BS2	TATA spare parts
278809110104	FUEL FILTER ELEMENT SPINON BS2	TATA spare parts
278809110105	ASSY. FUEL FILTER DOUBLE-WIF SENS. BS3/4	TATA spare parts
278809110106	ASSY.FUEL FILTER WITH WIF SENSOR	TATA spare parts
278809110107	WATER SENSOR ASSEMBLY	TATA spare parts
278809110108	FUEL FILTER ASSY WITH WIF SENSOR	TATA spare parts
278809130102	ASSY ISOLATOR(FOR SNORKEL&RESONATOR MTG)	TATA spare parts
278809130103	ASSY BRACKET-RH (AIR FILTER MTG)	TATA spare parts
278809130105	ASSY. SNORKEL WITH MESH	TATA spare parts
278809130107	ASSY RUBBER HOSE (FOR INTAKE SYSTEM)	TATA spare parts
278809130110	ASSY. BRACKET FOR SNORKEL MOUNTING (TOP)	TATA spare parts
278809130112	ASSY SNORKEL HUMP HOSE AIR CLEANER & CLA	TATA spare parts
278809130113	ASSY. AIR CLEANER BS2/3/4	TATA spare parts
278809130114	AIR FILTER ELEMENT BS2/3/4	TATA spare parts
278809130116	ASSY. GROMMET WITH SLEEVE (FLEETGUARD)BS	TATA spare parts
278809130117	ASSY. SNORKEL W/MESH BS2/3/4	TATA spare parts
278809130120	ASSY. SNORKEL WITH GASKET	TATA spare parts
278809130121	ASSY.SNORKEL HOSE AIR CLEANER & CLAMP	TATA spare parts
278809130123	ASSY.AIR CLEANER	TATA spare parts
278809130129	ASSY PIPE	TATA spare parts
278809130133	STRAP ASSY AIR FILTER	TATA spare parts



278809130134	ISOLATOR ASSY AIR FILTER MTG	TATA spare parts
278809130136	AIR INTAKE HOSE BS2/3/4	TATA spare parts
278809130137	HOSE ASSY INTAKE	TATA spare parts
278809130140	PIPE ASSY	TATA spare parts
278809130141	AIR FILTER ASSY	TATA spare parts
278809130142	PRE CLEANER	TATA spare parts
278809130146	BRACKET ASSY	TATA spare parts
278809130147	BRACKET ASSY	TATA spare parts
278809133302	BKT-LH (LIFTING HOOK & AIR FILTER MTG)	TATA spare parts
278809133304	BRACKET - LH (AIR FILTER MOUNTING)	TATA spare parts
278809133305	BRACKET - RH (AIR FILTER MOUNTING)	TATA spare parts
278809133306	LIFTING HOOK	TATA spare parts
278809134201	HOSE CLAMP	TATA spare parts
278809134202	CLAMP	TATA spare parts
278809134203	CLAMP	TATA spare parts
278809135301	GASKET (FOR ASSY RUBBER HOSE)	TATA spare parts
278809135303	RUBBER INSERT AIR CLEANER ACE BS2/3/4	TATA spare parts
278809135304	GASKET	TATA spare parts
278809135802	INTAKE HOSE (SNORKEL TO AIR FILT) BS3/4	TATA spare parts
278809135803	INTAKE HOSE SNORKEL TO RESONATOR	TATA spare parts
278809135805	HOSE BS2/3/4	TATA spare parts
278809135807	INTAKE HOSE-AIR CLEANER TO SNORKEL	TATA spare parts
278809135808	INTAKE HOSE(ELBOW TO AIR FILTER)	TATA spare parts
278809135809	INTAKE HOSE(ELBOW TO AIR FILTER)	TATA spare parts
278809135812	HOSE (AIR FILTER TO PIPE INTERMEDIATE)	TATA spare parts
278809135813	RUBBER HOSE (AIR FILTER TO SNORKEL)	TATA spare parts
278809135814	RUBBER HOSE (PRE-CLEANER TO PIPE)	TATA spare parts
278809135815	RUBBER HOSE (FLANGE TO PRE-CLEANER)	TATA spare parts
278809135818	PIPE AIR INATKE INTERMEDIATE	TATA spare parts
278809136301	SNORKEL	TATA spare parts
278809136302	RESONATOR BOX	TATA spare parts
278809136305	ELBOW FOR AIR INTAKE SYSTEM	TATA spare parts
278809136306	FLANGE (WHEEL ARCH)	TATA spare parts
278809136307	COVER	TATA spare parts
278809136308	PIPE WITH FLANGE	TATA spare parts
278809136309	FLANGE	TATA spare parts
278809137101	COVER PLATE-LH	TATA spare parts
278809137102	COVER PLATE-RH	TATA spare parts
278809137103	BRACKET (AIR FILTER MOUNTING)	TATA spare parts
278809137701	COVER BOTTOM PLASTIC BS6	TATA spare parts
278809137702	COVER TOP PLASTIC BS6	TATA spare parts
278809137703	GASKET (COVER PLATE-SNORKEL)	TATA spare parts
278809138203	BRACKET	TATA spare parts
278809139901	GASKET ORING BS6	TATA spare parts
278814100102	ASSY. INLET MANIFOLD (FOR EURO-II)	TATA spare parts
278814100107	ASSY.INLET MANIFOLD(WITH EGR PROVISION)	TATA spare parts
278814100109	INTAKE MANIFOLD ASSY WITH EGR PROVISION	TATA spare parts

278814100110	INTAKE MANIFOLD ASSY	TATA spare parts
278814105301	GASKET INLET MANIFOLD	TATA spare parts
278814105303	GASKET INLET MANIFOLD	TATA spare parts
278814105801	RUBBER HOSE I-MANIFOLD TO CYL HD COVER	TATA spare parts
278814110114	ASSY.EGR PIPE (EGR VALVE TO INLET)	TATA spare parts
278814110115	ASSY EGR PIPE (EXH.TO EGR VALVE)	TATA spare parts
278814110116	VACUUM MODULATOR W/O FILTER	TATA spare parts
278814110119	FILTER FOR VACUUM MODULATOR	TATA spare parts
278814110120	CATALYTIC CONVERTER ASSY BSIII	TATA spare parts
278814110121	EGR PIPE ASSY EXH MANIFOLD TO EGR VALVE	TATA spare parts
278814110122	EGR PIPE ASSY WITH CLAMP	TATA spare parts
278814110130	CATALYTIC CONVERTER ASSY	TATA spare parts
278814110132	CATALYTIC CONVERTER ASSY	TATA spare parts
278814110134	PIPE ASSY CATALYTIC CONVERTER FRONT	TATA spare parts
278814113702	EXHAUST MANIFOLD	TATA spare parts
278814113706	EXHAUST MANIFOLD (FOR EGR)	TATA spare parts
278814115301	GASKET EXHAUST MANIFOLD	TATA spare parts
278814115303	GASKET EXHAUST MANIFOLD	TATA spare parts
278814115801	HOSE-VACCUM PUMP TO VACCUM MODULATOR	TATA spare parts
278814115802	HOSE-VACCUM MODULATOR TO EGR VALVE	TATA spare parts
278814700101	ASSY. EGR COOLER W/VALVE BS4	TATA spare parts
278814700102	ASSY BRACKET FOR EGR COOLER MOUNTING	TATA spare parts
278814705301	GASKET (EGR VALVE-INLET)	TATA spare parts
278814705302	GASKET (EGR VALVE-OUTLET)	TATA spare parts
278814990101	DECARB GASKET KIT (BS-II) W/O CYL HD GSK	TATA spare parts
278814990102	DECARBONISING GASKET KIT (BS-IV)	TATA spare parts
278815140102	ASSY. BRACKET-ALTERNATOR - UPPER	TATA spare parts
278815143701	ALERNATOR MTG.BKT-CAST	TATA spare parts
278815148801	STUD (FOR A.C. & ALT. BRACKET)	TATA spare parts
278818100101	OIL PUMP ASSY (WITH STEEL BACK PLATE) BS	TATA spare parts
278818133201	BANJO BOLT (OIL FILTER ADAPTER)	TATA spare parts
278818133801	ADAPTOR(FOR OIL FILTER MOUNTING)	TATA spare parts
278818135301	GASKET (OIL FILTER ADAPTOR TO CRANKCASE)	TATA spare parts
278818150101	ASSY.STRAINER FOR OIL PUMP	TATA spare parts
278818156501	FLANGED CLINCH NUT	TATA spare parts
278820100101	ASSY. WATER PUMP BS1/2/3/4/6	TATA spare parts
278820100101DF	WATER PUMP-- 275IDI ACE/MAGIC	TATA spare parts
278820100102	WATER PUMP ASSY	TATA spare parts
278820120103	ASSY. ELBOW WATER INLET & BYPASS BS2/3/4	TATA spare parts
278820120104	ASSY. TUBE-WATER BYPASS	TATA spare parts
278820120106	ASSY. THERMOSTAT (87 DEG.SOT) BS2/3/4	TATA spare parts
278820120113	ASSY.ADAPTOR (FOR TEMP.SENSOR & COOLER )	TATA spare parts
278820120114	ASSY TUBE(WATER BYPASS)	TATA spare parts
278820120118	THERMOSTAT ASSEMBLY	TATA spare parts
278820123201	BANJO BOLT(FOR MTG TEMP SENSOR)	TATA spare parts
278820125801	HOSE-FOR WATER BYPASS BS2/3/4	TATA spare parts
278820125805	RUBBER HOSE (FROM ELBOW TO TRANSITION PI	TATA spare parts

278820125806	RUBBER HOSE (FOR VENT TUBE)	TATA spare parts
278820125809	HOSE (CYL HEAD TO EGR COOLER)	TATA spare parts
278820125810	HOSE (EGR COOLER TO BYPASS TUBE)	TATA spare parts
278822100101	ENGINE LIFTING HOOK (REAR)	TATA spare parts
278822107101	LIFTING HOOK (FRONT)	TATA spare parts
278822107104	LIFTING HOOK	TATA spare parts
278822123703	BRACKET FOR ENGINE MOUNTING ARM	TATA spare parts
278822123704	ENGINE MOUNTING ARM (FRONT)	TATA spare parts
278824100105	ASSY. ENGINE MOUNT (FRONT) BS2/3/4	TATA spare parts
278824100105DF	ENGINE MOUNTING FRONT - ACE/MAGIC	TATA spare parts
278824200105	ASSY. ENGINE MOUNT REAR BS2/3/4	TATA spare parts
278824200105DF	ENGINE MOUNTING REAR - ACE/MAGIC	TATA spare parts
278824200105DFBP	ENGINE MOUNTING REAR W/ BACK PLATE-ACE/M	TATA spare parts
278849100103	ASSY. CATCON WITH PM TRAP BS4	TATA spare parts
278849100104	ASSY. PM TRAP (ECOCAT) BS4	TATA spare parts
278849100106	ASSY.BRACKET CATCON SUPPORT	TATA spare parts
278849100107	ASSY CATCON WITH PM TRAP -ACE EX	TATA spare parts
278849100108	ASSY PM TRAP (ECOCAT) - ACE EX	TATA spare parts
278849100110	ASSY. CATALYTIC CONVERTER	TATA spare parts
278849100112	CATALYTIC CONVERTER ASSY EX BSIV	TATA spare parts
278849100113	ASSY. CATCON BSIII	TATA spare parts
278850100101	ASSY, RAD W/H FAN, SHRD, & MOTOR BSII	TATA spare parts
278850100102	ASSY. PIPE W/CLAMP-RAD. INLET BS2/3/4	TATA spare parts
278850100103	ASSY, RAD. W/H FAN, SHRD, & MOTOR BSII	TATA spare parts
278850100104	ASSY. RADIATOR W/THERMO SW. BS3/4	TATA spare parts
278850100107	PRESSURE CAP	TATA spare parts
278850100108	ASSY. FAN MOTOR & SHROUD BS2/3/4	TATA spare parts
278850100109	ASSY TRANSITION PIECE-UPPER COOLING LINE	TATA spare parts
278850100110	ASSY RAD. W/H FAN SHROUD & MOTOR	TATA spare parts
278850100112	ASSY RADIATOR	TATA spare parts
278850100114	PRESSURE CAP BS1/2/3/4	TATA spare parts
278850100115	ASSY RADIATOR COMPLETE	TATA spare parts
278850100116	ASSY RADIATOR (W/O DRAIN PLUG & FILLER C	TATA spare parts
278850100117	DRAIN PLUG ASSY	TATA spare parts
278850100118	FILLER CAP ( PRESSURE & VACCUM CAP )	TATA spare parts
278850100119	ASSY SHROUD WITH FAN & MOTOR	TATA spare parts
278850100124	ASSY. RADIATOR ACE 275ID BS2/3/4	TATA spare parts
278850100124DF	RADIATOR ASSY COMPLETE-ACE/MAGIC	TATA spare parts
278850100125	FAN&MOTOR&SHROUD&ASSY	TATA spare parts
278850100126	ASSY. PIPE WITH CLAMP (RADIATOR INLET)	TATA spare parts
278850100127	ASSY. PIPE WITH CLAMP (RADIATOR INLET)	TATA spare parts
278850100129	ASSY. RADIATOR (SELF BLEEDING)	TATA spare parts
278850100137	ASSY. TRANSITION PIECE UCL BLNG BS2/3/4	TATA spare parts
278850104202	CLAMP-LOWER COOLING LINE	TATA spare parts
278850104203	BRACKET FOR UCL MOUNTING ON FRAME	TATA spare parts
278850104204	HOSE CLAMP FOR RADIATOR HOSE	TATA spare parts
278850105801	HOSE - LOWER COOLING LINE BS2/3/4	TATA spare parts

278850105802	HOSE - UPPER COOLING LINE BS2/3/4/6	TATA spare parts
278850105803	HOSE UCL BS2/3/4/6	TATA spare parts
278850105804	HOSE UCL-TRANS. PIECE TO PIPE BS2/3/4	TATA spare parts
278850105805	BRACKET HOLDING SLEEVE	TATA spare parts
278850107501	RUBBER GROMMET	TATA spare parts
278850108001	BLEEDING SCREW (UPPER COOLING LINE)	TATA spare parts
278901000103	ASSY.ENG.COMPL.WITH CL.(2.2DICR)TM	TATA spare parts
278901000104	ASSY.ENG.COMPL.WITH CL (2.2 DICOR) (W/O	TATA spare parts
278901000111	ASSY.ENG.COMPL.W/O CL.(2.2DICR)SPRINT	TATA spare parts
278901000112	ASSY. ENGINE COMP. W/O CL 2.2L BS3	TATA spare parts
278901000114	ASSY.ENG.COMPL.W/O CL.(2.2DICOR)XENON	TATA spare parts
278901000116	ASSY.ENG.COMPL.W/O CL.(2.2L DICOR)XENON	TATA spare parts
278901000116YA	YELLOW AGGREGATE FOR 2.2L DICOR ENGINE A	TATA spare parts
278901000120	ASSY.ENG.COMPL.W/O CL.(2.2DICOR) XENON	TATA spare parts
278901000132	ENGINE W/O CL 2.2 WINGER BS4(AC+HD+PS)	TATA spare parts
278901000135	ENGINE COMPL W/O CL. XENON BS IV DMF	TATA spare parts
278901000136	ASSY.ENG.COMPL.W/O CL(2.2L DICOR) XENON	TATA spare parts
278901000146	ASSY ENGINE 2.2 DICOR E-V FOR XENON	TATA spare parts
278901000174	ENGINE W/O CL 2.2 STRETCHED WINGER BS4	TATA spare parts
278901000176	ASSY ENG W.O CL:2.2 WINGER BS4(PS)	TATA spare parts
278901000177	ASSY ENGINE 2.2L DICOR E-II FOR XENON	TATA spare parts
278901000189	ASSY. ENGINE COMP. 2.2L EURO2	TATA spare parts
278901000191	ASY ENG 2.2DICOR E-V FOR XENON AUSTRALIA	TATA spare parts
278901000194	ASSY ENGINE 2.2 DICOR E-V FOR XENON AUS.	TATA spare parts
278901000197	ASSY. ENGINE COMP. 2.2L EURO2	TATA spare parts
278901000204	ENGINE ASSY W/O CLUTCH	TATA spare parts
278901000212	ENGINE ASSY-2.2L DICOR XENON E-II X2	TATA spare parts
278901000214	ENGINE ASSY W/O CLUTCH	TATA spare parts
278901000218	ENGINE 2.2 L WINGER MY16 NON AC	TATA spare parts
278901000221	ENGINE ASSY W/O CLUTCH	TATA spare parts
278901000222	ENGINE ASSY W/O CLUTCH	TATA spare parts
278901000226	TPL GRP 00-2.2L DICOR XENON E-IV X2	TATA spare parts
278901000229	ASSY ENGINE 2.2L DICOR EIV FOR XENON	TATA spare parts
27890100024020	STAGE ROLL OUT POWERTRAIN 4X4 AT	TATA spare parts
27890100024040	STAGE ROLL OUT POWERTRAIN 4X2 AT	TATA spare parts
278901000243	ENGINE ASSY W/O CLUTCH BS6	TATA spare parts
278901000248	ENGINE ASSY W/O CLUTCH	TATA spare parts
278901000251	ENGINEASSYW/OCLUTCH BS6	TATA spare parts
278901000253	ENGINE ASSY W/O CLUTCH BS6	TATA spare parts
278901000254	ENGINE ASSY W/O CLUTCH BS6	TATA spare parts
278901000256	ENGINE ASSY W/O CLUTCH	TATA spare parts
278901000257	ENGINE ASSY W/O CLUTCH BS6	TATA spare parts
278901000280	ENGINE ASSY W/O CLUTCH BS6-PH2	TATA spare parts
278901000281	ENGINE ASSY W/O CLUTCH BS6-PH2	TATA spare parts
278901000285	ENGINE ASSY W/O CLUTCH BS6-PH2	TATA spare parts
278901000286	ENGINE ASSY W/O CLUTCH BS6-PH2	TATA spare parts
278901100101	ASSY.CYLINDER CRANKCASE	TATA spare parts

278901100102	ASSY.CYLINDER CRANKCASE WITH M.B.CAPS	TATA spare parts
278901100108	ASSY. CYLINDER CRANKCASE	TATA spare parts
278901100118	ASSY. CYLINDER CRANKCASE WITH M.B. CAP	TATA spare parts
278901100121	ASSY. CCC SUPPORT BRACKET(ON CYL.BLOCK)	TATA spare parts
278901100123	CYLINDER CRANKCASE ASSY BS6	TATA spare parts
278901100124	CYLINDER CRANKCASE ASSYBS6	TATA spare parts
278901100125	STIFFENER BRACKET ASSY BS6	TATA spare parts
278901103201	HEX.BOLT-M.B.CAP	TATA spare parts
278901103301	STIFFNER (CRANKCASE TO DIFFERENTIAL COVE	TATA spare parts
278901103704	BRACKET POWERTRAIN STIFFNER(LH SIDE)	TATA spare parts
278901103705	BRACKET POWERTRAIN STIFFNER(RH SIDE)	TATA spare parts
278901103714	CYLINDER CRANKCASEBS6	TATA spare parts
278901106901	TUBE-FROM CRANKCASE TO OIL COOLER	TATA spare parts
278901107804	OIL SEAL-CRANKSHAFT(REAR)	TATA spare parts
278901107805	OIL SEAL-CRANKSHAFT FRONT(CR SEAL) BS4	TATA spare parts
278901107806	OIL SEAL-CRANKSHAFT REAR(ROTOSTAT) BS6-P	TATA spare parts
278901130101	ASSY.OIL SUMP	TATA spare parts
278901130113	OIL SUMP ASSY	TATA spare parts
278901130119	ASSY. OIL SUMP WITH TUBE (WINGER)	TATA spare parts
278901130120	OIL SUMP ASSY	TATA spare parts
278901130122	OIL SUMP ASSY WITH TUBE BS6	TATA spare parts
278901131601	OIL SUMP	TATA spare parts
278901131602	OIL SUMP BS6	TATA spare parts
278901133201	HEX FLANGE BOLT(M6X90)	TATA spare parts
278901133801	LADDER FRAME	TATA spare parts
278901133808	AL. OIL SUMP	TATA spare parts
278901133809	OIL SUMP	TATA spare parts
278901133810	OIL SUMP	TATA spare parts
278901133811	STIFFENER BRACKET POWERTRAIN BS6	TATA spare parts
278901133812	OIL SUMP BS6	TATA spare parts
278901133813	OIL SUMP BS6	TATA spare parts
278901134801	HOLLOW DOWEL (OIL SUMP MTG.)	TATA spare parts
278901135302	OIL SUMP GASKET	TATA spare parts
278901136905	TUBE-OIL SUMP TO HOSE	TATA spare parts
278901136907	TUBE VACUUM PUMP TO SUMP BS6	TATA spare parts
278901137201	SCREW PLUG	TATA spare parts
278901137701	SEALING PLUG	TATA spare parts
278901139202	SEALING WASHER (OIL SUMP DRAIN PLUG)	TATA spare parts
278901140101	ASSY.REAR COVER CRANKCASE WITH OIL SEAL	TATA spare parts
278901140102	ASSY. COVER - BACK(TIMING BELT)	TATA spare parts
278901140103	ASSY.BOTTOM COVER (TIMING BELT)	TATA spare parts
278901140113	TIMING COVER ASSY BACK	TATA spare parts
278901140114	TIMING COVER ASSY FRONT	TATA spare parts
278901140115	TIMING COVER ASSY BOTTOM	TATA spare parts
278901143802	REAR COVER-CRANKCASE BS4	TATA spare parts
278901143803	COVER CRANKCASE REAR BS6-PH2	TATA spare parts
278901145301	GASKET-REAR COVER CRANKCASE	TATA spare parts

278901145302	GASKET-REAR COVER	TATA spare parts
278901147701	FRONT COVER-TOP (TIMING BELT)	TATA spare parts
278901147703	COVER-BACK (TIMING BELT)	TATA spare parts
278901147704	COVER-BOTTOM(TIMING BELT)	TATA spare parts
278901150101	ASSY.CYLINDER HEAD WITH VALVES	TATA spare parts
278901150102	ASSY. CYLINDER HEAD WITHOUT VALVES	TATA spare parts
278901150103	ASSY.CYLINDER HEAD COVER (WITH TUBE)	TATA spare parts
278901150104	ASSY.BAFFLE PLATE	TATA spare parts
278901150106	ASSY.ENGINE COVER	TATA spare parts
278901150107	ASSY.BRACKET(ENGINE COVER MTG.-LEFT)	TATA spare parts
278901150108	ASSY.BRACKET (ENGINE COVER MTG.-RIGHT)	TATA spare parts
278901150114	ASSLY. ENGINE COVER(PHOENIX/SPRINT)	TATA spare parts
278901150117	ASSY. CYLINDER HEAD COVER	TATA spare parts
278901150123	ASSEMBLY ENGINE COVER	TATA spare parts
278901150127	ASSLY. ENGINE COVER W/O SILVER IMD FILM	TATA spare parts
278901150129	ASSY. CYLINDER HEAD COVER +TUBE+BAFFLE P	TATA spare parts
278901150133	ASSY.CYLINDER HEAD WITH VALVES	TATA spare parts
278901150135	ASSY. CYL. HEAD WITHOUT VALVES	TATA spare parts
278901150141	ASSY. BRACKET (FOR ENGINE COVER MTG.)	TATA spare parts
278901150144	ASSY ENGINE COVER(PURE LX)-ARIA	TATA spare parts
278901150151	ASSY. CYL. HEAD WITHOUT VALVES	TATA spare parts
278901150160	ASSY CYLINDER HEAD WITHOUT VALVES	TATA spare parts
278901150161	CYLINDER HEAD ASSY WITH VALVES	TATA spare parts
278901150163	ASSY. CYL. HEAD W/O VALVE (INTERMEDIATE)	TATA spare parts
278901150170	BRACKET ASSY,ENGINE COVER MTG,REAR	TATA spare parts
278901150174	CYL HEAD ASSY W/O VALVES	TATA spare parts
278901150195	COVER ASSY CYLINDER HEAD BS6	TATA spare parts
278901150198	CYLINDER HEAD ASSY W/O VALVES BS6	TATA spare parts
278901150199	CYL HEAD ASSY WITH VALVES BS6	TATA spare parts
278901153201	HEX.BOLT-CYLINDER HEAD	TATA spare parts
278901153202	HEX BOLT M8X40 (INJECTOR CLAW)	TATA spare parts
278901153401	VALVE SEAT INSERT-INTAKE (NORMAL)	TATA spare parts
278901153403	VALVE SEAT INSERT-EXHAUST (NORMAL)	TATA spare parts
278901153803	BEARING FRAME	TATA spare parts
278901153805	ADAPTOR (FOR VACUUM PUMP)	TATA spare parts
278901153811	BEARING FRAME	TATA spare parts
278901153812	BEARING FRAME	TATA spare parts
278901154801	ORIFICE-CYL.HEAD OIL GALLERY	TATA spare parts
278901155301	GASKET-CYLINDER HEAD-MLS(1.3 THK)	TATA spare parts
278901155302	GASKET (CYLINDER HEAD COVER)	TATA spare parts
278901155303	GASKET-CYLINDER HEAD-MLS(1.4 THK)	TATA spare parts
278901155304	GASKET-CYLINDER HEAD-MLS(1.5 THK)	TATA spare parts
278901155306	GASKET - CYLINDER HEAD COVER	TATA spare parts
278901155308	GASKET-CYLINDER HEAD-MLS(1.3 THK)	TATA spare parts
278901155309	GASKET-CYLINDER HEAD-MLS(1.4 THK)	TATA spare parts
278901155310	ASKET-CYLINDER HEAD-MLS(1.5 THK-REINZ I	TATA spare parts
278901155311	GASKETCYLHEADCOVER BS6	TATA spare parts

278901155801	GASKET VACUUM PUMP	TATA spare parts
278901156701	BALL HEADED PIN (ENGINE COVER MOUNTING)	TATA spare parts
278901156703	BALL HEADED PIN ENGINE COVER MOUNTING	TATA spare parts
278901156704	BALL HEAD PIN,ENGINE COVER MTG	TATA spare parts
278901156901	TUBE CYLINDER HEAD COVER	TATA spare parts
278901157501	RUBBER GROMMET (ENGINE COVER MOUNTING)	TATA spare parts
278901157701	CYLINDER HEAD COVER	TATA spare parts
278901157705	OIL FILLER CAP	TATA spare parts
278901157709	OIL FILLER CAP (TAPS)	TATA spare parts
278901157709_niu1	OIL FILLER CAP (TAPS)	TATA spare parts
278901157713	OIL FILLER CAP	TATA spare parts
278901157718	O RING (FOR ADAPTOR) BS4	TATA spare parts
278901157728	O-RING,OIL FILLER CAP	TATA spare parts
278901160101	ASSY. FUEL INJECTOR BS3/4	TATA spare parts
278901160101AE	INJECTOR SET XEN DC XEN SC	TATA spare parts
278901160106	ASSY. FUEL INJECTOR BS3/4	TATA spare parts
278901160117	INJECTOR ASSY BS6	TATA spare parts
278901161601	CLAW INJECTOR	TATA spare parts
278901165301	GASKET (PIN INJECTOR CLAW	TATA spare parts
278901166701	PIN (INJECTOR CLAW SUPPORT)	TATA spare parts
278901166702	PIN INJECTOR CLAW	TATA spare parts
278901169201	WASHER (FOR INJECTOR) BS4	TATA spare parts
278901169202	SEALING WASHER BS4	TATA spare parts
278901170101	ASSY.DIPSTICK TUBE	TATA spare parts
278901170102	ASSY.DIPSTICK	TATA spare parts
278901170104	ASSY.DIPSTICK	TATA spare parts
278901170115	BRACKET (OIL SEPERATOR MTG)	TATA spare parts
278901170116	OIL MIST SEPARATOR	TATA spare parts
278901170119	OIL SEPARATOR	TATA spare parts
278901170122	ASSY. DIPSTICK TUBE	TATA spare parts
278901170123	ASSY. DIPSTICK	TATA spare parts
278901170132	ASSY.INTERMEDIATE PIPE(OMS TO AIR FILTER	TATA spare parts
278901170135	OIL MIST SEPARATOR ASSY	TATA spare parts
278901170137	ASSY.DIPSTICK TUBE	TATA spare parts
278901170138	ASSY.DIPSTICK (WINGER)	TATA spare parts
278901170139	ASSY. TUBE (VACUUM PUMP TO SUMP)	TATA spare parts
278901170150	DIPSTICK TUBE ASSY	TATA spare parts
278901170164	DIPSTICK TUBE ASSY BS6	TATA spare parts
278901170165	DIPSTICK TUBE ASSY	TATA spare parts
278901170166	PIPE ASSY OMS TO AIR FILTER HOSE	TATA spare parts
278901170168	DIPSTICK ASSY BS6	TATA spare parts
278901170169	DIPSTICK ASSY BS6	TATA spare parts
278901173301	BRACKET-OIL SEPERATOR MTG.	TATA spare parts
278901173311	BRACKET(OIL SEPERATOR MTG.)	TATA spare parts
278901173326	BRACKET OIL SEPARATOR MTG BS6	TATA spare parts
278901174203	PIPE CLIP(DIA.24-26)	TATA spare parts
278901175302	GASKET (DIPSTICK TUBE)	TATA spare parts

278901175801	HOSE (CYL.HEAD COVER TO OIL SEPARATOR)	TATA spare parts
278901175802	HOSE (BLOW BY TO OIL SEPERATOR)	TATA spare parts
278901175802AE	HOSE(OIL SEP AIR FLTR)-XEN DC/SC	TATA spare parts
278901175825	HOSE (OIL SEP. TO AIR FILTER HOSE)	TATA spare parts
278901175830	HOSE(CYL.HEAD COVER TO OIL SEPARATOR)	TATA spare parts
278901175831	HOSE(OIL SEP.TO OIL SUMP)	TATA spare parts
278901175832	BLOW BY HOSE (OIL SEPT. TO PIPE)	TATA spare parts
278901175845	BLOW BY HOSE(INTERMEDIATE PIPE TO AIR FI	TATA spare parts
278901175857	HOSE(OIL SEP.TO OIL SUMP):WINGER	TATA spare parts
278901175862	HOSE OMS	TATA spare parts
278901175867	HOSE,OIL SEPARATOR TO OIL SUMP BS6	TATA spare parts
278901175868	HOSE OIL SEPARATOR TO AIR FILTER HOSE BS	TATA spare parts
278901175869	HOSE CYL HEAD COVER TO OIL SEPARATOR BS6	TATA spare parts
278901177103	FLANGE ON CYL BLOCK FOR DIPSTICK TUBE	TATA spare parts
278901990101	SPD ENGINE EURO IV-TELCOLINE (AC+PSTG.+H	TATA spare parts
278901990102	BARE ENGINE-2.2	TATA spare parts
278901990103	HALF BLOCK SAFARI 2.2	TATA spare parts
278901990104	ENGINE OVERHAUL GASKET KIT (EURO IV)	TATA spare parts
278901990105	ENGINE OVERHAUL GASKET SUB KIT(EURO IV)	TATA spare parts
278901990106	ENGINE OVERHAUL SEAL KIT	TATA spare parts
278901990107	DECARB. GASKET KIT (EURO IV)	TATA spare parts
278901990108	CYL.HEAD W/O INJECTOR SAFARI 2.2.	TATA spare parts
278901990115	KIT-ENGINE OVERHAUL GASKET BS4	TATA spare parts
278901990116	ENGINE OVERHAUL GASKET SUB KIT	TATA spare parts
278901990117	DECARB. GASKET KIT (BS III)	TATA spare parts
278901990137	HALF BLOCK	TATA spare parts
278901990151	SPD ENGINE E II XENON AC+PS	TATA spare parts
278901990181	ASSY. CYL. HEAD W/O INJECTOR	TATA spare parts
278901990182	SPD ENGINE XENON E-V	TATA spare parts
278901990183	BARE ENGINE EURO5	TATA spare parts
278901990184	HALF BLOCK 2.2L BS3/4	TATA spare parts
278901990185	ENGINE OVERHAUL GASKET KIT(E-V)	TATA spare parts
278901990186	ENGINE OVERHAUL SEAL KIT	TATA spare parts
278901990187	ENGINE OVERHAUL GASKET SUB KIT-EURO V	TATA spare parts
278901990188	DECARB. GASKET KIT-EURO V	TATA spare parts
278901990201	ASSY. CYL. HEAD W/O INJECTOR BS4	TATA spare parts
278901990202	DECARB.GASKET KIT	TATA spare parts
278901990207	LONG BLOCK 2.2L DICOR -WINGER BS4	TATA spare parts
278901990208	HALF BLOCK WINGER BS4	TATA spare parts
278901990209	ENGINE OVERHAUL GASKET SUB KIT	TATA spare parts
278901990210	ENGINE OVERHAUL SEAL KIT	TATA spare parts
278901990212	ENGINE (WINGER BS4) AC+HD+PS	TATA spare parts
278901990214	ENGINE (STRETCHED WINGER BS4)AC+HD+P	TATA spare parts
278901990222	ASSY. CYC HEAD W/O INJECTOR	TATA spare parts
278901990224	DECARB GASKET KIT - BS IV ARIA LET	TATA spare parts
278901990228	ASSY. CYC HEAD W/O INJECTOR	TATA spare parts
278901990229	ASSY. CYL. HEAD W/O INJECT & PLUGS BS3/4	TATA spare parts



278901990234	ENGINE FOR XENON E-II ECUADOR/SAUDI	TATA spare parts
278901990235	LONG BLOCK 2.2L XENON BS3/4	TATA spare parts
278901990236	ASSY. LONG BLOCK 2.2L DICOR BS3/4	TATA spare parts
278901990237	LONG BLOCK	TATA spare parts
278901990245	BARE ENGINE STORME LET	TATA spare parts
278901990247	KIT-GASKET-SEAL + O RING	TATA spare parts
278901990266	KIT-GASKET (ENGINE OVERHAUL GASKET SUB K	TATA spare parts
278901990280	BARE ENGINE	TATA spare parts
278901990281	HALF BLOCK	TATA spare parts
278901990290	BARE ENGINE	TATA spare parts
278901990291	HALF BLOCK	TATA spare parts
278901990307	CYL HEAD ASSY W/O INJECTOR BS6	TATA spare parts
278901990308	BARE ENGINE BS6	TATA spare parts
278901990309	HALF BLOCK BS6	TATA spare parts
278901990313	KIT-GASKET ENGINE OVERHAUL WITH SEAL BS6	TATA spare parts
278901990314	KIT-GASKET ENGINE OVERHAUL W/ CYLINDER H	TATA spare parts
278901990316	KIT-DECARBONISING GASKET W/ CYLINDER HEA	TATA spare parts
278901990325	BARE ENGINE BS6	TATA spare parts
278901990326	HALF BLOCK BS6	TATA spare parts
278901990334	BARE ENGINE BS6-PH2	TATA spare parts
278901990335	HALF BLOCK BS6-PH2	TATA spare parts
278901990338	BARE ENGINE BS6-PH2	TATA spare parts
278901990339	HALF BLOCK BS6-PH2	TATA spare parts
278903100112	ASSY. CRANKSHAFT WITH PIN-MICRO ALLOYED	TATA spare parts
278903100121	ASSY CRANKSHAFT WITH CYL.PIN-NORMAL-MICR	TATA spare parts
278903107101	FRICITION PLATE ( ON CRANKSHAFT)	TATA spare parts
278903107901	CRANKSHAFT-NORMAL	TATA spare parts
278903110103	ASSY. FLYWHEEL WITH RING GEAR (INCREASED	TATA spare parts
278903110107	ASSY.FLYWHEEL WITH RING GEAR	TATA spare parts
278903110112	ASSY.FLYWHEEL WITH RING GEAR(DIA.260 CLU	TATA spare parts
278903110119	FLYWHEEL ASSY WITH RING GEAR BS6-PH2	TATA spare parts
278903113201	HEX.BOLT(FLYWHEEL MOUNTING)	TATA spare parts
278903113202	HEX.BOLT(FLYWHEEL MOUNTING)	TATA spare parts
278903113206	BOLT	TATA spare parts
278903115401	RING GEAR	TATA spare parts
278903120105	SET-M.B.SHELL(UPPER/LOWER)NORMAL BS4	TATA spare parts
278903120106	SET-M.B.SHELL (UPPER/LOWER) NORMAL I	TATA spare parts
278903120107	SET-M.B.SHELL (UPPER/LOWER) REPAIR-I	TATA spare parts
278903120108	SET-M.B.SHELL (UPPER/LOWER)-REPAIR-II	TATA spare parts
278903120114	SET THRUST WASHER (UPPER/LOWER)-2.52	TATA spare parts
278903120115	SET THRUST WASHER (UPPER/LOWER)-2.57	TATA spare parts
278903120116	SET THRUST WASHER (UPPER/LOWER)-2.62	TATA spare parts
278903120117	SET THRUST WASHER (UPPER/LOWER)-2.67	TATA spare parts
278903120118	SET THRUST WASHER (UPPER/LOWER)-2.72	TATA spare parts
278903120123	SET-M.B.SHELL(UPPER/LOWER)NORMAL(BIMETA	TATA spare parts
278903120125	SET-M.B.SHELL(UPPER/LOWER)-REPAIR I	TATA spare parts
278903120126	SET-M.B.SHELL(UPPER/LOWER)-REPAIR II	TATA spare parts

278903123415	M.B.SHELL-UPPER HALF-NORMAL	TATA spare parts
278903123419	M.B.SHELL-LOWER HALF NORMAL	TATA spare parts
278903123433	THRUST WASHER (UPPER) BIMETAL	TATA spare parts
278903123438	THRUST WASHER (LOWER)BIMETAL -2.52	TATA spare parts
278903123443	M.B.SHELL-UPPER HALF-NORMAL(BIMETAL)	TATA spare parts
278903123447	M.B.SHELL-LOWER HALF NORMAL(BIMETAL)	TATA spare parts
278903123451	THRUST WASHER (LOWER)FM -2.52	TATA spare parts
278903123456	THRUST WASHER (UPPER)FM -2.52	TATA spare parts
278903130101	ASSY.VIBRATION DAMPER	TATA spare parts
278903130102	ASSY.VIBRATION DAMPER	TATA spare parts
278903130103	ASSY. VIBRATION DAMPER	TATA spare parts
278903130104	ASSY.VIBRATION DAMPER	TATA spare parts
278903130110	VIBRATION DAMPER ASSY	TATA spare parts
278903130111	VIBRATION DAMPER ASSY	TATA spare parts
278903131601	ASSY. VIBRATION DAMPER	TATA spare parts
278903133201	HEX.BOLT-CRANKSHAFT GEAR	TATA spare parts
278903133701	PULLEY CRANKSHAFT BS6-PH2	TATA spare parts
278903139201	WASHER (CRANKSHAFT GEAR)	TATA spare parts
278903140102	ASSY.OIL CONTROL RING (INDIA PISTONS)	TATA spare parts
278903140123	ASSY.PISTON(E5) 320NM & 150PS A GRADE	TATA spare parts
278903140138	ASSY.PISTON E-IV A GRADE	TATA spare parts
278903149801	TOP RING (INDIA PISTONS)	TATA spare parts
278903149802	SECOND RING (INDIA PISTONS)	TATA spare parts
278903150103	ASSY.CONNECTING ROD WITH BUSH	TATA spare parts
278903150104	SET-BEARING HALF(UPPER/LOWER)-NORMAL	TATA spare parts
278903150108	SET-BEARING HALF(UPPER/LOWER)-NORMAL	TATA spare parts
278903150109	SET-BEARING HALF(UPPER/LOWER) NORMAL I	TATA spare parts
278903150110	SET-BEARING HALF(UPPER/LOWER) REPAIR I	TATA spare parts
278903150111	SET-BEARING HALF(UPPER/LOWER) REPAIR II	TATA spare parts
278903150142	SET-BRG. HALF(UPPER/LOWER)NORMAL BS3/4/6	TATA spare parts
278903150144	SET-BRG.HALF(UPPER/LOWER)REPAIR I	TATA spare parts
278903150145	SET-BRG.HALF(UPPER/LOWER)REPAIR II	TATA spare parts
278903153411	BUSH-CONNECTING ROD-NORMAL (GOETZE)	TATA spare parts
278903153413	BEARING HALF-UPPER-NORMAL(CON.ROD)	TATA spare parts
278903153417	BEARING HALF-LOWER-NORMAL(CON.ROD)GOET	TATA spare parts
278903153427	BEARING HALF-UPPER-NORMAL(CON.ROD)BIMET	TATA spare parts
278903153431	BEARING HALF-LOWER-NORMAL(CON.ROD)BIME	TATA spare parts
278903990101	SET-PISTON W/O RINGS GRADE A BS3/4	TATA spare parts
278903990102	SET PISTON GRADE B (IP)(W/O RINGS)	TATA spare parts
278903990103	SET PISTON WITHOUT RINGS GRADE C (IP)	TATA spare parts
278903990104	SET PISTON RINGS BS3/4	TATA spare parts
278903990123	SET-PISTON GRADE A BS3/4	TATA spare parts
278903990124	SET-PISTON GRADE B	TATA spare parts
278903990125	SET-PISTON GRADE C	TATA spare parts
278903990127	SET CON ROD BUSH-NORMAL	TATA spare parts
278903990135	SET-PISTON ASSY GRADE A	TATA spare parts
278903990138	SET-PISTON ASSY GRADE A REPAIR-I	TATA spare parts

278903990141	SET-PISTON ASSY GRADE A REPAIR-II	TATA spare parts
278903990145	SET-PISTON RINGS REPAIR-II	TATA spare parts
278903990146	SET-PISTON RINGS BS6	TATA spare parts
278903990147	SET-PISTON RINGS REPAIR-I BS6	TATA spare parts
278903990148	SET-PISTON RINGS REPAIR-II BS6	TATA spare parts
278903990175	"SET-PISTON ASSY, GRADE C"	TATA spare parts
278903990186	SET-CONNECTING ROD/BUSH NORMAL(BIMETAL)	TATA spare parts
278903990214	SET-PISTON W/O RINGS GRADE A BS6	TATA spare parts
278903990215	SET-PISTON W/O RINGS GRADE B	TATA spare parts
278903990216	SET-PISTON W/O RINGS GRADE C BS6	TATA spare parts
278905100101	ASSY.CAMSHAFT (INTAKE) WITH PIN & GEAR	TATA spare parts
278905100102	ASSY.CAMSHAFT (EXHAUST) WITH PIN & GEAR	TATA spare parts
278905107901	CAMSHAFT (INTAKE)	TATA spare parts
278905107902	CAMSHAFT (EXHAUST)	TATA spare parts
278905110101	ASSY. IDLER	TATA spare parts
278905110102	ASSY. TOUCH IDLER	TATA spare parts
278905110103	ASSY. TIMING GEAR (CAMSHAFT) WITH STOPPE	TATA spare parts
278905110109	IDLER PULLEY ASSEMBLY (INA)	TATA spare parts
278905110110	ASSY. AUTO TENSIONER (INA)	TATA spare parts
278905110112	ASSY. TOUCH IDLER BS3/4/6	TATA spare parts
278905110114	ASSY. AUTO TENSIONER BS3/4	TATA spare parts
278905113201	HEX.FLANGE BOLT	TATA spare parts
278905113202	STUD (FOR AUTO TENSIONER)	TATA spare parts
278905114801	CYLINDRICAL PIN (TENSIONER)	TATA spare parts
278905115403	CAMSHAFT GEAR-REAR	TATA spare parts
278905115408	TIMING GEAR-CAMSHAFT (FRONT)	TATA spare parts
278905115410	CRANKSHAFT GEAR (SINTERED)-LITENS	TATA spare parts
278905116301	TIMING BELT	TATA spare parts
278905116303	TIMING BELT	TATA spare parts
278905116305	TIMING BELT BS4	TATA spare parts
278905116305DF	TIMING BELT - WINGER 2.2L BS4	TATA spare parts
278905118201	FLANGE (CAMSHAFT GEAR)	TATA spare parts
278905118601	SPACER (TIMING BELT IDLER)	TATA spare parts
278905118801	AUTO TENSIONER ASSY -STUD	TATA spare parts
278905125101	RETAINER VALVE SPRING	TATA spare parts
278905128201	SPRING SEAT	TATA spare parts
278905128701	VALVE SPRING BS4	TATA spare parts
278905129001	INTAKE VALVE	TATA spare parts
278905129002	EXHAUST VALVE	TATA spare parts
278905129003	INLET VALVE	TATA spare parts
278905129004	EXHAUST VALVE	TATA spare parts
278905129005	INLET VALVE (SHRIRAM PRECISION)	TATA spare parts
278905129006	EXHAUST VALVE(SHRIRAM PRECISION)	TATA spare parts
278905153701	VALVE GUIDE INTAKE & EXHAUST NORMAL	TATA spare parts
278905153702	VALVE GUIDE INTAKE & EXHAUST NORMAL-I BS	TATA spare parts
278905990102	TIMING BELT REPAIR KIT	TATA spare parts
278905990103	KIT FOR TIMING BELT DRIVE NEW	TATA spare parts

278905990103_niu1	KIT FOR TIMING BELT DRIVE NEW	TATA spare parts
278905990104	KIT B FOR TIMING BELT DRIVE	TATA spare parts
278905990105	KIT FOR TIMING BELT DRIVE	TATA spare parts
278907100101	ASSY. ROTARY PUMP BS3/4	TATA spare parts
278907100101AE	FUEL PUMP XEN DC XEN SC	TATA spare parts
278907100104	HP PUMP ASSY BS6	TATA spare parts
278907120103	STIFFENER BRACKET (FIP SIDE)	TATA spare parts
278907123301	BRACKET-H.P.PUMP (SHEETMETAL)	TATA spare parts
278907123302	INTAKE STIFFNER BRACKET FIP TO INTAKE	TATA spare parts
278907123304	STIFFENER BRACKET (INTAKE PIPE SIDE)	TATA spare parts
278907123305	STIFFENER INTAKE PIPE	TATA spare parts
278907123801	BRACKET-FIP MTG.	TATA spare parts
278907135401	TIMING GEAR (FIP)	TATA spare parts
278907135403	TIMING GEAR (FIP)	TATA spare parts
278907140101	ASSY. FUEL RAIL BS3/4	TATA spare parts
278907140105	ASSY. CLAMPING PIECE LOWER	TATA spare parts
278907140106	ASSY.FUEL PRESSURE LINE-1 (RAIL TO INJ.)	TATA spare parts
278907140106AE	ASSY.FL PR LN-1(RL T INJ)-XEN DC	TATA spare parts
278907140107	ASSY.FUEL PRESSURE LINE-2 (RAIL TO INJ.)	TATA spare parts
278907140107AE	ASSY.FL PR LN-2(RL T INJ)-XEN DC	TATA spare parts
278907140108	ASSY.FUEL PRESSURE LINE-3 (RAIL TO INJ.)	TATA spare parts
278907140109	ASSY.FUEL PRESSURE LINE-4 (RAIL TO INJ.)	TATA spare parts
278907140109AE	ASSY.FL PR LN-4(RL T INJ)-XEN DC	TATA spare parts
278907140110	ASSY.FUEL PRESSURE LINE-PUMP TO RAIL	TATA spare parts
278907140111	ASSY. SET BACK LEAK HOSES	TATA spare parts
278907140121	HP PIPE (PUMP TO RAIL)	TATA spare parts
278907140124	ASSY. CLAMPING PIECE LOWER	TATA spare parts
278907140125	ASSY. CALMP HP PIPE (LOWER)	TATA spare parts
278907140133	SET-BACK LEAK HOSE ASSYBS6	TATA spare parts
278907140134	FUEL RAIL ASSY BS6	TATA spare parts
278907140135	FUEL PR PIPE ASSY RAIL TO INJ	TATA spare parts
278907140136	FUEL PR PIPE ASSY RAIL TO INJ	TATA spare parts
278907140137	FUEL PR PIPE ASSY RAIL TO INJ	TATA spare parts
278907140138	FUEL PR PIPE ASSY RAIL TO INJ	TATA spare parts
278907140139	FUEL PR PIPE ASSY PUMP TO RAIL	TATA spare parts
278907140144	FUEL PR PIPE ASSY RAIL TO INJ BS6-PH2	TATA spare parts
278907140145	FUEL PR PIPE ASSY RAIL TO INJ BS6-PH2	TATA spare parts
278907140146	FUEL PR PIPE ASSY RAIL TO INJ BS6-PH2	TATA spare parts
278907140147	FUEL PR PIPE ASSY RAIL TO INJ BS6-PH2	TATA spare parts
278907140148	FUEL PR PIPE ASSY PUMP TO RAIL BS6-PH2	TATA spare parts
278907147501	RUBBER GROMMET (ENGINE COVER MOUNTING)	TATA spare parts
278907148201	CLAMPING PIECE UPPER	TATA spare parts
278907148202	CLAMPING PIECE UPPER	TATA spare parts
278907990104	INLET METERING VALVE SENSOR HP PUMP	TATA spare parts
278907990105	INLET METERING VALVE SENSOR HP PUMP	TATA spare parts
278909110107	ASSY.BRACKET WITH RUBBER STRAP	TATA spare parts
278909110108	ASSY.BRACKET WITH RUBBER STRAP	TATA spare parts

278909110121	ASSY.FUEL FILTER W/ PLASTIC BKT.	TATA spare parts
278909110126	FUEL PRE-FILTER BS3/4	TATA spare parts
278909110127	ASSY.INTEGRATED FUEL FILTER	TATA spare parts
278909110128	ASSY.FUEL PRE-FILTER WITH BRACKET	TATA spare parts
278909110135	ASSEMBLY PLASTIC BRACKET	TATA spare parts
278909110140	WIF SENSOR KIT BS4	TATA spare parts
278909110143	FUEL PRE FILTER ASSY+BKT+2PIN CONNECTOR	TATA spare parts
278909110146	ASSY BRACKET FUEL PRE FILTER MOUNTING	TATA spare parts
278909110153	SUPPORT BRACKET ASSY	TATA spare parts
278909110156	BRACKET ASSY	TATA spare parts
278909113311	BRACKET (PRE-FILTER CONNECTOR PARKING)	TATA spare parts
278909118002	M6FIXINGSCREW	TATA spare parts
278909118207	SUPPORT BRACKET ASSY	TATA spare parts
278909130103	ASSY.HOSE-AIR FILTER OUTLET	TATA spare parts
278909130106	AIR FILTER ELEMENT BS3/4/6	TATA spare parts
278909130106AE	AIR CLEANER ELEMENT -XENON DC/SC	TATA spare parts
278909130107	ASSY.AIR FILTER	TATA spare parts
278909130108	ASSY.AIR FILTER+DUCT	TATA spare parts
278909130119	ASSY AIR FILTER WITH INTAKE DUCT	TATA spare parts
278909130121	RESERVOIR (AIR INTAKE)	TATA spare parts
278909130122	ASSY. HOSE (AIR FILTER OUTLET)	TATA spare parts
278909130129	ASSY AIR FILTER WITH INTAKE DUCT	TATA spare parts
278909130142	ASSY. HOSE (AIR FILTER OUTLET)	TATA spare parts
278909130147	ASSY. AIR INTAKE RESERVOIR	TATA spare parts
278909130156	ASSY HOSE AIR FILTER OUTLET	TATA spare parts
278909130160	ASSY. AIR INTAKE RESERVOIR	TATA spare parts
278909130162	BRACKET ASSY AIR FILTER(REAR)	TATA spare parts
278909130164	ASSY. SUPPORT BKT(ASSY. PIPE-TC INLET)	TATA spare parts
278909130171	ASSY.BRACKET(AIR FILTER MTG.FRONT SIDE)	TATA spare parts
278909130172	ASSY. BRACKET (AIR FILTER MOUNTING REAR	TATA spare parts
278909130191	ASSY. AIR FILTER EURO 5	TATA spare parts
278909130202	RESERVOIR ASSY AIR INTAKE	TATA spare parts
278909130203	ASSY.BRACKET (INTAKE DUCT MTG.)	TATA spare parts
278909130204	ASSY.INTAKE DUCT	TATA spare parts
278909130206	ASSY. AIR FILTER (WINGER)	TATA spare parts
278909130207	AIR FILTER ASSY	TATA spare parts
278909130222	HOSE ASSY AIR FILTER OUTLET	TATA spare parts
278909130230	DUCT ASSY AIR INTAKE SYSTEM	TATA spare parts
278909130243	DUCT&INTAKE&SYSTEM BS6	TATA spare parts
278909130244	AIR RESERVOIR ASSY	TATA spare parts
278909130246	HOSE ASSY AIR FILTER OUTLET BS6	TATA spare parts
278909130247	HOSE ASSY AIR FILTER OUTLET	TATA spare parts
278909133803	BRACKET-AIR FILTER(FRONT)	TATA spare parts
278909136305	RESERVOIR (AIR INTAKE)	TATA spare parts
278909137502	GROMMET (AIR RESERVIOR)	TATA spare parts
278909138001	SELF TAPPING SCREW	TATA spare parts
278909138602	WASHER (AIR FILTER ARRANGEMENT)	TATA spare parts

278909139902	O RING	TATA spare parts
278909139903	AIR INLET DUCT	TATA spare parts
278909139908	ASSY. INTAKE DUCT (SPRINT)	TATA spare parts
278909139915	PLUG(AIR FILTER)	TATA spare parts
278914100101	ASSY.INTAKE MANIFOLD	TATA spare parts
278914100102	ASSY.THROTTLE VALVE	TATA spare parts
278914100106	ASSY.SWIRL ACTUATOR	TATA spare parts
278914100108	ASSY.BRACKET(FOR ENGINE COVER MTG.)	TATA spare parts
278914100110	ASSY BRACKET (VACCUUM RESERVOIR MOUNTING)	TATA spare parts
278914100111	ASSY. INTAKE MANIFOLD (BS-3)	TATA spare parts
278914100112	ASSY. INTAKE MANIFOLD	TATA spare parts
278914100115	ASSY.INTAKE MANIFOLD W/SWIRL ACTUATOR-EU	TATA spare parts
278914100116	ASSY.INTAKE MANIFOLD W/SWIRL ACTUATOR-EU	TATA spare parts
278914100119	ASSY. INTAKE MANIFOLD (BS4)	TATA spare parts
278914100123	ASSY.THROTTLE VALVE (ELECTRONIC)	TATA spare parts
278914100127	ASSY. BRACKET (INTAKE MANIFOLD TO EGR CO	TATA spare parts
278914100135	ASSY.VACUUM HOSE(VACUUM LINE TO SOLENOID)	TATA spare parts
278914100137	ASSY BRACKET INTAKE PIPE SUPPORT	TATA spare parts
278914100138	INTAKE MANIFOLD ASSY	TATA spare parts
278914100148	THROTTLE BODY ASSY BS6	TATA spare parts
278914100152	TIFFENER ASSY INTAKE ADAPTER BS6	TATA spare parts
278914103303	BRACKET (VACCUM RESERVOIR/ NRV MTG.)	TATA spare parts
278914103304	BRACKET (VACCUM RESERVOIR/ NRV MTG-XENO	TATA spare parts
278914103305	BRACKET (VACUUM RESERVOIR MOUNTING	TATA spare parts
278914103307	BRACKET (VACCUM RESERVOIR MOUNTING)	TATA spare parts
278914103311	BRACKET (INTAKE MANIFOLD TO EGR COOLER)	TATA spare parts
278914103315	BRACKET EGR VALVE MTG	TATA spare parts
278914103318	BRACKET WIRING HARNESS MTG FRONT	TATA spare parts
278914103319	BRACKET, WIRING HARNESS MTG	TATA spare parts
278914103701	ADAPTER EGR VALVE MTG	TATA spare parts
278914103802	INTAKE PIPE	TATA spare parts
278914103805	INTAKE MANIFOLD	TATA spare parts
278914103806	INTAKE PIPE	TATA spare parts
278914103817	INTAKE MANIFOLD	TATA spare parts
278914103818	INTAKE ADAPTOR	TATA spare parts
278914103822	INTAKE ADAPTOR	TATA spare parts
278914103830	TC INTAKE ADAPTOR	TATA spare parts
278914103835	FLANGE PIPE-AL CAST(LET(320N-M/150PS)	TATA spare parts
278914103838	ADAPTER	TATA spare parts
278914103839	INTAKE MANIFOLD	TATA spare parts
278914103845	INTAKE MANIFOLD	TATA spare parts
278914103846	INTAKE ADAPTER BS6	TATA spare parts
278914103847	INTAKE ADAPTER	TATA spare parts
278914103848	ADAPTER TURBOCHARGER TO AIR FILTER HOSE	TATA spare parts
278914103849	ADAPTER TURBOCHARGER TO AIR FILTER HOSE	TATA spare parts
278914105302	GASKET-INTAKE MANIFOLD TO PIPE	TATA spare parts
278914105305	GASKET INTAKE MANIFOLD	TATA spare parts

278914105306	GASKET(ADAPTOR INTERCOOLER PIPE)	TATA spare parts
278914105309	GASKET (INTAKE MANIFOLD TO INTAKE ADAPTO	TATA spare parts
278914105310	GASKET (AIR INTAKE SCOOP TO TURBOCHARGER	TATA spare parts
278914105312	GASKET(INTAKE ADAPTOR) BS4	TATA spare parts
278914105313	GASKET AIR INTAKE SCOOP TO TURBOCHARGER	TATA spare parts
278914105314	GASKET THROTTLE BODY TO INTAKE ADAPTER	TATA spare parts
278914105801	RUBBER HOSE (INTAKE THROTTLE)	TATA spare parts
278914105818	HOSE-OUTLET PR.TUBE TO SENSOR	TATA spare parts
278914105820	HOSE (VACUUM LINE TO SOLENOID VALVE)	TATA spare parts
278914105821	HOSE (EVRV TO EGR VALVE)	TATA spare parts
278914105827	HOSE	TATA spare parts
278914110103	ASSY.HEAT SHIELD (TURBOCHARGER)	TATA spare parts
278914110105	ASSY.HEAT SHIELD (CYL. HEAD SIDE)	TATA spare parts
278914110106	ASSY.EGR VALVE (PNEUMATIC)	TATA spare parts
278914110108	ASSY.EGR PIPE(EXH.MANI.TO EGR VALVE)	TATA spare parts
278914110109	ASSY.EGR PIPE(EGR VALVE TO INTAKE PIPE)	TATA spare parts
278914110110	ASSY.EGR COOLER	TATA spare parts
278914110114	ASSY.BRACKET-VACUUM MODULATOR MTG.	TATA spare parts
278914110115	ASSY. EGR PIPE (EGR COOLER TO INTAKE PIP	TATA spare parts
278914110116	ASSY. EGR PIPE (MANIFOLD TO EGR VALVE)	TATA spare parts
278914110122	ASSY.EGR PIPE(ADAPTOR TO INTAKE PIPE)	TATA spare parts
278914110123	ASSY.EGR PIPE(EGR VALVE TO INTAKE PIPE)	TATA spare parts
278914110124	ASSY. TUBE VACCUM TO EVRV	TATA spare parts
278914110125	ASSY. TUBE EVR VENT	TATA spare parts
278914110128	ASSY. BRACKET (VACUUM MODULATOR PIPE MTG	TATA spare parts
278914110129	ASSY. TUBE VACCUM TO EVR	TATA spare parts
278914110130	ASSY. TUBE EVR VENT	TATA spare parts
278914110131	VACUUM HOSES (VACUUM RESERVOIR)	TATA spare parts
278914110134	BRACKET (VENT HOSE EVRV)	TATA spare parts
278914110138	HEAT SHIELD (EXHAUST MANIFOLD)	TATA spare parts
278914110145	ASSY. TUBE VACCUM TO EVRV	TATA spare parts
278914110147	ASSY. TUBE EVRV VENT COMPLETE	TATA spare parts
278914110164	VACUUM MODULATOR W/O FILTER BS3/4/6	TATA spare parts
278914110177	ASSEMBLY EGR VALVE (PNEUMATIC)	TATA spare parts
278914110178	VACUUM MODULATOR W/O FILTER	TATA spare parts
278914110182	ASSY. EGR COOLER W/VALVE & BY PASS BS3/4	TATA spare parts
278914110183	ASSY.EGR OUTLET PIPE	TATA spare parts
278914110185	ASSY.INLET EGR PIPE	TATA spare parts
278914110195	ASSY. REAR LIFTING HOOK AND EVRV BRACKET	TATA spare parts
278914110199	CC DOC AND CDPF ASSY WITH HEAT SHIELD	TATA spare parts
278914110201	CC DOC+DPF WITH BRACKET	TATA spare parts
278914110240	ASSY.EXHAUST PRESSURE LINES(P.D.SENSOR)	TATA spare parts
278914110245	ASSY. CC DOC+CDPF WITHOUT BRACKET	TATA spare parts
278914110246	ASSY DOC+CDPF BRACKET	TATA spare parts
278914110247	DPF HEAT SHIELD	TATA spare parts
278914110248	HEAT SHIELD REAR (EXHAUST MANIFOLD)	TATA spare parts
278914110249	HEATSHIELD(EXHAUSTMANIFOLD)	TATA spare parts

278914110255	XENON DPF HEAT SHIELD 1	TATA spare parts
278914110256	ASSY. EVRV VENT TUBE BS4	TATA spare parts
278914110258	ASSY CC DOC+CDPF WITH HEAT SHIELD	TATA spare parts
278914110259	XENON DPF HEAT SHIELD 2	TATA spare parts
278914110260	XENON DPF HEAT SHIELD 3	TATA spare parts
278914110261	XENON DPF HEAT SHIELD 4	TATA spare parts
278914110284	ASSEMBLY INTERMEDIATE BRACKET(CCC SUPPOR	TATA spare parts
278914110297	ASSY. CC CATCON WITH HEAT SHIELD+MTG.BKT	TATA spare parts
278914110301	ASSY. CC (DOC+DOC) WITH HEAT SHIELD+BKT	TATA spare parts
278914110312	CATALYTIC CONVERTER ASSY WITH H.S	TATA spare parts
278914110316	ASSY. CATALYTIC CONVERTER EURO4	TATA spare parts
278914110322	ASSY VACCUM HOSE FOR EGR	TATA spare parts
278914110323	EGR VALVE ASSY	TATA spare parts
278914110324	ASSY VACCUM HOSE FOR TC	TATA spare parts
278914110331	EGR COOLER ASSY	TATA spare parts
278914110343	CLOSE COUPLED CATCON ASSY	TATA spare parts
278914110344	CLOSE COUPLED CATCON ASSY	TATA spare parts
278914110345	EGR PIPE ASSY EGR VALVE TO INTAKE PIPE	TATA spare parts
278914110346	EGR MODULE ASSY	TATA spare parts
278914110355	EGR MODULE ASSY	TATA spare parts
278914110358	CLOSE COUPLED CATCON ASSY	TATA spare parts
278914110360	HEAT SHIELD TURBOCHARGER	TATA spare parts
278914110364	BRACKET ASSY VACUUM MODULATOR MTG	TATA spare parts
278914110365	EXHAUST PRESSURE PIPE ASSY PD SENSOR BS6	TATA spare parts
278914110367	BRACKET ASSY PRESSURE SENSOR MTG BS6	TATA spare parts
278914110368	EXHAUST PRESSURE PIPE ASSY PD SENSOR	TATA spare parts
278914110370	LNT & CDPF ASSY	TATA spare parts
278914110371	LNT & CDPF ASSY BS6	TATA spare parts
278914110372	EGR PIPE ASSY EXH MANIFOLD TO EGR COOLER	TATA spare parts
278914110373	EGR PIPE ASSY COOLER TO AIR INTAKE ELBOW	TATA spare parts
278914110374	EGR PIPE ASSY EGR COOLER TO INTAKE ELBOW	TATA spare parts
278914110375	HOSE ASSY AIR FILTER HOSE TO EVRV	TATA spare parts
278914110377	BRACKET NOX SENSOR MTG BS6-PH2	TATA spare parts
278914110381	HEAT SHIELD ASSY EXHAUST MANIFOLD REAR	TATA spare parts
278914110382	HEAT SHIELD ASSY EXHAUST MANIFOLD FRONT	TATA spare parts
278914110390	DOC & CDPF ASSY BS6-PH2	TATA spare parts
278914111625	HEAT SHIELD ON CCC AIR FILTER PROTECTION	TATA spare parts
278914111646	GASKET (EGR VALVE TO EGR COOLER)	TATA spare parts
278914113307	BRACKET(VACUUM MODULATOR PIPE)	TATA spare parts
278914113309	BRACKET (FOR EVR ROUTING)	TATA spare parts
278914113310	BRACKET (VENT HOSE EVRV)	TATA spare parts
278914113318	BRACKET (AIR FILTER TO TC EVRV HOSE)	TATA spare parts
278914113331	BRACKET (VENT TUBE MTG. BOOSTER SIDE)	TATA spare parts
278914113346	BRACKET (FOR ASSY. VENT ON A/F HOSE)	TATA spare parts
278914113347	TURBOCHARGER HEAT SHIELD	TATA spare parts
278914113368	BRACKET (VENT TUBE MTG. RESERVIOR SIDE)	TATA spare parts
278914113378	BKT1 HOSE(SOLENOID TO VACUUM LINE) MTG	TATA spare parts



278914113379	BKT2 HOSE(SOLENOID TO VACUUM LINE)MTG	TATA spare parts
278914113399	BRACKET EGR VALVE MTG	TATA spare parts
278914113701	EXHAUST MANIFOLD	TATA spare parts
278914113704	EXHAUST MANIFOLD	TATA spare parts
278914113705	EXHAUST MANIFOLD	TATA spare parts
278914113708	EXHAUST MANIFOLD	TATA spare parts
278914113709	BRACKET DPF MTG BS6	TATA spare parts
278914113710	BRACKET DPF MTG	TATA spare parts
278914113711	BRACKET LNT & CPDF BS6	TATA spare parts
278914113712	BRACKET DPF MTG	TATA spare parts
278914113801	ADAPTOR - EGR VALVE MTG.	TATA spare parts
278914113803	CLOSING PLATE(EGR CIRCUIT)	TATA spare parts
278914114201	CLAMP (EVRV VACUUM HOSES)	TATA spare parts
278914114203	CLAMP-EVRV HOSE(FOR 1 HOSE)	TATA spare parts
278914115302	GASKET-EGR VALVE TO EGR COOLER	TATA spare parts
278914115303	GASKET EXHAUST MANIFOLD	TATA spare parts
278914115304	GASKET-EGR VALVE TO EGR COOLER BS4	TATA spare parts
278914115306	GASKET- EGR PIPE TO EGR COOLER/INTAKE	TATA spare parts
278914115308	GASKET-EGR COOLER TO EGR PIPE	TATA spare parts
278914115309	GASKET (EGR INLET PIPE TO EGR VALVE)	TATA spare parts
278914115310	GASKET (EGR OUTLET PIPE TO EGR COOLER)	TATA spare parts
278914115311	GASKET (EXHAUST MANIFOLD TO TC INTAKE)	TATA spare parts
278914115313	GASKET (TC OUTLET TO DPF)	TATA spare parts
278914115320	GASKET EXHAUST MANIFOLD	TATA spare parts
278914115321	GASKET TC INTAKE TO EXHAUST MANIFOLD	TATA spare parts
278914115322	GASKET TC OUTLET TO DPF	TATA spare parts
278914115323	GASKET EGR PIPE FLANGE TO MANIFOLD	TATA spare parts
278914115324	GASKET EGR VALVE OUTLET	TATA spare parts
278914115801	HOSE EVRV VENT-1	TATA spare parts
278914115801AE	HOSE EVRV VENT-1 XEN DC XEN SC	TATA spare parts
278914115802	HOSE EVRV VENT -2	TATA spare parts
278914115802AE	HOSE EVRV VENT -2 XEN DC XEN SC	TATA spare parts
278914115803	HOSE EVRV VENT -3	TATA spare parts
278914115804	HOSE EVRV -1	TATA spare parts
278914115805	HOSE EVRV -2	TATA spare parts
278914115806	HOSE EVRV -3	TATA spare parts
278914115807	HOSE (EVR TO INTAKE THROTTLE)	TATA spare parts
278914115808	HOSE (TUBE TO NON RETURN VALVE)	TATA spare parts
278914115809	HOSE (EVR TO EGR VALVE)	TATA spare parts
278914115810	HOSE (EVR TO TURBOCHARGER)	TATA spare parts
278914115811	HOSE	TATA spare parts
278914115813	HOSE (VACUUM LINE TO NRV)	TATA spare parts
278914115814	HOSE (TEE CONNECTOR TO RESERVOIR)	TATA spare parts
278914115825	TC EVR HOSE (TC END)	TATA spare parts
278914115826	TC EVRV HOSE (EVRV END)	TATA spare parts
278914115827	EVRV HOSE (AIR FILTER END)	TATA spare parts
278914115834	HOSE (RESERVOIR TO EVRV)	TATA spare parts

278914115837	HOSE -VACUUM TO EVRV2	TATA spare parts
278914115838	HOSE - EVRV1 TO EGR VALVE	TATA spare parts
278914115839	TC EVRV HOSE (EVRV END)	TATA spare parts
278914115840	TC EVRV HOSE(TC END)	TATA spare parts
278914115841	HOSE EVRV TO TC	TATA spare parts
278914115842	HOSE (RESERVOIR TO EVRV)	TATA spare parts
278914115843	VACUUM HOSE (VACUUM LINE TO NRV)	TATA spare parts
278914115844	VACUUM HOSE (NRV TO T CONNECTOR)	TATA spare parts
278914115845	VACUUM HOSE (VACUUM LINE TO NRV)	TATA spare parts
278914115847	VACCUM HOSE (VACCUM LINE TO NRV)	TATA spare parts
278914115848	HOSE (RESERVOIR TO EVRV)	TATA spare parts
278914115865	HOSE (NYLON PIPE TO A/F)	TATA spare parts
278914115870	HOSE (EVRV TO VACUUM RESERVOIR)	TATA spare parts
278914115871	VACUUM HOSE (VACUUM LINE TO NRV)	TATA spare parts
278914115883	HOSE (EGR TO VACCUM SOLENOID VALVE)	TATA spare parts
278914115897	HOSE-INTAKE PR TUBE TO SENSOR	TATA spare parts
278914115898	HOSE-DPF INLET TO TUBE ASSY	TATA spare parts
278914115899	HOSE-DPF OUTLET TO TUBE ASSY	TATA spare parts
278914116901	STIFFENER (EXHAUST MANIFOLD )	TATA spare parts
278914116903	TUBE (EVR TO TC)	TATA spare parts
278914116905	STIFFENER (EXHAUST MANIFOLD)	TATA spare parts
278914117702	FLEXIBLE SPLIT TUBE (CORRUGATED)	TATA spare parts
278914118205	HEAT SHIELD FOR T.C	TATA spare parts
278914118603	SPACER (SOLENOID MTG.)	TATA spare parts
278914118604	SPACER	TATA spare parts
278914118801	STUD (TURBOCHARGER)	TATA spare parts
278914119901	TRANSFER LABLE (ABSOP.COEFF.)	TATA spare parts
278914119910	HEATED LAMBDA SENSOR	TATA spare parts
278914119911	TEMPERATURE SENSOR TS200(DPF)	TATA spare parts
278914119914	DIFF.PRESSURE SENSOR	TATA spare parts
278914119915	SENSOR TEMPERATURE EXHAUST MANIFOLD	TATA spare parts
278914119916	STICKER-FUEL CONSUMPTION	TATA spare parts
278914119922	TRANSFER LABLE (ABSOP.COEFF.)(E-V)	TATA spare parts
278914119929	DOC BRICK(4IN) WITH 40 GM LOADING DOC	TATA spare parts
278914119931	STICKER FUEL CONSUMPTION	TATA spare parts
278914119956	LEAN NOX TRAP BRICK BS6-PH2	TATA spare parts
278914119961	DPF BRICK WITH LOADING BS6-PH2	TATA spare parts
278914119962	LEAN NOX TRAP BRICK	TATA spare parts
278914120103	LNT & CDPF ASSY BS6	TATA spare parts
278914120104	LNT & CDPF ASSY BS6	TATA spare parts
278914120105	BRKT PM & NOX SENSOR CONNECTOR MTG BS6-PH2	TATA spare parts
278914120107	BRACKET PM SENSOR CONNECTOR MTG BS6-PH2	TATA spare parts
278914120109	SCR ASSY BS6-PH2	TATA spare parts
278914120113	LNT & CDPF ASSY BS6	TATA spare parts
278914120116	LNT & CDPF ASSY BS6-PH2	TATA spare parts
278914120121	LNT & CDPF ASSY	TATA spare parts
278914120131	LNT & CDPF ASSY BS6-PH2	TATA spare parts

278914123304	BRACKET LAMBDA SENSOR CONNECTOR MTG BS6	TATA spare parts
278914123306	BRACKET EVRV HOSE MTG BS6	TATA spare parts
278914125811	HOSE -VACUUM TO EVRV2	TATA spare parts
278914125812	HOSE-EVRV1 TO EGR VALVE	TATA spare parts
278914125813	TC EVRV HOSE (EVRV END)	TATA spare parts
278914125815	HOSE EVRV VENT-1	TATA spare parts
278914125816	HOSE EVRV VENT -2	TATA spare parts
278914125817	HOSE EVRV VENT -3 (VAMAC)	TATA spare parts
278914125818	HOSE EVRV-1 (VAMAC) (B)	TATA spare parts
278914125819	HOSE EVRV-2 (VAMAC) (B)	TATA spare parts
278914125820	HOSE EVRV-3	TATA spare parts
278914125821	HOSE (EVR TO INTAKE THROTTLE) VAMAC	TATA spare parts
278914125823	HOSE (EVR TO EGR VALVE)VAMAC (B)	TATA spare parts
278914125824	HOSE EVRV (AIR FILTER END)	TATA spare parts
278914125826	VACUUM HOSE (NRV TO T CONNECTOR)	TATA spare parts
278914125829	HOSE (RESERVOIR TO EVRV)	TATA spare parts
278914125830	HOSE (RESERVOIR TO EVRV)VAMAC	TATA spare parts
278914125831	VACUUM HOSE (VACUUM LINE TO NRV)VAMAC	TATA spare parts
278914125832	VACUUM HOSE (VACUUM LINE TO NRV)	TATA spare parts
278914125833	HOSE (TEE CONNECTOR TO RESERVOIR)	TATA spare parts
278914125846	HOSE (EVRV TO NYLON TUBE)	TATA spare parts
278914125847	VACUUM HOSE (NRV TO T-CONNECTOR)	TATA spare parts
278914125849	HOSE (EVRV TO EGR)VAMAC (B)	TATA spare parts
278914125851	TC EVR HOSE (TC END) VAMAC (B)	TATA spare parts
278914125880	HOSE DPF INTAKE TO TUBE ASSY	TATA spare parts
278914125881	HOSE DPF OUTLET TO TUBE ASSY	TATA spare parts
278914135801	HOSE SOLENOID VALVE TO EGR VALVE	TATA spare parts
278914135802	HOSE EVRV TO TURBOCHARGER	TATA spare parts
278914135803	HOSE EVRV TO CONNECTOR	TATA spare parts
278914135804	HOSE SOLENOID TO RESERVOIR	TATA spare parts
278914135805	HOSE SOLENOID TO RESERVOIR BS6	TATA spare parts
278914135806	HOSE EVRV TO CONNECTOR BS6	TATA spare parts
278914135807	HOSE INTAKE PRESSURE TUBE TO SENSOR BS6	TATA spare parts
278914135808	HOSE OUTLET PRESSURE TUBE TO SENSOR BS6	TATA spare parts
278914135809	HOSE DPF INTAKE TO TUBE ASSY BS6	TATA spare parts
278914135810	HOSE DPF OUTLET TO TUBE ASSY BS6	TATA spare parts
278914135811	HOSE EVRV TO CONNECTOR BS6	TATA spare parts
278914135812	HOSE EVRV TO TURBOCHARGER BS6	TATA spare parts
278914135813	VACUUM HOSE CONNECTOR TO NRV BS6	TATA spare parts
278914135816	HOSE INTAKE PRESSURE TUBE TO SENSOR	TATA spare parts
278914135817	HOSE OUTLET PRESSURE TUBE TO SENSOR	TATA spare parts
278914135818	HOSE DPF OUTLET TO TUBE ASSY	TATA spare parts
278914135819	HOSE DPF INTAKE TO TUBE ASSY	TATA spare parts
278914135821	HOSE NRV TO VACUUM T-CONNECTOR	TATA spare parts
278914135826	HOSE NRV TO T-CONNECTOR BS6	TATA spare parts
278914135827	HOSE T-CONNECTOR TO TUBE BS6	TATA spare parts
278914135832	HOSE EVRV TO CONNECTOR BS6	TATA spare parts

278914135833	HOSE EVRV TO CONNECTOR BS6	TATA spare parts
278914135834	HOSE T-CONNECTOR TO SOLENOID VALVE BS6	TATA spare parts
278914135835	HOSE T-CONNECTOR TO SOLENOID VALVE BS6	TATA spare parts
278914135857	VACUUM HOSE NRV TO CONNECTOR BS6	TATA spare parts
278914135858	HOSE NRV TO T-CONNECTOR BS6	TATA spare parts
278914510101	ASSY. TURBOCHARGER BS3/4	TATA spare parts
278914510102	ASSY.CLOSE CAT. CONVERTER	TATA spare parts
278914510103	ASSY.BRACKET-TC HEAT SHIELD BLOCKSIDE	TATA spare parts
278914510105	CLOSE CONVERTER ASSY (2.2 L DICR SPRINT)	TATA spare parts
278914510111	ASSY.CLOSE CAT. CONVERTER	TATA spare parts
278914510129	ASSY.CLOSE CAT.CON. FOR XENON BS-III	TATA spare parts
278914510135	ASSY. TURBOCHARGER BS3/4	TATA spare parts
278914510143	ASSY. TURBOCHARGER W/WASTE GATE BS4	TATA spare parts
278914510154	ASSY CLOSE CONVERTOR	TATA spare parts
278914510165	TURBOCHARGER ASSY	TATA spare parts
278914515303	RASKET-TURBOCHARGER INLET	TATA spare parts
278914515304	GASKET-TURBOCHARGER OUTLET	TATA spare parts
278914515305	GASKET-TURBOCHARGER (WASTE GATE) OUTLET	TATA spare parts
278914515801	RUBBER HOSE(TURBOCHARGER TO IC PIPE)	TATA spare parts
278914600102	ASSY.BRACKET-INTERCOOLER MTG.-LH	TATA spare parts
278914600103	ASSY.PIPE(IC TO INTAKE THROTTLE)	TATA spare parts
278914600104	ASSY.ADAPTOR - INTERCOOLER PIPE	TATA spare parts
278914600113	ASSY INTERCOOLER	TATA spare parts
278914600114	ASSY.PIPE (IC TO INTAKE THROTTLE-XENON)	TATA spare parts
278914600121	ASSY.PIPE(IC TO INTAKE ADAPTOR)	TATA spare parts
278914600122	ASSEMBLY PIPE(IC INTAKE)	TATA spare parts
278914600130	ASSY INTERCOOLER (E-V)XENON	TATA spare parts
278914600141	ASSY. BRACKET (INTAKE PIPE MOUNTING)	TATA spare parts
278914600143	ASSY. INATKE ADAPTOR	TATA spare parts
278914600167	PIPE ASSY INTERCOOLER OUTLET BS6	TATA spare parts
278914600168	PIPE ASSY TC TO INTERCOOLER BS6	TATA spare parts
278914600169	PIPE ASSY TC TO INTERCOOLER	TATA spare parts
278914600173	INTERCOOLER ASSY BS6	TATA spare parts
278914600178	PIPE ASSY TC TO INTERCOOLER BS6-PH2	TATA spare parts
278914600179	BRACKET ASSY TC TO IC PIPE MTG BS6-PH2	TATA spare parts
278914600181	PIPE ASSY TURBOCHARGER OUTLET BS6	TATA spare parts
278914600182	BRACKET ASSY TC TO IC PIPE MTG BS6-PH2	TATA spare parts
278914603806	PIPE-INTERCOOLER OUTLET	TATA spare parts
278914604201	CLAMP (WITH SPRING)	TATA spare parts
278914604204	HOSE CLAMP WITH SPRING(DIA 40-60)NORMA	TATA spare parts
278914605803	RUBBER HOSE (IC INLET/OUTLET)	TATA spare parts
278914605805	RUBBER HOSE (INTER COOLER OUTLET)	TATA spare parts
278914605806	HOSE (TC TO IC)	TATA spare parts
278914605808	HOSE ( T.C. TO I.C.)	TATA spare parts
278914605815	HOSE INTERCOOLER INTAKE	TATA spare parts
278914605816	HOSE INTERCOOLER TO PIPE	TATA spare parts
278914605817	HOSE ADAPTER TO IC PIPE	TATA spare parts

278914605818	HOSE (IC INLET PIPE TO IC)	TATA spare parts
278914605819	HOSE (TC TO IC INLET PIPE)	TATA spare parts
278914605821	HOSE(IC OUTLET PIPE TO THROTTLE)	TATA spare parts
278914605830	HOSE INTERCOOLER OUTLET	TATA spare parts
278914605848	HOSE IC OUT PIPE TO ASSY. INTAKE ADAPTOR	TATA spare parts
278914605851	HOSE	TATA spare parts
278914605852	HOSE	TATA spare parts
278914605879	HOSE INTERCOOLER TO PIPE	TATA spare parts
278914605880	HOSE ADAPTER TO INTERCOOLER PIPE	TATA spare parts
278914605882	HOSE IC PIPE TO THROTTLE BS6	TATA spare parts
278914605884	HOSE TC OUT TO INTERCOOLER PIPE BS6	TATA spare parts
278914605885	HOSE PIPE TO INTERCOOLER BS6	TATA spare parts
278914605890	HOSE PIPE ASSY TO IC	TATA spare parts
278914605891	HOSE TC TO PIPE ASSY	TATA spare parts
278914605892	HOSE IC OUTLET TO THROTTLE	TATA spare parts
278914605898	HOSE TC TO PIPE TC OUTLET BS6	TATA spare parts
278914605899	HOSE PIPE TC OUTLET TO PIPE IC INLET BS6	TATA spare parts
278914606305	DUCT INTERCOOLER BS6	TATA spare parts
278914606903	PIPE (T.C TO I.C.)	TATA spare parts
278914606921	INSERT TUBE (FOR IC PIPE MTG.)	TATA spare parts
278914607502	ISOLATOR (FOR IC PIPE MTG.)	TATA spare parts
278914609201	WASHER (IC PIPE MTG.)	TATA spare parts
278914609901	INTERCOOLER	TATA spare parts
278915100101	BRACKET ASSY HEAT SHIELD MTG	TATA spare parts
278915100102	HEAT SHIELD ASSY STARTER MOTOR BS6	TATA spare parts
278915100103	HEAT SHIELD ASSY STARTER MOTOR	TATA spare parts
278915135801	HOSE (VACUUM PUMP TO OIL SUMP)	TATA spare parts
278915135803	RUBBER HOSE VACUUM PUMP TO OIL SUMP BS6	TATA spare parts
278915143301	BRACKET-ALTERNATOR TENSIONER	TATA spare parts
278915143302	BRACKET ALTERNATOR MTG.	TATA spare parts
278915143701	BRACKET-ALTERNATOR & PSTG.PUMP MOUNTING	TATA spare parts
278915143801	BRACKET ALTERNATOR MTG	TATA spare parts
278915143802	BRACKET ALTERNATOR MTG BS6-PH2	TATA spare parts
278915144201	CLAMP CABLE ROUTING BS6-PH2	TATA spare parts
278915146301	BELT ALTERNATOR	TATA spare parts
278915146302	BELT ALTERNATOR BS6-PH2	TATA spare parts
278915200104	ECU LOADED WITH SOFTWARE	TATA spare parts
278915200108	ECU LOADED WITH SOFTWARE	TATA spare parts
278915200108AE	ECU LOADED WITH S/W -XEN DC/SC	TATA spare parts
278915200109	ECU LOADED WITH SOFTWARE	TATA spare parts
278915200140	ECU LOADED WITH SOFTWARE	TATA spare parts
278915200148	ECU LOADED WITH SOFTWARE	TATA spare parts
278915200151	ECU LOADED WITH SOFTWARE SAFARI 2.2 DICO	TATA spare parts
278915200154	ECU LOADED WITH SOFTWARE	TATA spare parts
278915200162	ECU BS4	TATA spare parts
278915200167	ECU LOADED WITH SOFTWARE	TATA spare parts
278915200285	ECU LOADED WITH SOFTWARE-XENON S.A E-II	TATA spare parts

278915200317	ECU LOADED WITH SOFTWARE - XENON EURO V	TATA spare parts
278915200351	ECU LOADED WITH SOFTWARE XENON OBD-II	TATA spare parts
278915200355	ECU LOADED WITH SOFTWARE	TATA spare parts
278915200362	ECU LOADED WITH SOFTWARE - XENON EURO V	TATA spare parts
278915200386	CONTAINER ASSY	TATA spare parts
278915200387	ECU LOADED WITH SOFTWARE - AUS E-V	TATA spare parts
278915201102	ECU ID FOR HOMOLOGATION - SAFARI BS III	TATA spare parts
278915201106	CALIBRATION SOFTWARE-XENON E-IV	TATA spare parts
278915230101	THROTTLE BODY ASSY BS6-PH2	TATA spare parts
278915400101	ASSY. T MAP SENSOR BS3/4	TATA spare parts
278915400103	ASSY. SIMAF SENSOR BS3/4	TATA spare parts
278915400103AE	ASSY. SIMAF SENSOR-XEN DC-XEN SC	TATA spare parts
278915400104	CAM SENSOR BS3/4	TATA spare parts
278915400105	FAN MOTOR ASSY. 1 - 2600 RPM	TATA spare parts
278915400106	FAN MOTOR ASSY. 2 - 3000 RPM	TATA spare parts
278915400111	ASSY SIMAF SENSOR	TATA spare parts
278916101204	CONTAINER ASSY	TATA spare parts
278916102002	CAMSHAFT SENSOR	TATA spare parts
278916102006	AIR MASS FLOW SENSOR BS6	TATA spare parts
278916102007	SENSOR EXHAUST TEMPERATURE BS6	TATA spare parts
278916102008	SENSOR EXHAUST TEMPERATURE BS6	TATA spare parts
278916102012	SENSOR UREA QUALITY BS6	TATA spare parts
278918100101	ASSY.OIL PUMP	TATA spare parts
278918100102	ASSY.OIL PUMP	TATA spare parts
278918105301	GASKET-OIL PUMP BS4	TATA spare parts
278918105302	GASKET OIL PUMP	TATA spare parts
278918130104	ASSY. OIL FILTER (-3 THREADS)	TATA spare parts
278918130104AE	OIL FILTER - XEN DC XEN SC	TATA spare parts
278918133201	ADAPTOR BOLT(OIL COOLER/OIL FILTER MTG.)	TATA spare parts
278918133802	ADAPTOR (OIL COOLER/OIL FILTER MTG.)	TATA spare parts
278918150101	ASSY.STRAINER	TATA spare parts
278918153801	STRAINER	TATA spare parts
278918155302	GASKET-OIL PUMP TO STRAINER	TATA spare parts
278918158207	BAFFEL STRAINER	TATA spare parts
278918170101	ASSY.OIL COOLER	TATA spare parts
278918170102	ASSY.PISTON COOLING NOZZLE	TATA spare parts
278918170104	ASSY.OIL FEEDER LINE(CYL.HEAD TO TC)	TATA spare parts
278918170105	ASSY.TUBE-TURBO OIL RETURN(SS BRAIDING)	TATA spare parts
278918170106	ASSY.PISTON COOLING NOZZLE	TATA spare parts
278918170108	ASSY.OIL COOLER	TATA spare parts
278918170109	ASSY. NOZZLE (PISTON COOLING)	TATA spare parts
278918170110	ASSY TUBE TURBO OIL RETURN	TATA spare parts
278918170114	ASSY. OIL COOLER (PN-NJ)	TATA spare parts
278918170119	ASSY.TC OIL FEEDER LINE	TATA spare parts
278918170120	ASSY TUBE TURBO OIL RETURN	TATA spare parts
278918170131	OIL RETURN PIPE ASSY TURBOCHARGER	TATA spare parts
278918170132	OIL FEEDER PIPE ASSY CYL HEAD TO TC	TATA spare parts

278918170133	OIL LINE ASSY BS6	TATA spare parts
278918170137	NOZZLE ASSY PISTON COOLING BS6	TATA spare parts
278918175302	GASKET-PISTON COOLING NOZZLE BS4	TATA spare parts
278918175304	GASKET-OIL FILTER ADAPTOR BS4	TATA spare parts
278918175304AE	GSKT-OIL FLTR ADPTR -XENON DC/SC	TATA spare parts
278918175307	GASKET TUBE TURBO OIL RETURN	TATA spare parts
278918175309	GASKET(ASSY. TC TUBE TO CYL. BLOCK) BS4	TATA spare parts
278918175310	GASKET (TC TO OIL RETURN TUBE)	TATA spare parts
278920100101	ASSY.WATER PUMP	TATA spare parts
278920100102	ASSY.WATER PUMP	TATA spare parts
278920100106	ASSY.WATER PUMP (KACO SEAL)	TATA spare parts
278920100106AE	ASSY.WATER PUMP (KACO SEAL)	TATA spare parts
278920100107	WATER PUMP ASSY	TATA spare parts
278920100109	WATER PUMP ASSY BS6	TATA spare parts
278920105301	GASKET-WATER PUMP BS4	TATA spare parts
278920105302	GASKET WATER PUMP	TATA spare parts
278920120102	ASSY.SPIDER HOSE	TATA spare parts
278920120106	ASSY.COOLANT PIPE(EGR/OIL COOLER RETURN)	TATA spare parts
278920120110	ASSY. CLAMP (COOLING PIPES)	TATA spare parts
278920120111	ASSY.PIPE-COOLANT BYPASS	TATA spare parts
278920120112	ASSY. THERMOSTAT HOUSING	TATA spare parts
278920120114	ASSY. VENT ADAPTOR	TATA spare parts
278920120123	ASSY THERMOSTAT HOUSING	TATA spare parts
278920120130	ASSEMBLY VENT ADAPTOR - INDICRUZ	TATA spare parts
278920120150	ASSY PIPE (COOLANT BYPASS)	TATA spare parts
278920120153	ASSY. PIPE (EGR COOLER TO BLOCK )SAFARI	TATA spare parts
278920120175	COOLANT ADAPTER ASSY,CYL BLOCK	TATA spare parts
278920120182	ASSY COOLANT PIPE (RADIATOR SIDE)	TATA spare parts
278920120195	ASSY COOLANT PIPE(ENGINE SIDE)	TATA spare parts
278920120196	COOLANT PIPE ENGINE SIDE(HD)	TATA spare parts
278920120199	ASSY.VENT TUBE (COOLANT PIPE TO RADIATOR	TATA spare parts
278920120206	VENT TUBE ASSY UCL TO RADIATOR	TATA spare parts
278920120207	HOSE ASSY COOLANT RETURN	TATA spare parts
278920120209	ASSY COOLANT PIPE ( EGR TO OIL RETURN)	TATA spare parts
278920120211	PIPE ASSY COOLANT RETURN	TATA spare parts
278920120212	THERMOSTAT ASSY	TATA spare parts
278920120215	HOSE ASSY EGR VALVE OUTLET	TATA spare parts
278920120216	THERMOSTAT ASSY	TATA spare parts
278920120218	SPIDER HOSE ASSY	TATA spare parts
278920120220	SPIDER HOSE ASSY	TATA spare parts
278920120223	VENT TUBE ASSY	TATA spare parts
278920120224	PIPE ASSY COOLANT RETURN	TATA spare parts
278920120227	PIPE ASSY COOLANT OUTLET BS6-PH2	TATA spare parts
278920120228	PIPE ASSY COOLANT RETURN BS6	TATA spare parts
278920120230	PIPE ASSY COOLANT RETURN BS6	TATA spare parts
278920120254	PIPE ASSY COOLANT RETURN BS6-PH2	TATA spare parts
278920120257	PIPE ASSY COOLANT RETURN BS6-PH2	TATA spare parts

278920120258	PIPE ASSY COOLANT RETURN BS6-PH2	TATA spare parts
278920120259	PIPE ASSY COOLANT RETURN BS6-PH2	TATA spare parts
278920120260	THERMOSTAT ASSY BS6-PH2	TATA spare parts
278920121605	GASKET-COOLANT ADAPTOR TO BLOCK	TATA spare parts
278920123301	BRACKET- WATER VALVE	TATA spare parts
278920123312	BRACKET (COOLANT PIPE TO MANIFOLD)	TATA spare parts
278920123313	BRACKET COOLANT PIPE TO MANIFOLD	TATA spare parts
278920123317	BRACKET, WIRING HARNESS MTG	TATA spare parts
278920123803	WATER OUTLET ELBOW(CYLINDER HEAD)	TATA spare parts
278920123804	COVER (THERMOSTAT HOUSING)	TATA spare parts
278920123811	COOLANT PIPE ENGINE(WITHOUT EC AND HD)	TATA spare parts
278920123815	ASSY PIPE COOLANT BYPASS	TATA spare parts
278920123816	COVER-THERMOSTAT HOUSING	TATA spare parts
278920123828	COOLANT ADAPTOR (ARIA)	TATA spare parts
278920123842	PIPE COOLANT OUTLET	TATA spare parts
278920123843	COVER THERMOSTAT BS6	TATA spare parts
278920123844	ADAPTER COOLANT	TATA spare parts
278920123845	PIPE COOLANT OUTLET BS6	TATA spare parts
278920124207	PIPE SEPERATOR CLIP	TATA spare parts
278920125305	GASKET-CYL.HEAD WATER OUTLET	TATA spare parts
278920125306	GASKET-ELBOW TO BYPASS PIPE	TATA spare parts
278920125310	GASKET- UC LINE TO ELBOW	TATA spare parts
278920125311	GASKET (THERMOSTAT HOUSING)	TATA spare parts
278920125316	GASKET (THERMOSTAT HOUSING)	TATA spare parts
278920125317	GASKET (COOLANT OUTLET TO BYPASS PIPE)	TATA spare parts
278920125318	GASKET CYL HEAD WATER OUTLET	TATA spare parts
278920125320	GASKET (BYPASS PIPE TO CYL. CRANKCASE)	TATA spare parts
278920125804	RUBBER HOSE (CRACKCASE TO OIL COOLER)	TATA spare parts
278920125808	RUBBER HOSE	TATA spare parts
278920125809	RUBBER HOSE-EGR/OIL COOLER TO THERMOSTAT	TATA spare parts
278920125810	RUBBER HOSE-BYPASS PIPE- THERMOSTAT HSG.	TATA spare parts
278920125815	RUBBER HOSE - (OIL COOLER OUTLET)	TATA spare parts
278920125816	RUBBER HOSE (EGR COOLER TO ADAPTOR)	TATA spare parts
278920125846	HOSE-EGR COOLER TO UCL PIPE	TATA spare parts
278920125853	HOSE(EGR COOLER TO COOLANT RETURN PIPE)	TATA spare parts
278920125854	HOSE(OIL COOLER TO COOLANT RETURN PIPE)	TATA spare parts
278920125857	HOSE EGR COOLER INTAKE	TATA spare parts
278920125861	HOSE BY PASS PIPE TO COOLANT ADAPTOR	TATA spare parts
278920125862	HOSE COOLANT RETURN PIPE TO COOLANT ADAP	TATA spare parts
278920125866	HOSE (EGR COOLER INLET)	TATA spare parts
278920125868	HOSE (VENT TUBE TO COOLANT PIPE)	TATA spare parts
278920125872	HOSE(ENGINE OIL COOLER TO COOLANT RETURN	TATA spare parts
278920125873	HOSE(AT OIL COOLER-COOLANT RETURN PIPE)	TATA spare parts
278920125877	HOSE(BLOCK TO ENGINE OIL COOLER)	TATA spare parts
278920125878	HOSE (VENT ADAPTOR TO VENT TUBE)	TATA spare parts
278920125887	HOSE UCL TO VENT TUBE	TATA spare parts
278920125888	HOSE UCL TO EGR COOLER	TATA spare parts



278920125889	COOLANT PIPE HOSE	TATA spare parts
278920125890	HOSE (COOLANT TUBE TO PIPE)	TATA spare parts
278920125891	HOSE UCL TO EGR VALVE	TATA spare parts
278920125893	HOSE EGR COOLER TO TUBE	TATA spare parts
278920128001	BLEEDING SCREW (ON COOLANT RETURN HOSE)	TATA spare parts
278920129901	THERMOSTAT-88 SOT	TATA spare parts
278920129901AE	THERMOSTAT-88 SOT XEN DC XEN SC	TATA spare parts
278920129905	THERMOSTAT (EURO V) BS4	TATA spare parts
278920135816	HOSE EGR COOLER TO COOLANT RETURN PIPE	TATA spare parts
278920135817	HOSE UCL TO EGR COOLER	TATA spare parts
278920135819	HOSE EGR COOLER TO TUBE	TATA spare parts
278920135822	HOSE VENT ADAPTER TO VENT TUBE BS6	TATA spare parts
278922100101	ASSY. LIFTING HOOK	TATA spare parts
278922100109	ASSY LIFTING HOOK + WIRING HARNESS PARKI	TATA spare parts
278922100110	ASSY. BKT.(ENGINE COVER LH FR)	TATA spare parts
278922100112	ASSY BRACKET(LAMBDA SENSOR CONNECTOR PA	TATA spare parts
278922100118	LIFTING HOOK ASSY REAR	TATA spare parts
278922107104	LIFTING HOOK FRONT	TATA spare parts
278922107115	LIFTING HOOK FRONT LH BS6	TATA spare parts
278922123701	ENGINE MOUNTING ARM-LEFT	TATA spare parts
278922123702	ENGINE MOUNTING ARM-RIGHT	TATA spare parts
278922123703	ENGINE MOUNTING ARM (LEFT)	TATA spare parts
278922123704	ENGINE MOUNTING ARM (RIGHT)	TATA spare parts
278922123709	ENGINE MOUNTING ARM (LEFT)	TATA spare parts
278922123710	ENGINE MOUNTING ARM (RIGHT)	TATA spare parts
278922123711	ENGINE MOUNTING ARM-LEFT	TATA spare parts
278922123712	ENGINE MOUNTING ARM-RIGHT	TATA spare parts
278922123715	ENGINE MTG ARM LH	TATA spare parts
278922123717	ENGINE MTG ARM FRONT-RH	TATA spare parts
278922200103	ASSY BRACKET REAR(ENGINE COVER MTG.)	TATA spare parts
278922200104	ASSY. REAR LIFTING HOOK	TATA spare parts
278922200108	ASSY LIFTING HOOK(EURO-5)	TATA spare parts
278922200121	LIFTING HOOK ASSY REAR BS6	TATA spare parts
278922207101	LIFTING HOOK-REAR	TATA spare parts
278923113805	BRACKET ALTERNATOR & POWER STG PUMP MTG	TATA spare parts
278923113806	BRACKET POWER STEERING PUMP MTG	TATA spare parts
278923116302	6PK EPDM BELT-1155(ALT+PSTG)(GATES)	TATA spare parts
278923116302DF	BELT 6PK EPDM 1155L ALT/PSTG-WING/XEN2.2	TATA spare parts
278923116307	ALTERNATOR BELT	TATA spare parts
278923116307DF	BELT POWER STEERING PUMP-XENON 2.2L BS4	TATA spare parts
278923116311	BELT POWER STEERING PUMP	TATA spare parts
278923120105	ASSY. A/C COMPRESSOR BS3/4	TATA spare parts
278923120108	ASSY.A/C BRACKET WITH ROLLER	TATA spare parts
278923123301	BRACKET ALTERNATOR MTG	TATA spare parts
278923123705	BRACKET- A/C COMP. MTG.	TATA spare parts
278923123707	BRACKET- A/C COMP. MTG	TATA spare parts
278923123713	AC COMPRESSOR BRACKET (SV7H15)	TATA spare parts

278923123716	BRACKET (POWER STG. PUMP)	TATA spare parts
278923123724	BRACKET:COMPRESSOR & ALTERNATOR MNTG. (S)	TATA spare parts
278923123727	BRACKET AC COMPRESSOR MTG	TATA spare parts
278923123801	BRACKET (P/S PUMP(E-V))	TATA spare parts
278923123803	A/C COMPRESSOR ALTERNATOR BRACKET	TATA spare parts
278923123804	BRACKET ALTERNATOR A/C COMPRESSOR	TATA spare parts
278923123805	BRACKET-ALPOWERSTEERINGPUMPMTG	TATA spare parts
278923123814	BRACKET ALTERNATOR & COMPRESSOR MTG	TATA spare parts
278923126302	6PK EPDM BELT-875(A/C)(GATES)	TATA spare parts
278923126302DF	BELT 6PK EPDM 875MM L A/C-XENON 2.2L BS4	TATA spare parts
278923126305	6PK EPDM BELT-895(A/C)(GATES)(SUMO GRAND	TATA spare parts
278923126305DF	BELT 6PK EPDM 895MM L A/C-WINGER 2.2L BS	TATA spare parts
278923126318	BELT AC COMP BS6	TATA spare parts
278923128001	TENSIONING SCREW-AC COMPRESSOR	TATA spare parts
278924100102	ENGINE MOUNT FRONT	TATA spare parts
278924100103	ENGINE MOUNT FRONT	TATA spare parts
278924100108	FRONT MOUNT-RH(WITH HEAT SHIELD)	TATA spare parts
278924100110	FRAME,ENGINE MOUNT,FRONT (INC STIFF)	TATA spare parts
278924100111	A-MOUNT ARM ENGINE MTG	TATA spare parts
278924107101	SPACER-FRONT ENGINE MOUNT	TATA spare parts
278924200103	ASSY. ENGINE MOUNT REAR 4X2	TATA spare parts
278924200104	ASSY ENGINE MOUNT REAR 4X4	TATA spare parts
278924200107	GEARBOX MOUNT (MARK-II)	TATA spare parts
278924200109	GEAR BOX MOUNT 4X2 (INC STIFF)	TATA spare parts
278924200110	GEAR BOX MOUNT 4X4 (INC STIFF)	TATA spare parts
278942105101	FRONT S CAM SHAFT-LH	TATA spare parts
278942105102	FRONT S CAM SHAFT-RH	TATA spare parts
278949100101	ASSY.CAT.CONVERTER	TATA spare parts
278949100104	ASSY.CAT.CONVERTER (U.B.) SAFARI BS IV	TATA spare parts
278949100109	SCR & MIXER ASSY BS6-PH2	TATA spare parts
278949100116	SCR ASSY BS6-PH2	TATA spare parts
278949103303	BRACKET SENSOR MTG BS6-PH2	TATA spare parts
278949200105	DOSER PUMP UNIT ASSY BS6	TATA spare parts
278949200107	TUBE ASSY UREA INJ COOLING ENG SIDE BS6-	TATA spare parts
278949200122	TUBE ASSY UREA INJ COOLING VEH SIDE BS6-	TATA spare parts
278949205810	HOSE TUBE TO TUBE BS6-PH2	TATA spare parts
278949205812	HOSE TUBE ASSY TO UREA INJECTOR BS6-PH2	TATA spare parts
278949205813	HOSE UCL TO TUBE ASSY BS6-PH2	TATA spare parts
278949205814	HOSE UREA INJECTOR TO TUBE ASSY BS6-PH2	TATA spare parts
278949205815	HOSE TUBE ASSY TO COOLANT RETURN PIPE BS	TATA spare parts
278949205826	HOSE TUBE TO TUBE BS6-PH2	TATA spare parts
278950100103	ASSY.RECOVERY BOTTLE	TATA spare parts
278950100109	ASSY.RADIATOR WITH FAN SHROUD	TATA spare parts
278950100115	ASSY.UPPER COOLING PIPE	TATA spare parts
278950100119	2.2L DICR RADIATOR & FAN SHROUD ASSY	TATA spare parts
278950100128	ASSY. PIPE (UPPER COOLING)	TATA spare parts
278950100139	ASSY.RADIATOR VENT HOSE WITH "T" CONNECT	TATA spare parts

278950100139_NIU1	ASSY.RADIATOR VENT HOSE WITH T CONN	TATA spare parts
278950100140	ASSY PIPE (UPPER COOLING- EIII)	TATA spare parts
278950100144	RADIATOR AND FAN SHROUD ASSY (XENON)	TATA spare parts
278950100145	SUB ASSY. RADIATOR W/DRAIN PLUG BS3/4	TATA spare parts
278950100147	ASSY RECOVERY BOTTLE	TATA spare parts
278950100155	PRESSURE CAP(1.1 BAR-AUX.TANK)	TATA spare parts
278950100168	RADIATOR AND FAN SHROUD ASSEMBLY	TATA spare parts
278950100170	RADIATOR SUB ASSY	TATA spare parts
278950100172	HIGH SPEED MOTOR ASSY.WITH CONNECTOR	TATA spare parts
278950100173	LOW SPEED MOTOR ASSY. WITH CONNECTOR	TATA spare parts
278950100176	PRESSURE CAP (RADIATOR)	TATA spare parts
278950100179	ASSY RECOVERY BOTTLE	TATA spare parts
278950100185	CAP WITHOUT CHAIN	TATA spare parts
278950100192	ASSY.CAP (RADIATOR)	TATA spare parts
278950100199	ASSY. RADIATOR WINGER 2.2L DICR BS4	TATA spare parts
278950100206	FAN SHROUD ASSEMBLY	TATA spare parts
278950100207	RADIATOR SUB ASSY WITHOUT DRAIN PLUG (XE	TATA spare parts
278950100241	ASSY VENT-TUBE(E5)	TATA spare parts
278950100253	SUB ASSY. RADIATOR (WINGER) BS4	TATA spare parts
278950100255	FAN SHROUD ASSEMBLY (WINGER)	TATA spare parts
278950100256	ASSY.RECOVERY TANK WITH CAP AND OVER-FLO	TATA spare parts
278950100258	ASSY. BRACKET FILLER NECK MTG	TATA spare parts
278950100262	BKT ASSY VENT ADAPTER & HEATER HOSE MTG	TATA spare parts
278950100263	FILLER NECK COOLANT FILLING	TATA spare parts
278950100309	HOSE ASSY UC PIPE TO RADIATOR	TATA spare parts
278950100310	RADIATOR ASSY BS6	TATA spare parts
278950100311	RADIATOR&ASSY BS6	TATA spare parts
278950100312	FAN MOTOR SHROUD ASSY BS6	TATA spare parts
278950100313	FAN&MOTOR&ASSY BS6	TATA spare parts
278950100325	SEAL ASSY RADIATOR FRONT-RH BS6	TATA spare parts
278950100326	SEAL ASSY RADIATOR FRONT-LH BS6	TATA spare parts
278950100350	RADIATOR ASSY WITH FAN SHROUD & PWM UNIT	TATA spare parts
278950105804	HOSE-UPPER COOLING PIPE TO EGR COOLER	TATA spare parts
278950105805	HOSE-UPPER COOLING PIPE TO RADIATOR	TATA spare parts
278950105805AE	HOSE-UPP CLING TO RAD -XEN DC/SC	TATA spare parts
278950105806	HOSE-RADIATOR TO THERMOSTAT HSG.	TATA spare parts
278950105806AE	HOSE-RDTR T THERMO HSG-XEN DC/SC	TATA spare parts
278950105807	FILL HOSE RAD	TATA spare parts
278950105808	RAD VENT HOSE	TATA spare parts
278950105810	VENT HOSE (EGR COOLER)	TATA spare parts
278950105819	FILL HOSE RAD	TATA spare parts
278950105821	HOSE (FILLER NECK TO RECOVERY BOTTLE)	TATA spare parts
278950105823	VENT HOSE	TATA spare parts
278950105837	HOSE RECOVERY TANK	TATA spare parts
278950105839	RADIATOR VENT HOSE	TATA spare parts
278950105841	FILLER NECK HOSE	TATA spare parts
278950105849	HOSE (UCL TO RADIATOR)	TATA spare parts

278950105850	HOSE (RADIATOR TO THERMOSTAT)	TATA spare parts
278950105859	HOSE COOLANT (RADIATOR TO THERMOSTAT)	TATA spare parts
278950105860	RUBBER HOSE(UC LINE TO RADIATOR)	TATA spare parts
278950105884	HOSE ( RADIATOR TO VENT TUBE)	TATA spare parts
278950105886	HOSE (VENT TUBE TO FILLER NECK)	TATA spare parts
278950105888	HOSE (VENT TUBE TO FILLER NECK)	TATA spare parts
278950105889	RADIATOR FILL HOSE (WINGER)	TATA spare parts
278950105890	RADIATOR VENT HOSE (WINGER)	TATA spare parts
278950105891	HOSE RADIATOR TO THERMOSTAT	TATA spare parts
278950105892	HOSE UC LINE TO RADIATOR	TATA spare parts
278950105893	HOSE FILLER NECK TO HEATER HOSE	TATA spare parts
278950105894	HOSE VENT TUBE TO FILLER NECK	TATA spare parts
278950106310	RECOVERY BOTTLE	TATA spare parts
278950106901	VENT TUBE-RADIATOR CAP TO RECOVERY BOTTL	TATA spare parts
278950106902	OVERFLOW TUBE-RECOVERY BOTTLE	TATA spare parts
278950106903	DRAIN COCK FLOW TUBE	TATA spare parts
278950106904	SLEEVE (RADIATOR TOP MNT)	TATA spare parts
278950107502	RUBBER GROMETS (RADIATOR TOP MNT)	TATA spare parts
278950107503	RUBBER GROMMET (RADIATOR BOTTOM MOUNT)	TATA spare parts
278950107701	FILLER NECK	TATA spare parts
278950107703	FILLER NECK- BEHR	TATA spare parts
278950107704	GASKET RING	TATA spare parts
278950107713	RADIATOR FILLER NECK (WINGER)	TATA spare parts
278950107718	SEAL RADIATOR TOP BS6	TATA spare parts
278950108001	POINTED SCREW (RADIATOR MTG.)	TATA spare parts
278950109901	DRAIN PLUG (SHORT)	TATA spare parts
278950109902	DRAIN PLUG ASSY	TATA spare parts
278950109904	DRAIN PLUG ASSY - XENON	TATA spare parts
278950109905	VENT ADAPTOR (ON UCL)	TATA spare parts
278950109907	VENT ADAPTOR (ON UCL)	TATA spare parts
278950115801	HOSE RADIATOR TO THERMOSTAT	TATA spare parts
278950115803	HOSE RADIATOR TO THERMOSTAT BS6	TATA spare parts
278950115804	HOSE UCL TO RADIATOR BS6	TATA spare parts
278950115805	HOSE RADIATOR TO VENT TUBE BS6	TATA spare parts
278950115806	HOSE RADIATOR TO VENT PIPE	TATA spare parts
278950500101	ASSY.FAN SHROUD	TATA spare parts
278950500102	ASSY.FAN SHROUD	TATA spare parts
279001100105	ASSY.CYLINDER CRANKCASE (TURBO)	TATA spare parts
279001100111	ASSY.CYLINDER CRANKCASE	TATA spare parts
279001100117	ASSY.CYLINDER CRANKCASE(NON-LINERED)	TATA spare parts
279001103201	HEX.BOLT-FOR M.B.CAP	TATA spare parts
279001103708	CYLINDER LINER	TATA spare parts
279001103712	CYLINDER LINER	TATA spare parts
279001103714	CYLINDER LINER	TATA spare parts
279001104801	DOWEL 6H 6X10	TATA spare parts
279001104802	HOLLOW DOWEL 14H6X10.5X14	TATA spare parts
279001104803	HOLLOW DOWEL 8h6x6.5x8L	TATA spare parts

279001104805	PLUGGING PIN (FOR TURBO CRANKCASE)	TATA spare parts
279001107801	OIL SEAL-CRANKSHAFT-FRONT	TATA spare parts
279001107802	OIL SEAL-CRANKSHAFT-REAR	TATA spare parts
279001107803	OIL SEAL-CRANKSHAFT-FRONT	TATA spare parts
279001107804	OIL SEAL-CRANKSHAFT-REAR	TATA spare parts
279001107805	CRK. OIL SEAL FRT.	TATA spare parts
279001107807	OIL SEAL-CRANKSHAFT-REAR	TATA spare parts
279001107808	OIL SEAL-CRANKSHAFT-REAR	TATA spare parts
279001107809	OIL SEAL-CRANKSHAFT-FRONT	TATA spare parts
279001107810	OIL SEAL-CRANKSHAFT-FRONT	TATA spare parts
279001107811	OIL SEAL-CRANKSHAFT-REAR	TATA spare parts
279001107812	OIL SEAL-CRANKSHAFT-FRONT	TATA spare parts
279001109902	ADAPTOR-OIL FILTER	TATA spare parts
279001130109	ASSY SOCKET WITH TUBE	TATA spare parts
279001135309	OIL SUMP GASKET 1 THK	TATA spare parts
279001135310	OIL SUMP GASKET 1 THK BS4	TATA spare parts
279001135311	OIL SUMP GASKET 1 THK	TATA spare parts
279001139201	SEAL WASHER OIL SUMP DRAIN	TATA spare parts
279001140102	TIMING COVER RR LH BTM-D	TATA spare parts
279001140103	TIMING COVER-RR RH TOP-D	TATA spare parts
279001140104	TIMING COVER RR TOP	TATA spare parts
279001140105	TIMING COVER RR RH BOTTOM	TATA spare parts
279001140108	FRT CVR LOWER TIMING CVR	TATA spare parts
27900114011120	ASSY.COVER (TIMING BELT-FRONT)	TATA spare parts
279001140112	ASSY.TIMING COVER REAR - TOP (PLASTIC)	TATA spare parts
279001140113	ASSY.TIMING COVER REAR - LEFT (PLASTIC)	TATA spare parts
279001140114	ASSY. TIMING COVER REAR - RIGHT	TATA spare parts
279001140115	ASSY REAR COVER CRANKCASE WITH OIL SEAL	TATA spare parts
279001143201	SHOULDER BOLT (FOR TIMING COVER)	TATA spare parts
279001143503	INSERT (FOR TIMING COVERS REAR-PLASTIC)	TATA spare parts
279001143801	REAR COVER CRANKCASE	TATA spare parts
279001143802	REAR COVER CRANKCASE-HOLLOW DOWEL	TATA spare parts
279001143803	FRONT TIMING COVER (BOTTOM)	TATA spare parts
279001145301	GASKET RR COVER CRANKCASE	TATA spare parts
279001145302	GASKET RR COVER CRANKCASE CAF	TATA spare parts
279001145303	GASKET(REAR COVER CRANKCASE)	TATA spare parts
279001146901	INSERT TUBE (FOR MTG.TIMING COVER)	TATA spare parts
279001146902	INSERT TUBE(FOR TIMING COVER MTG.)	TATA spare parts
279001147501	RUBBER BUFFER (FOR MTG.TIMING COVER)	TATA spare parts
279001147703	SEALING STRAP	TATA spare parts
279001147704	COVER TIMING BELT-FRONT	TATA spare parts
279001147707	SEALING STRAP	TATA spare parts
279001147708	COVER (TIMING BELT-FRONT)	TATA spare parts
279001148001	HEX.FLANGE SCREW M6X12	TATA spare parts
279001150101	ASSY.PRE-COMBUSTION CHAMBER W/H BALL(NA	TATA spare parts
279001150110	RUBBER BUSH CYL HEAD CVR	TATA spare parts
279001150113	ASSY. CAP (FOR CYL.HEAD COVER) BS1/2/3/4	TATA spare parts

279001150115	ENGINE COVER	TATA spare parts
279001150116	BUFFER ENG.MTG.COVER	TATA spare parts
279001150120	ASSY.ADAPTOR (FOR VENT ON CYL.HEAD)	TATA spare parts
279001150123	ASSY.PRE-COMBUSTION CHAMBER W/H BALL(TC)	TATA spare parts
279001150124	ASSY.CYL.HEAD WITH VALVES & INJ.EURO-III	TATA spare parts
279001150139	ASSY CYLINDER HEAD WITH VALVES (TCIC)	TATA spare parts
279001150140	ASSY.CYLINDER HEAD WITHOUT VALVES (TCIC)	TATA spare parts
279001150145	ASSY.CYL.HEAD WITHOUT VALVES & INJECTORS	TATA spare parts
279001150156	ASSY.CYL.HEAD COVER-PLASTIC(NA/TC)ENGTEC	TATA spare parts
279001150157	ASSY.CYL.HEAD COVER-PLASTIC(TCIC)ENGTECH	TATA spare parts
279001150159	ASSY.CYL.HEAD W/O VALVES-NA (W/O REAR SE	TATA spare parts
279001150160	ASSY. CYL. HEAD W/VLV (W/O RR SEAL)BS1/3	TATA spare parts
279001150161	ASSY.CYL.HEADW/OVALVES-TCIC(W/OR.SEAL	TATA spare parts
279001150169	COVER ASSY,CYLINDER HEAD	TATA spare parts
279001153201	HEX.BOLT (FOR CYL.HEAD)	TATA spare parts
279001153401	VALVE SEAT INS INLET STD	TATA spare parts
279001153403	VALVE SEAT INSERT EXH STD	TATA spare parts
279001153406	VALVE SEAT INSERT-INLET(HIGHER HARDNESS)	TATA spare parts
279001153408	VALVE SEAT INSERT-EXH.(HIGHER HARDNESS)	TATA spare parts
279001153410	VALVE SEAT INSERT INLET NORMAL	TATA spare parts
279001153411	VALVE SEAT INSERT EXHAUST NORMAL	TATA spare parts
279001155308	GASKET (FOR CYL.HEAD COVER )	TATA spare parts
279001155319	GASKET - BAFFLE (CYLINDER HEAD COVER)	TATA spare parts
279001155320	CYL.HD.GASKET 1.6 DIESEL NEW	TATA spare parts
279001155322	CYL.HD.GASKET 1.8 DIESEL NEW	TATA spare parts
279001155324	GASKET-CYL.HEAD(1.7 THK.)(SOFT)	TATA spare parts
279001155325	GASKET-CYL.HEAD(1.8 THK.)(SOFT)	TATA spare parts
279001155326	GASKET (FOR CYL.HEAD COVER )	TATA spare parts
279001155327	GASKET-CYL.HEAD(1.5 THK.)(MLS)	TATA spare parts
279001155328	GASKET-CYL.HEAD(1.6 THK.)	TATA spare parts
279001155329	GASKET-CYL.HEAD(1.7 THK.)	TATA spare parts
279001155337	GASKET (CYL.HEAD COVER-PLASTIC)	TATA spare parts
279001155339	GASKET-CYL.HEAD (1.5 THK)(MLS)(ELRING)	TATA spare parts
279001155340	GASKET-CYL.HEAD (1.6 THK)(MLS)	TATA spare parts
279001155341	GASKET-CYL.HEAD(1.7 THK)(MLS)(ELRING)	TATA spare parts
279001155344	GASKET CYL HEAD COVER	TATA spare parts
279001156501	DOMED CAP NUT CYL.HEAD	TATA spare parts
279001156904	SPACER TUBE CYL.HD.COVER	TATA spare parts
279001156905	SPACER TUBE CYL.HD.COVER	TATA spare parts
279001156910	NIPPLE (FOR HEAD COVER & INLET MANIFOLD)	TATA spare parts
279001157714	OIL FILLING CAP(PLASTIC HD.COVER)	TATA spare parts
279001158202	CORE PLUG-10 DIA.	TATA spare parts
279001158805	STUD-FOR CYL.HD.COVER	TATA spare parts
279001158806	STUD (FOR CYL.HD.COVER)	TATA spare parts
279001158809	STUD CM8X32 (FOR MTG.EXH.MANIFOLD)(TCIC)	TATA spare parts
279001159201	WASHER (FOR CYL.HEAD BOLT	TATA spare parts
279001159202	SEALING WASHER CYL.HEAD	TATA spare parts

279001159203	SEALING WASHER-FOR CYL.HEAD COVER	TATA spare parts
279001159904	ADAPTOR VENT ON CYL.HEAD	TATA spare parts
279001159905	OIL CAP	TATA spare parts
279001160105	ASSY.INJECTOR-CYL.NO.1 2&3 (E-III)	TATA spare parts
279001160106	ASSY.INJECTOR CYL.NO.4 (E-III)	TATA spare parts
279001160108	ASSY.INJ.W/H NOZZLE HOLDER TC	TATA spare parts
279001160109	ASSY.INJ.CYL.NO.4(NLS)(E-III-TCIC)	TATA spare parts
279001169202	SEALING WASHER-INJECTOR	TATA spare parts
279001170101	DIPSTICK TUBE	TATA spare parts
279001170102	DIPSTICK ASSY.	TATA spare parts
279001179901	ADAPTOR(FORASSY.DIPSTICKTUBE) BS6	TATA spare parts
279001990106	ENGINE OVERHAUL SEAL-SUB KIT	TATA spare parts
279001990126	ASSY.HALF BLOCK (TC & TCIC)	TATA spare parts
279001990130	ENGINE OVERHAUL GASKET SUB-KIT (TC&TCIC)	TATA spare parts
279001990131	SUB KIT-SEAL ENGINE OVERHAUL BS1/3	TATA spare parts
279001990133	BARE ENGINE (EURO-III) (TCIC)	TATA spare parts
279001993701	COLLARED LINER FOR ACE	TATA spare parts
279001993701DFSF	CYLINDER LINER SET 275IDI-ACE STD SF	TATA spare parts
279003110105	ASSY.FLYWHEEL (HIGH INERTIA)(TCIC)	TATA spare parts
279003110107	FLYWHEEL ASSY.TCIC(HI.TA65*)BLIND HOLE	TATA spare parts
279003113201	HEX BOLT-FLY WHEEL	TATA spare parts
279003114801	DOWEL (FOR CLUTCH ON FLYWHEEL)	TATA spare parts
279003115401	RING GEAR	TATA spare parts
279003123111	MAIN BRG.HALF NORMAL (CRK.SHAFT)	TATA spare parts
279003123112	MAIN BRG.HALF NORMAL (CRK.SHAFT)	TATA spare parts
279003123114	MAIN BRG.HALF NORMAL(CRK.SHAFT)	TATA spare parts
279003123117	THRUST WASHER LOWER 69 DIA	TATA spare parts
279003123118	THRUST WASHER UPPER 69 DIA	TATA spare parts
279003123119	THRUST WASHER LOWER 69 DIA	TATA spare parts
279003123120	THRUST WASHER UPPER 69 DIA	TATA spare parts
279003123121	THRUST WASHER LOWER-69 DIA.	TATA spare parts
279003123122	THRUST WASHER UPPER-69 DIA.	TATA spare parts
279003123128	MAIN BRG.HALF NORMAL(LOWER-TC)	TATA spare parts
279003123133	MAIN BRG.HALF REP-I (CRK.SHAFT)	TATA spare parts
279003123139	MAIN BRG.HALF SHEEL (NORMAL)(LOWER)TCIC	TATA spare parts
279003130107	VIB DAMPER WITH AC PULLEY	TATA spare parts
279003130115	ASSY.INT.VIB.DAMPER (5-GROOVES)	TATA spare parts
279003133201	HEX.BOLT CRANKSHAFT GEAR	TATA spare parts
279003138601	WASHER C/SHAFT GEAR	TATA spare parts
279003140112	OIL RING	TATA spare parts
279003140116	SET PISTON GRADE A	TATA spare parts
279003140117	SET PISTON GRADE B	TATA spare parts
279003140118	SET PISTON GRADE C	TATA spare parts
279003140129	OIL CONTROL RING R.I.	TATA spare parts
279003140130	ASSY.OIL CONTROL RING RII	TATA spare parts
279003140132	ASSY.OIL RING (TURBO)	TATA spare parts
279003144303	CIRCLIP	TATA spare parts

279003144304	CIRCLIP (TC)	TATA spare parts
279003146610	PISTON GRADE-A (NORMAL)	TATA spare parts
279003146611	PISTON GRADE-B (NORMAL)	TATA spare parts
279003146612	PISTON GRADE-C (NORMAL)	TATA spare parts
279003146616	PISTON GRADE A (TC)	TATA spare parts
279003146617	PISTON GRADE B (TC)	TATA spare parts
279003146618	PISTON GRADE C (TC)	TATA spare parts
279003146620	PISTON GRADE-A RI	TATA spare parts
279003146623	PISTON GRADE-A RII	TATA spare parts
279003146703	PISTON PIN	TATA spare parts
279003146704	PISTON PIN	TATA spare parts
279003146706	PISTON PIN (FM)	TATA spare parts
279003149914	TAPERFACED RING	TATA spare parts
279003149918	TOP COMP RING	TATA spare parts
279003149920	MOLY SPRAYED KEYSTONE RING (TURBO)	TATA spare parts
279003149921	TOP RING MOLY COATED	TATA spare parts
279003149922	TOP COMP.RING GRADE A B C RII	TATA spare parts
279003149924	TAPER FACED RING RI	TATA spare parts
279003149925	TAPER FACED RING GRADE A B C RII	TATA spare parts
279003149936	TAPER FACED RING-TC (FM)	TATA spare parts
279003150106	CONNECTING ROD-D	TATA spare parts
279003150109	ASSY.CONNECTING ROD WITH BUSH	TATA spare parts
279003150112	ASSY.CONNECTING ROD W/O BRG.SHELL (TC)	TATA spare parts
279003153101	BRG.HALF NORMAL-CON.ROD	TATA spare parts
279003153104	BRG.HALF REP-I (CON.ROD)	TATA spare parts
279003153106	BRG.HALF NORMAL (CON.ROD-TC)	TATA spare parts
279003153203	BOLT-FOR CONNECTING ROD	TATA spare parts
279003153402	BRG.HALF NORMAL CON.ROD	TATA spare parts
279003153404	BRG.HALF NORMAL CON.ROD	TATA spare parts
279003153407	CONROD BUSH-BM-DIESEL	TATA spare parts
279003153408	CONNECTING ROD BUSH-CLINCH	TATA spare parts
279003153421	CONNECTING ROD BUSH-TC/TCIC (KIRLOSKAR)	TATA spare parts
279003153422	CONNECTING ROD BUSH	TATA spare parts
279003156501	NUT (FOR CONNECTING ROD)	TATA spare parts
279003990105	PISTON SET WITHOUT RINGS GRADE B	TATA spare parts
279003990110	SET PISTON RINGS	TATA spare parts
279003990117	SET THRUST WASHER(UPPER AND LOWER)	TATA spare parts
279003990118	SET THRUST WASHER(UPPER AND LOWER)	TATA spare parts
279003990168	SET CON-ROD BRG RS-1 BIMETAL	TATA spare parts
279003990169	SET BRG.HALF R-II (CON.ROD)	TATA spare parts
279003990171	SET MAIN BRG RS-1 BIMETAL	TATA spare parts
279003990172	SET MAIN BRG.HALF R-II	TATA spare parts
279003990174	SET MAIN BRG. UPPER/LOWER REP-I	TATA spare parts
279003990175	SET MAIN BRG.UPPER/LOWER REP-II	TATA spare parts
279003990179	SET PISTON W/O RINGS GRADE A	TATA spare parts
279003990180	PISTON W/O RINGS GRADE B	TATA spare parts
279003990181	PISTON W/O RINGS GRADE C	TATA spare parts



279003990182	SET PISTON RINGS	TATA spare parts
279003990184	SET MAIN BRG.NORMAL(UPP/LOWER-TC)	TATA spare parts
279003990185	SET MAIN BRG.NORMAL(UPP/LOWER-TC)	TATA spare parts
279003990187	SET BRG.HALF NORMAL(CON.ROD-TC)	TATA spare parts
279003990189	SET BRG.HALF NORMAL(CON.ROD-TC)	TATA spare parts
279005103201	HEX BOLT CAMSHAFT GR MTG	TATA spare parts
279005106501	NUT (FOR CAMSHAFT BRG.CAP	TATA spare parts
279005107808	OIL SEAL-CAMSHAFT-FRONT	TATA spare parts
279005107809	OIL SEAL CAM FRT	TATA spare parts
279005107810	OIL SEAL (CAMSHAFT REAR) BS1/2/3/4	TATA spare parts
279005107811	OIL SEAL-CAMSHAFT REAR	TATA spare parts
279005107812	OIL SEAL-CAMSHAFT-FRONT	TATA spare parts
279005107813	OIL SEAL (CAMSHAFT REAR)	TATA spare parts
279005107903	CAMSHAFT	TATA spare parts
279005107909	CAMSHAFT (TURBO)	TATA spare parts
279005110101	ASSY.TENSIONER (TIMING BELT)(OFFER DRG.)	TATA spare parts
279005110103	ASSYIDLER-FOR TIMING BELT	TATA spare parts
279005110104	ASSYIDLER-FOR TIMING BELT	TATA spare parts
279005110106	ASSYIDLER-FOR TIMING BELT	TATA spare parts
279005110107	ASSY CRANKSHAFT GEAR	TATA spare parts
279005110108	ASSYTENSIONER-TIMING BELT	TATA spare parts
279005110111	ASSY.TENSIONER (TIMING BELT)	TATA spare parts
279005110112	A.C.IDLER TIMING RIJ	TATA spare parts
279005110113	SET ASSY.IDLER-TIMING BELT	TATA spare parts
279005110116	SET ASSYIDLER PULLEY SINGLE BALLBRG	TATA spare parts
279005110117	SET ASSY.IDLER-FOR TIMING BELT	TATA spare parts
279005113202	EX.FLANGE BOLT M10X65	TATA spare parts
279005113202_NIU1	EX.FLANGE BOLT M10X65	TATA spare parts
279005115401	TIMING GEAR-CAMSHAFT	TATA spare parts
279005118201	STOPPER(CAMSHAFT GEAR)	TATA spare parts
279005118606	SPACER(TIMING BELT TENSIONER)CYLINDRICAL	TATA spare parts
279005119201	WASHER (FOR CAMSHAFT GEAR)	TATA spare parts
279005119202	WASHER (FOR TIMING BELT IDLER)	TATA spare parts
279005124301	LOCK HALF	TATA spare parts
279005124302	LOCK HALF	TATA spare parts
279005125104	INTAKE VALVE	TATA spare parts
279005125105	EXHAUST VALVE	TATA spare parts
279005125110	VALVE SPRING RETAINER	TATA spare parts
279005125111	INTAKE VALVE	TATA spare parts
279005125112	EXHAUST VALVE	TATA spare parts
279005125115	INTAKE VALVE	TATA spare parts
279005125116	EXHAUST VALVE	TATA spare parts
279005128201	SPRING SEAT	TATA spare parts
279005128701	VALVE SPRING	TATA spare parts
279005138301	SHIM 2.500 THK.	TATA spare parts
279005138302	SHIM	TATA spare parts
279005138303	SHIM	TATA spare parts

279005138304	SHIM	TATA spare parts
279005138305	SHIM	TATA spare parts
279005138306	SHIM	TATA spare parts
279005138307	SHIM 2.80	TATA spare parts
279005138308	SHIM	TATA spare parts
279005138309	SHIM 2.900 THK.	TATA spare parts
279005138310	SHIM 2.95	TATA spare parts
279005138311	SHIM 3.000 THK.	TATA spare parts
279005138312	SHIM 3.05 THK	TATA spare parts
279005138313	SHIM 3.10 THK	TATA spare parts
279005138314	SHIM	TATA spare parts
279005138315	SHIM 3.20	TATA spare parts
279005138316	SHIM 3.25 THK	TATA spare parts
279005138317	SHIM 3.30 THK	TATA spare parts
279005138318	SHIM 3.35 THK	TATA spare parts
279005138319	SHIM 3.400 THK.	TATA spare parts
279005138320	SHIM 3.45 THK	TATA spare parts
279005138321	SHIM 3.50 THK	TATA spare parts
279005138322	SHIM 3.550 THK.	TATA spare parts
279005138323	SHIM 3.60 THK	TATA spare parts
279005138324	SHIM 3.65 THK	TATA spare parts
279005138325	SHIM 3.70 THK	TATA spare parts
279005138326	SHIM 3.75 THK	TATA spare parts
279005138327	SHIM-3.80	TATA spare parts
279005138328	SHIM 3.85	TATA spare parts
279005138329	SHIM	TATA spare parts
279005138340	SHIM 3.025 THK * 12.5 OD	TATA spare parts
279005138341	SHIM 3.075 THK.	TATA spare parts
279005138342	SHIM 3.125 THK.	TATA spare parts
279005138343	SHIM 3.175 THK.	TATA spare parts
279005138344	SHIM 3.225 THK.	TATA spare parts
279005138345	SHIM 3.275 THK.	TATA spare parts
279005138346	SHIM 3.325 THK.	TATA spare parts
279005138347	SHIM 3.375 THK.	TATA spare parts
279005138348	SHIM 3.425 THK.	TATA spare parts
279005138349	SHIM 3.475 THK.	TATA spare parts
279005139903	TAPPET NORMAL	TATA spare parts
279005153701	VALVE GUIDE INLET NORMAL (OFFER DRG.)	TATA spare parts
279005153702	VALVE GUIDE INLET NORMAL-I (OFFER DRG.)	TATA spare parts
279005153703	VALVE GUIDE EXHAUST NORMAL	TATA spare parts
279005153704	VALVE GUIDE EXHAUST NORMAL-I (OFFER DRG)	TATA spare parts
279005157801	VALVE GUIDE SEAL BS1/2/3/4	TATA spare parts
279005157806	VALVE GUIDE SEAL (CR INDIA)	TATA spare parts
279007100105	ASSY.DISTRIBUTOR PUMP E-III	TATA spare parts
279007100114	ASSY.DISTRIBUTOR PUMP(E-III-TCIC)	TATA spare parts
279007100120	ASSY. F.I.C.D.	TATA spare parts
279007100125	DISTRIBUTOR PUMP ASSY(TCIC BS-III)DELPHI	TATA spare parts

279007103201	FIP BANJO BOLT	TATA spare parts
279007103203	FIP BANJO BOLT	TATA spare parts
279007103205	BANJO BOLT FIP	TATA spare parts
279007105801	HOSE (FOR BOOST SENSOR LINE TO FIP)	TATA spare parts
279007105804	HOSE FROM VSV TO VACUUM PUMP	TATA spare parts
279007106501	ADAPTOR-FOR 1IP GEAR	TATA spare parts
279007109201	FIP BANJO SEALING WASHER	TATA spare parts
279007109203	FIP BANJO SEALING WASHER	TATA spare parts
279007109907	SOLENOID 16 OHMS	TATA spare parts
279007109908	POTENTIOMETER	TATA spare parts
279007109909	ASSY PR REGULATOR+HOSE	TATA spare parts
279007120102	BRACKET-FRT FOR FIP-D	TATA spare parts
279007120106	ASSY.BRACKET-FRONT (FOR FIP)	TATA spare parts
279007123201	BOLT (FOR BKT.FRONT FIP)	TATA spare parts
279007123701	BRACKET FIP-MIDDLE	TATA spare parts
279007128001	HEX.FL.SCREW M10X18(MTG.FIP BKT.FR.)	TATA spare parts
279007128002	HEX.FL.SCREW M8X18 (MTG.FIP BKT.MID)	TATA spare parts
279007135401	TIMING GEAR (FIP) (SINTERED)	TATA spare parts
279007140109	H P LINE	TATA spare parts
279007146902	PLUG INJECTOR OVER FLOW NO.4	TATA spare parts
279007146904	RUBBER TUBE INJECTOR OVERFLOW 160 MM LG	TATA spare parts
279007146905	FLEXIBLE SPLIT TUBE (FOR FUEL HOSES)	TATA spare parts
279009110102	ASSY. FUEL FILTER BS1/2/3/4	TATA spare parts
279009110104	ASSY.FUEL FILTER	TATA spare parts
279009110109	ASSY.BANJO BOLT W/H AIR VENT SCREW	TATA spare parts
279009113201	FUEL FILTER BANJO BOLT	TATA spare parts
279009119201	FUEL FILTER SEALING WASHER	TATA spare parts
279009120106	FUEL RETURN LINE	TATA spare parts
279009120108	FUEL LINE FUEL FILT FIP	TATA spare parts
279009130101	ASSY AIR FILTER	TATA spare parts
279009130105	BRACKET-REAR A/FILT MTG	TATA spare parts
279009130107	ASSY AIR FILTER	TATA spare parts
279009130108	AIR FILTER ELEMENT	TATA spare parts
279009130109	ASSY. BUSH (FOR SNORKEL)	TATA spare parts
279009130110	ASSY.AIR FILTER	TATA spare parts
279009130113	ISOLATOR ASSY,AIR FILTER	TATA spare parts
279009130124	RUBBER HOSE (A.FILTER,RESONATOR&SNORKEL)	TATA spare parts
279009133301	BKT FRT LFTG HOOK&A/F MTG	TATA spare parts
279009135802	INTAKE HOSE A/FILT - SNRK	TATA spare parts
279009136301	SNORKEL	TATA spare parts
279009136305	RESONATOR BOX 2K2	TATA spare parts
279009136306	SNORKEL 2K2	TATA spare parts
279009137501	BUSH (FOR AIR FILTER MTG.	TATA spare parts
279009137508	ISOLATOR AIR FILTER	TATA spare parts
279009137704	RUBBER SLEEVE (IN FILTER FOR I.MANIFOLD)	TATA spare parts
279014105301	GASKET INLET MANIFOLD	TATA spare parts
279014105304	GASKET EGR VAL E2	TATA spare parts

279014105308	GASKET (INLET ELBOW TO INLET MANIFOLD)	TATA spare parts
279014105802	HOSE HD CVR TO INLET MANIFOLD	TATA spare parts
279014110101	ASSY.EGR VALVE	TATA spare parts
279014110105	A. EGR PIPE W CLM NLS (0108)	TATA spare parts
279014110108	EGR PIPE	TATA spare parts
279014110109	ASSY.CLAMP-V BAND	TATA spare parts
279014110115	ASSY.BRACKET (NLS CABLE & ENG.COVER MTG)	TATA spare parts
279014110116	ASSY.EGR VALVE	TATA spare parts
279014110117	ASSY.BRACKET (FOR NLS CABLE MTG.)	TATA spare parts
279014110129	ASSY.EGR TUBE (NA)(IAI)	TATA spare parts
279014110131	ASSY. CLAMP-V BAND (EGR PIPE)	TATA spare parts
279014110134	ASSY.VACUUM MODULATOR	TATA spare parts
279014113709	EXHAUST ELBOW (FOR TC)	TATA spare parts
279014115310	INTEG.GASKET(INL/EX.MANIFOLD)	TATA spare parts
279014115311	INT.GASKET(INL/EX.MANIFOLD)TCIC	TATA spare parts
279014115313	INT.GASKET(INL/EX.MANIFOLD) TCIC	TATA spare parts
279014115314	GASKET (FOR FLANGE ON EXH.MANIFOLD)	TATA spare parts
279014115802	HOSE ALT TO SOLO VAL EUROII	TATA spare parts
279014115803	HOSE(310)(T-CONNECTOR TO SOLENOID VALVE)	TATA spare parts
279014115804	HOSE(T-CONN.TO A/C ACT&ALT.TO T-CONN)110	TATA spare parts
279014116501	FLANGED CLINCH NUT (SUNDARAM)	TATA spare parts
279014117101	FLANGE (FOR EXHAUST MANIFOLD)	TATA spare parts
279014117701	PROTECTIVE SLEEVE(FOR V.SOLENOID VALVE)	TATA spare parts
279014118203	CLAMP (FOR NLS CABLE MOUNTING)	TATA spare parts
279014119901	SOLENOID VAC. VALVE	TATA spare parts
279014119902	T-CONNECTOR-VAC.CONNECT.TO EGR S.VALVE	TATA spare parts
279014119904	ASSY.VACUUM SOLENOID VALVE	TATA spare parts
279014515305	GASKET (FOR EXHAUST ELBOW)	TATA spare parts
279014515306	GASKET (TC INLET)	TATA spare parts
279014515309	GASKET (FOR TC INLET)	TATA spare parts
279014515310	GASKET (FOR EXHAUST ELBOW)	TATA spare parts
279014990101	DECARB KIT DIESEL	TATA spare parts
279015130102	OIL LINE	TATA spare parts
279015130103	ASSY.OIL LINE (TEFLON) (VACUUM PUMP INLE	TATA spare parts
279015133201	PIPE UNION BOLT	TATA spare parts
279015135801	RUBBER HOSE VACPUMP-SUMP	TATA spare parts
279015135802	HOSE V/PUMP TO OIL SUMP	TATA spare parts
279015135804	RUBBER HOSE (VACUUM PUMP TO OIL SUMP)	TATA spare parts
279015140107	BRACKET 75 AMP.ALTERNATOR	TATA spare parts
279015140110	BRACKET (ALTERNATOR)	TATA spare parts
279015140120	ASSY.CLAMP ROD (COMPLETE) 140 MM	TATA spare parts
279015146306	COGGED V BELT (725LG.)	TATA spare parts
279015146307	POLY-V BELT (4 GROOVES-720)	TATA spare parts
279015146310	POLY-V BELT (4 GROOVES-720)	TATA spare parts
279015146310DF	BELT POLY V-4 GROOVE 720-275IDI-ACE/MAGI	TATA spare parts
279015203801	BRACKET(FOR CRANK ANGLE SENSOR)	TATA spare parts
279015209905	CRANK ANGLE SENSOR (HONEYWELL)	TATA spare parts

279018100102	ASSY OIL PUMP	TATA spare parts
279018100104	ASSY OIL PUMP	TATA spare parts
279018100107	ASSY OIL PUMP	TATA spare parts
279018100111	ASSY.OIL PUMP (TURBO)	TATA spare parts
279018100113	ASSY. OIL PUMP (TURBO) BS3/4/6	TATA spare parts
279018100114	ASSY.OIL PUMP-TURBO(WITH BOSS)	TATA spare parts
279018100115	ASSY OIL PUMP	TATA spare parts
279018100118	ASSY.HEX.SCREW M6X25 (MTG.OIL PUMP)	TATA spare parts
279018100120	ASSY.OIL PUMP WITH STEEL BACK PLATE	TATA spare parts
279018100121	ASSY.OIL PUMP WITH STEEL BACK PLATE TCIC	TATA spare parts
279018104801	HOLLOW DOWEL 10H6X8.4X8L	TATA spare parts
279018105302	GASKET OIL PUMP	TATA spare parts
279018105303	GASKET-FOR STRAINER	TATA spare parts
279018105304	GASKET (ADAPTOR OIL RETURN)	TATA spare parts
279018105306	GASKET (OIL PUMP STRAINER)	TATA spare parts
279018105309	GASKET(FOR OIL PUMP)	TATA spare parts
279018130101	ASSY.OIL FILTER ACE gold	TATA spare parts
279018130101DF	OIL FILTER ELEMENT-ACE/MAGIC BS2/3/4/6	TATA spare parts
279018130102	OIL FILTER	TATA spare parts
279018130103	OIL FILTER ASSY (NA)	TATA spare parts
279018130106	ASSY.OIL FILTER-TC	TATA spare parts
279018130106DF	OIL FILTER ELEMENT-SUPER ACE/V20 BS3/4	TATA spare parts
279018130107	OIL FILTER ASSY	TATA spare parts
279018130108	OIL FILTER ASSY	TATA spare parts
279018150102	ASSY. STRAINER OIL PUMP	TATA spare parts
279018150106	ASSY.STRAINER (FOR OIL PUMP-TCIC)	TATA spare parts
279018159901	STRAINER MESH (FOR OIL PUMP STRAINER)	TATA spare parts
279018170103	OIL COOLER	TATA spare parts
279018170110	ASSY.NOZZLE PISTON COOLING (CASTING-TC)	TATA spare parts
279018170115	ASSY.OIL COOLER (8-PLATE) (VORAS)	TATA spare parts
279018170116	ASSY.OIL COOLER	TATA spare parts
279018170117	ASSY.OIL COOLER (6-PLATE)	TATA spare parts
279018173201	PIPE UNION BOLT(OIL FEEDER & BOOST LINE)	TATA spare parts
279018174201	SEPERATOR CLAMP (FOR OIL COOLER HOSES)	TATA spare parts
279018175301	GASKET (FOR OIL COOLER)	TATA spare parts
279018175302	GASKET (FOR PISTON COOLING NOZZLE)	TATA spare parts
279018175303	GASKET(FOR PISTON COOLING NOZZLE)	TATA spare parts
279018175804	RUBBER HOSE (FOR TURBO OIL RETURN)	TATA spare parts
279018179201	WASHER (18X22X2-CU)	TATA spare parts
279018179901	ADAPTOR OIL COOLER/FILTER	TATA spare parts
279018179907	ADAPTOR (FOR OIL COOLER & OIL FILTER)	TATA spare parts
279020100101	ASSY WATER PUMP	TATA spare parts
279020100103	ASSY WATER PUMP	TATA spare parts
279020100105	ASSY WATER PUMP	TATA spare parts
279020100108	ASSY WATER PUMP	TATA spare parts
279020100110	ASSY WATER PUMP	TATA spare parts
279020100112	ASSY.HEX.SCREW M6X20 (MTG.WATER PUMP) (T	TATA spare parts

279020100113	ASSY WATER PUMP(CERAMIC SEAL)	TATA spare parts
279020105301	GASKET WATER PUMP	TATA spare parts
279020120102	ASSY THERMOSTAT-82 DEGSOT	TATA spare parts
279020120104	ASSY THERMOSTAT-82 DEGSOT	TATA spare parts
279020120111	ASSY THERMOSTAT-82 DEGSOT	TATA spare parts
279020120112	ASSYTUBE WATER BYPASS	TATA spare parts
279020120114	BANJO BOLT WITH NIPPLE	TATA spare parts
279020120115	ADAPTOR OIL COLLAR CONN	TATA spare parts
279020120116	ELBOW WATER INLET/BYPASS	TATA spare parts
279020120118	A COVER THEMOSTAT PLS	TATA spare parts
279020120119	ASSY.ADAPTER (FOR OIL COOLER CONNECTION)	TATA spare parts
279020120120	ASSY.BYPASS TUBE (FORGING)	TATA spare parts
279020120123	ASSY. THERMOSTAT(82 SOT-SINGL VENT)BS1/3	TATA spare parts
279020120124	ASSY.THERMOSTAT	TATA spare parts
279020120126	ASSY.HOSE (WATER BYPASS) (SPR.BAND)	TATA spare parts
279020120128	ASSY.COVER (THERMOSTAT)	TATA spare parts
279020120129	ASSY.ELBOW (FOR WATER INLET & BYPASS)	TATA spare parts
279020123202	BANJO BOLT (FOR ADAPTOR TEMP.SENSOR-TC)	TATA spare parts
279020123805	COVER THERMOSTAT	TATA spare parts
279020123811	COVER THERMOSTAT	TATA spare parts
279020125301	GASKET (ELBOW WATER INLET	TATA spare parts
279020125302	GASKET (ELBOW BYPASS)	TATA spare parts
279020125303	GASKET (FOR WATER BYPASS TUBE)	TATA spare parts
279020125304	GASKET (FOR WATER INLET ELBOW)	TATA spare parts
279020125802	HOSE (FOR WATER BYPASS)	TATA spare parts
279020125803	HOSE OIL COOLER WATER	TATA spare parts
279020125807	HOSE (OIL COOLER WATER CON.) (SPR BAND)	TATA spare parts
279020125808	RUBBER HOSE(OIL COOLER RET-TC)(SPR BAND)	TATA spare parts
279020127701	SEAL THERMOSTAT	TATA spare parts
279020127702	SEAL (THERMOSTAT)	TATA spare parts
279022100102	ASSY.LIFTING HOOK-REAR W/H ACCL.BKT.	TATA spare parts
279022100105	ASSY.LIFTING HOOK (FRONT)	TATA spare parts
279022107101	LIFTING HOOK - FRONT	TATA spare parts
279022120108	BRACKET ENG.MTG.ARM	TATA spare parts
279022123701	ENGINE MTG ARM (FRONT)	TATA spare parts
279022128803	STUD BM10X45	TATA spare parts
279023110103	ASSY.BRACKET (FOR 75 AMP ALT.& P.STG.)	TATA spare parts
279023113701	BRACKET (FOR 75 AMP ALT.& PSTG.)	TATA spare parts
279023116305	V BELT NLS 875 LG	TATA spare parts
279023116307	POLY-V BELT (4 GROOVES-875)	TATA spare parts
279023117003	PULLEY POWER STG.PUMP	TATA spare parts
279023120103	A.BKT.(MTG.COMP.DOWEL HOLE)(SUBROS-90CC)	TATA spare parts
279023120116	ASSY.AIR CONDITIONING COMPRESSOR	TATA spare parts
279023120122	IDLER AC COMP BELT	TATA spare parts
279023120126	SLIDER AND SCREW ASSEMBLY	TATA spare parts
279023120130	IDLER RIJ NEW	TATA spare parts
279023120134	COMPRESSOR DLX HALLA B	TATA spare parts

279023120142	ASSY.IDLER PULLEY (FOR ALTERNATOR)	TATA spare parts
279023120146	ASSY.SLIDER & SCREW (FOR A/C IDLER)	TATA spare parts
279023120147	ASSY.SHAFT W/H DUST SHIELD-FOR TENSIONER	TATA spare parts
279023120152	ASSY.TENSION PULLEY W/H SPACER(A/C COMP)	TATA spare parts
279023120164	ASSY.AIR CONDITIONING COMP.	TATA spare parts
279023120165	ASSY.BRACKET(W/H DOWEL HOLE)	TATA spare parts
279023123705	COMPRESSOR MTG BKT HALA FLATEND	TATA spare parts
279023123707	COMPRESSOR MTG BKT HALA FLATEND 110 CC	TATA spare parts
279023124101	SLIDER (FOR TENSIONER MTG.) (ALUMINIUM)	TATA spare parts
279023126304	POLY VBELT 4G 740 LG	TATA spare parts
279023126305	POLY V BELT 770 LG.	TATA spare parts
279023126308	POLY V BELT 730 LG.	TATA spare parts
279023126311	POLY V BELT(4-PK)(730 L-HPHW)(GATES)	TATA spare parts
279023126311DF	BELT POLY V-4PK 730L HPHW A/C-SUPER ACE	TATA spare parts
279023126314	MICRO-V BELT STRETCH FIT(4PK 722)	TATA spare parts
279023126501	HEX.NUT(FOR MTG.70 DIA.INA-TENSIONER)	TATA spare parts
279023128001	SCREW A.C.COMP.TENSIONER	TATA spare parts
279023128003	SLIDER SCREW (FOR TENSIONER)	TATA spare parts
279023128801	SLIDER FOR IDLER	TATA spare parts
279023128802	STUD/LOCATOR FOR MTG BKTS	TATA spare parts
279023129201	H. WASHER	TATA spare parts
279024100107	ASSY MNT INTERMED LINK RR	TATA spare parts
279024100114	BKT FUEL FILT/B MTG	TATA spare parts
279024100118	ENG MOUNT A OLD-M10*1.25 STUD	TATA spare parts
279024100119	ASSY.ENG.MOUNT- B (ON GEAR BOX)	TATA spare parts
279024100121	ASSY BUSH FOR C LINK	TATA spare parts
279024100147	ASSY. MOUNT INTERMEDIATE LINK	TATA spare parts
279024100155	ASSY.ENG.MOUNT-B(INTEGRAL DESIGN)	TATA spare parts
279024108204	BODY MTG BKT FOR C MOUNT	TATA spare parts
279024109203	WASHER (FORBMOUNT PLATE)	TATA spare parts
279049100105	RR SILENCER W/HANGER BKT	TATA spare parts
279050100107	PRESSURE CAP AUX TANK	TATA spare parts
279050100140	A R HOSE NLS (279150100103)	TATA spare parts
279050100141	HOSE A INTE (CYLHD) NLS	TATA spare parts
279050100146	RAD DIESEL (HVAC)	TATA spare parts
279050100147	RAD DIESEL	TATA spare parts
279050100153	CYL. HD. LINE	TATA spare parts
279050100157	AUX.WATER TANK	TATA spare parts
279050100161	ASSY.SHROUD WITH FAN & MOTOR (INDRAD)	TATA spare parts
279050104301	HOSE CLIP (FOR HOLDING RADIATOR VENT HOS	TATA spare parts
279050105808	RUB HOSE CYL.HD TO HVAC	TATA spare parts
279050105809	RUBBER HOSE(RAD VENT AC)	TATA spare parts
279050107501	RUBBER GROMET (RAD MOUNT)	TATA spare parts
279050109902	DRAIN PLUG FOR RADIATOR TOYO	TATA spare parts
279100000199	ASSY.ENG.COMP.85PS SUPERACE(LHD) 1396 CC	TATA spare parts
27910000019999	ASSY.ENG.COMP.85PS SUPERACE(LHD) 1396 CC	TATA spare parts
279101130105	ASSY OIL SUMP	TATA spare parts

279101130108	BRACKET ASSY OIL FILLING ADAPTER	TATA spare parts
279101133301	BRACKET	TATA spare parts
279101135801	HOSE(OIL FILLING)	TATA spare parts
279101140102	TIMING COVER REAR TOP	TATA spare parts
279101140120	ASSY.TIMING COVER (REAR)	TATA spare parts
279101140121	ASSY.TIMING COVER (FRONT)	TATA spare parts
279101145301	GASKET (REAR COVER CRANKCASE)	TATA spare parts
279101147701	COVER TIMING BELT (FRONT)	TATA spare parts
279101150118	ASSY.RUBBER GROMMET (ENGINE COVER MTG)	TATA spare parts
279101150120	ASSY.CYL.HEAD WITHOUT VALVES	TATA spare parts
279101150124	ASSY.CYL.HEAD COMP.WITH VALVES-JCAE	TATA spare parts
279101150126	ASSY.'T'CONNECTOR-FOR BLOWBY CONNECTIONS	TATA spare parts
279101150127	ASSY.CYLINDRE HEAD COVER COMPLETE	TATA spare parts
279101150133	ASSY.MOUNTING BRACKET (FOR ENGINE COVER)	TATA spare parts
279101153201	HEX BOLT (FOR CYL.HEAD)	TATA spare parts
279101153401	VALVE SEAT INSERT-INTAKE	TATA spare parts
279101153406	VALVE SEAT INSERT-INLET (NORMAL)	TATA spare parts
279101153410	VALVE SEAT INSERT-EXHAUST	TATA spare parts
279101153414	VALVE SEAT INSERT-INLET	TATA spare parts
279101153416	VALVE SEAT INSERT-INLET	TATA spare parts
279101155304	GASKET (FOR CYL.HEAD COVER)	TATA spare parts
279101155308	GASKET (FOR CYL.HEAD) (1.1THK.)	TATA spare parts
279101155311	GASKET MPFI	TATA spare parts
279101155312	AEROLITE	TATA spare parts
279101158201	CORE PLUG (39 DIA.)	TATA spare parts
279101158203	CORE PLUG (8 DIA.)	TATA spare parts
279101159901	OIL FILLER CAP	TATA spare parts
279101170101	ASSY.DIPSTICK	TATA spare parts
279101170102	ASSY. DIPSTICK TUBE	TATA spare parts
279101170111	ASSY.DIPSTICK TUBE	TATA spare parts
279101170112	ASSY.DIPSTICK	TATA spare parts
279101175804	HOSE MPFI (HD CVR TO A-FL)	TATA spare parts
279101175810	HOSE-BLOW BY(CYL.HEAD COVER TO AIRFILTER)	TATA spare parts
279101175811	HOSE-BLOW BY(CYL.HEAD COVER TO INTAKE MA	TATA spare parts
279101990116	ENGINE OVERHAUL-SEAL KIT (ROVER)	TATA spare parts
279101990144	ENGINE DECARBONIZING GASKET KIT	TATA spare parts
279101990161	HALF BLOCK ASSY SUPER ACE (LHD)	TATA spare parts
279101990162	LONG BLOCK FOR SUPERACE (LHD)	TATA spare parts
279101990165	ENGINE OVERHAUL GASKET SUB KIT	TATA spare parts
279101990167	SET INLET AND EXHUST KIT FOR SUPERACE	TATA spare parts
279101990169	SET OF INSERT EXHUAUST/ INLET VALVE	TATA spare parts
279101990174	SET MAIN BEARING SHELL (REPAIR KIT)	TATA spare parts
279101990176	SET CONNECTING ROD BEARING (REPAIR KIT)	TATA spare parts
279103107902	CRANK SHAFT - SUPER ACE	TATA spare parts
279103110102	FLYWHEEL COMPLETE-MPFI	TATA spare parts
279103110107	ASSY.FLYWHEEL (SUPER ACE)	TATA spare parts
279103133701	PULLEY CRANKSHAFT-ALT.DRIVE-4-GROOVES	TATA spare parts



279103140103	OIL RING PETROL IP	TATA spare parts
279103144301	INT.CIRCLIP 20 (IP)	TATA spare parts
279103146602	PISTON GRADE A (IP)	TATA spare parts
279103146620	PISTON GRADE A (IP)	TATA spare parts
279103146621	PISTON GRADE B (IP)	TATA spare parts
279103146622	PISTON GRADE C	TATA spare parts
279103146702	PISTON PIN	TATA spare parts
279103149904	TOP RING	TATA spare parts
279103149905	TAPER FACED RING	TATA spare parts
279103150102	ASSY CONNECTING ROD W/O BRG.SHELL	TATA spare parts
279105107905	CAM SHAFT (85PS MPFI)	TATA spare parts
279105110103	ASSY.TIMING GEAR (CAMSHAFT) (EURO-III)	TATA spare parts
279105115403	TIMING GEAR (CAMSHAFT) (EURO-III)	TATA spare parts
279105116301	TIMING BELT	TATA spare parts
279105116301DF	BELT TIMING - ACE/MAGIC CNG	TATA spare parts
279105116303	TIMING BELT (IMPORTED)	TATA spare parts
279105117102	SENSOR PLATE (CAMSHAFT GEAR)	TATA spare parts
279105118001	SCREW M6X12.5 (TIMING GEAR CAMSHAFT)	TATA spare parts
279105118601	SPACER (FOR IDLER)	TATA spare parts
279105125101	VALVE SPRING RETAINER	TATA spare parts
279105125104	INTAKE VALVE AUTOFIELD	TATA spare parts
279105125105	EX. VALVE AUTOFILD	TATA spare parts
279105125117	EXHAUST VALVE	TATA spare parts
279105125121	INTAKE VALVE (CNG)MPFI	TATA spare parts
279105125122	INLET VALVE (FOR MPFI CNG)	TATA spare parts
279105125123	VALVE SPRING RETAINER	TATA spare parts
279105128202	SPRING SEAT	TATA spare parts
279105128701	VALVE SPRING	TATA spare parts
279105128702	VALVE SPRING	TATA spare parts
279105140102	ROCKER SHAFT	TATA spare parts
279105140104	ASSY.ROLLER ROCKER ARM W/H ROLLER BRG.	TATA spare parts
279105143802	ROCKER ARM (AL CAST)	TATA spare parts
279105148001	ADJUST SCREW ROCKER ARM	TATA spare parts
279105148002	SCREW-ROCKER SHAFT HOLDER	TATA spare parts
279105148201	ROCKER SPRING SEAT	TATA spare parts
279105148701	SPRING (ROCKER ARM SHAFT)	TATA spare parts
279105149901	ROCKER NUT	TATA spare parts
279105153703	VALVE GUIDE EXHAUST NORM	TATA spare parts
279107100102	ASSY.PRESSURE REGULATOR	TATA spare parts
279107100112	ASSY.CARBON CANISTER	TATA spare parts
279107104207	INJECTOR RETAINER	TATA spare parts
279107140113	ASSY.FUEL RAIL	TATA spare parts
279107144203	CLAMP FOR CANISTER PURGE VALVE	TATA spare parts
279107145812	HOSE MPFI (CPV TO T-CON)	TATA spare parts
279107145813	HOSE MPFI (B.TUBE TO CPV)	TATA spare parts
279107145814	HOSE MPFI(TCONS TO INTAKE	TATA spare parts
279107145815	HOSE MPFI(TPU BUNDY TO T)	TATA spare parts

279107145816	HOSE MPFI(BUNDY TO CANS)	TATA spare parts
279107145822	RUBBER HOSE(CANISTER PURGE VALVE TO INTA	TATA spare parts
279109110102	ASSY.FUEL FILTEER(QUICK FIT TYPE)	TATA spare parts
279109125301	GASKET MPFI	TATA spare parts
279109125302	GASKET(FOR INTEGRATE TROTTLE BODY)	TATA spare parts
279109130105	SNORKEL (FOR AIR FILTER)	TATA spare parts
279109133302	BRACKET (DUST SEPARATOR)	TATA spare parts
279109135808	HOSE (THROTTLE BODY TO INTAKE PIPE)	TATA spare parts
279109135809	HOSE (INTAKE PIPE TO AIR FILTER PIPE)	TATA spare parts
279109136306	ASSY.SNORKEL (WITH MESH)	TATA spare parts
279109136901	ASSY.AIR INTAKE PIPE (WITH CLAMP)	TATA spare parts
279109136902	ASSY.TUBE FOR AIR INTAKE	TATA spare parts
279114100120	ASSY. INTAKE MANIFOLD	TATA spare parts
279114110104	ASSY.HEAT SHIELD (FOR EXHAUST MANIFOLD)	TATA spare parts
279114110114	ASSY.GASKET (EXHAUST MANIFOLD)	TATA spare parts
279114110123	ASSY CATCON WITH BOTH SIDE HEAT SHIELD	TATA spare parts
279114110124	BOTTOM HEAT SHIELD (EXHAUST MANIFOLD)	TATA spare parts
279114113704	EXHAUST MANIFOLD	TATA spare parts
279115200115	ASSY INTAKE FUEL PUMP (PANTADAEW)	TATA spare parts
279115203302	BRACKET (FOR CAM SENSOR)	TATA spare parts
279115203801	BRACKET (FOR CRANK ANGLE SENSOR)	TATA spare parts
279115203802	BRACKET(CRANK ANGLE SENSOR)	TATA spare parts
279115207704	RUBBER GROMET (FOR CAM SENSOR DUST SEAL)	TATA spare parts
279115209913	CRANK ANGLE SENSOR	TATA spare parts
279115209918	ELECTRONIC CONTOL UNIT(INDIGO )	TATA spare parts
279115210103	THROTTLE BODY (JCAE)	TATA spare parts
279115210104	IGNITION COIL	TATA spare parts
279115210105	CANISTER PURGE VALVE	TATA spare parts
279115210114	ASSY.INJECTOR (3-HOLE)	TATA spare parts
279115219901	ECU 1.4L MPFI(HARDWARE ONLY)	TATA spare parts
279115219902	CRANK ANGLE & RPM SENSOR	TATA spare parts
279115219903	CAM SENSOR	TATA spare parts
279115219904	KNOCK SENSOR	TATA spare parts
279115219905	MAP SENSOR	TATA spare parts
279115219906	COOLANT TEMP.SENSOR	TATA spare parts
279115219916	ECU S2000 FC5 1.4L	TATA spare parts
279116990101	ECU WITH SOFTWARE	TATA spare parts
279120120108	ASSY.WATER BYPASS TUBE	TATA spare parts
279120120109	ASSY.THERMOSTAT W/O BYPASS VALVE	TATA spare parts
279120120111	ASSY.HOSE (WATER BYPASS)	TATA spare parts
279120120116	SPECIAL NUT	TATA spare parts
279120120121	PROTECTION SLEEVE (WATER BYPASS)	TATA spare parts
279120123805	THERMOSTAT HSG.(IGNITION COIL MTG)	TATA spare parts
279122100103	ASSY.LIFTING HOOK (REAR)	TATA spare parts
279122100105	ASSY.LIFTING HOOK (FRONT)	TATA spare parts
279123116301	POLY VEE BELT	TATA spare parts
279123116302	POLY VEE BELT (5 PK-1075)	TATA spare parts

279149100130	ASSY.PRE-SILENCER(44.45 DIA.SS INTERNAL)	TATA spare parts
279150100105	ASSY.SHROUD WITH FAN & MOTOR	TATA spare parts
279150100115	ASSY.THERMOSWITCH(93ON/87OFF)	TATA spare parts
279150100116	ASSY.INTEGRAL RUBBER HOSE(W/H HEATER BR)	TATA spare parts
279150100148	RADIATOR COOLING LINE	TATA spare parts
279150100149	ASSY HOSE (WATER INLET)	TATA spare parts
279150100150	ASSY.HOSE (AUX TANK TO WATER INLET ELBOW)	TATA spare parts
279150100151	ASSY TUBE(RADIATOR VENT)	TATA spare parts
279150100152	ASSY.PIPE WITH CLAMP	TATA spare parts
279150100153	ASSY HOSE (AUX TANK TO CYL.HEAD VENT)	TATA spare parts
279150100158	ASSY VENT HOSE(AUX. TANK TO VENT TUBE)	TATA spare parts
279150100176	ASSY PIPE WITH CLAMP AND TUBE	TATA spare parts
279150105801	HOSE MPFI	TATA spare parts
279150105816	WATER OUTLET HOSE (THERMOSTAT COVER)	TATA spare parts
279150105817	RUBBER HOSE (UPPER COOLING LINE)	TATA spare parts
279150600102	ASSY.ADAPTER (FOR HEATER CONNECTION)	TATA spare parts
279201153401	VALVE SEAT INSERT INTAKE CNG	TATA spare parts
279201990104	ENG O/HKIT -MAJOR PET	TATA spare parts
279201990105	ENG O/H KIT -MINOR PET	TATA spare parts
279203130101	INDICATOR-FOR TIMINING	TATA spare parts
279205109202	CAM THRUST PLATE (FRONT)	TATA spare parts
279205109902	ADAPTOR (CAMSHAFT)	TATA spare parts
279207105301	GASKET (FOR CARBURETTOR)	TATA spare parts
279207106301	CUP CONNECTOR CARBTO A/F	TATA spare parts
279207145810	HOSE CANI PURGE PIP-CARB	TATA spare parts
279207145811	HOSE (CANISTER TO PIPE)	TATA spare parts
279207145812	HOSE MANI-TANK PURGE VALV	TATA spare parts
279207990101	FLOAT CHAMBER COVER KIT	TATA spare parts
279207990102	STEEL BALL KIT	TATA spare parts
279207990103	NEEDLE VALVE KIT	TATA spare parts
279209105301	GASKET (FOR FUEL PUMP)	TATA spare parts
279209110102	FUEL FILTER (PUROLATOR)	TATA spare parts
279209130110	AIR FILTER (KNECHT)	TATA spare parts
279214105301	GASKET FOR INLET MANIFOLD	TATA spare parts
279214105802	HOSE (CYL H COVER)	TATA spare parts
279214105805	HOSE (PVC VALUE TOT)	TATA spare parts
279215189901	SPARK PLUG	TATA spare parts
279220125301	GASKET ELBOW-WATER INLET	TATA spare parts
279220125803	HOSE	TATA spare parts
279250100116	ASSY R.HOSE (THERMO ROD)	TATA spare parts
279250100122	RADIATOR PETROL	TATA spare parts
279250100127	RADIATOR W/O TH SWITCH PETROL	TATA spare parts
279250105802	RUBBER HOSE CYL HEAD VENT	TATA spare parts
279250105803	RUBBER HOSE RADIATOR VENT	TATA spare parts
279700000156	ASSY 1.4L CRAIL ENGINE COMPLETE	TATA spare parts
279700000159	ASSY ENGINE COMPLETE E-IV	TATA spare parts
279700000161	ENGINE COMPLETE - BS IV	TATA spare parts

279700000164	SUPERACE ASSY ENG COMPL BS-IV AC+PS	TATA spare parts
279700000165	SUPERACE ASSY.ENG.COMPL.BS-IV PS	TATA spare parts
279700000166	ENGINE COMPLETE BS-III	TATA spare parts
279700000173	ENGINE ASSY .WITH KIT	TATA spare parts
279700000178	SUPERACE ASSY.ENG.COMPL. PS (E-IV)	TATA spare parts
279700000181	ENG.COMPL 1.4L INTRA 1100 BS-IV PS	TATA spare parts
279700000182	ENG.COMP.1400CC DI ENGINE INTRA V20 BSIV	TATA spare parts
279701100101	ASSY.CYLINDER CRANKCASE	TATA spare parts
279701103201	HEX BOLT (M.B.CAP)	TATA spare parts
279701103302	BRACKET(FOR BLOWBY HOSE MTG.)(SUPERACE)	TATA spare parts
279701104801	HOLLOW DOWEL (CYL.BLOCK TO CYL.HEAD)	TATA spare parts
279701109901	INSERT (FOR SENSOR ON CYL.CRANKCASE)	TATA spare parts
279701130104	ASSY.OIL SUMP COMP.(EDGE CUT)LIQUID GKT.	TATA spare parts
279701130109	ASSY.OIL SUMP COMPLETE (LIQUID GASKET)	TATA spare parts
279701130114	OIL SUMP ASSY WITH DRAIN PLUG	TATA spare parts
279701133801	LADDER FRAME	TATA spare parts
279701140101	COVER ASSY WITH OIL SEAL CRANKCASE REAR	TATA spare parts
279701140102	ASSY.TIMING COVER (BACK)	TATA spare parts
279701140103	ASSY.TIMING COVER (FRONT)	TATA spare parts
279701143801	REAR COVER CRANKCASE	TATA spare parts
279701143802	TIMING COVER (BOTTOM)(AL.)	TATA spare parts
279701143803	COVER,CRANKCASE,REAR	TATA spare parts
279701150114	ASSY. CYLINDER HEAD (WITHOUT VALVES)	TATA spare parts
279701150115	ASSY. CYL HEAD COVER	TATA spare parts
279701150116	ASSY. CYL. HEAD W/VALVES SUPERACE BS3/4	TATA spare parts
279701150117	ASSY. CYLINDER HEAD W/O VALVES BS3/4	TATA spare parts
279701150121	ASSY. CYL. HEAD COVER	TATA spare parts
279701150126	CYL HEAD ASSY WITH VALVES	TATA spare parts
279701153201	HEX.BOLT - CYLINDER HEAD	TATA spare parts
279701153301	BRACKET (WIRING HARNESS SUPPORT)	TATA spare parts
279701153302	BRACKET (FOR WIRING HARNESS)	TATA spare parts
279701153405	VALVE SEAT INSERT (INLET)	TATA spare parts
279701153407	VALVE SEAT INSERT (EXHAUST)	TATA spare parts
279701155303	GASKET - CYLINDER HEAD (1.3)	TATA spare parts
279701155304	GASKET - CYLINDER HEAD (1.4)	TATA spare parts
279701155305	GASKET - CYLINDER HEAD (1.5)	TATA spare parts
279701155311	GASKET - OFC	TATA spare parts
279701155314	GASKET-INNER (CYL. HEAD COVER)	TATA spare parts
279701155315	GASKET-OUTER (CYL. HEAD COVER)	TATA spare parts
279701155316	GASKET OFC	TATA spare parts
279701155320	GASKET CYL HEAD	TATA spare parts
279701155321	GASKET CYL HEAD	TATA spare parts
279701155322	GASKET CYL HEAD	TATA spare parts
279701156702	BALL HEAD PIN (15.5L)	TATA spare parts
279701159201	WASHER - CYLINDER HEAD BOLT	TATA spare parts
279701160103	ASSY.INJECTOR WITH WASHER	TATA spare parts
279701165101	INJECTOR CLAW	TATA spare parts

279701165102	INJECTOR CLAW	TATA spare parts
279701165103	INJECTOR CLAW(UDL)(AUTOPHORETIC COATING)	TATA spare parts
279701166701	PIN (INJETCOR CLAW SUPPORT)	TATA spare parts
279701167701	'O' RING (FOR INJECTOR)	TATA spare parts
279701169203	WASHER 25 THK (FOR INJECTOR)	TATA spare parts
279701169204	SPH.WASHER (INJECTOR CLAW)	TATA spare parts
279701170104	ASSYDIPSTICK	TATA spare parts
279701170105	ASSY. DIPSTICK TUBE (BS-IV)	TATA spare parts
279701170106	ASSY. BRACKET-OIL SEPRATOR MOUNTING	TATA spare parts
279701170111	ASSY.DIPSTICK TUBE (SUPERACE)	TATA spare parts
279701170117	BRACKET ASSY (OIL SEPARATOR & EVRV MTG.)	TATA spare parts
279701170119	DIPSTICK TUBE ASSY	TATA spare parts
279701170122	BRACKET ASSY	TATA spare parts
279701170123	DIPSTICK TUBE ASSY	TATA spare parts
279701170124	DIPSTICK ASSY	TATA spare parts
279701170126	BRACKET ASSY OIL SEPARATOR MTG	TATA spare parts
279701170127	HOSE ASSY CYL HEAD COVER TO OMS	TATA spare parts
279701173303	BRACKET(OIL FILLING HOSE SUPPORT)	TATA spare parts
279701173305	BRACKET (OIL SEP TO CYL HEAD COVER HOSE)	TATA spare parts
279701173306	BRACKET (FOR ASSY OF DIPSTICK TUBE)	TATA spare parts
279701173308	BRACKET DIPSTICK MTG	TATA spare parts
279701174201	CLAMP (OIL SEP.TO AIR INTAKE HOSE)	TATA spare parts
279701174202	CLAMP (FOR OIL SEP. HOSE)	TATA spare parts
279701175802	HOSE (CYL.HEAD COVER TO OIL SEPERATOR)	TATA spare parts
279701175803	HOSE OIL RET SEP.TO OIL SUMP SUPERACE	TATA spare parts
279701175805	RUBBER HOSE (OIL SEPARATOR TO OIL SUMP)	TATA spare parts
279701175807	HOSE BLOW-BY (CYL.HEAD COVER TO OIL SEP)	TATA spare parts
279701175808	HOSE(OIL ADAPTER TO OIL SUMP)(SUPERACE)	TATA spare parts
279701175814	RUBBER HOSE ADAPTER TO OIL SUMP	TATA spare parts
279701990106	ENGINE OVERHAUL - SEAL SUB KIT	TATA spare parts
279701990112	SUB KIT-ENGINE OVERHAUL GASKET BS3/4	TATA spare parts
279701990124	ASSY. LONG BLOCK 1.4L BS3/4	TATA spare parts
279701990125	ENGINE ASSY HALF BLOCK SUPERACE	TATA spare parts
279701990126	CYLINDER HEAD ASSY W/O INJ.SUPERACE	TATA spare parts
279701990138	EOH GASKET KIT SUPERACE,1.4 THK CYL HD	TATA spare parts
279701990141	BARE ENGINE ASSY	TATA spare parts
279701990142	HALF BLOCK ASSY ENGINE	TATA spare parts
279701990153	ASSY. LONG BLOCK BS4	TATA spare parts
279701990154	Half Block Assy	TATA spare parts
279703100102	ASSY.CRANKSHAFT WITH CYL.PIN (SUPERACE)	TATA spare parts
279703100103	ASSY.CRANKSHAFT WITH CYL.PIN & BALL BRG.	TATA spare parts
279703100108	ASSY.CRANKSHAFT WITH PIN(NORML)(MA)TA65*	TATA spare parts
279703110103	ASSY.FLYWHEEL (HIGH INERTIA) (SUPERACE)	TATA spare parts
279703110107	ASSY. FLYWHEEL (HIGH INERTIA)(TA65 STAR)	TATA spare parts
279703113201	HEXBOLT (FOR FLYWHEEL)	TATA spare parts
279703113202	BOLT (FLYWHEEL)	TATA spare parts
279703123103	M.B.SHELL UPPER NORMAL (CR.SHAFT)BIMETAL	TATA spare parts

279703123104	M.B.SHELL LOWER NORMAL (CR.SHAFT)BIMETAL	TATA spare parts
279703130103	VIBRATION DAMPER	TATA spare parts
279703130104	VIBRATION DAMPER ASSY.	TATA spare parts
279703133201	HEX.BOLT (CRANKSHAFT GEAR)	TATA spare parts
279703139201	WASHER (CRANKSHAFT GEAR)	TATA spare parts
279703140109	ASSY.PISTON GRADE B (IP)	TATA spare parts
279703150109	ASSY CONNECTING ROD(FRACTURE SPLIT)	TATA spare parts
279703153104	BRG.HALF LOWER NORMAL (CON.DOD)(BIMETAL)	TATA spare parts
279703153109	BRG.SHELL HALF UPPER/LOWER(C.ROD)BIMETAL	TATA spare parts
279703990104	SET PISTON RINGS	TATA spare parts
279703990105	SET MB SHELL HALF NOR(CR.SHAFT)	TATA spare parts
279703990109	SET THRUST WASHERS(LF) (BIMETAL)	TATA spare parts
279703990110	SET PISTON W/O RINGS 90PS GRADE A	TATA spare parts
279703990111	SET PISTON W/O RINGS 90PS GRADE B	TATA spare parts
279703990112	SET PISTON W/O RINGS 90PS GRADE C	TATA spare parts
279703990113	SET BRG.HALF NORMAL (CON.DOD)	TATA spare parts
279703990120	SET PISTON W/O RINGS GRADE A	TATA spare parts
279703990121	SET PISTON W/O RINGS GRADE B	TATA spare parts
279703990122	SET PISTON W/O RINGS GRADE C	TATA spare parts
279703990123	SET BUSH - CONNECTING ROD	TATA spare parts
279705103201	HEX.BOLT (CAMSHAFT BRG.CAP)	TATA spare parts
279705103203	HEX BOLT,CAMSHAFT GEAR MTG	TATA spare parts
279705107801	OIL SEAL (CAMSHAFT)	TATA spare parts
279705107901	CAMSHAFT (INTAKE)	TATA spare parts
279705107902	CAMSHAFT (EXHAUST)	TATA spare parts
279705110101	ASSY.TENSIONER	TATA spare parts
279705110107	ASSY GEAR CRANKSHAFT	TATA spare parts
279705113201	HEX. FL BOLT (FOR AUTO-TENTIONER)	TATA spare parts
279705113202	HEX. FL. BOLT (FOR TIMING BELT IDLER)	TATA spare parts
279705115402	GEAR CAMSHAFT (REAR)	TATA spare parts
279705115403	TIMING GEAR (CAMSHAFT) FRONT	TATA spare parts
279705115406	TIMING GEAR-CAMSHAFT(FRONT WITH STOPPER)	TATA spare parts
279705115408	GEAR CAMSHAFT (REAR)-(815M17)	TATA spare parts
279705118602	SPACER (FOR TIMING BELT IDLER)	TATA spare parts
279705125103	VALVE SPRING RETAINER	TATA spare parts
279705125105	INTALE VALVE	TATA spare parts
279705125106	EXHAUST VALVE	TATA spare parts
279705125109	INTAKE VALVE	TATA spare parts
279705125110	EXHAUST VALVE	TATA spare parts
279705128201	SPRING SEAT	TATA spare parts
279705128701	VALVE SPRING	TATA spare parts
279705140101	ASSY.ROLLER FINGER FOLLOWER	TATA spare parts
279705140102	ASSY.HYDRAULIC LASH ADJUSTER	TATA spare parts
279705140105	ASSY.RFF & HLA - DICOR	TATA spare parts
279705153701	VALVE GUIDE INTAKE & EXHAUST (NORMAL)	TATA spare parts
279705153703	VALVE GUIDE INTAKE-EXHAUST	TATA spare parts
279705157801	VALVE GUIDE SEAL (CR-SEAL)	TATA spare parts

279705157802	VALVE GUIDE SEAL INLET & EXHAUST BS4	TATA spare parts
279707100101	ASSY.HIGH PRESSURE PUMP	TATA spare parts
279707103201	HEX BOLT (FIP MTG ON BLOCK)	TATA spare parts
279707103202	HEX BOLT M8X75.5 (FIP MTG.ON BLOCK)	TATA spare parts
279707106501	NUT (FIP)	TATA spare parts
279707135401	TIMING GEAR (FIP)	TATA spare parts
279707140103	ASSY.FUEL RAIL	TATA spare parts
279707140104	SET BACK LEAK HOSES	TATA spare parts
279707140112	CLAMP ASSY,HP LINE PUMP TO RAIL	TATA spare parts
279707140114	HP LINE (PUMP TO RAIL) BEND (SUPERACE)	TATA spare parts
279707140117	HP LINE (RAIL TO INJ 1) BEND (SUPERACE)	TATA spare parts
279707140118	HP LINE (RAIL TO INJ 2) BEND (SUPERACE)	TATA spare parts
279707140119	HP LINE (RAIL TO INJ 3) BEND (SUPERACE)	TATA spare parts
279707140120	HP LINE (RAIL TO INJ 4) BEND (SUPERACE)	TATA spare parts
279707140128	ASSY.FUEL PR.LINE(BENT)PUMP TO RAIL(IAI)	TATA spare parts
279707140129	ASSY.FUEL LINE(BENT) RAIL TO INJ-1(IAI)	TATA spare parts
279707140130	ASSY.FUEL LINE(BENT) RAIL TO INJ-2(IAI)	TATA spare parts
279707140131	ASSY.FUEL LINE(BENT) RAIL TO INJ-3(IAI)	TATA spare parts
279707140132	ASSY.FUEL LINE(BENT) RAIL TO INJ-4(IAI)	TATA spare parts
279707145801	HOSE BACK LEAK (30MM)	TATA spare parts
279707145802	HOSE (BACK LEAK) (66MM)	TATA spare parts
279707145803	HOSE (BACK LEAK) (104MM)	TATA spare parts
279707145804	HOSE (BACK LEAK) (370MM)	TATA spare parts
279707147701	CLAMP RUBBER (FOR HP LINE-PUMP TO RAIL)	TATA spare parts
279707148201	CLAMP (FOR HP LINE-PUMP TO RAIL)	TATA spare parts
279709110103	ASSY.SEDIMENTOR	TATA spare parts
279709110106	ASSY. COMBI FUEL FILTER SEDIMENTOR	TATA spare parts
279709110113	ASSY. FUEL PRE-FILTER	TATA spare parts
279709110114	WATER SENSOR ASSY.	TATA spare parts
279709119901	KIT FUEL PRE-FILTER ELEMENT	TATA spare parts
279709130101	ASSY.RUBBER HOSE (HFM TO TC)	TATA spare parts
279709130121	ASSY. OF AIR INTAKE HOSE (HFM TO TC)	TATA spare parts
279709130122	ASSY. BRACKET(FOR SUPPORT RUBBER HOSE A/	TATA spare parts
279709130139	BRACKET&ASSY	TATA spare parts
279709130140	RIBBED&HOSE&ASSY&HFM&TO&TC	TATA spare parts
279709130141	BRACKET&ASSY	TATA spare parts
279709133801	AIR INTAKE PIPE	TATA spare parts
279709135802	HOSE (OIL SEPERATOR TO AIR INTAKE HOSE)	TATA spare parts
279709135805	HOSE (OIL SEPERATOR TO AIR INTAKE HOSE N	TATA spare parts
279709135817	RUBBER HOSE (AIR FILTER TO HFM)	TATA spare parts
279709135821	HOSE&AIR&FILTER&TO&AIR&MASS&SENSOR	TATA spare parts
279714100102	ASSY.INTAKE MANIFOLD WITH CORE PLUG	TATA spare parts
279714100103	INTAKE MANIFOLD ASSY WITH CORE PLUG	TATA spare parts
279714103804	INTAKE MANIFOLD (SUPERACE)	TATA spare parts
279714103806	AIR INTAKE ELBOW (SUPERACE BS-IV)	TATA spare parts
279714103807	Charge air Pipe	TATA spare parts
279714105302	GASKET	TATA spare parts

279714105305	GASKET(IC PIPE-INTAKE MANIFOLD)	TATA spare parts
279714105306	GASKET (INTAKE MANIFOLD)	TATA spare parts
279714110103	HEAT SHIELD (EXHAUST MANIFOLD)	TATA spare parts
279714110111	ASSY BRACKET (CCC SUPPORT)	TATA spare parts
279714110116	ASSY. CLOSED COUPLED CAT CON (BS-IV)	TATA spare parts
279714110117	ASSY.TUBE(EGR VALVE TO EGR PIPE)-JOINFLE	TATA spare parts
279714110119	ASSY. EGR VALVE	TATA spare parts
279714110122	ASSY.BRACKET EVRV (ON WATER BOX)	TATA spare parts
279714110123	ASSY HEAT SHIELD (VENTURE)	TATA spare parts
279714110125	ASSY EGR PIPE SUPER ACE-VENTURE RHD	TATA spare parts
279714110126	ASSY.CLOSE COUPLED CATCON,BS-IV	TATA spare parts
279714110127	ASSY.BRACKET (CCC SUPPORT)	TATA spare parts
279714110129	ASSY.TUBE(EGR VALVE TO EGR PIPE-JOINFLEX	TATA spare parts
279714110130	ASSY. HEAT SHIELD	TATA spare parts
279714110135	BRACKET ASSY	TATA spare parts
279714110137	BRACKET ASSY WITH WELD STUD	TATA spare parts
279714110142	BRACKET¿OIL¿SEPARATOR¿HOSE¿SUPPORT¿MTG	TATA spare parts
279714110143	BRACKET¿ASSY	TATA spare parts
279714110144	BRACKET¿ASSY¿WITH¿WELD¿STUD	TATA spare parts
279714113301	BRACKET(OIL SEPERATOR HOSE SUPPORT MTG.)	TATA spare parts
279714113701	EXHAUST MANIFOLD	TATA spare parts
279714113801	ELBOW (FOR EGR VALVE)	TATA spare parts
279714115301	GASKET (EXHAUST MANIFOLD)	TATA spare parts
279714115308	GASKET - (ELBOW TO EGR VALVE)	TATA spare parts
279714115309	GASKET (EGR VALVE TO EGR COOLER)	TATA spare parts
279714115310	GASKET (FOR EGR PIPE)	TATA spare parts
279714115801	HOSE (EVRC CKT)(BS-III)	TATA spare parts
279714115802	HOSE (EVRV TO EGR VALVE) (SUPERACE)	TATA spare parts
279714115812	RUBBER HOSE (EVRV TO 1WAY VALVE S/ACE	TATA spare parts
279714115813	RUBBER HOSE(EVRV TO AIR INTAKE HOSE)(WG)	TATA spare parts
279714115828	HOSE;EVRV TO AIR INTAKE	TATA spare parts
279714115829	HOSE;EVRV TO EGR VALVE	TATA spare parts
279714115830	HOSE;EVRV TO VACUUM PUMP	TATA spare parts
279714115831	HOSE¿EVRV¿TO¿AIR¿INTAKE	TATA spare parts
279714118201	BRACKET (SUPPORT) (TC TO IC BRACKET)	TATA spare parts
279714118202	BRACKET (TURBO SUPPORT)(SUPERACE)	TATA spare parts
279714119905	4-WAY-CONNECTOR (FOR VACUUM CONNECTION)	TATA spare parts
279714510105	ASSY. TURBOCHARGER (SUPERACE) BS3/4	TATA spare parts
279714510107	TURBOCHARGER ASSY	TATA spare parts
279714515301	GASKET (TC INLET TO EXHAUST MANIFOLD)	TATA spare parts
279714515302	GASKET	TATA spare parts
279714515304	GASKET (TC OUTLET TO CCC) (TALBROS)	TATA spare parts
279714600110	ASSY.PIPE (TC TO IC)(SUPERACE BS-IV)	TATA spare parts
279714600112	ASSY. PIPE (TC HOSE TO IC HOSE)(SUPERACE	TATA spare parts
279714600114	ASSY.BRACKET (INTERCOOLER OUTLET HOSE)	TATA spare parts
279714600124	PIPE ASSY (TC HOSE TO IC HOSE)	TATA spare parts
279714600128	DUCT ASSY;INTERCOOLER	TATA spare parts



279714600130	PIPE&ASSY&TURBOCHARGER&TO&INTAKE	TATA spare parts
279714600131	PIPE&ASSY&TURBOCHARGER&TO&INTERCOOLER	TATA spare parts
279714600132	PIPE&ASSY	TATA spare parts
279714600133	INTERCOOLER ASSY	TATA spare parts
279714603801	BRACKET (FOR INTERCOOLER SUPPORT)	TATA spare parts
279714605810	RUBBER HOSE(WASTEGATE OUTLET)(SUPERACE)	TATA spare parts
279714605811	HOSE (IC INLET) (SUPERACE BS-IV)	TATA spare parts
279714605812	HOSE (IC OUTLET)(SUPERACE BS-IV)	TATA spare parts
279714605814	HOSE (TC PIPE TO IC PIPE END)(SUPERACE B	TATA spare parts
279714605818	HOSE INTERCOOLER TO INTERCOOLER PIPE	TATA spare parts
279714605822	RUBBER HOSE INTERCOOLER TO PIPE	TATA spare parts
279714605823	RUBBER&HOSE&PIPE&TO&AIR&INTAKE&ELBOW	TATA spare parts
279714605824	RUBBER HOSE IC OUTLET TO PIPE	TATA spare parts
279714605825	RUBBER&HOSE&PIPE&TO&INTERCOOLER	TATA spare parts
279714605826	RUBBER&HOSE&TC&TO&PIPE&INTERCOOLER	TATA spare parts
279714607501	SPACER;INTERCOOLER DUCT MTG	TATA spare parts
279714700101	EGR COOLER	TATA spare parts
279714700103	EGR COOLER ASSY	TATA spare parts
279714705303	GASKET (ELBOW EGR TO CYL.HEAD)	TATA spare parts
279714990101	DECARBONISING KIT	TATA spare parts
279714990104	DECARBONISING GASKET KIT (BS-IV)	TATA spare parts
279715143704	BRACKET (ALTERNATOR MTG BKT)	TATA spare parts
279715143705	BRACKET (FOR ALTERNATOR MTG.)	TATA spare parts
279715148001	SLIDER SCREW	TATA spare parts
279715209901	ENGINE CONTROL UNIT (70 PS) (EURO-IV)	TATA spare parts
279715209903	AIR MASS FLOW SENSOR (HFM)	TATA spare parts
279715409901	GLOW PLUG	TATA spare parts
279715409901DF	GLOW PLUG-XENON/WINGER/V30/V50 BS4/6	TATA spare parts
279715409904	GLOW PLUG BS4 SUPER ACE	TATA spare parts
279715409904DF	GLOW PLUG-1.4L SUPER ACE/V20 BS4	TATA spare parts
279715409905	GLOW PLUG	TATA spare parts
279715990121	ASSY.ECU (PRE-FLASHED)BS-IV DOM.	TATA spare parts
279716101211	CONTAINER ASSY (ECU WITH SOFTWARE)	TATA spare parts
279716101212	CONTAINER ASSY (ECU WITH SOFTWARE)	TATA spare parts
279716101220	CONTAINER ASSY	TATA spare parts
279716102001	AIR MASS FLOW SENSOR	TATA spare parts
279718100104	ASSY. OIL PUMP	TATA spare parts
279718105303	GASKET (OIL PUMP) (TALBROS)	TATA spare parts
279718150103	STRAINER&ASSY&OIL&PUMP	TATA spare parts
279718170101	NOZZLE PISTON COOLING	TATA spare parts
279718170110	ASSY.OIL RETURN LINE (TC)(WASTE GATE)	TATA spare parts
279718170111	ASSY.OIL FEEDER LINE(CYL.HEAD TO TC)	TATA spare parts
279718170115	ASSY.OIL COOLER	TATA spare parts
279718170116	ASSY.OIL RETURN LINE (TC)(WASTE GATE)	TATA spare parts
279718170125	NOZZLE ASSY,PISTON COOLING	TATA spare parts
279718175303	GASKET (TC OIL RETURN OUTLET) (WG)	TATA spare parts
279718175304	GASKET (ADAPTOR OIL RETURN)	TATA spare parts

279718175307	GASKET(TCOILRETURNOUTLET)(WG)	TATA spare parts
279720100105	ASSY.WATER PUMP	TATA spare parts
279720105301	GASKET (WATER PUMP)	TATA spare parts
279720120105	ASSY. THERMOSTAT (87 DEG) CALTHERM (LOW	TATA spare parts
279720120106	ASSY.HOUSING (WATER OUTLET)(SUPERACE BS-	TATA spare parts
279720120107	ASSY. HOUSING (WATER OUTLET)	TATA spare parts
279720120108	ASSY. PIPE (WATER BOX TO RADIATOR INLET	TATA spare parts
279720120112	ASSY. THERMOSTAT (78 DEG) BS4	TATA spare parts
279720120114	WATER BOX ASSY	TATA spare parts
279720120115	ELBOW ASSY;WATER INTAKE	TATA spare parts
279720120117	THERMOSTAT ASSY	TATA spare parts
279720125301	GASKET (HOUSING-WATER OUTLET)	TATA spare parts
279720125304	GASKET THERMOSTAT	TATA spare parts
279720125305	GASKET- ASSY. PIPE WATER BOX	TATA spare parts
279722107101	LIFTING HOOK (REAR)	TATA spare parts
279722123701	BRACKET (FOR ENGINE MTG ARM)	TATA spare parts
279722123702	ENGINE MTG.ARM	TATA spare parts
279722123703	ENGINE MTG.ARM (SUPERACE)	TATA spare parts
279722123705	ENGINE MOUNTING ARM	TATA spare parts
279723113703	BRACKET TENSIONER (P.STG.DRIVE)	TATA spare parts
279723113704	BRACKET (PSTG.MTG.)	TATA spare parts
279723116301	BELT POWER STEERING PUMP	TATA spare parts
279723120105	ASSY.TENSION PULLEY WITH SPACER	TATA spare parts
279723120112	BRACKET ASSY (COMPRESSOR QS90CC MTG.)	TATA spare parts
279723120114	AC COMPRESSOR MTG BRACKET	TATA spare parts
279723126315	POLY V BELT	TATA spare parts
279723126315DF	BELT POLY V-5PK 732-SUPER ACE 1.4L/V30 1	TATA spare parts
279723126317	MICRO V-BELT 5-PEAKS (915L) HPHW BS4	TATA spare parts
279723126317DF	BELT POLY V - 5PK 915L HPHW	TATA spare parts
279723126318	POLY V-BELT,AC COMP 5PK 727L	TATA spare parts
279723126319	POLY V-BELT	TATA spare parts
279723126319DF	BELT POLY V - 5PK 988L-SUPER ACE/V20 1.4	TATA spare parts
279723128801	SLIDER (FOR TENSIONER PULLEY)	TATA spare parts
279749100104	CATCON ASSY	TATA spare parts
279750100110	ASSY.CLAMP (RETURN LINE)	TATA spare parts
279750100121	HOSE	TATA spare parts
279750100122	ASSY.HOSE (RETURN LINE)	TATA spare parts
279750100132	PIPE ASSY WITH CLAMP RAD TO WATER PUMP	TATA spare parts
279750100137	ASSY. HOSE (AUX. TANK TO WATER INLET ELB	TATA spare parts
279750100138	ASSY PIPE (AUX TANK TO RADIATOR)(SUPERAC	TATA spare parts
279750100139	ASSY HOSE (BYPASS LINE)(SUPERACE)	TATA spare parts
279750100142	ASSY. PIPE (REDIATOR OUTLET)	TATA spare parts
279750100146	ASSY.PIPE(INTERMEDIATE HOSE TO RAD. INLE	TATA spare parts
279750100148	ASSY PIPE (WATERBOX HOSE OUTLET)(SUPERAC	TATA spare parts
279750100149	ASSY PIPE (AUX TANK TO RADIATOR)(VENTURE	TATA spare parts
279750100150	ASSY. PIPE (RADIATOR OUTLET) (SUPERACE B	TATA spare parts
279750100153	ASSY.OF VENT TUBE (UNDER FLOOR)	TATA spare parts

279750100161	ASSY. METAL PIPE WITH RUBBER HOSES	TATA spare parts
279750100162	ASSY.BRACKET (FOR AUX.TANK TO RAD.PIPE)	TATA spare parts
279750100164	ASSY.PIPE(AUX TANK TO RADIATOR)	TATA spare parts
279750100165	PIPE ASSY (WATERBOX HSG.OUTLET)	TATA spare parts
279750100178	PIPE ASSY;UCL TO RADIATOR	TATA spare parts
279750100179	PIPE ASSY WITH CLAMP;RADIATOR OUTLET	TATA spare parts
279750100180	VENT TUBE ASSY;ENGINE TO AUX WATER TANK	TATA spare parts
279750100181	VENT TUBE ASSY;ENGINE TO AUX WATER TANK	TATA spare parts
279750100186	AUX COOLANT TANK ASSY	TATA spare parts
279750100187	HOSE ASSY RETURN LINE	TATA spare parts
279750100188	PIPE ASSY WITH CLAMP RAD TO WATER PUMP	TATA spare parts
279750100189	PIPE & CLAMP ASSY	TATA spare parts
279750100191	PRESSURE CAP ASSY	TATA spare parts
279750100197	BYPASS TUBE ASSY	TATA spare parts
279750100198	PIPE ASSY;EGR COOLER OUTLET	TATA spare parts
279750100199	PIPE ASSY WITH HOSE	TATA spare parts
279750100204	BYPASS&TUBE&ASSY	TATA spare parts
279750100205	BRACKET&ASSY&RADIATOR&MTG&BOTTOM	TATA spare parts
279750100209	PIPE&ASSY&UCL&TO&RADIATOR	TATA spare parts
279750100210	PIPE&ASSY&WITH&CLAMP&RADIATOR&OUTLET	TATA spare parts
279750100211	VENT&TUBE&ASSY&ENGINE&TO&AUX&WATER&TAN	TATA spare parts
279750100212	PIPE&ASSY&WITH&CLAMP&RADIATOR&OUTLET	TATA spare parts
279750100213	BRACKET&ASSY&WITH&SLEEVE	TATA spare parts
279750100214	PIPE ASSY WITH CLAMP RADIATOR OUTLET	TATA spare parts
279750100216	PIPE ASSY WITH CLAMP RADIATOR OUTLET	TATA spare parts
279750103302	CLAMP FOR THERMOSTAT HOSE	TATA spare parts
279750103304	BRACKET (AUXTANK TO VENT PIPE RAD. HOSE)	TATA spare parts
279750105301	SEALING FOAM BS6	TATA spare parts
279750105302	SEALING FOAM BS6	TATA spare parts
279750105802	RUBBER HOSE	TATA spare parts
279750105809	HOSE (EGR COOLER TO RETURN LINE)	TATA spare parts
279750105814	RUBBER CAP	TATA spare parts
279750105815	RUBBER CAP (FOR COOLING HOSE) (20 DIA)	TATA spare parts
279750105826	RUBBER HOSE (EGR COOLER OUTLET) (SUPERAC	TATA spare parts
279750105830	VENT HOSE (RADIATOR)(SUPERACE BS-IV)	TATA spare parts
279750105831	RUBBER HOSE(THERMOSTAT HSG TO RAD.PIPE)	TATA spare parts
279750105834	HOSE (AUX TANK TO WATER BOX)(SUPERACE)	TATA spare parts
279750105857	RUBBER PIPE (REDIATOR PIPE END) SUPERACE	TATA spare parts
279750105858	HOSE (AUX TANK TO VENT PIPE RADIATOR) (S	TATA spare parts
279750105865	RUBBER HOSE( WATERBOX (PIPE TO RAD.INLET	TATA spare parts
279750105866	HOSE(OIL COOLER INLET) (SUPERACE BS-IV)	TATA spare parts
279750105868	HOSE(VENT TUBE TO WATER BOX)VENTURE	TATA spare parts
279750105871	VENT HOSE(VENT TUBE ON ENG.TO VENT TUBE	TATA spare parts
279750105880	VENT HOSE (VENT HOSE ON ENG. TO FLOOR)	TATA spare parts
279750105881	RUBBER HOSE (OIL COOLER INLET)	TATA spare parts
279750105882	RUBBER HOSE (OIL COOLER RETURN LINE)	TATA spare parts
279750105886	RUBBER HOSE WATER BOX TO RADIATOR	TATA spare parts

279750105887	HOSE VENT;METAL TUBE TO WATER BOX	TATA spare parts
279750105894	HOSE;RADIATOR OUTLET	TATA spare parts
279750105895	HOSE;AUX WATER TANK OUTLET	TATA spare parts
279750105896	RUBBER HOSE;RADIATOR TO AUX WATER TANK	TATA spare parts
279750105897	HOSE;CYL HEAD TO AUX WATER TANK	TATA spare parts
279750105898	RUBBER HOSE;RADIATOR INTAKE	TATA spare parts
279750107201	DRAIN PLUG	TATA spare parts
279750107501	SPACER;AUX TANK MTG	TATA spare parts
279750108201	CLAMP	TATA spare parts
279750108206	SUPPORT¿RADIATOR¿MTG	TATA spare parts
279750108207	BRACKET¿RADIATOR¿ASSY¿MTG¿RH	TATA spare parts
279750108208	BRACKET¿RADIATOR¿ASSY¿MTG¿LH	TATA spare parts
279750108210	SEALING PLATE RADIATOR FRAME TOP	TATA spare parts
279750115803	HOSE;OIL COOLER INTAKE	TATA spare parts
279750115804	HOSE;OIL COOLER OUTLET	TATA spare parts
279750115805	HOSE;EGR COOLER INTAKE	TATA spare parts
279750115806	HOSE WATER OUTLET HSG TO RAD PIPE	TATA spare parts
279750115814	HOSE¿AUX¿WATER¿TANK¿OUTLET	TATA spare parts
279750115815	HOSE¿AUX¿WATER¿TANK¿RADIATOR¿VENT	TATA spare parts
279750115816	RUBBER¿HOSE¿AUX¿TANK¿TO¿WATER¿PUMP	TATA spare parts
279750115817	HOSE¿VENT¿LINE¿TO¿RADIATOR	TATA spare parts
279750115818	RUBBER¿HOSE¿RADIATOR¿INTAKE	TATA spare parts
279750115819	HOSE¿RADIATOR¿TO¿WATER¿INTAKE¿ELBOW	TATA spare parts
279750115820	HOSE¿RADIATOR¿OUTLET	TATA spare parts
279750115821	RUBBER HOSE RADIATOR INTAKE	TATA spare parts
279750115822	RUBBER CAP COOLING HOSE BS6	TATA spare parts
279801134801	HOLLOW DOWEL (OIL SUMP UPPER-ALUMINIUM)	TATA spare parts
279801140104	ASSY.TIMING COVER (BOTTOM - FRONT)	TATA spare parts
279801155307	OUTER GASKET (FOR PLASTIC CYL.HEAD COV.)	TATA spare parts
279801156701	BALL HEAD PIN (ENGINE COVER MOUNTING)	TATA spare parts
279803140101	ASSY.OIL CONTROL RING	TATA spare parts
279803144301	INTEGRAL ROUND WIRE CIRCLIP	TATA spare parts
279803146701	PISTON PIN	TATA spare parts
279803150103	ASSY.CONNECTING ROD W/O BRG.SHELL	TATA spare parts
279803153402	CON.ROD BUSH BIMETAL	TATA spare parts
279803990104	PISTON SET WITHOUT RINGS GRADE A (IP)	TATA spare parts
279803990105	PISTON SET WITHOUT RINGS GRADE B (IP)	TATA spare parts
279803990106	PISTON SET WITHOUT RINGS GRADE C (IP)	TATA spare parts
279803990107	SET PISTON RINGS ABC (IP)	TATA spare parts
279805125101	VALVE SPRING RETAINER	TATA spare parts
279805128201	SPRING SEAT	TATA spare parts
279805157801	VALVE GUIDE SEAL M/S CR SCALS	TATA spare parts
279901000116	GEN.ASSY.ENGINE COMPLETE	TATA spare parts
279901000122	GENERAL ENGINE ASSEMBLY COMPLETE	TATA spare parts
279901000125	GENERAL ENGINE ASSEMBLY XENON CNG	TATA spare parts
279901000126	ENGINE ASSY. COMPLETE XENON CNG DOMESTIC	TATA spare parts
279901000127	ENGINE ASSEMBLY COMPLETE - WINGER CNG BS	TATA spare parts

279901000129	ENGINE ASSEMBLY XENON 486PL	TATA spare parts
279901000131	GEN.ENGINE ASSY COMPLETE WINGER BS IV WI	TATA spare parts
279901000136	GEN. ENGINE CNG WINGER EOBD-2	TATA spare parts
279901100111	ASSY.CYL.CRANKCASE W/O CL.HSG.(INTERMED)	TATA spare parts
279901100112	ASSY. CYL. CRANKCASE (W/O CLUTCH HSG.) I	TATA spare parts
279901130101	ASSY. OIL SUMP COMPLETE	TATA spare parts
279901140101	ASSY BACK PLATE (INTAKE SIDE)	TATA spare parts
279901148202	FRONT COVER (LOWER) (TIMING GEAR)	TATA spare parts
279901150110	CYL. HEAD With VALVES Safari petrol	TATA spare parts
279901150112	ASSY.CYL.HEAD W/O VALVES(INTERMEDIATE)	TATA spare parts
279901150118	ASSY.CYLINDER HEAD COMPLETE WITH VALVES	TATA spare parts
279901150120	ASSY.CYL.HEAD W/O VALVES(INTERMEDIATE)	TATA spare parts
279901150122	ASSY.CYLINDER HEAD COMPLETE WITH VALVES	TATA spare parts
279901150137	ASSY. INTEGRATED CAM COVER	TATA spare parts
279901150145	ASSY.CYLINDER HEAD CNG NTERMEDIATE STIFF	TATA spare parts
279901150147	ASSY.CYLINDER HEAD WITH VALVES	TATA spare parts
279901150149	ASSY. CYL HEAD W/O VALVES COMP 12CR	TATA spare parts
279901150150	ASSY. CYL HEAD W/O VALVES COMP 12CR	TATA spare parts
279901150151	ASSY.CYLINDER HEAD INTERMEDIATE(9.6CR)	TATA spare parts
279901150153	ASSY.CYLINDER HEAD WITH VALVES(9.6CR)	TATA spare parts
279901153201	BOLT (CYL.HEAD)	TATA spare parts
279901153202	BOLT (CYL.HEAD)	TATA spare parts
279901153206	PILLAR BOLT (FOR INTAKE MANIFOLD MTG.)	TATA spare parts
279901153207	PILLAR BOLT (FOR PLUG TOP COIL MTG.)	TATA spare parts
279901153208	BOLT (CYL HEAD)	TATA spare parts
279901153401	VALVE SEAT INSERT-NORMAL (EXHAUST VALVE)	TATA spare parts
279901153407	VALVE SEAT INSERT EXHAUST (NORMAL)	TATA spare parts
279901153413	VALVE SEAT INSERT - INLET NORMAL	TATA spare parts
279901153421	VALVE SEAT INSERT INTAKE NORMAL	TATA spare parts
279901153422	VALVE SEAT INSERT INTAKE NORMAL I	TATA spare parts
279901153425	VALVE SEAT INSERT EXHAUST NORMAL	TATA spare parts
279901153439	EXAHUST VSI-NORMAL	TATA spare parts
279901153443	VALVE SEAT INSERT INTAKE REPAIR	TATA spare parts
279901153444	VALVE SEAT INSERT EXHAUST REPAIR	TATA spare parts
279901153445	VALVE SEAT INSERT EXHAUST REPAIR I	TATA spare parts
279901154801	DOWEL TUBE	TATA spare parts
279901154802	DOWEL SLEEVE (FOR INTEGRATED CAM COVER)	TATA spare parts
279901155302	GASKET CYL.HEAD 1.3 THK.	TATA spare parts
279901155303	GASKET CYL.HEAD 1.45 THK.	TATA spare parts
279901155309	GASKET CYLINDER HEAD 1.25 THK. MLS	TATA spare parts
279901155310	GASKET CYLINDER HEAD 1.40 THK BS3/4	TATA spare parts
279901155801	RUBBER HOSE PTC COVER	TATA spare parts
279901156903	SPACER TUBE	TATA spare parts
279901157501	RUBBER GROMMET FOR PLUG TOP COIL	TATA spare parts
279901157701	GASKET (PLUG TOP COIL)	TATA spare parts
279901157707	GASKET OUTER(INT.CAMCOVER)	TATA spare parts
279901157708	GASKET INNER (INT.CAMCOVER)	TATA spare parts

279901158201	COVER (PLUG TOP COIL) (B)	TATA spare parts
279901158801	STUD (FOR CAP BEARING CAMSHAFT MTG.)	TATA spare parts
279901159201	WASHER(CYL.HEAD BOLT)	TATA spare parts
279901170101	ASSY. DIPSTICK TUBE	TATA spare parts
279901170102	ASSY.DIPSTICK	TATA spare parts
279901170107	ASSY. DIPSTICK TUBE	TATA spare parts
279901170109	ASSY. DIPSTICK	TATA spare parts
279901170112	ASSY.SPIDER HOSE (OIL SEPARATOR)	TATA spare parts
279901170113	ASSY. DIPSTICK	TATA spare parts
279901170114	ASSY. DIPSTICK TUBE	TATA spare parts
279901170115	ASSY. OIL MIST SEPARATOR	TATA spare parts
279901170116	ASSY. SPIDER HOSE (OIL SEPARATOR)	TATA spare parts
279901170119	ASSY. SPIDER HOSE (OIL SEPERATOR)	TATA spare parts
279901170123	ASSY. DIPSTICK TUBE	TATA spare parts
279901170129	ASSY. RUBBER HOSE	TATA spare parts
279901175807	RUBBER HOSE (CAM COVER TO OIL SEPARATOR)	TATA spare parts
279901175808	RUBBER HOSE (RIBBED HOSE TO OIL SEPARAT)	TATA spare parts
279901175809	RUBBER HOSE (OIL SEPERAT TO BLOW BY PIPE	TATA spare parts
279901175812	RUBBER HOSE (OIL SEP. TO OIL SUMP)	TATA spare parts
279901175813	RUBBER HOSE (OMS TO THROTTLE BODY)	TATA spare parts
279901175814	RUBBER HOSE(OIL SEPARATOR TO MTB)	TATA spare parts
279901175817	RUBBER HOSE (OIL SEP.TO THROTTLE)XENON P	TATA spare parts
279901990102	ASSY.CYLINDER CRANKCASE W/O CLUTCH HSG.	TATA spare parts
279901990108	ENGINE OVERHAUL SEAL KIT	TATA spare parts
279901990113	BARE ENGINE/LONG BLOCK W/O HVAC (TM/CC)	TATA spare parts
279901990116	HALF BLOCK (TELCOLINE EURO-II)	TATA spare parts
279901990118	ENGINE OVERHAUL GASKET KIT	TATA spare parts
279901990119	DECARBONISING GASKET KIT	TATA spare parts
279901990123	HALF BLOCK XENON 486 CNG	TATA spare parts
279901990124	BARE ENGINE XENON 486 CNG	TATA spare parts
279901990154	HALF BLOCK (WINGER)	TATA spare parts
279901990166	BARE ENGINE WINGER CNG	TATA spare parts
279901990168	HALF BLOCK XENON 486 CNG EX PACKAGE	TATA spare parts
279901990169	LONG BLOCK XENON 486 CNG EX PACKAGE	TATA spare parts
279901990179	DECARBONISING GASKET KIT XENON PETROL	TATA spare parts
279901990180	ENGINE OVERHAUL GASKET KIT XENON PETROL	TATA spare parts
279901990181	HALF BLOCK XENON PETROL	TATA spare parts
279901990182	LONG BLOCK XENON PETROL EURO2	TATA spare parts
279901990189	KIT ASSY.CYL.HEAD WITH VALVES12CR	TATA spare parts
279901990192	LONG BLOCK XENON 486 CNG	TATA spare parts
279901990193	HALF BLOCK XENON 486 CNG	TATA spare parts
279901990194	DECARBONISING GASKET KIT XENON 486 CNG	TATA spare parts
279901990195	ENGINE OVERHAUL GASKET KIT XENON 486 CNG	TATA spare parts
279901990205	LONG BLOCK WINGER CNG 12 CR	TATA spare parts
279901990216	LONG BLOCK WINGER 10.2CR AC BS-IV	TATA spare parts
279903110102	ASSY.FLYWHEEL WITH RING GEAR(INTG.TEETH)	TATA spare parts
279903110103	ASSY.FLYWHEEL WITH RING GEAR-INTEG.TEETH	TATA spare parts

279903110104	ASSY.FLYWHEEL (WITH RING GEAR-INTEGRAL T	TATA spare parts
279903130101	ASSY.VIBRATION DAMPER	TATA spare parts
279903130102	ASSY.VIB.DAMPER(M/S VIBROMECH)	TATA spare parts
279903140104	ASSY.OIL CONTROL RING( I LTD)	TATA spare parts
279903146604	PISTON A	TATA spare parts
279903146610	PISTON A (WITH VALVE POCKET)	TATA spare parts
279903146701	PISTON PIN	TATA spare parts
279903149902	SECOND RING ( I LTD.)	TATA spare parts
279903149905	TOP RING { (I) LTD}	TATA spare parts
279903990102	SET PISTON RINGS	TATA spare parts
279903990103	SET PISTON A W/O RINGS	TATA spare parts
279903990104	SET PISTON B W/O RINGS	TATA spare parts
279903990105	SET PISTON C W/O RINGS	TATA spare parts
279905100108	ASSY.CAMCHAIN TENSIONER	TATA spare parts
279905107902	CAMSHAFT EXHAUST (TORQUE VERSION)	TATA spare parts
279905107904	CAMSHAFT INTAKE	TATA spare parts
279905107905	CAMSHAFT INTAKE	TATA spare parts
279905107906	CAMSHAFT EXHAUST	TATA spare parts
279905109901	STEEL ROLLER CHAIN (CAMSHAFT)	TATA spare parts
279905110101	ASSY IDLER (TIMING BELT)	TATA spare parts
279905110102	ASSY. IDLER	TATA spare parts
279905113101	ASSY. BEARING	TATA spare parts
279905113201	HEX.FL.BOLT FOR TIMING BELT IDLER	TATA spare parts
279905115401	PULLEY (EXHAUST CAMSHAFT)	TATA spare parts
279905116302	TIMING BELT - GD100 (M/S GATES)	TATA spare parts
279905118601	SPACER (TIMING BELT IDLER)	TATA spare parts
279905119201	HARDENED WASHER (FOR CAM CAP MTG.)	TATA spare parts
279905129006	EXHAUST VALVE	TATA spare parts
279905129009	INLET VALVE	TATA spare parts
279905129014	EXHAUST VALVE	TATA spare parts
279905129015	INLET VALVE	TATA spare parts
279905129018	EXHAUST VALVE	TATA spare parts
279905129026	EXHAUST VALVE	TATA spare parts
279905129027	INLET VALVES	TATA spare parts
279905130101	ASSY. HYDRAULIC TAPPET 4PL	TATA spare parts
279905153401	VALVE GUIDE NORMAL	TATA spare parts
279905153403	VALVE GUIDE NORMAL	TATA spare parts
279905153404	VALVE GUIDE NORMAL	TATA spare parts
279905153410	VALVE GUIDE NORMAL I	TATA spare parts
279905153411	VALVE GUIDE NORMAL	TATA spare parts
279905153415	VALVE GUIDE NORMAL	TATA spare parts
279905153417	VALVE GUIDE	TATA spare parts
279905990103	MINOR INTAKE VALVE KIT	TATA spare parts
279905990105	MINOR EXHAUST VALVE KIT	TATA spare parts
279905990111	MINOR VALVE KIT ASSY	TATA spare parts
279907100101	ASSY.FUEL RAIL	TATA spare parts
279907100102	ASSY.FUEL RAIL	TATA spare parts

279907100112	ASSY.FUEL RAIL - 486CNG	TATA spare parts
279907100121	ASSY. FUEL RAIL - 486CNG EOBD	TATA spare parts
279907103304	INJECTOR RETAINER (B)	TATA spare parts
279907108401	INJECTOR CLIP	TATA spare parts
279909125301	GASKET-THROTTLE BODY	TATA spare parts
279909125302	GASKET (ELECTRONIC THROTTLE CONTROL)	TATA spare parts
279909125801	PLUG (FOR THROTTLE BODY)	TATA spare parts
279909130101	ASSY.BRACKET (AIR FILTER MTG.)	TATA spare parts
279909130105	ASSY.AIR FILTER COMPLETE	TATA spare parts
279909130107	ASSY.RUBBER HOSE (INTAKE HOSE-AIRFILTER)	TATA spare parts
279909130109	ASSY.FILTER ELEMENT	TATA spare parts
279909130115	ASSY. SUPPORT BRACKET	TATA spare parts
279909130123	ASSY BRACKET COMPLETE (AIR FILTER MTG)	TATA spare parts
279909130124	ASSY. BRACKET (AIR FILTER MTG.)	TATA spare parts
279909130125	RIBBED HOSE (ADAPTER TO ETC)	TATA spare parts
279909130126	ASSEMBLY ADAPTER SUPPORT BRACKET	TATA spare parts
279909130127	RIBBED HOSE(ADAPTER TO ETC)	TATA spare parts
279909130132	ASSY.AIR FILTER COMPLETE	TATA spare parts
279909130136	ASSY.BRACKET (FOR AIR FILTER MTG.)	TATA spare parts
279909130137	ASSY. FILTER ELEMENT	TATA spare parts
279909133304	CLAMP (FOR ADAPTOR PIPE)	TATA spare parts
279909135805	RIBBED HOSE(AIR FILTER TO THROTTLE BODY)	TATA spare parts
279909135807	HOSE (RIBBED HOSE TO AIR BY PASS VALVE)	TATA spare parts
279909135808	RUBBER HOSE (AIR FILTER TO ADAPTOR)	TATA spare parts
279909135809	RUBBER HOSE(ADAPTER TO AIR FILTER)	TATA spare parts
279909135814	RUBBER HOSE (BYPASS VALVE)	TATA spare parts
279909135818	RUBBER HOSE (AIR FILTER TO SNORKEL)	TATA spare parts
279909135819	RIBBED HOSE (AIR FILTER TO THROTTLE BODY)	TATA spare parts
279909135820	RIBBED HOSE (AIRFILTER TO ETB)	TATA spare parts
279909135821	RUBBER HOSE (RIBBED HOSE TO AIR BY PASS	TATA spare parts
279909135823	RIBBED HOSE AIR FILTER TO ETB	TATA spare parts
279909136301	ASSY. SNORKEL	TATA spare parts
279909136302	ADAPTER AIR INTAKE	TATA spare parts
279909136303	SNORKEL - AIR INTAKE PLASTIC	TATA spare parts
279909136904	ADAPTOR (AIR FILTER TO THROTTLE)	TATA spare parts
279909137701	RUBBER STRAP WITH CUTOUT	TATA spare parts
279909137703	RUBBER STRAP FOR AIR FILTER	TATA spare parts
279914100102	ASSY.INTAKE MANIFOLD	TATA spare parts
279914100103	ASSY. INTAKE MANIFOLD CNG	TATA spare parts
279914100104	INLET MANIFOLD FOR ETC	TATA spare parts
279914100106	ASSY. INTAKE MANIFOLD (XENON 486PL)	TATA spare parts
279914103808	INTAKE MANIFOLD	TATA spare parts
279914105303	INTAKE MANIFOLD GASKET	TATA spare parts
279914105801	RUBBER HOSE (PCV VALVE-INTAKE MANIFOLD)	TATA spare parts
279914106901	NIPPLE BLOW BY (PCV)	TATA spare parts
279914106902	NIPPLE (CPV)	TATA spare parts
279914106903	NIPPLE (B)	TATA spare parts



279914106905	NIPPLE RESTRICTOR	TATA spare parts
279914107701	PLASTIC CLAMP FOR BOW BYE HOSE	TATA spare parts
279914108201	CLAMP BLOW BY HOSE ROUTING	TATA spare parts
279914110101	ASSY.HEAT SHIELD(FOR EXHAUST MANIFOLD)	TATA spare parts
279914110119	HEAT SHIELD (FOR EXHAUST MANIFOLD)	TATA spare parts
279914113701	ASSY.EXHAUST MANIFOLD	TATA spare parts
279914115301	GASKET EXHAUST MANIFOLD	TATA spare parts
279914115302	GASKET (EXHAUST MANIFOLD)	TATA spare parts
279915140106	ASSY.STAY (FOR ALTERNATOR)	TATA spare parts
279915140109	ASSY.BRACKET (FOR STAY,ALTERNATOR)	TATA spare parts
279915140115	ASSY.STAY (FOR ALTERNATOR)	TATA spare parts
279915143701	BRACKET (ALTERNATOR & PSTG PUMP MTG.)	TATA spare parts
279915143702	BRACKET(FOR STAY ALTERNATOR)	TATA spare parts
279915146304	POLY V BELT (6PK)-M/S SAMSONS	TATA spare parts
279915146307	POLY V BELT	TATA spare parts
279915146308	POLY V BELT	TATA spare parts
279915189901	SPARK PLUG BS3/4	TATA spare parts
279915210101	AIR BYPASS VALVE	TATA spare parts
279915210102	ASSY.THROTTLE BODY	TATA spare parts
279915210105	ASSY.CLAMP (CPV MTG.)	TATA spare parts
279915210108	ECU SOFTWARE LABEL(FOR COMPONENT ORDER)	TATA spare parts
279915210114	ASSY BRACKET (FOR IGNITION COIL MTG ON I	TATA spare parts
279915210115	ASSY BRACKET	TATA spare parts
279915210116	ETC (ELCETRONIC THROTTLE CONTROL)	TATA spare parts
279915210119	ELECTRONIC THROTTLE CONTROL (ETC)	TATA spare parts
279915210120	ECU SOFTWARE LABLE (FOR COMPONENT ORDER)	TATA spare parts
279915210123	ECU SOFTWARE LABEL(FOR COMPONENT ORDER)	TATA spare parts
279915210124	ELECTRONIC THROTTLE BODY	TATA spare parts
279915210140	ECU SOFTWARE LABLE (FOR COMPONENT ORDER)	TATA spare parts
279915213801	AIR BYPASS VALVE	TATA spare parts
279915214201	SUPPORT CLAMP(CANISTER PURGE VALVE MTG)	TATA spare parts
279915219903	HEATED LAMBDA SENSOR(07LS)	TATA spare parts
279915219904	FUEL INJECTOR	TATA spare parts
279915219905	HIGH TENSION CABLE-810L	TATA spare parts
279915219906	HIGH TENSION CABLE 680L	TATA spare parts
279915219907	HIGH TENSION CABLE 620L	TATA spare parts
279915219908	HIGH TENSION CABLE 580L	TATA spare parts
279915219914	INJECTOR CNG	TATA spare parts
279915219915	HT CABLE NO.01 L=255 CNG	TATA spare parts
279915219916	HT CABLE NO.02 L=445 CNG	TATA spare parts
279915219917	HT CABLE NO.03 L=715 CNG	TATA spare parts
279915219918	HT CABLE NO.04 L=800 CNG	TATA spare parts
279915219919	ECU HARDWARE CNG	TATA spare parts
279915219927	ECU HARDWARE BS4	TATA spare parts
279915219938	INJECTOR NGI2 CP CNG	TATA spare parts
279915997701	O-RING TOP(FUELRAIL CUP SIDE) OD.7.52	TATA spare parts
279915997702	O-RINGç BOTTOM(INJECTOR HOLE SIDE) OD8.3	TATA spare parts

279918100102	ASSY. OIL PUMP COMPLETE	TATA spare parts
279918150105	ASSY.STRAINER COMPLETE	TATA spare parts
279918173301	HEAT SHIELD (OIL COOLER HOSE)	TATA spare parts
279918175301	GASKET (OIL PASSAGE COVER)	TATA spare parts
279918175802	HOSE (OIL COOLER/COOLANT BY PASS)	TATA spare parts
279918175803	HOSE(OIL COOLER TO ASSY.TUBE)	TATA spare parts
279918176101	BLANKING PLATE(OIL PASSAGE COVER)	TATA spare parts
279918176102	BLANKING PLATE (OIL PASSAGE COVER)	TATA spare parts
279918176901	NIPPLE (ON CRANKCASE)	TATA spare parts
279920100105	ASSY. WATER PUMP BS3/4	TATA spare parts
279920120101	ASSY.PIPE(COOLANT BY PASS)	TATA spare parts
279920120102	ASSY.TUBE(OIL COOLER OUTLET)	TATA spare parts
279920120104	ASSY.COVER THERMOSTAT	TATA spare parts
279920120110	ASSY. RUBBER HOSE WITH HEAT SHIELD	TATA spare parts
279920123801	ELBOW (WATER INLET)	TATA spare parts
279920123805	THERMOSTAT COVER	TATA spare parts
279920124201	HOSE CLAMP DIA.26X9	TATA spare parts
279920125801	HOSE(ASSY.BYPASS PIPE TO ASSY.TUBE)	TATA spare parts
279920125802	HOSE(ASSY.TUBE TO ELBOW)	TATA spare parts
279920125803	RUBBER HOSE(THERMOSTAT COVER TO RADIATO	TATA spare parts
279920125804	RUBBER HOSE (ASSY.PIPE TO ELBOW & OIL CO	TATA spare parts
279920125807	RUBBER HOSE OIL COOLER/COOLANT BY PASS	TATA spare parts
279922000105	ASSY. ENGINE COVER	TATA spare parts
279922000106	ASSY BRACKET (ON INTAKE MANIFOLD ENG)	TATA spare parts
279922000107	ASSY BRACKET REAR (ENGINE COVER MTG)	TATA spare parts
279922000108	ASSY BRACKET FRONT (ENGINE CVR MTG)	TATA spare parts
279922103301	BRACKET(H.T.CABLE SUPPORT)	TATA spare parts
279922107101	LIFTING HOOK (REAR)	TATA spare parts
279923116301	POLY V BELT 6	TATA spare parts
279923116302	POLY V BELT	TATA spare parts
279923123704	BRACKET (A/C COMP.BKT.)	TATA spare parts
279924100102	ASSY.HEAT SHIELD (ENGINE MOUNT RH)	TATA spare parts
279932404201	U CLAMP	TATA spare parts
279950100118	ASSY.RADIATOR WITH FANS & SHROUD	TATA spare parts
279950100119	RADIATOR ASSY.	TATA spare parts
279950100121	PRESSURE CAP	TATA spare parts
279950100124	FAN MOTOR ASSY.(266 DIA.& 240 WATT)	TATA spare parts
279950100125	FAN MOTOR ASSY.(305 DIA.& 240 WATT)	TATA spare parts
279950100127	ASSY. CLAMP (FOR LCL PIPE)	TATA spare parts
279950100129	ASSEMBLY PIPE	TATA spare parts
279950100131	ASSY. RADIATOR COMPLETE	TATA spare parts
279950100132	ASSY.RADIATOR COMPLETE WITH FANS	TATA spare parts
279950100135	ASSY. RUBBER HOSE (THERMOATAT TO RADIATO	TATA spare parts
279950100138	ASSY. RUBBER HOSE (THERMOSTAT-RADIATOR)	TATA spare parts
279950100140	ASSY. RUBBER HOSE WITH CRIMPED HOSE	TATA spare parts
279950100143	ASSY. RUBBER HOSE (THERMOSTAT TO RADIATO	TATA spare parts
279950100144	ASSY. RUBBER HOSE (THERMOSTAT TO RADIATO	TATA spare parts

279950100145	ASSY.RADIATOR COMPL.WITH FANS& FANSHROU	TATA spare parts
279950100146	RADIATOR	TATA spare parts
279950104201	CLAMP (FOR LOWER COOLING HOSE)	TATA spare parts
279950104202	CLAMP (FOR LOWER COOLING LINE HOSE)	TATA spare parts
279950105804	RUBBER HOSE (RADIATOR TO ELBOW)	TATA spare parts
279950105806	RUBBER HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
279950105807	RUBBER HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
279950105809	RUBBER HOSE (RADIATOR TO PIPE)	TATA spare parts
279950105810	RUBBER HOSE(LCL PIPE TO ELBOW WATER INL)	TATA spare parts
279950105811	RUBBER HOSE (RADIATOR OUTLET TO ENGINE)	TATA spare parts
279950105814	RUBBER HOSE LCL (RADIATOR OUTLET TO ENGI	TATA spare parts
279950105815	RADIATOR VENT HOSE	TATA spare parts
279950105820	RUBBER HOSE (THERMOSTAT TO RADIATOR)	TATA spare parts
279950106901	RUBBER TUBE ( 1360 )	TATA spare parts
279950108001	POINTED SCREW (RADIATOR MTG.)	TATA spare parts
279950500102	ASSY.FANSHROUD	TATA spare parts
280142300125	ASSY REAR BRAKE RH WITH D/C	TATA spare parts
280142300127	ASSY REAR BRAKE LH WITH D/C	TATA spare parts
280142300188	ASSY. REAR BRAKE-L.H FOR TRAILER AXLE	TATA spare parts
280142300189	ASSY. REAR BRAKE-R.H FOR TRAILER AXLE	TATA spare parts
280142305101	CAM SHAFT - LH	TATA spare parts
280142305102	CAM SHAFT - RH	TATA spare parts
280224200101	ASSY. ENGINE MTG. BRACKET (REAR) LH	TATA spare parts
280224200102	ASSY. ENGINE MTG. BRACKET (REAR) RH	TATA spare parts
280226800102	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
280226806301	SPACER	TATA spare parts
280226810101	SUB.ASSY BRACKET (G.S.LEVER MOUNTING)	TATA spare parts
280228006901	SPACER TUBE ( 35 LONG )	TATA spare parts
280228500101	AGB MTG BKT LOWER LH	TATA spare parts
280228500102	AGB MTG BKT LOWER RH	TATA spare parts
280228500107	ASSY BRACKET (A.G.B. MTG.)	TATA spare parts
280228500108	ASSY BKT AGB MTG (BKT TO LM)	TATA spare parts
280228500109	ASSY BAR AGB MTG RH	TATA spare parts
280228500110	ASSY BAR AGB MTG LH	TATA spare parts
280228506702	AGB PIN	TATA spare parts
280228506703	AGB PIN	TATA spare parts
280228510101	AGB CONTROL VALVE	TATA spare parts
280228990101	KIT FOR AGB MTG & TYRE PRESSURE STICKER	TATA spare parts
280228990105	KIT FOUR POINT MOUNTING ARRANGEMENT	TATA spare parts
280229100103	ASSY BRACKET (CLUTCH PEDAL MTG)	TATA spare parts
280229100104	ASSY PEDAL STOPPER (FLOOR)	TATA spare parts
280229100107	ASSY CONNECTING LINE (TANK TO CMC)	TATA spare parts
280229100108	ASSY CLUCTH PEDAL COMPLETE	TATA spare parts
280229100113	ASSY.TUBE (6 O.D.X1780LG) -CL M/CYL TO S	TATA spare parts
280229100114	ASSY.TUBE (6 O.D.X 2250LG)	TATA spare parts
280229100122	ASSY BRACKET (MASTER CYLINDER MTG)	TATA spare parts
280229100129	ASSY CLUTCH PEDAL LEVER COMPLETE	TATA spare parts

280229100130	ASSY BRACKET (MASTER CYL MTG)	TATA spare parts
280229100133	CLUTCH MASTER CYLINDER	TATA spare parts
280229100139	ASSY TUBE 6 O.DX2750LG(HOSE TO CLUTCH BO	TATA spare parts
280229100140	ASSY TUBE 6 O.DX970LG(MASTER CYLINDER TO	TATA spare parts
280229108206	BRACKET (MASTER CYL MTG)	TATA spare parts
280230100101	ASSY PEDAL LEVER ACCELERATOR	TATA spare parts
280230100102	ASSY ACCL CABLE MTG BKT ON ENGINE	TATA spare parts
280230103301	EXTENSION ROD	TATA spare parts
280230107103	SPRING BRACKET	TATA spare parts
280230108201	BRACKET (ENG STOP RETURN SPRING)	TATA spare parts
280230200101	ASSY PULL CABLE ENGINE STOP	TATA spare parts
280230200102	ASSY PULL CABLE ACCELERATOR	TATA spare parts
280231000101	ASSY. FRAME COMPLETE	TATA spare parts
280231000107	ASSY FRAME	TATA spare parts
280231200101	ASSY. SUPPORT R.H (ENGINE C.M FRONT)	TATA spare parts
280231200102	ASSY. SUPPORT L.H (ENGINE C.M FRONT)	TATA spare parts
280231200103	ASSY.BRACKET R.H. (RADIATOR MOUNTING)	TATA spare parts
280231200104	ASSY.BRACKET L.H. (RADIATOR MOUNTING)	TATA spare parts
280231200112	ASSY CAB TIE MEMBER	TATA spare parts
280231208202	BRACKET (CAB HEATER DIESEL PUMP MTG)	TATA spare parts
280231208203	BRACKET FOR REAR AXLE BREATHER MTG	TATA spare parts
280231208204	BRACKET FOR FRONT AXLE BREATHER MTG	TATA spare parts
280231300102	CROSS MEMBER FOR AGB MTG	TATA spare parts
280231307101	REINFORCEMENT R.H(FRONT SPRING BKT REAR)	TATA spare parts
280231307102	REINFORCEMENT L.H	TATA spare parts
280231307103	SUPPORT TOP RH/ FOURTH C.M	TATA spare parts
280231307104	SUPPORT TOP LH/ FOURTH C.M	TATA spare parts
280231307105	CROSS MEMBER 6TH	TATA spare parts
280231308201	EXTENSION PIECE R.H (LONG MEMBER)	TATA spare parts
280231308202	EXTENSION PIECE L.H (LONG MEMBER)	TATA spare parts
280232100101	ASSY FRONT SPRING	TATA spare parts
280232107102	SPACER(BETWEEN AXLE AND FRONT SPRING	TATA spare parts
280232300103	ASSY BRKT-LH (FRONT S/A BTM)	TATA spare parts
280232300104	ASSY BRKT-RH (FRONT S/A BTM)	TATA spare parts
280232400103	ASSY REAR SPRING	TATA spare parts
280232403201	CENTER BOLT(LENGTH -255)	TATA spare parts
280232404201	U CLAMP OF LPTA 1623	TATA spare parts
280232404202	U CLAMP -REAR	TATA spare parts
280232404204	SPRING CLIP	TATA spare parts
280232407101	SPACER ( REAR SPRING-AXLE)	TATA spare parts
280232407102	CASTER PLATE (REAR AXLE)	TATA spare parts
280240100101	WHEEL RIM 10.00X20(165 OFFSET )	TATA spare parts
280240106301	TYRE 14.00R20-22PR SAND CUM HIGHWAY	TATA spare parts
280240300110	ASSY SPARE WHEEL LIFTING UNIT	TATA spare parts
280240300119	ASSY.PULLEY OF LPTA 1623	TATA spare parts
280240300125	ASSY. WIRE ROPE OF LPTA 1623	TATA spare parts
280240300128	ASSY.LONG RUNNER COMPLETE LH	TATA spare parts

280240300129	ASSY.LONG RUNNER COMPLETE-RH	TATA spare parts
280240300139	KIT FOR SPARE WHEEL LIFTING UNIT	TATA spare parts
280240300166	ASSY HANDLE (SPARE WHEEL LIFTING UNIT)	TATA spare parts
280240300172	ASSY WIRE ROPE(6M LONG)	TATA spare parts
280240300175	KIT SWC WINCH ACTUATION UNIT	TATA spare parts
280240300176	ASSY SPARE WHEEL CAREER KIT	TATA spare parts
280240300177	ASSY FRAME COMPLETE	TATA spare parts
280240305401	PINION	TATA spare parts
280240306711	PIN ARM	TATA spare parts
280240307112	PLATE LOCKING PIN	TATA spare parts
280240309202	SPACER	TATA spare parts
280240990102	RETRO KIT FOR SPARE WHEEL	TATA spare parts
280240993201	FA WHEEL BOLT	TATA spare parts
280240993202	RA WHEEL BOLT	TATA spare parts
280241100102	ASSY.PROPELLER SHAFT (AUX GEAR BOX TO LI	TATA spare parts
280241100103	ASSY.PROPELLER SHAFT( AUX GEAR BOX TO RE	TATA spare parts
280241100116	ASSY.PROP SHAFT(GEAR BOX TO AUX GEAR BOX	TATA spare parts
280241120109	ASSY. PROP. SHAFT TRANSFER CASE TO REAR	TATA spare parts
280241120110	ASSY PROP.SHAFT INTERAXLE SHAFT	TATA spare parts
280241120111	ASSY PROP.SHAFT TRANSFR CASE TO FRONT AX	TATA spare parts
280241120112	ASSY.PROP SHAFT GB TO TRANSFER CASE	TATA spare parts
280241120113	FLANGE YOKE	TATA spare parts
280241120114	ASSY PROPELLER SHAFT (AGB TO RA)	TATA spare parts
280241120115	LONG FORK SUB ASSY	TATA spare parts
280241120116	SHORT FORK AND REAR HOUSING ASSY	TATA spare parts
280241120117	FLANGE YOKE	TATA spare parts
280241120118	CROSS ASSY	TATA spare parts
280241120119	LONG FORK SUB ASSY	TATA spare parts
280241120120	SHORT FORK AND REAR HOUSING ASSY	TATA spare parts
280242100107	ASSY.F/A BRAKE RH WITH D COVER	TATA spare parts
280242100107AE	ASSY.F/A BRK RH W/ D COVER-1628	TATA spare parts
280242100108	ASSY.F/A BRAKE LH WITH D COVER	TATA spare parts
280242100108AE	ASSY.F/A BRK LH W/D COVER-1628	TATA spare parts
280242100117	ASSY.FRONT BRAKE-CHAMBER MTG.BRACKET-LH.	TATA spare parts
280242100118	ASSY.FRONT BRAKE-CHAMBER MTG.BRACKET-R.H	TATA spare parts
280242100123	SPIDER ASSY WITH BUSHES AND SEAL LH	TATA spare parts
280242100124	SPIDER ASSY WITH BUSHES AND SEAL RH	TATA spare parts
280242100127	GREASE FITTING	TATA spare parts
280242100128	PLUMMER BLOCK ASSY WITH BUSH SEAL & GREASE	TATA spare parts
280242105101	CAM SHAFT LH	TATA spare parts
280242105102	CAM SHAFT RH	TATA spare parts
280242108209	DUST SHIELD - TOP	TATA spare parts
280242108210	DUST SHIELD - BOTTOM	TATA spare parts
280242108601	SPACER- CAMSHAFT	TATA spare parts
280242300106	BRAKE WITH DC (RH) FWD + RWD	TATA spare parts
280242300107	BRAKE WITH DC (LH) FWD + RWD	TATA spare parts
280243700108	AIR DRYER 9 BAR WITH TYRE INFLATER	TATA spare parts

280243703301	TCV MTG. BKT	TATA spare parts
280243900104	ASSY.TUBE WITH CRIMPED HOSE(COMP.INLET)	TATA spare parts
280243900106	ASSY NYLON PIPE SET	TATA spare parts
280243900107	ASSY PIPE 15X1.5X4060LG	TATA spare parts
280243900108	ASSY PIPE 15X1.5X1700LG	TATA spare parts
280243900113	ASSY NYL PIPE SET COMPLETE	TATA spare parts
280243900126	COMP OUTLET 1ST PIPE	TATA spare parts
280243900127	ASSY COMP OUTLET 2ND METAL PIPE	TATA spare parts
280243900128	ASSY COMP OUTLET 3RD METAL PIPE	TATA spare parts
280243903301	BRACKET LCRV MTG	TATA spare parts
280243908202	TEE MTG. BKT. FOR REAR FORWARD AXLE.	TATA spare parts
280243908203	TEE MTG. BKT. FOR REAR REARWARD AXLE.	TATA spare parts
280243910106	COMP INLET PIPE (18OD)	TATA spare parts
280245300101	FRONT BREATHER HOSE ASSY	TATA spare parts
280246000102	ASSY DRAG LINK	TATA spare parts
280246000104	DRAG LINK ASSY	TATA spare parts
280246100101	ASSY STG GEAR BOX MTG BRACKET	TATA spare parts
280246100103	ASSY STG COLUMN SUPPORT	TATA spare parts
280246100106	ASSY STG GEAR BOX MTG BKT	TATA spare parts
280246100108	ASSY BRACKET LH HYD.RESERVOIR SUPPORT	TATA spare parts
280246106302	RUBBER BELLOWS	TATA spare parts
280246107105	BRACKET (STEERING RESERVIOR MTG)	TATA spare parts
280246200104	ASSY.STEERING SPINDLE MIDDLE	TATA spare parts
280246800107	ASSY SET PIPELINES AND CLAMPS	TATA spare parts
280246800116	PRESSURE LINE HOSE ASSY	TATA spare parts
280246800117	RETURN LINE HOSE ASSY.(TANK END)	TATA spare parts
280246800122	ASSY PIPELINE AND CLAMPS	TATA spare parts
280246800123	ASSY RETURN PIPE-II	TATA spare parts
280246800124	ASSY SUCTION HOSE- CRIMPED (STG TANK TO	TATA spare parts
280247100103	ASSY. DIPSTICK (FUEL)	TATA spare parts
280247100104	ASSY. FUEL TANK COMPLETE (400 LTR RECT)	TATA spare parts
280247100108	ASSY FUEL TANK COMP-(300 LTS RECT )	TATA spare parts
280247500101	ASSY SUPPORT (RECT FUEL TANK 400 LTR)	TATA spare parts
280247500102	ASSY STRAP	TATA spare parts
280247500103	FUEL TANK SUPPORT	TATA spare parts
280247507701	RUBBER PACKING	TATA spare parts
280247507702	PROFILED RUBBER PACKING	TATA spare parts
280247600102	ASSY. SUCTION TUBE WITH STRAINER	TATA spare parts
280247600107	ASSY. RETURNED TUBE WITH CRIMPED HOSS	TATA spare parts
280247600108	ASSY. SUCTION TUBE WITH CRIMPED HOSS.	TATA spare parts
280247600114	ASSY FUEL LINE FUEL WATER SEPARATOR TO E	TATA spare parts
280247600115	ASSY FUEL LINE ENGINE TO TANK	TATA spare parts
280247600116	ASSY FUEL SUCTION LINE FUEL TANK TO W/S	TATA spare parts
280247700103	FUEL WATER SEPERATOR WITH HEAD & HEATER	TATA spare parts
280249100101	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
280249100103	ASSY EXHAUST PIPE (EXH BRAKE TO MUFFLER)	TATA spare parts
280249100105	ASSY BRACKET (EXHAUST PIPE MTG)	TATA spare parts

280249108201	BRACKET (EXHAUST PIPE MOUNTING)	TATA spare parts
280249200101	ASSY EXHAUST PIPE FIRST	TATA spare parts
280249200102	ASSY EXHAUST PIPE SECOND(81.2 OD)	TATA spare parts
280249200103	ASSY BRACKET SIENCER MTG	TATA spare parts
280249200106	ASSY. BRACKET (SILENCER MOUNTING)	TATA spare parts
280249200107	ASSY BRACKET (SILENCER MOUNTING)	TATA spare parts
280249200108	ASSY TAIL PIPE	TATA spare parts
280249203301	BRACKET	TATA spare parts
280249207102	TAIL PIPE MOUNTING BRACKET	TATA spare parts
280249208201	CLAMP	TATA spare parts
280249208202	CLAMP	TATA spare parts
280249208209	CLAMP (SILENCER MOUNTING)	TATA spare parts
280249208218	RIB	TATA spare parts
280249209901	HEAT SHIELD	TATA spare parts
280249209902	HEAT SHIELD	TATA spare parts
280254100103	ASSY BATTERY CARRIER WELDED COMPLETE.	TATA spare parts
280254100105	ASSY BATT CABLE CU (+VE) 900 MM	TATA spare parts
280254100106	ASSY BATT CABLE LUG(+VE) -3000 MM	TATA spare parts
280254100107	ASSY BATT CABLE BATTERY TO BCS(+VE)1800M	TATA spare parts
280254100108	ASSY BATT CABLE BATTERY TO BCS(-VE)1500M	TATA spare parts
280254100109	ASSY BATT CABLE BCS TO SM(+VE)1650MM	TATA spare parts
280254100110	ASSY BATT CABLE SM TO BCS(-VE)1750MM	TATA spare parts
280254110101	ASSY BATT CABLE CU (-VE) 700 MM	TATA spare parts
280254110102	ASSY BATT CABLE LUG(-VE)50SQMM-2300LG	TATA spare parts
280254200101	MOUNTING BRACKET BATT CUT OFF SWITCH	TATA spare parts
280254209901	INSTRUMENT CLUSTER E-SPEEDO(1.55)	TATA spare parts
280254209902	ELECTRONIC SPEEDOMETER (1.55)	TATA spare parts
280254209903	CRYSTAL RPM WITH DIGITAL HOURMETER-24V	TATA spare parts
280254209905	WIRING HARNESS INSTR CLSTR	TATA spare parts
280254209907	INST CLST E-SPD(1.55) 24V 552HZ ARMY	TATA spare parts
280254209909	INST CLST ESPD 1.32 24V 636HZ ARMY	TATA spare parts
280254209913	E SPEDOMETER(1.48) 24V WITH MULTIPLE FAN	TATA spare parts
280254209914	INSTRUMENT CLUSTER E-SPDOMTR(1.48)24V 9V	TATA spare parts
280254400101	ENGINE LAMP MTG BRACKET	TATA spare parts
280254408201	CONVOY LAMP MTG BRACKET	TATA spare parts
280254408206	ASSY. TAIL LAMP BRACKET-RH	TATA spare parts
280254408207	ASSY. TAIL LAMP BRACKET-LH	TATA spare parts
280254601604	WIRING HARNESS MAIN	TATA spare parts
280254601605	WIRING HARNESS TAIL	TATA spare parts
280254601606	WIRING HARNESS ENGINE	TATA spare parts
280254601607	WIRING HARNESS ROOF	TATA spare parts
280254601608	WIRING HARNESS ENGINE PIGTAIL	TATA spare parts
280254660109	WIRING HARNESS PIGTAIL HEIGHT INDICATOR	TATA spare parts
280254660113	W/H MAIN LPTA1623TC BS-II	TATA spare parts
280254660114	WIRING HARNESS TAIL	TATA spare parts
280254660115	W/H ENGINE LPTA1623TC BSIII ISBE	TATA spare parts
280258109901	PIPE FOR TOMMY BAR	TATA spare parts

280324200103	ASSY. RUBBER PAD	TATA spare parts
280341115101	FLANGE YOKE FRT REAR	TATA spare parts
280341115103	SHORT FORK FRT REAR	TATA spare parts
280341120102	CROSS ASSEMBLY FRT REAR	TATA spare parts
280341125101	LONG FORK	TATA spare parts
280341125102	REAR HOUSING	TATA spare parts
280342300105	DRUM BRAKE ASSY REAR -RH DIA 410X180	TATA spare parts
280342300109	DRUM BRAKE ASSY REAR -LH DIA 410X180	TATA spare parts
280343400103	VR-119 RETARDER BS3/4	TATA spare parts
280343400104	KIT-RETARDER	TATA spare parts
280343406501	OUTPUT SHAFT SPECIAL NUT(RETARDER)	TATA spare parts
280343407102	RETARDER OUTLET FLANGE	TATA spare parts
280343700105	COMPRESSOR AIR	TATA spare parts
280343700106	HEAD ASM. KIT SINGLE 75MM US PORTS	TATA spare parts
280343700107	REAR SEAL / ADAPTER KIT MAJOR	TATA spare parts
280343700108	HEAD GASKET KIT SINGLE 75MM MAJOR	TATA spare parts
280343700109	SUMP PLUG KIT	TATA spare parts
280343700110	SPLINE ADAPTER 11TH	TATA spare parts
280343700111	CONN ROD ASM. KIT SINGLE 75MM MAJOR	TATA spare parts
280343700112	PISTON ASM. KIT SINGLE 75MM MAJOR	TATA spare parts
280343700113	COMPRESSOR AIR	TATA spare parts
280343700114	HEAD ASM.DIA 85MM SINGLE CYLINDER	TATA spare parts
280343700115	GASKET & SEAL SET KIT 85 MM SINGLE CYLR	TATA spare parts
280343700116	PISTON ASSY. KIT	TATA spare parts
280343700117	CON ROD ASSY.KIT	TATA spare parts
280343700118	RING KIT MINOR	TATA spare parts
280343704901	ECU R123	TATA spare parts
280343706101	SEAL RING	TATA spare parts
280343706103	SEAL RING	TATA spare parts
280343706104	SEAL RING	TATA spare parts
280343707201	SCREW PLUG	TATA spare parts
280343707202	SCREW PLUG	TATA spare parts
280343707203	SCREW PLUG	TATA spare parts
280343707701	SEAL	TATA spare parts
280343707801	O-RING KIT	TATA spare parts
280343708501	WATER SOCKET (OUTLET)	TATA spare parts
280343709001	PROPORTIONAL VALVE R123	TATA spare parts
280343709901	REP. KIT DAMPING PLATE	TATA spare parts
280343709902	OIL COOLER R123	TATA spare parts
280347509201	WASHER ( CNG.MTG.BKT)	TATA spare parts
280347610115	ASSY LOW PRESSURE HOSE BS6	TATA spare parts
280347709901	HIGH PRESSURE GAUGE	TATA spare parts
280347709902	LOW PRESSURE GAUGE	TATA spare parts
280349208201	CLAMP	TATA spare parts
280349208203	CLAMP	TATA spare parts
280349208204	CLAMP	TATA spare parts
280349208210	CLAMP -2ND PIPE	TATA spare parts



280354100105	ASSY.BATT.CABLE +VE 1.8LG 70SQ.MM W/COT	TATA spare parts
280354100106	ASSY.BATTERY CABLE +VE(70 SQ.MM)850 LG	TATA spare parts
280354110101	ASSY.BATTERY CABLE -VE(70 SQ.MM)2200 LG	TATA spare parts
280354110102	ASSY.BATT.CABLE -VE 3.7LG W/COT-70SQ.MM	TATA spare parts
280354200106	GAS PR.INDICATOR (24V)	TATA spare parts
280354200109	KIT CNG PR.TRANSDUCER ASSY(GREEN FUEL)	TATA spare parts
280354200113	ASSY.KIT GAS LEAK INDICATOR	TATA spare parts
280354207703	INSULATOR BASE-RETARDER ECU	TATA spare parts
280354209901	CNG GAS LEAKAGE INDICATOR	TATA spare parts
280354500101	ELECT.OPERATEDBATT.CUT	TATA spare parts
280354501602	PIANO SW (BATTERY CUT-OFF)	TATA spare parts
280531200104	ASSY. BRACKET-AUX. TANK MTG.	TATA spare parts
280531200105	ASSY. TUBULAR CROSS MEMBER	TATA spare parts
280531207105	REINFORCEMENT RH-TOP	TATA spare parts
280531207106	REINFORCEMENT LH-TOP	TATA spare parts
280531207113	CROSS MEMBER FRONT	TATA spare parts
280531207114	CROSS MEMBER REAR	TATA spare parts
280531208201	SPACER	TATA spare parts
280531208601	SPACER	TATA spare parts
280531307101	GUSSET RH	TATA spare parts
280531307102	GUSSET LH	TATA spare parts
280532100112	ASSY.SHOCK ABSORBER-REAR	TATA spare parts
280532100114	LEVELLING VALVE	TATA spare parts
280532100117	LINK ASSEMBLY	TATA spare parts
280532107116	PLATE LEVEL VALVE CONNECTING	TATA spare parts
280532400101	BRACKET SHOCK ABSORBER MTG LH	TATA spare parts
280532400102	BRACKET SHOCK ABSORBER MTG RH	TATA spare parts
280532400103	ASSY BKT AIR SPRING RH	TATA spare parts
280532400104	AXLE BKT ASSY RH	TATA spare parts
280532400105	AXLE BKT ASSY LH	TATA spare parts
280532400106	ASSY BKT CONTROL ARM	TATA spare parts
280532400108	TRACK BAR FIX	TATA spare parts
280532400109	TORQUE ROD ADJ	TATA spare parts
280532400117	ASSY.AIR SPRING-REAR	TATA spare parts
280532400118	LOCKING SPACER ASSY	TATA spare parts
280532400119	ASSY. SENSING TANK	TATA spare parts
280532400120	ASSY BKT AIR SPRING LH	TATA spare parts
280532400124	BRAM - TRANSVERSE SUB - ASSY	TATA spare parts
280532400125	BUSHING T BEAM	TATA spare parts
280532400126	BEAM EQUALIZING SUB ASSY RH	TATA spare parts
280532400127	BEAM EQUALIZING SUB ASSY LH	TATA spare parts
280532400130	ASSY. PIPE (FROM TEE CONNECTOR TO SENSIN	TATA spare parts
280532400131	ASSY. PIPE (TEE CONNECTOR TO LEVEL CONTR	TATA spare parts
280532400132	ASSY KIT AIR SUSPENSION LP1512	TATA spare parts
280532400133	ASSY KIT AIR SUSPENSION LP1512	TATA spare parts
280532400134	ASSY. PIPE-FROM T CONNECTOR	TATA spare parts
280532400135	ASSY. PIPE-FROM C.B. L 6 TO LEVELLING	TATA spare parts

280532403301	BRACKET COMPL FRAME LH	TATA spare parts
280532403302	BRACKET COMPL FRAME RH	TATA spare parts
280532403303	BRACE REAR-RH	TATA spare parts
280532403304	BRACE REAR-LH	TATA spare parts
280532403305	TRACK BAR FRAME BRACKET	TATA spare parts
280532403402	ADAPTOR BUSHING	TATA spare parts
280532403403	BUSHING PIVOT RR	TATA spare parts
280532403404	BUSHING AXLE	TATA spare parts
280532406501	NUT HEAVY-2.25 - 8	TATA spare parts
280532406503	HEX NUT M26 X 1.5	TATA spare parts
280532406801	COUPLING BODY	TATA spare parts
280532407123	PLATE RR AXLE ASSY BKT	TATA spare parts
280532408601	SPACER	TATA spare parts
280532408602	SPACER	TATA spare parts
280532409202	WASHER SPACER 2.56	TATA spare parts
280532409203	WASHER SPACER 1.125	TATA spare parts
280532409204	WASHER SPACER 2.52	TATA spare parts
280532409205	TAB LOCK WASHER	TATA spare parts
280532409206	WASHER	TATA spare parts
280542100112	DRUM BRAKE ASSY LH	TATA spare parts
280542100113	DRUM BRAKE ASSY RH	TATA spare parts
280542100117	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
280542100118	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
280542103702	BRAKE DRUM BS6	TATA spare parts
280542300120	AUTO SLACK ADJUSTER ASSY REAR-RH	TATA spare parts
280542300121	AUTO SLACK ADJUSTER ASSY REAR-LH	TATA spare parts
280542300125	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
280542300126	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
280542303702	BRAKE DRUM	TATA spare parts
280542303704	BRAKE DRUM BS6	TATA spare parts
280542303708	PLUMMER BLOCK BS6	TATA spare parts
280542303709	BRACKET BRAKE CHAMBER MTG REAR-LH	TATA spare parts
280542303710	BRACKET BRAKE CHAMBER MTG REAR-LH	TATA spare parts
280542990107	BRAKE ASSY -BRAKE SPRING KIT	TATA spare parts
280542990135	LINED SHOE ASSY	TATA spare parts
280542990136	LINED SHOE ASSY	TATA spare parts
280626800101	ASSY GEAR SHIFT LEVER WITH YOKE	TATA spare parts
280626800108	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
280630100101	ASSY PULL ROD - ACC.	TATA spare parts
280630100103	ASSY PULL ROD - ACC	TATA spare parts
280630100106	ASSY. ACC. LEVER-RFOB	TATA spare parts
280630100107	ASSY. CONTROL SHAFT-RFOB	TATA spare parts
280630100108	ASSY.ACCELERATOR PEDAL COMPLETE W/O COVER	TATA spare parts
280630100109	ASSY.ACCELE. PEDAL COMPLETE WITH COVER	TATA spare parts
280630100111	ASSY.BRACKET ACTUATOR UNIT MOUNTING	TATA spare parts
280630108203	SPACER PLATE	TATA spare parts
280631000108	ASSY FRAME COMPLETE LP1510/52 60% ROH	TATA spare parts

280631000109	ASSY. FRAME LP1510/52 WB	TATA spare parts
280631000110	ASSY FRAME COMPLETE LP1510/59 55% ROH	TATA spare parts
280631000112	ASSY FRAME FOR LP 1510/48 697TCIC BS II	TATA spare parts
280631200101	ASSY SUPPORT-ENG. C.M. FRONT	TATA spare parts
280631200102	ASSY. ENG CROSS MEMBER FRONT	TATA spare parts
280631200109	ASSY STOPPER BRACKET	TATA spare parts
280632800101	ASSY CONNECTING LINK	TATA spare parts
280633000101	ASSY.FRONT AXLE WITH BRAKES COMP	TATA spare parts
280641100109	ASSY. PROP. SHAFT WITH CEN. BRG.(L=486)	TATA spare parts
280641100112	ASSY. PROP. SHAFT WITH CEN. BRG.(L=1560)	TATA spare parts
280641100120	ASY.PROP.SHAFT WITH GREASABLE CB(L=1904)	TATA spare parts
280641120101	ASSY. PROP.SHAFT REAR COMP.(CLOSED=1741)	TATA spare parts
280641120106	ASSY. PROP. SHAFT REAR	TATA spare parts
280641303301	CENTER BEARING BRACKET	TATA spare parts
280642100101	TYPE 24 BRAKE CHAMBER	TATA spare parts
280642100101AE	BRAKE CHAMBER-TYPE 24LPA 1415/	TATA spare parts
280643200103	SUB.ASSY.AIR TANKS WITH 240 S.C.D.-VOSS	TATA spare parts
280643700110	RELY VALE VOSS(EL1-ADP&DEL2-PLG)	TATA spare parts
280643710101	MINOR SPARE KIT	TATA spare parts
280643710102	MAJOR SPARE KIT	TATA spare parts
280643710103	SPARE SPARE KIT	TATA spare parts
280643710106	MINOR SPARE KIT	TATA spare parts
280643710107	MAJOR SPARE KIT	TATA spare parts
280643900111	ASSY.PIPE(SECOND METAL PIPE ON COMPRESOR	TATA spare parts
280643900170	ASSY.NYLON PIPE SET COMPL-1510/59	TATA spare parts
280643900178	ASY.NYL.PIPE W/PLASTIC VOS LP1613/42	TATA spare parts
280643900184	ASSY.METAL PIPE 15 O.D THIRD	TATA spare parts
280646800102	ASSY PIPES CLAMPS & BKTS	TATA spare parts
280647600115	ASSY.NYLON FUEL SUCTION LINE	TATA spare parts
280647600119	ASSY.SUCTION LINE (10 O.D.)	TATA spare parts
280647600120	ASSY.SUCTION LINE (10 O.D.)	TATA spare parts
280647600121	ASSY.SUCTION LINE (10 O.D.)	TATA spare parts
280647600122	ASSY.SUCTION LINE (10 O.D.)	TATA spare parts
280647600123	ASSY.RETURN LINE (10 O.D.)	TATA spare parts
280647600126	ASSY. SUCTION LINE (WATER SEPARATOR TO E	TATA spare parts
280647600127	ASSY. RETURN LINE WITH CRIMPED HOSE	TATA spare parts
280647600138	ASSY. NYLON FUEL RETURN LINE	TATA spare parts
280647600139	ASSY. NYLON FUEL LINE TANK TO BABY FILTE	TATA spare parts
280647990101	ASSY RETRO KIT FOR LP 1510/697 TCIC BSII	TATA spare parts
280647990103	ASSY KIT FOR LP 1510/697 BSII	TATA spare parts
280649000101	ASSY BRACKET FOR TAIL PIPE	TATA spare parts
280649100101	ASSY EXHAUST FIRST PIPE	TATA spare parts
280649100102	ASSY EXHAUST SECOND PIPE 76.2 ODX1.6THK	TATA spare parts
280649100108	ASSY. SILENCER WITH TAIL PIPE.	TATA spare parts
280649100113	ASSY BRACKET FOR EXHAUST	TATA spare parts
280649100114	ASSY.BRACKET EXHAUST MTG	TATA spare parts
280649108201	BRACKET	TATA spare parts

280649200108	ASSY. SECOND PIPE FOR LP1510/52 E-II	TATA spare parts
280649200109	ASSY FIRST PIPE	TATA spare parts
280649200111	ASSY FIRST PIPE	TATA spare parts
280649200116	ASSY.SUPPORT (AT SILENCER)	TATA spare parts
280649200117	ASSY. SILENCER WITH TAIL PIPE	TATA spare parts
280649207101	SPACER	TATA spare parts
280649208201	SUPPORT BRACKET	TATA spare parts
280649208205	CLAMP (EXHAUST MTG.)	TATA spare parts
280649208208	CLAMP (EXHAUST MTG.)	TATA spare parts
280649208209	CLAMP (EXHAUST MTG.)	TATA spare parts
280649208210	CLAMP (EXHAUST MTG.)	TATA spare parts
280649208213	CLAMP (EXHAUST MTG.)	TATA spare parts
280649208214	CLAMP (EXHAUST MTG.)	TATA spare parts
280649208215	CLAMP (EXHAUST MTG.)	TATA spare parts
280649208216	CLAMP (EXHAUST MTG.)	TATA spare parts
280654100101	ASSY. BATTERY CABLE (+VE) 2000LG	TATA spare parts
280654100102	ASSY BATTERY CABLE (+VE) 70SQ MM 3700MM	TATA spare parts
280654108201	MOUNTING BKT-AMMETER MAXI FUSE	TATA spare parts
280654110101	ASSY. BATTERY CABLE (-VE) 1500LG	TATA spare parts
280654110102	ASSY.BATT.CABLE -VE 1.8LG W/COT-70SQ.MM	TATA spare parts
280654200101	ASSY.BRACKET(AMMETER MTG.BKT.)	TATA spare parts
280654200104	SPEED SENSOR	TATA spare parts
280654200105	MOTOR UNIT	TATA spare parts
280654200111	ELECT.KIT RSL 24V LP1512TC BSII	TATA spare parts
280654200113	ASSY BRACKET(ABS-ECU MTG.)	TATA spare parts
280654200117	CONTROL CABLE ASSY.	TATA spare parts
280654201605	INST.CLUSTER(1:0.88)W/OIL P.G	TATA spare parts
280654206301	COVER (FOR ABS ECU)	TATA spare parts
280654208201	BRACKET (AMMETER MTG)	TATA spare parts
280654209910	INST.CLUSTER(ELECT)(1:0.88)	TATA spare parts
280654209911	INST.CLUSTER(ELECT)(1:0.80)	TATA spare parts
280654240102	RESISTOR 5 OHMS 250W W/HEAT SINK	TATA spare parts
280654240103	ASSY. MOUNTING BRACKET (RESISTOR)	TATA spare parts
280654240104	RESISTOR 5 OHM W/HEAT SINK	TATA spare parts
280654240105	ASSY RESISTOR WITH BRACKET	TATA spare parts
280654500101	ASSY PLATE (BATTERY CUT OFF SWITCH)	TATA spare parts
280654500102	ASSY.BRACKET (BATT.CUT-OFF SWITCH)	TATA spare parts
280654600109	ASSY W/H (MOTOR)	TATA spare parts
280654600112	ASSY W/H (SENSOR	TATA spare parts
280654600115	ASSY W/H (SUPPLY)	TATA spare parts
280654604302	CLIP CABLE	TATA spare parts
280654604303	ADHESIVE CLIP-M/S PENWEL BS6	TATA spare parts
280654620104	W/H MAIN (LP1510 EURO-II 697)	TATA spare parts
280654620105	WIRING HARNESS TAIL	TATA spare parts
280654620106	W/H TAIL(LP1510/59 BS-II)	TATA spare parts
280654660105	WIRING HARNESS MAIN(ABS)	TATA spare parts
280654700101	MOTOR UNIT SPEED LIMITER BS3/4	TATA spare parts

280658900101	ASSY.SCREW JACK(8T)WITH HANDLE	TATA spare parts
280730100105	ASSY. PULL CABLE ACCELERATOR	TATA spare parts
280730100108	ASSY. PULL CABLE ACCELERATOR	TATA spare parts
280731200101	ASSY. SUPPORT-ENG. C/M FRONT	TATA spare parts
280731700101	STICKER SUPER TURBO	TATA spare parts
280740150111	ASSY. RADIAL TUBE 10.00R20	TATA spare parts
280740200101	ASSY.RAD TYER TUBE FLAP 10.00R20	TATA spare parts
280743900105	ASSY.NY.PIPE SET CHASSIS COMPL-2516/COWL	TATA spare parts
280743900115	ASSY.NY.PIPE SET COMPL	TATA spare parts
280743900123	ASSY.NY.PIPE SET COMPL	TATA spare parts
280743900132	ASSY CHASSIS SET COMP(PL CON)2516 697 CO	TATA spare parts
280743900133	ASSY.NYLON GAUGE PIPE SET FOR COWL	TATA spare parts
280743900136	ASSY.NY.PIPE SET COMPL	TATA spare parts
280743900140	ASSY CHASSIS SET COMP(PL CON)2515-TC	TATA spare parts
280743900147	ASSY 3RD METAL PIPE INTERMIDATE JOINT-2	TATA spare parts
280746803301	BRACKET (FOR STEERING PIPING) BS6	TATA spare parts
280746803302	BRACKET (PRESSURE LINE) BS6	TATA spare parts
280746803303	BRACKET BS6	TATA spare parts
280749200101	ASSY. HEAT SHIELD	TATA spare parts
280824200102	ASSY. BRACKET - RH-ENG. MTG. REAR	TATA spare parts
280824200103	ASSY. BRACKET - LH-ENG. MTG. REAR	TATA spare parts
280826800106	ASSY G S LEVER WITH YOKE	TATA spare parts
280826800107	ASSY TURNING TUBE	TATA spare parts
280826800109	ASSY. GEAR SHIFTER LEVER W/SEL BS1/2/3/4	TATA spare parts
280826800111	ASSY BRACKET	TATA spare parts
280826800113	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
280826800114	ASSY SUPPORT TUBE	TATA spare parts
280826800115	ASSY LINK ROD (LPT2515 697 TELCO ENGINE)	TATA spare parts
280826800116	ASSY BRACKET	TATA spare parts
280826800119	GEAR SHIFT LEVER ASSY WITH SHIFT YOKE	TATA spare parts
280826800120	TURNING TUBE ASSY	TATA spare parts
280826800123	GEAR SHIFT LINKAGE ASSY	TATA spare parts
280826809901	GEAR SHIFT LEVER	TATA spare parts
280826810101	BRACKET GEAR SHIFT LEVER MTG	TATA spare parts
280829100102	ASSY. CLUTCH PIPE (6 OD)	TATA spare parts
280829100104	ASSY.CONTROL MTG. BRACKET WITH TUBE	TATA spare parts
280829100105	ASSY.CONTROL MTG.BKT WITH CYL.MTG.BKT	TATA spare parts
280829100109	ASSY CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
280829100112	ASSY. CLUTCH MASTER CYLINDER BS1/2/3/4	TATA spare parts
280829100113	ASSY.CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
280829150103	ASSY.PIPE (6 O.D.)	TATA spare parts
280829350101	ASSLY BKT. CLUTCH BOOSTER MTG.	TATA spare parts
280829350102	ASSY.BRACKET (SUPPORT CLUTCH BOOSTER)	TATA spare parts
280830100104	ASSY.ACCELERATOR PULL ROD COMP. L=803	TATA spare parts
280830100106	ASSY. ACCELERATOR LEVER (RFOB)	TATA spare parts
280830100108	ASSY. PULL ROD (L=775)	TATA spare parts
280830100110	ASSY PULL ROD	TATA spare parts

280830100111	ACCELERATOR BRACKET ASSY	TATA spare parts
280830100113	ASSY. ACCELERATOR LEVER	TATA spare parts
280830100117	ASSY.PULL ROD	TATA spare parts
280831000102	ASSY. FRAME COMPLETE LPT2515EX_697TC	TATA spare parts
280831000103	ASSY.FRAME LPT 2515 W 697 BS-II WITH FUP	TATA spare parts
280831000107	ASSY. FRAME COMPLETE	TATA spare parts
280831200105	ASSY BUMPER CROSS MEMBER	TATA spare parts
280831207104	GUSSET - BUMPER CROSS MEMBER	TATA spare parts
280831700103	ASSY SUPPORT BKT ENGINE SIDE	TATA spare parts
280831700104	ASSY SUPPORT BKT(TRANS. SIDE)-RH	TATA spare parts
280831700105	ASSY SUPPORT BKT.(TRANS. SIDE)-LH	TATA spare parts
280831700107	ASSY SUPPORT BRACKET(TRANS RR SIDE)	TATA spare parts
280841100103	ASSY PROPSHAFT FRONT	TATA spare parts
280841100104	ASSY.PROP.SHAFT WITH CENTRE BRG. L=1418	TATA spare parts
280841100113	ASSY. PROP. SHAFT FRONT	TATA spare parts
280841100115	ASSY.PROP.SHAFT WITH C.B.(L=1418)	TATA spare parts
280841120101	ASSY.PROP.SHAFT REAR	TATA spare parts
280842100152	ASSY FRONT BRAKE LH WITH DUST COVER	TATA spare parts
280842100155	ASSY FRONT BRAKE RH WITH DUST COVER	TATA spare parts
280842103401	SENSOR SLEEVE - FRONT	TATA spare parts
280842300105	BRAKE ACTUATOR 24/75 WT MET+VOSS RH	TATA spare parts
280842300106	BRAKE ACTUATOR 24/75 WT MET+VOSS LH	TATA spare parts
280842300127	BRAKE ACTUATOR 24/75 WT MET+VOSS RH	TATA spare parts
280842300128	BRAKE ACTUATOR 24/75 WT MET+VOSS LH	TATA spare parts
280842300206	ASSY REAR BRAKE AAL RH WT D/C AF235	TATA spare parts
280842300210	ASSY REAR BRAKE AAL LH WT D/C AF235	TATA spare parts
280842300235	ASSY REAR BRAKE RH WITH DUST COVER	TATA spare parts
280842300239	ASSY REAR BRAKE LH WITH DUST COVER	TATA spare parts
280842303301	SENSOR AXLE BRACKET	TATA spare parts
280842303302	SENSOR MTG. BRACKET REAR	TATA spare parts
280842303303	SENSOR MOUNTING BRACKET REAR - FRICTION	TATA spare parts
280842303306	ABS SENSOR MOUNTING BRACKET REAR	TATA spare parts
280842303310	ABS SENSOR MOUNTING BRACKET REAR	TATA spare parts
280842307501	RUBBER GROMMET FOR (DIA 18 ABS HOLE)	TATA spare parts
280842307502	RUBBER GROMMET (FOR DIA 8 ABS HOLE)	TATA spare parts
280842309901	GREASE PACK	TATA spare parts
280842309902	GREASE PACK	TATA spare parts
280843200101	SUB ASSY.AIR TANKS 280 STRAP C.D.VOSS	TATA spare parts
280843200102	ASSY. AIR TANK WITH SEALING PLUG (V+M)	TATA spare parts
280843700101	AIR DRYER HI PR WT CONTROL PORT VOSS	TATA spare parts
280843700113	RELY VLV VOS(DEL-1VOSS&DEL2-ADP)	TATA spare parts
280843700133	MODULATOR VALVE FRONT 12 V	TATA spare parts
280843700134	MODULATOR VALVE(VOSS)12V	TATA spare parts
280843700136	ASSY MTG BKT-MODULATOR VALVE REAR	TATA spare parts
280843700139	MODULATOR VALVE(VOS+MET)12V	TATA spare parts
280843700140	MODULATOR VALVE(VOSS+MET)12V	TATA spare parts
280843700143	MODULATOR VALVE ABS	TATA spare parts

280843700156	DRAIN VALVE WITH FILTER	TATA spare parts
280843700158	ASSY. RELAY VALVE & BRKT(DEL-1&2-ADP)-KB	TATA spare parts
280843700159	ASY.RELAY VALVE&BRKT(DEL-1PLUG&2-VOSS)	TATA spare parts
280843900105	ASSY NYLON PIPE SET CHASSIS COMPL	TATA spare parts
280843900147	ASSY.NY.PIPE SET COMPL-2515/VOSS/	TATA spare parts
280843900148	ASSY.PIPE-SECOND METAL PIPE FROM COMPR.	TATA spare parts
280843900156	ASSY. HOSE-COMPRESSOR OUTLET	TATA spare parts
280843900171	ASSY.NYLON PIPE SET COMPLETE LPT2515TCIC	TATA spare parts
280843900172	ASSY.NYLON PIPE SET COMPLETE LPT2515TCIC	TATA spare parts
280843900190	ASSY.NY.PIPE SET COMPL/2515/KB/VOSS	TATA spare parts
280843900194	ASSY.HOSE (COMPR.OUTLET PIPE)	TATA spare parts
280843901602	ASSY.NYLON PIPE SET COMPLETE LPT2515TCIC	TATA spare parts
280843906801	COUPLING BODY VOSS (FROM SPV TO AIR TANK	TATA spare parts
280843906802	ELBOW- (FOR 6 DIA. NYLON PIPE)	TATA spare parts
280843906803	ELB PLUG NG12 NW9	TATA spare parts
280843910119	ASY CHASSIS SET COMP(PL CON)2515-697COWL	TATA spare parts
280843910126	ASY CHASSIS SET COMP(PL CON)2515-697COWL	TATA spare parts
280843910131	ASSY.TUBE WITH CRIMPED TEFLON HOSE.-1ST	TATA spare parts
280843910132	ASSY.TUBE COMP.2ND PIPE	TATA spare parts
280843910135	ASSY.COMP.PIPE 2ND	TATA spare parts
280843910136	ASSY.COMP.PIPE 3RD	TATA spare parts
280846100103	ASSY STEERING COLUMN WITHOUT STG.WHEEL	TATA spare parts
280846100104	ASSY.STEERING COLUMN SUPPORT	TATA spare parts
280846108201	SPACER PLATE(FOR STEERING GB MTG.)	TATA spare parts
280846200101	ASSY STEERING SPINDLE	TATA spare parts
280846400101	ASSY. STEERING WHEEL COMP 470DIA. BS1- 4	TATA spare parts
280846400101AE	ASSY STG.WHEEL 470DIALPA 1415/	TATA spare parts
280846400102	ASSY STG.WHEEL.WITHOUT TOP COVER BS6	TATA spare parts
280846400103	ASSY TOP COVER	TATA spare parts
280846800106	ASSY PIPES & CLAMPS	TATA spare parts
280846800107	ASSY HOSE PIPE SUCTION	TATA spare parts
280846800108	ASSY HOSE PRESSURE LINE	TATA spare parts
280847100111	WATER SEPERATOR	TATA spare parts
280847103302	BRACKET BABY FILTER MOUNTING	TATA spare parts
280847600101	ASSY.SUCTION LINE	TATA spare parts
280847600102	ASSY.SUCTION LINE	TATA spare parts
280847600104	ASSY.FUEL RETURN LINE	TATA spare parts
280847600105	ASSY SUCTION LINE BABY FILTER TO WATER S	TATA spare parts
280847600107	ASSY SUCTION PIPE-10 OD PIPE	TATA spare parts
280847600108	ASSY SUCTION PIPE-10 OD PIPE	TATA spare parts
280847600109	ASSY SUCTION PIPE-10 OD PIPE	TATA spare parts
280847600110	ASSY RETURN PIPE-10 OD PIPE	TATA spare parts
280847600111	ASSY SUCTION LINE FROM FUEL TANK TO BABY	TATA spare parts
280847600114	ASSLY SUCTION LINE(10 O.D. PIPE)	TATA spare parts
280847600118	ASSY.MOULDED SUCTION HOSE	TATA spare parts
280847600120	ASSY.SUCTION LINE WITH CRIMPED HOSE	TATA spare parts
280847600121	ASSY.SUCTION PIPE	TATA spare parts

280847990101	ASSY. RETROFIT KIT WITH ELE.FEED PUMP	TATA spare parts
280847990103	ASSY.RETROFITMENT KIT - MECH.FEED PUMP	TATA spare parts
280849100102	ASSY.EXHAUST SECOND PIPE 81.2 ODX1.6THK	TATA spare parts
280849100103	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
280849100106	ASSY MUFFLER WITH TAIL PIPE	TATA spare parts
280849106903	TAIL PIPE	TATA spare parts
280849200102	ASSY.EXHAUST FIRST PIPE	TATA spare parts
280849200106	ASSY. EXHAUST FIRST PIPE	TATA spare parts
280849200110	ASSY.EXHAUST FIRST PIPE	TATA spare parts
280849200111	ASSY.EXHAUST PIPE	TATA spare parts
280849200112	ASSY.EXHAUST FIRST PIPE	TATA spare parts
280849200122	ASSY. SECOND PIPE	TATA spare parts
280849200123	ASSY. FIFTH PIPE	TATA spare parts
280849200125	ASSY THIRD PIPE	TATA spare parts
280849208209	CLAMP (SILENCER MTG)	TATA spare parts
280854200103	INDUCTIVE SENSOR WITH SOCKET(ABS)	TATA spare parts
280854200112	ASSY BRACKET(ABS-ECU MTG.)	TATA spare parts
280854200113	TANK UNIT WITH TFR FOR 350LTRS -IIL	TATA spare parts
280854209901	INSTRUMENT CLUSTER-1:0.88	TATA spare parts
280854209902	RPM METER ASSY 12V 420 HZ	TATA spare parts
280854209907	ELECTRONIC CONTROL UNIT 12V	TATA spare parts
280854209908	SENSOR WHEEL SPEED	TATA spare parts
280854209908AE	SENSOR WHEEL SPEED-1628-1828	TATA spare parts
280854209909	BEEPER ALARM UNIT(W/MOULDED BKT)	TATA spare parts
280854209919	INST.CLUSTER(ELECT)(1:1.04)	TATA spare parts
280854209920	INSTRUMENT CLUSTER(ELECT) (1:1.04)	TATA spare parts
280854400103	ASSY REAR FOG LAMP(12V MTG.DOWN-A)	TATA spare parts
280854400104	ASSY REAR FOG LAMP(12V MTG.UP-B)	TATA spare parts
280854600105	W/H MAIN-LPT2515_CLSTR	TATA spare parts
280854600106	W/H MAIN LPT 2515-697	TATA spare parts
280854600107	W/H TAIL	TATA spare parts
280854600108	W/H TAIL (LPT2515-697 BS-II EXH.	TATA spare parts
280854600109	W/H TAIL(LPT2515-697 BS-II EXH TILT)	TATA spare parts
280854600110	W/H ADDON FOR FEEDPUMP	TATA spare parts
280854600112	W/H MAIN(LPT1613/2515 697 BS-II LP)	TATA spare parts
280854600113	W/H PIG TAIL(FEED PUMP)	TATA spare parts
280854600115	W/H FRAME LPT2515/48 ABS 12V II(RHD)	TATA spare parts
280854600116	WIRING HARNESS PIG TAIL ABS	TATA spare parts
280854600117	W/H FRAME 12V/24V ABS(RHD)	TATA spare parts
280854600118	W/H PIGTAIL ABS -ECU	TATA spare parts
280854620103	W/H MAIN-LPT2515_CLSTR	TATA spare parts
280854620104	W/H MAIN LPT 2515-697	TATA spare parts
280854620105	W/H TAIL	TATA spare parts
280854620106	W/H TAIL(LPT2515/48 697 BS-II LP)	TATA spare parts
280854620107	W/H TAIL(LPT2515-697 BS-II EXH TILT)	TATA spare parts
280854620108	W/H MAIN(LPT1613/2515 697 BS-II LP)	TATA spare parts
280854620109	W/H MAIN(LPT1613/2515 BS-II 697 TLT)	TATA spare parts



280854620110	W/H PIG TAIL(FEED PUMP)	TATA spare parts
280854660101	W/H MAIN-LPT2515_CLSTR	TATA spare parts
280854660102	W/H MAIN LPT 2515-697	TATA spare parts
280854660103	W/H TAIL	TATA spare parts
280854660104	W/H TAIL (LPT2515-697 BS-II EXH.) COWL	TATA spare parts
280854660105	W/H MAIN(LPT1613/2515 697 BS-II LP)	TATA spare parts
280854660106	W/H PIG TAIL(FEED PUMP)	TATA spare parts
280854680102	W/H MAIN(LPT1613/2515 697 BS-II LP)	TATA spare parts
280854680103	W/H TAIL(LPT2515/48 697 BS-II LP)	TATA spare parts
280854680107	W/H PIG TAIL(FEED PUMP)	TATA spare parts
28086202951	BELT TENSION GAUGE VSM-1 CONTINENTAL CON	TATA spare parts
280882400104	ACCESSORISE KIT FOR WIPER MOTOR	TATA spare parts
280882400105	ACCESSORISE KIT FOR WIPER MOTOR	TATA spare parts
280882400106	ACCESSORISE KIT FOR WIPER MOTOR	TATA spare parts
280882400107	ASSY. KIT FOR 17 W WIPER MOTOR	TATA spare parts
280882400108	ACCESSORIES KIT FOR WIPER MOTOR PRABHA	TATA spare parts
280882400111	KIT-WIPER ACCESSORIES BS6	TATA spare parts
280916100101	CONTAINER(ECU-697 E-III)	TATA spare parts
280924200102	ASSY. BRACKET (ENG. MTG. RR -TOP) BS1- 4	TATA spare parts
280924200103	ASSY BRACKET-RH (ENGINE MTG-REAR BOTTOM)	TATA spare parts
280924200104	ASSY.BRACKET-LH	TATA spare parts
280924200105	ASSY BRACKET-RH(ENGINE MTG-REAR BOTTOM)	TATA spare parts
280924200106	ASSY.BRACKET-LH(ENGINE MTG-REAR BOTTOM)	TATA spare parts
280924200107	ASSY BOTTOM BKT-RH (ENGINE MTG.REAR)	TATA spare parts
280924200108	ASSY BOTTOM BKT-LH (ENGINE MTG.REAR)	TATA spare parts
280926800102	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
280926800104	ASSY TURNING TUBE W/O BALL JOINT	TATA spare parts
280926800106	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
280926800109	ASSY GEAR SHIFT LEVER W/SEL.SHIFT YOKE &	TATA spare parts
280926800112	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
280926800114	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
280926800126	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
280926800129	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
280926800131	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
280926800133	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
280926800137	ASSY TURNING TUBE	TATA spare parts
280926810101	ASSY BRACKET(G.S.L.MTG)LPT1418 1DEG.INCI	TATA spare parts
280926810102	ASSY SUPPORT TUBE (LPT1418/LPT2518)	TATA spare parts
280926810103	ASSY BRACKET(G.S.L.MTG)LPT1618LHD.1DEG.	TATA spare parts
280926810104	ASSY BRACKET G.S. LEVER MTG	TATA spare parts
280926810105	ASSY SUPPORT TUBR (G/S BRACKET)	TATA spare parts
280926810106	ASSY BRACKET (G.S.LEVER MTG)LPK1618C LHD	TATA spare parts
280926810107	ASSY BRACKET(G.S.L.MTG)LPT1618 LHD 697T	TATA spare parts
280926810109	ASSY SUPPORT BRACKET	TATA spare parts
280926810112	ASSY G.S.L.MTG.BRACKET	TATA spare parts
280926810113	ASSY SUPPORT TUBE	TATA spare parts
280926810116	ASSY SUPPORT TUBE	TATA spare parts

280926810117	ASSY SUPPORT TUBE	TATA spare parts
280926810120	ASSY SUPPORT TUBE (LPT/LPK1618C LHD)	TATA spare parts
280929100103	ASSY.BRAKE PEDAL LEVER COMPLETE	TATA spare parts
280929100110	ASSY TUBE	TATA spare parts
280929100111	ASSY.PIPE	TATA spare parts
280929100111AE	ASSY.CL PIPE(MC. T RBER HSE-2523	TATA spare parts
280929100113	MAJOR REPAIR KIT CLU.BOOSTER 70DIA	TATA spare parts
280929100114	MINOR REPAIR KIT CLU.BOOSTER 70DIA	TATA spare parts
280929100115	ASSY CLUTCH PEDAL COMPLETE	TATA spare parts
280929100117	ASSY PIPE	TATA spare parts
280929100118	ASSY PIPE	TATA spare parts
280929100120	ASSY.CLUTCH PEDAL COMPLETE	TATA spare parts
280929100124	ASSY. PIPE	TATA spare parts
280929350101	ASSY BRACKET - MAIN (CLUTCH BOOSTER MTG)	TATA spare parts
280929350102	ASSY BRACKET (TAIL END -CB)	TATA spare parts
280929350103	ASSY BRACKET (CLUTCH BOOSTER MTG.)	TATA spare parts
280930100103	ASSY. PEDAL LEVER ACCELERATOR-LHD	TATA spare parts
280930100104	ASSY.PULL CABLE ACCLERATOR	TATA spare parts
280930100107	ASSY PEDAL WITH COVER	TATA spare parts
280930100109	ACCELERATOR LEVER ASSY	TATA spare parts
280930100110	ASSY. PULL CABLE (ACCELERATOR)	TATA spare parts
280930100111	ASSY. ACCELERATOR LEVER	TATA spare parts
280930100113	ASSY ACCELERATOR PULL CABLE	TATA spare parts
280930108201	SPACER PLATE	TATA spare parts
280931000101	ASSY. FRAME COMPLETE - LPT 1518TC/52	TATA spare parts
280931000102	ASSY. FRAME COMPLETE - LPT 1618TC/52-LHD	TATA spare parts
280931000105	ASSY. FRAME COMPLETE (LPK 1518TC/36)	TATA spare parts
280931000108	FRAME ASSY	TATA spare parts
280931200101	ASSY. BUMPER CROSS MEMBER	TATA spare parts
280931200102	ASSY. SUPPORT (ENG. C/M FRONT)	TATA spare parts
280931200103	ASSY. SUPPORT (ENG. C/M REAR)	TATA spare parts
280931200105	ASSY. ENG. C/M REAR	TATA spare parts
280931200106	ASSY. CROSS MEMBER - SHOCK ABS. REAR	TATA spare parts
280931200107	ASSY. BRACKET -RH (RADIATOR MOUNTING)	TATA spare parts
280931200108	ASSY. BRACKET -LH (RADIATOR MOUNTING)	TATA spare parts
280931200110	ASSY. CROSS MEMBER (5TH C/M) WITH SUPPOR	TATA spare parts
280931200111	ASSY. CROSS MEMBER (5TH C/M) WITH SUPPOR	TATA spare parts
280931200112	ASSY.CROSS MEMBER(REAR SPR.-FRONT BKT.)	TATA spare parts
28093120011235	CED-ASSY.CROSS MEMBER(RR SPR.FRT)BS6-PH2	TATA spare parts
280931200113	ASSY. END CROSS MEMBER	TATA spare parts
280931200114	ASSY. 4TH CROSS MEMBER WITH SUPPORT	TATA spare parts
280931200115	ASSY. END CROSS MEMBER (LPK 1518)	TATA spare parts
280931200116	ASSY. SUPPORT -RH (ENG C/M FRONT)	TATA spare parts
280931200117	ASSY. SUPPORT -LH (ENG C/MFRONT)	TATA spare parts
280931200118	ASSY.BRACKET -RH (RADIATOR MOUNTING)	TATA spare parts
280931200119	ASSY.BRACKET -LH (RADIATOR MOUNTING)	TATA spare parts
280931200122	ASSY. ENGINE CROSS MEMBER -REAR COMPLETE	TATA spare parts

280931200123	ASSY.BRACKET -RH (RADIATOR MOUNTING)	TATA spare parts
280931200124	ASSY.BRACKET -LH (RADIATOR MOUNTING)	TATA spare parts
280931200125	ASSY.SUPPORT (ENGINE CROSS MEMBER FRONT)	TATA spare parts
280931207105	INTERMEDIATE PLATE	TATA spare parts
280931207106	INTERMEDIATE PLATE	TATA spare parts
280931207116	COUPLING JAW	TATA spare parts
280931207123	INTERMEDIATE PLATE	TATA spare parts
280931208202	SHIM - 1.6 THK	TATA spare parts
280931307101	BOTTOM SUPPORT (SPR. C/M REAR-FRONT)	TATA spare parts
280931307102	BOTTOM SUPPORT - 6TH C/M	TATA spare parts
280931307103	SUPPORT BOTTOM - 4TH C/M	TATA spare parts
280931307104	ADDITIONAL SUPPORT - 4 TH C/M	TATA spare parts
280931307107	REINFORCEMENT BOTTOM -RH	TATA spare parts
280931307108	REINFORCEMENT BOTTOM -LH	TATA spare parts
280931307111	ADD. SUPPORT BOTTOM -SPR.C/M REAR FRONT	TATA spare parts
280931307112	REINFORCEMENTPLATE	TATA spare parts
280931307114	REINFORCEMENT TOP -RH	TATA spare parts
280931307115	REINFORCEMENT TOP -LH	TATA spare parts
280931700101	ASSY. BRACKET -LH (RUPD)	TATA spare parts
280931700102	ASSY. BRACKET -RH (RUPD)	TATA spare parts
280931700103	ASSY.REAR UNDERRUN PROTCTION DEVICE COM	TATA spare parts
280931700104	ASSY.REAR UNDERRUN PROTECTIVE DEVICE COM	TATA spare parts
280931700120	ASSY. REAR UNDERRUN PROTECTIVE DEVICE	TATA spare parts
280931700123	BEAM ASSY RUPD	TATA spare parts
280931706901	TUBE (19 I.D.X32 O.DX88 LENGTH)	TATA spare parts
280931709201	SPACER-TAIL LAMP MTG.(15-IDX45-ODX7-THK)	TATA spare parts
280932100102	ASSY. FRONT SPRING	TATA spare parts
280932107106	CASTER PLATE	TATA spare parts
280932300101	SHOCK ABSORBER (FRONT)	TATA spare parts
280932300105	SHOCK ABSORBER BKT ASSY TOP LH	TATA spare parts
280932308601	SPACER	TATA spare parts
280932600101	ASSY. REAR SHOCK ABSORBER	TATA spare parts
280932600102	ASSY. REAR SHOCK ABSORBER	TATA spare parts
280932600105	ASSY. BRACKET LH (REAR LOWER S/A MTG.)	TATA spare parts
280932600106	ASSY. BRACKET RH (REAR LOWER S/A MTG)	TATA spare parts
280932603301	BRACKET -SHOCK ABSORBER MTG LH	TATA spare parts
280932603302	BRACKET -SHOCK ABSORBER MTG RH	TATA spare parts
280932800101	ASSY. CONNECTING LINK	TATA spare parts
280932800101AE	ASSY. CONNECTING LINKLPA 1415/	TATA spare parts
280932800102	ANTI ROLL BAR	TATA spare parts
280932800104	ASSY. CONNECTING LINK	TATA spare parts
280933000101	ASSY FRONT AXLE COMPLETE WITH BRAKES	TATA spare parts
280933000102	ASSY FRONT AXLE COMPLETE WITH BRAKES	TATA spare parts
280933000107	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
280933800101	TIE ROD ASSY - SEALED TYPE	TATA spare parts
280933800103	TIE ROD END ASSEMBLY R.H	TATA spare parts
280933800104	TIE ROD END ASSEMBLY L.H	TATA spare parts

280933800105	ASSY TIEROD KIT	TATA spare parts
280940100101	ASSY. WHEEL RIM 8.25X22.5	TATA spare parts
280940100102	VALVE FOR TUBELESS TYRE	TATA spare parts
280940100103	ASSY. WHEEL RIM BS2/3/4	TATA spare parts
280940100104	ASSY WHEEL RIM & VALVE COMPLETE	TATA spare parts
280940100105	WHEEL RIM ASSY WITHOUT VALVE	TATA spare parts
280940100111	ASSY WHEEL RIM 8.25X22.5	TATA spare parts
280940106301	TUBELESS TYRE 11R22.5- 16PR RIB PATTERN	TATA spare parts
280940307101	REINFORCEMENT	TATA spare parts
280941100101	ASSY.PROP.SHAFT-FRONT	TATA spare parts
280941100102	ASSY.PROP.SHAFT-FRONT	TATA spare parts
280941100103	ASSY.PROP.SHAFT-MIDDLE	TATA spare parts
280941100106	ASSY.PROP.SHAFT FRONT	TATA spare parts
280941100109	COUPLING FLANGE ASSY	TATA spare parts
280941100110	UJ KIT	TATA spare parts
280941100111	KIT-CENTER BRG. (SEALED) SPICER BS1- 4	TATA spare parts
280941100113	ASSY.GUARD(PROPELLER SHAFT REAR)	TATA spare parts
280941100114	ASSY.PROP.SHAFT.FRONT	TATA spare parts
280941100119	SHORT FORK TUBE & FR END PIECE SUB ASSY	TATA spare parts
280941100120	CENTRE BEARING ASSY	TATA spare parts
280941100121	CENTER COUPLING FLANGE ASSY.	TATA spare parts
280941100122	ASSY. PROP SHAFT FRONT	TATA spare parts
280941100123	CENTER BEARING ASSY.	TATA spare parts
280941100124	COUPLING FLANGE	TATA spare parts
280941100125	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
280941103701	FLANGE YOKE	TATA spare parts
280941103702	FLANGE YOKE	TATA spare parts
280941103703	FULL RND FLANGE YOKE	TATA spare parts
280941105102	COMPANION FLANGE	TATA spare parts
280941105104	COMPANION FLANGE	TATA spare parts
280941106501	NUT	TATA spare parts
280941107501	CB RUBBER	TATA spare parts
280941109901	MSTS NUT (SEALED BRG. - P.SHAFT)	TATA spare parts
280941109902	ZERK	TATA spare parts
280941109904	HEX NUT	TATA spare parts
280941110101	ASSY.PROP.SHAFT-MIDDLE	TATA spare parts
280941110102	ASSY.PROP.SHAFT-FRONT	TATA spare parts
280941110103	ASSY. PROP SHAFT-FRONT	TATA spare parts
280941110104	ASSY. PROP. SHAFT-MIDDLE	TATA spare parts
280941110105	PROPELLER SHAFT ASSY FRONT	TATA spare parts
280941110106	PROPELLER SHAFT ASSY MIDDLE	TATA spare parts
280941116901	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
280941116902	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
280941120101	ASSY PROP SHAFT-REAR	TATA spare parts
280941120102	ASSY.PROP.SHAFT-REAR	TATA spare parts
280941120103	ASSY.PROP.SHAFT-REAR	TATA spare parts
280941120105	SLIP YOKE ASSY. (REAR P.SHAFT -)	TATA spare parts

280941120106	DUST CAP KIT (REAR P.SHAFT)	TATA spare parts
280941120107	ASSY PROP SHAFT REAR	TATA spare parts
280941120108	ASSY.PROP.SHAFT-REAR	TATA spare parts
280941120111	SLIP YOKE ASSY (REAR)	TATA spare parts
280941120112	DUST CAP KIT	TATA spare parts
280941120114	RR HOUSING TUBE & SHORT FORK SUB ASSY	TATA spare parts
280941120115	LONG FORK SUB ASSY.	TATA spare parts
280941120116	ASSY. PROP SHAFT REAR	TATA spare parts
280941120117	LONG FORK SUB ASSY	TATA spare parts
280941120118	REAR HOUSING	TATA spare parts
280941120119	ASSY. PROP. SHAFT-REAR	TATA spare parts
280941120120	PROPELLER SHAFT ASSY REAR	TATA spare parts
280941123701	SLIP YOKE ASSEMBLY	TATA spare parts
280941123702	SLIP YOKE (M/S SPICER)	TATA spare parts
280941126901	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
280941129901	GREASER (REAR P.SHAFT SPICER)	TATA spare parts
280941300101	CENTER BEARING ASSY.	TATA spare parts
280941303302	SPACER BRACKET	TATA spare parts
280941303303	SPACER BRACKET (FOR CENTER BEARING)	TATA spare parts
280941303304	SPACER BRACKET (FOR CENTER BEARING)	TATA spare parts
280941303306	SPACER BRACKET (FOR CENTER BEARING)	TATA spare parts
280941303307	SPACER BRACKET (FOR CENTER BEARING)	TATA spare parts
280941303309	CENTER BEARING ASSY BRK FRONT	TATA spare parts
280941303310	CENTER BEARING ASSY BRK MIDDLE	TATA spare parts
280941308201	GUARD (PROPELLER SHAFT REAR)	TATA spare parts
280941400101	ASSY. CROSS BS1/2/3/4	TATA spare parts
280941400101DF	UJ CROSS-DIA42 X 129-1613/1615/1618/2518	TATA spare parts
280941990104	FULL RND FLANGE YOKE	TATA spare parts
280941990105	ASSY. CENTER BEARING BS2/3/4	TATA spare parts
280941990106	RETAINER	TATA spare parts
280941990107	COMPANION FLANGE	TATA spare parts
280942100142	BRAKE ASSY -LH FRONT 410X200	TATA spare parts
280942100143	BRAKE ASSY -RH FRONT 410X200	TATA spare parts
280942300165	ASSY REAR BRAKE RH WITH DUST COVER	TATA spare parts
280942300169	ASY REAR BRAKE LH WITH DUST COVER	TATA spare parts
280942300202	ASSY BRAKE RH W/T D/C.AALAF235	TATA spare parts
280942300206	SLACK ADJ 60 OFFSET 140CD 40 CRANK RH	TATA spare parts
280942300208	SLACK ADJ 60 OFFSET 140CD 40 CRANK LH	TATA spare parts
280942300211	AUTO SLACK ADJUSTER LH 56 OFFSET 145 CD	TATA spare parts
280942300212	AUTO SLACK ADJUSTER RH 56 OFFSET 145 CD	TATA spare parts
280942308701	SPRING CAM END BS6	TATA spare parts
280942990109	KIT-CAMSHAFT LH BS6	TATA spare parts
280942990110	KIT-CAMSHAFT RH BS6	TATA spare parts
280942990111	CAMSHAFT LH	TATA spare parts
280942990112	CAMSHAFT RH	TATA spare parts
280942990113	KIT-BRAKE	TATA spare parts
280942990114	KIT-CAMSHAFT LH	TATA spare parts

280942990115	KIT-CAMSHAFT RH	TATA spare parts
280943200104	SUB ASSY.AIR TANKS 305STRAP C.D.FOR VOSS	TATA spare parts
280943200108	ASSY.BRACKET-AIR TANK MTG-ON FRAME	TATA spare parts
280943200109	ASSY.AIR TANK SUITABLE FOR VOSS FITTINGS	TATA spare parts
280943200110	SUB ASSY.AIR TANK W/VOSS FITTING(385CD.)	TATA spare parts
280943200111	AIR TANK ASSY WITH BKT	TATA spare parts
280943200114	SUB ASSY.AIR TANKS 305STRAP C.D.FOR VOSS	TATA spare parts
280943200119	ASSY. BULK ADAPTOR	TATA spare parts
280943200121	AIR TANK ASSY 30X2 LTRS	TATA spare parts
280943200123	AIR TANK ASSY 15 LTRS	TATA spare parts
280943700128	AUTOMATIC LOAD SENSING VALVE(VOSS)	TATA spare parts
280943700129	REPAIR KIT FOR AUTOMATIC LOAD SENSING VA	TATA spare parts
280943700129AE	REP KIT AUTO LD SENSNG VLVE -715	TATA spare parts
280943700130	TRAILER CONTROL VALVE BS1/2/3/4	TATA spare parts
280943700130AE	TRAILER CONTROL VALVE-VOSS 715	TATA spare parts
280943700131	REPAIR KIT FOR TRAILER CONTROL VALVE	TATA spare parts
280943700131AE	REP KIT TRLER CNTRL VALVE -715	TATA spare parts
280943700160	ASSY BKT-MODULATR VALVE MTG(REAR)LPT1618	TATA spare parts
280943700166	ASSY.BRAKE COIL SET	TATA spare parts
280943700187	4 CIR PROT VALV(WITH EG)9 BAR VOS	TATA spare parts
280943700189	BRACKET-RELAY VALVE MOUNTING	TATA spare parts
280943700191	MALE COUPLING TRACTOR SUPPLY LINE	TATA spare parts
280943700192	FEMALE COUPLING TRACTOR CONTROL LINE	TATA spare parts
280943703301	BRACKET-LCRV MOUNTING	TATA spare parts
280943703302	BRACKET-LH (PALM COUPLING MTG.)	TATA spare parts
280943703303	BRACKET RH (PALM COUPLING MTG.)	TATA spare parts
280943703311	BRACKET FOR NRV (C-CLAMP)	TATA spare parts
280943703312	BRACKET FOR NRV (L-TYPE)	TATA spare parts
280943707807	O-RING BS6	TATA spare parts
280943708601	SPACER 10MM THICK	TATA spare parts
280943710115	BRACKET ASSY PRV MTG	TATA spare parts
280943710117	BRACKET ASSY LCRV MTG	TATA spare parts
280943710118	BRACKET LCRV MOUNTING (C CLAMP)	TATA spare parts
280943900103	ASSY.BRACKET (QRV/RELAY VALVE MTG.)	TATA spare parts
280943900104	ASSY.PIPE(COMPR.TO AIR DRYER CUM.ENG.)	TATA spare parts
280943900136	ASSY.METAL PIPE WITH CRIMPED HOSE(AIR CO	TATA spare parts
280943900141	ASSY.NYLON PIPE SET CHASSIS COMPL	TATA spare parts
280943900177	ASSY.METAL PIPE-SECOND (HOSE TO INT.JOIN	TATA spare parts
280943900180	ASSY.NY.PIPE SET COMPLETE-LPK1518TC	TATA spare parts
280943900184	ASSY.NY.PIPE SET COMPL-1618/52/LHD/VOSS	TATA spare parts
280943900185	ASSY.NY.PIPE SET CHASSIS COMPL-VOSS	TATA spare parts
280943900187	ASSY.METAL PIPE WITH CRIMPED RUBBER HOSE	TATA spare parts
280943900188	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
280943900191	ASSY.NY.PIPE SET COMPL-1618/52/LHD	TATA spare parts
280943900192	ASSY. NYLON TUBE SET CHASSIS	TATA spare parts
280943900198	ASSY. METAL PIPE( INT JOINT TO DDU )	TATA spare parts
280943903301	BRACKET MODULATOR VALVE MTG	TATA spare parts

280943906801	TEE SOCKET	TATA spare parts
280943906802	T CONNECTOR 6X6X6 VOSS	TATA spare parts
280943908201	BRACKET-QUICK RELEASE/RELAY VALVE MTG.	TATA spare parts
280943910102	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
280943910103	NYL.PIPE SET COMPL-LPK1618/36LHD	TATA spare parts
280943910108	ASSY.METAL PIPE HOSE TO INT.JOINT(DIA18)	TATA spare parts
280943910109	ASSY.METAL PIPE INT.JOINT TO DDU(DIA18)	TATA spare parts
280943910119	ASY CHASSIS SET COMP(PL CON)1618-LHD-CAB	TATA spare parts
280943910127	ASSY.TUBE W/CRIMPED TEFLON HOSE	TATA spare parts
280943910128	ASSY. TUBE O.D.18X1.5(COMP.2ND PIPE)	TATA spare parts
280943910129	ASSY. COMPRESSOR 3RD PIPE	TATA spare parts
280943910131	ASSY NYLON PIPE SET CHASSIS	TATA spare parts
280943910132	ASSY.NY.GAUGE PIPE SET FOR CAB-VOSS	TATA spare parts
280943910133	ASSY. COMPRESSOR 1ST PIPE	TATA spare parts
280943910134	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
280943910135	ASSY. COMPRESSOR 3RD PIPE	TATA spare parts
280943910139	ASSY. NYLON PIPE CHASSIS SET COMPLETE	TATA spare parts
280943910150	ASSY NYLON PIPE SET CHASSIS LPK1623TC 36	TATA spare parts
280943910195	SET ASSY NYLON PIPE COMPL. WITH VOSS CON	TATA spare parts
280943910197	ASSY ST ADAPTOR VOSS NG 8 (BOTH SIDE)	TATA spare parts
280943920106	PIPE BUNCH ASSY	TATA spare parts
280943920120	PIPE ASSY BUNCH COMPLETE	TATA spare parts
280943920157	PIPE ASSY COMPRESSOR TO JOINT-1	TATA spare parts
280943920158	PIPE ASSY COMP 2ND JOINT-1 TO JOINT-2	TATA spare parts
280943920159	PIPE ASSY JOINT-2 TO APDA	TATA spare parts
280943930173	PIPE BUNCH ASSY	TATA spare parts
280943990101	REPAIR KIT BS6	TATA spare parts
280944000109	TIPPING ASSY	TATA spare parts
280944100103	BOTTOM MOUNTING BRACKET ASSEMBLY	TATA spare parts
280944100104	ASSY. TIPPING CYLINDER BS2/4	TATA spare parts
280944100105	LOCKING PLATE CYLINDER	TATA spare parts
280944100106	CYLINDER ASSY HYDRAULIC	TATA spare parts
280944100107	BOTTOM MOUNTING BRACKET	TATA spare parts
280944100108	HYDRAULIC CYLINDER ASSY	TATA spare parts
280944100112	BRACKET ASSY CYLINDER MTG BS6	TATA spare parts
280944100113	TELESCOPIC CYLINDER	TATA spare parts
280944100114	CYLINDER ASSY HYDRAULIC	TATA spare parts
280944100115	LOCKING PLATE BS6	TATA spare parts
280944100116	CYLINDER ASSY HYDRAULIC	TATA spare parts
280944100117	BRACKET CYLINDER MTG BS6	TATA spare parts
280944103201	HEX HEAD BOLT M16 X 55	TATA spare parts
280944103202	HEX HEAD BOLT BS6	TATA spare parts
280944104201	HOSE CLIP	TATA spare parts
280944105613	SUCTION HOSE R4 1 3/4INCH (METERS) BS6	TATA spare parts
280944105801	PRESSURE HOSE (3/4IN IDX2200L) BS6	TATA spare parts
280944105803	PRESSURE HOSE ASSYBS6	TATA spare parts
280944105804	CORRUGATED HOSE ID 3/4INCH 5 METER	TATA spare parts

280944105806	RETURN HOSE ASSEMBLY	TATA spare parts
280944105807	POLYURETHANE TUBE ID 4 X OD 6X7M	TATA spare parts
280944105809	RETURN LINE 1.25X1040	TATA spare parts
280944105810	SUCTION HOSE	TATA spare parts
280944105813	SUCTION HOSE ASSY	TATA spare parts
280944105815	HOSE ASSY PUMP TO RELIEF VALVE	TATA spare parts
280944105816	FLEXIBLE TUBE BS6	TATA spare parts
280944105817	AIR TUBE BS6	TATA spare parts
280944105818	RETURN HOSE ASSY BS6	TATA spare parts
280944105820	SUCTION HOSE ASSY BS6	TATA spare parts
280944105821	AIR TUBE BS6	TATA spare parts
280944105828	SUCTION VALVE KIT BS6	TATA spare parts
280944105829	HOSE PUMP TO VALVE BS6	TATA spare parts
280944105830	ADAPTER BS6	TATA spare parts
280944106502	HEX NUT	TATA spare parts
280944106503	HEX NUT M10	TATA spare parts
280944106504	NYLON NUT M16 X 2	TATA spare parts
280944106505	LOCK NUT	TATA spare parts
280944106506	LOCK NUT BS6	TATA spare parts
280944106701	SPLIT PIN 10 X 80	TATA spare parts
280944106702	CYLINDER TOP MOUNTING PIN	TATA spare parts
280944106704	SPLIT PIN BS6	TATA spare parts
280944106804	ELBOW (PNEUMATIC) SWIVEL	TATA spare parts
280944106807	ELBOW ADAPTOR ASY 1-1/2INCHBSPX1INCHBSP	TATA spare parts
280944106808	ASSEMBLY ELBOW 1INCH BSPX1- 3/4INCH BARE	TATA spare parts
280944106809	STRAIGHT ADAPTOR 1INCHBSP X3/4INCHBSP	TATA spare parts
280944106811	ADAPTER BS6	TATA spare parts
280944106816	ADAPTER BS6	TATA spare parts
280944106817	ADAPTER BS6	TATA spare parts
280944106818	ADAPTER	TATA spare parts
280944106819	HOSE ASSY BS6	TATA spare parts
280944107701	HOSE 1INCHID X1500LG 1INCHBSP FS90	TATA spare parts
280944107702	HOSE ID 1INCH X 1750MM LENGTH	TATA spare parts
280944107801	STD. BONDED SEAL ID33.7	TATA spare parts
280944107803	3/4INCH SELF CENTERING BONDED SEAL	TATA spare parts
280944107804	BONDED SEAL	TATA spare parts
280944108001	HEX HEAD SCREW M6X14	TATA spare parts
280944108002	HEX HEAD SCREW M6 X 30	TATA spare parts
280944108003	HEX.HD.SCREW ISO 4017 - M10X25-10.9 M10	TATA spare parts
280944109201	PLAIN WASHER	TATA spare parts
280944109202	SPRING WASHER	TATA spare parts
280944109203	SPRING WASHER	TATA spare parts
280944109205	WASHER	TATA spare parts
280944109206	PLAIN WASHER STEEL A 10.5	TATA spare parts
280944109207	WASHER BS6	TATA spare parts
280944109902	ADAPTOR (1INCHBSP X 1INCH BSP)	TATA spare parts
280944109905	ADAPTOR 1INCHBSP-1 1/4INCHBSP	TATA spare parts



280944109906	HOSE STRAP(NYLON)	TATA spare parts
280944400102	HYDRAULIC TANK ASSY	TATA spare parts
280944400104	TANK ASSY HYDRAULIC	TATA spare parts
280944400106	KIT-HYDRAULIC TANK	TATA spare parts
280944400107	TANK ASSY HYDRAULIC BS6	TATA spare parts
280944400110	HYDRAULIC TANK ASSY	TATA spare parts
280944404401	COLLAR FE410W B	TATA spare parts
280944409001	LINER SPOOL VALVE	TATA spare parts
280944409003	LINER SPOOL VALVE	TATA spare parts
280944409004	P209 DC VALVE BS6	TATA spare parts
280944409901	STRAP ASSY HYDRAULIC TANK BS6	TATA spare parts
280944409903	STRAP BS6	TATA spare parts
280944989901	RETURN LINE FILTER KIT BS6	TATA spare parts
280944990102	KIT-HYDRAULIC	TATA spare parts
280944993202	ALLEN KEY BOLT BS6	TATA spare parts
280944993203	ALLEN BOLT M6X10 BS6	TATA spare parts
280944993204	ALLEN KEY BOLT BS6	TATA spare parts
280944994201	SUCTION HOSE CLAMP KIT ( DIA 56-61) BS6	TATA spare parts
280944994203	L-CLAMP	TATA spare parts
280944994204	STRAIGHT CLAMP	TATA spare parts
280944994206	CLAMP BS6	TATA spare parts
280944994207	1-1/2 INCH HOSE CLAMP	TATA spare parts
280944994209	HOSE ROUTING CLAMP KIT DIA 31 BS6	TATA spare parts
280944994210	HOSE ROUTING CLAMP KIT DIA 58 BS6	TATA spare parts
280944994211	SUCTION HOSE CLAMP KIT (DIA 56-61) BS6	TATA spare parts
280944994215	CLAMP SUCTION HOSE BS6	TATA spare parts
280944995801	HOSE 3/4IN ID (RETURN LINE)	TATA spare parts
280944996701	CYLINDER MOUNTING PIN WITH SPLIT PIN	TATA spare parts
280944996702	SPLIT PIN 10-100 MM (DIN 94)	TATA spare parts
280944996801	ELBOW	TATA spare parts
280944996802	ELBOW	TATA spare parts
280944996803	HOSE CLAMP KIT 30	TATA spare parts
280944996804	HOSE CLAMP KIT 38	TATA spare parts
280944996805	HOSE CLAMP KIT BS6	TATA spare parts
280944996902	AIR TUBE BS6	TATA spare parts
280944997701	GROMMET	TATA spare parts
280944997702	RUBBER FOOT MOUNTING	TATA spare parts
280944997703	RUBBER STRAP OIL TANK BS6	TATA spare parts
280944997704	RUBBER PACKING HYDRAULIC TANK BS6	TATA spare parts
280944997705	TANK METAL STRAP WELDED BS6	TATA spare parts
280944997706	RUBBER PACKING HYDRAULIC TANK BS6	TATA spare parts
280944997710	RUBBER PACKING HYDRAULIC TANK BS6	TATA spare parts
280944997801	SEAL BS6	TATA spare parts
280944998601	CYLINDER EYE SPACER DIA 50 * 16	TATA spare parts
280944999001	LINER SPOOL VALVE BS6	TATA spare parts
280944999002	ACV	TATA spare parts
280944999003	BALL VALVE	TATA spare parts

280944999201	SPRING WASHER M8 BS6	TATA spare parts
280944999902	RETURN LINE FILTER BASE-BUILT IN TYPE BS	TATA spare parts
280944999904	ACV MOUNTING BRACKET BS6	TATA spare parts
280944999905	SUCTION ELBOW ADAPTOR KIT G1INCH BSPOT B	TATA spare parts
280944999907	AIR BREATHER ASSY	TATA spare parts
280944999908	PLATE BOTTOM BS6	TATA spare parts
280944999909	OIL LEVEL INDICATOR	TATA spare parts
280944999910	BRACKET ASSY CYLINDER MTG BOTTOM BS6	TATA spare parts
280944999911	SAFETY TIPPING STICKER(TATA) BS6	TATA spare parts
280944999912	NRV ADAPTER KIT BS6	TATA spare parts
280944999913	SUCTION ELBOW ADAPTER KIT BS6	TATA spare parts
280944999914	PRESSURE ADAPTER KIT BS6	TATA spare parts
280944999915	BODY FIX KIT (HYFIX) BS6	TATA spare parts
280944999917	PRESSURE ADAPTER KIT BS6	TATA spare parts
280944999918	CHASSIS BRACKET HM12 DIA 60 X 368 BS6	TATA spare parts
280944999921	NRV ADAPTER KIT BS6	TATA spare parts
280946100101	WELDING FIX.FOR ASSY.STEERING G/B BKT.	TATA spare parts
280946100109	STEERING GEARBOX MTG BKT ASSY	TATA spare parts
280946304101	PITMAN ARM	TATA spare parts
280946400101	ASSY.STG WHEEL-500DIA.WITH COVER	TATA spare parts
280946400102	ASSY.STEERING WHEEL -500 DIA W/O COVER	TATA spare parts
280946600102	DRAG LINK ASSY	TATA spare parts
280946600103	ASSY. DRAG LINK SEALED TYPE-RHD BS2/3	TATA spare parts
280946600107	LINK ASSY LHD	TATA spare parts
280946800101	ASSY.LP HOSE-CRIMPED(STG.TANK TO ST.PUMP	TATA spare parts
280946800102	ASSY. HOSE CRIMPED(STG G. B. TO STG. TAN	TATA spare parts
280946800116	ASSY HOSE CRIMPED(STG G. B. TO STG. TANK	TATA spare parts
280946800133	KIT ASSY.P/STG.PIPE LINES & CONNECTOR	TATA spare parts
280946800134	ASSY.HOSE PIPES KIT	TATA spare parts
280946800155	ASSY.TUBE W/CRIMPED R/HOSE(SUCTION LINE)	TATA spare parts
280946800156	ASSY.TUBE W/CRIMPED R/HOSE (PR.LINE)	TATA spare parts
280946800157	ASSY.TUBE W/CRIMPED R/HOSE (G.B END)	TATA spare parts
280946800158	ASSY.TUBE W/CRIMPED R/HOSE(TANK END)	TATA spare parts
280946808202	HEX NUT	TATA spare parts
280946990103	KIT-STEERING LINES AND CLAMPS	TATA spare parts
280947600101	ASSY. SUCTION LINE	TATA spare parts
280947600102	ASSY. RETURN TUBE WITH CRIMPED RUBBER HO	TATA spare parts
280947600107	ASSY. SUCTION LINE	TATA spare parts
280947600108	ASSY. RETURN LINE	TATA spare parts
280947600109	ASSY.SUCTION LINE	TATA spare parts
280947600110	ASSY.RETURN LINE	TATA spare parts
280947600122	ASSY. BRACKET (MICO WATER SEPERATOR MTG)	TATA spare parts
280947600145	FUEL SUCTION PIPE ASSY	TATA spare parts
280947600146	FUEL SUCTION PIPE ASSY	TATA spare parts
280947600147	FUEL RETURN PIPE ASSY	TATA spare parts
280947600149	BRACKET (FUEL FILTER MTG.)	TATA spare parts
280947608203	BRACKET (FUEL FEED PUMP MOUNTING)	TATA spare parts

280949100101	ASSY. MUFFLER BS1/2/3	TATA spare parts
280949100103	ASSY. SILENCER	TATA spare parts
280949100104	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
280949100105	ASSY. MUFFLER	TATA spare parts
280949200101	ASSY. EXHAUST PIPE	TATA spare parts
280949200102	ASSY. BRACKET (EXHAUST -TAIL PIPE MTG.)	TATA spare parts
280949200104	ASSY. BRACKET (EXHAUST MTG.)	TATA spare parts
280949200105	ASSY. BRACKET	TATA spare parts
280949200106	ASSY. EXHAUST FIRST PIPE	TATA spare parts
280949200107	ASSY. EXHAUST PIPE-INTERMEDIATE.	TATA spare parts
280949200114	ASSY.INTERMEDIATE PIPE(VERT.TAIL PIPE)	TATA spare parts
280949200115	ASSY.INTERMEDIATE PIPE	TATA spare parts
280949200116	ASSY. CLAMP (SHIELD MOUNTING)	TATA spare parts
280949200117	ASSY. BRACKET (VERTICAL EXHAUST MTG.)	TATA spare parts
280949200118	ASSY. CLAMP	TATA spare parts
280949200119	ASSY. BRACKET	TATA spare parts
280949200120	ASSY. SUPPORT (INTERMEDIATE PIPE)	TATA spare parts
280949200122	ASSY EXHAUST PIPE (WITH FLEX CONNECTOR)	TATA spare parts
280949200123	ASSY.EXHAUST FIRST PIPE	TATA spare parts
280949200124	ASSY.EXHAUST PIPE(INTERMEDIATE)	TATA spare parts
280949200125	ASSY. BRACKET(EXHAUST MTG.)	TATA spare parts
280949200127	ASSY.BRACKET-EXHAUST MTG.(ON ENG.BLOCK)	TATA spare parts
280949200128	ASSY. INTERMEDIATE PIPE (VERT.TAIL PIPE)	TATA spare parts
280949200129	ASSY. EXHAUST - INTERMEDIATE PIPE	TATA spare parts
280949200130	ASSY.BRACKET (EXHAUST MTG.)	TATA spare parts
280949200132	ASSY. EXHAUST PIPE (WITH FLEX CONNECTOR)	TATA spare parts
280949200134	ASSY. EXHAUST PIPE	TATA spare parts
280949200135	ASSY.EXHAUST PIPE FIRST	TATA spare parts
280949200137	ASSY. BRACKET	TATA spare parts
280949200139	ASSY.EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
280949200141	ASSY. BRACKET (EXHAUST MTG.)	TATA spare parts
280949200142	ASSY. INTERMEDIATE PIPE	TATA spare parts
280949200143	ASSY. EXHAUST PIPE (AFTER EXHAUST BRAKE)	TATA spare parts
280949200144	ASSY. BRACKET (SUPPORT FROM ENG. BLOCK)	TATA spare parts
280949200147	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
280949203301	BRACKET (EXHAUST MTG.)	TATA spare parts
280949203302	BRACKET	TATA spare parts
280949203303	BRACKET (EXHAUST PIPE MTG. ON C/M)	TATA spare parts
280949206002	TIE MEMBER	TATA spare parts
280949206902	TAIL PIPE	TATA spare parts
280949206908	TAIL PIPE END (VERTICAL EXHAUST)	TATA spare parts
280949206913	EXHAUST TAIL PIPE	TATA spare parts
280949206934	TAIL PIPE	TATA spare parts
280949208203	CLAMP-SILENCER MTG	TATA spare parts
280949208204	CLAMP	TATA spare parts
280949208205	CLAMP	TATA spare parts
280949208215	CLAMP	TATA spare parts

280949208217	CLAMP	TATA spare parts
280949208218	CLAMP (TAIL PIPE MTG.)	TATA spare parts
280949208220	SHIELD (VERTICAL EXHAUST - TAIL PIPE)	TATA spare parts
280949208221	SHIELD (VERTICAL EXHAUST - TAIL PIPE)	TATA spare parts
280949208223	CLAMP	TATA spare parts
280949208231	SHIELD	TATA spare parts
280949208237	CLAMP	TATA spare parts
280949208241	PIPE CLAMP	TATA spare parts
280949208242	CLAMP	TATA spare parts
280949208243	CLAMP (EXHAUST MOUNTING)	TATA spare parts
280949208244	BRACKET (EXHAUST PIPE MTG.)	TATA spare parts
280949208248	CLAMP	TATA spare parts
280949208254	CLAMP	TATA spare parts
280949208255	CLAMP	TATA spare parts
280954107501	CAP (FOR BATT.CABLE CLAMP -VE)	TATA spare parts
280954200101	ASSY BRACKET (FOR RELAY AND FUSE BOX)	TATA spare parts
280954200112	INSTRUMENT CLUSTER ASSY	TATA spare parts
280954208202	BRACKET(HORN MTG.)	TATA spare parts
280954209901	RPM METER W/DIGITAL HOUR METER 24V	TATA spare parts
280954209902	ELECT S.M. WI LCD ODOMETER (1:1)	TATA spare parts
280954209903	ELECT.S.M.WI LCD ODOMETER (1:1.8)	TATA spare parts
280954209905	REAR FOG LAMP CONTROLLER(24V)	TATA spare parts
280954209907	ELECTR.SPEEDOMETERRATIO1.04 24V IIL	TATA spare parts
280954209909	ELECT.SPEEDOMETER SPARE(0.88)12V	TATA spare parts
280954209914	ELECT.SPEEDOMETER SPARE(1.04)12V	TATA spare parts
280954209915	ELECT.SPEEDOMETER SPARE(0.80)24V-IIL	TATA spare parts
280954209916	ELECT.SPEEDOMETER SPARE(0.88)24V	TATA spare parts
280954209917	ELECTRONIC SPEEDOMETER (1:0.88)0-140 KMP	TATA spare parts
280954209919	ELECT.SPEEDOMETER(1.04)24V 0-140KMPH	TATA spare parts
280954400101	ASSY BKT.(RH) FOR TAIL LAMP MTG.BKT.	TATA spare parts
280954400102	ASSY BRACKET(LH)(FOR TAIL LAMP MTG.BKT.)	TATA spare parts
280954400105	ASSY TAIL LAMP BRACKET (RH)	TATA spare parts
280954400106	ASSY TAIL LAMP BRACKET (LH)	TATA spare parts
280954408210	TAIL LAMP MOUNTING BRACKET	TATA spare parts
280954408211	TAIL LAMP SUPPORT TRIP	TATA spare parts
280954440101	FIVE CHAMBER TAIL LAMP (24V) LH BS2/3/4	TATA spare parts
280954440102	FIVE CHAMBER TAIL LAMP (24V)-RH BS2/3/4	TATA spare parts
280954440104	ASSY WARNING LAMP IND.(24V)	TATA spare parts
280954440107	ASSY CAB LAMP	TATA spare parts
280954440111	ASSY 4CH.TAIL LAMP LH 24V(CLEAR)	TATA spare parts
280954440112	ASSY 4CH.TAIL LAMP RH 24V(CLEAR)	TATA spare parts
280954440117	H/L W/MOT 24V LH-RHD CLEAR	TATA spare parts
280954440118	H/L W/MOT 24V RH-RHD CLEAR	TATA spare parts
280954549901	FLASHER (24V)	TATA spare parts
280954600139	WIRING HARNESS TAIL	TATA spare parts
280954600140	WIRING HARNESS MAIN	TATA spare parts
280954600141	WIRING HARNESS ABS FRAME	TATA spare parts

280954600143	WIRING HARNESS TAIL	TATA spare parts
280954600144	WIRING HARNESS ABS FRAME	TATA spare parts
280954600148	WIRING HARNESS ABS SPLIT	TATA spare parts
280954601605	WIRING HARNESS LOAD BODY	TATA spare parts
280954601620	W/H 7 POLE SOCKET(TRAILER)LPT-1518	TATA spare parts
280954620101	W/H.MAIN LPT1518TC	TATA spare parts
280954620102	W/H.ENGINE LPT1518TC	TATA spare parts
280954620103	W/H TAIL(LPT1518/52TC BS-II)	TATA spare parts
280954620104	W/H PARK BR.& SEAT BELT SW.	TATA spare parts
280954620105	WIRING HARNESS 7 POLE SOCKT	TATA spare parts
280954620106	W/H INST.CONSOLE(LPT/LPK1518/1618TC)	TATA spare parts
280954620106AE	W/H INST.CONSOLE 1618 /LPT 2523	TATA spare parts
280954620107	W/H MAIN(LPT1618TC LHD(UAE)BS-II)	TATA spare parts
280954620108	W/H ENGINE(LPT1618TC LHD(UAE)BS-II)	TATA spare parts
280954620109	W/H TAIL(LPT1618TC LHD(UAE)BS-II)	TATA spare parts
280954620111	WIRING HARNESS MAIN	TATA spare parts
280954620112	W/H TAIL	TATA spare parts
280954620116	WIRING HARNESS MAIN	TATA spare parts
280954620117	WIRING HARNESS TAIL	TATA spare parts
280954620119	W/H MAIN LPT-1618 LHD 24V	TATA spare parts
280954620120	W/H ENGINE LPT-1618	TATA spare parts
280954620121	W/H TAIL LPT-1618 LHD 24V	TATA spare parts
280954620122	W/H SENSOR LPT-1618 LHD 24V	TATA spare parts
280954620123	W/H INST.CONSOLE LPT1618 LHD	TATA spare parts
280954620129	W/H INST.CONSOLE(LPT/LPK1518/1618TC)	TATA spare parts
280954620133	W/H PIGTAIL FOR SEAT BELT/PARK	TATA spare parts
280954620141	W/H MAIN	TATA spare parts
280954620142	W/H TAIL	TATA spare parts
280954660107	W/H LOW AIR PR.SW	TATA spare parts
280954700101	PLATE ASSY MOTOR MTG	TATA spare parts
280982400101	WIPER MOTOR AND BRACKET ASSY	TATA spare parts
280987000107	LOAD BODY WITH MOUNTINGS	TATA spare parts
280987000108	LOAD BODY	TATA spare parts
280987000115	LPK3118-18CUM BODY	TATA spare parts
280987000126	LOAD BODY ASSY (WITHOUT HYDRAULIC KIT &	TATA spare parts
280987000127	LOAD BODY WITH MOUNTINGS	TATA spare parts
280987000128	LOAD BODY ASSEMBLY	TATA spare parts
280987000129	LOAD BODY WITHOUT SUBFRAME	TATA spare parts
280987000130	LOAD BODY ASSY	TATA spare parts
280987000186	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
280987000198	LOAD BODY BS6	TATA spare parts
280987000202	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
280987000219	LOAD BODY BS6	TATA spare parts
280987000220	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
280987000234	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
280987000245	LOAD BODY BS6	TATA spare parts
280987000246	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts

280987010111	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
280987010112	LOAD BODY WITH MOUNTINGS BS6	TATA spare parts
280987010124	BODY MTG BS6	TATA spare parts
280987010125	BODY MTG BS6	TATA spare parts
280987010127	BODY MTG BS6	TATA spare parts
280987010164	LOAD BODY BS6	TATA spare parts
280987010165	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
280987010185	LOAD BODY WITH SUBFRAME ASSY BS6	TATA spare parts
280987010186	LOAD BODY ASSY BS6	TATA spare parts
280987010223	LOAD BODY WITH MOUNTINGS BS6	TATA spare parts
280987010230	SUBFRAME ASSY WITH MOUNTINGS-HAMMER BL	TATA spare parts
280987020101	BODY MTG BS6	TATA spare parts
280987100104	ASSY SUB FRAME	TATA spare parts
280987100108	SUB FRAME ASSY	TATA spare parts
280987100115	CRADLE ASSY CYL MTG BS6	TATA spare parts
280987100117	STABILIZER ASSY	TATA spare parts
280987100126	TUBE ASSY OUTER BS6	TATA spare parts
280987100127	BRACKET ASSY BS6	TATA spare parts
280987100134	SUBFRAME ASSY	TATA spare parts
280987100136	SUBFRAME ASSY WITH MOUNTINGS	TATA spare parts
280987100146	SUBFRAME ASSY 24 CUM BOX TIPPER	TATA spare parts
280987100149	CRADLE ASSY	TATA spare parts
280987100155	ASSY. SUBFRAME	TATA spare parts
280987100156	HYD TANK MTG ASSY_24CUM HD	TATA spare parts
280987100157	SUBFRAME ASSY	TATA spare parts
280987100158	CRADLE ASSY CYL MTG	TATA spare parts
280987100162	SUBFRAME ASSY BS6	TATA spare parts
280987100163	SUBFRAME ASSY BS6	TATA spare parts
280987100170	STABILIZER ASSY BS6	TATA spare parts
280987100181	CRADLE ASSY CYL MTG BS6	TATA spare parts
280987100183	SUBFRAME ASSY BS6	TATA spare parts
280987100207	SUBFRAME ASSY WITH MOUNTINGS BS6	TATA spare parts
280987100211	SUBFRAME ASSY WITH MOUNTINGS BS6	TATA spare parts
280987100214	SUBFRAME ASSY BS6	TATA spare parts
280987103406	OUTER BUSH	TATA spare parts
280987104201	ROD FRAME BS6	TATA spare parts
280987104202	PIN BS6	TATA spare parts
280987106701	PIN STABILIZER	TATA spare parts
280987106703	SHAFT REAR HINGE	TATA spare parts
280987106705	LOCK PIN	TATA spare parts
280987106706	PIN TAIL LOCK BS6	TATA spare parts
280987106707	LOCKING PIN BS6	TATA spare parts
280987106708	PIN STABILIZER MTG TOPBS6	TATA spare parts
280987106710	PIN TAIL LOCK BS6	TATA spare parts
280987106712	PIN TAIL LOCK BS6	TATA spare parts
280987107115	PLATE BS6	TATA spare parts
280987107116	GUSSET BS6	TATA spare parts

280987107118	PLATE BS6	TATA spare parts
280987107119	FORK	TATA spare parts
280987107122	Z-PLATE CRADLE	TATA spare parts
280987108205	PLATE CRADLE SUPPORT BS6	TATA spare parts
280987108234	STOPPER PLATE BS6	TATA spare parts
280987108239	STOPPER PLATE BS6	TATA spare parts
280987108241	CHANNEL BS6	TATA spare parts
280987108275	SUPPORT PLATE BS6	TATA spare parts
280987108298	PLATE CRADLE SUPPORT BS6	TATA spare parts
280987108299	PLATE BS6	TATA spare parts
280987109903	REFLECTIVE TAPE BS6	TATA spare parts
280987110135	BOX ASSY TIPPER BODY BS6	TATA spare parts
280987110138	TIPPER BODY ASSY WITH SUBFRAME BS6	TATA spare parts
280987110167	SUBFRAME ASSY WITH CRADLE & MOUNTINGS BS6	TATA spare parts
280987118298	FOOT STEP BS6	TATA spare parts
280987118299	C-SECTION FRONT WALL BS6	TATA spare parts
280987160102	SUBFRAME ASSY WITH MOUNTINGS BS6	TATA spare parts
280987200102	BRACKET CYLINDER MTG BS6	TATA spare parts
280987200107	BRACKET CYLINDER MTG BS6	TATA spare parts
280987300106	ASSY.TIPPING BODY/HALF CANOPY/LD/LPK3118	TATA spare parts
280987300108	TIPPING BODY/LD/ LPK3118/18CUM/SLCAB	TATA spare parts
280987300121	LADDER BS6	TATA spare parts
280987300122	HINGE ASSY TAILGATE LH BS6	TATA spare parts
280987300123	HINGE ASSY TAILGATE BS6	TATA spare parts
280987300152	LADDER BS6	TATA spare parts
280987300190	LOAD BODY BS6	TATA spare parts
280987304301	SNAP RING BS6	TATA spare parts
280987306001	HANDLE BS6	TATA spare parts
280987306702	COTTER PIN BS6	TATA spare parts
280987307103	STOPPER PLATE BS6	TATA spare parts
280987308219	BEND PLATE BS6	TATA spare parts
280987308221	BRACKET TOP MARKER LAMP MTG BS6	TATA spare parts
280987338207	RAIN FLAP LH BS6	TATA spare parts
280987338215	RAIN FLAP BS6	TATA spare parts
280987338216	RAIN FLAP BS6	TATA spare parts
280987400106	HINGE TAILGATE BS6	TATA spare parts
280987400107	TAILGATE ASSY BS6	TATA spare parts
280987400108	TAILGATE ASSY BS6	TATA spare parts
280987400112	TAILGATE ASSY BS6	TATA spare parts
280987400114	TAILGATE ASSY BS6	TATA spare parts
280987400116	HINGE ASSY TAILGATE BS6	TATA spare parts
280987400121	TAILGATE ASSY BS6	TATA spare parts
280987400142	TAILGATE ASSY BS6	TATA spare parts
280987400146	TAILGATE ASSY BS6	TATA spare parts
280987400149	TAILGATE ASSY BS6	TATA spare parts
280987400163	TAILGATE ASSY BS6	TATA spare parts
280987400164	TAILGATE ASSY BS6	TATA spare parts

280987405001	HOOK BS6	TATA spare parts
280987407101	TAIL DOOR HINGE L PLATE BS6	TATA spare parts
280987407102	HINGE TAILGATE BS6	TATA spare parts
280987407103	HINGE TAILGATE BS6	TATA spare parts
280987408293	RAIN FLAP RH BS6	TATA spare parts
280987409201	WASHER BS6	TATA spare parts
280987409202	WASHER BS6	TATA spare parts
280987800103	BODY MTG BS6	TATA spare parts
280987800106	RESILIENCE MTG ASSY UPPER BS6	TATA spare parts
280987800107	RESILIENCE MTG ASSY BS6	TATA spare parts
280987800108	BODY MTG BS6	TATA spare parts
280987800111	BODY MTG BS6	TATA spare parts
280987800112	BODY MTG BS6	TATA spare parts
280987800119	BODY MTG BS6	TATA spare parts
280987800121	BODY MTG BS6	TATA spare parts
280987800126	BODY MTG BS6	TATA spare parts
280987800127	BODY MTG BS6	TATA spare parts
280987800128	BODY MTG BS6	TATA spare parts
280987800130	RESILIENCE MTG ASSY BS6	TATA spare parts
280987800132	RESILIENCE MTG ASSY BS6	TATA spare parts
280987800148	BODY MTG BS6	TATA spare parts
280987800150	RESILIENCE MTG ASSY BS6	TATA spare parts
280987800151	RESILIENCE MTG ASSY BS6	TATA spare parts
280987800152	RESILIENCE MTG ASSY BS6	TATA spare parts
280987803308	RESILIENCE MTG BS6	TATA spare parts
280987803317	RESILIENCE MTG BS6	TATA spare parts
280987806001	CHAIN	TATA spare parts
280987807102	PLATEBOTTOMCLAMP BS6	TATA spare parts
280987808207	ATTACHMENT PLATE 1 BS6	TATA spare parts
280987808223	PLATE BOTTOM CLAMP BS6	TATA spare parts
280987808234	RESILIENCE MTG BS6	TATA spare parts
280987808701	PIVOT SPRING BS6	TATA spare parts
280987809201	WASHER RESILIENCE MTG BS6	TATA spare parts
280987900109	STABILIZER ASSEMBLY	TATA spare parts
280987900118	MUDGUARD ASSY	TATA spare parts
280987900121	FRAME ASSY BS6	TATA spare parts
280987900122	LOCKING BRACKET	TATA spare parts
280987900124	MUDGUARD ASSY BS6	TATA spare parts
280987900129	FRAME ASSY BS6	TATA spare parts
280987900132	MUDGUARD ASSY BS6	TATA spare parts
280987900142	MUDGUARD ASSY BS6	TATA spare parts
280987900143	MUDGUARD ASSY BS6	TATA spare parts
280987900144	HINGE ASSY MUDFLAP BS6	TATA spare parts
280987903301	BRACKET TAILGATE MTG	TATA spare parts
280987903304	LOCK BRACKET BS6	TATA spare parts
280987903305	LOCK BRACKET BS6	TATA spare parts
280987903306	LOCK BRACKETRH BS6	TATA spare parts



280987903307	LOCK BRACKETLH BS6	TATA spare parts
280987903308	LOCK BRACKET BS6	TATA spare parts
280987903309	LOCK BRACKET BS6	TATA spare parts
280987906001	FORK TAILGATE LOCKING MECHANISIMBS6	TATA spare parts
280987906909	PIPE BS6	TATA spare parts
280987907703	RAIN FLAP REAR	TATA spare parts
280987907704	RAIN FLAP BS6	TATA spare parts
280987907705	RAIN FLAP BS6	TATA spare parts
280987907706	RAIN FLAP REAR BS6	TATA spare parts
280987908204	BRACKET WHEEL CHOKE BS6	TATA spare parts
280987908205	PLATE MUDGUARD BS6	TATA spare parts
280987908216	MUDGUARD BS6	TATA spare parts
280987908217	PLATE HINGE BOTTOM BS6	TATA spare parts
280987908219	PLATE MUDGUARD BS6	TATA spare parts
280987908235	VALANCE COVER LH BS6	TATA spare parts
280987908236	VALANCE COVER RH BS6	TATA spare parts
280987908237	MUDGUARD BS6	TATA spare parts
280987908245	MUDGUARD BS6	TATA spare parts
280987908256	VALANCE COVER RH BS6	TATA spare parts
280987908257	VALANCE COVER LH BS6	TATA spare parts
280987908277	RAIN FLAP BS6	TATA spare parts
280987908278	RAIN FLAP BS6	TATA spare parts
280987908279	RAIN FLAP LH BS6	TATA spare parts
280987908280	RAIN FLAP RH BS6	TATA spare parts
280987908281	PLATE HINGE BOTTOM BS6	TATA spare parts
280987909901	PIN HINGE BS6	TATA spare parts
280987990109	KIT COMP.18CUM STD LD BODY	TATA spare parts
280987990131	CHAIN BS6	TATA spare parts
280987999901	DECAL	TATA spare parts
280987999902	REFLECTIVE TAPE BS6	TATA spare parts
280987999903	REFLECTIVE TAPE BS6	TATA spare parts
280987999904	REFLECTIVE TAPE BS6	TATA spare parts
280987999905	REFLECTIVE TAPE BS6	TATA spare parts
280987999907	REFLECTIVE TAPE TAILGATE VERTICAL BS6	TATA spare parts
280987999908	REFLECTIVE TAPE SIDEWALL BOTTOM-II BS6	TATA spare parts
280987999909	REFLECTIVE TAPE BS6	TATA spare parts
280987999910	REFLECTIVE TAPE BS6	TATA spare parts
280987999911	REFLECTIVE TAPE BS6	TATA spare parts
280987999912	REFLECTIVE TAPE BS6	TATA spare parts
280987999914	REFLECTIVE TAPE SIDEWALL BOTTOM-III BS6	TATA spare parts
280987999915	REFLECTIVE TAPE BS6	TATA spare parts
280987999916	REFLECTIVE TAPE BS6	TATA spare parts
280987999917	TATA STICKER (TAIL GATE)	TATA spare parts
280987999919	REFLECTIVE TAPE BS6	TATA spare parts
280987999928	SAFETY STICKER BS6	TATA spare parts
281589100154	HYDRAULIC CYLINDER ASSY. CAB TILTING	TATA spare parts
281615109902	SOLENOID SWITCH ASSEMBLY	TATA spare parts

281615109903	FIXING BRACKET ASSEMBLY	TATA spare parts
281615109904	ENGAGING LEVER & SUPPORT PLATE ASSY	TATA spare parts
281615109905	INTER BKT & BEARING ASSY	TATA spare parts
281615109906	RELAY ASSY	TATA spare parts
281615109907	OUTPUT SHAFT ASSY	TATA spare parts
281615109908	PLANETARY GEAR ASSY	TATA spare parts
281615109909	GEAR COVER PLATE	TATA spare parts
281615109910	ARMATURE & BEARING ASSY	TATA spare parts
281615109911	BALL BEARING (ARMATURE)	TATA spare parts
281615109912	FIELD COIL ASSY	TATA spare parts
281615109913	BRUSH GEAR ASSY	TATA spare parts
281615109914	DRIVE ASSEMBLY (10 TEETH)	TATA spare parts
281615109915	CE BKT ASSY	TATA spare parts
281615109916	BRUSH ASSEMBLY KIT	TATA spare parts
281615109920	FASTNERS & W/H ASSY KIT	TATA spare parts
281615409951	PULLEY (8GROOVE)	TATA spare parts
281615409952	DE BKT ASSY	TATA spare parts
281615409954	ROTOR ASSY (WITH BALL BEARING)	TATA spare parts
281615409955	SRE BALL BEARING	TATA spare parts
281615409956	STATOR WINDING ASSY	TATA spare parts
281615409957	SRE BKT ASSY	TATA spare parts
281615409958	RECTIFIER ASSY	TATA spare parts
281615409960	REGULATOR & CONNECTOR MOULDING ASSEMBLY	TATA spare parts
281615409961	REAR COVER MTG	TATA spare parts
281615409962	BEARING ASSEMBLING KIT	TATA spare parts
281615409967	FASTENERS ASSEMBLING KIT	TATA spare parts
281652200101	BRACKET ASSY REAR MUDGUARD FRONT-LHBS6	TATA spare parts
281652200102	BRACKET ASSY REAR MUDGUARD FRONT-RHBS6	TATA spare parts
281652200103	BRACKET ASSY REAR MUDGUARD REAR-LHBS6	TATA spare parts
281652200104	BRACKET ASSY REAR MUDGUARD REAR-RHBS6	TATA spare parts
281652200107	BRACKET ASSY REAR MUDGUARD REAR-LHBS6	TATA spare parts
281652200108	BRACKET ASSY REAR MUDGUARD REAR-RHBS6	TATA spare parts
281652200111	BRACKET ASSY REAR FENDER MTG FRONT-LH BS	TATA spare parts
281652200112	BRACKET ASSY REAR FENDER MTG FRONT-RH BS	TATA spare parts
281652200115	BRACKET ASSY REAR MUDGUARD REAR-LH BS6-P	TATA spare parts
281652200116	BRACKET ASSY REAR MUDGUARD REAR-RH BS6-P	TATA spare parts
281652206301	REAR MUDGUARD FRONT-LH BS6	TATA spare parts
281652206302	REAR MUDGUARD FRONT-RH BS6	TATA spare parts
281652206303	REAR MUDGUARD REAR-LH BS6	TATA spare parts
281652206304	REAR MUDGUARD REAR-RH BS6	TATA spare parts
281652206305	ARCH WHEEL REAR-LH	TATA spare parts
281652206306	ARCH WHEEL REAR-RH	TATA spare parts
281652206307	MUDFLAP REAR-LH BS6	TATA spare parts
281652206308	MUDFLAP REAR-RH BS6	TATA spare parts
281652206309	MUDFLAP REAR BS6	TATA spare parts
281652206310	REAR MUDGUARD FRONT-LH BS6	TATA spare parts
281652206311	REAR MUDGUARD FRONT-RH BS6	TATA spare parts

281652206312	REAR MUDGUARD REAR-LH BS6	TATA spare parts
281652206313	REAR MUDGUARD REAR-RH BS6	TATA spare parts
281652206320	ARCH WHEEL REAR-LH BS6	TATA spare parts
281652206321	ARCH WHEEL REAR-RH BS6	TATA spare parts
281652207105	LOCATING PLATE BS6	TATA spare parts
281654100125	BRKT A-BATT WITH MTG SPACER	TATA spare parts
281654100127	ASSY CARRIER BATTERY WITH A/TANK SUPPORT	TATA spare parts
281654100131	ASSY.COPPER BATTERY CABLE +VE (120 SQ.MM	TATA spare parts
281654100133	ASSY. COPPER BATTERY CABLE -VE (120 SQ.M	TATA spare parts
281654100135	ASSY COPPER BATTERY CABLE +VE (95 SQ.MM)	TATA spare parts
281654100137	ASSY COPPER BATTERY CABLE -VE (95 SQ.MM)	TATA spare parts
281654100147	ASSY PLATE AUX FUSE BOX	TATA spare parts
281654100149	POSITIVE BATTERY CABLE(95 SQ.MM)FOR LPS	TATA spare parts
281654100150	NEGATIVE BATTERY CABLE( 95 SQ MM) FOR LP	TATA spare parts
281654100162	BATTERY CABLE 16 SQMM	TATA spare parts
281654100163	ASSY COPPER BATTERY CABLE LINK 120 SQMM	TATA spare parts
281654100164	ASSY.COPPER BATTERY CABLE +VE 120 SQ.MM	TATA spare parts
281654100165	ASSY.COPPER BATTERY CABLE -VE (120 SQ.MM	TATA spare parts
281654100166	EARTH STRAP	TATA spare parts
281654100171	ASSY COPPER BATTERY CABLE +VE (95 SQ.MM)	TATA spare parts
281654100172	ASSY COPPER BATTERY CABLE -VE (95 SQ.MM)	TATA spare parts
281654100173	ASSY BRKT BATTERY CARRIER MTG ON LONG ME	TATA spare parts
281654100174	ASSY BRKT BATTERY CARRIER MTG ON LONG ME	TATA spare parts
281654100176	ASSY COPPER BATTERY CABLE LINK 95 SQ.MM	TATA spare parts
281654100182	ASSY CHANNEL BATTERY CLAMPING	TATA spare parts
281654100184	ASSY PROTECTOR BATTERY	TATA spare parts
281654100184AE	ASSY PROTECTOR BATTERY 1628	TATA spare parts
281654100201	ASSY CARRIER BATTERY	TATA spare parts
281654100207	ASSY CARRIER BATTERY (LPK 3128 & 3138)	TATA spare parts
281654100211	BATTERY CABLE NEGATIVE 70 SQ.MM M0	TATA spare parts
281654100223	BATT.CABLE +VE 70 SQ.MM	TATA spare parts
281654100224	BATT.CABLE -VE 70 SQ.MM	TATA spare parts
281654100237	BATT CABLE +VE 70 SQMM LENGTH 3400MM	TATA spare parts
281654100238	BATT CABLE -VE 70SQMM LENGTH 3000MM	TATA spare parts
281654100282	BATTERY LINK	TATA spare parts
281654100286	ASSY.MEGA FUSE MTG BRKT.	TATA spare parts
281654100313	BATTERY CABLE POSITIVE TO MF I/P	TATA spare parts
281654100314	BATTERY CABLE NEGATIVE	TATA spare parts
281654100315	BATTERY CABLE POSITIVE MF O/P TO SM	TATA spare parts
281654100330	BATTERY CABLE NEGATIVE	TATA spare parts
281654100332	BATTERY CABLE POSITIVE MF O/P TO SM	TATA spare parts
281654100340	BATTERY CABLE POSITIVE	TATA spare parts
281654100341	BATTERY CABLE POSITIVE MF O/P TO SM	TATA spare parts
281654100342	BATTERY CABLE NEGATIVE	TATA spare parts
281654100345	BATTERY CABLE POSITIVE TO MF I/P	TATA spare parts
281654100346	BATTERY CABLE NEGATIVE	TATA spare parts
281654100347	BATTERY CABLE POSITIVE MF TO SM	TATA spare parts

281654100348	BATTERY CABLE LINK	TATA spare parts
281654100351	CABLE ASSY BATTERY +VE	TATA spare parts
281654100352	CABLE BATTERY-VE	TATA spare parts
281654101675	BATTERY CABLE POSITIBE MF O/P TO SM	TATA spare parts
281654101676	BATTERY CABLE NEGATIVE	TATA spare parts
281654101678	BATTERY CABLE NEGATIVE	TATA spare parts
281654106305	COVER BATTERY	TATA spare parts
281654106305AE	BATTERY COVER FOR LPTA5252 1628	TATA spare parts
281654106306	BATTERY TRAY ( PLASTIC)	TATA spare parts
281654106307	DRAIN PIPE BATTERY TRAY	TATA spare parts
281654106308	SPACER BATTERY	TATA spare parts
281654106310	COVER AUX. FUSE BOX & BATTERY CUT OFF	TATA spare parts
281654106315	MEGA FUSE COVER	TATA spare parts
281654107706	BATTREY CABLE GROMMET	TATA spare parts
281654107707	STOPPER RUBBER FOR BATTERY (Y-DIRECTION)	TATA spare parts
281654107708	STOPPER RUBBER FOR BATTERY (Z-DIRECTION)	TATA spare parts
281654107711	BATT CABLE GROMMET OVAL SHAPE LPK2528 BS	TATA spare parts
281654107713	STOPPER RUBBER FOR BATTERY (Z-DIRECTION)	TATA spare parts
281654108239	CHANNEL BATTERY CLAMPING	TATA spare parts
281654108280	CLAMP BATTERY TOP	TATA spare parts
281654109901	TENSION ROD	TATA spare parts
281654109924	SPACER BATTERY MOUNTING	TATA spare parts
281654110121	ASSY COPPER BATTERY CABLE +VE(95SQ MM)/I	TATA spare parts
281654110122	ASSY BATTERY CABLE NEGATIVE(95SQ MM) 253	TATA spare parts
281654110129	POSITIVE BATTERY CABLE LPK3123	TATA spare parts
281654110130	NEGATIVE BAT. CABLE LPK/3123/	TATA spare parts
281654200023	WIRING HARNESS CONTROL PANEL	TATA spare parts
281654200102	INSTRUMENT CLUSTER	TATA spare parts
281654200108	BODY CONTROL MODULE L1 (RB)	TATA spare parts
281654200109	BODY CONTROL MODULE L2	TATA spare parts
281654200112	INSTRUMENT CLUSTER MIDLINE BS3/4	TATA spare parts
281654200113	INSTRUMENT CLUSTER BASELINE	TATA spare parts
281654200120	ASSY ECU MTG TRAY LOWER (POS. 4)	TATA spare parts
281654200121	ASSY ECU MTG TRAY CTR (POS. 2 & 3)	TATA spare parts
281654200122	ASSY ECU MTG TRAY SIDE (FOR ABS)	TATA spare parts
281654200126	ASSY. PUMP FOR CAB TILT BS3/4	TATA spare parts
281654200127	ASSY BRKT HORN MOUNTING	TATA spare parts
281654200133	ASSY BRKT HORN MOUNTING	TATA spare parts
281654200138	ELECTRONIC CONTROL MODULE ABS WITHOUT T	TATA spare parts
281654200146	INSTRUMENT CLUSTER (M0)	TATA spare parts
281654200148	INSTRUMENT CLUSTER LPS4021	TATA spare parts
281654200149	INSTRUMENT CLUSTER ASSY	TATA spare parts
281654200150	INSTRUMENT CLUSTER LPS4921	TATA spare parts
281654200160	ELECTRONIC CONTROL MODULE_ABS	TATA spare parts
281654200172	INSTRUMENT CLUSTER	TATA spare parts
281654200176	INSTRUMENT CLUSTER RA RATIO(5.58)	TATA spare parts
281654200177	INSTRUMENT CLUSTER WITH RA RATIO(5.58)	TATA spare parts

281654200185	INST CLUSTER 4928.S LX SRT109 11R20	TATA spare parts
281654200194	INSTRUMENT CLUSTER ASSY	TATA spare parts
281654200195	INSTRUMENT CLUSTER ASSY	TATA spare parts
281654200198	INST CLUSTER 4028.S LX	TATA spare parts
281654200203	INSTRUMENT CLUSTER	TATA spare parts
281654200204	INSTRUMENT CLUSTER	TATA spare parts
281654200206	INSTRUMENT CLUSTER ASSY BS6	TATA spare parts
281654206301	ECU MOUNTING MODULE	TATA spare parts
281654206302	ECU MOUNTING TRAY	TATA spare parts
281654206303	DUMMY AUTO LIGHT SENSOR	TATA spare parts
281654206304	HOLE COVER-1DIN ROOF	TATA spare parts
281654206305	HOLDER-DUMMY AUTO LIGHT SENSOR	TATA spare parts
281654208201	TRAY BCM MTG	TATA spare parts
281654208209	BRKT AIR PRESSURE SENSOR MTG ON FIRE WAL	TATA spare parts
281654208213	BRKT AIR PRESSURE SENSOR MTG ON FIRE WAL	TATA spare parts
281654209901	ELECTRONIC CONTROL UNITç 24V ABS6X	TATA spare parts
281654209905	RFID TAG	TATA spare parts
281654209918	AIR PRESSURE SENSOR BS3/4	TATA spare parts
281654209919	FUEL SENDER	TATA spare parts
281654209922	ADVANCED TELEMATICS CONTROL UNIT - CDMA	TATA spare parts
281654209923	ADVANCED TELEMATICS CONTROL UNIT - GSM W	TATA spare parts
281654209924	ASSY FUEL SENDOR INTEGRATED ENGINE	TATA spare parts
281654209930	ASSY FUEL SENDOR INTEGRATED ISLE ENGINE	TATA spare parts
281654209942	BODY CONTROL MODULE (HIGH + OPTION)	TATA spare parts
281654209943	BODY CONTROL MODULE RB (HIGH + OPTION)	TATA spare parts
281654209944	HORN DISC TYPE HIGH TONE 24V	TATA spare parts
281654209945	HORN DISC TYPE LOW TONE 24V	TATA spare parts
281654209947	24V 10A MICRO NOR RELAYç SEALED	TATA spare parts
281654209948	MINI RELAY_24V_1NO_20A	TATA spare parts
281654209952	DC DC CONVERTER	TATA spare parts
281654209953	STEER. ADJ.CONTROLLER	TATA spare parts
281654209954	WIPER CONTROLER	TATA spare parts
281654209968	HORN ELECTRONIC TYPE L.T 24V	TATA spare parts
281654209969	HORN ELECTRONIC TYPE H.T 24V	TATA spare parts
281654209974	L.T.HORN WITH VENT HOLE 24V BS4	TATA spare parts
281654209975	H.T.HORN WITH VENT HOLE 24V	TATA spare parts
281654209980	AXCU DIRECT DRIVE_2H_20KMPH	TATA spare parts
281654209981	AXCU OVERDRIVE_2H_25KMPH	TATA spare parts
281654209994	CONTROLLER STG WHEEL ADJUSTMENT	TATA spare parts
281654210115	INSTRUMENT CLUSTER ASSY	TATA spare parts
281654210125	ECU ABS 8 4S/4M 4S/3M 24V BS3/4	TATA spare parts
281654303302	BRACKET ASSY HORN MTG	TATA spare parts
281654309903	CAP FOR POWER SOCKET	TATA spare parts
281654400116	BULB HOLDER WITH BULB FOR DOOR LAMPS	TATA spare parts
281654400120	ASSY. LAMP LARGE ROOM	TATA spare parts
281654400121	LAMP ASSY BED SIDE READING	TATA spare parts
281654400122	LAMP ASSY WORKING	TATA spare parts

281654400123	LAMP ASSY TAIL LH	TATA spare parts
281654400124	LAMP ASSY TAIL RH	TATA spare parts
281654400125	BULB HOLDER WITH BULB	TATA spare parts
281654400126	LAMP A DIRTY STORAGE	TATA spare parts
281654400130	LAMP ASSY FRONT END OUTLINE MARKER	TATA spare parts
281654400131	LAMP ASSY FRONT END OUTLINE MARKER	TATA spare parts
281654400136	LAMP SIDE MARKER WITH PASSIVE REFLECTOR	TATA spare parts
281654400139	LAMP ASSY FOCUS	TATA spare parts
281654400142	LAMP ASSY BED SIDE READING LAMP	TATA spare parts
281654400144	LAMP DIRECTION INDICATOR LH	TATA spare parts
281654400145	LAMP DIRECTION INDICATOR RH	TATA spare parts
281654400146	ASSY. HEAD LAMP LH RHD BS3/4	TATA spare parts
281654400147	ASSY. HEAD LAMP RH RHD BS3/4	TATA spare parts
281654400150	FRONT RETRO REFLECTOR LH	TATA spare parts
281654400151	FRONT RETRO REFLECTOR RH	TATA spare parts
281654400152	LAMP ASSY FOG CARGO LH	TATA spare parts
281654400153	LAMP ASSY FOG CARGO RH	TATA spare parts
281654400155	LAMP ASSY HEAD LHD LH	TATA spare parts
281654400156	LAMP ASSY HEAD LHD RH	TATA spare parts
281654400157	BRKT ASSY TAIL LAMP MTG MAIN LH	TATA spare parts
281654400158	BRKT ASSY TAIL LAMP MTG MAIN RH	TATA spare parts
281654400159	BRKT ASSY LICENSE PLATE MTG RHD	TATA spare parts
281654400162	LAMP ASSY LICENCE PLATE BIG	TATA spare parts
281654400169	LAMP ASSY WORK AREA	TATA spare parts
281654400183	ASSY BRKT TAIL LAMP LH (LPK 3138)	TATA spare parts
281654400184	ASSY BRKT TAIL LAMP RH (LPK 3138)	TATA spare parts
281654400188	LAMP ASSY SIDE MARKER	TATA spare parts
281654400190	ASSY BRKT-TAIL LAMP MTG LH	TATA spare parts
281654400191	ASSY BRKT-TAIL LAMP MTG RH	TATA spare parts
281654400192	ASSY WORK AREA LAMP-2 BASE PLATE	TATA spare parts
281654400194	ASSY. TAIL LAMP BRKT LH	TATA spare parts
281654400195	ASSY. TAIL LAMP BRKT RH	TATA spare parts
281654400210	ASSY BRKT TAIL LAMP LH PRIMA LPT MO	TATA spare parts
281654400211	ASSY BRKT TAIL LAMP RH PRIMA MO LPT MOD	TATA spare parts
281654400212	ASSY BRKT TAIL LAMP MTG LPK LH	TATA spare parts
281654400213	ASSY BRKT TAIL LAMP MTG LPK RH	TATA spare parts
281654400216	ASSY TAIL LAMP MTG-LH	TATA spare parts
281654400217	ASSY BRKT-TAIL LAMP MTG RH	TATA spare parts
281654400233	ASSY TAIL LAMP MTG BKT FOR 6 CHAMB WITHO	TATA spare parts
281654400235	ASSY TAIL LAMP MTG BKT FOR 4 5 & 6	TATA spare parts
281654400236	ASSY TAIL LAMP MTG BRACKET FOR 4 5 & 6 C	TATA spare parts
281654400237	ASSY TAIL LAMP MTG BRACKET FOR 4 5 & 6	TATA spare parts
281654400252	LAMP ASSY FOG+DRL 24V	TATA spare parts
281654403311	BRACKET SIDE MARKER LAMP MTG BS6	TATA spare parts
281654406305	LAMP LENS DOOR AJAR LH	TATA spare parts
281654406306	LAMP LENS DOOR AJAR RH	TATA spare parts
281654406307	LAMP LENS STEP ILLUMINATION LH	TATA spare parts

281654406308	LAMP LENS STEP ILLUMINATION RH	TATA spare parts
281654406315	DUMMY FOCUS LAMP CUTOFF COVER	TATA spare parts
281654406316	BACK COVER HEADLAMP LH	TATA spare parts
281654406317	BACK COVER HEADLAMP RH	TATA spare parts
281654407706	GASKET-FRONT END OUTLINE MARKER LAMP LH	TATA spare parts
281654407707	GASKET-FRONT END OUTLINE MARKER LAMP RH	TATA spare parts
281654407708	GASKET (FOAM)-FRONT END OUTLINE MARKER	TATA spare parts
281654407709	GASKET (FOAM)-FRONT END OUTLINE MARKER	TATA spare parts
281654407710	GASKET SIDE INDICATOR LAMP	TATA spare parts
281654407712	PLASTIC SEAL FOR HEAD LAMP LEVELING HOLE	TATA spare parts
281654407713	ADDON FRONT RETRO REFLECTOR	TATA spare parts
281654408207	BRKT TAIL LAMP MTG ADD ON	TATA spare parts
281654408208	BRKT SIDE MARKER LAMP REAR LH	TATA spare parts
281654408209	BRKT SIDE MARKER LAMP REAR RH	TATA spare parts
281654408220	BRKT WORK AREA LAMP MTG	TATA spare parts
281654408229	BRKT WORK AREA LAMP MTG (LPK)	TATA spare parts
281654408255	BRKT FRONT RETRO REFLECTOR MTG LH (LPK)	TATA spare parts
281654408256	BRKT FRONT RETRO REFLECTOR MTG RH (LPK)	TATA spare parts
281654408257	BRKT LICENSE PLATE MTG ADDON LPK	TATA spare parts
281654408264	BRACKET DIRECTION INDICATOR LAMP MTG LH	TATA spare parts
281654408265	BRACKET DIRECTION INDICATOR LAMP MTG RH	TATA spare parts
281654408271	BRKT FOR FRONT SIDE MARKER LAMP MTG LH	TATA spare parts
281654408272	BRKT FRONT SIDE MARKER LAMP MTG RH	TATA spare parts
281654408284	BRKT SIDE REPEATER MTG LH	TATA spare parts
281654408285	BRKT SIDE REPEATER MTG RH	TATA spare parts
281654408294	BRKT FOR FRONT SIDE MARKER LAMP MTG LH	TATA spare parts
281654408295	BRKT FOR FRONT SIDE MARKER LAMP MTG RH	TATA spare parts
281654408298	ENGINE LAMP MTG BKT FOR LPK	TATA spare parts
281654408601	SPACER WORK AREA LAMP LPK	TATA spare parts
281654409904	FRONT RETRO REFLECTOR LH	TATA spare parts
281654409905	FRONT RETRO REFLECTOR RH	TATA spare parts
281654409906	BULB HI-BEAM H1 24V 70W	TATA spare parts
281654409907	BULB LOW BEAM H7 24V 70W	TATA spare parts
281654409908	SIDE FIRST RETRO REFLECTOR AMBER	TATA spare parts
281654409910	ASSY REFLEX REFLECTOR (WHITE)	TATA spare parts
281654409935	BULB R10W-24V	TATA spare parts
281654409936	BULB P21W - 24V	TATA spare parts
281654409937	BULB W5W - 24V	TATA spare parts
281654409938	BULB PY21W - 24V	TATA spare parts
281654409939	BULB H1 70W - 24V	TATA spare parts
281654409940	BULB H7 70W - 24V	TATA spare parts
281654409941	BULB H3 70W - 24V	TATA spare parts
281654410123	ROOF LAMP ASSY	TATA spare parts
281654410127	LAMP ASSY REGISTRATION PLATE	TATA spare parts
281654500103	SWITCH ASSY STEERING LOCK CUM IGNITION	TATA spare parts
281654500104	STEERING LOCK CUM IGNITION SWITCH BS4	TATA spare parts
281654500104AE	SW ASSY STEERING LOCK CUM -1628	TATA spare parts

281654500105	SWITCH STEERING WHEEL PAD LH MFD	TATA spare parts
281654500106	SWITCH STEERING WHEEL PAD RH RADIO	TATA spare parts
281654500111	SWITCH ASSY FACIA PACK OF THREE FOR GPS	TATA spare parts
281654500112	SWITCH ASSY FACIA PACK OF THREE UPPER	TATA spare parts
281654500117	BUNK CONTROL PANEL	TATA spare parts
281654500123	SWITCH ASSY FACIA PACK OF THREE CENTRE	TATA spare parts
281654500124	SWITCH ASSY FACIA PACK OF THREE LOWER	TATA spare parts
281654500125	SWITCH ASSY FACIA PACK OF THREE DUMMY	TATA spare parts
281654500126	ASSY FUSE & RELAY BOX	TATA spare parts
281654500127	SWITCH ASSY COMBINATION WITH 2 POS. ENG	TATA spare parts
281654500129	SWITCH ASSY COMBINATION WITH 3 POS. ENG	TATA spare parts
281654500134	ASSY BKT FOR STARTER RELAY MOUNTING	TATA spare parts
281654500150	ASSY COMBINATION SWITCH	TATA spare parts
281654504902	SWITCH EMERGENCY HELP	TATA spare parts
281654504905	SWITCH FAN RH	TATA spare parts
281654504906	SWITCH FAN LH	TATA spare parts
281654506307	CARRIER PLATE FACIA SWITCH	TATA spare parts
281654509904	SWITCH HEAD LAMP ROTARY	TATA spare parts
281654509905	SWITCH HEAD LAMP ROTARY	TATA spare parts
281654509912	SWITCH HAZARD WARNING	TATA spare parts
281654509913	SWITCH INSTRUMENT CLUSTER DIMMING	TATA spare parts
281654509914	SWITCH HEAD LAMP LEVELING	TATA spare parts
281654509915	SWITCH CAB TILT ENABLE	TATA spare parts
281654509916	SWITCH ENGINE DIAGNOSIS	TATA spare parts
281654509917	SWITCH ATC DIAGNOSIS	TATA spare parts
281654509918	SWITCH POWER TAKE OFF (PTO)	TATA spare parts
281654509919	SWITCH DUMMY AXLE DOWN	TATA spare parts
281654509920	SWITCH PINTLE HOOK	TATA spare parts
281654509921	SWITCH ELECTRIC MIRROR HEATING	TATA spare parts
281654509922	SWITCH FACIA DUMMY RH	TATA spare parts
281654509929	BEZEL DUMMY WINDOW WINDING LH	TATA spare parts
281654509930	BEZEL DUMMY WONDOW WINDING RH	TATA spare parts
281654509939	CLOCK SPRING WITHOUT AIR BAG	TATA spare parts
281654509941	CLUTCH SWITCH	TATA spare parts
281654509942	BRAKE SWITCH	TATA spare parts
281654509946	SWITCH AUTO LUBRICATION	TATA spare parts
281654509949	SWITCH WINDOW WINDER DRIVER	TATA spare parts
281654509950	SWITCH WINDOW WINDER ASSIST	TATA spare parts
281654509951	SWITCH WINDOW WINDER DRIVER LHD	TATA spare parts
281654509952	SWITCH WINDOW WINDER ASSIST LHD	TATA spare parts
281654509953	SWITCH WINDOW WINDER W/O ELEC MIRROR D	TATA spare parts
281654509957	SWITCH FACIA TRAILER ABS ECU	TATA spare parts
281654509960	SWITCH WORK AREA LAMP 2	TATA spare parts
281654509961	SWITCH DUMMY HEAD LAMP WASH	TATA spare parts
281654509962	SWITCH DUMMY HAZARD WARNING	TATA spare parts
281654509965	CLOCK SPRING WITHOUT AIR BAG BS6	TATA spare parts
281654509971	BATTERY CUTOFF SWITCH	TATA spare parts



281654509979	SWITCH STEERING WHEEL ADJUSTMENT	TATA spare parts
281654509980	SWITCH DIFF. LOCK L/R	TATA spare parts
281654509981	SWITCH MICROPHONE	TATA spare parts
281654509982	SWITCH DIFF. LOCK F/R	TATA spare parts
281654509986	SWITCH ABS DIAGNOSTIC	TATA spare parts
281654509989	SWITCH LARGE ROOM LAMP	TATA spare parts
281654509990	SWITCH WORK AREA LAMP	TATA spare parts
281654509991	SWITCH FOCUS LAMP RH	TATA spare parts
281654509992	SWITCH FOCUS LAMP LH	TATA spare parts
281654509993	SWITCH FACIA DUMMY LH	TATA spare parts
281654509994	SWITCH FACIA DOMMY CNTR	TATA spare parts
281654509995	SWITCH FACIA DUMMY RH	TATA spare parts
281654509997	COINBOX	TATA spare parts
281654600101	PIG TAIL ABS	TATA spare parts
281654600102	PIG TAIL ABS	TATA spare parts
281654600109	ASSY BULK HEAD BODY	TATA spare parts
281654600110	ASSY BULK HEAD COVER	TATA spare parts
281654600130	BULK HEAD ASSY	TATA spare parts
281654600131	ASSY. HORN MOUNTING BRACKET	TATA spare parts
281654600136	ASSY ASH TRAY LED	TATA spare parts
281654600146	ASSY OF T BKT FOR AUXILLIARY FUSE BOX	TATA spare parts
281654600176	ASSY.OF BRACKET FOR WIRING HARNESS BUNDL	TATA spare parts
281654600178	ASSY PLATE FOR ECU MTG (M0)	TATA spare parts
281654600179	ASSY PLATE FOR FRAME DASH W/H INTERCONN	TATA spare parts
281654600182	PIG TAIL ABS	TATA spare parts
281654600183	ASSY PLATE FOR FRAME DASH W/H INTERCONN.	TATA spare parts
281654600187	ASSY.T BRKT FOR CONNECTOR PARKING	TATA spare parts
281654600295	PLATE ASSY FRAME DASH W/H INTERCONN MTG	TATA spare parts
281654601601	DASHBOARD WIRING HARNESS	TATA spare parts
281654601602	FRAME WIREING HARNESS	TATA spare parts
281654601603	TAIL WIRING HARNESS LPS 4028	TATA spare parts
281654601604	HEAD BOX WIRING HARNESS	TATA spare parts
281654601605	ROOF WIRING HARNESS	TATA spare parts
281654601606	WIPER MOTOR WIRIN HARNESS	TATA spare parts
281654601608	STARTER MOTOR WIRING HARNESS	TATA spare parts
281654601609	DOOR LH WIRING HARNESS	TATA spare parts
281654601610	DOOR (RH) WIRING HARNESS	TATA spare parts
281654601614	WIRING HARNESS ABS LPS4935	TATA spare parts
281654601615	WIRING_HARNESS_ABS_LPS4027	TATA spare parts
281654601616	WIRING HARNESS DASH L2	TATA spare parts
281654601621	AUXILIARY FUSE BOX WIRING HARNESS	TATA spare parts
281654601623	WIRING HARNESS TAIL	TATA spare parts
281654601624	WIRING HARNESS FRAME ABS LPK 3138	TATA spare parts
281654601625	WIRING HARNESS FRAME ABS LPS 4027	TATA spare parts
281654601632	PIG TAIL Y-TYPE STRG WHEEL SWITCH&CLOCK	TATA spare parts
281654601634	WIRING HARNESS DASH LEVEL L1	TATA spare parts
281654601637	WIRING HARNESS HEADBOX LEVEL1	TATA spare parts

281654601638	WIRING HARNESS ROOF LEVEL1	TATA spare parts
281654601639	WIRING HARNESS TAIL	TATA spare parts
281654601640	WIRING HARNESS DOOR (LH) LEVEL1	TATA spare parts
281654601641	WIRING HARNESS DOOR (RH) LEVEL1	TATA spare parts
281654601644	WIRING HARNESS FRAME LPS4038 (L2) LHD	TATA spare parts
281654601649	WIRING HARNESS ROOF	TATA spare parts
281654601654	WIRING HARNESS TAIL	TATA spare parts
281654601657	WIRING HARNESS FOR GEAR BOX	TATA spare parts
281654601661	WIRING HARNESS DASH L1	TATA spare parts
281654601662	WIRING HARNESS DASH L2	TATA spare parts
281654601664	WIRING HARNESS PIGTAIL GEAR BOX LHD VEH	TATA spare parts
281654601665	WIRING HARNESS PIGTAIL FOR EATON GEAR BO	TATA spare parts
281654601667	PIGTAIL FOR STATER MOTOR SOLENOID	TATA spare parts
281654601668	FLOOR CONSOLE WIRING HARNESS	TATA spare parts
281654601669	SOCKET PIGTAIL (TRAILER LIGHTING)	TATA spare parts
281654601670	SOCKET PIGTAIL (TRAILER ABS )	TATA spare parts
281654601671	WIRING HARNESS_FRAME_ISBE_LPK3128_L1	TATA spare parts
281654601673	JUMPER CABLE (LIGHTING CONNECTIONS)	TATA spare parts
281654601674	JUMPER CABLE (ABS CONNECTIONS)	TATA spare parts
281654601686	WIRING HARNESS FRAME (ABS)	TATA spare parts
281654601689	WIRING HARNESS TAIL	TATA spare parts
281654601690	WIRING HARNESS FRAME (ABS)	TATA spare parts
281654601694	WIRING HARNESS_WIPER_LHD	TATA spare parts
281654601698	WIRING HARNESS FRAME (ABS) FOR LPS 4038_	TATA spare parts
281654601699	WIRING HARNESS FRAME (ABS)	TATA spare parts
281654603302	BRACKET INTERFACE CONNECTOR MTG	TATA spare parts
281654603321	BRACKET INTERFACE CONNECTOR MTG	TATA spare parts
281654606302	OUTER COVER BULK HEAD	TATA spare parts
281654606303	GUIDE PLATE BULK HEAD	TATA spare parts
281654606312	BULK HEAD BODY	TATA spare parts
281654607501	RUBBER GROMMET BS6	TATA spare parts
281654607705	A PILLER GROMMET	TATA spare parts
281654607708	TAIL LAMP GROMMET RH	TATA spare parts
281654607711	BULK HEAD TO FRAME GROMMET BS6	TATA spare parts
281654607714	GROMMET 100MM FOR TAIL WIRING HARNESS.	TATA spare parts
281654607715	GROMMET-BULK HEAD BS6	TATA spare parts
281654607717	BULK HEAD PLATE SEAL	TATA spare parts
281654607721	GROMMET DIA 45	TATA spare parts
281654607722	GROMMET DIA 40	TATA spare parts
281654607723	GROMMET FOR SWITCH CUTOUT	TATA spare parts
281654607726	SEAL FOR BULK HEAD PLATE	TATA spare parts
281654608203	BRKT AMBIENT SENSOR MTGBS6	TATA spare parts
281654608204	BRKT FOR HARNESS MTG ON CHASSIS TYPE C	TATA spare parts
281654608205	BRKT FOR HARNESS MTG ON CHASSIS TYPE B	TATA spare parts
281654608206	BRKT FOR HARNESS MOUNTING TYPE D	TATA spare parts
281654608210	BRACKET FOR HARNESS MOUNTING ON THIRD CR	TATA spare parts
281654608211	HARNESS MOUNTING BRACKET-Z SHAPE(WITH 1	TATA spare parts

281654608212	HARNESS MOUNTING BRACKET-Z SHAPE	TATA spare parts
281654608213	METAL CLAMP HARNESS MTG W/PLASTIC COATING	TATA spare parts
281654608214	P SHAPE METAL CLAMP FOR HARNESS CLAMPING	TATA spare parts
281654608215	WIRING HARNESS CLAMP P TYPE(DIA 33 )	TATA spare parts
281654608216	WIRING HARNESS CLAMP; P TYPE (DIA 16 )	TATA spare parts
281654608220	BRACKET FOR HARNESS MOUNTING ON DASH C	TATA spare parts
281654608221	BRACKET FOR PARKING INTERCONNECTION CONN	TATA spare parts
281654608222	BRACKET FOR VSS CONNECTOR PARKING	TATA spare parts
281654608223	C SHAPE BRACKET FOR HARNESS MOUNTING	TATA spare parts
281654608223AE	C SHPE BKT HRNSS MNTNG FRME-1628	TATA spare parts
281654608224	BRKT CAB TILT AREA WIRE MTG	TATA spare parts
281654608225	BRKT FOR JUMBER CABLE	TATA spare parts
281654608232	BRKT FOR HARNESS MTG ON GB	TATA spare parts
281654608235	L BRACKET WITH SLOTS	TATA spare parts
281654608236	HARNESS MOUNTING BRACKET-Z SHAPE	TATA spare parts
281654608254	BRACKET FOR BEEPER MTG	TATA spare parts
281654608255	L BRACKET WITH FLANGE	TATA spare parts
281654608257	BRKT FOR HORN MTG ON BUMPER C TYPE	TATA spare parts
281654608258	BRKT FOR HARNESS MTG TYPE L	TATA spare parts
281654608259	BUMPER WH BRKT TYPE C	TATA spare parts
281654608262	BRKT FOR 2 CONN MTG	TATA spare parts
281654608263	Z SHAPE BRKT	TATA spare parts
281654608264	C SHAPE BRKT	TATA spare parts
281654608265	Z SHAPE BRKT	TATA spare parts
281654608267	BRKT FOR WH CLAMPING ON FIREWALL	TATA spare parts
281654609902	DUMMY JUMPER CABLE SOCKET (ABS)	TATA spare parts
281654609903	DUMMY JUMPER CABLE SOCKET (LIGHTING)	TATA spare parts
281654609904	CLAMP HARNESS MTG WITH INSERT	TATA spare parts
281654609908	DUMMY JUMPER CABLE SOCKET	TATA spare parts
281654609911	AM/FM CABLE 1 MUSIC SYSTEM---A PILLAR	TATA spare parts
281654609912	AM/FM CABLE 2 A PILLAR---ANTENNA	TATA spare parts
281654609914	BULK HEAD SMALL FOAM BS6	TATA spare parts
281654609916	PIGTAIL WASHER KIT BS6	TATA spare parts
281654609917	EDGE CLIP (M/S A RAYMOND)	TATA spare parts
281654609919	ANTENNA CUTOUT GROMMET	TATA spare parts
281654609920	BOTTOM PLATE ANTENNA GROMMET	TATA spare parts
281654609921	JUMPER CABLE CONNECTIONS	TATA spare parts
281654609928	SOCKET WITH PIG 7PIN 24V N TYPE	TATA spare parts
281654609930	ASSY JUMPER CABLE (LIGHTING)	TATA spare parts
281654609931	DUMMY JUMPER CABLE SOCKET (LIGHTING)	TATA spare parts
281654609932	SOCKET PIGTAIL (TRAILER ABS)	TATA spare parts
281654609933	ASSY JUMPER CABLE(ABS)	TATA spare parts
281654609934	DUMMY JUMPER CABLE SOCKET (ABS)	TATA spare parts
281654609939	GASKET FOR ANTENNA CUTOUT	TATA spare parts
281654609947	CABIN FUSE & RELAY BOX STICKER.	TATA spare parts
281654609974	STICKER FUSE BOX BS6	TATA spare parts
281654609975	STICKER CABIN FUSE & RELAY BOX BS6	TATA spare parts

281654609978	STICKER MEGA FUSE BOX BS6-PH2	TATA spare parts
281654609984	STICKER-CABIN FUSE & RELAY BOX BS6	TATA spare parts
281654610119	WIRING HARNESS DASHBOARD	TATA spare parts
281654610168	WIRING HARNESS ABS FRAME	TATA spare parts
281654610169	PIGTAIL ABS WIRING HARNESS	TATA spare parts
281654610171	PIGTAIL ABS WIRING HARNESS	TATA spare parts
281654610189	WIRING HARNESS ABS FRAME	TATA spare parts
281654610195	W/H FRAME WITH AC	TATA spare parts
281654611603	WIRING HARNESS DASH LPS4038(L2) LHD	TATA spare parts
281654611604	WIRING HARNESS TAIL LPS4038 LHD L2	TATA spare parts
281654611616	WIRNG HARNESS ROOF_LHD_L2	TATA spare parts
281654611621	SOCKET WITH PIGTAIL(TRAILER AUXILLARY LI	TATA spare parts
281654611622	JUMPER CABLE (LIGHTING CONNECTIONS)	TATA spare parts
281654611633	WIRING HARNESS ENGINE	TATA spare parts
281654611660	W/H TAIL LPK 2528 45WB LHD	TATA spare parts
281654611662	FRAME WIRING HARNESS	TATA spare parts
281654611663	ENGINE W/H ISLE FOR LPS 4938 VEHICLE	TATA spare parts
281654611664	W/H ENGINE ISLE FOR LPK VEHICLE	TATA spare parts
281654611665	FRAME W/H HARNESS FOR LPK 3138 ISLE	TATA spare parts
281654611666	ENGINE WIRING HARNESS FOR LPS 4038 LHD I	TATA spare parts
281654611667	WIRING HARNESS FRAME FOR LPK2528/45/LHD/	TATA spare parts
281654611668	W/H ENGINE	TATA spare parts
281654611669	WIRING HARNESS ENGINE (ISBE)	TATA spare parts
281654611673	FRAME WIRING HARNESS	TATA spare parts
281654611674	WIRING HARNESS ENGINE	TATA spare parts
281654611675	ABS FRAME W/H (KB) FOR LPK 2528 (LHD) -	TATA spare parts
281654611691	DOOR WH LHD_LH	TATA spare parts
281654611692	WIRING HANRESS DOOR_RH_LHD	TATA spare parts
281654611693	WIRING HARNESS TAIL LPK 3138 & 3128	TATA spare parts
281654611694	TAIL WIRING HARNESS FOR LPK 2528_39WB	TATA spare parts
281654620112	WIRING HARNESS SIDE REPEATER	TATA spare parts
281654620137	W/H MEGAFUSE BOX	TATA spare parts
281654620144	WIRING HARNESS FRAME	TATA spare parts
281654620146	WIRING HARNESS MEGA FUSE	TATA spare parts
281654620149	WIRING HARNESS TAIL	TATA spare parts
281654620156	WIRING HARNESS DASHBOARD	TATA spare parts
281654620176	WIRING HARNESS DASHBOARD	TATA spare parts
281654620182	W/H PIGTAIL FOR STARTER MOUNTED RELAY	TATA spare parts
281654620183	W/H PIGTAIL FOR EXHAUST BRAKE SOLENOID	TATA spare parts
281654620208	WIRING HARNESS FRAME	TATA spare parts
281654621602	WIRING HARNESS HEADBOX	TATA spare parts
281654621603	WIRING HARNESS GEARBOX	TATA spare parts
281654621609	WH TAIL	TATA spare parts
281654621610	WIRING HARNESS WIPER SYSTEM	TATA spare parts
281654621612	ABS WIRING HARNESS LPS 4021	TATA spare parts
281654621613	TAIL WIRING HARNESS LPS 4921	TATA spare parts
281654621614	WIRING HARNESS ABS FOR LPS 4921	TATA spare parts

281654621615	PIGTAIL SIDE REPEATER LAMP	TATA spare parts
281654621616	CAN CONVERTER PIGTAIL	TATA spare parts
281654621619	ENGINE WH	TATA spare parts
281654621620	DASH WH	TATA spare parts
281654621621	W/H FRAME	TATA spare parts
281654621622	AUXILARY WH	TATA spare parts
281654621626	WIRING HARNESS ABS	TATA spare parts
281654621628	W/H TAIL FOR LPK3123/52/M0	TATA spare parts
281654621629	W/H FRAME	TATA spare parts
281654621633	FRAME WH LPK 3138 ISLE LHD	TATA spare parts
281654621634	WH ENGINE ISLE FOR LPK 3138 LHD	TATA spare parts
281654621635	WIRING HARNESS FOR WT ABS6 3138 (45 WB)	TATA spare parts
281654621638	WH TAIL LPK3138 LHD	TATA spare parts
281654621639	WH ROOF LPK LHD (NON SLR)	TATA spare parts
281654621674	FRAME WH FOR LPS 4938 PULLER (L1)	TATA spare parts
281654621675	TAIL WH LPS 4938 PULLER (L1)	TATA spare parts
281654621679	WH DASH_ FOR FIELD M0 MODELS	TATA spare parts
281654630132	ASSY BULK HEAD BODY	TATA spare parts
281654630133	ASSY BULK HEAD COVER	TATA spare parts
281654630135	W/H FRAME	TATA spare parts
281654630142	WIRING HARNESS ABS FRAME	TATA spare parts
281654630145	WIRING HARNESS ABS FRAME	TATA spare parts
281654630178	WIRING HARNESS DOSING UNIT PIGTAIL	TATA spare parts
281654630187	WIRING HARNESS DASHBOARD	TATA spare parts
281654630193	WIRING HARNESS ENGINE	TATA spare parts
281654631602	WH TAIL FOR LPT 2521	TATA spare parts
281654631607	W/H GEAR BOX	TATA spare parts
281654631610	W/H FRAME	TATA spare parts
281654631611	W/H TAIL LPK-2523 VEHICLE	TATA spare parts
281654631620	FRAME WH FOR LPS 4023 WITH A/C	TATA spare parts
281654631621	ENGINE WH ISBE LPS 4023 WITH A/C	TATA spare parts
281654631622	W/H ENGINE	TATA spare parts
281654631624	W/H FRAME	TATA spare parts
281654631632	WH DASH FOR LPK M0 WITH DGMS REQ.	TATA spare parts
281654631633	W/H HEADBOX FOR M0 LPK WITH DGMS	TATA spare parts
281654631635	W/H ENGINE FOR 2523.K/39	TATA spare parts
281654631636	W/H ENGINE FOR 3123.K/52	TATA spare parts
281654631647	WH AUXILIARY FUSE BOX FOR M0	TATA spare parts
281654631660	WIRING HARNESS TAIL	TATA spare parts
281654631668	TAIL WIRING HARNESS 4928 WITH HRT AXLE	TATA spare parts
281654631669	WH FRAME_LPT3123_LCCR ENGINE_M0	TATA spare parts
281654631697	WIRING HARNESS TAIL	TATA spare parts
281654640101	WIRING HARNESS ABS FRAME	TATA spare parts
281654640107	WIRING HARNESS ABS FRAME	TATA spare parts
281654640114	W/H DASH PRIMA M0	TATA spare parts
281654640117	WIRING HARNESS ABS FRAME	TATA spare parts
281654640121	WIRING HARNESS ABS FRAME	TATA spare parts

281654640123	WIRING HARNESS DOSING UNIT	TATA spare parts
281654640125	WIRING HARNESS ABS FRAME	TATA spare parts
281654640137	WIRING HARNESS FRAME	TATA spare parts
281654640139	WIRING HARNESS TAIL	TATA spare parts
281654640162	WIRING HARNESS ABS FRAME 4S3M	TATA spare parts
281654640173	WIRING HARNESS ABS FRAME 4S3M	TATA spare parts
281654640197	WIRING HARNESS PIGTAIL WIF SENSOR	TATA spare parts
281654641616	FANOUT UNIT SHORT LINK	TATA spare parts
281654641624	W/H FRMAE FOR FIELD M0 MODELS	TATA spare parts
281654641626	W/H TAIL LPT 3123	TATA spare parts
281654641627	WIRING HARNESS TAIL LPT 3123 62WB	TATA spare parts
281654641633	PIG TAIL W/H AC PRESSURE SWITCH	TATA spare parts
281654641657	W/H ENGINE WITH AC_LCCR	TATA spare parts
281654641674	WIRING HARNESS TAIL	TATA spare parts
281654641677	WIRING HARNESS	TATA spare parts
281654641679	WIRING HARNESS ENGINE	TATA spare parts
281654650101	WIRING HARNESS DASHBOARD	TATA spare parts
281654650105	WIRING HARNESS HEAD BOX	TATA spare parts
281654650114	WIRING HARNESS FRAME	TATA spare parts
281654650127	WIRING HARNESS FRAME	TATA spare parts
281654650134	WIRING HARNESS ENGINE	TATA spare parts
281654650135	WIRING HARNESS FRAME	TATA spare parts
281654650138	WIRING HARNESS TAIL	TATA spare parts
281654650139	WIRING HARNESS TAIL	TATA spare parts
281654650140	WIRING HARNESS DOSING UNIT	TATA spare parts
281654650153	WIRING HARNESS FRAME	TATA spare parts
281654650154	EARTH STRAP	TATA spare parts
281654650164	WIRING HARNESS FRAME	TATA spare parts
281654650165	WIRING HARNESS ENGINE	TATA spare parts
281654650199	WIRING HARNESS PIGTAIL WORK AREA LAMP	TATA spare parts
281654651642	WIRING HARNESS GEAR BOX	TATA spare parts
281654651643	WIRING HARNESS TAIL	TATA spare parts
281654651645	WIRING HARNESS DASHBOARD	TATA spare parts
281654651669	WIRING HARNESS FRAME	TATA spare parts
281654651670	WIRING HARNESS ENGINE	TATA spare parts
281654660105	WIRING HARNESS AUXILIARY FUSE BOX	TATA spare parts
281654660106	WIRING HARNESS FRAME	TATA spare parts
281654660107	WIRING HARNESS ABS FRAME	TATA spare parts
281654660108	WIRING HARNESS ENGINE	TATA spare parts
281654660109	WIRING HARNESS DASHBOARD	TATA spare parts
281654660127	PLATE ASSY FRAME DASH W/H INTERCONN MTG	TATA spare parts
281654660131	WIRING HARNESS TAIL	TATA spare parts
281654660133	WIRING HARNESS DASHBOARD	TATA spare parts
281654660135	WIRING HARNESS FRAME	TATA spare parts
281654660136	WIRING HARNESS ABS FRAME	TATA spare parts
281654660139	WIRING HARNESS HEADBOX	TATA spare parts
281654660141	WIRING HARNESS ENGINE	TATA spare parts

281654660172	WIRING HARNESS GEAR BOX	TATA spare parts
281654660188	WIRING HARNESS FRAME	TATA spare parts
281654660199	WIRING HARNESS FRAME	TATA spare parts
281654661605	WIRING HARNESS GEAR BOX	TATA spare parts
281654661619	WIRING HARNESS ENGINE	TATA spare parts
281654661699	WIRING HARNESS TAIL	TATA spare parts
281654670106	WIRING HARNESS DASHBOARD	TATA spare parts
281654670111	WIRING HARNESS ABS FRAME	TATA spare parts
281654670144	WIRING HARNESS ABS FRAME	TATA spare parts
281654670156	CABLE MUSIC SYSTEM	TATA spare parts
281654670157	AM/FM CABLE 2 A-PILLER TO ANTENNA	TATA spare parts
281654670158	WIRING HARNESS GEAR BOX	TATA spare parts
281654670160	WIRING HARNESS TAIL	TATA spare parts
281654670165	BATTERY CABLE +VE	TATA spare parts
281654670180	WIRING HARNESS GEAR BOX	TATA spare parts
281654670183	BATTERY CABLE +VE MEGA FUSE O/P TO SM	TATA spare parts
281654670184	BATTERY CABLE +VE	TATA spare parts
281654670187	WIRING HARNESS ASSY DRIVER DOOR BS6-PH2	TATA spare parts
281654670188	WIRING HARNESS RPAS BS6	TATA spare parts
281654670189	WIRING HARNESS ABS FRAME BS6	TATA spare parts
281654670194	WIRING HARNESS GEAR BOX	TATA spare parts
281654670196	WIRING HARNESS FRAME	TATA spare parts
281654670198	WIRING HARNESS FLOOR CONSOLE BS6-PH2	TATA spare parts
281654670199	WIRING HARNESS HEAD BOX BS6-PH2	TATA spare parts
281654671601	WIRING HARNESS FRAME	TATA spare parts
281654671608	WIRING HARNESS DOSING UNIT	TATA spare parts
281654671609	WIRING HARNESS MAXI FUSE	TATA spare parts
281654671615	WIRING HARNESS DASHBOARD	TATA spare parts
281654671630	WIRING HARNESS FRAME	TATA spare parts
281654671635	BATTERY CABLE -VE	TATA spare parts
281654671636	BATTERY CABLE +VE MEGA FUSE O/P TO SM	TATA spare parts
281654680102	WIRING HARNESS TAIL	TATA spare parts
281654680103	WIRING HARNESS ABS FRAME	TATA spare parts
281654680105	WIRING HARNESS ABS PIGTAIL BS6	TATA spare parts
281654680108	WIRING HARNESS HEADBOX	TATA spare parts
281654680122	WIRING HARNESS ASSY CO-DR DOOR BS6-PH2	TATA spare parts
281654680126	WIRING HARNESS TAIL	TATA spare parts
281654680129	CABLE BATT TAP +VE TO MANUAL CUT OFF +VE	TATA spare parts
281654680135	WIRING HARNESS DASHBOARD	TATA spare parts
281654680138	WIRING HARNESS ENGINE	TATA spare parts
281654680140	WIRING HARNESS ABS FRAME 4S3M	TATA spare parts
281654680141	WIRING HARNESS ABS PIGTAIL	TATA spare parts
281654680142	WIRING HARNESS FRAME	TATA spare parts
281654680145	WIRING HARNESS TAIL	TATA spare parts
281654680148	BATTERY CABLE POSITIVE MF O/P TO SM	TATA spare parts
281654680151	WIRING HARNESS DOSING UNIT BS6	TATA spare parts
281654680152	WIRING HARNESS TAIL BS6	TATA spare parts

281654680153	BATTERY CABLE NEGATIVE	TATA spare parts
281654680155	WIRING HARNESS ABS FRAME	TATA spare parts
281654680161	W/H BATTERY CABLE CUT OFF SW TO MFIP	TATA spare parts
281654680166	BATTERY CABLE +VE MEGA FUSE O/P TO SM	TATA spare parts
281654680170	WIRING HARNESS ABS FRAME 4S3M	TATA spare parts
281654680177	CABLE BATT +VE TO MANUAL CUTOFF +VE BS6	TATA spare parts
281654680178	W/H BATTERY CABLE CUT OFF SW TO MFIP BS6	TATA spare parts
281654680179	WIRING HARNESS TAIL BS6	TATA spare parts
281654680180	WIRING HARNESS ABS FRAME BS6	TATA spare parts
281654680181	BATTERY CABLE -VE BS6	TATA spare parts
281654680182	BATTERY CABLE +VE MEGA FUSE O/P TO SM BS	TATA spare parts
281654680183	WIRING HARNESS DOSING UNIT BS6	TATA spare parts
281654680185	WIRING HARNESS TAIL	TATA spare parts
281654680189	WIRING HARNESS DOSING UNIT BS6	TATA spare parts
281654680197	WIRING HARNESS ENGINE	TATA spare parts
281654680199	WIRING HARNESS DASHBOARD	TATA spare parts
281654690103	WIRING HARNESS DOSING UNIT	TATA spare parts
281654690104	WIRING HARNESS DOOR RH	TATA spare parts
281654690105	WIRING HARNESS DOOR LH	TATA spare parts
281654690107	WIRING HARNESS DASHBOARD BS6	TATA spare parts
281654690108	WIRING HARNESS TAIL BS6	TATA spare parts
281654690115	WIRING HARNESS ABS FRAME BS6	TATA spare parts
281654690116	WIRING HARNESS TAIL BS6	TATA spare parts
281654690127	WIRING HARNESS WIPER BS6	TATA spare parts
281654690131	WIRING HARNESS ABS FRAME 4S3M	TATA spare parts
281654690133	WIRING HARNESS FRAME BS6	TATA spare parts
281654690135	WIRING HARNESS TAIL BS6	TATA spare parts
281654690140	WH PIGTAIL AIS140	TATA spare parts
281654690143	WIRING HARNESS ABS PIGTAIL BS6	TATA spare parts
281654690154	WIRING HARNESS DASHBOARD BS6	TATA spare parts
281654690157	WIRING HARNESS FRAME	TATA spare parts
281654690159	WIRING HARNESS ENGINE	TATA spare parts
281654690164	BRACKET MEGA FUSE MTG BS6	TATA spare parts
281654690165	BATTERY CABLE +VE	TATA spare parts
281654690167	WIRING HARNESS DOSING UNIT BS6	TATA spare parts
281654690168	BATTERY CABLE +VE MEGA FUSE O/P TO SM BS	TATA spare parts
281654690169	WIRING HARNESS FRAME BS6	TATA spare parts
281654690173	WIRING HARNESS ENGINE BS6	TATA spare parts
281654690181	PIGTAIL STARTER MTG RELAY WIRING HARNESS	TATA spare parts
281654690182	POWER CABLE ALTERNATOR TO STARTER MOTOR	TATA spare parts
281654690183	W/H BATTERY CABLE CUT OFF SW TO MFIP BS6	TATA spare parts
281654690189	WIRING HARNESS TAIL BS6	TATA spare parts
281654690193	BATTERY CABLE -VE BS6	TATA spare parts
281654690194	BATTERY CABLE +VE MEGA FUSE O/P TO SM BS	TATA spare parts
281654690197	PIGTAIL JUMPER CABLE LIGHTING BS6	TATA spare parts
281654700106	PIGTAIL JUMPER CABLE ABS BS6	TATA spare parts
281654800101	SPEAKER 5.25 WITH RAIN COVER	TATA spare parts



281654800102	SPEAKER 5.25 WITH RAIN COVER	TATA spare parts
281654800104	ASSY BRKT USB INTERFACE & RKE MTG	TATA spare parts
281654800107	MUSIC SYSTEM ASSY PRIMA	TATA spare parts
281654800110	BRACKET ASSY ECU MTG PLATE	TATA spare parts
281654800113	TCU WITH GLOBAL SIM CARD-IB	TATA spare parts
281654808202	BRKT USB INTERFACE MTG	TATA spare parts
281654809903	MUSIC SYSTEM DOUBLE DIN	TATA spare parts
281654809905	SPEAKER 5.25 REAR WALL MOUNTED	TATA spare parts
281654809906	TWEETER 2 ON DOOR	TATA spare parts
281654809908	USB INTERFACE FOR MUSIC SYSTEM	TATA spare parts
281654809910	ANTENNA ASSY FOR L2 (RB)	TATA spare parts
281654809915	ANTENNA ASSY SHORT ROD	TATA spare parts
281654809916	ANTENNA ASSY SHORT ROD L2	TATA spare parts
281654909909	ECU IMMOBILIZER	TATA spare parts
281654909910	ILLUMINATION RING CUM TRANSPONDER ANTEN	TATA spare parts
281654909912	IGNITION KEY WITHOUT TRANSPONDER	TATA spare parts
281654909912AE	IGNITION KEY W/TRANSPONDER-1628	TATA spare parts
281654909913	IGNITION KEY WITHOUT TRANSPONDER	TATA spare parts
281654909914	REMOTE KEYLESS ENTRY RECIEVER 433MHZ	TATA spare parts
281654909915	REMOTE KEYLESS ENTRY TRANSMITTER 433MHZ	TATA spare parts
281654909917	REMOTE KEYLESS ENTRY RECIEVER 315MHZ	TATA spare parts
281654909918	REMOTE KEYLESS ENTRY TRANSMITTER 315MHZ	TATA spare parts
281655100103	MASCOT	TATA spare parts
281655100105	MASCOT ASSY	TATA spare parts
281655100108	MASCOT	TATA spare parts
281655100109	MASCOT	TATA spare parts
281655100110	MASCOT	TATA spare parts
281655100111	MASCOT	TATA spare parts
281655100113	MASCOT	TATA spare parts
281655100114	MASCOT	TATA spare parts
281655100117	MASCOT	TATA spare parts
281655100123	MASCOTASSY	TATA spare parts
281655100126	MASCOT ASSY	TATA spare parts
281655100136	MASCOT	TATA spare parts
281655100142	MASCOT ASSY BS6	TATA spare parts
281655100143	MASCOT ASSY BS6	TATA spare parts
281655100144	MASCOT ASSY	TATA spare parts
281655100145	MASCOT ASSY BS6	TATA spare parts
281655100147	MASCOT ASSY BS6	TATA spare parts
281655100149	MASCOT ASSY BS6	TATA spare parts
281655100151	MASCOT ASSY	TATA spare parts
281655100155	STICKER	TATA spare parts
281655100157	MASCOT ASSY BS6	TATA spare parts
281655100158	MASCOT ASSY	TATA spare parts
281655100160	MASCOT ASSY	TATA spare parts
281655151603	STICKER	TATA spare parts
281655156301	STICKER BS6	TATA spare parts

281655156309	DECAL BS6-PH2	TATA spare parts
281660100101	ASSY CAB COMPLETE RHD(C_LOW ROOF)	TATA spare parts
281660100108	ASSY SIDE SKIN SLPR LOW WITH WINDOW LH	TATA spare parts
281660100109	ASSY SIDE SKIN SLPR LOW RH WITH WINDOW	TATA spare parts
281660100126	ASSY SIDE SKIN NON SLPR FLAT LH	TATA spare parts
281660100127	ASSY SIDE SKIN NON SLPR FLAT RH	TATA spare parts
281660100135	ASSY SIDE SKIN SLPR LOW WITHOUT WINDOW	TATA spare parts
281660100136	ASSY SIDE SKIN SLPR LOW WITHOUT WINDOW	TATA spare parts
281660100144	ASSY SIDE SKIN SLPR FLAT W/O WINDOW LH	TATA spare parts
281660100145	ASSY SIDE SKIN SLPR FLAT W/O WINDOW RH	TATA spare parts
281660100157	PRIMA C SLEEPER LOW RHD	TATA spare parts
281660100170	PRIMA C NON SLEEPER FLAT RHD	TATA spare parts
281660100188	ASSY BODY SHELL PAINTED SIDE AND REAR WI	TATA spare parts
281660100193	ASSY BODY SHELL PAINTED SLPR LOW RHD	TATA spare parts
281660100198SJ	ASSY CAB COMP LPS 4438 (L2) 4X2 LH SPARE	TATA spare parts
281660100212SJ	ASSY CAB COMP W_T 4038.K ME SPARE PART	TATA spare parts
281660100220	PRIMA LX C SLEEPER FLAT RHD	TATA spare parts
281660100223	ASSY. CABIN BARE PRIMA SLPR TRK BS3	TATA spare parts
281660100224SJ	ASSY. CAB WITH FITMENTS PRIMA BS3	TATA spare parts
281660100226	CAB COMP PRIMA C SL FT LPT 3123	TATA spare parts
281660110127	ASSY. CABIN BARE RR WIND NSLPR BS3/4	TATA spare parts
281660110131	BODY SHELL PAINTED W WIN NSLPR FL LHD	TATA spare parts
281660110176	ASSY CAB COMPLETE NSLPR RHD_LPK3128	TATA spare parts
281660110176SJ	A.CAB COMP LPK 3128 RHD DOM SPARE PART	TATA spare parts
281660110177	ASSY CAB COMPLETE NSLPR	TATA spare parts
281660110177SJ	CAB COMPLTE NSLPR FLAT LPK 2528	TATA spare parts
281660110182SJ	ASSY CAB COMPL 2528K(DOMESTIC)SPARE	TATA spare parts
281660110203	ASSY CAB COMPLETE LPK 2528 (L2) NSLPR FL	TATA spare parts
281660110209	ASSY CAB COMPLETE LPS 4923 C SL LO	TATA spare parts
281660110209SJ	CAB COMPLETE LPS 4923	TATA spare parts
281660110212	ASSY CAB COMPLETE LPK 2538 RHD 6X4 SA (4	TATA spare parts
281660110213SJ	ASSY CAB COM LPK 3123 (M0)NSLPR WIT SPAR	TATA spare parts
281660110214	ASSY CAB COMPLETE LPS 4928 C SLPR LOW RH	TATA spare parts
281660110220	ASSY CAB COMPLETE 3138 (L1) NSLPR FLAT C	TATA spare parts
281660110223SJ	ASSY CAB COMPLETE	TATA spare parts
281660120101	ASSY CAB COMPLETE TRIMMED C SLP LOW RHD	TATA spare parts
281660120104	ASSY CAB COMPLETE LPS 4028 (L2) SLPR	TATA spare parts
281660120110	ASSY CAB COMPLETE LPS 4928 (L2) SLPR	TATA spare parts
281660120110SJ	ASSY CAB COMPLETE LPS 4928 (L2) SLPR SPR	TATA spare parts
281660120118	ASSY CAB COMPLETE 3338.K RHD (S.A.)	TATA spare parts
281660120122	ASSY CAB COMPLETE LPS 4023	TATA spare parts
281660120122SJ	ASSY. CAB COMP.PRIMA 4023.S STCAB SP BS3	TATA spare parts
281660120123SJ	CAB COMPLT LPK 2523(M0) NSLP(SPARE)	TATA spare parts
281660120129	PRIMA LX C SLEEPER LOW RHD	TATA spare parts
281660120132	ASSY. CABIN BARE PRIMA LX STCAB AC BS3/4	TATA spare parts
281660120173	ASSY BODY SHELL PAINTED SLPR FLAT M0	TATA spare parts
281660120181	ASSY CAB COMPLETE LPK 3138 8X4(L1) RHD (	TATA spare parts

281660120200	ASSY CAB COMPL LPS 4923 SLPR 6X4	TATA spare parts
281660120200SJ	ASSY. CAB COMP. LPS 4923 SLPR AC SP BS3	TATA spare parts
281660120204	ASSY CAB COMPLETE 4023.S TRACTOR¿ WITH A	TATA spare parts
281660120204SJ	ASSY CAB COMPLETE 4023.S TRACTOR¿ WITH A	TATA spare parts
281660120208SJ	ASSY CAB COMPLETE LPS 4938 (S.A.) SPARE	TATA spare parts
281660120213	ASSYCABCOMPLETELPS¿4038SAFORRACING	TATA spare parts
281660120215SJ	ASSLY CAB COMPL	TATA spare parts
281660120217SJ	CAB COMPL PRIMA 4028.S-LX SPARE PART	TATA spare parts
281660120218SJ	ASSLY CAB COMPL PRIMA 4928.S-LX	TATA spare parts
281660120228	CAB ASSY	TATA spare parts
281660120228SJ	CAB KIT FOR PRIMA LX 3123K AC NSL SPARE	TATA spare parts
281660130101	ASSY CAB COMPLETE WORKD TRUCK LPS 4738.K	TATA spare parts
281660130101SJ	CAB COMPLETE LPS4738.K SPARE PART	TATA spare parts
281660130111	ASSY CAB COMP C SL FL 3123.T	TATA spare parts
281660130114SJ	CAB ASSY SPARE PARTS	TATA spare parts
281660130116SJ	CAB ASSY	TATA spare parts
281660130117	CABASSY	TATA spare parts
281660130132	ASSY BODY SHELL PAINTED FOR PRIMA 5530 B	TATA spare parts
281661100103	ASSY LONG MEMBER SLPR LH	TATA spare parts
281661100104	ASSY LONG MEMBER SLPR RH	TATA spare parts
281661100107	ASSY LONG MEMBER NON SLPR LH BS6	TATA spare parts
281661100108	ASSY LONG MEMBER NON SLPR RH BS6	TATA spare parts
281661108220	SUPPORT LONG MEMBER FLOOR CENTER	TATA spare parts
281661200103	ASSY FLOOR STRUCTURE COMP SLPR	TATA spare parts
281661200113	ASSY SIDE SILL INNER COMP LH BS6	TATA spare parts
281661200114	ASSY SIDE SILL INNER COMP RH BS6	TATA spare parts
281661200116	ASSY. FLOOR STRUCTURE SIDE LH	TATA spare parts
281661200117	ASSY. FLOOR STRUCTURE SIDE RH	TATA spare parts
281661200118	ASSY FLOOR STRUCTURE COMP NON SLPR	TATA spare parts
281661200119	ASSY. FLOOR STRUCTURE SIDE LH	TATA spare parts
281661200120	ASSY. FLOOR STRUCTURE SIDE RH	TATA spare parts
281661200121	ASSY SIDE SILL INNER COMP LH NON SLPR BS	TATA spare parts
281661200122	ASSY SIDE SILL INNER COMP RH NON SLPR BS	TATA spare parts
281661200123	CROSS MEMBER MIDDLE FRONT	TATA spare parts
281661200125	ASSY CROSS MEMBER SEAT MTG REAR BS6	TATA spare parts
281661200129	ASSY FLOOR STRUCTURE COMPLETE SLPR M0	TATA spare parts
281661208207	CROSS_MEMBER_SEAT_MTG_FRONT BS6	TATA spare parts
281661208209	CROSS_MEMBER_SEAT_MTG_REAR BS6-PH2	TATA spare parts
281661208211	CROSS MEMBER FLOOR CENTER	TATA spare parts
281661208212	CROSS MEMBER SEAT MTG FRONT-LH BS6	TATA spare parts
281661208213	CROSS_MEMBER_SIDE_FRONT_RH BS6	TATA spare parts
281661208221	SUPPORT CROSS MEMBER FLOOR REAR	TATA spare parts
281661300101	ASSY REINF SEAT MTG REAR	TATA spare parts
281661300102	ASSY REINF SEAT MTG FRONT LH	TATA spare parts
281661300103	ASSY REINF SEAT MTG FRONT RH	TATA spare parts
281661600105	ASSY PANEL FLOOR SIDE LH	TATA spare parts
281661600106	ASSY PANEL FLOOR SIDE RH	TATA spare parts

281661600107	ASSY PANEL FLOOR CENTRE TUNNELç SLPR	TATA spare parts
281661600108	ASSY PANEL FLOOR REAR RHD	TATA spare parts
281661600109	ASSY PANEL FLOOR REAR CENTER SLPR	TATA spare parts
281661600110	ASSY FLOOR COMPLETE RHD SLPR	TATA spare parts
281661600112	ASSY FLOOR COMPLETE RHD NON SLPR	TATA spare parts
281661600136	ASSY BKT TIPPER CONTROL MOUNTING	TATA spare parts
281661600142	ASSY UNDER BODY COMPLETE RHD NON SLPR	TATA spare parts
281661600148	ASSY PANEL FLOOR CENTER TUNNEL RHD NON S	TATA spare parts
281661600156	ASSY FLOOR CENTER REAR NON SLPR	TATA spare parts
281661600162	ASSY PANEL FLOOR SIDE LH RHD M0	TATA spare parts
281661600163	ASSY PANEL FLOOR SIDE RH RHD M0	TATA spare parts
281661600164	ASSY PANEL FLOOR CENTRE TUNNEL SLPR M0	TATA spare parts
281661600166	ASSY FLOOR COMPLETE RHD SLPR M0	TATA spare parts
281661600182	ASSY PANEL FLOOR REAR RHD M0	TATA spare parts
281661600230	PANEL ASSY CENTER FLOOR TUNNEL BS6	TATA spare parts
281661600236	CENTER FLOOR ASSY REAR	TATA spare parts
281661600237	PANEL ASSY SIDE FLOOR LH	TATA spare parts
281661610107	FLOOR PANEL ASSY TUNNEL	TATA spare parts
281662200101	ASSY FRONT TUBE SUPPORT RH	TATA spare parts
281662200102	ASSY FRONT TUBE SUPPORT LH	TATA spare parts
281662400101	ASSY RAIL ROOF FRONT INNER	TATA spare parts
281662600101	ASSY FIREWALL INNER RHD	TATA spare parts
281662606301	INSULATION INNER PANEL FIREWALL	TATA spare parts
281662700101	BRACKET ASSY AERO CORNER MTG BS6-PH2	TATA spare parts
281662700103	ASSY MTG BKT ASSY AERO CORNER CENTER	TATA spare parts
281662700104	ASSY PANEL FIREWALL OUTER RHD	TATA spare parts
281662700117	ASSY MTG BKT ASSY AERO CORNER CEN FR	TATA spare parts
281663200101	ASSY REINF DOOR HINGE LH	TATA spare parts
281663200102	ASSY REINF DOOR HINGE RH	TATA spare parts
281663200104	ASSY REINF STRIKER	TATA spare parts
281663600101	ASSY SILL SUPPORT SLPR LH	TATA spare parts
281663600102	ASSY SILL SUPPORT SLPR RH	TATA spare parts
281663600103	ASSY PANEL SILL SUPPORT NON SLPR LH	TATA spare parts
281663600104	ASSY SILL SUPPORT NON SLPR RH	TATA spare parts
281663600105	ASSY SIDE WALL INNER COMPLETE LHç (C_SLP	TATA spare parts
281663600106	ASSY SIDE WALL INNER COMPLETE RH	TATA spare parts
281663600107	ASSY A PILLER LH	TATA spare parts
281663600108	ASSY A PILLER RH	TATA spare parts
281663600109	ASSY RAIL ROOF SIDE INNER FRONT LH	TATA spare parts
281663600110	ASSY RAIL ROOF SIDE INNER FRONT RH	TATA spare parts
281663600111	ASSY. PANEL BODY SIDE INNER SLPR LH	TATA spare parts
281663600112	ASSY. PANEL BODY SIDE INNER SLPR RH	TATA spare parts
281663600114	ASSY REINF LOWER ACCES HANDLE MTG	TATA spare parts
281663600117	ASSY BKT GAS STRUT MTG LH	TATA spare parts
281663600118	ASSY BKT GAS STRUT MTG RH	TATA spare parts
281663600121	ASSY BKT HOLDER NET ROOF SIDE RR SL LO	TATA spare parts
281663600125	ASSY SIDE WALL INNER NON SLPR COMPLETE L	TATA spare parts

281663600126	ASSY SIDE WALL INNER NON SLPR COMPLETE R	TATA spare parts
281663600127	ASSY. PANEL BODY SIDE INNER NON SLPR LH	TATA spare parts
281663600128	ASSY. PANEL BODY SIDE INNER NON SLPR RH	TATA spare parts
281663600132	ASSY_COAT_HOOK_NON_SL_LO BS6	TATA spare parts
281663600135	ASSY BKT HOLDER NET ROOF SIDE FR LH SL	TATA spare parts
281663600136	ASSY BKT HOLDER NET ROOF SIDE FR RH SL L	TATA spare parts
281663600137	ASSY. PANEL BODY SIDE INNER SLPR LH	TATA spare parts
281663600138	ASSY. PANEL BODY SIDE INNER SLPR RH	TATA spare parts
281663600141	ASSY BKT SNAKE LAMP MTG LH	TATA spare parts
281663600149	ASSY REINF ELR UNIT MTG. SLPR CAB LH	TATA spare parts
281663600150	ASSY REINF ELR MTG SLPR CAB RH	TATA spare parts
281663600151	ASSY BKT SNAKE LAMP MTG RH	TATA spare parts
281663600152	ASSY BODY SIDE WALL INNER SLPR WITHOUT W	TATA spare parts
281663600153	ASSY BODY SIDE WALL INNER SLPR WITHOUT W	TATA spare parts
281663600156	ASSY PANEL BODY SIDE INNER WITHOUT WINDO	TATA spare parts
281663600157	ASSY PANEL BODY SIDE INNER	TATA spare parts
281663600160	PANEL ASSY BODY SIDE INNER-LH BS6-PH2	TATA spare parts
281663600161	ASSY PANEL BODY SIDE INR NSLPR RH BS6-PH	TATA spare parts
281663603311	BRACKET B-PILLAR TRIM MTG BS6-PH2	TATA spare parts
281663603312	BRACKET B-PILLAR TRIM MTG RH BS6-PH2	TATA spare parts
281663603326	BKT_BOTTOM_TRIM_QUARTER_UPPER LH	TATA spare parts
281663603327	BKT_BOTTOM_TRIM_QUARTER_UPPER RH	TATA spare parts
281663603342	MTG BKT SIDE HEADBOX LH	TATA spare parts
281663603343	MTG BKT SIDE HEADBOX RH	TATA spare parts
281663603346	BKT TRIM B PILLAR UPPER BTM LH BS6	TATA spare parts
281663608209	PANEL BODY SIDE INNRR NON SLPR LH BS6	TATA spare parts
281663608210	PANEL BODY SIDE INNRR NON SLR RH BS6	TATA spare parts
281663608226	BRACKET CANTRAIL MTG LH BS6-PH2	TATA spare parts
281663608227	BRACKET CANTRAIL MTG RH BS6-PH2	TATA spare parts
281663608245	MTG BKT LATCH DIRTY STORAGE BOX	TATA spare parts
281663700107	ASSY SIDE WALL OUTER LH	TATA spare parts
281663700108	ASSY SIDE WALL OUTER RH	TATA spare parts
281663700109	ASSY SIDE WALL OUTER LH NSLPR	TATA spare parts
281663700110	ASSY SIDE WALL OUTER RH NSLPR	TATA spare parts
281663700112	ASSY PANEL DOOR APERTURE NON SLPR RH	TATA spare parts
281663700118	SIDE WALL ASSY OUTER-LH BS6-PH2	TATA spare parts
281663700119	SIDE WALL ASSY OUTER-RH BS6-PH2	TATA spare parts
281663708203	PANEL SKIN BODY SIDE SLPR WO WINDOW LH	TATA spare parts
281663708204	PANEL SKIN BODY SIDE SLPR	TATA spare parts
281663708205	PANEL SKIN SIDE SLPR WITH WINDOW LH	TATA spare parts
281663708206	PANEL SKIN SIDE SLPR WITH WINDOW RH	TATA spare parts
281663708207	PANEL SKIN BODY SIDE NON SLPR LH	TATA spare parts
281663708208	PANEL SKIN BDY SID NON SLPR RH	TATA spare parts
281663708211	PANEL_DOOR_APERTURE_NON_SLPR_LH	TATA spare parts
281663708212	PANEL DOOR APERTURE NON SLPR RH	TATA spare parts
281663708213	RAIL_ROOF_SIDE_OUTER_REAR_LH	TATA spare parts
281663708214	RAIL_ROOF_SIDE_OUTER_REAR_RH	TATA spare parts

281663708215	PANEL_SIDE_SILL_OUTER_LH	TATA spare parts
281663708216	PANEL_SIDE_SILL_OUTER_RH	TATA spare parts
281663708217	PANEL_C_PILLAR_OUTER_LH	TATA spare parts
281663708218	PANEL C PILLAR OUTER RH	TATA spare parts
281663708219	PANEL_BODY_SIDE_OUTER_NON_SLPR_LH	TATA spare parts
281663708220	PANEL BODY SIDE OUTER NON SLEEPER RH	TATA spare parts
281663708235	PANEL_DOOR_APERTURE_LH	TATA spare parts
281663708236	PANEL_DOOR_APERTURE_RH	TATA spare parts
281664200101	ASSY REAR WALL STRUCTURE SLPR	TATA spare parts
281664200102	ASSY REINF REARWALL LOWER OUTER	TATA spare parts
281664200103	POST REAR WALL	TATA spare parts
281664200112	ASSY. REINF REAR WALL LOWER INNER SIDE L	TATA spare parts
281664200113	ASSY. REINF REAR WALL LOWER INNER SIDE R	TATA spare parts
281664200114	ASSY REINF REARWALL LOWER OUTER NON SLPR	TATA spare parts
281664200115	ASSY. REINF REAR WALL SNORKEL MTG TOP	TATA spare parts
281664200116	ASSY. REINF REAR WALL SNORKEL MTG BOTTOM	TATA spare parts
281664200117	ASSY. REINF REAR WALL SNORKEL MTG BOTTOM	TATA spare parts
281664200119	ASSY REAR WALL STRUCTURE NON SLPR	TATA spare parts
281664200121	ASSY. REINF REAR WALL LOWER INNER MIDDLE	TATA spare parts
281664208201	REINF REAR WALL LOWER INR MIDDLE NR BS	TATA spare parts
281664208209	REINF REAR WALL WINDOW	TATA spare parts
281664400101	ASSY. RAIL ROOF REAR INNER	TATA spare parts
281664603301	BKT COMBINED BOTTOM TRIM QUARTER REAR L	TATA spare parts
281664603302	BKT COMBINED BOTTOM TRIM QUARTER REAR R	TATA spare parts
281664700103	ASSY REINF SNORKEL MTG	TATA spare parts
281664700109	ASSY. PANEL REAR WALL WITH WINDOW	TATA spare parts
281664700111	ASSY. PANEL REAR WALL WITH WINDOW	TATA spare parts
281664708202	PANEL REAR WALL WITH WINDOW	TATA spare parts
281664708211	PANEL_REARWALL_WITH_WINDOW NON SLPR	TATA spare parts
281665100101	ASSY ROOF STRUCTURE WELDED SLPR LOW	TATA spare parts
281665100107	ASSY BKT ROOF LAMP C LO	TATA spare parts
281665100108	ASSY ROOF STRUCTURE WELDED SLPR FLAT	TATA spare parts
281665100109	ASSY ROOF STRUCTURE WELDED NON SLPR FLAT	TATA spare parts
281665100110	ASSY BKT ROOF LAMP C FLAT	TATA spare parts
281665100113	ASSY. REINF ROOF LONGITUDINAL MIDDLE SLP	TATA spare parts
281665100114	ASSY. REINF ROOF LONGITUDINAL MIDDLE SLP	TATA spare parts
281665100115	ASSY REINF ROOF LONGIT MIDDLE LH NON SLP	TATA spare parts
281665100116	ASSY REINF ROOF LONGIT MID RH NSLPR FLAT	TATA spare parts
281665100117	ASSY BKT HEADBOX MTG TOP CENTER LOW	TATA spare parts
281665100118	ASSY BKT HEADBOX MTG TOP CENTER FLAT	TATA spare parts
281665100128	ASSY REINF LONGITUDINAL MIDDLE SLPR LOW	TATA spare parts
281665100129	ASSY REINF LONGITUDINAL MIDDLE SLPR LOW	TATA spare parts
281665100130	ASSY ROOF STRUCTURE WELDED SLPR LOW M0	TATA spare parts
281665100160	ROOF RAIL ASSY BS6	TATA spare parts
281665103305	BKT_FRT_TOP_TRIM_ROOF_SIDE_LO	TATA spare parts
281665103306	BKT_REAR_TOP_TRIM_ROOF_SIDE_LO	TATA spare parts
281665103307	BKT TOP TRIM ROOF SIDE FLAT	TATA spare parts

281665108214	REINF_ROOF_HATCH	TATA spare parts
281665400101	ASSY RAIL ROOF REAR OUTER	TATA spare parts
281665408201	RAIL_ROOF_FRONT_OUTER	TATA spare parts
281665408202	RAIL_ROOF_REAR_OUTER	TATA spare parts
281665408203	BRKT_ROOF_SIDE_REAR_JOINT_LH	TATA spare parts
281665408204	BRKT_ROOF_SIDE_REAR_JOINT_RH	TATA spare parts
281665408206	BRACKET ROOF SIDE REAR JOINT LH FLAT ROO	TATA spare parts
281665408207	BRACKET ROOF SIDE REAR JOINT RH FLAT ROO	TATA spare parts
281665700101	ASSY CENTRE ROOF WELDED SLPR LOW	TATA spare parts
281665700102	ASSY CENTRE ROOF WELDED SLPR FLAT	TATA spare parts
281665700110	ASSY CENTRE ROOF WELDED NON SLPR FLAT	TATA spare parts
281665700115	ASSY REINF END OUTLINE MARKER LAMP MTG B	TATA spare parts
281665700116	ASSY REINF END OUTLINE MARKER LAMP MTG B	TATA spare parts
281665700117	ASSY REINF END OUTLINE MARKER LAMP MTG B	TATA spare parts
281665700118	ASSY REINF END OUTLINE MARKER LAMP MTG B	TATA spare parts
281665708201	PANEL ROOF SIDE SLP LOW LH TML	TATA spare parts
281665708202	PANEL ROOF SIDE SLPR LOW RH RHD	TATA spare parts
281665708203	PANEL ROOF CENTRE FRONT SLPR LOW	TATA spare parts
281665708204	PANEL_ROOF_CETER_REAR_SLP_LOW	TATA spare parts
281665708207	PANEL ROOF CENTER FRONT SLPR FLAT	TATA spare parts
281665708208	PANEL ROOF CENTER REAR SLPR FLAT	TATA spare parts
281665708211	PANEL ROOF CENTER NON SLPR FLAT	TATA spare parts
281665708237	PANEL ROOF SIDE SLPR FLAT LH	TATA spare parts
281665708238	PANEL ROOF SIDE SLPR FLAT RH	TATA spare parts
281665708239	PANEL ROOF SIDE NON SLPR FLAT LH	TATA spare parts
281665708240	PANEL ROOF SIDE NON SLPR FLAT RH	TATA spare parts
281666100101	ASSY COVER BODY MOUNTED STEP LH	TATA spare parts
281666100102	ASSY COVER BODY MOUNTED STEP RH	TATA spare parts
281666100103	ASSY BKT PANEL FOOT STEP MTG LH	TATA spare parts
281666100104	ASSY BKT PANEL FOOT STEP MTG RH	TATA spare parts
281666100109	ASSY COVER BODY MOUNTED STEP LH NSLPR	TATA spare parts
281666100110	ASSY COVER BODY MOUNTED STEP RH NSLPR	TATA spare parts
281666100111	ASSY PANEL COVER BODY MOUNTED	TATA spare parts
281666100112	ASSY PANEL COVER BODY MOUNTED STEP RH MO	TATA spare parts
281666103801	STEP BOARD CAB MOUNTED LH	TATA spare parts
281666103802	STEP BOARD CAB MOUNTED RH	TATA spare parts
281666203309	BKT SKIRT MTG REAR LH	TATA spare parts
281666203310	BKT SKIRT MTG REAR RH	TATA spare parts
281666203311	PANEL FOOT STEP REINFORCEMENT LH	TATA spare parts
281666203312	REINFORCEMENT PANEL FOOT STEP RH	TATA spare parts
281666300109	ASSY SUPPORT PIPE FENDER CTR LH	TATA spare parts
281666300110	ASSY SUPPORT PIPE FENDER CTR RH	TATA spare parts
281666300111	ASSY BRKT 3RD STEP	TATA spare parts
281666300127	ASSY PIPE SUPPORT 3RD STEP LH	TATA spare parts
281666300128	ASSY PIPE SUPPORT 3RD STEP RH	TATA spare parts
281666308201	SUPT-3RD STEP LH / RH	TATA spare parts
281666600105	CTR FENDER A LH	TATA spare parts

281666600106	CTR FENDER A RH	TATA spare parts
281666600108	ASSY BKT MIDDLE FENDER LINEAR MTG	TATA spare parts
281666600117	ASSY FOOT STEP CTR FENDER LH	TATA spare parts
281666600118	ASSY FOOT STEP CTR FENDER RH	TATA spare parts
281666606305	NYLON BUSH	TATA spare parts
281667102302	WINDSHIELD GLASS _DIRECT_ GLAZE_C BS3/4	TATA spare parts
281667106301	SEAL WIND SCREEN-3700MM	TATA spare parts
281667106303	SUPPORT _WINDSCREEN_ BOTTOM	TATA spare parts
281667302301	GLASS _WINDOW_ SIDE LH	TATA spare parts
281667302302	GLASS WINDOW SIDE RH	TATA spare parts
281667306301	SEAL _GLASS_ SIDE LH	TATA spare parts
281667306302	SEAL GLASS SIDE RH	TATA spare parts
281667306305	3M BLACKOUT TAPE SIDE WINDOW	TATA spare parts
281667800102	ASSY SLDNG WNDW RR COMP	TATA spare parts
281667802301	GLASS _WINDOW_ REAR_C	TATA spare parts
281667806301	SEAL _GLASS_ REAR_C	TATA spare parts
281667806302	SEAL REAR SLIDING WINDOW	TATA spare parts
281668206310	CENTER TUNNEL FRONT MEL SHEET	TATA spare parts
281668206311	CENTER TUNNEL REAR RH RHD MEL SHEET	TATA spare parts
281668206313	CENTER TUNNEL REAR LH RHD/RH LHD MEL SHE	TATA spare parts
281668206314	SIDE FLOOR FRONT MEL SHEET LH RHD/RH LHD	TATA spare parts
281668206315	SIDE FLOOR FRONT MEL SHEET RH RHD/ LH LH	TATA spare parts
281668206316	SIDE FLOOR REAR MEL SHEET	TATA spare parts
281668206317	FLOOR REAR ADDON ADHESIVE MEL SHEET	TATA spare parts
281668206318	REAR FLOOR SIDE MEL SHEET	TATA spare parts
281668206319	DOOR REINF PAD	TATA spare parts
281668206322	REAR WALL ADHESIVE MEL SHEET WITH REINFO	TATA spare parts
281668206323	SIDE ROOF ADHESIVE MEL SHEET WITH REINFO	TATA spare parts
281668206324	CENTRE ROOF ANTI VIBRATION PAD	TATA spare parts
281668206325	CENTRE ROOF ADHESIVE MEL SHEET WITH REIN	TATA spare parts
281668206326	CENTRE ROOF ADHESIVE MEL SHEET WITH REIN	TATA spare parts
281668206329	ADHESIVE MEL SHEET WITH REINF PAPER BS6	TATA spare parts
281668206330	REAR WALL ADHESIVE MEL SHEET WITH REINFO	TATA spare parts
281668206331	ADHESIVE SHEET CROSS LINK FOAM (100X150X	TATA spare parts
281668206332	ADHESIVE SHEET CROSS LINK FOAM (35X50X2)	TATA spare parts
281668406301	SCUFF PLATE LH	TATA spare parts
281668406302	SCUFF PLATE RH	TATA spare parts
281668406303	CARPET CENTER C	TATA spare parts
281668406304	INSULATION UNDER BODY C	TATA spare parts
281668406305	CARPET REAR C	TATA spare parts
281668406306	CARPET LH	TATA spare parts
281668406307	CARPET RH	TATA spare parts
281668406308	INSULATION UNDERBODY ADDON CENTER C	TATA spare parts
281668406309	INSULATION UNDERBODY LH	TATA spare parts
281668406310	INSULATION UNDERBODY RH	TATA spare parts
281668406311	INSULATION UNDERBODY ADDON SIDE LH	TATA spare parts
281668406312	INSULATION UNDERBODY ADDON SIDE RH	TATA spare parts



281668406317	CARPET PARTITION PANEL SLPR FABRICATED	TATA spare parts
281668406321	INSULATION_UNDERBODY_SIDE_LH_C_CAB_LHD	TATA spare parts
281668406322	CARPET CENTER SLPR C CAB RHD	TATA spare parts
281668406323	CARPET SIDE LH SLPR C CAB RHD	TATA spare parts
281668406324	CARPET SIDE RH SLPR C CAB RHD	TATA spare parts
281668406325	CARPET CENTER DAY C CAB LHD	TATA spare parts
281668406326	CARPET SIDE LH DAY C CAB LHD	TATA spare parts
281668406327	CARPET SIDE RH DAY C CAB LHD	TATA spare parts
281668406331	INSULATION_CENTER_UNDERBODY_C_CAB_LHD	TATA spare parts
281668406332	UNDERBODY INSULATION CLIP	TATA spare parts
281668406333	INSULATION_UNDERBODY_SIDE_RH_C_CAB_LHD	TATA spare parts
281668406336	CARPET_REAR_RUSSIAN_SLPR_C_CAB_LHD	TATA spare parts
281668406341	CARPET_CENTER_RUSSIAN_SLPR_C_CAB_LHD	TATA spare parts
281668406342	CARPET_SIDE_LH_RUSSIAN_SLPR_C_CAB_LHD	TATA spare parts
281668406343	CARPET_SIDE_RH_RUSSIAN_SLPR_C_CAB_LHD	TATA spare parts
281668406347	CARPET PANEL BERTH INNER FABRICATED CAB	TATA spare parts
281668406348	CARPET PANEL REARWALL LH SLPR CAB	TATA spare parts
281668406349	CARPET PANEL BERTH OUTER CAB C	TATA spare parts
281668406351	CARPET PANEL REARWALL RH CAB	TATA spare parts
281668406357	FOAM CARPET CENTER TUNNEL CAB	TATA spare parts
281668406360	CARPET SIDE LH SLPR C CAB RHD	TATA spare parts
281668406361	CARPET SIDE RH SLPR C CAB RHD	TATA spare parts
281668406362	CARPET REAR SLPR C CAB RHD	TATA spare parts
281668406364	CARPET_SIDE_LH_NS_C_CAB_RHD	TATA spare parts
281668406365	CARPET_SIDE_RH_NS_C_CAB_RHD	TATA spare parts
281668406366	CARPET MOLDED CENTER SLPR C CAB RHD	TATA spare parts
281668406367	CARPET MOLDED CENTER NON SLPR C CAB MO R	TATA spare parts
281668406376	CARPET REAR BS6	TATA spare parts
281668406386	CARPET FRONT FLOOR LH BS6-PH2	TATA spare parts
281668406387	CARPET FRONT FLOOR RH BS6-PH2	TATA spare parts
281668406391	CARPET CENTER BS6-PH2	TATA spare parts
281668406396	CARPET FRONT FLOOR RH BS6	TATA spare parts
281668406398	CARPET FRONT FLOOR CENTER BS6	TATA spare parts
281668406399	CARPET FRONT FLOOR	TATA spare parts
281668416302	CARPET LH	TATA spare parts
281668416303	CARPET RH	TATA spare parts
281668900101	ASSY CROSS MEMBER DASHBOARD COMPLETE	TATA spare parts
281668900125	ASSY DASHBOARD COMPLETE RHD	TATA spare parts
281668900128	ASSY DUCT AIR INTAKE CAB RH RHD	TATA spare parts
281668900134	ASSY STEERING WHEEL	TATA spare parts
281668900138	ASSY DUCT AIR INTAKE CENTER CAB	TATA spare parts
281668900139	ASSY DEFROST DUCT CENTER	TATA spare parts
281668900141	ASSY DUCT FOOT SHOWER C CAB LH RHD	TATA spare parts
281668900142	ASSY DUCT FOOT SHOWER C CAB RH RHD	TATA spare parts
281668900143	ASSY DUCT FOOT SHOWER C CAB LH LHD	TATA spare parts
281668900144	ASSY DUCT FOOT SHOWER C CAB RH LHD	TATA spare parts
281668900145	ASSY DEFROST DUCT FOR DOOR LH	TATA spare parts

281668900146	ASSY DEFROST DUCT FOR DOOR RH	TATA spare parts
281668900150	ASSY_FRAME_GPS_AND_DIN_MTG_LHD	TATA spare parts
281668900152	ASSY COVER DASHBOARD UPPER RH LHD	TATA spare parts
281668900154	ASSY_COVER_DASHBOARD_CO_DRIVER_SIDE_RH	TATA spare parts
281668900157	ASSY_COVER_DASHBOARD_CO_DRIVER_SIDE_LH	TATA spare parts
281668900159	ASSY_COVER_DASHBOARD_DRIVER_SIDE_LH_LH	TATA spare parts
281668900160	ASSY_COVER_DASHBOARD_DRIVER_SIDE_RH_LH	TATA spare parts
281668900162	ASSY ASH TRAY DASH DRIVER SIDE RHD	TATA spare parts
281668900163	ASSY GLOVE BOX COMPLETE TML TYPE	TATA spare parts
281668900169	ASSY AIR VENT CENTER UPPER	TATA spare parts
281668900179	ASSY DASHBOARD SIDE COVER LH	TATA spare parts
281668900180	ASSY DASHBOARD SIDE COVER RH	TATA spare parts
281668900189	ASSY TOP COVER DASHBAORD SIDE LH	TATA spare parts
281668900190	ASSY TOP COVER DASHBOARD SIDE RH	TATA spare parts
281668900199	ASSY DASH CROSS MEMBER COMPLETE C CAB LH	TATA spare parts
281668900204	ASSY GLOVE BOX HANDLE	TATA spare parts
281668900205	ASSY STRIKER GLOVE BOX	TATA spare parts
281668900207	ASSY DUCT AIR INTAKE CAB LH RHD	TATA spare parts
281668900209	ASSY DUCT AIR INTAKE C CAB LH LHD	TATA spare parts
281668900210	ASSY DUCT AIR INTAKE C CAB RH LHD	TATA spare parts
281668900211	ASSY FLOOR CONSOLE TOP FRONT MANUAL	TATA spare parts
281668900213	ASSY FLOOR CONSOLE TOP FRONT AUTOMATIC	TATA spare parts
281668900215	ASSY FLOOR CONSOLE	TATA spare parts
281668900238	ASSY FLOOR CONSOLE COMPLETE	TATA spare parts
281668900241	ASSY FLOOR CONSOLE COMPLETE MANUAL	TATA spare parts
281668900246	ASSY. DASHBOARD COCKPIT BS3	TATA spare parts
281668900248	CENTER CLUSTER ASM-DASH C CAB	TATA spare parts
281668900250	ASSY STEERING WHEEL W/O SWITCHES	TATA spare parts
281668900250AE	ASSY STRNG WHEEL W/O SWES -1628	TATA spare parts
281668900259	ASSY STEERING WHEEL WITH DUMMY HORN PAD	TATA spare parts
281668900264	COCKPIT DASHBOARD ASSY	TATA spare parts
281668900273	CROSS CAR BEAM ASSY DASHBOARD BS6-PH2	TATA spare parts
281668900279	DUCT ASSY BS6-PH2	TATA spare parts
281668900281	DUCT ASSY DOOR VENT LH BS6-PH2	TATA spare parts
281668900283	COCKPIT DASHBOARD ASSY	TATA spare parts
281668900313	CONSOLE ASSY REAR BS6	TATA spare parts
281668900314	CONSOLE ASSY COVER UPPER-REAR BS6-PH2	TATA spare parts
281668900319	COVER ASSY DASHBOARD SIDE LH BS6-PH2	TATA spare parts
281668900320	COVER ASSY DASHBOARD SIDE RH BS6-PH2	TATA spare parts
281668900327	CONSOLE ASSY BEZEL USB FRONT BS6-PH2	TATA spare parts
281668900329	COCKPIT DASHBOARD ASSYBS6	TATA spare parts
281668900330	ARMATURE ASSY DASHBOARD DRIVER SIDE BS6	TATA spare parts
281668900331	SHROUD ASSY INSTRUMENT CLUSTER BS6	TATA spare parts
281668900333	DEFROST DUCT ASSY DOOR RH BS6-PH2	TATA spare parts
281668900334	DEFROST DUCT ASSY DOOR LH BS6-PH2	TATA spare parts
281668900339	BEZEL ASSY SWITCH BANK RH BS6-PH2	TATA spare parts
281668900341	COVER ASSY AIR VENT DASHBOARD SIDE RH BS	TATA spare parts

281668900342	GLOVE BOX LID ASSY INNER BS6-PH2	TATA spare parts
281668900347	FUSE BOX LID WITH KNOB ASSY BS6-PH2	TATA spare parts
281668900349	DUCT ASSY BS6-PH2	TATA spare parts
281668900355	SWITCH BEZEL ASSY BS6	TATA spare parts
281668900356	ARMATURE ASSY	TATA spare parts
281668900357	HORN PAD ASSY BS6	TATA spare parts
281668900358	ARMATURE ASSY BS6-PH2	TATA spare parts
281668905313	FOAM BS6-PH2	TATA spare parts
281668906302	ARMATURE_DASHBOARD_CO_DRIVER_SIDE	TATA spare parts
281668906303	ARMATURE_DASHBOARD_DRIVER_SIDE	TATA spare parts
281668906304	TOP COVER DASHBOARD CENTER C CAB	TATA spare parts
281668906314	FRAME_GPS_AND_DIN_MTG_RHD	TATA spare parts
281668906316	COVER_ECU_TOP_RHD	TATA spare parts
281668906318	COVER_DASH_CO_DRIVER_SIDE_LH_RHD	TATA spare parts
281668906320	COVER DASH DRIVER SIDE LH RHD	TATA spare parts
281668906321	COVER_DASH_DRIVER_SIDE_RH_RHD	TATA spare parts
281668906332	DASH_DEFROST_GRILL_CENTER	TATA spare parts
281668906333	DASH_DEFROST_GRILL_LH	TATA spare parts
281668906334	DASH_DEFROST_GRILL_RH	TATA spare parts
281668906335	COVER DASH SIDE LH	TATA spare parts
281668906336	COVER DASH SIDE RH	TATA spare parts
281668906337	NACELLE_TOP	TATA spare parts
281668906338	NACELLE_BOTTOM	TATA spare parts
281668906342	COVER_ECU_LWR_RHD	TATA spare parts
281668906343	COVER DASHBOARD BOTTOM DRIVER SIDE	TATA spare parts
281668906344	TRIM_A_PILLAR_LWR_RHD	TATA spare parts
281668906345	COVER_STEERING_COLUMN_RHD	TATA spare parts
281668906346	COVER_ECU_LWR_LHD	TATA spare parts
281668906347	TRIM A PILLAR LWR LHD	TATA spare parts
281668906348	COVER_STEERING_COLUMN_CENTER_LHD	TATA spare parts
281668906349	COVER DASHBOARD BOTTOM DRIVER SIDE RH LH	TATA spare parts
281668906352	SKIRT NACELLE COVER	TATA spare parts
281668906356	COVER_CENTER_BOTTOM_C_CAB	TATA spare parts
281668906358	GLOVE BOX INNER BS6	TATA spare parts
281668906365	FLOOR_CONSOLE	TATA spare parts
281668906366	GARNISH_GEAR_SHIFT_CUT_OUT_FLOOR_CONSO	TATA spare parts
281668906367	FLOOR_CONSOLE TOP FRONT MANUAL	TATA spare parts
281668906368	ADDON_FLOOR_CONSOLE	TATA spare parts
281668906371	FLOOR_CONSOLE_TOP_REAR	TATA spare parts
281668906375	GLOVE BOX LID OUTER BS6	TATA spare parts
281668906376	GARNISH RING GEAR SHIFT CUT OUT FLOOR	TATA spare parts
281668906382	GLOVE BOX HOUSING BS6	TATA spare parts
281668906384	HANDLE GLOVE BOX TML TYPE BS6	TATA spare parts
281668906385	PIN HINGE GLOVE BOX TML TYPE BS6	TATA spare parts
281668906387	DAMPER GLOVE BOX TML TYPE BS6	TATA spare parts
281668906388	BRACKET HOLDER GLOVE BOX HANDLE TML TYPE	TATA spare parts
281668906393	COVER DASHBOARD CO-DRIVER SIDE RH RHD WI	TATA spare parts

281668906422	LATCH ASH TRAY DASH C CAB RH	TATA spare parts
281668906428	CENTER_COVER_LOWER_C_CAB_M0_VERSION	TATA spare parts
281668906429	DUMMY_COVER_CENTER_CLUSTER	TATA spare parts
281668906430	DUMMY_COVER_FOR_MUSIC_SYSTEM	TATA spare parts
281668906431	DUMMY LID OUTER ASH TRAY DASH C CAB RHD	TATA spare parts
281668906449	COVER AIR VENT DASHBOARD RH	TATA spare parts
281668906453	COVER DASHBOARD CENTER-LOWER	TATA spare parts
281668906701	PIN GLOVE BOX HANDLE TML TYPE BS6	TATA spare parts
281668907701	PACKING DUCT DEFROST DOOR LH	TATA spare parts
281668907702	PACKING DUCT DEFROST DOOR RH	TATA spare parts
281668907711	RUBBER BEADING DASHBOARD BS6	TATA spare parts
281668908701	SPRING GLOVE BOX PIN HINGE BS6	TATA spare parts
281668908703	SPRING GLOVE BOX HANDLE BS6	TATA spare parts
281668909910	SEAL AND ANTINOISE PADS FOR ALL DUCTS	TATA spare parts
281668909912	FOAM DASHBOARD STEERING COLUMN COVER C	TATA spare parts
281668909913	BSR FOAMS FOR DASHBOARD EPDM FOAM	TATA spare parts
281668909915	BSR FOAMS FOR DASHBOARD PU FOAM	TATA spare parts
281668909919	BSR FOAMS FOR DASHBOARD	TATA spare parts
281668910107	COVER ASSY END-LH BS6-PH2	TATA spare parts
281668910109	COVER ASSY AIR VENT DASHBOARD SIDE RH BS	TATA spare parts
281668910112	COVER ASSY DASHBOARD DR SIDE RH BS6-PH2	TATA spare parts
281668910113	COVER ASSY END-RH BS6-PH2	TATA spare parts
281668910114	GLOVE BOX ASSY LH BS6-PH2	TATA spare parts
281668910115	COVER ASSY DASHBOARD BOTTOM-LH BS6-PH2	TATA spare parts
281668910116	COVER ASSY DASHBOARD BOTTOM-LH BS6-PH2	TATA spare parts
281668910118	ARMATURE ASSY DASHBOARD CO-DR BS6-PH2	TATA spare parts
281668910120	BEZEL ASSY GLOVE BOX BS6-PH2	TATA spare parts
281668910121	COVER ASSY INSTRUMENT CLUSTER BS6-PH2	TATA spare parts
281668910123	SHROUD ASSY INSTRUMENT CLUSTER BS6-PH2	TATA spare parts
281668910126	TOP COVER ASSY DASHBOARD BS6-PH2	TATA spare parts
281668910127	BEZEL ASSY BS6	TATA spare parts
281668910128	ARMATURE ASSY DASHBOARD BS6-PH2	TATA spare parts
281668910131	SIDE AIR VENT ASSY LH BS6-PH2	TATA spare parts
281668910134	AIR VENT ASSY CENTER BS6-PH2	TATA spare parts
281668910135	AIR VENT ASSY CENTER-RH BS6-PH2	TATA spare parts
281668910136	AIR VENT ASSY CENTER-LH BS6-PH2	TATA spare parts
281668910139	CONSOLE ASSY REAR BS6-PH2	TATA spare parts
281668910144	STEERING WHEEL ASSY	TATA spare parts
281668910146	STEERING WHEEL ASSY W/O SWITCH BS6-PH2	TATA spare parts
281668910147	BRACKET ASSY BS6-PH2	TATA spare parts
281668910148	NACELLE AND COMBI SWITCH COVERS BS6-PH2	TATA spare parts
281668910149	STEERING WHEEL ASSY	TATA spare parts
281668910151	CENTER FASCIA ASSY	TATA spare parts
281668910155	ADD ON COVER ASSY DASHBOARD	TATA spare parts
281668910158	COVER ASSY BS6-PH2	TATA spare parts
281668910159	GARNISH BS6-PH2	TATA spare parts
281668910161	COVER	TATA spare parts

281668916311	NACELLE TOP BS6-PH2	TATA spare parts
281668916327	NACELLE_BOTTOM BS6-PH2	TATA spare parts
281668916332	COVER DASHBOARD CENTER-UPPER BS6-PH2	TATA spare parts
281668916355	PIN GLOVE BOX BS6-PH2	TATA spare parts
281668916373	CONSOLE REAR BS6-PH2	TATA spare parts
281668926345	SHROUD INSTRUMENT CLUSTER BS6	TATA spare parts
281668926346	COVER STEERING COLUMN BS6-PH2	TATA spare parts
281668926349	COVER DRIVER SIDE LOWER BS6-PH2	TATA spare parts
281668926350	COVER ECU BOTTOM BS6-PH2	TATA spare parts
281668926351	COVER OBD CONNECTOR BS6-PH2	TATA spare parts
281668926352	DEFROST GRILL CENTER BS6-PH2	TATA spare parts
281668926355	DEFROST GRILL DASHBOARD LH BS6-PH2	TATA spare parts
281668926356	DEFROST GRILL DASHBOARD RH BS6-PH2	TATA spare parts
281668926364	CAP CONSOLE MID MTG SCREW BS6-PH2	TATA spare parts
281668926367	CONSOLE FRONT HOUSING BS6-PH2	TATA spare parts
281668926374	COVER DASHBOARD DRIVER SIDE LH BS6-PH2	TATA spare parts
281668926379	CAP CONSOLE MID MTG SCREW BS6-PH2	TATA spare parts
281668926380	CAP CENTER CONSOLE LOWER BS6-PH2	TATA spare parts
281669100101	FOOT REST ASSY BS6-PH2	TATA spare parts
281669100104	GRAB HANDLE	TATA spare parts
281669100105	ASSY TRIM A PILLAR LH	TATA spare parts
281669100106	ASSY TRIM A PILLAR RH	TATA spare parts
281669105001	RAIL CURTAIN FRONT CAB	TATA spare parts
281669105003	RAIL CURTAIN REAR LH	TATA spare parts
281669105004	RAIL CURTAIN REAR RH	TATA spare parts
281669105005	GUIDE CURTAIN RAIL	TATA spare parts
281669105006	END STOPPER CURTAIN RAIL	TATA spare parts
281669105007	HOOK CURTAIN RAIL	TATA spare parts
281669106301	TRIM A PILLAR LH	TATA spare parts
281669106302	TRIM A PILLAR RH	TATA spare parts
281669106303	CAB ACCES HANDHOLD FRONT UPPER	TATA spare parts
281669106304	CAB-ACCESS HANDHOLD FRONT UPPER RH	TATA spare parts
281669106305	CAB ACCES HANDHOLD REAR	TATA spare parts
281669106306	CAB-ACCESS HANDHOLD REAR RH	TATA spare parts
281669106308	CAB ACCES HANDHOLD FRONT LOWER	TATA spare parts
281669106309	CAB-ACCESS HANDHOLD FRONT LOWER RH	TATA spare parts
281669106310	COAT HOOK	TATA spare parts
281669106320	CAP CAB ACCESS HANDHOLD FRONT UPPER	TATA spare parts
281669106321	CAB ACCESS HANDHOLD FRONT LOWER LH	TATA spare parts
281669106322	CAB ACCESS HANDHOLD FRONT LOWER RH	TATA spare parts
281669106323	CAB ACCESS HANDHOLD REAR LH	TATA spare parts
281669106324	CAB ACCESS HANDHOLD REAR RH POWDER COAT	TATA spare parts
281669200101	ASSY TRIM CANT RAIL FRONT LOWER LH	TATA spare parts
281669200102	ASSY TRIM CANT RAIL FRONT LOWER RH	TATA spare parts
281669200103	ASSY TRIM CANT RAIL FRONT UPPER LH	TATA spare parts
281669200104	ASSY TRIM CANT RAIL FRONT UPPER RH	TATA spare parts
281669200105	ASSY TRIM CANT RAIL REAR LH	TATA spare parts

281669200106	ASSY TRIM CANT RAIL REAR RH	TATA spare parts
281669200107	ASSY TRIM QUARTER LOWER LH	TATA spare parts
281669200108	ASSY TRIM QUARTER LOWER RH	TATA spare parts
281669200113	CANTRAIL TRIM ASSY FRT-UPPER-LH BS6-PH2	TATA spare parts
281669200114	CANTRAIL TRIM ASSY FRT-UPPER-RH BS6-PH2	TATA spare parts
281669200203	ASSY TRIM QUARTER UPPER LH WITH FIX WIND	TATA spare parts
281669200204	ASSY TRIM QUARTER UPPER RH WITH FIX WIND	TATA spare parts
281669200207	ASSY TRIM QUARTER UPPER LH W/O WINDOW W	TATA spare parts
281669200208	ASSY TRIM QUARTER UPPER RH	TATA spare parts
281669200215	ASSY TRIM B PILLAR UPPER LH WITH FOAM	TATA spare parts
281669200216	ASSY TRIM B PILLAR UPPER RH WITH FOAM	TATA spare parts
281669200217	ASSY TRIM QUARTER UPPER LH W/O WINDOW	TATA spare parts
281669200218	ASSY TRIM QUARTER UPPER RH W/O WINDOW	TATA spare parts
281669200219	ASSY TRIM B PILLAR UPPER LH W/O FOAM BAC	TATA spare parts
281669200220	ASSY TRIM B PILLAR UPPER RH W/O FOAM BAC	TATA spare parts
281669200227	B-PILLAR TRIM ASSY UPPER-LH BS6-PH2	TATA spare parts
281669200228	B-PILLAR TRIM ASSY UPPER-RH BS6-PH2	TATA spare parts
281669206303	TRIM_QUARTER_UPPER_LH_WITH_TILT_WINDOW	TATA spare parts
281669206304	TRIM_QUARTER_UPPER_RH_WITH_TILT_WINDOW	TATA spare parts
281669206305	TRIM QUARTER LOWER LH	TATA spare parts
281669206306	TRIM QUARTER LOWER RH	TATA spare parts
281669206307	TRIM B PILLAR UPPER LH	TATA spare parts
281669206308	TRIM B PILLAR UPPER RH	TATA spare parts
281669206309	TRIM B PILLAR LOWER LH	TATA spare parts
281669206310	TRIM B-PILLAR LOWER RH	TATA spare parts
281669206311	TRIM_CANT_RAIL_FRONT_LOWER_LH	TATA spare parts
281669206312	TRIM CANT RAIL FRONT LOWER RH	TATA spare parts
281669206313	TRIM CANT RAIL FRONT UPPER LH	TATA spare parts
281669206314	TRIM CANT RAIL FRONT UPPER RH	TATA spare parts
281669206315	TRIM CANT RAIL REAR LH	TATA spare parts
281669206316	TRIM CANT RAIL REAR RH	TATA spare parts
281669206317	TRIM QUARTER UPPER LH WITH FIX WINDOW	TATA spare parts
281669206318	TRIM QUARTER UPPER RH WITH FIX WINDOW	TATA spare parts
281669206343	FOAM PACK ROOF BS6-PH2	TATA spare parts
281669206344	FOAM PACK ROOF BS6-PH2	TATA spare parts
281669206345	FOAM PACK ROOF BS6-PH2	TATA spare parts
281669206353	TRIM B PILLAR UPPER LH	TATA spare parts
281669206354	TRIM B PILLAR UPPER RH	TATA spare parts
281669206358	DUMMY CAP FRONT FOR TRIM CANTRAIL FRONT	TATA spare parts
281669206359	DUMMY CAP FRONT FOR TRIM CANTRAIL FRONT	TATA spare parts
281669206360	DUMMY CAP REAR FOR TRIM CANTRAIL FRONT U	TATA spare parts
281669206361	DUMMY CAP REAR FOR TRIM CANTRAIL FRONT U	TATA spare parts
281669300101	ASSY NET REAR WALL C	TATA spare parts
281669300103	ASSY MOUNTING BRACKET SPEAKER REARWALL	TATA spare parts
281669300104	ASSY BRACKET MOUNTING REAR	TATA spare parts
281669306301	GRILL_SPEAKER_REARWALL	TATA spare parts
281669306302	STORAGE BOX REAR WALL NON SLPR	TATA spare parts

281669308201	MTG BRACKET SPEAKER REAR WALL LH	TATA spare parts
281669308202	MTG BRACKET SPEAKER REAR WALL RH	TATA spare parts
281669400101	ASSY LINER FLOOR MBR BRKT	TATA spare parts
281669400102	ASSY BKT MIDDLE LINEAR REAR MTG RH	TATA spare parts
281669400202	ASSY TRIM REAR WALL WITH WINDOW WITH UPPER	TATA spare parts
281669400203	ASSY TRIM REAR WALL W/O WINDOW C NON SLPR	TATA spare parts
281669400206	ASSY TRIM REAR WALL WITH WINDOW W/O UPPER	TATA spare parts
281669400210	ASSYTRIMREARWALLCSLPRWITHWINDOWW/OUTER	TATA spare parts
281669400211	ASSY TRIM REAR WALL C SLPR WITH WINDOW W/O	TATA spare parts
281669400213	ASSY TRIM RW C NS WI WIN W/O FO BCK LHD	TATA spare parts
281669400214	ASSY TRIM REARWALL NONSLPR W/O FOAM BACK	TATA spare parts
281669400215	ASSY TRIM REAR WALL WITH WINDOW W/O UPPER	TATA spare parts
281669400230	REAR WALL LINING ASSY BS6-PH2	TATA spare parts
281669406301	TRIM REARWALL C W/O WINDOW WITH UPPER BERTH	TATA spare parts
281669406303	TRIM REAR WALL C NON SLPR WITH WINDOW	TATA spare parts
281669406304	LINING STRIP FENDER REAR RH	TATA spare parts
281669406310	EXIT VENT INNER	TATA spare parts
281669406311	TRIM REAR WALL	TATA spare parts
281669406314	LINING FENDER RR_LH	TATA spare parts
281669406315	LINING FENDER RR_RH	TATA spare parts
281669406319	LINING STRIP FENDER REAR LH	TATA spare parts
281669406320	LINING STRIP FENDER REAR RH	TATA spare parts
281669406324	LINING FENDER RR LH M0	TATA spare parts
281669406325	LINING FENDER RR RH M0	TATA spare parts
281669406326	LINING FENDER RR RH NSLPR	TATA spare parts
281669406329	LINING FENDER RR RH M0	TATA spare parts
281669500101	ASSY NET ROOF SIDE FRONT LH SL LO	TATA spare parts
281669500102	ASSY NET ROOF SIDE FRONT RH SL LO	TATA spare parts
281669500103	ASSY NET ROOF SIDE REAR LH SL LO	TATA spare parts
281669500104	ASSY NET ROOF SIDE REAR RH SL LO	TATA spare parts
281669500201	ASSY TRIM ROOF CENTER WITHOUT ROOF HATCH	TATA spare parts
281669500202	ASSY TRIM ROOF CENTER WITH ROOF HATCH	TATA spare parts
281669500203	ASSY TRIM ROOF SIDE LH SLPR LO	TATA spare parts
281669500204	ASSY TRIM ROOF SIDE RH SLPR LO	TATA spare parts
281669500207	ASSY TRIM ROOF W/O HATCH C FLAT NON SLPR	TATA spare parts
281669500209	ASSYTRIMROOFCENTERW/OROOFHATCHW/OUTER	TATA spare parts
281669500211	ASSY TRIM ROOF SIDE LH SLPR VERSION	TATA spare parts
281669500212	ASSY TRIM ROOF SIDE RH SLPR VERSION	TATA spare parts
281669500214	ASSY TRIM ROOF CENTER W/O ROOF HATCH WITH	TATA spare parts
281669500215	ASSY TRIM ROOF CENTER W/O HATCH C FLAT NON	TATA spare parts
281669500232	ROOF TRIM ASSY BS6-PH2	TATA spare parts
281669506301	TRIM ROOF CENTRE W/O HATCH	TATA spare parts
281669506303	TRIM ROOF SIDE LH	TATA spare parts
281669506304	TRIM ROOF SIDE RH	TATA spare parts
281669506307	TRIM ROOF WO HATCH C FL NON SLPR	TATA spare parts
281669506315	CAP MOUNTING UPPER BERTH ROOF	TATA spare parts
281669506326	TRIM ROOF W/O HATCH C NON SLR	TATA spare parts

281669506338	TR ROOF CTR C SLPR FL M0	TATA spare parts
281669506339	TRIM ROOF SIDE LH SLPR FLAT M0	TATA spare parts
281669506340	TRIM ROOF SIDE RH SLPR FLAT M0	TATA spare parts
281672000101	ASSY DOOR COMP LH AUTOMATIC WINDOW WIN	TATA spare parts
28167200010135	ASSY DOOR COMP LH AUTOMC WIN+CED+SEALA	TATA spare parts
281672000102	ASSY DOOR COMP RH AUTOMATIC WINDOW WIN	TATA spare parts
281672000103	ASSY DOOR COMP LH MANUAL WINDOW WINDIN	TATA spare parts
281672000104	ASSY DOOR COMP RH MANUAL WINDOW WINDIN	TATA spare parts
281672000120	ASSY DOOR COMP LH MANUAL WIN. WINDING	TATA spare parts
281672200101	ASSY_DOOR_SHELL_LH_LHD_TML/TDCV	TATA spare parts
281672200102	ASSY_DOOR_SHELL_RH_LHD_TML/TDCV	TATA spare parts
281672200103	ASSY. PANEL DOOR OUTER LH	TATA spare parts
281672200104	ASSY. PANEL DOOR OUTER RH	TATA spare parts
281672200105	ASSY DOOR SHELL LH	TATA spare parts
28167220010535	ASSY. DOOR SHELL LH+CED+SEAL BS3/4	TATA spare parts
281672200106	ASSY. DOOR SHELL RH BS3/4	TATA spare parts
281672200147	ASSY PANEL DOOR INNER COMPLT LH RHD	TATA spare parts
281672200148	ASSY PANEL DOOR INNER COMPLT RH RHD	TATA spare parts
281672200149	ASSY PANEL DOOR INNER COMPLT LH LHD TML	TATA spare parts
281672200150	ASSY PANEL DOOR INNER COMPLT RH LHD TML	TATA spare parts
281672200184	ASSY DOOR SHELL LH RHD	TATA spare parts
28167220018435	ASSY. DOORSHELL LH RHD MO+CED+SEAL BS3	TATA spare parts
281672200188	ASSY DOOR SHELL RH RHD	TATA spare parts
28167220018835	ASSY. DOORSHELL RH RHD MO +CED+SEAL BS3	TATA spare parts
281672208201	PANEL DOOR OUTER LH RHD	TATA spare parts
281672208202	PANEL DOOR OUTER RH RHD	TATA spare parts
281672208207	WAIST RAIL OUTER LH	TATA spare parts
281672208208	WAIST RAIL OUTER RH	TATA spare parts
281672208215	GLASS RUN CHANNEL MAIN LH	TATA spare parts
281672208216	GLASS RUN CHANNEL MAIN RH	TATA spare parts
281672208217	PANEL_DOOR_OUTER_LH_LHD_TML/TDCV	TATA spare parts
281672208244	REINF MIDDLE PANEL DOOR INNER LH	TATA spare parts
281672208245	REINF MIDDLE PANEL DOOR INNER RH	TATA spare parts
281672300101	ASSY DOOR HINGE	TATA spare parts
281672300103	LOCK SET ASSY	TATA spare parts
281672300117	DOOR TRIM ASSY FRONT DOOR LH BS6-PH2	TATA spare parts
281672300118	DOOR TRIM ASSY FRONT DOOR RH BS6-PH2	TATA spare parts
281672300119	ASSY BKT REAR BOTTOM GLASS RUN CHANNEL M	TATA spare parts
281672300120	ASSY BKT REAR BOTTOM GLASS RUN CHANNEL M	TATA spare parts
281672300125	INNER HANDEL ASSY FRONT DOOR LH BS6-PH2	TATA spare parts
281672300126	INNER HANDEL ASSY FRONT DOOR RH BS6-PH2	TATA spare parts
281672300128	ASSY LATCH LH	TATA spare parts
281672300129	ASSY LATCH RH	TATA spare parts
281672300131	ASSY FRONT GLASS RUN CHANNEL MTG LH	TATA spare parts
281672300132	ASSY_FRONT_GLASS_RUN_CHANNEL_MTG_RH	TATA spare parts
281672300136	DOOR PULL ASSY LH BS6-PH2	TATA spare parts
281672300137	ASSY BKT FRONT BOTTOM GLASS RUN CHANNEL	TATA spare parts



281672300139	DOOR PULL ASSY RH BS6-PH2	TATA spare parts
281672300141	ASSY BKT FRONT TOP GLASS RUN CHANNEL MTG	TATA spare parts
281672300142	ASSY REAR GLASS RUN CHANNEL MTG LH	TATA spare parts
281672300143	ASSY_REAR_GLASS_RUN_CHANNEL_MTG_RH	TATA spare parts
281672300145	ASSY CHECK STRAP	TATA spare parts
281672300146	ASSY DOOR STRIKER	TATA spare parts
281672300147	ASSY DOOR OUTER HANDLE LH	TATA spare parts
281672300148	ASSY DOOR OUTER HANDLE RH	TATA spare parts
281672300149	ASSY DOOR INNER HANDLE LH	TATA spare parts
281672300150	ASSY DOOR INNER HANDLE RH	TATA spare parts
281672300151	ASSY TRIM DOOR COMPLETE LH	TATA spare parts
281672300152	ASSY TRIM DOOR COMPLETE RH	TATA spare parts
281672300153	LOCK BARREL LH	TATA spare parts
281672300154	LOCK BARREL RH	TATA spare parts
281672300167	ASSY STOPPER DOOR	TATA spare parts
281672300169	ASSY TRIM DOOR LH WITH WINDOW WINDING C	TATA spare parts
281672300170	ASSY TRIM DOOR RH WITH WINDOW WINDING C	TATA spare parts
281672300174	LOCK SET ASSY WITH KEYS BS6	TATA spare parts
281672300175	SWITCH ASSY STEERING LOCK CUM IGNITION	TATA spare parts
281672300176	ASSY KIT FOR LOCK-LPK	TATA spare parts
281672300181	ASSY LOCK KIT FOR LPS W/O TRANSPONDER WI	TATA spare parts
281672300198	LOCK SET ASSY WITH KEYS BS6-PH2	TATA spare parts
281672303306	LINK HOLDING BRACKET	TATA spare parts
281672303307	LINK HOLDER (NOVUS)	TATA spare parts
281672306003	LINK_DOOR_HANDLE_INNER_LH	TATA spare parts
281672306004	LINK DOOR HANDLE INNER RH	TATA spare parts
281672306005	LINK POP UP LH	TATA spare parts
281672306006	LINK POP UP RH	TATA spare parts
281672306007	LINK_ACTUATOR_TO_LATCH_LH	TATA spare parts
281672306008	LINK ACTUATOR TO LATCH RH	TATA spare parts
281672306011	LINK LOCK BARREL TO LATCH LH	TATA spare parts
281672306012	LINK LOCK BARREL TO LATCH RH	TATA spare parts
281672306301	TRIM MAIN DOOR LH WITH AUTOMATIC WIND	TATA spare parts
281672306302	TRIM MAIN DOOR RH WITH AUTOMATIC WIND	TATA spare parts
281672306303	GRAB HANDLE LH	TATA spare parts
281672306304	GRAB HANDLE RH	TATA spare parts
281672306305	MAGAZINE POCKET LH	TATA spare parts
281672306306	MAGAZINE POCKET RH	TATA spare parts
281672306307	DEMIST VENT COVER TOP DOOR LH	TATA spare parts
281672306308	DEMIST VENT COVER TOP DOOR RH	TATA spare parts
281672306309	DEMIST VENT COVER BOTTOM DOOR LH	TATA spare parts
281672306310	DEMIST VENT COVER BOTTOM DOOR RH	TATA spare parts
281672306311	TOP TRIM DOOR LH	TATA spare parts
281672306312	TRIM TOP DOOR RH	TATA spare parts
281672306339	POP UP KNOB DOOR	TATA spare parts
281672306340	WATER BARRIER COVER DOOR LH	TATA spare parts
281672306341	TRIM_MAIN_DOOR_LH WITH WINDOW WINDING	TATA spare parts

281672306342	TRIM_MAIN_DOOR_RH WITH WINDOW WINDING	TATA spare parts
281672306343	GRAB HANDLE INNER DOOR UPPER LH	TATA spare parts
281672306344	GRAB HANDLE INNER DOOR UPPER RH	TATA spare parts
281672306345	INSULATION INNER DOOR LH	TATA spare parts
281672306346	INSULATION INNER DOOR RH	TATA spare parts
281672306347	DOOR WATER BARRIER COVER RH	TATA spare parts
281672306358	DOOR INNER HANDLE BRACKET BUTTON LH	TATA spare parts
281672306359	DOOR INNER HANDLE BRACKET BUTTON RH	TATA spare parts
281672306386	CAP INNER HANDLE LH BS6-PH2	TATA spare parts
281672306387	CAP INNER HANDLE RH BS6-PH2	TATA spare parts
281672306392	DOOR PULL HOUSING FRONT DOOR LH BS6-PH2	TATA spare parts
281672306393	DOOR PULL HOUSING FRONT DOOR RH BS6-PH2	TATA spare parts
281672306396	CAP DOOR TRIM LH BS6-PH2	TATA spare parts
281672306397	CAP DOOR TRIM RH BS6-PH2	TATA spare parts
281672306398	DOOR MEMBRANE LH BS6-PH2	TATA spare parts
281672306399	DOOR MEMBRANE RH BS6-PH2	TATA spare parts
281672307502	GROMMET POP UP KNOB DOOR	TATA spare parts
281672307503	GROMMET POP UP KNOB DOOR RH	TATA spare parts
281672307505	GROMMET_RVM_TOP	TATA spare parts
281672307508	DOOR STOPPER	TATA spare parts
281672307709	SEALANT FOR WATER BARRIER	TATA spare parts
281672308001	SCREW_LATCH	TATA spare parts
281672308002	SCREW_STRIKER	TATA spare parts
281672308003	FASTNER DOOR HINGE MTG	TATA spare parts
281672308202	GLASS RUN CHANNEL BOTTOM	TATA spare parts
281672308205	BRKT TOP GLASS RUN CHANNEL MTG REAR	TATA spare parts
281672308206	BRKT WINDOW REG MTG FRONT BOTTOM	TATA spare parts
281672308223	BKT_BOTTOM_GLASS_RUN_CHANNEL_MTG_REAR	TATA spare parts
281672308224	BKT BOTTOM RH (REAR GLASS RUN CH MTG)	TATA spare parts
281672308401	SLEEVE LINK DOOR HANDLE INNER	TATA spare parts
281672320101	LATCH ASSY LH BS6-PH2	TATA spare parts
281672320102	LATCH ASSY RH BS6-PH2	TATA spare parts
281672320103	LINK HOLDER BS6	TATA spare parts
281672330103	LINK INNER HANDLE TO LATCH FRT DR LH BS6	TATA spare parts
281672330104	LINK INNER HANDLE TO LATCH FRT DR RH BS6	TATA spare parts
281672330105	LINK POP UP KNOB TO LATCH FRT DR LH BS6-	TATA spare parts
281672330106	LINK POP UP KNOB TO LATCH FRT DR RH BS6-	TATA spare parts
281672500105	ASSY_OUTER_BELT_LH	TATA spare parts
281672500106	ASSY OUETR BELT RH	TATA spare parts
281672500107	ASSY_INNER_BELT_LH	TATA spare parts
281672500108	ASSY INNER BELT RH	TATA spare parts
281672500109	ASSY WINDOW WINDING REGULATOR MANUAL	TATA spare parts
281672500110	ASSY WINDOW WINDING REGULATOR MANUAL	TATA spare parts
281672500111	WINDOW WINDING REGULATOR ASSY LH BS6-PH2	TATA spare parts
281672500112	WINDOW WINDING REGULATOR ASSY RH BS6-PH2	TATA spare parts
281672500113	ASSY WINDOW WINDING REGULATOR MANUAL	TATA spare parts
281672500114	ASSY WINDOW WINDING REGULATOR MANUAL	TATA spare parts

281672500115	ASSY WINDOW WINDING REGULATOR AUTO LH	TATA spare parts
281672500116	ASSY WINDOW WINDING REGULATOR AUTO RH	TATA spare parts
281672500117	WINDOW_LIFTER_HANDLE	TATA spare parts
281672502301	GLASS WINDOW DOOR LH	TATA spare parts
281672502302	GLASS WINDOW DOOR RH	TATA spare parts
281672506304	SEAL SECONDARY LH	TATA spare parts
281672506305	SEAL SECONDARY RH	TATA spare parts
281672506306	SEAL_GLASS_RUN_CHANNEL_INNER_TOP_LH	TATA spare parts
281672506307	SEAL GLASS RUN CHANNEL INNER TOP RH	TATA spare parts
281672506308	SEAL_GLASS_RUN_CHANNEL_BOTTOM	TATA spare parts
281672506309	SEAL_GLASS_RUN_CHANNEL_REAR_BOTTOM	TATA spare parts
281672506310	WAIST BELT OUTER LH	TATA spare parts
281672506311	WAIST BELT OUTER RH	TATA spare parts
281672506313	SEAL GLASS RUN CHANNEL TOP LH-MANUAL WIN	TATA spare parts
281672506314	SEAL GLASS RUN CHANNEL TOP RH-MANUAL WIN	TATA spare parts
281672506315	SEAL GLASS RUN CHANNEL BOTTOM-MANUAL W	TATA spare parts
281672706301	ADD ON DOOR OUTER LH	TATA spare parts
281672706302	ADD ON DOOR OUTER RH	TATA spare parts
281672706303	ADD ON DOOR INNER LH	TATA spare parts
281672706304	ADD ON DOOR INNER RH	TATA spare parts
281672900101	ORVM ASSY	TATA spare parts
281672900102	ORVM ASSY LH	TATA spare parts
281672900103	ORVM ASSY RH	TATA spare parts
281672900104	PROXY MIRROR ASSY	TATA spare parts
281675100101	ASSY. FLAP CENTER COMPLETE BS3/4	TATA spare parts
281675100106	ASSY STRIP FLAP CENTER W/T-EMBLEM	TATA spare parts
281675100110	ASSY AERO CORNER LH	TATA spare parts
281675100110FD	ASSY AERO CORNER LH	TATA spare parts
281675100110GD	ASSY AERO CORNER LH	TATA spare parts
281675100110H6	ASSY AERO CORNER LH	TATA spare parts
281675100111	ASSY AERO CORNER RH	TATA spare parts
281675100111FD	ASSY AERO CORNER RH	TATA spare parts
281675100111GD	ASSY AERO CORNER RH	TATA spare parts
281675100114	ASSY. INSERT AERO CORNER LH BS3/4/6	TATA spare parts
281675100114FD	ASSY INSERT AERO CORNER LH BS6	TATA spare parts
281675100114GD	ASSY INSERT AERO CORNER LH	TATA spare parts
281675100115	ASSY. INSERT AERO CORNER RH BS3/4/6	TATA spare parts
281675100115FD	ASSY INSERT AERO CORNER RH BS6	TATA spare parts
281675100115GD	ASSY INSERT AERO CORNER RH	TATA spare parts
281675100123	GRILL FLAP CENTER	TATA spare parts
281675100130	ASSY STRIP FLAP CENTER	TATA spare parts
281675100131	ASSY AERO CORNER LH NON SLPR	TATA spare parts
281675100141	AIR DEFLECTOR ASSY LH BS6-PH2	TATA spare parts
281675100142	AIR DEFLECTOR ASSY RH BS6-PH2	TATA spare parts
281675100148	CENTER FLAP ASSY BS6-PH2	TATA spare parts
281675100155	COVER ASSY WIPER LH BS6-PH2	TATA spare parts
281675100156	COVER ASSY WIPER RH BS6-PH2	TATA spare parts

281675106301	FLAP CENTRE C CAB BS3/4	TATA spare parts
281675106301FD	SK_GOLN_YELW-CENTER FLAP C-CAB BS6	TATA spare parts
281675106302	GRILL FLAP CENTER	TATA spare parts
281675106303	INSECT PROTECTION GRILL FLAP CENT	TATA spare parts
281675106313	SIDE WIPER COVER LH	TATA spare parts
281675106314	SIDE WIPER COVER RH	TATA spare parts
281675106318	COVER WIPER SYSTEM	TATA spare parts
281675106320	INSECT PROTECTION GRILL FLAP CENT	TATA spare parts
281675106322	COVER WIPER SYSTEM MO	TATA spare parts
281675200108	HINGE FLAP ASSY CENTER-LH BS6-PH2	TATA spare parts
281675200109	ASSY MTG BRKT LATCH LH	TATA spare parts
281675200111	ASSY MTG BRKT LATCH RH	TATA spare parts
281675200114	HINGE FLAP ASSY CENTER-RH BS6-PH2	TATA spare parts
281675200142	ASSY RUBBER BUFFER FLAP CENTER	TATA spare parts
281675200143	ASSY LEVER RELEASE CABLE LH	TATA spare parts
281675200146	ASSY HINGE 4 BAR - CENTER FLAP LH	TATA spare parts
281675200147	ASSY HINGE 4 BAR-CENTRE FLAP RH	TATA spare parts
281675200151	BRACKET ASSY LATCH MTG LH BS6-PH2	TATA spare parts
281675200152	BRACKET ASSY LATCH MTG RH BS6-PH2	TATA spare parts
281675200153	ASSY LATCH DIRTY STORAGE BOX LH	TATA spare parts
281675200154	ASSY LATCH DIRTY STORAGE BOX RH	TATA spare parts
281675200155	LATCH FLAP ASSY CENTER-LH BS6-PH2	TATA spare parts
281675200156	LATCH FLAP ASSY CENTER-RH BS6-PH2	TATA spare parts
281675200164	CENTER FLAP LATCH ASSY BOTTOM LH	TATA spare parts
281675200165	CENTER FLAP LATCH ASSY BOTTOM RH	TATA spare parts
281675200168	ASSY GAS STRUT CENTER FLAP	TATA spare parts
281675200170	ASSY LEVER RELEASE CABLE RH	TATA spare parts
281675200171	ASSY STRAP FLAP CENTRE	TATA spare parts
281675204304	NON RETURNABLE STAR WASHER (6 DIA)	TATA spare parts
281675204305	NON RETURNABLE STAR WASHER (5 DIA)	TATA spare parts
281675206302	TATA EMBLEM	TATA spare parts
281675206306	GRILL COVER WIPER	TATA spare parts
281675206707	STRIKER CENTER FLAP LATCH	TATA spare parts
281675206708	LOCK PIN LINK	TATA spare parts
281675208201	MTG. BKT. GAS STRUT BODY SIDE	TATA spare parts
281675400101	ASSY LID COPMLETE DIRTY STORAGE BOX LH	TATA spare parts
281675400102	ASSY LID STORAGE BOX RH	TATA spare parts
281675400103	ASSY HEMMING-LID STORAGE BOX LH	TATA spare parts
281675400104	ASSY HEMMING LID STORAGE BOX RH	TATA spare parts
281675400106	ASSY BKT GAS STRUT UPPER LH	TATA spare parts
281675400107	ASSY BKT GAS STRUT UPPER RH	TATA spare parts
281675400109	ASSY LID INNER PANEL LH	TATA spare parts
281675400110	ASSY LID INNER PANEL RH	TATA spare parts
281675403301	SHORT LINK DIRTY STORAGE BOX LH	TATA spare parts
281675403302	LONG LINK DIRTY STORAGE BOX LH	TATA spare parts
281675406307	REINF PAD PANEL LID STORAGE BOX LH	TATA spare parts
281675406308	REINF PAD PANEL LID STORAGE BOX RH	TATA spare parts

281675408201	PANEL_LID_STORAGE_BOX_OUTER_LH	TATA spare parts
281675408203	PANEL_LID_STORAGE_BOX_INNER_LH	TATA spare parts
281675408204	PANEL LID STORAGE BOX INNER RH	TATA spare parts
281675408210	PANEL LID STORAGE BOX OUTER RH	TATA spare parts
281675500103	ASSY HINGE STORAGE BOX LH	TATA spare parts
281675500106	ASSY HINGE STORAGE RH	TATA spare parts
281675500113	RELEASE CABLE STORAGE BOX	TATA spare parts
281675500114	ASSY RELEASE CABLE DIRTY STORAGE BOX	TATA spare parts
281675500115	ASSY MTG BKT RELEASE CABLE DIRTY STORAGE	TATA spare parts
281675500117	ASSY STRIKER STORAGE BOX	TATA spare parts
281675500120	ASSY GAS STRUT DIRTY STORAGE BOX	TATA spare parts
281675506301	CARPET LID STORAGE BOX LH SLPR FAB	TATA spare parts
281675506302	SEAL DIRTY STORAGE LH	TATA spare parts
281675506303	SEAL DIRTY STORAGE RH	TATA spare parts
281675506304	SEAL DUST CONTROL LATCH	TATA spare parts
281675506305	CARPET LID STORAGE BOX RH SLPR FAB	TATA spare parts
281675507702	STOPPER FRONT DIRTY STORAGE BOX	TATA spare parts
281675507703	STOPPER REAR DIRTY STORAGE BOX	TATA spare parts
281675507706	STOPPER SIDE DIRTY STORAGE BOX	TATA spare parts
281675508210	CENTER FLAP REINFORCEMENT	TATA spare parts
281675508211	WIPER COVER REINFORCEMENT	TATA spare parts
281675508212	AERO CORNER BOTTOM BKT LH	TATA spare parts
281675508213	AERO CORNER BOTTOM BKT RH	TATA spare parts
281675508215	AERO CORNER BOTTOM REINF	TATA spare parts
281675508216	AERO CORNER SIDE REINFORCEMENT LH	TATA spare parts
281675508217	AERO CORNER SIDE REINFORCEMENT RH	TATA spare parts
281681000102	REFLECTIVE TAPE ASSY BS6-PH2	TATA spare parts
281681000103	ASSY MTG BKT ADD ON SIDE REAR LH	TATA spare parts
281681000104	ASSY MTG BKT ADD ON SIDE REAR RH	TATA spare parts
281681000105	ASSY RETRO REFLECTIVE TAPE FOR EXTERIOR	TATA spare parts
281681000106	ASSY MASCOT FOR 4938 S WORLDTRUCK	TATA spare parts
281681000107	ASSY MASCOT FOR 4028 S	TATA spare parts
281681000108	ASSY MASCOT FOR 4928 S WORLDTRUCK	TATA spare parts
281681000109	ASSY MASCOT FOR 4038 S WORLDTRUCK	TATA spare parts
281681000110	ASSY MASCOT 2528	TATA spare parts
281681000112	ASSY MASCOT 3138 K	TATA spare parts
281681000113	ASSY MASCOT FOR 3128 K	TATA spare parts
281681000114	ASSY BRAND NAME WORLDTRUCK	TATA spare parts
281681000115	ASSY MTG BRKT ADD ON BODY SIDE LH	TATA spare parts
281681000116	ASSY MTG BRKT ADD ON BODY SIDE RH	TATA spare parts
281681000119	ASSY MTG BKT ADD ON SIDE REAR LH C CONS	TATA spare parts
281681000120	ASSY MTG BKT ADD ON SIDE REAR RH C CONS	TATA spare parts
281681000122	ASSY RETRO REFLECTOR TAPE COMP	TATA spare parts
281681000123	REFLECTIVE TAPE FOR EXTERIOR TRIMS	TATA spare parts
281681000127	ASSY MASCOT FOR 4023 S WORLDTRUCK	TATA spare parts
281681000128	REFLECTIVETAPEFOREXTERIOR TRIMSSLPRCABM	TATA spare parts
281681000129	ASSY MASCOT FOR 3123 K WORLDTRUCK	TATA spare parts

281681000130	ASSY MASCOT FOR 4923 S WORLDTRUCK	TATA spare parts
281681000131	REFLECTIVETAPEFOREXTERIORTRIMSNONSLPRMO	TATA spare parts
281681000134	ASSY LX BRAND NAME WORLDTRUCK	TATA spare parts
281681000164	ASSY MASCOT FOR 2538 K WORLDTRUCK	TATA spare parts
281681000166	ASSY MASCOT FOR 4438 S WORLDTRUCK	TATA spare parts
281681000172	ASSY MASCOT FOR 4738 K WORLDTRUCK	TATA spare parts
281681000173	ASSY MASCOT FOR 3328 K WORLDTRUCK	TATA spare parts
281681000176	ASSY MASCOT FOR 4038 K WORLDTRUCK	TATA spare parts
281681000178	ASSY MASCOT FOR 2518 T WORLDTRUCK BS6	TATA spare parts
281681000179	ASSY MASCOT FOR 3518 S WORLDTRUCK	TATA spare parts
281681000180	MASCOT ASSY 3518.T BS6	TATA spare parts
281681100101	ASSY SEAL AERO CORNER LH	TATA spare parts
281681100102	ASSY SEAL AERO CORNER RH	TATA spare parts
281681100106	ASSY SUNVISOR SIDE LH	TATA spare parts
281681100107	ASSY SUNVISOR SIDE RH	TATA spare parts
281681100108	ASSY FRONT VIEW MIRROR BS6	TATA spare parts
281681100110	ASSY ADD ON BODY SIDE LH NS C	TATA spare parts
281681100111	ASSY ADD ON BODY SIDE RH NS C	TATA spare parts
281681100112	ASSY ADD ON BODY SIDE LH SLP C	TATA spare parts
281681100113	ASSY ADD ON BOSY SIDE RH SLP C	TATA spare parts
281681100118	ASSY MAIN VIEW MIRROR AND WIDE ANGLE MIR	TATA spare parts
281681100119	ASSY MAIN VIEW MIRROR AND WIDE ANGLE MIR	TATA spare parts
281681100120	ASSY_PROXIMITY_MIRROR_CO_DRIVER_SIDE	TATA spare parts
281681100122	ASSY PROXIMITY MIRROR CO DRIVER SIDE	TATA spare parts
281681100123	ASSY. MAIN & WIDE ANGLE MIRROR LH BS3-6	TATA spare parts
281681100124	ASSY MAIN VIEW AND WIDE ANGLE MIRROR RH	TATA spare parts
281681100125	ASSY_PROXIMITY_MIRROR_CO_DRIVER_SIDE_EE	TATA spare parts
281681100126	ASSY SET REAR VIEW MIRROR MANUAL VERSION	TATA spare parts
281681100129	ASSY ORVM SET FOR MANUAL W/O WIDE ANGLE	TATA spare parts
281681100130	ASSY. RVM ON DRIVER SIDE W/O WID BS3/4	TATA spare parts
281681100131	ASSY ADD ON BODY SIDE LH	TATA spare parts
281681100132	ASSY ADD ON BODY SIDE RH	TATA spare parts
281681100133	ASSY MAIN VIEW MIRROR AND WIDE ANGLE MIR	TATA spare parts
281681100134	ASSY MAIN VIEW MIRROR AND WIDE ANGLE MIR	TATA spare parts
281681100151	ASSY MASCOT FOR 2523 K WORLDTRUCK	TATA spare parts
281681100153	MASCOT FOR 3123 T WORLDTRUCK	TATA spare parts
281681100154	ASSY MASCOT FOR 2523 T WORLDTRUCK	TATA spare parts
281681100159	ASSY.CLOSE PROXIMITY MIRROR PRIMA M0	TATA spare parts
281681100161	DRG ASSY SUNVISOR SIDE LH	TATA spare parts
281681100162	DRG ASSY SUNVISOR SIDE RH	TATA spare parts
281681100165	ASSY MAIN VIEW AND WIDE ANGLE MIRROR LH	TATA spare parts
281681100166	ASSY PROXIMITY MIRROR CO DRIVER SIDE	TATA spare parts
281681100167	ASSY MAIN VIEW AND WIDE ANGLE MIRROR RH	TATA spare parts
281681100168	ASSY_PROXIMITY_MIRROR_CO_DRIVER_SIDE_SA	TATA spare parts
281681106301	ADD ON BODY SIDE LH NS	TATA spare parts
281681106302	ADD ON BODY SIDE RH NS	TATA spare parts
281681106303	ADD ON BODY SIDE LH SLP	TATA spare parts

281681106304	ADD ON BODY SIDE RH SLP	TATA spare parts
281681106309	EDGE_BEAD_ROOF_SLEEPER_LO	TATA spare parts
281681106310	EDGE BEAD ROOF SLEEPER FLAT	TATA spare parts
281681106312	EDGE BEAD ROOF NON SLEEPER	TATA spare parts
281681106313	SEAL PRIMARY LH	TATA spare parts
281681106314	SEAL PRIMARY RH	TATA spare parts
281681106315	SEAL SECONDARY LH	TATA spare parts
281681106316	SEAL SECONDARY RH	TATA spare parts
281681106325	SEAL SUPPORT LID STORAGE BOX	TATA spare parts
281681106326	SEAL TOP LID STORAGE BOX	TATA spare parts
281681108202	MTG BRKT ADD ON BODY SIDE REAR LH	TATA spare parts
281681108203	MTG BRKT ADD ON BODY SIDE REAR RH	TATA spare parts
281681110101	FRONT VIEW MIRROR ASSY BS6	TATA spare parts
281681900106	ASSY BRKT NOISE SHIELD LOWER	TATA spare parts
281681900108	ASSY NOISE SHIELD FENDER MTG BRKT	TATA spare parts
281681900109	ASSY BKT SUPORT MIDDLE NOISE SHEILD	TATA spare parts
281681900110	ASSY BKT SUPPORT FRONT NOISE SHEILD	TATA spare parts
281681900111	ASSY BKT REAR SUPPORT NOISE SHEILD	TATA spare parts
281681900112	ASSY BRACKET FRONT SUPPORT NOISE SHIELD	TATA spare parts
281681900113	ASSY BKT REAR SUPPORT NOISE SHEILD NON S	TATA spare parts
281681906301	PLUG BUTTON FOR ROOF CENTER HOLE DIA 25	TATA spare parts
281681906302	PLUG BUTTON FOR ROOF CENTER HOLE DIA 12	TATA spare parts
281681906303	PLUG BUTTON FOR ROOF SIDE HOLE DIA 16	TATA spare parts
281681906304	PLUG BUTTON FOR FIREWALL OUTER HOLE DIA	TATA spare parts
281681906305	PLUG BUTTON FOR FIREWALL OUTER HOLE DIA	TATA spare parts
281681906306	PLUG BUTTON FOR FIREWALL OUTER FOR SLOT	TATA spare parts
281681906308	PLUG BUTTON FOR REINF CAB MTG FRONT HOLE	TATA spare parts
281681906309	PLUG BUTTON FOR REINF CAB MTG FRONT SLOT	TATA spare parts
281681906310	PLUG BUTTON FOR PANEL DOOR APERTURE HOLE	TATA spare parts
281681906311	PLUG BUTTON FOR PANEL SKIN BODY SIDE SLO	TATA spare parts
281681906312	PLUG BUTTON FOR ROOF CENTER HOLE DIA 30	TATA spare parts
281681906313	PLUG BUTTON FOR ROOF CENTER HOLE DIA 14	TATA spare parts
281681906314	PLUG BUTTON FOR FIREWALL OUTER HOLE DIA	TATA spare parts
281681906315	PLUG BUTTON FOR FLOOR INNER HOLE DIA 18	TATA spare parts
281681906316	PLUG BUTTON FOR PANEL SKIN BODY SIDE SLO	TATA spare parts
281681906317	PLUG BUTTON FOR REINF CAB MTG FRONT SLOT	TATA spare parts
281681906320	PLUG BUTTON FOR REARWALL UPPER	TATA spare parts
281681906321	PLUG BUTTON FOR PANEL BODY SIDE INNER	TATA spare parts
281681906322	PLUG BUTTON - DOOR INNER PANEL (PROXY)	TATA spare parts
281681906323	PLUG BUTTON FOR REINF REARWALL LOWER INN	TATA spare parts
281681906324	PLUG BUTTON FOR SIDE SILL INNER DIA 8.0	TATA spare parts
281681906325	PLUG BUTTON FOR SIDE SILL INNER FOR SLOT	TATA spare parts
281681906326	PLUG BUTTON FOR SIDE SILL OUTER FOR SLO	TATA spare parts
281681906328	PLUG BUTTON FOR FIREWALL OUTER INNER FOR	TATA spare parts
281681906332	PLUG BUTTON FOR DOOR INNER PANEL BOTTOM	TATA spare parts
281681906333	PLUG BUTTON FOR DOOR INNER PANEL BOTTOM	TATA spare parts
281681906334	PLUG BUTTON FOR DOOR INNER PANEL BOTTOM	TATA spare parts

281681906801	NOISE SHIELD UPPER LH_FRT_SLPR	TATA spare parts
281681906802	NOISE SHIELD UPPER RH_FRT_SLPR	TATA spare parts
281681906805	NOISE_SHIELD_LOWER_LH_SLPR_C_CAB_RHD	TATA spare parts
281681906806	NOISE SHEILD FRONT LOWER RH SLPR	TATA spare parts
281681906807	NOISE SHIELD LOWER RH S CAB	TATA spare parts
281681906812	NOISE SHIELD UPPER LH_FRT_SLPR_LPS 4038	TATA spare parts
281681906815	NOISE SHIELD UPPER RH S CAB	TATA spare parts
281681906819	NOISE SHIELD UPPER LH NS CAB RHD	TATA spare parts
281681906820	NOISE SHIELD UPPER RH NS CAB RHD	TATA spare parts
281681906824	NOISE SHIELD UPPER RH LHD NS LPK 2538	TATA spare parts
281681906825	NOISE SHIELD UPPER LH NS RHD LPK 2528	TATA spare parts
281681906826	NOISE SHIELD UPPER RH NS RHD LPK 2528	TATA spare parts
281681906827	NOISE SHEILD LOWER LH SL RHD/LHD LPS 403	TATA spare parts
281681906828	NOISE SHEILD LOWER RH SL RHD/LHD LPS 403	TATA spare parts
281681906833	NOISE SHIELD UPPER LH SL RHD	TATA spare parts
281681906834	NOISE SHIELD UPPER RH SL RHD	TATA spare parts
281681906837	NOISE SHIELD UPPER RHFRTSLPRLPS4038 LHD	TATA spare parts
281681906840	NOISE SHIELD UPPER RH S CAB RHD LPS 4038	TATA spare parts
281681906848	NOISE SHIELD UPPER RH S CAB RHD LPS 4938	TATA spare parts
281681906852	NOISE SHIELD UPPER LH NS RHD LPK 3123	TATA spare parts
281681906854	NOISESHIELDUPPERLHNSLHD LPK4738ME	TATA spare parts
281681906859	NOISE SHIELD UPPER LH LHD 4038.S SLPR CA	TATA spare parts
281681906864	NOISE SHIELD UPPER LH_FRT_SLPR_LPS 4948	TATA spare parts
281681906867	NOISE SHIELD UPPER LH SL RHD M0_LPT3123	TATA spare parts
281681906869	NOISE SHIELD UPPER RH 3123T TWIN STEER	TATA spare parts
281681906870	NOISE SHIELD UPPER RH NS CAB 4038.K LHD	TATA spare parts
281681906871	NOISE INSULATION RH	TATA spare parts
281681908230	BRACKET SUPPORT REAR NOISE SHEILD	TATA spare parts
281681914701	AIR DEFLECTOR	TATA spare parts
281682400101	ASSY. WIPER SYSTEM RHD BS3/4	TATA spare parts
281682400103	WIPER MOTOR	TATA spare parts
281682400113	ASSY DRIVER SIDE SPINDLE MTG BKT RHD	TATA spare parts
281682400114	CO-DRIVER SIDE SPINDLE MTG BKT RHD	TATA spare parts
281682400117	MOTOR MTG BKT	TATA spare parts
281682400119	ASSY. WIPER ARM & BLADE RHD BS3/4	TATA spare parts
281682400125	ASSY WIPER SYSTEM COML RHD	TATA spare parts
281682400127	ASSY. WIPER SYSTEM LINKAGE RHD BS3/4/6	TATA spare parts
281682400131	WIPER BLADE	TATA spare parts
281682400141	GEAR AND SLIP RING ASSEMBLY	TATA spare parts
281682500102	POWER SOCKET 12 VDC	TATA spare parts
281682509901	POWER SOCKET DUMMY CAP OFFER	TATA spare parts
281682900101	KIT W/S WASHER SYSTEM RHD VEHICLE	TATA spare parts
281682900104	KIT W/S WASHER SYSTEM; LHD (EXPORT)	TATA spare parts
281682906301	TUBE FILTER BS6	TATA spare parts
281682906302	WASHER RESERVOIR BS6	TATA spare parts
281682906304	TUBE WASHER SYSTEM PVC 950MM RHD (DOM.)	TATA spare parts
281682906305	TUBE WASHER SYSTEM PVC 100MM RHD (DOM)	TATA spare parts



281682906306	TUBE WASHER SYSTEM PVC 600MM RHD (DOM)	TATA spare parts
281682906307	"TUBE WASHER SYSTEM EPDM 300MM,LHD(EX)"	TATA spare parts
281682906308	"TUBE WASHER SYSTEM EPDM 360MM,LHD(EX)"	TATA spare parts
281682906309	"TUBE WASHER SYSTEM EPDM 700MM,LHD(EX)"	TATA spare parts
281682907701	GROMMET&RUBBER&WASHER&PUMP BS6	TATA spare parts
281683100202	ASSY DUCT FOOT LH C CAB LHD	TATA spare parts
281683100203	ASSY DUCT FOOT RH C CAB LHD	TATA spare parts
281683100205	ASSY DUCT FOOT LH EXT-2 C CAB LHD	TATA spare parts
281683300104	AC CONTROL PANEL (MANUAL	TATA spare parts
281683300105	CONTROL SW - MANUAL BLOWER ONLY	TATA spare parts
281683300106	CONTROL SW - MANUAL HVAC	TATA spare parts
281683300110	HARNESS HVAC MODULE	TATA spare parts
281683306001	SUB HARN - HVAC MODULE-MANUAL	TATA spare parts
281683400101	KIT HVAC UNIT COMPLETE MANUAL	TATA spare parts
281683400102	HVAC UNIT COMPLETE - MANUAL	TATA spare parts
281683400109	ASSY. HVAC UNIT (MANUAL) BS3/4	TATA spare parts
281683400109AE	ASSY HVAC WITH MTG BRKTS -1828	TATA spare parts
281683400110	ASSY.HVAC UNIT FATC	TATA spare parts
281683400113	ASSY HEATER CORE COMPLETE	TATA spare parts
281683400114	ASSY. BLOWER MOTOR BS3	TATA spare parts
281683400115	ASSY BLOWER RESISTER COMPLETE FOR HVAC	TATA spare parts
281683400116	ASSY MOS MODULE COMPLETE FOR HVAC FATC	TATA spare parts
281683400117	ASSY. FRESH AIR FILTER BS3	TATA spare parts
281683400119	ASSY HVAC MANUAL WIRING HARNESS COMPLET	TATA spare parts
281683400120	ASSY HVAC FATC WIRING HARNESS	TATA spare parts
281683400130	ASSY MODE ACTUATOR MOTOR	TATA spare parts
281683400137	ASSY AIR FILTER FRAME	TATA spare parts
281683400138	ASSY INTAKE SENSOR	TATA spare parts
281683400139	ASSY WATER SENSOR - FATC	TATA spare parts
281683400140	ASSY CONDENSER CORE - RHD	TATA spare parts
281683400141	ASSY CONDENSER CORE MTG BKT LH	TATA spare parts
281683400142	ASSY CONDENSER CORE MTG BKT RH	TATA spare parts
281683400143	ASSY PRESSURE SWITCH	TATA spare parts
281683400144	ASSY RECEIVER/DRIER COMPLETE - RHD	TATA spare parts
281683400145	ASSY RECEIVER/DRIER MTG BKT - RHD	TATA spare parts
281683400146	ASSY RECEIVER/DRIER CLAMP	TATA spare parts
281683400147	ASSY O-RINGS CONENSER	TATA spare parts
281683400148	ASSY SHROUD CONDENSER FAN	TATA spare parts
281683400149	ASSY FAN CONDENSER	TATA spare parts
281683400150	ASSY MOTOR CONDENSER FAN	TATA spare parts
281683400152	ASSY. FRONT CONDENSER UNIT BS3/4/6	TATA spare parts
281683400153	ASSY. AC UNIT (MANUAL CONTROL) BS3/4/6	TATA spare parts
281683400160	ASSY BLOCK HEATER	TATA spare parts
281683400160AE	ASSY BLOCK HEATER - DBW -1828	TATA spare parts
281683400171	ASSY BLOWER UNIT	TATA spare parts
281683400181	HVAC UNIT ASSY	TATA spare parts
281683400182	AC UNIT ASSY BS6	TATA spare parts

281683400198	EVAPORATOR ASSY BS6	TATA spare parts
281683400199	DRAIN HOSE WITH GROMMET BS6	TATA spare parts
281683400202	ASSY BRKT MTG SIDE CONDENSER	TATA spare parts
281683400203	ASSY.SIDE CONDENSER	TATA spare parts
281683400213	ASSY MTG BKT FOR COND-LHD	TATA spare parts
281683400221	ASSY BRKT MTG SIDE CONDENSER - LPK	TATA spare parts
281683400236	ASSY PROTECTION MUD GUARD FOR SIDE CONDENSER	TATA spare parts
281683400241	ASSY RH MTG BKT TOP FRONT COND	TATA spare parts
281683400242	ASSY LH MTG BKT TOP FRONT COND	TATA spare parts
281683400243	ASSY MTG BKT BOTTOM FRONT COND	TATA spare parts
281683400244	ASSY. AIR COMPRESSOR MULTI PULLEY BS3/4	TATA spare parts
281683400245	ASSY. AC COMPRESSOR SINGLE PULLEY BS3	TATA spare parts
281683403310	MTG BKT TOP FRONT COND	TATA spare parts
281683403311	MTG BKT BOTTOM FOR FRONT COND	TATA spare parts
281683403313	MTG BKT TOP FRONT COND RH	TATA spare parts
281683403314	MTG BKT TOP FRONT COND LH	TATA spare parts
281683403315	MTG BKT BOTTOM FRONT COND RH	TATA spare parts
281683403316	MTG BKT BOTTOM FRONT COND LH	TATA spare parts
281683404101	STAY ROD TOP CONDENSER	TATA spare parts
281683404102	STAY ROD BOTTOM CONDENSER	TATA spare parts
281683404103	STAY ROD BOTTOM CONDENSER-LPK	TATA spare parts
281683404104	STAY ROD BOTTOM CONDENSER ISLE LPK	TATA spare parts
281683406001	PACKING HEATER PIPE	TATA spare parts
281683406002	PACKING-FOR AIR INTAKE HVAC	TATA spare parts
281683406003	PACKING-WIRE HARNESS CUTOUT	TATA spare parts
281683406009	PACKING FOAM FOR HEATER CUTOUT	TATA spare parts
281683406331	FOOT DUCT LH BS6	TATA spare parts
281683406332	FOOT DUCT RH BS6	TATA spare parts
281683406333	ADAPTER DUCT ASSY BS6	TATA spare parts
281683408221	SIDE COND. GUARD MTG BKT	TATA spare parts
281683408801	STUD BS6	TATA spare parts
281683409901	AC REFRIGERANT CHARGE QTY STICKER (450)	TATA spare parts
281683410101	HEATER ASSY	TATA spare parts
281683410102	BLOWER ASSY BS6	TATA spare parts
281683410103	FILTER ASSY BS6	TATA spare parts
281683410104	RESISTOR BLOWER BS6	TATA spare parts
281683410105	WIRING HARNESS	TATA spare parts
281683410109	WIRING HARNESS BS6	TATA spare parts
281683450104	ASSY. CONDENSER UNIT BS4	TATA spare parts
281683453401	BUSH	TATA spare parts
281683457201	PLUG	TATA spare parts
281683457202	PLUG	TATA spare parts
281683457203	CAP FILTER	TATA spare parts
281683457501	GROMMET	TATA spare parts
281683457801	O-RING	TATA spare parts
281683500110	MULTI PULLEY AC COMPRESSOR	TATA spare parts
281683500110AE	ASSY OF SP17 PULLEY AC COMP-1828	TATA spare parts

281683500111	ASSY AC COMPRESSOR SINGLE PULLEY	TATA spare parts
281683550105	COMPRESSOR ASSY	TATA spare parts
281683600103	ASSY HEATER HOSE-INLET (ENG TO HVAC) FOR	TATA spare parts
281683600104	ASSY HEATER HOSE-OUTLET (HVAC TO ENG) FO	TATA spare parts
281683600113	ASSY MTG BKT FOR AC PIPING	TATA spare parts
281683600118	ASSY HEATER HOSE-INLET(ENGINE TO HVAC)	TATA spare parts
281683600119	ASSY HEATER HOSE-OUTLET(HVAC TO ENGINE )	TATA spare parts
281683600122	ASSY HEATER HOSE-INLET (ENG TO HVAC) ISL	TATA spare parts
281683600123	ASSY HEATER HOSE-OUTLET (HVAC TO ENG) IS	TATA spare parts
281683600128	ASSY HEATER HOSE-OUTLET (HVAC TO ENG)	TATA spare parts
281683600133	KIT-DRAIN HOSE HVAC	TATA spare parts
281683600135	ASSY MTG BKT- L SHAPE	TATA spare parts
281683600136	ASSY MTG BKT WITH WELD STUD	TATA spare parts
281683600138	ASSY HEATER HOSE OUTLET FOR LPS ISLE	TATA spare parts
281683600154	ASSY HEATER HOSE INLET LPS ISLE	TATA spare parts
281683600166	ASSY MTG BKT FOR HEATER PIPE	TATA spare parts
281683600175	KIT DRAIN HOSE FOR HVAC ISLE	TATA spare parts
281683600186	ASSY MTG BKT FOR AC PIPES	TATA spare parts
281683600206	ASSY.REFRIGENT HOSE SUCTION SIDE	TATA spare parts
281683600207	ASSY.REFRIGENT HOSE SUCTION DISCHARGE	TATA spare parts
281683600209	ASSY.REFRIGENT HOSE LIQUID	TATA spare parts
281683600209F	REFRIGERANT DISCHARGE LINE	TATA spare parts
281683600301	LIQUID PIPE ASSY	TATA spare parts
281683600302	SUCTION PIPE ASSY	TATA spare parts
281683600303	SUCTION PIPE ASSY	TATA spare parts
281683600304	DISCHARGE PIPE ASSY	TATA spare parts
281683600315	SUCTION PIPE ASSY	TATA spare parts
281683600316	SUCTION PIPE ASSY	TATA spare parts
281683600317	DISCHARGE PIPE ASSY	TATA spare parts
281683600318	LIQUID PIPE ASSY	TATA spare parts
281683600319	SUCTIONPIPE COMPRESSOREND BS6	TATA spare parts
281683600320	DISCHARGEPIPE COMPRESSOREND BS6	TATA spare parts
281683603307	MTG BKT FOR HEATER HOSE	TATA spare parts
281683603309	MTG BKT FOR HEATER HOSE	TATA spare parts
281683603314	MOUNTING BRACKET	TATA spare parts
281683603315	L-BKT FOR HOSE MTG	TATA spare parts
281683603319	MTG BKT FOR HEATER HOSE	TATA spare parts
281683603320	MTG BKT FOR AC PIPES	TATA spare parts
281683603321	MTG BKT FOR SUCTION PIPE	TATA spare parts
281683603325	MTG BKT FOR AC PIPES (FIREWALL MTD)	TATA spare parts
281683603329	MTG BKT FOR HEATER PIPES	TATA spare parts
281683603331	MTG BKT FOR HEATER PIPE	TATA spare parts
281683603332	MTG BKT FOR HEATER PIPE	TATA spare parts
281683603334	MTG BKT FOR HEATER PIPE	TATA spare parts
281683603338	MTG BKT FOR AC PIPES	TATA spare parts
281683603340	MTG BKT FOR HEATER PIPES	TATA spare parts
281683603346	MTG BKT FOR AC PIPES	TATA spare parts

281683603356	MTG BKT FOR HEATER PIPES	TATA spare parts
281683603357	MTG BKT FOR HEATER PIPES	TATA spare parts
281683603358	MTG BKT FOR HEATER PIPES	TATA spare parts
281683603359	MTG BKT FOR AC PIPES	TATA spare parts
281683603362	MTG BKT FOR AC PIPES	TATA spare parts
281683603363	MTG BKT FOR HEATER PIPES	TATA spare parts
281683603364	MTG BKT FOR HEATER PIPES	TATA spare parts
281683603367	MTG BKT FOR AC PIPES	TATA spare parts
281683603368	MTG BKT FOR AC PIPES	TATA spare parts
281683603369	MTG BKT FOR AC PIPES	TATA spare parts
281683603371	MTG BKT FOR AC PIPES	TATA spare parts
281683603379	COMPRESSOR MTD BKT FOR AC PIPES	TATA spare parts
281683603382	MTG BRKT FOR AC PIPING	TATA spare parts
281683603384	MTG BKT FOR AC PIPES	TATA spare parts
281683603386	MTG BKT FOR AC PIPES (FIREWALL MTD)	TATA spare parts
281683604204	P-CLAMP (DIA.20 X 18W)	TATA spare parts
281683604207	CLAMP FOR AC HOSES	TATA spare parts
281683604211	P-CLAMP(DIA 9)	TATA spare parts
281683604213	CLAMP FOR AC HOSES	TATA spare parts
281683604214	U CLAMP FOR HEATER HOSES	TATA spare parts
281683604217	CLAMP	TATA spare parts
281683604218	P-CLAMP DIA 18	TATA spare parts
281683604302	CLIP FOR AC PIPING	TATA spare parts
281683604303	CLIP FOR AC PIPING	TATA spare parts
281683605804	DRAIN HOSE BS6	TATA spare parts
281683606901	REFRIGERANT SUCTION LINE	TATA spare parts
281683606902	REFRIGERANT DISCHARGE LINE	TATA spare parts
281683606906	REFRIGERANT SUCTION LINE FOR ISBE LPK LH	TATA spare parts
281683606907	REFRIGERANT HOSE DISCHARGE ISBE LPK LHD	TATA spare parts
281683606910	REFRIGERANT DISCHARGE LINE LPS ISLE LHD	TATA spare parts
281683606911	REFRIGERANT LIQUID LINE LPS ISLE LHD	TATA spare parts
281683606926	REFRIGERANT SUCTION LINE LPS ISLE LHD	TATA spare parts
281683606931	REFRIGERANT DISCHARGE LINE	TATA spare parts
281683606932	REFRIGERANT SUCTION LINE	TATA spare parts
281683606933	REFRIGERANT DISCHARGE LINE	TATA spare parts
281683606934	REFRIGERANT LIQUID LINE	TATA spare parts
281683606941	REFRIGERANT LIQUID LINE	TATA spare parts
281683606942	REFRIGERANT SUCTION LINE M0 ISBE FC	TATA spare parts
281683606943	REFRIGERANT DISCHARGE LINE M0 ISBE FC	TATA spare parts
281683606944	REFRIGERANT LIQUID LINE M0 ISBE FC	TATA spare parts
281683606945	REFRIGERANT DISCHARGE LINE ISLE LPK	TATA spare parts
281683606946	REFRIGERANT LIQUID LINE ISLE LPK FC-I	TATA spare parts
281683606947	REFRIGERANT LIQUID LINE ISLE LPK FC-II	TATA spare parts
281683606948	REFRIGERANT LIQUID LINE ISBE LPK FRONT C	TATA spare parts
281683606949	REFRIGERANT LIQUID LINE ISBE LPK FRONT C	TATA spare parts
281683606950	REFRIGERANT LIQUID LINE ISLE LPK FC	TATA spare parts
281683607701	HEATER HOSE INLET FOR ISLE	TATA spare parts

281683607702	HEATER HOSE OUTLET FOR ISLE	TATA spare parts
281683607706	CONNECTOR	TATA spare parts
281683607710	HEATER HOSE OUTLET(HVAC TO AUX.COOLANT T	TATA spare parts
281683607712	DRAIN HOSE FOR HVAC UNIT	TATA spare parts
281683607715	CLIP PLASTIC FOR DRAIN HOSE MTG	TATA spare parts
281683607722	HEATER HOSE INLET WITH CORRUGATED AL SLE	TATA spare parts
281683607723	PIPE FOR HEATER HOSE OUTLET ISLE	TATA spare parts
281683607724	HEATER HOSE OUTLET ISLE	TATA spare parts
281683607736	HEATER HOSE-OUTLET FOR LPK ISBE	TATA spare parts
281683607741	HEATER HOSE OUTLET ISLE LPK	TATA spare parts
281683607742	HEATER HOSE OUTLET ISLE LPK	TATA spare parts
281683607743	HEATER HOSE INLET ISLE LPK	TATA spare parts
281683607744	PIPE FOR HEATER HOSE OUTLET ISLE LPK	TATA spare parts
281683607745	PIPE FOR HEATER HOSE INLET ISLE LPK	TATA spare parts
281683607746	DRAIN HOSE FOR HVAC UNIT FOR ISLE	TATA spare parts
281683607750	DRAIN HOSE FOR ISLE LHD	TATA spare parts
281683607760	REDUCER HEATER HOSE (ID18 TO ID16) INLET	TATA spare parts
281683607770	PIPE FOR HEATER HOSE INLET ISLE LPS	TATA spare parts
281683650104	HEATER HOSE ASSY HVAC TO ENGINE	TATA spare parts
281683650106	HEATER HOSE ASSY INLET	TATA spare parts
281683750114	BRACKET ASSY CONDENSER MTG	TATA spare parts
281683750115	BRACKET ASSY CONDENSER MTG	TATA spare parts
281683750116	BRACKET ASSY AC PIPE MTG	TATA spare parts
281683750117	BRACKET ASSY AC PIPE MTG	TATA spare parts
281683750118	BRACKET ASSY AC PIPE MTG	TATA spare parts
281683750127	BRACKET ASSY WITH WELD NUT	TATA spare parts
281683750128	BRACKET ASSY WITH WELD NUT	TATA spare parts
281683750136	BRACKET ASSY CONDENSER MTG BS6	TATA spare parts
281683750137	BRACKET ASSY CONDENSER MTG BS6	TATA spare parts
281683750138	BRACKET ASSY CONDENSER MTG BS6	TATA spare parts
281683750139	BRACKET ASSY CONDENSER MTG BS6	TATA spare parts
281683753321	BRACKET HEATER HOSE MTG	TATA spare parts
281683753322	BRACKET ASSY HEATER PIPE MTG	TATA spare parts
281683784201	CLAMP AC PIPE	TATA spare parts
281683784202	CLAMP AC PIPE	TATA spare parts
281683784203	CLAMP AC PIPE	TATA spare parts
281683800101	KIT REAR AIR EXTRACTOR	TATA spare parts
281683800105	ASSY REAR AIR EXTRACTOR	TATA spare parts
281683805301	GASKET Baffle REAR AIR EXTRACTOR	TATA spare parts
281683805302	GROMMET FOR AIR EXTRACTOR	TATA spare parts
281683806302	COVER WATER PROTECTION	TATA spare parts
281683807702	GRILL FRESH AIR INTAKE	TATA spare parts
281683807703	BODY GRILL PLASTIC FRESH AIR INTAKE	TATA spare parts
281683807707	PACKING FOAM FOR FRESH AIR GRILL	TATA spare parts
281683807716	PACKING FRESH AIR GRILLE	TATA spare parts
281683990101	KIT SIDE CONDENSER MUD GUARD	TATA spare parts
281683990102	SPARE KIT OF FRONT CONDENSER FOR 2528.K	TATA spare parts

281684100102	ASSY LATCH HEADBOX	TATA spare parts
281684100103	ASSY HEAD BOX C LO	TATA spare parts
281684100104	ASSY HEADBOX C FL RHD	TATA spare parts
281684100109	ASSY BRACKET SIDE HEADBOX LOWER LH	TATA spare parts
281684100110	ASSY BRACKET SIDE HEADBOX LOWER RH	TATA spare parts
281684100113	ASSY STRUCTURE HEADBOX	TATA spare parts
281684100114	ASSY STRUCTURE HEAD BOX C FLAT	TATA spare parts
281684100115	ASSY PARTITION HEADBOX LOW	TATA spare parts
281684100117	SUB ASSEMBLY HEADBOX UPPER	TATA spare parts
281684100118	SUB ASSEMBLY HEADBOX LOWER	TATA spare parts
281684100119	SUB ASSEMBLY LID HEADBOX LH	TATA spare parts
281684100120	SUB ASSEMBLY LID HEADBOX RH	TATA spare parts
281684100122	ASSY BRACKET SPEAKER HEADBOX C	TATA spare parts
281684100123	ASSY BRACKET SPEAKER HEADBOX RH	TATA spare parts
281684100124	SUB ASSY COVER HEADBOX LH C FL RHD	TATA spare parts
281684100125	SUB ASSY COVER HEADBOX C RH FL RHD	TATA spare parts
281684100126	SUB ASSEMBLY COVER HEADBOX C CENTER FLAT	TATA spare parts
281684100127	SUB ASSY COVER HEADBOX CENTER LOW	TATA spare parts
281684100130	ASSY BKT BOTTOM HEADBOX LWR LH	TATA spare parts
281684100131	ASSY BKT BOTTOM HEAD BOX LWR RH	TATA spare parts
281684100132	ASSY BRACKET BOTTOM HEADBOX LOWER CENTER	TATA spare parts
281684100134	SUB ASSY HEADBOX LOWER CAB C FLAT RHD	TATA spare parts
281684100136	ASSY HEADBOX C CAB LOW M0 VERSION	TATA spare parts
281684100149	HEADBOX ASSY BS6-PH2	TATA spare parts
281684100152	BRACKET ASSY HEADBOX MTG LH BS6	TATA spare parts
281684100153	BRACKET ASSY HEADBOX MTG RH BS6	TATA spare parts
281684100154	BRACKET ASSY HEADBOX MTG LH BS6	TATA spare parts
281684100155	BRACKET ASSY HEADBOX MTG RH BS6	TATA spare parts
281684100159	HEADBOX ASSY LOWER BS6-PH2	TATA spare parts
281684103310	BKT TOP HEADBOX CENTER	TATA spare parts
281684106303	COVER STORAGE HEADBOX C FL	TATA spare parts
281684106318	STORAGE HEADBOX LH	TATA spare parts
281684106319	STORAGE HEADBOX RH	TATA spare parts
281684106327	GRILL SPEAKER HEADBOX LH	TATA spare parts
281684106330	GRILL SPEAKER HEADBOX RH	TATA spare parts
281684106331	FRAME ELECTRICAL PANEL MTG	TATA spare parts
281684106340	DUMMY CAP HEADBOX UPPER LH	TATA spare parts
281684106341	DUMMY CAP HEADBOX UPPER RH	TATA spare parts
281684106342	DUMMY CAP HEADBOX UPPER CENTER LH	TATA spare parts
281684106343	DUMMY CAP HEADBOX UPPER CENTER RH	TATA spare parts
281684106358	CAP HEADBOX UPPER-LH BS6-PH2	TATA spare parts
281684106359	CAP HEADBOX UPPER-RH BS6-PH2	TATA spare parts
281684106701	LOCATING PIN HEADBOX	TATA spare parts
281684106702	LOCATING PIN HEADBOX BS6	TATA spare parts
281684108701	SPRING - HEADBOX LID	TATA spare parts
281688000109	ASSY BUMPER COMPLETE	TATA spare parts
281688100110	FOOT BOARD ASSY FENDER LH	TATA spare parts

281688100111	FOOT BOARD ASSY FENDER RH	TATA spare parts
281688100112	FRONT FENDER ASSY LH BS6	TATA spare parts
281688100114	FRONT FENDER ASSY RH BS6-PH2	TATA spare parts
281688100147	ASSY SUPPORT REAR FENDER FRONT LH C	TATA spare parts
281688100148	ASSY SUPPORT REAR FENDER FRONT RH C	TATA spare parts
281688100154	ASSY COVER TILTING PUMP_LH	TATA spare parts
281688100155	ASSY COVER TILTING PUMP_RH	TATA spare parts
281688100162	ASSY FENDER FRONT REAR BRKT LH	TATA spare parts
281688100163	ASSY FENDER FRONT REAR BRKT RH	TATA spare parts
281688100170	FRT FENDER A LH	TATA spare parts
281688100171	FRT FENDER A RH	TATA spare parts
281688100190	ASSY FENDER FRONT LH M0 VEHICLE	TATA spare parts
281688100191	ASSY FENDER FRONT RH M0 VEHICLE	TATA spare parts
281688100194	ASSY BRKT STR MTG FENDER FRONT LH M0	TATA spare parts
281688100214	ASSY BRKT FUPD MTG FENDER FRONT LH	TATA spare parts
281688100216	ASSY STEP MTG FRAME FENDER FRONT LH	TATA spare parts
281688100217	ASSY STEP MTG FRAME FENDER FRONT RH M0	TATA spare parts
281688100218	ASSY COVER A-CAB TILTING	TATA spare parts
281688100219	ASSY BRKT REAR MTG FENDER FRONT LH M0	TATA spare parts
281688100220	ASSY BRKT REAR MTG FENDER FRONT RH M0	TATA spare parts
281688100221	ASSY FOOTSTEP FRAME FENDER BOTTOM LH	TATA spare parts
281688100222	ASSY FOOTSTEP FRAME FENDER BOTTOM RH	TATA spare parts
281688100244	ASSY FENDER FRONT LH M0 VEHICLE	TATA spare parts
281688100264	ASSY PLASTIC WASHER & CAP FOR M6 SCREW	TATA spare parts
281688100265	ASSY FENDER FRONT RH M0 LHD IB	TATA spare parts
281688100269	STRUCTURE ASSY FENDER FRONT-RH BS6	TATA spare parts
281688103701	BKT FENDER MTG	TATA spare parts
281688103704	FENDER CASTING MTG BRAKET LH	TATA spare parts
281688103705	FENDER CASTING MTG BRAKET RH	TATA spare parts
281688103807	STEP BOARD CAB C	TATA spare parts
281688103808	STEPBOARD FENDER RH	TATA spare parts
281688106301	FENDER FRONT LH	TATA spare parts
281688106302	FENDER FRONT RH	TATA spare parts
281688106305	COVER TILTING PUMP_LH	TATA spare parts
281688106306	COVER_HEAD_LAMP_ADJUSTMENT_LH	TATA spare parts
281688106308	COVER HEAD LAMP ADJUSTMENT RH	TATA spare parts
281688106309	FRONT LINER LH	TATA spare parts
281688106311	FENDER FRONT LH-PAINTED	TATA spare parts
281688106312	FENDER FRONT RH-PAINTED	TATA spare parts
281688106319	LINING FENDER FRT LH	TATA spare parts
281688106320	LINING FENDER FRT RH	TATA spare parts
281688106326	FENDER FRONT LH (LHD)	TATA spare parts
281688106327	FENDER FRONT RH	TATA spare parts
281688106334	LINER FENDER FRONT LH	TATA spare parts
281688106335	LINER FENDER FRONT RH M0	TATA spare parts
281688106355	LINER FRONT FENDER LH BS6-PH2	TATA spare parts
281688106356	LINER FRONT FENDER RH BS6-PH2	TATA spare parts

281688106357	HEADLAMP ACCESS COVER LH BS6-PH2	TATA spare parts
281688106358	HEADLAMP ACCESS COVER RH BS6-PH2	TATA spare parts
281688106901	PIPE_FRONT LINEAR LH	TATA spare parts
281688106902	PIPE TOP MTG FRT FENDER LH	TATA spare parts
281688106905	PIPE REINFORCEMENT SIDE LH	TATA spare parts
281688106906	PIPE REINFORCEMENT SIDE RH	TATA spare parts
281688106908	PIPE_FRONT LINEAR LH	TATA spare parts
281688106909	PIPE_FRONT LINEAR RH	TATA spare parts
281688106914	PIPE TOP MTG FRONT FENDER LH BS6-PH2	TATA spare parts
281688106916	PIPE REINFORCEMENT SIDE LH BS6-PH2	TATA spare parts
281688106917	PIPE REINFORCEMENT SIDE RH BS6-PH2	TATA spare parts
281688106918	PIPE TOP MTG FRONT FENDER LH BS6-PH2	TATA spare parts
281688108226	FENDER MTG SHEET BRKT	TATA spare parts
281688108227	FENDER MTG SHEET BRKT RH	TATA spare parts
281688108228	MOUNTING BRACKET FRONT LINER LH	TATA spare parts
281688108229	MOUNTING BRACKET FRONT LINER RH	TATA spare parts
281688108236	FENDER FRONT UPPER BRKT LH	TATA spare parts
281688108237	FENDER FRONT UPPER BRKT RH	TATA spare parts
281688108251	FENDER FRONT STEP LH	TATA spare parts
281688108252	FENDER FRONT STEP RH	TATA spare parts
281688108297	WASHER ELONG M6	TATA spare parts
281688110101	STRUCTURE ASSY FENDER FRONT-LH BS6-PH2	TATA spare parts
281688110102	STRUCTURE ASSY FENDER FRONT-RH BS6-PH2	TATA spare parts
281688110105	FOOT STEP ASSY FENDER LH BS6-PH2	TATA spare parts
281688110106	FOOT STEP ASSY FENDER RH BS6-PH2	TATA spare parts
281688110107	FOOT STEP ASSY FENDER LH BS6-PH2	TATA spare parts
281688110108	FOOT STEP ASSY FENDER RH BS6-PH2	TATA spare parts
281688110111	FRONT FENDER TRIM ASSY LH BS6-PH2	TATA spare parts
281688118212	FOOT STEP LOWER-LH BS6-PH2	TATA spare parts
281688118213	FOOT STEP LOWER-RH BS6-PH2	TATA spare parts
281688200101	ASSY. FENDER REAR LH	TATA spare parts
281688200102	ASSY. FENDER REAR RH	TATA spare parts
281688200110	PIPE ASSY FENDER TOP MTG REAR-RH BS6	TATA spare parts
281688200123	ASSY STRUCTURE FENDER REAR C	TATA spare parts
281688200135	ASSY FENDER REAR LH-PAINTED	TATA spare parts
281688200136	ASSY FENDER REAR RH-PAINTED	TATA spare parts
281688200137	ASSY PIPE STRUCTURE REAR LH	TATA spare parts
281688200138	ASSY FENDER REAR PIPE STRUCTURE BOTTOM R	TATA spare parts
281688200139	ASSY FENDER REAR PIPE STRUCTURE TOP MTG	TATA spare parts
281688200153	ASSY STRUCTURE FENDER REAR LH	TATA spare parts
281688200154	ASSY STRUCTURE FENDER REAR RH	TATA spare parts
281688200155	FENDER REAR ASSY TOP MTG PIPE LH	TATA spare parts
281688200156	FENDER REAR ASSY TOP MTG PIPE RH	TATA spare parts
281688200160	ASSY STR FENDER REAR RH NSLPR	TATA spare parts
281688200162	ASSY FENDER REAR TOP MTG RH NSLPR	TATA spare parts
281688200170	ASSY STAY ROD LH	TATA spare parts
281688200171	ASSY STAY ROD RH	TATA spare parts



281688200176	ASSY FNDR REAR MTG PIPE SLPR RH	TATA spare parts
281688206301	FENDER REAR LH	TATA spare parts
281688206302	FENDER REAR RH	TATA spare parts
281688206305	SPRAY SUPPRESSION LH MO VEHICLE	TATA spare parts
281688206306	SPRAY SUPPRESSION RH MO VEHICLE	TATA spare parts
281688206307	UD FLAP SPRAY SUPPRESSION REAR FENDER L	TATA spare parts
281688206308	FENDER SIDE REAR LH	TATA spare parts
281688206309	FENDER SIDE REAR RH	TATA spare parts
281688206310	MUD FLAP SPRAY SUPPRESSION REAR FENDER R	TATA spare parts
281688206313	FENDER REAR RH MO	TATA spare parts
281688206317	FRT MUD GUARD_LH TML	TATA spare parts
281688206318	FRT MUD GUARD_RH	TATA spare parts
281688206325	SPRAY SUPPRESSION REAR FENDER ON ROAD LH	TATA spare parts
281688206326	SPRAY SUPPRESSION REAR FENDER ON ROAD RH	TATA spare parts
281688206327	FENDER REAR LH 3128 C CONS	TATA spare parts
281688206328	FENDER REAR RH 3128 C CONS	TATA spare parts
281688206329	FENDER REAR LH MO	TATA spare parts
281688206330	FENDER REAR RH MO	TATA spare parts
281688206358	REAR FENDER LH BS6-PH2	TATA spare parts
281688206359	REAR FENDER RH BS6-PH2	TATA spare parts
281688206913	FENDER REAR TOP MTG SQ.TUBE	TATA spare parts
281688206923	FENDER REAR LH TOP MTG PIPE	TATA spare parts
281688208249	TUBE REAR FENDER MTG TOP BS6	TATA spare parts
281688210101	PIPE ASSY STRUCTURE REAR-LH	TATA spare parts
281688210102	REAR FENDER ASSY PIPE STR BOTTOM-RH	TATA spare parts
281688210103	PIPE ASSY FENDER TOP MTG REAR-RH	TATA spare parts
281688216301	LINING FENDER FRONT-LH BS6	TATA spare parts
281688216302	LINING FENDER FRONT-RH BS6	TATA spare parts
281688300103	ASSY HINGE FOOT BOARD BUMPER CARGO LH	TATA spare parts
281688300105	ASSY FOOT BOARD BASE PLATE CARGO	TATA spare parts
281688300111	ASSY ANTI SKID PAD BUMPER UPPER FOOT STE	TATA spare parts
281688300112	ASSY NEW LOCKING BUMPER FOOTSTEP	TATA spare parts
281688300116	ASSY ANTI SKID PAD BUMPER FOOT STEP	TATA spare parts
281688300117	ASSY ANTI SKID PAD BUMPER STEP PRIMA LX	TATA spare parts
281688300130	CABIN FENDER ASSY LH BS6-PH2	TATA spare parts
281688300131	CABIN FENDER ASSY RH BS6-PH2	TATA spare parts
281688303701	FOOT STEP FOLDING LINK	TATA spare parts
281688303702	HINGE MTG BKT FOOT STEP CARGO	TATA spare parts
281688304201	LOCK PIN FOOT STEP BUMPER CARGO	TATA spare parts
281688306318	GRILL FRONT BUMPER CARGO	TATA spare parts
281688306704	PIN FOR HINGE MTG BKT FOOT STEP CARGO	TATA spare parts
281688400101	ASSY FENDER JOINARY LH	TATA spare parts
281688400102	ASSY SUPPORT FENDER JOINARY RH	TATA spare parts
281688400113	ASSY MIDDLE REINF SUPPORT FENDER JOINERY	TATA spare parts
281688400114	ASSY MIDDLE REINF SUPPORT FENDER JOINERY	TATA spare parts
281688500101	ASSY BUMPER COMPLETE	TATA spare parts
281688500144	ASSY BUMPER SIDE MTG BKT LH	TATA spare parts

281688500145	ASSY BUMPER SIDE MTG BKT RH	TATA spare parts
281688500171	ASSY BUMPER SIDE ADD ON LH	TATA spare parts
281688500172	ASSY BUMPER SIDE ADD ON RH	TATA spare parts
281688500187	ASSY REST FOOT PIPE	TATA spare parts
281688500196	ASSY MIDDLE BUMPER	TATA spare parts
281688500206	ASSY BUMPER_UPPER BRKT SQUARE	TATA spare parts
281688500210	ASSY PIPE SUPPORT SIDE BUMPER LH	TATA spare parts
281688500211	ASSY PIPE SUPPORT SIDE BUMPER RH	TATA spare parts
281688500212	ASSY PIPE TOP MTG BUMPER SIDE LH	TATA spare parts
281688500213	ASSY PIPE TOP MTG BUMPER SIDE RH	TATA spare parts
281688500235	ASSY BUMPER COMPLETE LHD	TATA spare parts
281688503711	CASTING BKT BUMPER FENDER LH	TATA spare parts
281688503712	CASTING BKT BUMPER FENDER RH	TATA spare parts
281688506302	BUMPER_CENTER_C_CARGO	TATA spare parts
281688506303	BUMPER SIDE LH	TATA spare parts
281688506304	BUMPER SIDE NRH	TATA spare parts
281688506308	GRILL BUMPER TOP CARGO	TATA spare parts
281688506309	GRILL FRONT BUMPER LH BS6-PH2	TATA spare parts
281688506312	COVER FOG LAMP LH	TATA spare parts
281688506313	COVER FOG LAMP RH	TATA spare parts
281688506319	BUMPER CENTER-PAINTED	TATA spare parts
281688506320	BUMPER SIDE LH-PAINTED	TATA spare parts
281688506321	BUMPER SIDE RH-PAINTED	TATA spare parts
281688506322	GRILL FRONT BUMPER BOTTOM BS6	TATA spare parts
281688506326	MIDDLE BUMPER ADD-ON STEP	TATA spare parts
281688506341	BUMPER SIDE LH	TATA spare parts
281688506342	BUMPER SIDE RH	TATA spare parts
281688507701	BEAD MIDDLE BUMPER UPPER	TATA spare parts
281688507703	BEAD SIDE BUMPER UPPER STEERING SIDE	TATA spare parts
281688508231	BUMPER MTG BRACKET FRONT LH	TATA spare parts
281688508232	BUMPER MTG BRACKET FRONT RH	TATA spare parts
281688508283	PIPE HOLDER FOOT STEP LH	TATA spare parts
281688508284	PIPE HOLDER FOOT STEP RH	TATA spare parts
281688510114	ASSY PIPE HOLDER FOOT STEP LH	TATA spare parts
281688510115	ASSY PIPE HOLDER FOOT STEP RH	TATA spare parts
281688510130	ASSY BRKT BUMPER FRONT MTG	TATA spare parts
281688510136	ASSY CROSS MEMBER MTG FRONT BRKT M0	TATA spare parts
281688510143	ASSY CROSS MBR BRKT FRAME MTG LH M0	TATA spare parts
281688510144	ASSY CROSS MBR BRKT FRAME MTG RH M0	TATA spare parts
281688510147	ASSY BUMPER FOOTSTEP STRUCTURE	TATA spare parts
281688510167	ASSY PIPE STR BUMPER STEP	TATA spare parts
281688510168	ASSY. MIDDLE BUMPER SLPR BS3/4	TATA spare parts
281688510169	ASSY ADDON SLPR LOWER MTG LH M0	TATA spare parts
281688510170	BUMPER ADON	TATA spare parts
281688510172	ASSY PIPE TOP MTG BUMPER LH	TATA spare parts
281688510173	ASSY PIPE TOP MTG BUMPER RH	TATA spare parts
281688510174	ASSY BRKT MIDDLE BPR FUPD LH M0	TATA spare parts

281688510175	ASSY BRKT MIDDLE BPR FUPD RH M0	TATA spare parts
281688510176	ASSY BRKT MIDDLE BUMPR FOG MTG LH M0	TATA spare parts
281688510177	ASSY BRKT MIDDLE BUMPR FOG MTG RH M0	TATA spare parts
281688510178	ASSY BKT HEADLAMP MTG LH M0	TATA spare parts
281688510179	ASSY BKT HEADLAMP MTG RH M0	TATA spare parts
281688510180	ASSY MIDDLE BUMPER HEAD LAMP BRKT LH	TATA spare parts
281688510181	ASSY MIDDLE BUMPER HEAD LAMP BRKT RH	TATA spare parts
281688510182	ASSY MIDDLE BUMPER M0 NSLPR	TATA spare parts
281688510185	ASSY BRKT ADDON MIDDLE BPR M0 LH NSLPR	TATA spare parts
281688510186	ASSY BRKT ADDON MIDDLE BPR M0 RH NSLPR	TATA spare parts
281688510187	ASSY BRKT MTG MIDDLE BUMPER M0	TATA spare parts
281688510199	BUMPER MTG ASSY CROSS MEMBER LH ME NS	TATA spare parts
281688510200	BUMPER MTG ASSY CROSS MEMBER RH ME NS	TATA spare parts
281688510204	ASSY BUMPER UPPER BRKT	TATA spare parts
281688510221	BUMPER ASSY LOWER MTG LH ME PRIMA NS	TATA spare parts
281688510222	BUMPER ASSY LOWER MTG RH ME PRIMA NS	TATA spare parts
281688510223	BUMPER FRONT MTG ASSY LH ME PRIMA NS	TATA spare parts
281688510224	BUMPER FRONT MTG ASSY RH ME PRIMA NS	TATA spare parts
281688513308	BRKT MTG MIDDLE BUMPER M0	TATA spare parts
281688516303	FOG LAMP BEZEL LH	TATA spare parts
281688516304	FOG LAMP BEZEL RH	TATA spare parts
281688516305	BEZEL WITH DUMMY FOG LAMP LH	TATA spare parts
281688516306	BEZEL WITH DUMMY FOG LAMP RH	TATA spare parts
281688516701	BUMPER GUIDE PIN M0	TATA spare parts
281688518225	BUMPER FOOT STEP	TATA spare parts
281688518266	GRILL BUMPER TOP NSLPR	TATA spare parts
281688518281	BUMPER MIDDLE M0	TATA spare parts
281688518282	BUMPER ADDON NSLPR LH	TATA spare parts
281688518283	BUMPER ADDON NSLPR RH	TATA spare parts
281688518284	BUMPER ADDON SLPR	TATA spare parts
281688518285	BRKT REINF HEADLAMP TOP SIDE LH M0	TATA spare parts
281688518286	BRKT REINF HEADLAMP TOP SIDE RH M0	TATA spare parts
281688518294	BRKT MTG HEADLAMP MIDDLE BUMPER LH M0	TATA spare parts
281688518295	BRKT MTG HEADLAMP MIDDLE BUMPER RH M0	TATA spare parts
281688518296	BRKT REINF HEADLAMP BOTTOM SIDE LH M0	TATA spare parts
281688518297	BRKT REINF HEADLAMP BOTTOM SIDE RH M0	TATA spare parts
281688520104	ASSY CROSS MBR BUMPER COMPLETE M0 C CON	TATA spare parts
281688520111	ASSY PIPE FOOT STEP STR SLPR M0	TATA spare parts
281688520134	ASSY GRILL BUMPER PRIMA LX IB LH	TATA spare parts
281688520135	ASSY GRILL BUMPER PRIMA LX IB RH	TATA spare parts
281688520137	ASSY BMPR MDL SLPR COMPLETE PRIMA LX IB	TATA spare parts
281688520138	ASSY. BUMPER MDL PRIMA LX IB BS3/4	TATA spare parts
281688520140	ASSY ADDON SLPR LOWER MTG RUSSIA LH	TATA spare parts
281688520141	ASSY ADDON SLPR LOWER MTG RUSSIA RH	TATA spare parts
281688520148	ASSY SQ.TUBE MDL BMPR SLPR LX W/O ADDON	TATA spare parts
281688520151	ASSY BKTS BMPR SD MTG LX SLPR LH	TATA spare parts
281688520152	ASSY BKTS BMPR SD MTG LX SLPR RH	TATA spare parts

281688520158	BRACKET ASSY MIDDLE BUMPER LH BS6	TATA spare parts
281688520159	BRACKET ASSY MIDDLE BUMPER RH BS6	TATA spare parts
281688520166	BRACKET ASSY MIDDLE BUMPER LH BS6-PH2	TATA spare parts
281688520167	BRACKET ASSY MIDDLE BUMPER RH BS6-PH2	TATA spare parts
281688520168	BUMPER ASSY UPPER BS6-PH2	TATA spare parts
281688520169	BRACKET ASSY CROSS MEMBER MTG LH BS6-PH2	TATA spare parts
281688520170	BRACKET ASSY CROSS MEMBER MTG RH BS6-PH2	TATA spare parts
281688520172	BUMPER ASSY BS6-PH2	TATA spare parts
281688520177	BRACKET ASSY BUMPER SIDE MTG LH BS6-PH2	TATA spare parts
281688520178	BRACKET ASSY BUMPER SIDE MTG RH BS6-PH2	TATA spare parts
281688520185	BRACKET ASSY CROSS MEMBER FRAME MTG LH BS6-PH2	TATA spare parts
281688520186	BRACKET ASSY CROSS MEMBER FRAME MTG RH BS6-PH2	TATA spare parts
281688520187	CROSS MEMBER ASSY BUMPER MTG BS6-PH2	TATA spare parts
281688528201	BUMPER UPPER MIDDLE M0	TATA spare parts
281688528202	BUMPER UPPER LH M0	TATA spare parts
281688528203	BUMPER UPPER RH M0	TATA spare parts
281688528206	BUMPER FOOT STEP NSLPR	TATA spare parts
281688528240	GRILL BUMPER TOP PRIMA BASE	TATA spare parts
281688528264	BUMPER MIDDLE PRIMA LX IB	TATA spare parts
281688530104	BRACKET ASSY BUMPER MTG LOWER FRONT-LH BS6	TATA spare parts
281688530105	BRACKET ASSY BUMPER MTG LOWER FRONT-RH BS6	TATA spare parts
281688530110	BRACKET ASSY BUMPER SIDE MTG LH BS6	TATA spare parts
281688530111	BRACKET ASSY BUMPER SIDE MTG RH BS6	TATA spare parts
281688530123	GRILL ASSY HEADLAMP LH BS6-PH2	TATA spare parts
281688530124	GRILL ASSY HEADLAMP RH BS6-PH2	TATA spare parts
281688538243	ADD ON BUMPER BS6	TATA spare parts
281688990103	RETRO KIT OF M0 BMPR FNDR ASSY ON PRIMA	TATA spare parts
281689100101	ASSY FRONT STRUT COMPLETE	TATA spare parts
281689100102	ASSY REAR STRUT COMPLETE	TATA spare parts
281689100103	LATERAL SHOCK ABSORBER BS3/4	TATA spare parts
281689100103AE	LAT SHOCK ABS LPTA 1628/LPTA1828	TATA spare parts
281689100104	ASSY BRKT LATERAL S ABS MTG LH	TATA spare parts
281689100105	ASSY BKT LATERAL S ABS MTG NRH	TATA spare parts
281689100106	CAB TILTING CYLINDER	TATA spare parts
281689100108	LATCH	TATA spare parts
281689100118	ASSY BUMP STOPPER	TATA spare parts
281689100122	ASSY STRIKER COMPLETE	TATA spare parts
281689100128	ASSY PIPE TEE JOINT TO TEE JOINT	TATA spare parts
281689100138	ASSY STRIKER PLATE NON SLEEPER	TATA spare parts
281689100139	ASSY MTG BKT LAT S/A C CONS LH	TATA spare parts
281689100140	ASSY LAT SA MTG LH C CONST RH	TATA spare parts
281689100146	PIVOT BUSH	TATA spare parts
281689100148	ASSY HYDRAULIC CAB LATCH NRH	TATA spare parts
281689100149	ASSY BRKT FRONT SHOCK ABSORBER MTG LH	TATA spare parts
281689100150	DUMMY ASSY BRKT FRONT SHOCK ABSORBER MTG RH	TATA spare parts
281689100151	ASSY REBOUND STOPPER	TATA spare parts
281689100152	ASSY HOSE CYL PUSH PORT TO TEE COUPLER	TATA spare parts

281689100153	ASSY HOSE HAND PUMP PULL PORT TO CYL PUL	TATA spare parts
281689100155	ASSY BUNDY TUBE PRESSURE PORT ELE PUMP	TATA spare parts
281689100156	ASSY PIPE SUCTION PORT HAND PUMP TO SUCT	TATA spare parts
281689100157	ASSY PIPE TEE CONNECTOR TO HAND PUMP	TATA spare parts
281689100160	ASSY_BRKT_HAND_PUMP_MTG	TATA spare parts
281689100161	ASSY HOSE LATCH LH TO TEE COUPLER	TATA spare parts
281689100162	ASSY HOSE LATCH RH TO TEE COUPLER	TATA spare parts
281689100163	ASSY HAND PUMP CAB TILT	TATA spare parts
281689100165	DUST SEAL PIVOT BUSH MTG.	TATA spare parts
281689100166	DUST SEAL PIVOT ARM MTG.FRONT	TATA spare parts
281689100167	ASSY HOSE TEE CONNECTOR TO TEE CONNECTOR	TATA spare parts
281689100177	ASSY PIPE TEE CONNECTOR TO STRAIGHT CONN	TATA spare parts
281689100180	ASSY SLEEVE CYL UPPER MTG	TATA spare parts
281689100181	ASSY CAB TILTING PUMP _MANUAL	TATA spare parts
281689100183	HYD. CYLINDER FOR CAB TILTING BS3/4	TATA spare parts
281689100184	ASSY. CABIN LATCH LH BS3/4	TATA spare parts
281689100184AE	ASSY CABIN LATCH LH	TATA spare parts
281689100185	ASSY. LATCH CABIN RH BS3/4	TATA spare parts
281689100186	ASSY HOSE CYL TO SOCKET NON SLPR	TATA spare parts
281689100188	ASSY HOSE SUPPORT BRKT TO TEE COUPLER	TATA spare parts
281689100189	ASSY PIPE HAND PUMP TO TEE CONECTOR	TATA spare parts
281689100190	ASSY PIPE HAND PUMP PULL PORT TO HOSE CY	TATA spare parts
281689100191	ASSY BRKT HAND PUMP MTG NON SLPR	TATA spare parts
281689100192	HOSE ASSY CYLINDER TO HAND PUMP	TATA spare parts
281689100196	ASSY PIPE SUCTION PORT HAND PUMP TO SUCT	TATA spare parts
281689100197	ASSY HOSE PRESSURE PORT HAND PUMP TO PRE	TATA spare parts
281689100198	ASSY BRKT HAND PUMP MTG LHD	TATA spare parts
281689100199	ASSY CAB TILTING PUMP _MANUAL DONGJIN LHD	TATA spare parts
281689100202	ASSY BUNDY TUBE PRESSURE PORT ELE PUMP T	TATA spare parts
281689100203	ASSY PIPE TEE CONNECTOR TO HAND PUMP LHD	TATA spare parts
281689100205	ASSY PIPE TEE TO TEE LHD	TATA spare parts
281689100206	ASSY CAB MOUNTING FRONT NUT PLATE	TATA spare parts
281689100208	ASSY HOSE LH TO TEECOUPLER NON SLPR	TATA spare parts
281689100211	ASSY. STABILISER BAR WITH BUSH BS3/4	TATA spare parts
281689100217	ASSY PIPE HAND PUMP TO TEE CONECTOR NON	TATA spare parts
281689100218	ASSY PIPE HAND PUMP PULL PORT TO HOSE CY	TATA spare parts
281689100235	ASSY PIPE TEE CONNECTOR TO STRAIGHT CONN	TATA spare parts
281689100239	ASSY. FRONT STRUT SLPR CAB BS2/3	TATA spare parts
281689100240	ASSY. FRONT STRUT COMP. NON SLPR BS3/4	TATA spare parts
281689100241	ASSY. REAR STRUT BS1/3/4	TATA spare parts
281689100242	LATERAL SHOCK ABSORBER	TATA spare parts
281689100258	ASSY PIPE NON SLPR PNEUMATIC SUSP	TATA spare parts
281689100260	ASSY PIPE STRAIGHT CONNECTOR TO SOCKET F	TATA spare parts
281689100278	ASSY PIPE TEE CONNECTOR TO STRAIGHT CONN	TATA spare parts
281689100283	ASSY. REAR STRUT COMPL. SLPR CAB BS3/4	TATA spare parts
281689100284	HAND PUMP ASSY CAB TILT BS6	TATA spare parts
281689100285	CYLINDER ASSY CAB TILT BS6	TATA spare parts

281689100288	HAND PUMP ASSY CAB TILT BS6	TATA spare parts
281689100289	LATCH ASSY HYD CAB BS6	TATA spare parts
281689103202	HEX FL BOLT M10X105	TATA spare parts
281689103206	SPL HEX FL BOLT M16X1.5X155	TATA spare parts
281689103207	SPECIAL BOLT SLOTTED LINK	TATA spare parts
281689103211	SPL HEX FL BOLT M8	TATA spare parts
281689103212	SPECIAL HEX FL BOLT M14X1.5X135-10.9	TATA spare parts
281689103213	BEARING PIVOT BOLT FRONT CAB SUSP	TATA spare parts
281689103307	BASE PLATE CAB MTG REAR SUSP	TATA spare parts
281689103309	BACK PLATE CAB MTG REAR SUSP	TATA spare parts
281689103318	BRKT HEAT SHIELD MTG	TATA spare parts
281689103319	BRKT HEAT SHIELD MTG	TATA spare parts
281689103320	BRKT HEAT SHIELD MTG	TATA spare parts
281689103403	BUSH PIVOT ARM MTG BRASS	TATA spare parts
281689103404	BUSH PIVOT ARM MTG STEEL	TATA spare parts
281689103408	CAB PIVOT ARM MTG STEEL BUSH	TATA spare parts
281689103410	SLEEVE SLOTTED LINK	TATA spare parts
281689103701	PIVOT ARM LOWER LH	TATA spare parts
281689103702	PIVOT ARM LOWER RH	TATA spare parts
281689103703	BKT FRT CAB SUSP. UPPER LH	TATA spare parts
281689103704	BKT FRT CAB SUSP. UPPER RH	TATA spare parts
281689103705	BRKTFRONT CAB SUSP LOWER LH	TATA spare parts
281689103706	BRKT FRONT CAB SUSPENTION LOWER-RH	TATA spare parts
281689103711	BRACKET TILT CYLINDER LOWER LPS4934	TATA spare parts
281689103714	BRKY PIVOT ARM UPPER LH	TATA spare parts
281689103715	BRKT PIVOT ARM UPPER NRH	TATA spare parts
281689103717	CAB TILT STOPPER	TATA spare parts
281689103718	BRACKET TILT CYLINDER MTG LHD	TATA spare parts
281689103719	BRKT TILT CYLINDER LWR CURSOR	TATA spare parts
281689103731	BRKT FRONT CAB SUSP LOWER LH CAB	TATA spare parts
281689103732	BRKT FRONT CAB SUSP LOWER RH CAB	TATA spare parts
281689103733	BRKT TILT CYLINDER LWR C9 AND ISBE RHD	TATA spare parts
281689103734	BRKT TILT CYLINDER LWR C9 AND ISBE LHD	TATA spare parts
281689104302	CLIP FOR HYDRAULIC PIPE	TATA spare parts
281689105501	SPL WASHER	TATA spare parts
281689106301	SEAT HYDRAULIC LATCH	TATA spare parts
281689106303	CLIP BUNDY TUBE CLAMP	TATA spare parts
281689106304	SLEEVE BRKT FRONT CAB SUSP UPPER	TATA spare parts
281689106305	CLIP FOR TWO BUNDY TUBE	TATA spare parts
281689106307	WASHER	TATA spare parts
281689106308	WASHER	TATA spare parts
281689106501	SPL CASTLE NUT M20X1.5	TATA spare parts
281689106703	PIN LATERAL S/A AND LATCH MTG	TATA spare parts
281689106708	LOCKING PIN	TATA spare parts
281689106803	T COUPLER - CAB TILT	TATA spare parts
281689107102	CLIP SUPPORT PLATE	TATA spare parts
281689107501	PIVOT BUSH	TATA spare parts

281689107509	RUBBER GROMMET DIA.22	TATA spare parts
281689107510	RUBBER GROMMET DIA.16	TATA spare parts
281689107702	STABILIZER BAR BEARING DUST PROTECTION C	TATA spare parts
281689107902	STABILIZER_BAR	TATA spare parts
281689108206	BRKT_REAR_STRUT_MTG	TATA spare parts
281689108234	BRKT TEE COUPLER MTG	TATA spare parts
281689108238	SLEEVE PIVOT BUSH MTG	TATA spare parts
281689108239	BRKT TEE COUPLER MTG CROSS MEMBER	TATA spare parts
281689108241	SPACER PLATE CAB MOUNTING FRONT LH	TATA spare parts
281689108250	BRACKET HAND PUMP MTG NON SLPR	TATA spare parts
281689108252	BRACKET HOSES MTG NON SLPR	TATA spare parts
281689108256	BRKT TEE COUPLER MTG SA SIDE NON SLPR LH	TATA spare parts
281689108259	BRKT REAR STRUT MTG NON SLEEPER	TATA spare parts
281689108265	REINF WELD PLATE BKT HAND PUMP MTG LHD	TATA spare parts
281689108266	BRKTTEECOUPLERMTGLHD	TATA spare parts
281689108268	BRACKET HYDRAULIC PIPE MTG SLEEPER CAB	TATA spare parts
281689108273	BRACKET TEE COUPLER MTG SA SIDE NON SLPR	TATA spare parts
281689108280	BRKT L VALVE RR LWR	TATA spare parts
281689108290	BRKT TEE COUPLER MTG CROSS MEMBER SLEEPE	TATA spare parts
281689108299	BRACKET HOSES MTG NON SLPR NRH	TATA spare parts
281689108603	ABUTEMENT RING PIVOT BUSH	TATA spare parts
281689108608	SPACER FRONT MECHANICAL STRUT LWR	TATA spare parts
281689109202	SLOTTED WASHER PIVOT ARM MTG	TATA spare parts
281689109204	WASHER CYLINDER CAB TILT	TATA spare parts
281689109205	WASHER CYLINDER CAB TILT	TATA spare parts
281689109206	WASHER CYLINDER SLEEVE ASSY	TATA spare parts
281689109207	SPECIAL WASHER LATERAL SHOCK ABSORBER	TATA spare parts
281689109208	WASHER BRKT TILT CYLINDER LWR CURSOR 9 R	TATA spare parts
281689109209	SPECIAL WASHER LATCH SIDE	TATA spare parts
281689109210	WASHER SLOTTED LINK	TATA spare parts
281689109215	WASHER FOR REAR MECH SUSP	TATA spare parts
281689110108	ASSY BRKT LATERAL S/A MTG M0 CAB LH	TATA spare parts
281689110109	ASSY BRKT LATERAL S/A MTG M0 CAB RH	TATA spare parts
281689110111	ASSY PIPE HAND PUMP TO TEE CONECTOR LH	TATA spare parts
281689110112	ASSY PIPE PUMP PULLPORT TO CYL PULLPORT	TATA spare parts
281689110115	ASSY CROSS MEMBER FOR REAR CAB MECH SUSP	TATA spare parts
281689110123	ASSY BRKT HAND PUMP MTG M0	TATA spare parts
281689110125	ASSY PIPE HAND PUMP TO TEE CON LH	TATA spare parts
281689110126	ASSY PIPE PUMP PULLPORT TO CYL PULLPORT	TATA spare parts
281689110127	ASSY HEAT SHIELD COMPLETE TURBOCHARGER	TATA spare parts
281689110136	ASSY BRKT HAND PUMP MTG SLPR REAR	TATA spare parts
281689110137	ASSY PIPE HOSE TO TEE JOINT RHD	TATA spare parts
281689110138	ASSY PIPE HOSE TO HAND PUMP PULL PORT	TATA spare parts
281689110140	ASSY PIPE HAND PUMP PUSH PORT TO TEE RHD	TATA spare parts
281689110141	ASSY PIPE TEE JOINT TO TEE JOINT RHD	TATA spare parts
281689110142	ASSY PIPE CROSS MEMBER REAR ISLE ENG	TATA spare parts
281689110143	ASSY PIPE TEE CONNECTOR TO HOSE	TATA spare parts

281689110152	ASSY HOSE LATCH LH TO TEE FOR LHD	TATA spare parts
281689110153	ASSY CAB TILT PUMP MANUAL	TATA spare parts
281689110154	TILT PUMP FOR CAB - MANUAL	TATA spare parts
281689110157	ASSY BRKT HAND PUMP MTG NON SLPR LHD	TATA spare parts
281689110158	FRONT STRUT ASSY BS6	TATA spare parts
281689110159	REAR STRUT ASSY BS6	TATA spare parts
281689110160	FRONT STRUT ASSY	TATA spare parts
281689110161	ASSY. REAR STRUT BS3/4/6	TATA spare parts
281689110162	ASSY MTG BKT LAT S/A C CONS	TATA spare parts
281689110166	HYD. CYLINDER CAB TILTING BS3/4	TATA spare parts
281689110169	ASSY PIPE TEE CONNECTOR TO HOSE LHD	TATA spare parts
281689110172	ASSY PIVOT BUSH	TATA spare parts
281689110177	DOUBLE CLAMP	TATA spare parts
281689110191	ASSY BRKT HAND PUMP MTG M0 SLPR REAR	TATA spare parts
281689110192	ASSY PIPE HAND PUMP PULL PORT TO HOSE	TATA spare parts
281689110203	CROSS MEMBER ASSY CAB SUSPENSION REAR BS	TATA spare parts
281689110211	MICRO SWITCH ASSEMBLY	TATA spare parts
281689110213	HOSE ASSY CYLINDER TO HAND PUMP	TATA spare parts
281689110220	PIPE ASSY	TATA spare parts
281689110221	PIPE ASSY	TATA spare parts
281689110240	BRACKET ASSY HAND PUMP MTG LH	TATA spare parts
281689110245	HOSE ASSY CYLINDER TO HAND PUMP	TATA spare parts
281689110246	HOSE ASSY PUMP TO T-CONNECTOR	TATA spare parts
281689110247	HOSE ASSY T-CONN TO LATCH RH	TATA spare parts
281689110253	STOPPER BRACKET ASSY TILT LEVER LH	TATA spare parts
281689110254	STOPPER BRACKET ASSY TILT LEVER RH	TATA spare parts
281689110255	BRACKET ASSY HAND PUMP MTG RH	TATA spare parts
281689110273	HOSE ASSY PUMP TO T-CONNECTOR	TATA spare parts
281689110274	HOSE ASSY CYLINDER TO HAND PUMP	TATA spare parts
281689110275	HOSE ASSY T-CONNECTOR TO PUMP	TATA spare parts
281689118213	BRKT HAND PUMP MTG M0	TATA spare parts
281689118220	BRKT HEAT SHIELD MTG	TATA spare parts
281689118224	BRACKET HYDRAULIC PIPE MTG SLPR M0 CAB	TATA spare parts
281689118225	BRKT REAR STRUT MTG NON SLEEPER NRH	TATA spare parts
281689118247	BRACKET HYDRAULIC PIPE MTG SLPR M0 CAB	TATA spare parts
281689118249	SWITCH LEVER	TATA spare parts
281689118250	SWITCH A-CAB LOCK	TATA spare parts
281689118251	SPHERICAL BEARING	TATA spare parts
281689118252	BUSH PACKING	TATA spare parts
281689118253	BUSH-ROD END	TATA spare parts
281689118254	NIPPLE-ONE WAY DIRECTION	TATA spare parts
281689118255	NIPPLE-PUSH	TATA spare parts
281689118256	HEX BOLT - SEMS S/W	TATA spare parts
281689118262	NIPPLE-D	TATA spare parts
281689118289	BRACKET HAND PUMP MTG	TATA spare parts
281691000103	PNEUMATIC SUSPENDED DRIVER SEAT	TATA spare parts
281691000104	MECHANICAL SUSPENDED DRIVER SEAT	TATA spare parts



281691000105	ASSY KIT HEIGHT ADJ	TATA spare parts
281691000113	ASSY DRIVER LHD	TATA spare parts
281691000121	ASSY. BACKREST PNEUMATIC DR. LOWER END R	TATA spare parts
281691000123	ASSY. BACKREST PNEUMATIC DR. HIGHER END	TATA spare parts
281691000129	ASSY. CUSHION PNEUMATIC DR. LOWER END RH	TATA spare parts
281691000131	ASSY. CUSHION PNEUMATIC DR. HIGHER END R	TATA spare parts
281691000133	ASSY. KIT AIR CHAMBERS LUMBER SUPPORT	TATA spare parts
281691000138	ASSY. KIT PARTS SET (DIFF. PARTS)	TATA spare parts
281691000139	ASSY.BACKREST MECHANICAL DR. LOWER END R	TATA spare parts
281691000141	ASSY. KIT PNEUMATIC COMPONENTS	TATA spare parts
281691000144	ASSY. KIT SHOCK ABSORBER	TATA spare parts
281691000145	ASSY.BACKREST MECHANICAL DR. HIGHER END	TATA spare parts
281691000151	ASSY. CUSHION MECHANICAL DR. LOWER END R	TATA spare parts
281691000159	ASSY. KIT MECH. LUMBAR SUPPORT	TATA spare parts
281691000160	ASSY. KIT SHOCK ABSORBER	TATA spare parts
281691000163	ASSY. CUSHION MECHANICAL DR. HIGHER END	TATA spare parts
281691000177	ASSY PNEUMATICALLY SUSPENDED DRIVER SEAT	TATA spare parts
281691000177AE	ASSY PNEUMATIC DRVR SEAT -1828	TATA spare parts
281691000178	ASSY MECHANICAL DRIVER SEAT	TATA spare parts
281691000181	ASSY STATIC BASE M0 DRIVER SEAT	TATA spare parts
281691000185	ASSY RISER STATIC DR. SEAT	TATA spare parts
281691000187	ASSY KIT BELT BUCKLE WITH MICROSWITCH SE	TATA spare parts
281691000188	ASSY KIT 3POINT BELT RH	TATA spare parts
281691000189	ASSY KIT 3POINT BELT LH	TATA spare parts
281691000190	ASSY KIT PLASTIC COVER RHD	TATA spare parts
281691000191	ASSY KIT INCLINATION ADJ	TATA spare parts
281691000192	ASSY KIT SLIDS INCLINATION LEVER	TATA spare parts
281691000193	OPERATING SHACKLE	TATA spare parts
281691000206	DRIVER SEAT ASSY MECH SUSP SEAT BS6-PH2	TATA spare parts
281691006301	ASSY. PLASTIC COVER RH	TATA spare parts
281691006303	RUBBER BELLOW	TATA spare parts
281691006304	ASSY. KIT PLASTIC COVERS RH	TATA spare parts
281691006306	RUBBER BELLOW	TATA spare parts
281691009001	VALVE LUMBAR SUPPORT	TATA spare parts
281691010101	DRIVER SEAT ASSY BS6	TATA spare parts
281691010104	DRIVER SEAT ASSY	TATA spare parts
281691010106	DRIVER SEAT ASSY BS6-PH2	TATA spare parts
281691500103	ASSY. KIT 3 - POINT BELT LH	TATA spare parts
281691500104	ASSY.KIT 3 - POINT BELT RH	TATA spare parts
281691500105	ASSY. KIT BELT BUCKLE	TATA spare parts
281691500108	ASSY KIT BELT BUCKLE RH (RHD)	TATA spare parts
281691700101	ASSY AUXILLARY PIPE FOR PNEUMATIC SUSPEN	TATA spare parts
281691706901	AUXILLARY PIPE FOR PNEUMATIC SUSPENSION	TATA spare parts
281691900101	ASSY. KIT INCLINATION ADJ	TATA spare parts
281691900102	ASSY.KIT SLIDES INCLINATION LEVER	TATA spare parts
281691900103	ASSY. KIT VALVE FOR HEIGHT ADJ.	TATA spare parts
281691900104	ASSY. KIT HEIGHT LIMITER	TATA spare parts

281691900105	ASSY. KIT HEIGHT ADJ.	TATA spare parts
281691900106	ASSY. KIT SEAT LOWERING / UPMOVING	TATA spare parts
281691900107	ASSY. KIT INCLINATION	TATA spare parts
281691900108	ASSY. KIT HANDWHEEL WEIGHT ADJ.	TATA spare parts
281691906001	LEVER FOR SLIDE	TATA spare parts
281694000101	CO DRIVER SEAT	TATA spare parts
281694000105	ASSY CODRIVER SEAT HIGHER END RHD	TATA spare parts
281694000110	ASSY_CODRIVER_SEAT_HIGHER_END_LHD	TATA spare parts
281694000111	ASSY. BACKREST STATIC CO-DR. LOWER END R	TATA spare parts
281694000112	CO-DR SEAT ASSY WITH FOLDABLE BACK BS6-P	TATA spare parts
281694000113	ASSY. BACKREST STATIC CO-DR. HIGHER END	TATA spare parts
281694000119	ASSY. CUISHION STATIC CO-DR. LOWER END R	TATA spare parts
281694000120	CO-DRIVER 2-SEATER ASSY BS6	TATA spare parts
281694000121	ASSY. CUISHION STATIC CO-DR. HIGHER END	TATA spare parts
281694000127	ASSY CO-DRIVER STATIC SEAT W/O SLIDER	TATA spare parts
281694000130	ASSY M0 BACKREST STATIC DRIVER SEAT TRIM	TATA spare parts
281694000131	ASSY KIT 3-POINT BELT LH	TATA spare parts
281694000132	ASSY MO CUSION STATIC DRIVER SEAT TRIM	TATA spare parts
281694000133	ASSY KIT BELT BUCKLE RH	TATA spare parts
281694000134	ASSY KIT PARTS SET(DIFFERENT PARTS)1	TATA spare parts
281694000135	ASSY KIT PLASTIC COVER - STATIC	TATA spare parts
281694000136	ASSY M0 STATIC BASE CO DRIVER SEAT	TATA spare parts
281694000137	ASSY RISER STATIC CO.DRIVER SEAT	TATA spare parts
281694006301	ASSY. KIT PLASTIC COVERS - STATIC	TATA spare parts
281697400101	ASSY. KIT ARMREST LH	TATA spare parts
281698410121	ASSY PARTITION PANEL LOWER BERTH	TATA spare parts
281698410122	ASSY PANEL BERTH	TATA spare parts
281698410125	ASSY BKT SIDE SUPPORT LOWER BERTH CAB	TATA spare parts
281698410131	ASSY BKT REAR SUPPORT CENTER LO BERTH CA	TATA spare parts
281698410133	ASSY BKT REAR SUPPORT LO BERTH SIDE LH	TATA spare parts
281698410134	ASSY BKT REAR SUPPORT LO BERTH SIDE RH	TATA spare parts
281698410141	ASSY LOWER BERTH	TATA spare parts
281698410142	ASSY LOWER BERTH WITHOUT HEATER WITH LOV	TATA spare parts
281698410144	ASSY UPPER BERTH	TATA spare parts
281698410160	ASSY LOWER BERTH LOWER END VERSION	TATA spare parts
281698410161	ASSY UPPER BERTH VERSION	TATA spare parts
281698410234	BERTH ASSY LOWER	TATA spare parts
281698410237	PLATE SLIDING BERTH BS6-PH2	TATA spare parts
281698410238	PLATE SLIDING BERTH BS6-PH2	TATA spare parts
281698413304	BKT REAR SUPPORT LOW BIRTH CAB	TATA spare parts
281698417503	BUSH GAS SPRING BERTH	TATA spare parts
281698417504	PAD BS6-PH2	TATA spare parts
281698418292	BRACKET	TATA spare parts
281699003207	HEX BOLT M10X280	TATA spare parts
281699006502	NUT SPEED	TATA spare parts
281699006505	PLASTIC NUT	TATA spare parts
281699006509	CURTAIN RAIL CLIP M3	TATA spare parts

281699006510	NUT SPEED 4.2	TATA spare parts
281699008009	DIA5.8X16HISELFTAPPINGSOCR	TATA spare parts
281699106701	PIN HINGE HEADBOX MTG	TATA spare parts
281699500102	SCRIVET OB	TATA spare parts
281699504312	CLIP CABLE STEEL	TATA spare parts
281699504313	CLIP BUTTON N10	TATA spare parts
281699504314	PLASTIC CLIP	TATA spare parts
281699506301	ASSY SCRIVET (FOR SOFT TRIM)	TATA spare parts
281699506305	ASSY PIN GROMMET DIA 6.5 (PENWEL)	TATA spare parts
281699506306	XMAS TREE CLIP	TATA spare parts
281699506307	SCRIVET BS6	TATA spare parts
281699707501	RUBBER STOPPER	TATA spare parts
281800990101	ASSY KIT FOR VENTURE ENG COOLING IMPROVE	TATA spare parts
281815100101	STARTER MOTOR 1.4KW BS1/3/4	TATA spare parts
281815100105	STARTER MOTOR 1.4KW	TATA spare parts
281815100106	BRACKET STARTER MOTOR	TATA spare parts
281815109901	STARTER +VE CABLE LARGER LENGTH	TATA spare parts
281815109902	STARTER SOL CABLE LARGER LENGTH	TATA spare parts
281815109903	ASSY HEAT SHIELD	TATA spare parts
281815109910	STARTER POSITIVE CABLE	TATA spare parts
281815109911	STARTER SOLENOID CABLE	TATA spare parts
281815206304	IGNITION COIL COVER	TATA spare parts
281815400101	ALTERNATOR 12V 117A WITH INTERNNAL FAN	TATA spare parts
281815409901	GLOW PLUG STRIP	TATA spare parts
281824207701	RUBBER HEAT SHIELD	TATA spare parts
281829100102	ASSY. CLUTCH PEDAL LEVER	TATA spare parts
281829100104	ASSY. BRACKET (CLUTCH CABLE GUIDE)	TATA spare parts
281829100105	ASSY. CLUTCH CABLE	TATA spare parts
281829100106	ASSY. CLUTCH CABLE	TATA spare parts
281829100116	ASSY. CLUTCH PEDAL LEVER	TATA spare parts
281829100118	ASSY. BRACKET (CLUTCH CABLE GUIDE)	TATA spare parts
281829100139	ASSY. RUBBER GROMMET	TATA spare parts
281829100140	ASSY CLUTCH PIPE-LHD	TATA spare parts
281829100141	ASSY. BRACKET (CLUTCH CABLE GUIDE)	TATA spare parts
281829100143	ASSY. CLUTCH CABLE	TATA spare parts
281829100144	ASSY. CLUTCH CABLE 1880MM BS4 BS3/4	TATA spare parts
281829100145	ASSY. CLUTCH CABLE	TATA spare parts
281829100147	BUNDY TUBE	TATA spare parts
281829100148	ASSY. CLUTCH PEDAL COMPLETE	TATA spare parts
281829100151	ASSY CLUTCH CONTROL MOUNTING	TATA spare parts
281829100154	BUNDY TUBE	TATA spare parts
281829100155	CLUTCH HOSE	TATA spare parts
281829100156	BUNDY TUBE ASSY	TATA spare parts
281829100165	ASSY. CLUTCH PEDAL LEVER	TATA spare parts
281829100167	ASSY BUNDY TUBE	TATA spare parts
281829100168	ASSY BUNDY TUBE	TATA spare parts
281829100182	HIGH PRESSURE HOSE	TATA spare parts

281829100183	ASSY.BRACKET	TATA spare parts
281829100186	BUNDY TUBE ASSY	TATA spare parts
281829100204	CLUTCH CABLE ASSY	TATA spare parts
281829100206	BUNDY TUBE ASSY	TATA spare parts
281829100207	BUNDY TUBE ASSY	TATA spare parts
281829100208	BUNDY TUBE ASSY	TATA spare parts
281829103401	PIVOT BUSH	TATA spare parts
281829106301	PACKING FOAM (CONTROL MTG. BRACKET)	TATA spare parts
281829106306	PACKING FOAM (LHD CONTROL MOUNTING BRAC	TATA spare parts
281829107705	RUBBER CAP(FOR PEDAL LEVER STOPPER) BS6	TATA spare parts
281829107707	RUBBER STOPPER (CLUTCH PEDAL) BS6	TATA spare parts
281829108701	CLUTCH PEDAL ASSISTANCE SPRING	TATA spare parts
281829200102	ASSY. CONTROL MTG. BRACKET (CLUTCH AND B	TATA spare parts
281829200103	ASSY. CONTROL MOUNTING BRACKET	TATA spare parts
281829200104	ASSY. BRAKE PEDAL LEVER COMPLETE	TATA spare parts
281829200112	ASSY. CONTROL MTG. BRACKET (BRAKE AND AC	TATA spare parts
281829200124	ASSY. BRAKE PEDAL LEVER COMPLETE	TATA spare parts
281829200125	ASSY. CONTROL MOUNTING BRACKET	TATA spare parts
281829200126	ASSY. CONTROL MTG. BRACKET (BRAKE & CLUT	TATA spare parts
281829200138	BRACKET ASSY BRAKE CONTROL MTG	TATA spare parts
281829200146	ASSY. CABLE ANCHORING BRACKET	TATA spare parts
281829200160	ASSY. BRAKE PEDAL LEVER COMPLETE	TATA spare parts
281829200162	ASSY.CONTROL MTG.BRACKET(BRAKE & CLUTCH)	TATA spare parts
281829200175	ASSY. BRAKE PEDAL LEVER	TATA spare parts
281829206701	PIVOT PIN (BRAKE)	TATA spare parts
281829206706	PIVOT PIN (BRAKE)	TATA spare parts
281829208297	BRACKET (HP CLUTCH HOSE MTG.)	TATA spare parts
281829208702	RETURN SPRING (BRAKE)	TATA spare parts
281829218706	COMPRESSION SPRING CLUTCH PEDAL LHD	TATA spare parts
281829504201	SEPARATOR CLAMP	TATA spare parts
281830100101	ASSY. ACCELERATOR CABLE 2674MM BS2/3	TATA spare parts
281830100102	ASSY. ACCELERATOR PEDAL COMPLETE	TATA spare parts
281830100103	ASSY. ACCELERATOR PEDAL	TATA spare parts
281830100104	ASSY. BRACKET (ACCELERATOR PEDAL MTG.)	TATA spare parts
281830100105	ASSY ACCELERATOR CABLE	TATA spare parts
281830100106	ASSY. ACCELERATOR PEDAL COMPLETE	TATA spare parts
281830100110	ACCELERATOR PEDAL MODULE	TATA spare parts
281830100114	ASSY. ACCELERATOR PEDAL COMPLETE	TATA spare parts
281830100115	ASSY. ACCELERATOR PEDAL COMPLETE.	TATA spare parts
281830100119	ASSY ACCELERATOR CABLE 3100MM	TATA spare parts
281830100137	ASSY ACC CABLE SUPER ACE LHD PETROL	TATA spare parts
281830100145	APM(1.4LIT RHD DICOR)	TATA spare parts
281830100158	ASSY.APM STOPPER BRACKET	TATA spare parts
281830100160	ACCELERATOR CABLE ASSY	TATA spare parts
281830106301	PACKING FOAM (ASSY. ACCELERATOR PEDAL)	TATA spare parts
281830107701	GASKET (FOR꠫ ACCELERATOR PEDAL MODULE ST	TATA spare parts
281830108207	BRACKET (ACC. CABLE MTG)	TATA spare parts

281830108701	SPRING (FOR ACCELERATOR ROD)	TATA spare parts
281830108702	SPRING (FOR ACCELERATOR ROD)	TATA spare parts
281831000104	ASSY FRAME	TATA spare parts
281831000115	FRAME ASSY	TATA spare parts
281831000124	FRAME ASSY	TATA spare parts
281831140127	ASSY. BATTERY TRAY	TATA spare parts
281831148262	GUSSET CAB SUPPORT BS6	TATA spare parts
281831158232	STONE GUARD (ENGINE)	TATA spare parts
281831158247	STONE GAURD (AIR DUCT AND INTER COOLER)	TATA spare parts
281831200101	CROSS MEMBER ASSY FRONT	TATA spare parts
281831230135	ASSY. CROSS MEMBER (FRONT)	TATA spare parts
281831230169	ASSY GUARD (ALTERNATOR BELT)	TATA spare parts
281831230171	ASSY. REAR PROTECTION BAR	TATA spare parts
281831230199	ASSY.AIR DEFLECTOR	TATA spare parts
281831238205	BRACKET (RADIATOR MOUNTING)	TATA spare parts
281831240115	ASSY. BRACKET (UCL MTG.)	TATA spare parts
281831240167	ASSY. BRACKET AIR DEFLECTOR	TATA spare parts
281831240169	ASSY. RADIATOR BRACKET AND GUARD	TATA spare parts
281831240170	ASSY BRACKET STONE GAURD-AIR DUCT	TATA spare parts
281831240171	CLAMPING BOLT (STONE GAURD-AIR DUCT)	TATA spare parts
281831240172	ASSY.BRACKET (RADIATOR MTG.)	TATA spare parts
281831240174	ASSY BRACKET RADIATOR MTG.	TATA spare parts
281831240176	ASSY AIR DEFLECTOR	TATA spare parts
281831240190	ASSY. CROSS MEMBER (FUEL TANK MTG.)	TATA spare parts
281831240193	ASSY BRACKET (AIR DEFLECTOR)	TATA spare parts
281831250103	ASSY.BRACKET ENGINE MTG.	TATA spare parts
281831250108	ASSY.AIR DEFLECTOR	TATA spare parts
281831250113	ASSY BRACKET (ENGINE A PILLER MTG.)	TATA spare parts
281832100102	ASSY. FRT PIVOT BUSH(LOWER LINK) BS1/3/4	TATA spare parts
281832100126	ASSY LOWER LINK FRONT RH	TATA spare parts
281832100134	ASSY LOWER LINK FRONT LH	TATA spare parts
281832100138	ASSY SUBFRAME	TATA spare parts
281832100139	ASSY CROSS MEMBER	TATA spare parts
281832100143	ASSY LINK LH SUBFRAME	TATA spare parts
281832100144	ASSY LINK RH SUBFRAME	TATA spare parts
281832100150	ASSY. FRONT CROSS MEMBER	TATA spare parts
281832100153	ASSY. REAR PIVOT BUSH LOWER LINK BS1/3/4	TATA spare parts
281832100173	ASSY. SUBFRAME WITH SCOOP MTG. BKT	TATA spare parts
281832100179	ASSY. SUBFRAME WITH STONEGUARD MTG. BKT	TATA spare parts
281832100196	SUB FRAME LHD PETROL	TATA spare parts
281832100201	SUBFRAME ASSY WITH ABS MTG BKT	TATA spare parts
281832100206	ASSY LINK REAR PIVOT SUPPORT-RH	TATA spare parts
281832100207	ASSY LINK REAR PIVOT SUPPORT- LH	TATA spare parts
281832100220	ASSY REAR CROSS MEMBER SUBFRAME	TATA spare parts
281832100224	SUBFRAME ASSY COMPLETE	TATA spare parts
281832100228	ASSY. SUBFRAME COMPLETE WITH STONE GUARD	TATA spare parts
281832100230	ASSY SUBFRAME COMPLETE	TATA spare parts

281832100249	FRONT CROSS MEMBER SUBFRAME	TATA spare parts
281832103202	STRUT MOUNTING PIN ECCENTRIC	TATA spare parts
281832103204	HEXAGON FLANGE BOLT M12X1.25X160	TATA spare parts
281832103509	SPACER (REAR PIVOT MTG.)	TATA spare parts
281832105106	LOWER LINK FRONT RH	TATA spare parts
281832105107	LOWER LINK FRONT LH	TATA spare parts
281832105113	REAR PIVOT PIN LINK MTG	TATA spare parts
281832106902	OUTER CASE	TATA spare parts
281832106903	INNER CASE	TATA spare parts
281832107707	BUMP STOPPER FRONT	TATA spare parts
281832107712	FRONT SPRING SEAT TOP	TATA spare parts
281832107713	FRONT SPRING SEAT TOP	TATA spare parts
281832108601	SPACER - STRUT TOP.	TATA spare parts
281832108703	COIL SPRING FRONT BS1/3/4	TATA spare parts
281832108707	FRONT COIL SPRING (20KGF/MM)	TATA spare parts
281832109227	HARDENED WASHER - STRUT TOP.	TATA spare parts
281832118202	CLAMP (FRT ARB BOTTOM MTG)	TATA spare parts
281832200101	ASSY. BALL JOINT BS1/3/4	TATA spare parts
281832200101DF	STUB AXLE BALL JOINT - SUPER ACE	TATA spare parts
281832300101	ASSY STRUT TOP (FRONT STRUT)	TATA spare parts
281832300104	ASSY. FRONT STRUT COMPLETE (LH)	TATA spare parts
281832300108	ASSY. FRONT STRUT COMPLETE (RH)	TATA spare parts
281832300110	ASSY. FRONT STRUT (LH)	TATA spare parts
281832300111	ASSY. FRONT STRUT (RH)	TATA spare parts
281832300113	ASSY. FRONT STRUT COMPLETE LH	TATA spare parts
281832300114	ASSY FRONT STRUT COMPLETE RH	TATA spare parts
281832300118	DUST COVER WITH CUP ASSY	TATA spare parts
281832300129	ASSY. DUST COVER TUBE-FRONT STRUT	TATA spare parts
281832300136	SUB ASSY.STRUT TOP	TATA spare parts
281832300137	ASSY. STRUT TOP (FRONT STRUT) BS1/3/4	TATA spare parts
281832300139	ASSY.TOP CUP (STRUT TOP)	TATA spare parts
281832300140	ASSY.FRONT STRUT COMPLETE LH	TATA spare parts
281832300141	ASSY.FRONT STRUT COMPLETE RH	TATA spare parts
281832300146	ASSY.FRONT STRUT LH	TATA spare parts
281832300147	ASSY. FRONT STRUT RH	TATA spare parts
281832300167	STRUT ASSY FRONT-LH	TATA spare parts
281832300168	STRUT ASSY FRONT-RH	TATA spare parts
281832300178	STRUT ASSY COMP FRONT LH	TATA spare parts
281832300179	STRUT ASSY COMP FRONT RH	TATA spare parts
281832300186	ASSY. STRUT FRONT-LH BS1/3/4	TATA spare parts
281832300187	ASSY. STRUT FRONT-RH BS1/3/4	TATA spare parts
281832300194	STRUT TOP ASSY	TATA spare parts
281832300201	STRUT ASSY FRONT-LH	TATA spare parts
281832300202	STRUT ASSY FRONT-RH	TATA spare parts
281832309202	WASHER	TATA spare parts
281832310110	FRONT STRUT ASSY LH	TATA spare parts
281832310111	FRONT STRUT ASSY RH	TATA spare parts

281832400101	ASSLY TRAILING ARM WITH BUSH	TATA spare parts
281832400102	ASSLY TRAILING ARM WITH SLEEVE	TATA spare parts
281832400103	ASSLY PIVOT BUSH REAR TRAILING ARM (AXLE	TATA spare parts
281832400104	ASSLY PIVOT BUSH REAR TRAILING ARM (FRAM	TATA spare parts
281832400105	ASSY. PANHARD ROD WITH BUSH	TATA spare parts
281832400106	ASSY. PAN HARD ROD WITH SLEEVE	TATA spare parts
281832400107	ASSY PAN HARD BUSH	TATA spare parts
281832400108	ASSY REAR SPRING PARABOLIC	TATA spare parts
281832400125	ASSY REAR SPRING PARABOLIC	TATA spare parts
281832400134	1ST LEAF ASSY WITH BUSH	TATA spare parts
281832400135	ASSY BUMP STOP REAR	TATA spare parts
281832400138	ASSY REAR SPRING HANGER BRACKET - FRONT	TATA spare parts
281832400139	ASSY. REAR SPRING HANGER BRACKET - REAR	TATA spare parts
281832400140	ASSY. RUBBER BUSHING (RR SPRING) BS1/3/4	TATA spare parts
281832400145	ASSY SHACKLE (REAR SPRING)	TATA spare parts
281832400149	ASSY. GUIDE PLATE LH (REAR SPRING)	TATA spare parts
281832400150	ASSY. GUIDE PLATE RH (REAR SPRING)	TATA spare parts
281832400163	ASSY PAN HARD ROD SUPPORT TUBE	TATA spare parts
281832400164	ASSY RR SPRING SEMI ELLIPTICAL	TATA spare parts
281832400166	ASSY RR SPRING SEMI ELLIPTICAL	TATA spare parts
281832400169	ASSY RR SPRING SEMI ELLIPTICAL	TATA spare parts
281832400181	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
281832400193	VIBRATION DAMPER (REAR AXLE)	TATA spare parts
281832400195	ASSY. DAMPER PLATE - LH	TATA spare parts
281832400196	ASSY. DAMPER MOUNTING PLATE - RH	TATA spare parts
281832400210	ASSY TRAILING ARM WITH BUSH	TATA spare parts
281832403202	CENTRE BOLT (REAR LEAF SPRING)	TATA spare parts
281832407108	FIRST LEAF	TATA spare parts
281832407114	CLAMP (REAR LEAF SPRING)	TATA spare parts
281832407115	REAR SPRING PAD	TATA spare parts
281832407116	CLAMP-FRONT SIDE	TATA spare parts
281832407120	2ND LEAF	TATA spare parts
281832407121	3RD LEAF	TATA spare parts
281832407122	4TH LEAF	TATA spare parts
281832407123	5TH LEAF	TATA spare parts
281832407154	SECOND LEAF	TATA spare parts
281832407161	THIRD LEAF	TATA spare parts
281832407162	FOURTH LEAF	TATA spare parts
281832407163	FIFTH LEAF	TATA spare parts
281832407705	SPRING SEAT TOP (REAR)	TATA spare parts
281832407706	SPRING SEAT TOP (REAR) (ONE LUG) (33 MM)	TATA spare parts
281832407707	SPRING SEAT TOP (REAR) (TWO LUGS) (37 MM	TATA spare parts
281832408701	REAR COIL SPRING	TATA spare parts
281832408702	REAR COIL SPRING	TATA spare parts
281832408705	REAR COIL SPRING	TATA spare parts
281832409204	SPACER PANHARDROD AXLE END	TATA spare parts
281832409209	WASHER	TATA spare parts

281832410114	GUIDE PLATE ASSY LH BS6	TATA spare parts
281832410115	GUIDE PLATE ASSY RH	TATA spare parts
281832418260	GUIDE PLATE REAR SPRING BS6	TATA spare parts
281832500101	ASSY BUMP STOPPER REAR	TATA spare parts
281832500102	ASSY BUMP STOPPER REAR	TATA spare parts
281832504202	U CLAMP	TATA spare parts
281832600106	ASSY SHOCK ABSORBER (REAR)	TATA spare parts
281832600107	ASY. REAR SHOCK ABSORBER	TATA spare parts
281832600108	ASSY SHOCK ABSORBER (REAR)	TATA spare parts
281832600114	ASSY.SHOCK ABSORBER REAR	TATA spare parts
281832800104	ASSY BRACKET ARB MOUNTING FRAME	TATA spare parts
281832800106	ASSY FRONT ANTI ROLL BAR COMPLETE	TATA spare parts
281832800109	ASSY ANTI ROLL BAR COMPLETE(FRONT)	TATA spare parts
281832800110	ASSY. BRACKET ARB MOUNTING FRONT	TATA spare parts
281832800122	ASSY. FRONT ARB WITH RING	TATA spare parts
281832800123	ASSY ARB LINK	TATA spare parts
281832800140	ANTI ROLL BAR ASSY FRONT	TATA spare parts
281832805102	LINK ANTIROLL BAR	TATA spare parts
281832805104	LINK ANTIROLL BAR	TATA spare parts
281832807720	BEARING BLOCK	TATA spare parts
281832807721	BEARING BLOCK	TATA spare parts
281832807901	ANTI ROLL BAR FRONT	TATA spare parts
281832808213	CUP (FRONT ARB)	TATA spare parts
281832900106	ASSY.REAR ANTIROLL BAR COMPLETE	TATA spare parts
281833000101	ASSY. FRONT AXLE RH	TATA spare parts
281833000102	ASSY. FRONT AXLE LH	TATA spare parts
281833000112	ASSY. FRONT AXLE RH	TATA spare parts
281833000113	ASSY. FRONT AXLE LH	TATA spare parts
281833000114	"AXLE ASSY,FRONT-RH"	TATA spare parts
281833000115	ASSY FRONT AXLE LH	TATA spare parts
281833103701	FRONT HUB	TATA spare parts
281833103702	FRONT HUB	TATA spare parts
281833103704	FRONT HUB	TATA spare parts
281833203201	FLANGE BOLT	TATA spare parts
281833205103	STUB AXLE RH	TATA spare parts
281833205104	STUB AXLE LH	TATA spare parts
281833208601	SPACER TUBE	TATA spare parts
281833407801	OIL SEAL (FRONT HUB) BS1/3/4	TATA spare parts
281833408201	BAFFLE	TATA spare parts
281833408602	SEAL RACE (STUB AXLE)	TATA spare parts
281833409201	THRUST WASHER	TATA spare parts
281840100118	ASSY. WHEEL RIM BS1/3/4	TATA spare parts
281840103201	BOLT WHEEL MOUNTING FRONT	TATA spare parts
281840107701	SUPPORT PAD	TATA spare parts
281840107702	PAD(SPARE WHEEL SUPPORT)	TATA spare parts
281840109911	TUBELESS TYRE 175 R14	TATA spare parts
281840206501	WHEEL NUT	TATA spare parts



281840300104	ASSY. TUBE (SPARE WHEEL MTG.)	TATA spare parts
281840300114	ASSY.SPARE WHEEL CARRIER	TATA spare parts
281840308205	BRACKET (SPARE WHEEL MTG.)	TATA spare parts
281841100105	ASSEMBLY PROPELLER SHAFT	TATA spare parts
281841100107	ASSEMBLY PROPELLER SHAFT	TATA spare parts
281841100114	PROPELLER SHAFT FOR ACE 1 TON 2380 WB	TATA spare parts
281841100115	UJ KIT	TATA spare parts
281841100118	ASSY.PROPELLER SHAFT 1310 SERIES	TATA spare parts
281841100119	ASSY. PROPELLER SHAFT	TATA spare parts
281841100120	SLIP YOKE ASSY.	TATA spare parts
281841100121	UJ KIT	TATA spare parts
281841100122	FLANGE YOKE	TATA spare parts
281841100124	PROP. SHAFT ASSY	TATA spare parts
281841100126	TORSIONAL VIBRATION DAMPER BS1/3	TATA spare parts
281841100129	TORSIONAL VIBRATION DAMPER	TATA spare parts
281841100130	FLANGE YOKE	TATA spare parts
281841100133	ASSY.PROPELLER SHAFT-SUPER ACE	TATA spare parts
281841100134	TORSIONAL VIBRATION DAMPER BS3/4	TATA spare parts
281841100136	TORSIONAL VIBRATION DAMPER BS3	TATA spare parts
281841100139	PROPELLER SHAFT ASSY	TATA spare parts
281841100140	ASSY.PROP.SHAFT	TATA spare parts
281841100142	UJ KIT	TATA spare parts
281841100144	PROPELLER SHAFT ASSY	TATA spare parts
281841100156	PROPELLER SHAFT ASSY	TATA spare parts
281841100157	PROPELLER SHAFT ASSY	TATA spare parts
281841100159	UNIVERSAL JOINT ASSY	TATA spare parts
281841100160	LONG FORK ASSY	TATA spare parts
281841100166	PROPELLER SHAFT ASSY	TATA spare parts
281841100169	PROPELLER SHAFT ASSY	TATA spare parts
281841100170	PROPELLER SHAFT ASSY	TATA spare parts
281841100172	PROPELLER SHAFT ASSY	TATA spare parts
281841100173	PROPELLER SHAFT ASSY	TATA spare parts
281841100174	LONG FORK ASSY	TATA spare parts
281841100175	SLIP YOKE ASSY	TATA spare parts
281841105101	FLANGE YOKE	TATA spare parts
281841108202	GUARD (PROPELLER SHAFT)	TATA spare parts
281841108206	GUARD (PROPELLER SHAFT)	TATA spare parts
281841108207	GUARD PROPELLER SHAFT ASSY	TATA spare parts
281841108601	SPACER	TATA spare parts
281842100104	ASSY CALIPER BRAKE LH	TATA spare parts
281842100105	ASSY CALIPER BRAKE RH	TATA spare parts
281842100108	CALIPER ASSY.LH BS4	TATA spare parts
281842100109	ASSY. CALIPER RH BS1/3/4	TATA spare parts
281842103701	FRONT BRAKE DISC BS1/3/4	TATA spare parts
281842103701DF	BRAKE DISC FRONT-SUP ACE/MEGA/V10/V20 BS	TATA spare parts
281842108202	BRAKE DISC DUST COVER-RH	TATA spare parts
281842108204	BRAKE DISC DUST COVER-LH	TATA spare parts

281842300106	ASSY. REAR BRAKE LH	TATA spare parts
281842300107	ASSY. REAR BRAKE RH	TATA spare parts
281842300110	WHEEL CYLINDER ASSY LH	TATA spare parts
281842300111	WHEEL CYLINDER ASSY RH	TATA spare parts
281842300113	KIT MINOR WHEEL CYL.	TATA spare parts
281842300114	KIT MINOR WASHER	TATA spare parts
281842300120	ASSY. REAR BRAKE LH 17.46 W/C	TATA spare parts
281842300121	ASSY. REAR BRAKE RH 17.46 W/C	TATA spare parts
281842300122	ASSY. REAR BRAKE RH DIA 254	TATA spare parts
281842300123	ASSY. REAR BRAKE LH DIA 254	TATA spare parts
281842300147	SHOE KIT BS4	TATA spare parts
281842300158	KIT - HAND BRAKE LEVER RH	TATA spare parts
281842300159	KIT - HAND BRAKE LEVER LH	TATA spare parts
281842300161	ASSY. REAR BRAKE RH DIA 254	TATA spare parts
281842300162	ASSY. REAR BRAKE LH DIA 254	TATA spare parts
281842300167	DRUM BRAKE ASSY REAR-RH - DIA 254	TATA spare parts
281842300168	DRUM BRAKE ASSY REAR-LH - DIA 254	TATA spare parts
281842303301	ROCKER	TATA spare parts
281842303703	REAR BRAKE DRUM-254 DIA	TATA spare parts
281842306001	HANDBRAKE LEVER RH	TATA spare parts
281842306002	HANDBRAKE LEVER LH	TATA spare parts
281842306701	SPLIT PIN	TATA spare parts
281842306702	PIVOT PIN	TATA spare parts
281842308005	SCREW W/C MOUNTING BS6	TATA spare parts
281842309203	CUP WASHER	TATA spare parts
281842700105	ASSY. PARKING BRAKE LEVER	TATA spare parts
281842700105ZX	PARKING BRAKE LEVER ASSY WITH GRIP RHD	TATA spare parts
281842700105ZY	ASSY. PARKING BRAKE LEVER	TATA spare parts
281842700109	ASSY. PARKING CABLE FRONT	TATA spare parts
281842700111	ASSY. FRONT PARKING BRAKE CABLE	TATA spare parts
281842700115	ASSY PARKING BRAKE CABLE	TATA spare parts
281842700116	ASSY PARKING BRAKE CABLE REAR RH	TATA spare parts
281842700117	ASSY PARKING BRAKE CABLE LH	TATA spare parts
281842700124	ASSY. CLAMP PARKING CABLE FRONT - PELICA	TATA spare parts
281842700127	ASSY. PARKING BRAKE CABLE FRONT	TATA spare parts
281842700128	ASSY PARKING BRAKE CABLE REAR RH 1270MM	TATA spare parts
281842700129	ASSY PARKING BRAKE CABLE REAR LH 1810MM	TATA spare parts
281842700130	ASSY. PARKING BRAKE CABLE REAR RH	TATA spare parts
281842700131	ASSY. PARKING BRAKE CABLE REAR LH	TATA spare parts
281842700139	ASSY BRACKET-PARKING BRAKE CABLE REAR	TATA spare parts
281842700140	ASSY. PULL ROD	TATA spare parts
281842700145	ASSY. PARKING BRAKE LEVER	TATA spare parts
281842700146	PPARKING BRAKE CABLE ASSY FRONT	TATA spare parts
281842700168	ASSY BRACKET(CABLE CLAMPING)	TATA spare parts
281842700172	ASSY. PARKING BRAKE CABLE FRONT	TATA spare parts
281842700173	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
281842700175	PARKING BRAKE CABLE ASSY REAR-LH	TATA spare parts

281842700178	ASSY. PARKING BRAKE CABLE FRONT	TATA spare parts
281842700179	ASSY. PARKING BRAKE CABLE FRONT	TATA spare parts
281842700180	ASSY. REAR PARKING BRAKE CABLE	TATA spare parts
281842700182	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
281842700197	CABLE ASSY PARKING BRAKE FRONT	TATA spare parts
281842706501	SPECIAL NUT FRONT CABLE	TATA spare parts
281842706502	TURN BUKLE NUT	TATA spare parts
281842706701	PIN FRONT CABLE	TATA spare parts
281842708206	CLOSING PLATE - PARKING FRONT BRAKE CABL	TATA spare parts
281842708207	CLAMP	TATA spare parts
281842708210	LINK	TATA spare parts
281842990101	KIT-WHEEL CYLINDER MINOR	TATA spare parts
281842990105	KIT-LINED SHOE PER VEHICLE BS1/3/4	TATA spare parts
281842990106	KIT-BLEED SCREW PER W/CYL ASSY	TATA spare parts
281842990107	KIT-SCREW PER BRAKE ASSY	TATA spare parts
281842990108	KIT-SPRINGS PER BRAKE ASSY	TATA spare parts
281842990109	KIT-LEVER PAWL LH PER BRAKE ASSY-LH	TATA spare parts
281842990110	KIT-LEVER PAWL LH PER BRAKE ASSY-RH	TATA spare parts
281842990111	KIT-SHOE HOLD DOWN PER BRAKE ASSY	TATA spare parts
281842990112	BACK PLATE ASSY. LH	TATA spare parts
281842990113	BACK PLATE ASSY. RH	TATA spare parts
281842990114	WHEEL CYLINDER ASSY.	TATA spare parts
281842990115	ADJUSTER ASSY. LH	TATA spare parts
281842990116	ADJUSTER ASSY. RH	TATA spare parts
281842990123	STRUT & QUADRANT	TATA spare parts
281842990125	KIT-PAD ASSY WITH SHIM BS1/3/4	TATA spare parts
281842990125DF01	BRAKE PAD KIT - SUPER ACE/MEGA BS3/4	TATA spare parts
281842990125DF02	BRAKE PAD KIT - SUPER ACE/MEGA BS3/4	TATA spare parts
281842990128	KIT-SHOE HOLD DOWN	TATA spare parts
281842990129	KIT-CARRIER ASSY	TATA spare parts
281842990130	KIT-BLEED SCREW	TATA spare parts
281842998701	SPRING SHOE RETURN W/CYL END	TATA spare parts
281842998702	SPRING SHOE RETURN-ABUTMENT END	TATA spare parts
281842998705	SPRING-SHOE RETURN (UPPER)	TATA spare parts
281842998706	SPRING-SHOE RETURN (LOWER)	TATA spare parts
281842998707	SPRING-STRUT RETURN-LH & RH	TATA spare parts
281843100101	ASSY. VACUUM BOOSTER W/TMC 9 BS1/3/4	TATA spare parts
281843100106	ASSY. TWIN L.C.R.V.	TATA spare parts
281843100107	ASSY. 9 VACUUM BOOSTER WITH TMC	TATA spare parts
281843100108	ASSY. 9 INCH VACUUM BOOSTER WITH TMC	TATA spare parts
281843100109	ASSY. BRAKE FLUID RESERVOIR	TATA spare parts
281843100112	ASSY BRAKE FLUID RESERVOIR	TATA spare parts
281843100116	ASSY. TWIN L.C.R.V.	TATA spare parts
281843100117	KIT NRV	TATA spare parts
281843100119	KIT ADAPTOR	TATA spare parts
281843100120	MC KIT MAJOR BS4	TATA spare parts
281843100123	ASSY. MASTER CYLINDER BS1/3/4	TATA spare parts

281843100124	SERVO ASSY BS4	TATA spare parts
281843100125	BOOSTER& TMC MAJOR KIT	TATA spare parts
281843100126	BOOSTER& TMC MINOR KIT	TATA spare parts
281843100131	ASSY. BRAKE FLUID RESERVOIR LHD	TATA spare parts
281843100133	ASSY.BKT. LSPV MTG. ON FRAME	TATA spare parts
281843100135	OFFER DRG.ASSY.LSPV	TATA spare parts
281843100139	ASSY. L.S.P.V. BS3/4	TATA spare parts
281843100140	MODULATOR VALVE ABS BS6-PH2	TATA spare parts
281843100141	RESERVOIR ASSY RHD W/O CLUTCH PORT	TATA spare parts
281843100151	MODULATOR VALVE ABS	TATA spare parts
281843105801	HOSE RESERVOIR SECONDRY	TATA spare parts
281843105802	HOSE RESERVOIR PRIMARY	TATA spare parts
281843108217	BRACKET TWIN LCRV MTG. ON AXLE	TATA spare parts
281843403320	ASSY BRACKET	TATA spare parts
281843403331	ASSY AC PIPING BRACKET	TATA spare parts
281843500101	ASSY.9 IN VACUUM BOOSTER WITH TMC	TATA spare parts
281843500103	ASSY.VACUUM HOSE PUMP END(1.4LTR RHD)	TATA spare parts
281843500111	HOSE ASSY VACUUM PUMP END	TATA spare parts
281843505302	PROTECTIVE CAP BS6	TATA spare parts
281843800102	ASSY. FRONT BRAKE HOSE	TATA spare parts
281843800104	ASSY. PIPE	TATA spare parts
281843800105	ASSY. PIPE	TATA spare parts
281843800107	ASSY. PIPE	TATA spare parts
281843800108	ASSY. PIPE	TATA spare parts
281843800109	ASSY. PIPE	TATA spare parts
281843800112	ASSY. PIPE	TATA spare parts
281843800113	ASSY. PIPE	TATA spare parts
281843800116	ASSY. VACUUM PIPE PUMP END	TATA spare parts
281843800119	ASSY. FRONT BRAKE HOSE	TATA spare parts
281843800120	ASSY. REAR BRAKE HOSE	TATA spare parts
281843800121	ASSY. FRONT BRAKE HOSE	TATA spare parts
281843800124	ASSY. REAR BEAKE HOSE	TATA spare parts
281843800127	ASSY. PIPE	TATA spare parts
281843800128	ASSY. PIPE	TATA spare parts
281843800129	ASSY. PIPE	TATA spare parts
281843800130	ASSY. PIPE	TATA spare parts
281843800131	ASSY. PIPE	TATA spare parts
281843800132	ASSY. PIPE	TATA spare parts
281843800134	ASSY. PIPE	TATA spare parts
281843800135	ASSY. PIPE	TATA spare parts
281843800138	ASSY. PIPE	TATA spare parts
281843800139	ASSY. PIPE	TATA spare parts
281843800141	ASSY. PIPE (LHD)	TATA spare parts
281843800143	ASSY. PIPE	TATA spare parts
281843800144	ASSY. TUBE FROM LH T CONNECTOR TO LCRV	TATA spare parts
281843800146	ASSY. VACUUM PIPE BOOSTER END(LHD)	TATA spare parts
281843800147	ASSY. PIPE	TATA spare parts

281843800148	ASSY. PIPE	TATA spare parts
281843800151	ASSY PIPE	TATA spare parts
281843800154	ASSY. BKT. BRAKE PIPE CLAMPING ON AXLE	TATA spare parts
281843800163	ASSY. PIPE	TATA spare parts
281843800164	ASSY. PIPE	TATA spare parts
281843800165	ASSY. PIPE	TATA spare parts
281843800166	ASSY. PIPE	TATA spare parts
281843800167	ASSY. VACCUM PIPE I (NYLON)	TATA spare parts
281843800168	ASSY. VACCUM PIPE II (NYLON)	TATA spare parts
281843800169	ASSY. BRACKET FLOOR	TATA spare parts
281843800174	ASSY PIPE(LHD)	TATA spare parts
281843800175	ASSY. PIPE(LHD)	TATA spare parts
281843800177	VACUUM HOSE ASSY PUMP END	TATA spare parts
281843800178	ASSY. PIPE	TATA spare parts
281843800179	ASSY. PIPE	TATA spare parts
281843800195	ASSY. PIPE	TATA spare parts
281843800196	ASSY VACUUM HOSE ENGINE END	TATA spare parts
281843800197	ASSY. PIPE	TATA spare parts
281843800198	ASSY. PIPE	TATA spare parts
281843806501	HEX THIN NUT - M10X1	TATA spare parts
281843806804	ADAPTOR MALE BRAKE PIPE	TATA spare parts
281843806805	ADAPTOR MALE BRAKE PIPE	TATA spare parts
281843807703	CLAMP FOR 2 BRAKE LINES	TATA spare parts
281843807704	OFFER DRG. CLAMP FOR BRAKE LINE	TATA spare parts
281843807705	CLAMP FOR 3 BRAKE LINES	TATA spare parts
281843807706	CLAMP FOR BRAKE AND FUEL LINE	TATA spare parts
281843807707	CLAMP FOR BRAKE AND FUEL LINES	TATA spare parts
281843807708	HOSE BRAKE FLUID	TATA spare parts
281843807709	HOSE BRAKE FLUID	TATA spare parts
281843807713	HOSE BRAKE FLUID SECONDRY	TATA spare parts
281843807714	HOSE BRAKE FLUID PRIMARY	TATA spare parts
281843807719	BRAKE PIPE SNAP FIT	TATA spare parts
281843807720	FUNNEL - BRAKE FLUID RESERVOIR	TATA spare parts
281843808203	BRACKET REAR BRAKE HOSE MTG. ON AXLE	TATA spare parts
281843810112	TUBE ASSY ADAPTOR TO T CONNECTOR RH	TATA spare parts
281843810113	ASSY PIPE	TATA spare parts
281843810114	ASSY. VACCUM PIPE II (NYLON)	TATA spare parts
281843810116	TUBE ASSY T CONNECTOR TO LCRV	TATA spare parts
281843810117	TUBE ASSY T CONNECTOR TO LCRV	TATA spare parts
281843810118	TUBE ASSY ADAPTER TO ADAPTER	TATA spare parts
281843810119	TUBE ASSY ADAPTER TO ADAPTER	TATA spare parts
281843810120	TUBE ASSY ADAPTER TO FRONT BRAKE HOSE LH	TATA spare parts
281843810137	ASSY. PIPE	TATA spare parts
281843810138	ASSY. PIPE	TATA spare parts
281843810139	ASSY. PIPE	TATA spare parts
281843810140	ASSY. PIPE	TATA spare parts
281843810141	ASSY. PIPE	TATA spare parts

281843810142	ASSY. PIPE	TATA spare parts
281843810143	ASSY. PIPE	TATA spare parts
281843810144	OFFER DRG. ASSY. REAR BRAKE HOSE	TATA spare parts
281843810154	BRAKE HOSE ASSY REAR	TATA spare parts
281843810155	ASSY. TUBE FROM PRIMARY ADAPTER TO LCRV	TATA spare parts
281843810157	TUBE ASSY ADAPTOR TO LSPV INLET	TATA spare parts
281843810159	ASSY. BRAKE HOSE REAR	TATA spare parts
281843810161	ASSY. TUBE FROM LH T CONNECTOR TO LCRV	TATA spare parts
281843810162	TUBE ASSY HOSE TO REAR BRAKE ASSY RH	TATA spare parts
281843810163	TUBE ASSY HOSE TO REAR BRAKE ASSY LH	TATA spare parts
281843810171	TUBE ASSY HOSE TO REAR BRAKE ASSY RH	TATA spare parts
281843810172	TUBE ASSY HOSE TO REAR BRAKE ASSY LH	TATA spare parts
281843810174	TUBE ASSY ADAPTER TO MV	TATA spare parts
281843810175	TUBE ASSY ADAPTER TO MV	TATA spare parts
281843810176	TUBE ASSY MV TO ADAPTER	TATA spare parts
281843810177	TUBE ASSY MV TO ADAPTER	TATA spare parts
281843810178	TUBE ASSY MV TO ADAPTER	TATA spare parts
281843810180	TUBE ASSY T-CONN TO LCRV INLET	TATA spare parts
281843810183	TUBE ASSY ADAPTER TO REAR HOSE RH	TATA spare parts
281843810190	TUBE ASSY ADAPTER TO FRONT HOSE RH	TATA spare parts
281843810191	TUBE ASSY ADAPTER TO ADAPTER	TATA spare parts
281843990101	BOOSTER ASSEMBLY	TATA spare parts
281843990102	TANDEM MASTER CYLINDER ASSY.	TATA spare parts
281843990103	KIT-ADAPTER	TATA spare parts
281843990105	MASTER CYLINDER ASSY	TATA spare parts
281843990106	SERVO UNIT ASSY	TATA spare parts
281844800107	ASSY. HIGH PRESSURE HOSE BS1/3	TATA spare parts
281844800108	ASSY. BRACKET( PSTG LINE)	TATA spare parts
281844800114	ASSY.COOLER LOOP(RESERVOIR END)	TATA spare parts
281844800115	ASSY.RETURN LINE (GEAR END)	TATA spare parts
281844800116	ASSY.RETURN LINE	TATA spare parts
281844800119	ASSY.COOLER LOOP (RADIATOR FRONT)	TATA spare parts
281844800124	ASSY. HP HOSE	TATA spare parts
281844800125	ASSY.RETURN LINE (RESERVOIR END-DICOR)	TATA spare parts
281844800130	ASSY. COOLER LOOP-RADIATOR FRONT(LHD)	TATA spare parts
281844800134	ASSY RETURN LINE-COMPLETE(LHD)	TATA spare parts
281844800135	ASSY. RETURN LINE (RESERVOIR END)	TATA spare parts
281844800137	ASSY.SUCTION HOSE	TATA spare parts
281844800141	ASSY. HIGH PRESURE HOSE	TATA spare parts
281844800146	ASSY. HIGH PRESSURE LINE LHD	TATA spare parts
281844800148	ASSY RETURN LINE-GEAR END	TATA spare parts
281844800149	ASSY RETURN LINE MIDDLE	TATA spare parts
281844800163	SUCTION LINE HOSE ASSY	TATA spare parts
281844800167	ASSY. RETURN LINE COMPLETE	TATA spare parts
281844800171	RETURN LINE ASSY -COMPLETE(LHD DICOR)	TATA spare parts
281844805803	SUCTION HOSE	TATA spare parts
281844805813	SUCTION HOSE	TATA spare parts

281844806303	GROMMET POWER STEERING HOSE	TATA spare parts
281844808203	CLAMP (PSTG HOSE)	TATA spare parts
281844808222	BRACKET POWER STEERING LINE CLAMPING	TATA spare parts
281844808224	BRACKET SUCTION HOSE CLAMP	TATA spare parts
281846100103	ASSY. STEERING COLUMN (PWR. ASST.) BS1/3	TATA spare parts
281846100105	ASSY. STEERING COLUMN	TATA spare parts
281846100107	STEERING COLUMN	TATA spare parts
281846100108	COLUMN ASSEMBLY COLLAPSIBLE -MECHANICAL	TATA spare parts
281846100113	UPPER COLUMN ASSY	TATA spare parts
281846100118	UPPER COLUMN ASSEMBLY	TATA spare parts
281846100119	ASSY. I SHAFT MIDDLE BS1/3/4	TATA spare parts
281846100120	ASSY. LOWER SHAFT BS3	TATA spare parts
281846100121	RUBBER JOINT ASSY	TATA spare parts
281846100124	RUBBER JOINT ASSY-MANUAL	TATA spare parts
281846100126	ASSY STEERING COLUMN (TILT & TELESCOPIC)	TATA spare parts
281846100131	ASSY. STEERING COLUMN (BS-IV)	TATA spare parts
281846103201	HEX BOLT	TATA spare parts
281846106501	HEX NUT M12X1.5	TATA spare parts
281846107901	UPPER I SHAFT	TATA spare parts
281846109201	SPRING WASHER B12	TATA spare parts
281846109202	SPRING WASHER B8	TATA spare parts
281846200102	ASSY. RUBBER BELLOW	TATA spare parts
281846200104	ASSY. STG. COLUMN MTG. BRACKET	TATA spare parts
281846207702	RUBBER PACKING	TATA spare parts
281846207703	RUBBER PACKING	TATA spare parts
281846207704	RUBBER BELLOW	TATA spare parts
281846208211	COVER SHEET	TATA spare parts
281846400101	ASSY. STG. WHEEL (3 SPOKE)	TATA spare parts
281846400102	ASSY. STEERING WHEEL (3 SPOKE)	TATA spare parts
281846400102A3	STEERING WHEEL ASSY	TATA spare parts
281846400102AY	ASSY. STEERING WHEEL (3 SPOKE)	TATA spare parts
281846406301	HORN PAD	TATA spare parts
281846406302	BOTTOM COVER WITH BRASS CONTACT RING	TATA spare parts
281846406303	ASSY STEERING WHEEL WITH DAMPER	TATA spare parts
281846600104	POWER STEERING PUMP BS1/3	TATA spare parts
281846600105	ASSY. RACK AND PINION RHD-MECH	TATA spare parts
281846600106	ASSY. RACK & PINION POWER STG BS1/3	TATA spare parts
281846600108	RESERVOIR - ASSY POWER STEERING	TATA spare parts
281846600110	ASSY BRACKET -RH (RACK AND PINION MOUNTI	TATA spare parts
281846600111	ASSY BRACKET -LH (RACK AND PINION MOUNTI	TATA spare parts
281846600112	BELLOW KIT	TATA spare parts
281846600113	IBJ ASSY (M/S RANE-59602404)	TATA spare parts
281846600114	ASSY. OBJ (M/S RANE-59552407) BS1/3	TATA spare parts
281846600115	FEED PIPE ASSY LONG	TATA spare parts
281846600116	FEED PIPE ASY SHORT	TATA spare parts
281846600117	ASSY. POWER STEERING GEAR BS1/3	TATA spare parts
281846600119	ASSY POWER STEERING PUMP	TATA spare parts

281846600120	ASSY. POWER STEERING PUMP	TATA spare parts
281846600123	HOUSING ASSY. KIT	TATA spare parts
281846600124	CARTRIDGE ASSEMBLY KIT	TATA spare parts
281846600125	SEAL KIT	TATA spare parts
281846600130	ASSY. HOUSING SET	TATA spare parts
281846600131	ASSY. PINION SET	TATA spare parts
281846600133	IBJ ASSY.	TATA spare parts
281846600134	ASSY. BELLOW SET	TATA spare parts
281846600135	OBJ ASSY. WITH NUT	TATA spare parts
281846600136	STEERING GEAR W/O TIE ROD	TATA spare parts
281846600137	SHORT GEAR ASSY. KIT	TATA spare parts
281846600138	FEED TUBE ASSY. LEFT	TATA spare parts
281846600139	FEED TUBE ASSY. RIGHT	TATA spare parts
281846600140	BELLOW KIT	TATA spare parts
281846600141	INNER BALL JOINT ASSY. KIT BS4	TATA spare parts
281846600142	OUTER BALL JOINT ASSY. KIT BS4	TATA spare parts
281846600151	ASSY. STEERING GEAR LHD(POWER)	TATA spare parts
281846600156	ASSY. POWER STEERING PUMP	TATA spare parts
281846600161	POWER STEERING RACK & PINION ASSY. BS3/4	TATA spare parts
281846600162	ASSY. POWER STEERING RESERVOIR	TATA spare parts
281846600166	ASSY RESERVOIR MOUNTING BRACKET	TATA spare parts
281846600167	ASSY.RESERVOIR(POWER STG.)	TATA spare parts
281846600173	ASSY POWER STEERING PUMP	TATA spare parts
281846600174	ASSY. PSTG PUMP WITH PULLEY	TATA spare parts
281846600178	RACK & PINION ASSY POWER STG	TATA spare parts
281846600179	POWER&STEERING&PUMP&ASSY	TATA spare parts
281846600183	FEED PIPE ASSY SHORT	TATA spare parts
281846600184	FEED PIPE ASSY LONG	TATA spare parts
281846600185	OUTER BALL JOINT ASSY	TATA spare parts
281846600186	INNER BALL JOINT ASSY	TATA spare parts
281846600187	SHAFT ASSY	TATA spare parts
281846600188	RELIEF VALVE ASSY	TATA spare parts
281846603101	BALL BEARING	TATA spare parts
281846603201	BOLT	TATA spare parts
281846603801	SUCTION PORT CONNECTOR	TATA spare parts
281846604301	RETAINING RING (INT)	TATA spare parts
281846604801	DOWEL PIN	TATA spare parts
281846606501	IBJ NUT	TATA spare parts
281846606502	NUT	TATA spare parts
281846606801	SUCTION PORT CONNECTOR STG PUMP	TATA spare parts
281846606802	CONNECTOR PRESSURE PORT BS6	TATA spare parts
281846606901	RACK	TATA spare parts
281846607001	PULLEY POWER STG. PUMP(5 GROOVES)	TATA spare parts
281846607501	MOUNTING BUSH	TATA spare parts
281846607701	MOUNTING RUBBER	TATA spare parts
281846607703	MOUNTING RUBBER	TATA spare parts
281846607801	O' RING (PR. PORT CONNECTOR)	TATA spare parts



281846607802	O' RING (SUCTION CONNECTOR)	TATA spare parts
281846607803	DUST SEAL CAP	TATA spare parts
281846607807	DUST CAP	TATA spare parts
281846607901	SHAFT	TATA spare parts
281846608001	ALLEN HEAD SCREW	TATA spare parts
281846608211	MOUNTING CLAMP	TATA spare parts
281846608218	MOUNTING BRACKET	TATA spare parts
281846608701	SPRING	TATA spare parts
281846609201	RETAINING WASHER	TATA spare parts
281846609202	SPRING WASHER	TATA spare parts
281846609901	PRESSURE PORT CONNECTOR	TATA spare parts
281846800102	COOLER LOOP ASSY	TATA spare parts
281846800103	RETURN LINE ASSY RACK & PINION END	TATA spare parts
281846990103	UPPER I SHAFT ASSY.	TATA spare parts
281846990105	ASSY. LOWER I SHAFT BS3/4	TATA spare parts
281846990106	MIDDLE I SHAFT ASSY.	TATA spare parts
281846990107	LOWER I SHAFT ASSY.	TATA spare parts
281846990108	TILT & TELE.COLUMN ASSY.	TATA spare parts
281846990109	RESERVOIR BRACKET	TATA spare parts
281846990110	STEERING GEAR TIEROD ASSY	TATA spare parts
281846990112	FEED TUBE ASSY. LEFT	TATA spare parts
281846990113	FEED TUBE ASSY.RIGHT	TATA spare parts
281846990115	SHORT GEAR ASSY KIT	TATA spare parts
281846990116	FEED TUBE ASSY. LEFT	TATA spare parts
281846990117	FEED TUBE ASSY.RIGHT	TATA spare parts
281846990118	HOUSING ASSEMBLY KIT	TATA spare parts
281846990123	KIT-FEED TUBE ASSY	TATA spare parts
281846990124	KIT-BRACKET & RUBBER MOUNT	TATA spare parts
281846990126	KIT-SEAL	TATA spare parts
281846990127	KIT-HOUSING ASSY	TATA spare parts
281846993401	UPPER BUSH	TATA spare parts
281846993402	BOTTOM BUSH	TATA spare parts
281846996101	SPRING WASHER-LOCK	TATA spare parts
281846996501	NUT-PULLEY	TATA spare parts
281846997001	PULLEY-DRIVE	TATA spare parts
281846997901	SHAFT	TATA spare parts
281846998001	ALLEN HEAD SCREW	TATA spare parts
281846999201	RETAINING WASHER	TATA spare parts
281846999901	PRESSURE PORT CONNECTOR	TATA spare parts
281847100101	ASSY FUEL TANK	TATA spare parts
281847100108	ASSY. FILLER NECK	TATA spare parts
281847100111	FUELTANK STRAP AND RUBBER	TATA spare parts
281847100114	ASSY. BRACKET (FUEL LINE MTG. REAR)	TATA spare parts
281847100125	ASSY. FUEL TANK WELDED.	TATA spare parts
281847100130	ASSY FILLER NECK	TATA spare parts
281847100139	ASSY FUEL TANK COMPLETE	TATA spare parts
281847100140	ASSY. FUEL TANK COMPLETE	TATA spare parts

281847100141	FUEL TANK CAP WITH LOCK FOR ACE 1TON PIC	TATA spare parts
281847100152	FUEL TANK CAP WITH LOCK	TATA spare parts
281847100173	ASSY. FUEL TANK	TATA spare parts
281847100174	ASSY INTANK PUMP	TATA spare parts
281847100177	FUEL MODULE WITHOUT ACCESSORIES 45L	TATA spare parts
281847100178	LOCKABLE FUEL FILLER CAP ONE WAY	TATA spare parts
281847100184	ASSY.FUEL TANK COMPLETE	TATA spare parts
281847100186	ASSY. FUEL TANK COMPLETE (38 LITRES)	TATA spare parts
281847106913	SPACER TUBE	TATA spare parts
281847107701	FUEL HOSE	TATA spare parts
281847107705	HOSE (FUEL FILLER NECK)	TATA spare parts
281847107706	FUEL HOSE	TATA spare parts
281847107713	RUBBER HOSE (CANISTER TO TPV)	TATA spare parts
281847107715	RUBBER HOSE (FUEL FILLER)	TATA spare parts
281847107716	RUBBER HOSE (BREATHER)	TATA spare parts
281847107718	FUEL HOSE	TATA spare parts
281847108254	BRACKET (FUEL HEATER MTG.)	TATA spare parts
281847507711	RUBBER PACKING (FUEL TANK MTG BKT)	TATA spare parts
281847600101	ASSY. RETURN LINE	TATA spare parts
281847600102	ASSY. SUCTION LINE (FILTER TO TANK)	TATA spare parts
281847600103	ASSY. SUCTION LINE (FILTER TO FIP)	TATA spare parts
281847600104	ASSY. FUEL LINES (FOR NA ENGINE)	TATA spare parts
281847600113	ASSY. RETURN LINE	TATA spare parts
281847600114	ASSY. SUCTION LINE (FILTER TO TANK)	TATA spare parts
281847600115	ASSY SUCTION LINE (FILTER TO FIP)	TATA spare parts
281847600116	OFFER DRG ASSY NYLON FUEL LINES FOR TC	TATA spare parts
281847600119	ASSY. SUCTION LINE (FILTER TO TANK)	TATA spare parts
281847600121	ASSY RETURN LINE (FOR TCIC ENGINE)	TATA spare parts
281847600123	ASSY FUEL LINES (FOR TCIC ENGINE)	TATA spare parts
281847600125	ASSY SUCTION LINE(TANK TO PRE-FILTER)	TATA spare parts
281847600129	ASSY.SUCTION PIPE(FILTER TO ENGINE)	TATA spare parts
281847600132	ASSY RETURN LINE	TATA spare parts
281847600134	OFFER DRG.ASSY.SUCTION LINE (TANK TO WAT	TATA spare parts
281847600135	DRG. ASSY. SUCTION LINE ( FUEL HEATER T	TATA spare parts
281847600141	ASSY. SUCTION LINE (FILTER TO FIP)	TATA spare parts
281847600142	ASSY RETURN LINE (FOR TCIC ENGINE)	TATA spare parts
281847600143	ASSY FUEL LINES (FOR TCIC ENGINE)	TATA spare parts
281847600145	ASSY FUEL LINES (FOR DICOR ENGINES)	TATA spare parts
281847600164	ASSY FUEL LINE (DELIVERY AND RETURN)	TATA spare parts
281847600165	ASSY. DELIVERY LINE (FILTER TO ENGINE)	TATA spare parts
281847600166	ASSY VAPOUR LINE (CANISTER TO ENGINE)	TATA spare parts
281847600167	ASSY. VAPOUR LINE (PUMP TO TPV)	TATA spare parts
281847600168	ASSY DELIVERY LINE (PUMP TO FILTER)	TATA spare parts
281847600169	ASSY VENT LINE (CANISTER TO ATM.)	TATA spare parts
281847600171	FUEL SUCTION LINE ASSY	TATA spare parts
281847600172	FUEL SUCTION LINE ASSY	TATA spare parts
281847600174	FUEL SUCTION LINE ASSY	TATA spare parts

281847600176	ASSY FILLER NECK	TATA spare parts
281847600178	ASSY RETURN LINE	TATA spare parts
281847600180	ASSY SUCTION LINE(PRE-FILTER TO FILTER)	TATA spare parts
281847600187	FUEL RETURN LINE ASSY	TATA spare parts
281847600190	FUEL RETURN PIPE ASSY	TATA spare parts
281847600191	FUEL RETURN PIPE ASSY	TATA spare parts
281847600192	BRACKET ASSY COOLER LOOP MTG	TATA spare parts
281847600194	PRIMING PUMP MTG ASSY	TATA spare parts
281847603303	BRACKET COOLING LINES MTG	TATA spare parts
281847608202	BRACKET(FUEL LINES SUPPORT)	TATA spare parts
281847608203	BRACKET (FUEL LINES SUPPORT)	TATA spare parts
281849100113	ASSY. SILENCER	TATA spare parts
281849100116	ASSY. INLET PIPE WITH FLEXIBLE BELLOW	TATA spare parts
281849100124	ASSY. SILENCER	TATA spare parts
281849100132	ASSY. INLET PIPE WITH FLEXIBLE BELLOW	TATA spare parts
281849100139	ASSY. INLET PIPE WITH FLEXIBLE BELLOW	TATA spare parts
281849100140	ASSY.PRE SILENCER	TATA spare parts
281849100141	ASSY. INLET PIPE WITH FLEXIBLE BELLOW	TATA spare parts
281849100143	ASSY. OUTLET PIPE (PRESILENCER)	TATA spare parts
281849100152	ASSY. SILENCER (BS-III/E-III)	TATA spare parts
281849100158	ASSY POST SILENCER WITH HOOKS	TATA spare parts
281849100171	ASSY. TAILPIPE	TATA spare parts
281849100172	ASSY. SILENCER	TATA spare parts
281849100182	ASSY. SILENCER (SUPER ACE LHD E-II)	TATA spare parts
281849100186	ASSY. EXHAUST PIPE W/FLEX BELLOW FRT BS4	TATA spare parts
281849100190	ASSY. CATALYTIC CONVERTER	TATA spare parts
281849100191	ASSY SILENCER	TATA spare parts
281849100192	ASSY TAIL PIPE	TATA spare parts
281849100194	ASSLY MAIN SILENCER WITH HANGER	TATA spare parts
281849110115	ASSEMBLY SILENCER	TATA spare parts
281849110128	SILENCER ASSY WITH HOOK	TATA spare parts
281849200105	ASSY FRONT EXHAUST PIPE WITH FLEX BELLOW	TATA spare parts
281849200109	ASSY FRONT PIPE POST SILENCER	TATA spare parts
281849200123	PIPE ASSY. INLET WITH FLEXIBLE BELLOW	TATA spare parts
281849200147	ASSY.FRONT PIPE WITH FLEXIBLE BELLOW	TATA spare parts
281849200163	PIPE ASSY	TATA spare parts
281849208401	SPACER (DOC & POC MTG.ON GEAR BOX)	TATA spare parts
281854100101	ASSY. BATTERY CABLE +VE - OFFER	TATA spare parts
281854100102	ASSY. BATTERY CABLE -VE - OFFER	TATA spare parts
281854100103	ASSY. BATTERY BOX	TATA spare parts
281854100104	BATTERY_CABLE_+VE_MICROBUS	TATA spare parts
281854100105	ASSY_BATTERY_CABLE_-VE_-MICROBUS	TATA spare parts
281854100107	ASSY. BATTERY CABLE +VE	TATA spare parts
281854100110	ASSY BATTERY COVER	TATA spare parts
281854100113	BATT +VE SUPER ACE 1.4L DICOR LHD	TATA spare parts
281854100115	BATTERY +VE CABLE SUPERACE PETROL LHD	TATA spare parts
281854100116	MAXIFUSE MTG BKT	TATA spare parts

281854100117	MAXIFUSE MTG BKT-2	TATA spare parts
281854100127	BATTERY BOX ASSY	TATA spare parts
281854100128	BATTERY CABLE POSITIVE	TATA spare parts
281854108201	BATTERY CLAMP	TATA spare parts
281854108801	BATTERY CLAMP	TATA spare parts
281854109901	EARTH STRAP	TATA spare parts
281854109906	EARTH STRAP	TATA spare parts
281854200106	INSTRUMENT CLUSTER	TATA spare parts
281854200109	ASSY. TANK UNIT 38 LTR	TATA spare parts
281854200112	ASSY.ECU MTG BKT BELOW HVAC	TATA spare parts
281854200113	INSTRUMENT CLUSTER	TATA spare parts
281854200114	DIS MICROBUS	TATA spare parts
281854200115	ASSY_TANK_UNIT_MICROBUS	TATA spare parts
281854200116	INSTRUMENT CLUSTER BASE MODEL	TATA spare parts
281854200117	INST. CLUSTER	TATA spare parts
281854200120	DIS_MICROBUS_(HIGHEREND)	TATA spare parts
281854200121	DRIVER INFORMATION SYSTEM	TATA spare parts
281854200122	ASSY TANK UNIT BS4	TATA spare parts
281854200128	KIT_REVERSE_GUIDING_SYSTEM	TATA spare parts
281854200133	ASSLY ECU MTG BKT	TATA spare parts
281854200135	INSTRUMENT CLUSTER	TATA spare parts
281854200137	INST. CLUSTER SUPER ACE LHD PETROL HIGH	TATA spare parts
281854200169	INST CLUSTER	TATA spare parts
281854200175	INSTRUMENT CLUSTER	TATA spare parts
281854200177	INSTRUMENT CLUSTER ASSY	TATA spare parts
281854209904	HORN 12V DC	TATA spare parts
281854209905	DIS_TEMP_SENSOR	TATA spare parts
281854209906	REVERSE GUIDING SYSTEM CONTROLLER	TATA spare parts
281854209907	REVERSE_GUIDING_ULTRASONIC_SENSOR	TATA spare parts
281854209913	ASSY FUEL LEVEL SENSOR	TATA spare parts
281854209914	RELAY 12V 30A DUAL NO TYPE (WITH DIODE)	TATA spare parts
281854209915	12V 40A NO TYPE RELAY BS1/2/3/4	TATA spare parts
281854209916	RELAY 12V 70A NO 12V 70A NO	TATA spare parts
281854209931	NEW TEMP SESNSOR ED	TATA spare parts
281854209936	HIGH TEMPERATURE WARNING UNIT	TATA spare parts
281854304901	HORN	TATA spare parts
281854400101	ASSY HEAD LAMP LH BS3/4	TATA spare parts
281854400102	ASSY. HEAD LAMP RH BS1/3/4	TATA spare parts
281854400107	ASSY_HEAD_LAMP_RH_ONETONNER	TATA spare parts
281854400108	ASSY_HEAD_LAMP_LH_ONETONNER	TATA spare parts
281854400109	ASSY_TAIL_LAMP_LH_MICROBUS	TATA spare parts
281854400110	ASSY_TAIL_LAMP_RH_MICROBUS	TATA spare parts
281854400111	ASSY_ROOF_LAMP	TATA spare parts
281854400112	ASSY_HIGH_MOUNTED_STOP_LAMP_WITHOUT_	TATA spare parts
281854400113	ASSY_HIGH_MOUNTED_STOP_LAMP_WITH NOZ	TATA spare parts
281854400114	ASSY_ROOF_LAMP	TATA spare parts
281854400116	REAR FOG LAMP ONETONNER	TATA spare parts

281854400117	ASSY.FRONT FOG LAMP	TATA spare parts
281854400118	ASSY.FRONT FOG LAMP RH	TATA spare parts
281854400119	REAR ROOF LAMP	TATA spare parts
281854400130	ASSY HEAD LAMP LH LHD	TATA spare parts
281854400131	ASSY HEAD LAMP RH LHD	TATA spare parts
281854400132	ASSY REGISTRATION PLATE LAMP	TATA spare parts
281854400137	ASSY HEAD LAMP RH	TATA spare parts
281854400139	ASSY HEAD LAMP LH	TATA spare parts
281854400142	ASSY. TAIL LAMP LH - 4 CHAMBER BS3/4/6	TATA spare parts
281854400143	ASSY. TAIL LAMP RH FOUR CHAMBER BS3/4	TATA spare parts
281854400152	ASSY HEAD LAMP RH	TATA spare parts
281854400153	ASSY. HEAD LAMP LH	TATA spare parts
281854406301	HEAD LAMP PLASTIC COVER LH	TATA spare parts
281854406302	HEAD LAMP PLASTIC COVER LH	TATA spare parts
281854407501	RUBBER SEAL RH	TATA spare parts
281854407502	RUBBER SEAL LH	TATA spare parts
281854407503	RUBBER_SEAL_LH	TATA spare parts
281854407504	HEAD LAMP SEAL RH	TATA spare parts
281854407505	HEAD LAMP SEAL LH	TATA spare parts
281854407506	BLINKER SEAL RH	TATA spare parts
281854407507	BLINKER SEAL LH	TATA spare parts
281854409901	FRONT REFLEX REFLECTOR LH	TATA spare parts
281854409902	SIDE REPEATOR LAMP	TATA spare parts
281854409903	REAR_REFLEX_REFLECTOR	TATA spare parts
281854409904	SIDE REPETER RH SIDE	TATA spare parts
281854409905	FRONT REFLEX REFLECTOR RH	TATA spare parts
281854409906	REAR_REFLEX_REFLECTOR_RH	TATA spare parts
281854409914	ACTUATOR HEADLAMP LEVEL ARRANGEMENT	TATA spare parts
281854500104	ASSY. COMBI SWITCH-MICRO BUS BS1/3/4	TATA spare parts
281854500105	FACIA SWITCH FOR MICRO BUS-HIGH END	TATA spare parts
281854500107	ASSY COMBI SWITCH FOR MICRO BUS - HIGH E	TATA spare parts
281854500108	ASSY_COMBINATION_SWITCH_ONETONNER	TATA spare parts
281854500109	ASSY_COMBINATION_SWITCH_ONETONNER	TATA spare parts
281854500111	ASSY COMBI SWITCH FOR ONE TONNER	TATA spare parts
281854500115	FACIA SWITCH FOR MICRO BUS - LOW END.	TATA spare parts
281854500116	FACIA SWITCH FOR ONE TONNER HIGH END MOD	TATA spare parts
281854500117	FACIA SWITCH ONETONNER BASE SUPPLIER BS4	TATA spare parts
281854500121	FACIA SWITCH FOR MICRO BUS - MID END	TATA spare parts
281854500126	FACIA SWITCH	TATA spare parts
281854500127	ASSY COMBI SW SUPER ACE LHD HIGH END	TATA spare parts
281854500131	ASSY COMBINATION SWITCH	TATA spare parts
281854500135	ASSY.FACIA SW. SUPER ACE LHD HIGH END	TATA spare parts
281854500141	SWITCH BEZEL VENTURE AMBULANCE	TATA spare parts
281854500143	FACIA SWITCH ASSY	TATA spare parts
281854500144	FACIA SWITCH ASSY	TATA spare parts
281854507501	GROMMET-SLIDING DOOR LIMIT SWITCH CUTOU	TATA spare parts
281854509903	SLIDING_DOOR_SWITCH_DOOR_SUPPLIER	TATA spare parts

281854509904	SLIDING_DOOR_SWITCH_PILLAR_SUPPLIER	TATA spare parts
281854509905	COINBOX	TATA spare parts
281854509906	HEADLAMP_LEVELING_SWITCH	TATA spare parts
281854509907	DUMMY_KNOB_RH	TATA spare parts
281854509908	DUMMY_KNOB_LH	TATA spare parts
281854509909	HAZARD_WARNING_SWITCH BS4	TATA spare parts
281854509910	HRW_SWITCH	TATA spare parts
281854509911	POWER WINDOW SWITCH BS1/3/4	TATA spare parts
281854509912	SW. ASSY LIGHT & TURN	TATA spare parts
281854509913	SW. ASSY WIPER	TATA spare parts
281854509915	BEZEL_FACIA_SWITCH	TATA spare parts
281854509916	HEAD LAMP LEVELLING SWITCH 1 TONNER	TATA spare parts
281854509926	REAR_AC_SWITCH	TATA spare parts
281854509929	DOOR_SWITCH_SUPERACE_M/S_MINDARIKA	TATA spare parts
281854509934	SWITCH FOR SIREN	TATA spare parts
281854509935	SWITCH FOR REVOLVING LAMP	TATA spare parts
281854509937	SW. ASSY. WIPER	TATA spare parts
281854600103	HARNESS ENGINE ONETONNER	TATA spare parts
281854600104	WIRE HARNESS ROOF ONETONNER	TATA spare parts
281854600105	WIRING HARNESS FRONT DOOR LH 1TON	TATA spare parts
281854600107	SIDE BLINKER HARNESS ONETONNER	TATA spare parts
281854600109	WIRING HARNESS FRONT DOOR RH	TATA spare parts
281854600113	ROOF_WIRING_HARNESS_MICROBUS	TATA spare parts
281854600121	CABIN WIRING HARNESS	TATA spare parts
281854600123	HARNESS ENGINE ONETONNER	TATA spare parts
281854600124	ROOF WIRING HARNESS	TATA spare parts
281854600125	DOOR LH WIRING HARNESS	TATA spare parts
281854600126	WIRING_HARNESS_FRONT_DOOR_RH_ONETONNER	TATA spare parts
281854600127	SIDE REPEATER WIRING HARNESS	TATA spare parts
281854600128	CHASSIS WIRING HARNESS ---HVAC SOUTH AFR	TATA spare parts
281854600131	WH_CABIN_MICROBUS	TATA spare parts
281854600132	WH_CHASSIS_MICROBUS	TATA spare parts
281854600133	ROOF_WIRING_HARNESS_MICROBUS	TATA spare parts
281854600134	WH_REAR_ROOF_MICROBUS	TATA spare parts
281854600135	WH_DOOR_LH_MICROBUS	TATA spare parts
281854600136	WH_DOOR_RH_MICROBUS	TATA spare parts
281854600137	SIDE_BLINKER_HARNESS_MICROBUS	TATA spare parts
281854600138	WH_TAIL_GATE_MICROBUS	TATA spare parts
281854600139	W/H_SLIDING_DOOR_MICROBUS	TATA spare parts
281854600142	CHASSIS WIRING HARNESS --HEATING AND DEM	TATA spare parts
281854600143	CABIN WIRING HARNESS	TATA spare parts
281854600152	WIRING HARNESS CABIN LOW END ACE1TONNER	TATA spare parts
281854600153	WIRING HARNESS CHASSIS LOW END ACE1TONNER	TATA spare parts
281854600154	WIRING HARNESS ROOF LOW END AEC1TON	TATA spare parts
281854600155	WIRING HARNESS SIDE REPEATER LOW END	TATA spare parts
281854600156	WIRING HARNESS ENGINE LOW END ACE1TON	TATA spare parts
281854600159	WIRING HARNESS FRONT ROOF LAMP LOW END	TATA spare parts

281854600161	WH_TAIL_GATE_MICROBUS_LOW_END	TATA spare parts
281854600162	WIRING HARNESS CABIN LOW END MICROBUS M	TATA spare parts
281854600163	WIRE_HARNESS_CHASSI_MICROBUS_LOW_END	TATA spare parts
281854600164	WH CABIN MEDIUM END PELICAN	TATA spare parts
281854600165	WH CHASSIS MEDIUM END PELICAN	TATA spare parts
281854600169	WH_DOOR_RH_SUPERACE_THAILAND	TATA spare parts
281854600170	W/H DOOR LH SUPERACE	TATA spare parts
281854600171	W/H CABIN THAILAND VERSION	TATA spare parts
281854600180	BLOWER SW WIRING HARNESS PIGTAIL	TATA spare parts
281854600187	ENGINE WIRING HARNESS	TATA spare parts
281854600191	WIRING HARNESS ENGINE	TATA spare parts
281854600193	WIRING HARNESS ENGINE SENSOR	TATA spare parts
281854600196	DIAGNOSTIC MTG BRACKET	TATA spare parts
281854600202	BRACKET ASSY RETAINER PLATE	TATA spare parts
281854601603	W/H ENGINE EMS SUPERACE LHD DICOR	TATA spare parts
281854601604	WIRING HARNESS CABIN ACE BS1/3	TATA spare parts
281854601605	WIRING HARNESS CHASSIS LOW END ACE1TONNE	TATA spare parts
281854601606	WIRING HARNESS ROOF LOW END AEC1TON	TATA spare parts
281854601607	WIRING HARNESS SIDE REPEATER LOW END	TATA spare parts
281854601608	WIRING HARNESS ENGINE LOW END ACE1TON	TATA spare parts
281854601611	WIRING HARNESS FRONT ROOF LAMP LOW END M	TATA spare parts
281854601614	WIRING HARNESS CABIN LOW END - MICROBUS	TATA spare parts
281854601615	WIRE_HARNESS_CHASSI_MICROBUS_LOW_END_	TATA spare parts
281854601631	W/H ALT & STARTER PIGTAIL SUPER ACE LHD	TATA spare parts
281854603304	BRACKET RELAY MOUNTING LH	TATA spare parts
281854603305	BRACKET FOR RELAY MOUNTING RH	TATA spare parts
281854603309	BRACKET BATTERY CABLE MTG BS6	TATA spare parts
281854603318	BRACKET;FUSE BOX & RELAY MTG	TATA spare parts
281854603319	BRACKET;RELAY BASE MTG	TATA spare parts
281854603330	BRACKET;WIRING HARNESS CLAMP MTG	TATA spare parts
281854606303	SEPARATOR_CLAMP_DIA_30-20	TATA spare parts
281854606307	F/B STICKER VENTUREGX	TATA spare parts
281854606308	FUSE BOX STICKER : VENTURE-EX & CX	TATA spare parts
281854606309	F/B STICKER SUPER ACE HVAC	TATA spare parts
281854606310	F/B STICKER SUPER ACE DOMESTIC	TATA spare parts
281854606311	F/B STICKER SUPER ACE SOUTH AFRICA	TATA spare parts
281854606312	F/B STICKER SUPER ACE THAILAND	TATA spare parts
281854606313	MAXI F/B STICKER SUPER ACE/VENTURE	TATA spare parts
281854606318	CONNECTOR COVER DICOR	TATA spare parts
281854607506	RUBBER CAP FOR M6 STUD	TATA spare parts
281854608214	CONNECTOR MTG BKT WH CABIN SUPER ACE	TATA spare parts
281854608215	CONNECTOR MTG BKT WH CABIN SUPER ACE	TATA spare parts
281854608217	WIRING HARNESS SUPPORT TRANSAXLE	TATA spare parts
281854608218	WIRING HARNESS SUPPORT (GEAR BOX)	TATA spare parts
281854608221	CONNECTOR MTG BKT SUPER ACE DICOR	TATA spare parts
281854608222	FUSEBOX MOUNTING BRACKET-LHD	TATA spare parts
281854608226	WIRING HARNESS CHANNEL MTG BKT	TATA spare parts

281854608227	WIRING HARNESS CHANNEL MTG BKT	TATA spare parts
281854608232	WIRING HARNESS MTG BKT THERMOSTAT	TATA spare parts
281854608233	BRACKET WIRING HARNESS GEAR_BOX	TATA spare parts
281854608235	BRACKET WIRING HARNESS IGNITION COIL	TATA spare parts
281854608246	BRACKET ON CHASSIS FOR WH	TATA spare parts
281854608247	SIREN MTG BKT	TATA spare parts
281854608253	BOLTABLE MAXIFUSE MYG BRACKET	TATA spare parts
281854608256	BRACKET CRANK ANGLE SENSOR	TATA spare parts
281854608257	BRKT FOR BAT +VE CABLE	TATA spare parts
281854608261	BRACKET-(W/H ENG. CLAMPING)	TATA spare parts
281854608267	BRACKET AC CLUTCH CONNECTOR MTG	TATA spare parts
281854609903	SPARE FUSE 100A	TATA spare parts
281854609904	FUSE BOX COVER	TATA spare parts
281854609906	SPARE FUSE 60 A	TATA spare parts
281854609919	MAXI FUSE BOX COVER	TATA spare parts
281854609946	RELAY WITH DIODE	TATA spare parts
281854610113	WIRING HARNESS ENGINE BS3/4	TATA spare parts
281854610116	W/H STARTER & GLOW PLUG PIGTAIL	TATA spare parts
281854610122	ASSY MAXI FUSE BKT	TATA spare parts
281854610123	ASSY FUSE BOX MTG BKT	TATA spare parts
281854610130	WIRING HARNESS CHASSIS	TATA spare parts
281854610131	WIRING HARNESS CABIN	TATA spare parts
281854610133	WIRING HARNESS FRONT & REAR ROOF	TATA spare parts
281854610153	WIRING HARNESS EMS	TATA spare parts
281854610155	WIRING HARNESS CHASSIS	TATA spare parts
281854610159	SPARE-KIT-FUSES-FUSE-BOX-STCIKER-VENTURE	TATA spare parts
281854610160	VENTURE CHASSIS HARNESS	TATA spare parts
281854610161	VENTURE EX CHASSIS HARNESS_MSSL	TATA spare parts
281854610163	VENTURE TAILGATE HARNESS	TATA spare parts
281854610164	WIRING HARNESS TAIL GATE	TATA spare parts
281854610165	ASSY JUNCTION BOX MTG BKT	TATA spare parts
281854610166	W/H CABIN	TATA spare parts
281854610167	W/H CHASSIS	TATA spare parts
281854610168	WIRING HARNESS CABIN	TATA spare parts
281854610169	W/H CHASSIS SUPER ACE DICOR RHD	TATA spare parts
281854610170	WH CABIN SUPERACE DOM	TATA spare parts
281854610171	WIRING HARNESS ROOF VENTURE AMBULANCE	TATA spare parts
281854610172	FRONT ROOF LAMP PIGTAIL VENTURE AMBULANCE	TATA spare parts
281854610173	WIRING HARNESS CABIN VEN AMBULANCE	TATA spare parts
281854610174	SENSOR WH CRAIL-PIGTAIL-VENTURE-DICOR	TATA spare parts
281854610175	W/H DOOR LH WITH ORVM	TATA spare parts
281854610176	WIRING HARNESS CABIN	TATA spare parts
281854610177	RELAY MTG. BRACKET LH	TATA spare parts
281854610178	RELAY MTG. BRACKET RH	TATA spare parts
281854610179	RELAY MTG. BRACKET	TATA spare parts
281854610180	W/H CABIN	TATA spare parts
281854610182	W/H DOOR RH WITH ORVM	TATA spare parts



281854610183	REVERSE PARKING CONTROLLER PIGTAIL	TATA spare parts
281854610196	COMPRESSOR PIGTAIL	TATA spare parts
281854611658	BATTERY CABLE +VE	TATA spare parts
281854611694	WIRING HARNESS CABIN	TATA spare parts
281854611695	WIRING HARNESS CABIN	TATA spare parts
281854620106	WIRING HARNESS CABIN	TATA spare parts
281854620107	WIRING HARNESS CHASSIS	TATA spare parts
281854620113	WIRING HARNESS SIDE REPEATER	TATA spare parts
281854620114	WIRING HARNESS CABIN	TATA spare parts
281854620126	PIGTAIL W/H MAIN MIDI FUSE	TATA spare parts
281854620144	WIRING HARNESS ENGINE	TATA spare parts
281854620154	WIRING HARNESS CABIN	TATA spare parts
281854620156	WIRING HARNESS CHASSIS	TATA spare parts
281854620157	WIRING HARNESS ENGINE	TATA spare parts
281854700101	WIRING HARNESS	TATA spare parts
281854709901	BLOWER ASSY	TATA spare parts
281854709902	RESISTOR BS4	TATA spare parts
281854709903	FRESH_AIR_ACTUATOR_ASSY	TATA spare parts
281854709904	ACTUATOR MOTOR MODE/HEATER	TATA spare parts
281854709906	THERMO AMPLIFIER	TATA spare parts
281854709908	THERMISTOR EVAPORATOR	TATA spare parts
281854800103	CD RECEIVER	TATA spare parts
281854806301	SPEAKER MTG SUPPORT	TATA spare parts
281854900102	ASSY_IMMobilizer_KIT_ONETONNER	TATA spare parts
281854900103	CONTROLUNIT_ASSY_WITH_MTG_BRACKET	TATA spare parts
281854900115	IMMOBILIZER MOUNTING BRACKET ASSLY	TATA spare parts
281854900119	KIT CDL VENTURE BSIV DICOR	TATA spare parts
281854900124	KIT IMMOBILIZER VENTURE	TATA spare parts
281854900128	BRACKET ASSY EMS ECU MTG	TATA spare parts
281854906301	BUMPER HOUSING FOR SENSOR LH	TATA spare parts
281854906302	BUMPER HOUSING FOR SENSOR RH	TATA spare parts
281854906303	DIA 8 PUSH RIVET	TATA spare parts
281855106301	EURO II STICKER	TATA spare parts
281855106302	EURO III STICKER	TATA spare parts
281855106305	MASCOT	TATA spare parts
281855106306	DECAL FRONT	TATA spare parts
281855990101	KIT-DECAL	TATA spare parts
281858408207	TRANSFER LABEL TYRE PLACARD	TATA spare parts
281858604001	FRONT JACKING BRACKET	TATA spare parts
281858604005	FRONT JACKING BRACKET	TATA spare parts
281858900101	ASSY.SCISSORS JACK WITH 3PC HANDLE	TATA spare parts
281858900602	PULLER / CRANK SHAFT GR / PELICAN	TATA spare parts
281858900603	DRIFT / PILOT BRG / 475 IDI / PELICAN	TATA spare parts
281858900604	PULLER / PILOT BEARING / PELICAN	TATA spare parts
281858900701	BEND SPANNER / FIP 3RD MTG NUT / ACE 1T	TATA spare parts
281858901401	BEND SPANNER / TC 3RD MTG NUT / ACE 1T	TATA spare parts
281858901801	OIL FILTER SPANNER / ACE 1T	TATA spare parts

281858902601	PULLER / REMOVE SPRING PIN / 609 613	TATA spare parts
281858902602	DRIFT / R-4D DOWEL / 28180402 /G65 / PEL	TATA spare parts
281858902603	DRIFT / CIRCLIP FITMENT / GB65 / PELICAN	TATA spare parts
281858902604	DRIFT / R-4D DOWEL / 28180402/G65 / PELI	TATA spare parts
281858902605	DRIFT / R-5D DOWEL / 28180402/G65 / PELI	TATA spare parts
281858902606	CIRCLIP REMOVAL TOOL / G65 / PELICAN	TATA spare parts
281858902607	BEARING PULLER TOOL	TATA spare parts
281858902608	DRIFT / 6H7 DOWEL FITMENT / PELICAN	TATA spare parts
281858902609	DRIFT / REMOVE CIRCLIP / PELICAN	TATA spare parts
281858902610	PULLER / COUNTER SHAFT 5TH GR / PELICAN	TATA spare parts
281858902611	DRIFT / 4D DOWEL FITMENT / PELICAN	TATA spare parts
281858903201	SPRING COMPRESSOR (SUSPENSION)ACE 1 TONE	TATA spare parts
281858903303	CLICK TORQUE WRENCH 50 -120NM	TATA spare parts
281858903304	RATCHET INSERT	TATA spare parts
281858903305	TORQUE WRENCH 15-85NM	TATA spare parts
281858903306	OPEN ENDED INSERT 17 MM 9X12	TATA spare parts
281858903307	OPEN ENDED INSERT 21 MM 9X12	TATA spare parts
281858903501	DUMMY BRG / RA / ACE 1T	TATA spare parts
281858903502	P-DOLLEY / PINION I-CUP / RA / ACE 1T	TATA spare parts
281858903503	P-DOLLEY / PINION O-CUP / RA / ACE 1T	TATA spare parts
281858903504	P-DOLLEY / PINION I-CONE / RA / ACE 1T	TATA spare parts
281858903505	P-DOLLEY / PINION I-CONE / RA / ACE 1T	TATA spare parts
281858903506	ADOPTER / R-DIFF.CASE BRG / RA / ACE 1T	TATA spare parts
281858903507	ADOPTER / R-PINION I-BRG / RA / ACE 1T	TATA spare parts
281858903508	UNIVERSAL HANDLE / RA / ACE 1T	TATA spare parts
281858903509	P-DOLLEY / PINION O-OIL SEAL / RA / ACE	TATA spare parts
281858903510	PULLER / PINION O-SEAL / RA / ACE 1T	TATA spare parts
281858903511	PULLER / AXLE SHAFT BRG / RA / ACE 1T	TATA spare parts
281858903512	PRESS / REMOVE BRG / RA / ACE 1T	TATA spare parts
281858903513	P-DOLLEY / AXLE TUBE FLANGE O-SEAL / RA	TATA spare parts
281858903514	FLANGE / R-AXLE SHAFT / RA / ACE 1T	TATA spare parts
281858903515	EXPANDER / RA /ACE 1T	TATA spare parts
281858903516	PINION HEIGHT SETTING GAUGE / RA / ACE 1	TATA spare parts
281858903517	HEIGHT SETTING MASTER BLK / RA / ACE 1T	TATA spare parts
281858903518	HOLDER / FLANGE / RA / ACE 1T	TATA spare parts
281858903519	ADAPTER BEARING REMOVAL	TATA spare parts
281858903520	TOOL SEAL PRESSING	TATA spare parts
281858903521	SLEEVE GUIDE	TATA spare parts
281858903522	ADAPTER BEARING REMOVAL	TATA spare parts
281858903523	PIN DOWEL	TATA spare parts
281858903524	RING	TATA spare parts
281858903525	SETTING DUMMY PINION HEIGHT	TATA spare parts
281858903526	SETTING TOOL PINION HEIGHT	TATA spare parts
281858903527	SETTING BLOCK PINION HEIGHT	TATA spare parts
281858903528	ADAPTER BEARING REMOVAL	TATA spare parts
281858903529	LASH GAUGE DIFF ASSEMBLY	TATA spare parts
281858903530	PIN DOWEL	TATA spare parts

281858903531	ADAPTER BEARING REMOVAL	TATA spare parts
281858903532	TOOL SEAL PRESSING	TATA spare parts
281858903533	SUPPORT BLOCK	TATA spare parts
281858903534	SETTING DUMMY PINION HEIGHT	TATA spare parts
281858903535	ADAPTER BEARING ASSEMBLY	TATA spare parts
281858903536	SLEEVE GUIDE	TATA spare parts
281858903537	ADAPTER BEARING REMOVAL	TATA spare parts
281858903538	ADAPTER BEARING ASSEMBLY	TATA spare parts
281858903539	TOOL SEAL PRESSING	TATA spare parts
281858903540	ADAPTER BEARING REMOVAL	TATA spare parts
281858903541	RING	TATA spare parts
281858903542	TONNER RING PRESSING DOLLY BS6	TATA spare parts
281858904001	ASSY. SCISSORS JACK	TATA spare parts
281858904005	CORD - JACK CLAMPING	TATA spare parts
281858904006	JACK SEAT RUBBER	TATA spare parts
281860000102BF	ASSY BODY SHELL COMPLETE PAINTED MICROBU	TATA spare parts
281860000102FW	ASSY BODY SHELL COMPLETE PAINTED MICROBU	TATA spare parts
281860000102FY	ASSY BODY SHELL COMPLETE PAINTED MICROBU	TATA spare parts
281860000102FZ	ASSY BODY SHELL COMPLETE PAINTED MICROBU	TATA spare parts
281860000102GM	ASSY BODY SHELL COMPLETE PAINTED MICROBU	TATA spare parts
281860000102HF	ASSY BODY SHELL COMPLETE PAINTED MICROBU	TATA spare parts
281860000107BF	ASSY BODY SHELL COMPLETE PAINTED-1 TONNE	TATA spare parts
281860000107FW	ASSY BODY SHELL COMPLETE PAINTED-1 TONNE	TATA spare parts
281860000107FY	ASSY BODY SHELL COMPLETE PAINTED-1 TONNE	TATA spare parts
281860000107FZ	ASSY BODY SHELL COMPLETE PAINTED-1 TONNE	TATA spare parts
281860000107GC	ASSY BODY SHELL COMPLETE PAINTED-1 TONNE	TATA spare parts
281860000107GM	ASSY BODY SHELL COMPLETE PAINTED-1 TONNE	TATA spare parts
281860000107HF	ASSY BODY SHELL COMPLETE PAINTED-1 TONNE	TATA spare parts
281860000107IC	ASSY BODY SHELL COMPLETE PAINTED-1 TONNE	TATA spare parts
281860000107ID	ASSY BODY SHELL COMPLETE PAINTED-1 TONNE	TATA spare parts
281860000108	BODY SHELL COMPLETE - 1 TONNER	TATA spare parts
281860000128	ASSY BODY SHELL COMPLETE PAINTED HARD PA	TATA spare parts
281860000128BF	ASSY BODY SHELL COMPLETE PAINTED HARD PA	TATA spare parts
281860000128DZ	BODY SHELL COMPLETE GLOSSY BLACK PAINTED	TATA spare parts
281860000128FD	ASSY BODY SHELL COMPLETE PAINTED HARD	TATA spare parts
281860000128FW	ASSY BODY SHELL COMPLETE PAINTED HARD PA	TATA spare parts
281860000147BF	ASSY BODY SHELL COMPLETE	TATA spare parts
281860000147FD	ASSY BODY SHELL COMPLETE PAINTED	TATA spare parts
281860000147FY	ASSY BODY SHELL COMPLETE PAINTED LUNAR S	TATA spare parts
281860000147FZ	ASSY BODY SHELL COMPLETE PAINTED CHAMPGN	TATA spare parts
281860000147HF	ASSY BODY SHELL COMPLETE PAINTED	TATA spare parts
281860000165	ASSY BODY SHELL COMPLETE RHD DICOR	TATA spare parts
281860000166BF	ARCTIC WHITE-ASSY BODY SHELL COMPLETE PA	TATA spare parts
281860000166FZ	ASSY BODY SHELL COMPLETE PAINTED RHD DIC	TATA spare parts
281860000166GC	CASTLE GREY-ASSY BODY SHELL COMPLETE PAI	TATA spare parts
281860000166HF	METEOR SILVER-ASSY BODY SHELL COMPLETE P	TATA spare parts
281860000166IC	BLAZING RED-ASSY BODY SHELL COMPLETE PAI	TATA spare parts

281860000166ID	BODY SHELL COMPLETE PAINTED RHD DIC	TATA spare parts
281860000236	BODY SHELL IN WHITE	TATA spare parts
281860000239BF	BODY SHELL ASSY PAINTED_ARCTIC WHITE	TATA spare parts
281860000239HF	METEOR_SILVR-BODY SHELL ASSY PAINTED	TATA spare parts
281860000239IC	BODY SHELL ASSY PAINTED_BLAZING RED	TATA spare parts
281860000239ID	TWILIGHT_GREY-BODY SHELL ASSY PAINTED	TATA spare parts
281860000239JS	TITANIUM_WH-BODY SHELL ASSY PAINTED	TATA spare parts
281860000239K5	BRIGHT_PLUM-BODY SHELL ASSY PAINTED	TATA spare parts
28186000Z107	ASSY BODY SHELL COMPLETE PAINTED-1TONNER	TATA spare parts
28186000Z107BF	ASSY BODY SHELL COMPLETE PAINTED - ARTIC	TATA spare parts
28186000Z107FW	ASSY BODY SHELL COMPLETE PAINTED - IVORY	TATA spare parts
28186000Z107GC	ASSY BODY SHELL COMPLETE PAINTED - CASTL	TATA spare parts
28186000Z113	ASSY BODY SHELL COMPLETE(EXPORT)	TATA spare parts
28186000Z118	ASSY BODY SHELL COMPLETE - 1 TONNER (EXP	TATA spare parts
28186000Z119	ASSY BODY SHELL COMPLETE PAINTED - 1 TON	TATA spare parts
28186000Z119BF	ARCTIC_WHITE-ASSY BODY SHELL COMPLETE PA	TATA spare parts
28186000Z119GC	ASSY BODY SHELL COMPLETE PAINTED - 1 TON	TATA spare parts
28186000Z126BF	ASSY BODY SHELL COMPLETE PAINTED LHD	TATA spare parts
28186000Z137	ASSY BODY SHELL COMPLETE	TATA spare parts
28186000Z138BF	BODY SHELL ARCTIC WHITE - COMPLETE PAINT	TATA spare parts
28186000Z138FW	ASSY COWL IVORY WHITE	TATA spare parts
28186000Z138HF	BODY SHELL METEOR SILVER - COMPLETE PAIN	TATA spare parts
28186000Z138IC	BODY SHELL BLAZING RED - ¿COMPLETE PAINT	TATA spare parts
28186000Z138ID	BODY SHELL TWILIGHT GREY - ¿COMPLETE PAI	TATA spare parts
28186000Z142BF	ASSY BODY SHELL COMP PAINTED LHD-GULF	TATA spare parts
28186000Z145BF	ARCTIC_WHITE-ASSY BODY SHELL COMPLETE PA	TATA spare parts
28186000Z197BF	ASSY BODY SHELL COMPLETE PAINTED 1 TONNE	TATA spare parts
28186000Z197BU	ASSY BODY SHELL COMPLETE PAINTED - JET B	TATA spare parts
281860100131	ASSY UNDERBODY LHD	TATA spare parts
281860600102	ASSY DASHBOARD CROSS MEMBER	TATA spare parts
281860600110	ASSY CROSS SUPPORT MIDDLE	TATA spare parts
281860600112	ASSY DASHBOARD CROSS MEMBER LHD	TATA spare parts
281860600114	ASSY CROSS SUPPORT MIDDLE LHD	TATA spare parts
281860603318	IP LOWER END MTG BKT LH	TATA spare parts
281861200104	ASSY REAR CROSS MEMBER LHD	TATA spare parts
281861600103	ASSY PANEL FRONT FLOOR	TATA spare parts
281861600108	ASSY WHEEL ARCH INNER LH	TATA spare parts
281861600109	ASSY WHEEL ARCH INNER RH	TATA spare parts
281861600114	ASSY GUSSET RH	TATA spare parts
281861600117	ASSY PANEL EXTENSION WHEEL ARCH INNER LH	TATA spare parts
281861600135	ASSY CAB MTG BKT LH	TATA spare parts
281861600154	ASSY BKT CAB CLOSURE RH	TATA spare parts
281861600197	ASSY CAB MTG BKT LH	TATA spare parts
281861600208	ASSY CAB MTG BKT RH	TATA spare parts
281861600209	ASSY EXT WHEEL ARCH RH	TATA spare parts
281861600210	ASSY GUSSET LH FOR VACCUM HOSE MTG	TATA spare parts
281861600219	ASSY PANEL FRONT FLOOR RHD DICOR	TATA spare parts

281861600220	SUB ASSY REAR CROSS MEMBER RHD DICOR	TATA spare parts
281861600262	ASSY CAB CLOSURE BKT LH	TATA spare parts
281861608225	SILL INNER FRONT LH	TATA spare parts
281861608226	SILL INNER FRONT RH	TATA spare parts
281861608801	WELD STUD M6X20 (WITH COLLAR)	TATA spare parts
281861800102	ASSY MIDDLE FLOOR COMPLETE	TATA spare parts
281861800107	ASSLY VERTICAL WALL CLOSING OUTER	TATA spare parts
281861800117	ASSY MIDDLE FLOOR SILL SUPPORT RH	TATA spare parts
281861800141	BRKT ASSY SCUFF PLATE MTG REAR BS6-PH2	TATA spare parts
281861804701	COVER BATTERY-MICROBUS	TATA spare parts
281861804702	COVER FUEL FILTER	TATA spare parts
281861807701	SEAL FUEL TANK COVER	TATA spare parts
281861807702	SEAL BATTERY COVER	TATA spare parts
281862000101	ASSY FRONT WALL RHD (TATA VENTURE)	TATA spare parts
281862000113	ASSY FRONT WALL RHD	TATA spare parts
281862000124	BRACKET ASSY FIREWALL CONTROL MTG	TATA spare parts
281862000125	FIREWALL ASSY WITH STUD	TATA spare parts
281863000101	ASSY. SIDE WALL LH BS1/3/4	TATA spare parts
281863000102	ASSY SIDE WALL COMPLETE LH	TATA spare parts
281863000103	ASSY SIDEWALL COMPLETE RH	TATA spare parts
281863000104	ASSY. SIDE WALL RH 1 TONNER BS3/4	TATA spare parts
28186300Z101	ASSY SIDE WALL COMPLETE LH 1	TATA spare parts
28186300Z104	ASSY SIDE WALL COMPLETE RH 1	TATA spare parts
281863200108	ASSY SIDE BONNET TOP MTG LH	TATA spare parts
281863200109	ASSY SIDE BONNET TOP MTG RH	TATA spare parts
281863600192	ASSY B PILLAR INNER LH MB	TATA spare parts
281863603316	TOP RAIL COVER MOUNTING BKT	TATA spare parts
281863608231	PANEL WHEEL ARCH OUTER LH	TATA spare parts
281863608242	PANEL B PILLAR INNER LOWER LH	TATA spare parts
28186360C233	SILL COVER LH(COATED)	TATA spare parts
28186360C234	SILL COVER RH(COATED)	TATA spare parts
281863700134	ASSY LID FUEL FILLER	TATA spare parts
281863708201	PANEL REAR QUARTER OUTER LOWER LH - MB	TATA spare parts
281863708202	PANEL REAR QUARTER OUTER RH - MB	TATA spare parts
281863708208	PANEL REAR QUARTER OUTER TOP LH - MB	TATA spare parts
281863708219	PANEL SIDE WALL FRONT OUTER LH - MB	TATA spare parts
281863708220	PANEL SIDEWALL OUTER FRONT RH - MB	TATA spare parts
281863708232	PANEL SIDE WALL MID OUTER RH	TATA spare parts
28186370C223	PANEL SIDE WALL OUTER LH(COATED)	TATA spare parts
28186370C224	PANEL SIDE WALL OUTER RH(COATED)	TATA spare parts
281864000101	ASSY REAR WALL	TATA spare parts
281864000102	ASSY REAR WALL (EXPORT)	TATA spare parts
281864000104	ASSY REAR WALL RHD DICOR 1-TONNER	TATA spare parts
281864000106	REAR WALL ASSY	TATA spare parts
281864200101	ASSY MAGAZINE POCKET MTG BKT TOP	TATA spare parts
281864208207	REINF REAR WALL BOTTOM	TATA spare parts
281865200101	ASSY ROOF HEADER FRONT	TATA spare parts

281865208202	PANEL ROOF HEADER REAR - 1 TONNER	TATA spare parts
281865700101	ASSY FRONT ROOF BOW MICROBUS	TATA spare parts
281865700102	ASSY ROOF BOW FOR ROOF LAMP MTG BKT REAR	TATA spare parts
281865708201	PANEL ROOF - MB	TATA spare parts
281865708204	PANEL REAR HEADER MB	TATA spare parts
281865708205	PANEL ROOF - 1 TONNER	TATA spare parts
281865708207	PANEL ROOF - 1 TONNER (DOMESTIC)	TATA spare parts
281865708208	PANEL ROOF HARD PAD -PELICAN	TATA spare parts
281867100102	WINDSHIELD GLASS GREEN TINTED BS1/3/4	TATA spare parts
281867102301	WINDSHIELD GLASS CLEAR	TATA spare parts
281867106301	WINDSHIELD MOULD	TATA spare parts
281867106302	BOTTOM SUPPORT WINDSHIELD	TATA spare parts
281867106303	WINDSHIELD MOULD	TATA spare parts
281867300101	ASSY FRONT FIXED GLASS LH	TATA spare parts
281867300102	ASSY FRONT FIXED GLASS RH	TATA spare parts
281867306301	FRONT FIXED GLASS BEAD	TATA spare parts
281867500101	ASSY REAR FIXED GLASS LH	TATA spare parts
281867500102	ASSY REAR FIXED GLASS RH	TATA spare parts
281867500109	ASSY TOGGLE CLAMP	TATA spare parts
281867500112	ASSY BUTTERFLY WINDOW LH	TATA spare parts
281867500113	ASSY KIT TOGGLE CLAMP LH	TATA spare parts
281867500115	ASSY TOGGLE CLAMP RH	TATA spare parts
281867500117	ASSY BUTTERFLY WINDOW RH	TATA spare parts
281867500118	ASSY KIT TOGGLE CLAMP RH	TATA spare parts
281867506302	EDGE FINISHER REAR FIXED GLASS RH	TATA spare parts
281867506304	EDGE FINISHER REAR FIXED GLASS LH	TATA spare parts
281867506305	MOULD EDGE FINISHER BUTTER FLY WINDOW LH	TATA spare parts
281867506306	MOULD EDGE FINISHER BUTTER FLY WINDOW RH	TATA spare parts
281867506308	BUTTERFLY WINDOW PRIMARY SEAL - LH	TATA spare parts
281867506310	BUTTERFLY WINDOW PRIMARY SEAL	TATA spare parts
281867506311	EDGE FINISHER TAIL LAMP LH	TATA spare parts
281867506312	EDGE FINISHER TAIL LAMP RH	TATA spare parts
281867506313	PRIMARY SEAL BUTTERFLY WINDOW LH (METZLE)	TATA spare parts
281867507701	RUBBER STOPPER BUTTERFLY WINDOW	TATA spare parts
281867802303	REAR WINDOW GLASS	TATA spare parts
281868206302	ANTI VIBRATION SHEET FRONT DOOR MIDDLE	TATA spare parts
281868206303	STIFFENER PAD PANEL ROOF	TATA spare parts
281868206304	STIFFENER PAD ROOF PANEL MIDDLE	TATA spare parts
281868206306	MEL SHEET DOOR OUTER	TATA spare parts
281868206307	MEL SHEET REAR WHEELARCH INNER	TATA spare parts
281868206308	MEL SHEET MIDDLE FLOOR	TATA spare parts
281868406301	FRONT WALL CARPET	TATA spare parts
281868406301AY	FRONT WALL CARPET	TATA spare parts
281868406302AY	FLOOR CARPET	TATA spare parts
281868406303	VERTICAL WALL CARPET	TATA spare parts
281868406303AY	VERTICAL WALL CARPET	TATA spare parts
281868406304	REAR CROSSMEMBER CARPET	TATA spare parts

281868406305	VERTICAL WALL INSULATION	TATA spare parts
281868406306	WHEEL ARCH INSULATION_LH	TATA spare parts
281868406307	WHEEL ARCH INSULATION_RH	TATA spare parts
281868406308	REAR CROSS MEMBER INSULATION	TATA spare parts
281868406309AY	CARPET REAR-7+D HIGH END VERS	TATA spare parts
281868406313	FLOOR CARPET	TATA spare parts
281868406314	CARPET REAR	TATA spare parts
281868406315AY	CARPET REAR-6+D HIGH END VERSION PELICAN	TATA spare parts
281868406318	FLOOR CARPET (KINIFOAM) RH	TATA spare parts
281868406319AY	CARPET REAR-6+D HIGH END VERSION PELICAN	TATA spare parts
281868406320AY	CARPET-REAR CROSS MEMBER-LOW END	TATA spare parts
281868406323	FLOOR CARPET LH	TATA spare parts
281868406324	FLOOR CARPET RH	TATA spare parts
281868406331	INSULATION VERTICAL WALL - LHD	TATA spare parts
281868406332	INSULATION WHEELARCH LH - LHD	TATA spare parts
281868406336	VERTICAL FLOOR CARPET LH (PET FELT TYPE)	TATA spare parts
281868406337	VERTICAL FLOOR CARPET RH (PET FELT TYPE)	TATA spare parts
281868406338	FRONT WALL CARPET (PETFELT TYPE)	TATA spare parts
281868406341	FABRIC COVER PANEL ENGINE SHIELD	TATA spare parts
281868406345	VERTICAL WALL INSULATION - 1.4 LTR DICOR	TATA spare parts
281868406362	FRONT WALL CARPET - 1.4 LTR DICOR	TATA spare parts
281868406364	REAR CROSS MEMBER CARPET	TATA spare parts
281868406369	WHEEL ARCH COVER LH	TATA spare parts
281868406370	WHEEL ARCH COVER RH	TATA spare parts
281868406373	TUNEL HUMP COVER	TATA spare parts
281868406374	FLOOR CARPET	TATA spare parts
281868406379	FRONT FLOOR CARPET - LH	TATA spare parts
281868406380	FRONT FLOOR CARPET - RH	TATA spare parts
281868406382	FRONT FLOOR CARPET	TATA spare parts
281868806301	FELT FOR PANEL SIDE WALL OUTER BOTTOM RH	TATA spare parts
281868806302	FELT FOR PANEL SIDE WALL OUTER TOP RH	TATA spare parts
281868806303	FELT FOR PANEL REAR QUARTER OUTER BOTTOM	TATA spare parts
281868806304	FELT FOR PANEL REAR QUARTER OUTER RH	TATA spare parts
281868806305	FELT FOR PANEL REAR QUARTER OUTER LOWER	TATA spare parts
281868900103	ASSY DASHBOARD COMPLETE RHD	TATA spare parts
28186890010320	ASSY DASHBOARD SKIN - FOR PROCUREMENT	TATA spare parts
281868900103ZY	ASSY DASHBOARD COMPLETE RHD WITHOUT AIR	TATA spare parts
281868900103ZZ	ASSY DASHBOARD COMPLETE RHD WITHOUT AIR	TATA spare parts
281868900104	ASSY FLOOR CONSOLE RHD	TATA spare parts
281868900104A2	ASSY FLOOR CONSOLE RHD	TATA spare parts
281868900104A3	ASSY FLOOR CONSOLE RHD	TATA spare parts
281868900104AY	ASSY FLOOR CONSOLE RHD	TATA spare parts
281868900105	ASSY UTILITY BOX	TATA spare parts
281868900105A2	UTILITY BOX DK_GRAFITE_1	TATA spare parts
281868900105BB	UTILITY BOX BARLEY_BEIGE	TATA spare parts
281868900106	ASSY GLOVE BOX	TATA spare parts
281868900106A2	ASSY GLOVE BOX	TATA spare parts

281868900106A3	EBONY_1-ASSY GLOVE BOX	TATA spare parts
281868900106BB	ASSY GLOVE BOX	TATA spare parts
281868900107	ASSY AIR VENT LH	TATA spare parts
281868900107A2	ASSY AIR VENT LH	TATA spare parts
281868900107A3	ASSY AIR VENT LH	TATA spare parts
281868900107BB	ASSY AIR VENT LH	TATA spare parts
281868900108	ASSY AIR VENT RH	TATA spare parts
281868900108A2	ASSY AIR VENT RH	TATA spare parts
281868900108A3	ASSY AIR VENT RH	TATA spare parts
281868900108BB	ASSY AIR VENT RH	TATA spare parts
281868900109	ASSY AIR DISTRIBUTION	TATA spare parts
281868900111	ASSY DEFROST AIR DUCT	TATA spare parts
281868900112	ASSY CENTER CLUSTER	TATA spare parts
281868900112ZV	ASSY CENTER CLUSTER	TATA spare parts
281868900112ZY	ASSY CENTER CLUSTER	TATA spare parts
281868900112ZZ	CLRPART_ASSY-ASSY CENTER CLUSTER	TATA spare parts
281868900116	ASSY UTILITY BIN TOUCH LATCH	TATA spare parts
281868900116BB	ASSY UTILITY BIN TOUCH LATCH	TATA spare parts
281868900118	ASSY FLOOR CONSOLE UPPER	TATA spare parts
281868900118AY	SHADW GREY 2-ASSY FLOOR CONSOLE UPPER	TATA spare parts
281868900119	ASSY FLOOR CONSOLE LOWER LH	TATA spare parts
281868900119AY	SHADW GREY 2-ASSY FLOOR CONSOLE LOWER LH	TATA spare parts
281868900120	ASSY DASHBOARD LHD (W/O AIRBAG)	TATA spare parts
281868900122	ASSY GLOVE BOX LID - LHD	TATA spare parts
281868900129	ASSY. DASHBOARD NON PAB RHD BS3/4	TATA spare parts
281868900129A2	ASSY DASHBOARD NON PAB RHD	TATA spare parts
281868900129A3	ASSY DASHBOARD NON PAB RHD	TATA spare parts
281868900129BB	ASSY DASHBOARD NON PAB RHD	TATA spare parts
281868900131	ASSY END COVER LH - RHD	TATA spare parts
281868900131A2	ASSY END COVER LH - RHD	TATA spare parts
281868900131A3	ASSY END COVER LH - RHD	TATA spare parts
281868900131BB	ASSY END COVER LH - RHD	TATA spare parts
281868900132	ASSY END COVER RH - RHD	TATA spare parts
281868900132A2	ASSY END COVER RH - RHD	TATA spare parts
281868900132A3	ASSY END COVER RH - RHD	TATA spare parts
281868900132BB	ASSY END COVER RH - RHD	TATA spare parts
281868900135	ASSY GLOVE BOX LATCH RHD	TATA spare parts
281868900138	ASSY FLOOR CONSOLE COMPLETE	TATA spare parts
281868900145	ASSY DASHBOARD COMPLETE W/O AIRBAG	TATA spare parts
281868900156	ASSY UTILITY BOX	TATA spare parts
281868900157	ASSY ROTARY LATCH	TATA spare parts
281868900159	ASSY UTILITY BOX WITH LATCH	TATA spare parts
281868900160	ASSY ENGINE SHIELD CONSOLE-LHD (FIXED)	TATA spare parts
281868900161	ENGINE SHIELD CONSOLE- RHD (FIXED)	TATA spare parts
281868900161A2	ENGINE SHIELD CONSOLE- RHD (FIXED)	TATA spare parts
281868900161A3	ENGINE SHIELD CONSOLE- RHD (FIXED)	TATA spare parts
281868900162	ASSY DASHBOARD LHD	TATA spare parts



281868900162A2	DK_GRAFITE_1-ASSY DASHBOARD LHD - STAGE	TATA spare parts
281868906301	DASHBOARD SKIN	TATA spare parts
281868906302	NACELLE UPPER	TATA spare parts
281868906302A2	NACELLE UPPER	TATA spare parts
281868906302A3	NACELLE UPPER	TATA spare parts
281868906302AY	NACELLE UPPER	TATA spare parts
281868906303	NACELLE LOWER	TATA spare parts
281868906303A2	NACELLE LOWER	TATA spare parts
281868906303A3	NACELLE LOWER	TATA spare parts
281868906303AY	NACELLE LOWER	TATA spare parts
281868906308	END COVER LH	TATA spare parts
281868906308A2	END COVER LH	TATA spare parts
281868906308BB	END COVER LH	TATA spare parts
281868906309	END COVER RH	TATA spare parts
281868906309A2	END COVER RH	TATA spare parts
281868906309BB	END COVER RH	TATA spare parts
281868906310	FASCIA DRIVER INFORMATION SYSTEM	TATA spare parts
281868906311	INSTRUMENT CLUSTER	TATA spare parts
281868906313	COVER STEERING COLUMN	TATA spare parts
281868906313A2	COVER STEERING COLUMN	TATA spare parts
281868906313A3	EBONY_1-COVER STEERING COLUMN	TATA spare parts
281868906313BB	COVER STEERING COLUMN	TATA spare parts
281868906314	SIDE DEFROST DUCT LH	TATA spare parts
281868906315	SIDE DEFROST DUCT RH	TATA spare parts
281868906316	AIR DUCT CENTRAL	TATA spare parts
281868906319	MIX BOX	TATA spare parts
281868906320	SIDE DEMIST VENT LH	TATA spare parts
281868906321	SIDE DEMIST VENT RH	TATA spare parts
281868906322	FLOOR CONSOLE LOWER RH	TATA spare parts
281868906322AY	SHADW GREY 2-FLOOR CONSOLE LOWER RH	TATA spare parts
281868906323	RADIO BLANK COVER	TATA spare parts
281868906324	ADAPTOR FOR DRIVER INFORMATION SYSTEM	TATA spare parts
281868906325	GLOVE BOX GAP HIDER	TATA spare parts
281868906326	FLOOR CONSOLE BOOT RING	TATA spare parts
281868906326AY	FLOOR CONSOLE BOOT RING	TATA spare parts
281868906329	MATT FOR FLOOR CONSOLE	TATA spare parts
281868906329A2	MATT FOR FLOOR CONSOLE	TATA spare parts
281868906329AY	MATT FOR FLOOR CONSOLE	TATA spare parts
281868906330	FLOOR CONSOLE UPPER CAP	TATA spare parts
281868906330A2	FLOOR CONSOLE UPPER CAP	TATA spare parts
281868906330AY	FLOOR CONSOLE UPPER CAP	TATA spare parts
281868906332	FASCIA INSTRUMENT CLUSTER LHD	TATA spare parts
281868906333	COVER STEERING COLUMN LHD	TATA spare parts
281868906337	NACELLE UPPER GAP HIDER	TATA spare parts
281868906338	FL CONSOLE LWR LH FRONT CAP	TATA spare parts
281868906338AY	FL CONSOLE LWR LH FRONT CAP	TATA spare parts
281868906339	FL CONSOLE LWR LH REAR CAP	TATA spare parts

281868906339AY	FL CONSOLE LWR LH REAR CAP	TATA spare parts
281868906340	FL CONSOLE LWR RH FRONT CAP	TATA spare parts
281868906340AY	FL CONSOLE LWR RH FRONT CAP	TATA spare parts
281868906341	FL CONSOLE LWR RH REAR CAP	TATA spare parts
281868906341AY	FL CONSOLE LWR RH REAR CAP	TATA spare parts
281868906343	DEFROST DUCT FOAM SIDE	TATA spare parts
281868906344	DEFROST DUCT FOAM CENTER	TATA spare parts
281868906345	CLUSTER FINISHER FOAM	TATA spare parts
281868906348	END COVER LH	TATA spare parts
281868906349	END COVER CAP LH & RHD	TATA spare parts
281868906350	END COVER RH	TATA spare parts
281868906351	END COVER CAP RH & RHD	TATA spare parts
281868906357	NACELLE UPPER - LHD	TATA spare parts
281868906357A3	EBONY_1-NACELLE UPPER - LHD	TATA spare parts
281868906358	NACELLE LOWER - LHD	TATA spare parts
281868906358A3	EBONY_1-NACELLE LOWER - LHD	TATA spare parts
281868906360	DASHBOARD SIDE STRIP LH	TATA spare parts
281868906361	DASHBOARD SIDE STRIP RH	TATA spare parts
281868906370	FASCIA FOR DRIVER INFORMATION SYSTEM-LHD	TATA spare parts
281868906371	GLOVE BOX LHD	TATA spare parts
281868906380	UTILITY BIN - RHD	TATA spare parts
281868906501	C NUT -ST 4.8	TATA spare parts
281868916322	BEZEL UPPER	TATA spare parts
281868916327	FASCIA INSTRUMENT CLUSTER	TATA spare parts
281869100101	ASSY PAD SIDEWALL MIDDLE MB RH	TATA spare parts
281869100102	ASSY PAD SIDEWALL REAR UPR LH	TATA spare parts
281869100103	ASSY PAD SIDEWALL REAR UPR RH MBUS	TATA spare parts
281869100104	ASSY PAD SIDEWALL REAR LOWER MB LH	TATA spare parts
281869100105	ASSY PAD SIDEWALL REAR LOWER MB RH	TATA spare parts
281869100106	ASSY PAD SIDEWALL MIDDLE LOWER MB RH	TATA spare parts
281869100108	ASSY SIDE MIDDLE TRIM BASE MB RH	TATA spare parts
281869100108A2	ASSY SIDE MIDDLE TRIM BASE MB RH	TATA spare parts
281869100109BB	ASSY SIDE MIDDLE TRIM LUX MB RH	TATA spare parts
281869100110	ASSY C PILLAR TRIM LOWER MB LH	TATA spare parts
281869100110A2	ASSY C PILLAR TRIM LOWER MB LH	TATA spare parts
281869100110BB	BARLEY_BEIGE-ASSY C PILLAR TRIM LOWER MB	TATA spare parts
281869100111	ASSY REAR QTR TRIM BASE LH	TATA spare parts
281869100111A2	ASSY REAR QTR TRIM BASE LH	TATA spare parts
281869100112BB	ASSY REAR QTR TRIM LUX LH	TATA spare parts
281869100113	ASSY REAR QTR TRIM BASE RH	TATA spare parts
281869100113A2	ASSY REAR QTR TRIM BASE RH	TATA spare parts
281869100114BB	ASSY REAR QTR TRIM LUX RH	TATA spare parts
281869100115	ASSY AIR INTAKE VENT	TATA spare parts
281869100116A2	ASSY REAR AC COVER	TATA spare parts
281869100141	BATTERY COVER ASSY	TATA spare parts
281869105601	GRAB HANDLE LH	TATA spare parts
281869105601A3	GRAB HANDLE LH	TATA spare parts

281869105601AQ	LINEN-GRAB HANDLE LH	TATA spare parts
281869105602	B PILLAR INGRESS HANDLE	TATA spare parts
281869105603	CAP UPPER B PILLAR INGRESS HANDLE	TATA spare parts
281869105604	CAP LOWER B PILLAR INGRESS HANDLE	TATA spare parts
281869106301	A PILLAR TRIM LH	TATA spare parts
281869106301B6	A PILLAR TRIM LH	TATA spare parts
281869106302	A PILLAR TRIM RH	TATA spare parts
281869106302B6	A PILLAR TRIM RH	TATA spare parts
281869106303	B-PILLAR TRIM LH	TATA spare parts
281869106303A3	B-PILLAR TRIM LH	TATA spare parts
281869106304	B PILLAR TRIM RH	TATA spare parts
281869106304A3	B PILLAR TRIM RH	TATA spare parts
281869106311	B PILLAR TRIM UPPER MB LH	TATA spare parts
281869106311B6	BONE-B PILLAR TRIM UPPER MB LH	TATA spare parts
281869106312	B PILLAR TRIM LOWER MB LH	TATA spare parts
281869106312A2	B PILLAR TRIM LOWER MB LH	TATA spare parts
281869106312BB	BARLEY_BEIGE-B PILLAR TRIM LOWER MB LH	TATA spare parts
281869106313	B PILLAR TRIM MB RH	TATA spare parts
281869106313B6	BONE-B PILLAR TRIM MB RH	TATA spare parts
281869106315	C PILLAR TRIM UPPER MB LH	TATA spare parts
281869106315B6	BONE-C PILLAR TRIM UPPER MB LH	TATA spare parts
281869106316	C PILLAR TRIM UPPER MB RH	TATA spare parts
281869106316B6	BONE-C PILLAR TRIM UPPER MB RH	TATA spare parts
281869106319	DIV PILLAR TRIM MB LH	TATA spare parts
281869106319B6	BONE-DIV PILLAR TRIM MB LH	TATA spare parts
281869106320	DIV PILLAR TRIM MB RH	TATA spare parts
281869106320B6	BONE-DIV PILLAR TRIM MB RH	TATA spare parts
281869106321	REAR AC COVER MB RH	TATA spare parts
281869106321A2	REAR AC COVER MB RH	TATA spare parts
281869106321BB	REAR AC COVER MB RH	TATA spare parts
281869106323	C PILLAR TRIM LOWER MB RH	TATA spare parts
281869106323A2	C PILLAR TRIM LOWER MB RH	TATA spare parts
281869106323BB	BARLEY_BEIGE-C PILLAR TRIM LOWER MB RH	TATA spare parts
281869106324	D PILLAR TRIM UPPER MB LH	TATA spare parts
281869106324B6	BONE-D PILLAR TRIM UPPER MB LH	TATA spare parts
281869106325	D PILLAR TRIM UPPER MB RH	TATA spare parts
281869106325B6	BONE-D PILLAR TRIM UPPER MB RH	TATA spare parts
281869106326	D PILLAR TRIM LOWER MB LH	TATA spare parts
281869106326A2	D PILLAR TRIM LOWER MB LH	TATA spare parts
281869106326BB	BARLEY_BEIGE-D PILLAR TRIM LOWER MB LH	TATA spare parts
281869106331	COVER MIDDLE RAIL	TATA spare parts
281869106333	FUEL HOSE COVER TRIM MB	TATA spare parts
281869106333A2	FUEL HOSE COVER TRIM MB	TATA spare parts
281869106333BB	FUEL HOSE COVER TRIM MB	TATA spare parts
281869106334	SPEAKER GRILL MIDDLE TRIM MB RH	TATA spare parts
281869106334A2	SPEAKER GRILL MIDDLE TRIM MB RH	TATA spare parts
281869106334BB	SPEAKER GRILL MIDDLE TRIM MB RH	TATA spare parts

281869106342	ELR COVER LH	TATA spare parts
281869106343	ELR COVER RH	TATA spare parts
281869106344	SCUFF PLATE LH - FRONT	TATA spare parts
281869106344AY	SCUFF PLATE LH	TATA spare parts
281869106345	SCUFF PLATE RH - FRONT	TATA spare parts
281869106345AY	SCUFF PLATE RH	TATA spare parts
281869106350	END CONNECTOR FOR PRE-CLEANER	TATA spare parts
281869106351	CANTRAIL TRIM	TATA spare parts
281869106351B6	CANTRAIL TRIM	TATA spare parts
281869106352	B PILLAR TRIM MB HARDPAD VERSION LH	TATA spare parts
281869106353	B PILLAR TRIM MB HARDPAD VERSION RH	TATA spare parts
281869106354	C PILLAR TRIM MB HARDPAD VERSION LH	TATA spare parts
281869106355	SPARE WHEEL COVER FRONT MB	TATA spare parts
281869106356	SPARE WHEEL COVER REAR MB	TATA spare parts
281869106357	SCUFF PLATE MTG CAP( 1 TONNER)	TATA spare parts
281869106357AY	SCUFF PLATE MTG CAP( 1 TONNER)	TATA spare parts
281869106358	SCUFF PLATE SLIDING DOOR	TATA spare parts
281869106358AY	SCUFF PLATE SLIDING DOOR	TATA spare parts
281869106359	SCUFF PLATE TAILGATE	TATA spare parts
281869106359AY	SCUFF PLATE TAILGATE PELICAN	TATA spare parts
281869106360	ENGINE COVER REAR SCUFF PLATE	TATA spare parts
281869106360AY	ENGINE COVER REAR SCUFF PLATE	TATA spare parts
281869106365A2	CAP SBA CUTOUT C-PILLAR LOWER LH	TATA spare parts
281869106367B6	CAP C-PILLAR UPPER LH	TATA spare parts
281869106375	A PILLAR TRIM LOWER- LH	TATA spare parts
281869106376	A PILLAR TRIM LOWER- RH	TATA spare parts
281869107701	RUBBER SEAL	TATA spare parts
281869300101AY	SHADW_GREY_2-ASSY REAR UTILITY COVER	TATA spare parts
281869300102A2	ASSY REAR UTILITY COVER FOR DICOR VERSIO	TATA spare parts
281869306301	ASSY AIR EXIT VENT	TATA spare parts
281869306309	REAR UTILITY COVER MTG BRKT LH	TATA spare parts
281869306310	REAR UTILITY COVER MTG BRKT RH	TATA spare parts
281869306311AY	MATT OUTBOARD REAR UTILITY COVER	TATA spare parts
281869306312AY	MATT CENTER REAR UTILITY COVER	TATA spare parts
281869306313AY	MATT INBOARD REAR UTILITY COVER	TATA spare parts
281869406301	REAR WALL TRIM	TATA spare parts
281869406302	REAR WALL TRIM (NON A/C)	TATA spare parts
281869406303	REAR WALL LINER SUPERACE	TATA spare parts
281869406304	REAR WALL LINER - SUPERACE RHD	TATA spare parts
281869500101	ASSY ROOFLINER REAR-(HVAC)	TATA spare parts
281869500101B6	ASSY ROOFLINER REAR (HVAC)	TATA spare parts
281869500102	ASSY HEADLINER FRONT FOR 1-TON	TATA spare parts
281869500103	ASSY HEADLINER FRONT	TATA spare parts
281869500103B6	ASSY HEADLINER FRONT	TATA spare parts
281869500104	ASSY HEADLINER FRONT (DOMESTIC)	TATA spare parts
281869500105	ASSY KIT FOAM FOR ROOF INSULATION	TATA spare parts
281869500106	REAR HEADLINER ASSY	TATA spare parts

281869500108	ASSY FRONT HEADLINER	TATA spare parts
281869506303	TOP RAIL COVER MB	TATA spare parts
281869506303B6	TOP RAIL COVER MB	TATA spare parts
281869506304	ROOF LINER REAR MB (NON HVAC)	TATA spare parts
281870000125	ASSY LOADBODY SHELL SIDE DROP	TATA spare parts
281870000127	ASSY EXTENDED LOADBODY PAINTED	TATA spare parts
281870000127BF	ASSY EXTENDED LOADBODY PAINTED	TATA spare parts
281870000127FW	ASSY EXTENDED SIDE DROP LOADBODY PAINTED	TATA spare parts
281870000127FZ	ASSY EXTENDED SIDE DROP LOADBODY PAINTED	TATA spare parts
281870000127GC	ASSY EXTENDED SIDE DROP LOADBODY PAINTED	TATA spare parts
281870000127HF	ASSY EXTENDED SIDE DROP LOADBODY PAINTED	TATA spare parts
281870000130	ASSY KIT EXTENDED LOADBODY SIDE DROP	TATA spare parts
281870000136BF	LOAD BODY PAINTED SIDE FIXED - ARCTIC WH	TATA spare parts
281870000136HF	METEOR_SILVR-ASSY LOADBODY PAINTED SIDE	TATA spare parts
281870000136IC	BLAZING_RED-ASSY LOADBODY PAINTED SIDE F	TATA spare parts
281870000136ID	TWILIGHT_GREY-ASSY LOADBODY PAINTED SIDE	TATA spare parts
281870000138	ASSY LOAD BODY SHELL SIDE FIXED	TATA spare parts
281870000139	ASSY LOADBODY SHELL SIDE DROP	TATA spare parts
281870000141	ASSY EXTENDED LOADBODY PAINTED(EXPORT)	TATA spare parts
281870000141BF	LOAD BODY ARCTIC_WHITE-ASSY EXTENDED SID	TATA spare parts
281870000148	ASSY EXTENDED LOADBODY PAINTED	TATA spare parts
281870000148GC	ASSY EXTENDED SIDE DROP LOADBODY PAINTED	TATA spare parts
281870000149	ASSY LOADBODY SHELL SIDE DROP	TATA spare parts
281870000168	ASSY LOADBODY SHELL SIDE DROP	TATA spare parts
281870000169BF	ASSY SIDE DROP LOADBODY - ARTICWHITE	TATA spare parts
281870000169GC	CASTLE GREY-ASSY SIDE DROP LOAD BODY	TATA spare parts
281870000169HF	METEOR SILVER-ASSY SIDE DROP LOAD BODY	TATA spare parts
281870000169IC	BLAZING RED-ASSY SIDE DROP LOAD BODY	TATA spare parts
281870100167	ASSY. MUDFLAP PANEL BS1/3/4	TATA spare parts
281870106301	REFLECTING TAPE RED (CROSS MEBER LOADBOD	TATA spare parts
281870106902	SUPPORT PIPE MUDGUARD FRONT	TATA spare parts
281870106903	SUPPORT PIPE MUDGUARD REAR	TATA spare parts
281870200110	ASSY LOADGUARD COMPLETE (TUBULAR)	TATA spare parts
281870200130	ASSY.FRONT COVER	TATA spare parts
281870206301	INSULATION FRONT PANEL	TATA spare parts
281870206302	HEAT SHIELD FRONT COVER	TATA spare parts
281870300105	ASSY SIDE PANEL LH SIDE DROP	TATA spare parts
281870300106	ASSY SIDE PANEL RH SIDE DROP	TATA spare parts
281870308225	HOOK BS6-PH2	TATA spare parts
281870400101	ASSY TAILGATE PANEL	TATA spare parts
281870400102	ASSY TAILGATE SKIRT PANEL	TATA spare parts
281870408201	TAILGATE PANEL	TATA spare parts
281870508202	STOPPER LOAD GUARD	TATA spare parts
281870900103	ASSY TOGGLE CLAMP	TATA spare parts
281870900106	ASSY TIE HOOK BS6-PH2	TATA spare parts
281870900108	ASSEMBLY TOGGLE CLAMP DOMESTIC	TATA spare parts
281870906302	RUBBER MUDFLAP 1 TON	TATA spare parts

281870906303	FRONT RUBBER STOPPER	TATA spare parts
281870906304	DAMPER SIDE POST REAR	TATA spare parts
281870906305	FOG LAMP COVER	TATA spare parts
281870906306	RUBBER STOPPER TAILGATE	TATA spare parts
281870906307	RUBBER STOPPER	TATA spare parts
281870906312	MUDGUARD BS3/4/6	TATA spare parts
281870908001	SOCKET HEAD SCREW M8X25	TATA spare parts
281870908203	STRIP MUDFLAP 1 TON	TATA spare parts
281872000103	ASSY. FRONT DOOR SHELL LH BS1/3/4	TATA spare parts
281872000104	ASSY. FRONT DOOR SHELL RH BS1/3/4	TATA spare parts
281872000105	ASSY FRONT DOOR SHELL COMPLETE LH - PAIN	TATA spare parts
281872000106	ASSY FRONT DOOR SHELL COMPLETE RH - PAIN	TATA spare parts
28187200Z103	ASSY FRONT DOOR SHELL COMPLE	TATA spare parts
28187200Z104	ASSY FRONT DOOR SHELL COMPLE	TATA spare parts
281872208205	PANEL INNER FRONT DOOR LH	TATA spare parts
281872208206	PANEL INNER FRONT DOOR RH	TATA spare parts
281872208209	GLASS GUIDE CHANNEL UPPER LH	TATA spare parts
281872208210	GLASS GUIDE CHANNEL UPPER RH	TATA spare parts
28187220C201	PANEL OUTER FRONT DOOR-LH(COATED)	TATA spare parts
28187220C202	PANEL OUTER FRONT DOOR-RH(COATED)	TATA spare parts
281872300107	ASSY BODY SIDE HINGE LOWER LH	TATA spare parts
281872300108	ASSY BODY SIDE HINGE LOWER RH	TATA spare parts
281872300113	KIT-LOCKS BS1/3/4	TATA spare parts
281872300113A3	KIT- LOCKS BS1/3/4	TATA spare parts
281872300117	KIT ASSY LOCK KIT SET	TATA spare parts
281872300117BB	KIT ASSY LOCK KIT SET-PELICAN	TATA spare parts
281872300118	ASSY. MANUAL WINDOW REGULATOR LH BS1/3/4	TATA spare parts
281872300119	ASSY. MANUAL WINDOW REGULATOR RH BS1/3/4	TATA spare parts
281872300121	ASSY LATCH WITH LINKS LH	TATA spare parts
281872300122	ASSY LATCH WITH LINKS RH	TATA spare parts
281872300123	ASSY FRONT DOOR CHECK	TATA spare parts
281872300125	ASSY FRONT DOOR DUST SEAL	TATA spare parts
281872300126A2	DK_GRAFITE_1-ASSY FRONT DOOR INNER HANDL	TATA spare parts
281872300126A3	ASSY FRONT DOOR INNER HANDLE W/LINKS-LH	TATA spare parts
281872300126BB	ASSY FRONT DOOR INNER HANDLE LH	TATA spare parts
281872300127A2	DK_GRAFITE_1-ASSY FRONT DOOR INNER HANDL	TATA spare parts
281872300127A3	ASSY FRONT DOOR INNER HANDLE W/LINKS-RH	TATA spare parts
281872300127BB	BARLEY_BEIGE-ASSY FRONT DOOR INNER HANDL	TATA spare parts
281872300128	KIT ASSY FRONT DOOR OUTER HANDLE LH	TATA spare parts
281872300128A3	KIT ASSY FRONT DOOR OUTER HANDLE LH	TATA spare parts
281872300128BF	KIT ASSY FRONT DOOR OUTER HANDLE LH ARCT	TATA spare parts
281872300128FW	KIT ASSY FRONT DOOR OUTER HANDLE LH IVOR	TATA spare parts
281872300128FY	KIT ASSY FRONT DOOR OUTER HANDLE LH LUNA	TATA spare parts
281872300128FZ	KIT ASSY FRONT DOOR OUTER HANDLE LH CHAM	TATA spare parts
281872300128GC	KIT ASSY FRONT DOOR OUTER HANDLE LH - CA	TATA spare parts
281872300128GM	KIT ASSY FRONT DOOR OUTER HANDLE LH	TATA spare parts
281872300128HF	KIT ASSY FRONT DOOR OUTER HANDLE LH	TATA spare parts

281872300129	KIT ASSY FRONT DOOR OUTER HANDLE RH	TATA spare parts
281872300129A3	KIT ASSY FRONT DOOR OUTER HANDLE RH	TATA spare parts
281872300129BF	KIT ASSY FRONT DOOR OUTER HANDLE RH ARCT	TATA spare parts
281872300129FW	KIT ASSY FRONT DOOR OUTER HANDLE RH IVOR	TATA spare parts
281872300129FY	KIT ASSY FRONT DOOR OUTER HANDLE RH LUNA	TATA spare parts
281872300129FZ	KIT ASSY FRONT DOOR OUTER HANDLE RH CHAM	TATA spare parts
281872300129GC	KIT ASSY FRONT DOOR OUTER HANDLE RH - CA	TATA spare parts
281872300129GM	KIT ASSY FRONT DOOR OUTER HANDLE RH	TATA spare parts
281872300129HF	KIT ASSY FRONT DOOR OUTER HANDLE RH	TATA spare parts
281872303301	BRACKET - CHECK STRAP MTG	TATA spare parts
281872305001	BODY SIDE HINGE UPPER LH	TATA spare parts
281872305002	BODY SIDE HINGE UPPER RH	TATA spare parts
281872305003	BODY SIDE HINGE LOWER LH	TATA spare parts
281872305004	BODY SIDE HINGE LOWER RH	TATA spare parts
281872305006	UPPER HINGE DOOR SIDE RH	TATA spare parts
281872306003	LINK - INNER HANDLE LH	TATA spare parts
281872306004	LINK - INNER HANDLE RH	TATA spare parts
281872306005	LINK - LOCKING KNOB LH	TATA spare parts
281872306006	LINK - LOCKING KNOB RH	TATA spare parts
281872306007	LINK - SOLENOIDE LH	TATA spare parts
281872306008	LINK - SOLENOIDE RH	TATA spare parts
281872306307	PRIMARY SEAL FRONT DOOR LH	TATA spare parts
281872306308	PRIMARY SEAL FRONT DOOR RH	TATA spare parts
281872306309	FRONT DOOR WAIST SEAL OUTER LH	TATA spare parts
281872306310	FRONT DOOR WAIST SEAL OUTER RH	TATA spare parts
281872306311	FRONT DOOR WAIST SEAL INNER LH	TATA spare parts
281872306312	FRONT DOOR WAIST SEAL INNER RH	TATA spare parts
281872306313	FRONT DOOR PRIMARY SEAL LH	TATA spare parts
281872306314	FRONT DOOR PRIMARY SEAL RH	TATA spare parts
281872306318	SECONDARY SEAL FRONT DOOR LH	TATA spare parts
281872306319	SECONDARY SEAL FRONT DOOR RH	TATA spare parts
281872306320	SCREW CAP INR HANDLE FRT DR-LH	TATA spare parts
281872306321	SCREW CAP INR HANDLE FRT DR-RH	TATA spare parts
281872306701	HINGE PIN	TATA spare parts
281872309201	WASHER HINGE	TATA spare parts
281872500103	ASSY GUIDE CHANNEL FRONT	TATA spare parts
281872500104	ASSY GUIDE CHANNEL FRONT RH	TATA spare parts
281872500105	ASSY GUIDE CHANNEL REAR LH	TATA spare parts
281872500106	ASSY GUIDE CHANNEL REAR RH	TATA spare parts
281872500111	ASSY. POWER WINDOW REGULATOR LH BS1/3/4	TATA spare parts
281872500112	ASSY. POWER WINDOW REGULATOR RH BS1/3/4	TATA spare parts
281872502301	REGULATING GLASS FRONT DOOR LH	TATA spare parts
281872502302	REGULATING GLASS FRONT DOOR RH	TATA spare parts
281872502303	REGULATING GLASS FRONT DOOR - TINTED LH	TATA spare parts
281872502304	REGULATING GLASS FRONT DOOR TINTED RH	TATA spare parts
281872506303	FRONT DOOR GLASS RUN MOULD LH	TATA spare parts
281872506304	FRONT DOOR GLASS RUN MOULD RH	TATA spare parts

281872700101	ASSY FRONT DOOR TRIM LH PWR W/W-B001	TATA spare parts
281872700101BB	ASSY FRONT DOOR TRIM LH PWR W/W-B001	TATA spare parts
281872700102	ASSY FRONT DOOR TRIM RH PWR W/W-LUX	TATA spare parts
281872700102BB	ASSY FRONT DOOR TRIM RH PWR W/W-LUX	TATA spare parts
281872700103	ASSY FRONT DOOR TRIM LH BASE	TATA spare parts
281872700103A2	DK_GRAFITE_1-ASSY FRONT DOOR TRIM POWER	TATA spare parts
281872700103A3	ASSY FRONT DOOR TRIM POWER WINDOW WITH	TATA spare parts
281872700104	ASSY FRONT DOOR TRIM RH BASE	TATA spare parts
281872700104A2	DK_GRAFITE_1-ASSY FRONT DOOR TRIM POWER	TATA spare parts
281872700104A3	ASSY FRONT DOOR TRIM POWER WINDOW WITH	TATA spare parts
281872700107	ASSY FRONT DOOR TRIM MANUAL WINDOW WIT	TATA spare parts
281872700107A2	ASSY FRONT DOOR TRIM MANUAL WINDOW WIT	TATA spare parts
281872700107A3	ASSY FRONT DOOR TRIM MANUAL WINDOW WIT	TATA spare parts
281872700108	ASSY FR DR TRIM RH MANUAL W/W	TATA spare parts
281872700108A2	ASSY FR DR TRIM RH MANUAL W/W	TATA spare parts
281872700108A3	ASSY FRONT DOOR TRIM MANUAL WINDOW WIT	TATA spare parts
281872706301	PLASTIC MEMBRANE FRONT DOOR LH	TATA spare parts
281872706302	PLASTIC MEMBRANE FRONT DOOR RH	TATA spare parts
281872706315	MATT FOR FRONT DOOR TRIM LH	TATA spare parts
281872706316	MATT FOR FRONT DOOR TRIM RH	TATA spare parts
281873000101	ASSY SLIDING DOOR SHELL LH	TATA spare parts
281873000115	ASSY SLIDING DOOR SHELL FOR MOULDED TRIM	TATA spare parts
281873300107	ASSY BOTTOM CARRIAGE LH	TATA spare parts
281873300108	ASSY MIDDLE CARRIAGE LH	TATA spare parts
281873300110	ASSY TOP CARRIAGE LH	TATA spare parts
281873300112	ASSY TOP RAIL LH	TATA spare parts
281873300115	ASSY MIDDLE RAIL LH	TATA spare parts
281873300118	SLIDING DOOR OUTER HANDLE LH	TATA spare parts
281873300118A3	SLIDING DOOR OUTER HANDLE LH	TATA spare parts
281873300118BF	SLIDING DOOR OUTER HANDLE LH ARCTIC_WHITE	TATA spare parts
281873300118FW	SLIDING DOOR OUTER HANDLE LH IVORY_WHITE	TATA spare parts
281873300118FY	SLIDING DOOR OUTER HANDLE LH	TATA spare parts
281873300118FZ	SLIDING DOOR OUTER HANDLE LH CHAMPGN GO	TATA spare parts
281873300131	ASSY STOPPER ACTIVE LOCK	TATA spare parts
281873300133	ASSY MIDDLE CARRIAGE STOPPER	TATA spare parts
281873300134	ASSY CENTERING PIN DOOR SIDE	TATA spare parts
281873300135	ASSY CENTERING PIN BODY SIDE	TATA spare parts
281873300137	ASSY ACTIVE LOCK CABLE	TATA spare parts
281873300140	ASSY REMOTE LATCH SLIDING DOOR	TATA spare parts
281873300141	ASSY MAIN LATCH SLIDING DOOR	TATA spare parts
281873300144	ASSY SLIDING DOOR INNER HANDLE	TATA spare parts
281873300145	ASSY SLIDING DOOR STRIKER	TATA spare parts
281873300150	KIT ASSY SLD OUTER HANDLE	TATA spare parts
281873303402	BUSH FOR SLIDING GLASS FRAME	TATA spare parts
281873306001	LINK POPUP KNOB TO LATCH	TATA spare parts
281873306002	LINK REMOTE LATCH TO CRANK	TATA spare parts
281873306004	LINK REMOTE LATCH TO BELL CRANK	TATA spare parts



281873306005	LINK BELL CRANK TO CLU	TATA spare parts
281873306315	RUBBER STOPPER SLIDING DOOR	TATA spare parts
281873307704	LOCATING PIN	TATA spare parts
281873307705	RESTING PAD WITH ACRYLIC TAPE	TATA spare parts
281873307709	CLIP FOR RAIL	TATA spare parts
281873307713	FRAME FOR SLIDING GLASS	TATA spare parts
281873307714	SEAL FOR SLIDING GLASS FRAME	TATA spare parts
281873307715	COVER FOR BOTTOM KNOB	TATA spare parts
281873307716	BOTTOM KNOB FOR SLIDING GLASS FRAME	TATA spare parts
281873307717	COVER FOR TOP KNOB	TATA spare parts
281873307718	TOP KNOB FOR SLIDING GLASS FRAME	TATA spare parts
281873307719	SKATE BOTTOM	TATA spare parts
281873307720	SKATE TOP LOCKER SIDE	TATA spare parts
281873307721	SKATE TOP SLIDING GLASS SIDE	TATA spare parts
281873307722	FELT ANTI-NOISE FOR FRAME SLIDING GLASS	TATA spare parts
281873307723	FRONT LOWER COVER FOR FRAME SLIDING GLAS	TATA spare parts
281873307724	FRONT UPPER COVER FOR FRAME SLIDING GLAS	TATA spare parts
281873307725	BACK LOWER COVER FOR FRAME SLIDING GLASS	TATA spare parts
281873307726	BACK UPPER COVER FOR FRAME SLIDING GLASS	TATA spare parts
281873308002	M6 STAR SCREW_SLD MSM	TATA spare parts
281873308003	SCREW FOR KNOB COVER	TATA spare parts
281873308009	TORX SCREW M8	TATA spare parts
281873308011	SPECIAL RD CSK SCREW M6X16	TATA spare parts
281873308201	BOTTOM RAIL LH	TATA spare parts
281873308703	COMPRESSION SPRING	TATA spare parts
281873308803	STUD FOR SLIDING GLASS FRAME	TATA spare parts
281873500109	ASSY SLIDING GLASS PLUG-IN WINDOW LH	TATA spare parts
281873500110	ASSY PLUG-IN WINDOW LH	TATA spare parts
281873500112	ASSY PLUG-IN WINDOW RH	TATA spare parts
281873500114	ASSY SLIDING GLASS PLUG-IN WINDOW RH	TATA spare parts
281873506301	PRIMARY SEAL SLIDING DOOR	TATA spare parts
281873506309	MOULD EDGE FINISHER PLUG-IN WINDOW LH	TATA spare parts
281873506310	MOULD PRIMARY SEAL SLIDING DOOR	TATA spare parts
281873506311	SECONDARY SEAL SLIDING DOOR	TATA spare parts
281873506312	MOULD EDGE FINISHER PLUG-IN WINDOW RH	TATA spare parts
281873700101	ASSY PAD SLIDING DOOR MB LH	TATA spare parts
281873700102A2	DK_GRAFITE_1-ASSY SLIDING DOOR TRIM BASE	TATA spare parts
281873700103	ASSY SLIDING DOOR TRIM LUX LH	TATA spare parts
281873700103BB	ASSY SLIDING DOOR TRIM LUX MB LH	TATA spare parts
281873706305A2	SLIDING DOOR TRIM SPEAKER GRILL MB LH	TATA spare parts
281873706308A2	SLEEVE SLIDING DOOR INSERT FOR NON-FABRI	TATA spare parts
281873706310	PLASTIC MEMBRANE SLIDING DOOR	TATA spare parts
281873706311A2	SLIDING DOOR TRIM CAP	TATA spare parts
281874000102	ASSY TAILGATE SHELL COMPLETE	TATA spare parts
28187400010212	CED ASSY TAILGATE SHELL COMPLETE	TATA spare parts
281874208201	PANEL TAILGATE OUTER	TATA spare parts
281874300107	ASSY TAILGATE BALANCER COMPLETE RH	TATA spare parts

281874300109	ASSY INNER HANDLE TAILGATE	TATA spare parts
281874300109A2	DK_GRAFITE_1-ASSY INNER HANDLE TAILGATE	TATA spare parts
281874300109BB	BARLEY_BEIGE-ASSY INNER HANDLE TAILGATE	TATA spare parts
281874300110	ASSY LATCH TAILGATE	TATA spare parts
281874300111	ASSY TAILGATE OUTER HANDLE	TATA spare parts
281874300112	ASSY TAILGATE BALANCER COMPLETE LH	TATA spare parts
281874300113	ASSY TAILGATE BALANCER COMPLETE RH	TATA spare parts
281874300115	ASSY TAILGATE STRIKER	TATA spare parts
281874306001	LINK INNER HANDLE TOP	TATA spare parts
281874306002	LINK INNER HANDLE BOTTOM	TATA spare parts
281874306003	LINK POP UP KNOB TOP	TATA spare parts
281874306004	LINK POP UP KNOB BOTTOM	TATA spare parts
281874306005	LINK CENTRAL LOCKING UNIT	TATA spare parts
281874306006	LINK LOCK BARREL	TATA spare parts
281874306007	LINK-OUTER HANDLE	TATA spare parts
281874306301	REGISTRATION PLATE TAILGATE GARNISH	TATA spare parts
281874500102	ASSY TAILGATE GLASS TINTED-STD	TATA spare parts
281874500103	ASSY TAILGATE GLASS TINTED WITH HOLE & D	TATA spare parts
281874502301	TAILGATE GLASS TINTED-STD	TATA spare parts
281874502302	TAILGATE GLASS TINTED WITH HOLE & DIMIST	TATA spare parts
281874506304	TAIL GATE PRIMARY SEAL	TATA spare parts
281874700101	ASSY PAD TAILGATE MB	TATA spare parts
281874700101A2	ASSY PAD TAILGATE	TATA spare parts
281874700101BB	ASSY PAD TAILGATE	TATA spare parts
281874706301	REAR WIPER MOTOR COVER MB	TATA spare parts
281874706302	PLASTIC MEMBRANE TAILGATE	TATA spare parts
281881100101	ASSY SUNVISOR LH	TATA spare parts
281881100103	ASSY ORVM LH CABLE TYPE	TATA spare parts
281881100103FZ	ASSY ORVM LH-CABLE TYPE	TATA spare parts
281881100104	ASSY ORVM RH CABLE TYPE	TATA spare parts
281881100104FY	ASSY ORVM RH-CABLE TYPE	TATA spare parts
281881100104FZ	ASSY ORVM RH-CABLE TYPE	TATA spare parts
281881100106	ASSY SUNVISOR RH	TATA spare parts
281881100107	ASSY SEAT TIE BELT	TATA spare parts
281881100108	ASSY ORVM LH - TIP TAP TYPE	TATA spare parts
281881100109	ASSY ORVM RH - TIP TAP TYPE	TATA spare parts
281881100116	ORVM ASSEMBLY CABLE TYPE LH-RHD	TATA spare parts
281881100116BF	ARCTIC_WHITE-ORVM ASSEMBLY CABLE TYPE LH	TATA spare parts
281881100116FW	ORVM ASSEMBLY CABLE TYPE LH	TATA spare parts
281881100116FY	ORVM ASSEMBLY CABLE TYPE LH	TATA spare parts
281881100116FZ	CHAMPGN_GOLD-ORVM ASSEMBLY CABLE TYPE LH	TATA spare parts
281881100117	ORVM ASSEMBLY CABLE TYPE RH-RHD	TATA spare parts
281881100117BF	ARCTIC_WHITE-ORVM ASSEMBLY CABLE TYPE RH	TATA spare parts
281881100117FW	ORVM ASSEMBLY CABLE TYPE RH	TATA spare parts
281881100117FY	ORVM ASSEMBLY CABLE TYPE RH	TATA spare parts
281881100117FZ	CHAMPGN_GOLD-ORVM ASSEMBLY CABLE TYPE RH	TATA spare parts
281881100118	ASSY. ORVM TIP TAP TYPE-LH-RH BS1/3/4	TATA spare parts

281881100119	ASSY. ORVM TIP TAP TYPE-RH BS1/3/4	TATA spare parts
281881100124	OUTER REAR VIEW MIRROR LH	TATA spare parts
281881100125	OUTER REAR VIEW MIRROR RH	TATA spare parts
281881100126	ORVM ASSY TIP TAP TYPE LH	TATA spare parts
281881100127	ORVM ASSY TIP TAP TYPE RH	TATA spare parts
281881100134	ASSY NEW ORVM INNER COVER CABLE TYPE LH	TATA spare parts
281881100135	ASSY NEW ORVM INNER COVER CABLE TYPE RH	TATA spare parts
281881100137	SUNVISOR DRIVER SIDE - SUPERACE-LHD	TATA spare parts
281881100140	ORVM ASSEMBLY RH (INDICATOR TYPE) & SS	TATA spare parts
281881100140BF	ARCTIC_WHITE-ORVM ASSEMBLY RH (INDICATOR	TATA spare parts
281881100140HF	METEOR_SILVR-ORVM ASSEMBLY RH (INDICATOR	TATA spare parts
281881100141	ORVM ASSEMBLY LH (INDICATOR TYPE) & SS	TATA spare parts
281881100141BF	ARCTIC_WHITE-ORVM ASSEMBLY LH (INDICATOR	TATA spare parts
281881100141HF	METEOR_SILVR-ORVM ASSEMBLY LH (INDICATOR	TATA spare parts
281881100142	ASSEMBLY VENTURE FRONT SEAT HOLDING STRA	TATA spare parts
281881100144	OUTER REAR VIEW MIRROR LH	TATA spare parts
281881100145	OUTER REAR VIEW MIRROR RH	TATA spare parts
281881106301	INNER COVER ORVM CABLE TYPE LH	TATA spare parts
281881106304	INNER COVER ORVM CABLE TYPE RH	TATA spare parts
281881106306	INNER COVER ORVM TIP-TAP TYPE LH	TATA spare parts
281881106307	INNER COVER ORVM TIP-TAP TYPE RH	TATA spare parts
281881106308	BLACKENING TAPE MIDDLE RAIL LH	TATA spare parts
281881106310	BLACKENING TAPE PANEL FRONT DOOR OUTER L	TATA spare parts
281881106311	BLACKENING TAPE PANEL FRONT DOOR OUTER R	TATA spare parts
281881106314	CLOSING PAD SLIDING DOOR FRONT	TATA spare parts
281881106316	ASSY COVER BOTTOM RAIL	TATA spare parts
281881106317	SUPPORT BOTTOM RAIL COVER	TATA spare parts
281881106318	CLOSING PAD MIDDLE SLIDING DOOR REAR LH	TATA spare parts
281881106319	CLOSING PAD MIDDLE CARRIAGE	TATA spare parts
281881106320	TAILGATE STRIKER AREA BLACK STICKER	TATA spare parts
281881106335	UPPER CAP INNER COVER LH	TATA spare parts
281881106336	LOWER CAP INNER COVER LH	TATA spare parts
281881106338	UPPER CAP INNER COVER RH	TATA spare parts
281881106339	LOWER CAP INNER COVER RH	TATA spare parts
281881207701	FRONT SEAL ENGINE COVER FRONT	TATA spare parts
281881207702	REAR SEAL ENGINE COVER FRONT	TATA spare parts
281881207703	SEAL UPPER - ENGINE COVER REAR PELICAN	TATA spare parts
281881207704	SEAL LOWER - ENGINE COVER REAR PELICAN	TATA spare parts
281881207705	SEAL VERTICAL WALL LH - ENGINE COVER REA	TATA spare parts
281881207706	SEAL VERTICAL WALL RH - ENGINE COVER REA	TATA spare parts
281881207709	FRONT SEAL PANEL ENGINE SHIELD - LHD	TATA spare parts
281881207710	REAR SEAL PANEL ENGINE SHIELD - LHD	TATA spare parts
281881207715	FRONT SEAL PANEL ENGINE SHIELD - RHD DIC	TATA spare parts
281881304701	COVER FUEL NECK MBUS	TATA spare parts
281881400101	ASSLY MAGAZINE POCKET	TATA spare parts
281881400101A3	EBONY_BLACK- ASSLY MAGAZINE POCKET	TATA spare parts
281881706301	PLASTIC MEMBRANE PANEL REAR QUARTER INNE	TATA spare parts

281881706302	PLASTIC MEMBRANE PANEL REAR QUARTER INNE	TATA spare parts
281881706303	PLASTIC MEMBRANE PANEL REAR QUARTER INNE	TATA spare parts
281881706304	PLASTIC MEMBRANE PANEL REAR QTR FRONT BO	TATA spare parts
281881706305	PLASTIC MEMBRANE PANEL REAR QUARTER REAR	TATA spare parts
281881706306	PLASTIC MEMBRANE PANEL REAR QUARTER MIDD	TATA spare parts
281881706307	PLASTIC MEMBRANE SEAT BELT	TATA spare parts
281881706308	PLASTIC MEMBRANE FUEL HOUSING COVER	TATA spare parts
281881806301	MASCOT FOR ACE 1-TON	TATA spare parts
281881806302	MASCOT FOR VENTURE	TATA spare parts
281881806305	MASCOT FOR VENTURE_GX	TATA spare parts
281881806306	MASCOT FOR VENTURE LX	TATA spare parts
281881806307	MASCOT FOR VENTURE_EX	TATA spare parts
281881806308	MASCOT FOR VENTURE_CX	TATA spare parts
281881806309	FRONT DOOR DECAL LH - SUPERACE RHD	TATA spare parts
281881806310	FRONT DOOR DECAL RH - SUPERACE RHD	TATA spare parts
281881806313	DECALS SUPERACE 1 TON RHD	TATA spare parts
281881806314	BLACK TAPE TATA STICKER	TATA spare parts
281881806323	FRONT DECAL	TATA spare parts
281881806324	FRONT DOOR DECAL LH	TATA spare parts
281881806325	FRONT DOOR DECAL RH	TATA spare parts
281881806329	MINT MASCOT	TATA spare parts
281881906301	GROMMET FOR A PILLAR INNER LOWER	TATA spare parts
281881906311	PLUG BUTTON	TATA spare parts
281881990100	KIT SPARE WHEEL CARRIER AMBULANCE	TATA spare parts
281881990101	KIT FIRST AID BOX	TATA spare parts
281881990102	KIT MEDICAL CABINET	TATA spare parts
281881990103	KIT SALINE HOOK	TATA spare parts
281881997702	ADHESIVE TAPE	TATA spare parts
281881997703	ADHESIVE TAPE	TATA spare parts
281881997704	ADHESIVE TAPE	TATA spare parts
281882400101	KIT-WIPER FRONT BS1/3/4	TATA spare parts
281882400107	REAR WIPER ARM AND BLADE ASSEMBLY	TATA spare parts
281882400108	KIT_WASHER_SYSTEM_MICROBUS	TATA spare parts
281882400109	KIT_WASHER_SYSTEM_ONETONNER	TATA spare parts
281882400112	ASSY FRONT WIPER KIT	TATA spare parts
281882400113	WIPER ARM AND BLADE (DRIVER)- MICROBUS)	TATA spare parts
281882400114	WIPER ARM AND BLADE (CO-DRIVER)- MICROBU	TATA spare parts
281882400116	WIPER BLADE ASSY DRIVER SIDE	TATA spare parts
281882400118	WIPER BLADE ASSY CO-DRIVER	TATA spare parts
281882400119	REAR_WIPER_SYSTEM_MICROBUS	TATA spare parts
281882400121	NOZZLE UNIT CO-DRIVER SIDE BS4	TATA spare parts
281882400122	Wiping System	TATA spare parts
281882400131	ASSEMBLY WIPER KIT -LHD	TATA spare parts
281882400132	WIPER MOTOR- LHD	TATA spare parts
281882400133	ASSY WIPER ARM & BLADE DRIVER -LHD	TATA spare parts
281882400134	ASSY WIPER ARM & BLADE CO-DRIVER -LHD	TATA spare parts
281882400135	WIPER ARM DRIVER SIDE	TATA spare parts

281882400136	WIPER ARM CO-DRIVER SIDE	TATA spare parts
281882400144	KIT WASHER SYSTEM SUPERACE LHD PETROL	TATA spare parts
281882406310	PIPE FROM BOTTLE TO Y JOINT	TATA spare parts
281882406311	PIPE FROM Y JOINT TO CODRIVER	TATA spare parts
281882406312	PIPE FROM Y JOINT TO DRIVER	TATA spare parts
281882406314	WASHER_BOTTLE_ONE TONNER	TATA spare parts
281882406316	PIPE FROM Y JOINT TO CODRIVER LHD	TATA spare parts
281882406317	PIPE FROM Y JOINT TO DRIVER LHD	TATA spare parts
281882406323	HOSE_MTG_CLIP_DIA5	TATA spare parts
281882406325	HOSE MTG CLIP DIA 7	TATA spare parts
281882406332	PIPE FROM PUMP TO T JOINT LHD PETROL	TATA spare parts
281882407501	RUBBER BOOT FOR (WHEEL BOX)	TATA spare parts
281882407502	RUBBER SEAL FOR WIPER MOUNTING LH	TATA spare parts
281882407503	RUBBER SEAL FOR WIPER MOUNTING RH	TATA spare parts
281882409905	PUMP ASSY	TATA spare parts
281882409911	WIPER BLADE DRIVER BS1/3/4	TATA spare parts
281882409912	WIPER ARM DRIVER BS4	TATA spare parts
281882409913	WIPER BLADE CO-DRIVER BS1/3/4	TATA spare parts
281882409914	WIPER ARM? CO-DR BS4	TATA spare parts
281882409915	SPACER	TATA spare parts
281882409918	WASHER PUMP	TATA spare parts
281882409920	STATIC MTG ROD ASSEMBLY	TATA spare parts
281882900102	WASHER SYSTEM ASSY	TATA spare parts
281882900145	KIT-WASHER SYSTEM	TATA spare parts
281883103301	FOAM	TATA spare parts
281883106301	OFF TAKE DUCT REAR AC-MICROBUS	TATA spare parts
281883400106	ASSY HVAC CONTROL PANEL-FRONT-MANUAL	TATA spare parts
281883400112	KIT FOR MISC - HVAC	TATA spare parts
281883400117	ASSY HOSE HEATER INLET	TATA spare parts
281883400118	ASSY HOSE HEATER OUTLET	TATA spare parts
281883400120	ASSY BRACKET FOR HEATER CASING MOUNTING	TATA spare parts
281883400124	ASSY HOSE SUCTION	TATA spare parts
281883400125	PIPE SUCTION ASSY - A	TATA spare parts
281883400126	PIPE SUCTION ASSY - B	TATA spare parts
281883400127	ASSY HOSE DISCHARGE	TATA spare parts
281883400128	PIPE DISCHARGE ASSY - A	TATA spare parts
281883400129	PIPE DISCHARGE ASSY - B	TATA spare parts
281883400130	ASSY TUBE LIQUID AND ACCESSORIES	TATA spare parts
281883400133	BRACKET FOR HEATER HOSE CLAMP	TATA spare parts
281883400135	CONTROL PANEL FOR ONLY AC	TATA spare parts
281883400137	ASSY FRONT HVAC COMPLETE - ACE1 1 TON	TATA spare parts
281883400139	ASSY HEATING & DEMISTING FRONT-ACE 1TON	TATA spare parts
281883400140	ASSY COOLING UNIT	TATA spare parts
281883400141	EVAPORATOR CORE	TATA spare parts
281883400142	VALVE EXPENSION	TATA spare parts
281883400143	ASSY HEATER UNIT- ACE 1 TON	TATA spare parts
281883400144	ASSY HVAC ADAPTOR	TATA spare parts

281883400145	ASSY AIR INTAKE UNIT	TATA spare parts
281883400146	ASSY CONDENSER COMPLETE-ACE 1 TON	TATA spare parts
281883400147	ASSY VENTILATION SYSTEM-ACE 1T	TATA spare parts
281883400150	CONTROL PANEL FOR HEATING AND DIMISTING	TATA spare parts
281883400153	CONTROL PANEL	TATA spare parts
281883400154	ASSY CONDENSER MICROBUS	TATA spare parts
281883400155	REAR AC ASSY MICROBUS-CAD DATA	TATA spare parts
281883400156	ASSY AC PIPING MICROBUS	TATA spare parts
281883400157	ASSY AIR INTAKE UNIT- BLOWER UNIT	TATA spare parts
281883400158	COMPRESSOR ASSEMBLY FOR MICROBUS - RECIP	TATA spare parts
281883400159	PIPE ASSY; INLET OUTLET	TATA spare parts
281883400160	EPIPE ASSY D , LIQUID.	TATA spare parts
281883400161	PIPE ASSY C LIQUID	TATA spare parts
281883400162	PIPE ASSY B LIQUID	TATA spare parts
281883400163	HOSE ASSY B SUCTION-BS IV	TATA spare parts
281883400164	HOSE ASSY SUCTION	TATA spare parts
281883400165	HOSE ASSY. B SUCTION	TATA spare parts
281883400166	PIPE ASSY-A SUCTION	TATA spare parts
281883400167	HOSE ASSY DISCHARGE	TATA spare parts
281883400168	SOLINOID VALVE - PELICAN	TATA spare parts
281883400169	ASSY AC PIPING - MICROBUS	TATA spare parts
281883400170	PIPE ASSY B LIQUID	TATA spare parts
281883400171	PIPE ASSY-B DISCHARGE	TATA spare parts
281883400172	VENTURE 1.4L DICOR HVAC KIT	TATA spare parts
281883400176	SUCTION PIPE ASSY	TATA spare parts
281883400177	DISCHARGE PIPE ASSY	TATA spare parts
281883400178	BRACKET FOR AC PIPING- EURO IV	TATA spare parts
281883400186	MISC (ALL CLAMPS) FO HVAC LINES FITMENT	TATA spare parts
281883400188	AC UNIT FOR SUPER ACE	TATA spare parts
281883400189	COOLING UNIT CASING	TATA spare parts
281883400191	SECONDRY DRAIN & GROMMET	TATA spare parts
281883400198	SUCTION HOSE ASSY	TATA spare parts
281883400199	DISCHARGE HOSE ASSY	TATA spare parts
281883400212	ADAPTER DUCT ASSY	TATA spare parts
281883400214	PIPE ASSY A SUCTION	TATA spare parts
281883400217	ASSLY HEATER HOSE - BS IV	TATA spare parts
281883400224	HEATER UNIT ASSY	TATA spare parts
281883400243	AC COMPRESSORç QS 90 5PK 1.4L DICOR VENT	TATA spare parts
281883400248	MODIFIED CONDENSER	TATA spare parts
281883400254	AC CONDENSER-SUPER ACE LHD	TATA spare parts
281883400256	ONLY AC UNIT ASSY	TATA spare parts
281883400265	UNIT SUB ASSY FAD WITH CENTER DUCT	TATA spare parts
281883400266	EVAPORATOR ASSY WITH PIPE	TATA spare parts
281883400267	ASSY BKT MTG ASSY SUCTION PIPE	TATA spare parts
281883400274	BLOWER UNIT ASSY	TATA spare parts
281883403301	BRACKET FOR AC LINES FITTMENT	TATA spare parts
281883403306	BRACKET FOR HEATER HOSE CLAMP ( W/ARCH)	TATA spare parts

281883403307	BRACKET HEATER HOSE CLAMP	TATA spare parts
281883403320	ASSLY BRACKET FOR HEATER CASING MOUNTING	TATA spare parts
281883403326	BRACKET ASSY AC PIPE MTG	TATA spare parts
281883403331	AC PIPING BRACKET MOUNTED WITH STE	TATA spare parts
281883403334	CLAMP PIPING	TATA spare parts
281883403335	CLAMP PIPING	TATA spare parts
281883403339	RETAINER BRACKET FOR ONLY AC & ONLY BLOW	TATA spare parts
281883403344	BRACKET HVAC UNIT MTG	TATA spare parts
281883403345	BRACKET TXV PIPE MTG	TATA spare parts
281883403346	BRACKET TXV PIPE MTG	TATA spare parts
281883403348	"BRACKET,FRESH AIR ACTUATOR MTG 2"	TATA spare parts
281883403349	MODE ACTUATOR MNTG BRACKET 1	TATA spare parts
281883403350	SERVO MOTOR BRACKET	TATA spare parts
281883403351	HEATER ACTUATOR MNTG BRACKET 1	TATA spare parts
281883404201	CLAMP FOR AC LINES FITMENT	TATA spare parts
281883404204	CLAMP FOR AC LINES FITMENT	TATA spare parts
281883404208	SPACER CLAMP FOR AC PIPING - ACE 1T	TATA spare parts
281883404210	CLAMP FOR LIQUID PIPE	TATA spare parts
281883404907	BLOWER MOTOR - REAR AC	TATA spare parts
281883404909	TEMP SERVO MOTOR	TATA spare parts
281883404910	WIRING HARNESS	TATA spare parts
281883404911	PRESSURE SWITCH	TATA spare parts
281883404912	WIRING HARNESS - ONLY AC	TATA spare parts
281883404914	WIRING HARNESS - ONLY BLOWER	TATA spare parts
281883404915	THERMO-AMPLIFIER (ONLY AC)	TATA spare parts
281883404916	THERMISTER	TATA spare parts
281883404917	"ACTUATOR,HEATER & CONTROL-ELEC"	TATA spare parts
281883404919	BLOWER MOTOR ASSY	TATA spare parts
281883404921	WIRING HARNESS ASSY (ONLY AC)	TATA spare parts
281883404922	RESISTOR BLOWER	TATA spare parts
281883404923	PRESSURE SWITCH	TATA spare parts
281883404924	THERMISTER & THERMO-AMPLIFIER	TATA spare parts
281883406001	F/R SERVO MOTOR LEVER 1	TATA spare parts
281883406002	F/R SERVO MOTOR LEVER 2	TATA spare parts
281883406003	F/R SERVO MOTOR LEVER 3	TATA spare parts
281883406004	TEMP SERVO LEVER 1	TATA spare parts
281883406005	TEMP SERVO LEVER 2	TATA spare parts
281883406006	MODE SERVO LEVER 1	TATA spare parts
281883406007	MODE SERVO LEVER 2	TATA spare parts
281883406008	MODE SERVO LEVER 3	TATA spare parts
281883406009	MODE SERVO LEVER 4	TATA spare parts
281883406010	MODE SERVO LEVER 5	TATA spare parts
281883406011	FRESH AIR KINEMATIC LINK 1	TATA spare parts
281883406012	FRESH AIR KINEMATIC LINK 2	TATA spare parts
281883406013	FRESH AIR KINEMATIC LINK 3	TATA spare parts
281883406014	MODE KINEMATIC LINK 1	TATA spare parts
281883406015	MODE KINEMATIC LINK 2	TATA spare parts

281883406016	MODE KINEMATIC LINK 3	TATA spare parts
281883406017	MODE KINEMATIC LINK 4	TATA spare parts
281883406018	PIVOT PIN MODE	TATA spare parts
281883406019	MODE CAM	TATA spare parts
281883406021	HEATER KINEMATIC LINK 2	TATA spare parts
281883406022	HEATER KINEMATIC LINK 3	TATA spare parts
281883406025	SCREW LOCK KINEMATICS	TATA spare parts
281883406026	DAMPER FACE MODE	TATA spare parts
281883406027	DAMPER S/ASSY- FOOT	TATA spare parts
281883406028	DAMPER HEATER UPPER	TATA spare parts
281883406029	DAMPER HEATER LOWER	TATA spare parts
281883406030	DAMPER FAD	TATA spare parts
281883406031	MODE KINEMATIC LINK 5	TATA spare parts
281883406305	BLOWER INLET DUCT	TATA spare parts
281883406310	LEG DUCT-LH	TATA spare parts
281883406311	LEG DUCT-RH	TATA spare parts
281883406313	DRAIN HOSE - FRONT AC	TATA spare parts
281883406317	AIR INTAKE CASING. DUMMY	TATA spare parts
281883406318	ASSY BLOWER CASING DUMMY-VENTILATION SYS	TATA spare parts
281883406319	ASSY BLOWER CASING DUMMY-THAILAND VERSIO	TATA spare parts
281883406320	ASSY HEATER UNIT	TATA spare parts
281883406324	BLOCK FOR AIR INTAKE CUT OUT HVAC	TATA spare parts
281883406328	BLOWER UPPER CASING - FRONT HVAC	TATA spare parts
281883406329	BLOWER LOWER CASING - FRONT HVAC	TATA spare parts
281883406332	CASING FRONT HVAC LHS	TATA spare parts
281883406333	"CASING FRONT HVAC,RHS"	TATA spare parts
281883406334	FAD BRACKET FRONT HVAC	TATA spare parts
281883406335	"FAD,FRONT HVAC UPPER"	TATA spare parts
281883406336	"FAD,FRONT HVAC LOWER"	TATA spare parts
281883406337	FRONT CENTER DUCT FRONT HVAC	TATA spare parts
281883406338	REAR CENTER DUCT FRONT HVAC	TATA spare parts
281883406339	MOUNTING BRACKET WITH INSERT	TATA spare parts
281883406340	BRACKET FRONT HVAC MTG	TATA spare parts
281883406343	FOOT DUCT LHS - FRONT HVAC	TATA spare parts
281883406344	FOOT DUCT RHS - FRONT HVAC	TATA spare parts
281883406345	FAD FILTER FRONT HVAC	TATA spare parts
281883406346	EVAPORATOR COVER - FRONT HVAC	TATA spare parts
281883406347	HEATER UNIT CASING - RH	TATA spare parts
281883406348	HEATER UNIT CASING - LH	TATA spare parts
281883406350	NEW BLOWER INLET DUCT - FRONT	TATA spare parts
281883406351	NEW BLOWER INLET DUCT - UPPER	TATA spare parts
281883406352	NEW BLOWER INLET DUCT - LOWER	TATA spare parts
281883406354	HEATER CASING - RH CASING FOR ONLY AC &	TATA spare parts
281883406357	DRAIN HOSE ASSY WITH GROMMET	TATA spare parts
281883406358	COVER HEATER CUT OUT	TATA spare parts
281883406359	BELL MOUTH	TATA spare parts
281883406360	DRAIN HOSE WITH GROMMET	TATA spare parts



281883406801	GROMMET-HEATER PIPE AND FRONT FLOOR INT	TATA spare parts
281883406802	GROMMET TXV - AC PIPES AND FRONT INNE PA	TATA spare parts
281883406915	PIPE TXV	TATA spare parts
281883407503	GROMMET TANK TUBE CUTOUT	TATA spare parts
281883407507	GROMMET HEATER PIPE	TATA spare parts
281883407703	PACKING	TATA spare parts
281883407704	PACKING	TATA spare parts
281883409901	TXV - REAR AC	TATA spare parts
281883409904	FOAM ASSY WITH WIRE MESH	TATA spare parts
281883450101	CONDENSER ASSY	TATA spare parts
281883450102	CONDENSER ASSY	TATA spare parts
281883500101	HEATER CORE ASSY	TATA spare parts
281883500103	HEATER CORE ASSY FRONT-BS IV	TATA spare parts
281883550101	AC COMPRESSOR-SUPER ACE	TATA spare parts
281883550102	COMPRESSOR ASSY W/MAG. CLUTCH	TATA spare parts
281883550103	COMPRESSOR ASSEMBLY BS6	TATA spare parts
281883554301	BOLT WASHER HEAD	TATA spare parts
281883558501	SNAP RING	TATA spare parts
281883558502	SNAP RING	TATA spare parts
281883559201	WASHER PLATE SK(T-0.1)	TATA spare parts
281883559202	WASHER PLATE SK (T-0.3)	TATA spare parts
281883559203	WASHER PLATE SK (T-0.5)	TATA spare parts
281883559204	SCREW WASHER	TATA spare parts
281883559902	CLUTCH ASSY	TATA spare parts
281883600216	HOSE SUCTION ASSY	TATA spare parts
281883600217	HOSE DISCHARGE ASSY	TATA spare parts
281883600218	SUCTION TUBE ASSY (SUCTION)	TATA spare parts
281883600219	TUBE DISCHARGE ASSY	TATA spare parts
281883600220	TUBE & ACC. ASSY	TATA spare parts
281883600221	TUBE DISCHARGE ASSY	TATA spare parts
281883600222	HOSE SUCTION ASSY	TATA spare parts
281883600223	HOSE DISCHARGE ASSY	TATA spare parts
281883600224	ASSY INLET OUTLET PIPE-VENTURE	TATA spare parts
281883600225	LIQUID PIPE ASSY -F	TATA spare parts
281883600226	LIQUID PIPE ASSY -D	TATA spare parts
281883600227	LIQUID PIPE ASSY -C	TATA spare parts
281883600228	LIQUID PIPE ASSY -B	TATA spare parts
281883600229	DISCHARGE PIPE ASSY	TATA spare parts
281883600235	SUCTION PIPE ASSY	TATA spare parts
281883606901	ASSY HOSE SUCTION-10P08 COMP	TATA spare parts
281883606902	ASSY HOSE DISCHARGE-10P08 COMP	TATA spare parts
281883606905	SUCTION PIPE ASSY	TATA spare parts
281883606906	DISCHARGE PIPE	TATA spare parts
281883606907	EVAPORATOR PIPE	TATA spare parts
281883707501	GROMMET FOR HEATER PIPES CUTOUT ON FRON	TATA spare parts
281883707502	GROMMET FOR TXV HOLE ON FRONT INNER PANI	TATA spare parts
281883707801	BLOCK FOR AIR INTAKE CUT OUT.	TATA spare parts

281883750101	BRACKET ASSY AC PIPE MTG	TATA spare parts
281883753305	BRACKET AC PIPE MTG	TATA spare parts
281883753306	BRACKET AC PIPE MTG	TATA spare parts
281883784202	CLIP	TATA spare parts
281883800101	ASSY ROOF VENT FOR PELICAN	TATA spare parts
281888100107	ASSY SIDE BONNET LH	TATA spare parts
281888100108	ASSY SIDE BONNET RH	TATA spare parts
281888106301	SPLASH GUARD FRONT WHEEL ARCH LH	TATA spare parts
281888106302	SPLASH GUARD FRONT WHEEL ARCH RH	TATA spare parts
281888106303	SPLASH GUARD FRONT WHEEL ARCH LH - REAR	TATA spare parts
281888106304	SPLASH GUARD FRONT WHEEL ARCH RH - REAR	TATA spare parts
28188810Z107	ASSY SIDE BONNET LH -1 TONNER EXPORT	TATA spare parts
28188810Z108	ASSY SIDE BONNET RH 1-TONNER EXPORT	TATA spare parts
281888206301	SPLASH GUARD REAR WHEEL ARCH LH - FRONT	TATA spare parts
281888206302	SPLASH GUARD REAR WHEEL ARCH RH - FRONT	TATA spare parts
281888206303	SPLASH GUARD REAR WHEEL ARCH LH - BACK	TATA spare parts
281888206304	SPLASH GUARD REAR WHEEL ARCH RH - BACK	TATA spare parts
281888500102	ASSY FRONT BUMPER 1 TONNER	TATA spare parts
281888500102BF	ASSY.FRT BUMPER A. WHITE 1TONNER BS1/3/4	TATA spare parts
281888500102FW	ASSY FRONT BUMPER 1 TONNER -CASTLE GREY	TATA spare parts
281888500102FY	ASSY FRONT BUMPER 1 TONNER	TATA spare parts
281888500102FZ	ASSLY FRONT BUMPER	TATA spare parts
281888500102GC	ASSLY FRONT BUMPER (1 TONNER)	TATA spare parts
281888500102GM	ASSLY FRONT BUMPER (1 TONNER)	TATA spare parts
281888500102HF	ASSLY FRONT BUMPER (1 TONNER)	TATA spare parts
281888500102IC	ASSLY FRONT BUMPER (1 TONNER)	TATA spare parts
281888500102ID	TWLIGHT_GREY-ASSLY FRONT BUMPER - BASE	TATA spare parts
281888500104	ASSLY FRONT BUMPER	TATA spare parts
281888500104A3	ASSY. FRONT BUMPER (PELICAN) BS3	TATA spare parts
281888500104BF	ASSLY FRONT BUMPER	TATA spare parts
281888500105	ASSLY FRONT BUMPER - LUX	TATA spare parts
281888500105BF	ASLY FRONT BUMPER (PELICAN) - LUX ARTICT	TATA spare parts
281888500105FW	ASSLY FRONT BUMPER (PELICAN)	TATA spare parts
281888500105FY	ASSLY FRONT BUMPER (PELICAN)	TATA spare parts
281888500105FZ	ASSLY FRONT BUMPER (PELICAN)	TATA spare parts
281888500105GM	FRONT BUMPER SARDINIA_RED	TATA spare parts
281888500105HF	ASSLY FRONT BUMPER (PELICAN) - LUX	TATA spare parts
281888500106	ASSY. FRONT BUMPER SUPER ACE E3	TATA spare parts
281888500106BF	ARCTIC_WHITE-ASSLY FRONT BUMPER	TATA spare parts
281888500106FW	ASSY FRONT BUMPER	TATA spare parts
281888500112	FRONT BUMPER ASSY	TATA spare parts
281888500112BF	FRONT BUMPER ASSY_ARCTIC_WHITE	TATA spare parts
281888500112HF	METEOR_SILVR-FRONT BUMPER ASSY	TATA spare parts
281888500112IC	FRONT BUMPER ASSY_BLAZING_RED	TATA spare parts
281888500112ID	TWLIGHT_GREY-FRONT BUMPER ASSY	TATA spare parts
281888500116BF	FRONT BUMPER ASSY WITH GRILL	TATA spare parts
281888506303	BUMPER SIDE MTG BKT LH	TATA spare parts

281888506304	BUMPER SIDE MTG BKT RH	TATA spare parts
281888506305	TOW HOOK COVER	TATA spare parts
281888506305BF	TOW HOOK COVER_ARCTIC_WHITE	TATA spare parts
281888506305IC	TOW HOOK COVER_BLAZING_RED	TATA spare parts
281888506306	FOG LAMP MTG BKT LH	TATA spare parts
281888506307	FOG LAMP MTG BKT RH	TATA spare parts
281888506309	T EMBLEM FRONT BUMPER	TATA spare parts
281888506310BF	FOG LAMP COVER LH_ARCTIC_WHITE	TATA spare parts
281888506310IC	FOG LAMP COVER LH_BLAZING_RED	TATA spare parts
281888506311BF	FOG LAMP COVER RH_ARCTIC_WHITE	TATA spare parts
281888506311IC	FOG LAMP COVER RH_BLAZING_RED	TATA spare parts
281888506312	ADAPTOR FOR FRONT NUMBER PLATE	TATA spare parts
281888506313	FRONT STUFFER LH	TATA spare parts
281888506314	FRONT STUFFER RH	TATA spare parts
281888506315	REFLECTIVE TAPE WHITE 1 TONNER	TATA spare parts
281888506317	ADAPTOR FOR FRONT NUMBER PLATE - THAILAN	TATA spare parts
281888506318	FRONT BUMPER MOUNTING BRACKET-LH	TATA spare parts
281888506319	FRONT BUMPER MOUNTING BRACKET_RH	TATA spare parts
281888506330ID	GRILL FRONT BUMPER	TATA spare parts
281888600102	ASSY REAR BUMPER MBUS	TATA spare parts
281888600102A3	ASSY REAR BUMPER MBUS	TATA spare parts
281888600103	ASSY REAR BUMPER MBUS (WITH ULTRASONIC S	TATA spare parts
281888600103BF	ASSY REAR BUMPER MBUS (WITH ULTRASONIC S	TATA spare parts
281888600103FW	ASSY REAR BUMPER MBUS (WITH ULTRASONIC S	TATA spare parts
281888600103FY	ASSY REAR BUMPER MBUS (WITH ULTRASONIC S	TATA spare parts
281888600103FZ	ASSY REAR BUMPER MBUS (WITH ULTRASONIC S	TATA spare parts
281888600103HF	ASSY REAR BUMPER MBUS (WITH ULTRASONIC	TATA spare parts
281888700101	OFFER DWG ASSY FRONT ENGINE COVER	TATA spare parts
281888700102A2	ASSY ENGINE COVER REAR-LUX VERSION	TATA spare parts
281888700102AY	ASSY ENGINE COVER REAR-LUX VERSION	TATA spare parts
281888700105	ASSY CAP & WASHER FOR M6 SCREW	TATA spare parts
281888700106	ASSLY HINGE FOR OIL FILLING CAP	TATA spare parts
281888700108	ASSLY LATCH FOR OIL FILLING CAP	TATA spare parts
281888700109	ASSLY ENGINE COVER FRONT	TATA spare parts
281888700109A2	ASSLY ENGINE COVER FRONT	TATA spare parts
281888700109AY	ASSLY ENGINE COVER FRONT	TATA spare parts
281888700114	ASSY ENGINE SHIELD - LHD	TATA spare parts
281888706302	ENGINE COVER REAR-LUX VERSION-PELICAN	TATA spare parts
281888706304	INSULATION ENGINE COVER FRONT	TATA spare parts
281888706305	INSULATION ENGINE COVER REAR	TATA spare parts
281888706306	MATT FOR ENGINE COVER FRONT	TATA spare parts
281888706306A2	MATT FOR ENGINE COVER FRONT	TATA spare parts
281888706306AY	MATT FOR ENGINE COVER FRONT	TATA spare parts
281888706307	INSULATION OIL FILLING CAP	TATA spare parts
281888706312	HEAT SHIELD (LOAD BODY)	TATA spare parts
281888706314	ENGINE COVER REAR-HARDPAD VERSION-PELICA	TATA spare parts
281888706317	ENGINE COVER FRONT	TATA spare parts

281888706322	HEAT SHIELD - ENGINE COVER FRONT	TATA spare parts
281888706323	HEAT SHIELD - OIL FILLING CAP	TATA spare parts
281888706324	HEAT SHIELD - ENGINE COVER REAR	TATA spare parts
281888706325	INSULATION PANEL ENGINE SHIELD - LHD	TATA spare parts
281888706332	FRONT ENGINE - PVC COVER	TATA spare parts
281888707706	SEAL OIL FILLING CUT OUT	TATA spare parts
281888707707	STOPPER	TATA spare parts
281888800101	ASSY LEAF-SCREEN	TATA spare parts
281888800102BF	ASSY FRONT PANEL - PELICAN ARCTIC_WHITE	TATA spare parts
281888800102FD	ASSY FRONT PANEL - GOLDEN YELLOW	TATA spare parts
281888800102FW	ASSY FRONT PANEL - PELICAM	TATA spare parts
281888800102FY	ASSY FRONT PANEL	TATA spare parts
281888800102FZ	ASSY FRONT PANEL - PELICAN CHAMPGN_GOLD	TATA spare parts
281888800102GC	CASTLE GREY - ASSY FRONT PANEL	TATA spare parts
281888800102GM	FRONT PANEL SARDINIA_RED	TATA spare parts
281888800102HF	METEOR_SILVR-ASSY FRONT PANEL - PELICAM	TATA spare parts
281888800106	FRONT PANEL ASSY OUTER	TATA spare parts
281888800106K5	BRIGHT PLUM-FRONT PANEL ASSY OUTER	TATA spare parts
281888800107	FLAP ASSY WITH HINGE	TATA spare parts
281888800109BF	ARCTIC_WHITE-FRONT PANEL WITH GARNISH AS	TATA spare parts
281888800110	LATCH ASSY FRONT PANEL	TATA spare parts
281888804301	OMEGA CLIP	TATA spare parts
281888806301	FRONT PANEL OUTER - SUPER ACE	TATA spare parts
281888806301BF	FRONT PANEL OUTER SUPER ACE BS1/3/4	TATA spare parts
281888806301BU	FRONT PANEL OUTER ¿JET BLACK	TATA spare parts
281888806301FW	FRONT PANEL OUTER - SUPER ACE	TATA spare parts
281888806301FY	FRONT PANEL OUTER - SUPER ACE	TATA spare parts
281888806301FZ	FRONT PANEL OUTER - SUPER ACE	TATA spare parts
281888806301GC	FRONT PANEL OUTER - SUPER AC	TATA spare parts
281888806301GM	FRONT PANEL OUTER - SUPER ACE	TATA spare parts
281888806301HF	FRONT PANEL OUTER - SUPER ACE	TATA spare parts
281888806301IC	FRONT PANEL OUTER - SUPER ACE	TATA spare parts
281888806301ID	FRONT PANEL OUTER - SUPER ACE	TATA spare parts
281888806302	LEAF-SCREEN TRIM	TATA spare parts
281888806303	PLENUM SEAL	TATA spare parts
281888806304	GARNISH - FRONT PANEL	TATA spare parts
281888806305	FRONT PANEL OUTER	TATA spare parts
281888806306	RUBBER GROMMET FOR LEAF TRIM WIPER	TATA spare parts
281888806312	GARNISH FRONT	TATA spare parts
281891000102	ASSEMBLY DRIVER SEAT-LOW END_LHD-SS	TATA spare parts
281891000102ZY	CLRPRT_ASY_1-ASSEMBLY DRIVER SEAT-LOW EN	TATA spare parts
281891000104	ASSY DRIVER SEAT-LUX VERSION	TATA spare parts
281891000105	ASSY DRIVER SEAT-BASE VERSION	TATA spare parts
281891000106	ASSY DRIVER SEAT- MB-LUX VERSION	TATA spare parts
281891000107	ASSY DRIVER SEAT-MB-BASE VERSION	TATA spare parts
281891000108	ASSY DRIVER SEAT¿ VENTURE -MID VERSION	TATA spare parts
281891000109	ASSY DRIVER SEAT	TATA spare parts

281891000111	ASSY FRT SEAT COMP LH_SUPER ACE	TATA spare parts
281891000111ZZ	ASSY FRT SEAT COMP LH SUPER ACE	TATA spare parts
281891000116	DRIVER SEAT ASSY WITH HEADREST	TATA spare parts
281891000116ZZ	ASSY-DRIVER SEAT ASSY WITH HEADREST	TATA spare parts
281891000119	ASSY FRONT SEAT RH - NON SBA - HIGH END	TATA spare parts
281891000120	ASSY FRONT SEAT COMP RH SUPER ACE LOW EN	TATA spare parts
281891000121	ASSY FRONT SEAT RH NON SBA	TATA spare parts
281891000123	ASSY FRONT SEAT RH NON SBA-VENTURE-GX	TATA spare parts
281891000124	ASSY FRONT SEAT RH NON SBA	TATA spare parts
281891000125	ASSY FRONT SEAT RH-NON SBA-VENTURE-CX	TATA spare parts
281891000133	ASSY DRIVER SEAT HIGH END	TATA spare parts
281891000133ZY	CLRPRT_ASY_1-ASSY DRIVER SEAT HIGH END G	TATA spare parts
281891000133ZZ	ASSY DRIVER SEAT HIGH END GULF_SS	TATA spare parts
281891006301	CARPET SKIRT RH	TATA spare parts
281891006302	THERMAL INSULATION RH	TATA spare parts
281891006303	SEAT PAN INSULATION LH-LHD	TATA spare parts
281891006304	ASSY SUPER ACE RHD FHR COMP HIGH END	TATA spare parts
281891006305	ASSY SUPER ACE LHD FHR COMP HIGH END	TATA spare parts
281891006307	ASSEMBLY FHR COMP-VENTURE HIGH END	TATA spare parts
281891006309	SEAT SKIRT RH	TATA spare parts
281891006310	ASSY FHR COMP THAILAND	TATA spare parts
281891007701	BEADING	TATA spare parts
281891007702	ACE 1TON RECLINER PLASTIC COVER ASSEMBLY	TATA spare parts
281891007702BB	ACE-1TON RECLINER PLASTIC COVER ASSEMBLY	TATA spare parts
281891007703	BEADING FOR PAN	TATA spare parts
281891208201	ASSY FRONT SEAT TRACK RH	TATA spare parts
281891208202	PAN ASSY RH	TATA spare parts
281891306301	RECLINER COVER ASSY RH	TATA spare parts
281891306302	RECLINER KNOB RH SIDE	TATA spare parts
281891500101	ASSY FRONT SEAT BELT KIT	TATA spare parts
281891500104	ASSY FRONT SEAT BELT KIT RH COMPLETE AUT	TATA spare parts
281891500108BB	ASSY FRONT SEAT BELT KIT COMPLETE AUTOLI	TATA spare parts
281891500115	ASSLY FRONT SEAT BELT COMPLETE KIT	TATA spare parts
281891500133	FRONT CABIN SEAT BELTS W/O SWITCH COMPLE	TATA spare parts
281891500133A2	FRONT SEAT BELTS KIT W/O SWITCH DARK GRA	TATA spare parts
281891500133A3	EBONY_1-FRONT SEAT BELTS W/O SWITCH COMP	TATA spare parts
281891508002	SPECIAL SCREW M6X20	TATA spare parts
281891508003	INSERT MOULDED PLASTIC CAP	TATA spare parts
281891508004	DOUBLE ENDED STUD M6	TATA spare parts
281891704201	ASSY FRONT SEAT TOGGLE CLAMP	TATA spare parts
281892500111	ASSY SECOND ROW SEAT BELT KIT COMPLETE R	TATA spare parts
281892500111BB	ASSY SECOND ROW SEAT BELT KIT COMPLETE R	TATA spare parts
281892500116	ASSY THIRD ROW SEAT BELT KIT COMPLETE RH	TATA spare parts
281892500116BB	ASSY THIRD ROW SEAT BELT KIT COMPLETE RH	TATA spare parts
281892500119	ASSY SECOND ROW SEAT BELT KIT (6+1 LAYOU	TATA spare parts
281892500130	ASSY SECOND ROW SEAT BELT KIT COMPLETE R	TATA spare parts
281892700102	SECOND ROW SEAT ASSEMBLY 66% -LUX	TATA spare parts

281892700103	ASSY THIRD ROW SEAT-LUX	TATA spare parts
281892700106	SECOND ROW SEAT ASSEMBLY 34% -LUX	TATA spare parts
281892700111	ASSY SECOND ROW SEAT 900MM WIDE-LUX	TATA spare parts
281892700113	SECOND ROW SEAT ASSEMBLY 66% -LOW END	TATA spare parts
281892700114	ASSY THIRD ROW SEAT-LOW END	TATA spare parts
281892700115	SECOND ROW SEAT ASSEMBLY 34% -LOW	TATA spare parts
281892700116	ASSY SECOND ROW 7 SEATER-841 MM WIDE-LOW	TATA spare parts
281892700121	ASSY SECOND ROW CAPTAIN SEAT-RH	TATA spare parts
281892700122	ASSY SECOND ROW CAPTAIN SEAT LH	TATA spare parts
281892700124	ASSY SECOND ROW 66% SEAT VENTURE MID VER	TATA spare parts
281892700125	ASSY SECOND ROW TUMBLE SEAT VENTURE MID	TATA spare parts
281892700126	ASSY THIRD ROW SEAT VENTURE MID VERSION	TATA spare parts
281892700127	ASSY SECOND ROW SEAT 900MM WIDE VENTURE	TATA spare parts
281892700149	ASSY DOCTOR SEAT	TATA spare parts
281892700150	ASSY ATTENDANT SEAT	TATA spare parts
281892700151	STRETCHER ASSY	TATA spare parts
281892707701	FOLDING MECHANISM PLASTIC COVER RH	TATA spare parts
281892707702	THIRD ROW PLASTIC COVER IB RH	TATA spare parts
281892707703	FOLDING MECHANISM PLASTIC COVER LH	TATA spare parts
281892707704	THIRD ROW PLASTIC COVER IB LH	TATA spare parts
281892707709	SECOND ROW 34% PLASTIC COVER - OB	TATA spare parts
281892707710	SECOND ROW 34% PLASTIC COVER - OB	TATA spare parts
281892707710BB	SECOND ROW 34% PLASTIC COVER	TATA spare parts
281892707712	SECOND ROW 34% PLASTIC COVER - IB	TATA spare parts
281892707712BB	SECOND ROW 34% PLASTIC COVER	TATA spare parts
281892707713	SECOND ROW 34% REAR LEG PLASTIC COVER	TATA spare parts
281892707714	SECOND ROW 34% FRONT LEG PLASTIC COVER	TATA spare parts
281892707715	SECOND ROW 34% FRONT LEG HINGE BKT COVER	TATA spare parts
281892707718	RELEASE LEVER ASSEMBLY	TATA spare parts
281892707719	CABLE SEAT CAM ACTUATOR(7+D) LAYOUT	TATA spare parts
281892707720	CABLE FOR REAR LEG FOLDING	TATA spare parts
281892707721	ASSY TUMBLE SEAT LATCH	TATA spare parts
281892707722	CABLE SEAT CAM ACTUATOR	TATA spare parts
281892707724	ASSEMBLY TUMBLE SEAT LATCH	TATA spare parts
281894000102	ASSY CO-DRIVER SEAT-LUX VERSION	TATA spare parts
281894000103	ASSY CO-DRIVER SEAT-BASE VERSION	TATA spare parts
281894000104	ASSY CO-DRIVER SEAT-MB-LUX VERSION	TATA spare parts
281894000105	ASSY CO-DRIVER SEAT-MB-BASE VERSION	TATA spare parts
281894000107	ASSY CO-DRIVER SEAT VENTURE- MID VERSION	TATA spare parts
281894000108	ASSY CO-DRIVER SEAT	TATA spare parts
281894000110	ASSY FRONT SEAT COMP RH	TATA spare parts
281894000110ZZ	ASSY FRT SEAT COMP RH SUPER ACE	TATA spare parts
281894000112	CO-DRIVER SEAT ASSY WITH HEADREST	TATA spare parts
281894000112ZZ	ASSY-CO-DRIVER SEAT ASSY WITH HEADREST	TATA spare parts
281894000113	ASSY CO-DRIVER SEAT LOW END _LHD-SS	TATA spare parts
281894000113ZY	CLRPRT _ASY_1-ASSY CO-DRIVER SEAT LOW END	TATA spare parts
281894000116	ASSY FRONT SEAT LH - NON SBA - HIGH END	TATA spare parts

281894000117	ASSY FRONT SEAT COMP LH SUPER ACE LOW EN	TATA spare parts
281894000120	ASSY FRONT SEAT LH NON SBA	TATA spare parts
281894000122	ASSLY FRONT SEAT LH-NON SBA-VENTURE-GX	TATA spare parts
281894000123	ASSY FRONT SEAT LH NON SBA	TATA spare parts
281894000124	ASSY FRONT SEAT LH NON SBA	TATA spare parts
281894000133	ASSY CO-DRIVER SEAT	TATA spare parts
281894000133ZY	CLRPRT_ ASY_1-ASSY CO-DRIVER SEAT HIGHEN	TATA spare parts
281894000133ZZ	ASSY CO-DRIVER SEAT HIGHEND-GULF SS	TATA spare parts
281894006301	CARPET SKIRT LH	TATA spare parts
281894006302	THERMAL INSULATION LH	TATA spare parts
281894006303	SEAT PAN INSULATION RH-LHD	TATA spare parts
281894006307	SEAT SKIRT LH NEW FOR NON SBA SEATS	TATA spare parts
281894007701	ACE 1TONPLASTIC RECLINER COVER	TATA spare parts
281894208201	ASSY FRONT SEAT TRACK LH	TATA spare parts
281894208202	PAN ASSEMBLY LH	TATA spare parts
281894306301	RECLINER KNOB LH	TATA spare parts
281894306301A3	RECLINER LEVER LH	TATA spare parts
281894306302	RECLINER COVER ASSEMBLY LH	TATA spare parts
281899000101	ASSY SPARE WHEEL KNOB	TATA spare parts
281899005601	KNOB M8	TATA spare parts
281899005602	M8 TRIPLE START KNOB	TATA spare parts
281899500102	RETRO KIT FOR C CLIP AND SLEEVE	TATA spare parts
281899504301	SHEET METAL C CLIP	TATA spare parts
281899506302	HARDPAD CLIP	TATA spare parts
281926900102	ASSY. OILCOOLER BS2/3	TATA spare parts
281926900104	ASSEMBLY OIL COOLER (NOVUS)	TATA spare parts
281926907101	BRACKET RH (OILCOOLER ASSEMBLY)	TATA spare parts
281926907102	BRACKET LH (OIL COOLER ASSLY.)	TATA spare parts
281930100106	BRACKET ASSY ACCELEARTOR PEDAL MTG	TATA spare parts
281941120102	LONG FORK SUB ASSY.(MAIN SHAFT)	TATA spare parts
281941120104	ASSY. UNIVERSAL JOINT (M/SHAFT)BS2/3/4/6	TATA spare parts
281941120108	UNIVERSAL JOINT BS1/2/3/4	TATA spare parts
281941120108DF	UJ CROSS 48X134.2-LPT1613/1618/2518/3118	TATA spare parts
281941125101	FLANGE YOKE(MAIN SHAFT)	TATA spare parts
281941125102	FLANGE YOKE (INTER AXLE)	TATA spare parts
281946600101	POWER STG.PUMP(VANE PUMP) ASSY	TATA spare parts
281949103303	BRACKET(MAGNETIC VALVE MTG-EX BRAK)	TATA spare parts
281949200105	ASSY.BRACKET(MAGNETIC VALVE MTG-EX BRAK)	TATA spare parts
282015200102	KIT-H.T. CABLE	TATA spare parts
282015200107	KIT-H.T. CABLE	TATA spare parts
282015400101	ALTERNATOR 75A W/VP W/AC NOZ.MODIF	TATA spare parts
282015409975	SPARK PLUG-FR6DC4	TATA spare parts
282032100114	ASSY FRONT STRUT COMP LH	TATA spare parts
282032100115	ASSY FRONT STRUT COMP RH	TATA spare parts
282042806802	3-WAY UNION	TATA spare parts
282044807701	RUBBER HOSE (SUCTION LINE)	TATA spare parts
282047100101	ASSY. SCREW CAP-VENTED BS1/2/3/4	TATA spare parts

282047607705	CLAMP (PIPE 4.75X4.75)	TATA spare parts
282054209901	HORN LOW TONE W/O RIS CAP	TATA spare parts
282054209904	RELAY-40A C/O CONTACT	TATA spare parts
282054209930	RELAY WITH PARALLEL DIODE	TATA spare parts
282054219917	GLOW PLUG I UNIT	TATA spare parts
282054509907	HAND BRAKE SWITCH WITH PIG TAIL	TATA spare parts
282054700105	ASSY BLOWER RESISTOR(4 SPEED)	TATA spare parts
282054700111	BLOWER RESISTOR 4 STAGE	TATA spare parts
282054700123	ASSY BLOWER MOTOR(160W)	TATA spare parts
282054700132	ASSY BLOWER SWITCH(IMPR) M/S	TATA spare parts
282054709902	THERMO EVAP SWITCH(R134a)	TATA spare parts
282100000103	RETRO-KIT FOR LPK909/27WB BS-II TIPPER	TATA spare parts
28210000015R40	ASSEMBLY BODY FITTED BS6	TATA spare parts
282115109902	CE BRACKET ASSY BS6	TATA spare parts
282115109903	BRUSH GEAR ASSY BS6	TATA spare parts
282115219901	CATCON TEMP SENSOR CNG BS4	TATA spare parts
282115219902	GAS TEMPERATURE SENSOR	TATA spare parts
282115219903	PRESSURE TRANSDUCER	TATA spare parts
282115608202	BRACKET FOR CIGAR COIL BUNDLE SUPPORT	TATA spare parts
282115608204	BRACKET-2 FOR W/H SUPPORT ON INTAKE MANI	TATA spare parts
282115608205	BRACKET FOR CRANK SENSOR BRANCH SUPPORT	TATA spare parts
282115608206	BRACKET LAMBDA SENSOR B/SUPPORT 497 CNG	TATA spare parts
282115608207	BRACKET FOR WH SUPPORT AT GSL LOCATION	TATA spare parts
282116100102	CONTAINER(ECU 497TC BSIII) LPT912EX	TATA spare parts
282116100107	CONTAINER ECU 497TCIC 6.9/4.125 BS4	TATA spare parts
282116100108	CONTAINER(ECU497TCICBSIII-8.02/3.44)	TATA spare parts
282116100112	CONTAINER(ECU497 CNG)	TATA spare parts
282116100114	CONTAINER(ECU497 CNG)	TATA spare parts
282116100116	CONTAINER (ECU 497 TCIC BS-III -8.02/3.4	TATA spare parts
282116100118	CONTAINER(ECU-497 NA CNG BS-IV)	TATA spare parts
282116100120	CONTAINER(497TCIC BS3-G40-8.02_3.44)	TATA spare parts
282116100124	CONTAINER (ECU 697 CR BS-IV OBD II)	TATA spare parts
282116100127	CONTAINER(LP912/LPT909)	TATA spare parts
282116100132	CONTAINER(ECU497TCIC BS4-6.9/4.857 OBDII	TATA spare parts
282116102001	ECU BS6	TATA spare parts
282116204901	ECU BS6	TATA spare parts
282116204902	ECU	TATA spare parts
282124100103	BRACKET ASSY ENGINE MTG BOTTOM LH BS6	TATA spare parts
282124100104	BRACKET ASSY ENGINE MTG BOTTOM RH BS6	TATA spare parts
282124100108	BRACKET ASSY ENGINE MTG FRONT-LH BS6-PH2	TATA spare parts
282124100109	BRACKET ASSY ENGINE MTG FRONT-RH BS6-PH2	TATA spare parts
282124200103	ASSY ENGINE MTG BKT RH(BOTTOM)	TATA spare parts
282124200104	ASSY ENGINE MTG BKT LH(BOTTOM)	TATA spare parts
282124200105	ASSY ENGINE MTG BKT TOP(RH)	TATA spare parts
282124200106	BRACKET ASSY ENGINE MTG BOTTOM-LH BS6	TATA spare parts
282124200107	ASSY. RUBBER SUPPORT	TATA spare parts
282124200111	BRACKET ASSY ENGINE MTG BOTTOM-RH BS6	TATA spare parts



282129100101	ASSY. CLUTCH BOOSTER 90 DIA. BS1/2/3/4	TATA spare parts
282129100102	ASSY. TUBE	TATA spare parts
282129200106	ASSY. METAL PIPE(DDU TO 'T' CONNECTOR)	TATA spare parts
282129200107	ASSY. METAL PIPE('T' CONNECTOR TO HOSE)	TATA spare parts
282129200108	ASSY. METAL PIPE('T'CONNECTOR-PURGE TANK)	TATA spare parts
282129200110	ASSY. BRACKET (CLUTCH BOOSTER MOUNTING)	TATA spare parts
282129208208	CLUTCH RELEASE LEVER	TATA spare parts
282129300101	ASSY. PUSH ROD	TATA spare parts
282129300106	ASSY. PUSH ROD.	TATA spare parts
282129300112	NYLON PIPE ASSY BS6	TATA spare parts
282129300114	BUNDY TUBE ASSY MIDDLE BS6	TATA spare parts
282129300115	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
282129300119	HOSE ASSY BOOSTER TO CHASSIS BS6	TATA spare parts
282129300124	BUNDY TUBE ASSY CMC TO FIREWALL BS6	TATA spare parts
282129300126	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
282129300131	PIPE ASSY CMC BS6-PH2	TATA spare parts
282129300132	PIPE ASSY INT JOINT TO BOOSTER HYD BS6-P	TATA spare parts
282129300133	NYLON PIPE ASSY T-CONN TO AIR TANK BS6-P	TATA spare parts
282129300136	BUNDY TUBE ASSY CMC TO FIREWALL BS6-PH2	TATA spare parts
282129300137	BUNDY TUBE ASSY LONG MEMBER BS6-PH2	TATA spare parts
282129500101	BRACKET ASSY BOOSTER MTG BS6-PH2	TATA spare parts
282129990101	MINOR KIT-CLUTCH BOOSTER ASSY(90 DIA)	TATA spare parts
282129990102	MAJOR KIT-CLUTCH BOOSTER ASSY(90 DIA)	TATA spare parts
282130100101	ASSY ACCELERATOR CABLE 2073MM	TATA spare parts
282130100102	ASSY. BRACKET (ACCL. PEDAL MTG.)	TATA spare parts
282130108201	BRACKET(ACCL PEDAL MODULE MTG)	TATA spare parts
282130108205	ACCL. PEDAL MTG. BRACKET	TATA spare parts
282131000101	ASSY FRAME 38 WB	TATA spare parts
282131000102	ASSY.FRAME 34WB	TATA spare parts
282131000105	ASSY.FRAME (34 WB) LPT909 W/O CLEATS	TATA spare parts
282131000107	ASSY FRAME LPT 912/38WB BHARAT STAGE-III	TATA spare parts
282131000108	ASSY FRAME LPT 912/34WB BHARAT STAGE-III	TATA spare parts
282131000109	ASSY FRAME LPT 912/34 BS-III W/O CLEATS	TATA spare parts
282131000110	FRAME ASSY WITH FITMENT	TATA spare parts
282131000115	ASSY.FRAME LPT909EX/38WB W/O CLEATS	TATA spare parts
282131000116	ASSY. FRAME LPT912EX/38WB W/O CLEATS	TATA spare parts
282131000118	FRAME ASSY WITH FITMENT	TATA spare parts
282131000119	ASSY. FRAME WITH FITMENT BS2/3	TATA spare parts
282131000120	ASSY. FRAME COMPLETE LP 909/49WB BS-II	TATA spare parts
282131000122	ASSY FRAME COMPLETE(LP912/49)	TATA spare parts
282131000126	LP 909 FRAME FOR TMML MARCOPOLO	TATA spare parts
282131000127	ASSY.FRAME COMPLETE.	TATA spare parts
282131000128	ASSY.FRAME 912 LP 49 EX FES BUS PS TMML	TATA spare parts
282131000131	ASSY. FRAME WITH FITMENT BS4	TATA spare parts
282131000134	FRAME ASSY WITH FITMENT BS6	TATA spare parts
282131000135	ASSY FRAME COMPLETE WITH G550 GEAR BOX	TATA spare parts
282131000137	ASSY. FRAME LPT909/34WB BS-IV WITH G550	TATA spare parts

282131000138	ASSY. FRAME	TATA spare parts
282131000139	FRAME ASSY WITH FITMENT	TATA spare parts
282131000140	ASSY FRAME COMPLETE FOR LP909 CNG TMML	TATA spare parts
282131000144	FRAME ASSY WITH FITMENTBS6	TATA spare parts
282131000145	ASSY.FRAME COMPLETE W/O CLEATS	TATA spare parts
282131000149	FRAME ASSY WITH FITMENT	TATA spare parts
282131000151	ASSY FRAME LPT 909 HEX2/38WB BS-III W/O	TATA spare parts
282131000164	FRAME ASSY WITH FITMENT	TATA spare parts
282131000165	ASSY. FRAME WITH FITMENT BS3/4	TATA spare parts
282131000166	FRAME ASSY WITH FITMENT	TATA spare parts
282131000167	FRAME ASSY WITH FITMENT	TATA spare parts
282131000168	FRAME ASSY COMPLETE	TATA spare parts
282131000175	FRAME ASSY WITH FITMENT	TATA spare parts
282131000177	FRAME ASSY WITH FITMENT	TATA spare parts
282131000179	FRAME ASSY WITH FITMENT	TATA spare parts
282131000184	FRAME ASSY WITH FITMENT	TATA spare parts
28213100M10134	FRAME ASSY WITH FITMENTS BS6-PH2	TATA spare parts
28213100M10210	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
28213100M10215	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
282131010103	FRAME ASSY WITH FITMENT BS6	TATA spare parts
282131010106	FRAME ASSY WITH FITMENT	TATA spare parts
282131010108	FRAME ASSY WITH FITMENT BS6	TATA spare parts
282131010110	FRAME ASSY WITH FITMENT BS6	TATA spare parts
282131010113	FRAME ASSY WITH FITMENT BS6	TATA spare parts
282131010114	FRAME ASSY WITH FITMENT BS6	TATA spare parts
282131010123	FRAME ASSY WITH FITMENT BS6	TATA spare parts
282131010133	FRAME ASSY WITH FITMENT BS6	TATA spare parts
282131010135	FRAME ASSY WITH FITMENT BS6	TATA spare parts
282131010138	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
28213101M10140	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
282131200101	ASSY. CROSS MEMBER-RSB FRONT	TATA spare parts
282131200102	ASSY. CROSS MEMBER-REAR SPRING REAR	TATA spare parts
282131200103	ASSY. CROSS MEMBER-REAR SPRING REAR	TATA spare parts
282131200104	ASSY. CROSS MEMBER	TATA spare parts
282131200105	ASSY CROSS MEMBER	TATA spare parts
282131200106	ASSY CENTRE BEARING CROSS MEMBER	TATA spare parts
282131200107	ASSY CENTRE BEARING CM	TATA spare parts
282131200108	ASSY.CROSS MEMBER (CENTER BRG.)	TATA spare parts
282131200109	ASSY.CROSS MEMBER (CENTER BRG.)	TATA spare parts
282131200110	ASSY.CROSS MEMBER (SPARE WHEEL MTG.)	TATA spare parts
282131200121	ASSY. CROSS MEMBER (REAR SPRING REAR)	TATA spare parts
282131200123	ASSY CROSS MEMBER	TATA spare parts
282131200125	ASSY.SUPPORT(CROSS MEMBER)	TATA spare parts
282131200130	ASSY.CENTRE BEARING C.M.	TATA spare parts
282131200131	ASSY.CENTRE BEARING C.M.	TATA spare parts
282131200144	ALLIGATED CROSS MEMBER ASSY BS6	TATA spare parts
282131207105	JOINT GUSSET PLATE	TATA spare parts

282131207112	JOINT GUSSET PLATE - RH	TATA spare parts
282131207113	JOINT GUSSET PLATE - LH	TATA spare parts
282131207114	JOINT GUSSET PLATE - RH	TATA spare parts
282131207115	JOINT GUSSET PLATE - LH	TATA spare parts
282131207120	SUPPORT CROSS MEMBER	TATA spare parts
282131207122	SUPPORT PLATE (4)	TATA spare parts
282131207126	JOINT GUSSET PLATE	TATA spare parts
282131207127	JOINT GUSSET PLATE	TATA spare parts
282131207128	JOINT GUSSET PLATE	TATA spare parts
282131207129	JOINT GUSSET PLATE	TATA spare parts
282131207130	JOINT GUSSET PLATE	TATA spare parts
282131207131	JOINT GUSSET PLATE	TATA spare parts
282131207132	JOINT GUSSET PLATE	TATA spare parts
282131207135	JOINT GUSSET PLATE	TATA spare parts
282131207136	PACKING PLATE	TATA spare parts
282131207137	JOINT GUSSET PLATE - RH	TATA spare parts
282131207138	JOINT GUSSET PLATE - LH	TATA spare parts
282131207141	GUSSET -RH	TATA spare parts
282131207142	GUSSET -LH	TATA spare parts
282131207149	PLATE BS6-PH2	TATA spare parts
282131208201	REINFORCEMENT - RH(FRONT SPG. FRONT BKT)	TATA spare parts
282131208202	REINFORCEMENT - LH(FRONT SPG.FRONT BKT)	TATA spare parts
282131208205	GUSSET	TATA spare parts
282131208207	GUSSET BOTTOM	TATA spare parts
282131208208	GUSSET -BOTTOM-RH(REAR SPRING REAR C.M)	TATA spare parts
282131208209	GUSSET -BOTTOM-LH(REAR SPRING REAR C.M)	TATA spare parts
282131208210	REINFORCEMENT - RH (BOTTOM)	TATA spare parts
282131208211	REINFORCEMENT - LH (BOTTOM)	TATA spare parts
282131208215	REINFORCEMENT -RH (TOP)	TATA spare parts
282131208216	REINFORCEMENT -LH (TOP)	TATA spare parts
282131208217	REINFORCEMENT -RH (BOTTOM)	TATA spare parts
282131208218	REINFORCEMENT -LH (BOTTOM)	TATA spare parts
282131208219	REINFORCEMENT - RH	TATA spare parts
282131208220	REINFORCEMENT - LH	TATA spare parts
282131208221	REINFORCEMENT - RSB FRONT	TATA spare parts
282131208227	REINFORCEMENT RH	TATA spare parts
282131208228	REINFORCEMENT LH	TATA spare parts
282131208237	REINFORCEMENT RH (BOTTOM)	TATA spare parts
282131208238	REINFORCEMENT RH (BOTTOM)	TATA spare parts
282131208246	SPACER (4)	TATA spare parts
282131208276	REINFORCEMENT TOP-RH BS6	TATA spare parts
282131208277	REINFORCEMENT TOP-LH BS6	TATA spare parts
282131208278	REINFORCEMENT BOTTOM RH BS6	TATA spare parts
282131208279	REINFORCEMENT BOTTOM LH BS6	TATA spare parts
282131208283	REINFORCEMENT BS6	TATA spare parts
282131208284	REINFORCEMENT RH BS6	TATA spare parts
282131208285	REINFORCEMENT LH BS6	TATA spare parts

282131208286	REINFORCEMENT RH BS6	TATA spare parts
282131208287	REINFORCEMENT LH BS6	TATA spare parts
282131208298	REINFORCEMENT RH BS6-PH2	TATA spare parts
282131208299	REINFORCEMENT LH BS6-PH2	TATA spare parts
282131240109	TUBE ASSY CROSS MEMBER BS6	TATA spare parts
282131300101	SUPPORT BRACKET ASSY CROSS MEMBER-RH	TATA spare parts
282131300102	SUPPORT BRACKET ASSY CROSS MEMBER-LH	TATA spare parts
282131400103	ASSY.REINFORCEMENT CHANNEL-RH	TATA spare parts
282131400104	ASSY.REINFORCEMENT CHANNEL-LH	TATA spare parts
282131400105	ASSY.CM SHOCK ABSORBER MTG.	TATA spare parts
282131400108	ASSY. CROSS MEMBER	TATA spare parts
282131400109	ASSY REAR SHOCK ABSORBER CROSS MEMBER	TATA spare parts
282131400113	CROSS MEMBER ASSY BS6	TATA spare parts
282131400115	CROSS MEMBER ASSY BS6	TATA spare parts
282131400123	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
282131403301	SUPPORT BRACKET CROSS MEMBER RH BS6	TATA spare parts
282131403302	SUPPORT BRACKET CROSS MEMBER LH BS6	TATA spare parts
282131407101	SPACER (REAR SPRING BKT.)	TATA spare parts
282131407102	L-BRACKET BS6	TATA spare parts
282131407103	L-BRACKET BS6	TATA spare parts
282131407108	L-BRACKET BS6-PH2	TATA spare parts
282131407115	L-BRACKET BS6	TATA spare parts
282131407118	L-BRACKET BS6	TATA spare parts
282131407123	L-BRACKET BS6	TATA spare parts
282131407128	BRACKET REINFORCEMENT RH BS6-PH2	TATA spare parts
282131407129	BRACKET REINFORCEMENT LH BS6-PH2	TATA spare parts
282131408201	BRACKET(2ND CROSS-MEMBER)	TATA spare parts
282131408209	L-REINFORCEMENT BOTTOM-RH BS6	TATA spare parts
282131408210	L-REINFORCEMENT BOTTOM-LH BS6	TATA spare parts
282131408235	REINFORCEMENT FRONT SPRING HANGER RH BS6	TATA spare parts
282131408236	REINFORCEMENT FRONT SPRING HANGER LH BS6	TATA spare parts
282131505101	TOW HOOK BS6	TATA spare parts
282131505102	TOW HOOK HOLDING BLOCK FRONT BS6	TATA spare parts
282131505103	TOW HOOK HOLDING BLOCK FRONT BS6-PH2	TATA spare parts
282131700103	ASSY BEAM FUPD	TATA spare parts
282131700105	ASSY. SUPPORT BRACKET (LH)	TATA spare parts
282131700106	ASSY SUPPORT BRACKET (RH)	TATA spare parts
282131700112	ASSY.CHANNEL	TATA spare parts
282131700117	ASSY BEAM FUPD	TATA spare parts
282131700119	ASSY.CHANNEL	TATA spare parts
282131700153	CLEAT ASSY BS6	TATA spare parts
282131700170	TOW HOOK ASSY	TATA spare parts
282131700171	BRACKET ASSY BS6-PH2	TATA spare parts
282131703201	HEX BOLT (M12X1.5X160)	TATA spare parts
282131703202	HEX BOLT (M12X1.5X150)	TATA spare parts
282131703203	HEX.BOLT (M12X1.5X35) BS6	TATA spare parts
282131706901	TUBE	TATA spare parts

282131707122	L-PLATE BS6-PH2	TATA spare parts
282131708220	PLATE BS6	TATA spare parts
282131708230	BRACKET STONE GUARD MTG BS6	TATA spare parts
282131708231	BRACKET STONE GUARD MTG BS6	TATA spare parts
282131708232	L-BRACKET BS6	TATA spare parts
282131708233	L-BRACKET BS6	TATA spare parts
282131708234	L-BRACKET BS6	TATA spare parts
282131708235	L-BRACKET RH BS6	TATA spare parts
282131708236	L-BRACKET LH BS6	TATA spare parts
282131708239	L-BRACKET BS6	TATA spare parts
282132100106	ASSY. FRONT SPRING-HIGHER CAMBER	TATA spare parts
282132100107	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
282132100108	ASSY. FRONT SPRING-LOWER CAMBER	TATA spare parts
282132100109	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
282132100112	ASSY FRONT BRACKET-FOR FRONT SPRING	TATA spare parts
282132100119	ASSY. FRONT SPRING (HIGHER CAMBER)	TATA spare parts
282132100120	ASSY. FRONT SPRING (NORMAL CAMBER)	TATA spare parts
282132100121	ASSY. FIRST LEAF WITH BUSH (HIGHER CAMBER)	TATA spare parts
282132100122	ASSY. FIRST LEAF WITH BUSHES (NORMAL CAMBER)	TATA spare parts
282132100125	ASSY FRT PARABOLIC SPRING NORMAL CAMBER	TATA spare parts
282132100126	ASSY FRT PARABOLIC SPRING HIGHER CAMBER	TATA spare parts
282132100127	ASSY FIRST LEAF(WITH BUSH)	TATA spare parts
282132100128	ASSY FIRST LEAF(WITH BUSH)	TATA spare parts
282132100128DF	MAIN LEAF FRONT W/BUSH HI CAMB PARA-LP90	TATA spare parts
282132100129	ASSY. FRONT SPRING (HIGHER CAMBER)	TATA spare parts
282132100130	ASSY. FRONT SPRING (NORMAL CAMBER)	TATA spare parts
282132103201	CENTRE BOLT (EXTENDED HEAD) FRONT SPRING	TATA spare parts
282132103301	BRACKET SPRING HANGER FRONT-FRONT	TATA spare parts
282132103302	BRACKET SPRING HANGER FRONT-REAR	TATA spare parts
282132106701	PIN SPRING FRONT	TATA spare parts
282132107118	SECOND LEAF	TATA spare parts
282132107119	THIRD LEAF (HIGHER CAMBER)	TATA spare parts
282132107120	FOURTH LEAF (HIGHER CAMBER)	TATA spare parts
282132107121	FIFTH LEAF (HIGHER CAMBER)	TATA spare parts
282132107122	SIXTH LEAF (HIGHER CAMBER)	TATA spare parts
282132107123	SEVENTH LEAF (HIGHER CAMBER)	TATA spare parts
282132107124	EIGHTH LEAF (HIGHER CAMBER)	TATA spare parts
282132107125	NINTH LEAF (HIGHER CAMBER)	TATA spare parts
282132107126	TENTH LEAF (HIGHER CAMBER)	TATA spare parts
282132107127	ELEVENTH LEAF (HIGHER CAMBER)	TATA spare parts
282132107128	TWELVETH LEAF (HIGHER CAMBER)	TATA spare parts
282132107130	SECOND LEAF	TATA spare parts
282132107131	THIRD LEAF (NORMAL CAMBER)	TATA spare parts
282132107132	FOURTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107133	FIFTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107134	SIXTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107135	SEVENTH LEAF (NORMAL CAMBER)	TATA spare parts

282132107136	EIGHTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107137	NINTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107138	TENTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107139	ELEVENTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107140	TWELVETH LEAF (NORMAL CAMBER)	TATA spare parts
282132107154	SECOND LEAF (NORMAL CAMBER)	TATA spare parts
282132107154DF	SECOND LEAF FRONT NORM CAMB--LP909/912/9	TATA spare parts
282132107155	THIRD LEAF (NORMAL CAMBER)	TATA spare parts
282132107155DF	THIRD LEAF FRONT NORM CAMB--LP909/912/91	TATA spare parts
282132107156	FOURTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107157	FIFTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107158	SIXTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107159	SEVENTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107160	EIGHTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107161	NINETH LEAF (NORMAL CAMBER)	TATA spare parts
282132107162	TENTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107163	ELEVANTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107164	TWELVETH LEAF (NORMAL CAMBER)	TATA spare parts
282132107165	THIRTEENTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107166	FOURTEENTH LEAF (NORMAL CAMBER)	TATA spare parts
282132107168	SECOND LEAF (HIGHER CAMBER)	TATA spare parts
282132107169	THIRD LEAF(HIGHER CAMBER)	TATA spare parts
282132107170	FOURTH LEAF(HIGHER CAMBER)	TATA spare parts
282132107171	FIFTH LEAF(HIGHER CAMBER)	TATA spare parts
282132107172	SIXTH LEAF(HIGHER CAMBER)	TATA spare parts
282132107173	SEVENTH LEAF(HIGHER CAMBER)	TATA spare parts
282132107174	EIGHTH LEAF(HIGHER CAMBER)	TATA spare parts
282132107175	NINETH LEAF(HIGHER CAMBER)	TATA spare parts
282132107176	TENTH LEAF(HIGHER CAMBER)	TATA spare parts
282132107177	ELEVANTH LEAF(HIGHER CAMBER)	TATA spare parts
282132107178	TWELVETH LEAF(HIGHER CAMBER)	TATA spare parts
282132107179	THIRTEENTH LEAF(HIGHER CAMBER)	TATA spare parts
282132107180	FOURTEENTH LEAF(HIGHER CAMBER)	TATA spare parts
282132107192	SECOND LEAF (NORMAL CAMBER)	TATA spare parts
282132107192DF	SECOND LEAF FRONT NORM CAMB PARA-LP909/9	TATA spare parts
282132107193	THIRD LEAF (NORMAL CAMBER)	TATA spare parts
282132107193DF	THIRD LEAF FRONT NORM CAMB PARA-LP909/91	TATA spare parts
282132107195	SECOND LEAF(HIGHER CAMBER)	TATA spare parts
282132107196	THIRD LEAF (HIGHER CAMBER)	TATA spare parts
282132107197	PACKING PLATE	TATA spare parts
282132107198	SPACER PLATE(PACKING PLATE)	TATA spare parts
282132108301	SPACER PLATE	TATA spare parts
282132200101	BUMP STOPPER BS6	TATA spare parts
282132207104	CASTER PLATE (POWER STEERING)	TATA spare parts
282132300102	ASSY. FRONT SHOCK ABSORBER BRACKET	TATA spare parts
282132300103	BRACKET ASSY SHOCK ABSORBER	TATA spare parts
282132300104	SHOCK ABSORBER ASSY FRONT	TATA spare parts

282132300105	ASSY FRT SHOCK ABS	TATA spare parts
282132300106	SHOCK ABSORBER ASSY FRONT BS6	TATA spare parts
282132300107	BRACKET ASSY SHOCK ABSORBER MTG BS6	TATA spare parts
282132400102	ASSY. REAR SPRING WITH AUX. SPRING	TATA spare parts
282132400103	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
282132400106	ASSY.REAR SPRING	TATA spare parts
282132400108	ASSY. REAR SPRING	TATA spare parts
282132400109	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
282132400111	ASSY FIRST LEAF	TATA spare parts
282132400112	ASSY. REAR SPRING VE	TATA spare parts
282132400117	1ST LEAF ASSY WITH BUSH	TATA spare parts
282132400119	LEAF SPRING ASSY REAR	TATA spare parts
282132400128	REAR SPRING ASSY BS6	TATA spare parts
282132400129	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
282132403201	CENTRE BOLT	TATA spare parts
282132403202	CENTRE BOLT	TATA spare parts
282132403701	SLIDE SUPPORT REAR SPRING FRONT	TATA spare parts
282132403702	SLIDE SUPPORT REAR SPRING REAR	TATA spare parts
282132403703	SLIDE SUPPORT BS6	TATA spare parts
282132404201	SPRING CLIP BS6	TATA spare parts
282132404203	SPRING CLIP BS6	TATA spare parts
282132407102	SECOND LEAF (MAIN SPRING)	TATA spare parts
282132407103	THIRD LEAF (MAIN SPRING)	TATA spare parts
282132407104	FOURTH LEAF (MAIN SPRING)	TATA spare parts
282132407105	FIFTH LEAF (MAIN SPRING)	TATA spare parts
282132407106	SIXTH LEAF (MAIN SPRING)	TATA spare parts
282132407107	SEVENTH LEAF (MAIN SPRING)	TATA spare parts
282132407108	EIGHTH LEAF (MAIN SPRING)	TATA spare parts
282132407109	FIRST LEAF (AUX. SPRING)	TATA spare parts
282132407110	SECOND LEAF (AUX. SPRING)	TATA spare parts
282132407111	THIRD LEAF (AUX. SPRING)	TATA spare parts
282132407112	FOURTH LEAF (AUX. SPRING)	TATA spare parts
282132407113	FIFTH LEAF (AUX. SPRING)	TATA spare parts
282132407114	SIXTH LEAF (AUX. SPRING)	TATA spare parts
282132407115	SEVENTH LEAF (AUX. SPRING)	TATA spare parts
282132407129	SECOND LEAF	TATA spare parts
282132407141	SECOND LEAF	TATA spare parts
282132407142	THIRD LEAF	TATA spare parts
282132407143	FOURTH LEAF	TATA spare parts
282132407144	FIFTH LEAF	TATA spare parts
282132407145	SIXTH LEAF	TATA spare parts
282132407146	SEVENTH LEAF	TATA spare parts
282132407147	EIGHTH LEAF	TATA spare parts
282132407148	SPACER PLATE	TATA spare parts
282132407156	2ND LEAF	TATA spare parts
282132407157	3RD LEAF	TATA spare parts
282132407158	PACKING PLATE	TATA spare parts

282132407161	2ND¿LEAF¿MAIN¿SPRING¿ BS6	TATA spare parts
282132407162	3RD¿LEAF¿ BS6	TATA spare parts
282132407163	4TH¿LEAF¿ BS6	TATA spare parts
282132407164	5TH¿LEAF¿ BS6	TATA spare parts
282132407165	6TH¿LEAF¿ BS6	TATA spare parts
282132407166	7TH¿LEAF¿ BS6	TATA spare parts
282132407167	8TH¿LEAF¿MAIN¿SPRING¿ BS6	TATA spare parts
282132407168	1ST¿LEAF¿AUX¿SPRING¿ BS6	TATA spare parts
282132407169	2ND¿LEAF¿AUX¿SPRING¿ BS6	TATA spare parts
282132407170	3RD¿LEAF¿AUX¿SPRING¿ BS6	TATA spare parts
282132407171	4TH¿LEAF¿AUX¿SPRING¿ BS6	TATA spare parts
282132407172	5TH¿LEAF¿AUX¿SPRING¿ BS6	TATA spare parts
282132407173	6TH¿LEAF¿AUX¿SPRING¿ BS6	TATA spare parts
282132407174	7TH¿LEAF¿AUX¿SPRING¿ BS6	TATA spare parts
282132407175	8TH¿LEAF¿AUX¿SPRING¿ BS6	TATA spare parts
282132407176	9TH¿LEAF¿AUX¿SPRING¿ BS6	TATA spare parts
282132504201	U BOLT REAR SPRING	TATA spare parts
282132504202	U CLAMP	TATA spare parts
282132504203	U CLAMP REAR	TATA spare parts
282132504204	U CLAMP REAR	TATA spare parts
282132504205	U BOLT FOR REAR LEAF SPRING ASSY.	TATA spare parts
282132504206	U - CLAMP (L=315)	TATA spare parts
282132504207	U - CLAMP (L=190)	TATA spare parts
282132600101	ASSY. REAR SHOCK ABSORBER	TATA spare parts
282132601603	REAR SHOCK ABSORBER BS2/3/4	TATA spare parts
282132800102	ASSY.FRONT ANTIROLL BAR COMPLETE	TATA spare parts
282132800103	ASSY.CONNECTING ROD (FRONT ANTIROLLBAR)	TATA spare parts
282132803701	ARB TOP MOUNTING BKT.RH (FRONT)	TATA spare parts
282132803702	CLAMP SUPPORT (FRONT ANTIROLL BAR)	TATA spare parts
282132803703	ARB TOP MOUNTING BRACKET LH (FRONT)	TATA spare parts
282132804201	U CLAMP (FRONT ARB MOUNTING)	TATA spare parts
282132806701	MOUNTING PIN FR ARB BOTTOM END	TATA spare parts
282132806901	TUBE	TATA spare parts
282132807101	CLAMP PLATE (FRONT ARB.MTG.)	TATA spare parts
282132807702	RUBBER BUSH (FRONT ANTIROLL BAR)	TATA spare parts
282132807703	BEARING BLOCK (FRONT ARB MOUNTING)	TATA spare parts
282132807903	ANTIROLLBAR BS6	TATA spare parts
282132900103	ASSY.REAR ANTIROLL BAR COMPLETE	TATA spare parts
282132900104	ASSY. ANTIROLLBAR COMPLETE	TATA spare parts
282132903401	BUSH-HALF (BOTTOM)	TATA spare parts
282132903402	BUSH-HALF (TOP)	TATA spare parts
282132903701	BRACKET RH	TATA spare parts
282132903702	BRACKET LH	TATA spare parts
282132907101	CLAMP (REAR ANTIROLL BAR)	TATA spare parts
282133000101	ASSY.FRONT AXLE WITH BRAKE	TATA spare parts
282133000104	FA 912 ABS RHD	TATA spare parts
282133000107	ASSY FRONT AXLE WITH BRAKES	TATA spare parts



282133000111	ASSY.FRONT AXLE WITH BRAKES(NON ASBS)	TATA spare parts
282133000112	ASSY.FRONT AXLE WITH BRAKES(NON ASBS)	TATA spare parts
282133000113	ASSY FRONT AXLE WITH BRAKE	TATA spare parts
282133000114	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
282133000120	FA 912 BSIV ABS RHD	TATA spare parts
282133000122	FRONT AXLE 909 ABS RHD MULTIPLEX	TATA spare parts
282133000128	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
282133000133	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
282133000135	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
282133000136	FRONT AXLE ASSY WITH BRAKEBS6	TATA spare parts
282133000137	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
282133000139	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
282133105102	FRONT AXLE BEAM STD BS2/3/4	TATA spare parts
282133105106	FRONT AXLE BEAM(LOOSE FIT K.P NORMAL)	TATA spare parts
282133200102	ASSY.STUB AXLE STD	TATA spare parts
282133200106	ASSY STUB AXLE WITH BUSH STD	TATA spare parts
282133200115	ASSY STUB AXLE RH NORMAL(ABS)	TATA spare parts
282133200116	ASSY STUB AXLE LH NORMAL(ABS)	TATA spare parts
282133203101	THRUST BEARING STD	TATA spare parts
282133203102	THRUST BEARING (NORMAL-I) LH	TATA spare parts
282133203402	BUSH BS2/3/4/6	TATA spare parts
282133205101	STUB AXLE	TATA spare parts
282133205103	SPLIT NUT	TATA spare parts
282133205106	STUB AXLE RH(ABS)	TATA spare parts
282133205107	STUBE AXLE LH(ABS)	TATA spare parts
282133206701	KING PIN STD	TATA spare parts
282133208302	SHIM 0.8 MM THICK	TATA spare parts
282133208303	SHIM 0.85 MM THICK	TATA spare parts
282133208304	SHIM 0.9 MM THICK	TATA spare parts
282133208305	SHIM 0.95 MM THICK	TATA spare parts
282133208306	SHIM 1.0 MM THICK	TATA spare parts
282133208307	SHIM 1.05 MM THICK	TATA spare parts
282133208308	SHIM 1.10 MM THICK	TATA spare parts
282133208309	SHIM 1.15 MM THICK	TATA spare parts
282133208310	SHIM 1.20 MM THICK	TATA spare parts
282133208311	SHIM 1.25 MM THICK	TATA spare parts
282133208312	SHIM 1.30 MM THICK	TATA spare parts
282133208313	SHIM 1.35 MM THICK	TATA spare parts
282133208314	SHIM 1.40 MM THICK	TATA spare parts
282133208315	SHIM 1.45 MM THICK	TATA spare parts
282133208316	SHIM 1.50 MM THICK	TATA spare parts
282133208317	SHIM 1.55 MM THICK	TATA spare parts
282133208318	SHIM 1.60 MM THICK	TATA spare parts
282133208319	SHIM 1.65 MM THICK	TATA spare parts
282133208320	SHIM 1.70 MM THICK	TATA spare parts
282133209201	THRUST WASHER	TATA spare parts
282133209202	WASHER	TATA spare parts

282133209901	SPACER	TATA spare parts
282133400101	ASSY.HUB W/ BRGS	TATA spare parts
282133400103	ASSY. HUB	TATA spare parts
282133400104	ASSY.HUB WITH PIN	TATA spare parts
282133400105	ASSY.CAP RING & GREASE NIPPLE (AM8X1)	TATA spare parts
282133400106	ASSY.CAP RING & GREASE NIPPLE	TATA spare parts
282133400107	ASSY FRONT HUB WITH PIN	TATA spare parts
282133400108	ASSY HUB WITH BRGS	TATA spare parts
282133400111	ASSY.FRONTHUBWITHPIN BS6	TATA spare parts
282133400112	FRONT HUB ASSY ABS	TATA spare parts
282133403101	TAPER ROLLER BEARING(FRNT.HUB INNER)	TATA spare parts
282133403102	THRUST BEARING-NORMAL	TATA spare parts
282133403106	THRUST BEARING-NORMAL	TATA spare parts
282133403109	THRUST BEARING-NORMAL	TATA spare parts
282133403110	TAPER ROLLER BRG 33211	TATA spare parts
282133403113	THRUST BEARING (NORMAL-I) RH	TATA spare parts
282133403114	THRUST BEARING-NORMAL	TATA spare parts
282133403122	THRUST BEARING¿ (NORMAL)	TATA spare parts
282133403701	FRONT HUB	TATA spare parts
282133403702	FRONT HUB	TATA spare parts
282133403703	FRONT HUB(ABS)	TATA spare parts
282133403704	FRONT HUB	TATA spare parts
282133405501	FRONT HUB ABS	TATA spare parts
282133405502	FRONT HUB BS6-PH2	TATA spare parts
282133407701	SEALING RING	TATA spare parts
282133408202	KING PIN CAP	TATA spare parts
282133800101	TIE ROD ASSY	TATA spare parts
282133800102	BALL JOINT ASSEMBLY RH	TATA spare parts
282133800103	BALL JOINT ASSEMBLY LH	TATA spare parts
282133805101	STEERING ARM BS6	TATA spare parts
282133805102	STEERING ARM BS6-PH2	TATA spare parts
282133805104	STEERING ARM	TATA spare parts
282133805105	TIE ROD ARM RH	TATA spare parts
282133805106	STEERING ARM (RH)	TATA spare parts
282133805108	TIE ROD ARM RH	TATA spare parts
282133805109	TIE ROD ARM LH	TATA spare parts
282133805110	STEERING ARM	TATA spare parts
282140100104	ASSY. WHEEL DISC & RIM BS2/3/4	TATA spare parts
282140100112	ASSY.WH.RIM 6.00GX16 131.5 O/S	TATA spare parts
282140100117	TUBE	TATA spare parts
282140100118	TUBE	TATA spare parts
282140100128	WHEEL RIM ASSYBS6	TATA spare parts
282140100134	ASSY.WHEEL RIM 6G X 16	TATA spare parts
282140100148	ASSY.WHEEL RIM 6G X 16	TATA spare parts
282140100149	ASSY. WHEEL RIM 6.00GX16 131.5 O/S	TATA spare parts
282140100151	WHEEL RIM ASSY¿BS6	TATA spare parts
282140100152	ASSY WHEEL RIM 6.0GX16	TATA spare parts

282140100153	WHEEL RIM ASSY¿BS6	TATA spare parts
282140106701	HUB PIN REAR SCAM	TATA spare parts
282140106702	HUB PIN FRONT M18 X 87 10.9 IS1367	TATA spare parts
282140107702	FLAP	TATA spare parts
282140107703	FLAP	TATA spare parts
282140109901	TYRE	TATA spare parts
282140109903	TYRE	TATA spare parts
282140300102	ASSEMBLY SPARE WHEEL CARRIER	TATA spare parts
282140300103	ASSY. SPARE WHEEL CARRIER	TATA spare parts
282140300104	ASSY HANDLE.	TATA spare parts
282140300105	ASSY BRACKET (SPARE WHEEL MOUNTING)	TATA spare parts
282140300106	ASSY SPARE WHEEL CARRIER	TATA spare parts
282140300108	ASSY.SPARE WHEEL CARRIER	TATA spare parts
282140300109	ASSY.BRACKET (SPARE WHEEL MOUNTING)	TATA spare parts
282140300110	ASSY.BRACKET	TATA spare parts
282140300111	SPARE WHEEL ATTACHMENT SUPPORT ASSEMBLY	TATA spare parts
282140300114	ASSY.SPARE WHEEL CARRIER	TATA spare parts
282140300117	SPACER ASSY SPARE WHEEL CARRIER BS6	TATA spare parts
282140307101	SPARE WHEEL ATTACHMENT PLATE	TATA spare parts
282141000101	ASSY.UNITISED PROP.SHAFT	TATA spare parts
282141000110	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
282141000111	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
282141000112	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
282141000113	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
282141000118	ASSY. UNITIZED PROP. SHAFT BS3	TATA spare parts
282141000127	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
282141000130	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
282141000139	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
282141000143	ASSY.UNITISED PROP.SHAFT 38WB	TATA spare parts
282141000144	ASSY.UNITISED PROP.SHAFT 34WB	TATA spare parts
282141000145	PROPELLER ASSY CONSTANT VELOCITY	TATA spare parts
282141000152	PROPELLER SHAFT ASSY REAR	TATA spare parts
282141000153	ASSY.UNITIZED PROP.SHAFT	TATA spare parts
282141000154	ASSY.UNITIZED PROP.SHAFT	TATA spare parts
282141009901	SLEEVE YOKE	TATA spare parts
282141009902	KIT- U J 1480	TATA spare parts
282141009903	FLANGE YOKE 1480	TATA spare parts
282141009904	PROPELLER SHAFT SPLIT PIN	TATA spare parts
282141009905	PROPELLER SHAFT NUT	TATA spare parts
282141009906	PROPELLER SHAFT WASHER	TATA spare parts
282141009907	PROPELLER SHAFT COMPANION FLANGE	TATA spare parts
282141100105	PROPELELR SHAFT ASSY MONOTRON	TATA spare parts
282141100109	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
282141100110	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
282141100111	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
282141100112	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
282141100113	PROPELLER SHAFT ASSY BS6	TATA spare parts

282141100114	PROPELLER SHAFT ASSY BS6	TATA spare parts
282141100115	PROPELLER SHAFT ASSY BS6	TATA spare parts
282141105101	COUPLING FLANGE ASSY	TATA spare parts
282141110101	ASSY.PROP.SHAFT FRONT WITH CENTER BRG.	TATA spare parts
282141110104	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
282141110105	ASSY.PROP.SHAFT W CENT. BRG. 909	TATA spare parts
282141110106	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
282141110117	ASSY. PROP. SHAFT FRONT	TATA spare parts
282141110118	ASSY. PROP. SHAFT FRONT	TATA spare parts
282141110130	KIT-UNIVERSAL JOINT BS2/3/4	TATA spare parts
282141110130DF	UJ CROSS 34.95X126-LPT909/1109/1412	TATA spare parts
282141110131	KIT-CENTER BEARING BS2/3/4	TATA spare parts
282141110133	SLIP YOKE	TATA spare parts
282141110138	PROPELLER ASSY CONSTANT VELOCITY	TATA spare parts
282141110151	PROPELLER SHAFT ASSY FRONT	TATA spare parts
282141110152	PROPELLER SHAFT ASSY FRONT	TATA spare parts
282141110157	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
282141110158	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
282141110159	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
282141110162	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
282141115202	FLANGE YOKE	TATA spare parts
282141118202	BRACKET CENTER BRG SUPPORT BS6	TATA spare parts
282141120101	ASSY.PROP.SHAFT REAR COMPLETE	TATA spare parts
282141120104	ASSY.PROP.SHAFT REAR COMPLETE	TATA spare parts
282141120106	ASSY. PROP. SHAFT REAR COMPLETE	TATA spare parts
282141120109	ASSY.REAR PROP.SHAFT COMPLETE	TATA spare parts
282141120113	ASSY.KIT REAR PROP.SHAFT	TATA spare parts
282141120118	ASSY.PROP.SHAFT REAR COMPLETE	TATA spare parts
282141120120	PROPELLER SHAFT ASSY DRIVES6	TATA spare parts
282141120121	PROPELLER SHAFT ASSY REAR BS6	TATA spare parts
282141120128	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
282141120140	PROPELLER SHAFT ASSY REAR	TATA spare parts
282141129901	FLANGE YOKE FULL RND	TATA spare parts
282141129902	KIT- U J	TATA spare parts
282141129903	FLANGE YOKE FULL RND	TATA spare parts
282141129905	SHORTFORKTUBE&REARENDPIECEASSY BS6	TATA spare parts
282141155202	FLANGE YOKE	TATA spare parts
282141300104	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
282141300105	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
282141307101	BRACKET CENTER BRG MTG BS6	TATA spare parts
282141307115	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
282141307116	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
282141307117	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
282141308201	REINFORCEMENT	TATA spare parts
282141323301	PROPELLER SHAFT ASSY GUARD	TATA spare parts
282141990102	CROSS	TATA spare parts
282142100102	ASSY.FRONT BRAKE LH WITH DUST COVER	TATA spare parts

282142100104	ASSY.FRONT AXLE BRAKE RH WITH DUST COVER	TATA spare parts
282142100107	ASSY. TYPE 14 BRAKE CHAMBER	TATA spare parts
282142100118	ASSY.BRAKE SHOE WITH AF235 LINER	TATA spare parts
282142100125	ASSY FRONT AXLE BRAKE RH WITH DUST COVER	TATA spare parts
282142100129	ASSY FRONT AXLE BRAKE LH WITH DUST COVER	TATA spare parts
282142100131	ASSY DRUM BRAKE FRONT RH WT DC&FAST-	TATA spare parts
282142100132	ASSY DRUM BRAKE FRONT LH WT DC&FAST-	TATA spare parts
282142100135	BRAKE CHAMBER-TYPE 10.5	TATA spare parts
282142100137	BRAKE CHAMBER TYPE 12 WITH ADAPTOR	TATA spare parts
282142100144	ASSY BRAKE FRONT LH WT D/C. AF235 ABS	TATA spare parts
282142100145	ASSY BRAKE FRONT RH WT D/C AF235 ABS	TATA spare parts
282142100161	ASLY.BRAKE COMPLETE.325X140-LH	TATA spare parts
282142100162	ASLY.BRAKE COMPLETE.325X140-RH	TATA spare parts
282142100188	AUTO SLACK ADJUSTER	TATA spare parts
282142100189	AUTO SLACK ADJUSTER LH	TATA spare parts
282142100190	AUTO SLACK ADJUSTER RH	TATA spare parts
282142103201	COLLERED PIN	TATA spare parts
282142103202	PIN	TATA spare parts
282142103205	HEX BOLT (STRG. ARM REAR SIDE)	TATA spare parts
282142103206	HEX BOLT (W/O STRG. ARM SIDE)	TATA spare parts
282142103207	HEX BOLT (STRG. ARM FRONT SIDE)	TATA spare parts
282142103209	HEX BOLT M14X1.5X145	TATA spare parts
282142103702	BRAKE DRUM BS2/3/4	TATA spare parts
282142103703	BRAKE DRUM BS3/4	TATA spare parts
282142108301	SHIM 0.30 MM	TATA spare parts
282142108302	SHIM 0.50 MM	TATA spare parts
282142109201	WASHER	TATA spare parts
282142109202	WASHER-2.0 MM THK	TATA spare parts
282142109901	BRAKE ASSY -KIT BUSH	TATA spare parts
282142110101	ASSY.BRAKE SHOE WITH LINER	TATA spare parts
282142110105	KIT-LINING SET-STD	TATA spare parts
282142110106	KIT LINING SET-1.0 O/S	TATA spare parts
282142110107	BRAKE LINING SECONDARY KIT	TATA spare parts
282142300103	ASSY.R/A BRAKE LH WITH DUST COVER	TATA spare parts
282142300105	ASSY.R/A BRAKE RH WITH DUST COVER-ASB	TATA spare parts
282142300107	ASSY. BRACKET RH-FOR REAR CHAMBER MTG.	TATA spare parts
282142300108	ASSY.BRACKET LH FOR REAR CHAMBER MTG.	TATA spare parts
282142300116	ASSY R/A BRAKE RH WITH DUST COVER.	TATA spare parts
282142300119	ASSY R/A BRAKE LH WITH DUST COVER.	TATA spare parts
282142300124	ASSY DRUM BRAKE REAR RH WT DC&FAST-	TATA spare parts
282142300125	ASSY DRUM BRAKE REAR LH WT DC&FAST-	TATA spare parts
282142300141	ASSY DRUM BRAKE RH WT DC BIL AF235 ABS	TATA spare parts
282142300142	ASSY DRUM BRAKE LH WT DC BIL AF235 ABS	TATA spare parts
282142300152	ASSY REAR AXLE BRAKE LH W/DUST COVER	TATA spare parts
282142300153	ASSY REAR AXLE BRAKE RH W/DUST COVER	TATA spare parts
282142300156	ASSY REAR AXLE BRAKE ACTUATOR MTG BKT LH	TATA spare parts
282142300157	BRACKET ASSY ACTUATOR MTG REAR-RH - BS6	TATA spare parts

282142300163	ASSY REAR AXLE BRAKE RH WITH DUST COVER	TATA spare parts
282142300164	ASSY REAR AXLE BRAKE LH WITH DUST COVER	TATA spare parts
282142300167	KIT BUSH ASSY LPK	TATA spare parts
282142300169	KIT BUSH ASSEMBLY	TATA spare parts
282142300184	BRAKE ASSY 325X140 W-GROMMET & D/C-LH.	TATA spare parts
282142300185	BRAKE ASSY 325X140 W-GROMMET & D/C-RH.	TATA spare parts
282142300192	LINED SHOE ASSYMBLY(325X140)	TATA spare parts
282142300210	BRAKE ASSY REAR LH BRAKE W/T D/C.	TATA spare parts
282142300211	BRAKE ASSY REAR RH BRAKE W/T D/C.	TATA spare parts
282142303311	BRACKET ASSY SENSOR MTG BS6-PH2	TATA spare parts
282142303701	REAR BRAKE CHEMBER MTG BKT LH	TATA spare parts
282142303702	BRAKE CHEMBER ASSY MTG BKT	TATA spare parts
282142303703	REAR BRAKE DRUM BS3/4	TATA spare parts
282142303704	TORQUEPLATE LPK	TATA spare parts
282142303705	SPIDER REAR	TATA spare parts
282142303708	BRAKE ASSY TORQUE PLATE (ABS)	TATA spare parts
282142303709	BRACKET -LH SBA MOUNTING	TATA spare parts
282142303710	BRACKET -RH SBA MOUNTING	TATA spare parts
282142305104	REAR CAMSHAFT LH	TATA spare parts
282142305105	REAR CAMSHAFT RH	TATA spare parts
282142307501	RUBBER GROMMET (FOR DIA 18 HOLE)	TATA spare parts
282142307502	RUBBER GROMMET (FOR DIA 6.5 HOLE)	TATA spare parts
282142307503	RUBBER GROMMET (18 DIA. HOLE PLUGGED)	TATA spare parts
282142308202	DUST COVER TOP 325X140	TATA spare parts
282142308203	DUST COVER BOTTOM 325X140	TATA spare parts
282142308204	DUST SHIELD ASSY-TOP	TATA spare parts
282142308205	DUST SHIELD ASSY-BOTTOM	TATA spare parts
282142308206	ANCHOR BRACKET -LH	TATA spare parts
282142308207	ANCHOR BRACKET -RH	TATA spare parts
282142308401	SLEEVE	TATA spare parts
282142308601	SPACER	TATA spare parts
282142308602	SPACER (CAM SHAFT)	TATA spare parts
282142309905	POLE WHEEL REAR BS6-PH2	TATA spare parts
282142310105	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
282142310106	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
282142403301	BRACKET LCRV MTG	TATA spare parts
282142990102	KIT TORQUE PLATE ASSY	TATA spare parts
282142990114	KIT BRACKET ASSY	TATA spare parts
282142990117	KIT-CAMSHAFT	TATA spare parts
282142990118	KIT-CAMSHAFT	TATA spare parts
282142990151	DUST SHIELD	TATA spare parts
282142990152	DUST SHIELD	TATA spare parts
282142990165	KIT CAMSHAFT LH ( BIL) BS6	TATA spare parts
282142990166	KIT CAMSHAFT RH ( BIL) BS6	TATA spare parts
282142990170	KIT-TORQUE PLATE ASSY LH BS6-PH2	TATA spare parts
282142990171	KIT-TORQUE PLATE ASSY RH BS6-PH2	TATA spare parts
282142990174	KIT-BRACKET ASSY LH BS6-PH2	TATA spare parts

282142990175	KIT-BRACKET ASSY RH BS6-PH2	TATA spare parts
282142990178	KIT-CAMSHAFT LH BS6-PH2	TATA spare parts
282142990179	KIT-CAMSHAFT RH BS6-PH2	TATA spare parts
282142990182	KIT-TORQUE PLATE ASSY BS6-PH2	TATA spare parts
282142990184	KIT-CAMSHAFT LH BS6-PH2	TATA spare parts
282142990185	KIT-CAMSHAFT RH BS6-PH2	TATA spare parts
282142998201	DUST SHIELD TOP	TATA spare parts
282142998202	DUST SHIELD BOTTOM	TATA spare parts
282143200101	ASSY.AIR TANKS 20 LIT. COMPLETE WITH 110	TATA spare parts
282143200102	ASSY.AIR TANK(WITH LAPPED JOINTS)-20 LT.	TATA spare parts
282143200104	ASSY.AIR TANK 20 LIT.WITH SEALING PLUG	TATA spare parts
282143200107	ASSY AIR TANK-110 STRAP CENTRE DIST	TATA spare parts
282143200110	SUB ASSY. AIR TANK (20 LIT) LH	TATA spare parts
282143200111	SUB ASSY. AIR TANK (20 LIT) RH	TATA spare parts
282143200112	ASSY. AIR TANK 20 LIT. COMPLETE WITH 110	TATA spare parts
282143200113	SUB ASSY. AIR TANK (20 LIT) RH NON VOSS	TATA spare parts
282143200114	SUB ASSY. AIR TANK (20 LIT) LH NON VOSS	TATA spare parts
282143200115	AIRTANK WITH WELED BRACKET (20LTRS)	TATA spare parts
282143200122	AIR TANK ASSY WITH MTG BKT BS6-PH2	TATA spare parts
282143200125	AIR TANK ASSY BS6	TATA spare parts
282143200128	AIR TANK ASSY WITH BKT BS6	TATA spare parts
282143200131	AIR TANK ASSY RH BS6	TATA spare parts
282143200133	AIR TANK ASSY LH BS6	TATA spare parts
282143200136	AIR TANK ASSY BS6-PH2	TATA spare parts
282143200137	AIR TANK ASSY BS6-PH2	TATA spare parts
282143400102	BRACKET ASSY BS6-PH2	TATA spare parts
282143700105	ASSY GEAR DRIVEN COMPRESSOR WATER COOLE	TATA spare parts
282143700106	DUAL BRAKE VALVE WITH BIAS BS2/3/4	TATA spare parts
282143700108	AUTO LOAD SENSING VALVE (ALL VOSS PORT F	TATA spare parts
282143700109	BRACKET ASSY-HAND BRAKE VALVE MTG	TATA spare parts
282143700110	RELAY VALVE & MODULATOR VALVE ASSY B	TATA spare parts
282143700120	DRYING & DISTRIBUTION UNIT;BS6	TATA spare parts
282143700141	DUAL BRAKE VALVE BS6	TATA spare parts
282143703302	BRACKET BS6	TATA spare parts
282143707101	BRACKET (RELAY VALVE MTG.)	TATA spare parts
282143710109	KIT-DUAL BRAKE VALVE BS6-PH2	TATA spare parts
282143800101	METAL PIPE ASSY JOINT TO HOSE BS6	TATA spare parts
282143800102	METAL PIPE ASSY JOINT TO DDU BS6	TATA spare parts
282143800128	METAL PIPE ASSY ADAPTER TO ADAPTER BS6-P	TATA spare parts
282143800129	METAL PIPE ASSY ADAPTER TO APU BS6-PH2	TATA spare parts
282143900109	ASSY.NY PIPE SET CHASSIS COMPL-LPT909/38	TATA spare parts
282143900135	ASSY NYLON PIPE SET CHASS COMP LPT 912	TATA spare parts
282143900139	ASSY. METAL PIPE (COMPRESSOR TO DDU)	TATA spare parts
282143900144	ASSY.NYLON PIPE SET FOR CHASSIS	TATA spare parts
282143900149	ASSY NYLON PIPE SET CHASS COMP LP 909	TATA spare parts
282143900164	ASSY NYLON PIPE SET CHASS COMP LPK 909	TATA spare parts
282143900178	ASSY METAL PIPE SECOND FROM COMP TO DDU	TATA spare parts

282143900179	ASSY METAL PIPE THIRD FROM COMP TO DDU	TATA spare parts
282143900187	ASSY METAL PIPE DIA12 RELAY VALVE TO RBA	TATA spare parts
282143900188	ASSY METAL PIPE DIA12 TEE TO RELAY VALVE	TATA spare parts
282143900189	ASSY METAL PIPE DIA 12 RST TO TEE	TATA spare parts
282143900190	PIPE ASSY TEE TO SBA11 RH	TATA spare parts
282143900191	PIPE ASSY TEE TO SBA11 LH	TATA spare parts
282143900192	PIPE ASSY TEE TO SBA12 RH	TATA spare parts
282143900193	PIPE ASSY TEE TO SBA12 LH	TATA spare parts
282143900194	ASSY METAL PIPE DIA 12 FST TO DBV-1	TATA spare parts
282143900195	ASSY METAL PIPE DIA 12 FST TO DBV-2	TATA spare parts
282143900196	ASSY METAL PIPE DIA 12 DDU TO RST	TATA spare parts
282143900197	ASSY METAL PIPE DIA 12 DDU TO FST	TATA spare parts
282143900198	ASSY METAL PIPE DIA 12 TEE TO DBV	TATA spare parts
282143900199	ASSY METAL PIPE DIA 12 HBV TO RBA-3	TATA spare parts
282143900201	PIPE ASSY WITH CRIMP HOSE	TATA spare parts
282143900202	ASSY.METAL PIPE DIA.15.	TATA spare parts
282143900210	ASSY NYLON PIPE SET CHASSIS COMPL	TATA spare parts
282143900213	ASSY.BRACKET (HOSE MTG.ON REAR AXLE)	TATA spare parts
282143900214	RETRO KIT FOR LP909 49WB BS-II/III/IV	TATA spare parts
282143900225	ASSY. RETRO KIT FOR LPT909 3800WB	TATA spare parts
282143900234	ASSY NYLON PIPE SET CHASSIS COMPL. LPT90	TATA spare parts
282143900237	RETRO KIT FOR LPK909/912 27WB	TATA spare parts
282143900241	PIPE BUNCH ASSY CHASSIS	TATA spare parts
282143900250	PIPE ASSY BUNCH COMPLETE	TATA spare parts
282143900272	BRACKET ASSY FOR REAR HOSE MOUNTING	TATA spare parts
282143900301	PIPE ASSY WITH CRIMP HOSE	TATA spare parts
282143900302	PIPE ASSY COMP CRIMP HOSE TO DDU	TATA spare parts
282143900311	PIPE BUNCH ASSY CHASSIS	TATA spare parts
282143900326	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
282143900354	PIPE BUNCH ASSY CHASSIS	TATA spare parts
282143900380	METAL PIPE ASSY BS6-PH2	TATA spare parts
282143900381	METAL PIPE ASSY BS6-PH2	TATA spare parts
282143900392	PIPE BUNCH ASSY CHASSIS BS6-PH2	TATA spare parts
282143901601	HOSE 3/8FOR DIA 12 WITH END FITIG	TATA spare parts
282143901602	HOSE 3/8FOR DIA 6 WITH END FITING	TATA spare parts
282143903301	L BRACKET (METAL PIPE) BS6	TATA spare parts
282143903304	BRACKET REAR BRAKE HOSE MTG	TATA spare parts
282143903309	BRACKET (METAL PIPE AT CL BOOSTER)	TATA spare parts
282143903311	L - BRACKET (T MTG. ON CROSS MEMBER) BS6	TATA spare parts
282143903312	HOSE MTG. BRACKET ON LCRV	TATA spare parts
282143903501	BOSS BS6	TATA spare parts
282143906801	ELBOW BULKHEAD NW9-M18X1.5 BS6	TATA spare parts
282143907501	RUBBERGROMMETBS6	TATA spare parts
282143908201	BRACKET-MODULATOR VALVE MTG.- FRONT.	TATA spare parts
282143908202	BRACKET-MODULATOR VALVE MTG. REAR	TATA spare parts
282143908203	BRACKET MODULATOR VALVE (REAR)	TATA spare parts
282143908204	BRACKET MODULATOR VALVE (REAR LH)	TATA spare parts



282143908209	BRACKET FOR QUICK RELEASE VALVE	TATA spare parts
282143910101	ASSY METAL PIPE DIA 12 HBV TO RBA-4	TATA spare parts
282143910102	ASSY METAL PIPE DIA 12 DBV TO FST	TATA spare parts
282143910103	ASSY METAL PIPE DIA 12 FST TO DBV3	TATA spare parts
282143910104	ASSY HOSE 3/8 IN FOR DIA 12 (L500)	TATA spare parts
282143910105	ASSY HOSE 3/8 IN FOR DIA 6 (L500)	TATA spare parts
282143910106	ASSY METAL PIPE DIA 6 DBV TO RELAY VAL 3	TATA spare parts
282143910107	ASSY METAL PIPE DIA 12 HBV TO RBA1	TATA spare parts
282143910108	ASSY METAL PIPE DIA 6 DDU TO HBV3	TATA spare parts
282143910109	ASSY METAL PIPE DIA 12 HBV TO RBA2	TATA spare parts
282143910110	ASSY METAL PIPE DIA 6 DDU TO HBV2	TATA spare parts
282143910112	ASSY METAL PIPE DIA 12 DBV TO FTEE	TATA spare parts
282143910113	ASSY METAL PIPE DIA 12 FTEE TO FBC LH	TATA spare parts
282143910114	ASSY METAL PIPE DIA 12 FTEE TO FBC RH	TATA spare parts
282143910115	SSSY METAL PIPE DIA 6 DDU TO HBV1	TATA spare parts
282143910116	ASSY METAL PIPE DIA 6 DBV TO RELA VALVE1	TATA spare parts
282143910117	ASSY METAL PIPE DIA 6 DBV TO RELAY VAL 2	TATA spare parts
282143910118	ASSY METAL PIPE DIA 15 COMPRESSOR TO DDU	TATA spare parts
282143910119	METAL PIPE DIA 6 DBV TO GAUGE REAR	TATA spare parts
282143910120	METAL PIPE DIA 6 DBV TO GAUGE REAR	TATA spare parts
282143910122	METAL PIPE DIA15(COMPRESSOR TO DDU)	TATA spare parts
282143910123	METAL PIPE DIA12 (DDU TO FST)	TATA spare parts
282143910124	METAL PIPE DIA12 (FST TO DV-1)	TATA spare parts
282143910126	METAL PIPE WITH CRIMPED HOSE(FST TO DBV-	TATA spare parts
282143910127	METAL PIPE DIA12 WITH CRIMPED HOSE(DBV T	TATA spare parts
282143910128	ASSY BRACKET (AIRTANK MTG)	TATA spare parts
282143910129	METAL PIPE DIA12(DDU TO RST)	TATA spare parts
282143910130	METAL PIPE DIA12(RST TO DBV-1)	TATA spare parts
282143910132	METAL PIPE DIA12 WITH CRIMPED HOSE(RST T	TATA spare parts
282143910133	METAL PIPE DIA12 WITH CRIMPED HOSE(DBV T	TATA spare parts
282143910134	METAL PIPE DIA12(DBV TO LCRV-2)	TATA spare parts
282143910136	METAL PIPE DIA6 (DDU TO HBV-1)	TATA spare parts
282143910138	METAL PIPE DIA6 WITH CRIMPED HOSE(DDU TO	TATA spare parts
282143910139	NYLON PIPE DIA6 (DDU TO HBV-4)	TATA spare parts
282143910141	METAL PIPE DIA12 WITH CRIPMED HOSE(HBV T	TATA spare parts
282143910142	METAL PIPE DIA12 (HBV TO RBA-3)	TATA spare parts
282143910143	METAL PIPE DIA12 (HBV TO RBA-4)	TATA spare parts
282143910149	ASSY NYLON PIPE CHASSIS SET COMPL	TATA spare parts
282143910158	ASSY BRACKET (AIRTANK MTG)	TATA spare parts
282143910165	ASSY METAL PIPE DIA15 (COMP TO DDU)	TATA spare parts
282143910167	ASSY NYLON PIPE CHASSIS SET COMPL	TATA spare parts
282143910173	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
282143910174	ASSY.BRACKET HOSE MTG.ON REAR AXLE	TATA spare parts
282143910214	PIPE ASSY HBV TO RBC WITH SANTOPRENE	TATA spare parts
282143910215	PIPE DDU TO HBV WITH SANTOPRENE	TATA spare parts
282143910248	PIPE ASSY BUNCH COMPLETE	TATA spare parts
282143910260	PIPE ASSY BUNCH FOR CAB	TATA spare parts

282143910264	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
282143910266	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
282143910296	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
282143913311	Z-BRACKETBS6	TATA spare parts
282143917501	RUBBER GROMMET	TATA spare parts
282143920134	METAL PIPE ASSY WITH CRIMPED RUBBER HOSE	TATA spare parts
282143920136	METAL PIPE ASSY HOSE TO ADAPTER BS6	TATA spare parts
282143920137	METAL PIPE ASSY JOINT TO DDU BS6	TATA spare parts
282143920138	METAL PIPE ASSY JOINT TO HOSE BS6	TATA spare parts
282143920139	PIPE BUNCH ASSY CABIN	TATA spare parts
282143920157	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
282143920161	PIPE ASSY BUNCH COMPLETE	TATA spare parts
282143920174	PIPE ASSY BUNCH COMPLETE	TATA spare parts
282143920178	METAL PIPE ASSY FIRST	TATA spare parts
282143920179	METAL PIPE ASSY COUG. BODY TO COUG. BODY	TATA spare parts
282143930128	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
282143930149	PIPE ASSY BUNCH COMPLETE	TATA spare parts
282143940108	PIPE ASSY BUNCH FOR CHASSIS	TATA spare parts
282143940109	PIPE ASSY BUNCH FOR CAB	TATA spare parts
282143940178	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
282143940197	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
282143950120	PIPE ASSY BUNCH COMPLETE	TATA spare parts
282143950131	PIPE ASSY BUNCH COMPLETE	TATA spare parts
282143950132	PIPE BUNCH ASSY CABIN	TATA spare parts
282143950134	METAL PIPE ASSY JOINT TO HOSE	TATA spare parts
282143950135	METAL PIPE ASSY JOINT TO DDU	TATA spare parts
282143960120	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
282143960121	METAL PIPE ASSY BS6	TATA spare parts
282143960138	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
282143960144	PIPE BUNCH ASSY CABIN BS6	TATA spare parts
282143960147	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
282143960180	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
282143960188	PIPE ASSY QRV TO FBC RH BS6	TATA spare parts
282143970121	PIPE BUNCH ASSY CABIN BS6-PH2	TATA spare parts
282143990101	BRAKE CHAMBER TYPE 12	TATA spare parts
282146100103	STEERING&&C&C;COLUMN&&C&C;ASSY	TATA spare parts
282146100104	RUBBER&&C&C;BELLOW&&C&C;ASSY	TATA spare parts
282146100105	STEERING COLUMN ASSY UPPER	TATA spare parts
282146108001	HEX FLANGE BOLT M18X1.5X35	TATA spare parts
282146108201	CLAMPING RING BS6	TATA spare parts
282146200109	ASSY.VARIABLE STG.GEARBOX LPT909	TATA spare parts
282146200110	ASSY.COVER	TATA spare parts
282146200112	ASSY.GEAR BOX HSG.WITH BUSH (RH)	TATA spare parts
282146200114	ASSY. HOUSING COVER	TATA spare parts
282146200115	ASSY.SECTOR SHAFT	TATA spare parts
282146200117	ASSY. STEERING WORM W/STG. NUT BS2/3/4	TATA spare parts
282146200120	ASSY POWER STRG.GEAR BOX	TATA spare parts

282146200122	ASSY. STEERING GEAR BOX MTG. BKT BS2/3/4	TATA spare parts
282146200130	INPUT SHAFT SEAL KIT	TATA spare parts
282146200131	WORM & VALVE HSG & RACK ASM	TATA spare parts
282146200132	WORM AND VALVE HSG	TATA spare parts
282146200134	O RING-SPIGOT	TATA spare parts
282146200135	O RING SMALL	TATA spare parts
282146200138	SEAL RING VALVE	TATA spare parts
282146200139	ROLLER BEARING	TATA spare parts
282146200142	CLIP	TATA spare parts
282146200144	SET SCREW	TATA spare parts
282146200145	POPPET VALVE KIT	TATA spare parts
282146200146	SEAL KIT (PISTON RACK)	TATA spare parts
282146200147	NUT DROP ARM	TATA spare parts
282146200148	WASHER DROP ARM	TATA spare parts
282146200150	SEAL KIT (OUT SIDE)	TATA spare parts
282146200151	ROLLER BEARING	TATA spare parts
282146200152	HOUSING LH	TATA spare parts
282146200153	SECTOR SHAFT ASSY	TATA spare parts
282146200156	SIDE COVER	TATA spare parts
282146200157	SEAL KIT -SIDE COVER	TATA spare parts
282146200158	BOLT -M12X1.75X110	TATA spare parts
282146200161	O RING(S/C SPIGOT)	TATA spare parts
282146200162	MAJOR SEAL KIT	TATA spare parts
282146203201	ADJUSTING SCREW	TATA spare parts
282146206502	LOCK NUT	TATA spare parts
282146207802	OIL SEAL	TATA spare parts
282146208001	THREADED RETAINER	TATA spare parts
282146208601	SPACER	TATA spare parts
282146305101	PITAMAN ARM	TATA spare parts
282146305103	PITMAN ARM	TATA spare parts
282146305104	PITMAN ARM BS6-PH2	TATA spare parts
282146306004	PITMAN ARM LPT909 EX	TATA spare parts
282146400102	ASSY.STG.WHEEL WITHOUT T EMBLEM	TATA spare parts
282146600103	ASSY.DRAG LINK -RHD	TATA spare parts
282146600104	ASSY.DRAG LINK -RHD	TATA spare parts
282146600105	ASSY.DRAG LINK -RHD	TATA spare parts
282146600109	SHELL ASSY	TATA spare parts
282146600110	BRACKET ASSY	TATA spare parts
282146600111	BRACKET ASSY RESERVOIR MTG	TATA spare parts
282146600112	STEERING GEAR BOX ASSY	TATA spare parts
282146600113	POWER STEERING PUMP ASSY	TATA spare parts
282146600114	KIT-INPUT SHAFT SEAL	TATA spare parts
282146600115	VALVE HOUSING ASSY	TATA spare parts
282146600116	WORM RACK ASSY -RH	TATA spare parts
282146600117	KIT-POPPET VALVE	TATA spare parts
282146600118	KIT-SEAL	TATA spare parts
282146600119	SECTOR SHAFT ASSY	TATA spare parts

282146600120	KIT-SEAL	TATA spare parts
282146600121	KIT-MAJOR SEAL	TATA spare parts
282146600122	KIT-MAJOR SEAL	TATA spare parts
282146600124	KIT-HOUSING ASSY	TATA spare parts
282146600125	SHAFT ASSY	TATA spare parts
282146600126	KIT-CARTRIDGE ASSY	TATA spare parts
282146600127	KIT-SEAL	TATA spare parts
282146600132	STEERING GEAR BOX ASSY	TATA spare parts
282146600135	POWER STEERING PUMP ASSY BS6-PH2	TATA spare parts
282146603001	BALL RETURN GUIDE	TATA spare parts
282146603201	BOLT BS6	TATA spare parts
282146603701	HOUSING	TATA spare parts
282146604701	SIDE COVER	TATA spare parts
282146604801	DOWEL PIN	TATA spare parts
282146605501	HUB	TATA spare parts
282146606501	NUT 1/2IN UNF	TATA spare parts
282146606802	CONNECTOR SUCTION PORT	TATA spare parts
282146607701	O-RING	TATA spare parts
282146608001	ADJUSTING SCREW	TATA spare parts
282146700102	BRACKET ASSY POWER STG GEAR BOX	TATA spare parts
282146700104	BELLOW PLATE ASSY BS6-PH2	TATA spare parts
282146800101	ASSY. PIPE (RESERVOIR TO PUMP)	TATA spare parts
282146800102	ASSY. PIPE (PUMP TO GEAR BOX)	TATA spare parts
282146800103	ASSY. PIPE (GEAR BOX TO RESERVOIR)	TATA spare parts
282146800105	RESEVOIER ASSEMBLY	TATA spare parts
282146800106	POWER STEERING PUMP ASSEMBLY	TATA spare parts
282146800107	ASSY.PIPE (RES. TANK TO PUMP)	TATA spare parts
282146800108	ASSY. PIPE (PUMP TO GEAR BOX)	TATA spare parts
282146800109	ASSY. PIPE (GEAR BOX TO RES. TANK)	TATA spare parts
282146800111	BANJO ASSY(M16X1.5)	TATA spare parts
282146800115	ASSY PIPE (RES. TANK TO PUMP)	TATA spare parts
282146800116	ASSY PIPE (PUMP TO GEAR BOX)	TATA spare parts
282146800117	ASSY PIPE (GEAR BOX TO RES. TANK)	TATA spare parts
282146800121	ASSY.SUCTION LINE-CRIMPED(TANK TO PUMP)	TATA spare parts
282146800123	ASSY. SUCTION LINE-CRIMPED (TANK TO PUMP	TATA spare parts
282146800125	ASSY RETURN LINE-CRIMPED (GEAR BOX TO TA	TATA spare parts
282146800126	ASSY SUCTION LINE-CRIMPED (RESERVOIR TO	TATA spare parts
282146800127	ASSY.PIPE (PUMP TO GEAR BOX)	TATA spare parts
282146800131	ASSY PRESSURE PIPE (PUMP TO GEAR BOX)	TATA spare parts
282146800132	ASSY SUCTION LINE (RESERVIOR TO PUMP)	TATA spare parts
282146800133	ASSY RETURN LINE (GEAR BOX TO RESERVIOR)	TATA spare parts
282146800135	ASSY SUCTION PIPE	TATA spare parts
282146800142	ASSY. PIPE (PUMP TO GEAR BOX)	TATA spare parts
282146800143	ASSY.PIPE RETURN LINE(G.B TO RES.TANK)	TATA spare parts
282146800144	ASSY.SUCTION LINE-CRIMPED(TANK TO PUMP)	TATA spare parts
282146800145	BANJO BOLT M18X1.5	TATA spare parts
282146800147	HOUSING ASSEMBLY KIT	TATA spare parts

282146800148	SHAFT SUB ASSY	TATA spare parts
282146800149	RETAINING RING (INT)	TATA spare parts
282146800150	HUB	TATA spare parts
282146800151	CARTRIDGE ASSEMBLY KIT	TATA spare parts
282146800152	SEAL KIT	TATA spare parts
282146800153	SPRING	TATA spare parts
282146800154	RETAINING WASHER	TATA spare parts
282146800155	DOWEL PIN	TATA spare parts
282146800156	BOLT	TATA spare parts
282146800157	O RING (PR.PORT CONNECTOR)	TATA spare parts
282146800158	PRESSURE PORT CONNECTOR	TATA spare parts
282146800159	O RING (SUCTION CONNECTOR)	TATA spare parts
282146800160	SUCTION PORT CONNECTOR	TATA spare parts
282146800161	SPRING WASHER	TATA spare parts
282146800162	ALLEN HEAD SCREW	TATA spare parts
282146800167	ASSY PIPE SUCTION LINE	TATA spare parts
282146800168	ASSY PIPE PRESSURE LINE	TATA spare parts
282146800169	ASSY PIPE RETURN LINE	TATA spare parts
282146800186	SUCTION LINE ASSY	TATA spare parts
282146800187	PRESSURE LINE ASSY	TATA spare parts
282146800188	RETURN LINE ASSY	TATA spare parts
282146800201	SUCTION LINE ASSY	TATA spare parts
282146800202	SUCTION LINE ASSY BS6-PH2	TATA spare parts
282146800203	HIGH PRESSURE LINE ASSY BS6-PH2	TATA spare parts
282146800204	RTN LINE ASSY GR BOX TO INT JOINT BS6-PH	TATA spare parts
282146800205	RTN LINE ASSY INT JOINT TO RESERVOIR BS6	TATA spare parts
282146810101	PRESSURE LINE ASSY	TATA spare parts
282146810102	RETURN LINE ASSY	TATA spare parts
282146810103	SUCTION LINE ASSY	TATA spare parts
282146810104	PRESSURE LINE ASSY BS6	TATA spare parts
282146810105	PRESSURE LINE ASSY BS6	TATA spare parts
282146810106	RETURN LINE ASSY BS6	TATA spare parts
282146810107	SUCTION LINE ASSY BS6	TATA spare parts
282146810110	PRESSURE LINE ASSY BS6	TATA spare parts
282146810111	SUCTION LINE ASSY BS6	TATA spare parts
282146810116	SUCTION LINE ASSY BS6-PH2	TATA spare parts
282146810117	RETURN LINE ASSY BS6-PH2	TATA spare parts
282146810118	RETURN LINE ASSY BS6-PH2	TATA spare parts
282146810119	HIGH PRESSURE LINE ASSY BS6-PH2	TATA spare parts
282146810120	SUCTION LINE ASSY BS6-PH2	TATA spare parts
282146900104	DRAG LINK ASSY	TATA spare parts
282146900108	BALL JOINT ASSY BS6-PH2	TATA spare parts
282146900112	DRAG LINK ASSY	TATA spare parts
282146900116	DRAG LINK ASSY BS6-PH2	TATA spare parts
282146990104	KIT-POWER STEERING SYSTEM 3001	TATA spare parts
282147000101	ASSY.FUEL TANK COMP.WITH STRAP & SUPPORT	TATA spare parts
282147000103	FUEL TANK ASSY	TATA spare parts

282147000104	FUEL TANK ASSY WITH STRAP	TATA spare parts
282147000106	FUEL TANK ASSY BS6	TATA spare parts
282147000110	ASSY FUEL TANK COMP WITH MTG BKT	TATA spare parts
282147000113	ASSY FUEL TANK COMPLETE	TATA spare parts
282147100101	ASSY.FUEL TANK COMPLETE - 160 LTR	TATA spare parts
282147100103	ASSY.SUCTION TUBE - 160 LTR	TATA spare parts
282147100109	ASSY.CAP WITH LOCK	TATA spare parts
282147100134	FUEL TANK ASSY BS6-PH2	TATA spare parts
282147109901	CNG CYLINDER	TATA spare parts
282147109902	CNG CYLINDER	TATA spare parts
282147109903	CNG CYLINDER	TATA spare parts
282147109904	CNG CYLINDER	TATA spare parts
282147109911	CYLINDER BS6	TATA spare parts
282147109912	CNG CYLINDER	TATA spare parts
282147109925	CYLINDER BS6	TATA spare parts
282147500102	BRACKET ASSY CYLINDER MTG BS6	TATA spare parts
282147500103	BRACKET ASSY WITH RUBBER	TATA spare parts
282147500104	BRACKET ASSY FUEL TANK MTG	TATA spare parts
282147500107	ASSY STRUCTURE CNG CYL.MTG.(FRONT)	TATA spare parts
282147500109	ASSY STRUCTURE CNG CYL.MTG.(REAR)	TATA spare parts
282147500120	SPACER ASSY BS6	TATA spare parts
282147500132	ASSY. STRAP (WITH RUBBER PACKING)	TATA spare parts
282147500137	ASSY.STRUCTURE CNG CYL.MTG.(FRONT)	TATA spare parts
282147500138	ASSY.STRUCTURE CNG CYL.MTG.(REAR MTG)	TATA spare parts
282147500149	ASSY.GUARD(REGULATOR)	TATA spare parts
282147500154	ASSY.SUPPORT	TATA spare parts
282147500155	ASSY.GUARD (CYLINDER VALVE)	TATA spare parts
282147500158	ASSY. BRACKET	TATA spare parts
282147500161	ASSY. BRACKET (UNIT MTG.)	TATA spare parts
282147500162	ASSY.SINGLE CLAMP WITH BRACKET	TATA spare parts
282147500163	ASSY.SUPPORT	TATA spare parts
282147500164	ASSY. ARRESTOR	TATA spare parts
282147500165	ASSY.BRACKET -LH (END STOPPER)	TATA spare parts
282147500166	ASSY.BRACKET -RH (END STOPPER)	TATA spare parts
282147500169	ASSY. HPR & SOLENOID MOUNTING BKT.	TATA spare parts
282147500185	ARRESTOR ASSY REAR BS6	TATA spare parts
282147503201	`U` BOLT	TATA spare parts
282147507607	TIE MEMBER (FRONT MTG)	TATA spare parts
282147507608	TIE MEMBER	TATA spare parts
282147507702	BALATA PACKING	TATA spare parts
282147507704	RUBBER PACKING	TATA spare parts
282147507706	GROMMET	TATA spare parts
282147508218	GUARD	TATA spare parts
282147508266	BRACKET (HP FILTER MTG.)	TATA spare parts
282147508288	TOP COVER(UNIT MTG.)	TATA spare parts
282147508289	COMPLIANCE PLATE	TATA spare parts
282147509201	TAB WASHER	TATA spare parts

282147510102	STONE GUARD ASSY CYLINDER VALVE BS6-PH2	TATA spare parts
282147510103	HEAT SHIELD ASSY LH BS6-PH2	TATA spare parts
282147518201	COMPLIANCE PLATE	TATA spare parts
282147518247	COVER TOP BS6-PH2	TATA spare parts
282147600101	LP HOSE - 3/4 ID	TATA spare parts
282147600109	ASSY RETURN LINE (FIP TO LONG MEMBER-LH)	TATA spare parts
282147600110	ASSY.SUCTION LINE(F.TANK-W/SEP)	TATA spare parts
282147600111	ASSY SUCTION LINE(W.SEP-ENGINE)	TATA spare parts
282147600112	ASSY.RETURN LINE (ENGINE-F.TANK)	TATA spare parts
282147600113	ASSY RETURN LINE (LONG MEMBER- FUEL TANK	TATA spare parts
282147600114	ASSY. BRACKET (WATER SEPARATOR AND STAIN	TATA spare parts
282147600115	SUCTION LINE FUEL TANK TO PROTECT FILTER	TATA spare parts
282147600116	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
282147600118	ASSY SUCTION LINE (FUEL TANK TO W/SEP)	TATA spare parts
282147600119	ASSY RETURN LINE (ENGINE TO FUEL TANK)	TATA spare parts
282147600122	ASSY.FUEL LINE SUCTION (TANK TO STRAINER	TATA spare parts
282147600124	ASSY. FUEL LINE (WATER SEPARATOR TO ENGI	TATA spare parts
282147600125	ASSY. FUEL LINE (TANK TO STRAINER)	TATA spare parts
282147600126	ASSY. FUEL LINE (STRINER TO WATER SEPARA	TATA spare parts
282147600127	ASSY. RETURN LINE(ENGINE TO FUEL TANK)	TATA spare parts
282147600129	ASSY.SUCTION LINE(STRAINER TO MECH.FEED	TATA spare parts
282147600141	ASSY. RETURN LINE(ENGINE TO TANK)	TATA spare parts
282147600147	VENT PIPE ASSY	TATA spare parts
282147600148	HP PIPE ASSY FRT LH CYL TO FRT RH CYL BS	TATA spare parts
282147600160	HP PIPE ASSY FRT LH CYL TO FRONT RH CYL	TATA spare parts
282147600161	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
282147600162	FUEL RETURN PIPE ASSY BS6	TATA spare parts
282147600164	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
282147600168	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
282147600169	HP PIPE ASSY BS6	TATA spare parts
282147600170	HP PIPE ASSY BS6	TATA spare parts
282147600171	HP PIPE ASSY BS6	TATA spare parts
282147600172	ASSY. SOLENOID VALVE MTG. BKT.	TATA spare parts
282147600175	VENT PIPE ASSY BS6	TATA spare parts
282147600176	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
282147600178	ASSLY.SUCTION LINE(FUEL TANK TO STRAINER	TATA spare parts
282147600179	ASSLY SUCTION LINE(STRAINER TO MECH. FEE	TATA spare parts
282147600182	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
282147600183	ASSLY. P-CLAMP	TATA spare parts
282147600195	FUEL SUCTION LINE ASSY TANK TO B. FILTER	TATA spare parts
282147600196	RETURN LINE ASSY ENGINE TO FUEL TANK	TATA spare parts
282147600197	SUCTION FUEL PIPE ASSY	TATA spare parts
282147600198	FUEL SUCTION PIPE ASSY	TATA spare parts
282147600199	FUEL SUCTION PIPE ASSY	TATA spare parts
282147603304	BRACKET	TATA spare parts
282147603307	BRACKET BS6	TATA spare parts
282147603308	BRACKET BS6	TATA spare parts

282147605802	HOSE COOLANT LINE (PR REGULATOR TO RADIA	TATA spare parts
282147605803	HOSE COOLANT LINE (PR REGULATOR TO ENG U	TATA spare parts
282147606801	CONNECTOR ( HOSE TO STEPPER MOTOR)	TATA spare parts
282147608205	BRACKET BS6	TATA spare parts
282147608215	BRACKET STRAINER MOUNTING	TATA spare parts
282147608229	BRACKET MAIN FILTER	TATA spare parts
282147608230	BRACKET PROTECT FILTER	TATA spare parts
282147610101	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
282147610124	SUCTION FUEL PIPE ASSY	TATA spare parts
282147610125	SUCTION FUEL PIPE ASSY	TATA spare parts
282147610126	SUCTION FUEL PIPE ASSY	TATA spare parts
282147610127	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
282147610128	BRACKET ASSY	TATA spare parts
282147610140	HP PIPE ASSY BS6	TATA spare parts
282147610141	HP PIPE ASSY BS6	TATA spare parts
282147610142	HP PIPE ASSY FILLING UNIT TO FUEL FILTER	TATA spare parts
282147610149	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
282147610152	FUEL RETURN PIPE ASSY BS6	TATA spare parts
282147610153	FUEL RETURN PIPE ASSY BS6	TATA spare parts
282147610163	HP PIPE ASSY BS6	TATA spare parts
282147610164	HP PIPE ASSY BS6	TATA spare parts
282147610166	HP PIPE ASSY BS6	TATA spare parts
282147610167	HP PIPE ASSY BS6	TATA spare parts
282147610168	HP PIPE ASSY BS6	TATA spare parts
282147610169	HP PIPE ASSY BS6	TATA spare parts
282147610170	HP PIPE ASSY BS6	TATA spare parts
282147610171	HP PIPE ASSY BS6	TATA spare parts
282147610172	VENT PIPE ASSY BS6	TATA spare parts
282147610173	VENT PIPE ASSY BS6	TATA spare parts
282147610174	VENT PIPE ASSY BS6	TATA spare parts
282147610175	HP PIPE ASSY BS6	TATA spare parts
282147610176	VENT PIPE ASSY BS6	TATA spare parts
282147610177	HP PIPE ASSY BS6	TATA spare parts
282147610178	HP PIPE ASSY BS6	TATA spare parts
282147610180	HP PIPE ASSY BS6	TATA spare parts
282147610181	VENT PIPE ASSY BS6	TATA spare parts
282147610182	VENT PIPE ASSY BS6	TATA spare parts
282147610183	VENT PIPE ASSY BS6	TATA spare parts
282147610185	HP PIPE ASSY BS6	TATA spare parts
282147620109	VENT PIPE ASSY BS6	TATA spare parts
282147620113	VENT PIPE ASSY BS6	TATA spare parts
282147620114	VENT PIPE ASSY BS6	TATA spare parts
282147620121	HP PIPE ASSY BS6-PH2	TATA spare parts
282147620143	HP PIPE ASSY BS6-PH2	TATA spare parts
282147620146	HP PIPE ASSY BS6-PH2	TATA spare parts
282147620152	VENT PIPE ASSY BS6-PH2	TATA spare parts
282147620156	VENT PIPE ASSY BS6-PH2	TATA spare parts



282147620157	HP PIPE ASSY BS6-PH2	TATA spare parts
282147620159	VENT PIPE ASSY BS6-PH2	TATA spare parts
282147620160	VENT PIPE ASSY BS6-PH2	TATA spare parts
282147630164	HP PIPE ASSY BS6-PH2	TATA spare parts
282147630165	HP PIPE ASSY BS6-PH2	TATA spare parts
282147630166	HP PIPE ASSY BS6-PH2	TATA spare parts
282147630167	HP PIPE ASSY BS6-PH2	TATA spare parts
282147630168	VENT PIPE ASSY BS6-PH2	TATA spare parts
282147630169	VENT TUBE ASSY BS6-PH2	TATA spare parts
282147630176	HP PIPE ASSY BS6-PH2	TATA spare parts
282147630178	HP PIPE ASSY BS6-PH2	TATA spare parts
282147630179	VENT PIPE ASSY BS6-PH2	TATA spare parts
282147630180	VENT PIPE ASSY BS6-PH2	TATA spare parts
282147630181	VENT PIPE ASSY BS6-PH2	TATA spare parts
282147630182	VENT PIPE ASSY BS6-PH2	TATA spare parts
282147640102	HP PIPE ASSY BS6-PH2	TATA spare parts
282147640111	HP PIPE ASSY FRONT RH CYL TO BACK RH CYL	TATA spare parts
282147640112	VENT PIPE ASSY BS6-PH2	TATA spare parts
282147640116	VENT PIPE ASSY BS6-PH2	TATA spare parts
282147640117	VENT PIPE ASSY BS6-PH2	TATA spare parts
282147640118	VENT PIPE ASSY BS6-PH2	TATA spare parts
282147640120	HP PIPE ASSY BS6-PH2	TATA spare parts
282147640126	HP PIPE ASSY BACK RH CYL TO FRONT RH CYL	TATA spare parts
282147640128	HP PIPE ASSY BACK LH CYL TO FRONT LH CYL	TATA spare parts
282147640129	VENT TUBE ASSY BS6-PH2	TATA spare parts
282147700103	INTEGRATED FILLING UNIT ASSY BS6	TATA spare parts
282147700104	INTEGRATED FILLING UNIT ASSY BS6	TATA spare parts
282147703305	BRACKET BS6	TATA spare parts
282147800104	VENT PIPE ASSY BS6	TATA spare parts
282147800115	ASSY.HP PIPE-3(3 WAY VALVE-FRONT RH CYL)	TATA spare parts
282147800116	HP PIPE ASSY	TATA spare parts
282147800117	ASSY.HP PIPE-1(3 WAY VALVE-FRONT RH CYL)	TATA spare parts
282147800118	ASSY.HP PIPE-1(HP SOLENOID-PR REGULATOR)	TATA spare parts
282147800119	ASSY.HP PIPE(3 WAY VALVE TO HP FILTER)	TATA spare parts
282147800120	ASSY.HP PIPE(SLOW FILL.RECEP.TO 3 WAY)	TATA spare parts
282147800121	ASSY.HP PIPE(FAST FILLING .RECP.-3 WAY)	TATA spare parts
282147800122	ASSY.HP PIPE(HP GAUGE-3 WAY VALVE)	TATA spare parts
282147800123	ASSY VENT TUBE	TATA spare parts
282147800125	ASSY VENT TUBE	TATA spare parts
282147800126	ASSY VENT TUBE	TATA spare parts
282147800127	ASSY.HP PIPE2(FRONT RH CYL-FRONT LH CYL)	TATA spare parts
282147800128	ASSY.HP PIPE1(FRONT RH CYL-FRONT LH CYL)	TATA spare parts
282147800129	ASSY.HP PIPE-1(FRONT RH-REAR RH CYL)	TATA spare parts
282147800135	ASSY VENT TUBE	TATA spare parts
282147800137	ASSY VENT TUBE	TATA spare parts
282147800139	ASSY VENT TUBE	TATA spare parts
282147800141	ASSY VENT TUBE	TATA spare parts

282147800148	ASSY.HP PIPE-2(HP SOLENOID-PR REGULATOR)	TATA spare parts
282147800149	ASSY VENT TUBE	TATA spare parts
282147800150	ASSY.VENT PIPE	TATA spare parts
282147800151	ASSY.HP CNG PIPE(HP FILTER TO SOLENOID)	TATA spare parts
282147800152	ASSY.HP PIPE(REAR RH TO REAR LH CYL)	TATA spare parts
282147800153	ASSY.HP PIPE-2(FRONT RH TO RH REAR CYL)	TATA spare parts
282147800154	ASSY VENTING PIPE-2(LH FRONT TO LH REAR)	TATA spare parts
282147800157	ASSY HP PIPE	TATA spare parts
282147800159	ASSY HP PIPE	TATA spare parts
282147800161	ASSY H P PIPE	TATA spare parts
282147800163	ASSY HP PIPE	TATA spare parts
282147800165	ASSY HP PIPE	TATA spare parts
282147800166	ASSY. HP PIPE	TATA spare parts
282147800167	ASSY H.P.PIPE	TATA spare parts
282147800168	ASSY VENTING PIPE	TATA spare parts
282147800169	ASSY VENTING PIPE	TATA spare parts
282147800170	ASSY VENTING PIPE	TATA spare parts
282147800172	ASSY VENTING PIPE	TATA spare parts
282147800173	VENT PIPE ASSY BS6	TATA spare parts
282147800174	VENT PIPE ASSY BS6	TATA spare parts
282147800175	ASSY VENTING PIPE	TATA spare parts
282147800176	ASSY VENTING PIPE	TATA spare parts
282147800177	ASSY VENTING PIPE	TATA spare parts
282147800178	ASSY VENTING PIPE	TATA spare parts
282147800179	ASSY VENTING PIPE	TATA spare parts
282147800180	ASSY.VENTING PIPE	TATA spare parts
282147800183	ASSY.VENTING PIPE WITH PRESSURE CAP (L.H	TATA spare parts
282147800184	ASSY VENTING PIPE WITH PRESSURE CAP (R.H	TATA spare parts
282147800185	ASSY VENTING PIPE-2 (RH VENT-1 TO VENT-3	TATA spare parts
282147800186	ASSY VENT PIPE-3 (RH VENT-2 TO VENT-4)	TATA spare parts
282147800187	ASSY VENT PIPE-5 (RH FRONT CYL TO VENT-4	TATA spare parts
282147800188	ASSY RH VENT PIPE-4 (RH VENT-3 TO RH REA	TATA spare parts
282147800190	ASSY HP PIPE-1 (HP SOLENOID TO SENSOR)	TATA spare parts
282147800191	ASSY HP PIPE (SENSOR TO SOLENOID)	TATA spare parts
282147800192	ASSY HP PIPE (SOLENOID OUTLET TO REGULA	TATA spare parts
282147800193	ASSY VENTING PIPE-1 (HPR TO RH REAR)	TATA spare parts
282147800194	ASSY VENTING PIPE-1 (HPR TO RH REAR)	TATA spare parts
282147800195	HP PIPE ASSY FILLING RECP TO 3-WAY VALVE	TATA spare parts
282147800196	VENT CAP BS6	TATA spare parts
282149100101	ASSY. SILENCER (WITH TAILPIPE)	TATA spare parts
282149100102	ASSY. SILENCETR (WITH TAILPIPE)	TATA spare parts
282149100105	SILENCER ASSY WITH TAIL PIPE	TATA spare parts
282149100106	SILENCER ASSY WITH TAIL PIPE	TATA spare parts
282149100108	PIPE ASSY DPS SENSOR	TATA spare parts
282149100109	PIPE ASSY DPS SENSOR	TATA spare parts
282149100111	BRACKET ASSY DOC POC MTG	TATA spare parts
282149100117	BRACKET ASSY EGP MTG REAR BS6-PH2	TATA spare parts

282149100119	BRACKET ASSY-HEAT SHIELD MTG BS6	TATA spare parts
282149100120	BRACKET ASSY CATCON MTG BS6-PH2	TATA spare parts
282149100122	TUBE ASSY BS6	TATA spare parts
282149100123	TUBE ASSY BS6-PH2	TATA spare parts
282149103302	BRACKET	TATA spare parts
282149103311	BRACKET DPS SENSOR MTG BS6-PH2	TATA spare parts
282149103312	BRACKET DPS SENSOR PIPE MTG BS6-PH2	TATA spare parts
282149104201	CLAMP DOC POC	TATA spare parts
282149105801	HOSE PIPE	TATA spare parts
282149105802	HOSE PIPE	TATA spare parts
282149200102	ASSY.PLATE WITH HOOK(SILENCER MTG.)	TATA spare parts
282149200103	ASSY.PLATE WITH HOOK	TATA spare parts
282149200104	ASSY.BRACKET (SILENCER MTG.TOP)	TATA spare parts
282149200105	EXHAUST PIPE ASSY INT	TATA spare parts
282149200106	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
282149200107	ASSY.MOUNTING STRAP (HOOK TYPE MTG.)	TATA spare parts
282149200108	BRACKET ASSY BS6	TATA spare parts
282149200114	EXHAUST PIPE ASSY WITH FLEX JOINT FRONT	TATA spare parts
282149200116	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
282149200117	ASSY.MOUNTING STRAP (NT6 SILENCER)	TATA spare parts
282149200119	ASSY MOUNTING STRAP(SILENCER MTG.)	TATA spare parts
282149200121	ASSY.MOUNTING STRAP (CATCON MTG.)	TATA spare parts
282149200123	ASSY. FRONT EXHAUST PIPE (WITH FLEX. BEL	TATA spare parts
282149200124	ASSY.SILENCER (CIRCULAR)	TATA spare parts
282149200132	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
282149200133	BRACKET ASSY UREA TANK MTG BS6	TATA spare parts
282149200134	BRACKET ASSY UREA TANK MTG LH BS6	TATA spare parts
282149200135	BRACKET&ASSY&UREA&TANK&MTG&RH BS6	TATA spare parts
282149200138	BRACKET ASSY UREA TANK MTG BS6	TATA spare parts
282149200140	BRACKET&ASSY UREA&TANK&MTG LH&- BS6	TATA spare parts
282149200142	ASSY.FRONT EXHAUST PIPE	TATA spare parts
282149200143	ASSY.PLATE WITH HOOK	TATA spare parts
282149200147	BRACKET&ASSY UREA&TANK&MTG RH&- BS6	TATA spare parts
282149200149	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
282149200150	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
282149200152	EXHAUST PIPE ASSY WITH FLEX JOINT FRONT	TATA spare parts
282149200153	EXHAUST PIPE ASSY WITH HEAT SHIELD FRONT	TATA spare parts
282149200160	ASSY.FRONT EXHAUST PIPE	TATA spare parts
282149200162	ASSY.STRAP (SILENCER MTG)	TATA spare parts
282149200163	ASSY.INTERMEDIATE PIPE WITH BOSS	TATA spare parts
282149200167	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
282149200168	PIPE ASSY DPS SENSOR INTAKE	TATA spare parts
282149200169	PIPE ASSY DPS SENSOR	TATA spare parts
282149200173	EXHAUST ASSY FRONT	TATA spare parts
282149200175	EXHAUST PIPE ASSY WITH BELLOW	TATA spare parts
282149200176	EXT PIPE ASSY WITH HEAT SHIELD FRT BS6-P	TATA spare parts
282149200186	BRACKET ASSY BS6	TATA spare parts

282149203301	BRACKET	TATA spare parts
282149203317	BRACKET EGP MTG BS6-PH2	TATA spare parts
282149203319	BRACKET BS6-PH2	TATA spare parts
282149204206	MOUNTING STRAP (CATCON MTG.)	TATA spare parts
282149204207	CLAMP DOC POC	TATA spare parts
282149205801	HOSE DPS SENSOR PRE CATCON	TATA spare parts
282149205802	HOSE DPS SENSOR	TATA spare parts
282149206918	EXHAUST PIPE	TATA spare parts
282149206946	EXHAUST TAIL PIPE BS6-PH2	TATA spare parts
282149207102	PLATE BRACKET (EXHAUST MTG)	TATA spare parts
282149207501	GROMMET BS6	TATA spare parts
282149208203	PLATE	TATA spare parts
282149208207	CLAMP EXHAUST PIPE MTG BS6-PH2	TATA spare parts
282149208297	BRACKET	TATA spare parts
282149210101	ASSY. EXHAUST FRONT PIPE.	TATA spare parts
282149210102	ASSY.EXHAUST PIPE FRONT WITH FLEX.BELLOW	TATA spare parts
282149210104	ASSY.FRONT EXHAUST PIPE	TATA spare parts
282149210105	ASSY.FRONT EXHAUST PIPE	TATA spare parts
282149609901	HEAT SHIELD 1	TATA spare parts
282149609902	HEAT SHIELD 2	TATA spare parts
282149609903	HEAT SHIELD 3	TATA spare parts
282149609904	HEAT SHIELD 4	TATA spare parts
282149609905	HEAT SHIELD DOC POC	TATA spare parts
282154100102	ASSY TRAY (12V150AH BATTERY)	TATA spare parts
282154100103	ASSY.SUPPORT COMPLETE (BATTERY FITMENT)	TATA spare parts
282154100104	ASSY BATT.CABLE +VE W/COT 2.2LG 70SQ.MM	TATA spare parts
282154100105	ASSY.BATT.CABLE +VE 2.85LG W/COT-70SQ.MM	TATA spare parts
282154100106	ASSY BATT.CABLE +VE W/COT L2300MM 70SQMM	TATA spare parts
282154100108	ASSY.BAAT.CABLE +VE 0.9M 35SQ.MM	TATA spare parts
282154100109	ASSY.BATT.CABLE -VE 1.1M 35SQ.MM	TATA spare parts
282154100110	ASSY.BATT.CABLE +VE 0.230M 35SQ.MM	TATA spare parts
282154100111	ASSY.BATT.CABLE-VE 0.67M 35SQ.MM	TATA spare parts
282154100112	ASSY BATT. CABLE VE 2850MM 35SQMM	TATA spare parts
282154100113	ASSY BATT. CABLE -VE 3000MM 35SQMM	TATA spare parts
282154100115	ASSY BATTERY CABLE +VE 2000MM	TATA spare parts
282154100117	ASSY. BATTERY CUT-OFF SWITCH MTG. BKT.	TATA spare parts
282154110101	ASSY.BATT.CABLE -VE(WITH CORR.TUBE) 3LG	TATA spare parts
282154110102	ASSY.BATT.CABLE -VE(WITH CORR.TUBE)2.3LG	TATA spare parts
282154200103	INST.CLUST.1:0.85 W/APP	TATA spare parts
282154200108	ASSY.PLATE(TEMP.&PRS.IND.)LP909CNG	TATA spare parts
282154200109	ECU MOUNTING PLATE	TATA spare parts
282154200111	THERMOCOUPLE CATCON 168 DIA LPO909 CNG	TATA spare parts
282154200112	ASSY EARTHING CHAIN WITH MTG BKT	TATA spare parts
282154200114	TEMP.IND.CATCON (12_24V) LP 909 CNG.	TATA spare parts
282154200116	INSTRU.CLUSTER (1:0.85)	TATA spare parts
282154200120	INST.CLUSTER 0.85 LP909CNG BSIV	TATA spare parts
282154200127	INSTRUMENT CLUSTER ASSY	TATA spare parts

282154200128	INSTRUMENT CLUST LP912 0.64	TATA spare parts
282154200129	INSTRUMENT_CLUSTER_(0.76)_LP_912_BSIV	TATA spare parts
282154200131	INSTRUMENT CLUSTER 0.64 RATIO	TATA spare parts
282154200132	INST_CLUSTER_0.76_W_PTO_LPT_909_BSIV	TATA spare parts
282154200133	INSTRUEMNT_CLUSTER_1:0.90_LP912_BSIV	TATA spare parts
282154200138	INSTRUMENT CLUSTER	TATA spare parts
282154200143	INSTRUMENT CLUSTER ELEC-SPEEDO 0.76	TATA spare parts
282154200147	INSTRUMENT CLUSTER ASSY	TATA spare parts
282154200148	INSTRUMENT CLUSTER ASSY	TATA spare parts
282154200155	INSTRUMENT CLUSTER ASSY BS6	TATA spare parts
282154200158	INSTRUMENT CLUSTER ASSY	TATA spare parts
282154201604	INST.CLUSTER.ELE.-0.85-LP909 CNG	TATA spare parts
282154201606	INST_CLUSTER_1:0.85_LP909_CNG_BSIV	TATA spare parts
282154208203	L.R.ECU SUPPORT BRACKET-LP909 CNG	TATA spare parts
282154208204	HARNESS SUPPORT CLAMP	TATA spare parts
282154208205	BRACKET (SIDE BLINKER MTG)	TATA spare parts
282154209901	SPEEDOMETER 1:0.72-6+1 DIGIT	TATA spare parts
282154209902	SPEEDOMETER 1:0.72-6+1 DIGIT	TATA spare parts
282154209903	SPEEDOMETER 1:0.72-6+1 DIGIT	TATA spare parts
282154209904	SPEEDOMETER 1:0.72-6+1 DIGIT	TATA spare parts
282154209905	SPEEDOMETER 1:0.585 BACKLIT	TATA spare parts
282154209909	INST.CLUST.0.85 SPEEDORATIO MOVEMENT	TATA spare parts
282154209910	GILL IGNITER	TATA spare parts
282154209911	EMS ECU 497 CNG BS-IV HARDWA	TATA spare parts
282154209912	SPEEDOMETER 1:0.90	TATA spare parts
282154209915	ECU-560 3.8SGI OBD-II M/S WESTPORT HARDW	TATA spare parts
282154209918	ECU EMS 580 FOR 3.8 SGI ENG. BS4	TATA spare parts
282154300101	INST_CLUSTER_0.76_LPT909H BSIII	TATA spare parts
282154300104	INSTRUMENT CLUSTER ASSY	TATA spare parts
282154309901	FUEL GAUGE ASSY & AIR PR.(RE)GAUGE	TATA spare parts
282154309906	TEMP GAUGE ASSY &AIR PR.GAUGE	TATA spare parts
282154409901	ASSY BULB HOLDER FOR H1 LAMP	TATA spare parts
282154500102	ASSY.COMBINATION SWITCH	TATA spare parts
282154500105	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
282154500108	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
282154501601	HAZARD WARNING SWITCH BS6	TATA spare parts
282154501602	SWITCH FRONT FOG LAMP BS6	TATA spare parts
282154501603	SWITCH REAR FOG LAMP BS6	TATA spare parts
282154509903	PIANO KEY SW.(BLANK)	TATA spare parts
282154509907	PIANO KEY SW.(EXHAUST BR.ON)W/O CONNECTOR	TATA spare parts
282154509908	PIANO KEY SW.(ENGINE LAMP)W/O CONNECTOR	TATA spare parts
282154509909	PIANO KEY SW.(PTO) W/O CONNECTOR	TATA spare parts
282154509910	PIANO KEY SW.(FRONT FOG LAMP)W/O CONNECTOR	TATA spare parts
282154509911	PIANO KEY SW.(AXIAL PISTON PUMP)W/O CONNECTOR	TATA spare parts
282154509912	PIANO KEY SW.(ABS) W/O CONNECTOR	TATA spare parts
282154509913	PIANO KEY SW.(BATTERY CUT OFF)	TATA spare parts
282154509914	PIANO KEY SW.(3 TERMINAL FOG LAMP)	TATA spare parts

282154600106	W/H MAIN LPK407/909 EX	TATA spare parts
282154600109	W/H MAIN LPT 909H EX2	TATA spare parts
282154600110	LOW AIR PR.SENSOR PIGTAIL	TATA spare parts
282154600136	PIGTAIL - CLUSTER	TATA spare parts
282154600137	WIRING HARNESS MAIN	TATA spare parts
282154600156	W/H MAIN	TATA spare parts
282154600163	WIRING HARNESS TAIL	TATA spare parts
282154600166	BATTERY CABLE -VE	TATA spare parts
282154600167	BATTERY CABLE -VE	TATA spare parts
282154600172	WIRING HARNESS MAXI FUSE	TATA spare parts
282154600175	BATTERY CABLE +VE MEGA FUSE	TATA spare parts
282154600184	WIRING HARNESS SWITCH	TATA spare parts
282154600187	WIRING HARNESS ABS FRAME	TATA spare parts
282154600189	WIRING HARNESS TAIL	TATA spare parts
282154600191	WIRING HARNESS MAIN	TATA spare parts
282154600194	WIRING HARNESS MAXI FUSE	TATA spare parts
282154600195	WIRING HARNESS MAXI FUSE	TATA spare parts
282154600197	WIRING HARNESS TAIL	TATA spare parts
282154600198	WIRING HARNESS TAIL	TATA spare parts
282154601602	W/H MAIN LP909 EX/49 WB RHD BUS	TATA spare parts
282154601604	W/H MAIN OFFER LP912/49WB BS-III BUS	TATA spare parts
282154601605	W/H ENGINE (LP912/49WB BS-III BUS)	TATA spare parts
282154601607	W/H.ENGINE-LP909CNG-BSIII	TATA spare parts
282154601609	W/H.EMS-497CNG-BSIII	TATA spare parts
282154601610	W /H MAIN LP 909 CNG BS IV	TATA spare parts
282154601611	W/H MAIN (BASE VEHICLE) LPO909 CNG	TATA spare parts
282154601614	W/H TAIL (BASE) LP 909 CNG	TATA spare parts
282154601626	W/H MAIN LP912/49WB WITH BSIII IMPROVEME	TATA spare parts
282154601630	W/H_MAIN_LPT407/909_EX2_CNG_BSIV	TATA spare parts
282154601635	W/H MAIN LP/LPT407/909/709 EX CNG BSIV	TATA spare parts
282154601637	W/H TAIL FOR LP909 CNG BSIV 49WB WITH	TATA spare parts
282154601640	WIRING HARNESS TAIL	TATA spare parts
282154601641	W/H ENGINE FOR LP/LPT407/909 CNG BSIV	TATA spare parts
282154601642	WIRING HARNESS TAIL	TATA spare parts
282154601643	W/H MAIN LP407/909 CNG BSIV	TATA spare parts
282154601644	WIRING HARNESS SWITCH	TATA spare parts
282154601645	W/H MAXI FUSE FOR LP407/909 CNG BSIV	TATA spare parts
282154601646	W/H ENGINE FOR LP407/909 CNG BSIV MARCOP	TATA spare parts
282154603306	BRACKET INTERFACE CONNECTOR MTG BS6	TATA spare parts
282154603307	BRACKET INTERFACE CONNECTOR MTG BS6-PH2	TATA spare parts
282154603308	BRACKET INTERFACE CONNECTOR MTG BS6	TATA spare parts
282154608202	BRACKET FOR MAXI FUSE AND MIDI FUSE MTG.	TATA spare parts
282154609901	BATTERY -VE TERMINAL ASSY	TATA spare parts
282154610107	WIRING HARNESS MAIN	TATA spare parts
282154610108	WIRING HARNESS MAIN	TATA spare parts
282154610110	WIRING HARNESS MAIN	TATA spare parts
282154610112	WIRING HARNESS MAIN	TATA spare parts

282154610113	WIRING HARNESS TAIL	TATA spare parts
282154610124	WIRING HARNESS TAIL	TATA spare parts
282154610145	WIRING HARNESS MAIN	TATA spare parts
282154610146	WIRING HARNESS MAIN	TATA spare parts
282154610147	WIRING HARNESS MAIN	TATA spare parts
282154610158	BATTERY CABLE +VE	TATA spare parts
282154610159	BATTERY CABLE +VE BS6	TATA spare parts
282154610160	BATTERY CABLE -VE BS6	TATA spare parts
282154610165	WIRING HARNESS-TAIL BS6	TATA spare parts
282154610166	WIRING HARNESS ABS FRAME(52WB) (55135460	TATA spare parts
282154610169	WIRING HARNESS TAIL BS6	TATA spare parts
282154610170	WIRING HARNESS MAIN BS6	TATA spare parts
282154610171	WIRING HARNESS TAIL BS6	TATA spare parts
282154610176	BATTERY CABLE +VE BS6	TATA spare parts
282154610178	BATTERY CABLE +VE BS6	TATA spare parts
282154610182	WIRING HARNESS PIGTAIL BS6	TATA spare parts
282154610183	WIRING HARNESS TAIL BS6	TATA spare parts
282154610184	WIRING HARNESS TAIL BS6	TATA spare parts
282154610185	BATTERY CABLE +VE BS6	TATA spare parts
282154610186	WIRING HARNESS TAIL BS6	TATA spare parts
282154610188	WIRING HARNESS TAIL BS6	TATA spare parts
282154610189	WIRING HARNESS MAIN BS6	TATA spare parts
282154610190	WIRING HARNESS TAIL BS6	TATA spare parts
282154610192	WIRING HARNESS SENSOR BS6	TATA spare parts
282154610194	WIRING HARNESS MAXI FUSE	TATA spare parts
282154610195	WIRING HARNESS TAIL BS6	TATA spare parts
282154610201	WIRING HARNESS INSTRUMENT PANEL BS6-PH2	TATA spare parts
282154611611	WIRING HARNESS MAXI FUSE	TATA spare parts
282154611624	WIRING HARNESS TAIL	TATA spare parts
282154611626	BATTERY CABLE +VE	TATA spare parts
282154611635	WIRING HARNESS TAIL 38 WB	TATA spare parts
282154611637	W/H MAIN	TATA spare parts
282154611639	WIRING HARNESS TAIL 34 WB	TATA spare parts
282154611640	BATTERY CABLE -VE	TATA spare parts
282154611642	W/H TAIL LP912/49WB MARCOPOLO-OFFER	TATA spare parts
282154611647	WIRING HARNESS SWITCH	TATA spare parts
282154611653	BATTERY CABLE +VE	TATA spare parts
282154611654	WIRING HARNESS MAIN	TATA spare parts
282154611655	WIRING HARNESS TAIL	TATA spare parts
282154611658	WIRING HARNESS TAIL	TATA spare parts
282154611660	WIRING HARNESS MAIN	TATA spare parts
282154611662	WIRING HARNESS TAIL	TATA spare parts
282154611666	WIRING HARNESS TAIL	TATA spare parts
282154611668	WIRING HARNESS MAXI FUSE	TATA spare parts
282154611671	WIRING HARNESS TAIL	TATA spare parts
282154611673	WIRING HARNESS MAIN	TATA spare parts
282154611675	WIRING HARNESS MAIN	TATA spare parts

282154611676	WIRING HARNESS ENGINE	TATA spare parts
282154611677	WIRING HARNESS TAIL	TATA spare parts
282154620101	W/H TAIL LP909 EX/49WB RHD BUS	TATA spare parts
282154620102	W/H MAIN LP909 EX/49WB RHD BUS	TATA spare parts
282154620104	W/H MAIN (LP912/49WB BS-III BUS)	TATA spare parts
282154620105	W/H ENGINE (LP912/49 BS-III BUS)	TATA spare parts
282154620108	W/H MAIN LP912/49WB BSIII MARCOPOLO	TATA spare parts
282154620109	W/H TAIL LP912/49WB MARCOPOLO	TATA spare parts
282154620110	W/H ENGINE LP912/49WB MARCOPOLO	TATA spare parts
282154620111	W/H MAIN LP912 BSIII MARCO	TATA spare parts
282154620116	W/H EMS LP 909 CNG BS-IV WITH REAR	TATA spare parts
282154620120	W/H MAIN LP912/49WB WITH BSIII IMPROVEME	TATA spare parts
282154620124	W/H TAIL LP912/49	TATA spare parts
282154620150	WIRING HARNESS TAIL LP912/49WB BS-IV	TATA spare parts
282154620159	WIRING HARNESS MAIN	TATA spare parts
282154620161	BATTERY CABLE +VE BS6	TATA spare parts
282154620167	WIRING HARNESS MAIN BS6	TATA spare parts
282154620168	BATTERY CABLE -VE BS6	TATA spare parts
282154620170	WIRING HARNESS ENGINE BS6	TATA spare parts
282154620177	PIGTAIL WIRING HARNESS	TATA spare parts
282154620185	WIRING HARNESS ABS BS6	TATA spare parts
282154620187	WIRING HARNESS EMS BS6	TATA spare parts
282154620189	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
282154620195	WIRING HARNESS TAIL BS6	TATA spare parts
282154630103	WIRING HARNESS TAIL BS6	TATA spare parts
282154630104	WIRING HARNESS ABS BS6	TATA spare parts
282154630106	WIRING HARNESS TAIL BS6	TATA spare parts
282154630107	WIRING HARNESS TAIL BS6	TATA spare parts
282154630114	WIRING HARNESS-MAIN BS6	TATA spare parts
282154630115	WIRING HARNESS MAIN BS6	TATA spare parts
282154630123	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
282154630128	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
282154630133	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
282154630154	WIRING HARNESS FRONT CHASSIS BS6-PH2	TATA spare parts
282154630163	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
282154630171	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
282154630174	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
282154630175	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
282154630179	WIRING HARNESS FRONT CHASSIS BS6-PH2	TATA spare parts
282154630180	WIRING HARNESS ESC BS6-PH2	TATA spare parts
282154630181	WIRING HARNESS SENSOR BS6	TATA spare parts
282154630184	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
282154630186	WIRING HARNESS ESC BS6-PH2	TATA spare parts
282154640101	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
282154640104	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
282154640105	BATTERY CABLE -VE BS6-PH2	TATA spare parts
282154640110	WIRING HARNESS ABS BS6-PH2	TATA spare parts



282154640116	WIRING HARNESS MAIN	TATA spare parts
282154640118	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
282154640139	W/H TAIL LP912/49WB MARCOPOLO-MSSL	TATA spare parts
282154640141	WIRING HARNESS ENGINE	TATA spare parts
282154640143	WIRING HARNESS MAIN	TATA spare parts
282154640144	WIRING HARNESS LOW AIR PRESS.TRANSDUCER	TATA spare parts
282154640146	W/H MAIN LPT909H EX2 BSIII_ WITH CAT-6	TATA spare parts
282154660102	W/H MAIN LP909 RHD BUS	TATA spare parts
282154660103	W/H TAIL (LP912/49WB BS-III BUS)	TATA spare parts
282154660104	W/H MAIN (LP912/49WB BS-III BUS)	TATA spare parts
282154660105	W/H ENGINE (LP912/49 BS-III BUS)	TATA spare parts
282154660117	W/H MAIN LP912/49WB WITH BSIII IMPROVEME	TATA spare parts
282154660138	WH MAIN LP/LPT407/909EX CNG BSIV	TATA spare parts
282154660139	WIRING HARNESS MAIN	TATA spare parts
282154660141	WH MAIN LP407/909 CNG BSIV	TATA spare parts
282154660142	WIRING HARNESS HEAD LAMP & BLINKER	TATA spare parts
282154660144	WIRING HARNESS MAIN	TATA spare parts
282154660145	WIRING HARNESS MAIN (CAT-6) WITH EOBD II	TATA spare parts
282154660146	WIRING HARNESS TAIL WITH EOBD II	TATA spare parts
282154660147	WIRING HARNESS TAIL	TATA spare parts
282154660148	W/H TAIL WITH EOBD II LP909	TATA spare parts
282154660149	W/H TAIL WITH EOBD II LPT909	TATA spare parts
282154660150	W/H TAIL LP909 49WB CNG BSIV MARCOPOLO	TATA spare parts
282154660151	W/H MAIN LP407/909 CNG BSIV MARCO POLO	TATA spare parts
282154670187	W/H TAIL LP912/49WB MARCOPOLO-TYA	TATA spare parts
282154700105	BRACKET ASSY VEHICLE TRACKING ASSY MTGBS	TATA spare parts
282154800101	BRACKET ASSY ABS ECU MTG	TATA spare parts
282154800105	PLATE ASSY ABS ECU MTG	TATA spare parts
282154903301	BRACKET LAMBADA SENSOR MTG BS6	TATA spare parts
282158408206	LABEL - AIS140 12V 5-7.5M	TATA spare parts
282158408207	LABEL - AIS140 12V 8-9.4M	TATA spare parts
282158408208	LABEL - AIS140 24V 8-9.4M	TATA spare parts
282158408209	LABEL - AIS140 12V 10.1-11.5M	TATA spare parts
282158408210	LABEL - AIS140 24V 10.1-11.5M	TATA spare parts
282158900102	ASSY. SCREW JACK WITH HANDLE	TATA spare parts
282158900104	ASSY.SCREW JACK(5T)	TATA spare parts
282158900110	ASSY. SCREW JACK( 5T) WITH HANDLE	TATA spare parts
282158900112	KIT-TOOLS BS6 PH2	TATA spare parts
282158900601	ADAPTER CHECKING ENGINE COMPRESSION BS6	TATA spare parts
282158901502	PULLER / CIGAR COIL / 909	TATA spare parts
282158902601	CIRCLIP PLIER / FRONT & REAR HALF / GB 5	TATA spare parts
282158902602	570 SQ MTG PLATE / GB / LPT 912	TATA spare parts
282158902603	KIT / REMOVE & DROPP INNER GUT / LPT 912	TATA spare parts
282158902604	PULLER/REMOVE FR. HALF O-RACE BRG/LPT912	TATA spare parts
282158902605	PULLER/R-5TH & REV. ENGAGING GR /LPT 912	TATA spare parts
282158902606	PULLER / REMOVE REAR HALF HSG / GB 550	TATA spare parts
282158903701	STAND / GB / G400 G550 / LPT 912	TATA spare parts

282158904601	8 PIN SPANNER / THREAD RETAINER / V.STRG	TATA spare parts
282158990101	KIT-AIS 140 12V 5-7.5M	TATA spare parts
282158990102	KIT-AIS 140 12V 8-9.4M	TATA spare parts
282158990103	KIT-AIS 140 24V 8-9.4M	TATA spare parts
282158990104	KIT-AIS 140 12V 10.1-11.5M	TATA spare parts
28216000005R40	ASSEMBLY BODY FITTED	TATA spare parts
28216000010R40	ASSEMBLY BODY FITTED	TATA spare parts
28216000010R40AWBL	CAB PARTIALLY FITTED LPT 909 AW BL	TATA spare parts
28216000011R40	ASSY. CABIN KIT W/O W/H & STRG LPK912BS4	TATA spare parts
28216000011R40BRBL	CAB PARTIALLY FITTED LPK912 BR BLW	TATA spare parts
28216000011R40RRBL	CAB PARTIALLY FITTED LPK912 RR BLW	TATA spare parts
28216000016R40	PARTIALLY FITTED CAB W/O ELECTRICALS	TATA spare parts
28216000037R40	ASSEMBLY BODY FITTED	TATA spare parts
28216000048R40	ASSEMBLY BODY FITTED BS6	TATA spare parts
28216000057R40	ASSEMBLY BODY FITTED	TATA spare parts
28216000096R40	PARTIALLY FITTED CAB W/O ELECTRICALS BS6	TATA spare parts
28216000098R40	PARTIAL FITTED CAB LPT 1109G BS6	TATA spare parts
28216000109R40	PARTIAL FITTED CABIN 1109G LPT BS6	TATA spare parts
28216000175R40	1012 LPT DCR34HSD 125B6M5_CAB/COWL BS6	TATA spare parts
28216000178R40	PARTIAL FITTED CAB LPK912 EX/27WB BS6	TATA spare parts
28216000178R40BRBL	CAB PARTIALLY FITTED LPK 912 BR BLW	TATA spare parts
28216000179R40	1012 LPT DCR38CBC 125 B6M5_CAB/COWL BS6	TATA spare parts
28216000225R40	CAB PARTIALLY FITTED LPT 1012 LPT CAB/CO	TATA spare parts
282160CK0198	CAB LPT909EX2 BSIV/38 CAB W PTO OBDII SP	TATA spare parts
282160CK0199	ASSY. CABIN KIT LPT909EX2 CLB TCAB BS2/3	TATA spare parts
28216100014R40	PARTIAL FITTED CABIN 1009G LPT BS6	TATA spare parts
282170150101	SUPD ASSY LH BS6-PH2	TATA spare parts
282170150102	SUPD ASSY RH BS6-PH2	TATA spare parts
282182900101	KIT-WASHERSYSTEM BS6	TATA spare parts
282182900102	KIT-WASHER SYSTEM BS6	TATA spare parts
28219638000R40	PARTIAL FITTED CABIN	TATA spare parts
28219638000RLD29	LPT 909/38 CNG BS4_HDLB	TATA spare parts
2821A9Z0170003	LOAD BODY ASSY BS6-PH2	TATA spare parts
2821D1A1860001	FES STRUCTURE BS6-PH2	TATA spare parts
2821D1A1860002	FES STRUCTURE BS6-PH2	TATA spare parts
2821D9Z0160003	FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2821D9Z0160013	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2821H9X0233002	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
2821H9X0233004	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
2821H9X0233005	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
2821H9X0233006	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
2821H9X0233007	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
2821H9X0233008	FRONT AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
2821H9X0233009	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
2821H9X0233016	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
282215400103	ALTERNATOR 12V 120A 6 GROOVE PULLEY	TATA spare parts
282215400104	RECTIFIER ASSY	TATA spare parts

282215407001	PULLEY	TATA spare parts
282231000101	ASSY. FRAME COMPLETE (SFC909EX BS-II)	TATA spare parts
282231000102	ASSY. FRAME SFC909EX/38 WB BS-II W/O CLE	TATA spare parts
282231000104	ASSY. FRAME COMPLETE (SFC912EX/38WB)	TATA spare parts
282231000105	ASSY.FRAME SFC912EX/BS-III W/O CLEATS	TATA spare parts
282231000106	FRAME ASSY WITH FITMENT	TATA spare parts
282231200102	ASSY CROSS MEMBER(WITH TOE HOOK)	TATA spare parts
282231700102	ASSY SUPPORT BRACKET	TATA spare parts
282231700103	ASSY.BEAM FUPD	TATA spare parts
282231700104	ASSY REINFORCEMENT BRACKET (RH)	TATA spare parts
282231700105	ASSY. REINFORCEMENT BRACKET (LH)	TATA spare parts
282231700112	ASSY BRACKET	TATA spare parts
282231700114	ASSY PIPE (LH)	TATA spare parts
282231700115	ASSY PIPE (RH)	TATA spare parts
282231700120	BRACKET ASSY RUPD MTG RH	TATA spare parts
282231700121	BRACKET ASSY RUPD MTG LH	TATA spare parts
282231703201	HEX BOLT(M10X125 12.9CLASS)	TATA spare parts
282232100101	FRONT SPRING ASSY	TATA spare parts
282232100102	ASSY FIRST LEAF WITH BUSHES	TATA spare parts
282232100104	ASSY FRONT HANGER BKT FOR FRONT SPRING	TATA spare parts
282232100105	ASSY REAR HANGER BKT FOR FRONT SPRING	TATA spare parts
282232100106	ASSY FRONT SPRING-POWER STRG.	TATA spare parts
282232103312	BRACKET SPRING HANGER FRONT-FRONT BS6	TATA spare parts
282232107102	SECOND LEAF	TATA spare parts
282232107103	THIRD LEAF	TATA spare parts
282232107104	4TH LEAF	TATA spare parts
282232107105	5TH LEAF	TATA spare parts
282232107106	6TH LEAF	TATA spare parts
282232107107	SEVENTH LEAF	TATA spare parts
282232107108	EIGHTH LEAF	TATA spare parts
282232107109	NINTH LEAF	TATA spare parts
282232107110	LOCK PLATE	TATA spare parts
282232203702	CASTOR PLATE	TATA spare parts
282233000102	ASSY FRONT AXLE WITH BRAKES	TATA spare parts
282242300102	ASSY.R/A BRAKE WITH DUST COVER LH	TATA spare parts
282242300104	ASSY.R/A BRAKE WITH DUST COVER RH	TATA spare parts
282243900103	ASSY NYLON PIPE SET CHASSIS COMPLETE	TATA spare parts
282246306001	PITMAN ARM-RHD (SFC909/EX MECH STRG.)	TATA spare parts
282246600102	ASSY.DRAG LINK-RHD	TATA spare parts
282246800101	PRESSURE LINE ASSY	TATA spare parts
282246800102	SUCTION LINE ASSY	TATA spare parts
282246900101	DRAG LINK END ASSY -RH	TATA spare parts
282247600101	SUCTION PIPE ASSY	TATA spare parts
282247600102	SUCTION PIPE ASSY	TATA spare parts
282247600103	SUCTION PIPE ASSY	TATA spare parts
282247600104	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
282249200102	HOSE PIPE ASSY DPS TO PIPE DOWN STREAM	TATA spare parts

282249200103	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
282249200104	PIPE ASSY UPSTREAM	TATA spare parts
282249600102	HEAT SHIELD ASSY EXHAUST SYSTEM	TATA spare parts
282254601603	WIRING HARNESS TAIL	TATA spare parts
282254603301	EMS SUPPORT	TATA spare parts
282254603302	BRACKET	TATA spare parts
282254603304	EMS SUPPORT	TATA spare parts
282258900101	TOOL KIT- BS6	TATA spare parts
28226000002R40	ASSEMBLY BODY FITTED	TATA spare parts
282260CK0199	CAB SFC912EX/38WB BSIII WITH HIGH DECK N	TATA spare parts
282315100101	STARTER MOTOR(1.9KW)GEAR REDUCSTION-	TATA spare parts
282331000107	ASSY FRAME VICTA DI	TATA spare parts
282331200117	ASSY TUBE GEAR BOX EXTN.MTG.	TATA spare parts
282331300101	ASSY NOISE SHEILD	TATA spare parts
282332100109	LOWER WISHBONE COMP. RH (MECH)	TATA spare parts
282332100110	LOWER WISHBONE COMP. LH	TATA spare parts
282332500101	REAR AXLE STOPPER	TATA spare parts
282333000101	ASSY. FRONT AXLE R.H.	TATA spare parts
282333000102	ASSY. FRONT AXLE L.H.	TATA spare parts
282333200101	ASSY. STUB AXLE WITH SEAL RACE R.H.	TATA spare parts
282333200102	ASSY. STUB AXLE WITH SEAL RACE L.H.	TATA spare parts
282333205101	STUB AXLE RH	TATA spare parts
282333205104	STUB AXLE LH	TATA spare parts
282333400101	ASSY. HUB WITH BRAKE DISC (FRONT)	TATA spare parts
282333400102	SUB ASSY. FRT HUB WITH WHEEL MTG. PIN	TATA spare parts
282333403701	HUB (FRONT)	TATA spare parts
282340100101	ASSY.WHEELRIM COVER	TATA spare parts
282342300103	ASSY.REAR BRAKE LH LIN.-AUTO ADJ	TATA spare parts
282342300104	ASSY.REAR BRAKE RH2873 LIN.-AUTO ADJ	TATA spare parts
282342300105	ASSY.REAR BRAKE LH2873 LIN.-AUTO ADJ	TATA spare parts
282342300106	ASSY.REAR BRAKE RH2873 LIN.-AUTO ADJ	TATA spare parts
282342300107	REAR BRK.ASY.AUTO.ADJ.LH TVS2873MGG-	TATA spare parts
282342300108	REAR BRK.ASY.AUTO ADJ.RH TVS2873MGG-	TATA spare parts
282342300113	AUTO ADJ.ASSY.LH	TATA spare parts
282342300114	AUTO ADJ.ASSY.-RH	TATA spare parts
282342300115	KIT ASSY.AUTO ADJUSTER	TATA spare parts
282342300116	KIT - SHOE HOLD DOWN	TATA spare parts
282342300119	WHEEL CYLINDER KIT (MAJOR)	TATA spare parts
282342300120	WHEEL CYLINDER KIT (MINOR)	TATA spare parts
282342300121	KIT - LINED SHOE	TATA spare parts
282342300122	KIT - LINER (STD) LH	TATA spare parts
282342300131	BACK PLATE ASSY RLH (Sumo Gold)	TATA spare parts
282342300132	BACK PLATE ASSY RRH (Sumo Gold)	TATA spare parts
282342300133	PUSH ROD ASSEMBLY -LH	TATA spare parts
282342300134	PUSH ROD ASSEMBLY -RH	TATA spare parts
282342300135	WHEEL CYLINDER ASSY	TATA spare parts
282342303301	ADJ. LEVER LH	TATA spare parts

282342303302	ADJ. LEVER RH	TATA spare parts
282342306001	LEVER PAWL ¿LH	TATA spare parts
282342306002	LEVER PAWL ¿RH	TATA spare parts
282342307803	DUST CAP	TATA spare parts
282342308005	SCREW	TATA spare parts
282342308006	BLEED SCREW	TATA spare parts
282342308008	BLEED SCREW	TATA spare parts
282342308701	SHOE RETURN SPRING UPPER	TATA spare parts
282342308702	SHOE RETURN SPRING LOWER	TATA spare parts
282342308705	SPRING (Sumo Gold)	TATA spare parts
282342308706	SPRING (Sumo Gold)	TATA spare parts
282342308707	SPRING (Sumo Gold)	TATA spare parts
282342309903	PLUG SHOE INSP.HOLE (Sumo Gold)	TATA spare parts
282342309904	GROMMET - COLLAPSING HOLE	TATA spare parts
282342800115	ASSY. TUBE	TATA spare parts
282342800116	BRAKE PIPE ASSY,T-CONN TO BRAKE,REAR-LH	TATA spare parts
282342803201	BOLT (BRAKE DISC)	TATA spare parts
282346000103	ASY.P/STRG GEAR BOX RHD	TATA spare parts
282346200121	STRG COLUMN ASM WITH I-SHAFT ASM	TATA spare parts
282346200126	ASSY. BRACKET(BALL JOINT MTG. POWER STG)	TATA spare parts
282346203102	SPHERICAL SUPPORT STG. SPINDLE	TATA spare parts
282346203201	HEX BOLT M10X130-IS1364P1-10.9	TATA spare parts
282346203309	SUPPORT STG. SPINDLE SPH. JOINT	TATA spare parts
282346206301	BUSH	TATA spare parts
282346206302	COVER (STG. U/J)	TATA spare parts
282346207702	RUBBER BELLOW (BOTTOM)	TATA spare parts
282346208303	SHIM 1 THK	TATA spare parts
282346300101	ASSY.IDLER ARM WITH BUSH (P/STG.)	TATA spare parts
282346300102	ASSY.IDLER ARM WITH BUSH (M/STG.)	TATA spare parts
282346300103	ASSY.IDLER ARM WITH BRACKET RHD (P/STG.)	TATA spare parts
282346300104	ASSY.IDLER ARM WITH BRACKET RHD (M/STG.)	TATA spare parts
282346306001	PITMAN ARM POWER STEERING-RHD	TATA spare parts
282346306003	PITMAN ARM MECHANICAL STEERING-RHD	TATA spare parts
282346400103	ASSY. STEERING WHEEL (M/S EMDET)	TATA spare parts
282346600102	ASSY. TIE ROD	TATA spare parts
282346600104	ASSY. TIE ROD	TATA spare parts
282346600110	ASSY. TIE ROD	TATA spare parts
282346600112	ASSY.PAS PUMP	TATA spare parts
282346600124	ASSY.TIE ROD	TATA spare parts
282346600126	ASSY.STG.RESERVOIR COMP.	TATA spare parts
282346600131	REPAIR KIT MAJOR FOR STG. GEARBOX 0103	TATA spare parts
282346600132	MINOR PART KITS FOR STG. GEARBOX 0103	TATA spare parts
282346600133	HOUSING ASSEMBLY	TATA spare parts
282346600134	VALVE HOUSING ASSEMBLY FOR STG GEARBOX 0	TATA spare parts
282346600135	INPUT SHAFT AND WORM SHAFT ASSEMBLY FOR	TATA spare parts
282346600136	SCREW CAP ASSEMBLY FOR STG GEARBOX 0103	TATA spare parts
282346600137	PISTON ASSEMBLY FOR STG GEARBOX 0103	TATA spare parts

282346600138	SECTOR SHAFT ASSEMBLY FOR STG GEARBOX 01	TATA spare parts
282346600139	HOUSING COVER ASSEMBLY FOR STG GEARBOX 0	TATA spare parts
282346600140	WORM SHAFT & VALVE ASSY.FOR STG GEARBOX	TATA spare parts
282346600141	WORM SHAFT & PISTON ASSY FOR STG GEARBOX	TATA spare parts
282346600142	SECTOR SHAFT & VALVE ASSY FOR STG GEARBO	TATA spare parts
282346600148	REPAIR KIT FOR STRG RESERVOIR 0126	TATA spare parts
282346600151	ASSY. TIE ROD	TATA spare parts
282346609202	HARDEN WASHER 13	TATA spare parts
282346609203	HARDEN WASHER 10.5	TATA spare parts
282346800102	ASSY.HOSE STG.TANK TO PUMP	TATA spare parts
282347100108	ASSY. FUEL FILLING TUBE (INTERMEDIATE)	TATA spare parts
282347100115	ASSY.FUEL TANK (COMPLETE)	TATA spare parts
282347107703	HOSE (FUEL FILLING-FILLER NECK SIDE)	TATA spare parts
282347107705	HOSE (FUEL FILLING TANK SIDE)	TATA spare parts
282354100101	MAXI FUSE CLAMPING BRACKET	TATA spare parts
282354200130	ASSY.TANK UNIT 65LTRS	TATA spare parts
282354209903	FUSE PULLER -M/S.MSSL	TATA spare parts
282354209928	RELAY 12V 20A .	TATA spare parts
282354400103	ASSY.TAIL LAMP - LH - LUMAX	TATA spare parts
282354400104	ASSY.TAIL LAMP - RH	TATA spare parts
282354400113	ASSY.FRONT FOG LAMP LHS.	TATA spare parts
282354400114	ASSY.FRONT FOG LAMP RH-.	TATA spare parts
282354400115	ASSY. REAR FOG LAMP RH	TATA spare parts
282354400116	ASSY.REAR FOG LAMP LH	TATA spare parts
282354400117	SIDE REPEATER LAMP	TATA spare parts
282354400119	ASSY.SIDE REPEATER LAMP(CLEAR LENS)	TATA spare parts
282354400127	SIDE REPEATER LAMP	TATA spare parts
282354400128	HEAD LAMP(W/GEN-3 MTR & 6P)LH RHD	TATA spare parts
282354400129	HEAD LAMP(W/GEN-3 MTR & 6P)RH RHD	TATA spare parts
282354400132	REGISTRATION PLATE LAMP	TATA spare parts
282354406306	TAIL LAMP TOP MTG.KNOB	TATA spare parts
282354500102	KIT FICIA SWITCHES	TATA spare parts
282354500104	ASSY.PANEL ILLU+H/L LEV.SW. COVER PLATE	TATA spare parts
282354500125	ASSY. H/L LEVELING SW COVER PLATE	TATA spare parts
282354506301	FACIA SW.COVER PLATE	TATA spare parts
282354506305	FACIA SW.COVER PLATE W/CUTOOUT(CENTRE CO)	TATA spare parts
282354509902	SWITCH FRONT FOG LAMP	TATA spare parts
282354509904	SWITCH FOR REAR FOG LAMP -	TATA spare parts
282354509906	SWITCH FOR HEATED REAR WINDOW -	TATA spare parts
282354509908	SWITCH FOR REAR WASHER -	TATA spare parts
282354509910	SWITCH FOR REAR WIPER -	TATA spare parts
282354509914	DOOR SWITCH TAIL WITH 2 POLE CONN-	TATA spare parts
282354509917	H/L LEVELLING SW.	TATA spare parts
282354509918	FLASHER	TATA spare parts
282354509923	HEAD LAMP LEVELLING SW.(VERTICAL)	TATA spare parts
282354600104	WIRING HARNESS FRONT DOOR LH	TATA spare parts
282354600105	WIRING HARNESS FRONT DOOR RH	TATA spare parts

282354600106	WIRING HARNESS REAR DOOR LH	TATA spare parts
282354600107	WIRING HARNESS REAR DOOR RH	TATA spare parts
282354600123	WIRING HARNESS TAIL GATE	TATA spare parts
282354600151	WIRING HARNESS HVAC CABIN	TATA spare parts
282354700101	FICD KIT	TATA spare parts
282354700104	ASSY.4 SPEED BLOWER RESISTER-.	TATA spare parts
282354700105	ASSY.BLOWER MOTOR RHD	TATA spare parts
282354700106	ASSY.THERMOAMPLIFIER W/THERMISTER-	TATA spare parts
282354700112	ASSY CONDENSOR FAN FOR HVAC .	TATA spare parts
282354709903	FRESH RECIRCULATION MOTOR	TATA spare parts
282354909904	FOLLOWER ACTUATOR ASSY	TATA spare parts
282358405001	BAG FOR TOOL KIT & JACK HANDLE	TATA spare parts
282358604001	WING SCREW -M8	TATA spare parts
282360010140	BODY SHELL VICTA DI EX ICR W/O DOORS	TATA spare parts
282360010146	BODY SHELL SUMO VICTA DI GX TC ICR W/O	TATA spare parts
282360020109	BODY SHELL SUMO GOLD GX BS4 W/O DOORS	TATA spare parts
282360100107	DASHBOARD CROSS MEMBER COMPLETE RHD	TATA spare parts
282360100109	ASSY.REAR CROSS MEMBER COMPLETE	TATA spare parts
282360100111	ASSY.STAY TUBE	TATA spare parts
282360100119	TIE MEMBER COMPLETE (NA ENGINE)	TATA spare parts
282360100135	ASSY.LID LH (CABLE OPERATED FUEL LID)	TATA spare parts
282360100152	ASSY.TIE MEMBER COMPLETE-VICTA DI BS4	TATA spare parts
282360600109	ASSY.MUDGUARD WITH REINFORCEMENT COMP.	TATA spare parts
282363100107	TAILGATE POST LH	TATA spare parts
282363100108	ASSY TAILGATE POST RH	TATA spare parts
282363100109	ASSY.BRACKET (REAR CORNER BUMPER MTG.)	TATA spare parts
282363100120	ASSY.HOUSING LH (FUEL FILLER LID)	TATA spare parts
282363108210	SIDE PANEL OUTER RR LH WITH FUEL CUTOUT	TATA spare parts
282363108211	SIDE PANEL OUTER RR RH W/O FUEL CUTOUT	TATA spare parts
282363600170	ASSY.SIDE PNL.WITH CORNER PNL.COMPLT.LH	TATA spare parts
282363600171	ASSY.SIDE PNL.WITH CORNER PNL.COMPLT.RH	TATA spare parts
282368800116A3	EBONY_1-KIT INSULATION CARPET(DI BS4)	TATA spare parts
282368800117A3	EBONY_1-INSULATION CARPET FRONT FLOOR-BS	TATA spare parts
282368800118A3	EBONY_1-INSULATION CARPET REAR FLOOR	TATA spare parts
282368800119A3	INSULATION CARPET REAR W/ARCH LH	TATA spare parts
282368800120A3	INSULATION CARPET REAR W/ARCH RH	TATA spare parts
282368806317	MOULDED INSULATION FIRE WALL ENGINE SIDE	TATA spare parts
282368900126ZZ	ASSY.DASHBOARD COMP.WITH DUCTING-DI BS4	TATA spare parts
282368900127ZZ	ASSY.CENTRE CONSOLE-FARRARRI SILVER-BS4	TATA spare parts
282368906362A8	BEZEL INSTRUMENT CLUSTER BOTTOM-DI BS4	TATA spare parts
282368906366A3	NACELLE BOTTOM-DI BS4	TATA spare parts
282368906367A3	NACELLE TOP-DI BS4	TATA spare parts
282368906392A3	EBONY_1-FLOOR CONSOLE -DI BS4	TATA spare parts
282369100101	ASSY CAP (ROOF A/C SIDE TRIM MTG)	TATA spare parts
282369106317AQ	LINEN-TRIM FRONT POST LH	TATA spare parts
282369106318AQ	LINEN-TRIM FRONT POST RH	TATA spare parts
282369106319AQ	LINEN-TRIM `B` PILLAR LH	TATA spare parts

282369106320AQ	LINEN-TRIM `B` PILLAR RH	TATA spare parts
282369106321AQ	LINEN-TRIM `C` PILLAR LH	TATA spare parts
282369106322AQ	LINEN-TRIM `C` PILLAR RH	TATA spare parts
282369106323AQ	LINEN-REAR QTR.TRIM LH	TATA spare parts
282369106324AQ	LINEN-REAR QTR.TRIM RH	TATA spare parts
282369509902AQ	LINEN-PIN-PILLAR TRIMS	TATA spare parts
282372200115	ASSY FRONT DOOR SHELL LH	TATA spare parts
282372200116	ASSY FRONT DOOR SHELL RH	TATA spare parts
282372300108	ASSY HINGE COMP.BOTTOM FRONT DOOR LH	TATA spare parts
282372300109	ASSY HINGE COMP.BOTTOM FRONT DOOR RH	TATA spare parts
282372300114	ASSY INNER HANDLE FR.DOOR LH	TATA spare parts
282372300115	ASSY INNER HANDLE FR.DOOR RH	TATA spare parts
282372300116	ASSY HINGE TOP COMPLETE LH (FRONT DOOR)	TATA spare parts
282372300117	ASSY HINGE TOP COMPLETE RH (FRONT DOOR)	TATA spare parts
282372300121	ASSY OUTER HANDLE COMP.LH	TATA spare parts
282372300122	ASSY OUTER HANDLE COMP.RH	TATA spare parts
282372300126	KIT FOR LOCKS W/O FUEL LID LOCK	TATA spare parts
282372300126A8	MD_GRAFITE_1-KIT FOR LOCKS W/O FUEL LID	TATA spare parts
282372300127A8	MD_GRAFITE_1-ASSY.KIT FOR LOCK W/O FUEL	TATA spare parts
282372300130A3	EBONY_1-ASSY.INNER HANDLE LH-DI BS4	TATA spare parts
282372300131A3	EBONY_1-ASSY.INNER HANDLE RH-DI BS4	TATA spare parts
282372500103	ASSY.GLASS HOLDER LH (FRONT DOOR)	TATA spare parts
282372500104	ASSY.GLASS HOLDER RH (FRONT DOOR)	TATA spare parts
282372506301	BEADING (DOOR GLASS HOLDER)	TATA spare parts
282372700105	ASSY DOOR PULL	TATA spare parts
282372700119	ASSY GRAB HANDLE (DOOR)	TATA spare parts
282372700123	ASSY.FRONT DOOR TRIM LH-GX VICTA DI BS4	TATA spare parts
282372700124	ASSY.FRONT DOOR TRIM RH-GX VICTA DI BS4	TATA spare parts
282372700125	ASSY.FRONT DOOR TRIM LH-EX VICTA DI BS4	TATA spare parts
282372700126	ASSY.FRONT DOOR TRIM RH-EX VICTA DI BS4	TATA spare parts
282372706301A3	EBONY_1-HOUSING INNER HANDLE-VICTA DI BS	TATA spare parts
282372708201	BRACKET LH-FRONT DOOR WITH POWER WINDOW	TATA spare parts
282372708202	BRACKET RH-FRONT DOOR WITH POWER WINDOW	TATA spare parts
282373200103	ASSY REAR DOOR SHELL LH	TATA spare parts
282373200111	ASSY REAR DOOR SHELL LH	TATA spare parts
282373200112	ASSY REAR DOOR SHELL RH	TATA spare parts
282373300108	ASSY HINGE REAR COMP LH (BOTTOM) RR DOOR	TATA spare parts
282373300109	ASSY HINGE REAR COMP RH(BOTTOM) RR DOOR	TATA spare parts
282373300116	ASSY INNER HANDLE REAR DOOR LH	TATA spare parts
282373300117	ASSY INNER HANDLE REAR DOOR RH	TATA spare parts
282373300118	ASSY HINGE TOP COMPLETE LH (REAR DOOR)	TATA spare parts
282373300119	ASSY HINGE TOP COMPLETE RH (REAR DOOR)	TATA spare parts
282373300121A3	EBONY_1-ASSY.INNER HANDLE RR DOOR LH-DI	TATA spare parts
282373300122A3	EBONY_1-ASSY.INNER HANDLE RR DOOR RH-DI	TATA spare parts
282373500103	ASSY.POWER WINDOW REGULATOR LH	TATA spare parts
282373500104	ASSY.POWER WINDOW REGULATOR RH	TATA spare parts
282373500107	ASSY.GLASS HOLDER LH (REAR DOOR)	TATA spare parts



282373500108	ASSY.GLASS HOLDER RH (REAR DOOR)	TATA spare parts
282373700109	ASSY.REAR DOOR TRIM LH-GX DI BS4	TATA spare parts
282373700110	ASSY.REAR DOOR TRIM RH-GX DI BS4	TATA spare parts
282373700111	ASSY.REAR DOOR TRIM LH-EX DI BS4	TATA spare parts
282373700112	ASSY.REAR DOOR TRIM RH-EX DI BS4	TATA spare parts
282374200107	Assy.Tailgate Shell (Gx-lcr)	TATA spare parts
282374200108	ASSY TAILGATE SHELL	TATA spare parts
282374300101	OFFER DRG ASSY INNER HANDLE TAILGATE	TATA spare parts
282374300103A3	EBONY_1-ASSY.INNER HANDLE TAILGATE-VICTA	TATA spare parts
282374700104	ASSY.TAILGATE TRIM GX-VICTA DI BS4	TATA spare parts
282381100101	ASSY CENTER GRILL FRONT (EX)	TATA spare parts
282381100124DU	ASSY.EXTERNAL R.V.MIRROR RH	TATA spare parts
282381100125DU	ASSY.EXT R.V.MIRROR LH QUARTZ_BLACK	TATA spare parts
282381100128	ASSY.STRIP CHROME PLATED (CENTRE GRILL)	TATA spare parts
282381100139	ASSY.A.C.COVER	TATA spare parts
282381100149	ASSY.CENTRE GRILL FRONT-VICTA DI GX	TATA spare parts
282381100149BF	ARCTIC_WHITE-ASSY.CENTRE GRILL FRONT-VIC	TATA spare parts
282381100149D3	ARCTIC_SILVR-ASSY.CENTRE GRILL FRONT-VIC	TATA spare parts
282381100154AQ	ASSY.SUNVISOR COMPLT.RH	TATA spare parts
282381100155AQ	ASSY.SUNVISOR COMPLT.LH	TATA spare parts
282381100158	ASSY.INSIDE RR VIEW MIRROR-EBONY	TATA spare parts
282381100159A3	EBONY_1-ASSY.AC COVER-(DI BS4)	TATA spare parts
282381100165	ASSY SIDE FOOT STEP COMPLETE LH	TATA spare parts
282381100166	ASSY SIDE FOOT STEP COMPLETE RH	TATA spare parts
282381100167	ASSY REAR FOOT STEP COMPLETE	TATA spare parts
282381100171	ASSY.DECAL SET-SUMO GOLD	TATA spare parts
282381106310	T EMBLEM	TATA spare parts
282381106322	INSULATION FIREWALL	TATA spare parts
282381106345	MUD LINER LH (REAR WHEEL ARCH)	TATA spare parts
282381106346	MUD LINER RH (REAR WHEEL ARCH)	TATA spare parts
282381106392	COVER REAR FLOOR (SP.WHEEL ACCESS)	TATA spare parts
282381116301A3	COVER INNER LH (ORVM CABLE TYPE)	TATA spare parts
282381116302A3	COVER INNER RH (ORVM CABLE TYPE)	TATA spare parts
282381116305AQ	TAILLAMP ACCESS COVER	TATA spare parts
282381800125	ASSY.MASCOT `SUMO GOLD`	TATA spare parts
282381800126	ASSY.MASCOT `GX` - GOLD	TATA spare parts
282381800127	ASSY.MASCOT `EX` - GOLD	TATA spare parts
282382400102	ASSY.WIPER ARM WITH BLADE(DR.SIDE)	TATA spare parts
282382400109	KIT W/S WASHER SYS.FRONT & REAR	TATA spare parts
282383100107	ASSY.HVAC CONTROLS	TATA spare parts
282383106304	ELBOW DUCT SIDE RH BLOW	TATA spare parts
282383106305	ELBOW DUCT SIDE LH BLOW	TATA spare parts
282383300106	ASSY.CABLE-MODE CONTROL VICTA HVAC	TATA spare parts
282383300107	ASSY.CABLE-TEMP.CONTROL VICTA HVAC	TATA spare parts
282383400127	BLOWER UNIT ASSY.	TATA spare parts
282383400128	EVAPORATOR UNIT ASSY.	TATA spare parts
282383400129	EXPANSION VALVE HVAC/SUMO	TATA spare parts

282383400130	CABINAIRFILTER	TATA spare parts
282383400133	ASSY.HVAC UNIT COMPLETE -	TATA spare parts
282383400151	BLOWER FAN	TATA spare parts
282383400152	ASSYBLOWERMOTOR and fan	TATA spare parts
282383400154	ASSY COMP WITH RH PORT 105 DI	TATA spare parts
282383400159	CONDENSER	TATA spare parts
282383400160	ASSY.RD INLET PIPE-HVAC/ PH-II	TATA spare parts
282383400161	RD OUTLET PIPE SINGLE AC--PH-II	TATA spare parts
282383400162	ASSY TUBE LIQUID HVAC IN-VICTA DI-PH-II	TATA spare parts
282383400163	ASSY. HOSE SUCTION-HVAC/-PH-II	TATA spare parts
282383400164	ASSY. HOSE DISCHARGE-HVAC/-PH-II	TATA spare parts
282383400165	ASSYHEATERCORE & SEAL	TATA spare parts
282383400167	ASSY.RECEIVER DRIER - -PH II	TATA spare parts
282383400168	RECEIVER DRIER BOTTLE	TATA spare parts
282383400171	FAN SHROUD 14 MOTOR ASSY	TATA spare parts
282383400172	BRACKETASSYFSM condensor	TATA spare parts
282383400180	IRD CONDENSER ASSY COMPLETE	TATA spare parts
282383404201	CLAMP FOR HEATER HOSE	TATA spare parts
282383405805	HEATER HOSE (HVAC TO ENGINE)	TATA spare parts
282383405806	HEATER HOSE (ENGINE TO HVAC)	TATA spare parts
282383406301	DRAIN TUBE FOR HVAC -	TATA spare parts
282383406908	TUBE LIQUID CONDENSER OUT - VICTA DI BS	TATA spare parts
282383406910	TUBE LIQUID HVAC IN- VICTA DI BS IV DELP	TATA spare parts
282383406911	SUCTION HOSE - VICTA DI BS IV	TATA spare parts
282383406912	DISCHARGE HOSE - VICTA DI BS IV	TATA spare parts
282383407501	GROMMET FOR HEATER PIPES -	TATA spare parts
282383408209	BRKTBLOWERUNIT MTG (Firewall)	TATA spare parts
282383408210	RKTBLOWERUNIT MTG (Cross member)	TATA spare parts
282383408213	BRKT.HEATERUNITMTG	TATA spare parts
282383500101	HEATER UNIT ASSY	TATA spare parts
282383500102	ASSY.CLAMP FOR HEATER HOSE	TATA spare parts
282383500103	RUBBER HOSE (HEATER TO BY PASS)	TATA spare parts
282388100105	ASSY.BRACKET LH (BUMPER SIDE MTG)	TATA spare parts
282388100106	ASSY.BRACKET RH (BUMPER SIDE MTG)	TATA spare parts
282388100107	ASSY.BONNET SIDE COMPLETE LH	TATA spare parts
282388100108	ASSY.BONNET SIDE COMPLETE RH	TATA spare parts
282388500109	ASSY.FRONT BUMPER (BLACK)	TATA spare parts
282388506302	CAP FRONT BUMPER MTG LH	TATA spare parts
282388506303	CAP FRONT BUMPER MTG RH	TATA spare parts
282388600101	BRACKET LH (REAR CORNER BUMPER MTG)	TATA spare parts
282388600102	BRACKET RH (REAR CORNER BUMPER MTG)	TATA spare parts
282388606304	CAP UPPER (REAR CENTER BUMPER MTG)	TATA spare parts
282388606306	REAR BUMPER CORNER LH (BLACK)	TATA spare parts
282388606307	REAR BUMPER CORNER RH (BLACK)	TATA spare parts
282391000236	ASSY.DRIVER SEAT RH-GX VICTA DI BS4	TATA spare parts
282391000237	ASSY.CO-DRIVER SEAT LH-GX VICTA DI BS4	TATA spare parts
282391000238	ASSY.DRIVER SEAT RH-EX VICTA DI BS4	TATA spare parts

282391000239	ASSY.CO-DRIVER SEAT LH-EX VICTA DI BS4	TATA spare parts
282391506301A3	COVER (ELR UNIT)	TATA spare parts
282392000147	ASSY.2ND ROW SEAT-7 SEATER GX-DI BS4	TATA spare parts
282392000148	ASSY.2ND RWO SEAT-9 SEATER GX-DI BS4	TATA spare parts
282392000150	ASSY.2ND ROW SEAT-9 SEATER EX-DI BS4	TATA spare parts
282393000155	ASSY.SINGLE SEAT JUMP SEAT LH-GX-DI BS4	TATA spare parts
282393000156	ASSY.SINGLE SEAT JUMP SEAT RH-GX-DI BS4	TATA spare parts
282393000157	ASSY.TWIN SEAT JUMP SEAT LH-GX-DI BS4	TATA spare parts
282393000158	ASSY.TWIN SEAT JUMP SEAT RH-GX-DI BS4	TATA spare parts
282393000161	ASSY.TWIN SEAT JUMP SEAT LH-EX-DI BS4	TATA spare parts
282393000162	ASSY.TWIN SEAT JUMP SEAT RH-EX-DI BS4	TATA spare parts
282393506307A3	COVER INNER (ELR UNIT) REAR LH	TATA spare parts
282393506308A3	COVER INNER (ELR UNIT) REAR RH	TATA spare parts
282393506309A3	COVER OUTER (ELR UNIT) REAR LH	TATA spare parts
282393506310A3	COVER OUTER (ELR UNIT) REAR RH	TATA spare parts
282393508201	HOOK (SEAT LATCH)	TATA spare parts
282399506301	CLIP-DOOR TRIM	TATA spare parts
282543200109	ASSY.AIR TANK	TATA spare parts
282546100104	STEERING COLUMN ASSY F101400	TATA spare parts
282600000101	ASSY KIT COMPLETE 207DIRX RETRO	TATA spare parts
282615100101	STARTER MOTOR [MELCO TYPE] DOM	TATA spare parts
282615100104	C.E BRACKET ASSY	TATA spare parts
282615100105	OUTPUT SHAFT ASSY	TATA spare parts
282615100106	SWITCH ASSY	TATA spare parts
282615100107	INTERNAL GEAR ASSY	TATA spare parts
282615100108	CE BKT ASSY	TATA spare parts
282615100109	DRIVE ASSY	TATA spare parts
282615100110	ARMATURE ASSY	TATA spare parts
282615100111	PLANETARY GEAR ASSY [L-TVS-26 25 6839]	TATA spare parts
282615100112	INTERNAL GEAR ASSY	TATA spare parts
282615100113	PACKING GEAR & BEARING ASSLY KIT	TATA spare parts
282615100114	PLANETARY GEAR ASSY	TATA spare parts
282615100115	PLUNGER RETURN SPRING	TATA spare parts
282615100116	PLUNGER ASSLY	TATA spare parts
282615100118	C.E. BKT ASSLY	TATA spare parts
282615100119	BRUSH GEAR ASSLY	TATA spare parts
282615100120	ARMATURE ASSLY	TATA spare parts
282615100121	INTERNAL GEAR ASSLY	TATA spare parts
282615100122	OUTPUT SHAFT ASSLY	TATA spare parts
282615100123	DRIVE ASSLY	TATA spare parts
282615100124	FIXING BKT ASSLY	TATA spare parts
282615100125	SOLENOID SWITCH	TATA spare parts
282615100126	FASTNERS ASSEMBLY KIT	TATA spare parts
282615100127	CE BKT ASSY	TATA spare parts
282615103001	BALL	TATA spare parts
282615104301	JUMP RING	TATA spare parts
282615104401	THRUST COLLER	TATA spare parts

282615104801	DOWEL	TATA spare parts
282615106001	LEVER	TATA spare parts
282615106002	ENGAGING LEVER	TATA spare parts
282615106501	STR. TERMINAL NUT	TATA spare parts
282615107101	PIVOT PLATE	TATA spare parts
282615107201	VENT PLUG	TATA spare parts
282615107501	D.E.GROMMET	TATA spare parts
282615108001	SOLENOID FIXING SCREW	TATA spare parts
282615400111	12V 40A ALT EXT.FAN VAC 57 DIA 6-PK	TATA spare parts
282629100102	ASSY. CONTROL MTG. BRACKET COMPLETE	TATA spare parts
282629100105	ASSY.BRAKE PEDAL LEVER	TATA spare parts
282629100106	ASSY.CLUTCH PEDAL LEVER	TATA spare parts
282629103401	PIVOT BUSH	TATA spare parts
282629103402	BUSH - CLUTCH CONTROL	TATA spare parts
282630100101	DRAWING ACCELERATOR CABLE	TATA spare parts
282630100102	ASSY. BRKT- ACCELERATOR CABLE	TATA spare parts
282630108201	BRACKET (ACC. CABLE MTG. ON ENGINE)	TATA spare parts
282631000101	ASSY.FRAME 28WB (TCD REDUCTION)	TATA spare parts
282631000104	ASSY FRAME (TELCOLINE 4X2)	TATA spare parts
282631000106	ASSY. FRAME (207DI FLAT LOAD BODY)	TATA spare parts
28263100010621	ASSY FRAME 207DI FLAT L.B.(INHOUSE PAINT	TATA spare parts
28263100010622	ASSY FRAME 207DI FLAT L.B.(PARTY PAINTED	TATA spare parts
282631000107	ASSY FRAME 207DI 4X2 31WB RIGID AXLE	TATA spare parts
28263100010720	ASSY FRAME 207DI 4X2 31WB RIGID AXLE	TATA spare parts
282631000108	ASSY. FRAME COMPLETE (DICOR 2.2LTR 4X2 2	TATA spare parts
282631000110	ASSY FRAME 4X2 (SPRINT 28WB 2.2LDICOR)	TATA spare parts
282631000111	ASSY FRAME 4X2 (SPRINT 28WB 3LDICOR)	TATA spare parts
282631000113	ASSY FRAME 4X2 (SPRINT SC 31WB 2.2LDICR)	TATA spare parts
282631000116	ASSY FRAME 207DI RIGID FRONT AXLE	TATA spare parts
28263100011620	ASSY FRAME 207DI RIGID FRONT AXLE	TATA spare parts
282631000137	ASSY FRAME 207DI RX POWER STEERING	TATA spare parts
282631000139	ASSY FRM 207DI RX WIDER TRACK POWER STG.	TATA spare parts
282631000142	ASSY KIT FOR MECH STRG TO POWER STRG CON	TATA spare parts
282631200105	ASSY BRACKET (FUEL TANK MTG.)	TATA spare parts
282631200109	ASSY BRACKET L.H.(LOAD BODY MTG. MIDDLE)	TATA spare parts
282631200110	ASSY BRACKET R.H.(LOAD BODY MTG. MIDDLE)	TATA spare parts
282631200114	ASSY LOAD BODY MTG BRACKET REAR	TATA spare parts
282631200117	ASSY BRACKET RH (ENGINE MOUNTING FRONT)	TATA spare parts
282631200118	ASSY BRACKET LH (ENGINE MOUNTING FRONT)	TATA spare parts
282631200120	ASSY CROSS MEMBER FRONT	TATA spare parts
282631200126	ASSY. CAB MOUNTING BKT. (SECOND POINT)	TATA spare parts
282631200128	ASSY. CROSS MEMBER	TATA spare parts
282631200137	ASSY. BRACKET LOAD BODY MTG.	TATA spare parts
282631200138	ASSY. BRACKET BREATHER PIPE SUPPORT	TATA spare parts
282631200139	ASSY BKT R.H. LONG MEMBER EXTN.	TATA spare parts
282631200140	ASSY BKT L.H. LONG MEMBER EXTN.	TATA spare parts
282631200141	ASSY.CROSS MEMBER C.B.	TATA spare parts

282631200142	ASSY.CROSS MEMBER	TATA spare parts
282631200143	ASSY.BRACKET L/B MTG.	TATA spare parts
282631200144	ASSY.CROSS MEMBER (REAR)	TATA spare parts
282631200146	ASSY CROSS MEMBER FRONT	TATA spare parts
282631200149	ASSY BRACKET BODY MTG (RH)	TATA spare parts
282631200150	ASSY BRACKET BODY MTG LH.	TATA spare parts
282631200151	ASSY BRACKET ENGINE MTG.RH	TATA spare parts
282631200152	ASSY ENGINE MTG BRACKET LH	TATA spare parts
282631200156	ASSY CROSS MEMBER REAR	TATA spare parts
282631200157	ASSY BRACKET LOAD BODY MTG.MIDDLE LH.	TATA spare parts
282631200158	ASSY BRACKET LOAD BODY MTG.MIDDLE RH.	TATA spare parts
282631200164	ASSY. BRACKET PITMAN ARM STOPPER	TATA spare parts
282631200168	ASSY SPRING HANGER BKT REAR SHACKLE SIDE	TATA spare parts
282631200169	SUB ASSY.SPR.HANGER BKT.R.H(PIVOT END)	TATA spare parts
282631200170	SUB ASSY.SPR.HANGER BKT.L.H(PIVOT END)	TATA spare parts
282631206910	TUBE (PITMAN ARM STOPPER)	TATA spare parts
282631208279	SUPPORT BRACKET (PITMAN ARM STOPPER)	TATA spare parts
282631210109	ASSY.LOAD BODY MTG.BRKT.REAR	TATA spare parts
282631400101	ASSY TOWING HOOK FRONT	TATA spare parts
282631400105	ASSY.SPRING HANGER BRACKET FRONT RH	TATA spare parts
282631400106	ASSY.SPRING HANGER BRACKET FRONT LH.	TATA spare parts
282631700102	ASSY CROSS RUNNER (TAIL LAMP MTG)	TATA spare parts
282631700103	ASSY ADAPTER PLATE STG. BOX MTG	TATA spare parts
282631708202	FRONT SKIRT (SHEET METAL)	TATA spare parts
282632100102	ASSY FRONT SPG & RUBBER SEAT FOR FLAT LO	TATA spare parts
282632100108	ASSY SPRING HANGER BKT. FRONT	TATA spare parts
282632100111	ASSY. SHACKLE	TATA spare parts
282632100114	ASSY. FRT. SPR. PARABOLIC	TATA spare parts
282632100116	ASSY. FRT SPR. PARABOLIC	TATA spare parts
282632100117	ASSY.PARABOLIC SPRING(9.8KG/MM)	TATA spare parts
282632100118	RETROFIT. KIT FOR SUSP. & STG.PARTS(POWE	TATA spare parts
282632100119	KIT FOR SUSP. & STG.PARTS (MECH. STG.)	TATA spare parts
282632100124	SHACKLE (FRONT SPRING)	TATA spare parts
282632100126	ASSY. FRONT SPRING (9.8 KG/MM)	TATA spare parts
282632100127	SHACKLE (FRONT SPRING)	TATA spare parts
282632101601	ASSY. PARABOLIC SPRING FRONT	TATA spare parts
282632101602	ASSY LEAF SPRING FRONT	TATA spare parts
282632103502	SLEEVE	TATA spare parts
282632106701	SPRING PIN FRONT	TATA spare parts
282632106702	SPRING PIN	TATA spare parts
282632108203	CENTER PAD	TATA spare parts
282632108701	FRONT SPRING (SKY BLUE)	TATA spare parts
282632108702	FRONT SPRING (RED)	TATA spare parts
282632108703	FRONT SPRING (WHITE )	TATA spare parts
282632204202	U CLAMP	TATA spare parts
282632204203	U-CLAMP (FRONT)	TATA spare parts
282632207101	CASTER PLATE	TATA spare parts

282632207102	CASTER PLATE	TATA spare parts
282632300101	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
282632300105	FRONT SHOCK ABSORBER	TATA spare parts
282632300115	ASSY BRACKET LH (FRT. S/A MTG)	TATA spare parts
282632300116	ASSY BRACKET RH (FRT. S/A MTG)	TATA spare parts
282632300117	ASSY. BRACKET LH (LOWER S/A MTG)	TATA spare parts
282632300118	ASSY. BRACKET RH (LOWER S/A MTG)	TATA spare parts
282632300119	ASSY RUBBER BUSH WITH EYE BUSH.	TATA spare parts
282632308601	SPACER	TATA spare parts
282632400102	ASSY. REAR SPRING (PARABOLIC)	TATA spare parts
282632400102DF	LEAF SPRING ASSY REAR PARABOLIC-207DI BS	TATA spare parts
282632400103	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
282632400105	ASSY. REAR SPRING PARABOLIC	TATA spare parts
282632400113	SHACKLE ASSY	TATA spare parts
282632400116	SHACKLE ASSY	TATA spare parts
282632405101	GUIDE PLATE	TATA spare parts
282632406701	SPRING PIN	TATA spare parts
282632406702	SPRING PIN	TATA spare parts
282632407101	FIRST LEAF	TATA spare parts
282632407102	SECOND LEAF	TATA spare parts
282632407102DF	SECOND LEAF REAR PARABOLIC-207DI BS3/4	TATA spare parts
282632407103	THIRD LEAF	TATA spare parts
282632407103DF	THIRD LEAF REAR PARABOLIC-207DI BS3/4	TATA spare parts
282632407104	FOURTH LEAF	TATA spare parts
282632407104DF	FOURTH LEAF REAR PARABOLIC-207DI BS3/4	TATA spare parts
282632407105	CENTER PAD	TATA spare parts
282632407701	TIP INSERT	TATA spare parts
282632407702	TIP INSERT	TATA spare parts
282632500101	ASSY. REAR AXLE STOPPER	TATA spare parts
282632600101	ASSY. REAR SHOCK ABSORBER	TATA spare parts
282632600103	ASSY. BRACKET LH	TATA spare parts
282632600104	ASSY. BRACKET RH	TATA spare parts
282632800105	ASSY. ANTIROLL BAR COMPLETE	TATA spare parts
282632800106	ASSY. CLAMP(FRONT ARB SUPPORT)	TATA spare parts
282632800107	ASSY. CONNECTING LINK	TATA spare parts
282632800108	ASSY. ANTI ROLL BAR COMPLETE	TATA spare parts
282632804201	U CLAMP (FRONT ARB)	TATA spare parts
282632804202	U BOLT (FRONT ARB)	TATA spare parts
282632805101	CLAMP SUPPORT (FRT ARB MTG)	TATA spare parts
282632807701	BEARING BLOCK (ANTIROLL BAR)	TATA spare parts
282632807703	BEARING BLOCK BUSH (ARB)	TATA spare parts
282632807704	RUBBER BUSH (ARB END)	TATA spare parts
282632807902	FRONT ANTIROLL BAR	TATA spare parts
282632807903	FRONT ANTI ROLL BAR (DIA 30)	TATA spare parts
282632808202	WASHER (ARB TOP)	TATA spare parts
282632808212	CLAMP (FRT ARB MTG)	TATA spare parts
282632808213	CLAMP (FRONT ARB MTG)	TATA spare parts

282633000101	ASSY. FRONT AXLE	TATA spare parts
282633105102	FRONT AXLE BEAM BS1/2/3/4	TATA spare parts
282633109901	COTTER BOLT	TATA spare parts
282633200103	ASSY. STUB AXLE WITH BUSH LH	TATA spare parts
282633200104	ASSY. STUB AXLE WITH BUSH RH	TATA spare parts
282633203401	BUSH	TATA spare parts
282633206701	KING PIN NORMAL	TATA spare parts
282633206705	KING PIN REPAIR-I	TATA spare parts
282633206706	KING PIN REPAIR-II	TATA spare parts
282633206707	INTEREFERNCE FIT KING PIN	TATA spare parts
282633208601	SHIM 0.1 THK	TATA spare parts
282633208602	SHIM 0.2 THK	TATA spare parts
282633208603	SHIM 0.3 THK	TATA spare parts
282633208604	SHIM 0.4 THK	TATA spare parts
282633208605	SHIM 0.5 THK	TATA spare parts
282633208606	SHIM 0.6 THK	TATA spare parts
282633208607	SHIM 0.7 THK	TATA spare parts
282633208612	SHIM 0.15 THK BS6	TATA spare parts
282633403101	THRUST BEARING NORMAL	TATA spare parts
282633403102	THRUST PAD	TATA spare parts
282633403104	THRUST BEARING REPAIR-I	TATA spare parts
282633403105	THRUST BEARING REPAIR-II	TATA spare parts
282633403109	THRUST ROLLER KINGPIN BEARING NORMAL	TATA spare parts
282633403113	THRUST PAD KINGPIN BEARING NORMAL	TATA spare parts
282633407801	DOUBLE LIP OIL SEAL (M/S SKF)	TATA spare parts
282640100101	ASSY.WHEEL DISC & RIM 5.5FX16	TATA spare parts
282640100103	ASSY.WHEEL DISC & RIM 5.5FX16	TATA spare parts
282640100108	ASSY TUBE 7.00 R16 WITH VALVE	TATA spare parts
282640109907	TYRE 7.00X16-12PR	TATA spare parts
282641000101	ASSY.DANA PROP.SHAFT (MONOTRON)	TATA spare parts
282641000102	ASSY.PROP.SHAFT	TATA spare parts
282641100101	ASSY.PROP.SHAFT COMPLETE	TATA spare parts
282641117701	C.B.RUBBER	TATA spare parts
282642100101	ASSY. BRAKE DISC WITH BOLT	TATA spare parts
282642103701	VENTILATED BRAKE DISC BS1/2/3	TATA spare parts
282642300103	ADJUSTER ASSEMBLY (M/S-BIL-29193679)	TATA spare parts
282642300104	ADJUSTER ASSEMBLY (M/S-BIL-29193680)	TATA spare parts
282642300109	BACK PLATE ASSY LH	TATA spare parts
282642300110	BACK PLATE ASSY RH	TATA spare parts
282642300113	KIT SHOE HOLD DOWN (M/S BIL-29919291)	TATA spare parts
282642300115	KIT SCREW AND WASHER	TATA spare parts
282642308701	SPRING ABUTMENT END (M/S BIL-29192712)	TATA spare parts
282642308702	SPRING CYLINDER END	TATA spare parts
282642700103	ASSY.PARKING BRAKE UNIT	TATA spare parts
282642700105	ASSY. BRACKET	TATA spare parts
282642700110	ASSY PARKING BRAKE CABLE FRONT ( )	TATA spare parts
282642700112	ASSY PARKING BRAKE CABLE REAR	TATA spare parts

282642700113	ASSY PARKING BRAKE CABLE REAR	TATA spare parts
282642700114	ASSY PARKING BRAKE CABLE REAR	TATA spare parts
282642706701	CLEVIS PIN	TATA spare parts
282642800111	ASSY.TUBE	TATA spare parts
282642800112	ASSY. TUBE	TATA spare parts
282642800113	ASSY. TUBE	TATA spare parts
282642800114	ASSY. TUBE	TATA spare parts
282642800115	ASSY. TUBE	TATA spare parts
282642800119	ASSY. TUBE	TATA spare parts
282642800122	ASSY. TUBE	TATA spare parts
282642800127	ASSY. HOSE	TATA spare parts
282642800131	ASSY. FRONT BRAKE HOSE -	TATA spare parts
282642806916	TUBE 6 ODX0.7 THK.SS:4040-20	TATA spare parts
282643500101	ASSY. VACCUM HOSE	TATA spare parts
282643500101AE	ASSY. VACUUM HOSE XEN DC XEN SC	TATA spare parts
282643800101	ASSY. TUBE	TATA spare parts
282643800102	ASSY. TUBE	TATA spare parts
282643800107	ASSY. TUBE	TATA spare parts
282643800108	ASSY. TUBE	TATA spare parts
282643800109	ASSY. TUBE	TATA spare parts
282643800110	ASSY. TUBE	TATA spare parts
282643800111	ASSY. TUBE	TATA spare parts
282643800113	ASSY. TUBE	TATA spare parts
282643800114	ASSY. TUBE	TATA spare parts
282644805801	SUCTION HOSE (RESERVOIR TO PUMP)	TATA spare parts
282646000101	ASSY POWER STG GEARBOX	TATA spare parts
282646000103	ASSY. POWER STG. GEAR BOX 207 DI BS1- 4	TATA spare parts
282646000106	POWER STEERING GEARBOX HOUSING ASSY	TATA spare parts
282646000107	POWER STEERING GEARBOX HSG COVER ASSY	TATA spare parts
282646000108	POWER STEERING GEARBOX PISTON ASSY	TATA spare parts
282646000109	POWER STEERING GEARBOX SEALING KIT	TATA spare parts
282646000110	POWER STEERING GEARBOX SMALL COMP. SET	TATA spare parts
282646000112	POWER STEERING GEARBOX SECTOR SHAFT ASSY	TATA spare parts
282646108201	FLOOR CLOSING PLATE	TATA spare parts
282646200103	ASSY. STEERING GEAR BOX (MECHANICAL)	TATA spare parts
282646206301	RUBBER BELLOW (BOTTOM)	TATA spare parts
282646206302	BUSH (FOR STG. SPINDLE)	TATA spare parts
282646206304	DUST COVER (MECHANICAL STG. GEARBOX)	TATA spare parts
282646206305	DUST COVER (MECHANICAL STG. GEAR BOX)	TATA spare parts
282646207701	RUBBER BELLOW	TATA spare parts
282646306001	PITMAN ARM (POWER STEERING)	TATA spare parts
282646306002	PITMAN ARM (MECH. STEERING)	TATA spare parts
282646306005	PITMAN ARM (POWER STEERING)	TATA spare parts
282646306006	PITMAN ARM (MECHANICAL STEERING)	TATA spare parts
282646400102	ASSY STEERING WHEEL DIA 420	TATA spare parts
282646600101	ASSY. CENTRE LINK BS1/2/3	TATA spare parts
282646600111	CENTRE LINK ASSEMBLY	TATA spare parts



282646600116	ASSY. POWER STG. PUMP BS2/3/4	TATA spare parts
282646600117	ASSY. TIE ROD BS1/2/3/4	TATA spare parts
282646600118	ASSY.TIE ROD	TATA spare parts
282646600122	ASSY.POW.STRG PUMP	TATA spare parts
282646600129	ASSY.DRAG LINK	TATA spare parts
282646600130	ASSY. TIE ROD BS1/2/3/4	TATA spare parts
282646600136	ASSY.P/STG. PUMP 80 BAR	TATA spare parts
282646600137	ASSY. TIE ROD	TATA spare parts
282646600138	ASSY.DRAG LINK	TATA spare parts
282646600139	ASSY. STEERING COLUMN BS1/2/3/4	TATA spare parts
282646600158	REPAIR KIT MAJOR FOR STRG PUMP 0136	TATA spare parts
282646600159	REPAIR KIT MINOR FOR STRG PUMP 0136	TATA spare parts
282646600160	TIE ROD ASSEMBLY	TATA spare parts
282646600161	ASSY. DRAG LINK	TATA spare parts
282646600162	ASSY STG.COLUMN	TATA spare parts
282646600170	ASSY RETURN LINE (G.B. TO RESERVOIR)	TATA spare parts
282646600180	ASSY.BRACKET (STG.DAMPER MTG)	TATA spare parts
282646600181	ASSY. CLAMP (DRAGLINK)	TATA spare parts
282646600184	ASSY UNIVERSAL JOINT	TATA spare parts
282646600185	TIE ROD END RH	TATA spare parts
282646600186	TIE ROD END LH	TATA spare parts
282646600187	DRAG LINK END	TATA spare parts
282646600190	ASSY. DRAG LINK BS2/3	TATA spare parts
282646600194	SHAFT SUB ASSY	TATA spare parts
282646600195	CARTRIDGE ASSY KIT	TATA spare parts
282646600196	SEALKIT-STG.PUMP	TATA spare parts
282646603202	PIN (DAMPER MTG.)	TATA spare parts
282646606703	DOWEL PIN POWER STEERING PIN	TATA spare parts
282646606802	SUCTION PORT CONNECTOR	TATA spare parts
282646608209	BRACKET (DAMPER & ARB MTG.)	TATA spare parts
282646608211	CLAMP (DRAGLINK)	TATA spare parts
282646800102	ASSY. HIGH PRESSURE HOSE(PUMP END)	TATA spare parts
282646800103	ASSY. LOW PRESSURE HOSE(RESERVOIR END)	TATA spare parts
282646800106	ASSY.RETURN LINE COMPLETE(GEAR BOX END)	TATA spare parts
282646800108	ASSY.LOW PRESSURE HOSE ( GEAR BOX SIDE)	TATA spare parts
282646800123	ASSY.SUCTION HOSE	TATA spare parts
282646800124	ASSY. SUCTION LINE (RESERVIOR TO PUMP)	TATA spare parts
282646800125	ASSY. HIGH PRESSURE LINE (PUMP TO GB)	TATA spare parts
282646800126	ASSY. RETURN LINE (G.B. TO RESERVOIR)	TATA spare parts
282646800127	ASSY. RETURN LINE	TATA spare parts
282646800130	ASSY HIGH PRESS. HOSE COMPLETE	TATA spare parts
282646800133	ASSY.HIGH PRESSURE LINE(PUMP TO GEARBOX)	TATA spare parts
282646800134	ASSY. RETURN LINE (GEARBOX SIDE)	TATA spare parts
282646800135	ASSY. RETURN LINE (RESERVOIR SIDE)	TATA spare parts
282646800141	ASSY SUCTION LINE (PUMP SIDE)	TATA spare parts
282646800142	ASSY SUCTION LINE (RESERVOIR SIDE)	TATA spare parts
282646800149	ASSY RETURN LINE PIPE	TATA spare parts

282646800150	ASSY RETURN LINE PIPE	TATA spare parts
282646805806	SUCTION HOSE (RESERVOIR TO PUMP)	TATA spare parts
282646808201	BRACKET (P/STG. PIPE CLAMPING)	TATA spare parts
282647100107	ASSY. TUBE (FILLER NECK SUPPORT)	TATA spare parts
282647100108	ASSY BRACKET(FUEL TANK MTG)	TATA spare parts
282647100109	ASSY.FILLER NECK TOP WITH BRACKET	TATA spare parts
282647100112	ASSY. FUEL TANK (COMPLETE)	TATA spare parts
282647107701	HOSE (FUEL FILLING)	TATA spare parts
282647500101	ASSY. STRAP (FUEL TANK MOUNTING)	TATA spare parts
282647500104	ASSY.STRAP	TATA spare parts
282647500105	ASSY.STRAP	TATA spare parts
282647507701	RUBBER PACKING	TATA spare parts
282647507702	RUBBER PACKING	TATA spare parts
282647508206	BRACKET (FUEL LINE MTG.)	TATA spare parts
282647600118	ASSY PA TUBE DELIVERY LINE(F/T TO W/S)	TATA spare parts
282647600119	ASSY PA TUBE DELIVERY LINE-W/S TO ENGINE	TATA spare parts
282647600120	ASSY PA TUBE RETURN LINE(ENGINE TO F/T)	TATA spare parts
282647600121	ASSY. BREATHER TUBE. (15 OD)	TATA spare parts
282647600122	ASSY.SUCTION PIPE (TANK TO HOSE)	TATA spare parts
282647600123	ASSY.RETURN LINE (HOSE TO TANK)	TATA spare parts
282647600127	ASSY. BREATHER HOSE	TATA spare parts
282647600129	ASSY. FUEL LINE ON CHASSIS	TATA spare parts
282647600130	ASSY BREATHER PIPE (FILLER NECK TO TANK)	TATA spare parts
282647600138	ASSY.PA TUBE DELIVERY LINE(F/T.TO W/S.)	TATA spare parts
282647600139	ASSY.PA TUBE RETURN LINE(ENGINE TO F/T.)	TATA spare parts
282647600140	ASSY.PA TUBE DELIVERY LINE(W/S.TO ENGINE	TATA spare parts
282647605807	BREATHER HOSE(DIA.14.5ID.)	TATA spare parts
282647605808	HOSE BREATHER PIPE	TATA spare parts
282649100101	ASSY SILENCER + HOOK(DIA50 8:207DI)	TATA spare parts
282649200101	ASSY. EXHAUST PIPE MID. (207DI 31WB)	TATA spare parts
282649200102	ASSY. EXHAUST PIPE REAR (207DI)	TATA spare parts
282649200103	ASSY. EXHAUST PIPE FRONT (207-DI 28WB)	TATA spare parts
282649200104	ASSY. EXHAUST PIPE MID (207-DI 28WB)	TATA spare parts
282649200105	ASSY. EXHAUST PIPE FRONT (207-DI 31WB)	TATA spare parts
282649200106	ASSY. EXHAUST PIPE MID (207-DI 31WB)	TATA spare parts
282649200107	ASSY. EXHAUST PIPE REAR (207-DI 31WB)	TATA spare parts
282649200108	ASSY. EXHAUST PIPE REAR (207-DI 28WB)	TATA spare parts
282649200109	ASSY. BRACKET (SILENCER MTG.)	TATA spare parts
282649200118	PIPE ASSY	TATA spare parts
282654100101	ASSY.BATT.CABLE +VE & -VE	TATA spare parts
282654100102	ASSY BATTERY HOLDING ANGLE	TATA spare parts
282654100103	BATTERY CABLE +VE	TATA spare parts
282654100104	BATT.CABLE -VE [BATT.TO SIDE PANEL [O.D]	TATA spare parts
282654100105	BATT.CABLE -VE [CLUTCH HSG-FLOOR]	TATA spare parts
282654108202	KET CONNECTOR HOLDER	TATA spare parts
282654109902	BATTERY -12V,75Ah LH	TATA spare parts
282654109903	BATTERY 12V 80AH	TATA spare parts

282654200104	INST.CLUSTER 1:1.0625 W/TRIP ODO	TATA spare parts
282654200105	INST.CLUSTER 1:1.7 W/TRIP ODO	TATA spare parts
282654200106	INST.CLUSTER 1:1.935 DI-CMVR-2000	TATA spare parts
282654200107	INST.CLUSTER 1:1.935 DI-BH-II	TATA spare parts
282654200108	INST.CLUSTER 1:1.1 WITH TRIP ODO	TATA spare parts
282654200109	INST CLUASTER 1:0.935 W/TR ODO	TATA spare parts
282654200110	ASSY.BKT EGR CTRL-BS-III	TATA spare parts
282654200111	INST CLUSTER 1:1 04 W/TRIP ODO	TATA spare parts
282654200112	ASSY.CHANNEL [MAGNETIC VALVE]	TATA spare parts
282654200116	ASSY.INSN CLUST 1:0.812 W/TR ODO	TATA spare parts
282654200117	ASSY.INST.CLUST.1:0935 W/TRI ODO	TATA spare parts
282654200118	ASSY.2.2L ECU SUPPORT	TATA spare parts
282654200122	ASSY SPEEDOMETER	TATA spare parts
282654200124	FUEL AND TEMP GAUGE	TATA spare parts
282654200125	ASSY.RPM METRE 0-8000 W/O LED	TATA spare parts
282654209901	SPEEDOMETER 0-160 1.0625 WHITE DIAL	TATA spare parts
282654209903	ASSY RPM METER 0-6000 WHITE DIAL [4X2]	TATA spare parts
282654209904	FUEL+TEMP GAUGE ASSY W/PCB U1 WHITE DIAL	TATA spare parts
282654209909	RPM METER 0-4000 GREEN BAND [1:2.82]	TATA spare parts
282654400101	REAR FOG LAMP	TATA spare parts
282654406301	REAR FOG LAMP DUMMY COVER	TATA spare parts
282654500102	STEERING COMBI SWITCH	TATA spare parts
282654500103	STEERING LOCK/IG.SW.W/KEY SENSOR	TATA spare parts
282654500104	STEERING COMBI SWITCH RHD	TATA spare parts
282654500105	ASSY BONNET SWITCH HOLDER	TATA spare parts
282654509901	IC.FLASHER.W/MTG.BKT.W/O.CONN.	TATA spare parts
282654509904	STEERING COMBI. SW.-RHD	TATA spare parts
282654600106	W/H.ENGINE [FACELIFT EURO-II]	TATA spare parts
282654600107	W/H.FRONT 4X2-EURO-II[FACELIFT]	TATA spare parts
282654600110	WING HARNESS FRONT-EURO-III	TATA spare parts
282654600113	W/H.ENGINE CMVR-2000 MECH STG.	TATA spare parts
282654600114	WIRING HARNESS TAIL	TATA spare parts
282654600115	WIRING HARESS ROOF	TATA spare parts
282654600117	WIRING HARNESS EGR CTRL.BS-II	TATA spare parts
282654600121	WIRING HARNESS CABIN LHD EURO-III	TATA spare parts
282654600122	WIRING HARNESS CABIN RHD EURO-III	TATA spare parts
282654600123	WIRING HARNESS MAIN BS-II-EX	TATA spare parts
282654600124	WIRING HARNESS MAIN BS-III-EX	TATA spare parts
282654600131	WIRING HARNESS TAIL	TATA spare parts
282654600132	WIRING HARNESS ENGINE BS-II	TATA spare parts
282654600133	WIRING HARNESS EGR CTRL BS-II	TATA spare parts
282654600139	WIRING HARNESS ENGINE-BS-II	TATA spare parts
282654600140	WIRING HARNESS EGR CTRL.BS-II	TATA spare parts
282654600144	WIRING HARNESS FRONT EURO-III	TATA spare parts
282654600148	WIRING HARNESS DRIVER DOOR	TATA spare parts
282654600149	WIRING HARNESS CO-DRIVER DOOR	TATA spare parts
282654600150	WIRING HARNESS DR.SIDE REAR DOOR	TATA spare parts

282654600151	WIRING HARNESS CO-DR.SIDE REAR DOOR	TATA spare parts
282654600152	WIRING HARNESS MAIN	TATA spare parts
282654600154	WIRING HARNESS MAIN BS-II-EX	TATA spare parts
282654600155	WIRING HARNESS MAIN BS-III-EX	TATA spare parts
282654600156	WIRING HARNESS CABIN LHD EURO-III	TATA spare parts
282654600164	W/H MAIN LHD WITH BLOWER	TATA spare parts
282654600165	WIRING HARNESS MAIN	TATA spare parts
282654600166	WIRING HARNESS TAIL	TATA spare parts
282654600170	W/H.FRONT BS-II	TATA spare parts
282654600171	W/H/CABIN RHD BS-II	TATA spare parts
282654601603	WIRING HARNESS MAIN	TATA spare parts
282654601611	BATTERY CABLE NEGATIVE	TATA spare parts
282654601612	WIRING HARNESS TAIL	TATA spare parts
282654608203	ANGLE WIRING HARNESS CLAMP	TATA spare parts
282654900101	KIT-IMMO.+KEY LESS ENTRY SYSTEM-MINDAHUF	TATA spare parts
282654900102	KIT-IMMOBILISER + KEYLESS ENTRY SYSTEM	TATA spare parts
282658900102	ASSY SCISSOR JACK WITH 3 PIECE HANDLE	TATA spare parts
282660000101BF	ASSY BODY COMPLETE RHD	TATA spare parts
282660000101BN	ASSY BODY COMPLETE RHD	TATA spare parts
282660000101BS	ASSY BODY COMPLETE SOLID GREEN	TATA spare parts
282660000102BF	ASSY BODY SHELL COMPLETE PAINTED RHD	TATA spare parts
282660000102BN	ASSY BODY SHELL COMPLETE PAINTED RHD	TATA spare parts
282660000102BS	ASSY BODY SHELL PAINTED SOLID GREEN	TATA spare parts
282670000101	ASSY.LOAD BODY WITH FITMENTS-VAJRA	TATA spare parts
282670000106BF	ASSY.L/BODY S/W F/BED EXTENDED (207DI RX	TATA spare parts
282670000111	ASSY.L/B S/W F/BED EXTENDED PAINTED	TATA spare parts
282670000111BF	ASSY.L/B S/W F/BED EXTENDED PAINTED	TATA spare parts
282670000121BF	ARCTIC_WHITE-LOAD BODY ASSY	TATA spare parts
282670006301	MUD FLAP LH	TATA spare parts
282670006302	MUD FLAP RH	TATA spare parts
282670200101	ASSY FRONT PANEL	TATA spare parts
282670300105	ASSY SIDE PANEL LH	TATA spare parts
282670300106	ASSY SIDE PANEL RH	TATA spare parts
282670400101	ASSY TAIL GATE PANEL	TATA spare parts
282682400101	WIND SHIELD WASHER KIT	TATA spare parts
282682400102	WIND SHIELD WASHER KIT	TATA spare parts
282682406302	TANK ASSY [PRABHA]	TATA spare parts
282682406902	TUBE DIA 4 X DIA7 TUBE 1800MM	TATA spare parts
282682406905	TUBE;PUMP TO NOZZLE BS6	TATA spare parts
282682407502	RUBBER GROMENT	TATA spare parts
282683500103	KIT HEATER WITH COIL-LHD	TATA spare parts
282683500104	ASSY.BRACKET(FOR N.D.WATER VALVE MTG)	TATA spare parts
282683505802	RUBBER HOSE (ENGINE TO AWTER VALVE)	TATA spare parts
282683505803	RUBBER HOSE (HEATER TO ENGINE)	TATA spare parts
282683505804	RUBBER HOSE (WATER VALVE TO HEATER UNIT)	TATA spare parts
282691500101	ASSY SEAT BELT KIT(W/O MICRO SW - DIBUK)	TATA spare parts
282715400104	12V 75A ALT EXT FAN VAC.57 DIA.	TATA spare parts

282715400108	ALT.INT FAN 12V 75A VAC 57 DIA	TATA spare parts
282715400109	12V,75A ALT.EXT.FAN VAC.57 DIA 6-PK-MICO	TATA spare parts
282715409901	PULLEY FOR ALTERNATOR 75A	TATA spare parts
282715409902	D.E BRACKET MACHINING FOR ALT 75	TATA spare parts
282715409903	ROTOR ASSY FINAL	TATA spare parts
282715409904	STATOR WINDING FINAL ASSY	TATA spare parts
282715409905	RECTIFIER ARRANGEMENT	TATA spare parts
282715409906	S.R.E. BRACKET MACHINING	TATA spare parts
282715409907	REGULATOR AND BRUSH BOX ASSY	TATA spare parts
282715409908	HOUSING M/C FINAL	TATA spare parts
282715409909	ROTOR OF ALTERNATOR	TATA spare parts
282715409910	CENTRAL PLATE OF ALTERNATOR 75A	TATA spare parts
282715409911	VANES OF ALTERNATOR	TATA spare parts
282715409912	CHECK VALVE ASSY	TATA spare parts
282715409913	BEARING ASSY KIT OF ALTERNATOR 75A	TATA spare parts
282715409914	FASTNERS & SUNDRIES PART KIT	TATA spare parts
282715409915	VACCUM PUMP ASSY KIT	TATA spare parts
282740100102	ASSY.WHEEL RIM COVER	TATA spare parts
282741110101	ASSY. SINGLE PIECE PROPELLER SHAFT	TATA spare parts
282746800102	ASSY. RETURN LINE HOSE	TATA spare parts
282749100101	ASSY SILENCER + BKT(DIA50.8-4X2NA)	TATA spare parts
282749100102	ASSY SILENCER + BKT(DIA50.8-4X2NA)	TATA spare parts
282749100103	ASSY SILENCER + BKT(DIA50.8-4X2NA)	TATA spare parts
282754209901	EGR CONTROLLER	TATA spare parts
282754509901	TEMP.SWITCH 15 DEG.CENT [NC] [OFFER DRG]	TATA spare parts
282754509902	TEMP.SWITCH 15 DEG.CENT.[NC]	TATA spare parts
282754600115	WIRING HARNESS ENGINE BS-III	TATA spare parts
282854409911	SIDE REP- WHITE LEN	TATA spare parts
282915100101	ASSY.JUNCTION BOX MTG BKT ACE DICOR	TATA spare parts
282915100103	ASSY. STARTER MOTOR BS3/4	TATA spare parts
282915100137	PLUNGER ASSY.	TATA spare parts
282915109903	STARTER MOTOR BS2/3/4	TATA spare parts
282915109903DF	STARTER MOTOR ASSY - ACE/MAGIC BS3/4	TATA spare parts
282915109905	PLUNGER ASSEMBLY	TATA spare parts
282915109906	PLUNGER RETURN SPRING	TATA spare parts
282915109907	SOLENOID SWITCH ASSEMBLY	TATA spare parts
282915109907DF	SOLENOID ASSY - ACE/MAGIC BS3/4	TATA spare parts
282915109909	ENGAGING LEVER ASSEMBLY	TATA spare parts
282915109910	DRIVE ASSEMBLY	TATA spare parts
282915109910DF	STARTER DRIVE ASSY - ACE/MAGIC BS3/4	TATA spare parts
282915109911	FIXING BRACKET ASSEMBLY	TATA spare parts
282915109911DF	STARTER FIXED BRACKET ASSY-ACE/MAGIC BS3	TATA spare parts
282915109912	FIELD COIL ASSEMBLY	TATA spare parts
282915109912DF	STARTER FIELD COIL ASSY-ACE/MAGIC BS3/4	TATA spare parts
282915109913	BRUSH GEAR ASSEMBLY	TATA spare parts
282915109913DF	STARTER BRUSH GEAR - ACE/MAGIC BS3/4	TATA spare parts
282915109915	ARMATURE ASSEMBLING KIT	TATA spare parts

282915109917	BEARING BUSH ASSY KIT	TATA spare parts
282915109924	STARTER MOTOR FOR ACE	TATA spare parts
282915109926	STARTER-MOTOR-DICOR(WITH SS)	TATA spare parts
282915109928	PLUNGER ASSY	TATA spare parts
282915109929	PLUNGER RETURN SPRING	TATA spare parts
282915109930	SOLENOID ASSY BS4	TATA spare parts
282915109931	FIXING BRACKET ASSY	TATA spare parts
282915109932	DRIVE ASSY	TATA spare parts
282915109933	ENGAGING LEVER	TATA spare parts
282915109934	ANNULUS ASSY	TATA spare parts
282915109935	PLANETARY GEAR ASSY	TATA spare parts
282915109936	OUTPUT SHAFT ASSY	TATA spare parts
282915109937	ARMATURE ASSY	TATA spare parts
282915109938	BUSH GEAR ASSY	TATA spare parts
282915109939	C.E. BRACKET ASSY	TATA spare parts
282915109940	FASTENERS KIT	TATA spare parts
282915109941	SEALING KIT	TATA spare parts
282915109942	BEARING BUSH KIT	TATA spare parts
282915109947	C.E. BRKT ASSY.	TATA spare parts
282915109948	FASTNERS KIT	TATA spare parts
282915206301	HOSE SEPERATOR CLAMP	TATA spare parts
282915400104	ALTERNATOR 50A W/O VACUUM PUMP	TATA spare parts
282915400106	ALTERNATOR 65A BS3/4	TATA spare parts
282915409901	ALTERNATOR 12V 40A-4GR.PULLEY	TATA spare parts
282915409903	GLOW PLUG STRIP	TATA spare parts
282915409906	ALTERNATOR W/VACCUM PUMP 12V 40A BS2/3	TATA spare parts
282915409921	ALTERNATOR 40A 4-GR PULLY	TATA spare parts
282915409926	ALTERNATOR WITH ZENER DIODE12V 40A	TATA spare parts
282915409929	ALTERNATOR 55A WITH INT.FAN& LRC REGULAT	TATA spare parts
282915409930	ALTERNATOR 40A-FOR ACE 275 IDI BSIV	TATA spare parts
282915409931	ALTERNATOR 40A WITH VACCUM PUMP FOR MA	TATA spare parts
282915409933	FLANGE NUT	TATA spare parts
282915409934	PULLEY	TATA spare parts
282915409935	D. E BRACKET ASSY	TATA spare parts
282915409936	BEARING COLLAR	TATA spare parts
282915409937	DE FAN	TATA spare parts
282915409938	STARTOR ASSY	TATA spare parts
282915409939	S.R.E BRACKET ASSY	TATA spare parts
282915409940	THROUGH BOLT	TATA spare parts
282915409941	RECTIFIER ASSY	TATA spare parts
282915409942	RECTIFIER FIXING SCREW	TATA spare parts
282915409943	SEAL	TATA spare parts
282915409945	REGULATOR ASSY BS4	TATA spare parts
282915409946	BUSH ASSY	TATA spare parts
282915409947	REGULAR FIXING SCREW	TATA spare parts
282915409948	A & L POINT FIXING SCREW	TATA spare parts
282915409949	REAR COVER	TATA spare parts

282915409950	CAPACITOR ASSY	TATA spare parts
282915409951	NUT	TATA spare parts
282915409952	BEARING ASY KIT	TATA spare parts
282915409953	FASTENERS ASSY KIT	TATA spare parts
282915409954	FUSE ASSY.	TATA spare parts
282915409955	STUD (FUSE SUPPORT)	TATA spare parts
282915409956	STUD (FUSE SUPPORT)	TATA spare parts
282915409965	PULLEY(MACHINED)	TATA spare parts
282915409966	D.E.BRACKET ASSY.	TATA spare parts
282915409970	D.E.FAN	TATA spare parts
282915409971	ROTOR ASSY.	TATA spare parts
282915409975	ROTOR ASSY	TATA spare parts
282915409976	S.R.E.BEARING	TATA spare parts
282915409977	STATOR ASSY.	TATA spare parts
282915409980	S.R.E. BRACKET ASSY.	TATA spare parts
282915409983	RECTIFIER ASSY	TATA spare parts
282915409989	REGULATOR ASSY	TATA spare parts
282915409993	BRUSH ASSY.	TATA spare parts
282915409994	BRUSH	TATA spare parts
282915409997	REAR COVER	TATA spare parts
282929100108	ASSY.CLUTCH PEDAL LEVER	TATA spare parts
282929100109	ASSY. CLUTCH CABLE	TATA spare parts
282929100122	ASSY.BRACKET-CLUTCH CABLE GUIDE	TATA spare parts
282929100125	ASSY. CLUTCH CABLE	TATA spare parts
282929100126	ASSY. CLUTCH CABLE	TATA spare parts
282929100128	ASSY. CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
282929100130	ASSY. CLUTCH CABLE BS2/3/4	TATA spare parts
282929100131	ASSY. CLUTCH RELEASE LEVER ARRANGEMENT	TATA spare parts
282929100140	ASSY. CLUTCH CABLE ACE 2050MM BS2/3/4	TATA spare parts
282929100141	ASSY. BRACKET (CLUTCH CABLE GUIDE)	TATA spare parts
282929100142	ASSY. CLUTCH PEDAL LEVER (COMPLETE)	TATA spare parts
282929100145	ASSY. CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
282929100147	CLUTCH¿ PEDAL LEVER COMPLETE	TATA spare parts
282929100149	ASSY. CLUTCH CABLE	TATA spare parts
282929100153	ASSY. CLUTCH RELEASE ARR.(170MM) BS2-6	TATA spare parts
282929100162	ASSY.CLUTCH¿ PEDAL LEVER COMPLETE	TATA spare parts
282929100168	ASSY.CLUTCH¿ PEDAL LEVER COMPLETE	TATA spare parts
282929100170	ASSY. CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
282929100178	ASSY. CLUTCH CABLE 1800MM BS3/4	TATA spare parts
282929100182	ASSY. CLUTCH PEDAL LEVER	TATA spare parts
282929100185	ASSY.CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
282929103401	BUSH (CLUTCH CABLE) BS6	TATA spare parts
282929104201	CLAMP (CLUTCH CABLE MTG.)	TATA spare parts
282929106301	PACKING FOAM (CONTROL MTG. BRACKET)	TATA spare parts
282929106303	PACKING FOAM ACE FACELIFT	TATA spare parts
282929106702	PIVOT PIN (CLUTCH)	TATA spare parts
282929106703	PIN (FOR CLUTCH CABLE GUIDE)	TATA spare parts

282929106704	SLEEVE (CLUTCH CABLE PEDAL END)	TATA spare parts
282929106705	PIVOT PIN (CLUTCH)	TATA spare parts
282929108701	CLUTCH PEDAL ASSISTANCE SPRING	TATA spare parts
282929108702	SPRING (CLUTCH RELEASE LEVER)	TATA spare parts
282929108703	CLUTCH PEDAL ASSISTANCE SPRING	TATA spare parts
282929200103	BRAKE PEDAL ASSY WITH BUSH	TATA spare parts
282929200111	ASSY. CLIP	TATA spare parts
282929200116	ASSY.BRAKE PEDAL COMPLETE	TATA spare parts
282929200118	ASSY.CONTROL MTG.BRACKET	TATA spare parts
282929200120	ASSY CONTROL MTG BKT (CLUTCH & BRAKE)	TATA spare parts
282929200128	ASSY. BRAKE PEDAL LEVER COMPLETE	TATA spare parts
282929200130	ASSY. CONTROL MTG. BRACKET (CLUTCH AND B	TATA spare parts
282929200141	ASSY. CONTROL MTG. BRACKET (CLUTCH BRAKE	TATA spare parts
282929200145	ASSY. CONTROL MTG.(CLUTCH & BRAKE)	TATA spare parts
282929200148	ASSY.COTROL MTG.BRKT.(CLUTCH & BRAKE)	TATA spare parts
282929200149	BRAKE PEDAL COMPLETE	TATA spare parts
282929200168	ASSY. BRAKE PEDAL LEVER COMPLETE	TATA spare parts
282929200170	ASSY. CONTROL MTG. BRACKET (CLUTCH AND B	TATA spare parts
282929200178	ASSY.COTROL MTG.BRKT.(CLUTCH & BRAKE)	TATA spare parts
282929200179	ASSY.BRAKE PEDAL COMPLETE	TATA spare parts
282929200190	ASSY.BRAKE PEDAL COMPLETE	TATA spare parts
282929200191	ASSY. BRAKE PEDAL	TATA spare parts
282929200192	ASSY. BRAKE PEDAL LEVER COMPLETE	TATA spare parts
282929200196	ASSY. CONTROL MTG. BRACKET (CL.& BR.)	TATA spare parts
282929206702	PIVOT PIN (BRAKE)	TATA spare parts
282929206705	SPACER	TATA spare parts
282929206706	BRAKE PIN	TATA spare parts
282929206707	BRAKE PIN	TATA spare parts
282929206711	PIVOT PIN (BRAKE)	TATA spare parts
282929208220	LOCKING PLATE	TATA spare parts
282929208702	RETURN SPRING (BRAKE)	TATA spare parts
282929208703	RETURN SPRING (BRAKE)	TATA spare parts
282929208705	RETURN SPRING (BRAKE)	TATA spare parts
282929500102	ASSY.CONTROL MTG.BRKT.(CLUTCH & BRAKE)	TATA spare parts
282929500105	ASSY.CONTROL MTG. BRACKET(CLUTCH AND BRA	TATA spare parts
282929500112	ASSY. CONTROL MTG. BRACKET(C&B)	TATA spare parts
282929500114	BRAKE & CLUTCH PEDAL ASSY WITH MTG BKT	TATA spare parts
282929500116	ASSY. CONTROL MTG. BRACKET (C&B)	TATA spare parts
282930100111	ACCELERATOR CABLE	TATA spare parts
282930100129	ASSY. ACCELERATOR PEDAL	TATA spare parts
282930100130	ASSY. ACCELERATOR PEDAL COMP. BS2/3/4	TATA spare parts
282930100131	ASSY. BRACKET (ACCELERATOR PEDAL MTG.)	TATA spare parts
282930100132	ACCELERATOR CABLE 2800MM BS2/3/4	TATA spare parts
282930100134	ASSY. ACCELERATOR CABLE 2800MM BS3/4	TATA spare parts
282930100141	ASSY. ACCELERATOR CABLE	TATA spare parts
282930100154	ASSY SUPPORTPLATE (ACCELERATOR MOUNTING	TATA spare parts
282930100157	ASSY. ACCELERATOR PEDAL COMPLETE	TATA spare parts



282930100158	ASSY. ACCELERATOR PEDAL	TATA spare parts
282930100159	ACCLERATOR PIVOT ASSY.	TATA spare parts
282930100165	ACCELERATOR PEDAL MODULE	TATA spare parts
282930100167	ASSY. ACCELERATOR PEDAL COMPLETE	TATA spare parts
282930100171	ASSY. ACCELERATOR PEDAL MTG BRACKET	TATA spare parts
282930100172	AASY.ACCEL.CABLE WITH BENT TUBE	TATA spare parts
282930100175	ASSY. ACCELERATOR CABLE	TATA spare parts
282930100181	ASSY. ACCELERATOR CABLE 2728MM BS2/3/4	TATA spare parts
282930103402	BUSH (FOR ACCL. PEDAL ROD MTG.)	TATA spare parts
282930108701	SPRING (FOR ACCELERATOR PEDAL)	TATA spare parts
282930108703	SPRING (FOR ACCELERATOR PEDALS)	TATA spare parts
282930108705	SPRING (FOR ACCELERATOR PEDAL)	TATA spare parts
282931000109	ASSY. FRAME (2100 WHEELBASE) TATA ACE	TATA spare parts
282931000113	ASSY. FRAME	TATA spare parts
282931000124	ASSY. FRAME (750 PAYLOAD)	TATA spare parts
282931000126	ASSY. FRAME	TATA spare parts
282931129901	TOWING HOOK	TATA spare parts
282931130105	ASSY. BRKT MID (LOADBODY MTG.) BS6-PH2	TATA spare parts
282931130106	ASSY. BRKT REAR (LOADBODY MTG.) BS6-PH2	TATA spare parts
282931130107	BRACKET ASSY LOAD BODY MTG RH BS6-PH2	TATA spare parts
282931130108	BRACKET ASSY LOAD BODY MTG LH BS6-PH2	TATA spare parts
282931130109	ASSY. BRACKET TOWING HOOK FRONT	TATA spare parts
282931130119	BATTERY TRAY ASSY BS6-PH2	TATA spare parts
282931130125	ASSY. BRACKET TOWING HOOK REAR	TATA spare parts
282931130134	ASSY. BRACKET (SECOND LOADBODY MTG.) BS6	TATA spare parts
282931138222	BRACKET (CROSS MEMBER CONNECTION) BS6	TATA spare parts
282931138225	BRACKET (RADIATOR SUPPORT)	TATA spare parts
282931138252	CLOSING PLATE LH REAR BS6-PH2	TATA spare parts
282931138286	BRACKET (WIRING HARNESS MTG.) BS6	TATA spare parts
282931138290	BRACKET (REAR S/A MOUNTING TOP)	TATA spare parts
282931230101	ASSY. FRONT CROSS MEMBER BS2/3/4	TATA spare parts
282931230102	CROSS MEMBER ASSY FRONT SPRING	TATA spare parts
282931230114	ASSY.CROSS MEMBER(FR. SPRING RR.)	TATA spare parts
282931230133	ASSY.CROSS MEMBER(FR. SPRING RR.)	TATA spare parts
282931230136	ASSY.CROSS MEMBER COMPLETE G.B. MTG.	TATA spare parts
282931230138	CROSS MEMBER ASSY	TATA spare parts
282931230151	CROSS MEMBER ASSY RR SPIRNG RR BS6-PH2	TATA spare parts
282931236901	CROSS MEMBER (ENGINE MOUNTING)	TATA spare parts
282931238202	CROSS MEMBER BS6	TATA spare parts
282931238221	CAB SUPPORT LH BS6	TATA spare parts
282931240111	ASSY. CROSS MEMBER GEARBOX MTG. BS6	TATA spare parts
282931240116	ASSY CROSS MEMBER COMPLETE (GEARBOX MOU	TATA spare parts
282931240170	ASSY. CROSSMEMBER (GEAR BOX MTG) BS2/3/4	TATA spare parts
282931240171	ASSY CROSS MEMBER (GEAR BOX MTG.)	TATA spare parts
282931248283	CROSS MEMBER GEAR BOX MTG BS6	TATA spare parts
282931248284	BASE PLATE SUPPORT GEARBOX MTG BS6	TATA spare parts
282931248285	REINFORCEMENT CROSS MEMBER BS6	TATA spare parts

282932100106	ASSY FRONT SPRING PARABOLIC	TATA spare parts
282932100115	ASSY. BUMP STOPPER-FRONT	TATA spare parts
282932100116	ASSY FRONT SPRING PARABOLIC	TATA spare parts
282932100122	ASSY.FRONT SPRING HANGER BRACKET(FR FR)	TATA spare parts
282932100124	ASSY SHACKLE	TATA spare parts
282932100129	ASSY FRONT SPRING	TATA spare parts
282932100130	BRACKET ASSY FRONT SPRING HANGER REAR	TATA spare parts
282932100132	ASSY FRONT SPRING PARABOLIC	TATA spare parts
282932100133	ASSY FIRST LEAF WITH BUSH	TATA spare parts
282932100134	ASSY. FRONT SPRING PARABOLIC BS2/3/4	TATA spare parts
282932100135	FIRST LEAF WITH BUSH	TATA spare parts
282932100138	ASSY FRONT SPRING PARABOLIC	TATA spare parts
282932100139	ASSY. FIRST LEAF WITH BUSH BS2/3/4	TATA spare parts
282932100139DF	MAIN LEAF FRONT W/BUSH-ACE/MAGIC BS3/4	TATA spare parts
282932100148	ASSY SHACKLE	TATA spare parts
282932100151	ASSY. FRONT SPRING PARABOLIC	TATA spare parts
282932100152	ASSY FIRST LEAF WITH BUSH	TATA spare parts
282932100158	ASSY. FRONT LEAF SPRING PARABOLIC	TATA spare parts
282932103202	CENTER BOLT	TATA spare parts
282932104201	U BOLT FRONT SPRING	TATA spare parts
282932104202	U BOLT FOR FR SUSP SPRING 10X1.5PX190L	TATA spare parts
282932104203	CLIP	TATA spare parts
282932104205	CLIP	TATA spare parts
282932107106	GUIDE PLATE FRONT	TATA spare parts
282932107108	GUIDE PLATE FRONT	TATA spare parts
282932107110	SECOND LEAF	TATA spare parts
282932107112	SECOND LEAF	TATA spare parts
282932107114	SECOND LEAF FRONT SPRING BS2/3/4	TATA spare parts
282932107114DF	SECOND LEAF FRONT-ACE/MAGIC BS3/4	TATA spare parts
282932107121	FIRST LEAF	TATA spare parts
282932107122	SECOND LEAF	TATA spare parts
282932107703	RUBBER BUFFER FRONT	TATA spare parts
282932107704	TIP INSERT	TATA spare parts
282932107705	RUBBER PAD FRONT SPRING	TATA spare parts
282932107706	CENTER PAD	TATA spare parts
282932108212	SHACKLE	TATA spare parts
282932108238	BASE PLATE FRONT BUMP STOPPER	TATA spare parts
282932109207	WASHER 17 ID. BS2/3/4/6	TATA spare parts
282932300101	ASSY FRONT SHOCK ABSORBER	TATA spare parts
282932300110	ASSY FRONT SHOCK ABSORBER	TATA spare parts
282932300115	ASSY FRONT SHOCK ABSORBER	TATA spare parts
282932300118	ASSY FRONT SHOCK ABSORBER	TATA spare parts
282932300119	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
282932300120	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
282932300123	ASSY BRACKET S/A MOUNTING FRONT TOP	TATA spare parts
282932300124	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
282932300128	ASSY. FRONT SHOCK ABSORBER BS2/3/4	TATA spare parts

282932300129	ASSY FRONT SHOCK ABSORBER	TATA spare parts
282932308236	WASHER	TATA spare parts
282932309201	SPACER(FRT&S/A&MTG&TOP) BS6	TATA spare parts
282932400112	ASSY. GUIDE PLATE LH-REAR SPRING	TATA spare parts
282932400113	ASSY. GUIDE PLATE RH-REAR SPRING	TATA spare parts
282932400134	ASSY. REAR SPRING PARABOLIC	TATA spare parts
282932400135	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
282932400141	ASSY. REAR SPRING PARABOLIC	TATA spare parts
282932400143	ASSY. REAR SPRING PARABOLIC	TATA spare parts
282932400145	ASSY REAR SPRING PARABOLIC	TATA spare parts
282932400147	ASSY REAR SPRING PARABOLIC	TATA spare parts
282932400148	ASSY FIRST LEAF WITH BUSH	TATA spare parts
282932400152	ASSY REAR SPRING PARABOLIC	TATA spare parts
282932400153	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
282932400153DF	MAIN LEAF REAR W/BUSH--ACE/MAGIC BS3/4	TATA spare parts
282932400156	ASSY GUIDE PLATE LH (REAR SPRING)	TATA spare parts
282932400157	ASSY GUIDE PLATE RH (REAR SPRING)	TATA spare parts
282932400183	ASSY.RR SPRING SEMI-ELLIPTICAL	TATA spare parts
282932400184	FIRST LEAF WITH BUSH	TATA spare parts
282932403201	CENTRE BOLT	TATA spare parts
282932403202	HEX FLANGE BOLT	TATA spare parts
282932403401	SPRING BUSH BS2/3/4/6	TATA spare parts
282932403402	BI-METALIC SPRING BUSH	TATA spare parts
282932404201	CLIP WITH PAD FRONT	TATA spare parts
282932404202	CLIP WITH PAD REAR	TATA spare parts
282932404203	U BOLT REAR (M10 X 1.5 X 175)	TATA spare parts
282932406701	SPRING PIN-FRONT	TATA spare parts
282932406702	SPRING PIN-REAR BS2/3/4/6	TATA spare parts
282932407128	SECOND LEAF	TATA spare parts
282932407129	THIRD LEAF	TATA spare parts
282932407134	SECOND LEAF	TATA spare parts
282932407135	THIRD LEAF	TATA spare parts
282932407137	SECOND LEAF	TATA spare parts
282932407137DF	SECOND LEAF REAR-ACE/MAGIC BS3/4	TATA spare parts
282932407138	THIRD LEAF	TATA spare parts
282932407138DF	THIRD LEAF REAR-ACE/MAGIC BS3/4	TATA spare parts
282932407177	FIRST LEAF	TATA spare parts
282932407178	SECOND LEAF	TATA spare parts
282932407178DF	SECOND LEAF REAR-ACE GOLD/MAGIC EXP BS3/	TATA spare parts
282932407179	THIRD LEAF	TATA spare parts
282932407179DF	THIRD LEAF REAR-ACE GOLD/MAGIC EXP BS3/4	TATA spare parts
282932407180	FOURTH LEAF	TATA spare parts
282932407180DF	FOURTH LEAF REAR-ACE GOLD/MAGIC EXP BS3/	TATA spare parts
282932407181	FIFTH LEAF	TATA spare parts
282932407181DF	FIFTH LEAF REAR-ACE GOLD/MAGIC EXP BS3/4	TATA spare parts
282932407701	TIP INSERT REAR SPRING NYLON	TATA spare parts
282932407703	WEAR PAD REAR SPRING RUBBER	TATA spare parts

282932407706	CENTRE PAD	TATA spare parts
282932407707	TIP INSERT (RUBBER)	TATA spare parts
282932409206	WASHER	TATA spare parts
282932500101	ASSY.BUMP STOPPER REAR	TATA spare parts
282932500102	ASSY. BUMP STOPPER REAR BS2/3/4/6	TATA spare parts
282932504201	U CLAMP REAR	TATA spare parts
282932504202	U CLAMP REAR	TATA spare parts
282932600102	ASSY REAR SHOCK ABSORBER	TATA spare parts
282932600104	ASSY REAR SHOCK ABSORBER	TATA spare parts
282932600106	ASSY. REAR SHOCK ABSORBER BS2/3/4	TATA spare parts
282932600109	ASSY REAR SHOCK ABSORBER	TATA spare parts
282932600111	ASSY REAR SHOCK ABSORBER	TATA spare parts
282932600115	ASSY. REAR SHOCK ABSORBER	TATA spare parts
282932606706	PIN (REAR S/A MOUNTING TOP)	TATA spare parts
282932606707	PIN (REAR S/A MOUNTING TOP)	TATA spare parts
282932800117	ANTIROLL BAR MTG. BKT.	TATA spare parts
282932800119	LINK ASSY. (FRONT ARB)	TATA spare parts
282932800120	FRONT ANTIROLL BAR ASSY.	TATA spare parts
282932800124	ANTI ROLL BAR WITH CRIMPED RING FRONT BS	TATA spare parts
282932806905	SLEEVE	TATA spare parts
282932806906	SLEEVE (FRONT ARB LINK)	TATA spare parts
282932806907	INNER SLEEVE (FRONT ARB LINK)	TATA spare parts
282932806909	SLEEVE (REAR ARB LINK)	TATA spare parts
282932806911	INNER SLEEVE (FRONT ARB LINK)	TATA spare parts
282932807708	BEARING BLOCK (FRONT ARB)	TATA spare parts
282932807709	RUBBER BUSH BS3/4/6	TATA spare parts
282932807711	RUBBER BUSH (FRONT ARB) BS3/4	TATA spare parts
282932807712	BEARING BLOCK REAR ANTI ROLL BAR (ACE DI	TATA spare parts
282932807907	ANTI ROLL BAR FRONT BS6	TATA spare parts
282932900103	ASSY. RR. ANTI ROLL BAR COMPLETE	TATA spare parts
282932908205	CLAMP ANTIROLL BAR MTG BRACKET	TATA spare parts
282933000106	ASSY FRONT AXLE	TATA spare parts
282933000107	ASSY. FRONT AXLE TUBE-NORMAL	TATA spare parts
282933000117	ASSY. FRONT AXLE	TATA spare parts
282933000118	ASSY FRONT AXLE	TATA spare parts
282933000121	ASSY. FRONT AXLE TUBE (NORMAL)	TATA spare parts
282933000123	FRONT AXLE TUBE ASSY	TATA spare parts
282933000125	FRONTAXLETUBEASSY BS6	TATA spare parts
282933000161	FRONT AXLE ASSY	TATA spare parts
282933103702	FRONT HUB BS2/3/4	TATA spare parts
282933103704	FRONT HUB	TATA spare parts
282933109902	COTTER BOLT	TATA spare parts
282933200130	ASSY KING PIN CAP	TATA spare parts
282933200133	ASSY. STUB AXLE WITH BUSH RH-NORMAL	TATA spare parts
282933200134	ASSY. STUB AXLE WITH BUSH LH-NORMAL	TATA spare parts
282933200135	ASSY KING PIN CAP	TATA spare parts
282933200142	ASSY. STUB AXLE WITH BUSH LH (NORMAL)	TATA spare parts

282933200143	ASSY. STUB AXLE WITH RH (NORMAL)	TATA spare parts
282933200150	STUB AXLE WITH BUSH RH (NORMAL)	TATA spare parts
282933200151	STUB AXLE WITH BUSH LH (NORMAL)	TATA spare parts
282933203209	FLANGE BOLT	TATA spare parts
282933203402	BUSH KING PIN BS2/3/4/6	TATA spare parts
282933206709	KING PIN-NORMAL BS2/3/4	TATA spare parts
282933206711	KING PIN (REPAIR-I)	TATA spare parts
282933206712	KING PIN (REPAIR-II)	TATA spare parts
282933208610	SPACER TUBE	TATA spare parts
282933208611	SHIM 0.1 THK-KING PIN	TATA spare parts
282933208612	SHIM 0.2 THK-KING PIN	TATA spare parts
282933208613	SHIM 0.3 THK-KING PIN	TATA spare parts
282933208614	SHIM 0.4 THK-KING PIN	TATA spare parts
282933208615	SHIM 0.5 THK-KING PIN	TATA spare parts
282933208616	SHIM 0.6 THK-KING PIN	TATA spare parts
282933208617	SHIM 0.7 THK-KING PIN	TATA spare parts
282933208618	SHIM 0.1 THK SPACER	TATA spare parts
282933208619	SHIM 0.15 THK-SPACER	TATA spare parts
282933208620	SHIM 0.20 THK SPACER	TATA spare parts
282933208621	SHIM 0.25 THK SPACER	TATA spare parts
282933208622	SHIM 0.30 THK-SPACER	TATA spare parts
282933208623	SHIM 0.4 THK-SPACER	TATA spare parts
282933208624	SHIM 0.5 THK-SPACER	TATA spare parts
282933208625	SHIM 0.6 THK-SPACER	TATA spare parts
282933208626	SHIM 0.7 THK SPACER	TATA spare parts
282933209902	KING PIN CAP	TATA spare parts
282933209903	GREASE NIPPLE	TATA spare parts
282933401602	OIL SEAL	TATA spare parts
282933403105	TAPER ROLLER BRG. 320/32 BS2/3/4	TATA spare parts
282933403106	THRUST BEARING (NORMAL)	TATA spare parts
282933403107	TAPER ROLLER BEARING	TATA spare parts
282933403108	THRUST BEARING 350000 BS2/3/4	TATA spare parts
282933403109	TAPER ROLLER BEARING	TATA spare parts
282933403110	TAPER ROLLER BEARING	TATA spare parts
282933403111	TAPER ROLLER BEARING	TATA spare parts
282933403115	THRUST PAD BEARING STD	TATA spare parts
282933407702	GASKET	TATA spare parts
282933407703	GASKET	TATA spare parts
282933407803	FRONT HUB OIL SEAL BS2/3/4	TATA spare parts
282933407805	OIL SEAL	TATA spare parts
282933408201	BAFFLE	TATA spare parts
282933408203	HUB COVER	TATA spare parts
282933408205	HUB COVER	TATA spare parts
282933408602	SEAL RACE-STUB AXLE	TATA spare parts
282933409203	THRUST WASHER	TATA spare parts
282933800109	ASSY. TIE ROD BS2/3/4	TATA spare parts
282933800110	TIE ROD ASSEMBLY	TATA spare parts

282933800111	ASSY TIE ROD	TATA spare parts
282933800112	TIE ROD	TATA spare parts
282933800113	ASSY. TIE ROD END RH BS2/3/4	TATA spare parts
28293380011314DF	TIE ROD END LH/RH SET-ACE/MAGIC BS3/4	TATA spare parts
282933800114	ASSY. TIE ROD END LH BS2/3/4	TATA spare parts
282933805108	STEERING ARM-12 INCH WHEEL	TATA spare parts
282933805109	STEERING ARM	TATA spare parts
282933805110	STEERING ARM (13 IN WHEEL)	TATA spare parts
282933806501	LOCK NUT LH	TATA spare parts
282933990101	BALL JOINT RH	TATA spare parts
282933990103	TIE ROD END ASSY RH BS6	TATA spare parts
282933990104	TIE ROD END ASSY LH BS6	TATA spare parts
282940100107	ASSY. WHEEL RIM BS2/3/4/6	TATA spare parts
282940100114	ASSY WHEEL RIM	TATA spare parts
282940100119	ASSY WHEEL RIM	TATA spare parts
282940100131	ASSY. WHEEL RIM BS3/4	TATA spare parts
282940100135	ASSY WHEEL RIM 5J X 14	TATA spare parts
282940100136	ASSY. WHEEL RIM 4.5J X 13 BS2/3/4	TATA spare parts
282940100138	ASSY. WHEEL RIM 4 1/2 J X 13	TATA spare parts
282940109913	TYRE 4.50-12 8PR ULT	TATA spare parts
282940109914	TUBE 4.50-12	TATA spare parts
282940109940	TUBE	TATA spare parts
282940109941	TYRE 165 R 14 LT 96Q	TATA spare parts
282940109942	TYRE 155 R13 LT	TATA spare parts
282940109943	TUBE 155 R 13 LT	TATA spare parts
282940109948	TYRE 145R12 TUBELESS	TATA spare parts
282940109951	TUBE LESS TYRE 145 R12C 8PR 86/84N	TATA spare parts
282940109952	TUBE LESS TYRE 145R12 LT 86/84Q 8PR	TATA spare parts
282940109954	155R13 8PR TYRE	TATA spare parts
282940109955	155R13 8PR TUBE	TATA spare parts
282940109963	TUBE LESS TYRE 155 R13C 8PR	TATA spare parts
282940109975	TUBELESS TYRE 155 R13	TATA spare parts
282940206501	WHEEL NUT	TATA spare parts
282940300110	ASSY. TUBE-SPARE WHEEL MTG.	TATA spare parts
282940300113	ASSY.BRACKET SPARE WHEEL LOCK	TATA spare parts
282940300117	ASSY. TUBE (SPARE WHEEL MTG.)	TATA spare parts
282940300121	ASSY.TUBE AND BRACKET (SPARE WHEEL MTG.)	TATA spare parts
282940306501	HEX NUT	TATA spare parts
282940306701	PIN (SPARE WHEEL MTG.)	TATA spare parts
282940306702	PIN (SPARE WHEEL MTG.)	TATA spare parts
282940306906	CLAMP-SPARE WHEEL MTG.	TATA spare parts
282940309905	NYLON SPACER (SPARE WHEEL MTG)	TATA spare parts
282941100106	ASSY. PROPELLER SHAFT BS2/3/4	TATA spare parts
282941100107	ASSY. PROP SHAFT	TATA spare parts
282941100108	SLIP YOKE ASSEMBLY	TATA spare parts
282941100109	UJ KIT ASSEMBLY	TATA spare parts
282941100112	ASSY.PROP SHAFT	TATA spare parts

282941100117	SLIP YOKE ASSY.	TATA spare parts
282941100118	KIT-UNIVERSAL JOINT BS2/3/4	TATA spare parts
282941100119	FLANGE YOKE	TATA spare parts
282941100120	ASSEMBLY PROPELLER SHAFT	TATA spare parts
282941100121	PROPELLER SHAFT FOR ACE WITH 5 SPEED GEA	TATA spare parts
282941100126	ASSY.PROP. SHAFT 1310 SERIES FOR 800 C	TATA spare parts
282941100127	ASSY.PROPELLER SHAFT ACE	TATA spare parts
282941100128	ASSY.PROPELLER SHAFT ACE 5 SPD	TATA spare parts
282941100129	UJ KIT ASSEMBLY	TATA spare parts
282941100135	PROPELLER SHAFT ASSY	TATA spare parts
282941100136	ASSY.PROP.SHAFT ACE	TATA spare parts
282941100137	SLIP YOKE ASSY	TATA spare parts
282941100138	CROSS ASSY	TATA spare parts
282941100138DF	UJ CROSS DIA23.8 X 60MM AAM - ACE/MAGIC	TATA spare parts
282941100139	FLANGE YOKE	TATA spare parts
282941105101	FLANG YOKE	TATA spare parts
282941108001	FITTING SCREW (PROPELLER SHAFT)	TATA spare parts
282941108201	GUARD ( FOR PROPELLER SHAFT)	TATA spare parts
282942100106	TANDEM MASTER CYL. DIA.19.05 BS2/3/4	TATA spare parts
282942100123	ASSY. BRAKE FLUID RESERVOIR	TATA spare parts
282942100124	ASSY. BRAKE FLUID RESERVOIR	TATA spare parts
282942100125	ASSY. BRAKE FLUID RESERVOIR	TATA spare parts
282942100132	CALIPER ASSEMBLY LH	TATA spare parts
282942100133	CALIPER ASSEMBLY RH	TATA spare parts
282942100134	CALIPER ASSEMBLY LH	TATA spare parts
282942100135	CALIPER ASSEMBLY RH	TATA spare parts
282942100138	ASSY.CALIPER LH	TATA spare parts
282942100139	ASSY.CALIPER RH	TATA spare parts
282942103701	VENTILATED BRAKE DISC 17 THICK BS2/3/4	TATA spare parts
282942103701DF	BRAKE DISC VENTILATED 17 THK-ACE/MAGIC B	TATA spare parts
282942103702	VENTILATED BRAKE DISC (18 THICK) BS2/3/4	TATA spare parts
282942300104	BRAKE ASSLY RH	TATA spare parts
282942300105	BRAKE ASSLY LH	TATA spare parts
282942300108	REAR BRAKE ASSY. RH NON/ASBS	TATA spare parts
282942300109	REAR BRAKE ASSY. LH NON/ASBS	TATA spare parts
282942300110	REAR BRAKE ASSY. RH NON/ASBS	TATA spare parts
282942300111	REAR BRAKE ASSY. LH NON/ASBS	TATA spare parts
282942300112	REAR BRAKE ASSY. LH NON/ASBS	TATA spare parts
282942300113	REAR BRAKE ASSY. RH NON/ASBS	TATA spare parts
282942300117	REAR BRAKE ASSY. LH NON/ASBS	TATA spare parts
282942300118	REAR BRAKE ASSY. RH NON/ASBS	TATA spare parts
282942300121	BACK PLATE ASSY. LH	TATA spare parts
282942300122	BACK PLATE ASSY. RH	TATA spare parts
282942300123	KIT-LINED SHOE BS2/3/4	TATA spare parts
282942300123DF	LINED SHOE KIT - ACE/MAGIC/SUPER ACE	TATA spare parts
282942300124	ASSY. WHEEL CYL. 15.87DIA. LH BS2/3/4	TATA spare parts
282942300125	ASSY. WHEEL CYL. 15.87 DIA. RH BS2/3/4	TATA spare parts

282942300126	KIT-MINOR ASSY.WHEEL CYL.	TATA spare parts
282942300128	BACK PLATE COMP LH	TATA spare parts
282942300129	BACK PLATE COMP RH	TATA spare parts
282942300130	ASSY. WHEEL CYLINDER LH BS2/3/4	TATA spare parts
282942300131	ASSY. WHEEL CYLINDER RH BS2/3/4	TATA spare parts
282942300132	KIT WHEEL CYLINDER-MINOR	TATA spare parts
282942300133	KIT-BRAKE SHOE BS2/3/4	TATA spare parts
282942300133DF	LINED SHOE KIT-K TYPE-ACE/MAGIC	TATA spare parts
282942300135	STRUT ASSY. RH BS4	TATA spare parts
282942300136	STRUT ASSY. LH BS4	TATA spare parts
282942300137	MAJOR KIT W/C.	TATA spare parts
282942300138	AUTO ADJUSTER KIT	TATA spare parts
282942303701	BRAKE DRUM REAR DIA. 200X30 BS2/3/4/6	TATA spare parts
282942303701DF	BRAKE DRUM - ACE/MAGIC/SUPER ACE	TATA spare parts
282942306701	PIN SHOE SET	TATA spare parts
282942308701	SPRING SHOE RETURN (ANCH. PLATE)	TATA spare parts
282942308702	RETURN SPRING-D	TATA spare parts
282942308703	STRUT SPRING LH (RH ASSY)	TATA spare parts
282942308704	STRUT SPRING RH (LH ASSY)	TATA spare parts
282942700105	ASSY. PARK. BRK CABLE RR 1060MM BS2/3/4	TATA spare parts
282942700106	PARKING BRK CABLE RR LH 1590MM BS2/3/4	TATA spare parts
282942700107	ASSY. PARK. BRK CABLE FRT 1630MM BS2/3/4	TATA spare parts
282942700108	ASSY. BRACKET (PARKING BRAKE)	TATA spare parts
282942700109	ASSY.PARKING LEVER WITH BRKT.	TATA spare parts
282942700110	ASSY. PARKING BRK LEVER W/GRIP BS2/3/4/6	TATA spare parts
282942700111	PARKING BRAKE CABLE REAR RH	TATA spare parts
282942700112	PARKING BRAKE CABLE REAR L.H	TATA spare parts
282942700113	PARKING BRAKE CABLE FRONT	TATA spare parts
282942700114	PARKING BRAKE CABLE FRONT	TATA spare parts
282942700115	PARKING BRAKE CABLE REAR L.H	TATA spare parts
282942700116	PARKING BRAKE CABLE REAR-RH	TATA spare parts
282942700117	PARKING BRAKE LEVER ASSY	TATA spare parts
282942700117C7	GRANIT_BLACK-PARKING BRAKE LEVER ASSY WI	TATA spare parts
282942700121	ASSY.PARKING BRAKE CABLE FRONT	TATA spare parts
282942700124	ASSY.PARKING BRAKE CABLE FRONT	TATA spare parts
282942700141	FRONT PARKING BRAKE CABLE ASSY-ACE 800CC	TATA spare parts
282942706001	LEVER HAND BRAKE LH	TATA spare parts
282942706002	LEVER HAND BRAKE RH	TATA spare parts
282942708204	LINK	TATA spare parts
282942708208	BRACKET (FOR PARKING BRAKE CABLE)	TATA spare parts
282942708401	SLEEVE BS6	TATA spare parts
282942800103	ASSY. FRONT BRAKE HOSE	TATA spare parts
282942800104	ASSY. REAR BRAKE HOSE	TATA spare parts
282942807501	RUBBER GROMMET (FOR BRAKE PIPES)	TATA spare parts
282942808207	BRACKET (REAR HOSE MTG. ON FRAME)	TATA spare parts
282942808209	BRACKET	TATA spare parts
282942808216	BRACKET (FRONT HOSE MOUNTING ON FRAME)	TATA spare parts



282942990103	STRUT & QUADRANT-LH & RH BS4	TATA spare parts
282942990104	KIT - HAND BRAKE LEVER LH	TATA spare parts
282942990105	KIT - HAND BRAKE LEVER RH	TATA spare parts
282942990106	KIT BLEED SCREW	TATA spare parts
282942990107	KIT-BLEED SCREW	TATA spare parts
282942990112	KIT PAD FRONT BS2/3/4	TATA spare parts
282942990112DF01	BRAKE PAD KIT FRONT - SUPER ACE	TATA spare parts
282942990112DF02	BRAKE PAD KIT FRONT - SUPER ACE	TATA spare parts
282942990116	KIT-CARRIER ASSY	TATA spare parts
282942990117	KIT-SHOE HOLD DOWN	TATA spare parts
282942990140	PAD & INDICATO ASSY	TATA spare parts
282942990142	PAD ASSY	TATA spare parts
282942990146	KIT-PAD ASSY BS2/3/4	TATA spare parts
282942990146DF	BRAKE PAD KIT - ACE DICOR/MAGIC MANTRA	TATA spare parts
282942993701	CARRIERMACHINING BS6	TATA spare parts
282943100101	TANDEM MASTER CYL. DIA.19.05	TATA spare parts
282943100102	TANDEM MASTER CYL. DIA.19.05	TATA spare parts
282943100103	MAJOR KIT-TANDEM MASTER CYL.	TATA spare parts
282943100104	MINOR KIT-TANDEM MASTER CYLINDER	TATA spare parts
282943100105	MAJOR KIT-CALIPER	TATA spare parts
282943100106	MINOR KIT-CALIPER	TATA spare parts
282943100107	KIT SLIDING PIN	TATA spare parts
282943100108	KIT-PAD ASSEMBLY	TATA spare parts
282943100113	MAJOR KIT-TMC	TATA spare parts
282943100114	PUSH ROD COMPLETE	TATA spare parts
282943100115	MINOR KIT-TMC	TATA spare parts
282943100116	NIPPLE HOLDER	TATA spare parts
282943100117	KIT CALIPER MAJOR	TATA spare parts
282943100118	KIT CALIPER MINOR	TATA spare parts
282943100119	KIT SLIDING PIN	TATA spare parts
282943100121	KIT PAD FRONT BS2/3/4	TATA spare parts
282943100122	ASSY. 6 INCH BOOSTER WITH TMC	TATA spare parts
282943100123	ASSY. 6 INCH BOOSTER WITH TMC	TATA spare parts
282943100124	ASSY. 6 INCH BOOSTER WITH TMC	TATA spare parts
282943100126	ASSY. TMC	TATA spare parts
282943100131	VACCUM BOOSTER ASSY	TATA spare parts
282943100132	TMC ASSY	TATA spare parts
282943104302	ANTIRATTLE CLIP	TATA spare parts
282943104304	PISTON STOPPER(CIRCLIP)	TATA spare parts
282943104306	PAD SPRING	TATA spare parts
282943104307	SHOE SET SPRING (LEADING)	TATA spare parts
282943104308	SHOE SET SPRING RH (TRAILING)	TATA spare parts
282943104309	SHOE SET SPRING LH(TRAILING)	TATA spare parts
282943105301	GASKET	TATA spare parts
282943106603	PISTON	TATA spare parts
282943106705	SECONDARY PISTON	TATA spare parts
282943107501	GROMMET	TATA spare parts

282943107502	RESERVOIR GROMMET	TATA spare parts
282943107702	BOOT	TATA spare parts
282943107704	BOOT RING	TATA spare parts
282943108002	BLEED SCREW	TATA spare parts
282943108004	NIPPLE HOLDER BOLT	TATA spare parts
282943108006	BLEEDER	TATA spare parts
282943108302	FILLER UNION	TATA spare parts
282943500101	ASSY. VACUUM PUMP	TATA spare parts
282943500102	ASSY. VACUUM PUMP	TATA spare parts
282943500103	ASSY. VACUUM HOSE ENGINE END	TATA spare parts
282943500105	ASSY. PIPE	TATA spare parts
282943505801	HOSE VACUUM BS6	TATA spare parts
282943505802	HOSE VACUUM II	TATA spare parts
282943800102	ASSY. FRONT BRAKE HOSE	TATA spare parts
282943800103	ASSY. REAR BRAKE HOSE	TATA spare parts
282943800104	ASSY. REAR BRAKE HOSE	TATA spare parts
282943800105	ASSY. FRONT BRAKE HOSE	TATA spare parts
282943800106	ASSY. PIPE	TATA spare parts
282943800107	ASSY. PIPE	TATA spare parts
282943800108	ASSY. PIPE	TATA spare parts
282943800109	ASSY. PIPE	TATA spare parts
282943800110	ASSY. PIPE LH TMC TO CONNECTOR	TATA spare parts
282943800111	ASSY PIPE LH CONNECTOR TO RR BR HOSE	TATA spare parts
282943800112	ASSY PIPE LH RR BR HOSE TO RR WH CYL	TATA spare parts
282943800113	ASSY. PIPE RH TMC TO CONNECTOR	TATA spare parts
282943800114	ASSY PIPE RH CONNECTOR TO RR BR HOSE	TATA spare parts
282943800115	ASSY PIPE RH RR BR HOSE TO RR WH CYL	TATA spare parts
282943800117	BRACKET ASSY BRAKE PIPE CLAMPING BS6	TATA spare parts
282943800130	ASSY BRACKET	TATA spare parts
282943800132	ASSY. TUBE	TATA spare parts
282943800134	ASSY. TUBE	TATA spare parts
282943800135	ASSY. TUBE	TATA spare parts
282943800136	ASSY. TUBE	TATA spare parts
282943800137	ASSY. TUBE	TATA spare parts
282943800138	ASSY. TUBE	TATA spare parts
282943800139	ASSY. TUBE	TATA spare parts
282943800140	ASSY. TUBE	TATA spare parts
282943800141	ASSY. TUBE	TATA spare parts
282943800142	ASSY. TUBE	TATA spare parts
282943800144	ASSY. TUBE	TATA spare parts
282943800145	ASSY. REAR BRAKE HOSE	TATA spare parts
282943800154	REAR BRAKE PIPE - LH (CONNECTOR TO REAR	TATA spare parts
282943800157	FRONT BRAKE HOSE ASSY	TATA spare parts
282943800158	REAR BRAKE HOSE ASSY	TATA spare parts
282943800159	ASSY. BRAKE PIPE	TATA spare parts
282943800162	REAR BRAKE PIPE - RH (REAR BRAKE HOSE TO	TATA spare parts
282943800163	REAR BRAKE PIPE - LH (REAR BRAKE HOSE TO	TATA spare parts

282943800182	ASSY. PIPE	TATA spare parts
282943800183	ASSY. PIPE	TATA spare parts
282943800194	ASSY PIPE	TATA spare parts
282943800195	ASSY PIPE	TATA spare parts
282943800196	ASSY.PIPE	TATA spare parts
282943800197	ASSY.PIPE	TATA spare parts
282943800198	ASSY.PIPE	TATA spare parts
282943800199	ASSY.PIPE	TATA spare parts
282943806916	TUBE OD 10X0.7 THK. SS:4040-20 OR 30	TATA spare parts
282943806992	TUBE OD 10X0.7 THK. SS:4040-20 OR 30	TATA spare parts
282943807501	RUBBER GROMMET (FOR VACUUM PIPE)	TATA spare parts
282943807701	HOSE	TATA spare parts
282943807702	HOSE	TATA spare parts
282943807704	HOSE	TATA spare parts
282943807705	VACUUM HOSE ENGINE SIDE	TATA spare parts
282943807710	HOSE - VACUUM ENGINE SIDE	TATA spare parts
282943808202	BRACKET (BRAKE PIPE CLAMPING)	TATA spare parts
282943810105	ASSY. PIPE	TATA spare parts
282943810106	ASSY. PIPE	TATA spare parts
282943810107	ASSY. PIPE	TATA spare parts
282943810109	ASSY. PIPE	TATA spare parts
282943810111	ASSY. PIPE WITH ADAPTOR	TATA spare parts
282943810112	ASSY. PIPE WITH ATAPTOR	TATA spare parts
282943810113	ASSY. PIPE WITH ADAPTOR	TATA spare parts
282943810114	ASSY. PIPE WITH ADAPTOR	TATA spare parts
282943810115	ASSY. PIPE WITH ADAPTOR	TATA spare parts
282943810116	ASSY. PIPE WITH ATAPTOR	TATA spare parts
282943810127	TUBE ASSY ADAPTOR TO CALIPER LH	TATA spare parts
282943810130	ASSY. PIPE	TATA spare parts
282943810131	ASSY. PIPE	TATA spare parts
282943810132	MASTER CYLINDER TO REAR BRAKE PIPE RH	TATA spare parts
282943810134	MASTER CYLINDER TO REAR BRAKE PIPE LH	TATA spare parts
282943810136	MASTER CYLINDER TO FRONT BRAKE PIPE RH	TATA spare parts
282943810138	MASTER CYLINDER TO FRONT BRAKE PIPE LH	TATA spare parts
282943810143	ASSY. PIPE (BRAKE PIPE)	TATA spare parts
282943810144	ASSY. PIPE (BRAKE PIPE)	TATA spare parts
282943810147	ASSY. PIPE	TATA spare parts
282943810148	ASSY. PIPE	TATA spare parts
282943810152	ASSY. PIPE	TATA spare parts
282943810153	ASSY. PIPE	TATA spare parts
282943810154	ASSY. PIPE	TATA spare parts
282943810155	ASSY. PIPE	TATA spare parts
282943810156	ASSY PIPE	TATA spare parts
282943810157	ASSY PIPE	TATA spare parts
282943990102	M.C. KIT (MINOR)	TATA spare parts
282943990103	M.C. KIT (MAJOR)	TATA spare parts
282943990105	MINOR KIT- TANDEM MASTER CYLINDER	TATA spare parts

282946100104	ASSY. STEERING COLUMN BS2/3/4	TATA spare parts
282946100105	ASSY STEERING COLUMN	TATA spare parts
282946100106	ASSY STEERING COLUMN	TATA spare parts
282946100107	YOKE ASSEMBLY	TATA spare parts
282946100112	LOWER SHAFT W/SHEET METAL YOKE BS2/3/4	TATA spare parts
282946100114	ASSY STEERING COLUMN-LHD	TATA spare parts
282946100117	UPPER COLUMN ASSY	TATA spare parts
282946100118	LOWER SHFT ASSY	TATA spare parts
282946107901	I-SHAFT	TATA spare parts
282946200104	ASSY.STG.GEAR BOX	TATA spare parts
282946200105	BOX SUB ASSEMBLY	TATA spare parts
282946200106	WORM AND NUT ASSEMBLY	TATA spare parts
282946200112	ASSY. STG. GEAR BOX	TATA spare parts
282946200115	TOP BEARING ASSEMBLY	TATA spare parts
282946200116	BOTTOM BEARING ASSEMBLY	TATA spare parts
282946200117	BOX SUB ASSEMBLY	TATA spare parts
282946200120	ASSY. STEERING RUBBER BELLOW	TATA spare parts
282946200121	BALL AND NUT-TYPE STEERING GEAR ASSEMBLY	TATA spare parts
282946200122	REPAIR KIT FOR STRG GEAR ASSY 0121	TATA spare parts
282946200126	ASSY. STG. GEAR BOX	TATA spare parts
282946200129	ASSY. STEERING GEAR BOX ( VARIABLE RATIO	TATA spare parts
282946203002	STEEL BALLS (9/32 INCH)	TATA spare parts
282946203003	SPHERICAL ROLLER	TATA spare parts
282946203201	ADJUSTER	TATA spare parts
282946203202	BOLT	TATA spare parts
282946203501	ADJ.BALL RACE (TOP)	TATA spare parts
282946203502	ADJ. BALL RACE (BOTTOM)	TATA spare parts
282946206001	DROPPARM	TATA spare parts
282946206305	FOAM PACKING	TATA spare parts
282946206501	LOCK NUT	TATA spare parts
282946206502	LOCK NUT	TATA spare parts
282946206503	LOCK NUT -ADJUSTER SCREW	TATA spare parts
282946206504	LOCK NUT ROCKER SHAFT	TATA spare parts
282946207101	END PLATE	TATA spare parts
282946207201	OIL PLUG	TATA spare parts
282946207703	RUBBER BELLOW	TATA spare parts
282946207704	RUBBER BELLOW	TATA spare parts
282946207801	OIL SEAL	TATA spare parts
282946207802	OIL SEAL	TATA spare parts
282946207803	DUST SEAL	TATA spare parts
282946207804	OILSEAL	TATA spare parts
282946207805	OIL SEAL	TATA spare parts
282946207806	DUST SEAL	TATA spare parts
282946207807	OIL SEAL SCREW SHAFT	TATA spare parts
282946207808	OIL SEAL SECTOR SHAFT	TATA spare parts
282946207902	ROCKER SHAFT	TATA spare parts
282946207903	ROCKER SHAFT	TATA spare parts

282946208207	COVER SHEET	TATA spare parts
282946208212	COVER SHEET	TATA spare parts
282946208301	SHIMS (0.010 INCH)	TATA spare parts
282946208302	SHIMS (0.005 INCH)	TATA spare parts
282946208303	SHIMS (0.003 INCH)	TATA spare parts
282946208304	SHIMS(0.001 INCH)	TATA spare parts
282946209201	SPRING WASHER	TATA spare parts
282946209202	SPRING WASHER	TATA spare parts
282946209203	JOINT WASHER	TATA spare parts
282946209204	JOINT WASHER COVERPLATE	TATA spare parts
282946209205	SPRING WASHER(DROP ARM)	TATA spare parts
282946400107	ASSY. STEERING WHEEL BS2/3/4/6	TATA spare parts
282946400108	ASSY STEERING WHEEL	TATA spare parts
282946400109	ASSY. STEERING WHEEL	TATA spare parts
282946400109C7	GRANIT_BLACK-ASSY. STEERING WHEEL WITHOU	TATA spare parts
282946400110	ASSY. STEERING WHEEL	TATA spare parts
282946400111	ASSY. STEERING WHEEL WITHOUT T EMBLEM	TATA spare parts
282946406301	T EMBLEM	TATA spare parts
282946406302	T EMBLEM-BEIGE B002 COLOUR	TATA spare parts
282946600108	ASSY. DRAG LINK BS2/3/4/6	TATA spare parts
282946600109	ASSY DRAG LINK	TATA spare parts
282946600110	ASSY.DRAG LINK	TATA spare parts
282946600111	DRAG LINK END ASSY. RH	TATA spare parts
282946600112	RESERVOIR - ASSY POWER STEERING	TATA spare parts
282946600116	ASSY.DRAG LINK	TATA spare parts
282946600127	ASSY. RESERVOIR	TATA spare parts
282946600130	ASSY.DRAG LINK	TATA spare parts
282946600132	DRAG LINK ASSEMBLY-LHD	TATA spare parts
282946600134	RESERVOIR COVER ASSY	TATA spare parts
282946600137	RESERVOIR FILTER ASSY	TATA spare parts
282946600139	ASSY. BALL JOINT DRAG LINK	TATA spare parts
282946604301	BOOT CLIP	TATA spare parts
282946606501	LOCK NUT	TATA spare parts
282946606502	SLOTTED NUT	TATA spare parts
282946607701	BOOT	TATA spare parts
282946990101	UPPER COLUMN ASSY	TATA spare parts
282946990102	I-SHAFT ASSY	TATA spare parts
282946990106	BOX SUB ASSEMBLY	TATA spare parts
282946990107	WORM & NUT SUB ASSEMBLY	TATA spare parts
282946990108	ASSY BALL JOINT THREADED	TATA spare parts
282946990109	TUBEASSY&BALLJOINT(CRIMPEDEND) BS6	TATA spare parts
282946993001	SPHERICAL ROLLER	TATA spare parts
282946993002	BALL BEARING	TATA spare parts
282946993003	BALL BEARING	TATA spare parts
282946993201	M8 BOLT	TATA spare parts
282946994701	COVER PLATE	TATA spare parts
282946994702	END PLATE	TATA spare parts

282946995101	DROP ARM	TATA spare parts
282946996501	LOCK NUT (ADJUSTER)	TATA spare parts
282946996502	LOCK NUT (R/S)	TATA spare parts
282946997201	OIL PLUG	TATA spare parts
282946997801	OIL SEAL-WORMEND	TATA spare parts
282946997802	DUST SEAL	TATA spare parts
282946997901	ROCKER SHAFT MACHINED	TATA spare parts
282946998001	ADJUSTER SCREW	TATA spare parts
282946998301	SHIM 0.010 IN	TATA spare parts
282946998302	SHIM 0.005 IN	TATA spare parts
282946998303	SHIM 0.003 IN	TATA spare parts
282946999201	M8 SPRING WASHER	TATA spare parts
282946999202	SPRING WASHER	TATA spare parts
282947100121	ASSY BRACKET (FUEL FILTER MTG)	TATA spare parts
282947100137	ASSY FUEL TANK COMPLETE-30 LITRES	TATA spare parts
282947100139	ASSEMBLY STRAP FUEL FILTER MOUNTING	TATA spare parts
282947100143	ASSY. FILLER NECK	TATA spare parts
282947100148	FUEL TANK STRAP & RUBBER	TATA spare parts
282947100153	ASSY. FUEL TANK COMPLETE (30 LIT)	TATA spare parts
282947100155	FILLER NECK ASSY.	TATA spare parts
282947100157	ASSY. FUEL TANK COMPLETE BS2/3/4	TATA spare parts
282947100158	ASSY. FILLER NECK	TATA spare parts
282947100169	ASSY PRE-FILTER FOR ACE	TATA spare parts
282947100170	ASSY FUEL TANK W/O TANK UNIT	TATA spare parts
282947100172	ASSY. FUEL TANK COMPLETE(28 LITRES)	TATA spare parts
282947100176	FUEL TANK ASSY	TATA spare parts
282947100177	ASSY. FUEL TANK COMPLETE	TATA spare parts
282947100178	ASSY. TANK UNIT BS3/4	TATA spare parts
282947100184	FUEL FILTER (FWS) ELEMENT BS2	TATA spare parts
282947100186	ASSY FUEL TANK COMPLETE (30 LITRES)	TATA spare parts
282947100188	ASSY. FUEL TANK COMPLETE (30 LITRES)	TATA spare parts
282947100190	FUEL PUMP MODULE BS4	TATA spare parts
282947106909	TUBE BS6	TATA spare parts
282947107704	FUEL HOSE	TATA spare parts
282947107705	FUEL HOSE-FUEL FILLING	TATA spare parts
282947107706	FUEL HOSE	TATA spare parts
282947107707	HOSE (FUEL FILLING)	TATA spare parts
282947107708	FUEL HOSE	TATA spare parts
282947107709	SEAL (FILLER/BREATHER HOSE)	TATA spare parts
282947107710	RUBBER GROMMET (VENT TUBE)	TATA spare parts
282947107712	RUBBER GROMMET (FUEL LINE)	TATA spare parts
282947107715	FUEL HOSE	TATA spare parts
282947108212	BRACKET BS6	TATA spare parts
282947108223	BRACKET (FUEL LINES)	TATA spare parts
282947108266	BRACKET (FUEL LINES)	TATA spare parts
282947108292	COVER (FOR FILLING NOZZLE)	TATA spare parts
282947109903	35 LIT. CNG CYLINDER	TATA spare parts

282947109905	70 LIT. CNG CYLINDER	TATA spare parts
282947109906	CNG CYLINDER 35 LIT.	TATA spare parts
282947109908	35 LIT. CNG CYLINDER (M/S.JAY-FE)	TATA spare parts
282947500103	ASSY. STRAP	TATA spare parts
282947500104	ASSY. STRAP	TATA spare parts
282947500105	ASSY. STRAP (CYLINDER MTG.)	TATA spare parts
282947500116	ASSY. BRACKET (FILLING NOZZLE MTG.) BS6	TATA spare parts
282947500128	ASSY. BRACKET WITH WELDED MESH (PRESSURE	TATA spare parts
282947500132	ASSY. BRACKET (CYLINDER MTG.)	TATA spare parts
282947500140	ASSY FILLING NOZZLE (RECEPTACLE) WITH TE	TATA spare parts
282947500146	FUEL TANK STRAP & RUBBER (FOR MAGIC)	TATA spare parts
282947507701	RUBBER PACKING	TATA spare parts
282947507702	RUBBER PACKING	TATA spare parts
282947507704	RUBBER PACKING	TATA spare parts
282947507705	RUBBER PACKING	TATA spare parts
282947507706	RUBBER PACKING	TATA spare parts
282947507708	RUBBER PACKING (ASSY. STRAP MTG.)	TATA spare parts
282947507709	RUBBER PACKING (LATERAL CYL. STOPPER)	TATA spare parts
282947507710	RUBBER PACKING	TATA spare parts
282947508209	COMPLIANCE PLATE	TATA spare parts
282947600104	FUEL LINE FUEL TANK TO FILTER BS2/3/4	TATA spare parts
282947600105	FUEL LINE FIP TO FUEL TANK BS2/3/4	TATA spare parts
282947600106	FUEL LINE FILTER TO FIP BS2/3/4	TATA spare parts
282947600108	ASSY. NYLON FUEL LINE	TATA spare parts
282947600117	FUEL LINE FIP TO FUEL TANK	TATA spare parts
282947600118	FUEL LINE FUEL TANK TO FILTER	TATA spare parts
282947600119	FUEL LINE FILTER TO FIP	TATA spare parts
282947600120	ASSY. FUEL LINE	TATA spare parts
282947600129	ASSY. COOLER LOOP (FUEL RETURN LINE)	TATA spare parts
282947600131	ASSY¿ COOLER LOOP (FUEL RETURN LINE)	TATA spare parts
282947600136	ASSY RETURN LINE 1	TATA spare parts
282947600137	ASSY SUCTION LINE(TANK TO FILTER) 1	TATA spare parts
282947600138	FUEL SUCT. PIPE 1183MM FILTER -FIP BS3/4	TATA spare parts
282947600139	ASSY FUEL LINES WITH CLAMPS	TATA spare parts
282947600141	ASSY SUCTION LINE	TATA spare parts
282947600142	ASSY SUCTION LINE	TATA spare parts
282947600143	ASSY RETURN LINE	TATA spare parts
282947600145	ASSY SUCTION LINE	TATA spare parts
282947600146	FUEL SUCTION PIPE ASSY	TATA spare parts
282947600147	FUEL RETURN PIPE ASSY	TATA spare parts
282947600148	FUEL PIPE ASSY	TATA spare parts
282947600149	FUEL SUCTION PIPE ASSY	TATA spare parts
282947600150	FUEL SUCTION PIPE ASSY	TATA spare parts
282947600151	FUEL RETURN PIPE ASSY	TATA spare parts
282947600169	FUEL SUCTION PIPE ASSY	TATA spare parts
282947600176	FUEL SUCTION PIPE ASSY	TATA spare parts
282947600177	FUEL SUCTION PIPE ASSY	TATA spare parts

282947600178	FUEL RETURN PIPE ASSY	TATA spare parts
282947600184	FUEL RETURN PIPE ASSY	TATA spare parts
282947600185	FUEL SUCTION PIPE ASSY	TATA spare parts
282947600187	FUEL SUCTION PIPE ASSY	TATA spare parts
282947600188	FUEL SUCTION PIPE ASSY	TATA spare parts
282947600189	FUEL SUCT. PIPE L=882 FILTER -FIP BS3/4	TATA spare parts
282947600197	FUEL SUCTION PIPE ASSY	TATA spare parts
282947600198	FUEL RETURN PIPE ASSY	TATA spare parts
282947600199	FUEL RETURN PIPE ASSY	TATA spare parts
282947604201	CLAMP	TATA spare parts
282947604202	CLAMP	TATA spare parts
282947604206	CLAMP (H.P. PIPE CLAMPING)	TATA spare parts
282947604208	CLAMP (L.P.HOSE)	TATA spare parts
282947604209	CLAMP (H.P.PIPE CLAMPING)	TATA spare parts
282947604210	CLAMP (L.P.FILTER)	TATA spare parts
282947604213	P CLAMP	TATA spare parts
282947604214	DOUBLE P CLAMP	TATA spare parts
282947604215	DOUBLE P CLAMP (HEATING LINE)	TATA spare parts
282947604216	COATED CLAMP (10X10)	TATA spare parts
282947605815	HOSE HEATING LINE (ENGINE TO REGULATOR)	TATA spare parts
282947605816	HOSE HEATING LINE (REGULATOR TO RADIATOR)	TATA spare parts
282947605817	HOSE (HEATING LINE-ENGINE TO REGULATOR)	TATA spare parts
282947605818	HOSE (HEATING LINE-REGULATOR TO BYPASS T	TATA spare parts
282947605819	HOSE (HEATING LINE-ENGINE TO REGULATOR)	TATA spare parts
282947605820	HOSE (HEATING LINE-REGULATOR TO BYPASS T	TATA spare parts
282947606806	NZS NOZZLE NUT	TATA spare parts
282947606807	PRESSURE GAUGE TEE (1/4 INCH)	TATA spare parts
282947606809	HP INLET FITTING	TATA spare parts
282947606810	OUTLET LP FITTING	TATA spare parts
282947606811	PRESSURE GAUGE TEE FORç FILLING RECEPTAC	TATA spare parts
282947606812	NUT (FOR FILLING RECEPTACLE )	TATA spare parts
282947606813	UNION ELBOW (1/4IN O.D X1/4IN O.D)	TATA spare parts
282947607710	TUBE HOLDER	TATA spare parts
282947607711	TUBE HOLDER BS6	TATA spare parts
282947607712	TUBE HOLDER	TATA spare parts
282947607713	TUBE HOLDER	TATA spare parts
282947608222	PLATE (BOTTOM)	TATA spare parts
282947608223	PLATE (BOTTOM)	TATA spare parts
282947608224	PLATE (BOTTOM) BS6	TATA spare parts
282947608242	BRACKET (HP PIPE CLAMPING)	TATA spare parts
282947608244	PLATE (BOTTOM)	TATA spare parts
282947608246	BRACKET (H.P. PIPE COVER WHEEL ARCH)	TATA spare parts
282947609201	SEALING WASHER (PRESSURE GAUGE)	TATA spare parts
282947609903	PROTECTIVE COVER (LOW PRESSURE HOSE)	TATA spare parts
282947609904	PROTECTIVE COVER (LOW PRESSURE HOSE)	TATA spare parts
282947609905	PROTECTIVE COVER (LOW PRESSURE HOSE)	TATA spare parts
282947610102	CNG CYLINDER VALVE	TATA spare parts



282947610104	ASSY. LOW PRESSURE PIPE	TATA spare parts
282947610105	HEATING LINE (REGULATOR TO RADIATOR)	TATA spare parts
282947610106	HEATING LINE (ENGINE TO REGULATOR)	TATA spare parts
282947610110	ASSY. H.P. GAS TUBE (FILTER TO REGULATOR)	TATA spare parts
282947610128	CNG CYLINDER VALVE	TATA spare parts
282947610135	CNG CYLINDER VALVE	TATA spare parts
282947610138	ASSY. H.P. GAS TUBE (FILLING NOZZLE TO H	TATA spare parts
282947610139	ASSY. H.P. GAS TUBE (REAR CYLINDER TO FR	TATA spare parts
282947610140	ASSY. H.P GAS TUBE (FILLING NOZZLE TO RE	TATA spare parts
282947610141	ASSY. VENTING TUBE (REAR CYLINDER.)	TATA spare parts
282947610142	ASSY. VENTING TUBE (FRONT CYLINDER).	TATA spare parts
282947610143	ASSY. VENTING TUBE (REAR TEE TO FRONT TE	TATA spare parts
282947610144	ASSY. VENTING TUBE (PRESSURE REGULATOR)	TATA spare parts
282947610146	ASSY. VENTING TUBE WITH ADAPTOR.	TATA spare parts
282947610147	ASSY. BRACKET (VENT PIPE CLAMPING.) BS6	TATA spare parts
282947610149	ASSY. LOW PRESSURE PIPE	TATA spare parts
282947610157	ASSY. H.P. GAS TUBE (H.P.FILTER TO REGUL	TATA spare parts
282947610159	ASSY. VENTING TUBE (COUPLING BODY TO REG	TATA spare parts
282947610160	ASSY. VENTING TUBE (REAR CYLINDER TEE TO	TATA spare parts
282947610161	ASSY. VENTING TUBE (REAR CYLINDER - BURS	TATA spare parts
282947610162	ASSY. VENTING TUBE (REAR CLINDER - PRD)	TATA spare parts
282947610164	ASSY. VENTING TUBE (PRESSURE REGULATOR)	TATA spare parts
282947610167	ASSY. VENTING TUBE	TATA spare parts
282947610184	ASSY. H.P GAS TUBE (ELBOW TO HP FILTER)	TATA spare parts
282947610187	ASSY. VENTING TUBE (REAR TEE TO FRONT TE	TATA spare parts
282947610194	ASSY. VENTING TUBE (PRESSURE REGULATOR)	TATA spare parts
282947610198	ASSY.H.P.GAS TUBE (FILLING NOZZLE TO H.P	TATA spare parts
282947620101	BURST DISC ASSY. FOR CNG CYLINDER VALVE	TATA spare parts
282947620103	ASSY. H.P.GAS TUBE (FILLING NOZZLE TO RE	TATA spare parts
282947620104	ASSY. VENTING TUBE (REAR CYLINDER)	TATA spare parts
282947620109	ASSY. H.P. GAS TUBE (TEE TO PRESS. GAUGE	TATA spare parts
282947620110	ASSY H.P. GAS TUBE (TEE TO REAR CYL.UNIO	TATA spare parts
282947620111	ASSY. H.P. GAS TUBE (UNION TO REAR CYLIN	TATA spare parts
282947620112	ASSY H.P. GAS TUBE (FILLING NOZZLE TO UN	TATA spare parts
282947620118	ASSY.H.P.GAS TUBE (FILLING NOZZLE TO TEE	TATA spare parts
282947620121	ASSY. BRACKET (REGULATOR TO LP FILTER) B	TATA spare parts
282947620124	ASSY. H.P. GAS TUBE (FOR OMB VALVE) (REA	TATA spare parts
282947620125	ASSY. HP GAS TUBE (FOR OMB VALVE) NOZZLE	TATA spare parts
282947620126	ASSY VENTING TUBE (REAR CYLINDER)	TATA spare parts
282947620127	ASSY. VENTING TUBE (FOR OMB VALVE) (FRON	TATA spare parts
282947620128	ASSY. LP LINE (REGULATOR TO FILTER)	TATA spare parts
282947620129	ASSY. LP LINE (FILTER TO ENGINE)	TATA spare parts
282947620133	CYLINDER VALVE (OMB)	TATA spare parts
282947620134	ASSY. L.P.LINE (REGULATOR TO L P FILTER)	TATA spare parts
282947620135	ASSY. L.P.LINE (L.P.FILTER TO ENGINE)	TATA spare parts
282947620138	ASSY. H.P.GAS TUBE (FILLING NOZZLE UNION	TATA spare parts
282947620142	ASSY. H.P. GAS TUBE (H.P.FILTER TO REGUL	TATA spare parts

282947620143	ASSY. VENTING TUBE (PRESSURE REGULATOR)	TATA spare parts
282947620144	ASSY. L.P.LINE (REGULATOR TO L P FILTER)	TATA spare parts
282947700102	FILLING NOZZLE (NZS)	TATA spare parts
282947700103	PRESSURE GAUGE (2')	TATA spare parts
282947700104	HIGH PRESSURE REGULATOR	TATA spare parts
282947700105	LOW PRESSURE FILTER	TATA spare parts
282947700106	H.P.FILTER	TATA spare parts
282947700107	PRESSURE GAUGE(GLYCERENE FILLED)	TATA spare parts
282947700108	SOLENOID ASSY.	TATA spare parts
282947700109	CARTIDGE ASSY (CARTIDGE WITH O-RING)	TATA spare parts
282947700110	DRAIN PLUG ASSY (DUST PLUGE WITH O- RING	TATA spare parts
282947700111	DUST PLUGE ASSY.	TATA spare parts
282947700112	PLUNGER ASSY	TATA spare parts
282947700113	FILLING NOZZLE	TATA spare parts
282947700114	FILLING NOZZLE	TATA spare parts
282947700115	FILLING RECEPTACLE	TATA spare parts
282947700116	FILLING RECEPTACLE BS6	TATA spare parts
282947700118	ASSY LOW PRESURE FILTER FOR BS-IV	TATA spare parts
282947700121	SOLENOID VALVE ASSY BS6	TATA spare parts
282947703202	BANJO BOLT	TATA spare parts
282947707801	INLET FITTING O RING	TATA spare parts
282947707802	OUTLET FITTING O RING	TATA spare parts
282947707805	O-RING BODY	TATA spare parts
282947707807	O-RING 3.35 X 1.78 BS6	TATA spare parts
282947707808	N.R.V PLUNGER BS6	TATA spare parts
282947707809	O-RING 11.4 X 1.5 BS6	TATA spare parts
282947708701	SPRING RETENTION	TATA spare parts
282947709901	PRESSURE TRANSDUCER	TATA spare parts
282947709902	FILTER INLET (SINTERED)	TATA spare parts
282947709903	MICRO SWITCH	TATA spare parts
282947709904	O-RING NRV	TATA spare parts
282947900101	ASSY. CLAMP	TATA spare parts
282949100112	ASSY. SILENCER	TATA spare parts
282949100137	ASSY. INLET PIPE WITH FLEXIBLE JOINT BS2	TATA spare parts
282949100140	ASSY. PRESILENCER BSII	TATA spare parts
282949100143	ASSY. INLET PIPE WITH FLEXIBLE JOINT	TATA spare parts
282949100148	ASSY. SILENCER BS4	TATA spare parts
282949100150	ASSY. RUBBER HANGER BS1/2/3/4	TATA spare parts
282949100164	ASSY. PRE-SILENCER	TATA spare parts
282949100165	ASSY. SILENCER	TATA spare parts
282949100169	ASSY. INLET PIPE WITH FLEXIBLE JOINT	TATA spare parts
282949100172	ASSY. SILENCER	TATA spare parts
282949100174	ASSY. SILENCER BS2	TATA spare parts
282949100178	ASSY. INLET PIPE WITH FLEXIBLE JOINT BS2	TATA spare parts
282949100179	ASSY. INLET PIPE W/FLEX JOINT BS2/3/4	TATA spare parts
282949100182	ASSY. INLET PIPE WITH FLEXIBLE JOINT	TATA spare parts
282949100183	ASSY. SILENCER (BS-III)	TATA spare parts

282949100188	ASSY. INLET PIPE WITH FLEXIBLE HOSE	TATA spare parts
282949100199	ASSY. SILENCER	TATA spare parts
282949110101	ASSY. INLET PIPE W/FLEXIBLE BELLOW BS3/4	TATA spare parts
282949110104	ASSY. FRONT PIPE W/FLEXIBLE BELLOW BS4	TATA spare parts
282949110108	ASSY. PIPE (SILENCER INLET)	TATA spare parts
282949110109	ASSY. PIPE (SILENCER INLET)	TATA spare parts
282949110116	ASSY. INLET PIPE (WITH FLEXIBLE BELLOW)	TATA spare parts
282949110121	ASSY. PIPE (SILENCER INLET)	TATA spare parts
282949110123	ASSY. FRONT PIPE WITH FLEXIBLE BELLOW	TATA spare parts
282949110125	ASSY. HOOK (FRONT PIPE MTG)	TATA spare parts
282949200103	GASKET-EXHAUST MANIFOLD	TATA spare parts
282949200108DF01	FLEX CONNECTOR STD-45X152	TATA spare parts
282949200108DF01LL	FLEX CONNECTOR STD-45X152 LONG LIFE	TATA spare parts
282949200108DF02	FLEX CONNECTOR-45X170	TATA spare parts
282949200108DF02LL	FLEX CONNECTOR-45X170 LONG LIFE	TATA spare parts
282949200108DF03	FLEX CONNECTOR STD-45X152 WITH EXTENSION	TATA spare parts
282949200108DF03LL	FLEX CONNECTOR STD-45X152 W/EXT LONG LIF	TATA spare parts
282949200108DF04	FLEX CONNECTOR-45X170 WITH EXTENSION	TATA spare parts
282949200108DF04LL	FLEX CONNECTOR-45X170 W/EXT LONG LIFE	TATA spare parts
282949200113	ASSY. SILINCER	TATA spare parts
282949200122	ASSY. MIDDLE PIPE (CAT.CON TO SILENCER)	TATA spare parts
282949200130	ASSY. INLET PIPE WITH FLEXIBLE JOINT	TATA spare parts
282949200134	PIPE ASSY INTERMEDIATE	TATA spare parts
282949200142	SILENCER ASSY	TATA spare parts
282949200149	SILENCER ASSY WITH TAIL PIPE	TATA spare parts
282949200164	ASSY. INLET PIPE W/FLEXIBLE BELLOW BS3/4	TATA spare parts
282949200165	ASSY. SILENCERç - BS-III	TATA spare parts
282949200172	ASSEMBLY INLET PIPE WITH FLEXIBLE JOINT	TATA spare parts
282949200174	ASSY FRONT PIPE WITH FLEXIBLE BELLOW	TATA spare parts
282949200175	FLEXIBLE BELLOW ASSY BS6	TATA spare parts
282949200183	PIPE ASSY	TATA spare parts
282949204251	HOOK (RH LONG MEMBER) BS6	TATA spare parts
282954100109	ASSYBATTERY CABLE +VE FOR CUB	TATA spare parts
282954100110	ASSYBATTERY CABLE -VE FOR CUB	TATA spare parts
282954100113	ASSYBATTERY CABLE +VE FOR CUB	TATA spare parts
282954100114	ASSYBATTERY CABLE -VE FOR CUB	TATA spare parts
282954100117	ASSY. BATTERY CLAMP	TATA spare parts
282954100118	ASSY.BATTERY CLAMPING STUD	TATA spare parts
282954100119	ASSY.BATT.CLAMPING STUD LOCKSIDE	TATA spare parts
282954100120	ASSY.BATTERY TRAY ACE PEOPLES CARRIER	TATA spare parts
282954100121	ASSY.BATTERY CABLE +VE - OFFER	TATA spare parts
282954100122	ASSY. BATTERY CABLE -VE - OFFER	TATA spare parts
282954100123	ASSY.BATTERY CABLE +VE	TATA spare parts
282954100126	ACE START STOP SYS ASSY.BATTERY CLAMP	TATA spare parts
282954100127	ACE START STOP SYS ASSY.BATTERY STUD LOC	TATA spare parts
282954100130	ASSLY. BATTERY CLAMPING STUD - START-STO	TATA spare parts
282954100131	BATTERY CABLE +VE START-STOP SYSTEM	TATA spare parts

282954100132	BATTERY CABLE -VE START STOP SYSTEM	TATA spare parts
282954100133	ASSY BATTERY TRAY	TATA spare parts
282954100141	BATTERY CABLE +VE ACE 275 IDI BS-IV	TATA spare parts
282954100143	BATTERY CABLE +VE	TATA spare parts
282954100145	BATTERY CABLE NEGATIVE ACE DICOR	TATA spare parts
282954100146	BATT.CABLE +VE ACE-DICOR	TATA spare parts
282954100147	BATTERY CABLE +VE MAGIC DICOR	TATA spare parts
282954100149	BATTERY CABLE +VE ACE CNG BS IV	TATA spare parts
282954100150	ASSY.BATTERY CABLE +VE	TATA spare parts
282954100152	ASSLY MAXI FUSE MOUNTING BRACKET	TATA spare parts
282954100176	MAIN BATTERY CABLE TO STARTER MOTOR ACE	TATA spare parts
282954100177	BATTERY CABLE ASSY	TATA spare parts
282954108205	BATTERY CLAMP	TATA spare parts
282954108209	BATTERY_CLAMPING_STUD_LOCKSIDE	TATA spare parts
282954108801	BATTERY CLAMPING STUD LOCKSIDE	TATA spare parts
282954109904	FUSIBLE LINK 80A-80MM LONG W/TER 312SRS	TATA spare parts
282954109905	FUSIBLE LINK 80A-80MM LONG	TATA spare parts
282954109907	EARTH STRAP	TATA spare parts
282954109916	NEW EARTH STRAP	TATA spare parts
282954109924	BATTERY 35AH	TATA spare parts
282954200105	TANK UNIT (20LTRS)	TATA spare parts
282954200106	ASSY. TANK UNIT-30 LTRS BS2/3/4	TATA spare parts
282954200107	ASSY.HORN MOUNTING BRACKET	TATA spare parts
282954200108	ASSY. TANK UNIT-30 LTRS	TATA spare parts
282954200109	ASSY. INSTR. CLUSTER 0.65 RATIO	TATA spare parts
282954200111	ASSY. INSTR.CLUSTER WITH 0.6 RATIO	TATA spare parts
282954200112	ASSY.TANK UNIT	TATA spare parts
282954200113	ASSY. INSTRUMENT CLUSTER	TATA spare parts
282954200114	ASSY. INSTR. CLUSTER W/0.65 RATIO BS2/3	TATA spare parts
282954200115	ASSY.MOUNTING BRACKET (IGN COIL)	TATA spare parts
282954200118	ASSY BRACKET (RELAYS MTG)	TATA spare parts
282954200132	INSTRUMENT CLUSTER	TATA spare parts
282954200136	ASSY. ECU MTG BKT ACE DICOR	TATA spare parts
282954200140	ASSLY. START-STOP CONTROLLER WITH BKT.	TATA spare parts
282954200141	ASSLY. START-STOP CONTROLLER	TATA spare parts
282954200143	FLOAT UNIT	TATA spare parts
282954200145	TANK UNIT WITH THICK FILM RESISTANCE	TATA spare parts
282954200156	INSTR_CLUSTER_WITH_FLEXIBLE_PCB_0.62R	TATA spare parts
282954200159	INSTR CLUSTER 0.62R	TATA spare parts
282954200162	ASSY. TANK UNIT FOR PLASTIC TANK	TATA spare parts
282954200166	ELECTRONIC INSTR CLUSTER(0.5625 RATIO)	TATA spare parts
282954200168	ELECTRONIC INSTR CLUSTER(0.62 RATIO)	TATA spare parts
282954200169	ELECT. INSTR CLUSTER(0.65 RATIO) BS3/4	TATA spare parts
282954200170	ELECT. INSTR CLUSTER(0.65 RATIO) BS2/3	TATA spare parts
282954200172	ACE MAGIC NEW ASSY.HORN MTG BKT	TATA spare parts
282954200176	ELECTRONIC INSTR CLUSTER(0.65 RATIO)	TATA spare parts
282954200177	ELECTRONIC INSTR CLUSTER(0.65 RATIO)	TATA spare parts

282954200181	ELECTRONIC INSTR CLUSTER(0.62 RATIO) PRI	TATA spare parts
282954200184	ASSLY. SS CONTROLLER PHASE-1 ACE-EX-BS-I	TATA spare parts
282954200189	ASSLY. SS CONTROLLER PH1 BS-III	TATA spare parts
282954200192	ELCTRONIC INST.CLUSTER FOR CNG	TATA spare parts
282954200193	ASSLY WIF CONTR MTG BKT FOR ACE MAGIC	TATA spare parts
282954200194	WATER IN FUEL IND	TATA spare parts
282954200198	INST.CLUSTER ACE CNG OBD-II FACELIFT	TATA spare parts
282954200199	FLOAT UNIT	TATA spare parts
282954207501	PLUG FOR SPEDDO CABLE HOLE ACE	TATA spare parts
282954208203	ECU HOLDING CLAMP	TATA spare parts
282954208257	DIAGNOSTIC CONNECTOR MTG. BKT.	TATA spare parts
282954208260	MATING CONNECTOR MTG. BKT. WH ENGINE ANI	TATA spare parts
282954208262	PIANO SW.& DIAGNOSTIC MTG BKT ACE-EX BS	TATA spare parts
282954208270	WIF SENSOR BRANCH MTG BKT	TATA spare parts
282954209902	SPEEDO CABLE 3.2 DIA 2350MM BS2/3/4	TATA spare parts
282954209905	HORN 12V LOW TONE 82DIA	TATA spare parts
282954209907	3.2DIA SPEEDO CABLE-2350MM JIS	TATA spare parts
282954209921	GLOW PLUG BS2/3/4	TATA spare parts
282954209922	RAD. COLLING FAN CONTROLLER	TATA spare parts
282954209923	RAD. COOLING FAN CONTROLLER BS2/3/4	TATA spare parts
282954209924	RADIATOR COOLING FAN CONTROLLER BS2	TATA spare parts
282954209927	GLOW PLUG BS2/3	TATA spare parts
282954209929	3.2DIA SPEEDO CABLE-2350MM JIS	TATA spare parts
282954209930	DIGITAL CLOCK BS2/3/4	TATA spare parts
282954209934	RELAY_12V_40A_CNG_EMS	TATA spare parts
282954209935	RELAY 12V 20A(RADIATOR COOLING FAN)	TATA spare parts
282954209936	STARTER_RELAY_12V_40A	TATA spare parts
282954209937	IGNITION COIL	TATA spare parts
282954209938	H T CABLE	TATA spare parts
282954209950	EGR_CONTROLLER_ACE_275_IDI_BSIV	TATA spare parts
282954209951	GLOW-PLUG-TIMER-ACE 275IDI BS3/4	TATA spare parts
282954209959	SPEEDO CABLE-2800MM	TATA spare parts
282954209961	TEMPERATURE_SENSOR_M16_ACE-DICOR BS4	TATA spare parts
282954209963	HORN 108DIA	TATA spare parts
282954209964	VEHICLE SPEED SENSOR 8-PULSE	TATA spare parts
282954209965	HORN 12V DC BS1/2/3/4	TATA spare parts
282954209968	SPEEDO CABLE 2400 MM ACE START STOP	TATA spare parts
282954209969	EGR_CONTROLLER_ACE_EX_275_IDI_BSIV	TATA spare parts
282954209977	EGR CONTROLLER OBD II ACE BS IV	TATA spare parts
282954209978	EGR CONTROLLER	TATA spare parts
282954209979	RELAY NO TYPE 12V 20 AMP WITH RESISTOR	TATA spare parts
282954304901	WATER IN FUEL INDICATOR	TATA spare parts
282954400103	SIDE REPEATER LAMP BS2/3/4/6	TATA spare parts
282954400106	ASSY.REGISTRATION PLATE LAMPD	TATA spare parts
282954400107	REVERSE LAMP	TATA spare parts
282954400110	CABIN LAMP	TATA spare parts
282954400112	ASSY.FRONT BLINKER-LH BS4	TATA spare parts

282954400113	ASSY.FRONT BLINKER-RH BS4	TATA spare parts
282954400114	SIDE REPEATER LAMP	TATA spare parts
282954400115	ASSY. RECTANGULAR TAIL LAMP LH BS1- 4/6	TATA spare parts
282954400116	ASSY. RECTANGULAR TAIL LAMP RH BS1- 4/6	TATA spare parts
282954400117	RECTANGULAR REVERSING LAMP	TATA spare parts
282954400118	ASSY.HEAD LAMP WITH MOTORISED LH	TATA spare parts
282954400119	ASSY.HEAD LAMP WITH MOTORISED RH	TATA spare parts
282954400128	ASSY. HEAD LAMP LH(NORM LENS MOTOR)BS2-6	TATA spare parts
282954400129	ASSY. HEAD LAMP RH(NORM LENS MOTOR)BS2-6	TATA spare parts
282954400130	ASSY NORMAL LENS MOTORISED H/L LH	TATA spare parts
282954400131	ASSY NORMAL LENS MOTORISED H/L RH	TATA spare parts
282954400132	ASSY. H/L W/O MOTOR-LH	TATA spare parts
282954400133	ASSY. H/L W/O MOTOR-RH	TATA spare parts
282954400142	ASSY. HIGH MOUNTED STOP LAMP	TATA spare parts
282954400143	ASSY. TAIL LAMP LH	TATA spare parts
282954400144	ASSY. TAIL LAMP RH	TATA spare parts
282954400145	TAIL LAMP REVERSE RH	TATA spare parts
282954400146	SIDE REPEATER LAMP	TATA spare parts
282954400148	ASSY_ ROOF LAMP BRIGE COLOUR	TATA spare parts
282954400149	ROOF LAMP PASSANGER COMP SHORTER LANGTH	TATA spare parts
282954400150	ROOF LAMP BEIGE COLOUR MEDIUM LENGTH	TATA spare parts
282954400151	ROOF LAMP BLACK COLOUR MEDIUM LENGTH	TATA spare parts
282954400157	WARNING INDI.I (CHECK ENGINE & HIGH TEMP	TATA spare parts
282954400158	WARNING INDI.II (LOW FUEL)M/S JAY	TATA spare parts
282954400168	ASSY NORMAL LENS MOTORISED HEAD LAMP LH	TATA spare parts
282954400169	ASSY NORMAL LENS MOTORISED HEAD LAMP RH	TATA spare parts
282954400170	ASSY. NORMAL LENS MOTORISED HL RH ACE LH	TATA spare parts
282954400171	ASSY. NORMAL LENS MOTORISED HL LH ACE LH	TATA spare parts
282954400174	ASSY FRONT BLINKER LH	TATA spare parts
282954400175	ASSY FRONT BLINKER RH	TATA spare parts
282954400176	SIDE REPEATER LAMP	TATA spare parts
282954400177	ASSY REVERSE LAMP	TATA spare parts
282954400178	ASSY TAIL LAMP LH	TATA spare parts
282954400179	ASSY TAIL LAMP RH	TATA spare parts
282954400185	ASSY.ROFF LAMP BLACK COLOUR MEDIUM LENGT	TATA spare parts
282954400191	ASSY TAIL LAMP LH	TATA spare parts
282954400192	ASSY TAIL LAMP RH	TATA spare parts
282954406301	HEAD LAMP CAP RH	TATA spare parts
282954406302	HEAD LAMP CAP LH	TATA spare parts
282954406309	COVER FOR REVERSE LAMP CUTOUT	TATA spare parts
282954406313	CROCODILE CLIP	TATA spare parts
282954407507	GROMMET FOR BLINKER CUTOUT	TATA spare parts
282954407514	RUBBER GASKET - M/S.LUMAX¿ BS6	TATA spare parts
282954407515	RUBBER CAP BS6	TATA spare parts
282954408221	HEAD LAMP MTG. PLATE - M/S.LUMAX BS6	TATA spare parts
282954408222	HEAD LAMP MTG. PLATE EH- M/S.LUMAX BS6	TATA spare parts
282954409903	REFLEX REFLECTOR (WHITE)	TATA spare parts

282954409906	LEVELING MOTOR FOR ASSY. HEAD LAMP BS6	TATA spare parts
282954409941	DASHBOARD IND. LAMP FOR START-STOP SYSTE	TATA spare parts
282954409947	BULB C5W-12V BS6	TATA spare parts
282954410106	LAMP REGISTRATION&PLATE	TATA spare parts
282954500103	ASSY.COMBI SWITCH W/O WASH FUNCTION	TATA spare parts
282954500104	STEERING LOCK CUM IGNITION SW.	TATA spare parts
282954500105	ASSY. COMBI SWITCH BS2/3/4	TATA spare parts
282954500106	STEERING CUM IGNITION SWITCH BS2/3/4/6	TATA spare parts
282954500107	ASSY. COMBI. SWITCH W/WASH FCTN. BS2/3/4	TATA spare parts
282954500117	ASSY. COMBISWITCH W/WASH FUNC. BS2/3/4/6	TATA spare parts
282954508201	ACE START STOP SYS PIANO SW MTG BKT	TATA spare parts
282954509901	HEAD LAMP LEVELING SW.	TATA spare parts
282954509902	HEAD_LAMP_LEVELLING_S/W	TATA spare parts
282954509902C7	GRANIT_BLACK-HEAD_LAMP_LEVELLING_S/W BS	TATA spare parts
282954509905	ASSY REVERSE LIGHT SWITCH	TATA spare parts
282954509907	AUTO STOP ON-OFF SWITCH	TATA spare parts
282954509908	AUTO STOP ON-OFF SWITCH	TATA spare parts
282954509909	AUTO STOP ON-OFF SWITCH	TATA spare parts
282954509921	CLUTCH SWITCH-ACE-EX	TATA spare parts
282954509922	NEUTRAL SWITCH	TATA spare parts
282954509922AE	NEUTRAL SWT LPTA 1628/LPTA 1828	TATA spare parts
282954600101	WIRING HARNESS MAIN	TATA spare parts
282954600103	WIRING HARNESS ENGINE	TATA spare parts
282954600107	WIRING HARNESS MAIN	TATA spare parts
282954600108	WIRING HARNESS ENGINE	TATA spare parts
282954600109	WIRING HARNESS MAIN BS III	TATA spare parts
282954600110	WIRING HARNESS ENGINE BS2/3/4	TATA spare parts
282954600113	WIRING HARNESS MAIN	TATA spare parts
282954600114	PIG TAIL FOR SIDE REP & BLINKER	TATA spare parts
282954600115	PIG TAIL FOR TAIL GATE	TATA spare parts
282954600121	WIRING HARNESS MAIN BS2/3	TATA spare parts
282954600122	WIRING HARNESS MAIN - MAGIC	TATA spare parts
282954600138	W/H ENGINE ACE DICOR	TATA spare parts
282954600140	WH ENGINE ACE DICOR	TATA spare parts
282954600141	WH MAIN ACE DICOR	TATA spare parts
282954600143	W/H MAIN (ELEC. INSTR. CLUSTER) BS2/3	TATA spare parts
282954600145	WH MAIN (ELECTRONIC INSTRUMENT CLUSTER)	TATA spare parts
282954600147	W/H ACE MAGIC LHD (SHORT TERM)	TATA spare parts
282954600149	WH MAIN ACE-EX 275 IDI BS IV	TATA spare parts
282954600152	WH ENGINE ACE-EX 275 IDI BS IV	TATA spare parts
282954600154	WH ENGINE ACE MAGIC DICOR	TATA spare parts
282954600158	W/H MAIN	TATA spare parts
282954600160	WH ENGINE ACE DICOR NA HT TATA YAZAKI	TATA spare parts
282954600162	ACE EX WH MAIN SUPPLIER	TATA spare parts
282954600163	ASSY MAIN W/H ACE CNG BSIV	TATA spare parts
282954600164	ASSY ENGINE W/H ACE CNG BS IV	TATA spare parts
282954600165	ACE MAGIC CNG MAIN WH BS IV	TATA spare parts

282954600168	MAGIC_CNG_MAIN_WH	TATA spare parts
282954600174	W/H MAIN (START-STOP)	TATA spare parts
282954600175	W/H ENGINE(START-STOP)	TATA spare parts
282954600183	WH MAIN LHD	TATA spare parts
282954600184	ACE MAGIC MAIN WIRING HARNESS (HORN)	TATA spare parts
282954600192	ACE_MAGIC_CNG_MAIN_WH_BS_IV	TATA spare parts
282954600194	W/H MAIN ACE 275 IDI BSIV	TATA spare parts
282954600196	W/H ENGINE ACE 275 IDI BSIV	TATA spare parts
282954600198	W/H MAIN ACE MAGIC 275 IDI BSIV	TATA spare parts
282954601601	W/H MAIN	TATA spare parts
282954601602	W/H ENGINE	TATA spare parts
282954601603	W/H CYLINDER EARTHING	TATA spare parts
282954606308	CABLE STRAP LENGTH 360MM	TATA spare parts
282954607508	GROMMET	TATA spare parts
282954608202	CLAMP 10.5DIA (W/H CLAMPING)	TATA spare parts
282954608205	AIR_COMP_CONNECTOR_MTG_BKT_ACE_DICOR	TATA spare parts
282954608210	WH MTG BKT NEAR ALTERNATOR 1 ACE DICOR	TATA spare parts
282954608212	ACE DICOR OIL PRESSURE SWITCH SUPPORTING	TATA spare parts
282954608217	WIRING HARNESS SUPPORT NEAR CAM ACE CNG	TATA spare parts
282954608219	WIRING HARNESS SUPPORT ON ENGINE ACE CNG	TATA spare parts
282954608220	WIRING HARNESS SUPPORT ECU	TATA spare parts
282954608224	RELAY MTG BKT	TATA spare parts
282954608225	ACE DICOR WH ENGINE MTG BKT ON TIME BELT	TATA spare parts
282954608226	ACE DICOR WH ENGINE MTG BKT ON CYLINDER	TATA spare parts
282954608227	ACE DICOR WH ENGINE MTG BKT NEAR ENGINE	TATA spare parts
282954608228	WH ENGINE MTG BRACKET ON CYLINDER HEAD	TATA spare parts
282954608231	ACE_DICOR_WH_ENGINE_MTG_BKT_ON_HOOK	TATA spare parts
282954608233	ACE DICOR WH BRACKET ON ALTERNATOR	TATA spare parts
282954608235	EMS MAIN INT BRACKET ACE CNG	TATA spare parts
282954608237	WH ENGINE MTG BKT ON TRANSMISSION ACE CN	TATA spare parts
282954608238	COMMON BKT FOR WH B CABLE ACE CNG BS6	TATA spare parts
282954608240	ENGINE HARNESS MTG BKT ERV	TATA spare parts
282954609906	STICKER POWER O/P	TATA spare parts
282954660101	W/H MAIN	TATA spare parts
282954660102	W/H ENGINE	TATA spare parts
282954660104	ACE_MAGIC_CNG_ENGINE_WH_BS_IV	TATA spare parts
282954660105	W/H MAIN ACE CNG BS-IV	TATA spare parts
282954993601	FILTER FUEL TANK UNIT	TATA spare parts
282954997701	GASKET BS6	TATA spare parts
282955106301	STICKER LH ACE EX	TATA spare parts
282955106302	STICKER RH ACE EX	TATA spare parts
282955106303	STICKER ACE BS-4	TATA spare parts
282958408204	TR.LABEL-TYRE PRESSURE-145 R12 LT 8PR	TATA spare parts
282958408206	TRANSFER LABEL-CNG (REAR)	TATA spare parts
282958604001	FIRE EXTINGUISHER MOUNTING BRACKET	TATA spare parts
282958900102	ASSY.SCISSOR'S JACK	TATA spare parts
282958900105	ASSY. WORKSHOP TOOLS-G65 GEAR BOX CUB	TATA spare parts



282958900108	TENSIONER BELT ASSY.-WINDSHIELD GLAS-ACE	TATA spare parts
282958900109	TOOL KIT - TATA ACE	TATA spare parts
282958900110	ASSY. SCISSORS JACK	TATA spare parts
282958900601	SUPPORT RAIL / 275 IDI / CUB	TATA spare parts
282958900602	SPACER FOR VALVE GUIDE	TATA spare parts
282958900603	SPACER FOR VALVE GUIDE SEAL (INLET AND E	TATA spare parts
282958900604	SUPPORT RAIL	TATA spare parts
282958900605	VALVE SPRING COMPRESSOR	TATA spare parts
282958900606	DRIFT CAMSHAFT OIL SEAL PRESSING	TATA spare parts
282958900607	DRIFT CRANKSHAFT OIL SEAL REAR PRESSING	TATA spare parts
282958900701	PULLER INJECTOR REMOVAL	TATA spare parts
282958900702	SHIM SELECTION GAUGE	TATA spare parts
282958901801	SPANNER FOR OIL FILTER	TATA spare parts
282958901802	SPANNER (FUEL FILTER)	TATA spare parts
282958902401	BRACKET - RH FOR MOUNTING 275 IDI ENGINE	TATA spare parts
282958902403	ENGINE MTG BRACKET LH (ENGINE REPAIR)	TATA spare parts
282958902404	ENG. MTG. BKT. RH. (ENGINE ROTARY STAND)	TATA spare parts
282958902501	MANDREL / CLUTCH DISC ALIGNMENT / CUB	TATA spare parts
282958902601	MOUNTING PLATE -G65 GEAR BOX-TATA CUB	TATA spare parts
282958902602	DRIFT-FOR REMOVAL OF DOWEL SLEEVE DIA.5	TATA spare parts
282958902603	DRIFT-REMOVAL OF DOWEL SLEEVE-DIA 4	TATA spare parts
282958902604	DRIFT-INSTALL OF SPEEDO SHAFT OIL SEAL	TATA spare parts
282958902605	PULLER/REMOVE COUNTER SHAFT BRG/ CUB	TATA spare parts
282958902606	DRIFT	TATA spare parts
282958902607	DRIFT	TATA spare parts
282958902608	DRIFT-INSTALL. OF MAIN SHAFT BEARING	TATA spare parts
282958903301	DRIFT-INSTA OUTER RACE OF FRONT HUB BRGS	TATA spare parts
282958903302	PULLER / REMOVE F-HUB I-BRG O-RACE / CUB	TATA spare parts
282958903501	EXTENDED SOCKET-8 A/F PROPELLER SHAFT	TATA spare parts
282958903502	UNIVERSAL HANDLE / RA / CUB	TATA spare parts
282958903503	EXPANDER / RA / CUB	TATA spare parts
282958903504	PINION HEIGHT SETTING GAUGE/RA/CUB	TATA spare parts
282958903505	PINION HEIGHT SETTING MASTER/RA/CUB	TATA spare parts
282958903507	P-DOLLY/PINION INNER CUP / RA / CUB	TATA spare parts
282958903508	P-DOLLY / PINION OUTER CUP/RA/ CUB	TATA spare parts
282958903509	P-DOLLY/ PINION INNER CONE / RA/CUB	TATA spare parts
282958903510	P-DOLLY /DIFF.CASE BRG / RA / CUB	TATA spare parts
282958903511	ADAPTER/REMOVE DIFF CASE BRG/RA/CUB	TATA spare parts
282958903512	ADAPTER/REMOVE P- INNER BRG/RA/CUB	TATA spare parts
282958903513	ADAPTER/REMOVE P- INNER CUP/RA/CUB	TATA spare parts
282958903514	ADAPTER/REMOVE P-OUTER CUP/RA/CUB	TATA spare parts
282958903515	FLANGE HOLDER / RA / 207	TATA spare parts
282958903516	P-DOLLY / P-OUTER OIL SEAL / RA/CUB	TATA spare parts
282958903517	PULLER / OIL SEAL PINION /RA / CUB	TATA spare parts
282958903518	PRESS / BEARING REMOVE / RA / CUB	TATA spare parts
282958903520	AXLE SHAFT ASSY PULLER / RA / CUB	TATA spare parts
282958903521	PULLER-REMOVING AXLE SHAFT BRG	TATA spare parts

282958904601	PULLER FOR REMOVING STEERING WHEEL	TATA spare parts
282958905001	BAG-TOOL KIT TRIANGLE MED.KIT & HANDLE	TATA spare parts
282960100102	ASSY.BODY SHELL COMPLETE PAINTED	TATA spare parts
282960100111	ASSY BODY SHELL COMP PAINTED (WITH SIDE	TATA spare parts
282960100111BF	ASSY BODY SHELL COMP PAINTED_ ARCTIC WHIT	TATA spare parts
282960100111BN	ASSY BODY SHELL COMP PAINTED_ RUBY_ RED	TATA spare parts
282960100111C9	ASSY BODY SHELL COMP PAINTED_ GOLDN_ YELLO	TATA spare parts
282960100111CN	ASSY BODY SHELL COMP PAINTED_ IRISH_ CREAM	TATA spare parts
282960100113	ASSY REAR TUBE MTG BRACKET	TATA spare parts
282960100118BF	ASSY BODY SHELL COMPLETE PAINTED -PC	TATA spare parts
282960100118BN	ASSY BODY SHELL COMP PAINTED RUBY_ RED	TATA spare parts
282960100118BU	ASSY BODY SHELL COMP PAINTED JET_ BLACK	TATA spare parts
282960100129	ASSY.BODY SHELL COMPLETE PAINTED	TATA spare parts
282960100129BN	ASSY BODY SHELL COMP PAINTED_ RUBY_ RED	TATA spare parts
282960100129CN	ASSY. CABIN BARE W/FRAME IRISH BS2/3/4	TATA spare parts
282960100129FD	ASSY.BODY SHELL COMPLETE PAINTED	TATA spare parts
282960100129H3	ASSY.BODY SHELL COMPLETE PAINTED	TATA spare parts
282960100130	ASSY BODY SHELL COMPLETE	TATA spare parts
282960100146	ASSY BODY SHELL COMPLETED -CED COATED.	TATA spare parts
282960100148	ASSY REAR TUBE MTG BKT BS6	TATA spare parts
282960100150	ASSY TUBE REAR	TATA spare parts
282960100156	ASSY.BODY SHELL WITH FRAME COMPLETE	TATA spare parts
282960100156BF	ASSY BODY SHELL COMPL PAINTED - CNG	TATA spare parts
282960100161CN	ASSY.BODY SHELL WITH FRAME COMPLETE - IR	TATA spare parts
282960100197BF	ARCTIC_ WHITE-ASSY BODY SHELL COMPLETE	TATA spare parts
282960100197FW	ASSY BODY SHELL COMPL PIANTED - BSIV	TATA spare parts
282960100207BF	BODY SHEEL COMPL PAINTED - ACE MAGIC CNG	TATA spare parts
282960100227	ASSY UNDERBODY GC	TATA spare parts
282960100228	FRAME WITH UNDERBODY WITH FRONT WALL	TATA spare parts
282960100234BF	ASSY BODY SHELL COMPLETE PAINTED LHD_ ARCT	TATA spare parts
282960100242BF	ASSY BODY SHELL COMPLETE PAINTED ACE EX	TATA spare parts
282960100271BF	ASSY BODY SHELL COMPL PAINTED - ACE CNG	TATA spare parts
282960100282BF	ASSY BODY SHELL COMPL PAINTED-MAGIC CNG	TATA spare parts
282960106901	TUBE REAR	TATA spare parts
28296010Z233	ASSY BODY SHELL COMPLETE LHD DIESEL	TATA spare parts
28296010Z234BF	ASSY BODY SHELL COMPLETE PAINTED LHD DIES	TATA spare parts
28296010Z234CN	ASSY BODY SHELL COMPLETE PAINTED LHD DIES	TATA spare parts
282960600101	ASSY BRACKET SUPPORT D/B CROSS MEMBER	TATA spare parts
282960600102	ASSY DASHBOARD CROSS MEMBER	TATA spare parts
282960600122	ASSY DASHBOARD CROSS MEMBER LHD	TATA spare parts
282960606301	RUBBER PAD RADIO MTG BKT BS6	TATA spare parts
282961200102	ASSY REAR CROSS MEMBER	TATA spare parts
282961200104	ASSY SILL REAR	TATA spare parts
282961208201	SILL REAR	TATA spare parts
282961208204	SEAL REAR INNER LH	TATA spare parts
282961208205	SEAL REAR INNER RH	TATA spare parts
282961500102	ASSY REAR BUMPER MTG BRACKET	TATA spare parts

282961600109	ASSY ENGINE COVER	TATA spare parts
282961600111	ASSEMBLY VERTICAL FLOOR COMPLETE	TATA spare parts
282961600115	ASSY WHEEL ARCH INNER LH	TATA spare parts
282961600116	ASSY WHEEL ARCH INNER RH	TATA spare parts
282961600126	ASSY PANEL FRONT FLOOR	TATA spare parts
282961600131	ASSY CAB MTG CLOSING LH	TATA spare parts
282961600132	ASSY CAB MTG CLOSING RH	TATA spare parts
282961600134	ASSY COVER - OIL FILLING CUTOUT	TATA spare parts
282961600137	ASSY WHEEL ARCH INNER RH -PC BS6	TATA spare parts
282961600143	ASSY SEAL INNER FRONT LH	TATA spare parts
282961600144	ASSY SEAL INNER FRONT RH	TATA spare parts
282961600146	ASSY CAB CLOSURE BKT LH	TATA spare parts
282961600147	ASSY CAB CLOSURE BKT LH	TATA spare parts
282961600153	ASSY MIDDLE FLOOR	TATA spare parts
282961600182	ASSY VERTICAL FLR COMP	TATA spare parts
282961600189	ASSY CAB MTG CLOSING RH - ACE BSIV	TATA spare parts
282961600195	ASSY FLOOR MIDDLE -ACE MAGIC CNG - O3	TATA spare parts
282961600198	ASSY WHEELARCH INNER RH ACE 800CC DICOR	TATA spare parts
282961604701	COVER FUEL FILTER	TATA spare parts
282961604703	COVER FOR GB MICRO SWITCH	TATA spare parts
282961607705	SEAL - OIL FILLING CUTOUT	TATA spare parts
282961608210	SILL INNER FRONT LH	TATA spare parts
282961608211	SILL INNER FRONT RH	TATA spare parts
282961608239	GUSSET RR CROSS MBR SUPPORT LH	TATA spare parts
282961608248	GUSSET - RR CROSS MBR SUPPORT RH	TATA spare parts
282961800101	ASSY REAR FLOOR (WITH SPARE WHEEL MTG. B	TATA spare parts
282961800103	ASSY SPARE WHEEL MTG BKT	TATA spare parts
282961800106	ASSY REAR FLOOR - ACE MAGIC CNG - O3	TATA spare parts
282961808201	COVER PLATE REAR FLOOR CORNER LH	TATA spare parts
282961808202	COVER PLATE REAR FLOOR CORNER RH	TATA spare parts
282962000101	ASSEMBLY FRONT WALL	TATA spare parts
282962508201	SUPPORT PANEL-WINDSHIELD	TATA spare parts
282962508203	SUPPORT PANEL-WINDSHIELD LHD	TATA spare parts
282962608202	PANEL RADIATOR COVER	TATA spare parts
282963000101	ASSY. SIDE WALL LH BS2/3/4	TATA spare parts
282963000102	ASSY. SIDE WALL RH BS2/3/4	TATA spare parts
282963000103	ASSY SIDE WALL COMPLETE-LH (PC)	TATA spare parts
282963000104	ASSY SIDE WALL COMPLETE-RH (PC)	TATA spare parts
282963000105	ASSY SIDE WALL COMPL LH - ACE CNG	TATA spare parts
28296300Z101	ASSY.SIDE WALL COMPLETE-LH	TATA spare parts
28296300Z102	ASSY.SIDE WALL COMPLETE-RH	TATA spare parts
28296300Z103	ASSY SIDE WALL COMPLETE-LH (PC)	TATA spare parts
28296300Z104	ASSY SIDE WALL COMPLETE-RH (PC)	TATA spare parts
282963100110	ASSY A PILLAR REINF LH BS6	TATA spare parts
282963100111	ASSY A PILLAR REINF RH BS6	TATA spare parts
282963200103	ASSY STRIKER MTG REINF LH BS6	TATA spare parts
282963200104	ASSY STRIKER MTG REINF RH BS6	TATA spare parts

282963208202	FRONT PANEL MTG BKT BOTTOM LH	TATA spare parts
282963208203	FRT PANEL SIDE MTG BKT TOP LH	TATA spare parts
282963208204	FRT PANEL SIDE MTG BKT TOP RH	TATA spare parts
282963208205	FRONT PANEL MTG BKT BOTTOM RH	TATA spare parts
282963208218	SIDE SUPPORT LOWER LH BS6	TATA spare parts
282963208219	SIDE SUPPORT LOWER RH BS6	TATA spare parts
282963600101	ASSY SIDE WALL INNER-LH BS6	TATA spare parts
282963600102	ASSY SIDE WALL INNER-RH BS6	TATA spare parts
282963600121	ASSY REAR WHEEL ARCH OUTER LH	TATA spare parts
282963600122	ASSY REAR WHEEL ARCH OUTER RH	TATA spare parts
282963600125	ASSY FUEL HOUSING WITH BKT	TATA spare parts
282963600132	ASSY FUEL HOUSING WITH BKT-CNG	TATA spare parts
282963700108	ASSY SIDE OUTER LH	TATA spare parts
282963700110	ASSY SIDE OUTER RH	TATA spare parts
282963700112	ASSY LID FUEL FILTER HOUSING	TATA spare parts
282963700113	ASSY FRONT SIDE OUTER LH	TATA spare parts
282963700114	ASSY SILL OUTER LH	TATA spare parts
282963700115	ASSY REAR CORNER OUTER LH	TATA spare parts
282963700116	ASSY REAR CORNER OUTER RH(COATED)	TATA spare parts
282963700118	ASSY SIDE REAR OUTER LH	TATA spare parts
282963700119	ASSY CANOPY MTG PLATE SIDE -LH	TATA spare parts
282963700120	ASSY CANOPY MTG PLATE SIDE -RH	TATA spare parts
282963700122	ASSY SIDE OUTER LH- ACE MAGIC CNG	TATA spare parts
282963700124	LID ASSY FUEL FILLER HOUSING BS6	TATA spare parts
282963700125	ASSY SIDE REAR OUTER LH - ACE MAGIC CNG	TATA spare parts
282963708201	PANEL SIDE WALL OUTER-LH BS6	TATA spare parts
282963708202	PANEL SIDE WALL OUTER-RH	TATA spare parts
282963708215	CANOPY MTG PLATE TOP	TATA spare parts
282963708216	CANOPY MTG PLATE SIDE LH	TATA spare parts
282963708219	CANOPY MTG PLATE SIDE RH	TATA spare parts
282963708225	CANOPY MTG PLATE TOP CORNER LH	TATA spare parts
282963708226	CANOPY MTG PLATE TOP CORNER RH	TATA spare parts
28296370Z108	ASSY SIDE WALL REAR COMPLETE LH	TATA spare parts
282964000101	ASSEMBLY REAR WALL	TATA spare parts
282964000102	ASSEMBLY REAR WALL - CNG	TATA spare parts
282964000103	ASSY REAR WALL ACE - BS4	TATA spare parts
282964000105	ASSY REAR WALL LHD	TATA spare parts
282964200103	BRACKET ASSY UTILITY POCKET MTG	TATA spare parts
282965700101	ASSY ROOF HEADER FRONT	TATA spare parts
282965708201	ROOF PANEL BS2/3/4/6	TATA spare parts
282965708202	ROOF HEADER FRONT	TATA spare parts
282965708203	PANEL ROOF HEADER REAR	TATA spare parts
282965708204	ROOF PANEL REAR	TATA spare parts
282966100101	ASSY STRUCTURE CNG CYL COVER	TATA spare parts
282966106301	TOP LID CNG CYL COVER-MAGIC CNG	TATA spare parts
282966106302	TOP COVER-MAGIC CNG	TATA spare parts
282966106303	PANEL FRONT CYL COVER-MAGIC CNG	TATA spare parts

282966106304	PANEL SIDE RH CNG CYL COVER-MAGIC CNG	TATA spare parts
282966106305	PANEL REAR CYL COVER-MAGIC CNG	TATA spare parts
282967100101	WINDSHIELD GLASS BS2/3/4/6	TATA spare parts
282967106301	WINDSCREEN MOULD	TATA spare parts
282967106304	WINDSHIELD MOULD BS2/3/4/6	TATA spare parts
282967800102	ASSY. REAR SLIDING WINDOW BS1/2/3/4	TATA spare parts
282967802301	GLASS-REAR WINDOW	TATA spare parts
282967806301	MOULD-REAR GLASS	TATA spare parts
282967806302	REAR GLASS MOULD	TATA spare parts
282967806304	MOULD GLASS REAR WINDOW BS6	TATA spare parts
282968406302	ENGINE COVER CARPET	TATA spare parts
282968406303	REAR CROSS MEMBER CARPET	TATA spare parts
282968406304	ENGINE COVER INSULATION	TATA spare parts
282968406305	WHEEL ARCH INSULATION	TATA spare parts
282968406306	WHEEL ARCH INSULATION RH	TATA spare parts
282968406307	INSULATION PAD LH	TATA spare parts
282968406308	INSULATION PAD RH	TATA spare parts
282968406309	OIL FILLING COVER INSULATION	TATA spare parts
282968406310	ENGINE COVER INSULATION - GLASS WOOL	TATA spare parts
282968406313	REAR FLOOR MAT	TATA spare parts
282968406315	CARPET FULL REAR CROSS MEM PC	TATA spare parts
282968406316	MIDDLE FLOOR MAT	TATA spare parts
282968406318	INSULATION PAD LH - GLASS WOOL	TATA spare parts
282968406319	INSULATION PAD RH - GLASS WOOL	TATA spare parts
282968406320	OIL FILLING COVER INSULATION - GLASS WOO	TATA spare parts
282968406321	MIDDLE FLOOR MAT (2 SEATER RR	TATA spare parts
282968706302	PVC MATT WITH KINIFOAM	TATA spare parts
282968706303	FRONT WALL CARPET	TATA spare parts
282968706304	VERTICAL WALL CARPET	TATA spare parts
282968706305	VERTICAL WALL INSULATION	TATA spare parts
282968706307	VERTICAL WALL INSULATION - GLASS WOOL	TATA spare parts
282968706312	PVC MATT WITH KINIFOAM - ACE CNG	TATA spare parts
282968706313	FRONT WALL CARPET - ACE CNG	TATA spare parts
282968706314	VERTICAL WALL CARPET-ACE CNG	TATA spare parts
282968706315	FLOOR CARPET WITH INSULATION ACE DICOR B	TATA spare parts
282968706319	FRONT WALL CARPET LHD DIESEL	TATA spare parts
282968706320	FRONT FLOOR CARPET WITH INSULATION LHD	TATA spare parts
282968900101	ASSY. DASHBOARD BS2/3/4	TATA spare parts
282968900105	ASSY DASH BOARD	TATA spare parts
282968900108	BEZEL - DIGITAL CLOCK	TATA spare parts
282968900110	ASSY DASHBOARD EV-LHD FOR DEFROST-DEMIST	TATA spare parts
282968900117	ASSY DASHBAORD LHD DIESEL	TATA spare parts
282968906302	NACELLE FRONT	TATA spare parts
282968906302C7	GRANIT_BLACK-NACELLE FRONT BS6	TATA spare parts
282968906303	NACELLE REAR	TATA spare parts
282968906303C7	GRANIT_Black-NACELLE REAR BS6	TATA spare parts
282968906304	CAP DASHBOARD MTG.	TATA spare parts

282968906306	CAP DASH BOARD MTG	TATA spare parts
282968906307	BEZEL - INSTRUMENT CLUSTER	TATA spare parts
282968906308	BAZEL DIGITAL CLOCK	TATA spare parts
282968906309	CAP DASH BOARD - BRAKE FL RESERVOIR	TATA spare parts
282968906310	LOCK GLOVE BOX	TATA spare parts
282968906311	CAP DASHBOARD MTG SCREW	TATA spare parts
282968906312	NACELLE FRONT	TATA spare parts
282968906313	NACELLE REAR	TATA spare parts
282968906318	CAP DASH BOARD-BRAKE FLUID RESERVOIR	TATA spare parts
282968906346	CAP AUX TANK LHD	TATA spare parts
282969100101	ASSY AIR INTAKE GRILL	TATA spare parts
282969100102	ASSY AIR INTAKE GRILL TOP	TATA spare parts
282969106301	A PILLAR TRIM UPPER LH	TATA spare parts
282969106301AQ	LINEN-`A PILLAR TRIM UPPER LH BS6	TATA spare parts
282969106302	A PILLAR TRIM UPPER RH	TATA spare parts
282969106302AQ	LINEN-`A PILLAR TRIM UPPER RH BS6	TATA spare parts
282969106303	TRIM PAD FRONT LH	TATA spare parts
282969106304	PAD SIDE WALL INNER RH	TATA spare parts
282969106305	PAD SIDE WALL REAR INNER LH	TATA spare parts
282969106306	TAIL LAMP TRIM LH	TATA spare parts
282969106307	TAIL LAMP TRIM RH	TATA spare parts
282969106309	A PILLAR TRIM UPPER LH	TATA spare parts
282969106310	A PILLAR TRIM UPPER RH	TATA spare parts
282969106312	COVER SIDE TUBE FRONT LH	TATA spare parts
282969106313	COVER SIDE TUBE REAR LH	TATA spare parts
282969106318	A PILLAR TRIM UPPER RH LHD	TATA spare parts
282969306301	TUBE COVER REAR (PC)	TATA spare parts
282969306302	TOP COVER REAR(PC)-RH	TATA spare parts
282969506301	HEADLINER	TATA spare parts
282969506303	HEAD LINER FOR PC	TATA spare parts
282969506304	HEADLINER REAR	TATA spare parts
282969506316	REAR HEADLINER WITH HARD BOARD	TATA spare parts
282969506320	COVER CROSS TUBE FRONT	TATA spare parts
282969506321	COVER CROSS TUBE MIDDLE	TATA spare parts
282969506322	COVER CROSS TUBE REAR	TATA spare parts
282969506323	HEADLINER LHD	TATA spare parts
282970000101	ASSY 2.2M LOAD BODY-SIDE FIXED	TATA spare parts
282970000102	ASSY 2.2M LOAD BODY-SIDE DROP	TATA spare parts
282970000105	ASSY KIT LOADBODY SIDE FIXED	TATA spare parts
282970000106	ASSY KIT LOADBODY SIDE DROP	TATA spare parts
282970000107	ASSY 2.2M LOAD BODY (SIDE FIXED) PAINTED	TATA spare parts
282970000107BF	ASSY 2.2M LOAD BODY (SIDE FIXED) PAINTED	TATA spare parts
282970000107BN	ASSY 2.2M LOAD BODY (SIDE FIXED) RUBY RE	TATA spare parts
282970000107CN	2.2M LOAD BODY (SIDE FIXED) PAINTED	TATA spare parts
282970000107FD	ASSY 2.2M LOAD BODY (SIDE FIXED) PAINTED	TATA spare parts
282970000107FW	IVORY_ WHITE-ASSY 2.2M LOAD BODY (SIDE FI	TATA spare parts
282970000107H3	ASSY 2.2M LOAD BODY (SIDE FIXED) PAINTED	TATA spare parts

282970000108	ASSY 2.2M LOAD BODY-SIDE DROP	TATA spare parts
282970000108BF	ASSY 2.2M LOAD BODY (SIDE DROP) PAINTED	TATA spare parts
282970000108BN	ASSY 2.2M LOAD BODY (SIDE DROP) PAINTED	TATA spare parts
282970000120	ASSY LOADBODY SHELL 2.2M SIDE FIX CNG	TATA spare parts
282970000129	ASSY LOADBODY COMPLETE SIDE FIXED	TATA spare parts
282970000155BF	ASSY 2.2M LOAD BODY	TATA spare parts
282970000155C9	ASSY 2.2M LOAD BODY (SIDE DROP) PAINTED	TATA spare parts
282970100116	ASSY SKIRT REAR DRIVE CHASSIS	TATA spare parts
282970100132	ASSY MUDGUARD CNG	TATA spare parts
282970100150	CROSS MEMBER ASSY-REAR BS6	TATA spare parts
282970100152	CROSS MEMBER ASSY-FRONT BS6	TATA spare parts
282970100177	ASSY TAILGATE SKIRT (0.75T) LOAD BODY CN	TATA spare parts
282970100178	ASSY TAILGATE CNG LOAD BODY OPTIMIZE	TATA spare parts
282970100184	ASSY CROSS MEMBER-2ND ROW OPTIMIZE BS6	TATA spare parts
282970100185	ASSY MID C/M OPTIMIZE (BODY MTG 3ROW) BS	TATA spare parts
282970100186	ASSEMBLY CROSS MEMBER SHORT OPTIMIZE BS6	TATA spare parts
282970106301	REFLECTIVE TAPE RED	TATA spare parts
282970106302	REFLECTIVE TAPE RED	TATA spare parts
282970106303	REFLECTIVE TAPE RED	TATA spare parts
282970110101	ASSEMBLY MUDGUARD FRONT LH OPTIMIZEBS6	TATA spare parts
282970110102	ASSEMBLY MUDGUARD FRONT RH OPTIMIZEBS6	TATA spare parts
282970118265	FRONT PANEL	TATA spare parts
282970118274	MUDGUARD SUPPORT PANEL OPTIMIZE BS6	TATA spare parts
282970128012	FRONT COVER	TATA spare parts
282970128203	TAIL GATE PANEL-CNG LOAD BODY OPTIMIZE	TATA spare parts
282970208201	FRONT PANEL - SIDE FIXED	TATA spare parts
282970208202	FRONT PANEL - SIDE DROP	TATA spare parts
282970208213	COVER FRONT BS6-PH2	TATA spare parts
282970300103	ASSY SIDEWALL LH SIDE DROP	TATA spare parts
282970300104	ASSY SIDEWALL RH	TATA spare parts
282970308201	SIDE PANEL LH - SIDE FIXED	TATA spare parts
282970308202	SIDE PANEL RH - SIDE FIXED	TATA spare parts
282970308203	SIDE PANEL LH - SIDE DROP	TATA spare parts
282970308204	SIDE PANEL RH - SIDE DROP	TATA spare parts
282970408201	TAIL GATE PANEL	TATA spare parts
282970900104	ASSY CHAIN	TATA spare parts
282970903301	BKT CHAIN HOOK	TATA spare parts
282970904201	ASSY TOGGLE CLAMP TATA ACE	TATA spare parts
282970906301	DAMPER - SIDE POST REAR LH	TATA spare parts
282970906303	PANEL END CAP LH	TATA spare parts
282970906304	RUBBER STOPPER	TATA spare parts
282970906305	BALLATA PACKING	TATA spare parts
282970906308	RUBBER PAD CUB LOAD BODY	TATA spare parts
282970906309	MUDFLAP FOR LOADBODY	TATA spare parts
282970906311	SEAL LOADBODY FRONT COVER	TATA spare parts
282970906312	DAMPER SIDE POST REAR RH	TATA spare parts
282970908201	EXTENSION MUDFLAP	TATA spare parts

282970908202	STRIP MUD FLAP	TATA spare parts
282970908203	HINGE FIXED BS6	TATA spare parts
282972000105	ASSY.FRONT DOOR SHELL COMP-LH	TATA spare parts
282972000106	ASSY.FRONT DOOR SHELL COMP-RH	TATA spare parts
282972000109	ASSY. FRT DOOR SHELL LH CED COAT BS2/3/4	TATA spare parts
282972000110	ASSY. FRT DOOR SHELL RH CED COAT BS2/3/4	TATA spare parts
282972000113	ASSY FRONT DOOR SHELL COML LH - LHD	TATA spare parts
282972000114	ASSY FRONT DOOR SHELL COMP RH LHD	TATA spare parts
28297200Z109	ASSY FRONT DOOR COMP CED COTED	TATA spare parts
28297200Z110	ASSY.FRONT DOOR COMPLETE-CED COATED	TATA spare parts
28297200Z113	ASSY.FRONT DOOR SHELL COMP-LH	TATA spare parts
28297200Z114	ASSY.FRONT DOOR SHELL COMP-RH	TATA spare parts
282972200101	ASSY FRONT DOOR SHELL LH	TATA spare parts
282972200102	ASSY.FRONT DOOR SHELL RH	TATA spare parts
282972200105	ASSY FRONT DOOR INNER LH	TATA spare parts
282972200106	ASSY FRONT DOOR INNER RH	TATA spare parts
282972200113	ASSY GLASS GUIDE CHANNEL REAR LH	TATA spare parts
282972200114	ASSY GLASS GUIDE CHANNEL REAR RH	TATA spare parts
282972200119	ASSY WAIST REINF OUTER LH BS6	TATA spare parts
282972200120	ASSY WAIST REINF OUTER RH BS6	TATA spare parts
282972208201	PANEL OUTER FRONT DOOR-LH BS6-PH2	TATA spare parts
282972208202	PANEL OUTER FRONT DOOR-RH BS6	TATA spare parts
282972208205	PANEL INNER FRONT DOOR-LH BS6	TATA spare parts
282972208206	PANEL INNER FRONT DOOR-RH BS6	TATA spare parts
282972208213	INTRUSION PANEL FRONT DOOR LH BS6	TATA spare parts
282972208214	INTRUSION PANEL FRONT DOOR RH BS6	TATA spare parts
282972300103	ASSY CHECK STRAP	TATA spare parts
282972300107	ASSY. DOOR HINGE LH BS2/3/4	TATA spare parts
282972300108	ASSY. DOOR HINGE RH BS2/3/4	TATA spare parts
282972300109	ASSY WAIST SEAL OUTER LH	TATA spare parts
282972300110	ASSY WAIST SEAL OUTER RH	TATA spare parts
282972300111	ASSY WAIST SEAL INNER LH	TATA spare parts
282972300112	ASSY WAIST SEAL INNER RH	TATA spare parts
282972300115	ASSY CHECK STRAP	TATA spare parts
282972300116	ASSY INNER HANDLE	TATA spare parts
282972300117	ASSY INNER HANDLE RH	TATA spare parts
282972300118	ASSY CHECK STRAP	TATA spare parts
282972300119	ASSY. DOOR LATCH LH BS2/3/4/6	TATA spare parts
282972300120	ASSY. DOOR LATCH RH BS2/3/4/6	TATA spare parts
282972300121	ASSY DOOR LATCH LH	TATA spare parts
282972300122	ASSY DOOR LATCH RH	TATA spare parts
282972300123	KIT ASSY LOCK	TATA spare parts
282972300130	ASSY POP-UP KNOB LINK LH	TATA spare parts
282972300131	ASSY POP-UP KNOB LINK RH	TATA spare parts
282972300132	ASSY INNER HANDLE	TATA spare parts
282972300134	ASSY INNER HANDLE	TATA spare parts
282972300134C7	GRANIT_BLACK-ASSY INNER HANDLE (JAY SWIT	TATA spare parts



282972300135	KIT-LOCKS BS2/3/4	TATA spare parts
282972300138	ASSY LOCK SET -PC	TATA spare parts
282972300143	ASSY. HINGE FRONT DOOR BS4/6	TATA spare parts
282972303301	BRACKET - CHECK STRAP MTG	TATA spare parts
282972306001	LINK OUTER HANDLE -FRONT DOOR	TATA spare parts
282972306003	LINK - INNER HANDLE LH	TATA spare parts
282972306004	LINK - INNER HANDLE RH	TATA spare parts
282972306005	LINK - POP UP KNOB LH	TATA spare parts
282972306006	LINK - POP UP KNOB RH	TATA spare parts
282972306007	LINK - LOCK BARREL LH	TATA spare parts
282972306008	LINK - LOCK BARREL RH	TATA spare parts
282972306306	DOOR PULL	TATA spare parts
282972306306C7	GRANIT_BLACK-DOOR PULL HANDLE BS6	TATA spare parts
282972306307	MOULD DUST SEAL LH	TATA spare parts
282972306309	FRONT DOOR DUST SEAL MOULD LH	TATA spare parts
282972306310	FRONT DOOR DUST SEAL MOULD (M/S METZELER)	TATA spare parts
282972306311	DOOR DAMPER	TATA spare parts
282972306312	WAIST SEAL ASSY INNER-LH	TATA spare parts
282972306313	WAIST SEAL ASSY INNER-RH	TATA spare parts
282972306314	WAIST SEAL ASSY FRONT DOOR OUTER-LH	TATA spare parts
282972306315	WAIST SEAL ASSY FRONT DOOR OUTER-RH	TATA spare parts
282972306317	RUBBER PAD DOOR OUTER	TATA spare parts
282972306318	DOOR PULL HANDLE	TATA spare parts
282972306319	GROMMET (POP UP KNOB	TATA spare parts
282972306702	CHECK STRAP PIN	TATA spare parts
282972500101	ASSY.GLASS GUIDE CHANEL FRONT LH	TATA spare parts
282972500104	ASSY.GLASS GUIDE CHANEL FRONT-RH	TATA spare parts
282972500105	ASSY. WINDOW REG. LH BS2/3/4/6	TATA spare parts
282972500106	ASSY. WINDOW REG. RH BS2/3/4/6	TATA spare parts
282972500108	ASSY WINDOW REGULATOR LH	TATA spare parts
282972500109	ASSY WINDOW REGULATOR RH	TATA spare parts
282972500110	ASSY. HANDLE WINDOW WINDING BS2/3/4	TATA spare parts
282972500110C7	ASSY HANDLE WINDOW WINDING BS6	TATA spare parts
282972500115	ASSY WINDOW REGULATOR LH	TATA spare parts
282972500116	ASSY WINDOW REGULATOR RH	TATA spare parts
282972502301	REG. GLASS FRONT DOOR LH BS2/3/4/6	TATA spare parts
282972502302	REG. GLASS FRONT DOOR RH BS2/3/4/6	TATA spare parts
282972506301	MOULD GLASS RUN CHANEL FRONT DOOR-LH	TATA spare parts
282972506302	MOULD GLASS RUN CHANEL FRONT DOOR-RH	TATA spare parts
282972506307	MOULD - PRIMARY SEAL LH	TATA spare parts
282972506308	MOULD - PRIMARY SEAL RH	TATA spare parts
282972506309	FRONT DOOR GLASS RUN BS2/3/4/6	TATA spare parts
282972506310	FRONT DOOR GLASS RUN BS2/3/4/6	TATA spare parts
282972506311	PRIMARY SEAL FRONT DOOR LH BS2/3/4/6	TATA spare parts
282972506312	MOULD PRIMARY SEAL RH BS2/3/4/6	TATA spare parts
282972508001	SPECIAL SCREW (M6 X 12)	TATA spare parts
282972700101	ASSY. DOOR PAD LH - STD BS2/3/4/6	TATA spare parts

282972700101C7	GRANIT_BLACK-ASSY DOOR PAD LH - STD BS6	TATA spare parts
282972700102	ASSY. DOOR PAD RH - STD BS2/3/4/6	TATA spare parts
282972700102C7	GRANIT_BLACK-ASSY DOOR PAD RH - STD BS6	TATA spare parts
282972700105	ASSY DOOR PAD LH	TATA spare parts
282972700106	ASSY DOOR PAD RH	TATA spare parts
282972706304	PLASTIC MEMBRANE FRONT DOOR LH	TATA spare parts
282972706305	PLASTIC MEMBRANE FRONT DOOR RH	TATA spare parts
282972706306	PLASTIC MEMBRANE INNER HANDLE CUTOUT	TATA spare parts
282973000102	ASSY REAR DOOR SHELL	TATA spare parts
282973000104	ASSY REAR DOOR COMP WITH HINGES	TATA spare parts
282973000105	ASSY REAR DOOR SHELL COMPLETE CED COATED	TATA spare parts
28297300Z104	ASSY REAR DOOR COMP WITH HINGES LH(COATE	TATA spare parts
282973300101	ASSY REAR DOOR HINGE	TATA spare parts
282973300108	ASSY INNER HANDLE REAR DOOR	TATA spare parts
282973303801	DOVETAIL DOOR SIDE	TATA spare parts
282973306001	LINK OUTER HANDLE TO LATCH	TATA spare parts
282973306002	LINK INNER HANDLE TO LATCH	TATA spare parts
282973306003	LINK POP UP KNOB TO LATCH	TATA spare parts
282973306301	REAR DOOR TOP COVER	TATA spare parts
282973306302	STRAP REAR DOOR	TATA spare parts
282973306303	GROMMET POP UP KNOB	TATA spare parts
282973306304	SCUFF PLATE REAR DOOR SIDE	TATA spare parts
282973506301	MOULD PRIMARY SEAL RR DOOR	TATA spare parts
282973506303	SIDE DOOR PRIMARY SEAL	TATA spare parts
282973700101	ASSY PAD REAR DOOR	TATA spare parts
282973706301	PLASTIC MEMBRANE RR DOOR LH	TATA spare parts
282973706302	PLASTIC MEMBRANE RR DOOR RH	TATA spare parts
282973706303	PLUG BUTTON	TATA spare parts
282974000101	ASSY TAILGATE SHELL COMP WITH HINGES	TATA spare parts
282974000102	ASSY TAIL - GATE SHELL BS6	TATA spare parts
282974000105	ASSY TAILGATE SHELL COMPLETE CED COATED	TATA spare parts
28297400Z101	ASSY TAILGATE (HEMMED)	TATA spare parts
282974206301	REGISTRATION PLATE GARNISH T GATE	TATA spare parts
282974300101	ASSY HINGE TAILGATE	TATA spare parts
282974306001	LINK OUTER HANDLE TO LATCH T'GATE	TATA spare parts
282974306002	LINK INNER HANDLE TO LATCH	TATA spare parts
282974306301	TAIL GATE TOP COVER	TATA spare parts
282974306302	ASSY CHECK STRAP	TATA spare parts
282974306303	HIGH COVER	TATA spare parts
282974306305	NUMBER PLATE STOPPER	TATA spare parts
282974506301	MOULD PRIMARY SEAL TAILGATE	TATA spare parts
282974506302	TAILGATE PRIMARY SEAL	TATA spare parts
282974700101	ASSY PAD TAIL GATE	TATA spare parts
282974706301	PLASTIC MEMBRANE TAILGATE	TATA spare parts
282979100112	ASSY TUBULAR STRUCTURE COMPLETE	TATA spare parts
282979100128	ASSY TUBULAR STRUCTURE COMPLETE - ACE MA	TATA spare parts
282979108249	EXTN RAIN CHANNEL LOWER LH	TATA spare parts

282979108250	EXTN RAIN CHANNEL LOWER RH	TATA spare parts
282979200101	ASSY CANOPY COMP STD BS6	TATA spare parts
282979200103	ASSY. CANOPY COMPLETE -TMETC BS2/3/4	TATA spare parts
282979200103FD	ASSY CANOPY -TMETC	TATA spare parts
282981006301	STICKER - MPGI	TATA spare parts
282981006302	STICKER - SIDE DOOR LH (ACE CNG)	TATA spare parts
282981006303	STICKER - SIDE DOOR RH (ACE-CNG)	TATA spare parts
282981006304	STICKER FOR SIDE PANEL LH-ACE MAGIC CNG	TATA spare parts
282981006305	STICKER FOR SIDE PANEL RH-ACE MAGIC CNG	TATA spare parts
282981100102	ASSY OUTER REAR VIEW MIRROR	TATA spare parts
282981100104	ASSY SUNVISOR RH	TATA spare parts
282981100106	REAR VIEW MIRROR-INNER	TATA spare parts
282981100107	REAR VIEW MIRROR-INNER	TATA spare parts
282981100107C7	GRANIT_BLACK-ASSY INNER REAR VIEW MIRROR	TATA spare parts
282981100108	ASSY DRIVER SEAT	TATA spare parts
282981100110	ASSY GRAB HANDLE	TATA spare parts
282981100110C7	GRANIT_Black-GRAB HANDLE ASSY BS6	TATA spare parts
282981100111	ASSY ORVM RH	TATA spare parts
282981100116	ASSY ORVM(DOOR MOUNTED) LH	TATA spare parts
282981100117	ASSY ORVM(DOOR MOUNTED) RH	TATA spare parts
282981100118	ASSY ORVM(DOOR MOUNTED) LH	TATA spare parts
282981100118C7	GRANIT_Black-ASSY ORVM(DOOR MOUNTED) LH	TATA spare parts
282981100119	ASSY ORVM(DOOR MOUNTED) RH	TATA spare parts
282981100119C7	GRANIT_Black-ASSY ORVM(DOOR MOUNTED) RH	TATA spare parts
282981100121	ASSY LATCH FUEL LID	TATA spare parts
282981100122	ASSY HAND HOLD	TATA spare parts
282981100124	ASSY GRAB HANDLE PC	TATA spare parts
282981100125	ASSY SUNVISOR	TATA spare parts
282981100126	INNER REAR VIEW MIRROR	TATA spare parts
282981100127	SUNVISOR LH	TATA spare parts
282981106303	COVER - B PILLAR LH	TATA spare parts
282981106304	COVER - B PILLAR RH	TATA spare parts
282981106308	COVER UNDER DASHBOARD LH	TATA spare parts
282981106308C7	GRANIT_Black-COVER UNDER DASHBOARD LH B	TATA spare parts
282981106309	COVER UNDER DASHBOARD RH	TATA spare parts
282981106309C7	GRANIT_Black-COVER UNDER DASHBOARD RH B	TATA spare parts
282981106312	PLASTIC MEMBRANE FRONT PANEL BS6	TATA spare parts
282981106318	SIDE WALL TOP COVER	TATA spare parts
282981106319	COVER-AIR INTAKE	TATA spare parts
282981106321	COVER UNDER DASHBOARD LH LHD DIESEL	TATA spare parts
282981106325	COVER UNDER DASHBOARD RH RHD EV	TATA spare parts
282981107703	RUBBER PAD ORVM MTG	TATA spare parts
282981108001	PAN HEAD CONICAL SCREW	TATA spare parts
282981108207	RETAINER - INSULATION	TATA spare parts
282981153301	FUEL FILLER STOPPER BRACKET BS6	TATA spare parts
282981205301	STICKER-TUBULAR STRUCTURE	TATA spare parts
282981207701	SEAL - ENGINE COVER FRONT	TATA spare parts

282981207702	SEAL - ENGINE COVER REAR	TATA spare parts
282981207703	RUBBER SEAL	TATA spare parts
282981207705	SEAL GB MICRO SWITCH COVER BS6	TATA spare parts
282981207707	FRONT SEAL ENGINE COVER FRONT	TATA spare parts
282981207708	REAR SEAL ENGINE COVER FRONT A	TATA spare parts
282981300101	OFFER DRG ASSY GEAR SHIFT COVER	TATA spare parts
282981300103	ASSY ECU COVER	TATA spare parts
282981306301	ACCL PEDAL COVER BSIV	TATA spare parts
282981306302	REAR ENGINE COVER BOTTOM	TATA spare parts
282981306303	REAR ENGINE COVER TOP	TATA spare parts
282981306304	FUEL PIPE COVER	TATA spare parts
282981306305	ENGINE COVER LH	TATA spare parts
282981306307	REAR ENGINE COVER BOTTOM	TATA spare parts
282981306308	REAR ENGINE COVER TOP	TATA spare parts
282981306312	ECU COVER ACE BS IV	TATA spare parts
282981306313	PARKING BRAKE HIDER ACE BS IV	TATA spare parts
282981306314	PARKING BRAKE HIDER SUPPORT ACE BS IV	TATA spare parts
282981400101	ASSY UTILITY POCKET	TATA spare parts
282981806301	MASCOT FOR CUB	TATA spare parts
282981806302	MASCOT ACE -HT	TATA spare parts
282981806304	MAGIC MASCOT	TATA spare parts
282981806305	MASCOT HT	TATA spare parts
282981806307	ACE-EX MASCOT	TATA spare parts
282982400107	KIT FRONT WIPER SYSTEM	TATA spare parts
282982400108	ASSY.WIPER MOTOR WITH MTG.BRACKET	TATA spare parts
282982400109	ASSY.¿WIPER¿¿SPEED-M/S.LUCAS¿TVS BS6	TATA spare parts
282982400110	WIPER ARM DRIVER SIDE BS4	TATA spare parts
282982400111	WIPER ARM CO-DRIVER SIDE BS4	TATA spare parts
282982400113	ASSY.WIPER ARM & BLADE DR-SIDE	TATA spare parts
282982400114	ASSY.WIPER ARM & BLADE CO-DRSIDE	TATA spare parts
282982400115	ASSY. WIPER ARM & BLADE DR-SIDE BS2-6	TATA spare parts
282982400116	ASSYWIPER ARM & BLADE CO-DRSIDE	TATA spare parts
282982400118	ASSY NOZZLE UNIT	TATA spare parts
282982400120	ASSY.WIPER MOTOR WITH MTG. BKT	TATA spare parts
282982400121	KIT FRONT WIPER SYSTEM	TATA spare parts
282982400125	KIT WASHER SYSTEM	TATA spare parts
282982400132	ASSY. WIPER MOTOR	TATA spare parts
282982400133	ASSY. ARM BLADE & NOZZLE FITMENT DRIVER	TATA spare parts
282982400135	ASSY. ARM BLADE & NOZZLE FITMENT	TATA spare parts
282982400136	ASSY. NOZZLE BS6	TATA spare parts
282982400137	ASSY WIPER KIT FRONT LHD	TATA spare parts
282982400138	ASSY WIPER ARM AND BLADE WITH NOZZLE DR	TATA spare parts
282982400142	ASSY WIPER BLADE ARM AND BLADE WITH NOZZ	TATA spare parts
282982400144	ASSY WIPER ARM AND BLADE DR SIDE	TATA spare parts
282982400145	ASSY WIPER ARM AND BLADE CO DR	TATA spare parts
282982400147	ASSY WIPER MOTOR WITH BKT	TATA spare parts
282982400148	ASS WIPER ARM AND BLADE¿ DR LHD	TATA spare parts

282982400149	ASSY WIPER ARM & BLADEç CODR LHD	TATA spare parts
282982406311	TEE JOINT	TATA spare parts
282982406314	FEXIBLE PIPE BS6	TATA spare parts
282982406317	FEXIBLE PIPE DRIVER SIDE	TATA spare parts
282982406318	FLEXIBLE PIPE CO-DRIVER SIDE	TATA spare parts
282982407501	RUBEER BOOT (WHEEL BOX)	TATA spare parts
282982407502	RUBBER GROMMET	TATA spare parts
282982407503	CLIP FOR PIPE HOLDING (WINDSHIELD WASHER	TATA spare parts
282982408205	WIPER MOTOR MOUNTING BRACKET	TATA spare parts
282982408207	WIPER MOTOR BRACKET	TATA spare parts
282982408208	WIPER MOTOR MTG BKT LHD	TATA spare parts
282982409906	WHEELBOXDRIVERSIDE-M/S.LUCASTVS BS6	TATA spare parts
282982409907	WHEELBOXDRIVERSIDE-M/S.LUCASTVS BS6	TATA spare parts
282982409910	WIPER BLADE CO-DRSIDE 425MM	TATA spare parts
282982409911	WIPER BLADE DRIVER SIDE 500MM	TATA spare parts
282982409919	PRIARYLINKASSY. BS6	TATA spare parts
282982409920	TANDEMLINKASSY. BS6	TATA spare parts
282982409921	ASSY. PUMP BS6	TATA spare parts
282983100101	VENTILATION DUCT ASSY LH BS6	TATA spare parts
282983106301	VENTILATION DUCT LH	TATA spare parts
282983106302	VENTILATION DUCT RH	TATA spare parts
282983106306	GRILLE VENTILATION BS6	TATA spare parts
282983607701	RUBBER GASKET FOR AIR VENT	TATA spare parts
282983607702	CROSS LINK FOAM VENTILATION DUCT	TATA spare parts
282988500102	ASSY FRONT BUMPER	TATA spare parts
282988500102C7	GRANIT_BLACK-ASSY FRONT BUMPER BS6	TATA spare parts
282988500102FD	ASSY FRONT BUMPER	TATA spare parts
282988500102H3	ASSY FRONT BUMPER	TATA spare parts
282988500104	ASSY. FRONT BUMPER PC BS2/3/4/6	TATA spare parts
282988506301	BUMPER FRONT	TATA spare parts
282988506302	REFLECTIVE TAPE WHITE	TATA spare parts
282988506701	FRT BUMPER SIDE ADJUSTABLE SCREW	TATA spare parts
282988600102	ASSY REAR MIDDLE BUMPER	TATA spare parts
282988606302	REAR BUMPER CORNER LH	TATA spare parts
282988606303	REAR BUMPER CORNER RH	TATA spare parts
282988606304	TOW HOOK COVER	TATA spare parts
282988608201	REAR BUMPER MIDDLE	TATA spare parts
282988700101	TOGGLE CLAMP	TATA spare parts
282988800101	ASSY FRONT PANEL OUTER	TATA spare parts
282988800101BF	ASSY FRONT PANEL OUTER ARCTIC WHITE	TATA spare parts
282988800101BN	ASSY FRONT PANEL OUTER RUBY RED	TATA spare parts
282988800101BU	ASSY FRONT PANEL OUTER JET BLACK	TATA spare parts
282988800101CN	ASSY FRONT PANEL OUTER IRISH CREAM	TATA spare parts
282988800101EP	ASSY FRONT PANEL OUTER YELLOW	TATA spare parts
282988800101FK	ASSY FRONT PANEL OUTER CNG GREEN	TATA spare parts
282988800102	ASSY FRONT PANEL OUTER COMPLETE	TATA spare parts
282988800104	ASSY. FRONT PANEL OUTER (SMC) BS2/4/6	TATA spare parts

282988800104BF	FRONT PANEL OUTER ARCTIC WHITE BS2/3/4	TATA spare parts
282988800104BN	ASSY FRONT PANEL OUTER RUBY RED	TATA spare parts
282988800104BU	ASSY FRONT PANEL OUTER JET BLACK	TATA spare parts
282988800104CN	FRONT PANEL OUTER IRISH CREAM BS2/3/4	TATA spare parts
282988800104EP	ASSY FRONT PANEL OUTER YELLOW	TATA spare parts
282988800104FD	ASSY FRONT PANEL OUTER	TATA spare parts
282988800104FK	ASSY FRONT PANEL OUTER CNG GREEN	TATA spare parts
282988800104FW	IVORY_WHITE-ASSY FRONT PANEL OUTER	TATA spare parts
282988800104H3	ASSY FRONT PANEL OUTER	TATA spare parts
282988800104HU	AZURE_BLUE-PANEL ASSY FRONT-OUTER BS6	TATA spare parts
282988800104JS	TITANIUM_WH-ASSY FRONT PANEL OUTER (SMC)	TATA spare parts
282988800105CN	ASSY FRONT PANEL OUTER IRISH CREAM	TATA spare parts
282988800106BF	ASSY FRONT PANEL OUTER COMP	TATA spare parts
282988800111BF	PANEL ASSY FRONT-OUTER BS6	TATA spare parts
282988806301	PANEL FRONT OUTER	TATA spare parts
282988806302	GRILL FRONT PANEL OUTER	TATA spare parts
282988806303	MOULD - FRONT PANEL SEAL	TATA spare parts
282988806305	FRONT PANEL SEAL BS2/3/4/6	TATA spare parts
282988806306	POLYCARBONETFILMBELOWT-EMBLEM BS6	TATA spare parts
282988806307	POLYCARBONATEFILMCORNERMTGLH BS6	TATA spare parts
282988806308	POLYCARBONATEFILMCORNERMTGRH BS6	TATA spare parts
282988900108	BEZEL - DIGITAL CLOCK	TATA spare parts
282991000104	ASSY DRIVER SEAT WITHOUT HEAD REST	TATA spare parts
282991000105	ASSY DRIVER SEAT PC	TATA spare parts
282991000106	ASSY CO-DRIVER SEAT-PC	TATA spare parts
282991000107	ASSY DRIVER SEAT PC	TATA spare parts
282991000111	ASSY DRIVER SEAT	TATA spare parts
282991500101	DRIVER SEAT BELT KIT WITH ELR	TATA spare parts
282991500103	FRONT SEAT BET KIT WITH ELR	TATA spare parts
282991500107	ASSY. SEAT BELT KIT COMP. BS2/3/4/6	TATA spare parts
282991500107C7	GRANIT_BLACK-KIT-SEAT BELT WITH ELR BS6	TATA spare parts
282991500108	SEAT BELT KIT LH - ELR	TATA spare parts
282991500109	SEAT BELT KIT RH - ELR	TATA spare parts
282991500112	ASSY STEM BUCKLE LH	TATA spare parts
282991500113	ASSY STEM BUCKLE RH	TATA spare parts
282991500119	ASSY FRONT SEAT BELT ELR(IFB) LH BS6	TATA spare parts
282991500120	ASSY FRONT SEAT BELT ELR RH	TATA spare parts
282991500121	ASSY FRONT SEAT BELT KIT-PC	TATA spare parts
282991500128	DRIVER SEAT BELT ASSY WITH ELR	TATA spare parts
282991500129	FRONT SEAT BELT KIT WITH ELR	TATA spare parts
282991500131	ASSY STEM BUCKLE RH	TATA spare parts
282991500132	DRIVER ELR ASSY RH	TATA spare parts
282992000102	ASSY FRONT FACING SEAT PC	TATA spare parts
282992000103	ASSY REAR FACING SEAT	TATA spare parts
282992000104	ASSY.FRONT FACING SEAT FIXED BACK	TATA spare parts
282992000109	ASSY REAR FACING SEAT WITH LATCHING	TATA spare parts
282992000112	ASSY TWO SEATER REAR FACING SEAT	TATA spare parts

282992500106	ASSY SEAT BELT KIT THIRD ROW	TATA spare parts
282992500116	ASSY NON-ELR BELT KIT THIRD ROW	TATA spare parts
282994000101	ASSY CO-DRIVER SEAT COMPLETE	TATA spare parts
282994000102	ASSY CO-DRIVER SEAT COMPLETE	TATA spare parts
282994000104	ASSY CO-DRIVER SEAT-PC	TATA spare parts
282994000108	ASSY CO-DRIVER SEAT	TATA spare parts
282994300101	ASSY CO-DRIVER SEAT MTG BKT BOTTOM LH	TATA spare parts
282994500101	CO-DRIVER SEAT BELT KIT WITH ELR	TATA spare parts
282994500105	CO-DRIVER SEAT BELT ASSY WITH ELR	TATA spare parts
282994500106	ASSY STEM BUCKLE LH	TATA spare parts
282994500107	CO-DRIVER ELR ASSY LH	TATA spare parts
282999000101	ASSY KNOB(SPARE WHEEL MTG)	TATA spare parts
282999005601	SPARE WHEEL KNOB	TATA spare parts
282999005601C7	GRANIT_BLACK-KNOB M6 BS6	TATA spare parts
282999006501	M6 CAGE NUT	TATA spare parts
282999506301	TREE CLIP	TATA spare parts
282999506301AQ	LINEN-TREE CLIP BS6	TATA spare parts
282999506302	CANOPY TOP MTG CLIP	TATA spare parts
282999506303	CANOPY SIDE MTG CLIP BS2/3/4	TATA spare parts
282999506304	TREE CLIP A PILLAR	TATA spare parts
282999706301	GROMMET FRONT PANEL MTG	TATA spare parts
283015400101	ALT 12V 90A INT FAN 63 DIA 6-PK	TATA spare parts
283015400102	BRACKET ASSY FRONT	TATA spare parts
283015400103	ROTOR ASSLY	TATA spare parts
283015400104	BRACKET ASSY REAR	TATA spare parts
283015400105	RECTIFIER ASSLY	TATA spare parts
283015400106	REGULATOR ASSLY	TATA spare parts
283015403101	BEARING	TATA spare parts
283015403102	BEARING ASSLY	TATA spare parts
283015403201	HEXAGOAN HEAD BOLT	TATA spare parts
283015403301	WORKING BKT FRONT	TATA spare parts
283015403302	WORKING BKT REAR	TATA spare parts
283015403401	INSERTS	TATA spare parts
283015403402	SLIDING BUSH	TATA spare parts
283015403403	INSUL BUSH	TATA spare parts
283015406501	HEXAGOAN NUT	TATA spare parts
283015406502	NUT	TATA spare parts
283015407001	PULLEY	TATA spare parts
283015407101	RETAINER PLATE	TATA spare parts
283015408001	FLANGE SCREW	TATA spare parts
283015408002	P.H. SCREW & WASHER	TATA spare parts
283015408003	P.H. SCREW & WASHER	TATA spare parts
283015408601	SPACER	TATA spare parts
283015409201	NUT & WASHER	TATA spare parts
283015409202	SPRING WASHER	TATA spare parts
283015409901	STATOR	TATA spare parts
283029100103	ASSY CLUTCH PIPE	TATA spare parts

283031000102	ASSY. FRAME XENON (DICR ENG TCD) BS3/4	TATA spare parts
283031000103	ASSY. FRAME COMP.(2.2LTR DICOR 4X2 31WB)	TATA spare parts
283031000105	FRAME XENON CREWCAB 2.2LDICOR 4*2	TATA spare parts
283031200104	ASSY TUBE(FOR GEARSHIFT LEVER EXTN.MTG)	TATA spare parts
283031200106	ASSY CROSS MEMBER (CENTER BEARING MTG.)	TATA spare parts
283031200111	ASSY TUBE (FOR GEAR BOX EXTENSION) - 4X2	TATA spare parts
283031200113	ASSY. CROSS MEMBER REAR	TATA spare parts
283031200120	ASSY CROSS MEMBER (CENTER BEARING MTG.)	TATA spare parts
283031200125	ASSY CROSS MEMBER (CENTER BEARING MTG.)	TATA spare parts
283031200126	ASSY.BRACKET ENGINE MTG REAR	TATA spare parts
283031200128	ASSY BRACKET	TATA spare parts
283031200131	ASSY CROSS MEMBER FRONT EXTENSION	TATA spare parts
283031210102	ASSY. BRACKET FRONT (FUEL TANK MTG.)	TATA spare parts
283031210103	ASSY CROSS MEMBER(FUEL TANK MTG)	TATA spare parts
283032100101	ASSY CROSS MEMBER(FRT SUSP LOWER W/B BKT	TATA spare parts
283040306901	HEX.BOLT M12	TATA spare parts
2830405	BREATHER CRANKCASE	TATA spare parts
2830409	SEAL O RING	TATA spare parts
283041000101	ASSY. PROPELLER SHAFT	TATA spare parts
283041100101	PROP.SHAFTCREW 4X2-2.2L -694M/997M	TATA spare parts
283042409901	TRANSFER LABLE L.C.R.V.	TATA spare parts
283042700104	ASSY. PARKING BRAKE CABLE REAR LH	TATA spare parts
283042800104	ASSY. BRACKET (TEE MTG.)	TATA spare parts
283042800106	ASSY. BRAKE HOSE FRONT	TATA spare parts
283042800107	ASSY. BRAKE HOSE FRONT	TATA spare parts
283042800108	ASSY. BRACKET LCRV MOUNTING	TATA spare parts
283043100101	ASSY. TANDEM MASTER CYL. DIA 25.4	TATA spare parts
283043500101	8INCH+9INCH TANDEM BOOSTER TMC DIA 25.4	TATA spare parts
283043500103	ASSY.VACUUM HOSE	TATA spare parts
283043500104	ASY.VACCUM BOOSTER 9"+8"WITH TMC25.4 BIL	TATA spare parts
283043504201	CLAMP (VACCUM HOSE)	TATA spare parts
283043505801	HOSE (VACCUM)	TATA spare parts
283043800101	ASSY. TUBE	TATA spare parts
283043800102	ASSY. TUBE	TATA spare parts
283043800103	ASSY.TUBE	TATA spare parts
283043800104	ASSY. TUBE	TATA spare parts
283043800105	ASSY. TUBE	TATA spare parts
283043800106	ASSY. TUBE	TATA spare parts
283043800107	ASSY. TUBE	TATA spare parts
283043800109	ASSEMBLY BRAKE PIPE	TATA spare parts
283043800110	ASSY.BRAKE TUBE	TATA spare parts
283043800111	ASSY.BRAKE TUBE	TATA spare parts
283043800112	ASSY.BRAKE TUBE	TATA spare parts
2830444	GASKET EXHAUST MANIFOLD	TATA spare parts
283047100109	ASSY. FILLER NECK TOP WITH BRACKET	TATA spare parts
283047100111	ASSY.FUEL TANK WITHOUT PUMP	TATA spare parts
283047100114	ASSY. BRACKET (FOR FUEL FILTER MTG.)	TATA spare parts



283047100117	ASSY. FUEL TANK (COMPLETE)	TATA spare parts
283047507703	RUBBER PACKING	TATA spare parts
283047600102	ASSY. BREATHER HOSE	TATA spare parts
283047600105	ASSY BREATHER PIPE (FILLER NECK TO TANK)	TATA spare parts
283047600121	ASSY.TUBE (DELIVERY LINE)	TATA spare parts
283047600122	ASSY. TUBE (FUEL PUMP TO FUEL FILTER)	TATA spare parts
283047600123	ASSY. TUBE(RESTRICTOR TO EVP LINE)	TATA spare parts
283047600124	ASSY. TUBE (DELIVERY LINE TO ENGINE)	TATA spare parts
283047600137	ASSY. FUEL LINE ON ENGINE	TATA spare parts
283047600138	ASSY. FUEL LINE ON CHASSIS	TATA spare parts
283047604201	DOUBLE CLAMP(12.5X12.5)	TATA spare parts
283047605801	HOSE (LENGTH 320 MM)(8 I.D.X3.5 THK.)	TATA spare parts
283047605802	HOSE (LENGTH 110 MM) (8 I.D.X3.5 THK.)	TATA spare parts
283047605803	HOSE (LENGTH 205 MM) (4.5 I.D.X3.5 THK.)	TATA spare parts
283047605804	HOSE (LENGTH 570 MM) (6 I.D.X3.5 THK.)	TATA spare parts
283047605805	HOSE (LENGTH 190MM) (8 I.D.X3.5 THK.)	TATA spare parts
283047608201	BRACKET (FOR FUEL LINE CLAMPING)	TATA spare parts
283047608202	BRACKET (FOR FUEL LINE CLAMPING)	TATA spare parts
283049100103	ASSY. SILENCER COMP WITH HANGER BRACKET	TATA spare parts
283049100106	ASSY. CATALYTIC CONVERTER COMPLETE	TATA spare parts
283049100107	ASSY. SILENCER COMPLETE	TATA spare parts
283049100111	ASSY BRACKET¿ (SILENCER MTG.)	TATA spare parts
283049100113	ASSY.CAT.CON WITH HEAT SHIELD	TATA spare parts
283049100115	ASSY TAIL PIPE	TATA spare parts
283049100116	ASSY TAIL PIPE	TATA spare parts
283049100117	ASSY.SILENCER	TATA spare parts
283049101601	ASSY.CAT.CON WITH HEAT SHIELD	TATA spare parts
283049200103	ASSY.EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
283049200104	ASSY.TAIL PIPE	TATA spare parts
283049200115	ASSY TAIL PIPE & POST SILENCER	TATA spare parts
283049200118	ASSY.FRONT PIPE(WITH FLEXIBLE BELOW)	TATA spare parts
283049200119	ASSY EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
283049200121	ASSY. EXHAUST PIPE(INTERMEDIATE)	TATA spare parts
283049200125	ASSY. FRONT PIPE WITH BOSS	TATA spare parts
283049200128	ASSY EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
283054100102	ASSY.BATT.CABLE +VE & -VE LHD	TATA spare parts
283054100106	ASSY +VE BATTERY CABLE 25MM SQ.	TATA spare parts
283054100107	ASSY -VE BATTERY CABLE 25MM SQ.	TATA spare parts
283054100108	ASSY.BATTERY CABLE +VE [LHD 4PL]	TATA spare parts
283054100109	ASSY.BATTERY CABLE -VE [LHD 4PL]	TATA spare parts
283054100110	ASSY BATTERY HOLDING ANGLE	TATA spare parts
283054200102	ASSY.INST.CLUSTER 1:1.21 TRIP	TATA spare parts
283054200104	ASSY.RELAY AND FUSE BOX COVER	TATA spare parts
283054209901	70 LTRS. TANK UNIT	TATA spare parts
283054209903	DIGITAL CLOCK - TELCO LINE	TATA spare parts
283054209904	ELECT.CONTROL UNIT	TATA spare parts
283054400101	ASSY. HEAD LAMP LH - LHD	TATA spare parts

283054400102	ASSY. HEAD LAMP RH - LHD	TATA spare parts
283054409901	SQ.REFLEX RELFECTOR [RED]	TATA spare parts
283054409902	LEVELLING MOTOR ASSY BS6	TATA spare parts
283054500101	STEERING COMBI SWITCH	TATA spare parts
283054501601	HAZARD WARNING SWITCH	TATA spare parts
283054509901	HAZARD WARNING SWITCH	TATA spare parts
283054509907	HAZARD WARNING SWITCH	TATA spare parts
283054509909	STEERING COMBI SWITCH RHD	TATA spare parts
283054509911	STG COMBI SWITCH LHD COLLAP	TATA spare parts
283054509912	HAZARD WARNING SWITCH	TATA spare parts
283054509914	REAR WINDOW HEAT+DEMIST	TATA spare parts
283054509915	HEAD LAMP LEV. SW. VERTICAL [FOUR FRONT]	TATA spare parts
283054509916	HEAD LAMP LEV SW. HORI. [FOUR FRONT]	TATA spare parts
283054509917	SWITCH TRANSFER CASE SELECTION 4X4 HORIZ	TATA spare parts
283054600101	WIRING HARNESS CABIN LHD EURO-II	TATA spare parts
283054600102	WIRING HARNESS CABIN RHD EURO-II	TATA spare parts
283054600109	WIRING HARNESS FRONT EURO-II	TATA spare parts
283054600110	WIRING HARNESS FRONT EURO-III	TATA spare parts
283054600111	WIRING HARNESS FRONT 4PL	TATA spare parts
283054600112	WIRING HARNESS CABIN 4PL LHD	TATA spare parts
283054600113	WIRING HARNESS ECU	TATA spare parts
283054600115	WIRING HARNESS FRONT EURO-II	TATA spare parts
283054600116	WIRING HARNESS CABIN RHD EURO-II	TATA spare parts
283054600118	WIRING HARNESS 4-PL ENGINE	TATA spare parts
283054600125	WIRING HARNESS CABIN RHD BS-III	TATA spare parts
283054600126	WIRING HARNESS TAIL + FUEL PUMP	TATA spare parts
283054600128	W/H.ENGINE BS-II W/COLD ADVANCE TIMER	TATA spare parts
283054600129	WIRING HARNESS FRONT BS-II	TATA spare parts
283054600130	WIRING HARNESS CABIN RHD BS-II	TATA spare parts
283054600131	W/H.ENGINE BS-II WITH KSB	TATA spare parts
283054600134	WIRING HARNESS MAIN BS-II	TATA spare parts
283054600136	WIRING HARNESS ECU 4PL	TATA spare parts
283054600137	WIRING HARNESS TAIL 4PL	TATA spare parts
283054600138	WIRING HARNESS ENGINE 4PL	TATA spare parts
283054600139	WIRING HARNESS FRONT 4PL	TATA spare parts
283054600140	WIRING HARNESS CABIN LHD 4PL	TATA spare parts
283054600141	WIRING HARNESS MAIN BS-II	TATA spare parts
283054600142	WIRING HARNESS MAIN BS-III	TATA spare parts
283054601606	WIRING HARNESS MAIN BS-II	TATA spare parts
283054601613	WH MAIN BS-III [ELE. CLUSTER]	TATA spare parts
283054610113	WH MAIN BS-III [ELE. CLUSTER]	TATA spare parts
283054620113	WH MAIN BS-III [ELE. CLUSTER]	TATA spare parts
283054620114	WH TAIL BS-III [ELC.SPPEDO CLUSTER]	TATA spare parts
283054900101	KIT-IMMO.+KEY LESS ENTRY SYSTEM MINDAHUF	TATA spare parts
283054900104	KIT-IMMO.+KEY LESS ENTRY SYSTEM MINDAHUF	TATA spare parts
2830559	GASKET OIL COOLER CORE	TATA spare parts
283058408204	TRANSFER LBL.TYRE PRESSURE-215/75 R15 LT	TATA spare parts

283060000102BF	ASSY BODY SHELL COMPL. PAINTED ARTIC WHI	TATA spare parts
283060000102BL	ASSY BODY SHELL COMPL. PAINTED NEP. BLUE	TATA spare parts
283060000102CN	ASSY BODY SHELL COMPL. PAINTED IRISH CRE	TATA spare parts
283070100112BF	ASSY LOAD BODY PAINTED WITHOUT FITMENTS	TATA spare parts
283070300101	ASSY.SIDE TUBULAR FRAME (LOAD BODY)	TATA spare parts
283070400102	ASSY.SHELL (TAIL GATE)	TATA spare parts
283070806301	BOLT COVER	TATA spare parts
283070906301	PACKING (LOAD BODY -CHASSIS)	TATA spare parts
283070906302	PACKING (SUPPT.BRKT.)	TATA spare parts
2831077	GASKET FILTER HEAD	TATA spare parts
283131000101	ASSY.FRAME- LP 1510/48	TATA spare parts
283255106301	DECAL TATAMOBILE TUFF PICKUP LH	TATA spare parts
283255106302	DECAL TATAMOBILE TUFF PICKUP RH	TATA spare parts
283255106304	MASCOT MOBIA	TATA spare parts
283260000101BF	ASSY BODY COMPLETE RHD ARTIC WHITE	TATA spare parts
283260000102D7	ASSY BODY SHELL COMPLETE PAINTED RHD SIL	TATA spare parts
283260000106D3	ASSY BODY COMPLETE LHD ARTIC SILVER	TATA spare parts
283260000107BF	ASSY BODY SHELL COMPLETE PAINTED ARTIC W	TATA spare parts
283260000107BG	ASSY BODY SHELL COMPLETE PAINTED MICA B_	TATA spare parts
283260000107BM	ASSY BODY SHELL COMPLETE PAINTED FIJI BL	TATA spare parts
283260000107D3	ASSY BODY SHELL COMPLETE PAINTED ARTIC S	TATA spare parts
283260000107D5	ASSY BODY SHELL COMPLETE PAINTED TIMBER	TATA spare parts
283260000107D7	ASSY BODY SHELL COMPLETE PAINTED SILVER	TATA spare parts
283260000107DP	ASSY BODY SHELL COMPLETE PAINTED PASSION	TATA spare parts
283260000111BF	ASSY BODY COMPLETE LHD ARTIC WHITE	TATA spare parts
283260000111D7	ASSY BODY COMPLETE LHD SILVER MIST	TATA spare parts
283260000111DP	ASSY BODY COMPLETE LHD PASSION RED	TATA spare parts
283260000112BF	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283260000112BM	ASSY BODY SHELL COMPLETE PAINTED LHD FIJ	TATA spare parts
283260000112D3	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283260000112D5	ASSY BODY SHELL COMPLETE PAINTED LHD TIM	TATA spare parts
283260000112D7	ASSY BODY SHELL COMPLETE PAINTED LHD SIL	TATA spare parts
283260000112DP	ASSY BODY SHELL COMPLETE PAINTED LHD PAS	TATA spare parts
283260000115BF	ASSY BODY COMPLETE LHD ARTIC WHITE 4X4	TATA spare parts
283260000115BM	ASSY BODY COMPLETE LHD FIJI BLUE 4X4 AC	TATA spare parts
283260000115D3	ASSY BODY COMPLETE LHD ARTIC SILVER 4X4	TATA spare parts
283260000115D5	ASSY BODY COMPLETE LHD TIMBER GREEN 4X4	TATA spare parts
283260000115DP	ASSY BODY COMPLETE LHD PASSION RED 4X4	TATA spare parts
283260000116BF	ASSY BODY COMPLETE RHD ARTIC WHITE	TATA spare parts
283260000117BF	ASSY BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283260000117BG	ASSY BODY SHELL COMPLETE PAINTED RHD MIC	TATA spare parts
283260000117BM	ASSY BODY SHELL COMPLETE PAINTED RHD FIJ	TATA spare parts
283260000117D3	ASSY BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283260000117D5	ASSY BODY SHELL COMPLETE PAINTED RHD TIM	TATA spare parts
283260000117D7	ASSY BODY SHELL COMPLETE PAINTED RHD SIL	TATA spare parts
283260000117DP	ASSY BODY SHELL COMPLETE PAINTED RHD PAS	TATA spare parts
283260000120D3	ASSY.BODY COMPLETE RHD ARTICT SILVER	TATA spare parts

283260000120DU	ASSY.BODY COMPLETE RHD QUARTZ BLACK	TATA spare parts
283260000121BF	ASSY BODY COMPLETE RHD ARTIC WHITE	TATA spare parts
283260000121BG	ASSY BODY COMPLETE RHD MICA B_RED	TATA spare parts
283260000121BM	ASSY BODY COMPLETE RHD FIJI BLUE	TATA spare parts
283260000121BN	ASSY BODY COMPLETE RHD RUBY RED	TATA spare parts
283260000121D3	ASSY BODY COMPLETE RHD ARTIC SILVER	TATA spare parts
283260000121D5	ASSY BODY COMPLETE RHD TIMBER GREEN	TATA spare parts
283260000121D7	ASSY BODY COMPLETE RHD SILVER MIST	TATA spare parts
283260000122BF	ASSY BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283260000122BG	ASSY BODY SHELL COMPLETE PAINTED RHD MIC	TATA spare parts
283260000122BM	ASSY BODY SHELL COMPLETE PAINTED RHD FIJ	TATA spare parts
283260000122BN	ASSY BODY SHELL COMPLETE PAINTED RHD RUB	TATA spare parts
283260000122D3	ASSY BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283260000122D5	ASSY BODY SHELL COMPLETE PAINTED RHD TIM	TATA spare parts
283260000122D7	ASSY BODY SHELL COMPLETE PAINTED RHD SIL	TATA spare parts
283260000122DP	ASSY BODY SHELL COMPLETE PAINTED RHD PAS	TATA spare parts
283260000126BF	ASSY BODY COMPLETE LHD ARTIC WHITE	TATA spare parts
283260000126BM	ASSY BODY COMPLETE LHD FIJI BLUE	TATA spare parts
283260000126BN	ASSY BODY COMPLETE LHD RUBY RED	TATA spare parts
283260000126BP	ASSY BODY COMPLETE LHD METALLIC SILVER	TATA spare parts
283260000126D3	ASSY BODY COMPLETE LHD ARTIC SILVER	TATA spare parts
283260000126D5	ASSY BODY COMPLETE LHD TIMBER GREEN	TATA spare parts
283260000126D7	ASSY BODY COMPLETE LHD SILVER MIST	TATA spare parts
283260000127BF	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283260000127BM	ASSY BODY SHELL COMPLETE PAINTED LHD FIJ	TATA spare parts
283260000127BN	ASSY BODY SHELL COMPLETE PAINTED LHD RUB	TATA spare parts
283260000127BP	ASSY BODY SHELL COMPLETE PAINTED LHD MET	TATA spare parts
283260000127D3	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283260000127D5	ASSY BODY SHELL COMPLETE PAINTED LHD TIM	TATA spare parts
283260000127D7	ASSY BODY SHELL COMPLETE PAINTED LHD SIL	TATA spare parts
283260000127DP	ASSY BODY SHELL COMPLETE PAINTED LHD PAS	TATA spare parts
283260000132BF	ASSY BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283260000132BG	ASSY BODY SHELL COMPLETE PAINTED RHD MIC	TATA spare parts
283260000132BM	ASSY BODY SHELL COMPLETE PAINTED RHD FIJ	TATA spare parts
283260000132BN	ASSY BODY SHELL COMPLETE PAINTED RHD RUB	TATA spare parts
283260000132D3	ASSY BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283260000132D5	ASSY BODY SHELL COMPLETE PAINTED RHD TIM	TATA spare parts
283260000132D7	ASSY BODY SHELL COMPLETE PAINTED RHD SIL	TATA spare parts
283260000132DP	ASSY BODY SHELL COMPLETE PAINTED RHD PAS	TATA spare parts
283260000135BF	ASSY.BODY COMPLETE LHD ARTIC WHITE	TATA spare parts
283260000135BM	ASSY.BODY COMPLETE LHD FIJI BLUE	TATA spare parts
283260000135BN	ASSY.BODY COMPLETE LHD RUBY RED	TATA spare parts
283260000135BP	ASSY.BODY COMPLETE LHD METALLIC SILVER	TATA spare parts
283260000135D3	ASSY.BODY COMPLETE LHD ARTIC SILVER	TATA spare parts
283260000135D5	ASSY.BODY COMPLETE LHD TIMBER GREEN	TATA spare parts
283260000135D7	ASSY.BODY COMPLETE LHD SILVER MIST	TATA spare parts
283260000135DP	ASSY.BODY COMPLETE LHD PASSION RED	TATA spare parts

283260000136BF	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283260000136BM	ASSY BODY SHELL COMPLETE PAINTED LHD FIJ	TATA spare parts
283260000136BN	ASSY BODY SHELL COMPLETE PAINTED LHD RUB	TATA spare parts
283260000136D3	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283260000136D5	ASSY BODY SHELL COMPLETE PAINTED LHD TIM	TATA spare parts
283260000136D7	ASSY BODY SHELL COMPLETE PAINTED LHD SIL	TATA spare parts
283260000136DP	ASSY BODY SHELL COMPLETE PAINTED LHD PAS	TATA spare parts
283260000146BF	ASSY BODY COMPLETE RHD ARTIC WHITE	TATA spare parts
283260000146BG	ASSY BODY COMPLETE RHD MICA B_RED	TATA spare parts
283260000146BM	ASSY BODY COMPLETE RHD FIJI BLUE	TATA spare parts
283260000146D3	ASSY BODY COMPLETE RHD ARTIC WHITE	TATA spare parts
283260000146D5	ASSY BODY COMPLETE RHD TIMBER GREEN	TATA spare parts
283260000146D7	ASSY BODY COMPLETE RHD SILVER MIST	TATA spare parts
283260000147BF	ASSY BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283260000147BG	ASSY BODY SHELL COMPLETE PAINTED RHD MIC	TATA spare parts
283260000147BM	ASSY BODY SHELL COMPLETE PAINTED RHD FIJ	TATA spare parts
283260000147D3	ASSY BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283260000147D5	ASSY BODY SHELL COMPLETE PAINTED RHD TIM	TATA spare parts
283260000147D7	ASSY BODY SHELL COMPLETE PAINTED RHD SIL	TATA spare parts
283260000164BF	TM LHD 4X2 TC BU AC+HD FACE LIFT ARTIC_W	TATA spare parts
283260000164BG	TM LHD 4X2 TC BU AC+HD FACE LI BURNING_R	TATA spare parts
283260000164BM	TM LHD 4X2 TC BU AC+HD FACE LIFT FIJI_BL	TATA spare parts
283260000164D5	TM LHD 4X2 TC BU AC+HD FACE L TIMBER_GRE	TATA spare parts
283260000164D7	TM LHD 4X2 TC BU AC+HD FACE L SILVER_MIS	TATA spare parts
283260000164DP	ASSY.CAB COMPLETE LHD PASSION RED	TATA spare parts
283260000171D3	ASSY BODY COMPLETE UK 4X4 ARTIC SILVER	TATA spare parts
283260000171DP	ASSY BODY COMPLETE UK 4X4 PASSION RED	TATA spare parts
283260000179BF	ASSY BODY COMPL. 207DI EX ARCTIC_WHITE	TATA spare parts
283260000179BL	ASSY BODY COMPLETE RHD 207DI EX D.NEPTUN	TATA spare parts
283260000179BN	ASSY BODY COMPL. 207DI EX RUBY_RED	TATA spare parts
283260000179BS	ASSY BODY COMPL. RHD 207DI EX SOLID_GREE	TATA spare parts
283260000179CN	ASSY BODY COMPL. RHD 207DI EX IRISH CREA	TATA spare parts
283260000183BF	ASSY.BODY SHELL PAINTED LHD ARC WHITE	TATA spare parts
283260000183CN	ASSY.BODY SHELL PAINTED LHD IRISH CREAM	TATA spare parts
283260000184BF	ASSY BODY COMPL 207DI EGYPT LHD ARC WHIT	TATA spare parts
283260000184CN	ASSY BODY COMPL 207DI EGYPT LHD IRISH CR	TATA spare parts
283260000188BF	ASSY BODY SHELL PNTD 207DI EX ARCTIC WHI	TATA spare parts
283260000188BL	ASSY.BODY SHELL COMPLT.PAINTED RHD D.NEP	TATA spare parts
283260000188BN	ASSY BODY SHELL PNTD 207DI EX RUBY RED	TATA spare parts
283260000188BS	ASSY BODY SHELL PNTD 207DI EX SOLID GREE	TATA spare parts
283260000188CN	ASSY BODY SHELL PNTD 207DI EX IRISH CREA	TATA spare parts
283260000192BF	ASSY.BODY SHELL COMPLT.PAINTED RHD	TATA spare parts
28326000Z183BF	ASSYBODYSHELLCOMP.PAINTEDLHD-ARTICWHITE	TATA spare parts
28326000Z183CN	ASSYBODYSHELLCOMP.PAINTEDLHD-IRISHCREAM	TATA spare parts
28326000Z184BF	ASSYBODYCOMPLETELHD-ARTICWHITE	TATA spare parts
28326000Z184CN	ASSY BODY COMPLETE LHD - IRISH CREAM	TATA spare parts
28326000Z199BF	ASSY.BODY COMPLETE LHD 4X2 (2.2 BUKET HD	TATA spare parts

28326000Z199BM	ASSY.BODY COMPLETE LHD 4X2 (2.2 BUKET HD	TATA spare parts
28326000Z199D3	ASSY.BODY COMPLETE LHD 4X2 (2.2 BUKET HD	TATA spare parts
28326000Z199D5	ASSY.BODY COMPLETE LHD 4X2 (2.2 BUKET HD	TATA spare parts
283260010110BF	ASSY.BODY COMPLETE RHD(DI RIGID FR.AXLE)	TATA spare parts
283260010111BF	ASSY.BODY SHELL COMP.PAINTED RHD(DI RFA	TATA spare parts
283260010111BL	ASSY BODY SHELL PAINTED. DK_NEPT_BLUE	TATA spare parts
283260010111FG	ASSY BODY SHELL PAINTED (RFA) MINERAL RE	TATA spare parts
283260010111GZ	ASSY.BODY SHELL COMP.PAINTED RHD(DI RFA)	TATA spare parts
283260010137BF	ASSY.BODY.COMPLT.RHD	TATA spare parts
283260010139BF	BODY COMPLT.ASSY.RHD	TATA spare parts
283260010142	BODY SHELL COMPLT.ASSY.RHD (4SPTC BS IV)	TATA spare parts
283260010143BF	BODY SHELL COMPLT.ASSY.PAINTED RHD (4SPT	TATA spare parts
283260010143BL	BODY SHELL COMPLT.ASSY.PAINTED RHD (4SPT	TATA spare parts
283260010150BF	BODY COMPLETE ASSY.RHD	TATA spare parts
283260010158BF	BODYSHELLCOMPLT.ASSYRHD	TATA spare parts
283260010171BF	BODY SHELL ASSY COMPL ARCTIC WHITE PAINT	TATA spare parts
28326001Z101BF	ASSY.BODY SHELL COMP.PAINTED LHD 4X2 ART	TATA spare parts
28326001Z101BM	ASSY.BODY SHELL COMP.PAINTED LHD 4X2 FIJ	TATA spare parts
28326001Z101D3	ASSY.BODY SHELL COMP.PAINTED LHD 4X2 ART	TATA spare parts
28326001Z101D5	ASSY.BODY SHELL COMP.PAINTED LHD 4X2 TIM	TATA spare parts
28326001Z120BF	ASSY. BODY COMP WITH FITMENTS ARCTIC WHI	TATA spare parts
28326001Z121BF	ASSY. BODY SHELL PAINTED ARCTIC WHITE	TATA spare parts
283260100106	ASSY TIE MEMBER COMPLT(NEW GRILL)	TATA spare parts
283260100109	TIE-MEMBER COMPLETE ASSY.(4SP)	TATA spare parts
283260100121	TIE-MEMBER COMPLETE ASSY	TATA spare parts
283260100122	ASSY.ENGINE HOUSE(4SPTC)	TATA spare parts
283260100124	BATTERY TRAY ASSY.	TATA spare parts
283260100125	ASSY.ENGINE HOUSE	TATA spare parts
28326010Z108	ASSY.TIE-MEMBER COMPL.WITH FRONT PANEL (	TATA spare parts
28326060010320	ASSY PANEL INR SIDE BONNET WITH WELD NUT	TATA spare parts
283260600106	ASSY. MUDGURAD FRONT LH	TATA spare parts
283260600109	ASSY.MUD-GUARD COMPLETE RH	TATA spare parts
283260608202	REINF.LH BONNET SIDE PANEL INNER	TATA spare parts
283260608203	REINF RH BONNET SIDE PANEL INNER	TATA spare parts
283261000115	SUB-STRUCTURE WITH FLOOR ASSY.COMPLT RHD	TATA spare parts
283262500101	PANEL W/S ASSY OUTER BOTTOM RHD	TATA spare parts
283262600104	ASSY FIRE WALL COMPLT.	TATA spare parts
283262608204	PANEL FIREWALL RHD(W/O.ACHD BLOWER)	TATA spare parts
283263600103	ASSY.W/S SIDE & TOP RAIL SIDE LH	TATA spare parts
283263600104	ASSY.W/S SIDE & TOP RAIL SIDE RH	TATA spare parts
283268800101	ASSY MOULDED CARPET KIT LHD	TATA spare parts
283268800102	ASSY MOULDED CARPET KIT RHD	TATA spare parts
283268800105	ASSY.MOULDED CARPET KIT LHD 4X4	TATA spare parts
283268800107	ASSY.MOULDED CARPET KIT RHD 4X4	TATA spare parts
283268800121	ASSY.KIT FLOOR MAT RHD(RIGID FRONT AXLE)	TATA spare parts
283268800126	KIT FLOOR MAT ASSY.(BUCKET)RHD R/AXLE	TATA spare parts
283268800128	ASSY.KIT FLOOR MAT (RHD)	TATA spare parts

283268806301	NOISE INSULATION F/W CAB SIDE LHD	TATA spare parts
283268806307	NOISE INSULATION FIREWALL LHD (E/HOUSE)	TATA spare parts
283268806314	NOISE INSULATION (FLOOR TUNNEL)	TATA spare parts
283268900105	ASSY.NACELLE	TATA spare parts
283268906301	BASE PLATE (G.S.LEVER)	TATA spare parts
283268906302	NACELLE FRONT	TATA spare parts
283268906303	NACELLE REAR	TATA spare parts
283268906307	DASH BOARD (DARK GRAY) 207DI EX	TATA spare parts
283268906308	MINI CONSOLE LHD(BLOWER 4X4T)	TATA spare parts
283268906319	COVER (D/B VENT.CUT OUT)	TATA spare parts
283268906320	COVER (VENT CONTROL CUTOUT)	TATA spare parts
283268906321	COVER(RADIO)	TATA spare parts
283268906322	COVER(AUTO WINDING SWITCH)	TATA spare parts
283268906323	COVER(HAZARD WARNING SWITCH)	TATA spare parts
283269206301	APILLAR TRIM LH	TATA spare parts
283269206302	APILLAR TRIM RH	TATA spare parts
283269206304	TRIM PANEL INNER CORNER R/W LH	TATA spare parts
283269206305	TRIM PANEL INNER CORNER R/W RH	TATA spare parts
283269206306	TRIM FOR PANEL INNER BOTTOM(R/W)	TATA spare parts
283269506303	ASSY.REAR WALL PADDING(GRAY)	TATA spare parts
283270000107BF	ASSY.L/BODY (3150 WB FLAT BED) PAINTED A	TATA spare parts
283270000107CN	ASSY.L/BODY (3150 WB FLAT BED) PAINTED I	TATA spare parts
283270000108BF	ASSY L/BODY (3150 WB FLAT BED) ARC. WHIT	TATA spare parts
283270000108CN	ASSY L/BODY (3150 WB FLAT BED) IRISH CRE	TATA spare parts
283270000109	ASSY L/B S/W 31WB 3S/DROP F/BED	TATA spare parts
283270000110BF	ASSY.LOAD BODY PAINTED ARCTIC WHITE	TATA spare parts
283270000110CN	ASSY.LOAD BODY PAINTED IRISH CREAM	TATA spare parts
283270000118	ASSY FUEL FLAP ( WITHOUT LOCK & KEY )	TATA spare parts
283270006301	FENDER EXTN.(L/B)-GRAY	TATA spare parts
283270200101	ASSY FRONT PANEL 207DI FLAT L/BODY	TATA spare parts
283270300101	ASSY.LOAD GUARD COMPLT.(TUBULAR)	TATA spare parts
283270300103	ASSY SIDE PANEL LH 207DI FLAT L/BODY	TATA spare parts
283270300104	ASSY SIDE PANEL RH 207DI FLAT L/BODY	TATA spare parts
283270400102	KIT LOOSE ITEMS FIT ON L/BODY	TATA spare parts
283270400103	ASSY TAIL GATE 207DI FLAT L/BODY	TATA spare parts
283272200109	ASSY DOOR SHELL LH(W/O SIDE INTR)	TATA spare parts
283272200110	ASSY DOOR SHELL RH(W/O SIDE INTR)	TATA spare parts
28327220Z109	ASSY. DOOR SHELL LH	TATA spare parts
28327220Z110	ASSY. DOOR SHELL RH	TATA spare parts
283272300101	ASSY.LINK POP-UP KNOB LH	TATA spare parts
283272300102	ASSY.LINK POP-UP KNOB RH	TATA spare parts
283272300103	ASSY.LINK	TATA spare parts
283272300104	ASSY DOOR LOCK SET W/STG LOCK/SENSOR	TATA spare parts
283272300105	ASSY.HANDLE WINDOW WINDING (BLACK)	TATA spare parts
283272500103	ASSY.WEATHER STRIP OUTER-FRONT LH	TATA spare parts
283272500104	ASSY.WEATHER STRIP OUTER-FRONT RH	TATA spare parts
283272500105	ASSY.WEATHER STRIP INNER-FRONT	TATA spare parts

283272700107	ASSY.PADDING DOOR COMPLT.LH	TATA spare parts
283272700108	ASSY.PADDING DOOR COMPLT.RH	TATA spare parts
283272700111	ASSY.PADDING DOOR LH	TATA spare parts
283272700112	ASSY.PADDING DOOR RH	TATA spare parts
283272700115	PADDING DOOR ASSY.LH	TATA spare parts
283272706301	MAGAZINE POCKET FRONT DOOR LH (BLACK)	TATA spare parts
283272706302	MAGAZINE POCKET FRONT DOOR RH (BLACK)	TATA spare parts
283281100104	ASSY.EXTERNAL RVM RH RHD (PLAIN)	TATA spare parts
283281100105	ASSY.EXTERNAL RVM LH RHD (SPHERICAL)	TATA spare parts
283281100106	ASSY.EXTERNAL RVM LH LHD (PLAIN)	TATA spare parts
283281100107	ASSY.EXTERNAL RVM RH LHD (SPHERICAL)	TATA spare parts
283281100110	ASSY.EXTERNAL RVM LH RHD (SPHERICAL)	TATA spare parts
283281100114	ASSY.CAP(SEAT BELT ELR CAVITY)	TATA spare parts
283281100119	DECAL SET 207 DI RIGID FRONT AXLE T/M	TATA spare parts
283281100137	ASSY.KIT DECAL 207DI EX T/M MECH.STG.	TATA spare parts
283281100138	ASSY.KIT DECAL 207DI EX T/M POWER STG.	TATA spare parts
283281100143	ASSY.COVER INNER LH GRAY (G001)	TATA spare parts
283281100144	ASSY.COVER INNER RH GRAY (G001)	TATA spare parts
283281100161	KIT DECAL 207DI EX T/M (M/STG) FIG NO CO	TATA spare parts
283281100172	SIDE STEP ASSY.	TATA spare parts
283281100176	DECAL SET 207 DI RIGID FRONT AXLE T/M	TATA spare parts
283281106315	FOOT STEP STRIP	TATA spare parts
283281106320	ROOF CAP LH (REAR)	TATA spare parts
283281106321	ROOF CAP RH (REAR)	TATA spare parts
283281106337	LINER INNER FRT.W/A LH RHD (DI 4SPTC EX)	TATA spare parts
283281106338	LINER INNER FRT.W/A RH RHD (DI 4SPTC EX)	TATA spare parts
283281106344	MUDFLAP FRONT LH	TATA spare parts
283281106345	MUDFLAP FRONT RH	TATA spare parts
283281108201	REAR BOTTOM BRACKET LH(FRT.FENDER EXT.)	TATA spare parts
283281108203	REAR BOTTOM BRACKET RH(FRONT FENDER EXT)	TATA spare parts
283281108601	SPACER(ORVM)	TATA spare parts
283281800104	RX-PICKUP DECAL ASSY (FOR L/BODY)	TATA spare parts
283281800105	RX-PICKUP DECAL ASSY.(FOR CAB)	TATA spare parts
283283100129	KIT FOR AC+HTR-LHD (2.2LTR ENG) CONSISTS	TATA spare parts
283283100130	ASSY.CONDENSER COMPLETE	TATA spare parts
283283106302	ASSY.COIL HSG CUM DUCT-LHD	TATA spare parts
283283505802	RUBBER HOSE (UPR COOL.LINE TO WATER VAL)	TATA spare parts
283288100109	BONNET SIDE ASSY.LH	TATA spare parts
28328810010935	CED BONNET SIDE ASSY.LH	TATA spare parts
283288100110	BONNET SIDE ASSY.RH	TATA spare parts
28328810011035	CED BONNET SIDE ASSY.RH	TATA spare parts
283288500102BF	ASSY. BUMPER FRONT ARTICE WHITE BS1- 4	TATA spare parts
283288500102BJ	BUMPER ANTHRAS_GREY-FRONT COMPLT.	TATA spare parts
283288500102BL	ASSY.BUMPER FR COMPL. (16 TYRE) D. NE	TATA spare parts
283288500102BS	ASSY.BUMPER FR COMPL. (16 TYRE) S GRE	TATA spare parts
283288500102CN	ASSY.BUMPER FR COMPL. (16 TYRE) IRISH	TATA spare parts
283288700101	ASSY. STAY ROD	TATA spare parts



283288703401	NORGLIDE BEARING	TATA spare parts
283288706301	END CAP STAY ROD	TATA spare parts
283288706302	CENTER BONNET INSULATION	TATA spare parts
283288706303	REINFORCEMENT PAD	TATA spare parts
283288800102	ASSY CHROME STRIP	TATA spare parts
283288800104	GRILL ASSY	TATA spare parts
283289100102	ASSY.KIT FOR RUBBER MTG.	TATA spare parts
283291000102	ASSY.DRIVER SEAT(ADJUST)-207 D1 EX	TATA spare parts
283291000103	ASSY.CO-DRIV SEAT (FIXED)-207DI EX	TATA spare parts
283291000105	ASSY.COMPT.DRIV.SEAT 207DI-EX RHD	TATA spare parts
283291000106	ASSY.COMPT.CO-DRIV.BENCH SEAT 207DI-EX	TATA spare parts
283291000108	ASSY.COMP.DRIVER SEAT (207DI) LHD	TATA spare parts
283291000115	ASSY.DRIVER SEAT(ADJ.)W/MTG.BKT.RHD	TATA spare parts
283291000116	ASSY.CO-DRIV.SEAT W/MTG.BKT.RHD-	TATA spare parts
283291000118	ASSY.DRIV.SEAT(ADJ.)W/MTG.BKT.LHD	TATA spare parts
283291000122	ASSY.COMP.DRIVER SEAT 207DI LHD	TATA spare parts
283291000123	ASSY.COMP.CO-DRIVER BENCH SEAT 207DI LHD	TATA spare parts
283291500106	ASSY.SEAT BELT KIT STATIC W/O SW.(207DI)	TATA spare parts
283291500108	ASSY.SEAT BELT KIT PASSIVE(BUCKET)	TATA spare parts
283299506301	XMAS TREE CLIP	TATA spare parts
283360000101BF	ASSY BODY COMPLETE LHD ARTIC WHITE	TATA spare parts
283360000101BG	ASSY BODY COMPLETE LHD BURNING RED	TATA spare parts
283360000101BM	ASSY BODY COMPLETE LHD FIJI BLUE	TATA spare parts
283360000101BP	ASSY BODY COMPLETE LHD METALLIC SILVER	TATA spare parts
283360000101D3	ASSY BODY COMPLETE LHD ARTIC SILVER	TATA spare parts
283360000101D5	ASSY BODY COMPLETE LHD TIMBER GREEN	TATA spare parts
283360000101D7	ASSY BODY COMPLETE LHD SILVER MIST	TATA spare parts
283360000102BF	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283360000102BG	ASSY BODY SHELL COMPLETE PAINTED LHD MIC	TATA spare parts
283360000102BM	ASSY BODY SHELL COMPLETE PAINTED LHD FIJ	TATA spare parts
283360000102BP	ASSY BODY SHELL COMPLETE PAINTED LHD MET	TATA spare parts
283360000102D3	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283360000102D5	ASSY BODY SHELL COMPLETE PAINTED LHD TIM	TATA spare parts
283360000102D7	ASSY BODY SHELL COMPLETE PAINTED LHD SIL	TATA spare parts
283360000111D5	ASSY BODY COMPLETE LHD TIMBER_GREEN	TATA spare parts
283360000112BM	ASSY BODY SHELL COMPLETE PAINTED LHD FIJ	TATA spare parts
283360000112D5	ASSY BODY SHELL COMPLETE PAINTED LHD	TATA spare parts
283360000114BF	ASSY.CAB COMPLETE LHD ARTIC WHITE	TATA spare parts
283360000114BG	ASSY.CAB COMPLETE LHD BURNING RED	TATA spare parts
283360000114BM	ASSY.CAB COMPLETE LHD FIJI BLUE	TATA spare parts
283360000114BN	ASSY.CAB COMPLETE LHD RUBY RED	TATA spare parts
283360000114D3	ASSY.CAB COMPLETE LHD ARTIC SILVER	TATA spare parts
283360000114D5	ASSY.CAB COMPLETE LHD TIMBER GREEN	TATA spare parts
283360000114D7	ASSY.CAB COMPLETE LHD SILVER MIST	TATA spare parts
283360000114DP	ASSY.CAB COMPLETE LHD PASSION RED	TATA spare parts
283360000116BF	ASSY BODY COMPLETE RHD ARTIC WHITE	TATA spare parts
283360000116BM	ASSY BODY COMPLETE RHD FIJI BLUE	TATA spare parts

283360000117BF	ASSY BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283360000131BF	ASSY BODY COMPLETE LHD ARTIC WHITE	TATA spare parts
283360000131BM	ASSY BODY COMPLETE LHD FIJI BLUE	TATA spare parts
283360000131D3	ASSY BODY COMPLETE LHD ARTIC SILVER	TATA spare parts
283360000131D5	ASSY BODY COMPLETE LHD TIMBER GREEN	TATA spare parts
283360000131D7	ASSY BODY COMPLETE LHD SILVER MIST	TATA spare parts
283360000131DP	ASSY BODY COMPLETE LHD PASSION RED	TATA spare parts
283360000132BF	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283360000132BM	ASSY BODY SHELL COMPLETE PAINTED LHD FIJ	TATA spare parts
283360000132D3	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283360000132D5	ASSY BODY SHELL COMPLETE PAINTED LHD TIM	TATA spare parts
283360000132D7	ASSY BODY SHELL COMPLETE PAINTED LHD SIL	TATA spare parts
283360000132DP	ASSY BODY SHELL COMPLETE PAINTED LHD PAS	TATA spare parts
283360000135BF	ASSY.BODY SHELL COMPLT.PAINTED RHD	TATA spare parts
283360000135D3	ASSY.BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283360000135DU	ASSY.BODY SHELL COMPLETE PAINTED RHD QUA	TATA spare parts
283360000136BF	ASSY BODY COMPLETE RHD ARTIC WHITE	TATA spare parts
283360000136BG	ASSY BODY COMPLETE RHD BURNING RED	TATA spare parts
283360000136BM	ASSY BODY COMPLETE RHD FIJI BLUE	TATA spare parts
283360000136BN	ASSY BODY COMPLETE RHD RUBY RED	TATA spare parts
283360000136D3	ASSY BODY COMPLETE RHD ARTIC SILVER	TATA spare parts
283360000136D5	ASSY BODY COMPLETE RHD TIMBER GREEN	TATA spare parts
283360000136D7	ASSY BODY COMPLETE RHD SILVER MIST	TATA spare parts
283360000136DP	ASSY BODY COMPLETE RHD PASSION RED	TATA spare parts
283360000137BF	ASSY BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283360000137BG	ASSY BODY SHELL COMPLETE PAINTED RHD MIC	TATA spare parts
283360000137BM	ASSY BODY SHELL COMPLETE PAINTED RHD FIJ	TATA spare parts
283360000137BN	ASSY BODY SHELL COMPLETE PAINTED RHD RUB	TATA spare parts
283360000137D3	ASSY BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283360000137D5	ASSY BODY SHELL COMPLETE PAINTED RHD TIM	TATA spare parts
283360000137D7	ASSY BODY SHELL COMPLETE PAINTED RHD SIL	TATA spare parts
283360000137DP	ASSY BODY SHELL COMPLETE PAINTED RHD PAS	TATA spare parts
283360000139D3	ASSY.BODY COMPLETE RHD ARTIC SILVER	TATA spare parts
283360000139DU	ASSY.BODY COMPLETE RHD QUARTZ BLACK	TATA spare parts
283360000139ZZ	ASSY.BODY COMPLT.RHD	TATA spare parts
283360000149BF	ASSY BODY COMPLETE LHD ARTIC WHITE	TATA spare parts
283360000149BG	ASSY BODY COMPLETE LHD BURNING RED	TATA spare parts
283360000149BM	ASSY BODY COMPLETE LHD FIJI BLUE	TATA spare parts
283360000149BP	ASSY BODY COMPLETE LHD METALLIC SILVER	TATA spare parts
283360000149D3	ASSY BODY COMPLETE LHD ARTIC SILVER	TATA spare parts
283360000149D5	ASSY BODY COMPLETE LHD TIMBER GREEN	TATA spare parts
283360000149D7	ASSY BODY COMPLETE LHD SILVER MIST	TATA spare parts
283360000149DP	ASSY BODY COMPLETE LHD PASSION RED	TATA spare parts
283360000149DU	ASSY BODY COMPLETE LHD QUARTZ BLACK	TATA spare parts
283360000150BF	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283360000150BG	ASSY BODY SHELL COMPLETE PAINTED LHD MIC	TATA spare parts
283360000150BM	ASSY BODY SHELL COMPLETE PAINTED LHD FIJ	TATA spare parts

283360000150BP	ASSY BODY SHELL COMPLETE PAINTED LHD MET	TATA spare parts
283360000150D3	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283360000150D5	ASSY BODY SHELL COMPLETE PAINTED LHD TIM	TATA spare parts
283360000150D7	ASSY BODY SHELL COMPLETE PAINTED LHD SIL	TATA spare parts
283360000150DP	ASSY BODY SHELL COMPLETE PAINTED LHD PAS	TATA spare parts
283360000150DU	ASSY BODY SHELL COMPLETE PAINTED LHD QUA	TATA spare parts
283360000153BF	CC RHD 4X4 TC AC+HD FACE LIFT ARTIC WHIT	TATA spare parts
283360000153BG	CC RHD 4X4 TC AC+HD FACE LIFT BURNING RE	TATA spare parts
283360000153BM	CC RHD 4X4 TC AC+HD FACE LIFT FIJI BLUE	TATA spare parts
283360000153BN	ASSY BODY COMPLETE RHD RUBY RED	TATA spare parts
283360000153D3	ASSY BODY COMPLETE RHD ARTIC SILVER	TATA spare parts
283360000153D5	CC RHD 4X4 TC AC+HD FACE LIFT TIMBER GRE	TATA spare parts
283360000153D7	CC RHD 4X4 TC AC+HD FACE LIFT SILVER MIS	TATA spare parts
283360000153DP	ASSY BODY COMPLETE RHD PASSION RED	TATA spare parts
283360000154BF	ASSY BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283360000154BG	ASSY BODY SHELL COMPLETE PAINTED RHD MIC	TATA spare parts
283360000154BM	ASSY BODY SHELL COMPLETE PAINTED RHD FIJ	TATA spare parts
283360000154BN	ASSY BODY SHELL COMPLETE PAINTED RHD RUB	TATA spare parts
283360000154D3	ASSY BODY SHELL COMPLETE PAINTED RHD ART	TATA spare parts
283360000154D5	ASSY BODY SHELL COMPLETE PAINTED RHD TIM	TATA spare parts
283360000154D7	ASSY BODY SHELL COMPLETE PAINTED RHD SIL	TATA spare parts
283360000154DP	ASSY BODY SHELL COMPLETE PAINTED RHD PAS	TATA spare parts
283360000154DU	ASSY BODY SHELL COMPLETE PAINTED RHD	TATA spare parts
283360000181BF	ASSY BODY COMPLETE LHD ARTIC WHITE	TATA spare parts
283360000181BG	ASSY BODY COMPLETE LHD BURNING RED	TATA spare parts
283360000181BM	ASSY BODY COMPLETE LHD FIJI BLUE	TATA spare parts
283360000181BN	ASSY BODY COMPLETE LHD RUBY RED	TATA spare parts
283360000181D3	ASSY BODY COMPLETE LHD ARTIC SILVER	TATA spare parts
283360000181D5	ASSY BODY COMPLETE LHD TIMBER GREEN	TATA spare parts
283360000181D7	ASSY BODY COMPLETE LHD SILVER MIST	TATA spare parts
283360000181DP	ASSY BODY COMPLETE LHD PASSION RED	TATA spare parts
283360000181DU	ASSY BODY COMPLETE LHD QUARTZ BLACK	TATA spare parts
283360000182BF	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283360000182BG	ASSY BODY SHELL COMPLETE PAINTED LHD MIC	TATA spare parts
283360000182BM	ASSY BODY SHELL COMPLETE PAINTED LHD FIJ	TATA spare parts
283360000182BN	ASSY BODY SHELL COMPLETE PAINTED LHD RUB	TATA spare parts
283360000182D3	ASSY BODY SHELL COMPLETE PAINTED LHD ART	TATA spare parts
283360000182D5	ASSY BODY SHELL COMPLETE PAINTED LHD TIM	TATA spare parts
283360000182D7	ASSY BODY SHELL COMPLETE PAINTED LHD SIL	TATA spare parts
283360000182DP	ASSY BODY SHELL COMPLETE PAINTED LHD PAS	TATA spare parts
283360000182DU	ASSY BODY SHELL COMPLETE PAINTED LHD QUA	TATA spare parts
283360000184BF	ASSY BODY COMPLETE RHD ARTIC WHITE	TATA spare parts
283360000184BG	ASSY BODY COMPLETE RHD BURNING RED	TATA spare parts
283360000184BM	ASSY BODY COMPLETE RHD FIJI BLUE	TATA spare parts
283360000184D3	ASSY BODY COMPLETE RHD ARTIC SILVER	TATA spare parts
283360000184D5	ASSY BODY COMPLETE RHD TIMBER GREEN	TATA spare parts
283360000184D7	ASSY BODY COMPLETE RHD SILVER MIST	TATA spare parts

28336000184DP	ASSY BODY COMPLETE RHD PASSION RED	TATA spare parts
28336000Z140BF	ASSY.BODY COMPLETE LHD 4X2 (2.2 BUKET AC	TATA spare parts
28336000Z140BM	ASSY.BODY COMP.LHD(2.2DICOR ACHD BUK EEC	TATA spare parts
28336000Z140D3	ASSY.BODY COMPLETE LHD 4X2 (2.2 BUKET AC	TATA spare parts
28336000Z140D5	ASSY.BODY COMPLETE LHD 4X2 (2.2 BUKET AC	TATA spare parts
28336000Z152BF	ASSY.BODY SHELL COMP.PAINTED LHD 4X2 ART	TATA spare parts
28336000Z152BM	ASSY.BODY SHELL COMP.PAINTED LHD(2.2 BUK	TATA spare parts
28336000Z152D3	ASSY.BODY SHELL COMP.PAINTED LHD 4X2 ART	TATA spare parts
28336000Z152D5	ASSY.BODY SHELL COMP.PAINTED LHD 4X2 TIM	TATA spare parts
28336000Z181BF	ASSY.BODY COMPLETE LHD	TATA spare parts
28336000Z184BF	ASSY BODY COMPLETE RHD ARTIC WHITE	TATA spare parts
28336000Z185BM	ASSY.BODY SHELL COMPLETE PAINTED RHD 4X2	TATA spare parts
283360010119BF	ASSY BODY COMPLETE 207DI EX CC ARTIC WHI	TATA spare parts
283360010119BL	ASSY BODY COMPLETE 207DI EX CC NEP. BLUE	TATA spare parts
283360010119CN	ASSY BODY COMPLETE 207DI EX CC IRISH CRE	TATA spare parts
283360010121D3	ASSY.BODY SHELL PAINTED ARCTIC_SILVR	TATA spare parts
283360010122D3	ASSY.BODY COMPLT ARCTIC_SILVR	TATA spare parts
283360010144BF	ASSY.CAB COMPLETE RHD(4SP BS2/3 1+4FIX)	TATA spare parts
283360010144CN	ASSY.BODY COMPLETE RHD IRISH CREAM	TATA spare parts
283360010145ZZ	ASSY.CAB COMP.RHD(4X4 TC BUK DI FEATURE	TATA spare parts
283360010146BF	ASSY.BODY SHELL COM.PAINTED RHD(4X4 TC)	TATA spare parts
28336001Z117BM	ASSY.BODY COMPLETE RHD 4X2 FIJI BLUE	TATA spare parts
28336001Z124BF	ASSY CAB COMPLETE LHD ARTIC WHITE	TATA spare parts
28336001Z124D3	ASSY.BODY COMP.LHD(4X4T AC BUKSBA RR FOL	TATA spare parts
28336001Z124D5	ASSY.BODY COMP.LHD(4X4T AC BUKSBA RR FOL	TATA spare parts
28336001Z125BF	ASSY BODY SHELL COMPLETE PAINTED ARTIC	TATA spare parts
28336001Z125D3	ASSY.BODY SHELL COMP.PAINTED LHD(AC 4X4T	TATA spare parts
28336001Z125D5	ASSY.BODY SHELL COMP.PAINTED LHD(AC 4X4T	TATA spare parts
283360106901	SUPPORT TUBE(TIE MEMBER - PANEL FRONT)	TATA spare parts
28336010Z110	ASSY.TIE MEMBER COMPLETE(2.2DICOR)	TATA spare parts
283360600102	PANEL INNER SIDE BONNET LH	TATA spare parts
283360600103	PANEL INNER SIDE BONNET RH	TATA spare parts
283360600104	ASSY. MUDGUARD FRONT LH	TATA spare parts
283360600105	ASSY. MUDGUARD FRONT RH	TATA spare parts
283360600107	ASSY.PANEL INNER S/BONNET RH	TATA spare parts
283360600114	ASSY.PANEL INNER SIDE BONNET LH (2.2DICO	TATA spare parts
283360600115	ASSY.PANEL INNER SIDE BONNET RH (2.2DICO	TATA spare parts
283360600116	ASSY.MUDGUARD COMPL.LH(4SPTC)	TATA spare parts
283360600118	ASSY.PANEL INNER SIDE BONNET LH(4SPTC)	TATA spare parts
283360608202	PANEL INNER SIDE BONNET LH(4SP TC/DICOR)	TATA spare parts
283360608203	PANEL INNER SIDE BONNET RH(4SP TC/DICOR)	TATA spare parts
283361600112	ASSY SEAT SUPPORT DRIVER SEAT-M10	TATA spare parts
283361606301	PLUG GROMMET (LOAD BODY)	TATA spare parts
283363000101	ASSY.SIDE WALL LH(W/O RR S/B MTG)RHD	TATA spare parts
283363000102	ASSY.SIDE WALL RH(W/O RR S/B MTG)RHD	TATA spare parts
283368800101	ASSY MOULDED CARPET KIT LHD(SAFARI TYPE)	TATA spare parts
283368800103	ASSY MOULDED CARPET KIT	TATA spare parts

283368800105	ASSY MOULDED CARPET KIT LHD	TATA spare parts
283368800107	ASSY MOULDED CARPET KIT RHD	TATA spare parts
283368800116	ASSY.KIT FLOOR MAT RHD	TATA spare parts
283369206301	TRIM BC POST LH	TATA spare parts
283369206302	TRIM BC POST RH	TATA spare parts
283369206303	TRIM FOR PANEL INNER CORNER R/W LH	TATA spare parts
283369206304	TRIM FOR PANEL INNER CORNER R/W RH	TATA spare parts
283370006301	FENDER EXTENSION (L/B)-GRAY	TATA spare parts
283373300101	ASSY.LINK LH (BELL CRANK)	TATA spare parts
283373300102	ASSY.LINK RH (BELL CRANK)	TATA spare parts
283373300103	DOOR SEALING RR LH OUTER	TATA spare parts
283373300104	DOOR SEALING RR RH OUTER	TATA spare parts
283373500103	ASSY.WEATHER STRIP OUTER-REAR LH	TATA spare parts
283373500104	ASSY.WEATHER STRIP OUTER-REAR RH	TATA spare parts
283373500105	ASSY.WEATHER STRIP INNER-REAR LH	TATA spare parts
283373500106	ASSY.WEATHER STRIP INNER-REAR RH	TATA spare parts
283373700101	ASSY.PADDING DOOR LH	TATA spare parts
283373700102	ASSY.PADDING DOOR RH	TATA spare parts
283373706301	CAP(COVER PADDING SCREWED TYPE)GRAY	TATA spare parts
283381100108	ASSY.SEALING INNER LH-FRONT DOOR	TATA spare parts
283381100109	ASSY.SEALING INNER RH (FRONT DOOR)-ANCO	TATA spare parts
283381100110	ASSY.SEALING INNER-LH (REAR DOOR)	TATA spare parts
283381100111	ASSY.SEALING INNER-RH (REAR DOOR)	TATA spare parts
283381100118	ASSY.SEALING INNER LH (FRONT DOOR)	TATA spare parts
283381100119	ASSY.SEALING INNER RH (FRONT DOOR)	TATA spare parts
283381100120	ASSY.SEALING INNER LH (REAR DOOR)	TATA spare parts
283381100121	ASSY.SEALING INNER RH (REAR DOOR)	TATA spare parts
283381100122	KIT FOR DECALS CREW CAB 4X4 PASS LIGHT	TATA spare parts
283381100123	ASSY.SEALING INNER LH (FRT.DOOR)	TATA spare parts
283381100124	ASSY.SEALING INNER RH (FRT.DOOR)	TATA spare parts
283381100125	ASSY.SEALING INNER LH (RR.DOOR)	TATA spare parts
283381100126	ASSY.SEALING INNER RH (RR.DOOR)	TATA spare parts
283381100130	ASSY.COVER LHD (SUPPORT PANEL)	TATA spare parts
283381100131	ASSY FOOT STEP LH	TATA spare parts
283381100136	ASSY.KIT DECAL 207 DI EX TMC/C MECH.STG.	TATA spare parts
283381100137	ASSY.KIT DECAL 207DI EX TMC/C POWER STG.	TATA spare parts
283381100164	DECAL SET TMCC 4X2LHD W/LOAD BODY PETROL	TATA spare parts
283381100165	KIT DECAL 207DI EX C/CAB (MECH. STG.)	TATA spare parts
283381100167	SIDE STEP ASSY	TATA spare parts
283381106301	COVER SILL FRONT (BLACK)	TATA spare parts
283381106302	COVER SILL REAR (BLACK)	TATA spare parts
283381106323	FOOT STEP STRIP	TATA spare parts
283381106332	LINER FRONT OUTER LH WHEEL ARCH(2.2DICOR	TATA spare parts
283381106333	LINER FRONT OUTER RH WHEEL ARCH(2.2DICOR	TATA spare parts
283381800101	ASSY. TATA 2.1 L MASCOT	TATA spare parts
283381800102	ASSY. `TATA 2.2 L ' MASCOT	TATA spare parts
283383100102	KIT AC COMPLETE	TATA spare parts

283383400101	KIT FOR AC FITMENTS	TATA spare parts
283383400102	ASSY.HOSE SUCTION	TATA spare parts
283383400103	ASSY.TUBE LIQUID(CONT.OUTLET)	TATA spare parts
283383400104	ASSY.TUBE LIQUID (R.D) OUTLET/LHD	TATA spare parts
283383400105	ASSY.TUBE LIQUID(R.D INLET)	TATA spare parts
283383400106	ASSY.HOSE DISCHARGE	TATA spare parts
283383400107	ASSY.TUBE LIQUID(C.COIL INLET)LHD	TATA spare parts
283383500101	ASSY HEATER COIL	TATA spare parts
283383500102	ASSY.HEATER COIL CPT.(NEW CONNECTOR)	TATA spare parts
283383505801	RUBBER HOSE (HEATER TO ENGINE)	TATA spare parts
283383505801AE	RBBR HSE(HTER TO ENG)-XEN DC/SC	TATA spare parts
283388500102BJ	BUMPER FRONT COMPLT ASSY.(16IN TYRE)	TATA spare parts
283391000104	ASSY.FRONT SEAT COMPLT.RH	TATA spare parts
283391000105	ASSY.FRONT SEAT COMPLT.LH	TATA spare parts
283391000111	ASSY.FRONT SEAT COMPLETE RH.	TATA spare parts
283391000112	ASSY.FRONT SEAT COMPLETE LH.	TATA spare parts
283391500101	ASSY.S/BELT COMPT. E CERT	TATA spare parts
283393000101	ASSY.RR.SEAT COMPLT.207DI-EX F/VINYL	TATA spare parts
283393000103	ASSY.RR.SEAT COMPLT.207DI-EX F/VINYL	TATA spare parts
283393000104	ASSY.RR.SEAT COMPLT.207DI-EX F/VINYL	TATA spare parts
283393000107	ASSY.REAR SEAT COMPLT.	TATA spare parts
283415100110	STARTER MOTOR TX SIDE-PETROL(COMSTAR)	TATA spare parts
283415400139	ALTERNATOR BSIV 70A (BOSCH MAKE)	TATA spare parts
283415990113	ROTOR ASSY.	TATA spare parts
283415990118	BRUSH ASSY.	TATA spare parts
283415990163	ENDPLATEASSY (STARTER0.8KWCOMSTAR) BS6	TATA spare parts
283415990164	BRUSHHOLDERASSY (STARTER0.8KWCOMSTAR) BS6	TATA spare parts
283415990165	ARMATUREASSY(STARTER0.8KWCOMSTAR) BS6	TATA spare parts
283415990166	FRAMEASSY (STARTER0.8KWCOMSTAR) BS6	TATA spare parts
283415990167	DRIVE&GEARASSY (STARTER0.8KWCOMSTAR) BS6	TATA spare parts
283415990168	HOUSINGASSY (STARTER0.8KWCOMSTAR) BS6	TATA spare parts
283415990169	SOLENOIDASSY (STARTER0.8KWCOMSTAR) BS6	TATA spare parts
283415999929	D.E. FAN	TATA spare parts
283415999930	S.R.E.BEARING	TATA spare parts
2834290	TURBOCHARGER	TATA spare parts
283429104203	SEPARATOR FOR DIA 10 X DIA 18 (M/S A RAY	TATA spare parts
283429104204	SEPARATOR FOR DIA 10 X DIA 10 (M/S A RAY	TATA spare parts
283429106501	NUT (FOR CLUTCH CABLE LOCK)	TATA spare parts
283429106501_niu3	NUT (FOR CLUTCH CABLE LOCK)	TATA spare parts
283429106701	PIN (FOR CLUTCH CABLE GUIDE)	TATA spare parts
283429108702	TORSION SPRING (FOR CLUTCH PEDAL RETURN)	TATA spare parts
283430104201	SEPERATOR FOR DIA 8 FUEL PIPE & DIA 6 AC	TATA spare parts
283430104203	SEPERATOR FOR DIA 13 FUEL PIPE & DIA 6 A	TATA spare parts
283430107703	RUBBER STOPPER (FOR ACCLERATOR PEDAL)	TATA spare parts
283430107703_NIU1	RUBBER STOPPER (FOR ACCLERATOR PEDAL)	TATA spare parts
283430107712	SLEEVE FOR LONG MEMBER EDGE (PETROL)	TATA spare parts
283430108701	TORSION SPRING (ACC. PEDAL RTN.)	TATA spare parts

283432100125	ASSY PIVOT BUSH - FRONT	TATA spare parts
283432401604	OFFER DRAWING - BUMP STOPPER REAR	TATA spare parts
283432409209	THRUST WASHER-(REAR AXLE) (REAR AXLE)	TATA spare parts
283433208201	HUB COVER	TATA spare parts
283442306006	ROCKER	TATA spare parts
283442308710	STRUT SPRING LH	TATA spare parts
283442308711	STRUT SPRING RH	TATA spare parts
283442704204	CLAMP (PARKING BRAKE CABLE)	TATA spare parts
283442704205	CLAMP PARKING BRAKE CABLE MOUNTING	TATA spare parts
283442704210	PARKING BRAKE CLAMP	TATA spare parts
283442708204	EQUALIZER PARKING BRAKE	TATA spare parts
283442708204_niu1	EQUALIZER PARKING BRAKE	TATA spare parts
283442804206	CLIP FOR BRAKE TUBE DIA 4.75 (M/S A RAYM	TATA spare parts
283442804207	CLIP FOR PARKING BRAKE DIA 9 (RAYMOND 13	TATA spare parts
283442804208	FRONT CLAMP FOR DIA.4.75 & DIA.10 DIA	TATA spare parts
283442804209	SEPERATOR FOR DIA.4.75 & DIA.10 PIPE	TATA spare parts
283442804216	MIDDLE BRAKE CLAMP FOR DIA.4.75 & DIA.10	TATA spare parts
283442990113	WHEEL CYL ASSY M/S BIL	TATA spare parts
283442990114	Adjuster Assembly -LH	TATA spare parts
283442990115	Adjuster Assembly -RH	TATA spare parts
283442990121	KIT LINED SHOE ASSY:CONTENT PER VEH.SET	TATA spare parts
283442990122	KIT W/CYL-MAJOR: CONTENTS PER W/CYL	TATA spare parts
283442990123	KIT W/CYL-MINOR:CONTENTS PER W/CYL	TATA spare parts
283442990124	KIT SHOE HOLD DOWN:CONTENTS PER BRK ASSY	TATA spare parts
283442990125	KIT LEVER PAWL:CONTENTS PER LH BRK ASSY	TATA spare parts
283442990126	KIT LEVER PAWL:CONTENTS PER RH BRK ASSY	TATA spare parts
283442990128	KIT W/CYL-MINOR:CONTENT PER W/CYL	TATA spare parts
283442990132	KIT HAND BRAKE LEVER PER LH BRAKE ASSY	TATA spare parts
283442990133	KIT HAND BRAKE LEVER PER RH BRAKE ASSY	TATA spare parts
283442990137	KIT SPRING ASSY	TATA spare parts
283442990158	ADJUSTER ASSY-RH	TATA spare parts
283442990159	ADJUSTER ASSY-LH	TATA spare parts
283442990161	W/CYL ASSY (?25.4)	TATA spare parts
283442997703	GROMMET - LINING INSPECTION	TATA spare parts
283442998005	BLEEDER SCREW	TATA spare parts
283442998708	SPRING W/CYL END	TATA spare parts
283442998709	PRING ADJUSTMENT	TATA spare parts
283442998713	SPRING W/CYL END	TATA spare parts
283443990113	RBIC MAJOR KIT	TATA spare parts
283443990114	RBIC MINOR KIT	TATA spare parts
283443990115	NRV MINOR KIT	TATA spare parts
283443990121	KIT SERVO	TATA spare parts
283443990128	WHEEL CYLINDER ASSY .( FRONT) ( FRONT 25	TATA spare parts
283443990140	AUTO ADJESTER LH	TATA spare parts
283443990141	AUTO ADJESTER RH	TATA spare parts
283443996704	SHOE HOLD DOWN SPRING	TATA spare parts
283443998003	BLEEDER SCREW	TATA spare parts

283443998702	SHOE HOLD DOWN CUP	TATA spare parts
283443999906	PLUG-BRAKE SHOE INSPECTION WINDOW	TATA spare parts
283447604207	STEPLESS EAR CLAMP(SIZE 22.6)- OETIKER	TATA spare parts
283447607709	CLAMP	TATA spare parts
283447607710	T-CONN(EVAPORATIVE LINE 10X10X10)	TATA spare parts
283447607711	CLAMP	TATA spare parts
283447607712	LINE SEPERATOR (DIA 17 X DIA 15)	TATA spare parts
283447607716	CLIP FOR DIA 11 TO 18	TATA spare parts
283447607719	CLAMP(M/S A RAYMOND)	TATA spare parts
283447607720	CLIP FOR PURGE VALVE TO ENGINE MAINFOLD	TATA spare parts
283447607722	CLAMP FOR 8 DIA FUEL LINE	TATA spare parts
283447607737	SEPERATOR CLAMP(DIA 8 X DIA 14)A RAYMOND	TATA spare parts
283447607743	CLAMP 12 DIA NYLON	TATA spare parts
283447607758	FUEL LINE CLAMP (8X10 OD TUBES) M/S RAYM	TATA spare parts
283447607767	SEPERATOR CLAMP (DIA 8 X DIA 9) M/S A RA	TATA spare parts
283449205306	GASKET (FOR CATALYTIC CONVERTER)	TATA spare parts
283454209916	GLOW PLUG INTERFACE UNIT BS-4 OG	TATA spare parts
283454209931	MICRORELAY 12V 25A WITH DIODE BS4	TATA spare parts
283454209935	VEHICLE SPEED SENSOR M/S PRICOL MAKE	TATA spare parts
283454400122	ASSY REAR FOG LAMP M/S LUMAX MAKE	TATA spare parts
283454400122_niu1	ASSY REAR FOG LAMP	TATA spare parts
283454400124	ASSY REGISTRATION PLATE LAMP	TATA spare parts
283454400124_niu1	ASSY REGISTRATION PLATE LAMP	TATA spare parts
283454406306	TAIL LAMP TOP CATCHER	TATA spare parts
283454406307	TAIL LAMP BOTTOM CATCHER ITW MAKE	TATA spare parts
283454406307_niu1	TAIL LAMP BOTTOM CATCHER	TATA spare parts
283454406310	HEAD LAMP CATCHER ITW MAKE	TATA spare parts
283454409908	SPECIAL SELF TAPPING SCREW OFFER	TATA spare parts
283454409908_niu1	SPECIAL SELF TAPPING SCREW	TATA spare parts
283454509914	REVERSE LAMP SWITCH	TATA spare parts
283454509947	OIL PRESSURE SWITCH (HIGH TEMP) PMP MAKE	TATA spare parts
283454606305	FASTENER FOR EMS WH DIA 19	TATA spare parts
283454606328	SEPERATOR CLAMP AC HEATER HOSE TO WH	TATA spare parts
283454606330	SEPERATOR CLAMP BETWEEN RUBBER HOSE &W	TATA spare parts
283454606341	SERVICE CLAMP DIA 29-35 MM	TATA spare parts
283454608286	BRACKET FOR CRANK ANGLE SENSOR WH MOUN	TATA spare parts
283454609903	EDGE CLIP	TATA spare parts
283454628225	BRACKET ON INTAKE MANIFOLD-AMT BS6	TATA spare parts
283454670136	ASSY BKT ON INTAKE MANIFOLD-AMT	TATA spare parts
283454700102	EX FAN_ DIESEL (120DEG)	TATA spare parts
283455106303	T EMBLEM TAILGATE	TATA spare parts
283455106304	MASCOT TATA	TATA spare parts
283458300101	ASSY. FIRST AID KIT	TATA spare parts
283458900601	DRIFT/BALANCER SHFT BUSH/NANO/ITEM DELET	TATA spare parts
283458900602	SPACER - VALVE GUIDE	TATA spare parts
283458900602_niu1	SPACER - VALVE GUIDE	TATA spare parts
283458900603	ENG.AND TRANSAXLE HOLDER	TATA spare parts



283458900603_NIU1	ENGINE AND TRANS AXLE HOLDER / NANO	TATA spare parts
283458900604	SPACER-VALVE GUIDE SEAL	TATA spare parts
283458900607	DRIFT-CRANK SHAFT FRONT & CAMSHAFT OIL S	TATA spare parts
283458900608	DRIFT-CRANK SHAFT REAR OIL SEAL	TATA spare parts
283458900609	HOLDING BRACKET FOR ENGINE	TATA spare parts
283458900612	TOOL FOR PRESS FITTING CYL. PIN ON CRANK	TATA spare parts
283458900613	TENSIONER (A/C COMPRESSOR BELT)	TATA spare parts
283458900614	TDC LOCKING PIN FOR FLYWHEEL	TATA spare parts
283458900615	SPANNER (FOR OIL FILTER)	TATA spare parts
283458900617	DIPSTICK TUBE ADAPTOR PRESSING TOOL	TATA spare parts
283458900620	CAMSHAFT LOCKING PLATE	TATA spare parts
283458900622	SUPPORT RAIL	TATA spare parts
283458902401	ENGINE TRANSAXLE WITH CRADLE MTG. STAND	TATA spare parts
283458902402	ENGINE SUPPORT STAND	TATA spare parts
283458902404	ENG.MTG.BKT.- RH	TATA spare parts
283458902405	ENG.MTG.BKT.-LH	TATA spare parts
283458902501	MANDREL FOR CLUTCH DISC ALIGNMENT	TATA spare parts
283458902502	MANDREL FOR CLUTCH DISC ALIGNMENT	TATA spare parts
283458902601	PULLER FOR REMOVAL OF INPUT SHAFT BEARIN	TATA spare parts
283458902604	PULLER FOR BEARING	TATA spare parts
283458902605	DRIFT FOR FITMENT OF DIFFERENTIAL BEARIN	TATA spare parts
283458902606	PULLER FOR BEARING FROM DIFFERENTIAL	TATA spare parts
283458902607	DRIFT	TATA spare parts
283458902608	SPL.TOOL FOR SNAP RING	TATA spare parts
283458902609	SPL. TOOL FOR SNAP RING.	TATA spare parts
283458902610	CIRCLIP INSERT TOOL	TATA spare parts
283458902611	MOUNTING PLATE FOR 4PL GEAR BOX	TATA spare parts
283458902614	DRIFT-SPL. TOOL FOR SNAP RING ASSY.	TATA spare parts
283458902615	DRIFT-INPUT AND LAY SHAFT REAR END BEARI	TATA spare parts
283458902616	PULLER FOR CRANK SHAFT BEARING	TATA spare parts
283458903201	REMOVAL OF BEARING FROM HUB	TATA spare parts
283458903202	DRIFT FOR FITMENT OF BEARING	TATA spare parts
283458903203	SPRING COMPRESSOR	TATA spare parts
283458903205	DOLLY-PIVOT BUSH	TATA spare parts
283458903206	DOLLY-PIVOT BUSH	TATA spare parts
283458903207	DOLLY - PIVOT BUSH (FOR REMOVAL)	TATA spare parts
283458903210	DOLLY -INSTALLATION OF BUSH ON LOWER LIN	TATA spare parts
283458903301	PULLER-FRONT WHEEL BRAKE DRUM	TATA spare parts
283458903501	PULLER/REMOVER INJECTOR	TATA spare parts
283458904201	HANDLE FOR - SHOE SET SPRING REMOVAL	TATA spare parts
283467102303_NIU	W/S GLASS TOUGHENED	TATA spare parts
283467106304	GLASS SPACER	TATA spare parts
283468900110	ASSY AIR VENT	TATA spare parts
283468908210	C NUT ST 4.8	TATA spare parts
283472300112	ASSY HINGE COMPLETE LH	TATA spare parts
283472300112_niu1	ASSY HINGE COMPLETE LH	TATA spare parts
283472300129	ASSY HINGE COMPLETE RH	TATA spare parts

283472300145	ASSY DOOR INNER HANDLE FRT LH	TATA spare parts
283472300145A6	ASSY DOOR INNER HANDLE FRT LH	TATA spare parts
283472300145AY	ASSY DOOR INNER HANDLE FRT LH	TATA spare parts
283472300146A6	ASSY DOOR INNER HANDLE FRT RH	TATA spare parts
283472300146AY	ASSY DOOR INNER HANDLE FRT RH	TATA spare parts
283472300155	ASSY WINDOW WINDING HANDLE	TATA spare parts
283472300155A6	ASSY WINDOW WINDING HANDLE	TATA spare parts
283472300155AY	SHADW_GREY_2-ASSY WINDOW WINDING HAND	TATA spare parts
283472300155_NIU01	WINDOW WINDING REGULATING HANDLE	TATA spare parts
283472300159	ASSY LATCH FRONT DOOR LH	TATA spare parts
283472300160	ASSY LATCH FRONT DOOR RH	TATA spare parts
283472300173	ASSY STRIKER SHIVANI	TATA spare parts
283472300173_niu1	ASSY STRIKER	TATA spare parts
283472306316	POP UP KNOB	TATA spare parts
283472306319	GROMMET POP UP KNOB	TATA spare parts
283472306325A6	BEZEL DOOR INNER HANDLE LH_ITW	TATA spare parts
283472306325AY	SHADW_GREY_2-BEZEL DOOR INNER HANDLE LH	TATA spare parts
283472306326A6	BEZEL DOOR INNER HANDLE RH_ITW	TATA spare parts
283472306326AY	BEZEL DOOR INNER HANDLE RH_ITW	TATA spare parts
283472308001	HEX FL BOLT M8X20 TS17130-8.8-SS8451S2-Y	TATA spare parts
283472308242	STRIKER MTG SHIM_1	TATA spare parts
283472308243	SPECIAL WASHER FOR DOOR HINGE	TATA spare parts
283472310119	ASSY HINGE COMPLETE WITH SINGLE PIN LH	TATA spare parts
283472310120	ASSY HINGE COMPLETE WITH SINGLE PIN RH	TATA spare parts
283472310123	ASSY HINGE COMPLETE LH (ICR)	TATA spare parts
283472310124	ASSY HINGE COMPLETE RH (ICR)	TATA spare parts
283472506310	GLASS CLIP	TATA spare parts
283481100119	ASSY SUNVISOR WITH TWO POINT MTG LH	TATA spare parts
283481100120	ASSY SUNVISOR WITH TWO POINT MTG RH	TATA spare parts
283481100120AQ	ASSY SUNVISOR	TATA spare parts
283481106337	SUNVISOR HINGE CLIP MOUNTING LH	TATA spare parts
283481106337AQ	SUNVISOR HINGE CLIP MOUNTING LH	TATA spare parts
283481106338	SUN VISOR HINGE CLIP MOUNTING RH	TATA spare parts
283481106341	HOLE PLUG (FOAM 35X20)	TATA spare parts
283481106345	HOLE PLUG(FOAM DIA.18)	TATA spare parts
283482407705	EXTENSION_PIECE_WASHER_PIPE	TATA spare parts
283483400115	ASSEMBLY COMPRESSOR COMPLETE - PANASONI	TATA spare parts
283483400159	ASSY THERMAL PROTECTOR KIT COMPRESSOR	TATA spare parts
283483400160	ASSY RELIEF VALVE COMPRESSOR	TATA spare parts
283483400161	ASSY CLAMP THERMAL COMPRESSOR	TATA spare parts
283483400162	ASSY SCREW WASH FOR COMPRESSOR	TATA spare parts
283483400163	ASSY 'O' RING COMPLETE FOR COMPRESSOR	TATA spare parts
283483400164	ASSY MAGNETIC CLUTCH COMPLETE FOR COMPR	TATA spare parts
283483400165	ASSY SHIM KIT COMPLETE FOR COMPRESSOR	TATA spare parts
283483400174	ASSY COMPRESSOR COMPLETE - PANASONIC 65C	TATA spare parts
283483400347	RING SNAP 10P08 COMPRESSOR NANO BS6	TATA spare parts
283483400348	ASSY RING SNAP 10P08 COMPRESSOR SK5 NANO	TATA spare parts

283483400349	ASSY WASHER PLATE T0.1- 10P08 COMP NANO	TATA spare parts
283483400350	ASSY WASHER PLATE T0.3- 10P08 COMP NANO	TATA spare parts
283483400351	ASSY WASHER PLATE T0.5- 10P08 COMP NANO	TATA spare parts
283483400352	BOLT WASHER HEAD SCM435 10P08 COMPR NANO	TATA spare parts
283483400353	SCREW WASHER SWCH6-8 10P08 COMP NANO BS	TATA spare parts
283483404230	A RAYMOND SEPARATOR CLAMP - FOR ENGINE S	TATA spare parts
283491306302	RECLINER PP KNOB	TATA spare parts
283499506304	HEADLINING MTG CLIP ITW	TATA spare parts
283499506306	CARPET CLIP ITW	TATA spare parts
283499506306C7	GRANIT_BLACK-CARPET CLIP ITW	TATA spare parts
283499506315AQ	HEADLINING TREE CLIP LENGTH 25 JAIHIND	TATA spare parts
283499706303	HOLE PLUG DIA 25	TATA spare parts
283499706304	RUBBER GROMMET 14.6X18.6 FLANGED	TATA spare parts
283499706306	RUBBER GROMMET 10X12	TATA spare parts
283499706309	HOLE PLUG DIA 30	TATA spare parts
283499706316	PLUG BUTTON FOR 16X20 SLOT	TATA spare parts
283499706323	TESA TAPE 35 DIA	TATA spare parts
283826800101	ASSY TURNING TUBEW/O BJOINT(LP1510CBSII)	TATA spare parts
283840100101	ASSY.WH RIM 7.00X20 148 OFFSET	TATA spare parts
283841100101	ASSY.PROP.SHAFT WITH SEALED CENTRE BRG.(	TATA spare parts
283841100104	ASSY.PROP.SHAFT WITH SEALED CENTRE BRG.(	TATA spare parts
283841100107	ASSY.PROP.SHAFT WITH SEALED CENTRE BRG.(	TATA spare parts
283841120101	ASSY.PROP.SHAFT REAR COMPLETE (1730 CLOS	TATA spare parts
283841120104	ASSY.PROP.SHAFT REAR COMPLETE (1695 CLOS	TATA spare parts
283841300101	ASSY.BRACKET RH (PROP.SHAFT GUARD MTG.)	TATA spare parts
283841300102	ASSY.BRACKET LH (PROP.SHAFT GUARD MTG)	TATA spare parts
283924200101	ASSY.BKT.ENGINE MTG.-LH (REAR BOTTOM)	TATA spare parts
283924200102	ASSY.BKT.ENGINE MTG.-RH (REAR BOTTOM)	TATA spare parts
283924200104	ASSY.BRACKET-LH (ENGINE MOUNTING REAR)	TATA spare parts
283924200105	ASSY.BRACKET-RH (ENGINE MOUNTING REAR)	TATA spare parts
283926800103	ASSY TURNING TUBE WITHOUT BALL JOINT	TATA spare parts
283926800105	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
283926800109	ASSY G.S.LEVER WITH ASSY TURNING TUBE	TATA spare parts
283926800111	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
283926800115	ASSY. TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
283926800120	TURNING TUBE ASSY	TATA spare parts
283926800124	TURNING TUBE ASSY BS6	TATA spare parts
283926800127	TURNING TUBE ASSY(W/O BALL JOINT) BS6	TATA spare parts
283926810101	ASSY BRACKET G.S.LEVER MTG	TATA spare parts
283926810102	ASSY BRACKET (G.S.LEVER MTG)	TATA spare parts
283929100102	ASSY. CLUTCH PIPE (6 O.D.)	TATA spare parts
283929100105	ASSY.CLUTCH FLUID RESERVOIR WTH CLAMP-RH	TATA spare parts
283929100106	ASSY.CLUTCH FLUID RESERVOIR	TATA spare parts
283929100107	ASSY.CLUTCH FLUIDE RESERVOIR	TATA spare parts
283929100108	ASSY CONNECTING LINE (10 O.D)	TATA spare parts
283930100106	ASSY PULL ROD(ACC.CONTROL L=885)	TATA spare parts
283930100107	ASSY PULL ROD (L=735)	TATA spare parts

283930100109	ASSY.PULL ROD	TATA spare parts
283930100110	ASSY.STOPPER	TATA spare parts
283930107601	STUD BS6-PH2	TATA spare parts
283931000101	ASSY.FRAME COMPLETE TC TILT CAB	TATA spare parts
283931000102	ASSY.FRAME LPT2515EX BSII COWL	TATA spare parts
283931000103	ASSY.FRAME COMP( LD.BDY. CLEAT)2515 LPT	TATA spare parts
283931000104	ASSY. FRAME COMPLETE	TATA spare parts
283931000105	ASSY. FRAME COMPLETE	TATA spare parts
283931200101	ASSY.SUPPORT (ENGINE CROSS MEMBER FRONT)	TATA spare parts
283931200102	ASSEMBLY BUMPER CROSS MEMBER	TATA spare parts
283931200103	ASSY. REINFORCEMENT(FR SPR HANGER BKT)	TATA spare parts
283931200104	ASSY REINFORCEMENT LH FR SPR HANGER BKT	TATA spare parts
283931200105	ASSY. SUPPORT (ENG. C.M. FRONT)	TATA spare parts
283931200106	ASSY.ENGINE C.M.REAR WITH SPACER PLATES	TATA spare parts
283931200108	ASSY. RADIATOR MTG. BKT.	TATA spare parts
283931307101	REINFORCEMENT - RH	TATA spare parts
283931307102	REINFORCEMENT - LH	TATA spare parts
283931700102	ASSY. BOTTOM SHIELD(ENGINE)	TATA spare parts
283931700103	ASSY. TRANSMISSION SHIELD(FRT. SIDE)	TATA spare parts
283931700104	ASSY. TRANSMISSION SHIELD REAR SIDE	TATA spare parts
283931700105	ASSY. SUPPORT BKT(ENGINE SIDE)	TATA spare parts
283931700109	ASSY BOTTOM SHIELD ENGINE SIDE	TATA spare parts
283931700110	ASSY TRANSMISSION SHIELD FRT. SIDE	TATA spare parts
283931700112	ASSY BOTTOM SHIELD(RAD. SIDE)	TATA spare parts
283931700113	ASSY SIDE SHIELD-RH	TATA spare parts
283931700114	ASSY SIDE SHIELD-LH	TATA spare parts
283932204201	U CLAMP	TATA spare parts
283932208601	SPACER	TATA spare parts
283932208602	SPACER	TATA spare parts
283932300101	ASSY. BRACKET (FRONT S/A UPPER)	TATA spare parts
283932403301	SPRING HANGER BRACKET (REAR -FRONT)	TATA spare parts
283932403302	SPRING HANGER BRACKET (REAR MIDDLE)	TATA spare parts
283932403303	SPRING HANGER BRACKET (REAR REAR)	TATA spare parts
283932403401	BUSH(77L) BELL CRANK LEVER	TATA spare parts
283932403402	BUSH (57 L) BELL CRANK LEVER	TATA spare parts
283932800103	ASSY.ANTIROLL BAR WITH EYE PIECE COMPL.	TATA spare parts
283933000101	ASSY.FRONT AXLE COMP. WITH BRAKES	TATA spare parts
283933000103	ASSY FRONT AXLE COMP.WITH BRAKES	TATA spare parts
283933000104	FRONT AXLE ASSY WITH BRAKES	TATA spare parts
283933400104	ASSY WHEEL HUB FRONT COMPLETE	TATA spare parts
283933400105	ASSY.WHEEL HUB WITH POLE WHEEL.	TATA spare parts
283933400106	FRONT HUB ASSY BS6	TATA spare parts
283933405101	WHEEL HUB FRONT	TATA spare parts
283933405301	HUB COVER GASKET¿BS6	TATA spare parts
283940200101	ASY RDL TYRE TUBE FLAP REAR 10.00R20 LUG	TATA spare parts
283940200102	TYRE,BLOCK TYPE 10.00 R20	TATA spare parts
283941100101	ASSY.PROP.SHAFT. FRONT	TATA spare parts

283941100104	ASSY PROPELLER SHAFT FRONT	TATA spare parts
283941100105	ASSY PROP SHAFT FRONT	TATA spare parts
283941120101	ASSY.PROP.SHAFT REAR	TATA spare parts
283941120102	ASSY.PROP.SHAFT REAR	TATA spare parts
283941303301	SPACER(CENTRE BRG. MTG. BKT.) BS2/3	TATA spare parts
283942100129	FRONT BRAKE LINING KIT STD	TATA spare parts
283942100130	FRONT BRAKE LINING KIT OS1	TATA spare parts
283942100131	FRONT BRAKE LINING KIT OS2	TATA spare parts
283942109901	POLEWHEEL - FRONT	TATA spare parts
283942109902	KIT LINING SET NO.- STANDARD SIZE	TATA spare parts
283942109903	KIT LINING SET NO.- FIRST OVER SIZE	TATA spare parts
283942109904	KIT LINING SET NO.- FIRST OVER SIZE	TATA spare parts
283942300107	ASSY.BRACKET RH-S.B.ACTUATOR MTG.	TATA spare parts
283942300108	ASSY.BRACKET LH-S.B.ACTUATOR MTG.	TATA spare parts
283942300178	ASY SPRG BRAKE ACTUAT RH	TATA spare parts
283942300179	ASY SPRG BRAKE ACTUAT LH	TATA spare parts
283942300181	ASY SPRG BRAKE ACTUAT-	TATA spare parts
283942300182	ASY SPRG BRAKE ACTUAT-	TATA spare parts
283942300202	ASSY.REAR DRUM BRAKE W/DUST COVER LH	TATA spare parts
283942300203	ASSY.REAR DRUM BRAKE W/DUST COVER RH	TATA spare parts
283942300237	ASSYREAR BRAKE LH WITH D/C	TATA spare parts
283942300238	ASSY REAR BRAKE RH WITH D/C	TATA spare parts
283942303401	BUSH-S.B.ACTUATOR MTG.BKT.	TATA spare parts
283942303701	BRACKET RH-BRAKE CHAMBER MTG.	TATA spare parts
283942303702	BRACKET LH-BRAKE CHAMBER MTG.	TATA spare parts
283942307801	OIL SEAL-CHAMBER MTG.BKT.	TATA spare parts
283942307901	CAMSHAFT LH (SHORTER TYPE)	TATA spare parts
283942307902	CAMSHAFT RH (SHORTER TYPE)	TATA spare parts
283942308301	SHIM 0.3 MM	TATA spare parts
283942309903	POLE WHEEL (REAR)	TATA spare parts
283942309904	POLEWHEEL REAR	TATA spare parts
283942309905	SET OF BRAKE LININGS W/O RIVETS (WHEEL S	TATA spare parts
283942309906	SET OF BRAKE LININGS W/O RIVETS (WHEEL S	TATA spare parts
283942309907	SET OF BRAKE LININGS W/O RIVETS (WHEEL S	TATA spare parts
283942310106	REAR BRAKE LINING KIT STD	TATA spare parts
283942310107	REAR BRAKE LINING KIT OS1	TATA spare parts
283942310108	REAR BRAKE LINING KIT OS2	TATA spare parts
283942310109	SPRING BRAKE ACTUATOR TYPE 20/24 M/S. SC	TATA spare parts
283942310110	SPRING BRAKE ACTUATOR-KB-TYPE 20/24 STRA	TATA spare parts
283942990101	TORQUE PLATE M/C	TATA spare parts
283942990102	TORQUE PLATE M/C	TATA spare parts
283942990103	KIT--TORQUE PLATE LH BS6	TATA spare parts
283942990104	KIT TORQUE PLATE	TATA spare parts
283942990107	KIT-CAMSHAFT LH BS6-PH2	TATA spare parts
283942990108	KIT-CAMSHAFT RH BS6-PH2	TATA spare parts
283942990109	KIT- TORQUE PLATE RH BS6	TATA spare parts
283942990110	KIT-CAMSHAFT	TATA spare parts

283942990111	KIT-CAMSHAFT	TATA spare parts
283942990112	KIT-CAMSHAFT LH (BIL)	TATA spare parts
283942990113	KIT-CAMSHAFT RH (BIL)	TATA spare parts
283942990120	DUST SHIELD BOTTOM	TATA spare parts
283942990121	KIT-BRAKE BRACKET ASSY	TATA spare parts
283942990126	KIT-BRAKE BRACKET ASSY (BIL) BS6-PH2	TATA spare parts
283942990128	KIT-BRAKE BUSH (BIL)	TATA spare parts
283942990130	KIT-BRAKE DUST SHIELD ASSY	TATA spare parts
283943200101	ASSY.AIR TANKS WITH STRAP-VOSS	TATA spare parts
283943700101	ASSY VOITH RETARDER (CHASSIS MOUNTED)	TATA spare parts
283943700110	ASSY.SPRING BRAKE ACTUATOR RH TYPE-20/75	TATA spare parts
283943700111	SPRING BRK. ACTUATOR LH 20/75 BS1/2/3	TATA spare parts
283943700118	RELAY VALVE VOSS(1 DEL.PORT BS1/2/3/4	TATA spare parts
283943700119	RELAY VALVE VOSS(1DEL.POT PL	TATA spare parts
283943703801	HEAT EXCHANGER KIT	TATA spare parts
283943704301	CIRCLIP	TATA spare parts
283943704701	HOUSING VENTILATION	TATA spare parts
283943704901	ECU	TATA spare parts
283943706101	SHAFT SEAL RING	TATA spare parts
283943706102	SEAL RING	TATA spare parts
283943707201	SCREW PLUG	TATA spare parts
283943707701	SEAL	TATA spare parts
283943707702	SEAL RING	TATA spare parts
283943707703	SEAL	TATA spare parts
283943707801	O-RING	TATA spare parts
283943707802	O-RING	TATA spare parts
283943707803	O-RING	TATA spare parts
283943707804	O-RING	TATA spare parts
283943707805	O-RING	TATA spare parts
283943708201	ISOLATING PLATE	TATA spare parts
283943708202	HAND-LEVER	TATA spare parts
283943708301	GLAND RING	TATA spare parts
283943708302	MEGI RING BUFFER	TATA spare parts
283943709001	PROP. VALVE	TATA spare parts
283943709201	WASHER	TATA spare parts
283943709202	UNDULATED WASHER	TATA spare parts
283943709203	WASHER	TATA spare parts
283943709901	PRESSURE SENSOR LPO1616	TATA spare parts
283943709902	TEMPERATURE SENSOR	TATA spare parts
283943709903	FOOT CONTROL	TATA spare parts
283943900108	ASSY.NYLON PIPE SET FOR CHASSIS-LPT2518	TATA spare parts
283943900109	ASSY.METAL PIPE WITH CRIMPED HOSE-2518TC	TATA spare parts
283943900111	ASSY.NYLON PIPE SET CHASSIS COMPLETE-VOS	TATA spare parts
283943900120	ASSY.NYLON PIPE SET COMPLETE -/CAB/VOSS	TATA spare parts
283943900126	ASSY.NYLON PIPE SET CAB COMPLETE-2515TC	TATA spare parts
283943900134	ASSY.METAL PIPE HOSE TO INT.JOINT(DIA18)	TATA spare parts
283943900135	ASSY.METAL PIPE INT.JOINT TO DDU (DIA18)	TATA spare parts

283943906801	FIRTEE 12X6X12	TATA spare parts
283947600101	ASSY SUCTION LINE (NYLON)	TATA spare parts
283947600102	ASSY RETURN LINE (NYLON)	TATA spare parts
283949200102	ASSY.EXHAUST PIPE (81.2 O.D.)	TATA spare parts
283949200103	ASSY.INTERMEDIATE EXHAUST PIPE(81.2 OD)	TATA spare parts
283949200108	ASSY SUPPORT BRACKET	TATA spare parts
283949200109	ASSY EXHAUST PIPE	TATA spare parts
283949200110	ASSY EXHAUST PIPE	TATA spare parts
283949203304	CLAMP	TATA spare parts
283949203305	CLAMP	TATA spare parts
283949203307	BRACKET	TATA spare parts
283949203308	BRACKET	TATA spare parts
283954100101	ASSY BATTERY CABLE +VE (50SQ MM)	TATA spare parts
283954209901	SPEEDOCABLE (JIS) 4000 LG.	TATA spare parts
283954209902	SPEEDOCABLE (JIS) 4000 LG.	TATA spare parts
283954209903	INSTRUMENT CLUSTER 1:1.04 BS-II	TATA spare parts
283954209906	WIPER CONTROLLER 24V	TATA spare parts
283954209912	INST.CLUSTER (ELECT)(1:1.04)	TATA spare parts
283954209913	INSTRUMENT CLUSTER(1:1.04)	TATA spare parts
283954209915	INST.CLUSTER(ELECT)(1:1.04)	TATA spare parts
283954209916	INSTRUMENT CLUSTER(ELECT) (1:1.04)	TATA spare parts
283954209917	INST.CLUSTER(ELECT)(1 1.04)M/S MINDA	TATA spare parts
283954249901	SPEEDOMETER (1:0.88)(BACKLIT)	TATA spare parts
283954249902	SPEEDOMETER 1:0.88(BACKLIT)	TATA spare parts
283954249903	RPM METER 24V(BACKLIT)	TATA spare parts
283954249904	SPEEDOMETER (1:0.88)(BACKLIT)	TATA spare parts
283954249906	SPEEDOMETER(1:1.04)(BACKLIT)24V	TATA spare parts
283954249908	R.P.M.METER(24V BAKLIT 1600-2200RPM)	TATA spare parts
283954400101	ASSY ENGINE LAMP(24V 21W W/BULB S/W)	TATA spare parts
283954400102	ASSY ENGINE LAMP(24V 21W W/BLB W/SW)	TATA spare parts
283954440103	LAMP END OUTLINE MARKER - 24V	TATA spare parts
283954440105	ASSY WARNING LAMP IND(24V)	TATA spare parts
283954440106	ASSY WARNING LAMP INDICATOR (24V)	TATA spare parts
283954440107	END OUTLINE MARKER LAMP(24V)	TATA spare parts
283954440109	ASSY MOTORISED HEAD LAMP COMPLETE 24V LH	TATA spare parts
283954440109AE	ASSY. HLAMP WITH BULB LH -715	TATA spare parts
283954440110	ASSY MOTORISED HEAD LAMP COMPLETE 24V RH	TATA spare parts
283954440110AE	ASSY. HLAMP WITH BULB RH -715	TATA spare parts
283954440112	ASY FRONT FOG LAMP 24V MTG.BOTM	TATA spare parts
283954440113	ASY FRONT FOG LAMP 24V MTG.TOP	TATA spare parts
283954440114	LAMP ASSY REAR FOG LAMP 24V 'A'MTG	TATA spare parts
283954440124	ASSY H/L RH (RHD)	TATA spare parts
283954440125	ASSY H/L LH (RHD)	TATA spare parts
283954440128	ASSY H/L RH (RHD)24V W/O HLL MOT	TATA spare parts
283954440129	ASSY H/L LH (RHD)24V W/O HLL MOT	TATA spare parts
283954440134	ASSY HEADLAMP LH (RHD)24V W/O HLLA	TATA spare parts
283954440135	ASSY HEADLAMP RH (RHD)24V W/O HLLA	TATA spare parts

283954440137	ASSY LAMP- WARNING IND-24V	TATA spare parts
283954504901	SWITCH EMERGENCY HELP	TATA spare parts
283954506301	DUMMY FACIA SWITCH COVER	TATA spare parts
283954509901	SWITCH EXHAUST BRAKE	TATA spare parts
283954509902	SWITCH ABS DIAGNOSTICS	TATA spare parts
283954509903	SWITCH FRONT FOG LAMP	TATA spare parts
283954509904	SWITCH REAR FOG LAMP	TATA spare parts
283954509905	RETARDER ON/OFF SWITCH	TATA spare parts
283954509913	SWITCH ENGINE LAMP	TATA spare parts
283954509915	SWITCH REAR ILLUMINATION LAMP	TATA spare parts
283954509924	HAZARD WARNING SWITCH	TATA spare parts
283954509925	HEADLAMP LEVELLING SWITCH	TATA spare parts
283954559901	EXHAUST BRAKE SW 24V (FACIA SW)	TATA spare parts
283954559902	ABS DIAGNOSTIC SW 24V(FACIA SW)	TATA spare parts
283954559903	FRONT FOG LAMP SW 24V(FACIA SW)	TATA spare parts
283954559904	REAR FOG LAMP 24V-FACIA SW	TATA spare parts
283954559905	RETARDER ON/OFF SW 24V-FACIA SW	TATA spare parts
283954559906	POWER TAKE OFF SW 24V-FACIA SW	TATA spare parts
283954559907	DIFFERENTIAL LOCK SW 24V-FACIA SW	TATA spare parts
283954559909	INTER AXLE DIFF LOCK 24V-FACIA SW	TATA spare parts
283954559910	TRANSFER CASE LOW 24V-FACIA SW	TATA spare parts
283954559911	LOW COOLANT LEVEL SW 24V-FACIA SW	TATA spare parts
283954559912	ENGINE DIAGNOSTIC SW 24V-FACIA SW	TATA spare parts
283954559914	ENGINE LAMP SW 24V-FACIA SW	TATA spare parts
283954559915	BATT CUT OFF ELECT.SW 24V-FACIA SW	TATA spare parts
283954559916	REAR ILLUMINATION LAMP SW 24V-FACIA SW	TATA spare parts
283954559924	HAZARD WARNING SW. 24V BS1/2/3/4	TATA spare parts
283954559925	HEAD LAMP LEVELLING SW (24V)	TATA spare parts
283954559926	BLANK FASCIA SWITCH (24V)	TATA spare parts
283954600101	W/H MAIN--TILT CAB VERSION	TATA spare parts
283954600103	W/H CONSOLE--TILT CAB VERSION	TATA spare parts
283954600104	W/H TAIL--TILT CAB VERSION	TATA spare parts
283954600105	W/H MAIN LPT2518TC-BS-II LP	TATA spare parts
283954600106	W/H TAIL LPT2518TC/48 BS-II LP FACE	TATA spare parts
283954600107	W/H ENGINE LPT2518TC BS-II LP FACE	TATA spare parts
283954600114	W/H ENGINE--TILT CAB VERSION	TATA spare parts
283954608202	L-CHANNEL SUPPORT	TATA spare parts
283954620102	W/H TAIL--TILT CAB VERSION	TATA spare parts
283954620104	W/H MAIN--TILT CAB VERSION	TATA spare parts
283954620105	W/H CONSOLE--TILT CAB VERSION	TATA spare parts
283954620106	W/H MAIN LPT2518TC BS-II LP FACE	TATA spare parts
283954620107	W/H ENGINE LPT2518TC BS-II LP FACE	TATA spare parts
283954620108	W/H TAIL LPT2518/48TC EXH.BR.LP FACE	TATA spare parts
283954620109	W/H ENGINE--TILT CAB VERSION	TATA spare parts
283954620111	WIRING HARNESS CONSOLE	TATA spare parts
283954620113	W/H MAIN LPT 2518TC E-II ELE CLUSTR	TATA spare parts
283954620115	W/H TAIL LPT2518TC W ELE CLSUTER	TATA spare parts



283954620128	W/H TAIL LPT2518/62WB TC 24V BS-III	TATA spare parts
283954620131	W/H MAIN-LPT2518TC COWL 24V ERGO PACK W	TATA spare parts
283954620139	WIRING HARNESS PARK BRAKE SWITCH	TATA spare parts
283954660101	W/H MAIN LPT2518TC BS-II LP FACE	TATA spare parts
283954660102	W/H TAIL LPT2518TC BS-II LP FACE	TATA spare parts
283954660103	W/H ENGINE LPT2518TC BS-II LP FACE	TATA spare parts
283954660111	W/H MAIN-LPT2518TC COWL 24V ERGO PACK	TATA spare parts
283954660113	WIRING HARNESS TAIL	TATA spare parts
283954660125	WIRING HARNESS TAIL	TATA spare parts
283954680101	W/H MAIN LPT2518TC BS-II 24V LP	TATA spare parts
283954680102	W/H ENGINE LPT2518TC BS-II 24V LP FACE	TATA spare parts
283954680103	W/H TAIL LPT2518TC BS-II LP EX.BK	TATA spare parts
283954690102	W/H MAIN-LPT2518TC COWL 24V	TATA spare parts
283954700101	W/HMAIN-LPT2518TC COWL 24V ERGOPACK	TATA spare parts
284031500101	TOW HOOK	TATA spare parts
284032100103	ASSY.BRACKET LH. AXLE STOPPER	TATA spare parts
284032100104	ASSY. BRACKET RH.AXLE STOPPER	TATA spare parts
284032100110	ASSY. FRONT SPRING	TATA spare parts
284032103202	CENTRE BOLT M12X1.5	TATA spare parts
284032105101	SADDLE -LH (BOTTOM -FRONT)	TATA spare parts
284032105102	SADDLE -RH (BOTTOM -FRONT)	TATA spare parts
284032105103	SADDLE-LH(BOTTOM FRONT)	TATA spare parts
284032105104	SADDLE-RH(BOTTOM FRONT)	TATA spare parts
284032106701	DOWEL PIN (BOTTOM SADDLE -FRONT)	TATA spare parts
284032203701	GUIDE PLATE	TATA spare parts
284032204203	U BOLT	TATA spare parts
284032204204	U BOLT	TATA spare parts
284032204205	U BOLT	TATA spare parts
284032204206	U BOLT	TATA spare parts
284032400106	ASSY. REAR SPRING	TATA spare parts
284032403201	CENTRE BOLT M16X1.5	TATA spare parts
284032403701	GUIDE PLATE	TATA spare parts
284032404201	U BOLT	TATA spare parts
284032404201AE	U CLAMP 1628	TATA spare parts
284032405101	SADDLE (BOTTEM REAR)	TATA spare parts
284032406701	DOWEL PIN (BOTTOM SADDLE REAR)	TATA spare parts
284032406701AE	DWL PIN (BTTM SADDLE RR) -1628	TATA spare parts
284042103401	SENSOR SLEEVE-FRONT	TATA spare parts
284042109903	POLE WHEEL- FRONT ABS	TATA spare parts
284042109903AE	POLE WHEEL- FRONT ABS 1628	TATA spare parts
284042300120	ASSY REAR BRAKE LH	TATA spare parts
284042300121	ASSY REAR BRAKE RH	TATA spare parts
284047700101	ASSY.BRACKET (FUEL FILTER MOUNTING)	TATA spare parts
284054100101	ASSY.COPPER BATT.CABLE (+ VE) 70SQMM RED	TATA spare parts
284054100102	ASSY.COPPER BATT. CABLE (- VE) BLACK	TATA spare parts
284054100106	ASSY.COPPER BATT. CABLE (+ VE) RED 200A	TATA spare parts
284054100108	ASSY.COPPER BATT. CABLE (- VE) BLACK 200	TATA spare parts

284054400105	ASSY FRONT FOG LAMP 24V	TATA spare parts
284054400105AE	ASSY FRONT FOG LAMP 24V - -1628	TATA spare parts
284054660102	W/H BUMPER LPTA 2038TC 6X6	TATA spare parts
284054660106	W/H ROOF LPTA2038TC BS-III	TATA spare parts
284054660107	W/H SWITCH LPTA 2038TC BSIII	TATA spare parts
284126800101	ASSY BRACKET(G.S.L.MTG)LPS4018-2.64DEG.	TATA spare parts
284126800103	ASSY TURNING TUBE(WITHOUT BALL JOINT)	TATA spare parts
284126800114	ASSY. TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
284126800118	ASSY.TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
284126800120	TURNING TUBE ASSY	TATA spare parts
284126800125	TURNING TUBE ASSY BS6	TATA spare parts
284126800127	TURNING TUBE ASSY BS6-PH2	TATA spare parts
284126800129	TURNING TUBE ASSY BS6-PH2	TATA spare parts
284126800133	TURNING TUBE ASSY BS6-PH2	TATA spare parts
284126810104	ASSY. BRACKET (GEAR SHIFT LEVER MTG.)	TATA spare parts
284126900101	ASSY HOSE - OIL HOSE OUT	TATA spare parts
284126900102	ASSY. HOSE-OIL IN	TATA spare parts
284129100101	ASSY. LEVER	TATA spare parts
284129100102	ASSY CLUTCH LEVER	TATA spare parts
284129500101	ASSY.CONTROL MTG.BKT.WITH CYL.MTG.BKT	TATA spare parts
284130100101	ASSY.BRACKET	TATA spare parts
284130100102	ASSY.ACCELERATOR LEVER	TATA spare parts
284130100103	ASSY.LEVER ACCELERATOR PEDAL	TATA spare parts
284130100104	ASSY.THRUST ROD	TATA spare parts
284131000101	ASSY. FRAME	TATA spare parts
284131000102	ASSY. FRAME LPS 4018 TC	TATA spare parts
284131000103	ASSY. FRAME WITH FITMENT BS2/3/4	TATA spare parts
284131200101	ASSY. BUMPER CROSS MEMBER BS1/2/3/4	TATA spare parts
284131200102	ASSY. CHANNEL	TATA spare parts
284131208203	PLATFORM	TATA spare parts
284131208205	PLATFORM (FRONT)	TATA spare parts
284131600101	ASSY.MOUNTING PLATE-V WHEEL COUPLING	TATA spare parts
284131600102	ASSY MTG PLATE WITH FIFTH WH COUPLING	TATA spare parts
284131700102	ASSY BOTTOM SHIELD(ENGINE SIDE)3516/4018	TATA spare parts
284131700103	ASSY TRANS.SHIELD FRT SIDE (3516/4018)	TATA spare parts
284131700104	ASSY TRANS.SHIELD RR SIDE(3516/4018)	TATA spare parts
284131700105	ASSY SUPPORT BRACKET(FRT. ENGINE SIDE)	TATA spare parts
284131700108	ASSY SUPPORT BKT(RR.TRANS.SHLD RT.SIDE)_	TATA spare parts
284131700109	ASSY SUPPORT BKT.(RR.TRANS.SIDE LT.SIDE)	TATA spare parts
284131700113	ASSY TRANS.SHIELD(RR UPPER SIDE)	TATA spare parts
284131700114	ASSY SUPPORT BKT.(RR UPPER SIDE)	TATA spare parts
284132100101	ASSY. FRONT SPRING	TATA spare parts
284132100102	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
284132100104	ASSY. BRACKET - RH (AXLE STOPPER)	TATA spare parts
284132100105	ASSY. BRACKET - LH (AXLE STOPPER)	TATA spare parts
284132100106	ASSY.FRONT SPRING PARABOLIC	TATA spare parts
284132100111	FRONT SPRING ASSY	TATA spare parts

284132100113	FRONT SPRING ASSY	TATA spare parts
284132103201	CENTRE BOLT	TATA spare parts
284132103203	CENTRE BOLT	TATA spare parts
284132107102	SECOND LEAF	TATA spare parts
284132107103	THIRD LEAF	TATA spare parts
284132107104	FOURTH LEAF	TATA spare parts
284132107105	FIFTH LEAF	TATA spare parts
284132107106	SIXTH LEAF	TATA spare parts
284132107107	SEVENTH LEAF	TATA spare parts
284132107108	EIGHTH LEAF	TATA spare parts
284132107109	PACKING PLATE	TATA spare parts
284132107110	PACKING PLATE	TATA spare parts
284132107116	CASTER PLATE	TATA spare parts
284132400101	ASSY. REAR SPRING W/ AUX. SPR. BS1/2/3/4	TATA spare parts
284132400102	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
284132400102DF	MAIN LEAF REAR W/BUSH-LPK1613-LPS3516/40	TATA spare parts
284132400106	ASSY. REAR SPRING (WITH AUX. SPRING)	TATA spare parts
284132403201	CENTRE BOLT	TATA spare parts
284132404203	AUX. CLIP (MAIN SPRING RAER)	TATA spare parts
284132404204	U - CLAMP	TATA spare parts
284132404205	SPRING CLIP	TATA spare parts
284132407102	SECOND LEAF (MAIN SPRING)	TATA spare parts
284132407103	THIRD LEAF (MAIN SPRING)	TATA spare parts
284132407103DF	THIRD LEAF REAR-LPK1613/1618-LPS3516/401	TATA spare parts
284132407104	FOURTH LEAF (MAIN SPRING)	TATA spare parts
284132407105	FIFTH LEAF (MAIN SPRING)	TATA spare parts
284132407105DF	FIFTH LEAF REAR-LPK1613/1618-LPS3516/401	TATA spare parts
284132407106	SIXTH LEAF (MAIN SPRING)	TATA spare parts
284132407107	SEVENTH LEAF (MAIN SPRING)	TATA spare parts
284132407108	EIGHTH LEAF-(MAIN SPRING)	TATA spare parts
284132407109	MAIN LEAF (AUX PACK)	TATA spare parts
284132407109DF	MAIN LEAF AUX SPRING-LPK1613-LPS3516/401	TATA spare parts
284132407110	2ND LEAF (AUX PACK)	TATA spare parts
284132407111	3RD LEAF (AUX PACK)	TATA spare parts
284132407112	4TH LEAF (AUX PACK)	TATA spare parts
284132407113	5TH LEAF (AUX PACK)	TATA spare parts
284132800103	ASSY. CONNECTING LINK	TATA spare parts
284132800104	ASSY. ANTIROLL BAR COMPLETE WITH LINK	TATA spare parts
284132800105	ASSY. ANTIROLL BAR WITH EYE PIECE	TATA spare parts
284132800108	ASSY CONNECTING LINK	TATA spare parts
284134100101	ASSY. FIFTH WHEEL COUPLING BS1/2/3/4	TATA spare parts
284134200101	SPARE KIT FIFTH WHEEL COUPLING	TATA spare parts
284134200201	LATCH ASSY	TATA spare parts
284134200202	ASSY. PEDESTAN BLOCK BS1/2/3/4	TATA spare parts
284134200203	ASSY. PEDESTAL BS4/6	TATA spare parts
284134200301	HANDLE ASSY	TATA spare parts
284134203201	HEX BOLT	TATA spare parts

284134203202	SPECIAL HEX BOLT OF FIFTH WHEEL	TATA spare parts
284134203203	SPECIAL HEX BOLT OF FIFTH WHEEL	TATA spare parts
284134203204	HEX BOLT	TATA spare parts
284134203205	HEX BOLT	TATA spare parts
284134203206	SOCKET HEAD BOLT	TATA spare parts
284134203501	BOSS	TATA spare parts
284134206002	LOCK JAW	TATA spare parts
284134206003	LEVER	TATA spare parts
284134206101	LOCKING PLATE	TATA spare parts
284134206701	CLAMPING PROFILE	TATA spare parts
284134206702	SPLIT PIN	TATA spare parts
284134206703	PIVOT PIN	TATA spare parts
284134207101	FIFTH WHEEL TOP PLATE BS6	TATA spare parts
284134207501	BUSH	TATA spare parts
284134208001	ADJUSTING SCREW	TATA spare parts
284134208701	WEAR RING	TATA spare parts
284134208702	SPRING	TATA spare parts
284134208703	TENSION SPRING	TATA spare parts
284134208704	TENSION SPRING	TATA spare parts
284141120101	ASSY.PROP. SHAFT	TATA spare parts
284141120102	SLIP YOKE ASSY	TATA spare parts
284141125101	FLANGE YOKE	TATA spare parts
284142109901	POLEWHEEL FRONT (MACHINED)	TATA spare parts
284142300101	ASS.R/A BRAKE LH WITH DUST COVER	TATA spare parts
284142300102	ASS.R/A BRAKE RH WITH DUST COVER	TATA spare parts
284142300117	S-CAM SHAFT RH(REAR BRAKE ASSY)	TATA spare parts
284142300118	S-CAM SHAFT LH(REAR BRAKE ASSY)	TATA spare parts
284142308201	ANCHOR BRACKET-REAR (FOR AUTO SLACK ADJ)	TATA spare parts
284142308202	ANCHOR BRACKET FOR AUTO SLK ADJ.	TATA spare parts
284142308203	ANCHOR BRACKET RH FOR AUTO SLACK ADJ	TATA spare parts
284142308205	ANCHOR BRACKET LH FOR ASA SUPPORT.	TATA spare parts
284142308206	ANCHOR BRACKET RH FOR ASA SUPPORT	TATA spare parts
284142308208	ANCHOR BRACKET FOR ASA TRAILER AXLE L.	TATA spare parts
284142308209	ANCHOR BRACKET FOR ASA TRAILER AXLE R.H	TATA spare parts
284142309901	POLE WHEEL-REAR	TATA spare parts
284143200101	ASSY. BRACKET-DDU MOUNTING	TATA spare parts
284143200102	ASSY.BRACKET-AIR TANK MOUNTING	TATA spare parts
284143200103	ASSY AIR TANK WITH BKT(VOSS)-LPS4018	TATA spare parts
284143900133	ASSY.MODULATOR VALVE	TATA spare parts
284143900134	MADULATOR VALVE 24V	TATA spare parts
284146207901	STEERING SPINDLE - BOTTOM LPS4018	TATA spare parts
284147100101	BALL VALVE D/FEMALE 1/2IN BSPN RIVIGO	TATA spare parts
284147100102	ASSY.FUEL TANK COMP RH(225 L 24V TU)	TATA spare parts
284147100103	ASSY. FUEL TANK COMP LH (225L)	TATA spare parts
284147508601	SPACER	TATA spare parts
284149104201	CLAMP (SILENCER MOUNTING)	TATA spare parts
284149200101	ASSY.PIPES ( I & II ) WITH FLEX CONNECTR	TATA spare parts

284149200113	ASSY.TAIL PIPE WITH SPARK ARRESTER	TATA spare parts
284149200116	ASSY.MUFFLER	TATA spare parts
284149200117	ASSY.HEAT SHIELD.	TATA spare parts
284149200123	ASSY PIPE (I & II) WITH FLEX CONNECTOR	TATA spare parts
284149203313	BRACKET (ON ENGINE BLOCK)	TATA spare parts
284149204201	EXHAUST CLAMP (MUFFLER INLET & OUTLET)	TATA spare parts
284149204202	CLAMP (SPARK ARRESTER MOUNTING)	TATA spare parts
284149204203	CLAMP (SECOND PIPE)	TATA spare parts
284149208203	BRACKET (RADIATOR FRAME TO FIRST PIPE)	TATA spare parts
284149208208	SUPPORT BRACKET	TATA spare parts
284149208209	MUFFLER SUPPORT BRACKET RH	TATA spare parts
284149208210	MUFFLER SUPPORT BRACKET LH	TATA spare parts
284149208216	BRACKET(HEAT SHIELD MTG.)	TATA spare parts
284152200101	ASSY.SPACER FRT LH -(REAR WH ARCH MTG)	TATA spare parts
284152200102	ASSY. SPACER FRT RH (REAR WH ARCH MTG)	TATA spare parts
284152200103	ASSY BKT LH REAR COMPLETE	TATA spare parts
284152200104	ASSY BKT RH REAR COMPLETE	TATA spare parts
284152200105	ASSY.BKT.LH FRT(REAR WHEEL ARCH MTG.)	TATA spare parts
284152200106	ASSY.BKT.RH FRT(REAR WHEEL ARCH MTG.)	TATA spare parts
284152200107	ASSY PLATE REAR WHEEL ARCH MOUNTING	TATA spare parts
284152200108	ASSY WHEEL ARCH - LH	TATA spare parts
284152200111	ASSY WHEEL ARCH - RH	TATA spare parts
284152203301	BRACKET-TAIL LAMP MTG.	TATA spare parts
284152204201	CLAMP(REAR MUD GUARD MTG.)	TATA spare parts
284152206304	MUD FLAP REAR (UPPER)- LH.3516 4018 TC	TATA spare parts
284152206305	MUD FLAP REAR (UPPER)- RH.3516 4018 TC	TATA spare parts
284152206307	MUD FLAP REAR (LOWER)3516 4018 TC	TATA spare parts
284152208202	COVER (MUD FLAP)	TATA spare parts
284152400101	BRACKET ASSY COMPLETE-LH (TAIL LAMP MTG)	TATA spare parts
284152400102	BRACKET ASSY COMPLETE-RH (TAIL LAMP MTG)	TATA spare parts
284154100101	ASSY FRAME WITH COVER (BATTERY MTG.)	TATA spare parts
284154108211	CHANNEL (444 LG.)(BATTERY CLAMPING)	TATA spare parts
284154249901	RPM METER (1200-2000)24V	TATA spare parts
284154249902	FUEL GAUGE_24V BIPOLAR	TATA spare parts
284154249903	ELECT.TEMP GAUGE 24V BIPOLAR	TATA spare parts
284154249904	AIR PRESSURE GAUGE_24V BIPOLAR	TATA spare parts
284154249905	SPEEDOMETER 1:0.88 BIPOLAR	TATA spare parts
284154400101	ASSY.H/L N/MOTRSD 12V W/O RIM LHD LH AUT	TATA spare parts
284154400102	ASSY.H/L N/MOTRSD 12V W/O RIM LHD RH AUT	TATA spare parts
284154440101	ASY SIDE IND LMP RH 24V W/BLB(BIPOLR)	TATA spare parts
284154440102	ASY SIDE IND LMP-LH 24V W/BLB(BIPOLR)	TATA spare parts
284154440103	ASY T/MKR LAMP-RH 24V W/BULB_BIPOLAR	TATA spare parts
284154440104	ASY T/MKR LAMP-LH_24V W/BULB_BIPOLAR	TATA spare parts
284154440112	ASSY MOTORISED H/L LH W/O RIM 24V	TATA spare parts
284154440113	ASSY MOTORISED H/L RH W/O RIM 24V	TATA spare parts
284154440114	ASSY. HEAD LAMP RH 24V MTR W/O RIM BS3/4	TATA spare parts
284154440115	ASSY. HEAD LAMP LH 24V MTR W/O RIM BS3/4	TATA spare parts

284154440116	ASY MOT H/L 24V E CRT LH-RHD-W/O RIM	TATA spare parts
284154440117	ASY MOT H/L 24V E CRT RH-RHD-W/O RIM	TATA spare parts
284154440122	ASSY.H/L E-CERT 12V B W/O RIM RHD LH	TATA spare parts
284154440123	ASSY.H/L E-CERT 12V B W/O RIM RHD RH	TATA spare parts
284154440126	ASSY N/MOTRSD H/L LHD LH W/O RIM 24V AUT	TATA spare parts
284154440127	ASSY N/MOTRSD.H/L LHD RH W/O RIM 24V AUT	TATA spare parts
284160100106	ASSY CAB COMPLETE-RHD	TATA spare parts
284160100106SJ	ASSY SL. CAB COMPL LPS 4018 TC ABS SPARE	TATA spare parts
284160100107	ASSY. BODYSHELL PAINTED-RHD BS1/2/3	TATA spare parts
284160100116	ASSY.CAB COMPLETE	TATA spare parts
284160100116SJ	ASSY.CAB COMPLETE-RHD SPARE PARTS	TATA spare parts
284160100117	ASSY COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
284160100118	ASSY COWL SHELL PAINTED	TATA spare parts
284160100123	ASSY COWL COMPLETE WITH FITMENTS	TATA spare parts
284160100124	ASSY COWL SHELL PAINTED	TATA spare parts
284160100129	ASSY COWL SHELL PAINTED	TATA spare parts
284161000102	ASSY SUBSTRUCTURE-RHD	TATA spare parts
284161600101	ASSY.FLOOR PANEL LH RHD FRONT	TATA spare parts
284161600105	ASSY EXTN. MUDGUARD REAR-LH	TATA spare parts
284161600106	ASSY EXTN. MUDGUARD REAR-RH	TATA spare parts
284161608201	RETAINER FLOOR SIDE BS6	TATA spare parts
284162200101	SUPPORT ASSY WAIST RAIL BS6	TATA spare parts
284162200102	ASSY BRACKET(AUX.WATER TANK MTG.) BS6	TATA spare parts
284162200103	ASSY PARTITION WALL RH	TATA spare parts
284162200104	WAIST RAIL ASSY	TATA spare parts
284162200107	ASSY. PARTITION WALL LH BS6	TATA spare parts
284162500103	ASSY BRACKET(SIDE GRILLE MTG.)	TATA spare parts
284162500105	ASSY PANEL OUTER COMPLETE RHD BS6	TATA spare parts
284162508201	PANEL FACE SIDE BOOTOM-LH	TATA spare parts
28416250820135	PANEL FACE SIDE BOOTOM-LH+CED BS1/2/3/4	TATA spare parts
284162508202	PANEL FACE SIDE BOTTOM-RH BS1/2/3/4	TATA spare parts
284162600101	ASSY BONNET COMPLETE	TATA spare parts
284162608203	CORNER GUSSET LH BS6	TATA spare parts
284162608204	CORNER GUSSET RH BS6	TATA spare parts
284168400101	ASSY COMPOSITE FLOOR MAT-RHD	TATA spare parts
284172300109	KIT LOCKS RHD BS1/2/3	TATA spare parts
284172300112	ASSY OUTER HANDLE WITH LOCK-LH	TATA spare parts
284172300113	ASSY OUTER HANDLE WITH LOCK-RH	TATA spare parts
284172300114	ASSY LOCK-GLOVE BOX	TATA spare parts
284172300115	ASSY KEY	TATA spare parts
284175100101	ASSY.CENTRE FLAP WELDED	TATA spare parts
28417510010135	ASSY.CENTRE FLAP WELDED + CED BS1/2/3/4	TATA spare parts
284175108201	PANEL OUTER(CENTRE FLAP)	TATA spare parts
284175108202	PANEL INNER (CENTRE FLAP)	TATA spare parts
284181100101	ASSY GRILL-SIDE WINDOW	TATA spare parts
284181100102	ASSY GRILL-REAR WINDOW	TATA spare parts
284181100103	ASSY. GRILL COMP.(CENTRE FLAP) BS1/2/3/4	TATA spare parts

284181100104	ASSY GRILLE CENTRE FLAP	TATA spare parts
284181100107	ASY ARRESTOR SPRAY SUPPRESSION	TATA spare parts
284181106301	GRILLE SIDE LH BS1/2/3/4	TATA spare parts
284181106302	SIDE GRILLE RH BS1/2/3/4	TATA spare parts
284181106304	CAP SCREW(M6 PAN HD SCR.)	TATA spare parts
284181106305	REPEATER BEZEL LH	TATA spare parts
284181106306	REPEATER BEZEL RH	TATA spare parts
284181106307	HEADLAMP COVER LH	TATA spare parts
284181106308	HEADLAMP COVER RH	TATA spare parts
284181106501	CR.PAN HD SCR.M6X44(CONICAL END)	TATA spare parts
284181109901	BRASS INSERT M6(M/S TAPS) BS6	TATA spare parts
284181800101	ASSY TATA 4018 C MASCOT	TATA spare parts
284181900101	ASSY ENGINE SHIELDING LH-RHD	TATA spare parts
284181900102	ASSY ENGINE SHIELDING RH-RHD	TATA spare parts
284181900105	ASSY ENGINE HEAT SHIELD REAR	TATA spare parts
284182409901	WIPER MOTOR 24V 17W-HI POWER RHD	TATA spare parts
284188106303	FENDER TRIM LH BS1/2/3/4	TATA spare parts
284188106304	FENDER TRIM RH BS1/2/3/4	TATA spare parts
284188106305	MUDFLAP REAR	TATA spare parts
284188106306	MUD FLAP REAR	TATA spare parts
284188106307	FENDER TRIM LH	TATA spare parts
284188106308	FENDER TRIM RH	TATA spare parts
284188107701	BEADING FENDER LH	TATA spare parts
284188107702	BEADING FENDER RH	TATA spare parts
284188500101	ASSY BUMPER COMPLETE	TATA spare parts
284188500106	ASSY BUMPER COMPL WITH FOAM	TATA spare parts
284188500106C0	ASSY BUMPER WITH REFLECTOR - BLACK	TATA spare parts
284188500114	ASSY BUMPER COMPLETE	TATA spare parts
284188700101	ASSY. ENGINE HOOD COMP. BS1/2/3/4/6	TATA spare parts
284188700102	ASSYINSULATIONRH(ENGINEHOOD) BS6	TATA spare parts
284188700103	ASSY ENGINE HOOD COMPLETE LHD	TATA spare parts
284188700106	ENGINE HOOD ASSY	TATA spare parts
284188706303	ENGINEHOOD BS6	TATA spare parts
284188707101	SEALING RUBBER(ENGINE HOOD)	TATA spare parts
284189100101	ASSY BRACKET-LH(REAR MTG.)	TATA spare parts
284189100102	ASSY BRACKET RH(REAR MTG.)	TATA spare parts
284189100103	ASSY. BRACKET LH (REAR MTG.)	TATA spare parts
284189100104	ASSY. BRACKET RH (REAR MTG.)	TATA spare parts
284189100105	ASSY MOUNTING BRACKET LH - REAR	TATA spare parts
284189100106	ASSY MOUNTING BRACKET RH - REAR	TATA spare parts
284189100107	ASSY MTG BKT LH(REAR)	TATA spare parts
284189100108	ASSY MTG BKT RH(REAR)	TATA spare parts
284191000108	ASSY DRIVER SEAT(4018)H/R-RHD-FABRIC (LP	TATA spare parts
284191000110	ASSY DRIVER SEAT(2516)-RHD W/O HR	TATA spare parts
284191000111	ASSY DRIVER SEAT(2516)W/O HR LHD-VINYL	TATA spare parts
284215409901	WORKING BRACKET FRONT	TATA spare parts
284215409902	ROTOR	TATA spare parts

284215409903	STATOR	TATA spare parts
284215409904	REGULATOR FOR AFTER MARKET	TATA spare parts
284215409905	WORKING BRACKET REAR	TATA spare parts
284215409906	RECTIFIER ASSY(26214284)	TATA spare parts
284242807703	SEPERATOR FOR THREE PIPE LINES	TATA spare parts
284242807704	SEPERATOR FOR TWO PIPELINES	TATA spare parts
284246600101	POWER RACK & PINION STG.GEAR-LHD(TRW-RAN	TATA spare parts
284247100107	ASSY FUEL TANK CAP-NONVENTED	TATA spare parts
284254209907	VEHICLE SPEED SENSOR-VDO	TATA spare parts
284254209912	MINIATURE RELAY 12V 20A	TATA spare parts
284254209916	MICRO RELAY 12V 20A R-ENGINEERING	TATA spare parts
284254209921	RELAY 12V 40A BROWN	TATA spare parts
284254509911	POWER STEERING PRESS SW-NC-OFFER	TATA spare parts
284254509912	DOOR SWITCH(REAR) WITH 2 POLE CONN	TATA spare parts
284254509915	DOOR SWITCH (REAR)-2 TER	TATA spare parts
284254509917	HOOD(BONNET) SWITCH-2 TER	TATA spare parts
284254509919	OIL PRESSURE SWITCH	TATA spare parts
284254606303	STUD MOUNTABLE CABLE TIE L-160 FOR M6	TATA spare parts
284342806801	3-WAY CONNECTOR	TATA spare parts
284344807701	SUCTION HOSE (P/STG)(NON-ABS)	TATA spare parts
284354200119	KIT TANK UNIT PETROL	TATA spare parts
284354209913	VEHICLE SPEED SENSOR (FACELIFT)	TATA spare parts
284354209915	VEHICLE SPEED SENSOR (FACELIFT)	TATA spare parts
284354209931	TEMP SENSOR	TATA spare parts
284354209934	VEHICLE SPEED SENSOR (FACELIFT)	TATA spare parts
284354209942	12V 20A MICRO NOR RELAY	TATA spare parts
284354209952	RELAY 12V 40A NO/NC R-ENGG	TATA spare parts
284354209953	RELAY 12V 20A NO/NC	TATA spare parts
284354209954	VEHICLE SPEED SENSOR	TATA spare parts
284354209963	EGR CONTROLLER III	TATA spare parts
284354409919	SIDE REPEATER LAMP (CLEAR LENS)	TATA spare parts
284354409922	RED BULB - 12V 21W	TATA spare parts
284354409945	SIDE REPEATER LAMP (CLEAR LENS)	TATA spare parts
284354409956	SIDE REPEATER LAMP (CLEAR LENS)	TATA spare parts
284354500111	KIT POWER WINDOW SW	TATA spare parts
284354509906	FRONT POWER WINDOW SW PACK	TATA spare parts
284354509910	FRONT POWER WINDOW SW PACK BS3/4	TATA spare parts
284354509913	POWER WINDOW SW FR DOORS	TATA spare parts
284354509914	POWER WINDOW SW FR DOORS	TATA spare parts
284354509916	OIL PRESSURE SW(BANJO TYPE)	TATA spare parts
284354608202	BRACKET WIRING HARNESS CLAMP	TATA spare parts
284354608206	BRKT W/H PARKING ON FIP	TATA spare parts
284354608207	BRACKET - W/H ON ENGINE	TATA spare parts
284354609904	PIGTAIL - HAND BRAKE SWITCH	TATA spare parts
284354610157	ASSY. CABLE TIE HOLDER	TATA spare parts
284354909902	MASTER CUM FOLLOWER UNIT	TATA spare parts
284354909903	FOLLOWER UNIT	TATA spare parts



284355106306	MASCOT GLE	TATA spare parts
284358408202	VIN NO. PLATE- SOUTH AFRICA	TATA spare parts
284383100149	Evap Assy for round tube	TATA spare parts
284399508801	STUD (EYEBROW FIXING)	TATA spare parts
284467102301	WIND SHIELD GLASS TINTED WITH BLUE BAND	TATA spare parts
284488504302	CLIP LOWER GRILL	TATA spare parts
284500990101	RETRO KIT ASSY FOR WINGER PLATINUM	TATA spare parts
284500990102	SERVICE KIT WINGER 3488WB AIS 140	TATA spare parts
284500990103	SERVICE KIT WINGER 3200WB AIS 140	TATA spare parts
284515100101	STARTER MOTOR 1.9KW WITH THERMAL CUTOFF	TATA spare parts
284515109901	STARTER FRAME BS6	TATA spare parts
284515109902	EPICYCLOIDAL GEAR TRAIN	TATA spare parts
284515109903	OVERRUNNING-DRIVE CLUTCH	TATA spare parts
284515109904	DRIVE END SHIELD	TATA spare parts
284515109905	BEARING PEDESTAL BS6	TATA spare parts
284515109906	SEAL BS6	TATA spare parts
284515109907	SOLENOID SWITCH	TATA spare parts
284515109908	ARMATURE	TATA spare parts
284515109909	COMMUTATOR END SHIELD	TATA spare parts
284515109910	BRUSH HOLDER	TATA spare parts
284515109911	HEXAGON SCREW BS6	TATA spare parts
284515109912	OVAL-HEAD SCREW	TATA spare parts
284515109913	SPRING LOCK WASHER (M8)	TATA spare parts
284515400101	ALTERNATOR-W/VCCU.PUMP-12V 150A	TATA spare parts
284515400105	ALTERNATOR 12V 90A 51.5DIA PULLY	TATA spare parts
284515400106	IMPROVED 150A ALTERNATOR	TATA spare parts
284515400107	IMP.ALTERNATOR-150AMP-W/O VACC.PUMP-CN	TATA spare parts
284515400108	ALTERNATOR WINGER 2.2L BSIV	TATA spare parts
284515400112	STATOR ASSY BS6-PH2	TATA spare parts
284515400113	ROTOR ASSY BS6-PH2	TATA spare parts
284515400126	ALTERNATOR 12V 150A INT FAN VACCUM PUMP	TATA spare parts
284515400127	D.E BRACKET ASSEMBLY BS6	TATA spare parts
284515400128	ROTOR ASSEMBLY BS6	TATA spare parts
284515400129	STATOR WINDING ASSY BS6	TATA spare parts
284515400130	RECTIFIER ASSY BS6	TATA spare parts
284515400131	REGULATOR CUM BRUSH BOX ASSY BS6	TATA spare parts
284515400132	SRE BRACKET ASSEMBLY BS6	TATA spare parts
284515400133	VACUUM PUMP ASSEMBLY BS6	TATA spare parts
284515400135	SUCTION CONNECTOR ASSY BS6	TATA spare parts
284515400137	BEARING ASSEMBLY KIT BS6	TATA spare parts
284515400138	FASTENERS ASSEMBLY KIT BS6	TATA spare parts
284515403201	HEX BOLT ALTERNATOR BS6-PH2	TATA spare parts
284515403301	D.E BRACKETS M/C	TATA spare parts
284515403302	S.R.E BRACKET M/C	TATA spare parts
284515406301	COVER ASSY BS6-PH2	TATA spare parts
284515406501	HEXAGON NUT BS6-PH2	TATA spare parts
284515407001	PULLY ALTERNATOR	TATA spare parts

284515407002	PULLEY BS6-PH2	TATA spare parts
284515407902	ROTOR ASSY	TATA spare parts
284515407903	ROTOR	TATA spare parts
284515409901	STATOR WINDING FINAL ASSY.	TATA spare parts
284515409902	RECTIFIER ASSEMBLY	TATA spare parts
284515409903	REGULATOR CUM BRUSH BOX ARRANGEMENT	TATA spare parts
284515409905	VANES	TATA spare parts
284515409906	CHECK VALVE ASSY	TATA spare parts
284515409907	BEARING ASSY KIT	TATA spare parts
284515409909	VACCUM PUMP ASSEMBLING KIT	TATA spare parts
284515409910	PLUG MOULDING ASSEMBLING KIT	TATA spare parts
284515409912	ASYMMETRIC FAN	TATA spare parts
284515409939	PULLEY BS6	TATA spare parts
284515608201	WH EMS SUPPORT BKT	TATA spare parts
284524100102	HEAT SHIELD BS6	TATA spare parts
284529100101	ASSY. CONT.MTG.BKT.	TATA spare parts
284529100103	ASSY. CLUTCH CABLE 2233MM BS2/3/4	TATA spare parts
284529100106	ASSY CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
284529100109	ASSY. CLUTCH CABLE	TATA spare parts
284529100111	BRACKET	TATA spare parts
284529100112	ASSY.CONTROL MTG.BKT.WITH BRAKE&CLUTCH	TATA spare parts
284529100117	ASSY CONTL MTG BKT	TATA spare parts
284529100120	BRACKET ASSY BRAKE & CLUTCH CONTROL MTG	TATA spare parts
284529100124	CLUTCH PEDAL ASM	TATA spare parts
284529100125	CLUTCH PEDAL BRACKET ASSEMBLY	TATA spare parts
284529100126	CLUTCH PEDAL ASSEMBLY WITH BRACKET	TATA spare parts
284529100128	STOPPER BRACKET ASSEMBLY	TATA spare parts
284529100129	ASSEMBLY HP LINE CMC	TATA spare parts
284529100130	ASSY TUBE TO SLAVE CYLINDER	TATA spare parts
284529100137	BRACKET CLUTCH CABLE - YOKE& END	TATA spare parts
284529100202	CLUTCH PEDAL ASSY BS6-PH2	TATA spare parts
284529100204	BRACKET ASSY PEDAL SUPPORT BS6-PH2	TATA spare parts
284529100205	CLUTCH PEDAL ASSY WITH MTG BRKT BS6-PH2	TATA spare parts
284529104301	CLIP-CLUTCH CABLE	TATA spare parts
284529104302	CLIP(FOR SHAFT PEDAL)	TATA spare parts
284529106701	PIN(FOR CLUTCH CABLE)	TATA spare parts
284529106702	PIN - CLUTCH PEDAL	TATA spare parts
284529106902	CLUTCH - PRESSURE LINE BS4	TATA spare parts
284529107703	CLUTCH PEDAL STOPPER	TATA spare parts
284529107704	GASKET	TATA spare parts
284529108204	FORK-CLUTCH CABLE	TATA spare parts
284529108223	CMC BRACKET ON FIREWALL	TATA spare parts
284529108701	CLUTCH PEDAL ASSISTANCE SPRING	TATA spare parts
284529108740	COMPRESSION SPRING BS6-PH2	TATA spare parts
284529109201	WASHER FLEXIBLE 16	TATA spare parts
284529109202	WASHER (BOOSTER PIN MOUNTING) BS6	TATA spare parts
284529200101	ASSY. BRAKE PEDAL LEVER COMPLETE	TATA spare parts

284529200102	ASSY BRAKE PEDAL	TATA spare parts
284529200104	ASSY. BRAKE PEDAL WELDED	TATA spare parts
284529200105	ASSEMBLY BRAKE PEDAL WITH BRACKET	TATA spare parts
284529200106	ASSY CONTROL-2.2L DICOR BSIV	TATA spare parts
284529200112	BRAKE PEDAL ASSY WITH BUSH	TATA spare parts
284529200113	BRAKE PEDAL ASSY WITH MTG BRACKET	TATA spare parts
284529206701	PIN(FOR BOOSTER)	TATA spare parts
284529206702	PIN(FOR BOOSTER)	TATA spare parts
284529208601	SPACER	TATA spare parts
284529208602	SPACER	TATA spare parts
284529403401	BUSH (16X18)	TATA spare parts
284529403402	BUSH (6X8)	TATA spare parts
284529406901	SHAFT - CLUTCH & BRAKE PEDAL	TATA spare parts
284529406903	SHAFT CLUTCH & BRAKE PEDAL	TATA spare parts
284530100102	ASSY. ACCELERATOR PEDAL COMPLETE.	TATA spare parts
284530100104	ASSY ACCELERATOR CABLE 1522MM	TATA spare parts
284530100105	ASSY ACCELERATOR CABLE	TATA spare parts
284530100107	ASSY ACCELERATOR CABLE	TATA spare parts
284530100108	ASSY ACCELERATOR CABLE	TATA spare parts
284530100109	ASSY BRACKET-PEDAL STOPPER	TATA spare parts
284530100112	ACCELERATOR PEDAL MODULE	TATA spare parts
284530100113	BRACKET ASSY ACCELERATOR	TATA spare parts
284530100116	ACCELERATOR CABLE ASSY	TATA spare parts
284530100117	ACCELERATOR CABLE ASSY	TATA spare parts
284530100118	ACCELERATOR CABLE ASSY	TATA spare parts
284530101602	ASSY ACCELERATOR PEDAL	TATA spare parts
284530107703	PROTECTOR	TATA spare parts
284530107704	RUBBER COVER	TATA spare parts
284530108701	RETURN SPRING ACCELERATOR PEDAL	TATA spare parts
284531000101	ASSY.RETRO KIT FOR WINGER FRAME FLATROOF	TATA spare parts
284531300101	ASSY TIE MEMBER LH	TATA spare parts
284531300102	ASSY TIE MEMBER RH	TATA spare parts
284531300103	ASSY ENG MTG CROSS MEMBER(3RD POINT)	TATA spare parts
284531300104	ASSY GEAR BOX MTG BRACKET	TATA spare parts
284531300106	ASSY CAGE NUT M8X1.25	TATA spare parts
284531300110	CROSS MEMBER ASSY ENGINE MTG BS6-PH2	TATA spare parts
284531300111	PLATE ASSY BS6-PH2	TATA spare parts
284531308001	HEX BOLT M10 X 105	TATA spare parts
284531308002	HEX.FL BOLT M12X1.25X70	TATA spare parts
284531308206	BRACKET CROSS MEMBER (3RD POINT)	TATA spare parts
284531600101	ASSY. SUBFRAME FRONT BS2/3/4	TATA spare parts
284531600111	FRONT SUBFRAME ASSY.	TATA spare parts
284531600116	SUBFRAME ASSY	TATA spare parts
284531607701	RUBBER FOR SUPPORT BKT FRONT	TATA spare parts
284531608226	ENGINE MOUNT SUPPORT BKT LH FRONT	TATA spare parts
284531608227	ENGINE MOUNT SUPPORT BKT RH FRONT	TATA spare parts
284532100104	ASSY. LOWER BALL JOINT BS2/3/4	TATA spare parts

284532100105	ASSY LOWER WISHBONE FRONT LH BS4	TATA spare parts
284532100106	ASSY LOWER WISHBONE FRONT RH BS4	TATA spare parts
284532100108	ASSY LOWER BALL JOINT	TATA spare parts
284532100109	ASSY LOWER BALL JOINT	TATA spare parts
284532100111	ASSY. TOP CUP WITH BEARING BS2/3/4	TATA spare parts
284532100112	ASSY. BUSH LOWER WISHBONE BS2/3/4	TATA spare parts
284532100118	ASSY. LOWER WISHBONE COMPLETE LH	TATA spare parts
284532100119	ASSY. LOWER WISHBONE COMPLETE RH	TATA spare parts
284532100125	ASSY FRONT ARB WITH BEARING	TATA spare parts
284532100136	TOP CUP ASSY WITH BEARING	TATA spare parts
284532100137	SPACER ASSY	TATA spare parts
284532100138	TOP MOUNT ASSY	TATA spare parts
284532100149	DUAL PATH STRUT ASSY LH	TATA spare parts
284532100151	DUAL PATH STRUT ASSY RH	TATA spare parts
284532103105	BEARING ASSY	TATA spare parts
284532103701	LOWER WISHBONE FRONT LH	TATA spare parts
284532103702	LOWER WISHBONE FRONT RH	TATA spare parts
284532103703	LOWER WISHBONE FRONT LH BS6	TATA spare parts
284532103704	LOWER WISHBONE FRONT RH BS6	TATA spare parts
284532104201	CLAMP ANTI ROLL BAR MTG	TATA spare parts
284532104202	CLAMP FRONT ARB MTG.	TATA spare parts
284532106502	NYLOC NUT WISHBONE MTG. M18X1.5	TATA spare parts
284532106701	PIN LOWER WISHBONE MTG FRONT	TATA spare parts
284532106702	PIN LOWER WISHBONE MTG FRONT BS2/3/4	TATA spare parts
284532106704	PIN LOWER WISHBONE MTG	TATA spare parts
284532106901	TUBE EXT LOWER WISHBONE MTG PIN	TATA spare parts
284532106903	TUBE WISHBONE MTG BS6	TATA spare parts
284532107501	BUSH LOWER WISHBONE	TATA spare parts
284532107502	BUSH ANTI ROLL BAR MTG	TATA spare parts
284532107701	BEARING BLOCK ANTI ROLL BAR FRONT	TATA spare parts
284532107703	COVER TOP CUP	TATA spare parts
284532107704	BUMP STOP FRONT	TATA spare parts
284532107706	DUST COVER FRT STRUT	TATA spare parts
284532107714	DUST COVER FRONT DUAL PATH STRUT	TATA spare parts
284532107717	RUBBER SEAT FRONT STRUT LOWER	TATA spare parts
284532108201	SPRING SEAT TOP	TATA spare parts
284532108202	CLAMP PLATE FRT ARB MTG	TATA spare parts
284532108203	TOP RETAINING CUP FRT STRUT	TATA spare parts
284532108215	SPACER TOP CUP BS6	TATA spare parts
284532108601	SPACER LOWER WISHBONE	TATA spare parts
284532108603	WASHER STAMPED	TATA spare parts
284532108604	SPACER ANTIROLL BAR MTG	TATA spare parts
284532108605	SPACER FRT STRUT TOP - 26.5L	TATA spare parts
284532108607	SPACER FRONT STRUT ASSY.	TATA spare parts
284532108612	SPACER FRONT STRUT DUAL PATH	TATA spare parts
284532108613	SPACER FRONT STRUT DUAL PATH BS6-PH2	TATA spare parts
284532108701	SPRING FRONT SUSPENSION	TATA spare parts

284532108703	SPRING FRONT SUSPENSION	TATA spare parts
284532108704	SPRING FRT SUSPENSION	TATA spare parts
284532108706	SPRING FRONT SUSPENSION	TATA spare parts
284532108709	SPRING FRONT SUSPENSION	TATA spare parts
284532108710	COIL SPRING FRONT BS6	TATA spare parts
284532108715	COIL SPRING FRONT	TATA spare parts
284532109201	WASHER 14.5X3	TATA spare parts
284532109202	WASHER 18.1 ID X 40 OD	TATA spare parts
284532109203	WASHER 18.1 ID X 50 OD	TATA spare parts
284532110102	ASSY. FRONT STRUT COMP.LH 28WB BS3/4	TATA spare parts
284532110103	ASSY. FRONT STRUT COMP. RH 28WB BS3/4	TATA spare parts
284532110104	ASSY. FRONT STRUT LH BS2/3/4	TATA spare parts
284532110105	ASSY. STRUT FRONT RH BS2/3/4	TATA spare parts
284532110106	ASSY. FRONT STRUT RH	TATA spare parts
284532110107	ASSY FRONT STRUT LH	TATA spare parts
284532110109	ASSY. FRONT STRUT COMP. LH 32WB BS4	TATA spare parts
284532110110	ASSY. FRONT STRUT COMP. RH 32WB BS4	TATA spare parts
284532110111	ASSY. STRUT FRONT COMP. LH BS3/4	TATA spare parts
284532110112	ASSY. STRUT FRONT RH BS3/4	TATA spare parts
284532110127	STRIKER CAP ASSY	TATA spare parts
284532110128	ASSY. STRUT DUAL PATH LH BS3/4	TATA spare parts
284532110129	ASSY. STRUT DUAL PATH RH BS3/4	TATA spare parts
284532110130	DAMPER ASSY FRONT STRUT LH	TATA spare parts
284532110131	DAMPER ASSY FRONT STRUT RH	TATA spare parts
284532110134	DUAL PATH STRUT ASSY LH	TATA spare parts
284532110135	DUAL PATH STRUT ASSY RH	TATA spare parts
284532400102	ASSY REAR SHACKLE	TATA spare parts
284532400103	ASSY. REAR SPRING PARABOLIC BS2/3/4	TATA spare parts
284532400105	ASSY SHACKLE WITH WELDED PINS	TATA spare parts
284532400108	ASSY REAR SPRING PARABOLIC	TATA spare parts
284532400109	ASSY FIRST LEAF WITH BUSH	TATA spare parts
284532400110	ASSY REAR SPRING PARABOLIC	TATA spare parts
284532400111	ASSY FIRST LEAF WITH BUSH	TATA spare parts
284532400114	ASSY REAR SPRING (6-8KG/MM)	TATA spare parts
284532400115	ASSY. REAR LEAF SPRING	TATA spare parts
284532400118	ASSY REAR LEAF SPRING	TATA spare parts
284532400119	ASSLY REAR LEAF SPRING	TATA spare parts
284532400121	ASSY. REAR LEAF SPRING	TATA spare parts
284532400126	ASSY FIRST LEAF WITH BUSH	TATA spare parts
284532400127	ASSY FIRST LEAF WITH BUSH	TATA spare parts
284532400129	SHACKLE ASSY REAR SPRING	TATA spare parts
284532400130	ASSY FIRST LEAF WITH BUSH	TATA spare parts
284532400132	LEAF SPRING ASSY REAR PARABOLIC	TATA spare parts
284532400133	1ST LEAF ASSY WITH BUSH	TATA spare parts
284532400134	1ST LEAF ASSY WITH BUSH	TATA spare parts
284532400135	1ST LEAF ASSY WITH BUSH	TATA spare parts
284532400136	LEAF SPRING ASSY REAR PARABOLIC	TATA spare parts

284532400137	LEAF SPRING ASSY REAR PARABOLIC	TATA spare parts
284532400138	LEAF SPRING ASSY REAR	TATA spare parts
284532401601	ASSY.REAR SPRING PARABOLIC	TATA spare parts
284532403401	SPRING BUSH	TATA spare parts
284532403402	SPRING BUSH	TATA spare parts
284532403701	SUPPORT REAR SHACKLE	TATA spare parts
284532403702	SUPPORT REAR SHACKLE	TATA spare parts
284532406703	SPRING PIN FRONT	TATA spare parts
284532406704	PIN SPRING MTG REAR	TATA spare parts
284532407103	GUIDE PLATE REAR SPRING	TATA spare parts
284532407104	1ST LEAF BS6	TATA spare parts
284532407105	SECOND LEAF	TATA spare parts
284532407105DF	SECOND LEAF REAR - WINGER BS3/4	TATA spare parts
284532407106	1ST LEAF BS6	TATA spare parts
284532407107	SECOND LEAF	TATA spare parts
284532407110	THIRD LEAF	TATA spare parts
284532407111	FIRST LEAF	TATA spare parts
284532407112	SECOND LEAF	TATA spare parts
284532407114	SECOND LEAF	TATA spare parts
284532407116	SECOND LEAF	TATA spare parts
284532407117	THIRD LEAF	TATA spare parts
284532407502	BUSH SPRING PIN REAR	TATA spare parts
284532407701	TOP COVER REAR SHOCK ABSORBER	TATA spare parts
284532407706	RUBBER PAD	TATA spare parts
284532407707	TIP INSERT 60X60X4	TATA spare parts
284532407708	TIP INSERT 63.5X63.5X4	TATA spare parts
284532407709	TIP INSERT BS6	TATA spare parts
284532408201	SHACKLE PLATE	TATA spare parts
284532408202	PLATE SUPPORT REAR SHACKLE	TATA spare parts
284532408208	SHIM REAR SPRING MTG	TATA spare parts
284532408209	CENTRE PAD 105X60X3	TATA spare parts
284532408211	CENTRE PAD	TATA spare parts
284532408212	CLAMP RUBBERISED	TATA spare parts
284532408213	CLAMP REAR SPRING	TATA spare parts
284532408214	CLINCH CLAMP REAR SPRING	TATA spare parts
284532408215	CENTRE PAD 105X60X2	TATA spare parts
284532408217	CENTER PAD 105 X 60 X 3	TATA spare parts
284532408218	CLAMP REAR SPRING	TATA spare parts
284532408301	STRIP REAR SPRING MTG	TATA spare parts
284532409203	WASHER 12 2	TATA spare parts
284532409205	WASHER	TATA spare parts
284532500101	ASSY BUMP STOP REAR	TATA spare parts
284532500108	ASSY. BRACKET WITH SPACER BS6	TATA spare parts
284532504201	U CLAMP REAR	TATA spare parts
284532504202	U CLAMP REAR SPRING MTG.	TATA spare parts
284532600101	ASSY. SHOCK ABSORBER REAR BS2/3/4	TATA spare parts
284532600102	ASSY SHOCK ABSORBER REAR	TATA spare parts

284532600103	ASSY SHOCK ABSORBER REAR	TATA spare parts
284532606701	PIN REAR S/A MTG	TATA spare parts
284532800101	CLAMP (FRONT ARB MTG.)	TATA spare parts
284532807701	BEARING BLOCK (FRONT ARB)	TATA spare parts
284532807901	ANTI-ROLL BAR FRONT	TATA spare parts
284532807902	FRONT ANTIROLL BAR	TATA spare parts
284532900103	ASSY BUSH - REAR ARB MTG ON FRAME	TATA spare parts
284532900104	ASSY.ARB WITH BUSH MTG.ON FRAME	TATA spare parts
284532907701	BEARING BLOCK REAR ANTI ROLL BAR	TATA spare parts
284532907901	ANTI ROLL BAR REAR	TATA spare parts
284532908203	BRACKET REAR ARB MTG ON FRAME	TATA spare parts
28453300M10001	FRONT AXLE ASSY LH BS6-PH2	TATA spare parts
28453300M10002	FRONT AXLE ASSY RH BS6-PH2	TATA spare parts
284533106501	NYLOC NUT M20 X 1.5	TATA spare parts
284533106502	HEX NUT M20 X 1.5	TATA spare parts
284533106503	LOCK NUT M20X1.5	TATA spare parts
284533109201	WASHER	TATA spare parts
284533200101	ASSY FRONT AXLE LH	TATA spare parts
284533200102	ASSY FRONT AXLE RH	TATA spare parts
284533200103	ASSY. FRONT AXLE LH	TATA spare parts
284533200104	ASSY. FRONT AXLE RH	TATA spare parts
284533200109	ASSY FRONT AXLE LH WITHOUT CALIPER	TATA spare parts
284533200110	ASSY FRONT AXLE RH WITHOUT CALIPER	TATA spare parts
284533200111	ASSY. FRONT AXLE LH WITHOUT CALIPER	TATA spare parts
284533200112	ASSY. FRONT AXLE RH WITHOUT CALIPER	TATA spare parts
284533203701	STUB AXLE FRONT LH	TATA spare parts
284533203702	STUB AXLE FRONT RH	TATA spare parts
284533203703	STUB AXLE LH	TATA spare parts
284533203704	STUB AXLE RH	TATA spare parts
284533403101	BEARING FRONT HUB BS2/3/4	TATA spare parts
284533403102	FRONT HUB BEARING	TATA spare parts
284533403201	BOLT WHEEL MTG	TATA spare parts
284533403202	BOLT WHEEL MTG	TATA spare parts
284533403203	BOLT WHEEL MTG REAR	TATA spare parts
284533403204	BOLT WHEEL MTG REAR	TATA spare parts
284533403701	FRONT HUB BS2/3/4	TATA spare parts
284533403702	FRONT HUB	TATA spare parts
284533404301	INTERNAL CIRCLIP FRONT HUB	TATA spare parts
284533408601	RETAINER FRT HUB BEARING	TATA spare parts
284533990101	RETRO KIT FOR WHEEL STOPPER ON STUB AXLE	TATA spare parts
284535100101	ASSY REAR AXLE BEAM	TATA spare parts
284535100102	ASSY REAR AXLE WITH BRAKE	TATA spare parts
284535100105	ASSY REAR AXLE WITH BRAKES (FOR CNG)	TATA spare parts
284535100107	ASSY REAR AXLE - NON ABS / ABS	TATA spare parts
284535100108	REAR AXLE ASSY WITH BRAKE	TATA spare parts
284535100111	ASSY REAR AXLE WITH BRAKES	TATA spare parts
284535100113	REAR AXLE ASSY WITH BRAKE	TATA spare parts

284535100115	REAR AXLE ASSY WITH BRAKE	TATA spare parts
284535103701	REAR HUB	TATA spare parts
284535106501	REAR AXLE HUB CHECK NUT	TATA spare parts
284535106702	WHEEL BOLT	TATA spare parts
284535106902	REAR AXLE TUBE	TATA spare parts
284535108201	HUB CAP	TATA spare parts
284535108203	DEFLECTOR	TATA spare parts
284535109201	WASHER	TATA spare parts
284535109901	SPACER	TATA spare parts
284535603103	TAPER ROLLER BEARING OUTER	TATA spare parts
284535603105	TAPER ROLLER BRG. OUTER 33205 BS2/3/4	TATA spare parts
284535603106	TAPER ROLLER BRG 33207 BS2/3/4	TATA spare parts
284535603107	TAPER ROLLER BRG.OUTER	TATA spare parts
284535603108	TAPER ROLLER BRG.INNER	TATA spare parts
284535603109	TAPER ROLLER BRG.OUTER	TATA spare parts
284535603110	TAPER ROLLER BRG INNER	TATA spare parts
284535603111	TAPER ROLLER BRG.OUTER	TATA spare parts
284535603112	TAPER ROLLER BRG OUTER	TATA spare parts
284535607802	OIL SEAL BS2/3/4	TATA spare parts
284540100103	ASSY WHEEL RIM 5.5J X 14	TATA spare parts
284540100105	5 1/2 J X 14 WHEEL RIM	TATA spare parts
284540100113	ASSY WHEEL RIM 5.5J X 15	TATA spare parts
284540100114	ASSY. SPARE WHEEL MTG. BRACKET	TATA spare parts
284540100117	ASSY WHEEL RIM COVER	TATA spare parts
284540100127	WHEEL RIM COVER ASSY	TATA spare parts
284540100135	WHEEL RIM ASSY BS6	TATA spare parts
284540106501	WHEEL NUT	TATA spare parts
284540107101	SUPPORT PLATE FOR SPARE WHEEL MTG	TATA spare parts
284540108801	CENTER HOOK FOR SPARE WHEEL MTG	TATA spare parts
284540109902	BALANCE WEIGHT 10 GMS BS6	TATA spare parts
284540109903	BALANCE WEIGHT 15 GMS BS6	TATA spare parts
284540109904	BALANCE WEIGHT 20 GMS BS6	TATA spare parts
284540109905	BALANCE WEIGHT 25 GMS BS6	TATA spare parts
284540109906	BALANCE WEIGHT 30 GMS BS6	TATA spare parts
284540109907	BALANCE WEIGHT 35 GMS BS6	TATA spare parts
284540109908	BALANCE WEIGHT 40 GMS BS6	TATA spare parts
284540109909	BALANCE WEIGHT 45 GMS BS6	TATA spare parts
284540109910	BALANCE WEIGHT 50 GMS BS6	TATA spare parts
284540109911	BALANCE WEIGHT 55 GMS BS6	TATA spare parts
284540109912	BALANCE WEIGHT 60 GMS BS6	TATA spare parts
284540109913	TYRE,RIB TYPE 185 R14LT-8PR	TATA spare parts
284540109914	TUBE 185	TATA spare parts
284540109917	BALANCE WEIGHT 70 GMS BS6	TATA spare parts
284540109918	BALANCE WEIGHT 80 GMS BS6	TATA spare parts
284540109921	TUBELESS TYRE 195 R15LT-8PR(RADIAL TYRE)	TATA spare parts
284540300102	ASSY SPARE WHEEL STRUCTURE MTG	TATA spare parts
284540300103	ASSY TUBE STRUCTURE	TATA spare parts



284540306501	HEX NUT BS6	TATA spare parts
284540306701	PIN (SPARE WHEEL MTG.)	TATA spare parts
284542100105	ASSY DISC BRAKE RH	TATA spare parts
284542100106	ASSY DISC BRAKE LH	TATA spare parts
284542100108	PAD KITTWIN POT CALIPER	TATA spare parts
284542100110	CALIPER KIT MAJOR TWIN POT	TATA spare parts
284542100111	CALIPER KIT MINOR TWIN POT	TATA spare parts
284542100112	SLIDING PIN KIT TWIN POT CALIPER	TATA spare parts
284542100116	KIT-FRONT BRAKE CALIPER BS2/3/4	TATA spare parts
284542100116DF	BRAKE PAD KIT - K TYPE- WINGER BS3/4	TATA spare parts
284542100117	CALIPER ASSY FRONT-RH BS6-PH2	TATA spare parts
284542100118	CALIPER ASSY FRONT-LH BS6-PH2	TATA spare parts
284542100120	ASSY CALIPER FRONT RH	TATA spare parts
284542100121	ASSY CALIPER FRONT LH	TATA spare parts
284542100124	MINOR KIT	TATA spare parts
284542100125	GUIDE PIN KIT	TATA spare parts
284542100126	RH KIT- CARRIER SUB ASSEMBLY	TATA spare parts
284542100127	RH KIT- CALIPER SUB ASSEMBLY	TATA spare parts
284542100128	BLEEDER KIT	TATA spare parts
284542100129	MAJOR KIT	TATA spare parts
284542100130	LH KIT-CARRIER SUB ASSY	TATA spare parts
284542100131	LH KIT-CALIPER SUB ASSY	TATA spare parts
284542100132	MINOR KIT	TATA spare parts
284542100133	PINS KIT	TATA spare parts
284542100134	RH KIT CARRIER SUB ASSY	TATA spare parts
284542100135	RH KIT CALIPER SUB ASSY	TATA spare parts
284542100136	MAJOR KIT	TATA spare parts
284542100137	LH KIT CARRIER SUB ASSY	TATA spare parts
284542100138	LH KIT CALIPER SUB ASSY	TATA spare parts
284542100140	KIT FOR PAD DB8207 MFG-ROULUNDS	TATA spare parts
284542100141	KIT FOR PAD DB8127 MFG-ROULUNDS	TATA spare parts
284542103701	FRONT BRAKE DISC BS2/3/4	TATA spare parts
284542103701DF	BRAKE DISC FRONT - WINGER BS3/4	TATA spare parts
284542103702	FRONT BRAKE DISC VENTILATED	TATA spare parts
284542105401	TONER RING FRONT AND REAR	TATA spare parts
284542300103	ASSY DRUM BRAKE REAR LH	TATA spare parts
284542300104	ASSY DRUM BRAKE REAR RH	TATA spare parts
284542300106	ASSY REAR BRAKE LH C.I. W/C DIA22.2	TATA spare parts
284542300107	ASSY REAR BRAKE RH C.I. W/C DIA22.2	TATA spare parts
284542300110	BACK PLATE ASSEMBLY LH	TATA spare parts
284542300111	BACK PLATE ASSEMBLY RH	TATA spare parts
284542300115	HAND BRAKE LEVER SUB ASSEMBLY LH	TATA spare parts
284542300116	HAND BRAKE LEVER SUB ASSEMBLY RH	TATA spare parts
284542300117	ASSY. WHEEL CYL. DIA 22.22MM BS2/3/4	TATA spare parts
284542300118	AUTO ADJUSTER WITH THERMALCLIP LH KBX447	TATA spare parts
284542300119	AUTO ADJUSTER WITH THERMALCLIP RH	TATA spare parts
284542300120	KIT-BRAKE SHOE KBX 457 BS2/3/4	TATA spare parts

284542300121	WHEEL CYLINDER MAJOR KIT	TATA spare parts
284542300122	WHEEL CYLINDER MINOR KIT	TATA spare parts
284542300124	SHOE HOLD DOWN KIT	TATA spare parts
284542300132	ASSY REAR BRAKE LH	TATA spare parts
284542300133	ASSY REAR BRAKE RH	TATA spare parts
284542300138	AUTO ADJUSTER WITH THERMAL CLIP LH KIT	TATA spare parts
284542300139	AUTO ADJUSTER WITH THERMAL CLIP RH KIT	TATA spare parts
284542300140	WHEEL CYLINDER KIT - MAJOR	TATA spare parts
284542300141	WHEEL CYLINDER KIT - MINOR	TATA spare parts
284542300142	BRAKE SHOE KIT - STD	TATA spare parts
284542300143	SHOE HOLD DOWN KIT	TATA spare parts
284542300146	BRAKE DRUM ASSY REAR-LH	TATA spare parts
284542300147	BRAKE DRUM ASSY REAR-RH	TATA spare parts
284542303201	BOLT (M6 X 12)	TATA spare parts
284542303701	BRAKE DRUM REAR BS2/3/4	TATA spare parts
284542303702	BRAKE DRUM REAR	TATA spare parts
284542306701	H B L PIN	TATA spare parts
284542307201	PLUG	TATA spare parts
284542307202	PLUG	TATA spare parts
284542308002	BLEEDER SCREW	TATA spare parts
284542309201	H B L PIN SELF LOCKING WASHER	TATA spare parts
284542309202	SPRING WASHER B6	TATA spare parts
284542400101	ASSY L.S.P.V.	TATA spare parts
284542400102	ASSY BRACKET L.S.P.V. MTG	TATA spare parts
284542400103	ASSY CONTROL LINK L.S.P.V.	TATA spare parts
284542400104	ASSY BRACKET BEARING SUPPORT	TATA spare parts
284542400106	ASSY L.S.P.V.	TATA spare parts
284542400107	ASSY LSPV	TATA spare parts
284542400108	ASSY LSPV -28WB	TATA spare parts
284542400111	ASSY BRACKET(SUPPORT BEARING)	TATA spare parts
284542400114	ASSY. BRACKET TWIN L.S.P.V. MTG.	TATA spare parts
284542400117	ASSY. CONTROL LINK TWIN L.S.P.V.	TATA spare parts
284542400118	L.S.P.V ASSY.	TATA spare parts
284542400121	ASSY. BEARING SUPPORT ADAPTOR BRACKET.	TATA spare parts
284542407701	BEARING CONTROL LINK L.S.	TATA spare parts
284542407702	GUIDE BUSH	TATA spare parts
284542407703	GUIDE BUSH	TATA spare parts
284542408204	CLAMP DIAM 16	TATA spare parts
284542700102	ASSY RELEASE LEVER	TATA spare parts
284542700104	ASSY PARKING BRAKE CABLE FRONT	TATA spare parts
284542700105	ASSY PARKING BRAKE CABLE REAR	TATA spare parts
284542700106	ASSY PARKING BRAKE CABLE REAR	TATA spare parts
284542700107	ASSY BRACKET PARKING BRAKE CABLE SUPPORT	TATA spare parts
284542700110	ASSY PARKING BRAKE LEVER	TATA spare parts
284542700111	ASY PARKING BRK CABLE FRT	TATA spare parts
284542700112	ASY PARKING BRK CABLE RR RH	TATA spare parts
284542700113	ASY PARKING BRK CABLE RR LH	TATA spare parts

284542700116	ASY PARKING BRK LEVER COMPLETE	TATA spare parts
284542700119	PARKING BRAKE CABLE REAR LH	TATA spare parts
284542700120	PARKING BRAKE CABLE REAR RH	TATA spare parts
284542700121	ASSY. PARKING BRAKE LEVER	TATA spare parts
284542700125	ASSY.PARKING BRAKE LINK AND SPRING PLATE	TATA spare parts
284542700126	PARKING BRAKE CABLE REAR RH	TATA spare parts
284542700127	PARKING BRAKE CABLE REAR LH	TATA spare parts
284542700130	PARKING BRAKE CABLE FRONT	TATA spare parts
284542700131	ASSY. PARKING BRAKE LEVER	TATA spare parts
284542706501	ADJUSTING NUT	TATA spare parts
284542706702	PIN 6-13.5	TATA spare parts
284542706703	CYLINDRICAL PIN DIAM 6-17	TATA spare parts
284542706901	COIL SUPPORT PARKING CABLE BS6-PH2	TATA spare parts
284542707501	GROMMET PARKING BRAKE	TATA spare parts
284542707901	CONTROL ROD PARKING BRAKE 986L	TATA spare parts
284542707902	CONTROL ROD PARKING BRAKE 586L	TATA spare parts
284542707903	CONTROL ROD PARKING BRAKE.	TATA spare parts
284542708204	BRACKET PARKING BRAKE CABLE	TATA spare parts
284542708701	RETRIEVAL SPRING	TATA spare parts
284542800101	HYDRAULIC MODULATOR ABS 8	TATA spare parts
284542990112	KIT-CALIPER BS6-PH2	TATA spare parts
284542990117	KIT-PAD DB8207 BS3/4	TATA spare parts
284542990118	KIT FOR PAD	TATA spare parts
284543000101	ASSY. S.V. MASTER (8 +9 ) BS2/3/4	TATA spare parts
284543007701	GASKET TANDEM BOOSTER MOUNTING	TATA spare parts
284543100101	MODULATOR VALVE ABS BS6-PH2	TATA spare parts
284543100103	ASSY. TANDEM BOOSTER BS2/3/4	TATA spare parts
284543100104	TANDEM MASTER CYL. W/O RESV. BS2/3/4	TATA spare parts
284543100105	MAJOR KIT TMC	TATA spare parts
284543100106	KIT NRV	TATA spare parts
284543100107	MINOR KIT TMC	TATA spare parts
284543100110	ASSY. TWIN L.C.R.V	TATA spare parts
284543100111	BOOSTER ASSY	TATA spare parts
284543100112	S.V. MASTER ASSY. 8+9	TATA spare parts
284543100114	MINOR KIT	TATA spare parts
284543100115	MAJOR KIT	TATA spare parts
284543100119	SWITCH FLWI	TATA spare parts
284543100123	TMC ASSEMBLY (W/O RESV)	TATA spare parts
284543100124	RESERVOIR ASSEMBLY WITH FLWI	TATA spare parts
284543100125	TMC ASSEMBLY WITHOUT RESERVOIR	TATA spare parts
284543100126	TMC ASSY.WITH RESV AND FLWI	TATA spare parts
284543100127	TANDEM BOOSTER ASSEMBLY	TATA spare parts
284543100128	HYDRAULIC MODULATOR ABS	TATA spare parts
284543100133	TMC ASSY W/O RESERVIOR WITH SEAL FLUID T	TATA spare parts
284543100134	TMC ASSY WITH RESERVIOR	TATA spare parts
284543107501	GROMMET	TATA spare parts
284543200102	RESERVOIR ASSEMBLY WITH FLWI	TATA spare parts

284543207501	GROMMET RESERVOIR	TATA spare parts
284543207701	CAP RESERVOIR	TATA spare parts
284543209901	FILTER RESERVOIR	TATA spare parts
284543209902	SWITCH FLWI	TATA spare parts
284543500101	ASSY.VACUUM TANK COMPLETE.	TATA spare parts
284543500108	RESERVOIR CAP ASSY	TATA spare parts
284543500109	VACUUM PIPE ASSY.	TATA spare parts
284543500111	ASSY VACCUME HOSE	TATA spare parts
284543500112	VACUUM TANK ASSY COMPLETE	TATA spare parts
284543500113	VACUUM PIPE ASSY	TATA spare parts
284543500114	VACUUM PIPE ASSY	TATA spare parts
284543500116	VACUUM PIPE ASSY	TATA spare parts
284543500117	VACUUM PIPE ASSY	TATA spare parts
284543500121	VACUUM PIPE ASSY BS6	TATA spare parts
284543500123	VACUUM PIPE ASSY BS6	TATA spare parts
284543506909	PIPE	TATA spare parts
284543506910	PIPE	TATA spare parts
284543506911	PIPE	TATA spare parts
284543506912	PIPE	TATA spare parts
284543506913	PIPE	TATA spare parts
284543508201	BRACKET VACUUM TANK MOUNTING	TATA spare parts
284543800101	ASSY VACUUM PIPE(BOOSTER)	TATA spare parts
284543800102	ASSYTUBE-TMC SECONDARY TO CALIPER LH FRT	TATA spare parts
284543800103	ASSY TUBE-TMC SECONDARY TO FRONT RH	TATA spare parts
284543800104	ASSY TUBE FROM TMC PRIMARY TO RH	TATA spare parts
284543800105	ASSY TUBE -T CONNECTOR TO CALIPER LH FRT	TATA spare parts
284543800106	ASSY TUBE T CONNE RH TO FRONT RH	TATA spare parts
284543800107	ASSY TUBE-TMC PRIMARY TO ADAPTOR	TATA spare parts
284543800108	ASSY TUBE-ADAPTOR	TATA spare parts
284543800109	ASST TUBE - HOSE REAR TO T CONNECTOR	TATA spare parts
284543800110	ASSY TUBE-TCONNECTOR TO BRAKE REAR LH	TATA spare parts
284543800111	ASSY TUBE-T CONNECTOR TO BRAKE REAR RH	TATA spare parts
284543800112	ASSY TUBE ADAPTOR	TATA spare parts
284543800113	ASSY FLEXIBLE HOSE LEADING	TATA spare parts
284543800114	ASSY FLEXIBLE HOSE TRAILING	TATA spare parts
284543800117	FLEXIBLE BRAKE HOSE (REAR) 410MM.LONG.	TATA spare parts
284543800118	ASSY.VACUUM PIPE	TATA spare parts
284543800125	REAR BRAKE HOSE ASSY	TATA spare parts
284543800128	FRONT BRAKE HOSE ASSY.	TATA spare parts
284543800129	ASSY. BRACKET REAR HOSE MTG	TATA spare parts
284543800131	ASSY TUBE FROM TMC PRIMERY TO T CONNECTO	TATA spare parts
284543800132	ASSY TUBE FROM T CONNECTOR RH	TATA spare parts
284543800133	ASSY TUBE FROM FRONT LH ADAPTOR TO REAR	TATA spare parts
284543800134	ASSY. TUBE FROM T CONNECTOR RH TO FRONT	TATA spare parts
284543800135	ASSY TUBE FROM REAR HOSE LH TO REAR BRAK	TATA spare parts
284543800136	ASSY TUBE FROM TMC SECONDERY TO T CONNEC	TATA spare parts
284543800137	ASSY TUBE FROM T CONNECTOR TO FRONT HOSE	TATA spare parts

284543800138	ASSY TUBE FROM T CONNECTOR TO REAR ADAPT	TATA spare parts
284543800139	ASSY TUBE FROM REAR HOSE RH TO REAR BRAK	TATA spare parts
284543800142	ASSY TUBE FROM ADAPTOR 1 REAR TO TWIN LS	TATA spare parts
284543800143	ASSY TUBE FROM ADAPTOR 2 REAR TO TWIN LS	TATA spare parts
284543800144	BRAKE HOSE ASSY. REAR RH (GREEN)	TATA spare parts
284543800145	BRAKE HOSE ASSY.REAR LH (RED)	TATA spare parts
284543800146	ASSY. TUBE FROM TMC PRIMARY TO UNION 1	TATA spare parts
284543800148	ASSY .TUBE FROM ABS ECU-RL TO REAR ADAPT	TATA spare parts
284543800149	ASSY. TUBE FROM ADAPTOR 6 TO FRONT RH HO	TATA spare parts
284543800150	ASSY .TUBE FROM ABS ECU-RR TO REAR ADAPT	TATA spare parts
284543800151	ASSY. TUBE FROM ADAPTOR 3 TO FRONT LH HO	TATA spare parts
284543800152	TUBE ASSY ADAPTER TO REAR ADAPTOR	TATA spare parts
284543800153	ASSY. TUBE FROM ABS ECU-FR TO FRONT ADAP	TATA spare parts
284543800154	TUBE ASSY ADAPTER TO REAR ADAPTOR	TATA spare parts
284543800155	ASSY. TUBE FROM ABS ECU-FL TO FRONT ADAP	TATA spare parts
284543800157	ASSY. TUBE FROM UNION 2 TO ABS ECU-MC1	TATA spare parts
284543800158	ASSY. TUBE FROM UNION 1 TO ABS ECU-MC2	TATA spare parts
284543800159	ASSY. TUBE FROM TMC SECONDARY TO UNION 2	TATA spare parts
284543800162	TUBE ASSY ADAPTER TO REAR ADAPTOR	TATA spare parts
284543800163	TUBE ASSY ADAPTER TO REAR ADAPTOR	TATA spare parts
284543800165	ASSY FROM TMC SECONDRY TO FRONT LH TRALI	TATA spare parts
284543800166	ASSY BRAKE TUBE FROM TMC PRIMERY TO ADAP	TATA spare parts
284543800167	TUBE ASSY ADAPTER TO REAR HOSE MTG BKT	TATA spare parts
284543800168	TUBE ASSY ADAPTER TO REAR ADAPTOR	TATA spare parts
284543800169	ASSY BRAKE TUBE FROM RH T CONN. TO FRONT	TATA spare parts
284543800173	ASSY BRK TUBE FROM `T` CONN. RH TO ADAPT	TATA spare parts
284543800174	ASSY BRAKE TUBE FROM TMC SECONDARY TO `T`	TATA spare parts
284543800176	ASSY. COVER ABS MODULATOR	TATA spare parts
284543803301	BRACKET REAR HOSE MTG	TATA spare parts
284543803304	BRACKET BS6-PH2	TATA spare parts
284543806802	THREE WAY UNION	TATA spare parts
284543807701	CLIP 3 BUNDY TUBE SUPPORT	TATA spare parts
284543807702	FLEXIBLE BRAKE HOSE FRONT	TATA spare parts
284543807704	FLEXIBLE BRAKE HOSE REAR LH	TATA spare parts
284543807705	CLIP 2 BUNDY TUBE SUPPORT	TATA spare parts
284543807706	CLIP 1 BUNDY TUBE SUPPORT	TATA spare parts
284543807707	FLEXIBLE BRAKE HOSE (REAR) 410MM.LONG.	TATA spare parts
284543808202	CLAMP FLEXIBLE HOSE SUPPORT	TATA spare parts
284543808206	BRACKET ABS ECU MODULATOR	TATA spare parts
284543808218	BRACKET RH FR. WSS CABLE MTG	TATA spare parts
284543808219	BRACKET LH FR WSS CABLE MTG	TATA spare parts
284543808220	BRACKET REAR WSS CABLE MTG	TATA spare parts
284543808221	BRACKET REAR SENSOR CABLE MTG.	TATA spare parts
284543808222	BRACKET WSS CABLE MTG	TATA spare parts
284543810101	TUBE ASSY RR ADAPTER TO RR HOSE MTG BKT	TATA spare parts
284543810102	TUBE ASSY RR ADAPTER TO RR HOSE MTG BKT	TATA spare parts
284543810109	TUBE ASSY FRONT ADAPTER TO REAR ADAPTER	TATA spare parts

284543810110	TUBE ASSY T-CONN TO ADAPTER	TATA spare parts
284543810111	TUBE ASSY PRIMARY OUT TO ADAPTER BS6	TATA spare parts
284543810112	TUBE ASSY TMC SECONDARY TO MV BS6	TATA spare parts
284543810121	TUBE ASSY TMC SECONDARY TO T-CONN	TATA spare parts
284543810123	TUBE ASSY T-CONN TO ADAPTER LH	TATA spare parts
284543810124	TUBE ASSY MODULATOR TO REAR-RH	TATA spare parts
284543810125	TUBE ASSY MODULATOR TO REAR-LH	TATA spare parts
284543810126	TUBE ASSY MODULATOR TO FRONT-RH	TATA spare parts
284543810127	TUBE ASSY MODULATOR TO FRONT-LH	TATA spare parts
284543810128	TUBE ASSY MODULATOR TO ADAPTER	TATA spare parts
284543810129	TUBE ASSY MODULATOR TO ADAPTER	TATA spare parts
284543990101	BOOSTER NOAH - AA KIT	TATA spare parts
284543990102	TMC8 + RSV - AA KIT	TATA spare parts
284543990104	TMC8 ASSLY W/O RESV-AA KIT	TATA spare parts
284543990106	RESERVOR AA KIT	TATA spare parts
284543996501	NUT DOCKING	TATA spare parts
284543997501	GROMMET	TATA spare parts
284543997801	O-RING	TATA spare parts
284543998001	RESERVOIR FIXATION SCREW	TATA spare parts
284546100101	ASSY.STEERING COLUMN	TATA spare parts
284546100102	ASSY. STG. SUPPORT BKT. UPPER	TATA spare parts
284546100104	ASSY.STEERING MTG.BRACKET LOWER(RHD)	TATA spare parts
284546105301	GASKET	TATA spare parts
284546106701	PIN	TATA spare parts
284546200101	BEARING ASSY. INTERMEDIATE	TATA spare parts
284546200102	ASSY PROTECTION COVER	TATA spare parts
284546206302	DUST COVER	TATA spare parts
284546207501	RUBBER BUSH	TATA spare parts
284546207701	PROTECTION LHS LE PROFILE	TATA spare parts
284546207702	PROTECTION RHS LE PROFILE	TATA spare parts
284546400101	STEERING WHEEL.(O.D. 426MM)	TATA spare parts
284546400102	ASSY STG. WHEEL	TATA spare parts
284546400103	ASSY.STG WHEEL (COL.BEIGE)	TATA spare parts
284546400105	ASSY.STEERING WHEEL WINGER M1	TATA spare parts
284546600101	RACK & PINION GEAR (OFFER DRG.) BS2/3/4	TATA spare parts
284546600104	ASSY. OUTER BALL JOINT BS2/3/4	TATA spare parts
284546600105	FEED PIPE ASSY - SHORT	TATA spare parts
284546600106	FEED PIPE ASSY - LONG	TATA spare parts
284546600107	INNER BALL JOINT ASSY	TATA spare parts
284546600108	ASSY OF BELLOW KIT	TATA spare parts
284546600109	ASSY OF IBJ & BELLOW KIT	TATA spare parts
284546600110	ASSY OF MOUNTING KIT - WINGER	TATA spare parts
284546600111	BELLOW KIT	TATA spare parts
284546600112	KIT-IBJ & BELLOW BS2/3/4	TATA spare parts
284546600113	MOUNTING KIT ASSY	TATA spare parts
284546600116	POWER STEERING RESERVOIR ASSY.	TATA spare parts
284546600117	CAP ASSY	TATA spare parts

284546600119	BRACKET ASSY	TATA spare parts
284546600120	BELLOW KIT	TATA spare parts
284546600122	INNER BALL JOINT ASSY - WINGER 15+D	TATA spare parts
284546600123	POWER STEERING PUMP ASSY	TATA spare parts
284546600124	RACK & PINION ASSY POWER STG	TATA spare parts
284546600125	FEED PIPE ASSY SHORT	TATA spare parts
284546600126	FEED PIPE ASSY LONG	TATA spare parts
284546600127	POWER STEERING PUMP ASSY BS6	TATA spare parts
284546603203	BOLT M8X1.25X25LGR8.8 PLATING	TATA spare parts
284546603301	P/STG.RESERVOIR MTG BKT	TATA spare parts
284546604204	RUBBER CLAMP	TATA spare parts
284546606501	IBJ NUT	TATA spare parts
284546606502	NUT M8	TATA spare parts
284546606801	CONNECTOR PRESSURE PORT BS6	TATA spare parts
284546607708	CAP DUST	TATA spare parts
284546800101	SUPPORT ASSY. POWER STG. TUBES	TATA spare parts
284546800103	ASSY. HIGH PR. HOSE COMPLETE.	TATA spare parts
284546800104	ASSY. LOW PR. HOSE.	TATA spare parts
284546800105	SUPPORT ASSY. TUBING	TATA spare parts
284546800108	ASSY. HIGH PRESSURE FEEDING BS2/3/4	TATA spare parts
284546800110	ASSY HIGHPRESSURE FEEDING FOR CNG	TATA spare parts
284546800111	ASSY COOLING LOOP (WINGER ST AMBULANCE)	TATA spare parts
284546800112	ASSY RETURN LINE (WINGER ST AMBULANCE)	TATA spare parts
284546800113	ASSY HOSE (RESERVOIR END)	TATA spare parts
284546800115	ASSY.SUCTION LINE (RESERVOIR TO PUMP)	TATA spare parts
284546800117	ASSY.RETURN LINE II(RAP TO RESERVOIR)	TATA spare parts
284546800118	ASSY.RETURN LINE III(RESERVOIR END)	TATA spare parts
284546800120	ASSY.SUCTION LINE MTG.BRACKET	TATA spare parts
284546800123	HIGH PRESSURE LINE ASSY BS6	TATA spare parts
284546800124	RETURN LINE ASSY BS6	TATA spare parts
284546800125	ASSY.HIGH PRESSURE LINE(BSIV)	TATA spare parts
284546800126	SUCTION HOSE ASSY RESERVOIR TO PUMP BS6	TATA spare parts
284546800127	ASSY.SUPPORT BRACKET	TATA spare parts
284546800128	SUPPORT BRACKET REAR	TATA spare parts
284546800132	ASSY.COOLING LOOP(BSIV)	TATA spare parts
284546800140	HIGH PRESSURE LINE ASSY	TATA spare parts
284546804202	CLAMP 18+ RUBBER	TATA spare parts
284546805801	HOSE (PUMP TO RESEVIOR)	TATA spare parts
284546805804	RETURN HOSE BS6	TATA spare parts
284546808207	RESERVOIR MTG.BRACKET	TATA spare parts
284546808211	BRACKET POWER STG BS6	TATA spare parts
284546990101	KIT-MOUNTING BRACKET ASSY	TATA spare parts
284546990104	KIT-HOUSING ASSY BS6	TATA spare parts
284547100101	ASSY. FUEL TANK COMPLETE WITH HOSE	TATA spare parts
284547100104	FILLER NECK ASSY WITH BRACKET BS6	TATA spare parts
284547100105	ASSY SUCTION TUBE	TATA spare parts
284547100106	ASSY FILLER NECK TOP WITH BRACKET	TATA spare parts

284547100107	ASSY. CAP FUEL TANK (CHAIN-KEY) BS1- 4	TATA spare parts
284547100111	FUEL TANK ASSY BS6-PH2	TATA spare parts
284547100112	FUEL TANK CAP	TATA spare parts
284547100113	ASSY FUEL TANK COMPLETE	TATA spare parts
284547107702	GROMMET FUEL FILLER NECK BS6	TATA spare parts
284547107703	BREATHER HOSE PIPE	TATA spare parts
284547107705	GROMMET FUEL TANK PIPE	TATA spare parts
284547109908	CNG CYLINDER(85L)	TATA spare parts
284547109909	CNG CYLINDER(78L)	TATA spare parts
284547500101	ASSY. STRAP	TATA spare parts
284547500102	ASSY .STRAPPER HOOK	TATA spare parts
284547500114	STRAP ASSY & RUBBER FUEL TANK MTG BS6-PH	TATA spare parts
284547500115	STRAP ASSY & RUBBER FUEL TANK MTG BS6-PH	TATA spare parts
284547500135	ASSY CYLINDER MTG BASE	TATA spare parts
284547500136	ASSY CYL MTG STRAP	TATA spare parts
284547500137	ASSY LOCKING STRAP	TATA spare parts
284547500156	ASSY.BASE PLATE CYLINDER MTG.	TATA spare parts
284547500158	ASSY BRACKET RECEPTACLE MTG.	TATA spare parts
284547500161	ASSY BRACKET - HPR	TATA spare parts
284547500163	ASSY. STRAP	TATA spare parts
284547500166	ASSY.BRACKET FOR SLOW FILLING RECEPTACLE	TATA spare parts
284547500167	ASSY BRACKET FOR FUEL LINE MTG.	TATA spare parts
284547500168	ASSY BRACKET FOR PRE FILTER MOUNTING	TATA spare parts
284547503302	BRACKET BS6	TATA spare parts
284547503303	BRACKET FUEL FILTER MTG BS6	TATA spare parts
284547504201	RUBBER CLAMP-10DIA	TATA spare parts
284547506701	PIN WITH HOLE	TATA spare parts
284547506702	PIN WITH THREADED HOLE	TATA spare parts
284547507701	RUBBER PACKING (STRAPPER)	TATA spare parts
284547507702	RUBBER PACKING (FRONT)	TATA spare parts
284547507703	RUBBER PACKING (REAR)	TATA spare parts
284547507704	HOSE (FUEL FILLING)	TATA spare parts
284547507705	RUBBER WASHER	TATA spare parts
284547507706	GROMMET	TATA spare parts
284547507707	GROMMET RELEASE FOR FUEL FILLER NECK	TATA spare parts
284547508210	BRACKET(FUEL LINE MTG)	TATA spare parts
284547508211	SEDIMENTOR MTG BKT	TATA spare parts
284547508212	PRIMING PUMP MTG BKT	TATA spare parts
284547508213	FILTER MTG BKT	TATA spare parts
284547508214	BRACKET (FOR FUEL LINE CLAMPING)	TATA spare parts
284547508216	STONE GUARD BS6-PH2	TATA spare parts
284547508246	BASE PLATE CYLINDER MTG	TATA spare parts
284547508247	H P FILTER BRACKET	TATA spare parts
284547508256	BRACKET ASSY CLAMP MTG	TATA spare parts
284547508277	GUARD (HPR)	TATA spare parts
284547509201	WASHER(CYLINDER MTG BKT)	TATA spare parts
284547509901	COMPLIANCE PLATE	TATA spare parts



284547509902	RECEPTACLE CAP	TATA spare parts
284547600101	ASSY.VALVE	TATA spare parts
284547600103	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
284547600104	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
284547600105	RETURN FUEL PIPE ASSY BS6	TATA spare parts
284547600106	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
284547600108	ASSY FUEL LINE	TATA spare parts
284547600109	ASSY. RETURN LINE	TATA spare parts
284547600110	ASSY RETURN LINE (FOR TC)	TATA spare parts
284547600111	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
284547600112	ASSY.VENT TUBE I(FROM REGULATOR END)	TATA spare parts
284547600119	RETURN FUEL PIPE ASSY BS6	TATA spare parts
284547600122	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
284547600124	FUEL RETURN PIPE ASSY BS6	TATA spare parts
284547600125	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
284547600135	ASSY.HIGH PRESS.TUBEIII(CYL.TO CROSS)	TATA spare parts
284547600139	ASSY.HIGH PRESS.TUBE IV(CYL.TO CROSS)	TATA spare parts
284547600140	ASSY.HIGH PRESS.TUBE(2WAY VALVE-CROSS)	TATA spare parts
284547600145	ASSY.HIGH PRESS.TUBE (PR.GAUGE TO CROSS)	TATA spare parts
284547600147	ASSY.HIGH PRESS.TUBE(RECEP.TO CROSS)	TATA spare parts
284547600148	ASSY.VENT TUBE II (FROM REGULATOR)	TATA spare parts
284547600150	ASSY.HIGH PRESS.TUBEII(FRT CYL.TO CROSS)	TATA spare parts
284547600151	ASSY.HIGH PRESS.TUBEII(FILTER TO REGULAT	TATA spare parts
284547600152	ASSY HIGH PRESSURE TUBE I(FRT.CYL-CROSS)	TATA spare parts
284547600153	ASSY.HIGH PRESS.TUBE(CYL.I TO CYL.II)	TATA spare parts
284547600157	ASSY H P TUBE(2 WAY VAVLE TO H P FILTER)	TATA spare parts
284547600158	ASSY. LOW PRESS.HOSE	TATA spare parts
284547600178	ASSY.HIGH PRESS.TUBE(RECEPTACLE TO CROSS	TATA spare parts
284547600179	ASSY.HIGH PRESS.TUBE(GAUGE TO CROSS)	TATA spare parts
284547600182	ASSY SUCTION LINE TANK TO SEDIMENTOR	TATA spare parts
284547600183	ASSY SUCTION LINE PRE FILTER TO PRIM PUM	TATA spare parts
284547600184	ASSY SUCTION LINE PRIMING PUMP TO FILTER	TATA spare parts
284547600185	ASSY SUCTION LINE FILTER TO FIP	TATA spare parts
284547600186	ASSY RETURN LINE	TATA spare parts
284547600187	ASSY SUCTION LINE FIREWALL TO PRIMING	TATA spare parts
284547600188	FUEL RETURN LINE ASSY FIP TO COOL LOOP	TATA spare parts
284547600189	FUEL RETURN LINE ASSY COOL LOOP TO TANK	TATA spare parts
284547600190	FUEL RETURN LINE ASSY COOLING LOOP	TATA spare parts
284547600192	FUEL RETURN LINE ASSY	TATA spare parts
284547603301	BRACKET	TATA spare parts
284547604201	SINGLE TUBE CLAMP 1/4IN (TOP PLATE)	TATA spare parts
284547605807	HEATING LINE (ENGINE TO REGULATOR)	TATA spare parts
284547605808	HEATING LINE (REGULATOR TO ENGINE)	TATA spare parts
284547605809	HEATING LINE (ENG TO REGULATOR)	TATA spare parts
284547605810	HEATING LINE (REGULATOR TO ENG)	TATA spare parts
284547605812	RUBBER HOSE (PRE FILTER TO ASSY. PRIMING	TATA spare parts
284547605813	RUBBER HOSE (ASSY. PRIMING PUMP TO FILTE	TATA spare parts

284547605820	FUEL FILLING HOSE BS6	TATA spare parts
284547605823	FUEL HOSE BS6	TATA spare parts
284547605825	FUEL FILLER HOSE BS6-PH2	TATA spare parts
284547605831	BREATHER HOSE BS6-PH2	TATA spare parts
284547606801	CORRUGATED HOSE(30-70MM)	TATA spare parts
284547606802	UNION CROSS 1/4 IN OD	TATA spare parts
284547606803	BULKHEAD FEMALE CONNECTOR 1/4 IN OD	TATA spare parts
284547609001	TWO WAY ISOLATION VALVE 1/4 OD	TATA spare parts
284547610101	AUTOMATIC CYL VALVE(MOON)(M/S GREEN FUEL	TATA spare parts
284547610102	AUTOMATIC VENTED VALVE(GREENFUEL)	TATA spare parts
284547700101	H P REGULATOR ASSY	TATA spare parts
284547700102	HP REGULATOR ASSEMBLY (CLASS 1)	TATA spare parts
284547701601	OFFER DRAWING HP REGULATOR	TATA spare parts
284547709001	RECEPTACLE 1/4 IN OD	TATA spare parts
284547709002	SLOW FILLING RECEPTACLE	TATA spare parts
284547709901	HIGHPRESSURE GAUGE 50MM DIAL	TATA spare parts
284547709902	NIPPLE	TATA spare parts
284547900101	ASSY. CLAMP( VENT TUBE)	TATA spare parts
284549100101	ASSY. FRONT PIPE I NABS-II (WB 2800)	TATA spare parts
284549100102	ASSY FRONT PIPE 4DLNA BS III	TATA spare parts
284549100104	ASSY. FRONT PIPE	TATA spare parts
284549100105	ASSY. MID PIPE I	TATA spare parts
284549100106	ASSY. MID PIPE II	TATA spare parts
284549100109	ASSY. EXHAUST MID PIPE I	TATA spare parts
284549100110	ASSY. MID PIPE II	TATA spare parts
284549100113	ASSY. REAR PIPE	TATA spare parts
284549100114	ASSY. REAR PIPE	TATA spare parts
284549100118	ASSY SILENCER	TATA spare parts
284549100120	ASSY SILENCER COMPLETE	TATA spare parts
284549100121	ASSY SILENCER COMPLETE	TATA spare parts
284549100122	ASSY SILENCER COMPLETE	TATA spare parts
284549100123	ASSY. FRONT PIPE II	TATA spare parts
284549100125	ASSY CAT CON	TATA spare parts
284549100129	ASSY CAT CON. WITH HEAT SHIELD (NA BSIII	TATA spare parts
284549100142	ASSY. FRONT PIPE (CNG EXHAUST)	TATA spare parts
284549100145	ASSY MID PIPE I (CNG EXHAUST)	TATA spare parts
284549100146	ASSY MID PIPE II (CNG EXHAUST)	TATA spare parts
284549100147	ASSY. REAR PIPE (CNG EXHAUST)	TATA spare parts
284549100148	ASSY SILENCER COMPLETE	TATA spare parts
284549100150	ASSY. SILENCER COMPLETE	TATA spare parts
284549100152	ASSY MID PIPE II	TATA spare parts
284549100153	ASSY REAR PIPE TC BSIII	TATA spare parts
284549100156	ASSY MID PIPE II	TATA spare parts
284549100159	ASSY FRONT PIPE I (WINGER BSIV M1 28 & 3	TATA spare parts
284549100161	ASSY MID PIPE II (WINGER BSIV 32WB )	TATA spare parts
284549100168	ASSY.CAT.CON WITH HEAT SHIELD	TATA spare parts
284549100169	ASSEMBLY MID PIPE 1 (WINGER TC 32WB BSIV	TATA spare parts

284549100171	ASSEMBLY TAIL PIPE (WINGER TC 32WB BSIV)	TATA spare parts
284549100172	ASSY. FRONT PIPE (CNG BS IV)	TATA spare parts
284549100173	ASSY. MID PIPE I (CNG BSIV)	TATA spare parts
284549100176	ASSY FRONT PIPE (WINGER TC 32WB BSIV)	TATA spare parts
284549100183	ASSY SILENCER	TATA spare parts
284549100185	ASSY MID PIPE I (28 WB BSIV)	TATA spare parts
284549100192	ASSY EXHAUST TAIL PIPE (STR WINGER BS-IV	TATA spare parts
284549100199	ASSY MID PIPE II (WINGER BSIV 28 & M1 WB	TATA spare parts
284549100201	ASSY OF MID PIPE FOR STRETCH AMBULANCE	TATA spare parts
284549100202	ASSY OF SILENCER FOR ST AMBULANCE	TATA spare parts
284549100203	ASSY SILENCER WITH HOOKS FOR WINGER 2.2L	TATA spare parts
284549100204	PIPE ASSY MIDDLE	TATA spare parts
284549100207	ASSY WINGER BOTTOM NOISE SHIELD WELDED 2	TATA spare parts
284549100208	ASSY OF TAIL PIPE (WINGER BSIV 28 & 32WB	TATA spare parts
284549100211	ASSY MID PIPE I (WINGER BSIV M1 28 & 32W	TATA spare parts
284549100223	ASSY FRONT PIPE I(WINGER 4DLTC BS4 32WB)	TATA spare parts
284549100228	INSULATION ASSY	TATA spare parts
284549100229	INSULATION ASSY	TATA spare parts
284549100230	INSULATION ASSY	TATA spare parts
284549101601	ASSY. SILENCER COMPLETE	TATA spare parts
284549106302	BOTTOM NOISE SHIELD	TATA spare parts
284549200106	PIPE ASSY MIDDLE	TATA spare parts
284549200107	PIPE ASSY TAIL	TATA spare parts
284549200111	SILENCER ASSY	TATA spare parts
284549200112	PIPE ASSY MIDDLE	TATA spare parts
284549200113	PIPE ASSY MIDDLE	TATA spare parts
284549200114	PIPE ASSY MIDDLE	TATA spare parts
284549200118	FRONT PIPE ASSY	TATA spare parts
284549200120	FRONT PIPE ASSY BS6	TATA spare parts
284549200121	PIPE ASSY MIDDLE BS6	TATA spare parts
284549200128	PIPE ASSY MIDDLE BS6	TATA spare parts
284549200141	TAIL PIPE ASSY BS6	TATA spare parts
284549200176	PIPE ASSY UREA SUPPLY BS6-PH2	TATA spare parts
284549200190	TAIL PIPE ASSY BS6	TATA spare parts
284549200192	EXHAUST PIPE ASSY INTERMEDIATE BS6	TATA spare parts
284549200201	ASSY OF HOOK	TATA spare parts
284549205801	HOSE BS6-PH2	TATA spare parts
284549205802	HOSE BS6-PH2	TATA spare parts
284549207726	STONE GUARD BS6-PH2	TATA spare parts
284549207801	O-RING BS6-PH2	TATA spare parts
284549208202	HEAT SHIELD FOR CATCON	TATA spare parts
284549210102	EXHAUST PIPE ASSY INTERMEDIATE BS6	TATA spare parts
284549210108	PIPE ASSY WITH BELLOW FRONT BS6-PH2	TATA spare parts
284549210112	BRACKET ASSY BS6-PH2	TATA spare parts
284549210113	BRACKET ASSY BS6-PH2	TATA spare parts
284549210123	UREA TANK ASSY BS6-PH2	TATA spare parts
284554100109	ASSY.BATTERY CABLE	TATA spare parts

284554100110	ASSY.BATTERY CABLE	TATA spare parts
284554100112	ASSY.EARTHING CABLE - TATA MINI BUS	TATA spare parts
284554100113	ASSY.BATTERY TRAY	TATA spare parts
284554100118	BATT CABLE -VE STR.WINGER AMB.	TATA spare parts
284554100125	ASSY.AUXILLARY BATTERY TRAY	TATA spare parts
284554100132	ASSY BATTERY CABLE +VE	TATA spare parts
284554100133	ASSY BRACKET-BATTERY CABLE (ON LONG MEMB	TATA spare parts
284554100134	ASSY BRACKET BATTERY CABLE CLAMPING	TATA spare parts
284554100137	ASSY BATTERY CABLE +VE CLAMPING BRACKET	TATA spare parts
284554100152	BATTERY CABLE + VE (BATT TO CUT-OFF SW)	TATA spare parts
284554100153	BATTERY CABLE FROM BATTERY CUT OFF SWIT	TATA spare parts
284554100154	BATTERY CABLE	TATA spare parts
284554100156	BRACKET ASSY BATTERY MTG BS6-PH2	TATA spare parts
284554108216	BATTERY CABLE +VE HOLDING BRACKET	TATA spare parts
284554200102	TANK UNIT - TATA MINI BUS	TATA spare parts
284554200105	INSTRUMENT CLUSTER	TATA spare parts
284554200106	KIT-ASSY.W/SHIELD WASHER	TATA spare parts
284554200107	ASSY.FILLER NECK WITH CAP-MINIBUS	TATA spare parts
284554200108	NOZZLE ASSY - TATA MINI BUS	TATA spare parts
284554200110	ASSY.MTG.BRACKET(ECU MTG.)-TATA MINI BUS	TATA spare parts
284554200112	ASSY.SUPPORT(ASSY.BASE PLATE) MINI BUS	TATA spare parts
284554200116	ASSY.BRACKET(A-ECU MTG.)TATA MINI BUS	TATA spare parts
284554200118	INST.CLUSTER-0.61-WHITE ILLU.	TATA spare parts
284554200119	INST.CLUSTER-0.57-WHITE ILLU.	TATA spare parts
284554200121	ASSY.BRACKET(TUBE LT.MTG)-AMBULANCE-WNG	TATA spare parts
284554200122	ASSY.MTG.BRACKET(FAN MTG)-AMBULANCE-WN	TATA spare parts
284554200125	RETRO.KIT FOR FITMENT OF MAXI FUSE-WNG	TATA spare parts
284554200129	INST CLUST CNG-14INTYRE 0.57RATIO WINGER	TATA spare parts
284554200130	INST CLUST ST.AMB TC15INTYRE 0.53 RATIO	TATA spare parts
284554200134	INST CLUSTER WINGER M1 CLASS	TATA spare parts
284554200136	RETRO KIT FOR 5 POLE-WINGER	TATA spare parts
284554200137	ASSY.MAXIFUSE & BATT.CLAMPING BRACKET	TATA spare parts
284554200139	6 POLE MAXIFUSE MTG BKT	TATA spare parts
284554200143	INSTRUMENT CLUSTER 4DL TCIC BS-IV 14 TYR	TATA spare parts
284554200145	INST CLUSTER WINGER M1 CLASS BSIV	TATA spare parts
284554200148	ASSY WASHER BOTTLE MTG BKT BSIV	TATA spare parts
284554200150	ASSY ECU MTG BKT- WINGER BSIV	TATA spare parts
284554200151	ASSY FILLER NECK MTG BKT	TATA spare parts
284554200152	INST CLUSTER M2 2.2L BS4 RATIO 2.65 STAL	TATA spare parts
284554200153	INSTRUMENT CLUSTER 2.2L BS415 ABS 2.51 (	TATA spare parts
284554200154	INST CLUSTER M2 ST AMB 2.2L BS4	TATA spare parts
284554200157	INSTRUMENT CLUSTER M1 TCIC BS-III	TATA spare parts
284554200165	ASSY.WINDSHIELD WASHER UNIT(2.2L)	TATA spare parts
284554200169	INST.CLUSTER M2 4DL NA BS-III WITHOUT AB	TATA spare parts
284554200172	INST.CLUSTER M2 4DL TCIC BS-III WITHOUT	TATA spare parts
284554200173	INST.CLUSTER M2 4DL TCIC WITHOUT ABS ST.	TATA spare parts
284554200174	INSTRUMENT CLUSTER ASSY	TATA spare parts

284554200175	INSTR CLUSTER WINGER CNG NA 10.2 CR & OB	TATA spare parts
284554201604	AMBULANCE ELECTRONIC SIREN	TATA spare parts
284554206301	FLEXIBLE PIPE - TATA MINI BUS	TATA spare parts
284554206304	BREATHER TUBE- 300MM-TATA MINI BUS (4X7	TATA spare parts
284554206305	PVC TUBE-850MM - TATA MINI BUS(4X7PVC)	TATA spare parts
284554206306	PVC TUBE-220MM - TATA MINI BUS (4X7PVC)	TATA spare parts
284554206307	PVC TUBE-700MM - TATA MINI BUS (4X7PVC)	TATA spare parts
284554206309	BREATHER TUBE 480MM	TATA spare parts
284554206310	PVC TUBE 1150MM(PUMP TO CONNECTOR)	TATA spare parts
284554208205	HORN MOUNTING BRACKET	TATA spare parts
284554208218	ECU MTG.BRACKET-LH-WINGER-CNG	TATA spare parts
284554208219	ECU MTG.BRACKET-RH-WINGER-CNG	TATA spare parts
284554208229	VEHICLE SPEED SENSOR W\H ROUTING BRACKET	TATA spare parts
284554209901	A'ECU-PANEL VAN-4DL NA BS-III	TATA spare parts
284554209902	A ECU-PANEL VAN-4DL NA BS-II-VIOLET	TATA spare parts
284554209903	A ECU-PANEL VAN-4DL WG TC BS-III-YELLOW	TATA spare parts
284554209905	AECU PANEL VAN	TATA spare parts
284554209908	ELCTRO.SPEED SENSOR 12/24V(8 PULSES)	TATA spare parts
284554209910	SIREN-FOR AMBULANCE	TATA spare parts
284554209912	FRONT WHEEL SENSOR	TATA spare parts
284554209913	REAR WHEEL SPEED SENSOR [M2 ABS]-WINGER	TATA spare parts
284554209917	A-ECU TCIC BSIV OBD-II	TATA spare parts
284554209918	A ECU PANEL VAN [BS-IV TCIC]	TATA spare parts
284554209925	DUAL TEMP SENSOR WINGER	TATA spare parts
284554300101	HORN STROBE	TATA spare parts
284554400101	ASSY.TAIL LAMP-LH-W/FOG-MINI BUS	TATA spare parts
284554400106	ASSY.TAIL LAMP-RH-W/FOG-MINI BUS	TATA spare parts
284554400116	ASSY. HEAD LAMP RH 12V RHD BS2/3/4	TATA spare parts
284554400117	ASSY. HEAD LAMP LH 12V RHD BS2/3/4	TATA spare parts
284554400118	ASSY.TAIL LAMP-LH	TATA spare parts
284554400119	ASSY.TAIL LAMP-RH-W/FOG-L	TATA spare parts
284554400120	ASSY.FRONT BLINKER-LH	TATA spare parts
284554400121	ASSY.FRONT BLINKER-RH	TATA spare parts
284554400123	REAR REGI.PLATE LAMP	TATA spare parts
284554400124	ASSY.ROOF LAMP-CENTRE-GREY-WINGER	TATA spare parts
284554400125	ASSY.ROOF LAMP-SIDE-ELECT	TATA spare parts
284554400126	ASSY_FRONT_FOG_LAMP_LH	TATA spare parts
284554400127	ASSY_FRONT_FOG_LAMP_RH	TATA spare parts
284554400128	ASSY.SIDE REPEATER LAMP-ELECTRICA	TATA spare parts
284554400129	ASSY.ENGINE LAMP - TATA MINI BUS	TATA spare parts
284554400130	ASSY.ROOF LAMP(MIDDLE)-MINI BUS	TATA spare parts
284554400131	ASSY.ROOF LAMP-CENTRE-BEIGE-WINGER	TATA spare parts
284554400135	ASSY.BUSH (H/L.MTG.ADJ)-MINI BUS	TATA spare parts
284554400136	HIGH MOUNTED STOP LAMP	TATA spare parts
284554400173	ASSY TUBELIGHT	TATA spare parts
284554401601	ASSY.BUSH(H/L.MTG.ADJ)	TATA spare parts
284554401608	ASSY.BUSH (H/L.MTG.ADJ)-MINI BUS	TATA spare parts

284554401610	ASSY.ROOF LAMP-CENTRE-BEIGE-WINGER	TATA spare parts
284554406301	RUBBER BUFFER(FOR H/R REV.LAMP)WIN.AMB.	TATA spare parts
284554409903	ASSY.DUMMY BLINKER - LH	TATA spare parts
284554409904	ASSY.DUMMY BLINKER-RH	TATA spare parts
284554409905	BATT.CHARG INDICATOR TATA WING STR AMB.	TATA spare parts
284554500108	REVERSE LIGHT SW.-TATA MINI BUS	TATA spare parts
284554500110	ASSY. COMBI SWITCH-PANEL VAN BS2/3/4	TATA spare parts
284554500111	HAZARD WARNING SWITCH-MINI BUS	TATA spare parts
284554500112	HEAD LAMP LEVEL.SW.(GREY)-WINGER	TATA spare parts
284554500113	ASSY.DOOR SWITCH(11.5MM)-MINIBUS	TATA spare parts
284554500114	ASSY.DOOR SWITCH(15.0MM)	TATA spare parts
284554500117	ROOF LAMP SWITCH-TATA MINI BUS	TATA spare parts
284554500118	HEAD LAMP LEVEL.SW.(BEIGE)-WINGER	TATA spare parts
284554500119	SWITCH-REVOLVING LAMP-AMBULANCE-WINGER	TATA spare parts
284554500120	SWITCH-FOR SIREN-AMBULANCE-WINGER	TATA spare parts
284554500121	SWITCH-FOR FANS-AMBULANCE-WINGER	TATA spare parts
284554500122	ENGINE CUT OFF SWITCH-CNG-WNG	TATA spare parts
284554500128	ASSY.DOOR SWITCH(15.0MM)	TATA spare parts
284554500129	REAR AC MASTER S/W-TATA WINGER	TATA spare parts
284554500130	REAR AC MASTER SW-WINGER M2	TATA spare parts
284554500131	REAR AC SWITCH	TATA spare parts
284554500132	REVERSE LIGHT SWITCH	TATA spare parts
284554500134	HEAD LAMP LEVEL.SW.(GREY)	TATA spare parts
284554500137	ROOF LAMP SWITCH-WINGER	TATA spare parts
284554500142	ENGINE CUT OFF SWITCH-CNG-WNG	TATA spare parts
284554500143	ASSY.COMBI SWITCH	TATA spare parts
284554500145	HAZARD WARNING SWITCH	TATA spare parts
284554500154	RELAY ASSY BATTERY CUTOFF	TATA spare parts
284554500157	HEAD LAMP LEVELLING SW(GREY)	TATA spare parts
284554500158	HEAD LAMP LEVELLING SW.(BEIGE)	TATA spare parts
284554500161	REAR AC SWITCH	TATA spare parts
284554500162	SWITCH-REVOLVING LAMP-AMB-M/S FOUR FRONT	TATA spare parts
284554500163	ROOF LAMP SWITCH	TATA spare parts
284554500164	SWITCH-FOR SIREN-AMB-M/S FOUR FRONT	TATA spare parts
284554500165	SWITCH-FOR FANS-AMB-M/S FOUR FRONT	TATA spare parts
284554501601	HEAD LAMP LEVEL.SW.(GREY)-WINGER	TATA spare parts
284554501602	HAZARD WARNING SWITCH-MINI BUS	TATA spare parts
284554501603	ASSY.DOOR SWITCH(15.0MM)	TATA spare parts
284554501604	REVERSE LIGHT SWITCH-OFFER-TATA MINI BUS	TATA spare parts
284554501605	HEAD LAMP LEVEL.SW.(BEIGE)-WINGER	TATA spare parts
284554501606	ROOF LAMP SWITCH-WINGER	TATA spare parts
284554501621	DOOR SWITCH WITH GROMMET	TATA spare parts
284554501629	REAR AC MASTER SW-TATA WNG M2	TATA spare parts
284554503302	HEAD LAMP LEVELLING SWITCH-M1	TATA spare parts
284554503303	DOOR SWITCH	TATA spare parts
284554504902	"PIANO KEY SWITCH,BATTERY CUT OFF"	TATA spare parts
284554504903	PIANO KEY SWITCH DISABLE PERSON	TATA spare parts

284554504904	DOOR SWITCH	TATA spare parts
284554509906	SINGLE POLE MIDI FUSE BOX	TATA spare parts
284554600108	W/H.TAIL-32WB-TATA MINI BUS	TATA spare parts
284554600110	W/H.T/GATE-RH-F/R H/R BSII&III T/N	TATA spare parts
284554600111	ASSY.BRACKET(CONN.MTG)TATA MINI BUS	TATA spare parts
284554600112	WIRING HARNESS CABIN	TATA spare parts
284554600114	KIT-W/H.WINGER-32WB TCIC F/ROOF AC BSIII	TATA spare parts
284554600115	KIT-W/H.WINGER-32WB TCIC H/ROOF AC BSIII	TATA spare parts
284554600116	KIT-W/H WINGER-32WB TCIC H/R N/AC BSIII	TATA spare parts
284554600128	KIT-W/H-WIN-M2-32WB TC AC F/R BS3 N-ABS	TATA spare parts
284554600141	BODY CLIP	TATA spare parts
284554600162	WIRING HARNESS CABIN	TATA spare parts
284554600163	WIRING HARNESS CABIN	TATA spare parts
284554600168	WIRING HARNESS CABIN	TATA spare parts
284554600179	ASSY DIAGNOSTIC CONNECTOR PARKING BKT	TATA spare parts
284554600195	ASSY BRACKET FOR I/C OF FRONT & ENGINE	TATA spare parts
284554600205	BATTERY +VE CABLE ASSY WITH ENGINE W/H B	TATA spare parts
284554600206	BATTERY +VE CABLE ASSY WITH ENGINE W/H B	TATA spare parts
284554600245	WIRING HARNESS FRONT	TATA spare parts
284554600262	WIRING HARNESS FRONT	TATA spare parts
284554600276	PIGTAIL REAR BLOWER	TATA spare parts
284554601602	W/H.MAIN-NON AC-TATA MINI BUS	TATA spare parts
284554601603	W/H.ENGINE-NA/TC-BSIITC-BSIII-TMB	TATA spare parts
284554601604	W/H.FRONT-NON AC-TATA MINI BUS	TATA spare parts
284554601605	W/H.ROOF NON-AC-FL/R-TATA MINI BUS	TATA spare parts
284554601606	W/H.DOOR-LH-TATA MINI BUS	TATA spare parts
284554601607	W/H.DOOR-RH-TATA MINI BUS	TATA spare parts
284554601608	W/H.TAIL-28WB-TATA MINI BUS	TATA spare parts
284554601617	W/H.ROOF-LH-32WB-FLAT ROOF-MINIBUS	TATA spare parts
284554601639	W/H ENGINE NA BSIII TATA WNG	TATA spare parts
284554601640	W/H ENGINE NA BSII/TC BSIII WNG	TATA spare parts
284554601641	TATA WNG:W/H FRONT M1 CLASS	TATA spare parts
284554601642	TATA WNG:W/H MAIN M1 CLASS	TATA spare parts
284554601644	W/H TAIL 28WB M1 CLASS WNG	TATA spare parts
284554601645	W/H ROOF LH 28WB FR M1 CLASS WNG	TATA spare parts
284554601647	W/H HIGH MOUNTED STOP LAMP-WNG	TATA spare parts
284554601655	WH TAIL	TATA spare parts
284554601656	WIRING HARNESS TAIL	TATA spare parts
284554601665	W/H ROOF RH FR-TATA WING M2 CLASS	TATA spare parts
284554601668	W/H ENGINE TCIC TATA WING M2 CLASS	TATA spare parts
284554601669	BATTERY CABLE +VE	TATA spare parts
284554601671	W/H ABS ECU	TATA spare parts
284554601673	ASSY TAIL WIRING HARNESS STR WINGER	TATA spare parts
284554601676	WIRING HARNESS ECU	TATA spare parts
284554601678	WIRING HARNESS TAILGATE	TATA spare parts
284554601679	WIRING HARNESS TAILGATE	TATA spare parts
284554601681	WIRING HARNESS FRONT CNG	TATA spare parts

284554601682	WIRING HARNESS CABIN CNG	TATA spare parts
284554601683	WIRING HARNESS ENGIN CNG	TATA spare parts
284554601684	WIRING HARNESS TAIL CNG	TATA spare parts
284554601685	WIRING HARNESS EMS CNG	TATA spare parts
284554601689	W/H EMS WITH PLUG TOP COIL-WNG-CNG	TATA spare parts
284554608204	BRACKET BATTERY +VE CABLE MTG BS6	TATA spare parts
284554608205	BATTERY CABLE ROUTING SUPPORT BKT	TATA spare parts
284554608206	WH EMS SUPPORT BKT 1 BS6	TATA spare parts
284554608208	Z BRACKET FOR HARNESS CLAMPING	TATA spare parts
284554608211	BRACKET EMS PIGTAIL	TATA spare parts
284554608218	BRACKET FOR ALTERNATOR BRANCH	TATA spare parts
284554608219	ABS W/H½ CHANNEL SUPPORT BRACKET	TATA spare parts
284554609902	DC CORD ASSY	TATA spare parts
284554610101	W/H EMS-WNG-CNG-(INT.CAM COVER)	TATA spare parts
284554610187	WIRING HARNESS	TATA spare parts
284554610188	WIRING HARNESS	TATA spare parts
284554610189	WIRING HARNESS ROOF RH	TATA spare parts
284554610190	WIRING HARNESS	TATA spare parts
284554610191	WIRING HARNESS ROOF LH	TATA spare parts
284554610193	WIRING HARNESS ROOF LH	TATA spare parts
284554610194	WIRING HARNESS	TATA spare parts
284554610198	JUNCTION BOX WITH PIGTAIL BS6	TATA spare parts
284554611602	W/H FRONT 4DLTCIC BSIV	TATA spare parts
284554611605	W/H ENGINE 4DLTCIC _BSIV	TATA spare parts
284554611611	W/H MAIN BSIV TCIC DUAL AC M1 CLASS	TATA spare parts
284554611627	WIRING HARNESS ROOF RH	TATA spare parts
284554611628	WIRING HARNESS FRONT	TATA spare parts
284554611630	FRONT WIRING HARNESS STR WINGER - 2.2L B	TATA spare parts
284554611631	WIRING HARNESS FRONT	TATA spare parts
284554611632	CABIN WIRING HARNESS STR WINGER - 2.2L B	TATA spare parts
284554611651	WIRING HARNESS FRONT	TATA spare parts
284554611652	WIRING HARNESS CABIN	TATA spare parts
284554611666	W/H FRONT NON AC	TATA spare parts
284554611667	W/H MAIN	TATA spare parts
284554611674	W/H MAIN AC 4DL BS-III	TATA spare parts
284554611678	W/H FRONT 4DL BSIV NON AC	TATA spare parts
284554611679	W/H MAIN 4DL BSIV NON AC	TATA spare parts
284554611687	W/H ROOF LH	TATA spare parts
284554611691	W/H FRONT AC 4DL BS-III	TATA spare parts
284554620103	WIRING HARNESS CABIN	TATA spare parts
284554620104	WIRING HARNESS CABIN	TATA spare parts
284554620106	WIRING HARNESS ROOF LH	TATA spare parts
284554620107	WIRING HARNESS ROOF LH	TATA spare parts
284554620108	WIRING HARNESS ROOF LH	TATA spare parts
284554620109	WIRING HARNESS ROOF LH	TATA spare parts
284554620110	WIRING HARNESS CABIN	TATA spare parts
284554620111	WIRING HARNESS ROOF LH	TATA spare parts



284554620113	WIRING HARNESS ROOF LH	TATA spare parts
284554620114	WIRING HARNESS CABIN	TATA spare parts
284554620119	CABLE LINEAR HEAT SENSING BS6	TATA spare parts
284554620120	WIRING HARNESS BS6	TATA spare parts
284554620121	WIRING HARNESS HOOTER BS6	TATA spare parts
284554620124	CABLE FIRE RETARDANT LOW SMOKE BS6	TATA spare parts
284554621610	W/H FRONT AC 2.2L BS-IV	TATA spare parts
284554621612	W/H MAIN AC 2.2L BS-IV	TATA spare parts
284554621613	W/H FRONT 2.2L BSIV NON AC	TATA spare parts
284554621614	W/H MAIN 2.2L BSIV NON AC	TATA spare parts
284554621615	WIRING HARNESS FRONT	TATA spare parts
284554621616	WIRING HARNESS CABIN	TATA spare parts
284554621617	W/H ENGINE	TATA spare parts
284554621618	W/H ENGINE 4DL BS4 NAC	TATA spare parts
284554621619	W/H ROOF RH	TATA spare parts
284554621620	W/H ROOF RH FOR STR WINGER ABS	TATA spare parts
284554621623	WH ROOF LH STR WINGER (3488WB)	TATA spare parts
284554621646	WIRING HARNESS SIREN REVOLVING LAMP	TATA spare parts
284554621665	WIRING HARNESS ABS ECU	TATA spare parts
284554621671	WIRING HARNESS CABIN	TATA spare parts
284554621675	WIRING HARNESS FRONT	TATA spare parts
284554621677	WIRING HARNESS FRONT	TATA spare parts
284554621678	WIRING HARNESS TAIL	TATA spare parts
284554621679	WIRING HARNESS ROOF LH	TATA spare parts
284554621681	WIRING HARNESS CABIN	TATA spare parts
284554621682	WIRING HARNESS TAIL	TATA spare parts
284554621685	WIRING HARNESS FRONT	TATA spare parts
284554621698	WIRING HARNESS FRONT	TATA spare parts
284554621699	WIRING HARNESS FRONT	TATA spare parts
284554631601	WIRING HARNESS TAIL	TATA spare parts
284554631602	WIRING HARNESS FRONT	TATA spare parts
284554631606	WIRING HARNESS CABIN	TATA spare parts
284554631610	WIRING HARNESS FRONT	TATA spare parts
284554640101	W/H.MAIN-NON AC	TATA spare parts
284554640102	W/H.ENGINE-NA/TC-BSII TC-BSIII	TATA spare parts
284554640103	W/H.TAIL-32WB	TATA spare parts
284554640104	W/H.FRONT-NON AC	TATA spare parts
284554640105	W/H.ROOF-N/AC-FL/ROOF-TATA MINI BUS	TATA spare parts
284554640106	W/H.TAIL GATE-RH-FL/R NA BSII 28WB.	TATA spare parts
284554640107	W/H.DOOR-LH	TATA spare parts
284554640108	W/H.DOOR-RH-TABLE-TATA MINI BUS	TATA spare parts
284554640109	W/H.TAIL-28WB-TATA MINI BUS	TATA spare parts
284554640110	W/H.T/GATE-RH-F/R H/R BSII&III TC/N	TATA spare parts
284554640111	W/H.MAIN-AC-TATA MINI BUS	TATA spare parts
284554640112	W/H.FRONT-AC-TATA MINI BUS	TATA spare parts
284554640113	W/H.ENGINE-NA/BSIII	TATA spare parts
284554640117	W/H.ROOF-LH-28WB-FLAT ROOF-MINIBUS	TATA spare parts

284554640118	W/H.ROOF-LH-32WB-FLAT ROOF-MINIBUS	TATA spare parts
284554640119	W/H.ROOF-LH-32WB-HIGH ROOF-MINIBUS	TATA spare parts
284554640120	W/H.ROOF-RH-AC FLATROOF-MINI BUS	TATA spare parts
284554640121	W/H.ROOF-RH-AC HIGH ROOF-MINI BUS	TATA spare parts
284554640122	W/H.SIREN SWITCHS & FRONT FAN-WNG.	TATA spare parts
284554640123	W/H.R/LAMP PAT.LAMP FAN(CEN)-WNG-H/R	TATA spare parts
284554640124	W/H.R/LAMP PAT.LAMP FAN(CEN)-WNG-F/R	TATA spare parts
284554640126	W/H.ROOF-LH-CL.GOODS CARRIER	TATA spare parts
284554640127	W/H.TAIL TO ROOF-CL.GOODS CARR-WING	TATA spare parts
284554640136	W/H ROOF LH 3488WB AC HR TATA WNG	TATA spare parts
284554640137	W/H TAIL 3488WB STR.WINGER	TATA spare parts
284554640138	W/H TAIL GATE 3488WB STR.WINGER	TATA spare parts
284554640139	W/H ENGINE NA BSIII TATA WNG	TATA spare parts
284554640140	W/H ENGINE NA BSII/TS BSIII WNG	TATA spare parts
284554640141	TATA WNG:W/H FRONT M1 CLASS	TATA spare parts
284554640142	TATA WNG:W/H MAIN M1 CLASS	TATA spare parts
284554640144	W/H TAIL 28WB M1 CLASS WNG	TATA spare parts
284554640145	W/H ROOF LH 28WB FR M1 CLASS	TATA spare parts
284554640147	W/H HIGH MOUNTED STOP LAMP-WNG	TATA spare parts
284554640149	W/H WINGER M2 TAIL LIMITED EDITION	TATA spare parts
284554640158	W/H HIGH MOUNTED STOP LAMP	TATA spare parts
284554640161	W/H FRONT AC-TATA WING M2 CLASS	TATA spare parts
284554640162	W/H CABIN AC WINGER M2 CLASS	TATA spare parts
284554640164	W/H TAIL 32WB-TATA WING M2 CLASS	TATA spare parts
284554640165	W/H ROOF RH-FR-TATA WING M2 CLASS	TATA spare parts
284554640168	W/H ENGINE TCIC TATA WING M2 CLASS	TATA spare parts
284554640181	WIRING HARNESS FRONT CNG	TATA spare parts
284554640182	WIRING HARNESS CABIN CNG	TATA spare parts
284554640183	WIRING HARNESS ENGIN CNG	TATA spare parts
284554640184	WIRING HARNESS TAIL CNG	TATA spare parts
284554640185	WIRING HARNESS EMS CNG	TATA spare parts
284554640186	W/H FRONT-STR-WINGER-AMB	TATA spare parts
284554640187	W/H MAIN-STR-WINGER-AMB	TATA spare parts
284554640189	W/H EMS WITH PLUG TOP COIL-WNG-CNG	TATA spare parts
284554640190	W/H ROOF LH-32WB-AMBULANCE	TATA spare parts
284554640193	W/H FRONT WINGER BS-IV	TATA spare parts
284554640194	W/H CABIN WINGER BS-IV	TATA spare parts
284554640195	W/H EMS WINGER BS-IV	TATA spare parts
284554640198	W/H ROOF RH HIGH ROOF	TATA spare parts
284554650102	WH FRONT TCIC BS IV	TATA spare parts
284554650105	W/H ENGINE BS-IV TCIC	TATA spare parts
284554650111	W/H MAIN BSIV TCIC DUAL AC M1 CLASS	TATA spare parts
284554650117	WH FRONT STR.AMB 2.2L BS-IV	TATA spare parts
284554650118	WH CABIN STR AMB 2.2L BS-IV	TATA spare parts
284554650128	WH ENGINE WINGER 4DL BS-IV	TATA spare parts
284554650142	WH FRONT NON AC WINGER M2 4DL BS-IV	TATA spare parts
284554650143	WH TAIL WINGER CNG 3200WB WITH INTEGRATE	TATA spare parts

284554650144	WH ENGINE WINGER CNG WITH INTEGRATED CAM	TATA spare parts
284554650145	WH FRONT WINGER CNG WITH INTEGRATED CAM	TATA spare parts
284554650146	WH CABIN WINGER CNG WITH INTEGRATED CAM	TATA spare parts
284554650147	WH ECU WINGER CNG WITH INTEGRATED CAM C	TATA spare parts
284554650149	WH ENGINE WINGER BSII/BSIINA/TCIC/STR	TATA spare parts
284554650154	WH CABIN WINGER M2 NON AC 4DL BS-IV	TATA spare parts
284554650157	WH FRONT NON AC WINGER 2.2L M2 BS-IV	TATA spare parts
284554650158	WH ROOF RH 2.2L BS-IV STR WNG	TATA spare parts
284554650168	WIRING HARNESS EMS	TATA spare parts
284554660101	W/H CABIN NON AC VERSION WINGER	TATA spare parts
284554660104	W/H FRONT-NON AC-TATA WINGER	TATA spare parts
284554660107	W/H DOOR LH WINGER	TATA spare parts
284554660108	W/H DOOR RH WINGER	TATA spare parts
284554660109	W/H TAIL 28 W/B WINGER	TATA spare parts
284554660110	W/H TAIL GATE F/R H/R.NA/TC BS2/BS3	TATA spare parts
284554660117	W/H ROOF LH-FLAT ROOF 28 WB WINGER	TATA spare parts
284554660139	W/H ENGINE NA BSIII TATA WNG.	TATA spare parts
284554660140	W/H ENGINE NA BSII/TCBSIII WNG	TATA spare parts
284554660141	TATA WNG:W/H FRONT M1 CLASS	TATA spare parts
284554660142	W/H MAIN M1 CLASS TATA WNG	TATA spare parts
284554660144	W/H TAIL 28WB M1 CLASS WNG	TATA spare parts
284554660145	W/H ROOF LH 28WB FR M1CLASS	TATA spare parts
284554660147	W/H HIGH MOUNTED STOP LAMP-WNG	TATA spare parts
284554660164	W/H_TAIL 32WB TATA WING M2 CLASS	TATA spare parts
284554660165	W/H ROOF RH-FR-TATA WING M2 CLASS	TATA spare parts
284554660168	W/H ENGINE TCIC TATA WING M2 CLASS	TATA spare parts
284554660181	WIRING HARNESS FRONT CNG	TATA spare parts
284554660182	WIRING HARNESS CABIN CNG	TATA spare parts
284554660183	WIRING HARNESS ENGIN CNG	TATA spare parts
284554660184	WIRING HARNESS TAIL CNG	TATA spare parts
284554660185	WIRING HARNESS EMS CNG	TATA spare parts
284554660189	W/H EMS WITH PLUG TOP COIL-WNG-CNG	TATA spare parts
284554660197	PIG TAIL FOR 5P-MAXIFUSE FITMENT	TATA spare parts
284554670112	WH ENGINE WINGER BSII/BSIII NA/TCIC/STR	TATA spare parts
284554680102	WH FRONT TCIC BS IV	TATA spare parts
284554680105	W/H ENGINE BS-IV TCIC	TATA spare parts
284554680111	W/H MAIN BSIV TCIC DUAL AC M1 CLASS	TATA spare parts
284554690135	TATA STR WNG AMB BATT.CABLE	TATA spare parts
284554700101	KIT-A/C ELECT.AGGR.-SANDEN VIKAS-WINGER	TATA spare parts
284554700102	WIRING HARNESS A/C-WINGER	TATA spare parts
284554700103	ASSY.A/C.SWITCH-WINGER	TATA spare parts
284554700105	TATA WING:A/C BLOWER RESISTOR	TATA spare parts
284554700106	W/H FRONT AC-WINGER	TATA spare parts
284554700108	FRONT BLOWER RESISTOR	TATA spare parts
284554700113	BRACKET ASSY VECU MTG BS6-PH2	TATA spare parts
284554700114	BRACKET ASSY SPEED LIMITER MOTOR MTG	TATA spare parts
284554700115	BRACKET ASSY ECU MTG	TATA spare parts

284554709901	THERMOAMPLIFIER-A/C SW.-WINGER	TATA spare parts
284554709902	RELAY-5POLE-A/C-WINGER	TATA spare parts
284554709912	REVERSE PARK ASSISTANCE SENSOR BS6	TATA spare parts
284554709912C7	GRANIT_BLACK-REVERSE PARK ASSISTANCE SEN	TATA spare parts
284554709913	REVERSE PARK ASSISTANCE SENSOR BS6	TATA spare parts
284554709913C7	GRANIT_BLACK-REVERSE PARK ASSISTANCE SEN	TATA spare parts
284554709914	VEHICLE ELECTRONIC CONTROLLER UNIT BS6	TATA spare parts
284554709917	BODY CONTROL MODULE BS6	TATA spare parts
284554800101	KIT MUSIC SYSTEM	TATA spare parts
284554800103	ASSY MUSIC SYSTEM MTG BKT	TATA spare parts
284554800107	KIT-FIRE DETECTION SUPPRESSION SYSTEM BS	TATA spare parts
284554800108	KIT-FIRE DETECTION SYSTEM	TATA spare parts
284554800111	BRACKET ASSY CONTROL MTG BS6	TATA spare parts
284554800113	HORN STROBE ASSY BS6	TATA spare parts
284554800114	JUNCTION BOX ASSY BS6	TATA spare parts
284554800116	BRACKET ASSY P-CLAMP MTG BS6	TATA spare parts
284554803302	BRACKET CONTROL UNIT MTG BS6	TATA spare parts
284554803303	BRACKET JUNCTION BOX MTG BS6	TATA spare parts
284554803304	BRACKET	TATA spare parts
284554803306	PLATE	TATA spare parts
284554803309	PLATE BS6	TATA spare parts
284554803310	BRACKET BS6	TATA spare parts
284554804905	CABLE	TATA spare parts
284554804908	CONTROL UNIT	TATA spare parts
284554804909	SOUNDER CUM FLASHER-24V	TATA spare parts
284554804938	JUNCTION BOX	TATA spare parts
284554804940	CONTROL UNIT BS6	TATA spare parts
284554804941	END OF LINE	TATA spare parts
284554807502	RUBBER CAP	TATA spare parts
284554820101	BRACKET ASSY WASHER BOTTLE MTG BS6	TATA spare parts
284554820103	KIT-WINDSHIELD WASHER SYSTEM BS6	TATA spare parts
284554823301	WASHER HOSE MTG BRACKET BS6	TATA spare parts
284554900104	BRACKET ASSY EMS ECU MTG BS6	TATA spare parts
284554900106	BRACKET SUPPORT BRACKET ASSY ECU MTG BS6	TATA spare parts
284554904902	USB CHARGER BS6	TATA spare parts
284554904903	USB CHARGER BS6	TATA spare parts
284555106302	MASCOT	TATA spare parts
284555106303	T-LOGO BASE PLATE BS6	TATA spare parts
284555156302	DECAL	TATA spare parts
284555156304	DECAL	TATA spare parts
284555156307	DECAL BS6	TATA spare parts
284555156308	DECAL	TATA spare parts
284555156310	DECAL BS6	TATA spare parts
284555156313	DECAL	TATA spare parts
284558300103	FIRE DETECTION & SUPPRESSION SYSTEM	TATA spare parts
284558300104	FIRE DETECTION & SUPPRESSION SYSTEM BS6	TATA spare parts
284558300105	TUBE BS6	TATA spare parts

284558300107	EXTENSION TUBE BS6	TATA spare parts
284558304001	HAMMER 1 (FOR PASSENGERS)	TATA spare parts
284558304002	HAMMER 2 (FOR DRIVER & CO-DRIVER)	TATA spare parts
284558304010	CANISTER STAND BS6	TATA spare parts
284558304011	CANISTER BS6	TATA spare parts
284558304012	ELBOW CONNECTOR BS6	TATA spare parts
284558304013	GROMMET BS6	TATA spare parts
284558304017	UNION BS6	TATA spare parts
284558304018	HOSE BS6	TATA spare parts
284558304019	NOZZLE FUEL RAIL BS6	TATA spare parts
284558304020	NOZZLE BS6	TATA spare parts
284558304021	EXTENSION TUBE BS6	TATA spare parts
284558304022	GROMMET BS6	TATA spare parts
284558304023	TUBE BS6	TATA spare parts
284558304025	TUBE ASSY BS6	TATA spare parts
284558304028	EXTENSION TUBE BS6	TATA spare parts
284558304033	CLAMP BS6	TATA spare parts
284558304034	CLAMP BS6	TATA spare parts
284558408203	TRANSFER LABEL-Vehicle Jacking Locations	TATA spare parts
284558408204	TRANSFER LABEL-RUNNING INSTRUCTIONS	TATA spare parts
284558408212	TRANSFER LABEL TYRE PRESSURE (195 R15 R	TATA spare parts
284558408217	TRANSFER LABEL EMERGENCY EXIT-LH	TATA spare parts
284558408218	TRANSFER LABEL EMERGENCY EXIT-RH	TATA spare parts
284558408219	TRANSFER LABEL FIRE EXTINGUISHER	TATA spare parts
284558408220	TRANSFER LABEL FIRE EXTINGUISHER	TATA spare parts
284558408221	TRANSFER LABEL EMERGENCY EXIT	TATA spare parts
284558408222	TRANSFER LABEL HANDICAPPED ONLY	TATA spare parts
284558408223	TRANSFER LABEL EMERGENCY EXIT RR DOOR	TATA spare parts
284558408224	LABEL INSTRUCTION IN EMERGENCY	TATA spare parts
284558408225	LABEL INSTRUCTION TO BREAK GLASS	TATA spare parts
284558900102	ASSY.SCISSORS JACK	TATA spare parts
284558900103	TOOL KIT - PANEL VAN (DIESEL)	TATA spare parts
284558900114	ASSY SCISSORS JACK WITH 1 PIECE JACK HAN	TATA spare parts
284558900115	TOOL KIT - ST WINGER	TATA spare parts
284558900601	VALVE RESTING PLATE / 486 CNG / WINGER	TATA spare parts
284558900602	DOLLEY / R-VALVE STEM SEAL/ 486CNG / WIN	TATA spare parts
284558900603	SPANNER 24 HEX-395L Z/CRANKSHAFT-CNG/WIN	TATA spare parts
284558902401	LHS engine mount bolt removal tool	TATA spare parts
284558902601	Mounting plate TA70 gear box.	TATA spare parts
284558902602	DUMMY BEARING-I(PINION DEPTH)TA 70	TATA spare parts
284558902603	Fixture spring assy selector shaft	TATA spare parts
284558902604	LOCKING TOOL FOR 5TH ENGAGING GEAR	TATA spare parts
284558902605	PULLER-5TH ENGAGING GEAR (TA 70)	TATA spare parts
284558902606	LOCKING PLATE-(DROP DOWN GEAR TA70)	TATA spare parts
284558902607	PULLER/REMOVE I- BRG I-RACE SHFT-BRG/VAN	TATA spare parts
284558902608	PULLER/ REMOVE I-BRG O-RACE-P-SHFT / VAN	TATA spare parts
284558902609	DRIFT-DOUBLE LIP OIL SEAL, TA70	TATA spare parts

284558902610	DUMMY BEARING-II(PINION DEPTH)TA 70	TATA spare parts
284558902611	ADAPTOR/CHECK PINION BRG PRELOAD/WINGER	TATA spare parts
284558902612	SOCKET FOR THREADED LOCK RING-TA 70	TATA spare parts
284558902613	PULLER FOR CROWN WHEEL BRG.-LHS- TA70	TATA spare parts
284558902614	PULLER-CROWN WHEEL BRG-RHS	TATA spare parts
284558902615	DRIFT-CROWN WHEEL BRG-LHS, TA70	TATA spare parts
284558902616	DUMMY BEARING/CROWN WHEEL BRG-TA70/VA	TATA spare parts
284558902617	LOCATOR-REVERSE IDLER GEAR	TATA spare parts
284558902618	FIXTURE FOR LAYSHAFT ASSY.	TATA spare parts
284558902619	LOKATING PIN	TATA spare parts
284558902620	DRIFT-CROWN WHEEL BRG-RHS, TA70	TATA spare parts
284558902621	SPACER-FOR PULLER	TATA spare parts
284558902622	PULLER-REMOVAL OF 5TH GEAR ON LAY SHAFT	TATA spare parts
284558902623	DRIFT-REMOVAL OF LAYSHAFT BRG.(TA70 G.B)	TATA spare parts
284558902624	DRIFT-INPUT SHAFT BRG.& LAY SHAFT BRG.	TATA spare parts
284558902625	DRIFT-FIT. OF INPUT SHAFT BRG.(TA70 G.B)	TATA spare parts
284558902626	BACKLASH MEASUREMENT TOOL	TATA spare parts
284558902627	SOC 36 BI-1/4"SQ-60L/PINION BRG PRE-LOAD	TATA spare parts
284558902628	SOCKET FOR RH AXLE SHAFT	TATA spare parts
284558902629	SOCKET FOR LH-AXLE SHAFT	TATA spare parts
284558902630	GAUGE- CROWN WHEEL	TATA spare parts
284558903201	SPRING COMPRESSOR (SUSPENSION)	TATA spare parts
284558903301	PULLER / FRONT HUB ASSY. / PANNEL VAN	TATA spare parts
284558903302	MOUNTING PLATE/S- AXLE W-SUB FRAME/VAN	TATA spare parts
284558903303	PULLER FOR HUB BEARING	TATA spare parts
284558903304	DRIFT	TATA spare parts
284558903305	DRIFT / PRESSING FRONT HUB/SA/PANNEL VAN	TATA spare parts
284558903306	KIT FOR STUB AXLE MOUNTING STAND	TATA spare parts
284558903501	DRIFT-FIT. OF INNER BRG.	TATA spare parts
284558903502	DRIFT-OUTER BRG OUTER RACE	TATA spare parts
284558903503	DRIFT-OUTER BRG OUTER RACE	TATA spare parts
284558903504	DRIFT-FIT.OF INNER BRG INNER RACE	TATA spare parts
284558903505	DRIFT-FIT.OF INNER BRG. OIL SEAL	TATA spare parts
284558903506	HUB PLAY CHECKING UNIT-REAR HUB	TATA spare parts
284558903507	PULLER / REAR HUB / WINGER, RA -1068	TATA spare parts
284558903508	ADAPTOR STAND / R- AXLE. / PANEL VAN	TATA spare parts
284558903509	SOCKET 13HEX-1/2-120L / PANEL VAN	TATA spare parts
284558904006	FIRE EXTIGUISHER-2KG	TATA spare parts
284558904601	RACK HOLDING TOOL FOR RANE STEERING	TATA spare parts
284558904602	BELOW SUPPORT / RANE STRG / PANEL VAN	TATA spare parts
284558904603	SPANNR 36A/F 0E-114L/RANE STRG/PANEL VAN	TATA spare parts
284560000102BF	ASSY.BODY SHELL COMPLETE WITH DOORS (FLA	TATA spare parts
284560000102FD	ASSY.BODY SHELL COMP.WITH DOORS (FLATROO	TATA spare parts
284560000103	ASSY BODY SHELL COMP-RHD FLAT ROOF BS2	TATA spare parts
284560000110BF	ASSY BODY SHELL COMPLETE PAINTED-RHD ARTI	TATA spare parts
284560000110D3	ASSY BODY SHELL COMPLETE PAINTED-RHD ARTI	TATA spare parts
284560000115D3	ASSY BODY SHELL COMP PAINTED-RHD ARTICT S	TATA spare parts

284560000115D8	ASSY BODYSHELL COMP PAINTED-RHD PEARL_WH	TATA spare parts
284560000115FD	ASSY BODYSHELL COMP PAINTED-RHD SK_GOLN	TATA spare parts
284560000121	ASSY BODYSHELL COMP-CED COAT-2800WBFR	TATA spare parts
284560000128BF	ASSY BODYSHELL COMP PAINTED-(FLAT ROOF)	TATA spare parts
284560000143BF	ASSY.BODY SHELL COMP.WITH DOORS (FLATROO	TATA spare parts
284560000151	ASSY BODY SHELL COMPLETE PAINTED RHD	TATA spare parts
284560000151BF	ASSY BODYSHELL COMPLETE PAINTED-(HIGH RO	TATA spare parts
284560000182BF	ASSY BODYSHELL COMPLETE PAINTED-(HIGH RO	TATA spare parts
284560000190D8	ASSY BODYSHELL COMPLETE PAINTED RHD	TATA spare parts
284560000190FD	ASSY BODYSHELL COMPLETE PAINTED RHD SK G	TATA spare parts
284560000197BF	ASSY BODY SHELL COMP PAINTED 9+1	TATA spare parts
284560000201D8	ASSY BODY SHELL COMPLETE PAINTED-RHD PEA	TATA spare parts
284560000201EN	ASSY BODY SHELL COMPLETE PAINTED-RHD	TATA spare parts
284560000209D3	ASSY BODYSHELL COMPLETE PAINTED RHD	TATA spare parts
284560000209D8	ASSY BODYSHELL COMPLETE PAINTED RHD.	TATA spare parts
284560000209FD	ASSY BODYSHELL COMPLETE PAINTED RHD.	TATA spare parts
284560000212	ASSY BODYSHELL COMPLETE WITHOUT DOOR-RH	TATA spare parts
284560000218BF	ASSY BODYSHELL COMPLETE PAINTED RHD	TATA spare parts
284560000224D8	BODY SHELL COMPLETE PAINTED-RHD	TATA spare parts
284560000238	ASSY BODYSHELL COMP W/O DOOR CED COATED	TATA spare parts
284560000243	ASSY BODYSHELL COMP W/O DOOR CED COATED	TATA spare parts
284560000248	ASSY BODYSHELL COMP W/O DOOR CED COATED	TATA spare parts
284560000249	ASSY BODYSHELL COMP W/O DOOR CED COATED	TATA spare parts
284560000250	ASSY BODYSHELL COMP W/O DOOR CED COATED	TATA spare parts
284560000251	ASSY BODYSHELL COMP W/O DOOR CED COATED	TATA spare parts
284560000252	ASSY BODYSHELL COMP W/O DOOR CED COATED	TATA spare parts
284560000272BF	ARCTIC_WHITE-ASSY BODYSHELL PAINTED STRE	TATA spare parts
284560000279BF	ARCTIC WHITE_ASSY BODYSHELL COMP PAINTED	TATA spare parts
284560000310D3	¿ASSY BODYSHELL COMPLETE PAINTED RHD.2.2	TATA spare parts
284560000310D8	ASSY BODYSHELL COMPLETE PAINTED RHD.2.2L	TATA spare parts
284560000316FD	ASSY BODYSHELL COMPLETE PAINTED-RHD 2.2L	TATA spare parts
284560000324FD	ASSY BODYSHELL COMPLETE SK_GOLN_YELW	TATA spare parts
284560000328	ASSY BODYSHELL COMP W/O DOOR CED COATED	TATA spare parts
284560000338BF	ASSY BODYSHELL COMPLETE PAINTED 2.2L DI	TATA spare parts
284560000338G3	PORCLN_WHITE_ASSY BODYSHELL COMPLETE PA	TATA spare parts
284560000344D3	ASSY BODYSHELL COMPLETE PAINTED RHD 2.2L	TATA spare parts
284560000344D8	ASSY BODYSHELL COMPLETE PAINTED RHD 2.2L	TATA spare parts
284560000350BF	ASSY BODYSHELL COMP. RHD PAINTED 2.2L DI	TATA spare parts
284560000355D8	ASSY BODY SHELL COMPLETE PAINTED-RHD 320	TATA spare parts
284560000361BF	ARCTIC_WHITE-ASSY BODYSHELL COMP PAINTED	TATA spare parts
284560000361FD	BODY SHELL SK_GOLN_YELW COMP PAINTED RHD	TATA spare parts
284560000384GM	ASSY BODYSHELL COMPLETE PAINTED RHD	TATA spare parts
284560000399	ASSY BODYSHELL COMP W/O DOORS STR CED	TATA spare parts
284560010102	ASSY BODYSHELL WITHOUT DOORS	TATA spare parts
284560010103	ASSY BODYSHELL COMPLETE RHD	TATA spare parts
284560010104	ASSY BODYSHELL COMPLETE WITH CED COATED	TATA spare parts
284560010105BF	ASSY BODYSHELL PAINTED RHD	TATA spare parts

284560010123BF	ASSY BODYSHELL PAINTED RHD	TATA spare parts
284560010129	ASSY BODYSHELL COMP STR WITH CED	TATA spare parts
284560010130BF	ASSY BODYSHELL PAINTED STR AMB M2	TATA spare parts
284560010130G3	ASSY. CABIN BARE WINGER PORCLN WH BS4	TATA spare parts
284560010151BF	BODY ASSY PAINTED	TATA spare parts
284560010167BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED	TATA spare parts
284560010167FD	ASSY BODY SHELL _GOLN_YELW	TATA spare parts
284560010261	BODY SHELL ASSY WITH CED COAT BS6	TATA spare parts
284560010265FD	SK_GOLN_YELW-BODY ASSY PAINTED BS6	TATA spare parts
284560010265JS	TITANIUM_WH-BODY ASSY PAINTED BS6	TATA spare parts
284560020103D8	ASSY BODY WINGER PEARL_WHITE BS6	TATA spare parts
284560020122	BODY ASSY WITH CED COAT BS6	TATA spare parts
284560020129G3	PORCLN_WHITE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
284560020134FD	SK_GOLN_YELW-BODY ASSY PAINTED BS6	TATA spare parts
284560020140G3	PORCLN_WHITE-BODY ASSY PAINTED BS6	TATA spare parts
284560020146	BODY SHELL ASSY WITH CED COAT BS6	TATA spare parts
284560020150D8	PEARL_WHITE-BODY ASSY PAINTED BS6	TATA spare parts
284560020150FD	SK_GOLN_YELW-BODY ASSY PAINTED BS6	TATA spare parts
284560020153G3	PORCLN_WHITE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
284560020158G3	PORCLN_WHITE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
284560020160	BODY SHELL ASSY WITH CED COAT BS6	TATA spare parts
284560020189G3	PORCLN_WHITE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
284560020192	BODY ASSY WITH CED COAT BS6	TATA spare parts
284560030111JS	TITANIUM_WH-BODY ASSY PAINTED BS6	TATA spare parts
284560100106	ASSY TIE MEMBER UPPER	TATA spare parts
284560100107	ASSY CROSS MEMBER LOWER COMPLETE	TATA spare parts
284560100108	ASSY FUEL FILLER HOUSING	TATA spare parts
284560100111	ASSY TIE MEMBER UPPER BS-4	TATA spare parts
284560100115	ASSY TIE MEMBER UPPER WITH CED COATED	TATA spare parts
284560100116	ASSY FUEL FILLER HOUSING CNG	TATA spare parts
284560100119	ASSY CROSS MBR LOWER COMPLETE (BS-IV)	TATA spare parts
284560100150	TIE MEMBER ASSY UPPER BS6	TATA spare parts
284560100164	SUPPORT PLATE ASSY BS6	TATA spare parts
284560100182	CLOSING PLATE ASSY BS6	TATA spare parts
284560103306	BRACKET FRONT BUMPER MTG BS6	TATA spare parts
284560108221	CUP (BODY MOUNT) FRONT LH	TATA spare parts
284560108222	CUP (BODY MOUNT) FRONT RH	TATA spare parts
284560108223	CUP (BODY MOUNT) REAR LH	TATA spare parts
284560108224	CUP (BODY MOUNT) REAR RH	TATA spare parts
284560108228	MTG BRACKET HOOTER BS6	TATA spare parts
284560108229	BRACKET BUZZER MTG BS6-PH2	TATA spare parts
284560108235	CAGE RETAINER	TATA spare parts
284560108262	GUSSET CENTRAL CROSS MBR REAR EXTREME LH	TATA spare parts
284560108263	GUSSET CENTRAL CROSS MBR REAR EXTREME RH	TATA spare parts
284560108264	GUSSET SIDE MEMBER SPRING MTG REAR LH	TATA spare parts
284560108265	GUSSET SIDE MEMBER SPRING MTG REAR RH	TATA spare parts
284560108266	REAR CM EXTN LEAF SRING MTG RETRO A LH	TATA spare parts



284560108267	REAR CM EXTN LEAF SRING MTG RETRO A RH	TATA spare parts
284560108268	REAR CM EXTN LEAF SRING MTG RETRO B LH	TATA spare parts
284560108269	REAR CM EXTN LEAF SRING MTG RETRO B RH	TATA spare parts
284560108270	GUSSET REAR D PILLAR CORNER LH	TATA spare parts
284560108271	GUSSET REAR D PILLAR CORNER RH	TATA spare parts
284560108272	REINF FLOOR LEAF SPRING MTG	TATA spare parts
284560108277	BRACKET FUEL FILTER MTG BS6	TATA spare parts
284560600106	ASSY SUPPORT FRONT BUMPER SIDE.	TATA spare parts
284560608204	REINF FLANGE LH	TATA spare parts
284560608205	REINF FLANGE RH	TATA spare parts
284560608206	SUPPORT FRONT BUMPER SIDE	TATA spare parts
284560608213	MTG BKT B PILLAR SIDE TRIM RH FR	TATA spare parts
284560608224	END PLATE SUPPORT FRONT BUMPERSIDE LH	TATA spare parts
284560608225	END PLATE SUPPORT FRONT BUMPER SIDE RH	TATA spare parts
284560990107	CUP SHOCK ABSORBER LH+ RH	TATA spare parts
284561000103	ASSY REAR S/STRUCTURE WITH FLOOR COMP.	TATA spare parts
284561000104	ASSY SUBSTRUCTURE FRONT COMPLETE	TATA spare parts
284561000109	ASSY REAR SUBSTRUCTURE WITH FLOOR COMPL	TATA spare parts
284561000112	ASSY RR S/S WITH FLOOR COMP AMBULANCE	TATA spare parts
284561000133	ASSY REAR S/S WITH FLOOR COMP STRTCH AMB	TATA spare parts
284561000156	SUBSTRUCTURE ASSY WITH FLOOR REAR BS6	TATA spare parts
284561000157	SUBSTRUCTURE ASSY FRONT BS6	TATA spare parts
284561000160	SUBSTRUCTURE ASSY FRONT BS6	TATA spare parts
284561000190	SUBSTRUCTURE ASSY WITH FLOOR REAR BS6	TATA spare parts
284561200108	ASSY SILL INNER SIDE LH	TATA spare parts
284561200109	ASSY SILL INNER SIDE RH	TATA spare parts
284561200115	ASSY SILL INNER SIDE LH	TATA spare parts
284561200116	ASSY SILL INNER SIDE RH	TATA spare parts
284561200118	ASSY SILL INNER SIDE LH(NON SLIDING DOOR	TATA spare parts
284561200119	ASSY SILL INNER SIDE RH(NON SLIDING DOOR	TATA spare parts
284561200138	ASSY REINFORCEMENT AUX CONDENSER RETROK	TATA spare parts
284561200144	CED-ASSY SILL INNER SIDE LH	TATA spare parts
284561200145	CED-ASSY SILL INNER SIDE RH	TATA spare parts
284561208213	SILL INNER REAR CORNER LH	TATA spare parts
284561208214	SILL INNER REAR CORNER RH	TATA spare parts
284561208235	SILL_INNER_REAR_CORNER_LH	TATA spare parts
284561208236	SILL INNER REAR CORNER RH	TATA spare parts
284561300179	ASSY CLOSING PLATE LONG MEMBER BS6	TATA spare parts
284561300201	BRACKET ASSY BS6-PH2	TATA spare parts
284561300202	CLOSING PLATE ASSY LONG MEMBER BS6-PH2	TATA spare parts
284561300207	BRACKET BS6-PH2	TATA spare parts
284561300208	BRACKET ASSY BS6-PH2	TATA spare parts
284561300209	BRACKET ASSY BS6-PH2	TATA spare parts
284561300210	BRACKET ASSY PIPE MTG BS6-PH2	TATA spare parts
284561300211	BRACKET ASSY PIPE MTG BS6-PH2	TATA spare parts
284561308247	BRACKET BS6-PH2	TATA spare parts
284561308271	CLOSING PLATE	TATA spare parts

284561308273	REINF. SEAT MTG. BS6	TATA spare parts
284561308274	REINFORCEMENT LOWER SIDE BONNET LH	TATA spare parts
284561308275	REINFORCEMENT LOWER SIDE BONNET RH	TATA spare parts
284561310105	ASSY. REINF REAR CNG MTG TOWARDS LH SIDE	TATA spare parts
284561310107	ASSY EXTN CROSS MBR NEAR SPARE WHEEL LH	TATA spare parts
284561310108	ASSY EXTN CROSS MBR NEAR SPARE WHEEL RH	TATA spare parts
284561310116	ASSY EXTN CROSS MBR JACK MTG REAR COMPLH	TATA spare parts
284561310117	ASSY EXTN CROSS MBR JACK MTG REAR COMPRH	TATA spare parts
284561310126	BRACKET EXTENSION ASSY REAR BUMPER MTG	TATA spare parts
284561310199	ASSY EMS BRACKET. BS6	TATA spare parts
284561320109	BRACKET ASSY BS6-PH2	TATA spare parts
284561328223	REINF SIDE MEMBER SPRING MTG LH	TATA spare parts
284561328224	REINF SIDE MEMBER SPRING MTG RH	TATA spare parts
284561330104	BRACKET ASSY BS6-PH2	TATA spare parts
284561338203	BRACKET BS6	TATA spare parts
284561408202	GUSSET CENTRAL CROSS MBR MIDDLE LH BS6-P	TATA spare parts
284561408203	GUSSET CENTRAL CROSS MBR MIDDLE RH BS6-P	TATA spare parts
284561500102	NUT PLATE ASSY BS6	TATA spare parts
284561600102	ASSY FRONT FLOOR	TATA spare parts
284561600117	ASSY FIRE EXTINGUISHER MTG BKT	TATA spare parts
284561600130	ASSY FRONT FLOOR STRETCH WINGER	TATA spare parts
284561600142	BRACKET ASSY AMPLIFIER & BATT CUTOFF SW	TATA spare parts
284561608201	PANEL REAR FLOOR	TATA spare parts
284561608203	PANEL REAR FLOOR BS6	TATA spare parts
284561608215	PANEL REAR FLOOR STRETCHED WINGER BS6	TATA spare parts
284562000101	ASSY FIREWALL	TATA spare parts
284562000103	ASSY WINDSCREEN PILLAR	TATA spare parts
284562000109	WINDSHIELD PILLAR ASSY BS6	TATA spare parts
284562200101	ASSY CROSS MEMBER WINDSCREEN UPPER	TATA spare parts
284562200108	ASSY SHOT GUN	TATA spare parts
284562200111	ASSY CROSSMEMBER WINDSCREEN UPPER	TATA spare parts
284562200119	ASSY CROSS MBR WINDSCREEN UPPER	TATA spare parts
284562200125	ASSY DASH BORAD MTG BKT LH	TATA spare parts
284562200126	ASSY DASH BORAD MTG BKT RH	TATA spare parts
284562200145	BRACKET ASSY AIR DUCT CUT OUT MTG BS6	TATA spare parts
284562208225	CROSS MEMBER WINDSCREEN UPPER	TATA spare parts
284562208226	REINF CUP	TATA spare parts
284562208244	FRESH AIR DUCT CUTOFF CL. BKT FIER WALL.	TATA spare parts
284562208253	DASH BOARD MTG BKT CENTER SUPPORT	TATA spare parts
284562208254	TOP MTG BKT DASH BOAD	TATA spare parts
284562218217	BRACKET HORN MTG BS6	TATA spare parts
284562218218	REINFORCEMENT BONNET HINGE MTG LH BS6	TATA spare parts
284562218219	REINFORCEMENT BONNET HINGE MTG RH BS6	TATA spare parts
284562600101	SIDE BONNET ASSY INNER LH BS6	TATA spare parts
284562600102	ASSY FRONT WHEEL ARCH COMPLETE LH	TATA spare parts
284562600107	ASSY FRONT WHEEL ARCH COMPLETE RH	TATA spare parts
284562600112	ASSY SIDE BONNET INNER LH	TATA spare parts

284562600113	ASSY SIDE BONNET INNER RH	TATA spare parts
284562600114	ASSY HEADLAMP MTG.LH	TATA spare parts
284562600116	ASSY HEADLAMP MTG RH	TATA spare parts
284562600124	ASSY SHOT GUN COMPLETE LH	TATA spare parts
284562600125	ASSY SHOT GUN COMPLETE RH	TATA spare parts
284562600134	ASSY FRONT WHEEL ARCH COMP. RH	TATA spare parts
284562600139	ASSY DIN MTG BKT	TATA spare parts
284562600162	SIDE BONNET ASSY INNER RH BS6	TATA spare parts
284562600171	HEADLAMP HOUSING ASSY LH BS6	TATA spare parts
284562600172	HEADLAMP HOUSING ASSY RH BS6	TATA spare parts
284562600182	BRACKET ASSY FENDER MTG TOP-FRONT-LH BS6	TATA spare parts
284562600183	BRACKET ASSY FENDER MTG TOP-FRONT-RH BS6	TATA spare parts
284562608220	SUPPORT PLATE SIDE BONNET INNER	TATA spare parts
284562608226	REINF WHEEL ARCH LOWER LH	TATA spare parts
284562608227	REINF WHEEL ARCH LOWER RH	TATA spare parts
284562608230	REINFORCEMENT WHEEL ARCH FRONT INNER RH	TATA spare parts
284562608231	REINFORCEMENT WHEEL ARCH FRONT INNER LH	TATA spare parts
284562608241	REINFORCEMENT WHEEL ARCH FRONT INNER-LH	TATA spare parts
284562608250	REINFORCEMENT WHEEL ARCH FRONT INNER-RH	TATA spare parts
284563000101	ASSY SIDE WALL COMPLETE LH	TATA spare parts
284563000102	ASSY SIDE WALL COMPLETE RH	TATA spare parts
284563000105	ASSY INNER PANEL COMPLETE LH	TATA spare parts
284563000106	ASSY INNER PANEL COMPLETE RH	TATA spare parts
284563000113	ASSY SIDE WALL COMPLETE LH	TATA spare parts
284563000114	ASSY SIDE WALL COMPLETE RH	TATA spare parts
284563000115	ASSY INNER PANEL COMPLETE LH	TATA spare parts
284563000116	ASSY INNER PANEL COMPLETE RH	TATA spare parts
284563000117	ASSY SIDEWALL COMPLETE LH	TATA spare parts
284563000118	ASSY SIDE WALL COMPLETE RH	TATA spare parts
284563000123	ASSY INNER PANEL COMPLETE	TATA spare parts
284563000124	ASSY INNER PANEL COMPLETE	TATA spare parts
284563000127	ASSY SIDEWALL COMPLETE LH	TATA spare parts
284563000130	ASSY SIDE WALL COMPLETE LH	TATA spare parts
284563000145	ASSY SIDE WALL RH	TATA spare parts
284563000147	ASSY SIDEWALL LH	TATA spare parts
284563000149	ASSY SIDEWALL COMPLETE LH	TATA spare parts
284563000150	ASSY SIDEWALL COMPLETE RH	TATA spare parts
284563000157	ASSY SIDEWALL COMPLETE LH CNG	TATA spare parts
284563000158	ASSY SIDEWALL COMP LH STRETCH WINGER AMB	TATA spare parts
284563000159	ASSY SIDEWALL COMP RH STRETCH WINGER AMB	TATA spare parts
284563000167	ASSY SIDEWALL COMP RH M1	TATA spare parts
284563000169	ASSY SIDEWALL COMPLETE LH (M1 WINGER)	TATA spare parts
284563000207	SIDE WALL ASSY LH	TATA spare parts
284563000208	SIDE WALL ASSY RH	TATA spare parts
284563000247	SIDE WALL ASSY LH BS6	TATA spare parts
284563000248	SIDE WALL ASSY RH BS6	TATA spare parts
284563000261	SIDE WALL ASSY LH BS6	TATA spare parts

284563000266	SIDE WALL ASSY RH BS6	TATA spare parts
284563000277	SIDE WALL ASSY LH BS6	TATA spare parts
284563000278	SIDE WALL ASSY RH BS6	TATA spare parts
284563000288	SIDE WALL ASSY LH BS6	TATA spare parts
284563000289	SIDE WALL ASSY RH BS6	TATA spare parts
284563100132	ASSY D PILLAR REAR COMPLETE LH	TATA spare parts
284563100133	ASSY D PILLAR REAR COMPLETE RH	TATA spare parts
284563100184	BRACKET ASSY A-PILLAR LH BS6	TATA spare parts
284563100185	BRACKET ASSY A-PILLAR RH BS6	TATA spare parts
284563200101	ASSY HINGE LOWER MALE BS6	TATA spare parts
284563200102	ASSY HINGE UPPER MALE LH BS6	TATA spare parts
284563200103	ASSY HINGE UPPER MALE RH BS6	TATA spare parts
284563200106	ASSY FRONT DOOR APERTURE LH	TATA spare parts
284563200107	ASSY FRONT DOOR APERTURE	TATA spare parts
284563200111	ASSY REAR CORNER OUTER LH	TATA spare parts
284563200112	ASSY REAR CORNER OUTER RH	TATA spare parts
284563200123	ASSY REINF B PILLAR COMPLETE LH BS6	TATA spare parts
284563200124	ASSY REINF B PILLAR COMPLETE RH BS6	TATA spare parts
284563200127	ASSY SEAT BELT ANCHORAGE B PILLAR UPPER	TATA spare parts
284563200154	ASSY REAR SIDE WINDOW LH	TATA spare parts
284563200155	ASSY FRONT SIDE WINDOW RH	TATA spare parts
284563200157	ASSY REAR SIDE WINDOW RH	TATA spare parts
284563200170	ASSY PANEL FRONT SIDE RH	TATA spare parts
284563200178	ASSY PANEL REAR SIDE LH	TATA spare parts
284563200179	ASSY PANEL REAR SIDE RH	TATA spare parts
284563200186	ASSY REAR CORNER OUTER LH	TATA spare parts
284563200187	ASSY REAR CORNER OUTER RH	TATA spare parts
284563200192	ASSY PANEL REAR SIDE LH	TATA spare parts
284563208213	RAIL CENTER LH	TATA spare parts
284563208273	CANTRAIL REAR LH BS6	TATA spare parts
284563208274	CANTRAIL REAR RH BS6	TATA spare parts
284563210102	ASSY FRONT DOOR APERTURE LH	TATA spare parts
284563210103	ASSY FRONT DOOR APERTURE RH	TATA spare parts
284563210106	ASSY OUTER PANEL LATERAL	TATA spare parts
284563210130	ASSY INNER PANEL FRONT CANTRAIL COMP LH	TATA spare parts
284563210133	ASSY INNER PANEL FRONT CANTRAIL RH BS6	TATA spare parts
284563210134	ASSY REAR SIDE WINDOW LH	TATA spare parts
284563210141	ASSY REAR SIDE WINDOW RH	TATA spare parts
284563210157	ASSY PANEL REAR SIDE RH	TATA spare parts
284563210158	ASSY PANEL REAR SIDE LH	TATA spare parts
284563218218	BRACKET REAR BUMPER FIXING BS6	TATA spare parts
284563218224	FRAME FRONT SIDE WINDOW INNER LOWER BS6	TATA spare parts
284563218228	FRAME REAR SIDE WINDOW UPPER BS6	TATA spare parts
284563218229	FRAME WINDOW UPPER BS6	TATA spare parts
284563218256	CANTRAIL REAR LH BS6	TATA spare parts
284563218257	CANTRAIL REAR RH BS6	TATA spare parts
284563218260	INNER PANER CANTRAIL REAR LH BS6	TATA spare parts

284563218261	INNER PANEL REAR CANTRAIL RH BS6	TATA spare parts
284563218266	INNER PANEL MIDDLE CANTRAIL RH BS6	TATA spare parts
284563218269	FRAME WINDOW LOWER BS6	TATA spare parts
284563218283	INNER PANEL MIDDLE CANTRAIL LH BS6	TATA spare parts
284563218284	MIDDLE CANTRAIL LH BS6	TATA spare parts
284563218288	FRAME WINDOW UPPER BS6	TATA spare parts
284563218299	SPACER FOR FIRE EXTINGUISHER. BS6	TATA spare parts
284563228217	MIDDLE CANTRAIL RH BS6	TATA spare parts
284563228249	INNER PANEL REAR CANTRAIL STAGE 1 RH BS6	TATA spare parts
284563228269	MAGNET MOUNTING BRACKET BS6	TATA spare parts
284563230180	ASSY EXP BAFFLE FOR SHOT GUN BS6	TATA spare parts
284563230181	ASSY EXP BAFFLE FOR FOOTSTEP SILL INR LH	TATA spare parts
284563230182	ASSY EXP BAFFLE FOR FOOTSTEP SILL IER RH	TATA spare parts
284563230183	ASSY EXP BAFFLE FOR WHEEL ARCH FRONT LH	TATA spare parts
284563230184	ASSY EXP BAFFLE FOR WHEEL ARCH FRONT RH	TATA spare parts
284563230186	ASSY EXP BAFFLE FOR SIDE BONNET INNER BS	TATA spare parts
284563238276	OUTER CORNER PANEL REAR-LH BS6	TATA spare parts
284563238290	OUTER CORNER PANEL REAR-RH BS6	TATA spare parts
284563240102	PANEL ASSY D-PILLAR REAR CORNER OUTER-RH	TATA spare parts
284563240104	BRACKET ASSY REAR BUMPER MTG LH BS6	TATA spare parts
284563240109	REAR BUMPER CORNER MTG ASSY LH BS6	TATA spare parts
284563240112	BRACKET ASSY REAR BUMPER MTG RH BS6	TATA spare parts
284563240116	REAR BUMPER CORNER MTG ASSY RH BS6	TATA spare parts
284565000105	ASSY ROOF COMPLETE CED COATED	TATA spare parts
284565000117	ROOF ASSY(STRETCH AMBU-AC+REVLVNG LAMP	TATA spare parts
284565000120	PANEL ASSY ROOF MIDDLE	TATA spare parts
284565000122	PANEL ASSY ROOF MIDDLE BS6	TATA spare parts
284565000124	ROOF ASSY BS6	TATA spare parts
284565000127	ROOF ASSY BS6	TATA spare parts
284565000150	ROOF ASSY BS6	TATA spare parts
284565100101	ASSY CROSS MEMBER UPPER REAR	TATA spare parts
284565100105	ASSY STIFFNER ROOF	TATA spare parts
284565100106	ASSY STIFFNER ROOF FRONT	TATA spare parts
284565100107	ASSY CROSSMEMBER UPPER REAR	TATA spare parts
284565100109	ASSY STIFFNER ROOF FRONT	TATA spare parts
284565100110	ASSY STIFFNER ROOF CENTRE BS6	TATA spare parts
284565100111	ASSY STIFFNER ROOF REAR	TATA spare parts
284565100112	ASSY STIFFNER ROOF FRONT PILLAR	TATA spare parts
284565100117	ASSY STIFFNER HEADLINER FRONT LH BS6	TATA spare parts
284565100118	ASSY STIFFNER HEADLINER FRONT RH BS6	TATA spare parts
284565100125	ASSY STIFFNER ROOF CENTER LWB HR STR	TATA spare parts
284565100129	ASSY TUBE LIGHT MTG BKT REAR	TATA spare parts
284565100131	STIFFENER ASSY ROOF FRONT PILLAR BS6	TATA spare parts
284565100134	ASSY TUBE LIGHT BKT REAR EXTEN.	TATA spare parts
284565100135	ASSY FRONT STIFFNER HEADLINER FLAT ROOF	TATA spare parts
284565100140	STIFFENER ASSY ROOF REAR BS6	TATA spare parts
284565100146	TUBE ASSY LIGHT BKT REAR BS6	TATA spare parts

284565100156	STIFFENER ASSY ROOF REAR BS6	TATA spare parts
284565100157	STIFFENER ASSY ROOF BS6	TATA spare parts
284565100171	BRACKET ASSY AC UNIT MTG LH BS6	TATA spare parts
284565100177	BRACKET ASSY AC UNIT MTG LH BS6	TATA spare parts
284565100178	BRACKET ASSY BS6	TATA spare parts
284565100179	CROSS MEMBER ASSY-UPPER-REAR BS6	TATA spare parts
284565100183	BRACKET ASSY BS6	TATA spare parts
284565100186	BRACKET ASSY BS6	TATA spare parts
284565100187	BRACKET ASSY BS6	TATA spare parts
284565100192	BRACKET ASSY BS6	TATA spare parts
284565103346	CHANNEL SUPPORT BS6	TATA spare parts
284565106303	REINFORCEMENT BS6	TATA spare parts
284565108233	BRACKET ROOF STIFFNER FRONT	TATA spare parts
284565108234	REINF REV LAMP MTG	TATA spare parts
284565108273	TAIL GATE SWITCH MTG BKT	TATA spare parts
284565200107	CHANNEL ASSY REINF ROOF SIDE BS6	TATA spare parts
284565200111	CHANNEL ASSY REINF ROOF SIDE BS6	TATA spare parts
284565700101	ASSY ROOF PANEL	TATA spare parts
284565700103	ASSY ROOF BOW AC UNIT COMPLETE	TATA spare parts
284565700104	ASSY AC UNIT MOUNTING BRACKET LH BS6	TATA spare parts
284565700105	ASSY AC UNIT MOUNTING BRACKET RH BS6	TATA spare parts
284565700107	HIGH DOM ROOF BOW	TATA spare parts
284565700111	ASSY ROOF (AMBULANCE)	TATA spare parts
284565700129	ASSY ROOF BOW AC UNIT HR COMP. ST AMBULA	TATA spare parts
284565700142	BRACKET ASSY BS6	TATA spare parts
284565708201	ROOF	TATA spare parts
284565708202	PANEL ROOF REAR	TATA spare parts
284565708203	PANEL ROOF CENTRE	TATA spare parts
284565708204	PANEL ROOF FRONT	TATA spare parts
284565708205	PANEL ROOF SIDE FRONT LH	TATA spare parts
284565708206	PANEL ROOF SIDE FRONT RH	TATA spare parts
284565708207	PANEL ROOF SIDE REAR LH	TATA spare parts
284565708208	PANEL ROOF SIDE REAR RH	TATA spare parts
284565708211	MOUNTING CUP ROOF	TATA spare parts
284565708218	CAP (CARGO ROOF)	TATA spare parts
284565708221	PANEL ROOF LATERAL EXTENSION	TATA spare parts
284565708222	PANEL ROOF LATERAL EXTENSION RH	TATA spare parts
284565708223	PANEL CENTER ROOF EXTENSION	TATA spare parts
284565708224	PANEL ROOF CENTER (STRETCH AMBULANCE)	TATA spare parts
284565708240	PANEL ROOF CENTER BS6-PH2	TATA spare parts
284565708244	PANEL ROOF REAR STR AMBULANCE	TATA spare parts
284566106320	COVER LUGGAGE AREA RH BS6-PH2	TATA spare parts
284566106321	COVER LUGGAGE AREA TOP BS6-PH2	TATA spare parts
284566106322	COVER LUGGAGE AREA BOTTOM BS6-PH2	TATA spare parts
284566106323	FLOOR MAT LUGGAGE AREA BS6-PH2	TATA spare parts
284567102301	WINDSHIELD GLASS BS2/3/4	TATA spare parts
284567102303	WINDSHIELD GLASS(W/BAND-TOP PROP) BS3/4	TATA spare parts

284567107701	WINDSCREEN GLASS RUBBER MOULD BS2/3/4	TATA spare parts
284567300101	SLIDING GLASS ASSY FRONT LH	TATA spare parts
284567300102	SLIDING GLASS ASSY FRONT RH	TATA spare parts
284567300103	SLIDING GLASS ASSY REAR LH 2800WB	TATA spare parts
284567300104	SLIDING GLASS ASSY REAR RH 2800WB	TATA spare parts
284567300105	SLIDING GLASS ASSY REAR LH (3200WB)	TATA spare parts
284567300106	SLIDING GLASS ASSY REAR RH(3200WB)	TATA spare parts
284567300107	SLIDING GLASS ASSY FRONT LH (AC VERSION)	TATA spare parts
284567300108	SLIDING GLASS ASSY FRONT RH (AC VERSION)	TATA spare parts
284567300109	SLIDING GLASS ASSY REAR LH(AC-VER 3200WB	TATA spare parts
284567300110	SLIDING GLASS ASSY REAR RH(AC VER 3200WB	TATA spare parts
284567300111	ASSY SLIDING GLASS FRONT LH	TATA spare parts
284567300112	ASSY SLIDING GLASS FRONT RH(CLEAR GLASS	TATA spare parts
284567300113	ASSY SLIDING GLASS REAR LH	TATA spare parts
284567300114	ASSY SLIDING GLASS REAR RH	TATA spare parts
284567300115	SLIDING GLASS ASSY REAR LH 3200WB(AW)	TATA spare parts
284567300116	SLIDING GLASS ASSY REAR RH	TATA spare parts
284567300117	SLIDING GLASS ASSY FRONT LH	TATA spare parts
284567300118	SLIDING GLASS ASSY FRONT RH	TATA spare parts
284567300119	ASSY SLIDING GLASS REAR LH	TATA spare parts
284567300120	ASSY SLIDING GLASS REAR RH	TATA spare parts
284567300134	SLIDING GLASS ASSY REAR LH M1 WINGER	TATA spare parts
284567300135	SLIDING GLASS ASSY REAR RH M1 WINGER	TATA spare parts
284567302301	FIXED GLASS RH SIDE ASSY	TATA spare parts
284567302302	FIXED TINTED GLASS SIDE WINDOW REAR-RH	TATA spare parts
284567306101	DP LOCK SET WITH TAPER MB	TATA spare parts
284567306102	DP LOCK SET WITH TAPER MB WITH GROMET	TATA spare parts
284567307701	FRONT SLIDING GLASS ASSY RUBBER MOULD	TATA spare parts
284567307702	REAR SLIDING GLASS RUBBER MOULD LH	TATA spare parts
284567307703	REAR SLIDING GLASS RUBBER MOULD LH3200WB	TATA spare parts
284567307704	REAR SLIDING GLASS RUBBER MOULD RH3200WB	TATA spare parts
284567307706	RUBBER MOULD FIXED SIDE WINDOW	TATA spare parts
284567307707	"RUBBER MOULD, FIXED GLASS, RH"	TATA spare parts
284567507701	TILT WINDOW GLASS RUBBER	TATA spare parts
284568206306	INSULATION FENDER RHS	TATA spare parts
284568206307	INSULATION FENDER LHS	TATA spare parts
284568206308	INSULATION BONNET	TATA spare parts
284568206309	INSULATION LHS DASHBOARD	TATA spare parts
284568206310	INSULATION RHS DASHBOARD	TATA spare parts
284568206312	INSULATION INSIDE DASHBOARD	TATA spare parts
284568206317	INSULATION ENGINE HOOD M1 WINGER	TATA spare parts
284568206318	INSULATION ENGINE HOOD INNER AC VERSION	TATA spare parts
284568206323	INSULATION FIREWALL NON AC VERSION BS6	TATA spare parts
284568206324	REINFPAD (AFTER CED)	TATA spare parts
284568400101	FRONT CARPET ASSY	TATA spare parts
284568400102	REAR CARPET ASSY SWB	TATA spare parts
284568400103	REAR CARPET ASSY 3200LWB NON AC	TATA spare parts

284568400104	FRONT CARPET ASSY AMBULANCE VERSION	TATA spare parts
284568400105	FRONT CARPET ASSY(CLOSED GOODS LWB)	TATA spare parts
284568400107	REAR CARPET ASSY 3200 LWB AC VERSION	TATA spare parts
284568400108	REAR CARPET ASSY 3200 LWB CNG VERSION	TATA spare parts
284568400109	REAR CARPET(PLATFORM STEP)ASSY LWB CNG	TATA spare parts
284568400112	ASSY FRONT CARPET. (M1 WINGER)	TATA spare parts
284568400113	ASSY REAR CARPET. (M1 WINGER)	TATA spare parts
284568400115	ASSY FRONT CARPET	TATA spare parts
284568400121	CARPET ASSY FRONT	TATA spare parts
284568400124	CARPET ASSY FRONT	TATA spare parts
284568400125	CARPET ASSY FRONT BS6	TATA spare parts
284568400126	CARPET ASSY FRONT BS6	TATA spare parts
284568400127	CARPET ASSY FRONT BS6	TATA spare parts
284568400128	CARPET ASSY FRONT BS6	TATA spare parts
284568400129	CARPET ASSY FRONT BS6	TATA spare parts
284568400138	CARPET ASSY REAR FLOOR BS6-PH2	TATA spare parts
284568406301	CARPET WHEEL ARCH LH	TATA spare parts
284568406302	CARPET WHEEL ARCH RH	TATA spare parts
284568406307	MEL SHEET FRONT FLOOR SIDE 970X575	TATA spare parts
284568406308	MEL SHEET FRONT FLOOR CENTRE 470X445	TATA spare parts
284568706307	MEL SHEET FRONT WHEEL ARCH	TATA spare parts
284568706308	MEL SHEET REAR WHEEL ARCH	TATA spare parts
284568900101	DASHBOARD BODY RHD BARE	TATA spare parts
284568900102	DASHBOARD BODY RHD ASSY	TATA spare parts
284568900104	DISTRIBUTION CHAMBER	TATA spare parts
284568900105	DASHBOARD BODY RHD ASSY3200 FLAT	TATA spare parts
284568900110	AIR MANIFOLD	TATA spare parts
284568900112	ASH TRAY ASSY	TATA spare parts
284568900115	ASSY HEATER & BLOWER UNIT	TATA spare parts
284568900116	ASSY COVER HEATING CONTROL	TATA spare parts
284568900117	ASSY COVER UNIT WITHOUT HEATER	TATA spare parts
284568900118	FRESH AIR KIT	TATA spare parts
284568900119	DASHBOARD BODY RHD BARE	TATA spare parts
284568900120	ASH TRAY ASSY	TATA spare parts
284568900121	AIR VENT ASSY LH	TATA spare parts
284568900122	AIR VENT ASSY RH	TATA spare parts
284568900123	AIR VENT ASSY LH	TATA spare parts
284568900124	AIR VENT ASSY RH	TATA spare parts
284568900125	SECOND ROW AIRVENT ASSY	TATA spare parts
284568900125AQ	LINEN-SECOND ROW AIRVENT ASSY ENGINETECH	TATA spare parts
284568900126	ASSY VENT NOZZLE LH	TATA spare parts
284568900126C7	GRANIT_BLACK-VENTILATION NOZZLE ASSY LH	TATA spare parts
284568900127	ASSY COVER FRESH AIR & BLOWER UNIT	TATA spare parts
284568900128	ASSY LEVER HOUSING FRESH AIR	TATA spare parts
284568900129	ASSY LEVER HOUSING HEATER	TATA spare parts
284568900130	ASSY COVER UNIT(FRHAIR&HEATER)	TATA spare parts
284568900132	ASSY VENT NOZZLE RH	TATA spare parts



284568900133	DASHBOARD BODY RHD ASSY AMBULANCE	TATA spare parts
284568900136	SECOND ROW AIRVENT ASSY	TATA spare parts
284568900138	ASSY DASHBOARD BODY RHD BARE	TATA spare parts
284568900139	DASH BOARD ASSY RHD COMPLETE	TATA spare parts
284568900140	ASSY DIN COVER	TATA spare parts
284568900143	DASHBOARD	TATA spare parts
284568900145	DASHBOARD ASSY BS6	TATA spare parts
284568900145ZY	CLRPRT_ASY_1-DASHBOARD ASSY BS6	TATA spare parts
284568900145ZZ	CLRPART_ASSY-DASHBOARD ASSY BS6	TATA spare parts
284568900165	DASHBOARD ASSY BS6	TATA spare parts
284568900165ZZ	DASHBOARD ASSY	TATA spare parts
284568900311	RADIO SUPPORT LUG	TATA spare parts
284568906301	LID CENTRAL GLOVE BOX	TATA spare parts
284568906303	LID CENTRAL GLOVE BOX	TATA spare parts
284568906304	GLOVE BOX UPPER	TATA spare parts
284568906307	TOP NACELLE	TATA spare parts
284568906308	BOTTOM NACELLE	TATA spare parts
284568906310	DEMISTING DUCT	TATA spare parts
284568906311	GLOVE BOX UPPER	TATA spare parts
284568906312	ACCESS FLAP	TATA spare parts
284568906313	DASHBOARD VISOR	TATA spare parts
284568906314	COWL SEALING	TATA spare parts
284568906315	CLIP-DASHBOARD UPPER	TATA spare parts
284568906322	RADIO PACKAGE TRAY	TATA spare parts
284568906323	GLOVE BOX STRIP	TATA spare parts
284568906324	ACCESS FLAP	TATA spare parts
284568906325	NOZZLE OF DEMISTING	TATA spare parts
284568906326	NOZZLE AIR DUCT LH	TATA spare parts
284568906328	DASHBOARD VISOR	TATA spare parts
284568906331	TOP NACELLE	TATA spare parts
284568906332	BOTTOM NACELLE	TATA spare parts
284568906335	RADIO PACKAGE TRAY	TATA spare parts
284568906342	PASSENGER PACKAGE TRAY INNER	TATA spare parts
284568906343	SCUFF PLATE LH	TATA spare parts
284568906344	SCUFF PLATE RH	TATA spare parts
284568906345	GLOVE BOX STRIP	TATA spare parts
284568906356	FRESH AIR CONTROL KNOB	TATA spare parts
284568906357	HEATER CONTROL SWITCH KNOB	TATA spare parts
284568906361	DIN COVER	TATA spare parts
284568906365	MUSIC SYSTEM BAZEL	TATA spare parts
284568907701	RUBBER MOULD AIR MANIFOLD	TATA spare parts
284568907704	RUBBER HOSE DRAIN AIR MANIFOLD	TATA spare parts
284568907705	BONNET FOAM	TATA spare parts
284568907708	LINING DASHBOARD GLOVE BOX	TATA spare parts
284568908209	AIR DUCT BASE PLATE RH	TATA spare parts
284568910101	CENTRAL CLUSTER FRAME FASCIA ASSY (FOR S	TATA spare parts
284568910101CE	PIANO_BK_PLN-CENTRAL CLUSTER FRAME ASSY	TATA spare parts

284568910103	CENTRAL CLUSTER FRAME FASCIA ASSY (FOR 7	TATA spare parts
284568910103CE	CENTRAL CLUSTER FRAME ASSY	TATA spare parts
284568910105	BEZEL ASSY INSTRUMENT CLUSTER BS6	TATA spare parts
284568910105C7	BEZEL ASSY_INSTRUMENT CLUSTER	TATA spare parts
284568910106	COVER ASSY AC CONTROL FRONT AC TRIM BS6	TATA spare parts
284568910106ZZ	CLRPART_ASSY-COVER ASSY AC CONTROL	TATA spare parts
284568910107	BRACKET BOTTOM LH BS6	TATA spare parts
284568910108	BRACKET RH-AC TRIM BS6	TATA spare parts
284568910109	BRACKET LH-AC TRIM BS6	TATA spare parts
284568910110	BRACKET BOTTOM RH BS6	TATA spare parts
284568916315C7	GRANIT_BLACK-COVER AIR VENT DASHBOARD LH	TATA spare parts
284568916318C7	GRANIT_BLACK-COVER AIR VENT DASHBOARD SI	TATA spare parts
284568916321C7	GRANIT_BLACK-AIR VENT BEZEL HOUSING BS6	TATA spare parts
284568916329C7	GRANIT_BLACK-AIR VENT BEZEL HOUSING BS6	TATA spare parts
284568916331	NACELLE LOWER BS6	TATA spare parts
284568916331C7	GRANIT_BLACK-NACELLE LOWER	TATA spare parts
284568916332	NACELLE TOP BS6	TATA spare parts
284568916332C7	GRANIT_BLACK-NACELLE TOP	TATA spare parts
284568916333C7	GRANIT_BLACK-DASHBOARD CO-DRIVER SIDE LO	TATA spare parts
284568916336	COVER UNIT-ECU BS6	TATA spare parts
284568916336C7	GRANIT_BLACK-COVER UNIT	TATA spare parts
284568916346	COVER AC CONTROL CUT OUT BS6	TATA spare parts
284568916348C7	GRANIT_BLACK-DASHBOARD MAIN SKIN BS6	TATA spare parts
284569100101	ASSY A PILLAR LH (M1 WINGER)	TATA spare parts
284569100102	ASSY A PILLAR RH (M1 WINGER)	TATA spare parts
284569100103	ASSY B PILLAR TRIM UPPER LH.(M1 WINGER)	TATA spare parts
284569100104	ASSY B PILLAR TRIM UPPER RH. (M1 WINGER)	TATA spare parts
284569100105	ASSY B PILLAR TRIM LOWER LH. (M1 WINGER)	TATA spare parts
284569100106	ASSY B PILLAR TRIM LOWER RH. (M1 WINGER)	TATA spare parts
284569100107	ASSY C PILLAR TRIM UPPER LH. (M1 WINGER)	TATA spare parts
284569100108	ASSY C PILLAR TRIM UPPER RH. (M1 WINGER)	TATA spare parts
284569100109	ASSY C PILLAR TRIM LOWER LH. (M1 WINGER)	TATA spare parts
284569100110	ASSY C PILLAR TRIM LOWER RH. (M1 WINGER)	TATA spare parts
284569100111	ASSY D PILLAR TRIM UPPER LH. (M1 WINGER)	TATA spare parts
284569100112	ASSY D PILLAR TRIM UPPER RH. (M1 WINGER)	TATA spare parts
284569100113	ASSY D PILLAR TRIM LOWER LH. (M1 WINGER)	TATA spare parts
284569100114	ASSY D PILLAR TRIM LOWER RH. (M1 WINGER)	TATA spare parts
284569100115	ASSY SCUFF PLATE SLIDING DOOR.	TATA spare parts
284569106310	FRONT PAD LOWER LH LWB	TATA spare parts
284569106311	FRONT PAD LOWER RH LWB(CLOSED VAN)	TATA spare parts
284569106313	REAR PAD LOWER RH LWB(CLOSED VAN)	TATA spare parts
284569106317	REAR PAD LOWER LH LWB	TATA spare parts
284569106327	A PILLAR TRIM LH	TATA spare parts
284569106328	TRIM RH G004	TATA spare parts
284569106329	B PILLAR TRIM UPPER LH	TATA spare parts
284569106330	B PILLAR TRIM UPPER RH	TATA spare parts
284569106331	B PILLAR TRIM LOWER LH	TATA spare parts

284569106332	B PILLAR TRIM LOWER RH	TATA spare parts
284569106333	C PILLAR TRIM UPPER LH	TATA spare parts
284569106334	C PILLAR TRIM UPPER RH	TATA spare parts
284569106334AQ	LINEN-C PILLAR TRIM UPPER RH G004 BS6-PH	TATA spare parts
284569106335	C PILLAR TRIM LOWER LH	TATA spare parts
284569106336	C PILLAR TRIM LOWER RH	TATA spare parts
284569106337	D PILLAR TRIM UPPER LH	TATA spare parts
284569106337AQ	LINEN-D PILLAR TRIM UPPER LH G004 BS6	TATA spare parts
284569106338	D PILLAR TRIM UPPER RH	TATA spare parts
284569106338AQ	LINEN-D PILLAR TRIM UPPER RH BS6	TATA spare parts
284569106339	D PILLAR TRIM LOWER LH	TATA spare parts
284569106340	D PILLAR TRIM LOWER RH	TATA spare parts
284569106340C7	GRANIT_BLACK-D PILLAR TRIM LOWER RH G001	TATA spare parts
284569106341	BODYSIDE TRIM FRONT UPPER RH	TATA spare parts
284569106342	BODYSIDE TRIM FRONT LOWER RH	TATA spare parts
284569106343	BODYSIDE TRIM REAR UPPER LH	TATA spare parts
284569106344	BODYSIDE TRIM REAR UPPER RH	TATA spare parts
284569106345	BODYSIDE TRIM REAR LOWER LH	TATA spare parts
284569106346	BODYSIDE TRIM REAR LOWER RH	TATA spare parts
284569106347	BODYSIDE TRIM REAR UPPER LH	TATA spare parts
284569106348	BODYSIDE TRIM REAR UPPER RH	TATA spare parts
284569106349	BODYSIDE TRIM REAR LOWER LH	TATA spare parts
284569106350	BODYSIDE TRIM REAR LOWER RH	TATA spare parts
284569106351	A PILLAR TRIM LH	TATA spare parts
284569106351AQ	LINEN-A PILLAR TRIM LH B001 BS6	TATA spare parts
284569106352	A PILLAR TRIM RH	TATA spare parts
284569106352AQ	LINEN-A PILLAR TRIM RH B001 BS6	TATA spare parts
284569106353	B PILLAR TRIM UPPER LH	TATA spare parts
284569106353AQ	LINEN-B PILLAR TRIM UPPER LH B001 BS6	TATA spare parts
284569106354	B PILLAR TRIM UPPER RH	TATA spare parts
284569106354AQ	LINEN-B PILLAR TRIM UPPER RH B001 BS6	TATA spare parts
284569106355	B PILLAR TRIM LOWER LH	TATA spare parts
284569106356	B PILLAR TRIM LOWER RH	TATA spare parts
284569106356C7	GRANIT_BLACK-B PILLAR TRIM LOWER RH B002	TATA spare parts
284569106357	C PILLAR TRIM UPPER LH	TATA spare parts
284569106357AQ	LINEN-C PILLAR TRIM UPPER LH B001 BS6	TATA spare parts
284569106358	C PILLAR TRIM UPPER RH	TATA spare parts
284569106359	C PILLAR TRIM LOWER LH	TATA spare parts
284569106359C7	GRANIT_BLACK-C PILLAR TRIM LOWER LH B002	TATA spare parts
284569106360	C PILLAR TRIM LOWER RH	TATA spare parts
284569106360C7	GRANIT_BLACK-C PILLAR TRIM LOWER RH B002	TATA spare parts
284569106361	D PILLAR TRIM UPPER LH	TATA spare parts
284569106361AQ	LINEN-D PILLAR TRIM UPPER LH B001 BS6	TATA spare parts
284569106362	D PILLAR TRIM UPPER RH	TATA spare parts
284569106362AQ	LINEN-D PILLAR TRIM UPPER RH B001 BS6	TATA spare parts
284569106363	D PILLAR TRIM LOWER LH	TATA spare parts
284569106363C7	GRANIT_BLACK-D PILLAR TRIM LOWER LH B002	TATA spare parts

284569106364	D PILLAR TRIM LOWER RH	TATA spare parts
284569106364C7	GRANIT_BLACK-D PILLAR TRIM LOWER RH B002	TATA spare parts
284569106365	BODYSIDE TRIM FRONT UPPER RH	TATA spare parts
284569106365AQ	LINEN-BODYSIDE TRIM FRONT UPPER RH B001	TATA spare parts
284569106366	BODYSIDE TRIM FRONT LOWER RH	TATA spare parts
284569106366C7	GRANIT_BLACK-BODYSIDE TRIM FRONT LOWER R	TATA spare parts
284569106367	BODYSIDE TRIM REAR UPPER LH	TATA spare parts
284569106367AQ	LINEN-BODYSIDE TRIM REAR UPPER LH 3200FR	TATA spare parts
284569106368	BODYSIDE TRIM REAR UPPER RH	TATA spare parts
284569106368AQ	LINEN-BODYSIDE TRIM REAR UPPER RH 3200FR	TATA spare parts
284569106369	BODYSIDE TRIM REAR LOWER LH	TATA spare parts
284569106370	BODYSIDE TRIM REAR LOWER RH	TATA spare parts
284569106370C7	GRANIT_BLACK-BODYSIDE TRIM REAR LOWER RH	TATA spare parts
284569106375	B PILLAR TRIM LOWER LH	TATA spare parts
284569106376	B PILLAR TRIM UPPER LH	TATA spare parts
284569106377	D PILLAR TRIM UPPER LH	TATA spare parts
284569106378	BODYSIDE TRIM REAR LOWER LH	TATA spare parts
284569106379	BODYSIDE TRIM REAR LOWER LH	TATA spare parts
284569106382	BODY SIDE TRIM REAR LOWER LH	TATA spare parts
284569106382C7	GRANIT_BLACK-BODY SIDE TRIM REAR LOWER L	TATA spare parts
284569106385	B PILLAR TRIM UPPER LH	TATA spare parts
284569106389	PLASTIC COVER REAR CR-MBR	TATA spare parts
284569106396	B PILLAR TRIM LOWER LH	TATA spare parts
284569106397	C PILLAR TRIM UPPER RH	TATA spare parts
284569106397AQ	LINEN-C PILLAR TRIM UPPER RH B001(AMBULA	TATA spare parts
284569106398	C PILLAR TRIM UPPER LH B001(AMBULANCE)	TATA spare parts
284569106399	D PILLAR TRIM UPPER LH	TATA spare parts
284569106403	B PILLAR BELT GUIDE LH (M1 WINGER	TATA spare parts
284569106403BN	B PILLAR BELT GUIDE LH (M1 WINGER)	TATA spare parts
284569106404BN	B PILLAR BELT GUIDE RH (M1 WINGER)	TATA spare parts
284569106405BN	C PILLAR BELT GUIDE RH (M1 WINGER)	TATA spare parts
284569106406	D PILLAR BELT GUIDE LH (M1 WINGER	TATA spare parts
284569106406BN	D PILLAR BELT GUIDE LH (M1 WINGER)	TATA spare parts
284569106407BN	D PILLAR BELT GUIDE RH (M1 WINGER)	TATA spare parts
284569106418	PARKING BRAKE BAZEL	TATA spare parts
284569116307	BODY SIDE TRIM REAR LOWER LH CNG G001N B	TATA spare parts
284569116325	BODY SIDE TRIM REAR-UPPER-RH28/3488 B001	TATA spare parts
284569116325AQ	LINEN-BODY SIDE TRIM REAR-UPPER-RH28/348	TATA spare parts
284569116326	BODY SIDE TRIM FRONT-LOWER-LH (AMB)B002	TATA spare parts
284569116326C7	GRANIT_BLACK-BODY SIDE TRIM FRONT-LOWER-	TATA spare parts
284569116330	SIDE TRIM LH RR 3488WB BOO2	TATA spare parts
284569116330C7	GRANIT_BLACK-SIDE TRIM LH BS6	TATA spare parts
284569116331	SIDE PANEL TRIM RH RR 3488WB BOO2	TATA spare parts
284569116331C7	GRANIT_BLACK-SIDE TRIM RH BS6	TATA spare parts
284569116334	B-PILLAR TRIM LOWER-LH	TATA spare parts
284569116335	B-PILLAR TRIM LOWER-LH BS6	TATA spare parts
284569116336	B-PILLAR TRIM LOWER-LH BS6	TATA spare parts

284569116337	B-PILLAR TRIM LOWER-LH	TATA spare parts
284569116338	FRONT PAD LOWER-LH BS6	TATA spare parts
284569116339	REAR PAD LOWER-RH BS6	TATA spare parts
284569116351	B-PILLAR TRIM LOWER-LH BS6	TATA spare parts
284569116351C7	GRANIT_BLACK-B-PILLAR TRIM LOWER-LH BS6	TATA spare parts
284569116353AQ	LINEN-CAP SCREW BS6	TATA spare parts
284569136301	B-PILLAR TRIM UPPER-RH 3488WB B001	TATA spare parts
284569136301AQ	LINEN-B-PILLAR TRIM UPPER-RH BS6	TATA spare parts
284569136302	B-PILLAR TRIM UPPER-LH W/SLD 3488	TATA spare parts
284569136303	B-PILLAR TRIM UPPER-LH	TATA spare parts
284569136303AQ	LINEN-B-PILLAR TRIM UPPER-LH BS6	TATA spare parts
284569136304	B PILLAR TRIM- UPPER LH BS6	TATA spare parts
284569136304AQ	LINEN-B-PILLAR TRIM UPPER-LH BS6	TATA spare parts
284569136305	BODY SIDE TRIM REAR UPPER LH BS6	TATA spare parts
284569136305AQ	LINEN-TRIM BODY REAR UPPER-LH BS6	TATA spare parts
284569136306	BODY SIDE TRIM REAR UPPER RH BS6	TATA spare parts
284569136306AQ	LINEN-TRIM BODY REAR UPPER-RH BS6	TATA spare parts
284569136307	B PILLAR TRIM- UPPER RH BS6	TATA spare parts
284569136307AQ	LINEN-B-PILLAR TRIM UPPER-RH BS6	TATA spare parts
284569136312AQ	LINEN-B-PILLAR TRIM UPPER-LH BS6-PH2	TATA spare parts
284569136316C7	GRANIT_BLACK-B-PILLAR TRIM LOWER-LH BS6-	TATA spare parts
284569146301	C-PILLAR TRIM UPPER-LH	TATA spare parts
284569146302	C-PILLAR TRIM UPPER-RH	TATA spare parts
284569146303	C-PILLAR LOWER-LH 3488 B002	TATA spare parts
284569146303C7	GRANIT_BLACK-C-PILLAR LOWER-LH BS6	TATA spare parts
284569146304	C-PILLAR TRIM LOWER-RH 3488 B002	TATA spare parts
284569146304C7	GRANIT_BLACK-C-PILLAR TRIM LOWER-RH BS6	TATA spare parts
284569146305	C-PILLAR TRIM UPPER-RH	TATA spare parts
284569146305AQ	LINEN-C-PILLAR TRIM UPPER-RH BS6	TATA spare parts
284569146306	C-PILLAR TRIM UPPER-RH	TATA spare parts
284569146309	C PILLAR TRIM- LOWER RH BS6	TATA spare parts
284569146309AQ	LINEN-C-PILLAR TRIM UPPER-RH BS6	TATA spare parts
284569146310	C PILLAR TRIM- UPPER LH BS6	TATA spare parts
284569156301	D-PILLAR TRIM LOWER-LH 3488WB BOO2	TATA spare parts
284569156301C7	GRANIT_BLACK-D-PILLAR TRIM ASSY LOWER-LH	TATA spare parts
284569156302	D-PILLAR TRIM LOWER-RH 3488WB BOO2	TATA spare parts
284569156302C7	GRANIT_BLACK-D-PILLAR TRIM LOWER-RH BS6	TATA spare parts
284569156305C7	GRANIT_BLACK-D-PILLAR TRIM LOWER-LH BS6	TATA spare parts
284569156306C7	GRANIT_BLACK-D-PILLAR TRIM LOWER-RH BS6	TATA spare parts
284569166301	WASHER BS6	TATA spare parts
284569176301	BODYSIDE TRIM REAR LOWER LH SWB	TATA spare parts
284569176302	BODY SIDE TRIM REAR UPPER LH BS6	TATA spare parts
284569176302AQ	LINEN-BODY SIDE TRIM REAR-UPPER-LH BS6	TATA spare parts
284569176303	BODY SIDE TRIM REAR UPPER RH BS6	TATA spare parts
284569176303AQ	LINEN-BODY SIDE TRIM REAR-UPPER-RH BS6	TATA spare parts
284569176305AQ	LINEN-C-PILLAR TRIM UPPER-RH BS6	TATA spare parts
284569176306	B-PILLAR TRIM UPPER-RH BS6	TATA spare parts

284569176306AQ	LINEN-B-PILLAR TRIM UPPER-RH BS6	TATA spare parts
284569206301	BODYSIDE TRIM REAR LOWER LH	TATA spare parts
284569206320	B-PILLAR TRIM LOWER-LH BS6	TATA spare parts
284569206321	B-PILLAR TRIM LOWER-RH BS6	TATA spare parts
284569206321C7	GRANIT_BLACK-B-PILLAR TRIM LOWER-LH BS6	TATA spare parts
284569300101	COVER ASSY AC AUX UNIT	TATA spare parts
284569300103AQ	LINEN-COVER ASSY AUXILIARY AC UNIT REAR	TATA spare parts
284569500101	ASSY CENTER TRIM AC UNIT	TATA spare parts
284569500102	ASSY SIDE TRIM LH	TATA spare parts
284569500103	ASSY SIDE TRIM RH	TATA spare parts
284569500104	ASSY SIDE TRIM LOWER HIGH ROOF LH B002	TATA spare parts
284569500105	ASSY SIDE TRIM LOWER HIGH ROOF RH B002	TATA spare parts
284569500106	ASSY CENTRE TRIM AC UNIT	TATA spare parts
284569500110	ASSY SIDE TRIM LOWER RH	TATA spare parts
284569500111	ASSY KIT FOAM ROOF INSULATION	TATA spare parts
284569500122	ASSY HEADLINER BEADING 3200 FLAT ROOF	TATA spare parts
284569500123	ASSY AL CHANNEL BEADING PROP1(CLS GOODS)	TATA spare parts
284569500142	ASSY FRONT AC TRIM COVER	TATA spare parts
284569500143	ASSY CENTERTRIM ACUNIT DUAL AC	TATA spare parts
284569500157	ASSY CENTER TRIM AC UNIT	TATA spare parts
284569500157AQ	LINEN-ASSY CENTER TRIM AC UNIT BS6	TATA spare parts
284569500158	ASSY CENTER TRIM AC UNIT HR	TATA spare parts
284569500158AQ	LINEN-ASSY CENTER TRIM AC UNIT HR BS6	TATA spare parts
284569500160	HEADLINER ASSY FRONT-LH	TATA spare parts
284569500161	HEADLINER ASSY FRONT-RH	TATA spare parts
284569500167	HEADLINER ASSY BS6	TATA spare parts
284569500167AQ	LINEN-HEADLINER ASSY BS6	TATA spare parts
284569506307	HEADLINER MOULDED FRONT FLAT ROOF	TATA spare parts
284569506308	HEADLINER MOULDED REAR 2800 FLATROOF	TATA spare parts
284569506309	HEADLINING MOULDED FRONTCENTRE	TATA spare parts
284569506310	HEADLINING MOULDED FRONT LH	TATA spare parts
284569506311	HEADLINER MOULDED FRONT FLAT ROOF	TATA spare parts
284569506311AQ	LINEN-HEADLINER MOULDED FRONT FLAT ROOF	TATA spare parts
284569506312	HEADLINER MOULDED REAR 3200 FR	TATA spare parts
284569506315	SIDE TRIM LH AC UNIT FLAT ROOF	TATA spare parts
284569506316	SIDE TRIM RH AC UNIT FLAT ROOF	TATA spare parts
284569506317	SIDE TRIM UPPER LH AC UNIT HIGH ROOF	TATA spare parts
284569506318	SIDE TRIM UPPER RH AC UNIT HIGH ROOF	TATA spare parts
284569506329	HEADLINING MOULDED FRONT RH	TATA spare parts
284569506330	ADLINING MOULDED REAR CENTRE	TATA spare parts
284569506331	HEADLINING MOULDED REAR LH	TATA spare parts
284569506332	HEADLINING MOULDED REAR RH	TATA spare parts
284569506336	HEADLINING MOULDED FRONT CENTRE32HR B00	TATA spare parts
284569506336AQ	LINEN-HEADLINING MOULDED FRONT CENTRE32H	TATA spare parts
284569506339	HEADLINING MOULDED REAR CENTRE	TATA spare parts
284569506351	HEADLINER MOULDED FRONT 3200FR G004	TATA spare parts
284569506351AQ	LINEN-HEADLINER MOULDED FRONT 3200FR G00	TATA spare parts

284569506352	HEADLINER MOULDED REAR	TATA spare parts
284569506352AQ	LINEN-HEADLINER MOULDED REAR 3200 FR G00	TATA spare parts
284569506353	RIGID PU FOAM HIGH ROOF NON AC 60X125	TATA spare parts
284569506354	RIGID PU FOAM HIGH ROOF AC VERSION60X90	TATA spare parts
284569506355	RIGID PU FOAM FRONT CENTRE HEADLINING	TATA spare parts
284569506359	HEADLINING MOULDED FRONT CENTRE HR GOOD	TATA spare parts
284569506360	HEADLINING MOULDED FRONT LH	TATA spare parts
284569506361	HEADLINING MOULDED FRONT RH	TATA spare parts
284569506374	HEADLINING MOULDED REAR 2870WB M1	TATA spare parts
284569506374BE	HEADLINING MOULDED REAR 2870WB M1 WING	TATA spare parts
284569506394	SIDE TRIM LH DUAL AC HR	TATA spare parts
284569506395	SIDE TRIM RH DUAL AC HR	TATA spare parts
284569506396	HEADLINING MOULDED FRONT LH HR DUAL AC	TATA spare parts
284569506396AQ	LINEN-HEADLINING MOULDED FRONT LH HR DUA	TATA spare parts
284569506397	HEADLINING MOULDED FRONT RH HR DUAL AC	TATA spare parts
284569506403	HEADLINER REAR FLAT ROOF BS6	TATA spare parts
284569506403AQ	LINEN-HEADLINER REAR FLAT ROOF BS6	TATA spare parts
284569516306BE	HEADLINER FORNT 2780WB M1 WINGER.	TATA spare parts
284569516308	CENTER TRIM	TATA spare parts
284569516320	HEADLINER MOULDED REAR CENTRE 3488WB HR	TATA spare parts
284569516321	HEADLINER MOULDED REAR LH 3488WB HR	TATA spare parts
284569516322	HEADLINER MOULDED REAR RH 3488WB HR	TATA spare parts
284569516323	HEADLINER MIDDLE CENTRE 3488WB HR	TATA spare parts
284569516324	HEADLINER MOULDED MIDDLE LH 3488WB HR	TATA spare parts
284569516325	HEADLINER MOULDED MIDDLE RH 3488WB HR	TATA spare parts
284569516336	HEADLINER REAR-CENTER	TATA spare parts
284569516336AQ	LINEN-HEADLINER REAR-CENTER	TATA spare parts
284569516337	ROOF LINING REAR	TATA spare parts
284569516337AQ	LINEN-ROOF LINING REAR BS6	TATA spare parts
284569516338	ROOF LINING REAR	TATA spare parts
284569516338AQ	LINEN-ROOF LINING REAR BS6	TATA spare parts
284569516339	HEADLINER ASSY MID	TATA spare parts
284569516339AQ	LINEN-HEADLINER ASSY MID BS6	TATA spare parts
284569516340	ROOF LINING LH	TATA spare parts
284569516340AQ	LINEN-ROOF LINING LH BS6	TATA spare parts
284569516341	ROOF LINING RH	TATA spare parts
284569516341AQ	LINEN-ROOF LINING RH BS6	TATA spare parts
284569516342	HEADLINER ASSY FRONT-LH	TATA spare parts
284569516342AQ	LINEN-HEADLINER ASSY FRONT-LH BS6	TATA spare parts
284569516343	HEADLINER ASSY FRONT	TATA spare parts
284569516343AQ	LINEN-HEADLINER ASSY FRONT BS6	TATA spare parts
284569516344	ROOF LINING CENTER-FRONT	TATA spare parts
284569516344AQ	LINEN-ROOF LINING CENTER-FRONT BS6	TATA spare parts
284569516345	HEAD LINING FRONT-CENTER	TATA spare parts
284569516347AQ	LINEN-HEAD LINING FRONT-CENTER BS6	TATA spare parts
284569516349AQ	LINEN-HEAD LINING REAR-RH BS6	TATA spare parts
284569516350AQ	LINEN-HEAD LINING REAR-LH BS6	TATA spare parts

284569516351AQ	LINEN-HEAD LINING FRONT-RH BS6	TATA spare parts
284569516353AQ	LINEN-HEADLINER REAR-CENTER BS6	TATA spare parts
284569516354AQ	LINEN-HEADLINER CENTRAL BS6	TATA spare parts
284569516355AQ	LINEN-HEAD LINING FRONT-LH BS6	TATA spare parts
284569516356AQ	LINEN-HEADLINER MIDDLE-LH BS6	TATA spare parts
284569516358AQ	LINEN-HEADLINER MIDDLE-RH BS6	TATA spare parts
284569516360	HEADLINER CENTRAL REAR BS6	TATA spare parts
284569516360AQ	LINEN-HEADLINER CENTRAL REAR BS6	TATA spare parts
284569516374AQ	LINEN-HEAD LINING FRONT-RH	TATA spare parts
284569990101	KIT ASSY HEADLINER BEADING 3488WB 14+D	TATA spare parts
284569990101ZY	CLRPRT_ASY_1-HEADLINER BEADING ASSY	TATA spare parts
284572200108	ASSY FRONT DOOR SHELL LH	TATA spare parts
284572200109	ASSY FRONT DOOR SHELL RH	TATA spare parts
284572200110	DOOR PAD ASSY RH	TATA spare parts
284572200112	DOOR PAD ASSY LH	TATA spare parts
284572200115	ASSY FRONT DOOR SHELL WITH CED COATED LH	TATA spare parts
284572200116	ASSY. FRONT DOOR SHELL CED COAT RH BS2-4	TATA spare parts
284572200133	ASSY DOOR PAD LH. FOR M1 WINGER B	TATA spare parts
284572200133ZZ	ASSY DOOR PAD LH. FOR M1 WINGER B001	TATA spare parts
284572200134	ASSY DOOR PAD RH. FOR M1 WINGER B	TATA spare parts
284572200134ZZ	ASSY DOOR PAD RH. FOR M1 WINGER B001	TATA spare parts
284572200150	FRONT DOOR SHELL ASSY LH BS6	TATA spare parts
284572200151	FRONT DOOR SHELL ASSY RH BS6	TATA spare parts
284572206308	DOOR PAD LH	TATA spare parts
284572206309	DOOR PAD RH	TATA spare parts
284572300101	INNER HANDLE ASSY RH	TATA spare parts
284572300101C7	GRANIT_BLACK-INNER HANDLE ASSY RH BS6	TATA spare parts
284572300102	INNER HANDLE ASSY LH	TATA spare parts
284572300102C7	GRANIT_BLACK-INNER HANDLE ASSY LH BS6	TATA spare parts
284572300103	OUTER LATCH ASSY LH	TATA spare parts
284572300104	OUTER LATCH ASSY RH	TATA spare parts
284572300105	STRIKER BODY SIDE RH	TATA spare parts
284572300106	STRIKER BODY SIDE LH	TATA spare parts
284572300113	CHECK STRAP ASSY	TATA spare parts
284572300114	CONTROL UNIT RH	TATA spare parts
284572300114D3	CONTROL UNIT RH	TATA spare parts
284572300114D8	CONTROL UNIT RH	TATA spare parts
284572300114EN	CONTROL UNIT RH	TATA spare parts
284572300115	CONTROL UNIT LH	TATA spare parts
284572300115D3	CONTROL UNIT LH	TATA spare parts
284572300115D8	CONTROL UNIT LH	TATA spare parts
284572300115EN	CONTROL UNIT LH	TATA spare parts
284572300116	STRIKER BODY SIDE RH	TATA spare parts
284572300117	STRIKER BODY SIDE LH	TATA spare parts
284572300118	KIT ASSY LOCK SET	TATA spare parts
284572300119	OUTER LATCH ASSY LH	TATA spare parts
284572300120	OUTER LATCH ASSY RH	TATA spare parts



284572300121	INNER HANDLE ASSY LH	TATA spare parts
284572300122	INNER HANDLE ASSY	TATA spare parts
284572300123	ASSY DIVISION BAR LH	TATA spare parts
284572300124	ASSY DIVISION BAR RH	TATA spare parts
284572300125	GRAB HANDLE FRONT DOOR	TATA spare parts
284572300131	GLASS GUIDE CHANNEL ASSY LH	TATA spare parts
284572300132	GLASS GUIDE CHANNEL ASSY RH	TATA spare parts
284572300134	CHECK STRAP ASSY FRONT DOOR	TATA spare parts
284572300135	GRAB HANDLE FRONT DOOR	TATA spare parts
284572300136	LATCH CONTROL UNIT FRONT DOOR RH	TATA spare parts
284572300136D3	LATCH CONTROL UNIT FRONT DOOR RH	TATA spare parts
284572300136D8	LATCH CONTROL UNIT FRONT DOOR RH	TATA spare parts
284572300136EN	LATCH CONTROL UNIT FRONT DOOR RH	TATA spare parts
284572300137	LATCH CONTROL UNIT FRONT DOOR LH	TATA spare parts
284572300137D3	LATCH CONTROL UNIT FRONT DOOR LH	TATA spare parts
284572300137D8	LATCH CONTROL UNIT FRONT DOOR LH	TATA spare parts
284572300137EN	LATCH CONTROL UNIT FRONT DOOR LH	TATA spare parts
284572300138	INNER HANDLE ASSY LH B002	TATA spare parts
284572300139	INNER HANDLE ASSY RH B002	TATA spare parts
284572300142	KIT ASSY LOCK SET (NON SLD DOOR VERSION)	TATA spare parts
284572300143	KIT ASSY LOCK SET (M1 WINGER)	TATA spare parts
284572303301	CHECK STRAP MTG BKT	TATA spare parts
284572303303	CHECK STRAP MTG BKT FRONT DOOR	TATA spare parts
284572306001	LINK INNER HANDLE LEVER	TATA spare parts
284572306002	LINK POP UP KNOB	TATA spare parts
284572306003	LINK INNER HANDLE LEVER ROD	TATA spare parts
284572306004	LINK POP UP KNOB	TATA spare parts
284572306301	HANDLE OF WINDOW LIFT KIT	TATA spare parts
284572306307	EXTERIOR HANDLE FRONT DOOR MINDA HUF	TATA spare parts
284572306307C7	GRANIT_BLACK-EXTERIOR HANDLE FRONT DOOR	TATA spare parts
284572306307D3	EXTERIOR HANDLE FRONT DOOR	TATA spare parts
284572306307D8	EXTERIOR HANDLE FRONT DOOR	TATA spare parts
284572306307EN	EXTERIOR HANDLE FRONT DOOR CYCUS_GREY	TATA spare parts
284572306307GM	EXTERIOR HANDLE FRONT DOOR	TATA spare parts
284572306310	EATHERSTRIP OF FRONT DOOR INNER	TATA spare parts
284572306311	WEATHERSTRIP OF FRONT DOOR OUTER	TATA spare parts
284572306312	PLASTIC MEMBRANE FRONT DOOR RH RENUKAIN	TATA spare parts
284572306313	POCKET FRONT DOOR LH	TATA spare parts
284572306314	MAGAZINE POCKET FRONT DOOR RH	TATA spare parts
284572306317	CLIP SUPPORT WEATHERSTRIP	TATA spare parts
284572306321	END PIECE OF FIXED VENT PILLER	TATA spare parts
284572306323	EXTERIOR HANDLE	TATA spare parts
284572306324	HANDLE OF WINDOW LIFT KIT	TATA spare parts
284572306328	MAGAZINE POCKET FRONT DOOR LH	TATA spare parts
284572306329	MAGAZINE POCKET FRONT DOOR RH	TATA spare parts
284572306333	PLASTIC MEMBRANE FRONT DOOR RENUKA IND	TATA spare parts
284572306338	CLIP SUPPORT WEATHERSTRIP	TATA spare parts

284572306342	CLIP RETAINER	TATA spare parts
284572306344	CLIP-RETAINING	TATA spare parts
284572306346	DOOR STOPPER	TATA spare parts
284572307701	FIXED GLASS RUBBER MOULD	TATA spare parts
284572307702	BODY SIDE RUBBER MOULD(DOOR)	TATA spare parts
284572308212	HINGE FEMALE LOWER LH	TATA spare parts
284572308213	HINGE FEMALE LOWER RH	TATA spare parts
284572308214	HINGE FEMALE UPPER LH	TATA spare parts
284572308215	HINGE FEMALE UPPER RH	TATA spare parts
284572308233	CLIP OF GLASS GUIDING SUPPORT	TATA spare parts
284572308234	BACKING PLATE	TATA spare parts
284572308301	SHIM LOWER BS6	TATA spare parts
284572308302	SHIM UPPER BS6	TATA spare parts
284572336305	GRAB HANDLE FRONT DOOR LH BS6	TATA spare parts
284572336305C7	GRANIT_BLACK-GRAB HANDLE FRONT DOOR LH BS6	TATA spare parts
284572336306	GRAB HANDLE FRONT DOOR RH BS6	TATA spare parts
284572336306C7	GRANIT_BLACK-GRAB HANDLE FRONT DOOR RH BS6	TATA spare parts
284572336307	CAP DOOR HANDLE LH BS6	TATA spare parts
284572336308	CAP DOOR HANDLE RH BS6	TATA spare parts
284572336309	CAP DOOR HANDLE LH BS6	TATA spare parts
284572336310	CAP DOOR HANDLE RH BS6	TATA spare parts
284572500103	ASSY WINDOW WINDING MECH LH	TATA spare parts
284572500104	ASSY. WINDOW WINDING RH BS2/3/4	TATA spare parts
284572500105	GLASS BOTTOM HOLDER ASSY	TATA spare parts
284572500106	ASSY WINDOW WINDING MECH LH	TATA spare parts
284572500107	WINDOW WINDING ASSY RH	TATA spare parts
284572502301	WINDING GLASS FRONT DOOR RH	TATA spare parts
284572502302	WINDING GLASS FRONT DOOR LH	TATA spare parts
284572502303	FIXED QUARTER GLASS,TOUGHNED WHITE RH	TATA spare parts
284572502304	FIXED QUARTER GLASS TOUGHNED WHITE LH	TATA spare parts
284572502305	WINDING GLASS FRONT DOOR GREEN TINTED LH	TATA spare parts
284572502306	WINDING GLASS FRONT DOOR GREEN TINTED RH	TATA spare parts
284572502307	FIXED QUARTER GLASS GREEN TINTED LH	TATA spare parts
284572502308	FIXED QUARTER GLASS GREEN TINTED RH	TATA spare parts
284572507701	GLASS RUN DIVISION BAR	TATA spare parts
284572507702	GLASS RUN GUIDE CHANNEL RUBBER	TATA spare parts
284572547701	SECONDARY SEAL FRONT DOOR	TATA spare parts
284572700104	MAGAZINE POCKET ASSY FRONT DOOR RH BS6	TATA spare parts
284572700104C7	GRANIT_Black-MAGAZINE POCKET ASSY FRONT DOOR RH BS6	TATA spare parts
284572700105	MAGAZINE POCKET ASSY FRONT DOOR LH BS6	TATA spare parts
284572700105C7	GRANIT_Black-MAGAZINE POCKET ASSY FRONT DOOR LH BS6	TATA spare parts
284572706301	DOOR TRIM FRONT DOOR LOWER-RH BS6	TATA spare parts
284572706301D3	JDR_MID_GREY-DOOR TRIM FRONT DOOR LOWER-RH BS6	TATA spare parts
284572706308	DOOR TRIM FRONT DOOR LOWER-LH BS6	TATA spare parts
284572706308D3	JDR_MID_GREY-DOOR TRIM FRONT DOOR LOWER-LH BS6	TATA spare parts
284572716301	MEMBRANE FRONT DOOR LH BS6	TATA spare parts
284572716303	MEMBRANE FRONT DOOR RH BS6	TATA spare parts

284573200109	ASSY SIDE SLIDING DOOR SHELL LH	TATA spare parts
284573200112	ASSY SLIDING DOOR SHELL WITH CED COATED	TATA spare parts
284573200120	ASSY MNTG. PLATE INNER HANDLE SLD DOOR	TATA spare parts
284573206306	DOOR PAD SLIDING DOOR	TATA spare parts
284573206306D3	JDR_MID_GREY-DOOR PAD SLIDING DOOR G004	TATA spare parts
284573206307	DOOR PAD SLIDING DOOR	TATA spare parts
284573206311	DOOR PAD SLIDING DOOR(WELD LINE)	TATA spare parts
284573206312BN	DOOR PAD SLIDING DOOR M1	TATA spare parts
284573300101	LOCKING KNOB ASSY	TATA spare parts
284573300102	INNER LATCH CONTROL UNIT	TATA spare parts
284573300102D3	INNER LATCH CONTROL UNIT ARTICT SILVER	TATA spare parts
284573300102D8	INNER LATCH CONTROL UNIT PEARL WHITE	TATA spare parts
284573300102EN	INNER LATCH CONTROL UNIT CYCUS_GREY	TATA spare parts
284573300103	UPPER GUIDE KIT DOOR SIDE	TATA spare parts
284573300104	INNER LATCH CONTROL	TATA spare parts
284573300104D3	INNER LATCH CONTROL UNIT ARTICT SILVER	TATA spare parts
284573300104D8	INNER LATCH CONTROL UNIT PEARL WHITE	TATA spare parts
284573300104EN	INNER LATCH CONTROL UNIT CYCUS_GREY	TATA spare parts
284573300106	LATCH HANDLE ASSY FRONT	TATA spare parts
284573300108	CENTRAL GUIDE ASSY LH	TATA spare parts
284573300109	UPPER RAIL ASSY BODY SIDE	TATA spare parts
284573300110	LOWER GUIDE KIT DOOR SIDE LH	TATA spare parts
284573300114	ASSY. CENTRAL GUIDE BS2/3/4	TATA spare parts
284573300117	LATCH HANDLE ASSY FRONT	TATA spare parts
284573300118	UPPER GUIDE KIT DOOR SIDE	TATA spare parts
284573300119	UPPER RAIL ASSY BODY SIDE	TATA spare parts
284573300120	LOWER GUIDE KIT DOOR SIDE LH	TATA spare parts
284573300121	LOCKING KNOB ASSY	TATA spare parts
284573300124	UPPER RAIL ASSY BODY SIDE	TATA spare parts
284573303102	BEARING-CENTRAL SLIDING MECH. BS2/3/4	TATA spare parts
284573303301	CENTERING DEVICE FEMALE	TATA spare parts
284573303302	CENTERING DEVICE MALE	TATA spare parts
284573306001	LINK OF REMOTE LOCKING	TATA spare parts
284573306002	LOCKING LINK OF SLIDING DOOR	TATA spare parts
284573306003	LINK OF REMOTE CONTROL	TATA spare parts
284573306004	LINK OF REMOTE CONTROL	TATA spare parts
284573306005	LOCKING LINK OF SLIDING DOOR	TATA spare parts
284573306006	LINK OF REMOTE LOCKING	TATA spare parts
284573306301	END PIECE- FRONT	TATA spare parts
284573306302	END PIECE- REAR	TATA spare parts
284573306304	PLASTIC MEMBRANE SLIDING DOOR RENUKA IND	TATA spare parts
284573306305	SECONDARY HANDLE	TATA spare parts
284573306305D3	SECONDARY HANDLE	TATA spare parts
284573306305D8	SECONDARY HANDLE	TATA spare parts
284573306305EN	SECONDARY HANDLE	TATA spare parts
284573306306	SECONDARY HANDLE SLIDING DOOR	TATA spare parts
284573306306C7	GRANIT_BLACK-SECONDARY HANDLE SLIDING DO	TATA spare parts

284573306306D3	SECONDARY HANDLE SLIDING DOOR	TATA spare parts
284573306306D8	SECONDARY HANDLE SLIDING DOOR	TATA spare parts
284573306306EN	SECONDARY HANDLE SLIDING DOOR	TATA spare parts
284573306309	STOP OF SLIDING DOOR	TATA spare parts
284573306317	CLIP-LINK SUPPORT	TATA spare parts
284573306323	GROMMET SLIDING DOOR SIDE	TATA spare parts
284573306324	GROMMET BODY SIDE	TATA spare parts
284573306326	COVER UPPER GUIDE ASSY BLACK	TATA spare parts
284573306327	COVER STRIP SLD UPPER RAIL	TATA spare parts
284573307701	SEAL MIDDLE RAIL	TATA spare parts
284573307702	RUBBER SEAL BODY SIDE	TATA spare parts
284573307704	BOTTOM RUBBER SEAL DOOR SIDE	TATA spare parts
284573307706	SEAL MIDDLE RAIL	TATA spare parts
284573308201	STRIKER PIN SLIDING DOOR	TATA spare parts
284573308202	STRIKER PIN SLIDING DOOR	TATA spare parts
284573308206	CENTRAL SLIDING MECH COVER STRIP 2800SWB	TATA spare parts
284573308208	MIDDLE RAIL COVER FIXING BKT FRONT SIDE	TATA spare parts
284573308212	GUIDE OF DOOR LOCKING	TATA spare parts
284573308216	LOWER RAIL	TATA spare parts
284573308223	CENTRAL SLIDING MECH COVER STRIP 3200LWB	TATA spare parts
284573308224	MTG BRACKET SLIDING RAIL	TATA spare parts
284573308301	SHIM OF STRIKER THICK1	TATA spare parts
284573547701	SECONDARY SEAL SLIDING DOOR	TATA spare parts
284574200107	ASSY REAR DOOR SHELL LH	TATA spare parts
284574200108	ASSY REAR DOOR SHELL RH	TATA spare parts
284574200109	ASSY REAR DOOR SHELL LH	TATA spare parts
284574200110	DOOR SHELL ASSY REAR-RH	TATA spare parts
284574200115	ASSY REAR DOOR SHELL WITH CED COATED LH	TATA spare parts
284574200116	ASSY REAR DOOR SHELL WITH CED COATED RH	TATA spare parts
284574200117	ASSY REAR DOOR SHELL WITH CED COATED LH	TATA spare parts
284574200118	ASSY REAR DOOR SHELL WITH CED COATED RH	TATA spare parts
284574200121	ASSY REAR DOOR SHELL LH FR	TATA spare parts
284574200122	ASSY REAR DOOR SHELL LH HR BS6	TATA spare parts
284574200130	ASSY REAR DOOR SHELL LH (ST WINGER)	TATA spare parts
284574200131	ASSY REAR DOOR SHELL RH (ST WINGER)	TATA spare parts
284574200139	ASSY REAR DOOR SHELL WITH CED COATED LH	TATA spare parts
284574200140	ASSY REAR DOOR SHELL WITH CED COATED RH	TATA spare parts
284574200165	BRACKET ASSY TAILGATE TRIM MTG BS6	TATA spare parts
284574208215	PLATE	TATA spare parts
284574300109	ASSY HINGE REAR DOOR UPPER	TATA spare parts
284574300110	ASSY HINGE REAR DOOR LOWER RH	TATA spare parts
284574300114	HANDLE ASSY EXTERIOR REAR DOOR	TATA spare parts
284574300114D3	HANDLE ASSY EXT	TATA spare parts
284574300114D8	HANDLE ASSY EXT	TATA spare parts
284574300114EN	HANDLE ASSY EXT	TATA spare parts
284574300116	LATCH ASSY REAR DOOR LH	TATA spare parts
284574300117	LATCH ASSY REAR DOOR RH	TATA spare parts

284574300118	REAR CLADDING LH BS6	TATA spare parts
284574300118C7	GRANIT_BLACK-CLADDING ASSY REAR DOOR LH	TATA spare parts
284574300118D8	PEARL_WHITE-CLADDING ASSY REAR DOOR LH B	TATA spare parts
284574300119	REAR CLADDING RH BS6	TATA spare parts
284574300119C7	GRANIT_BLACK-CLADDING ASSY REAR DOOR RH	TATA spare parts
284574300119D8	PEARL_WHITE-CLADDING ASSY REAR DOOR RH B	TATA spare parts
284574300125	LOCKING LATCH CONTROL UNIT	TATA spare parts
284574300130	LATCH CONTROL ASSY RH	TATA spare parts
284574300132	CHECKSTRAP ASSY RH	TATA spare parts
284574300134	CHECK STRAP ASSY LH	TATA spare parts
284574300135	LATCH CONTROL ASSY RH	TATA spare parts
284574300136	LATCH ASSY REAR DOOR LH	TATA spare parts
284574300137	LATCH ASSY REAR DOOR RH	TATA spare parts
284574300138	LOCKING LATCH CONTROL UNIT	TATA spare parts
284574300139	ASSY. HANDLE REAR DOOR EXTERIOR BS3/4	TATA spare parts
284574300139C7	GRANIT_BLACK-HANDLE ASSY EXTERIOR REAR D	TATA spare parts
284574300139D3	HANDLE ASSY EXTERIOR REAR DOOR	TATA spare parts
284574300139D8	HANDLE ASSY EXTERIOR REAR DOOR	TATA spare parts
284574300139EN	HANDLE ASSY EXTERIOR REAR DOOR	TATA spare parts
284574300140	CHECK STRAP ASSY REAR DOOR RH	TATA spare parts
284574300141	CHECK STARP ASSY REAR DOOR LH	TATA spare parts
284574300149	ASSY COMP. UPPER HINGE REAR DOOR LH.	TATA spare parts
284574300150	ASSY COMP. UPPER HINGE REAR DOOR RH	TATA spare parts
284574300157	ASSY COMP. LOWER HINGE REAR DOOR LH	TATA spare parts
284574300158	ASSY COMP.LOWER HINGE REAR DOOR RH.	TATA spare parts
284574300159	MAGNET ASSY	TATA spare parts
284574300161	MAGNET STOPPER ASSY	TATA spare parts
284574302901	HINGE-REAR DOOR FEMALE LH	TATA spare parts
284574302902	HINGE REAR DOOR FEMALE RH	TATA spare parts
284574303301	STRIKER LH(TOP/BOTTOM)	TATA spare parts
284574303302	STRIKER REAR DOOR TOP/BOTTOM	TATA spare parts
284574303304	STRIKER REAR DOOR(TOP/BOTTOM)	TATA spare parts
284574306003	LINK OPENING CONTROL UPPER (2800 SWB)	TATA spare parts
284574306004	LINK OPENING CONTROL LOWER	TATA spare parts
284574306005	LINK OPENING CONTROL UPPER(3200 LWB)	TATA spare parts
284574306006	LINK OPENING CONTROL UPPER (2800 SWB)	TATA spare parts
284574306007	LINK OPENING CONTROL UPPER 3200	TATA spare parts
284574306008	LINK OPENING CONTROL LOWER	TATA spare parts
284574306302	PLASTIC MEMBRANE REAR DOOR LH	TATA spare parts
284574306303	PLASTIC MEMBRANE REAR DOOR RH	TATA spare parts
284574306304	KNOB OF INTERNAL LOCK (TO LOCK)	TATA spare parts
284574306304C7	GRANIT_BLACK-KNOB OF INTERNAL LOCK (TO L	TATA spare parts
284574306305	DOOR CLADDING LH	TATA spare parts
284574306305D3	DOOR CLADDING LH	TATA spare parts
284574306305D8	MOULDING OF REAR DOOR PEARL WHITE	TATA spare parts
284574306305EN	MOULDING OF REAR DOOR CYCUS_GREY	TATA spare parts
284574306305HB	MOULDING OF REAR DOOR	TATA spare parts

284574306308	INNER OPEN KNOB (TO OPEN THE DOOR)	TATA spare parts
284574306308C7	GRANIT_BLACK-INNER OPEN KNOBç BS6	TATA spare parts
284574306309	RECTANGULAR GROMMET	TATA spare parts
284574306310	DOOR PAD REAR DOOR RH	TATA spare parts
284574306311	DOOR PAD REAR DOOR LH	TATA spare parts
284574306312	GROMMET REAR DOOR DIA 52MM	TATA spare parts
284574306313	GROMMET WIDE RECTANGULAR LH	TATA spare parts
284574306315	GROMMET(BUTTON TYPE REAR DOOR	TATA spare parts
284574306316	GROMMET REAR DOOR CENTRAL	TATA spare parts
284574306323	DOOR STOP REAR DOOR	TATA spare parts
284574306325	DOOR PAD REAR DOOR LH	TATA spare parts
284574306325D3	JDR_MID_GREY-DOOR PAD REAR DOOR LH (FABR	TATA spare parts
284574306326	DOOR PAD REAR DOOR RH	TATA spare parts
284574306326D3	JDR_MID_GREY-DOOR PAD REAR DOOR RH(FABR	TATA spare parts
284574306328	DOOR CLADDING RH	TATA spare parts
284574306328D3	DOOR CLADDING RH	TATA spare parts
284574306328D8	DOOR CLADDING RH PEARL WHITE	TATA spare parts
284574306328EN	DOOR CLADDING RH CYCUS_GREY	TATA spare parts
284574306328HB	DOOR CLADDING RH	TATA spare parts
284574306329	GROMMET WIDE RECTANGULAR LH	TATA spare parts
284574306330	INNER OPEN KNOB	TATA spare parts
284574306331	KNOB OF INTERNAL LOCK	TATA spare parts
284574306333	RECTANGULAR GROMMET (CHECK STRAP)B002 B	TATA spare parts
284574306340BN	DOOR PAD REAR DOOR LH M1 WINGER	TATA spare parts
284574306341BN	DOOR PAD REAR DOOR RH M1 WINGER	TATA spare parts
284574306701	HINGE PIN	TATA spare parts
284574307701	REAR DOOR GLASS	TATA spare parts
284574307702	BOTTOM RUBBER DOOR SIDE LH	TATA spare parts
284574307703	BOTTOM RUBBER DOOR SIDE RH	TATA spare parts
284574307704	LH DOOR SEALING CENTRAL	TATA spare parts
284574307707	REAR DOOR GLASS RUBBER MOULD HIGH ROOF	TATA spare parts
284574307708	BODY SIDE RUBBER MOULD	TATA spare parts
284574307709	BODY SIDE RUBBER MOULD	TATA spare parts
284574307710	LH DOOR SEALING CENTRAL	TATA spare parts
284574307711	TOP RUBBER STOP	TATA spare parts
284574307712	RUBBER GROMMET REAR DOOR LOWER	TATA spare parts
284574307724	TOP RUBBER SEAL REAR DOOR SIDE (FLAT RO	TATA spare parts
284574307725	TOP RUBBER SEAL REAR DR SIDE (HIGH ROOF)	TATA spare parts
284574308217	TOP RUBBER STOP BRACKET	TATA spare parts
284574308301	SHIM 1 BS6	TATA spare parts
284574308302	SHIM 2 BS6	TATA spare parts
284574308303	SHIM TAILGATE STRIKER	TATA spare parts
284574502301	GLASS OF REAR DOOR LH	TATA spare parts
284574502302	GLASS OF REAR RH DOOR	TATA spare parts
284574502303	GLASS OF REAR LH	TATA spare parts
284574502304	GLASS OF REAR RH	TATA spare parts
284574502305	GLASS OF REAR LH	TATA spare parts

284574502306	GLASS OF REAR RH	TATA spare parts
284574502307	GLASS OF REAR LH	TATA spare parts
284574502308	GLASS OF REAR RH	TATA spare parts
284581006301	REFLECTIVE TAPE CENTER BS6	TATA spare parts
284581006302	REFLECTIVE TAPE TAIL GATE BS6	TATA spare parts
284581100101	REAR VIEW MIRROR INNER	TATA spare parts
284581100102	ASSY. ORVM LH BS2/3/4	TATA spare parts
284581100102D3	REAR VIEW MIRROR OUTER LH	TATA spare parts
284581100102D8	REAR VIEW MIRROR OUTER LH	TATA spare parts
284581100102EN	REAR VIEW MIRROR OUTER LH CYCUS_GREY	TATA spare parts
284581100102GM	SARDINIA_RED-REAR VIEW MIRROR OUTER	TATA spare parts
284581100103	ASSY. ORVM RH BS2/3/4	TATA spare parts
284581100103D3	REAR VIEW MIRROR OUTER RH	TATA spare parts
284581100103D8	REAR VIEW MIRROR OUTER RH	TATA spare parts
284581100103EN	REAR VIEW MIRROR OUTER RH CYCUS_GREY	TATA spare parts
284581100103GM	SARDINIA_RED-REAR VIEW MIRROR OUTER	TATA spare parts
284581100104	ASSY FUEL FILLER FLAP WITH HOUSING	TATA spare parts
284581100106	REAR VIEW MIRROR INNER	TATA spare parts
284581100110	REAR VIEW MIRROR OUTER RH RHD	TATA spare parts
284581100110D3	REAR VIEW MIRROR OUTER LH RHD	TATA spare parts
284581100110D8	REAR VIEW MIRROR OUTER RH PEARL WHITE	TATA spare parts
284581100110EN	REAR VIEW MIRROR OUTER RH CYCUS_GREY	TATA spare parts
284581100111	REAR VIEW MIRROR OUTER LH RHD	TATA spare parts
284581100111D3	REAR VIEW MIRROR OUTER LH LHD	TATA spare parts
284581100111D8	REAR VIEW MIRROR OUTER LH PEARL WHITE	TATA spare parts
284581100111EN	REAR VIEW MIRROR OUTER LH CYCUS_GREY	TATA spare parts
284581100115	ASSY. FRONT GRILLE COMP. BS2/3/4	TATA spare parts
284581100115D3	ASSY FRONT GRILLE COMPLETE	TATA spare parts
284581100115D8	ASSY FRONT GRILLE COMPLETE	TATA spare parts
284581100115EN	ASSY FRONT GRILLE COMPLETE	TATA spare parts
284581100115GM	FRONT GRILLE SARDINIA_RED	TATA spare parts
284581100116	ASSY MUDLINER RH	TATA spare parts
284581100117	ASSY GRILLE MTG BRACKET	TATA spare parts
284581100118	ASSY SIDE FOORSTEP COMPLET LH	TATA spare parts
284581100121	ASSY GRILLE MTG BRACKET BS-IV	TATA spare parts
284581100123	ASSY SIDE FOOT STEP COMPLETE	TATA spare parts
284581100123C7	GRANIT_BLACK-FOOT STEP ASSY BS6	TATA spare parts
284581100124	FOOT STEP ASSY	TATA spare parts
284581100125	BRACKET ASSY FOOT STEP MTG BS6	TATA spare parts
284581100126	ASSY SIDE FOOT STEP COMPLETE LIMITED	TATA spare parts
284581100135	SIDE STEP ASSY-LH BKT ASSY REAR END CAP	TATA spare parts
284581100137C7	GRANIT_BLACK-KIT-ORVM LH BS6	TATA spare parts
284581100138C7	GRANIT_BLACK-KIT-ORVM RH BS6	TATA spare parts
284581100157	FOOT STEP ASSY BS6-PH2	TATA spare parts
284581100158	FOOT STEP ASSY BS6-PH2	TATA spare parts
284581100160	BRACKET ASSY FOOT STEP MTG BS6-PH2	TATA spare parts
284581100164	CLOSING PIECE ASSY-LH BS6	TATA spare parts

284581100165	CLOSING PIECE ASSY-RH BS6	TATA spare parts
284581104304	PLUG 24 6	TATA spare parts
284581106301	TIE MEMBER COVER	TATA spare parts
284581106305	BONNET GRILLE	TATA spare parts
284581106306	COVER WINDSCREEN GLASS	TATA spare parts
284581106308	SUNVISOR LHS G004	TATA spare parts
284581106310	EMBLEM	TATA spare parts
284581106311	TAIL LAMP COVER	TATA spare parts
284581106313	PLASTIC GROMMET FOOTSTEP	TATA spare parts
284581106314	PLASTIC INSERT FOOTSTEP	TATA spare parts
284581106315	PLASTIC SCREW FOOTSTEP	TATA spare parts
284581106317	CAP CENTRAL GRILLE MOUNTING	TATA spare parts
284581106319	INTERNAL GRAB HANDLE	TATA spare parts
284581106320	SUNVISOR RHS G004	TATA spare parts
284581106320AQ	LINEN-SUNVISOR RHS G004 BS6	TATA spare parts
284581106322	RECTANGULAR GROMMET	TATA spare parts
284581106323BN	GRAB HANDLE M1 WINGER B001	TATA spare parts
284581106324	INTERCOOLER DUCT	TATA spare parts
284581106325	HEAD LAMP BOTTOM PROTECTION	TATA spare parts
284581106326	HEADLAMP BOTTOM PROTECTION	TATA spare parts
284581106328	GROMMET SIDE BONNET & SILL INNER	TATA spare parts
284581106331	COVER-FRONT LH	TATA spare parts
284581106331D3	COVER-FRONT LH	TATA spare parts
284581106331D8	COVER-FRONT LH PEARL WHITE	TATA spare parts
284581106331EN	COVER-FRONT LH CYCUS_GREY	TATA spare parts
284581106332	COVER FRONT RH	TATA spare parts
284581106332D3	COVER FRONT RH	TATA spare parts
284581106332D8	COVER FRONT RH PEARL WHITE	TATA spare parts
284581106332EN	COVER FRONT RH CYCUS_GREY	TATA spare parts
284581106334	FOOT STEP COVER RH	TATA spare parts
284581106334C7	GRANIT_BLACK-FOOT STEP COVER RH BS6	TATA spare parts
284581106335	FOOT STEP COVER LH	TATA spare parts
284581106340	PLASTIC FLANGED SCREW	TATA spare parts
284581106341	CIRCULAR GROMMET	TATA spare parts
284581106342	SPACER	TATA spare parts
284581106345	RUBBER RAIL 3200 LWB	TATA spare parts
284581106346	MUDLINER LH	TATA spare parts
284581106347	MUDLINER RH	TATA spare parts
284581106349	PLASTIC PLUG ON SILL INNER	TATA spare parts
284581106350	SEAT BELT COVER TRIM ON B PILLAR	TATA spare parts
284581106351	WINGER MASCOT	TATA spare parts
284581106352	CLAMP JACK HANDLE MTG	TATA spare parts
284581106353	GRAB HANDLE (A PILLAR) LH	TATA spare parts
284581106353AQ	LINEN-GRAB HANDLE (A PILL	TATA spare parts
284581106354	INTERNAL GRAB HANDLE	TATA spare parts
284581106354C7	GRANIT_BLACK-INTERNAL GRAB HANDLE B001 B	TATA spare parts
284581106355	SUNVISOR RHS	TATA spare parts



284581106355AQ	LINEN-SUNVISOR RHS B001 BS6	TATA spare parts
284581106356	SUNVISOR LHS	TATA spare parts
284581106357	GRAB HANDLE (A PILLAR) LH	TATA spare parts
284581106357AQ	LINEN-GRAB HANDLE (A PILLAR) LH B001 BS6	TATA spare parts
284581106358	DECAL(FOR LIGHT BODY COLOUR)	TATA spare parts
284581106359	DECAL (FOR DARK BODY COLOUR)	TATA spare parts
284581106360	GRAB HANDLE A PILLAR RH	TATA spare parts
284581106361	DRIP RAIL SEALING 2800 FLAT ROOF	TATA spare parts
284581106362	DRIP RAIL SEALING 3200 HIGH ROOF	TATA spare parts
284581106365	ROOF DRIP RAIL SEALING 3200 HIGH ROOF	TATA spare parts
284581106366	RUBBER RAIL 3200 LWB	TATA spare parts
284581106367	RUBBER RAIL 2800 SWB	TATA spare parts
284581106368	GRAB HANDLE A PILLAR RH B001	TATA spare parts
284581106369	DECAL AMBULANCE	TATA spare parts
284581106370	DECAL SCHOOL BUS	TATA spare parts
284581106371	DECAL AMBULANCE	TATA spare parts
284581106372	PLASTIC PLUG ON REAR FLOOR	TATA spare parts
284581106375	RUBBER RAIL	TATA spare parts
284581106376	RUBBER RAIL	TATA spare parts
284581106382	BONNET GRILLE WITHOUT CUTOUT	TATA spare parts
284581106383	SUNVISOR LH FOR M1 WINGER. (B001)	TATA spare parts
284581106383AQ	LINEN-SUNVISOR LH FOR M1 WINGER. (B001)	TATA spare parts
284581106383BE	SUNVISOR LH FOR M1 WINGER. (B001)	TATA spare parts
284581106384	SUNVISOR RH FOR M1 WINGER. (B001)	TATA spare parts
284581106384AQ	LINEN-SUNVISOR RH FOR M1 WINGER. (B001)	TATA spare parts
284581106384BE	SUNVISOR RH FOR M1 WINGER. (B001)	TATA spare parts
284581106389	DECAL SCHOOL BUS	TATA spare parts
284581106391	WINGER MASCOT PLATINUM	TATA spare parts
284581106392	DECAL CNG 3M TAPE	TATA spare parts
284581106393BN	GRAB HANDLE C PILLAR	TATA spare parts
284581106394BN	GRAB HANDLE A PILLAR LH	TATA spare parts
284581106395BN	GRAB HANDLE A PILLAR RH	TATA spare parts
284581106398BN	GAITER	TATA spare parts
284581106399	BLACKOUT AND DECAL M1 WINGER	TATA spare parts
284581106401	DECAL M1 WINGER	TATA spare parts
284581106405	TIE MEMBER COVER BSIV	TATA spare parts
284581107701	DRIP RAIL 3200 HIGH ROOF	TATA spare parts
284581107702	DRIP RAIL 3200 FLAT ROOF	TATA spare parts
284581107703	ROOF DRIP RAIL SEALING	TATA spare parts
284581107706	BONNET SEALING	TATA spare parts
284581107707	ENGINE COVER SEALING	TATA spare parts
284581107708	ROOF DRIP RAIL SEALING	TATA spare parts
284581107709	DRIP RAIL	TATA spare parts
284581107715	SEAL CLOSURE PANEL BS6	TATA spare parts
284581107718	RUBBER GROMMET A PILLAR	TATA spare parts
284581107720	RUBBER GROMMET 12.2X6.2 SIDE BONNET	TATA spare parts
284581107721	RUBBER GROMMET DIA 19.5 FRONT FLOOR	TATA spare parts

284581107724	RUBBER GROMMET FRONT FLOOR DIA 40 MM	TATA spare parts
284581107725	RUBBER GROMMET B PILLAR LOWER	TATA spare parts
284581107726	RUBBER GROMMET B PILLAR LOWER WITH HOLE	TATA spare parts
284581107730	GROMMET FUEL TANK PIPE	TATA spare parts
284581107732	GROMMET FRONT WHEEL ARCH(SCUFF PLATE)	TATA spare parts
284581107733	ROOF RAIN CHANNEL BEADING HR	TATA spare parts
284581107734	RUBBER GROMMET FRONT WHEEL ARCH	TATA spare parts
284581107735	RUBBER GROMMET FRONT WHEEL ARCH	TATA spare parts
284581107736	RUBBER GROMMET TUMBLING SEAT	TATA spare parts
284581107739	DRIP RAIL HIGH ROOF 3500WB BS6	TATA spare parts
284581107740	BONNET SEALING (SIDE BONNET SIDE)	TATA spare parts
284581107741	BONNET SEALING (SUPPROT HEAD LAMP PANEL	TATA spare parts
284581108211	WIRE MESH FOR GRILL	TATA spare parts
284581108212	ALUMINIUM PLATE NR LOWER RAIL	TATA spare parts
284581116301	RUBBER RAIL - STR WINGER BS6	TATA spare parts
284581116313	COVER FOOT STEP LH	TATA spare parts
284581116313C7	GRANIT_BLACK-COVER FOOT STEP LH BS6	TATA spare parts
284581116318	FRONT END CAP SIDE FOOT STEP	TATA spare parts
284581116319	REAR END CAP SIDE FOOT STEP	TATA spare parts
284581116324	ORVM CORNER PIECE LH BS6	TATA spare parts
284581116325	ORVM CORNER PIECE RH BS6	TATA spare parts
284581116326	CAP BS6	TATA spare parts
284581116333	CAP BS6	TATA spare parts
284581116335	DECAL BS6	TATA spare parts
284581116336	DECAL BS6	TATA spare parts
284581400102	ASSY CNG SPLIT STRUCTURE LH	TATA spare parts
284581400103	CNG FOOT REST	TATA spare parts
284581400115	ASSY CNG SPLIT STRUCTURE RH	TATA spare parts
284581400128BN	ASSY PARCEL RACK LID LH	TATA spare parts
284581400129BN	ASSY PARCEL RACK LID RH	TATA spare parts
284581400130BN	ASSY PARCEL RACK CENTER	TATA spare parts
284581400131	CNG REAR COVER ASSY.	TATA spare parts
284581400132	CNG FRONT COVER ASSY.	TATA spare parts
284581400143	ASSY SUPPORT LUGGAGE COMPARTMENT LH.	TATA spare parts
284581400144	ASSY SUPPORT LUGGAGE COMPARTMENT RH	TATA spare parts
284581400167	PARCEL RACK ASSY BS6	TATA spare parts
284581400188	PARCEL RACK ASSY FRONT END COVER RH BS6	TATA spare parts
284581400199	BEZEL ASSY BS6	TATA spare parts
284581406303	CNG FOOT REST COVER	TATA spare parts
284581406304	CNG COVER LH	TATA spare parts
284581406305	CNG COVER RH	TATA spare parts
284581406311BN	PARCEL RACK LH	TATA spare parts
284581406312BN	PARCEL RACK RH	TATA spare parts
284581406323	SPARE WHEEL COVER	TATA spare parts
284581406333	PARCEL RACK FRONT TRIM RH BS6	TATA spare parts
284581406334	PARCEL RACK COVER REAR-RH BS6	TATA spare parts
284581406336	PARCEL RACK FRONT TRIM LH BS6	TATA spare parts

284581406340	PARCEL RACK FRONT END COVER RH BS6	TATA spare parts
284581406348	PARCEL RACK HVAC DUCT LOWER-RH BS6	TATA spare parts
284581406354	PARCEL RACK HVAC DUCT LOWER-RH BS6	TATA spare parts
284581406355	PARCEL RACK HVAC DUCT LOWER-RH BS6	TATA spare parts
284581407701	CNG RUBBER BEADING FOR FRONT COVER	TATA spare parts
284581407702	CNG RUBBER BEADING FOR REAR COVER	TATA spare parts
284581407703	CNG RUBBER BEADING FOR CHEQUERED PLATE	TATA spare parts
284581408215	CNG FOOT REST CHEQUERED PLATE	TATA spare parts
284581408216	CNG COVER CHEQUERED PLATE	TATA spare parts
284581410101	PARCEL RACK ASSY VERTICAL SUPPORT BKT RH	TATA spare parts
284581410102	PARCEL RACK ASSY VERTICAL SUPPORT BKT RH	TATA spare parts
284581500110	ASSY PARTATION CLOSED GOODS	TATA spare parts
284581904701BN	COVER PARKING BRAKE.	TATA spare parts
284581907704	SHAFT LAY SHAFT	TATA spare parts
284582400101	ASSY KIT WINDSCREEN WIPER MOTOR	TATA spare parts
284582400102	ASSY KIT WINDSCREEN WIPER MOTOR	TATA spare parts
284582400103	WIPER BLADE & ARM	TATA spare parts
284582400104	ASSY KIT W/S WIPER MOTOR (2.2L DIOCR)	TATA spare parts
284582400105	WIPING LINKAGES ASSY WITH SPINDLE	TATA spare parts
284582400106	WIPING LINKAGES ASSY WITH SPINDLE BS6	TATA spare parts
284582400110	WIPER MOTOR ASSY WITH LINKAGES BS6	TATA spare parts
284582409901	WIPER ARM	TATA spare parts
284582409902	WIPER BLADE WITH RUBBER ELEMENT	TATA spare parts
284582409903	WIPER MOTOR	TATA spare parts
284583000103	ASSY. CONDENSER MAIN MULTIFLOW BS3/4	TATA spare parts
284583000104	COOLING UNIT ROOF COMPLETE	TATA spare parts
284583000106	CONDENSER UNIT AUXILLARY	TATA spare parts
284583000107	R D ASSY	TATA spare parts
284583000109	KIT-DEMISTING? BS3/4	TATA spare parts
284583000110	ASSY AC KIT FLAT ROOF	TATA spare parts
284583000111	ASSY AC KIT HIGH ROOF	TATA spare parts
284583000112	ASSY AC PIPES HOSE FLAT	TATA spare parts
284583000113	ASSY AC PIPES HOSE HIGH	TATA spare parts
284583000114	PIPE ASSY SUCTION B PILLAR	TATA spare parts
284583000115	PIPE ASSY B SUCTION	TATA spare parts
284583000116	PIPE ASSY-C SUCTION	TATA spare parts
284583000117	HOSE ASSY SUCTION	TATA spare parts
284583000118	HOSE ASSY DISCHARGE	TATA spare parts
284583000119	PIPE ASSY JOINT TO AUX CONDENSER	TATA spare parts
284583000120	PIPE ASSY -A RECEIVER INLET	TATA spare parts
284583000121	PIPE ASSY-A RECEIVER OUTLET	TATA spare parts
284583000122	PIPE ASSY -B RECEIVER OUTLET	TATA spare parts
284583000123	PIPE ASSY LIQUID B PILLAR	TATA spare parts
284583000124	AUXILLARY CONDENSOR FAN	TATA spare parts
284583000125	AUXILLARY CONDENSOR	TATA spare parts
284583000126	THERMOSTATIC EXPANSION VALVE	TATA spare parts
284583000127	EVAPORATOR ASSY	TATA spare parts

284583000128	THERMISTER ASSY	TATA spare parts
284583000129	EVAPORATOR FILTER COOLING COIL	TATA spare parts
284583000130	BLOWER MOTOR(WITH IMPELER ASSY)	TATA spare parts
284583000131	BLOWER ASSY FAN	TATA spare parts
284583000132	PIPE ASSY A SUCTION B PILLAR SANDEN	TATA spare parts
284583000133	PIPE ASSY B SUCTION SANDEN	TATA spare parts
284583000135	PIPE ASSY SUCTION (COOLING UNIT)	TATA spare parts
284583000136	UPPER CASE (COOLING UNIT)	TATA spare parts
284583000137	FRONT AC UNIT	TATA spare parts
284583000138	FLOOR MOUNTED CONDENSER	TATA spare parts
284583000140	ASSY AC KIT FLAT ROOF SANDEN(MODIFIED)	TATA spare parts
284583000143BE	ROOF LINER MOUNTED AIRVENT ASSY DUAL BAR	TATA spare parts
284583000150	ASSY LIQUID LINE FRONT EVAPORATOR INLET	TATA spare parts
284583000151	ASSY SUCTION LINE FRONT EVAPO. OUTLET	TATA spare parts
284583000152	ASSY SUCTION HOSE FRONT EVAP TO COMP	TATA spare parts
284583000154	KIT ASSY DUAL AC PIPES FOR FLAT ROOF	TATA spare parts
284583000155	HOSE ASSY-A SUCTION	TATA spare parts
284583000156	PIPE ASSY-JOINT_A MAIN COND TO AUX COND	TATA spare parts
284583000157	PIPE ASSY-C AUX COND TO RD INLET	TATA spare parts
284583000158	PIPE ASSY-C RECIEVER OUTLET	TATA spare parts
284583000159	PIPE ASSY-JOINT_B MAIN COND TO AUX COND	TATA spare parts
284583000160	PIPE ASSY-D AUX COND TO RD INLET	TATA spare parts
284583000161	ASSY_FRP_FRONT_AC_UNIT	TATA spare parts
284583000163	PIPE ASSY C-JOINT	TATA spare parts
284583000164	PIPE ASSY - B RECIEVER OUTLET	TATA spare parts
284583000170	ASSY FAN SHROUD FLOOR CONDNESER	TATA spare parts
284583000171	ASSY FLOOR MOUNTED CONDENSER CORE	TATA spare parts
284583000172	CASE LOWER ROOF COOLING UNIT	TATA spare parts
284583000175	KIT ASSY DUAL AC PIPES FOR HIGH ROOF	TATA spare parts
284583000176	KIT ASSY DUAL AC PIPES FLAT ROOF SET_1	TATA spare parts
284583000177	HOSE ASSY-A SUCTION SET_1	TATA spare parts
284583000180	PIPE ASSY B SUCTION SET_1	TATA spare parts
284583000183	HOSE ASSY LIQUID A SET-1	TATA spare parts
284583000184	PIPE ASSY C-JOINT SET-1	TATA spare parts
284583000185	PIPE ASSY A SUCTION B-PILLAR HIGH ROOF	TATA spare parts
284583000186	PIPE ASSY LIQUID B-PILLARHIGH ROOF	TATA spare parts
284583000187	UNDER FLOOR CONDENSER M1 2800WB	TATA spare parts
284583000188	PIPE ASSY C-SUCTION ROOF AC	TATA spare parts
284583000189	HEATER CONTROL KNOB	TATA spare parts
284583000190	HOSE ASSY SUCTION B SET-1	TATA spare parts
284583000191	PIPE ASSY INLET EVAP SET-1	TATA spare parts
284583000192	PIPE ASSY OUTLET EVAP SET-1	TATA spare parts
284583000193	PIPE ASSY A RCVR OUTLET SET-1	TATA spare parts
284583000198	KIT DUAL AC HOSE & PIPE ST AMBULANCE HR	TATA spare parts
284583000210	KIT ROOF IRD CONDENSER	TATA spare parts
284583000211	ASSY ROOF AC KIT FLAT ROOF M1	TATA spare parts
284583000234	PIPE ASSY A SUCTION	TATA spare parts

284583000235	HOSE ASSY A DISCHARGE	TATA spare parts
284583000236	PIPE ASSY A DISCHARGE	TATA spare parts
284583000237	PIPE ASSY B DISCHARGE	TATA spare parts
284583000238	PIPE ASSY C DISCHARGE	TATA spare parts
284583000239	PIPE ASSY D DISCHARGE A	TATA spare parts
284583000240	INLET PIPE ASSY - A	TATA spare parts
284583000241	OUTLET PIPE ASSY - A	TATA spare parts
284583000242	PIPE ASSY A LIQUID A	TATA spare parts
284583000243BE	ROOF TRIM MOUNTED AIRVENT ASSY DUAL BARR	TATA spare parts
284583000244	PIPE ASSY D LIQUID	TATA spare parts
284583000245	PIPE ASSY B LIQUID_A	TATA spare parts
284583000246	PIPE ASSY C RCVER OUTLET	TATA spare parts
284583000248	FLOOR MOUNTED CONDENSER	TATA spare parts
284583000250	INLET PIPE ASSY - B	TATA spare parts
284583000251	OUTLET PIPE ASSY - B	TATA spare parts
2845830002510A	PIPE ASSY B DISCHARGE ROOF CONDEN. MOD.A	TATA spare parts
284583100101	DUCT SIDE LH	TATA spare parts
284583100102	DUCT SIDE RH	TATA spare parts
284583100103	JOINT DUCT RH FLAT ROOF	TATA spare parts
284583100104	JOINT DUCT RH HIGH ROOF	TATA spare parts
284583100105	JOINT DUCT LH FLAT ROOF	TATA spare parts
284583100106	JOINT DUCT LH HIGH ROOF	TATA spare parts
284583100107	DUCT SIDE LH HIGH ROOF	TATA spare parts
284583100108	DUCT SIDE RH HIGH ROOF	TATA spare parts
284583100109	ROOF DUCT ASSY LH	TATA spare parts
284583100110	ROOF DUCT ASSY RH	TATA spare parts
284583100111	ROOF DUCT ASSY	TATA spare parts
284583100112	ROOF DUCT ASSY UPPER	TATA spare parts
284583100113	ROOF DUCT ASSY LOWER	TATA spare parts
284583100119	DUCT ASSY- REAR RH BS6	TATA spare parts
284583100122	BRACKET ASSY DUCT MTG BS6	TATA spare parts
284583100125	BRACKET ASSY DUCT MTG BS6	TATA spare parts
284583106309	HEATER DUCT BS6	TATA spare parts
284583106310	HEATER DUCT BS6	TATA spare parts
284583106321	COVER DUCT BS6	TATA spare parts
284583106322	DUCT ROOF FRONT BS6	TATA spare parts
284583106323	DUCT ROOF CENTER BS6	TATA spare parts
284583106324	DUCT ROOF REAR BS6	TATA spare parts
284583108202	RD BOTTLE WITH PRESSURE SWITCH	TATA spare parts
284583108203	PIPE CLAMP A SUCTION	TATA spare parts
284583116301	ROOF AC DUCT DISTRIBUTION CENTRE STEP-1	TATA spare parts
284583116304	STICKER FOR DUAL AC CONTORL	TATA spare parts
284583116305	STICKER FOR DUAL AC CONTROL	TATA spare parts
284583116306	STICKER FOR DUAL AC CONTROL	TATA spare parts
284583116307	STICKER FOR REAR AC MASTER SWITCH	TATA spare parts
284583206302	AIRVENT COVER	TATA spare parts
284583206303	AIR VENT ASSY BS6	TATA spare parts

284583300101	ASSY CONTROL PANEL	TATA spare parts
284583300102	ASSY COVER FOR NON AC VERSION	TATA spare parts
284583400101	COMPRESSOR	TATA spare parts
284583400102	COMPRESSOR	TATA spare parts
284583400103	BLOWER ASSY	TATA spare parts
284583400105	EVAPORATOR SUB ASSY	TATA spare parts
284583400109	ASSEMBLY ROOF ID CONDENSER	TATA spare parts
284583400117	ASSY DRAIN HOSE FOR FRONT COOLING UNIT	TATA spare parts
284583400121	RD ASSY FOR WINGER BSIV	TATA spare parts
284583400153	AC UNIT ASSY LH BS6	TATA spare parts
284583400156	AC UNIT ASSY RH BS6	TATA spare parts
284583400158	AC UNIT ASSY FRONT BS6	TATA spare parts
284583400160	BRACKET ASSY BS6	TATA spare parts
284583400161	BRACKET ASSY BS6	TATA spare parts
284583400163	AC UNIT ASSY FRONT BS6	TATA spare parts
284583400165	AC UNIT ASSY FRONT BS6	TATA spare parts
284583400169	BRACKET ASSY CONDENSER LH BS6	TATA spare parts
284583400170	EVAPORATOR ASSY BS6	TATA spare parts
284583400171	EVAPORATOR ASSY BS6	TATA spare parts
284583400172	COOLING UNIT ASSY BS6	TATA spare parts
284583400174	EVAPORATOR ASSY BS6	TATA spare parts
284583400176	COOLING UNIT ASSY BS6	TATA spare parts
284583400177	RECEIVER DRIER BOTTLE ASSY BS6	TATA spare parts
284583400178	BLOWER CASING LOWER BS6	TATA spare parts
284583400179	EVAPORATOR ASSY BS6	TATA spare parts
284583400182	BLOWER CASING UPPER BS6	TATA spare parts
284583400202	FRONT COOLING UNIT WITHOUT FRP CASING	TATA spare parts
284583400204	ASSY ROOF AC UNIT WITHOUT FRP DUCT	TATA spare parts
284583400206	FRONT COOLING UNIT WITH PLASTIC CASING	TATA spare parts
284583403301	MTG BRKT BLOWER CENTER	TATA spare parts
284583403302	MTG BRKT BOTTOM	TATA spare parts
284583403303	MTG BRKT SIDE LEFT	TATA spare parts
284583403304	MTG BRKT SIDE RIGHT	TATA spare parts
284583403305	MTG BRKT LOWER SUPPORT	TATA spare parts
284583403306	FRONT AC UNIT CASES MOUNTING BKT.	TATA spare parts
284583403307	FLOOR CONDENSER FRONT MOUNTING BRACKET	TATA spare parts
284583403308	FLOOR CONDENSER REAR MOUNTING BRACKET	TATA spare parts
284583403309	FLOOR CONDENSER STONE GUARD	TATA spare parts
284583403310	FLOOR CONDENSER INLET MOUNTING BRACKET	TATA spare parts
284583403311	FLOOR CONDENSER OUTLET MOUNTING BRACKET	TATA spare parts
284583403312	FLOOR CONDENSER L CHANNEL ASSY	TATA spare parts
284583403313	FLOOR CONDENSER BOTTOM MOUNTING BRACKET	TATA spare parts
284583403314	BRACKET ROOF UNIT MTG LH	TATA spare parts
284583403315	BRACKET ROOF UNIT MTG RI-I	TATA spare parts
284583403316	BRACKET COVER MTG RIGHT	TATA spare parts
284583403317	BRACKET COVER MTG LH	TATA spare parts
284583403318	BRACKET REAR-A ROOF UNIT MTG	TATA spare parts

284583403319	BRACKET REAR-B ROOF UNIT MTG	TATA spare parts
284583403320	AIR DUCT BASE PLATE LH	TATA spare parts
284583403327	TOGGLE CLAMP HEATER BLOWER UNIT ASSY	TATA spare parts
284583403349	SUCTION PIPE MTG BRKT	TATA spare parts
284583403350	HEATER HOSE MTG BRKT	TATA spare parts
284583403360	LH FRONT COND MTG BKT	TATA spare parts
284583403361	RH MTG BRKT FRONT COND	TATA spare parts
284583403364	PIPE RETAINER	TATA spare parts
284583404902	BLOWER MOTOR ASSY BS6	TATA spare parts
284583404903	WIRING HARNESS BS6	TATA spare parts
284583404905	BLOWER ASSY BS6	TATA spare parts
284583404907	THERMISTER BS6	TATA spare parts
284583404908	RELAY BS6	TATA spare parts
284583404910	WIRING HARNESS ASSY BS6	TATA spare parts
284583404912	BLOWER ASSY BS6	TATA spare parts
284583404913	THERMO AMPLIFIER BS6	TATA spare parts
284583405301	INSULATOR BS6	TATA spare parts
284583405802	HEATER DRAIN HOSE BS6	TATA spare parts
284583405808	DRAIN PIPE BS6	TATA spare parts
284583406301	FRONT AC UNIT CASING LOWER	TATA spare parts
284583406302	FRONT AC UNIT CASING UPPER	TATA spare parts
284583406303	FRONT AC UNIT EVAPORATOR COVER	TATA spare parts
284583406304	FRONT AC COOLING UNIT CASING LOWER	TATA spare parts
284583406305	FRONT AC COOLING UNIT CASING UPPER	TATA spare parts
284583406307	CASING DOOR - A	TATA spare parts
284583406308	CASING DOOR - B	TATA spare parts
284583406311	CASE UNIT ASSY BS6	TATA spare parts
284583406312	CASE BS6	TATA spare parts
284583406313	BLOWER CASING BS6	TATA spare parts
284583406801	CASE COOLING UNIT LOWER BS6	TATA spare parts
284583406802	HOSE BS6	TATA spare parts
284583406909	FRESH AIR DUCT DRAIN PIPE	TATA spare parts
284583406927	PIPE ASSY¿ RD INLET	TATA spare parts
284583406928	RD OUTLET PIPE	TATA spare parts
284583406929	HOSE ASSY A SUCTION_FRONT AC	TATA spare parts
284583406930	HOSE ASSY B SUCTION_FRONT AC	TATA spare parts
284583406932	HOSE ASSY B SUCTION_ROOF AC	TATA spare parts
284583406935	PIPE ASSY¿ INLET EVP	TATA spare parts
284583406937	LIQUID PIPE ASSY 2 FRONT COND	TATA spare parts
284583406938	LIQUID PIPE ASSY 2 FRONT COND	TATA spare parts
284583406939	HOSE DISCHARGE PIPE BSIV	TATA spare parts
284583406940	HOSE ASSY C LIQUID	TATA spare parts
284583406941	HOSE ASSY A DISCHARGE	TATA spare parts
284583406942	PIPE ASSY C-JOINT FOR 3200WB	TATA spare parts
284583406948	LIQUID PIPE A 3200WB BS4	TATA spare parts
284583406969	FRONT CONDENSER CORE	TATA spare parts
284583406970	RD BOTTLE BS6	TATA spare parts

284583407501	SEALING GRILLE BS6	TATA spare parts
284583407502	GROMMET BS6	TATA spare parts
284583407701	RUBBER DRAIN HOSE FLAT ROOF	TATA spare parts
284583407702	RUBBER DRAIN HOSE HIGH ROOF	TATA spare parts
284583407704	HOSE DRAIN LEFT	TATA spare parts
284583407706	DRAIN HOSE GROMMET CIRULAR	TATA spare parts
284583407707	AC LIQUID PIPE GROMMET CIRCULAR	TATA spare parts
284583407709	AC PIPES FIREWALL GROMMET	TATA spare parts
284583407710	AIR DUCT SEAL LH	TATA spare parts
284583407712	DRAIN HOSE RH FRONT AC UNIT	TATA spare parts
284583407713	DRAIN HOSE LH FRONT AC UNIT	TATA spare parts
284583407715	FLAT ROOF AC UNIT ASSY DRAIN HOSE RH	TATA spare parts
284583407718	FLAT ROOF AC UNIT ASSY DRAIN HOSE LH	TATA spare parts
284583407720	AIR VENT SEAL LH	TATA spare parts
284583407721	RUUBER PAD	TATA spare parts
284583407724	HIGH ROOF AC UNIT ASSY DRAIN HOSE RH	TATA spare parts
284583407726	HIGH ROOF AC UNIT ASSY DRAIN HOSE LH	TATA spare parts
284583407732	INSULATOR SUCTION PIPE	TATA spare parts
284583407733	EVAPORATOR SEALING (COAL TAPE)	TATA spare parts
284583407734	INSULATOR EVAPORATOR	TATA spare parts
284583407735	DRAIN HOSE LH FRONT AC UNIT	TATA spare parts
284583407736	DRAIN HOSE RH FRONT AC UNIT	TATA spare parts
284583407740	DRAIN HOSE AC UNIT RH BS6	TATA spare parts
284583407741	DRAIN HOSE AC UNIT LH BS6	TATA spare parts
284583408201	EVAPORATOR COIL WIRE MESH	TATA spare parts
284583409901	A/C COMPR. OIL 250ML CAN	TATA spare parts
284583409902	LABEL FOR REFRIGERENT QTY BS6	TATA spare parts
284583409904	STICKER FOR DRAIN HOSE REMOVAL	TATA spare parts
284583409907	STICKER- AC REFRIGERANT CHARGE QTY BS6	TATA spare parts
284583409908	CONTROL PANEL ASSY BS6	TATA spare parts
284583409912	EVAPORATOR SEALING BS6	TATA spare parts
284583409913	FILTER ASSY BS6	TATA spare parts
284583409914	WIRE MESH BS6	TATA spare parts
284583409915	EVAPORATOR SEALING BS6	TATA spare parts
284583409916	MOTOR ASSY WITH FAN BS6	TATA spare parts
284583409917	MOTOR ASSY WITH FAN BS6	TATA spare parts
284583450102	CONDENSER FAN ASSY BS6	TATA spare parts
284583450105	CONDENSER ASSY BS6	TATA spare parts
284583450107	CONDENSER FAN ASSY	TATA spare parts
284583450109	CONDENSER ASSY FRONT BS6-PH2	TATA spare parts
284583500101	HEATER COIL ASSY WITH WATER VALVE	TATA spare parts
284583500102	BLOWER MOTOR	TATA spare parts
284583500103	FAN BLOWER	TATA spare parts
284583500104	RESISTOR 3 POLE BS4	TATA spare parts
284583500107	ASSY DISTRIBUTION CHAMBER M1	TATA spare parts
284583505801	HEATER HOSE HEATER TO ENGINE	TATA spare parts
284583505802	HEATER HOSE ENGINE TO HEATER	TATA spare parts



284583505803	HEATER HOSE FOR CNG (ENGINE TO HEATER)	TATA spare parts
284583506301	VALVE WATER HEATER	TATA spare parts
284583506302	HEATER CASE ASSY	TATA spare parts
284583506303	TANK I/O	TATA spare parts
284583506304	VALVE WATER	TATA spare parts
284583600101	ASSY HEATER INLET	TATA spare parts
284583600102	HEATER HOSE ASSY(OUTLET)	TATA spare parts
284583600103	LIQUID HOSE ASSY (4DL)	TATA spare parts
284583600104	LIQUID PIPE CONDENSER END (2.2L)	TATA spare parts
284583600108	"SUCTION HOSE ASSY,FRONT AC BS6"	TATA spare parts
284583600111	LIQUID PIPE ASSY FRONT CAB BS6	TATA spare parts
284583600112	DISCHARGE PIPE ASSY BS6	TATA spare parts
284583600116	SUCTION PIPE ASSY BS6	TATA spare parts
284583600117	EVAPARATOR PIPE ASSY INTAKE BS6	TATA spare parts
284583600120	DISCHARGE PIPE COMPRESSOR END BS6	TATA spare parts
284583600121	"SUCTION HOSE ASSY,FRONT AC BS6"	TATA spare parts
284583600122	"PIPE ASSY,RECEIVER OUTLET BS6"	TATA spare parts
284583600123	"SUCTION HOSE ASSY,COMPRESSOR END BS6"	TATA spare parts
284583600124	LIQUID PIPE CONDENSER END BS6	TATA spare parts
284583600125	LIQUID PIPE MIDDLE BS6	TATA spare parts
284583600128	LIQUID PIPE CONDENSER TO TXV BS6	TATA spare parts
284583600130	DISCHARGE PIPE ASSY ROOF CONDENSER BS6	TATA spare parts
284583600131	LIQUID PIPE ASSY BS6	TATA spare parts
284583600132	SUCTION PIPE UNIT END BS6	TATA spare parts
284583600134	"DISCHARGE PIPE,COMPRESSOR END BS6"	TATA spare parts
284583600135	"SUCTION HOSE ASSY,COMPRESSOR END BS6"	TATA spare parts
284583600136	SUCTION PIPE ASSY BS6	TATA spare parts
284583600139	PIPE ASSY RECEIVER DRIER OUTLET BS6-PH2	TATA spare parts
284583600143	SUCTION PIPE REAR AC BS6	TATA spare parts
284583600145	LIQUID PIPE ASSY BS6	TATA spare parts
284583600150	SUCTION PIPE ASSY B-PILLAR BS6	TATA spare parts
284583600152	LIQUID PIPE ASSY BS6	TATA spare parts
284583600155	DISCHARGE HOSE ASSY CONDENSER INTAKE BS6	TATA spare parts
284583600156	LIQUID PIPE ASSY BS6	TATA spare parts
284583600157	PIPE ASSY RECEIVER DRIER OUTLET BS6	TATA spare parts
284583600160	DISCHARGE HOSE ASSY FRONT CONDENSER BS6	TATA spare parts
284583600161	DISCHARGE PIPE ASSY FRONT BS6	TATA spare parts
284583600162	DISCHARGE HOSE ASSY BS6-PH2	TATA spare parts
284583600163	LIQUID PIPE RECEIVER DRIER INLET BS6-PH2	TATA spare parts
284583600168	LIQUID PIPE ASSY B-PILLAR BS6	TATA spare parts
284583600170	LIQUID PIPE ASSY B-PILLAR BS6-PH2	TATA spare parts
284583600172	AC PIPE ASSY BS6	TATA spare parts
284583606922	PIPE ASSY CONDENSER OUTLET BS6	TATA spare parts
284583650101	HEATER HOSE ASSY INLET BS6	TATA spare parts
284583650102	HEATER HOSE ASSY OUTLET BS6	TATA spare parts
284583707501	GROMMET DRAIN HOSE	TATA spare parts
284583707503	FOAM PACKING BS6-PH2	TATA spare parts

284583750102	BRACKET ASSY SUCTION PIPE MTG BS6-PH2	TATA spare parts
284583750103	BRACKET ASSY LIQUID TUBE MTG BS6-PH2	TATA spare parts
284583750104	BRACKET ASSY AC PIPE BS6-PH2	TATA spare parts
284583750109	BRACKET ASSY HEATER HOSE BS6-PH2	TATA spare parts
284583750111	BRACKET ASSY HEATER HOSE BS6-PH2	TATA spare parts
284583753316	BRACKET ASSY RECEIVER DRIER MTG BS6	TATA spare parts
284583753317	BRACKET ASSY AC UNIT MTG BS6	TATA spare parts
284583753319	BRACKET BS6-PH2	TATA spare parts
284583753333	BRACKET AC UNIT MTG RH BS6-PH2	TATA spare parts
284583753335	BRACKET AC UNIT MTG LH BS6-PH2	TATA spare parts
284583806301	ROOF AC AIR INTAKE GRILLE	TATA spare parts
284583806306	DASH LH AIRVENT COVER FOR NON AC VERSION	TATA spare parts
284583990101	MISCELLANEOUS KIT FOR FLAT ROOF WINGER A	TATA spare parts
284583990102	MISCELLANEOUS KIT FOR HIGH ROOF WINGER	TATA spare parts
284583990103	MISCELLANEOUS KIT FOR ST AMBULANCE WINGER	TATA spare parts
284583990105	KIT-ROOF AC BS6	TATA spare parts
284583993301	KIT MOUNTIN BRACKETS BS6	TATA spare parts
284583993302	KIT MOUNTIN BRACKETS BS6	TATA spare parts
284583995801	DRAIN HOSE ASSY HIGH ROOF AC UNIT BS6	TATA spare parts
284586000101	ASSY KIT AMBULANCE	TATA spare parts
284586000104	ASSY STRETCHER COMPLETE 2800	TATA spare parts
284586000105	ASSY OXYGEN CYLINDER MTG	TATA spare parts
284586000106	ASSY WASH BASIN	TATA spare parts
284586000107	FRONT 2 SEATER 2800 AMBULANCE	TATA spare parts
284586000108	REAR 2 SEATER 2800 AMBULANCE	TATA spare parts
284586000109	ASSY CHEQUERED PLATE REAR FLOOR	TATA spare parts
284586000110	ASSY ROOF PVC COATING	TATA spare parts
284586000111	ASSY IV HOOK	TATA spare parts
284586000113	FRONT SINGLE SEAT 3200 AMBULANCE	TATA spare parts
284586000114	FRONT 3 SEATER 3200 AMBULANCE	TATA spare parts
284586000115	REAR 2 SEATER 3200 AMBULANCE	TATA spare parts
284586000116	ASSY KIT AMBULANCE 3200WB	TATA spare parts
284586000119	ASSY FRNT SINGLE SEATER 3488WB AMBULANCE	TATA spare parts
284586000125	ASSY STRETCHER	TATA spare parts
284586000126	ASSY WHEEL	TATA spare parts
284586000127	ASSY FIRST AID BOX	TATA spare parts
284586000128	ASSY STRETCHER SUPPORT FRAME	TATA spare parts
284586000129	ASSY LOCK STRETCHER	TATA spare parts
284586000130	ASSY STRETCHER SUPPORT BOX	TATA spare parts
284586000132	ASSY FRONT 4 SEATER 3488WB AMBULANCE	TATA spare parts
284586000133	ASSY STRETCHER 3488WB AMBULANCE	TATA spare parts
284586000134	SEAT LAYOUT 8+D AMBULANCE KIT	TATA spare parts
284586000135	ASSY AMBULANCE KIT 7+D 3488WB	TATA spare parts
284586000190	STRETCHER ASSY	TATA spare parts
284586000191	STRETCHER ASSY	TATA spare parts
284586000193	OXYGEN CYL ASSY BS6	TATA spare parts
284586000194	SPARE WHEEL BOX	TATA spare parts

284586000195	2-SEATER AMBULANCE ASSY	TATA spare parts
284586000196	3-SEATER AMBULANCE ASSY	TATA spare parts
284586000197	4-SEATER AMBULANCE ASSY	TATA spare parts
284586000198	FLOOR EXTENSION BS6	TATA spare parts
284586006301	CUSHION STRETCHER	TATA spare parts
284586008201	LATCH BRACKET STRETCHER	TATA spare parts
284586008202	STOPPER PLATE	TATA spare parts
284586100101	STRETCHER ASSY BS6	TATA spare parts
284586100102	STRETCHER ASSY BS6	TATA spare parts
284586100103	STRETCHER ASSY BS6	TATA spare parts
284586100104	STRETCHER ASSY BS6	TATA spare parts
284586100107	ACTUATING PIPE STRETCHER ASSY BS6	TATA spare parts
284586100108	ACTUATING LEVER STRETCHER ASSY BS6	TATA spare parts
284586100109	REVOLVING WHEEL STRETCHER ASSY BS6	TATA spare parts
284586100110	SAFETY LOCK STRETCHER ASSY BS6	TATA spare parts
284586100111	LEG STRETCHER ASSY BS6	TATA spare parts
284586100112	LOCK STRETCHER ASSY BS6	TATA spare parts
284586100113	HEADREST LOCK STRETCHER ASSY BS6	TATA spare parts
284586100114	IV STAND STRETCHER ASSY BS6	TATA spare parts
284586100115	HEADREST LEVER STRETCHER ASSY BS6	TATA spare parts
284586100116	GUARD STRETCHER ASSY BS6	TATA spare parts
284586100117	STRAP BELT STRETCHER ASSY BS6	TATA spare parts
284586100118	CUSHION STRETCHER ASSY BS6	TATA spare parts
284586100119	FOOTREST LOCK STRETCHER ASSY BS6	TATA spare parts
284586100121	LOCK STUD STRETCHER ASSY BS6	TATA spare parts
284586100123	RAIL STRETCHER ASSY BS6	TATA spare parts
284586100125	LOCK STRETCHER ASSY BS6	TATA spare parts
284586100127	SAFETY PIN STRETCHER ASSY BS6	TATA spare parts
284586100128	LOCK STRETCHER ASSY BS6	TATA spare parts
284586100129	HINGE STRETCHER ASSY BS6	TATA spare parts
284586100131	WHEEL STRETCHER ASSY BS6	TATA spare parts
284586106301	IDLE WHEEL STRETCHER ASSY BS6	TATA spare parts
284586106302	WHEEL STRETCHER ASSY BS6	TATA spare parts
284586106305	CUSHION STRETCHER ASSY BS6	TATA spare parts
284586106306	BELT LOCK STRETCHER ASSY BS6	TATA spare parts
284586106307	BUSH STRETCHER ASSY BS6	TATA spare parts
284586106308	WHEEL STRETCHER ASSY BS6	TATA spare parts
284586106309	ACHRYLIC SHEET STRETCHER ASSY BS6	TATA spare parts
284586106310	ACHRYLIC SHEET STRETCHER ASSY BS6	TATA spare parts
284586106311	ACHRYLIC SHEET STRETCHER ASSY BS6	TATA spare parts
284586107701	CAP STRETCHER TROLLEY ASSY BOTTOM BS6	TATA spare parts
284586107702	CAP STRETCHER TROLLEY ASSY BOTTOM BS6	TATA spare parts
284586107703	CAP HEADREST LEVER STRETCHER ASSY BS6	TATA spare parts
284586107704	COVER FOOTREST LEVER STRETCHER ASSY BS6	TATA spare parts
284586107705	COVER FOOTREST LEVER STRETCHER ASSY BS6	TATA spare parts
284586107706	CAP SALINE CHANNEL STRETCHER ASSY BS6	TATA spare parts
284586108201	CURTAIN WIRE	TATA spare parts

284586108202	IV SALINE CHANNEL	TATA spare parts
284586108205	CHANNEL BS6	TATA spare parts
284586108220	SPRING STRETCHER ASSY BS6	TATA spare parts
284586108226	RAIL STRETCHER ASSY BS6	TATA spare parts
284586108230	LOCK PLATE STRETCHER ASSY BS6	TATA spare parts
284586108241	SCREW STRETCHER ASSY BS6	TATA spare parts
284586108247	KNOB & PLUNGER STRETCHER ASSY BS6	TATA spare parts
284586108701	SPRING STRETCHER ASSY BS6	TATA spare parts
284586108702	SPRING STRETCHER ASSY BS6	TATA spare parts
284586108703	SPRING STRETCHER ASSY BS6	TATA spare parts
284586600101	MEDICAL EQUIPMENT BS6	TATA spare parts
284586600102	MEDICAL EQUIPMENT BS6	TATA spare parts
284586706301	ROOF PVC COATING FRONT LH	TATA spare parts
284586706302	ROOF PVC COATING FRONT RH	TATA spare parts
284586706303	ROOF PVC COATING FRONT CENTRE	TATA spare parts
284586706304	ROOF PVC COATING REAR LH	TATA spare parts
284586706305	ROOF PVC COATING REAR RH	TATA spare parts
284586706306	ROOF PVC COATING REAR CENTRE	TATA spare parts
284586706307	ROOF PVC COATING REAR TAILGATE	TATA spare parts
284586706308	ROOF BEADING	TATA spare parts
284586708201	ALUMINIUM CHANNEL	TATA spare parts
284586800108	OXYGEN CYL ASSY BS6	TATA spare parts
284586800109	FIRE EXTINGUISHER BS6	TATA spare parts
284586800115	HAND RAIL & HAND HOLD	TATA spare parts
284586800117	FLOOR EXTENSION BS6	TATA spare parts
284586800118	FLOOR EXTENSION BS6	TATA spare parts
284586800119	HOOK ASSY BS6	TATA spare parts
284586800120	STORAGE BOX BS6	TATA spare parts
284586800121	FLOOR EXTENSION BS6	TATA spare parts
284586800123	PUBLIC ADDRESS SYSTEM BS6	TATA spare parts
284586800125	PUBLIC ADDRESS SYSTEM BS6	TATA spare parts
284586800126	SIREN BS6	TATA spare parts
284586808201	CHANNEL BS6	TATA spare parts
284586808202	CHANNEL BS6	TATA spare parts
284588100101	ASSY SIDE BONNET OUTER LH	TATA spare parts
284588100102	ASSY SIDE BONNET OUTER RH	TATA spare parts
284588100103	SIDE BONNET ASSY LH BS6	TATA spare parts
284588100104	SIDE BONNET ASSY RH BS6	TATA spare parts
284588100111	FENDER ASSY OUTER-LH BS6	TATA spare parts
284588100112	FENDER ASSY OUTER-RH BS6	TATA spare parts
284588100118	ASSY SIDE BONNET OTR WITH CED COATED LH	TATA spare parts
284588100119	ASSY SIDE BONNET OTR WITH CED COATED RH	TATA spare parts
284588120103	FRONT MUD GUARD LINER BS6	TATA spare parts
284588300101	ASSY REAR FOOTSTEP	TATA spare parts
284588406303	BUTYL PAD FIREWALL	TATA spare parts
284588460102	BRACKET ASSY FRONT BUMPER MTG LOWER-LH BS6	TATA spare parts
284588460103	BRACKET ASSY FRONT BUMPER MTG LOWER-RH BS6	TATA spare parts

284588460106	BRACKET ASSY FRONT BUMPER BOTTOM MTG BS	TATA spare parts
284588460107	SUPPORT ASSY CENTER BUMPER MTG BS6	TATA spare parts
284588460108	BRACKET ASSY FRONT BUMPER MTG LH BS6	TATA spare parts
284588500101	ASSY. FRONT BUMPER BS3/4	TATA spare parts
284588500101D3	FRONT BUMPER ASSY	TATA spare parts
284588500101D8	FRONT BUMPER ASSY PEARL WHITE	TATA spare parts
284588500101EN	FRONT BUMPER ASSY	TATA spare parts
284588500101GM	BUMPER ASSY FRONT SARDINIA_RED	TATA spare parts
284588500101HB	FRONT BUMPER ASSY	TATA spare parts
284588500104	ASSY. FRONT BUMPER BS3/4	TATA spare parts
284588500104HB	FRONT BUMPER ASSY (WITHOUT FOG LAMP)	TATA spare parts
284588500107	ASSY. FRONT BUMPER W/O FOG LAMP BS2/3/4	TATA spare parts
284588500113	ASSY MTG BKT FRONT BUMPER LH M1	TATA spare parts
284588500114	ASSY MTG BKT FRONT BUMPER RH M1	TATA spare parts
284588500118	ASSY FRONT BUMPER MTG BRACKET LH BS-IV	TATA spare parts
284588500119	ASSY FRONT BUMPER MTG BRACKET RH BS4	TATA spare parts
284588500129	BUMPER ASSY BS6	TATA spare parts
284588500129C7	GRANIT_BLACK-BUMPER ASSY BS6	TATA spare parts
284588500129D8	PEARL_WHITE-BUMPER ASSY BS6	TATA spare parts
284588500130	HEADLAMP ACCESS COVER ASSY BUMPER-LH BS	TATA spare parts
284588500131	HEADLAMP ACCESS COVER ASSY BUMPER-RH BS	TATA spare parts
284588506302	INNER ENERGY	TATA spare parts
284588506303	OUTER ENERGY ABSORBER LH	TATA spare parts
284588506304	OUTER ENERGY ABSORBER RH	TATA spare parts
284588506308	REFLECTIVE TAPE LONG BS6	TATA spare parts
284588506309	SHORT REFLECTIVE TAPE	TATA spare parts
284588506311	WHITE REFLECTIVE TAPE FRONT BUMPER	TATA spare parts
284588506313	RED REFLECTIVE TAPE 660X20	TATA spare parts
284588506314	BONNET CORNER REF. TAPE	TATA spare parts
284588506315	BONNET CENTER REF. TAPE WHITE	TATA spare parts
284588506316	TAILGATE REFLECTIVE TAPE RED	TATA spare parts
284588506329	GRILL FRONT BUMPER TOP BS6	TATA spare parts
284588506330C7	GRANIT_BLACK-FRONT BUMPER BS6	TATA spare parts
284588506337	GRILL FOG LAMP LH BS6-PH2	TATA spare parts
284588506338	GRILL FOG LAMP RH BS6-PH2	TATA spare parts
284588506339	GRILL FRONT BUMPER LOWER BS6-PH2	TATA spare parts
284588506340	FOG LAMP BEZEL ASSY LH BS6	TATA spare parts
284588506341	FOG LAMP BEZEL ASSY RH BS6	TATA spare parts
284588506342	BRACKET BUMPER MTG FRONT- LH BS6	TATA spare parts
284588506343	BRACKET BUMPER MTG FRONT- RH BS6	TATA spare parts
284588600102	SIDE ABSORBER ASSY	TATA spare parts
284588600103	TOW HOOK	TATA spare parts
284588600104	BUMPER REAR CENTRAL	TATA spare parts
284588600107	CENTRAL BUMPER ASSY WITHOUT POWDERCOAT	TATA spare parts
284588600144	REAR BUMPER ASSY LH BS6	TATA spare parts
284588600144C7	GRANIT_BLACK-REAR BUMPER ASSY LH BS6	TATA spare parts
284588600144D8	PEARL_WHITE-REAR BUMPER ASSY LH BS6	TATA spare parts

284588600145	REAR BUMPER ASSY RH BS6	TATA spare parts
284588600145C7	GRANIT_BLACK-REAR BUMPER ASSY RH BS6	TATA spare parts
284588600145D8	PEARL_WHITE-REAR BUMPER ASSY RH BS6	TATA spare parts
284588606301	BUMPER LHS REAR BS2/3/4	TATA spare parts
284588606301D3	BUMPER LHS REAR	TATA spare parts
284588606301D8	BUMPER LHS REAR PEARL WHITE	TATA spare parts
284588606301EN	BUMPER LHS REAR CYCUS_GREY	TATA spare parts
284588606301HB	BUMPER LHS REAR	TATA spare parts
284588606304	ENERGY ABSORBER LHS	TATA spare parts
284588606305	ENERGY ABSORBER L RHS	TATA spare parts
284588606306	BUMPER RHS REAR BS2/3/4	TATA spare parts
284588606306D3	BUMPER RHS REAR	TATA spare parts
284588606306D8	BUMPER RHS REAR PEARL WHITE	TATA spare parts
284588606306EN	BUMPER RHS REAR CYCUS_GREY	TATA spare parts
284588606306HB	BUMPER RHS REAR	TATA spare parts
284588606316	REAR BUMPER LH M1 W	TATA spare parts
284588606316EN	REAR BUMPER LH M1 WINGER	TATA spare parts
284588606317	REAR BUMPER RH M1 W	TATA spare parts
284588606317EN	REAR BUMPER RH M1 WINGER	TATA spare parts
284588606333	BRACKET REAR BUMPER MTG LH BS6	TATA spare parts
284588606334	BRACKET REAR BUMPER MTG RH BS6	TATA spare parts
284588607701	RUBBER BEADING FOR REAR BUMPER	TATA spare parts
284588700102	ASSY BONNET SHELL	TATA spare parts
284588700109	ASSY BONNET HINGE COMPLET	TATA spare parts
284588700110	ASSY BONNET HINGE COMPLET	TATA spare parts
284588700115	ASSY ENGINE HOOD COMPLETE	TATA spare parts
284588700117	RELEASE LEVER ASSY	TATA spare parts
284588700119	BONNET LOCK KIT	TATA spare parts
284588700120	RELEASE LEVER ASSY	TATA spare parts
284588700121	BONNET LATCH ASSY	TATA spare parts
284588700122	ASSY CENTER BONNET SHELL COMPLETE	TATA spare parts
284588700123	ASSY. CENTER BONNET W/CED COATED BS2/3/4	TATA spare parts
284588700127	ASSY ENGINE HOOD COMPLETE AC VERSION.	TATA spare parts
284588700135	ASSY ENGINE HOOD COMPLETE M1 WINGER	TATA spare parts
284588700160	CENTERBONNETSHELLASSYWITHHINGES BS6	TATA spare parts
284588700162	CENTER BONNET ASSY INNER BS6	TATA spare parts
284588700170	HINGE ASSY CENTER BONNET LH BS6	TATA spare parts
284588700171	HINGE ASSY CENTER BONNET RH BS6	TATA spare parts
284588700181	CABLE ASSY HOOD LATCH BS6	TATA spare parts
284588700182	KIT-STAY ROD BS6	TATA spare parts
284588700186	BRACKET ASSY FENDER UPPER-LH BS6	TATA spare parts
284588700187	BRACKET ASSY FENDER UPPER-RH BS6	TATA spare parts
284588704303	CLIP SUPPORT FOR LINK	TATA spare parts
284588706306	STAY ROD CLIP	TATA spare parts
284588706307	CLIP SUPPORT ON FENDER	TATA spare parts
284588706309	BONNET CROME STRIP M1 WINGER	TATA spare parts
284588707701	BONNET RUBBER STOP	TATA spare parts

284588707702	BONNET RUBBER STOP PREMIER SEAL	TATA spare parts
284588707706	BONNET SEAL REAR BS6	TATA spare parts
284588707707	BONNET SEAL FRONT BS6	TATA spare parts
284588707708	FOAM HOOD INNER BS6-PH2	TATA spare parts
284588708216	STRIKER LHS	TATA spare parts
284588708217	SECONDARY LEVER ASSY	TATA spare parts
284588708218	STRIKER RHS	TATA spare parts
284588708219	SECONDARY BONNET OPENING LINK	TATA spare parts
284588708221	BONNET STAY ROD	TATA spare parts
284588708222	SECONDARY BONNET OPENING LINK	TATA spare parts
284588708223	SECONDARY LEVER ASSY	TATA spare parts
284588708224	BONNET STRIKER LH	TATA spare parts
284588708225	BONNET STRIKER RH	TATA spare parts
284588708244	BONNET OUTER BS6-PH2	TATA spare parts
284588708271	BRACKET FENDER LOWER-LH BS6	TATA spare parts
284588708272	BRACKET FENDER LOWER-RH BS6	TATA spare parts
284588708701	SPRING OF TRACTION TYPE 150	TATA spare parts
284588800101	TRUST BAR ASSY BS6	TATA spare parts
284588800102	TRUST BAR ASSY BS6	TATA spare parts
284588806303	TRUST BAR BS6	TATA spare parts
284588806304	TRUST BAR BS6	TATA spare parts
284588806305	LEAF SCREEN BS6	TATA spare parts
284591000104	ASSY DRIVER SEAT(13+1 12+1)VSPL2800	TATA spare parts
284591000106	ASSY DRIVER SEAT(12&13+1)3200	TATA spare parts
284591000109	ASSY DRIVER SEAT AMBUL32WB DUAL AC BIEGE	TATA spare parts
284591000110	ASSY DRIVER SEAT	TATA spare parts
284591000111	ASSY DRIVER SEAT	TATA spare parts
284591000112	ASSY DRIVER SEAT STRETCH WINGER	TATA spare parts
284591000113	ASSY DRIVER SEAT 6+1 M1 WINGER.	TATA spare parts
284591000119	DRIVER SEAT ASSY	TATA spare parts
284591000125	DRIVER SEAT ASSY BS6-PH2	TATA spare parts
284591000126	DRIVER SEAT ASSY BS6-PH2	TATA spare parts
284591000127	DRIVER SEAT ASSY	TATA spare parts
284591000128	DRIVER SEAT ASSY BS6	TATA spare parts
284591000131	DRIVER SEAT ASSY BS6	TATA spare parts
284591000132	DRIVER SEAT ASSY BS6	TATA spare parts
284591100101	RISER ASSY	TATA spare parts
284591100105	RISER ASSY DRIVER SEAT RH BS6	TATA spare parts
284591200102	CUSHION ASSY DRIVER SEAT BS6	TATA spare parts
284591300102	BACKREST ASSY DRIVER SEAT BS6	TATA spare parts
284591500104	ASSY KIT SEAT BELT 13+D DRIVER ROW	TATA spare parts
284591500105	SEAT BELT ASSY LH	TATA spare parts
284591500106	SEAT BELT ASSY RH	TATA spare parts
284591500107	CABLE BUCKLE ASSY RH	TATA spare parts
284591500109	ASSY KIT SEAT BELT 9+D	TATA spare parts
284591500110	ASSY KIT SEAT BELT12&13+1(DRIVER ROW)	TATA spare parts
284591500111	CABLE BUCKLE ASSY LH&MIDDLE 12 13+1 IFB	TATA spare parts

284591500112	CABLE BUCKLE ASSY RH 12 13+1 AUTOLIVEIFB	TATA spare parts
284591500113	TOUNGE ASSY LH 12 13+1 DRIVER ROW IFB	TATA spare parts
284591500114	TOUNGE ASSY RH 12 13+1 DRIVER ROW IFB	TATA spare parts
284591500115	LAP BELT ASSY 12 13+1 DRIVER ROW IFB	TATA spare parts
284591500116	ASSY KIT SEAT BELT 13+D DRIVER ROW	TATA spare parts
284591500117	LAP BELT ASSY	TATA spare parts
284591500118	CABLE BUCKLE ASSY LH & MIDDLE13+1 BIEGE	TATA spare parts
284591500119	ASSY KIT FR ROW SEAT BELT 6+1	TATA spare parts
284591750101	COVER TRIM FRONT SEAT RISER RH BS6	TATA spare parts
284591900102	SLIDER ASSY LH	TATA spare parts
284591900103	SLIDER ASSY RH	TATA spare parts
284591900105	HEIGHT ADJUSTER	TATA spare parts
284591900106	ADJUSTER ASSY BS6	TATA spare parts
284591900107	TRACK ASSY RH BS6	TATA spare parts
284591930101	HEADREST ASSY	TATA spare parts
284591930102	HEADREST ASSY DRIVER SEAT BS6	TATA spare parts
284592000103	ASSY 2 SEATER 3RD ROW	TATA spare parts
284592000104	ASSY 2 SEATER 2NDROW 9+1 VSPL	TATA spare parts
284592000105	ASSY 1 SEATER	TATA spare parts
284592000106	ASSY 1 SEATER REAR LH(9+1)VSPL	TATA spare parts
284592000107	ASSY 2 SEATER REAR SEAT RH(12+1)VSPL	TATA spare parts
284592000108	ASSY MIDDLE REAR SEAT(9+1)VSPL	TATA spare parts
284592000109	ASSY 2 SEATER REAR SEAT LH(12+1)VSPL	TATA spare parts
284592000110	ASSY 1 SEATER REAR RH (9+1)VSPL	TATA spare parts
284592000111	ASSY2SEATER REAR RH(13+1 12+1)28VSPL	TATA spare parts
284592000112	ASSY2SEATER REAR LH(13+112+1)28VSPL	TATA spare parts
284592000113	ASSY 1SEAT(13+1 12+1)2800 VSPL	TATA spare parts
284592000114	ASSY2SEATER 2NDROW(13+1 12+1)28VSPL	TATA spare parts
284592000115	ASSY4SEATER RISER(13+1 12+1)2800VSPL	TATA spare parts
284592000116	ASSY 2SEATER 3RD ROW(12&13+1)280VSPL	TATA spare parts
284592000117	ASSY 2 SEATER 2ND ROW 13+1 3200 VSPL	TATA spare parts
284592000118	ASSY 4 SEATER REAR 4TH ROW 12 13+1 32	TATA spare parts
284592000119	ASSY 3 SEATER 4TH ROW 9+1(3200VSPL)	TATA spare parts
284592000120	ASSY 2 SEATER 2ND ROW 12+1 3200 VSPL	TATA spare parts
284592000121	HEX SCR M6X16 IS1364P2-8.8-SS8457S1-BL-B	TATA spare parts
284592000122	ASSY 2 SEATER 3RDROW 9+13200	TATA spare parts
284592000128	ASSY 2 SEATER 2ND ROW 13+1 3200	TATA spare parts
284592000129	ASSY 2 SEATER 3RD ROW 13+1 3200	TATA spare parts
284592000130	ASSY 4 SEATER REAR 4TH ROW3200	TATA spare parts
284592000131	ASSY 2 SEATER REAR LH 3200	TATA spare parts
284592000132	ASSY 2 SEATER REAR RH 3200	TATA spare parts
284592000133	ASSY 1 SEATER 3RD ROW 3200	TATA spare parts
284592000141	ASSY 2 SEATER 2ND ROW 12+1 3200	TATA spare parts
284592000145	ASSY 2 SEATER 2ND ROW 9+1 2800	TATA spare parts
284592000146	ASSY SINGLE SEATER 2ND ROW 9+1 2800	TATA spare parts
284592000147	ASSY 4 SEATER REAR 3RD ROW 9+1 2800	TATA spare parts
284592000150	ASSY REAR 2 SEATER 4TH ROW CNG LUX	TATA spare parts



284592000151	ASSY REAR 1 SEATER 4TH ROW CNG LUX	TATA spare parts
284592000152	ASSY 2 SEATER 2ND ROW 6+1 M1 WINGER	TATA spare parts
284592000153	ASSY 3 SEATER 3RD ROW 6+1 M1WINGER	TATA spare parts
284592000154	ASSY 2SEATER REAR 4TH ROW LH CNG BIEGE	TATA spare parts
284592000155	ASSY 2SEATER REAR 4TH ROW RH CNG BIEGE	TATA spare parts
284592000173	2ND ROW SINGLE SEAT ASSY	TATA spare parts
284592000174	2ND ROW TWIN SEAT ASSY	TATA spare parts
284592000175	4TH ROW SINGLE SEAT ASSY	TATA spare parts
284592000176	2-SEATER 4TH ROW SEAT ASSY RH	TATA spare parts
284592000177	5TH ROW TWIN SEAT	TATA spare parts
284592010129	2-SEATER 3RD ROW SEAT ASSY	TATA spare parts
284592010130	SINGLE SEATER 3RD ROW SEAT ASSY	TATA spare parts
284592010131	2-SEATER 2ND ROW SEAT ASSY	TATA spare parts
284592020103	SEAT ASSY BS6	TATA spare parts
284592020109	SEAT ASSY BS6	TATA spare parts
284592020114	SINGLE SEATER 3RD ROW SEAT ASSY BS6	TATA spare parts
284592020115	2-SEATER 3RD ROW SEAT ASSY BS6-PH2	TATA spare parts
284592020119	3-SEATER 4TH ROW SEAT ASSY BS6-PH2	TATA spare parts
284592020121	2-SEATER 3RD ROW SEAT ASSY BS6	TATA spare parts
284592020124	REAR SEAT ASSY BS6	TATA spare parts
284592020125	REAR SEAT ASSY BS6	TATA spare parts
284592020126	2ND ROW TWIN SEAT ASSY BS6	TATA spare parts
284592020134	2-SEATER 2ND ROW SEAT ASSY BS6-PH2	TATA spare parts
284592020139	2-SEATER 2ND ROW SEAT ASSY BS6	TATA spare parts
284592020146	SINGLE SEATER 3RD ROW SEAT ASSY BS6	TATA spare parts
284592020149	2-SEATER 3RD ROW SEAT ASSY BS6	TATA spare parts
284592020184	2-SEATER 2ND ROW SEAT ASSY BS6	TATA spare parts
284592020185	REAR SEAT ASSY BS6	TATA spare parts
284592020186	2-SEATER 3RD ROW SEAT ASSY BS6	TATA spare parts
284592020188	SINGLE SEATER 3RD ROW SEAT ASSY BS6	TATA spare parts
284592020193	5TH ROW TWIN SEAT BS6	TATA spare parts
284592020199	3RD ROW SINGLE SEAT ASSY BS6	TATA spare parts
284592030103	2-SEATER 2ND ROW SEAT ASSY BS6	TATA spare parts
284592030105	4TH ROW SINGLE SEAT ASSY BS6	TATA spare parts
284592030106	2ND ROW SINGLE SEAT ASSY BS6	TATA spare parts
284592030108	2-SEATER 4TH ROW SEAT ASSY BS6	TATA spare parts
284592030110	2-SEATER 2ND ROW SEAT ASSY BS6-PH2	TATA spare parts
284592030111	2-SEATER 3RD ROW SEAT ASSY	TATA spare parts
284592030113	SINGLE SEATER 3RD ROW SEAT ASSY BS6-PH2	TATA spare parts
284592030114	3-SEATER 4TH ROW SEAT ASSY BS6-PH2	TATA spare parts
284592030115	2ND ROW TWIN SEAT ASSY	TATA spare parts
284592030116	REAR SEAT ASSY LH BS6-PH2	TATA spare parts
284592030119	REAR SEAT ASSY BS6-PH2	TATA spare parts
284592030120	2-SEATER 3RD ROW SEAT ASSY BS6-PH2	TATA spare parts
284592030121	2-SEATER 4TH ROW SEAT ASSY BS6-PH2	TATA spare parts
284592030122	REAR SEAT ASSY RH BS6-PH2	TATA spare parts
284592030123	2ND ROW SEAT ASSY RH BS6-PH2	TATA spare parts

284592030128	2-SEATER 2ND ROW SEAT ASSY BS6-PH2	TATA spare parts
284592030129	REAR SEAT ASSY	TATA spare parts
284592030130	2-SEATER 3RD ROW SEAT ASSY	TATA spare parts
284592030131	SINGLE SEATER 3RD ROW SEAT ASSY	TATA spare parts
284592030132	2ND ROW TWIN SEAT ASSY	TATA spare parts
284592030133	REAR SEAT ASSY BS6-PH2	TATA spare parts
284592100101	ASSY REAR SEAT RISER(12+1)VSPL	TATA spare parts
284592100102	ASSY REAR 3 SEATER RISER	TATA spare parts
284592750103	PLASTIC COVER THIRD ROW RH BS6	TATA spare parts
284592750108	HANDLE REAR SEAT RH BS6	TATA spare parts
284592900101	RECLINER ASSY LH	TATA spare parts
284593000101	ASSY TUMBLING SEAT12+1VSPL3200	TATA spare parts
284593000102	ASSY TUMBLING SEAT (9+1)VSPL	TATA spare parts
284593000103	ASSY TUMBLING2SEATER(13+128VSPL	TATA spare parts
284593000104	ASSY TUMBLING SINGLE SEATER 12+1VSPL2800	TATA spare parts
284593000105	ASSY TUMBLING 2 SEATER 13+1 3200VSPL	TATA spare parts
284593000109	ASSY TUMBLING 2 SEATER(3200)	TATA spare parts
284593000111	ASSY TUMBLING 1 SEAT 12+1 3200	TATA spare parts
284593000132	TUMBLE SEAT ASSY BS6	TATA spare parts
284593000133	TUMBLE SEAT ASSY BS6	TATA spare parts
284593000134	TUMBLE SEAT ASSY BS6-PH2	TATA spare parts
284593000136	TUMBLE SEAT ASSY BS6	TATA spare parts
284593000139	TUMBLE SEAT ASSY	TATA spare parts
284593000142	TUMBLE SEAT ASSY BS6-PH2	TATA spare parts
284593000143	TUMBLE SEAT ASSY	TATA spare parts
284593900101	LATCH ASSY LH	TATA spare parts
284593900102	LATCH ASSY RH	TATA spare parts
284593908701	RETURN SPRING TUMBLING SEAT	TATA spare parts
284594000101	ASSY CO-DRIVER SEAT(12+1)3200VSPL	TATA spare parts
284594000102	ASSY CO-DRIVER SEAT (9+1)VSPL	TATA spare parts
284594000103	ASSY CO-DRIVER SEAT(13+1 12+1)28VSPL	TATA spare parts
284594000105	ASSY CO-DRIVER 2 SEATER 3200	TATA spare parts
284594000108	ASSY CO-DRIVER SEAT CLOSED GOODS	TATA spare parts
284594000109	ASSY CO-DRIVER SEAT AMBULANCE32B002	TATA spare parts
284594000111	ASSY CO-DRIVER SEAT ST.WINGER BIEGE	TATA spare parts
284594000112	ASSY CO-DRIVER SEAT 6+1 M1 WINGER	TATA spare parts
284594000115	CO-DRIVER SEAT ASSY	TATA spare parts
284594000122	CO-DRIVER SEAT ASSY	TATA spare parts
284594000123	CO-DRIVER 2-SEATER ASSY	TATA spare parts
284594000131	CO-DRIVER SEAT ASSY BS6	TATA spare parts
284594000132	CO-DRIVER 2-SEATER ASSY BS6	TATA spare parts
284594000133	CO-DRIVER SEAT ASSY BS6-PH2	TATA spare parts
284594000136	CO-DRIVER SEAT ASSY BS6-PH2	TATA spare parts
284594000137	CO-DRIVER SEAT ASSY BS6-PH2	TATA spare parts
284594000140	2-SEATER CO-DRIVER SEAT ASSY BS6	TATA spare parts
284594000142	CO-DRIVER SEAT ASSY BS6	TATA spare parts
284594000143	CO-DRIVER SEAT ASSY BS6-PH2	TATA spare parts

284594000145	CO-DRIVER SEAT ASSY BS6	TATA spare parts
284594000146	CO-DRIVER SEAT ASSY BS6-PH2	TATA spare parts
284594010106	CO-DRIVER SEAT ASSY BS6	TATA spare parts
284594900101	DAMPER ASSY	TATA spare parts
284597500101	SEAT BELT ASSY WITH ELR FRONT-RH BS6	TATA spare parts
284597500102	WEBBING BUCKLE ASSY MIDDLE BS6-PH2	TATA spare parts
284597500103	CABLE BUCKLE ASSY DRIVER BS6	TATA spare parts
284597500103C7	GRANIT_BLACK-CABLE BUCKLE ASSY DRIVER BS	TATA spare parts
284597500104C7	GRANIT_BLACK-CABLE BUCKLE ASSY CO-DRIVER	TATA spare parts
284597500105	LAP BELT ASSY MIDDLE BS6-PH2	TATA spare parts
284597500105C7	GRANIT_BLACK-LAP BELT ASSY MIDDLE BS6	TATA spare parts
284597500106	SEAT BELT ASSY WITH ELR FRONT-RH BS6	TATA spare parts
284597500106C7	GRANIT_BLACK-SEAT BELT ASSY WITH ELR FRO	TATA spare parts
284597500107	SEAT BELT ASSY WITH ELR FRONT-LH BS6-PH2	TATA spare parts
284597500107C7	GRANIT_BLACK-SEAT BELT ASSY WITH ELR FRO	TATA spare parts
284597500108	WEBBING BUCKLE ASSY CO-DRIVER & MIDDLE B	TATA spare parts
284597980102	KIT-SEAT BELT FRONT	TATA spare parts
284597980104	WEBBING BUCKLE ASSY CO-DRIVER & MIDDLE	TATA spare parts
284598800101	BRACKET ASSY FOR HAMMER MTG	TATA spare parts
284599000101	ASSY KNOB SPARE WHEEL	TATA spare parts
284599006501	METAL CLIP M5	TATA spare parts
284599006512	FLANGED NUT M6X1.0	TATA spare parts
284599006541	U SPHIRE NUT	TATA spare parts
284599006550	CAGE NUT M5(DASHBOARD)	TATA spare parts
284599006551	U SPIRE NUT M5 DASHBOARD	TATA spare parts
284599006555	U CLIP DRIP RAIL SEALING	TATA spare parts
284599006556	U SPIRE NUT M5 DASHBOARD	TATA spare parts
284599008048	M6X1X45 COUNTER SUNK SCREW	TATA spare parts
284599008055	CR REC PAN HD SCR M8 IS7483 SS8457S1-BL-	TATA spare parts
284599106704	HINGE PIN	TATA spare parts
284599203401	HINGE BUSH	TATA spare parts
284599504311	TREE CLIP SIDE TRIM TOP¿ G004	TATA spare parts
284599504311AQ	LINEN-TREE CLIP SIDE TRIM TOP G004 BS6	TATA spare parts
284599504312	TREE CLIP SIDE TRIM BOTTOM	TATA spare parts
284599504313	TREE CLIP SIDE TRIM TOP	TATA spare parts
284599504314	TREE CLIP SIDE TRIM BOTTOM	TATA spare parts
284599504314C7	GRANIT_BLACK-TREE CLIP SIDE TRIM BOTTOM	TATA spare parts
284599504315	TREE CLIP HEADLINER MTG	TATA spare parts
284599504316	TREE CLIP HEADLINER MTG	TATA spare parts
284599504318	TREE CLIP MNTG HID	TATA spare parts
2845H9W0239001	DEAD REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
284600990101	KIT FULLY BUILD COWL LPT 3118 STLM BS4	TATA spare parts
284600990102	KIT FULLY BUILD COWL LPT 3118 BS3	TATA spare parts
284600990103	KIT-FULLY BUILD COWL LPT3118 BLW/AC BS4	TATA spare parts
284600990104	KIT FULLY BUILD SLTCAB LPT 3118 BS4 NA	TATA spare parts
284600990105	ASSY. CABIN KIT LPT3118 SLP TCAB BLW BS4	TATA spare parts
284600990106	KIT FULLY BUILD SLTCAB LPT 3118 BS3 NA	TATA spare parts

284600990107	KIT FULLY BUILD COWL LPT 3518 BS4 BLW	TATA spare parts
284624200103	ASSY. BRACKET-LH (ENGINE MTG. REAR)	TATA spare parts
284624200104	ASSY. BRACKET-RH (ENGINE MTG. REAR)	TATA spare parts
284624200109	ASSY.BRACKET-LH(ENGINE MTG.REAR 10MM)	TATA spare parts
284624200110	ASSY.BRACKET-RH(ENGINE MTG.REAR 10MM)	TATA spare parts
284624200111	ENGINE MOUNTING LH (REAR BOTTOM)	TATA spare parts
284624200112	ENGINE MOUNTING RH (REAR BOTTOM)	TATA spare parts
284624200113	ASSYBKT-LH (ENG MTG REAR FOR STR FRM)	TATA spare parts
284624200114	ASSYBKT-RH (ENG MTG REAR FOR STR FRM)	TATA spare parts
284624200119	BRACKET ASSY CHASSIS LH	TATA spare parts
284624200120	BRACKET ASSY CHASSIS RH	TATA spare parts
284624203701	ENGINE MTG ARM	TATA spare parts
284624203702	ENGINE MTG ARM BS6	TATA spare parts
284624203703	BRACKET ENGINE MTG BOTTOM REAR-RH	TATA spare parts
284624203704	BRACKET ENGINE MTG BOTTOM REAR-LH	TATA spare parts
284624203707	BRACKET ENGINE MTG BOTTOM REAR-RH	TATA spare parts
284624203708	BRACKET ENGINE MTG BOTTOM REAR-LH	TATA spare parts
284624203709	ENGINE MTG ARM	TATA spare parts
284626800102	ASSY. G.S. LEVER W/SEL & SHIFTER BS2/3/4	TATA spare parts
284626800105	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
284629100103	ASSY. CONTROLS COMPLETE.	TATA spare parts
284629100108	ASSY. INTERMEDIATE PIPE	TATA spare parts
284629100109	ASSY FORK WITH ROD (MASTER CYL)	TATA spare parts
284629100110	ASSY CONNECTING LINE (HYD CLUTCH 10 O.D)	TATA spare parts
284629100111	ASSY.PIPE 6 O.D (CB TO CMC)	TATA spare parts
284629100114	ASSY.HYD.PIPE(M/CYL.TO INTERMEDIATE JOIN	TATA spare parts
284629100116	PIPE ASSY (INTERMEDIATE HYD PIPE)	TATA spare parts
284629300101	BUNDY TUBE ASSY LONG MEMBER	TATA spare parts
284629300102	BUNDY TUBE ASSY LONG MEMBER	TATA spare parts
284629300103	BUNDY TUBE ASSY-LONG MEMBER BS6	TATA spare parts
284629508201	BRACKET ON LM	TATA spare parts
284629508202	T-BRACKET ON GB	TATA spare parts
284630108201	BRACKET ACCELERATOR PEDAL MTG	TATA spare parts
284631000101	ASSY. FRAME COMPLETE	TATA spare parts
284631000102	ASSY.FRAME COMPLETE(COWL)	TATA spare parts
284631000105	ASSY. FRAME COMPLETE	TATA spare parts
284631000106	ASSY.FRAME FOR LPT3118 TC CAB 56WB	TATA spare parts
284631000107	ASSY. FRAME COMPLETE	TATA spare parts
284631000108	ASSY.FRAME COMPLETE.(3118 TC BSIII 56 WB	TATA spare parts
284631000109	ASSY. FRAME LPT 3118 BS3	TATA spare parts
284631000110	ASSY.FRAME COMPLETE 3118 TC BSIII 52 WB	TATA spare parts
284631000118	ASSY. FRAME WITH FITMENT BS3/4	TATA spare parts
28463100011804	ASSY FRAME LPT3118(FAB 4 HOLE BRKT)BS3/4	TATA spare parts
28463100011806	ASSY FRAME (CAST TYPE 6 HOLE BRKT)	TATA spare parts
284631000120	ASSY. FRAME WITH FITMENT BS3	TATA spare parts
284631000122	ASSY. FRAME COMPLETE 62WB	TATA spare parts
284631000123	ASSY. FRAME WITH FITMENT BS3	TATA spare parts

284631000130	FRAME ASSY WITH FITMENT	TATA spare parts
284631000135	ASSY FRAME COMPLETE	TATA spare parts
284631000136	FRAME ASSY COMPLETE ST. LM	TATA spare parts
284631000169	FRAME ASSY WITH FITMENT	TATA spare parts
284631000171	FRAME ASSY WITH FITMENT	TATA spare parts
284631000172	FRAME ASSY	TATA spare parts
284631000173	ASSY. FRAME WITH FITMENT BS3/4	TATA spare parts
284631000174	FRAME ASSY	TATA spare parts
284631000175	ASSY. FRAME WITH FITMENTS LPT 3518? BS4	TATA spare parts
284631000176	ASSY. FRAME WITH FITMENT LPT 3518 BS4	TATA spare parts
284631000178	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
284631000180	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
284631000182	FRAME ASSY	TATA spare parts
284631000183	ASSY. FRAME WITH FITMENT BS4	TATA spare parts
284631000184	FRAME ASSY WITH FITMENT	TATA spare parts
284631000185	FRAME ASSY WITH FITMENT	TATA spare parts
284631000187	ASSY. FRAME WITH FITMENTS LPT 3518 BS4	TATA spare parts
284631000188	ASSY. FRAME WITH FITMENT BS4	TATA spare parts
284631000190	FRAME ASSY WITH FITMENT	TATA spare parts
284631000196	FRAME ASSY	TATA spare parts
284631000197	FRAME ASSY WITH FITMENT	TATA spare parts
284631000202	FRAME ASSY WITH FITMENT	TATA spare parts
284631000208	FRAME ASSY WITH FITMENT	TATA spare parts
284631010101	FRAME ASSY WITH FITMENT	TATA spare parts
284631010112	FRAME ASSY WITH FITMENT	TATA spare parts
284631100110	ASSLY.RETRO KIT FOR LPT 3118	TATA spare parts
284631107109	REINFORCEMENT -LM-RH	TATA spare parts
284631107110	REINFORCEMENT LM -LH	TATA spare parts
284631107111	REINFORCEMENT-RH (LONG MEMBER)	TATA spare parts
284631107112	REINFORCEMENT-LH (LONG MEMBER)	TATA spare parts
284631107188	REINFORCEMENT LONG MEMBER RH	TATA spare parts
284631107189	REINFORCEMENT LONG MEMBER LH	TATA spare parts
284631107192	REINFORCEMENT RH	TATA spare parts
284631107193	REINFORCEMENT LH	TATA spare parts
284631107196	REINFORCEMENT RH	TATA spare parts
284631107197	REINFORCEMENT LH	TATA spare parts
284631117123	REINFORCEMENT LONG MEMBER RH	TATA spare parts
284631117124	REINFORCEMENT LONG MEMBER LH	TATA spare parts
284631117134	REINFORCEMENT RH	TATA spare parts
284631117135	REINFORCEMENT LH	TATA spare parts
284631117155	REINFROCEMENT RH	TATA spare parts
284631117156	REINFROCEMENT LH	TATA spare parts
284631117159	REINFORCEMENT CROSS MEMBER	TATA spare parts
284631200104	ASSY. BRACKET-LH (AUX. WATER TANK MTG.)	TATA spare parts
284631200105	ASSY. BRACKET-RH (AUX. WATER TANK MTG.)	TATA spare parts
284631200107	ASSY ENGINE CROSS MEMBER (REAR)	TATA spare parts
284631200108	ASSY SPACER PLATE (ENGINE C/M REAR)	TATA spare parts

284631200109	ASSY ENGINE CROSS MEMBER FRONT	TATA spare parts
284631200112	ASSY GUSSET-LH	TATA spare parts
284631200113	ASSY GUSSET-RH	TATA spare parts
284631200114	ASSEMBLY RADIATOR MTG-RH	TATA spare parts
284631200115	ASSEMBLY RADIATOR MTG-LH	TATA spare parts
284631200123	CROSS MEMBER ASSY ENGINE MTG REAR	TATA spare parts
284631200125	ASSMLY.4 TH CROSS MEMBER	TATA spare parts
28463120012561	ASSMLY.4 TH CROSS MEMBER_UNASSEMBLED	TATA spare parts
284631200127	ASSY 6TH CROSS MEMBER & BOTTOM SUPPORT	TATA spare parts
284631200128	ASSY. RADIATOR MOUNTING BRACKET-RH	TATA spare parts
284631200129	ASSY. RADIATOR MOUNTING BRACKET-LH	TATA spare parts
284631200130	SUPPORT ASSY RH	TATA spare parts
284631200131	SUPPORT ASSY LH	TATA spare parts
284631200133	ASSY. CROSS MEMBER (REAR)	TATA spare parts
284631200147	CROSS MEMBER ASSY WITH GUSSET BS6	TATA spare parts
284631200152	CROSS MEMBER ASSY WITH SUPPORT ENG MTG	TATA spare parts
284631200153	CROSS MEMBER ASSY	TATA spare parts
28463120015335	CM ASSY LIFT AXLE- REAR_UNPAINTED	TATA spare parts
284631207101	REINFORCEMENT(LIFT AXLE CM)	TATA spare parts
284631207104	REINFORCEMENT-RH (SHOCK ABS.FRONT)	TATA spare parts
284631207105	REINFORCEMENT-LH (SHOCK ABS. FRONT)	TATA spare parts
284631300101	SUPPORT ASSY LH (BUMP STOPPER)	TATA spare parts
284631300102	SUPPORT ASSY RH (BUMP STOPPER)	TATA spare parts
284631307104	REINFORCEMENT TOP(RH)	TATA spare parts
284631307105	TOP REINFORCEMENT (LH)	TATA spare parts
284631307106	REINFORCEMENT- RH(SPRNG HNGR)	TATA spare parts
284631307107	REINFORCEMENT-LH(SPRNG HNGR)	TATA spare parts
284631307108	BOTTOM REINFORCEMENT	TATA spare parts
284631307118	GUSSET BOTTOM SUPPORT(4 TH CROSS MEMBER	TATA spare parts
284631307122	REINFORCEMENT BUMPER CROSS MEMBER LH	TATA spare parts
284631307123	REINFORCEMENT BUMPER CROSS MEMBER RH	TATA spare parts
284631307141	GUSSET TOP-RH (BUMPER CROSS MEMBER)	TATA spare parts
284631307142	GUSSET TOP-LH (BUMPER CROSS MEMBER)	TATA spare parts
284631307153	GUSSET CROSS MEMBER BOTTOM-RH	TATA spare parts
284631307154	GUSSET CROSS MEMBER BOTTOM-LH	TATA spare parts
284631307155	GUSSET LIFT AXLE SUPPORT TOP-RH	TATA spare parts
284631307156	GUSSET LIFT AXLE SUPPORT TOP-LH	TATA spare parts
284631307165	GUSSET CROSS MEMBER MTG TOP-RH	TATA spare parts
284631307166	GUSSET CROSS MEMBER MTG TOP-LH	TATA spare parts
284631307167	GUSSET CROSS MEMBER BOTTOM-RH	TATA spare parts
284631307168	GUSSET CROSS MEMBER BOTTOM-LH	TATA spare parts
284631700105	ASSY BRACKET-LH	TATA spare parts
284631700106	ASSY BRACKET-RH	TATA spare parts
284631700107	ASSY MAIN BRACKET-LH	TATA spare parts
284631700108	ASSY MAIN BARCKET-RH	TATA spare parts
284631700109	ASSY SUPPORT BKT	TATA spare parts
284631700110	ASSY SIDE PLATE-LH	TATA spare parts

284631700111	SIDE BRACKET-RH	TATA spare parts
284631700113	ASSY RUPD LPT 3118-ICR	TATA spare parts
284631700114	ASSY.FUPD BRACKET-RH	TATA spare parts
284631700115	ASSY.FUPD BRACKET-LH	TATA spare parts
284631700117	ASSY. FUPD SIDE SUPPORT-RH	TATA spare parts
284631700118	ASSY. FUPD SIDE SUPPORT-LH	TATA spare parts
284631700125	BRACKET ASSY RADIATOR MTG LH	TATA spare parts
284631700126	BRACKET ASSY RADIATOR MTG RH	TATA spare parts
284631707128	SIDE PLATE	TATA spare parts
284631707139	SPACER PLATE (ICR RUPD)	TATA spare parts
284632100104	ASSY.FRONT SPRING PARABOLIC	TATA spare parts
284632100115	ASSY PARABOLIC SPRING	TATA spare parts
284632100120	ASSY SPACER BLOCK & SPIGOT	TATA spare parts
284632100125	ASSY AXLE BUMP STOPPER	TATA spare parts
284632100127	ASSY AXLE STOPPER MTG BKT FWD-ON CHASSIS	TATA spare parts
284632100136	FRONT SPRING ASSY LPT 2518	TATA spare parts
284632103202	CENTER BOLT	TATA spare parts
284632103209	CENTERBOLT LEAFSPRINGCENTREBOLT BS6	TATA spare parts
284632103210	HEX BOLT BS6	TATA spare parts
284632103301	BRACKET SPRING HANGER BS6	TATA spare parts
284632103702	SPACER FRONT SUSPENSION	TATA spare parts
284632104201	SPRING CLIP	TATA spare parts
284632104204	SPRING CLIP BS6	TATA spare parts
284632104205	SPRING CLIP	TATA spare parts
284632104207	U-BOLT BS6	TATA spare parts
284632107101	SPACER BLOCK	TATA spare parts
284632107102	CASTER PLATE	TATA spare parts
284632107108	SPACER	TATA spare parts
284632107121	CASTER PLATE BS6	TATA spare parts
284632108602	SPACER BS6	TATA spare parts
284632108604	SPACER TUBE	TATA spare parts
284632204202	U CLAMP	TATA spare parts
284632204203	U CLAMP	TATA spare parts
284632300101	ASSY. BRACKET (FRT.SHOCK ABSORBER UPPER)	TATA spare parts
284632300104	ASSY. BRACKET-RH (FRONT SHOCK ABSORBER)	TATA spare parts
284632300105	ASSY. BRACKET-LH (FRONT SHOCK ABSORBER)	TATA spare parts
284632300106	ASSY. BRACKET (FRONT SHOCK ABSORBER UPPE	TATA spare parts
284632300107	ASSY BRACKET (FRONT S/A UPPER)	TATA spare parts
284632400177	BUSH ASSY FULCRUM BS6	TATA spare parts
284632400180	LEAF SPRING ASSY REAR BS6	TATA spare parts
284632400182	LEAF SPRING ASSY BS6	TATA spare parts
284632400187	TORQUE ROD ASSY BS6	TATA spare parts
284632400188	TORQUE ROD ASSY BS6	TATA spare parts
284632403715	BRACKET REAR SPRING HANGER FRONT BS6	TATA spare parts
284632403719	WEAR PAD BS6	TATA spare parts
284632403721	WEAR PAD BS6	TATA spare parts
284632403722	BRACKET REAR SPRING MTG REAR BS6	TATA spare parts

284632403729	BRACKET SPRING HANGER REAR-MIDDLE BS6	TATA spare parts
284632404201	SPRING CLIP BS6	TATA spare parts
284632404203	SPRING CLIP TABLE DRAWING BS6	TATA spare parts
284632407113	CASTER PLATE REAR SPRING BS6	TATA spare parts
284632407114	SPACER BS6	TATA spare parts
284632407141	C-BRACKET BS6	TATA spare parts
284632407142	C-BRACKET BS6	TATA spare parts
284632407143	1ST LEAF BS6	TATA spare parts
284632407144	2ND LEAF BS6	TATA spare parts
284632407145	3RD LEAF BS6	TATA spare parts
284632407146	4TH LEAF BS6	TATA spare parts
284632407147	5TH LEAF BS6	TATA spare parts
284632407148	6TH LEAF BS6	TATA spare parts
284632407150	7TH LEAF BS6	TATA spare parts
284632407151	8TH LEAF BS6	TATA spare parts
284632407152	9TH LEAF BS6	TATA spare parts
284632407153	10TH LEAF BS6	TATA spare parts
284632407154	11TH LEAF BS6	TATA spare parts
284632407157	1ST LEAF BS6	TATA spare parts
284632407158	2ND LEAF BS6	TATA spare parts
284632407159	3RD LEAF BS6	TATA spare parts
284632407160	4TH LEAF BS6	TATA spare parts
284632407161	5TH LEAF BS6	TATA spare parts
284632407162	6TH LEAF BS6	TATA spare parts
284632407163	7TH LEAF BS6	TATA spare parts
284632407164	8TH LEAF BS6	TATA spare parts
284632407165	9TH LEAF BS6	TATA spare parts
284632407166	10TH LEAF BS6	TATA spare parts
284632407172	SLEEVE REAR BRACKET BOLT SLEEVE BS6	TATA spare parts
284632408605	SPACER BS6	TATA spare parts
284632700107	MACHINED BEAM ASSY	TATA spare parts
284632700108	MACHINED BEAM ASSY	TATA spare parts
284632700110	SADDLE ASSY	TATA spare parts
284632703303	SIDE RAIL	TATA spare parts
284632703304	SIDE RAIL	TATA spare parts
284632703306	AXLE SEAT LH	TATA spare parts
284632703309	AXLE SEAT RH	TATA spare parts
284632706002	ACTUATION ARM	TATA spare parts
284632706003	ACTUATION ARM	TATA spare parts
284632707102	UPPER AIR SPRING PLATE	TATA spare parts
284632707103	UPPER AIR SPRING PLATE	TATA spare parts
284632707122	RETAINING PLATE	TATA spare parts
284632708601	SPACER	TATA spare parts
284633000101	ASSY FRONT AXLE COMPLETE WITH BRAKES	TATA spare parts
284633000102	ASSY FRONT AXLE COMP WITH BRAKES	TATA spare parts
284633000105	ASSY. FRONT PUSHER/LIFT AXLE COMPLETE WI	TATA spare parts
284633000106	FRONT AXLE COMPLETE WITH BRAKES	TATA spare parts



284633000108	ASSY. FRONT AXLE COMPLETE WITH BRAKES	TATA spare parts
284633000109	FRONT AXLE LPT2518/3118-62WB840CD/NON ABS	TATA spare parts
284633000116	ASSY. FRONT AXLE COMPLETE WITH BRAKES	TATA spare parts
284633000117	ASSY FRT AXLE WITH BRAKES(6.5T FAB)	TATA spare parts
284633000118	LIFT AXLE ASSY WITH BRAKE	TATA spare parts
284633000128	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
284633000131	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
284633000132	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
284633000133	FRONT AXLE ASSY WITH BRAKE;ABS	TATA spare parts
284633000135	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
284633105101	LIFT AXLE BEAM NORMAL BS2/3/4	TATA spare parts
284633105103	ASSY. FRONT AXLE BEAM BS4	TATA spare parts
284633105104	FRONT AXLE BEAM 6.5T P-II	TATA spare parts
284633105105	FRONT AXLE BEAM 6.5T P-II BS3/4	TATA spare parts
284633109901	STICKER TRUCK HUB UNIT BS6	TATA spare parts
284633200108	STUB AXLE ASSY	TATA spare parts
284633200116	STUB AXLE ASSY LH 6.5T PII	TATA spare parts
284633200117	STUB AXLE ASSY RH 6.5T PII	TATA spare parts
284633200118	STUB AXLE ENDCAP ASSEMBLY	TATA spare parts
284633200124	ASSY. STUB AXLE RH ABS BS3/4	TATA spare parts
284633200125	ASSY. STUB AXLE LH ABS BS3/4	TATA spare parts
284633200126	STUB AXLE ASSY ABS RH	TATA spare parts
284633200128	STUB AXLE ASSY ABS LH	TATA spare parts
284633200132	STUB AXLE ASSY ABS RH BS6	TATA spare parts
284633200133	STUB AXLE ASSY ABS LH BS6	TATA spare parts
284633200134	STUB AXLE ASSY BS6	TATA spare parts
284633200135	STUB AXLE ASSY BS6	TATA spare parts
284633203101	TAPER ROLLER THRU BRG. NORMAL BS1/2/3/4	TATA spare parts
284633205108	STUB AXLE NON ABS-LH	TATA spare parts
284633205109	STUB AXLE NON ABS-RH	TATA spare parts
284633205113	STUB AXLE ABS RH BS6	TATA spare parts
284633205114	STUB AXLE ABS LH BS6	TATA spare parts
284633205122	STUB AXLE ABS RH BS6	TATA spare parts
284633205123	STUB AXLE ABS LH BS6	TATA spare parts
284633205124	STUB AXLE RH BS6	TATA spare parts
284633205125	STUB AXLE LH BS6	TATA spare parts
284633206701	KING PIN 6.5T PII BS3/4	TATA spare parts
284633206702	COTTER PIN 6.5T PII	TATA spare parts
284633207101	STUB AXLE END CAP 6.5T PII	TATA spare parts
284633209201	THRUST WASHER STUBAXLE T=3.5	TATA spare parts
284633209202	THRUST WASHER STUBAXLE T=3.2	TATA spare parts
284633209203	THRUST WASHER STUB AXLE T=3.3	TATA spare parts
284633209204	THRUST WASHER STUB AXLE T=3.4	TATA spare parts
284633209205	THRUST WASHER STUBAXLE T=3.6	TATA spare parts
284633209206	THRUST WASHER STUBAXLE T=3.7	TATA spare parts
284633209207	THRUST WASHER STUBAXLE T=3.8	TATA spare parts
284633209208	THRUST WASHER STUBAXLE T=3.9	TATA spare parts

284633209209	THRUST WASHER STUB AXLE BS6	TATA spare parts
284633209210	THRUST WASHER STUB AXLE BS6	TATA spare parts
284633209211	THRUST WASHER STUB AXLE BS6	TATA spare parts
284633209212	THRUST WASHER STUB AXLE BS6	TATA spare parts
284633209213	THRUST WASHER STUB AXLE BS6	TATA spare parts
284633209214	THRUST WASHER STUB AXLE BS6	TATA spare parts
284633209215	THRUST WASHER STUB AXLE BS6	TATA spare parts
284633209216	THRUST WASHER STUB AXLE BS6	TATA spare parts
284633400101	FRONT HUB ASSY	TATA spare parts
284633400105	HUB ASSY FRONT ABS 6.5T PII BS3/4/6	TATA spare parts
284633400106	FRONT HUB ASSY WITH POLE WHEEL BS6	TATA spare parts
284633403101	TAPER ROLLER BRG INNER 6.5T PII BS3/4	TATA spare parts
284633403102	TAPER ROLLER BEARING 6.5T P2 BS3/4/6	TATA spare parts
284633403105	TAPER ROLLER BEARING	TATA spare parts
284633403106	TAPER ROLLER BEARING	TATA spare parts
284633403107	TAPER ROLLER BEARING BS6	TATA spare parts
284633403108	TAPER ROLLER BEARING BS6	TATA spare parts
284633403701	FRONT HUB COVERç 6.5T P-II	TATA spare parts
284633405501	FRONT HUB BS6	TATA spare parts
284633405502	WHEEL HUB NON ABS	TATA spare parts
284633405503	FRONT HUBçBS6	TATA spare parts
284633405504	HUB FRONT AXLE-ABS 6.5T P-II	TATA spare parts
284633405505	FRONT HUB ABS BS6	TATA spare parts
284633405506	FRONT HUB ABS BS6	TATA spare parts
284633406501	BEARING NUT FRONT HUB 6.5T P-II	TATA spare parts
284633407801	HUB SEAL 6.5T PII BS3/4	TATA spare parts
284633407801DF	HUB SEAL - 6.5T P2 AXLE	TATA spare parts
284633408301	SHIM 1MM LOCK BOLT	TATA spare parts
284633408302	SHIM FRONT HUB	TATA spare parts
284633408303	SHIM FRONT HUB	TATA spare parts
284633408304	SHIM FRONT HUB	TATA spare parts
284633408305	SHIM FRONT HUB	TATA spare parts
284633408306	SHIM FRONT HUB	TATA spare parts
284633408307	SHIM FRONT HUB	TATA spare parts
284633408308	SHIM FRONT HUB	TATA spare parts
284633408309	SHIM FRONT HUB	TATA spare parts
284633408310	SHIM FRONT HUB 1.35 THK	TATA spare parts
284633408311	SHIM FRONT HUB 1.40 THK	TATA spare parts
284633408312	SHIM FRONT HUB 1.45 THK	TATA spare parts
284633408313	SHIM FRONT HUB 1.55 THK	TATA spare parts
284633408314	SHIM FRONT HUB 1.60 THK	TATA spare parts
284633408315	SHIM FRONT HUB 1.65 THK	TATA spare parts
284633408316	SHIM FRONT HUB 0.85 THK	TATA spare parts
284633408317	SHIM FRONT HUB 0.90 THK	TATA spare parts
284633408318	SHIM FRONT HUB 0.95 THK	TATA spare parts
284633408601	SPACER TUBE FRONT HUB 6.5T P-II	TATA spare parts
284633409201	LOCK WASHER BEARING HUB. 6.5T P-II	TATA spare parts

284633409202	HUB CAP GASKET	TATA spare parts
284633800102	TIE ROD ASSEMBLY	TATA spare parts
284633800111	ASSY TIE ROD-LIFT AXLE	TATA spare parts
284633800112	ASSY. TIE ROD-FRONT AXLE BS1/2/3/4	TATA spare parts
284633800113	ASSY. TIE ROD-FRONT AXLE BS1/2/3/4	TATA spare parts
284633800114	ASSY TIE ROD-LIFT AXLE	TATA spare parts
284633800128	TIE ROD ASSY	TATA spare parts
284633800129	ASSY. BALL JOINT RH BS1/2/3/4	TATA spare parts
284633800130	ASSY. BALL JOINT LH	TATA spare parts
284633800131	ASSY. TIE ROD BS3/4	TATA spare parts
284633800132	TIE ROD ASSY	TATA spare parts
284633800133	TIE ROD ASSY	TATA spare parts
284633800134	TIE ROD END ASSY. L.H.	TATA spare parts
284633800135	TIE ROD END ASSY. R.H.	TATA spare parts
284633800136	REPAIR KIT	TATA spare parts
284633800137	TIE ROD END ASSY. L.H.	TATA spare parts
284633800138	TIE ROD END ASSY. R.H.	TATA spare parts
284633800140	TIE ROD ASSY	TATA spare parts
284633800141	TIE ROD ASSLY(RANE MADRAS)	TATA spare parts
284633800142	TIE ROD ASSY	TATA spare parts
284633800143	BALL JOINT ASSY RH	TATA spare parts
284633800144	BALL JOINT ASSY LH	TATA spare parts
284633800145	TIE ROD ASSY	TATA spare parts
284633801602	ASSY. TIE ROD BS3/4	TATA spare parts
284633805101	STEERING ARM RH BS2/3/4	TATA spare parts
284633805102	STEERING ARM LH BS2/3/4	TATA spare parts
284633805103	ARM TIE ROD LH	TATA spare parts
284633805104	ARM TIE ROD RH	TATA spare parts
284633805127	TIE ROD ARM RH	TATA spare parts
284633805128	TIE ROD ARM LH	TATA spare parts
284633805130	STEERING ARM	TATA spare parts
284633805131	TIE ROD ARM RH 6.5T P-II	TATA spare parts
284633805132	TIE ROD ARM LH 6.5T PII	TATA spare parts
284633805133	STEERING ARM 6.5T PII	TATA spare parts
284633805134	STEERING ARM	TATA spare parts
284633805135	STEERING ARM	TATA spare parts
284633805136	STEERING ARM	TATA spare parts
284633805137	STEERING ARM	TATA spare parts
284633900105	KIT FOR LIFT AXLE PIPING	TATA spare parts
284633900106	KIT FOR LIFT AXLE	TATA spare parts
284633900108	ASSY BRAKE CHAMBER WITH VOSS CONNECTOR	TATA spare parts
284633900109	ASSY SOLENOID VALVE WITH VOSS CONNECTORS	TATA spare parts
284633900110	ASSY LOAD SENSING VALVE WITH VOSS CONN	TATA spare parts
284633900111	ASSY LIFT AXLE CONT VALVE WITH VOSS	TATA spare parts
284633900112	ASSY PRESSURE SWITCH WITH VOSS	TATA spare parts
284633900113	ASSY PRESSURE REGULATOR WITH VOSS	TATA spare parts
284633900114	VOSS CONNECTOR M16X1.5	TATA spare parts

284633900115	ASSY. LINK	TATA spare parts
284633900116	ASSY. BRACKET(ON DRIVE AXLE)	TATA spare parts
284633900117	VOSS CONNECTOR M22.5X1.5	TATA spare parts
284633900118	VOSS CONNECTOR M12X1.5	TATA spare parts
284633900119	KIT FOR VOSS CONNECTOR	TATA spare parts
284633900120	ASY FWD REV LOCK VALVE WITH CONNECTOR	TATA spare parts
284633900121	ASSY LOCK BOLT	TATA spare parts
284633900124	KIT LIFT AXLE PIPES AND CONNECTORS	TATA spare parts
284633900128	PRESSURE CONTROL BOX	TATA spare parts
284633900135	HANGER WELDED ASSY LH	TATA spare parts
284633900136	HANGER WELDED ASSY RH	TATA spare parts
284633900137	Z SECTION WELDED ASSY	TATA spare parts
284633900138	SADDLE ASSEMBLY	TATA spare parts
284633900139	ACTUATOR ARM ASSEMBLY LH	TATA spare parts
284633900140	ACTUATOR ARM ASSEMBLY RH	TATA spare parts
284633900141	MACHINED BEAM ASSEMBLY LH	TATA spare parts
284633900142	MACHINED BEAM ASSEMBLY RH	TATA spare parts
284633900143	AXLE SEAT LH	TATA spare parts
284633900144	AXLE SEAT RH	TATA spare parts
284633900145	UPPER AIRSPRING PLATE LH	TATA spare parts
284633900146	UPPER AIRSPRING PLATE RH	TATA spare parts
284633900147	SADDLE WELDMENT RH	TATA spare parts
284633900148	SADDLE WELDMENT LH	TATA spare parts
284633900149	BRACE WELDED ASSY	TATA spare parts
284633900150	BUSH ASSY SINGLE FOR BEAMS	TATA spare parts
284633900151	MAIN PIVOT BUSH	TATA spare parts
284633900152	ASSY. BRACKET-RH FOR LSV MTG. (LS-3000)	TATA spare parts
284633900153	ASSY. BRACKET-LH FOR LSV MTG.(LS-3000)	TATA spare parts
284633900154	KIT LIFT AXLE PIPES AND CONNECTORS	TATA spare parts
284633900158	ASSY PIPES AND CONN FOR LIFT AXLE (PTO)	TATA spare parts
284633900162	ASSY. BRACKET FOR PROTECTOR SHEET MTG.	TATA spare parts
284633900190	ASSY. CROSS MEMBER (C-TYPE)	TATA spare parts
284633900200	ASSY LIFT AXLE CONT VALVE-VOSS	TATA spare parts
284633900201	ASSY. LIFT AXLE CNTRL VALVE G-II BS2/3/4	TATA spare parts
284633900205	ASSY. LIFT AXLE PIPE & CLAMPS	TATA spare parts
284633900209	ASSY. LIFT AXLE PIPE & CLAMPS (56WB)	TATA spare parts
284633900211	KIT FOR LIFT AXLE (PARALIFT)	TATA spare parts
284633900214	SIDE RAIL-RH	TATA spare parts
284633900215	SIDE RAIL LH	TATA spare parts
284633900216	ASSY Z SECTION	TATA spare parts
284633900217	ASSY BUSHED SADDLE	TATA spare parts
284633900219	PLATE SPACER ASSEMBLY	TATA spare parts
284633900221	KIT FOR LIFT AXLE	TATA spare parts
284633900223	SIDE RAIL-LH	TATA spare parts
284633900224	SIDE RAIL-RH	TATA spare parts
284633900225	Z SECTION	TATA spare parts
284633900226	ASSY AXLE SEAT-LH	TATA spare parts

284633900227	ASSY AXLE SEAT-RH	TATA spare parts
284633900230	ASSY MACHINED BEAM LH	TATA spare parts
284633900231	ASSY MACHINED BEAM RH	TATA spare parts
284633900232	ASSY. EMERGENCY LIFT AXLE SWITCH MTG. BO	TATA spare parts
284633900240	LIFT AXLE RETRO KIT	TATA spare parts
284633900244	LOAD SENSING VALVE	TATA spare parts
284633900245	ASSEMBLY BRACKET LSV	TATA spare parts
284633900247	LOAD SENSING VALVE-(WITH P CLAMP)	TATA spare parts
284633900248	SPARE KIT FOR LSV-KB(WITH P CLAMP)-MAJOR	TATA spare parts
284633900249	SPARE KIT FOR LSV-KB(WITH P CLAMP)MINIOR	TATA spare parts
284633900258	ASSY. ADAPTER (M12X1.5+NG8+THRUST WASHER)	TATA spare parts
284633900260	ASSY. QUICK RELEASE VALVE WITH BRACKET	TATA spare parts
284633900261	KIT ASSY NYLON PIPE LACV GEN-II (56WB)	TATA spare parts
284633900263	PIPING & CLAMP ASSY LIFT AXLE (52 WB)	TATA spare parts
284633900264	LIFT AXLE CONTROL VALVE BS2/3/4	TATA spare parts
284633900265	LOAD DETECTION VALVE	TATA spare parts
284633900266	ASSY. ADAPTER (M12X1.5+NG12+THRUST WASHER)	TATA spare parts
284633900268	ASSY. LIFT AXLE PIPINGS AND CLAMPS	TATA spare parts
284633900269	KIT ASSY. NYLON PIPES	TATA spare parts
284633900271	HENDRICKSON KIT FOR LIFT AXLE (PHASE-I)	TATA spare parts
284633900274	AIR SPRING MOUNT LH FINISHED	TATA spare parts
284633900275	AIR SPRING MOUNT RH FINISHED	TATA spare parts
284633900277	HANGER LH	TATA spare parts
284633900278	HANGER RH	TATA spare parts
284633900280	U SECTION	TATA spare parts
284633900281	BEAM ASSEMBLY LH	TATA spare parts
284633900282	BEAM ASSEMBLY RH	TATA spare parts
284633900283	AXLE SEAT LH FINISHED	TATA spare parts
284633900284	AXLE SEAT RH FINISHED	TATA spare parts
284633900289	ASSLY PULL ROD	TATA spare parts
284633900291	AIR SPRING MTG ASSY-RH	TATA spare parts
284633900292	AXLE SEAT RH	TATA spare parts
284633900293	BEAM ASSY LH	TATA spare parts
284633900294	BEAM ASSY RH	TATA spare parts
284633900295	AIR SPRING MTG ASSY-LH	TATA spare parts
284633900297	EXTERNAL BUMP STOP ASSY. LH	TATA spare parts
284633900298	EXTERNAL BUMP STOP ASSY. RH	TATA spare parts
284633900332	SOLENOID VALVE 3X2 NO TYPE(24V)	TATA spare parts
284633900339	AXLE SEAT LH	TATA spare parts
284633900360	NYLON PIPE ASSY LDV TO LACV	TATA spare parts
284633900362	NYLON PIPE ASSY PLV TO LSV	TATA spare parts
284633900369	NYLON PIPE ASSY LSV TO LACV	TATA spare parts
284633900377	NYLON PIPE ASSY LACV TO QRV	TATA spare parts
284633900379	NYLON PIPE ASSY QRV TO MAIN BELLOW LH	TATA spare parts
284633900380	NYLON PIPE ASSY QRV TO MAIN BELLOW RH	TATA spare parts
284633900384	NYLON PIPE ASSY LACV TO QRV BS6	TATA spare parts
284633900385	NYLON PIPE ASSY QRV TO MAIN BELLOW LH	TATA spare parts

284633900386	NYLON PIPE ASSY QRV TO MAIN BELLOW RH	TATA spare parts
284633903202	LOCK BOLT (LIFT AXLE)	TATA spare parts
284633903204	SLEEVE FOR LOCK BOLT	TATA spare parts
284633903205	SEALING PLUG FOR LOCK BOLT	TATA spare parts
284633903206	HEX.SOCKET HEAD CAP SCREW M12X1.5X30L	TATA spare parts
284633903207	SLEEVE FOR LOCK BOLT	TATA spare parts
284633903208	SEALING PLUG FOR LOCK BOLT	TATA spare parts
284633903209	HEX.SOCKET HEAD CAP SCREW M12X1.5X25L	TATA spare parts
284633903302	CROSS MEMBER CHANNEL	TATA spare parts
284633903303	END CAP LH TOP	TATA spare parts
284633903304	END CAP RH TOP	TATA spare parts
284633903305	LOWER END CAP LH	TATA spare parts
284633903306	LOWER END CAP RH	TATA spare parts
284633903307	BKT-LOCKOUT VALVE MTG	TATA spare parts
284633903308	BKT-SOLENOID VALVE MOUNTING	TATA spare parts
284633903309	BRACKET SOLENOID VALVE MTG.	TATA spare parts
284633903310	M16X2-50LG GRD 10.9 FLANGE HD BOLT	TATA spare parts
284633903311	M16X2 AMPT GRD 10 AMPT HEX NUT	TATA spare parts
284633903312	M16 HARDENED PLAIN WASHER	TATA spare parts
284633903313	M24-3.0 230LG GRD 10.9 HEX HD BOLT DIN 9	TATA spare parts
284633903314	M24-3.0 CLASS 10 AMPT HEXNUT DIN 980 F21	TATA spare parts
284633903315	M24 HARDENED PLAIN WASHER DIN 6916 F21	TATA spare parts
284633903316	M24-3.0 190LG GRD 10.9 HEX HD BOLT DIN 9	TATA spare parts
284633903318	M20 HARDENED PLAIN WASHER	TATA spare parts
284633903319	M10-1.5 25LG GRD 10.9 FLANGE HD BOLT	TATA spare parts
284633903321	UPPER DAMPER MOUNT	TATA spare parts
284633903322	STEERING ARM SPACER	TATA spare parts
284633903323	M16X2-60LG GRD 12 HEX HD BOLT	TATA spare parts
284633903324	M20-2.5 75LG GRD 10.9 HEX HD BOLT	TATA spare parts
284633903325	M20-2.5 CLASS 10 AMPT HEXNUT	TATA spare parts
284633903327	M12 HARDENED PLAIN WASHER	TATA spare parts
284633903328	M12-1.75 55LG GRD 10.9 HEX BOLT	TATA spare parts
284633903329	M12-1.75 CLASS 10 AMPT HEX NUT	TATA spare parts
284633903330	M20 LARGE HARDENED PLAIN WASHER	TATA spare parts
284633903331	M20-2.5 150LG GRD 8.8 HEX HD BOLT	TATA spare parts
284633903332	M20-2.5 100LG GRD 8.8 HEX HD BOLT	TATA spare parts
284633903333	M20-1.5 CLASS 10 AMPT NUT	TATA spare parts
284633903335	M18 HARDENED PLAIN WASHER	TATA spare parts
284633903336	M18-2.5 130LG GRD 8.8 HEX HD BOLT	TATA spare parts
284633903337	M18-2.5 CLASS 10 AMPT NUT	TATA spare parts
284633903338	M20X2.5X50 HEX BOLT-10.9	TATA spare parts
284633903350	CROSS MEMBER( LIFT AXLE)	TATA spare parts
284633903351	END CAP-RH	TATA spare parts
284633903352	END CAP-LH	TATA spare parts
284633903354	LOWER END CAP-RH	TATA spare parts
284633903355	LOWER END CAP-LH	TATA spare parts
284633903356	M 12X1.75-FLANGE HEX NUT-10	TATA spare parts

284633903357	M 16X2-AMPT NUT-10	TATA spare parts
284633903358	M 18X2.5-AMPT NUT-10	TATA spare parts
284633903359	M 20X1.5-FLANGE HEX NUT-10	TATA spare parts
284633903360	M 20X2.5-AMPT NUT-10	TATA spare parts
284633903361	M 24X3.0-AMPT NUT-10	TATA spare parts
284633903362	M 10X1.5X25 LG.-FLANGE BOLT -10.9	TATA spare parts
284633903363	M 16X2.0X60 LG.-FLANGE BOLT -10.9	TATA spare parts
284633903364	M 18X2.5X130 LG.-FLANGE BOLT -10.9	TATA spare parts
284633903365	M 20X2.5X75 LG.-FLANGE BOLT -10.9	TATA spare parts
284633903366	M 24X3.0X190 LG -HEX. BOLT -10.9	TATA spare parts
284633903367	M 24X3.0X230 LG -HEX. BOLT -10.9	TATA spare parts
284633903381	M16 X 2 X 50LG GRD. 10.9 FLANGE HD. BOLT	TATA spare parts
284633903409	BUSH OUTER RUBBER	TATA spare parts
284633903411	BUSHING INNER STEEL	TATA spare parts
284633906502	HEX NUT M16X1.5	TATA spare parts
284633906806	M14 EQU L TEE BODY COUPLING	TATA spare parts
284633906807	ELBOW BODY M16XM14	TATA spare parts
284633906808	COUPLING BODY M22XM14	TATA spare parts
284633906902	PIPE DIA.15(FOR LIFT AXLE PIPING)	TATA spare parts
284633906903	PIPE DIA.15(FOR LIFT AXLE PIPING)	TATA spare parts
284633906904	PIPE DIA.15(FOR LIFT AXLE PIPING)	TATA spare parts
284633906905	PIPE DIA.15(FOR LIFT AXLE PIPING)	TATA spare parts
284633906906	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906907	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906908	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906909	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906910	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906911	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906912	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906913	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906914	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906915	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906916	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906917	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906918	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906919	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906920	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906921	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906922	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906923	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906924	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906925	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906926	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906927	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906928	PIPE DIA.8(FOR LIFT AXLE PIPING)	TATA spare parts
284633906929	PIPE DIA.15(FOR LIFT AXLE PIPING)	TATA spare parts
284633906930	ASSY.PIPE DIA.12(FOR LIFT AXLE PIPING)	TATA spare parts

284633907128	P CLAMP	TATA spare parts
284633908207	BRACKET FOR PIANO KEY SWITCH-LIFT AXLE	TATA spare parts
284633908208	PROTECTOR SHEET	TATA spare parts
284633908209	U SECTION	TATA spare parts
284633909001	ASSY. LIFT AXLE CONTROL VALVE	TATA spare parts
284633909201	HARDENED WASHER ACE EV	TATA spare parts
284633909204	WASHER (FOR LSV)	TATA spare parts
284633909909	BRACKET (DUMMY AXLE MTG)	TATA spare parts
284633909910	BRACKET (LSV MTG.)	TATA spare parts
284633909911	TUBE (LSV ARRANGEMENT)	TATA spare parts
284633909917	SPRING	TATA spare parts
284633909918	LINK CONNECTOR(LSV-EQ.LINK)	TATA spare parts
284633909919	PRESSURE REG.MTG.BKT. (FOR PARKER)	TATA spare parts
284633909920	BRACKET (PRESSURE SWITCH MTG.)	TATA spare parts
284633909921	HOLDER (PRESSURE SWITCH MTG.)	TATA spare parts
284633909922	PRESSURE REG. MTG. BKT (FOR KB)	TATA spare parts
284633909923	LINKAGE FOR LSV	TATA spare parts
284633909925	SOLENOID VALVE (FOR CONTROL VALVE)	TATA spare parts
284633909931	WEAR PAD BS2/3/4/6	TATA spare parts
284633909933	WEAR PAD SMALL	TATA spare parts
284633909934	LIFT AIR SPRING (HPN-41CX008C01) BS2/3/4	TATA spare parts
284633909934DF	AIR SPRING LIFT-6T LIFT AXLE-3118/3718	TATA spare parts
284633909935	AIR SPRING MAIN BELLOWS	TATA spare parts
284633909936	SHOCK ABSORBER	TATA spare parts
284633909937	STABILIZER (STEERING DAMPER) BS2/3/4	TATA spare parts
284633909939	SLEEVE INNER	TATA spare parts
284633909943	PRESSURE REG. MTG. BKT	TATA spare parts
284633909972	MAIN AIR SPRING BS2/3/4	TATA spare parts
284633909972DF	AIR SPRING MAIN-6T LIFT AXLE-3118/3718	TATA spare parts
284633910108	ASSY. LINK	TATA spare parts
284633990101	ASSY RETRO KIT FOR LSV	TATA spare parts
284633990110	KIT-THREADED END LH	TATA spare parts
284633990111	KIT-THREADED END RH	TATA spare parts
284633990120	KIT-NYLON PIPE ASSY	TATA spare parts
284633990125	KIT-NYLON PIPE ASSY	TATA spare parts
284633990130	KIT-NYLON PIPE ASSY	TATA spare parts
284633990134	KIT-NYLON PIPE ASSY	TATA spare parts
284633990153	KIT-LIFT AXLE CONTROLS	TATA spare parts
284633995316	SEALING RING	TATA spare parts
284633997801	SEALING RING	TATA spare parts
284633999201	WASHER	TATA spare parts
284633999902	REPAIR KIT	TATA spare parts
284633999903	REPAIR KIT	TATA spare parts
284633999904	REPAIR KIT	TATA spare parts
284633999905	REPAIR KIT	TATA spare parts
284640100122	ASSY. WHEEL RIM BS4	TATA spare parts
284640200133	TYRE ASSY WITH WHEEL RIM	TATA spare parts



284640300101	ASSY. BRACKET(SPARE WHEEL)	TATA spare parts
284640300102	ASSY SPARE WHEEL CARRIER (LPT 3118)	TATA spare parts
284641100101	ASSY.PROPELLER SHAFT FRONT	TATA spare parts
284641100102	ASSY PROPELLER SHAFT FRONT	TATA spare parts
284641100103	CENTRE BEARING ASSY(FRONT)	TATA spare parts
284641100104	CENTRE BEARING ASSY(FRONT)	TATA spare parts
284641100106	ASSY.PROPELLER SHAFT FRONT	TATA spare parts
284641100109	ASSEMBLY PROP. SHAFT GUARD (RETRO KIT)	TATA spare parts
284641100110	ASSY. PROPELLER SHAFT FRONT	TATA spare parts
284641100111	ASSY. CENTER BEARING BS1/3	TATA spare parts
284641100111DF	CENTER BEARING ASSY 1615/2518/3118BS3/4	TATA spare parts
284641100112	COUPLING FLANGE DUST COVER ASSY.	TATA spare parts
284641100113	SHORT FORK TUBE FRONT END PIECE ASSY	TATA spare parts
284641100114	ASSY. PROPELLER SHAFT FRONT TC BS III -M	TATA spare parts
284641100115	ASSY.PROPELLER SHAFT FRONT	TATA spare parts
284641100116	ASSY.PROPELLER SHAFT MIDDLE	TATA spare parts
284641100117	S/FORK TUBE & F.E.P ASSY	TATA spare parts
284641100119	PROPELLER SHAFT ASSY FRONT	TATA spare parts
284641105101	FRONT END PIECE(FRONT)	TATA spare parts
284641105102	COUPLING FLANGE (FRONT)	TATA spare parts
284641105103	NUT(FRONT)	TATA spare parts
284641105104	COMPANION FLANGE (FRONT)	TATA spare parts
284641105105	SHAFT NUT	TATA spare parts
284641105106	HEX NUT	TATA spare parts
284641110103	PROPELLER SHAFT ASSY FRONT	TATA spare parts
284641110105	PROPELLER SHAFT ASSY FRONT	TATA spare parts
284641110110	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
284641110112	PROPELLER SHAFT ASSY FRONT	TATA spare parts
284641110113	PROPELLER SHAFT ASSY FRONT	TATA spare parts
284641110114	PROPELLER SHAFT ASSY MIDDLE	TATA spare parts
284641110115	PROPELLER SHAFT ASSY FRONT	TATA spare parts
284641110118	PROPELLERSHAFTASSY FRONT	TATA spare parts
284641110120	PROPELELR SHAFT ASSY COUPLING FRONT	TATA spare parts
284641110121	PROPELELR SHAFT ASSY COUPLING MIDDLE	TATA spare parts
284641110122	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
284641110127	SHORT FORK TUBE&FRONT END PIECE ASSY	TATA spare parts
284641110128	SHORT FORK TUBE AND FRT END PIECE	TATA spare parts
284641110129	SHORT FORK TUBE AND FRT END PIECE	TATA spare parts
284641110136	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
284641110137	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
284641120101	ASSY. PROPELLER SHAFT REAR	TATA spare parts
284641120102	ASSY PROPELLER SHAFT REAR	TATA spare parts
284641120103	DUST COVER ASSY (REAR)	TATA spare parts
284641120104	SLIP YOKE ASSY	TATA spare parts
284641120105	ASSY PROPELLER SHAFT REAR	TATA spare parts
284641120107	CROSS ASSLY	TATA spare parts
284641120108	LONG FORK SUB ASSY	TATA spare parts

284641120109	SHORT FORK TUBE REAR HSG. ASSY	TATA spare parts
284641120110	ASSY. PROPELLER SHAFT REAR	TATA spare parts
284641120111	ASSY. PROPELLER SHAFT REAR 56 WB	TATA spare parts
284641120112	S/FORK TUBE & REAR HOUSING ASSY	TATA spare parts
284641120113	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
284641120114	PROPELLER SHAFT ASSY REAR	TATA spare parts
284641120116	PROPELLER SHAFT ASSY REAR BS6	TATA spare parts
284641120123	PROPELLER SHAFT ASSY REAR	TATA spare parts
284641120124	PROPELLER SHAFT ASSY REAR	TATA spare parts
284641120126	PROPELLER SHAFT ASSY REAR	TATA spare parts
284641120129	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
284641120131	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
284641120133	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
284641120134	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
284641125101	FLANGE YOKE (FRONT AND REAR)	TATA spare parts
284641125102	GREASE NIPPLE ZERK	TATA spare parts
284641125103	FLANGE YOKE	TATA spare parts
284641129901	CROSS ASSEMBLY	TATA spare parts
284641129903	SLIP YOKE ASSLY	TATA spare parts
284641129904	SEAL	TATA spare parts
284641200101	ASSY. PROP SHAFT GUARD (REAR)	TATA spare parts
284641200104	ASSY.CENTER BEARING MTG BKT	TATA spare parts
284641300102	BRACKET ASSY PROPELLER SHAFT GUARD LH	TATA spare parts
284641303302	BRACKET CENTER BRG MTG	TATA spare parts
284641303304	SPACER(CNETER BRG MTG)	TATA spare parts
284641303305	CENTRE BEARING MOUNTING BRACKET	TATA spare parts
284641303306	CENTRE BEARING MOUNTING BRACKET	TATA spare parts
284641303307	BRACKET CENTER BRG MTG	TATA spare parts
284641303308	CENTE BEARING MTG. BRACKET	TATA spare parts
284641303310	BRACKET CENTER BRG MTG FRONT	TATA spare parts
284641303316	BRACKET CENTER BEARING	TATA spare parts
284641308201	PROPELLER SHAFT GUARD(FRONT)	TATA spare parts
284641308203	L-BRACKET(GUARD MTG.)	TATA spare parts
284641308209	L-BRACKET(GUARD MTG.)	TATA spare parts
284641308212	PROPELLER SHAFT GUARD -RH	TATA spare parts
284641990108	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
284641990109	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
284642100118	ASSY FRT DRUM BRAKE WT DUST COVER RH	TATA spare parts
284642100119	ASSY FRT DRUM BRAKE WT DUST COVER LH	TATA spare parts
284642100138	BRAKE CHAMBER TYPE 30	TATA spare parts
284642100225	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
284642100226	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
284642100229	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
284642100230	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
284642100233	BRAKE SHOE W/LINING & ROLLER BS1/2/3/4	TATA spare parts
284642100234	BRAKE SHOE WITHOUT LINING	TATA spare parts
284642100241	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts

284642100242	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
284642100243	DRUM BRAKE ASSY FRONT -LH DIA410X180 M16	TATA spare parts
284642100244	DRUM BRAKE ASSY FRONT -RH DIA410X180 M16	TATA spare parts
284642100261	DRUM BRAKE ASSY FRONT -LH DIA410X180 M16	TATA spare parts
284642100262	DRUM BRAKE ASSY FRONT -RH DIA410X180 M16	TATA spare parts
284642100275	DRUM BRAKE ASSY FRONT -LH DIA410X180 M16	TATA spare parts
284642100276	DRUM BRAKE ASSY FRONT -RH DIA410X180 M16	TATA spare parts
284642103201	HEX BOLT	TATA spare parts
284642103401	SLEEVE -ABS SENSOR FRONT	TATA spare parts
284642103701	BRAKE DRUM SPIGOTTED 410 DIA BS3/4/6	TATA spare parts
284642106501	CASTLE NUT M20X2	TATA spare parts
284642106701	COLLERED PIN FOR BRK. ASSY.	TATA spare parts
284642106702	COLLERED PIN FOR AAL BRAKE ASSEMBLY	TATA spare parts
284642106703	COLLER PIN STG SIDE	TATA spare parts
284642106704	COLLARED PIN - M16X1.5X147 CLASS 10.9	TATA spare parts
284642106706	COLLARED PIN - M16X1.5X144	TATA spare parts
284642106708	COLLARED PIN-M20X2X154	TATA spare parts
284642106712	COLLARED PIN - M20X2X205 CLASS 10.9	TATA spare parts
284642106713	COLLARED PIN - M20X2X145	TATA spare parts
284642106714	COLLARED PIN - M20X2X165 CLASS 10.9	TATA spare parts
284642106715	COLLARED PIN - M20X2X185 CLASS 10.9	TATA spare parts
284642108201	ANCHOR BRACKET -LH ASA FRONT BRAKE	TATA spare parts
284642108202	ANCHOR BRACKET -RH ASA FRONT BRAKE	TATA spare parts
284642108203	ANCHOR BRACKET BS6-PH2	TATA spare parts
284642108204	ANCHOR BRACKET BS6-PH2	TATA spare parts
284642109901	POLE WHEEL -FRONT 100 TEETH PCD 147.5	TATA spare parts
284642300130	ASSY REAR AXLE BRAKE LH	TATA spare parts
284642300131	ASSY REAR AXLE BRAKE RH	TATA spare parts
284642300191	BRACKET ASSY BRAKE CHAMBER MTG	TATA spare parts
284642300192	BRACKET ASSY REAR CHAMBER MTG RH	TATA spare parts
284642300202	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
284642300203	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
284642305101	REAR BRAKE CAMSHAFT LH	TATA spare parts
284642305102	REAR BRAKE CAMSHAFT RH	TATA spare parts
284642308203	ANCHOR BRACKET LH BS6	TATA spare parts
284642308204	ANCHOR BRACKET RH BS6	TATA spare parts
284642990102	SPIDER ASSY LH	TATA spare parts
284642990103	SPIDER ASSY RH	TATA spare parts
284642990104	BRACKET LH	TATA spare parts
284642990105	BRACKET RH	TATA spare parts
284642990108	FRONT BRAKE OVERHAUL KIT (MINOR)	TATA spare parts
284642990109	SERVICE KIT FOR CAMSHAFT (FRONT)	TATA spare parts
284642990111	DRUM BRAKE -RIVETS KIT	TATA spare parts
284642990112	DRUM BRAKE -LINED SHOE KIT	TATA spare parts
284642990114	SERVICE KIT (MINOR) FRONT	TATA spare parts
284642990115	BRAKE SPRING KIT (FRONT)	TATA spare parts
284642990116	DRUM BRAKE -CAM SHAFT WASHER KIT	TATA spare parts

284642990120	ASSY. LINED SHOE NA1707 BS2/3/4/6	TATA spare parts
284642990121	TORQUE PLATE LH	TATA spare parts
284642990122	TORQUE PLATE RH	TATA spare parts
284642990123	TUBE - FLANGE AND BRACKET ASSY - LH	TATA spare parts
284642990124	TUBE - FLANGE AND BRACKET ASSY - RH	TATA spare parts
284642990125	DRUM BRAKE -KIT TORQUE PLATE LH	TATA spare parts
284642990126	DRUM BRAKE -KIT TORQUE PLATE RH	TATA spare parts
284642990127	KIT BRACKET ASSY LH ( BIL)	TATA spare parts
284642990128	KIT BRACKET ASSY RH ( BIL)	TATA spare parts
284642990130	KIT SPRING	TATA spare parts
284642990131	KIT DUST SHILD ASSY	TATA spare parts
284642990132	KIT CAMSHAFT LH	TATA spare parts
284642990133	KIT CAMSHAFT RH	TATA spare parts
284642990141	KIT BRACKET ASSY LH	TATA spare parts
284642990142	KIT BRACKET ASSY RH	TATA spare parts
284642990143	KIT CAMSHAFT RH	TATA spare parts
284642990144	KIT CAMSHAFT LH	TATA spare parts
284642990149	KIT BUSH	TATA spare parts
284642990150	KIT FULCRUM PIN	TATA spare parts
284642990153	KIT BRACKET ASSY LH ( BIL) BS6	TATA spare parts
284642990154	KIT BRACKET ASSY RH ( BIL) BS6	TATA spare parts
284642990157	KIT- ROLLER	TATA spare parts
284642993401	BUSH - CAM END	TATA spare parts
284642997801	OILSEAL (DOUBLE LIP)	TATA spare parts
284642997901	CAM SHAFT RH	TATA spare parts
284642997902	CAM SHAFT LH	TATA spare parts
284642997907	CAM SHAFT LH	TATA spare parts
284642997908	CAM SHAFT RH	TATA spare parts
284642998201	SHIELD ASSY - BOTTOM	TATA spare parts
284642998202	SHIELD ASSY - TOP	TATA spare parts
284643200101	ASSY AIR TANK-SUITABLE FOR VOSS(40 LTR)	TATA spare parts
284643200102	SUB ASSY.AIR TANK (WITH 70 MM BKT. C.D.)	TATA spare parts
284643200103	SUB ASSY.AIR TANK (270 MM BKT. C.D.)	TATA spare parts
284643200104	SUB ASSY.AIR TANKS 350 STRAP C.D.-VOSS	TATA spare parts
284643200105	ASSY.AIR TANK WITH SEALING PLUG-VOSS	TATA spare parts
284643200106	ASSY.BRACKET - (AIR TANK MTG.15LTR)	TATA spare parts
284643200107	ASSY. BRACKET (AIR TANK MTG. 30 LTR)	TATA spare parts
284643200109	ASSY.AIR TANKS 350 DIA 40 LIT.WITH BRACK	TATA spare parts
284643200110	ASSY.AIR TANK WITH SEALING PLUG-VOSS+MET	TATA spare parts
284643200111	AIR TANK ASSY 40 LTR 3-PORT VOSS	TATA spare parts
284643200112	ASSY BRACKET-LH(AIR TANK MTG.15LTR)	TATA spare parts
284643200113	ASSY BRACKET-RH(AIR TANK MTG.15LTR)	TATA spare parts
284643200114	ASSY BRACKET (15 LTR AIR TANK MTG)	TATA spare parts
284643200122	ASSY BRACKET - AIR TANK MTG	TATA spare parts
284643200135	BRACKET ASSY AIR TANK BS6	TATA spare parts
284643200137	ASSY MTG BRACKET FOR ADJUSTING VALVE	TATA spare parts
284643200138	ASSY AIR TANK 40 LTR VOSS W/O PLUG	TATA spare parts

284643200139	ASSY AIR TANK 40 LTR W/O SEALING PLUG	TATA spare parts
284643200140	ASSY AIR TANK 40L VOSS-METRIC W/O PLUG	TATA spare parts
284643200146	AIR TANK ASSY 40 LTR REAR VOSS	TATA spare parts
284643200148	AIR TANK ASSY 40 L FRONT 3 PORT	TATA spare parts
284643200149	AIR TANK ASSY 40 LTR REAR 3 PORT	TATA spare parts
284643200153	AIR TANK ASSY 40 LTR WITH BRACKETS	TATA spare parts
284643200154	ASSY AIR TANK WITH END FITTINGS	TATA spare parts
284643200158	AIR TANK ASSY WITH BKT	TATA spare parts
284643203201	HEX BOLT M8X110	TATA spare parts
284643208229	BRACKET RELAY VALVE MTG	TATA spare parts
284643208232	BRACKET RELAY MOUNTING	TATA spare parts
284643607501	GROMMET	TATA spare parts
284643700105	NON-RETURN VALVE(M306100)VOSS	TATA spare parts
284643700106	ASSY BRACKET- AIR TANKS MTG	TATA spare parts
284643700107	ASSY AIR TANK(30 LTS)VOSS-LPT3118 WO NRV	TATA spare parts
284643700116	AIR PROCESSING UNIT	TATA spare parts
284643700117	KIT-BRAKE CHAMBER	TATA spare parts
284643700119	ASSY. BRACKET(DDU MTG.)	TATA spare parts
284643700120	ASSY AIR TANK (15 LTR)VOSS WITH BRACKET	TATA spare parts
284643700121	ASSY.AIR TANK(30 LIR)VOSS-WITH BRACKET	TATA spare parts
284643700123	ASSY AIR TANK(15LTR)VOSS-LPT WT NRV	TATA spare parts
284643700126	ASSY AIR TANK (15LTRS) VOSS WITH MTG BKT	TATA spare parts
284643700138	REPAIR KIT DUAL BRAKE VALVE	TATA spare parts
284643700150	AIR DRYER(8.1BAR-VOSS)	TATA spare parts
284643700162	GRAD HAND CONTR. VLV W/SELF RETURN BS1-6	TATA spare parts
284643700163	GRAD HAND CONTROL VALVE WITH SELF RETURN	TATA spare parts
284643700164	GRAD HAND CONTROL VALVE WITH SELF RETURN	TATA spare parts
284643700165	GRAD HAND CONTR. VLV W/SELF RETURN BS1-6	TATA spare parts
284643700166	REPAIR KIT-GR HAND BR VALVE	TATA spare parts
284643700178	RELAY VALVE VOSS(KB)	TATA spare parts
284643700183	SYSTEM PROTCTION VALVE	TATA spare parts
284643700184	ADJUSTING VALVE	TATA spare parts
284643700185	TYPE 30 BRAKE CHAMBER	TATA spare parts
284643700190	ASSY AIR TANK 20 LIT VOSS	TATA spare parts
284643700205	BRACKET ASSY AIR TANK MOUNTING	TATA spare parts
284643700212	BRACKET ASSY AIR TANK MOUNTING	TATA spare parts
284643700213	BRACKET ASSY AIR TANK MOUNTING	TATA spare parts
284643700214	BRACKET ASSY SUPPORT AIR DRYER MTG	TATA spare parts
284643700216	BRACKET ASSY FOR CONNECTOR MTG	TATA spare parts
284643700235	REPAIR KIT AIR PROCESSING UNIT-KB	TATA spare parts
284643700237	SOLENOID MODULATOR VALVE	TATA spare parts
284643700240	SYSTEM PROTECTION VALVE-WABCO	TATA spare parts
284643700252	KIT-BRAKE CHAMBER MAJOR	TATA spare parts
284643700253	KIT-BRAKE CHAMBER MINOR	TATA spare parts
284643700254	KIT-SPRING BRAKE ACTUATOR MAJOR	TATA spare parts
284643700255	KIT-SPRING BRAKE ACTUATOR MINOR	TATA spare parts
284643700257	KIT-SPRING BRAKE ACTUATOR BS6	TATA spare parts

284643700259	KIT-SPRING BRAKE ACTUATOR	TATA spare parts
284643700260	KIT-SPRING BRAKE ACTUATOR	TATA spare parts
284643707706	SPECIAL WASHER	TATA spare parts
284643707711	O-RING	TATA spare parts
284643710104	ASSY 30 LTRS AIR TANK	TATA spare parts
284643710109	DUAL TREADLE VALVE (ERGO) BS2/3/4	TATA spare parts
284643710111	FOOT BRAKE VALVE	TATA spare parts
284643710112	AIR DRYER(8.1BAR-VOSS) BS3/4	TATA spare parts
284643710126	SPRING BRAKE ACTUATOR TYPE 20/24 (V+M)	TATA spare parts
284643710127	SPRING BRAKE ACTUATOR TYPE 20/24 VOSS	TATA spare parts
284643710130	ASY RELY VAL&BRKT (DEL1-PLG&DEL2-ADP)	TATA spare parts
284643710139	BRACKET ASSY RELAY VALVE MOUNTING	TATA spare parts
284643710150	SYSTEM PROTCTION VALVE	TATA spare parts
284643710151	BRACKET ASSY RELAY VALVE MOUNTING	TATA spare parts
284643710154	KIT-SPRING BRAKE ACTUATOR SERVICE(MINOR)	TATA spare parts
284643710162	BRAKE CHAMBER TYPE 16	TATA spare parts
284643710164	RELAY WITH MODULATOR VALVE ASSEMBLY	TATA spare parts
284643710178	SYSTEM PROTECTION VALVE-KB	TATA spare parts
284643900152	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
284643900153	ASY.NY.PIPE SET COMP3118COWL/VOSS	TATA spare parts
284643900160	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
284643900161	ASSY.METAL PIPE COMP TO HOSE(DIA18)	TATA spare parts
284643900162	ASSY.METAL PIPE HOSE TO INT.JOINT(DIA18)	TATA spare parts
284643900163	ASSY.METAL PIPE INT.JOINT TO DDU(DIA18)	TATA spare parts
284643900167	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
284643900168	5/8INC HOSE ASSY. WITH END FITTINGS - 70	TATA spare parts
284643900169	5/8INC HOSE ASSY. WITH END FITTINGS - 80	TATA spare parts
284643900170	5/8INC HOSE ASSY. WITH END FITTINGS - 10	TATA spare parts
284643900172	KIT-NYLON PIPE WITH CLAMPS & BKTS	TATA spare parts
284643900181	PIPE ASSY BUNCH COMPLETE	TATA spare parts
284643900186	PIPE BUNCH ASSY	TATA spare parts
284643900198	PIPE BUNCH ASSY	TATA spare parts
284643903305	BRACKET STRAIGHT	TATA spare parts
284643903306	STRAIGHT BRACKET	TATA spare parts
284643903308	STRAIGHT BRACKET	TATA spare parts
284643903318	MALE ADAPTOR (M26X1.5 TO M26X1.5) BS6-PH	TATA spare parts
284643903319	O RING (VITON) BS6	TATA spare parts
284643903367	BRACKET BS6	TATA spare parts
284643906801	COUPLING BODY (M26X1.5 TO M22X1.5)	TATA spare parts
284643906804	BRACKET (FOR T CONNTR. MOUNTING)	TATA spare parts
284643906821	COUPLING BODY (M14X1.5 TO M22X1.5)	TATA spare parts
284643906824	BRACKET FOR T CONNECTOR MTG.(DEAD AXLE)	TATA spare parts
284643906828	FIRTEE 12X8X12	TATA spare parts
284643906832	BRACKET T-CONN MTG	TATA spare parts
284643908207	BRACKET SPV MOUNTING	TATA spare parts
284643910102	HOSE ASSY WITH O-RING NIPPLE	TATA spare parts
284643910116	ASSY.NY.PIPE SET CHASSIS COMPL-LPT3118	TATA spare parts

284643910120	ASSY. STRAP	TATA spare parts
284643910124	ASSY AIR TANK WITH END FITTINGS	TATA spare parts
284643910127	ASSY.METAL PIPE FOR CONTROL PORT OUTLET	TATA spare parts
284643910132	ASSY.NYLON PIPE SET COMPLETE	TATA spare parts
284643910141	ASSY NYLON PIPE SET FOR CHASSIS	TATA spare parts
284643910142	ASSY METAL PIPE HOSE TO INT JOINT	TATA spare parts
284643910144	ASSY METAL PIPE INT. JOINT TO AIR DRYER	TATA spare parts
284643910146	ASSY NYLON PIPE SET CHASSIS LPT3118TC-56	TATA spare parts
284643910155	ASSY.HOSE 3/8WITH O-RING & 490MM LENG	TATA spare parts
284643910156	ASSY.HOSE 3/8WITH O-RING & 490MM LENG	TATA spare parts
284643910157	ASSY.HOSE 3/8IN WITH O-RING & 410MM LENG	TATA spare parts
284643910170	ASSY NYLON PIPE SET CHASSIS COMP	TATA spare parts
284643910173	ASSY METAL PIPE FR COMP OUTLET TO INT JT	TATA spare parts
284643910174	ASSY METAL PIPE FROM INT JT1 TO JT2	TATA spare parts
284643910175	ASSY METAL PIPE FR INT JT2 TO DDU INLET	TATA spare parts
284643910181	ASSY COUPLING BODY(26X1.5) WITH O RINGN	TATA spare parts
284643910184	ASSY NYLON PIPE SET COML.LPT3118TC52-CAB	TATA spare parts
284643910186	ASSY.HOSE 3/8 IN WITH O-RING & 552MM LEN	TATA spare parts
284643910190	ASSY METAL PIPE FR COMP OUTLET TO INT JT	TATA spare parts
284643910191	ASSY METAL PIPE FROM INT JT1 TO JT2	TATA spare parts
284643910192	ASSY METAL PIPE FR INT JT2 TO AD INLET	TATA spare parts
284643920121	METAL PIPE ASSY COMP OUTLET 2ND	TATA spare parts
284643920122	METAL PIPE ASSY COMP OUTLET 3RD	TATA spare parts
284643920123	METAL PIPE ASSY COMP OUTLET 4TH	TATA spare parts
284643920142	DKO-NIPPLE FOR 6MM NYLON TUBE BS6	TATA spare parts
284643920159	ASSY METAL PIPE 2ND WITH O-RING	TATA spare parts
284643920160	ASSY METAL PIPE 3RD WITH O-RING	TATA spare parts
284643920261	METAL PIPE ASSY	TATA spare parts
284643920262	METAL PIPE ASSY	TATA spare parts
284643920263	METAL PIPE ASSY	TATA spare parts
284643920273	PIPE BUNCH ASSY	TATA spare parts
284643930149	ASSY METAL PIPE JOINT 2 TO DDU	TATA spare parts
284643930152	ASSY METAL PIPE FROM INT JT1 T	TATA spare parts
284643930164	ASSY NYLON PIPE SET CHASSIS LPT3118TC-56	TATA spare parts
284643930171	ASSY COMP.METAL PIPE JOINT-1 TO JOINT-2	TATA spare parts
284643930172	ASSY COMP.3RD METAL PIPE JOINT-2 TO AD	TATA spare parts
284643930173	ASSY.HOSE 3/8IN WITH O-RING & 410MM LEN	TATA spare parts
284643930174	ASSY.HOSE 3/8INWITH O-RING & 552MM LEN	TATA spare parts
284643930179	ASSY.HOSE 3/8IN WITH O-RING & 590MM LEN	TATA spare parts
284643930180	ASSY.HOSE 3/8IN WITH O-RING & 620MM LEN-	TATA spare parts
284643930181	ASSY.HOSE 3/8 WITH O-RING & 865MM LEN	TATA spare parts
284643930182	ASSY.HOSE 3/8INWITH O-RING & 610MM LEN	TATA spare parts
284643930183	ASSY.HOSE 3/8INWITH O-RING & 490MM LEN	TATA spare parts
284643930186	ASSY METAL PIPE 3RD LPT3118TC-62WB	TATA spare parts
284643930187	ASSY METAL PIPE 2ND LPT3118TC-62WB	TATA spare parts
284643930195	ASSY NYLON PIPE BUNCH	TATA spare parts
284643930196	ASSY. COMPRESSOR 1ST METAL PIPE BS3/4/6	TATA spare parts

284643930199	NYLON PIPE BUNCH ASSY	TATA spare parts
284643930201	PIPE BUNCH ASSY COMPLETE	TATA spare parts
284643930284	METAL PIPE ASSY JOINT-2 TO AIR DRYER	TATA spare parts
284643930291	PIPE BUNCH ASSY COMPLETE	TATA spare parts
284643936952	METAL PIPE JOINT 2 TO DDU	TATA spare parts
284643940151	ASSY NYLON PIPE SET CHASSIS LPT3118TC	TATA spare parts
284643940200	PIPE ASSY BUNCH COMPLETE	TATA spare parts
284643940252	METAL PIPE ASSY 3 RD WITH O RING	TATA spare parts
284643940260	PIPE BUNCH ASSY COMPLETE	TATA spare parts
284643940302	PIPE ASSY JOINT-1 TO JOINT-2	TATA spare parts
284643950108	ASSY NYLON PIPE BUNCH	TATA spare parts
284643950201	PIPE BUNCH ASSY COMPLETE	TATA spare parts
284643950215	PIPE ASSY BUNCH COMPLETE	TATA spare parts
284643950225	PIPE ASSY BUNCH COMPLETE	TATA spare parts
284643950243	PIPE ASSY COMP JOINT-1 TO JOINT-2	TATA spare parts
284643950256	PIPE ASSY BUNCH COMPLETE	TATA spare parts
284643950283	PIPE ASSY BUNCH COMPLETE	TATA spare parts
284643950293	PIPE BUNCH ASSY	TATA spare parts
284643960179	ASSY METAL PIPE COMPRESSOR TO JOINT-1	TATA spare parts
284643960180	METAL PIPE ASSY 2ND JOINT-1 TO JOINT-2	TATA spare parts
284643960182	METAL PIPE ASSY 3RD JOINT-2 TO AIR DRYER	TATA spare parts
284643960208	METAL PIPE ASSY	TATA spare parts
284643960210	METAL PIPE ASSY	TATA spare parts
284643970103	PIPE ASSY BUNCH LPT3118 TWIN STEER	TATA spare parts
284643970127	PIPE ASSY METAL INTER. JOINT 1 TO 2	TATA spare parts
284643980158	PIPE BUNCH ASSEMBLY COMPLETE	TATA spare parts
284643990123	KIT-SPRING BRAKE ACTUATOR TYPE-24/24	TATA spare parts
284643990124	KIT-NON RETURN VALVE BS6-PH2	TATA spare parts
284643990175	MINOR KIT BS6	TATA spare parts
284643990176	MAJOR KIT BS6	TATA spare parts
284645100102	BREATHER HOSE ASSY	TATA spare parts
284645903301	BRACKET(BREATHER MOUNTING)	TATA spare parts
284645903302	BRACKET(BREATHER MOUNTING)FOR 3118 62WB	TATA spare parts
284645908202	COUPLING BODY	TATA spare parts
284646000122	ASSY. STEERING GEAR BOX BS3/4/6	TATA spare parts
284646000125	ASSY. DRAG LINK-RHD(OFFER DRG.) BS1- 4	TATA spare parts
284646000126	ASSY.DRAG LINK-SERVICEABILITY	TATA spare parts
284646000128	ASSY.DRAG LINK	TATA spare parts
284646100101	KIT ASSY PIPE&CLAMPS COWL	TATA spare parts
284646100103	BRACKET STG. GEAR BOX MTG. BS2/3	TATA spare parts
284646100104	ASSY STG GEAR BOX MTG BRACKET.CAB	TATA spare parts
284646100105	KIT FOR ASSY. PIPE & CLAMPS (TILT CAB)	TATA spare parts
284646100106	KIT ASSY PIPE&CLAMPS COWL	TATA spare parts
284646100114	ASSY. STG. GEAR BOX MTG. BRACKET	TATA spare parts
284646100121	STEERING GEARBOX MTG BKT BS3/4	TATA spare parts
284646100128	STEERING COLUMN ASSY W/O STEERING WHEEL	TATA spare parts
284646106301	HOLDING BRACKET BS6	TATA spare parts



284646107179	PLATE MOUNTING	TATA spare parts
284646107180	PLATE MOUNTING	TATA spare parts
284646108001	HEX.SCREW M20X1.5X50 IS13725-10.9-SS:845	TATA spare parts
284646108003	HEX FLANGE BOLT	TATA spare parts
284646108601	SPACER BS6	TATA spare parts
284646207702	RUBBER BELLOW BS6	TATA spare parts
284646207901	SLEEVE STEERING	TATA spare parts
284646207902	STEERING SLEEVE	TATA spare parts
284646207903	STEERING SPINDE BOTTOM	TATA spare parts
284646208202	PLATE BELLOW BS6	TATA spare parts
284646304101	PITMAN ARM	TATA spare parts
284646305103	PITMAN ARM	TATA spare parts
284646305104	PITMAN ARM	TATA spare parts
284646305105	PITMAN ARM	TATA spare parts
284646305106	PITMAN ARM	TATA spare parts
284646305107	PITMAN ARM	TATA spare parts
284646305110	RELAY ARM	TATA spare parts
284646400101	STEERING WHEEL ASSY WITH HORN PAD	TATA spare parts
284646508202	DOUBLE CLAMP 15X18	TATA spare parts
284646600102	STEERING PUMP TYPE II	TATA spare parts
284646600103	POWER STEERING GEARBOX	TATA spare parts
284646600104	ASSY. STEERING GEAR BOX BS3/4	TATA spare parts
284646600106	POWER STEERING PUMP ASSY BS6	TATA spare parts
284646600108	ASSY. STEERING GEAR BOX BS3/4	TATA spare parts
284646600109	STEERING GEAR BOX ASSY	TATA spare parts
284646600111	BRACKET ASSY RESERVOIR	TATA spare parts
284646600112	STEERING GEAR BOX ASSY	TATA spare parts
284646600123	ASSY. STEERING GEAR BOX BS4	TATA spare parts
284646600130	KIT-SEAL	TATA spare parts
284646600131	KIT-SEAL	TATA spare parts
284646600132	KIT-AUTO POPPET VALVE	TATA spare parts
284646600134	KIT-RELIEF VALVE	TATA spare parts
284646600136	KIT-SEAL	TATA spare parts
284646600138	KIT-SEAL	TATA spare parts
284646600139	KIT-RELIEF VALVE	TATA spare parts
284646600142	CARTRIDGE ASSY BS6	TATA spare parts
284646600143	KIT-HOUSING ASSY BS6	TATA spare parts
284646600146	SHAFT ASSY BS6	TATA spare parts
284646600153	KIT-HOUSING ASSY BS6	TATA spare parts
284646600156	KIT-SEAL BS6	TATA spare parts
284646600159	CARTRIDGE ASSEMBLY BS6	TATA spare parts
284646603201	BOLT BS6	TATA spare parts
284646603303	BRACKET STG GEAR BOX MTG	TATA spare parts
284646603702	PUMP BODY BS6	TATA spare parts
284646606801	PRESSURE PORT CONNECTOR BS6	TATA spare parts
284646607201	CV PLUG BS6	TATA spare parts
284646607811	O RING BS6	TATA spare parts

284646607812	O RING BS6	TATA spare parts
284646607813	O RING BS6	TATA spare parts
284646607814	O RING BS6	TATA spare parts
284646609901	HOUSING ASM.	TATA spare parts
284646609902	VALVE INSERT ASM.	TATA spare parts
284646609903	HOUSING COVER ASM.	TATA spare parts
284646609904	VALVE LIMITER	TATA spare parts
284646609905	SECTOR SHAFT ASM.	TATA spare parts
284646609906	PISTON ASM.	TATA spare parts
284646609907	SHAFT SEAL	TATA spare parts
284646609908	COMPLETE SEALING KIT.	TATA spare parts
284646609909	DUST SEAL	TATA spare parts
284646609910	HARDWARE KIT	TATA spare parts
284646609946	INPUT SHAFT SEAL KIT	TATA spare parts
284646609947	VALVE HOUSING ASSY	TATA spare parts
284646609948	KIT-THRUST BEARING	TATA spare parts
284646609949	WORM RACK ASSY	TATA spare parts
284646609950	BALL RETURN GUIDE -RH	TATA spare parts
284646609951	SET-SCREW	TATA spare parts
284646609952	HOUSING	TATA spare parts
284646609953	SECTOR SHAFT ASSY	TATA spare parts
284646609954	SEAL	TATA spare parts
284646609955	RELIEF VALVE ASSY (130 BAR)	TATA spare parts
284646609956	SPRING WASHER	TATA spare parts
284646609958	KIT-MAJOR SEAL	TATA spare parts
284646609959	KIT-MAJOR SEAL (COMPACT)	TATA spare parts
284646609960	KIT-MAJOR SEAL	TATA spare parts
284646609961	VALVE INSERT ASSY	TATA spare parts
284646609962	PISTON ASSY	TATA spare parts
284646703303	STEERING GEAR BOX MOUNTING BRKT	TATA spare parts
284646703305	POWER CYLINDER MTG.BRACKET	TATA spare parts
284646703306	BRACKET STG GEAR BOX MTG	TATA spare parts
284646703308	BRACKET STG GEAR BOX MTG BS3/4	TATA spare parts
284646703310	BRACKET STG GEAR BOX MTG	TATA spare parts
284646703313	BRACKET STG GEAR BOX MTG	TATA spare parts
284646703316	ASSY. BRACKET STG. GEAR BOX MTG. BS3/4/6	TATA spare parts
284646703317	BRACKET STG GEAR BOX MTG	TATA spare parts
284646800127	ASSY. HOSE SUCTION LINE (REV. TO PUMP)	TATA spare parts
284646800128	ASSY. PRESSURE LINE (PUMP TO GEAR BOX)	TATA spare parts
284646800129	ASSY. RETURN LINE(PUMP TO 1ST INT JOINT)	TATA spare parts
284646800130	ASSY. RETURN LINE(1ST INT JOINT TO REV.)	TATA spare parts
284646800131	ASSY. SUCTION LINE (REV. TO PUMP)	TATA spare parts
284646800132	ASSY.3/8 IN R1HOSE PRESSURE LINE(PUMP TO	TATA spare parts
284646800133	ASSY.3/8 IN R1HOSE RET.LINE (GB TO RESER	TATA spare parts
284646800145	ASSY. COUPLING BODY WITH O RING	TATA spare parts
284646800146	ASSY. COUPLING BODY WITH O-RING	TATA spare parts
284646800147	ASSY. COUPLING BODY WITH O-RING	TATA spare parts

284646800148	ASSY PRESSURE LINE FROM PUMP TO GB	TATA spare parts
284646800149	ASSY RETURN LINE	TATA spare parts
284646800150	ASSY. PRESSURE LINE-C	TATA spare parts
284646800151	ASSY.PRESSURE LINE-D FROM CYL TO STG GB	TATA spare parts
284646800152	ASSY SUCTION LINE	TATA spare parts
284646800153	ASSY.SEALING RING (M22X1.5)	TATA spare parts
284646800163	ASSY SUCTION LINE	TATA spare parts
284646800166	RETURN LINE ASSY	TATA spare parts
284646800167	PRESSURE LINE ASSY	TATA spare parts
284646800179	RETURN LINE ASSY- JOINT 1 TO HYD TANK	TATA spare parts
284646800181	SUCTION LINE ASSY- HYD TANK TO STG PUMP	TATA spare parts
284646800182	HIGH PRESSURE LINE ASSY -C PORT	TATA spare parts
284646800183	HIGH PRESSURE LINE ASSY -D PORT	TATA spare parts
284646800184	HIGH PRESSURE LINE ASSY- STG PUMP TO STG	TATA spare parts
284646800185	RETURN LINE ASSY- STG GEAR BOX TO JOINT	TATA spare parts
284646800186	ELBOW ADAPTER ASSY	TATA spare parts
284646800189	ELBOW ADAPTOR ASSY	TATA spare parts
284646800190	ASSY. COUPLING BODY WITH O RING	TATA spare parts
284646800191	SUCTION LINE ASSY	TATA spare parts
284646800192	PRESSURE LINE ASSY	TATA spare parts
284646800193	RETURN LINE ASSY	TATA spare parts
284646800194	PRESSURE LINE ASSY-RANE	TATA spare parts
284646800195	RETURN LINE ASSY-RANE	TATA spare parts
284646800199	SUCTION LINE ASSY	TATA spare parts
284646800201	PRESSURE LINE ASSY	TATA spare parts
284646800202	RETURN LINE ASSY GB END	TATA spare parts
284646800203	RETURN LINE ASSY RESERVIOR END	TATA spare parts
284646803301	BRACKET	TATA spare parts
284646804206	CLAMP	TATA spare parts
284646806923	O-RING BS6-PH2	TATA spare parts
284646806924	O-RING	TATA spare parts
284646808206	ADAPTOR M26XM18 BS6-PH2	TATA spare parts
284646808207	COUPLING BODY(M22X1.5-M18X1.5)	TATA spare parts
284646808208	COUPLING BODY	TATA spare parts
284646900101	ASSY. DRAG LINK BS3/4	TATA spare parts
284646900102	ASSY. DRAG LINK BS3/4/6	TATA spare parts
284646900103	DRAG LINK ASSY	TATA spare parts
284646900104	BALL JOINT ASSY	TATA spare parts
284646900107	BALL JOINT ASSY	TATA spare parts
284646900108	DRAG LINK ASSY	TATA spare parts
284646909901	BALL JOINT& ASSY	TATA spare parts
284646909902	END ASSY RH	TATA spare parts
284646913301	BRACKET	TATA spare parts
284646990105	ASSY KIT OF PIPELINES & ADAPTERS	TATA spare parts
284646990113	KIT-STEERING LINES	TATA spare parts
284646990121	KIT-STEERING LINES	TATA spare parts
284646990126	SHAFT SUB ASSY	TATA spare parts

284646990127	CARTRIDGE ASSY	TATA spare parts
284646990128	SEAL KIT	TATA spare parts
284646990129	END COVER	TATA spare parts
284646990130	DOWEL PIN	TATA spare parts
284646990131	ALLEN SCREW	TATA spare parts
284646990132	O RING	TATA spare parts
284646990133	NEEDLE ROLLER BEARING	TATA spare parts
284646990134	RETAINING RING	TATA spare parts
284646990135	SPRING (FLOW CONTROL)	TATA spare parts
284646990136	SEAL WASHER	TATA spare parts
284646990137	PLUG SUB ASSY	TATA spare parts
284646990138	O RING (SPIGOT)	TATA spare parts
284646990139	DRIVE COUPLING DISC	TATA spare parts
284646990142	BOLT-V/HSG	TATA spare parts
284646990143	SEAL NUT (POPPET ADJ. SCREW)	TATA spare parts
284646990144	ADJ. SCREW - POPPET (V/HSG) D1088	TATA spare parts
284646990145	O RING (V/HSG)	TATA spare parts
284646990146	THRUST BEARING KIT	TATA spare parts
284646990147	SEAL KIT(VALVE SLEEVE)	TATA spare parts
284646990149	BALL	TATA spare parts
284646990150	BALL RETURN GUIDE	TATA spare parts
284646990152	CLIP	TATA spare parts
284646990153	HEX HEAD SCREW B/RTN CLIP	TATA spare parts
284646990154	POPPET VALVE KIT	TATA spare parts
284646990155	SEAL KIT (WORM SHAFT)	TATA spare parts
284646990156	SEAL KIT (PISTON RACK)	TATA spare parts
284646990157	ADJ. SCREW-THRIST	TATA spare parts
284646990158	SEAL NUT (WORM ADJ. SCREW)	TATA spare parts
284646990159	ADJ SCREW - POPPET (HSG)	TATA spare parts
284646990160	NUT DROP ARM	TATA spare parts
284646990161	WASHER DROPARM	TATA spare parts
284646990162	SEAL KIT - (OUTPUT SHAFT SIDE) BS6	TATA spare parts
284646990163	ROLLER BEARING(HSG/SIDE COVER)	TATA spare parts
284646990164	RETAINING RING	TATA spare parts
284646990166	SECTOR SHAFT ASSY	TATA spare parts
284646990167	S/S ADJ SCREW KIT	TATA spare parts
284646990168	S/S ADJ SCREW KIT (ALTERNATE)	TATA spare parts
284646990169	SEAL-SIDE COVER	TATA spare parts
284646990170	O RING-SIDE COVER	TATA spare parts
284646990171	SIDE COVER	TATA spare parts
284646990172	HEXAGONAL HEAD BOLT-S/COVER	TATA spare parts
284646990173	NUT1/2INCH UNF S/S ADJ SCREW	TATA spare parts
284646990174	NUT1/2IN UNF S/S ADJ SCREW (ALTERNATE)	TATA spare parts
284646990175	PLUG	TATA spare parts
284646990176	O RING(RELIEF VALVE)	TATA spare parts
284646990177	PLUG(RELIEF VALVE)	TATA spare parts
284646990178	RELIEF VALVE ASSY(150 BAR)	TATA spare parts

284646990181	NUT DROP ARM WITH COLLAR	TATA spare parts
284646990184	KIT-PIPE & ADAPTER	TATA spare parts
284646990185	KIT-PIPE & ADAPTER	TATA spare parts
284646990187	SECTOR SHAFT ASSY	TATA spare parts
284646990195	KIT-SEAL	TATA spare parts
284646990196	SECTOR SHAFT ASSY	TATA spare parts
284646990197	KIT-SEAL	TATA spare parts
284646990199	KIT-MAJOR SEAL	TATA spare parts
284646990201	S/S ADJ SCREW KIT	TATA spare parts
284646990204	WORM RACK ASSY ALTERNATE	TATA spare parts
284646990205	WORM RACK ASSY	TATA spare parts
284646990206	KIT-PIPE & ADAPTER	TATA spare parts
284646990208	KIT-PIPE & ADAPTER	TATA spare parts
284646990223	KIT-RELAY ARM ASSY & DRAGLINK TUBE	TATA spare parts
284646990262	BOOT	TATA spare parts
284646990263	SHAFT	TATA spare parts
284646990264	KIT-SEAL	TATA spare parts
284646990265	COVER	TATA spare parts
284646990266	KIT-SEAL	TATA spare parts
284646990269	KIT-RELIEF VALVE	TATA spare parts
284646990270	BEARING	TATA spare parts
284646990271	KIT SEAL	TATA spare parts
284646990272	HOUSING	TATA spare parts
284646990273	PISTON	TATA spare parts
284646990274	CAP	TATA spare parts
284646993701	HOUSING	TATA spare parts
284646998001	SET-SCREW	TATA spare parts
284646998201	BALL RETURN GUIDE RH	TATA spare parts
284646998202	BALL RETURN GUIDE RH	TATA spare parts
284647100101	ASSY. FUEL TANK COMPLETE (400 LTR) BS1-4	TATA spare parts
284647100113	ASSY. FUEL TANK W/TANK UNIT BS4	TATA spare parts
284647100118	FUEL TANK ASSY W/O TANK UNIT BS6	TATA spare parts
284647100119	FUEL TANK ASSY W/O CAP BS6	TATA spare parts
284647100138	FUEL CAP & CHAIN ASSY	TATA spare parts
284647100139	TUBE ANTI SYPHON UNIT WITH FLAP BS6	TATA spare parts
284647103801	FILLER NECK BS6	TATA spare parts
284647107801	O-RING BS6	TATA spare parts
284647108205	TUBE ANT ISYPHON BS6	TATA spare parts
284647109202	RUBBER WASHER BS6	TATA spare parts
284647500102	ASSY SUPPORT (RECT 400 LTR)	TATA spare parts
284647500103	ASSY BRACKET (LM MTG)	TATA spare parts
284647500104	ASSY.OF RUBBER PACKING-STRAP & ASSY.STRA	TATA spare parts
284647500105	ASSY. BRACKET FUEL TANK MTG. BS2/3/4	TATA spare parts
284647500110	FUEL TANK MTG BKT ASSY (SECOND)	TATA spare parts
284647506701	CLEVIS PIN	TATA spare parts
284647600104	ASSY. SUCTION LINE	TATA spare parts
284647600105	ASSY. RETURN LINE	TATA spare parts

284647600112	SUCTION LINE (FUEL TANK TO FUEL FILTER)	TATA spare parts
284647600113	SUCTION LINE (FUEL FILTER TO ENG)	TATA spare parts
284647600114	RETURN LINE ASSY ON TANK	TATA spare parts
284647600121	ASSY. SUCTION LINE	TATA spare parts
284647600122	ASSY. RETURN LINE	TATA spare parts
284647600131	ASSY.RETURN LINE (FIP TO FUEL TANK)	TATA spare parts
284647600143	FUEL SUCTION PIPE ASSY FUEL FTR TO ENG	TATA spare parts
284647600144	SUCTION LINE (FUEL FILTER TO ENG)	TATA spare parts
284647600145	RETURN LINE ASSY ON TANK (ENG.TO TANK)	TATA spare parts
284647600146	SUCTION LINE (FUEL FILTER TO ENG)	TATA spare parts
284647600147	SUCTION LINE (FUEL TANK TO FUEL FILTER)	TATA spare parts
284647600149	SUCTION LINE (TANK TO FILTER)	TATA spare parts
284647600150	SUCTION LINE (FILTER TO ENG)	TATA spare parts
284647600151	RETURN LINE ASSY ON TANK	TATA spare parts
284647600154	SUCTION LINE (FUEL TANK TO FUEL FILTER)	TATA spare parts
284647600155	SUCTION LINE (FUEL FILTER TO ENG)	TATA spare parts
284647600156	ASSY RETURN LINE (FIP TO FUEL TANK)	TATA spare parts
284647600161	SUCTION LINE TUBE ASSY TANK TO W/SEP	TATA spare parts
284647600162	SUCTION FUEL PIPE W/SEP TO FIP	TATA spare parts
284647600163	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
284647600166	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
284647603301	SUPPORT BKT FOR FUEL PIPING	TATA spare parts
284647603303	BRACKET FUEL LINE SUPPORT RIVIGO	TATA spare parts
284647703301	BRACKET FUEL FILTER MTG	TATA spare parts
284647703302	BRACKET FILTER MTG	TATA spare parts
284647707101	BRACKET FUEL WATER SEPARATOR MTG	TATA spare parts
284647913301	BRACKET(SUPPORT FOR FUEL LINE)	TATA spare parts
284649100103	ASSY 2ND PIPE WITH FLEX CONNECTOR	TATA spare parts
284649100104	ASSY SILENCER WITH TAIL PIPE	TATA spare parts
284649100107	ASSY. BRACKET-RH(FOR EXHAUST MTG)	TATA spare parts
284649100108	ASSY. BRACKET-LH (FOR EXHAUST MTG)	TATA spare parts
284649100122	ASSY 2ND PIPE WITH FLEX CONNECTOR	TATA spare parts
284649100126	ASSY EXHAUST WITH FLEX PIPE - 56 WB	TATA spare parts
284649100127	ASSY. SILENCER WITH TAIL PIPE BS3/4	TATA spare parts
284649100128	ASSY EXHAUST PIPE WITH FLEX PIPE - 52WB	TATA spare parts
284649100138	SILENCER ASSY WITH TAIL PIPE	TATA spare parts
284649200104	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
284649200107	STRAP ASSY UREA TANK MTG	TATA spare parts
284649200110	ASSY. EXHAUST PIPE	TATA spare parts
284649200111	ASSY. BRACKET	TATA spare parts
284649200112	ASSY. EXHAUST PIPE	TATA spare parts
284649200117	ASSY EXHAUST FIRST PIPE (TC COWL BS III)	TATA spare parts
284649200120	ASSY. MUFFLER (DOUBLE JACKET BSIII)	TATA spare parts
284649200121	ASSY. BRACKET-RH (EXHAUST MTG ON LM)	TATA spare parts
284649200122	ASSY. BRACKET-LH (EXHAUST MTG ON LM)	TATA spare parts
284649200123	ASSY. BRACKET SILENCER MTG-RH.	TATA spare parts
284649200124	ASSY. BRACKET SILENCER MTG-LH.	TATA spare parts

284649200125	ASSY. EXHAUST PIPE (C/M) CAB	TATA spare parts
284649200127	ASSY. EXHAUST 2ND PIPE	TATA spare parts
284649200128	ASSY. EXHAUST 3RD PIPE	TATA spare parts
284649200130	ASSY. 2ND EXHAUST PIPE	TATA spare parts
284649200131	ASSY. EXHAUST PIPE 3RD	TATA spare parts
284649200135	ASSY. EXHAUST 2ND PIPE	TATA spare parts
284649200141	EXHAUST PIPE ASSY SECOND	TATA spare parts
284649200142	ASSY. THIRD PIPE	TATA spare parts
284649200144	BRACKET ASSY (TAIL PIPE MOUNTING)	TATA spare parts
284649200145	BRACKET ASSY SILENCER MOUNTING	TATA spare parts
284649200157	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
284649200158	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
284649200159	BRACKET ASSY EXHAUST MTG	TATA spare parts
284649200160	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
284649200165	BRACKET ASSY EGP MTG	TATA spare parts
284649200166	BRACKET ASSY EGP MTG	TATA spare parts
284649200168	BRACKET ASSY	TATA spare parts
284649200169	BRACKET ASSY NOX SENSOR MTG	TATA spare parts
284649200170	BRACKET ASSY UREA TANK MTG LH	TATA spare parts
284649200171	BRACKET ASSY UREA TANK MTG RH	TATA spare parts
284649200172	STRAP ASSY UREA TANK MTG	TATA spare parts
284649200173	BRACKET ASSY UREA TANK & DOSING UNIT MTG	TATA spare parts
284649200175	PIPE ASSY T-CONNECTOR TO AIR OIL FILTER	TATA spare parts
284649200177	BRACKET ASSY UREA TANK MTG	TATA spare parts
284649200178	STRAP ASSY AUS TANK MTG	TATA spare parts
284649200179	PIPE ASSY AIR OIL FILTER TO DU	TATA spare parts
284649200180	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
284649203306	L-BRACKET & EXHAUST & SILENCER	TATA spare parts
284649203319	BRACKET TAIL PIPE MTG	TATA spare parts
284649203329	L-BRACKET EXHAUST MTG	TATA spare parts
284649206956	TAIL PIPE	TATA spare parts
284649207104	BRACKET (EXHAUST PIPE MTG)	TATA spare parts
284649207702	RUBBER PACKING UREA TANK	TATA spare parts
284649207703	RUBBER PACKING UREA TANK	TATA spare parts
284649207704	RUBBER PACKING UREA TANK	TATA spare parts
284649208201	EXHAUST CLAMP	TATA spare parts
284649208202	EXHAUST CLAMP	TATA spare parts
284649208203	L-CLAMP	TATA spare parts
284649208204	CLAMP SILENCER	TATA spare parts
284649208205	BRACKET(ON CM)	TATA spare parts
284649208207	BRACKET ( FOR SILENCER CLAMP MTG)	TATA spare parts
284649208226	L-CLAMP	TATA spare parts
284649208227	BRACKET ( ON ENGINE )	TATA spare parts
284649208228	EXHAUST CLAMP	TATA spare parts
284649208230	BRACKET(ON CM)	TATA spare parts
284649208244	ANGLED L-BRACKET	TATA spare parts
284649208253	CLAMP	TATA spare parts

284649208256	PROTECTIVE COVER DOSER UNIT	TATA spare parts
284649605304	HEAT SHIELD EGP INNER SHEET	TATA spare parts
284649605305	BEND HEAT SHIELD	TATA spare parts
284649605306	FLANGE HEAT SHIELD	TATA spare parts
284649605307	BEND HEAT SHIELD	TATA spare parts
284649605309	HEAT SHIELD SILENCER	TATA spare parts
284649605310	HEAT SHIELD STRAIGHT	TATA spare parts
284649605311	BEND HEAT SHIELD	TATA spare parts
284649990101	KIT-EXHAUST HEAT SHIELD	TATA spare parts
284649990102	KIT-HEAT SHIELD FOR SILENCER & EXH PIPE	TATA spare parts
284649995305	BEND HEAT SHIELD	TATA spare parts
284654100108	BATTERY SUPPORT BRACKET ASSY WITH MF	TATA spare parts
284654100114	BATTERY CABLE NEGATIVE	TATA spare parts
284654100115	BATTERY CABLE NEGATIVE	TATA spare parts
284654100116	BATTERY +VE CABLE ASSY	TATA spare parts
284654100117	BATTERY +VE CABLE ASSY	TATA spare parts
284654200102	INSTRUMENT CLUSTER(ELECT)	TATA spare parts
284654200103	INST.CLUSTER(ELECT)1:1.04	TATA spare parts
284654200104	ASSY BKT FOR DC-DC CONVER (10 AMPS)	TATA spare parts
284654209901	INSTRUMENT CLUSTER(1:0.88/FREQ.552)	TATA spare parts
284654209902	INSTRUMENT CLUSTER(ELECTRONIC)(1:0.88)	TATA spare parts
284654209903	INST.CLUSTER(ELECT)(1:0.88)	TATA spare parts
284654209908	ELE. S.M. WI. LCD ODO.M.24V (1 0.93)	TATA spare parts
284654209909	INST.CLUSTER (ELECT.) (0.93)	TATA spare parts
284654209910	INST.CLUSTER (ELECT.) (0.93)	TATA spare parts
284654209911	INST.CLUSTER (ELECT.) (0.93)	TATA spare parts
284654209912	INST.CLUSTER (ELECT.) (0.93)	TATA spare parts
284654209917	INST.CLUSTER (ELECT.)(0.93/0.70)WITH TWO	TATA spare parts
284654209919	ELECTR. SPEEDOMETER RATIO 0.93 2/24V	TATA spare parts
284654209921	ELECTR.SPEEDOMETER RATIO (0.93/0.70)24V	TATA spare parts
284654209923	DC TO DC CONVERTER 24/12V (10A)	TATA spare parts
284654440101	ASSY. MOTORIZED HEAD LAMP 24V LH BS2/3/4	TATA spare parts
284654440102	ASSY. MOTORIZED HEAD LAMP 24V RH BS2/3/4	TATA spare parts
284654440109	LAMP H/L(-1.8%)12VHLL W/O RIM 24V RHD-LH	TATA spare parts
284654440110	LAMP H/L(-1.8%)12VHLL W/O RIM 24V RHD-RH	TATA spare parts
284654440128	ASSY H/L W/BULB W/O RIM 24V LH RHD	TATA spare parts
284654440129	ASSY H/L W/BULB W/O RIM 24V RH RHD	TATA spare parts
284654441601	ASSY WARNING LAMP INDICATOR(LIFT AXLE)	TATA spare parts
284654501601	LIFT AXLE SW(UP & DOWN)	TATA spare parts
284654504901	SWITCH HEAVY MODE BS4	TATA spare parts
284654504903	SWITCH LIGHT MODE BS4	TATA spare parts
284654509901	SWITCH LIFT AXLE	TATA spare parts
284654600105	PIG TAIL PRESSURE SW(LIFT AXLE UP PR.LN)	TATA spare parts
284654600124	WIRING HARNESS ABS FRAME 4S4M	TATA spare parts
284654600125	WIRING HARNESS TAIL	TATA spare parts
284654600131	WIRING HARNESS ABS FRAME	TATA spare parts
284654600140	WIRING HARNESS ABS FRAME	TATA spare parts



284654600141	WIRING HARNESS ENGINE BS4	TATA spare parts
284654600142	WIRING HARNESS ENGINE	TATA spare parts
284654600143	WIRING HARNESS SCR UNIT	TATA spare parts
284654600148	WIRING HARNESS TAIL	TATA spare parts
284654600149	BATTERY CABLE +VE	TATA spare parts
284654600150	BATTERY CABLE +VE MEGA FUSE TO CUT OFF	TATA spare parts
284654600154	WIRING HARNESS MAIN	TATA spare parts
284654600182	WIRING HARNESS ABS SPLIT	TATA spare parts
284654600184	FUSE BOX COVER WITH PRINTING	TATA spare parts
284654600189	WIRING HARNESS ABS FRAME	TATA spare parts
284654600190	WIRING HARNESS ABS FRAME	TATA spare parts
284654600191	WIRING HARNESS ABS SPLIT	TATA spare parts
284654600192	WIRING HARNESS ABS SPLIT BS3/4	TATA spare parts
284654600194	WIRING HARNESS ABS FRAME	TATA spare parts
284654600197	WIRING HARNESS ABS FRAME	TATA spare parts
284654600198	WIRING HARNESS ABS FRAME	TATA spare parts
284654600199	WIRING HARNESS ABS FRAME	TATA spare parts
284654601699	W/H ENGINE LPT3118TC BSIII 24V COWL	TATA spare parts
284654603301	BRACKET CONNECTOR MTG	TATA spare parts
284654603302	BRACKET ASSY MAXIFUSE MTG	TATA spare parts
284654603303	BRACKET CONNECTOR MTG	TATA spare parts
284654603304	BRACKET CONNECTOR MTG	TATA spare parts
284654608207	BRACKET	TATA spare parts
284654608208	BRACKET	TATA spare parts
284654610145	WIRING HARNESS ASSY MAIN	TATA spare parts
284654610148	WIRING HARNESS ASSY MAIN	TATA spare parts
284654610149	WIRING HARNESS ASSY MAIN	TATA spare parts
284654611610	W/H ENGINE	TATA spare parts
284654611626	W/H PIGTAIL FOR LIFT AXLE BS6	TATA spare parts
284654611627	W/H PIGTAIL FOR LIFT AXLE	TATA spare parts
284654611661	WIRING HARNESS SCR UNIT	TATA spare parts
284654611675	WIRING HARNESS TAIL	TATA spare parts
284654611677	WIRING HARNESS ENGINE	TATA spare parts
284654611681	WIRING HARNESS TAIL	TATA spare parts
284654611682	WIRING HARNESS TAIL	TATA spare parts
284654611684	WIRING HARNESS TAIL	TATA spare parts
284654611692	WIRING HARNESS SCR UNIT	TATA spare parts
284654611693	WIRING HARNESS MAIN	TATA spare parts
284654620101	WIRING HARNESS MAIN	TATA spare parts
284654620102	WIRING HARNESS TAIL	TATA spare parts
284654620103	WIRING HARNESS INST.CONSOLE(LIFT AXLE T	TATA spare parts
284654620104	W/H MAIN(LPT3118TC BSII LIFTAXLE LP)	TATA spare parts
284654620105	W/H TAIL(LPT3118TC/52 LIFT LP BSII)	TATA spare parts
284654620106	PIGTAIL LOW AIR PR.SW-LIFT AXLE	TATA spare parts
284654620107	PIGTAIL HEADLAMP	TATA spare parts
284654620117	WIRING HARNESS PIGTAIL LIFT AXLE SW.	TATA spare parts
284654620119	W/H ENGINE LPT3118TC 24V BSIII COWL	TATA spare parts

284654620120	WIRING HARNESS TAIL	TATA spare parts
284654620121	W/H MAIN LPT3118TC BSIII 24V LP COWL ER	TATA spare parts
284654620123	WIRING HARNESS TAIL	TATA spare parts
284654620124	W/H MAIN LPT-3118TC ABS-TCAB	TATA spare parts
284654620133	W/H ENGINE LPT-3118TC TCAB	TATA spare parts
284654620144	WH TAIL LPT3118TC TILT CAB PARA LIFT 24V	TATA spare parts
284654620146	WH MAIN LPT3118TC BS-II LP FACE PARA LIF	TATA spare parts
284654620147	WH TAIL LPT3118TC BS-II LP FACE PARA LIF	TATA spare parts
284654620148	WIRING HARNESS TAIL PARA LIFT	TATA spare parts
284654620151	WH TAIL LPT 3118TC/56WB 24V TILT CAB ABS	TATA spare parts
284654620153	W/H STOP LT.SW LP SW & PR.TRANSDUCER	TATA spare parts
284654620161	W/H TAIL LPT3118TC52WB BS-III LP COWL 2	TATA spare parts
284654620162	W/H TAIL LPT3118TC 56WB BS-III LP COWL	TATA spare parts
284654620167	W/H MAIN - LPT3118/62 TC BSIII COW	TATA spare parts
284654620168	SUPPORT BRACKET (FOR INTERMEDIATE PIPE)	TATA spare parts
284654620169	W/H ENGINE - LPT3118/62 TC BSIII COW	TATA spare parts
284654620175	WIRING HARNESS ENGINE LPT 3118TC 24V TIL	TATA spare parts
284654620176	W/H ENGINE LPT3118TC 24V BSIII COWL WITH	TATA spare parts
284654620180	W/H MAIN LPT3118TC 24V CAB BSIII	TATA spare parts
284654620184	W/H TAIL LPT3118TC 52WB BS-III TLT CAB	TATA spare parts
284654620185	W/H TAIL LPT3118TC 56WB BS-III TLT CAB 2	TATA spare parts
284654620188	W/H INST CONSOLE	TATA spare parts
284654620195	W/H TAIL LPT3118TC BSIII 56WB CWL	TATA spare parts
284654620204	W/H ENGINE	TATA spare parts
284654620205	WIRING HARNESS ENGINE	TATA spare parts
284654630102	W/H TAIL LPT3118TC BSIII 52WB 24V COW	TATA spare parts
284654630103	W/H TAIL LPT3118TC BSIII 56WB 24V COWL	TATA spare parts
284654630107	W/H MAIN LPT3118TC	TATA spare parts
284654630110	W/H ENGINE	TATA spare parts
284654630114	WIRING HARNESS TAIL	TATA spare parts
284654630115	WIRING HARNESS TAIL	TATA spare parts
284654630117	W/H TAIL	TATA spare parts
284654630125	WIRING HARNESS TAIL	TATA spare parts
284654630128	WIRING HARNESS SCR UNIT BS4	TATA spare parts
284654630129	WIRING HARNESS MAIN BS4/6	TATA spare parts
284654630136	WIRING HARNESS ENGINE BS4	TATA spare parts
284654630138	WIRING HARNESS TAIL	TATA spare parts
284654660103	W/H MAIN(LPT3118TC BS-II L/AXLE LP)	TATA spare parts
284654660107	PIGTAIL HEADLAMP-LPT 3118 LPFACE	TATA spare parts
284654660117	W/H MAIN LPT3118TC BSIII 24V LP COWL 6X4	TATA spare parts
284654660119	W/H ENGINE LPT3118TC 24V BSIII COWL	TATA spare parts
284654660121	W/H MAIN LPT 3118TC LPFACE	TATA spare parts
284654660152	W/H STOP LT.SW LP SW & PR.TRANSDUCER -	TATA spare parts
284654660160	W/H TAIL LPT3118TC 52WB BS-III LP COWL 2	TATA spare parts
284654660174	W/H ENGINE LPT 3118TC 24V TILT CAB	TATA spare parts
284654660175	W/H ENGINE LPT3118TC 24 V	TATA spare parts
284654660190	W/H TAIL LPT3118TCBSIII56WB24VCOWL W/TWC	TATA spare parts

284654660193	W/H MAIN LPT3118TCBSIII24VCOWL WITH TWO	TATA spare parts
284654660194	W/H TAIL LPT3118TC BSIII 52WB CWL -TYA	TATA spare parts
284654660195	W/H TAIL LPT3118TC	TATA spare parts
284654660198	W/H MAIN LPT3118TC BSIII 24V LP COWL	TATA spare parts
284654670102	W/H TAIL LPT3118TC BSIII 52WB 24V COWL	TATA spare parts
284654670107	W/H MAIN LPT2518TC BSIII COWL 24V	TATA spare parts
284654670109	WIRING HARNESS MAIN	TATA spare parts
284654670110	W/H ENGINE LPT3118TC BSIII 24V COWL	TATA spare parts
284654670111	W/H MAIN LPT3118TC COWL TWIN SPEED	TATA spare parts
284654670116	WIRING HARNESS TAIL LPT3118TC/52	TATA spare parts
284654670117	LPT3118TC/56 BSIII COWL 24V LACV	TATA spare parts
284654670119	W/H PIGTAIL FOR LIFT AXLE	TATA spare parts
284654670120	W/H PIGTAIL FOR LIFT AXLE	TATA spare parts
284654670121	WIRING HARNESS TAIL	TATA spare parts
284654670122	W/H TAIL	TATA spare parts
284654690103	W/H ENGINE LPT3118TC 24V BSIII COWL	TATA spare parts
284654690105	W/H MAIN LPT3118TC	TATA spare parts
284654690108	W/H ENGINE	TATA spare parts
284654690109	W/H TAIL LPT3118TC BSIII 62WB 24V COWL	TATA spare parts
284654690110	W/H TAIL LPT3118TC BSIII 52WB 24V COWL	TATA spare parts
284654690111	W/H TAIL	TATA spare parts
284654700103	W/H ENGINE LPT3118TC 24V BSIII COWL	TATA spare parts
284654703301	BRACKET	TATA spare parts
284654709901	STICKER FUEL ECONOMY SWITCH CONTROLLER B	TATA spare parts
284670000101	KIT ASSY SUPD	TATA spare parts
284670108207	BRACKET LH (SUPD)	TATA spare parts
284670108208	RACKET RH (SUPD)	TATA spare parts
284670108209	BRACKET REAR (SUPD)	TATA spare parts
284682400101	WIPER MOTOR ASSY WITH BRACKET	TATA spare parts
284683300101	CONTROL PANEL ASSY	TATA spare parts
284683300104	CONTROL PANEL ASSY	TATA spare parts
284683301601	CONTROL PANEL ASSY	TATA spare parts
284683400101	AC UNIT ASSY	TATA spare parts
284683400103	BLOWER HSG ASSY	TATA spare parts
284683400106	WIRING HARNESS	TATA spare parts
284683400107	DRAIN NIPPLE	TATA spare parts
284683400108	ASSY. VENTILATION UNIT BS4	TATA spare parts
284683400109	BLOWER MOTOR	TATA spare parts
284683400110	BLOWER ASSY	TATA spare parts
284683400111	DRAIN HOSE ASSY	TATA spare parts
284683400112	THERMO AMPLIFIER	TATA spare parts
284683400114	EVAPORATOR ASSY	TATA spare parts
284683400115	WIRING HARNESS	TATA spare parts
284683400117	THERMISTER	TATA spare parts
284683400118	BLOWER MOTOR ASSY	TATA spare parts
284683400119	RELAY	TATA spare parts
284683400120	EVAPORATOR ASSY WITH HEAT CORE	TATA spare parts

284683400121	COOLING UNIT ASSY	TATA spare parts
284683400123	VENTILATION UNIT ASSY	TATA spare parts
284683400124	WIRING HARNESS BS6	TATA spare parts
284683403301	BRACKET RH	TATA spare parts
284683403303	BRACKET LH	TATA spare parts
284683405801	DRAIN HOSE	TATA spare parts
284683406301	COVER AC UNIT	TATA spare parts
284683406302	COVER AC UNIT	TATA spare parts
284683406310	COVER WATER PROTECTION	TATA spare parts
284683409901	STICKER-AC REFRIGERANT CHARGE QTY	TATA spare parts
284683409903	STICKER-AC REFRIGERANT CHARGE QTY	TATA spare parts
284683450102	CONDENSER UNIT ASSY	TATA spare parts
284683450106	DESICCANT BAG BS6	TATA spare parts
284683453601	FILTER ASSY BS6	TATA spare parts
284683457501	RUBBER SEALING BS6	TATA spare parts
284683457503	GROMMET BS6	TATA spare parts
284683457802	O-RING BS6	TATA spare parts
284683550101	COMPRESSOR ASSY	TATA spare parts
284683600101	SUCTION PIPE HVAC END	TATA spare parts
284683600102	SUCTION PIPE COMPRESSOR END	TATA spare parts
284683600103	DISCHARGE PIPE ASSY	TATA spare parts
284683600105	LIQUID PIPE CONDENSER END	TATA spare parts
284683600112	LIQUID PIPE HVAC END	TATA spare parts
284683600114	SUCTION PIPE HVAC END	TATA spare parts
284683600115	LIQUID PIPE HVAC END	TATA spare parts
284683600116	SUCTION PIPE HVAC END	TATA spare parts
284683600117	SUCTION PIPE COMPRESSOR END	TATA spare parts
284683600119	DISCHARGE PIPE CONDENSER END	TATA spare parts
284683600120	LIQUID PIPE CONDENSER END	TATA spare parts
284683600121	LIQUID PIPE HVAC END	TATA spare parts
284683707501	GROMMET DRAIN PIPE	TATA spare parts
284683750101	BRACKET ASSY AC PIPE MTG	TATA spare parts
284683750102	BRACKET ASSY AC PIPE MTG	TATA spare parts
284683750103	BRACKET ASSY AC PIPE MTG	TATA spare parts
284683990101	KIT-COVER FITMENT BS6	TATA spare parts
284749995306	FLANGE HEAT SHIELD	TATA spare parts
284829100102	ASSY CONTROL MOUNTING BRACKET	TATA spare parts
284829100122	ASSY. TUBE O.D. 6	TATA spare parts
284841110101	ASSY PROPELLER SHAFT FRONT	TATA spare parts
284841110102	FLANGE YOKE	TATA spare parts
284841110103	CROSS ASSY	TATA spare parts
284841110104	ASSY. CENTER BEARING BS1/2/3/4	TATA spare parts
284841110105	COUPLING FLANGE ASSY	TATA spare parts
284841110106	HEX NUT	TATA spare parts
284841110107	SHORT FORK TUBE AND FRONT END PIECE ASSY	TATA spare parts
284841120101	ASSY PROPELLER SHAFT REAR	TATA spare parts
284841120105	CROSS ASSY	TATA spare parts

284841120106	SUB ASSY. LONG FORK BS1/2/3/4	TATA spare parts
284841120107	SHORT FORK TUBE AND REAR HOUSING ASSY	TATA spare parts
284841303301	ASSY CENTER BEARING	TATA spare parts
284843900113	ASSY CHASSIS SET COMP	TATA spare parts
284849200102	ASSY. EXHAUST THIRD PIPE	TATA spare parts
284849995307	BEND HEAT SHIELD	TATA spare parts
284854200101	INST CLUST ELE SM (1:0.88)	TATA spare parts
284854209902	INST.CLUSTER(ELECT)(0.93)	TATA spare parts
284854209903	INST.CLUSTER(ELECT)(0.93)	TATA spare parts
284916100104	CONTAINER (ECU 697TC) LPT2518_BSIII	TATA spare parts
284916100107	CONTAINER (ECU 697TCIC BSIII)	TATA spare parts
284924200101	ASSY.BRACKET-RH. ENGINE MTG.REAR	TATA spare parts
284924200102	ASSY.BRACKET-LH-ENGINE MTG.REAR	TATA spare parts
284924200103	ASSY. BRACKET-RH (ENGINE MTG. REAR)	TATA spare parts
284924200104	ASSY. BRACKET-LH(ENGINE MTG. REAR)	TATA spare parts
284924200107	ASSY BKT-LH(ENG MTG REAR TOP)	TATA spare parts
284924200108	ASSY BKT -RH(ENG MTG REAR TOP)	TATA spare parts
284926800105	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
284926810101	ASSY BRACKET (G.S.L.MTG.)2518 BS3 TILT.	TATA spare parts
284926810102	ASSY SUPPORT TUBE(LPT2518 BS3 TILT)	TATA spare parts
284926810103	ASSY BRACKET (G.S.LEVER MTG.)	TATA spare parts
284926810104	ASSY SUPPORT TUBE	TATA spare parts
284929100105	ASSY. CLUTCH PEDAL COMPLETE	TATA spare parts
284929100108	ASSY.CONTROL MTG.BRACKET WITH TUBE	TATA spare parts
284930100101	ASSY BRACKET (ELECTRONIC ACCL.PEDAL MTG)	TATA spare parts
284930100107	ASSY BKT-ACCE PEDAL MTG	TATA spare parts
284931000101	ASSY.FRAME LPT 2515 W 697 BS-II W/O FUPD	TATA spare parts
284931000102	ASSY. FRAME LPT 2518 697TC E3 TILTCAB	TATA spare parts
284931000103	ASSY FRAME LB MTG CLEAT LPT2515-697BS2	TATA spare parts
284931107105	REINFORCEMENT-RH	TATA spare parts
284931107106	REINFORCEMENT-LH	TATA spare parts
284931200102	ASSY.ENGINE CROSS MEMBER (REAR)	TATA spare parts
284931200103	ASSY SUPPORT RH - ENG CM FRONT	TATA spare parts
284931200104	ASSY. SUPPORT-LH FRONT ENG. CROSS MEM.	TATA spare parts
284931200107	ASSY. RADIATOR MTG. BKT.-RH(COMPLETE)	TATA spare parts
284931200108	ASSY. RADIATOR MTG. BKT-LH(COMPLETE)	TATA spare parts
284931200118	GUSSET LH (TC)	TATA spare parts
284931200119	GUSSET RH (TC)	TATA spare parts
284931200120	ASSY BUMPER CROSS MEMBER COMPLETE.	TATA spare parts
284931200121	ASSY EXTENSION GUSSET- RH	TATA spare parts
284931200122	ASSY EXTENSION GUSSET- LH	TATA spare parts
284931200124	ASSY BUMPER CROSS MEMBER	TATA spare parts
284931200127	ASSLY. GUSSET WITH REINFORCEMENT - LH (T	TATA spare parts
284931200128	ASSY GUSSET WITH REINFORCEMENT-RH(TC)	TATA spare parts
284931200132	ASSY. GUSSET REINFORCEMENT-LH (TC)	TATA spare parts
284931200133	ASSY. GUSSET REINFORCEMENT-RH (TC)	TATA spare parts
284931300116	REINFORCEMENT RH	TATA spare parts

284931300117	REINFORCEMENT LH	TATA spare parts
284931700103	ASSY.TRANS.SHIELD FRT SIDE(LPT2515CMVR)	TATA spare parts
284931700104	ASSY. TRANS.SHIELD REAR SIDE(LPT2515CMVR	TATA spare parts
284931700105	ASSY. SUPPORT BKT(TRANS. SHIELD FRT.)	TATA spare parts
284931700107	ASSY BOTTOM SHIELD(RAD SIDE)LPT1615BS-3	TATA spare parts
284931700115	ASSY FUPD CROSS BEAM COMPLETE	TATA spare parts
284931700118	FUPD BRACKET ASSY. COMPLETE - RH	TATA spare parts
284931700119	FUPD BRACKET ASSY COMPLETE - LH	TATA spare parts
284931700132	ASSY. FUPD CROSS BEAM BS1/2/3/4	TATA spare parts
284931700133	FUPD BRACKET ASSY COMPLETE-RH	TATA spare parts
284931700134	FUPD BRACKET ASSY COMPLETE-LH	TATA spare parts
284931700135	FUPD SIDE SUPPORT ASSY-RH	TATA spare parts
284931700136	FUPD SIDE SUPPORT ASSY-LH	TATA spare parts
284931700140	ASSY. FUPD KIT COMPLETE	TATA spare parts
284931700142	FUPD BRACKET ASSY COMPLETE-RH	TATA spare parts
284931700143	FUPD BRACKET ASSY COMPLETE-LH	TATA spare parts
284931700144	FUPD SIDE SUPPORT ASSY-RH	TATA spare parts
284931700145	FUPS SIDE SUPPORT ASSY-LH	TATA spare parts
284931707147	BEADING BS6	TATA spare parts
284933000104	ASSY. FRONT AXLE COMP. WITH BRAKES	TATA spare parts
284933000106	ASSY.F. A COMP(WT FAB 840CD)LPT2518 62WB	TATA spare parts
284933000113	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
284933105101	FA BEAM 7.5T 6.5DEG FOR 888 FRAME	TATA spare parts
284933105102	FA BEAM 7.5T6.5 LPT2518 62WB (CD840MM)	TATA spare parts
284933105103	FRONT AXLE BEAM NORMAL BS3	TATA spare parts
284933105105	SPIGOT	TATA spare parts
284933105106	FRONT AXLE BEAM	TATA spare parts
284933105108	FRONT AXLE BEAM W/SPIGOT LOCATION BS3/4	TATA spare parts
284933105109	FRONT AXLE BEAM	TATA spare parts
284933200113	ASSY.STUBAXLE FOR AL.BRONZE BUSHES	TATA spare parts
284933400108	FRONT HUB ASSY WITH BEARING BS6	TATA spare parts
284933400110	ASSY TAPER ROLLER BRG	TATA spare parts
284933400112	FRONT HUB ASSY WITH POLE WHEEL BS6	TATA spare parts
284933403701	COVER FRONT HUB	TATA spare parts
284933405301	HUB COVER GASKET-FRT WHEEL	TATA spare parts
284933405504	WHEEL HUB FRONT SPIGOTTED(THU1)	TATA spare parts
284933406501	BRG NUT FRT HUB	TATA spare parts
284933409201	THRUST WASHER	TATA spare parts
284933409202	LOCK WASHER BRG NUT	TATA spare parts
284941100101	ASSY PROP. SHAFT. FRONT	TATA spare parts
284941100102	ASSY PROP. SHAFT. FRONT	TATA spare parts
284941100104	ASSY PROPSHAFT FRONT	TATA spare parts
284941100105	ASSY PROPR SHAFT KIT	TATA spare parts
284941100109	ASSY PROP SHAFT FRONT (150 SER)	TATA spare parts
284941120102	ASSY PROP SHAFT REAR	TATA spare parts
284941120103	ASSY PROP SHAFT REAR (150 SER)	TATA spare parts
284941303301	SPACER (CENTER BEARING MTG BKT)	TATA spare parts

284943700110	DUAL TREADLE VALVE VOSS BSIII	TATA spare parts
284943700115	MODULATOR VALVE(VOSS) 24V BS1/3/4	TATA spare parts
284943700115AE	MODULATOR VALVE(VOSS)24V 1628	TATA spare parts
284943700116	MODULATOR VALVE(VOSS)24V-REAR	TATA spare parts
284943700121	MODULATOR VALVE(VOS+MET) 24V BS2/3/4	TATA spare parts
284943700122	SOLENOID MODULATOR VALVE BS1/2/3/4	TATA spare parts
284943700122AE	MODULATOR VLVE (VOSS+MET)-1828	TATA spare parts
284943900105	ASSY.NYLON PIPE SET FOR CHASSIS-LPT2518	TATA spare parts
284943900114	ASSY.PIPE-SECOND PIPE FROM COMPR. TO DDU	TATA spare parts
284943900115	ASSY.PIPE-THIRD PIPE FROM COMPR. TO DDU	TATA spare parts
284943900116	ASSY.METAL PIPE WITH CRIMPED HOSE-2518	TATA spare parts
284943906801	COUPLING BODY(MODULATOR VALVE INLT PORT)	TATA spare parts
284946000113	ASSY. DRAG LINK BS3/4	TATA spare parts
284946103301	STEERING GB MTG BKT CASTING	TATA spare parts
284946106301	RUBBER BELLOWS	TATA spare parts
284946108201	CLAMPING RING	TATA spare parts
284946200101	ASSY STEERING SPINDLE	TATA spare parts
284946207902	STEERING SLEEVE	TATA spare parts
284946207904	STEERING SLEEVE	TATA spare parts
284947100121	ASSY.FUEL TANK WITH 5 BAFFLE	TATA spare parts
284947104202	CLAMP (FUEL FEED PUMP MTG)	TATA spare parts
284947108201	BRACKET (FUEL FEED PUMP MTG)	TATA spare parts
284947600101	ASSY.SUCTION LINE. (10 OD PIPE	TATA spare parts
284947600102	ASSY.SUCTION LINE. (10 OD PIPE)	TATA spare parts
284947600103	ASSY.SUCTION LINE. (10 OD PIPE)	TATA spare parts
284947600106	ASSY.RETURN LINE. (10 OD PIPE)	TATA spare parts
284947600122	ASSY SUCTION FUEL-LINE-1	TATA spare parts
284947600124	ASSY SUCTION FUEL-LINE-2	TATA spare parts
284947606903	PIPE 10 O.D. X 0.7 THK.SS:4040-20	TATA spare parts
284947608201	BRACKET-WATER SEPARATOR MTG	TATA spare parts
284949100101	ASSY. MUFFLER	TATA spare parts
284949100104	ASSLY SILENCER WITH TAIL PIPE	TATA spare parts
284949200101	ASSY.FIRST PIPE	TATA spare parts
284949200103	ASSY. FIRST PIPE (ELBOW)	TATA spare parts
284949200105	ASSY. INTERMEDIATE PIECE	TATA spare parts
284949200109	ASSY. BKT. (SILENCER SUPPORT)	TATA spare parts
284949200110	ASSY. BRACKET (EXHAUST MTG.)	TATA spare parts
284949200113	ASSLY.BRACKET(EXHAUST MTG.)	TATA spare parts
284949200114	ASSY. EXHAUST SECOND PIPE	TATA spare parts
284949208213	CLAMP(SILENCER)	TATA spare parts
284949208214	CLAMP	TATA spare parts
284949208218	SUPPORT BKT.(SILENCER)	TATA spare parts
284949208219	SUPPORT BKT.(TAIL PIPE)	TATA spare parts
284949208223	BRACKET	TATA spare parts
284949995309	HEAT SHIELD SILENCER	TATA spare parts
284954100103	ASSY.SUPPORT (FOR 100AH)	TATA spare parts
284954100105	ASSY BATTERY CABLE (LINK) 180 LG	TATA spare parts

284954108203	CLAMP TOP (BATTERY CLAMPING)	TATA spare parts
284954200101	ASSY BRACKET(DC-DC 18/10 AMPS CONV.MTG.)	TATA spare parts
284954200105	ELECTRONIC CONTROL UNIT 24V ABS-E	TATA spare parts
284954200105AE	ELECTR CNTRL UNIT;24V-1628-1828	TATA spare parts
284954201606	INST CLUST (ELECT)(1:0.93)	TATA spare parts
284954209902	INSTRUMENT CLUSTER 1:0.88	TATA spare parts
284954209904	RPM METER 24V 420 HTZ	TATA spare parts
284954209907	INST.CLUSTER (1:1.04)(LPT2518BS-3)	TATA spare parts
284954209909	DC-DC CONVERTER(20Amp)	TATA spare parts
284954209910	DC TO DC CONVERTER BS2/3/4	TATA spare parts
284954209914	INST.CLUSTER(ELECT)(1:0.88)	TATA spare parts
284954209916	INST.CLUSTER(ELECT)(1:0.88)	TATA spare parts
284954209917	INST.CLUSTER(ELECT)(1:1.04)	TATA spare parts
284954209918	INST.CLUSTER(ELECT)(1:0.88)	TATA spare parts
284954209919	INST.CLUSTER(ELECT)(1:0.88)	TATA spare parts
284954209920	INST.CLUSTER(ELECT)(1:0.88)	TATA spare parts
284954209922	INSTRUMENT CLUSTER(ELECT) (1:0.88)	TATA spare parts
284954209923	INST.CLUSTER(ELECT)(1:0.88)	TATA spare parts
284954209925	INST CLUST (ELECT)(1:0.93)	TATA spare parts
284954209926	INST CLUST (ELECT)(1:0.93)	TATA spare parts
284954209931	24V DC-12V DC CONVERTER (20AMPS)	TATA spare parts
284954209946	ELECTR. SPEEDOMETER RATIO 1.04 12/24V-M	TATA spare parts
284954209947	ELECTR. SPEEDOMETER RATIO 0.72 12/24V-M	TATA spare parts
284954209948	ELECTR. SPEEDOMETER RATIO 0.80 12/24V-M	TATA spare parts
284954209949	ELECTR. SPEEDOMETER RATIO 0.88 12/24V-M	TATA spare parts
284954209950	ELECTR. SPEEDOMETER RATIO 0.93 12/24V-M	TATA spare parts
284954209951	ELECT. SPEEDOMETER RATIO 0.98 12/24V	TATA spare parts
284954209952	ELECTR. SPEEDOMETER RATIO 0.88 12/24V	TATA spare parts
284954209953	ELECT. SPEEDOMETER RATIO 0.93 12/24V	TATA spare parts
284954209954	RPM METER(12V 438HZ)	TATA spare parts
284954209955	RPM METER(24V 438HZ)	TATA spare parts
284954209958	R.P.M.METER 24V	TATA spare parts
284954219901	DC-DC CONVERTER 24 / 12 V - 18 AMP	TATA spare parts
284954440101	ASSY WARNING LAMP IND (24V)	TATA spare parts
284954441601	ASSY. WARNING LAMP (24V)	TATA spare parts
284954601603	W/H TAIL LPT-2518/48 697 24V	TATA spare parts
284954601624	W/H MAIN LPT 1615/2518 697-BSIIICOWL	TATA spare parts
284954620119	WIRING HARNESS TAIL	TATA spare parts
284954620122	W/H MAIN(LPT2518-697 BS-IIICAB ABS)	TATA spare parts
284954620123	W/H TAIL LPT1615/52 697 BSIII TILT CAB	TATA spare parts
284954620124	W/H TAIL LPT1615/48 697 BSIII TILT CAB-M	TATA spare parts
284954620126	W/H MAIN LPT1615/2518697BSIIICOWL	TATA spare parts
284954620130	WIRING HARNESS STOP LT.SW & PR.TRANSDUC	TATA spare parts
284954620149	W/H SENSOR LPT1613 697 BSIII TILT CAB	TATA spare parts
284954660101	W/H MAIN (LPT2518 697 BS-III)	TATA spare parts
284954660110	W/H INST.CONSOLE(LPT2518 III CAB 697)	TATA spare parts
284954660131	WH MAIN LPT1615/2518 697 BSIII COWL VEH	TATA spare parts



284954660135	W/H STOP LT.SW PR.TRANSDUCER	TATA spare parts
284954660138	W/H MAIN LPT1615/2518 697 24V	TATA spare parts
284954660152	WIRING HARNESS MAIN	TATA spare parts
284954660154	W/H SENSOR LPT1613 697 BSIII TILT CAB	TATA spare parts
285035000101	DANA R.A.COMP 5.143 W/BRAKES.	TATA spare parts
285035000104	R.A.COMP 5.143 W/BRAKES.	TATA spare parts
285035000107	ACE REAR AXLE WITH 4.88 RATIO	TATA spare parts
285035000108	DANA RA 4.43(31/7) RATIO FOR PEOPLE CARR	TATA spare parts
285035000109	REAR AXLE4.88 (44/9) FOR PEOPLE CARRIER-	TATA spare parts
285035000111	REAR AXLE ASSY 4.1 (41/10) RATIO FOR A	TATA spare parts
285035000112	BANJO REAR AXLE WITH 4.44 (40/9) RATIO F	TATA spare parts
285035000113	BANJO REAR AXLE WITH 4.88 (44/9) RATIO F	TATA spare parts
285035000116	BANJO REAR AXLE ASSY WITH 4.1 (41/10) RA	TATA spare parts
285035000123	AAM BANJO RA WITH 411 (37/9) RATIO FOR	TATA spare parts
285035000124	AXLE ASM REAR 5.9IN 4.88 STD	TATA spare parts
285035000131	REAR AXLE	TATA spare parts
285035000135	BANJO REAR AXLE WITH 5.14 (36/7) RATIO F	TATA spare parts
285035000145	ASSY AAM RA WITH 4.88(44/9) RATIO FOR 80	TATA spare parts
285035000147	RA 4.88 RATIO W/254 DIA BRK FOR SUPERACE	TATA spare parts
285035000150	SERV KIT RING AND PINION	TATA spare parts
285035000151	SERV KIT THRUST WASHER	TATA spare parts
285035000153	ASSY REAR AXLE SALISBURY 4.1 RATIO W/254	TATA spare parts
285035000159	BANJO REAR AXLE ASSY - RATIO 4.11 (37/9)	TATA spare parts
285035000166	ASSY REAR AXLE WITH 4.88 RATIO FOR ACE 8	TATA spare parts
285035000167	ASSY BANJO REAR AXLE WITH 4.44(40/9) RAT	TATA spare parts
285035000175	BANJO REAR AXLE ASSY - RATIO 5.143 (36/7	TATA spare parts
285035000179	REAR AXLE ASSY WITH DRUM BRAKE	TATA spare parts
285035000181	REAR AXLE ASSY WITH DRUM BRAKE	TATA spare parts
285035000187	REAR AXLE ASSY 40/9 RAT MAGIC CLOSED V	TATA spare parts
285035000191	REAR AXLE ASSY LCRV (RATIO 4.43)	TATA spare parts
285035000192	REAR AXLE ASSY	TATA spare parts
285035000193	REAR AXLE ASSY	TATA spare parts
285035000195	REAR AXLE ASSY W/O WHEEL END TWIN SPEED	TATA spare parts
285035000196	REAR AXLE ASSY	TATA spare parts
285035000197	REAR AXLE ASSY	TATA spare parts
285035000211	REAR AXLE ASSY WITH BRAKE	TATA spare parts
285035000212	REAR AXLE ASSY WITH BRAKE	TATA spare parts
285035000214	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
285035000215	REAR AXLE ASSY WITH BRAKE	TATA spare parts
285035000216	REAR AXLE ASSY WITH BRAKE	TATA spare parts
285035000220	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
285035000221	REAR AXLE ASSY ABS	TATA spare parts
285035000222	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
285035000223	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
285035000224	AXLE ASSY WITH BRAKE BS6	TATA spare parts
285035000229	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
285035000230	REAR AXLE ASSY WITH BRAKE	TATA spare parts

285035000231	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
285035000234	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
285035000235	AXLE ASSY WITH BRAKE BS6	TATA spare parts
285035000236	REAR AXLE ASSY WITH BRAKE ACE EV	TATA spare parts
285035000238	REAR AXLE ASSY WITH BRAKE BS6-PH2	TATA spare parts
285035000239	AXLE ASSY WITH BRAKE BS6	TATA spare parts
285035000240	REAR AXLE ASSY BS6	TATA spare parts
285035000241	REAR AXLE ASSY WITH BRAKE BS6-PH2	TATA spare parts
285035000246	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
285035000247	REAR AXLE ASSY W+I791 I828ITH BRAKE BS6-	TATA spare parts
285035007703	PINION OIL SEAL	TATA spare parts
285035010128	AXLE BEAM ASSY	TATA spare parts
285035010129	AXLE BRAM ASSY	TATA spare parts
285035100101	BEAM ASSEMBLY	TATA spare parts
285035100103	BEAM ASSY.	TATA spare parts
285035100105	HOUSING & COVER ASSY ĩ BANJO	TATA spare parts
285035100106	COMPANION FLANGE ASSY	TATA spare parts
285035100108	BANJO BEAM ASM	TATA spare parts
285035100109	CARRIER ASM CAPS AND	TATA spare parts
285035100110	BREATHER ASSY	TATA spare parts
285035100111	BANJO BEAM ASSY	TATA spare parts
285035100112	CARRIER ASSEMBLY	TATA spare parts
285035100116	BEAM ASSY	TATA spare parts
285035100117	COMPANION FLANGE ASSY 1310	TATA spare parts
285035100118	HOUSING & COVER ASSY - BANJO	TATA spare parts
285035100119	BANJO BEAM ASSY	TATA spare parts
285035100120	CARRIER ASM	TATA spare parts
285035100121	COM. FLANGE ASSY	TATA spare parts
285035100128	BANJO HOUSING	TATA spare parts
285035100130	AXLE ASSY - PARTIAL REAR (BEAM ASSY)	TATA spare parts
285035100133	HOSE ASSEMBLY BREATHER	TATA spare parts
285035100137	HOUSING WITH COVER ASSY	TATA spare parts
285035100141	REAR AXLE BEAM ASSY	TATA spare parts
285035100142	HOUSING WITH COVER ASSY	TATA spare parts
285035100143	AXLE BEAM ASSY BS6	TATA spare parts
285035100151	HOUSING WITH COVER ASSY	TATA spare parts
285035100152	HOUSINGWITHCOVERASSY BS6	TATA spare parts
285035100154	HOUSING WITH COVER ASSY	TATA spare parts
285035100155	HOUSING WITH COVER ASSY	TATA spare parts
285035100156	AXLE BEAM ASSY	TATA spare parts
285035100157	HOUSING WITH COVER ASSY BS6	TATA spare parts
285035100158	COMPANION FLANGE DEFLECTOR ASSY	TATA spare parts
285035100160	HOUSING WITH COVER ASSY BS6	TATA spare parts
285035100161	BANJO HOUSING AND COVER ASSY (10117726)	TATA spare parts
285035100162	BRACKET ASSY	TATA spare parts
285035100164	REAR AXLE BEAM ASSY BS6	TATA spare parts
285035100165	HOUSING WITH COVER ASSY (RA BEAM) BS6	TATA spare parts

285035100167	HOUSING WITH COVER ASSY BS6	TATA spare parts
285035100168	HOUSING WITH COVER ASSY	TATA spare parts
285035100169	AXLE BEAM ASSY ACE EV	TATA spare parts
285035100171	HOUSING WITH COVER ASSY BS6	TATA spare parts
285035100172	REAR AXLE BEAM ASSY BS6	TATA spare parts
285035100174	HOUSING WITH COVER ASSY BS6-PH2	TATA spare parts
285035100176	HOUSING WITH COVER ASSY BS6-PH2	TATA spare parts
285035107201	DRAIN PLUG	TATA spare parts
285035107202	DRAIN PLUG	TATA spare parts
285035107203	FILLER PLUG	TATA spare parts
285035107205	PLUG BREATHER HOLE BS6	TATA spare parts
285035107206	PLUG BREATHER HOLE BS6	TATA spare parts
285035108201	COVER CARRIER	TATA spare parts
285035108203	RATIO TAG	TATA spare parts
285035108205	COVER-CARRIER FIN	TATA spare parts
285035108209	REMOTE BREATHER MTG BRACKET LOWER	TATA spare parts
285035110101	CARRIER SUB ASSLY	TATA spare parts
285035110102	CARRIER ASSLY-4.44	TATA spare parts
285035110103	CARRIER ASSLY-4.88	TATA spare parts
285035110104	CARRIER ASSY	TATA spare parts
285035110107	CARRIER SUB ASSY	TATA spare parts
285035110111	CARRIERSUBASSY	TATA spare parts
285035110112	CARRIER ASSY	TATA spare parts
285035110113	CARRIERASSY	TATA spare parts
285035110121	CARRIER ASSY BS6	TATA spare parts
285035110124	CARRIER SUB ASSY	TATA spare parts
285035113201	HEX BOLT BRG CAP(P-BLOCK COVER)	TATA spare parts
285035113202	BOLT M8X1.25	TATA spare parts
285035113203	BOLT M10 X 1.5	TATA spare parts
285035113204	BOLT HEX	TATA spare parts
285035113701	CARRIER - FIN	TATA spare parts
285035113703	CASE DIFFERENTIAL (MACH)	TATA spare parts
285035113704	CASE DIFFERENTIAL	TATA spare parts
285035113706	COVER-CARRIER FIN	TATA spare parts
285035116501	NUT M8	TATA spare parts
285035118203	CAP - DIFF BRG FIN	TATA spare parts
285035118301	SHIM PINION HEAD (1.460)	TATA spare parts
285035118302	SHIM PINION HEAD (1.485)	TATA spare parts
285035118303	SHIM PINION HEAD (1.510)	TATA spare parts
285035118304	SHIM PINION HEAD (1.535)	TATA spare parts
285035118305	SHIM PINION HEAD (1.560)	TATA spare parts
285035118306	SHIM PINION HEAD (1.585)	TATA spare parts
285035118307	SHIM PINION HEAD (1.610)	TATA spare parts
285035118308	SHIM PINION HEAD (1.635)	TATA spare parts
285035118309	SHIM PINION HEAD (1.660)	TATA spare parts
285035118310	SHIM PINION HEAD (1.685)	TATA spare parts
285035118311	SHIM PINION HEAD (1.710)	TATA spare parts

285035118312	SHIM PINION HEAD (1.735)	TATA spare parts
285035118313	SHIM PINION HEAD (1.760)	TATA spare parts
285035118314	SHIM PINION HEAD (1.785)	TATA spare parts
285035118315	SHIM PINION HEAD (1.810)	TATA spare parts
285035118316	SHIM PINION HEAD (1.835)	TATA spare parts
285035118317	SHIM PINION HEAD (1.860)	TATA spare parts
285035118318	SHIM PINION HEAD (1.885)	TATA spare parts
285035118319	SHIM PINION HEAD (1.910)	TATA spare parts
285035118320	SHIM PINION HEAD (1.935)	TATA spare parts
285035118321	SHIM PINION HEAD(1.710)	TATA spare parts
285035118322	SHIM PINION HEAD(1.460)	TATA spare parts
285035118323	SHIM PINION HEAD(1.485)	TATA spare parts
285035118324	SHIM PINION HEAD(1.510)	TATA spare parts
285035118325	SHIM PINION HEAD(1.535)	TATA spare parts
285035118326	SHIM PINION HEAD(1.560)	TATA spare parts
285035118327	SHIM PINION HEAD(1.585)	TATA spare parts
285035118328	SHIM PINION HEAD(1.610)	TATA spare parts
285035118329	SHIM PINION HEAD(1.635)	TATA spare parts
285035118330	SHIM PINION HEAD(1.660)	TATA spare parts
285035118331	SHIM PINION HEAD(1.685)	TATA spare parts
285035118332	SHIM PINION HEAD(1.735)	TATA spare parts
285035118333	SHIM PINION HEAD(1.760)	TATA spare parts
285035118334	SHIM PINION HEAD(1.785)	TATA spare parts
285035118335	SHIMS PINION HEAD	TATA spare parts
285035118336	SHIM PINION HEAD(1.835)	TATA spare parts
285035118337	SHIM PINION HEAD(1.860)	TATA spare parts
285035118338	SHIM PINION HEAD(1.885)	TATA spare parts
285035118339	SHIM PINION HEAD(1.910)	TATA spare parts
285035118340	SHIM PINION HEAD(1.935)	TATA spare parts
285035118601	SPACER PINION BEARING	TATA spare parts
285035118602	SPACER PINION BEARING	TATA spare parts
285035118801	STUD M8	TATA spare parts
285035118802	STUD M8 X 1.25 X 48	TATA spare parts
285035119201	WASHER FLAT	TATA spare parts
285035150101	BREATHER	TATA spare parts
285035150102	BREATHER	TATA spare parts
285035150104	BREATHER BS6	TATA spare parts
285035158604	SPACER-COLLAPSIBLE	TATA spare parts
285035300102	DIFFERENTIAL CASE ASSY-STD	TATA spare parts
285035300105	PINION OIL SEAL KIT	TATA spare parts
285035300106	RING GEAR LOCK STRAP KIT	TATA spare parts
285035300107	ACE HYPOID GEAR KIT (4.42- 31/7)	TATA spare parts
285035300108	DIFF CASE THRUST WASHER KIT	TATA spare parts
285035300109	DIFF CASE KIT (MAJOR)	TATA spare parts
285035300110	ACE HYPOID GEAR SET(4.42 - 31/7)	TATA spare parts
285035300110DF	CROWN PINION SET 31/7-4.42 RATIO - ACE	TATA spare parts
285035300114	ACE HYPOID GEAR SET (4.88 - 44/9)	TATA spare parts

285035300114DF	CROWN PINION SET-44/9-4.88 RATIO - ACE	TATA spare parts
285035300115	ACE HYPOID GEAR KIT (4.88 - 44/9)	TATA spare parts
285035300115DF	CROWN PINION SET-44/9 THICK-4.88R-ACE	TATA spare parts
285035300117	ACE HYPOID GEAR SET (4.44 - 40/9)	TATA spare parts
285035300118	ASSY. DIFFERENTIAL CASE-STD BS2/3/4/6	TATA spare parts
285035300119	ACE HYPOID GEAR SET (BANJO- 44/9)	TATA spare parts
285035300120	KIT-SEAL	TATA spare parts
285035300121	KIT-DRIVE GEAR & PINION ASSY	TATA spare parts
285035300121DF	CROWN PINION SET-40/9-4.44-ACE/MAGIC CNG	TATA spare parts
285035300122	KIT-DRIVE GEAR & PINION ASSY	TATA spare parts
285035300123	KIT-DIFF CASE INNER PARTS STD	TATA spare parts
285035300124	KIT-DIFF CASE STD BS2/3/4/6	TATA spare parts
285035300125	RETAINER OIL SEAL ASSY	TATA spare parts
285035300126	GEAR AND PINION ASSY ĩ HYPOID	TATA spare parts
285035300129	CASE ASSY ĩ DIFF STD (1 PIECE)	TATA spare parts
285035300131	RETAINER ASSY ĩ OIL SEAL	TATA spare parts
285035300132	KIT-SEAL	TATA spare parts
285035300133	KIT- DIFF CASE INNNER PARTS STD	TATA spare parts
285035300134	KIT- DIFF CASE STD	TATA spare parts
285035300135	GEAR SET W SMALL PARTS- SERVICE (4.10)	TATA spare parts
285035300136	PKG-SCREW	TATA spare parts
285035300137	CROWN WHEEL PINION SET (5.143-36/07)	TATA spare parts
285035300138	CROWNWHEEL - PINION KIT (5.143)	TATA spare parts
285035300139	ACE HYPOID GEAR SET (4.88-39/08) 2010188	TATA spare parts
285035300140	CROWN WHEEL/PINION KIT 4.88 (39/08) 2010	TATA spare parts
285035300140DF	CROWN PINION SET-39/8 THIN-4.88-ACE	TATA spare parts
285035300142	CROWN WHEEL/PINION KIT 4.88 (39/08) 2013	TATA spare parts
285035300143	ASSY. CROWN & PINION (4.88) BS2/3/4	TATA spare parts
285035300143DF	CROWN PINION SET-44/9-4.88-LONG-ACE	TATA spare parts
285035300144	BEARING ASM TAPERED TAIL	TATA spare parts
285035300145	SEAL ASM PINION	TATA spare parts
285035300146	FLANGE ASM DEFLECTOR AND	TATA spare parts
285035300147	BEARING ASM TAPERED DIFF	TATA spare parts
285035300148	BEARING ASM TAPERED HEAD	TATA spare parts
285035300149	SERV KIT SEAL (PINION SEAL)	TATA spare parts
285035300150	SERV KIT RING AND PINION	TATA spare parts
285035300151	SERV KIT THRUST WASHER	TATA spare parts
285035300152	KIT-DIFF CASE (40081348) BS2/3/4	TATA spare parts
285035300153	SERV KIT BEARING (DGBB)	TATA spare parts
285035300154	SERV KIT SEAL (OUTBOARD SEAL)	TATA spare parts
285035300155	SERV KIT AXLE SHAFT	TATA spare parts
285035300156	CROWN WHEEL PINION SET 4.11 (37/9)	TATA spare parts
285035300157	BEARING ASSY TAPPERED HEAD	TATA spare parts
285035300158	COUPLING FLANGE ASSY	TATA spare parts
285035300159	KIT SEAL (PINION SEAL)	TATA spare parts
285035300160	KIT RING AND PINION	TATA spare parts
285035300161	KIT THRUST WASHER	TATA spare parts

285035300162	KIT DIFF CASE	TATA spare parts
285035300163	KIT BEARING (DGBB)	TATA spare parts
285035300164	KIT SEAL (OUTBOARD SEAL)	TATA spare parts
285035300165	KIT AXLE SHAFT	TATA spare parts
285035300166	ASSY. CWN & PINION HYP DRIV(5.14)BS2/3/4	TATA spare parts
285035300167	CROWN WHEEL/ PINION KIT 5.14	TATA spare parts
285035300168	GEAR AND PINION ASSY - HYPOID DRIVE (4.1	TATA spare parts
285035300169	CASE ASSY - DIFF STD (1 PIECE)	TATA spare parts
285035300170	COMPANION FLANGE ASSY	TATA spare parts
285035300172	KIT SEAL	TATA spare parts
285035300174	KIT-BEARING BS1/3/4	TATA spare parts
285035300176	KIT-DIFF CASE INNER PARTS STD	TATA spare parts
285035300177	KIT-DIFF CASE ASSY STD	TATA spare parts
285035300178	GEAR & PINION ASSY-HYPOID	TATA spare parts
285035300179	CASE ASSY - DIFF STD (1 PIECE)	TATA spare parts
285035300180	GEAR SET W SMALL PART 4.44	TATA spare parts
285035300182	BEARING ASM TAPERED HEAD	TATA spare parts
285035300183	BEARING ASM BALL	TATA spare parts
285035300184	SERV KIT SEAL (PINION SEAL)	TATA spare parts
285035300185	SERV KIT RING AND PINION	TATA spare parts
285035300186	SERV KIT DIFF CASE	TATA spare parts
285035300187	RETAINER ASSY - OIL SEAL	TATA spare parts
285035300188	GEARANDPINIONASSY-HYPOIDDRIVE4.89	TATA spare parts
285035300189	ASSY. CROWN & PINION RATIO 4.88 BS3/4	TATA spare parts
285035300190	GEAR AND PINION ASSY - HYPOID DRIVE (4.1	TATA spare parts
285035300195	CROWN WHEEL & PINION ASSY	TATA spare parts
285035300202	BEARING DIFFERANTIAL	TATA spare parts
285035300203	BEARING PINION	TATA spare parts
285035300204	BEARING PINION	TATA spare parts
285035300210	KIT-SEAL	TATA spare parts
285035300212	BEARING	TATA spare parts
285035300213	KIT BEARING (CUP & CONE)	TATA spare parts
285035300217	CROWN WHEEL & PINION ASSY	TATA spare parts
285035300218	BEARING&KIT BS6	TATA spare parts
285035300220	COMPANION FLANGE ASSY	TATA spare parts
285035300221	KIT-OIL SEAL WITH PINION NUT	TATA spare parts
285035300222	CROWN WHEEL & PINION ASSY	TATA spare parts
285035300223	CROWNWHEEL&PINIONASSY BS6	TATA spare parts
285035300224	BEARING	TATA spare parts
285035300228	KIT-OIL SEAL WITH PINION NUT BS6	TATA spare parts
285035300229	KIT-OIL SEAL WITH PINION NUT BS6	TATA spare parts
285035300230	DRIVE GEAR WITH PINION BS6	TATA spare parts
285035300231	GEAR - HYPOID GEARSET (10101564) BS6	TATA spare parts
285035300232	PKG - SCREW BS6	TATA spare parts
285035300233	COUPLING FLANGE ASSY BS6	TATA spare parts
285035300234	CROWN WHEEL & PINION ASSY BS6	TATA spare parts
285035300235	CROWN WHEEL & PINION ASSY BS6-PH2	TATA spare parts

285035300236	DIFFERENTIAL ASSY BS6	TATA spare parts
285035300237	DIFFERENTIAL HOUSING ASSY BS6	TATA spare parts
285035300238	SHAFT ASSY BS6	TATA spare parts
285035300239	CROWN WHEEL & PINION ASSY	TATA spare parts
285035300245	KIT-DRIVE GEAR AND PINION ASSY BS6	TATA spare parts
285035300246	CROWN WHEEL & PINION ASSY BS6	TATA spare parts
285035300247	CROWN WHEEL & PINION ASSY BS6	TATA spare parts
285035300249	CROWN WHEEL & PINION ASSY BS6-PH2	TATA spare parts
285035300250	KIT -BEARING BS6-PH2	TATA spare parts
28503530133	KIT-DIFF CASE INNER PART STD	TATA spare parts
285035303101	PINION INNER BRG CUP\CONE	TATA spare parts
285035303102	PINION INNER BRG CONE & CUP BS2/3/4/6	TATA spare parts
285035303103	DIFF BEARING ASSY CONE & CUP	TATA spare parts
285035303106	ASSY. BEARING DIFF. (CONE/CUP) BS2/3/4/6	TATA spare parts
285035303108	BEARING CUP & ROLLER	TATA spare parts
285035303109	BEARING CONE & ROLLER BS4	TATA spare parts
285035303110	BEARING CONE - ROLLER	TATA spare parts
285035303111	TAPER ROLLER BRG ASSY 565909	TATA spare parts
285035303113	SINGLEROWBALLBEARING BS6	TATA spare parts
285035303114	ROLLER BEARING CUP	TATA spare parts
285035303115	BEARING CONE ROLLER	TATA spare parts
285035303116	ROLLER BEARING CUP	TATA spare parts
285035303119	BEARING CUP	TATA spare parts
285035303120	BEARING CONE	TATA spare parts
285035303125	BEARING BS6	TATA spare parts
285035303201	BOLT M10 X 1.25 (SERRATIONS UNDER HEAD)	TATA spare parts
285035303302	BRACKET BRAKE CABLE FIN	TATA spare parts
285035303707	BEARING CONE & ROLLER BS4	TATA spare parts
285035305001	COMPANION FLANGE	TATA spare parts
285035305005	COMPANION FLANGE	TATA spare parts
285035305006	COMPANION FLANGE ASSY	TATA spare parts
285035305007	COMPANION FLANGE	TATA spare parts
285035305009	COMPANION FLANGE	TATA spare parts
285035305010	COMPANIONFLANGE DEFLECTORASSY BS6	TATA spare parts
285035305101	DIFFERENTIAL CASE HSG.	TATA spare parts
285035305102	DIFFERENTIAL SHAFT	TATA spare parts
285035305104	DIFF CASE FIN	TATA spare parts
285035305105	DIFF SHAFT	TATA spare parts
285035305106	CASE - FIN (DIFF STD)	TATA spare parts
285035305108	DIFFERENTIAL HOUSING BS6	TATA spare parts
285035305109	DIFFERENTIAL SHAFT BS6	TATA spare parts
285035305110	CASE FIN (DIFF STD)10234885 BS6	TATA spare parts
285035305111	DIFF CASE STD (FINISHED) 10332343 BS6-PH	TATA spare parts
285035305403	DIFFERENTIAL GEAR	TATA spare parts
285035305404	DIFFERENTIAL PINION	TATA spare parts
285035305409	PINION DIFF - FIN	TATA spare parts
285035305410	GEAR DIFF - FIN	TATA spare parts

285035305416	GEAR - NET FORMED DIFF FIN (2006146) BS6	TATA spare parts
285035305417	PINION - NET FORMED	TATA spare parts
285035305420	GEAR DIFF PINION (MACH)	TATA spare parts
285035305421	GEAR DIFF SIDE (MACH)	TATA spare parts
285035305441	CROWN WHEEL & PINION ASSY BS6	TATA spare parts
285035306101	LOCK STRAP-RING GEAR BOLT	TATA spare parts
285035306501	NUT - PINION (2009621) BS6	TATA spare parts
285035306502	NUT PINION	TATA spare parts
285035306503	NUT - LOCK (10001447) BS6	TATA spare parts
285035306701	PIN ROLL	TATA spare parts
285035306702	PIN ROLL (53288) BS6	TATA spare parts
285035306703	RETAINER DIFF PINION SHAFT	TATA spare parts
285035306704	RETAINER DIFF PINION SHAFT	TATA spare parts
285035307101	RETAINER & BEARING FIN	TATA spare parts
285035307102	RETAINER & WHEEL BRG INNER	TATA spare parts
285035307105	RETAINER PLATE ASSY BS6	TATA spare parts
285035307106	RETAINER - OIL SEAL (2023028) BS6	TATA spare parts
285035307701	OIL SEAL PINION	TATA spare parts
285035307702	OIL SEAL OUTBOARD BS2/3	TATA spare parts
285035307703	OIL SEAL (PINION) BS2/3/4/6	TATA spare parts
285035307704	OIL SEAL INBOARD BS2/3/4	TATA spare parts
285035307705	SEAL-OIL	TATA spare parts
285035307706	SEAL & OIL (INBOARD)	TATA spare parts
285035307707	SEAL & OIL	TATA spare parts
285035307708	SEAL & OIL	TATA spare parts
285035307710	SEAL OIL BS4	TATA spare parts
285035307711	OIL SEAL BS6	TATA spare parts
285035307712	OILSEAL BS6	TATA spare parts
285035307901	SHAFT DIFF PINION	TATA spare parts
285035307902	SHAFT DIFF PINION	TATA spare parts
285035307904	SHAFT-FLANGED AXLE (FINISHED)(SEMI-FLOAT	TATA spare parts
285035308001	RING GEAR BOLT	TATA spare parts
285035308003	RING GEAR BOLT	TATA spare parts
285035308004	SCREW - FLANGE HEAD	TATA spare parts
285035308005	SCREW - FLANGE HEAD	TATA spare parts
285035308006	SCREW - DRIVE GEAR	TATA spare parts
285035308007	SCREW - FLANGE HEAD (2010659-1) BS6	TATA spare parts
285035308008	SCREW BS6	TATA spare parts
285035308201	PINION TAIL SLINGER	TATA spare parts
285035308202	RETAINER OIL SEAL	TATA spare parts
285035308205	PINION TAIL SLINGER	TATA spare parts
285035308206	DEFLECTOR	TATA spare parts
285035308207	SLINGER & DUST	TATA spare parts
285035308208	RETAINER OIL SEAL	TATA spare parts
285035308209	RETAINER PLATE	TATA spare parts
285035308301	SHIM PINION	TATA spare parts
285035308302	SHIM DIFFERENTIAL	TATA spare parts



285035308306	SHIM ç AD.J	TATA spare parts
285035308307	SHIM DIFF BEARING (1.779/1.789)	TATA spare parts
285035308308	SHIM DIFF BEARING (1.83/1.84)	TATA spare parts
285035308309	SHIM DIFF BEARING (1.881/1.891)	TATA spare parts
285035308310	SHIM DIFF BEARING (1.932/1.942)	TATA spare parts
285035308311	SHIM DIFF BEARING (1.983/1.993)	TATA spare parts
285035308312	SHIM DIFF BEARING (2.034/2.044)	TATA spare parts
285035308313	SHIM DIFF BEARING (2.085/2.095)	TATA spare parts
285035308314	SHIM DIFF BEARING (2.136/2.146)	TATA spare parts
285035308315	SHIM DIFF BEARING (2.187/2.197)	TATA spare parts
285035308316	SHIM DIFF BEARING (2.238/2.248)	TATA spare parts
285035308317	SHIM DIFF BEARING (2.289/2.299)	TATA spare parts
285035308318	SHIM DIFF BEARING (2.34/2.35)	TATA spare parts
285035308319	SHIM DIFF BEARING (1.575/1.585)	TATA spare parts
285035308320	SHIM DIFF BEARING (1.626/1.636)	TATA spare parts
285035308321	SHIM DIFF BEARING (1.677/1.687)	TATA spare parts
285035308322	SHIM DIFF BEARING (1.728/1.738)	TATA spare parts
285035308323	SHIM PINION-ADJUSTMENT HK-1.33	TATA spare parts
285035308324	SHIM PINION- ADJUSTMENT THK-1.35	TATA spare parts
285035308325	SHIM PINION- ADJUSTMENT THK-1.50	TATA spare parts
285035308326	SHIM PINION- ADJUSTMENT THK-1.45	TATA spare parts
285035308327	SHIM PINION- ADJUSTMENT THK-1.40	TATA spare parts
285035308328	SHIM PINION- ADJUSTMENT THK-1.48	TATA spare parts
285035308329	SHIM PINION- ADJUSTMENT THK-1.60	TATA spare parts
285035308330	SHIM PINION- ADJUSTMENT THK-1.55	TATA spare parts
285035308331	SHIM PINION- ADJUSTMENT THK-1.58	TATA spare parts
285035308332	SHIM PINION- ADJUSTMENT THK-1.43	TATA spare parts
285035308333	SHIM PINION- ADJUSTMENT THK-1.63	TATA spare parts
285035308334	SHIM PINION- ADJUSTMENT THK-1.65	TATA spare parts
285035308335	SHIM PINION- ADJUSTMENT THK-1.68	TATA spare parts
285035308336	SHIM PINION- ADJUSTMENT THK-1.53	TATA spare parts
285035308337	SPACER - BRG PRELOAD (DIFF)(THK-2.89)	TATA spare parts
285035308338	SPACER - BRG PRELOAD (DIFF)(THK-3.29)	TATA spare parts
285035308339	SPACER - BRG PRELOAD (DIFF)(THK-3.21)	TATA spare parts
285035308340	SPACER - BRG PRELOAD (DIFF)(THK 3.16)	TATA spare parts
285035308341	SPACER - BRG PRELOAD (DIFF)(THK 3.26)	TATA spare parts
285035308342	SPACER - BRG PRELOAD (DIFF)(THK 3.41)	TATA spare parts
285035308343	SPACER - BRG PRELOAD (DIFF)(THK 3.06)	TATA spare parts
285035308344	SPACER - BRG PRELOAD (DIFF)(THK 3.04)	TATA spare parts
285035308345	SPACER - BRG PRELOAD (DIFF)(THK 3.46)	TATA spare parts
285035308346	SPACER - BRG PRELOAD (DIFF)(THK 3.44)	TATA spare parts
285035308347	SPACER - BRG PRELOAD (DIFF)(THK 3.49)	TATA spare parts
285035308348	SPACER - BRG PRELOAD (DIFF)(THK 3.11)	TATA spare parts
285035308349	SPACER - BRG PRELOAD (DIFF)(THK 3.36)	TATA spare parts
285035308350	SPACER - BRG PRELOAD (DIFF)(THK 3.01)	TATA spare parts
285035308351	SPACER - BRG PRELOAD (DIFF)(THK 3.31)	TATA spare parts
285035308352	SPACER - BRG PRELOAD (DIFF)(THK 3.09)	TATA spare parts

285035308353	SPACER - BRG PRELOAD (DIFF)(THK 3.51)	TATA spare parts
285035308354	SPACER - BRG PRELOAD (DIFF)(THK 3.39)	TATA spare parts
285035308355	SPACER - BRG PRELOAD (DIFF)(THK 3.14)	TATA spare parts
285035308356	SPACER - BRG PRELOAD (DIFF)(THK 2.99)	TATA spare parts
285035308357	SPACER PINION BEARING (THK-1.23)	TATA spare parts
285035308358	SPACER PINION BEARING (THK-1.30)	TATA spare parts
285035308359	SPACER PINION BEARING (THK-1.32)	TATA spare parts
285035308360	SPACER PINION BEARING (THK-1.34)	TATA spare parts
285035308361	SPACER PINION BEARING (THK-1.35)	TATA spare parts
285035308362	SPACER PINION BEARING (THK-1.40)	TATA spare parts
285035308363	SPACER PINION BEARING (THK-1.41)	TATA spare parts
285035308364	SPACER PINION BEARING (THK-1.42)	TATA spare parts
285035308365	SPACER PINION BEARING (THK-1.43)	TATA spare parts
285035308366	SPACER PINION BEARING (THK-1.44)	TATA spare parts
285035308367	SPACER PINION BEARING (THK-1.46)	TATA spare parts
285035308368	SPACER PINION BEARING (THK-1.47)	TATA spare parts
285035308369	SHIM DIFF BRG(THK-2.16)	TATA spare parts
285035308370	SHIM DIFF BRG(THK-2.38)	TATA spare parts
285035308371	SHIM DIFF BRG(THK-2.39)	TATA spare parts
285035308372	SHIM DIFF BRG(THK-2.4)	TATA spare parts
285035308373	SHIM DIFF BRG(THK-2.41)	TATA spare parts
285035308374	SHIM DIFF BRG(THK-2.42)	TATA spare parts
285035308375	SHIM DIFF BRG(THK-2.43)	TATA spare parts
285035308376	SHIM DIFF BRG(THK-2.44)	TATA spare parts
285035308377	SHIM DIFF BRG(THK-2.45)	TATA spare parts
285035308378	SHIM DIFF BRG(THK-2.46)	TATA spare parts
285035308379	SHIM DIFF BRG(THK-2.55)	TATA spare parts
285035308380	SHIM DIFF BRG(THK-2.59)	TATA spare parts
285035308381	SHIM DIFF BRG(THK-2.61)	TATA spare parts
285035308382	SHIM DIFF BRG(THK-2.62)	TATA spare parts
285035308383	SHIM DIFF BRG(THK-2.63)	TATA spare parts
285035308384	SHIM DIFF BRG(THK-2.65)	TATA spare parts
285035308385	SHIM DIFF BRG(THK-2.66)	TATA spare parts
285035308386	SHIM DIFF BRG(THK-2.68)	TATA spare parts
285035308387	SHIM DIFF BRG(THK-2.69)	TATA spare parts
285035308388	SHIM DIFF BRG(THK-2.7)	TATA spare parts
285035308601	COLLAPSABLE SPACER	TATA spare parts
285035308602	SPACER & PINION BRC	TATA spare parts
285035308603	SPACER & COLLAPSIBLE	TATA spare parts
285035308604	SPACER - COLLAPSIBLE (10075514) BS6	TATA spare parts
285035308605	SPACER PINION BRG PRELOAD BS6	TATA spare parts
285035309201	THRUST WASHER DIFF.GEAR	TATA spare parts
285035309202	THRUST WASHER (DIFF. PINION)	TATA spare parts
285035309203	THRUST WASHER - DIFF PINION (2006145) BS	TATA spare parts
285035309204	WASHER THRUST PINION	TATA spare parts
285035309205	WASHER THRUST SIDE GEAR (0.74/0.79)	TATA spare parts
285035309206	WASHER FLAT	TATA spare parts

285035309207	WASHER THRUST SIDE GEAR (0.85/0.90)	TATA spare parts
285035309208	WASHER THRUST SIDE GEAR (0.95/1.0)	TATA spare parts
285035309209	WASHER THRUST PINION	TATA spare parts
285035309213	THRUST WASHER BS6	TATA spare parts
285035600101	BEARING ASM BALL	TATA spare parts
285035600102	BEARING ASSY BALL	TATA spare parts
285035600103	RETAINER PLATE ASSY BS6	TATA spare parts
285035600104	BEARING HUB BS6	TATA spare parts
285035600105	RETAINER PLATE ASSY BS6	TATA spare parts
285035600106	BEARING HUB BS6	TATA spare parts
285035603101	BALL BEARING 2002106 BS2/3/4	TATA spare parts
285035603101DF	BEARING REAR AXLE - ACE/MAGIC	TATA spare parts
285035603102	BEARING BS6	TATA spare parts
285035603103	BEARING BS6	TATA spare parts
285035603201	WHEEL BOLT BS2/3/4	TATA spare parts
285035603202	BOLT WHEEL M12 X 1.5	TATA spare parts
285035603203	BOLT M10 X 1.5	TATA spare parts
285035603204	WHEEL BOLT	TATA spare parts
285035603205	BOLT - WHEEL RH	TATA spare parts
285035603701	BRAKE DRUM-2002111	TATA spare parts
285035605303	GASKET RETAINER PLATE	TATA spare parts
285035605304	GASKET BRAKE BACK PLATE	TATA spare parts
285035606205	NUT HEX	TATA spare parts
285035606501	NUT-LOCK	TATA spare parts
285035606502	HEX NUT	TATA spare parts
285035606504	WHEEL NUT	TATA spare parts
285035606505	NUT M10	TATA spare parts
285035606506	NUT BS6	TATA spare parts
285035607101	PLATE SIDE	TATA spare parts
285035607102	PLATE SIDE	TATA spare parts
285035607103	SIDE PLATE (4.44)	TATA spare parts
285035607203	OIL SEAL BS6	TATA spare parts
285035607801	SEAL OIL	TATA spare parts
285035607802	OIL SEAL	TATA spare parts
285035607804	OIL SEAL BS6	TATA spare parts
285035607805	OIL SEAL BS6	TATA spare parts
285035608302	SHIM REAR HUB BS6	TATA spare parts
285035608601	RING RETAINING BS2/3/4	TATA spare parts
285035608602	RING SNAP	TATA spare parts
285035608603	RING SNAP	TATA spare parts
285035608604	RING RETAINING A 1	TATA spare parts
285035608801	STUD -DOWEL	TATA spare parts
285035608802	STUD (2008296-1) BS6	TATA spare parts
285035700101	RETAINER OIL SEAL ASY KIT	TATA spare parts
285035700102	AXLE SHAFT KIT	TATA spare parts
285035700103	AXLE SHAFT BEARING KIT	TATA spare parts
285035700105	KIT-SEAL	TATA spare parts

285035700106	KIT-BRG	TATA spare parts
285035700107	AXLE SHAFT ASSEMBLY	TATA spare parts
285035700108	SHAFT ASSY¿REAR AXLE COMPLETE	TATA spare parts
285035700109	SHAFT AND BOLT ASSY	TATA spare parts
285035700110	KIT - BRG	TATA spare parts
285035700112	SHAFT ASSY - REAR AXLE COMPLETE	TATA spare parts
285035700113	SHAFT AND BOLT ASSY	TATA spare parts
285035700114	ASSY. BEARING (TAPERED ROLLER) BS3/4	TATA spare parts
285035700115	RETAINER ASSY - OIL SEAL	TATA spare parts
285035700116	SERV KIT SEAL (OUTBOARD SEAL) 40115477	TATA spare parts
285035700117	SERV KIT AXLE SHAFT	TATA spare parts
285035700118	SERV KIT BEARING	TATA spare parts
285035700120	SHAFTASSYREARAXLECOMPLETE	TATA spare parts
285035700125	SHAFT ASSY	TATA spare parts
285035700126	SHAFT ASSY	TATA spare parts
285035700127	SHAFT ASSY	TATA spare parts
285035700128	SHAFT ASSY BS6	TATA spare parts
285035700129	KIT-BEARING (10143792)	TATA spare parts
285035700130	REAR AXLE SHAFT ASSY RH BS6	TATA spare parts
285035700131	REAR AXLE SHAFT ASSY LH BS6	TATA spare parts
285035700134	REAR AXLE SHAFT ASSY RH BS6	TATA spare parts
285035700135	REAR AXLE SHAFT ASSY LH BS6	TATA spare parts
285035700136	KIT-OIL SEAL WITH PINION NUT BS6-PH2	TATA spare parts
285035700137	SHAFT ASSY BS6-PH2	TATA spare parts
285035700140	SHAFT ASSY BS6-PH2	TATA spare parts
285035700141	SHAFT ASSY BS6-PH2	TATA spare parts
285035700212	SHAFTASSY BS6	TATA spare parts
285035700213	SHAFT ASSY	TATA spare parts
285035700214	KIT - BEARING BS6	TATA spare parts
285035703101	BEARING BS6	TATA spare parts
285035703201	RETAINER BOLT	TATA spare parts
285035703202	BOLTBUTTONHEAD	TATA spare parts
285035703203	BOLT - BUTTON HEAD (54932-7) BS6	TATA spare parts
285035707101	RETAINER - BEARING FIN	TATA spare parts
285035707102	RETAINER - WHEEL BRG INNER	TATA spare parts
285035707701	OIL SEAL INBOARD (AXLE SHAFT)	TATA spare parts
285035707702	OIL SEAL BS6-PH2	TATA spare parts
285035707801	SEAL - OIL	TATA spare parts
285035707802	SEAL - OIL BS1/3/4/6	TATA spare parts
285035707802DF	OIL SEAL REAR AXLE - MEGA/SUPER ACE	TATA spare parts
285035707803	O-RING BS6	TATA spare parts
285035707901	REAR AXLE SHAFT BS2/3/4	TATA spare parts
285035707902	SHAFT - DIFF STD AND T/L (2006280) BS6	TATA spare parts
285035707903	SHAFT ¿ FLANGED AXLE FIN (SF)	TATA spare parts
285035707904	SHAFT AXLE (MACH) 40057028 BS2/3/4	TATA spare parts
285035707905	SHAFT AXLE (MACH)	TATA spare parts
285035707906	REAR AXLE SHAFT (W/1684 TRACK) BS4 BS2/3	TATA spare parts

285035707909	SHAFT AXLE (MACH)	TATA spare parts
285035707911	SHAFT	TATA spare parts
285035707912	SHAFT-FLANGE AXLE	TATA spare parts
285035707913	SHAFT ASSY BS6	TATA spare parts
285035707914	SHAFT-FLANGED AXLE (FINISHED)	TATA spare parts
285035707915	REAR AXLE SHAFT BS6	TATA spare parts
285035707916	REAR AXLE SHAFT BS6	TATA spare parts
285035707918	SHAFT-FLAMGED AXLE BS6-PH2	TATA spare parts
285035707919	SHAFT-FLANGED AXLE (FINISHED) BS6-PH2	TATA spare parts
285035708201	RETAINER BEARING RING BS2/3/4	TATA spare parts
285035708202	RETAINER - WHEEL BRG INNER (10091389) BS	TATA spare parts
285049995310	HEAT SHIELD STRAIGHT	TATA spare parts
285126010102	ASSY.G65 GEAR BOX COMPLETE FOR 4 SPEED	TATA spare parts
285126010104	ASSY.G65-6.3/4 GEAR BOX COMPLETE	TATA spare parts
285126010105	ASSY. GEARBOX G65/5-4.19	TATA spare parts
285126010106	ASSY G65-5/527 GEARBOX COMPLETE	TATA spare parts
285126010108	ASSY G65-5/5.27 GEARBOX COMPLETE	TATA spare parts
285126010110	ASSY. GEAR BOX G65 5/5.07 BS1/3/4	TATA spare parts
285126010111	GEAR BOX ASSY BS6	TATA spare parts
285126010112	ASSY G65-5/5.27 GEARBOX COMPLETE FOR CNG	TATA spare parts
285126010114	ASSY. GEARBOX G65/5-4.19 (5TH GEAR 0.75)	TATA spare parts
285126010115	ASSY. GEARBOX G65-4/6.3 FOR HILLY TERRA	TATA spare parts
285126010119	GEAR BOX G65 5/5.27 ACE CNG W/PTO PROVIS	TATA spare parts
285126010121	ASSY G65-5S/ 5.27 GEAR BOX	TATA spare parts
285126010130	ASSY GEARBOX G65/5-5.07 WITH CRB	TATA spare parts
285126010135	ASSY G65-5/5.27 GEARBOX FOR 800CC DICOR	TATA spare parts
285126010137	GEARBOX G65/5-5.07 ASSY WITH PTO	TATA spare parts
285126010151	ASSY. GEAR BOX COMP.(G65/5-5.07) BS4	TATA spare parts
285126010152	GEAR BOX ASSY	TATA spare parts
285126010153	GEAR BOX (GBS 65-5/5.07) WITH PTO PROVIS	TATA spare parts
285126010154	GEAR BOX ASSY WITH PTO	TATA spare parts
285126010160	GEAR BOX ASSY	TATA spare parts
285126010161	GEAR BOX ASSY WITH PTO	TATA spare parts
285126010164	GEAR BOX ASSY BS6	TATA spare parts
285126010167	GEAR BOX ASSY BS6	TATA spare parts
285126010168	GEAR BOX ASSYBS6	TATA spare parts
285126010169	GEARBOX	TATA spare parts
285126010170	GEAR BOX ASSY BS6	TATA spare parts
285126010173	GEAR BOX ASSY BS6-PH2	TATA spare parts
285126010175	GEAR BOX ASSY WITH PTO PROVISION BS6	TATA spare parts
285126010178	GEAR BOX ASSY BS6	TATA spare parts
285126010181	GEAR BOX ASSY BS6	TATA spare parts
285126010182	GEAR BOX ASSY WITH PTO PROVISION BS6	TATA spare parts
285126010183	GEAR BOX ASSY WITH PTO PROVISION BS6	TATA spare parts
285126010184	GEAR BOX ASSY BS6	TATA spare parts
285126010188	GEAR BOX ASSY BS6	TATA spare parts
285126010189	GEAR BOX ASSEMBLY - ACE	TATA spare parts

285126010190	GEAR BOX ASSY BS6	TATA spare parts
285126010194	GEAR BOX ASSY BS6-PH2	TATA spare parts
285126010195	GEAR BOX ASSY	TATA spare parts
285126100111	SUB. ASSY. GEARBOX HOUSING REAR HALF	TATA spare parts
285126100116	SUB ASSY HOUSING REAR HALF WITH SEALING	TATA spare parts
285126100117	ASSY. GEARBOX HOUSING REAR HALF	TATA spare parts
285126100129	SUB.ASSY GEARBOX HSG.FRONT HALF	TATA spare parts
285126100160	GEAR BOX HOUSING ASSY FRONT BS6	TATA spare parts
285126100178	REAR HALF ASSY BS6	TATA spare parts
285126103801	HOUSING FRONT HALF	TATA spare parts
285126103803	LOCK PLATE-FOR MAIN SHAFT BRG.	TATA spare parts
285126103804	REAR HALF	TATA spare parts
285126103805	HOUSING REAR HALF	TATA spare parts
285126103806	HOUSING FRONT HALF	TATA spare parts
285126103808	HOUSING FRONT HALF WITH PTO PROVISION	TATA spare parts
285126103809	REAR HALF FOR 5 SPEED	TATA spare parts
285126103810	FRONT HALF HOUSING BS2/3/4	TATA spare parts
285126103811	FRONT HALF WITH PTO PROVISION	TATA spare parts
285126103813	FRONT HALF	TATA spare parts
285126103814	REAR HALF	TATA spare parts
285126103817	HOUSING FRONT HALF WITH PTO & CRB	TATA spare parts
285126103818	HOUSING FRONT HALF BS6	TATA spare parts
285126103824	CLUTCH HOUSING BS6	TATA spare parts
285126103827	CLUTCH HOUSING BS6	TATA spare parts
285126103828	CLUTCH HOUSING BS6	TATA spare parts
285126103829	REAR HALF	TATA spare parts
285126103832	HOUSING FRONT-HALF BS6-PH2	TATA spare parts
285126103833	INTERMEDIATE PLATE BS6-PH2	TATA spare parts
285126103834	REAR HALF BS6-PH2	TATA spare parts
285126103835	CLUTCH HOUSING BS6	TATA spare parts
285126103836	GEAR BOX HOUSING BS6	TATA spare parts
285126103837	CLUTCH HOUSING BS6	TATA spare parts
285126103843	CLUTCH HOUSING (WITH PTO OPENING) BS6	TATA spare parts
285126103847	CLUTCH HOUSING BS6	TATA spare parts
285126103848	CLUTCH HOUSING BS6	TATA spare parts
285126103851	CLUTCH HOUSING BS6	TATA spare parts
285126103854	CLUTCH HOUSING BS6	TATA spare parts
285126103856	CLUTCH HOUSING BS6-PH2	TATA spare parts
285126103858	CLUTCH HOUSING BS6-PH2	TATA spare parts
285126104801	DOWEL SLEEVE (REAR HALF TO REAR COVER)	TATA spare parts
285126104802	DOWEL SLEEVE (FRONT HALF TO REAR HALF)	TATA spare parts
285126106701	PIVOT PIN-REV.SHIFTER LEVER	TATA spare parts
285126107201	PLUG-DETENT SPRING	TATA spare parts
285126107202	DRAIN PLUG FOR ACE G65 BS4	TATA spare parts
285126108201	LOCK PLATE-PIVOT PIN	TATA spare parts
285126108601	SEALING WASHER COPPER(CUP SHAPED)	TATA spare parts
285126109201	WASHER (FR. HALF HSG. TO PIVOT PIN) BS6	TATA spare parts

285126109901	ADAPTOR	TATA spare parts
285126200104	ASSY. ENGAGING GEAR (5TH SPEED GEAR) BS6	TATA spare parts
285126200110	SPEEDO PINION (13/3) PLASTIC VER. BS4	TATA spare parts
285126200111	ASSY.SPEEDO GEAR-13/3 PLASTIC VER. BS4	TATA spare parts
285126200115	KIT-SYNCHRO (1/2 SPD) W/O CONE BS2/3/4	TATA spare parts
285126200116	KIT-SYNCHRO (3/4 SPEED) W/O CONE BS2/3/4	TATA spare parts
285126200119	ASSY. ENGAGING GEAR (1ST/2ND SPEED GEAR)	TATA spare parts
285126200123	ASSY. REAR COVER	TATA spare parts
285126200126	ASSY. BRACKET (GEARBOX MOUNTING)	TATA spare parts
285126200127	SUB ASSY REAR COVER WITH BUSH	TATA spare parts
285126200131	SUB ASSY REAR COVER WITH SLIDING BUSH.	TATA spare parts
285126200136	SUB ASSY REAR COVER WITH BUSH	TATA spare parts
285126200139	SUB ASSY REAR COVER(LH SPEEDO)WITH SLIDI	TATA spare parts
285126200146	SUB ASSY REAR COVER WITH LH SPEEDO.	TATA spare parts
285126200157	REAR COVER ASSY	TATA spare parts
285126200161	COVER ASSY WITH BUSH REAR	TATA spare parts
285126200170	GEAR CASE COVER ASSY	TATA spare parts
285126200188	COVER ASSY WITH BUSH REAR BS6	TATA spare parts
285126200190	COVER ASSY WITH BUSH REAR BS6	TATA spare parts
285126200192	COVER ASSY WITH BUSH REAR	TATA spare parts
285126200196	COVER ASSY WITH BUSH REAR	TATA spare parts
285126200198	COVER ASSY WITH BUSH REAR	TATA spare parts
285126203101	NEEDLE ROLLER BEARING 2ND/3RD GEAR	TATA spare parts
285126203102	NEEDLE ROLLER BEARING-1ST SPEED GEAR	TATA spare parts
285126203103	NEEDLE BEARING (5TH GEAR MAIN SHAFT)	TATA spare parts
285126203105	NEEDLE ROLLER BEARING (1ST SPEED GEAR) B	TATA spare parts
285126203106	NEEDLE ROLLER BEARING (2ND/3RD GEAR) BS6	TATA spare parts
285126203107	NEEDLE ROLLER BEARING BS6	TATA spare parts
285126203113	NEEDLE ROLLER BEARING	TATA spare parts
285126203115	NEEDLE ROLLER BEARING BS6	TATA spare parts
285126203117	DEEP GROOVE BALL BEARING BS6	TATA spare parts
285126203118	NEEDLE ROLLER BRG 2ND/3RD GR BS6-PH2	TATA spare parts
285126203119	NEEDLE ROLLER BEARING 1ST SPEED GEAR BS6	TATA spare parts
285126203120	NEEDLE BEARING	TATA spare parts
285126203401	BUSH (5TH GEAR)	TATA spare parts
285126203402	BUSH-1ST GEAR	TATA spare parts
285126203403	BUSH-SLIDING JOINT	TATA spare parts
285126203406	BUSH	TATA spare parts
285126203802	REAR COVER	TATA spare parts
285126204316	SNAP RING 2.0 THK.	TATA spare parts
285126204317	SNAP RING 2.1 THK.	TATA spare parts
285126204318	SNAP RING 2.2 THK.	TATA spare parts
285126204319	CIRCLIP 2.00 THK.-C TYPE	TATA spare parts
285126204320	CIRCLIP 2.05 THK.-C TYPE	TATA spare parts
285126204321	CIRCLIP 2.10 THK.-C TYPE	TATA spare parts
285126204322	CIRCLIP 2.15 THK.-C TYPE	TATA spare parts
285126204323	CIRCLIP 2.20 THK.-C TYPE	TATA spare parts

285126204324	CIRCLIP 2.25 THK.-C TYPE	TATA spare parts
285126204325	CIRCLIP 2.30 THK.-C TYPE	TATA spare parts
285126204326	SNAP RING 2.3 THK.	TATA spare parts
285126204327	SNAP RING 2.4 THK.	TATA spare parts
285126204328	SNAP RING 2.5 THK.	TATA spare parts
285126204329	CIRCLIP 2.35 THK. (C TYPE)	TATA spare parts
285126204330	CIRCLIP 2.40 THK. (C TYPE)	TATA spare parts
285126204331	CIRCLIP 2.45 THK. (C TYPE)	TATA spare parts
285126204332	CIRCLIP 2.50 THK. (C TYPE)	TATA spare parts
285126204333	CIRCLIP 2.55 THK. (C TYPE)	TATA spare parts
285126204334	CIRCLIP 2.60 THK. (C TYPE)	TATA spare parts
285126204335	CIRCLIP 2.65 THK. (C TYPE)	TATA spare parts
285126204336	CIRCLIP 2.70 THK. (C TYPE)	TATA spare parts
285126204339	CIRCLIP 1.80 THK. (C TYPE)	TATA spare parts
285126204340	CIRCLIP 1.85 THK. (C TYPE)	TATA spare parts
285126204341	CIRCLIP 1.90 THK. (C TYPE)	TATA spare parts
285126204342	CIRCLIP 1.95 THK. (C TYPE)	TATA spare parts
285126204343	SNAP RING (BALL BEARING)	TATA spare parts
285126204344	CIRCLIP 1.6 THK. (C TYPE) BS6	TATA spare parts
285126204345	CIRCLIP 1.65 THK. (C TYPE) BS6-PH2	TATA spare parts
285126204346	CIRCLIP 1.7 THK. (C TYPE) BS6-PH2	TATA spare parts
285126204347	CIRCLIP 1.75 THK. (C TYPE) BS6-PH2	TATA spare parts
285126204348	CIRCLIP 2.75 THK. (C TYPE) BS6-PH2	TATA spare parts
285126204349	CIRCLIP 2.8 THK. (C TYPE) BS6-PH2	TATA spare parts
285126204350	CIRCLIP 2.85 THK. (C TYPE) BS6-PH2	TATA spare parts
285126204360	SNAP RING BALL BEARING	TATA spare parts
285126204386	SNAP RING BS6-PH2	TATA spare parts
285126204387	SNAP RING BS6-PH2	TATA spare parts
285126204388	SNAP RING BS6-PH2	TATA spare parts
285126204389	SNAP RING BS6-PH2	TATA spare parts
285126204390	SNAP RING BS6-PH2	TATA spare parts
285126204391	SNAP RING BS6-PH2	TATA spare parts
285126204392	SNAP RING BS6-PH2	TATA spare parts
285126204393	SNAP RING BS6-PH2	TATA spare parts
285126204394	SNAP RING BS6-PH2	TATA spare parts
285126204395	SNAP RING BS6-PH2	TATA spare parts
285126204396	SNAP RING BS6-PH2	TATA spare parts
285126204397	SNAP RING BS6-PH2	TATA spare parts
285126204398	SNAP RING BS6-PH2	TATA spare parts
285126204399	SNAP RING BS6-PH2	TATA spare parts
285126204401	SNAP RING BS6-PH2	TATA spare parts
285126204601	ENGAGING GEAR 5TH SPEED(SINT SOFT VER.)	TATA spare parts
285126204604	MAIN SHAFT ENGAGING GEAR 1/2ND SPEED BS6	TATA spare parts
285126204606	ENGAGING GEAR 5TH/REVERSE SPEED BS6	TATA spare parts
285126204609	ENGAGING GEAR 1ST/2ND SPEED	TATA spare parts
285126205405	2ND GEAR	TATA spare parts
285126205406	3RD GEAR	TATA spare parts



285126205407	SHIFTER SLEEVE REV/1ST/2ND SPEED BS2/3/4	TATA spare parts
285126205411	1ST GEAR	TATA spare parts
285126205413	1ST GEAR	TATA spare parts
285126205414	2ND GEAR	TATA spare parts
285126205415	1ST GEAR	TATA spare parts
285126205416	2ND GEAR	TATA spare parts
285126205417	3RD GEAR BS2/3/4	TATA spare parts
285126205419	2ND GEAR	TATA spare parts
285126205420	2ND GEAR - TCIC	TATA spare parts
285126205421	THIRD SPEED GEAR BS1/2/3/4/6	TATA spare parts
285126205422	FIFTH SPEED GEAR	TATA spare parts
285126205423	REV. GEAR/SHIFTER SLEEVE	TATA spare parts
285126205424	FIFTH SPEED GEAR	TATA spare parts
285126205425	FIRST SPEED GEAR	TATA spare parts
285126205430	FIRST SPEED GEAR-DEEPER RATIO	TATA spare parts
285126205432	2ND SPEED GEAR	TATA spare parts
285126205433	FIRST SPEED GEAR	TATA spare parts
285126205434	2ND SPEED GEAR	TATA spare parts
285126205437	SHIFTER SLEEVE REV. GEAR BS1/2/3/4/6	TATA spare parts
285126205440	1ST SPEED GEAR(STOPER ARRANGEMENT)	TATA spare parts
285126205441	2ND SPEED GEAR(STOPPER ARRANGEMENT)	TATA spare parts
285126205444	1ST SPEED GEAR (STOPPER ARRANGEMENT)	TATA spare parts
285126205445	2ND SPEED GEAR (STOPPER ARRANGEMENT)	TATA spare parts
285126205446	GEAR;1ST SPEED;MAIN SHAFT	TATA spare parts
285126205447	GEAR;2ND SPEED;MAIN SHAFT	TATA spare parts
285126205450	REV GEAR & SHIFTER SLEEVE;1ST/2ND SPEED	TATA spare parts
285126205451	GEAR 2ND SPEED (STOPPER ARRANGEMENT)	TATA spare parts
285126205452	GEAR 1ST SPEED (STOPPER ARRANGEMENT)	TATA spare parts
285126205454	"GEAR,2ND SPEED (STOPPER ARRANGEMENT)"	TATA spare parts
285126205465	SPEED SENSING WHEEL	TATA spare parts
285126205466	GEAR 1ST SPEED	TATA spare parts
285126205467	GEAR 2ND SPEED	TATA spare parts
285126205468	REV GEAR/SHIFTER SLEEVE 1ST/2ND SPEED	TATA spare parts
285126205469	SPEED SENSING WHEEL BS6	TATA spare parts
285126205470	GEAR 1ST SPEED BS6	TATA spare parts
285126205471	GEAR 2ND SPEED BS6	TATA spare parts
285126205475	GEAR 1ST SPEED BS6	TATA spare parts
285126205477	GEAR 2ND SPEED MAIN SHAFT BS6-PH2	TATA spare parts
285126205478	GEAR 3RD SPEED MAIN SHAFT BS6-PH2	TATA spare parts
285126205479	GEAR 4TH SPEED MAIN SHAFT BS6-PH2	TATA spare parts
285126205480	GEAR 3RD SPEED MAIN SHAFT BS6-PH2	TATA spare parts
285126205481	GEAR 4TH SPEED MAIN SHAFT BS6-PH2	TATA spare parts
285126206701	PIVOT PIN (5TH SWING LEVER)	TATA spare parts
285126206702	PIVOT PIN BS6	TATA spare parts
285126207701	OIL SEAL-MAIN SHAFT	TATA spare parts
285126207702	OIL SEAL (MAIN SHAFT)	TATA spare parts
285126207801	OIL SEAL-MAIN SHAFT	TATA spare parts

285126207803	OIL SEAL (MAIN SHAFT) 38X48X8 BS1/2/3/4/	TATA spare parts
285126207902	MAIN SHAFT	TATA spare parts
285126207904	MAIN SHAFT	TATA spare parts
285126207908	MAIN SHAFT BS1/2/3/4/6	TATA spare parts
285126207910	MAIN SHAFT	TATA spare parts
285126207912	MAIN SHAFT BS6-PH2	TATA spare parts
285126208001	HEX. SCREW(SPEEDO LOCK PLATE)	TATA spare parts
285126208201	BREATHER TUBE	TATA spare parts
285126208203	BRACKET (GEAR BOX MOUNTING)	TATA spare parts
285126208204	BRACKET (GEARBOX MOUNTING)	TATA spare parts
285126208601	SPACER-1ST GEAR	TATA spare parts
285126208602	SPACER (5 TH GEAR)	TATA spare parts
285126208603	SPACER-MAINSHAFT	TATA spare parts
285126208604	LOCK PLATE (5TH SPEED GEAR)	TATA spare parts
285126208605	OIL DEFLECTOR	TATA spare parts
285126208607	OIL DEFLECTOR FOR LH SPEEDO BS4	TATA spare parts
285126208613	SPACER MAIN SHAFT BS6-PH2	TATA spare parts
285126209901	SPEEDO ADAPTOR	TATA spare parts
285126209902	CARRIER (1/2 SPEED)	TATA spare parts
285126209903	SPEEDO ADAPTOR	TATA spare parts
285126209904	SPEEDO ADAPTOR	TATA spare parts
285126250106	ASSY GEAR CASE COVER FRONT	TATA spare parts
285126253101	DEEP GROOVE BALL BRG. D/S&M/S BS1-6	TATA spare parts
285126253102	ROLLER BEARING-DRIVE SHAFT	TATA spare parts
285126253103	DEEP GROOVE BALL BRG D/S&M/S	TATA spare parts
285126253106	ROLLER BEARING (DRIVE SHAFT) BS6	TATA spare parts
285126253801	GEAR CASE COVER FRONT BS2/3/4/6	TATA spare parts
285126253802	GEAR CASE COVER FRONT	TATA spare parts
285126253803	GEAR CASE COVER (FRONT)	TATA spare parts
285126253804	GEAR CASE COVER FRONT BS6	TATA spare parts
285126253806	COVER FRONT BS6	TATA spare parts
285126257701	OIL SEAL (INPUT SHAFT)	TATA spare parts
285126257901	DRIVE SHAFT	TATA spare parts
285126257902	ASSY. DRIVE SHAFT(RAT 9.19) BS2/3/4	TATA spare parts
285126257903	DRIVE SHAFT	TATA spare parts
285126257904	DRIVE SHAFT	TATA spare parts
285126257905	DRIVE SHAFT ACE LHD PETROL BS6	TATA spare parts
285126257909	DRIVE SHAFT BS6	TATA spare parts
285126257910	DRIVE SHAFT BS6	TATA spare parts
285126258601	SPACER (DRIVE SHAFT)-2.2 THK.	TATA spare parts
285126258602	SPACER (DRIVE SHAFT) - 2.25 THK.	TATA spare parts
285126258603	SPACER (DRIVE SHAFT) - 2.3 THK.	TATA spare parts
285126258604	SPACER (DRIVE SHAFT) - 2.35 THK.	TATA spare parts
285126300102	ASSY.OIL SPLASHER	TATA spare parts
285126300120	SUB ASSY COUNTER SHAFT	TATA spare parts
285126300123	SUB ASSY COUNTERSHAFT	TATA spare parts
285126300124	SUB ASSY COUNTERSHAFT	TATA spare parts

285126300125	SUBASSY COUNTERSHAFT	TATA spare parts
285126300127	ASSY. COUNTER SHAFT BS3/4/6	TATA spare parts
285126300137	SUB ASSY COUNTER SHAFT	TATA spare parts
285126300149	COUNTER SHAFT ASSY	TATA spare parts
285126303102	CYLINDRICAL ROLLER BEARING	TATA spare parts
285126303104	CYLINDRICAL ROLLER BEARING BS6-PH2	TATA spare parts
285126304301	C TYPE CIRCLIP-2.5 THK. COUNTER SHAFT	TATA spare parts
285126304302	C TYPE CIRCLIP-2.6 THK. COUNTER SHAFT	TATA spare parts
285126304303	C TYPE CIRCLIP-2.7 THK. COUNTER SHAFT	TATA spare parts
285126304304	CTYPE CIRCLIP-2.82 THK. COUNTER SHAFT	TATA spare parts
285126304306	C TYPE CIRCLIP FOR COUNTER SHAFT	TATA spare parts
285126304307	C'TYPE CIRCLIP COUNTER SHAFT	TATA spare parts
285126305404	FIFTH GEAR (COUNTER SHAFT)	TATA spare parts
285126305406	5TH GEAR COUNTER SHAFT	TATA spare parts
285126305408	3RD GEAR (30 TEETH) - COUNTER SHAFT	TATA spare parts
285126305409	CONSTANT MESH GEAR (34/25) - COUNTER SHA	TATA spare parts
285126305410	3RD GEAR (32 TEETH) - COUNTER SHAFT	TATA spare parts
285126305411	CONSTANT MESH GEAR (37/24) - COUNTER SHA	TATA spare parts
285126305413	5TH GEAR ON COUNTER SHAFT	TATA spare parts
285126305418	GEAR 5TH SPEED COUNTER SHAFT	TATA spare parts
285126306305	SPACER COUNTER SHAFT BS6-PH2	TATA spare parts
285126307904	COUNTER SHAFT	TATA spare parts
285126307906	COUNTER SHAFT	TATA spare parts
285126307907	COUNTER SHAFT	TATA spare parts
285126307908	COUNTER SHAFT - TCIC	TATA spare parts
285126307911	COUNTER SHAFT - DEEPER RATIO	TATA spare parts
285126307913	COUNTER SHAFT	TATA spare parts
285126307918	COUNTER SHAFT	TATA spare parts
285126307939	COUNTER SHAFT BS6-PH2	TATA spare parts
285126307943	COUNTER SHAFT BS6-PH2	TATA spare parts
285126353101	NEEDLE BUSH-SKEWED	TATA spare parts
285126355401	REVERSE IDLER GEAR	TATA spare parts
285126355402	REVERSE IDLER GEAR	TATA spare parts
285126355404	REVERSE IDLER GEAR	TATA spare parts
285126357901	REVERSE IDLER GEAR SHAFT	TATA spare parts
285126357902	REVERSE IDLER SHAFT	TATA spare parts
285126403801	COVER PLATE PTO	TATA spare parts
285126513701	FORK-1ST/2ND SPEED	TATA spare parts
285126513702	FORK-3RD/4TH SPEED	TATA spare parts
285126513703	SWING FORK (CASTING)	TATA spare parts
285126513704	FORK 1ST/2ND SPEED	TATA spare parts
285126513705	SHIFTER FORK 1ST & 2ND SPEED AL VERSION	TATA spare parts
285126513801	SHIFTER FORK 3RD & 4TH SPEED AL VERSION	TATA spare parts
285126515101	DOG (5 TH SHIFTER SHAFT)	TATA spare parts
285126515103	SHIFTER DOG (5TH/ REV. SPEED)	TATA spare parts
285126515104	SHIFTER DOG-3 RD/4 TH SPEED	TATA spare parts
285126515106	DOG-LEVER REV.IDLER	TATA spare parts

285126515107	SHIFTER DOG-REV.SPEED	TATA spare parts
285126515108	DOG-REV.LIGHT SWITCH	TATA spare parts
285126515110	DOG (LEVER REVERSE IDLER)	TATA spare parts
285126515111	INTERLOCK FINGER (5/R)	TATA spare parts
285126515116	SHIFTER DOG - 5TH/REVERSE SPEED	TATA spare parts
285126515117	SHIFTER DOG - 3RD/4TH SPEED	TATA spare parts
285126515118	DOG REVERSE LIGHT SWITCH BS6	TATA spare parts
285126515119	DOG LEVER REVERSE IDLER BS6-PH2	TATA spare parts
285126516001	PIVOT LEVER-FOR REVERSE GEAR	TATA spare parts
285126516003	PIVOT LEVER (FOR REVERSE GEAR)	TATA spare parts
285126516701	PIVOT PIN-ON LEVER FOR R.I.SHIFTING	TATA spare parts
285126516702	SLIDING KEY (5TH SWING LEVER)	TATA spare parts
285126516703	SHIFTER PAD	TATA spare parts
285126516705	SHIFTER PAD(1ST/2ND/3RD/4TH SPEED)	TATA spare parts
285126516706	SLIDING KEY (5TH SWING LEVER)	TATA spare parts
285126518701	SPRING (INTERLOCK FINGER)	TATA spare parts
285126518702	SPRING-DETENT (TOP COVER)	TATA spare parts
285126518703	SPRING DETENT	TATA spare parts
285126700109	ASSY.LEVER-SEL/SHIFTING	TATA spare parts
285126700112	ASSY. TOP COVER BS2/3/4	TATA spare parts
285126700120	ASSY. SELECTION SHAFT	TATA spare parts
285126700122	ASSY. LEVER (SELECTION)	TATA spare parts
285126700123	ASSY. SHIFTER SHAFT (TOP COVER)	TATA spare parts
285126700124	ASSY. TOP COVER	TATA spare parts
285126700128	ASSY.SEL/SHIFTER SHAFT (TOP COVER)	TATA spare parts
285126700129	ASSY. TOP COVER	TATA spare parts
285126700131	ASSY TOP COVER FOR CNG	TATA spare parts
285126700150	SELECTOR LEVER ASSY	TATA spare parts
285126700151	SELECTOR SHIFTER SHAFT ASSY	TATA spare parts
285126700152	SHIFTER SHAFT ASSY	TATA spare parts
285126700153	ASSY. TOP COVER BS1/3/4	TATA spare parts
285126700154	ASSY. SEL./SHIFTER SHAFT (TOP COVER)	TATA spare parts
285126700155	ASSY. TOP COVER BS2/3/4	TATA spare parts
285126700156	TOP COVER ASSY	TATA spare parts
285126700157	COVER ASSY TOP	TATA spare parts
285126700169	LEVER ASSY SELECTION	TATA spare parts
285126700170	SHIFTER LEVER ASSY	TATA spare parts
285126700171	COVER ASSY TOP BS6	TATA spare parts
285126700172	COVER ASSY TOP	TATA spare parts
285126700175	COVER ASSY TOP	TATA spare parts
285126700176	COVER ASSY TOP BS6	TATA spare parts
285126700182	ANGLE BS6	TATA spare parts
285126700183	LEVERASSYSELECTION BS6	TATA spare parts
285126700185	COVERASSYTOP BS6	TATA spare parts
285126700188	COVER ASSY TOP BS6-PH2	TATA spare parts
285126700189	SHIFTER SHAFT ASSY BS6-PH2	TATA spare parts
285126703001	NEEDLE ROLLER-INTERLOCK	TATA spare parts

285126703101	NEEDLE BUSH-TOP COVER	TATA spare parts
285126703802	TOP COVER-SHIFTING	TATA spare parts
285126703804	TOP COVER (SHIFTING)	TATA spare parts
285126703805	TOP COVER (SHIFTING)	TATA spare parts
285126703806	TOP COVER (SHIFTING)	TATA spare parts
285126703807	TOP COVER FOR CNG	TATA spare parts
285126705101	FINGER-SEL/SHIFTING	TATA spare parts
285126705102	SHIFTING FINGER	TATA spare parts
285126705105	FINGER SHIFTING	TATA spare parts
285126705109	SHIFTING FINGER	TATA spare parts
285126706002	LEVER (SELECTION)	TATA spare parts
285126706704	PIN (5/R INTERLOCK)	TATA spare parts
285126706705	PIN (SELECTION)	TATA spare parts
285126707701	RUBBER BELLOW (SELECTION LEVER)	TATA spare parts
285126707703	RUBBER BELLOW-SEL/SHIFT SHAFT	TATA spare parts
285126707704	RUBBER BELOW (SEL/SHIFT SHAFT)	TATA spare parts
285126707707	RUBBER BELLOW	TATA spare parts
285126707709	BELLOW BS6	TATA spare parts
285126707801	DOUBLE LIP OIL SEAL	TATA spare parts
285126707907	SHIFTER SHAFT-1/2 SPEED	TATA spare parts
285126707908	SHIFTER SHAFT-3/4 SPEED	TATA spare parts
285126707909	SHIFTER SHAFT-REVERSE	TATA spare parts
285126707911	SHIFTER SHAFT (FIFTH SPEED)	TATA spare parts
285126707912	SHIFTER SHAFT (REVERSE)	TATA spare parts
285126707913	SHIFTER SHAFT (3/4 SPEED)	TATA spare parts
285126707914	SHIFTER SHAFT (1ST/2ND SPEED)	TATA spare parts
285126707916	SHIFTER SHAFT (FIFTH SPEED)	TATA spare parts
285126707917	SHIFTER SHAFT (REVERSE)	TATA spare parts
285126707919	SHIFTER SHAFT (1ST/2ND SPEED)	TATA spare parts
285126707922	SHIFTER SHAFT;1ST/2ND SPEED	TATA spare parts
285126707923	SHIFTER SHAFT (3/4 SPEED) BS6	TATA spare parts
285126707936	SHIFTER SHAFT	TATA spare parts
285126707938	SHIFTER SHAFT - 1ST/2ND SPEED	TATA spare parts
285126707939	SHIFTER SHAFT REVERSE SPEED BS6-PH2	TATA spare parts
285126707940	SHIFTER SHAFT BS6-PH2	TATA spare parts
285126707941	SHIFTER SHAFT BS6-PH2	TATA spare parts
285126707942	SHIFTER SHAFT BS6-PH2	TATA spare parts
285126707943	SHIFTER SHAFT 3RD/4TH SPEED	TATA spare parts
285126708202	SEALING CUP-TOP COVER	TATA spare parts
285126708203	WASHER-TOP COVER	TATA spare parts
285126708204	WASHER	TATA spare parts
285126708601	SPACER-TOP COVER	TATA spare parts
285126708602	SPACER-SHIFTER SHAFT	TATA spare parts
285126708603	SPACER-REV.SHIFTER SHAFT	TATA spare parts
285126708604	SPACER (3/4 SHIFTER SHAFT)	TATA spare parts
285126708605	SPACER (1/2 SHIFTER SHAFT)	TATA spare parts
285126708606	SLEEVE	TATA spare parts

285126708612	SLEEVE	TATA spare parts
285126708614	SPACER MAIN SHAFT BS6-PH2	TATA spare parts
285126708619	WASHER BS6	TATA spare parts
285126708705	SPRING SELECTION 1/2	TATA spare parts
285126708706	SPRING SELECTION 1/2	TATA spare parts
285126708707	SPRING SELECTION-REVERSE	TATA spare parts
285126708708	SPRING SELECTION (REVERSE)	TATA spare parts
285126708710	SPRING (SELECTION)	TATA spare parts
285126709204	WASHER	TATA spare parts
285126709205	WASHER	TATA spare parts
285126710101	BRACKETASSYWITHBOSS BS6	TATA spare parts
285126800122	SUB ASSY.GEAR SHIFT LEVER-UPPER PART	TATA spare parts
285126800123	SUB ASSY.GEAR SHIFT LEVER-LOWER PART	TATA spare parts
285126800125	ASSY. CROSS LINK BS2/3/4	TATA spare parts
285126800135	ASSY. SHIFT LINK W/CROSS LINK BS2/3/4	TATA spare parts
285126800137	ASSY. SHIFT LINK BS2/3/4	TATA spare parts
285126800138	ASSY.GEAR SHIFT LEVER-UPPER	TATA spare parts
285126800139	GEAR SHIFTER MECHANISM W/CABLES BS1/3/4	TATA spare parts
285126800151	ASSY. BELLOW (WITH K BS6	TATA spare parts
285126800152	BRACKET (CABLE ANCHORING)	TATA spare parts
285126800154	ASSY. GEAR SHIFT LEVER KNOB	TATA spare parts
285126800154AY	ASSY. GEAR SHIFT LEVER KNOB	TATA spare parts
285126800155	ASSY. CABLE SHIFTER BS1/3/4	TATA spare parts
285126800156	ASSY. CABLE SELECTOR BS1/3/4	TATA spare parts
285126800157	ASSY. SPHERICAL END TERMINAL	TATA spare parts
285126800158	ASSY. SHIFT LINK	TATA spare parts
285126800160	SUB ASSY. SHIFT LINK WITH CROSS LINK	TATA spare parts
285126800161	ASSY GEAR SHIFT LINKAGE COMPLETE	TATA spare parts
285126800162	ASSY.GEAR SHIFT LEVER (UPPER)	TATA spare parts
285126800171	SUB ASSY. BELLOW WITH BOOT RING	TATA spare parts
285126800171ZY	SUB ASSY. BELLOW WITH BOOT RING	TATA spare parts
285126800171ZZ	SUB ASSY. BELLOW WITH BOOT RING	TATA spare parts
285126800178	GEAR SHIFT ASSY WITH CABLE ASSY	TATA spare parts
285126800179	ASSY CABLE SHIFTER	TATA spare parts
285126800180	ASSY CABLE SELECTOR	TATA spare parts
285126800189	ASSY BELLOW (WITH KNOB AND BOOT RING)	TATA spare parts
285126800203	GEAR SHIFT MECHANISM WITH CABLES S/ACE	TATA spare parts
285126800204	GSM FOR VENTURE/SUPERACE BSIV DICOR	TATA spare parts
285126800205	ASSY CABLE SHIFTER SUPER ACE RHD DICOR B	TATA spare parts
285126800206	ASSY. CABLE SELECTOR SUPER ACE RHD DICOR	TATA spare parts
285126800207	ASSY CABLE SHIFTER DICOR BS 4 - RHD	TATA spare parts
285126800208	ASSY. CABLE SELECTOR DICOR BS 4 - RHD	TATA spare parts
285126800209	ASSY CABLE ANCHORING BRACKET	TATA spare parts
285126800211	ASSY CABLE ANCHORING BKT WITH HOOK	TATA spare parts
285126800214	ASSY GEAR SHIFT LEVER KNOB(5 SPEED)	TATA spare parts
285126800216	ASSY GEAR SHIFT LEVER KNOB (4 SPEED)	TATA spare parts
285126800216C7	GRANIT_BLACK-ASSY GEAR SHIFT LEVER KNOB	TATA spare parts

285126800220	ASSY BRACKET CABLE GUIDE	TATA spare parts
285126800223	ASSY HOOK & BKT (LONG MEMBER)	TATA spare parts
285126800225	ASSY HOOK & BRACKET(FRONT HALF)	TATA spare parts
285126800226	ASSY BRACKET & WELD NUT LONG MEMBER	TATA spare parts
285126800232	ASSY GSL CABLE HOOK & BRKT BS6	TATA spare parts
285126800235	GEAR SHIFT LEVER ASSY	TATA spare parts
285126800237	HOOK ASSY WITH BRACKET FRONT HALF	TATA spare parts
285126800238	GSM WITH CABLES ACE DICOR BS3/4	TATA spare parts
285126800239	ASSY. CABLE SHIFTER ACE DICOR BS3/4	TATA spare parts
285126800240	ASSY. CABLE SELECTOR ACE DICOR BS3/4/6	TATA spare parts
285126800242	GSM WITH CABLES FOR SUPERACE LHD PETROL	TATA spare parts
285126800243	ASSY CABLE SHIFTER	TATA spare parts
285126800244	ASSY CABLE SELECTOR	TATA spare parts
285126800246	ASSY.GEAR SHIFT LEVER W/O KNOB (UPPER)	TATA spare parts
285126800262	GEAR SHIFT CABLE	TATA spare parts
285126800263	CABLE ASSY GEAR SELECT	TATA spare parts
285126800265	HOOK ASSY WITH BRACKET	TATA spare parts
285126800268	CABLE ASSY GEAR SHIFTER	TATA spare parts
285126800269	GEAR SHIFT ASSY WITH CABLE ASSY	TATA spare parts
285126800271	GEAR SHIFT UNIT	TATA spare parts
285126800272	CABLE ASSY GEAR SHIFTER	TATA spare parts
285126800273	ASSY. GEAR SHIFT MECHANISM W/CABLE BS3/4	TATA spare parts
285126800277	HOOK ASSY WITH BRACKET	TATA spare parts
285126800278	HOOK ASSY WITH BRACKET	TATA spare parts
285126800279	CABLE ASSY SELECTION/SHIFTING	TATA spare parts
285126800284	GEAR SHIFT UNIT ASSY WITH CABLE BS6	TATA spare parts
285126800285	CABLE ASSY BS6	TATA spare parts
285126800287	CABLE ASSY GEAR SHIFTER BS6	TATA spare parts
285126800288	GEAR SHIFT ASSY WITH CABLE ASSY BS6	TATA spare parts
285126800291	GEAR SHIFT LINKAGE ASSY (285126800292) B	TATA spare parts
285126800293	GEAR SHIFT & SELECT CABLE ASSY BS6	TATA spare parts
285126800294	CABLE ASSY GEAR SHIFTER	TATA spare parts
285126800295	GEAR SHIFT ASSY WITH CABLE ASSY	TATA spare parts
285126800296	ANCHOR BRACKET BS6	TATA spare parts
285126800301	HOOK ASSY WITH BRACKET GSL CABLE BS6	TATA spare parts
285126800302	BRACKETASSYCABLEANCHORING BS6	TATA spare parts
285126800303	GEARSHIFTUNITASSYWITHCABLE BS6	TATA spare parts
285126800306	CABLE ASSY GEAR SHIFTER BS6-PH2	TATA spare parts
285126800307	GEAR SHIFT ASSY WITH CABLE ASSY BS6-PH2	TATA spare parts
285126800311	ANCHOR BRACKET BS6	TATA spare parts
285126800318	BRACKET ASSY CABLE GUIDE BS6-PH2	TATA spare parts
285126800319	HOOK ASSY WITH BRACKET FRONT HALF BS6-PH	TATA spare parts
285126800321	GEAR SHIFT UNIT ASSY WITH CABLE BS6	TATA spare parts
285126800323	GEAR SHIFT UNIT ASSY WITH CABLE BS6-PH2	TATA spare parts
285126800325	BRACKET ASSY CABLE ANCHORING BS6	TATA spare parts
285126800329	CABLE ANCHOR BRACKET BS6-PH2	TATA spare parts
285126800334	GEAR SHIFT UNIT ASSY WITH CABLE BS6-PH2	TATA spare parts

285126800338	GEAR SHIFT UNIT ASSY WITH CABLE BS6-PH2	TATA spare parts
285126800339	CABLE ANCHOR BRACKET BS6-PH2	TATA spare parts
285126800340	BELLOW ASSY WITH KNOB & BOOT RING BS6	TATA spare parts
285126800341	SELECTION CABLE ASSY BS6-PH2	TATA spare parts
285126800342	SHIFT CABLE ASSY BS6-PH2	TATA spare parts
285126800343	SELECTION CABLE ASSY BS6-PH2	TATA spare parts
285126800344	SHIFT CABLE ASSY BS6-PH2	TATA spare parts
285126800347	GEAR SHIFT UNIT ASSY WITH CABLE BS6-PH2	TATA spare parts
285126800348	GEAR SHIFT UNIT ASSY WITH CABLE BS6-PH2	TATA spare parts
285126800350	KNOB ASSY WITH BELLOW BS6	TATA spare parts
285126803401	METAL BUSH	TATA spare parts
285126803509	BOSS (ASSY.G.S.LEVER LOWER)	TATA spare parts
285126803801	BRACKET (ENGINE REAR MOUNT LH)	TATA spare parts
285126803802	BRACKET (ENGINE REAR MOUNT RH)	TATA spare parts
285126803805	CABLE ANCHOR BRACKET	TATA spare parts
285126803806	BRACKET B-MOUNT	TATA spare parts
285126804301	SPRING CLIP	TATA spare parts
285126804304	CLIP BS6	TATA spare parts
285126806014	SHIFTER LEVER	TATA spare parts
285126806015	SELECT LEVER	TATA spare parts
285126806018	SHIFTER LEVER SUPER ACE LHD	TATA spare parts
285126806029	SHIFT LEVER - SUPER ACE RHD & BS IV	TATA spare parts
285126806037	GEAR SHIFT LEVER BS6-PH2	TATA spare parts
285126806308	CAP BS6	TATA spare parts
285126806310	EYE END SNAP	TATA spare parts
285126806712	PIN	TATA spare parts
285126807501	RUBBER BUSH	TATA spare parts
285126807502	GROMMET	TATA spare parts
285126807505	GROMMET	TATA spare parts
285126807702	RUBBER BELLOW-LOWER	TATA spare parts
285126807703	RUBBER BELLOW-GEAR SHIFT LEVER	TATA spare parts
285126807704	BELLOW (CONSOLE)	TATA spare parts
285126807705	O RING	TATA spare parts
285126807706	O RING	TATA spare parts
285126807707	BODY	TATA spare parts
285126807708	LOWER HALF SHELF	TATA spare parts
285126807709	UPPER HALF SHELF	TATA spare parts
285126807710	SLIDING BLOCK	TATA spare parts
285126807726	BELLOW GEAR SHIFT LEVER BS6	TATA spare parts
285126807728	BODY BS6-PH2	TATA spare parts
285126808001	SELF TAPPING SCREW	TATA spare parts
285126808002	SELF TAPPING SCREW	TATA spare parts
285126808003	SOCKET HEAD HEX BOLT	TATA spare parts
285126808213	CUP OUTER (BALL SEAT)	TATA spare parts
285126808214	CUP INNER (BALL SEAT)	TATA spare parts
285126808215	BRACKET-CROSS LINK	TATA spare parts
285126808229	CLAMP (CABLE ROUTING)	TATA spare parts



285126808230	COVER	TATA spare parts
285126808231	SHROUD FOR GROMMET	TATA spare parts
285126808232	BRACKET (CROSS LINK)	TATA spare parts
285126808236	CABLE GUIDE CLAMP	TATA spare parts
285126808238	CABLE GUIDE BRACKET	TATA spare parts
285126808264	COVER - SUPER ACE RHD& BS IV	TATA spare parts
285126808274	CABLE GUIDE HOOK (CROSS MEMBER)	TATA spare parts
285126808279	BRACKET CABLE GUIDE(LONG MEMBER)	TATA spare parts
285126808702	BIASING SPRING	TATA spare parts
285126830106	HOOK ASSY WITH BRACKET FRONT HALF BS6	TATA spare parts
285126830107	HOOK ASSY WITH BRACKET FRONT HALF BS6	TATA spare parts
285126830108	HOOK ASSY WITH BRACKET FRONT HALF BS6	TATA spare parts
285126830109	HOOK ASSY WITH BRACKET BS6	TATA spare parts
285126830110	HOOK ASSY WITH BRACKET	TATA spare parts
285126830111	HOOK ASSY WITH BRACKET BS6	TATA spare parts
285126830112	HOOK ASSY WITH BRACKET BS6	TATA spare parts
285126830113	HOOK ASSY WITH BRACKET BS6	TATA spare parts
285126830118	HOOK ASSY WITH BRACKET BS6	TATA spare parts
285126830119	HOOKASSYWITHBRACKETFRONTHALF BS6	TATA spare parts
285126830122	HOOK ASSY WITH BRACKET BS6	TATA spare parts
285126830125	HOOK ASSY WITH BRACKET BS6	TATA spare parts
285126830126	HOOK ASSY WITH BRACKET BS6	TATA spare parts
285126830127	HOOK ASSY WITH BRACKET BS6-PH2	TATA spare parts
285126830128	HOOK ASSY WITH BRACKET BS6-PH2	TATA spare parts
285126830129	HOOK ASSY WITH BRACKET BS6-PH2	TATA spare parts
285126830130	HOOK ASSY WITH BRACKET BS6-PH2	TATA spare parts
285126836008	SELECT CABLE	TATA spare parts
285126836009	SHIFT CABLE	TATA spare parts
285126836021	SELECTION&CABLE&ASSY BS6	TATA spare parts
285126836022	SHIFT CABLE ASSY BS6	TATA spare parts
285126837702	GEAR SHIFTER HOUSING	TATA spare parts
285126860103	BELLOW ASSY WITH BOOT RING	TATA spare parts
285126860103C7	GRANIT_BLACK-BELLOW ASSY WITH BOOT RING	TATA spare parts
285126860103CX	GRANIT_BLACK-BELLOW ASSY WITH BOOT RING	TATA spare parts
285126860104C7	GRANIT_BLACK-BELLOW ASSY WITH KNOB & BOC	TATA spare parts
285126860106	BELLOW ASSY WITH BOOT RING	TATA spare parts
285126860107	GEAR SHIFT KNOB ASSY	TATA spare parts
285126860109	GEAR SHIFT KNOB ASSY	TATA spare parts
285126860109C7	GRANIT_BLACK-GEAR SHIFT KNOB ASSY	TATA spare parts
285126860110	KNOB ASSY WITH BELLOW BS6	TATA spare parts
285126860110C7	GRANIT_BLACK-KNOB ASSY WITH BELLOW BS6	TATA spare parts
285126878208	DETENT PLATE BS6	TATA spare parts
285126878209	GASKET DETENT PLATE BS6	TATA spare parts
285149995311	BEND HEAT SHIELD	TATA spare parts
285226010101	ASSY G380-5/5.19GBOX W/O PTO PROV CPLFLG	TATA spare parts
285226010102	ASSY G380-5/5.53 GBOX W/O PTO PROV CPLFG	TATA spare parts
285226010103	ASSY G380-5/5.19 GBOX DIRECT SHIFT	TATA spare parts

285226010104	ASSY G380 5/4.9 DIRECT SHIFT CPL FLG	TATA spare parts
285226010108	ASSY G380-5/5.19 GEARBOX WITH PTO SFC	TATA spare parts
285226010113	ASSY G380-5/6.03GBOX W/O PTO PROV C/F LP	TATA spare parts
285226010114	ASSY. G380-5/5.53GBOX W/PTO P	TATA spare parts
285226010117	ASSY G380-5/5.19A GBOX 3RD/4TH SHALLOW W	TATA spare parts
285226010119	ASSLY. G380-5/5.53 GBOX PTO PROV. SFC4	TATA spare parts
285226010120	GEAR BOX G380-5/5.53 W/O PTO SFC407 BSII	TATA spare parts
285226010121	GEAR BOX G380-5/5.53 W/O PTO SFC407(4X4)	TATA spare parts
285226010122	ASSY G380-5/6.01 GBOX PTO PROV SFC-407	TATA spare parts
285226010123	ASSEMBLY GEAR BOX G380-5/5.53	TATA spare parts
285226010124	ASSEMBLY GEAR BOX G380-5/6.01	TATA spare parts
285226010127	GEAR BOX G380-5/6.01 SFC PTO PR CL280 BS	TATA spare parts
285226010128	GEAR BOX G380 5/6.01 SFC W/PTO CL280 AND	TATA spare parts
285226010131	ASSY. G380-5/5.53 SFC BS-III W/O PTO 280	TATA spare parts
285226010133	G380-5/5.53 SFC407 W/O PTO	TATA spare parts
285226010139	GEAR BOX ASSY	TATA spare parts
285226010144	GEAR BOX ASSY	TATA spare parts
285226100102	ASSY GEAR BOX HOUSING(WITH PTO OPENING)	TATA spare parts
285226100105	BRACKET ASSY	TATA spare parts
285226103701	GEARBOX HOUSING W/O PTO OPENING	TATA spare parts
285226103702	GEARBOX HOUSING	TATA spare parts
285226103704	GEAR BOX HOUSING	TATA spare parts
285226103801	GEARBOX HOUSING	TATA spare parts
285226105301	GASKET	TATA spare parts
285226200119	SUBASSY 3RD GEAR (LASER WELD 5.19A/5.19C	TATA spare parts
285226200121	SUBASSY 4THGEAR LASERWELD5.19C/5.53/6.01	TATA spare parts
285226203101	NEEDLE CAGE 3RD/4TH GEAR	TATA spare parts
285226203102	NEEDLE CAGE 1ST/2ND GEAR	TATA spare parts
285226203103	DEEP GROOVE BALL BRG	TATA spare parts
285226203104	DEEP GROOVE BALL BRG	TATA spare parts
285226203105	NEEDLE CAGE 1ST/2ND GEAR	TATA spare parts
285226203106	NEEDLE CAGE 3RD/4TH GEAR	TATA spare parts
285226203107	NEEDLE CAGE 3RD/4TH GEAR	TATA spare parts
285226203108	NEEDLE CAGE 1ST/2ND GEAR	TATA spare parts
285226203401	COLLAR BUSH? 4TH GEAR BS2/3/4	TATA spare parts
285226203404	SENSING WHEEL CONTACTLESS SPEEDOMETER	TATA spare parts
285226203702	COVER HOUSING REAR	TATA spare parts
285226203801	SYNCHRONISING CONE (82 DIA-THRD'D BRASS)	TATA spare parts
285226203802	SYNCHRONISING CONE (96 DIA-THRD'D BRASS)	TATA spare parts
285226204601	SYNCHRO RING (1ST SPEED WITH OIL GROOVE)	TATA spare parts
285226204602	SYNCHRO RING (2ND/3RD W/OIL GROOVE)BS2-4	TATA spare parts
285226204603	SYNCHRO RING 4TH WITH OIL GROOVES	TATA spare parts
285226204604	ENGAGING GEAR 1ST SPEED	TATA spare parts
285226204605	ENGAGING GEAR 2ND/3RD SPEED	TATA spare parts
285226204606	ENGAGING GEAR 4TH/5TH SPEED	TATA spare parts
285226204607	SHIFTER SLEEVE 1ST SPEED	TATA spare parts
285226204608	SHIFTER SLEEVE 2/3/4/5TH SPEED BS2/3/4	TATA spare parts

285226204611	SYNCHRONISING CONE 82 DIA.THR. BS2/3/4	TATA spare parts
285226204612	SYNCHRO CONE 96 DIA. THREADED BS2/3/4	TATA spare parts
285226204616	SYNCHRO RING( LASER WELD 1ST SPEED )	TATA spare parts
285226204617	SYNCHRO RING LASER WELD (2ND/3RD SPEED)	TATA spare parts
285226204618	SYNCHRO RING (LASER WELD 4TH SPEED)	TATA spare parts
285226205401	HELICAL GEAR 1ST SPEED M/SHAFT	TATA spare parts
285226205402	HELICAL GEAR 2ND SPEED M/SHAFT BS2/3/4	TATA spare parts
285226205403	HELICAL GEAR 3RD SPEED M/SHAFT	TATA spare parts
285226205404	HELICAL GEAR 4TH SPEED M/SHAFT	TATA spare parts
285226205405	REVERSE GEAR MAIN SHAFT BS2/3/4	TATA spare parts
285226205406	HELICAL GEAR (3RD SPEED M/SHAFT)	TATA spare parts
285226205407	HELICAL GEAR (4TH SPEED M/SHAFT)	TATA spare parts
285226205408	HELICAL GEAR (4TH SPEED M/SHAFT)(5.19A)	TATA spare parts
285226205409	HELICAL GEAR 1ST SPEED (LASER WELD)	TATA spare parts
285226205410	HELICAL GEAR 2ND SPEED( LASER WELD )	TATA spare parts
285226205412	HELICAL 3RD GEAR(LASER 5.19A/5.19C/5.53)	TATA spare parts
285226205414	HELICAL GEAR 4SP(LASER 5.19C/5.53/6.01)	TATA spare parts
285226207801	PTFE SEAL 68*48*10/LH MAIN SHAFT	TATA spare parts
285226207901	MAIN SHAFT G380 BS2/3/4	TATA spare parts
285226207902	MAIN SHAFT	TATA spare parts
285226208001	FLANGED SCREW WITH SERRATIONS	TATA spare parts
285226208601	SPACER 3.65 THK	TATA spare parts
285226208602	SPACER 3.70 THK	TATA spare parts
285226208603	SPACER 3.75 THK	TATA spare parts
285226208604	SPACER 3.80 THK	TATA spare parts
285226208605	SPACER 3.85 THK	TATA spare parts
285226208606	SPACER 3.90 THK	TATA spare parts
285226208607	SPACER 3.95 THK	TATA spare parts
285226208608	SPACER 4.00 THK	TATA spare parts
285226208609	SPACER 4.05 THK	TATA spare parts
285226208610	SPACER 4.10 THK	TATA spare parts
285226208611	SPACER 4.15 THK	TATA spare parts
285226208612	SPACER 4.20 THK	TATA spare parts
285226208613	SPACER 4.25 THK	TATA spare parts
285226208614	SPACER 4.30 THK	TATA spare parts
285226208615	SPACER 4.35 THK	TATA spare parts
285226208616	SPACER 4.40 THK	TATA spare parts
285226208617	SPACER 4.45 THK	TATA spare parts
285226208701	RETENTION SPRING	TATA spare parts
285226209902	CARRIER	TATA spare parts
285226250101	ASSY COVER FRONT	TATA spare parts
285226253101	CYLINDRICAL ROLLER BRG.NUP	TATA spare parts
285226253102	CYLINDRICAL ROLLER BRG.NUP	TATA spare parts
285226253104	CYLINDRICAL ROLLER BRG(NUP308EN)	TATA spare parts
285226253701	GEAR BOX HSG FRONT COVER	TATA spare parts
285226254601	SYNCHRO RING DRIVE SHAFT	TATA spare parts
285226254602	SYNCHRO RING-DRIVE SHAFT (W/O OIL GROOVE	TATA spare parts

285226257801	PTFE SEAL 57*39*9/RH DRIVE SHAFT	TATA spare parts
285226257901	DRIVE SHAFT	TATA spare parts
285226257902	DRIVE SHAFT (5.53)	TATA spare parts
285226257903	DRIVE SHAFT (5.19 RATIO)	TATA spare parts
285226257904	DRIVE SHAFT (6.03)	TATA spare parts
285226257905	DRIVE SHAFT(5.53)(280 DIA CLUTCH)	TATA spare parts
285226257906	DRIVE SHAFT(6.01)(280 DIA CLUTCH)	TATA spare parts
285226258601	SPACER DRIVE SHAFT	TATA spare parts
285226305401	4TH GEAR COUNTER SHAFT	TATA spare parts
285226305402	CONSTANT MESH GEAR	TATA spare parts
285226305403	4TH GEAR (COUNTER SHAFT)	TATA spare parts
285226305404	CONSTANT MESH GEAR (5.53)	TATA spare parts
285226305405	CONSTANT MESH GEAR	TATA spare parts
285226305406	CONSTANT MESH GEAR(6.03)	TATA spare parts
285226305407	HELICAL GEAR 4TH SPEED (5.19A)	TATA spare parts
285226307901	COUNTER SHAFT (G380) BS3	TATA spare parts
285226307902	COUNTER SHAFT 5.53 (G-380) BS2/3/4	TATA spare parts
285226353101	NEEDLE CAGE SKEWED	TATA spare parts
285226355401	REVERSE IDLER GEAR BS2/3/4	TATA spare parts
285226357901	SHAFT REVERSE IDLER	TATA spare parts
285226358601	SPACER R.I.GEAR	TATA spare parts
285226400101	ASSY PTO COMP W/O LEVER(G380-5/5.19 4.9)	TATA spare parts
285226400102	ASSY PTO COMP W/O LEVER(G380-5/5.53)	TATA spare parts
285226405402	INTERMEDIATE GEAR	TATA spare parts
285226407802	OIL SEAL	TATA spare parts
285226510101	SUB ASSY INTERMEDIATE LEVER	TATA spare parts
285226513801	SHIFTER FORK 1ST SPEED	TATA spare parts
285226513802	SHIFTER FORK 2ND/3RD SPEED	TATA spare parts
285226513803	SHIFTER FORK 4TH/5TH SPEED	TATA spare parts
285226515101	SHIFTER DOG 4TH/5TH SPEED	TATA spare parts
285226515901	SLIDING KEY	TATA spare parts
285226700110	KNOB	TATA spare parts
285226706701	PRESSURE PIECE	TATA spare parts
285226707101	CHECK PLATE (GEAR CASE COVER)	TATA spare parts
285226707901	SHIFTER SHAFT 1ST SPEED	TATA spare parts
285226707902	SHIFTER SHAFT 2/3 SPEED	TATA spare parts
285226707903	SHIFTER SHAFT 4/5 SPEED	TATA spare parts
285226707904	SHIFTER SHAFT (1ST SPEED LP)	TATA spare parts
285226707905	SHIFTER SHAFT (REVERSE SPEED)	TATA spare parts
285226707906	SHIFTER SHAFT REVERSE SPEED (LP)	TATA spare parts
285226707911	SELECTOR & SHIFTER SHAFT	TATA spare parts
285226707913	SHIFTER SHAFT	TATA spare parts
285226710102	ASSY. GEAR BOX COVER TOP BS3	TATA spare parts
285226710103	GEAR CASE COVER TOP COMPLETE (RHD)	TATA spare parts
285226710122	GEAR CASE COVER TOP (ASSLY LOWER HALF)	TATA spare parts
285226710123	GEAR CASE COVER TOP (ASSLY UPPER HALF)	TATA spare parts
285226713701	SHIFTING FINGER (CABLE SHIFT)	TATA spare parts

285226713702	INTERLOCK FINGER (CABLE SHIFT) BS3/4/6	TATA spare parts
285226713704	"GEAR CASE COVER, TOP (LOWER)"	TATA spare parts
285226713705	GEAR CASE COVER TOP (UPPER)	TATA spare parts
285226717101	STOPPER PLATE (CABLE SHIFT)	TATA spare parts
285226717102	LOCK PLATE	TATA spare parts
285226718702	COMPRESSION SPRING (OUTER)	TATA spare parts
285226800101	ASSY.GEAR SHIFT LEVER RHD	TATA spare parts
285226800107	ASSY. GEAR SHIFT LEVER (RHD)	TATA spare parts
285226800109	GEAR SHIFT LEVER ASSY	TATA spare parts
285226800111	ASSY. GEAR SHIFT LEVER BS2/3/4	TATA spare parts
285226800112	GEAR SHIFT LEVER ASSY.	TATA spare parts
285226800125	GEAR SHIFT LEVER ASSY	TATA spare parts
2852621074DB	PIN	TATA spare parts
285326203108	NEEDLE CAGE (39X45X24) NRB	TATA spare parts
285326253112	NEEDLE CAGE (44X49X24)NRB	TATA spare parts
285326253116	CYL ROLLER BEARING, INPUT SHAFT	TATA spare parts
285326253405	BUSH 5TH GEAR INPUT SHAFT	TATA spare parts
285326253801	SYNCHRO CONE	TATA spare parts
285326254301	SNAP RING	TATA spare parts
285326254617	ENGAGING GEAR (3RD/4TH SPEED)	TATA spare parts
285326254618	SHIFTER SLEEVE (3RD/4TH SPEED&5/6 SPEED)	TATA spare parts
285326254619	ENGAGING GEAR (5TH SPEED & 6TH SPEED)	TATA spare parts
285326257702	OIL SEAL	TATA spare parts
285326303201	COLLARED SCREW	TATA spare parts
285326354801	DOWEL PIN	TATA spare parts
285326519902	DETENT ASSY, SHIFTER SHAFT	TATA spare parts
285426000101	ASSY GEARBOX COMPLETE 4DL NA 5.69 RATIO.	TATA spare parts
285426000102	ASSY GEARBOX COMPLETE 4DL TCIC	TATA spare parts
285426000103	KIT- TATA WINGER GEAR BOX TA-70 BS2/3/4	TATA spare parts
285426000104	ASSY GEARBOX COMPLETE 4DL TCIC-CNG	TATA spare parts
285426000106	ASSY.GEARBOX COMPLETE 4DL NA	TATA spare parts
285426000107	ASSY. GEAR BOX COMP. 4DL TCIC BS3/4	TATA spare parts
285426000108	ASSY. GEAR BOX TA70 2.2 DICOR BS4/6	TATA spare parts
285426000117	ASSY GEARBOX TA-70 WINGER CNG 10.2CR 14	TATA spare parts
285426000121	GEAR BOX ASSY NA WITH CONTECTLESS SPEED	TATA spare parts
285426000122	GEAR BOX ASSY TCIC WITH CONTECTLESS	TATA spare parts
285426000131	GEAR BOX ASSY BS6	TATA spare parts
285426000133	TRANSAXLE ASSY BS6-PH2	TATA spare parts
285426009901	TRANSFER LABEL (OIL SPECS.)	TATA spare parts
285426100103	ASSY.CLUTCH HSG.W/DIFF.COVER (FOR M/C)	TATA spare parts
28542610010320	ASSY CLUTCH HSG W/DIFF COVER	TATA spare parts
285426100104	BOTTOM COVER	TATA spare parts
285426100105	SUB ASSY. REAR HALF W/BUSHES BS2/3/4	TATA spare parts
285426100106	ASSY. CLUTCH HSG.W/DIFF. COVER BS2/3/4	TATA spare parts
285426100107	ASSY. CLUTCH HSG. W/DIFF. COVER BS4	TATA spare parts
285426100115	CLUTCH HSG ASSY WITH DIFFERENTIAL COVER	TATA spare parts
285426103401	BUSH (REAR HALF-SEL.SHFT SHAFT)	TATA spare parts

285426103801	HOUSING FRONT HALF	TATA spare parts
285426103802	HOUSING REAR HALF	TATA spare parts
285426103803	CLUTCH HOUSING	TATA spare parts
285426103804	DIFFERENTIAL COVER (HALF)	TATA spare parts
285426103805	REAR COVER	TATA spare parts
285426103806	CLUTCH HOUSING	TATA spare parts
285426103807	CLUTCH HOUSING(2.2 DICOR)	TATA spare parts
285426103811	REAR COVER CONTACTLESS SPEEDO	TATA spare parts
285426103818	HOUSING FRONT HALF	TATA spare parts
285426104801	DOWEL HOLLOW DIA.13	TATA spare parts
285426104802	DOWEL HOLLOW DIA.11	TATA spare parts
285426105301	GASKET (REAR COVER TO REAR HALF)	TATA spare parts
285426105302	GASKET (REAR HALF TO FRONT HALF)	TATA spare parts
285426105303	GASKET (FRONT HALF TO CL.HSG.)	TATA spare parts
285426105304	GASKET(FRONT HALF BOTTOM COVER PLATE)	TATA spare parts
285426106301	OIL DEFLECTOR	TATA spare parts
285426106302	OIL CATCHER	TATA spare parts
285426107201	DETENT PLUG FORWARD	TATA spare parts
285426107202	DETENT PLUG REVERSE	TATA spare parts
285426107203	OIL LEVEL PLUG (GEAR BOX) BS6	TATA spare parts
285426107801	OIL SEAL(SPEEDO SHAFT)	TATA spare parts
285426107802	'OFFER DRG.'OIL SEAL(SEL/SHIFTER SHAFT)	TATA spare parts
285426107805	OIL SEAL(CROWN WHEEL PINION)	TATA spare parts
285426107806	OIL SEAL(15X24X4.5)	TATA spare parts
285426107807	OIL SEAL (42X64/62X21.2)	TATA spare parts
285426107808	OIL SEAL (8.5X16X6.5)	TATA spare parts
285426108201	CAP(HSG.REAR HALF)	TATA spare parts
285426108202	PLUG (INTERLOCK BORE)	TATA spare parts
285426108203	CAP (HSG FRONT HALF)	TATA spare parts
285426108205	CAP (REAR COVER)	TATA spare parts
285426108206	HOLDER (BELLOW SEL/SHFT SHAFT)	TATA spare parts
285426108208	HOLDER (BELLOW SEL./SHIFTER SHAFT)	TATA spare parts
285426108210	THREADED RING LOCK PLATE.	TATA spare parts
285426200107	ASSY.1ST SP.GEAR (4DL NA)	TATA spare parts
285426200108	ASSY.2ND SP.GEAR (4DL NA)	TATA spare parts
285426200112	ASSY 1ST SPEED GEAR	TATA spare parts
285426200113	ASSY 2ND SPEED GEAR	TATA spare parts
285426203103	CYL.ROLLER BRG.	TATA spare parts
285426203104	D.G.BALL BRG.(25X62.02X17.5)	TATA spare parts
285426203801	SYNCHRO CONE (1/2)	TATA spare parts
285426203803	SYNCHRO CONE(3/4 & 5TH) BS2/3/4	TATA spare parts
285426204301	SNAP RING (LAY SHAFT)	TATA spare parts
285426204302	SNAP RING(MAIN SHAFT-32.3X2.8)	TATA spare parts
285426204303	SNAP RING(MAIN SHAFT-30X3.4)	TATA spare parts
285426204601	ENGAGING GEAR (1/2)	TATA spare parts
285426204602	ENGAGING GEAR (3/4)	TATA spare parts
285426204603	SHIFTER SLEEVE (1/2)	TATA spare parts

285426204604	SHIFTER SLEEVE (3/4) BS2	TATA spare parts
285426204605	ENGAGING GEAR (1ST/2ND)	TATA spare parts
285426205401	1ST SPEED GEAR (4DL NA )	TATA spare parts
285426205402	2ND SPEED GEAR (4DL NA)	TATA spare parts
285426205403	3RD SPEED GEAR (4DL NA)	TATA spare parts
285426205404	4TH SPEED GEAR (4DL NA)	TATA spare parts
285426205405	FIFTH GEAR LAY SHAFT (NA)	TATA spare parts
285426205406	DRIVE GEAR ON LAY SHAFT	TATA spare parts
285426205407	DRIVE GEAR ON PINION	TATA spare parts
285426205408	SPEEDO GEAR	TATA spare parts
285426205409	SPEEDO PINION	TATA spare parts
285426205410	1ST SPEED GEAR (4DL TCIC)	TATA spare parts
285426205411	2ND SPEED GEAR (4DL TCIC)	TATA spare parts
285426205412	3RD SPEED GEAR	TATA spare parts
285426205413	GEAR 4DL	TATA spare parts
285426205414	5TH SPEED GEAR (LAY SHAFT 4DL TCIC)	TATA spare parts
285426205415	DRIVE GEAR LAY SHAFT (TCIC)	TATA spare parts
285426205423	3RD SPEED GEAR(DICOR)	TATA spare parts
285426205425	5TH SPEED GEAR LAY SHAFT DICOR	TATA spare parts
285426205426	4TH SPEED GEAR LAY SHAFT DICOR	TATA spare parts
285426206501	HEX.NUT (M20X1.5)	TATA spare parts
285426207901	LAY SHAFT	TATA spare parts
285426207903	SHAFT SPEEDO	TATA spare parts
285426207906	SHAFT LAY SHAFT	TATA spare parts
285426208601	SPACER 33.4X44X2.2 (MAIN SHAFT)	TATA spare parts
285426208602	SPACER 31X42.5X2.2(MAIN SHAFT)	TATA spare parts
285426208603	THRUST WASHER	TATA spare parts
285426208701	SYNCHRONIZATION SPRING	TATA spare parts
285426208702	SYNCHRO SPRING(1ST/2ND)	TATA spare parts
285426209901	ROLLER	TATA spare parts
285426209902	ADAPTOR SPEEDO SHAFT	TATA spare parts
285426209903	ADAPTOR REVERSE LOCK CABLE	TATA spare parts
285426250106	SUB.ASSY CLUTCHSHAFT W/COUPLER(2.2DICOR)	TATA spare parts
285426253101	DOUBLE ROW NEEDLE CAGE	TATA spare parts
285426253104	FULL COMP.CYL.ROLLER BRG	TATA spare parts
285426253105	DEEP GROOVE BALL BRG	TATA spare parts
285426253401	COUPLER (INPUT SHAFT)	TATA spare parts
285426253402	SLEEVE (INPUT SHAFT)	TATA spare parts
285426253403	SLIDING BUSH (CLUTCH SHAFT)	TATA spare parts
285426254301	SNAP RING (CLUTCH SHAFT)	TATA spare parts
285426254302	INTERNAL CIRCLIP (BRG 25X69X20)	TATA spare parts
285426254303	SNAP RING (INPUT SHAFT)	TATA spare parts
285426254601	ENGAGING GEAR (5TH SPEED)	TATA spare parts
285426254602	SHIFTER SEEVE (5TH) BS2/3/4	TATA spare parts
285426255401	5TH SPEED GEAR (INPPUT SHAFT NA)	TATA spare parts
285426255402	5TH SPEED GEAR (INPUT SHAFT 4DL	TATA spare parts
28542625540221	INPUT SHAFT 5TH SPEED BS6-PH2	TATA spare parts

285426255403	5TH SPEED GEAR INPUT SHAFT( DICOR)	TATA spare parts
285426257802	OFFER DRG OIL SEAL (INPUT SHAFT)	TATA spare parts
285426257804	OIL SEAL (24.5X40X8.5)	TATA spare parts
285426257903	INPUT SHAFT (4DLNA VERSION) BS2/3/4	TATA spare parts
285426257904	CLUTH SHAFT	TATA spare parts
285426257905	INPUT SHAFT(4DL TCIC) BS3/4	TATA spare parts
285426257906	CLUTCH SHAFT(2.2 DICOR)	TATA spare parts
285426257908	INPUT SHAFT WINGER DICOR	TATA spare parts
285426258201	GUIDE TUBE	TATA spare parts
285426258202	GUIDE TUBE(2.2 DICOR)	TATA spare parts
285426258601	THRUST WASHER (5TH SPEED)	TATA spare parts
285426258602	RETAINER (SPRING CLUTCH SHAFT)	TATA spare parts
285426258603	SPACER(CLUTCH SHAFT)	TATA spare parts
285426258701	SYNCHRONIZER SPRING (5TH SPEED)	TATA spare parts
285426258702	SPRING COMP.(CLUTCH SHAFT)	TATA spare parts
285426300103	ASSY. DRIVE SHAFT (TATA VAN) BS2/3/4	TATA spare parts
285426300106	ASSY DIFFERENTIAL HOUSING	TATA spare parts
285426300108	ASSY. CROWN & PINION (37/9-SPIR) BS2/3/4	TATA spare parts
285426300109	BJ SET ABS	TATA spare parts
285426300110	BJ SET NABS	TATA spare parts
285426300111	TJ SET	TATA spare parts
285426300112	BJ BOOT SET	TATA spare parts
285426300113	TJ BOOT SET	TATA spare parts
285426300114	ASSY. DRIVE SHAFT NON-ABS BS3/4	TATA spare parts
285426300115	ASSEMBLY DRIVE SHAFT-ABS	TATA spare parts
285426300121	BJ SET ABS 15INCH.	TATA spare parts
285426300122	BJ SET NABS (GKN NO-10185652)15INCH	TATA spare parts
285426300126	KIT -AXLE AND JOINT TJ SET	TATA spare parts
285426300128	DRIVE SHAFT ASSY	TATA spare parts
285426300129	OUTER JOINT KIT BS6	TATA spare parts
285426300130	INNER JOINT KIT BS6	TATA spare parts
285426300131	INNER BOOT KIT BS6	TATA spare parts
285426300132	TRIPOD ASSY KIT BS6	TATA spare parts
285426303105	DEEP GROOVE BALL BRG	TATA spare parts
285426303106	TAPER ROLLER BRG 32009	TATA spare parts
285426303107	DEEP GROOVE BALL BRG	TATA spare parts
285426303108	TAPERED ROLLER BEARING BS2/3/4	TATA spare parts
285426303109	TAPER ROLLER BRG	TATA spare parts
285426303402	SENSING WHEEL	TATA spare parts
285426305101	THREADED RING	TATA spare parts
285426305103	THREADED RING	TATA spare parts
285426305401	BEVEL PINION	TATA spare parts
285426305402	AXLE SHAFT GEAR (RIGHT)	TATA spare parts
285426305403	AXLE SHAFT GEAR (LEFT)	TATA spare parts
285426305404	CROWN WHEEL CUM DIFFERENTIAL CASE BS6	TATA spare parts
285426305405	PINION (FOR PANEL VAN)	TATA spare parts
285426305406	DRIVE GEAR PINION SHAFT (TCIC)	TATA spare parts



285426306301	DUST SEAL (DIFF.COVER)	TATA spare parts
285426306501	HEX NUT (M24X1.5) FINAL DRIVE	TATA spare parts
285426306701	MOUNTING BOLT	TATA spare parts
285426307803	'O'RING (DIFF.COVER)	TATA spare parts
285426307804	OIL SEAL (DRIVE SHAFT RH) BS4	TATA spare parts
285426307805	OIL SEAL (DRIVE SHAFT LH) BS4	TATA spare parts
285426307806	OIL SEAL (42X58X20)	TATA spare parts
285426307807	OIL SEAL (32X47X9.5)	TATA spare parts
285426307902	PIN DIFFERENTIAL	TATA spare parts
285426308202	BAFFLE- OIL SEAL DRIVE SHAFT RH	TATA spare parts
285426308203	DUST CAP	TATA spare parts
285426308301	SHIM (47X55X0.8)	TATA spare parts
285426308302	SHIM (47X55X0.85)	TATA spare parts
285426308303	SHIM (47X55X0.9)	TATA spare parts
285426308304	SHIM (47X55X0.95)	TATA spare parts
285426308305	SHIM (47X55X1)	TATA spare parts
285426308306	SHIM (47X55X1.05)	TATA spare parts
285426308307	SHIM (47X55X1.1)	TATA spare parts
285426308308	SHIM (47X55X1.15)	TATA spare parts
285426308309	SHIM (47X55X1.2)	TATA spare parts
285426308310	SHIM (47X55X1.25)	TATA spare parts
285426308311	SHIM (47X55X1.3)	TATA spare parts
285426308312	SHIM (47X55X1.35)	TATA spare parts
285426308313	SHIM (47X55X1.4)	TATA spare parts
285426308314	FRICITION WASHER (SUN GEAR)	TATA spare parts
285426308315	SHIM (0.1)	TATA spare parts
285426308316	SHIM (0.15)	TATA spare parts
285426308317	SHIM (0.20)	TATA spare parts
285426308318	SHIM (0.25)	TATA spare parts
285426308319	SHIM (0.30)	TATA spare parts
285426308320	SHIM (0.45)	TATA spare parts
285426308321	SHIM (0.50)	TATA spare parts
285426308322	SHIM (1.0)	TATA spare parts
285426308338	SHIM (0.05)	TATA spare parts
285426308610	SPACER	TATA spare parts
285426308620	SPHERICAL WASHER (DIFFERENTIAL)	TATA spare parts
285426308621	SPACER (DIFFERENTIAL HSG)	TATA spare parts
285426350101	ASSY REVERSE IDLER GEAR	TATA spare parts
285426355401	REVERSE IDLER GEAR	TATA spare parts
285426357901	SHAFT REVERSE IDLER GEAR	TATA spare parts
285426510102	SUB ASSY SHIFTER SHAFT (3/4)	TATA spare parts
285426510103	SUB ASSY SHIFTER SHAFT (5TH)	TATA spare parts
285426510104	SUB ASSY. SHIFTER SHAFT (3/4)	TATA spare parts
285426510107	SUB ASSY.SHIFTER SHAFT (1/2)	TATA spare parts
285426515101	SHIFTER FORK (1/2)	TATA spare parts
285426515102	SHIFTER FORK (3/4)	TATA spare parts
285426515103	SHIFTER FORK (5TH)	TATA spare parts

285426515104	SHIFTER DOG (3/4)	TATA spare parts
285426515105	SHIFTER FORK (1/2) STEEL INV CAST	TATA spare parts
285426515106	SHIFTER FORK (3/4) STEEL INV CAST	TATA spare parts
285426515107	SHIFTER FORK (5TH) STEEL INV CAST	TATA spare parts
285426515108	SHIFTER FORK-ALUMINIUM (1ST/2ND)	TATA spare parts
285426516701	INTERLOCK PIN	TATA spare parts
285426516702	INTERLOCK PIN (5TH / REVERSE)	TATA spare parts
285426516703	DOWEL SLEEVE	TATA spare parts
285426516704	DOWEL SLEEVE	TATA spare parts
285426516705	INTERLOCKPIN(1/2)	TATA spare parts
285426516706	INTERLOCKPIN (FORWARD)	TATA spare parts
285426516707	PIVOT PIN (FORK 5TH SPEED)	TATA spare parts
285426517901	SHIFTER SHAFT (1/2)	TATA spare parts
285426517902	SHIFTER SHAFT (3/4)	TATA spare parts
285426517903	SHIFTER SHAFT (5TH)	TATA spare parts
285426517904	SHIFTER SHAFT (1ST/2ND)	TATA spare parts
285426518701	SPRING DETENT	TATA spare parts
285426700101	SUB ASSY SELECTOR SHIFTER SHAFT	TATA spare parts
285426700102	GROMMET ASSY	TATA spare parts
285426700103	ASSY SEL/SHIFTER SHAFT WITH YOKE	TATA spare parts
285426700109	GROMMET ASSY BS6	TATA spare parts
285426700110	SHIFTING YOKE SELECTOR & SHIFTER SHAFT B	TATA spare parts
285426703401	HALF BUSH (SELECTOR SHAFT)	TATA spare parts
285426703402	HALF BUSH (SELECTOR SHAFT)	TATA spare parts
285426705101	SHIFT LEVER (REVERSE GEAR)	TATA spare parts
285426705102	FINGER(SEL./SHIFTER SHAFT)	TATA spare parts
285426706701	DETENT REVERSE	TATA spare parts
285426706702	DOWEL SLEEVE	TATA spare parts
285426706703	DOWEL SLEEVE	TATA spare parts
285426707701	BELLOW (SELECTOR SHIFTER	TATA spare parts
285426707704	BELLOW (SEL./ SHIFTER SHAFT)	TATA spare parts
285426707901	SELECTOR SHIFTER SHAFT	TATA spare parts
285426708201	SHIFTING YOKE (SEL.SHIFTER SHAFT)	TATA spare parts
285426708601	SPACER (SEL./SHFT SHAFT)	TATA spare parts
285426708701	SPRING INNER(SEL./SHFT SHAFT)	TATA spare parts
285426708702	SPRING OUTER(SEL./SHFT SHAFT)	TATA spare parts
285426800102	ASSY SHIFT LINKAGE	TATA spare parts
285426800103	CABLE(FOR REVERSE GEAR LOCKING) 434MM	TATA spare parts
285426800104	ASSY GEARSHIFT LEVER KNOB	TATA spare parts
285426800109	ASSY. GEAR SHIFT LEVER KNOB	TATA spare parts
285426800110	ASSY. GEAR SHIFT LEVER KNOB	TATA spare parts
285426800110C7	GRANIT_BLACK-ASSY. GEAR SHIFT LE BS6	TATA spare parts
285426800113	ASSY GEAR SHIFT LEV	TATA spare parts
285426800115	ASSY.GEAR SHIFT KNOB M1	TATA spare parts
285426803401	BUSH GEAR SHIFT LEVER	TATA spare parts
285426803402	BUSH (GEARSHIFT LINKAGE)	TATA spare parts
285426803404	SLIDING SLEEVE (GEARSHIFT LEVER)	TATA spare parts

285426803405	BUSH(GEAR SHIFT LEVER BKT)	TATA spare parts
285426803406	NYLON INSERT (I BOLT)	TATA spare parts
285426803407	STEEL INSERT (I BOLT)	TATA spare parts
285426803408	STEEL INSERT (I BOLT)	TATA spare parts
285426803409BN	SLIDING SLEEVE (GEAR SHIFT LEVER M1)	TATA spare parts
285426804201	BASE PLATE (GEARSHIFT LEVER)	TATA spare parts
285426807201	STUD (SHIFT LINKAGE BKT)	TATA spare parts
285426807202	I BOLT(SHIFT LINKAGE)	TATA spare parts
285426807702	BELLOW (GEAR SHIFT LEVER)	TATA spare parts
285426807703	GAITER (M1)	TATA spare parts
285426808201	BRACKET (SHIFT LINKAGE MTG)	TATA spare parts
285426808212	BRACKET BS6	TATA spare parts
285426808601	SPACER DIA. 27X8.4X2 (SHIFT LINKAGE)	TATA spare parts
285426808602	SPACER DIA. 27X15X2(SHIFT LINKAGE)	TATA spare parts
285426808701	SPRING COMP.(GEAR SHIFT LEVER)	TATA spare parts
285426809903	TRANSFER LABEL (LIFT & SHIFT)	TATA spare parts
285526000106	ASSY. GEAR BOX G550-6/6.9(0.84 OD)BS3	TATA spare parts
285526000108	ASSY. GEAR BOX G550-6/6.9 (3L ENG) BS3/4	TATA spare parts
285526000112	ASSY. GEARBOX G550-6/6.9 (0.84 OD) CABL	TATA spare parts
285526000113	ASSY. GEAR BOX G550 6/6.9 BS3/4	TATA spare parts
285526000116	ASSY. GEAR BOX G550-6/6.9 (0.84 OD) CABL	TATA spare parts
285526000119	GEAR BOX G550-6/6.9 PNEUMATIC AMT	TATA spare parts
285526000122	ASSY.GEARBOX G550- 5/7.51 WITH 8 B.C.F.	TATA spare parts
285526000129	GEAR BOX G550-5/7.51 SERRATED SHORT C/F	TATA spare parts
285526000130	G550-6/6.9 GEARBOX SERR. C/F (LPT 909)	TATA spare parts
285526000132	GEAR BOX G550 6/6.9 REMOTE SHIFT	TATA spare parts
285526000139	GEAR BOX ASSY	TATA spare parts
285526000140	GEAR BOX ASSY	TATA spare parts
285526000151	GEAR BOX ASSY	TATA spare parts
285526000153	GEAR BOX ASSY BS6	TATA spare parts
285526000154	GEAR BOX ASSY	TATA spare parts
285526000155	GEAR BOX ASSY	TATA spare parts
285526000156	GEAR BOX ASSY WITH CABLE SHIFT BS6	TATA spare parts
285526000158	GEAR BOX ASSY BS6	TATA spare parts
285526000159	GEAR BOX ASSY BS6	TATA spare parts
285526000160	GEAR BOX ASSY BS6	TATA spare parts
285526000162	GEAR BOX ASSY BS6	TATA spare parts
285526000164	GEAR BOX ASSY BS6	TATA spare parts
285526100103	ASSLY. GEARBOX HOUSING (FRONT HALF)	TATA spare parts
285526100109	ASSY. GEARBOX HOUSING (FRONT HALF)	TATA spare parts
285526100129	REAR HALF ASSY BS6	TATA spare parts
285526100130	REAR HALF ASSY BS6	TATA spare parts
285526100132	FRONT HALF ASSY BS6	TATA spare parts
285526103701	FRONT HALF BS6	TATA spare parts
285526103703	REAR HALF BS6	TATA spare parts
285526103704	REAR HALF BS6	TATA spare parts
285526103802	GEARBOX HOUSING (REAR HALF) BS3/4	TATA spare parts

285526103803	GEARBOX HOUSING (FRONT HALF) BS3/4	TATA spare parts
285526103805	GEARBOX HOUSING (REAR HALF FOR AMT)	TATA spare parts
285526103806	GEARBOX HOUSING FRONT HALF (5 SPEED)	TATA spare parts
285526103807	GEARBOX HOUSING (REAR HALF-5 SPEED)	TATA spare parts
285526103808	REAR HALF	TATA spare parts
285526103809	FRONT HALF	TATA spare parts
285526103811	REAR HALF BS6	TATA spare parts
285526103815	REAR HALF BS6-PH2	TATA spare parts
285526105301	GASKET (HSG.JT.FACE)	TATA spare parts
285526108201	CAP (FOR GEAR BOX HOUSING)	TATA spare parts
285526108204	GEAR BOX NUMBER PLATE BS6	TATA spare parts
285526108205	COVER BS6	TATA spare parts
285526200110	ASSY.ENGAGING GEAR(5TH/REV) BS6	TATA spare parts
285526200111	ENGAGING GR SHIFT SLV ASSY 1/2ND SPD BS6	TATA spare parts
285526200118	BRACKET (THIRD POINT MOUNT)	TATA spare parts
285526200127	SYNCHRO CONE ASSY-1ST/2ND SPEED BS6	TATA spare parts
285526200134	BRACKET ASSY C-MOUNT BS6	TATA spare parts
285526200137	MAIN SHAFT ASSY BS6	TATA spare parts
285526200138	BRACKET ASSY TOP MOUNT BS6	TATA spare parts
285526200144	BRACKET ASSY-TOP MOUNT BS6	TATA spare parts
285526201601	SYNCHRO CONE 108 DIA. BS3/4	TATA spare parts
285526203101	DEEP GROOVE BALL BRG.(DBL SEAL) BS3/4/6	TATA spare parts
285526203103	DEEP GROOVE BALL BRG.6310-2RSI (M/S-NRB)	TATA spare parts
285526203104	DEEP GROOVE BALL BRG 6310-2RSR	TATA spare parts
285526203401	SPACER (MAIN SHAFT)	TATA spare parts
285526203402	SPEEDO ADAPTOR	TATA spare parts
285526203403	ADAPTOR BREATHER	TATA spare parts
285526203404	SPEED SENSING WHEEL BS6	TATA spare parts
285526203802	REAR COVER (5 SPEED)	TATA spare parts
285526203803	REAR COVER (6SPEED) BS3/4	TATA spare parts
285526203805	REAR COVER (6 SPEED CABLE SHIFT)	TATA spare parts
285526203807	COVER REAR BS6	TATA spare parts
285526204301	EXT.CIRCLIP (2.4 THK)	TATA spare parts
285526204302	EXT.CIRCLIP (2.5 THK)	TATA spare parts
285526204303	EXT.CIRCLIP (2.6 THK)	TATA spare parts
285526204304	EXT.CIRCLIP (2.7 THK)	TATA spare parts
285526204305	EXT.CIRCLIP (2.8 THK)	TATA spare parts
285526204306	EXT.CIRCLIP (2.9 THK)	TATA spare parts
285526204602	SHIFTER SLEEVE (1ST/2ND-3RD/4TH) BS3/4/6	TATA spare parts
285526204606	ENGAGING GEAR (5TH/REVERSE SPEED)	TATA spare parts
285526204607	SHIFTER SLEEVE (5TH/REV) BS3/4/6	TATA spare parts
285526204608	SYNCHRO RING-DOUBLECONE(1ST/2ND SPEED)	TATA spare parts
285526204610	ENGAGING GEAR (1ST/2ND SPEED)	TATA spare parts
285526204611	INNER CONE W/CORBON LINING (1/2ND) BS3/4	TATA spare parts
285526204612	SYNCHRO RING INTERMEDIATE (1/2) BS3/4/6	TATA spare parts
285526204614	SYNCHRO RING (REVERSE GEAR) BS3/4/6	TATA spare parts
285526204615	INTERMEDIATE CONE 1ST/2ND SPEED BS6	TATA spare parts

285526204621	ENGAGING GEAR 5TH/REVERSE SPEED BS6	TATA spare parts
285526204622	SYNCHRO RING REVERSE SPEED BS6	TATA spare parts
285526205001	COUPLING FLANGE	TATA spare parts
285526205002	COUPLING FLANGE (120 DIA 6 BOLT)	TATA spare parts
285526205101	COUPLING FLANGE	TATA spare parts
285526205102	COUPLING FLANGE (SERRETED SHORT)	TATA spare parts
285526205104	COUPLING FLANGEBS6	TATA spare parts
285526205105	COUPLING FLANGE BS6-PH2	TATA spare parts
285526205301	GASKET (REAR CVR)	TATA spare parts
285526205401	HELICAL GEAR 1ST SP.(6.9 RATIO) M/SHAFT	TATA spare parts
285526205404	OVERDRIVE GEAR (MAIN SHAFT)	TATA spare parts
285526205406	GEAR (SPEEDOMETER DRIVE)	TATA spare parts
285526205407	HELICAL GEAR 2ND SPEED(MAIN SHAFT)	TATA spare parts
285526205408	HELICAL GEAR REV. SPEED(6.9 RATIO)	TATA spare parts
285526205409	OVERDRIVE GEAR (MAIN SHAFT) (6.9 RATIO)	TATA spare parts
285526205415	HELICAL GEAR 1ST SPEED	TATA spare parts
285526205416	HELICAL GEAR 2ND SPEED	TATA spare parts
285526205424	HELICAL GEAR REVERSE SPEED BS6	TATA spare parts
285526206501	HEX NUT (MAINSHAFT)	TATA spare parts
285526206701	COUPLING FLANGE BOLT	TATA spare parts
285526206702	BRAKE DRUM BOLT (6.9 RATIO)	TATA spare parts
285526207901	MAIN SHAFT (6.34 RATIO)	TATA spare parts
285526207902	SPEEDO PINION	TATA spare parts
285526207904	MAIN SHAFT (6.9 RATIO) BS3/4	TATA spare parts
285526207906	MAIN SHAFT-TABLE DRG	TATA spare parts
285526207908	MAIN SHAFT BS6	TATA spare parts
285526208201	SLINGER (REAR COVER)	TATA spare parts
285526208227	OIL DEFLECTOR BS6	TATA spare parts
285526208601	SPACER (MAIN SHAFT)	TATA spare parts
285526208602	SPACER (MAIN SHAFT)	TATA spare parts
285526208603	SPACER (MAIN SHAFT)	TATA spare parts
285526208604	SPACER (MAIN SHAFT)	TATA spare parts
285526208605	SPACER (MAIN SHAFT)	TATA spare parts
285526208606	SPACER (MAIN SHAFT)	TATA spare parts
285526208607	SPACER (MAIN SHAFT)	TATA spare parts
285526208608	SPACER (MAIN SHAFT)	TATA spare parts
285526250110	DRIVE SHAFT ASSY BS6-PH2	TATA spare parts
285526253701	FRONT COVER (CASTING)	TATA spare parts
285526253705	COVER	TATA spare parts
285526254301	INT.CIRCLIP(4.2THK)	TATA spare parts
285526254302	INT.CIRCLIP(4.15THK)	TATA spare parts
285526254303	INT.CIRCLIP(4.1THK)	TATA spare parts
285526254304	INT.CIRCLIP(4.05THK)	TATA spare parts
285526254305	INT.CIRCLIP(4THK)	TATA spare parts
285526254306	INT.CIRCLIP(3.95THK)	TATA spare parts
285526254307	INT.CIRCLIP(3.9THK)	TATA spare parts
285526254308	EXT. CIRCLIP (2.8 THK.)	TATA spare parts

285526254309	EXT. CIRCLIP (2.9 THK)	TATA spare parts
285526254310	EXT. CIRCLIP (2.95 THK)	TATA spare parts
285526254311	EXT. CIRCLIP (3.0 THK)	TATA spare parts
285526254312	EXT. CIRCLIP (3.05 THK)	TATA spare parts
285526254313	EXT. CIRCLIP (3.1 THK)	TATA spare parts
285526254314	EXT. CIRCLIP (3.15 THK.)	TATA spare parts
285526254601	SYNCHRO RING (DRIVE SHAFT)	TATA spare parts
285526255301	GASKET (FRONT COVER)	TATA spare parts
285526255304	GASKET	TATA spare parts
285526257901	DRIVE SHAFT (7.51)	TATA spare parts
285526257903	DRIVE SHAFT(6.9 RATIO) BS3/4	TATA spare parts
285526257905	DRIVE SHAFT BS6	TATA spare parts
285526257906	DRIVE SHAFT BS6	TATA spare parts
285526258203	OIL SLINGER	TATA spare parts
285526258601	SPACER (6.9 RATIO)	TATA spare parts
285526258608	SPACER (6.9 RATIO)	TATA spare parts
285526300121	COUNTER SHAFT ASSY BS6-PH2	TATA spare parts
285526303101	CYL. ROLLER BRG. (C/SHAFT)	TATA spare parts
285526303401	COLLAR BUSH (6 SPEED)	TATA spare parts
285526304301	EXTERNAL CIRCLIP (40X1.75)	TATA spare parts
285526304601	SYNCHRO RING (OVERDRIVE)	TATA spare parts
285526304603	ENGAGING GEAR (3RD/4TH SPEED)	TATA spare parts
285526304604	SYNCHRO RING (3RD/4TH SPEED) BS3/4/6	TATA spare parts
285526305301	GASKET BS6	TATA spare parts
285526305302	GASKET BS6	TATA spare parts
285526305401	CONSTANT MESH GEAR	TATA spare parts
285526305404	OVERDRIVE GEAR (COUNTER SHAFT) BS3/4	TATA spare parts
285526305406	HELICAL GEAR 3RD SPEED(C SHAFT)6.34RATIO	TATA spare parts
285526305407	HELICAL GEAR 4TH SPEED(C SHAFT)6.34RATIO	TATA spare parts
285526305408	CONSTANT MESH GEAR (6.9 RATIO )	TATA spare parts
285526305409	HELICAL GEAR 3 RD SPEED (COUNTER SHAFT 6	TATA spare parts
285526305410	HELICAL GEAR 4TH SPEED (COUNTER SHAFT 6.	TATA spare parts
285526305417	GEAR 3RD SPEED COUNTER SHAFT	TATA spare parts
285526305418	HELICAL GEAR 4TH SPEED	TATA spare parts
285526305423	CONSTANT MESH GEAR BS6	TATA spare parts
285526305424	GEAR ASSY 3RD SPEED (COUNTER SHAFT) BS6	TATA spare parts
285526305426	CONSTANT MESH GEAR-TABLE DRG BS6	TATA spare parts
285526306501	HEX NUT (M26X1.5 LH)	TATA spare parts
285526307903	COUNTER SHAFT 6 SPEED (6.9 RATIO) BS3/4	TATA spare parts
285526307905	COUNTER SHAFT -5 SPEED (7.51 DEEPER RATI	TATA spare parts
285526307906	COUNTER SHAFT	TATA spare parts
285526308201	OIL SPLASHER	TATA spare parts
285526308202	COVER BS6	TATA spare parts
285526308203	COVER BS6	TATA spare parts
285526308204	CORE PLUG BS6	TATA spare parts
285526308601	SPACER (C/SHAFT)	TATA spare parts
285526308602	SPACER (C/SHAFT)	TATA spare parts

285526308603	SPACER (C/SHAFT)	TATA spare parts
285526308604	SPACER (C/SHAFT)	TATA spare parts
285526308605	SPACER (C/SHAFT)	TATA spare parts
285526308606	SPACER (C/SHAFT)	TATA spare parts
285526308607	SPACER (C/SHAFT)	TATA spare parts
285526308608	WASHER ON COUNTER SHAFT	TATA spare parts
285526308609	SPACER (C/SHAFT) (7.20 MM THICK)	TATA spare parts
285526308610	SPACER (C/SHAFT) (7.25 MM THICK)	TATA spare parts
285526308611	SPACER (C/SHAFT) (7.30 MM THICK)	TATA spare parts
285526353801	R.I. COVER (CASTING)	TATA spare parts
285526355301	GASKET (R.I.WINDOW)	TATA spare parts
285526355302	GASKET (R.I COVER-AMT)	TATA spare parts
285526355402	REVERSE IDLER GEAR (6.9 RATIO)	TATA spare parts
285526355405	REVERSE IDLER GEAR BS6	TATA spare parts
285526357901	REVERSE IDLER SHAFT	TATA spare parts
285526358201	COVER (R.I WINDOW)	TATA spare parts
285526358601	THRUST WASHER (R.I SHAFT)	TATA spare parts
285526400107	PTO ASSY	TATA spare parts
285526400108	ASSY. PTO (GB550) SIDE MOUNTED BS6	TATA spare parts
285526400109	PTO ASSY BS6	TATA spare parts
285526510101	ASSY. SWING FORK (1ST/2ND) BS6	TATA spare parts
285526510102	ASSY.SWING FORK (3RD/4TH) BS6	TATA spare parts
285526510103	ASSY. SWING FORK (5TH/REV.) BS6	TATA spare parts
285526510111	ASSY INHIBITOR	TATA spare parts
285526510118	SHIFTER SHAFT ASSY 1ST/2ND SPEEDBS6-PH2	TATA spare parts
285526510119	SHIFTER SHAFT ASSY 3RD/4TH SPEEDBS6-PH2	TATA spare parts
285526510128	SHIFTER SHAFT 5TH/6TH/REVERSE SPEED BS6	TATA spare parts
285526513401	COLLAR BUSH FOR SHIFTER FORK	TATA spare parts
285526513402	BUSH FOR SHIFTER FORK	TATA spare parts
285526513404	COLLAR BUSH SHIFTER FORK	TATA spare parts
285526513405	BUSH	TATA spare parts
285526513801	SWING FORK 1ST AND 2ND	TATA spare parts
285526513802	SWING FORK 3RD AND 4TH	TATA spare parts
285526513803	SWING FORK 5TH & REV	TATA spare parts
285526513804	SWING FORK (OVERDRIVE)	TATA spare parts
285526515102	SHIFT PLUNGER (5TH/REV)	TATA spare parts
285526515109	INTERLOCK DOG 6TH SPEED	TATA spare parts
285526515110	SWING DOG (1ST/2ND/5TH/REV)	TATA spare parts
285526515111	SWING DOG (3RD/4TH&6TH)	TATA spare parts
285526515112	SHIFTER DOG (5TH/REV.)	TATA spare parts
285526515113	SHIFTER DOG (1ST/2ND)	TATA spare parts
285526515114	SHIFTER DOG (3RD / 4TH)	TATA spare parts
285526515115	SHIFTER DOG (5TH/6TH/REVERSE)	TATA spare parts
285526515116	PLUNGER (FOR 5TH/6TH/REV.SHIFT DOG)	TATA spare parts
285526515118	SHIFTER DOG ASSY	TATA spare parts
285526515301	GASKET(RETAINER PIN)	TATA spare parts
285526516501	NEUTRAL DETENT PLUG	TATA spare parts

285526516701	PIVOT PIN	TATA spare parts
285526516702	INTERLOCK PIN	TATA spare parts
285526516703	RETAINER PIN (6.9 RATIO)	TATA spare parts
285526517907	SHIFTER SHAFT (1ST / 2ND SPEED)	TATA spare parts
285526517908	SHIFTER SHAFT (3RD /4TH SPEED)	TATA spare parts
285526517909	SHIFTER SHAFT (5TH/REVERSE)-FOR 5 SPEED	TATA spare parts
285526517910	SHIFTER SHAFT (6TH SPEED)	TATA spare parts
285526517911	SHIFTER SHAFT (5TH/REV.)-FOR 6 SPEED	TATA spare parts
285526517912	SHIFTER SHAFT 1ST/2ND SPEED	TATA spare parts
285526517913	SHIFTER SHAFT 3RD/4TH SPEED	TATA spare parts
285526517914	SHIFTER SHAFT 5TH/REVERSE	TATA spare parts
285526517915	SHIFTER SHAFT 6TH SPEED	TATA spare parts
285526517917	SHIFTER SHAFT 5TH/REVERSE BS6	TATA spare parts
285526518702	SPRING (PLUNGER 5TH/REV DOG)	TATA spare parts
285526518704	PLUNGER SPRING (REVERSE GEAR)	TATA spare parts
285526519901	BRASS PAD	TATA spare parts
285526700103	ASSY. SELECTOR SHAFT & SELECTION LEVER A	TATA spare parts
285526700104	ASSY. SELECTOR SHAFT & SELECTION LEVER A	TATA spare parts
285526700105	ASSY.SELECTOR SHAFT & SELECTOR LEVER	TATA spare parts
285526700106	SELECTION LEVER & SELECTOR SHAFT ASSY	TATA spare parts
285526706006	SELECTION LEVER BS6	TATA spare parts
285526707902	SELECTOR & SHIFTER SHAFT	TATA spare parts
285526707904	SELECTOR & SHIFTER SHAFT (6.9 RATIO)	TATA spare parts
285526707905	SELECTOR SHAFT BS6	TATA spare parts
285526707906	SHAFT SHIFTER	TATA spare parts
285526710105	ASSLY.TOP COVER (6 SPEED - REMOTE SHIFT)	TATA spare parts
285526710106	ASSLY LINK ROD ANCHORING BRACKET (6.9 RA	TATA spare parts
285526710107	ASSY. TOP COVER	TATA spare parts
285526710109	COVER ASSY TOP	TATA spare parts
285526710111	ASSY. TOP COVER	TATA spare parts
285526710120	COVER ASSY TOP BS6	TATA spare parts
285526710121	COVER ASSY TOP BS6	TATA spare parts
285526713403	SPH. DETENT (SEL SHIFT SFT/INA ) BS3/4/6	TATA spare parts
285526713404	CENTRAL DETENT BS6	TATA spare parts
285526713405	NEEDLE BUSH BS6-PH2	TATA spare parts
285526713406	NEEDLE BEARING	TATA spare parts
285526713701	SHIFTING FINGER	TATA spare parts
28552671370121	STAGE PART SHIFTING FINGER BS6	TATA spare parts
285526713702	INTERLOCK FINGER	TATA spare parts
285526713803	TOP COVER (CABLE SHIFT)	TATA spare parts
285526713804	TOP COVER (REM SHIFT W/O NEUTRAL SWITCH)	TATA spare parts
285526713805	TOP COVER(CABLESHIFT W/O NEUTRAL SWITCH)	TATA spare parts
285526713806	COVER TOP (ROD SHIFT) W/NEUTRAL SWITCH	TATA spare parts
285526713807	COVER TOP	TATA spare parts
285526715102	SELECTION LEVER	TATA spare parts
285526715301	GASKET (TOP CVR)	TATA spare parts
285526715302	GASKET (SIDE COVER)	TATA spare parts



285526716501	DETENT PLUG	TATA spare parts
285526717102	GUIDE PLATE	TATA spare parts
285526717108	BRACKET LINK ROD MTG BS6	TATA spare parts
285526718202	COVER (SIDE-TOP COVER)	TATA spare parts
285526718601	THRUST WASHER (20.1X26X2)	TATA spare parts
285526718701	COMPRESSION SPRING(OUTER)-CENTRAL DETENT	TATA spare parts
285526718702	COMPRESSION SPRING(INNER)-CENTRAL DETENT	TATA spare parts
285526718703	REVERSE DETENT SPRING	TATA spare parts
285526718704	REVERSE DETENT SPRING (2.2 STIFFNESS)	TATA spare parts
285526718705	COMPRESSION SPRING (OUTER)	TATA spare parts
285526718706	COMPRESSION SPRING (INNER)	TATA spare parts
285526718707	COMPRESSION SPRING -CENTRAL DETENT	TATA spare parts
285526718708	REVERSE DETENT SPRING	TATA spare parts
285526800105	ASSY. GEARSHIFT LEVER KNOB	TATA spare parts
285526800114	GEAR SHIFT LEVER YOKE ASSY WITH LEVER	TATA spare parts
285526800117	TURNING TUBE ASSY WITH BALL JOINT	TATA spare parts
285526800127	GEAR SHIFTER ASSY BS6	TATA spare parts
285526800128	EXTENSIONARM ASSY BS6	TATA spare parts
285526800129	LINK ROD ASSY BS6	TATA spare parts
285526805103	GEARSHIFTLEVER BS6	TATA spare parts
285526807901	LINK ROD	TATA spare parts
285526820106	ASSLY. G.S. WITH CABLE 9.5T/7.5T RHD	TATA spare parts
285526820110	G.S.WITH CABLE ASSY LP RH 497	TATA spare parts
285526820114	ASSLY. G.S. WITH CABLE LPO 7.5T/8.5T/9.6	TATA spare parts
285526820117	ASSY HUMP MTG.GSL LPT 709/909/1109 BSIV	TATA spare parts
285526820118	GSL ASSY UNIT ULTRA LPT RH 3L	TATA spare parts
285526820120	SHIFTER CABLE ASSY	TATA spare parts
285526820124	ANCHORBRACKET BS6	TATA spare parts
285526820126	GSL ASSY UNIT ULTRA LPO RH 3L	TATA spare parts
285526820128	SHIFTER CABLE ASSY	TATA spare parts
285526820136	ASSY GEAR SHIFT KNOB	TATA spare parts
285526820137	GEAR SHIFT KNOB ASSY (G550-FIVE SPEED)	TATA spare parts
285526820141	ASSY.G.S. WITH CABLES	TATA spare parts
285526820142	CABLE ANCHORING BRACKET (BSIV)	TATA spare parts
285526820144	ASSY. GEAR SHIFT W/CABLES BS3/4	TATA spare parts
285526820145	ASSY. G.S.WITH CABLES FOR LP410/712/912	TATA spare parts
285526820149	ASSLY CLAMP PLATE	TATA spare parts
285526820150	CABLE ANCHORING BRACKET	TATA spare parts
285526820161	ASSY DWG( HAT BKT AND TOP COVER)	TATA spare parts
285526820175	GEAR SHIFT KNOB ASSY BS6	TATA spare parts
285526820179	CABLE ANCHOR BRACKET	TATA spare parts
285526820180	GEAR SHIFT ASSY	TATA spare parts
285526820182	SHIFTER CABLE ASSY	TATA spare parts
285526820184	SHIFTER CABLE ASSY	TATA spare parts
285526820190	KNOB ASSY	TATA spare parts
285526820199	GEAR SHIFT KNOB ASSY 285526821637 BS6	TATA spare parts
285526820210	ANCHOR BRACKET ASSY SHIFT CABLE BS6	TATA spare parts

285526820211	ASSY.GEAR SHIFTER WITH CABLES BS6	TATA spare parts
285526820212	SHIFTER CABLE ASSY	TATA spare parts
285526820216	SHIFTER CABLE ASSY BS6	TATA spare parts
285526820217	SHIFTER CABLE ASSY BS6	TATA spare parts
285526820218	SHIFTERCABLEASSY BS6	TATA spare parts
285526820220	SHIFTER CABLE ASSY BS6	TATA spare parts
285526820222	SHIFT CABLE ASSY BS6	TATA spare parts
285526820223	SELECTION CABLE ASSY BS6	TATA spare parts
285526820226	SHIFT CABLE ASSY BS6	TATA spare parts
285526820227	SELECTION CABLE ASSY BS6	TATA spare parts
285526820229	SHIFTER CABLE ASSY BS6	TATA spare parts
285526823501	BOSS -HEAT SHIELD SUPPORT	TATA spare parts
285526824201	P CLAMP	TATA spare parts
285526824202	CLAMP (CABLES)	TATA spare parts
285526824301	CLIP CABLE MTG BS6	TATA spare parts
285526824302	CLIP CABLE MTG BS6	TATA spare parts
285526824801	DOWEL PIN BS6	TATA spare parts
285526825101	SHIFT LEVER	TATA spare parts
285526826004	SHIFTING LEVER (160MM)	TATA spare parts
285526826038	GEAR LEVER BS6	TATA spare parts
285526826039	LEVER ASSY BS6-PH2	TATA spare parts
285526826095	GEAR SHIFT LEVER BS6	TATA spare parts
285526826096	GEAR SHIFT LEVER	TATA spare parts
285526826097	GEAR SHIFT LEVER BS6	TATA spare parts
285526826098	SHIFTING LEVER (R160)	TATA spare parts
285526826501	NUT BS6	TATA spare parts
285526826701	BALL JOINT M8	TATA spare parts
285526826703	PIN	TATA spare parts
285526827101	MOUNTING PLATE ASSY RH BS6	TATA spare parts
285526827702	REXENE BELLOW (BS4)	TATA spare parts
285526827703	BELLOW CONSOLE(ULTRA RHD TRUCK)	TATA spare parts
285526827704	BELLOW (BSIV TRUCK)	TATA spare parts
285526827708	BELLOW BS6	TATA spare parts
285526828001	COUNTERSUNK BOLT BS6	TATA spare parts
285526828002	SOCKET HEAD CAP SCREW BS6	TATA spare parts
285526828203	L BRACKET	TATA spare parts
285526828206	BRACKET BS6	TATA spare parts
285526828219	CLAMPING PLATE	TATA spare parts
285526828226	HEAT SHIELD (ULTRA-3L)	TATA spare parts
285526828235	L BRACKET (CABLE CLAMP)	TATA spare parts
285526828236	Z BRACKET	TATA spare parts
285526828241	CABLE CLAMPING PLATE	TATA spare parts
285526828601	SPACER BS6	TATA spare parts
285526828801	BALL JOINT BS6	TATA spare parts
285526829910	ASSY. DASH MOUNTED GEAR SHIFTER FOR Y1 B	TATA spare parts
285526840101	ACTUATOR ASSY AMT	TATA spare parts
285526840102	PNEUMATIC CLUTCH ACTUATOR	TATA spare parts

285526840103	SHIFT LEVER UNIT	TATA spare parts
285526840104	ASSY. PUSH ROD	TATA spare parts
285526840107	BRACKET PNEUMATIC CLUTCH ACTUATOR	TATA spare parts
285526843801	ADAPTOR PLATE (AMT)	TATA spare parts
285526845301	GASKET	TATA spare parts
285526846001	CLUTCH RELEASE LEVER(G550-AMT)	TATA spare parts
285526849901	INPUT SPEED SENSOR	TATA spare parts
285526849902	OUTPUT SPEED SENSOR	TATA spare parts
285526990101	SHIFT CABLE ASSY	TATA spare parts
285526990102	SELECT CABLE ASSY	TATA spare parts
285526990103	TOP ASSEMBLY	TATA spare parts
285526990104	CLAMP ASSEMBLY	TATA spare parts
285526990105	CLAMP ASSEMBLY	TATA spare parts
285526990106	GEAR SHIFT CABLE	TATA spare parts
285526990107	GEAR SELECT CABLE	TATA spare parts
285526990108	TOP ASSLY	TATA spare parts
285526990109	ASSY CABLE ASSY	TATA spare parts
285526990110	SHIFT CABLE ASSY	TATA spare parts
285526990111	SELECT CABLE ASSY	TATA spare parts
285526990112	TOP ASSEMBLY	TATA spare parts
285526990113	CLAMP ASSEMBLY	TATA spare parts
285526990114	CLAMP ASSEMBLY	TATA spare parts
285526990115	SHIFT CABLE ASSEMBLY	TATA spare parts
285526990116	SELECT CABLE ASSEMBLY	TATA spare parts
285526990120	KIT-SHIFT CABLE ASSY	TATA spare parts
285526990121	KIT-SELECT CABLE ASSY	TATA spare parts
285526990128	SHIFTER TOP ASSY	TATA spare parts
285526990130	SELECT CABLE	TATA spare parts
285526990131	SHIFT CABLE	TATA spare parts
285526990132	EYE END	TATA spare parts
285526990136	SHIFT CABLE ASSY	TATA spare parts
285526990137	SELECT CABLE	TATA spare parts
285526990138	SHIFT CABLE ASSY	TATA spare parts
285526990139	SELECT CABLE ASSY	TATA spare parts
285526990148	KIT-SHIFTER BS6	TATA spare parts
285526990149	SHIFT CABLE ASSY	TATA spare parts
285526990150	SELECT/SHIFTER ASSY CABLE SHIFT MECH	TATA spare parts
285526993801	TOP COVER	TATA spare parts
285526993802	BOTTOM COVER	TATA spare parts
285526994301	RETAINER CLIP	TATA spare parts
285526994302	RETAINER CLIP BS6	TATA spare parts
285526997702	DAMPER BUSH BS6	TATA spare parts
285526997703	SPACER BS6	TATA spare parts
285526998801	BALL & STUD BS6	TATA spare parts
285526998802	BALL & STUD BS6	TATA spare parts
285526999901	BALL JOINT ASSY	TATA spare parts
285526999902	ROD END	TATA spare parts

285526999903	SPHERICAL BALL JOINT ASSY	TATA spare parts
285626106304	BREATHER	TATA spare parts
285626203810	INTERMEDIATE CONE 1st/2nd (INA)	TATA spare parts
285626203811	INNER CONE 1ST / 2ND (WITH CARBON LINING	TATA spare parts
285626203812	SYNCHROCONE OUTER 1ST/2ND (BRASS WITH CA	TATA spare parts
285626204601	ENGAGING GEAR 1st/2nd (SINT SOFT VERSION	TATA spare parts
285626206301	CARRIER 1ST/2ND SPEED BS6	TATA spare parts
285626206302	CARRIER 3RD/4TH/5TH SPEED BS6	TATA spare parts
285626516706	SPIRAL PIN	TATA spare parts
285626519901	BARREL REVERSE DETENT	TATA spare parts
285626703802	CENTRAL DETENT	TATA spare parts
285626703803	CENTRAL DETENT (INA)	TATA spare parts
285626707403	PIN BS6	TATA spare parts
285626707803	OIL SEAL (SELECTOR SHIFTER SHAFT) M/S SI	TATA spare parts
285626708702	SPRING (CENTRAL DETENT ) BS6	TATA spare parts
285626806501	Thin Nut ( M12 X 1.25 )	TATA spare parts
285626808206	MOUNTING CLIP (SHIFTER SIDE),TATA FICOSA	TATA spare parts
285626808702	Retention Spring	TATA spare parts
285726305401	BEVEL GEAR (ASSY DIFF.) FOR END GEARBOX	TATA spare parts
285726305402	BEVEL PINION (ASSY DIFF.) FOR END GEARBO	TATA spare parts
285726307801	OIL SEAL DRIVE SHAFT	TATA spare parts
285726307801_NIU01	OIL SEAL DRIVE SHAFT	TATA spare parts
285726309201	WASHER - DIFF BEVEL GEAR (0.4MM)	TATA spare parts
285726309201_niu1	WASHER - DIFF BEVEL GEAR (0.4MM)	TATA spare parts
285726309202	WASHER - DIFF. BEVEL GEAR (0.45MM)	TATA spare parts
285726309203	WASHER - DIFF. BEVEL GEAR (0.50MM)	TATA spare parts
285726309204	WASHER - DIFF. BEVEL GEAR (0.55MM)	TATA spare parts
285726309205	WASHER - DIFF. BEVEL GEAR (0.6MM)	TATA spare parts
285726309206	WASHER - DIFF. BEVEL GEAR (0.65MM)	TATA spare parts
285726309207	WAHSER - DIFF. BEVEL GEAR (0.7MM)	TATA spare parts
285726309208	WASHER - DIFF. BEVEL GEAR (0.75MM)	TATA spare parts
285726309209	WASHER - DIFF. BEVEL GEAR (0.8MM)	TATA spare parts
285726309210	WASHER - DIFF. BEVEL GEAR (0.85MM)	TATA spare parts
285726309211	WASHER - DIFF. BEVEL GEAR (0.9MM)	TATA spare parts
285726309212	WASHER - DIFF. BEVEL GEAR (0.95MM)	TATA spare parts
285726309213	WASHER - DIFF. BEVEL GEAR (1.0MM)	TATA spare parts
285933000106	FRONT AXLE ASSY WITH 3.73 & ABS	TATA spare parts
285933000111	ASSY DANA FA ARIA 4.1,ABS,LHD	TATA spare parts
285933103201	WHEEL BOLT (2009867-2)	TATA spare parts
285933150105	BEARING ASSY (W O RACE) 566063	TATA spare parts
285933150106	COVER AND MOTOR ASSY - DISCONNECT (20087	TATA spare parts
285933150107	MOTOR ASSY (2007805)	TATA spare parts
285933150108	KIT-ELECTRIC DISCONNECT MOTOR (2016152)	TATA spare parts
285933150109	KIT-ELECTRIC DISCONNECT MOTOR (2016153)	TATA spare parts
285933150113	AXLE BEAM ASSY (2017213)	TATA spare parts
285933150118	TUBE ASSY WITH COUPLING NUT	TATA spare parts
285933151604	RUBBER HOSE - ARIA EURO V & MERLIN.	TATA spare parts

285933153201	BOLT HEX (48631)	TATA spare parts
285933153401	BUSHING - SYNTHETIC (43342)	TATA spare parts
285933154401	COLLAR - FIN (42998)	TATA spare parts
285933154801	PIN - DOWEL	TATA spare parts
285933155301	GASKET (2008768)	TATA spare parts
285933157701	EDGE CLIP	TATA spare parts
285933157901	SHAFT - SHIFT FORK (2007801)	TATA spare parts
285933157902	SHAFT - INTERMEDIATE FIN (2006582)	TATA spare parts
285933157903	SHAFT - AXLE FIN(2006584)	TATA spare parts
285933158002	SCREW - FLANGE HEAD (52784-2)	TATA spare parts
285933158701	SPRING - COMPRESSION (2008669)	TATA spare parts
285933500101	GEAR & PINION ASSY (3.73) 2008776	TATA spare parts
285933500104	KIT-DRIVE GEAR AND PINION (2014265)	TATA spare parts
285933508001	SCREW (2003804-1)	TATA spare parts
285933508202	COVER DISCONNECT HOUSING FIN (2008682)	TATA spare parts
285933508601	SPACER - BRG PRELOAD (42104)	TATA spare parts
285933508602	SPACER - BRG PRELOAD (42104-35)	TATA spare parts
285933508603	SPACER - BRG PRELOAD (42104-37)	TATA spare parts
285933508604	SPACER - BRG PRELOAD (42104-39)	TATA spare parts
285933508605	SPACER - BRG PRELOAD (42104-41)	TATA spare parts
285933509201	BAFFLE - PINION OIL (2010247)	TATA spare parts
285933750101	SHAFT AND JOINT ASSY RH (2006562)	TATA spare parts
285933750102	SHAFT AND JOINT ASSY LH (2006563)	TATA spare parts
285933800103	BEARING AND SEAL ASSY (2012542)	TATA spare parts
285933800104	SPINDLE ASSY (2006520)	TATA spare parts
285933800107	KNUCKLE ASSY - STEERING RH (2008583-2)	TATA spare parts
285933800108	KNUCKLE SUB ASSY RH (2006512-2)	TATA spare parts
285933800109	KNUCKLE ASSY - STEERING LH (2008582-2)	TATA spare parts
285933800110	KNUCKLE SUB ASSY LH (2006511-2)	TATA spare parts
285933800114	WHEEL END AND SHAFT ASSY RH (2015528-2)	TATA spare parts
285933800115	WHEEL END AND SHAFT ASSY LH (2015529-2)	TATA spare parts
285933803401	BUSHING - SYNTHETIC (43337)	TATA spare parts
285933803703	KNUCKLE - STEERING RH FIN (2006349-2)	TATA spare parts
285933803704	KNUCKLE - STEERING LH FIN (2006347-2)	TATA spare parts
285933804201	CHART PIN (ROLL OR COTTER) 500025-10	TATA spare parts
285933804301	RING - SNAP (2012533)	TATA spare parts
285933804302	SNAP RING (46073)	TATA spare parts
285933806101	WASHER - FLAT (40596)	TATA spare parts
285933806102	SPRING - WAVE WASHER	TATA spare parts
285933806103	WASHER - THRUST (46075)	TATA spare parts
285933806104	WASHER - THRUST (46076)	TATA spare parts
285933806501	NUT HEX PINION (40597)	TATA spare parts
285933806502	RETAINER NUT (40598)	TATA spare parts
285933807201	PLUG - SHIPPING (2014010)	TATA spare parts
285933807901	SPINDLE - WHEEL BRG FIN (2006521)	TATA spare parts
285933808001	SCREW - DRIVE GEAR (2011846)	TATA spare parts
285933808201	SLINGER - DUST	TATA spare parts

286035300121	HYP GEAR SET ASSLY	TATA spare parts
286035307105	RETAINER -RX PICKUP	TATA spare parts
286035609203	WASHER	TATA spare parts
286201130103	ASSY.MAGNETIC DRAIN PLUG	TATA spare parts
286301000103	ENGINE 6BT (ISLE 375 HP LMFO)	TATA spare parts
286301000104	ASSY. ENGINE COMP. ISLE8.9-370HP BS3	TATA spare parts
286301000105	ASSY ENGINE COMPLETE (PRIMA 3138.K)	TATA spare parts
286301000107	CUMMINS ISLE 370-30 BS-III ENGINE	TATA spare parts
286301000118	ENGINE OPTION ISLE 370(3138.K AT)	TATA spare parts
286301000127	ENGINE ASSY COMPLETE (LPTA 3138)	TATA spare parts
286301000128	ASSY. ENGINE COMP.	TATA spare parts
286301000133	ASSY. ENGINE COMP. ISLE8.9-370HP BS3	TATA spare parts
286301000136	ENGINE	TATA spare parts
286301000148	ENGINE COMPLETE OPTION LIST	TATA spare parts
286301170101	BRACKET ASSY DIPSTICK MTG	TATA spare parts
286301173301	BRACKET (DIPSTICK MOUNTING)	TATA spare parts
286301173302	BRACKET (DIP STICK MOUNTING)	TATA spare parts
286301173304	DIPSTICK MOUNTING BRACKET	TATA spare parts
286301173305	DIPSTICK MGT BKT	TATA spare parts
286301990106	HOUSING BREATHER	TATA spare parts
286301990108	ISOLATOR VIBRATION	TATA spare parts
286301990109	DIPSTICK	TATA spare parts
286301990115	INJECTOR ISLE8.9 BS3	TATA spare parts
286301990119	LONG BLOCK ISLE809 EURO3 BS3	TATA spare parts
286301990120	INJECTOR	TATA spare parts
286301990121	KIT-GASKET UPPER	TATA spare parts
286301990122	KIT-GASKET LOWER	TATA spare parts
286301990125	CYLINDER HEAD BS3	TATA spare parts
286301990128	OIL SUMP	TATA spare parts
286301993101	BEARING MAIN	TATA spare parts
286301993102	BEARING MAIN	TATA spare parts
286301993401	BUSHING REDUCING PIPE	TATA spare parts
286301993701	CYLINDER HEAD BS3	TATA spare parts
286301993702	BLOCK CYLINDER	TATA spare parts
286301993703	HOUSING ENGINE BRAKE	TATA spare parts
286301993704	HOUSING ENGINE BRAKE	TATA spare parts
286301993708	BLOCK CYLINDER	TATA spare parts
286301994201	CUP WIRE RETAINING	TATA spare parts
286301994301	CLIP	TATA spare parts
286301994701	PLATE LINER REMOVER	TATA spare parts
286301994801	DOWEL PIN	TATA spare parts
286301994802	DOWEL PIN	TATA spare parts
286301995301	GASKET OILPAN	TATA spare parts
286301995302	GASKET VALVE COVER	TATA spare parts
286301995303	GASKET CYLINDER HEAD	TATA spare parts
286301996903	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
286301997201	PLUG/THREADED	TATA spare parts

286301997203	PLUG THREADED	TATA spare parts
286301997204	PLUGJHREADED	TATA spare parts
286301997205	PLUG THREADED BS4	TATA spare parts
286301997206	PLUG EXPANSION	TATA spare parts
286301998001	SCREW HEX. FLANGE HEAD CAP	TATA spare parts
286301998002	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286301998003	SCREW STUDDED FLANGE CAP	TATA spare parts
286301998004	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286301998005	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286301998006	SCREW STUDDED HEXAGON CAP	TATA spare parts
286301998007	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286301998008	SCREW SOCKETSET	TATA spare parts
286301998009	SCREW STUDDED FLANGE CAP	TATA spare parts
286301998010	SCREW HEX FLANGE HEAD BS4	TATA spare parts
286301998011	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286301998012	SCREW CAPTIVE WASHER CAP	TATA spare parts
286301998013	SCREW CAPTIVE WASHER CAP	TATA spare parts
286301998201	PAN OIL	TATA spare parts
286301998601	SPACERJHREADED	TATA spare parts
286301999201	WASHER PLAIN	TATA spare parts
286301999202	WASHER SEALING	TATA spare parts
286301999801	DIPSTICK	TATA spare parts
286301999802	INJECTOR	TATA spare parts
286301999803	DIPSTICK	TATA spare parts
286301999804	HOUSING ENGINE BRAKE	TATA spare parts
286301999805	HOUSING ENGINE BRAKE	TATA spare parts
286301999901	GASKET CYLINDER HEAD	TATA spare parts
286301999903	CUP PLUG DRIVING TOOLS UH BS4/SBS6	TATA spare parts
286301999908	RTV SILICONE SEALANT BS4/SBS6	TATA spare parts
286301999909	CUP PLUG DRIVING TOOLS DH (11/16-INCH) B	TATA spare parts
286301999910	CUP PLUG DRIVING TOOLS DH (2-1/4-INCH) B	TATA spare parts
286301999912	CYL LINER PULLER	TATA spare parts
286301999916	CLEANER QD CONTACT	TATA spare parts
286301999919	RING SPEED INDICATOR	TATA spare parts
286301999920	LINER CYLINDER BS2/3	TATA spare parts
286301999921	CAP ADJUSTING NUT	TATA spare parts
286301999922	PLUG EXPANSION BS1/3/4/6	TATA spare parts
286301999923	UNION MALE	TATA spare parts
286301999924	PLUG EXPANSION	TATA spare parts
286301999925	SEAL RECTANGULAR RING	TATA spare parts
286301999927	PLUG EXPANSION	TATA spare parts
286301999928	UNION MALE	TATA spare parts
286301999929	BLOW BY TOOL 0.302 ORIFICE	TATA spare parts
286301999930	LUBRICATING OIL COOLER PRESSURE TEST KIT	TATA spare parts
286301999935	TEE PLAIN ADAPTER	TATA spare parts
286301999936	HOUSING BREATHER	TATA spare parts
286301999944	ELBOW MALE ADAPTER	TATA spare parts

28630199945	CONNECTOR QCK DISCONNECT	TATA spare parts
286303114701	COVER FLYWHEEL HOUSING	TATA spare parts
286303990104	CRANKSHAFT ENGINE	TATA spare parts
286303990106	DAMPER VISCOUS VIBRATION	TATA spare parts
286303990108	CRANKSHAFT ENGINE	TATA spare parts
286303990109	ROD ENGINE CONNECTING	TATA spare parts
286303990111	FLYWHEEL	TATA spare parts
286303990115	KIT-PISTON (WITH RINGS)	TATA spare parts
286303990117	CONNECTING ROD	TATA spare parts
286303990118	DAMPER VISCOUS VIBRATION	TATA spare parts
286303990119	FLYWHEEL HOUSING	TATA spare parts
286303993101	BEARING CONNECTING ROD	TATA spare parts
286303993402	BUSHING	TATA spare parts
286303993404	BUSHING	TATA spare parts
286303993705	HOUSING FLYWHEEL	TATA spare parts
286303994702	PLATE COVER	TATA spare parts
286303994703	PLATE COVER	TATA spare parts
286303995301	GASKET ACTUATOR	TATA spare parts
286303995401	PULLEY CRANKSHAFT	TATA spare parts
286303996603	TOP PISTON	TATA spare parts
286303996604	SKIRT PISTON	TATA spare parts
286303996605	RING SET (STANDARD)	TATA spare parts
286303996701	PIN PISTON	TATA spare parts
286303997701	SEAL O RING	TATA spare parts
286303997702	SEAL OIL	TATA spare parts
286303997703	SEAL O RING	TATA spare parts
286303998001	SCREW CONNECTING ROD CAP	TATA spare parts
286303998003	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286303999901	CAP MAIN BEARING	TATA spare parts
286303999903	FLYWHEEL	TATA spare parts
286303999904	ADAPTER CRANKSHAFT	TATA spare parts
286303999907	EXPANDER PISTON	TATA spare parts
286303999909	NOZZLE PISTON COOLING	TATA spare parts
286303999910	RING COMPRESSION PISTON	TATA spare parts
286303999911	RING COMPRESSION PISTON	TATA spare parts
286303999912	ADAPTER CRANKSHAFT	TATA spare parts
286303999913	SUPPORT CAMSHAFT THRUST	TATA spare parts
286303999914	RING OIL PISTON	TATA spare parts
286303999915	PISTON RING COMPRESSOR	TATA spare parts
286303999916	NOZZLE PISTON	TATA spare parts
286305990109	ASSEMBLY ROCKER LEVER	TATA spare parts
286305990111	HOUSING ROCKER LEVER	TATA spare parts
286305993401	GUIDE VALVE STEM	TATA spare parts
286305993402	INSERT VALVE	TATA spare parts
286305993403	INSERT VALVE	TATA spare parts
286305993701	COVER VALVE	TATA spare parts
286305993702	HOUSING ROCKER LEVER	TATA spare parts



286305993703	HOUSING GEAR	TATA spare parts
286305994701	COVER GEAR	TATA spare parts
286305995301	GASKET REAR COVER	TATA spare parts
286305995302	GASKET RKR LEVER HOUSING	TATA spare parts
286305995401	GEAR CAMSHAFT	TATA spare parts
286305995405	GEAR CAMSHAFT	TATA spare parts
286305996501	NUT	TATA spare parts
286305996503	NUT LOCK	TATA spare parts
286305997702	SEAL VALVE STEM	TATA spare parts
286305997703	SEAL VALVE STEM	TATA spare parts
286305997902	CAMSHAFT	TATA spare parts
286305997903	ROD PUSH	TATA spare parts
286305998001	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286305998007	SCREW STUDED FLANGE CAP	TATA spare parts
286305999001	TAPPET VALVE	TATA spare parts
286305999002	VALVE INTAKE	TATA spare parts
286305999003	VALVE EXHAUST	TATA spare parts
286305999901	GUIDE TAPPET	TATA spare parts
286305999902	RETAINER VALVE SPRING	TATA spare parts
286305999903	SEAL VALVE ST	TATA spare parts
286305999904	SPRING VALVE	TATA spare parts
286305999905	VALVE INTAKE	TATA spare parts
286305999906	VALVE EXHAUST	TATA spare parts
286305999910	GAUGE FEELER	TATA spare parts
286305999911	LUBRICATION OIL SEAL INSTALLATION TOOL	TATA spare parts
286305999912	CROSSHEAD VALVE	TATA spare parts
286305999913	CROSSHEAD VALVE	TATA spare parts
286305999915	CAM BUSHING DRIVER	TATA spare parts
286305999916	CAM SHAFT BUSHING TOOL	TATA spare parts
286307990105	PUMP FUEL TRANSFER	TATA spare parts
286307990109	PUMP FUEL INJECTION	TATA spare parts
286307990110	MANIFOLD FUEL	TATA spare parts
286307990111	TUBE FUEL SUPPLY	TATA spare parts
286307990125	PUMP,FUEL INJECTION ISLe8.9 BS3	TATA spare parts
286307993301	BRACKET TRANSFER PUMP	TATA spare parts
286307993302	BRACKET FILTER	TATA spare parts
286307994201	CLIP	TATA spare parts
286307994202	CLAMP INJECTOR	TATA spare parts
286307994203	CLAMP TUBE BS6	TATA spare parts
286307994301	CLIP WIRE RETAINING	TATA spare parts
286307994701	PLATE FUEL PUMP MOUNTING	TATA spare parts
286307995401	GEAR FUEL PUMP	TATA spare parts
286307995402	GEAR FUEL PUMP	TATA spare parts
286307995403	GEAR FUEL PUMP	TATA spare parts
286307995404	GEAR FUEL PUMP ISLE8.9 BS3	TATA spare parts
286307996903	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
286307996904	TUBE FUEL SUPPLY	TATA spare parts

286307996905	TUBE FUEL SUPPLY	TATA spare parts
286307996908	TUBEINJECTOR FUEL SUPPLY	TATA spare parts
286307996909	TUBEINJECTOR FUEL SUPPLY	TATA spare parts
286307996910	TUBEINJECTOR FUEL SUPPLY	TATA spare parts
286307996911	TUBE FUEL SUPPLY	TATA spare parts
286307996912	TUBE FUEL DRAIN	TATA spare parts
286307996913	TUBE FUEL DRAIN	TATA spare parts
286307996914	TUBE FUEL SUPPLY	TATA spare parts
286307996915	TUBE FUEL DRAIN	TATA spare parts
286307996916	TUBE FUEL SUPPLY	TATA spare parts
286307996917	TUBE FUEL SUPPLY	TATA spare parts
286307996918	TUBE FUEL SUPPLY	TATA spare parts
286307996919	TUBE FUEL SUPPLY	TATA spare parts
286307996922	TUBE FUEL DRAIN	TATA spare parts
286307997710	SEAL O RING	TATA spare parts
286307998005	SCREW HEX FLANGE HEAD	TATA spare parts
286307998006	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286307998007	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286307999001	VALVE CHECK BS4	TATA spare parts
286307999001AE	VALVE CHECK 1628	TATA spare parts
286307999203	WASHER SEALING	TATA spare parts
286307999204	WASHER SEAUNG	TATA spare parts
286307999205	WASHER SEALING	TATA spare parts
286307999804	MANIFOLD FUEL	TATA spare parts
286307999901	FUEL FILTER BS3	TATA spare parts
286307999907	BRACE TUBE	TATA spare parts
286307999908	BRACE TUBE	TATA spare parts
286307999911	ACTUATOR ETR FUEL CONTROL	TATA spare parts
286307999913	CONNECTION ADAPTER	TATA spare parts
286307999914	VALVE CHECK	TATA spare parts
286307999915	TESTER FUEL SYSTEM LEAK	TATA spare parts
286307999917	PRESSURE ADAPTER BS4/SBS6	TATA spare parts
286307999919	ADAPTER FUEL CONNECTOR	TATA spare parts
286307999920	FILTER FUEL	TATA spare parts
286307999921	FILTER FUEL	TATA spare parts
286307999922	CONNECTOR QCK DISCONNECT	TATA spare parts
286307999923	UNION MALE	TATA spare parts
286307999924	CONNECTION ADAPTER	TATA spare parts
286307999925	SUPPORT FUELPUMP	TATA spare parts
286307999926	SUPPORT FILTER	TATA spare parts
286307999927	CONNECTION FUEL BLOCK	TATA spare parts
286307999928	ADAPTER FUEL CONNECTOR	TATA spare parts
286307999929	SCREW DRIVE	TATA spare parts
286307999931	RETAINER INJ FUL SUP CNR BS4	TATA spare parts
286307999938	CONNECTOR QUICK CONNECT	TATA spare parts
286307999940	FUEL PUMP GEAR PULLER	TATA spare parts
286309130114	ASSY STRAP	TATA spare parts

286309130183	ISOLATOR (FOR SNORKEL)	TATA spare parts
286309130191	AIR FILTER BS3	TATA spare parts
286309130193	SUCTION PIPE ASSY	TATA spare parts
286309130194	CLEAN AIR DUCT ASSY	TATA spare parts
286309130195	AIR FILTER HOUSING ASSY	TATA spare parts
286309130200	RUBBER BELLOW ASSY	TATA spare parts
286309130204	ASSY BRACKET RH(SNORKEL MTG UPPER)	TATA spare parts
286309130205	ASSY BRACKET RH(SNORKEL MTG LOWER)	TATA spare parts
286309130206	AIR FILTER MOUNTING BKT	TATA spare parts
286309130208	ASSY BRACKET LH (SNORKEL MTG UPPER)(LPTA	TATA spare parts
286309130209	ASSY BRACKET LH (SNORKEL MTG LOWER)(LPTA	TATA spare parts
286309130211	SET AIR INTAKE ASSY (3138.K)	TATA spare parts
286309130217	AIR PROTECTOR BKT RH (AIR FILTER)	TATA spare parts
286309130218	AIR PROTECTOR BKT LH(AIR FILTER)LPTA3138	TATA spare parts
286309130219	ASSY AIR FILTER MTG BKT (3138.K LHD)	TATA spare parts
286309130233	DUCT ASSY AIRINTAKE SYSTEM	TATA spare parts
286309130234	SET AIR INTAKE SYSTEM (4438.S ME)	TATA spare parts
286309130236	SET AIR INTAKE SYSTEM 2540.K	TATA spare parts
286309130240	ASSY AIR FILTER BRACKET	TATA spare parts
286309130242	AIR CLEANER ASSY	TATA spare parts
286309130243	BRACKET ASSY POWDER COATED	TATA spare parts
286309130244	ASSY BRACKET	TATA spare parts
286309130249	PIPE ASSY	TATA spare parts
286309130264	BRACKETASSY AIRFILTERMTG	TATA spare parts
286309130268	ARRANGEMENT AIR INTAKE SYSTEM	TATA spare parts
286309130269	RAIN HOOD SNORKEL	TATA spare parts
286309130270	AIR FILTER	TATA spare parts
286309130271	SUPPORT BRACKET ASSY TC PIPE INLET	TATA spare parts
286309130272	AIR INTAKE PIPE ASSY A/F TO T/C	TATA spare parts
286309130273	PIPE ASSY AIR FILTER TO TC	TATA spare parts
286309130277	PIPE ASSY AIR FILTER	TATA spare parts
286309133201	HEX FL BOLT M14X1.5X170	TATA spare parts
286309133316	SUPPORT BRACKET (AIR FILTER TO TC PIPE)	TATA spare parts
286309133332	MOUNTING BRACKET	TATA spare parts
286309133339	BRACKET AIR FILTER PIPE TO TC	TATA spare parts
286309134202	HOSE CLAMP (DUST UNLOADER VALVE)	TATA spare parts
286309134204	HOSE CLAMP	TATA spare parts
286309134205	HOSE CLAMP	TATA spare parts
286309134206	HOSE CLAMP	TATA spare parts
286309134301	CLIP (AIR FILTER LOCKING)	TATA spare parts
286309135801	HOSE (AIR FILTER OUTLET)	TATA spare parts
286309135828	HOSE (AIR FILTER TO TC)	TATA spare parts
286309135829	HUMP HOSE (TC )	TATA spare parts
286309135834	HOSE (TC - AIR FILTER PIPE) LPTA 3138	TATA spare parts
286309135836	REDUCER HOSE	TATA spare parts
286309135837	COBRA HOSE	TATA spare parts
286309135838	HOSE ELBOW	TATA spare parts

286309135840	REDUCER HOSE	TATA spare parts
286309136313	SNORKEL	TATA spare parts
286309136905	PIPE (TC TO AIR FILTER LPTA 3138 8X8)	TATA spare parts
286309136924	PIPE ASSY.	TATA spare parts
286309136925	PIPE ASSY.	TATA spare parts
286309136930	PIPE ASY	TATA spare parts
286309137704	DUST UNLOADER VALVE	TATA spare parts
286309137705	WATER RETURN VALVE	TATA spare parts
286309137707	RUBBER SLEEVE	TATA spare parts
286309137709	WATER RETURN VALVE SNORKEL	TATA spare parts
286309139928	AIR FILTER ELEMENT (PRIMARY) BS3	TATA spare parts
286309139929	AIR FILTER ELEMENT (SAFETY) BS3	TATA spare parts
286309139932	SERVICE INDICATOR	TATA spare parts
286309990102	CONNECTION AIR INTAKE	TATA spare parts
286309990103	PUMP FUEL TRANSFER	TATA spare parts
286309990104	CONNECTION AIR TRANSFER	TATA spare parts
286309990105	CONNECTION AIR TRANSFER	TATA spare parts
286309994201	CLAMP V BAND BS1/2/3/4	TATA spare parts
286309995301	GASKET CONNECTION	TATA spare parts
286309998001	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286309999901	UNION MALE	TATA spare parts
286313135803	HOSE AIR COMPRESSOR TO PIPE	TATA spare parts
286313135804	HOSE	TATA spare parts
286313136902	PIPE AIR COMPRESSOR	TATA spare parts
286313990103	COMPRESSOR AIR	TATA spare parts
286313994201	CLAMP HOSE	TATA spare parts
286313995401	GEAR ACCE DRIVE	TATA spare parts
286313995802	HOSE FLEXIBLE	TATA spare parts
286313995803	HOSE PLAIN	TATA spare parts
286313996903	TUBE CPR WATER OUTLET	TATA spare parts
286313996904	TUBE COMPRESSOR AIR INLET	TATA spare parts
286313996909	TUBE WATER TRANSFER	TATA spare parts
286313997701	OIL DRAIN PLUG O RING	TATA spare parts
286313997702	SEAL O RING	TATA spare parts
286313999905	COUPUNG ELBOW HOSE	TATA spare parts
286313999906	TEE PLAIN ADAPTER	TATA spare parts
286313999907	BRACE JU BE	TATA spare parts
286313999908	BRACE TUBE	TATA spare parts
286313999909	BRACE TUBE	TATA spare parts
286314110102	ASSY. UREA DOSE PUMP BS4	TATA spare parts
286314110109	EXHAUST GAS PROCESSOR ASSY	TATA spare parts
286314600101	ASSY BRACKET (TC TO IC PIPE SUPPORT)	TATA spare parts
286314603305	SUPPORT BRACKET (TC TO IC PIPE )	TATA spare parts
286314603307	BRACKET (TC TO IC PIPE SUPPORT)	TATA spare parts
286314603310	SUPPORT BRACKET (TC TO IC PIPE)	TATA spare parts
286314604201	CLAMP (FOR INTERCOOLER PIPE CLAMPING)	TATA spare parts
286314605801	HOSE HUMP --	TATA spare parts

286314606901	PIPE (IC TO ENGINE)	TATA spare parts
286314606903	PIPE (TC TO IC) LPK 2528	TATA spare parts
286314606904	PIPE (TC TO IC) LPTA 3138	TATA spare parts
286314606905	PIPE (IC TO ENG) LPTA 3138	TATA spare parts
286314606906	PIPE (TC TO IC)	TATA spare parts
286314606914	PIPE TURBOCHARGER TO IC LPTA 4545	TATA spare parts
286314609907	ASSY. INTERCOOLER BS3	TATA spare parts
286314609908	INTERCOOLER (LPTA 3138)	TATA spare parts
286314609911	INTERCOOLER	TATA spare parts
286314609912	ASSY. INTERCOOLER W/CONDENSER MTG BS3/4	TATA spare parts
286314990101	ASSY. TURBOCHARGER BS3	TATA spare parts
286314990107	TURBOCHARGER	TATA spare parts
286314990108	TURBOCHARGER	TATA spare parts
286314990111	TURBO CHARGER	TATA spare parts
286314993301	BRACKET EXH CONNECTION	TATA spare parts
286314993701	MANIFOLD EXHAUST	TATA spare parts
286314993702	MANIFOLD EXHAUST	TATA spare parts
286314994201	CLAMP V BAND	TATA spare parts
286314994701	COVER INTAKE MANIFOLD	TATA spare parts
286314994702	COVER INTAKE MANIFOLD	TATA spare parts
286314995301	GASKET EXHAUST MANIFOLD	TATA spare parts
286314995302	GASKET EXHAUST MANIFOLD	TATA spare parts
286314995303	GASKET TURBOCHARGER	TATA spare parts
286314995801	HOSE FLEXIBLE	TATA spare parts
286314995802	HOSE FLEXIBLE	TATA spare parts
286314995804	HOSE FLEXIBLE	TATA spare parts
286314996501	NUT TWELVE POINT	TATA spare parts
286314996901	CONNECTION TUR OIL DRAIN	TATA spare parts
286314996902	TUBE WATER TRANSFER	TATA spare parts
286314996903	TUBE AIR	TATA spare parts
286314996904	TUBE AIR	TATA spare parts
286314996905	TUBE TUR OIL DRAIN	TATA spare parts
286314997201	PLUG PIPE	TATA spare parts
286314997202	PLUG THREADED	TATA spare parts
286314998001	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286314998801	STUD DOUBLE END COLLAR	TATA spare parts
286314999801	UNION MALE ADAPTER	TATA spare parts
286314999802	VALVE AIR CONTROL	TATA spare parts
286314999803	CONNECTION EXHAUST OUTLET	TATA spare parts
286314999902	CONNECTION EXHAUST OUTLET	TATA spare parts
286314999903	MANIFOLD EXHAUST	TATA spare parts
286315260101	SPEED SENSOR	TATA spare parts
286315260102	PRESSURE/TEMPERATURE SENSOR	TATA spare parts
286315990105	ALTERNATOR	TATA spare parts
286315990107	DIGITAL MULTMETER	TATA spare parts
286315990109	HARNESS WIRING	TATA spare parts
286315990110	HARNESS WIRING	TATA spare parts

286315990111	HEATERJNTAKEAIR	TATA spare parts
286315990112	HARNESS WIRING	TATA spare parts
286315990113	HARNESS WIRING	TATA spare parts
286315990114	HARNESS WIRING	TATA spare parts
286315990121	HARNESS WIRING	TATA spare parts
286315990122	MOTOR,STARTING ISLe8.9 BS3	TATA spare parts
286315990127	KIT-WIRING HARNESS	TATA spare parts
286315990140	MODULE ELECTRONIC CONTROL	TATA spare parts
286315993302	S R E BRACKET ASSY	TATA spare parts
286315993303	BRACE TUBE	TATA spare parts
286315997001	PULLEY ALTERNATOR	TATA spare parts
286315998001	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286315998002	SCREW CAPTIVE WASHER	TATA spare parts
286315998003	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286315998004	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286315998005	SCREW SOCKET HEAD CAP BS4	TATA spare parts
286315998006	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286315998601	SPACER STARTING MOTOR	TATA spare parts
286315999201	WASHER LOCK	TATA spare parts
286315999801	WIRING HARNESS	TATA spare parts
286315999802	HARNESS ETR CNT MDL WRG	TATA spare parts
286315999803	SENSOR POSITION	TATA spare parts
286315999804	HARNESS ETR CNT MDL WRG	TATA spare parts
286315999805	SENSOR PRESSURE	TATA spare parts
286315999908	COOLER ELECTRONIC CONTROL	TATA spare parts
286315999909	WIRE GROUND	TATA spare parts
286315999910	SENSOR POSITION	TATA spare parts
286315999910AE	SENSOR POSITION 1628 1828	TATA spare parts
286315999911	SENSOR POSITION	TATA spare parts
286315999912	WIRE GROUND	TATA spare parts
286315999913	SENSOR PRESSURE	TATA spare parts
286315999913AE	SENSOR PRESSURE 1628 1828	TATA spare parts
286315999914	SWITCH PRESSURE BS4	TATA spare parts
286315999914AE	SWITCH PRESSURE 1628 1828	TATA spare parts
286315999915	SENSOR PRS TEMPERATURE	TATA spare parts
286315999915AE	SENSOR PRS TEMPERATURE-1628-1828	TATA spare parts
286315999916	SENSOR TEMPERATURE BS4	TATA spare parts
286315999916AE	SENSOR TEMPERATURE 1628 1828	TATA spare parts
286315999917	INSITE BASIC REGISTRATION	TATA spare parts
286315999918	INSITE LITE REGISTRATION	TATA spare parts
286315999919	INSITE PRO REGISTRATION	TATA spare parts
286315999920	CABLE ELECTRICAL	TATA spare parts
286315999921	CABLE ELECTRICAL	TATA spare parts
286315999922	BETT UPDATE-BASIC ELECT	TATA spare parts
286315999925	QUICK-CHECK	TATA spare parts
286315999927	VIRTUAL COLLEGE CD	TATA spare parts
286315999928	CONNECTOR ELECTRICAL	TATA spare parts

28631599929	BRACE ALTERNATOR	TATA spare parts
28631599930	BRACE ALTERNATOR	TATA spare parts
28631599933	WIRE GROUND	TATA spare parts
28631599959	PRESSURE/TEMPERATURE SENSOR BS3/4	TATA spare parts
28631599960	HARNESS WIRING	TATA spare parts
28631599961	ROTOR	TATA spare parts
28631599962	REGULATOR ASSY	TATA spare parts
28631599963	FASTENERS KIT	TATA spare parts
28631599964	PLUG MOULDING ASSY KIT	TATA spare parts
286318990101	HEAD LUB OIL FILTER	TATA spare parts
286318990103	CAP FILLER	TATA spare parts
286318990109	PUMP LUBRICATING OIL	TATA spare parts
286318990112	PUMP LUBRICATING OIL	TATA spare parts
286318994301	CLIP	TATA spare parts
286318994801	DOWEL RING	TATA spare parts
286318995301	GASKET CONNECTION	TATA spare parts
286318995302	GASKET LUB OIL CLR COVERN	TATA spare parts
286318995303	GASKET OIL SUC CONNECTION	TATA spare parts
286318995801	HOSE PLAIN	TATA spare parts
286318995802	HOSE FLEXIBLE	TATA spare parts
286318996902	CONNECTION TUR OIL DRAIN	TATA spare parts
286318996903	CONNECTION OIL SUCTION	TATA spare parts
286318996904	TUBE OIL GAUGE	TATA spare parts
286318996905	BRACEJUBE	TATA spare parts
286318996906	TUBE LUB OIL DRAIN	TATA spare parts
286318996907	TUBE LUB OIL DRAIN	TATA spare parts
286318997702	SEAL RECTANGULAR RING	TATA spare parts
286318997801	SEAL& O RING	TATA spare parts
286318998001	SCREW TWELVE POINT CAP	TATA spare parts
286318999902	OIL FILTER WRENCH	TATA spare parts
286318999903	CONNECTION ADAPTER	TATA spare parts
286318999904	BRACE TUBE	TATA spare parts
286318999905	CORE COOLER	TATA spare parts
286318999906	CAP FILLER	TATA spare parts
286318999908	CONNECTION OIL FILLER	TATA spare parts
286318999909	CORE COOLER	TATA spare parts
286320150101	PIPE ASSY OIL COOLER OUTLET	TATA spare parts
286320150103	FILTER ELEMENT	TATA spare parts
286320150104	BLOCK	TATA spare parts
286320990101	CONNECTION WATER OUTLET	TATA spare parts
286320990102	TENSIONER BELT	TATA spare parts
286320990103	THERMOSTAT	TATA spare parts
286320990111	WATER PUMP	TATA spare parts
286320990117	FAN ENGINE	TATA spare parts
286320993101	BEARING BALL	TATA spare parts
286320995301	GASKET CONNECTION	TATA spare parts
286320995501	HUB FAN	TATA spare parts

286320996301	BELT V RIBBED BS2/3	TATA spare parts
286320996303	BELT V RIBBED	TATA spare parts
286320997101	PLATE CLAMPING	TATA spare parts
286320998001	SCREW HEXAGON HEAD CAP	TATA spare parts
286320998002	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286320998003	SCREW BANJO CONNECTOR	TATA spare parts
286320998601	SPACER FAN PILOT	TATA spare parts
286320999201	WASHER SEALING	TATA spare parts
286320999901	RING RETAINING	TATA spare parts
286320999902	RETAINER FAN HUB	TATA spare parts
286320999903	SUPPORT FAN	TATA spare parts
286320999905	THERMOSTAT	TATA spare parts
286320999906	PUMP WATER	TATA spare parts
286322100101	INSL ENG MTG FRT	TATA spare parts
286322100102	INSL ENG MTG RR	TATA spare parts
286322100103	ENGINE MOUNT FRONT	TATA spare parts
286322993301	BRACKET ENGINE LIFTING	TATA spare parts
286322993302	BRACKET ENGINE LIFTING	TATA spare parts
286322998001	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286322998002	SCREW STUDDED FLANGE CAP	TATA spare parts
286322998003	SCREW HEX FLANGE HEAD CAP	TATA spare parts
286323120107	ASSY AC COMPRESSOR	TATA spare parts
286323120108	ASSY. BRACKET A/C COMPRESSOR MOUNTING	TATA spare parts
286323120109	ASSY. BRACKET A/C COMPRESSOR MOUNTING	TATA spare parts
286323120110	BRACKET (A/C COMP MTG & BELT TENSIONER)	TATA spare parts
286323120112	BRACKET AC COMPRESSOR MTG	TATA spare parts
286323123303	BRACKET (A/C COMP MTG & BELT TENSIONER)	TATA spare parts
286323126301	BELT (1175 MM LENGTH)	TATA spare parts
286323126302	PULLEY BELT COGGED	TATA spare parts
286323995301	GASKET ACC DRIVE SUPPORT	TATA spare parts
286350000103	CUSHION RUBBER (RAD LOWER MTG)	TATA spare parts
286350000106	FILL PIPE ASSY	TATA spare parts
286350000107	ASSEMBLY BRACKET (IC MOUNTING)	TATA spare parts
286350000108	ASSEMBLY BRACKET RH (IC MOUNTING)	TATA spare parts
286350000111	FILL PIPE ASSY	TATA spare parts
286350000115	ASSY BRACKET LH (RADIATOR MOUNTING - BOT	TATA spare parts
286350000116	ASSY BRACKET RH (RADIATOR MOUNTING - BO	TATA spare parts
286350000118	ASSY BRACKET RH (RADIATOR MOUNTING TOP S	TATA spare parts
286350000118AE	ASSY BRKT R(RAD MNTNG TOP) -1628	TATA spare parts
286350000119	ASSY BRACKET LH (RADIATOR MOUNTING TOP S	TATA spare parts
286350000119AE	BRKT RH (RAD.MNTNG TOP) -1628	TATA spare parts
286350000120	ASSY BKT RH (AUX WATER TANK MTG)	TATA spare parts
286350000120AE	ASSY BRKT R(AUX WTR TK MTG)-1628	TATA spare parts
286350000121	ASSY. BKT LH (AUX WATER TANK MTG)	TATA spare parts
286350000121AE	BRKT RH (AUX WATER TNK MTG)-1628	TATA spare parts
286350000122	ASSY. BRACKET RH (RAD MTG ON CHASSIS)	TATA spare parts
286350000123	ASSY. BRACKET LH (RAD MTG ON CHASSIS)	TATA spare parts



286350000124	ASSY PIPE (RAD TO WATER INLET)	TATA spare parts
286350000125	ASSY FILL PIPE	TATA spare parts
286350000129	ASSY FILL PIPE (LPTA 2038)	TATA spare parts
286350000170	ASSY BKT (VENT HOSE SUPPORT)	TATA spare parts
286350000171	ASSY PIPE (RAD TO ENGINE)	TATA spare parts
286350000176	ASSY BKT RAD MGT	TATA spare parts
286350000177	ASSY BKT RAD MGT	TATA spare parts
286350000178	ASSY BRACKET LOWER RAD MOUNTING	TATA spare parts
286350000196	PIPE ASSY RADIATOR TO WATER INLET	TATA spare parts
286350000201	PIPE RAD TO ENGINE	TATA spare parts
286350000202	VENT HOSE ASSY(RAD TO AUX TANK)	TATA spare parts
286350000203	VENT HOSE ASSY (AUX TANK TO ENGINE)	TATA spare parts
286350000213	PIPE ASSY RADIATOR TO WATER INLET	TATA spare parts
286350000221	PIPE ASSY OIL COOLER TO ENGINE -	TATA spare parts
286350000232	ASSY BRACKET RH (RAD MTG - ON CHASSIS)	TATA spare parts
286350000233	BRACKET ASSY RADIATOR FRAME MTG LH	TATA spare parts
286350003301	BRACKET (RAD LOWER MTG)	TATA spare parts
286350003302	BRACKET (RAD LOWER MTG - FRAME)	TATA spare parts
286350003303	BRACKET - LH (RADIATOR MOUNTING)	TATA spare parts
286350003304	BRACKET - RH (RADIATOR MOUNTING)	TATA spare parts
286350003307	BRACKET LH (RADIATOR MOUNTING)	TATA spare parts
286350003308	BRACKET (RAD MTG RH)	TATA spare parts
286350003314	BRACKET LH (RAD LOWER MTG-FRAME)	TATA spare parts
286350003315	BRACKET RH (RAD LOWER MTG-FRAME)	TATA spare parts
286350003316	BRACKET (RAD LOWER MTG)	TATA spare parts
286350003318	RAD MOUNTING BRACKET (LH)	TATA spare parts
286350003319	RADIATOR MOUNTING BRACKET(RH)	TATA spare parts
286350003320	RADIATOR MOUNTING BRACKET(LH)	TATA spare parts
286350003321	RADIATOR MOUNTING BRACKET (RH)	TATA spare parts
286350006302	RUBBER BUFFER (FOR AUX TANK HOSE)	TATA spare parts
286350008801	STUD F' TYPE	TATA spare parts
286350009201	WASHER (FOR RUBBER BUFFER)	TATA spare parts
286350100105	ASSY. CLAMP (FOR WATER FILL HOSE)	TATA spare parts
286350100107	ASSY. RADIATOR BS3/4	TATA spare parts
286350100107AE	ASSY. RADIATOR 1628 1828	TATA spare parts
286350100113	ASSY. AUXILLIARY WATER TANK BS3/4	TATA spare parts
286350100114	ASSY. RADIATOR	TATA spare parts
286350100117	SET COOLING SYSTEM 4938.S	TATA spare parts
286350100122	ASSY. RADIATOR	TATA spare parts
286350100144	SET-COOLING SYSTEM WITH FAN SHROUD	TATA spare parts
286350100149	AIR VENT TUBE	TATA spare parts
286350104202	CLAMP (FOR VENT TUBE)	TATA spare parts
286350105802	HOSE(RADIATOR TO ENGINE)	TATA spare parts
286350105803	HOSE (ENGINE TO RAD)	TATA spare parts
286350105807	HOSE (RAD PIPE TO FILL PIPE) (RAD PIPE T	TATA spare parts
286350105809	VENT HOSE (ENG TO AUX TANK)	TATA spare parts
286350105810	VENT HOSE (RADIATOR TO AUX TANK)	TATA spare parts

286350105812	HOSE AUX WATER TANK TO FILLER PIPE	TATA spare parts
286350105813	HOSE (AUX. WATER TANK TO FILL PIPE)	TATA spare parts
286350105816	HOSE (RADIATOR TO ENGINE)	TATA spare parts
286350105817	HOSE (RADIATOR TO ENGINE)	TATA spare parts
286350105818	HOSE (WATER FILL PIPE)	TATA spare parts
286350105819	HOSE (ENGINE TO RAD)(LPTA3138)	TATA spare parts
286350105821	HOSE (9 ID X 500L)	TATA spare parts
286350105821AE	AUX TANK TO RAD HOSE 1628	TATA spare parts
286350105822	HOSE (AUX TANK TO ENG)(LPTA_3138)	TATA spare parts
286350105822AE	HOSE AUX WTR TANK ENG-1628-1828	TATA spare parts
286350105823	HOSE (28.6 ID X 350L)	TATA spare parts
286350105823AE	HOSE AX WTR TNK T FILL PIPE-1628	TATA spare parts
286350105825	HOSE REDUCER DIA76 TO 58(RAD.TO ENGINE)	TATA spare parts
286350105830	HOSE(ENG TO RAD)	TATA spare parts
286350105831	VENT HOSE	TATA spare parts
286350105842	HOSE (9 ID X 250L)	TATA spare parts
286350105851	HOSE	TATA spare parts
286350106901	PIPE (RAD TO ENG)	TATA spare parts
286350106905	PIPE (RAD TO ENG) LPTA 3138	TATA spare parts
286350106906	PIPE (ENGINE TO RADIATOR)	TATA spare parts
286350106910	VENT TUBE (ENG TO AUX WATER TANK)	TATA spare parts
286350106918	VENT TUBE (ENG TO AUX WATER TANK)LPTA313	TATA spare parts
286350106923	VENT TUBE	TATA spare parts
286350106934	VENT TUBE ASSY (ENG TO AUX TANK)LPTA4545	TATA spare parts
286350106948	AIR VENT TUBE TO TURBO	TATA spare parts
286350106949	VENT TUBE	TATA spare parts
286350500102	AIR PROTECTOR (RADIATOR UPPER)	TATA spare parts
286350500103	FAN SHROUD (FOR 26 INCH RING FAN)	TATA spare parts
286350506301	FAN SHROUD (FOR 26 INCH RING FAN)(LPTA 3	TATA spare parts
286350506301AE	FAN SHROUD 1628	TATA spare parts
286350506302	FAN SHROUD(26 INCH WT)	TATA spare parts
286350506304	FAN SHROUD (28 IN JET RING FAN)(LPTA 203	TATA spare parts
286350506306	FAN SHROUD (28 INCH) 3138.K	TATA spare parts
286350506310	FAN SHROUD (28" OPEN BLADE FAN LPTA	TATA spare parts
286350999901	TESTER COOLANT SYSTEM BS4/SBS6	TATA spare parts
286400000102	ASSY.ENG.COMPLETE (TCIC) HVAC+P.STG	TATA spare parts
286400000106	ASSY.ENG.COMPLETE BS-III (TCIC) HVAC+PS	TATA spare parts
286400000108	ASSY ENGINE COMPLETE (E-II HD+P.STG)	TATA spare parts
286400000109	ASSY ENGINE COMPLETE (MICROBUS BS-III)	TATA spare parts
286400000111	ASSY ENG COMPLETE TCIC(1TON BS-III)	TATA spare parts
286400000117	ASSY. ENG.COMP. HVAC & PSTG.(EURO-II)	TATA spare parts
286400000122	ASSY. ENGINE COMPLETE	TATA spare parts
286400000125	ASSY. ENGINE COMPLETE AC AND PSTG	TATA spare parts
286400000126	ASSY. ENGINE COMPLETE (BS-I)	TATA spare parts
286400000127	ASSY. ENGINE COMPLETE (BS-I)	TATA spare parts
286400000128	ASSY. ENGINE COMPLETE EURO-II PSTG.	TATA spare parts
286400000129	ENGINE COMPLETE	TATA spare parts

286401000104	ASSY ENG. COMPLETE WITH CLUTCH 1T ACE	TATA spare parts
286401100101	CYL CRANKCASE ASSY	TATA spare parts
286401130101	ASSY OIL SUMP COMPLETE	TATA spare parts
286401130103	ASSY. OIL SUMP COMPLETE (CORK GASKET)	TATA spare parts
286401130105	ASSY. OIL SUMP COMPLETE (LIQUID GASKET)	TATA spare parts
286401130107	ASSY. OIL SUMP COMPLETE	TATA spare parts
286401130120	ASSY OIL SUMP COMPLETE (LIQUID GASKET	TATA spare parts
286401130122	BRACKET	TATA spare parts
286401133801	LADDER FRAME	TATA spare parts
286401135301	GASKET (OIL SUMP TO LADDER FRAME)	TATA spare parts
286401135302	GASKET (OIL SUMP TO LADDER FRAME)	TATA spare parts
286401135801	RUBBER HOSE (ADAPTOR TO OIL SUMP)	TATA spare parts
286401136301	ADAPTOR(OIL CAP)	TATA spare parts
286401138213	BRACKET	TATA spare parts
286401140101	ASSY TIMING COVER REAR - TOP	TATA spare parts
286401140102	ASSY TIMING COVER REAR - RIGHT	TATA spare parts
286401147701	FRONT COVER	TATA spare parts
286401153801	CYLINDER HEAD COVER ALUMINIUM	TATA spare parts
286401155301	GASKET (FOR BAFFLE ON CYL. HEAD COVER)	TATA spare parts
286401155303	GASKET-BAFFLE ON CYL HEAD COVER	TATA spare parts
286401157701	DAMPER-CYL HEAD COVER	TATA spare parts
286401157702	DAMPER-CYL HEAD COVER	TATA spare parts
286401157703	DAMPER-CYL HEAD COVER	TATA spare parts
286401158201	BAFFLE (CYL HEAD COVER)	TATA spare parts
286401158202	DEFLECTOR	TATA spare parts
286401170101	ASSY. DIPSTICK	TATA spare parts
286401170103	ASSY. BRACKET (OIL SEPERATOR MTG.)	TATA spare parts
286401170104	ASSY TUBE (DIPSTICK)	TATA spare parts
286401170105	ASSY. BRACKET (OIL SEPERATOR MTG.)	TATA spare parts
286401170110	ASSY OIL SEP. RETURN LINE	TATA spare parts
286401170114	ASSY DIPSTICK TUBE	TATA spare parts
286401170115	ASSY. DIPSTICK (STEEL WIRE)	TATA spare parts
286401170117	ASSY.OIL SEP. RETURN LINE	TATA spare parts
286401170118	OIL RETURN ASSY WITH CRIMP HOSE OMS	TATA spare parts
286401174201	CLAMP (DIPSTICK TUBE)	TATA spare parts
286401174205	CLAMP	TATA spare parts
286401175803	RUBBER HOSE (OIL SEP TO INTAKE HOSE)	TATA spare parts
286401175804	RUBBER HOSE (CYL HEAD COVER TO OIL SEP)	TATA spare parts
286401175805	HOSE (OIL SEP. TO OIL SUMP)	TATA spare parts
286401175806	BLOW BY HOSE (CYL. HEAD COVER TO INLET)	TATA spare parts
286401175807	RUBBER HOSE (CYL HEAD COVER TO OIL SEP)	TATA spare parts
286401175808	RUBBER HOSE (OIL SEP TO INTAKE HOSE)	TATA spare parts
286401175809	HOSE (OIL SEP. TO OIL SUMP)	TATA spare parts
286401175812	BLOW BY HOSE(CYL. HEAD COVER TO OIL SEP)	TATA spare parts
286401179902	DIPSTICK TUBE ADAPTOR	TATA spare parts
286401990106	ENG OVERHAUL GASKET SUB KIT (TCIC)	TATA spare parts
286401990107	KIT-ENG OVERHAUL GASKET+SEAL BS1/3	TATA spare parts

286401990108	BARE ENGINE BS3	TATA spare parts
286401990109	HALF BLOCK (TCIC BS-III)	TATA spare parts
286401990112	ENGINE FOR PELICAN	TATA spare parts
286401990114	ENGINE FOR PELICAN	TATA spare parts
286401990117	BARE ENGINE	TATA spare parts
286401990120	HALF BLOCK (VENTURE NA)	TATA spare parts
286401990122	BARE ENG (TCIC)	TATA spare parts
286401990132	LONG BLOCK 475TCIC BS1/3	TATA spare parts
286403100101	ASSY CRANKSHAFT WITH PIN	TATA spare parts
286403100102	ASSY. CRANKSHAFT WITH PIN	TATA spare parts
286403100105	ASSY. CRANKSHAFT WITH CYL PIN	TATA spare parts
286403151602	CONNECTING ROD ASSY FACTURED WITH BUSH	TATA spare parts
286403990104	SET BUSH - CONNECTING ROD	TATA spare parts
286405111601	TIMING BELT BS1/3/4/6	TATA spare parts
286405116301	TIMING BELT	TATA spare parts
286407120101	ASSY BRACKET (FIP REAR)	TATA spare parts
286407120103	ASSY BRACKET FRONT	TATA spare parts
286407120104	ASSY BKT FIP(REAR)-BOOST SENSOR LINE MTG	TATA spare parts
286407123701	BRACKET (FOR FIP BRACKET MIDDLE)	TATA spare parts
286407140101	ASSY FUEL PR. LINE (CYL.NO.1)	TATA spare parts
286407140102	ASSY FUEL PR. LINE (CYL.NO.2)	TATA spare parts
286407140103	ASSY FUEL PR. LINE (CYL.NO.3)	TATA spare parts
286407140104	ASSY FUEL PR. LINE (CYL.NO.4)	TATA spare parts
286407140105	SET ASSY FUEL PR. LINE	TATA spare parts
286409110102	FUEL FILTER ASSY	TATA spare parts
286409130105	ASSY STRAP WITH RUBBER STRAP(AIR FILTER)	TATA spare parts
286409130106	ASSY. AIR FILTER W/SEALING PLG BS1/3/4/6	TATA spare parts
286409130107	ASSY AIR FILTER MTG. BKT.	TATA spare parts
286409130108	ASSY AIR FILTER COMPLETE	TATA spare parts
286409130109	ASSY. BRACKET FOR SNORKEL MOUNTING	TATA spare parts
286409130110	ASSY. BRACKET FOR SNORKEL MOUNTING	TATA spare parts
286409130111	ASSY.SERVICE INDICATOR	TATA spare parts
286409130112	ASSEMBLY PRECLEANER	TATA spare parts
286409130117	ASSEMBLY SNORKEL(WITH MESH)	TATA spare parts
286409130118	ASSY. AIR FILTER W/SEALING PLUG BS6	TATA spare parts
286409130122	ASSY AIR FILTER MTG. BKT.	TATA spare parts
286409130125	ASSEMBLY HOSE- AIR FILTER SERVICE INDICA	TATA spare parts
286409130126	ASSEMBLY ADAPTOR	TATA spare parts
286409130131	ASSY. AIR INTAKE PIPE (WITH CLAMP)	TATA spare parts
286409130133	ADAPTER ASSY	TATA spare parts
286409131602	ASSY. SNORKEL (WITH MESH)	TATA spare parts
286409134202	HOSE CLAMP (70 DIA)	TATA spare parts
286409134203	HOSE CLAMP (75 DIA.)	TATA spare parts
286409135814	RUBBER HOSE (AIR FILTER TO INT. PIPE)	TATA spare parts
286409135815	ASSY INTAKE HOSE (INT PIPE TO TC)	TATA spare parts
286409135818	RUBBER HOSE (AIR FILTER TO INT. PIPE)	TATA spare parts
286409135820	RUBBER HOSE (INTERMEDIATE PIPE TO TC)	TATA spare parts

286409135822	RUBBER HOSE	TATA spare parts
286409135824	AIR INTAKE HOSE (INTERMEDIATE PIPE TO IN	TATA spare parts
286409135825	RUBBER HOSE (PRE-CLEANER TO AIR FILTER)	TATA spare parts
286409135826	RUBBER HOSE (INLET DUCT TO PRE-CLEANER)	TATA spare parts
286409135829	RUBBER HOSE (INT PIPE - TC) (LHD)	TATA spare parts
286409135839	RUBBER HOSE(SNORKEL TO FILTER)	TATA spare parts
286409136304	AIR FILTER HOUSING	TATA spare parts
286409136305	AIR FILTER COVER	TATA spare parts
286409136902	ASSY. INTERMEDIATE PIPE + CLAMP (INTAKE)	TATA spare parts
286409136904	AIR INTAKE PIPE (WITH CLAMP & NIPPLE)	TATA spare parts
286409137101	BRACKET (AIR FILTER MTG)	TATA spare parts
286409139904	AIR FILTER ELEMENT BS1/3/4/6	TATA spare parts
286414100103	ASSY BOOST SENSOR LINE	TATA spare parts
286414100104	ASSY. INLET MANIFOLD FOR EGR (NA)	TATA spare parts
286414101601	GASKET (INLET ELBOW TO MANIFOLD)	TATA spare parts
286414101602	GASKET (EGR VALVE)	TATA spare parts
286414103802	INLET MANIFOLD	TATA spare parts
286414103803	AIR INLET ELBOW	TATA spare parts
286414105301	GASKET(IN.ELBOW TO MAN.)	TATA spare parts
286414105302	GASKET (EGR VALVE)	TATA spare parts
286414105305	GASKET	TATA spare parts
286414108202	CLOSING PLATE (AIR INLET ELBOW)(LHD)	TATA spare parts
286414110103	ASSY. EGR PIPE	TATA spare parts
286414110105	HEAT SHIELD EXHAUST MANIFOLD	TATA spare parts
286414110106	HEAT SHIELD EXHAUST MANIFOLD	TATA spare parts
286414110107	HEAT SHIELD - TURBOCHARGER ELBOW	TATA spare parts
286414110108	ASSY EGR TUBE	TATA spare parts
286414110109	BRACKET (EVRV MTG)	TATA spare parts
286414110123	ASSY. NYLON HOSE (EVRV TO VACCUM PUMP)	TATA spare parts
286414110125	ASSY. NYLON HOSE(EXOTECH)	TATA spare parts
286414110148	HOSE ASSY (EVRV TO AIR INTAKE PIPE)	TATA spare parts
286414111604	HEAT SHIELD (TURBOCHARGER ELBOW)	TATA spare parts
286414113201	HEX HEAD FLANGE BOLT M8 X 50	TATA spare parts
286414113202	H/FL BOLT M8X70 TS17130-10.9-SS8451S2-YH	TATA spare parts
286414113307	BRACKET (EVRV MTG)	TATA spare parts
286414113308	BRACKET (FOR EVRV ROUTING)	TATA spare parts
286414113701	EXHAUST MANIFOLD	TATA spare parts
286414113702	EXHAUST MANIFOLD	TATA spare parts
286414114201	ASSY. V BAND CLAMP	TATA spare parts
286414114202	BRACKET (FOR EVRV HOSE ROUTING)	TATA spare parts
286414115301	GASKET (ASSY.PIPE TO )	TATA spare parts
286414115302	GASKET (TC OIL RETURN )	TATA spare parts
286414115801	RUBBER HOSE (VAC. PUMP TO EVRV)	TATA spare parts
286414115803	RUBBER HOSE (EVRV TO EGR VALVE) (TCIC)	TATA spare parts
286414115804	RUBBER HOSE (EVRV TO AIR INTAKE PIPE)	TATA spare parts
286414115810	RUBBER HOSE (EVRV TO EGR VALVE) (TCIC)	TATA spare parts
286414115811	RUBBER HOSE (EVRV TO AIR INTAKE PIPE)	TATA spare parts

286414115812	RUBBER HOSE (VAC. PUMP TO EVRV)	TATA spare parts
286414115813	RUBBER HOSE (EVRV TO AIR INTAKE)	TATA spare parts
286414115814	RUBBER HOSE (EVRV TO EGR VALVE)	TATA spare parts
286414115822	RUBBER HOSE(EVRV TO CONNECTOR)	TATA spare parts
286414115824	RUBBER HOSE(CONNECTOR TO VAC.PUMP)	TATA spare parts
286414115827	RUBBER HOSE (EVRV TO CONNECTOR)	TATA spare parts
286414115829	RUBBER HOSE (CONNECTOR TO AIR INTAKE VEN	TATA spare parts
286414116503	FLANGED LOCK NUT	TATA spare parts
286414118201	BRACKET (FOR EX. ELBOW SUPPORT)	TATA spare parts
286414118801	STUD BM8X25	TATA spare parts
286414118802	STUD CM8X32	TATA spare parts
286414119902	ASSY. EGR VALVE	TATA spare parts
286414510101	ASSY. TURBOCHARGER BS1/3	TATA spare parts
286414510102	ASSY OIL FEEDER LINE	TATA spare parts
286414510103	OIL FEEDER LINE	TATA spare parts
286414511601	ASSY. NOISE SHIELD	TATA spare parts
286414515301	GASKET TURBOCHARGER INTAKE	TATA spare parts
286414600101	ASSY. BRACKET	TATA spare parts
286414600102	INTERCOOLER DUCT	TATA spare parts
286414600105	ASSY. INTERMEDIATE PIPE WITH CLAMP (IC T	TATA spare parts
286414600106	ASSY. INTERMEDIATE PIPE WITH CLAMP (TC T	TATA spare parts
286414600109	INT PIPE ASSY WITH CLAMP TC TO IC	TATA spare parts
286414600110	ASSY INTERMEDIATE PIPE WITH CLAMP (IC TO	TATA spare parts
286414600115	DUCT ASSY INTERCOOLER	TATA spare parts
286414604201	ASSY. CLAMP	TATA spare parts
286414604202	CLAMP (FOR PIPE IC TO INLET ELBOW)	TATA spare parts
286414604203	CLAMP (FOR TC HOSE TO PIPE)	TATA spare parts
286414605802	RUBBER HOSE (PIPE TO INLET ELBOW)	TATA spare parts
286414605803	RUBBER HOSE (PIPE TO IC)	TATA spare parts
286414605804	RUBBER HOSE (IC TO PIPE)	TATA spare parts
286414605805	RUBBER HOSE (TC TO PIPE)	TATA spare parts
286414605806	RUBBER HOSE (FOR 65 CORE INTERCOOLER)	TATA spare parts
286414605807	RUBBER HOSE (FOR 65 CORE INTERCOOLER)	TATA spare parts
286414605808	RUBBER HOSE (PIPE TO IN ELBOW)	TATA spare parts
286414605811	RUBBER HOSE (I/C TO PIPE)	TATA spare parts
286414605812	RUBBER HOSE (PIPE TO INTERCOOLER)(LHD)	TATA spare parts
286414605813	RUBBER HOSE (IC TO PIPE)(LHD)	TATA spare parts
286414605816	RUBBER HOSE (TC TO PIPE)(LHD)	TATA spare parts
286414605817	RUBBER HOSE PIPE TO INTAKE ELBOW	TATA spare parts
286414606302	GROMMET (INT.DUCT MTG.)	TATA spare parts
286414606901	PIPE (TC TO IC)	TATA spare parts
286414606902	PIPE (IC TO INLET MANIFOLD)	TATA spare parts
286414607701	DUCT SEAL (DUCT TO INTERCOOLER)	TATA spare parts
286414609901	ASSY INTERCOOLER	TATA spare parts
286414609904	ASSY. INTERCOOLER (65 CORE) BS1/3/4	TATA spare parts
286414990105	DECARBONISING GASKET KIT	TATA spare parts
286415135801	RUBBER HOSE (VACUUM PUMP TO OIL SUMP)	TATA spare parts

286415143701	BRACKET (ALTERNATOR POWER STEERING)	TATA spare parts
286415143702	BRACKET (ALT. MTG.)	TATA spare parts
286415144201	CLAMPING PIECE	TATA spare parts
286415146302	POLY VEE BELT-5PK (760)	TATA spare parts
286415200101	ECU HARDWARE SCN 2.3	TATA spare parts
286415200109	ECU SOFTWARE (MICROBUS 475 IDI NA BS-III	TATA spare parts
286415200110	ECU WITH SOFTWARE	TATA spare parts
286415200115	ECU WITH SOFTWARE	TATA spare parts
286415200116	ECU WITH SOFTWARE	TATA spare parts
286415200117	ECU WITH SOFTWARE	TATA spare parts
286415200121	ECU WITH SOFTWARE BS3	TATA spare parts
286415200122	ECU WITH SOFTWARE	TATA spare parts
286415200127	ECU WITH SOFTWARE	TATA spare parts
286415200134	ECU WITH SOFTWARE	TATA spare parts
286418150101	ASSY STRAINER (FOR OIL PUMP)	TATA spare parts
286418150102	ASSY. STRAINER (FOR OIL PUMP)	TATA spare parts
286418150103	ASSY. STRAINER (FOR OIL PUMP)	TATA spare parts
286418150104	ASSY. STRAINER (FOR OIL PUMP)(TCIC)	TATA spare parts
286418170101	ASSY OIL RETURN LINE	TATA spare parts
286420120101	ASSY ELBOW FOR WATER INTAKE AND BYPASS	TATA spare parts
286420120102	ASSY ELBOW (FOR WATER HEATER)	TATA spare parts
286420120103	ASSY. VENT TUBE (ON ENGINE)	TATA spare parts
286420120104	ASSEMBLY VENT TUBE	TATA spare parts
286420120105	ASSY. ELBOW (FOR NON-HVAC)	TATA spare parts
286420120106	ASSY. HEATER ELBOW (FOR HVAC)	TATA spare parts
286420120107	ASSY. ELBOW	TATA spare parts
286420120108	ASSY.VENT TUBE(ON ENGINE)	TATA spare parts
286420120109	ASSEMBLY VENT TUBE (UNDER FLOOR)(LHD)	TATA spare parts
286420120111	TUBE ASSY VENT ENGINE(LHD)	TATA spare parts
286420120112	ASSY ELBOW FOR WATER INTAKE AND BYPASS	TATA spare parts
286420123801	THERMOSTAT COVER	TATA spare parts
286420125802	RUBBER HOSE	TATA spare parts
286420125803	VENT HOSE	TATA spare parts
286420125804	VENT HOSE	TATA spare parts
286420125805	RUBBER HOSE	TATA spare parts
286420125806	RUBBER HOSE (VENT TUBE ON ENG. TO VENT T	TATA spare parts
286420125820	HOSE (VENT TUBE ON FLOOR TO RADIATOR)	TATA spare parts
286422123702	BRACKET	TATA spare parts
286422123703	ENGINE MTG. ARM (FRONT)	TATA spare parts
286423120101	ASSY A/C COMP. MTG. BKT.	TATA spare parts
286423121601	POLY V BELT 755	TATA spare parts
286423123701	COMPRESSOR MOUNTING BRACKET	TATA spare parts
286423126303	POLY V BELT 755	TATA spare parts
286424100101	ASSY. ENGINE MOUNT (FRONT)	TATA spare parts
286424200101	ASSY. ENGINE MOUNT (REAR) BS1/3/4	TATA spare parts
286424207101	SPACER PLATE REAR LH	TATA spare parts
286449100101	ASSY CATALYTIC CONVERTER	TATA spare parts

286449100103	ASSY CAT CONVERTER	TATA spare parts
286449100104	ASSY CATALYTIC CONVERTER BS-III	TATA spare parts
286449100106	ASSY CAT CONVERTER	TATA spare parts
286449101602	CATALYTIC CONVERTER -BS III MICROBUS	TATA spare parts
286450100102	ASSY PIPE WITH CLAMP (RADIATOR INLET)	TATA spare parts
286450100103	ASSY PIPE WITH CLAMP (RADIATOR OUTLET)	TATA spare parts
286450100104	ASSY RAD. WITH FAN SHROUD & MOTOR	TATA spare parts
286450100105	ASSY. RADIATOR ACE/VENTURE BS3	TATA spare parts
286450100105DF	RADIATOR ASSY - SUPER ACE BS3	TATA spare parts
286450100107	ASSY UPPER COOLING LINE WITH CLAMP	TATA spare parts
286450100108	NO LOSS TANK	TATA spare parts
286450100109	ASSY. PIPE WITH TUBE (FOR HVAC)	TATA spare parts
286450100111	ASSEMBLY SEALING (NON-A/C APPLICATION)	TATA spare parts
286450100112	ASSY. OVER FLOW LINE (WITH SLEEVE)	TATA spare parts
286450100113	ASSY. UPPER COOLING LINE WITH CLAMP	TATA spare parts
286450100114	ASSEMBLY RADIATOR SEALING	TATA spare parts
286450100115	PIPE ASSY UNDER BODY UCL(LHD)	TATA spare parts
286450100116	PIPE ASSY UNDER BODY LCL(LHD)	TATA spare parts
286450100117	ASSY COOLING GUIDES (LHD)	TATA spare parts
286450100119	ASSY. AUXILLARY TANK BS1/3/4	TATA spare parts
286450100120	ASSEMBLY HOSE FOR AUX TANK	TATA spare parts
286450100121	ASSEMBLY HOSE (AUX TANK TO CYL.HEAD)	TATA spare parts
286450100122	ASSY.VENT TUBE(AUXTANK TO ENG.VENT TUBE)	TATA spare parts
286450100123	ASSY.RAD+FAN MOTOR+SHROUD(TATA TOYO)	TATA spare parts
286450100124	ASSY. RADIATOR 475IDI BS1/3	TATA spare parts
286450100125	INTERMEDIATE PIPE (UPPER COOLING LINE)	TATA spare parts
286450100126	HOSE ASSY (AUX TANK TO CYL. HEAD) (LHD)	TATA spare parts
286450100127	HOSE ASSY (AUX TANK TO VENT TUBE) (LHD)	TATA spare parts
286450100128	HOSE ASSY. (AUX TANK TO ELBOW) (LHD)	TATA spare parts
286450100129	ASSY. TUBE AND CLAMP (ASSY. VENT HOSE -	TATA spare parts
286450100133	ASSEMBLY SEALING (A/C APPLICATION)	TATA spare parts
286450100136	COOLING GUIDE ASSY	TATA spare parts
286450100143	ASSY. PIPE UCL WITH CLAMP	TATA spare parts
286450100144	ASSY. INTERMEDIATE PIPE(RADIATOR INLET)	TATA spare parts
286450100145	ASSY. PIPE LCL(NON HD)	TATA spare parts
286450100147	ASSY. PIPE WITH TUBE(FOR HVAC)	TATA spare parts
286450100153	ASSY RAD. WITH FAN MOTOR SHROUD (TOYO)	TATA spare parts
286450100154	ASSY RADIATOR SEALING(A/C APPLICATION)	TATA spare parts
286450100155	ASSY DEFLECTOR	TATA spare parts
286450100160	ASSY. DEFLECTOR	TATA spare parts
286450100161	ASSY. RADIATOR W/FAN SHROUD BS1/3/4	TATA spare parts
286450100162	ASSY. DEFLECTOR (SUPERACE)	TATA spare parts
286450100166	RADIATOR WITH FAN MOTOR SHROUD ASSY	TATA spare parts
286450100179	RADIATOR & FAN SHROUD ASSY	TATA spare parts
286450100194	SHROUD ASSY WITH FLAP	TATA spare parts
286450101606	RADIATOR SEALING BOTTOM	TATA spare parts
286450101607	RADIATOR SEALING TOP	TATA spare parts



286450101609	RADIATOR SEALING LH (NON-A/C APPLICATION	TATA spare parts
286450101610	RADIATOR SEALING RH (NON-A/C APPLICATION	TATA spare parts
286450101611	RADIATOR SEALING LH (A/C APPLICATION)	TATA spare parts
286450101612	RADIATOR SEALING RH (A/C APPLICATION)	TATA spare parts
286450101613	RADIATOR SEALING BOTTOM (A/C APPLICATION	TATA spare parts
286450101614	RADIATOR SEALING BOTTOM (A/C APPLICATION	TATA spare parts
286450103301	BRACKET - TOP (AUX TANK MTG)	TATA spare parts
286450103302	ASSEMBLY BRACKET (AUX TANK MTG)	TATA spare parts
286450104202	HOSE CLAMP (FOR RADIATOR HOSE-UCL)	TATA spare parts
286450104205	CLAMP	TATA spare parts
286450104210	HOSE CLIP ROTATABLE	TATA spare parts
286450105801	HOSE-LCL (300)(RAD.TO WATER INLET ELBOW)	TATA spare parts
286450105803	BRACKET HOLDING SLEEVE	TATA spare parts
286450105805	HOSE-UCL(RADIATOR INLET TO ASSY.PIPE)	TATA spare parts
286450105807	HOSE-LCL (RAD. OUTLET TO ASSY.PIPE)	TATA spare parts
286450105808	RUBBER HOSE (UCL)	TATA spare parts
286450105809	RUBBER HOSE	TATA spare parts
286450105811	RUBBER HOSE	TATA spare parts
286450105812	HOSE-UCL(RAD. INLET TO ASSY. PIPE)(LHD)	TATA spare parts
286450105813	HOSE-LCL (RAD. OUTLET TO ASSY. PIPE)(LHD	TATA spare parts
286450105814	RUBBER HOSE (UPPER COOLING LINE)	TATA spare parts
286450105815	RUBBER HOSE (THERMOSTAT TO PIPE - UCL)(L	TATA spare parts
286450105816	RUBBER HOSE (HOSE A/TANK TO W/INLET ELB)	TATA spare parts
286450105817	RUBBER HOSE (ASSY. HOSE - AUX. TANK TO C	TATA spare parts
286450105818	RUBBER HOSE (ASSY. VENT HOSE - AUX. TANK	TATA spare parts
286450105820	RUBBER HOSE (HOSE - AU/TANK. TO CYL.HD)	TATA spare parts
286450105823	RUBBER HOSE (HOSE A/TANK TO W/INLET ELB)	TATA spare parts
286450105824	LCL HOSE	TATA spare parts
286450105835	RUBBER HOSE(ASSY PIPE TO INTERMEDIATE HO	TATA spare parts
286450105836	RUBBER HOSE(ASSY PIPE TO RADIATORO	TATA spare parts
286450105837	RUBBER HOSE(ASSY PIPE TO WATER INLET ELB	TATA spare parts
286450105841	HOSE( ASSY PIPE TO WATER INLET ELBOW)	TATA spare parts
286450106302	RUBBER SUPPORT (AUX TANK)	TATA spare parts
286450106307	RADIATOR SEALING LH (A/C APPLICATION)	TATA spare parts
286450106308	RADIATOR SEALING RH (A/C APPLICATION)	TATA spare parts
286450106310	RADIATOR SEALING LH(A/C APPLICATION)	TATA spare parts
286450106311	RADIATOR SEALING RH(A/C APPLICATION)	TATA spare parts
286450106904	TUBE (HOSE - AUX TANK TO CYL. HEAD)	TATA spare parts
286450106905	TUBE (HOSE - AUX TANK TO WINLET ELB)	TATA spare parts
286450107501	RUBBER GROMMET(RADIATOR BOTTOM)	TATA spare parts
286450108201	SUPPORT BRACKET (AUX TANK)	TATA spare parts
286450108202	AUX. COVER MTG. BRACKET	TATA spare parts
286450108203	AUX TANK PROTECTIVE COVER	TATA spare parts
286450109902	RESISTOR BS1/3/4	TATA spare parts
286450109903	FAN MOTOR ASSEMBLY	TATA spare parts
286450109905	RADIATOR ASSY	TATA spare parts
286450109906	SHROUD ASSY WITH FAN & MOTOR	TATA spare parts

286450109907	ASSY. RADIATOR SUPER ACE BS1/3/4	TATA spare parts
286450109907DF	RADIATOR ASSY W/O NECK-SUPER ACE MINT BS	TATA spare parts
286450109909	RADIATOR ASSY RESISTOR	TATA spare parts
286450109910	RADIATOR ASSY	TATA spare parts
286450109911	ASSY. FAN MOTOR SHROUD BS4	TATA spare parts
286450109912	FAN MOTOR ASSY	TATA spare parts
286450109913	RESISTOR	TATA spare parts
286450109914	ASSY. SHROUD W/FAN & MOTOR EURO2	TATA spare parts
286450500101	ASSY. FAN SHROUD BS1/3	TATA spare parts
286450500102	FANSHROUDASSY	TATA spare parts
286526000104	ASSY GEAR BOX	TATA spare parts
286526000109	GEAR BOX ASSY LPT2523 RHD	TATA spare parts
286526000110	ASSY GEAR BOX /9.48 ADDON	TATA spare parts
286526000111	GEARBOX FOR LPO1628 VEHICLE	TATA spare parts
286526000115	ASSY GEAR BOX 12.73 WITH NH/4C P	TATA spare parts
286526000117	ASSY GEARBOX	TATA spare parts
286526000119	GEAR BOX WITH INTEGRATED SERVO	TATA spare parts
286526000121	ASSY GEAR BOX	TATA spare parts
286526000121AE	ASSY GEAR BOX 2523	TATA spare parts
286526000122	GEAR BOX LPK3328	TATA spare parts
286526000123	GEAR BOX WITH INT. SERVO	TATA spare parts
286526000124	ASSY. GEAR BOX ZF9S1110TD INTEGRA BS3	TATA spare parts
286526000133	ASSY. GEAR BOX ZF9S1110TO PRIMA EURO3	TATA spare parts
286526000137	GEAR BOX LPK2528 RHD	TATA spare parts
286526000147	GEAR BOX ASSY	TATA spare parts
286526000148	GEAR BOX ASSY WITH PTO	TATA spare parts
286526000151	ASSY. GEAR BOX W/O SPEEDO SENSOR BS4	TATA spare parts
286526000154	GEAR BOX W/O SPEEDO SENSOR	TATA spare parts
286526000156	GEAR BOX ASSY WITH PTO	TATA spare parts
286526000157	GEAR BOX ASSY	TATA spare parts
286526000160	GEAR BOX ASSY WITH SPEEDO SENSOR	TATA spare parts
286526000162	GEAR BOX ASSY	TATA spare parts
286526008002	SCREW	TATA spare parts
286526109806	SEALING RING	TATA spare parts
286526109846	KIT-GASKET GEAR BOX	TATA spare parts
286526109847	CYLINDER	TATA spare parts
286526109848	CYLINDER	TATA spare parts
286526109901	CLUTCH BELL HOUSING	TATA spare parts
286526109902	HEXAGON SCREW	TATA spare parts
286526109903	WASHER	TATA spare parts
286526109904	HEXAGON SCREW	TATA spare parts
286526109905	WASHER	TATA spare parts
286526109906	SCREW PLUG	TATA spare parts
286526109907	WASHER	TATA spare parts
286526109908	HEXAGON SCREW	TATA spare parts
286526109909	WASHER	TATA spare parts
286526109910	COVER	TATA spare parts

286526109911	HEXAGON SCREW	TATA spare parts
286526109914	INTERM.PLATE	TATA spare parts
286526109915	HEXAGON SCREW	TATA spare parts
286526109916	SEALING RING	TATA spare parts
286526109917	HOUSING III	TATA spare parts
286526109918	SCREW PLUG	TATA spare parts
286526109919	SCREW PLUG	TATA spare parts
286526109920	HOUSING	TATA spare parts
286526109921	SCREW PLUG	TATA spare parts
286526109922	GASKET	TATA spare parts
286526109923	TYPE PLATE	TATA spare parts
286526109924	HEXAGON SCREW	TATA spare parts
286526109925	CYLINDRICAL PIN	TATA spare parts
286526109926	TYPE PLATE	TATA spare parts
286526109927	BLIND RIVET	TATA spare parts
286526109928	BREATHER	TATA spare parts
286526109929	COVER	TATA spare parts
286526109930	GASKET	TATA spare parts
286526109931	HEXAGON SCREW	TATA spare parts
286526109932	CONN.PLATE	TATA spare parts
286526109933	SHAFT SEAL	TATA spare parts
286526109934	GASKET	TATA spare parts
286526109935	HEXAGON SCREW	TATA spare parts
286526109936	SEALING CAP	TATA spare parts
286526109937	CIRCLIP	TATA spare parts
286526109938	PUMP	TATA spare parts
286526109939	GASKET	TATA spare parts
286526109940	HEXAGON SCREW	TATA spare parts
286526109941	LOCK WASHER	TATA spare parts
286526109942	SEALING RING	TATA spare parts
286526109943	SEALING RING	TATA spare parts
286526109944	SEALING RING	TATA spare parts
286526109945	SEALING RING	TATA spare parts
286526109946	TYPE PLATE	TATA spare parts
286526109948	CIRCLIP	TATA spare parts
286526109950	GASKET	TATA spare parts
286526109951	HEXAGON SCREW	TATA spare parts
286526109952	WASHER	TATA spare parts
286526109953	HEXAGON SCREW	TATA spare parts
286526109955	GEAR SHIFT COVER	TATA spare parts
286526109956	COVER	TATA spare parts
286526109957	GASKET	TATA spare parts
286526109958	HEXAGON SCREW	TATA spare parts
286526109959	WASHER	TATA spare parts
286526109960	GASKET	TATA spare parts
286526109961	HEXAGON SCREW	TATA spare parts
286526109962	HOUSING	TATA spare parts

286526109963	GASKET	TATA spare parts
286526109964	HEXAGON SCREW	TATA spare parts
286526109965	HEXAGON SCREW	TATA spare parts
286526109966	HEXAGON SCREW	TATA spare parts
286526109967	CYLINDRICAL PIN	TATA spare parts
286526109968	COVER	TATA spare parts
286526109970	HEXAGON SCREW	TATA spare parts
286526109971	CYLINDER	TATA spare parts
286526109973	BOLT	TATA spare parts
286526109974	PULSE SENSOR	TATA spare parts
286526109975	O-RING	TATA spare parts
286526109977	HEXAGON SCREW	TATA spare parts
286526109978	SPEEDOMETER COVER	TATA spare parts
286526109979	HOUSING	TATA spare parts
286526109980	SCREW PLUG	TATA spare parts
286526109982	BALL	TATA spare parts
286526109983	SWITCH	TATA spare parts
286526109984	UNION SCREW	TATA spare parts
286526209801	SLIDING SLEEVE	TATA spare parts
286526209802	PRESSURE PART	TATA spare parts
286526209803	COMPRESSION SPRING	TATA spare parts
286526209804	COMPRESSION SPRING	TATA spare parts
286526209805	CLUTCH BODY	TATA spare parts
286526209806	CLUTCH BODY(1324.233.006) BS6	TATA spare parts
286526209807	SYNCHRO BODY	TATA spare parts
286526209809	SUN GEAR	TATA spare parts
286526209812	SYNCHRO SET	TATA spare parts
286526209813	RING GEAR	TATA spare parts
286526209901	PLANETENRADSATZ (PLANET WHEEL SENTENCE)	TATA spare parts
286526209902	NEEDLE CAGE	TATA spare parts
286526209903	HELICAL GEAR	TATA spare parts
286526209905	SLIDING SLEEVE	TATA spare parts
286526209906	CIRCLIP	TATA spare parts
286526209907	CIRCLIP	TATA spare parts
286526209908	CIRCLIP	TATA spare parts
286526209909	CIRCLIP	TATA spare parts
286526209910	CIRCLIP	TATA spare parts
286526209911	NEEDLE CAGE	TATA spare parts
286526209912	HELICAL GEAR	TATA spare parts
286526209913	TA.ROLL.BEARING	TATA spare parts
286526209915	CIRCLIP	TATA spare parts
286526209916	CIRCLIP	TATA spare parts
286526209917	CIRCLIP	TATA spare parts
286526209918	CIRCLIP	TATA spare parts
286526209919	RETAINING RING	TATA spare parts
286526209920	CIRCLIP	TATA spare parts
286526209921	CIRCLIP	TATA spare parts

286526209922	CIRCLIP	TATA spare parts
286526209923	CIRCLIP	TATA spare parts
286526209924	CIRCLIP	TATA spare parts
286526209925	CIRCLIP	TATA spare parts
286526209926	CIRCLIP	TATA spare parts
286526209927	CIRCLIP	TATA spare parts
286526209928	CIRCLIP	TATA spare parts
286526209929	CIRCLIP	TATA spare parts
286526209930	CIRCLIP	TATA spare parts
286526209931	CIRCLIP	TATA spare parts
286526209932	CIRCLIP	TATA spare parts
286526209933	CIRCLIP	TATA spare parts
286526209934	CIRCLIP	TATA spare parts
286526209935	CIRCLIP	TATA spare parts
286526209936	CIRCLIP	TATA spare parts
286526209937	CIRCLIP	TATA spare parts
286526209938	TUBE	TATA spare parts
286526209939	NEEDLE CAGE	TATA spare parts
286526209940	HELICAL GEAR	TATA spare parts
286526209941	CLUTCH BODY(1324.304.013) BS3/4	TATA spare parts
286526209942	SYNCHRO.BODY	TATA spare parts
286526209943	SLIDING SLEEVE	TATA spare parts
286526209944	SYNCHRO.RING	TATA spare parts
286526209945	PRESSURE PART	TATA spare parts
286526209946	COMPRESSION SPRING	TATA spare parts
286526209947	CLUTCH BODY	TATA spare parts
286526209948	BUSH	TATA spare parts
286526209949	CIRCLIP	TATA spare parts
286526209950	CIRCLIP	TATA spare parts
286526209951	CIRCLIP	TATA spare parts
286526209952	CIRCLIP	TATA spare parts
286526209953	CIRCLIP	TATA spare parts
286526209954	CIRCLIP	TATA spare parts
286526209955	NEEDLE CAGE	TATA spare parts
286526209956	HELICAL GEAR	TATA spare parts
286526209957	NEEDLE CAGE	TATA spare parts
286526209958	HELICAL GEAR	TATA spare parts
286526209959	CLUTCH BODY BS3/4	TATA spare parts
286526209962	SLIDING SLEEVE	TATA spare parts
286526209963	SYNCHRO.RING	TATA spare parts
286526209964	CLUTCH BODY	TATA spare parts
286526209965	TA.ROLL.BEARING	TATA spare parts
286526209967	CIRCLIP	TATA spare parts
286526209968	CIRCLIP	TATA spare parts
286526209969	CIRCLIP	TATA spare parts
286526209970	CIRCLIP	TATA spare parts
286526209971	CIRCLIP	TATA spare parts

286526209972	BALL BEARING	TATA spare parts
286526209973	PLANET CARRIER	TATA spare parts
286526209974	PLANETENRADSATZ (PLANET WHEEL SENTENCE)	TATA spare parts
286526209975	INTERMEDIATE WASHER	TATA spare parts
286526209976	WASHER	TATA spare parts
286526209977	COMPRESSION SPRING	TATA spare parts
286526209978	NEEDLE ROLLER	TATA spare parts
286526209979	SLOT.PIN	TATA spare parts
286526209980	SLOT.PIN	TATA spare parts
286526209981	RING GEAR CARR.	TATA spare parts
286526209982	BALL BEARING	TATA spare parts
286526209983	SNAP RING	TATA spare parts
286526209984	SNAP RING	TATA spare parts
286526209985	SNAP RING	TATA spare parts
286526209986	SNAP RING	TATA spare parts
286526209987	SNAP RING	TATA spare parts
286526209988	SNAP RING	TATA spare parts
286526209989	SNAP RING	TATA spare parts
286526209990	LOCKING WIRE	TATA spare parts
286526209991	OUTPUT FLANGE	TATA spare parts
286526209992	O-RING	TATA spare parts
286526209993	WASHER	TATA spare parts
286526209994	HEXAGON SCREW	TATA spare parts
286526209995	CIRCLIP	TATA spare parts
286526209996	CIRCLIP	TATA spare parts
286526209997	CIRCLIP	TATA spare parts
286526209998	CIRCLIP	TATA spare parts
286526209999	SYNCHRO.RING	TATA spare parts
286526259807	CLUTCH HOUSING	TATA spare parts
286526259901	INPUT SHAFT	TATA spare parts
286526259902	TA.ROLL.BEARING	TATA spare parts
286526259903	SHIM	TATA spare parts
286526259904	SHIM	TATA spare parts
286526259905	SHIM	TATA spare parts
286526259906	SHIM	TATA spare parts
286526259907	SHIM	TATA spare parts
286526259908	SHIM	TATA spare parts
286526259909	SHIM	TATA spare parts
286526259910	SHIM	TATA spare parts
286526259912	SHIM	TATA spare parts
286526259913	SHIM	TATA spare parts
286526259914	SHIM	TATA spare parts
286526259915	SHIM	TATA spare parts
286526259916	SHIM	TATA spare parts
286526259917	SHIM	TATA spare parts
286526259918	SHIM	TATA spare parts
286526259919	SHIM	TATA spare parts

286526259920	SHIM	TATA spare parts
286526259921	SHIM	TATA spare parts
286526259922	SHIM	TATA spare parts
286526259923	SHIM	TATA spare parts
286526259924	SHIM	TATA spare parts
286526259926	INPUT SHAFT BS3/4	TATA spare parts
286526259927	COVER	TATA spare parts
286526259962	CLUTCH BODY BS6	TATA spare parts
286526259996	TAPERED ROLLER BEARINGç 1	TATA spare parts
286526309901	LAYSHAFT	TATA spare parts
286526309902	TA.ROLL.BEARING	TATA spare parts
286526309904	HELICAL GEAR	TATA spare parts
286526309905	HELICAL GEAR	TATA spare parts
286526309906	CIRCLIP	TATA spare parts
286526309907	CIRCLIP	TATA spare parts
286526309908	CIRCLIP	TATA spare parts
286526309909	CIRCLIP	TATA spare parts
286526309910	CIRCLIP	TATA spare parts
286526309911	CIRCLIP	TATA spare parts
286526309912	TA.ROLL.BEARING	TATA spare parts
286526309913	SHIM	TATA spare parts
286526309914	SHIM	TATA spare parts
286526309915	SHIM	TATA spare parts
286526309916	SHIM	TATA spare parts
286526309917	SHIM	TATA spare parts
286526309918	SHIM	TATA spare parts
286526309919	SHIM	TATA spare parts
286526309920	SHIM	TATA spare parts
286526309921	SHIM	TATA spare parts
286526309922	SHIM	TATA spare parts
286526309923	SHIM	TATA spare parts
286526309924	SHIM	TATA spare parts
286526309925	SHIM	TATA spare parts
286526309926	SHIM	TATA spare parts
286526309927	SHIM	TATA spare parts
286526309928	SHIM	TATA spare parts
286526309929	SHIM	TATA spare parts
286526309930	SHIM	TATA spare parts
286526309931	SHIM	TATA spare parts
286526309932	DOUBLE GEAR	TATA spare parts
286526309933	HELICAL GEAR	TATA spare parts
286526309934	HELICAL GEAR	TATA spare parts
286526309937	DOUBLE GEAR	TATA spare parts
286526359901	REV.IDLER GEAR	TATA spare parts
286526359902	STUD	TATA spare parts
286526359903	ROLLER CAGE	TATA spare parts
286526359904	CIRCLIP	TATA spare parts

286526519900	GEAR SHIFT RAIL	TATA spare parts
286526519901	BEARING PLATE	TATA spare parts
286526519902	GEAR SHIFT RAIL	TATA spare parts
286526519903	GEAR SHIFT FORK	TATA spare parts
286526519905	SLIDING PAD	TATA spare parts
286526519906	ARTICULAT.BOLT	TATA spare parts
286526519907	LOCK WASHER	TATA spare parts
286526519908	GEAR SHIFT RAIL	TATA spare parts
286526519909	GEAR SHIFT FORK	TATA spare parts
286526519910	SLIDING PAD	TATA spare parts
286526519911	GEAR SHIFT RAIL	TATA spare parts
286526519912	GEAR SHIFT FORK	TATA spare parts
286526519913	SLIDING PAD	TATA spare parts
286526519914	LOCKING LEVER	TATA spare parts
286526519915	BEARING PLATE	TATA spare parts
286526519917	COMPRESSION SPRING	TATA spare parts
286526519918	SCREW PLUG	TATA spare parts
286526519919	SEALING RING	TATA spare parts
286526519920	SWITCH	TATA spare parts
286526519921	SEALING RING	TATA spare parts
286526519922	BALL	TATA spare parts
286526519923	STUD	TATA spare parts
286526519924	GASKET	TATA spare parts
286526519925	PLATE	TATA spare parts
286526519926	HEXAGON SCREW	TATA spare parts
286526519927	LOCK WASHER	TATA spare parts
286526519928	SWITCH	TATA spare parts
286526519929	GEAR SHIFT RAIL	TATA spare parts
286526519930	HUTMANSCHETTE (HAT CUFF)	TATA spare parts
286526519931	PISTON	TATA spare parts
286526519932	SEALING RING	TATA spare parts
286526519933	GUIDE RING	TATA spare parts
286526519934	LOCKING NUT	TATA spare parts
286526519935	O-RING	TATA spare parts
286526519936	GEAR SHIFT FORK	TATA spare parts
286526519937	ARTICULAT.BOLT	TATA spare parts
286526519938	LOCK WASHER	TATA spare parts
286526519939	SLIDING PAD	TATA spare parts
286526519940	SEALING RING	TATA spare parts
286526709901	RELEASE FORK	TATA spare parts
286526709902	SUPPORT BRACKET	TATA spare parts
286526709903	STUD	TATA spare parts
286526709904	JOINT BEARING	TATA spare parts
286526709905	CIRCLIP	TATA spare parts
286526709906	SEALING RING	TATA spare parts
286526709907	SEALING WASHER	TATA spare parts
286526709908	CIRCLIP	TATA spare parts



286526709909	G.SHIFT SHAFT	TATA spare parts
286526709910	DRIVER	TATA spare parts
286526709911	DRIVER	TATA spare parts
286526709912	RING	TATA spare parts
286526709913	DRIVER	TATA spare parts
286526709914	RASTENTEIL (REST PART)	TATA spare parts
286526709915	PIN	TATA spare parts
286526709916	SNAP RING	TATA spare parts
286526709917	CYLINDRICAL PIN	TATA spare parts
286526709919	COMPRESSION SPRING	TATA spare parts
286526709920	WASHER	TATA spare parts
286526709921	COMPRESSION SPRING	TATA spare parts
286526709922	V-RING	TATA spare parts
286526709923	COMPRESSION SPRING	TATA spare parts
286526709924	JOINT BEARING	TATA spare parts
286526719901	BOLT	TATA spare parts
286526719902	SCREW PLUG	TATA spare parts
286526719903	SEALING RING	TATA spare parts
286526719904	PROTECTION CAP	TATA spare parts
286526719905	CUT-OFF VALVE	TATA spare parts
286526719906	BALL ROLLER	TATA spare parts
286526719907	HEXAGON SCREW	TATA spare parts
286526719908	O-RING	TATA spare parts
286526719909	O-RING	TATA spare parts
286526719910	HEXAGON SCREW	TATA spare parts
286526719911	ARRETIERBOLZEN (ARREST BOLT)	TATA spare parts
286526719912	COVER	TATA spare parts
286526719913	BEARING BUSH	TATA spare parts
286526719914	BEARING BUSH	TATA spare parts
286526719915	SHAFT SEAL	TATA spare parts
286526719916	SCRAPER	TATA spare parts
286526719917	SEALING CAP	TATA spare parts
286526719918	TUBE	TATA spare parts
286526719919	RING PIECE	TATA spare parts
286526719920	TUBE	TATA spare parts
286526719921	SEALING RING	TATA spare parts
286526719922	CABLE CLIP	TATA spare parts
286526719923	DETENT PLUNGER	TATA spare parts
286526719930	HEXAGON SCREW BS6	TATA spare parts
286526719980	TUBE	TATA spare parts
286526719981	TUBE FOR OIL COOLER	TATA spare parts
286526800103	ASSY TURNING TUBE	TATA spare parts
286526800106	ASSY BRACKET(LINK ROD MTG)	TATA spare parts
286526800112	ASSY TURNING TUBE (W/O BALL JOINT)	TATA spare parts
286526800114	ASSY LINK ROD (LHD GEARBOX) BS6	TATA spare parts
286526800115	ASSY BRACKET(LINK ROD MTG)	TATA spare parts
286526803302	BRACKET CABLE MTG	TATA spare parts

286526806001	SHIFTING LEVER	TATA spare parts
286526807113	LINK ROD BS6	TATA spare parts
286526909901	TUBE	TATA spare parts
286526909902	SCREEN INSERT	TATA spare parts
286526990103	ASSY REPAIR KIT-ZF GEARBOX	TATA spare parts
286526990104	KIT-GEAR BOX	TATA spare parts
286526993001	BALL	TATA spare parts
286526993002	NEEDLE CAGE	TATA spare parts
286526993003	NEEDLE CAGE	TATA spare parts
286526993004	NEEDLE CAGE	TATA spare parts
286526993005	NEEDLE BEARING	TATA spare parts
286526993006	NEEDLE CAGE	TATA spare parts
286526993007	NEEDLE CAGE	TATA spare parts
286526993008	CYL.ROLLER	TATA spare parts
286526993009	NEEDLE SLEEVE	TATA spare parts
286526993010	CYL.ROLLER	TATA spare parts
286526993011	NEEDLE CAGE(16X22X16)	TATA spare parts
286526993012	NEEDLE CAGE	TATA spare parts
286526993015	NEEDLE SLEEVE	TATA spare parts
286526993016	ROLLER	TATA spare parts
286526993017	ROLLER CAGE	TATA spare parts
286526993018	BALL	TATA spare parts
286526993019	NEEDLE CAGE	TATA spare parts
286526993020	NEEDLE CAGE	TATA spare parts
286526993021	NEEDLE CAGE	TATA spare parts
286526993022	NEEDLE CAGE	TATA spare parts
286526993023	NEEDLE CAGE	TATA spare parts
286526993101	TAPER ROLLER BEARING	TATA spare parts
286526993102	JOINT BEARING	TATA spare parts
286526993103	TA.ROLL.BEARING	TATA spare parts
286526993106	TA.ROLL.BEARING	TATA spare parts
286526993107	TA.ROLL.BEARING	TATA spare parts
286526993108	JOINT BEARING	TATA spare parts
286526993109	CYROLLBEARING	TATA spare parts
286526993110	BALL BEARING	TATA spare parts
286526993111	TAROLLBEARING	TATA spare parts
286526993112	TAROLLBEARING	TATA spare parts
286526993113	TAROLLBEARING	TATA spare parts
286526993114	TAROLLBEARING	TATA spare parts
286526993115	TAROLLBEARING	TATA spare parts
286526993116	TAROLLBEARING	TATA spare parts
286526993117	TAPER ROLLER BEARING	TATA spare parts
286526993118	BALL BEARING	TATA spare parts
286526993120	JOINT BEARING	TATA spare parts
286526993122	TAPER ROLLER BEARING	TATA spare parts
286526993201	FASTENERS	TATA spare parts
286526993205	HEXAGON BOLT	TATA spare parts

286526993207	HEXAGON BOLT	TATA spare parts
286526993208	HEXAGON SCREW	TATA spare parts
286526993209	ARTICULATION BOLT	TATA spare parts
286526993212	HEXAGON SCREW	TATA spare parts
286526993214	HEXAGON SCREW	TATA spare parts
286526993217	HEXAGON SCREW	TATA spare parts
286526993220	ARTICULATION BOLT	TATA spare parts
286526993221	ARTICULATION BOLT	TATA spare parts
286526993222	HEXAGON BOLT	TATA spare parts
286526993223	HEXAGON BOLT	TATA spare parts
286526993224	HEXAGON BOLT	TATA spare parts
286526993225	HEXAGON BOLT	TATA spare parts
286526993226	HEXAGON SCREW	TATA spare parts
286526993227	HEXAGON BOLT	TATA spare parts
286526993228	HEXAGON SCREW	TATA spare parts
286526993229	HEXAGON BOLT	TATA spare parts
286526993230	HEXAGON SCREW	TATA spare parts
286526993231	HEXAGON BOLT	TATA spare parts
286526993232	HEXAGON BOLT	TATA spare parts
286526993233	HEXAGON BOLT	TATA spare parts
286526993234	HEXAGON BOLT	TATA spare parts
286526993235	HEXAGON BOLT	TATA spare parts
286526993236	HEXAGON BOLT	TATA spare parts
286526993237	HEXAGON SCREW M18X1.5X160	TATA spare parts
286526993238	HEXAGON BOLT	TATA spare parts
286526993239	HEXAGON BOLT	TATA spare parts
286526993240	HEXAGON BOLT	TATA spare parts
286526993241	ARTICULAT.BOLT	TATA spare parts
286526993401	FLANGE BUSH	TATA spare parts
286526993402	BUSH	TATA spare parts
286526993403	THREADED BUSH	TATA spare parts
286526993404	BEARING BUSH	TATA spare parts
286526993405	BEARING BUSH	TATA spare parts
286526993406	BEARING BUSH	TATA spare parts
286526993407	BEARING BUSH	TATA spare parts
286526993408	BEARING BUSH	TATA spare parts
286526993409	BUSH	TATA spare parts
286526993410	NEEDLE BUSH	TATA spare parts
286526993414	BUSH	TATA spare parts
286526993415	PLUG-IN BUSH BS6	TATA spare parts
286526993417	BEARING BUSH	TATA spare parts
286526993421	BUSH	TATA spare parts
286526993422	BUSH	TATA spare parts
286526993701	HOUSING	TATA spare parts
286526993703	G.SHIFT HOUSING	TATA spare parts
286526993704	PUMP HOUSING	TATA spare parts
286526993705	BELL HOUSING	TATA spare parts

286526993706	HOUSING	TATA spare parts
286526993707	BELL HOUSING	TATA spare parts
286526993709	GEAR SHIFT HOUSING	TATA spare parts
286526993710	GEAR SHIFT FORK	TATA spare parts
286526993717	HOUSING I	TATA spare parts
286526993718	GEAR SHIFT HOUSING	TATA spare parts
286526993719	BELL HOUSING	TATA spare parts
286526993729	HOUSING	TATA spare parts
286526993732	HOUSING ILL	TATA spare parts
286526993801	CLUTCH BELL HOUSING	TATA spare parts
286526993814	HOUSING CLUTCH	TATA spare parts
286526994101	RELEASE FORK	TATA spare parts
286526994102	RELEASE FORK	TATA spare parts
286526994103	RELEASE FORK	TATA spare parts
286526994104	FORK	TATA spare parts
286526994201	SHIFT CLAMP	TATA spare parts
286526994202	CONNECT.SOCKET	TATA spare parts
286526994301	RETAINING RING	TATA spare parts
286526994320	SEALING RING (3.6)	TATA spare parts
286526994321	SEALING RING (3.4)	TATA spare parts
286526994322	SEALING RING (3.2)	TATA spare parts
286526994323	SEALING RING (3.0)	TATA spare parts
286526994324	SEALING RING (2.8)	TATA spare parts
286526994326	SEALING RING (2.4)	TATA spare parts
286526994327	SEALING RING (2.2)	TATA spare parts
286526994335	SEALING RING	TATA spare parts
286526994336	SEALING RING	TATA spare parts
286526994338	SEALING RING	TATA spare parts
286526994338AE	SEALING RING 1628	TATA spare parts
286526994339	SEALING RING	TATA spare parts
286526994340	RETAINING RING	TATA spare parts
286526994341	RETAINING RING	TATA spare parts
286526994342	RETAINING RING	TATA spare parts
286526994343	CIRCLIP	TATA spare parts
286526994344	CIRCLIP	TATA spare parts
286526994345	RING	TATA spare parts
286526994346	RING PIECE	TATA spare parts
286526994347	SEALING RING	TATA spare parts
286526994348	RETAINING RING	TATA spare parts
286526994349	RETAINING RING BS6	TATA spare parts
286526994350	RETAINING RING	TATA spare parts
286526994601	CLUTCH BODY	TATA spare parts
286526994610	CLUTCH BODY	TATA spare parts
286526994616	CLUTCH BODY	TATA spare parts
286526994621	SYNCHRONIZER BS3/4	TATA spare parts
286526994622	CLUTCH BODY	TATA spare parts
286526994623	SYNCHROBODY	TATA spare parts

286526994624	SYNCHROBODY	TATA spare parts
286526994625	SYNCHROBODY	TATA spare parts
286526994626	SYNCHRONIZER BS3/4	TATA spare parts
286526994631	GEAR ASSY SYNCHRONIZER	TATA spare parts
286526994632	SYNCHRO RING	TATA spare parts
286526994633	CLUTCH HOUSING	TATA spare parts
286526994635	CLUTCH BODY BS6	TATA spare parts
286526994638	RING	TATA spare parts
286526994701	COVER	TATA spare parts
286526994703	COVER	TATA spare parts
286526994704	COVER	TATA spare parts
286526994705	COVER	TATA spare parts
286526994706	COVER	TATA spare parts
286526994707	PUMP COVER	TATA spare parts
286526994708	COVER	TATA spare parts
286526994711	COVER	TATA spare parts
286526994712	COVER	TATA spare parts
286526994713	GEAR SHIFT COVER	TATA spare parts
286526994714	GEAR SHIFT COVER	TATA spare parts
286526994715	GEAR SHIFT COVER	TATA spare parts
286526994721	COVER	TATA spare parts
286526994722	COVER	TATA spare parts
286526994723	GEAR SHIFT COVER	TATA spare parts
286526994724	GEAR SHIFT COVER	TATA spare parts
286526994729	GEAR SHIFT COVER	TATA spare parts
286526994737	COVER	TATA spare parts
286526994738	GEAR SHIFT COVER	TATA spare parts
286526994740	COVER	TATA spare parts
286526994742	COVER	TATA spare parts
286526994801	DOWEL	TATA spare parts
286526995101	RING GEAR CARRIER	TATA spare parts
286526995102	OUTPUT FLANGE	TATA spare parts
286526995113	SHIFT RAIL	TATA spare parts
286526995114	SHIFT RAIL	TATA spare parts
286526995115	SHIFT RAIL	TATA spare parts
286526995116	SHIFT RAIL	TATA spare parts
286526995302	GASKET	TATA spare parts
286526995303	GASKET	TATA spare parts
286526995304	GASKET	TATA spare parts
286526995305	GASKET	TATA spare parts
286526995306	GASKET	TATA spare parts
286526995307	GASKET	TATA spare parts
286526995308	GASKET	TATA spare parts
286526995310	GASKET	TATA spare parts
286526995311	GASKET	TATA spare parts
286526995312	GASKET	TATA spare parts
286526995313	GASKET	TATA spare parts

286526995314	GASKET	TATA spare parts
286526995319	GASKET	TATA spare parts
286526995401	IDLER GEAR	TATA spare parts
286526995402	HELICAL GEAR	TATA spare parts
286526995403	HELICAL GEAR	TATA spare parts
286526995404	HELICAL GEAR	TATA spare parts
286526995405	HELICAL GEAR	TATA spare parts
286526995406	HELICAL GEAR	TATA spare parts
286526995407	HELICAL GEAR	TATA spare parts
286526995408	HELICAL GEAR	TATA spare parts
286526995409	HELICAL GEAR	TATA spare parts
286526995410	HELICAL GEAR	TATA spare parts
286526995411	SPUR GEAR	TATA spare parts
286526995412	DOUBLE GEAR	TATA spare parts
286526995413	HELICAL GEAR	TATA spare parts
286526995414	HELICAL GEAR	TATA spare parts
286526995415	HELICAL GEAR	TATA spare parts
286526995416	REVERSE IDLER GEAR	TATA spare parts
286526995417	SUN GEAR	TATA spare parts
286526995419	HELICAL GEAR	TATA spare parts
286526995423	GEAR	TATA spare parts
286526995424	GEAR	TATA spare parts
286526995425	GEAR	TATA spare parts
286526995426	GEAR	TATA spare parts
286526995427	GEAR	TATA spare parts
286526995428	GEAR	TATA spare parts
286526995429	GEAR	TATA spare parts
286526995431	GEAR	TATA spare parts
286526995432	GEAR	TATA spare parts
286526995434	REVERSE IDLER GEAR	TATA spare parts
286526996001	GEAR SHIFT RAIL	TATA spare parts
286526996002	GEAR SHIFT RAIL	TATA spare parts
286526996003	GEAR SHIFT RAIL	TATA spare parts
286526996004	GEAR SHIFT RAIL	TATA spare parts
286526996005	SHIFTING INTERLOCK	TATA spare parts
286526996006	LOCKING LEVER	TATA spare parts
286526996008	SELECTOR LEVER	TATA spare parts
286526996009	SELECTOR LEVER	TATA spare parts
286526996010	SHIFTING INTERLOCK	TATA spare parts
286526996011	VALVE LEVER	TATA spare parts
286526996012	RELAY LEVER	TATA spare parts
286526996013	GEAR SHIFT LEVER	TATA spare parts
286526996014	LEVER	TATA spare parts
286526996015	GEAR SHIFT LEVER	TATA spare parts
286526996016	SHIFTING INTERLOCK	TATA spare parts
286526996020	GEAR SHIFT LEVER	TATA spare parts
286526996023	GEAR SHIFT RAIL BS6	TATA spare parts

286526996025	GEAR SHIFT RAIL	TATA spare parts
286526996301	SWITCH	TATA spare parts
286526996501	HEXAGON NUT	TATA spare parts
286526996502	HEXAGON NUT	TATA spare parts
286526996503	LOCKING NUT	TATA spare parts
286526996504	HEXAGON NUT	TATA spare parts
286526996505	HEXAGON NUT	TATA spare parts
286526996602	PISTON WITH MAGNETIC RING	TATA spare parts
286526996603	PISTON	TATA spare parts
286526996701	CYLINDRICAL PIN	TATA spare parts
286526996703	PRESSURE PART	TATA spare parts
286526996704	DETENT PIN	TATA spare parts
286526996707	STOP PIN	TATA spare parts
286526996708	RASTENTEIL	TATA spare parts
286526996709	SLOT.PIN	TATA spare parts
286526996710	SLOT.PIN	TATA spare parts
286526996711	RASTENTEIL	TATA spare parts
286526996714	PIN	TATA spare parts
286526996715	RETAINING RING	TATA spare parts
286526996716	SLOT.PIN	TATA spare parts
286526996717	CYLINDRICAL PIN 6X18	TATA spare parts
286526996718	CYLINDRICAL PIN	TATA spare parts
286526996719	CYLINDER PIN	TATA spare parts
286526996720	DETENT	TATA spare parts
286526996721	DETENT PART	TATA spare parts
286526996722	DETENT PLUNGER	TATA spare parts
286526996723	PIN	TATA spare parts
286526996724	PIN	TATA spare parts
286526996725	PIN	TATA spare parts
286526996726	DETENT PLUNGER	TATA spare parts
286526996727	DETENT	TATA spare parts
286526996728	BALL PIN	TATA spare parts
286526996735	PIN BS6	TATA spare parts
286526996736	SPRING PIN BS6	TATA spare parts
286526996738	PIN	TATA spare parts
286526996803	PIPE UNION	TATA spare parts
286526996804	PIPE UNION	TATA spare parts
286526996805	HOSE PIPE	TATA spare parts
286526996806	HOSE PIPE	TATA spare parts
286526996807	HOSE PIPE	TATA spare parts
286526996808	ASSY. RETRO KIT FOR OIL COOLER-LPK2528	TATA spare parts
286526996811	ASSY. RETRO KIT FOR OIL COOLER-LPK3128	TATA spare parts
286526996814	ASSY. RETRO KIT FOR OIL COOLER	TATA spare parts
286526996817	ASSY. RETRO KIT FOR OIL COOLER	TATA spare parts
286526996901	COOLER SET	TATA spare parts
286526996902	OIL TUBE	TATA spare parts
286526996903	OIL TUBE	TATA spare parts

286526996906	TUBE FOR OIL COOLER	TATA spare parts
286526996907	PIPE	TATA spare parts
286526996908	PIPE	TATA spare parts
286526996909	PIPE	TATA spare parts
286526996911	TUBE	TATA spare parts
286526996917	TUBE	TATA spare parts
286526996918	TUBE	TATA spare parts
286526996919	TUBE	TATA spare parts
286526996920	TUBE	TATA spare parts
286526996921	TUBE	TATA spare parts
286526996928	PLATE	TATA spare parts
286526996932	CLUTCH BODY BS6	TATA spare parts
286526996935	GEARSHIFT FORK BS6	TATA spare parts
286526996938	SYNCHRO.RING BS6	TATA spare parts
286526996940	CLUTCH HOUSING	TATA spare parts
286526996942	FORK BS6	TATA spare parts
286526996944	BUSH BS6	TATA spare parts
286526997101	CONNECTION PLATE	TATA spare parts
286526997102	CONN.PLATE	TATA spare parts
286526997105	BRACKET	TATA spare parts
286526997107	TYPE PLATE	TATA spare parts
286526997109	CONNPLATE	TATA spare parts
286526997118	COVER ASSY INPUT SHAFT	TATA spare parts
286526997206	SCREW PLUG	TATA spare parts
286526997207	SCREW PLUG	TATA spare parts
286526997208	SCREW PLUG	TATA spare parts
286526997209	SCREW PLUG	TATA spare parts
286526997210	SCREW PLUG	TATA spare parts
286526997211	SCREW PLUG	TATA spare parts
286526997212	SCREW PLUG	TATA spare parts
286526997302	RETAINING RING 2.45 BS6	TATA spare parts
286526997303	RETAINING RING 2.50 BS6	TATA spare parts
286526997304	RETAINING RING 2.55 BS6	TATA spare parts
286526997305	RETAINING RING 2.60 BS6	TATA spare parts
286526997306	RETAINING RING 2.65 BS6	TATA spare parts
286526997307	RETAINING RING 2.70 BS6	TATA spare parts
286526997308	RETAINING RING 2.75 BS6	TATA spare parts
286526997309	RETAINING RING 2.80 BS6	TATA spare parts
286526997310	RETAINING RING 2.85 BS6	TATA spare parts
286526997311	RETAINING RING 2.90 BS6	TATA spare parts
286526997312	RETAINING RING 2.95 BS6	TATA spare parts
286526997401	BLIND RIVET	TATA spare parts
286526997701	O-RING	TATA spare parts
286526997702	SHAFT SEAL	TATA spare parts
286526997703	SHAFT SEAL	TATA spare parts
286526997705	V-RING	TATA spare parts
286526997706	O-RING	TATA spare parts



286526997708	O-RING	TATA spare parts
286526997709	O-RING 73X2	TATA spare parts
286526997710	O-RING 70X2	TATA spare parts
286526997711	O-RING	TATA spare parts
286526997712	SHAFT SEAL	TATA spare parts
286526997713	SHAFT SEAL	TATA spare parts
286526997714	SHAFT SEAL	TATA spare parts
286526997715	V-RING	TATA spare parts
286526997716	V-RING	TATA spare parts
286526997717	SHAFT SEAL	TATA spare parts
286526997718	SEALS	TATA spare parts
286526997721	ACCESSORIES (ZF-6090.102.805)	TATA spare parts
286526997722	GEARBOX ACCESSORIES (ZF-6090.190.046)	TATA spare parts
286526997737	SHAFT SEAL	TATA spare parts
286526997739	SEAL	TATA spare parts
286526997801	PULSE SENSOR	TATA spare parts
286526997802	OIL DAM	TATA spare parts
286526997803	OIL DAM	TATA spare parts
286526997804	SEALING CAP	TATA spare parts
286526997805	SEALING CAP	TATA spare parts
286526997806	SEALING CAP	TATA spare parts
286526997807	SEALING CAP	TATA spare parts
286526997808	SEALING CAP	TATA spare parts
286526997814	PROTECTIVE CAP	TATA spare parts
286526997815	O-RING	TATA spare parts
286526997816	O-RING	TATA spare parts
286526997901	INPUT SHAFT	TATA spare parts
286526997903	LAYSHAFT	TATA spare parts
286526997904	MAIN SHAFT	TATA spare parts
286526997905	G.SHIFT SHAFT	TATA spare parts
286526997906	PUMP SHAFT	TATA spare parts
286526997907	INPUT SHAFT	TATA spare parts
286526997908	INTERMEDIATE SHAFT	TATA spare parts
286526997909	GEAR SHIFT SHAFT	TATA spare parts
286526997910	PLANET SHAFT	TATA spare parts
286526997911	PLANET SHAFT	TATA spare parts
286526997912	QUILL SHAFT	TATA spare parts
286526997913	SELECTOR SHAFT	TATA spare parts
286526997920	INPUT SHAFT	TATA spare parts
286526997921	GEAR SHIFT SHAFT	TATA spare parts
286526997923	SHAFT	TATA spare parts
286526997924	SHAFT PLANET	TATA spare parts
286526997930	SHAFT (ZF-1304.242.006)	TATA spare parts
286526997935	INPUT SHAFT	TATA spare parts
286526997937	MAIN SHAFT	TATA spare parts
286526997948	COUNTER SHAFT	TATA spare parts
286526998001	UNION SCREW	TATA spare parts

286526998002	COMBISCREW M4X25	TATA spare parts
286526998003	HEXAGON SCREW	TATA spare parts
286526998004	UNION SCREW	TATA spare parts
286526998006	UNION SCREW	TATA spare parts
286526998007	HEX SCREW	TATA spare parts
286526998008	HEX SCREW	TATA spare parts
286526998009	THROTILE SCREW	TATA spare parts
286526998010	HEXAGON SCREW	TATA spare parts
286526998013	SCREW	TATA spare parts
286526998327	SHIM (0.95 THK)	TATA spare parts
286526998328	SHIM (1.6 THK)	TATA spare parts
286526998329	SHIM (1.55 THK)	TATA spare parts
286526998330	SHIM (1.50 THK)	TATA spare parts
286526998331	SHIM (1.45 THK)	TATA spare parts
286526998332	SHIM (1.40 THK)	TATA spare parts
286526998333	SHIM (1.35 THK)	TATA spare parts
286526998334	SHIM (1.30 THK)	TATA spare parts
286526998335	SHIM (1.25 THK)	TATA spare parts
286526998336	SHIM (1.20 THK)	TATA spare parts
286526998337	SHIM (1.15 THK)	TATA spare parts
286526998338	SHIM (1.10 THK)	TATA spare parts
286526998339	SHIM (1.05 THK)	TATA spare parts
286526998340	SHIM (1.00 THK)	TATA spare parts
286526998341	SHIM (0.95 THK)	TATA spare parts
286526998342	SHIM (0.90 THK)	TATA spare parts
286526998343	SHIM (0.85 THK)	TATA spare parts
286526998344	SHIM (0.80 THK)	TATA spare parts
286526998345	SHIM (0.75 THK)	TATA spare parts
286526998346	SHIM (0.70 THK)	TATA spare parts
286526998347	SHIM (0.65 THK)	TATA spare parts
286526998348	SHIM	TATA spare parts
286526998349	SHIM	TATA spare parts
286526998350	SHIM	TATA spare parts
286526998351	SHIM	TATA spare parts
286526998352	SHIM	TATA spare parts
286526998401	SLIDING SLEEVE	TATA spare parts
286526998402	SLEEVE CARRIER	TATA spare parts
286526998403	SLIDING SLEEVE	TATA spare parts
286526998701	COMPRESSION SPRING	TATA spare parts
286526998702	COMPR.SPRING	TATA spare parts
286526998703	COMPRESSION SPRING	TATA spare parts
286526998705	COMPR.SPRING	TATA spare parts
286526998706	COMPR.SPRING	TATA spare parts
286526998707	COMPRSPRING	TATA spare parts
286526998708	COMPRESSION SPRING	TATA spare parts
286526998709	COMPRESSION SPRING	TATA spare parts
286526998710	COMPRESSION SPRING	TATA spare parts

286526998713	COMPRSPRING	TATA spare parts
286526998714	COMPRSPRING	TATA spare parts
286526998715	COMPRSPRING	TATA spare parts
286526998716	COMPRSPRING	TATA spare parts
286526998718	COMPRESSION SPRING	TATA spare parts
286526998720	COMPR.SPRING	TATA spare parts
286526998725	COMPRESSION SPRING BS6	TATA spare parts
286526998801	STUD M12X70	TATA spare parts
286526998802	STUD M12X130	TATA spare parts
286526998803	STUD M12X90	TATA spare parts
286526998804	STUD	TATA spare parts
286526998805	STUD	TATA spare parts
286526999001	VALVE	TATA spare parts
286526999002	CUT-OFF VALVE	TATA spare parts
286526999003	GREASE	TATA spare parts
286526999004	PNEUMATIC SERVO UNIT BS3/4	TATA spare parts
286526999225	WASHER	TATA spare parts
286526999230	WASHER	TATA spare parts
286526999231	SEALING WASHER	TATA spare parts
286526999232	WASHER	TATA spare parts
286526999233	SNAP RING	TATA spare parts
286526999234	CENTERING RING	TATA spare parts
286526999235	SNAP RING	TATA spare parts
286526999236	WASHER	TATA spare parts
286526999237	SNAP RING	TATA spare parts
286526999238	SPRING WASHER	TATA spare parts
286526999239	WASHER	TATA spare parts
286526999240	WASHER	TATA spare parts
286526999241	WASHER	TATA spare parts
286526999242	WASHER	TATA spare parts
286526999244	WASHER	TATA spare parts
286526999247	SPRING WASHER	TATA spare parts
286526999249	SNAP RING	TATA spare parts
286526999250	SNAP RING BS6	TATA spare parts
286526999251	SNAP RING BS6	TATA spare parts
286526999252	SNAP RING	TATA spare parts
286526999253	SNAP RING BS6	TATA spare parts
286526999254	SNAP RING BS6	TATA spare parts
286526999801	CUP	TATA spare parts
286526999901	PTO SPARE KIT	TATA spare parts
286526999903	PULSE SENSOR	TATA spare parts
286526999904	IMPULSSCHEIBE	TATA spare parts
286526999905	SLIDING PAD	TATA spare parts
286526999907	SWITCH	TATA spare parts
286526999908	ADAPTER	TATA spare parts
286526999909	PLUG KIT	TATA spare parts
286526999911	PROTECTION CAP	TATA spare parts

286526999912	DRIVER	TATA spare parts
286526999913	SCRAPER	TATA spare parts
286526999914	SWITCH	TATA spare parts
286526999916	INTERM.PIECE	TATA spare parts
286526999917	SCREEN INSERT	TATA spare parts
286526999918	HEAT EXCHANGER	TATA spare parts
286526999919	REDUCER	TATA spare parts
286526999920	PLUG	TATA spare parts
286526999921	SEALING CAP BS6	TATA spare parts
286526999923	PROTECTING CAP	TATA spare parts
286526999924	THRUST RING	TATA spare parts
286526999925	BREATHER	TATA spare parts
286526999926	SCRAPER	TATA spare parts
286526999927	PROTECTION CAP	TATA spare parts
286526999928	PROTECTING CAP	TATA spare parts
286526999929	PUMP	TATA spare parts
286526999930	OIL PUMP	TATA spare parts
286526999931	DRIVER	TATA spare parts
286526999932	DRIVER	TATA spare parts
286526999933	DRIVER	TATA spare parts
286526999950	CABLE NAT	TATA spare parts
286526999951	PLUG	TATA spare parts
286526999952	DRIVER	TATA spare parts
286526999953	OUTPUT FLANGE	TATA spare parts
286526999954	OUTPUT FLANGE	TATA spare parts
286526999955	CABLE NAT	TATA spare parts
286526999956	BALL CUP	TATA spare parts
286526999957	WIRE	TATA spare parts
286526999958	BALL CUP	TATA spare parts
286526999959	PLUG	TATA spare parts
286526999963	SWITCH	TATA spare parts
286526999964	CAP SHIFTER SHAFT	TATA spare parts
286526999972	PUMP	TATA spare parts
286526999975	BALL CUP	TATA spare parts
286526999980	PLUG	TATA spare parts
286526999984	TUBE	TATA spare parts
286526999986	TUBE BS6	TATA spare parts
286526999987	PROTECTIVE TUBE BS6	TATA spare parts
286526999988	SWITCH	TATA spare parts
286601153801	AIR INTAKE ELBOW	TATA spare parts
286609130102	ASSY. BKT.(FOR AIR FILTER MTG.)	TATA spare parts
286609130103	ASSY. BRACKET (FOR PRECLEANER MTG.)	TATA spare parts
286609130105	ASSY AIR CLEANER (LPO 1623 HIDECK)	TATA spare parts
286609130106	ASSY. PRECLEANER	TATA spare parts
286609135801	HOSE REDUCER(140 ID TO 102 ID)	TATA spare parts
286609135802	HOSE(152 ID)	TATA spare parts
286609135803	HOSE ELBOW(152 ID TO 152 ID)	TATA spare parts

286609136901	PIPE (TC TO AIR FILTER)	TATA spare parts
286609136902	PIPE(PRECLENER TO AIR FILTER)	TATA spare parts
286609139901	AIR FILTER ELEMENT PRIMARY BS2/3/4	TATA spare parts
286609139901AE	ASSY AIR FLTR PRIM CRTRDGE -2523	TATA spare parts
286609139902	AIR FILTER ELEMENT CARTRIDGE BS2/3/4	TATA spare parts
286609139902AE	AIR FILTER SAFETY ELEMENT 2523	TATA spare parts
286613130101	ASSY. ADAPTOR	TATA spare parts
286613136901	SUCTION PIPE	TATA spare parts
286613136902	SUCTION PIPE	TATA spare parts
286613138201	BRACKET	TATA spare parts
286614603301	SUPPORT (IC TO ENGINE PIPE)	TATA spare parts
286614604201	CLAMP (SUPPORT PIPE IC TO ENG)	TATA spare parts
286614605801	HUMP HOSE BS1/2/3/4	TATA spare parts
286614605801AE	HUMP HOSE (MRP-BLUE) 1628 1828	TATA spare parts
286614606901	PIPE (INTERCOOLER TO ENGINE)	TATA spare parts
286614606902	PIPE (TC TO INTERCOOLER)	TATA spare parts
286614609901	INTERCOOLER	TATA spare parts
286614609902	ASSY INTERCOOLER	TATA spare parts
286620157906	SHAFT (FOR VISCOUS FAN WITH THRADED MTG.	TATA spare parts
286622100101	ASSY RUBBER SUPPORT FRONT	TATA spare parts
286622100102	ASSY RUBBER SUPPORT REAR	TATA spare parts
286623120101	ASSY. BRACKET (A.C. MTG.)	TATA spare parts
286623126302	COGGED V BELT (A/C DRIVE) TWIN GROOVE	TATA spare parts
286650009901	CONNECTOR RETARDER (ON THERMOSTAT HOUS	TATA spare parts
286650100103	ASSY RADIATOR	TATA spare parts
286650990101	ASSY. FOAM	TATA spare parts
286732100101	ASSY. FRONT SPRING-HIGHER CAMBER	TATA spare parts
286732100102	ASSY FIRST LEAF WITH BUSHES	TATA spare parts
286732100103	ASSY. FRONT SPRING-NORMAL CAMBER	TATA spare parts
286732100104	ASSY FIRST LEAF WITH BUSHES	TATA spare parts
286732103201	CENTRE BOLT	TATA spare parts
286732104201	SPRING CLIP	TATA spare parts
286732104202	SPRING CLIP	TATA spare parts
286732107102	SECOND LEAF	TATA spare parts
286732107103	THIRD LEAF	TATA spare parts
286732107104	FORTH LEAF	TATA spare parts
286732107105	FIFTH LEAF	TATA spare parts
286732107106	SIXTH LEAF	TATA spare parts
286732107107	SEVENTH LEAF	TATA spare parts
286732107108	EIGHTH LEAF	TATA spare parts
286732107109	NINETH LEAF	TATA spare parts
286732107110	TENTH LEAF	TATA spare parts
286732107112	SECOND LEAF	TATA spare parts
286732107113	THIRD LEAF	TATA spare parts
286732107114	FORTH LEAF	TATA spare parts
286732107115	FIFTH LEAF	TATA spare parts
286732107116	SIXTH LEAF	TATA spare parts

286732107117	SEVENTH LEAF	TATA spare parts
286732107118	EIGHTH LEAF	TATA spare parts
286732107119	NINETH LEAF	TATA spare parts
286732107120	TENTH LEAF	TATA spare parts
286742100106	BRAKE ASSY FRONT-LH WITH DUST COVER	TATA spare parts
286742100106AE	BRAKE ASSY FRT-LH WITH DUST -715	TATA spare parts
286742100107	BRAKE ASSY FRONT RH WITH DUST COVER	TATA spare parts
286742100107AE	BRK ASSY FRT RH W/DUST-1415-715	TATA spare parts
286742100165	ASSY CHAMBER MTG BKT (SA1212)-R H	TATA spare parts
286742100166	ASSY FRONT CHAMBER MTG BKT-L H	TATA spare parts
286742100173	ASSY SLACK ADJUSTER LH	TATA spare parts
286742100173AE	ASSY SLACK ADJUSTER LH 715	TATA spare parts
286742100174	ASSY SLACK ADJUSTER RH	TATA spare parts
286742100174AE	ASSY SLACK ADJUSTER RH 715	TATA spare parts
286742100175	ASSY SPRING BRAKE ACTUATOR TYPE 16/56--F	TATA spare parts
286742100175AE	ASSY SPRNG BRK ACTUTR(16/56)-715	TATA spare parts
286742100178	ASSY CHAMBER MTG BRACKET (RH)	TATA spare parts
286742100179	ASSY CHAMBER MTG BRACKET (LH)	TATA spare parts
286742100184	SPRING ACTUATOR(TYPE 16/56) LH FRONT 715	TATA spare parts
286742100185	SPRING ACTUATOR(TYPE 16/56) RH FRONT 715	TATA spare parts
286742103701	BRAKE DRUM FRONT-DIA.410 X 160 (LPTA715)	TATA spare parts
286742103701AE	BRK DRUM FRT-DIA410X160-1415-715	TATA spare parts
286742103703	BRAKE DRUM FRONT (SA\SAK1212)	TATA spare parts
286742103732	SPACER	TATA spare parts
286742108211	ANCHOR BRACKET FRONT(SA/SAK1212 SD1015)	TATA spare parts
286742108212	ANCHOR BRACKET FRONT	TATA spare parts
286742130101	SBA MAJOR SPARE KIT TYPE 16/16	TATA spare parts
286742130102	TYPE 16/16 SBA PORTS SPARE KIT	TATA spare parts
286742300117	ASSY R/AXLE BRAKE RH WITH DUST COVER	TATA spare parts
286742300119	ASSY R/AXLE BRAKE LH WITH DUST COVER	TATA spare parts
286742300132	ASSY LCRV BRACKET	TATA spare parts
286742303701	BRAKE DRUM REAR DIA.410 X 160	TATA spare parts
286742303701AE	BRK DRUM RR DIA410X160-1415-715	TATA spare parts
286742303703	PARKING BRAKE LEVER (DOAH BRAKE ASSY)	TATA spare parts
286742303724	CHAMBER MTG BKT RH (76.2 PITCH)	TATA spare parts
286742303728	CHAMBER MTG BKT LH (76.2 PITCH)	TATA spare parts
286742308210	ANCHOR BRACKET STRAIGHT	TATA spare parts
286742308211	ANCHOR BRACKET STRAIGHT	TATA spare parts
2868063	PULLEY CRANKSHAFT	TATA spare parts
2868081	CONVERTER CATALYTIC	TATA spare parts
2868126	SPACER CRANKSHAFT	TATA spare parts
286815100101	STARTER 1.4KW-IMP GR WITH CABLES	TATA spare parts
286815159901	ARMATURE ASSY	TATA spare parts
286815159902	BRUSH GEAR ASSY STARTER	TATA spare parts
286815159903	CE BRACKET ASSY STARTER	TATA spare parts
286815159904	Fastener assly KIT	TATA spare parts
286815159905	PACKING,GEAR & BEARING ASSY. KIT (262444	TATA spare parts

286815159906	Internal gear assly	TATA spare parts
286840109902	BALANCE WEIGHT (10GMS)(ZINC ALLOY)	TATA spare parts
286840109903	BALANCE WEIGHT (15GMS)(ZINC ALLOY)	TATA spare parts
286840109904	BALANCE WEIGHT (20GMS)(ZINC ALLOY)	TATA spare parts
286840109905	BALANCE WEIGHT (25GMS)(ZINC ALLOY)	TATA spare parts
286840109906	BALANCE WEIGHT (30GMS)(ZINC ALLOY)	TATA spare parts
286840109908	BALANCE WEIGHT (40GMS)(ZINC ALLOY)	TATA spare parts
286840109909	BALANCE WEIGHT (45GMS)(ZINC ALLOY)	TATA spare parts
286846607001	PULLEY POWER STG. PUMP	TATA spare parts
286854209921	RELAY 12V 40A 1 C/O SEALED	TATA spare parts
286854209923	STARTER MOTOR PROTECTION UNIT	TATA spare parts
286854209927	Sealed relay 20A	TATA spare parts
286854209928	RELAY 12V 20A 1 N/O SEALED R-ENGG	TATA spare parts
2868544	PULLEY CRANKSHAFT	TATA spare parts
286854700104	ASSY BLOWER MOTOR MET BODY M/S SUBROS	TATA spare parts
286858900601	SPANNER FOR GLOW PLUG- 8A/F(1.4L)	TATA spare parts
286858900602	VALVE SPRING COMPRESSOR - 1.4L DICOR	TATA spare parts
286858900603	TIMING PLATE FOR CAMSHAFT LOCK	TATA spare parts
286858900604	TDC LOCKING PIN - 1.4L DICOR	TATA spare parts
286858900605	DRIFT-VALVE GUIDE INLET/EXHAUST	TATA spare parts
286858900606	SPACER FOR FITMENT OF VALVE GUIDE ALONG	TATA spare parts
286858900701	ADAPTOR/CHECKING ENGINE COMP	TATA spare parts
286858900704	PULLER / REMOVE INJECTOR	TATA spare parts
286858901501	SPANNER-12 A/F FOR STARTER MOTOR	TATA spare parts
286858904003	PORTABLE FIRE EXTINGUISHER 1KG	TATA spare parts
286858904004	PORTABLE FIRE EXTINGUISHER-1KG	TATA spare parts
286858904005	PORTABLE FIRE EXTINGUISHER-1KG(STD FIRE)	TATA spare parts
286872300104	ASSY HANDLE WINDOW WINDING	TATA spare parts
286883110101	ASSY EXPANSION VALVE-1.2 TON SUBROS	TATA spare parts
286883130105	assy. Expansion valve 2 ton (BEHR)	TATA spare parts
287015409926	SPACER RING FOR ALTERNATOR	TATA spare parts
287015409928	DEEP_GROOVE_BALL_BEARING_FOR_ALTERNATOR	TATA spare parts
287015409931	ROTOR_FOR_ALTERNATOR	TATA spare parts
287015409934	HEXAGONAL_SCREW_FOR_ALTERNATOR	TATA spare parts
287015409937	RECTIFIER_FOR_ALTERNATOR	TATA spare parts
287015409954	REGULATOR BS6	TATA spare parts
287029100187	ASSY CLUTCH MASTER CYLINDER	TATA spare parts
287029100208	HIGH PRESSURE HOSE	TATA spare parts
287029106302	STAY ROD FOR ARIA (CSC 5.4 RATIO)	TATA spare parts
287029107704	GASKET	TATA spare parts
287029107706	RUBBER COVER (ARIA BRAKE PEDAL - AT)	TATA spare parts
287029108247	BRACKET HIGH PRESSURE LINE (MTG ON FIREW	TATA spare parts
287031700110	ASSY REAR STONEGUARD	TATA spare parts
287032100101	ASSY UPPER WISHBONE COMPLETE-RH	TATA spare parts
287032100104	ASSY UPPER WISHBONE COMPLETE-LH	TATA spare parts
287032100197	ASSY LOWER WISHBONE COMPLETE-RH (INTEGRA	TATA spare parts
287032100198	ASSY LOWER WISHBONE COMPLETE - LH	TATA spare parts

287032103202	HEX BOLT-UPPER WISHBONE MOUNTING	TATA spare parts
287032109203	WASHER UPPER WISHBONE MOUNTING	TATA spare parts
287032110102	ASSY RUBBER BUSH (UPPER WISHBONE)-M/S SV	TATA spare parts
287032110113	ASSY RUBBER BUSH (LOWER WISHBONE- FRONT)	TATA spare parts
287032110114	ASSY RUBBER BUSH (LOWER WISHBONE - REAR)	TATA spare parts
287032110151	ASSY UPPER BALL JONT	TATA spare parts
287032800116	ASSLY LINK-ARB-RH FRONT-M/S SONA SOMIC	TATA spare parts
287032800117	ASSY LINK-ARB-LH FRONT-M/S SONA SOMIC	TATA spare parts
287032807703	BEARING BLOCK (ANTI ROLL BAR)	TATA spare parts
287032808214	CLAMP ANTI ROLL BAR MOUNITING BRACKET	TATA spare parts
287033100103	ASSY BUSH UPPER (AXLE MTG.ON FRAME).	TATA spare parts
287033100104	AASY BUSH LOWER (AXLE MTG.ON FRAME).	TATA spare parts
287033100107	ASSY RUBBER BUSH TOP (AXLE MTG)	TATA spare parts
287033100111	ASSY RUBBER BUSH (FRONT AXLE MTG.) M/S S	TATA spare parts
287033100114	ASSY RUBBER BUSH-LOWER (AXLE FRNT MNTG)	TATA spare parts
287033203201	WHEEL STOPPER BOLT (LOWER WISHBONE)	TATA spare parts
287033205103	STUB AXLE-RH-4X2-ABS	TATA spare parts
287033205104	STUB AXLE-LH-4X2-ABS	TATA spare parts
287033400111	ASSY HUB W BRAKE DISC & TONER RING-ABS	TATA spare parts
287033403103	TAPERED ROLLER BEARING(HUB UNIT)	TATA spare parts
287033403705	WHEEL HUB (FRONT) - 4X2	TATA spare parts
287033407701	GASKET ( FRONT AXLE) 4X2	TATA spare parts
287033408202	HUB COVER	TATA spare parts
287033408603	SPACER	TATA spare parts
287033408604	SPACER (FRONT AXLE MOUNTING)	TATA spare parts
287040100124	ASSY COVER (WHEEL RIM) WITH GASKET	TATA spare parts
287040106701	WHEEL BOLT M14X1.5X47-10.9	TATA spare parts
287040107705	COVER (WHEEL RIM)	TATA spare parts
287040107706	GASKET	TATA spare parts
287040307702	RUBBER STRAP (FOR SPARE WHEEL)	TATA spare parts
287041110131	ASSY PROPELLER SHAFT -4X4-FRONT	TATA spare parts
287042100106	ASSY CALIPER BRAKE - RH	TATA spare parts
287042100107	ASSY CALIPER BRAKE - LH	TATA spare parts
287042100120	KIT PAD ASSEMBLY ( WITH SHIM) PER VEHICL	TATA spare parts
287042100120DF	BRAKE PAD KIT FRONT-XENON/YODHA BS3/4	TATA spare parts
287042100122	KIT BLEED SCREW ( M/S BIL:-29946045)	TATA spare parts
287042103705	BRAKE DISC (VENTILATED)-4X4	TATA spare parts
287042103707	BRAKE DISC-4X2-VENTILATED	TATA spare parts
287042104301	ANTI RATTLE CLIP	TATA spare parts
287042104302	ANTI RATTLE SPRING	TATA spare parts
287042105403	TONER RING (FRONT) 4X2	TATA spare parts
287042300107	ASSY REAR DRUM BRAKE - LH (M/S BIL)	TATA spare parts
287042300108	REAR DRUM BRAKE - RH	TATA spare parts
287042300134	ASSY.KIT LINED SHOE M/S BIL-29937370	TATA spare parts
287042300138	KIT W/C ASSY-MAJOR M/S BIL-29967253	TATA spare parts
287042300139	KIT W/C ASSY-MINOR M/S BIL-29967254	TATA spare parts
287042300140	KIT LINED SHOE ASSY	TATA spare parts



287042300141	KIT SHOE HOLD DOWN ASSY-M/S BIL-29919219	TATA spare parts
287042300142	KIT SHOE AND WASHER	TATA spare parts
287042300143	KIT LEVER ASSY LH (M/S BIL-29919237)	TATA spare parts
287042300144	KIT LEVER ASSY RH (M/S BIL-29919238)	TATA spare parts
287042300145	KIT LEVER PAWL-L.H. M/S-BIL 29919222	TATA spare parts
287042300146	KIT LEVER PAWL.R.H.-M/S BIL-29919223	TATA spare parts
287042300148	W/CLY ASSY-26.99 DIA-M/S BIL-2966568	TATA spare parts
287042300173	BACK PLATE ASSY	TATA spare parts
287042300174	BACK PLATE ASSY	TATA spare parts
287042300177	ADJUSTER ASSY (M/S BIL-29192613)	TATA spare parts
287042300178	ADJUSTER ASSY (M/S BIL-29192614)	TATA spare parts
287042303701	BRAKE DRUM	TATA spare parts
287042305301	GASKET	TATA spare parts
287042306801	ADAPTOR	TATA spare parts
287042308002	BLEED SCREW	TATA spare parts
287042308701	SPRING UPPER RETURN	TATA spare parts
287042308703	SPRING ABUTMENT END	TATA spare parts
287042308704	SPRING	TATA spare parts
287042309904	GROMMET	TATA spare parts
287042706701	CLEVIS PIN	TATA spare parts
287042800171	FRONT CALIPER HOSE M/S BRAKES INDIA LTD.	TATA spare parts
287042800211	CAMSHAFT DRIVEN VACUUM PUMP	TATA spare parts
287042807702	ABS_ECU_DAMPER_3	TATA spare parts
287042807704	CLAMP - FOR BRAKE LINES	TATA spare parts
287042807709	SINGLE PIPE CLAMP FOR BRAKE PIPELINES.	TATA spare parts
287042807710	TWO PIPE CLAMP FOR BRAKE PIPELINES	TATA spare parts
287042807711	SEPERATOR FOR FRONT HOSE AND WSS	TATA spare parts
287042807713	CLAMP FOR BRAKE AND VACUUM PIPELINES	TATA spare parts
287042807717	ASSY CLAMP FOR VACUUM PIPELINE (SUTAIBLE	TATA spare parts
287042807721	CLAMP FOR VACUUM AND BRAKE PIPELINES	TATA spare parts
287042807723	SEPERATOR CLAMP FOR WSS AND ARB(21 DIA)	TATA spare parts
287042808237	BRACKET FOR HOSE MOUNTING ON STUB AXLE (	TATA spare parts
287042808238	BRACKET FOR HOSE MOUNTING ON STUB AXLE (	TATA spare parts
287044807708	OFFER DRAWING-CLAMP FOR POWER STG. LINE.	TATA spare parts
287044807720	CLAMP FOR POWER STEERING PIPE LINES	TATA spare parts
287046600164	ASSY P/STRG PUMP - 90BAR	TATA spare parts
287046600168	OBJ ASSEMBLY	TATA spare parts
287046600170	FEED PIPE ASSEMBLY SHORT	TATA spare parts
287046600172	FEED PIPE ASSEMBLY LONG	TATA spare parts
287046600178	BELLOW ASSY	TATA spare parts
287046600179	IBJ KIT / ASSY- HEXA	TATA spare parts
287046600187	ALLEN HEAD SCREW	TATA spare parts
287046603401	INSULATOR MOUNTING	TATA spare parts
287046606501	NUT OBJ	TATA spare parts
287046606801	PRESSURE PORT CONNECTOR	TATA spare parts
287046607708	DUST COVER	TATA spare parts
287047109201	BONDED SEALANT (M 18)	TATA spare parts

287049207701	RUBBER HANGER	TATA spare parts
287049208207	GASKET (CC TO FRONT PIPE)	TATA spare parts
287054208233	MTG BRACKET WH CHASSIS ON GEARBOX	TATA spare parts
287054208247	REVERSE LIGHT SWITCH W/H PARKING BRACKET	TATA spare parts
287054209901	REAR_AXLE_WHEEL_SPEED_SENSOR_M/S_BOSCH	TATA spare parts
287054209902	FRONT_AXLE_WHEEL_SPEED_SENSOR_4X4_M/S	TATA spare parts
287054209903	FRONT_AXLE_WHEEL_SPEED_SENSOR_4X2_M/S	TATA spare parts
287054209904	STEERING_ANGLE_SENSOR_M/S_BOSCH	TATA spare parts
287054209907	TOD_ECU_M/S_BORG_WARNER	TATA spare parts
287054209909	HORN_LOW_TONE	TATA spare parts
287054209910	HORN_HIGH_TONE	TATA spare parts
287054209923	BUZZER_REVERSE_GUIDING_SYSTEM	TATA spare parts
287054209967	RELAY_40A_MAKE_CONTACT_WITH_RESISTOR	TATA spare parts
287054209968	SAS MOUNTING SCREW	TATA spare parts
287054409901	THREE_SW_ROOF_LAMP	TATA spare parts
287054509920	REVERSE_LIGHT_SWITCH	TATA spare parts
287054509926	TRANSPONDER AND RF KEY	TATA spare parts
287054509940	FUSE_MIDIVAL 60A	TATA spare parts
287054509941	FUSE_MIDIVAL 40A	TATA spare parts
287054509944	HOUSING COMBI SWITCH HIGH END	TATA spare parts
287054509951	CLOCK SPRING	TATA spare parts
287054509952	FUSE 40A (COOLING FAN 1)	TATA spare parts
287054609984	FUSE PULLER	TATA spare parts
287054610173	WIRING HARNESS,EMS	TATA spare parts
287054809910	TWEETER	TATA spare parts
287058900122	KIT - L/W BUSH REMOVAL BS6	TATA spare parts
287058900123	KIT - BUSH INSTALLER (LOWER WISHBONE) BS	TATA spare parts
287058900601	FLY WHEEL LOCKING PIN / CO	TATA spare parts
287058901801	OIL FILTER	TATA spare parts
287058901802	OIL FILTER SPANNER / MAHLE / CO	TATA spare parts
287058901804	OIL FILTER SPANNER	TATA spare parts
287058901805	SPL.SPANNER - OIL FILTER - 2.2L (M/S MAH	TATA spare parts
287058902501	MANDREL/CLUTCH DISC ALIGNMENT/207 COMM	TATA spare parts
287058902610	14BI-1/2"-280L Z SPNR/O-FILLING SCRE/CO	TATA spare parts
287058902611	MOUNTING PLATE FOR G-76 GEAR BOX	TATA spare parts
287058902612	DOLLY OIL FILTER SEAL INSTALLATION	TATA spare parts
287058902613	DOLLY-SHIFTER SHAFT SEAL INSTALLATION	TATA spare parts
287058902614	PULLER-SHIFTER SHAFT OIL SEAL	TATA spare parts
287058902615	MOUNTING PLATE-GEAR BOX	TATA spare parts
287058902616	HANGER FOR LIFTING GEAR BOX	TATA spare parts
287058902617	SUPPORT STAND-GEAR BOX	TATA spare parts
287058902620	PLATE STOPPER	TATA spare parts
287058902621	BRACKET	TATA spare parts
287058903201	DRIFT/ INSTALL BUSH/ USE W-28700111/ CO	TATA spare parts
287058903203	TOOL HOLD STRUCTURE STAND/USE W-28700111	TATA spare parts
287058903204	DRIFT/R-U- WIHBOB BUSH/USE W-28700112/CO	TATA spare parts
287058903206	EXTENSION/R-F-U WISHBONE BUSH/28700112/C	TATA spare parts

287058903231	GUIDE PIN/USE W-28700109,112,113,121,123	TATA spare parts
287058903232	GUIDE PIN / USE W-287058900111 / CO	TATA spare parts
287058903241	SUPPORT BLOCK BS6	TATA spare parts
287058903242	TOP PLATE BS6	TATA spare parts
287058903243	EXTENSION TUBE BS6	TATA spare parts
287058903244	DRIFT - W/B FRONT BUSH REMOVAL BS6	TATA spare parts
287058903245	DRIFT - W/B FRONT BUSH REMOVAL. BS6	TATA spare parts
287058903247	SLEEVE BUSH FRONT BS6	TATA spare parts
287058903248	CLAMP FRONT BS6	TATA spare parts
287058903255	SUPPORT BUSH INSTALLER	TATA spare parts
287058903256	DRIFT - BUSH INSTALLER	TATA spare parts
287058903257	STAND / INSTALL BUSH / CO	TATA spare parts
287058903258	REAR DAMPER BUSH FITMENT & REMOVAL	TATA spare parts
287058903301	PULLER / R-F WHEEL HUB / TONER RING / CO	TATA spare parts
287058903302	DRIFT / TONER RING / CO 4X2	TATA spare parts
287058903304	P-DOLLEY / CARRIER CYL ROLLER BRG	TATA spare parts
287058903305	PULLER / R-FLANGE CARRIER BRG / USE W-28	TATA spare parts
287058903306	P-DOLLEY / TUBE NEEDLE ROLLER BRG	TATA spare parts
287058903307	ASSY PULLER / TUBE NEEDLE ROLLER BRG	TATA spare parts
287058903308	P-DOLLEY / TUBE SYNTHETIC WASHER	TATA spare parts
287058903309	PINION HEIGHT SETTING GAUGE	TATA spare parts
287058903310	PINION HEIGHT MASTER BLOCK	TATA spare parts
287058903311	SIL/F186/09 - PULLER FOR SPINDLE REMOVE	TATA spare parts
287058903312	ASSY HUB PRESSING IN KNUCKLE	TATA spare parts
287058903313	REMOVE KNUCKLE BRG	TATA spare parts
287058903314	P-DOLLEY / KNUCKLE SPINDLE	TATA spare parts
287058903315	P-DOLLEY / TONNER RING	TATA spare parts
287058903316	ASSY HUB HOLDER	TATA spare parts
287058904601	PULLER/L-WISHBONE BALL JOINT / CO	TATA spare parts
287061303201	HEXAGON STEPPED BOLT M10	TATA spare parts
287061309201	WASHER EYE BOLT EURONCAP	TATA spare parts
287061603401	NYLON BUSH EYE BOLT	TATA spare parts
287061607501	RUBBER BUSH EURONCAP	TATA spare parts
287068900147ZX	CLRPRT_ASY_2-ASY 4 SPK STG WHL NONAIRBAG	TATA spare parts
287068900147ZY	CLRPRT_ASY_1-ASY 4 SPK STG WHL NONAIRBAG	TATA spare parts
287069104301	CLIP SCUFF PLATE MTG.	TATA spare parts
287069104302	PLASTIC CLIP (ITW M48-0600-02)	TATA spare parts
287069104303	PLASTIC CLIP (ITW:QF-FI-60439-00)	TATA spare parts
287069506322	SUNVISOR_WARNING_LABEL	TATA spare parts
287073502303	GLASS REAR DOOR WINDING LH	TATA spare parts
287074300104	ASSY.HINGE TAILGATE COMPLETE	TATA spare parts
287081104305	PUSH ON CLIP FOR M6 STUD	TATA spare parts
287081906306	GROMMET FOR PLP 12X16	TATA spare parts
287081906308	GROMMET FOR C/M CEN FLR DIA 16 THK 1.6	TATA spare parts
287081906309	GROMMET FOR PAINT DRAIN D20 THK0.7	TATA spare parts
287081906311	GROMMET FOR PLP CENTRE FLOOR	TATA spare parts
287081906318	GROMMET DIA16X20X1.6THK FOR CRS MBR CEN	TATA spare parts

287081906319	GROMMET DIA16X20X1.25THK FOR LONG REAR P	TATA spare parts
287081906327	GROMMET DIA14X2.3 THK FOR CONSOLE MTG RE	TATA spare parts
287081906333	PLUG BUTTON (24X20 SLOT)	TATA spare parts
287082409913	HOSE CONNECTOR ITW 6105419	TATA spare parts
287083000105	BRACKET AND OAT SENSOR ASSY	TATA spare parts
287083000111	BRACKET FOR OAT SENSOR	TATA spare parts
287083408006	PT_3.5X16_FLANGE_SCREW BS6-PH2	TATA spare parts
287085100108ZZ	CLRPART_ASSY-ROOF RAIL ASSY,RH	TATA spare parts
287088506338	T-EMBLEM,FRONT GRILL	TATA spare parts
287088704302	CLIP FOR HOOD RELEASE CABLE 7 X 12	TATA spare parts
287099506305	TAILGATE TRIM CLIP	TATA spare parts
287115100103	STARTER_MOTOR_1.4KW	TATA spare parts
287115150101	HOUSING ASSY	TATA spare parts
287115150102	DRIVE ASSY	TATA spare parts
287115150103	FRAME ASSY	TATA spare parts
287115150104	BRUSH HOLDER ASSY	TATA spare parts
287115150105	SOLENOID ASSY	TATA spare parts
287115157501	DRAIN TUBE	TATA spare parts
287115159901	THRUST BALL	TATA spare parts
287115159902	ARMATURE	TATA spare parts
287115159903	END PLATE	TATA spare parts
287115159904	THRU BOLT	TATA spare parts
287115159905	BRUSH HOLDER SCREW	TATA spare parts
287115159907	SOLENOID TERMINAL NUT M5	TATA spare parts
287115159908	BATTERY TERMINAL NUT M8	TATA spare parts
287115159909	SOLENOID SCREW	TATA spare parts
287115159910	SEAL	TATA spare parts
287130107702	COVER (FOR ACCELERATOR PEDAL)	TATA spare parts
287130107704	SEPERATOR FOR ACC. CABLE M/S.ITW	TATA spare parts
287131601622	SEALING RIVET	TATA spare parts
287131601622_NIU1	SEALING RIVET	TATA spare parts
287132100107	ASSY. REAR PIVOT BUSH (FRONT SUSP.)	TATA spare parts
287132100122	ASSY. REAR PIVOT BUSH (FRONT SUSP.)	TATA spare parts
287140100113	ASSEMBLY WHEEL RIM COVER (13 INCH) - POL	TATA spare parts
287140100146	ASSY WHEEL RIM COVER 13 INCH VISTA REFRE	TATA spare parts
287140106510	WHEEL NUT	TATA spare parts
287140106705	WHEEL MOUNTING BOLT - FRONT (SUNDRAM FA	TATA spare parts
287142100115	ASSY CALIPER LH (C51) DP23 PAD	TATA spare parts
287142100116	ASSY CALIPER RH (C51) .-DP23 PAD	TATA spare parts
287142807703	CLAMP FOR SINGLE BRAKE PIP	TATA spare parts
287142807709	CLAMP (FOR 3-BRAKE PIPES)	TATA spare parts
287142807710	SEPERATOR (FOR 4-BRAKE PIPES)	TATA spare parts
287142807711	CLAMP (FOR SINGLE BRAKE PIPE)	TATA spare parts
287142807711_NIU1	CLAMP (FOR SINGLE BRAKE PIPE)	TATA spare parts
287142807712	CLAMP (FOR 2-BRAKE PIPES)	TATA spare parts
287142807713	CLAMP (BRAKE & FUEL PIPES)	TATA spare parts
287142807713_NIU01	CLAMP (BRAKE & FUEL PIPES)	TATA spare parts

287142807715	CLAMP (VACUUM HOSE)	TATA spare parts
287142807720	CLAMP FOR 5-BRAKE LINES (LHD-ABS) M/S.IT	TATA spare parts
287142809912	SHIM	TATA spare parts
287142990103	KIT - SHOE HOLD DOWN	TATA spare parts
287142990104	KIT - LEVER ASSY - LH	TATA spare parts
287142990105	KIT - LEVER ASSY. RH	TATA spare parts
287142990113	KIT - W/CYL (MINOR)	TATA spare parts
287142990115	M C KIT MINOR	TATA spare parts
287142990117	KIT SERVO BS4	TATA spare parts
287142990132	ADJUSTER ASSY. - LH	TATA spare parts
287142990133	ADJUSTER ASSY. - RH	TATA spare parts
287142990149	WHEEL CYL. ASSY. - LH 17.46MM	TATA spare parts
287142990150	WHEEL CYL. ASSY-RH-17.46MM	TATA spare parts
287142990151	WHEEL CYL. ASSY. - LH	TATA spare parts
287142990152	WHEEL CYL. ASSY. - RH	TATA spare parts
287142990156	KIT CALIPER (MAJOR)	TATA spare parts
287142990157	KIT CALIPER (MINOR)	TATA spare parts
287142990158	KIT PAD ASSY	TATA spare parts
287142990159	KIT SLIDING PIN	TATA spare parts
287142990160	KIT CALIPER (MAJOR)	TATA spare parts
287142990161	KIT CALIPER (MINOR)	TATA spare parts
287142990162	KIT PAD ASSY	TATA spare parts
287142990175	KIT-PAD ASSY WITH SHIM	TATA spare parts
287142993706	CARRIER MACHINING	TATA spare parts
287142993709	CARRIER MACHINING	TATA spare parts
287142994304	ANTI RATTLE CLIP	TATA spare parts
287142994305	ANTI RATTLE CLIP	TATA spare parts
287142994305_niu1	ANTI RATTLE CLIP	TATA spare parts
287142997501	GROMMET	TATA spare parts
287142997502	GROMMET	TATA spare parts
287142997701	DUST CAP	TATA spare parts
287142997806	SEAL FLUID TANK BS6	TATA spare parts
287142998005	BLEED SCREW	TATA spare parts
287142998201	KIT PAD ASSY	TATA spare parts
287142998702	SPRING ADJUSTER	TATA spare parts
287142998704	SPRING ABUTMENT	TATA spare parts
287142998803	BLEED SCREW	TATA spare parts
287142999205	SPRING WASHER - FOR BUNDY TUBE	TATA spare parts
287144806301	PLASTIC CLAMP	TATA spare parts
287146603203	BOLT	TATA spare parts
287146604801	DOWEL PIN POWER STEERING PIN	TATA spare parts
287146606801	PRESSURE PORT CONNECTOR	TATA spare parts
287146607721	ABS SDE SEPERATOR CLAMP FOR SUCTION & RE	TATA spare parts
287146607803	O RING (PR.PORT CONNECTOR)	TATA spare parts
287146607804	O RING (SUCTION CONNECTOR)	TATA spare parts
287146608701	SPRING	TATA spare parts
287147100184	ASSY CARBON CANISTER	TATA spare parts

287147100203	FUEL FILLER CAP ONE WAY	TATA spare parts
287147100204	FUEL CAP DUAL VENTED	TATA spare parts
287147100219	UFI'S FUEL FILTER SUITABLE FOR 7.89 QFC	TATA spare parts
287147107704	FUEL FILTER BRACKET	TATA spare parts
287147107720	O-RING GASOLINE-DELPHI	TATA spare parts
287147109906	TANK PRESSURE VALVE (M/S.PADMINI)	TATA spare parts
287147109907	LOCKING RING INTANK PUMP	TATA spare parts
287147607719	.CANISTER VENT LINE CLAMP	TATA spare parts
287147607720	FUEL LINE CLAMP (10X22 TUBE) BS6-PH2	TATA spare parts
287147607721	CLAMP (PRIMING PUMP)	TATA spare parts
287147607722	PLASTIC CLAMP(ON FILTER SDE)	TATA spare parts
287147607726	FUEL LINE CLAMP	TATA spare parts
287149207703	RUBBER HANGER	TATA spare parts
287154206301	12V_POWER_SOCKET_CAP	TATA spare parts
287154206301_niu1	12V_POWER_SOCKET_CAP	TATA spare parts
287154209903	AMBIENT_TEMPERATURE_SENSOR_M S_SIEMENS	TATA spare parts
287154209923	BUZZER CT 12V - MINDA	TATA spare parts
287154209930	BODY CONTROL MODULE	TATA spare parts
287154209931	VEHICLE SPEED SENSOR	TATA spare parts
287154209996	VEHICLE SPEED SENSOR BS4	TATA spare parts
287154406322	CATCHER HEADLAMP 5TH LOCATOR	TATA spare parts
287154409930	GLOVE BOX LAMP	TATA spare parts
287154409932	LOAD_AREA_LAMP	TATA spare parts
287154409948	SPRING_CLIP_212BA_M/S_SPIRNG_INDIA	TATA spare parts
287154500123	ASSY. IGNITION SWITCH BS1/3/4	TATA spare parts
287154509904	GLOVE_BOX_LAMP_SWITCH	TATA spare parts
287154509906	STOP LIGHT SWITCH -2C/O NO&NC FIAT	TATA spare parts
287154609944	LAMBDA_SENSOR_CLIP_ON_FEM	TATA spare parts
287154609947	SEPARATOR_CLAMP_FOR_BLOW_PIPE_AND_BAT	TATA spare parts
287154800104	KIT EXTERNAL ANTENNA M/S NIPPON	TATA spare parts
287154800105	ASSY_ANTENNA_DUMMY_CAP	TATA spare parts
287154800108	SPEAKER_FRONT_DOOR	TATA spare parts
287154800109	SPEAKER_WITH_TWEETER_REAR_DOOR	TATA spare parts
287154806303	SPEAKER CATCHER	TATA spare parts
287154809901	EXTERNAL_ANTENNA_BASE_M/S_NIPPON	TATA spare parts
287154809902	EXTERNAL_ANTENNA_ROD_M/S_NIPPON	TATA spare parts
287155106359	MASCOT PLUS	TATA spare parts
287158900675	FLYWHEEL LOCKING PIN	TATA spare parts
287158900701	ADAPTOR - CHECKING ENGINE COMPRESSION	TATA spare parts
287158902501	MANDREL FOR CLUTCH DISC ALIGNMENT#(FOR F	TATA spare parts
287168206323	FIB.GL.BUTYL PAD-1.6X30X30	TATA spare parts
287169106352	OMEGA CLIP	TATA spare parts
287169506301	GRAB HANDLE (BASE)	TATA spare parts
287169506301AQ	LINEN-GRAB HANDLE (BASE)	TATA spare parts
287169506301B6	GRAB HANDLE (BASE)	TATA spare parts
287172300101	ASSY.DOOR LOCK LH	TATA spare parts
287172300102	ASSY.DOOR LOCK RH	TATA spare parts

287172300105	ASSY.INR HANDLE COMPL FRT DR LH	TATA spare parts
287172300106	ASSY.INR HANDLE COMPL FR DR RH	TATA spare parts
287172300116	ASSY.DOOR HANDLE OUTER LH (BASE)	TATA spare parts
287172300117	ASSY.DOOR HANDLE OUTER RH (BASE)	TATA spare parts
287172306307	LONG REVERSE LOCK NUT(FOR INNER HANDLE	TATA spare parts
287172308005	SOCKET HEADED M6 SPECIAL BOLT FOR FENDER	TATA spare parts
287181100102	ASSY REAR VIEW MIRROR INNER (PLAIN)	TATA spare parts
287181100102C7	GRANIT_BLACK-ASSY REAR VIEW MIRROR INNER	TATA spare parts
287181100105	ASSY.KEY (WITH TAG)	TATA spare parts
287181105902	KEY BLANK WITHOUT TRANSPONDER	TATA spare parts
287181106303	HINGE CLIP SUNVISOR	TATA spare parts
287181106338	T EMBLEM TAILGATE	TATA spare parts
287181106340	STAY ROD CLIP (ITW)	TATA spare parts
287181106342	MASCOT FOR TATA	TATA spare parts
287182400112	WASHER BOTTLE 3.5L WITH 2 PUMP AND BKT	TATA spare parts
287182400126	ASSY WASHER NOZZLE WITH ADAPTER	TATA spare parts
287182406301	WASHER BOTTLE FILLER NECK	TATA spare parts
287182406306	EDGE_CLAMP_FOR_WASHER_BOTTLE_FILLER_HC	TATA spare parts
287182406310	T JOINT FOR WASHER TUBE	TATA spare parts
287182409901	1.5LTR WASHER BOTTLE	TATA spare parts
287182409905	WASHER_PUMP	TATA spare parts
287182409906	WASHER NOZZLE ASSY	TATA spare parts
287182409907	PUMP SEAL	TATA spare parts
287182409908	NOZZLE ADAPTER	TATA spare parts
287183400150	ASSY ACTUATOR MOTOR FOR AIR & TEMP MODE	TATA spare parts
287183400182	SCROLL COMPRESSOR (QS70) FIAT SDE BS3/4	TATA spare parts
287183606309	HEATER HOSE ITW CLAMP	TATA spare parts
287183606311	HOSE CLIP ROTATABLE FOR SDE DISCHARGE PI	TATA spare parts
287188600101	ASSY.REAR BUMPER COMPLETE (STD)	TATA spare parts
287191000188	BEZEL HR ACTIVE (EBONY)	TATA spare parts
287191000190	BEZEL HR PASSIVE (EBONY)	TATA spare parts
287199008005	OFFER DWG M8X1.25X20 PAN HEAD SCREW	TATA spare parts
287199504301	NON RETURNABLE SPRING CLIP (TAPS HAG 206	TATA spare parts
287199504302	NON RETURNABLE SPRING CLIP	TATA spare parts
287199506301	TRIM CLIP (ITW)	TATA spare parts
287199506303	ASSY PIN GROMMET DIA6.5	TATA spare parts
287199506310	TRIM CLIP (ITW)	TATA spare parts
287199706303	RUBBER-GROMMET-(HOLE-35-DIA)	TATA spare parts
287199706308	HOLE PLUG DIA 10	TATA spare parts
287199706309	HOLE PLUG HOLE(20X25)	TATA spare parts
287199706310	HOLE PLUG DIA20	TATA spare parts
287199706314	RUBBER GROMMET (DIA 30)	TATA spare parts
287199706315	HOLE PLUG DIA 5	TATA spare parts
287215100102	STARTER MOTOR	TATA spare parts
287215109902	FLY LEAD-185MM-STARTER SOLENOID	TATA spare parts
287215109903	FLY LEAD 155 MM-STARTER +VE	TATA spare parts
287215109904	SOLENOID SW ASSY	TATA spare parts

287215109905	FIXING BKT ASSY	TATA spare parts
287215109906	DRIVE ASSY (26245134)	TATA spare parts
287242800101	CAMSHAFT DRIVEN VACUUM PUMP-VAPEC19S-	TATA spare parts
287242800124	VACUUM RESERVOIR (ACCUMULATOR)	TATA spare parts
287242805823	HOSE-FROM EVRV(FOR EGR) TO EGR VALVE	TATA spare parts
287242807801	O-RING (VACUUM PUMP-1.4L)	TATA spare parts
287243700101	ONE WAY CHECK VALVE	TATA spare parts
287247100113	ASSY FUEL TANK SCREW CAP	TATA spare parts
287247100115	ASSY FUEL TANK SCREW CAP (2 WAY)	TATA spare parts
287249205301	GASKET	TATA spare parts
287254109901	BATTERY DIN55 BOTTOM HOLD M/S EXIDE	TATA spare parts
287254509902	CLUTCH SWITCH	TATA spare parts
287254608212	CLAMP AC CLUTCH CONNECTOR MTG RHD	TATA spare parts
287315400101	ALTERNATOR 12V 120A W/O VP	TATA spare parts
287315400102	ALTERNATOR 12V 117A W/VP	TATA spare parts
287347506830	DEAD PLUG	TATA spare parts
287347509907	GAS CYLINDER	TATA spare parts
287354200101	ASSY BODY CONTROL MODULE M/S ED	TATA spare parts
287354209910	EXPRESS DOWN CONTROLLER	TATA spare parts
287383400114	ASSY THERMISTER REAR AC	TATA spare parts
287447608201	P CLAMP	TATA spare parts
287454400110	SPARE_BULB_KIT	TATA spare parts
287469506307	GRAB HANDLE	TATA spare parts
287469506307AQ	GRAB HANDLE WITHOUT COAT HOOK	TATA spare parts
287469506307CC	GRAB HANDLE WITHOUT	TATA spare parts
287499506301	RIB LOCK CLIP (ITW)	TATA spare parts
287499506304	SERVICABLE CLIP CARPET MTG (ARAYMOND)	TATA spare parts
287499506314	PIN GROMMET 7X7 BS6	TATA spare parts
287499706303	GROMMET (DIA-7)	TATA spare parts
287629100101	ASSY.CLUTCH BOOSTER DIA.70	TATA spare parts
287629100104	ASSY. PUSH ROD (CLUTCH BOOSTER 70 DIA.)	TATA spare parts
287629106001	CLUTCH RELEASE LEVER	TATA spare parts
287642108203	ANCHOR BRACKET RH (AUTO SLACK ADJUSTER)	TATA spare parts
287642108204	ANCHOR BRACKET LH (AUTO SLACK ADJUSTER)	TATA spare parts
287642130101	ASSY. LINED SHOE	TATA spare parts
287642300106	AUTO SLACK ADJUSTER RH(43MM OFF)	TATA spare parts
287642300107	AUTO SLACK ADJUSTER LH(43MM OFF)	TATA spare parts
287924200101	ASSY.BKT.ENGINE MTG.-LH (REAR BOTTOM)	TATA spare parts
287924200102	ASSY.BKT.ENGINE MTG.-RH (REAR BOTTOM)	TATA spare parts
287926800107	ASSY BRACKET(G.S.L.MTG)	TATA spare parts
287929100101	ASSY CLUTCH BOOSTER 3 INCH DIA	TATA spare parts
287929100101AE	CLUTCH BOOSTER 2523	TATA spare parts
287929100107	ASSY. CLUTCH PIPE (MASTER CYL. TO ASSY.	TATA spare parts
287929100115	ASSY. HOSE CLUTCH	TATA spare parts
287929100115AE	ASSY. HOSE CLUTCHLPT 2523/	TATA spare parts
287929100116	ASSY.HYDRAULIC CLUTCH PIPE	TATA spare parts
287929100118	ASSY HOSE CLUTCH	TATA spare parts



287929107101	SPACER PLATE	TATA spare parts
287930100102	ASSY PULL CABLE ACCELERATOR	TATA spare parts
287930100103	ASSY.ACCELERATOE BRACKET	TATA spare parts
287930100104	ASSY PEDAL LEVER ACCELERATOR-LHD	TATA spare parts
287930100105	ASSY PULL CABLE - ACCELERATOR	TATA spare parts
287930107101	SPRING BRACKET	TATA spare parts
287930200102	ASSY.PULL CABLE ENGINE STOP	TATA spare parts
287930200103	ASSY PULL CABLE - ENGINE STOP	TATA spare parts
287931000101	ASSY FRAME COMPLETE (SANDWICH 888)	TATA spare parts
287931000102	ASSY. FRAME COMPLETE	TATA spare parts
287931200104	ASSY.END CROSS MEMBER	TATA spare parts
287931700101	ASSY. REAR UNDERRUN PROTECTIVE DEVICE	TATA spare parts
287931700104	ASSY. BRACKET - LH RUPD MTG.	TATA spare parts
287931700105	ASSY. BRACKET - RH RUPD MTG.	TATA spare parts
287931707110	SIDE PLATE RUPD	TATA spare parts
287933000101	ASSY.FRONT AXLE COMPLETE WITH BRAKES	TATA spare parts
287933000102	ASSY FRONT AXLE COMP.WITH BRAKES	TATA spare parts
287941100103	ASSY. PROP. SHAFT FRONT (L=1245)	TATA spare parts
287941100103AE	ASSY PROPELLER SHAFT FRT 2523	TATA spare parts
287941109901	¿FLANGE YOKE	TATA spare parts
287941109902	ASSY. CROSS? BS3/4/6	TATA spare parts
287941109903	¿COUPLING FLANGE & DUST COVER ASSY	TATA spare parts
287941109904	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
287941120103	ASSY. PROP. SHAFT REAR (L=1010)	TATA spare parts
287941120103AE	ASSY PROPELLER SHAFT REAR 2523	TATA spare parts
287941120104	ASSY. INTERAXLE PROP. SHAFT (L=665)	TATA spare parts
287941120104AE	INTER AXLE PROP SHAFT 2523	TATA spare parts
287941129901	¿LONG FORK ASSY	TATA spare parts
287941129902	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
287941129904	¿LONG FORK SUB ASSY	TATA spare parts
287941129905	CROSS ASSY	TATA spare parts
287941129906	LONG FORK SUB ASSY	TATA spare parts
287941129907	REAR HOUSING TUBE & SHORT FORK SUB ASSY.	TATA spare parts
287941303303	BRACKET (FOR CENTER BEARING)	TATA spare parts
287941308201	PROP.SHAFT GUARD	TATA spare parts
287942100105	ASSY. F/A BRAKE LH WITH D.C.	TATA spare parts
287942100109	ASSY.F/A BRAKE RH WITH D.C.	TATA spare parts
287942100113	DRUM BRAKE ASSYFRONT -LHDIA 410X180	TATA spare parts
287942100114	DRUM BRAKE ASSYFRONT -RHDIA 410X180	TATA spare parts
287942100124	FRONT BRAKE ASSEMBL L.H. (RAF-7 LINER)	TATA spare parts
287942100125	FRONT BRAKE ASSEMBLY R.H. (RAF-7 LINER	TATA spare parts
287942100143	ASSY DRUM BRAKE LH W/DC	TATA spare parts
287942100144	ASSY DRUM BRAKE RH W/DC	TATA spare parts
287942100145	BRACKET ASSY LH	TATA spare parts
287942100146	BRACKET ASSY RH	TATA spare parts
287942105101	CAM SHAFT LH	TATA spare parts
287942105102	CAM SHAFT RH	TATA spare parts

287942108201	ANCHOR BRACKET LH FOR FRONT BRAKE	TATA spare parts
287942108202	ANCHOR BRACKET RH FOR FRONT BRAKE	TATA spare parts
287942109901	FITTING GREASE	TATA spare parts
287942300150	ASSY REAR BRAKE RH WITH D/C	TATA spare parts
287942300154	ASSY REAR BRAKE LH WITH D/C.	TATA spare parts
287942300170	ASSY FABRICATED CHAMBER MTG BKT LH	TATA spare parts
287942300171	ASSY FABRICATED CHAMBER MTG BKT RH	TATA spare parts
287942300177	ASSY.CHAMBER MOUNTING BRACKET LH.	TATA spare parts
287942300178	ASSY.CHAMBER MTG. BRACKET RH.	TATA spare parts
287942300179	REAR BRK ASSY. RH WITH D/C	TATA spare parts
287942300185	REAR BRAKE LH WITH D/C	TATA spare parts
287942300191	SLACK ADJUSTER LH 76 OFFSET 160 CD BS3/4	TATA spare parts
287942300192	SLACK ADJUSTER RH 76 OFFSET 160 CD BS3/4	TATA spare parts
287942300202	ASSY CHAMBER MOUNTING BRACKET LH.	TATA spare parts
287942300203	ASSY.CHAMBER MOUNTING BRACKET RH.	TATA spare parts
287942300271	R/A BRAKE W/DC-LH NA1707	TATA spare parts
287942300272	R/A BRAKE W/DC-RH NA1707	TATA spare parts
287942303704	BRKT ASSY LH	TATA spare parts
287942303705	BRKT ASSY RH	TATA spare parts
287942308223	ANCHOR BRACKET LH	TATA spare parts
287942308224	ANCHOR BRACKET RH.	TATA spare parts
287942308227	ANCHOR BRACKET	TATA spare parts
287942308236	ANCHOR BRACKET LH	TATA spare parts
287942308237	ANCHOR BRACKET RH	TATA spare parts
287942308240	ANCHOR BRACKET LH.	TATA spare parts
287942308243	ANCHOR BRACKET RH	TATA spare parts
287942308244	SHIM-PLUMMER BLOCK	TATA spare parts
287942309902	KIT SPRING BS6	TATA spare parts
287942990103	CAM SHAFT LH	TATA spare parts
287942990110	CAM SHAFT RH	TATA spare parts
287942990117	KIT - TORQUE PLATE	TATA spare parts
287942990120	KIT-CAMSHAFT LH BS6	TATA spare parts
287942990121	CAMSHAFT LH	TATA spare parts
287942990122	CAMSHAFT RH	TATA spare parts
287942990123	KIT-CAMSHAFT RH BS6	TATA spare parts
287942990124	KIT-BRAKE DUST SHIELD	TATA spare parts
287942990125	KIT-BRAKE BUSH BS6	TATA spare parts
287942995109	CAM SHAFT LH	TATA spare parts
287942995110	CAM SHAFT RH	TATA spare parts
287942999201	SLEEVE LH	TATA spare parts
287942999202	SLEEVE RH	TATA spare parts
287943200102	SUB.ASSY.AIR TANK (15 LTR)	TATA spare parts
287943200110	AIR TANK ASSY 30LTRS WITH PTC(280/150)	TATA spare parts
287943700116	FOOT BRAKE VALVE VOSS 74.5MM	TATA spare parts
287943700118	AIR TANK 30 LTRS (VOSS+METRIC)-320/80	TATA spare parts
287943700123	RELAY VALVE (VOSS+VOSS)	TATA spare parts
287943700124	SPRING BRAKE ACTUATOR-TYPE24(V+V)	TATA spare parts

287943700125	SPRING BRAKE ACTUATOR (T-24/24)	TATA spare parts
287943700127	SPRING BRAKE ACTUATOR	TATA spare parts
287943700130	SPRING BRAKE ACTUATOR TYPE 24/24 BS2/3/4	TATA spare parts
287943906801	T-SOCKET	TATA spare parts
287943906802	T SOCKET	TATA spare parts
287943906803	SEALING PLUG M10X1	TATA spare parts
287943908203	BRACKET FOR PRESSURE REDCTION VALVE	TATA spare parts
287943909901	BRACKET-FOR LCRV MOUNTING (LPT 2523)	TATA spare parts
287943910102	ASSY NYLON PIPE CHASSIS BUNCH-LPT2523	TATA spare parts
287943910103	ASY METAL PIPE FR COMP OUTLET TO INT JT1	TATA spare parts
287943910104	ASSY METAL PIPE JOINT-1 TO JOINT-2	TATA spare parts
287943910105	ASY METAL PIPE JOINT-2TO AIR DRIER INLET	TATA spare parts
287943910109	ASSY NYLON PIPE CHASSIS BUNCH-LPT2523	TATA spare parts
287943910110	ASSY NYLON PIPE BUNCH CHASSIS	TATA spare parts
287946100101	ASSEMBLY BRACKET(AUX WATER TANK MTG)	TATA spare parts
287946100102	ASSY. STEERING GEAR BOX BRACKET	TATA spare parts
287946305101	PITMAN ARM	TATA spare parts
287946600101	ASSY. POWER STEERING GEAR BOX EURO2	TATA spare parts
287946800115	ASSY. HOSE SUCTION LINE (TANK TO PUMP)	TATA spare parts
287946800116	ASSY. HOSE PRESSURE LINE(PUMP TO G/BOX)	TATA spare parts
287946800117	ASSY. RETURN LINE-1 (G/BOX TO TANK)	TATA spare parts
287946800118	ASSY. RETURN LINE-2 (1ST JOINT TO TANK)	TATA spare parts
287946800121	ASSY. KIT FOR HYD. STG. PIPELINE	TATA spare parts
287947100101	ASSY. FUEL TANK COMPLETE 350 LTR	TATA spare parts
287947600106	ASSY. SUCTION LINE	TATA spare parts
287947600107	ASSY. RETURN LINE	TATA spare parts
287949100102	ASSY. BRACKET	TATA spare parts
287949100106	ASSY. BRACKET	TATA spare parts
287949100107	ASSY STAY ROD	TATA spare parts
287949100108	ASSY. MUFFLER	TATA spare parts
287949100109	ASSY. BRACKET	TATA spare parts
287949100110	ASSY. BRACKET	TATA spare parts
287949107108	BRACKET	TATA spare parts
287949108217	SHIELD	TATA spare parts
287949108219	CLAMP	TATA spare parts
287949108221	BRACKET	TATA spare parts
287949108223	BRACKET FOR BATTERY CABLE MTG.	TATA spare parts
287949200112	ASSY EXHAUST PIPE	TATA spare parts
287949200114	ASSY. EXHAUST PIPE	TATA spare parts
287949200115	ASSY. EXHAUST PIPE	TATA spare parts
287949200118	ASSY. EXHUAST PIPE	TATA spare parts
287949200123	ASSY FIRST PIPE	TATA spare parts
287949200124	ASSY. BRACKET (SUPPORT FROM ENG. BLOCK)	TATA spare parts
287949200128	ASSY EXHAUST PIPE (AFTER EXHAUST BRAKE)	TATA spare parts
287949208224	CLAMP	TATA spare parts
287949208226	CLAMP	TATA spare parts
287949208227	BRACKET	TATA spare parts

287954249901	SPEEDOMETER 1:0.935 (BACKLIT)	TATA spare parts
287954620101	W/H MAIN LPT 2523 TC E-II SA	TATA spare parts
287954620102	W/H ENGINE LPT 2523 TC E-II SA	TATA spare parts
287954620103	W/H TAIL LPT 2523 TC E-II	TATA spare parts
287954620103AE	WIRING HARNESS TAIL 2523	TATA spare parts
287954620105	W/H MAIN LPT 2523 TC E-II LHD	TATA spare parts
287954620105AE	WIRING HARNESS MAIN 2523	TATA spare parts
287954620107	W/H ENGINE	TATA spare parts
28800142000R40	PARTIAL FITTED CABIN W/O FITMENT	TATA spare parts
28800242000RCK	CABIN KIT FOR PRIMA 5038.S EURO3	TATA spare parts
288024000105	REBOUND RING ENG MTG RR	TATA spare parts
288024000105AE	REBND RING MTG LPTA1628/LPTA1828	TATA spare parts
288024103201	CAP SCREW 12 POINT M12X45	TATA spare parts
288024103701	ENG MTG BRKT FRT ENG LH	TATA spare parts
288024103702	ENG MTG BRKT FRT ENG RH	TATA spare parts
288024103710	ENG MTG BRKT FRT FRAME LH	TATA spare parts
288024103711	ENG MTG BRKT FRT FRAME RH	TATA spare parts
288024107101	LOCK PLATE-ENG MTG FRT	TATA spare parts
288026800114	HORIZONTAL GEAR SHIFT UNIT ASSY	TATA spare parts
288026800114AE	HRZNTAL GR SHIFT UNIT ASSY -1628	TATA spare parts
288026800115	GEAR SELECT CABLE COMP.	TATA spare parts
288026800115AE	ASSY SELECTION CABLE 1628	TATA spare parts
288026800116	ASSY. GEAR SHIFT CABLE BS3	TATA spare parts
288026800116AE	ASSY SHIFT CABLE 1628	TATA spare parts
288026800118	ASSY GEARSHIFT UNIT WITH CABLES	TATA spare parts
288026800122	ASSY FIREWALL BRACKET	TATA spare parts
288026800124	ASSY CLAMP	TATA spare parts
288026800125	LEVER-UJ ASSEMBLY	TATA spare parts
288026800126	SELECT ARM ASSEMBLY	TATA spare parts
288026800129	ASSY GEARSHIFT KNOB	TATA spare parts
288026800129AE	ASSY GEARSHIFT KNOB 1628 1828	TATA spare parts
288026800138	GEAR SHIFT LEVER KNOB ASSY BS6-PH2	TATA spare parts
288026800139	GEAR SHIFT KNOB ASSY BS6	TATA spare parts
288026801606	GEAR SHIFT LEVER KNOB ASSY	TATA spare parts
288026803203	BOLT-ALLEN M4X10	TATA spare parts
288026803704	BRACKET(SELECT AND SHIFT)	TATA spare parts
288026803802	TOP COVER EXTENSION	TATA spare parts
288026803803	TOP COVER	TATA spare parts
288026804301	RETAINER CLIP	TATA spare parts
288026806002	SHIFTER LEVER	TATA spare parts
288026806003	SELECTION LEVER	TATA spare parts
288026806302	SHEATHING	TATA spare parts
288026806803	CONNECTOR QUICK BS6	TATA spare parts
288026807704	RUBBER BELLOW (CONSOLE)	TATA spare parts
288026807705	RUBBER FOR ASSY FIREWALL BRACKET	TATA spare parts
288026807706	RUBBER FOR ASSY. FIREWALL BRACKET	TATA spare parts
288026807707	RUBBER FOR ASSY. FIREWALL BKT.	TATA spare parts

288026808220	ANGLE PLATE(CABLE CLAMP)	TATA spare parts
288026808221	BOTTOM COVER	TATA spare parts
288026808224	L- TYPE BRACKET	TATA spare parts
288026808225	DOUBLE CLAMP (CABLE CLAMPING)	TATA spare parts
288026808701	SPRING	TATA spare parts
288029000103	ASSY. CLUTCH BOOSTER BS3	TATA spare parts
288029000103AE	ASSY. CLUTCH BSTER-1628-1828	TATA spare parts
288029000108	INTEGRATED PEDAL UNIT	TATA spare parts
288029100103	ASSY. PIPE COMPLETE FROM MASTER CYLINDER	TATA spare parts
288029100105	CLUTCH PEDAL ASSEMBLY	TATA spare parts
288029200103	BRAKE PEDAL ASSEMBLY	TATA spare parts
288029300101	KIT-MASTER CYLINDER MINOR	TATA spare parts
288029300102	KIT-MASTER CYLINDER MAJOR	TATA spare parts
288029300105	KIT-PEDAL LEVERS	TATA spare parts
288029300107	CLUCTH MASTER CYLINDER ASSY	TATA spare parts
288029308702	SPRING	TATA spare parts
288030100103	ASSY. ACCELERATOR PEDAL UNIT -RHD BS3/4	TATA spare parts
288030100103AE	ASSY ACCLRTR PEDAL -1628-1828	TATA spare parts
288030104901	SENSOR-134143	TATA spare parts
288031000101	ASSY. FRAME LPS4938 WITH ISLE ENG	TATA spare parts
288031000104	FRAME ASSY	TATA spare parts
288031000105	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
288031107103	REINFORCEMENT LH	TATA spare parts
288031107104	REINFORCEMENT RH	TATA spare parts
288031200101	ASSY CROSS MEMBER 1ST	TATA spare parts
288031200102	ASSY CROSS MEMBER CAB REAR	TATA spare parts
288031200104	ASSEMBLY ALLIGATED CROSS MEMBER	TATA spare parts
288031200104AE	ASSY. ALLIGATED CRSS MEMBR -1628	TATA spare parts
288031200108	ASSEMBLY CROSS MEMBER PROP SHAFT	TATA spare parts
288031200110	ASSY CTR CROSS MEMBER WITH GUSSETS	TATA spare parts
288031200111	END CROSS MEMBER	TATA spare parts
288031207101	CROSS MEMBER FIRST W/O GUSSET	TATA spare parts
288031207102	CROSS MEMBER CTR	TATA spare parts
288031207103	CAB REAR CROSS MEMBER	TATA spare parts
288031207106	CROSS MEMBER PROP SHAFT	TATA spare parts
288031207107	ALLIGATED CROSS MEMBER UPPER	TATA spare parts
288031300105	ASSY GUSSET CAB REAR	TATA spare parts
288031307101	GUSSET TYPE 1 FRONT CROSS MEMBER	TATA spare parts
288031307102	GUSSET TYPE 2 FRONT CROSS MEMBER	TATA spare parts
288031307105	GUSSET - CTR UPR LH	TATA spare parts
288031307106	GUSSET-CTR LWR LH	TATA spare parts
288031307107	GUSSET - CTR UPR RH	TATA spare parts
288031307108	GUSSET-CTR LWR RH	TATA spare parts
288031307116	GUSSET UPPPER-ALLIGATED CROSSMEMBER	TATA spare parts
288031307117	GUSSET LOWER-ALLIGATED CROSS MEMBER	TATA spare parts
288031307123	FRT ENG MTG C/M BKT	TATA spare parts
288031700104	ASSY TOW PIN	TATA spare parts

288031700107	ASSEMBLY OF PIPE STRUCTURE FOR FOOTSTEPS	TATA spare parts
288031700110	ASSEMBLY OF FOOTSTEP STRUCTURE & COVER	TATA spare parts
288031700112	ASSY BRACKET	TATA spare parts
288031700113	ASSY OF STRIP FOR FOOTSTEP COVER	TATA spare parts
288031700119	ASSEMBLY FOR SHIELD UNDER ENGINE	TATA spare parts
288031703702	TOWING HOOK (DETACHABLE) BRACKET RH	TATA spare parts
288031703704	TOW HOOK MOUNTING BRACKET (RH)	TATA spare parts
288031703705	TOW HOOK MOUNTING BRACKET (LH)	TATA spare parts
288031705101	TOW HOOK YOKE	TATA spare parts
288031707701	RUBBER LATCH	TATA spare parts
288031707703	SHIELD UNDER FLYWHEEL	TATA spare parts
288031707705	LID FOR SHIELD UNDER ENGINE	TATA spare parts
288031707706	FOOTSTEP COVER	TATA spare parts
288031707709	SHIELD UNDER ENGINE	TATA spare parts
288031708201	BRACKET FOR NOISE SHIELD	TATA spare parts
288031708204	SHIELD MOUNTING BRACKET	TATA spare parts
288031708208	BRACKET FOR NOISE SHIELD	TATA spare parts
288031708210	BRACKET FOR NOISE SHIELD	TATA spare parts
288032100103	ASSLY.FRONT SPRING	TATA spare parts
288032103201	CENTER BOLT M16X1.5X170	TATA spare parts
288032103301	SPRING HANGER BRACKET FRONT	TATA spare parts
288032400107	V-ROD ASSY BS6	TATA spare parts
288032400109	TORQUE ROD ASSY	TATA spare parts
288032400110	V-ROD ASSY BS6	TATA spare parts
288032400118	LEAF SPRING ASSY REAR BS6	TATA spare parts
288032400130	ASSEMBLY - REAR TANDEM SUSPENSION	TATA spare parts
288032400132	ASSEMBLY TRUNNION SUPPORT	TATA spare parts
288032400133	LEAF SPRING ASSY WITH TRUNNION HSG BS6	TATA spare parts
288032400134	ASSEMBLY LEAF SPRING	TATA spare parts
288032400135	ASSY. RUBBER BOLSTER SPRING BS2/3/4	TATA spare parts
288032400135DF	RUBBER BOLSTER-TATA HENDRICKSON BOGIE SU	TATA spare parts
288032400137	CAP END CLOSURE & SEAL ASSY. 178 OD	TATA spare parts
288032400138	LINK TORQUE ROD	TATA spare parts
288032400139	LINK ASSEMBLY - TORQUE ROD	TATA spare parts
288032400140	BUSH_PIN ASSEMBLY (TORQUE ROD)	TATA spare parts
288032400142	LINK ASSEMBLY - V ROD	TATA spare parts
288032400148	ASSY. BUSH CENTRE BS3	TATA spare parts
288032400149	ASSY ADAPTOR PLATE (V ROD)	TATA spare parts
288032400155	ASSY. TRUNNION TML SUSPENSION BS3/4	TATA spare parts
288032400157	PIVOT HSG ASSEMBLY-TML SUSPENSION	TATA spare parts
288032400167	SPRING ASSEMBLY-TML SUSPENSION	TATA spare parts
288032400170	BOLSTER TML SUSPENSION BS3/4	TATA spare parts
288032400170DF	RUBBER BOLSTER - TML BOGIE SUSPENSION	TATA spare parts
288032400172	ASSY. TORQUE ROD-TML SUSPENSION BS3/4	TATA spare parts
288032400173	ASSY. V-ROD TML SUSPENSION BS3/4	TATA spare parts
288032400179	SPRING ASSY-TML SUSP-LPS4930	TATA spare parts
288032400181	ASSY PIVOT HSG-LPS4930	TATA spare parts

288032400189	REPAIR KIT-BUSH PIN BS3/4	TATA spare parts
288032400190	REPAIR KIT-CENTER BUSH V ROD BS3/4	TATA spare parts
288032403207	CENTER BOLT	TATA spare parts
288032403208	HEX. BOLT M10	TATA spare parts
288032403213	CENTER BOLT BS6	TATA spare parts
288032403217	HEX FL.BOLT M14X2X170	TATA spare parts
288032403219	HEX.BOLT M16X2X70-10 ZINC PLATING	TATA spare parts
288032403225	CENTRE BOLT-SPRING ASSEMBLY	TATA spare parts
288032403229	SPRING ASSY CENTER BOLT-LPS4930	TATA spare parts
288032403401	TRUNNION BUSH (26 TON) BS2/3/4	TATA spare parts
288032403402	TRUNNION BUSH	TATA spare parts
288032403405	TRUNNION BUSH¿ LFX-QUADRANT	TATA spare parts
288032403701	BRACKET V-ROD MTG	TATA spare parts
288032403702	BRACKET ARTICULATION STOPPER	TATA spare parts
288032403704	AXLE CLAMP UPPER (HR210 AXLE)	TATA spare parts
288032403705	PIVOT HOUSING (TRUNNION)	TATA spare parts
288032403706	BRACKET VROD MTG (ON CHASSIS)	TATA spare parts
288032403707	AXLE STOPPER	TATA spare parts
288032403709	GUIDE PLATE (UBOLT-REAR)	TATA spare parts
288032403716	ADAPTOR PLATE (V ROD)	TATA spare parts
288032403718	TRUNNION BRACKET BS3/4	TATA spare parts
288032403719	V-ROD MTG. BKT ON FRAME-TML SUSPENSION	TATA spare parts
288032403721	PIVOT HOUSING BRACKET	TATA spare parts
288032403722	GUIDE PLATE-TML SUSPENSION	TATA spare parts
28803240374750	TORQUE ROD MTG. BOTTOM LH FWD	TATA spare parts
28803240374950	TORQUE ROD MTG. BOTTOM RH FWD	TATA spare parts
288032403751	ARTICULATION STOPPER STEEL CASTING	TATA spare parts
28803240375350	BRACKET RUBBER BOLSTER MTG RH	TATA spare parts
28803240375750	BRACKET RUBBER BOLSTER MTG LH FWD	TATA spare parts
288032403766	TRUNN. HOUSING REVERSE U BOLT(TML SUSP)	TATA spare parts
288032403767	GUIDE PLATE	TATA spare parts
288032403777	GUIDE PLATE BS6	TATA spare parts
288032404201	U BOLT - REAR	TATA spare parts
288032404202	SPRING CLIP (LEAF SPRING - REAR)	TATA spare parts
288032404203	U-BOLT(M24)-TML SUSPENSION	TATA spare parts
288032404208	SPRING CLIP -TML SUSPENSION(NAMASKAR)	TATA spare parts
288032404209	SPRING CLIP-TML SUSPENSION	TATA spare parts
288032404211	U-BOLT REAR	TATA spare parts
288032404212	SPRING CLIP	TATA spare parts
288032404214	U-BOLT REAR BS6	TATA spare parts
288032404301	CIRCLIP - EYE END (TORQUE ROD)	TATA spare parts
288032404302	EXTERNAL CIRCLIP	TATA spare parts
288032404303	INTERNAL CIRCLIP	TATA spare parts
288032404306	EXTRNAL CIRCLIP 128X4 N IS 3075(PART 1)	TATA spare parts
288032404801	SPRING DOWEL BS6	TATA spare parts
288032404803	DOWEL (40 MM) (ADAPTOR PLATE MTG)	TATA spare parts
288032404804	DOWEL PIN 10 X 35 DIN6325	TATA spare parts

288032404805	SPRING DOWEL (HEAVY TYPE)	TATA spare parts
288032406504	NUT-M24 (REAR-U BOLT)	TATA spare parts
288032406505	HEX NUT M12X1.75-10	TATA spare parts
288032406506	NUT M10	TATA spare parts
288032406509	HEX FLANGE NUT (SELF LOCKING TYPE)	TATA spare parts
288032406513	HEX FL NUT M24X2 - 10 ISO7044	TATA spare parts
288032406702	TRUNNION PIN	TATA spare parts
288032407102	SECOND LEAF (REAR)	TATA spare parts
288032407102DF	SECOND LEAF-TATA HENDRICKSON BOGIE SUSPE	TATA spare parts
288032407103	THIRD LEAF (REAR)	TATA spare parts
288032407103DF	THIRD LEAF-TATA HENDRICKSON BOGIE SUSPEN	TATA spare parts
288032407104	FOURTH LEAF (REAR)	TATA spare parts
288032407104DF	FOURTH LEAF-TATA HENDRICKSON BOGIE SUSPE	TATA spare parts
288032407105	FIFTH LEAF (REAR)	TATA spare parts
288032407105DF	FIFTH LEAF-TATA HENDRICKSON BOGIE SUSPEN	TATA spare parts
288032407106	SIXTH LEAF-REAR	TATA spare parts
288032407107	SEVENTH LEAF (REAR)	TATA spare parts
288032407108	FIRST LEAF - REAR	TATA spare parts
288032407108DF	MAIN LEAF-TATA HENDRICKSON BOGIE SUSPENS	TATA spare parts
288032407109	FIRST LEAF BS3/4/6	TATA spare parts
288032407110	SECOND LEAF REAR SPRING BS3/4/6	TATA spare parts
288032407111	THIRD LEAF	TATA spare parts
288032407112	FOURTH LEAF	TATA spare parts
288032407113	FIFTH LEAF	TATA spare parts
288032407114	SIXTH LEAF	TATA spare parts
288032407115	SEVENTH LEAF	TATA spare parts
288032407116	EIGHTH LEAF	TATA spare parts
288032407117	NINTH LEAF	TATA spare parts
288032407118	TENTH LEAF	TATA spare parts
288032407119	ELEVENTH LEAF	TATA spare parts
288032407120	TWELVETH LEAF	TATA spare parts
288032407121	1ST LEAF BS6	TATA spare parts
288032407122	2ND LEAF BS6	TATA spare parts
288032407129	ARB BRACKET BOTTOM-TML SUSPENSION	TATA spare parts
288032407130	CENTER PAD REAR TML BOGIE SUSP	TATA spare parts
288032407131	SPACER PLATE-V ROD MTG BKT ON FRAME	TATA spare parts
288032407133	FIRST LEAF-TML SUSP -LPS4930	TATA spare parts
288032407134	SECOND LEAF-TML SUSP -LPS4930	TATA spare parts
288032407135	THIRD LEAF-TML SUSP -LPS4930	TATA spare parts
288032407136	FOURTH LEAF-TML SUSP -LPS4930	TATA spare parts
288032407137	FIFTH LEAF-TML SUSP -LPS4930	TATA spare parts
288032407138	SIXTH LEAF-TML SUSP -LPS4930	TATA spare parts
288032407139	SEVENTH LEAF-TML SUSP -LPS4930	TATA spare parts
288032407144	SPACER PLATE ARTICULATION STOPPER	TATA spare parts
288032407150	3RD LEAF BS6	TATA spare parts
288032407151	4TH LEAF BS6	TATA spare parts
288032407152	5TH LEAF BS6	TATA spare parts



288032407153	6TH LEAF BS6	TATA spare parts
288032407154	7TH LEAF BS6	TATA spare parts
288032407155	8TH LEAF BS6	TATA spare parts
288032407156	9TH LEAF BS6	TATA spare parts
288032407401	RIVET DIA 16 37T SPRING BS6	TATA spare parts
288032407402	RIVET SPRING CLIP BS6	TATA spare parts
288032407703	RUBBER SEAL-TRUNNION HOUSING	TATA spare parts
288032407708	SEALING GASKET	TATA spare parts
288032407801	OIL SEAL (TRUNNION HOUSING)	TATA spare parts
288032407802	DUST SEAL B165X190X12 DOUBLE LIP	TATA spare parts
288032408201	END CAP	TATA spare parts
288032408203	END CAP TRUNNION	TATA spare parts
288032408204	END CAP PIVOT HOUSING	TATA spare parts
288032408205	CAP END CLOSURE BS6	TATA spare parts
288032408301	SHIM	TATA spare parts
288032408302	SHIM	TATA spare parts
288032408303	SHIM	TATA spare parts
288032408304	SHIM-1 MM THICK	TATA spare parts
288032408305	SHIM-2 MM THICK	TATA spare parts
288032408601	SPACER	TATA spare parts
288032408602	SPACER - EYE END (TORQUE ROD)	TATA spare parts
288032408607	SPACER (LEAF SPRING CLIP)	TATA spare parts
288032409201	THRUST WASHER (BENT TABS) (TRUNNION PIN)	TATA spare parts
288032409202	THRUST WASHER (WITH TABS) (TRUNNION HOUSING)	TATA spare parts
288032409203	WASHER (SPRING CLIP-REAR)	TATA spare parts
288032409204	WASHER (M24)	TATA spare parts
288032409208	THRUST WASHER (STRAIGHT TABS)	TATA spare parts
288032409209	THRUST WASHER (BENT TABS) TRUNNION PIN	TATA spare parts
288032409901	GREASE NIPPLE M8X1 TRUNNION HOUSING	TATA spare parts
288032607101	BRACKET SHOCK ABSORBER MTG UPPER BS6	TATA spare parts
288032900101	ASSY. ARB LINK TML SUSP REAR BS3/4/6	TATA spare parts
288032903703	TOP ARB MOUNTING BRACKET-TML SUSPENSION	TATA spare parts
288032903704	ARB MTG BRACKET BOTTOM TML SUSPENSION	TATA spare parts
288032907101	ARB C CLAMP-TML SUSPENSION	TATA spare parts
288032907902	ANTIROLL BAR-TML REAR BOGIE SUSPENSION	TATA spare parts
288032907903	REAR ANTIROLL BAR TML SUSPENSION	TATA spare parts
288034100104	ASSY. FIFTH WHEEL COUPLING BS2/3/4	TATA spare parts
288034100105	ASSY. FIFTH WHEEL COUPLING BS2/3/4	TATA spare parts
288034200101	GUIDE BRACKET ASSY LH	TATA spare parts
288034200102	GUIDE BRACKET ASSY RH	TATA spare parts
288034200106	ASSY SUB-STRUCTURE FOR FIFTH WHEEL COUPL	TATA spare parts
288034200107	ASY.CORRUGATED PLATE &5TH WHEEL PRESSED	TATA spare parts
288034200111	ASSEMBLY BRACKET COUPLER LH	TATA spare parts
288034200112	ASSEMBLY BRACKET COUPLER RH	TATA spare parts
288034207112	STOPPER FOR CORRUGATED PLATE	TATA spare parts
288034207125	STOPPER FOR FIFTH WHEEL COUPLING	TATA spare parts
288034207126	BRACKET COUPLER LH	TATA spare parts

288034207127	BRACKET COUPLER RH	TATA spare parts
288034207128	FIFTH WHEEL COUPLING MOUNTING PLATE	TATA spare parts
288034990102	LOCKING JAW COMPLETE	TATA spare parts
288034990103	LOCKING BAR COMPLETE	TATA spare parts
288034990104	AUTOMATIC SPRING LOCK COMP	TATA spare parts
288034990106	ADJUSTING SCREW COMPLETE	TATA spare parts
288034990107	180 PEDESTAL	TATA spare parts
288034990108	SPARE KIT ASSEMBLY-FIFTH WHEEL COUPLING	TATA spare parts
288034990110	PEDESTAL A	TATA spare parts
288034993101	HEXAGONAL BOLT COMPLETE	TATA spare parts
288034993201	BOLT	TATA spare parts
288034993202	SOCKET HEAD BOLT	TATA spare parts
288034993203	SOCKET HEAD BOLT	TATA spare parts
288034993205	WASHER	TATA spare parts
288034993207	HEXAGONAL HEAD BOLT	TATA spare parts
288034993208	HEXAGONAL BOLT COMPLETE	TATA spare parts
288034993209	HEXAGONAL HEAD BOLT	TATA spare parts
288034993210	BAR BOLT COMPLETE	TATA spare parts
288034993211	BOLTS	TATA spare parts
288034993265	HEXAGONAL HEAD BOLT	TATA spare parts
288034995601	HANDLE	TATA spare parts
288034996001	LATCH CORD	TATA spare parts
288034996002	PULL HANDLE	TATA spare parts
288034996003	HANDLE	TATA spare parts
288034996004	BEARING	TATA spare parts
288034996101	LOCKING BAR	TATA spare parts
288034996102	LOCKING BAR	TATA spare parts
288034996103	LOCKING LEVER	TATA spare parts
288034996104	LOCK JAW	TATA spare parts
288034996701	PIVOT PIN	TATA spare parts
288034996702	SPLIT PIN	TATA spare parts
288034997101	FIXING PLATE	TATA spare parts
288034997102	COUPLING PLATE BS4	TATA spare parts
288034997501	RUBBER BUSH	TATA spare parts
288034997502	RUBBER BUSH LOWER BS2/3/4	TATA spare parts
288034997503	RUBBER BUSH UPPER BS2/3/4	TATA spare parts
288034997802	WEARING RING	TATA spare parts
288034997803	WEARING RING	TATA spare parts
288034998601	FIXING LOOP	TATA spare parts
288034998602	SPACER	TATA spare parts
288034998603	BRIDGE	TATA spare parts
288034998701	DOUBLE TENSION SPRING	TATA spare parts
288034998702	TORSION SPRING	TATA spare parts
288034998703	LEVER	TATA spare parts
288034998704	SPRING LOOP	TATA spare parts
288034998705	TENSION SPRING	TATA spare parts
288034999201	WASHER	TATA spare parts

288035113202	BOLT M8 X 1.25	TATA spare parts
288040000101	ASSY WHEEL RIM 8.0X20 STEEL	TATA spare parts
288040000104	ASSY WHEEL RIM 8.0X20	TATA spare parts
288040000105	ASSY WHEEL RIM 8.0X20 STEEL	TATA spare parts
288040100106	ASSY - HUB COVER	TATA spare parts
288040100127	ASSY. WHEEL RIM BS6	TATA spare parts
288040100128	ASSY. WHEEL RIM BS2/3/4/6	TATA spare parts
288040100129	ASSY WHEEL RIM BS6	TATA spare parts
288040100130	WHEEL RIM ASSY BS6	TATA spare parts
288040100131	WHEEL RIM ASSY BS6	TATA spare parts
288040100132	ASSY WHEEL RIM 8X20	TATA spare parts
288040106302	TYRE 11R20 16PR RIB FRT	TATA spare parts
288040106304	CAP - WHEEL NUT	TATA spare parts
288040200107	ASSEMBLY - VALVE EXTENSION	TATA spare parts
288040300101	ASSY S/TYRE MTG. BRACKET	TATA spare parts
288040300102	ASSY S/TYRE MTG BRACKET WITH LOCKING BOL	TATA spare parts
288040306901	LOCK BOLT	TATA spare parts
288041100101	ASSY PROPELLER SHAFT MAIN	TATA spare parts
288041107101	GUARD-P/SHAFT FRONT	TATA spare parts
288041110101	UNIT PACK	TATA spare parts
288041110101DF	UJ CROSS - LPK3138	TATA spare parts
288041110103	MAIN SHAFT WITH SLIDING JOINT	TATA spare parts
288041110105	PROPELLERSHAFTASSLY DRIVE	TATA spare parts
288041110106	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
288041115101	FLANGE YOKE	TATA spare parts
288041120101	ASSY PROPELLER SHAFT INTERAXLE	TATA spare parts
288042100103	ASSY. FRONT BRAKE WITH DUST COVER LH	TATA spare parts
288042100104	ASSY. FRONT BRAKE WITH DUST COVER RH	TATA spare parts
288042100106	ASSY FRONT AXLE BRAKE LH WITH DUST COVER	TATA spare parts
288042100107	ASSY.FRONT AXLE BRAKE RH WITH DUST COVER	TATA spare parts
288042100126	LINED SHOE ASSY	TATA spare parts
288042100127	TUBE - FLANGE AND BRACKET ASSY. - LH	TATA spare parts
288042100128	TUBE - FLANGE AND BRACKET ASSY. - RH	TATA spare parts
288042103001	ROLLER - BRAKE SHOE	TATA spare parts
288042103201	HEX BOLT M16X52	TATA spare parts
288042103202	SET BOLT - FOR BUNDY TUBE	TATA spare parts
288042103203	MOUNTING BOLT	TATA spare parts
288042103401	SENSOR SLEEVE FOR ABS	TATA spare parts
288042103402	BUSH - ABUTMENT	TATA spare parts
288042103402AE	BUSH ABUTMENT FRT BRAKE -1628	TATA spare parts
288042103403	BUSH - CAM END	TATA spare parts
288042103404	BUSH - BRACKET END	TATA spare parts
288042103405	BUSHING - CAM & SPIDER	TATA spare parts
288042103702	BRAKE DRUM FRONT	TATA spare parts
288042103703	TORQUE PLATE - LH	TATA spare parts
288042103704	TORQUE PLATE - RH	TATA spare parts
288042103705	BRAKE DRUM FRONT BS2/3	TATA spare parts

288042104301	CIRCLIP	TATA spare parts
288042104302	CIRCLIP - CAM END	TATA spare parts
288042105301	GASKET - BRACKET & SPIDER	TATA spare parts
288042106301	FRONT BRAKE LINING STANDARD	TATA spare parts
288042106302	FRONT BRAKE LINING OVER SIZE 1	TATA spare parts
288042106303	FRONT BRAKE LINING OVER SIZE 2	TATA spare parts
288042106701	FULCRUM PIN	TATA spare parts
288042107401	RIVET FOR BRAKE LINING	TATA spare parts
288042107402	RIVETS	TATA spare parts
288042107801	OIL SEAL BS4	TATA spare parts
288042107801AE	OIL SEAL FOR REAR BRAKE -1628	TATA spare parts
288042107901	CAM SHAFT - LH	TATA spare parts
288042107902	CAM SHAFT - RH	TATA spare parts
288042108001	CAP SCREW - BRACKET ASSY.	TATA spare parts
288042108002	CAP SCREW - DUST SHIELD	TATA spare parts
288042108201	SHIELD ASSY. - LH	TATA spare parts
288042108202	SHIELD ASSY. - RH	TATA spare parts
288042108203	SHIELD ASSY. - LH	TATA spare parts
288042108204	SHIELD ASSY. - RH	TATA spare parts
288042108207	PLUG - DUST SHIELD	TATA spare parts
288042108301	SHIM - 0.5 MM	TATA spare parts
288042108302	SHIM - 1.0 MM	TATA spare parts
288042108303	SHIM - 0.3 MM	TATA spare parts
288042108401	SLEEVE - DELRIN	TATA spare parts
288042108601	SPACER FOR FRONT BRAKE	TATA spare parts
288042108701	SPRING CAM END FOR FRONT BRAKE	TATA spare parts
288042108702	SPRING ABUTMENT END FOR FRONT BRK BS1- 6	TATA spare parts
288042108703	RETAINER - ROLLER	TATA spare parts
288042108704	RETURN SPRING - BRAKE SHOE	TATA spare parts
288042109001	RELIEF VALVE FOR FRONT BRAKE	TATA spare parts
288042109201	WASHER	TATA spare parts
288042109202	SPRING WASHER	TATA spare parts
288042109203	WASHER - M14	TATA spare parts
288042109205	WASHER - BRACKET ASSY.	TATA spare parts
288042109214	WASHER	TATA spare parts
288042109901	POLE WHEEL	TATA spare parts
288042109902	GREASE NIPPLE	TATA spare parts
288042109904	FITTING GREASE	TATA spare parts
288042109905	ABS SENSOR L TYPE	TATA spare parts
288042109906	GREASE NIPPLE	TATA spare parts
288042300108	ASSY. REAR FWD AXLE LH BRAKE COMPLETE	TATA spare parts
288042300109	ASSY. REAR FWD AXLE RH BRAKE COMPLETE	TATA spare parts
288042300110	ASSY. REAR FWD AXLE BRAKE COMPLETE	TATA spare parts
288042300111	ASSY. REAR FWD. AXLE BRAKE RH WITH DUST	TATA spare parts
288042300114	ASSY REAR RWD AXLE LH BRAKE COMPLETE	TATA spare parts
288042300115	ASSY REAR RWD AXLE RH BRAKE COMPLETE	TATA spare parts
288042300122	ASSY SLACK ADJUSTER LH 38 MM OFFSET-FOR	TATA spare parts

288042300123	ASSY SLACK ADJUSTER RH 38 MM OFFSET-FOR	TATA spare parts
288042300124	ASSY AUTO SLACK ADJUSTER LH 60 MM OFFSET	TATA spare parts
288042300124AE	AUTO SLCK ADJSTR L 60MM OFF-1628	TATA spare parts
288042300125	ASSY AUTO SLACK ADJUSTER RH 60 MM OFFSET	TATA spare parts
288042300125AE	AUTO SLCK ADJSTR R 60MM OFF-1628	TATA spare parts
288042300141	ASSY. BRAKE SHOE W/LNG. & ROLLER BS2/3/4	TATA spare parts
288042300142	SPIDER ASSY. ( WITH BUSHES & SEAL )	TATA spare parts
288042300160	LINED SHOE ASSY	TATA spare parts
288042303001	ROLLER - BRAKE SHOE	TATA spare parts
288042303301	SENSOR AXLE BRACKET REAR	TATA spare parts
288042303302	SENSOR MOUNTING BRACKET	TATA spare parts
288042303401	BUSH - REAR BRAKE CHAMBER MOUNTING BRAC	TATA spare parts
288042303403	BUSHING - CAM & SPIDER	TATA spare parts
288042303403AE	BUSHING -CAM&SPIDER R BRK-1628	TATA spare parts
288042303702	BRAKE DRUM REAR (410X220) BS2/3	TATA spare parts
288042303702AE	BRAKE DRUMS FRONT 1628 1828	TATA spare parts
288042303708	CHAMBER MOUNTING BRACKET REAR FORWARD	TATA spare parts
288042303709	CHAMBER MOUNTING BRACKET REAR FORWARD	TATA spare parts
288042303712	CHAMBER MOUNTING BRACKET LH REAR RWD A	TATA spare parts
288042303714	CHAMBER MOUNTING BRACKET RH REAR RWD A	TATA spare parts
288042303715	TORQUE PLATE FOR REAR BRAKE	TATA spare parts
288042303716	BRAKE DRUM REAR	TATA spare parts
288042303717	CHAMBER MOUNTING BRACKET LH FOR REAR RW	TATA spare parts
288042303718	CHAMBER MOUNTING BRACKET RH FOR REAR RV	TATA spare parts
288042306301	REAR BRAKE LINING STANDARD	TATA spare parts
288042306301AE	BRAKE LINERS REAR 1628 1828	TATA spare parts
288042306302	KIT LINING SET I O/S REAR	TATA spare parts
288042306303	KIT LINING SET II O/S REAR	TATA spare parts
288042306304	BRAKE LINING - AF 5157	TATA spare parts
288042306501	HEX NUT W/COLLAR M14X1 5 FOR REAR BRAKE	TATA spare parts
288042306701	ANCHOR PIN - BRAKE SHOE	TATA spare parts
288042306701AE	ANCHR PIN BRK SHOE RR BRK-1628	TATA spare parts
288042307101	BRAKE SHOE WITHOUT LINING	TATA spare parts
288042307101AE	BRK SHOE W/O LNG R BRK-1628-1828	TATA spare parts
288042307401	BRASS RIVET (L 12) EXTRA LENGTH	TATA spare parts
288042307401AE	RIVETS 1828	TATA spare parts
288042307801	OIL SEAL	TATA spare parts
288042307901	CAM SHAFT LH FOR REAR BRAKE	TATA spare parts
288042307902	CAM SHAFT RH FOR REAR BRAKE	TATA spare parts
288042307903	CAM SHAFT - LH	TATA spare parts
288042307903AE	CAM SFT LH RR BRAKE -1628-1828	TATA spare parts
288042307904	CAM SHAFT - RH	TATA spare parts
288042307904AE	CAM SFT RH RR BRAKE -1628-1828	TATA spare parts
288042307909	CAM SHAFT - LH	TATA spare parts
288042307910	CAM SHAFT - RH	TATA spare parts
288042307911	CAM SHAFT - LH	TATA spare parts
288042307912	CAM SHAFT - RH	TATA spare parts

288042307913	CAM SHAFT - LH	TATA spare parts
288042307914	CAM SHAFT - RH	TATA spare parts
288042307915	CAM SHAFT - LH	TATA spare parts
288042307916	CAM SHAFT - RH	TATA spare parts
288042308201	ANCHOR BRACKET LH AUTO SLACK ADJUSTER 41	TATA spare parts
288042308202	ANCHOR BRACKET RH AUTO SLACK ADJUSTER 41	TATA spare parts
288042308203	ANCHOR BRACKET AUTO SLACK ADJUSTER 60 MM	TATA spare parts
288042308205	SHIELD BOTTOM	TATA spare parts
288042308205AE	DUST SHIELD BTTM RR BRAKE -1628	TATA spare parts
288042308206	SHIELD TOP	TATA spare parts
288042308206AE	DUST SHIELD TOP RR BRAKE -1628	TATA spare parts
288042308207	DUST SHIELD - TOP	TATA spare parts
288042308207AE	DUST SHIELD-TOP RR BRK-1628-1828	TATA spare parts
288042308208	DUST SHIELD - BOTTOM	TATA spare parts
288042308208AE	DUST SHILD-BTTM RR BRK-1628-1828	TATA spare parts
288042308301	SHIM - 0.5 MM	TATA spare parts
288042308302	SHIM - 1.0 MM	TATA spare parts
288042308303	SHIM - 0.3 MM	TATA spare parts
288042308701	RETURN SPRING - BRAKE SHOE	TATA spare parts
288042309201	WASHER	TATA spare parts
288042309901	GERASE NIPPLE FOR REAR BRAKE	TATA spare parts
288042309902	FITTING GREASE - SPIDER	TATA spare parts
288042990101	KIT-BRAKE LINING FRONT BS3/4	TATA spare parts
288042990102	MINOR KIT FRONT BRAKE LINING SET 1.0 O/	TATA spare parts
288042990103	MINOR KIT FRONT BRAKE LINING SET 2.0 O/	TATA spare parts
288042990105	MINOR KIT-REAR BRK LINING STD BS2/3/4	TATA spare parts
288042990106	MINOR KIT REAR BRAKE LINING SET 1.0 O/S	TATA spare parts
288042990107	MINOR KIT REAR BRAKE LINING SET 2.0 O/S	TATA spare parts
288042990109	MINOR KIT FRONT BRAKE SET STANDARD	TATA spare parts
288042990111	BRAKE LINING KIT REAR	TATA spare parts
288042990127	DRUM BRAKE KIT-CAMSHAFT-LH	TATA spare parts
288042990128	DRUM BRAKE KIT-CAMSHAFT-RH	TATA spare parts
288042990134	LINED SHOE ASSY	TATA spare parts
288042990148	KIT DUST SHIELD ASSY	TATA spare parts
288042990149	KIT LINED SHOE ASSY	TATA spare parts
288042990150	KIT-BUSH	TATA spare parts
288042990154	KIT-CAMSHAFT	TATA spare parts
288042990155	KIT-CAMSHAFT	TATA spare parts
288042990158	KIT BRACKET ASSY - LH	TATA spare parts
288042990159	KIT BRACKET ASSY - RH	TATA spare parts
288042990160	KIT TORQUE PLATE ASSY - LH	TATA spare parts
288042990161	KIT TORQUE PLATE ASSY - RH	TATA spare parts
288042990162	KIT-BRAKE	TATA spare parts
288042990183	KIT-CAMSHAFT LH BS6	TATA spare parts
288042990185	DUST SHIELD BOTTOM	TATA spare parts
288042990186	KIT-CAMSHAFT RH BS6	TATA spare parts
288042990188	MINOR SERVICE KIT-FRONT & REAR	TATA spare parts

288042990189	KIT-BRAKE SPRING	TATA spare parts
288043139901	SPARE KIT APDA	TATA spare parts
288043139902	REPAIR KIT CONTROL UNIT	TATA spare parts
288043139903	REPAIR KIT EXHAUST UNIT	TATA spare parts
288043139904	REPAIR KIT SEALING	TATA spare parts
288043139905	FILTER CARTRIADGE	TATA spare parts
288043139905AE	FILTER CARTRIADGE APU. 1628	TATA spare parts
288043139906	REPAIR KIT	TATA spare parts
288043139907	REPAIR KIT	TATA spare parts
288043200102	BRACKET ASSY	TATA spare parts
288043200111	ASSY. BRACKET DOUBLE CHECK VALVE	TATA spare parts
288043200125	ASSY. MODULATOR VALVE MTG. BKT.	TATA spare parts
288043200125AE	ASSY MODULAOR VLVE MTG BRKT-1628	TATA spare parts
288043200127	SUB ASSY. AIR TANK - 30 LTR WITH BRACKET	TATA spare parts
288043200128	SUB ASSY. AIR TANK - 30 LTR WITH BRACKET	TATA spare parts
288043200129	ASSY. STRAP COMP.FOR AIR TANK MTG	TATA spare parts
288043200130	ASSY. STRAP COMP. (AIR TANK MTG.)	TATA spare parts
288043200132	ASSY. SUPPORT BRACKET (AIR TANK MTG.)	TATA spare parts
288043200134	ASSY. MODULATOR VALVE MTG. BKT. (REAR)	TATA spare parts
288043200135	ASSY. BRACKET (AIR TANK MTG.)	TATA spare parts
288043200136	ASSY BRACKET (AIR TANK MTG)	TATA spare parts
288043200139	ASSY. AIR TANK SUPPORT BKT	TATA spare parts
288043200140	ASSY. AIR TANK MTG CHANNEL	TATA spare parts
288043200142	ASSY - L BRACKET	TATA spare parts
288043200144	ASSY. TCV MTG. BRACKET	TATA spare parts
288043200146	SUB. ASSY. AIR TANK VOSS + VOSS (30L)	TATA spare parts
288043200148	ASSY. AIR TANK WITH SEALING PLUG FOR VOS	TATA spare parts
288043200149	ASSY AIR TANK VOSSVOSS (30L)	TATA spare parts
288043200155	ASSY. FOOT STEP MTG. BKT. LH	TATA spare parts
288043200156	ASSY. FOOT STEP MTG. BKT RH	TATA spare parts
288043208211	ASR VALVE MOUNTING BRACKET	TATA spare parts
288043208212	DOUBLE CHECK VLV MOUNTING BKT	TATA spare parts
288043208213	AIR TANK SUPPORT CHANNEL	TATA spare parts
288043208234	BRACKET (A.L.S.V. MOUNTING)	TATA spare parts
288043208235	APU & TCV MOUNTING BRACKET	TATA spare parts
288043208245	BRACKET FOR GEAR SHIFTE AND BRAKE AND CL	TATA spare parts
288043208246	BRACKET-RELAY VALVE(R12) AND REAR MODULA	TATA spare parts
288043208249	BRACKET ON CAB TO CLAMP NYLON PIPES	TATA spare parts
288043208251	DOUBLE SOCKET	TATA spare parts
288043208252	MOUNTING BRACKET TRAILOR CONTROL VALVE	TATA spare parts
288043208253	CHANNEL BRACKET FOR PIPE HOLDING	TATA spare parts
288043208281	BKT TO CLAMP METAL PIPE ON ENG	TATA spare parts
288043208284	BRACKET FOR CLAMP METAL PIPE ON ENGINE	TATA spare parts
288043700101	AIR PROCESSING UNIT	TATA spare parts
288043700102	DUAL BRAKE VALVE (BRAKE PEDAL MODULE)	TATA spare parts
288043700103	TYPE 24 BRAKE CHAMBER-75MM STROKE	TATA spare parts
288043700104	TYPE 24/24 SPRING BRAKE ACTUATOR-75MM ST	TATA spare parts

288043700105	BRAKE CHAMBER TYPE 30	TATA spare parts
288043700106	TYPE 30/30 SPRING BRAKE ACTUATOR-75MM ST	TATA spare parts
288043700107	RELAY VALVE	TATA spare parts
288043700108	HAND BRAKE VALVE WITH TRAILER CHECK	TATA spare parts
288043700114	TYPE 24 BRAKE CHAMBER-75MM STROKE	TATA spare parts
288043700115	TYPE 24/24 SPRING BRAKE ACTUATOR-75MM ST	TATA spare parts
288043700116	TYPE 30 BRAKE CHAMBER-75MM STROKE	TATA spare parts
288043700118	PALM COUPLING SUPPLY LINE	TATA spare parts
288043700119	PALM COUPLING CONTROL LINE	TATA spare parts
288043700120	HAND BRAKE VALVE WITH TRAILER CHECK	TATA spare parts
288043700124	RELAY VALVE (ANTI-COMPOUNDING)	TATA spare parts
288043700126	DOUBLE CHECK VALVE	TATA spare parts
288043700126AE	DOUBLE CHECK VALVE -1628-1828	TATA spare parts
288043700127	ASR DIFFERENTIAL VALVE	TATA spare parts
288043700133	RELAY VALVE R-12 WITH BOTH DELIVERY PORT	TATA spare parts
288043700144	TURBO CHECK VALVE	TATA spare parts
288043700146	NON-RETURN VALVE	TATA spare parts
288043700147	TRAILER CONTROL VALVE	TATA spare parts
288043700148	PRESSURE REDUCTION VALVE	TATA spare parts
288043700149	TRAILER CONTROL VALVE	TATA spare parts
288043700152	TRAILER CONTROL VALVE-KB(IMP)	TATA spare parts
288043700155	PRESSURE LIMITING VALVE	TATA spare parts
288043700156	APU 8 BAR	TATA spare parts
288043700157	TYPE 24 BRAKE CHAMBER	TATA spare parts
288043700158	BRAKE CHAMBER TYPE 30	TATA spare parts
288043700159	TYPE 24/24 SBA	TATA spare parts
288043700161	BRAKE CHAMBER TY 24 -75MM STROKE	TATA spare parts
288043700162	BRAKE CHAMBER TY 30 -75MM STROKE	TATA spare parts
288043700163	SPRING BRAKE ACTUATOR TY 24/24 75 STROKE	TATA spare parts
288043700164	SPRING BRAKE ACUATOR TY.30/30 75 STROKE	TATA spare parts
288043700164AE	SPRING BRK ACUATOR TY.30/30-1628	TATA spare parts
288043700165	DUAL BRAKE VALVE WITH BRAKE PEDAL MODULE	TATA spare parts
288043700166	PRESSURE LIMITING VALVE	TATA spare parts
288043700175	ANTI-COMPOUNDING RELAY VALVE	TATA spare parts
288043700177	SPRING BRAKE ACTUATOR TYPE 24/24	TATA spare parts
288043700178	SPRING BRAKE ACTUATOR	TATA spare parts
288043700179	ANTI-COMPOUNDING RELAY VALVE WITH ONE DE	TATA spare parts
288043700186	ANTI COMPOUNDING RELAY VALVE BS2/3	TATA spare parts
288043700186C	ANTI COMPOUNDING RELAY VALVE CORE	TATA spare parts
288043700190	RELAY VALVE WITH LH VOSS & RH PORT PLUG	TATA spare parts
288043700191	RELAY VALVE WITH LH PORT PLUGGED & RH	TATA spare parts
288043700192	MODULATOR VALVE WITH INLET VOSS & DEL ME	TATA spare parts
288043700193	MODULATOR VLV W/INLET METRIC & DEL BS2-4	TATA spare parts
288043700194	RG2 RELAY VLV DEL. PORT METRIC BS2/3/4/6	TATA spare parts
288043700194C	RG2 RELAY VALVE DELIVERY PORT METRIC CORE	TATA spare parts
288043700196	SOLENOID MODULATOR VALVE WITH INLET PORT	TATA spare parts
288043700197	AUTOMATIC LOAD SENSING VALVE	TATA spare parts



288043700199	HAND BRAKE VALVE WITH SWITCH	TATA spare parts
288043700207	RELAY VALVE WITH RH PORT PLUG & LH DEL.P	TATA spare parts
288043700207AE	RELAY VALVE (R12)-SCL 1828	TATA spare parts
288043700209	SBA TYPE 24/24 W/275MM STAND OUT BS3/4	TATA spare parts
288043700210	TRAILOR CONTROL VALVE BS2/3/4/6	TATA spare parts
288043700210AE	TRAILER CONTROL VALVE 1828	TATA spare parts
288043700211	LOAD SENSING VALVE WITH 75MM LEVER LENGT	TATA spare parts
288043700213	HAND BRAKE VALVE WITH TRAILOR CHECK	TATA spare parts
288043700218	APDA	TATA spare parts
288043700224	TWO BOLT MTG. DUAL BRAKE VALVE	TATA spare parts
288043700225	RELY VLV VOS(DEL-1VOSS&DEL2-PLUG)	TATA spare parts
288043700226	RELY VLV VOS(DEL-1MET&DEL2-PLUG)	TATA spare parts
288043700251	DUAL BRAKE VALVE TWO BOLT MTG BS3/4	TATA spare parts
288043700252	REPAIR KIT- RELAY VALVE WITH RH PORT PLU	TATA spare parts
288043700265	SPARE KIT-AIR DRYR	TATA spare parts
288043700268	PRESSURE LIMITING VALVE SPARE KIT	TATA spare parts
288043700271	SPRING BRAKE ACTUATOR TYPE-24/24 METRIC	TATA spare parts
288043700280	AIR PROCESSING UNIT LOCALISED EURO3	TATA spare parts
288043708209	BRACKET (PALM COUPLING MTG)	TATA spare parts
288043708215	BRACKET-ANTICOMPOUNDING VALVE	TATA spare parts
288043709901	CONECTOR PRUEBA AIRE (VOSS)	TATA spare parts
288043709902	PRESSURE TEST-CONNECTOR BS6	TATA spare parts
288043709961	CARTRIDGE - APU	TATA spare parts
288043709970	SILENCER	TATA spare parts
288043709995	DESICCANT CARTRIDGE	TATA spare parts
288043710119	EXHAUST BRAKE ASSY (100 MM DIA) WITH CYL	TATA spare parts
288043710125	MAJOR KIT - BRAKE CHAMBER	TATA spare parts
288043710126	MINOR KIT - BRAKE CHAMBER	TATA spare parts
288043720101	REPAIRKIT-MSP3/103DOUBLECHECKVALVE	TATA spare parts
288043900126	METAL PIPE ASSY	TATA spare parts
288043900187	ASSY. NYLON PIPE TEE-16 TO TEE-17	TATA spare parts
288043900188	ASSY. NYLON PIPE TEE-18 TO SOLENOID VALV	TATA spare parts
288043900189	ASSY. NYLON PIPE SOLENOID VALVE TO BRAKE	TATA spare parts
288043900197	BUNCH ASSY PIPE	TATA spare parts
288043900199	ASSY. NYLON PIPE TEE 18 TO TEE 20	TATA spare parts
288043900301	ASSY. NYLON PIPE BUNCH	TATA spare parts
288043903302	BRACKET FOR METAL PIPE MTG.	TATA spare parts
288043904201	CLAMP(18 O.D. METAL PIPE)	TATA spare parts
288043906801	DOUBLE SOCKET	TATA spare parts
288043906805	TEE-8X8X6	TATA spare parts
288043907101	CLAMP STRIP	TATA spare parts
288043907503	GROMMET (FOR BRAKE PIPES-LONG MEMBER)	TATA spare parts
288043908204	MODULATOR VALVE MTG. BKT	TATA spare parts
288043910106	METAL PIPE ASSY	TATA spare parts
288043910108	BUNCH ASSY PIPE	TATA spare parts
288043910155	ASSY. NYLON PIPE APU CONTROL PORT (4) TO	TATA spare parts
288043910161	PIPE BUNCH ASSY	TATA spare parts

288043990105	REPAIR KIT RELAY VALVE	TATA spare parts
288043990106	REPAIR KIT RELAY VALVE	TATA spare parts
288043990108	DUAL BRAKE VALVE REPAIR KIT	TATA spare parts
288043990109	MAJOR KIT - PALM COUPLING HEAD BS6-PH2	TATA spare parts
288043990110	MINOR KIT - PALM COUPLING HEAD BS6-PH2	TATA spare parts
288043990121	MAJOR KIT SBA TYPE-24	TATA spare parts
288043990122	MINOR KIT SBA TYPE-24	TATA spare parts
288043990123	DIAPHRAGM KIT SBA TYPE-24	TATA spare parts
288043990124	CLAMP RING KIT SBA TYPE-24	TATA spare parts
288043990129	MAJOR KIT BRAKE CHAMBER	TATA spare parts
288043990130	MINOR KIT BRAKE CHAMBER	TATA spare parts
288043990141	REPAIR KIT FOR TRAILER CONTROL VALVE	TATA spare parts
288043997701	ADAPTER	TATA spare parts
288045100101	SET ASSY. COMPLETE NYLON PIPE BUNCH FOR	TATA spare parts
288045100103	NYLON PIPE DIA 6 (AUXILIARY TANK - TEE 1	TATA spare parts
288045100104	NYLON PIPE DIA 6 (TEE 1 - SOLENOID 1)	TATA spare parts
288045100105	NYLON PIPE DIA 6 (TEE 1 - SOLENOID 2)	TATA spare parts
288045100106	NYLON PIPE DIA 6 (SOLENOID 1 - TEE 2)	TATA spare parts
288045100107	NYLON PIPE DIA 6 (TEE 2 - FWD AXLE)	TATA spare parts
288045100108	NYLON PIPE DIA 6 (TEE 2 - RWD AXLE)	TATA spare parts
288045100109	NYLON PIPE (SOLENOID 2 - INTER AXLE DIFF	TATA spare parts
288045200102	PNEUMATIC FITTING 6MM	TATA spare parts
288045200103	PNEUMATIC FITTING 6MM -MALE CONNECTOR	TATA spare parts
288046100101	ASSY. STEERING GEAR BOX BS3/4	TATA spare parts
288046100102	STEERING COLUMN ASSY	TATA spare parts
288046100102AE	STEERING CLMN ASSY -1628	TATA spare parts
288046100105	SRG GEAR BOX ASSY	TATA spare parts
288046100106	GEAR BOX LHD	TATA spare parts
288046100106AE	ASSY PWR STRNG GR BOX -1628-1828	TATA spare parts
288046100107	STEERING GEAR BOX	TATA spare parts
288046103801	STRG COLUMN MTG BRKT	TATA spare parts
288046103801AE	STRG COLUMN MTG BRKT 1628	TATA spare parts
288046107101	BASE PLATE	TATA spare parts
288046109201	SPACER	TATA spare parts
288046200102	ASSY. INTERMEDIATE SHAFT BS3/4	TATA spare parts
288046300102	DRAG LINK ASSEMBLY	TATA spare parts
288046300104	DRAG LINK ASM LHD	TATA spare parts
288046304101	PITMAN ARM	TATA spare parts
288046304102	PITMAN ARM	TATA spare parts
288046304103	PITMAN ARM LHD	TATA spare parts
288046508208	CLAMP	TATA spare parts
288046508209	CLAMP OD 18	TATA spare parts
288046508210	CLAMP DIA. 22	TATA spare parts
288046508211	DOUBLE CLAMP 15X18	TATA spare parts
288046508212	CLAMP 18X22	TATA spare parts
288046508214	DOUBLE CLAMP 15X15	TATA spare parts
288046508215	CLAMP 18X18	TATA spare parts

288046600101	GEAR PUMP	TATA spare parts
288046600105	STEERING RESRVOIR	TATA spare parts
288046600106	INDIGENIZED ISLE GEAR PUMP TYPE-II	TATA spare parts
288046603304	BRKT-STG RESERVOIR MTG	TATA spare parts
288046607501	SCREW GROMMET	TATA spare parts
288046690101	PA TUBE OD 4MM-1M	TATA spare parts
288046700101	SPACER- STEERING GEAR BOX MTG BRKT	TATA spare parts
288046703301	STEERING GEAR BOX MTG BRKT	TATA spare parts
288046703302	GEAR BOX MTG. BRKT LHD	TATA spare parts
288046800102	SUCTION LINE HOSE & PIPE ASSY -G.B END	TATA spare parts
288046800103	RETURN LINE HOSE & PIPE ASSY G.B. END	TATA spare parts
288046800104	RETURN LINE HOSE & PIPE ASSY-RESR END	TATA spare parts
288046800111	SUCTION LINE HOSE ASSY. TYPE-II	TATA spare parts
288046800112	PRESSURE LINE HOSE ASSY. TYPE-II	TATA spare parts
288046800113	RETURN LINE HOSE ASSY. - TYPE II	TATA spare parts
288046800116	PRESSURE HOSE & PIPE ASSY. PUMP END TYPE	TATA spare parts
288046800125	SUCTION LINE HOSE & PIPE ASSY TYPE II(IN	TATA spare parts
288046800126	PRESSURE HOSE & PIPE ASSY PUMP END TYPE	TATA spare parts
288046800143	SUCTION LINE TYPE-II (FOR INDIGENIZED IS	TATA spare parts
288046800145	PRESSURE LINE ASSY PUMP END TYPE-II	TATA spare parts
288046803304	BRKT-STG PIPE MTG ON CROSS MEMBER	TATA spare parts
288046803305	BRACKET¿STEERING¿PIPE¿MTG	TATA spare parts
288046806803	MALE ADAPTER M12X1.5 TO DIA 4	TATA spare parts
288046806803AE	MALE ADPTR M12X1.5 TO DIA4 -1628	TATA spare parts
288046806805	MALE ADAPTER M12X1.5 TO DIA 6	TATA spare parts
288046806805AE	MALE ADPTR M12X1.5 TO DIA6 -1628	TATA spare parts
288046990101	SPARE KIT FOR STEERING GEARBOX	TATA spare parts
288046990106	SPARE KIT FOR STEERING COLUMN	TATA spare parts
288046990107	MAJOR SEAL KIT	TATA spare parts
288046990110	SEAL KIT	TATA spare parts
288046993001	BALL RETURN GUIDE KIT-RH	TATA spare parts
288046993002	BALL RETURN GUIDE KIT-LH	TATA spare parts
288046993201	SIDE COVER BOLT-HEX HEAD	TATA spare parts
288046993202	VALVE HOUSING BOLT-TORX HEAD	TATA spare parts
288046994701	SIDE COVER SUB ASSY	TATA spare parts
288046995301	SIDE COVER GASKET	TATA spare parts
288046996501	NUT-DROP ARM	TATA spare parts
288046996502	NUT(ADJ SCREW	TATA spare parts
288046996601	RACK PISTON ASSY-RH	TATA spare parts
288046996602	RACK PISTON ASSY. - LH	TATA spare parts
288046997201	VENT PLUG(S/CVR)	TATA spare parts
288046997701	SEAL KIT INPUT SHAFT	TATA spare parts
288046997702	DIRT & WATER SEAL (OUTPUT SHAFT)	TATA spare parts
288046997703	DIRT & WATER SEAL	TATA spare parts
288046997704	RACK SEAL KIT	TATA spare parts
288046997801	O RING	TATA spare parts
288046997802	O RING (VALVE HSG SPIGOT)	TATA spare parts

288046997901	SECTOR SHAFT ASSY	TATA spare parts
288046998001	HSG. POPPET ADJ SCREW KIT	TATA spare parts
288046998002	POPPET STOP SCREW KIT	TATA spare parts
288046999001	AUTO LIMITER VALVE	TATA spare parts
288046999002	PRESSURE RELIEF VALVE(VENTIL INSERT)	TATA spare parts
288046999003	VALVE HSG/VALVE & WORM ASSY RH	TATA spare parts
288046999004	VALVE HSG./VALVE & WORM ASSY-LH	TATA spare parts
288046999005	AUTO POPPET VALVE KIT	TATA spare parts
288046999006	RELIEF VALVE ASSY KIT	TATA spare parts
288046999901	HOUSING SUB ASSY-LH	TATA spare parts
288046999902	HOUSING SUB ASSY.-RH	TATA spare parts
288047100103	FILLER NECK ASM	TATA spare parts
288047100105	FUEL TANK CAP ASM	TATA spare parts
288047100107	ASSY. FUEL TANK COMPLETE(INTEGRATED SEND	TATA spare parts
288047100111	ASSY FUEL TANK COMPLETE (RECT)	TATA spare parts
288047100154	FUEL TANK RH 365L T-1 NECK (GALVANNEALED	TATA spare parts
288047500101	BRACKET-FUEL TANK MTG	TATA spare parts
288047500104	ASSY.STRAP	TATA spare parts
288047506501	SLEEVE NUT M12 X 1.5	TATA spare parts
288047506701	CLEVIS PIN	TATA spare parts
288047507702	RUBBER PACKING-STRAP	TATA spare parts
288047508205	STRAP	TATA spare parts
288047600101	FUEL INTERCONNECTION LINE	TATA spare parts
288047600103	ASSY. SUCTION LINE-W/S TO ENGINE	TATA spare parts
288047600105	ASSY.FUEL SUCTION LINE-F/TANK TO W/S	TATA spare parts
288047600106	ASSY.FUEL RETURN LINE-ENGINE TO F/TANK	TATA spare parts
288047600107	ASSY FUEL LINE FT-W/S WITH NORMA CON.	TATA spare parts
288047600109	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
288047600115	FUEL SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
288047600116	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
288047600118	RETURN PIPE ASSY	TATA spare parts
288047600119	INTER CONNECTION PIPE	TATA spare parts
288047603301	BRKT-NYLON TUBE	TATA spare parts
288047606801	VOSS ADAPTER M18X1.5	TATA spare parts
288047606803	VOSS 246 STQC 7/8	TATA spare parts
288047606805	VOSS 246 STRAIGHT QC 3/4-16UNF CONNECTOR	TATA spare parts
288047606808	VOSS ADAPTOR M14 NG12	TATA spare parts
288047606903	AIR BREATHER PIPE FOR INT SENDER	TATA spare parts
288047704901	WATER SEPARATOR	TATA spare parts
288047704901AE	FILTER FUEL 715	TATA spare parts
288047704903	BRKT-FILTER FUEL	TATA spare parts
288047704904	SPIN-FUEL SEPARATOR	TATA spare parts
288047704904AE	SPIN-FUEL SEPARATOR	TATA spare parts
288049100104	ASSY BRACKET SILENCER MTG	TATA spare parts
288049100106	ASSY STRAP ( FOR SILENCER )	TATA spare parts
288049100107	EXHAUST MUFFLER	TATA spare parts
288049100108	ASSY BRACKET FRONT SILENCER MTG	TATA spare parts

288049100109	ASSY BRACKET REAR SILENCER MTG	TATA spare parts
288049100114	ASSY EXH PIPE (FLEX PIPE TO SILENCER)	TATA spare parts
288049100115	ASSY SUPPORT EXHAUST PIPE INT	TATA spare parts
288049100117	VERTICAL STRUCTURE ASSY TAIL PIPE	TATA spare parts
288049100118	FIRST PIPE FROM TURBO TO FLEX	TATA spare parts
288049100119	WESTFALIA FLEX CONNECTOR FOR LPS 4938	TATA spare parts
288049100120	BRACKET ASSY HEAT SHIELD MTG	TATA spare parts
288049100121	GASKET	TATA spare parts
288049100122	BRACKET ASSY EGP MTG	TATA spare parts
288049100123	BRACKET ASSY EGP MTG	TATA spare parts
288049100127	PIPE ASSY UREA SUPPLY	TATA spare parts
288049100128	PIPE ASSY UREA RETURN	TATA spare parts
288049100129	PIPE UREA INJECTOR	TATA spare parts
288049100130	BRACKET ASSY UREA TANK - DOSING UNIT MTG	TATA spare parts
288049100131	TANK ASSY UREA SUPPLY	TATA spare parts
288049106501	HEX FLANGED NUT ( M12 )	TATA spare parts
288049108001	HEX FLANGED SCREW ( M12 X 40 )	TATA spare parts
288049108202	HEAT SHIELD FOR SILENCER	TATA spare parts
288049108203	TURBOCHARGER ELBOW SUPPORT BRACKET FOR	TATA spare parts
288049108204	CLAMP SILENCER MTG	TATA spare parts
288049108206	HEAT SHIELD TAIL PIPE MIDDLE	TATA spare parts
288049108240	HEAT SHIELD ASSY	TATA spare parts
288049200110	BRACKET ASSY NOX SENSOR MTG	TATA spare parts
288049204201	V-BAND CLAMP	TATA spare parts
288049207701	RUBBER PACKING UREA TANK	TATA spare parts
288049207702	RUBBER PACKING UREA TANK	TATA spare parts
288049207703	RUBBER PACKING UREA TANK	TATA spare parts
288049208202	STRAP UREA TANK MTG	TATA spare parts
288049208203	STRAP UREA TANK MTG	TATA spare parts
288052200131	ASSY RR FENDER MTG BRKT & PIPE (F & R)	TATA spare parts
288052200132	ASSY RR FENDER MTG BRKT & PIPE (MIDDLE)	TATA spare parts
288052200135	BRKT ASSY REAR FENDER MTG FORWARD	TATA spare parts
288052203802	CLAMP-RR FENDER MTG. 'A'	TATA spare parts
288052203802AE	CLAMP-RR FENDER MTG. A 1628	TATA spare parts
288052203803	CLAMP-RR FENDER MTG. 'B'	TATA spare parts
288052203803AE	CLAMP-RR FENDER MTG. B 1628	TATA spare parts
288052203807	CLAMP-RR FENDER MTG. 'A'	TATA spare parts
288052203808	CLAMP-RR FENDER MTG. 'B'	TATA spare parts
288052206301	REAR FENDER - CENTER	TATA spare parts
288052206302	REAR FENDER - RH (FRONT)	TATA spare parts
288052206302AE	REAR FENDER - RH (FRONT) 1628	TATA spare parts
288052206303	REAR FENDER - LH (FRONT)	TATA spare parts
288052206303AE	REAR FENDER - LH (FRONT) 1628	TATA spare parts
288052206304	REAR FENDER - RH (FRONT) WITH CUT OUT	TATA spare parts
288052206305	REAR FENDER - LH (FRONT) WITH CUT OUT	TATA spare parts
288052206327	REAR FENDER - LH (REAR)	TATA spare parts
288052206328	REAR FENDER - RH (REAR)	TATA spare parts

288052206329	REAR FENDER - LH (REAR) WITH CUT OUT	TATA spare parts
288052206330	REAR FENDER - RH (REAR) WITH CUT OUT	TATA spare parts
288052206335	RUBBER BINDER	TATA spare parts
288052206344	SPACER - FENDER MTG BKT MIDDLE	TATA spare parts
288052400102	ASSY. ARRESTOR	TATA spare parts
288054509901	CLUTCH SWITCH	TATA spare parts
288054509902	BRAKE SWITCH	TATA spare parts
288054600102	WIRING HARNESS WIPER	TATA spare parts
288058404001	WHEEL CHOCK	TATA spare parts
288058404002	WHEEL CHOCK	TATA spare parts
288058405001	CHASSIS RECORD BAG	TATA spare parts
288058604003	JACK MTG. BKT.(15 T)	TATA spare parts
288058900101	PULLER ASSY / HUB I-O BRG O-RACE / RA /	TATA spare parts
288058900102	PULLER ASSY / T-PINION O- BRG O-RACE / R	TATA spare parts
288058900103	ASSY PULLER / USE 2880 3513 3522 3527	TATA spare parts
288058900104	ASSY PULLER / USE 28803307 3309 / HUB I-	TATA spare parts
288058900114	ASSY.JACK HANDLE	TATA spare parts
288058902603	DRIFT FOR REMOVAL OF SRDG BALL BRG.	TATA spare parts
288058902604	DRIFT FOR INSTALLATION OF SRDG BALL BRG.	TATA spare parts
288058902605	DRIFT FOR REMOVAL OF SRDG BALL BRG.	TATA spare parts
288058902606	DRIFT FOR INSTALLATION OF SRDG BALL BRG.	TATA spare parts
288058902612	PULLER FOR DRIVE SHAFT BRG.	TATA spare parts
288058902613	DRIFT FOR INSTALLATION OF DRIVE SHAFT	TATA spare parts
288058902615	PULLER FOR REMOVAL OF MAIN SHAFT & PTO	TATA spare parts
288058902616	DRIFT FOR MAIN SHAFT BRG.	TATA spare parts
288058902631	MOUNTING	TATA spare parts
288058902634	ASSEMBLY AID	TATA spare parts
288058902635	EXTENSION TUBE	TATA spare parts
288058902637	THREADED RING	TATA spare parts
288058902638	GRIPPING INSERT	TATA spare parts
288058902639	ASSEMBLY FIXTURE	TATA spare parts
288058902641	GRIPPER	TATA spare parts
288058902642	LIFTING DEVICE	TATA spare parts
288058902643	HOOK	TATA spare parts
288058902644	MOUNTING	TATA spare parts
288058902645	EXTRACTOR	TATA spare parts
288058902647	FIXING DEVICE	TATA spare parts
288058902648	SPLIT RING	TATA spare parts
288058902650	PROTECTING SLEEVE	TATA spare parts
288058902652	HOLDING FIXTURE	TATA spare parts
288058902653	MOUNTING	TATA spare parts
288058902654	MOUNTING	TATA spare parts
288058902655	MOUNTING	TATA spare parts
288058902656	MOUNTING	TATA spare parts
288058902657	HOOK	TATA spare parts
288058902659	GRIPPING INSERT	TATA spare parts
288058902660	ASSEMBLY FIXTURE	TATA spare parts

288058902661	OIL PUMP SEAL INSTALLER	TATA spare parts
288058902662	CTR SHAFT FR BR CUP INST	TATA spare parts
288058902663	INPUT SHAFT BRG CUP INST	TATA spare parts
288058902664	MAINSHAFT RR BRG INST	TATA spare parts
288058902665	CTR SHAFT RR BRG CUP INST	TATA spare parts
288058902666	REAR SEAL INSTALLER	TATA spare parts
288058902667	OUTPUT SHAFT BRG INST	TATA spare parts
288058902668	SELECTOR SHAFT BUSH INST	TATA spare parts
288058902669	SUN GEAR RETAINER	TATA spare parts
288058902670	MAINSHAFT BRG RR PILOT	TATA spare parts
288058902671	DRIVER	TATA spare parts
288058902672	BEARING REMOVAL PULLER	TATA spare parts
288058902677	GEAR ASSY LIFT FIXTURE	TATA spare parts
288058902680	SLIDE HAMMER WT ADAPTER	TATA spare parts
288058903301	75.3 HEX SOC / HUB LOCK NUT / FA / 7.5T	TATA spare parts
288058903302	PULLER / REMOVE HUB ASSY / FA / 7.5T	TATA spare parts
288058903304	DRIFT/ INSTALL HUB I-BRG O-RACE/ FA/7.5T	TATA spare parts
288058903305	DRIFT/INSTALL HUB O-BR O-RACE/ FA / 7.5T	TATA spare parts
288058903306	DRIFT / R-O-BRG O-RACE / FA / 7.5T	TATA spare parts
288058903307	ROCKER	TATA spare parts
288058903309	PULLER SUPPORT / 28800104 / FA / 7.5T	TATA spare parts
288058903501	PULLER / COUPLING FLANGE / RA / WT	TATA spare parts
288058903502	DRIFT / INSTALL COUP. FLANGE / RA / WT	TATA spare parts
288058903503	DRIFT /INSTAAL OUTPUT SHAFT BRG /RA /WT	TATA spare parts
288058903504	DRIFT/ INSTALL T-PINION I-OBRG / RA / WT	TATA spare parts
288058903505	DRIFT / DIFF BRG I-RACE / RA / WT	TATA spare parts
288058903506	DRIFT / INSTALL I-S ROLL BRG I-RACE /WT	TATA spare parts
288058903507	DRIFT/ INS TR BRG O-RAC/ I-SHAFT/RA/ WT	TATA spare parts
288058903508	DRIFT/ INSTALL HUB I-O BRGO-RACE/ RA /WT	TATA spare parts
288058903509	DRIFT FOR TAIL PINION OUTER BRG.OUTER RA	TATA spare parts
288058903510	DRIFT FOR TAIL PINION INNER BRG.OUTER RA	TATA spare parts
288058903511	ROCKER	TATA spare parts
288058903512	ROCKER	TATA spare parts
288058903513	ROCKER / T-PIN I-BRG O-RACE/ RA/0402/WT	TATA spare parts
288058903514	DOLLY FOR REMOVAL OF TR BRG.OUTER RACE F	TATA spare parts
288058903515	BEARING PULLER	TATA spare parts
288058903516	PULLER/T-PINION I-BRG I-RACE/USE W-3515/	TATA spare parts
288058903517	PULLER/R-DIFF. BRG I-RACE/USE W-3515/WT	TATA spare parts
288058903518	MOUNTING PIN / R-DIFF LOCK FORK SHAFT	TATA spare parts
288058903519	PULLER / REMOVE F-HUB ASSY. / RA / WT	TATA spare parts
288058903520	FIXTURE / LOCKING T-PINION DRIVE / RA	TATA spare parts
288058903521	TOOL 105HEX-3/4IN-65L SOC /HUB LOCK NUT/	TATA spare parts
288058903522	STUD/ USE W-0101 0102 0103 0104/ RA / W	TATA spare parts
288058903523	HANDLE / USE W-2880 3509 3510 / WT	TATA spare parts
288058903524	PULLER SUPPORT / USE W-28800101/ RA / WT	TATA spare parts
288058903525	PULLER SUPPORT / USE W-28800102/ RA / WT	TATA spare parts
288058903526	DRIFT/INSTALL PLANETORY HSGCOVER SEAL/WT	TATA spare parts

288058903527	PULLER SUPPORT / USE W-28800103/ RA / WT	TATA spare parts
288058903528	DRIFT FOR FITMENT OF PLANETARY BELL HSG	TATA spare parts
288058906306	STRAP WITH MALE VELLCRO	TATA spare parts
288058906307	STRAP WITH FEMALE VELLCRO	TATA spare parts
288100000101	RETRO KIT FOR LP 1112	TATA spare parts
288115100101	STARTER MOTOR	TATA spare parts
288115100102	STARTER MOTOR 24V LP1512_497BSIII	TATA spare parts
288115109901	SHROUND	TATA spare parts
288115109902	PLUNGER ASSEMBLY	TATA spare parts
288115109903	SOLENOID SWITCH BS6	TATA spare parts
288115109904	ARMATURE ASSEMBLY BS6	TATA spare parts
288115109905	INTERMEDIATE BRACKET ASSEMBLY BS6	TATA spare parts
288115109906	ENGAGING LEVER ASSEMBLY	TATA spare parts
288115109907	DRIVE ASSYMBLY BS6	TATA spare parts
288115109908	FIXING BRACKET BS6	TATA spare parts
288115109909	FIELD COIL ASSEMBLY BS6	TATA spare parts
288115109910	BRUSH GEAR ASSEMBLY BS6	TATA spare parts
288115109911	CE BRACKET ASSEMBLY BS6	TATA spare parts
288115109912	ARMATURE ASSEMBLYING KIT BS6	TATA spare parts
288115109917	BEARING BUSH KIT BS6	TATA spare parts
288115109921	BRUSH ASSEMBLING KIT BS6	TATA spare parts
288115109926	FASTENERS KIT BS6	TATA spare parts
288115109948	SEALING KIT BS6	TATA spare parts
288116100101	CONTAINER (ECU 497TCIC) BSIII)	TATA spare parts
288116100103	CONTAINER (ECU 497TC BS-III)	TATA spare parts
288124100101	ASSY. BRACKET(ENGINE MOUNTING FRONT)	TATA spare parts
288124100103	ENGINE MTG ASSY FRONT-LH	TATA spare parts
288124100104	ASSY. BRACKET ENGINE MOUNTING - FRONT	TATA spare parts
288124200102	ASSY. BRACKET (ENGINE MTG.REAR BOTTOM)	TATA spare parts
288124200103	ASSLY RUBBER SUPPORT REAR	TATA spare parts
288124200106	ASSY. BRACKET R.H (ENG.MTG.TOP)	TATA spare parts
288124200107	ASSLY BRACKET-LH(ENGINE MTG.REAR TOP)	TATA spare parts
288126717701	PACKING GS BRACKET MTG	TATA spare parts
288126800103	ASSY TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
288126800104	ASSY GEAR SHIFT LEVER	TATA spare parts
288126800106	ASSY BRACKET	TATA spare parts
288126800107	ASSY KIT FOR BRACKET & SUPPORT MTG.ARRGT	TATA spare parts
288126800109	GEAR SHIFT LEVER ASSY	TATA spare parts
288126800112	ASSY TURNING TUBE 126 (WITHOUT BALL JOIN	TATA spare parts
288126800117	TURNING TUBE ASSY	TATA spare parts
288126800118	GEAR SHIFT LEVER ASSY WITH SELECTOR FORK	TATA spare parts
288126810101	ASSY SUPPORT TUBE	TATA spare parts
288126810102	ASSY BRACKET (SUPPORT TUBE MOUNTING)	TATA spare parts
288126810104	BRACKET ASSY GEAR SHIFT LEVER MTG	TATA spare parts
288126810105	BRACKET ASSY SUPPORT TUBE MTG	TATA spare parts
288126810106	SUPPORT TUBE ASSY	TATA spare parts
288126810107	SUPPORT TUBE ASSY	TATA spare parts



288126810108	BRACKET ASSY SUPPORT TUBE MTG	TATA spare parts
288126810109	BRACKET ASSY GEAR SHIFT LEVER MTG	TATA spare parts
288126813701	BRACKET GEAR SHIFT LEVER MTG	TATA spare parts
288129100102	ASSLY PIPE MASTER CYL.TO SLV CYL.	TATA spare parts
288129100103	HYD PIPE ASSY MASTER CLY TO HOSE	TATA spare parts
288129100109	ASSY HYD PIPE(M/CYL TO S/CYL)- SECOND PI	TATA spare parts
288129100113	ASSY PEDAL BOX WITH CMC MOUNTING	TATA spare parts
288129100117	CLUTCH BOOSTER ASSY	TATA spare parts
288129300101	ASSLY BRACKET(FOR CLUTCH SENSOR FITMENT)	TATA spare parts
288129300102	BUNDY TUBE ASSY CMC TO LONG MEMBER	TATA spare parts
288129300103	BUNDY TUBE ASSY	TATA spare parts
288129500101	ASSY BRACKET FOR CLUTCH BOOSTER MTG	TATA spare parts
288130100101	BRACKET ASSY ACCELERATOR PEDAL	TATA spare parts
288131000102	ASSY FRAME COMPLETE LP1512/52 60% ROH	TATA spare parts
288131000106	ASSY FRAME COMP LP1112/48 60%ROH	TATA spare parts
288131000108	FRAME ASSY	TATA spare parts
288131000112	FRAME ASSY WITH FITMENT	TATA spare parts
288131200101	ASSY. SUPPORT-RH(FIRST CROSS MEMBER)	TATA spare parts
288131200102	ASSY. SUPPORT-LH(FIRST CROSS MEMBER)	TATA spare parts
288131200103	ASSLY SUPPORT C/M REAR	TATA spare parts
288131200104	ASSY.SUPPORTBRACKET-RH	TATA spare parts
288131200105	ASSY.SUPPORTBRACKET-LH	TATA spare parts
288131200106	SUPPORT ASSY CROSS MEMBER RH	TATA spare parts
288131200107	SUPPORT ASSY CROSS MEMBER LH	TATA spare parts
288131200108	BRACKET ASSY RADIATOR MTG	TATA spare parts
288131208204	PACKING PLATE	TATA spare parts
288131700101	ASSY TRANSMISSION SHIELD FRT.SIDE	TATA spare parts
288131700102	ASSY TRANSMISSION SHIELD	TATA spare parts
288131700103	ASSY BOTTOM SHIELD (ENGINE SIDE)	TATA spare parts
288131700104	ASSY BOTTOM SHIELD (RADIATOR SIDE)	TATA spare parts
288131700105	ASSY.SUPPORT BKT TRANSMISSION SIDE -RH	TATA spare parts
288131700106	ASSY SUPPORT BKT.TRANSMISSION SIDE-LH	TATA spare parts
288141100113	ASSY. PROP SHAFT FRONT (L= 677)	TATA spare parts
288141100123	ASSY. PROP SHAFT MIDDLE (L=1435)	TATA spare parts
288141100131	ASSY PROP SHAFT FRONT	TATA spare parts
288141110101	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
288141110102	PROPELLER SHAFT ASSY	TATA spare parts
288141120117	ASSY. PROP SHAFT REAR (L=1507)	TATA spare parts
288141120119	ASSY.PROP SHAFT REAR (L=1848)	TATA spare parts
288141303301	CENTRE BEARING BRACKET	TATA spare parts
288141303302	SPACER BRACKET (FOR CENTRE BEARING)	TATA spare parts
288141303303	SPACER BRACKET( FOR CENTRE BEARING)	TATA spare parts
288141303304	SPACER BRACKET (FOR CENTRE BEARING)	TATA spare parts
288141303307	BRACKET CENTER BRG	TATA spare parts
288141303312	CENTER BRG.MTG. BRKT	TATA spare parts
288141303313	CENTER BRG.MTG. BRKT	TATA spare parts
288141303314	BRACKET CENTER BRG MTG	TATA spare parts

288143700115	BRACKET ASSY ABS MODULATOR MTG	TATA spare parts
288143900104	ASSY.PIPE(FIRST METAL PIPE ON COMPRESSOR	TATA spare parts
288143900105	ASSY.PIPE(SECOND METAL PIPE ON COMPR.)	TATA spare parts
288143900108	ASSY.NYLON PIPE SET FOR COWL-LP1512/497	TATA spare parts
288143900109	ASSY.NYLON PIPE SET CHASSIS COMPL-LP1512	TATA spare parts
288143900136	PIPE ASSY COMPRESSOR OUTLET-3	TATA spare parts
288143900149	SET ASSY NYL PIPE LP1512/48.VOSS 497-BS3	TATA spare parts
288143900155	SET ASSY NYLON PIPE BUNCH FOR LP1512/52	TATA spare parts
288143900156	ASSY.18DIA FIRST METAL PIPELINE WITH CRI	TATA spare parts
288143900157	ASSY PIPE-SECOND METAL PIPE COMP-18 DIA	TATA spare parts
288143900161	AC INLET METAL PIPE 18 DIA WITH CRIMPE H	TATA spare parts
288143900171	PIPE ASSY THIRD METAL PIPE 18 OD	TATA spare parts
288143900172	PIPE ASSY SECOND METAL PIPE	TATA spare parts
288143900176	ASSY 18 DIA THIRD METAL PIPE	TATA spare parts
288143900177	ASSY 18 DIA FOURTH METAL PIPE	TATA spare parts
288143910101	PIPE ASSY COMPRESSOR OUTLET-2	TATA spare parts
288143910104	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
288143910105	PIPE ASSY MV DEL TO SBA HOSE L	TATA spare parts
288143910106	PIPE ASSY MV DEL TO SBA HOSE R	TATA spare parts
288143910107	PIPE ASSY DDU 21 TO REAR AIR TANK	TATA spare parts
288143910108	PIPE ASSY DDU 23 TO HBV 1	TATA spare parts
288143910109	PIPE ASSY HBV 2 TO QRV HOSE	TATA spare parts
288143910110	PIPE ASSY REAR AIR TANK TO TEE 1	TATA spare parts
288143910111	PIPE ASSY DDU 22 TO FRONT AIR TANK	TATA spare parts
288143910112	PIPE ASSY TEE 1 TO RELAY RES	TATA spare parts
288143910113	PIPE ASSY TEE 2 TO FC HOSE R	TATA spare parts
288143910114	PIPE ASSY TEE 2 TO FC HOSE L	TATA spare parts
288143910115	PIPE ASSY QRV DEL TO SBA 12 R	TATA spare parts
288143910116	PIPE ASSY QRV DEL TO SBA 12 L	TATA spare parts
288143910117	PIPE ASSY SOLENOIDE VALVE TO EBC	TATA spare parts
288143910118	PIPE ASSY DDU 24 TO SPV 24	TATA spare parts
288143910119	PIPE ASSY TEE 1 TO DTV 11	TATA spare parts
288143910120	PIPE ASSY FRONT AIR TANK TO DTV 12	TATA spare parts
288143910121	PIPE ASSY DTV 22 TO QRV IN	TATA spare parts
288143910122	PIPE ASSY DTV 21 TO RV CONT	TATA spare parts
288143910123	PIPE ASSY QRV TO MV	TATA spare parts
288143910124	PIPE ASSY MV TO TEE 2	TATA spare parts
288143910125	PIPE ASSY COMPRESSOR OUTLET-1	TATA spare parts
288143910128	PIPE ASSY COMPRESSOR OUTLET-3	TATA spare parts
288143910130	PIPE ASSY BUNCH COMPLETE	TATA spare parts
288143910136	PIPE ASSY BUNCH COMPLETE	TATA spare parts
288143910154	PIPE ASSY COMPRESSOR FOURTH METAL PIPE	TATA spare parts
288143910198	PIPE ASSY COMPRESSOR OUTLET	TATA spare parts
288143920103	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
288143920145	PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
288143920146	PIPE ASSY	TATA spare parts
288143920147	PIPE ASSY	TATA spare parts

288146800101	ASSY PIPE STEERING G BOX TO TANK	TATA spare parts
288146800102	ASSY PIPE RES TO PUMP	TATA spare parts
288146800103	ASSY PIPE PUMP TO GEAR BOX	TATA spare parts
288146800105	HOSE ASSY PRESSURE LINE ( PUMP TO GEAR B	TATA spare parts
288146800106	RETURN LINE ASSY ( STRG. G BOX TO TANK)	TATA spare parts
288146800107	SUCTION LINE ASSY¿ (RESERVOIR TO PUMP)	TATA spare parts
288147100101	ASSEMBLY MTG. BRACKET	TATA spare parts
288147100103	ASSLY HOSE WITH CRIMP	TATA spare parts
288147600109	ASSLY RETURN PIPE 10 O.D.	TATA spare parts
288147600115	ASSLY SUCTION PIPE 10.O.D.X 0.7 THK	TATA spare parts
288147600117	ASSLY SUCTION LINE-WATER SEP. TO PUMP	TATA spare parts
288147600121	ASSY SUCTION LINE(FROM FEED PUMP TO ENG)	TATA spare parts
288147600124	ASSY.SUCTION LINE-WATER SEP.TO MECH.PUMP	TATA spare parts
288147600132	ASSY. NYLON FUEL LINE TANK TO BABY FILTE	TATA spare parts
288147600133	ASSY NYLON FUEL RETURN LINE.	TATA spare parts
288147600134	ASSY NYLON FUEL LINE(B FILTER TO F PUMP)	TATA spare parts
288147600138	FUEL LINES ASSY (PROTECT FILTER TO FWS)	TATA spare parts
288147600140	FUEL NYLON PIPE ASSY	TATA spare parts
288147600143	BRACKET ASSY	TATA spare parts
288147600144	FUEL SUCTION PIPE ASSY P/FILTER TO WFS	TATA spare parts
288147600145	FUEL RETURN PIPE ASSY ENGINE TO TANK	TATA spare parts
288147600146	FUEL SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
288147600153	SUCTION PIPE TANK TO PRE FILTER	TATA spare parts
288147600154	FUEL SUCTION PIPE P/FILTER TO W/SEP	TATA spare parts
288147600155	FUEL PIPE ASSY W/SEP TO ENGINE	TATA spare parts
288147600156	FUEL PIPE ASSY RETURN LINE	TATA spare parts
288147603301	BRACKET	TATA spare parts
288147608202	BRACKET FILTER	TATA spare parts
288147608203	BRACKET FILTER	TATA spare parts
288147990101	RETROFIT.KIT FOR FUEL FEED PUMP LP1512TC	TATA spare parts
288149100101	ASSY. SILENCER COMPLETE WITH TAIL PIPE	TATA spare parts
288149100102	ASSY.SILENCER COMPLT WITH TAIL PIPE(NT2)	TATA spare parts
288149100103	ASSY. SILENCER COMPLETE (NT2)	TATA spare parts
288149100104	ASSY SILENCER COMPLT WITH TAIL PIPE(NT2)	TATA spare parts
288149100106	ASSY SILENCER (WITH TAIL PIPE)	TATA spare parts
288149200104	FIRST PIPE ASSLY	TATA spare parts
288149200106	ASSY.SECOND PIPE (COMPLETE)	TATA spare parts
288149200108	ASSY. FIRST PIPE	TATA spare parts
288149200109	ASSY. SECOND PIPE	TATA spare parts
288149200110	ASSY SECOND EXHAUST PIPE	TATA spare parts
288149200115	ASSY THIRD EXHAUST PIPE(52WB)	TATA spare parts
288149200116	ASSY THIRD EXHAUST PIPE(48WB)	TATA spare parts
288149200117	ASSY. FRONT PIPE	TATA spare parts
288149200119	ASSY BRACKET (EXHAUST MTG)	TATA spare parts
288149200120	ASSY. BRACKET (EXHAUST MTG.)	TATA spare parts
288149200121	ASSY BRACKET WITH SPACER(EXHAUST MTG)	TATA spare parts
288149200122	ASSY BRACKET(FOR ASSY FRONT PIPE MTG)	TATA spare parts

288149200123	ASSY EXHAUST PIPE (CATCON TO MUFFLER)	TATA spare parts
288149200124	ASSY. PIPE EXHAUST (WITH BOSS)	TATA spare parts
288149200127	EXHAUST PIPE ASSY WITH BELLOW	TATA spare parts
288149200128	BRACKET ASSY DOC POC MTG	TATA spare parts
288149200129	BRACKET ASSY DOC POC MTG	TATA spare parts
288149200130	BRACKET ASSY SILENCER MTG	TATA spare parts
288149203302	CLAMP (CATCON MTG.)	TATA spare parts
288149206925	TUBE OD6X0.7 THK (HOSE TO DPS)	TATA spare parts
288149206926	TUBE OD6X0.7 THK (HOSE TO DPS)	TATA spare parts
288149208203	CLAMP(SILENCER MTG )	TATA spare parts
288149208204	BRACKET	TATA spare parts
288149208205	BRACKET	TATA spare parts
288149208207	CLAMP	TATA spare parts
288149208208	CLAMP	TATA spare parts
288149208210	BRACKET	TATA spare parts
288149208212	BRACKET	TATA spare parts
288149208214	CLAMP	TATA spare parts
288149208215	CLAMP	TATA spare parts
288149208227	CLAMP (EXHAUST)	TATA spare parts
288149208228	BRACKET (DPS) MTG	TATA spare parts
288149208229	CLAMP (EXHAUST SYSTEM)	TATA spare parts
288149209901	ASSY HEAT SHIELD BEND1	TATA spare parts
288149209902	ASSY HEAT SHIELD BEND2	TATA spare parts
288149609903	HEAT SHIELD EXHAUST	TATA spare parts
288149990102	KIT-EXHAUST HEAT SHIELD	TATA spare parts
288154108209	BRACKET CUT OFF SWITCH MTG	TATA spare parts
288154200104	INSTRUMENT CLUSTER ASSY	TATA spare parts
288154209902	INSTRUMENT CLUSTER (1:0.80)	TATA spare parts
288154600104	W/H TAIL (LP1512/52 497-BS-III)	TATA spare parts
288154600119	MAIN WIRING HARNESS	TATA spare parts
288154600120	WIRING HARNESS TAIL	TATA spare parts
288154600122	WIRING HARNESS POWER CABLE	TATA spare parts
288154600123	MAIN WIRING HARNESS	TATA spare parts
288154601606	WIRING HARNESS MAIN	TATA spare parts
288154601613	WIRING HARNESS MAIN	TATA spare parts
288154620105	W/H SENSOR	TATA spare parts
288154620106	WIRING HARNESS ENGINE	TATA spare parts
288154620107	WIRING HARNESS MAIN	TATA spare parts
288154660102	W/H TAIL (LP1512/52 497-BS-III)	TATA spare parts
288154660103	W/H ENGINE (LP1512 497ENG.BS-III)	TATA spare parts
288154660104	W/H MAIN (LP1512 497 BS-III)	TATA spare parts
288154660110	WIRING HARNESS TAIL	TATA spare parts
288154660113	WIRING HARNESS ENGINE	TATA spare parts
288154660114	WIRING HARNESS MAIN	TATA spare parts
288160100306	COWL ASSY FRONT STRUCTURE	TATA spare parts
288200000103	ASSY SPARE KIT FOR GB600/8.47 LPT1616	TATA spare parts
288216100103	CONTAINER (ECU 697TCIC) LPO1615_BSIII	TATA spare parts

288216100104	CONTAINER (ECU 697TCIC BS-III)	TATA spare parts
288224200101	ASSY. BRACKET -RH (ENG. MOUNTING REAR)	TATA spare parts
288224200102	ASSY. BRACKET -LH (ENG. MOUNTING REAR)	TATA spare parts
288231000101	ASSY FRAME COMPLETE LPT 1615/42 BS-III	TATA spare parts
288231000102	ASSY. FRAME LPT1613 (FAB 4 HOLE BKT) BS3	TATA spare parts
288231000104	ASSY. FRAME LPT 1615/52 697 TCIC BS III	TATA spare parts
288231000105	ASSY FRAME COMPLETE(LPT1616/5260%ROH)	TATA spare parts
288231000106	ASSY FRAME LPT1616/52 60 PERC ROH CAB 69	TATA spare parts
288231000107	ASSY FRAME COMPLETE	TATA spare parts
288231000108	ASSY. FRAME 1613 (FAB 4 HOLE BRKT) BS3/4	TATA spare parts
288231000117	FRAME ASSY WITH FITMENT	TATA spare parts
288231000121	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
288231200103	ASSY SUPPORT ENGINE-CROSS-MEMBER(REAR)	TATA spare parts
288231540111	BRACKET ASSY BATTERY MTG	TATA spare parts
288231548205	CLAMP TOP	TATA spare parts
288231548206	BATTERY SUPPORT	TATA spare parts
288232100104	BUMP STOPPER ASSY -LH	TATA spare parts
288232100105	BUMP STOPPER ASSY -RH	TATA spare parts
288232100106	BUMP STOPPER ASSY -LH	TATA spare parts
288232100107	BUMP STOPPER ASSY -RH	TATA spare parts
288232204201	U BOLT	TATA spare parts
288232300101	ASSY BRACKET (FRONT SHOCK ABSORBER)	TATA spare parts
288232300102	SHOCK ABSORBER BRK ASSY TOP LH	TATA spare parts
288232300103	SHOCK ABSORBER BRK ASSY TOP RH	TATA spare parts
288232300105	BRACKET ASSY SHOCK ABSORBER MTG	TATA spare parts
288232308601	SPACER	TATA spare parts
288241100102	ASSY.PROP.SHAFT WITH CENTRE BRG.(L=979)	TATA spare parts
288241110105	ASSY.PROP.SHAFT WITH CENT BEARING	TATA spare parts
288241110111	ASSY PROP. SHAFT WITH CENTRE BEARING FRO	TATA spare parts
288241110120	ASSY PROPELLER SHAFT FRONT	TATA spare parts
288241110124	ASSY PROPELLER SHAFT FRONT	TATA spare parts
288241110220	SHORT FORKTUBE & FRT END PIECE ASSY	TATA spare parts
288241110224	SHORT FORKTUBE & FRT END PIECE ASSY	TATA spare parts
288241120105	ASSY.PROPELLER SHAFT REAR COMPLETE	TATA spare parts
288241120120	ASSY PROPELLER SHAFT REAR	TATA spare parts
288241120122	ASSY PROPELLER SHAFT REAR	TATA spare parts
288241120124	ASSY PROPELLER SHAFT REAR	TATA spare parts
288241303301	BRACKET (CENTRE BEARING)	TATA spare parts
288241303302	BRACKET (CENTRE BEARING MOUNTING)	TATA spare parts
288243900134	ASSY. NYLON PIPE CHASSIS SET FOR COWL	TATA spare parts
288243900138	ASSY. NYLON PIPE CHASSIS SET	TATA spare parts
288243900142	ASSY.NYLON PIPE SET CHASSIS COMPL	TATA spare parts
288243900176	ASSY.THIRD METAL PIPE	TATA spare parts
288243900177	ASSY.SECOND METAL PIPE	TATA spare parts
288243900178	ASSY COMP THIRD METAL PIPE JOINT-2 TO AI	TATA spare parts
288243900179	ASSY COMP.SECOND METAL PIPE JOINT-1 TO J	TATA spare parts
288243900180	ASSY COMP.FIRST METAL PIPE COMP TO JOINT	TATA spare parts

288247107701	RUBBER PACKING	TATA spare parts
288247600105	ASSY.SUCTION PIPE	TATA spare parts
288247600106	ASSY.SUCTION PIPE	TATA spare parts
288247600107	ASSY.SUCTION PIPE	TATA spare parts
288247600108	ASSY.DELIVERY PIPE	TATA spare parts
288247600112	ASSY RETURN LINE	TATA spare parts
288247600114	ASSY. SUCTION LINE(AFTER BABY FILTER)	TATA spare parts
288247600118	ASSY. SUCTION LINE 10 O.D.(FROM FUEL TAN	TATA spare parts
288247600119	ASSY. RETURN LINE	TATA spare parts
288249200102	ASSY.SECOND PIPE	TATA spare parts
288249200103	ASSY.THIRD PIPE	TATA spare parts
288249200104	ASSY.SECOND PIPE	TATA spare parts
288249200106	ASSY.SECOND PIPE	TATA spare parts
288249200116	ASSY.BRACKET (EXHAUST SUPPORT)	TATA spare parts
288249203302	BRACKET	TATA spare parts
288249203303	BRACKET	TATA spare parts
288249208203	BRACKET	TATA spare parts
288254400103	HEAD LIGHT W/MOTOR 12V LH-RHD	TATA spare parts
288254400104	HEAD LIGHT W/MOTOR 12V RH-RHD	TATA spare parts
288254620109	W/H MAIN LPT1615 697 24V ERGO PACK BS3	TATA spare parts
288254660107	W/H MAIN-ERGO PACK WITH WILLIAM CONTROL	TATA spare parts
288254660109	WIRING HARNESS MAIN LPT1615 697 BSIII 24	TATA spare parts
288320105	DIFFERENTIAL LOCK RING	TATA spare parts
288320106	DIFFERENTIAL LOCK	TATA spare parts
288324200101	ASSY BRACKET ENG. MTG REAR-RH	TATA spare parts
288324200102	ASSY BRACKET ENG. MTG. REAR-LH	TATA spare parts
288329100104	ASSY CONTROL MTG. BRACKET WITH TUBE	TATA spare parts
288329100105	ASSY CONTROL MTG. BRACKET(W/O TUBE)	TATA spare parts
288329100107	ASSY CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
288329300101	ASSY. BRACKET (FOR CLUTCH SENSOR FIT.)	TATA spare parts
288329506901	TUBE	TATA spare parts
288331000102	ASSY FRAME COMPLETE LP 1615/52 BS-III 60	TATA spare parts
288331000103	ASSY. FRAME - LP 1615 BS-III 59WB 55%ROH	TATA spare parts
288331200101	ASSY SPACER ENG. CM REAR	TATA spare parts
288331200102	ASSY SUPPORT ENG. CM FRONT RH	TATA spare parts
288331200103	ASSY SUPPORT ENG. CM FRONT LH	TATA spare parts
288331200104	ASSY. CROSS MEMBER (REAR SHOCK ABSORBER)	TATA spare parts
288331208201	PACKING SHEET - 3.15 THK	TATA spare parts
288331208202	PACKING SHEET - 1.6 THK	TATA spare parts
288331700103	ASSY.TRANSMISSION SHIELD(FRT. SIDE)	TATA spare parts
288331700104	ASSY SUPPORT BRACKET(TRANS. RR SIDE)-LH	TATA spare parts
288332600101	ASSY.REAR SHOCK ABSORBER MTG.BRACKET(RH)	TATA spare parts
288332600102	ASSY.REAR SHOCK ABSORBER MTG.BRACKET(LH)	TATA spare parts
288333000101	ASSY. FRONT AXLE COMP. WITH BRAKES	TATA spare parts
288341100101	ASSY. PROP. SHAFT FR.	TATA spare parts
288341120101	ASSY. PROP. SHAFT RR	TATA spare parts
288341303301	SPACER BRACKET (FOR CENTER BEARING)	TATA spare parts

288342100122	ASSY. F/A BRAKE RH WITH DUST COVER	TATA spare parts
288342100123	ASSY. F/A BRAKE LH WITH DUST COVER	TATA spare parts
288342100131	ASSY. F/A BRAKE RH WITH DUST COVER	TATA spare parts
288342100132	ASSY. F/A BRAKE LH WITH DUST COVER	TATA spare parts
288342100165	ASSY FRONT BRAKE RH WITH D/C RAF7 LINING	TATA spare parts
288342100169	ASSY FRONT BRAKE LH WITH D/C.RAF7 LINING	TATA spare parts
288342100174	F/A BRK W/DC-LH 410X160	TATA spare parts
288342100175	F/A BRK W/DC-RH 410X160	TATA spare parts
288342300121	ASSY. R/A BRAKE RH WITH DUST COVER	TATA spare parts
288342300122	ASSY. R/A BRAEK LH WITH DUST COVER	TATA spare parts
288342300130	ASSY. R/A BRAEK RH WIITH DUST COVER	TATA spare parts
288342300131	ASSY. R/A BRAEK LH WITH DUST COVER	TATA spare parts
288342300203	ASSY.REAR BRAKE-L.H W/T D/C	TATA spare parts
288342300204	ASSY.REAR BRAKE-R.H W/T D/C	TATA spare parts
288349200101	ASSY BRACKET	TATA spare parts
288349200102	ASSY EXHAUST SECOND PIPE	TATA spare parts
288349200103	ASSY EXHAUST FIRST PIPE COMPLETE	TATA spare parts
288349200104	ASSY BRACKET	TATA spare parts
288349206903	TAIL PIPE	TATA spare parts
288349208202	CLAMP (EXHAUST MTG.)	TATA spare parts
288349208203	CLAMP (EXHAUST MTG.)	TATA spare parts
288349208204	CLAMP (EXHAUST MTG.)	TATA spare parts
288354660101	W/H MAIN (LP1615/52,697,BS-III)	TATA spare parts
288431000102	ASSY.FRAME COMPLETE	TATA spare parts
288431200103	ASSY. END CROSS MEMBER	TATA spare parts
288431700102	ASSY.BOTTOM SHIELD (ENGINE SIDE)	TATA spare parts
288431700103	ASSY TRANS. SHIELD(FRT. SIDE)	TATA spare parts
288431700104	ASSY. TRANS. SHIELD (REAR SIDE)	TATA spare parts
288431700105	ASSY. SUPPORT BRACKET-ENG. REAR SIDE	TATA spare parts
288431700107	ASSY. SUPPORT BRACKET-FRT.TRANS.SIDE-LH	TATA spare parts
288431700108	ASSY. SUPPORT BRACKET-FRT. TRANS. SIDE	TATA spare parts
288431700112	ASSY. SUPPORT BRACKET (ENGINE SIDE-LH)	TATA spare parts
288431700113	ASSY.BRACKET FRONT (ENGINE SIDE-RH)	TATA spare parts
288431700114	ASSY. SUPPORT BRACKET (TRANS.FRONT-RH)	TATA spare parts
288431700115	ASSY. SUPPORT BRACKET(TRANS.REAR-RH)	TATA spare parts
288431700116	ASSY. SUPPORT BRACKET (TRANS. REAR LH)	TATA spare parts
288431700117	ASSY. SUPPORT BRACKET (FRT.ENGINE SIDE)	TATA spare parts
288431700118	ASSY. BOTTOM SHIELD - ENGINE SIDE	TATA spare parts
288431700119	ASSY. TRANSMISSION SHIELD (FRONT SIDE)	TATA spare parts
288431700120	ASSY. TRANS. SHIELD (REAR SIDE)	TATA spare parts
288431700122	ASSY.BOTTOM SHIELD (RADIATOR SIDE)	TATA spare parts
288441100101	FRONT PROPELLER SHAFT LPT 1618/52	TATA spare parts
288441100102	REAR PROPELLER SHAFT LPT 1618/52	TATA spare parts
288441303301	SPACER BRACKET(CENTRE BEARING)	TATA spare parts
288443200102	ASSY. BRACKET (AIR TANK MTG. REAR)	TATA spare parts
288443700104	QUICK RELEASE VALVE(3 PORT VOSS)	TATA spare parts
288443700105	GRADUATED HAND BRAKE VALVE	TATA spare parts

288443900106	ASSY. PIPE (SECOND PIPE ON COMPRESSOR)	TATA spare parts
288443900107	ASSY. PIPE (THIRD PIPE ON COMPRESSOR)	TATA spare parts
288443900112	ASSY. NYLON PIPE SET COMPLETE (VOSS) RHD	TATA spare parts
288454500101	ASY.COMBI.SW.LHD(W/HORN SW.ON STALK)	TATA spare parts
288454620103	WIRING HARNESS MAIN	TATA spare parts
288454620104	WIRING HARNESS TAIL	TATA spare parts
288500990101	KIT C-SL SHELL+INST.CLST+WINDSHIELD+WIND	TATA spare parts
288500990102	KIT C-SL SHELL+D/B+COMP.I/TRIMS+COMP.W/H	TATA spare parts
288524100101	ASSY FRONT ENGINE MOUNT	TATA spare parts
288524100101AE	ASSY FRONT ENG MOUNT -1628-1828	TATA spare parts
288524105101	ENGINE MOUNTING ARM RH-FRONT	TATA spare parts
288524105101AE	ENG MNTNG ARM RH-FRT -1628-1828	TATA spare parts
288524105103	ENGINE MOUNTING ARM LH-FRONT	TATA spare parts
288524105103AE	ENG MNTNG ARM RH-FRT -1628-1828	TATA spare parts
288524203701	ENG MTG BRKT REAR FRAME	TATA spare parts
288524203702	BRKT-ENG MTG RR F/W HSG	TATA spare parts
288524203702AE	"BRKT-ENG MTG RR,FW HSG-1628-1828"	TATA spare parts
288524203703	BRKT-ENG MTG RR F/W HSG	TATA spare parts
288524203703AE	"BRKT-ENG MTG RR,FW HSG-1628-1828"	TATA spare parts
288526708201	DUST CAP	TATA spare parts
288526710101	ASSY PRESSURE REGULATOR(4BAR)	TATA spare parts
288526710102	ASSY PRESSURE REGULATOR(4BAR)	TATA spare parts
288526715101	SHIFTING AND SELECTION LEVER	TATA spare parts
288526800101	ASSY. PIVOT LEVER	TATA spare parts
288526800102	ASSY SELECTION LEVER WITH MOUNTING BKT	TATA spare parts
288526800105	ASSY ANCHOR PLATE (CABLE)	TATA spare parts
288526800108	ASSY. GEAR SHIFT CABLE COMPLETE	TATA spare parts
288526800109	ASSY. GEAR SELECT CABLE COMPLETE	TATA spare parts
288526800110	GEAR SHIFT CABLE	TATA spare parts
288526800111	GEAR SELECT CABLE	TATA spare parts
288526800112	ASSY. GEARSHIFT UNIT WITH CABLES	TATA spare parts
288526800114	ASSY. GEAR SHIFT UNIT W/CABLES	TATA spare parts
288526800115	ASSY GEAR SHIFT CABLE COMP.	TATA spare parts
288526800116	ASSY. GEAR SELECT CABLE COMP.	TATA spare parts
288526800117	ASSY BRACKET (SERVO CYLINDER)	TATA spare parts
288526800124	ASSY. MOUNTING BRACKET (SELECTION CABLE)	TATA spare parts
288526800126	SHIFT CABLE	TATA spare parts
288526800127	SELECT CABLE	TATA spare parts
288526800128	GEARSHIFT UNIT WITH CABLES	TATA spare parts
288526800131	ASSY BRACKET (SELECTION CABLE ANCHORING)	TATA spare parts
288526800132	ASSY SELECTION LEVER AND MOUNTING BRACKET	TATA spare parts
288526800133	BRACKET SELECTION CABLE	TATA spare parts
288526801602	ST. CONNECTOR (QUICK FIX) 8OD METRN	TATA spare parts
288526801604	STRAIGHT CONNECTOR 4 OD M5	TATA spare parts
288526801605	ADAPTOR BREATHER ADAPTOR M10 X 1.0	TATA spare parts
288526803701	BRACKET (SELECT CABLE ANCHOR)	TATA spare parts
288526803702	BRACKET (SHIFT CABLE ANCHOR)	TATA spare parts



288526803703	BRACKET ( SHIFTING LEVER )	TATA spare parts
288526803706	MOUNTING BRACKET (SHIFT CABLE)	TATA spare parts
288526803707	BRACKET FOR SHIFT & SELECT CABLE ROUTING	TATA spare parts
288526803709	BRACKET CABLE SHIFT	TATA spare parts
288526803711	BRACKET CABLE SHIFT	TATA spare parts
288526803712	BRACKET	TATA spare parts
288526806501	CONNECTOR (SHIFT CABLE)	TATA spare parts
288526806801	ELBOW CONNECTOR (QUICKFIX TYPE)	TATA spare parts
288526806802	ST CONNECTOR (QUICKFIX TYPE)	TATA spare parts
288526806803	ST. CONNECTOR	TATA spare parts
288526808217	OIL COOLER HOSE CLAMP BKT	TATA spare parts
288526808217AE	HOSE CLAMPING BRKT 1628	TATA spare parts
288526808602	SPACER	TATA spare parts
288526900101	ASSY. HOSE - OIL IN	TATA spare parts
288526900102	ASSY. HOSE - OIL OUT	TATA spare parts
288526900104	RETRO KIT PRESSURE REGULATOR	TATA spare parts
288526908201	CLAMP - OIL COOLER HOSE	TATA spare parts
288526908202	BRACKET - (CLAMP OIL COOLER)	TATA spare parts
288526908203	BRACKET RH ( OIL COOLER MOUNTING)	TATA spare parts
288526908204	BRACKET LH (OIL COOLER MOUNTING)	TATA spare parts
288528990101	BRACKET ASSY	TATA spare parts
288529000101	ASSY. INTEGRATED PEDAL UNIT (TYPE-1)	TATA spare parts
288529000106	ASSY. INTEGRATED PEDAL UNIT (TYPE-2)	TATA spare parts
288529000107	ASSY. INTEGRATED PEDAL UNIT (TYPE-1)	TATA spare parts
288529000109	INTEGRATED PEDAL UNIT	TATA spare parts
288529100101	ASSY. PIPE COMPLETE FROM MASTER CYLINDER	TATA spare parts
288529100102	ASSY. PIPE COMPLETE FROM MASTER CYLINDER	TATA spare parts
288529100102AE	ASSY. PIPE COMPL. -1628-1828	TATA spare parts
288529100109	ASSY.PIPE FROM MASTER CYLINDER BS3/4	TATA spare parts
288529103301	CLUTCH BOOSTER MTG.BRACKET	TATA spare parts
288529103301AE	CL BOOSTER MNTNG BRKT(GRBOX-1628	TATA spare parts
288529103302	CLUTCH BOOSTER MTG BKT (G1400 GEARBOX)	TATA spare parts
288529106801	ELBOW FOR CLUTCH BOOSTER	TATA spare parts
288529107102	CLAMPING PLATE	TATA spare parts
288529300103	REPAIR KIT FOR PUSH ROD & FORK	TATA spare parts
288529300103C1	KIT PART-AC TRACTOR VEHICLE (4023.S & 49	TATA spare parts
288529300103C2	KIT PART-NON AC TRACTOR& VEHICLE (4023.S	TATA spare parts
288529300103C3	KIT PART-TIPPER	TATA spare parts
288529990101	SPARE KIT ASSY CLUTCH BOOSTER (TYPE-1)	TATA spare parts
288529990103	MINOR KIT ASSY. IPU(TYPE-1)	TATA spare parts
288531000101	ASSY.FRAME	TATA spare parts
288531000109	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
288531000110	FRAME ASSY	TATA spare parts
288531107103	STIFFNER LH	TATA spare parts
288531107104	STIFFNER-RH	TATA spare parts
288531107105	L REINFORCEMENT CRANK REGION-RH	TATA spare parts
288531107106	L-REINFORCEMENT CRANK REGION-LH	TATA spare parts

288531107121	REINFORCEMENT LH	TATA spare parts
288531107123	REINFORCEMENT RH	TATA spare parts
288531200102	ASSY END CROSS MEMBER	TATA spare parts
288531200103	ASSY 5TH C/MBR WITH GUSSET	TATA spare parts
288531200107	ASSY ENG MTG CROSS MEMBER	TATA spare parts
288531207104	C/MBR 5TH	TATA spare parts
288531207105	CROSS MEMBER END	TATA spare parts
288531207106	STIFFNER	TATA spare parts
288531207107	ENG MTG C/MBR OUTER PIECE	TATA spare parts
288531307105	GUSSET END UPPER LH	TATA spare parts
288531307106	GUSSET END UPPER RH	TATA spare parts
288531307108	LOWER GUSSET-5TH C/M	TATA spare parts
288531307111	UPPER GUSSET-5TH C/M	TATA spare parts
288531307112	GUSSET END LOWER RH	TATA spare parts
288531307113	GUSSET END LOWER-LH	TATA spare parts
288531307125	FRONT ENG. MTG. C/M BRACKET-LH	TATA spare parts
288531307126	FRONT ENG MTG C/M BRACKET-RH	TATA spare parts
288531307127	END C/M GUSSET - LH	TATA spare parts
288531307128	END C/M GUSSET - RH	TATA spare parts
288531540102	BATTERY MTG ASSY WITH SPACER	TATA spare parts
288531700101	ASSY FRONT UNDERRUN PROTECTION DEVICE	TATA spare parts
288531700102	ASSY CROSS MEMBER (FUPD)	TATA spare parts
288531700104	ASSY CLAMP & RUBBER PAD	TATA spare parts
288531700105	ASSY RUBBERPAD & BRACKET	TATA spare parts
288531700106	ASSY WHEEL CHOCK BRACKET	TATA spare parts
288531700107	ENGINE SHIELD ASSEMBLY	TATA spare parts
288531700109	FAB OF BRACKET FOR W/T ASSY FRONT BUMP	TATA spare parts
288531700110	ASSY BRACKET-CHASSIS PLATE	TATA spare parts
288531700111	ASSY HEAT SHIELD FOR TURBO CHARGER/EXHAU	TATA spare parts
288531700112	ASSY CHASSIS PLATE FRONT	TATA spare parts
288531700113	ASSY BKT FOR TOW HOOK MTG IN CAB	TATA spare parts
288531700130	FUPD CROSS BEAM ASSY	TATA spare parts
288531707106	CLAMP FOR WHEEL CHOCK	TATA spare parts
288531707107	C BRACKET WHEEL CHOCK	TATA spare parts
288531707110	STIFFNER REAR BUMP	TATA spare parts
288531707111	STFNR B/RUB FRT	TATA spare parts
288531707701	SHIELD UNDER ENGINE	TATA spare parts
288531707702	SHIELD UNDER CLUTCH HOUSING	TATA spare parts
288531707703	SHIELD UNDER TRANSMISSION	TATA spare parts
288531707704	RUBBER PAD FOR WHEEL CHOCK CLAMP	TATA spare parts
288531708205	BRACKET FOR NOISE SHIELD	TATA spare parts
288531708210	J CLAMP NOISE SHIELD	TATA spare parts
288531708213	CLAMP PLATE(FOR TOW HOOK MTG IN CAB)	TATA spare parts
288531708216	BRACKET FOR NOISE SHIELD-RH	TATA spare parts
288531909902	LABEL - CUSTOMER ASSISTANCE BS6-PH2	TATA spare parts
288531909903	LABEL - BS3	TATA spare parts
288532100101	TAPER LEAF SPRING ASSY. FRONT	TATA spare parts

288532100102	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
288532100102AE	ASSY FIRST LEAF WITH BUSH 1628	TATA spare parts
288532100102DF	MAIN LEAF FRONT PARA-3718/4223/4825	TATA spare parts
288532100103	SHACKLE ASSY.	TATA spare parts
288532100103AE	SHACKLE ASM 1628	TATA spare parts
288532100104	ASSY CLAMP PLATE U BOLT	TATA spare parts
288532100106	TAPER LEAF SPRING ASSY. FRONT	TATA spare parts
288532103202	HEX FLANGE BOLT	TATA spare parts
288532103203	HEX FLANGE BOLT M14X1.5X55	TATA spare parts
288532103204	HEX FLANGE BOLT	TATA spare parts
288532103205	HEX FLANGE BOLT	TATA spare parts
288532103206	HEX BOLT M14X1.5X65	TATA spare parts
288532103303	BRACKET FRT SPRING FRT	TATA spare parts
288532103303AE	BRKT-FRT SPRING FRT 1628	TATA spare parts
288532103305	BRKT - FRT SPRING REAR LH	TATA spare parts
288532103306	BRKT - FRT SPRING REAR RH	TATA spare parts
288532103403	BUSH	TATA spare parts
288532104201	CLIP	TATA spare parts
288532104202	U BOLT FRT- SPRING	TATA spare parts
288532104203	U BOLT FRONT SPRING	TATA spare parts
288532106501	HEX FLANGE NUT	TATA spare parts
288532106502	HEX FLANGE NUT	TATA spare parts
288532106503	HEX FLANGE NUT	TATA spare parts
288532106506	HEX. FL NUT M10X1.5	TATA spare parts
288532107101	FIRST LEAF	TATA spare parts
288532107102	SECOND LEAF	TATA spare parts
288532107102AE	SECOND LEAF 1628	TATA spare parts
288532107102DF	SECOND LEAF FRONT PARA-3718/4223/4825	TATA spare parts
288532107103	THIRD LEAF	TATA spare parts
288532107103AE	THIRD LEAF 1628	TATA spare parts
288532107103DF	THIRD LEAF FRONT PARA-3718/4223/4825	TATA spare parts
288532107401	RIVET	TATA spare parts
288532108601	CLIP PIPE	TATA spare parts
288532108605	CENTRAL LINER	TATA spare parts
288532109001	WASHER SPRING PIN	TATA spare parts
288532300101	SHOCK ABSORBER FRONT	TATA spare parts
288532300103	ASSY. FRONT SHOCK ABSORBER BS3/4/6	TATA spare parts
288532300104	SHOCK ABSORBER ASSY FRONT	TATA spare parts
288532303201	HEX BOLT M22X1.5X150	TATA spare parts
288532303202	HEX BOLT M22X1.5X165	TATA spare parts
288532303303	BRACKET SHOCK ABSORBER UPPER	TATA spare parts
288532303306	BRKT-S/ABS LWR(LH)	TATA spare parts
288532303307	BRKT-S/ABS LWR(RH)	TATA spare parts
288532306501	HEX NUT M22X1.5 8 IS 1367	TATA spare parts
288532309201	SPRING WASHER	TATA spare parts
288532309202	SPRING WASHER	TATA spare parts
288532309203	WASHER	TATA spare parts

288532400101	ASSY. REAR SPRING	TATA spare parts
288532400102	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
288532400103	ASSY. REAR SHACKLE	TATA spare parts
288532400105	ASSY. BUMP STOPPER	TATA spare parts
288532400110	SPRING ASSY LPS 4438	TATA spare parts
288532403201	HEX BOLT M14X1.5	TATA spare parts
288532403202	HEX BOLT M14X1.5	TATA spare parts
288532403203	HEX BOLT M14X1.5	TATA spare parts
288532403301	SPRING HANGER BRACKET REAR-SPRING	TATA spare parts
288532403302	HELPER SPRING BRACKET	TATA spare parts
288532403304	GUIDE PLATE	TATA spare parts
288532403401	SPRING BUSH	TATA spare parts
288532403701	SUPPORT PLATE	TATA spare parts
288532404201	SPRING CLIP	TATA spare parts
288532404202	SPRING CLIP	TATA spare parts
288532404203	SPRING CLIP	TATA spare parts
288532404204	AUX CLIP	TATA spare parts
288532404205	U BOLT REAR SPRING	TATA spare parts
288532406501	HEX NUT M24 X 2 GR 10	TATA spare parts
288532406701	SPRING PIN	TATA spare parts
288532407101	FIRST LEAF(MAIN SPRING)	TATA spare parts
288532407102	SECOND LEAF SPRING	TATA spare parts
288532407103	THIRD LEAF	TATA spare parts
288532407104	FORTH LEAF	TATA spare parts
288532407105	FIFTH LEAF	TATA spare parts
288532407106	SIXTH LEAF	TATA spare parts
288532407107	SEVENTH LEAF	TATA spare parts
288532407108	EIGHTH LEAF	TATA spare parts
288532407109	NINTH LEAF	TATA spare parts
288532407110	FIRST LEAF	TATA spare parts
288532407111	SECOND LEAF	TATA spare parts
288532407112	THIRD LEAF	TATA spare parts
288532407113	FORTH LEAF	TATA spare parts
288532407114	FIFTH LEAF	TATA spare parts
288532407115	SIXTH LEAF	TATA spare parts
288532407116	SEVENTH LEAF	TATA spare parts
288532407117	EIGHTH LEAF	TATA spare parts
288532407122	LEAF NO 4	TATA spare parts
288532407123	LEAF NO 5	TATA spare parts
288532407124	LEAF NO 6	TATA spare parts
288532407125	LEAF NO 7-MAIN LEAF	TATA spare parts
288532407126	LEAF NO 8-MAIN SPRING	TATA spare parts
288532407127	LEAF NO 9-MAIN SPRING	TATA spare parts
288532407128	LEAF NO 10-MAIN SPRING	TATA spare parts
288532407129	LEAF NO 4-AUX SPRING	TATA spare parts
288532407130	LEAF NO 5-AUX SPRING	TATA spare parts
288532407131	LEAF NO 6-AUX SPRING	TATA spare parts

288532407132	LEAF NO 7-AUX SPRING	TATA spare parts
288532407133	LEAF NO 8-AUX SPRING	TATA spare parts
288532407134	NINETH LEAF-AUX SPRING	TATA spare parts
288532408601	SPACER (LEAF SPRING CLIP)	TATA spare parts
288532408602	SPACER (LEAF SPRING CLIP)	TATA spare parts
288532408603	WASHER	TATA spare parts
288532803302	BRACKET (ANTI ROLL BAR MTG)	TATA spare parts
288532803303	BRKT-STABILIZER;AXLE	TATA spare parts
288532803303AE	BRKT-STABILIZER; AXLE 1628	TATA spare parts
288532803304	BRACKET ANTIROLLBAR MOUNTING	TATA spare parts
288532803304AE	BRKT (ANTIROLL BAR MNTNG) -1628	TATA spare parts
288532806701	PIN STABILISER	TATA spare parts
288532806701AE	PIN-STABILIZER 1628	TATA spare parts
288532806704	PIN STABILIZER	TATA spare parts
288532807101	ROD STABILISER	TATA spare parts
288532807102	PLATE STABILIZER	TATA spare parts
288532807102AE	PLATE-STABILIZER 1628	TATA spare parts
288532807501	BUSH STABILIZER AXLE	TATA spare parts
288532807501AE	BUSH-STABILIZER;AXLE 1628	TATA spare parts
288532807502	BUSH STABILISER FRAME	TATA spare parts
288532807502AE	BUSH-STABILIZER;FRAME 1628	TATA spare parts
288532807901	STABILISER BAR FRONT	TATA spare parts
288532807903	ANTIROLL BAR	TATA spare parts
288532807904	ANTIROLL BAR	TATA spare parts
288532807905	ANTIROLL BAR	TATA spare parts
288533000101	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
288533000105	ASSY. FRONT AXLE TML BEAM 7.5T 6.5 DEG W	TATA spare parts
288533000108	FRONT AXLE ASSY 7.5T 6.5DEG.	TATA spare parts
288533105101	FRONT AXLE BEAM 7.5T 6.5DEG.	TATA spare parts
288533105102	FRONT AXLE BEAM BS6	TATA spare parts
288533200101	ASSY. STUB AXLE LH	TATA spare parts
288533200102	ASSY. STUB AXLE RH	TATA spare parts
288533203101	KING PIN THRUST BEARING BS2/3/4	TATA spare parts
288533203102	THRUST BEARING-TEXSPIN BRG.	TATA spare parts
288533203201	BOLT M22X1.5 -TIE ROD ARM FIX	TATA spare parts
288533203202	HEX BOLT FOR STEERING ARM	TATA spare parts
288533203203	HEX BOLT FOR STEERING ARM	TATA spare parts
288533203402	BUSH KING PIN 50 UPR	TATA spare parts
288533203403	BUSH KING PIN 62 LWR	TATA spare parts
288533203406	BUSH KING PIN 50 UPR-I BS2/3/4	TATA spare parts
288533203407	BUSH KING PIN 62 LWR-I	TATA spare parts
288533205101	KNUCKLE LH 6.5 DEG	TATA spare parts
288533205102	KNUCKLE RH 6.5 DEG	TATA spare parts
288533206501	NUT FOR TIE ROD ARM	TATA spare parts
288533206503	LOCK NUT	TATA spare parts
288533206701	KING PIN BS 2/3/4	TATA spare parts
288533206702	THREADED COTTER PIN	TATA spare parts

288533207101	COVER KING PIN UPPER	TATA spare parts
288533207102	COVER KING PIN LWR	TATA spare parts
288533207701	O-RING KING PIN UPPER	TATA spare parts
288533207702	O-RING LOWER KING PING COVER	TATA spare parts
288533207801	OIL SEAL KING PIN	TATA spare parts
288533209201	THRUST WASHER KNUCKLE	TATA spare parts
288533209202	THRUST WASHER KNUCKLE	TATA spare parts
288533209203	THRUST WASHER KNUCKLE	TATA spare parts
288533209204	THRUST WASHER KNUCKLE	TATA spare parts
288533209205	THRUST WASHER KNUCKLE	TATA spare parts
288533209206	THRUST WASHER KNUCKLE	TATA spare parts
288533209207	THRUST WASHER KNUCKLE	TATA spare parts
288533209208	THRUST WASHER KNUCKLE	TATA spare parts
288533400101	ASSY.HUB & BOLT	TATA spare parts
288533400102	ASSY.WHEEL HUB FRONT COMPLETE	TATA spare parts
288533403103	CONE HUB BEARING OUTER BS2/3/4	TATA spare parts
288533403104	CONE HUB BRG INNER TR 6814232 BS2/3/4	TATA spare parts
288533404301	SNAP RING	TATA spare parts
288533405301	PACKING HUB CAP	TATA spare parts
288533405505	WHEEL HUB FRONT	TATA spare parts
288533405506	WHEEL HUB FRONT W/O POLE WHEEL	TATA spare parts
288533406501	NUT BRG.FRONT HUB	TATA spare parts
288533407801	COVER HUB BRG.INNER	TATA spare parts
288533407802	OIL SEAL FRONT WHEEL HUB BS2/3/4	TATA spare parts
288533407803	OIL SEAL WHEEL HUB FRONT	TATA spare parts
288533408201	HUB CAP FRONT	TATA spare parts
288533408301	SHIMS FR HUB OD 64 X ID 50.35 THK 1.5	TATA spare parts
288533408302	SHIMS FR HUB OD 64 X ID 50.35 THK 1.0	TATA spare parts
288533408303	SHIMS FR HUB OD 64 X ID 50.35 THK 0.5	TATA spare parts
288533408304	SHIMS FRONT HUB	TATA spare parts
288533408305	SHIMS FR HUB OD 64 X ID 50.35 THK 0.1	TATA spare parts
288533408307	SHIMS FR HUB OD 64 X ID 50.35 THK 0.15	TATA spare parts
288533408308	SHIMS FR HUB OD 64 X ID 50.35 THK 0.25	TATA spare parts
288533408309	SHIM FRONT HUB 0.85 MM	TATA spare parts
288533408310	SHIM FRONT HUB 0.90 MM	TATA spare parts
288533408311	SHIM FRONT HUB 0.95 MM	TATA spare parts
288533408312	SHIM FRONT HUB 1.05 MM	TATA spare parts
288533408313	SHIM FRONT HUB 1.10 MM	TATA spare parts
288533408314	SHIM FRONT HUB 1.15 MM	TATA spare parts
288533408315	SHIM FRONT HUB 1.20 MM	TATA spare parts
288533408316	SHIM FRONT HUB 1.25 MM	TATA spare parts
288533408317	SHIM FRONT HUB 1.30MM	TATA spare parts
288533408318	SHIM FRONT HUB 1.35 MM	TATA spare parts
288533408319	SHIM FRONT HUB 1.40 MM	TATA spare parts
288533408320	SHIM FRONT HUB 1.45 MM	TATA spare parts
288533408321	SHIM FRONT HUB 1.55 MM	TATA spare parts
288533408322	SHIM FRONT HUB 1.60 MM	TATA spare parts

288533408323	SHIM FRONT HUB 1.65 MM	TATA spare parts
288533408601	SPACER TUBE FRONT HUB	TATA spare parts
288533409201	LOCK WASHER BRG HUB OD 100X7	TATA spare parts
288533409202	LOCK WASHER BRG.NUT	TATA spare parts
288533800102	ASSY. TIE ROD BS2/3	TATA spare parts
288533800106	TIE ROD ASSEMBLY¿ FRONT FORWARD AXLE	TATA spare parts
288533800107	TIE ROD ASSEMBLY¿ FRONT REARWARD AXLE	TATA spare parts
288533800108	TIE ROD END ASSY. R.H.	TATA spare parts
288533800109	TIE ROD END ASSY. L.H.	TATA spare parts
288533805101	KNUCKLE ARM LH SIDE	TATA spare parts
288533805102	KNUCKLE ARM RH SIDE	TATA spare parts
288533805103	TIE ROD ARM LH	TATA spare parts
288533805104	TIE ROD ARM RH	TATA spare parts
288533990101	TIE ROD END RH	TATA spare parts
288533990102	TIE ROD END LH	TATA spare parts
288541100101	ASSY PROPELLER SHAFT MAIN	TATA spare parts
288541100105	ASSY PROP SHAFT MAIN	TATA spare parts
288541100106	ASSY PROPELLER SHAFT MAIN	TATA spare parts
288541110101	UNIT PACK	TATA spare parts
288541110102	UNIVERSAL JOINT BS3/4	TATA spare parts
288541115101	FLANGE YOKE	TATA spare parts
288541115102	FLANGE YOKE	TATA spare parts
288541120101	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
288541990107	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
288542300104	ASSY. REAR AXLE BRAKE LH WITH DUST COVER	TATA spare parts
288542300105	ASSY. REAR AXLE BRAKE WITH DUST COVER RH	TATA spare parts
288542300106	ASSY. REAR AXLE BRAKE WITH DUST COVER	TATA spare parts
288542300107	ASSY. REAR AXLE BRAKE RH WITH DUST COVER	TATA spare parts
288543200112	ASSY. AIR TANK (20L)	TATA spare parts
288543200114	ASSY. PARKING AIR TANK (20L) COMPLETE	TATA spare parts
288543200115	SUB. ASSY AIR TANK (20 LIR.) W/BACKET	TATA spare parts
288543200116	ASSY. NYLON PIPE BUNCH HOLDING BKT	TATA spare parts
288543200117	ASSY.NYLON PIPE BUNCH HOLDING BRACKET LH	TATA spare parts
288543208201	OIL SEPERATOR BRACKET	TATA spare parts
288543208215	BRACKET TO SUPPORT NYLON PIPE	TATA spare parts
288543400101	ASSY. BRACKET (LCRV ON AXLE)	TATA spare parts
288543400102	ASSY. PULL ROD	TATA spare parts
288543503301	LCRV & TCV MTG. BRACKET	TATA spare parts
288543700122	DUAL BRAKE VALVE FOR TRACTORS	TATA spare parts
288543700122AE	DUAL BRAKE VALVE TRACTORS -1828	TATA spare parts
288543900101	ASSY. NYLON PIPES & CLAMPS	TATA spare parts
288543900115	ASSY. NYLON PIPE TEE 5 TO R-14	TATA spare parts
288543900119	ASSY. NYLON PIPE DBV PORT 22 TO TEE 1	TATA spare parts
288543900120	ASSY. NYLON PIPE DBV PORT 21 TO TEE 4	TATA spare parts
288543900121	ASSY. NYLON PIPE DBV PORT 12 TO AIR TANK	TATA spare parts
288543900122	ASSY. NYLON PIPE DBV PORT 11 TO TEE 6	TATA spare parts
288543900123	ASSY. NYLON PIPE TEE 3 TO TCV PORT 42	TATA spare parts

288543900124	ASSY. NYLON PIPE TEE 1 TO TEE 3	TATA spare parts
288543900125	ASSY. NYLON PIPE TEE 3 TO FRONT LH MV	TATA spare parts
288543900126	ASSY. NYLON PIPE TEE 1 TO FRONT RH MV	TATA spare parts
288543900127	ASSY. NYLON PIPE TEE 4 TO TEE 7	TATA spare parts
288543900128	ASSY. NYLON PIPE TEE 7 TO TCV PRT 41	TATA spare parts
288543900129	ASSY. NYLON PIPE TEE 7 TO R-14	TATA spare parts
288543900134	ASSY. NYLON PIPE AIR TANK FRONT TO TEE 5	TATA spare parts
288543900136	ASSY. NYLON PIPE TCV PORT 23 TO HBV	TATA spare parts
288543900137	ASSY. NYLON PIPE HBV TO TEE 2	TATA spare parts
288543900138	ASSY. NYLON PIPE R-14 TO HBV	TATA spare parts
288543900139	ASSY. METAL PIPE	TATA spare parts
288543900140	ASSY. METAL PIPE (SECOND)	TATA spare parts
288543900142	ASSY. METAL PIPE (FIRST)	TATA spare parts
288543900149	ASSY. NYLON PIPE TEE 4 TO LCRV PORT 1	TATA spare parts
288543900150	ASSY. NYLON PIPE ANTICOMPOUNDIN RELAY VA	TATA spare parts
288543900153	ASSY. NYLON PIPE HBV PORT 22 TO VOSS ADA	TATA spare parts
288543900154	ASSY. NYLON PIPE HBV PORT 1 TO VOSS ADAP	TATA spare parts
288543900155	ASSY. NYLON PIPE HBV PORT 21 TO VOSS ADA	TATA spare parts
288543900157	BUNCH ASSY PIPE	TATA spare parts
288543900163	ASSY METAL PIPE FROM APU TO TURBO CHECK	TATA spare parts
288543900164	ASSY METAL PIPE TURBO CHECK VALVE TO OI	TATA spare parts
288543900166	ASSY. METAL PIPE( FROM HOSE END TO OIL S	TATA spare parts
288543900193	ASSY. NYLON PIPE FROM APU TO OIL SEPERAT	TATA spare parts
288543900196	ASSY CLAMP (DIA 50)	TATA spare parts
288543900198	ASSY. METAL PIPE FROM 1ST METAL PIPE TO	TATA spare parts
288543900204	ASSY. NYLON PIPE NON RETURN VALVE (PARKI	TATA spare parts
288543900222	NYLON PIPE APU TO PRESSURE REDUCTION VAL	TATA spare parts
288543900230	ASSY. NYLON PIPE EXHAUST BRAKE SOLENOID	TATA spare parts
288543900232	ASSY. NYLON PIPE AUXILIARY AIR TANK TO T	TATA spare parts
288543900233	ASSY. NYLON PIPE TEE-10 TO CLUTCH BOOSTE	TATA spare parts
288543900234	ASSY. NYLON PIPE TEE-10 TO TEE-11	TATA spare parts
288543900235	ASSY. NYLON PIPE TEE-11 TO EXHAUST BRAKE	TATA spare parts
288543900236	ASSY. NYLON PIPE TEE-11 TO TEE-13	TATA spare parts
288543900237	ASSY. NYLON PIPE TEE-12 TO TEE-14	TATA spare parts
288543900239	ASSY. NYLON PIPE TEE-13TO AIR SUSPENDE	TATA spare parts
288543900240	ASSY. NYLON PIPE TEE-13 TO STEERING	TATA spare parts
288543900241	ASSY. NYLON PIPE TEE-2 TO NRV (PARKING)	TATA spare parts
288543900242	ASSY. NYLON PIPE PARKING AIR TANK TO PRV	TATA spare parts
288543900243	ASSY. NYLON PIPE TEE- 8 TO SBA (LH) PORT	TATA spare parts
288543900244	ASSY. NYLON PIPE TEE- 8 TO SBA (RH) PORT	TATA spare parts
288543900245	ASSY. NYLON PIPE DBV(12) TO PRESSURE SE	TATA spare parts
288543900249	INSULATION ALUMINIUM SLEEVE	TATA spare parts
288543900251	ASSY. NYLON PIPE P.V.R. AUXILIARY AIR TA	TATA spare parts
288543900253	ASSY. NYLON PIPE TCV PORT 12 TO PALM COU	TATA spare parts
288543900254	ASSY. NYLON PIPE TCV 22 TO PALM COUPLING	TATA spare parts
288543900260	CORRUGATED TUBE (O.D. 42X2.0 LENGTH 5	TATA spare parts
288543900261	CORRUGATED TUBE (O.D. 42X2.0 LENGTH 3	TATA spare parts



288543900269	ASSY. NYLON PIPE APU(24) TO NRV	TATA spare parts
288543900270	ASSY. NYLON PIPE TEE-10 TO TEE-12	TATA spare parts
288543900271	ASSY NYLON PIPE TEE-14 TO RANGE CYLINDER	TATA spare parts
288543900272	ASSY NYLON PIPE TEE-14 TO MAGNETIC VALVE	TATA spare parts
288543900273	ASSY NYLON PIPE MAGNETIC VALVE TO PRESSU	TATA spare parts
288543900274	ASSY NYLON PIPE PRESSURE REGULATOR TO SE	TATA spare parts
288543900307	ASSY. NYLON PIPE SET FOR LPS4028	TATA spare parts
288543900362	BUNCH ASSY PIPE	TATA spare parts
288543900363	METAL PIPE ASSY	TATA spare parts
288543904202	CLAMP (DIA 50)	TATA spare parts
288543906801	SOCKET	TATA spare parts
288543910150	METAL PIPE ASSY JOINT-4 TO COMPRESSOR EN	TATA spare parts
288546107101	PLATE-RUBBER COATED	TATA spare parts
288546600101	ASSY. POWER STG GEAR PUMP(TYPE I) BS3/4	TATA spare parts
288546600101AE	PWR STEERING PUMP ISBE 1628/1828	TATA spare parts
288546600102	PUMP ISBE	TATA spare parts
288546600103	POWER STEERING PUMP ASSEMBLY	TATA spare parts
288546600104	STEERING GEAR PUMP	TATA spare parts
288546600105	ISBE GEAR PUMP TYPE-II	TATA spare parts
288546800101	PERSSURE LINE HOSE & PIPE ASSY GEAR BOX	TATA spare parts
288546800102	SUCTION LINE HOSE & PIPE ASSY	TATA spare parts
288546800110	AUXILIARY PIPE ASM - INTERMEDIATE	TATA spare parts
288546800111	AUXILIARY PIPE ASM-INSIDE CABIN	TATA spare parts
288546800157	COUPLING BODY M16XM22	TATA spare parts
288546800158	COUPLING BODY M18XM22	TATA spare parts
288546800160	MALE ADAPTOR M18X1.5-M22X1.5	TATA spare parts
288546803301	BRKT-STG PIPE MTG ON FRAME	TATA spare parts
288546803303	BRKT-STRG PIPE MTG	TATA spare parts
288546803304	BRKT-STRG PIPE MTG	TATA spare parts
288546803305	BRKT STG PIPE MTG	TATA spare parts
288546803306	BRKT STG PIPE MTG	TATA spare parts
288546803307	BRKT STG PIPE MTG	TATA spare parts
288546803308	BRKT STG PIPE MTG	TATA spare parts
288546803309	BRKT STG PIPE MTG	TATA spare parts
288546803310	BRKT STG PIPE MTG	TATA spare parts
288546803311	Z -BRACKET FOR STEERING LINES MTG	TATA spare parts
288546803313	STG PIPE MTG BRKT ON FRAME	TATA spare parts
288546803314	BRACKET STG PIPE MTG FRAME	TATA spare parts
288546803315	BRKT-STG PIPE MTG ON FRAME	TATA spare parts
288546803316	BRKT-STG PIPE MTG ON FRAME	TATA spare parts
288546803317	BRKT-STG PIPE MTG ON FRAME	TATA spare parts
288546803328	BRACKET STG PIPE MTG	TATA spare parts
288546808201	BRKT-WIRING HARNESS CLAMPING	TATA spare parts
288546990102	HOUSING ASSY	TATA spare parts
288547100108	ASSY. FUEL TANK COMPLETE-INTEGRATED SEND	TATA spare parts
288547107101	ROLLOVER VALVE	TATA spare parts
288547507701	RUBBER PACKING	TATA spare parts

288547600106	ASSY.FUEL SUCTION LINE-F/TANK TO W/S	TATA spare parts
288547600108	FUEL SUCTION PIPE ASSY	TATA spare parts
288547600109	FUEL SUCTION PIPE ASSY	TATA spare parts
288547603301	SUPPORT PLATE FOR ASSY.FUEL LINES	TATA spare parts
288547603302	SUPPORT BRACKET FOR ASSY.FUEL LINES	TATA spare parts
288547606801	FLOW STOP ADAPTER VOSS M18 NG12	TATA spare parts
288547606802	VOSS ELBOW	TATA spare parts
288547606903	PIPE FOR ROV VALVE	TATA spare parts
288547700101	ASSY. HEAD FOR FUEL FILTER BS3/4	TATA spare parts
288547700105	FUEL FILTER (FWS) ELEMENT BS3/4	TATA spare parts
288547704901	FUEL FILTER (FWS) SPINON BS3/4	TATA spare parts
288547704901AE	FILTER FUEL 1628 1828	TATA spare parts
288547704905	FUEL FILTER (FWS) W/DRAIN VALVE BS3/4	TATA spare parts
288547709901	FUEL WATER SEPARATOR SPINON	TATA spare parts
288549100108	ASSY BRACKET (MUFFLER MOUNTING FRONT)	TATA spare parts
288549100109	ASSY EXHAUST PIPE(EXH ELBOW TO EXH BRAKE	TATA spare parts
288549100109AE	ASY EXH PIP(EX ELBW EXHBRK)-1628	TATA spare parts
288549100110	EXHAUST MUFFLER	TATA spare parts
288549100111	ASSY BRACKET SUPPORT EXHAUST BRAKE	TATA spare parts
288549100114	V BAND CLAMP 3.8 INCH	TATA spare parts
288549100114AE	"V BAND CLAMP JUPITER 3.8"" -1628"	TATA spare parts
288549100117	ASSY FRONT BKT FOR SILENCER MTG FRAME	TATA spare parts
288549100118	V-BAND CLAMP	TATA spare parts
288549100121	ASSY SILENCER REAR END SUPPORT	TATA spare parts
288549100123	FIRST PIPE FROM ENGINE TO SECOND PIPE	TATA spare parts
288549100125	ASSY EXH PIPE (FLEX CONNECTOR TO MUFFLER	TATA spare parts
288549100126	ASSY EXHAUST TAIL PIPE	TATA spare parts
288549100130	FLX CONNECTOR FOR LPS 4027	TATA spare parts
288549100133	GASKET	TATA spare parts
288549100134	GASKET-EXH BRAKE SIDE	TATA spare parts
288549100142	V BAND CLAMP	TATA spare parts
288549100143	V BAND CLAMP	TATA spare parts
288549101602	V-BAND CLAMP BS6	TATA spare parts
288549106912	SECOND PIPE (FROM FIRST PIPE TO FLEX)	TATA spare parts
288549106915	TUBE	TATA spare parts
288549107121	BRACKET REAR FOR SILENCER MOUNTING FRAME	TATA spare parts
288549107501	RUBBER BUFFER	TATA spare parts
288549107501AE	RUBBER BUFFER 1628	TATA spare parts
288549108209	CLAMP EXHAUST PIPE INT	TATA spare parts
288549108209AE	CLAMP EXH PIPE 1628	TATA spare parts
288549108225	BRACKET SUPPORT EXH PIPE GEARBOX	TATA spare parts
288549108231	BRACKET FOR HOLDING TAIL PIPE	TATA spare parts
288549108233	BRACKET FOR TAIL PIPE CLAMP	TATA spare parts
288549108233AE	BRKT FOR TAIL PIPE CLAMP -1628	TATA spare parts
288549108234	CLAMP EXH PIPE	TATA spare parts
288549108234AE	CLAMP EXH PIPE 1628	TATA spare parts
288549109201	WASHER	TATA spare parts

288552200101	ASSY.FRONT FENDER MTG. BKT. - LH	TATA spare parts
288552200102	ASSY.FRONT FENDER MTG. BKT. - RH	TATA spare parts
288552200103	ASY.BKT.REAR-LH(REAR FENDER)	TATA spare parts
288552200104	ASY.BKT.REAR-RH(REAR FENDER)	TATA spare parts
288552200114	ASSY. BRACKET REAR - RR FENDER.	TATA spare parts
288552206301	MUD FLAP - REAR	TATA spare parts
288552207101	SPACER-FOR FENDER MTG.BKT.REAR	TATA spare parts
288552400101	ASSY.ARRESTOR	TATA spare parts
288552990101	RETRO FITMENT KIT FOR FENDER MTG. REAR B	TATA spare parts
288554200101	LOW OXYGEN LEVEL INDICATOR	TATA spare parts
288554201601	LOW OXYGEN LEVEL INDICATOR	TATA spare parts
288554500101	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
288554600101	WIRING HARNESS FRAME	TATA spare parts
288554600102	WIRING HARNESS DASHBOARD	TATA spare parts
288554600103	WIRING HARNESS ENGINE	TATA spare parts
288554600104	WIRING HARNESS HEAD BOX	TATA spare parts
288554630102	BATTERY CABLE +VE BCS TO MEGA FUSE BS6	TATA spare parts
288554630105	WIRING HARNESS-TAIL BS6	TATA spare parts
288554700101	BRACKET ASSY YAW RATE SENSOR MTG BS6	TATA spare parts
288554704901	STEERING ANGLE SENSOR BS6	TATA spare parts
288554704902	ELECTRONICS STABILITY CONTROL MODULE BS6	TATA spare parts
288554850101	DMS CONTROLLER BS6	TATA spare parts
288640100102	ASSY BRACKET SPARE WHEEL CARRIER MTG.	TATA spare parts
288640100104	ASSY WHEEL RIM 5.5JX16	TATA spare parts
288642400103	LCRV & LINKAGE ASSY.	TATA spare parts
288642700105	ASSY PARKING BRAKE CABLE II	TATA spare parts
288642800102	ASSY. BRACKET(TEE MTG.ON REAR)	TATA spare parts
288642800105	ASSY. BRACKET LCRV LINK & TEE MTG.	TATA spare parts
288643800102	ASSY. TUBE	TATA spare parts
288643800103	ASSY. TUBE	TATA spare parts
288643800104	ASSY. TUBE	TATA spare parts
288643800106	ASSY. TUBE	TATA spare parts
288643800107	ASSY. TUBE	TATA spare parts
288643800110	ASSY. TUBE	TATA spare parts
288649200110	ASSY TAIL PIPE EXHAUST	TATA spare parts
288654209905	ASSY.HORN 12V-LOW TONE 100DIA	TATA spare parts
288654600118	W/H ENGINE SPACIO BS-II & BS-III	TATA spare parts
288729506301	HYDRAULIC ADAPTER (FOR CSC)	TATA spare parts
288730062	O STYLE PACKING RING	TATA spare parts
288730100101	ASSY. ACCELERATOR PEDAL COMP.	TATA spare parts
288731208201	SPACER PLATE	TATA spare parts
288742800123	ASSY BRACKET (FOR BRAKE PIPE LINE)	TATA spare parts
288742800153	ASSY BRACKET (BRAKE PIPE LINE - BOOSTER)	TATA spare parts
288742800193	HOSE ASSY	TATA spare parts
288742807701	BRAKE PIPE CLAMP (TWO PIPES)	TATA spare parts
288743100102	KIT SERVO ASSY	TATA spare parts
288743100108	ASSY 8+9 BOOSTER TMC 26.99 & RESERVOIR	TATA spare parts

288743100109	TMC 26.99(CV/CV)	TATA spare parts
288743100110	SERVO ASSY	TATA spare parts
288743100112	KIT SERVO ASSY	TATA spare parts
288743100117	BRAKE FLUID RESERVOIR	TATA spare parts
288743100132	KIT FILLER CAP	TATA spare parts
288743100135	KIT FILLER CAP	TATA spare parts
288743100136	KIT RESERVOIR ASSY	TATA spare parts
288743100137	FLUID RESERVOIR ASSY COMP	TATA spare parts
288743100138	KIT-REPAIR FLUID RESERVOIR ASSY BS6-PH2	TATA spare parts
288743107701	O RING	TATA spare parts
288769100102	ASSY.CAP (ROOF AC SIDE TRIM MTG)-LB-B001	TATA spare parts
288769506303	TRIM CLIP FOR HEADLINING	TATA spare parts
288781100105	ASSY.REAR VIEW MIRROR INR BLACK	TATA spare parts
288781100110	ASSY INNER RVM-BLACK	TATA spare parts
288781101601	ASSY.REAR VIEW MIRROR INR BLACK	TATA spare parts
288781103801	INNER REAR VIEW MIRROR BASE MTG.BLACK	TATA spare parts
288783400121	HUB S/A MAGNET CLUTCH	TATA spare parts
288791506316	HEIGHT ADJUSTER LEVER LOCKING RH	TATA spare parts
288791506317	HEIGHT ADJUSTER LEVER LH	TATA spare parts
288799504301	METAL CLIP FOR GRILL(ASSY FRT GRILL) BS6	TATA spare parts
288824100101	ASSY. BRACKET - RH (FRONT ENGINE MOUNT)	TATA spare parts
288824100102	ASSY. BRACKET - LH (FRONT ENGINE MOUNT)	TATA spare parts
288829100149	ASSY CLUTCH SLAVE CYLINDER	TATA spare parts
288832100107	ASSY. VIBRATION DAMPER	TATA spare parts
288844800113	ASSY.HIGH PRESSURE LINE (PUMP TO G/BOX.)	TATA spare parts
288847600110	ASSY PRIMING PUMP	TATA spare parts
288847607701	FUEL LINE CLAMP (PIPE 12.5X10.0)	TATA spare parts
288940100102	ASSY WHEEL RIM COVER	TATA spare parts
288942800115	ASSY. VACUUM PUMP	TATA spare parts
288954409917	BULB_12H7_55W-M/S_PHILIPS	TATA spare parts
288954700114	ASSY THERMISTER FOR FLAT EVAP COIL-BEHR	TATA spare parts
2890098	BRACE HOSE	TATA spare parts
2890099	BRACE HOSE	TATA spare parts
289224107101	TORQUE SUPPORT	TATA spare parts
289229000101	CLUTCH BOOSTER	TATA spare parts
289229100102	ASSY.SUPPORT COMPLETE	TATA spare parts
289229100104	ASSY.CLUTCH PEDAL COMPLETE	TATA spare parts
289229100106	ASSY.BRACKET(CL BOOSTER MTG)	TATA spare parts
289229100107	ASSY FORK WITH CLUTCH BOOSTER	TATA spare parts
289229100108	ASSEMBLY FORK	TATA spare parts
289229106801	MALE STUD COUPLING BODY	TATA spare parts
289229108501	ADAPTOR	TATA spare parts
289229306901	NYLON TUBE	TATA spare parts
289230100101	ASSY.BELL CRANK WITH BUSH	TATA spare parts
289230100102	BRACKET	TATA spare parts
289230100103	ASSY. PULL CABLE ACCELERATOR	TATA spare parts
289230100106	ASSY.BELL CRANK WITH BUSH	TATA spare parts

289230100108	ASSY.ACCELERATOR BRACKET COMP.	TATA spare parts
289230103301	EXTENSION ROD	TATA spare parts
289230106001	THRUST ROD	TATA spare parts
289230106701	PIN	TATA spare parts
289230107101	ACCELERATOR BRACKET	TATA spare parts
289230107120	SPRING BRACKET	TATA spare parts
289230107121	BRACKET ENGINE STOP	TATA spare parts
289230107122	BASE PLATE	TATA spare parts
289230108217	BRACKET FOR ENGINE STOP	TATA spare parts
289230200101	ASY PULL CABLE ENGINE STOP	TATA spare parts
289231708601	SPACER	TATA spare parts
289232100103	ASSY. BRACKET (LOWER ARM MTG)	TATA spare parts
289232100107	ASSY. BRACKET (FRAME TO BOTTOM RADIUS RO	TATA spare parts
289232100121	ASSY. UPPER ARM	TATA spare parts
289232100122	ASSY. LOWER ARM - LH	TATA spare parts
289232100123	ASSY. LOWER ARM - RH	TATA spare parts
289232100124	ASSY. AIR SPRING (FRONT SUSPENSION)	TATA spare parts
289232100125	ASSY. KNUCKLE - LH	TATA spare parts
289232100126	ASSY. KNUCKLE - RH	TATA spare parts
289232100127	ASSY. ARB LINK - LH	TATA spare parts
289232100128	ASSY. ARB LINK - RH	TATA spare parts
289232100129	ASSY. FRONT SUSPENSION WITH BRAKES	TATA spare parts
289232100135	REPAIR KIT - UPPER CONTROL ARM	TATA spare parts
289232100136	REPAIR KIT - LOWER CONTROL ARM	TATA spare parts
289232100137	REPAIR KIT - LOWER CONTROL ARM	TATA spare parts
289232100138	WHEEL HEAD - LH	TATA spare parts
289232100139	BEARING UNIT	TATA spare parts
289232100140	WHEEL HEAD - RH	TATA spare parts
289232100141	TRACK ROD	TATA spare parts
289232103001	BALL JOINT	TATA spare parts
289232103002	BALL JOINT	TATA spare parts
289232103101	ROLLER BEARING	TATA spare parts
289232103102	AX. ROLLER BEARING	TATA spare parts
289232103201	HEX BOLT	TATA spare parts
289232103202	HEX. BOLT	TATA spare parts
289232103203	WHEEL BOLT	TATA spare parts
289232103401	BUSH	TATA spare parts
289232104301	CLIP	TATA spare parts
289232104701	COVER	TATA spare parts
289232105501	HUB	TATA spare parts
289232106001	TRACK LEVER	TATA spare parts
289232106002	TRACK LEVER - RH	TATA spare parts
289232106501	HEXAGON NUT	TATA spare parts
289232106502	SLOTTED NUT	TATA spare parts
289232106503	HEXAGON NUT	TATA spare parts
289232106701	PIN	TATA spare parts
289232106702	PIVOT PIN	TATA spare parts

289232106901	PIPE	TATA spare parts
289232107121	BRACKET - LEVELING VALVE BOTTOM	TATA spare parts
289232107122	BRACKET LH - LEVELING VALVE TOP	TATA spare parts
289232107123	BRACKET RH - LEVELING VALVE TOP	TATA spare parts
289232107124	LEVER - LEVELING VALVE	TATA spare parts
289232107702	SHAFT SEAL	TATA spare parts
289232107704	O RING	TATA spare parts
289232107705	SEALING RING	TATA spare parts
289232107901	FRONT ANTIROLL ABR (HIGH DECK BUS)	TATA spare parts
289232108001	TORX SCREW	TATA spare parts
289232108002	HEXAGON SCREW	TATA spare parts
289232108003	HEXAGON SCREW	TATA spare parts
289232108004	STOP SCREW	TATA spare parts
289232108005	HEXAGON SCREW	TATA spare parts
289232108301	SHIM	TATA spare parts
289232108302	SHIM	TATA spare parts
289232108303	SHIM	TATA spare parts
289232108304	SHIM	TATA spare parts
289232108305	SHIM	TATA spare parts
289232108306	SHIM	TATA spare parts
289232108307	SHIM	TATA spare parts
289232108308	SHIM	TATA spare parts
289232108309	SHIM	TATA spare parts
289232108310	SHIM	TATA spare parts
289232108311	SHIM	TATA spare parts
289232108312	SHIM	TATA spare parts
289232108313	SHIM	TATA spare parts
289232108314	SHIM	TATA spare parts
289232108315	SHIM	TATA spare parts
289232108316	SHIM	TATA spare parts
289232108317	SHIM	TATA spare parts
289232108318	SHIM	TATA spare parts
289232108319	SHIM	TATA spare parts
289232108320	SHIM	TATA spare parts
289232108321	SHIM	TATA spare parts
289232108322	SHIM	TATA spare parts
289232108323	SHIM	TATA spare parts
289232108324	SHIM	TATA spare parts
289232108325	SHIM	TATA spare parts
289232108326	SHIM	TATA spare parts
289232108401	NEEDLE SLEEVE	TATA spare parts
289232108402	CLAMPING SLEEVE	TATA spare parts
289232108601	SPACER (FRONT SUSPENSION)	TATA spare parts
289232109001	ARB WASHER	TATA spare parts
289232109203	WASHER	TATA spare parts
289232109204	WASHER	TATA spare parts
289232109205	WASHER	TATA spare parts

289232109206	WASHER	TATA spare parts
289232109207	WASHER	TATA spare parts
289232109208	WASHER	TATA spare parts
289232109209	WASHER	TATA spare parts
289232109210	WASHER	TATA spare parts
289232109211	WASHER	TATA spare parts
289232109212	WASHER	TATA spare parts
289232109213	WASHER	TATA spare parts
289232109214	WASHER	TATA spare parts
289232109215	WASHER	TATA spare parts
289232109216	WASHER	TATA spare parts
289232109217	WASHER	TATA spare parts
289232109218	WASHER	TATA spare parts
289232109219	WASHER	TATA spare parts
289232109220	WASHER	TATA spare parts
289232109221	WASHER	TATA spare parts
289232109222	TAB WASHER	TATA spare parts
289232109901	KNUCKLE CARRIER LH	TATA spare parts
289232109902	LUBRICATION NIPPLE	TATA spare parts
289232109903	RING	TATA spare parts
289232109904	ROD WIPER	TATA spare parts
289232109905	TYPE PLATE	TATA spare parts
289232109906	STRUT	TATA spare parts
289232109907	KNUCKLE CARRIER RH	TATA spare parts
289232109909	STEER KNUCKLE - RH	TATA spare parts
289232109910	BRAKE DISC	TATA spare parts
289232109911	PULSE DISC	TATA spare parts
289232109912	SEALING HOLDER	TATA spare parts
289232109913	RETAINING RING	TATA spare parts
289232109914	REV. COUNTER	TATA spare parts
289232109915	STEER KNUCKLE - LH	TATA spare parts
289232109916	LUFTFEDERBALG	TATA spare parts
289232109917	AUXILLARY SPRING	TATA spare parts
289232300101	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
289232300102	ASSY FRONT SHOCK ABSORBER	TATA spare parts
289232400103	ASSY. COWHORN BRACKET - LH	TATA spare parts
289232400104	ASSY. COWHORN BRACKET - RH	TATA spare parts
289232400107	FRONT AIR SPRING BKT - LH	TATA spare parts
289232400108	FRONT AIR SPRING BKT - RH	TATA spare parts
289232400109	REAR AIR SPRING BKT - LH	TATA spare parts
289232400110	REAR AIR SPRING BKT- RH	TATA spare parts
289232400111	FRONT AIR SPRING CROSS MEMBER	TATA spare parts
289232400112	REAR AIR SPRING CROSS MEMBER	TATA spare parts
289232400113	PARALLEL LINK BKT CROSS MEMBER ASSY	TATA spare parts
289232400114	RADIUS ROD ASSY	TATA spare parts
289232400115	PARALLEL LINK ASSY - LH	TATA spare parts
289232400116	ASSY. LEVELING VALVE	TATA spare parts

289232400117	ASSY AIR SPRING - REAR	TATA spare parts
289232400118	CONNECTING ROD ASSY	TATA spare parts
289232400119	PARALLEL LINK ASSY - RH	TATA spare parts
289232400121	PARALLEL LINK ASSY - LH	TATA spare parts
289232400122	PARALLEL LINK ASSY - RH	TATA spare parts
289232400123	PARALLEL LINK BKT ASSY - LH	TATA spare parts
289232400124	PARALLEL LINK BKT ASSY - RH	TATA spare parts
289232400125	RADIUS ROD ASSY	TATA spare parts
289232400126	ASSY COWHORN MAJOR-LH	TATA spare parts
289232400127	ASSY COWHORN MAJOR-RH	TATA spare parts
289232403301	COMPOUND LINK BRACKET - LH	TATA spare parts
289232403302	COMPOUND LINK BRACKET - RH	TATA spare parts
289232404201	U BOLT - REAR	TATA spare parts
289232404802	DOWEL PIN	TATA spare parts
289232408201	LEVER - LEVELING VALVE	TATA spare parts
289232600101	ASSY. SHOCK ABSORBER - REAR	TATA spare parts
289232807102	CLAMP FRONT ANTIROLL BAR	TATA spare parts
289232807702	BUSH FRONT ANTI ROLL BAR	TATA spare parts
289232807901	FRONT ANTIROLL BAR	TATA spare parts
289232900101	ANTI ROLL BAR ASSY	TATA spare parts
289240100104	TUBELESS TYRE 295/80 R22.5	TATA spare parts
289240300101	ASSY. SPARE WHEEL CARRIER	TATA spare parts
289241100101	DRIVE SHAFT	TATA spare parts
289242100103	BRAKE CHAMBER	TATA spare parts
289242100109	TYPE 27/30 SPRING BRAKE ACTUATOR (VOSS C	TATA spare parts
289242100110	SPRING BRAKE ACTUATOR 27/30 (WABCO) BS4	TATA spare parts
289242100118	BRAKE DISC	TATA spare parts
289242100127	BRAKE PAD	TATA spare parts
289242106501	CASTLE NUT FOR FRONT BRAKE M16 1.5	TATA spare parts
289242200101	ASSY HAND LEVER SW BKT (RETARDER)	TATA spare parts
289242300106	AUTO. SLACK ADJUSTER STR-CD160 BS2/3/4/6	TATA spare parts
289242300107	SPRING BRAKE ACTUATOR - TYPE 27/30	TATA spare parts
289242300119	AUTOMATIC SLACK ADJ.STRAIGHT	TATA spare parts
289242303201	HEX BOLT M16X1.5	TATA spare parts
289242303202	HEX BOLT M14X1.5	TATA spare parts
289242303701	BRAKE DRUM-REAR (410X220) BS2/3/4	TATA spare parts
289242303702	CHAMBER MOUNTING BRACKET REAR LH	TATA spare parts
289242303703	CHAMBER MOUNTING BRACKET REAR RH	TATA spare parts
289242308201	ANCHOR BRACKET LH	TATA spare parts
289242308202	ANCHOR BRACKET RH	TATA spare parts
289242400102	RETARDER ASSY.	TATA spare parts
289242408801	STUD FOR RETARDER	TATA spare parts
289243200103	ASSY BRACKET	TATA spare parts
289243200104	ASSY STRAP COMPLETE(AIR TANK MOUNTING)	TATA spare parts
289243206701	PIN	TATA spare parts
289243206702	PIN	TATA spare parts
289243207701	RUBBER(STRAP AND AIR TANK)	TATA spare parts



289243208202	BRACKET R.H (AIR TANK MTG)	TATA spare parts
289243208203	BRACKET L.H (AIR TANK MTG).	TATA spare parts
289243208204	STRAP(AIR TANK MTG)	TATA spare parts
289243208601	SPACER	TATA spare parts
289243405801	60 I.D. HOSE	TATA spare parts
289243405802	60 I.D.HOSE	TATA spare parts
289243405803	28.6 I.D.HOSE	TATA spare parts
289243405804	28.6 ID HODE	TATA spare parts
289243405805	RADIATOR TO 60 DIA PIPE#HOSE	TATA spare parts
289243405806	BEND HOSE 28.6 DIA	TATA spare parts
289243700101	ASSY BASE PLATE (DUAL TREADLE VALVE)	TATA spare parts
289243700105	PURGE TANK	TATA spare parts
289243703201	HEX BOLTS	TATA spare parts
289243703202	HEX BOLTS	TATA spare parts
289243703203	CENTRE BOLT WITH NORD WASHER	TATA spare parts
289243706101	SEAL RING	TATA spare parts
289243706501	HEX NUT	TATA spare parts
289243707801	O RING FOR HOUSING VENTILATION	TATA spare parts
289243707802	O RING WATER SOCKET	TATA spare parts
289243707803	O-RING	TATA spare parts
289243707805	O-RING	TATA spare parts
289243708001	THREADED PIECE	TATA spare parts
289243709001	NON RETURN VALVE	TATA spare parts
289243709901	DIRT REPELLER	TATA spare parts
289243709902	PRESSURE SENSOR	TATA spare parts
289243709903	FLANGE CARDAN SHAFT	TATA spare parts
289243900102	ASSY. BRACKET (MODULATOR VALVE)	TATA spare parts
289243900103	COOLING PIPE (RETARDER)	TATA spare parts
289243900104	COOLING PIPE(RETARDER)	TATA spare parts
289243900105	COOLING PIPE(RETARDER)	TATA spare parts
289243900106	COOLINNG PIPE(RETARDER)	TATA spare parts
289243900107	COOLING PIPE(RETARDER)	TATA spare parts
289243900108	COOLING PIPE(RETARDER)	TATA spare parts
289243900111	ASSY 3/8IN HOSE WITH L12 COUPLING NUT BO	TATA spare parts
289243900113	ASSY. 3/8 HOSE WITH L12 COUPLINGNUT B	TATA spare parts
289243908217	BRACKET 12 BS6	TATA spare parts
289243908220	BRACKET 15	TATA spare parts
289243908221	BRACKET 16 BS6	TATA spare parts
289246100102	ASSY.BRACKET (BEVEL G.B. MTG)	TATA spare parts
289246100103	ASSY.CROSS MEMBER (STG. G.B. MTG)	TATA spare parts
289246100104	ASSY.BRACKET	TATA spare parts
289246100106	ASSY.STG.COLUMN BKT.	TATA spare parts
289246100107	ADAPTER REDUCER 6 DIA TO 4 DIA	TATA spare parts
289246100111	ASSY. BRACKET	TATA spare parts
289246100112	ASSY. SUPPORT	TATA spare parts
289246103201	HEX.BOLT (FOR STG.GB MTG.BKT)	TATA spare parts
289246104301	CLAMPING RING	TATA spare parts

289246106801	COUPLING (FOR STG. SOLENOID)	TATA spare parts
289246305101	PITMAN ARM (TRIANGULAR)	TATA spare parts
289246400103	ASSY.STEERING WHEEL 500 DIA.	TATA spare parts
289246600101	ASSY.STG.GEAR BOX	TATA spare parts
289246800101	ASSY HOSE- CRIMPED (STG TANK TO STG PUMP	TATA spare parts
289246800102	ASSY PIPE (15 OD)	TATA spare parts
289246800103	ASSY HOSE - CRIMPED (STG TANK TO STG GB)	TATA spare parts
289246800104	ASSY PIPE (15 OD)	TATA spare parts
289246800106	ASSY. PIPE (15 O.D.)	TATA spare parts
289246800107	ASSLY PIPE	TATA spare parts
289246800108	ASSLY PIPE	TATA spare parts
289246800109	ASSLY PIPE	TATA spare parts
289246800110	ASSLY PIPE	TATA spare parts
289246800111	ASSLY PIPE	TATA spare parts
289247100102	ASSY.FUEL TANK WELDED (400 LTR.RECT.)	TATA spare parts
289247105801	HOSE	TATA spare parts
289247500106	ASSY.STRAP	TATA spare parts
289249100102	ASSY PIPE	TATA spare parts
289249100104	EXHAUST SILENCER ASSY. HI DECK BUS	TATA spare parts
289249100108	HEAT SHIELD (EXHAUST BRAKE)	TATA spare parts
289249106906	TAIL PIPE	TATA spare parts
289249108202	CLAMP(SILENCER MTG)	TATA spare parts
289249108204	BRACKET	TATA spare parts
289249108207	CLAMP (TAIL PIPE)	TATA spare parts
289249108214	SOLENOID MOUNTING BRACKET	TATA spare parts
289249207101	BRACKET(ON ENGINE BLOCK)	TATA spare parts
289254000001	CIRCUIT SCHEMATIC FUSE BOX	TATA spare parts
289254200101	FUEL TANK UNIT KIT(400 LTRS)	TATA spare parts
289254200104	INSTRUMENT CLUSTER (LPO1623 HD BUS)	TATA spare parts
289254200108	ASSY.BRACKET(ECU MOUNTING)	TATA spare parts
289254200116	FUEL TANK UNIT (400LTRS) BS1/2/3/4	TATA spare parts
289254206701	DRIVE TIP (JIS TYPE)	TATA spare parts
289254209904	ECU VOITH RETARDER 24V	TATA spare parts
289254209906	TEMP.SENSOR VOITH RETARDER 24V	TATA spare parts
289254209909	ELECTRONIC SPEEDO WITH 4.7K PULLUP (RATI	TATA spare parts
289254209910	ELECTRONIC SPEEDO WITH 4.7K PULLUP (RATI	TATA spare parts
289254500101	STG. LOCK CUM IGNITION SW	TATA spare parts
289254500108	COMBI SWITCH RHD DOUBLE LEVER	TATA spare parts
289254506901	PIANO SWITCH (ABS DIAGONOSTIC)	TATA spare parts
289254506902	PIANO SW (RETARDER)	TATA spare parts
289254506903	PIANO SWITCH (STG. WHEEL ADJ)	TATA spare parts
289254506904	PIANO SWITCH (ENG LAMP)	TATA spare parts
289254600101	W/H MAIN	TATA spare parts
289254600102	W/H TAIL	TATA spare parts
289254600107	W/H HAND BRAKE STAGE SW VOITH RETARDER	TATA spare parts
289254600109	W/H FRAME ASSY HI_DECK BUS	TATA spare parts
289254600401	W/H FRAME	TATA spare parts

289261500101	ASSY SUBSTR MTG OUTRIGGER FRONT	TATA spare parts
289262600101	ASSY PANEL FRONT INNER	TATA spare parts
289429100101	ASSY.CTRL MTG.WITH CLUTCH & BRAKE PEDAL	TATA spare parts
289429100201	ASSY.CLUTCH MASTER CYL-D 19.05	TATA spare parts
289430100102	ASSY. ACCL. PEDAL COMPLETE (RHD)	TATA spare parts
289431000102	ASSY FRAME DC 4X2 (XENON 4PL WT.R)	TATA spare parts
289431000103	ASSY FRAME DC 4X2 (THAILAND 2.2L WT.R)	TATA spare parts
289431000107	ASSY FRAME DC 4X2 AIRBAG 2.2L DICOR	TATA spare parts
289431000108	ASSY FRAME XENON 3.0L DC 4X2 31WB	TATA spare parts
289431000125	FRAME ASSY	TATA spare parts
289431106303	END CAP FOR HOLE DIA 20	TATA spare parts
289431106304	END CAP FOR DIA 64	TATA spare parts
289431106305	END CAP FOR HOLE DIA 30	TATA spare parts
289431200101	ASSY TUBE (FOR GEAR BOX EXTN. MTG)	TATA spare parts
289431200108	ASSY BRACKET (REAR ENGINE MOUNT 4X2)	TATA spare parts
289431200109	ASSY. ENGINE MOUNTING BRACKET REAR 4X2	TATA spare parts
289431200111	ASSY. TUBE (RADIATOR GUARD)	TATA spare parts
289431200113	ASSY. BRACKET (REAR ENGINE MOUNT 4X2)	TATA spare parts
289432400103	1ST LEAF ASSY WITH BUSH	TATA spare parts
289432400104	LEAF SPRING ASSY REAR	TATA spare parts
289432407102	2ND LEAF	TATA spare parts
289432407103	3RD LEAF	TATA spare parts
289432407104	4TH LEAF	TATA spare parts
289432407105	5TH LEAF	TATA spare parts
289432407106	6TH LEAF	TATA spare parts
289432407107	7TH LEAF	TATA spare parts
289432408601	SPACER BS6	TATA spare parts
289433000101	ASSY. STUB AXLE WITH HUB - RH	TATA spare parts
289433000102	ASSY. STUB AXLE WITH HUB - LH	TATA spare parts
289433000108	ASSY. FRONT AXLE WITH HUB & BRAKE DISC	TATA spare parts
289433000109	ASSY. FRONT AXLE WITH HUB & BRAKE DISC	TATA spare parts
289433000110	ASSY. FRT. AXLE HUB & DISC SCRUB ABS-RH	TATA spare parts
289433000111	ASSY. FRT. AXLE HUB & DISC SCRUB ABS-LH	TATA spare parts
289433000112	FRONT AXLE ASSY RH	TATA spare parts
289433000113	FRONT AXLE ASSY LH	TATA spare parts
289433200101	ASSY. STUB AXLE WITH SEAL RACE	TATA spare parts
289433200102	ASSY. STUB AXLE WITH SEAL RACE - LH	TATA spare parts
289433200105	ASSY. STUB AXLE WITH SEAL RACE - RH	TATA spare parts
289433200106	ASSY. STUB AXLE WITH SEAL RACE - LH	TATA spare parts
289433205101	STUB AXLE - RH	TATA spare parts
289433205102	STUB AXLE - LH	TATA spare parts
289433400101	ASSY.HUB WITH BRAKE DISC 4X2 TWIN POT	TATA spare parts
289440100104	ASSY RIM TYRE & BALWEIGHT(5.5X16-AL)	TATA spare parts
289440100202	ASSY. WHEEL RIM COVER 16INCH BS3/4	TATA spare parts
289440100203	ASSY WHEEL RIM 5.5J X 16 (BLACK)	TATA spare parts
289441100103	ASSY.PROP.SHAFT.RR-4X2-31WB2.2L	TATA spare parts
289441100105	ASSY. PROP. SHAFT-REAR FOR SC/SPC/CC 31W	TATA spare parts

289441100106	ASSY PROP SHAFT-REAR FOR SC/SPC/CC 31WB	TATA spare parts
289441100107	TORSIONAL VIBRATION DAMPER	TATA spare parts
289441100108	PROP.SHAFT 31WB 4X2 WITH SALISABRAY AXLE	TATA spare parts
289441110105	ASSY.KIT FRONT TUBE (TF) REAR PROP.SHAFT	TATA spare parts
289441110106	ASSY.KIT FRONT TUBE(TF)REAR PROP.SHAFT	TATA spare parts
289441110108	ASSY.PROPELLER SHAFT FRONT 4X2	TATA spare parts
289441120105	ASSY.KIT REAR TUBE (TR) REAR PROP.SHAFT	TATA spare parts
289441120106	ASSY.KIT REAR TUBE(TR)REAR PROP.SHAFT	TATA spare parts
289442108201	COVER (BRAKE DISC)RH	TATA spare parts
289442108202	COVER (BRAKE DISC)LH	TATA spare parts
289443109901	HYDRAULIC UNIT	TATA spare parts
289443500105	ASSLY.VACUUM HOSE	TATA spare parts
289443800106	ASSY BRACKET	TATA spare parts
289443800108	ASSY BRACKET ( CAB MTG BRACKET )	TATA spare parts
289443800109	ASSY BRACKET ( ABS COVER MTG )	TATA spare parts
289443800128	ASSEMBLY SENSOR CABLE MTG.BKT.-LH	TATA spare parts
289443800129	ASSEMBLY SENSOR CABLE MTG.BKT.-RH	TATA spare parts
289443800130	ASSEMBLY BRACKET BRAKE PIPE CL	TATA spare parts
289443800136	ASSEMBLY SENSOR CABLE BRACKET LH	TATA spare parts
289443800137	ASSEMBLY SENSOR CABLE BRACKET RH	TATA spare parts
289443800138	ASSY.MODULATOR MTG.BKT.	TATA spare parts
289443800160	TUBE ASSY REAR T-CONN TO REAR BRAKE RH	TATA spare parts
289443800161	TUBE ASSY REAR T-CONN TO REAR BRAKE LH	TATA spare parts
289443800162	TUBE ASSY REAR T-CONN TO REAR BRAKE RH B	TATA spare parts
289443800163	TUBE ASSY REAR T-CONN TO REAR BRAKE LH B	TATA spare parts
289443800165	TUBE ASSY REAR T-CONN TO REAR BRAKE RH	TATA spare parts
289443800166	TUBE ASSY ADAPTER TO REAR HOSE	TATA spare parts
289443800167	TUBE ASSY REAR T-CONN TO REAR BRAKE LH	TATA spare parts
289443800168	ASSY.BRAKE TUBE	TATA spare parts
289443800169	ASSY.BRAKE TUBE	TATA spare parts
289443800170	ASSY.BRAKE TUBE	TATA spare parts
289443800171	ASSY.BRAKE TUBE	TATA spare parts
289443800172	ASSY.BRAKE TUBE	TATA spare parts
289443800173	ASSY.BRAKE TUBE	TATA spare parts
289443800174	ASSY.BRAKE TUBE	TATA spare parts
289443800175	ASSY.BRAKE TUBE	TATA spare parts
289443800177	ASSEMBLY BRAKE TUBE	TATA spare parts
289443800178	ASSEMBLY BRAKE TUBE	TATA spare parts
289443800179	ASSEMBLY BRAKE TUBE	TATA spare parts
289443800181	ASSEMBLY BRAKE TUBE	TATA spare parts
289443800182	ASSY.BRAKE TUBE	TATA spare parts
289443800183	ASSY.BRAKE TUBE	TATA spare parts
289443800184	ASSY.BRAKE TUBE	TATA spare parts
289443800185	ASSY.BRAKE TUBE	TATA spare parts
289443800187	BRAKE TUBE ASSY TMC PRIMARY TO MV MC1	TATA spare parts
289443800189	ASSY. BRAKE PIPE	TATA spare parts
289443800196	ASSY.BRACKET (ESP MODULATOR MTG.BRACKET)	TATA spare parts

289443800197	ESP HYDRAULIC MODULATOR	TATA spare parts
289443800198	BRAKE TUBE ASSY TMC SECONDARY TO MV MC2	TATA spare parts
289443803305	BRACKET RH	TATA spare parts
289443803309	BRACKET-SUPPORT	TATA spare parts
289443803312	BRACKET ( SENSOR CABLE FRONT LH )	TATA spare parts
289443803313	BRACKET ABS SHIELD	TATA spare parts
289443803315	BRACKET (SENSOR CABLE MTG.ON REAR AXLE)	TATA spare parts
289443803318	BRACKET ( STUB AXLE MTG )	TATA spare parts
289443803320	BRACKET ( SENSOR MTG )	TATA spare parts
289443803321	BRACKET SENSOR CABLE ASSEMBLY	TATA spare parts
289443803375	BRACKET (FR.LH BRAKE HOSE MTG.) NON-ABS	TATA spare parts
289443803376	BRACKET (FR.RH BRAKE HOSE MTG.) NON-ABS	TATA spare parts
289443803380	SENSOR CABLE BRACKET AT REAR RH	TATA spare parts
289443807701	COVER ( XENON ABS MTG )	TATA spare parts
289443813305	BRACKET ABS FR SENSOR LH	TATA spare parts
289443813306	BRACKET ABS FR SENSOR RH	TATA spare parts
289443990101	HYDRAULIC UNIT	TATA spare parts
289446200101	ASSY¿SPHERICAL¿SUPPORT¿FOR¿STG COLUMN	TATA spare parts
289446800101	ASSY.SUCTION LINES (RESERVOIR TO PUMP)	TATA spare parts
289446800102	ASSY.HIGH PRESSURE LINE (PUMP TO G/BOX.)	TATA spare parts
289446800104	ASSY.RETURN LINE (G/BOX.TO RESERVOIR)	TATA spare parts
289446800105	ASSY.RETURN LINE (G/BOX.TO RESERVOIR)	TATA spare parts
289446800106	ASSY.SUCTION LINE (RESERVOIR TO PUMP)	TATA spare parts
289446800107	ASSY.SUCTION LINE (RESERVOIR TO PUMP)	TATA spare parts
289446800108	ASSY.RETURN LINE (G/BOX TO RESERVOIR)	TATA spare parts
289446800109	ASSY.RETURN LINE (G/BOX TO RESERVOIR)	TATA spare parts
289446800119	ASSY SUCTION LINE - 3L XENON RHD	TATA spare parts
289446800120	ASSY. HIGH PR. LINE	TATA spare parts
289446800121	ASSY. RETURN LINE	TATA spare parts
289446800126	SUCTION LINE ASSY	TATA spare parts
289446800127	RETURN LINE ASSY	TATA spare parts
289447100101	ASSY. FUEL TANK COMPLETE - 70L PETROL F	TATA spare parts
289447100106	ASSY FUEL PUMP	TATA spare parts
289447100108	FUEL PUMP	TATA spare parts
289447100109	FUELTANKASSY BS6	TATA spare parts
289447100110	FUEL TANK ASSY¿ WITH TANK UNIT	TATA spare parts
289447500101	STRAP ASSY BS6	TATA spare parts
289447508201	LOCK PLATE	TATA spare parts
289447600102	ASSY.FUEL LINE ON ENGINE	TATA spare parts
289447600103	ASSY.FUEL LINE ON CHASSIS	TATA spare parts
289447600107	ASSY. SUCTION LINE(FILTER TO F.I.P)	TATA spare parts
289447600109	ASSY. RETURN LINE(FILTER TO FIREWALL)	TATA spare parts
289447600113	ASSY.DELIVERY LINE (F/WALL-PRIMING PUMP)	TATA spare parts
289447600117	ASSY. TUBE (DELIVERY TUBE TO ENGINE)	TATA spare parts
289447600118	ASSY. FUEL LINE -(DELIEVERY/RETURN LINE)	TATA spare parts
289447600119	ASSY. EVAPOATION LINE(TANK - FIREWALL)	TATA spare parts
289447600120	ASSY DELIVERY LINE(FUEL PUMP-FUEL FILETR	TATA spare parts

289447600122	ASSY VAPOUR LINE (TANK TO TPV)	TATA spare parts
289447600123	ASSY. FUEL LINE (CANISTER TO ATMOSPHERE)	TATA spare parts
289447600125	ASSY FUEL LINE ON CHASSIS	TATA spare parts
289447600126	ASSY DELIVERY LINE (SEDIMNTR TO FIREWAL)	TATA spare parts
289447600127	ASSY RETURN LINE (FIREWALL TO FUEL TANK)	TATA spare parts
289447600130	ASSY DELIVERY LINE (SEDIMNTR TO FIREWAL)	TATA spare parts
289447600131	ASSY RETURN LINE (FIREWALL TO FUEL TANK)	TATA spare parts
289447600132	ASSY.FUEL LINE ON ENGINE	TATA spare parts
289447600133	ASSY.DELIVERY LINE (F/WALL-PRIMING PUMP)	TATA spare parts
289447600134	ASSY. RETURN LINE(FILTER TO FIREWALL)	TATA spare parts
289447600138	ASSY DELIVERY LINE (TANK TO FIREWAL)	TATA spare parts
289447600140	ASSY.DELIVERY LINE (F/WALL-SEDIMENTOR)	TATA spare parts
289447600142	ASSY. RETURN LINE(FILTER TO FIREWALL)	TATA spare parts
289447600144	SUCTION PIPE ASSY TANK TO FIREWALL	TATA spare parts
289447602733	RUBBER HOSE	TATA spare parts
289447604201	SPECIAL CLAMP (PIPE OD 11X11 & 6 OD & 4.	TATA spare parts
289447605801	RUBBER HOSE(ASSY.PRIMING PUMP TO FILTER)	TATA spare parts
289447605804	HOSE (CC - PV) - 515 MM	TATA spare parts
289447605805	HOSE - (PV -AIS)	TATA spare parts
289447605807	HOSE (TANK TO TPV)	TATA spare parts
289447605808	RUBBER HOSE (CANISTER TO TPV)	TATA spare parts
289447605809	HOSE (CANISTER TO PURGE)	TATA spare parts
289447605810	BREATHER HOSE	TATA spare parts
289447605811	RUBBER HOSE	TATA spare parts
289447605813	FUEL FILLING HOSE	TATA spare parts
289447605816	BREATHER HOSE	TATA spare parts
289447605817	FUEL FILLING HOSE	TATA spare parts
289447607701	HOSE - FUEL FILLING	TATA spare parts
289449100105	CATCON ASSLY. WITH FRONT Y PIPE	TATA spare parts
289449100108	ASSY. CATCON W/FRONT PIPE-20GM EURO2/3	TATA spare parts
289449100110	CATCON ASSY.WITH FRONT PIPE	TATA spare parts
289449200101	ASSY. EXHAUST PIPE FRONT.	TATA spare parts
289449200104	ASSY INTERMEDIATE PIPE WITH RESONATOR	TATA spare parts
289454100102	BATT.CABLE -VE [BATT TO SIDE PANEL]	TATA spare parts
289454100103	BATT.CABLE -VE [CLUTCH HSG-FLOOR]	TATA spare parts
289454100107	ASSY.+VE BATTERY CABLE LHD 2.2L DICOR	TATA spare parts
289454100108	ASSY +VE BATTERY CABLE 3.L	TATA spare parts
289454100109	BATTERY CABLE +VE XENON 4PL	TATA spare parts
289454100116	BATTERY CABLE -VE EURO-V (BATT TO SIDE P	TATA spare parts
289454100117	BATTERY +VE CABLE	TATA spare parts
289454200101	ELECT.INST.CLUST. 1:0.725 3.0L	TATA spare parts
289454200102	ASSY.INST.CLUSTER 2.2 L DICOR [Pricol]	TATA spare parts
289454200102AE	ELECT.INST.CLUST.2.2L -XEN DC/SC	TATA spare parts
289454200105	KIT-BODY CONTROL MODULE BS3/4	TATA spare parts
289454200105AE	KIT BODY CNTRL MODULE-XEN DC/SC	TATA spare parts
289454200107	BODY CONTROL MODULE-KIT [ELECTRONIC DIVN	TATA spare parts
289454200108	STARTER RELAY BRACKET	TATA spare parts

289454200110	3.0L ECU SUPPORT	TATA spare parts
289454200111	ELECT.INST.CLUSTER	TATA spare parts
289454200112	INSTRUMENT CLUSTR 1:0.725-3.0L	TATA spare parts
289454200114	ELECT INST CLUST 1:0.8125 2.2L WITH ABS	TATA spare parts
289454200116	ELECT INST CLUSTER CNG DOMESTIC	TATA spare parts
289454200117	ELECTRONIC INST CLUSTER PETROL	TATA spare parts
289454200119	ELECT INST CLUSTER XENON RX	TATA spare parts
289454200122	ELECT INST CLUSTER 3.0L WAIRBAG 1:0.725	TATA spare parts
289454200123	ELE INST CLU XENON RX CC 4SPTC BS-IV.	TATA spare parts
289454200124	ELECT.INST.1:0.8125 WITH SPEED LIMIT	TATA spare parts
289454200125	ELECT INST CLUSTER XENON 2.2L_ABS WITH S	TATA spare parts
289454206301	DUMMY COVER-ANALOG CLOCK	TATA spare parts
289454209901	ANALOG CLOCK	TATA spare parts
289454209911	CONTROLLER POWER WINDOW EXPRESS DOWN	TATA spare parts
289454209912	BODY CONTROL MODULE M2 BS3/4	TATA spare parts
289454209914	WHEEL SPEED SENSOR RIGHT	TATA spare parts
289454209915	WHEEL SPEED SENSOR LEFT	TATA spare parts
289454209916	REAR WHEEL SPEED SENSOR	TATA spare parts
289454209918	FUEL LEVEL SENSOR UNIT	TATA spare parts
289454209919	USER REMOTE (NEW)	TATA spare parts
289454400101	ASSY. HEAD LAMP W/BLINKER LH LHD BS3/4	TATA spare parts
289454400102	ASSY HEAD LAMP W/BLINKER RH LHD BS2	TATA spare parts
289454400103	ASSY.TAIL LAMP -LH SIDE	TATA spare parts
289454400104	ASSY. TAIL LAMP -RH SIDE BS3/4	TATA spare parts
289454400104AE	ASSY.TLAMP -RH SIDE -XENON DC/SC	TATA spare parts
289454400105	HIGH MOUNTED STOP LAMP E CERT	TATA spare parts
289454400106	REAR FOG LAMP W/REFLECTOR LH LHD	TATA spare parts
289454400107	REV LAMP W/REFLECTOR RH LHD	TATA spare parts
289454400107AE	REV LMP W/REFLECTOR RH-XEN DC/SC	TATA spare parts
289454400108	ASSY. FRONT FOG LAMP W/EMARK BLB BS3/4/6	TATA spare parts
289454400110	FRONT ROOF LAMP GREY HSG	TATA spare parts
289454400111	REAR ROOF LAMP GREY	TATA spare parts
289454400112	FRONT ROOF LAMP BEIGE HSG	TATA spare parts
289454400113	REAR ROOF LAMP BEIGE HSG	TATA spare parts
289454400115	BULB H11 (12V 55W)	TATA spare parts
289454400116	ASSY. H/L WITH BLINKER- RH RHD	TATA spare parts
289454400117	ASSY H/L WITH? BLINKER-LH RHD	TATA spare parts
289454400118	ASSY H/L WITH BLINKER -RH LHD	TATA spare parts
289454400119	ASSY H/L WITH BLINKER -LH LHD	TATA spare parts
289454400120	ASSY H/L WITH BLINKER W/O MOTOR _LH RHD	TATA spare parts
289454400121	ASSY H/L WITH BLINKER W/O MOTOR _RH RHD	TATA spare parts
289454500101	FACIA SW H/L DEMIS DUMMY-RHD	TATA spare parts
289454500102	FACIA SW 4X4 DUMMY-RHD	TATA spare parts
289454500103	FACIA SW.H/L,DEMIS,DUMMY-LHD	TATA spare parts
289454500104	FACIA SW.4X4 DUMMY-LHD	TATA spare parts
289454500105	ASSY.MIRROR SWITCH	TATA spare parts
289454500106	FACIA SWITCH DUMMY DUMMY-RHD	TATA spare parts

289454500107	FACIA SWITCH DUMMY DUMMY-LHD	TATA spare parts
289454500108	52-POLE CONNECTOR PARKING ANGLE	TATA spare parts
289454500109	FACIA SW.DUMMY-DUMMY-RWH-RHD	TATA spare parts
289454500110	FACIA SW H/L DUMMY DUMMY RHD	TATA spare parts
289454500111	FACIA SW DUMMY - RHD	TATA spare parts
289454500112	ASSY FASCIA SW 4X2 EURO-V	TATA spare parts
289454500116	ESP-OFF SWITCH	TATA spare parts
289454500123	FACIA SW(2 PACK) DUMMY DUMMY-RHD BS6	TATA spare parts
289454504902	SWITCH¿DUMMY¿KNOB BS6	TATA spare parts
289454504904	SWITCH¿DUMMY¿KNOB¿4X4 BS6	TATA spare parts
289454506309	SWITCH DUMMY KNOB	TATA spare parts
289454506311	CARRIER PLATE FASCIA SWITCH BS6	TATA spare parts
289454506312	BEZEL FASCIA SWITCH BS6	TATA spare parts
289454508201	PARKING ANGLE (TRINARY PR.SWITCH)	TATA spare parts
289454509901	STG LOCK/IG.SW.WITH ILLU.RING	TATA spare parts
289454509902	COMBI SWITCH LHD	TATA spare parts
289454509904	ASSY.HAZARD WARNING SW	TATA spare parts
289454509905	WINDOW WINDING SW.REAR DOOR LH	TATA spare parts
289454509906	WINDOW WINDING SW.REAR DOOR RH	TATA spare parts
289454509907	BSSY COMBI SWITCH RHD	TATA spare parts
289454509908	COMBI SWITCH RHD COLLAP.STG.	TATA spare parts
289454509909	COMBI SW LHD COLL STG COL	TATA spare parts
289454509910	REVERSE LIGHT SW WITH PIGTAIL	TATA spare parts
289454509910_NIU01	REVERSE LIGHT SW WITH PIGTAIL	TATA spare parts
289454509914	SWITCH HEAD LAMP LEVELLING	TATA spare parts
289454509915	SWITCH 4X4 TRANSFER	TATA spare parts
289454509919	HLL SWITCH BS6	TATA spare parts
289454509920	DUMMY KNOB	TATA spare parts
289454509922	CARRIER PLATE 3 SW PACK RHD	TATA spare parts
289454509923	BEZEL 3 SW PACK RHD	TATA spare parts
289454509928	BEZEL 2 SW PACK RHD BS6	TATA spare parts
289454509929	CARRIER PLATE 2 SW PACK RHD BS6	TATA spare parts
289454509930	DUMMY KNOB 4X4 BS6	TATA spare parts
289454600101	WIRING HARNESS ENGINE 3 LTR.DICOR	TATA spare parts
289454600105	W/H FRONT LHD/RHD, 2.2L DICOR [TYCO]	TATA spare parts
289454600108	W/H CABIN LHD 2.2L DICOR [M/S.TYCO]	TATA spare parts
289454600116	WIRING HARNESS ROOF (DC)	TATA spare parts
289454600122	W/H TRINARY PR.SW.& B.F.B. SW.[O.D]	TATA spare parts
289454600123	W/H ECU WITHOUT VGT 3.0L DICOR	TATA spare parts
289454600128	WIRING HARNESS ENGINE 3.0L	TATA spare parts
289454600129	W/H FRONT W/O VGT BS-III	TATA spare parts
289454600130	W/H.FRONT W/O.VGT EURO-II EURO-III	TATA spare parts
289454600131	W/H CABIN W/O VGT RHD BS-III/E-III	TATA spare parts
289454600132	W/H.CABIN LHD W/O.VGT	TATA spare parts
289454600133	W/H.ECU 3.0L W/O VGT EURO-III	TATA spare parts
289454600134	W/H.ECU 3.0L W/O.VGT E-II BS-III	TATA spare parts
289454600135	W/H TAIL 4X2 3.0L	TATA spare parts



289454600136	WIRING HARNESS ROOF DOUBLE CAB	TATA spare parts
289454600137	WIRING HARNESS DRIVER DOOR RHD	TATA spare parts
289454600138	WIRING HARNESS DRIVER DOOR LHD	TATA spare parts
289454600139	WIRING HARNESS CO-DRIVER DOOR	TATA spare parts
289454600140	WIRING HARNESS REAR DOOR	TATA spare parts
289454600152	WH CABIN RHD 3L BSIII EII EIII 4X2 4X4	TATA spare parts
289454600155	WH CABIN LHD 3L BSIII EII EIII 4X2 4X4	TATA spare parts
289454600158	WH FRONT RHD LHD 3L BSIII EII EIII 4X2 4	TATA spare parts
289454600165	W/H CABIN XENON 4PL	TATA spare parts
289454600168	W/H FRONT XENON 4PL	TATA spare parts
289454600171	W/H TAIL XENON 4PL	TATA spare parts
289454600173	W/H DRIVER DOOR XENON 4PL	TATA spare parts
289454600174	W/H DRIVER DOOR XENON 4PL	TATA spare parts
289454600175	W/H DRIVER DOOR XENON 4PL	TATA spare parts
289454600185	W/H EMS XENON 4PL	TATA spare parts
289454600192	ASSY INTERFACING CONN SUPPORT	TATA spare parts
289454600202	W/H ROOF BASE SC BS6	TATA spare parts
289454601603	WIRING HARNESS ENGINE 3.0L	TATA spare parts
289454601604	W/H FRONT W/O VGT BS-III	TATA spare parts
289454601605	W/H CABIN W/O VGT RHD BS-III/E-III	TATA spare parts
289454601606	W/H DR DOOR-RHD	TATA spare parts
289454601609	WIRING HARNESS ROOF DOUBLE CAB	TATA spare parts
289454601612	W/H TAIL 4X2 3.0L	TATA spare parts
289454601615	W/H CABIN LHD 3.0L	TATA spare parts
289454601616	WIRING HARNESS DRIVER DOOR LHD	TATA spare parts
289454601617	WIRING HARNESS TAIL	TATA spare parts
289454601630	W/H DRIVER DOOR LHD	TATA spare parts
289454601636	W/H FRONT XENON 2.2L EURO-V [AIRBAG]	TATA spare parts
289454608201	PARKING ANGLE (34-POLE CONNECTOR)	TATA spare parts
289454608202	7-POLE CONN.SUPPORT PLATE	TATA spare parts
289454608203	34 POLE CONNECTOR BRACKET	TATA spare parts
289454608211	ASSY INTER CONN BRACKET FOR XENON BS IV	TATA spare parts
289454610101	WH FRONT EURO-V	TATA spare parts
289454610107	PIGTAIL ASSY EARTH WIRE FOR IMMO DEACTIV	TATA spare parts
289454610113	WIRING HARNESS CABIN	TATA spare parts
289454620101	WH FRONT EURO-V	TATA spare parts
289454620102	WIRING HARNESS TAIL	TATA spare parts
289454620103	WH CABIN NON ABS XENON 4PL	TATA spare parts
289454620104	WH FRONT NON ABS XENON 4PL	TATA spare parts
289454620105	WH TAIL NON ABS XENON 4PL	TATA spare parts
289454620106	W/H TAIL ABS W/O LB (XENON 4PL)	TATA spare parts
289454620110	WIRING HARNESS FRONT	TATA spare parts
289454620111	WIRING HARNESS CABIN	TATA spare parts
289454620116	WIRING HARNESS TAIL	TATA spare parts
289454620117	"WIRING HARNESS,TAIL"	TATA spare parts
289454630101	WH FRONT EURO-V	TATA spare parts
289454800101	KIT-ANTENNA	TATA spare parts

289454801601	KIT-ANTENNA	TATA spare parts
289454801604	ASSY.ANTENNA	TATA spare parts
289454908201	WINDOW WINDING DUEL RELAY HOLDER	TATA spare parts
289454909901	IMMOBILIZER ALERT LABEL	TATA spare parts
289455106301	MASCOT 2.2 VTT	TATA spare parts
289455106302	MASCOT DICOR LH	TATA spare parts
289455106303	MASCOT DICOR RH	TATA spare parts
289455106304	STICKER ABS (DEEP METALLIC SILVER)	TATA spare parts
289455106306	LIMITED SLIP DIFFERENTIAL DECAL-LH	TATA spare parts
289455106307	LIMITED SLIP DIFFERENTIAL DECAL-RH	TATA spare parts
289455106308	GLS MASCOT (FOR LOW END XENON 4PL)	TATA spare parts
289455106310	MASCOT 2.1L (FOR XENON 4PL)	TATA spare parts
289455106312	MASCOT	TATA spare parts
289455106313	MASCOT 3.0 L FOR XENON RX PICKUP	TATA spare parts
289455106314	MASCOT TURBO FOR XENON RX PICKUP	TATA spare parts
289455106315	MASCOT XENON FOR FENDER OUTER FRONT	TATA spare parts
289455106318	DECAL XENON PICKUP FOR TAIL GATE	TATA spare parts
289455106319	DECAL XENON PICKUP FOR FRONT DOOR LH	TATA spare parts
289455106320	DECAL XENON PICKUP FOR FRONT DOOR RH	TATA spare parts
289455106322	DECAL XENON PICKUP FOR FRONT DOOR LH	TATA spare parts
289455106323	DECAL XENON PICKUP FOR FRONT DOOR RH	TATA spare parts
289458304001	ADVANCE WARNING TRIANGLE-EXP.	TATA spare parts
289458304002	ADVANCE WARNING TRIANGLE EXP.	TATA spare parts
289458304003	ADVANCE WARNING TRIANGLE	TATA spare parts
289458408203	TRANSFER LABEL-JACKING INSTRUCTIONS	TATA spare parts
289458408205	DATA PLATE	TATA spare parts
289458408211	TRANSFER LABEL (TYRE PLACARD)-XENON 4X4	TATA spare parts
289458408214	TRANSFER LABEL-(TYRE PRESSURE)	TATA spare parts
289458408217	TRANSFER LABEL - TYRE PLACARD	TATA spare parts
289458409904	OPERATOR S SERVICE BOOK-XENON-2.2L D	TATA spare parts
289458409912	OSB XENON 2.2L/3.0L EXPORT	TATA spare parts
289458904001	FOLDABLE 3 PIECE JACK HANDLE	TATA spare parts
289460000102BF	ASSY BODY COMPLETE RHD 3.0 LTR ARCTIC WH	TATA spare parts
289460000102D3	ASSY BODY COMPLETE RHD 3.0 LTR ARCTIC SI	TATA spare parts
289460000102DP	ASSY BODY COMPLETE RHD 3.0 LTR PASSION R	TATA spare parts
289460000102000000	ASSY BODY COMPLETE RHD 3.0 LTR ARIZONA B	TATA spare parts
289460000104	CAB CC BIW 3.0L PS BU BSIII (XENON) -RHD	TATA spare parts
289460000110BF	ASSY BODY SHELL COMP PAINTED. RHD 3.0 LT	TATA spare parts
289460000110D3	ASSY BODY SHELL COMP PAINTED. RHD 3.0 LT	TATA spare parts
289460000110DP	ASSY BODY SHELL COMP PAINTED. RHD 3.0 LT	TATA spare parts
289460000110DU	ASSY BODY SHELL COMP PAINTED RHD 3 LTR	TATA spare parts
289460000110000000	ASSY BODY SHELL COMP PAINTED. RHD 3.0 LT	TATA spare parts
289460000110FG	ASSY BODY SHELL COMP PAINTED RHD 3 LTR	TATA spare parts
289460000112BF	ARCTIC_WHITE-ASSY BODY SHELL COMPLETE PA	TATA spare parts
289460000112BL	DK_NEPT_BLUE-BODY ASSY PAINTED	TATA spare parts
289460000116BF	ARCTIC_WHITE-BODY ASSY PAINTED BS6	TATA spare parts
289460000121BF	ASSY BODY SHELL COMP PAINTED. LHD 3.0 LT	TATA spare parts

289460000121D3	ASSY BODY SHELL COMP PAINTED. LHD 3.0 LT	TATA spare parts
289460000121DP	ASSY BODY SHELL COMP PAINTED. LHD 3.0 LT	TATA spare parts
289460000121000000	ASSY BODY SHELL COMP PAINTED. LHD 3.0 LT	TATA spare parts
289460000126BF	ASSY BODY COMPLETE LHD 3.0 LTR ARCTIC WH	TATA spare parts
289460000126D3	ASSY BODY COMPLETE LHD 3.0 LTR ARCTIC SI	TATA spare parts
289460000126DP	ASSY BODY COMPLETE LHD 3.0 LTR PASSION R	TATA spare parts
289460000126000000	ASSY BODY COMPLETE LHD 3.0 LTR ARIZONA B	TATA spare parts
289460000127BF	ASSY BODY COMPLETE LHD 2.2 LTR ARCTIC WH	TATA spare parts
289460000127D3	ASSY BODY COMPLETE LHD 2.2 LTR ARCTIC SI	TATA spare parts
289460000127DP	ASSY BODY COMPLETE LHD 2.2 LTR PASSION R	TATA spare parts
289460000127DU	ASSY BODY COMPLETE LHD 2.2 LTR QUARTZ BL	TATA spare parts
289460000127000000	ASSY BODY COMPLETE LHD 2.2 LTR ARIZONA B	TATA spare parts
289460000127FG	ASSY BODY COMPLETE LHD 2.2 LTR MINERAL_R	TATA spare parts
289460000128BF	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289460000128D3	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289460000128DP	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289460000128DU	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289460000128000000	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289460000128FG	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289460000132BF	ASSY.BODY COMPLT.RHD-(2.2L DICOR) ARCTIC	TATA spare parts
289460000132D3	ASSY.BODY COMPLT.RHD-(2.2L DICOR) ARCTIC	TATA spare parts
289460000132000000	ASSY.BODY COMPLT.RHD-(2.2L DICOR) LIGHT_	TATA spare parts
289460000132000000	ASSY.BODY COMPLT.RHD-(2.2L DICOR) ARIZON	TATA spare parts
289460000132EY	ASSY.BODY COMPLT.RHD-(2.2L DICOR) ODYSSY	TATA spare parts
28946000013320	ASSY BODY CED COATED	TATA spare parts
289460000133BF	ASSY BODY SHELL COMP.PAINTED RHD 2.2LTR	TATA spare parts
289460000133D3	ASSY BODY SHELL COMP.PAINTED RHD 2.2LTR	TATA spare parts
289460000133DU	ASSY BODY SHELL COMP.PAINTED RHD 2.2LTR	TATA spare parts
289460000133000000	ASSY BODY SHELL COMP.PAINTED RHD 2.2LTR	TATA spare parts
289460000133000000	ARIZONA BLUE-ASSY FLAT LOAD BODY PAINTED	TATA spare parts
289460000133EY	ASSY BODY SHELL COMP.PAINTED RHD 2.2LTR	TATA spare parts
289460000133FG	ASSY.BODY SHELL PAINTED RHD (2.2L) MINER	TATA spare parts
289460000134	XENON CREWCAB 4X2 2.2L DIC (BIW) RHD	TATA spare parts
289460000141BF	ASSY.BODY.COMPLT.LHD (2.2L DICOR) ARCTIC	TATA spare parts
289460000141D3	ASSY.BODY.COMPLT.LHD (2.2L DICOR) ARCTIC	TATA spare parts
289460000141DP	ASSY.BODY.COMPLT.LHD (2.2L DICOR) PASSIO	TATA spare parts
289460000141DU	ASSY.BODY.COMPLT.LHD (2.2L DICOR) QUARTZ	TATA spare parts
289460000141000000	ASSY.BODY.COMPLT.LHD (2.2L DICOR) ARIZON	TATA spare parts
289460000141FG	ASSY.BODY.COMPLT.LHD (2.2L DICOR) MINERA	TATA spare parts
289460000142BF	ASSY.BODY COMPLT.LHD (3.0L DICOR) ARCTI	TATA spare parts
289460000142D3	ASSY.BODY COMPLT.LHD (3.0L DICOR) ARCTI	TATA spare parts
289460000142DP	ASSY.BODY COMPLT.LHD (3.0L DICOR) PASSIO	TATA spare parts
289460000142000000	ASSY.BODY COMPLT.LHD (3.0L DICOR) ARIZON	TATA spare parts
289460000163BF	ASSY BODY SHELL COMPLETE PAINTED 2 2 LT	TATA spare parts
289460000163D3	ASSY BODY SHELL COMPLETE PAINTED 2 2 LTR	TATA spare parts
289460000163DU	ASSY BODY SHELL COMPLETE PAINTED 2 2 LTR	TATA spare parts
289460000163000000	ASSY BODY SHELL COMPLETE PAINTED 2 2 LTR	TATA spare parts

289460000163FG	ASSY BODY SHELL COMPLETE PAINTED 2 2 LTR	TATA spare parts
289460000172BF	DC RHD 4X2 2.2LPREMIUM S/A ARTIC_WHITE	TATA spare parts
289460000172D3	DC RHD 4X2 2.2LPREMIUM S/A ARTIC_SILVE	TATA spare parts
289460000172DU	DC RHD 4X2 2.2LPREMIUM S/A QUARTZ BLAC	TATA spare parts
289460000172000000	DC RHD 4X2 2.2LPREMIUM S/A ARIZONA_BLU	TATA spare parts
289460000172FG	DC RHD 4X2 2.2LPREMIUM S/A MINERAL_RED	TATA spare parts
289460000175BF	ASSYBODYSHELLCOMPLETEPAINTEDLHD	TATA spare parts
289460000175D3	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289460000175000000	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289460000175FG	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289460000176BF	ASSY BODY COMPLETE LHD 2.2 LTR - DC ARCT	TATA spare parts
289460000176D3	ASSY BODY COMPLETE LHD 2.2 LTR - DC ARCT	TATA spare parts
289460000176000000	ARIZONA_BLUE-ASSY BODY COMPLETE LHD 2.2	TATA spare parts
289460000176FG	ASSY BODY COMPLETE LHD 2.2 LTR - DC MINE	TATA spare parts
289460000176ZY	CLRPRT_ASY_1-ASSY BODY COMPLETE LHD 2.2	TATA spare parts
289460000207ZX	ASSY BODY COMP.4PL 4DR LHD SAUDI ARABIA	TATA spare parts
289460000207ZY	ASSY BODY COMP.4PL 4DR LHD SAUDI ARABIA	TATA spare parts
289460000208BF	ASSY BODY SHELL COMPLETE - SIDE INTR 4-P	TATA spare parts
289460000208D3	ASSY BODY SHELL COMPLETE - SIDE INTR 4-P	TATA spare parts
289460000213ZX	CLRPRT_ASY_2-ASSY BODY COMPLT DOUBLE CAB	TATA spare parts
289460000213ZY	CLRPRT_ASY_1-ASSY BODY COMPLT DOUBLE CAB	TATA spare parts
289460000213ZZ	CLRPART_ASY-ASSY BODY COMPLT DOUBLE CAB	TATA spare parts
289460000214BF	ASSY BODY SHELL COMP PAINTED LHD 2.2 L E	TATA spare parts
289460000214D3	ASSY BODY SHELL COMP PAINTED LHD 2.2 L E	TATA spare parts
289460000214DU	ASSY BODY SHELL COMP PAINTED LHD 2.2 L E	TATA spare parts
289460000214000000	ASSY BODY SHELL COMP PAINTED LHD 2.2 L E	TATA spare parts
289460000214FG	ASSY BODY SHELL COMP PAINTED LHD 2.2 L E	TATA spare parts
289460000215	ASSY BODY SHELL COMPLETE LHD 2.2 LTR EUR	TATA spare parts
289460000216	ASSY BODY SHELL LHD COMP 2.2 LTR EURO V	TATA spare parts
289460000223ZY	CLRPRT_ASY_1-ASSY BODY COMP.4PL 4DR LHD	TATA spare parts
289460000224ZV	ASSY BODY COMPLETE RHD DOM.3 LTR MAN ORV	TATA spare parts
289460000224ZX	ASSY BODY COMPLETE RHD DOM.3 LTR MAN ORV	TATA spare parts
289460000224ZY	ASSY BODY COMPLETE RHD DOM.3 LTR MAN ORV	TATA spare parts
289460000224ZZ	ASSY BODY COMPLETE RHD DOM.3 LTR MAN ORV	TATA spare parts
289460000229BF	ASSY BODY SHELL ARCTIC WHITE COMPLETE PA	TATA spare parts
289460000230ZQ	ASSY BODY COMPLETE RHD 3 LTR XENON RX NO	TATA spare parts
289460000230ZU	ASSY BODY COMPLETE RHD 3 LTR XENON RX NO	TATA spare parts
289460000236BF	ASY B/S COMP PNTED LHD 3/2 L AB SENEGAL	TATA spare parts
289460000236D3	ASY B/S COMP PNTED LHD 3/2 L AB SENEGAL	TATA spare parts
289460000236DU	ASY B/S COMP PNTED LHD 3/2 L AB SENEGAL	TATA spare parts
289460000236000000	ASY B/S COMP PNTED LHD 3/2 L AB SENEGAL	TATA spare parts
289460000236FG	ASY B/S COMP PNTED LHD 3/2 L AB SENEGAL	TATA spare parts
289460000242BF	ARCTIC_WHITE-BODY SHELL ASSY WITH PAINT	TATA spare parts
289460000242D3	ARCTIC_SILVR-BODY SHELL ASSY WITH PAINT	TATA spare parts
289460000242DU	QUARTZ_BLACK-BODY SHELL ASSY WITH PAINT	TATA spare parts
289460000242EO	BODY SHELL COMP PAINTED ASSY AB 2 RR	TATA spare parts
289460000264BF	ARCTIC_WHITE-BODY ASSY PAINTED BS6	TATA spare parts

289460010125BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
289460100101	ASSY BATTERY TRAY LH	TATA spare parts
289460100102	BATTERY TRAY	TATA spare parts
289460100104	ASSY TIE MEMBER COMPLETE	TATA spare parts
289460100107	ASSY B/S HINGE REINF BONNET LH	TATA spare parts
289460100108	ASSY B/S HINGE REINF BONNET RH	TATA spare parts
289460100118	INTERCOOLER MTG BRACKET LH 2_2 LTR	TATA spare parts
289460100120	ASSY INT.COOLER MTG BKT TOP LH 3 LTR	TATA spare parts
289460100121	ASSY RAD AND INTER MTG BKT TOP LH 3 LTR	TATA spare parts
289460100122	ASSY RADIATOR MTG BKT TOP RH 3 LTR DICOR	TATA spare parts
289460100123	ASSY RAD AND INT MTG BKT BOTTOM LH 3 LTR	TATA spare parts
289460100124	ASSY RADIATOR MTG BKT BOTTOM RH 3 LTR	TATA spare parts
289460100129	ASSY CLOSING WHEEL ARCH LH	TATA spare parts
289460100130	ASSY CLOSING WHEEL ARCH RH	TATA spare parts
289460100131	ASSY RADIATOR MTG BRACKET LOWER RH 2.2L	TATA spare parts
289460100135	ASSY SHOT GUN LH	TATA spare parts
289460100136	ASSY SHOT GUN RH	TATA spare parts
289460100139	INTERCOOLER MTG BRACKET LH 2 2 LTR EURO	TATA spare parts
289460107101	BIW NUMBER PLATE	TATA spare parts
289460108205	SHOTGUN LH	TATA spare parts
289460108206	SHOTGUN RH	TATA spare parts
289460108234	RADIATOR MTG BRACKET BOTTOM LH 2_2 LTR	TATA spare parts
289460600101	ASSY FENDER INNER UPPER LH 3 LTR	TATA spare parts
289460600102	ASSY FENDER INNER UPPER COMP RH 3L	TATA spare parts
289460600105	ASSY FENDER INR UPPR LH	TATA spare parts
289460600106	ASSY FENDER INR UPPR RH	TATA spare parts
289460600111	ASSY WHEELARCH LH	TATA spare parts
289460600112	ASSY WHEELARCH RH	TATA spare parts
289460600114	ASSY FENDER INNER UPPER COMP.2.2/4DL	TATA spare parts
289460600116	ASSY_2_2_AIR_RESV_BRKT_REAR	TATA spare parts
289460600118	ASSY 2.2 AIR RESV MTG BKT FRONT	TATA spare parts
289460600119	ASSY W/A LH WITH BATTERY TRAY - 2.2LT	TATA spare parts
289460600121	ASSY FENDER INNER COMPLT 2.2 LTR RH	TATA spare parts
289460600123	ASSY W/A RH WITH BATTERY TRAY - 3 LTR	TATA spare parts
289460600139	ASSY FENDER INR UPPER 2.2 L RH COMP EURO	TATA spare parts
289460600143	BLANKING PLATE	TATA spare parts
289460608213	ASSY_2_2_AIR_RESV_BRKT_MIDDLE	TATA spare parts
289460608220	BLANKING PLATE FOR CNG/4PL AIRINLET	TATA spare parts
289460608231	AIR INTAKE UMBRELLA COVER	TATA spare parts
289461000104	ASSY FLOOR WITH SUBSTRUCTURE COMPLETE	TATA spare parts
289461000109	SUBSTRUCTURE ASSY WITH FLOOR	TATA spare parts
289461000110	ASSY SUBSTR WITH FLOOR RHD	TATA spare parts
289461000130	SUBSTRUCTURE ASSY WITH FLOOR BS6	TATA spare parts
289461000133	SUBSTRUCTURE ASSY WITH FLOOR	TATA spare parts
289461100104	ASSY CAB LIFTING HOOK	TATA spare parts
289461200110	ASSY.SUPPORT HANDBRAKE CTR	TATA spare parts
289461200120	ASSY REINF.HAND BRAKE OUTER	TATA spare parts

289461200133	EYE BOLT ASSY	TATA spare parts
289461203201	EYE BOLT SEAT RESTRAIN AIRBAG	TATA spare parts
289461206301	EYE BOLT SLEEVE SEAT RESTRAIN AIRBAG	TATA spare parts
289461600114	ASSY CUP LH(CAB FRONT)	TATA spare parts
289461600115	ASSY CUP RH (CAB FRONT)	TATA spare parts
289461600197	SUBSTRUCTURE ASSY WITH FLOOR	TATA spare parts
289461606301	CAP 4X4 MECH SHIFTING TUNNEL CUTOUT	TATA spare parts
289462508203	COWL PANEL	TATA spare parts
289462600105	ASSY FIREWALL COMPLETE	TATA spare parts
289462600112	ASSY DASH PANEL COMP.LHD.	TATA spare parts
289462600125	ASSY DASH PANEL COMPLETE LHD EURO V WITH	TATA spare parts
289462600130	ASSY DASH PANEL COMPLETE RHD EURO V WITH	TATA spare parts
289462600132	DASH PANEL ASSY	TATA spare parts
289463100103	ASSY REINF CROSS CAR BEAM LH	TATA spare parts
289463100104	ASSY REINF CROSSCAR BEAM RH	TATA spare parts
289463100105	ASSY REINF.DOOR STOP	TATA spare parts
289463100111	ASSY REINF STRIKER FRONT	TATA spare parts
289463100120	ASSY REINF A PILLAR UPPER LH	TATA spare parts
289463100121	ASSY REINF A PILLAR UPPER RH	TATA spare parts
289463100145	ASSY REINF RETRACTOR B PILLAR LH	TATA spare parts
289463100146	ASSY REINF RETRACTOR B PILLAR RH	TATA spare parts
289463100149	ASSY REINF A PILLAR LOWER COMPLT LH	TATA spare parts
289463100150	ASSY REINF A PILLAR LOWER COMPLT RH	TATA spare parts
289463100151	ASSY FILLER EXP FOAM CANT RAIL FRT LH	TATA spare parts
289463100152	ASSY FILLER EXP FOAM CANT RAIL FRT RH	TATA spare parts
289463100155	ASSY FILLER EXP FOAM A PILLAR LH	TATA spare parts
289463100156	ASSY FILLER EXP FOAM A PILLAR RH	TATA spare parts
289463100157	ASSY FILLER EXP FOAM SILL INR FRT LH	TATA spare parts
289463100158	ASSY FILLER EXP FOAM SILL INR FRT RH	TATA spare parts
289463100159	ASSY FILLER EXP FOAM SILL INR REAR LH	TATA spare parts
289463100160	ASSY FILLER EXP FOAM SILL INR REAR RH	TATA spare parts
289463600101	ASSY BODYSIDE INNR LH	TATA spare parts
289463600102	ASSY BODYSIDE INNR RH	TATA spare parts
289463600107	ASSY BODY SIDE INNER REAR COMPLETE LH BS	TATA spare parts
289463600108	ASSY BODY SIDE INNER REAR COMPLETE RH BS	TATA spare parts
289463600109	ASSY PANEL BODYSIDE INNER FRONT LH	TATA spare parts
289463600110	ASSY PANEL BODYSIDE INNER FRONT RH	TATA spare parts
289463600113	BODY SIDE ASSY INNER PANEL LH BS6	TATA spare parts
289463600114	BODY SIDE ASSY INNER PANEL RH BS6	TATA spare parts
289463700101	ASSY BODYSIDE OUTER LH	TATA spare parts
289463700102	ASSY BODYSIDE OUTER RH	TATA spare parts
289463700105	BODY SIDE ASSY OUTER-LH	TATA spare parts
289463700106	BODY SIDE ASSY OUTER-RH	TATA spare parts
289463708201	BODY SIDE OUTER-LH BS6-PH2	TATA spare parts
289463708202	BODY SIDE OUTER-RH BS6-PH2	TATA spare parts
289463708207	STIFFENER A-PILLAR REINF.LOWER LH	TATA spare parts
289463708208	STIFFENER A-PILLAR REINF.LOWER RH	TATA spare parts

289464200101	ASSY REINF REAR WALL	TATA spare parts
289464200106	ASSY REINF.REAR SEAT STRIKER MTG	TATA spare parts
289464208207	CORNER REINF.REAR WALL	TATA spare parts
289464208208	VERTICAL LOWER REINF REAR WALL LH	TATA spare parts
289464208209	VERTICAL LOWER REINF REAR WALL RH	TATA spare parts
289464700101	ASSY REAR WALL	TATA spare parts
289464700103	REAR WALL ASSY	TATA spare parts
289465100105	ASSY FRONT HEADER	TATA spare parts
289465108201	ROOF BOW CENTRE	TATA spare parts
289465108203	REAR HEADER	TATA spare parts
289465708201	PANEL ROOF	TATA spare parts
289465708202	PANEL ROOF WITH ROOF RAIL	TATA spare parts
289467100101	WINDSHIELD GLASS BS1/3/4	TATA spare parts
289467100102	WINDSHIELD GLASS W/O DARK BAND AT TOP	TATA spare parts
289467102301	WINDSHIELD GLASS	TATA spare parts
289467106301	RUBBER MOULD WINDSHIELD GLASS	TATA spare parts
289467106301AE	RUBB MOULD W/GLASS -XENON DC/SC	TATA spare parts
289467106302	STOPPER - WIND SHIELD GLASS	TATA spare parts
289467106303	WINDSHIELD MOULD - PCRCL - THAILAND	TATA spare parts
289467106304	STOPPER WIND SHIELD GLASS - PCRCL - THA	TATA spare parts
289467802301	FIXED GLASS REAR WINDOW WITHOUT HEATING	TATA spare parts
289467802302	FIXED GLASS REAR WINDOW WITH HEATING	TATA spare parts
289467802302AE	FIXED GLSS R WNDW W/HTING-XEN DC	TATA spare parts
289467806301	END BID	TATA spare parts
289467806302	VERTICAL FOAM BETWEEN GLASS REAR WINDOW	TATA spare parts
289467806303	HORIZONTAL FOAM BETWEEN GLASS REAR WIND	TATA spare parts
289467807701	SEAL REAR SLIDING WINDOW BS6	TATA spare parts
289468200103	NOISE INSULATION FEN INNER LH 2.2 LTR	TATA spare parts
289468200104	NOISE INSULATION FEN INNER RH 2.2 LTR	TATA spare parts
289468406301	MELT SHEET FOR FLOOR PANEL FRONT	TATA spare parts
289468406310	MELT SHEET FOR REAR	TATA spare parts
289468406311	MELT SHEET REAR FLOOR SIDE	TATA spare parts
289468500101	ASSY FLOOR MOULDED CARPET GRAY LHD	TATA spare parts
289468500102	ASSY FLOOR MOULDED CARPET GRAY RHD	TATA spare parts
289468500103	NVH INSULATION UNDER TUNNEL	TATA spare parts
289468500106	ASSY FLOOR MOULDED CARPET RHD BR35	TATA spare parts
289468500107	NVH INSULATION UNDER TUNNEL 4X4 MECH SHI	TATA spare parts
289468500108	CARPET ASSY FLOOR	TATA spare parts
289468500109	CARPET ASSY FLOOR BS6	TATA spare parts
289468506301	CARPET REAR FLOOR BS6-PH2	TATA spare parts
289468506302	CARPET FRONT FLOOR LH BS6-PH2	TATA spare parts
289468506303	INSULATION FOR DASH PANEL CABSIDE LHD	TATA spare parts
289468506304	INSULATION FOR DASH PANEL CAB SIDE RHD	TATA spare parts
289468506305	INSULATION FIREWALL ENGINE SIDE LHD	TATA spare parts
289468506306	INSULATION FIREWALL ENGINE SIDE RHD	TATA spare parts
289468506307	NVH INSULATION FELT GEAR LEVER	TATA spare parts
289468506308	COVER FOR BCM MTG.(GRAY)	TATA spare parts

289468506310	COVER BCM MTG BR35(BIEGE)	TATA spare parts
289468506321	INSULATION FIRE WALL ENGINE SIDE LHD	TATA spare parts
289468506322	FLOOR MOULDED VINYL CARPET BACKED BY FEL	TATA spare parts
289468506323	INSULATION PANEL DASHBOARD	TATA spare parts
289468506324	CARPET FRONT TUNNEL BS6-PH2	TATA spare parts
289468806303	FIRE WALL INSULATION CAB SIDE LHD	TATA spare parts
289468900102	ASSY DASHBOARD RHD	TATA spare parts
289468900103	ASSY LID GLOVE BOX RHD NG003	TATA spare parts
289468900106	ASSY A/C VENT LH	TATA spare parts
289468900107	ASSY A/C VENT RH	TATA spare parts
289468900108	ASSY A/C VENTS CENTRE	TATA spare parts
289468900109	ASSY CENTER CONSOLE BUCKET TYPE	TATA spare parts
289468900110	ASSY BELLOW GEAR SHIFT LEVER 4X2	TATA spare parts
289468900112	ASSY ASH TRAY	TATA spare parts
289468900114	ASSY FLOOR CONSOLE BUCKET TYPE	TATA spare parts
289468900115	ASSY CENTRE CONSOLE BENCH TYPE	TATA spare parts
289468900118	ASSY BKT CCB MTG LH (BODY SIDE)	TATA spare parts
289468900119	ASSY BKT CCB MTG RH (BODY SIDE)	TATA spare parts
289468900126	ASSY SUPPORT TUBE CROSS CAR BEAM RHD	TATA spare parts
289468900127	ASSY CROSS MEMBER DASHBOARD COMPL	TATA spare parts
289468900147	ASSY CROSS MEMBER DASHBOARD COMPL LHD	TATA spare parts
289468900148	ASSY DASHBOARD LHD	TATA spare parts
289468900149	ASSY LID GLOVE BOX LHD	TATA spare parts
289468900153	ASSY FACIA A/C CTRL BUCKET TYPE	TATA spare parts
289468900155	ASSY DASHBOARD COMPLETE RHD BENCH TYPE	TATA spare parts
289468900162	ASSY.STEERING WHEEL(SUN)	TATA spare parts
289468900163	ASSY_WINDSHIELD_DEMIST_DUCT	TATA spare parts
289468900167	ASSY STG PAINTED + LEATHER	TATA spare parts
289468900170	ASSY DASHBOARD RHD B002	TATA spare parts
289468900171	ASSY A/C VENTS LH H1	TATA spare parts
289468900172	ASSY A/C VENTS RH H1	TATA spare parts
289468900176	ASSY CENTRE CONSOLE BUCK	TATA spare parts
289468900177	ASSY CENTRE CONSOLE BUCK	TATA spare parts
289468900178	ASSY ASH TRAY	TATA spare parts
289468900179	ASSY ASH TRAY	TATA spare parts
289468900180	ASSY BELLOW GEAR SHIFT LEVER	TATA spare parts
289468900181	ASSY DASHBOARD RHD H1	TATA spare parts
289468900182	ASSY FLOOR CONSOLE BUCKET ARGENT GREY	TATA spare parts
289468900186	ASSY DASHBOARD LHD - H1	TATA spare parts
289468900203	ASSEMBLY NACELLE TOP DIA 380 COLLAPS STG	TATA spare parts
289468900206	ASSEMBLY NACELLE TOP DIA 380 COLLAPS STG	TATA spare parts
289468900217	ASSY STEERING WHEEL D380 COLLPS PAINTED	TATA spare parts
289468900219	PAINTED LEATHER (GREY)	TATA spare parts
289468900220	ASSY STEERING WHEEL D380 COLLPS UNPAINTE	TATA spare parts
289468900224	ASSY HORN PAD D380 COLLP HIGH END NG003	TATA spare parts
289468900228	ASSY HORN PAD D380 COLLP HIGH END NG003	TATA spare parts
289468900229	ASSY STEERING WHEEL D380 COLLPS NON LEAT	TATA spare parts



289468900230	ASSY HORN PAD D380 COLLP LOW END NG003	TATA spare parts
289468900317	REMOTE LEVER AND CABLE ASSEMBLY FOR HOOD	TATA spare parts
289468900321	REMOTE LEVER AND CABLE ASSEMBLY FOR FUEL	TATA spare parts
289468900323	ASSY D/B CROSS MBR COMPLETE LHD AIRBAG	TATA spare parts
289468900333	ASSY REMOTE LEVER CABLE	TATA spare parts
289468900334	ASSY D/B CROSS MBR COMPLETE RHD AIRBAG	TATA spare parts
289468906301	DASHBOARD SKIN RHD	TATA spare parts
289468906302	FLOOR CONSOLE BUCKET TYPE	TATA spare parts
289468906303	A/C VENTILATION DUCT (BLOW MOULDED)	TATA spare parts
289468906304	STEERING COLUMN COVER RHD	TATA spare parts
289468906306	WINDSHIELDEMISTDUCT(INJMOULDED) BS6	TATA spare parts
289468906307	GARNISH WINDSHIELD DUCT	TATA spare parts
289468906308	DOOR DEMIST DUCT LH (BLOW MOULDED)	TATA spare parts
289468906309	DOOR DEMIST DUCT RH (BLOW MOULDED)	TATA spare parts
289468906313	MATT FLOOR CONSOLE BUCKET TYPE	TATA spare parts
289468906314	MATT FLOOR CONSOLE BENCH TYPE	TATA spare parts
289468906317	NACELLE TOP RHD	TATA spare parts
289468906318	NACELLE BOTTOM RHD	TATA spare parts
289468906319	BINNACLE INSTRUMENT CLUSTER REAR RHD	TATA spare parts
289468906320	BINNACLE INSTRUMENT CLUSTER FRONT RHD	TATA spare parts
289468906321	CENTER CONSOLE BUCKET TYPE	TATA spare parts
289468906323	LOCATOR TOP CENTRE DASHBOARD	TATA spare parts
289468906326	CENTRE CONSOLE BENCH TYPE	TATA spare parts
289468906327	FLOORCONSOLEBENCHTYPE BS6	TATA spare parts
289468906328	DASHBOARD SKIN LHD	TATA spare parts
289468906329	NACELLE TOP LHD	TATA spare parts
289468906330	NACELLE BOTTOM LHD	TATA spare parts
289468906331	BINNACLE INSTRUMENT CLUSTER REAR LHD	TATA spare parts
289468906332	INSTRUMENT CLUSTER FRONT LHD	TATA spare parts
289468906333	STEERING COLUMN COVER LHD	TATA spare parts
289468906336	COIN HOLDER / BOTTLE HOLDER	TATA spare parts
289468906337	GARNISH WINDSHIELD DUCT CENTRE RH	TATA spare parts
289468906338	GARNISH WINDSHIELD DUCT SIDE LH	TATA spare parts
289468906339	GARNISH WINDSHIELD DUCT SIDE RH	TATA spare parts
289468906341	RUBBER DAMPER	TATA spare parts
289468906342	RUBBER SLEEVE BINNACLE REAR MTG W-DASH	TATA spare parts
289468906343	HINGE PIN GLOVE BOX	TATA spare parts
289468906344	PU FOAM DEMIST DUCT FRONT	TATA spare parts
289468906346	PU FOAM AC-VENT CENTRE	TATA spare parts
289468906347	PU FOAM AC-VENT DOOR DEMISTER	TATA spare parts
289468906348	PU FOAM REAR WS-DEMIST DUCT DEFLECTOR	TATA spare parts
289468906349	PU FOAM FROMT WS-DEMIST DUCT DEFLECTOR	TATA spare parts
289468906350	NACELLE TOP	TATA spare parts
289468906351	NACELLE BOTTOM	TATA spare parts
289468906356	BINNACLE FRONT-B002	TATA spare parts
289468906360	BOTTLE HOLDER / COIN HOLDER B002	TATA spare parts
289468906361	MATT FLOOR CONSOLE BUCKET TYPE	TATA spare parts

289468906361_niu1	MATT FLOOR CONSOLE BUCKET TYPE	TATA spare parts
289468906362	STEERING COLUMN COVER RHD B002	TATA spare parts
289468906365	GARNISH WINDSHIELD DUCT SIDE LH	TATA spare parts
289468906366	GARNISH WINDSHIELD DUCT SIDE RH	TATA spare parts
289468906381	NACELLE BOTTOM DIA 380 C	TATA spare parts
289468906387	NACELLE RUBBER FLAP RH NG003	TATA spare parts
289468906396	FLOOR CONSOLE BUCKET TYPE NG003 LOW END	TATA spare parts
289468906398	STOPPER GLOVE BOX COVER LH (NG003)	TATA spare parts
289468906399	STOPPER GLOVE BOX COVER RH (NG003)	TATA spare parts
289468906418	CROSS LINKED FOAM-DASH BOARD	TATA spare parts
289468906419	DASHBOARD UNDER COVER RHD LH	TATA spare parts
289468906420	DASHBOARD UNDER COVER RHD RH	TATA spare parts
289468906478	FLOOR CONSOLE BUCKET TYPE B002 WITH TOP	TATA spare parts
289468906480	COVER A/C VENT-CENTER NG003	TATA spare parts
289468906481	COVER A/C VENT LH NG003	TATA spare parts
289468906482	COVER A/C VENT RH NG003	TATA spare parts
289468906902	SUPPORT TUBE CROSS CAR BEAM	TATA spare parts
289469100101	ASSY AIR EXTRACTOR VALVE	TATA spare parts
289469106301	FOAM - NVH - FRONT FENDER LH	TATA spare parts
289469106302	FOAM - NVH - FRONT FENDER RH	TATA spare parts
289469106303	FOAM - NVH - B PILLER DOOR SEALING LH	TATA spare parts
289469106304	FOAM - NVH - B PILLAR DOOR RH	TATA spare parts
289469106305	FOAM - NVH - A POST LH	TATA spare parts
289469106306	FOAM - NVH - A POST RH	TATA spare parts
289469200102	TRIM A PILLAR LOWER LH	TATA spare parts
289469200103	TRIM A PILLAR LOWER RH	TATA spare parts
289469200104	TRIM A PILLAR UPPER LH GRAY	TATA spare parts
289469200105	TRIM A PILLAR UPPER RH GRAY	TATA spare parts
289469200106	TRIM C PILLAR UPPER LH GRAY	TATA spare parts
289469200107	TRIM C PILLAR UPPER RH	TATA spare parts
289469200108	TRIM C PILLAR LOWER LH	TATA spare parts
289469200109	TRIM C PILLAR LOWER RH	TATA spare parts
289469200110	ASSY TRIM B PILLAR UPPER LH GRAY	TATA spare parts
289469200111	ASSY TRIM B PILLAR UPPER RH GRAY	TATA spare parts
289469200112	ASSY TRIM B PILLAR LOWER LH	TATA spare parts
289469200113	ASSY TRIM B PILLAR LOWER RH	TATA spare parts
289469200114	ASSY.TRIM A PILLAR UPPER LH B001	TATA spare parts
289469200115	ASSY.TRIM A PILLAR UPPER RH B001	TATA spare parts
289469200116	ASSY.TRIM A PILLAR LOWER LH B002	TATA spare parts
289469200117	ASSY.TRIM A PILLAR LOWER RH B002	TATA spare parts
289469200118	ASSY.TRIM `B` PILLAR UPPER LH BEIGE	TATA spare parts
289469200119	ASSY.TRIM `B` PILLAR UPPER RH BEIGE	TATA spare parts
289469200120	ASSY.TRIM `B` PILLAR LOWER LH B002	TATA spare parts
289469200121	ASSY.TRIM `B` PILLAR LOWER RH BEIGE B002	TATA spare parts
289469200122	ASSY.TRIM `C` PILLAR UPPER LH B001	TATA spare parts
289469200123	ASSY.TRIM `C` PILLAR UPPER RH B001	TATA spare parts
289469200124	ASSY.TRIM `C` PILLAR LOWER LH B002	TATA spare parts

289469200125	ASSY.TRIM `C` PILLAR LOWER RH B002	TATA spare parts
289469200141	ASSY TRIM REAR WALL CROSS MEMBER B001	TATA spare parts
289469200160	ASSY TRIM B PILLAR LOWER LH 4DR FOR AIRB	TATA spare parts
289469200161	ASSY TRIM B PILLAR LOWER RH 4DR FOR AIRB	TATA spare parts
289469206301	TRIM A PILLAR UPPER LH	TATA spare parts
289469206302	TRIM A PILLAR UPPER RH	TATA spare parts
289469206303	TRIM B PILLAR UPPER LH	TATA spare parts
289469206304	TRIM B PILLAR UPPAR RH	TATA spare parts
289469206305	TRIM B PILLAR LOWER LH	TATA spare parts
289469206306	TRIM B PILLAR LOWER RH	TATA spare parts
289469206309	SCUFF PLATE FRONT LH	TATA spare parts
289469206310	SCUFF PLATE FRONT RH	TATA spare parts
289469206311	SCUFF PLATE REAR LH	TATA spare parts
289469206312	SCUFF PLATE REAR RH	TATA spare parts
289469206313	TRIM C PILLAR UPPER LH	TATA spare parts
289469206314	TRIM C PILLAR UPPER RH	TATA spare parts
289469206315	TRIM C PILLAR LOWER LH	TATA spare parts
289469206316	TRIM C PILLAR LOWER RH	TATA spare parts
289469206317	TRIM A PILLAR LOWER LH	TATA spare parts
289469206318	TRIM A PILLAT LOWER RH	TATA spare parts
289469206319	TRIM REAR WALL CROSS MEMBER 4-D00R	TATA spare parts
289469206322	CAP(BONNET OPENING LEVER)	TATA spare parts
289469206323	CAP SCUFF PLATE	TATA spare parts
289469206337	SCUFF PLATE FRONT LH B002	TATA spare parts
289469206338	SCUFF PLATE FRONT RH B002	TATA spare parts
289469206339	SCUFF PLATE REAR LH	TATA spare parts
289469206340	SCUFF PLATE REAR RH	TATA spare parts
289469206347	DUMMY CAP(BONNET OPENING LEVER)BR35	TATA spare parts
289469500101	ASSY SUNVISOR LH RHD	TATA spare parts
289469500102	ASSY SUNVISOR RH RHD	TATA spare parts
289469500103	ASSY SUNVISOR LH LHD	TATA spare parts
289469500104	ASSY SUNVISOR RH LHD	TATA spare parts
289469500105	ASSY.ROOF LINING 4 DR	TATA spare parts
289469500105AE	ASSY.ROOF LNG 4 DR -XENON DC/SC	TATA spare parts
289469500109	ROOF LINER ASSY BS6	TATA spare parts
289469500110	KIT FIT OF ROOF INSULATION 4DR	TATA spare parts
289469500111	ASSY.SUNVISOR LH RHD	TATA spare parts
289469500112	ASSY.SUNVISOR RH RHD	TATA spare parts
289469500113	ASSY.SUNVISOR LH LHD B001	TATA spare parts
289469500114	ASSY.SUNVISOR RH LHD B001	TATA spare parts
289469500116	ASSY ROOF LINING	TATA spare parts
289469500125	ASSY GRAB HANDLE COLLAPSIBLE	TATA spare parts
289469500126	ASSY SUNVISOR LH RHD - BE 88	TATA spare parts
289469500127	ASSY SUNVISOR RH RHD - BE 88	TATA spare parts
289469500129	ASSY GRAB HANDLE COLLAPSIBLE NG002	TATA spare parts
289469506304	CRASS LINKED FOAM CAB LAMP AREA	TATA spare parts
289469506305	CROSS BONDED FOAM FOR A-PILLAR TOP	TATA spare parts

289469506306	FOAM SUNVISOR BS6-PH2	TATA spare parts
289469506307	4DR ROOF INSULATION FRONT	TATA spare parts
289469506311	CROSSLINKED FOAM SUNVISOR AREA	TATA spare parts
289469506319	PLASTIC BUTTON GRAB HANDLE HOLE BR35	TATA spare parts
289469506320	TRIM CLIP FOR HEADLINIG BE 88	TATA spare parts
289469506323	ROOF LINING BUTTON	TATA spare parts
289469506324	POT HOOK SUNVISOR NG002	TATA spare parts
289469506325	POT HOOK SUNVISOR B001	TATA spare parts
289469506326	POT HOOK SUNVISOR BE88	TATA spare parts
289469506359	PLUG GRAB HANDLE - BR 35	TATA spare parts
289469508201	FIXING CLIP FOR FRONT ROOF LAMP	TATA spare parts
289469508202	FIXING CLIP FOR REAR ROOF LAMP	TATA spare parts
289470000103	ASSY.LOADBODY COMP PAINTED RHD	TATA spare parts
289470000103BF	ASSY. LOAD BODY COMPLETE PAINTED LHD AR	TATA spare parts
289470000103BL	ASSY.LOADBODY COMP PAINTED RHD	TATA spare parts
289470000103D3	ASSY.LOADBODY COMP PAINTED RHD ARCTIC SI	TATA spare parts
289470000103DP	ASSY. LOAD BODY COMPLETE PAINTED LHD PA	TATA spare parts
289470000103DU	ASSY. LOAD BODY COMPLETE PAINTED LHD QUA	TATA spare parts
28947000010300000	ASSY.LOADBODY COMP PAINTED RHD	TATA spare parts
289470000103000000	ASSY. LOAD BODY COMPLETE PAINTED LHD AR	TATA spare parts
289470000103EO	ASSY LOAD BODY COMP PAINTED RHD	TATA spare parts
289470000103EY	ASSY.LOADBODY COMP PAINTED RHD	TATA spare parts
289470000103FG	ASSY.LOADBODY COMP PAINTED RHD MINERAL R	TATA spare parts
289470000104	ASSY.LOADBODY COMPLETE RHD UNPAINTED	TATA spare parts
289470000107	ASSY.KIT FIT.OF LOADBODY MUDLINERS LH	TATA spare parts
289470000108	ASSY.KIT.FIT.OF LOADBODY MUDLINERS RH	TATA spare parts
289470000109	ASSY.KIT FIT OF MUDFLAP LH	TATA spare parts
289470000110	ASSY.KIT FIT OF MUDFLAP RH	TATA spare parts
289470000120BF	ARCTIC_ WHITE-LOAD BODY ASSY	TATA spare parts
28947000013020	ASSY LOAD BODY CED COATED	TATA spare parts
289470000131	ASSY LOADBODY COMPLETE THAI W/R	TATA spare parts
289470000139	KIT - LOAD BODY FITMENTS PLM ONWARDS	TATA spare parts
289470000140	ASSY MUD FLAP REAR LH-LONGER	TATA spare parts
289470000141	ASSY MUD FLAP REAR RH-LONGER	TATA spare parts
289470000157	LOAD BODY ASSY REAR EXTENDED	TATA spare parts
289470000165BF	ARCTIC_ WHITE_ ASSY LOADBODY PAINTED REAR	TATA spare parts
289470000173BF	ARCTIC_ WHITE-LOAD BODY ASSY BS6	TATA spare parts
289470000175	LOAD BODY ASSY WITH FASTENERS BS6	TATA spare parts
289470006301	MUDFLAP REAR LH	TATA spare parts
289470006302	MUDFLAP REAR RH	TATA spare parts
289470006303	MUDLINER REAR OUTER FRONT SIDE LH	TATA spare parts
289470006304	MUDLINER REAR OUTER FRONT SIDE RH	TATA spare parts
289470006305	MUDLINER REAR OUTER REAR SIDE LH	TATA spare parts
289470006306	MUDLINER REAR OUTER REAR SIDE RH	TATA spare parts
289470100101	ASSY LOADBODY UNDERSTRUCTURE 4DR	TATA spare parts
289470100106	ASSY REAR CLOSING PANEL	TATA spare parts
289470100118	ASSY L/B SUB STR W/O SUPP BKT	TATA spare parts

289470106301	GROMMET - LOADBODY FLOOR - CNG	TATA spare parts
289470106901	STAY ROD LH	TATA spare parts
289470106902	STAY ROD RH	TATA spare parts
289470108001	HEX.FL.SCR.M6X16 TS17130 A2-70 ST.STEEL	TATA spare parts
289470108002	CRFL PANHD TAPSCR C-ST4.2X16TS17249A2-5	TATA spare parts
289470108201	LOADBODY FLOOR 4DR	TATA spare parts
289470108202	REAR CLOSING PANEL	TATA spare parts
289470108216	REINFORCEMENT REAR CLOSING PANEL	TATA spare parts
289470108224	CORNER REINF.LH - REAR CLOSING PANEL	TATA spare parts
289470108225	CORNER REINF RH - REAR CLOSING PANEL	TATA spare parts
289470108230	BRACKET L/B OUTER MUDLINER MOUNTING	TATA spare parts
289470108268	MUDGUARD CENTER BS6	TATA spare parts
289470200101	FRONT PANEL ASSY WITH CRASH GUARD	TATA spare parts
289470200104	ASSY.LOAD GUARD COMP.(TUBULAR)	TATA spare parts
289470200110	ASSY LOADBODY FRONT PANEL	TATA spare parts
289470206301	PLASTIC CAP LOAD GUARD	TATA spare parts
289470206501	HEX.FLG.SCREW M8X60 ST.STEEL	TATA spare parts
289470208201	LOAD BODY FRONT PANEL	TATA spare parts
289470208202	REINFORCEMENT FRONT PANEL	TATA spare parts
289470300105	ASSY.FENDER COMPLETE LH	TATA spare parts
289470300106	ASSY FENDER COMPLETE RH	TATA spare parts
289470300109	FUEL FILTER HOUSING	TATA spare parts
289470300110	ASSY STRIKER POST LH	TATA spare parts
289470300111	ASSY STRIKER POST RH	TATA spare parts
289470300112	ASSY FUEL FILLER LID	TATA spare parts
289470300114	SIDE WALL ASSY RH	TATA spare parts
289470300121	ASSY FENDER INNER REAR LH	TATA spare parts
289470300122	ASSY FENDER INNER REAR RH	TATA spare parts
289470300126	SIDE WALL ASSY LH	TATA spare parts
289470300127	WHEEL ARCH OUTER PANEL LH	TATA spare parts
289470300138	ASSY STAY TUBE REAR	TATA spare parts
289470300139	ASSY.NUT-PLATE FOR REAR CORNER BUMPER	TATA spare parts
289470300140	ASSY END PIECE LH(FEN INNER) KIT THAI	TATA spare parts
289470300141	ASSY END PIECE RH(FEN INNER) TAHI KIT	TATA spare parts
289470300144	ASSY KIT FOR HOOK-LOADBODY	TATA spare parts
289470306302	EXPANDABLE PAD - LOADBODY FENDER	TATA spare parts
289470306303	DAMPER FOAM FUEL FLAP	TATA spare parts
289470308201	LOADBODY FENDER OUTER LH	TATA spare parts
289470308202	LOADBODY FENDER OUTER RH	TATA spare parts
289470308205	STRIKER POST LH	TATA spare parts
289470308206	STRILER POST RH	TATA spare parts
289470308209	FRONT INFILL PANEL LH	TATA spare parts
289470308210	FRONT INFILL PANEL RH	TATA spare parts
289470308211	WHEEL ARCH OUTER	TATA spare parts
289470308215	HOUSING FUEL FILLER	TATA spare parts
289470308227	FUEL FILLER FLAP HOLDER	TATA spare parts
289470308229	SUPPORT TAIL GATE STRIKER POST	TATA spare parts

289470400104	ASSY CAVITY INSERT TAIL GATE HANDLE	TATA spare parts
289470400104BF	ASSY CAVITY INSERT TAIL GATE HANDLE	TATA spare parts
289470400104D3	ASSY CAVITY INSERT TAIL GATE HANDLE	TATA spare parts
289470400104DP	CAVITY INSERT TAIL GATE HANDLE PASSION R	TATA spare parts
289470400104DU	COVER T/G LATCH QUARTZ BLACK	TATA spare parts
28947040010400000	ASSY CAVITY INSERT TAIL GATE HANDLE	TATA spare parts
289470400104000000	CAVITY INSERT TAIL GATE HANDLE LIGHT_GOL	TATA spare parts
289470400104EY	ASSY CAVITY INSERT TAIL GATE HANDLE	TATA spare parts
289470400104FG	ASSY CAVITY INSERT TAIL GATE HANDLE	TATA spare parts
289470400104FP	ASSY CAVITY INSERT TAIL GATE HANDLE	TATA spare parts
289470400108	ASSY TAILGATE WITH HINGES	TATA spare parts
289470400109	ASSY TAILGATE	TATA spare parts
289470400114	ASSY CENTRE LATCH	TATA spare parts
289470400116	ASSY PULL ROD COMP.	TATA spare parts
289470400118	ASSY.FOOT STEP REAR COMP.	TATA spare parts
289470400120	ASSY.SUPPORT FRONT LH	TATA spare parts
289470400121	ASSY.SUPPORT FRONT RH	TATA spare parts
289470400122	ASSY.SUPPORT REAR RR BUMPER	TATA spare parts
289470400135	ASSY.STRIKER (TAIL GATE LATCH)	TATA spare parts
289470400141	ASSY CENTRE LATCH	TATA spare parts
289470400142	ASSY HINGE TAIL GATE	TATA spare parts
289470400147	ASSY.NEW TAILGATE SIDE LATCH- CAM TYPE	TATA spare parts
289470400148	ASSY STRIKER TAILGATE FOR NEW TAIGATE LA	TATA spare parts
289470400149	ASSY PULL ROD COMPLETE(TAILGATE CAM TYPE	TATA spare parts
289470400150	ASSY.PULL ROD (NEW TAILGATE SIDE LATCH)	TATA spare parts
289470400153	KIT FITMENT OF WIRE ROPES	TATA spare parts
289470406006	TAILGATE WIRE ROPE THAILAND	TATA spare parts
289470406301	REAR CORNER BUMPER LH	TATA spare parts
289470406301BF	REAR CORNER BUMPER LH	TATA spare parts
289470406301D3	REAR CORNER BUMPER LH ARTICT SILVER	TATA spare parts
289470406301DP	REAR CORNER BUMPER LH PASSION RED	TATA spare parts
289470406301DU	REAR CORNER BUMPER LH QUARTZ BLACK	TATA spare parts
289470406301000000	REAR CORNER BUMPER LH ARIZONA BLUE	TATA spare parts
289470406301FG	REAR CORNER BUMPER LH	TATA spare parts
289470406302	REAR CORNER BUMPER RH	TATA spare parts
289470406302BF	REAR CORNER BUMPER RH	TATA spare parts
289470406302D3	REAR CORNER BUMPER RH ARTICT SILVER	TATA spare parts
289470406302DP	REAR CORNER BUMPER RH PASSION RED	TATA spare parts
289470406302DU	REAR CORNER BUMPER RH QUARTZ BLACK	TATA spare parts
289470406302000000	REAR CORNER BUMPER RH ARIZONA BLUE	TATA spare parts
289470406302FG	REAR CORNER BUMPER RH	TATA spare parts
289470406303	COVER T/G LATCH	TATA spare parts
289470406303BF	COVER T/G LATCH ARTICT WHITE	TATA spare parts
289470406303D3	COVER T/G LATCH ARTICT SILVER	TATA spare parts
289470406303DP	COVER T/G LATCH PASSION RED	TATA spare parts
289470406303DU	COVER T/G LATCH QUARTZ BLACK	TATA spare parts
28947040630300000	TAIL GATE PLASTIC OUTER HANDLE	TATA spare parts

289470406303000000	COVER T/G LATCH ARIZONA BLUE	TATA spare parts
289470406303EY	TAIL GATE PLASTIC OUTER HANDLE	TATA spare parts
289470406303FG	TAIL GATE PLASTIC OUTER HANDLE	TATA spare parts
289470406303FP	TAIL GATE PLASTIC OUTER HANDLE	TATA spare parts
289470406304	CAVITY INSERT TAIL GATE HANDLE	TATA spare parts
289470406304BF	CAVITY INSERT TAIL GATE HANDLE RTICT WHI	TATA spare parts
289470406304D3	CAVITY INSERT TAIL GATE HANDLE ARTICT SI	TATA spare parts
289470406304DP	CAVITY INSERT TAIL GATE HANDLE PASSION R	TATA spare parts
289470406304DU	CAVITY INSERT TAIL GATE HANDLE	TATA spare parts
289470406304000000	CAVITY INSERT TAIL GATE HANDLE ARIZONA B	TATA spare parts
289470406305	REAR BUMPER MTG.BRACKET-PLASTIC	TATA spare parts
289470406306	REAR BUMPER MTG.BRACKET-PLASTIC¿ RH	TATA spare parts
289470406902	ALUMINIUM EXTRUSION REAR FOOT STEP	TATA spare parts
289470408225	STRIKING STRAP TAILGATE	TATA spare parts
289470506301	RETRO REFLECTIVE TAPE LH REAR CLOSING PA	TATA spare parts
289470506302	RETRO REFLECTIVE TAPE RH FOR REAR CLOSIN	TATA spare parts
289470506303	RETRO REFLECTIVE TAPE FOR¿ REAR CORNER	TATA spare parts
289470809201	WASHER BODY MTG	TATA spare parts
289472200101	ASSY DOOR SHELL FRONT LH	TATA spare parts
289472200102	ASSY DOOR SHELL FRONT RH	TATA spare parts
289472200116	ASSY FRAME PART LOWER LH	TATA spare parts
289472200117	ASSY FRAME PART LOWER RH	TATA spare parts
289472200124	ASSY DOOR SHELL FRONT LH WITH HINGES	TATA spare parts
289472200125	ASSY DOOR SHELL FRONT RH WITH HINGES	TATA spare parts
289472200132	ASSY F/D LH WITH HINGES - SIDE INTRUSION	TATA spare parts
289472200133	ASSY F/D RH WITH HINGES - SIDE INTRUSION	TATA spare parts
289472200135	ASSY SUPPORT BEARING GUIDE COMPLETE MANU	TATA spare parts
289472200144	INNER PANEL ASSY FRONT DOOR LH	TATA spare parts
289472200145	INNER PANEL ASSY FRONT DOOR RH	TATA spare parts
289472200146	DOORSHELLASSY FRONTDOOR LH	TATA spare parts
289472200147	DOORSHELLASSY FRONTDOOR RH	TATA spare parts
289472206301	REINF.PAD INNER PANEL FRONT DOOR LH	TATA spare parts
289472206302	REINF.PAD INNER PANEL FRONT DOOR RH	TATA spare parts
289472206303	DOOR LATCH SEAL FOAM	TATA spare parts
289472208213	WAIST REINFORCEMENT OUTER LH	TATA spare parts
289472208214	WAIST REINFORCEMENT OUTER RH	TATA spare parts
289472208222	FRAME PART UPPER LH BS6	TATA spare parts
289472208223	FRAME PART UPPER RH BS6	TATA spare parts
289472208227	FRAME PART LOWER LH	TATA spare parts
289472208229	FRAME PART LOWER RH	TATA spare parts
289472300101	ASSY HANDLE WINDOW WINDING	TATA spare parts
289472300102	ASSY STRIKER	TATA spare parts
289472300104	ASSY DOOR OUTER HANDLE FR DR LH	TATA spare parts
289472300104A3	ASSY DOOR OUTER HANDLE FRONT DOOR LH BS6	TATA spare parts
289472300104BF	ASSY DOOR OUTER HANDLE FRONT DOOR LH	TATA spare parts
289472300104CI	ASSY DOOR OUTER HANDLE FRONT DOOR LH	TATA spare parts
289472300104D3	ASSY DOOR OUTER HANDLE FR DR LH	TATA spare parts

289472300104DP	ASSY DOOR OUTER HANDLE FR DR LH	TATA spare parts
289472300104DU	ASSY DOOR OUTER HANDLE FR DR LH QUARTZ B	TATA spare parts
28947230010400000	ASSY DOOR OUTER HANDLE FR DR LH	TATA spare parts
289472300104000000	ASSY DOOR OUTER HANDLE FR DR LH	TATA spare parts
289472300104EY	ASSY DOOR OUTER HANDLE FR DR LH	TATA spare parts
289472300104F2	ASSY DOOR OUTER HANDLE FR DR LH	TATA spare parts
289472300104FG	ASSY DOOR OUTER HANDLE FR DR LH	TATA spare parts
289472300104FP	ASSY DOOR OUTER HANDLE FR DR LH	TATA spare parts
289472300104GA	ASSY DOOR OUTER HANDLE FRONT DOOR LH	TATA spare parts
289472300105	DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105A3	EBONY_1-ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105BF	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105CI	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105D3	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105DP	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105DU	ASSY DOOR OUTER HANDLE FR DR RH QUARTZ B	TATA spare parts
28947230010500000	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105000000	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105EY	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105F2	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105FG	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105FP	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105G6	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105GA	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105GC	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300105GF	ASSY DOOR OUTER HANDLE FR DR RH	TATA spare parts
289472300107	INNER HANDEL ASSY FRONT DOOR RH	TATA spare parts
289472300108	ASSY.CHECK STRAP FRONT DOOR	TATA spare parts
289472300110	ASSY DOOR HINGE	TATA spare parts
289472300114	ASSY.LINK LH(LOCK TO POP_UP KNOB)	TATA spare parts
289472300115	ASSY.LINK RH(LOCK TO POP_UP KNOB)	TATA spare parts
289472300121	ASSY.BRACKET DOOR PULL MTG.	TATA spare parts
289472300122	ASSY DOOR INNER HANDLE WITH LINK F/D LH	TATA spare parts
289472300123	ASSY DOOR INNER HANDLE WITH LINK F/D RH	TATA spare parts
289472300124	ASSY LATCH FRONT DOOR WITH LINK LH	TATA spare parts
289472300125	ASSY LATCH FRONT DOOR WITH LINK RH	TATA spare parts
289472300127	KIT DECORATIVE TAPES FRONT DOOR	TATA spare parts
289472300129	ASSY.KEY SET	TATA spare parts
289472300130	XENON KEY SET(TWO KEYS)	TATA spare parts
289472300131	ASSY.LOCK KIT RHD	TATA spare parts
289472300132	ASSY.LOCK KIT LHD	TATA spare parts
289472300133	FDL LINK SUB ASSY.LH	TATA spare parts
289472300134	FDL LINK SUB ASSY.RH	TATA spare parts
289472300137	ASSY LOCK KIT RHD	TATA spare parts
289472300146	ASSY LOCK KIT LHD COLLAPSIBLE STG NG003	TATA spare parts
289472300147	ASSY LOCK KIT RHD COLLAPSIBLE STG	TATA spare parts
289472300148	ASSY LOCK KIT LHD COLLAPSIBLE STG B002 M	TATA spare parts



289472300149	ASSY LOCK KIT RHD COLLAPSIBLE STG B002 -	TATA spare parts
289472300152	ASSY NEW DOOR INNER HANDLE WITH HOUSING	TATA spare parts
289472300153	ASSY NEW DOOR INNER HANDLE WITH HOUSING	TATA spare parts
289472300158	ASSY CHECK STRAP WITH COATED ARM & SPRIN	TATA spare parts
289472300159	ASSY CHECK STRAP WITH COATED ARM & SPRIN	TATA spare parts
289472300162	ASSY LATCH FRONT DOOR LH(LHD)WITH MASTER	TATA spare parts
289472300163	ASSY LATCH FRONT DOOR RH(RHD)WITH MASTER	TATA spare parts
289472300164	ASSY LATCH FRONT DOOR RH(LHD)WITH SLAVE	TATA spare parts
289472300165	ASSY LATCH FRONT DOOR LH(RHD)WITH SLAVE	TATA spare parts
289472300166	ASSY LATCH FRONT DOOR RH MANUAL WITH DOO	TATA spare parts
289472300167	ASSY LATCH FRONT DOOR LH MANUAL WITH DOO	TATA spare parts
289472300176	ASSY STRIKER FOR SIDE DOOR LATCH	TATA spare parts
289472300179	ASSY NEW DR INN HDL WITH HSG LH FOR CABL	TATA spare parts
289472300180	ASSY NEW DR INN HDL WITH HSG RH FOR CABL	TATA spare parts
289472300182	LINK ASSY FLAT DOOR TRIM LH	TATA spare parts
289472300183	LINK ASSY FLAT DOOR TRIM RH	TATA spare parts
289472300187	ASSY DOOR INNER HANDLE W/O LINK LH FOR T	TATA spare parts
289472300188	ASSY DOOR INNER HANDLE W/O LINK RH FOR T	TATA spare parts
289472300189	ASSY DOOR INNER HANDLE W/O LINK FLAT DOO	TATA spare parts
289472300212	KEY SET ASSY	TATA spare parts
289472300213	MAGAZINE POCKET ASSY RH BS6-PH2	TATA spare parts
289472300215	MAGAZINE POCKET ASSY LH BS6-PH2	TATA spare parts
289472301601	ASSY STRIKER	TATA spare parts
289472301602	ASSY.CHECK STRAP FRONT DOOR	TATA spare parts
289472301603	ASSY DOOR HINGE LH/RH	TATA spare parts
289472301604	TORX SCREW M8X28	TATA spare parts
289472306009	LINK LH(CLU TO POP_UP KNOB)	TATA spare parts
289472306010	LINK RH(CLU TO POP_UP KNOB)	TATA spare parts
289472306032	LINK LH FRONT DOOR (LOCK CYLINDER TO LAT	TATA spare parts
289472306033	LINK RH FRONT DOOR (LOCK CYLINDER TO LAT	TATA spare parts
289472306034	LINK LH FRONT DOOR (LATCH TO OUTER HANDL	TATA spare parts
289472306035	LINK RH FRONT DOOR (LATCH TO OUTER HANDL	TATA spare parts
289472306036	LINK FRONT DOOR POP UP KNOB LH	TATA spare parts
289472306037	LINK FRONT DOOR POP UP KNOB RH	TATA spare parts
289472306038	LINK HANDLE TO LATCH LH	TATA spare parts
289472306039	LINK HANDLE TO LATCH RH	TATA spare parts
289472306301	SECONDARY DOOR SEAL FRONT LH	TATA spare parts
289472306302	SECONDARY DOOR SEAL FRONT RH	TATA spare parts
289472306303	PRIMARY DOOR SEAL FRONT LH	TATA spare parts
289472306304	PRIMARY DOOR SEAL FRONT RH	TATA spare parts
289472306305	FRONT DOOR OUTER BELT LH	TATA spare parts
289472306306	FRONT DOOR OUTER BELT RH	TATA spare parts
289472306307	FRONT DOOR INNER BELT LH	TATA spare parts
289472306308	FRONT DOOR INNER BELT RH	TATA spare parts
289472306309	FRONT DOOR GLASS RUN LH	TATA spare parts
289472306310	FRONT DOOR GLASS RUN RH	TATA spare parts
289472306312	COVER PUDDLE LAMP CUT_OUT	TATA spare parts

289472306313	RUBBER BUFFER FRONT DOOR H D 9	TATA spare parts
289472306314	RUBBER PLUG FRONT DOOR	TATA spare parts
289472306315	DOOR PLUG - RECT	TATA spare parts
289472306317	PRIMARY DOOR SEAL FRONT LH	TATA spare parts
289472306318	PRIMARY DOOR SEAL FRONT RH RUSSIA	TATA spare parts
289472306319	SECONDARY DOOR SEAL FRONT - LH - RUSSIA	TATA spare parts
289472306320	SECONDARY SEAL FRONT DOOR - RUSSIA -RH	TATA spare parts
289472306327	OUTER BELT F/D LH PCRCL THAILAND	TATA spare parts
289472306328	OUTER BELT F/D RH PCRCL THAILAND	TATA spare parts
289472306329	INNER BELT F/D LH PCRCL- THAILAND	TATA spare parts
289472306330	INNER BELT F/D RH PCRCL THAILAND	TATA spare parts
289472306331	BEZEL FOR DOOR INNER HANDLE FRONT LH NGO	TATA spare parts
289472306332	BEZEL FOR DOOR INNER HANDLE FRONT RH NGO	TATA spare parts
289472306340	ANTI WIND NOISE A PIILAR FOAM LH	TATA spare parts
289472306341	ANTI WIND NOISE A PIILAR FOAM RH	TATA spare parts
289472306346	BELL CRANK LH XENON MARK 2	TATA spare parts
289472306353	SECONDARY SEAL FRONT DOOR LH BS6-PH2	TATA spare parts
289472306354	SECONDARY SEAL FRONT DOOR RH BS6-PH2	TATA spare parts
289472308001	TORX SCREW M8 X 28	TATA spare parts
289472320101	LATCH ASSY FRONT DOOR LH	TATA spare parts
289472500101	ASSY WINDOW REG.MANUAL LH	TATA spare parts
289472500102	ASSY WINDOW REG.RH MANUAL	TATA spare parts
289472500103	ASSY WINDOW REG.LH POWER	TATA spare parts
289472500104	ASSY WINDOW REG.RH POWER	TATA spare parts
289472500109	ASSY.DOOR GLASS HOLDER	TATA spare parts
289472500110	WINDOW WINDING REGULATOR ASSY LH	TATA spare parts
289472500111	WINDOW WINDING REGULATOR ASSY RH	TATA spare parts
289472501601	ASSY WINDOW REG.MANUAL LH	TATA spare parts
289472501602	ASSY WINDOW REG.RH MANUAL	TATA spare parts
289472502301	GLASS FRONT DOOR LH	TATA spare parts
289472502301AE	GLASS FRT DOOR LH -XEN DC-XEN SC	TATA spare parts
289472502302	GLASS FRONT DOOR RH	TATA spare parts
289472502302AE	GLASS FRT DOOR RH -XEN DC-XEN SC	TATA spare parts
289472700101	ASSY TRIM FRONT DOOR LH	TATA spare parts
289472700102	ASSY TRIM FRONT DOOR RH	TATA spare parts
289472700103	TRIM ASSY FRONT DOOR LH	TATA spare parts
289472700104	TRIM ASSY FRONT DOOR RH	TATA spare parts
289472700105	ASSY.FABRIC TRIM INSERT LH	TATA spare parts
289472700106	ASSY.FABRIC TRIM INSERT RH	TATA spare parts
289472700109	DOOR PULL ASSY	TATA spare parts
289472700110	HARDBOARDASSYFRONTDOORPADDINGLH BS6	TATA spare parts
289472700111	FLAT DOOR TRIM ASSY LH	TATA spare parts
289472700113	ASSY.HOUSING INNER HANDLE LH	TATA spare parts
289472700114	ASSY.HOUSING INNER HANDLE RH	TATA spare parts
289472700115	ASSY.DOOR TRIM FRONT LH - LOW END	TATA spare parts
289472700116	ASSY.DOOR TRIM FRONT RH LOW END	TATA spare parts
289472700117	ASSY.TRIM FRONT DOOR COMPLT.LH	TATA spare parts

289472700118	ASSY.TRIM FRONT DOOR COMPLT.RH	TATA spare parts
289472700121	ASSY ARMREST GREY LH WITH CLIPS	TATA spare parts
289472700122	ASSY ARMREST GRAY RH WITH CLIPS	TATA spare parts
289472700125	ASSY ARMREST GREY NG003 LH WITH CLIPS LO	TATA spare parts
289472700126	ASSY ARMREST GRAY NG003 RH WITH CLIPS LO	TATA spare parts
289472700127	ASSY DOOR TRIM FRONT LH RHD HIGH END	TATA spare parts
289472700128	ASSY DOOR TRIM FRONT RH RHD HIGH END	TATA spare parts
289472700131	ASSY DOOR TRIM FRONT LH RHD BIEGE HI	TATA spare parts
289472700132	ASSY DOOR TRIM RH RHD BIEGE HIGH	TATA spare parts
289472700140	ASSY DOOR TRIM CLIP	TATA spare parts
289472700163	ASSY DOOR TRIM FRONT LH RHD BEIGEHIGH EN	TATA spare parts
289472700164	ASSY DOOR TRIM FRONT RH RHD BEIGEHIGH EN	TATA spare parts
289472700169	ASSY FRONT DOOR PADDING LH	TATA spare parts
289472700170	ASSY FRONT DOOR PADDING RH	TATA spare parts
289472706303	INNER COVER MAGAZINE POCKET LH	TATA spare parts
289472706304	INNER COVER MAGAZINE POCKET RH	TATA spare parts
289472706309	FABRIC FRONT DOOR TRIM LH	TATA spare parts
289472706310	FABRIC FRONT DOOR TRIM RH	TATA spare parts
289472706313	DOOR PULL FRONT LH	TATA spare parts
289472706314	DOOR PULL FRONT RH	TATA spare parts
289472706315	MEMBRANE FRONT DOOR LH	TATA spare parts
289472706317	POP UP KNOB	TATA spare parts
289472706318	MEMBRANE FRONT DOOR RH	TATA spare parts
289472706320	PIN	TATA spare parts
289472706321	MEMBRANE FRONT DOOR LH	TATA spare parts
289472706324	PLASTIC INSERT FRONT LH LOW END	TATA spare parts
289472706325	PLASTIC INSERT FRONT LOW END RH	TATA spare parts
289472706326	ARM REST FRONT DOOR LH	TATA spare parts
289472706327	ARM REST FRONT DOOR RH	TATA spare parts
289472706328	DOOR TRIM FRONT LH	TATA spare parts
289472706329	DOOR TRIM FRONT RH	TATA spare parts
289472706336	MIRROR SWITCH BEZEL	TATA spare parts
289472706338	DUMMY BEZEL MIRROR SWITCH	TATA spare parts
289472706339	SPEAKER MOUNT FRONT DOOR LH	TATA spare parts
289472706340	SPEAKER MOUNT FRONT DOOR RH	TATA spare parts
289472706341	GUIDE LH (W/W HANDLE)	TATA spare parts
289472706342	GUIDE RH(W/W HANDLE)	TATA spare parts
289472706343	MATT ARM REST FRONT DOOR LH	TATA spare parts
289472706344	MATT ARM REST FRONT DOOR RH	TATA spare parts
289472706345	PLASTIC MEMBRANE FRONT DOOR LH	TATA spare parts
289472706346	PLASTIC MEMBRANE FRONT DOOR RH	TATA spare parts
289472706372	NVH INSULATION FRONT DOOR MIDDLE LH	TATA spare parts
289472706373	NVH INSULATION FRONT DOOR SIDE LH	TATA spare parts
289472706374	NVH INSULATION FRONT DOOR BOTTOM LH	TATA spare parts
289472706376	SUPPORT FOAM FRONT DOOR TRIM	TATA spare parts
289472706385	CLOSING CAP F/D UPPER LH	TATA spare parts
289472706386	CLOSING CAP F/D UPPER RH	TATA spare parts

289472706387	CLOSING CAP F/D UPPER LH - B002	TATA spare parts
289472706388	CLOSING CAP F/D UPPER RH - B002	TATA spare parts
289472706389	CLOSING CAP F/D LOWER LH	TATA spare parts
289472706390	CLOSING CAP F/D LOWER RH	TATA spare parts
289472706391	CLOSING CAP F/D LOWER LH - B002	TATA spare parts
289472706392	CLOSING CAP F/D LOWER RH - B002	TATA spare parts
289472706393	NVH INSULATION FRONT DOOR MIDDLE RH	TATA spare parts
289472706394	NVH INSULATION FRONT DOOR SIDE RH	TATA spare parts
289472706395	NVH INSULATION FRONT DOOR BOTTOM RH	TATA spare parts
289472706399	GUIDE FLAT DOOR WINDOW WINDING HANDLE B	TATA spare parts
289472706438	UPPER FLAT DOOR TRIM LH	TATA spare parts
289472706439	UPPER FLAT DOOR TRIM RH	TATA spare parts
289472706440	HOUSING INNER HANDLE FLAT DOOR TRIM	TATA spare parts
289472706445	FOAMCROSSLINK BS6	TATA spare parts
289472916301	FOAM ORVM LH	TATA spare parts
289472916302	FOAM ORVM RH	TATA spare parts
289472916303	FOAM ORVM REAR-LH	TATA spare parts
289472916304	FOAM ORVM REAR-RH	TATA spare parts
289473200101	ASSY.DOOR SHELL LH	TATA spare parts
289473200102	ASSY.DOOR SHELL RH	TATA spare parts
289473200113	ASSY FRAME PART LOWER LH	TATA spare parts
289473200114	ASSY. FRAME PART LOWER RH	TATA spare parts
289473200123	ASSY.DOOR SHELL LH WITH HINGES	TATA spare parts
289473200124	ASSY.DOOR SHELL RH WITH HINGES	TATA spare parts
289473200131	ASSY R/D LH WITH HINGES - SIDE INTRUSION	TATA spare parts
289473200132	ASSY R/D RH WITH HINGES - SIDE INTRUSION	TATA spare parts
289473200134	ASSY SUPPORT BEARING GUIDE COMPLETE MANU	TATA spare parts
289473200142	DOOR SHELL ASSY REAR DOOR LH	TATA spare parts
289473200143	DOOR SHELL ASSY REAR DOOR RH	TATA spare parts
289473206301	REINF.PAD INNER PANEL REAR DOOR LH	TATA spare parts
289473206302	REINF.PAD INNER PANEL REAR DOOR RH	TATA spare parts
289473300105	ASSY.CHECK STRAP REAR DOOR	TATA spare parts
289473300109	DOOR OUTER HANDLE RR DR LH	TATA spare parts
289473300109A3	EBONY_1-ASSY DOOR OUTER HANDLE RR DR LH	TATA spare parts
289473300109BF	ASSY DOOR OUTER HANDLE RR DR LH	TATA spare parts
289473300109D3	ASSY DOOR OUTER HANDLE RR DR LH	TATA spare parts
289473300109DP	ASSY DOOR OUTER HANDLE RR DR LH	TATA spare parts
289473300109DU	ASSY DOOR OUTER HANDLE RR DR LH QUARTZ B	TATA spare parts
28947330010900000	ASSY DOOR OUTER HANDLE RR DR LH LIGHT GO	TATA spare parts
289473300109000000	ASSY DOOR OUTER HANDLE RR DR LH	TATA spare parts
289473300109EY	ASSY DOOR OUTER HANDLE RR DR LH ODYSSY_B	TATA spare parts
289473300109F2	ASSY DOOR OUTER HANDLE RR DR LH	TATA spare parts
289473300109FG	ASSY DOOR OUTER HANDLE RR DR LH	TATA spare parts
289473300109FP	ASSY DOOR OUTER HANDLE RR DR LH	TATA spare parts
289473300110	DOOR OUTER HANDLE RR DR RH	TATA spare parts
289473300110A3	EBONY_1-ASSY DOOR OUTER HANDLE RR DR RH	TATA spare parts
289473300110BF	ASSY DOOR OUTER HANDLE RR DR RH	TATA spare parts

289473300110D3	ASSY DOOR OUTER HANDLE RR DR RH	TATA spare parts
289473300110DP	ASSY DOOR OUTER HANDLE RR DR RH	TATA spare parts
289473300110DU	ASSY DOOR OUTER HANDLE RR DR RH QUARTZ B	TATA spare parts
28947330011000000	ASSY DOOR OUTER HANDLE RR DR RH LIGHT GO	TATA spare parts
289473300110000000	ASSY DOOR OUTER HANDLE RR DR RH	TATA spare parts
289473300110EY	ASSY DOOR OUTER HANDLE RR DR RH ODYSSY_B	TATA spare parts
289473300110F2	ASSY DOOR OUTER HANDLE RR DR RH	TATA spare parts
289473300110FG	ASSY DOOR OUTER HANDLE RR DR RH	TATA spare parts
289473300110FP	ASSY DOOR OUTER HANDLE RR DR RH	TATA spare parts
289473300110G6	WALNUT_GOLD-ASSY DOOR OUTER HANDLE RR D	TATA spare parts
289473300110GA	DEW_WHITE-ASSY DOOR OUTER HANDLE RR DR F	TATA spare parts
289473300110GC	CASTLE_GREY-ASSY DOOR OUTER HANDLE RR DR	TATA spare parts
289473300110GF	PLATNM_BEIGE-ASSY DOOR OUTER HANDLE RR D	TATA spare parts
289473300111	ASSY.LINK LH(LOCK TO BELL CRANK)	TATA spare parts
289473300112	ASSY.LINK RH(LOCK TO BELL CRANK)	TATA spare parts
289473300123	ASSY.BRACKET DOOR PULL	TATA spare parts
289473300124	ASSY.DOOR INNER HANDLE WITH LINKS RD LH	TATA spare parts
289473300125	ASSY DOOR INNER HANDLE W/LINKS GRAY RH	TATA spare parts
289473300126	ASSY LATCH DOOR REAR WITH LINK LH	TATA spare parts
289473300127	ASSY LATCH DOOR REAR WITH LINK RH	TATA spare parts
289473300129	KIT DECORATIV TAPES REAR DOOR	TATA spare parts
289473300130	RDL CRANK LEVER & LINK ASSY.LH	TATA spare parts
289473300131	RDL CRANK LEVER & LINK ASSY.RH	TATA spare parts
289473300139	ASSY NEW DOOR INNER HANDLE WITH HOUSING	TATA spare parts
289473300140	ASSY NEW DOOR INNER HANDLE WITH HOUSING	TATA spare parts
289473300141	ASSY CHECK STRAP WITH COATED ARM & SPRIN	TATA spare parts
289473300142	ASSY CHECK STRAP WITH COATED ARM & SPRIN	TATA spare parts
289473300145	ASSY LATCH REAR DOOR LH WITH SLAVE ACTUA	TATA spare parts
289473300146	ASSY LATCH REAR DOOR RH WITH SLAVE ACTUA	TATA spare parts
289473300147	ASSY LATCH REAR DOOR RH MANUAL WITH DOO	TATA spare parts
289473300148	ASSY LATCH REAR DOOR LH MANUAL WITH DOOF	TATA spare parts
289473301601	ASSY.CHECK STRAP REAR DOOR	TATA spare parts
289473306009	LINK LH(CLU BELL CRANK)	TATA spare parts
289473306010	LINK RH(CLU BELL CRANK)	TATA spare parts
289473306011	LINK LH(BELL CRANK)	TATA spare parts
289473306012	LINK RH(BELL CRANK)	TATA spare parts
289473306013	LINK (BELL CRANK POP_UP KNOB)	TATA spare parts
289473306015	BELL CRANK LH	TATA spare parts
289473306016	BELL CRANK RH	TATA spare parts
289473306023	LINK LH REAR DOOR (LATCH TO OUTER HANDLE	TATA spare parts
289473306024	LINK RH REAR DOOR (LATCH TO OUTER HANDLE	TATA spare parts
289473306031	LINK INNER HANDLE TO LATCH LH	TATA spare parts
289473306032	LINK INNER HANDLE TO LATCH RH	TATA spare parts
289473306033	LINK BELL CRANK LOCK TO POP UP KNOB LH	TATA spare parts
289473306034	LINK BELL CRANK LOCK TO POP UP KNOB RH	TATA spare parts
289473306035	LINK BELL CRANK TO LATCH LH	TATA spare parts
289473306036	LINK BELL CRANK TO LATCH RH	TATA spare parts

289473306301	REAR DOOR GLASS RUN UPPER LH	TATA spare parts
289473306302	REAR DOOR GLASS RUN UPPER RH	TATA spare parts
289473306303	PRIMARY DOOR SEAL REAR LH	TATA spare parts
289473306303AE	PRIMARY DOOR SEAL REAR LH-XEN DC	TATA spare parts
289473306304	PRIMARY DOOR SEAL REAR RH	TATA spare parts
289473306304AE	PRIMARY DOOR SEAL REAR RH-XEN DC	TATA spare parts
289473306305	SECONDARY DOOR SEAL REAR LH	TATA spare parts
289473306305AE	SECONDARY DOOR SEAL REAR LH	TATA spare parts
289473306306	SECONDARY DOOR SEAL REAR RH	TATA spare parts
289473306307	REAR DOOR INNER BELT LH	TATA spare parts
289473306308	REAR DOOR INNER BELT RH	TATA spare parts
289473306309	REAR DOOR OUTER BELT LH	TATA spare parts
289473306310	REAR DOOR OUTER BELT RH	TATA spare parts
289473306311	REAR DOOR GLASS RUN LOWER FRONT	TATA spare parts
289473306312	REAR DOOR GLASS RUN LOWER FRONT RH	TATA spare parts
289473306313	REAR DOOR GLASS RUN LOWER REAR	TATA spare parts
289473306315	RUBBER BUFFER REAR DOOR H D 9	TATA spare parts
289473306317	PRIMARY REAR DOOR SEAL LH - RUSSIA	TATA spare parts
289473306318	PRIMARY REAR DOOR SEAL RH - RUSSIA	TATA spare parts
289473306319	SECONDARY SEAL REAR DOOR LH RUSSIA	TATA spare parts
289473306320	SECONDARY SEAL REAR DOOR RH RUSSIA	TATA spare parts
289473306333	BEZEL FOR DOOR INNER HANDLE REAR LH	TATA spare parts
289473306334	BEZEL FOR DOOR INNER HANDLE REAR RH	TATA spare parts
289473308201	CLOSER FRAME PART RH	TATA spare parts
289473308202	CLOSER BKT.RR FRAME UPPER RH	TATA spare parts
289473500101	ASSY WINDOW REG.LH MANUAL	TATA spare parts
289473500102	ASSY WINDOW REG.RH MANUAL	TATA spare parts
289473500103	ASSY WINDOW REG.LH POWER	TATA spare parts
289473500103AE	ASSY WNDW REG LH PWR -XEN DC/SC	TATA spare parts
289473500104	ASSY WINDOW REG.RH POWER	TATA spare parts
289473502301	GLASS REAR DOOR LH	TATA spare parts
289473502302	GLASS REAR DOOR RH	TATA spare parts
289473700101	ASSY TRIM REAR DOOR LH	TATA spare parts
289473700102	ASSY TRIM REAR DOOR RH	TATA spare parts
289473700103	ASSY.FABRIC INSERT REAR LH	TATA spare parts
289473700104	ASSY.FABRIC INSERT REAR RH	TATA spare parts
289473700107	ASSY.DOOR TRIM REAR LH NG003 LOW END	TATA spare parts
289473700108	ASSY.DOOR TRIM REAR RH NG003 LOW END	TATA spare parts
289473700109	ASSY.TRIM REAR DOOR LH	TATA spare parts
289473700110	ASSY.TRIM REAR DOOR RH	TATA spare parts
289473700111	ASSY DOOR TRIM LH PREMIUM BEIGE WITH FLU	TATA spare parts
289473700112	ASSY DOOR TRIM RH PREMIUM BEIGE WITH FLU	TATA spare parts
289473700115	ASSY ARM REST LH HIGH END GRAY NG003	TATA spare parts
289473700116	ASSY ARM REST RH HIGH END GRAY NG003	TATA spare parts
289473700117	ASSY ARM REST LH LOW END GRAY	TATA spare parts
289473700118	ASSY ARM REST RH LOW END GRAY	TATA spare parts
289473700137	ASSY ARM REST REAR DOOR LH AIRBAG EBONY	TATA spare parts

289473700138	ASSY ARM REST REAR DOOR RH AIRBAG EBONY	TATA spare parts
289473700149	TRIM ASSY REAR DOOR SIDE LH	TATA spare parts
289473700150	TRIM ASSY REAR DOOR SIDE RH	TATA spare parts
289473700153	DOOR TRIM ASSY REAR DOOR LOWER-LH	TATA spare parts
289473700154	DOOR TRIM ASSY REAR DOOR LOWER-RH	TATA spare parts
289473706305	HOUSING INER HANDLE REAR DOOR LH	TATA spare parts
289473706306	HOUSING INER HANDLE REAR DOOR RH	TATA spare parts
289473706309	FABRIC REAR DOOR LH	TATA spare parts
289473706310	FABRIC REAR DOOR RH	TATA spare parts
289473706313	DOOR PULL LH	TATA spare parts
289473706314	DOOR PULL RH	TATA spare parts
289473706319	ARM REST REAR DOOR LH(Low END)	TATA spare parts
289473706320	ARM REST REAR DOOR RH(Low END)	TATA spare parts
289473706321	DOOR TRIM REAR LH	TATA spare parts
289473706322	DOOR TRIM REAR RH	TATA spare parts
289473706325	GUIDE LH(W/W HANDLE)	TATA spare parts
289473706326	GUIDE RH(W/W HANDLE) NG003	TATA spare parts
289473706327	MATT ARM REST REAR DOOR LH	TATA spare parts
289473706328	MATT ARM REST REAR DOOR RH	TATA spare parts
289473706329	PLASTIC MEMBRANE REAR DOOR LH	TATA spare parts
289473706330	PLASTIC MEMBRANE REAR DOOR RH	TATA spare parts
289473706335	BODY TRIM REAR DOOR LH	TATA spare parts
289473706336	BODY TRIM REAR DOOR RH	TATA spare parts
289473706339	NVH INSULATION REAR DOOR MIDDLE LH	TATA spare parts
289473706340	NVH INSULATION REAR DOOR SIDE LH	TATA spare parts
289473706341	NVH INSULATION REAR DOOR BOTTOM LH	TATA spare parts
289473706342	CLOSING CAP R/D UPPER LH	TATA spare parts
289473706343	CLOSING CAP R/D UPPER RH	TATA spare parts
289473706346	CLOSING CAP R/D LOWER LH	TATA spare parts
289473706347	CLOSING CAP R/D LOWER RH	TATA spare parts
289473706350	NVH INSULATION REAR DOOR MIDDLE RH	TATA spare parts
289473706351	NVH INSULATION REAR DOOR SIDE RH	TATA spare parts
289473706352	NVH INSULATION REAR DOOR BOTTOM RH	TATA spare parts
289473706391	MEMBRANE REAR DOOR LH	TATA spare parts
289473706392	MEMBRANE REAR DOOR RH	TATA spare parts
289481000103	KIT FOR FIT OF LOCKS LHD	TATA spare parts
289481000104	LIT FIT OF LOCKS RHD	TATA spare parts
289481100106	ORVM INNER COVER-MANUAL LH	TATA spare parts
289481100107	ORVM INNER COVER_ MANUAL RH	TATA spare parts
289481100117	ASSY ORVM LH RHD POWER ENGTECH(W/O HEAT	TATA spare parts
289481100117BF	ASSY ORVM LH RHD POWER W/O HEATER ARTICT	TATA spare parts
289481100117D3	ASSY ORVM LH RHD POWER W/O HEATER ARTICT	TATA spare parts
289481100117DP	ASSY ORVM LH RHD POWER W/O HEATER PASSIO	TATA spare parts
28948110011700000	ASSY ORVM LH RHD POWER W/O HEATER LIGHT	TATA spare parts
289481100117000000	ASSY ORVM LH RHD POWER W/O HEATER ARIZON	TATA spare parts
289481100117EY	ASSY ORVM LH RHD POWER W/O HEATER ODYSS	TATA spare parts
289481100118	ASSY ORVM RH RHD POWER ENGTECH(W/O HEAT	TATA spare parts

289481100118BF	ASSY ORVM RH RHD POWER W/O HEATER ARTIC	TATA spare parts
289481100118D3	ASSY ORVM RH RHD POWER W/O HEATER ARTIC	TATA spare parts
289481100118DP	ASSY ORVM RH RHD POWER W/O HEATER PASSIC	TATA spare parts
28948110011800000	ASSY ORVM RH RHD POWER W/O HEATER LIGHT	TATA spare parts
289481100118000000	ASSY ORVM RH RHD POWER W/O HEATER ARIZO	TATA spare parts
289481100118EY	ASSY ORVM RH RHD POWER W/O HEATER ODYSS	TATA spare parts
289481100119BF	ASSY ORVH LH LHD POWER (W/O HEATER) ARTI	TATA spare parts
289481100119D3	ASSY ORVH LH LHD POWER (W/O HEATER) ARTI	TATA spare parts
289481100119DP	ASSY ORVH LH LHD POWER (W/O HEATER) PASS	TATA spare parts
289481100119000000	ASSY ORVH LH LHD POWER (W/O HEATER) ARIZ	TATA spare parts
289481100120BF	ASSY ORVH LH LHD POWER (W/O HEATER) ARTI	TATA spare parts
289481100120D3	ASSY ORVM RH LHD POWER (W/O HEATER) ARTI	TATA spare parts
289481100120DP	ASSY ORVM RH LHD POWER (W/O HEATER) PASS	TATA spare parts
289481100120000000	ASSY ORVM RH LHD POWER (W/O HEATER) ARI	TATA spare parts
289481100122	ASSY FRONT GRILL AND FINSHER	TATA spare parts
289481100127	ASSY LEAF SCREEN LHD	TATA spare parts
289481100128	ASSY LEAF SCREEN RHD	TATA spare parts
289481100137	ASSY CABLE FUEL LATCH REL LHD	TATA spare parts
289481100138	ASSY CABLE FUEL LID LATCH RHD 4DR	TATA spare parts
289481100141	ASSY. ORVM LH RHD CABLE ENGTECH BS1/3/4	TATA spare parts
289481100141BF	ASSY ORVM LH RHD CABLE	TATA spare parts
289481100141D3	ASSY ORVM LH RHD CABLE	TATA spare parts
289481100141DP	ASSY ORVM LH RHD CABLE	TATA spare parts
289481100141000000	ASSY ORVM LH RHD CABLE	TATA spare parts
289481100142	ASSY.ORVM RH RHD CABLE W/O HEATER BS2/4	TATA spare parts
289481100142BF	ASSY ORVM RH RHD CABLE	TATA spare parts
289481100142D3	ASSY ORVM RH RHD CABLE	TATA spare parts
289481100142DP	ASSY ORVM RH RHD CABLE	TATA spare parts
289481100142000000	ASSY ORVM RH RHD CABLE	TATA spare parts
289481100143	ASSY ORVM LH LHD CABLE (W/O HEATER)	TATA spare parts
289481100144	ASSY ORVM RH LHD CABLE (W/O HEATER)	TATA spare parts
289481100145	ASSY ORVM LH RHD POWER (HEATER)	TATA spare parts
289481100145BF	ASSY ORVM LH RHD POWER (HEATER)	TATA spare parts
289481100145D3	ASSY ORVM LH RHD POWER ENGTECH(HEATER) A	TATA spare parts
289481100145DP	ASSY ORVM LH RHD POWER ENGTECH(HEATER) P	TATA spare parts
289481100145DU	ASSY ORVM LH RHD POWER ENGTECH(HEATER) C	TATA spare parts
289481100145000000	ASSY ORVM LH RHD POWER ENGTECH(HEATER) C	TATA spare parts
289481100145FG	ASSY ORVM LH RHD POWER	TATA spare parts
289481100146	ASSY.ORVM RH RHD POWER (HEATER)	TATA spare parts
289481100146BF	ASSY.ORVM RH RHD POWER (HEATER)	TATA spare parts
289481100146D3	ASSY ORVM RH RHD POWER ENGTECH(HEATER) A	TATA spare parts
289481100146DP	ASSY ORVM RH RHD POWER ENGTECH(HEATER) F	TATA spare parts
289481100146DU	ASSY ORVM RH RHD POWER ENGTECH(HEATER) C	TATA spare parts
289481100146000000	ASSY ORVM RH RHD POWER ENGTECH(HEATER) C	TATA spare parts
289481100146FG	ASSY.ORVM RH RHD POWER	TATA spare parts
289481100147	ASSY ORVM LH LHD POWER (HEATER)	TATA spare parts
289481100147BF	ASSY ORVM LH LHD POWER ENGTECH(HEATER)	TATA spare parts



289481100147D3	ASSY ORVM LH LHD POWER (HEATER) ARTICT S	TATA spare parts
289481100147DP	ASSY ORVM LH LHD POWER (HEATER) PASSION	TATA spare parts
289481100147DU	ASSY ORVM LH LHD POWER (HEATER) QUARTZ_B	TATA spare parts
289481100147000000	ASSY ORVM LH LHD POWER (HEATER) QUARTZ_B	TATA spare parts
289481100148	ASSY ORVM RH LHD POWER ENGTECH(HEATER)	TATA spare parts
289481100148BF	ASSY ORVM RH LHD POWER ENGTECH(HEATER)	TATA spare parts
289481100148D3	ASSY ORVM RH LHD POWER (HEATER) ARTICT S	TATA spare parts
289481100148DP	ASSY ORVM RH LHD POWER (HEATER) PASSION	TATA spare parts
289481100148DU	ASSY ORVM RH LHD POWER (HEATER) QUARTZ_B	TATA spare parts
289481100148000000	ASSY ORVM RH LHD POWER (HEATER) QUARTZ_B	TATA spare parts
289481100149BF	ASSY ORVM LH RHD CABLE (HEATER)	TATA spare parts
289481100155	ASSY.FOOT STEP SIDE LH 4-DOOR	TATA spare parts
289481100156	ASSY.FOOT.STEP SIDE RH 4-DOOR	TATA spare parts
289481100159	ASSY CABLE FUEL LID LATCH LHD	TATA spare parts
289481100160	ASSY CABLE FUEL LID LATCH RHD 4DR	TATA spare parts
289481100161	ASSY.LEVER FUEL FILLER RHD	TATA spare parts
289481100162	ASSY.LEVER-FUEL FILLER LHD	TATA spare parts
289481100168	ASSY MUDLINER AND WATER DEFLECTOR LH 3L	TATA spare parts
289481100169	ASSY MUDLINER AND WATER DEFLECTOR RH 4DL	TATA spare parts
289481100171	ASSY COWL PANEL LEAF GRILL WITH FOAM	TATA spare parts
289481100175	ASSY COWL PANEL LEAF GRILL FOAM W/O HOLE	TATA spare parts
289481100176	ASSY.WATER DEFLECTOR LH	TATA spare parts
289481100177	ASSY.WATER DEFLECTOR RH	TATA spare parts
289481100178	ASSY CLOSING PLATE SUPPORT PANEL	TATA spare parts
289481100183	ASSY WIPING SYSTEM LINKAGE LHD	TATA spare parts
289481100184	ASSY IRVM W/O BASE - GRAY NG002	TATA spare parts
289481100185	ASSY IRVM W/O BASE BEIGE	TATA spare parts
289481100199	ASSY. WIPER LINKAGES RHD BS1/3/4/6	TATA spare parts
289481100201BF	ARCTIC_WHITE-ASSY FINISHER GRILL LH	TATA spare parts
289481100201BL	DK_NEPT_BLUE-ASSY FINISHER GRILL LH	TATA spare parts
289481100202BF	ARCTIC_WHITE-ASSY FINISHER GRILL RH	TATA spare parts
289481100202BL	DK_NEPT_BLUE-ASSY FINISHER GRILL RH	TATA spare parts
289481100209	ASSY OUTER DUMMY ORVM COVER WITH GASKE	TATA spare parts
289481100212	ASSY MUD FLAP FRONT LH-LONGER	TATA spare parts
289481100213	ASSY MUD FLAP FRONT RH-LONGER	TATA spare parts
289481100238	ASSY AIRFLAP LH THAILAND CNG	TATA spare parts
289481100239	ASSY AIRFLAP RH THAILAND CNG	TATA spare parts
289481100242	ASSY ORVM CABLE OPERATED FOR GULF LH LHD	TATA spare parts
289481100243	ASSY ORVM CABLE OPERATED FOR GULF RH LHD	TATA spare parts
289481100247	ASSY MUD FLAP FRONT 235/70 R15 TYRE LH	TATA spare parts
289481100248	ASSY MUD FLAP FRONT 235/70 R15 TYRE RH	TATA spare parts
289481100255	FOOT STEP ASSY LH CREW CAB MYANMAR	TATA spare parts
289481100259	FOOT STEP ASSY RH CREW CAB MYANMAR	TATA spare parts
289481106301	MUDLINER FRONT OUTER LH	TATA spare parts
289481106302	MUDLINER FRONT OUTER RH	TATA spare parts
289481106303	MUDFLAP FRONT LH	TATA spare parts
289481106304	MUDFLAP FRONT RH	TATA spare parts

289481106305	MUDLINER FRONT INNER LH	TATA spare parts
289481106306	MUDLINER FRONT INNER RH	TATA spare parts
289481106307	ASSY.ROOF DITCH LH	TATA spare parts
289481106308	ASSY.ROOF DITCH RH	TATA spare parts
289481106311	END CAP LEAF SCREEN LH	TATA spare parts
289481106312	END CAP LEAF SCREEN RH	TATA spare parts
289481106313	BUMPER MOUNTING	TATA spare parts
289481106314	BUMPER MOUNTING WITH HEADLAMP RH	TATA spare parts
289481106315	MUDLINER FRONT RH LHD	TATA spare parts
289481106316	MUDLINER FRONT LH RHD	TATA spare parts
289481106317	PLENUM SEAL	TATA spare parts
289481106318	COWEL PANEL LEAF GRILL	TATA spare parts
289481106319	ORVM INNER COVER MANUAL LH	TATA spare parts
289481106320	ORVM INNER COVER MANUAL RH	TATA spare parts
289481106321	ORVM INNER COVER ELECTRICAL LH	TATA spare parts
289481106322	ORVM INNER COVER ELECTRICAL RH	TATA spare parts
289481106323	FUEL LID BUFFER	TATA spare parts
289481106324	FUEL LID RUBBER STOPPER	TATA spare parts
289481106325	WATER DEFLECTOR LH - 3 LTR ENG	TATA spare parts
289481106327	END CAP FOR SIDE FOOT STEP	TATA spare parts
289481106328	END COVER SIDE FOOT STEP LH	TATA spare parts
289481106329	END COVER SIDE FOOT STEP RH	TATA spare parts
289481106335	ORVM INNER COVER ELECTRICAL LH	TATA spare parts
289481106336	ORVM INNER COVER ELECTRICAL RH	TATA spare parts
289481106339	HOUSING TRIM FIXING BEIGE	TATA spare parts
289481106340	CLIP TRIM FIXING BEIGE	TATA spare parts
289481106341	PLUG FOR DASH PANEL A/C HOLE	TATA spare parts
289481106342	COVER FUEL LEVER BRACKET LH BEIGE	TATA spare parts
289481106343	COVER FUEL LEVER BRACKET RH BEIGE	TATA spare parts
289481106344	COVER FUEL LEVER BRACKET LH GRAY	TATA spare parts
289481106345	COVER FUEL LEVER BRACKET RH GRAY	TATA spare parts
289481106351	WIPER SPINDLE RUBBER GROMMET	TATA spare parts
289481106352	CROSS LINKED FOAM	TATA spare parts
289481106353	HOUSING TRIM FIXING BEIGE BR35	TATA spare parts
289481106354	CLIP TRIM FIXING BEIGE BR35	TATA spare parts
289481106355	FLANGE SEAL 510L	TATA spare parts
289481106358	FUEL RELEASE CABLE HOLDING CLIP	TATA spare parts
289481106361	MUDLINER FRONT INNER LH RHD XENON RX	TATA spare parts
289481106362	MUDLINER FRONT INNER RH XENON RX	TATA spare parts
289481106370	RUBBER BEAD LENGTH 335MM (AIR FILTER UMB	TATA spare parts
289481106501	SPRING CLIP - SELF TAPPING SCR - 4.2	TATA spare parts
289481108001	CR PAN HD TAPSCR C-ST4.8X19TS17245 A2-5	TATA spare parts
289481108208	STOPPER BRKT FUEL LID	TATA spare parts
289481109201	WASHER LEAF SCREEN - SS	TATA spare parts
289481110101	ORVM ASSY LH	TATA spare parts
289481110102	ORVM ASSY RH	TATA spare parts
289481500101	ASSY ROOF RAIL COMPLETE LH (EXTRUDED)	TATA spare parts

289481500102	ASSY ROOF RAIL COMPLETE RH-BLACK	TATA spare parts
289481506301	FRONT GASKET - ROOF RAIL - RH	TATA spare parts
289481506302	FRONT GASKET - ROOF RAIL RH	TATA spare parts
289481506303	REAR GASKET - ROOF RAIL LH	TATA spare parts
289481506304	REAR GASKET - ROOF RAIL RH	TATA spare parts
289481706305	STICKER CHILD LOCK	TATA spare parts
289481800101	ASSY XENON MASCOT	TATA spare parts
289481800104	ASSY 2.2L MASCOT	TATA spare parts
289481800106	ASSY 3.0 L MASCOT	TATA spare parts
289481800107	ASSY 4X4 MASCOT	TATA spare parts
289481800108	ASSY DICOR MASCOT	TATA spare parts
289481800110	ASSY DLS MASCOT	TATA spare parts
289481800111	ASSY DLE MASCOT	TATA spare parts
289481800112	ASSY XT MASCOT - DOMESTIC M1	TATA spare parts
289481906301	PLUG ACCL CABLE HOLE	TATA spare parts
289481906302	PLUG SIDE HAND BRAKE	TATA spare parts
289481906303	PLUG CENTRAL HAND BRAKE	TATA spare parts
289481906304	REAR WALL GROMMET	TATA spare parts
289481906305	PLUG - FLOOR - DIA 20	TATA spare parts
289481906306	PLUG - DASH PANEL - DIA 26	TATA spare parts
289481906307	PLUG - DASH PANEL - DIA 12	TATA spare parts
289481906308	PLUG - SILL - DIA 16	TATA spare parts
289481906309	PLUG - HOLE DIA 8	TATA spare parts
289481906310	PLUG - BONNET KEY HOLE	TATA spare parts
289481906311	PLUG - REAR PANEL - DIA 35	TATA spare parts
289481906312	PLUG - SILL AREA - SLOT	TATA spare parts
289481906314	PLUG - DASH PANEL - DIA 23	TATA spare parts
289481906315	PLUG - DASH PANEL SLOT	TATA spare parts
289481906316	PLUG - BONNET SLOT - 50X20	TATA spare parts
289481906317	PLUG - BONNET SLOT - 120X23	TATA spare parts
289481906318	PLUG - BONNET SLOT - 14X18	TATA spare parts
289481906319	PLUG - BONNET SLOT - 18X31	TATA spare parts
289481906320	PLUG FOR CLOSING HOLE - M12	TATA spare parts
289481906321	SPACER - ORVM INNER COVER MTG	TATA spare parts
289481906322	PLUG FLOOR	TATA spare parts
289481906323	PLUG FLOOR	TATA spare parts
289482400103	KIT-ELECTRIC W/S WASHER UNIT BS1/3/4	TATA spare parts
289482400103AE	KIT ELEC W/S WASHER-XEN DC/SC	TATA spare parts
289482400104	ASSY.WASHER BOTTLE MOUNTING BRACKET	TATA spare parts
289482400106	ASSY WIPER ARM AND BLADE CO.DR.RHD	TATA spare parts
289482400107	ASSY WIPER ARM AND BLADE CO.DR.LHD	TATA spare parts
289482400107AE	ASSY WIPER ARM&BLDE CO.DR-XEN DC	TATA spare parts
289482400108	ASSY WIPER ARM AND BLADE DR.RHD	TATA spare parts
289482400109	ASSY WIPER ARM AND BLADE DR.LHD	TATA spare parts
289482400109AE	ASSY WIPR ARM&BLADE DR-XEN DC/SC	TATA spare parts
289482400110	ASSLY TANK	TATA spare parts
289482400111	TUBE ASSLY	TATA spare parts

289482400113	HOLDER-W/S WASHER BOTTLE FUNNEL CAP	TATA spare parts
289482400114	WASHER BOTTLE FUNNEL HOLDER	TATA spare parts
289482400118	WASHER BOTTLE FUNNEL HOLDER	TATA spare parts
289482400119	ASSY WIPER ARM DRIVER SIDE - LHD	TATA spare parts
289482400120	ASSY WIPER ARM DRIVER SIDE RHD	TATA spare parts
289482400121	ASSY BLADE WITH SPOILER - DRIVER SIDE LH	TATA spare parts
289482400123	ASSY WIPER BLADE WITH SPOILER DRIVER SID	TATA spare parts
289482400124	ASSY WIPER ARM CO-DRIVER LHD	TATA spare parts
289482400125	ASSY WIPER ARM CO-DRIVER RHD	TATA spare parts
289482400126	ASSY WIPER BLADE CO-DRIVER	TATA spare parts
289482400135	ASSY WIPER MOTOR WITH MTG BKT	TATA spare parts
289482400137	SEAL	TATA spare parts
289482400141	ROTARY LINK ASSY	TATA spare parts
289482406303	FLEXIBLE CONDUIT LG-400MM	TATA spare parts
289482406903	BREATHER TUBE 450MM-4IDX60D	TATA spare parts
289482407501	GROMMET [WINDSHIELD PIPE]	TATA spare parts
289482409901	WIPER MOTOR	TATA spare parts
289483106313	SIDE_DEMIST_DUCT_LH (AIR BAG PROJECT)	TATA spare parts
289483106314	SIDE_DEMIST_DUCT_RH (AIR BAG PROJECT)	TATA spare parts
289483300101	ASSY HVAC CONTROL PANEL-ELECTRIC	TATA spare parts
289483300102	ASSY HVAC CONTROL PANEL-ELECTRIC	TATA spare parts
289483300105	ASSY HVAC CONTROL PANEL MANUAL RHD	TATA spare parts
289483300106	ASSY HVAC CONTROL PANEL MANUAL LHD	TATA spare parts
289483300107	ASSY AC CONTROL PANEL RHD	TATA spare parts
289483300109	ASSY HEATING DEMISTING CONTROL PANEL RHD	TATA spare parts
289483400101	ASSY.HVAC UNIT COMPLETE-SUBROS-RHD	TATA spare parts
289483400102	ASSY.EVAPORATOR UNIT-SUBROS-RHD	TATA spare parts
289483400103	ASSY.EVAPORATOR COIL-SUBROS-RHD	TATA spare parts
289483400104	ASSY.BLOWER+HEATER UNIT-RHD	TATA spare parts
289483400105	ASSY HEATER COMPLETE	TATA spare parts
289483400106	ASSY.W/HARNESS	TATA spare parts
289483400107	KIT AC SYSTEM LHD	TATA spare parts
289483400108	KIT FOR HVAC FROM RHD	TATA spare parts
289483400109	ASSY. CONDENSER COMP. (W/FAN&BKTS) BS3/4	TATA spare parts
289483400112	KIT CONTROL PANEL-SUBROS-RHD	TATA spare parts
289483400113	ASSY.BRACKET HVAC UNIT MTG. ON FIREWALL	TATA spare parts
289483400114	COCONTROL CABLE MODE CONTROL	TATA spare parts
289483400115	CONTROL CABLE HEATER	TATA spare parts
289483400116	ASSY.FRESH/RECIRC HOUSING HVAC-RHD	TATA spare parts
289483400117	KIT CONTROL PANEL LHD	TATA spare parts
289483400119	KIT FOR REFRIGERANT PIPES-LHD	TATA spare parts
289483400120	ASSY.FRESH/RECIRC HOUSING HVAC-LHD	TATA spare parts
289483400120AE	ASSY.FRESH/HSG HVAC-XEN DC/SC	TATA spare parts
289483400121	CONTROL CABLE HEATER-LHD	TATA spare parts
289483400122	CONTROL CABLE MODE CONTROL-LHD	TATA spare parts
289483400123	KIT REFRIGERENT PIPES 486PL LHD	TATA spare parts
289483400124	ASSY.BLOWER+HEATER UNIT-LHD	TATA spare parts

289483400124AE	ASSY.BLOWER+HEATER-XEN DC/SC	TATA spare parts
289483400125	ASSY.EVAPORATOR COIL-SUBROS-LHD	TATA spare parts
289483400126	ASSY.EVAPORATOR UNIT-LHD	TATA spare parts
289483400126AE	ASSY.EVAPORATOR UNIT -XEN DC/SC	TATA spare parts
289483400127	ASSY.HVAC UNIT COMPLETE-LHD	TATA spare parts
289483400128	KIT FOR HVAC COMPLETE LHD	TATA spare parts
289483400129	KIT FOR HVAC FROM -RHD	TATA spare parts
289483400131	KIT FOR HVAC COMPLETE LHD	TATA spare parts
289483400132	KIT FOR REFRIGERANT PIPES-LHD	TATA spare parts
289483400132AE	KIT REFRIGERANT PIPES -XEN DC/SC	TATA spare parts
289483400137	KIT FOR HEATING SYSTEM FROM-LHD	TATA spare parts
289483400139	KIT CONTROL PANEL-LHD	TATA spare parts
289483400142	KIT FOR HEATING SYSTEM -RHD	TATA spare parts
289483400146	KIT CONTROL PANEL RHD	TATA spare parts
289483400147	ASSY CONDENSER COMPLETE2.2LTR RHD (W/FA)	TATA spare parts
289483400148	ASSY CONDENSER COMPLETE 2.2LTR LHD(W/FA)	TATA spare parts
289483400151	CONDENSER ASSY	TATA spare parts
289483400152	KIT FOR AC FROM SUBROS-RHD	TATA spare parts
289483400153	ASSY.AC UNIT COMPLETE-RHD	TATA spare parts
289483400154	KIT CONTROL PANEL-RHD ONLY AC	TATA spare parts
289483400155	ASSY.BLOWER UNIT-RHD	TATA spare parts
289483400156	AIR DUCT (FRESH AIR)	TATA spare parts
289483400157	FRESH AIR DUCT CASING LH	TATA spare parts
289483400158	FRESH AIR DUCT CASING RH	TATA spare parts
289483400159	FRESH AIR DAMPER SUB ASSY	TATA spare parts
289483400160	FRESH AIR DAMPER ACTUATOR	TATA spare parts
289483400161	FILTER COVER	TATA spare parts
289483400165	ASSY DRAIN HOSE WITH GROMMET	TATA spare parts
289483400189	CASE AIR DAMPER	TATA spare parts
289483400190	ACTUATOR	TATA spare parts
289483400191	FRESH AIR DUCT CASING LH	TATA spare parts
289483400192	DAMPER ASSY	TATA spare parts
289483400193	COVER FILTER (POLLEN FILTER)	TATA spare parts
289483400194	SUCTION & TUBE LIQUID ASSY RHD	TATA spare parts
289483400195	BRACKET	TATA spare parts
289483400196	BRACKET	TATA spare parts
289483400197	SUCTION & TUBE LIQUID ASSY LHD	TATA spare parts
289483400198	CORE CONDENSER 647710-3620 (SUBROS)	TATA spare parts
289483400199	ASSY SHROUD	TATA spare parts
28948340020	BRACKET SUB ASSLY C/U MTG.	TATA spare parts
289483400201	BRACKET S/A	TATA spare parts
289483400202	BRACKET	TATA spare parts
289483400203	LEVER SUB-ASSY CONTROL	TATA spare parts
289483400204	BRACKET BLOWER RH	TATA spare parts
289483400205	BRACKET BLOWER LH	TATA spare parts
289483400206	FILTER	TATA spare parts
289483400207	TUBE LIQUID COND OUT	TATA spare parts

289483400208	DESCICANT BAG	TATA spare parts
289483400209	COND MTG BRACKET	TATA spare parts
289483400210	SHROUD BRACKET	TATA spare parts
289483400211	CONDENSER MOUNTING BRACKET ON CORE	TATA spare parts
289483400212	SHROUD BRACKET	TATA spare parts
289483400213	CLAMP	TATA spare parts
289483400215	TUBE DISCHARGE	TATA spare parts
289483400216	COND MTG BRACKET	TATA spare parts
289483400217	COND MTG BRACKET	TATA spare parts
289483400218	SHROUD BRACKET	TATA spare parts
289483400223	KIT FOR AC-RHD	TATA spare parts
289483400225	HOSE SUCTION ASSY-RHD-CNG	TATA spare parts
289483400226	HOSE DISCHARGE	TATA spare parts
289483400227	COMPRESSOR	TATA spare parts
289483400238	CONDENSER ASSY FOR XENON CNG	TATA spare parts
289483400239	COMPRESSOR CLUTCH	TATA spare parts
289483400244	THERMISTOR	TATA spare parts
289483400246	MOUNTING CLIP	TATA spare parts
289483400247	DESICCANT 645911-0040-0-N (SUBROS)	TATA spare parts
289483400249	COND MTG BRACKET	TATA spare parts
289483400250	COND MTG BRACKET	TATA spare parts
289483400253	BRACKET	TATA spare parts
289483400262	ASSY STATOR FOR 10S11 COMP-2.2L (SUBROS)	TATA spare parts
289483400265	TUBE DISCHARGE ASSY (COND IN)	TATA spare parts
289483400286	HUB ASSY MAGNETIC CLUTCH - A/C	TATA spare parts
289483400288	STATOR MAG. CLUTCH 647310-0120-0-H (SUBR)	TATA spare parts
289483400290	COND MTG BRACKET	TATA spare parts
289483400291	SHROUD BRACKET	TATA spare parts
289483400305	KIT REFRIGERENT PIPES 2.2L LHD EV QS70 C	TATA spare parts
289483400308	ASSY HVAC UNIT WITH SERVO-MOTORS RHD	TATA spare parts
289483400310	ASSY MTG BKT WITH WELD NUT	TATA spare parts
289483400311	HVAC UNIT ASSY (ELECTRIC) SP EVAP LHD	TATA spare parts
289483400312	ASSY MTG BKT FOR AC PIPING (PETROL LHD)	TATA spare parts
289483400313	ASSY MTG BKT FOR TUBE LIQUID PETROL LHD	TATA spare parts
289483400314	ASSY SUCT DISCH HOSE FOR 2.2L EV QS70	TATA spare parts
289483400315	ASSY MTG BKT WITH WELD NUT (EURO-V)	TATA spare parts
289483400316	ASSY MTG BKT FOR TUBE SUCTION (EURO V)	TATA spare parts
289483400317	ASSY MTG BKT FOR TUBE DISCHARGE (EURO V)	TATA spare parts
289483400318	ASSY MTG BKT FOR SUCT & DISCH (EURO V)	TATA spare parts
289483400324	KIT HVAC 2.2L RHD EV AIRBAG	TATA spare parts
289483400325	KIT HVAC 2.2L LHD EV AIRBAG	TATA spare parts
289483400327	ASSY W/H ONLY AC LHD	TATA spare parts
289483400328	ASSY MTG BKT FOR TUBE LIQUID EV	TATA spare parts
289483400329	HEATER CORE ASSEMBLY	TATA spare parts
289483400330	ASSY W/H HVAC EV AIRBAG LHD	TATA spare parts
289483400332	ASSY. HVAC UNIT (MANUAL)RS EVP RHD BS3/4	TATA spare parts
289483400333	HVAC UNIT ASSY MANUAL LHD	TATA spare parts

289483400336	KIT HVAC 3.0L RHD	TATA spare parts
289483400340	ASSY EVAPORATOR HOUSING LOWER RHD	TATA spare parts
289483400341	KIT HVAC 4SPTC-CR10 RHD	TATA spare parts
289483400344	HVAC UNIT ASSY (ELECTRIC) RS EVAP RHD	TATA spare parts
289483400353	ASSY HVAC UNIT (ELECTRIC) RS EVAP LHD	TATA spare parts
289483400356	EVAPORATOR RS UNIT ASSY RHD	TATA spare parts
289483400357	BLOWER UNIT ASSY WITH HEATER	TATA spare parts
289483400358	EVAPORATOR COIL ASSY LHD	TATA spare parts
289483400359	EXPANSION VALVE ASSY	TATA spare parts
289483400360	SUCTION TUBE LIQUID ASSY (AFTER TXV)	TATA spare parts
289483400361	SUCTION TUBE LIQUID ASSY (BEFORE TXV)	TATA spare parts
289483400362	BLOWER AND HEATER UNIT ASSY	TATA spare parts
289483400363	EVAPORATOR UNIT ASSY LHD	TATA spare parts
289483400364	SUCTION TUBE LIQUID ASSY (AFTER TXV) LHD	TATA spare parts
289483400365	SUCTION TUBE LIQUID ASSY (BEFOR TXV) LHD	TATA spare parts
289483400366	BLOWER & HEATER UNIT ASSY LHD	TATA spare parts
289483400368	WIRING HARNESS ASSY HVAC (RS) MANUAL RHD	TATA spare parts
289483400369	WIRING HARNESS ASSY HVAC (RS) MANUAL LHD	TATA spare parts
289483400372	BLOWER ASSY COMPLETE FOR AC MANUAL RHD	TATA spare parts
289483400373	ASSY WIRING HARNESS AC MANUAL RHD	TATA spare parts
289483400374	THERMO AMPLIFIER	TATA spare parts
289483400375	EVAPORATOR (RS) UNIT ASSY ELEC RHD	TATA spare parts
289483400376	THERMISTER ASSY FIN TYPE	TATA spare parts
289483400377	WIRING HARNESS ASSY ELECT (RS) HVAC RHD	TATA spare parts
289483400378	EVAPORATOR (RS) UNIT ASSY ELECTRIC LHD	TATA spare parts
289483400379	BLOWER UNIT ASSY WITH HEATER ELE LHD	TATA spare parts
289483400380	WIRING HARNESS ASSY ELECT (RS) HVAC LHD	TATA spare parts
289483403335	PLATE REFORATED RHD	TATA spare parts
289483403336	BRACKET (PLATE PERFORATED)LHD	TATA spare parts
289483403337	HEATER CORE LOCKING BRACKET BOTTOM	TATA spare parts
289483403338	HEATER CORE LOCKING BRACKET UPPER	TATA spare parts
289483403341	BRACKET CONTROL CABLE MTG	TATA spare parts
289483404201	CLAMP FOR HOSE SUCTION	TATA spare parts
289483404202	CLAMP FOR PIPING	TATA spare parts
289483404203	CLAMP FOR PIPING 646780-0180	TATA spare parts
289483404204	CLAMP TUBE LIQUID (SUBROS)	TATA spare parts
289483404205	CLAMP 646680-1830	TATA spare parts
289483404211	CLAMPDIA15	TATA spare parts
289483404212	CLAMP MODE CABLE	TATA spare parts
289483404213	CLAMP TEMPATRURE CABLE	TATA spare parts
289483404214	CLIPS FOR ADAPTOR & HVAC CASING	TATA spare parts
289483404215	THERMISTER CLIP BS6	TATA spare parts
289483404302	RING SNAP	TATA spare parts
289483404303	RING SNAP 10S11 COMP (949070-1360)	TATA spare parts
289483404701	COVER FILTER	TATA spare parts
289483404901	THERMO AMPLIFIER	TATA spare parts
289483405302	FOAM AC PIPING DAROMA FOAM	TATA spare parts

289483405303	DAROMA PACKING	TATA spare parts
289483405309	HEATING PIPING DAROMA FOAM	TATA spare parts
289483405310	HARD FOAM FOR HEATER PIPE SUPPORT ELECT	TATA spare parts
289483406001	LEVER SA CONTROL (AIR MODE)	TATA spare parts
289483406002	LEVER SA CONTROL (HEATER MODE)	TATA spare parts
289483406003	LEVER AIR MODE	TATA spare parts
289483406004	LEVER HEATER MODE	TATA spare parts
289483406005	SHAFT(AIR MODE)	TATA spare parts
289483406006	SHAFT(HEATER MODE)	TATA spare parts
289483406008	LEVER SA CONTROL (HEATER MODE)	TATA spare parts
289483406011	SHAFT (AIR MODE)	TATA spare parts
289483406012	LEVER SA CONTROL (HEATER MODE)	TATA spare parts
289483406014	CAM MODE SELECTION ELECT LHD	TATA spare parts
289483406015	CAM TEMPERATURE CONTROL ELECT HVAC LHD	TATA spare parts
289483406016	SHAFT AIR MODE ELECT RHD	TATA spare parts
289483406017	SHAFT TEMPERATURE MODE ELECT RHD	TATA spare parts
289483406018	SHAFT(AIR MODE)	TATA spare parts
289483406019	SHAFT(HEATER MODE)	TATA spare parts
289483406020	LEVER PLATE FAD	TATA spare parts
289483406021	LEVER SERVO MOTOR FAD	TATA spare parts
289483406022	LEVER SERVOMOTOR AIR MODE RHD	TATA spare parts
289483406023	LEVER SERVOMOTOR TEMP MODE RHD	TATA spare parts
289483406024	LEVER SERVOMOTOR AIR MODE LHD	TATA spare parts
289483406025	LEVER SERVOMOTOR TEMP MODE LHD	TATA spare parts
289483406301	GROMMET FOR HEATER CUTOUT	TATA spare parts
289483406302	O RING (SUCTION) 949142-0030	TATA spare parts
289483406303	O RING (DISCHARGE) 949142-0020	TATA spare parts
289483406304	O RING (LIQIUD) 949142-0010	TATA spare parts
289483406310	CONTROL PANEL COVER FOR NON AC VERSION	TATA spare parts
289483406312	CENTRALUTILITYBINNG003FORNONHVAC BS6	TATA spare parts
289483406314	CONTROL PANEL BASE PLATE WITH KNOB	TATA spare parts
289483406315	CONTROL PANEL FACIA	TATA spare parts
289483406317	COVER FILTER	TATA spare parts
289483406318	HVAC FRESH AIR DUCT	TATA spare parts
289483406319	HVAC BLOWER CASE LH	TATA spare parts
289483406320	HVAC BLOWER CASE RH	TATA spare parts
289483406321	LEVER S/A	TATA spare parts
289483406323	EVAPORATOR UNIT UPPER CASE RHD	TATA spare parts
289483406324	EVAPORATOR UNIT LOWER CASE RHD	TATA spare parts
289483406325	BKT MODE SERVOMOTOR MTG	TATA spare parts
289483406326	BKT TEMP SERVOMOTOR MTG	TATA spare parts
289483406329	BLOWER CASE LH	TATA spare parts
289483406330	BLOWER CASE RH	TATA spare parts
289483406332	BLOWER CASE RH LHD	TATA spare parts
289483406333	BLOWER CASE RH ELE HVAC RHD	TATA spare parts
289483406334	HVAC BLOWER CASE LH	TATA spare parts
289483406335	LEVER AIR MODE	TATA spare parts



289483406336	LEAVER HEATER MODE	TATA spare parts
289483406337	LEVER SA CONTROL (AIR MODE)	TATA spare parts
289483406338	LEVER SA CONTROL (HEATER MODE)	TATA spare parts
289483406341	CAGE UPPER RHD/LHD	TATA spare parts
289483406342	CAGE LOWER RHD	TATA spare parts
289483406343	CAGE LOWER LHD	TATA spare parts
289483406901	TUBE LIQUID ASSY 2.2 LTR RHD	TATA spare parts
289483406902	TUBE & ACC. ASSY 2.2LTR RHD	TATA spare parts
289483406903	TUBE LIQUID (HVAC-IN) 2.2LTR RHD	TATA spare parts
289483406904	HOSE SUCTION ASSY 2.2LTR RHD	TATA spare parts
289483406905	HOSE DISCHARGE ASSY 2.2LTR RHD/LHD	TATA spare parts
289483406906	TUBE AND ACC ASSY	TATA spare parts
289483406907	TUBE LIQUID HVAC IN	TATA spare parts
289483406908	TUBE LIQUID	TATA spare parts
289483406909	HOSE SUCTION	TATA spare parts
289483406910	HOSE DISCHARGE	TATA spare parts
289483406911	HOSE SUCTION	TATA spare parts
289483406912	TUBE & ACC ASSY 3.0L LHD	TATA spare parts
289483406914	TUBE LIQUID ASSY3.0L LHD	TATA spare parts
289483406916	ASSY HOSE SUCTION 2.2L LHD	TATA spare parts
289483406917	TUBE &ACC ASSY 2.2L LHD	TATA spare parts
289483406918	TUBE LIQUID (HVAC -IN )	TATA spare parts
289483406919	TUBE LIQUID ASSY 2.2L LHD	TATA spare parts
289483406920	ASSY SUCTION PIPE 2.2LTR	TATA spare parts
289483406925	HEATER PIPE ASSY OUTLET	TATA spare parts
289483406926	HEATER PIPE ASSY INLET	TATA spare parts
289483406927	HOSE SUCTION 486PL LHD	TATA spare parts
289483406928	HOSE DISCHARGE 486PL LHD	TATA spare parts
289483406929	TUBE LIQUID (HVAC-IN) 486PL LHD	TATA spare parts
289483406930	TUBE LIQUID (COND-OUT) 486PL LHD	TATA spare parts
289483406931	TUBE SUCTION 2.2L RHD COMP	TATA spare parts
289483406932	HOSE DISCHARGE 2.2L RHD/LHD EV COMP	TATA spare parts
289483406933	TUBE LIQUID 2.2L RHD/LHD EV COMP	TATA spare parts
289483406934	TUBE LIQUID COND END 2.2L RHD/LHD EV COM	TATA spare parts
289483406935	TUBE SUCTION 2.2L LHD EV COMP	TATA spare parts
289483406936	HOSE SUCTION 2.2L LHD EV COMP	TATA spare parts
289483406937	TUBE LIQUID HVAC END 2.2L RHD COMP	TATA spare parts
289483406938	TUBE LIQUID HVAC IN 2.2L LHD EV COMP/486	TATA spare parts
289483406939	HEATER PIPE ASSY INLET 2.2L	TATA spare parts
289483406940	TUBE SUCTION 2.2L RHD/LHD EV COMP	TATA spare parts
289483406941	TUBE DISCHARGE 2.2L RHD/LHD EV COMP	TATA spare parts
289483406942	TUBE LIQUID 2.2L RHD COMP	TATA spare parts
289483406945	TUBELIQUID(CONDOUT)3.0LRHDAIRBAG	TATA spare parts
289483406946	TUBELIQUID(ACIN)3.0LRHDAIRBAG	TATA spare parts
289483406947	ASSY TUBE SUCTION 4SPTC-CR10 RHD	TATA spare parts
289483407501	RUBBER GROMMET FOR DRAIN HOSE	TATA spare parts
289483407502	HOSE DRAIN	TATA spare parts

289483407503	DRAIN HOSE - LHD	TATA spare parts
289483407503AE	DRAIN HOSE LHD XEN DC XEN SC	TATA spare parts
289483407801	POLLEN FILTER	TATA spare parts
289483407803	POLLEN FILTER LH BS1/3/4	TATA spare parts
289483408001	HEX FL SCR M6X30 BLACK PASSIVATION/COLOU	TATA spare parts
289483409904	AC REFRIGERANT CHARGE QTY STICKER	TATA spare parts
289483450101	CONDENSER FAN ASSY WITH SHROUD	TATA spare parts
289483500104	KIT FOR HEATER PIPES 2.2L LH/RH	TATA spare parts
289483500105	ASSY HEATER HOSE (ENGINE TO HEATER IN)	TATA spare parts
289483500106	ASSY HEATER HOSE (HEATER OUT TO ENGINE)	TATA spare parts
289483500108	ASSY HEATER HOSE (ENGINE TO HEATER) 2.2L	TATA spare parts
289483500109	ASSY HEATER HOSE (ENGINE TO HEATER) 2.2	TATA spare parts
289483500110	ASSY HEATER PIPE (HEATER TO ENGINE) 4PL	TATA spare parts
289483500111	ASSY HEATER HOSE(ENGINE TO HEATER)3.0LAI	TATA spare parts
289483500112	ASSY HEATER HOSE(HEATER TO ENGINE)3.0LAI	TATA spare parts
289483500113	ASSY HEATER CORE E-V	TATA spare parts
289483500114	HEATER CORE ASSY	TATA spare parts
289483505802	RUBBER HOSE (ENGINE TO HEATER IN) 3 LTR	TATA spare parts
289483505803	RUBBER HOSE (HEATER OUT TO ENGINE) 3 LTR	TATA spare parts
289483505804	RUBBER HOSE (ENGINE TO HEATER IN)2.2 LTR	TATA spare parts
289483505804AE	RUBBER HOSE(ENG TO HTR)-XEN DC	TATA spare parts
289483505805	RUBBER HOSE (HEATER OUT TO ENGINE)2.2LTR	TATA spare parts
289483505806	RUBBER HOSE (ENGINE TO HVAC FOR 486PL)	TATA spare parts
289483505811	HEATER HOSE (ENGINE TO HEATER IN) 2.2L E	TATA spare parts
289483505812	HEATER HOSE (HEATER OUT TO ENGINE) 2.2L	TATA spare parts
289483505813	RUBBER HOSE (HEATER OUT 486PL LHD)	TATA spare parts
289483505814	RUBBER HOSE (ENGINE IN 486PL LHD)	TATA spare parts
289483505817	RUBBER HOSE (ENGINE TO HEATER)	TATA spare parts
289483505818	RUBBER HOSE (HEATER TO ENGINE)	TATA spare parts
289483506801	QUICK CONNECTOR (16 DIA 90 DEGREE ELBOW)	TATA spare parts
289483600101	SUCTION HOSE ASSY	TATA spare parts
289483600102	DISCHARGE HOSE ASSY	TATA spare parts
289483600103	DISCHARGE PIPE ASSY	TATA spare parts
289483600104	SUCTION PIPE ASSY	TATA spare parts
289483600105	SUCTION PIPE ASSY	TATA spare parts
289483650101	HEATER HOSE ASSY ENGINE TO HEATER	TATA spare parts
289483650102	HEATER HOSE ASSY HEATER TO ENGINE	TATA spare parts
289483707502	RUBBER GROMMET	TATA spare parts
289483750102	BRACKET ASSY AC PIPE MTG	TATA spare parts
289483750103	BRACKET ASSY AC PIPE MTG	TATA spare parts
289483750114	BRACKET ASSY AC PIPE MTG	TATA spare parts
289483750115	BRACKET ASSY AC PIPE MTG	TATA spare parts
289483750116	BRACKET ASSY AC PIPE MTG	TATA spare parts
289483753301	BRACKET HEATER HOSE MTG	TATA spare parts
289483784206	CLAMP	TATA spare parts
289483784208	CLAMP AC LINE	TATA spare parts
289483800104	ASSY_AIR_VENT_SIDE_LH_WITH_SATIN_SILVER_	TATA spare parts

289483800105	ASSY_AIR_VENT_SIDE_RH_WITH_SATIN_SILVER_	TATA spare parts
289488100103	ASSY FENDER OUTER COMPLETE LH	TATA spare parts
289488100104	ASSY FENDER OUTER COMPLETE RH	TATA spare parts
289488100106	ASSY MUDLINER MTG INNER LH	TATA spare parts
289488100107	ASSY MUDLINER MTG INNER RH	TATA spare parts
289488100108	ASSY MUDLINER MTG OUTER LH	TATA spare parts
289488100109	ASSY MUDLINER MTG OUTER RH	TATA spare parts
289488106301	FENDER FINISHER LH	TATA spare parts
289488106301BF	FENDER FINISHER LH ARCTIC WHITE	TATA spare parts
289488106301CI	FENDER FINISHER LH	TATA spare parts
289488106301D3	FENDER FINISHER LH ARCTIC SILVER	TATA spare parts
289488106301DP	FENDER FINISHER LH PASSION RED	TATA spare parts
289488106301DU	FENDER FINISHER LH	TATA spare parts
28948810630100000	FENDER FINISHER LH	TATA spare parts
289488106301000000	FENDER FINISHER LH ARCTIC ARRIZONA BLUE	TATA spare parts
289488106301EY	FENDER FINISHER LH	TATA spare parts
289488106301FG	FENDER FINISHER LH	TATA spare parts
289488106301FP	FENDER FINISHER LH	TATA spare parts
289488106302	FENDER FINISHER RH	TATA spare parts
289488106302BF	FENDER FINISHER RH ARCTIC WHITE	TATA spare parts
289488106302CI	FENDER FINISHER RH	TATA spare parts
289488106302D3	FENDER FINISHER RH ARCTIC SILVER	TATA spare parts
289488106302DP	FENDER FINISHER RH PASSION RED	TATA spare parts
289488106302DU	FENDER FINISHER RH	TATA spare parts
28948810630200000	FENDER FINISHER RH	TATA spare parts
289488106302000000	FENDER FINISHER RH ARCTIC ARRIZONA BLUE	TATA spare parts
289488106302EY	FENDER FINISHER RH	TATA spare parts
289488106302FG	FENDER FINISHER RH	TATA spare parts
289488106302FP	FENDER FINISHER RH	TATA spare parts
289488106303	REINF PAD BONNET BS6	TATA spare parts
289488106304	FENDER FINISHER LH BS6	TATA spare parts
289488106305	FENDER FINISHER RH BS6	TATA spare parts
289488108202	FENDER OUTER RH	TATA spare parts
289488300106	FOOT STEP ASSY LH	TATA spare parts
289488300110	FOOT STEP ASSY RH	TATA spare parts
289488500101	ASSY.BUMPER MTG.BKT UPPER LH	TATA spare parts
289488500102	ASSY.BUMPER MTG.BKT.UPPER RH	TATA spare parts
289488500103	ASSY.BUMPER MTG.BKT LOWER LH	TATA spare parts
289488500104	ASSY.BUMPER MTG.BKT.LOWER RH	TATA spare parts
289488500105	GRILL FINISHER ASSY LH BS6	TATA spare parts
289488500106	GRILL FINISHER ASSY RH BS6	TATA spare parts
289488500107	ASSY.BUMPER MTG.BKT.SIDE LH	TATA spare parts
289488500108	ASSY.BUMPER MTG.BKT.SIDE RH	TATA spare parts
289488500109	ASSY.FRT BUMPER PLASTIC W_ BKTS BS1/3/4	TATA spare parts
289488500109BF	ASSY FRONT BUMPER WITH MTG BKTS PLASTIC	TATA spare parts
289488500109D3	ASSY FRONT BUMPER WITH MTG BKTS PLASTIC	TATA spare parts
289488500109DP	ASSY FRONT BUMPER WITH MTG BKTS PLASTIC	TATA spare parts

289488500109DU	QUARTZ BLACK-ASSY FRONT BUMPER WITH MTG	TATA spare parts
289488500109000000	ASSY FRONT BUMPER WITH MTG BKTS PLASTIC	TATA spare parts
289488500110	FRONT BUMPER ASSY WITH FOG LAMP BS6	TATA spare parts
289488500113	ASSY NUT PLATE BUMPER MTG - FENDER	TATA spare parts
289488500116	ASSY. FRT BUMPER W/FOG LAMP ADAPT BS3/4	TATA spare parts
289488500116BF	ARCTIC WHITE-ASSY FRONT BUMPER WITH FOG	TATA spare parts
289488500116D3	ARCTIC SILVR-ASSY FRONT BUMPER WITH FOG	TATA spare parts
289488500116DU	QUARTZ BLACK-ASSY FRONT BUMPER WITH FOG	TATA spare parts
289488500116000000	ARIZONA BLUE-ASSY FRONT BUMPER WITH FOG	TATA spare parts
289488500116FG	ASSY FRONT BUMPER WITH FOG LAMP ADAPTOR	TATA spare parts
289488500116IQ	ASSY FRONT BUMPER WITH FOG LAMP ADAPTOR	TATA spare parts
289488500117	ASSY.FRT. BUMPER W/ FOG LAMP COVER BS3/4	TATA spare parts
289488500117A3	FRONT BUMPER WITH FOG LAMP COVER	TATA spare parts
289488500117BF	ASSY FRONT BUMPER WITH FOG LAMP COVER	TATA spare parts
289488500117D3	FRONT BUMPER ARCTIC_SILVR-ASSY WITH FOG	TATA spare parts
289488500117000000	ASSY FRONT BUMPER WITH FOG LAMP COVER	TATA spare parts
289488500117FG	ASSY FRONT BUMPER WITH FOG LAMP COVER	TATA spare parts
289488506301	GRILL	TATA spare parts
289488506302	FRONT BUMPER	TATA spare parts
289488506303	FINISHER GRILL LH	TATA spare parts
289488506303BF	FINISHER GRILL LH	TATA spare parts
289488506303CI	FINISHER GRILL LH	TATA spare parts
289488506303D3	FINISHER GRILL LH ARCTIC SILVER	TATA spare parts
289488506303DP	FINISHER GRILL LH PASSION RED	TATA spare parts
289488506303DU	FINISHER GRILL LH	TATA spare parts
28948850630300000	FINISHER GRILL LH LIGHT GOLD	TATA spare parts
289488506303000000	FINISHER GRILL LH ARIZONA BLUE	TATA spare parts
289488506303EY	FINISHER GRILL LH ODYSSEY_BLUE	TATA spare parts
289488506303F2	FINISHER GRILL LH NIGHTFIR_RED	TATA spare parts
289488506303FG	FINISHER GRILL LH	TATA spare parts
289488506303_niu1	FINISHER GRILL LH	TATA spare parts
289488506304	FINISHER GRILL RH	TATA spare parts
289488506304BF	FINISHER GRILL RH	TATA spare parts
289488506304CI	FINISHER GRILL RH	TATA spare parts
289488506304D3	FINISHER GRILL RH ARCTIC SILVER	TATA spare parts
289488506304DP	FINISHER GRILL RH PASSION RED	TATA spare parts
289488506304DU	FINISHER GRILL RH	TATA spare parts
28948850630400000	FINISHER GRILL RH LIGHT GOLD	TATA spare parts
289488506304000000	FINISHER GRILL RH ARIZONA BLUE	TATA spare parts
289488506304EY	FINISHER GRILL RH ODYSSEY_BLUE	TATA spare parts
289488506304F2	FINISHER GRILL RH NIGHTFIR_RED	TATA spare parts
289488506304FG	FINISHER GRILL RH MINERAL_RED	TATA spare parts
289488506306	FOG LAMP COVER LH	TATA spare parts
289488506307	FOG LAMP COVER RH	TATA spare parts
289488506308	RUBBER BUSH FRONT GRILL	TATA spare parts
289488506309	BUMPER MTG.BKT.ON FENDER LH	TATA spare parts
289488506310	BUMPER MTG.BKT.ON FENDER RH	TATA spare parts

289488506313	FRONT FOG LAMP COVER LH	TATA spare parts
289488506314	FRONT FOG LAMP COVER RH	TATA spare parts
289488506315	RETRO REFLECTIVE TAPE LH FOR FRONT BUMPE	TATA spare parts
289488506316	RETRO REFLECTIVE TAPE RH FOR FRONT BUMPE	TATA spare parts
289488508212	RECTANGULAR NON RETURNABLE SPRING CLIP-F	TATA spare parts
289488700101	ASSY CENTRE BONNET	TATA spare parts
289488700102	ASSY INNER PANEL CENTRE BONNET	TATA spare parts
289488700103	ASSY REINFORCEMENT BONNET LOCK BS6	TATA spare parts
289488700104	ASSY REINF BONNET HINGE LH BS6	TATA spare parts
289488700105	ASSY REINF BONNET HINGE RH BS6	TATA spare parts
289488700106	ASSY BONNET HINGE LH	TATA spare parts
289488700107	ASSY BONNET HINGE RH	TATA spare parts
289488700108	ASSY. CENTRE BONNET WITH HINGES BS1/3/4	TATA spare parts
289488700115	ASSY STAY ROD	TATA spare parts
289488700118	RELEASE CABLE LHD	TATA spare parts
289488700118AE	RELEASE CABLE -XEN DC/SC	TATA spare parts
289488700119	RELEASE CABLE RHD - ASEY ENGG	TATA spare parts
289488700122	KIT SHIMS - BIONNET HINGE FIT.	TATA spare parts
289488700129	BONNET LOCK BONNET SIDE - - STD	TATA spare parts
289488700130	KIT FIT OF BON LOCK BON SIDE	TATA spare parts
289488700133	KIT BONNET LOCK FITMENT B/S RHD	TATA spare parts
289488700137	ASSY BONNET STRIKER (BONNET SIDE)	TATA spare parts
289488700138	ASSY. BONNET LATCH (TIE MEMBER SIDE)	TATA spare parts
289488704301	BUTTON CLIP - BONNET LINING	TATA spare parts
289488706302	BONNET INSULATION	TATA spare parts
289488706303	BONNET SEAL FRONT	TATA spare parts
289488706304	BONNET SEAL REAR	TATA spare parts
289488706306	RUBBER BUFFER SIDE	TATA spare parts
289488706307	RUBBER BUFFER FRONT	TATA spare parts
289488706309	BONNET SEAL REAR - RUSSIA	TATA spare parts
289488706310	BONNET SEAL FRONT - RUSSIA	TATA spare parts
289488708201	OUTER PANEL CENTRE BONNET	TATA spare parts
289489100102	KIT ASSY.RUBBER MOUNTING	TATA spare parts
289489100103	KIT ASSY RUBBER MTG X=1600	TATA spare parts
289489100104	KIT FIT OF BODY MOUNTING 1ST MTG	TATA spare parts
289489109201	WASHER	TATA spare parts
289489109202	WASHER	TATA spare parts
289491000101	ASSY.FRONT SEAT COMP.LH RHD HIGHEND	TATA spare parts
289491000102	ASSY.FRONT SEAT COMP.RH RHD HIGHEND	TATA spare parts
289491000103	ASSY. FRONT SEAT LH LHD HIGH END EURO2-4	TATA spare parts
289491000104	ASSY.FRONT SEAT COMP.RH LHD HIGH END	TATA spare parts
289491000105	ASSY.FRT.SEAT LH RHD H/END NON EURO	TATA spare parts
289491000106	ASSY.FRT SEAT RH RHD H/END NON EURO	TATA spare parts
289491000107	ASSY FRONT SEAT COMP LH LHD N EU	TATA spare parts
289491000108	ASSY FRONT SEAT COMP RH LHD N EU	TATA spare parts
289491000109	ASSY FRONT SEAT COMP RH RHD LOW END	TATA spare parts
289491000110	ASSY FRONT SEAT COMP LH RHD LOW END	TATA spare parts

289491000111	ASSY FRONT SEAT COMP LH LHD LOW END	TATA spare parts
289491000112	ASSY FRONT SEAT COMP RH LHD LOW END	TATA spare parts
289491000132	ASSY CO-DRIVER SEAT LHD (SAFARI TYPE) WI	TATA spare parts
289491000133	ASSY DRIVER SEAT LHD (SAFARI TYPE) WITH	TATA spare parts
289491000134	ASSY DRIVER SEAT RHD (SAFARI TYPE) WITH	TATA spare parts
289491000135	ASSY CO-DRIVER SEAT RHD (SAFARI TYPE) WI	TATA spare parts
289491100101	RISER ASSY BS6	TATA spare parts
289491100102	RISER ASSY BS6	TATA spare parts
289491400101	STEM BUCKLE KIT W/O MICRO	TATA spare parts
289491400102	STEM BUCKLE KIT WITH MICRO	TATA spare parts
289491400103	STEM BUCKLE KIT WITH MICRO SW	TATA spare parts
289491400104	STEM BUCKLE KIT W/O MICRO SW	TATA spare parts
289491400105	LEVER TYPE RECLINER O/B LH	TATA spare parts
289491400106	LEVER TYPE RECLINER O/B RH	TATA spare parts
289491400107	ASSY SIDE VALANCE I/B LH COMP	TATA spare parts
289491400108	ASSY SIDE VALANCE I/B LH COMP	TATA spare parts
289491400109	ASSY SIDE VALANCE I/B RH COMP	TATA spare parts
289491400110	ASSY SIDE VALANCE I/B RH COMP	TATA spare parts
289491400111	ASSY SIDE VALANCE O/B LH COMP	TATA spare parts
289491400112	ASSY SIDE VALANCE O/B LH COMP	TATA spare parts
289491400113	ASSY SIDE VALANCE O/B RH COMP	TATA spare parts
289491400114	ASSY SIDE VALANCE O/B RH COMP 953792	TATA spare parts
289491400115	ASSY FHR COMPLETE	TATA spare parts
289491400116	ASSY FHR COMPLETE	TATA spare parts
289491400117	ASSY FHR COMPLETE	TATA spare parts
289491400118	ASSY FSB COMPLETE LH	TATA spare parts
289491400119	ASSY FSB COMPLETE RH	TATA spare parts
289491400120	ASSY FSB COMPLETE LH	TATA spare parts
289491400121	ASSY FSB COMPLETE RH	TATA spare parts
289491400122	ASSY FSB COMPLETE LH	TATA spare parts
289491400123	ASSY FSB COMPLETE RH	TATA spare parts
289491400124	ASSY FSC COMPLETE	TATA spare parts
289491400125	ASSY FSC COMPLETE	TATA spare parts
289491400126	ASSY FSC COMPLETE	TATA spare parts
289491400132	ASSY SIDE VALANCE I/B LH COMPLETE	TATA spare parts
289491400133	ASSY SIDE VALANCE I/B RH COMPLETE	TATA spare parts
289491400134	ASSY SIDE VALANCE O/B LH COMPLETE	TATA spare parts
289491400135	ASSY SIDE VALANCE O/B RH COMPLETE	TATA spare parts
289491400138	ASSY FSB COMPLETE LH	TATA spare parts
289491400139	ASSY FSB COMPLETE RH	TATA spare parts
289491400142	ASSY FSB COMPLETE LH	TATA spare parts
289491400143	ASSY FSB COMPLETE RH	TATA spare parts
289491400144	ASSY FSC COMPLETE RH	TATA spare parts
289491400145	ASSY FSC COMPLETE LH	TATA spare parts
289491400146	ASSY FSB COMPLETE RH	TATA spare parts
289491400147	ASSY FSB COMPLETE LH	TATA spare parts
289491400148	ASSY FHR COMPLETE	TATA spare parts

289491400149	ASSY. SIDE VALANCE PLASTIC O/B RH	TATA spare parts
289491400150	ASSY. SIDE VALANCE PLASTIC O/B LH	TATA spare parts
289491400151	ASSY. SIDE MTG. PLASTIC COVER RH	TATA spare parts
289491400152	ASSY. SIDE MTG. PLASTIC COVER LH	TATA spare parts
289491400155	ASSY RECLINER COVER I\B RH AIRBAG	TATA spare parts
289491400156	ASSY RECLINER COVER I\B LH AIRBAG	TATA spare parts
289491400157	ASSY FSC COMPLETE LH	TATA spare parts
289491400158	ASSY FSC COMPLETE RH	TATA spare parts
289491400160	ASSY FSC COMPLETE RH	TATA spare parts
289491400161	ASSY FSC COMPLETE LH	TATA spare parts
289491406301	RECLINER OPERATING KNOB LH	TATA spare parts
289491406302	RECLINER OPERATING KNOB B002 953803	TATA spare parts
289491406303	RECLINER OPERATING KNOB RH	TATA spare parts
289491406304	RECLINER OPERATING KNOB B002 953802	TATA spare parts
289491406305	RECLINER LEVER COVER RH	TATA spare parts
289491406306	RECLINER LEVER COVER LH	TATA spare parts
289491406307	RECLINER COVER INNER OB RH	TATA spare parts
289491406308	RECLINER COVER INNER IB RH	TATA spare parts
289491406309	HANDLE OPERATING LUMBAR RH	TATA spare parts
289491406310	HANDLE OPERATING LUMBAR LH	TATA spare parts
289491500102	KIT SEAT BELT ASSY.FRONT(IFB)WITH H/ADJ.	TATA spare parts
289491500102AE	KIT SEAT BELT FRT W/H/ADJ-XEN DC	TATA spare parts
289491500103	SEAT BELT ASSY.FRONT LH WITH H/ADJ	TATA spare parts
289491500104	SEAT BELT ASSY.FRONT RH WITH H/ADJ	TATA spare parts
289491500108	KIT SEAT BELTS FRONT BEIGE - HIGH END	TATA spare parts
289491500113	KIT FOR FITMENT OF SEAT BELT GUIDE	TATA spare parts
289491500115	ASSY BRACKET LH SEAT BELT STALK ANCHORAG	TATA spare parts
289491500116	ASSY BRACKET RH SEAT BELT STALK ANCHORAG	TATA spare parts
289491500119	ASSY STEM BUCKLE KIT WITH MICROSWITCH	TATA spare parts
289491500120	KIT SEAT BELT ASSY.FRONT BLACK A/B	TATA spare parts
289491500121	ASSY STEM BUCKLE KIT WITHOUT MICROSWITCH	TATA spare parts
289491506301	GUIDE COVER FOR SEAT BELT	TATA spare parts
289492000101	REAR BENCH SEAT ASSY	TATA spare parts
289492000102	REAR BENCH SEAT ASSY BS6	TATA spare parts
289492000104	REAR SEAT ASSY BS6-PH2	TATA spare parts
289492100101	CUSHION ASSY WITH WIREMEASH AND BKTS BS6	TATA spare parts
289492300101	BACKFRAME ASSY WITH WIREMESH BS6	TATA spare parts
289492400101	BACK TRIM XENON CREW CAB BS6	TATA spare parts
289492400102	CU TRIM XENON CREW CAB BS6	TATA spare parts
289492450101	BACK FOAM XENON CREW CAB BS6	TATA spare parts
289492450102	CU FOAM XENON CREW CAB BS6	TATA spare parts
289492700101	ASSY.STRIKER REAR SEAT	TATA spare parts
289493000101	ASSY.REAR SEAT COMP.F/SBACK HIGH END	TATA spare parts
289493000102	ASSY.RR.SEAT COMPT F/S BACK H/END	TATA spare parts
289493000105	ASSY REAR SEAT COMP LOW END	TATA spare parts
289493000115	ASSY. REAR SEAT-21DEG TORSO ANGLE HIGH E	TATA spare parts
289493000116	ASSY. REAR.SEAT-21DEG TORSO ANGLE HIGH	TATA spare parts

289493000117	ASSY. REAR SEAT-21DEG TORSO ANGLE LOW EN	TATA spare parts
289493000120	ASSY.REAR SEAT-21DEG TORSO ANGLE FOR AIR	TATA spare parts
289493400102	ASSY RSB COMPLETE FOLDABLE	TATA spare parts
289493400104	ASSY RSC COMPLETE FIXED	TATA spare parts
289493500102	ASSY KIT SEAT BELT COMPLETE REAR	TATA spare parts
289493500105	LAP BELT ASSY CENTER BS6-PH2	TATA spare parts
289493500106	WEB BUCKLE CENTER BS6-PH2	TATA spare parts
289493500107	ASSY KIT SEAT BELT COMPLETE REAR	TATA spare parts
289493500107AE	ASY KIT SEAT BLT COMP R-XENDC/SC	TATA spare parts
289493500108	KIT SEAT BELTS REAR BIEGE	TATA spare parts
289493500117	WEB BUCKLE ASSY ON REAR FLOOR BLACK AIRB	TATA spare parts
289493500118	KIT REAR SEAT BELT ASSY WITH LAP BELT AN	TATA spare parts
289529100114	OFFER DRG. ASSY HOSE (SLAVE CYL. BLEEDIN	TATA spare parts
289529100120	MASTER CYLINDER W/BOTTLE BS2/3/4	TATA spare parts
289529100131	ASSY. ADAPTOR WITH STUD	TATA spare parts
289529100133	ASSY. CMC WITH LOW PRESSURE PIPE	TATA spare parts
289529100134	ASSY. SLAVE CYLINDER BS3/4/6	TATA spare parts
289529100136	ASSY. HIGH PRESSURE PIPE	TATA spare parts
289529100146	KIT FLUID RESERVOIR	TATA spare parts
289529100147	KIT FILLER CAP	TATA spare parts
289529103402	BUSH (CLUTCH CONTROL)	TATA spare parts
289529103402AE	BUSH (CLTCH CNTRL) -XENON DC/SC	TATA spare parts
289529104201	SEPRATOR CLAMP	TATA spare parts
289531210110	ASSY. BODY MOUNTING BRACKET-2ND	TATA spare parts
289531210111	ASSY. BODY MOUNTING BRACKET-3RD	TATA spare parts
289532100127	ASSY. BUMP STOPPER FRONT	TATA spare parts
289532400105	ASSY LEAF SPRING REAR	TATA spare parts
289532807701	BEARING BLOCK	TATA spare parts
289540100110	ASSY WHEEL RIM 6.5JX16(M/S WHEELS INDIA)	TATA spare parts
289542100102	CALIPER LH	TATA spare parts
289542100102AE	ASSY TWIN CALIPER LH -XEN DC/SC	TATA spare parts
289542100103	CALIPER RH	TATA spare parts
289542100103AE	ASSY TWIN CALIPER RH -XEN DC/SC	TATA spare parts
289542100107	MAJOR KIT FOR CALIPER	TATA spare parts
289542100108	MINOR KIT FOR CALIPER (. BI 29932377)	TATA spare parts
289542100109	SLIDIING PIN KIT FOR CALIPER	TATA spare parts
289542100109_niu1	SLIDIING PIN KIT FOR CALIPER	TATA spare parts
289542100110	PAD ASSY.KIT FOR CALIPER	TATA spare parts
289542100111	KIT PAD ASSY WITH PACKING	TATA spare parts
289542300115	WHEEL CYLINDER ASSY (M/S BIL-29668546)	TATA spare parts
289542300117	MINOR KIT FOR W.C.25.4DIA.	TATA spare parts
289542300120	KIT LINED SHOE	TATA spare parts
289542300123	ASSY. REAR BRAKE LH (BIL)	TATA spare parts
289542300124	ASSY. REAR BRAKE RH (BIL)	TATA spare parts
289542309904	WHEEL CYL.ASSY.DIA.25.4	TATA spare parts
289542700109	ASSY. BRACKET (PARKING BRAKE SWITCH MTG)	TATA spare parts
289542803307	BRACKET (ON REAR AXLE FOR BUNDY TUBE MTG)	TATA spare parts



289542980101	KIT PAD FRONT BS3/4	TATA spare parts
289542980102	KIT CARRIER ASSY	TATA spare parts
289542994305	ANTI RATTLE CLIP	TATA spare parts
289543500101	ASSY. VACUUM HOSE	TATA spare parts
289543500118	KIT FLUID RESERVIOR	TATA spare parts
289543700120	ABS 8.1 HYDRAULIC MODULATOR	TATA spare parts
289543700121	FILLED WET UNIT ABS 8.1 HYD. BS3/4	TATA spare parts
289546107701	RUBBER SLEEVE (STG. CLOULUMN)	TATA spare parts
289546200103	POWER STG.GEAR BOX-	TATA spare parts
289546300101	ASSY. IDLER ARM WITH BRK RHD (P/STG)	TATA spare parts
289546600106	ASSY P/STG PUMP ( 80 BAR-ELBOW)	TATA spare parts
289546600150	HOUSING ASSEMBLY KIT STG. PUMP - SUMO GR	TATA spare parts
289546603801	SUCTION PORT CONNECTOR STG. PUMP - SUMO	TATA spare parts
289547200105	ASSY BRACKET (FUEL FILTER MTG)	TATA spare parts
289547604201	SEPERATOR CLAMP BS6	TATA spare parts
289554200102	ASSY.TANK UNIT 65LTR.	TATA spare parts
289554208208	DIAGNOSTIC CONNECTOR MTG BKT	TATA spare parts
289554209901	ASSY.HORN 12V 100DIA HIGH TONE	TATA spare parts
289554209902	ELECTRONIC DUAL FLASHER.	TATA spare parts
289554209903	VEHICLE SPEED SENSOR .	TATA spare parts
289554400101	MOTORISEDHEADLAMPLH	TATA spare parts
289554409905	DOOR AJAR LAMP COVER PLATE WIT	TATA spare parts
289554700105	REAR BLOWER SWITCH	TATA spare parts
289554700105AQ	LINEN-REAR BLOWER SWITCH BS6-PH2	TATA spare parts
289554700105BE	REAR BLOWER SWITCH	TATA spare parts
289554809911	SPEAKER(REAR)	TATA spare parts
289558902501	ADAPTOR - CMC MOUNTING	TATA spare parts
289558903201	SPL SOCKET 18A/F BIHEX X 1/2INC	TATA spare parts
289558903202	HANDLE SHORT RH 1/2INC SQ M-F/TOP	TATA spare parts
289558903203	HANDLE LONG RH 1/2 INC SQ.M-F/TOP	TATA spare parts
289558903204	HANDLE SHORT LH 1/2INC SQ.M-F/TOP	TATA spare parts
289558903205	HANDLE LONG LH 1/2INC SQ.M-F/TOP	TATA spare parts
289568206310	MEL SHEET DOOR	TATA spare parts
289572300117	ASSY.CHECK STRAP-FRONT DOOR	TATA spare parts
289572300137	ASSY OUTER HANDLE FRT DOOR LH	TATA spare parts
289572300137A3	ASSY OUTER HANDLE FRT DOOR LH	TATA spare parts
289572300137BF	ASSY OUTER HANDLE FRT DOOR LH	TATA spare parts
289572300137D3	ASSY OUTER HANDLE FRT DOOR LH	TATA spare parts
289572300137DU	ASSY OUTER HANDLE FRT DOOR LH	TATA spare parts
289572300137FG	ASSY OUTER HANDLE FRT DOOR LH	TATA spare parts
289572300138	ASSY OUTER HANDLE FRT DOOR RH	TATA spare parts
289572300138A3	ASSY OUTER HANDLE FRT DOOR RH	TATA spare parts
289572300138BF	ASSY OUTER HANDLE FRT DOOR RH	TATA spare parts
289572300138D3	ASSY OUTER HANDLE FRT DOOR RH	TATA spare parts
289572300138DU	ASSY OUTER HANDLE FRT DOOR LH	TATA spare parts
289572300138FG	ASSY OUTER HANDLE FRT DOOR RH	TATA spare parts
289572308001	TORX SCREW - M8X28	TATA spare parts

289573300109	ASSY.CHECK STRAP-REAR DOOR	TATA spare parts
289573300120A3	ASSY OUTER HANDLE REAR DOOR LH	TATA spare parts
289573300120BF	ASSY OUTER HANDLE REAR DOOR LH	TATA spare parts
289573300120D3	ASSY OUTER HANDLE REAR DOOR LH	TATA spare parts
289573300120DU	ASSY OUTER HANDLE REAR DOOR LH	TATA spare parts
289573300120FG	ASSY OUTER HANDLE REAR DOOR LH	TATA spare parts
289573300121A3	ASSY.OUTER HANDLE REAR DOOR RH	TATA spare parts
289573300121BF	ASSY.OUTER HANDLE REAR DOOR RH	TATA spare parts
289573300121D3	ASSY.OUTER HANDLE REAR DOOR RH	TATA spare parts
289573300121DU	ASSY.OUTER HANDLE REAR DOOR RH	TATA spare parts
289573300121FG	ASSY.OUTER HANDLE REAR DOOR RH	TATA spare parts
289581100154	ASSY.COVER- FIREWALL RH SIDE	TATA spare parts
289581906301	PLUG BUTTON (11 DIA HOLE)	TATA spare parts
289581906302	PLUG BUTTON (14 DIA HOLE)	TATA spare parts
289581906303	PLUG BUTTON (15 DIA HOLE)	TATA spare parts
289581906306	PLUG BUTTON (20 DIA HOLE)	TATA spare parts
289581906308	PLUG BUTTON (22 DIA HOLE) BS6	TATA spare parts
289581906309	PLUG BUTTON (25 DIA HOLE) BS6	TATA spare parts
289581906313	PLUG BUTTON (16 DIA HOLE)	TATA spare parts
289582400123	ASSY.NOZZLE SYSTEM.	TATA spare parts
289582406301	Y-JOINT	TATA spare parts
289582407501	GROMMET FOR WASH PIPE	TATA spare parts
289583400206	FRESH AIR FILTER	TATA spare parts
289589100103	ASSY.KIT FOR BODY MTG	TATA spare parts
289589100112	ASSY.BODY MTG.TOP-(FOR 1ST & 6TH MTG)-M/	TATA spare parts
289589100113	ASSY.BODY MTG.BOTTOM-(FOR FIRST & SIXTH	TATA spare parts
289589100114	ASSY.BODY MTG.TOP-(FOR 2ND 3RD 7TH & 8TH	TATA spare parts
289589100115	ASSY.BODY MTG.BOTTOM- (FOR 2ND 3RD 7TH &	TATA spare parts
289589100116	ASSY.BODY MTG.TOP-(FOR 4TH 5TH 9TH & 10T	TATA spare parts
289589100117	ASSY.BODY MTG.BOTTOM-(FOR 4TH 5TH 9TH &	TATA spare parts
289615219901	ECU WITH GORE PLUG	TATA spare parts
289629100105	ASSY PEDAL LEVER(CLUTCH)	TATA spare parts
289629100106	ASSY CONTROL MTG BRACKET WELDED(CLUTCH)	TATA spare parts
289629100108	ASSY. CONTROL MTG. BRACKET COPMLETE (CLU	TATA spare parts
289629100110	ASSY PEDAL LEVER (CLUTCH)-LHD	TATA spare parts
289629100111	ASSY. CONTROL MTG. BRACKET COPMLETE (CLU	TATA spare parts
289629100117	ASSY.CONTROL MTG.BKT COPMLETE(CLUTCH)	TATA spare parts
289629100118	ASSY. CONTROL MTG BRACKET WELDED(CLUTCH)	TATA spare parts
289629100119	ASSY. PEDAL LEVER (CLUTCH)	TATA spare parts
289629100120	ASSY CONTROL MTG BKT. COMPLETE(CLUTCH)	TATA spare parts
289629100124	ASSY. HIGH PRESSURE PIPE - LHD	TATA spare parts
289629100125	ASSY PEDAL LEVER CLUTCH - LHD	TATA spare parts
289629106301	BUSH (FOR TORSION SPRING)	TATA spare parts
289629106302	BUSH (FOR TORSION SPRING)	TATA spare parts
289629106303	SLEEVE(FOR PEDAL STOPPER PIN)	TATA spare parts
289629106701	PIN (PEDAL STOPPER)	TATA spare parts
289629107401	RIVET (FOR CLUTCH CONTROL MTG)	TATA spare parts

289629108601	SPACER	TATA spare parts
289629108701	TORSION SPRING (CLUTCH)	TATA spare parts
289629108702	TORSION SPRING (CLUTCH)	TATA spare parts
289629108703	RETURN SPRING	TATA spare parts
289630100101	ASSY BRACKET	TATA spare parts
289631000105	ASSY FRAME COMP SC 4X2 28WB 2.2L WT.R	TATA spare parts
289631000107	ASSY FRAME SC 4X2 31WB CNG W/O LB	TATA spare parts
289631000111	ASSY FRAME SC 28WB AIRBAG-E-V	TATA spare parts
289631000112	ASSY FRAME SC 4X2 31WB W/O LB	TATA spare parts
289631000122	FRAME ASSY	TATA spare parts
289631200101	ASSY CROSS MEMBER (CENTER BEARING MTG.)	TATA spare parts
289631200115	ASSY CROSS MEMBER CENTER BEARING MOUTIN	TATA spare parts
289631200117	ASSY.CROSS MEMBER (CNG CYL MTG.REAR)	TATA spare parts
289631200123	ASSY TUBE (FOR GEAR BOX EXTN. MTG.)	TATA spare parts
289631500101	TOW HOOK ASSY REAR	TATA spare parts
289631700102	ASSY. BRACKET RH TAIL LAMP MTG	TATA spare parts
289631700103	ASSY. BRACKET LH TAIL LAMP MTG	TATA spare parts
289631707102	PLATE	TATA spare parts
289632107901	TORSION BAR RH (DIA 30)	TATA spare parts
289632107902	TORSION BAR LH (DIA 30)	TATA spare parts
289632108301	SHIM (CASTOR ADJUSTING)	TATA spare parts
289632300101	ASSY. BRACKET LH (FRT. SHOCK ABS. MTG	TATA spare parts
289632400102	ASSY. RUBBER BUSHING(PIVOT END)	TATA spare parts
289632400105	ASSY. GUIDE PLATE - LH	TATA spare parts
289632400106	ASSY. GUIDE PLATE - RH	TATA spare parts
289632400108	ASSY REAR LEAF SPRING	TATA spare parts
289632400115	LEAF SPRING ASSY REAR	TATA spare parts
289632400116	1ST LEAF WITH BUSH	TATA spare parts
289632400117	BRACKET ASSY BUMP STOPPER MTG REAR	TATA spare parts
289632400118	CLAMP ASSY	TATA spare parts
289632400119	CLAMP ASSY	TATA spare parts
289632407118	FIRST LEAF	TATA spare parts
289632407119	SECOND LEAF	TATA spare parts
289632407120	THIRD LEAF	TATA spare parts
289632407121	FOURTH LEAF	TATA spare parts
289632407122	FIFTH LEAF	TATA spare parts
289632407123	SIXTH LEAF	TATA spare parts
289632407124	SEVENTH LEAF	TATA spare parts
289632407125	1ST LEAF	TATA spare parts
289632407126	2ND LEAF	TATA spare parts
289632407127	3RD LEAF	TATA spare parts
289632407128	4TH LEAF	TATA spare parts
289632407129	5 TH LEAF	TATA spare parts
289632407130	6TH LEAF	TATA spare parts
289632407131	7TH LEAF	TATA spare parts
289632500101	ASSY. REAR AXLE STOPPER	TATA spare parts
289632500102	BUMP STOPPER ASSY REAR	TATA spare parts

289632504201	U CLAMP FOR XENON CNG FLB WITH 407 AXL	TATA spare parts
289632800101	ASSY. ANTI-ROLL BAR COMPLETE	TATA spare parts
289632807701	BEARING BLOCK (ANTI ROLL BAR FRONT)	TATA spare parts
289632808201	CLAMP (ARB FRONT)	TATA spare parts
289640100101	ASSY. RIM TYRE AND BALANCE WEIGHTS.	TATA spare parts
289640100103	ASSY BRACKET SPARE WHEEL MTG.	TATA spare parts
289640100108	ASSY. WHEEL RIM BS1/3/4	TATA spare parts
28964010010820	SPL PACKING ASSY WHEEL RIM 5.5JX16	TATA spare parts
289640100201	ASSY.WHEEL CAP 4X2 (ALLOY WHEEL RIM)	TATA spare parts
289640107701	RUBBER STOPPER	TATA spare parts
289640109902	TYRE 215/75R16 C	TATA spare parts
289641100101	ASSY.PROPELLER SHAFT COMPLETE	TATA spare parts
289641100103	ASSY.PROP.SHAFT COMPLETE-REAR	TATA spare parts
289641100107	ASSY. PROP. SHAFT-REAR FOR SC 28WB-4X2-2	TATA spare parts
289641100108	ASSY PROP SHAFT-REAR SC 28WB-4X2-3L	TATA spare parts
289641100109	ASSY. PROP. SHAFT-REAR FOR SC 28WB-4X2-2	TATA spare parts
289641100208	ASSY.PROP.SHAFT FOR CNG 4X2 3150WB	TATA spare parts
289641109901	COMP FLANGE FOR XENON	TATA spare parts
289641110108	ASSY.PROPELLER SHAFT FRONT	TATA spare parts
289641110208	ASSY.PROPELLER SHAFT FRONT 4X2 -CNG-407	TATA spare parts
289641120108	ASSY.PROPELLER SHAFT REAR	TATA spare parts
289641120208	ASSY.PROPELLER SHAFT REAR 4X2 -CNG-407 A	TATA spare parts
289642100101	ASSY.TWIN POT CALIPER LH	TATA spare parts
289642100102	ASSY.TWIN POT CALIPER RH	TATA spare parts
289642100106	ASSY. TWIN POT CALIPER - (LH) BS1/3/4/6	TATA spare parts
289642100107	ASSY. TWIN POT CALIPER -(RH) BS1/3/4/6	TATA spare parts
289642103701	BRAKE DISC (VENTILATED)	TATA spare parts
289642103702	BRAKE DISC (VENTILATED) BS3/4	TATA spare parts
289642700101	ASSY. BRACKET (PARKING BRAKE LEVER MTG.)	TATA spare parts
289642700108	ASSY. PARKING BRAKE CABLE REAR RH	TATA spare parts
289642700109	ASSY. PARKING BRAKE CABLE REAR LH	TATA spare parts
289642700109AE	ASY PRKNG BRK CBLE R-L-XEN DC/SC	TATA spare parts
289642700110	ASSY. PARKING BRAKE LEVER WITH COVER	TATA spare parts
289642700110AE	ASSY. PARKING BRK LVR-XEN DC/SC	TATA spare parts
289642700116	ASSY. BRACKET (FRONT)	TATA spare parts
289642700118	ASSY. PARKING BRAKE CABLE - FRONT	TATA spare parts
289642700118AE	ASSY.PRKING CABLE FRT-XEN DC/SC	TATA spare parts
289642700119	ASSY. PARKING BRAKE CABLE - FRONT	TATA spare parts
289642700120	ASSY. PARKING BRAKE CABLE REAR RH	TATA spare parts
289642700121	ASSY. PARKING BRAKE CABLE REAR LH	TATA spare parts
289642700122	ASSY. PARKING BRAKE CABLE - FRONT	TATA spare parts
289642700123	ASSY. PARKING BRAKE CABLE - FRONT	TATA spare parts
289642700124	ASSY. PARKING BRAKE CABLE RH - REAR	TATA spare parts
289642700125	ASSY. PARKING BRAKE CABLE REAR LH	TATA spare parts
289642700126	ASSY. PARKING BRAKE CABLE RH - REAR	TATA spare parts
289642700127	ASSY. PARKING BRAKE CABLE REAR LH	TATA spare parts
289642700128	ASSY. BRACKET (REAR CABLE MTG.)	TATA spare parts

289642700129	ASSY. PARKING BRAKE CABLE - FRONT	TATA spare parts
289642700132	ASSY. PARKING BRAKE CABLE - FRONT	TATA spare parts
289642700133	ASSY. PARKING BRAKE CABLE RH - REAR	TATA spare parts
289642700134	ASSY. PARKING BRAKE CABLE REAR LH	TATA spare parts
289642700142	ASSY.PARKING BRAKE CABLE LH.	TATA spare parts
289642700143	ASSY.PARKING BRAKE CABLE RH	TATA spare parts
289642700152	ASSY. PARKING BRAKE LEVER WITH COVER	TATA spare parts
289642700155	ASSY.CLIP	TATA spare parts
289642701602	ASSY. PARKING BRAKE CABLE REAR RH	TATA spare parts
289642701603	ASSY. PARKING BRAKE CABLE REAR LH	TATA spare parts
289642706301	COVER (HAND BRAKE LEVER)	TATA spare parts
289642706302	COVER(HAND BRAKE LEVER) BEIGE BR	TATA spare parts
289642706304	COVER(PARKING BRAKE LEVER)	TATA spare parts
289642800102	ASSY. BRAKE HOSE FRONT	TATA spare parts
289642800103	ASSY. BRACKET (LCRV MTG. ON REAR AXLE)	TATA spare parts
289642800104	ASSY. VACUUM PUMP	TATA spare parts
289642800104AE	VACUUM PUMP XEN DC XEN SC	TATA spare parts
289642806890	7 WAY CONNECTOR	TATA spare parts
289642980101	KIT SLIDING PIN BS4	TATA spare parts
289642980102	KIT CARRIER ASSY	TATA spare parts
289643100101	ASSY. TANDEM MASTER CYL. DIA 25.4	TATA spare parts
289643100103	ASSY TANDEM MASTER CYLINDER	TATA spare parts
289643500101	ASSY. TANDEM BOOSTER W/TMC BOTLE BS1/3/4	TATA spare parts
289643500102	BOOSTER TMC ASSY	TATA spare parts
289643500102AE	ASSY.TANDEM BOOSTER -XENON DC/SC	TATA spare parts
289643500103	ASSY. TENDEM BOOSTER 9 +8 BS1/3/4	TATA spare parts
289643500104	ASSY. TANDEM BOOSTER WITH TMC BOTTLE	TATA spare parts
289643500105	ASSY. TANDEM BOOSTER WITH TMC BOTTLE	TATA spare parts
289643500106	ASSY. TANDEM BOOSTER W/TMC BOTTLE BS4	TATA spare parts
289643500109	ASSY. VACUUM PIPE WITH HOSE CRIMPED	TATA spare parts
289643500116	ASSY. VACUUM HOSE	TATA spare parts
289643500119	ASSY.VACUUM HOSE	TATA spare parts
289643500120	ASSY. VACUUM HOSE	TATA spare parts
289643700102	ASSY.BRACKET(ABS 8.1 ECU MTG.BRACKET)	TATA spare parts
289643800107	ASSY.TUBE	TATA spare parts
289643800108	ASSY.TUBE	TATA spare parts
289643800109	ASSY. TUBE	TATA spare parts
289643800112	ASSY. TUBE	TATA spare parts
289643800113	ASSY. TUBE	TATA spare parts
289643800114	ASSY. TUBE	TATA spare parts
289643800122	TUBE ASSY T-CONN TO FRONT BRAKE HOSE RH	TATA spare parts
289643800131	ASSY.TUBE	TATA spare parts
289643800132	ASSY.TUBE	TATA spare parts
289643800133	ASSY.TUBE	TATA spare parts
289643800134	ASSY.TUBE	TATA spare parts
289643800135	ASSY.TUBE	TATA spare parts
289643800136	ASSY.TUBE	TATA spare parts

289643800137	ASSY.TUBE	TATA spare parts
289643800138	ASSY.TUBE	TATA spare parts
289643800144	TUBE ASSY T-CONN TO FRONT BRAKE HOSE LH	TATA spare parts
289643800145	TUBE ASSY ADAPTER TO REAR HOSE	TATA spare parts
289643800148	ASSY.TUBE	TATA spare parts
289643800149	ASSY.TUBE	TATA spare parts
289643800157	ASSY.TUBE	TATA spare parts
289643800158	ASSY.TUBE	TATA spare parts
289643800168	ASSY. LCRV BRACKET	TATA spare parts
289643800172	ASSEMBLY TUBE	TATA spare parts
289643800173	ASSEMBLY TUBE	TATA spare parts
289643800174	ASSEMBLY TUBE	TATA spare parts
289643800177	ASSY TUBE	TATA spare parts
289643800178	ASSY TUBE	TATA spare parts
289643800180	ASSY TUBE	TATA spare parts
289643800182	ASSY TUBE	TATA spare parts
289643800183	ASSY TUBE	TATA spare parts
289643800184	ASSY TUBE	TATA spare parts
289643800185	ASSEMBLY TUBE	TATA spare parts
289643800186	ASSEMBLY TUBE	TATA spare parts
289643800187	ASSY.TUBE	TATA spare parts
289643800188	ASSY.TUBE	TATA spare parts
289643800189	ASSY.TUBE	TATA spare parts
289643800194	ASSEMBLY TUBE	TATA spare parts
289643800205	ASSY.FRONT BRAKE HOSE	TATA spare parts
289643808235	BRACKET (LCRV MTG. ON AXLE)	TATA spare parts
289643810106	ASSY.TUBE	TATA spare parts
289643810107	ASSY.TUBE	TATA spare parts
289643810113	ASSY. BRACKET (LCRV MTG. ON REAR AXLE)	TATA spare parts
289643810118	ASSY.T MTG.BKT. ON REAR AXLE LH	TATA spare parts
289643810120	ASSY.BRAKE PIPE MODULATOR PORT A -LONG M	TATA spare parts
289643810121	ASSY.BRAKE PIPE MODULATOR PORT B -LONG M	TATA spare parts
289643810123	ASSLY.BRACKET(REAR AXLE MOUNTING)	TATA spare parts
289643810125	ASSEMBLY BRACKET LH (REAR AXLE T MTG.)	TATA spare parts
289643810126	ASSY.BKT.BRAKE PIPE REAR AXLE MTG.	TATA spare parts
289643980101	TMC MAJOR KIT BS4	TATA spare parts
289643980102	TMC MINOR KIT BS4	TATA spare parts
289643980105	TMC WITH RESERVOIR	TATA spare parts
289643980106	ASSY. TANDEM BOOSTER 8IN+9IN	TATA spare parts
289643989101	FLUID RESERVOIR ASSY	TATA spare parts
289643990101	SERVO UNIT ASSY	TATA spare parts
289643990103	RESERVOIR ASSY BRAKE FLUID	TATA spare parts
289646300101	ASSY IDLER ARM BRACKET RHD	TATA spare parts
289646300102	ASSY IDLER ARM BRACKET LHD	TATA spare parts
289646300103	ASSY IDLER ARM WITH MTG BRACKET RHD	TATA spare parts
289646300104	ASSY IDLER ARM WITH MTG BRACKET LHD	TATA spare parts
289646300105	ASSY IDLER ARM WITH BUSH RHD	TATA spare parts

289646300106	ASSY IDLER ARM WITH BUSH LHD	TATA spare parts
289646300106AE	ASSY IDLER ARM W/BUSH-XEN DC/SC	TATA spare parts
289646303402	NORGLIDE BEARING	TATA spare parts
289646309201	WASHER IDLER ARM	TATA spare parts
289646309202	TAB WASHER (IDLER ARM)	TATA spare parts
289646800101	ASSY. RETURN LINE (G/BOX TO RESERVOIR)	TATA spare parts
289646800102	ASSY. HIGH PRESSURE LINE (PUMP TO G/BOX)	TATA spare parts
289646800103	ASSY. RETURN LINE (G/BOX TO RESERVOIR)	TATA spare parts
289646800104	ASSY.SUCTION LINE (RESERVOIR TO PUMP)	TATA spare parts
289646800105	SUCTION LINE (RESERVOIR TO PU)	TATA spare parts
289646800106	ASSY. RETURN LINE	TATA spare parts
289646800111	ASSY SUCTION LINE	TATA spare parts
289646800112	ASSY RETURN LINE	TATA spare parts
289646800114	ASSY. HIGH PR. LINE	TATA spare parts
289646800118	ASSY. SUCTION LINE(RESERVOIR TO PUMP) -	TATA spare parts
289646800119	ASSY. HI. PRESSURE LINE(PUMP TO GEAR BOX	TATA spare parts
289646800120	ASSY. RETURN LINE (G/BOX TO RESERVOIR) -	TATA spare parts
289646800122	ASSY. HIGH PR. LINE W/H TUNER CABLE	TATA spare parts
289646800123	ASSY.HP LINE W/H TUNER CABLE	TATA spare parts
289646804201	CLAMP FOR SUPPORTING STG. LINES	TATA spare parts
289646804202	CLAMP FOR SUPPORTING STG. LINES	TATA spare parts
289646808201	CLAMPING PLATE	TATA spare parts
289647100101	ASSY. TUBE(FUEL FILLER NECK SUPPORT)	TATA spare parts
289647100120	ASSY.BRACKET (CNG CYL.MTG.REAR)	TATA spare parts
289647100127	ASSY. FUEL FILLER NECK	TATA spare parts
289647100130	ASSY. MTG BKT (FUEL FILLER NECK)	TATA spare parts
289647100133	ASSY BKT (FUEL FILLER NECK MTG)	TATA spare parts
289647100134	ASSY.STRUCTURE (FUEL FILLER HOUSING)	TATA spare parts
289647100141	ASSY.GUARD (FUEL LINES)	TATA spare parts
289647100157	ASSY.STRUCTURE (BOWL MTG)	TATA spare parts
289647100167	ASSY REGULATOR MTG. BKT	TATA spare parts
289647104208	COATED CLAMP	TATA spare parts
289647106912	SPACER TUBE	TATA spare parts
289647107704	FUEL FILLING HOSE	TATA spare parts
289647107705	RECEPTACLE CAP STRIP	TATA spare parts
289647107707	FUEL FILLER HOSE	TATA spare parts
289647107708	FUEL FILLING HOSE (FOR W/O LOADBODY)	TATA spare parts
289647107709	FUEL FILLING HOSE ALGERIA	TATA spare parts
289647107710	FUEL FILLING HOSE	TATA spare parts
289647108225	BRACKET (HEATING LINE MTG)	TATA spare parts
289647108293	PIGTAIL MTG BKT	TATA spare parts
289647109901	40 LIT.CNG CYLINDER	TATA spare parts
289647109902	60 LIT.CNG CYLINDER	TATA spare parts
289647109903	60 LIT.CNG CYLINDER	TATA spare parts
289647109904	40 LIT.CNG CYLINDER	TATA spare parts
289647109907	CNG CYLINDER - 90L	TATA spare parts
289647200102	ASSY. BRACKET (CRADLE MOUNTING)	TATA spare parts

289647200104	ASSY.CRADLE COMPLETE	TATA spare parts
289647208215	WASHER	TATA spare parts
289647500103	ASSY STRAP (CNG CYL.MTG)	TATA spare parts
289647500106	ASSY.BRACKET (FUEL LINE MTG)	TATA spare parts
289647500108	ASSY STRAP (FOR 325 DIA.CNG CYL.)	TATA spare parts
289647500109	ASSY STRAP (FOR 267DIA CNG CYL)	TATA spare parts
289647507701	RUBBER PACKING(CNG CYL.MTG)-XENON	TATA spare parts
289647507703	RUBBER PACKING(FOR CNG CYLINDER)	TATA spare parts
289647507704	RUBBER PACKING (FOR 267 DIA.CNG CYL.)	TATA spare parts
289647507705	RUBBER PACKING (FOR 325 DIA.CNG CYL.)	TATA spare parts
289647507706	RUBBER PACKING (ASSY.STRAP MTG.-325 DIA	TATA spare parts
289647600102	ASSY. FUEL LINE ON CHASSIS	TATA spare parts
289647600114	ASSY FUEL LINE ON CHASSIS	TATA spare parts
289647600121	ASSY. L P HOSE (REGULATOR TO ENGINE)	TATA spare parts
289647600122	ASSEMBLY LOCK KIT LHD	TATA spare parts
289647600123	ASSY.HIGH PRESSURE LINE (UNION CROSS TO	TATA spare parts
289647600124	ASSY.HIGH PRESSURE LINE (FRONT CYLINDER	TATA spare parts
289647600126	ASSEMBLY LOCK KIT RHD	TATA spare parts
289647600136	MANUAL VALVE FOR CNG	TATA spare parts
289647600142	MANUAL VALVE FOR CNG CYL	TATA spare parts
289647600143	ASSY.HP LINE (HP FILTER TO REGULATOR)	TATA spare parts
289647600144	ASSY FUEL LINE ON CHASSIS	TATA spare parts
289647600148	ASSY.HP LINE (FILLING NOZZLE TO HP FILTE	TATA spare parts
289647600150	ASSY.HP LINE (FRONT CYL.TO MIDDILE CYL.)	TATA spare parts
289647600151	ASSY.HP LINE (MIDDLE CYL.TO REAR CYL.)	TATA spare parts
289647600159	ASSY HP LINE( NOZZLE TO UNION TEE)	TATA spare parts
289647600160	ASSY.HP LINE (PRESSURE GAUGE TO UNION TE	TATA spare parts
289647600161	ASSY.HP LINE (UNION TEE TO FIRST CYLINDE	TATA spare parts
289647600162	ASSY.HP LINE (UNION TEE TO MIDDLE CYLIND	TATA spare parts
289647600165	ASSY.HP LINE (UNION TEE TO FIRST CYLINDE	TATA spare parts
289647600170	RETURN PIPE ASSY UNDERBODY	TATA spare parts
289647600174	ASSY HEATING LINE(REGULATOR TO RADIATOR)	TATA spare parts
289647600181	ASSY DELIVERY LINE (SEDIMNTR TO FIREWAL)	TATA spare parts
289647600182	ASSY RETURN LINE (FIREWALL TO FUEL TANK)	TATA spare parts
289647600187	ASSY. LOCK KIT RHD-GREY	TATA spare parts
289647600189	KIT LOCK RH (AIRBAG)	TATA spare parts
289647604201	SINGLE TUBE CLAMP-SINGLE CAB	TATA spare parts
289647604204	CLAMP	TATA spare parts
289647604205	CLAMP BS6	TATA spare parts
289647605811	BREATHER HOSE	TATA spare parts
289647605816	BREATHER HOSE	TATA spare parts
289647605824	BREATHER HOSE	TATA spare parts
289647605825	FUEL FILLING HOSE	TATA spare parts
289647606801	MALE CONNECTOR 1/4 ODX1/4 NPT (M)	TATA spare parts
289647606802	UNION CROSS 1/4 OD	TATA spare parts
289647606803	BULK HEAD FEMALE CONNECTOR 1/4 OD	TATA spare parts
289647606804	PIPE PLUG 1/4 NPT	TATA spare parts



289647606806	UNION CROSS 1/4 INCH OD	TATA spare parts
289647606807	BULKHEAD FEMALE CONNECTOR 1/4 INCH OD	TATA spare parts
289647606809	MALE ADAPTER (ON HP REGULATOR)	TATA spare parts
289647606810	PORT CONNECTOR (FOR LP HOSE)	TATA spare parts
289647606951	HEATING LINE (ENGINE TO REGULATOR)	TATA spare parts
289647608201	MOUNTING BRACKET (HIGH PRESSURE FILTER)	TATA spare parts
289647609002	TWO WAY ISOLATION VALVE 1/4 OD	TATA spare parts
289647609004	TWO WAY ISOLATION VALVE (NPT THREAD)	TATA spare parts
289647610103	ASSY.HP.GAS TUBE(TWO WAY VALVE TO H.P F	TATA spare parts
289647610112	ASSY.HEATING LINE(REGULATOR TO RADIATOR)	TATA spare parts
289647610113	ASSY.HEATING LINE(ENGINE TO PR.REGULATOR	TATA spare parts
289647610115	H.P GAS TUBE	TATA spare parts
289647610116	HIGH PRESSURE GAS TUBE	TATA spare parts
289647610117	HIGH PRESSURE GAS TUBE	TATA spare parts
289647616920	HEATING LINE (ENGINE TO REGULATOR)	TATA spare parts
289647700101	HP REGULATOR	TATA spare parts
289647709001	RECEPTACLE	TATA spare parts
289647709003	HP FILTER	TATA spare parts
289649100109	ASSY CATCON WITH HEAT SHIELD	TATA spare parts
289649100110	ASSY CATCON WIT HEAT SHIELD	TATA spare parts
289649200111	EXHAUST FRT PIPE ASSY	TATA spare parts
289649200113	EXHAUST MAIN SILENCER ASSY	TATA spare parts
289649200115	EXHAUST POST SILENCER ASSY	TATA spare parts
289649200118	ASSY SILENCER XENON CNG	TATA spare parts
289649200121	ASSY TAIL PIPE	TATA spare parts
289649200122	ASSY CAT.CON WITH HEAT SHIELD FOR XENON	TATA spare parts
289649200124	ASSY.TAIL PIPE (W/O POST SILENCER)	TATA spare parts
289649200129	ASSY HEAT SHIELD FOR XENON CNG - RETRO	TATA spare parts
289649200131	ASSY. MIDDLE PIPE	TATA spare parts
289649200133	ASSY.FRONT PIPE - XENON EURO-V EXHAUST S	TATA spare parts
289649200134	ASSY.INTERMIDATE PIPE	TATA spare parts
289649200135	ASSY SILENCER - 2.2L XENON EURO-V	TATA spare parts
289649200136	ASSY TAILPIPE EURO-V	TATA spare parts
289649200137	ASSY INTERMEDIATE PIPE (28WB)	TATA spare parts
289649200144	PIPE ASSY WITH RESONATOR INT	TATA spare parts
289649200146	PIPE ASSY RESONATOR	TATA spare parts
289649200147	SILENCER ASSY	TATA spare parts
289649200148	PIPE ASSY FRONT	TATA spare parts
289649200149	SILENCER ASSY WITH HOOKS	TATA spare parts
289649200150	PIPE ASSY WITH RESONATOR INT	TATA spare parts
289649200151	SILENCER ASSY WITH HOOKS	TATA spare parts
289654100105	ASSY.EARTH CHANNEL	TATA spare parts
289654100106	ASSY BATTERY HOLDER	TATA spare parts
289654100107	ASSY.+VE BATTERY CABLE 2.2L	TATA spare parts
289654100109	BATT.CABLE -VE[BATT TO SIDE PANEL	TATA spare parts
289654100111	ASSY BATT. HOLDING ANGLE	TATA spare parts
289654100112	ASSY +VE BATTERY CABLE-2.2L	TATA spare parts

289654100112AE	ASSY +VE BATTERY CABLE-2.2L	TATA spare parts
289654100115	ASSY_CLIP	TATA spare parts
289654100117	ASSY HEAT SHIELD	TATA spare parts
289654108201	BATTERY CABLE SUPPORT	TATA spare parts
289654109901	BATTERY 12V 80AH LHD	TATA spare parts
289654200101	ASSY 2.2L ECU MOUNTING BRACKET	TATA spare parts
289654200103	ASSY.ECU MTG BKT 3.0L	TATA spare parts
289654200104	ASSY 4X4 ECU MOUNTING BRACKET	TATA spare parts
289654200105	ASSY.CLU RELAY BRACKET	TATA spare parts
289654200110	ASSY.CNG ECU MTG BKT.[WELDED]	TATA spare parts
289654200111	ASSY CNG ECU HOLDING CLAMP	TATA spare parts
289654200118	ASSY BCM MTG BRACKET	TATA spare parts
289654200119	ASSY_34P_CONN_SUPPORT_2.2L	TATA spare parts
289654200122	ASSY 4PL ECU SUPPORT	TATA spare parts
289654200126	ASSY 2.2L ECU SUPPORT BKT [XENON-AIRBAG]	TATA spare parts
289654200139	BRACKET ASSY BCM MTG	TATA spare parts
289654201602	RELAY-BUZZER-TURN IND.& DR AJAR	TATA spare parts
289654209902	HORN 12V CLEAR LOW TONE 100 DIA [HELLA]	TATA spare parts
289654209905	ELECTRIC HORN 108 MM LOW	TATA spare parts
289654209906	ELECTRICAL HORN 108 MM HIGH	TATA spare parts
289654209907	CIGARETTE LIGHTER	TATA spare parts
289654209911	RELAY-BUZZER-TURN IND.& DOOR	TATA spare parts
289654400101	ASSY. HEAD LAMP W/BLINK LH RHD BS1/3/4	TATA spare parts
289654400102	ASSY. HEAD LAMP W/BLINK RH RHD BS1/3/4	TATA spare parts
289654400103	REAR FOG LAMP W/REFLECTOR RH RHD	TATA spare parts
289654400104	REV.LAMP W/REFLECTOR LH RHD	TATA spare parts
289654400107	HEADLAMP LEVELIING MOTOR[XENON]	TATA spare parts
289654403301	FRONT REFLEX REFLECTOR MTG BKT	TATA spare parts
289654403302	FRONT REFLEX REFLECTOR MTG BKT RH	TATA spare parts
289654406301	CLIP HEAD LAMP WITHOUT RUBBER GASKET	TATA spare parts
289654500101	ASSY FUSE RELAY BOX BRACKET [2.2L DICOR]	TATA spare parts
289654500102	ASSY.GPIU AND MAXI FUSE BRACKET.	TATA spare parts
289654500103	ASSY.FUSE & RELAY BOX MTG BKT(3L DICOR)	TATA spare parts
289654500105	ASSY.FUSE RELAY BOX	TATA spare parts
289654500107	ASSY 30-POLE FUSE BRACKET LH SIDE	TATA spare parts
289654500108	ASSY BONNET SWITCH WITH HOLDER	TATA spare parts
289654500110	30-POLE FUSE BASE SUPPORT	TATA spare parts
289654500121	ASSY FUSE BOX MTG BKT 4PL	TATA spare parts
289654501602	STG_COMBI_SWITCH_RHD_COLLAPSIBLE	TATA spare parts
289654503305	30 POLE FUSE BOX SUPPORT LH SIDE	TATA spare parts
289654508202	FUSE BOX HOLDER	TATA spare parts
289654508206	FLASHER BASE BRACKET	TATA spare parts
289654508221	ABS 2 POLE MAXI FUSE¿ SUPPORT	TATA spare parts
289654509902	STG COMBI SWITCH RHD COLLAPSIBLE BS1-6	TATA spare parts
289654509907	STG COMBI SWITCH LHD COLLAP	TATA spare parts
289654600102	W/H CABIN RHD 2.2L DICOR	TATA spare parts
289654600105	WIRING HARNESS ROOF SINGLE CAB	TATA spare parts

289654600106	WIRING HARNESS 2.2L EMS EURO-IV	TATA spare parts
289654600110	W/H TAIL 2.2L/4DL W/O LOAD BODY	TATA spare parts
289654600113	WIRING HARNESS CNG EMS	TATA spare parts
289654600118	W/H EMS E-III RHD PREMIUM THAILAND[TYCO	TATA spare parts
289654600128	W/H FRONT	TATA spare parts
289654600129	W/H CABIN RHD	TATA spare parts
289654600130	W/H CABIN LHD	TATA spare parts
289654600131	WIRING /HARNESS EMS 2.2L	TATA spare parts
289654600132	W/H DR-DOOR RHD	TATA spare parts
289654600136	W/H TAIL 4X4	TATA spare parts
289654600139	WIRING HARNESS ROOF DOUBLE CAB	TATA spare parts
289654600144	WIRING HARNESS ROOF DOUBLE CAB	TATA spare parts
289654600148	W/H FRONT 3.0L	TATA spare parts
289654600149	W/H CABIN W/O VGT RHD BS-III/E-III	TATA spare parts
289654600150	W/H CABIN LHD 3.0L	TATA spare parts
289654600153	WIRING HARNESS ENGINE 3.0L	TATA spare parts
289654600159	W/H FRONT 3.0L	TATA spare parts
289654600160	W/H CABIN W/O VGT RHD BS-III/E-III	TATA spare parts
289654600161	W/H CABIN LHD 3.0L	TATA spare parts
289654600164	WIRING HARNESS ENGINE 3.0L	TATA spare parts
289654600166	W/H FRONT 2.2L	TATA spare parts
289654600167	W/H CABIN LHD 2.2L	TATA spare parts
289654600168	W/H CABIN RHD 2.2L	TATA spare parts
289654600169	WIRING /HARNESS EMS 2.2L	TATA spare parts
289654600170	W/H DR DOOR RHD 2.2L	TATA spare parts
289654600171	W/H DR-DOOR LHD 2.2L	TATA spare parts
289654600174	W/H ROOF SC 2.2L	TATA spare parts
289654600175	WIRING HARNESS ROOF DOUBLE CAB	TATA spare parts
289654600177	W/H TAIL 4X4 2.2L	TATA spare parts
289654600178	W/H TAIL 4X4 3.0L	TATA spare parts
289654600179	W/H TAIL 4X4 3.0L	TATA spare parts
289654600186	WIRING HARNESS EMS E II	TATA spare parts
289654600187	WIRING HARNESS EMS E II	TATA spare parts
289654600188	WIRING HARNESS EMS E II	TATA spare parts
289654600189	WH TAIL & TRANSFER CASE WITH ABS 4X4	TATA spare parts
289654600190	WH TAIL & TRANSFER CASE WITH ABS 4X4	TATA spare parts
289654600192	WH TAIL WITH ABS 4X2	TATA spare parts
289654601601	W/H ROOF	TATA spare parts
289654601602	WIRING HARNESS 2.2L EMS EURO-IV	TATA spare parts
289654601606	WIRING HARNESS EMS E II	TATA spare parts
289654601622	W/H CO DR DOOR	TATA spare parts
289654601623	W/H REAR DOOR	TATA spare parts
289654603302	52_POLE_CONN_SUPPORT	TATA spare parts
289654607501	GROMMET	TATA spare parts
289654608201	SUPPORT BATT +VE CABLE CONNECTOR	TATA spare parts
289654608202	1-POLE GLOW PLUG CONN.BKT LHD	TATA spare parts
289654608204	34 POLE CONNECTOR SUPPORT 2.2L	TATA spare parts

289654608205	1 POLE GLOW PLUG CONN BKT RHD	TATA spare parts
289654608221	BRACKET EMS WIRING HARNESS MTG BS6	TATA spare parts
289654608222	BRACKET EMS CABLE MTG	TATA spare parts
289654608223	W/H EMS SUPPORT XENON 4PL	TATA spare parts
289654608236	WH SUPPORT NEAR REA XENON 2.2L	TATA spare parts
289654608237	BRACKET NEAR EGR	TATA spare parts
289654608239	DOOR CONN SUPPORT DRVER SIDE LHD	TATA spare parts
289654608241	WH SUPPORT NEAR RADIATOR	TATA spare parts
289654610122	W/H CO DR DOOR	TATA spare parts
289654610123	W/H REAR DOOR	TATA spare parts
289654620102	WH TAIL WITH ABS W/O LOAD BODY	TATA spare parts
289654620121	WH DR DOOR WITH ADITYA LATCH THAISUMMIT	TATA spare parts
289654620122	WH CO DR DOOR WITH ADITYA LATCH	TATA spare parts
289654620123	WH REAR DOORWITH ADITYA LATCH	TATA spare parts
289654620124	W/H TAIL XENON 2.2L 4X2 W/O LOADBODY EUR	TATA spare parts
289654620125	WIRING HARNESS TAIL	TATA spare parts
289654630122	W/H CO DR DOOR	TATA spare parts
289654630123	W/H REAR DOOR	TATA spare parts
289654640122	W/H CO DR DOOR	TATA spare parts
289654640123	W/H REAR DOOR	TATA spare parts
289654800103	KIT ANTENNA	TATA spare parts
289655106301	XENON PICKUP CNG DECAL LH DOOR-DOMESTIC	TATA spare parts
289655106302	XENON PICKUP CNG DECAL RH DOOR-DOMESTIC	TATA spare parts
289655106303	XENON PICKUP CNG DECAL TAILGATE-DOMESTIC	TATA spare parts
289655106304	MASCOT	TATA spare parts
289658408201	TYPE AND CHASSIS NUMBER PLATE	TATA spare parts
289658900101	ASSY. SCISSORS JACK THAILAND	TATA spare parts
289658900102	ASSY. SCISSOR'S JACK	TATA spare parts
289658900103	ASSY. TOOL KIT - THAILAND	TATA spare parts
289658905001	TOOL BAG	TATA spare parts
289660000109BF	ASSY BODY COMPLETE LHD 3 LTR ARCTIC WHIT	TATA spare parts
289660000109D3	ASSY BODY COMPLETE LHD 3 LT ARCTIC SILVR	TATA spare parts
289660000109DP	ASSY BODY COMPLETE LHD 3 LT PASSION RED	TATA spare parts
289660000109000000	ASSY BODY COMPLETE LHD 3 LT ARIZONA BLUE	TATA spare parts
289660000110BF	ASSY BODY COMPLETE 3 LTR DICR RHD ARCTIC	TATA spare parts
289660000110D3	ASSY BODY COMPLETE 3 LTR DICR RHD ARCTIC	TATA spare parts
289660000110DP	ASSY BODY COMPLETE 3 LTR DICR RHD PASSIO	TATA spare parts
289660000110000000	ASSY BODY COMPLETE 3 LTR DICR RHD ARIZON	TATA spare parts
289660000111BF	ASSY BODY COMPLETE 2.2 L DICOR LHD	TATA spare parts
289660000111D3	ASSY BODY COMPLETE LHD 2.2 LTR ARCTIC SI	TATA spare parts
289660000111DP	ASSY BODY COMPLETE LHD 2.2 LTR PASSION R	TATA spare parts
289660000111DU	QUARTZ_BLACK-ASSY BODY COMPLETE 2.2 L DI	TATA spare parts
289660000111000000	ASSY BODY COMPLETE 2.2 L DICOR LHD	TATA spare parts
289660000111FG	MINERAL_RED-ASSY BODY COMPLETE 2.2 L DIC	TATA spare parts
289660000118BF	ASSY BODY SHELL COMPLT PAINTED LHD 3 LTR	TATA spare parts
289660000118D3	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289660000118DP	ASSY BODY SHELL COMPLT PAINTED LHD 3 LTR	TATA spare parts

289660000118000000	ASSY BODY SHELL COMPLT PAINTED LHD 3 LTR	TATA spare parts
289660000124BF	ASSY BODY SHELL COMPLT PAINTED RHD 3 LTR	TATA spare parts
289660000124D3	ASSY BODY SHELL COMPLT PAINTED RHD 3 LTR	TATA spare parts
289660000124DP	ASSY BODY SHELL COMPLT PAINTED RHD 3 LTR	TATA spare parts
289660000124DU	ASSY BODY SHELL COMP PAINTED RHD 2.2LTR	TATA spare parts
28966000012400000	ASSY.BODY SHELL PAINTED RHD (2.2L) LIGHT	TATA spare parts
289660000124000000	ASSY BODY SHELL COMPLT PAINTED RHD 3 LTR	TATA spare parts
289660000124EY	ASSY.BODY SHELL PAINTED RHD (2.2L) ODYSS	TATA spare parts
289660000125	ASSY BODY SHELL COMPLETE RHD	TATA spare parts
289660000127BF	ASSY.BODY COMPLT.RHD-(2.2L DICOR) ARCTIC	TATA spare parts
289660000127D3	ASSY.BODY COMPLT.RHD-(2.2L DICOR) ARCTIC	TATA spare parts
28966000012700000	ASSY.BODY COMPLT.RHD-(2.2L DICOR) LIGHT_	TATA spare parts
289660000127EY	ASSY.BODY COMPLT.RHD-(2.2L DICOR) ODYSSY	TATA spare parts
289660000129BF	ASSY.BODY COMPLT.LHD (3.0L DICOR) ARCTIC	TATA spare parts
289660000129D3	ASSY.BODY COMPLT.LHD (3.0L DICOR) ARCTIC	TATA spare parts
289660000129DP	ASSY.BODY COMPLT.LHD (3.0L DICOR) PASSIO	TATA spare parts
289660000129000000	ASSY.BODY COMPLT.LHD (3.0L DICOR) ARIZON	TATA spare parts
289660000135BF	ASSY BODY COMPLETE RHD BASE 3 LTR HD	TATA spare parts
289660000135D3	ASSY BODY COMPLETE RHD BASE 3 LTR HD	TATA spare parts
289660000135DP	ASSY BODY COMPLETE RHD BASE 3 LTR HD	TATA spare parts
289660000135000000	ASSY BODY COMPLETE RHD BASE 3 LTR HD	TATA spare parts
289660000136ZZ	ASSY BODY COMPLETE RHD DOMESTIC CNG 2.1	TATA spare parts
289660000141BF	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289660000141D3	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289660000141DP	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289660000141DU	ASSY BODY SHELL COMPLETE PAINTED 2.2 LHD	TATA spare parts
289660000141000000	ASSY BODY SHELL COMP PAINTED. LHD 2.2 LT	TATA spare parts
289660000141FG	ASSY BODY SHELL COMPLETE PAINTED 2.2 LHD	TATA spare parts
289660000150BF	ASSY BODY SHELL COMP PAINTED. LHD 3.0 LT	TATA spare parts
289660000150BL	DK_NEPT_BLUE-ASSY BODY SHELL COMP PAINTE	TATA spare parts
289660000150D3	ASSY BODY SHELL COMP PAINTED. LHD 3.0 LT	TATA spare parts
289660000150DP	ASSY BODY SHELL COMP PAINTED. LHD 3.0 LT	TATA spare parts
289660000150000000	ASSY BODY SHELL COMP PAINTED. LHD 3.0 LT	TATA spare parts
289660000151	ASSY BODY SHELL COMPLETE RHD 3 LTR	TATA spare parts
289660000163BF	ASSY B/S COMPLETE PAINTED LHD SIDE INTRU	TATA spare parts
289660000163D3	ASSY B/S COMPLETE PAINTED LHD SIDE INTRU	TATA spare parts
289660000170BF	ASSY BODY COMPLETE RHD 2.2 LTR PREMIUM A	TATA spare parts
289660000170D3	ARCTIC_SILVR-ASSY BODY COMPLETE RHD 2.2	TATA spare parts
289660000170DU	QUARTZ_BLACK-ASSY BODY COMPLETE RHD 2.2	TATA spare parts
289660000170000000	ARIZONA_BLUE-ASSY BODY COMPLETE RHD 2.2	TATA spare parts
289660000170FG	MINERAL_RED-ASSY BODY COMPLETE RHD 2.2 L	TATA spare parts
289660000174BF	ASSY B/S COMPLETE PAINTED LHD SIDE INTRU	TATA spare parts
289660000174D3	ASSY B/S COMPLETE PAINTED LHD SIDE INTRU	TATA spare parts
289660000174000000	ASSY B/S COMPLETE PAINTED LHD SIDE INTRU	TATA spare parts
289660000175BF	ASSY BODY COMPLETE SAUDI LHD 2.2 LTR ARC	TATA spare parts
289660000175D3	ASSY BODY COMPLETE SAUDI LHD 2.2 LTR ARC	TATA spare parts
289660000175000000	ASSY BODY COMPLETE SAUDI LHD 2.2 LTR ARI	TATA spare parts

289660000179BF	ARCTIC_WHITE-ASSY BODY COMPLETE 2.2 LTR	TATA spare parts
289660000181BF	ASSY BODY COMPLETE RHD 2.2LTRBASE W/O LB	TATA spare parts
289660000181D3	ARCTIC_SILVR-ASSY BODY COMPLETE RHD 2.2L	TATA spare parts
289660000213BF	ASSY BODY SHELL COMPLETE PAINTED RHD CNG	TATA spare parts
289660000213D3	ASSY BODY SHELL COMPLETE PAINTED RHD CNG	TATA spare parts
289660000224ZL	ASSY BODY COMPLETE XENON RX 4SPTC BASE	TATA spare parts
289660000224ZM	ASSY BODY COMPLETE XENON RX 4SPTC BASE	TATA spare parts
289660000224ZN	ASSY BODY COMPLETE XENON RX 4SPTC BASE	TATA spare parts
289660000224ZO	ASSY BODY COMPLETE XENON RX 4SPTC BASE	TATA spare parts
289660000224ZR	ASSY BODY COMPLETE XENON RX 4SPTC BASE	TATA spare parts
289660000224ZU	ASSY BODY COMPLETE XENON RX 4SPTC BASE	TATA spare parts
289660000224ZV	ASSY BODY COMPLETE XENON RX 4SPTC BASE	TATA spare parts
289660000224ZW	ASSY BODY COMPLETE XENON RX 4SPTC BASE	TATA spare parts
289660000224ZZ	ASSY BODY COMPLETE XENON RX 4SPTC BASE	TATA spare parts
289660000235BF	ARCTIC_WHITE-ASSY BODY SHELL COMPLETE PA	TATA spare parts
289660000238BF	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
289660000238CI	OLIVE_GREEN-ASSY BODY SHELL PAINTED	TATA spare parts
289660000238D3	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
289660000238DU	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
289660000238000000	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
289660000238FG	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
289660000248BF	ASSYBODYSHELLCOMPLETEPAINTEDXENONR	TATA spare parts
289660000248D3	ASSY BODY SHELL COMPLETE PAINTED XENON R	TATA spare parts
289660000248DU	ASSY BODY SHELL COMPLETE PAINTED XENON Q	TATA spare parts
289660000248000000	ASSY BODY SHELL COMPLETE PAINTED XENON A	TATA spare parts
289660000248FG	ASSY BODY SHELL COMPLETE PAINTED XENON	TATA spare parts
289660000249	ASSY BODY SHELL COMPLETE RHD XENON RX	TATA spare parts
289660000254BF	BODY SHELL COMPLETE PAINTED LHD SIDE INT	TATA spare parts
289660000258ZY	ASSY BODY COMP.4PL 4DR LHD SAUDI ARABIA	TATA spare parts
289660000259ZY	ASSY BODY COMPLETE 2.2 LTR	TATA spare parts
289660010105BF	ASSY BODY SHELL COMPLETE PAINTED RHD_ARC	TATA spare parts
289661000103	ASSY FLOOR WITH SUBSTRUCTURE COMPLETE	TATA spare parts
289661000110	ASSY FLOOR STAGE I	TATA spare parts
289661000125	ASSY FLOOR STAGE I 2.2L RHD EURO V & AIR	TATA spare parts
289661000143	SUBSTRUCTURE ASSY WITH FLOOR	TATA spare parts
289661200116	EYE BOLT ASSY X2 CHASSIS	TATA spare parts
289661206301	EYE BOLT SLEEVE SEAT RESTRAIN AIRBAG3150	TATA spare parts
289662600106	ASSY DASH PANEL COMPLETE RHD FOR NON AC	TATA spare parts
289662608205	DASH PANEL RHD FOR DOMESTIC CNG BS6	TATA spare parts
289663100103	ASSY REINF SB ADJ B PILLAR LH	TATA spare parts
289663100104	ASSY REINF SB ADJ B PILLAR RH	TATA spare parts
289663600101	ASSY BODYSIDE INNR LH	TATA spare parts
289663600102	ASSY BODYSIDE INNR RH	TATA spare parts
289663700101	ASSY BODY SIDE OUTER COMPLETE LH	TATA spare parts
289663700102	ASSY BODY SIDE OUTER COMPLETE RH	TATA spare parts
289664200101	ASSY LOWER VERT REINF REAR WALL	TATA spare parts
289664200104	ASSY REINF UPPER REAR WALL	TATA spare parts

289664200106	REINFORCEMENT ASSY REAR WALL UPPER	TATA spare parts
289664208201	REINFORCEMENT REAR WALL BS6	TATA spare parts
289664208219	REINFORCEMENT REAR WALL CORNER LH	TATA spare parts
289664208220	REINFORCEMENT REAR WALL CORNER RH	TATA spare parts
289664700101	ASSY REAR WALL COMPLETE LHD	TATA spare parts
289664700102	ASSY REAR WALL COMPLETE RHD	TATA spare parts
289664700104	REAR WALL ASSY	TATA spare parts
289664706301	SEAL REAR WALL SC 3150 WB	TATA spare parts
289664708202	REAR WALL INFILL PANEL 2 DR BS6	TATA spare parts
289664708203	REAR WALL INFILL PANEL RH 2 DR BS6	TATA spare parts
289665100101	ASSY REAR HEADER	TATA spare parts
289665708201	PANEL ROOF 2 DR	TATA spare parts
289667802301	GLASS REAR WINDOW HEATING SC 3150 WB	TATA spare parts
289667806301	REAR FIXED GLASS END BID 3150 WB	TATA spare parts
289668500101	ASSY FLOOR MOULDED CARPET LHD(GRAY)2-DR	TATA spare parts
289668500102	ASSY FLOOR MOULDED CARPET RHD(GRAY)2-DR	TATA spare parts
289668500104	ASSY.FLOOR MOULDED CARPET RHD BIEGE 2-DR	TATA spare parts
289668500106	ASSY FLOOR MOULDED CARPET RHD	TATA spare parts
289668506309	MOULDED CARPET FLOOR-RHD GRAY(NG003)	TATA spare parts
289668900103	ASSY CROSS MEMBER DB COMP RHD COLPS	TATA spare parts
289668900104	ASSY CROSS MEMBER DB COMP LHD COLPS	TATA spare parts
289668900107	CROSS MEMBER ASSY DASHBOARD BS6	TATA spare parts
289668900121	ASSY CROSS MBR DASHBOARD COMP COLPS LHD	TATA spare parts
289668900122	ASSY CROSS MEMBER DASHBOARD COMP.COLPS	TATA spare parts
289668900125	ASSY GEAR SHIFT LEVER BELLOW - SHORTER	TATA spare parts
289668900132	ASSY DASH BOARD RHD GRAY DOMESTIC CNG W/	TATA spare parts
289668900133	ASSY CENTRE CONSOLE DOMESTIC CNG W/O HVA	TATA spare parts
289668900134	ASSY REMOTE LEVER CABLE FUEL LID LHD	TATA spare parts
289668900135	REMOTE LEVER AND CABLE ASSEMBLY FOR FUEL	TATA spare parts
289668906304	STEERING COLUMN COVER RHD COLPSIBLE NG00	TATA spare parts
289668906305	STEERING COLUMN COVER LHD COLPSIBLE NG00	TATA spare parts
289668906310	STEERING COLUMN COVER RHD COLPSIBLE B002	TATA spare parts
289668906315	RUBBER MATT FLOOR CONSOLE ASH TRAY	TATA spare parts
289669200101	ASSY TRIM B PILLAR UPPER LH NG002	TATA spare parts
289669200102	TRIM B PILLAR UPPAR RH	TATA spare parts
289669200103	TRIM B PILLAR LOWER LH GRAY	TATA spare parts
289669200104	TRIM B PILLAR LOWER RH	TATA spare parts
289669200105	ASSY REAL WALL TRIM 2DOOR NG003	TATA spare parts
289669200109	ASSY.TRIM `B` PILLAR LOWER RH 2DR B002	TATA spare parts
289669200122	ASSY TRIM B PILLAR LOWER LH EBONY BLACK	TATA spare parts
289669200123	ASSY TRIM B PILLAR LOWER RH EBONY BLACK	TATA spare parts
289669200124	ASSY REAR WALL TRIM EBONY BLACK AIRBAG	TATA spare parts
289669200125	ASSY TRIM B PILLAR UPPER LH 2 DR LINEN (	TATA spare parts
289669200126	ASSY TRIM B PILLAR UPPER RH 2 DR LINEN (	TATA spare parts
289669200127	B-PILLAR TRIM ASSY LOWER-LH BS6	TATA spare parts
289669200129	B-PILLAR TRIM ASSY LOWER-RH BS6	TATA spare parts
289669206301	TRIM B PILLAR UPPAR LH - 2 DR	TATA spare parts

289669206302	TRIM B PILLAR UPPER RH - 2DR	TATA spare parts
289669206303	TRIM B PILLAR LOWER LH - 2DR	TATA spare parts
289669206304	TRIM B PILLAR LOWER RH - 2DR	TATA spare parts
289669206305	TRIM REAR WALL CROSS MEMBER 2 DOOR	TATA spare parts
289669400103	ASSEMBLY REAR WALL PADDING LH GRAY NG003	TATA spare parts
289669400104	ASSEMBLY REAR WALL PADDING RH GRAY NG003	TATA spare parts
289669400105	ASSY.REAR WALL PADDING LH - B002	TATA spare parts
289669400106	ASSY.REAR WALL PADDING RH - B002	TATA spare parts
289669400107	ASSY REAR WALL PADDING LH	TATA spare parts
289669400108	ASSY REAR WALL PADDING RH	TATA spare parts
289669400118	ASSY REAR WALL PADDING LH EBONY BLACK AI	TATA spare parts
289669400119	ASSY REAR WALL PADDING RH EBONY BLACK AI	TATA spare parts
289669406301	REAR WALL VERTICAL TRIM GRAY	TATA spare parts
289669406302	REAR WALL VERTICAL TRIM BEIGE	TATA spare parts
289669406303	CAP - REAR WALL PADING	TATA spare parts
289669406308	REAR WALL VERTICAL TRIM EBONY BLACK AIRB	TATA spare parts
289669500101	ASSY ROOF LINING 2-DOOR	TATA spare parts
289669500102	KIT FIT OF ROOF INSULATION	TATA spare parts
289669500103	ASSY.ROOF LINING - B001	TATA spare parts
289669500109	ASSY ROOF LINING LINEN (LIGHT GREY) AIRB	TATA spare parts
289669506304	CROSS LINKED FOAM CAB LAMP AREA	TATA spare parts
289670000102	BOLT ASSY	TATA spare parts
289670000104	ASSY.STAY TUBE FRONT LH	TATA spare parts
289670000105	ASSY.STAY TUBE FRONT RH	TATA spare parts
289670000107BF	ASSY LOAD BODY COMPLETE PAINTED	TATA spare parts
289670000107D3	ASSY LOAD BODY COMPLETE PAINTED	TATA spare parts
289670000107DP	ASSY. LOAD BODY COMPLETE PAINTED LHD PA	TATA spare parts
289670000107DU	ASSY. LOAD BODY COMPLETE PAINTED LHD QUA	TATA spare parts
289670000107000000	ASSY LOAD BODY COMPLETE UNPAINTED	TATA spare parts
289670000107FG	MINERAL_READ-XENON TM LOAD BODY(PAINTED)	TATA spare parts
289670000107IQ	ASSY LOAD BODY COMPLETE	TATA spare parts
289670000135	ASSY 3 SIDE DROP FLAT BED LOAD BODY COMP	TATA spare parts
289670000144	XENON CNG 3SIDEDROP FLAT BED LOADBODY PA	TATA spare parts
289670000150	ASSY LOAD BODY COMPLETE SC 3150 WB	TATA spare parts
289670000151BF	ARCTIC_WHITE-ASSY LOADBODY COMPLETE PAIN	TATA spare parts
289670000151D3	ARCTIC_SILVER-ASSY LOADBODY COMPLETE PAI	TATA spare parts
289670006309	MUD LINER INNER REAR LH 3150 WB	TATA spare parts
289670006310	MUD LINER INNER REAR RH	TATA spare parts
289670006311	MUD LINER FRONT INNER LH 3150 WB	TATA spare parts
289670006312	MUD LINER FRONT INNER RH	TATA spare parts
289670006317	INNER MUD LINER REAR-LH	TATA spare parts
289670006318	INNER MUD LINER REAR-RH	TATA spare parts
289670100101	SUBSTRUCTURE 2 DOOR	TATA spare parts
289670108201	LOADBODY FLOOR 2DR	TATA spare parts
289670200101	KIT FIT.OF -ASSY.LOAD GUARD	TATA spare parts
289670200102	ASSY FRONT PANEL XENON FLAT LOADBODY CNG	TATA spare parts
289670200108	ASSY BRACKET LOAD GUARD MTG 3150 WB LH	TATA spare parts



289670200109	ASSY BRACKET LOAD GUARD MTG 3150 WB RH	TATA spare parts
289670200115	LOAD GUARD ASSY 3150 WB	TATA spare parts
289670300101	ASSY FENDER COMPLETE LH	TATA spare parts
289670300102	ASSY FENDER COMPLETE RH	TATA spare parts
289670300120	ASSY SIDE WALL LH XENON CNG FLAT LOADBOD	TATA spare parts
289670300121	ASSY SIDE WALL RH XENON CNG FLAT LOADBOD	TATA spare parts
289670304201	CLAMP 3150 WB	TATA spare parts
289670306301	SEAL FOR SERVICE COVER	TATA spare parts
289670308201	LOADBODY FENDER OUTER LH	TATA spare parts
289670308202	LOADBODY FENDER OUTER RH	TATA spare parts
289670308207	SERVICE COVER FRNDR INNER CNG	TATA spare parts
289670400101	ASSY TAIL GATE XENON CNG FLAT LOADBODY	TATA spare parts
289670400106	ASSY.LATCH.LH	TATA spare parts
289670400107	ASSY.LATCH RH	TATA spare parts
289670400109	ASSY SUPPORT REAR RR BUMPER 2DR 3150 WB	TATA spare parts
289670400117	BRACKET ASSY FRONT-LH	TATA spare parts
289670406305	MTG BKT REAR CORNER BUMPER	TATA spare parts
289670406306	REAR CRNR FACELIFT BUMPER LH 2DR 3150 WB	TATA spare parts
289670406306BF	ARCTIC_WHITE-REAR CRNR FACELIFT BUMPER L	TATA spare parts
289670406306FG	MINERAL_RED-REAR CRNR FACELIFT BUMPER LH	TATA spare parts
289670406307	REAR CRNR FACELIFT BUMPER RH 2DR 3150 WB	TATA spare parts
289670406307BF	ARCTIC_WHITE-REAR CRNR FACELIFT BUMPER R	TATA spare parts
289670406307FG	MINERAL_RED-REAR CRNR FACELIFT BUMPER RH	TATA spare parts
289670900101	ASSY HINGE FLATBED LOADBODY; XENON CNG	TATA spare parts
289672300103	ASSY.LOCK KIT FOR FLAT L/B CNG	TATA spare parts
289672700102	ASSY.DOOR TRIM FRONT LH - LOW END NG003-	TATA spare parts
289672700103	ASSY.DOOR TRIM FRONT RH - LOW END NG003	TATA spare parts
289681100106	ASSY RELEASE CABLE FUEL LID RHD	TATA spare parts
289681100107	ASSY CABLE FUEL LID LATCH LHD	TATA spare parts
289681100112	ASSY RELEASE CABLE FUEL LID LHD	TATA spare parts
289681100113	ASSY CABLE FUEL LID LATCH RHD	TATA spare parts
289681100120	ASSY ROOF DITCH LH METZELER	TATA spare parts
289681100121	ASSY ROOF DITCH RH METZELER	TATA spare parts
289681100135	ASSY. ORVM TIP TAP LH RHD W/O HEAT BS3/4	TATA spare parts
289681100135A3	ASSY ORVM TIP TAP LH RHD W/OHEAD EBONY_1	TATA spare parts
289681100136	ASSY. ORVM TIP TAP RH RHD W/O HEAT BS3/4	TATA spare parts
289681100136A3	ASSY ORVM TIP TAP RH RHD W/OHEAD EBONY_1	TATA spare parts
289681100148	DUMMY LEVER - NON LOAD BODY VC	TATA spare parts
289681508201	GUARD HEAD REST	TATA spare parts
289681508202	GUARD HEAD REST EXTENDED CAB 3150 WB	TATA spare parts
289688126301	MUD LINER FRONT-LH	TATA spare parts
289688126302	MUD LINER FRONT-RH	TATA spare parts
289688126303	MUD LINER INNER FRONT-LH	TATA spare parts
289688126304	MUD LINER INNER FRONT-RH	TATA spare parts
289688300101	FOOT STEP ASSY LH	TATA spare parts
289688300102	FOOT STEP ASSY RH	TATA spare parts
289688460101	BRACKET ASSY SIDE MTG FRONT BUMPER LH	TATA spare parts

289688460102	BRACKET ASSY SIDE MTG FRONT BUMPER RH	TATA spare parts
289688460103	BRACKET ASSY LOWER MTG FRONT BUMPER LH	TATA spare parts
289688460104	BRACKET ASSY LOWER MTG FRONT BUMPER RH	TATA spare parts
289688460105	BRACKET ASSY	TATA spare parts
289688460106	BRACKET ASSY	TATA spare parts
289688500106	ASSY. FRONT GRILL CHROME PLATED BS1/3/4	TATA spare parts
289688500107	GRILL FINISHER LH	TATA spare parts
289688500107BF	ARCTIC_WHITE-ASSY NEW GRILL FINISHER LH	TATA spare parts
289688500107CI	OLIVE_GREEN-ASSY NEW GRILL FINISHER LH	TATA spare parts
289688500107D3	ARCTIC_SILVR-ASSY NEW GRILL FINISHER LH	TATA spare parts
289688500107DU	QUARTZ_BLACK-ASSY NEW GRILL FINISHER LH	TATA spare parts
289688500107000000	ASSY NEW GRILL FINISHER LH	TATA spare parts
289688500107FG	MINERAL_RED-ASSY NEW GRILL FINISHER LH	TATA spare parts
289688500107IQ	DEN_FORST_GN-ASSY NEW GRILL FINISHER LH	TATA spare parts
289688500108	GRILL FINISHER RH	TATA spare parts
289688500108BF	ARCTIC_WHITE-ASSY NEW GRILL FINISHER RH	TATA spare parts
289688500108CI	OLIVE_GREEN-ASSY NEW GRILL FINISHER RH	TATA spare parts
289688500108D3	ARCTIC_SILVR-ASSY NEW GRILL FINISHER RH	TATA spare parts
289688500108DU	QUARTZ_BLACK-ASSY NEW GRILL FINISHER RH	TATA spare parts
289688500108000000	ASSY NEW GRILL FINISHER RH	TATA spare parts
289688500108FG	MINERAL_RED-ASSY NEW GRILL FINISHER RH	TATA spare parts
289688500108IQ	DEN_FORST_GN-ASSY NEW GRILL FINISHER RH	TATA spare parts
289688500117	FRONT BUMPER ASSY STYLS LD BDY 3150	TATA spare parts
289688500117BF	ARCTIC_WHITE-FRONT BUMPER ASSY STYLS LD	TATA spare parts
289688500120	GRILL ASSY	TATA spare parts
289688506303	NEW BLACK FILM FRONT GRILL CHROME PLATE	TATA spare parts
289688506306	SUMPGUARD FRONT BUMPER HIGH END	TATA spare parts
289688506308	NUMBER PLATE MOUNTING FRT BMPR HIGH END	TATA spare parts
289688506309	T-EMBLEM FRT BMPR 3150	TATA spare parts
289688506312	CHROME TOP FRT BMPR 3150	TATA spare parts
289688508201	STEEL WIRE MESH NEW FRONT CHROME GRILL	TATA spare parts
289691000101	ASSY FRONT SEAT COMP. LH RHD XENON CNG D	TATA spare parts
289691000102	ASSY FRONT SEAT COMP. RH RHD XENON CNG D	TATA spare parts
289691000105	SC ASSY FRONT SEAT LH RHD FABRIC+VINYL	TATA spare parts
289691000106	SC ASSY FRONT SEAT RH RHD FABRIC+VINYL	TATA spare parts
289691000107	FRONT SEAT LH RHD XENON RX-EGR MTG	TATA spare parts
289691000109	ASSY XENON RX FRONT SEAT RH HEAD REST	TATA spare parts
289691000110	ASSY XENON RX FRONT SEAT LH(HEAD REST)	TATA spare parts
289691000113	DRIVER SEAT ASSY RH	TATA spare parts
289691000114	CO-DRIVER SEAT ASSY LH	TATA spare parts
289691000122	DRIVER SEAT ASSY	TATA spare parts
289691000123	CO-DRIVER SEAT ASSY	TATA spare parts
289691000124	DRIVER SEAT ASSY LH	TATA spare parts
289691100113	RISER ASSY FRONT SEAT	TATA spare parts
289691100114	SLIDER ASSY LH	TATA spare parts
289691100115	SLIDER ASSY RH	TATA spare parts
289691100116	SEAT FRAME ASSY DRIVER SEAT	TATA spare parts

289691100119	RECLINER ASSY RH	TATA spare parts
289691400125	ASSY HEAD RESTRAINT COMPLETE	TATA spare parts
289691500101	KIT SEAT BELT FRONT WITH IB BUCKLE FLOOR	TATA spare parts
289691500102	ASSY CABLE BUCKLE FRONT(GREY)	TATA spare parts
289691930101	HEADREST ASSY	TATA spare parts
289694000101	CO-DRIVER SEAT ASSY RH	TATA spare parts
289715206302	HT CABLE CLAMP	TATA spare parts
289715209901	PLUG TOP COIL BS3/4	TATA spare parts
289715209903	HT CABLE 750L	TATA spare parts
289715209904	HT CABLE 690L	TATA spare parts
289715209905	HT CABLE 620L	TATA spare parts
289715209906	HT CABLE 580L	TATA spare parts
289729100102	ASSY HOSE (CLUTCH)	TATA spare parts
289729108201	BRACKET(CLUTCH BLEEDING HOSE SUPPORT)	TATA spare parts
289730100101	ASSY ACCELERATOR CABLE XENON	TATA spare parts
289730100103	ASSY. ACCELERATOR CABLE	TATA spare parts
289731000106	ASSY FRAME 4X2(SPACE CAB 2.2L DICOR ENG)	TATA spare parts
289731200101	ASSY. CROSS MEMBER (FRONT EXTENSION)	TATA spare parts
289731200112	ASSY. BRACKET FUEL TANK MTG. FRONT	TATA spare parts
289731200113	ASSY CROSS MEMBER (FUEL TANK MTG)	TATA spare parts
289731200116	ASSY. BRACKET ENGINE MTG. REAR	TATA spare parts
289731200120	ASSY CROSS MEMBER ENGINE MOUNTING REAR	TATA spare parts
289731200121	ASSY.REAR CROSSMEMBER (FRNT SUSP)	TATA spare parts
289731208213	SUPPORT (CAB MTG. END) BS6	TATA spare parts
289732100105	ASSY. BRACKET (SCRUB) - RH (UPPER W/B MT	TATA spare parts
289732100106	ASSY. BRACKET- LH (UPPER W/B MTG.)	TATA spare parts
289732100107	SUB. ASSY. LOWER WISHBONE (SCRUB) - RH	TATA spare parts
289732100108	SUB. ASSY. LOWER WISHBONE (SCRUB) - LH	TATA spare parts
289732100111	ASSY. LOWER WISHBONE (SCRUB)RH BS3/4	TATA spare parts
289732100112	ASSY. LOWER WISHBONE LH BS3/4	TATA spare parts
289732100117	ASSY. LOWER BALL JOINT BS3/4	TATA spare parts
289732100118	ASSY PIVOT BUSH(FRT SUSP LOWER LINK)	TATA spare parts
289732100119	ASSY. BRKT - LH (FRONT SUSP. L W/B MTG.)	TATA spare parts
289732100120	ASSY.BRKT - RH (FRONT SUSP. L W/B MTG.)	TATA spare parts
289732100127	SUB ASSY. LOWER WISHBONE - RH	TATA spare parts
289732100128	SUB ASSY. LOWER WISHBONE - LH	TATA spare parts
289732100129	SUB ASSY LOWER WISHBONE WITH BUSH - RH	TATA spare parts
289732100130	SUB ASSY. LOWER WISHBONE WITH BUSH - LH	TATA spare parts
289732100131	ASSY. LOWER WISHBONE RH BS3/4	TATA spare parts
289732100132	ASSY. LOWER WISHBONE COMP. LH BS3/4	TATA spare parts
289732100140	UPPER WISHBONE SUB ASSY WITH BUSH RH	TATA spare parts
289732100141	UPPER WISHBONE SUB ASSY WITH BUSH LH	TATA spare parts
289732100142	UPPER WISHBONE ASSY COMP RH	TATA spare parts
289732100143	UPPER WISHBONE ASSY COMP LH	TATA spare parts
289732100147	BUSH ASSY LOWER WISHBONE REAR	TATA spare parts
289732100148	BUSH ASSY LOWER WISHBONE FRONT	TATA spare parts
289732100162	LOWER WISHBONE ASSY RH	TATA spare parts

289732100163	LOWER WISHBONE ASSY LH	TATA spare parts
289732100166	UPPER WISHBONE ASSY RH	TATA spare parts
289732100167	UPPER WISHBONE ASSY LH	TATA spare parts
289732103201	WHEEL STOPPER BOLT	TATA spare parts
289732103204	MOUNTING PIN LOWER WISHBONE FRONT	TATA spare parts
289732105103	SPINDLE TOP	TATA spare parts
289732105104	UPPER WISHBONE RH	TATA spare parts
289732105105	UPPER WISHBONE LH	TATA spare parts
289732107705	BUSH TORSION BAR LEVER	TATA spare parts
289732108601	WHEEL STOPPER - RH	TATA spare parts
289732108602	WHEEL STOPPER - LH	TATA spare parts
289732300101	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
289732300102	ASSY. FRONT SHOCK ABSORBER BS3/4	TATA spare parts
289732300103	FRONT SHOCK ABSORBER	TATA spare parts
289732301601	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
289732400102	REAR LEAF SPRINGS	TATA spare parts
289732400104	ASSY. GUIDE PLATE LH (REAR SPRING)	TATA spare parts
289732400105	ASSY. GUIDE PLATE RH (REAR SPRING)	TATA spare parts
289732400107	ASSY. BRACKET (VIBRATION DAMPER MTG.)	TATA spare parts
289732400108	ASSY. REAR LEAF SPRING	TATA spare parts
289732400111	ASSY. VIBRATION DAMPER.	TATA spare parts
289732400114	ASSY. GUIDE PLATE - LH (REAR SPRING ASSY	TATA spare parts
289732400115	ASSY. GUIDE PLATE - RH (REAR SPRING ASSY	TATA spare parts
289732400116	ASSY. REAR LEAF SPRING	TATA spare parts
289732400126	FIRST LEAF ASSY WITH BUSH	TATA spare parts
289732400126DF	MAIN LEAF W/BUSH - XENON 2.2L BS4	TATA spare parts
289732400130	LEAF SPRING ASSY REAR	TATA spare parts
289732401601	REAR LEAF SPRING	TATA spare parts
289732404205	CLAMP	TATA spare parts
289732404209	CLAMP - RR	TATA spare parts
289732407126	FIRST LEAF	TATA spare parts
289732407127	SECOND LEAF	TATA spare parts
289732407128	THIRD LEAF	TATA spare parts
289732407129	FIRST LEAF	TATA spare parts
289732407130	SECOND LEAF	TATA spare parts
289732407131	FOURTH LEAF	TATA spare parts
289732407132	FIFTH LEAF	TATA spare parts
289732407133	SIXTH LEAF	TATA spare parts
289732407134	SEVENTH LEAF	TATA spare parts
289732407135	EIGHTH LEAF	TATA spare parts
289732407136	NINETH LEAF	TATA spare parts
289732407137	NINETH LEAF	TATA spare parts
289732407146	FIRST LEAF	TATA spare parts
289732407147	SECOND LEAF	TATA spare parts
289732407147DF	SECOND LEAF - XENON 2.2L BS4	TATA spare parts
289732407148	THIRD LEAF	TATA spare parts
289732407148DF	THIRD LEAF - XENON 2.2L BS4	TATA spare parts

289732407702	TIP INSERT	TATA spare parts
289732408213	CENTER PAD	TATA spare parts
289732408605	FERRULE	TATA spare parts
289732500101	ASSY. REAR AXLE STOPPER	TATA spare parts
289732504201	'U' BOLT (REAR SPRING)	TATA spare parts
289732504202	U' CLAMP (REAR)	TATA spare parts
289732600103	ASSY.REAR SHOCK ABSORBER	TATA spare parts
289732600104	ASSY. REAR SHOCK ABSORBER BS1/3/4	TATA spare parts
289732600105	SHOCK ABSORBER ASSY REAR	TATA spare parts
289732600106	REAR SHOCK ABSORBER	TATA spare parts
289732601601	ASSY. REAR SHOCK ABSORBER	TATA spare parts
289732601601AE	ASSY RR SHCK ABSRBR -XEN DC/SC	TATA spare parts
289732800102	ASSY. LINK FRONT ANTIROLL BAR	TATA spare parts
289732800103	ASSY. ANTI-ROLL BAR COMPLETE. (SCRUB)	TATA spare parts
289732800107	KIT FOR ARB. (CLAMP & BUSH)	TATA spare parts
289732800108	KIT FOR ARB (LINK COMP.)	TATA spare parts
289732807901	FRONT ANTI-ROLL BAR	TATA spare parts
289733000103	FRONT AXLE RH WITH HUB & BRA.4X2(N/ABS)	TATA spare parts
289733000104	FRONT AXLE LH WITH HUB & BRA.4X2(N/ABS)	TATA spare parts
289733205101	STUB AXLE - RH - 4X2 ABS ONLY.	TATA spare parts
289733205102	STUB AXLE - LH - 4X2 ABS ONLY.	TATA spare parts
289733208201	LOCK PLATE	TATA spare parts
289733805101	TIE ROD ARM-RH	TATA spare parts
289733805102	TIE ROD ARM-LH	TATA spare parts
289740100102	ASSEMBLY BRACKET SPARE WHEEL MOUNTING	TATA spare parts
289740100201	ASSY.WHEEL CAP 4X2 (ALLOY WHEEL RIM)	TATA spare parts
289740100204	ASSY.VALVE	TATA spare parts
289740106501	ASSY.DOMED WHEEL NUT	TATA spare parts
289740106702	WHEEL BOLT	TATA spare parts
289740300201	ASSY.SPARE WHEEL CARRIER- CHAIN TYPE	TATA spare parts
289740307701	SPARE WHEEL MTG. BRACKET - RUBBER STRIP.	TATA spare parts
289740309901	HEX SCREW M10X1.25X25	TATA spare parts
289741100101	ASSY.PROP.SHAFT COMPLETE-REAR	TATA spare parts
289741100104	ASSY PROP.SHAFT SC/SPC/CC 3150WB 4X2 REA	TATA spare parts
289742700106	ASSY.PARKING BRAKE CABLE REAR RH	TATA spare parts
289742700107	ASSY.PARKING BRAKE CABLE REAR LH	TATA spare parts
289742700108	ASSY.PARKING CABLE FRONT	TATA spare parts
289742800101	ASSY.BRAKE HOSE FRONT LH	TATA spare parts
289743800105	ASSY.BRACKET( DAMPER )	TATA spare parts
289743800115	ASSY. TUBE	TATA spare parts
289743800120	ASSY. METAL PIPE	TATA spare parts
289743800121	ASSY. VACUUM HOSE	TATA spare parts
289743800125	ASSY TUBE	TATA spare parts
289743800126	ASSY TUBE	TATA spare parts
289743800144	ASSY.TUBE	TATA spare parts
289743800145	ASSY TUBE	TATA spare parts
289743800146	ASSY TUBE	TATA spare parts

289743800147	ASSY. TUBE	TATA spare parts
289743808601	SPACER THK.10	TATA spare parts
289746100101	ASSY.RADIATOR MTG-TOP RH	TATA spare parts
289746108201	RADIATOR MTG BRACKET- TOP LH	TATA spare parts
289746108203	RADIATOR MTG BRACKET-BOTTOM LH	TATA spare parts
289746108204	RADIATOR MTG BRACKET -BOTTOM RH	TATA spare parts
289747108216	PIGTAIL MTG BRACKET	TATA spare parts
289747404901	INLINE FUEL HEATER	TATA spare parts
289747507701	RUBBER PAD CYLINDER STOPPER	TATA spare parts
289747507709	RUBBER PACKING FOR 317 DIA.CNG	TATA spare parts
289747600103	ASSY.VENT LINE (CONNECTOR TO LOAD GUARD)	TATA spare parts
289747600112	ASSY.LOW PRESSURE HOSE (FUEL RAIL TO HP	TATA spare parts
289747600118	ASSY.VENT LINE (REGULATOR TO FREE END)	TATA spare parts
289747606801	MALE CONNECTOR(1/4 INCH NPT X M18)	TATA spare parts
289747606810	NIPPLE (HP REGULATOR END)- CLASS 2	TATA spare parts
289747608203	MTG.BRACKET (LP HOSE)- CLASS	TATA spare parts
289747609001	TWO WAY ISOLATION VALVE 1/4IN OD	TATA spare parts
289747610101	ASSY.HP.GAS TUBE(HP.FILTER TO REGULATOR)	TATA spare parts
289747610102	ASSY.VENTING TUBE(PRE.REGULATOR-CONNECT)	TATA spare parts
289747620101	OMB IDRA VT MANUAL CYLINDER VALVE	TATA spare parts
289747700102	H.P.REGULATOR ASSEMBLY (CLASS 2)	TATA spare parts
289747709901	AEB PRESSURE GAUGE	TATA spare parts
289747994901	SOLENOID COIL	TATA spare parts
289747995301	GASKET (MOON CYLINDER VALVE TO CYLINDER)	TATA spare parts
289747997201	DRAIN PLUG	TATA spare parts
289747997701	O-RING OF DRAIN PLUG	TATA spare parts
289747997702	SCREW PLUG O-RING	TATA spare parts
289747997703	SCREW PLUG BACKUP O-RING	TATA spare parts
289747997704	O-RING RECEPTACLE	TATA spare parts
289747999901	HP FILTER CARTRIDGE	TATA spare parts
289749100106	ASSY. SILENCER	TATA spare parts
289749200101	ASSY.INTERMEDIATE EXHAUST PIPE	TATA spare parts
289749200103	ASSY EXHAUST PIPE	TATA spare parts
289749200108	3 HOLE GASKET	TATA spare parts
289749200109	TWO HOLE GASKET	TATA spare parts
289754100101	BATT.CABLE POSITIVE	TATA spare parts
289754100102	ASSY BATTERY CABLE -VE BATT TO CUT OFF	TATA spare parts
289754100103	ASSY BATTERY CABLE - VE CUT OFF SW TO S	TATA spare parts
289754100104	BATTERY ASSY CABLE - VE CLUTCH HSG TO F	TATA spare parts
289754100105	W/H ALTERNATOR STA	TATA spare parts
289754100106	ASSY. BATTERY HOLDING CLAMP	TATA spare parts
289754100108	BATT.CABLE POSITIVE XENON CNG	TATA spare parts
289754100110	ASSY +VE BATTERY CABLE CNG (EX)	TATA spare parts
289754109901	STARTER SOLENOID CABLE XENON CNG EX	TATA spare parts
289754200108	ASSY.CNG ECU HOLDING BKT AND CLAMP	TATA spare parts
289754200110	ASSY CNG MTG BRACKET	TATA spare parts
289754209902	WARNING BUZZER	TATA spare parts

289754500101	ASSY BATT.CUT-OFF SWITCH MTG. BKT	TATA spare parts
289754509901	BATTERY CUT OFF SWTCH 12V 100A BS2/3/4/6	TATA spare parts
289754509903	DOOR SWITCH	TATA spare parts
289754509905	REVERSE LIGHT SWITCH	TATA spare parts
289754600102	ASSY.CLOSING PLATE	TATA spare parts
289754600105	ASSY CHANNEL SUPPORT W/H EMS	TATA spare parts
289754600108	WIRING HARNESS ENGINE (EMS W/H)	TATA spare parts
289754600110	U CLAMP ASSY 3R90(14.5MM)+3T14T(20MM) M/	TATA spare parts
289754600114	SPARE KIT FOR MODIFIED XENON 2.2L BATTER	TATA spare parts
289754600116	ASSY BKT FOR W/H CH SUPPORT-XENON CNG	TATA spare parts
289754600117	ASSY. BKT W/H EMS XENON CNG	TATA spare parts
289754600118	ASSY BKT FOR W/H CH SUPPORT	TATA spare parts
289754601604	W/H ROOF BASE SC	TATA spare parts
289754601613	WH CABIN RHD BASE DOMESTIC	TATA spare parts
289754601614	WH FRONT RHD BASE DOMESTIC	TATA spare parts
289754601615	WH TAIL CNG DOMESTIC	TATA spare parts
289754608201	CONNECTOR SUPPORT	TATA spare parts
289754608202	CABLE SUPPORT	TATA spare parts
289754608203	CONN HOLDING ANGLE	TATA spare parts
289754608206	LAMDA SENSOR PARKING SUPPORT	TATA spare parts
289754608211	CHANNEL SUPPORT-XENON CNG	TATA spare parts
289754608222	LAMBDA SENSOR PIGTAIL SUPPORT	TATA spare parts
289754608223	LAMBDA SENSOR PARKING¿ BRACKET	TATA spare parts
289754609906	U CLAMP ASSY (14.5MM)+(18.6MM)	TATA spare parts
289754609908	PIPE CLIP ASSY (18~20MM)+(14~16MM) M/S A	TATA spare parts
289754609909	PIPE CLIP ASSY (18~20MM)+(16~24MM) M/S A	TATA spare parts
289754609913	HT CABLE 750L (SUUPLIER PART) M/S ADVANT	TATA spare parts
289754609914	HT CABLE 690L (SUUPLIER PART) M/S ADVANT	TATA spare parts
289754609915	HT CABLE 620L (SUUPLIER PART) M/S ADVANT	TATA spare parts
289754609916	HT CABLE 580L (SUUPLIER PART) M/S ADVANT	TATA spare parts
289754610104	WH CABIN RHD BASE DOMESTIC	TATA spare parts
289754610105	WH FRONT RHD BASE DOMESTIC	TATA spare parts
289754610106	WH TAIL CNG DOMESTIC	TATA spare parts
289754610108	WH EMS WITH ETC-PTC & NANO SENSOR	TATA spare parts
289754610109	PIGTAIL FOR AFS REGULATOR SENSOR	TATA spare parts
289754610110	WH EMS CNG DOMESTIC	TATA spare parts
289754610111	WIRING HARNESS EMS XENON CNG	TATA spare parts
289754620102	WH CYLINDER EARTHING-2	TATA spare parts
289754620103	WH CYLINDER EARTHING-3	TATA spare parts
289754620104	WH CABIN RHD BASE DOMESTIC	TATA spare parts
289754620105	WH FRONT RHD BASE DOMESTIC	TATA spare parts
289754620106	WH TAIL CNG DOMESTIC	TATA spare parts
289754620109	WH ROOF BASE SC	TATA spare parts
289754620111	WIRING HARNESS EMS XENON CNG	TATA spare parts
289754630104	WH CABIN RHD BASE DOMESTIC	TATA spare parts
289754630105	WH FRONT RHD BASE DOMESTIC	TATA spare parts
289754630106	WH TAIL CNG DOMESTIC	TATA spare parts

289755106301	CNG MASCOT	TATA spare parts
289755106302	MASCOT CLE - BASE VERSION	TATA spare parts
289755106303	MASCOT CLS - PREMIUM VERSION	TATA spare parts
289758408201	TWO WAY VALVE ON-OFF STICKER	TATA spare parts
289758509901	CROSSLINK FOAM	TATA spare parts
289761000104	ASSY FRONT FLOOR UNDERSTRUCTURE LH	TATA spare parts
289761000105	ASSY FRONT FLOOR UNDERSTRUCTURE RH	TATA spare parts
289761200101	ASSY BRACKET PICK UP POINT	TATA spare parts
289761208201	REINFORCEMENT REAR	TATA spare parts
289761508201	JACK RETAINING BRACKET	TATA spare parts
289761600106	ASSY FLOOR PANEL FRONT COMPLETE RHD	TATA spare parts
289763100110	ASSY B PILLAR INNER RH	TATA spare parts
289763100111	ASSY REINF C PILLAR LOWER LH	TATA spare parts
289763100112	ASSY REINF C PILLAR LOWER RH	TATA spare parts
289763108231	REINF C PILLAR UPPER LH	TATA spare parts
289763108232	REINF C PILLAR UPPER RH	TATA spare parts
289763600111	ASSY FILLER EXP FOAM CANT RAIL REAR LH	TATA spare parts
289763600112	ASSY FILLER EXP FOAM CANT RAIL REAR RH	TATA spare parts
289763608203	SILL STRENGTHENER OUTER LH	TATA spare parts
289763608204	SILL STRENGTHENER OUTER RH	TATA spare parts
289764208203	REINF VERTICAL LOWER SPC CAB NVH	TATA spare parts
289764208205	CORNER REINF REAR WALL	TATA spare parts
289764208206	BRACKET REAR WALL TRIM LOWER	TATA spare parts
289764700101	ASSY REAR WALL	TATA spare parts
289767300104	KIT HINGE AND MTG BKT FOR FLIP GLASS	TATA spare parts
289767306309	SEALING WASHER QTR GLASS	TATA spare parts
289768500105	ASSY MOULDED CARPET FLOOR RHD	TATA spare parts
289768900102	ASSY CROSS CAR BEAM COMPLETE	TATA spare parts
289768900123	ASSY STG.380 DIA SUN STG LEATHER BR35- T	TATA spare parts
289768900126	ASSY STG 380 DIA SUN STG THAI LOW END	TATA spare parts
289768900129	PAINTED LEATHER (BIEGE )	TATA spare parts
289768900131	ASSY STEERING WHEEL D380 NON COLLPS LEAT	TATA spare parts
289768900132	UN PAINTED NON LEATHER( BLACK )	TATA spare parts
289768900135	ASSY STEERING WHEEL D380 COLLPS PAINTED	TATA spare parts
289768900136	ASSY STEERING WHEEL D380 COLLPS UNPAINTE	TATA spare parts
289768900146	ASSY HORN PAD COLLP LOW END	TATA spare parts
289768900147	ASSY CROSS CAR BEAM COMPLETE RHD - COLLA	TATA spare parts
289768906320	BINNACLE INSTRUMENT CLUSTER FRONT RHD	TATA spare parts
289768906329	MAT FLOOR CONSOLE BUCKET TYPE	TATA spare parts
289768906364	T' EMBLEM	TATA spare parts
289769200124	ASSY REAR WALL TRIM LOWER	TATA spare parts
289769206341	FOAM BETWEEN REAR WALL TRIM & QUARTER T	TATA spare parts
289769406304	FOOT STEP MTG.BKT.COVER	TATA spare parts
289769500104	KIT ROOF INSULATIONS SPACE CAB	TATA spare parts
289770100101	ASSY LOAD BODY UNDERSTRUCTURE	TATA spare parts
289770100105	ASSY REAR CLOSING PANEL	TATA spare parts
289770108201	LOADBODY FLOOR	TATA spare parts



289770300115	ASSY F/I CENTRE LH WITH 0125 THAI KIT	TATA spare parts
289770300116	ASSY F/I CENTER RH WITH 0125 THAI KIT	TATA spare parts
289770300118	ASSY FENDER INNER FRONT LH STAGE 1 CNG	TATA spare parts
289770308203	LOADBODY FENDER INNER LH	TATA spare parts
289770308204	LOADBODY FENDER INNER RH	TATA spare parts
289770400101	ASSY TAILGATE WITH HINGES	TATA spare parts
289770400109	REAR FOOT STEP THAILAND DEV	TATA spare parts
289772300101	ASSY INNER HANDLE WITH LINK TH BEIGE	TATA spare parts
289772300102	ASSY INNER HANDLE WITH LINK RH TH BEIGE	TATA spare parts
289772300104	ASSY LOCK KIT RHD - THAILAND	TATA spare parts
289772300106	ASSY LOCK KIT RHD - COLLAPSIBLE STG RHD	TATA spare parts
289772706315	DUMMY BAZEL MIRROR SWITCH THAI BEIGE	TATA spare parts
289773300101	ASSY DOOR INNER HANDLE LH TH BEIGE	TATA spare parts
289773300102	ASSY DOOR INNER HANDLE WITH LINK RH TH B	TATA spare parts
289781100103	FUEL LID CABLE SPACE CAB RHD	TATA spare parts
289781100114	ASSY ORVM WITH TURN IND HEATER LH RHD	TATA spare parts
289781100114BF	ASSY ORVM WITH TURN IND HEATER LH RHD	TATA spare parts
289781100114D3	ASSY ORVM WITH TURN IND HEATER LH RHD	TATA spare parts
289781100114DU	ASSY ORVM WITH TURN IND HEATER LH RHD	TATA spare parts
28978110011400000	ASSY ORVM WITH TURN IND HEATER LH RHD	TATA spare parts
289781100114000000	ASSY ORVM WITH TURN IND HEATER LH RHD AR	TATA spare parts
289781100114EY	ASSY ORVM WITH TURN IND HEATER LH RHD	TATA spare parts
289781100114FG	ASSY ORVM WITH TURN IND HEATER LH RHD MI	TATA spare parts
289781100114FP	ASSY ORVM WITH TURN IND HEATER LH RHD	TATA spare parts
289781100115	ASSY ORVM WITH TURN IND HEATER RH RHD	TATA spare parts
289781100115BF	ASSY ORVM WITH TURN IND HEATER RH RHD	TATA spare parts
289781100115D3	ASSY ORVM WITH TURN IND HEATER RH RHD	TATA spare parts
289781100115DU	ASSY ORVM WITH TURN IND HEATER RH RHD	TATA spare parts
28978110011500000	ASSY ORVM WITH TURN IND HEATER RH RHD	TATA spare parts
289781100115000000	ASSY ORVM WITH TURN IND HEATER RH RHD AR	TATA spare parts
289781100115EY	ASSY ORVM WITH TURN IND HEATER RH RHD	TATA spare parts
289781100115FG	ASSY ORVM WITH TURN IND HEATER RH RHD MI	TATA spare parts
289781100115FP	ASSY ORVM WITH TURN IND HEATER RH RHD	TATA spare parts
289781100116	ASSY ORVM WITH TURN INDICATOR HEATER LH	TATA spare parts
289781100116BF	ASSY ORVM WITH TURN INDICATOR HEATER LH	TATA spare parts
289781100116D3	ASSY ORVM WITH TURN INDICATOR HEATER LH	TATA spare parts
289781100116DU	ASSY ORVM WITH TURN INDICATOR HEATER LH	TATA spare parts
289781100116000000	ASSY ORVM WITH TURN INDICATOR HEATER LH	TATA spare parts
289781100116FG	ASSY ORVM WITH TURN INDICATOR HEATER LH	TATA spare parts
289781100116IQ	ASSY ORVM WITH TURN INDICATOR HEATER LH	TATA spare parts
289781100117	ASSY ORVM WITH TURN INDICATOR HEATER RH	TATA spare parts
289781100117BF	ASSY ORVM WITH TURN INDICATOR HEATER RH	TATA spare parts
289781100117D3	ASSY ORVM WITH TURN INDICATOR HEATER RH	TATA spare parts
289781100117DU	ASSY ORVM WITH TURN INDICATOR HEATER RH	TATA spare parts
289781100117000000	ASSY ORVM WITH TURN INDICATOR HEATER RH	TATA spare parts
289781100117FG	ASSY ORVM WITH TURN INDICATOR HEATER RH	TATA spare parts
289781100117IQ	ASSY ORVM WITH TURN INDICATOR HEATER RH	TATA spare parts

289781100122	ASSY GRILL - HIGH END	TATA spare parts
289781100125	ASSY IRVM W/O BASE BR35	TATA spare parts
289781100132	ORVM WITH TURN INDICATOR RHD LH	TATA spare parts
289781100132EO	BSF GREEN-ASSY ORVM WITH TURN INDICATOR	TATA spare parts
289781100133	ORVM WITH TURN INDICATOR RHD RH	TATA spare parts
289781100133EO	BSF GREEN-ASSY ORVM WITH TURN INDICATOR	TATA spare parts
289781100145BF	ASSY ORVM WITH TI/HT GULF LH LHD	TATA spare parts
289781100146BF	ASSY ORVM WITH TI HT GULF RH LHD	TATA spare parts
289781106309	ORVM INNER COVER ELE LH BR35	TATA spare parts
289781106310	ORVM INNER COVER ELE RH BR35	TATA spare parts
289781106311	ORVM INNER COVER MAN LH	TATA spare parts
289781106312	ORVM INNER COVER MAN RH	TATA spare parts
289781106314	COVER FUEL LID LEVER BKT RHD - BR35	TATA spare parts
289788506303	FINISHER GRILL LH - THAILAND	TATA spare parts
289788506303BF	FINISHER GRILL LH - THAILAND	TATA spare parts
289788506303D3	FINISHER GRILL LH - THAILAND	TATA spare parts
289788506303FG	FINISHER GRILL LH - THAILAND	TATA spare parts
289788506304	FINISHER GRILL RH - THAILAND	TATA spare parts
289788506304BF	FINISHER GRILL RH - THAILAND	TATA spare parts
289788506304D3	FINISHER GRILL RH - THAILAND	TATA spare parts
289788506304FG	FINISHER GRILL RH - THAILAND	TATA spare parts
289793400123	ASSY RSB COMPLETE FOLDABLE	TATA spare parts
289793400125	ASSY RSB COMPLETE FOLDABLE	TATA spare parts
289793400127	ASSY RSC COMPLETE FIXED	TATA spare parts
289793400129	ASSY RSC COMPLETE FIXED	TATA spare parts
289793406301	RUBBER STOPPER	TATA spare parts
289793406310	RUBBER STOPPER	TATA spare parts
289799008002	M10 FLANGE BOLT	TATA spare parts
289815400101	12V 75A ALT VAC PUMP 61D 6GR PULL L	TATA spare parts
289815400102	ALTERNATOR 12V 75A LIN BS6-PH2	TATA spare parts
289815400104	ALTERNATOR 75 A WITH SINGLE BIG BANJO	TATA spare parts
289815400105	ALTERNATOR 12V 75A 6PK W/O VP BS6	TATA spare parts
289815400106	STATOR ASSEMBLY BS6	TATA spare parts
289815400107	RECTIFIER BS6	TATA spare parts
289815400108	ALTERNATOR 12V 75A 6PK W/O VP BS6	TATA spare parts
289815400109	D E BRACKET ASSY BS6	TATA spare parts
289815400110	ROTOR BS6	TATA spare parts
289815400111	S R E BRACKET ASSY BS6	TATA spare parts
289815400112	REGULATOR ASSY. FINAL BS6	TATA spare parts
289815400113	FASTENERS & 4 FLANGE SCREW SUNDRIES	TATA spare parts
289815400114	BEARING ASSEMBLY KIT BS6	TATA spare parts
289815400115	TERMINAL BUSH KIT BS6	TATA spare parts
289815400116	DRIVE END SHIELD ASSY ALTERNATOR BS6-PH2	TATA spare parts
289815400117	ROTOR BS6-PH2	TATA spare parts
289815406301	COVER REAR BS6	TATA spare parts
289815407001	PULLEY BS6	TATA spare parts
289815407002	PULLEY BS6	TATA spare parts

289815409917	ROTOR ASSEMBLY	TATA spare parts
289815409918	117A ALTERNATOR WITH VACUUM PUMP	TATA spare parts
289816262001	INSTRUMENT CLUSTER INTERFACE HARDWARE BS	TATA spare parts
289824100106	HEAT SHIELD	TATA spare parts
289824100110	ENGINE MOUNT ASSY FRONT-RH BS6	TATA spare parts
289824100111	ENGINE MOUNT ASSY FRONT-LH BS6	TATA spare parts
289824200101	ENGINE MOUNT ASSY REAR	TATA spare parts
289829100101	ASSY CNTRL MTG BRKT WITH BRAKE & CLUTCH	TATA spare parts
289829100102	ASSY CONTROL MTG BRACKET	TATA spare parts
289829100103	ASSY CLUTCH PEDAL LEVER	TATA spare parts
289829100105	ASSY. CONTROL MTG. BKT.WELDED (BRAKE)	TATA spare parts
289829100106	ASSY. BRAKE PEDAL R.H.LEVER (5:1)	TATA spare parts
289829100107	ASSY. CLUTCH PEDAL LEVER	TATA spare parts
289829100108	ASSY CNTRL MTG BRKT WITH BRAKE & CLUTCH	TATA spare parts
289829100109	CLUTCH PIPE BS4	TATA spare parts
289829100110	ASSY CONTROL MTG BKT COMPLETE(BRAKE)RHD	TATA spare parts
289829100116	CLUTCH PEDAL ASSY WITH MTG BKT BS6	TATA spare parts
289829100117	LEVER ASSY CLUTCH PEDAL BS6	TATA spare parts
289829100128	CLUTCH PEDAL ASSY WITH PEDAL BOX BS6-PH2	TATA spare parts
289829100130	CLUTCH PIPE ASSY BS6-PH2	TATA spare parts
289829100132	ADAPTER ASSY	TATA spare parts
289829200102	ASSY. PEDAL LEVER (BRAKE R.H.D.)	TATA spare parts
289829200117	LEVER ASSY BRAKE PEDAL BS6	TATA spare parts
289829200118	BRAKE PEDAL ASSY WITH CONTROL MTG BKT BS	TATA spare parts
289829500101	BRACKET ASSY CLUTCH CONTROL MTG BS6	TATA spare parts
289829500102	BRACKET ASSY BOOSTER - BRAKE PEDAL MTG B	TATA spare parts
289829503308	BRACKET BRAKE PEDAL RETURN SPRING BS6	TATA spare parts
289830100101	ACCELERATOR CABLE ASSY	TATA spare parts
289830100104	ASSY. ACCL. ROD WITH BRACKET COMPLETE	TATA spare parts
289830100106	ACCELERATOR CABLE ASSY	TATA spare parts
289830103303	BRACKET ACCELERATOR CABLE MTG	TATA spare parts
289830104201	SWIVEL SPACER CLIP	TATA spare parts
289831000102	ASSY. FRAME 207DI FL/LB BS4	TATA spare parts
289831000104	ASSY. FRAME XENON RX WIDER TRACK BS1/3/4	TATA spare parts
289831000107	FRAME ASSY	TATA spare parts
289831000108	ASSY FRAME	TATA spare parts
289831000111	ASSY. FRAME XENON BS3/4	TATA spare parts
289831000114	FRAME ASSY	TATA spare parts
289831000121	ASSY FRAME 28 WB FOR XENON COMPACT 4X2	TATA spare parts
289831000123	FRAME ASSY	TATA spare parts
289831000125	FRAME ASSY	TATA spare parts
289831000129	FRAME ASSY BS6	TATA spare parts
289831000132	FRAME ASSY BS6	TATA spare parts
289831000133	FRAME ASSY BS6	TATA spare parts
289831000134	FRAME ASSY BS6	TATA spare parts
289831000135	FRAME ASSY BS6	TATA spare parts
289831000138	FRAME ASSY	TATA spare parts

289831000140	FRAME ASSY BS6	TATA spare parts
289831000151	FRAME ASSY BS6-PH2	TATA spare parts
289831000153	FRAME ASSY BS6-PH2	TATA spare parts
289831000154	FRAME ASSY BS6-PH2	TATA spare parts
289831000156	FRAME ASSY BS6-PH2	TATA spare parts
289831000159	FRAME ASSY BS6	TATA spare parts
289831000160	FRAME ASSY BS6	TATA spare parts
289831000162	FRAME ASSY BS6	TATA spare parts
289831007701	FRONT SKIRT	TATA spare parts
289831200106	ASSY TUBE (FOR GEAR SHIFT LEVER EXTN)	TATA spare parts
289831200107	ASSY.BODY MOUNTING BRACKET LH.	TATA spare parts
289831200108	ASSY.BODY MOUNTING BRACKET RH.	TATA spare parts
289831200112	ASSY. CROSS MEMBER (FRONT EXTENSION)	TATA spare parts
289831200156	CROSS MEMBER ASSY ENGINE MTG REAR BS6	TATA spare parts
289831200164	BRACKET ASSY BODY MTG FRONT-RH BS6	TATA spare parts
289831200168	BODY MTG ASSY BRACKET BS6	TATA spare parts
289831200180	CROSS MEMBER ASSY ENGINE MTG REAR BS6	TATA spare parts
289831200187	BRACKET ASSY ENGINE MTG REAR BS6	TATA spare parts
289831203307	BRACKET CROSS MEMBER MTG BS6	TATA spare parts
289831206913	CROSS MEMBER BUMPER MTG.	TATA spare parts
289831206914	CROSS MEMBER STEERING MOUNT	TATA spare parts
289831206922	CROSS MEMBER ENGINE	TATA spare parts
289831240103	BRACKET ASSY GEAR BOX MTG BS6	TATA spare parts
289831500107	SIDE PLATE TOWING ASSY BS6	TATA spare parts
289831509904	TOW HOOK BS6	TATA spare parts
289831700109	BEAM ASSY RUPD BS6	TATA spare parts
289831700110	BRACKET ASSY RUPD MTG LH BS6	TATA spare parts
289831700111	BRACKET ASSY RUPD MTG RH BS6	TATA spare parts
289831890102	BRACKET ASSY CAB MTG FRONT-LH BS6	TATA spare parts
289831890105	BRACKET ASSY LOAD BODY MTG BS6	TATA spare parts
289831900101	SUPPORT BRACKET ASSY RH	TATA spare parts
289831906301	STONE GUARD BS3/4	TATA spare parts
289832000101	ASSY. SUSPENSION KIT FOR 207 DI RX VEH.	TATA spare parts
289832000102	ASSY. SUSP. KIT 207DIRX NORMAL TRACK VEH	TATA spare parts
289832000103	ASSY. SUSPN. KIT FOR 207 DI RX PS	TATA spare parts
289832100105	ASSY. FRONT LEAF SPRING	TATA spare parts
289832100114	ASSY. FRONT LEAF SPRING ( 8KG)	TATA spare parts
289832100126	BUMP STOPPER FRONT	TATA spare parts
289832100130	SADDLE ASSY FRONT	TATA spare parts
289832100133	ASSLY. FRONT LEAF SPRING (PARABOLIC)	TATA spare parts
289832100137	BUMP STOPPER FRONT	TATA spare parts
289832100143	LEAF SPRING ASSY FRONT	TATA spare parts
289832100149	CLAMP ASSY	TATA spare parts
289832100150	CLAMP ASSY	TATA spare parts
289832100152	MOUNTING PIN ASSY	TATA spare parts
289832100155	SHACKLE ASSY	TATA spare parts
289832100158	LEAF SPRING ASSY FRONT	TATA spare parts

289832100159	CLAMP ASSY	TATA spare parts
289832100160	CLAMP ASSY	TATA spare parts
289832100161	RUBBER BUSH ASSY	TATA spare parts
289832100163	GUIDE PLATE ASSY LH	TATA spare parts
289832100164	GUIDE PLATE ASSY	TATA spare parts
289832100165	GUIDE PLATE ASSY	TATA spare parts
289832100168	LEAF SPRING ASSY FRONT BS6	TATA spare parts
289832100169	GUIDE PLATE ASSY RH	TATA spare parts
289832100170	GUIDE PLATE ASSY LH	TATA spare parts
289832100188	LEAF SPRING ASSY FRONT BS6	TATA spare parts
289832100190	GUIDE PLATE ASSY LH BS6	TATA spare parts
289832100191	GUIDE PLATE ASSY RH BS6	TATA spare parts
289832103304	SADDLE BRACKET BS6-PH2	TATA spare parts
289832103501	SLEEVE BS6	TATA spare parts
289832103503	BOSS BS6	TATA spare parts
289832104201	U CLAMP FRONT	TATA spare parts
289832104206	U-BOLT	TATA spare parts
289832106501	CENTRE BOLT NUT	TATA spare parts
289832106704	SPRING PIN	TATA spare parts
289832107104	FIRST LEAF	TATA spare parts
289832107105	SECOND LEAF	TATA spare parts
289832107106	THIRD LEAF	TATA spare parts
289832107107	FOURTH LEAF	TATA spare parts
289832107108	FIFTH LEAF	TATA spare parts
289832107142	2ND LEAF	TATA spare parts
289832107143	3RD LEAF	TATA spare parts
289832107144	4TH LEAF	TATA spare parts
289832107145	5TH LEAF	TATA spare parts
289832107146	6TH LEAF	TATA spare parts
289832107149	1ST LEAF	TATA spare parts
289832107151	1ST LEAF	TATA spare parts
289832107152	2ND LEAF	TATA spare parts
289832107153	3RD LEAF	TATA spare parts
289832107154	4TH LEAF	TATA spare parts
289832107155	5TH LEAF	TATA spare parts
289832107156	6TH LEAF	TATA spare parts
289832107160	1STLEAF BS6	TATA spare parts
289832107165	1ST LEAF BS6	TATA spare parts
289832107166	2ND LEAF BS6	TATA spare parts
289832107167	3RD LEAF BS6	TATA spare parts
289832107168	4TH LEAF BS6	TATA spare parts
289832107171	5TH LEAF BS6	TATA spare parts
289832107172	6TH LEAF BS6	TATA spare parts
289832107173	CASTER PLATE BS6	TATA spare parts
289832107402	RIVET	TATA spare parts
289832107707	RUBBER BUSH	TATA spare parts
289832108204	CLAMP	TATA spare parts

289832108220	SHACKLE FRONT SPRING	TATA spare parts
289832108301	CENTRE PAD	TATA spare parts
289832108401	SLEEVE BS6	TATA spare parts
289832108402	SLEEVE BS6	TATA spare parts
289832300112	ASSY SHOCK ABSORBER FRONT BS4	TATA spare parts
289832400102	ASSY. REAR LEAF SPRING	TATA spare parts
289832400103	ASSY. REAR LEAF SPRING JAI-14KG/MM 207RX	TATA spare parts
289832400108	ASSY. REAR LEAF SPRING	TATA spare parts
289832400127	SHACKLE ASSY REAR SPRING	TATA spare parts
289832400130	BUMP STOPPER REAR BS4	TATA spare parts
289832400135	BRACKET ASSY SPRING HANGER REAR	TATA spare parts
289832400138	RUBBER BUSHING ASSY BS4	TATA spare parts
289832400139	1ST LEAF ASSY WITH BUSH	TATA spare parts
289832400141	LEAF SPRING ASSY REAR	TATA spare parts
289832400142	LEAF SPRING ASSY REAR	TATA spare parts
289832400145	1ST LEAF ASSY WITH BUSH	TATA spare parts
289832400146	BUMP STOPPER ASSY REAR BS6	TATA spare parts
289832400153	BRACKET ASSY REAR SHACKLE-LH BS6	TATA spare parts
289832400154	LEAF SPRING ASSY REAR BS6	TATA spare parts
289832400155	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
289832400156	CLAMP ASSY BS6	TATA spare parts
289832400159	BRACKET ASSY REAR SHACKLE-RH BS6	TATA spare parts
289832400194	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
289832400197	LEAF SPRING ASSY REAR BS6	TATA spare parts
289832401602	ASSY. REAR LEAF SPRING (15 KG/MM)	TATA spare parts
289832401605	ASSY REAR LEAF SPRING	TATA spare parts
289832403201	CENTER BOLT	TATA spare parts
289832403206	CENTER BOLT BS6	TATA spare parts
289832404204	U-CLAMP REAR SPRING	TATA spare parts
289832404207	CLAMP REAR LEAF SPRING	TATA spare parts
289832404209	CLAMP BS6	TATA spare parts
289832404210	U-BOLT REAR	TATA spare parts
289832404218	CLINCH CLAMP REAR SPRING BS6	TATA spare parts
289832404220	CLAMP BS6	TATA spare parts
289832405101	SADDLE SPRING REAR LH	TATA spare parts
289832405102	SADDLE SPRING REAR RH	TATA spare parts
289832406701	SPRING PIN	TATA spare parts
289832406907	FERRULE BS6	TATA spare parts
289832407102	FIRST LEAF(WITHOUT BUSH)	TATA spare parts
289832407103	SECOND LEAF	TATA spare parts
289832407104	THIRD LEAF	TATA spare parts
289832407105	FOURTH LEAF	TATA spare parts
289832407106	FIFTH LEAF	TATA spare parts
289832407107	SIXTH LEAF	TATA spare parts
289832407108	SEVENTH LEAF	TATA spare parts
289832407109	8TH LEAF	TATA spare parts
289832407110	NINETH LEAF	TATA spare parts

289832407111	TENTH LEAF	TATA spare parts
289832407112	FIRST LEAF. WITHOUT BUSH	TATA spare parts
289832407113	SECOND LEAF	TATA spare parts
289832407114	THIRD LEAF	TATA spare parts
289832407115	FOURTH LEAF	TATA spare parts
289832407116	FIFTH LEAF	TATA spare parts
289832407117	SIXTH LEAF	TATA spare parts
289832407118	SEVENTH LEAF	TATA spare parts
289832407119	EIGHTH LEAF	TATA spare parts
289832407120	NINTH LEAF	TATA spare parts
289832407121	TENTH LEAF	TATA spare parts
289832407122	ELEVENTH LEAF	TATA spare parts
289832407141	3RD LEAF	TATA spare parts
289832407142	4TH LEAF	TATA spare parts
289832407143	5TH LEAF	TATA spare parts
289832407144	6TH LEAF	TATA spare parts
289832407145	7TH LEAF	TATA spare parts
289832407146	8TH LEAF	TATA spare parts
289832407147	9TH LEAF	TATA spare parts
289832407165	2ND LEAF	TATA spare parts
289832407166	3RD LEAF	TATA spare parts
289832407167	4TH LEAF	TATA spare parts
289832407168	5TH LEAF	TATA spare parts
289832407169	6TH LEAF	TATA spare parts
289832407170	7TH LEAF	TATA spare parts
289832407171	CLAMP REAR SPRING	TATA spare parts
289832407172	CLAMP LEAF SPRING	TATA spare parts
289832407175	2ND LEAF	TATA spare parts
289832407188	1ST LEAF BS6-PH2	TATA spare parts
289832407191	2ND LEAF BS6	TATA spare parts
289832407192	3RD LEAF BS6	TATA spare parts
289832407193	4TH LEAF BS6	TATA spare parts
289832407194	5TH LEAF BS6	TATA spare parts
289832407195	6TH LEAF BS6	TATA spare parts
289832407196	7TH LEAF BS6	TATA spare parts
289832407197	8TH LEAF BS6	TATA spare parts
289832407198	9TH LEAF BS6	TATA spare parts
289832407404	RIVET SPRING CLIP BS6	TATA spare parts
289832407705	PLASTIC INSERT BS6	TATA spare parts
289832407708	TIP INSERT 2ND LEAF BS6	TATA spare parts
289832407712	TIP INSERT 3RD LEAF BS6	TATA spare parts
289832408205	CLAMP(CLAMP SEC 25X6 S=76 H=50 BENDING)	TATA spare parts
289832408602	SPACER BS6	TATA spare parts
289832409202	WASHER	TATA spare parts
289832409204	SPHERICAL WASHER BS6	TATA spare parts
289832410125	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
289832410128	PARABOLIC LEAF SPRING ASSY REAR BS6	TATA spare parts

289832410129	PARABOLIC LEAF SPRING ASSY BS6	TATA spare parts
289832413201	HEX BOLT BS6	TATA spare parts
289832417103	1ST LEAF BS6	TATA spare parts
289832417107	2ND LEAF BS6	TATA spare parts
289832417108	3RD LEAF BS6	TATA spare parts
289832417109	4TH LEAF BS6	TATA spare parts
289832417110	5TH LEAF BS6	TATA spare parts
289832417111	6TH LEAF BS6	TATA spare parts
289832417112	7TH LEAF BS6	TATA spare parts
289832417113	8TH LEAF BS6	TATA spare parts
289832417114	9TH LEAF BS6	TATA spare parts
289832417132	3RD LEAF BS6	TATA spare parts
289832417141	PACKING PLATE BS6	TATA spare parts
289832417142	2ND LEAF BS6	TATA spare parts
289832417145	1ST LEAF BS6	TATA spare parts
289832418601	CENTER PAD REAR SPRING BS6	TATA spare parts
289832600102	SHOCK ABSORBER ASSY REAR BS4	TATA spare parts
289832800105	LINK ASSY ANTI ROLL BAR FRONT	TATA spare parts
289832800106	ANTI ROLL BAR ASSY COMPL FRONT	TATA spare parts
289832800108	ANTI ROLL BAR ASSY COMPL FRONT	TATA spare parts
289832800110	BRACKET ASSY ANTI ROLL BAR MTG	TATA spare parts
289832800112	ANTI ROLL BAR ASSY WITH CRIMPED WASHER B	TATA spare parts
289832800113	ANTI ROLL BAR ASSY FRONT BS6	TATA spare parts
289832800117	ANTI ROLL BAR ASSY FRONT BS6	TATA spare parts
289832804201	U CLAMP (FRONT ARB)	TATA spare parts
289832807702	RUBBER BUSH	TATA spare parts
289832808207	CLAMP ANTI ROLL BAR MTG	TATA spare parts
289832808601	SPACER	TATA spare parts
289832808803	STUD	TATA spare parts
289833000117	FRONT AXLE ASSY	TATA spare parts
289833000118	FRONT AXLE ASSY	TATA spare parts
289833000121	FRONT AXLE ASSY	TATA spare parts
289833000125	FRONT AXLE ASSY BS6	TATA spare parts
289833000126	FRONT AXLE ASSY RH BS6	TATA spare parts
289833000127	FRONT AXLE ASSY LH BS6	TATA spare parts
289833100102	FRONT AXLE TUBE ASSY	TATA spare parts
289833105103	FRONT YOKE AXLE TUBE BS6	TATA spare parts
289833106503	AXLE BEAM FRONT ADJUSTABLE NUT	TATA spare parts
289833106504	AXLE BEAM FRONT SLOTTED NUT M18X1.5	TATA spare parts
289833106505	NYLOC NUT M18X1.5	TATA spare parts
289833106904	FRONT AXLE TUBE	TATA spare parts
289833200102	BALL JOINT STUB AXLE BS4	TATA spare parts
289833200103	STUB AXLE ASSY WITH BUSH LH	TATA spare parts
289833200104	STUB AXLE ASSY WITH BUSH RH	TATA spare parts
289833203709	STUB AXLE RHBS6	TATA spare parts
289833203710	STUB AXLE LHBS6	TATA spare parts
289833205107	STUB AXLE - LH	TATA spare parts



289833205108	STUB AXLE - RH	TATA spare parts
289833205111	STUB AXLE -LH BS4	TATA spare parts
289833205112	STUB AXLE - RH BS4	TATA spare parts
289833205116	STUB AXLE RH	TATA spare parts
289833205117	STUB AXLE LH	TATA spare parts
289833207903	STUB AXLE SPINDLE BS4	TATA spare parts
289833207906	SPINDLE STUB AXLE	TATA spare parts
289833207907	STUB AXLE SPINDLE BS6	TATA spare parts
289833400106	HUB ASSY WITH WHEEL BOLT BS6	TATA spare parts
289833403703	HUB FRONT	TATA spare parts
289840100106	ASSY WHEEL RIM 5.5J X 15	TATA spare parts
289840100120	ASSY WHEEL RIM 5.5J X 16 (SILVER)	TATA spare parts
289840100125	WHEEL RIM ASSY BS6	TATA spare parts
289840100127	WHEEL RIM ASSY BS6	TATA spare parts
289840109907	TYRE	TATA spare parts
289840109908	TUBE	TATA spare parts
289840109909	TYRE	TATA spare parts
289840109910	TUBE	TATA spare parts
289840109916	TYRE FRONT	TATA spare parts
289840300102	SUPPORT ASSY SPARE WHEEL MTG	TATA spare parts
289840300105	TUBE ASSY WITH STOPPER	TATA spare parts
289840300107	HOLDING BRACKET ASSY	TATA spare parts
289840300110	TUBE ASSY SPARE WHEEL CARRIER BS6	TATA spare parts
289840300111	SUPPORT ASSY SPARE WHEEL MTG BS6	TATA spare parts
289840300112	HOLDING BRACKET ASSY BS6	TATA spare parts
289840303203	HEX BOLT	TATA spare parts
289840306501	WHEEL NUT SPARE WHEEL (A/F 19)	TATA spare parts
289840306701	PIN BS6	TATA spare parts
289840307101	HOLDING PLATE	TATA spare parts
289840307103	HOLDING PLATE BS6	TATA spare parts
289841100102	ASSY.PROPELLER SHAFT REAR	TATA spare parts
289841100105	PROPELLER SHAFT ASSY	TATA spare parts
289841100107	ASSY.SINGLE PIECE PROPELLER SHAFT	TATA spare parts
289841100108	PROPELLER SHAFT ASSY REAR	TATA spare parts
289841100109	PROPELLER SHAFT ASSY	TATA spare parts
289841100110	PROPELLER SHAFT ASSY BS6	TATA spare parts
289841100113	CENTER BEARING ASSY BS6	TATA spare parts
289841100118	PROPELLER SHAFT ASSY MONOTRON BS6-PH2	TATA spare parts
289841100119	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
289841110101	SLIP YOKE ASSY	TATA spare parts
289841110102	SLIP YOKE ASSY BS4	TATA spare parts
289841110103	DUST COVER	TATA spare parts
289841110104	SLIP YOKE ASSY	TATA spare parts
289841113101	CENTER BEARING BS4	TATA spare parts
289841117701	RUBBER CENTER BEARING BS4	TATA spare parts
289841117702	DUST SEAL BS4	TATA spare parts
289841118201	BEARING RETAINER	TATA spare parts

289841118202	RETAINER CAP	TATA spare parts
289841118203	BRACKET CENTER BEARING BS4	TATA spare parts
289841118204	FLINGER	TATA spare parts
289841118205	LOCATING CLIP CENTER BEARING	TATA spare parts
289841118206	BRACKET CENTER BRG MTG TOP BS6	TATA spare parts
289841119901	FLANGE YOKE BS4	TATA spare parts
289841120101	ASSY.PROPELLER SHAFT REAR	TATA spare parts
289842100101	LH CALLIPER	TATA spare parts
289842100102	RH CALLIPER	TATA spare parts
289842100103	CALIPER ASSY FRONT-LH BS6	TATA spare parts
289842100104	CALIPER ASSY FRONT-RH BS6	TATA spare parts
289842100109	KIT-PAD ASSY BS6	TATA spare parts
289842100110	KIT-PAD ASSY BS6	TATA spare parts
289842100113	KIT-SLIDING PIN BS6	TATA spare parts
289842100115	MINOR KIT-CALIPER BS6	TATA spare parts
289842100116	MINOR KIT-CALIPER BS6	TATA spare parts
289842100117	KIT-CARRIER ASSY LH BS6	TATA spare parts
289842100118	KIT-CARRIER ASSY BS6	TATA spare parts
289842100119	MAJOR KIT-CALIPER BS6	TATA spare parts
289842100120	MAJOR KIT-CALIPER BS6	TATA spare parts
289842100123	KIT-BRAKE PAD SPRING BS6	TATA spare parts
289842100125	KIT-CARRIER ASSY RH BS6	TATA spare parts
289842100126	CALIPER ASSY WITH SHIM LH BS6-PH2	TATA spare parts
289842100127	CALIPER ASSY WITH SHIM RH BS6-PH2	TATA spare parts
289842103701	VENTILATED DISC	TATA spare parts
289842103702	BRAKE DISC (VENTILATED) BS2/4	TATA spare parts
289842300101	BRAKE DRUM ASSY (LH)	TATA spare parts
289842300102	BRAKE DRUM ASSY (RH)	TATA spare parts
289842300105	DRUM BRAKE ASSY REAR-LH	TATA spare parts
289842300106	DRUM BRAKE ASSY REAR-RH	TATA spare parts
289842303701	BRAKE DRUM BS6	TATA spare parts
289842700112	PARKING BRAKE CABLE ASSY REAR	TATA spare parts
289842700113	PARKING BRAKE CABLE ASSY REAR	TATA spare parts
289842700114	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
289842700119	BRACKET ASSY HAND BRAKE LEVER	TATA spare parts
289842700121	PARKING BRAKE CABLE ASSY REAR	TATA spare parts
289842700123	PARKING BRAKE CABLE ASSY REAR	TATA spare parts
289842700127	PARKING BRAKE CABLE ASSY FRONT BS6	TATA spare parts
289842700128	PARKING BRAKE CABLE ASSY REAR BS6	TATA spare parts
289842700130	REAR PARKING BRAKE CABLE LH	TATA spare parts
289842700131	REAR PARKING BRAKE CABLE RH	TATA spare parts
289842700132	FRONT PARKING BRAKES CABLE FRONT	TATA spare parts
289842700134	ASSY PARKING BRAKE CABLE FRONT	TATA spare parts
289842700140	PARKING BRAKE CABLE ASSY REAR BS6	TATA spare parts
289842700144	BRACKET ASSY FRONT CABLE MTG	TATA spare parts
289842700145	BRACKET ASSY CABLE MTG REAR	TATA spare parts
289842700149	PARKING BRAKE CABLE ASSY FRONT BS6	TATA spare parts

289842700154	PARKING BRAKE CABLE ASSY REAR BS6	TATA spare parts
289842700165	PARKING BRAKE CABLE ASSY REAR BS6-PH2	TATA spare parts
289842700166	PARKING BRAKE CABLE ASSY REAR BS6-PH2	TATA spare parts
289842700173	PARKING BRAKE CABLE ASSY REAR BS6	TATA spare parts
289842700175	PARKING BRAKE CABLE ASSY REAR BS6-PH2	TATA spare parts
289842703303	SUPPORT PARKING BRAKE CABLE MTG FRONT	TATA spare parts
289842990101	AUTO ADJUSTER ASSY KIT BS6	TATA spare parts
289842990102	AUTO ADJUSTER ASSY (LH)	TATA spare parts
289842990103	AUTO ADJUSTER ASSY (RH)	TATA spare parts
289842990108	WHEEL CYLINDER ASSY	TATA spare parts
289842990112	KIT-BRAKE SHOE WITH LINER (LH) BS3/4/6	TATA spare parts
289842990113	KIT-BRAKE SHOE WITH LINER (RH) BS3/4/6	TATA spare parts
289842990114	ADJUSTER ASSY RH	TATA spare parts
289842990115	ADJUSTER ASSY LH	TATA spare parts
289842990117	KIT-BRAKE (MINOR KIT CALIPER)	TATA spare parts
289842990118	KIT-BRAKE (MAJOR KIT CALIPER)	TATA spare parts
289842990119	KIT-BRAKE PAD	TATA spare parts
289842990125	WHEEL CYLINDER ASSY	TATA spare parts
289842990126	WHEEL CYLINDER KIT (MAJOR) BS4	TATA spare parts
289842990127	WHEEL CYLINDER KIT (MINOR) BS4	TATA spare parts
289842993701	WHEEL CYLINDER BODY	TATA spare parts
289842998703	SPRING SHOE RETURN	TATA spare parts
289843500101	ASSY.VACUUM HOSE	TATA spare parts
289843500102	ASSY.VACUUM HOSE	TATA spare parts
289843500105	VACUUM HOSE ASSY	TATA spare parts
289843500106	BOOSTER ASSY	TATA spare parts
289843500107	ASSY VACUUM HOSE	TATA spare parts
289843500110	BOOSTER ASSY WITH TMC & RESERVOIR BS6-PH	TATA spare parts
289843500114	BOOSTER ASSY WITH TMC & RESERVOIR	TATA spare parts
289843500117	BOOSTER ASSY WITH CLUTCH PORT BS6	TATA spare parts
289843500118	VACUUM HOSE ASSY BS6	TATA spare parts
289843500126	VACUUM HOSE ASSY	TATA spare parts
289843800106	ASSY.TUBE	TATA spare parts
289843800107	ASSY.TUBE	TATA spare parts
289843800112	BRACKET ABS MODULATOR MTG	TATA spare parts
289843800114	TUBE ASSY MODULATOR TO FRONT-RH	TATA spare parts
289843800115	TUBE ASSY ADAPTER TO REAR BRAKE HOSE LH	TATA spare parts
289843800116	TUBE ASSY MODULATOR TO REAR-LH	TATA spare parts
289843800117	TUBE ASSY MODULATOR TO REAR-RH	TATA spare parts
289843800118	BRAKE TUBE ASSY TMC PRIMARY TO MV MC1	TATA spare parts
289843800119	TUBE ASSY REAR HOSE TO BRAKE ASSY RH	TATA spare parts
289843800120	TUBE ASSY HOSE TO REAR BRAKE ASSY LH	TATA spare parts
289843800135	BRACKET- BRAKE CABLE	TATA spare parts
289843800136	TUBE ASSY TMC PRIMARY TO ADAPTER	TATA spare parts
289843800137	TUBE ASSY TMC SEC. TO FR BRK HOSE LH	TATA spare parts
289843800138	TUBE ASSY TMC SEC. TO FR BRK HOSE RH	TATA spare parts
289843800139	TUBE ASSY ADAPTER TO LCRV INLET REAR	TATA spare parts

289843800141	TUBE ASSY REAR-RH	TATA spare parts
289843800144	TUBE ASSY CONNECTOR TO REAR BRAKE LH	TATA spare parts
289843800145	TUBE ASSY CONNECTOR TO REAR BRAKE RH	TATA spare parts
289843800146	TUBE ASSY TMC SECONDARY TO FRONT LH	TATA spare parts
289843800147	TUBE ASSY TMC SECONDARY TO FRONT RH	TATA spare parts
289843800148	TUBE ASSY TMC PRIMARY TO ADAPTER	TATA spare parts
289843800153	TUBE ASSY REAR-LH	TATA spare parts
289843800155	BRACKET-BRAKE CABLE BS6	TATA spare parts
289843800163	TUBE ASSY; ADAPTER TO REAR BRAKE HOSE	TATA spare parts
289843800164	TUBE ASSY T CONNECTOR TO RR LH BR ASSY	TATA spare parts
289843800165	TUBE ASSY T CONNECTOR TO RR RH BR ASSY	TATA spare parts
289843800168	TUBE ASSY TMC SEC. TO FRONT LH	TATA spare parts
289843800169	TUBE ASSY TMC SEC. TO FRONT RH	TATA spare parts
289843800170	TUBE ASSY TMC PRIMARY TO ADAPTER	TATA spare parts
289843800176	TUBE ASSY TMC PRIMARY TO ADAPTER	TATA spare parts
289843800180	TUBE ASSY,REAR-LH	TATA spare parts
289843800181	TUBE ASSY,REAR-RH	TATA spare parts
289843800182	TUBE ASSY TMC PRIMARY TO ADAPTER	TATA spare parts
289843800183	TUBE ASSY TMC SECONDARY TO FRONT LH	TATA spare parts
289843800184	TUBE ASSY TMC SECONDARY TO FRONT RH	TATA spare parts
289843800185	TUBE ASSY ADAPTER TO REAR HOSE	TATA spare parts
289843800188	BRACKET ASSY COMBINATION CLAMP	TATA spare parts
289843800189	TUBE ASSY TMC SECONDARY TO T-CONN	TATA spare parts
289843800192	TUBE ASSY ADAPTER TO REAR HOSE	TATA spare parts
289843800193	TUBE ASSY REAR LH	TATA spare parts
289843800194	TUBE ASSY REAR RH	TATA spare parts
289843800197	BRAKE HOSE FRONT	TATA spare parts
289843800198	HOSE FRONT	TATA spare parts
289843800203	TUBE ASSY ADAPTER TO REAR BRAKE HOSE RH	TATA spare parts
289843800206	TUBE ASSY MODULATOR TO FRONT-LH	TATA spare parts
289843800207	BRAKE TUBE ASSY TMC SECONDARY TO MV MC2	TATA spare parts
289843800211	TUBE ASSY TMC SECONDARY TO T-CONN BS6	TATA spare parts
289843800212	TUBE ASSY TMC PRIMARY TO ADAPTER BS6-PH2	TATA spare parts
289843803304	BRACKET BRAKE HOSE CLAMPING	TATA spare parts
289843803306	BRACKET FIREWALL MTG	TATA spare parts
289843803311	BRACKET SENSOR CABLE MTG BS6	TATA spare parts
289843804201	CLAMP BUNDY TUBE SUPPORT	TATA spare parts
289843810101	ASSY.TUBE	TATA spare parts
289843810102	ASSY.TUBE	TATA spare parts
289843810106	ASSY.TUBE	TATA spare parts
289843810107	ASSY.TUBE	TATA spare parts
289843810109	ASSY TUBE	TATA spare parts
289843810110	ASSY TUBE	TATA spare parts
289843810111	ASSY BRAKE PIPE BOOSTER PRIMARY TO REAR	TATA spare parts
289843810112	ASSY TUBE	TATA spare parts
289843810113	ASSY TUBE	TATA spare parts
289843810114	ASSY TUBE	TATA spare parts

289843990101	BOOSTER ASSY BS6	TATA spare parts
289843990102	MASTER CYLINDER ASSY WITH RESERVOIR BS6-	TATA spare parts
289843990103	MASTER CYLINDER ASSY WITHOUT RESERVIOR B	TATA spare parts
289843990104	MASTER CYLINDER ASSY WITH RESERVIORY BS6	TATA spare parts
289843990105	KIT-SERVO UNIT BS6	TATA spare parts
289843990106	MAJOR KIT-MASTER CYLINDER BS6	TATA spare parts
289846000101	SECTOR SHAFT ASSY	TATA spare parts
289846000102	PISTON ASSY	TATA spare parts
289846000110	HOUSING ASSY	TATA spare parts
289846000117	TIE ROD ASSY	TATA spare parts
289846000118	DRAG LINK ASSY	TATA spare parts
289846100109	STEERING COLUMN ASSY BS6	TATA spare parts
289846100110	STEERING COLUMN ASSY BS6	TATA spare parts
289846100133	INTERMEDIATE SHAFT ASSY BS6	TATA spare parts
289846100134	STEERING COLUMN ASSY UPPER BS6	TATA spare parts
289846100135	INTERMEDIATE SHAFT ASSY STG COLUMN BS6	TATA spare parts
289846107701	RUBBER BELLOW BS6	TATA spare parts
289846200103	ASSY. SLEEVE	TATA spare parts
289846200104	ASSY.LOWER INTERMEDIATE SHAFT	TATA spare parts
289846200111	STEERING I SHAFT (POWER)	TATA spare parts
289846201601	ASSY. INTERMEDIATE SHAFT	TATA spare parts
289846207702	RUBBER BELLOW	TATA spare parts
289846207903	STEERING SPINDLE (MALE PART)	TATA spare parts
289846306004	PITMAN ARM	TATA spare parts
289846600104	ASSY RESERVOIR MOUNTING BRACKET	TATA spare parts
289846600106	ASSLY RESERVOIR MOUNTING BRACKET	TATA spare parts
289846600115	POWER STEERING GEAR ASSY	TATA spare parts
289846600117	BRACKET ASSY	TATA spare parts
289846600120	GEAR BOX ASSY (MECHANICAL)	TATA spare parts
289846600122	CLAMP SUB ASSY BS6	TATA spare parts
289846600123	POWER STEERING GEAR ASSY	TATA spare parts
289846600125	GEAR BOX ASSY (BOX SUB ASSEMBLY)	TATA spare parts
289846600126	WORM & NUT ASSY	TATA spare parts
289846600127	COVER PLATE ASSY	TATA spare parts
289846600128	BEARING SUB ASSEMBLY	TATA spare parts
289846600129	ASSY. DRAG LINK BS1/2/3/4	TATA spare parts
289846600130	TIE ROD ASSY	TATA spare parts
289846600131	BALL JOINT ASSY - RH	TATA spare parts
289846600132	BALL JOINT ASSY - LH	TATA spare parts
289846600133	BALL JOINT ASSY - RH	TATA spare parts
289846600134	DRAG LINK ASSY	TATA spare parts
289846600135	ASSY. TIE ROD BS3/4/6	TATA spare parts
289846600140	CLAMP ASSY	TATA spare parts
289846600143	RESERVOIR ASSY WITH BRACKET POWER STG	TATA spare parts
289846600145	POWER STEERING PUMP ASSY BS6	TATA spare parts
289846600147	TIE ROD ASSY	TATA spare parts
289846600148	BRACKET ASSY RESERVOIR MTG	TATA spare parts

289846600151	BRACKET ASSY RESERVOIR MTG	TATA spare parts
289846600152	POWER STEERING PUMP ASSY	TATA spare parts
289846600153	HOUSING ASSY BS6	TATA spare parts
289846600155	ROLLER SHAFT AND RACK ASSY BS6	TATA spare parts
289846600156	WORM & VALVE HSG ASSY BS6	TATA spare parts
289846600161	UNIVERSAL JOINT ASSY BS6	TATA spare parts
289846600162	RACK - PINION ASSY POWER STG BS6	TATA spare parts
289846600168	FEED PIPE ASSY LONG BS6	TATA spare parts
289846600170	FEED PIPE ASSY SHORT BS6	TATA spare parts
289846603201	BOLT M8	TATA spare parts
289846603401	GEAR BOX ASSY (BUSH)	TATA spare parts
289846603402	BUSH COVER PLATE	TATA spare parts
289846603601	STRAINER	TATA spare parts
289846604801	DOWEL PIN	TATA spare parts
289846605101	U-BOLT (FOR STG. DAMPER MTG	TATA spare parts
289846605102	SUPPORT CLAMP (FOR STG. DAMPER MTG.)	TATA spare parts
289846605105	DROP ARM	TATA spare parts
289846606506	LOCK NUT	TATA spare parts
289846606507	MAIN NUT ROLLER	TATA spare parts
289846606508	LOCK NUT	TATA spare parts
289846606803	CONNECTOR PRESSURE PORT BS6	TATA spare parts
289846607804	OIL SEAL	TATA spare parts
289846607901	ROCKER SHAFT	TATA spare parts
289846608001	ADJUSTING SCREW	TATA spare parts
289846608002	SCREW PLUG	TATA spare parts
289846608202	BRACKET POWER STEERING RESERVOIR	TATA spare parts
289846608204	BRACKET POWER STRG. RESERVOIR	TATA spare parts
289846800108	ASSY. RETURN LINE(G/BOX TO RESERVOIR)	TATA spare parts
289846800112	ASSY.HIGH PR. LINE(PUMP TO STG.G/BOX)	TATA spare parts
289846800115	RETURN LINE	TATA spare parts
289846800116	HIGH PRESSURE LINE	TATA spare parts
289846800121	HIGH PRESSURE LINE ASSY	TATA spare parts
289846800123	RETURN LINE ASSY GEAR BOX TO RESERVOIR	TATA spare parts
289846800124	SUCTION LINE ASSY	TATA spare parts
289846800125	HIGH PRESSURE LINE ASSY BS6	TATA spare parts
289846800126	RETURN LINE ASSY	TATA spare parts
289846800131	HIGH PRESSURE LINE ASSY BS6	TATA spare parts
289846800132	RETURN LINE ASSY POWER STG BS6	TATA spare parts
289846800133	RETURN LINE ASSY BS6	TATA spare parts
289846800134	HIGH PRESSURE LINE ASSY BS6	TATA spare parts
289846800136	SUCTION LINE ASSY BS6	TATA spare parts
289846805804	SUCTION HOSE (RESERVOIR TO PUMP)	TATA spare parts
289846805807	SUCTION HOSE (RESERVOIR TO PUMP)	TATA spare parts
289846805810	RETURN LINE (GEAR BOX TO RESERVOIR)	TATA spare parts
289846805812	SUCTION LINE	TATA spare parts
289846805814	SUCTION HOSE RESERVOIR TO PUMP	TATA spare parts
289846900104	DRAG LINK ASSY BS6	TATA spare parts

289846990103	UNIVERSAL JOINT ASSY BS6	TATA spare parts
289846990107	BALL JOINT ASSY	TATA spare parts
289846990113	BOWL ASSY	TATA spare parts
289846990117	KIT - MAJOR SEAL BS6	TATA spare parts
289846990121	KIT-HOUSING ASSY BS6	TATA spare parts
289846990126	KIT-BALL JOINT BS6	TATA spare parts
289846990127	KIT-BELLOW BS6	TATA spare parts
289846999201	TAB WASHER	TATA spare parts
289847100112	BRKT ASSY FUEL FILLER NECK MTG BS6-PH2	TATA spare parts
289847100113	BRACKET ASSY FUEL FILTER MTG	TATA spare parts
289847100114	FUEL TANK ASSY BS6-PH2	TATA spare parts
289847107702	HOSE (FUEL FILLING)	TATA spare parts
289847600102	ASSY. FUEL LINE-CHASSIS SIDE	TATA spare parts
289847600106	ASSY.SUCTION LINE(FUEL FILTER-FIP)	TATA spare parts
289847600109	ASSY.FUEL LINE (ENGINE SIDE)	TATA spare parts
289847600121	ASSY.DELIVERY LINE(FIREWALL-PRIMINGPUMP)	TATA spare parts
289847600123	FUEL RETURN LINE ASSY	TATA spare parts
289847600125	ASSY.RETURN LINE(FIREWALL TO FUEL TANK)	TATA spare parts
289847600130	FUEL SUCTION PIPE ASSY	TATA spare parts
289847600132	FUEL RETURN PIPE ASSY	TATA spare parts
289847600133	FUEL RETURN PIPE ASSY	TATA spare parts
289847600134	FUEL SUCTION PIPE ASSY	TATA spare parts
289847600135	FUEL SUCTION PIPE ASSY	TATA spare parts
289847600137	FUEL SUCTION PIPE ASSY	TATA spare parts
289847600138	FUEL SUCTION PIPE ASSY TANK TO FIREWALL	TATA spare parts
289847600139	FUEL RETURN PIPE ASSY FIREWALL TO TANK	TATA spare parts
289847600141	FUEL RETURN PIPE ASSY FILTER TO FIREWALL	TATA spare parts
289847600142	FUEL SUCTION PIPE ASSY FIREWALL TO SED	TATA spare parts
289847600143	ASSY DELIVERY LINE (SEDI. TO PRIMING)	TATA spare parts
289847600146	ASSY SUCTION LINE (FUEL FILTER TO FIP)	TATA spare parts
289847600147	ASSY RETURN LINE (FILTER TO FW)	TATA spare parts
289847600148	ASSY PRIMING PUMP	TATA spare parts
289847600149	ASSY DELIVERY LINE (FW TO SEDIMENTOR)	TATA spare parts
289847600150	ASSY. DELIVERY LINE (TANK TO FW)	TATA spare parts
289847600155	FUEL RETURN LINE ASSY	TATA spare parts
289847600157	FUEL RETURN PIPE ASSY FIP TO T-CONN	TATA spare parts
289847600158	SUCTION PIPE ASSY TANK TO FIREWALL	TATA spare parts
289847600159	DELIVERY PIPE ASSY FIREWALL TO FILTER	TATA spare parts
289847600160	DELIVERY PIPE ASSY FUEL FILTER TO FIP	TATA spare parts
289847600161	RETURN PIPE ASSY FIP TO UNDERBODY	TATA spare parts
289847600162	RETURN PIPE ASSY U/B TO TANK	TATA spare parts
289847600169	DELIVERY PIPE ASSY FIREWALL TO PR FILTER	TATA spare parts
289847600170	RETURN PIPE ASSY FILTER TO T-CONN	TATA spare parts
289847600171	DELIVERY PIPE ASSY FILTER TO FIP	TATA spare parts
289847600172	RETURN PIPE ASSY FIP TO FIREWALL	TATA spare parts
289847600175	FUEL RETURN PIPE ASSY	TATA spare parts
289847600176	FUEL SUCTION PIPE ASSY	TATA spare parts

289847600179	FUEL RETURN PIPE ASSY	TATA spare parts
289847600180	FUEL SUCTION PIPE ASSY	TATA spare parts
289847600184	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
289847600187	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
289847600202	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
289847600206	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
289847600207	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
289847600209	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
289847605806	FUEL FILLING HOSE	TATA spare parts
289847605807	BREATHER HOSE	TATA spare parts
289847605823	FUEL FILLING HOSE	TATA spare parts
289847605832	FUEL FILLING HOSE	TATA spare parts
289847605860	FUEL FILLING HOSE BS6-PH2	TATA spare parts
289847610104	FUEL RETURN PIPE ASSY BS6	TATA spare parts
289847610105	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
289847610106	FUEL RETURN PIPE ASSY BS6	TATA spare parts
289847610107	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
289847700102	ASSY SEDIMENTOR BRACKET	TATA spare parts
289847700105	ASSY SUPPORT PLATE	TATA spare parts
289847700108	ASSY FILTER & SEDI.BKT(W/RUBBER STRAP)	TATA spare parts
289849100104	PIPE ASSY	TATA spare parts
289849200101	ASSY EXHAUST FRONT PIPE	TATA spare parts
289849200106	ASSY.FRONT PIPE - XENON RX	TATA spare parts
289849200107	ASSY.INTERMIDATE PIPE	TATA spare parts
289849200136	TAIL PIPE ASSY BS6	TATA spare parts
289849200139	PIPE ASSY INLET WITH FLEXIBLE BELLOW BS6	TATA spare parts
289849200150	PIPE ASSY INLET WITH FLEXIBLE BELLOW BS6	TATA spare parts
289849200163	PIPE ASSY INLET WITH FLEXIBLE BELLOW BS6	TATA spare parts
289849200164	TAIL PIPE ASSY BS6-PH2	TATA spare parts
289849200168	EXHAUST PIPE ASSY WITH BELLOW BS6-PH2	TATA spare parts
289849200170	BRACKET ASSY BS6-PH2	TATA spare parts
289849200172	BRACKET ASSY BS6-PH2	TATA spare parts
289849200174	EXHAUST PIPE ASSY BS6-PH2	TATA spare parts
289849205302	GASKET ASSY BS6-PH2	TATA spare parts
289854100102	ASSY POSITIVE AND NEGATIVE BATTERY CABL	TATA spare parts
289854100105	ASSY BATT CABLE +VE & -VE 207 DI E-II	TATA spare parts
289854100130	BATTERY SUPPORT ASSY BS6-PH2	TATA spare parts
289854100131	BATTERY MTG SUPPORT ASSY BS6-PH2	TATA spare parts
289854100132	BATTERY MTG SUPPORT ASSY BS6-PH2	TATA spare parts
289854108801	BATTERY CLAMPING STUD 290MM	TATA spare parts
289854109904	XENON RX BATTERY CABLE AND ENGINE WH BS	TATA spare parts
289854200110	ASSY EGR BS III CTRL SUPPORT	TATA spare parts
289854200125	WH BATT.CAB+VE & ENGINE WH XENON BSIV	TATA spare parts
289854200127	INSTRUMENT CLUSTER ASSY	TATA spare parts
289854200131	INSTRUMENT CLUSTER ASSY	TATA spare parts
289854200132	INSTRUMENT CLUSTER ASSY	TATA spare parts
289854207501	GROMMET SPEEDCOCABLE HOLE CLOSING	TATA spare parts



289854209902	INSTRUMENT CLUSTER 207DI E-II	TATA spare parts
289854209903	ELECT.INST.CLUSTER-207 DI BS-IV	TATA spare parts
289854209905	EMS ECU DCM 2.5	TATA spare parts
289854209910	A ECU XENON TC-BSIII	TATA spare parts
289854209912	ECU FOR 207DITC EURO-II SA	TATA spare parts
289854209914	ELECT.INST.CLUSTER-207 DI BS-III	TATA spare parts
289854300101	TANK UNIT WITH TFR	TATA spare parts
289854400108	REFLEX REFLECTOR ASSY LH BS6	TATA spare parts
289854400109	REFLEX REFLECTOR ASSY RH BS6	TATA spare parts
289854400111	BRACKET ASSY RH BS6-PH2	TATA spare parts
289854400112	ASSY WASHER BOTTLE FUNNEL HOLDER	TATA spare parts
289854403301	BRKT ASSY TAIL LAMP & LICENCE PL BS6-PH2	TATA spare parts
289854500102	BRACKET ASSY FUSEBOX MTG	TATA spare parts
289854500105	ASSY 5 POLE MAXI FUSE SUPPORT	TATA spare parts
289854500106	ASSY.FUSE & RELAY BOX MTG BKT (XENON RX)	TATA spare parts
289854500111	ASSY FUSE RELAY BOX & ECU MTG BKT	TATA spare parts
289854500118	FASCIA SWITCH ASSY	TATA spare parts
289854500126	COMBI SWITCH ASSY STEERING BS6	TATA spare parts
289854500127	COMBI SWITCH ASSY STEERING BS6	TATA spare parts
289854500131	FASCIA SWITCH ASSY BS6	TATA spare parts
289854500132	EL BATTERY CUT OFF SWITCH BS6-PH2	TATA spare parts
289854501631	ELECTRICAL BATTERY CUT OFF SWITCH BS6	TATA spare parts
289854503301	BRACKET REVERSE LIGHT CLIP MTG	TATA spare parts
289854503303	BRACKET BATTERY CUT OFF SWITCH MTG BS6	TATA spare parts
289854504901	ECO SWITCH BS6	TATA spare parts
289854504902	SWITCH REGENERATION START MANUAL BS6	TATA spare parts
289854504906	BATTERY CUT OFF SWITCH BS6	TATA spare parts
289854506306	5 POLE MAXI FUSE & DIAGNOSTIC CONN COVER	TATA spare parts
289854508205	BRACKET FUSE BOX MTG	TATA spare parts
289854600103	WIRING HARNESS MAIN BS6	TATA spare parts
289854600107	WIRING HARNESS TAIL BS6	TATA spare parts
289854600109	WIRING HARNESS EMS BS6	TATA spare parts
289854600113	BRACKET ENGINE W/H MTG	TATA spare parts
289854600120	BATTERY +VE CABLE ASSY WITH ENGINE W/H	TATA spare parts
289854600123	BRACKET ASSY RELAY MTG	TATA spare parts
289854600124	BRACKET ASSY RELAY BASE & RELAY MTG	TATA spare parts
289854600129	WIRING HARNESS TAIL	TATA spare parts
289854600130	WIRING HARNESS TAIL BS6	TATA spare parts
289854600132	WIRING HARNESS MAIN	TATA spare parts
289854600137	BRACKET ASSY RELAY BOX MTG	TATA spare parts
289854600140	WIRING HARNESS TAIL	TATA spare parts
289854600141	WIRING HARNESS MAIN	TATA spare parts
289854600142	WIRING HARNESS-MAIN BS6	TATA spare parts
289854600143	WIRING HARNESS EMS	TATA spare parts
289854600144	WIRING HARNESS ABS PIGTAIL	TATA spare parts
289854600149	WIRING HARNESS RPASBS6	TATA spare parts
289854600150	WIRINGHARNESSMAIN BS6	TATA spare parts

289854600152	MEGA FUSE BOX ASSY BS6-PH2	TATA spare parts
289854600154	WIRING HARNESS MAIN BS6	TATA spare parts
289854600155	PIGTAIL VEHICLE TRACKING SYSTEM BS6	TATA spare parts
289854600169	WIRING HARNESS EMS BS6	TATA spare parts
289854600171	WIRING HARNESS MAIN BS6	TATA spare parts
289854600173	WIRING HARNESS MAIN BS6	TATA spare parts
289854600174	WIRING HARNESS EMS BS6-PH2	TATA spare parts
289854600177	WIRING HARNESS SCR UNIT BS6-PH2	TATA spare parts
289854600178	BATTERY +VE CABLE ASSY WITH ENGINE W/H B	TATA spare parts
289854600180	BATTERY +VE CABLE ASSY WITH ENGINE W/H B	TATA spare parts
289854600181	WIRING HARNESS CO-DRIVER DOOR BS6	TATA spare parts
289854600182	WIRING HARNESS DRIVER DOOR BS6	TATA spare parts
289854600187	WIRING HARNESS SCR UNIT BS6-PH2	TATA spare parts
289854600190	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
289854600196	WIRING HARNESS EMS BS6-PH2	TATA spare parts
289854601649	WIRING HARNESS REGISTRATION PLATE LAMP	TATA spare parts
289854601674	PIG TAIL FOR REG. PLATE LAMP	TATA spare parts
289854601675	PIGTAIL FOR REG. PLATE LAMP	TATA spare parts
289854601683	WIRING HARNESS TAIL	TATA spare parts
289854601687	W/H ENGINE WITH BATT.CABLE +VE	TATA spare parts
289854601691	WIRING HARNESS TAIL	TATA spare parts
289854603303	BRACKET EMS WIRING HARNESS MTG BS6	TATA spare parts
289854603312	BRACKET ASSY MAXI FUSE MTG	TATA spare parts
289854603316	BRACKET ASSY DIAGNOSTIC CONN MTG	TATA spare parts
289854603321	BRACKET EMS INTERCONNECTOR MTG	TATA spare parts
289854603323	BRACKET CLIP MTG	TATA spare parts
289854603325	BRACKET ASSY EMS WIRING HARNESS MTG	TATA spare parts
289854603327	BRACKET EGR SENSOR	TATA spare parts
289854603332	BRACKET W/H EMS CONN PARKING	TATA spare parts
289854603336	WIRING HARNESS SUPPORT	TATA spare parts
289854603340	MAXI FUSE SUPPORT	TATA spare parts
289854606302	HOLDER	TATA spare parts
289854608206	BKT NEAR LIFTING HOOK	TATA spare parts
289854608210	BRKT CAB & TAIL INTERCONNECTION W/H BS6-	TATA spare parts
289854610101	WH CABIN 207 DI BSIV	TATA spare parts
289854610102	WH FRONT 207DI BS-IV	TATA spare parts
289854610103	WH EMS 207DI BS-IV WITH 2.5 DCM	TATA spare parts
289854610104	WH TAIL 207DI BS-IV	TATA spare parts
289854610105	WH ENGINE 207DI BS-IV	TATA spare parts
289854610114	W/H CABIN E-II	TATA spare parts
289854610115	WH FRONT E-II	TATA spare parts
289854610116	W/H TAIL E-II	TATA spare parts
289854610146	WIRING HARNESS MAIN MB BS6-PH2	TATA spare parts
289854610169	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
289854610170	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
289854610171	WIRING HARNESS TAIL BS6	TATA spare parts
289854610172	WIRING HARNESS RPAS BS6-PH2	TATA spare parts

289854610173	WIRING HARNESS RPAS BS6	TATA spare parts
289854610174	BATTERY CABLE +VE BATTERY TO BCS OFF I/P	TATA spare parts
289854610177	WIRING HARNESS MAIN	TATA spare parts
289854610178	BATTERY CABLE +VE BCS O/P TO SM BS6	TATA spare parts
289854610182	BATT CABLE +VE BATT TO MEGA FUSE BS6-PH2	TATA spare parts
289854620107	WH FRONT XENON RX BS-III	TATA spare parts
289854620108	WH CABIN XENON RX BS-III	TATA spare parts
289854620110	WIRING HARNESS TAIL	TATA spare parts
289854620111	WH TAIL XENON RX BS-III	TATA spare parts
289854620112	W/H FRONT	TATA spare parts
289854620118	W/H CABIN	TATA spare parts
289854620119	W/H TAIL	TATA spare parts
289854620120	WIRING HARNESS CABIN	TATA spare parts
289854620122	WH CABIN XENON 4SPTC BS-IV	TATA spare parts
289854620123	WH FRONT XENON 4SPTC BS-IV	TATA spare parts
289854620124	WH TAIL XENON RX BS-IV	TATA spare parts
289854620126	WH EMS XENON 4SPTC BS-IV	TATA spare parts
289854620127	WH TAIL XENON EX CC BS-IV	TATA spare parts
289854620134	W/H CABIN	TATA spare parts
289854620135	W/H FRONT	TATA spare parts
289854620146	BATT CABLE +VE BATTERY TO MEGA FUSE I/P	TATA spare parts
289854620148	BATTERY +VE CABLE ASSY WITH ENGINE W/H B	TATA spare parts
289854620152	WIRING HARNESS TAIL	TATA spare parts
289854620153	WIRING HARNESS MAIN	TATA spare parts
289854620154	WIRING HARNESS EMS	TATA spare parts
289854620155	W/H TAIL COMPACT	TATA spare parts
289854620158	WH/ MAIN CABLE BS 3	TATA spare parts
289854620162	WIRING HARNESS FRONT	TATA spare parts
289854620163	WIRING HARNESS CABIN	TATA spare parts
289854620164	WIRING HARNESS TAIL	TATA spare parts
289854620165	WIRING HARNESS CABIN	TATA spare parts
289854620166	WIRING HARNESS FRONT	TATA spare parts
289854620167	WIRING HARNESS MAIN	TATA spare parts
289854700112	BRACKET ASSY GDCU UNIT MOUNTING BS6-PH2	TATA spare parts
289854706301	HOLDER PARKING SENSOR BS6	TATA spare parts
289854706302	HOLDER PARKING SENSOR BS6	TATA spare parts
289854708202	BRACKET SPEED LIMITER DEVICE MOTOR MTG	TATA spare parts
289854708203	BRACKET SPEED LIMITER ECU MTG	TATA spare parts
289854709901	EGR CONTROLLER ECU	TATA spare parts
289854709904	CLIP BS6	TATA spare parts
289854709905	EGR CONTROLLER ECU	TATA spare parts
289854720103	CROSS MEMBER ASSY RPAS SENSOR MTG BS6-PH	TATA spare parts
289854809902	SPACER	TATA spare parts
289854900108	BRACKET ASSY ECU MTG	TATA spare parts
289854900111	BRACKET ASSY ECU MTG	TATA spare parts
289855106301	MASCOT	TATA spare parts
289855106302	MASCOT	TATA spare parts

289855106303	MASCOT	TATA spare parts
289855156301	DECAL	TATA spare parts
289855156302	DECAL	TATA spare parts
289855156303	DECAL FRONT DOOR RH	TATA spare parts
289855156304	DECAL	TATA spare parts
289855156306	DECAL RH	TATA spare parts
289855156307	DECAL (YODHA_1700) BS6	TATA spare parts
289855156308	DECAL (YODHA_1200) BS6	TATA spare parts
289855156314	DECAL BS6	TATA spare parts
289855156315	DECAL BS6-PH2	TATA spare parts
289858300101	TOOL KIT	TATA spare parts
289858304001	HANDLE JACK	TATA spare parts
289858304009	BRACKET ASSY JACK MTG BS6-PH2	TATA spare parts
289858304011	BRACKET ASSY JACK MTG BS6-PH2	TATA spare parts
289858900601	SPECIAL TOOL FOR STRETCH BELT REMOVAL	TATA spare parts
289858900701	ADAPTER CHECKING ENGINE COMPRESSION BS6	TATA spare parts
289858901801	OIL FILTER REMOVAL & FITMENT	TATA spare parts
289858903201	SUSPENSION INSTALLER & REMOVER FIXTURE B	TATA spare parts
289858903202	BUSH INSTALLER UPPER WISHBONE BS6	TATA spare parts
289858903203	SUPPORT BUSH INSTALLER BS6	TATA spare parts
289858903204	FIXTURE HOLDING UPPER WISHBONE BS6	TATA spare parts
289858903205	KIT-BUSH REMOVER BS6	TATA spare parts
289858903301	"SOCKET,ADJUSTABLE NUT FRONT YOKE"	TATA spare parts
289858903302	"PULLER,BUSH REMOVAL"	TATA spare parts
289858903303	"PULLER,BALL JOINT"	TATA spare parts
289858903304	"PULLER,BALL JOINT"	TATA spare parts
289858903305	PULLER BALL JOINT REMOVING FROM STUB AXL	TATA spare parts
289858903306	DRIFT BALL JOINT FITMENT ON STUB AXLE	TATA spare parts
289858903307	HOLDER BALL JOINT FITMENT ON STUB AXLE	TATA spare parts
289858903308	PULLER BALL JOINT	TATA spare parts
289858903311	SOCKET LOCK NUT	TATA spare parts
289860000109BF	ASSY.CABIN BARE XENON ARCTIC WHITE BS3/4	TATA spare parts
289860000130BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
289860000130BL	ASSY BODY SHELL DK_NEPT_BLUE BS6	TATA spare parts
289860000131	BODY SHELL ASSY BS6	TATA spare parts
289860000138BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
289860000167BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
289860000167KO	JOSH_BLUE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
289860000187BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
28986000031R40BF	PARTIAL FITTED CABIN YODHA BS6	TATA spare parts
28986000128R40BF	PARTIAL FITTED CABIN YODHA SC BS6	TATA spare parts
289860100104	TIE MEMBER ASSY.COMPLETE	TATA spare parts
289860100106	SUPPORT ASSY BATTERY MTG	TATA spare parts
289860100110	BRACKET ASSY FRONT MTG BS6	TATA spare parts
289860108201	BATTERY TRAY	TATA spare parts
289860108210	BRACKET FRONT GRILL MTG LH BS6	TATA spare parts
289860108211	BRACKET FRONT GRILL MTG RH BS6	TATA spare parts

28986010M10104	TIE MEMBER ASSY BS6-PH2	TATA spare parts
28986010M10135	ASSY SHOT GUN LH BS6-PH2	TATA spare parts
28986010M10136	ASSY SHOT GUN RH BS6-PH2	TATA spare parts
289860600102	WHEEL ARCH ASSY RH	TATA spare parts
289860600103	WHEEL ARCH ASSY LH	TATA spare parts
289860600106	WHEELARCHASSY LH BS6	TATA spare parts
289860608208	SUPPORT BRACKET LH BS6-PH2	TATA spare parts
289860608209	SUPPORT BRACKET RH BS6-PH2	TATA spare parts
28986060M10102	WHEEL ARCH ASSY RH BS6-PH2	TATA spare parts
28986060M10105	ASSY FENDER INNER UPPER COMP LH 3L BS6-P	TATA spare parts
28986060M10106	WHEEL ARCH ASSY LH BS6-PH2	TATA spare parts
28986060M10139	FENDER ASSY INNER-RH BS6-PH2	TATA spare parts
289861000101	FLOOR ASSY WITH SUBSTRUCTURE	TATA spare parts
289861000112	FLOOR ASSY WITH SUBSTRUCTURE BS6	TATA spare parts
289861000116	FLOOR ASSY WITH SUBSTRUCTURE BS6	TATA spare parts
289861000124	FLOOR ASSY WITH SUBSTRUCTURE	TATA spare parts
289861606301	FOAM BLOCK MIDDLE-FRONT	TATA spare parts
289861608209	CLOSING PLATE TUNNEL	TATA spare parts
289861608213	REINFORCEMENT EXTENSION LH BS6	TATA spare parts
289861608215	REINFORCEMENT EXTENSION LH BS6	TATA spare parts
289861608216	PLATE BS6	TATA spare parts
28986160M10103	FLOOR PANEL ASSY FRONT BS6-PH2	TATA spare parts
289862600102	DASH PANEL COMPLETE ASSY. RHD	TATA spare parts
289862600114	DASH PANEL ASSY BS6	TATA spare parts
28986260M10102	DASH PANEL ASSY BS6-PH2	TATA spare parts
28986260M10114	DASH PANEL ASSY BS6-PH2	TATA spare parts
289863600103	BODY SIDE ASSY INNER-LH BS6	TATA spare parts
289863600104	BODY SIDE ASSY INNER-RH	TATA spare parts
28986360M10103	BODY SIDE ASSY INNER-LH BS6-PH2	TATA spare parts
28986360M10104	BODY SIDE ASSY INNER-RH BS6-PH2	TATA spare parts
289863700101	BODY SIDE ASSY OUTER-LH	TATA spare parts
289863700102	BODY SIDE ASSY OUTER-RH	TATA spare parts
28986370M10101	BODY SIDE ASSY OUTER-LH BS6-PH2	TATA spare parts
28986370M10102	BODY SIDE ASSY OUTER-RH BS6-PH2	TATA spare parts
289864700101	REAR WALL ASSY	TATA spare parts
289864700103	REAR WALL ASSY BS6	TATA spare parts
28986470M10103	REAR WALL ASSY BS6-PH2	TATA spare parts
28986510M10102	FRONT HEADER ASSY BS6-PH2	TATA spare parts
289868500101	CARPET ASSY FRONT FLOOR	TATA spare parts
289868500104	CARPET ASSY FRONT FLOOR BS6	TATA spare parts
289868506302	CARPET FRONTFLOOR LH BS6	TATA spare parts
289868506303	CARPET FRONTFLOOR RH BS6	TATA spare parts
289868506304	CARPET FRONTTUNNEL BS6	TATA spare parts
289868506308	CARPET FRONT FLOOR RH BS6-PH2	TATA spare parts
289868506309	CARPET FRONT FLOOR RH BS6	TATA spare parts
289868900101	SUPPORT¿TUBE¿ASSY¿CCB BS6	TATA spare parts
289868900104	CROSS MEMBER ASSY DASHBOARD	TATA spare parts

289868900106	CENTER CONSOLE ASSY	TATA spare parts
289868900110	CENTER CONSOLE ASSY BS6	TATA spare parts
289868900113	CENTER CONSOLE ASSY	TATA spare parts
289868900114	DASHBOARD ASSY WITH GLOVE BOX BS6	TATA spare parts
289868900116	NACELLE ASSY UPPER BS6	TATA spare parts
289868900117	FASCIA ASSY CENTER BS6	TATA spare parts
289868900118	DASHBOARDASSY BS6	TATA spare parts
289868906303	UTILITY BIN BS6	TATA spare parts
289868906306	UTILITYBINCENTER BS6	TATA spare parts
289868906307	DASHBOARD SKIN BS6-PH2	TATA spare parts
289868906308	COIN BOX BS6	TATA spare parts
289868906309	UTILITYBINTOP BS6	TATA spare parts
289868906312	NACELLE LOWER BS6	TATA spare parts
289868907502	GROMMET DASHBOARD LOCATOR CENTER BS6	TATA spare parts
28986890M10104	CROSS MEMBER ASSY DASHBOARD BS6-PH2	TATA spare parts
28986890M10118	BRACKET ASSY CCB MTG LH BS6-PH2	TATA spare parts
28986890M10119	BRACKET ASSY CCB MTG RH BS6-PH2	TATA spare parts
289869500101	ROOF LINER ASSY	TATA spare parts
289869506303	FOAM PACKING BS6	TATA spare parts
289870000102	ASSY 3 SIDE DROP LOAD BODY XENON RX 70	TATA spare parts
289870000103	ASSY FLAT LOAD BODY PAINTED; XENON RX	TATA spare parts
289870000103BF	ARCTIC_WHITE-ASSY FLAT LOAD BODY PAINT	TATA spare parts
289870000103D3	ASSY 2.2M LOAD BODY (SIDE DROP) PAINTED	TATA spare parts
289870000103DU	ASSY FLAT LOAD BODY PAINTED; XENON RX	TATA spare parts
289870000103000000	ARIZONA BLUE-ASSY FLAT LOAD BODY PAINTED	TATA spare parts
289870000103FG	ASSY FLAT LOAD BODY PAINTED; XENON RX	TATA spare parts
289870000118	ASSY LOAD BODY COMPLETE WITH FASTNERS	TATA spare parts
289870000119BF	ASSLY LOAD BODY PAINTED	TATA spare parts
289870000119D3	ASSLY LOAD BODY PAINTED.	TATA spare parts
289870000119DU	ASSLY LOAD BODY PAINTED.	TATA spare parts
289870000119000000	ASSLY LOAD BODY PAINTED.	TATA spare parts
289870000119FG	ASSLY LOAD BODY PAINTED	TATA spare parts
289870000121ZY	ASSY LOAD BODY PAINTED	TATA spare parts
289870000124	LOAD BODY ASSY WITH FASTENER BS6	TATA spare parts
289870000126BF	LOAD BODY PAINTED_ARCTIC WHITE	TATA spare parts
289870000132BF	ARCTIC_WHITE_ASSY LOADBODY PAINTED XENON	TATA spare parts
289870000136BF	LOAD BODY BODY W/O SKIRT207F_ARCTIC WHIT	TATA spare parts
289870000136BL	LOAD BODY BODY W/O SKIRT207F_DARK NEPTUN	TATA spare parts
289870000136FG	LOAD BODY BODY W/O SKIRT207F_MINERAL RED	TATA spare parts
289870000136GZ	LOAD BODY BODY W/O SKIRT207F_BISLRI_GREE	TATA spare parts
289870000139BF	ARCTIC_WHITE-LOAD BODY ASSY	TATA spare parts
289870000140	LOAD BODY ASSY WITH FASTENERS	TATA spare parts
289870000144BF	LOAD BODY ASSY ARCTIC_WHITE	TATA spare parts
289870000159	LOAD BODY ASSY BS6	TATA spare parts
289870000163BF	ARCTIC_WHITE-LOAD BODY ASSY BS6	TATA spare parts
289870000163KO	JOSH_BLUE-LOAD BODY ASSY BS6	TATA spare parts
289870000164BF	ARCTIC_WHITE-LOAD BODY ASSY BS6	TATA spare parts

289870000174BF	ARCTIC_WHITE-LOAD BODY ASSY BS6	TATA spare parts
289870000183BF	ARCTIC_WHITE-LOAD BODY ASSY BS6	TATA spare parts
289870006301	MUD FLAP LH	TATA spare parts
289870006302	MUD FLAP RH	TATA spare parts
289870006303	MUDFLAP REAR WITH T	TATA spare parts
28987000M10140	LOAD BODY PAINTED ASSY BS6-PH2	TATA spare parts
28987000M10164	LOAD BODY PAINTED ASSY BS6-PH2	TATA spare parts
28987000M10171	LOAD BODY ASSY BS6-PH2	TATA spare parts
28987000M10189	LOAD BODY PAINTED ASSY BS6-PH2	TATA spare parts
28987000M10189KO	JOSH_BLUE-LOAD BODY PAINTED ASSY BS6-PH2	TATA spare parts
289870100132	MOUNTING BRACKET ASSY BS6	TATA spare parts
289870100138	REAR SKIRT ASSY	TATA spare parts
289870100140	NUT PLATE ASSY BS6	TATA spare parts
289870100159	FUEL HINGE ASSY WITH CAP BS6	TATA spare parts
289870100163	REINFORCEMENT FRONT PANEL BS6-PH2	TATA spare parts
289870100164	SKIRT ASSY REAR	TATA spare parts
289870100191	SKIRT ASSY REAR BS6	TATA spare parts
289870108294	MUD GUARD BS6	TATA spare parts
289870108295	FENDER SUPPORT BKT BS6	TATA spare parts
289870108298	CLAMP	TATA spare parts
289870108299	CLAMP	TATA spare parts
289870110137	MUDGUARD ASSY LH BS6-PH2	TATA spare parts
289870110138	MUDGUARD ASSY RH BS6-PH2	TATA spare parts
289870118298	COVER MUDGUARD BS6-PH2	TATA spare parts
289870120103	SUPD ASSY LH BS6	TATA spare parts
289870120104	SUPD ASSY RH BS6	TATA spare parts
289870120112	SUPD ASSY LH BS6-PH2	TATA spare parts
289870120113	SUPD ASSY RH BS6-PH2	TATA spare parts
289870200103	ASSY FRONT PANEL	TATA spare parts
289870200110	ASSY. REINFORCEMENT FRONT PANEL BS6	TATA spare parts
289870200115	FRONT PANEL ASSY BS6	TATA spare parts
289870200121	SIDE WALL ASSY LH BS6	TATA spare parts
289870200126	FRONT PANEL ASSY BS6	TATA spare parts
289870200128	SIDE WALL ASSY RH BS6	TATA spare parts
289870200149	FRONT PANEL ASSY BS6	TATA spare parts
289870208211	REINFORCEMENT FRONT PANEL BS6-PH2	TATA spare parts
289870208231	SUPPORT PLATE BS6	TATA spare parts
289870208249	SUPPORT PLATE BS6-PH2	TATA spare parts
289870300127	ASSY SIDE WALL LH	TATA spare parts
289870300128	ASSY SIDE WALL RH	TATA spare parts
289870300129	ASSY.FUEL HINGE WITH CAP BS6	TATA spare parts
289870300138	SIDE WALL ASSY LH BS6	TATA spare parts
289870300139	SIDE WALL ASSY RH BS6	TATA spare parts
289870300142	SIDE WALL ASSY LH	TATA spare parts
289870300143	SIDE WALL ASSY RH	TATA spare parts
289870308256	REAR SKIRT LH	TATA spare parts
289870308258	REAR SKIRT RH	TATA spare parts

289870308259	FRONT SKIRT LH	TATA spare parts
289870308260	FRONT SKIRT RH	TATA spare parts
289870308279	HINGE PLATE FIX	TATA spare parts
289870308280	CLAMP BS6	TATA spare parts
289870308284	CLAMP BS6	TATA spare parts
289870400102	ASSY TAIL PANEL	TATA spare parts
289870400108	LOCK ASSY TAILGATE REAR-RH	TATA spare parts
289870400109	LOCK ASSY TAILGATE REAR-LH	TATA spare parts
289870400110	TAILGATE ASSY BS6	TATA spare parts
289870400114	TAILGATE ASSY	TATA spare parts
289870400115	TAIL PANEL ASSY BS6	TATA spare parts
289870900102	ASSY HINGE	TATA spare parts
289870900103	ASSY.LOCK FRONT LH	TATA spare parts
289870900104	ASSY.LOCK FRONT RH	TATA spare parts
289870900105	ASSY.LOCK REAR LH	TATA spare parts
289870900106	ASSY.LOCK REAR RH	TATA spare parts
289870900107	HINGE ASSY	TATA spare parts
289870906301	RUBBER GROMMET	TATA spare parts
289870906302	RUBBER STOPPER	TATA spare parts
289870906305	CAP 10 DIA	TATA spare parts
289870906306	SIDE PANEL CAP 22 DIA	TATA spare parts
289870906307	U CLIP	TATA spare parts
289870906308	FLOOR CAP 12 DIA	TATA spare parts
289870908203	PIN BS6-PH2	TATA spare parts
289870908205	LOCK L-PLATE RH	TATA spare parts
289870908210	LOCK L-PLATE LH	TATA spare parts
289870908214	HINGE MALE BS6-PH2	TATA spare parts
289870908215	L-PLATE FRONTLOCK RH	TATA spare parts
289870908216	L-PLATE FRONTLOCK LH	TATA spare parts
289870908219	HINGE FEMALE BS6-PH2	TATA spare parts
289872200111	DOOR SHELL ASSY FRONT DOOR LHBS6	TATA spare parts
28987220011135	CED-DOOR SHELL ASSY FRONT DOOR LH	TATA spare parts
289872200112	DOOR SHELL ASSY FRONT DOOR RHBS6	TATA spare parts
28987220011235	CED-DOOR SHELL ASSY FRONT DOOR RH	TATA spare parts
289872200116	DOOR SHELL ASSY FRONT DOOR LH BS6	TATA spare parts
289872200118	BRACKET ASSY BOTTLE HOLDER MTG BS6-PH2	TATA spare parts
289872200119	BRACKET ASSY BOTTLE HOLDER MTG BS6-PH2	TATA spare parts
28987220M10112	DOOR SHELL ASSY FRONT DOOR RH BS6-PH2	TATA spare parts
28987220M10114	FRONT DOOR ASSY WITH HINGES RH BS6-PH2	TATA spare parts
28987220M10116	DOOR SHELL ASSY FRONT DOOR LH BS6-PH2	TATA spare parts
28987220M10117	FRONT DOOR ASSY WITH HINGES LH BS6-PH2	TATA spare parts
289872706301	MAGAZINE POCKET FRONT DOOR LH	TATA spare parts
289872706306	INNER COVER MAGAZINE POCKET RH BS6-PH2	TATA spare parts
289872706307	INNER COVER MAGAZINE POCKET LH BS6-PH2	TATA spare parts
289872990101	KIT-LOCK	TATA spare parts
289881100103	COVER SUPPORT PANEL ASSY.RH SIDE	TATA spare parts
289881100108	REAR VIEW MIRROR ASSY INNER BS6-PH2	TATA spare parts



289881100109	ROOF DITCH ASSY LH BS6	TATA spare parts
289881100110	ROOF DITCH ASSY RH BS6	TATA spare parts
289881100111	COVER ASSY MIDDLE BS6	TATA spare parts
289881106301	FRONT MUDGUARD LINER INNER-LH	TATA spare parts
289881106302	FRONT MUDGUARD LINER INNER-RH	TATA spare parts
289881106303	END CAP ROOF BEADING REAR-LH BS6	TATA spare parts
289881106304	END CAP ROOF BEADING REAR-RH BS6	TATA spare parts
289881106307	STICKER BS6	TATA spare parts
289882900101	WASHER SYSTEM ASSY	TATA spare parts
289882900102	TUBE ASSY	TATA spare parts
289882900103	WASHER BOTTLE ASSY BS6	TATA spare parts
289883106301	COVER LH BS6-PH2	TATA spare parts
289883106302	CASE BS6-PH2	TATA spare parts
289883106303	DISTRIBUTION DUCT BLOWER LH BS6-PH2	TATA spare parts
289883106304	DISTRIBUTION DUCT BLOWER RH BS6-PH2	TATA spare parts
289883106305	UPPER CASE BLOWER BS6-PH2	TATA spare parts
289883106307	COVER RH BS6-PH2	TATA spare parts
289883300102	ASSY PUSH-PULL CABLE (HEATER CONTROL) 20	TATA spare parts
289883306301	COVER PLATE CONTROL PANEL BS6-PH2	TATA spare parts
289883400106	ASSY.BINARY PRESSURE SWITCH	TATA spare parts
289883400118	HVAC UNIT ASSYBS6	TATA spare parts
289883400119	FORCE VENTILATION ASSY-BLOWER UNIT BS6-P	TATA spare parts
289883401601	HVAC UNIT ASSY BS6	TATA spare parts
289883403304	BRACKET BLOWER MTG BOTTOM BS6-PH2	TATA spare parts
289883403305	BRACKET ASSY HOUSING BS6-PH2	TATA spare parts
289883403306	BRACKET ASSY TOP-RH BS6-PH2	TATA spare parts
289883403308	BRACKET ASSY TOP-LH BS6-PH2	TATA spare parts
289883404901	WIRING HARNESS BS6-PH2	TATA spare parts
289883407701	SEALING FOAM BS6-PH2	TATA spare parts
289883500102	ASSY BKT FOR WATER VALVE	TATA spare parts
289883500106	HEATER CORE S/A BS6	TATA spare parts
289883505801	HEATER HOSE (ENGINE TO WATER VALVE)	TATA spare parts
289883505805	HEATER HOSE (WATER VALVE TO HEATER)	TATA spare parts
289883505806	HEATER HOSE (HEATER OUT)	TATA spare parts
289883600101	DISCHARGE HOSE ASSY BS6	TATA spare parts
289883600102	TUBE ASSY LIQUID LINE BS6	TATA spare parts
289883600103	DISCHARGE PIPE ASSY BS6	TATA spare parts
289883600104	SUCTION PIPE ASSY BS6	TATA spare parts
289883600106	SUCTION HOSE ASSY BS6	TATA spare parts
289883650101	HEATER HOSE ASSY ENGINE TO HEATER BS6	TATA spare parts
289883650103	HEATER HOSE ASSY HEATER TO ENGINE BS6	TATA spare parts
289883750102	BRACKETASSYACPIPEMTG BS6	TATA spare parts
289883750103	BRACKETASSYWITHWELDNUT BS6	TATA spare parts
289883750107	BRACKET ASSY WITH WELD NUT BS6-PH2	TATA spare parts
289883753303	BRACKETHEATERHOSEMTG BS6	TATA spare parts
289883753305	BRACKET HEATER HOSE MTG BS6-PH2	TATA spare parts
289888100101	FENDERASSY OUTER-LH BS6	TATA spare parts

289888100102	FENDERASSY OUTER-RH BS6	TATA spare parts
289888100103	FENDER ASSY OUTER-LH BS6	TATA spare parts
289888100104	FENDER ASSY OUTER-RH BS6	TATA spare parts
289888100105	BEZEL MTG ASSY LH BS6-PH2	TATA spare parts
289888100106	BEZEL MTG ASSY RH BS6-PH2	TATA spare parts
289888100107	MUDFLAP ASSY WHEEL ARCH FRONT-LH BS6	TATA spare parts
289888100108	MUDFLAP ASSY WHEEL ARCH FRONT-RH BS6	TATA spare parts
289888100109	COVER ASSY REPEATOR FENDER LH BS6	TATA spare parts
289888100110	COVER ASSY REPEATOR FENDER RH BS6	TATA spare parts
289888100113	CLOSING PLATE ASSY FRONT-LH	TATA spare parts
289888100114	CLOSING PLATE ASSY FRONT-RH	TATA spare parts
289888108201	FENDER OUTER-LH	TATA spare parts
289888108202	FENDER OUTER-RH	TATA spare parts
28988810M10103	FENDER ASSY OUTER-LH BS6-PH2	TATA spare parts
28988810M10104	FENDER ASSY OUTER-RH BS6-PH2	TATA spare parts
289888110105	LINER ASSY FRONT WHEEL ARCH UPPER-LH BS6	TATA spare parts
289888110106	LINER ASSY FRONT WHEEL ARCH UPPER-RH BS6	TATA spare parts
289888110107	LINER ASSY FRONT WHEEL ARCH LOWER-LH BS6	TATA spare parts
289888110108	LINER ASSY FRONT WHEEL ARCH LOWER-RH BS6	TATA spare parts
289888110109	WATER DEFLECTOR ASSY RH BS6	TATA spare parts
289888208201	FENDER	TATA spare parts
289888300102	FOOT STEP ASSY	TATA spare parts
289888300103	FOOT STEP ASSY BS6	TATA spare parts
289888460107	BRACKET ASSY MIDDLE BUMPER MTG BS6	TATA spare parts
289888460121	BRACKET ASSY BUMPER FOG LAMP LH BS6-PH2	TATA spare parts
289888460122	BRACKET ASSY BUMPER FOG LAMP RH BS6-PH2	TATA spare parts
289888468207	GUSSET BUMPER MOUNTING BRACKET BS6	TATA spare parts
289888468303	SHIM BS6	TATA spare parts
289888500109	CENTER BUMPER ASSY BS6	TATA spare parts
289888500111	BUMPER ASSY LH BS6	TATA spare parts
289888500112	BUMPER ASSY RH BS6	TATA spare parts
289888500115	SUPPORT ASSY LH BS6	TATA spare parts
289888500116	SUPPORT ASSY RH BS6	TATA spare parts
289888500117	HUMANITY STRIP ASSY FRT BUMPER GRILL MID	TATA spare parts
289888500117BF	ARCTIC_WHITE-HUMANITY STRIP ASSY FRT BUM	TATA spare parts
289888500120	SIDE BUMPER ASSY LH BS6	TATA spare parts
289888500121	SIDE BUMPER ASSY RH BS6	TATA spare parts
289888500127	GUARD ASSY FRONT BS6	TATA spare parts
289888500128	BRACKET ASSY CORNER BUMPER MTG LH BS6	TATA spare parts
289888500129	BRACKET ASSY CORNER BUMPER MTG RH BS6	TATA spare parts
289888506303	RETRO REFLECTIVE TAPE	TATA spare parts
289888506304	FRONT GRILL BOTTOM BS6	TATA spare parts
289888506309	FOG LAMP BEZEL FRONT-LH BS6	TATA spare parts
289888506310	FOG LAMP BEZEL FRONT-RH BS6	TATA spare parts
289888506316	HUMANITY CHROME LH BS6	TATA spare parts
289888506316BF	ARCTIC_WHITE-HUMANITY CHROME LH BS6-PH2	TATA spare parts
289888506316KO	JOSH_BLUE-HUMANITY CHROME LH BS6-PH2	TATA spare parts

289888506317	HUMANITY CHROME RH BS6	TATA spare parts
289888506317BF	ARCTIC_WHITE-HUMANITY CHROME RH BS6-PH2	TATA spare parts
289888506317KO	JOSH_BLUE HUMANITY CHROME RH BS6	TATA spare parts
289888506318	FOG LAMP TRIM LOWER-LH BS6	TATA spare parts
289888506319	FOG LAMP TRIM LOWER-RH BS6	TATA spare parts
289888506320	FOG LAMP TRIM UPPER-LH BS6	TATA spare parts
289888506321	FOG LAMP TRIM UPPER-RH BS6	TATA spare parts
289888506322	REFLECTIVE TAPE BS6	TATA spare parts
289888700102	BONNET CENTER ASSY BS6	TATA spare parts
28988870M10103	BONNET CENTER ASSY BS6-PH2	TATA spare parts
289888800101	TOP GRILL ASSY BS6	TATA spare parts
289888806302	TRUST BAR BS6	TATA spare parts
289888806303	FRONT GRILL BS6	TATA spare parts
289891000102	DRIVER SEAT ASSY	TATA spare parts
289891000103	DRIVER SEAT ASSY	TATA spare parts
289891000118	DRIVER SEAT ASSY WITH HEADREST BS6	TATA spare parts
289891000121	DRIVER SEAT ASSY WITH HEADREST BS6	TATA spare parts
289891100101	RISER ASSY	TATA spare parts
289891100102	SEAT FRAME ASSY DRIVER SEAT	TATA spare parts
289891100105	RISER ASSY BS6	TATA spare parts
289891100106	RISER ASSY BS6	TATA spare parts
289891200103	CUSHION ASSY BS6	TATA spare parts
289891300103	BACKREST ASSY BS6	TATA spare parts
289891750101	RECLINER HANDLE RH BS6	TATA spare parts
289891750102	RECLINER COVER RH BS6	TATA spare parts
289891900101	ACTIVE SLIDE RAIL ASSY	TATA spare parts
289891900102	PASSIVE SLIDE RAIL ASSY	TATA spare parts
289891900105	TRACK ASSY RH BS6	TATA spare parts
289891919901	BOLT BS6	TATA spare parts
289891930104	HEADREST ASSY BS6	TATA spare parts
289894000101	CO-DRIVER SEAT ASSY	TATA spare parts
289894000106	CO-DRIVER SEAT ASSY BS6	TATA spare parts
289894000112	CO-DRIVER SEAT ASSY WITH HEADREST BS6	TATA spare parts
289894100101	SEAT FRAME ASSY CO-DRIVER SEAT BS6	TATA spare parts
289894100104	SEAT FRAME ASSY CO-DRIVER SEAT BS6	TATA spare parts
289894300101	FRAME ASSY FRONT SEAT BACK BS6	TATA spare parts
289894400101	TRIM ASSY FRONT SEAT BACK BS6	TATA spare parts
289894400102	TRIM ASSY FRONT SEAT CUSHION BS6	TATA spare parts
289894450108	FOAM ASSY FRONT SEAT CUSHION BS6	TATA spare parts
289894450111	FOAM ASSY FRONT SEAT BACK BS6	TATA spare parts
289897500101	SEAT BELT ASSY WITH ELR FRONT-LHBS6	TATA spare parts
289897500102	SEAT BELT ASSY WITH ELR FRONT-RHBS6	TATA spare parts
289897980101	SEAT BELT ASSY WITH ELR FRONT-RH	TATA spare parts
289897980102	SEAT BELT ASSY WITH ELR FRONT-LH	TATA spare parts
289897980103	KIT-SEAT BELT FRONT	TATA spare parts
2898D1A1465001	PANEL ROOF FRONT BS6-PH2	TATA spare parts
2898D1D0170001	SIDE PANEL ASSY BS6-PH2	TATA spare parts

2898D1D0170003	SIDE PANEL ASSY BS6-PH2	TATA spare parts
2898D1D0370001	FRONT PANEL ASSY BS6-PH2	TATA spare parts
2898D1D0370003	FRONT PANEL ASSY BS6-PH2	TATA spare parts
2898D1D0470001	TAIL GATE ASSY BS6-PH2	TATA spare parts
2898D1D0470003	TAIL GATE ASSY BS6-PH2	TATA spare parts
2898D9Y0160003BF	ARCTIC_WHITE-PAINTED BODY SHELL-MFG BS6-	TATA spare parts
2898D9Y0160003KO	JOSH_BLUE-PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
2898H9X0233001	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
289970000101	HIGH DECK LOAD BODY FOR LPT-2515	TATA spare parts
289970806901	U BOLT 606	TATA spare parts
289970806902	U BOLT 530	TATA spare parts
289970906304	PACKING BALATA	TATA spare parts
290000990101	COLD START CRANKING KIT-ALL 3.3L MODELS	TATA spare parts
290015400101	ALTERNATOR 12V 120A LIN WITH FUSE BS6-PH	TATA spare parts
290016172001	ELECTRONIC STABILITY CONTROLLER BS6 PH2	TATA spare parts
290024020102	STOPPER ASSY REAR BS6	TATA spare parts
290024027501	RUBBER PAD BS6	TATA spare parts
290024200101	BRACKET ASSY CHASSIS RH BS6	TATA spare parts
290024200102	BRACKET ASSY CHASSIS LH BS6	TATA spare parts
290024200103	BRACKET ASSY ENGINE MTG FRONT-RH BS6	TATA spare parts
290024200104	BRACKET ASSY ENGINE MTG FRONT-LH BS6	TATA spare parts
290024200105	BRACKETASSYENGINEMTGRH BS6	TATA spare parts
290024200106	BRACKETASSYENGINEMTGFRONT-LH BS6	TATA spare parts
290024200112	REAR MOUNT ASSY BS6-PH2	TATA spare parts
290024200114	BRACKET ASSY ENGINE MTG REAR-LH BS6-PH2	TATA spare parts
290024200115	BRACKET ASSY ENGINE MTG REAR-RH BS6-PH2	TATA spare parts
290024203701	ENGINE MTG ARM BS6	TATA spare parts
290029200102	BRAKE PEDAL ASSY WITH BUSH BS6-PH2	TATA spare parts
290029300101	NYLON PIPE ASSY T-CONN TO CLUTCH BOOSTER	TATA spare parts
290029300109	NYL PIPE ASSY T-CONN TO AIR TANK BS6-PH2	TATA spare parts
290031000101	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000103	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000105	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000107	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000114	FRAME ASSY WITH FITMENT	TATA spare parts
290031000116	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000130	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000132	FRAMEASSYWITHFITMENT BS6	TATA spare parts
290031000136	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000151	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000156	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000158	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000163	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000168	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000173	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000219	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000221	FRAME ASSY WITH FITMENT BS6	TATA spare parts

290031000223	FRAME ASSY WITH FITMENT BS6	TATA spare parts
290031000225	FRAME ASSY WITH FITMENT	TATA spare parts
29003100M10119	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
29003100M10121	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
29003100M10163	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
29003100M10164	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
29003100M10192	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
290031200104	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
290031200110	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
290031200114	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
290031200115	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
290031207114	REINFORCEMENT REAR-BOTTOM RH BS6	TATA spare parts
290031207115	REINFORCEMENT REAR-BOTTOM-LH BS6	TATA spare parts
290031207116	REINFORCEMENT REAR-RH BS6	TATA spare parts
290031207117	REINFORCEMENT REAR-LH BS6	TATA spare parts
290031207119	SPACER PLATE BS6	TATA spare parts
290031208201	CROSSMEMBER BS6	TATA spare parts
290031208301	CROSS MEMBER BS6-PH2	TATA spare parts
290031208302	CROSS MEMBER BS6-PH2	TATA spare parts
290031327101	BRACKET BS6	TATA spare parts
290031327102	BRACKET BS6	TATA spare parts
290031327103	BRACKET BS6	TATA spare parts
290031400101	CROSS MEMBER ASSY BS6	TATA spare parts
290031540101	KIT-BATTERY CARRIER BS6	TATA spare parts
290031700102	RUPD ASSY BS6	TATA spare parts
290031700112	BRACKET ASSY FUPD MTG RH BS6	TATA spare parts
290031700113	BRACKET ASSY FUPD MTG LH BS6	TATA spare parts
290031700114	FUPD ASSY BS6	TATA spare parts
290031700138	BRACKET ASSY BS6-PH2	TATA spare parts
290031700141	BRACKET ASSY FUPD MTG LH BS6-PH2	TATA spare parts
290031700142	BRACKET ASSY FUPD MTG RH BS6-PH2	TATA spare parts
290031700145	BRACKET ASSY RUPD MTG RH BS6	TATA spare parts
290031700146	BRACKET ASSY RUPD MTG LH BS6	TATA spare parts
290031700149	FUPD ASSY CROSS BEAM BS6	TATA spare parts
290031706701	TOW PIN BS6-PH2	TATA spare parts
290031707112	SPACER	TATA spare parts
290031707115	L-BRACKET BS6-PH2	TATA spare parts
290032800102	ANTI ROLL BAR ASSY-FRONT BS6	TATA spare parts
290033000103	FRONTAXLEASSYWITHBRAKEABS BS6	TATA spare parts
290033000104	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
290033000105	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
290033000108	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
290033207201	SEALING PLUG BS6-PH2	TATA spare parts
290033405501	FRONT HUB BS6	TATA spare parts
290033805103	STEERING ARM BS6	TATA spare parts
290033805104	STEERINGARM BS6	TATA spare parts
290040300101	SPARE WHEEL CARRIER ASSY BS6	TATA spare parts

290041100102	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
290041100103	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
290041100105	PROPELLER SHAFT ASSYBS6	TATA spare parts
290041110102	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
290041110105	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
290041110111	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
290041110112	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
290041110117	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
290041110118	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
290041110127	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
290041110129	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
290041118201	BRACKET CENTER BRG MTG BS6	TATA spare parts
290041120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
290041120103	PROPELLER SHAFT ASSY DRIVEBS6	TATA spare parts
290041120104	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
290041120108	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
290041120121	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
290041120123	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
290041120133	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
290041120135	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
290041129901	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
290041300101	BRACKET ASSY CENTER BRG MTG	TATA spare parts
290041300103	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
290041303308	BRACKET CENTER BRG MTG BS6	TATA spare parts
290041303317	BRACKET CENTER BRG MTG BS6	TATA spare parts
290041303318	BRACKET-CENTER BRG MTG BS6	TATA spare parts
290041303319	BRACKET-CENTER BRG MTG BS6	TATA spare parts
290041303320	BRACKET CENTER BRG MTG BS6	TATA spare parts
290042100101	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
290042100102	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
290042300101	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
290042300102	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
290042990102	CHAMBER MTG BRACKET ASSY KIT LH BS6-PH2	TATA spare parts
290042990103	CHAMBER MTG BRACKET ASSY KIT RH BS6-PH2	TATA spare parts
290042990106	CAMSHAT KIT LH BS6-PH2	TATA spare parts
290042990107	CAMSHAT KIT RH BS6-PH2	TATA spare parts
290042990108	DUST SHIELD KIT BS6-PH2	TATA spare parts
290042990110	ROLLER KIT BS6-PH2	TATA spare parts
290042990111	BRACKET ASSY WITH CLAMPS & FASTENERS BS6	TATA spare parts
290042990112	DUST SHIELD MOUNTING FASTNER KIT BS6-PH2	TATA spare parts
290042990113	SPRING SHOE RETURN KIT BS6-PH2	TATA spare parts
290042990114	SPRING SHOE RETURN KIT BS6-PH2	TATA spare parts
290042990115	SPRING RETAINING KIT BS6-PH2	TATA spare parts
290042990116	ANCHOR PIN KIT BS6-PH2	TATA spare parts
290042990117	RIVET KIT BS6-PH2	TATA spare parts
290042990118	MINOR OVER HAUL KIT / AXLE (SUS 631J1) B	TATA spare parts
290042990119	MINOR OVER HAUL KIT / AXLE (SPRING FLEX	TATA spare parts

290042990120	CAM SHAFT SERVICE KIT BS6-PH2	TATA spare parts
290042990121	SPIDER ASSEMBLY KIT LH BS6-PH2	TATA spare parts
290042990122	SPIDER ASSEMBLY KIT RH BS6-PH2	TATA spare parts
290042990123	CAMSHAT KIT LH BS6-PH2	TATA spare parts
290042990124	CAMSHAT KIT RH BS6-PH2	TATA spare parts
290042990125	DUST SHIELD KIT BS6-PH2	TATA spare parts
290042990182	CAM SHAFT SERVICE KIT BS6-PH2	TATA spare parts
290042990183	BRAKE SHOE KIT BS6-PH2	TATA spare parts
290042990186	BRAKE SHOE & LINER KIT BS6-PH2	TATA spare parts
290042990187	MINOR SERVICE KIT BS6-PH2	TATA spare parts
290042990188	MINOR SERVICE KIT BS6-PH2	TATA spare parts
290042990189	BRAKE SPRING KIT (SUS 631J1) BS6-PH2	TATA spare parts
290042990190	BRAKE SPRING KIT (SPRING FLEX SH) BS6-PH	TATA spare parts
290042990191	CAM SHAFT WASHER KIT BS6-PH2	TATA spare parts
290042990197	SPIDER ASSEMBLY KIT LH BS6-PH2	TATA spare parts
290042990198	SPIDER ASSEMBLY KIT RH BS6-PH2	TATA spare parts
290043200101	AIR TANK ASSY BS6	TATA spare parts
290043200102	AIR TANK ASSY BS6	TATA spare parts
290043200105	AIR TANK ASSY WITH MTG BKT BS6	TATA spare parts
290043200107	AIR TANK ASSY BS6	TATA spare parts
290043200108	AIR TANK ASSY BS6	TATA spare parts
290043200109	AIR TANK ASSY WITH MTG BKT BS6	TATA spare parts
290043700101	BRACKET ASSY APU MTG	TATA spare parts
290043700102	HANDBRAKE VALVE WITH MTG BKT BS6	TATA spare parts
290043700112	AIR PROCESSING UNIT	TATA spare parts
290043700134	QUICK RELEASE VALVE WITH MTG BKT BS6	TATA spare parts
290043700136	AIR PROCESSING UNIT WITH MTG BKT BS6	TATA spare parts
290043700172	BRACKET ASSY APU MTG	TATA spare parts
290043700179	SPRING BRAKE ACTUATOR BS6	TATA spare parts
290043709901	KIT-FOUR CIRCUIT PROTECTION VALVE BS6	TATA spare parts
290043800101	METALPIPEWITHCRIMPEDHOSE BS6	TATA spare parts
290043900102	PIPE BUNCH ASSY	TATA spare parts
290043900103	METAL PIPE ASSY HOSE TO ADAPTER	TATA spare parts
290043900104	METAL PIPE ASSY ADAPTER TO DDU	TATA spare parts
290043900119	PIPE ASSY BS6	TATA spare parts
290043900121	METAL PIPE ASSY WITH CRIMPED RUBBER HOSE	TATA spare parts
290043900122	METAL PIPE ASSY HOSE TO ADAPTER BS6	TATA spare parts
290043900123	PIPE BUNCH ASSY	TATA spare parts
290043900124	METAL PIPE ASSY ADAPTER TO APU BS6	TATA spare parts
290043900125	PIPE BUNCH ASSY BS6	TATA spare parts
290043900132	PIPE BUNCH ASSY BS6	TATA spare parts
290043900170	PIPE BUNCH ASSY BS6	TATA spare parts
290043900171	PIPE BUNCH ASSY BS6	TATA spare parts
290043900211	PIPE BUNCH ASSY CABIN BS6-PH2	TATA spare parts
290043900246	PIPE BUNCH ASSY CABIN BS6-PH2	TATA spare parts
290043900282	NYLON PIPE BUNCH ASSY CHASSIS BS6-PH2	TATA spare parts
290043900288	METAL PIPE WITH CRIMPED HOSE BS6-PH2	TATA spare parts

290043900292	NYLON PIPE BUNCH ASSY CHASSIS BS6-PH2	TATA spare parts
290043900311	PIPE BUNCH ASSY CABIN BS6-PH2	TATA spare parts
290043910112	PIPE BUNCH ASSY BS6	TATA spare parts
290043910156	PIPE BUNCH ASSY BS6	TATA spare parts
290043910190	PIPE BUNCH ASSY BS6	TATA spare parts
290043910195	NYLON PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
290043910197	PIPE BUNCH ASSY BS6	TATA spare parts
290043910201	BRAKE AGGR ASSY BS6	TATA spare parts
290043910202	METAL PIPE ASSY WITH CLAMPS BS6	TATA spare parts
290043910203	PIPE ASSY WITH CLAMPS & BKTS BS6	TATA spare parts
290043910204	PIPE BUNCH ASSY CHASSIS	TATA spare parts
290043910233	PIPE BUNCH ASSY BS6	TATA spare parts
290043910261	METAL PIPE BS6-PH2	TATA spare parts
290043920106	PIPE BUNCH ASSY BS6	TATA spare parts
290043920114	PIPE BUNCH ASSY BS6	TATA spare parts
290043920126	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
290043920127	METAL PIPE ASSY JOINT 1 TO JOINT 2 BS6	TATA spare parts
290043920128	METAL PIPE ASSY APU TO JOINT BS6	TATA spare parts
290043920134	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
290043920184	PIPE BUNCH ASSY CHASSIS BS6-PH2	TATA spare parts
290043920214	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
290043920216	PIPE BUNCH ASSY-CHASSIS BS6	TATA spare parts
290043930102	PIPE BUNCH ASSY CABIN BS6-PH2	TATA spare parts
290043930135	PIPE BUNCH ASSY CHASSIS BS6-PH2	TATA spare parts
290043930139	PIPE BUNCH ASSY BS6	TATA spare parts
290046100101	STEERING COLUMN ASSY BS6-PH2	TATA spare parts
290046100102	INTERMEDIATE SHAFT ASSY BS6-PH2	TATA spare parts
290046100106	STEERING COLUMN ASSY BS6-PH2	TATA spare parts
290046305101	PITMAN ARM BS6	TATA spare parts
290046305103	PITMAN ARM BS6	TATA spare parts
290046305104	PITMANARM BS6	TATA spare parts
290046305105	PITMAN ARM BS6-PH2	TATA spare parts
290046600101	STEERINGGEARBOXASSY BS6	TATA spare parts
290046600110	POWER STEERING PUMP ASSY BS6-PH2	TATA spare parts
290046600111	STEERING GEAR BOX ASSY BS6	TATA spare parts
290046600113	POWER STEERING PUMP ASSY BS6-PH2	TATA spare parts
290046700105	BELLOW PLATE ASSY BS6-PH2	TATA spare parts
290046700106	BRACKET OIL RESERVOIR MTG BS6-PH2	TATA spare parts
290046703301	BRACKET STG GEAR BOX MTG BS6	TATA spare parts
290046703304	BRACKET STG GEAR BOX MTG	TATA spare parts
290046800101	PRESSURE LINE ASSY BS6	TATA spare parts
290046800102	RETURN LINE ASSY BS6	TATA spare parts
290046800103	SUCTION LINE ASSY BS6	TATA spare parts
290046800104	SUCTION LINE ASSY BS6	TATA spare parts
290046800105	SUCTION LINE ASSY BS6	TATA spare parts
290046800107	PRESSURE LINE ASSY BS6	TATA spare parts
290046800108	SUCTION LINE ASSY BS6	TATA spare parts



290046800109	RETURN LINE ASSY BS6	TATA spare parts
290046800110	SUCTION LINE ASSY BS6	TATA spare parts
290046800111	RETURN LINE ASSY BS6	TATA spare parts
290046800114	RETURNLINEASSY BS6	TATA spare parts
290046800116	HIGH PRESSURE LINE ASSY BS6	TATA spare parts
290046800117	SUCTION LINE ASSY BS6	TATA spare parts
290046800118	RETURN LINE ASSY BS6	TATA spare parts
290046800123	SUCTION LINE ASSY BS6-PH2	TATA spare parts
290046800124	HIGH PRESSURE LINE ASSY BS6-PH2	TATA spare parts
290046800125	RTN LINE ASSY GR BOX TO INT JOINT BS6-PH	TATA spare parts
290046800126	RTN LINE ASSY INT JOINT TO RESERVOIR BS6	TATA spare parts
290046800133	PRESSURE LINE ASSY BS6	TATA spare parts
290046800134	RETURN LINE ASSY BS6	TATA spare parts
290046800135	SUCTION LINE ASSY BS6	TATA spare parts
290046900101	DRAG LINK ASSY BS6	TATA spare parts
290046900103	DRAG LINK ASSY BS6	TATA spare parts
290046900105	DRAGLINKASSY BS6	TATA spare parts
290046900106	DRAG LINK ASSY BS6-PH2	TATA spare parts
290047100106	ASSY. CYL. WITH VALVE BS6	TATA spare parts
290047100108	CYLINDER ASSY WITH CYLINDER VALVE BS6-PH	TATA spare parts
290047109906	CYLINDER BS6	TATA spare parts
290047109907	CYLINDER	TATA spare parts
290047109908	CYLINDER BS6	TATA spare parts
290047500103	HEAT SHIELD ASSY LH BS6	TATA spare parts
290047500123	ARRESTOR ASSY REAR BS6-PH2	TATA spare parts
290047500124	CYL ASSY WITH MTG BRKT RH BS6	TATA spare parts
290047500125	CYLINDER ASSY WITH MTG BRACKET LH BS6	TATA spare parts
290047500128	BRACKET ASSY HP REGULATOR MTG BS6-PH2	TATA spare parts
290047500129	ARRESTOR ASSY REAR CYLINDER LH BS6	TATA spare parts
290047500130	ARRESTOR ASSY REAR CYLINDER RH BS6	TATA spare parts
290047500138	ARRESTOR ASSY BS6	TATA spare parts
290047508230	COMPLIANCE PLATE BS6	TATA spare parts
290047518201	COMPLIANCE PLATE	TATA spare parts
290047600101	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
290047600102	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
290047600103	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
290047600104	FUEL RETURN PIPE ASSY BS6	TATA spare parts
290047600105	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
290047600106	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
290047600107	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
290047600108	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
290047600109	FUEL RETURN PIPE ASSY BS6	TATA spare parts
290047600110	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
290047600111	HP PIPE ASSY CYLINDER VALVE TO CONNECTOR	TATA spare parts
290047600114	VENT PIPE ASSY BS6	TATA spare parts
290047600115	VENT PIPE ASSY BS6	TATA spare parts
290047600117	HP PIPE ASSY CONNECTOR TO REAR RH CYL BS	TATA spare parts

290047600120	VENT PIPE ASSY BS6	TATA spare parts
290047600123	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
290047600124	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
290047600125	FUEL RETURN PIPE ASSY BS6	TATA spare parts
290047600128	FUEL RETURN PIPE ASSY BS6	TATA spare parts
290047600129	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
290047600130	HP PIPE ASSY INTEGRATED FILLING UNIT TO	TATA spare parts
290047600131	HP PIPE ASSY INTEGRATED FILLING UNIT TO	TATA spare parts
290047600132	HP PIPE ASSY INTEGRATED FILLING UNIT TO	TATA spare parts
290047600133	HP PIPE ASSY INTEGRATED FILLING UNIT TO	TATA spare parts
290047600134	HP PIPE ASSY HP SOLENOID TO HP REGULATOR	TATA spare parts
290047600135	HP PIPE ASSY BS6	TATA spare parts
290047600137	HP PIPE ASSY BS6	TATA spare parts
290047600139	VENT PIPE ASSY BS6	TATA spare parts
290047600195	HP PIPE ASSY BS6-PH2	TATA spare parts
290047600196	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047600199	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047603301	BRACKET BS6	TATA spare parts
290047610106	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047610107	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047610111	HP PIPE ASSY BS6-PH2	TATA spare parts
290047610112	HP PIPE ASSY BS6-PH2	TATA spare parts
290047610116	HP PIPE ASSY BS6-PH2	TATA spare parts
290047610156	HP PIPE ASSY BS6	TATA spare parts
290047610167	HP PIPE ASSY BS6	TATA spare parts
290047610170	VENT PIPE ASSY BS6	TATA spare parts
290047610171	VENT PIPE ASSY BS6	TATA spare parts
290047610174	VENT PIPE ASSY BS6	TATA spare parts
290047610175	HP PIPE ASSY BS6	TATA spare parts
290047610176	VENT PIPE ASSY BS6	TATA spare parts
290047610177	HP PIPE ASSY BS6	TATA spare parts
290047610178	VENT PIPE ASSY BS6	TATA spare parts
290047610179	VENT PIPE ASSY BS6	TATA spare parts
290047610180	HP PIPE ASSY BS6	TATA spare parts
290047610181	HP PIPE ASSY BS6	TATA spare parts
290047610185	VENT PIPE ASSY BS6	TATA spare parts
290047610186	VENT PIPE ASSY BS6	TATA spare parts
290047610190	VENT PIPE ASSY BS6	TATA spare parts
290047610191	VENT PIPE ASSY BS6	TATA spare parts
290047610197	VENT PIPE ASSY BS6	TATA spare parts
290047610199	VENT PIPE ASSY BS6	TATA spare parts
290047620140	VENT PIPE ASSY BS6	TATA spare parts
290047620144	VENT PIPE ASSY BS6	TATA spare parts
290047620145	VENT PIPE ASSY BS6	TATA spare parts
290047620146	VENT PIPE ASSY BS6	TATA spare parts
290047620147	VENT PIPE ASSY BS6	TATA spare parts
290047620166	VENT PIPE ASSY BS6	TATA spare parts

290047620168	VENT PIPE ASSY BS6	TATA spare parts
290047620169	VENT PIPE ASSY BS6	TATA spare parts
290047620171	VENT PIPE ASSY BS6	TATA spare parts
290047620174	VENT PIPE ASSY BS6	TATA spare parts
290047620175	VENT PIPE ASSY BS6	TATA spare parts
290047620176	HP PIPE ASSY BS6	TATA spare parts
290047620193	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047630104	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047630116	VENT PIPE ASSY BS6	TATA spare parts
290047630118	VENT PIPE ASSY BS6	TATA spare parts
290047630131	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047630136	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047630144	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047630156	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047630157	VENT PIPE ASSY BS6	TATA spare parts
290047630163	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047630187	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047630190	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047630301	VENT PIPE ASSY BS6-PH2	TATA spare parts
290047700101	BRACKET FUEL FILTER MTG BS6	TATA spare parts
290047800101	HP PIPE ASSY RECEPTACLE TO 3-WAY VALVE	TATA spare parts
290047800102	HP PIPE ASSY T-CONN TO VALVE	TATA spare parts
290047800103	HP PIPE ASSY	TATA spare parts
290047800104	HP PIPE ASSY 3-WAY VALVE TO HP GAUGE	TATA spare parts
290047800105	HP PIPE ASSY T-CONN TO VALVE	TATA spare parts
290047800106	HP PIPE ASSY	TATA spare parts
290047800107	HP PIPE ASSY	TATA spare parts
290047800108	HP PIPE ASSY	TATA spare parts
290047800109	HP PIPE ASSY	TATA spare parts
290047800110	HP PIPE ASSY	TATA spare parts
290047800111	HP PIPE ASSY	TATA spare parts
290047800112	VENT PIPE ASSY	TATA spare parts
290047800113	VENT PIPE ASSY	TATA spare parts
290047800114	VENT PIPE ASSY	TATA spare parts
290047800116	VENT PIPE ASSY	TATA spare parts
290047800117	VENT PIPE ASSY	TATA spare parts
290047800118	VENT PIPE ASSY	TATA spare parts
290047800119	HP PIPE ASSY	TATA spare parts
290047800120	HP PIPE ASSY HP SOLENOID TO HP REGULATOR	TATA spare parts
290047800121	VENT PIPE ASSY	TATA spare parts
290047800122	VENT PIPE ASSY	TATA spare parts
290047808201	COMPLIANCE PLATE BS6-PH2	TATA spare parts
290047997801	O-RING 3.35 X 1 78 BS6	TATA spare parts
290047997804	O-RING 17X2 BS6	TATA spare parts
290047998701	SPRING BS6	TATA spare parts
290047999901	NON RETURN VALVE BS6	TATA spare parts
290049100103	CLAMP ASSY EGP MTG BS6	TATA spare parts

290049100104	CLAMP ASSY EGP MTG BS6	TATA spare parts
290049100107	PIPE ASSY DPS SENSOR INTAKE BS6	TATA spare parts
290049100108	PIPE ASSY DPS SENSOR REAR BS6	TATA spare parts
290049100109	CLAMP ASSY-CATCON MTG BS6	TATA spare parts
290049100110	PIPE ASSY-DPS SENSOR-REAR BS6	TATA spare parts
290049100111	PIPE ASSY-DPS SENSOR-INTAKE BS6	TATA spare parts
290049100112	CLAMP ASSY-CATCON MTG BS6	TATA spare parts
290049103301	BRACKET CATCON MTG BS6	TATA spare parts
290049104201	CLAMP EGP MTG BS6	TATA spare parts
290049107101	EXHAUST FLANGE BS6	TATA spare parts
290049200101	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
290049200106	BRACKET ASSY EGP MTG BS6	TATA spare parts
290049200108	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
290049200110	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
290049200120	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
290049200121	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
290049200122	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
290049200123	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
290049200130	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
290049200131	EXHAUST PIPE ASSY INTERMEDIATE BS6	TATA spare parts
290049200135	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
290049200136	EXH PIPE ASSY W/FLEX BELLOW FRT BS6-PH2	TATA spare parts
290049200147	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6-P	TATA spare parts
290049200148	HEAT SHIELD ASSY	TATA spare parts
290049203318	CLAMP EXHAUST MTG BS6	TATA spare parts
290049203319	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
290049203322	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
290049203324	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
290049203325	CLAMP BS6	TATA spare parts
290049203328	BRACKET FRONT PIPE MTG BS6-PH2	TATA spare parts
290049204203	PIPE CLAMP FRONT BS6	TATA spare parts
290049204204	PIPE CLAMP FRONT BS6	TATA spare parts
290049205807	GROMMET BS6	TATA spare parts
290049207705	RUBBER PACKING UREA TANK BS6	TATA spare parts
290049208201	U-BOLT BS6	TATA spare parts
290049604202	CLAMP BS6	TATA spare parts
290049990116	KIT-EXHAUST PIPE HEAT SHIELD ASSY	TATA spare parts
290049990117	KIT-EXHAUST TAIL PIPE HEAT SHIELD	TATA spare parts
290054500101	BATTERY CUT OFF SWITCH SUPPORT	TATA spare parts
290054503303	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
290054504901	SWITCH ENGINE LAMP BS6	TATA spare parts
290054504902	SWITCH ABS DIAGNOSTICS BS6	TATA spare parts
290054600124	WIRING HARNESS TAIL	TATA spare parts
290054600125	WIRING HARNESS MAIN	TATA spare parts
290054600127	BATTERY CABLE -VE	TATA spare parts
290054600129	WIRING HARNESS ENGINE BS6	TATA spare parts
290054600135	BATTERY CABLE +VE	TATA spare parts

290054600136	BATTERY CABLE +VE	TATA spare parts
290054600141	WIRING HARNESS SIDE MARKER LAMP BS6	TATA spare parts
290054600142	WIRING HARNESS SIDE MARKER LAMP	TATA spare parts
290054600143	WIRING HARNESS SIDE MARKER LAMP	TATA spare parts
290054600145	WIRINGHARNESSSIDEMARKERLAMP BS6	TATA spare parts
290054600146	BATTERY CABLE +VE	TATA spare parts
290054600149	BATTERY CABLE +VE	TATA spare parts
290054600150	WIRING HARNESS TAIL	TATA spare parts
290054600151	WIRING HARNESS SIDE MARKER LAMP	TATA spare parts
290054600156	WIRING HARNESS-SIDE MARKER LAMP BS6	TATA spare parts
290054600158	WIRING HARNESS SENSOR	TATA spare parts
290054600160	WIRING HARNESS ENGINE BS6	TATA spare parts
290054600161	WIRING HARNESS MAIN BS6	TATA spare parts
290054600165	BATTERY CABLE -VE BS6	TATA spare parts
290054600166	WIRING HARNESS MAIN BS6	TATA spare parts
290054600167	BRACKET ASSY CONNECTOR MTG BS6-PH2	TATA spare parts
290054600168	WIRING HARNESS INJECTOR BS6	TATA spare parts
290054600174	WIRING HARNESS SIDE MARKER LAMP BS6	TATA spare parts
290054600176	WIRING HARNESS TAIL BS6	TATA spare parts
290054600177	WIRING HARNESS TAIL	TATA spare parts
290054600185	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
290054600189	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
290054600199	WIRING HARNESS CAB TILT SWITCH BS6-PH2	TATA spare parts
290054603302	BRACKET BS6	TATA spare parts
290054603303	BRACKET INTERFACE CONNECTOR MTG BS6	TATA spare parts
290054603304	BRACKET INTERFACE CONNECTOR MTG BS6	TATA spare parts
290054603305	BRACKET INTERFACE CONNECTOR MTG BS6	TATA spare parts
290054603306	BRACKETINTERFACECONNECTORMTG BS6	TATA spare parts
290054610101	WIRING HARNESS TAIL BS6	TATA spare parts
290054610102	WIRING HARNESS MAIN BS6	TATA spare parts
290054610105	WIRINGHARNESSTAIL BS6	TATA spare parts
290054610106	WIRING HARNESS TAIL BS6	TATA spare parts
290054610107	WIRINGHARNESSTAIL BS6	TATA spare parts
290054610109	WIRINGHARNESSTAIL BS6	TATA spare parts
290054610111	WIRING HARNESS SENSOR BS6	TATA spare parts
290054610113	WIRING HARNESS TAIL BS6	TATA spare parts
290054610114	PIGTAIL ENGINE LAMP BS6	TATA spare parts
290054610115	WIRING HARNESS SIDE MARKER LAMP BS6	TATA spare parts
290054610116	BATTERY CABLE +VE BS6	TATA spare parts
290054610118	WIRING HARNESS TAIL BS6	TATA spare parts
290054610120	WIRING HARNESS REVERSE PARK ASSIST BS6	TATA spare parts
290054610123	WIRING HARNESS TAIL BS6	TATA spare parts
290054610127	WIRING HARNESS SIDE BLINKER BS6-PH2	TATA spare parts
290054610129	WIRING HARNESS SENSOR BS6	TATA spare parts
290054610130	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
290054610131	WIRING HARNESS MAIN BS6	TATA spare parts
290054610132	WIRING HARNESS MAIN BS6	TATA spare parts

290054610133	WIRING HARNESS MAIN BS6	TATA spare parts
290054610135	WIRING HARNESS REVERSE PARK ASSIST BS6	TATA spare parts
290054610137	BRACKET ASSY CONNECTOR MTG BS6-PH2	TATA spare parts
290054610140	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
290054620112	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
290054620114	WIRING HARNESS REAR CHASSIS	TATA spare parts
290054630110	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
290054630112	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
290054630122	WIRING HARNESS MAIN BS6	TATA spare parts
290054630123	WIRING HARNESS REAR CHASSIS	TATA spare parts
290054630125	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
290054630126	WIRING HARNESS FRONT CHASSIS BS6 -PH2	TATA spare parts
290054630140	PIGTAIL BS6-PH2	TATA spare parts
290058902602	PULLER GEAR BOX REAR HALF HSG BS6-PH2	TATA spare parts
290058902603	REAR HOUSING FITMENT TOOL BS6-PH2	TATA spare parts
29006000002R40	ASSY. CAB WITHOUT FITMENTS BS4	TATA spare parts
29006000002R40BRBL	CAB PARTIALLY FITTED LPT1412 BR BLW	TATA spare parts
29006000002R40GBBL	CAB PARTIALLY FITTED LPT1412 GB BLW	TATA spare parts
29006000003R40	ASSY. CAB WITHOUT FITMENT LPT1109 BS3	TATA spare parts
29006000003R40BRBL	CAB PARTIALLY FITTED LPT1109 BR BLW	TATA spare parts
29006000003R40GBBL	CAB PARTIALLY FITTED LPT1109 GB BLW	TATA spare parts
29006000004R40	ASSY BODY SHELL PAINTED	TATA spare parts
29006000005R40	ASSY BODY FITTED	TATA spare parts
29006000012R40	ASSY. CAB WITHOUT FITMENT LPT1109 BS3	TATA spare parts
29006000012R40BRBL	CAB PARTIALLY FITTED LPT1109 BR BLW	TATA spare parts
29006000012R40GBBL	CAB PARTIALLY FITTED LPT1109 GB BLW	TATA spare parts
29006000019R40	ASSEMBLY BODY FITTED	TATA spare parts
29006000019R40BRBL	CAB PARTIALLY FITTED LPT1212 BR BLW	TATA spare parts
29006000019R40GBBL	CAB PARTIALLY FITTED LPT1212 GB BLW	TATA spare parts
29006000023R40	ASSEMBLY BODY FITTED	TATA spare parts
29006000026R40	ASSEMBLY BODY FITTED	TATA spare parts
29006000026R40AWBL	CAB PARTIALLY FITTED LPT1512 AW BLW	TATA spare parts
29006000026R40BRBL	CAB PARTIALLY FITTED LPT1512 BR BLW	TATA spare parts
29006000028R40	PARTIALLY FITTED CAB W/O ELECTICALS & CO	TATA spare parts
29006000040R40	CAB PARTIALLY FITTED LPT1412 CNG	TATA spare parts
29006000046R40	1412G LPT PARTIAL FITTED CABIN BS6	TATA spare parts
29006000050R40	ASSEMBLY BODY FITTED	TATA spare parts
29006000051R40	1412G LPT PARTIAL FITTED CABIN BS6	TATA spare parts
29006000064R40	PARTIALLY FITTED CAB W/O ELECTICALS	TATA spare parts
29006000159R40	PARTIALLY FITTED CAB WITHOUT ELECTRICALS	TATA spare parts
29006000168R40	LPT 1412 PARTIAL FITTED CABIN BS6	TATA spare parts
29006000169R40	PARTIAL FITTED CAB LPT 1212 BS6	TATA spare parts
29006000174R40	1512 LPT 125B6M5 PARTIAL FITTED CAB BS6	TATA spare parts
29006000177R40	LPT 1512 PARTIAL FITTED CAB BS6	TATA spare parts
29006000188R40	LPT 1512 PARTIAL FITTED CAB BS6	TATA spare parts
29006000191R40	PARTIALLY FITTED CAB W/O ELECTICALS	TATA spare parts
29006000198R40	1512 LPT SLR48CBC 125B6M5_CAB/COWL BS6	TATA spare parts

29006000233R40	PARTIAL FITTED CABIN FOR LPT 1815 BS6	TATA spare parts
29006004M10175	BODY SHELL ASSY BS6-PH2	TATA spare parts
29006004M10178	BODY SHELL ASSY BS6-PH2	TATA spare parts
29006004M10179	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
29006010M10107	ASSY PANEL INNER TOP BS6-PH2	TATA spare parts
29006010M10108	SUPPORTASSY FRONTGRILL BS6-PH2	TATA spare parts
29006010M10146	INNER PANNEL ASSY TOP WITH REINFORCEMENT	TATA spare parts
29006010M10181	INNER PANNEL ASSY TOP WITH GUSSET BS6-PH	TATA spare parts
29006013M10171	INNER PANEL & FIREWALL ASSY BS6-PH2	TATA spare parts
29006100M10295	SUBSTRUCTURE ASSY WITH FLR & STEP PANEL	TATA spare parts
29006100M10296	SUBSTRUCTURE ASSY WITH FLOOR BS6-PH2	TATA spare parts
29006100M10301	SUBSTRUCTUREASSYWITHFLR&STEPPANEL BS6-P	TATA spare parts
29006100M10302	SUB STRUCTURE ASSY WITH FLOOR BS6-PH2	TATA spare parts
29006101M10119	SUBSTRUCTURE ASSY WITH FLOOR BS6-PH2	TATA spare parts
29006101M10120	SUBSTRUCTURE ASSY WITH FLR & STEP PANEL	TATA spare parts
29006160M10191	STEP PANEL ASSY INNER-LH BS6-PH2	TATA spare parts
29006160M10192	STEP PANEL ASSY INNER-RH BS6-PH2	TATA spare parts
29006300M10112	SIDE WALL ASSY LH BS6-PH2	TATA spare parts
29006300M10113	SIDE WALL ASSY RH BS6-PH2	TATA spare parts
29006300M10116	SIDE WALL ASSY LH BS6-PH2	TATA spare parts
29006300M10118	SIDE WALL ASSY RH BS6-PH2	TATA spare parts
29006300M10129	SIDE WALL ASSY LH BS6-PH2	TATA spare parts
29006300M10130	SIDE WALL ASSY RH BS6-PH2	TATA spare parts
29006470M10103	REAR WALL ASSY BS6-PH2	TATA spare parts
29006470M10107	REAR WALL ASSY BS6-PH2	TATA spare parts
29006470M10108	REAR WALL ASSY BS6-PH2	TATA spare parts
29006570M10103	ROOF ASSY WITH ROOF BOW BS6-PH2	TATA spare parts
29006570M10105	ASSY ROOF BS6-PH2	TATA spare parts
29006570M10108	FRAME ASSY ROOF BOW BS6-PH2	TATA spare parts
290070000104	LOAD BODY ASSY BS6-PH2	TATA spare parts
290070100108	SUPD ASSY BS6-PH2	TATA spare parts
290070100110	SUPD ASSY RH BS6-PH2	TATA spare parts
290070100111	SUPD ASSY LH BS6-PH2	TATA spare parts
29007220M10117	DOOR SHELL ASSY LH BS6-PH2	TATA spare parts
29007220M10118	DOOR SHELL ASSY RH BS6-PH2	TATA spare parts
29007220M10119	OUTER PANEL ASSY FRONT DOOR LH BS6-PH2	TATA spare parts
29007220M10120	OUTER PANEL ASSY FRONT DOOR RH BS6-PH2	TATA spare parts
29007220M10121	INNER PANEL ASSY FRONT DOOR LH BS6-PH2	TATA spare parts
29007220M10122	INNER PANEL ASSY FRONT DOOR RH BS6-PH2	TATA spare parts
29007220M10131	REINFORCEMENT ASSY OUTER-LH BS6-PH2	TATA spare parts
29007220M10132	REINFORCEMENT ASSY OUTER-RH BS6-PH2	TATA spare parts
29007510M10116	CENTRE FLAP ASSY WITH HINGES BS6-PH2	TATA spare parts
2900D1B0475001	FRONT FLAP AND BONNET ASSY BS6-PH2	TATA spare parts
2900D9X0160002	BIW ASSY WITH DOORS-MFG BS6-PH2	TATA spare parts
2900D9Y0160001	PAINTED BODY SHELL BS6-PH2	TATA spare parts
2900D9Y0160002	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
2900D9Y0160003	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts

2900D9Y0160004	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
2900D9Y0160006	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
2900D9Y0160007	PAINTED BODY SHELL-MFG	TATA spare parts
2900D9Y0160010	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
2900D9Z0160020	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2900D9Z0160028	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2900D9Z0160030	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2900D9Z0160031	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2900D9Z0160032	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2900D9Z0160033	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2900D9Z0160036	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2900D9Z0160038	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2900D9Z0160039	FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2900D9Z0160040	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2900D9Z0160052	FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2900D9Z0160062	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2900D9Z0160067	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2900D9Z0160094	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
2910011209	SCREW	TATA spare parts
2910011242	SCREW	TATA spare parts
2910012203	SCREW	TATA spare parts
2910021199	SCREW	TATA spare parts
2910022196	SCREW	TATA spare parts
2910022199	SCREW	TATA spare parts
2910061242	HEX SCREW	TATA spare parts
2910501189	CSK SCREW	TATA spare parts
2910501196	CSK SCREW	TATA spare parts
2910501203	CSK SCREW	TATA spare parts
291104827229	ASSY STEERING GEAR BOX	TATA spare parts
291104827233	BEVEL BOX	TATA spare parts
2911061157	SCREW	TATA spare parts
2911061196	HEX SCREW	TATA spare parts
2911061201	HEX SCREW	TATA spare parts
2911062193	SCREW	TATA spare parts
2911062196	SCREW	TATA spare parts
2911062199	HEX SCREW	TATA spare parts
2911201701	HOLLOW SCREW	TATA spare parts
2911205701	HOLLOW SCREW	TATA spare parts
2911232700	HOLLOW SCREW	TATA spare parts
2911271701	SCREW PLUG	TATA spare parts
2912031197	SCREW	TATA spare parts
2912031207	SCREW	TATA spare parts
291204211051	ASSY RADIATOR	TATA spare parts
291208217266	SHIM FOR WATER PUMP	TATA spare parts
291208217267	SHIM FOR WATER PUMP	TATA spare parts
291209211023	AIR FILTER MOUNTING BRACKET FOR WT	TATA spare parts
291209212013	BRACKET (SNORKEL MOUNTING)	TATA spare parts



291209214025	HEXAGONAL ROD (5MM)	TATA spare parts
291209214026	HEXAGONAL ROD (85.5MM)	TATA spare parts
291287117033	VISO HAND PUMP	TATA spare parts
291287117034	VISO RESERVOIR(NON-CAPACITY 27ML)	TATA spare parts
291287117035	SPRAY FLUID REFILL CAN	TATA spare parts
291288117009	SPRAY NOZZLE STRAIGHT 100MM	TATA spare parts
291288117010	NYLON TUBE(4MM OD)AND OLIVES	TATA spare parts
291293214177	RUBBER HOSE	TATA spare parts
291293216053	RUBBER HOSE	TATA spare parts
291293216421	A/FILTER ELEMENT	TATA spare parts
291293216423	A/FILTER ELEMENT PRIMARY	TATA spare parts
291301324780	ASSY. CONNECTING LINK	TATA spare parts
291302477644	ASSY. BULL NOSE WITH EXCESS FLOW VALVE	TATA spare parts
291305293054	ASSY. BRACKET (CLUTCH BOOSTER MTG)	TATA spare parts
291305460251	INTERMEDIATE SHAFT	TATA spare parts
291305467447	STEERING PUMP	TATA spare parts
291306473467	ASSY MOUNTING BRACKET (FOR AFC GSOV)	TATA spare parts
291306474927	NON RETURN VALVE	TATA spare parts
291307477174	CYLINDER VALVE 1-1/4 INCH	TATA spare parts
291308357674	FORWARD CROWN WHEEL & PINION ASSY	TATA spare parts
291308357675	REAR CROWN WHEEL & PINION ASSY	TATA spare parts
291308357675DF	CROWN PINION SET 5.83-RR RWD-LPS4923 BS2	TATA spare parts
291308357675DFPN	PINION OF CWP 35/6-5.83-RR RWD-4923 BS2	TATA spare parts
291308461630	ASSY STG GEAR BOX LHD	TATA spare parts
2915011007	HEX NUT	TATA spare parts
2915012007	HEX NUT	TATA spare parts
291603037690	AXLE SHAFT ASSLY	TATA spare parts
2916080015	RETAINING RING	TATA spare parts
291608024697	ADAPTOR BREATHER	TATA spare parts
291608027115	ASSY GEAR BOX	TATA spare parts
2916080907	RETAINING RING	TATA spare parts
291610022458	ADAPTOR HOUSING BLOCK G1150	TATA spare parts
291610027159	PTO	TATA spare parts
291610027160	PTO ADAPTATION PARTS	TATA spare parts
291610027161	OIL COOLER VALVE BLOCK	TATA spare parts
291610027162	OIL COOLER PIPE	TATA spare parts
291610027360	ASSY EATON FS0 8406 A GEAR BOX	TATA spare parts
291610027460	ASSY PTO IPH	TATA spare parts
291613024291	LEVER	TATA spare parts
2916580003	WASHER	TATA spare parts
2916690009	WASHER	TATA spare parts
2916710601	WASHER	TATA spare parts
2916710602	PACKING RING	TATA spare parts
2916710603	PACKING RING	TATA spare parts
2916710605	PACKING RING	TATA spare parts
2916710607	PACKING RING	TATA spare parts
2916710609	PACKING RING	TATA spare parts

2916710611	PACKING RING	TATA spare parts
2916710613	PACKING RING	TATA spare parts
291693022286	GEAR SHIFT LEVER	TATA spare parts
291693037219	CROWN WHEEL & PINION 41/6	TATA spare parts
291693053469	KNOB	TATA spare parts
2917031150	PIN	TATA spare parts
2917500059	PIN FOR LINK	TATA spare parts
291794427185	PIPE AIR COMP TO HOSE	TATA spare parts
291794427186	HOSE PIPE	TATA spare parts
2920000177	KEY	TATA spare parts
292011116180	ELECTRICAL INSULATING MATT 2MM IS15652	TATA spare parts
292014067334	GLOVES INFLATOR KIT CG-117- CATU MAKE	TATA spare parts
292014077555	LEATHER OVER GLOVES SIZE 9 CG-96* CATU	TATA spare parts
292018010664	PASTIC CONE RED SIZE H12	TATA spare parts
292018010665	Plastic Cone Yellow	TATA spare parts
292018010666	Plastic Cone Green	TATA spare parts
292018040975	SALISBURY 51511 DI-ELECTRIC OVER SHOES 9	TATA spare parts
292018040976	SALISBURY 51511 DI-ELECTRIC OVER SHOES10	TATA spare parts
292021014228	LPTA 5252 TC 12X12 VEHICLE ASSY.	TATA spare parts
292107029189	SPEEDOMETER W-0.935 -LPT2523TC	TATA spare parts
292109022305	MECHANICAL SPEEDOMETER 140 DIA(0.98)	TATA spare parts
292109022306	ELECTRONIC SPEEDOMETER 140 DIA (0.98)	TATA spare parts
292110993789	KIBES 32 RUNTIME SOFTWARE WITH DONGLE	TATA spare parts
292110993790	K LINE ADAPTER	TATA spare parts
292113217038	KIBES 32 RUNTIME SOFTWARE WITH DONGLE	TATA spare parts
292113217039	K-LINE ADAPTER	TATA spare parts
292185040085	HALOGEN BULB 60/55W ESTAT	TATA spare parts
292205437265	VOITH RETARDER KIT	TATA spare parts
292270320971	REAR AIR SUSPENSION KIT	TATA spare parts
292822014039	SCROLL AIR COMPRESSOR WITH FILTER KIT	TATA spare parts
293215007024	MISALIGNMENT INSTRUMENT	TATA spare parts
293942990110	KIT-CAMSHAFT LH BS6	TATA spare parts
293942990111	KIT-CAMSHAFT RH BS6	TATA spare parts
29500025	SEALRING EXTERNAL 61.4 MM OD	TATA spare parts
29500034	PLUG ASSEMBLY PRESSURE TAP	TATA spare parts
29500063	ROLLER STATOR	TATA spare parts
29500064	SPRING STATOR	TATA spare parts
29500066	WASHER STATOR THRUST FRONT	TATA spare parts
29500068	RACE STATOR	TATA spare parts
29500571	GEAR SET P2 PINION	TATA spare parts
29500573	GEAR SET P1 PINION	TATA spare parts
29500616	BOLT T-HEAD M8 X 1.25 X 25	TATA spare parts
29500667	BOLT M8 X 1.25 X 20	TATA spare parts
29500689	RING RETAINING 159.2 MM OD	TATA spare parts
29500699	RING RETAINING INTERNAL 190.2 MM OD	TATA spare parts
29500767	GEAR P2 SUN	TATA spare parts
29500768	BEARING ASSEMBLY THRUST	TATA spare parts

29500822	PIN RETENTION 3 OD X 43 MM	TATA spare parts
29500823	PIN RETENTION 2.5 OD X 40 MM	TATA spare parts
29500908	WASHER PUMP THRUST	TATA spare parts
29500939	PISTON ASSEMBLY LOCKUP	TATA spare parts
29500963	SPRING MAIN REGULATOR	TATA spare parts
29501135	PIN DOWEL 10 X 32 MM	TATA spare parts
29501339	NUT M8 X 1.25	TATA spare parts
29502001	GEAR P3 SUN	TATA spare parts
29502037	WASHER P2 THRUST	TATA spare parts
29502040	WASHER P1 THRUST	TATA spare parts
29502275	SHIM CONVERTER SELECTIVE 0.715 MM (0.	TATA spare parts
29502276	SHIM CONVERTER SELECTIVE 0.485 MM (0.	TATA spare parts
29502277	SHIM CONVERTER SELECTIVE 0.254 MM (0.	TATA spare parts
29502439	O-RING 66.3 MM ID	TATA spare parts
29502831	GEAR SET P3 PINION	TATA spare parts
29503066	GEAR RING P2 PLANETARY	TATA spare parts
29503067	GEAR RING P3 PLANETARY	TATA spare parts
29503084	GEAR ASSEMBLY SUN COMPLETE	TATA spare parts
29503196	BUSHING	TATA spare parts
29503197	SEALRING LOCKUP PISTON 86.9 MM ID	TATA spare parts
29503208	O-RING 34.6 MM ID	TATA spare parts
29503209	RING RETAINING INTERNAL	TATA spare parts
29503215	SPRING ASSEMBLY RETURN	TATA spare parts
29503218	SHIM SELECTIVE 0.27 MM (0.01 INCH)	TATA spare parts
29503219	SHIM SELECTIVE 0.54 MM (0.02 INCH)	TATA spare parts
29503220	SHIM SELECTIVE 0.81 MM (0.03 INCH)	TATA spare parts
29503221	SHIM SELECTIVE 1.08 MM (0.04 INCH)	TATA spare parts
29503222	SHIM SELECTIVE 1.35 MM (0.05 INCH)	TATA spare parts
29503223	SHIM SELECTIVE 1.62 MM (0.06 INCH)	TATA spare parts
29503224	SHIM SELECTIVE 1.89 MM (0.07 INCH)	TATA spare parts
29503225	BEARING ASSEMBLY THRUST	TATA spare parts
29503239	RING RETAINING	TATA spare parts
29503270	HOUSING CONVERTER	TATA spare parts
29503283	GASKET CASE	TATA spare parts
29503288	GASKET CONVERTER HOUSING	TATA spare parts
29503294	SUPPORT ASSEMBLY FRONT	TATA spare parts
29503382	O-RING 14.0 MM ID	TATA spare parts
29503383	O-RING 15.6 MM ID	TATA spare parts
29503384	O-RING 18.8 MM ID	TATA spare parts
29503663	STOP MAIN REGULATOR	TATA spare parts
29503714	SEALRING ROTATING	TATA spare parts
29503843	RETAINER SPEED SENSOR	TATA spare parts
29503974	SEALRING KIT	TATA spare parts
29503979	TURBINE ASSEMBLY COMPLETE	TATA spare parts
29503980	PLATE ASSEMBLY STATOR THRUST	TATA spare parts
29505511	SPACER BEARING	TATA spare parts
29505617	WASHER TANGED THRUST BEARING NO. 2	TATA spare parts

29505681	SHIM TURBINE SELECTIVE 4.203 MM (0.16	TATA spare parts
29505682	SHIM TURBINE SELECTIVE 4.381 MM (0.17	TATA spare parts
29505683	SHIM TURBINE SELECTIVE 4.559 MM (0.17	TATA spare parts
29505684	SHIM TURBINE SELECTIVE 4.736 MM (0.18	TATA spare parts
29505685	SHIM TURBINE SELECTIVE 4.914 MM (0.193 I	TATA spare parts
29505686	SHIM TURBINE SELECTIVE 5.092 MM (0.200 I	TATA spare parts
29505688	SHIM TURBINE SELECTIVE 4.000 MM (0.15	TATA spare parts
29505891	RING RETAINING EXTERNAL	TATA spare parts
29505905	PLATE WEAR	TATA spare parts
29506338	PISTON C5 CLUTCH	TATA spare parts
29506446	STATOR AND CAM ASSEMBLY	TATA spare parts
29507437	O-RING 75.9 MM ID	TATA spare parts
29507456	SPRING CONVERTOR REGULATOR	TATA spare parts
29507462	VALVE CONVERTOR REGULATOR	TATA spare parts
29507528	SEAL ASSEMBLY OIL	TATA spare parts
29507709	SPRING 11.48 ID X 53.20 MM	TATA spare parts
29507755	BRACKET OIL FILL TUBE	TATA spare parts
29507757	BRACKET CONVERTER SHIPPING	TATA spare parts
29507780	RETAINER ASSEMBLY SPRING	TATA spare parts
29507796	PLUG ASSEMBLY FRONT COOLER PORTS	TATA spare parts
29507823	SEAL FILL TUBE	TATA spare parts
29507922	INDICATOR OIL LEVEL	TATA spare parts
29508255	DRUM ROTATING CLUTCH	TATA spare parts
29509732	PLUG CONVERTER END	TATA spare parts
29510682	SEALRING LIP-TYPE INTERNAL 140.3 MM O	TATA spare parts
29511377	PUMP ASSEMBLY CONVERTER COMPLETE	TATA spare parts
29511406	WASHER P3 THRUST	TATA spare parts
29512790	PLUG TACHOGRAPH	TATA spare parts
29512791	WASHER PLUG	TATA spare parts
29512875	O-RING 12.3 MM ID	TATA spare parts
29514182	PLUG FLOW VALVE	TATA spare parts
29514364	RING RETAINING EXTERNAL	TATA spare parts
29514788	PUMP ASSEMBLY CONVERTER COMPLETE	TATA spare parts
29514804	BACKPLATE LOCKUP-CLUTCH	TATA spare parts
29515692	SPRING RETARDER VALVE	TATA spare parts
29516030	PIN DOWEL 6 X 34.5 MM	TATA spare parts
29516175	PLATE STIFFENING	TATA spare parts
29516484	SLEEVE GROUND	TATA spare parts
29519129	PLUG ASSEMBLY SHIPPING	TATA spare parts
29519130	PLUG SHIPPING	TATA spare parts
29519212	SCREW TAPPING M8 X 25	TATA spare parts
29524442	PLATE OIL TRANSFER	TATA spare parts
29524447	COVER FILTER	TATA spare parts
29524449	GASKET FILTER COVER	TATA spare parts
29527781	SHAFT MAIN	TATA spare parts
29528323	ROTOR RETARDER	TATA spare parts
29529310	SPRING	TATA spare parts

29530105	SENSOR ASSEMBLY OIL LEVEL	TATA spare parts
29530328	PLUG ASSEMBLY SEAL EXPANDER	TATA spare parts
29530448	HUB C1 DRIVE	TATA spare parts
29530449	HUB C2 DRIVE	TATA spare parts
29530450	SHAFT ASSEMBLY TURBINE	TATA spare parts
29531001	BUSHING ROTATING CLUTCH HUB 99.15 MM I	TATA spare parts
29531003	BUSHING P1 SUN GEAR DRIVE HUB 68.164 M	TATA spare parts
29531004	BUSHING 43.104 MM ID	TATA spare parts
29531005	BUSHING TURBINE SHAFT 20 MM ID	TATA spare parts
29531022	CLIP	TATA spare parts
29533975	BUSHING 75.15 MM ID	TATA spare parts
29533980	BRACKET TEMPERATURE SENSOR	TATA spare parts
29534362	PLUG ASSEMBLY OIL DRAIN	TATA spare parts
29534493	HUB ASSEMBLY ROTATING CLUTCH COMPLETE	TATA spare parts
29534574	PLATE C1 CLUTCH PRESSURE	TATA spare parts
29535213	PLATE RETAINING	TATA spare parts
29535219	BOLT M14 X 2 X 70	TATA spare parts
29535518	O-RING 13.0 MM ID	TATA spare parts
29535581	PLUG CONVERTER END	TATA spare parts
29535595	COVER ASSEMBLY	TATA spare parts
29536230	PLUG ACCUMULATOR	TATA spare parts
29536334	PLATE C1 CLUTCH FRICTION	TATA spare parts
29536335	PLATE C2 CLUTCH FRICTION	TATA spare parts
29536336	PLATE C3 CLUTCH FRICTION	TATA spare parts
29536337	PLATE C5 CLUTCH FRICTION	TATA spare parts
29536343	PLATE C1 CLUTCH REACTION	TATA spare parts
29536344	PLATE C2 CLUTCH REACTION	TATA spare parts
29536346	PLATE C5 CLUTCH REACTION	TATA spare parts
29536564	BOLT M6 X 1.0 X 45	TATA spare parts
29536567	FERRULE VITON	TATA spare parts
29536651	ROTATING CLUTCH	TATA spare parts
29536727	COVER RETARDER HOUSING	TATA spare parts
29536728	GASKET RETARDER HOUSING COVER	TATA spare parts
29536730	VALVE RETARDER	TATA spare parts
29536742	GASKET RETARDER HOUSING	TATA spare parts
29536743	STATOR HOUSING	TATA spare parts
29536765	MANIFOLD JUMPER	TATA spare parts
29536766	GASKET JUMPER MANIFOLD	TATA spare parts
29536988	COVER SENSOR SHIPPING	TATA spare parts
29537066	GASKET SUCTION FILTER	TATA spare parts
29537369	SOLENOID ASSEMBLY	TATA spare parts
29537507	BOLT M8 X 1.25 X 20	TATA spare parts
29537755	PISTON C1	TATA spare parts
29537867	GASKET ADAPTER HOUSING	TATA spare parts
29537922	CARRIER P1 PLANETARY	TATA spare parts
29537931	SPINDLE P1 PLANETARY	TATA spare parts
29537932	SPINDLE P2 PLANETARY	TATA spare parts

29537934	SPINDLE P3 PLANETARY	TATA spare parts
29537936	CARRIER AND BUSHING ASSEMBLY	TATA spare parts
29537939	RING P1 INDEXING	TATA spare parts
29537940	RING P2 INDEXING	TATA spare parts
29537941	RING P3 INDEXING	TATA spare parts
29538343	PLATE THRUST GEAR	TATA spare parts
29538448	SEALRING KIT	TATA spare parts
29538477	STOP CONVERTOR REGULATOR	TATA spare parts
29538532	BACKPLATE ASSEMBLY CLUTCH	TATA spare parts
29539665	BACKPLATE C1	TATA spare parts
29539807	RING RETAINING EXTERNAL 48.0 MM ID	TATA spare parts
29540988	WASHER BELLEVILLE	TATA spare parts
29540989	SEAL ASSEMBLY OIL	TATA spare parts
29540990	SHAFT ASSEMBLY OUTPUT	TATA spare parts
29540992	RING RETAINING EXTERNAL	TATA spare parts
29540996	NUT BEARING RETAINER	TATA spare parts
29541000	CARRIER P3 PLANETARY	TATA spare parts
29541274	BOLT M10 X 1.5 X 100	TATA spare parts
29541286	BOLT M10 X 1.5 X 55	TATA spare parts
29541563	BEARING ASSEMBLY P3 ROLLER	TATA spare parts
29541564	BEARING ASSEMBLY ROLLER	TATA spare parts
29541565	BEARING ASSEMBLY ROLLER	TATA spare parts
29541590	CONNECTOR 2 WAY	TATA spare parts
29541880	BOLT M10 X 1.5 X 192	TATA spare parts
29541881	BOLT M10 X 1.5 X 182	TATA spare parts
29541882	BOLT M12 X 1.75 X 190	TATA spare parts
29541883	BOLT M12 X 1.75 X 130	TATA spare parts
29541889	SEAL ASSEMBLY OIL	TATA spare parts
29541897	SOLENOID VARIABLE BLEED CENH	TATA spare parts
29542025	GEAR SET ASSEMBLY CYCLOIDAL	TATA spare parts
29542026	BUSHING GEAR SET	TATA spare parts
29542084	SEAL	TATA spare parts
29542338	GEAR P1 RING	TATA spare parts
29542354	HOUSING ASSEMBLY PUMP	TATA spare parts
29542376	HOUSING ASSEMBLY RETARTER	TATA spare parts
29542516	SOLENOID AND CONNECTOR ASSEMBLY VARIABLE	TATA spare parts
29542572	VALVE REGULATOR	TATA spare parts
29542573	VALVE RELAY	TATA spare parts
29542748	PLATE C3 CLUTCH REACTION	TATA spare parts
29542752	HOUSING CLUTCH C4	TATA spare parts
29542753	PISTON CLUTCH C3	TATA spare parts
29542754	PLATE PISTON RETURN	TATA spare parts
29542756	HOUSING ASSEMBLY C3 CLUTCH	TATA spare parts
29542780	PLUG ASSEMBLY STRAIGHT THREAD	TATA spare parts
29542891	PLATE SOLENOID SEPARATOR	TATA spare parts
29542902	VALVE ASSEMBLY CONTROL	TATA spare parts
29542915	PLATE SEPARATOR	TATA spare parts

29542919	GASKET CHANNEL PLATE	TATA spare parts
29542923	BODY CONTROL VALVE	TATA spare parts
29542925	VALVE CONTROL MAIN	TATA spare parts
29542926	SPRING CONTROL MAIN	TATA spare parts
29542927	VALVE MAIN REGULATOR	TATA spare parts
29542928	VALVE C1 LATCH	TATA spare parts
29542929	SPRING C2 LATCH	TATA spare parts
29542930	STOP C2 LATCH	TATA spare parts
29542932	PLATE SOLENOID SEPARATOR	TATA spare parts
29542935	BODY ASSEMBLY SOLENOID VALVE AND PIN	TATA spare parts
29542937	VALVE LOCKUP TRIM	TATA spare parts
29542938	SPRING	TATA spare parts
29542939	VALVE CLUTCH TRIM	TATA spare parts
29542940	VALVE DIAGNOSTIC	TATA spare parts
29542941	SPRING DIAGNOSTIC	TATA spare parts
29542944	SWITCH ASSEMBLY	TATA spare parts
29542946	BRACKET	TATA spare parts
29542954	PIN	TATA spare parts
29542976	O-RING 10.5 MM ID	TATA spare parts
29542986	BODY RETARDER CONTROL	TATA spare parts
29542988	BOLTS M8 X 1.25 X 65	TATA spare parts
29542991	SEAL FACE	TATA spare parts
29542996	PIN RETAINING SOLENOID	TATA spare parts
29543019	CHANNEL	TATA spare parts
29543047	SEAL SQUARE CUT O-RING	TATA spare parts
29543067	FILTER ASSEMBLY SUCTION	TATA spare parts
29543433	SENSOR SPEED	TATA spare parts
29543434	SENSOR ASSEMBLY SPEED	TATA spare parts
29543436	CAP. INTERNAL HARNESS 20W	TATA spare parts
29543926	O-RING 85.3 MM ID	TATA spare parts
29543994	PLATE IDENTIFICATION	TATA spare parts
29543995	PLATE IDENTIFICATION	TATA spare parts
29544144	DAMPER ASSEMBLY	TATA spare parts
29544147	HOUSING ASSEMBLY MAIN	TATA spare parts
29544184	CONNECTOR 2 WAY (PCS3)	TATA spare parts
29544297	SOLENOID TCC VARIABLE BLEED CENL	TATA spare parts
29544645	O-RING	TATA spare parts
29544671	HARNESS ASSEMBLY CONTROL INTERNAL	TATA spare parts
29544785	FILTER ASSEMBLY KIT SUCTION	TATA spare parts
29544937	VALVE C2 LATCH	TATA spare parts
29548988	FILTER KIT	TATA spare parts
29804	WASHER-SPIDER	TATA spare parts
299000033146	HOSE AIR FILTER LPK2516TC	TATA spare parts
299001033226	ASSY TURNING TUBE-LPS3516LOW MOUNT	TATA spare parts
299001033230	AL PIPE A/F TO TC	TATA spare parts
299002013021	SUPPORT ENGINE X/M REAR	TATA spare parts
299002031009	ASSY AUX WATER TANK	TATA spare parts

299002032018	ASSY EXT. PIPE (INT).	TATA spare parts
299002033041	ASSY. BKT	TATA spare parts
299002042013	ASSEMBLY GRILL	TATA spare parts
299003054829	LINED SHOE ASSY REAR	TATA spare parts
299003054830	LINED SHOE ASSY FRONT	TATA spare parts
299005021019	INST. CLUSTER WITH ELECT SPEEDOMETER	TATA spare parts
299005033032	PIPE ( INTERCOOLER TO TC )	TATA spare parts
299005033033	PIPE ( INTERCOOLER TO ENGINE INLET )	TATA spare parts
299005033037	AIR INTAKE PIPE 127DIA	TATA spare parts
299005033059	RUBBER HOSE (AIR FILTER OUTLET)	TATA spare parts
299005034060	COATED CLAMP	TATA spare parts
299008023224	ELECTRONICSPEEDOMETERWITH MULT.FAN	TATA spare parts
299010024365	DIODE 3A WITH 2 POLE CONN	TATA spare parts
299011021805	W/H PIGTAIL FOR ACCELERATOR PEDAL	TATA spare parts
299011023350	W/H PIGTAIL FOR WIPER MOTOR	TATA spare parts
299013000697	M35A2 VEHICLE ASSY KIT	TATA spare parts
299013000823	M35A2 VEH SUB ASSY-1 KIT	TATA spare parts
299013000824	M35A2 VEH SUB ASSY-2 KIT	TATA spare parts
299013000825	M35A2 VEH SUB ASSY-3 KIT	TATA spare parts
299013000826	M35A2 VEH SUB ASSY-4 KIT	TATA spare parts
299013000827	M35A2 VEH SUB ASSY-5 KIT	TATA spare parts
299014000149	WIRING HARNESS PIGTAIL STOP LIGHT	TATA spare parts
299016000128	BRACKET ASSY RH	TATA spare parts
299016000130	BRACKET ASSY LH	TATA spare parts
299017000722	PIGTAIL BOOM PUMP BS6	TATA spare parts
299017000726	WIRING HARNESS PIGTAIL BS6	TATA spare parts
299020060005	LPTA 2038 6X6 W/AUTO TRANSMISSION KIT	TATA spare parts
299082010013	REAR AXLE ASSY RA108	TATA spare parts
299082010014	STRG GEAR BOX 1210LP YELL	TATA spare parts
299082100011	FRONT AXLE YELLOW	TATA spare parts
299094014202	D-SHACKLE	TATA spare parts
299094037768	ASSY.PROPELLER SHAFT-FRONT	TATA spare parts
299094037769	ASSY.PROPELLER SHAFT-REAR	TATA spare parts
299097017028	ROPE 16D 6X37 RH LAY 60MTR LG FC IS 2266	TATA spare parts
299098017141	ROD SEAL I	TATA spare parts
299098017142	ROD SEAL 2	TATA spare parts
299098017143	ROD SEAL 3	TATA spare parts
299098017144	ROD SEAL 4	TATA spare parts
299098017145	O RING	TATA spare parts
299098017146	SEALING WASHER	TATA spare parts
299098017147	O RING	TATA spare parts
299098017148	WIPER	TATA spare parts
299098017149	QUAD RING	TATA spare parts
299098017150	SEALING WASHER	TATA spare parts
299098017151	SEALING WASHER	TATA spare parts
299098017152	GASKET	TATA spare parts
299098017153	PLUNGER SEAT	TATA spare parts



299098017154	SQUARE RING	TATA spare parts
299098017155	OIL SEAL	TATA spare parts
299098017156	O RING	TATA spare parts
299098017157	O RING	TATA spare parts
299098017158	SEALING WASHER	TATA spare parts
299098017159	SEALING WASHER	TATA spare parts
299098017160	SSK FOR MANUAL VALVE ROT	TATA spare parts
299098017161	GASKET PTO	TATA spare parts
299098017162	GASKET PUMP	TATA spare parts
299098017163	SHIFTING SHOE	TATA spare parts
299098017164	OIL SEAL	TATA spare parts
299098017165	O RING	TATA spare parts
299098017166	RLF CARTRIDGE	TATA spare parts
299098017167	OIL STRAINER	TATA spare parts
299098017168	GASKET	TATA spare parts
299098017169	O RING	TATA spare parts
299098017170	WASHER CU	TATA spare parts
299098017171	SUCTION HOSE	TATA spare parts
299098017172	PRESSURE HOSE	TATA spare parts
299098017173	PRESSURE HOSE	TATA spare parts
299098017174	PRESSURE HOSE	TATA spare parts
299098017175	BONDED SEAL	TATA spare parts
299098017176	HOSE CLAMP	TATA spare parts
299098017177	BONDED SEAL	TATA spare parts
299098020123	ASSY MAIN CABLE SET	TATA spare parts
299098020124	ASSY CABLE SET	TATA spare parts
299098021066	CABLE ASSY	TATA spare parts
299098022015	REDUCER HOSE	TATA spare parts
299098022061	WATER IN FUELLINE INDICATOR	TATA spare parts
299098037007	KIT CONVERSION OF ROTARY	TATA spare parts
299098051134	BELLOW (G.S.)	TATA spare parts
299098051173	INSULATION ENGINE HOOD	TATA spare parts
299098053127	INSULATION PODEST	TATA spare parts
299098053146	GROMMET FLICK VALVE	TATA spare parts
299098053164	INSULATION PODEST	TATA spare parts
299098054128	RUBBER STOPPER	TATA spare parts
299098054129	RUBBER GROMATE RH SIDE	TATA spare parts
299098054130	RUBBER GROMATE LH SIDE	TATA spare parts
299098054157	RUBBER BUSH-G.S	TATA spare parts
299099031026	ASSY BRACKET	TATA spare parts
299099032055	ASSY BRKT FOR AIR DRYER	TATA spare parts
299099034087	ASSY.6BTAA ENGINE(210 HP).HMRO FIXED FAN	TATA spare parts
299305294001	FORK ASSEMBLY	TATA spare parts
299305467501	ASSY.STG.PIPE (15 O.D.)	TATA spare parts
299305467502	ASSY.STG.PIPE (15 O.D.)	TATA spare parts
299305467503	ASSY.STG.PIPE (15 O.D.)	TATA spare parts
299305502005	HOSE(RAD.TO WATER PUMP)LPT2515-TC	TATA spare parts

299305583001	JACK	TATA spare parts
299306063501	BATTERY MTG BKT	TATA spare parts
299306064501	BATTREY MTG STUD	TATA spare parts
299306091501	AIR INTAKE CAST PIPE	TATA spare parts
299306093201	AIR INLET PIPE FLOOR MTD	TATA spare parts
299306093202	AIR INLET PIPE	TATA spare parts
299306093501	AIR FILTER OUTLET BELLOW REDUCER	TATA spare parts
299306302501	ASSY. PULL CABLE ACCELERATOR	TATA spare parts
299306304502	BKT ACC CABLE MTG ENG END	TATA spare parts
299306312501	ASSY. REAR BUMPER MIDDLE	TATA spare parts
299306324502	7.40 ID CORRUGATED TUBE FR TYPE	TATA spare parts
299306324503	10.7ID CORRUGATED TUBE	TATA spare parts
299306324504	15.2 ID CORRUGATED TUBE FR TYPE	TATA spare parts
299306324505	CORRUGATED TUBE FR TYPE 22.1 ID	TATA spare parts
299306324506	25.5 ID CORRUGATED TUBE FR TYPE	TATA spare parts
299306423201	HOSE ASSEMBLY (16 MM ID)	TATA spare parts
299306423501	VOITH RETARDER	TATA spare parts
299306427502	ASSY.METAL PIPE (15 O.D.)	TATA spare parts
299306427503	ASSY.METAL PIPE (15 O.D.)	TATA spare parts
299306430501	SET ASSY NYLON BRAKE PIPE COMP. 1610RE	TATA spare parts
299306430505	PIPE1 DBV 21 TO RV	TATA spare parts
299306430506	PIPE2 DBV 21 TO RV	TATA spare parts
299306430516	PIPE DDU 22 TO FRONT TANK	TATA spare parts
299306430517	PIPE FRONT TANK TO DBV 12	TATA spare parts
299306430518	PIPE-1 DBV 22 TO QRV	TATA spare parts
299306430519	PIPE-2 DBV 22 TO QRV	TATA spare parts
299306430520	PIPE QRV TO FRONT CH RH	TATA spare parts
299306430521	PIPE QRV TO FRONT CH LH	TATA spare parts
299306430522	PIPE SPV 23 TO HAND BRAKE	TATA spare parts
299306430523	PIPE-1 HAND BRAKE TO QRV HOSE	TATA spare parts
299306430524	PIPE-2 HAND BRAKE VALVE TO QRV HOSE	TATA spare parts
299306430525	PIPE-3 HAND BRAKE VALVE TO QRV HOSE	TATA spare parts
299306430530	PIPE -1 SPV PORT 24 TO SUSPENSION TAN	TATA spare parts
299306430531	PIPE -2 SPV PORT 24 TO SUSPENSION TAN	TATA spare parts
299306430532	PIPE -3 SPV PORT 24 TO SUSPENSION TA	TATA spare parts
299306430538	PIPE RETARDER TANK TO TEE	TATA spare parts
299306434201	PIPE (THERMOSTAT BYPASS)	TATA spare parts
299306434215	AC DRIER TO AC HEAD PIPE 1	TATA spare parts
299306434216	AC DRIER TO AC HEAD PIPE 2	TATA spare parts
299306464203	PIPE STEERING MAIN LINE 3	TATA spare parts
299306464204	PIPE STEERING MAIN LINE 4	TATA spare parts
299306464206	PIPE STEERING RETURN LINE 1	TATA spare parts
299306464207	PIPE STEERING RETURN LINE 2	TATA spare parts
299306464209	PIPE STEERING RETURN LINE 4	TATA spare parts
299306470001	FUEL LINE PIPE 1	TATA spare parts
299306470002	FUEL LINE PIPE 2	TATA spare parts
299306474201	FUEL LINE 1 SUCTION (HI DECK)	TATA spare parts

299306474202	FUEL LINE 2 SUCTION (HI DECK)	TATA spare parts
299306474227	UNION TEE - 1/2 OD	TATA spare parts
299306474239	MALE CONNECTOR - 1/4 OD X 3/4-16 SA	TATA spare parts
299306474251	UNION - 1/2 OD	TATA spare parts
299306492501	ASSY EXHAUST PIPE	TATA spare parts
299306507501	ASSY 6 DIA CRIMP PIPE (AUX. TANK TO RAD)	TATA spare parts
299306507502	ASSY 6 DIA CRIMP PIPE (AUX. TANK TO ENG)	TATA spare parts
299306507509	WATER FILL PIPE	TATA spare parts
299306510504	ASSY REAR STRUCTURE COMPLETE - RE BS2	TATA spare parts
299306513503	PRE FILTER MTG. BKT FRONT	TATA spare parts
299306513504	ASSY. AIR FILTER MTG. BKT.	TATA spare parts
299306513505	PRE FILTER MTG. BKT. REAR	TATA spare parts
299306540001	INSTRUMENT CLUSTER	TATA spare parts
299306540002	KIT WATER PROOF CONNECTORS (HCBS)	TATA spare parts
299306540501	W/H MAIN	TATA spare parts
299306540502	W/H TAIL	TATA spare parts
299307093503	ASSY SNORKEL BOX	TATA spare parts
299307323701	RADIUS ROD AXLE BKT	TATA spare parts
299307324803	NYLON TUBE	TATA spare parts
299307423505	HOSE SILICON	TATA spare parts
299307434851	AIR COMPRESSOR DISCHARGE HOSE	TATA spare parts
299307434852	PIPE( 60 DIA)- RADIATOR OUTLET TO C/M	TATA spare parts
299307434853	PIPE( 60 DIA)- C/M TO RETARDER INLET	TATA spare parts
299307434854	PIPE( 60 DIA)- RETARDER OUTLET TO WATER	TATA spare parts
299307474516	BANGALORE FLUID SYSTEM COMPONE	TATA spare parts
299307474517	SS-810-3-8-4 REDUCING TEE 1/2" TO 1/4"	TATA spare parts
299307474518	SS-400 R-8 REDUCER 1/2" TO 1/4" OD	TATA spare parts
299307474519	CHECK VALVE 1/4 OD X 1/4 NPT MALE	TATA spare parts
299307474802	1/2 SS TUBE 0.049 WALL THICKNESS	TATA spare parts
299307474803	FEMALE CONNECTOR 1/4 ODX1/4 NPT	TATA spare parts
299307544510	FITMENT HARNESS FOR ELCTRONIC SPEEDOMETE	TATA spare parts
299307544802	PIGTAIL FOR ELECTRONIC SPEED SENSOR	TATA spare parts
299307544817	ELEC. RPM METER WITH DIG. HR. METER	TATA spare parts
299307984501	11.8 ID CORRUGATED TUBE FR TYPE	TATA spare parts
299307984503	19.5 ID CORRUGATED TUBE FR TYPE	TATA spare parts
299307984504	PROTECTIVE COVER (OD 34.0 ID 28.2)	TATA spare parts
299307984505	30.5 ID CORRUGATED TUBE FR TYPE	TATA spare parts
299307984506	34.0 ID CORRUGATED TUBE FR TYPE	TATA spare parts
299307984507	40.5 ID CORRUGATED TUBE FR TYPE	TATA spare parts
299308303833	SPRING FOR BELL CRANK LEVER RETURN	TATA spare parts
299308493858	PLATE EXHAUST HEAT SHIELD	TATA spare parts
299308543857	PIGTAIL FOR RETARDER/ACC PEDAL SWITCH	TATA spare parts
299308544831	PIG TAIL W/H WLECTRONIC SPEED SENSOR	TATA spare parts
299308544838	Pigtail Speedsensor	TATA spare parts
299308544856	AIR PRESSURE SENSOR PIGTAIL	TATA spare parts
299309433870	ASSY PIPE- 22MM DIA WITH NUT & FERRULE	TATA spare parts
299309544860	PIGTAIL FOR POWER SHIFT SOLENOID	TATA spare parts

299354113001	W/H PIGTAIL FOR EXHAUST BRAKE	TATA spare parts
299806434218	AC HEAD INLET TO AIR CLEANER 2	TATA spare parts
2P4354620103	W/H MAIN LPO P4P4-VOITH RETARDER	TATA spare parts
300001309	MINOR REPAIR KIT FOR 230CC COMP	TATA spare parts
300001310	MAJOR REPAIR KIT FOR 230CC COMP	TATA spare parts
300001311	PISTON RING KIT 230CC COMP	TATA spare parts
300001312	PISTON REPAIR KIT 230CC COMP	TATA spare parts
300002033	CLUTCH SERVICE KIT 4 INCH	TATA spare parts
300003112	OIL SEPERATOR KIT	TATA spare parts
3004258	PLUG EXPANSION	TATA spare parts
3007632	PLUG EXPANSION	TATA spare parts
3007635	PLUG EXPANSION	TATA spare parts
3008400	GASKET HYDRAULIC PUMP	TATA spare parts
3008464	PLUG PIPE	TATA spare parts
3008465	PLUG PIPE	TATA spare parts
3008468	PLUG PIPE	TATA spare parts
3008469	PLUG PIPE	TATA spare parts
3008470	PLUG PIPE	TATA spare parts
3008690	CLAMP HOSE	TATA spare parts
3008760	VALVE SHUTOFF	TATA spare parts
3010536	SHAFT SHUTOFF VALVE	TATA spare parts
3010596	SCREW CAPTIVE WASHER CAP	TATA spare parts
3022670006	CAP GERA SHIFT DOME	TATA spare parts
3022670008	BALL PIECE GR SHIFT DOME	TATA spare parts
3023198	TEE STREET PIPE	TATA spare parts
3025806	SCREW SOCKET HEAD CAP	TATA spare parts
3026396	CLAMP HOSE	TATA spare parts
3027232	PLUG PIPE	TATA spare parts
3029910015	BALL PIN CR-51052	TATA spare parts
3029970035	PLUG	TATA spare parts
3033033	CLAMP HOSE	TATA spare parts
3033380026	BALL CUP TOP	TATA spare parts
3033740	VALVE ASSY.	TATA spare parts
3035228	O RING DISTRIBUTOR CNG	TATA spare parts
3035960	RING RETAINING	TATA spare parts
3036666	SEAL O RING	TATA spare parts
3037236	SEAL O RING	TATA spare parts
3037536	PLUG THREADED (9/16 - 18 UNF)	TATA spare parts
3037537	O RING	TATA spare parts
3039532	TEE CONNECTOR	TATA spare parts
3040817	SEAL O RING	TATA spare parts
3040995	PLUG THREADED	TATA spare parts
3041001650	COMPLETE CABIN NOVUS	TATA spare parts
3042619	NIPPLE COUPLING	TATA spare parts
3042620	NIPPLE COUPLING	TATA spare parts
3043100207	ASSY CHAIN WITH RING HOOK	TATA spare parts
3046201	O RING	TATA spare parts

3049278	CONNECTOR MALE	TATA spare parts
3049910015	BALL PIN	TATA spare parts
3052061	SCREW HEXAGON HEAD CAP (1/2-13 X 1 INCH)	TATA spare parts
3052587	ASSY. PROPELLER SHAFT	TATA spare parts
3059279	UNION MALE	TATA spare parts
3066211	SEAL O RING	TATA spare parts
306744004009	TESTING RING	TATA spare parts
306744004010	SPECIAL TYPE SPANNER (FORGED)	TATA spare parts
3069053	CLAMP V BAND	TATA spare parts
30703	EXPANSION PLUG UPPER	TATA spare parts
3070475	PIN ROLL	TATA spare parts
3071049	HOSE HUMP	TATA spare parts
3071051	HOSE HUMP	TATA spare parts
3071221	PLUG PIPE	TATA spare parts
3080408	SENSOR MIXER INLET PRESSURE-LEAN BURN EN	TATA spare parts
3081000080	BOLT-EXHAUST BRAKE FIX	TATA spare parts
3081000082	BOLT-EXHAUST BRAKE FIX	TATA spare parts
3081000150	BOLT-W/WASHER M10X1.25	TATA spare parts
3081000154	BOLT-W/WASHER M10X1.25	TATA spare parts
3081000160	HEX BOLT M8X1.25 (L=230)	TATA spare parts
3081000162	HEX BOLT M8X1.25	TATA spare parts
3081000230	BOLT M8X1.25	TATA spare parts
3081000320	BOLT M16X2.0	TATA spare parts
3081000340	BOLT M16X2.0	TATA spare parts
3081000510	FLANGE BOLT M10X1.25	TATA spare parts
3081000710	HEX BOLT M12X1.75	TATA spare parts
3081000790	HEX BOLT M12X1.25	TATA spare parts
3081000860	HEX BOLT M20X1.5	TATA spare parts
3081001070	FLANGE BOLT M10X1.25	TATA spare parts
3081001131	FLANGE BOLT M8X1.25	TATA spare parts
3081001160	RIVET-REFLECTIVE SHEET	TATA spare parts
3081001320	HEX BOLT M10X1.5	TATA spare parts
3082000050	HEX NUT M12X1.0	TATA spare parts
3082000051	HEX NUT M12X1.0	TATA spare parts
3082000101	FLANGE NUT M5X0.8	TATA spare parts
3082000190	SELF LOCK NUT M20X1.5	TATA spare parts
3082000220	SELF LOCK NUT M18X1.5	TATA spare parts
3082000560	LOCK NUT M12X1.5	TATA spare parts
3082000561	LOCK NUT M12X1.5	TATA spare parts
3082000580	FLANGE-NUT M22X1.5	TATA spare parts
3082000680	HEX NUT M16X1.5	TATA spare parts
3083000030	SCREW-S/TAP M5X16	TATA spare parts
3083000140	TAP SCREW	TATA spare parts
3083000260	SCREW-MACH PAN HD M5X0.8	TATA spare parts
3083000280	SCREW M8X1.25	TATA spare parts
3083000282	SCREW M8X1.25	TATA spare parts
3083000290	TAPPING SCREW-PAN HEAD	TATA spare parts

3083000292	TAPPING SCREW-PAN HEAD	TATA spare parts
3083000380	MACH SCREW-PAN HD M6X1.0(RH)	TATA spare parts
3083000381	MACH SCREW-PAN HD M6X1.0	TATA spare parts
3083000390	SCREW-S/TAP	TATA spare parts
3083000400	SCREW-W/WASHER	TATA spare parts
3083000402	SCREW-W/WASHER	TATA spare parts
3083000410	TAPPING SCREW-PAN HEAD	TATA spare parts
3083000420	SCREW-W/WASHER PAN HEAD M6X1.0	TATA spare parts
3083000440	SCREW-W/WASHER M8	TATA spare parts
3083000460	NYLON WASHER	TATA spare parts
3083000470	MACHINE SCREW-PAN HEAD	TATA spare parts
3083000520	SCREW PAN HD M6X1.0	TATA spare parts
3083000540	SCW P/HD W/WASHER M8X1.25	TATA spare parts
3083000541	SCREW P/HD W/WASHER M8X1.25	TATA spare parts
3083000550	MACHIN SCREW-M6X1.0	TATA spare parts
3083000590	PLAIN WASHER	TATA spare parts
3083000740	CK-HD SCREW M8X1.25	TATA spare parts
3083980	COUPLING ELBOW HOSE	TATA spare parts
3084000080	PUSH NUT	TATA spare parts
3084000190	RIVET A13	TATA spare parts
30840045	HEX. HEAD SCREW M6X20 - 8.8	TATA spare parts
30850064	HEX. HEAD SCREW M8X30 - 8.8	TATA spare parts
30850072	HEX. HEAD BOLT M8X75 - 8.8	TATA spare parts
30850323	Allen Key Bolts M8x80	TATA spare parts
3085600010	WELD STUD M5X0.8	TATA spare parts
3086000100	PLUG-TUBE	TATA spare parts
3086000101	PLUG-TUBE	TATA spare parts
30860042	LOCKING PIN BOLTS M10X20	TATA spare parts
30860066	HEX. HEAD SCREW M10X40 - 8.8	TATA spare parts
30860070	LOCK BOLT M10X65	TATA spare parts
30860084	HEX BOLT M10X30 -10.9	TATA spare parts
30870068	Hex Head Bolt M12X50 Grade 10.9	TATA spare parts
30870086	HEX HEAD BOLT M12X40 GRADE8.8	TATA spare parts
30870088	HEX HEAD BOLT M12X50 GRADE 10.9	TATA spare parts
30870186	Hex Head Bolt M12x40 Grade8.8	TATA spare parts
3087500011	JAW JOINT YOKE	TATA spare parts
3088500010	CLIP-ONE TOUCH	TATA spare parts
3088500011	CLIP-ONE TOUCH	TATA spare parts
3088500040	CLIP- A TYPE	TATA spare parts
3088500050	CLIP- A TYPE	TATA spare parts
3088500060	CLIP- A TYPE	TATA spare parts
3088500080	CLIP- A TYPE	TATA spare parts
3088500160	CLIP A- F TYPE	TATA spare parts
3088500190	GROMMET-SCREW	TATA spare parts
3088500192	SCREW GROMMET	TATA spare parts
3088500200	GROMMET-SCREW	TATA spare parts
3088500230	SCREW GROMMET	TATA spare parts

3088500290	CLIP- F TYPE	TATA spare parts
3088500313	CLAMP TUBE	TATA spare parts
3088500360	X-MASS TREE CLIP	TATA spare parts
3088500450	CLIP-BATTERY CABLE	TATA spare parts
3088500500	SCREW RIVET	TATA spare parts
3088500500SB	SCREW RIVET	TATA spare parts
3088500540	GROMMET-SCREW	TATA spare parts
3088500560	SCREW RIVET M5X0.8	TATA spare parts
3088500560LB	SCREW RIVET M5X0.8	TATA spare parts
3088500600	X-MASS TREE CLIP	TATA spare parts
3088500600LB	X-MASS TREE CLIP	TATA spare parts
3088500620	SCREW RIVET	TATA spare parts
3088500620SB	SCREW RIVET	TATA spare parts
3088500630	HOLDER-ROD	TATA spare parts
30890020	HEX. HEAD BOLT M16X160 - 10.9	TATA spare parts
30890040	HEX. HEAD BOLT M16X220 - 10.9	TATA spare parts
30890079	Pivot Bolt M16 X 150	TATA spare parts
30890080	PIVOT BOLT M16 X 110	TATA spare parts
30890109	CYLINDER MOUNTING BOLT M16 X 60	TATA spare parts
30890120	Pivot Bolt M16 X 110	TATA spare parts
30890180	CYLINDER MOUNTING BOLT M16 X 50	TATA spare parts
30890228	Cylinder Mounting Bolt M16 X 50	TATA spare parts
3089232	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3089238	PLUG THREADED	TATA spare parts
3089239	PLUG THREADED	TATA spare parts
3089240	SEAL O RING	TATA spare parts
3089316	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3089384	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3089700060	SNAP PIN	TATA spare parts
3089700070	SNAP PIN	TATA spare parts
3089800040	CLAMP-RUBBER HOSE(HOSE O.D 34.2)	TATA spare parts
3089800042	CLAMP-RUBBER HOSE	TATA spare parts
3089800050	UNION-STRAIGHT LONG(M20X1.5 RETURN)	TATA spare parts
3089800090	O RING	TATA spare parts
3089800110	O RING	TATA spare parts
3089800130	O RING	TATA spare parts
3089800150	O RING	TATA spare parts
3089800160	O RING	TATA spare parts
3089800170	O RING	TATA spare parts
3089800370	CLAMP-RUBBER HOSE	TATA spare parts
3089800371	CLAMP-RUBBER HOSE	TATA spare parts
3089800380	CLAMP-RUBBER HOSE	TATA spare parts
3089800400	HEX NUT M10X1.25	TATA spare parts
3089800720	PLAIN WASHER	TATA spare parts
3089800740	BAND CLAMP-RUBBER HOSE	TATA spare parts
3092253	CLAMP SPRING HOSE	TATA spare parts
3093730	SCREW HEX FLANGE HEAD CAP	TATA spare parts

3093775	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3093828	NUT HEXAGON FLANGE	TATA spare parts
3093923	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3093936	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3093956	SCREW HEX FLANGE HEAD CAP	TATA spare parts
30940003	Grub Screw	TATA spare parts
3094000810	ASSY CAB COMPLETE NOVUS	TATA spare parts
3095000090	GLASS ASSY. OSRVM MAIN	TATA spare parts
3095000120	GLASS ASSY. REAR UNDER VIEW MIRROR	TATA spare parts
30950025	PLAIN NUT M16 LH THREAD	TATA spare parts
30950115	LOCK NUT M16	TATA spare parts
30950180	NYLOC NUT M6	TATA spare parts
30950182	NYLOC NUT M8	TATA spare parts
30950185	NYLOC NUT M10	TATA spare parts
30950186	NYLOC NUT M12 X 1.25 P	TATA spare parts
30950187	Nyloc Nut M12 X 1.25 p	TATA spare parts
30950188	NYLOC NUT M14	TATA spare parts
30950190	NUT M16 - PIVOT MOUNTING	TATA spare parts
30950191	NYLOC NUT M16X1.5 FINE PITCH	TATA spare parts
30950215	Nut M16 - Pivot Mounting	TATA spare parts
31020028	SPLIT PIN DIA8X45	TATA spare parts
31020041	Cotter Pin - Cylinder Mounting	TATA spare parts
3102763	MOTOR STARTING	TATA spare parts
3102928	VALVE PRESSURE REGULATOR	TATA spare parts
31030002	Plain Washer M6	TATA spare parts
31030005	M.S. Plain Washer M12	TATA spare parts
31030007	Washer M16	TATA spare parts
31030023	M8 SPRING WASHER SQ. SECTION	TATA spare parts
31030024	M10 SPRING WASHER SQ. SECTION	TATA spare parts
31030062	M8 STAR WASHER	TATA spare parts
31030067	M16 HARDENED WASHER (30/17*3)	TATA spare parts
31040001	Copper Washer 38x 44x 2.5	TATA spare parts
31040003	COPPER WASHER 38X 44X 2.5	TATA spare parts
31040100	Copper Washer 1/8INCH	TATA spare parts
31050002	Dowty Seal 1/4INCH	TATA spare parts
31050006	Dowty Seal 3/4INCH	TATA spare parts
31050008	Dowty Seal 1INCH	TATA spare parts
31050009	Dowty Seal 1 1/4INCH	TATA spare parts
31060001	NYLON TIE 4X 254	TATA spare parts
31060002	NYLON TIE 4X 254	TATA spare parts
3107-E-1071	COLLAR CLUTCH	TATA spare parts
31070001	Grease Nipple - Straight	TATA spare parts
31070002	Grease Nipple - 45 Degree	TATA spare parts
31070003	GREASE NIPPLE - 45 DEGREE	TATA spare parts
31070004	GREASE NIPPLE 1/8INCH BSP	TATA spare parts
31080001	SPRINGS (PIVOT)	TATA spare parts
3120100280	ASSY TOP COVER W POINTER	TATA spare parts



3120100333	TIMING GEAR HOUSING	TATA spare parts
3120100823	ASSY MAIN BEARING CAP	TATA spare parts
3120100923	MAIN BEARING CAP	TATA spare parts
3120102452	PRECHAMBER 1	TATA spare parts
3120102552	PRECHAMBER 3	TATA spare parts
3120140521	GASKET LEFT	TATA spare parts
3120140621	GASKET RIGHT	TATA spare parts
3120140721	GASKET	TATA spare parts
3120150009	COVER TIMING GEAR	TATA spare parts
3120150031	POINTER	TATA spare parts
3120150080	GASKET TOP COVER	TATA spare parts
3120150220	GASKET	TATA spare parts
3120150222	GASKET PUSH ROD CH COVER	TATA spare parts
3120150301	COVER/TGH WO OILSEAL	TATA spare parts
3120150580	GASKET	TATA spare parts
3120160061	PLUG	TATA spare parts
3120160621	GASKET CYL HEAD COVER	TATA spare parts
3120162320	GASKET CYLINDER HEAD PC	TATA spare parts
3120170203	PRESSURE PLUG	TATA spare parts
3120170619	GASKET	TATA spare parts
3120180005	SEALING COVER	TATA spare parts
3120180068	SUPPORT RING	TATA spare parts
3120180140	PIPE CLAMP	TATA spare parts
3120180280DB	GASKET	TATA spare parts
3120180340	BRACKET LP	TATA spare parts
3120300305	FLY WHEEL	TATA spare parts
3120300618	PISTON STD	TATA spare parts
3120300918	PISTON RS1	TATA spare parts
3120301018	PISTON RS2	TATA spare parts
3120301118	PISTON RS3	TATA spare parts
3120310471	SCREW HEX HEAD	TATA spare parts
3120310533	LOCKING RING	TATA spare parts
3120320105	RING GEAR 280D	TATA spare parts
3120350062	THRUST WASHER	TATA spare parts
3120350271	VIBRATION DAMPER LOCK	TATA spare parts
3120350426	RUBBER SLEEVE	TATA spare parts
3120370015	SET PISTON RING STD	TATA spare parts
3120370115	SET PISTON RING STD1 & 2	TATA spare parts
3120370215	SET PISTON RING RS1	TATA spare parts
3120370415	SET PISTON RING RS3	TATA spare parts
3120380471	CON ROD SCREW BOTTOM M12X73 10K	TATA spare parts
3120500033	ASY ROCKER ARM LEFT	TATA spare parts
3120500034	ASSY ROCKER ARM RIGHT	TATA spare parts
3120500231	ROCKER ARM SHAFT	TATA spare parts
3120520262	THRUST WASHER	TATA spare parts
3120520401	GEAR CAMSHAFT	TATA spare parts
3120520503	CRANKSHAFT GEAR	TATA spare parts

3120530127	LOCK HALF	TATA spare parts
3120540501	VALVE TAPPET STD	TATA spare parts
3120540601	VALVE TAPPET RS1	TATA spare parts
3120540701	VALVE TAPPET RS2	TATA spare parts
3120550050	BUSH	TATA spare parts
3120550171	BOLT (ROCKER ARM)	TATA spare parts
3120550310	ROCKER ARM SUPPORT	TATA spare parts
3120550405	ROCKER ARM SHAFT	TATA spare parts
3120550410	ROCKER ARM SUPPORT	TATA spare parts
3120550510	ROCKER ARM SUPPORT	TATA spare parts
3120550553	CON NIPPLE OUTSIDE	TATA spare parts
3120550653	NIPPLE INNER	TATA spare parts
3120700113	DRIVE GEAR	TATA spare parts
3120700321	LEVER ACCELERATOR	TATA spare parts
3120702033	PRESSURE LINE 1ST	TATA spare parts
3120702033DB	PRESSURE LINE 1ST CYL	TATA spare parts
3120702133	PRESSURE LINE 2ND	TATA spare parts
3120702233	PRESSURE LINE 3RD	TATA spare parts
3120702333	PRESSURE LINE 4TH	TATA spare parts
3120702433	PRESSURE LINE 5TH	TATA spare parts
3120702533	PRESSURE LINE 6TH	TATA spare parts
3120760279	GASKET	TATA spare parts
3120760435	SUPPORT	TATA spare parts
3120941191	RUBBER CUFF	TATA spare parts
3121300001	ASSY PIPE AIRCOMPRESSOR	TATA spare parts
3121300101	PIPE AIR	TATA spare parts
3121300119	CYL HEAD AIR COMP 70D	TATA spare parts
3121300817	PISTON STD I	TATA spare parts
3121310008	VALVE SPRING	TATA spare parts
3121310022	GUDGEON PINS	TATA spare parts
3121310119	CYL HEAD AIR COMP	TATA spare parts
3121310128	SPRING HSG. A/C	TATA spare parts
3121310176	VALVE DISC	TATA spare parts
3121310179	GASKET SLV TO HEAD 70D	TATA spare parts
3121310331	PRESSURE VALVE SEAT A/C	TATA spare parts
3121310431	SUCTION VALVE CAP	TATA spare parts
3121310531	SUCTION VALVE SEAT	TATA spare parts
3121420012	CLAMP CENTRE	TATA spare parts
3121420080	GASKET EXHAUST MANIFOLD	TATA spare parts
3121420112	CLAMP EXHAUST MANIFOLD LATERAL	TATA spare parts
3121420212	CLAMP OUTER	TATA spare parts
3121440274	BUSH	TATA spare parts
3121500032	ASY EARTH CABLE	TATA spare parts
3121510212	INTERMEDIATE FLANGE	TATA spare parts
3121550174	GUIDE PIN M10X52.5	TATA spare parts
3121550437	CLAMP (BRACKET) GENERATOR	TATA spare parts
3121550515	PULLEY GEN	TATA spare parts

3121590121	BAR CONTACT CENTRE	TATA spare parts
3121800165	ASSY OIL COOLER	TATA spare parts
3121800365	OIL COOLER	TATA spare parts
3121801651	SUCTION TUBE PC	TATA spare parts
3121810042	PLUNGER OIL PR REL VALVE	TATA spare parts
3121810308	DRIVE GEAR OIL PUMP	TATA spare parts
3121810810	SHAFT OIL PUMP	TATA spare parts
3121810905	DRIVE SHAFT	TATA spare parts
3121811206	GEAR OIL PUMP PC	TATA spare parts
3121811220	COVER OIL PUMP	TATA spare parts
3121840380	GASKET RING OIL FILTER HSG COVER	TATA spare parts
3121841079	GASKET	TATA spare parts
3121860080	GASKET/SHORTER OIL PUMP	TATA spare parts
3121881102	COVER OIL COOLER	TATA spare parts
3121881135	SLEEVE	TATA spare parts
3121881135P	SLEEVE CYL BLOCK	TATA spare parts
3121881201	OIL COOLER	TATA spare parts
3121881235	SCREW PLUG	TATA spare parts
3121881479	GASKET	TATA spare parts
3121881579	GASKET WASHER	TATA spare parts
3122000098	ASSY GREASE CUP	TATA spare parts
3122000160	GASKET WASHER	TATA spare parts
3122000402	WATER PUMP SHAFT.	TATA spare parts
3122000460	PACKING HOLDER	TATA spare parts
3122010078	GASKET	TATA spare parts
3122010119	SLIP RING	TATA spare parts
3122010153	SPACER TUBE	TATA spare parts
3122010203	COVER WATER PUMP	TATA spare parts
3122010318	SEALING RING	TATA spare parts
3122010359	COVER WATER PUMP	TATA spare parts
3122010380	GASKET	TATA spare parts
3122010405	WATER PUMP SHAFT	TATA spare parts
3122010407	IMPELER WATER PUMP	TATA spare parts
3122010480	GASKET	TATA spare parts
3122010580	GASKET	TATA spare parts
3122010658	SLIP RING CAGE	TATA spare parts
3122010752	SHIM 0.05 MM	TATA spare parts
3122010758	BRACKET WATER PUMP	TATA spare parts
3122010852	SHIM 0.10 MM	TATA spare parts
3122010952	SHIM 0.15 MM	TATA spare parts
3122011052	SHIM 0.20 MM	TATA spare parts
3122011062	SLINGER	TATA spare parts
3122011152	SHIM 0.5 MM THICK	TATA spare parts
3122030480	GASKET	TATA spare parts
3122050212	HUB	TATA spare parts
3122050311	PULLEY HALF	TATA spare parts
3122050411	PULLEY HALF	TATA spare parts

3122050606	FAN BLADE	TATA spare parts
3122201317	RUBBER PAD REAR	TATA spare parts
3122201517	RUBBER PAD ENG SUSPN FRT	TATA spare parts
3122230804	SUPPORT ENGINE SUSPENSION FORNT	TATA spare parts
3122511002	LOWER PART	TATA spare parts
3122511004	COVER CLUTCH HOUSING UPER	TATA spare parts
3122511006	PLATE	TATA spare parts
3122511127	SLOTTED SET PIN	TATA spare parts
3122521071	SET SCREW	TATA spare parts
3122541013	LOCKING WIRE	TATA spare parts
3122601340	ASSY LEVER KNOB	TATA spare parts
3122601417	COUPLING FLANGE	TATA spare parts
3122601517	ASSY.COUPLING FLANGE	TATA spare parts
3122601910	POWER TAKE OFF	TATA spare parts
3122602216	COVER REAR	TATA spare parts
3122602539	GEAR SHIFT LEVER	TATA spare parts
3122603339	GEAR SHIFT LEVER	TATA spare parts
3122603810DB	GEAR DRIVE UNIT	TATA spare parts
3122604414	TOP COVER LP	TATA spare parts
3122610372	CROWN RING	TATA spare parts
3122611019	GEAR CASE COVER SIDE	TATA spare parts
3122611060	SEALING RING	TATA spare parts
3122611079	GASKET	TATA spare parts
3122611080	GASKET	TATA spare parts
3122611131	THREADED BUSH	TATA spare parts
3122611179	GASKET	TATA spare parts
3122611279	GASKET	TATA spare parts
3122611363	RING COVER	TATA spare parts
3122611601	GEAR CASE	TATA spare parts
3122611633	GEAR CASE COVER FR LOWER	TATA spare parts
3122611720	COVER REAR	TATA spare parts
3122611918	G B HSG COVER FRONT TOP	TATA spare parts
3122612179	GASKET FR COVER TO HSG	TATA spare parts
3122621063	DUST COVER	TATA spare parts
3122621063AE	DUST PROTECTOR 715	TATA spare parts
3122621074	PIN MAIN SHAFT	TATA spare parts
3122621172	HEX NUT	TATA spare parts
3122621445	COUPLING FLANGE-6-HOLE	TATA spare parts
3122621545	COUPLING FLANGE	TATA spare parts
3122621723	SLEEVE 2/3	TATA spare parts
3122621745	COUPLING FLANGE	TATA spare parts
3122621750	COLLAR BUSH 2ND SPEED	TATA spare parts
3122621923	SLEEVE 4/5	TATA spare parts
3122621952DB	SPACER 0.3 MM	TATA spare parts
3122622105	MAIN SHAFT	TATA spare parts
3122622213	GEAR 3RD SPEED	TATA spare parts
3122622436	GEAR 2/3 SPEED	TATA spare parts

3122622536	GEAR 4/5 SPEED	TATA spare parts
3122622762	BUTTING RING MAIN SHAFT	TATA spare parts
3122623162	BUTTING RING	TATA spare parts
3122623262	BUTTING RING 8.10 MM	TATA spare parts
3122623362	BUTTING RING 8.20 MM	TATA spare parts
3122623362DB	BUTTING RING	TATA spare parts
3122623462	BUTTING RING 3.00 MM	TATA spare parts
3122623562	BUTTING RING3.15MM	TATA spare parts
3122623662	BUTTING RING 3.2 MM	TATA spare parts
3122623762	BUTTING RING 3.25 MM	TATA spare parts
3122623862	BUTTING RING 3.30	TATA spare parts
3122624162	BUTTING RING 8.15 MM	TATA spare parts
3122624262	BUTTING RING 8.05 MM	TATA spare parts
3122624362	BUTTING RING 3.05 MM	TATA spare parts
3122624362DB	BUTTING RING	TATA spare parts
3122624462	BUTTING RING 3.10 MM	TATA spare parts
3122624662	BUTTING RING 3.35 MM	TATA spare parts
3122624762	BUTTING RING 3.40 MM	TATA spare parts
3122625062DB	BUTTING RING	TATA spare parts
3122625162DB	BUTTING RING	TATA spare parts
3122625462	BUTTING RING 2.90	TATA spare parts
3122625562	BUTTING RING 2.95 MM	TATA spare parts
3122631153	SPACER TUBE	TATA spare parts
3122631262	BUTTING RING	TATA spare parts
3122631452	SHIM 0.125MM	TATA spare parts
3122631552	SHIM 0.240 MM	TATA spare parts
3122631652	SHIM 0.500 MM	TATA spare parts
3122631814	DOUBLE GEAR C/SHAFT 4TH	TATA spare parts
3122632052	SHIM 2.000 MM	TATA spare parts
3122632152	SHIM 0.050 MM	TATA spare parts
3122641022	GEAR SLIDING PTO 19 TEETH	TATA spare parts
3122641025	SHIFTER SHAFT	TATA spare parts
3122641071	HEX SCREW	TATA spare parts
3122641079	GASKET PTO TO GEAR BOX	TATA spare parts
3122641118	IDLER SHAFT- 709/609 PTO	TATA spare parts
3122641179	GASKET FR COVER TO HSG	TATA spare parts
3122641231	SPEEDO GR STEEL SMALL LHD	TATA spare parts
3122641232	SHAFT	TATA spare parts
3122641279	GASKET	TATA spare parts
3122641311	REAR COVER	TATA spare parts
3122641326	SHIFTING FORK	TATA spare parts
3122641410	FRONT COVER	TATA spare parts
3122641432	SPEEDO DRIVE SHAFT	TATA spare parts
3122641630	SPEEDO GEAR STEEL BIG LHD	TATA spare parts
3122642652DB	WASHER 0.2MM	TATA spare parts
3122643452DB	WASHER	TATA spare parts
3122643652	SPACER 7.30 MM	TATA spare parts

3122651036	CLAMP	TATA spare parts
3122651146	STOP PLATE	TATA spare parts
3122651236	CLAMP	TATA spare parts
3122651248	INTERLOCK PIN STOP PLATE	TATA spare parts
3122651316	PRESSURE PIECE STOP PLATE	TATA spare parts
3122652402	SHIFT FORK	TATA spare parts
3122652502	SHIFTER FORK 2/3 SPEED	TATA spare parts
3122652802	SHIFT FORK 4/5	TATA spare parts
3122652805	SHIFTER SHAFT 2/3 SPEED	TATA spare parts
3122653005	SHIFTER SHAFT REV SPEED	TATA spare parts
3122671006	CAP L	TATA spare parts
3122671096	PROTECTIVE CAP	TATA spare parts
3122671206	CAP LP	TATA spare parts
3122671308	BALL FITTING	TATA spare parts
3122671608	SLIDING KEY LP	TATA spare parts
3122671701	LEVER TOP	TATA spare parts
3122681324	SHIFTING LEVER	TATA spare parts
3122801121DB	DRIVE SHAFT	TATA spare parts
3122801221DB	DRIVEN SHAFT	TATA spare parts
3122801386	AGB MOUNTING	TATA spare parts
3122802246	KNOB SELECTOR LEVER BLACK	TATA spare parts
3122811079DB	GASKET	TATA spare parts
3122820253	SPACER	TATA spare parts
3122821062DB	BUTTING PLATE	TATA spare parts
3122821072	HEX NUT	TATA spare parts
3122821962	BUTTING RING REAR	TATA spare parts
3122821962DB	BUTTING PLATE	TATA spare parts
3122822062	BUTTING RING	TATA spare parts
3122822211	GEAR FRONT BS1/2/3/4	TATA spare parts
3122822262DB	BUTTING PLATE FRONT	TATA spare parts
3122822562	BUTTING RING	TATA spare parts
3122822562DB	BUTTING PLATE	TATA spare parts
3122831031	SMALL DRIVE GEAR	TATA spare parts
3122831052	SHIM 0.10 MM	TATA spare parts
3122831055	OIL SLINGER	TATA spare parts
3122831055DB	OIL SLINGER	TATA spare parts
3122831152	SHIM 0.2	TATA spare parts
3122831230	SPEEDO GEAR STEEL BIG RHD	TATA spare parts
3122831252	SHIM 0.4	TATA spare parts
3122831252DB	WASHER	TATA spare parts
3122831352	SHIM-0.1	TATA spare parts
3122831352DB	WASHER 0.1 MM	TATA spare parts
3122831452	SHIM 0.20 MM	TATA spare parts
3122831453DB	SPACER SLEEVE	TATA spare parts
3122831552	SHIM 0.40 MM	TATA spare parts
3122831652	SHIM 0.05 MM	TATA spare parts
3122831752	SHIM 0.05 BS4	TATA spare parts

3122832152	SHIM 0.8	TATA spare parts
3122841011DB	GEAR SHIFT LEVER	TATA spare parts
3122841020	SHIFTER SHAFT	TATA spare parts
3122841021	GUIDE SHAFT	TATA spare parts
3122841038	FLANGE	TATA spare parts
3122841050	BUSH	TATA spare parts
3122841050DB	BUSH	TATA spare parts
3122841060	SEALING RING	TATA spare parts
3122841079	SEALING SHIM	TATA spare parts
3122841097	DUST COVER SHIFTER SHAFT	TATA spare parts
3122841151	INTERMEDIATE RING	TATA spare parts
3122841301	GEAR SHIFT FORK UPPER	TATA spare parts
3122851003	BEARING HALF UPPER	TATA spare parts
3122851103	BEARING HALF LOWER	TATA spare parts
3122851484	PLATE REINFORCEMENT	TATA spare parts
3122901026	TUBE BRAKE LEVER	TATA spare parts
3122901234	ASSY LEVER BRAKE SHAFT	TATA spare parts
3122901620	ASSY TUBE PEDAL	TATA spare parts
3122904618	BRAKE PEDAL LEVER	TATA spare parts
3122905718DB	BRAKE PEDAL LEVER	TATA spare parts
3122911040	ANCHOR PIN	TATA spare parts
3122911174	PIN	TATA spare parts
3122911197	SEALING WASHER	TATA spare parts
3122921905	CLUTCH LEVER	TATA spare parts
3122931211	RELEASE FORK	TATA spare parts
3122940150	BUSH	TATA spare parts
3122941050	BUSH	TATA spare parts
3122941804	TUBE	TATA spare parts
3123001125	LEVER ACCELERATOR	TATA spare parts
3123001320	ACCELERATOR SHAFT	TATA spare parts
3123001528	DOUBLE LEVER	TATA spare parts
3123001918	ZUS BAU ZUGSTANGE	TATA spare parts
3123002220	ACCELERATOR SHAFT	TATA spare parts
3123011009	HINGE PIN PEDAL	TATA spare parts
3123011032	LEVER	TATA spare parts
3123011040	BRACKET	TATA spare parts
3123011115	PULLROD	TATA spare parts
3123011150	BUSH	TATA spare parts
3123011215	THRUST ROD LHD	TATA spare parts
3123011315	THRUST ROD	TATA spare parts
3123011319	ACCELERATOR SHAFT	TATA spare parts
3123011432	LEVER	TATA spare parts
3123011620	LEVER ACCELERATOR	TATA spare parts
3123011719	ACCELERATOR SHAFT	TATA spare parts
3123021005	CABLE	TATA spare parts
3123101040	CROSS MEMBER RR S/ABS	TATA spare parts
3123121019	CROSS MEMBER	TATA spare parts

3123122610	CROSS MEMBER LP 312	TATA spare parts
3123122652DB	BRACKET	TATA spare parts
3123204008	REAR SPRING W/O AUX LP312	TATA spare parts
3123204108	REAR SPRING ASSY W/O AUX	TATA spare parts
3123211071DB	CENTRE BOLT	TATA spare parts
3123211450	BUSH FRONT SPRING	TATA spare parts
3123213233	PRG CLAMP LR INNER	TATA spare parts
3123220584	CASTOR PLATE	TATA spare parts
3123221052	SPACER WASHER	TATA spare parts
3123221150	BUSH	TATA spare parts
3123221530	SPRING PIN	TATA spare parts
3123230171	SET SCREW	TATA spare parts
3123231263	BRACKET LOWER LH	TATA spare parts
3123231363	BRACKET LOWER RH	TATA spare parts
3123231576	WASHER	TATA spare parts
3123251050	BUSH	TATA spare parts
3123251070	SPHERICAL WASHER	TATA spare parts
3123251217	SLIDE SUPPORT	TATA spare parts
3123251330	SPRING PIN	TATA spare parts
3123251331	GUIDE PLATE	TATA spare parts
3123251617	SLIDE SUPPORT	TATA spare parts
3123251701	BRACKET REAR SPRING FRT	TATA spare parts
3123251801	BRACKET REAR SPRING	TATA spare parts
3123301044	COUPLING FLANGE	TATA spare parts
3123301283	ASSY COVER PLATE FRT. AXLE HOUSING	TATA spare parts
3123302803	TIE ROD ASSY	TATA spare parts
3123303803DB	TIE ROD ASSY	TATA spare parts
3123311021	REINFORCEMENT	TATA spare parts
3123311051	SPACER RING	TATA spare parts
3123311052DB	SPACER	TATA spare parts
3123311073	LOCKING RING	TATA spare parts
3123311073DB	CIRCLIP 5 MM	TATA spare parts
3123311150DB	BUSH	TATA spare parts
3123311173	LOCKING RING	TATA spare parts
3123311825	U CLAMP 216 MM	TATA spare parts
3123312425DB	U CLAMP 192 MM	TATA spare parts
3123312625	U CLAMP 180 MM	TATA spare parts
3123314325DB	U CLAMP 170 MM	TATA spare parts
3123320059	SEALING RING	TATA spare parts
3123321052	SPACER	TATA spare parts
3123321073	LOCKING PLATE	TATA spare parts
3123321749	KING PIN BUSH	TATA spare parts
3123321806DB	KING PIN BOTTOM	TATA spare parts
3123322806	KING PIN RS2	TATA spare parts
3123322962	WASHER LOWER 8.00 MM	TATA spare parts
3123371045DB	COUPLING FLANGE	TATA spare parts
3123371073DB	LOCKING PLATE	TATA spare parts



3123371262DB	THT WASHER 3.8	TATA spare parts
3123371502DB	DRIVE SHAFT	TATA spare parts
3123371562DB	THT WASHER 4.1	TATA spare parts
3123371962DB	THRUST WASHER 4.6MM	TATA spare parts
3123381005	STEERING LEVER LH	TATA spare parts
3123381006	STEERING LEVER RH	TATA spare parts
3123381801DB	STEERING ARM	TATA spare parts
3123501090	ASSY.BREATHER	TATA spare parts
3123501243	COUPLING FLANGE	TATA spare parts
3123501245	COUPLING FLANGE 312	TATA spare parts
3123501521	COVER REAR AXLE 312	TATA spare parts
3123501839	ASSY CROWNWHEEL & PINION	TATA spare parts
3123510925	U CLAMP	TATA spare parts
3123511080	GASKET	TATA spare parts
3123511080AE	GSKT (FRONT AXLE COVER) -713-715	TATA spare parts
3123511174	PIN	TATA spare parts
3123511311	PLUMMER BLOCK	TATA spare parts
3123511515	FLANGE 312	TATA spare parts
3123511725	U CLAMP 350 MM	TATA spare parts
3123512225	U CLAMP 287 MM	TATA spare parts
3123531049	SLIDER	TATA spare parts
3123531062	THRUST WASHER 2.0THK	TATA spare parts
3123531076	PIN ADJUSTING	TATA spare parts
3123531125	THREADED RING	TATA spare parts
3123531162	THRUST WASHER 1.95THK	TATA spare parts
3123531173	LOCK PLATE	TATA spare parts
3123531224	THRUST WASHER	TATA spare parts
3123531262	THRUST WASHER 2.05 MM	TATA spare parts
3123531352	SHIM	TATA spare parts
3123531452	SHIM	TATA spare parts
3123531462	THRUST WASHER 2.15 THK	TATA spare parts
3123531562	THRUAT WASHER REAR AXLE SHAFT GEAR	TATA spare parts
3123531662	THRUST WASHER 2.30THK	TATA spare parts
3123531951	SPACER RING 312	TATA spare parts
3123532852	SHIM	TATA spare parts
3123532952	SHIM	TATA spare parts
3123533052	WASHER PINION	TATA spare parts
3123533152	SHIM	TATA spare parts
3123533252	SHIM	TATA spare parts
3123560126	NUT GROOVED	TATA spare parts
3123560126DB	GROOVED RING	TATA spare parts
3123561079	GASKET	TATA spare parts
3123571026	GROOVED NUT	TATA spare parts
3123571026AE	GROOVED NUT 713	TATA spare parts
3123571052	SPACER	TATA spare parts
3123571082	OIL CATCHER 312	TATA spare parts
3124001087	ASSY WING NUT AND RING	TATA spare parts

3124021071	WHEEL MOUNTING PIN	TATA spare parts
3124031029	HOOK	TATA spare parts
3124101251	CENTRE BEARING 76D	TATA spare parts
3124101430	COUPLING FLANGE	TATA spare parts
3124107302	PROP SHAFT REAR	TATA spare parts
3124107502	PROP SHAFT FRONT	TATA spare parts
3124107602	ASSY PROPELLER SHAFT REAR COMPLETE	TATA spare parts
3124107802	PROP SHAFT RR 70X3X1264	TATA spare parts
3124108202	PROP SHAFT REAR 70X3X865	TATA spare parts
3124110051	RING	TATA spare parts
3124111094	BALANCING WEIGHT 95MM WIDE	TATA spare parts
3124111111	UNIVERSAL JOINT FLANGE	TATA spare parts
3124111111AE	UNIVERSAL JOINT FLANGE 713 715	TATA spare parts
3124111111AN	FLANGE YOKE DIA 70 - 8H	TATA spare parts
3124111205	UNIVERSAL JOINT FORK	TATA spare parts
3124111233	CLOSING RING	TATA spare parts
3124111558	GREASE RETAINER	TATA spare parts
3124111702	REAR END PIECE	TATA spare parts
3124112102	FRONT END PIECE	TATA spare parts
3124131112	RUBBER PAD	TATA spare parts
3124131180	PACKING RING	TATA spare parts
3124131231	SPACER RING CEN BRG	TATA spare parts
3124131258	GREASE RETAINER	TATA spare parts
3124131361	PROTECTIVE CAP	TATA spare parts
3124200937	PIPE AIR	TATA spare parts
3124201038	ADJUSTER ECCENTRIC	TATA spare parts
3124201338	ADJUSTER ECCENTRIC	TATA spare parts
3124201430	BRAKE TUBE LH	TATA spare parts
3124201578	SUPPORT	TATA spare parts
3124201678	SUPPORT	TATA spare parts
3124202412	BRAKE LEVER	TATA spare parts
3124203280	BRAKE SHAFT	TATA spare parts
3124203412	BRAKE LEVER	TATA spare parts
3124204180	BRAKE SHAFT	TATA spare parts
3124204983	INTERMEDIATE LEVER LH	TATA spare parts
3124211068	COVER	TATA spare parts
3124211073	LOCK	TATA spare parts
3124211190	THRUST SPRING	TATA spare parts
3124211192	RETURN SPRING SHORT	TATA spare parts
3124211310	BRAKE LINING RS1	TATA spare parts
3124211410	BRAKE LINING RS2	TATA spare parts
3124211774	SPRING PIN	TATA spare parts
3124231051	GUARD RING	TATA spare parts
3124231089	SPRING CAP	TATA spare parts
3124231094	LINK BRAKE SHOE	TATA spare parts
3124231174	CLEVIS PIN WITH GROOVE	TATA spare parts
3124231187	BEARING RING	TATA spare parts

3124231189	SPRING SEAT	TATA spare parts
3124231418	PIN BR SHOE LINK	TATA spare parts
3124231552	SPACER 0.2 MM	TATA spare parts
3124231594	LINK BRAKE SHOE	TATA spare parts
3124231652	SPACER 1.0 MM BR SHAFT	TATA spare parts
3124231718	PIN	TATA spare parts
3124231752	SPACER 2.0 MM	TATA spare parts
3124232110	BRAKE LINING STD	TATA spare parts
3124232192	RETURN SPRING LONG	TATA spare parts
3124232210	BRAKE LINING RS1	TATA spare parts
3124232310	BRAKE LINING RS2	TATA spare parts
3124232410	BRAKE LINING STD	TATA spare parts
3124232510	BRAKE LINING RS1	TATA spare parts
3124261150DB	BUSH	TATA spare parts
3124261344	FORK 130 MM	TATA spare parts
3124261550	BUSH	TATA spare parts
3124261574	BEARING PIN	TATA spare parts
3124261708	PILLOW BLOCK	TATA spare parts
3124261812	BRAKE LEVER	TATA spare parts
3124261912	BRAKE LEVER LH	TATA spare parts
3124271196	RUBBER SEALING CUP	TATA spare parts
3124271215	PAWL BRAKE	TATA spare parts
3124271220	HANDLE BRAKE	TATA spare parts
3124271550	BUSH	TATA spare parts
3124272250	BUSH	TATA spare parts
3124272350	BUSH	TATA spare parts
3124273941	HOLDER PAWL ROD	TATA spare parts
3124276310	INTERMEDIATE LEVER LH	TATA spare parts
3124276410	INTERMEDIATE LEVER RH	TATA spare parts
3124281026	ADAPTOR	TATA spare parts
3124281340DB	BRACKET BR HOSE	TATA spare parts
3124291403	PIPE AIR 15 X 1.5 X 818	TATA spare parts
3124291802	PIPE AIR	TATA spare parts
3124291919	PIPE AIR	TATA spare parts
3124295002	PIPE AIR	TATA spare parts
3124295902	PIPE AIR	TATA spare parts
3124296202	PIPE AIR	TATA spare parts
3124298002	PIPE AIR	TATA spare parts
3124298102	PIPE AIR	TATA spare parts
3124311097	YOKE	TATA spare parts
3124311592	PULL ROD	TATA spare parts
3124312092	STUD	TATA spare parts
3124322616	SUPPORT	TATA spare parts
3124601335	STEERING BRACKET	TATA spare parts
3124601630	BRACKET HALF	TATA spare parts
3124602029	BRACKET STRG GEAR	TATA spare parts
3124605205	DRAG LINK	TATA spare parts

3124608908DB	STRG SPINDLE	TATA spare parts
3124621150	BUSH	TATA spare parts
3124634001DB	PITMAN ARM	TATA spare parts
3124634801	PITMAN ARM	TATA spare parts
3124701126	RISING PIPE	TATA spare parts
3124701271	FUEL PIPE	TATA spare parts
3124702372	OVER FLOW RETURN LINE	TATA spare parts
3124706570	OVER FLOW RETURN LINE	TATA spare parts
3124712015	AIR VENT PIPE	TATA spare parts
3124760026	RUBBER HOSE	TATA spare parts
3124761426	RUBBER HOSE	TATA spare parts
3124761535	HOLDING PLATE	TATA spare parts
3124761735DB	BRACKET	TATA spare parts
3124901130	ASSY HEAT PROTECTION SHIELD	TATA spare parts
3124902720	EXHAUST PIPE FRONT	TATA spare parts
3124921080	GASKET	TATA spare parts
3124921211	FLANGE	TATA spare parts
3124921302	EXHAUST PIPE	TATA spare parts
3124921740	ROHRSCHEUE	TATA spare parts
3125000045	RADIATOR STAY LH	TATA spare parts
3125001036	CAP RADIATOR SHELL	TATA spare parts
3125001110	T EMBLEM	TATA spare parts
3125002901	RADIATOR ASSY L/PC	TATA spare parts
3125021035	SPRING	TATA spare parts
3125021234	SUPPORT	TATA spare parts
3125101638	PEDAL FLOOR REAR	TATA spare parts
3125201473	BRACKET W/H LH	TATA spare parts
3125201627DB	COVER MOULDING	TATA spare parts
3125203635	SUPPORT CENTRE	TATA spare parts
3125211282	RUBBER RING	TATA spare parts
3125251351	BRKT NO PLATE	TATA spare parts
3125271016	CLAMP	TATA spare parts
3125271118	BRACKET	TATA spare parts
3125271711	HINGE PORTION	TATA spare parts
3125271717	HOOD FASTENER BLACK	TATA spare parts
3125401171DB	SUPPORT	TATA spare parts
3125402040	ELECTRIC CABLE	TATA spare parts
3125421083	RUBBER HOSE	TATA spare parts
3125424843	PIPE AIR 6 X 0.7 X 1610	TATA spare parts
3125441124	RUBBER PLATE	TATA spare parts
3125451501	FUSE BOX	TATA spare parts
3125461020	EARTH STRAP	TATA spare parts
3125461385	PROTECTIVE TUBE	TATA spare parts
3125800085	ADJUSTING FORK	TATA spare parts
3125840198DB	ACCESSORY TACHO	TATA spare parts
3125890003	SPANNER	TATA spare parts
3125890007	FACE SPANNER	TATA spare parts

3125890009	SOCKET WRENCH	TATA spare parts
3125890011	SCREW DRIVER	TATA spare parts
3125890021	FIXTURE	TATA spare parts
3125890031	CLAMPING DEVICE	TATA spare parts
3125890033	PULLER	TATA spare parts
3125890037	SPECIAL PLIER	TATA spare parts
3125890039	DRIFT WITH SLEEVE	TATA spare parts
3125890061	CENTERING ARBOR	TATA spare parts
3125890103	SPANNER	TATA spare parts
3125890109	SOCKET WRENCH	TATA spare parts
3125890111	SCREW DRIVER	TATA spare parts
3125890123	FEELER STRIPS	TATA spare parts
3125890131	HANDLES	TATA spare parts
3125890133	PULLER PIECE	TATA spare parts
3125890135	DRIFT	TATA spare parts
3125890207	SPECIAL WRENCH	TATA spare parts
3125890209	UNI-JOINT SOC. WRENCH/F-ENG.MTG BOLT	TATA spare parts
3125890223	SWAN NECK TUBE	TATA spare parts
3125890231	VALVE SPRING COMPRESSOR	TATA spare parts
3125890233	PULLER	TATA spare parts
3125890235	SUPPORT/EXTRACTION T-PINION BRG/RA312	TATA spare parts
3125890261	PLIERS	TATA spare parts
3125890307	SPECIAL WRENCH	TATA spare parts
3125890309	SOCKET WRENCH	TATA spare parts
3125890331	SOPPORT RAIL	TATA spare parts
3125890333	PULLER / REMOVE FAN PULLEY	TATA spare parts
3125890335	EXTRACTOR	TATA spare parts
3125890339	DRIFT	TATA spare parts
3125890391	SUPPORT RAIL	TATA spare parts
3125890407	WRENCH	TATA spare parts
3125890431	VALVE SPRING COMPRESSOR	TATA spare parts
3125890433	PULLER	TATA spare parts
3125890435	DRIFT	TATA spare parts
3125890507	WRENCH	TATA spare parts
3125890533	PULLER	TATA spare parts
3125890607	WRENCH	TATA spare parts
3125890631	RING PISTON COMPRESSOR	TATA spare parts
3125890633	PULLER	TATA spare parts
3125890707	HOLDER	TATA spare parts
3125890733	PULLER	TATA spare parts
3125890739	DRIFT	TATA spare parts
3125890831	FIXTURE	TATA spare parts
3125890839	DRIFT	TATA spare parts
3125890907	SPECIAL WRENCH	TATA spare parts
3125890933	PULLER	TATA spare parts
3125891023	SETTING GAUGE/37 ANFLE OF LOCK/F-AXLE	TATA spare parts
3125891031	FIXTURE	TATA spare parts

3125891039	DRIFT	TATA spare parts
3125891123	GAUGE RA BEND CHECKING	TATA spare parts
3125891233	PULLER	TATA spare parts
3125891239	DRIFT	TATA spare parts
3125891333	PULLER	TATA spare parts
3125891339	DRIFT FOR PRESSING OUT PISTON PIN	TATA spare parts
3125891433	PULLER	TATA spare parts
3125891439	DRIFT-Install.of Drive shaft & tail brg.	TATA spare parts
3125891533	PULLER	TATA spare parts
3125891639	DRIFT	TATA spare parts
3125891733	PULLER	TATA spare parts
3125891739	DRIFT	TATA spare parts
3125891833	PULLER TO DRG	TATA spare parts
3125891839	DRIFT	TATA spare parts
3125892033	PULLER	TATA spare parts
3125892133	PULLER	TATA spare parts
3125892233	PULLER	TATA spare parts
3125892333	PULLER	TATA spare parts
3125892533	PULLER	TATA spare parts
3125893033	PULLER	TATA spare parts
3125893039	DRIFT	TATA spare parts
3125893133	PULLER	TATA spare parts
3125893333	PULLER	TATA spare parts
3125893339	SLEEVE	TATA spare parts
3125893433	PULLER	TATA spare parts
3125893539	DRIFT	TATA spare parts
3125893733	PULLER /SPEEDOMETER THRD.BUSHING	TATA spare parts
3125893833	PULLER	TATA spare parts
3128180413	STEEL SHIM	TATA spare parts
3128582230	U CLAMP	TATA spare parts
3129810301	BEARING	TATA spare parts
3129811325	BEARING BALL GROOVED	TATA spare parts
3129870110	FELT STRAP	TATA spare parts
3129900004	HEX SCREW	TATA spare parts
3129900017	LOCKING BOLT	TATA spare parts
3129900043	CAP SUPPORT	TATA spare parts
3129900096	HALF ROUND RIVET	TATA spare parts
3129900148	SPRING WASHER	TATA spare parts
3129900195DB	HOLLOW RIVET	TATA spare parts
3129900202DB	HEX HEAD SCREW	TATA spare parts
3129900251	BALL PIN NUT M12X1	TATA spare parts
3129900251AE	HEX NUT(BALL PIN-RCKER ARM)-713	TATA spare parts
3129900301	HEX HEAD BOLT M12X27 10K	TATA spare parts
3129900351	HEX NUT	TATA spare parts
3129900540	WASHER	TATA spare parts
3129900640	WASHER	TATA spare parts
3129901038	EYE BOLT	TATA spare parts

3129901040	WASHER	TATA spare parts
3129901138	EYE BOLT	TATA spare parts
3129901151	HEX NUT	TATA spare parts
3129901705	STUD BOLT	TATA spare parts
3129901740	WASHER	TATA spare parts
3129901740AE	WASHER 715	TATA spare parts
3129901851DB	HEX NUT	TATA spare parts
3129902001	HEX HEAD BOLT MAIN BRG CAP	TATA spare parts
3129902501	STUD.BOLT.M12X1.5X1.75X145	TATA spare parts
3129903201	SET SCREW	TATA spare parts
3129903301	HEX HEAD SCREW	TATA spare parts
3129904001	HEX SCREW 12 MM	TATA spare parts
3129904640	WASHER	TATA spare parts
3129904640DB	WASHER	TATA spare parts
3129910120	BALL PIN	TATA spare parts
3129910260	DOWEL PIN	TATA spare parts
3129910460	PIN	TATA spare parts
3129910860	SET PIN	TATA spare parts
3129911035	SPACER GUIDE PLATE	TATA spare parts
3129911205	PIN	TATA spare parts
3129911205DB	PIN	TATA spare parts
3129911362	DOWEL PIN	TATA spare parts
3129912840	SPACER HORN	TATA spare parts
3129930005	SPRING SHORT	TATA spare parts
3129930025	SPRING CLIP	TATA spare parts
3129930701	SPRING LONG	TATA spare parts
3129931001	PRESSURE SPRING BS4	TATA spare parts
3129931401	RETURN SPRING	TATA spare parts
3129931410	TENSION SPRING	TATA spare parts
3129931510	RETURN SPRING BR LEVER	TATA spare parts
3129931701	PRESSURE SPRING BS4	TATA spare parts
3129931901	PRESSURE SPRING	TATA spare parts
3129932301	PRESSURE SPRING	TATA spare parts
3129932510	RETURN SPRING CL RELEASE	TATA spare parts
3129932601	PRESSURE SPRING	TATA spare parts
3129932801	SPRING GENERATOR	TATA spare parts
3129933801	THRUST SPRING	TATA spare parts
3129933901	THRUST SPRING	TATA spare parts
3129934101	SPRING	TATA spare parts
3129934201	PRESSURE SPRING BS4	TATA spare parts
3129934701	SPRING CONECTING NIPPLE	TATA spare parts
3129934901	THRUST SPRING	TATA spare parts
3129936501	PRESSURE SPRING	TATA spare parts
3129937201	PRESSURE SPRING	TATA spare parts
3129937301	PRESSURE SPRING	TATA spare parts
3129940034	SPRING RING	TATA spare parts
3129940132	LOCKING PLATE	TATA spare parts

3129940134	SPRING RING	TATA spare parts
3129940141	SNAP RING	TATA spare parts
3129940141DB	SNAP RING	TATA spare parts
3129940232	LOCKING PLATE	TATA spare parts
3129940302	LOCKING PLATE	TATA spare parts
3129940310	LOCKING PLATE	TATA spare parts
3129940330	LOCKING PLATE	TATA spare parts
3129940332	LOCKING PLATE/FOR CLAMP TO HOUSING	TATA spare parts
3129940705	LOCKING PLATE	TATA spare parts
3129941030DB	LOCKING PLATE	TATA spare parts
3129941032	LOCKING PLATE	TATA spare parts
3129941135	SPRING RING 2.5 THICK	TATA spare parts
3129941135DB	SPRING RING	TATA spare parts
3129941201	LOCKING PLATE	TATA spare parts
3129941209	LOCKING PLATE	TATA spare parts
3129941235	SNAP RING	TATA spare parts
3129941301	LOCKING PLATE	TATA spare parts
3129941435	SPRING RING 2.65 THK	TATA spare parts
3129941735DB	SPRING RING	TATA spare parts
3129950033DB	TRIPLE CLAMP	TATA spare parts
3129950232	CLIP	TATA spare parts
3129950332	DOUBLE CLAMP	TATA spare parts
3129950510	CLAMP	TATA spare parts
3129951020	FASTENING CLIP	TATA spare parts
3129951040	CLIP	TATA spare parts
3129951401	CLIP	TATA spare parts
3129951620	FASTENING CLIP	TATA spare parts
3129952020	BEFESTIGUNGSSCHELLE BS6-PH2	TATA spare parts
3129952220	CLIP	TATA spare parts
3129952401	CLIP	TATA spare parts
3129952420	CLAMP	TATA spare parts
3129952601	CLIP	TATA spare parts
3129953220	CLAMP	TATA spare parts
3129970230	SCREW PLUG	TATA spare parts
3129970330	SCREW PLUG	TATA spare parts
3129970481	RUBBER GROMMET	TATA spare parts
3129970581	RUBBER GROMMET	TATA spare parts
3129970582	HOSE BRAKE TUBE	TATA spare parts
3129970630DB	SCREW PLUG	TATA spare parts
3129970681	RUBBER GROMMET	TATA spare parts
3129970840	GASKET RING	TATA spare parts
3129970982	RUBBER SLEEVE	TATA spare parts
3129971002	THREADED PLUG	TATA spare parts
3129971103	SLOTTED PLUG	TATA spare parts
3129971180	FLANGE GASKET	TATA spare parts
3129971440	RUBBER RING	TATA spare parts
3129972182	RUBBER HOSE	TATA spare parts



3129973482	RUBBER HOSE	TATA spare parts
3129976182	RUBBER HOSE	TATA spare parts
3130000390	HOSE-OVERFLOW ENG	TATA spare parts
3130000630	HOSE-OVERFLOW ENG	TATA spare parts
31311GB/T297-94	ROW STEEP ROLLER BEARING	TATA spare parts
31366	SPACER WASHER	TATA spare parts
3140160121	GASKET CYL HEAD COVER 4SP/497	TATA spare parts
3140160220	CYLINDER HEAD GASKET	TATA spare parts
3140350214	SPACER	TATA spare parts
314147	MINOR OVEHAUL KIT	TATA spare parts
3141550228	CLAMPING PIECE	TATA spare parts
3141800260	SEALING RING	TATA spare parts
3141801538	FILTER HEAD ASSY	TATA spare parts
3141840117	SOCKET	TATA spare parts
3141840179	GASKET	TATA spare parts
3141840261	SEALING RING	TATA spare parts
3141840820	SPRING	TATA spare parts
3142620076	SOCKET	TATA spare parts
3142620437	SYNCHRO CONE GBS-24	TATA spare parts
3142650349	SLIDING KEY INTER LEVER	TATA spare parts
314310080001	FRP ENGINEHOOD FOR 407 BS3	TATA spare parts
314310090001	FRP PODEST FOR 407 BS3	TATA spare parts
314310120001	FRP PODEST FOR 709 BS3	TATA spare parts
314310180001	FRP ENGINEHOOD FOR MAXICAB	TATA spare parts
314310190001	FRP ENGINEHOOD FOR 407 BS3	TATA spare parts
314310200001	FRP PODEST FOR 709 BS3	TATA spare parts
314410670001	REAR FRP	TATA spare parts
314410750001	DOOR FRAME ASSEMBLY	TATA spare parts
314410780001	FRP KIDZZ REAR WITH REAR DOOR AP	TATA spare parts
314410860001	FRP INNER PANEL (TAIL LAMP )RH	TATA spare parts
314410880001	FRP INNER PANEL (TAIL LAMP ) LH	TATA spare parts
314410890001	REAR FRP	TATA spare parts
314410920001	REAR FRP	TATA spare parts
314410930001	FRP INNER SKIN	TATA spare parts
314421120001	REAR EMBOSSED PANEL	TATA spare parts
314421390001	DOOR FRAME ASSEMBLY	TATA spare parts
314421400001	DOOR FRAME ASSEMBLY	TATA spare parts
3149900363	SEALING PLUG	TATA spare parts
3150380072	HEX NUT	TATA spare parts
3150770151	BUTTING RING	TATA spare parts
3157000350	BRKT-OIL DIP STICK FRAME	TATA spare parts
3157000351	BRKT-OIL DIP STICK FRAME	TATA spare parts
3159900051	LOCK NUT	TATA spare parts
3159900801	DRAIN PLUG	TATA spare parts
3159971030	SCREW PLUG	TATA spare parts
3159972182	RUBBER HOSE	TATA spare parts
316200	TUBE FUEL SUPPLY	TATA spare parts

3162000	TUBE FUEL SUPPLY	TATA spare parts
3162001	MANIFOLD FUEL	TATA spare parts
3162002	TUBE FUEL SUPPLY	TATA spare parts
3162004	ISOLATOR VIBRATION	TATA spare parts
3162005	SPACER FAN PILOT	TATA spare parts
3162253	CAMBUSH INSTALLATION / REMOVAL TOOL	TATA spare parts
3162871	ENGINE LIFTING FIXTURE	TATA spare parts
3163054	CAMSHAFT GEAR INSTALLATION / REMOVAL TOOL	TATA spare parts
3163096	Cable	TATA spare parts
3163099	KIT ADOPTOR	TATA spare parts
3163196	TORQUE WRENCH ADAPTER	TATA spare parts
3163293	BOOT PLIER	TATA spare parts
3163597	Cable	TATA spare parts
3164025	FUEL CONNECTOR REMOVER	TATA spare parts
3164027	WIRING REPAIR KIT	TATA spare parts
3164055	VALVE STEM SEAL INSTALLER	TATA spare parts
3164067	THREE-BOND SEALANT	TATA spare parts
3164098	CONNECTOR ELC REPAIR	TATA spare parts
3164100	CONNECTOR ELC REPAIR	TATA spare parts
3164111	LEAD ELECTRICAL TEST	TATA spare parts
3164113	LEAD ELECTRICAL TEST	TATA spare parts
3164117	TERMINAL ELC CNR REPAIR	TATA spare parts
3164131	TERMINAL ELC CNR REPAIR	TATA spare parts
3164329	VALVE SPRING COMPRESSOR	TATA spare parts
3164488	DIGITAL MULTMETER	TATA spare parts
3164489	DIGITAL MULTMETER	TATA spare parts
3164490	ADAPTER CURRENT - CLAMP-ON TO BE USED WITH	TATA spare parts
3164491	PRESSURE VACCUM MODULE	TATA spare parts
3164498	BEAD PROBE	TATA spare parts
3164499	DIGITAL THERMOMETER	TATA spare parts
3164659	CRANKSHAFT SEAL REPLACER	TATA spare parts
3164660	CRANKSHAFT SEAL REPLACER REAR	TATA spare parts
3164956	Dielectric grease	TATA spare parts
3165035	CAM BUSHING DRIVER	TATA spare parts
3165045	CAMSHAFT BUSHING TOOL	TATA spare parts
3165141	Cable	TATA spare parts
3165170	VALVE SEAT EXTRATOR COLLET	TATA spare parts
3165179	COMBUSTIBLE GAS DETECTOR	TATA spare parts
31653113008	MACHINEREAMERS TAPERSHANK&TAPERFLUTE13	TATA spare parts
31653115001	MACHINEREAMERS TAPERSHANK&TAPERFLUTE15	TATA spare parts
3169972182	RUBBER HOSE	TATA spare parts
317010640001	FLAP COMPL.(SPARE WHEEL)	TATA spare parts
317010650001	SKIRT PANEL	TATA spare parts
317010660001	SKIRT PANEL	TATA spare parts
317010690001	SKIRT PANEL COMPL.	TATA spare parts
317010690002	SKIRT PANEL COMPL.	TATA spare parts
317010690003	SKIRT PANEL COMPL.(F.T)	TATA spare parts

317010690004	SKIRT PANEL COMPL.	TATA spare parts
317010710001	BATTERY BOX FLAP COMPLETE	TATA spare parts
317011250001	FLAP ASSY (FT) BS6-PH2	TATA spare parts
317020300001	SKIRT PANEL L=1280	TATA spare parts
317020310001	SKIRT PANEL L=2245	TATA spare parts
317020320001	SKIRT PANEL L=595	TATA spare parts
317020330001	SKIRT PANEL L=1425	TATA spare parts
317020340001	SKIRT PANEL L=1210	TATA spare parts
3172670008	BALL PIECE	TATA spare parts
3175891533	PULLER	TATA spare parts
3179930501	PRESSURE SPRING	TATA spare parts
3179970481	RUBBER GROMMET	TATA spare parts
319001003001	SIDE PILLER ASSEMBLY LH	TATA spare parts
319001003002	SIDE PILLER ASSEMBLY RH BS6	TATA spare parts
319001003003	WINDSHIELD LOWER ROOF STICK ASSY	TATA spare parts
319002003001	ROOF ARCH ASSY	TATA spare parts
319003002049	WINDOW GRILL FIXING BRACKET ASSY	TATA spare parts
319003003022	DOOR PILLAR BS6	TATA spare parts
319003003065	PASSENGER DOUBLE DOOR ASSY FRONT	TATA spare parts
319003003066	PASSENGER DOUBLE DOOR ASS REAR	TATA spare parts
319003003098	SIDE STRUCTURE LH FRONT_Y1-ROLLOVER	TATA spare parts
319003003179	FRONT WHEEL ARC ASSY_LH_Y1	TATA spare parts
319003004008	PASSENGER DOUBLE DOOR ASSY FRONT	TATA spare parts
319003004009	PASSENGER DOUBLE DOOR ASSY FRONT	TATA spare parts
319003013449	RH 'A' PILLAR BS6	TATA spare parts
319003014024	PASSENGER DOOR FRONT COLUMN	TATA spare parts
319003083014	SUPPORT PLATE 1	TATA spare parts
319003083019	RVM MOUNTING BRACKET	TATA spare parts
319007002087	Y1-MODULAR PLATE & FUSE BOX BKT ASSY	TATA spare parts
319007002148	FRONT ROOF STRUCTURE ASSEMBLY	TATA spare parts
319010231001	LPO Y1 FRONT WINDSHIELD 2550	TATA spare parts
319010231002	FRONT WINDSHIELD W/O IR- GEN 5-9X9 WP	TATA spare parts
319010239001	WINDSHIELD FRONT Y1 LPO WP BS3/4	TATA spare parts
319010239004	WINDSHIELD FRONT Y1 LPO RM WP BS3/4	TATA spare parts
319010900016	COMPRESSOR F400	TATA spare parts
319010900017	STOP VALVE 3/4 INCH	TATA spare parts
319010900018	EXPANSION VALVEç	TATA spare parts
319010900019	FILTER DRIER 5/8 INCH	TATA spare parts
319010900020	SUCTION HOSE WITH PRE CRIMPED FITTINGS	TATA spare parts
319010900021	DISCHARGE HOSE WITH PRE CRIMPED FITTINGS	TATA spare parts
319010900022	RETURN AIR GRILL	TATA spare parts
319010900023	SIGHT GLASSç	TATA spare parts
319010900024	CONDENSER COIL R CC230	TATA spare parts
319010900025	AXIAL FAN BASIC	TATA spare parts
319010900026	RADIAL BLOWER	TATA spare parts
319010900027	EVAP COIL LEFT SIDE	TATA spare parts
319010900028	EVAP COIL RIGHT SIDE	TATA spare parts

319010900029	FILTER DRIER	TATA spare parts
319010900030	MULTIFLOW CONDENSOR	TATA spare parts
319010900031	EXPANSION VALVE	TATA spare parts
319010900032	EVAPORATOR COIL R CC230	TATA spare parts
319010900033	PRE CRIMPED DISCHARGE HOSE	TATA spare parts
319010900034	PRE CRIMPED SUCTION HOSE	TATA spare parts
319010900035	CONDENSOR FAN GRILL	TATA spare parts
319010900036	EVAPORATOR COIL L CC230	TATA spare parts
319010900037	EVAPORATOR COVER CC230	TATA spare parts
319010900038	CONDENSER COVER CC230	TATA spare parts
319010900039	O RING 3/4 IN	TATA spare parts
319010900040	O RING 5/8 IN	TATA spare parts
319010900041	CONDENSER COIL L CC230	TATA spare parts
319010900042	NEW ALTERNATOR 110A 24V	TATA spare parts
319010900043	COMPRESSOR BRACKET KIT TATA YI/497	TATA spare parts
319010900044	COMPRESSOR BELT	TATA spare parts
319010901006	AL PROF FOR DOOR SEALING 3MTR	TATA spare parts
319010901007	L PROF FOR EXT PAN RH/LH 2.5MTR	TATA spare parts
319010901008	SIDE EXT PAN FINISH ALU PROF 2MTR	TATA spare parts
319010901009	RUBBER FOR SIDE EXT PAN G2 6MTR	TATA spare parts
319010901011	MFC COIL	TATA spare parts
319010901012	EVAPORATOR COIL LH	TATA spare parts
319010901013	EVAPORATOR COIL RH	TATA spare parts
319010901014	DASH CONTROL 12/24V GL	TATA spare parts
319010901015	THERMISTER ABS 30L PERC TERMINAL	TATA spare parts
319010901016	REUSABLE FLAT 45 20 FITTING	TATA spare parts
319010901017	REUSABLE FLAT 45 16 FITTING	TATA spare parts
319010901018	SUCTION END FITTING PAD TYPE	TATA spare parts
319010901019	DISCHARGE END FITTING PAD TYPE	TATA spare parts
319010901020	SUCTION END FITTING PAD TYPE	TATA spare parts
319010901021	DISCHARGE END FITTING PAD TYPE	TATA spare parts
319010901022	EXPANSION VALVE	TATA spare parts
319010901023	RETURN AIR GRILL FILTER	TATA spare parts
319010901024	O RING CONNECTION - ADAPTER CC225	TATA spare parts
319010901025	UNION ORING 5/8 IN (16.0) (7/8X14UNF)	TATA spare parts
319010901026	O RING NUT BRASS 3/8 IN (5/8X18UNF)	TATA spare parts
319010901027	REUSABLE FITTING GASKET	TATA spare parts
319010901028	FUSE NUT	TATA spare parts
319010901029	FUSE 100A	TATA spare parts
319010901030	MAIN W/H	TATA spare parts
319010901031	MAIN W/H	TATA spare parts
319010901032	SS HOSE CLAMP (5 IN)	TATA spare parts
319010901033	O RING 1/4 IN	TATA spare parts
319010901034	O RING DIA 25.07 X 2.62 7/8 IN	TATA spare parts
319010901035	O RING DIA 29.20 X 5.2 1-1/8 IN	TATA spare parts
319010901036	DISCHARGE TUBING - [COMP X COND]	TATA spare parts
319010901037	CONDENSER-RECEIVER TUBING OULET (AL)	TATA spare parts

319010901038	RECEIVER SUB-COOLING TUBING INLET (AL)	TATA spare parts
319010901039	LIQ LN 1-TBNG¿ [LIQ LN 2-TBNG X TXV]	TATA spare parts
319010901040	SUCTION TUBING - [EVAP X COMP]	TATA spare parts
319010901041	LIQ LN 2 TBNG (AL)-[COND X LIQ LN 1]	TATA spare parts
319010901042	GAS HOSE 16 (DISCHARGE)	TATA spare parts
319010901043	GAS HOSE 20 (SUCTION)	TATA spare parts
319010901044	FIBRE BASE	TATA spare parts
319010901045	EVAPORATOR COVER	TATA spare parts
319010901046	O RING DIA 10.82 X TH 1.80¿ 1/2 IN	TATA spare parts
319010901047	O RING DIA 7.7 X TH 1.78¿ 3/8 IN	TATA spare parts
319010901048	RD BOTTLE	TATA spare parts
319010901049	RECEIVER DRIER BRACKET	TATA spare parts
319010901050	CONDENSER¿ BRACKET	TATA spare parts
319010901051	FAN PLATE - SPAL	TATA spare parts
319010901052	PRE CRIMPED DISCHARGE HOSE ASSY 7.7MTR	TATA spare parts
319010901053	PRE CRIMPED SUCTION HOSE ASSY 7.7MTR	TATA spare parts
319010901054	PRE CRIMPED DISCHARGE HOSE ASSY 7.7MTR	TATA spare parts
319010901055	PRE CRIMPED SUCTION HOSE ASSY 7.7MTR	TATA spare parts
319010901056	FAN PLATE BRACKET	TATA spare parts
319010901058	HOSE CLAMP 1 INCH	TATA spare parts
319010901059	HOSE CLAMP 1-3/8 INCH	TATA spare parts
319010901060	HOSE CLAMP 1-1/8 INCH	TATA spare parts
319010901073	Y1 DRIVER DOOR KIT FOR RETRO FITMENT	TATA spare parts
319010901092	BUTYL TAPE ROOF PANNELING 10MTRS	TATA spare parts
319010901094	2 SEAT 450CH TYP-1 BOTTOM COVER	TATA spare parts
319010901095	1 SEAT 450CH TYP-1 BACK REST COVER	TATA spare parts
319010901096	1 SEAT 450CH TYP-1 BOTTOM COVER	TATA spare parts
319010901097	SUCTION HOSE ASSY Y1 497 SPHEROS BS6	TATA spare parts
319010901101	ALUMINUM PROFILE 3MTRS	TATA spare parts
319010901104	PVC+ABS PROFILE FOR HATRACK-Y1 6MTR	TATA spare parts
319010901116	ASSY EVAPORATOR COIL LH & RH	TATA spare parts
319010901121	RUBBER PROFILE FOR INSPN COVER 1.5 MTRS	TATA spare parts
319010901142	GREY FINISHING RUBBER PROFILE 1MTR	TATA spare parts
319010901143	NEW VERTICAL WIPER_TPE 0.75 MTR	TATA spare parts
319010901154	VNL FLR 1.5THK RE CAN 5329-510-4_24SQM	TATA spare parts
319010901155	436X2020X0.72 PVC LAMINATED GI RAL 9001	TATA spare parts
319010901158	ROOF PC EXTRUSION 3.7MTR	TATA spare parts
319010901180	AC DUCT PC EXTRUSION 5MTR	TATA spare parts
319010901181	SELF ADHESIVE KINI FOAM FR 35 KG/CM3_SPD	TATA spare parts
319010901183	DRIVER DOOR KIT PART FOR VC 31901110006R	TATA spare parts
319010901185	VINYL_LW_3THK_RECANOPUS 5329-506-4 24SQM	TATA spare parts
319010901186	WELDING ROD GREY (ROUND) 10M	TATA spare parts
319010901189	GANGWAY LED SRTIP ACRYLI EV 3.3M	TATA spare parts
319010901191	INTERNAL FINISHING PROFILE-PVC 7 X 32.8	TATA spare parts
319010901192	WINDOW SIDE LED ACRYLIC PROFILE_ 6M	TATA spare parts
319010901193	ROOF ALUMINIUM PROFILE 5M	TATA spare parts
319010901195	FR XPE__GRAY_INSUL.TAPE 10M	TATA spare parts

319010901196	VELCRO(MALE&FEMALE)30MM WIDTH 50M	TATA spare parts
319010901197	DXPE-SS420-CLOSED FOAM 30 SQM	TATA spare parts
319010961002	Y1_42 WB AIS 140 RETRO KIT 2	TATA spare parts
319010961003	Y1_49 WB AIS 140 RETRO KIT 2	TATA spare parts
319010961004	Y1_52 WB AIS 140 RETRO KIT 2	TATA spare parts
319010961005	Y1 ELE_49 WB AIS 140 RETRO KIT 24V	TATA spare parts
319012002003	FRONT & REAR MUD FLAP ASSEMBLY (LLDPE)	TATA spare parts
319012083031	REAR MUDGUARD ATTACHING PROFILE	TATA spare parts
319012283001	FRONT LLDPE MUD FLAP LH	TATA spare parts
319012283002	REAR LLDPE MUD FLAP LH	TATA spare parts
319012283003	REAR LLDPE MUD FLAP RH	TATA spare parts
319012283004	FRONT LLDPE MUD FLAP RH	TATA spare parts
319012283009	FRONT AXLE REAR MUD FLAP_LH	TATA spare parts
319012283010	FRONT AXLE REAR MUD FLAP_RH	TATA spare parts
319015002001	DRIVER DOOR ASSEMBLY	TATA spare parts
319015002002	DRIVER DOOR FINISHING ASSEMBLY RHD	TATA spare parts
319015002011	DRIVER DOOR ASSEMBLYRHD	TATA spare parts
319015003002	DRIVER DOOR & LOCK KIT ASSY	TATA spare parts
319015003003	Y1 DRIVER DOOR ASSLY	TATA spare parts
319015003004	DRIVER DOOR HINGE ASSLY	TATA spare parts
319015003005	DRIVER DOOR HINGE ASSLY	TATA spare parts
319015003006	DD STR AND PANEL ASY	TATA spare parts
319015003007	DRIVER DOOR HANDLE	TATA spare parts
319015003036	DRIVER DOOR ASSLY WITH EXT HINGE LHD	TATA spare parts
319015003039	DRIVER DOOR & LOCK KIT ASSLY	TATA spare parts
319015004001	DRIVER DOOR ASSLY Y1	TATA spare parts
319015004010	DRIVER DOOR EXTERNAL PANELING	TATA spare parts
319015004023	DRIVER DOOR PANNELING AND STR ASSLY LHD	TATA spare parts
319015004028	LIFT DR STR & PANEL ASSY	TATA spare parts
319015004029	DRIVER DOOR EXTERNAL PANELING_EV9X9	TATA spare parts
319015083001	DRIVER DOOR INTERNAL REVITMENT	TATA spare parts
319015083004	DRIVER DOOR INTERNAL PANEL	TATA spare parts
319015083006	DRIVER DOOR INTERNAL PANELING	TATA spare parts
319015083009	DRIVER DOOR INTERNAL PANEL	TATA spare parts
319015083017	INTERNAL PANEL FOR DRIVERDOOR LHD	TATA spare parts
319015085065	LIFT DOOR INTERNAL PANEL BS6	TATA spare parts
319015183001	920 DR. DOOR INTERNAL PANEL - ALUMA	TATA spare parts
319015183002	DRIVER DOOR INTERNAL PANEL_ALUMA	TATA spare parts
319015183003	LIFT DOOR INTERNAL PANEL_ALUMA EV	TATA spare parts
319015263001	DRIVER DOOR CANOPY	TATA spare parts
319015303001	DRIVER DOOR LOCK FINISHING COVER	TATA spare parts
319015303002	DOOR BOLT FINISHING COVER	TATA spare parts
319015303003	DRIVER DOOR LOCK FINISHING COVER	TATA spare parts
319015303004	DOOR BOLT FINISHING COVER	TATA spare parts
319015303007	DRIVER DOOR CANOPY - PP	TATA spare parts
319015303013	DRIVER DOOR CANOPY_PP_EDGE CUT	TATA spare parts
319015303014	DOOR BOLT COVER- RAL-7024	TATA spare parts

319015303016	DRIVER DOOR LOCK COVER - RH_ RAL-7024	TATA spare parts
319015323001	DRIVER DOOR LOCK COVER	TATA spare parts
319015323002	DRIVER DOOR TOP ABS FINISHING	TATA spare parts
319015323004	WATER BOTTLE HOLDER ABS	TATA spare parts
319015323006	DRI DOOR HINGE COVER ABS	TATA spare parts
319015323009	920_DR. DOOR INTERNAL PANEL - ABS BS6	TATA spare parts
319016002001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
319016002002	EMERGENCY DOOR ASSEMBLY	TATA spare parts
319016003002	EMG DOOR & LOCK KIT ASSEMBLY	TATA spare parts
319016003003	Y1 EME DOOR ASSLY	TATA spare parts
319016003013	EMERGENCY DOOR ASSLY	TATA spare parts
319016003022	EMERGENCYDOORANDLOCKFLUSHTYPEASSLY	TATA spare parts
319016083001	EMERGENCY DOOR INTERNAL PANEL 1	TATA spare parts
319016083006	EMERGENCY DOOR INTERNAL PANEL 1	TATA spare parts
319016083010	EMERGENCY DOOR INTERNAL PANEL	TATA spare parts
319016083013	INTERNAL PANEL	TATA spare parts
319016083014	GRAY INTERNAL PANEL	TATA spare parts
319016083017	EME DOOR PANEL LHD	TATA spare parts
319016083018	INTERNALPANELFORFLUSHTYPEDOOR	TATA spare parts
319016183003	EMG DOOR INT PANEL ALUMA 720X1549	TATA spare parts
319016183007	EMG DOOR INTERNAL PANEL_ALUMA	TATA spare parts
319016303001	EMERGENCY DOOR LOCK COVER Y1	TATA spare parts
319016303002	EMERGENCY DOOR LOCK COVER	TATA spare parts
319016303004	EMERGENCY DOOR CANOPY - PP	TATA spare parts
319016303007	EMERGENCY DOOR LOCK COVER-RAL-7024	TATA spare parts
319017002001	PASSENGER DOOR ASSY RHD	TATA spare parts
319017002007	PNEUMATIC KIT 1210MM PASS DOOR	TATA spare parts
319017003071	PASSENGER DOOR LOCK	TATA spare parts
319017003072	PASSENGER DOOR PNEUMATIC SYSTEM	TATA spare parts
319017003090	PNEUMATIC PASSENGER DOOR ASSY 1210MM	TATA spare parts
319017003096	PASSENGER DOOR PNEUMATIC KIT TREE ASSY	TATA spare parts
319017003103	OUTSWING PASSENGER DOOR EXT PANEL ASSY	TATA spare parts
319017003104	PASSANGER DOOR ASSLY HANUMAN TRAVELS	TATA spare parts
319017003105	PNEUMATIC DOOR SUPPORT PLATE ASSLY	TATA spare parts
319017003114	830 FRONT ELEC-PNEUMATIC ASSY	TATA spare parts
319017003115	WIRING HARNESS	TATA spare parts
319017003116	1210 REAR ELEC-PNEUMATIC ASSY	TATA spare parts
319017003117	JK PASSENGER DOOR	TATA spare parts
319017003120	830 FRONT ELEC-PNEUMATIC ASSY	TATA spare parts
319017003121	1210 REAR ELEC-PNEUMATIC ASSY	TATA spare parts
319017003124	PNEUMATIC CYLINDER HOLDER	TATA spare parts
319017003125	PASS DOOR ASSY (PNEUMATIC 1210MM)	TATA spare parts
319017003134	BOTTOM BRACKET ASSY	TATA spare parts
319017003136	PARTITION DOOR ASSLY RED VIN	TATA spare parts
319017003141	TAPER PASS. DOOR ASSLY 830 LHD AC	TATA spare parts
319017003164	OUTSWING DOOR 1210X2113 APP Y1 9/9 ELEC	TATA spare parts
319017003165	OUTSWING TREE ASSY 1210X2113 APP Y1 9/9	TATA spare parts

319017003166	OUTSWING DOOR PNEU KIT ASSY 1210 Y19/9	TATA spare parts
319017003167	IN SWING DOOR ASSY 830X1943 APP	TATA spare parts
319017003172	PARTITION DOOR ASSLY VINYL	TATA spare parts
319017003174	WIRE HARNESS DETAILS_Y1_9/9_ELECTRIC	TATA spare parts
319017003182	PARTITION DOOR ASSLY VINYL	TATA spare parts
319017003188	FRONT NON BRYS JK TOP MTG 800X1918 APP B	TATA spare parts
319017003189	REAR NON BRYS JK TOP MTG 800X1918 APP BS	TATA spare parts
319017003190	FRONT BRYS JK BOTTOM MTG _900X1930 APP B	TATA spare parts
319017003191	REAR BRYS JK BOTTOM MTG _800X1930 APP BS	TATA spare parts
319017003192	FRONT NON BRYS JK TOP MTG SHELF PLATE	TATA spare parts
319017003193	REAR NON BRYS JK TOP MTG SHELF PLATE	TATA spare parts
319017003195	BRYS & NON BRYS JK DOOR WIRING HARNESS	TATA spare parts
319017003211	BRYS & NON BRYS JK DOOR WIRING HARNESS	TATA spare parts
319017003217	FRONT JK DOOR ASSY 780X1984 APP EV	TATA spare parts
319017003218	MIDDLE JK DOOR ASSY 1210X2096 APP EV	TATA spare parts
319017003219	FRONT 780 & MIDDLE 1210 PNEU LAYOUT EV	TATA spare parts
319017003229	Y1 LHD JK TAPER PASSENGER DOOR ASSY	TATA spare parts
319017003233	FRONT JK DOOR ASSY 800X2025 APP	TATA spare parts
319017003234	MIDDLE JK DOOR ASSY 1210X2025 APP	TATA spare parts
319017003236	FRONT & MIDDLE WIRING HARNESS_SHAVO	TATA spare parts
319017003237	FRONT 800 JK DOOR TOP SEALING BRUSH	TATA spare parts
319017004008	PASSENGER DOOR LOCK ASSY.	TATA spare parts
319017004015	STRUCTER ASSY.	TATA spare parts
319017004016	RUBBER AND GLASS ASSY.	TATA spare parts
319017004020	PARTITION DOOR GLASS ASSY	TATA spare parts
319017004021	PARTITION DOOR STR.	TATA spare parts
319017004026	PNEUMATIC PASSENGER DOOR 830MM	TATA spare parts
319017004028	PASSENGER DOOR ASSEMBLY	TATA spare parts
319017004033	MALE CLEVIS	TATA spare parts
319017004034	ROD END SPHERICAL	TATA spare parts
319017004035	FLOW CONTROL VALVE	TATA spare parts
319017004036	FILTER REGULATOR WITH GAUGE	TATA spare parts
319017004037	EMERGENCY SWITCH - INNER	TATA spare parts
319017004038	EMERGENCY SWITCH - OUTER	TATA spare parts
319017004039	PNEUMATIC TUBES	TATA spare parts
319017004040	PNEUMATIC TUBES	TATA spare parts
319017004041	DASHBORD EMERGENCY SWITCH	TATA spare parts
319017004042	ELECTRO PNEUMATIC SENSORS	TATA spare parts
319017004043	PE CONVERTER	TATA spare parts
319017004044	REED SWITCH	TATA spare parts
319017004045	DCV VALVE 5/2DOU.SOL 24 VDC	TATA spare parts
319017004046	ROCKER SWITCH OPEN/CLOSE	TATA spare parts
319017004047	5POLE RELAY	TATA spare parts
319017004048	WIRING HARNESS	TATA spare parts
319017004050	FRONT DOOR ASSEMBLY -830 APERTURE	TATA spare parts
319017004051	REAR DOOR ASSEMBLY-1210 APERTURE	TATA spare parts
319017004052	FRONT DOOR MECHANISM-830 APERTURE	TATA spare parts



319017004053	REAR DOOR MECHANISM-1260 APERTURE	TATA spare parts
319017004054	HINGE WITHOUT HANDLE	TATA spare parts
319017004055	HINGE WITH HANDLE	TATA spare parts
319017004056	HANDLE(YELLOW)	TATA spare parts
319017004057	DOOR GLASS(CLEAR)	TATA spare parts
319017004058	DOOR EDGES CENTER	TATA spare parts
319017004059	DOOR EDGES SIDE	TATA spare parts
319017004060	DOOR EDGES SENSOR	TATA spare parts
319017004061	SEALED ROLLER BEARING	TATA spare parts
319017004062	TOP PIVOT ASSEMBLY	TATA spare parts
319017004063	HINGE WITHOUT HANDLE	TATA spare parts
319017004064	HINGE WITH HANDLE	TATA spare parts
319017004065	HANDLE(YELLOW)	TATA spare parts
319017004066	BOTTOM BRACKET	TATA spare parts
319017004067	DOOR GLASS(CLEAR)	TATA spare parts
319017004068	DOOR EDGES CENTER	TATA spare parts
319017004069	DOOR EDGES SIDE	TATA spare parts
319017004070	DOOR EDGES SENSORç FEMALE	TATA spare parts
319017004071	DOOR EDGES SENSORç MALE	TATA spare parts
319017004072	SEALED ROLLER BEARING	TATA spare parts
319017004073	FRONT SHELFPLATE PANEL(BOTTOM MOUNTINGS	TATA spare parts
319017004074	AIR CYLINDER WITH ACCESERIES	TATA spare parts
319017004075	REED SWITCHçç WITH CLAMP 12 -24 V	TATA spare parts
319017004076	SHELFPLATE HARNESS	TATA spare parts
319017004077	AIR CYLINDER	TATA spare parts
319017004078	MALE ELBOW 1/4 X 6	TATA spare parts
319017004079	MALE ELBOW M5 X 6	TATA spare parts
319017004080	EMERGENCY SWITCH COVER - INNER	TATA spare parts
319017004081	EMERGENCY SWITCH COVER - OUTER	TATA spare parts
319017004082	FRONT PASSENGER DOOR ASSEMBLY_ ELECTRO P	TATA spare parts
319017004083	REAR PASSENGER DOOR ASSEMBLY_ ELECTRO PN	TATA spare parts
319017004085	HANDLE FOR LHD PASS. DOOR	TATA spare parts
319017004097	SLOW START VALVE ASSY_ M/S. SHAVO MAKE	TATA spare parts
319017004101	BRTS BOTTOM MTG PNEU KIT ASSY_ SHAVO	TATA spare parts
319017004107	M/S SHAVO PNEUMATIC KIT PARTS	TATA spare parts
319017004114	780 FRONT JK DOOR SHELF PLATE ASSY	TATA spare parts
319017004115	1210 MIDDLE JK DOOR SHELF PLATE ASSY	TATA spare parts
319017004122	REAR DOOR ASSEMBLY LH WITH GLASS AND GAS	TATA spare parts
319017004123	REAR DOOR ASSY RH WITH GLASS AND GASKET	TATA spare parts
319017004124	DIA CYL 50X100 SU	TATA spare parts
319017004125	DIA 50 X 100MM CYLINDER WITH FORK	TATA spare parts
319017004128	FRONT 780 JK DOOR SHELF PLATE	TATA spare parts
319017004130	FRONT JK DOOR SHELF PLATE ASSY	TATA spare parts
319017005017	PNEUMATIC FITTINGS-Y CONNECTOR	TATA spare parts
319017005018	PNEUMATIC FITTINGS- T CONNECTOR	TATA spare parts
319017005019	PNEUMATIC FITTINGS- I CONNECTOR	TATA spare parts
319017005029	BLUE ON/OFF SWITCH	TATA spare parts

319017005038	COUPLING DIKTING PNEUMATIC PARTS	TATA spare parts
319017005042	PANELLING DIKITING PNEUMATIC PARTS	TATA spare parts
319017005043	TRIM DIKITING PNEUMATIC PARTS	TATA spare parts
319017005044	FRONT DOOR MTG PLATE ASSY	TATA spare parts
319017005045	MIDDLE DOOR MTG PLATE ASSY	TATA spare parts
319017005046	PNALING STAGE DIKITING	TATA spare parts
319017005047	TRIM STAGE DIKITING	TATA spare parts
319017005048	SHELF PLATE FOR SINGLE DOOR EV	TATA spare parts
319017083001	CYLINDER HOLDING BRACKET	TATA spare parts
319017083004	LATCH CATCHER	TATA spare parts
319017083011	PASSENGER DOOR INT PANEL	TATA spare parts
319017084012	PASSENGER DOOR INTERNAL PANELLING	TATA spare parts
319017084015	PASSENGER DOOR EXT PANEL	TATA spare parts
319017084016	PASSENGER DOOR INT PANEL	TATA spare parts
319017084017	DOOR HINGE COVER	TATA spare parts
319017084029	PASSENGER DOOR EXT. PANEL	TATA spare parts
319017084032	PASSENGER DOOR EXT PANEL	TATA spare parts
319017084056	HINGE ASSEMBLY WITH HANDLE	TATA spare parts
319017084057	HINGE ASSEMBLY W/O HANDLE	TATA spare parts
319017084069	PASS DOOR STOPPER BRACKET BS6	TATA spare parts
319017215001	ALUMINIUM PROFILE	TATA spare parts
319017215002	AL PROFILE	TATA spare parts
319017215003	AL PROFILE	TATA spare parts
319017215004	AL PROFILE FOR PARTATION	TATA spare parts
319017215005	AL PROFILE FOR PARTATION	TATA spare parts
319017215006	AL PROFILE FOR PARTATION	TATA spare parts
319017233001	PARTITION DOOR GLASS	TATA spare parts
319017234003	PASSENGER DOOR GLASS	TATA spare parts
319017234004	PARTITION GLASS	TATA spare parts
319017234005	PASS DOOR TAPER GLASS	TATA spare parts
319017234006	REAR PASS. DOOR GLASS	TATA spare parts
319017234008	DOOR GLASS RUBBER PROFILE	TATA spare parts
319017234009	REAR PASS. DOOR GLASS RUBBER	TATA spare parts
319017234010	GLASS FOR FRONT DOOR EV	TATA spare parts
319017234011	GLASS FOR REAR DOOR EV	TATA spare parts
319017235001	PARTITION DOOR GLASS	TATA spare parts
319017263002	PASSENGER DOUBLE DOOR CANOPY	TATA spare parts
319017263003	PASSANGER DOOR CANOPY	TATA spare parts
319017284005	RUBBER	TATA spare parts
319017284006	RUBBER	TATA spare parts
319017284007	RUBBER	TATA spare parts
319017284008	DOOR GLASS RUBBER PROFILE	TATA spare parts
319017284009	REAR PASS. DOOR GLASS RUBBER	TATA spare parts
319017285001	PARTITION DOOR GLASS RUBBER	TATA spare parts
319017285002	PARTITION DOOR GLASS RUBBER	TATA spare parts
319017303002	PASSENGER DOOR CANOPY 783 APR - PP	TATA spare parts
319017303029	PASS DOOR CANOPY 783 APR-PP_EDGE CUT	TATA spare parts

319017323007	DOOR LOCK COVER FINISHING	TATA spare parts
319017323008	PASSENGER DOOR CYLINDER FINISHING COVER	TATA spare parts
319017323009	PARTITION DOOR FINISHING COVER FR	TATA spare parts
319017323010	PARTITION DOOR FINISHING COVER RR	TATA spare parts
319017323011	PASSENGER DOOR HINGE FINISHING TOP COVER	TATA spare parts
319017323012	PASSENGER DOOR LOCK COVER	TATA spare parts
319017323018	PASSENGER DOOR LOCK COVER 180MM	TATA spare parts
319017323019	PASSENGER DOOR INT PANEL-ABS	TATA spare parts
319017323023	PASSENGER DOOR LOCK COVER	TATA spare parts
319017323029	PARTITION DOOR ABS. FOR KUONI	TATA spare parts
319017323035	PARTITION DOOR ABS. FOR KUONIRAL 7040	TATA spare parts
319017323038	PASSENGER DOOR INT PANEL ABS	TATA spare parts
319017324001	PARTITION DOOR FINISHING - PS	TATA spare parts
319017324002	PARTITION DOOR FINISHING PANNEL	TATA spare parts
319017324004	DRIVER PARTITION DOOR FINISHING-PS	TATA spare parts
319017324005	DRIVER PARTITION DOOR FINISHING-PS	TATA spare parts
319017334001	STICKER FRONT DOOR 20X12	TATA spare parts
319017334002	STICKER REAR DOOR 20X12	TATA spare parts
319017912043	PASSENGER DOOR FITMENT DETAILS FOR SAKET	TATA spare parts
319017964001	LOWER MTG ASSY	TATA spare parts
319017964002	SPLINE SHAFT FOR JK DOOR	TATA spare parts
319017964003	ROLLER ASSEMBLY	TATA spare parts
319017964004	DOOR HANDLE	TATA spare parts
319017964006	BRTS PASS DOOR GLASS 800X1960 APP	TATA spare parts
319017964009	BRTS& NON BRTS DOOR HINGE WITH HANDLE	TATA spare parts
319017964010	BRTS & NON BRTS DOOR SIDE GASKET	TATA spare parts
319017964011	BRTS&NON BRTS DOOR HINGE GASKET	TATA spare parts
319017964012	BRTS& NON BRTS DOOR SIDE GASKET 2	TATA spare parts
319017964013	BRTS& NON BRTS DOOR BOTTOM GASKET/BRUSH	TATA spare parts
319017964015	BRTS&NON BRTS BOTTOM MTG GASKET PLATE	TATA spare parts
319017964016	BRTS&NON BRTS BOTTOM MTG PIN	TATA spare parts
319017964017	BRTS & NON BRTS DIA 14MM BALL	TATA spare parts
319017964018	SS STAR SCREW CSK M8 X 40	TATA spare parts
319017964019	STAR CSK BOLT M6X25	TATA spare parts
319017964020	SOCKET HEAD M6X25	TATA spare parts
319017964021	SOCKET HEAD M8X30	TATA spare parts
319017964022	M8 POP NUT	TATA spare parts
319017964023	NON BRTS PASS DOOR HANDLE	TATA spare parts
319017964025	T CONNECTOR 6 X 6 X 6 BS6	TATA spare parts
319017964027	SELF TAPPING SCREW 4.2X25	TATA spare parts
319017964028	DOOR BOTTOM SUPPORT PLATE	TATA spare parts
319017964030	DOOR GLASS OUTSWING DOOR 1210X2113 APP	TATA spare parts
319017964031	TOP BRACKET	TATA spare parts
319017964032	BOTTOM BRACKET	TATA spare parts
319017964034	DOOR RUBBER LH	TATA spare parts
319017964035	SEALING RUBBER	TATA spare parts
319017964036	APERTURE SEALING RUBBER	TATA spare parts

319017964037	LEAF RUBBER	TATA spare parts
319017964038	ALUMINIUM PROFILE	TATA spare parts
319017964040	DOOR GLASS INSWING DOOR 830X1943 APP	TATA spare parts
319017964041	DOOR RUBBER RH	TATA spare parts
319017964042	APERTURE SEALING RUBBER 1	TATA spare parts
319017964043	APERTURE SEALING RUBBER 2	TATA spare parts
319017964044	ALUMINIUM PROFILE	TATA spare parts
319017964045	DOOR RUBBER_INSWING DOOR	TATA spare parts
319017964046	DOOR TOP BRUSH DETAIL Y1 9/9	TATA spare parts
319017964047	GRAB HAND HOLD	TATA spare parts
319017964049	BOTTOM SWING ARM BRACKET	TATA spare parts
319017964050	GUIDE BRACKET	TATA spare parts
319017964057	PIVOT SHAFT	TATA spare parts
319017964062	FRONT CYLINDER BRACKET	TATA spare parts
319017964063	REAR CYLINDER BRACKET	TATA spare parts
319017964075	DRIVE SHAFT FRONT	TATA spare parts
319017964076	UPPER SWING ARM FRONT	TATA spare parts
319017964077	LOWER SWING ARM FRONT	TATA spare parts
319017964078	DRIVE SHAFT REAR	TATA spare parts
319017964079	UPPER SWING ARM REAR	TATA spare parts
319017964080	LOWER SWING ARM REAR	TATA spare parts
319017964081	DOOR PANEL FRONT	TATA spare parts
319017964082	DOOR PANEL REAR	TATA spare parts
319017964083	UPPER ROD FRONT	TATA spare parts
319017964085	SHELF PLATE	TATA spare parts
319017964086	SLIDE WAY_FRONT	TATA spare parts
319017964088	CYLINDER WITH MAGNETIC SENSOR	TATA spare parts
319017964089	CRANK	TATA spare parts
319017964091	LOWER ARM JOINT	TATA spare parts
319017964093	DOOR PANEL FRONT	TATA spare parts
319017964095	BOTTOM FIXED BRUSH FRONT	TATA spare parts
319017964097	DOOR GLASS INSWING DOOR 870X2005 APP	TATA spare parts
319017964098	GRAB HAND HOLD	TATA spare parts
319017964099	DOOR TOP BRUSH	TATA spare parts
319017964100	CANOPY 1210 APP	TATA spare parts
319017964109	CYLINDER BRACKET	TATA spare parts
319017964124	ROLLER ASSEMBLY/BEARING	TATA spare parts
319017964125	DOOR HANDLE	TATA spare parts
319017964126	HINGE WITH HANDLE	TATA spare parts
319017964127	HINGE WITHOUT HANDLE	TATA spare parts
319017964128	HINGE GASKET	TATA spare parts
319017964129	SIDE GASKET	TATA spare parts
319017964130	RUBBER STOPPER	TATA spare parts
319017964131	RUBBER STRIP	TATA spare parts
319017964132	MTG STRIP FRONT DOOR	TATA spare parts
319017964134	MTG STRIP MIDDLE DOOR	TATA spare parts
319017964136	SIDE GASKET 2	TATA spare parts

319017964137	NYLON RUBBER	TATA spare parts
319017964138	MIDDLE GASKET	TATA spare parts
319017964141	RUBBER STOPPER DIA 30X L 25	TATA spare parts
319017964142	GLASS FOR FRONT DOOR	TATA spare parts
319017964143	ROLLER ASSEMBLY/BEARING	TATA spare parts
319017964144	DOOR HANDLE	TATA spare parts
319017964146	RUBBER STRIP	TATA spare parts
319017964147	MTG STRIP	TATA spare parts
319017964148	GLASS	TATA spare parts
319017964150	SPLINE SHAFT	TATA spare parts
319017964152	DOOR HANDLE	TATA spare parts
319017964153	MTG STRIP	TATA spare parts
319017964154	VALVE MTG PLATE LOOSE SUPPLY	TATA spare parts
319017964155	RUBBER STRIP	TATA spare parts
319017964156	MTG PLATE ASSEMBLY	TATA spare parts
319017964157	MTG PLATE ASSY	TATA spare parts
319017964158	DIA 50X125 MM CYLINDER WITH FORK & REAR	TATA spare parts
319017964161	SPLINE SHAFT	TATA spare parts
319017964162	LOWER MOUNTING ASSY	TATA spare parts
319017965001	PNEUMATIC CYLINDER	TATA spare parts
319017965005	DOOR RESET SWITCH SHAVO BS6	TATA spare parts
319017965008	SPRING WASHER BS6	TATA spare parts
319017965010	PLAIN WASHER M16	TATA spare parts
319017965011	BUSH-1 BS6	TATA spare parts
319017965012	BUSH-2	TATA spare parts
319017965013	SUPPORT BRACKET_LH BS6	TATA spare parts
319017965014	PLAIN WASHER A8 BS6	TATA spare parts
319017965015	LINKAGE PIN + SPLIT PIN BS6	TATA spare parts
319017965017	SUPPORT BRACKET_RH	TATA spare parts
319017965019	LOWER PIVOT ASSY & 14MM BALL BS6	TATA spare parts
319017965020	SUPPORT PLATE BS6	TATA spare parts
319017965022	BRTS RH REAR DR ATTACH PLATE_FRONT BS6	TATA spare parts
319017965023	BRTS RH REAR DR ATTACH PLATE_REAR BS6	TATA spare parts
319017965024	SUPPORT BRACKET RH_AJL BS6	TATA spare parts
319017965025	LINKAGE	TATA spare parts
319017965027	ALLEN BOLT_M8 X 40MM BS6	TATA spare parts
319017965028	DOME NUT M8 BS6	TATA spare parts
319017965029	3/2 DOUBLE PILOT VALVE	TATA spare parts
319018003005	FRONT FACE ASSY-Y1	TATA spare parts
319018003006	ASSY. FRONT BUMPER -Y1 BS3/4	TATA spare parts
319018003007	FRONT BUMPER ASSY-Y1	TATA spare parts
319018003008	Y1-LP-FRP FRONT FACE FLAP ASSY	TATA spare parts
319018003010	LP Y1 FRP FRONT FLAP WIT STR & HING ASSY	TATA spare parts
319018003012	LP Y1 FRP FR BUMPER HR WI FOGLAMP ASSY	TATA spare parts
319018003013	LPO Y1 FRP FRONT FACE WIT RW ASSY	TATA spare parts
319018003014	FRONT BUMPER SUB ASSY	TATA spare parts
319018003016	FRONT BUMPER ASSY	TATA spare parts

319018003018	FRP FRNT FLAP WITH STR & HINGE ASSY	TATA spare parts
319018003019	FRONT FACE ASSY	TATA spare parts
319018003020	FRONT FACE WITH FLAP ASSEMBLY	TATA spare parts
319018003021	Y1 FRP FT FACE WIT RW & FLAP GRILL ASSY	TATA spare parts
319018003028	Y1 FRONT METAL BUMPER ASSEMBLY	TATA spare parts
319018003033	Y1 FRNT FAC WIT RW & FLAP GRILL ASSY	TATA spare parts
319018003040	FRONT BUMPER WITHOUT FOG LAMP ASSY-2550	TATA spare parts
319018003049	Y1 EV FRONT FACE & FLAP ASSY	TATA spare parts
319018003050	Y1 EV 9/9 FRONT BUMPER ASSY	TATA spare parts
319018003055	FRONT FLAP INFO DRG FOR Y1	TATA spare parts
319018003056	FRP FRONT FLAP GRILL ASSY_Y1	TATA spare parts
319018003058	FRONT FACE & FLAP ASSY_Y1	TATA spare parts
319018003061	Y1_EV_9/9_FRONT BUMPER ASSY W/O FOG LAMP	TATA spare parts
319018003063	EV FRONT FACE AND BUMPER WITH FOG ASMBLY	TATA spare parts
319018003066	FRONT FACE & FLAP WITH BUMPER ASSY-GEN 5	TATA spare parts
319018004001	FRONT FACE SUB ASSY-Y1	TATA spare parts
319018004002	FRONT FACE FLAP ASSY-Y1	TATA spare parts
319018004004	EXTERNAL FRONT FACE Y1-LP-FRP	TATA spare parts
319018004006	LP Y1 FRP FRONT FLAP WIT VENT & STR ASSY	TATA spare parts
319018004008	FRONT FLAP & STRUCTURE ASSY	TATA spare parts
319018005001	FRONT FLAP HINGE COVER ASSY LH	TATA spare parts
319018005002	FRONT FLAP HINGE COVER ASSY RH	TATA spare parts
319018005003	FRONT FLAP WITH STRUCTURE ASSY-Y1	TATA spare parts
319018083001	FRONT FACE TOP MOUNTING L ANGLE	TATA spare parts
319018083027	HINGE MOUNTING L-PROFILE LH	TATA spare parts
319018083028	HINGE MOUNTING L-PROFILE RH	TATA spare parts
319018084004	FRONT BUMPER MESH-Y1	TATA spare parts
319018085001	FRONT FACE MESH-Y1	TATA spare parts
319018184001	FRONT BUMPER AL MESH	TATA spare parts
319018213001	RAIN GUTTER FRONT LH-Y1	TATA spare parts
319018213002	RAIN GUTTER FRONT RH-Y1	TATA spare parts
319018213003	FINISHING PROFILE LH-Y1(LUX)	TATA spare parts
319018213004	FINISHING PROFILE RH-Y1(LUX)	TATA spare parts
319018213007	LP Y1 FRONT FACE FINISHING PROFILE-LH	TATA spare parts
319018213008	LP Y1 FRONT FACE FINISHING PROFILE-RH	TATA spare parts
319018213011	RAIN GUTTER FRONT LH-Y1	TATA spare parts
319018213012	RAIN GUTTER FRONT RH-Y1	TATA spare parts
319018264001	FRP FRONT BUMPER-Y1	TATA spare parts
319018264004	FRP Y1 LPO FRONT FACE WITH RUBBER W/S	TATA spare parts
319018264006	LPO-Y1 FRP FRONT FACE-2550	TATA spare parts
319018264007	LPO-Y1 FRP FRONT BUMPER-2550	TATA spare parts
319018264017	Y1_9X9_EV_FRONT FLAP WITH TRUSS BAR BS6	TATA spare parts
319018265001	FRP FRONT FACE -Y1	TATA spare parts
319018265002	EXTERNAL FRONT FACE Y1-LP-FRP	TATA spare parts
319018266001	FRP FRONT FLAP-Y1	TATA spare parts
319019003001	REAR BUMPER ASSY-Y1	TATA spare parts
319019003003	REAR FLAP ASSEMBLY	TATA spare parts

319019003005	REAR BUMPER ASSY-Y1	TATA spare parts
319019003010	REAR BUMPER ASSY	TATA spare parts
319019003016	Y1 REAR FACE SUB ASSEMBLY	TATA spare parts
319019003017	FRP REAR FACE	TATA spare parts
319019003021	Y1 REAR METAL BUMPER ASSEMBLY	TATA spare parts
319019003036	Y1 EV BRTS REAR BUMPER ASSEMBLY EV	TATA spare parts
319019003039	REAR FACE WITH BUMPER ASSY GEN5 9X9	TATA spare parts
319019004003	REAR FLAP LATCH ASSY	TATA spare parts
319019004005	REAR FLAP STRUCTURE ASSY	TATA spare parts
319019085001	RARE FLAP LATCH HOLDER	TATA spare parts
319019184001	RLB FLAP EXT PANELING SHEET	TATA spare parts
319019213001	RAIN GUTTER REAR RH-Y1	TATA spare parts
319019213002	RAIN GUTTER REAR LH-Y1	TATA spare parts
319019263001	FRP REAR FACE -Y1	TATA spare parts
319019263002	REAR FACE WITH RLB	TATA spare parts
319019263007	LPO Y1 FRP REAR FACE WIT RW	TATA spare parts
319019263008	LPO-Y1 FRP REAR FACE-2550	TATA spare parts
319019263014	Y1REARFACERWWITHRLB	TATA spare parts
319019264001	FRP REAR BUMPER-Y1	TATA spare parts
319019264002	LPO-Y1 FRP REAR BUMPER-2550	TATA spare parts
319020002001	SIDE LUGGAGE FLAP ASSY.	TATA spare parts
319020002002	BATTERY FLAP ASSY.	TATA spare parts
319020002003	AIR FILTER FLAP ASSY.	TATA spare parts
319020002004	SPARE WHEEL SIDE FLAP ASSY	TATA spare parts
319020002006	SLB FLAP SUB ASSLY 700X428	TATA spare parts
319020003001	AIR FILTER FLAP ASSY	TATA spare parts
319020003002	BATTERY FLAP ASSY	TATA spare parts
319020003003	SPARE WHEEL SIDE FLAP ASSY	TATA spare parts
319020003015	AL AIR FILTER FLAP ASSY	TATA spare parts
319020003016	BATTERY FLAP ASSY	TATA spare parts
319020003021	AL CBCU FLAP ASSY	TATA spare parts
319020003044	AL CBCU FLAP ASSY	TATA spare parts
319020003045	AL AIR FILTER FLAP ASSY	TATA spare parts
319020003046	AL BATTERY FLAP ASSY	TATA spare parts
319020003048	BATTERY FLAP ASSY	TATA spare parts
319020003049	BATTERY FLAP ASSLY W/O SIDE MARKER HOLE	TATA spare parts
319020003055	SLB FLAP ASSLY 700X428	TATA spare parts
319020003062	CHARGER TAPER FLAP ASSY WITH GUIDE ROD	TATA spare parts
319020003063	CHARGER FLAP ASSY WITH GUIDE ROD	TATA spare parts
319020003064	BATTERY FLAP SUB ASSLY 400X369 APP	TATA spare parts
319020003065	BATTERY FLAP ASSLY	TATA spare parts
319020003066	AUX DRIVE FLAP ASSLY_920X456APP	TATA spare parts
319020003071	AUX PANEL ASSY 455X1345 APP	TATA spare parts
319020003072	SERVICE FLAP ASSLY_592X455APP	TATA spare parts
319020003073	LV BATTERY FLAP ASSY	TATA spare parts
319020004013	BATTERY FLAP ASSLY	TATA spare parts
319020084011	FLAP LOCK ASSY PLATE BS6	TATA spare parts

319020084049	STAY ROD BARCKET BS6	TATA spare parts
319020084050	HINGE BRACKET BS6	TATA spare parts
319020084054	LOCK CATCHER BS6	TATA spare parts
319020912046	CHARGER TAPER FLAP INFO 160X160 BS6	TATA spare parts
319020912047	CHARGER FLAP INFO 160X160 APP	TATA spare parts
319020912058	CHARGER FLAP INFO	TATA spare parts
319021083013	ENGINE HOOD SUPPORT L SECTION 4	TATA spare parts
319022083015	DOOR MIRROR FRONT AT DRIVER PLATFORM	TATA spare parts
319022083016	DOOR MIRROR FRONT & REAR LH & RH	TATA spare parts
319022083017	DOOR MIRROR REAR LH RH	TATA spare parts
319022084169	FRONT STEP BOTTEM PANEL	TATA spare parts
319027003015	HAT SECTION SUB ASSY	TATA spare parts
319027003016	Y1(9X9)_EV_NEW BATTERY COVER & FLAP ASSY	TATA spare parts
319027003020	Y1 EV AJL BATTERY COVER & FLAP ASBLY	TATA spare parts
319027003028	SPLIT CORNER LH1 ASSY GEN5 9X9	TATA spare parts
319027003029	SPLIT CORNER LH2 ASSY GEN5 9X9	TATA spare parts
319027003030	SPLIT CORNER RH1 ASSY GEN5 9X9	TATA spare parts
319027003031	SPLIT CORNER RH2 ASSY GEN5 9X9	TATA spare parts
319027003032	FRONT END SHOW COVER ASBMLY GEN 5 9X9	TATA spare parts
319027003033	REAR END SHOW COVER ASMBLY GEN5- 9X9	TATA spare parts
319027004002	Y1(9X9)_EV_JUNCTION BOX FLAP ASSY	TATA spare parts
319027004003	Y1(9X9)_EV_BCS UNIT SERVICE FLAP ASSY	TATA spare parts
319027004004	Y1(9X9)_EV_BATTERY SERVICE FLAP ASSY	TATA spare parts
319027004006	Y1(9X9)_EV_MSD SERVICE FLAP ASSY	TATA spare parts
319027004007	Y1_9X9_AJL_EV_JUNCT BOX SRVC FLAP ASSY	TATA spare parts
319027004008	Y1_9X9_AJL_EV_BCS UNIT SERVICE FLAP ASSY	TATA spare parts
319027004009	Y1_9X9_AJL_EV_BATTERY SERVICE FLAP ASSY	TATA spare parts
319027004010	Y1_9X9_AJL_MSD_SERVICE FLAP ASSY	TATA spare parts
319027004011	Y1_9X9_AJL_EV COVER & STRUCTURE ASMBLY	TATA spare parts
319027074001	BATTERY COVER LIFTING HOOK(TECH FORCE)	TATA spare parts
319027083015	TOP VENTILATION LOUVERS	TATA spare parts
319027083019	Y1-BATTERY COVER FRONT LOUVER MESH	TATA spare parts
319027083020	Y1-BATTERY COVER REAR LOUVER MESH	TATA spare parts
319027083027	AJL-BATTERY COVER REAR LOUVER MESH	TATA spare parts
319027083028	AJL-BATTERY COVER FRONT MESH 1	TATA spare parts
319027083029	AJL-BATTERY COVER FRONT MESH 2	TATA spare parts
319027083037	Y1 9X9 REG BATTERY COVER RETRO PLATE	TATA spare parts
319027183015	BATTERY COVER REAR LOUVER MESH-GEN 5 9X9	TATA spare parts
319027263009	Y1_EV(9X9)_OUTSIDE CABLE COVER	TATA spare parts
319027265005	Y1(9X9)_EV_BATTERY FULL COVER	TATA spare parts
319027283001	BALLATA PACKING 70X50	TATA spare parts
319027912073	Y1_AJL_BRTS_BATTERY_COVER_FITMENT BS6	TATA spare parts
319028081001	SKIRT PANEL BELOW DRIVER DOOR	TATA spare parts
319028083002	STRETCH PANEL R.H SIDE	TATA spare parts
319028083003	STRETCH PANEL_RH SIDE	TATA spare parts
319028083004	STRETCH PANEL_RH SIDE REAR	TATA spare parts
319028083005	SKIRT PANEL REAR LH SIDE	TATA spare parts



319028083006	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083007	STRETCH PANEL_RH SIDE	TATA spare parts
319028083008	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083009	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083010	A -PILLER PANEL LH SIDE	TATA spare parts
319028083011	PLATE BESIDE DRIVER DOOR	TATA spare parts
319028083015	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083016	SKIRT PANEL BELOW DRIVE DOOR	TATA spare parts
319028083017	SKIRT PANEL LH SIDE 1	TATA spare parts
319028083018	SKIRT PANEL LH SIDE	TATA spare parts
319028083036	STRETCH PENEL-LH SIDE	TATA spare parts
319028083037	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028083038	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083040	SKIRT PANEL LH SIDE 1	TATA spare parts
319028083041	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083042	SKIRT PANEL AT SLB	TATA spare parts
319028083043	SIDE OUTER PANEL LH BESIDE SLB	TATA spare parts
319028083050	STRETCH PANEL_RH SIDE	TATA spare parts
319028083056	STRETCH PANEL LPROFILE R.H SIDE 920MM	TATA spare parts
319028083058	STRETCH PANEL RH SIDE	TATA spare parts
319028083078	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
319028083079	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083080	SKIRT PANEL LH SIDE	TATA spare parts
319028083081	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028083082	STRETCH PANEL LH SIDE	TATA spare parts
319028083083	SIDE PANEL LH BESIDE SPARE WHEEL	TATA spare parts
319028083084	SIDE PANEL LH BESIDE SLB	TATA spare parts
319028083085	SKIRT PANEL LH SIDE	TATA spare parts
319028083086	STRECH PANEL 717X3110X0.65	TATA spare parts
319028083087	STRECH PANEL 717X39300X0.65	TATA spare parts
319028083089	SKIRT PANEL LH SIDE 1065 LN	TATA spare parts
319028083090	SKIRT PANEL LH SIDE 1190X494X.95	TATA spare parts
319028083138	STRETCH PANEL LH SIDE	TATA spare parts
319028083139	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
319028083140	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083141	SKIRT PANEL LH SIDE	TATA spare parts
319028083142	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028083143	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083144	SKIRT PANEL LH SIDE 1	TATA spare parts
319028083145	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083146	SKIRT PANEL LH SIDE FRONT	TATA spare parts
319028083149	FRONT EXTERNAL PANEL LH SIDE	TATA spare parts
319028083150	C CHANNEL 1165 FOR EXTERNAL PANELLING LH	TATA spare parts
319028083153	C CHANNEL 819 FOR EXTERNAL PANELLING LH	TATA spare parts
319028083154	C CHANNEL 152 FOR EXTERNAL PANELLING LH	TATA spare parts
319028083156	C CHANNEL 378 FOR EXTERNAL PANELLING LH	TATA spare parts
319028083157	C CHANNEL 719 FOR EXTERNAL PANELLING LH	TATA spare parts

319028083158	C CHANNEL 378 FOR EXTERNAL PANELLING LH	TATA spare parts
319028083159	C CHANNEL 355 FOR EXTERNAL PANELLING	TATA spare parts
319028083160	C CHANNEL 291 FOR EXTERNAL PANELLING	TATA spare parts
319028083161	C CHANNEL 2106 FOR EXTERNAL PANELLING	TATA spare parts
319028083162	C CHANNEL 479 FOR EXTERNAL PANELLING	TATA spare parts
319028083164	C CHANNEL 568 FOR EXTERNAL PANELLING	TATA spare parts
319028083165	C CHANNEL 210 FOR EXTERNAL PANELLING RH	TATA spare parts
319028083166	C CHANNEL 568 FOR EXTERNAL PANELLING	TATA spare parts
319028083167	C CHANNEL 970 FOR EXTERNAL PANELLING RH	TATA spare parts
319028083169	C CHANNEL 1250 FOR EXTERNAL PANELLING RH	TATA spare parts
319028083171	C CHANNEL 473 FOR EXTERNAL PANELLING RH	TATA spare parts
319028083172	C CHANNEL 648 FOR EXTERNAL PANELLING RH	TATA spare parts
319028083173	FRONT LH EXTERNAL PANELLING 422	TATA spare parts
319028083174	FRONT EXTERNAL PANELLING LH 477	TATA spare parts
319028083175	BOX TYPE EXTERNAL PANELLING LH 477	TATA spare parts
319028083176	REAR WHEEL EXTERNAL PANELLING LH	TATA spare parts
319028083177	REAR EXTERNAL PANELLING LH	TATA spare parts
319028083178	SIDE EXTERNAL STRETCH PANEL	TATA spare parts
319028083179	REAR EXTERNAL PANELLING RH	TATA spare parts
319028083180	REAR EXTERNAL PANELLING RH	TATA spare parts
319028083181	FRONT EXTERNAL PANELLING RH	TATA spare parts
319028083182	BELOW DRIVER EXTERNAL PANELLING	TATA spare parts
319028083184	C CHANNEL 362 FOR EXTERNAL PANELLING	TATA spare parts
319028083185	C CHANNEL 620 FOR EXTERNAL PANELLING	TATA spare parts
319028083186	C CHANNEL 347 FOR EXTERNAL PANELLING	TATA spare parts
319028083187	BOX TYPE EXTERNAL PANELLING LH 477X533	TATA spare parts
319028083188	REAR WHEEL EXTERNAL PANELLING LH	TATA spare parts
319028083189	REAR EXTERNAL PANELLING LH 52WB	TATA spare parts
319028083190	SIDE EXTERNAL STRETCH PANEL 52WB	TATA spare parts
319028083191	REAR EXTERNAL PANELLING RH	TATA spare parts
319028083192	REAR EXTERNAL PANELLING RH 52WB	TATA spare parts
319028083193	A PILLER PANEL RH SIDE 52WB	TATA spare parts
319028083194	FRONT EXTERNAL PANELLING RH	TATA spare parts
319028083206	C CHANNEL 716 FOR EXTERNAL PANELLING RH	TATA spare parts
319028083207	EXTERNAL PANELLING RH 725	TATA spare parts
319028083208	FRONT EXTERNAL PANEL	TATA spare parts
319028083209	C CHANNEL 460 FOR EXTERNAL PANELLING LH	TATA spare parts
319028083210	A PILLER PANEL 100MM	TATA spare parts
319028083211	A PILLAR PANEL LH SIDE	TATA spare parts
319028083222	STRETCH PANEL RH FRONT AT PEEP WINDOW	TATA spare parts
319028083223	STRETCH PANEL RH BETWEEN DOORS	TATA spare parts
319028083224	STRETCH PANEL RH DOOR REAR	TATA spare parts
319028083225	PANEL RH AT RVM	TATA spare parts
319028083226	CANOPY REAR 720 APPARTURE	TATA spare parts
319028083227	CANOPY FRONT 830 APPARTURE	TATA spare parts
319028083228	FRONT RH WHEEL FRONT	TATA spare parts
319028083229	FRONT LH WHEEL REAR	TATA spare parts

319028083230	BATTERY TOP PANEL	TATA spare parts
319028083231	DOOR REAR WHEEL FRONT PANEL	TATA spare parts
319028083232	DOOR REAR WHEEL REAR PANEL	TATA spare parts
319028083233	RH LAST PANEL	TATA spare parts
319028083234	STRETCH PANEL LH	TATA spare parts
319028083235	PANEL LH AT RVM	TATA spare parts
319028083236	LH SIDE PANEL BETWEEN WB	TATA spare parts
319028083237	LH LAST PANEL	TATA spare parts
319028083238	PANEL AT DRIVER FOOTSTEP	TATA spare parts
319028083239	DRIVER DOOR FRONT PANEL	TATA spare parts
319028083240	DRIVER DOOR BOTTOM PANEL	TATA spare parts
319028083241	A PILLER COVERING PANEL	TATA spare parts
319028083254	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
319028083255	SKIRT PANEL LH SIDE HANUMAN	TATA spare parts
319028083257	SKIRT PANEL BETWEEN FLAPS	TATA spare parts
319028083258	SKIRT PANEL AT SLB	TATA spare parts
319028083259	DOOR SIDE SKIRT PANEL	TATA spare parts
319028083273	RVM PANEL PLATE	TATA spare parts
319028083274	SKIRT PANEL REAR RH	TATA spare parts
319028083275	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028083290	SKIRT PANEL LH SIDE	TATA spare parts
319028083291	SKIRT PANEL AT SLB	TATA spare parts
319028083292	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
319028083299	REAR VIEW MIRROR PANEL PLATE	TATA spare parts
319028083300	DOOR CANOPY FOR 1210 DOOR	TATA spare parts
319028083301	DOOR CANOPY FOR 720 DOOR	TATA spare parts
319028083302	DOOR CANOPY FOR FRONT DOOR	TATA spare parts
319028083303	REAR VIEW MIRROR PANEL PLATE	TATA spare parts
319028083304	DOOR CANOPY FOR 920 DRIVER DOOR	TATA spare parts
319028083305	REAR WHEEL EXTERNAL PANELLING LH	TATA spare parts
319028083306	BOX TYPE EXTERNAL PANELLING LH	TATA spare parts
319028083308	DRIVER SIDE SKIRT PANEL	TATA spare parts
319028083345	SKIRT PANEL BELOW DRIVE DOOR	TATA spare parts
319028083346	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083347	SKIRT PANEL LH SIDE 1	TATA spare parts
319028083348	SKIRT PANEL LH SIDE	TATA spare parts
319028083349	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028083350	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083351	SKIRT PANEL LH SIDE	TATA spare parts
319028083352	SKIRT PANEL LH SIDE 1	TATA spare parts
319028083353	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083354	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083355	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083360	DRIVER FOOT STEP SUPPORT BRACKET	TATA spare parts
319028083363	SKIRT PANEL LH SIDE	TATA spare parts
319028083364	A PILLER PANEL LH SIDE	TATA spare parts
319028083365	RVM PANEL PLATE LH SIDE	TATA spare parts

319028083376	SKIRT PANEL AT CBCU UNIT	TATA spare parts
319028083378	STRTCH PANEL RH SIDE	TATA spare parts
319028083379	SKIRT PANEL LH SIDE	TATA spare parts
319028083381	SKIRT PANEL AT BATTERY	TATA spare parts
319028083382	SKIRT PANEL LH SIDE 1	TATA spare parts
319028083384	EXT PANEL RVM	TATA spare parts
319028083385	A PILLAR PANEL	TATA spare parts
319028083386	SKIRT PANEL LH SIDE	TATA spare parts
319028083387	SKIRT PANEL LH 2	TATA spare parts
319028083388	SKIRT PANEL LH	TATA spare parts
319028083389	SKIRT PANEL LH SIDE	TATA spare parts
319028083390	STRETCH PANEL RH SIDE	TATA spare parts
319028083391	SKIRT PANEL LH SIDE REAR AXLE 42WB	TATA spare parts
319028083392	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083393	A PILLAR PANEL	TATA spare parts
319028083396	WINDOWPILLARPANEL	TATA spare parts
319028083397	WINDOW PILLAR PANEL	TATA spare parts
319028083398	WINDOW PILLAR PANEL	TATA spare parts
319028083399	WINDOW PILLAR PANEL	TATA spare parts
319028083400	WINDOW PILLAR PANEL	TATA spare parts
319028083401	WINDOW PILLAR PANEL	TATA spare parts
319028083403	WINDOW PILLAR PANEL	TATA spare parts
319028083404	WINDOW PILLAR PANEL	TATA spare parts
319028083405	WINDOW PILLAR PANEL	TATA spare parts
319028083408	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028083409	SKIRT PANEL LH SIDE	TATA spare parts
319028083418	SKIRT PANEL¿ RH SIDE	TATA spare parts
319028083419	SKIRT PANEL RH SIDE	TATA spare parts
319028083420	SKIRT PANEL¿ RH SIDE	TATA spare parts
319028083425	WINDOW PILLAR PANEL	TATA spare parts
319028083426	STRETCH PANEL_LH SIDE_AC_665MM WIDTH	TATA spare parts
319028083429	SKIRTPANELREARRHSIDE	TATA spare parts
319028083430	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083434	STRETCH PANEL-RH SIDE Y1-42WB	TATA spare parts
319028083435	EXTERNAL PANELING OVER PASSENGER DOOR	TATA spare parts
319028083436	SKIRT PANEL¿ SIDE	TATA spare parts
319028083437	SKIRT PANEL REAR -SIDE	TATA spare parts
319028083438	SKIRT PANEL REAR LH SIDE-RLB	TATA spare parts
319028083441	STRETCH PANEL_LH SIDE_636 WIDTH_42WB_PG	TATA spare parts
319028083465	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083466	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083467	WINDOW PILLAR PANEL	TATA spare parts
319028083468	STRETCH PANEL RH SIDE	TATA spare parts
319028083469	EXTERNAL PANEL OVER EMERGENCY DOOR	TATA spare parts
319028083475	SIDE PANEL LH AT END	TATA spare parts
319028083476	STRETCH PANEL L PROFILE LH/RH SIDE	TATA spare parts
319028083477	SIDE PANEL RH AT END	TATA spare parts

319028083478	SIDE PANEL RH BESIDE SPARE WHEEL	TATA spare parts
319028083479	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083481	SKIRT PANEL BELOW DRIVE DOOR LHD	TATA spare parts
319028083482	SKIRT PANEL LH SIDE LHD 42WB	TATA spare parts
319028083483	SKIRT PANEL LH SIDE 2 LPO914	TATA spare parts
319028083486	SIDE PANEL RH BESIDE SPARE WHEEL	TATA spare parts
319028083488	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083489	SKIRT PANEL LH SIDE	TATA spare parts
319028083496	STRETCH PANEL_RH SIDE	TATA spare parts
319028083497	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083499	SKIRT PANEL LH SIDE 1	TATA spare parts
319028083500	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083503	SKIRT PANEL LH SIDE_1	TATA spare parts
319028083504	SKIRT PANEL LH SIDE_2	TATA spare parts
319028083505	WINDOW PILLAR PANEL_52WB_NEPAL	TATA spare parts
319028083506	SKIRT PANEL LH SIDE_3	TATA spare parts
319028083508	RVM PANEL PLATE	TATA spare parts
319028083509	FRONT EXTERNAL PANEL LH SIDE	TATA spare parts
319028083510	SKIRT PANEL LH SIDE 1	TATA spare parts
319028083513	SKIRT PANEL REAR SIDE_1	TATA spare parts
319028083514	SKIRT PANEL REAR SIDE_2	TATA spare parts
319028083515	SKIRT PANEL SIDE	TATA spare parts
319028083516	SKIRT PANEL AT SLB	TATA spare parts
319028083520	SIDE PANEL RH AT END WITH ED STEP CUTOUT	TATA spare parts
319028083529	SKIRT PANEL LH SIDE_52WB_ARVIND	TATA spare parts
319028083599	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083600	A PILLER PANEL	TATA spare parts
319028083601	SKIRT PANEL BELOW DRIVE DOOR	TATA spare parts
319028083602	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083604	SKIRT PANEL LH SIDE 1	TATA spare parts
319028083638	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028083639	SKIRT PANEL LH SIDE	TATA spare parts
319028083640	SKIRT PANEL LH SIDE 3	TATA spare parts
319028083641	SKIRT PANEL	TATA spare parts
319028083642	SKIRT PANEL	TATA spare parts
319028083643	RVM PANEL PLATE LH	TATA spare parts
319028083644	RVM PANEL PLATE RH	TATA spare parts
319028083646	SKIRT PANEL RH SIDE 1	TATA spare parts
319028083647	STRETCH PANEL_LH SIDE(SS)	TATA spare parts
319028083648	STRETCH PANEL_RH SIDE(SS)	TATA spare parts
319028083649	STRETCH PANEL_LH SIDE REAR (SS)	TATA spare parts
319028083651	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028083652	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083653	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028083654	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083655	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083659	WINDOW PILLAR PANEL EMERGENCY SIDE	TATA spare parts

319028083661	WINDOW PILLAR PANEL	TATA spare parts
319028083664	SIDE WINDOW PILLER PANEL	TATA spare parts
319028083665	SIDE WINDOW PILLER PANEL_1	TATA spare parts
319028083666	SIDE WINDOW PILLER PANEL_2	TATA spare parts
319028083667	SIDE WINDOW PILLER PANEL_3	TATA spare parts
319028083668	SIDE WINDOW PILLER PANEL_4	TATA spare parts
319028083669	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
319028083670	SKIRT PANEL RH SIDE 1	TATA spare parts
319028083671	SKIRT PANEL LH SIDE_1	TATA spare parts
319028083672	SKIRT PANEL AT AUX DRIVE	TATA spare parts
319028083673	SIDE WINDOW PILLER PANEL_6	TATA spare parts
319028083674	EMER DOOR TOP PANEL	TATA spare parts
319028083675	SIDE WINDOW PILLER PANEL_7	TATA spare parts
319028083676	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083677	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083678	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083683	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083684	WINDOW PILLAR PANEL	TATA spare parts
319028083685	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
319028083686	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083687	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083688	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083689	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083690	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083691	SKIRT PANEL LH SIDE 2	TATA spare parts
319028083692	SKIRT PANEL LH SIDE	TATA spare parts
319028083694	A PILLER PANEL	TATA spare parts
319028083709	SKIRT PANEL RH SIDE 1	TATA spare parts
319028083712	SKIRT PANEL BELOW DRIVER DOOR	TATA spare parts
319028083713	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083714	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028083716	SKIRT PANEL LH SIDE	TATA spare parts
319028083719	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028083725	RH SKIRT PANEL	TATA spare parts
319028083728	A PILLER PANEL BS6	TATA spare parts
319028083731	STRECH PANEL LH BS6	TATA spare parts
319028083733	STRECH PANEL LH BS6	TATA spare parts
319028083742	RH TUBE CLOSING SKIRT PANEL BS6	TATA spare parts
319028083743	SKIRT PANEL L PROFILE BS6	TATA spare parts
319028083744	SKIRT PANEL L PROFILE BS6	TATA spare parts
319028083745	FRONT DOOR BOTTOM L PROFILE BS6	TATA spare parts
319028083746	LH SIDE SKIRT PANEL 1 BS6	TATA spare parts
319028083747	LH SIDE EXT PANEL 02 BS6	TATA spare parts
319028083748	LH SIDE SKIRT PANEL 03 BS6	TATA spare parts
319028083749	MIDDLE PASS DOOR BOTTOM L PROFILE BS6	TATA spare parts
319028083750	LH SKIRT PANEL 04 BS6	TATA spare parts
319028083751	LH SIDE SKIRT PANEL 05 BS6	TATA spare parts

319028083752	RH SIDE SKIRT PANEL 01 BS6	TATA spare parts
319028083753	RH SIDE SKIRT PANEL 02 BS6	TATA spare parts
319028083755	RH SIDE SKIRT PANEL 03 BS6	TATA spare parts
319028083756	RH SIDE SKIRT PANEL BS6	TATA spare parts
319028084003	DRIVER FOOT STEP SUPPORT BRACKET	TATA spare parts
319028084007	SQUARE WASHER 2.7THK EV	TATA spare parts
319028084008	LIFT TOP EXTERNAL PANEL EV	TATA spare parts
319028183001	SKIRT PANEL LH SIDE 2	TATA spare parts
319028183002	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028183005	SKIRT PANEL LH SIDE 1 AL	TATA spare parts
319028183006	SKIRT PANEL LH SIDE 1 AL	TATA spare parts
319028183007	SKIRT PANEL REAR RH SIDE AL	TATA spare parts
319028183010	SIDE AL PANEL LH BESIDE SLB	TATA spare parts
319028183011	SIDE AL PANEL LH BESIDE SPARE WHEEL	TATA spare parts
319028183012	SIDE AL PANEL LH BESIDE SLB	TATA spare parts
319028183060	SKIRT PANEL BELOW DRIVE DOOR	TATA spare parts
319028183061	SKIRT PANEL LH SIDE 2	TATA spare parts
319028183062	SKIRT PANEL LH SIDE	TATA spare parts
319028183063	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028183067	SKIRT PANEL LH SIDE 3	TATA spare parts
319028183068	SKIRT PANEL LH SIDE 1	TATA spare parts
319028183069	SKIRT PANEL LH SIDE 2	TATA spare parts
319028183070	SKIRT PANEL LH SIDE 1	TATA spare parts
319028183071	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028183093	DRIVER DOOR BELOW SKIRT PANEL 42WB	TATA spare parts
319028183094	AL SKIRT PANEL LH SIDE 2 42WB	TATA spare parts
319028183095	AL SKIRT PANEL LH SIDE 1 42WB	TATA spare parts
319028183096	AL SKIRT PANEL REAR RH SIDE_42WB	TATA spare parts
319028183097	AL SIDE OUTER PANEL LH BESIDE SLB_42WB	TATA spare parts
319028183098	AL SKIRT PANEL LH SIDE 2 42WB	TATA spare parts
319028183099	AL SKIRT PANEL REAR LH SIDE 42WB	TATA spare parts
319028183100	PASSENGER DOOR FINISHING TOP PROFILE	TATA spare parts
319028183101	PASSENGER DOOR FINISHING BOTTOM PROFILE	TATA spare parts
319028183107	EMERGENCY DOOR FINISHING PROFILE_RH	TATA spare parts
319028183108	EMERGENCY DOOR FINISHING PROFILE_LH	TATA spare parts
319028183109	DRIVER DOOR FINISHING PROFILE	TATA spare parts
319028183110	FINISHING PROFILE	TATA spare parts
319028183125	DRIVER DOOR FINISHING PROFILE	TATA spare parts
319028183126	PASSENGER DOOR FINISHING PROFILE_RH	TATA spare parts
319028183127	PASSENGER DOOR FINISHING PROFILE_LH	TATA spare parts
319028183128	DRIVER DOOR FINISHING PROFILE_EX	TATA spare parts
319028183150	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028183176	DRIVER DOOR FINISHING PROFILE_630	TATA spare parts
319028183177	AL SKIRT PANEL LH SIDE	TATA spare parts
319028183178	AL_SKIRT PANEL LH SIDE	TATA spare parts
319028183179	AL_SKIRT PANEL LH SIDE	TATA spare parts
319028183180	AL_SKIRT PANEL LH SIDE	TATA spare parts

319028183181	ALSKIRT PANEL LH SIDE 2	TATA spare parts
319028183182	AL SKIRT PANEL RH SIDE 1	TATA spare parts
319028183183	AL SKIRT PANEL REAR RH SIDE	TATA spare parts
319028183186	EMERGENCY DOOR FINISHING PROFILE_2	TATA spare parts
319028183187	PASSENGER DOOR FINISHING PROFILE	TATA spare parts
319028183191	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028183192	SKIRT PANEL LH SIDE 2	TATA spare parts
319028183193	SKIRT PANEL LH SIDE	TATA spare parts
319028183195	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028183196	SKIRT PANEL RH SIDE _2	TATA spare parts
319028183197	SKIRT PANEL RH SIDE 1	TATA spare parts
319028183198	SKIRT PANEL RH SIDE _3	TATA spare parts
319028183199	SKIRT PANEL BELOW DRIVE DOOR	TATA spare parts
319028183200	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028183202	SKIRT PANEL LH SIDE 1	TATA spare parts
319028183203	SKIRT PANEL LH SIDE 2	TATA spare parts
319028183204	SKIRT PANEL LH SIDE 3	TATA spare parts
319028183205	SKIRT PANEL REAR LH SIDE	TATA spare parts
319028183206	SKIRT PANEL AT BATTERY	TATA spare parts
319028183207	SKIRT PANEL AT AUX DRIVE	TATA spare parts
319028183208	SKIRT PANEL_6	TATA spare parts
319028183209	STOP ARM TOP FINISHING PROFILE	TATA spare parts
319028183211	STOP ARM SIDE FINISHING PROFILE	TATA spare parts
319028183212	STOP ARM SIDE FINISHING PROFILE1	TATA spare parts
319028183213	STOP ARM TOP FINISHING PROFILE2	TATA spare parts
319028183214	STOP ARM SIDE FINISHING PROFILE3	TATA spare parts
319028183215	STOP ARM SIDE FINISHING PROFILE 4	TATA spare parts
319028183216	SKIRT PANEL REAR RH SIDE	TATA spare parts
319028183218	SKIRT PANEL LH SIDE	TATA spare parts
319028183219	PASSENGER DOOR FINISHING PROFILE	TATA spare parts
319028183220	PASSENGER DOOR FINISHING PROFILE	TATA spare parts
319028183221	SKIRT PANEL LH SIDE 2	TATA spare parts
319028183222	SKIRT PANEL LH SIDE	TATA spare parts
319028183246	SKIRT PANEL BELOW DRIVE DOOR	TATA spare parts
319028183247	SKIRT PANEL BELOW DRIVE DOOR	TATA spare parts
319028183249	SKIRT PANEL LH SIDE 3 BS6	TATA spare parts
319028183253	SKIRT PANEL LH MIDDLE BS6	TATA spare parts
319028183256	SKIRT PANEL REAR RH SIDE BS6	TATA spare parts
319028183257	SKIRT PANEL RH SIDE _3 BS6	TATA spare parts
319028183259	SKIRT PANEL BELOW DRIVER DOOR BS6	TATA spare parts
319028183260	SKIRT PANEL LH SIDE 1 BS6	TATA spare parts
319028183261	SKIRT PANEL LH 04 BS6	TATA spare parts
319028183262	SKIRT PANEL REAR LH SIDE BS6	TATA spare parts
319028183263	AL.SKIRT PANEL BS6	TATA spare parts
319028183264	PASSENGER DOOR FINISHING PROFILE BS6	TATA spare parts
319028183266	SKIRT PANEL AT BATTERY BS6	TATA spare parts
319028183267	SKIRT PANEL AT AUXILLARY BS6	TATA spare parts



319028183269	SKIRT PANEL RH SIDE _2 BS6	TATA spare parts
319028183270	SKIRT PANEL RH SIDE 1 BS6	TATA spare parts
319028183271	AL.SKIRT PANEL BS6	TATA spare parts
319028183272	SKIRT PANEL LH SIDE 3	TATA spare parts
319028183273	SKIRT PANEL LH SIDE 2	TATA spare parts
319028184001	EME DOOR FINISHING R.H SIDE	TATA spare parts
319029003002	INSPECTION CUT OUT ASSY Y1	TATA spare parts
319029003004	GEAR BOX CUTOFF ASSY	TATA spare parts
319029003005	Y1AMTPLYWOODINSPCOVERASSY	TATA spare parts
319029003006	TOOL BOX ASSEMBLY	TATA spare parts
319029003014	GEAR BOX CUT OUT ASSY FLAT	TATA spare parts
319029003019	SPRE WHEEL INSPECTION COVER	TATA spare parts
319029003020	PNEUMATIC BOX INSPECT COVER	TATA spare parts
319029003028	GEAR BOX CUT-OUT ASSY WITH AL.CHQRD-TR	TATA spare parts
319029003034	FRONT INSPECTION CUT-OUT ASSY_01	TATA spare parts
319029003035	FRONT INSPECTION CUT-OUT ASSY_02	TATA spare parts
319029003036	FRONT INSPECTION CUT-OUT ASSY_03	TATA spare parts
319029003057	FRONT INSPECTION CUT-OUT ASSY_03	TATA spare parts
319029003058	INSPECTION COVER_AUX DRIVE	TATA spare parts
319029003059	FRONT INSPECTION CUT-OUT ASSY_02 BS6	TATA spare parts
319029003060	INSPECTION COVER_AUX DRIVE-BEST	TATA spare parts
319029003072	INSPECTION COVER ASSY EV 9X9_APP757X667	TATA spare parts
319029003073	INSPECTION COVER ASSY EV 9X9_APP 628X719	TATA spare parts
319029003074	INSPECTION COVER ASSY EV 9X9_APP 665X442	TATA spare parts
319029183001	AL CHEQUERED 210X430MM	TATA spare parts
319029183002	AL CHEQUERED 230X430	TATA spare parts
319029183006	AL CHEQUERED 395X95MM	TATA spare parts
319029183018	AL CHEQUERED REAR SIDE	TATA spare parts
319029183019	AL CHEQUERED FRONT STEP SIDE	TATA spare parts
319029183030	AL CHEQUERED 2207X477MM	TATA spare parts
319029183034	AL CHEQUERED 11207X63MM	TATA spare parts
319029183036	AL CHEQUERED 1422X670MM	TATA spare parts
319029183037	AL CHEQUERED 732X225MM	TATA spare parts
319029183038	AL CHEQUERED 452X165MM	TATA spare parts
319029183039	AL CHEQUERED 446X120MM	TATA spare parts
319029183040	AL CEQUERED 493X1093MM	TATA spare parts
319029183042	AL CHEQUERED 360X175MM	TATA spare parts
319029183043	AL CHEQUERED 2600X762MM LH SIDE 42WB	TATA spare parts
319029183044	AL CHEQUERED 2600X762MM 42WB	TATA spare parts
319029183045	AL CHEQUERED 2633X677MM 42WB	TATA spare parts
319029183046	AL CHEQUERED 1793X762MM 42WB	TATA spare parts
319029183047	AL CHEQUERED 1793X762MM 42WB	TATA spare parts
319029183048	AL CHEQ. PLATE ON REAR STEP	TATA spare parts
319029183049	AL CHEQUERED TOP PLATE ON REAR STEP	TATA spare parts
319029183050	AL CHECKERED PLATE 1	TATA spare parts
319029183052	AL CHECKERED PLATE 2	TATA spare parts
319029183053	AL CHECKERED PLATE 3	TATA spare parts

319029183054	AL CHECKERED PLATE 4	TATA spare parts
319029183055	AL CHECKERED PLATE 5	TATA spare parts
319029183056	AL CHECKERED PLATE 6	TATA spare parts
319029183057	AL CHECKERED PLATE 7	TATA spare parts
319029183058	AL CHECKERED PLATE 8	TATA spare parts
319029184001	AL CHEQUERED 380X400MM	TATA spare parts
319029243336	MIDDLE 1 PLYWOOD	TATA spare parts
319029263001	INSPECTION LID-FRP	TATA spare parts
319029912016	VINYL FLOORING & FINISHING ASSEMBLY	TATA spare parts
319040003001	RH 2 SEAT 500CH SM1L AR Y1 SKOOL	TATA spare parts
319040003002	RH 2 SEAT 450CH SM1L Y1 SKOOL	TATA spare parts
319040003003	RH 2 SEAT 450CH SM1L WA Y1 SKOOL	TATA spare parts
319040003004	RH REAR 2 SEAT 450CH SM1L Y1 SKOOL	TATA spare parts
319040003005	RH 2 SEAT 450CH 2LM Y1 SKOOL	TATA spare parts
319040003006	REAR MID 1 SEAT 450CH 2LM Y1 SKOOL	TATA spare parts
319040003007	LH 2 SEAT 450CH SM1L Y1 SKOOL	TATA spare parts
319040003008	LH 2 SEAT 500CH SM1L Y1 SKOOL	TATA spare parts
319040003009	LH 2 SEAT 450CH SM1L WA Y1 SKOOL	TATA spare parts
319040003011	RH 2 SEAT 500CH SM1L AR Y1 SKOOL	TATA spare parts
319040003012	RH 2 SEAT 450CH SM1L Y1 SKOOL	TATA spare parts
319040003013	RH 2 SEAT 450CH SM1L WA Y1 SKOOL	TATA spare parts
319040003014	LH REAR 2 SEAT 450CH SM1L Y1 SKOOL	TATA spare parts
319040003015	RH 2 SEAT 450CH 2LM Y1 SKOOL	TATA spare parts
319040003016	RH REAR 3 SEAT 450CH SM2L Y1 SKOOL	TATA spare parts
319040003017	LH 2 SEAT 450CH SM1L Y1 SKOOL	TATA spare parts
319040003018	LH 2 SEAT 500CH SM1L Y1 SKOOL	TATA spare parts
319040003019	LH 2 SEAT 450CH SM1L WA Y1 SKOOL	TATA spare parts
319040003021	LH REAR 2 SEAT 450CH SM1L Y1 SKOOL	TATA spare parts
319040003022	RH 2 SEAT 430CH_SM1LM_2LB_AR_Y1_TJC HB	TATA spare parts
319040003023	RH 2 SEAT 430CH_SM1LM_Y1_TJC HB	TATA spare parts
319040003024	RH 2 SEAT 430CH_2LM_Y1_TJC HB	TATA spare parts
319040003025	MID 1 SEAT 430CH_2LM_LB_Y1_TJC HB	TATA spare parts
319040003026	LH 2 SEAT 430CH_SM1LM_Y1_TJC HB	TATA spare parts
319040003027	LH 2 SEAT 430CH_SM1LM_1LB_AR_Y1_TJC HB	TATA spare parts
319040003028	LH 1 SEAT 430CH_SM1LM_LB_AR_Y1_TJC HB	TATA spare parts
319040003029	RH 2 SEAT 450CH_SM1LM_2LB_AR_Y1_VSPL HB	TATA spare parts
319040003030	RH 2 SEAT 450CH_SM1LM_Y1_VSPL HB	TATA spare parts
319040003031	RH 2 SEAT 450CH_2LM_Y1_VSPL HB	TATA spare parts
319040003032	MID 1 SEAT 450CH_2LM_LB_Y1_VSPL HB	TATA spare parts
319040003033	LH 2 SEAT 450CH_SM1LM_Y1_VSPL HB	TATA spare parts
319040003034	LH 2 SEAT 450CH_SM1LM_1LB_AR_Y1_VSPL HB	TATA spare parts
319040003035	LH 1 SEAT 450CH_SM1LM_LB_AR_Y1_VSPL HB	TATA spare parts
319040003049	RH 2 SEAT 500CH_SM1L_AR LB_SKOOL	TATA spare parts
319040003050	RH 2 SEAT 450CH_SM1L_AR LB_SKOOL	TATA spare parts
319040003051	RH 2 SEAT 450CH_SM1L_WA_AR LB_SKOOL	TATA spare parts
319040003052	LH REAR 2 SEAT 450CH_SM1L_AR LB_VSPL SKL	TATA spare parts
319040003053	RH 2 SEAT 450CH_2LM_AR LB_VSPL SKOOL	TATA spare parts

319040003054	RH REAR 3 SEAT 450CH_SM2L_AR LB_VSPL SKL	TATA spare parts
319040003055	LH 2 SEAT 450CH_SM1L_AR LB_VSPL SKOOL	TATA spare parts
319040003056	LH 2 SEAT 500CH_SM1L_AR LB_VSPL SKOOL	TATA spare parts
319040003057	LH 2 SEAT 450CH_SM1L_WA_AR LB_VSPL SKOOL	TATA spare parts
319040003058	LH 1SEAT 390CH_SM1L_WA_AR LB_VSPL SKOOL	TATA spare parts
319040003084	RH 2SEAT 450CH_TYP-2_SM1LM_LB_AR_VSPL HB	TATA spare parts
319040003085	RH 2 SEAT 450CH TYP-2 SM1LM HB	TATA spare parts
319040003086	RH 2 SEAT 450CH TYP-2 2LM HB	TATA spare parts
319040003087	MID 1 SEAT 450CH TYP-2 2LM LB HB	TATA spare parts
319040003088	LH 2 SEAT 450CH TYP-2 SM1LM HB	TATA spare parts
319040003098	RH 2SEAT 450CH TYP 1 SM1LM AR	TATA spare parts
319040003099	RH 2 SEAT 450CH TYP 1 SM1LM	TATA spare parts
319040003100	RH 2 SEAT 450CH TYP 1 AR 2LM	TATA spare parts
319040003101	MID 1 SEAT 450CH TYP 1 2LM LB	TATA spare parts
319040003102	LH 2 SEAT 450CH TYP 1 SM1LM	TATA spare parts
319040003103	LH 2SEAT 450CH TYP 1 SM1LM AR 1LB	TATA spare parts
319040003104	LH 1SEAT 360CH TYP-1 SM1LM AR LB	TATA spare parts
319040003105	RH 2 SEAT 500CH_SM1L_AR_W/O.BH_TJC SKOOL	TATA spare parts
319040003106	RH 2 SEAT 450CH_SM1L_AR_W/O.BH_TJC SKOOL	TATA spare parts
319040003107	RH 2 SEAT 450CH_2LM_AR_W/O.BH_TJC SKOOL	TATA spare parts
319040003108	RHREAR 2SEAT 450CH_SM1L_AR_W/O.BH_TJCSK	TATA spare parts
319040003109	REAR MID 1 SEAT 450CH_2LM_W/O.BH_TJC SKL	TATA spare parts
319040003110	LHREAR 2SEAT 450CH_SM1L_AR_W/O.BH_TJCSK	TATA spare parts
319040003111	LH 2 SEAT 450CH_SM1L_AR_W/O.BH_TJC SKL	TATA spare parts
319040003112	LH 2 SEAT 500CH_SM1L_AR_W/O.BH_TJC SKL	TATA spare parts
319040003113	LH 1SEAT 390CH_SM1L_WA_AR_W/O.BH_TJC SKL	TATA spare parts
319040003114	RH 2 SEAT 500CH SM1L AR W/O.BH HB SKL	TATA spare parts
319040003115	RH 2 SEAT 450CH SM1L AR W/O.BH HB SKL	TATA spare parts
319040003116	RH 2 SEAT 450CH 2LM AR W/O.BH HB SKL	TATA spare parts
319040003117	RHREAR 3SEAT450CH SM2L AR W/O.BH HB SKL	TATA spare parts
319040003118	LHREAR 2SEAT450CH SM1L AR W/O.BH HB SKL	TATA spare parts
319040003119	LH 2 SEAT 450CH SM1L AR W/O.BH HB SKL	TATA spare parts
319040003120	LH 2 SEAT 500CH SM1L AR W/O.BH HB SKL	TATA spare parts
319040003122	RH 2SEAT HBREC_SM1L_900W_AR	TATA spare parts
319040003123	RH 2SEAT HBREC_2L_900W_AR	TATA spare parts
319040003124	REAR RH 2SEAT HBREC_900W_AR	TATA spare parts
319040003125	REAR LH 2SEAT HBREC_900W_AR	TATA spare parts
319040003126	LH 2 SEAT HB REC_SM1L_900W_AR	TATA spare parts
319040003127	RH 2 SEAT_DLX_1025W_3AR	TATA spare parts
319040003128	REAR RH 2 SEAT_DLX_1025W_3AR	TATA spare parts
319040003129	LH 1 SEAT_DLX_1025W_2AR	TATA spare parts
319040003130	LH 1 SEAT_DLX_1025W_360CH_2AR_WH	TATA spare parts
319040003139	RH REAR 3 SEAT 450CH SM1YL AR LB	TATA spare parts
319040003141	RH 3 SEAT 500CH SM1YL AR LB HB SKL	TATA spare parts
319040003142	RH 3 SEAT 450CH SM1YL AR LB HB SKL	TATA spare parts
319040003143	RH 3 SEAT 450CH SM1YL WA AR LB HB SKL	TATA spare parts
319040003144	RH 3 SEAT 450CH 2LM1YL AR LB HB SKL	TATA spare parts

319040003146	LH 1 SEAT HB REC_SM1L_485W_AR_LB	TATA spare parts
319040003147	REAR MID SEAT HB REC_410W_LB	TATA spare parts
319040003149	LH REAR 3SEAT 450CH SM1YL AR LBç SKL	TATA spare parts
319040003150	LH 1 SEAT 360CH_SM1LM_LB_AR_WA_Y1_TJC HB	TATA spare parts
319040003151	LH 1SEAT 360CH_SM1LM_LB_AR_WA_Y1_VSPL H	TATA spare parts
319040003152	LH 1SEAT 350CH SM1L WA AR LB SKOOL	TATA spare parts
319040003153	LH 1SEAT 350CH SM1L WA AR LB SKOOL	TATA spare parts
319040003165	RH 2SEAT FIX TYPE HB SM1L 900W AR	TATA spare parts
319040003166	RH 2SEAT FIX TYPE HB 2L 900W AR	TATA spare parts
319040003167	REAR MID FIX TYPE HB SEAT 400W	TATA spare parts
319040003168	LH 2SEAT FIX TYPE HB SM1L 900W AR	TATA spare parts
319040003169	LH 1SEAT FIX TYPE HB SM1L 485W AR	TATA spare parts
319040003170	RH REAR 2SEAT FIX TYP HB SM1L AR	TATA spare parts
319040003171	LH REAR 2SEAT FIX TYP HB SM1L AR	TATA spare parts
319040003172	RHREAR 3SEAT 450CH 1230W SM2L LBç SKL	TATA spare parts
319040003173	RH 2 SEATER_STD_2T_SM1LG_760 WIDTH	TATA spare parts
319040003174	RH 2SEAT_STD_2T_2LG_AR_2LB_760 WDT	TATA spare parts
319040003175	RR RH 3SEAT_STD_2T_SM2LG_1LB_1140WDT	TATA spare parts
319040003176	RR LH 2 SEAT_STD_2T_SM1LG_760 WIDTH	TATA spare parts
319040003177	LH 2 SEAT_STD_2T_SM1LG_760 WIDTH	TATA spare parts
319040003178	LH 1 SEAT_STD_2T_SM1LG_WH_380 WIDTH	TATA spare parts
319040003179	RH 2 SEATER 1025W 2LM 3PLB 3AR	TATA spare parts
319040003180	RH 2 SEATER 1025W 1SL1BL 3PLB 3AR	TATA spare parts
319040003181	RH REAR 2 SEAT 1025W 2LM 3PLB 3AR	TATA spare parts
319040003182	LH REAR 2 SEAT 1025W 2LM 3PLB 3AR	TATA spare parts
319040003183	LH 1 SEATER 545W 2LM 3PLB 2AR	TATA spare parts
319040003184	LH 1 SEATER (525W)	TATA spare parts
319040003195	REAR RH 2 SEAT 450DSM1LM	TATA spare parts
319040003196	REAR LH 2 SEAT 450DSM1LM	TATA spare parts
319040003197	REAR RH 2 SEAT 450DSM1LM	TATA spare parts
319040003198	REAR LH 2 SEAT 450DSM1LM	TATA spare parts
319040003199	RH 2 SEAT SM1L PLSTIC BLUE FAB	TATA spare parts
319040003201	LH 2SEAT SM1L PLSTIC AR LB BLUE FAB	TATA spare parts
319040003202	REAR MID SEAT 2L LB PLSTIC BLUE FAB	TATA spare parts
319040003204	LH 2 SEAT SM1L PLSTIC BLUE FAB	TATA spare parts
319040003215	RH 3 SEATR 1050W SKL	TATA spare parts
319040003216	RH 3 SEATR 1050W SKL	TATA spare parts
319040003217	RH 3 SEATR 1050W WH SKL	TATA spare parts
319040003218	RH 3 SEATR 1050W SKL	TATA spare parts
319040003219	REAR RH 3 SEATR 1050W 3LM SKL	TATA spare parts
319040003220	LH 2 SEATR 700W SM1LM SKL	TATA spare parts
319040003221	LH 2 SEATR 700W SM1LM WH SKL	TATA spare parts
319040003222	LH 2 SEATR 700W SM1LM LB SKL	TATA spare parts
319040003223	REAR LH 3 SEATR 1050W LB SKL	TATA spare parts
319040003224	RH 3 SEATR 1050W FPS SKL	TATA spare parts
319040003225	RH 3 SEATR 1050W FPS SKL	TATA spare parts
319040003226	RH 3 SEATR 1050W WH FPS SKL	TATA spare parts

319040003227	RH 3 SEATR 1050W FPS SKL	TATA spare parts
319040003228	REAR RH 3 SEATR 1050W 3LM FPS SKL	TATA spare parts
319040003229	LH 2 SEATR 760W SM1LM FPS SKL	TATA spare parts
319040003230	LH 2 SEATR 760W SM1LM WH FPS SKL	TATA spare parts
319040003231	LH 2 SEATR 760W SM1LM LB FPS SKL	TATA spare parts
319040003232	REAR LH 3 SEATR 1050W LB SKL	TATA spare parts
319040003238	2 SEATER_WH_810W_360CH_2LGM_VSPL BS6	TATA spare parts
319040003239	LH 2SEAT 460CH 810W 2LM PLSTC	TATA spare parts
319040003243	RH 2 SEAT 450CH SM1L Y1 MAROON FABSKOOL	TATA spare parts
319040003244	RH 2 MAROON FBSEAT 450CH SM1L WA Y1 SKL	TATA spare parts
319040003245	RH 2 MAROON FASEAT 500CH SM1L AR Y1 SKL	TATA spare parts
319040003246	RH 2 MAROON FASEAT 450CH 2LM Y1 SKL	TATA spare parts
319040003247	RH REAR MAROON F3SEAT 450CH SM2L Y1 SKL	TATA spare parts
319040003248	LH REAR MAROONFA2SEAT 450CH SM1L Y1 SKL	TATA spare parts
319040003249	LH MAROON FA2 SEAT 450CH SM1L Y1 SKL	TATA spare parts
319040003250	LH MAROON FA2SEAT 450CH SM1L WA Y1 SKL	TATA spare parts
319040003251	LH MAROONFA1SEAT350CH SM1L WA AR LB SKL	TATA spare parts
319040003258	RH 2 SEAT 450CH SM1LM AR HB	TATA spare parts
319040003259	RH 2 SEAT 450CH 2LM AR HB	TATA spare parts
319040003260	LH 2 SEAT 450CH SM1LM AR HB	TATA spare parts
319040003261	RH 2 SEAT 450CH SM1LM AR	TATA spare parts
319040003262	RH 2 SEAT 450CH 2LM AR	TATA spare parts
319040003263	LH 2 SEAT 450CH SM1LM AR	TATA spare parts
319040003269	LH 1SEAT 350CH SM1L WA AR	TATA spare parts
319040003270	RH 2 SEAT 2LG PMS 460CH AR BLUE FAB	TATA spare parts
319040003271	LH 2SEAT 2LG PMS 460CH AR BLUE FAB	TATA spare parts
319040003272	LH 1 SEAT 360CH 2LM AR BLUE FAB PMS	TATA spare parts
319040003273	LH 1 SEAT 460CH 2LM AR BLUE FAB	TATA spare parts
319040003274	RH 2 SEAT 2LG PMS 460CH BLUE FAB	TATA spare parts
319040003275	LH 2 SEAT 2LG PMS 460CH BLUE FAB	TATA spare parts
319040003276	RH 2 SEAT 2LG PMS 360CH BLUE FAB	TATA spare parts
319040003277	LH 2 SEAT 2LG PMS 360CH BLUE FAB	TATA spare parts
319040003280	RH 2 SEAT 2LG PMS 500CH BLUE FAB	TATA spare parts
319040003281	LH 2 SEAT 2LG PMS 500CH BLUE FAB	TATA spare parts
319040003299	RH 2 SEAT DLX 1025W 3AR	TATA spare parts
319040003300	RH 2SEAT DL 1025W 3AR LEAFGREEN W/O FR	TATA spare parts
319040003301	REAR RH 2 SEAT DLX 1025W 3AR	TATA spare parts
319040003302	LH 1 SEAT DLX 555W 2AR	TATA spare parts
319040003303	LH 1 SEAT DLX 555W 2AR W/O FR	TATA spare parts
319040003304	MECHANICAL SUSPENDED DRIVER SEAT	TATA spare parts
319040003307	LH 2SEAT HBREC_SM1L_900W_VSPL	TATA spare parts
319040003308	RM 2LM HBREC SEAT_400W_LB_CVG	TATA spare parts
319040003309	RH 2SEAT HBREC_SM1L_900W_AR_W/O FR_VSPL	TATA spare parts
319040003310	LH 2SEAT HBREC_SM1L_900W_AR_W/O FR_VSPL	TATA spare parts
319040003311	RH 2 SEAT 430CH SM1LM 2LB AR Y1 HSSL HB	TATA spare parts
319040003312	RH 2 SEAT 430CH SM1LM Y1 HSSL HB	TATA spare parts
319040003313	RH 2 SEAT 430CH 2LM Y1 HSSL HB	TATA spare parts

319040003314	MID 1 SEAT 430CH 2LM LB Y1 HSSL HB	TATA spare parts
319040003315	LH 2 SEAT 430CH SM1LM Y1 HSSL HB	TATA spare parts
319040003316	LH 2 SEAT 430CH SM1LM 1LB AR Y1 HSSL HB	TATA spare parts
319040003317	LH 1 SEAT 360CH SM1LM LB AR WA HSSL HB	TATA spare parts
319040003318	REAR RH 2 SEAT 450D SM1LM HSSL HB	TATA spare parts
319040003319	REAR LH 2 SEAT 450D SM1LM HSSL HB	TATA spare parts
319040003321	LH 2 ST 460CH 880W 221SM1L AR PMS	TATA spare parts
319040003325	REAR MID 1 SEAT 460CH 2LM PMS	TATA spare parts
319040003328	LH 2 SEAT 460CH 880W 221SM1L AR	TATA spare parts
319040003338	REAR RH 2 SEAT ON RLB HB	TATA spare parts
319040003339	REAR LH 2 SEAT ON RLB HB	TATA spare parts
319040003340	REAR MID 1 SEAT ON RLB LB HB	TATA spare parts
319040003346	LH 1 SEAT 460CH SM1L AR LB SKOOL	TATA spare parts
319040003357	RH 2 SEAT NEW HB 900W_SM1L_470CH_AR	TATA spare parts
319040003358	RH 2 SEAT NEW HB 900W_SM1L_470CH	TATA spare parts
319040003359	RH 2 SEAT NEW HB 900W_2L_470CH	TATA spare parts
319040003360	RR RH 2 SEAT NEW HB 900W_SM1L_470CH	TATA spare parts
319040003361	RR MID 1 SEAT NEW HB 400W_2L_470CH	TATA spare parts
319040003362	LH RR 2 SEAT NEW HB 900W_SM1L_470CH	TATA spare parts
319040003363	LH 2 SEAT NEW HB 900W_SM1L_470CH	TATA spare parts
319040003364	LH 2 SEAT NEW HB 900W_SM1L_470CH_AR	TATA spare parts
319040003365	LH 1 SEAT NEW HB 400W SM1L 470CH AR	TATA spare parts
319040003366	LH 1 NEW HB 400W_SM1L_360CH_AR	TATA spare parts
319040003367	RH 2 SEAT 2LEG PMS 460CH RED FAB CVG	TATA spare parts
319040003368	RH 2 SEAT 2LEG PMS 190CH RED FAB CVG	TATA spare parts
319040003369	LH 2SEAT 2LEG PMS 460CH AR RED FAB CVG	TATA spare parts
319040003370	LH 2 SEAT 2LEG PMS 500CH RED FAB CVG	TATA spare parts
319040003372	LH 2 SEAT 2LEG PMS 460CH RED FAB CVG	TATA spare parts
319040003373	LH 2 SEAT 2LEG PMS 190CH RED FAB CVG	TATA spare parts
319040003374	RH 2 SEAT 2LEG PMS 500CH RED FAB CVG	TATA spare parts
319040003377	REAR MID SEAT 2L LB PLSTIC RED FAB CVG	TATA spare parts
319040003378	LH 1 SEAT 360CH 2LEG MOUNT AR RED FAB PM	TATA spare parts
319040003414	RH 3 SEATR SM1CL LP 900W¿ SKL	TATA spare parts
319040003415	RH 3 SEATR SM1CL 900W¿ SKL	TATA spare parts
319040003416	RH 3 SEATR 900W SM1LG1CL WH¿ SKL	TATA spare parts
319040003417	RH 3 SEATR 900W 3LM SKL	TATA spare parts
319040003418	LH 3 SEATR 900W SM1CLM¿ SKL	TATA spare parts
319040003419	LH 3 SEATR 900W SM1CLM WH¿ SKL	TATA spare parts
319040003421	RR8 SKL SEAT MID LB 2150W LMTG	TATA spare parts
319040003432	RH 2SEAT HBR SM1L 900W AR LB	TATA spare parts
319040003433	RH 2SEAT HBR SM1L 900W AR LB W/O FR	TATA spare parts
319040003434	RH 2SEAT HBR 2LM 900W AR LB	TATA spare parts
319040003435	REAR RH RLB 2SEAT HBR 900W AR LB	TATA spare parts
319040003436	REAR LH RLB 2SEAT HBR 900W AR LB	TATA spare parts
319040003437	LH 2SEAT HBR SM1L 900W AR LB W/O FR	TATA spare parts
319040003438	LH 2SEAT HBR SM1L 900W AR LB	TATA spare parts
319040003439	CO-DRIVER FOLDABLE SEAT-Y1 RHD RED	TATA spare parts

319040003441	RH 2 SEAT 460CH SM1L PMS LB	TATA spare parts
319040003442	LH 2 SEAT 460CH SM1L PMS LB	TATA spare parts
319040003452	LH 2 SEAT SM1L PMS BLUE FABç RHS LB	TATA spare parts
319040003462	RH2 NW HB WO MP SM1L 900W	TATA spare parts
319040003463	RH2 NW HB WO MP AR 2L 900W	TATA spare parts
319040003464	RR MIDI NW HB WO MP AR 2L 400W LP	TATA spare parts
319040003465	LH 2 NW HB WO MP AR SM1L 900W	TATA spare parts
319040003466	LH 1 NW HB WO MP AR SM1L 900W BR	TATA spare parts
319040003467	LH1SEAT 2LG PMS 500CH BLUE FAB	TATA spare parts
319040003468	RH2SEAT 2LG PMS 500CH BLUE FAB	TATA spare parts
319040003495	RH 2 SEAT 460CH SM1L PMS LB	TATA spare parts
319040003496	LH 2 SEAT 460CH SM1L PMS LB	TATA spare parts
319040003497	COD RH 1 SEAT RH 2L AR PLASTIC	TATA spare parts
319040003501	RH 2SEAT 850W 510CH SM1LM LB AR HB1	TATA spare parts
319040003505	LH 1 SEAT 360CH SM1L WH AR LB SKL	TATA spare parts
319040003507	RH 2SEAT 850W 510CH SM1LM HB1	TATA spare parts
319040003509	LH 2SEAT 850W 510CH SM1LM HB1	TATA spare parts
319040003540	RH 2 SEAT 510CH TYP-2 SM1LMçç HB	TATA spare parts
319040003541	LH 2 SEAT 510CH TYP-2 SM1LMçç HB	TATA spare parts
319040003554	RH 2 SEAT 2LGç 460CH BLUE FAB	TATA spare parts
319040003555	RH 2 SEAT 2LGç 190CH BLUE FAB	TATA spare parts
319040003557	REAR MIDç 460CH 2LM LB BLUE FAB	TATA spare parts
319040003558	RH 2 SEAT 2LGç 460CH AR BLUE FAB	TATA spare parts
319040003561	RH 2 SEAT 2LGç 500CH BLUE FAB	TATA spare parts
319040003581	LH 1 SEAT 460CH 2LM BLUE FAB	TATA spare parts
319040003582	LH 1 SEAT 190CH 2LM WA BLUE FAB	TATA spare parts
319040003583	LH 1 SEAT 2LGç 500CH BLUE FAB	TATA spare parts
319040003584	RR LH 2 SEAT 460CH 2LG LB	TATA spare parts
319040003585	RH 2 SEAT 460CH 2LG LB BLUE FAB	TATA spare parts
319040003604	R RH 2 SEAT 460CH 2LG LB	TATA spare parts
319040003621	LH 2 SEAT 450CH SM1LM 2LB AR Y1 HB	TATA spare parts
319040003629	RH 2 SEAT 2LEG PMS 460CH AR RED FAB CVG	TATA spare parts
319040003630	RH 2 SEAT 2LEG PMS 460CH LP AR RED FAB C	TATA spare parts
319040003631	RH 2 SEAT 510CH TYP-2 SM1LMçç AR HB	TATA spare parts
319040003632	2 RH RR HB2 SM1LM 450CH	TATA spare parts
319040003633	2 LH RR HB2 SM1LM 450CH	TATA spare parts
319040003634	2 SEAT LH AR HB2 SM1LM	TATA spare parts
319040003635	LH 2SEAT 450CH TYP1 SM1LM 1LB AR HSSL HB	TATA spare parts
319040003637	RH 2SEAT DLX 1025W 3AR 2PLBç RED FAB CVG	TATA spare parts
319040003638	RH 2SEAT DL 1025W 3AR 2LB RED FAB W/O FR	TATA spare parts
319040003639	RR RH 2SEAT RLB DLX 1025W 3AR R FAB CVG	TATA spare parts
319040003656	LH 1 SEAT DLX 555W 2AR 2P LB RED FAB CVG	TATA spare parts
319040003657	LH 1SEAT DLX 555W 2AR LB RFAB W/O FR CVG	TATA spare parts
319040003673	RH 2ST SM1L 485CH850W_LB_AR_HB2 HSSL	TATA spare parts
319040003674	RH 2ST SM1L 485CH850W HB2 HSSL	TATA spare parts
319040003675	RH 2ST 2LM 485CH850W HB2 HSSL	TATA spare parts
319040003676	MID 1ST 2LM 485CH400W LB HB2 HSSL	TATA spare parts

319040003677	LH 2ST SM1L 485CH850W HB2 HSSL	TATA spare parts
319040003681	RH 2SEAT RR_HB2_SM1LM_450CH_HSSL	TATA spare parts
319040003682	RR LH 2ST SM1LM 485C850W HB2 HSSL	TATA spare parts
319040003683	LH 2 ST SM1L 485C850W AR HB2 HSSL	TATA spare parts
319040003684	LH 2ST SM1L 480CH850W BEFORE WA HB2	TATA spare parts
319040003685	RH 2ST SM1L 450CH850W BEFORE WA HB2 CVG	TATA spare parts
319040003686	LH 2ST SM1L 450CH850W BEFORE WA HB1 CVG	TATA spare parts
319040003687	RH 2ST SM1L 450CH850W BEFORE WA HB1 CVG	TATA spare parts
319040003693	LH 2ST SM1L 485CH850W BEFORE WA HB2 HSSL	TATA spare parts
319040003694	RH 2ST SM1L 485CH850W BEFORE WA HB2 HSSL	TATA spare parts
319040003695	RH 3SEAT 480CH SM2LM 1LB HB2 1200W	TATA spare parts
319040003696	RH 3SEAT 480CH SM2LM HB2 1200W	TATA spare parts
319040003697	RH 3ST SM2L 480CH1200W BEFORE WA HB2	TATA spare parts
319040003698	RH 3SEAT 480CH 3LM HB2 1200W	TATA spare parts
319040003699	REAR RH 3SEAT 480CH 3LM HB2 1200W	TATA spare parts
319040003700	RR LH 3SEAT 480CH SM2LM1LB HB2 1200W	TATA spare parts
319040003701	LH 2ST SM1L 480CH850W 2LB HB2	TATA spare parts
319040003702	3RH SM2L 450C1060W LB BH SKL TM	TATA spare parts
319040003703	3RH SM2L 450C1060W BH SKL TM	TATA spare parts
319040003704	3RH SM2L 450C1060W WA BH SKL TM	TATA spare parts
319040003706	2LH SM1L 450C760W BH SKL TM	TATA spare parts
319040003707	2LH SM1L 320C760W WA BH SKL TM	TATA spare parts
319040003708	2LH SM1L 450C850W AR LB HB1 TM	TATA spare parts
319040003709	3RH 3LM 450C1060W BH SKL TM	TATA spare parts
319040003757	RH 2SEAT 480CH HB2 2LM AR LB CVG BFAB	TATA spare parts
319040003759	RH 2 SEAT 480CH HB2 AR LB SM1LM BFAB CVG	TATA spare parts
319040003760	MID 1 SEAT 480CH HB2 2LM LB CVG BFAB	TATA spare parts
319040003761	LH 2ST 480CH HB2 AR LB SM1LM Y1 CVG BFAB	TATA spare parts
319040003763	LH2ST SM1L 480CH AR LB B4WH BFAB HB2 CVG	TATA spare parts
319040003764	RH2ST SM1L 480CH AR LB B4WH BFAB HB2 CVG	TATA spare parts
319040003765	RR RH 2 SEAT 480CH LB HB2 SM1LM CVG BFAB	TATA spare parts
319040003766	RR LH 2 SEAT 480CH LB HB2 SM1LM CVG BFAB	TATA spare parts
319040003767	LH 2 SEAT HBR_SM1L_900W_AR_1LB_RFAB_CVG	TATA spare parts
319040003768	RR RH 2SEAT HBREC_SM1L_LB_900W_CVG	TATA spare parts
319040003769	3RH SM2L 485CH1200W LB HB2 HSSL	TATA spare parts
319040003770	3RH SM2L 485CH1200W HB2 HSSL	TATA spare parts
319040003771	3RH SM2L 485C1200W BEFOR WA HB2 HSSL	TATA spare parts
319040003772	3RH 3LM 485CH1200W HB2 HSSL	TATA spare parts
319040003773	3RR RH SM2L 485C1200W HB2 HSSL	TATA spare parts
319040003774	3RR LH SM2L 480C1200W LB HB2 HSSL	TATA spare parts
319040003775	2LH SIDE MOUNT 1LEG 485 CH850W 2LB	TATA spare parts
319040003786	3RR 3LM 450C1060W BH SKL TM	TATA spare parts
319040003787	3RL 3LM 450C1060W LB BH SKL TM	TATA spare parts
319040003789	2RH SM1L 450C850W HB1 TM	TATA spare parts
319040003790	2RH 2LM 450C850W HB1 TM	TATA spare parts
319040003791	1RM 2LM 450C410W LB HB1 TM	TATA spare parts
319040003792	2LH SM1L 450C850W HB1 TM	TATA spare parts



319040003793	2LH SM1L 450C850W AR 2LB HB1 TM	TATA spare parts
319040003794	2RL SM1L 450C850W HB1 TM	TATA spare parts
319040003795	2RR SM1L 450C850W HB1 TM	TATA spare parts
319040003796	2RH SM1L 510C850W HB1 TM	TATA spare parts
319040003797	2LH SM1L 510C850W HB1 TM	TATA spare parts
319040003802	2RR 2LM 485C810W LB FB HB2 CVG	TATA spare parts
319040003803	1RM 485C410W LB FB HB2 CVG	TATA spare parts
319040003817	1LH_SM1L_360C400W_AR_LB_HB2_CVG	TATA spare parts
319040003820	2RH 2LM 475C1025W AR 3PLB BLFB PB HS	TATA spare parts
319040003821	2RH 2LM 365C1025W AR 3PLB WA BLFB PB HS	TATA spare parts
319040003822	2RH 2LM 475C1025W AR 3PLB WOFR BFB PB HS	TATA spare parts
319040003823	2LH 2LM 475C1025W AR 3PLB WOFR BFB PB HS	TATA spare parts
319040003824	1LH 2LM 365C1025W AR 3PLB WA BLFB PB HS	TATA spare parts
319040003825	1LH 2LM 475C1025W AR 3PLB BLFB PB HS	TATA spare parts
319040003839	2RH SIDE MOUNT 1LEG 460C850W 2PLB HB1 CV	TATA spare parts
319040003840	2RH 2LEG MOUNT 460C850W 2PLB HB1 CVG	TATA spare parts
319040003841	2RR 2LEG MOUNT 460C850W 2PLB HB1 CVG	TATA spare parts
319040003842	2RL SIDE MOUNT 1LEG 460C850W 2PLB HB1 CV	TATA spare parts
319040003843	2LH SIDE MOUNT 1LEG 460C850W 2PLB HB1 CV	TATA spare parts
319040003844	2LH SIDE MOUNT 1LEG 460C850W 2PLB AR HB1	TATA spare parts
319040003846	2RH 2LM 460C940W AR LB BLFB PB PN	TATA spare parts
319040003851	2LH 2LM 460C940W AR LB BLFB PB PN	TATA spare parts
319040003852	RH_2S_2L_CVG_PMS_460C_810W_2LP_AR_W/O	TATA spare parts
319040003853	RH_2ST_2LG_PMS_CVG_360CH_810W_W/O CUS	TATA spare parts
319040003855	RH_2S_460CH_810W_2LM_2LB_PMS_CVG_W/O	TATA spare parts
319040003856	LH_2S_2L_PMS_CVG_460C_810W_1LP_AR_W/O	TATA spare parts
319040003857	LH 1S_360CH_2LM_AR_PMS_400W_CVG_W/O C	TATA spare parts
319040003870	RH 2SEAT HBREC SM1L 900W AR VSPL BS-14	TATA spare parts
319040003871	RH 2SEAT HBREC SM1L 900W AR W/O FR CVG	TATA spare parts
319040003872	REAR RH RLB 2SEAT HBR 900W AR LB CVG	TATA spare parts
319040003874	LH 2 SEAT HB REC SM1L 900W AR CVG	TATA spare parts
319040003875	LH 1 SEAT HB REC SM1L 485W AR LB CVG	TATA spare parts
319040003876	REAR MID SEAT HB REC 410W LB CVG	TATA spare parts
319040003877	LH 2 SEAT HBR SM1L 900W AR 1LB RFAB CVG	TATA spare parts
319040003878	LH 2SEAT HBREC SM1L 900W AR W/O FR CVG	TATA spare parts
319040003879	2RH SIDE MOUNT 1LEG MOUNT 450CH850W HB2	TATA spare parts
319040003880	2RH SIDE MOUNT 1LEG MOUNT 450CH850W HB2	TATA spare parts
319040003881	2RH 450CH850W HB2 2LEG MOUNT RFB CVG BS-	TATA spare parts
319040003882	2RR SIDE MOUNT 1LEG MOUNT 480C850W FB HB	TATA spare parts
319040003883	1MID 480CH400W HB2 RFB 2LEG MOUNT LB CVG	TATA spare parts
319040003884	2RL SIDE MOUNT 1LEG MOUNT 480C850W FB HB	TATA spare parts
319040003885	2LH SIDE MOUNT 1LEG MOUNT 450CH850W HB2	TATA spare parts
319040003886	2LH SIDE MOUNT 1LEG MOUNT 450CH850W HB2	TATA spare parts
319040003887	2LH SIDE MOUNT 1LEG MOUNT 450CH850W HB2	TATA spare parts
319040003888	2RH SIDE MOUNT 1LEG MOUNT 450CH850W HB2	TATA spare parts
319040003915	2RH SM1L 480C850W AR LB HB2 TM	TATA spare parts
319040003916	2RH SM1L 480C850W HB2 TM	TATA spare parts

319040003917	2RH 2LM 480C850W HB2 TM	TATA spare parts
319040003918	1RM 2LM 480C410W LB HB2 TM	TATA spare parts
319040003919	2LH SM1L 480C850W HB2 TM	TATA spare parts
319040003920	2LH SM1L 480C850W AR HB2 TM	TATA spare parts
319040003921	2LH SM1L 480CH850W BEFORE WA HB2 TM	TATA spare parts
319040003922	2RH SM1L 480CH850W BEFORE WA HB2 TM	TATA spare parts
319040003923	2RR SM1L 480C850W HB2 TM	TATA spare parts
319040003924	2RL SM1L 480C850W HB2 TM	TATA spare parts
319040003925	2RH SM1L 450C850W AR LB HB1 TM	TATA spare parts
319040003926	2RH SM1L 460C850W AR LB HB1 BS-13 CVG	TATA spare parts
319040003927	2RH SM1L 460C850W AR HB1 BS-13 CVG	TATA spare parts
319040003928	2RR 2LM 460C850W HB1 BS-13 CVG	TATA spare parts
319040003929	1RM 460C410W LB HB1 BS-13 CVG	TATA spare parts
319040003930	2RL SM1L 460C850W HB1 BS-13 CVG	TATA spare parts
319040003931	2LH SM1L 460C850W AR HB1 BS-13 CVG	TATA spare parts
319040003932	2LH SM1L 460C850W AR 1LB HB1 BS-13 CVG	TATA spare parts
319040003933	1LH SM1L 360C410W AR HB1 BS-13 CVG	TATA spare parts
319040003934	1LH 2LM 460C410W AR LB HB1 BS-13 CVG	TATA spare parts
319040003944	1LH SM1L 360CH410W_LB_AR_WA_HB1 TM	TATA spare parts
319040003945	2LH SM1L 450C850W AR 1LB HB1 TM	TATA spare parts
319040003946	RH 2SEAT HBR SM1L 900W AR LB CVG BS-14	TATA spare parts
319040003947	RH 2SEAT HBR SM1L 900W AR LB W/O FR CVG	TATA spare parts
319040003949	RR LH RLB 2SEAT HBR 900W AR LB BS14 CVG	TATA spare parts
319040003950	LH 2 SEAT HBR SM1L 900W AR LB BS14 CVG	TATA spare parts
319040003951	LH 2SEAT HBR SM1L 900W AR LB W/O FR CVG	TATA spare parts
319040003960	CO-DRIVER 1SEAT BS-13 FOLDABLE CVG	TATA spare parts
319040003968	2RR 2LM 485C810W LB VN HB2 HSSL	TATA spare parts
319040003970	2RR 2LM 485C810W LB VN HB2 CVG	TATA spare parts
319040004007	BOTTLE HOLDER	TATA spare parts
319040004008	MAGAZINE POUCH BS6	TATA spare parts
319040004009	OUTER VALENCE COVER RH HBR SEAT	TATA spare parts
319040004010	OUTER VALENCE COVER LH HBR SEAT	TATA spare parts
319040004016	BACKREST PLASTIC INSERT BLUE	TATA spare parts
319040004017	BACKREST PLASTIC INSERT ORANGE	TATA spare parts
319040004018	CUSHION PLASTIC INSERT BLUE	TATA spare parts
319040004019	CUSHION PLASTIC INSERT ORANGE	TATA spare parts
319040004020	PASSANGER SEAT PLASTIC FRAME	TATA spare parts
319040004021	BACKREST PLASTIC WITH HONEY COMB FABRIC	TATA spare parts
319040004022	CUSHION PLASTIC WITH HONEY COMB FABRIC	TATA spare parts
319042001001	KPIT ITS_KIT_MOUD-II (MIDI)	TATA spare parts
319042003002	PANEL PLATE ASSEMBLY LH	TATA spare parts
319042003004	PANEL PLATE ASSEMBLY LH	TATA spare parts
319042003005	PANEL PLATE ASSEMBLY LH	TATA spare parts
319042003006	PANEL PLATE ASSEMBLY RH	TATA spare parts
319042003008	REAR DESTINATION BOARD BRKT ASSY LH	TATA spare parts
319042003009	REAR DESTINATION BOARD BRKT ASSY RH	TATA spare parts
319042003011	SIDE DESTINATION BOARD BRKT ASSY LH	TATA spare parts

319042003012	SIDE DESTINATION BOARD BRKT ASSY RH	TATA spare parts
319042003015	PANEL PLATE ASSEMBLY LH	TATA spare parts
319042003016	SUPPORT BKT INNER DESTINATION BOARD ASSY	TATA spare parts
319042003017	SUPPORT BKT FRONT DESTINATION BOARD ASSY	TATA spare parts
319042003021	FRONT DESTINATION BOARD BRT.ASSLY LH	TATA spare parts
319042003022	FRONT DESTINATION BOARD BRT.ASSLY RH	TATA spare parts
319042003029	PANEL PLATE ASSEMBLY _LH	TATA spare parts
319042003032	PANEL PLATE ASSY LH	TATA spare parts
319042003037	KPIT W/H KIT ITS-09-005 _MIDI	TATA spare parts
319042003043	SUPPORT RHç BKT INNER DESTINATION BOARD	TATA spare parts
319042003045	PANEL PLATE ASSEMBLY LH	TATA spare parts
319042003046	PANEL PLATE ASSEMBLY RH	TATA spare parts
319042003047	PANEL PLATE ASSEMBLYç LH	TATA spare parts
319042003049	PANEL PLATE ASSEMBLY LH 3 LTR	TATA spare parts
319042003050	PANEL PLATE ASSEMBLY RH 3 LTR	TATA spare parts
319042003051	PANEL PLATE ASSY RH ABS	TATA spare parts
319042003052	PANEL PLATE ASSY LH ABS	TATA spare parts
319042003056	PANEL PLATE _LH ASSEMBLY	TATA spare parts
319042003060	PANELPLATEASSEMBLY _LH	TATA spare parts
319042003067	KPIT W/H KIT ITS-09-005 MIDI	TATA spare parts
319042003073	PANEL PLATE ASSEMBLY AMT LH	TATA spare parts
319042003077	PANEL PLATE ASSEMBLY RH _SURAT	TATA spare parts
319042003078	PANEL PLATE ASSY RH-LHD	TATA spare parts
319042003079	PANEL PLATE ASSY LH LHD	TATA spare parts
319042003087	PANEL PLATE ASSY LH WITH BDC	TATA spare parts
319042003088	PANEL PLATE ASSEMBLY LH AMT	TATA spare parts
319042082001	RH SIDE PANEL PLATE ASSY	TATA spare parts
319042082011	REVERSE CAMERA MOUNTING PLATE GEN5	TATA spare parts
319042083003	DASHBOARD HAND BRAKE PLATE	TATA spare parts
319042083004	LAPTOP CHARGER INVERTER BOX 150W	TATA spare parts
319042083013	FRONT DESTINATION BOARD BRKT LH	TATA spare parts
319042083014	FRONT DESTINATION BOARD BRKT RH	TATA spare parts
319042083015	INTERNAL DESTINATION BOARD BRKT LH	TATA spare parts
319042083016	INTERNAL DESTINATION BOARD BRKT RH	TATA spare parts
319042083017	SIDE DESTINATION BOARD BRKT LH	TATA spare parts
319042083018	SIDE DESTINATION BOARD BRKT RH	TATA spare parts
319042083019	COVER FOR LIMIT SWITCH	TATA spare parts
319042083026	RADIO PANEL PLATE	TATA spare parts
319042083028	SCU MOUNTING BRACKET Z TYPE LH	TATA spare parts
319042083030	SCU MOUNTING BRACKET Z TYPE RH	TATA spare parts
319042083033	LAPTOP CHARGER INVERTER BOX	TATA spare parts
319042083037	PANEL PLATE LH	TATA spare parts
319042083038	PANEL PLATE RH	TATA spare parts
319042083051	CLOSING PLATE _AC CUTOUT _PMPML	TATA spare parts
319042084020	ROOF ANTENA MOUNTING BKT	TATA spare parts
319042084050	HAND BRAKE MOUNTING PLATE	TATA spare parts
319042084071	PANELPLATE _RH _AMT	TATA spare parts

319042084074	SUPPORT PLATE FOR SIDE D.B.	TATA spare parts
319042084076	SUPPORT PLATE FOR SIDE D.B.	TATA spare parts
319042084093	HAND BRAKE MOUNTING PLATE FOR LHD	TATA spare parts
319042084108	SIDE DESTI BOARD MTG BKT 1	TATA spare parts
319042084109	SIDE DESTI BOARD MTG BKT 2	TATA spare parts
319042324001	LUMINARY FRAME	TATA spare parts
319042361002	ELECTRICAL HARNESS ASSY MIDI	TATA spare parts
319042361005	PIGTAIL W/H FOR USB ETM CHARGER 9X9 GEN5	TATA spare parts
319042362001	DASHBOARD MULTIPLEX HARNESS	TATA spare parts
319042362002	UPPER FRONT MULTIPLEX HARNESS	TATA spare parts
319042362004	LEFT SIDE ROOF HARNESS MUX	TATA spare parts
319042362014	HARNESS OBU BDC 9M GEN 5_CHEMITO	TATA spare parts
319042362015	HARNESS ITS COMPONENT 9M GEN5_CHEMITO	TATA spare parts
319042363001	DASHBOARD ELECTRICAL HARNESS	TATA spare parts
319042363002	UPPER FRONT ELECTRICAL HARNESS	TATA spare parts
319042363003	INTERNAL ILLUMINATION ELECTRICAL HARNESS	TATA spare parts
319042363004	REAR SPEAKERS ELECTRICAL HARNESS	TATA spare parts
319042363005	RADIO (DASHBOARD) ELECTRICAL HARNESS	TATA spare parts
319042363006	SINGLE DOOR LOWER ELECTRICAL HARNESS	TATA spare parts
319042363007	DOUBLE DOOR LOWER ELECTRICAL HARNESS	TATA spare parts
319042363008	TAIL LAMPS PIG TAIL ELECTRICAL HARNESS	TATA spare parts
319042363009	STOP REQUEST SWITCH ELECTRICAL HARNESS	TATA spare parts
319042363011	SIDE TURN INDICATOR ELECT. HARNESS_RH	TATA spare parts
319042363012	SIDE TURN INDICATOR ELECT. HARNESS_LH	TATA spare parts
319042363017	INVERTER OUTPUT ELECTRICAL HARNESS	TATA spare parts
319042363018	DOOR OPENED INDICATION HARNESS	TATA spare parts
319042363019	INVERTER POWER SUPPLY W/H 300W	TATA spare parts
319042363020	REAR LAPTOP INVERTER PIG TAIL	TATA spare parts
319042363021	LUGGAGE BOOTH LAMP HARNESS	TATA spare parts
319042363022	AC_UPPER FRONT ELECTRICAL HARNESS	TATA spare parts
319042363023	MONITOR POWER SUPPLY W/H	TATA spare parts
319042363024	AC DUCT LAMPS HARNESES LH/RH	TATA spare parts
319042363025	GROUND CONNECTION CABLE	TATA spare parts
319042363028	MONITOR PIG TAIL	TATA spare parts
319042363032	DASHBOARD ELECTRICAL HARNESS	TATA spare parts
319042363033	UPPER FRONT ELECTRICAL HARNESS	TATA spare parts
319042363036	DRIVER FAN ELECTRIC HARNESS	TATA spare parts
319042363040	PIGTAIL HARNESS FOR SIDE TURN INDICATOR	TATA spare parts
319042363041	PIGTAIL HARNESS FOR SIDE MARKER LAMP	TATA spare parts
319042363042	DESTINATION BOARD ELECTRICAL HARNESS	TATA spare parts
319042363044	SIDE MARKER HARNESS 47WB MULTIPLEX	TATA spare parts
319042363045	STOP REQUEST EME AND HANDICAP HARNESS	TATA spare parts
319042363047	SLB&R RLB LAMP HARNESS	TATA spare parts
319042363048	POWER SUPPLY HARNESS FOR AMPLIFIER	TATA spare parts
319042363049	CO DRIVER LAMP HARNESS	TATA spare parts
319042363050	SPEAKER ELECTRIC HARNESS	TATA spare parts
319042363051	PIGTAIL ADAPTER DIN 5 PIN M2F	TATA spare parts

319042363053	PASSENGER FAN HARNESS CDS	TATA spare parts
319042363055	ROOF ELECTRIC HARNESS	TATA spare parts
319042363056	FRONT DESTINATION BOARD ELECTRIC HARNESS	TATA spare parts
319042363059	SPEAKER ELECTRICAL HARNESS	TATA spare parts
319042363061	LED LUMINARY WH PIGTAIL SUPPLY	TATA spare parts
319042363067	STOP REQUEST HARNESS CO DRIVER SIDE	TATA spare parts
319042363068	STOP REQUEST HARNESS DRIVER SIDE	TATA spare parts
319042363069	POWER SUPPLY HARNESS FOR CONDUCTOR FAN	TATA spare parts
319042363072	PIGTAIL ADAPTER 2*RCA TO PLUG 6.3MM	TATA spare parts
319042363075	CENTRE & REAR SPEAKER HARNESS	TATA spare parts
319042363076	DIGITAL CLOCK ELECTRICAL HARNESS	TATA spare parts
319042363077	INTERNAL LAMP HARNESS	TATA spare parts
319042363078	DOOR OPENED INDICATION HARNESS	TATA spare parts
319042363088	MIL INDICATOR PIGTAIL HARNESS	TATA spare parts
319042363089	BATTERY CUT-OFF SWITCH PIGTAIL HARNESS	TATA spare parts
319042363090	HAZARD WARNING SWITCH PIGTAIL HARNESS	TATA spare parts
319042363091	PIGTAIL FOR KPIT HEAD SET	TATA spare parts
319042363092	PIGTAIL FOR STEP LAMP	TATA spare parts
319042363093	FDSS POWER HARNESS TO CCU	TATA spare parts
319042363094	FDSS CCU TO DETECTOR HARNESS	TATA spare parts
319042363096	WIPER MOTOR PIGTAIL HARNESS	TATA spare parts
319042363098	MIDDLE DOOR LOWER ELECTRICAL HARNESS	TATA spare parts
319042363099	INTERNAL LAMP HARNESS Y1 AC	TATA spare parts
319042363101	DOOR ELECTRICAL HARNESS	TATA spare parts
319042363106	EMERGENCY DECLARATION ELECTRIC HARNESS	TATA spare parts
319042363107	STOP REQUEST SWITCH HARNESS	TATA spare parts
319042363109	DRIVER LAMP POWER SUPPLY HARNESS	TATA spare parts
319042363111	INTERNAL LAMP HARNESS ABS	TATA spare parts
319042363112	ROOF HARNESS	TATA spare parts
319042363113	SPEAKAR ELECTRIC HARNESS	TATA spare parts
319042363114	STOP REQUEST SWITCH ELECTRICAL HARNESS	TATA spare parts
319042363115	DVR AND WI-FI SYS POWER SUPPLY DC(6-32V)	TATA spare parts
319042363116	MOBILE CHARGER USB WIRING HARNESS	TATA spare parts
319042363119	MOBILE CHARGER HARNESS FOR DRIVER SIDE	TATA spare parts
319042363120	MOBILE CHARGER HARNESS FOR CO-DRIVER	TATA spare parts
319042363121	INTERNAL LAMP HARNESS_AC	TATA spare parts
319042363122	UPPER FRONT ELECTRIC HARNESS	TATA spare parts
319042363123	SIDE MARKER LAMP HARNESS PIGTAIL	TATA spare parts
319042363127	SLB HARNESS_3SLB_TANZANIA	TATA spare parts
319042363130	SIDE & REAR DESTINATION HARNESS_NAGPUR B	TATA spare parts
319042363131	READING LAMP SUPPLY HARNESS	TATA spare parts
319042363132	INTERNAL LAMP HARNESS	TATA spare parts
319042363133	EMERGENCY DECLARATION HARNESS_MUX	TATA spare parts
319042363137	READING LAMP HARNESS	TATA spare parts
319042363140	DESTINATION BOARD HARNESS_JON DEERE	TATA spare parts
319042363141	CONVERTER PIGATIL_PMPML	TATA spare parts
319042363143	WIRING HARNESS PIGTAIL FOR FRONT CAMERA	TATA spare parts

319042363149	RADIO/DVD HARNESS_NEPAL	TATA spare parts
319042363150	PIGTAIL HARNEAA FOR REVERSE ALARM TO DVR	TATA spare parts
319042363151	SPEAKER ELECTRIC HARNESS_NEPAL	TATA spare parts
319042363154	EMERGENCY DECLARATION HARNESS	TATA spare parts
319042363155	UPPER FRONT PASSANGER FAN HARNESS	TATA spare parts
319042363156	CONT. TO FRONT DB COMM. CABLE	TATA spare parts
319042363157	FRONT TO REAR COMMUNICATION CABLE	TATA spare parts
319042363158	INTERNAL TO SIDE REAR COMM CABLE BS6	TATA spare parts
319042363159	MOBILE CHARGER HARNESS DS & CDS	TATA spare parts
319042363160	PIGTAIL HARNESS FOR MANUAL DEST BOARD BS	TATA spare parts
319042363164	SUPPLY HARNESS FOR MONITOR	TATA spare parts
319042363165	DESTINATION BOARD POWER SUPPLY HARNESS	TATA spare parts
319042363168	AIS140 EMERGENCY SWITCH HARNESS_49/52WB	TATA spare parts
319042363169	AIS140 EMERGENCY SW HARNESS_42WB	TATA spare parts
319042363170	MOBILE CHARGER HARNESS_CSD	TATA spare parts
319042363171	MOBILE CHARGER HARNESS_DS	TATA spare parts
319042363175	MOBILE CHARGER HARNESS 8NOS	TATA spare parts
319042363177	EMERGENCY DECLARATION HARNESS	TATA spare parts
319042363181	INTERNAL LAMP HARNESS	TATA spare parts
319042363182	PASSENGER FAN HARNESS DS EV 9/9	TATA spare parts
319042363183	PASSENGER FAN HARNESS CDS EV9/9	TATA spare parts
319042363184	FRONT ROOF MULTIPLEX W/H EV 9/9	TATA spare parts
319042363185	PIGTAIL HARNESS FOR 600MM LED STRIP EV	TATA spare parts
319042363186	REAR LOWER ELECTRIC HARNESS EV	TATA spare parts
319042363187	REAR ROOF MULTIPLEX W/H EV 9/9	TATA spare parts
319042363192	INTERNAL LAMP HARNESS Y1 EXPO	TATA spare parts
319042363193	GANGWAY LAMP & USB HARNESS EXPO	TATA spare parts
319042363196	SUPPLY HARNESS FOR MOBILE CHARGER	TATA spare parts
319042363200	INTERNAL ILLUMINATION HARNESS 52WB AC	TATA spare parts
319042363202	VIDEO SPLITTER_2 TV_DVD	TATA spare parts
319042363207	MONITOR POWER SUPPLY	TATA spare parts
319042363208	MONITOR TO SPEAKER HARNESS	TATA spare parts
319042363209	INTERNAL LAMP HARNESS FOR PE LAMP	TATA spare parts
319042363210	GANGWAY GRAB HANDLE & USB HARNESS	TATA spare parts
319042363211	SUPPLY HARNESS FOR USB CHARGER	TATA spare parts
319042363212	MOBILE CHARGER HARNESS DS	TATA spare parts
319042363213	STOP REQUEST HARNESS EV	TATA spare parts
319042363214	STOP REQUEST SWITCH HARNESS	TATA spare parts
319042363217	PIGTAIL FOR CAMERA_KPIT	TATA spare parts
319042363219	GANG WAY LAMP & USSB HARNESS CDS	TATA spare parts
319042363221	MOBILE CHARGER USB HARNESS EV	TATA spare parts
319042363226	POWER SUPPLY HARNESS FOR CONT AIS 153	TATA spare parts
319042363227	INTERNAL LAMP PIGTAIL EV NAC	TATA spare parts
319042363228	PIGTAIL FOR VMS SIGNAL_EV	TATA spare parts
319042363229	INTERNAL ILLUMINATION HARNESS_7NO	TATA spare parts
319042363230	PIGTAIL FOR PASSENGER FAN BS6	TATA spare parts
319042363231	MOBILE CHARGER HARNESS_USB	TATA spare parts

319042363232	RFID POWER SUPPLY HARNESS BS6	TATA spare parts
319042363241	MOBILE CHARGER HARNESS CDS	TATA spare parts
319042363242	MOBILE CHARGER HARNESS-DS	TATA spare parts
319042363245	PNEUMATIC DOOR HARNESS FOR AIS 153	TATA spare parts
319042363249	*REAR ROOF MULTIPLEX W/H_EV_9/9 BRT* BS6	TATA spare parts
319042363256	AIS 140 EMEGENCY SW HARNESS 9/9 BS6	TATA spare parts
319042363261	PIGTAIL FOR BRYS DOOR LED STRIP BS6	TATA spare parts
319042363262	FRONT DEST BOARD TO INNER DEST BOARD BS6	TATA spare parts
319042363263	INNER TO RH DESTINATION BOARD BS6	TATA spare parts
319042363264	RH TO REAR DESTINATION BOARD BS6	TATA spare parts
319042363265	REAR TO LH DEST BOARD HARNESS BS6	TATA spare parts
319042363267	WH SCU SPEAKER AND CAMERA FOR IP BS6	TATA spare parts
319042363268	WH SCU POWER SUPPLY FOR IP BS6	TATA spare parts
319042363269	WH REVERSE CAMERA FOR IP BS6	TATA spare parts
319042363271	WH IP CAMERA 02 TO POE BS6	TATA spare parts
319042363272	WH IP CAMERA 03 TO POE BS6	TATA spare parts
319042363275	WH SCU TO POE BS6	TATA spare parts
319042363276	WH ROOF SPEAKER TO SCU BS6	TATA spare parts
319042363278	MOBILE CHARGER HARNESS USB TYPE DS BS6	TATA spare parts
319042363279	MOBILE CHARGER HARNESS USB TYPE CDS BS6	TATA spare parts
319042363282	ITS WIRING HARNESS_9MTR_CHEMITO EV	TATA spare parts
319042363283	LIFT HARNESS_EV EV	TATA spare parts
319042363284	NEGATIVE_CABLE_BEST EV_9X9 EV	TATA spare parts
319042363286	W/HARNESS USB PASSENGER EV ALL SEATS	TATA spare parts
319042363287	W/HARNESS PASSENGER USB LH EV	TATA spare parts
319042363290	HARNESS AIS 140 SW 6-NOS_DS_GEN 5	TATA spare parts
319042363291	HARNESS_FRONT VECU INTERFACE_GEN5	TATA spare parts
319042363292	HARNESS_REAR VECU INTERFACE_GEN5	TATA spare parts
319042363293	HARNESS_STOP REQUEST SWITCH_GEN5	TATA spare parts
319042363295	WIRING HARNESS LIFT_9/9 CESL	TATA spare parts
319042363296	INTERNAL LAMP W/H_CESL	TATA spare parts
319042363297	HARNESS AIS 140 SW 3-NOS_DS_GEN 5	TATA spare parts
319042363300	CABLE ANALOG CAMERA EXTENSION_CHEMITO	TATA spare parts
319042364006	KPIT_DEST_FRNT_TO_SIDE_ITS-09-018	TATA spare parts
319042372004	LED STRIP 600MM_36+3_0.5WATT INVEL	TATA spare parts
319042372005	LED STRIP AMBIENT SALOON_INVEL	TATA spare parts
319042373001	ROOF LUMINARY ASSEMBLY 24V	TATA spare parts
319042373002	INTERNAL LUMINARY ASSEMBLY-12V	TATA spare parts
319042373006	SIDE & REAR DESTINATION BOARD	TATA spare parts
319042373007	INTERNAL DESTINATION BOARD	TATA spare parts
319042373008	IBDC CONTROLLER	TATA spare parts
319042373009	FRONT DESTINATION BOARD	TATA spare parts
319042373010	INTERNAL DESTINATION BOARD	TATA spare parts
319042373015	ACCOLADE BDC MOUNTING STAND	TATA spare parts
319042373016	MICROPHONE ACCOLADE BS6	TATA spare parts
319042373018	ACCOLADE WITH GRILL SPEAKER BS6	TATA spare parts
319042373019	ACCOLADE CAMERA BS6	TATA spare parts

319042373020	ACCOLADE HEAD SET BS6	TATA spare parts
319042373021	ACCOLADEç BDC BS6	TATA spare parts
319042373022	ACCOLADE IP CAMERA	TATA spare parts
319042373025	ACCOLADE SCU+POE BS6	TATA spare parts
319042373026	ACCOLADE COMBI ANTENNA BS6	TATA spare parts
319042912036	LAPTOP AND MOBILE CHARGER ASSY_F&R_150W	TATA spare parts
319042963001	Y1_42 WB AIS 140 RETRO KIT	TATA spare parts
319042963002	Y1_49 WB AIS 140 RETRO KIT	TATA spare parts
319042963003	Y1_52 WB AIS 140 RETRO KIT	TATA spare parts
319042963004	Y1_42 WB AIS 140 RETRO KIT_24V	TATA spare parts
319042963005	Y1_49 WB AIS 140 RETRO KIT_24V	TATA spare parts
319042963006	Y1_52 WB AIS 140 RETRO KIT_24V	TATA spare parts
319044003004	LADDER ASSEMBLY	TATA spare parts
319044003012	RLC COMPLETE STRUCTURE ASSY	TATA spare parts
319044183003	ALUMINIUM CHEQUERED PLATE RLC BASE 2050	TATA spare parts
319045003111	REAR DEST. BOARD BKT ASSY	TATA spare parts
319045003113	BRACKET ASSEMBLY	TATA spare parts
319045083014	CROSS BEARER NEAR REAR SUSPENSOR	TATA spare parts
319045083015	CROSS BEARER NEAR REAR SUSPENSOR (RH)	TATA spare parts
319045083460	LV BATTERY CLOSING PANEL	TATA spare parts
319045912136	SHELL ASSEMBLY DOOR BETWEEN WB	TATA spare parts
319046073001	TOWING HOOK	TATA spare parts
319050003005	AIR TRANSITION BOX ASSY	TATA spare parts
319050003007	AC DUCT ASSEMBLY(DRIVER SIDE)	TATA spare parts
319050003008	AC DUCT ASSEMBLY CO-DRIVER SIDE	TATA spare parts
319050003014	FRONT AC DUCT SUB ASSEMBLY	TATA spare parts
319050003015	DRIVER EXTENSION SUB ASSEMBLY	TATA spare parts
319050003016	AC DUCT CONNECTOR SUB ASSEMBLY	TATA spare parts
319050003021	RH SIDE AC DUCT ASSY WITH REXINE 52WB	TATA spare parts
319050003022	LH SIDE AC DUCT ASSY WITH REXINE 52WB	TATA spare parts
319050003024	RH AND LH TR BOX COVERS	TATA spare parts
319050003028	SUN SHADE ASSY Y1 MIDI	TATA spare parts
319050003034	AC DUCT ASSY CO-DRIVER SIDE	TATA spare parts
319050003035	LH AND RH TR BOX COVER DRI&CO-DRI	TATA spare parts
319050003036	AC DUCT ASSY DRIVER SIDE	TATA spare parts
319050003042	RH AND LH TR BOX COVERS	TATA spare parts
319050003044	AC DUCT ASSEMBLY	TATA spare parts
319050003045	AC DUCT ASSEMBLY CO-DRIVER SIDE	TATA spare parts
319050003047	AC DUCT ASSY CO DRIVER SIDE	TATA spare parts
319050003048	AC DUCT ASSEMBLY RH SIDE	TATA spare parts
319050003049	FRONT PLYWOOD COVER FOR TRANSITION BOX	TATA spare parts
319050003050	RH AND LH TR BOX COVER	TATA spare parts
319050003055	AC DUCT PANEL ASSY RH Y1-900	TATA spare parts
319050003056	AC DUCT PANEL ASSY LH Y1-900	TATA spare parts
319050003063	AC DUCT ASSEMBLY_DRIVER SIDE_41HBS	TATA spare parts
319050003064	AC DUCT ASSEMBLY_CO-DRIVER SIDE	TATA spare parts
319050003065	AC DUCT ASSEMBLY_CO DRIVER SIDE	TATA spare parts



319050003066	AC DUCT ASSEMBLY_RH SIDE_AIS063	TATA spare parts
319050003067	AC DUCT ASSEMBLY DRIVER SIDE EVO 1	TATA spare parts
319050003068	AC DUCT ASSEMBLY-CO-DRIVER SIDE EVO1	TATA spare parts
319050003069	AC DUCT SHEET-2020 X 676(6 HOLES) RH 2ND	TATA spare parts
319050003070	AC DUCT SHEET-2020 X 676. (6 HOLES)	TATA spare parts
319050003074	RH AC DUCT ASSEMBLY HBS SEATS 52WB	TATA spare parts
319050003075	CO-DRIVER AC DUCT ASSEMBLY 52WB	TATA spare parts
319050003076	RH AC DUCT ASSEMBLY PBS SEATS 52WB	TATA spare parts
319050003077	CO-DRIVER AC DUCT ASSEMBLY 52WB PBS	TATA spare parts
319050003089	Y1 GRILL HAT RACK BRACKET ASSY REAR	TATA spare parts
319050003093	AC DUCT ASSEMBLY	TATA spare parts
319050003094	AC DUCT ASSEMBLY	TATA spare parts
319050003137	BUDGET LOCK	TATA spare parts
319050003144	AC DUCT PANEL ASSY-RH 1	TATA spare parts
319050003145	AC DUCT PANEL ASSY-RH 2	TATA spare parts
319050003146	AC DUCT PANEL ASSY-RH 3	TATA spare parts
319050003147	AC DUCT PANEL ASSY-RH 4	TATA spare parts
319050003148	AC DUCT PANEL ASSY 1	TATA spare parts
319050003149	AC DUCT PANEL ASSY-LH 2	TATA spare parts
319050003150	AC DUCT PANEL ASSY-LH 3	TATA spare parts
319050003179	AC DUCT & HATRACK SUB ASSY-LH	TATA spare parts
319050003180	AC DUCT & HATRACK SUB ASSY-RH	TATA spare parts
319050003210	END PANEL 1 ASSY	TATA spare parts
319050003211	END PANEL 2 ASSY	TATA spare parts
319050003212	TRANSITION PANEL 1 ASSY	TATA spare parts
319050003213	TRANSITION PANEL 2 ASSY	TATA spare parts
319050003214	AC DUCT & HATRACK SUB ASSY-LH	TATA spare parts
319050003215	AC DUCT & HATRACK SUB ASSY-RH	TATA spare parts
319050003221	AC DUCT ASSY-RH GREY	TATA spare parts
319050003226	AC DUCT ASSY-LH	TATA spare parts
319050003227	AC DUCT ASSY-RH	TATA spare parts
319050003238	AC DUCT ASSEMBLY	TATA spare parts
319050003239	AC DUCT ASSEMBLY EV01	TATA spare parts
319050003255	AC DUCT & HATRACK SUB ASSY-RH	TATA spare parts
319050003257	AC DUCT & HATRACK SUB ASSY-LH	TATA spare parts
319050003258	AC DUCT & HATRACK SUB ASSY-RH	TATA spare parts
319050003264	AC DUCT & HATRACK SUB ASSY-RH	TATA spare parts
319050003265	AC DUCT & HATRACK SUB ASSY-LH	TATA spare parts
319050003267	AC DUCT & HATRACK SUB ASSY-LH LHD	TATA spare parts
319050003268	AC DUCT & HATRACK SUB ASSY-RH-LHD	TATA spare parts
319050003283	WINDOW EXTRUSION -LH 1	TATA spare parts
319050003284	WINDOW EXTRUSION -LH 2	TATA spare parts
319050003285	WINDOW EXTRUSION -LH 3	TATA spare parts
319050003286	WINDOW EXTRUSION -LH 4	TATA spare parts
319050003287	WINDOW EXTRUSION -LH 5	TATA spare parts
319050003288	WINDOW EXTRUSION -RH_1	TATA spare parts
319050003289	WINDOW EXTRUSION -RH_2	TATA spare parts

319050003290	WINDOW EXTRUSION -RH_3	TATA spare parts
319050003291	END PANEL ASSEMBLY BS6	TATA spare parts
319050003294	AC DUCT PANEL ASSY-LH BS6	TATA spare parts
319050003295	AC DUCT PANEL ASSY-RH FRONT BS6	TATA spare parts
319050003296	AC DUCT PANEL ASSY-RH REAR BS6	TATA spare parts
319050003308	ROOF EXTRUSION CUT-OUT LH & RH	TATA spare parts
319050003309	ROOF EXTRUSION CUT-OUT LH_2	TATA spare parts
319050003314	BUDGET LOCK - MANALEE	TATA spare parts
319050003325	ROOF EXTRUSION CUT-OUT RH FRONT	TATA spare parts
319050003326	ROOF EXTRUSION CUT-OUT RH REAR	TATA spare parts
319050003328	AC LOUVER-GRILL TYPE	TATA spare parts
319050003341	FABRIC DUCT ADAPTOR ASSY -LH BS6	TATA spare parts
319050003342	FABRIC DUCT ADAPTOR ASSY -RH BS6	TATA spare parts
319050003354	EV 9X9 - AITTR AC UNIT EAITS-05-S	TATA spare parts
319050003355	END PANEL ASSEMBLY BS6	TATA spare parts
319050003356	LOUVER CLOSED TYPE	TATA spare parts
319050003412	EV 9X9 CESL REAR AIR CURTAIN	TATA spare parts
319050003414	EV 9X9 CESL FRONT AIR CURTAIN	TATA spare parts
319050004001	HATRACK SUPPORT ASSY Y1	TATA spare parts
319050004011	HAT RACK SUPPORT ASSEMBLY	TATA spare parts
319050004031	AC DUCT PANEL ASSY REAR RH 9.6T 49WB	TATA spare parts
319050004032	AC DUCT PANEL ASSLY REAR LH 9.6T 49WB	TATA spare parts
319050004033	AC DUCT PANEL ASSLY MID RH 9.6T 49WB	TATA spare parts
319050004034	AC DUCT PANEL ASSY MID LH 9.6T 49WB	TATA spare parts
319050004035	AC DUCT PANEL ASSY FRONT RH 9.6T 49WB	TATA spare parts
319050004036	AC DUCT PANEL ASSLY FRONT LH 9.6T 49WB	TATA spare parts
319050004045	AC DUCT PANEL ASSY¿ RH 9.6T 49WB	TATA spare parts
319050004046	AC DUCT PANEL ASSY¿ LH 9.6T 49WB	TATA spare parts
319050083032	LUGGAGE SUPPORT PLATE TYPE 1	TATA spare parts
319050084028	Y1 GRILL HATRACK BRACKET REAR	TATA spare parts
319050084029	Y1 AC DUCT WITH HAT RACK BRACKET	TATA spare parts
319050084082	A/C SUPPORT PLATE	TATA spare parts
319050084084	END COVER SUPPORT BRACKET TYPE 1-BROWN	TATA spare parts
319050084099	SHEET METAL TRANSITION DUCT LH	TATA spare parts
319050084100	SHEET METAL TRANSITION DUCT RH	TATA spare parts
319050084127	AC DUCT L-ANGLE -GREY-TYPE-1	TATA spare parts
319050084129	AC DUCT PANEL -TYPE 1 -GREY	TATA spare parts
319050084132	SHEET METAL TRANSITION DUCT LH-EV01	TATA spare parts
319050084133	SHEET METAL TRANSITION DUCT RH-EV01	TATA spare parts
319050084145	AC DUCT PANEL- 1 -GREY TYPE	TATA spare parts
319050084146	AC DUCT PANEL -2 -GREY TYPE	TATA spare parts
319050084210	AC DUCT PANEL GREY L-380	TATA spare parts
319050084211	AC DUCT L-ANGLE GREY L-1150	TATA spare parts
319050084214	END COVER SUPPORT BRACKET	TATA spare parts
319050084234	FABRIC DUCT BAFFLE	TATA spare parts
319050184009	FRONT TR BOX PLATE.CC225	TATA spare parts
319050184010	REAR TR BOX PLATE CC225	TATA spare parts

319050184011	TR BOX RH COVER PLATE	TATA spare parts
319050184012	TR BOX LH COVER PLATE	TATA spare parts
319050184017	AC DUCT SHEET-1762 X 666 RH FRONT	TATA spare parts
319050184018	AC DUCT SHEET-2020X666 RH 2ND SHEET	TATA spare parts
319050184019	AC DUCT SHEET-2020X666 RH 3RD SHEET	TATA spare parts
319050184020	AC DUCT SHEET-2032X666 RH REAR SHEET	TATA spare parts
319050184021	AC DUCT SHEET-2032X666 LH REAR SHEET	TATA spare parts
319050184022	AC DUCT SHEET-2020X666 LH 3RD SHEET	TATA spare parts
319050184023	AC DUCT SHEET-2020X666 LH 2ND SHEET	TATA spare parts
319050184024	AC DUCT SHEET-1025X666 CO-DRIVER FRONT	TATA spare parts
319050184025	ACDUCTSHEET1500X666LH SIDE	TATA spare parts
319050184026	ACDUCTSHEET-265X676	TATA spare parts
319050184027	ACDUCTSHEET-2020X676(4200WB)	TATA spare parts
319050184028	ACDUCTSHEET-1920X676	TATA spare parts
319050184029	ACDUCTSHEET-2020X666.(6HOLES)	TATA spare parts
319050184030	ACDUCTSHEET-1920X676.(4HOLES)	TATA spare parts
319050184031	ACDUCTSHEET-2020X676(4200WB)	TATA spare parts
319050184033	AC DUCT SHEET 1774 X 666. (4 HOLES)	TATA spare parts
319050184034	AC DUCT SHEET 2020X666.W/O PVC LAMINATED	TATA spare parts
319050184035	AC DUCT SHEET 2020X666. (6 HOLES)	TATA spare parts
319050184036	RH SIDE AC DUCT SHEET 2020X666 52WB	TATA spare parts
319050184037	AC DUCT SHEET 2020X666 LH 52WB	TATA spare parts
319050184038	AC DUCT SHEET 2020X666.(6 HOLES) LH SIDE	TATA spare parts
319050184039	AC DUCT SHEET 2020X666 LH SIDE 2ND SHEET	TATA spare parts
319050184040	AC DUCT SHEET 1004X666 LH SIDE	TATA spare parts
319050184058	AC DUCT SHEET-1762 X 676 RH FRONT	TATA spare parts
319050184059	AC DUCT SHEET-2020X676 RH 2ND SHEET	TATA spare parts
319050184060	AC DUCT SHEET-2020X676 RH 3RD SHEET	TATA spare parts
319050184061	AC DUCT SHEET-2032X676 RH REAR SH	TATA spare parts
319050184062	AC DUCT SHEET 2032X676 LH REAR	TATA spare parts
319050184063	AC DUCT SHEET 2020X666 LH 3RD SHEET	TATA spare parts
319050184064	AC DUCT SHEET 2020X676 LH 2ND SHEET	TATA spare parts
319050184065	AC DUCT SHEET 1025X676 CO-DRIVER FR	TATA spare parts
319050184066	AC DUCT SHEET 2020X676 LH REAR SIDE	TATA spare parts
319050184067	AC DUCT SHEET 2020X676 LH 2ND REAR SIDE	TATA spare parts
319050184068	AC DUCT SHEET 1609X676 LH SIDE FRONT	TATA spare parts
319050184069	AC DUCT SHEET 2020X676 RH FRONT	TATA spare parts
319050184070	AC DUCT SHEET 1920X676 RH 2ND	TATA spare parts
319050184071	AC DUCT SHEET 2020X676 FRONT 3RD	TATA spare parts
319050184072	AC DUCT SHEET 348X676 RH REAR	TATA spare parts
319050184087	AC DUCT SHEET-1774 X 676. (4 HOLES)	TATA spare parts
319050184088	AC DUCT SHEET-2020X676. (6 HOLES)	TATA spare parts
319050184089	AC DUCT SHEET-2020X676. (4 HOLES)	TATA spare parts
319050184090	AC DUCT SHEET-2020X676	TATA spare parts
319050184091	AC DUCT SHEET-2020X676_LH REAR SHEET	TATA spare parts
319050184092	AC DUCT SHEET-2020X676. (4 HOLES)	TATA spare parts
319050184093	AC DUCT SHEET-2020X676_LH SIDE	TATA spare parts

319050184094	AC DUCT SHEET-1004X676_LH FRONT SHEET	TATA spare parts
319050184095	AC DUCT SHEET-2020X676_LH REAR	TATA spare parts
319050184096	AC DUCT SHEET-2020X676_LH REAR 2ND	TATA spare parts
319050184097	AC DUCT SHEET-2020X676_LH REAR 3RD	TATA spare parts
319050184098	AC DUCT SHEET-1004X676_LH FRONT	TATA spare parts
319050184099	AC DUCT SHEET-1774 X 676_RH FRONT	TATA spare parts
319050184100	AC DUCT SHEET-2020X676_RH 2ND	TATA spare parts
319050184101	AC DUCT SHEET-2020X676_RH 3RD	TATA spare parts
319050184102	AC DUCT SHEET-2020X676_RH REAR	TATA spare parts
319050184103	AC DUCT 1ST SHEET DRIVER SIDE EVO1	TATA spare parts
319050184104	AC DUCT 2ND SHEET DRIVER SIDE EVO 1	TATA spare parts
319050184105	AC DUCT 3RD SHEET DRIVER SIDE EVO 1	TATA spare parts
319050184106	AC DUCT LAST SHEET DRIVER SIDE EVO 1	TATA spare parts
319050184107	AC DUCT REAR SHEET CO-DRIVER SIDE EVO1	TATA spare parts
319050184108	AC DUCT 3RD SHEET CO-DRIVER SIDE EVO1	TATA spare parts
319050184109	AC DUCT 2ND SHEET CO-DRIVER SIDE EVO 1	TATA spare parts
319050184110	AC DUCT 1ST SHEET CO-DRIVER SIDE EVO 1	TATA spare parts
319050184111	AC DUCT SHEET-1509X676 LH FRONT	TATA spare parts
319050184112	ROOF TOP UNIT AC CC225 24V Y1 3 LTR	TATA spare parts
319050184113	AC DUCT SHEET-1509X676 LH FRONT	TATA spare parts
319050184114	AC DUCT SHEET-1720 X 676. (4 HOLES)	TATA spare parts
319050184115	AC DUCT SHEET-348 X 676. (2 HOLES)	TATA spare parts
319050184116	AC DUCT SHEET-1820X676 SKL 42WB	TATA spare parts
319050184117	AC DUCT SHEET-2020X676 42WB SKL	TATA spare parts
319050184119	RH FRONT AC DUCT SHEET-1920X676(4 HOLES)	TATA spare parts
319050184120	RH 2ND AC DUCT SHEET-2020X676(6 HOLES)	TATA spare parts
319050184121	RH 3RD AC DUCT SHEET-2020X676(6 HOLES)	TATA spare parts
319050184122	RH REAR_AC DUCT SHEET-1676X676	TATA spare parts
319050184123	AC DUCT SHEET-956X676 LH REAR	TATA spare parts
319050184124	AC DUCT SHEET-2020X676(6 HOLES)_2ND REAR	TATA spare parts
319050184125	AC DUCT SHEET-2020X676_2ND FRONT SHEET	TATA spare parts
319050184126	AC DUCT SHEET-1870X676_LH FRONT SHEET	TATA spare parts
319050184127	AC DUCT SHEET-1920 X 676(4 HOLES)	TATA spare parts
319050184128	AC DUCT SHEET-2020X676.(6 HOLES)	TATA spare parts
319050184129	AC DUCT SHEET-2020X676.(4 HOLES)	TATA spare parts
319050184130	AC DUCT SHEET-1676X676	TATA spare parts
319050184131	AC DUCT SHEET-2020X676. (6 HOLES)	TATA spare parts
319050184132	AC DUCT SHEET-2020X676	TATA spare parts
319050184133	AC DUCT SHEET-1870X676	TATA spare parts
319050184274	AC DUCT PANEL-LH_1	TATA spare parts
319050184275	AC DUCT PANEL-LH_2	TATA spare parts
319050184276	AC DUCT PANEL-LH_3	TATA spare parts
319050184277	AC DUCT PANEL-LH_4	TATA spare parts
319050184278	AC DUCT PANEL-RH_1	TATA spare parts
319050184279	AC DUCT PANEL-RH REAR 1	TATA spare parts
319050184280	AC DUCT PANEL-RH REAR 2	TATA spare parts
319050184283	END PANEL	TATA spare parts

319050184303	END PANEL	TATA spare parts
319050214009	ROOF ALUMINIUM PROFILE_EV 9X9	TATA spare parts
319050263005	ULTRA-EX HOSE COVER	TATA spare parts
319050263015	Y1-2550 TRANSITION DUCT_RH	TATA spare parts
319050263016	Y1-2550 TRANSITION DUCT_LH	TATA spare parts
319050263017	Y1-2550 TRANSITION DUCT_RH_7040	TATA spare parts
319050263018	Y1-2550 TRANSITION DUCT_LH_7040	TATA spare parts
319050264005	AC DUCT END CAP-LH	TATA spare parts
319050264006	AC DUCT END CAP-RH	TATA spare parts
319050303001	AIR DIFFUSER FINISH	TATA spare parts
319050303002	AC LOUVER	TATA spare parts
319050303005	AIR DIFFUSER FINISH	TATA spare parts
319050303006	AC LOUVER	TATA spare parts
319050303007	AIR DIFFUSER FINISHING_RAL 7040 BS6	TATA spare parts
319050303010	VENTILATION PLASTIC GRILL_RAL8024	TATA spare parts
319050303022	AC LOUER RAL 7044	TATA spare parts
319050304018	RECTANGULAR FREE LOUVER	TATA spare parts
319050323003	DUCT FINISHING ABS COVER	TATA spare parts
319050324018	AC DUCT BASE PANEL ABS BLANK	TATA spare parts
319050324019	AC DUCT SERVICE SET	TATA spare parts
319050324022	HAT RACK END COVER-RAL 8024	TATA spare parts
319050324052	FRONT INNER DUCT COVER 1_EV 9X9	TATA spare parts
319050324053	FRONT INNER DUCT COVER 2_EV 9X9	TATA spare parts
319050324056	AC DUCT PANEL MID LH 1_EV 9X9	TATA spare parts
319050324057	AC DUCT PANEL MID LH 2_EV 9X9	TATA spare parts
319050324062	AC DUCT END CAP_EV 9X9	TATA spare parts
319050324063	AC DUCT PANEL_EV 9X9	TATA spare parts
319050324064	AC DUCT PANEL_EV 9X9	TATA spare parts
319050324065	AC DUCT PANEL_EV 9X9	TATA spare parts
319050324066	AC DUCT PANEL_EV 9X9	TATA spare parts
319050324067	AC DUCT PANEL_EV 9X9	TATA spare parts
319050324068	AC DUCT PANEL_EV 9X9	TATA spare parts
319050324069	AC DUCT PANEL_EV 9X9	TATA spare parts
319050324070	AC DUCT PANEL_EV 9X9	TATA spare parts
319050324071	AC DUCT PANEL_EV 9X9	TATA spare parts
319050324072	AC DUCT PANEL_EV 9X9	TATA spare parts
319050324073	AC DUCT PANEL_EV 9X9	TATA spare parts
319050324074	AC DUCT PANEL_EV 9X9	TATA spare parts
319050324075	AC DUCT PANEL_EV 9X9	TATA spare parts
319050324076	AC DUCT PANEL_EV 9X9	TATA spare parts
319050962003	AC CC225 24V (ONLY ROOF TOP UNIT)	TATA spare parts
319050962012	REFRIGERANT HOSES_Y1-37WB	TATA spare parts
319050962013	REFGN HOSES-7.7MTR_CC-225_Y1_3L-52WB	TATA spare parts
319050962018	ROOF TOP UNIT AC CC225 24V Y1 3 LTR	TATA spare parts
319050962020	AC UNIT-260 E	TATA spare parts
319050962021	SPHEROS AC CC-225 24V-HVAC UNIT	TATA spare parts
319050963003	LEFT SIDE EVAPORATOR COIL ASSY EV	TATA spare parts

319050963004	RIGHT SIDE EVAPORATOR COIL ASSY EV	TATA spare parts
319050963005	CONDENSER COILS ASSY(4FAN) EV	TATA spare parts
319050963006	CONDENSER FAN WIRING	TATA spare parts
319050963007	INVERTER AND COMPRESSOR	TATA spare parts
319050963008	CONTROL PANEL WIRE	TATA spare parts
319050963009	CONTROL PANEL TRANSIT WIRE	TATA spare parts
319050963012	HVAC UNIT EV 9X9 J&K (PTC HEATER)	TATA spare parts
319050964001	EVAP BLOWER 24VWG-14081-00 (BLDC)	TATA spare parts
319050964002	CONDENSER FAN 24VWG-14035-00(BLDC)	TATA spare parts
319050964003	SC 600 DASH CONTROL(11117118A)	TATA spare parts
319050964005	MCCOY SOUDAL 250XF (600 ML)	TATA spare parts
319050964006	COT B-13	TATA spare parts
319050964007	RELAY 24V 35AMP	TATA spare parts
319050964008	C.V. BODY HEX 13 MM WITH VALVE	TATA spare parts
319050964009	ROUND THIMBLE 25X8MM	TATA spare parts
319050964010	COUPLER 1 POLE MALE FEMALE	TATA spare parts
319050964011	BATTERY WIRE(25SQ-MM BLACK COLOR)	TATA spare parts
319050964012	HOSE CLAMP 1 INCH ( SS)	TATA spare parts
319050964013	HEX BOLT 10X50 SS 304 GR-A2 80	TATA spare parts
319050964014	ALLEN BOLT M10X1.25X50MM MS(10.9)	TATA spare parts
319050964015	ALLEN BOLT M8X1.25X45 MS (10.9)	TATA spare parts
319050964016	RUBBER LONG PROFILE (PATTI)	TATA spare parts
319050964017	FOAM PU+FILM 960X90X15MM CC-200	TATA spare parts
319050964018	FAST NUT M8	TATA spare parts
319050964019	HOSE CLAMP 4 1/2INCH _4X	TATA spare parts
319050964020	RD SUB-COOLING TUBING INLET CC225	TATA spare parts
319050964021	COND-RECEIVER TUBING OUTLET-CC225	TATA spare parts
319050964049	AC CONTROL PANEL EV	TATA spare parts
319050964050	SENSOR (R25?=5K??3270) EV	TATA spare parts
319050964051	DRIER EV	TATA spare parts
319050964052	DC-DC POWER DC350?800V/ DC24V?3KW EV	TATA spare parts
319050964053	FREQUENCY CONVERTOR VFD-110E43A EV	TATA spare parts
319050964054	EVAPORATOR BLOWER EV	TATA spare parts
319050964055	CONDENSER FAN EV	TATA spare parts
319050964056	RADIATOR FAN EV	TATA spare parts
319050964057	HERMETIC SCROLL SANYO C-SWS225H01A-220V	TATA spare parts
319050964058	LOW PRESSURE SWITCH EV	TATA spare parts
319050964059	HIGH PRESSURE SWITCH EV	TATA spare parts
319050964060	CAN MODULE-BUS OVERHEAD MODULE EV	TATA spare parts
319050964061	DEFORST SENSOR (R25?=5K??3270) EV	TATA spare parts
319050964062	TEMPERATURE SENSOR (RETURN AIR) EV	TATA spare parts
319050964063	TKT-260E ONE-WAY VALVE	TATA spare parts
319050964064	COMPRESSOR EXHAUST ADAPTER PIPE	TATA spare parts
319050964065	COMPRESSOR RETURN AIR PIPE	TATA spare parts
319050964066	EVAPORATOR RETURN AIR ADAPT PIPE (3A21)	TATA spare parts
319050964067	EVAPORATOR LIQUID DISTRIBUTE ADPT PIPE	TATA spare parts
319050964068	PZF-GZQ ADAPTER PIPE	TATA spare parts

319050964069	ELECTRIC CONTROL BOX STEEL PLATE	TATA spare parts
319050964070	EVAPORATOR COIL AIR FILTER	TATA spare parts
319050964071	EVAPORATOR COIL LIQUID FILTER	TATA spare parts
319050964072	A/C BASEMENT	TATA spare parts
319050964073	FAN STEEL PLATE (4FAN)	TATA spare parts
319050964074	EXTERNAL BALANCE PIPE	TATA spare parts
319050964075	EXPANSION VALVE	TATA spare parts
319050964077	GAS-LIQUID SEPARATOR	TATA spare parts
319050964078	SIGHT GLASS	TATA spare parts
319050964079	FRAME	TATA spare parts
319050964080	PRESSURE RELEASE VALVE	TATA spare parts
319050964083	EXHAUST FAN	TATA spare parts
319050964085	ELECTRIC CONTROL BOX	TATA spare parts
319050964088	DEFROST SENSOR	TATA spare parts
319050964089	ELECTRIC CONTROL PART VALVE	TATA spare parts
319050964091	DC/DC POWER	TATA spare parts
319050964092	FRESH AIR UNIT	TATA spare parts
319050964093	TERMINAL STRIP	TATA spare parts
319050964094	DC CONTACTOR	TATA spare parts
319050964095	RETURN AIR GRILL	TATA spare parts
319050964096	CONDENSER FAN COVER	TATA spare parts
319050964097	A/C COVER	TATA spare parts
319050964100	RETURN AIR GRILL FILTER	TATA spare parts
319050964101	REFRIGERANT 407C	TATA spare parts
319050964102	REFRIGERANT OIL (PEG OIL)	TATA spare parts
319050964103	CAN MODULE	TATA spare parts
319051003002	GRAB RAIL ASSEMBLY	TATA spare parts
319051003003	SUPPORT TUBE CO DRIVER SIDE	TATA spare parts
319051003004	SUPPORT TUBE CO DRIVER SIDE_LN 158	TATA spare parts
319051003005	DRIVER PARTITION FOR STD WITH GLASS	TATA spare parts
319051003006	DR PARTITION FOR STD WITH NEW WL HOUSING	TATA spare parts
319051003007	CO DR PARTITION TUBE ASSY_NEW WL HSNNG	TATA spare parts
319051003011	HANDHOLD TUBE WITH SLEEVE	TATA spare parts
319051003016	BEND TUBE FOR DRIVER PARTITION	TATA spare parts
319051003017	HAND HOLD TUBE WITH SLEEVE LN900	TATA spare parts
319051003018	HANDHOLD TUBE ASSY WITH SLEEVE LN520	TATA spare parts
319051003020	HANDHOLD TUBE WITH SLEEVE_DELUXE	TATA spare parts
319051003021	HANDHOLD STRAP OF BLACK COLOR	TATA spare parts
319051003026	HANDHOLD TUBE WITH SLEEVE	TATA spare parts
319051003027	CO DRIVER PARTITION ASSY_STOP SWITCH	TATA spare parts
319051003028	REAR DOOR PARTITION_STOP SWITCH	TATA spare parts
319051003029	HAND HOLD TUBE WITH SLEEVE_LN790	TATA spare parts
319051003030	HAND HOLD ASSY WITH SLEEVE_LN1850	TATA spare parts
319051003031	REAR PARTITION ASSY_DOUBLE DOOR	TATA spare parts
319051003032	CO-DRIVER PARTITION ASSY	TATA spare parts
319051003034	HANDHOLD TUBE WITH SLEEVE LN-6823	TATA spare parts
319051003063	PASSENGER PARTITION ASSEMBLY	TATA spare parts

319051003085	DRIVER PARTITION WALL ASSEMBLY	TATA spare parts
319051003086	STEP WELL PARTITION WALL ASSY	TATA spare parts
319051003087	STEP WELL PARTITION WALL ASSY	TATA spare parts
319051003094	HAND HOLD TUBE WITH SLEEVE L-4142	TATA spare parts
319051003100	HANDHOLD TUBE WITH SLEEVE LN 5690	TATA spare parts
319051003116	PASSENGER DOOR PARTITION ASSY	TATA spare parts
319051003119	DRIVER PARTITION FOR STD_AC BUS	TATA spare parts
319051003120	HANDHOLD TUBE ASSY WITH SLEEVE LN470	TATA spare parts
319051003125	DRIVER PARTITION WALL ASSEMBLY MIDI AC	TATA spare parts
319051003128	DRIVER PARTITION	TATA spare parts
319051003134	HAND HOLD TUBE WITH SLEEVE L-2064	TATA spare parts
319051003139	STEP WELL PARTITION WALL ASSY	TATA spare parts
319051003140	DRIVER PARTITION WALL ASSEMBLY	TATA spare parts
319051003142	MIDDLE DOOR PARTITION ASSEMBLY	TATA spare parts
319051003145	DRIVER PARTITION WALL ASSY	TATA spare parts
319051003149	EX DRIVER PARTITION TUBE ASSY STOP SWITC	TATA spare parts
319051003151	STEP WELL PARTITION ASSY 860 MM	TATA spare parts
319051003153	DRIVER PARTITION	TATA spare parts
319051003154	CO DRIVER PARTITION TUBE ASSY	TATA spare parts
319051003161	CO-DRIVER PARTITION ASSEMBLY	TATA spare parts
319051003162	DRIVER PARTITION ASSEMBLY (GREY)	TATA spare parts
319051003163	SUPPORT TUBE CO-DRIVER SIDE GREY	TATA spare parts
319051003164	EXT DRIVER PARTITION GREY COLOR	TATA spare parts
319051003167	REAR PARTITION ASSY_ DOUBLE DOOR	TATA spare parts
319051003176	DRIVER PARTITION FOR STD_GRAY_NAC	TATA spare parts
319051003188	DRIVER PARTITION WALL ASSY_PMPML	TATA spare parts
319051003190	STEP WELL PARTITION WALL ASSY_PMPML	TATA spare parts
319051003194	STEP WELL PARTITION WALL ASSY_NEPAL	TATA spare parts
319051003197	HANDHOLD TUBE WITH SLEEVE	TATA spare parts
319051003243	HAND RAIL 1	TATA spare parts
319051003244	HAND RAIL 1	TATA spare parts
319051003245	HAPPIZ PARTS	TATA spare parts
319051003246	BRACKET	TATA spare parts
319051003249	BRACKET ASSY	TATA spare parts
319051003250	CONNECT PLATE WITH 2 STUDS	TATA spare parts
319051003253	SPLIT T BRACKET 3 WAY 32X32 ASSY	TATA spare parts
319051003254	BASE BRACKET DIA 32	TATA spare parts
319051003266	STEP PARTITION EV	TATA spare parts
319051003267	DRIVER PARTITION WALL ASSEMBLY	TATA spare parts
319051003268	DRIVER PARTITION EV	TATA spare parts
319051003269	MODULER DRIVER PARTATION ASSLY	TATA spare parts
319051003270	STEP MODULER PARTITION ASSLY	TATA spare parts
319051003275	DRIVER PARTITION WALL ASSEMBLY_EV	TATA spare parts
319051003277	STEP PARTITION_EV	TATA spare parts
319051003344	WHEEL CHAIR SUPPORT PARTITION WALL ASSY	TATA spare parts
319051003352	STANCHION TUBE DIA. 40X 3_1918LEN SLEEVE	TATA spare parts
319051003353	STEP WHEEL PARTITION WALL ASSY_1 BS6	TATA spare parts



319051003356	DRIVER PARTITION ASSY BS6	TATA spare parts
319051003359	STEP WALL PARTITION ASSY BS6	TATA spare parts
319051003374	STANCHION TUBE DIA. 40X 3_1922LEN SLEEVE	TATA spare parts
319051003375	STEP WHEEL PARTITION WALL ASSY_1 EV	TATA spare parts
319051003376	STANCHION TUBE DIA. 40X 3_1922LEN SLEEVE	TATA spare parts
319051003377	DIA. 32-HANDHOLD TUBE ASSY-723 EV	TATA spare parts
319051003378	DIA. 32-HANDHOLD TUBE ASSY-445 EV	TATA spare parts
319051003381	PASS. STEP PARTITION WALL ASSY	TATA spare parts
319051003382	DRIVER PARTITION WALL ASSY EV	TATA spare parts
319051003394	ROOF GRAB RAIL_3275	TATA spare parts
319051003395	GRAB RAIL BEND TUBE_ENDRESS	TATA spare parts
319051003398	ADVERTISMENT HANDLE	TATA spare parts
319051003401	LH HANDHOLD ASSY BS6	TATA spare parts
319051003402	STANCHION TUBE ASSY	TATA spare parts
319051003403	DRIVER PARTITION HANDHOLD ARRANGEMENT B	TATA spare parts
319051004001	HAND HOLD TUBE WITH SLEEVE	TATA spare parts
319051004002	HAND HOLD TUBE WITH SLEEVE	TATA spare parts
319051004003	HAND HOLD TUBE WITH SLEEVE LN1765	TATA spare parts
319051004004	HAND HOLD TUBE WITH SLEEVE KADAMBA 1	TATA spare parts
319051004012	HAND HOLD TUBE WITH SLEEVE	TATA spare parts
319051004039	HAND HOLD TUBE WITH SLEEVE 1940	TATA spare parts
319051004040	HAND HOLD TUBE WITH SLEEVE 770	TATA spare parts
319051004057	HAND HOLD TUBE WITH SLEEVE-L-1616	TATA spare parts
319051004058	HAND HOLD TUBE WITH SLEEVE-L-1745	TATA spare parts
319051004062	HAND HOLD TUBE WITH SLEEVE-L-1922	TATA spare parts
319051004064	HAND HOLD TUBE WITH SLEEVE	TATA spare parts
319051004065	HAND HOLD TUBE WITH SLEEVE	TATA spare parts
319051004066	HAND HOLD TUBE WITH SLEEVE	TATA spare parts
319051004067	HAND HOLD TUBE WITH SLEEVE 1482	TATA spare parts
319051004068	HAND HOLD TUBE WITH SLEEVE	TATA spare parts
319051004077	HAND HOLD TUBE WITH SLEEVE	TATA spare parts
319051004078	HAND HOLD TUBE WITH SLEEVE	TATA spare parts
319051004079	HAND HOLD TUBE WITH SLEEVE	TATA spare parts
319051004080	HAND HOLD TUBE WITH GREY SLEEVE	TATA spare parts
319051004081	HAND HOLD TUBE WITH GREY COLOR SLEEVE	TATA spare parts
319051004086	HAND HOLD TUBE WITH GRAY SLEEVE	TATA spare parts
319051004087	HAND HOLD TUBE WITH SLEEVE	TATA spare parts
319051004096	HANDHOLD TUBE ASSY_1765	TATA spare parts
319051004097	HANDHOLD TUBE ASSY_1518	TATA spare parts
319051004098	HANDHOLD TUBE ASSY_545	TATA spare parts
319051004099	HANDHOLD TUBE ASSY_536	TATA spare parts
319051004100	HANDHOLD TUBE ASSY_464	TATA spare parts
319051004107	HANDHOLD TUBE ASSY_1923	TATA spare parts
319051004112	HANDHOLD TUBE ASSY	TATA spare parts
319051004113	HANDHOLD TUBE ASSY	TATA spare parts
319051004114	HANDHOLD TUBE ASSY (7046)	TATA spare parts
319051004115	HANDHOLD TUBE ASSY_1927	TATA spare parts

319051004116	HANDHOLD TUBE ASSY_700	TATA spare parts
319051004135	HAND HOLD TUBE WITH SLEEVE	TATA spare parts
319051004146	TUBE ASSY	TATA spare parts
319051004154	HAND HOLD TUBE WITH 1765MM(GREEN)	TATA spare parts
319051004182	HAND HOLD TUBE WITH SLEEVE	TATA spare parts
319051004191	WHEEL CHAIR SUPPORT PARTITION STRUCTURE	TATA spare parts
319051004201	DIA. 32-HANDHOLD TUBE ASSY-628	TATA spare parts
319051004202	DIA. 32-HANDHOLD TUBE ASSY-358	TATA spare parts
319051004207	STANCHION TUBE DIA. 40X3_1764LEN SLEEVE	TATA spare parts
319051004208	DIA. 32-HANDHOLD TUBE ASSY-614	TATA spare parts
319051004209	DIA. 32-HANDHOLD TUBE ASSY-628	TATA spare parts
319051004210	DIA. 32-HANDHOLD TUBE ASSY-595	TATA spare parts
319051004221	PASS. STANCHION TUBE DIA. 40X 3_1200LEN	TATA spare parts
319051004222	DIA. 32-HANDHOLD TUBE ASSY-182	TATA spare parts
319051004223	STANCHION TUBE DIA. 40X 3_1768LEN SLEEVE	TATA spare parts
319051004224	DIA. 32-HANDHOLD TUBE ASSY-658 EV	TATA spare parts
319051004226	DIA. 32-HANDHOLD TUBE ASSY-662 EV	TATA spare parts
319051004229	40 DIA STANCHION PIPE SUB ASSY 9X9	TATA spare parts
319051004230	32 DIA HANDHOLD SUBASSY	TATA spare parts
319051004231	32 DIA PARTITION SUPPORTIVE TUBE	TATA spare parts
319051004232	DRIVER PARTITION STANCHION TUBE	TATA spare parts
319051004233	DRIVER PARTITION SUPPORTIVE TUBE	TATA spare parts
319051004234	DRIVER PARTITION SUPPORTIVE TUBE_1	TATA spare parts
319051005001	ASSY. FOR BENT STANCHION PIPE	TATA spare parts
319051063002	HAND HOLD TUBE ASSY	TATA spare parts
319051063003	HAND HOLD TUBE ASSY	TATA spare parts
319051063004	BENT STANCHION PIPE 1952	TATA spare parts
319051063010	DRIVER PARTITION	TATA spare parts
319051063011	HAND HOLD TUBE ASSY Y1_ENG HOOD	TATA spare parts
319051063015	HAND HOLD TUBE ASSY Y1_ENG HOOD(YELLOW)	TATA spare parts
319051063018	GRAB RAIL TUBE	TATA spare parts
319051063023	PARTITION STANCHION PIPE	TATA spare parts
319051063024	PARTITION STANCHION PIPE 02	TATA spare parts
319051063029	Y1 LHD HAND HOLD ASSY ENG HOOD(GREY)	TATA spare parts
319051064003	SUPPORT TUBE WITHOUT SLEEVE	TATA spare parts
319051064004	SUPPORT TUBE CO DRIVER SIDE_LN 158	TATA spare parts
319051064005	CO DRIVER PARTITION TUBE WITHOUT SLEEVE	TATA spare parts
319051064075	STEPWELL PARTITION TUBE 800MM	TATA spare parts
319051064135	STEP PARTITION TUBE	TATA spare parts
319051064136	DRIVER PARTITION TUBE	TATA spare parts
319051064137	STEP PARTITION TUBE	TATA spare parts
319051064147	STEP PARTITION TUBE	TATA spare parts
319051064151	HANDHOLD TUBE _1765	TATA spare parts
319051064152	HANDHOLD TUBE _1927	TATA spare parts
319051065001	HAND HOLD TUBE 1.93M	TATA spare parts
319051065002	HAND HOLD TUBE	TATA spare parts
319051065003	HAND HOLD TUBE WITHOUT SLEEVE LN 1765	TATA spare parts

319051214001	ALUMINIUM PROFILE FOR DRIVER PARTITION	TATA spare parts
319051214002	ALUMINIUM PROFILE FOR STEPWELL PARTITION	TATA spare parts
319051214010	ALUMINIUM PROFILE FOR PARTITION 695	TATA spare parts
319051214012	ALUMINIUM PROFILE FOR PARTITION	TATA spare parts
319051214013	ALUMINIUM PROFILE FOR PARTITION	TATA spare parts
319051214017	AL PROFILE FOR DRIVER PARTITION_GREY	TATA spare parts
319051214025	ALUMINIUM PROFILE FOR DRI PARTITION_630L	TATA spare parts
319051234001	DRIVER PARTITION GLASS	TATA spare parts
319051234009	WALL GLASS FOR PARTITION	TATA spare parts
319051234010	WALL GLASS FOR PARTITION	TATA spare parts
319051244001	WHITE PARTITION BOARD.	TATA spare parts
319051304002	PARTITION WALL ACRYLIC	TATA spare parts
319051313001	32MM PIPE ROOF SOCKET(CLOSED-GREY)	TATA spare parts
319051313004	32MM PIPE ROOF SOCKET AT JOINERY(OPEN)	TATA spare parts
319051393004	GRAB RAIL PIPE 5500	TATA spare parts
319051393005	GRAB RAIL PIPE 1000	TATA spare parts
319051912012	HANDHOLD ASSEMBLY_LUXURY_52WB	TATA spare parts
319052003001	REAR INTERNAL ASSY-Y1	TATA spare parts
319052003003	FRONT INTERNAL ABOVE DRIVER ASSY-Y1	TATA spare parts
319052003004	FRP ENGINE HOOD ASSEMBLY-Y1	TATA spare parts
319052003005	DASH BOARD WITH FLAP ASSEMBLY-Y1	TATA spare parts
319052003006	INSTRUMENT CLUSTER ASSEMBLY-Y1	TATA spare parts
319052003007	PANEL PLATE ASSEMBLY_RH	TATA spare parts
319052003008	PANEL PLATE ASSEMBLY_RH	TATA spare parts
319052003009	CLUTCH OIL TANK CLOSING COVER ASSY.	TATA spare parts
319052003010	INSULATION CLAMPING BOTTOM PLATE ASSY	TATA spare parts
319052003012	DASH BOARD WITH FLAP ASSY Y1	TATA spare parts
319052003013	REAR INTERNAL ASSY Y1	TATA spare parts
319052003020	FRP FRONT INTERNAL SUB ASSEMBLY	TATA spare parts
319052003021	DASH BOARD WITH FLAP ASSEMBLY	TATA spare parts
319052003023	ENGINE HOOD INSULATION SUB ASSY	TATA spare parts
319052003036	ENGINE HOOD INSULATION SUB ASSY	TATA spare parts
319052003043	FRONT INTERNAL SUB ASSEMBLY	TATA spare parts
319052003044	FRONT INTERNAL SUB ASSY	TATA spare parts
319052003045	REAR INTERNAL ASSY	TATA spare parts
319052003048	INSTRUMENT CLUSTER SUB ASSY	TATA spare parts
319052003051	FRONT INTERNAL ASSEMBLY-2550	TATA spare parts
319052003052	FRP REAR INNER ASSY	TATA spare parts
319052003069	FRONT INTERNAL SUB ASSEMBLY_12V	TATA spare parts
319052003077	Y1 LPO REAR INTERNAL ASSYRW	TATA spare parts
319052003079	FRP FRONT INNER	TATA spare parts
319052003084	FRONT INTERNAL SUB ASSEMBLY AC -RAL 7040	TATA spare parts
319052003086	FRONT INTERNAL SUB ASSEMBLY DETAIL	TATA spare parts
319052003088	DASHBOARD Y1 COMMON ADD ON ASSY-2340	TATA spare parts
319052003089	ENGINE HOOD EXT & INT ASSY	TATA spare parts
319052003091	COVER ASSY	TATA spare parts
319052003094	Y1-COMMON DASHBOARD ADD ON ASSY-2550BV	TATA spare parts

319052003095	Y1-COMMON DASHBOARD & ENGINEHOOD ASSY	TATA spare parts
319052003096	DASHBOARD & ENGINE HOOD ASSY	TATA spare parts
319052003100	ABS REAR INTERNAL ASSY	TATA spare parts
319052003101	ABS FRONT INTERNAL ABOVE DRIVER ASSY	TATA spare parts
319052003110	Y1 LPO REAR INTERNAL ASSY-RW (EVO-01)	TATA spare parts
319052003111	FRP FRONT INTERNAL SUB ASSEMBLY	TATA spare parts
319052003112	AC FRONT INNER SUB ASSEMBLY RAL 9001	TATA spare parts
319052003113	AC FRONT INNER SUB ASSEMBLY RAL 7040	TATA spare parts
319052003118	Y1 REAR INNER ASSY-RW WIT RLB (RAL-9001)	TATA spare parts
319052003123	FRONT INTERNAL ASSEMBLY-Y1 EVO1	TATA spare parts
319052003124	Y1 ENGINEHOOD ASSY WITH CHAIN	TATA spare parts
319052003125	Y1- DASHBORD & ENGINHOOD ASSY WIT CHAIN	TATA spare parts
319052003126	FRONT INTERNAL ASSEMBLY	TATA spare parts
319052003128	Y1 COMMON DASHBOARD ASSY(MANNUAL DES	TATA spare parts
319052003129	Y1 REAR INNER ASSY-RW WIT RLB (RAL-9001)	TATA spare parts
319052003130	Y1 REAR INNER ASSY-RW WIT RLB (EVO-01)	TATA spare parts
319052003142	ABS FRONT INTERNAL SUB ASSEMBLY	TATA spare parts
319052003144	Y1 AC FRONT INNER_DESTINATION(EVO-01)	TATA spare parts
319052003145	Y1 AC FRONT INNER ASSY(BASRUR 9001)	TATA spare parts
319052003146	Y1 (9X9) EV-DASHBOARD & FLAP ASSY	TATA spare parts
319052003147	Y1-EV_TOP SERVICE FLAP ASSY EV	TATA spare parts
319052003148	Y1 497 DASHBOARD ADD ON ASSY	TATA spare parts
319052003149	Y1 DASHBOARD TOP FLAP ASSY	TATA spare parts
319052003150	Y1 497 DASHBOARD & ENGINEHOOD ASSY	TATA spare parts
319052003151	Y1 (9X9) EV-DASHBOARD CLAMP ASSY	TATA spare parts
319052003153	FRP REAR INNER ASSY- HIRA	TATA spare parts
319052003155	Y1 LHD DASHBOARD & ENGINHOOD ASSY	TATA spare parts
319052003156	Y1 LHD DASHBOARD TOP FLAP ASSY	TATA spare parts
319052003157	Y1 LHD ENGINEHOOD INT & EXT ASSY	TATA spare parts
319052003160	Y1-EV FRONT INNER ASSEMBLY	TATA spare parts
319052003161	Y1 LHD FRONT INNER ASSY WITH AC-RAL7040	TATA spare parts
319052003163	Y1 AC FRONT INNER ASSY(BASRUR_7040)	TATA spare parts
319052003167	Y1 COMMOM DASHBOARD WITH DVD BOX	TATA spare parts
319052003169	Y1 COMMON DASHBOARD ADD ON ASSY(BLACK	TATA spare parts
319052003170	Y1-COMMON DASHBOARD & ENGINEHOOD ASSY	TATA spare parts
319052003172	LPO Y1 MANUAL GSL COVER ASSY (BLACK)	TATA spare parts
319052003178	Y1 LPO REAR INTERNAL ASSY-RW (EVO-01)	TATA spare parts
319052003189	Y1-EV_FRONT INNER ASSBLY_NON AC	TATA spare parts
319052003192	Y1 2550 DASHBOARD ADD ON ASSY_497	TATA spare parts
319052003193	Y1-2550 DASHBOARD & ENGINEHOOD ASSY_497	TATA spare parts
319052003195	Y1 GSL COVER ASSY_497	TATA spare parts
319052003196	Y1 AC FRONT INNER ASSY_AIS153	TATA spare parts
319052003197	Y1-2550 FRONT INNER ASSY_AIS153	TATA spare parts
319052003199	ABS FRONT INTERNAL ASSEMBLY BS6	TATA spare parts
319052003202	Y1 LHD FRONT INNER ASSY	TATA spare parts
319052003219	Y1_(9X9)_BRTS_EV-DASHBOARD & FLAP ASSY E	TATA spare parts
319052003220	Y1 9X9__EV_AJL_BRTS_FRONT INNER ASBLY E	TATA spare parts

319052003229	Y1-EV_FRONT DOOR COVER ASSY	TATA spare parts
319052003231	FRP LHD_FRONT INNER ASSY_EVO-01	TATA spare parts
319052003232	Y1 9X9__EV_AJL_FAME 2-FRONT INNER ASBLY	TATA spare parts
319052003241	DASHBOARD & FLAP ASSY_GEN5 9X9	TATA spare parts
319052004001	FRONT INTERNAL FUSE BOX FLAP	TATA spare parts
319052004002	FAST COUPLING	TATA spare parts
319052004003	FLAP DASH BOARD FLAP ASSEMBLY-Y1	TATA spare parts
319052004004	GEAR SHIFT LEVER FINISHING ASSY-Y1	TATA spare parts
319052004005	INSTRUMENT CLUSTER PANEL SUB ASSY	TATA spare parts
319052004006	FRONT INTERNAL FLAP SUB ASSY	TATA spare parts
319052004008	EXTERNAL & INTERNAL ENGINE HOOD ASSY	TATA spare parts
319052004009	EXTERNAL & INTERNAL ENGINE HOOD ASSY	TATA spare parts
319052004016	FRONT INTRNL FUSE BOX FLP ASSY-Y1 EVO 1	TATA spare parts
319052004018	FUSE BOX FLAP SUB ASSEMBLY	TATA spare parts
319052004019	FRONT INTERNAL FUSE BOX FLAP SUB ASSY	TATA spare parts
319052004025	FT INNER GLOVE BOX FLAP ASSY(CEN)-2550	TATA spare parts
319052004031	FRONT INTERNAL FUSE BOX FLAP SUB ASSY	TATA spare parts
319052004034	Y1-DIESEL FUSE BOX FLAP ASSY-2340 BW	TATA spare parts
319052004048	Y1 (9X9) EV-FUSE BOX FLAP CLAMP ASSY	TATA spare parts
319052004049	Y1_(9X9)_EV-AUX INVT FLAP CLAMP ASSY EV	TATA spare parts
319052004050	Y1_(9X9)_EV-ABS SERVICE FLAP CLAMP ASSY	TATA spare parts
319052004056	Y1 LHD DASHBOARD ADD ON ASSY	TATA spare parts
319052004073	Y1_BRTS_EV-FUSE BOX FLAP CLAMP ASSY EV	TATA spare parts
319052005003	DASHBOARD LPO Y1 NEW 2340 BW	TATA spare parts
319052083001	PANEL PLATE_Y1_LH	TATA spare parts
319052083003	INSULATION CLAMPING TOP PLATE	TATA spare parts
319052083013	CONTROL BRACKET UNIT FOR FDAS	TATA spare parts
319052084033	Y1_(9X9)_BRTS_EV_DOOR COVER PLATE BS6	TATA spare parts
319052183001	AL CHEQUERED PLATE ON FRP PASSENGER STEP	TATA spare parts
319052183002	AL CHEQD PLATE ON FRP PASR FIRST STEP	TATA spare parts
319052263001	A PILLAR-LH	TATA spare parts
319052263002	A PILLAR-RH	TATA spare parts
319052263003	FRP PASSENGER STEP-Y1	TATA spare parts
319052263011	A PILLAR LH	TATA spare parts
319052263021	Y1 FRP A-PILLAR FIN-LH (RUBBER W/S)	TATA spare parts
319052263022	Y1 FRP A-PILLAR FIN-RH (RUBBER W/S)	TATA spare parts
319052263023	FRP A PILLAR-LH_Y1	TATA spare parts
319052263024	CLUSTER FRP	TATA spare parts
319052263025	CLUSTER COVER FRP LPO Y1 NEW NON MUL	TATA spare parts
319052263026	MULT CLUSTER COVER FRP	TATA spare parts
319052263039	Y1 FRP A-PILLAR RH EVO-3	TATA spare parts
319052263040	Y1 FRP A-PILLAR LH EVO-3	TATA spare parts
319052263041	Y1-EV A PILLER LH	TATA spare parts
319052263042	Y1-EV A PILLER RH	TATA spare parts
319052263058	Y1 NEW NON MUL CLUSTER COVER FRP_497	TATA spare parts
319052263059	Y1 FRP MULTIPLEX CLUSTER COVER FRP_497	TATA spare parts
319052263061	EV BRTS 9X9 ROOF INTERNAL AC_PANEL -1	TATA spare parts

319052263065	Y1-EV_F2-AJL_A PILLER LH	TATA spare parts
319052264001	FRP REAR INTERNAL-Y1	TATA spare parts
319052264003	FRP FRONT INTERNAL ABOVE DRIVER-Y1	TATA spare parts
319052264004	DASH BOARD-Y1	TATA spare parts
319052264005	INSTRUMENT CLUSTER	TATA spare parts
319052264006	MULTIPLEX CLUSTER PANEL	TATA spare parts
319052264007	FRP GLOVE BOX	TATA spare parts
319052264009	DASH BOARD Y1	TATA spare parts
319052264011	FRP FRONT INTERNAL	TATA spare parts
319052264031	FRP FRONT INTERNAL WITH AC PROVISION	TATA spare parts
319052264032	FRP REAR INTERNAL	TATA spare parts
319052264033	FRP FRONT INNER	TATA spare parts
319052264037	FRP FRONT INNER	TATA spare parts
319052264041	LPO Y1 FRP CLUSTER	TATA spare parts
319052264042	PNEUMATIC DOOR BOX	TATA spare parts
319052264043	PNEUMATIC DOOR BOX FLAP	TATA spare parts
319052264048	LPO Y1 AC FRP HOSE CVR(NON JNNURM BUSES)	TATA spare parts
319052264064	LPO Y1 MIDI CLUSTER FINISHING COVER	TATA spare parts
319052264069	Y1 AC DUCT END CAP REAR LH	TATA spare parts
319052264070	Y1 AC DUCT END CAP REAR RH	TATA spare parts
319052264071	Y1 AC DUCT END CAP FRONT LH	TATA spare parts
319052264072	Y1 AC DUCT END CAP FRONT RH	TATA spare parts
319052264098	FRP FRONT INT WITH AC PRVSN	TATA spare parts
319052264100	LPO Y1 AC FRP HOSE COVER-RAL 7040	TATA spare parts
319052264102	FRP INNER AC DUCT COVER-LH	TATA spare parts
319052264103	FRP INNER AC DUCT COVER-RH	TATA spare parts
319052264104	FRP COVER	TATA spare parts
319052264143	Y1-EV BOTTOM SERVICE FLAP	TATA spare parts
319052264152	Y1 LHD CLUSTER FRP	TATA spare parts
319052264167	Y1 COMMON FUSE BOX FLAP (BLACK)	TATA spare parts
319052264168	LPO Y1 FRP COMMON CLUSTER (BLACK)	TATA spare parts
319052264169	LPO Y1 NON MULTI CLUSTER COVER (BLACK)	TATA spare parts
319052264187	EV BRYS 9X9 MIDDLE DOOR COVER BS6	TATA spare parts
319052264188	EV BRYS 9X9 AJL MIDDLE DOOR COVER2 BS6	TATA spare parts
319052265001	FRP FRONT INTERNAL FUSE BOX FLAP-Y1	TATA spare parts
319052265002	FRP EXTERNAL ENGINE HOOD-Y1	TATA spare parts
319052265003	FRP INTERNAL ENGINE HOOD-Y1	TATA spare parts
319052265004	FRP DASH BOARD FLAP-Y1	TATA spare parts
319052265005	GEAR SHIFT LEVER FINISHING - Y1	TATA spare parts
319052265010	FRP EXTERNAL ENGINE HOOD	TATA spare parts
319052265015	FRP FUSE BOX FLAP	TATA spare parts
319052265016	FRP GLOVE BOX FLAP CENTRE	TATA spare parts
319052265022	FUSE BOX FLAP FRP	TATA spare parts
319052265043	EV BRYS 9X9 MIDDLE DOOR COVER FLAP BS6	TATA spare parts
319052304004	ACRYLIC PLATE_EV	TATA spare parts
319052323001	PASS DOOR HINGE FINISHING BOTTOM COVER	TATA spare parts
319052323002	PASS DOOR CYL BRACKET FINISHING COVER	TATA spare parts

319052323003	ABS A PILLAR RH	TATA spare parts
319052323004	ABS A PILLAR-LH	TATA spare parts
319052323020	Y1 A PILLAR LH _ RAL9001	TATA spare parts
319052323021	Y1 A PILLAR RH _ RAL9001	TATA spare parts
319052323035	A PILLAR COVER LH_GEN5_9X9	TATA spare parts
319052323036	A PILLAR COVER RH_GEN5_9X9	TATA spare parts
319052323037	ITS SERVICE COVER_GEN5_9X9	TATA spare parts
319052324001	ABS MULTIPLEX CLUSTER RING	TATA spare parts
319052324006	ABS FRONT INTERNAL ABOVE DRIVER	TATA spare parts
319052324008	SPEAKER GRILL RH	TATA spare parts
319052324009	SPEAKER GRILL LH	TATA spare parts
319052324040	FRONT INNER_GEN5_9X9	TATA spare parts
319052324041	DRIVER DOOR COVER_GEN5_9X9	TATA spare parts
319052324042	LIFT DOOR CONSOLE COVER_GEN5_9X9	TATA spare parts
319052324044	TOP REAR INNER_GEN5_9X9	TATA spare parts
319052324046	INSIDE DESTINATION BOARD COVER_GEN5_9X9	TATA spare parts
319052324054	DRIVER DOOR TOP PANEL_GEN5_9X9	TATA spare parts
319052325001	ABS GEAR SHIFT LEVER FINISHING	TATA spare parts
319052325002	ABS FUSE BOX FLAP	TATA spare parts
319052325003	ABS FRONT INTERNAL FUSE BOX FLAP	TATA spare parts
319052325005	ABS FRONT INTERNAL FUSE BOX FLAP	TATA spare parts
319052325022	MIDDLE DOOR COVER_GEN5_9X9	TATA spare parts
319052325023	FRONT DOOR COVER_GEN5_9X9	TATA spare parts
319052335001	STEERING COLUMN FINISHING	TATA spare parts
319052964001	Y1 DASHBOARD & ENGINEHOOD INSL ASSY	TATA spare parts
319053002007	HAT RACK ASSEMBLY WITH NEW BRACKET	TATA spare parts
319053002008	HAT RACK ASSY NEW BRKT STD	TATA spare parts
319053002009	HAT RACK ASSEMBLY (MOULDED TYPE) NEW BKT	TATA spare parts
319053002010	HAT RACK ASSEMBLY (MOULDED TYPE)_NEW BKT	TATA spare parts
319053002011	HAT RACK ASSEMBLY (MOULDED TYPE)_NEW BKT	TATA spare parts
319053002012	HAT RACK ASSEMBLY (MOULDED TYPE) NEW BKT	TATA spare parts
319053002013	HAT RACK ASSEMBLY (MOULDED TYPE)_NEW BKT	TATA spare parts
319053002016	HATRACK LH SIDE_WITH PARTITION	TATA spare parts
319053002021	HAT RACK ASSEMBLY (MOULDED TYPE) GSRTC	TATA spare parts
319053002024	NON AC GRILL HATRACK_RH	TATA spare parts
319053002025	HATRACKASSEMBLY(MOULDEDTYPE)_NEWBKT	TATA spare parts
319053002026	HAT RACK ASSY(MODLR TYP)_NEW BKT(STD)	TATA spare parts
319053002028	HAT RACK ASSEMBLY (MOULDED TYPE) SIDE	TATA spare parts
319053002031	MODULAR HATRACK	TATA spare parts
319053002032	NON AC GRILL HATRACK_LH	TATA spare parts
319053002037	NON AC GRILL HATRACK_RH	TATA spare parts
319053002038	NON AC GRILL HATRACK_LH	TATA spare parts
319053003007	HATRACK SUPPORT ASSY WITH MEW BRACKET	TATA spare parts
319053003008	HATRACK ASSEMBLY RH SIDE	TATA spare parts
319053003009	HATRACK ASSEMBLY LH FRONT SIDE	TATA spare parts
319053003010	HATRACK ASSEMBLY LH REAR SIDE	TATA spare parts
319053003011	HAT RACK ASSY LH REAR SIDE	TATA spare parts

319053003012	HAT RACK ASSY LH FRONT SIDE	TATA spare parts
319053003013	HAT RACK ASSY LH SIDE	TATA spare parts
319053003014	HATRACK TUBULAR RH	TATA spare parts
319053003015	HATRACK ASSEMBLY LH	TATA spare parts
319053003016	HATRACK ASSEMBLY LH REAR	TATA spare parts
319053003020	HAT RACK SUPPORT ASSEMBLY	TATA spare parts
319053003022	HATRACK SUPPORT ASSY WITH MEW BRACKET	TATA spare parts
319053003026	GRILLED HATRACK-RH	TATA spare parts
319053003027	GRILLED HATRACK-LH	TATA spare parts
319053003028	EMERGENCY SWITCH BRACKET ASSM	TATA spare parts
319053003036	GRILLED HATRACK_RH	TATA spare parts
319053003037	GRILLED HATRACK_LH	TATA spare parts
319053003038	GRILLED HATRACK_LH (BEHIND DOOR)	TATA spare parts
319053003045	NON AC HATRACK_52WB RH	TATA spare parts
319053004006	HATRACK SINGLE HOLE BRACKET ASSY	TATA spare parts
319053004007	HATRACK SINGLE HOLE BRKT ASSY_GREY	TATA spare parts
319053083004	MODULAR HATRACK END COVER SUPPORT	TATA spare parts
319053084002	PLYWOOD HOLDING BRACKET	TATA spare parts
319053084005	STEEL HAT RACK BRACKET	TATA spare parts
319053084015	PLYWOOD HOLDING BRACKET	TATA spare parts
319053084017	STEEL HAT RACK BRACKET	TATA spare parts
319053303002	HAT RACK GRILL (CREAM)	TATA spare parts
319053323001	HAT RACK FINISHING COVER-Y1	TATA spare parts
319053323002	JOINERY FOR HATRACK	TATA spare parts
319053324001	SUPPORT BRACKET COVERING-HATRACK-Y1	TATA spare parts
319053324002	HATRACK END COVER RH	TATA spare parts
319053324003	HATRACK END COVER LH	TATA spare parts
319053324005	SUPPORT BRACKET COVERING-HATRACK-Y1	TATA spare parts
319053324006	SUPPORT BRACKET COVER - AC DUCT	TATA spare parts
319053324007	SUPPORT BRACKET COVER AC DUCT	TATA spare parts
319054063001	WINDOW GUARD RAIL 19.05 DIA_4026MM	TATA spare parts
319054063002	WINDOW GUARD RAIL 19.05 DIA_4255MM	TATA spare parts
319054063003	WINDOW GUARD RAIL 19.05 DIA_3976MM	TATA spare parts
319054063004	WINDOW GUARD RAIL 19.05 DIA_2705MM	TATA spare parts
319054063005	WINDOW GUARD RAIL 19.05 DIA_703MM	TATA spare parts
319054063006	WINDOW GUARD RAIL 19.05 DIA_3836MM	TATA spare parts
319054063007	WINDOW GUARD RAIL 19.05 DIA_2260MM	TATA spare parts
319054063008	WINDOW GUARD RAIL 19.05 DIA_757MM	TATA spare parts
319054063011	WINDOW GUARD RAIL 1905 DIA 2455MM	TATA spare parts
319056083001	SIDE INTERNAL PANELING BETWEEN WINDO	TATA spare parts
319056083002	SIDE NTERNAL PANEL BESIDE EMERGENCY DOOR	TATA spare parts
319056083004	SIDE INTERNAL PANELING LH SIDE_ABOVE THE	TATA spare parts
319056083005	SIDE INTERNAL PANELING BETWEEN WINDOWS	TATA spare parts
319056083006	SIDE INTERNAL PANELING LH SIDE	TATA spare parts
319056083008	PANEL	TATA spare parts
319056083009	REAR PANEL	TATA spare parts
319056083104	WINDOW PILLER OF AT REAR STR-EVO-1	TATA spare parts



319056083113	REAR PANEL MIDDLE	TATA spare parts
319056083114	REAR REVITMENT LH & RH SIDE	TATA spare parts
319056083118	DRIVER DOOR PILLER-EVO-1	TATA spare parts
319056083282	SIDE INT PANEL ABOVE PASSENGER DOOR	TATA spare parts
319056083442	SIDE INTERNAL PANELING	TATA spare parts
319056083443	SIDE INTERNAL PANELING RH BEHIND DR DOOR	TATA spare parts
319057083005	ROOF INTERNAL REAR SHEET	TATA spare parts
319057083196	ROOF INTRNAL REAR RH PANEL	TATA spare parts
319057083197	ROOF INTRNAL FRONT LH PANEL	TATA spare parts
319057083200	ROOF INTRNAL REAR LH PANEL	TATA spare parts
319057083205	ROOF INTERNAL SHEET-2020	TATA spare parts
319057083206	ROOF INTERNAL SHEET-1365	TATA spare parts
319057083268	ROOF INTERNAL PANEL _1	TATA spare parts
319057083269	ROOF INTERNAL PANEL-2010	TATA spare parts
319057083270	ROOF INTERNAL PANEL 3	TATA spare parts
319057083271	ROOF INTERNAL PANEL -1885	TATA spare parts
319057083272	ROOF INTERNAL PANEL	TATA spare parts
319057083460	ROOF INTERNAL PANEL_04	TATA spare parts
319057083465	ROOF INTERNAL PANEL_10	TATA spare parts
319057183028	ROOF INTERNAL PANEL-01	TATA spare parts
319057183072	ROOF INTERNAL PANEL_02	TATA spare parts
319057183073	ROOF INTERNAL PANEL_03	TATA spare parts
319058083001	FRONT&REAR LIC PLATE 520 X 120-Y1	TATA spare parts
319058183001	REAR CAMER COVER FOR PMPML	TATA spare parts
319058263001	FRP FRONT WHEEL ARCH COVER-Y1	TATA spare parts
319058263002	FRP REAR WHEEL ARCH COVER-Y1	TATA spare parts
319058263004	WHEEL ARCH GEN 5 - 9X9	TATA spare parts
319058323004	Y1 EV_FRONT DOOR CANOPY	TATA spare parts
319058912023	DECAL STICKER ASSY_Y1_42 WB_SD	TATA spare parts
319058912080	EMERGENCY DOOR CANOPY - PP	TATA spare parts
319058912089	BUTYL TAPE_ROOF PANELING INFO ASSY_42WB	TATA spare parts
319058912203	EV 9/9 BRYS AJL_DECAL POS. FITMENT DWG	TATA spare parts
319058962001	DECAL STICKER ASSY_Y1_49 WB_KIT PART	TATA spare parts
319058962002	DECAL STICKER ASSY_Y1_52 WB_KIT PART	TATA spare parts
319058962003	DECAL STICKER ASSY_Y1_42 WB_KIT PART	TATA spare parts
319058962004	DECAL STICKER KIT Y1 ULTRA LUXURY&DELUXE	TATA spare parts
319058962011	DECAL STICKER KIT_Y1_ULTRA LUX&DLX(SRL)	TATA spare parts
319058962012	DECAL STICKER ASSEMBLY_Y1 42 WB DD PMPML	TATA spare parts
319058962013	DECAL KIT ASSEMBLY_Y1_DD_ASCDCL	TATA spare parts
319058962014	DECAL KIT ASSEMBLY_Y1_DD_PMPML	TATA spare parts
319058962015	DECAL KIT ASSEMBLY_Y1_NMMT	TATA spare parts
319058963002	Y1 DECAL (BLACK-BLUE) KIT PART DRAWING	TATA spare parts
319058963007	EV 9/9 BRYS AJL KIT PART 1	TATA spare parts
319058963008	EV 9/9 BRYS AJL KIT PART 2	TATA spare parts
319058963009	EV 9/9 BRYS AJL KIT PART 3	TATA spare parts
319058963010	EV 9/9 BRYS AJL KIT PART 4	TATA spare parts
319058963011	EV 9/9 BRYS AJL KIT PART 5	TATA spare parts

319058963012	EV 9/9 BRTS AJL KIT PART 6	TATA spare parts
319058963013	EV 9/9 BRTS AJL KIT PART 7	TATA spare parts
319058963014	EV 9/9 BRTS AJL KIT PART 8	TATA spare parts
319058963015	EV 9/9 BRTS AJL KIT PART 9	TATA spare parts
319058963016	EV 9/9 BRTS AJL KIT PART 10	TATA spare parts
319058963017	EV 9/9 BRTS AJL KIT PART 11	TATA spare parts
319058963018	EV 9/9 BRTS AJL KIT PART 12	TATA spare parts
319059003008	Y1_BRTS_EV_CABLE COVER BOTTOM_RH_ASSY	TATA spare parts
319059323009	ABS DRIVER PARTITION FINISHING 1	TATA spare parts
319059323010	ABS DRIVER PARTITION FINISHING 2	TATA spare parts
319059323011	ABS DRIVER PARTITION FINISHING 3	TATA spare parts
319059323013	ABS DRIVER PARTITION FINISH_1	TATA spare parts
319059323014	ABS DRIVER PARTITION FINISH_2	TATA spare parts
319059323015	ABS DRIVER PARTITION FINISH_3	TATA spare parts
319059323020	50X40 WINDOW PILLAR_ABS	TATA spare parts
319059323034	SEAT BELT FINISHING COVER	TATA spare parts
319059323083	ABS COVER FOR PANIC SWITCH_RAL-9004	TATA spare parts
319059323092	Y1 NAC_EV_INSIDE CABLE COVER TOP_RH	TATA spare parts
319059323098	AJL 9X9 TOP HV CABLE COVER	TATA spare parts
319059323099	AJL 9X9 TOP HV CABLE COVER	TATA spare parts
319059333001	CURTAIN FABRIC CFT 154 GREEN 680X1170	TATA spare parts
319059333002	CURTAIN FABRIC CFT 154 GREEN 780X1170	TATA spare parts
319059333003	CURTAIN FABRIC CFT 154 GREEN 900X1170	TATA spare parts
319059333004	EMERGENCY EXIT DOOR STICKER	TATA spare parts
319059333005	STICKER LIFT HANDLE TO UNLOCK	TATA spare parts
319059333006	EMERGENCY DOOR OPEN INSTRUCTION(OUTSIDE)	TATA spare parts
319059333009	INSTURCTION STICKER ELECTRONIC SURVE	TATA spare parts
319059333010	EMERGENCY EXIT STICKER	TATA spare parts
319059333011	EMERGENCY STICKER	TATA spare parts
319059333014	BBC_FIRE EXTIGUISHER STICKER	TATA spare parts
319059333015	EMERGENCY EXIT STICKER INSIDE BS6	TATA spare parts
319059333016	EMERGENCY EXIT STICKER OUTSIDE	TATA spare parts
319059333035	STICK.IN CASE OF EME.PUSH ESC.HATCH	TATA spare parts
319059333042	EMERGENCY EXIT STICKER (91X119) BS6	TATA spare parts
319059333043	GLASS BREAKING INF. STICKER (145X123) BS	TATA spare parts
319059333044	STICKER LIFT HANDLE TO UNLOCK (134X105)	TATA spare parts
319059333045	EME.DOOR OPEN INST.STICKER (193X154) BS6	TATA spare parts
319059333046	EMERGENCY DOOR EXIT STICKER (131X236) BS	TATA spare parts
319059333047	EME.STICKER TO BREAK GLASS (145X123) BS6	TATA spare parts
319059333048	FIRE EXTINGUISHER STICKER (116X65) BS6	TATA spare parts
319059333049	STICKER LEVER PUSH DOWN (106X124) BS6	TATA spare parts
319059333050	EMERGENCY ESCAPE HATCH STICKER (168X158)	TATA spare parts
319059333051	EMERGENCY DOOR EXIT STICKER BS6	TATA spare parts
319059333052	CAUTION MIND YOUR HEAD STICKER	TATA spare parts
319059333053	CAUTION MIND YOUR STEP STICKER	TATA spare parts
319059333054	ARROW SYMBOL STICKER (106X56)	TATA spare parts
319059333065	BREAK THE GLS&PULL THE LEVER-EXTRNL STCR	TATA spare parts

319059403003	CURTAIN	TATA spare parts
319059403004	CURTAIN	TATA spare parts
319059962002	REFLECTIVE TAPE Y1_52WB_SKL_STD	TATA spare parts
319059962003	REFLECTIVE TAPE Y1_42WB_SKL_STD	TATA spare parts
319059962004	REFLECTIVE TAPE_Y1_52WB_SKL_STD_RR EMD	TATA spare parts
319059962005	REFLECTIVE TAPE Y1 42WB SKL STD REAR ED	TATA spare parts
319059963002	DECALE STICKER LH & RH SIDE	TATA spare parts
319059963003	WAVE DECAL STICKER KIT PART LH & RH SIDE	TATA spare parts
319060003002	REAR VIEW MIRROR SUPPORT ARM	TATA spare parts
319060003004	REAR-VIEW MIRROR SUPPORT_RHD_DRIVER SIDE	TATA spare parts
319061003002	MECHANICAL SUSPENDED DRIVER SEAT_RHD	TATA spare parts
319062003001	FIRE EXTINGUISHER BOX ASSY	TATA spare parts
319062004003	CONTROL UNIT AF-300	TATA spare parts
319062004047	FLASHING SOUNDER_12V & 24V_FDAS_SAFEX	TATA spare parts
319062004049	CONTROL UNIT_12V_FDAS_GRN.FUEL BS6	TATA spare parts
319062004050	CONTROL UNIT_24V_FDAS_GRN.FUEL	TATA spare parts
319062004059	HOOTER_12V_FDAS_GREEN FUEL BS6	TATA spare parts
319062004060	HOOTER_24V_FDAS_GREEN FUEL	TATA spare parts
319062004061	WIRING HARNS FDAS 12V & 24V GREEN FUEL B	TATA spare parts
319062004062	LHS CABLE ASSY_12V & 24V_FDAS_GREEN FUEL	TATA spare parts
319062004063	LHS CABLE CLAMP_12V & 24V_FDAS BS6	TATA spare parts
319062004064	HEX NUT M5X0.8_FDAS_GREEN FUEL BS6	TATA spare parts
319062004065	HEX BOLT FDAS_GREEN FUEL BS6	TATA spare parts
319062004066	PLAIN WASHER_FDAS_GREEN FUEL BS6	TATA spare parts
319062004072	P-CLIP_CLH	TATA spare parts
319062004080	ZONE1 LHD CABLE ASSY	TATA spare parts
319062004081	ZONE2 LHD CABLE ASSY	TATA spare parts
319062004082	WIRING HARNESS	TATA spare parts
319062005001	END OF LINE_EV_CLH	TATA spare parts
319062005004	LHD CABLE_138*C_4000	TATA spare parts
319062005006	LHD CABLE_138*C_6400	TATA spare parts
319062005007	LHD CABLE_138*C_9000	TATA spare parts
319062005008	JONCTION BOX	TATA spare parts
319062005009	FRLS CABLE FOR ZONE2(2000MM)	TATA spare parts
319062005010	FRLS CABLE FOR ZONE2(300MM)	TATA spare parts
319062005011	FRLS CABLE FOR ZONE1(1300MM)	TATA spare parts
319062005012	CAUTION STICKER	TATA spare parts
319062005013	CONTROL PANEL_EV	TATA spare parts
319062005014	HORN STROBE_EV	TATA spare parts
319062005015	SUPPRESSION TUBE ASSY EV 9X9	TATA spare parts
319062005016	WIRING HARNESS EV 9X9	TATA spare parts
319062005017	HEAT SENSING CABLE EV 9X9	TATA spare parts
319062006005	FDSS CONTROL UNIT_EV_9X9 BS6	TATA spare parts
319062006006	FDSS_HOSE_EV_9X9 BS6	TATA spare parts
319062333001	EMERGENCY SWITCH STICKER	TATA spare parts
319062333002	PASSENGER DOOR STICKER	TATA spare parts
319062333003	PASSENGER DOOR AIR CUTOFF STICKER BS6	TATA spare parts

319062912026	ELECTRONIC SURVEILLANCE STICKER ASSY	TATA spare parts
319062912052	ULTRA_LPO 914_DRIVER SEAT BELT	TATA spare parts
319062963020	FDAS_12V/24V_GREEN FUEL KIT PART	TATA spare parts
319062963021	FIRE DETECTION & ALARMING SYSTEM 24V KIT	TATA spare parts
319062963022	FDAS KIT_EV_CLH	TATA spare parts
319062964001	FDAS_SAFEX_12V & 24V_PANELING	TATA spare parts
319062964002	FDAS_12V & 24V_SAFEX_TRIM	TATA spare parts
319062964003	FDAS_GREEN FUEL_12V & 24V_PANELING BS6	TATA spare parts
319062964004	FDAS_12V_GREEN FUEL_TRIM KIT BS6	TATA spare parts
319062964005	FDAS_24V_GREEN FUEL_TRIM KIT	TATA spare parts
319062964008	FDAS_12V & 24V_CLH_PANELING BS6	TATA spare parts
319062964009	FDAS_12V_CLH_TRIM BS6	TATA spare parts
319062964011	FASS_PANELING_EV_CLH EV	TATA spare parts
319062964012	FDAS_TRIM_EV_CLH EV	TATA spare parts
319062964013	FDSS TRIM KIT_EV_9X9_BRT	TATA spare parts
319062964014	FDSS_PANELING_KIT_EV_9X9_BRT BS6	TATA spare parts
319062964018	FDAS_PANELING_KIT_EV_9X12	TATA spare parts
319063001003	DESTINATION BOARD KIT MINI & MIDI	TATA spare parts
319063003010	SIDE DESTINATION BOARD BRKT ASSY_RH	TATA spare parts
319063003011	SIDE DESTI BOARD SUPPORTING BRKT ASSY_LH	TATA spare parts
319063003012	DESTINATION BOARD BRKT ASSY	TATA spare parts
319063003014	SIDE DESTINATION BOARD BRKT ASSY_LH	TATA spare parts
319063003015	SIDE DESTINATION BOARD BRKT ASSY_RH	TATA spare parts
319063003016	SIDE DESTINATION BOARD BRKT ASSY_LH	TATA spare parts
319063003017	SIDE DESTI BOARD SUPPORTING BRKT ASSY	TATA spare parts
319063003018	DESTINATION BOARD BRKT ASSY	TATA spare parts
319063003019	DESTINATION BOARD BRKT SUB-ASSY	TATA spare parts
319063083004	FRONT DESTINATION BOARD BRKT	TATA spare parts
319063083006	LED REINFORCEMENT PLATE 770 (DEST_BOARD)	TATA spare parts
319063083007	REAR DESTINATION BOARD BRKT	TATA spare parts
319063083008	LED REINFORCEMENT PLATE	TATA spare parts
319063083009	DESTINATION BOARD BRACKET	TATA spare parts
319063183001	ALU PL FOR DESTINATION BOARD SUPPORT	TATA spare parts
319063183002	ALUMINIUM PLATE_FRONT DESTINATION BOARD	TATA spare parts
319063183003	ALUMINIUM PLATE FOR DESTINATION BOARD	TATA spare parts
319064003001	WINDOW RH_1243X1070_T1/3F B2/3S_30%T_SE	TATA spare parts
319064003002	WINDOW RH_1293X1070_T1/3F B2/3S_30%T_SE	TATA spare parts
319064003003	WINDOW RH_663X1070_T1/3F B2/3S_30%T_SER	TATA spare parts
319064003004	WINDOW LH_1493X1070_T1/3F B2/3S_30%T_SE	TATA spare parts
319064003005	WINDOW LH_1293X1070_T1/3F B2/3S_30%T_SE	TATA spare parts
319064003006	DRIVER DOOR WINDOW Y1	TATA spare parts
319064003007	EMERGENCY DOOR WINDOW Y1	TATA spare parts
319064003008	WINDOW RH_843X1070_T1/3F B2/3S_30%T_SER	TATA spare parts
319064003009	WINDOW RH_713X1070_T1/3F B2/3S_30%T_SER	TATA spare parts
319064003010	WINDOW LH_1093X1070_T1/3F B2/3S_30%T_SE	TATA spare parts
319064003014	WINDOW LH 1476X1056_TF BS_R7K_30%T_EPDN	TATA spare parts
319064003015	WINDOW LH 1266X1056_TF BS_R7K_30%T_EPDN	TATA spare parts

319064003016	WINDOW RH 1216X1056_TF BS_R7K_30%T_EPDM	TATA spare parts
319064003017	WINDOW RH 1266X1056_TF BS_R7K_30%T_EPDM	TATA spare parts
319064003018	WINDOW RH 656X1056_TF BS_R7K_30%T_EPDM	TATA spare parts
319064003019	WINDOW RH 569X792_EDW SL_R7K_30%T_EPDM	TATA spare parts
319064003020	WINDOW RH 769X792_DDW SL OP_R7K_CLR_EPI	TATA spare parts
319064003022	DLX DRIVER DOOR PASTED SLIDING WINDOW	TATA spare parts
319064003028	PASSEN DOOR WINDOW Y1	TATA spare parts
319064003029	WIN RH_873X1070	TATA spare parts
319064003030	WIN LH_873X1070	TATA spare parts
319064003031	FIXED PEEP WINDOW_363X1070	TATA spare parts
319064003033	FIXED PEEP WINDOW_320X1070	TATA spare parts
319064003034	WIN RH_873X1070_T1/3F B2/3S_50%T_SER	TATA spare parts
319064003035	WIN RH_1293X1070_T1/3F B2/3S_50%T_SER	TATA spare parts
319064003036	WIN RH_1493X1070_T1/3F B2/3S_50%T_SER	TATA spare parts
319064003037	WIN LH_1493X1070_T1/3F B2/3S_50%T_SER	TATA spare parts
319064003038	WIN LH_1293X1070_T1/3F B2/3S_50%T_SER	TATA spare parts
319064003039	WIN LH_873X1070_T1/3F B2/3S_50%T_SER	TATA spare parts
319064003040	FIXED PEEP WINDOW_50%T_363X1070	TATA spare parts
319064003052	CO DRIVER WINDOW1398X880CLEAR	TATA spare parts
319064003054	WINDOW RH_1243X1070_T1/3P B2/3S_30%T_SE	TATA spare parts
319064003055	WINDOW RH_1293X1070_T1/3P B2/3S_30%T_SE	TATA spare parts
319064003056	WINDOW RH 663X1070	TATA spare parts
319064003057	WINDOW LH_1493X1070_T1/3P B2/3S_30%T_SE	TATA spare parts
319064003058	WINDOW LH_1293X1070_T1/3P B2/3S_30%T_SE	TATA spare parts
319064003059	WINDOW RH_843X1070_T1/3P B2/3S_30%T_SER	TATA spare parts
319064003060	WINDOW RH_713X1070_T1/3P B2/3S_30%T_SER	TATA spare parts
319064003061	WINDOW LH_1093X1070_T1/3P B2/3S_30%T_SE	TATA spare parts
319064003062	WINDOW RH_1043X1070_T1/3P B2/3S_30%T_SE	TATA spare parts
319064003064	WIN RH_873X1070_T1/3F B2/3S_30%T_SERV	TATA spare parts
319064003065	WIN LH_873X1070_T1/3F B2/3S_30%T_SERV	TATA spare parts
319064003066	WIN RH 1293X1070 T1/3P50PERC TINT	TATA spare parts
319064003067	WIN LH 1293X1070 T1/3P50PERC TINT	TATA spare parts
319064003068	WIN RH 713X1070 T1/3P50PERC TINT	TATA spare parts
319064003069	WIN RH 1043X1070 T1/3P50PERC TINT	TATA spare parts
319064003070	WIN RH 873X1070 T1/3P50PERC TINT	TATA spare parts
319064003071	WIN LH 873X1070 T1/3P50PERC TINT	TATA spare parts
319064003072	FIXED PEEP WINDOW 363X1070 30PERC TNT	TATA spare parts
319064003073	FIXED PEEP WINDOW 314X1070 30PERCTINT	TATA spare parts
319064003074	COMMUNICATION WINDOW 644X494 CLEAR	TATA spare parts
319064003075	WINDOW LH 1043X1070 T1/3P B2/3S 30PERCT	TATA spare parts
319064003076	WINDOW LH 713X1070 T1/3P B2/3S 30PERCT S	TATA spare parts
319064003077	PEEP WINDOW 310X475 SERVICEABLE CLEAR	TATA spare parts
319064003080	WIN RH 873X1070 T1/3F	TATA spare parts
319064003081	WIN RH 1293X1070 T1/3P	TATA spare parts
319064003082	WIN RH 663X1070 T1/3P	TATA spare parts
319064003083	WIN LH 1493X1070 T1/3P	TATA spare parts
319064003084	WIN LH 1293X1070 T1/3P	TATA spare parts

319064003085	WIN LH 873X1070 T1/3F	TATA spare parts
319064003092	WINDOW EME.DOOR 587X690MM	TATA spare parts
319064003093	WIN LH993X1070T1/3F B2/3S30PERC TSER	TATA spare parts
319064003094	WIN RH993X1070T1/3F B2/3S30PERC TSER	TATA spare parts
319064003095	WIN RH1126X1070T1/3F B2/3S30PERC TSER	TATA spare parts
319064003096	WIN RH1208X1070T1/3F B2/3S30PERC SER	TATA spare parts
319064003097	WIN LH868X1070T1/3F B2/3S30PERC TSER	TATA spare parts
319064003098	WIN LH1238X1070T1/3F B2/3S30PERC TSER	TATA spare parts
319064003099	WIN RH1238X1070T1/3F B2/3S30PERC TSER	TATA spare parts
319064003102	FIXED PEEP WINDOW193X107030PERC TNT	TATA spare parts
319064003103	DRIVER DOOR WINDOW Y1-MIDI 787X810	TATA spare parts
319064003104	EMERGENCY DOOR WINDOW	TATA spare parts
319064003105	WINDOW LH 1293X1070 T1/3P B2/3S CLR SER	TATA spare parts
319064003106	WINDOW RH 1293X1070 T1/3P B2/3S CLR SER	TATA spare parts
319064003107	WINDOW RH 1243X1070 T1/3P B2/3S CLR SER	TATA spare parts
319064003108	WINDOW LH 1093X1070 T1/3P B2/3S CLR SER	TATA spare parts
319064003109	WINDOW RH 1093X1070 T1/3P B2/3S CLR SER	TATA spare parts
319064003110	WINDOW LH 1043X1070 T1/3P B2/3S CLR SER	TATA spare parts
319064003113	PEEP WINDOW 310X423 SERVICEABLE CLEAR	TATA spare parts
319064003121	WIN LH 1253X1070 T1/3F B2/3S 30T SER	TATA spare parts
319064003122	WINDOW LH 1023X1070	TATA spare parts
319064003124	PEEP WINDOW 290X350SERVICEABLECLEAR	TATA spare parts
319064003126	DRIVER DOOR WINDOW Y1_LHD_787X810	TATA spare parts
319064003128	PEEP WINDOW-363X1070MM	TATA spare parts
319064003129	EMERGENCY DOOR WINDOW 587X810	TATA spare parts
319064003131	WINDOW RH 483X1070 T1/3F B2/3S 30T SER	TATA spare parts
319064003133	DR OPENABLE SCOOP LH WIN_426X890 CLEAR	TATA spare parts
319064003134	COD RH WIN_1398X880_SLIDING_SER_CLR	TATA spare parts
319064003136	WINDOW RH_483X1070_T1/3F B2/3S_30PERCT_	TATA spare parts
319064003137	DRIVER DOOR WINDOW Y1RHD780X921	TATA spare parts
319064003138	CO DRIVER WINDOW 815X855 CLEAR	TATA spare parts
319064003139	PEEP WINDOW 443X445	TATA spare parts
319064003141	WINDOW LH 1238X1070MM	TATA spare parts
319064003142	WINDOW RH 1238X1070MM	TATA spare parts
319064003143	WINDOW LH 868X1070MM	TATA spare parts
319064003144	WINDOW RH 1208X1070MM	TATA spare parts
319064003145	WINDOW LH 993X1070MM	TATA spare parts
319064003146	WINDOW RH 993X1070MM	TATA spare parts
319064003147	SEARVICABLE TYPE SECTIONS	TATA spare parts
319064003148	PEEP WINDOW-193X1070MM CLEAR GLASS	TATA spare parts
319064003149	FIXED WINDOW 454X1070	TATA spare parts
319064003156	FIXED PEEP WIN_193X1070_50PERC GREY TINT	TATA spare parts
319064003162	FIXED WINDOW_383X1070_CLR GLASS	TATA spare parts
319064003163	WINDOW RH 928X1070 T1/3P B2/3S CLR SER	TATA spare parts
319064003164	WINDOW RH 456X1070 FIXED CLR SER	TATA spare parts
319064003165	WINDOW LH 958X1070 T1/3P B2/3S CLR SER	TATA spare parts
319064003166	WINDOW LH 1228X1070 T1/3P B2/3S CLR SER	TATA spare parts

319064003167	WIN RH 713X1070 T1/3P B2/3S CLR SER	TATA spare parts
319064003168	WIN LH_713X1070_T1/3P	TATA spare parts
319064003169	WINDOW RH_1043X1070_T1/3P	TATA spare parts
319064003170	WIND RH_843X1070_T1/3P	TATA spare parts
319064003171	WIN LH 1493X1070 T1/3F B2/3S CLR SER	TATA spare parts
319064003177	WINDOW RH_663X1070_T1/3P	TATA spare parts
319064003180	WIN RH 1293X1070	TATA spare parts
319064003181	WIN RH 713X1070	TATA spare parts
319064003182	RH WIN 1043X1070	TATA spare parts
319064003183	LH WIN 1293X1070	TATA spare parts
319064003184	RH WIN 1243X1070	TATA spare parts
319064003186	WIN RH 1043X1070 T1/3F B2/3S 50PERC T SE	TATA spare parts
319064003187	WINDOW LH 713X1070 T1/3P B2/3S 50PERC T	TATA spare parts
319064003188	FIXED PEEP WINDOW 50PERC T 363X1070	TATA spare parts
319064003189	WINDOW RH_563X1070_T1/3F B2/3S_30PERCT_	TATA spare parts
319064003190	EMERGENCY DOOR WINDOW¿ 605X800 CLEAR	TATA spare parts
319064003191	EME.WINDOW RH_1243X1070_FIXED_CLEAR	TATA spare parts
319064003193	EMER DOOR WINDOW Y1_605X800 50PERCGREY	TATA spare parts
319064003194	EMER DOOR WINDOW¿ 605X800 30	TATA spare parts
319064003197	WINDOW RH 563X1070 T1/3F B2/3S SER CLR	TATA spare parts
319064003198	FIXED WIN LH\RH_456X1070_30PERCT_SER	TATA spare parts
319064003199	WINLH_1493X1070_T1/3F B2/3S_30PERCT_SER_	TATA spare parts
319064003201	WINDOW LH 563X1070 T1/3F B2/3S SER CLR	TATA spare parts
319064003202	WIND LH 843X1070 T1/3P B2/3S CLR GLASS	TATA spare parts
319064003203	EME.WINDOW RH_873X1070_FIXED_50PERC_SE	TATA spare parts
319064003205	FIXED WINDOW_383X1070_50PERC GREY TINT	TATA spare parts
319064003220	FIXED PEEP WINDOW 123X1070	TATA spare parts
319064003221	WINDOW RH_483X1070_T1/3F	TATA spare parts
319064003222	EME.FIXED WIN RH_1243X1070_50PERC_GREY S	TATA spare parts
319064003223	WINDOW RH_713X1070_T1/3P B2/3S_50PERCT_	TATA spare parts
319064003237	WINDOW LH 695X1070MM_CLEAR GLASS	TATA spare parts
319064003245	WIN RH_1243X1070_T1/3F	TATA spare parts
319064003262	PASTED GLASS+VENT W._1163X1340_50PERC GR	TATA spare parts
319064003278	WINDOW RH 483X1070 T1/3F	TATA spare parts
319064003285	WINDOWRH1293X1070T1/3F	TATA spare parts
319064003286	WINDOWLH1293X1070T1/3F	TATA spare parts
319064003287	WIN LH 1493X1070 T1/3F	TATA spare parts
319064003288	WIN RH 713X1070 T1/3F	TATA spare parts
319064003289	WIN RH 873X1070 T1/3F	TATA spare parts
319064003290	EMERGENCYDOORWINDOWY1603X80050PERCG	TATA spare parts
319064003291	EXT GLS LH INT GLS RH 50PERCGN TINT 445X	TATA spare parts
319064003292	WINDOW GUARD RAIL 75	TATA spare parts
319064003295	WIN RH 1043X1070 T1/3F	TATA spare parts
319064003302	WINDOW RH 1056X1056_TF BS_CLEAR_EPDM	TATA spare parts
319064003303	WINDOW RH 1226X1056_TF BS_CLEAR_EPDM	TATA spare parts
319064003304	WINDOW RH 921X1056_TF BS_CLEAR_EPDM	TATA spare parts
319064003305	WINDOW RH 388X1056_FF_CLEAR_EPDM	TATA spare parts

319064003306	WINDOW RH 566X771_EDW SLD_CLEAR_EPDM	TATA spare parts
319064003307	WINDOW LH 1169X1056_TF BS_CLEAR_EPDM	TATA spare parts
319064003308	WINDOW LH 941X1056_TF BS_CLEAR_EPDM	TATA spare parts
319064003309	WINDOW LH 1036X1056_TF BS_CLEAR_EPDM	TATA spare parts
319064003310	WINDOW LH 1056X1056_TF BS_CLEAR_EPDM	TATA spare parts
319064003312	WINDOW LH_868X1070_T1/3F	TATA spare parts
319064003313	WINDOW LH_1253X1070_T1/3F	TATA spare parts
319064003314	WINDOW RH_1238X1070_T1/3F	TATA spare parts
319064003320	CASSETTE TYPE WINDOW 1340X1163	TATA spare parts
319064003322	CASSETTE TYPE WINDOW 920X1163	TATA spare parts
319064003323	CASSETTE TYPE WINDOW 606X1163	TATA spare parts
319064003324	CASSETTE TYPE WINDOW RH SIDE 1340X1163	TATA spare parts
319064003325	CASSETTE TYPE WINDOW RH SIDE 1400X1163	TATA spare parts
319064003326	CASSETTE TYPE WINDOW RH SIDE 920X1163	TATA spare parts
319064003331	WINDOW RH 749X781_DDW SL OP_R7K_CLR_EPDM	TATA spare parts
319064003333	WIND RH_663X1070_T1/3F	TATA spare parts
319064003342	LH LIFT DR.WIND_1078X979_50PERCGRAY SLID	TATA spare parts
319064003348	WINDOW LH 1243X1070MM	TATA spare parts
319064004098	VENT WINDOW_2 HANDLE_PASTED_50PERCGRM	TATA spare parts
319064004120	VENT WIND_2HANDLE_PASTED_30PERCGREEN T	TATA spare parts
319064083003	LH G.I RVM SHEET_152X215X1.55MM	TATA spare parts
319064083004	RH G.I RVM SHEET_286X271X1.55MM	TATA spare parts
319064183001	Y1_EV_RVM COVER BS6	TATA spare parts
319064233004	PASTED GLASS RH LH 1163X1343 50% GREY	TATA spare parts
319064233008	PASTED GLASS LH(PASS DOOR) 889X808 CLEAR	TATA spare parts
319064233009	PASTED GLASS LH 1163X1457 50PERC GREY	TATA spare parts
319064233016	PASTED GLASS LH_1163X1397_50PERC GREY	TATA spare parts
319064233023	PASTED GLASS VENT 1163X1340 50% GREY	TATA spare parts
319064233024	PASTED GLASS LH/RH 1163X920 50% GREY	TATA spare parts
319064233025	PASTED GLASS LH/RH_1163X525_50PERC GREY	TATA spare parts
319064233027	PASTED GLASS LH(REAR)_1163X875_50PERC GR	TATA spare parts
319064233028	PASTED GLASS RH TOP_272X710_CLEAR	TATA spare parts
319064233029	PASTED DR.PART GLASS 1087X1166 CLEAR	TATA spare parts
319064233030	PASTED GLASS EME WINDOW_873X690_50PERC	TATA spare parts
319064233031	PASTED GLASS REAR LH_1163X1400_50PERC GR	TATA spare parts
319064233032	PASTED GLASS LH TOP 292X830 CLEAR	TATA spare parts
319064233033	PASTED GLASS RH TOP 233X660 CLEAR	TATA spare parts
319064233034	PASTED DR.PART GLASS-LH 850X372 CLEAR	TATA spare parts
319064233035	PASTED GLASS 1163X415MM	TATA spare parts
319064233036	PASTED GLASS LH 1163X1604 50 PERC GREY	TATA spare parts
319064233037	PASTED GLASS RH 1163X1604 50 PERC GREY	TATA spare parts
319064233038	PASTED GLASS LH 1163X1450 50 PERC GREY	TATA spare parts
319064233041	PASTED GLASS RH LH 1163X1287 50PERC GREY	TATA spare parts
319064233046	PASTED GLASS LH TOP 233X660 CLEAR	TATA spare parts
319064233048	PASTED GLASS LH 1163X1175 50PERC GREY	TATA spare parts
319064233049	PASTED GLASS RH 1163X1030 50PERC GREY	TATA spare parts
319064233050	PASTED GLASS LH 1163X1143 50PERC GREY	TATA spare parts



319064233051	PASTED GLASS RH 1163X533 50PERC GREY	TATA spare parts
319064233052	PASTED GLASS LH 358X1204 50PERC GREY	TATA spare parts
319064233053	PASTED GLASS RH(REAR)_1163X835_50PERC GR	TATA spare parts
319064233066	PASTED GLASS LH 1163X1005 50PERC GREY	TATA spare parts
319064233067	PASTED GLASS LH 1163X1278 50PERC GREY	TATA spare parts
319064233069	PASTED GLASS LH/RH_1163X525_50PERC GREY	TATA spare parts
319064233072	PASTED GLASS+VENT_1163X1145_50PERC GREY	TATA spare parts
319064233074	PASTED GLASS LH/RH 1163X293 50% GREY	TATA spare parts
319064233075	PASTED GLASS LH/RH 1163X587 50% GREY	TATA spare parts
319064233076	PASTED GLASS RH TOP 233X660 CLEAR	TATA spare parts
319064233077	PASTED GLASS LH TOP 292X540 CLEAR	TATA spare parts
319064233078	PASTED GLASS EME WINDOW_878X696_50PERC	TATA spare parts
319064233079	PASTED GLASS RH_1163X1397_50PERCGREY	TATA spare parts
319064233080	PASTED GLASS RH 1163X226MM CLEAR	TATA spare parts
319064233083	PASTED GLASS RH_1163X606_50PERCGREY	TATA spare parts
319064233084	RH PASTED GLASS 800X840 50PERC GRAY TINT	TATA spare parts
319064233087	RH PASTED GLASS 155X840 CLEAR TINT	TATA spare parts
319064233095	PASTED GLASS RH\LH_1163X1340_CLEAR	TATA spare parts
319064233119	PASTED GLASS RH	TATA spare parts
319064233121	PASTED GLASS LH/RH_1163X920_50PERC GRN	TATA spare parts
319064233122	PASTED GLASS LH_1163X1604_50PERC GRN	TATA spare parts
319064233123	PASTED GLASS LH/RH_1163X525_50PERC GRN	TATA spare parts
319064233124	PASTED GLASS LH/RH_1163X293_50PERC GRN	TATA spare parts
319064233125	PASTED GLASS LH/RH_1163X587_50PERC GRN	TATA spare parts
319064233126	PASTED GLASS EME WINDOW_878X696_50PERC	TATA spare parts
319064233144	PASTED GLASS RH(REAR)_1163X835_50PERC GR	TATA spare parts
319064233145	PASTED GLASS RH_1163X1397_50PERC GREEN T	TATA spare parts
319064233146	PASTED GLASS RH_1163X606_50PERC GREEN TI	TATA spare parts
319064233147	PASTED GLS.REAR LH_1163X1400_50PERCGREEN	TATA spare parts
319064233150	PASTED GLASS RH 1163X660 50PERC GREEN TI	TATA spare parts
319064233152	PASTED GLASS_1163X945_50% GREEN TINT	TATA spare parts
319064233153	PASTED GLASS_1163X720_50%GREEN TINT	TATA spare parts
319064233154	PASTED GLASS LH_1163X660_50% GREEN TINT	TATA spare parts
319064233155	PAS GLS RH_1163X558_50% GREEN EXT HINGE	TATA spare parts
319064233156	PASTED GLASS LH_1163X1055_50% GREEN TINT	TATA spare parts
319064233157	PASTED GLASS LH TOP 312X540 CLEAR	TATA spare parts
319064233158	PASTED GLASS RH 1300X1163 50PERC GREY TI	TATA spare parts
319064233159	PAS GLS RH LH 1150X1163 VENT 50PERCGRY T	TATA spare parts
319064233160	PAS GLS LH RH 1320X1163 50PERC GREY TINT	TATA spare parts
319064233161	PAS GLS RH LH 1320X1163 VENT 50PERCGRY T	TATA spare parts
319064233162	PAS GLS RH 1055X1163 50PERC GREY TINT	TATA spare parts
319064233163	ED PAS GLAS RH 534X1163 50PERC GREY TINT	TATA spare parts
319064233164	PAS GLAS LH 1410X1163 VENT 50PERC GRY TI	TATA spare parts
319064233165	PAS GLAS LH 1220X1163 50PERC GREY TINT	TATA spare parts
319064233166	PASTED GLASS LH 325X1163 CLEAR GLASS	TATA spare parts
319064233167	PAS GLS LH RH 1035X1163 50PERC GREY TINT	TATA spare parts
319064233168	PAS GLS RH LH 1035X1163 VENT 50PERCGRY T	TATA spare parts

319064233169	PASTED GLASS LH 1278X1163 50PERC GREY TI	TATA spare parts
319064233181	PASTED GLASS EME WINDOW 878X696 50PERC G	TATA spare parts
319064233195	PAS GLASS BEFORE ED_1163X191_50PERC_GRAY	TATA spare parts
319064233196	PAS GLS LH_478X1163_50PERC GREY TINT	TATA spare parts
319064233200	PASTED GLASS LH/RH_1163X525_50% GREY	TATA spare parts
319064233204	PAS GLAS MIDDLE TOP 1200X188 CLEAR	TATA spare parts
319064233205	PASTED GLASS RH_1163X810_EMG_50PERC GREY	TATA spare parts
319064233206	PASTED GLS 1163X525 CLEAR CERAMIC	TATA spare parts
319064233207	PASTED GLS EMG RH 1163X815 50PERC GREEN	TATA spare parts
319064233208	PAST GLASS BEFORE ED_1163X373_50% GREY	TATA spare parts
319064233209	PAS GLS_RH_1163X297_50% GREY TNT	TATA spare parts
319064233210	PASTED GLASS RH TOP-343X540 CLEAR	TATA spare parts
319064233211	PASTED GLS_EMG_RH_1163X785_50PERC GREEN	TATA spare parts
319064233212	PASTED GLASS LH EMG SINDOW 878X696	TATA spare parts
319064233213	PASTED GLS_LH-1163X1425_50PERC GREY TINT	TATA spare parts
319064233214	PASTED GLASS_LH TOP_350X1200_CLEAR	TATA spare parts
319064233215	PAST GLS LH	TATA spare parts
319064233216	PAS GLS_RH_BEF_ED_1163X251_50%GREY	TATA spare parts
319064233217	PASTED GLASS_RH_1163X414_50% GREY	TATA spare parts
319064233218	PASTED GLASS RH 1163X576 50PERC GREEN TN	TATA spare parts
319064233239	LH_PASTED_1160X1163_50PERCGREY TINT EV	TATA spare parts
319064233240	LH PASTED CLEAR FULL CERMAIC 245X1163 EV	TATA spare parts
319064233241	PASTED GLASS_RH_1300X1163_50PERCGRY BS6	TATA spare parts
319064233242	PASTED GLASS_RH_804X1163_50PERCGRY BS6	TATA spare parts
319064233243	PASTED GLASS_RH_390X1163_50PERC GRY BS6	TATA spare parts
319064233244	PASTED GLASS RH_996X1163_50PERCGRY BS6	TATA spare parts
319064233245	PASTED GLASS_RH/LH_1035X1163_50PERCGRY B	TATA spare parts
319064233246	PASTED GLASS_RH_1273X1163_50PERCGRY BS6	TATA spare parts
319064233247	PASTED GLASS_LH_1273X1163_50PERCGRY BS6	TATA spare parts
319064233248	PASTED GLASS_LH_946X1163_50PERCGRY BS6	TATA spare parts
319064233249	PASTED GLASS_LH_754X1163_50PERCGRY BS6	TATA spare parts
319064233250	PASTED GLASS_LH_1305X1163_50PERCGRY BS6	TATA spare parts
319064233251	PASTED GLASS_LH_995X1149_CLEAR GLS BS6	TATA spare parts
319064233252	PASTED GLASS_LH_490X1163_50PERCGREY BS6	TATA spare parts
319064233253	PASTED GLS_LH_790X380_50PERC GRY TINT BS	TATA spare parts
319064233254	RH PASTED GLS_ BS6	TATA spare parts
319064233257	PASTED GLS_LH_1410X1163_50PERCGREY TNT	TATA spare parts
319064233287	RH RVM PASTED GLS_706X270_FULL CERAMIC	TATA spare parts
319064233288	RH PASTED GLS_1279X1163_50PERC GRAY TINT	TATA spare parts
319064233289	LH PASTED GLS_1150X1163_50PERC GRAY TINT	TATA spare parts
319064233290	LH/RH PASTED_VENT_1150X1163_50PERC GRAY	TATA spare parts
319064233291	LH PASTED GLS_1197X1163_50PERC GRAY TINT	TATA spare parts
319064233292	LH PASTED GLS_1184X1030_50PERC GRAY TINT	TATA spare parts
319064233293	LH PASTED GLS_1222X113_FULL CERAMIC	TATA spare parts
319064233294	LH PASTED GLS_91X1163_FULL CERAMIC	TATA spare parts
319064233295	LH ABV PASS DR GLS_1200X297_FULL CERAMIC	TATA spare parts
319064233296	LH PASTED GLS_1080X1163_50PERC GRAY TINT	TATA spare parts

319064233297	LH REAR PASTED GLS_400X1163_50PERC GRAY	TATA spare parts
319064233298	LH RVM PASTED GLS_891X319_FULL CERAMIC	TATA spare parts
319064233299	RH REAR PASTED_400X1163_50PERC GRAY TINT	TATA spare parts
319064233300	DESTINATION DISPLAY GLASS GEN5 9X9	TATA spare parts
319064234002	EXT GLAS RH INT GLS LH 30% TINT 655X685	TATA spare parts
319064234003	REAR GLAS RH EXT GLS LH 30% TINT 655X685	TATA spare parts
319064234004	PASTED GLASS 1282X356 30%TINT	TATA spare parts
319064234005	EXT GLAS RH INT GLS LH 30% TINT 340X685	TATA spare parts
319064234006	INT GLAS RH EXT GLS LH 30% TINT 340X685	TATA spare parts
319064234007	PASTED GLASS 652X356 30%TINT	TATA spare parts
319064234008	INT GLAS RH EXT GLS LH 30% TINT 760X685	TATA spare parts
319064234009	EXT GLAS RH INT GLS LH 30% TINT 760X685	TATA spare parts
319064234010	PASTED GLASS 1482X356 30%TINT	TATA spare parts
319064234011	FRONT EXT GLS_RH_402X787_CLEAR	TATA spare parts
319064234012	REAR INT GLS_RH_402X787_CLEAR	TATA spare parts
319064234013	FRONT EXT GLS_RH_302X788_CLEAR	TATA spare parts
319064234014	REAR INT GLS_RH_302X788_CLEAR	TATA spare parts
319064234015	FRONT EXT GLS_RH_364/320X697_CLEAR	TATA spare parts
319064234016	REAR INT GLS_RH_320X697_CLEAR	TATA spare parts
319064234017	EXT GLAS RH INT GLS LH 30PERC TINT 445X6	TATA spare parts
319064234018	INT GLAS RH EXT GLAS LH 30PERC TINT 445X	TATA spare parts
319064234019	PASTED GLASS 862X356 30PERC TINT	TATA spare parts
319064234021	FIXED GLASS_281X1038_30 PERC TINT	TATA spare parts
319064234031	FIXED GLASS_331X1038_50%TINT	TATA spare parts
319064234032	EXT GLAS RH INT GLS LH 30% TINT 630X685	TATA spare parts
319064234033	INT GLAS RH EXT GLS LH 30% TINT 630X685	TATA spare parts
319064234034	PASTED GLASS 1232X356 30%TINT	TATA spare parts
319064234035	EXT GLAS RH INT GLS LH 30% TINT 365X685	TATA spare parts
319064234036	INT GLAS RH EXT GLS LH 30% TINT 365X685	TATA spare parts
319064234037	PASTED GLASS 702X356 30% TINT	TATA spare parts
319064234038	EXT GLAS RH_INT GLS LH_30 PERC TINT_555X	TATA spare parts
319064234039	INT GLAS RH_EXT GLS LH_30 PERC TINT_555X	TATA spare parts
319064234040	PASTED GLASS_1082X356_30 PERC TINT	TATA spare parts
319064234041	EXT GLAS RH INT GLS LH 30% TINT 530X685	TATA spare parts
319064234042	INT GLAS RH EXT GLS LH 30% TINT 530X685	TATA spare parts
319064234043	PASTED GLASS 1032X356 30% TINT	TATA spare parts
319064234044	EXT GLAS RH_INT GLS LH_30 PERC TINT_430X	TATA spare parts
319064234045	INT GLAS RH_EXT GLS LH_30 PERC TINT_430X	TATA spare parts
319064234046	PASTED GLASS_832X356_30 PERC TINT	TATA spare parts
319064234047	EXT GLS RH_INT GLS LH_30%TNT_631X673_KTC	TATA spare parts
319064234048	INT GLS RH_EXT GLS LH_30%TNT_631X673_KTC	TATA spare parts
319064234049	FIX GLASS_1211X343_30%TINT_KTC	TATA spare parts
319064234050	EXT GLS RH_INT GLS LH_30%TNT_656X673	TATA spare parts
319064234051	INT GLS RH_EXT GLS LH_30%TNT_656X673	TATA spare parts
319064234052	FIX GLASS_1261X356_30%TIN	TATA spare parts
319064234053	EXT GLS RH_INT GLS LH_30%TNT_341X673	TATA spare parts
319064234054	INT GLS RH_EXT GLS LH_30%TNT_341X673	TATA spare parts

319064234055	FIX GLASS_631X343_30%TINT	TATA spare parts
319064234056	INT GLS RH_EXT GLS LH_30%TNT_756X673	TATA spare parts
319064234057	EXT GLS RH_INT GLS LH_30%TNT_756X673	TATA spare parts
319064234058	FIX GLASS_1461X343_30% TINT	TATA spare parts
319064234062	EXT GLS RH_INT GLS LH_50%TNT_446X673	TATA spare parts
319064234063	INT GLS RH_EXT GLS LH_50%TNT_446X673	TATA spare parts
319064234064	FIXED GLASS_841X343_50% TINT	TATA spare parts
319064234065	EXT GLS RH_INT GLS LH_50%TNT_656X673	TATA spare parts
319064234066	INT GLS RH_EXT GLS LH_50%TNT_656X673	TATA spare parts
319064234067	FIX GLASS_1261X343_50% TINT	TATA spare parts
319064234068	EXT GLS RH_INT GLS LH_50%TNT_756X673	TATA spare parts
319064234069	INT GLS RH_EXT GLS LH_50%TNT_756X677	TATA spare parts
319064234070	FIX GLASS_1461X343_50%TINT	TATA spare parts
319064234079	PASTED GLASS 1285X357 50PERCTINT	TATA spare parts
319064234080	PASTED GLASS 705X357 50PERC TINT	TATA spare parts
319064234081	PASTED GLASS 1035X356 50PERCTINT	TATA spare parts
319064234082	PASTED GLASS 865X356 50PERCTINT	TATA spare parts
319064234083	FIXED GLASS 355X1062 50 PERC TINT	TATA spare parts
319064234084	FIXED GLASS 305X1062 50PERCTINT	TATA spare parts
319064234085	ET GS FR RH RR IT GLS FR LH CLR 331X471	TATA spare parts
319064234086	ET GS FR LH RR IT GLS FR RH CLR 331X471	TATA spare parts
319064234087	EXT GLAS RH INT GLS LH 30PERC TINT 448X6	TATA spare parts
319064234088	INT GLAS RH EXT GLAS LH 30PERC TINT 448X	TATA spare parts
319064234089	WIN GLS FIXED CLR 302X467	TATA spare parts
319064234090	EXTGLAS RH INTGLS LH 50 PERCGREY TNT 445	TATA spare parts
319064234091	INTGLAS RH EXTGLAS LH 50 PERCGREYTNT 445	TATA spare parts
319064234092	PASTED GLASS 862X356 50PERC GREY TINT	TATA spare parts
319064234093	EXTGLAS RH INTGLS LH 50 PERCGREYTINT 655	TATA spare parts
319064234094	REARGLAS RH EXTGLS LH 50PERC GREYTNT 655	TATA spare parts
319064234095	PASTED GLASS 1282X356 50PERC GREY TINT	TATA spare parts
319064234096	EXTGLAS RH INTGLS LH 50 PERCGREYTNT 340X	TATA spare parts
319064234097	INTGLAS RH EXTGLS LH 50 PERCGREYTNT 340X	TATA spare parts
319064234098	PASTED GLASS 652X356 50PERC GREY TINT	TATA spare parts
319064234099	INTGLAS RH EXTGLS LH 50 PERCGREYTNT 760X	TATA spare parts
319064234100	EXTGLAS RH INTGLS LH 50 PERCGREYTNT 760X	TATA spare parts
319064234101	PASTED GLASS 1482X356 50PERC GREY TINT	TATA spare parts
319064234108	EXTGLAS RHINTGLS LH30PERC TINT669X302	TATA spare parts
319064234109	INTGLS LHEXTGLAS RH30PERC TINT669X302	TATA spare parts
319064234110	EXT GLAS RHINT GLS LH30PERC TINT505X685	TATA spare parts
319064234111	INT GLAS RHEXT GLS LH30PERC TINT505X685	TATA spare parts
319064234112	PASTED GLASS982X35630PERC TINT	TATA spare parts
319064234113	EXT GLAS RHINT GLS LH30PERC TINT572X685	TATA spare parts
319064234114	INT GLAS RHEXT GLS LH30PERC TINT572X685	TATA spare parts
319064234115	PASTED GLASS1115X35630PERC TINT	TATA spare parts
319064234116	EXT GLAS RHINT GLS LH30PERC TINT613X685	TATA spare parts
319064234117	INT GLAS RHEXT GLS LH30PERC TINT613X685	TATA spare parts
319064234118	PASTED GLASS1197X35630PERC TINT	TATA spare parts

319064234119	EXT GLAS RHINT GLS LH30PERC TINT443X685	TATA spare parts
319064234120	INT GLAS RHEXT GLS LH30PERC TINT443X685	TATA spare parts
319064234121	PASTED GLASS857X35630PERC TINT	TATA spare parts
319064234122	EXT GLAS RHINT GLS LH30PERC TINT628X685	TATA spare parts
319064234123	INT GLAS RHEXT GLS LH30PERC TINT628X685	TATA spare parts
319064234124	PASTED GLASS1227X35630PERC TINT	TATA spare parts
319064234127	FIXED GLASS185X106230PERC TINT	TATA spare parts
319064234128	FRONT EXT GLS RH 402X789X5THK CLEAR	TATA spare parts
319064234129	REAR INT GLS RH 402X789X5THK CLEAR	TATA spare parts
319064234130	FRONT EXT GLS RH 302X789X5THK CLEAR	TATA spare parts
319064234131	REAR INT GLS RH 302X789X5THK CLEAR	TATA spare parts
319064234132	EXT GLS RH INT GLS LH CLEAR 655X685X5THK	TATA spare parts
319064234133	REAR GLS RH EXT GLS LH CLR 655X685X5THK	TATA spare parts
319064234134	PASTED GLASS 1282X356X5THK CLEAR	TATA spare parts
319064234135	EXT GLS RH INT GLS LH CLEAR 630X685X5THK	TATA spare parts
319064234136	INT GLS RH EXT GLS LH CLEAR 630X685X5THK	TATA spare parts
319064234137	PASTED GLASS 1232X356X5THK CLEAR	TATA spare parts
319064234138	EXT GLS RH INT GLS LH CLR 555X685X5THK	TATA spare parts
319064234139	INT GLS RH EXT GLS LH CLR 555X685X5THK	TATA spare parts
319064234140	PASTED GLASS 1082X356X5THK CLEAR	TATA spare parts
319064234141	EXT GLS RH INT GLS LH CLR 530X685X5THK	TATA spare parts
319064234142	INT GLS RH EXT GLS LH CLR 530X685X5THK	TATA spare parts
319064234143	PASTED GLASS 1032X356X5THK CLEAR	TATA spare parts
319064234147	WIN GLS_FIXED_CLR_302X415X5THK	TATA spare parts
319064234160	EXT GLAS RH_INT GLS LH_30 PERC TINT_520X	TATA spare parts
319064234161	INT GLAS RH_EXT GLS LH_30 PERC TINT_520X	TATA spare parts
319064234162	PASTED GLASS_1012X356_30 PERC TINT	TATA spare parts
319064234165	PASTED GLASS_1242X356_30PERC TINT	TATA spare parts
319064234169	WIN GLS_FIXEDCLR285X345	TATA spare parts
319064234171	FRONT EXT GLSRH870X865CLEAR	TATA spare parts
319064234172	REAR INT GLSRH552X865CLEAR	TATA spare parts
319064234179	ED WINDOW GLASSES	TATA spare parts
319064234180	ED WINDOW GLASSES	TATA spare parts
319064234187	WIN GLASS RH FS EXT_251X685_30PERC LG TI	TATA spare parts
319064234188	WIN GLASS RH RR FIX_251X685_30PERC LG TI	TATA spare parts
319064234189	PASTED GLASS_457X356_30PERC LG TINT	TATA spare parts
319064234190	EXT GLASS RH DRI.DR WINCLR601X759X5THK	TATA spare parts
319064234191	INT GLASS RH DRI.DR WINCLR338X759X5THK	TATA spare parts
319064234193	CO-DRI LH FS WIN GLASS_815X856_5MM CLEAR	TATA spare parts
319064234194	CO-DRI LH RS WIN GLASS_815X856_5MM CLEAR	TATA spare parts
319064234210	FIXED GLASS_CLEAR TYPE	TATA spare parts
319064234211	FIXED GLASS_445X1062_30 PERC TINT	TATA spare parts
319064234214	FIXED GLASS CLEAR TYPE 375 X 1062	TATA spare parts
319064234217	SIDE WINDOW GLASSES_CLEAR TYPE 682X356	TATA spare parts
319064234220	EXT GLS RH INT GLS LH CLR 623X685X5THK	TATA spare parts
319064234221	INT GLS RH EXT GLS LH CLR 623X685X5THK	TATA spare parts
319064234222	PASTED GLASS 1217X356X5THK CLEAR	TATA spare parts

319064234223	EXT GLS RH INT GLS LH CLEAR 473X685X5THK	TATA spare parts
319064234224	INT GLS RH EXT GLS LH CLEAR 473X685X5THK	TATA spare parts
319064234225	PASTED GLASS 917X356X5THK CLEAR	TATA spare parts
319064234226	FIXED GLASS 448X1062X5THK CLEAR	TATA spare parts
319064234227	EXT GLAS RH_INT GLS LH__365X685-CLR GLAS	TATA spare parts
319064234228	INT GLAS RH_EXT GLS LH_365X685_CLR_GLASS	TATA spare parts
319064234229	PASTED GLASS_705X357__CLR_GLASS	TATA spare parts
319064234230	EXT GLAS RH_INT GLS LH_CLR_GLASS_430X685	TATA spare parts
319064234231	INT GLAS RH_EXT GLS LH_CLR_GLASS_430X685	TATA spare parts
319064234232	PASTED GLASS_832X356_CLEAR_GLASS	TATA spare parts
319064234233	EXT GLS RH_INT GLS LH_CLR_GLASS_755X685	TATA spare parts
319064234234	INT GLS RH_EXT GLS LH_CLR_GLASS_755X685	TATA spare parts
319064234235	FIX GLASS_1482X356_CLR_GLASS	TATA spare parts
319064234236	EXT GLAS RH_INT GLS LH_CLR_340X685	TATA spare parts
319064234237	INT GLAS RH_EXT GLS LH_CLR_340X685	TATA spare parts
319064234238	PASTED GLASS_652X356_CLR_GLASS	TATA spare parts
319064234239	EXT GLS RH INT GLS LH CLR 488X685X5THK	TATA spare parts
319064234240	INT GLS RH EXT GLS LH CLR 488X685X5THK	TATA spare parts
319064234241	PASTED GLASS 947X356X5THK CLEAR	TATA spare parts
319064234246	FIX GLASS_1282X356_30PERC GREEN TINT_CAN	TATA spare parts
319064234247	PASTED GLASS_702X356_30PERC GREEN T_CAN	TATA spare parts
319064234248	PASTED GLASS_1043X356_30PERC GREEN T_CAN	TATA spare parts
319064234249	PASTED GLASS_1232X356_30PERCTINT_CAN	TATA spare parts
319064234251	EXTERNAL GLASS	TATA spare parts
319064234252	REAR GLASS	TATA spare parts
319064234253	FIXED GLASS	TATA spare parts
319064234254	EXTERNAL GLASS	TATA spare parts
319064234255	REAR GLASS	TATA spare parts
319064234256	FIXED GLASS	TATA spare parts
319064234257	FIXED GLASS	TATA spare parts
319064234258	FRONT SLIDING GLASS 311X777 CLEAR	TATA spare parts
319064234259	REAR SLIDING GLASS 311X777 CLEAR	TATA spare parts
319064234260	FIXED GLASS E.WINDOW_1235X1062 CLEAR	TATA spare parts
319064234262	FRNT SLIDING GLASS 311X777 50PERC GRAY T	TATA spare parts
319064234263	REAR SLIDING GLASS 311X777 50PERC GREY T	TATA spare parts
319064234264	FIXED GLASS_185X1062_50PERC GREY TINT	TATA spare parts
319064234265	FRONT SLIDING GLASS 311X777 30PERC	TATA spare parts
319064234266	FRONT SLIDING GLASS 311X777 30PERC	TATA spare parts
319064234269	EXT GLS SLDNG RH_INT GLS LH_CLR_290X685	TATA spare parts
319064234270	FIXED INT GLS RH_EXT GLS LH_CLR_290X685	TATA spare parts
319064234271	TOP FIXED GLASS 356X552 CLR	TATA spare parts
319064234272	FIXED GLASS_448X1062X5THK_30PERC GREEN T	TATA spare parts
319064234273	PASTED GLASS_1482X356_30PERCTINT_CAN	TATA spare parts
319064234289	FIXED GLASS CLEAR TYPE 115 X 1062	TATA spare parts
319064234293	FIXED GLASS	TATA spare parts
319064234295	SIDE WINDOW GLASS_CLR TYPE 685X356 F.LH	TATA spare parts
319064234296	SIDE WINDOW GLASS_CLR TYPE 685X356 F.RH	TATA spare parts

319064234318	EXT GLS RH_INT GLS LH_50PERCT_630X685X5T	TATA spare parts
319064234319	INT GLS RH_EXT GLS LH_50PERCT_630X685X5T	TATA spare parts
319064234320	FIXED GLASS LH/RH_1232X356X5THK_50PERC T	TATA spare parts
319064234340	PASTED GLASS_VENT_1163X1340_50PERC GRN	TATA spare parts
319064234371	EXT GLS LH INT GLS RH 50PERCGN TINT 655X	TATA spare parts
319064234372	EXT GLS RH INT GLS LH 50PERCGN TINT 655X	TATA spare parts
319064234373	TOP FIXED GLASS 1282X356 50PERC GREEN TI	TATA spare parts
319064234374	FRONT EXT GLASS RH 295X685 CLEAR	TATA spare parts
319064234375	REAR INT GLASS RH/LH 205X685 CLEAR	TATA spare parts
319064234376	TOP FIXED GLASS RH/LH 474X356X4	TATA spare parts
319064234384	EXT GLS LH INT GLS RH 50PERCGN TINT 755X	TATA spare parts
319064234385	EXT GLS RH INT GLS LH 50PERCGN TINT 755X	TATA spare parts
319064234386	TOP FIX GLASS 1482X356 50PERC GRN GLASS	TATA spare parts
319064234387	EXT GLS RH INT GLS LH 50PERCGN TINT 365X	TATA spare parts
319064234388	EXT GLS LH INT GLS RH 50PERCGN TINT 365X	TATA spare parts
319064234389	TOP FIX GLASS 702X356 50PERC GRN GLASS	TATA spare parts
319064234390	TOP FIX GLASS 862 X356 50PERC GRN GLASS	TATA spare parts
319064234391	FIXED WINDOW 363X1070 50PERC GREEN TNT	TATA spare parts
319064234392	FIXED GLASS 355X1062X4MM 50PERC GREEN TI	TATA spare parts
319064234393	EXT GLS RH INT GLS LH 50PERCGN TINT 310X	TATA spare parts
319064234394	EXT GLS LH INT GLS RH 50PERCGN TINT 310X	TATA spare parts
319064234395	PASSENGER DOOR HINGE WITH HANDLE	TATA spare parts
319064234402	FR EXT LH RR INT RH 530X685 50PERC GRN T	TATA spare parts
319064234403	FR EXT RH RR INT LH 530X685 50PERC GRN T	TATA spare parts
319064234404	TOP FIXED GLS LH/RH 1032X356X4 50PERC GR	TATA spare parts
319064234405	WIN GLS_FIXED_CLR_283X334X4THK	TATA spare parts
319064234406	FIXED GLASS E.WIN 865X1062 50PERC GRN TI	TATA spare parts
319064234407	FIXED GLASS 375 X 1062 50PERC GREEN TINT	TATA spare parts
319064234408	EXT GLAS LH_INT GLS RH_30PERC TINT_443X6	TATA spare parts
319064234409	EXT GLAS RH_INT GLS LH_30PERC TINT_443X6	TATA spare parts
319064234410	EXT GLAS LH_INT GLS RH_30PERC TINT_635X6	TATA spare parts
319064234411	EXT GLAS LH_INT GLS RH_30PERC TINT_635X6	TATA spare parts
319064234412	EXT GLAS RH_INT GLS LH_30PERC TINT_628X6	TATA spare parts
319064234413	EXT GLAS LH_INT GLS RH_30PERC TINT_628X6	TATA spare parts
319064234423	EXTGLAS RH_INTGLS LH_30PERCGREENTNT_250X	TATA spare parts
319064234424	INTGLAS RH_EXTGLS LH_30PERCGREENTNT_250X	TATA spare parts
319064234425	PASTED GLASS_472X356_30PERCGREEN TINT	TATA spare parts
319064234449	EXT GLS LH_RR INT GLS RH_CLEAR_524X691	TATA spare parts
319064234450	EXT GLS RH_RR INT GLS LH_CLEAR_524X691	TATA spare parts
319064234451	TOP FIXED GLASS_CLEAR_1056X338	TATA spare parts
319064234452	EXT GLS LH_RR INT GLS RH_CLEAR_609X691	TATA spare parts
319064234453	EXT GLS RH_INT GLS LH_CLEAR_609X691	TATA spare parts
319064234454	TOP FIXED GLASS_CLEAR_1226X338	TATA spare parts
319064234455	EXT GLS LH_INT GLS RH_CLEAR_457X691	TATA spare parts
319064234456	EXT GLS RH_INT GLS LH_CLEAR_457X691	TATA spare parts
319064234457	TOP FIXED GLASS_CLEAR_921X338	TATA spare parts
319064234458	FULL FIXED GLASS_CLEAR_388X1059	TATA spare parts

319064234459	EMG.WIN_SLIDING GLASS_RH_CLEAR_279X734	TATA spare parts
319064234460	EMG.WIN_SLIDING GLASS_RH_CLEAR_279X734	TATA spare parts
319064234461	EXT GLS LH_INT GLS RH_CLEAR_581X691	TATA spare parts
319064234462	EXT GLS RH_INT GLS LH_CLEAR_581X691	TATA spare parts
319064234463	TOP FIXED GLASS_CLEAR_1169X338	TATA spare parts
319064234464	EXT GLS LH_INT GLS RH_CLEAR_467X691	TATA spare parts
319064234465	EXT GLS RH_INT GLS LH_CLEAR_467X691	TATA spare parts
319064234466	TOP FIXED GLASS_CLEAR_941X338	TATA spare parts
319064234467	EXT GLS LH_INT GLS_RH_CLEAR_514X691	TATA spare parts
319064234468	EXT GLS RH_INT GLS_LH_CLEAR_514X691	TATA spare parts
319064234469	TOP FIXED GLASS_CLEAR_1036X338	TATA spare parts
319064234470	DRI.WIN_RR INT GLS_RH_CLEAR_386X744	TATA spare parts
319064234471	DRI.WIN_FRNT EXT GLS_RH_CLEAR_369X740	TATA spare parts
319065003015	WIPER MOTOR 24V DC/70NM/120W	TATA spare parts
319065003016	WASHER KIT ASSY 24V	TATA spare parts
319065004002	WIPER BUSH ASSY	TATA spare parts
319065233001	FRONT WINDSHIELD GLASS	TATA spare parts
319065233002	REAR WINDSHIELD GLASS-Y1	TATA spare parts
319065233004	FRONT WINDSHIELD GLASS BS2	TATA spare parts
319065233005	REAR WINDSHIELD GLASS-Y1 (CLEAR GLASS)	TATA spare parts
319065233008	Y1 RM FRONT WINDSHIELD_GREEN BAND	TATA spare parts
319065234001	LP Y1 FRONT WINDSHIELD	TATA spare parts
319065234002	REAR WINDSHIELD	TATA spare parts
319065234003	FRONT WINDSHIELD	TATA spare parts
319065234004	REAR WINDSHIELD	TATA spare parts
319065234007	FRONT WINDSHIELD 2550 LPO Y1	TATA spare parts
319065234008	REAR WIND SHILED WITH GREY TINTED	TATA spare parts
319065234010	REARWINDSHIELDWITHGREENTINTED	TATA spare parts
319065234016	FRONT WINDSHIELD W/O IR- GEN 5-9X9	TATA spare parts
319065234017	REAR W/S GLASS W/O IR CUT GEN 5 9X9	TATA spare parts
319065284001	LP Y1 FRONT RUBBER OUTLINE-SINGLE GLASS	TATA spare parts
319065284002	LP Y1 REAR RUBBER OUTLINE-SINGLE GLASS	TATA spare parts
319065284003	FRONT RUBBER OUTLINE-SINGLE GLASS	TATA spare parts
319065284004	REAR RUBBER OUTLINE-SINGLE GLASS	TATA spare parts
319065284005	FRONT WINDSHIELD RUBBER-2550	TATA spare parts
319065284008	FRONT WINDSHIELD RUBBER GEN 5 9X9	TATA spare parts
319068004010	3 WAY CONNECTING BRACKET DIA 43X35 MM	TATA spare parts
319068004011	3 WAY CONNECTING BRACKET DIA 35X35 MM	TATA spare parts
319068005005	LOCK PH2 -E-	TATA spare parts
319068005006	RETRACTION SPRING 50N 45 MM	TATA spare parts
319068005007	SPACER BUSH	TATA spare parts
319068005008	LIMIT SWITCH ARM DHP	TATA spare parts
319068005009	PIN	TATA spare parts
319068005010	WASHER DIN 125B	TATA spare parts
319068005011	BOLT M10X16 DIN7991	TATA spare parts
319068005015	BEARING BUSH FLANGE	TATA spare parts
319068005018	FIXATION BRACKET COVER PH2	TATA spare parts



319068005035	LOCKABLE LEFT PH2.03-05.04	TATA spare parts
319068005036	LOCKABLE RIGHT PH2.03-05.04	TATA spare parts
319068005058	GAS SPRING E-E 1500N - 100MM	TATA spare parts
319068005059	ROLLER BEARING	TATA spare parts
319068005061	LIGHT LED 24V	TATA spare parts
319068005073	BANJO SIMPLE M10X1 - PRESSURE -	TATA spare parts
319068005074	HP HOSE E-E 3/16 - 750MM	TATA spare parts
319068005076	HP HOSE E-E 3/16 - 1750MM	TATA spare parts
319068005079	CONNECTION MOTOR 30CC 90 DEG	TATA spare parts
319068005080	WANDER LEAD 3BT. P20-CANNON	TATA spare parts
319068005081	SEAL SET DIA30/32	TATA spare parts
319068005082	CHECK VALVE 1/4	TATA spare parts
319068005083	SAFETY VALVE DA 24V - DHO M18 - HYDAC	TATA spare parts
319068005084	O RING DIA 9X1.2MM	TATA spare parts
319068005085	BUSH PALLET STOP DIA10/15X7.2	TATA spare parts
319068005086	ROLL PVC DIA65/13X15	TATA spare parts
319068005087	SPRING WASHER M6	TATA spare parts
319068005088	ALLENBOLT M8X25 DIN7991	TATA spare parts
319068005089	WASHER BODY M6	TATA spare parts
319068005090	ALLENBOLT MET BOLKOP M6X12MM	TATA spare parts
319068963001	SS PEDAL OPERATED DUST BIN 5LTS	TATA spare parts
3191423	SUPPORT ROCKER LEVER	TATA spare parts
319540003024	3RH SM2L 450C1060W LB SKL CVG	TATA spare parts
319540003025	3RH SM2L 450C1060W SKL CVG	TATA spare parts
319540003026	3RH SM2L 450C1060W WA SKL CVG	TATA spare parts
319540003029	2LH SM1L 450C760W SKL CVG	TATA spare parts
319540003030	2LH SM1L 450C760W WA SKL CVG	TATA spare parts
319540003032	3RL 3LM 450C1060W LB SKL CVG	TATA spare parts
319540003033	3RH SM2L 450C1050W LB SKL HSSL	TATA spare parts
319540003034	3RH SM2L 450C1050W SKL HSSL	TATA spare parts
319540003035	3RH SM2L 450C1050W WA SKL HSSL	TATA spare parts
319540003038	2LH SM1L 450C760W SKL HSSL	TATA spare parts
319540003039	2LH SM1L 450C760W WA SKL HSSL	TATA spare parts
319540003041	3RL 3LM 450C1050W LB SKL HSSL	TATA spare parts
319540003042	3RH SM2L 450C1050W LB SKL TM	TATA spare parts
319540003043	3RH SM2L 450C1050W SKL TM	TATA spare parts
319540003044	3RH SM2L 450C1050W WA SKL TM	TATA spare parts
319540003047	2LH SM1L 450C760W SKL TM	TATA spare parts
319540003048	2LH SM1L 450C760W WA SKL TM	TATA spare parts
319540003050	3RL 3LM 450C1060W LB SKL TM	TATA spare parts
319540003183	3RH SM2LM 450C1050W 3LB SKL OR TM	TATA spare parts
319540003184	3RH SM2LM 450C1050W SKL BR TM	TATA spare parts
319540003185	3RH SM2LM 450C1050W SKL OR TM	TATA spare parts
319540003186	3RH SM2LM 450C1050W SKL YR TM	TATA spare parts
319540003187	3RH SM2LM 450C1050W SKL PR TM	TATA spare parts
319540003188	3RH SM2LM 450C1050W SKL WA BR TM	TATA spare parts
319540003189	3RH SM2LM 450C1050W SKL WA OR TM	TATA spare parts

319540003191	3RR 3LM 450C1050W SKL PR TM	TATA spare parts
319540003192	3RL 3LM 450C1050W SKL PR TM	TATA spare parts
319540003193	2LH SM1LM 450C760W SKL YR TM	TATA spare parts
319540003194	2LH SM1LM 450C760W SKL WA OR TM	TATA spare parts
319540003195	2LH SM1LM 450C760W SKL WA BR TM	TATA spare parts
319540003196	2LH SM1LM 450C760W SKL PR TM	TATA spare parts
319540003197	2LH SMLM 450C810W AR LB HB OR TM	TATA spare parts
319540003198	2LH SM1LM 450C760W SKL OR TM	TATA spare parts
319540003199	2LH SM1LM 450C760W SKL BR TM	TATA spare parts
319540003331	LH 2ST SM1L 480CH850W 2LB HB2 TM	TATA spare parts
319540003335	2RH SM1L 480C850W AR LP NHB2 RX CVG	TATA spare parts
319540003336	2RH SM1L 480C850W NHB2 RX CVG	TATA spare parts
319540003338	MID RR 2LM 480CH400W LB NHB2 RX CVG	TATA spare parts
319540003339	2LH SM1L 480C850W NHB2 RX CVG	TATA spare parts
319540003340	2LH SM1L 480C850W AR NHB2 RX CVG	TATA spare parts
319540003341	2LH SM1L 480C850W BWA NHB2 RX CVG	TATA spare parts
319540003342	2RH SM1L 480C850W BWA NHB2 RX CVG	TATA spare parts
319540003344	2LH_RR_NHB2_RX_SM1LM_480C850W_CVG	TATA spare parts
319540003345	2RH SIDE MOUNT 1LEG MOUNT 450CH850W NHB2	TATA spare parts
319540003346	2RH SIDE MOUNT 1LEG MOUNT 450CH850W NHB2	TATA spare parts
319540003349	1MID 2LEG MOUNT 480CH400W NHB2 RFB LB CVG	TATA spare parts
319540003350	2RL SIDE MOUNT 1LEG MOUNT 480C850W FB NHB2	TATA spare parts
319540003351	2LH SIDE MOUNT 1LEG MOUNT 480CH850W NHB2	TATA spare parts
319540003352	2RR 2LEG MOUNT 480C850W NHB2 CVG BS-14	TATA spare parts
319540003353	2LH SIDE MOUNT 1LEG MOUNT 480C850W NHB2	TATA spare parts
319540003354	2RH SIDE MOUNT 1LEG MOUNT 480C850W NHB2	TATA spare parts
319540003382	4RR 3LM 450C1060W 4LB SKL TM	TATA spare parts
319540003383	4RR 3LM 450C1060W 4LB SKL HSSL	TATA spare parts
319540003384	4RR 3LM 450C1060W 4LB SKL CVG	TATA spare parts
319540003385	2RH 2LM_PMS_460CH810W_BS-13 FAB_CVG	TATA spare parts
319540003386	2RH_2LM_PMS_190CH810_BS-13 FAB_CVG	TATA spare parts
319540003388	1RM 2LM_PMS_460CH810W_LB_BS-13 FAB_CVG	TATA spare parts
319540003390	2LH 2LM_PMS_460CH810W_BS-13 FAB_CVG	TATA spare parts
319540003391	2LH_2LM_PMS_190CH810_BS-13 FAB_CVG	TATA spare parts
319540003394	1LH_2LM_PMS_360CH810_AR_BS-13 FAB_CVG	TATA spare parts
319540003395	2LH SM1L 450C760W 1LB SKL TM	TATA spare parts
319540003396	2LH SM1L 450C760W 1LB SKL HSSL	TATA spare parts
319540003397	2LH SM1L 450C760W 1LB SKL CVG	TATA spare parts
319540003398	2RR 2LM 485CH850W VN HB2 TM	TATA spare parts
319540003410	MID 1SEAT 2LEG MOUNT 450CH TYP-2 LB AR C	TATA spare parts
319540003411	MID 1SEAT 2LEG MOUNT LB 450CH TYP-2 AR H	TATA spare parts
319540003412	MID 1SEAT 450CH TYP-2 2LM LB AR TM HB	TATA spare parts
319540003454	2RH 2L 460C810W STER	TATA spare parts
319540003455	2LHRH 2L 360C810W STER	TATA spare parts
319540003457	1MID 2L 460C400W LP STER	TATA spare parts
319540003460	2LH 2L 460C810W LB STER	TATA spare parts
319540003461	2RH 2L 460C810W AR STER	TATA spare parts

319540003462	2RH 2L 460C810W LP STER	TATA spare parts
319540003463	2LH/RH 2L 515C810W STER	TATA spare parts
319540003465	1LH 360C400W WA AR STER	TATA spare parts
319540003468	1LH SIDE MOUNT 1LEG MOUNT 480CH410W NHB	TATA spare parts
319540003475	2LH_RR_NHB2 RX 2LM_480C850W_CVG	TATA spare parts
319540003507	1LH 2LM 460C410W AR LB HB1 BS-13 TM	TATA spare parts
319540003518	2RH_2LM_475C1220W_AR_LB_FBLTR_PB_MMG	TATA spare parts
319540003519	2RH_2LM_345C1220W_AR_LB_WA_FBLTR_PB_M	TATA spare parts
319540003522	1LH_2LM_475C6500W_AR_LB_FBLTR_PB_MMG	TATA spare parts
319540003523	1LH_2LM_345C650W_AR_LB_WA_FBLTR_PB_MN	TATA spare parts
319540003530	2RH SM1L 450C850W HB1 AR TM	TATA spare parts
319540003534	2RH SM1L 460C850W AR HB1 BS-13 TM	TATA spare parts
319540003535	2RR 2LM 460C850W HB1 BS-13 TM	TATA spare parts
319540003536	2LH SM1L 460C850W AR HB1 BS-13 TM	TATA spare parts
319540003537	2LH SM1L 460C850W AR 1LB HB1 BS-13 TM	TATA spare parts
319540003538	1LH SM1L 360C410W AR HB1 BS-13 TM	TATA spare parts
319540003539	2RH SM1L 460C850W 2PLB HB1 TM	TATA spare parts
319540003540	2RH 2LM 460C850W 2PLB HB1 TM	TATA spare parts
319540003542	2RL SM1L 460C850W 2PLB HB1 TM	TATA spare parts
319540003543	2LH SM1L 460C850W 2PLB HB1 TM	TATA spare parts
319540003544	1LH SM1LM_450CH410W_HB_LB_AR_Y1_TM	TATA spare parts
319540003548	3RH SM2L 480CH1200W AR LP NHBII RX CVG	TATA spare parts
319540003549	3RH SM2L 480C1200W NHBII REXINE CVG	TATA spare parts
319540003550	RR 3LH SM2L 480CH1200W NHBII REX CVG	TATA spare parts
319540003551	3RH SM2L 480C1200W BWA NHBII RX CVG	TATA spare parts
319540003552	RR 3RH SM2L 480CH1200W NHBII REX CVG	TATA spare parts
319540003553	2RH_2LM_490CH1025W_HCF_AR_LB_BS14_HSSL	TATA spare parts
319540003554	2RH_2LM_490CH1025W_HCF_AR_BS14_HSSL	TATA spare parts
319540003555	2RH_2LM_360CH1025W_HCF_AR_WH_BS14_HS	TATA spare parts
319540003559	1LH_2LM_490CH535W_HCF_AR_BS14_HSSL	TATA spare parts
319540003572	2LH SM1L 480C850W NHB2 ARLB BS13 FB CVG	TATA spare parts
319540003576	RR_3LH_SM2L_480CH1200W_NHB2_BS14_RFB_C	TATA spare parts
319540003592	2RH 2LM_PMS_460CH810W_AR_2LB_BS-13_CVG	TATA spare parts
319540003593	2LH 2LM_PMS_460CH810W_AR_LB_BS-13_CVG	TATA spare parts
319540003594	RH_2S_500CH810W_2LM_AR_PMS_BS-13_CVG	TATA spare parts
319540003596	2RH 2LM 475CH1025W AR MARR REX HSSL MGN	TATA spare parts
319540003597	2RH 2LM 365C1025W AR WA MARR REX HSL MG	TATA spare parts
319540003598	2RH 2LM 475C1025W AR WOFR MAR RX HSL MG	TATA spare parts
319540003599	2LH 2LM 475C1025W AR 2PLB WOFR MARR HMG	TATA spare parts
319540003600	1LH 2LM 475C555W AR MARR REX HSSL MGN	TATA spare parts
319540003601	1LH 2LM 365C555W AR WA MARR REX HSSL MGN	TATA spare parts
319540003602	2RH 2LM 190CH810W WH BJ1000 BLUE REX_CVG	TATA spare parts
319540003603	2LH 2LM 190CH810W WH BJ1000 BLUE REX_CVG	TATA spare parts
319540003604	2RH 2LM 500CH810W BJ1000 BLUE REX_CVG	TATA spare parts
319540003605	2LH 2LM 500CH810W BJ1000 BLUE REX_CVG	TATA spare parts
319540003606	2RH 2LM 475C1025W AR 2PL MARR RX HSL MGN	TATA spare parts
319540003607	1LH 2LM 475C555W AR 2PLB MARR RX HSL MGN	TATA spare parts

319540003608	2LH_2LM_460C810W_AR_BJ1000 BLUE REX_CVG	TATA spare parts
319540003609	2RH_2LM_460CH810W_AR_BJ1000 BLUE REX_CV	TATA spare parts
319540003610	2RH_285C1220W_AR_LB_RLB_FBLTR_PB_MMG	TATA spare parts
319540003611	1LH_285C650W_AR_LB_FBLTR_PB_MMG	TATA spare parts
319540003612	2RH SM1L 480C850W AR LP NHB2 RX TM	TATA spare parts
319540003613	2RH SM1L 480C850W NHB2 RX TM	TATA spare parts
319540003615	MID RR 2LM 480CH400W LB NHB2 RX TM	TATA spare parts
319540003616	2LH SM1L 480C850W NHB2 RX TM	TATA spare parts
319540003617	2LH SM1L 480C850W AR NHB2 RX TM	TATA spare parts
319540003618	2LH SM1L 480C850W BWA NHB2 RX TM	TATA spare parts
319540003619	2RH SM1L 480C850W BWA NHB2 RX TM	TATA spare parts
319540003621	2LH_RR_NHB2 RX_SM1LM_480C850W_TM	TATA spare parts
319540003622	2LH_RR_NHB2 RX 2LM_480C850W_TM	TATA spare parts
319540003623	2RH 450CH850W_NHB2_SM1LM_AR_LB_TM_BS-	TATA spare parts
319540003624	2RH 450CH850W_NHB2_SM1LM_RFB_AR_TM	TATA spare parts
319540003627	1MID 480CH400W_NHB2_RFB_2LM_LB_TM_BS-	TATA spare parts
319540003628	2RL SM1LM 480C850W FB_NHB2 TM BS-14	TATA spare parts
319540003629	2LH 480CH850W_NHB2_SM1LM_AR_TM_BS-14	TATA spare parts
319540003630	2LH_SM1LM_480C850W_NHB2_BS-14_BWA_AR	TATA spare parts
319540003631	2RH 480C850W_NHB2_SM1LM_BS-14_BWA_AR	TATA spare parts
319540003632	2RR 2LM 480C850W NHB2 TM_BS-14	TATA spare parts
319540003633	2RR_SM1L_460C850W_2PLB_HBI_CVG	TATA spare parts
319540003641	1LH_SM1L_360CH410W_LB_AR_REX_HBI_CVG	TATA spare parts
319540003643	2RH_2LM_460C810W_2LB_AR_PMS_CUS_REX_C	TATA spare parts
319540003644	2RH_2LM_460810W_PMS_CUS_REX_CVG	TATA spare parts
319540003645	2RH_2LM_360CH810W_W/H_PMS_CUS_REX_CV	TATA spare parts
319540003646	2RH_2LM_460CH810W_AR_LB_PMS_CUS_REX_C	TATA spare parts
319540003647	2LH_2LM_460C810W_1LB_AR_PMS_CUS_REX_C	TATA spare parts
319540003648	RR_5S_450C2400W_AR_3PL_USB_FBLTR_MGM	TATA spare parts
319540003649	1LH SM1LM 360C400W LB AR WA GFB NHBI CVG	TATA spare parts
319540003650	2LH SM1L 460CH850W AR 1LB GFB NHBI CVG	TATA spare parts
319540003651	2RH 2LM 360C940W WH AR LB BLFB PB PN	TATA spare parts
319540003652	RR 2RH 205C870W AR LB RLB BLFB PB PN	TATA spare parts
319540003653	RR 1MID 205C400W AR LB RLB BLFB PB PN	TATA spare parts
319540003654	RR 2LH 205C870W AR LB RLB BLFB PB PN	TATA spare parts
319540003655	1LH 2LM 460C940W AR LB BLFB PB PN	TATA spare parts
319540003656	2LH 2LM 360C940W WH AR LB BLFB PB PN	TATA spare parts
319540003658	2RH_2LM_490CH1025W_HCF_AR_LB_BS14_HSS	TATA spare parts
319540003659	1LH_2LM_360CH535W_HCF_AR_WH_BS14_HSS	TATA spare parts
319540003660	RR_2LH_2LM_490C1025_HCF_AR_1LB_BS14_HSS	TATA spare parts
319540003671	2RH SM1LM 485CH850 NHB2 AR 3PLB CVG	TATA spare parts
319540003672	2RR SM1LM 485C850W 3PLB BS-13 NHB2 CVG	TATA spare parts
319540003673	2RL 2LM 485C850W 3PLB FB BS-13 NHB2 CVG	TATA spare parts
319540003674	1RM 2LM 485C410W 3PLB FB BS-13 NHB2 CVG	TATA spare parts
319540003675	2LH 2LM 480CH850 NHB2 FB-13 AR 3PB CVG	TATA spare parts
319540003676	2LHRH 2L 515C810W REX STER	TATA spare parts
319540003677	2LHRH 2L 460C810W REX STER	TATA spare parts

319540003678	2LHRH 2L 360C810W REX STER	TATA spare parts
319540003679	2RH 2L 460C810W AR REX STER	TATA spare parts
319540003680	2LH 2L 460C810W LP AR REX STER	TATA spare parts
319540003681	2LHRH 2L 460C810W LP REX STER	TATA spare parts
319540003682	1MID 2L 460C400W LP AR REX STER	TATA spare parts
319540003687	2RH 2L 510C810W AR STER	TATA spare parts
319540003688	2RH 2L 415C810W WA AR STER	TATA spare parts
319540003689	2RH 2L 415C810W LB AR STER	TATA spare parts
319540003690	2LH 2L 415C810W AR STER	TATA spare parts
319540003691	2LH 2L 510C810W AR STER	TATA spare parts
319540003692	2LH 2L 415C810W WA AR STER	TATA spare parts
319540003693	2RH 2LM 475C1015W AR LB BLFB PB HM	TATA spare parts
319540003694	2LH 2LM 475C1015W AR LB BLFB PB HM	TATA spare parts
319540003695	2LH 2LM 360C1015W WA AR LB BLFB PB HM	TATA spare parts
319540003696	2RH 2LM 360C1015W WA AR LB BLFB PB HM	TATA spare parts
319540003697	5R 4LM 475C2400W AR LB BLFB PB HM	TATA spare parts
319540003738	3RH SM2L 450C1050W LB WA SKL CVG	TATA spare parts
319540003739	3RL 3LM 450C1060W LB SKL CVG	TATA spare parts
319540003740	2LH SM1L 450C760W LB SKL CVG	TATA spare parts
319540003741	2LH SM1L 450C760W LB WA SKL CVG	TATA spare parts
319540003751	2LH_2LM_465C865W_AR_LB_PMS_CVG	TATA spare parts
319540003752	2LH_2LM_465C865W_2ARLB_PMS_CVG	TATA spare parts
319540003753	2RH/LH_2LM_465CH865W_LB_PMS_CVG	TATA spare parts
319540003754	1RR_2LM_465CH410W_LB_PMS_CVG	TATA spare parts
319540003768	3RR SM2L 480C1200W HB2 FB 3LB BS14 CVG	TATA spare parts
319540003777	3RR 3LM 480C1170W 3LB NHBT2_FB_RX_CVG BS6	TATA spare parts
319540003778	3RL 3LM 480C1170W LB NHBT2_FB_RX_CVG BS6	TATA spare parts
319540003786	2RH SM1LM 480C850W AR LB NHBT2_FB_RX_CVG	TATA spare parts
319540003789	2LH SM1LM 480C850W AR LB NHBT2_FB_RX_CVG	TATA spare parts
319540003831	2RH SM1L 480C850W LB AR NHB2 BS-13 CVG	TATA spare parts
319540003832	1RH SM1L 360C410W NHBT2 AR LB BS13FB CVG	TATA spare parts
319540003835	5RR3LM 160C2045W 1LB BS13 FB CVG	TATA spare parts
319540003848	2LH SM1L 480C850W AR NHB2 BS-13 CVG	TATA spare parts
319540003849	2RH SM1L 480C850W AR NHB2 BS-13 CVG	TATA spare parts
319540003850	1LH SM1L 360C410W NHBT2 AR LB REX CVG	TATA spare parts
319540003851	1LH SM1L 360C410W NHBT2 AR LB REX TM	TATA spare parts
319540003859	2RH 2LM 430C810W TM EV	TATA spare parts
319540003862	1MID 2L 430C400W AR LP TM EV	TATA spare parts
319540003864	2RH 2LM 430C810W LB TM EV	TATA spare parts
319540003877	2LH SM1L 460C850W AR LB FB NHBT2 TM BS14	TATA spare parts
319540003925	2RH SM1L 460C850W LB NHBT2 REX CVG	TATA spare parts
319540003926	2RR 2L 460C850W LB NHBT2 REX CVG	TATA spare parts
319540003927	2RL SM1L 460C850W LB NHBT2 REX CVG	TATA spare parts
319540003928	2LH SM1L 460C850W LB NHBT2 REX CVG	TATA spare parts
319540003929	2RH SM1L 460C850W LB NHBT2 REX TM	TATA spare parts
319540003930	2RR 2L 460C850W LB NHBT2 REX TM	TATA spare parts
319540003931	2RL SM1L 460C850W LB NHBT2 REX TM	TATA spare parts

319540003932	2LH SM1L 460C850W LB NHBT2 REX TM	TATA spare parts
319540003992	2LH 2LM 430C810W 2LB AR W/O.CUSH_TM BS6	TATA spare parts
319540003993	2LH/RH 2LM 490C810W W/O.CUSH_TM BS6	TATA spare parts
319540003994	2LH/RH 2LM 430C810W W/O.CUSH_TM BS6	TATA spare parts
319540003995	1REAR MID 2LM 430C410W 1LB W/O.CUSH_TM BS6	TATA spare parts
319540003996	2RH 2LM 430C810W 2LB AR W/O.CUSH_TM BS6	TATA spare parts
319540003997	2LH/RH 2LM 350C810W 2LB W/O.CUSH_TM BS6	TATA spare parts
319542363007	UPPERFRONT ELECTRIC HARNESS	TATA spare parts
319552303001	CLUTCH FLUID LID	TATA spare parts
319552303002	PARTITION DOOR HANDLE	TATA spare parts
3200782	PLATE COVER	TATA spare parts
3201562	SEAL O RING	TATA spare parts
3202925082	RUBBER COVER	TATA spare parts
3204270226	PAWL HANDLE	TATA spare parts
320500250001	REAR FRP INNER PANEL - 4 TONNER	TATA spare parts
320500260001	FRONT FRP INNER PANEL - 4 TONNER	TATA spare parts
320500340001	FRP FRONT ROOF INNER PANEL	TATA spare parts
32055	SOLENOID VALVE	TATA spare parts
3209885071	WIRE LEAD	TATA spare parts
3209900077	LOCKING PIN	TATA spare parts
3209900601	HEX SCREW	TATA spare parts
3209930601	PRESSURE SPRING	TATA spare parts
3210180040DB	BRACKET	TATA spare parts
3210331201	MAIN BEARING STD	TATA spare parts
3210331202	MAIN BEARING	TATA spare parts
3210331301	MAIN BRG UPP HALF STDI	TATA spare parts
3210331302	MAIN BRG L/HALF	TATA spare parts
3210331401	M.B.SHELL UPPER RS-1	TATA spare parts
3210331402	MAIN BRG R/S I	TATA spare parts
3210331408	MAIN BRG R/S 1	TATA spare parts
3210331501	MAIN BRG R/S II	TATA spare parts
3210331502	MAIN BRG HALF LOWER REPAIR SIZE II	TATA spare parts
3210331602	MAIN BRG HALF LOWER REPAIR SIZE III	TATA spare parts
3210331701	MAIN BRG HALF UPPER REPAIR SIZE IV	TATA spare parts
3210331702	MAIN BRG HALF LOWER REPAIR SIZE IV	TATA spare parts
3210380010	CON BRG STD	TATA spare parts
3210380071	SCREW CON ROD	TATA spare parts
3210380110	CONN ROD BRG SHELL HALF NORMAL I	TATA spare parts
3210380210	CON BRG R/S I	TATA spare parts
3210380310	CON BRG R/S II	TATA spare parts
3210380850	BUSH R/S IV	TATA spare parts
3210381050	CONNECTING ROD BUSH	TATA spare parts
3210381150	BUSH R/S I	TATA spare parts
3210381250	BUSH R/S II	TATA spare parts
3210510112	BEARING CAMSHAFT 3	TATA spare parts
3210530705	VALVE EXHAUST	TATA spare parts
3210530705DB	VALVE EXHAUST	TATA spare parts

3210530801	VALVE INLET	TATA spare parts
3211300017	ASSY.PISTON NORMAL	TATA spare parts
3211300116	CON ROD 94D	TATA spare parts
3211300117	PISTON W/RING STD1 77D AC	TATA spare parts
3211300217	PISTON W/RING STD2 77D AC	TATA spare parts
3211300271	INSL A-ENG MTG FRT	TATA spare parts
3211300416	ASSY. A.C. CONNECTING ROD WITH CAP	TATA spare parts
3211300516	ASSY CON. ROD W/O BRG	TATA spare parts
3211310050	CONNECTING ROD BUSH	TATA spare parts
3211310079	GASKET 0.25 MM	TATA spare parts
3211310102	SLEEVE CYLINDER STD 70D	TATA spare parts
3211310171	CON ROD SCREW.	TATA spare parts
3211310179	GASKET CYLINDER SLEEVE CYL BLOCK	TATA spare parts
3211310202	SLEEVE CYLINDER STD1 70D	TATA spare parts
3211310217	CONNECTING ROD	TATA spare parts
3211310302	SLEEVE CYLINDER STD2 70D	TATA spare parts
3211311333	CON ROD BEARING STD	TATA spare parts
3211420201	EXHAUST MANIFOLD	TATA spare parts
3211550235	SUPPORT GEN	TATA spare parts
3211590320	BAR CONTACT FRONT	TATA spare parts
3211590420	BAR CONTACT CENTRE	TATA spare parts
3211800072	LOCK PLATE-ENGINE MOUNTING FRT	TATA spare parts
321180137A	BRKT-ENG MTG FRT FRAME	TATA spare parts
321180138A	MASCOT	TATA spare parts
321180139A	BRKT-ENG MTG FRT LWR	TATA spare parts
321180140A	BRKT-FRT MTG ENG SIDE LH	TATA spare parts
321180141A	BRKT-FRT MTG ENG SIDE LH	TATA spare parts
3211801480	BRKT-ENG MTG FRT ENG LH	TATA spare parts
3211801490	BRKT-ENG MTG FRT ENG RH	TATA spare parts
3211801500	BRKT-ENG MTG FRT LWR	TATA spare parts
3211801651	BRKT-FRT MTG ENG SIDE LH	TATA spare parts
3211801661	BRKT-FRT MTG ENG SIDE RH	TATA spare parts
3211801670	BRKT-ENG MTG FRT LWR (NOT IN FRAME LKD)	TATA spare parts
3211801680	BRKT-ENG MOUNTING FRT FRAME LH	TATA spare parts
3211801690	BRKT-ENG MOUNTING FRT FRAME RH	TATA spare parts
3211802380	BRKT ENG MTG FRT FRAME LH	TATA spare parts
3211802390	BRKT ENG MTG FRT FRAME RH	TATA spare parts
3211810042	PLUNGER (FOR OIL PRESSURE RELIEF VALVE)	TATA spare parts
3211880179	GASKET	TATA spare parts
3212030182	HOSE PIPE	TATA spare parts
3212600086	THREADED BUSH	TATA spare parts
3212600469	RETURN SPRING WITH WASHER	TATA spare parts
3212600723	SHIFTER LEVER 1ST 1210SD	TATA spare parts
3212600846	STOP PLATE BS1/2/3/4	TATA spare parts
3212601430	ASSY SELECTOR FORK - SHAFT 1ST SPEED BS6	TATA spare parts
3212602930	ASSY SELECTOR FORK - SHAFT 2-3RD SPEED B	TATA spare parts
3212610031	...ADAPTER	TATA spare parts

3212610318	G B HSG COVER FRONT TOP	TATA spare parts
3212610333	COVER REAR FOR PTO	TATA spare parts
3212610779DB	GASKET	TATA spare parts
3212611705DB	COVER	TATA spare parts
3212611979DB	GASKET	TATA spare parts
3212620073	LOCKING PLATE	TATA spare parts
3212620313DB	HELICAL GEAR	TATA spare parts
3212620374	PIN MAIN SHAFT	TATA spare parts
3212620462	BUTTING RING MAIN SHAFT 7.40 THICK	TATA spare parts
3212620562	BUTTING RING 7.50 MM	TATA spare parts
3212620662	BUTTING RING 7.60 MM	TATA spare parts
3212620674	RETAINING PIN 1ST SPEED	TATA spare parts
3212620723	SHIFTER SLEEVE 1ST SPEED BS1/2/3/4	TATA spare parts
3212620762	BUTTING RING 7.70 MM	TATA spare parts
3212620774	RETAINING PIN	TATA spare parts
3212620823	SHIFTER SLEEVE 2/3 4/5 SP (45T)BS1/2/3/4	TATA spare parts
3212620823AE	SHIFTING SLEEVE 713	TATA spare parts
3212620823DF	SHIFTER SLEEVE 2/3-4/5 SPEED 45T - GB40	TATA spare parts
3212620862	BUTTING RING 2.90 MM	TATA spare parts
3212620940	CARRIER 1ST SPEED	TATA spare parts
3212620962	BUTTING RING 3.00 MM	TATA spare parts
3212621040	CARRIER	TATA spare parts
3212621050DB	COLLAR BUSH	TATA spare parts
3212621062	BUTTING RING 3.10MM	TATA spare parts
3212621162	BUTTING RING	TATA spare parts
3212621262	BUTTING RING 3.30 MM	TATA spare parts
3212621362	SPACER WASHER 3.4MM	TATA spare parts
3212621462	BUTTING RING	TATA spare parts
3212621762	BUTTING RING 7.30 MM	TATA spare parts
3212621862	BUTTING RING 7.20 MM	TATA spare parts
3212621962	BUTTING RING 7.10 MM	TATA spare parts
3212622062	BUTTING RING 7.00 MM	TATA spare parts
3212622162	BUTTING RING 6.9MM THICK	TATA spare parts
3212622562	BUTTING RING 7.80 MM	TATA spare parts
3212622662	BUTTING RING 7.90 MM	TATA spare parts
3212622762	BUTTING RING 8.0 MM.THICK	TATA spare parts
3212622862	BUTTING RING 7.45 MM	TATA spare parts
3212622962	BUTTING RING 7.55 MM	TATA spare parts
3212623062	BUTTING RING 7.65 MM	TATA spare parts
3212630450	BUSH	TATA spare parts
3212640153	SPACER	TATA spare parts
3212640174	PIN /1210 SA 42	TATA spare parts
3212640532	SHAFT SPEEDOMETER DRIVE	TATA spare parts
3212640631	PINION SPEEDOMETER DRIVE	TATA spare parts
3212650016DB	PRESSURE PIECE	TATA spare parts
3212650050DB	BUSHING	TATA spare parts
3212650123	SHIFTER FORK 1	TATA spare parts



3212650148	INTERLOCK PIN CHECK PLATE	TATA spare parts
3212650150	BUSH INTERLOCK DEVICE	TATA spare parts
3212650208	INT.LEVER.REV.GR. GBS-40 GEAR.BOX	TATA spare parts
3212650250	BUSH	TATA spare parts
3212650403	SHIFTER FORK REV SPEED	TATA spare parts
3212650416	PRESSURE PIECE CHECK PLATE	TATA spare parts
3212650702DB	SHIFT FORK 2/3	TATA spare parts
3212650805	SELECTOR.SHAFT.1SI.SP BS4	TATA spare parts
3212650849	SLIDING KEY	TATA spare parts
3212651202	SHIFTER FORK 2/3 SPEED BS1/2/3/4	TATA spare parts
3212651301	SHIFTER FORK 1ST SPEED BS4	TATA spare parts
3212651805	SELECTOR.SHAFT 2/3 BS4	TATA spare parts
3212651905	SELECTOR.SHAFT 4/5 BS4	TATA spare parts
3212670025	SLIDE PIN.	TATA spare parts
3212900524	PEDAL PLATE BRAKE & CLUTCH	TATA spare parts
3212900816	CLUTCH PEDAL LEVER	TATA spare parts
3213120087	GUSSET PLATE LH	TATA spare parts
3213120187	GUSSET PLATE RH	TATA spare parts
3213200278	BRACKET UPPER	TATA spare parts
3213210112	LEAF SPRING 2ND	TATA spare parts
3213220249DF	BUSH KING PIN	TATA spare parts
3213250041	SUPPORT PLATE	TATA spare parts
321325004160	REINFORCEMENT PLATE_UNPAINTED BS6	TATA spare parts
3213310344	RUBBER BUFFER	TATA spare parts
3213320249	BUSH	TATA spare parts
3213320362	TH WASHER UPPER STD	TATA spare parts
3213320462	TH WASHER LOWER STD	TATA spare parts
3213320762	TH WASHER BRASS	TATA spare parts
3213320862	TH WASHER BRASS	TATA spare parts
3213320962	TH WASHER STEEL	TATA spare parts
3213321062	TH WASHER STEEL	TATA spare parts
3213321162	TH WASHER UPPER STD1	TATA spare parts
3213321262	TH WASHER LOWER STD1	TATA spare parts
3213340051	SPACER RING	TATA spare parts
3213340115	SPACER LEFT	TATA spare parts
3213340125	WHEEL CAP	TATA spare parts
3213340215	SPACER R H	TATA spare parts
3213510825	U CLAMP	TATA spare parts
3213530025	THREADED RING LH	TATA spare parts
3213530062	THRUST WASHER	TATA spare parts
3213530062AE	THRUST WASHER 1.95 MM THICK 715	TATA spare parts
3213530162	THRUST WASHER	TATA spare parts
3213530162AE	THRUST WASHER 2.00 MM THICK 715	TATA spare parts
3213530220	DIFFERENTIAL SPIDER BS1/2/3/4/6	TATA spare parts
3213530220AE	DIFFERENTIAL SPIDER 715	TATA spare parts
3213530262	THRUST WASHER 2.07 MM	TATA spare parts
3213530362	THRUST WASHER 2.13MM	TATA spare parts

3213530462	THRUST WASHER 2.15MM TH	TATA spare parts
3213530562	THRUST WASHER 2.20 MM	TATA spare parts
3213530662	THRUST WASHER 2.30 MM	TATA spare parts
3213530762	THRUST RING	TATA spare parts
3213560026	LOCKING RING	TATA spare parts
3213560051	SPACER	TATA spare parts
3213560082	OIL CATCHER	TATA spare parts
3213560173	LOCKING PLATE	TATA spare parts
3213570082	OIL SEAL	TATA spare parts
3214101901	PROP SHAFT FRONT	TATA spare parts
3214102101	PROP SHAFT FRONT	TATA spare parts
3214102301	PROP SHAFT FR W/CEN BRG	TATA spare parts
3214102401	PROP SHAFT	TATA spare parts
3214200130	BRAKE TUBE	TATA spare parts
3214200131	ASY BRAKE TUBE	TATA spare parts
3214200176	FORK	TATA spare parts
3214200228	BRAKE TUBE	TATA spare parts
3214200229	BRAKE TUBE	TATA spare parts
3214210310	BRAKE LINING FR STD	TATA spare parts
3214210410	BRAKE LINING RS1	TATA spare parts
3214210510	BRAKE LINING RS2	TATA spare parts
3214230020	DUST SHIELD	TATA spare parts
3214296602DB	AIR PR PIPE	TATA spare parts
3214300140	STRAP AIR CONTAINER	TATA spare parts
3214600911	SECTOR SHAFT	TATA spare parts
3214601005	DRAG LINK ASSY	TATA spare parts
3214601105	DRAG LINK ASSY	TATA spare parts
3214601302	STEERING HOUSING	TATA spare parts
3214601305	DRAG LINK ASSY	TATA spare parts
3214610162	THRUST WASHER	TATA spare parts
3214610350	BUSH	TATA spare parts
3214610350DB	BUSH	TATA spare parts
3214610450DB	BUSH R/S I	TATA spare parts
3214610480	GASKET	TATA spare parts
3214610880	GASKET	TATA spare parts
3214620165	RETAINING RING	TATA spare parts
3214620171	ADJUSTING SCREW	TATA spare parts
3214620185	PRESSURE TUBE	TATA spare parts
3214620250	BUSH	TATA spare parts
3214620437	BALL SOCKET	TATA spare parts
3214634801	PITMAN ARM	TATA spare parts
3215300752	REBOUND RING-ENG MOUNTING RR	TATA spare parts
3215300800	INSL-ENG MTG RR	TATA spare parts
3215802410	BRACKET-ENG MTG RR LOWER	TATA spare parts
3215802411	BRACKET-ENG MTG RR LOWER	TATA spare parts
3215802850	BRKT-ENG MTG RR FRAME	TATA spare parts
3215802860	BRKT-ENG MTG RR FRAME	TATA spare parts

3215802940	BRKT-ENG MTG F/W HSG	TATA spare parts
3215802950	BRKT-ENG MTG F/W HSG	TATA spare parts
3215861403DB	M BRG SET R/S 1	TATA spare parts
3215861703DB	M BRG SET R/S 2	TATA spare parts
3215862003DB	M BRG SET R/S 3	TATA spare parts
3215862703DB	CON BRG SET RS2	TATA spare parts
3215890021	DIAL GAUGE HOLDER	TATA spare parts
3215890035	SLEEVE	TATA spare parts
3215890039	DRIFT	TATA spare parts
3215890061	REAMING SET	TATA spare parts
3215890131	HOLDER	TATA spare parts
3215890135	DRIFT	TATA spare parts
3215890137	RING PISTON A.C.PLIER	TATA spare parts
3215890207	SPECIAL WRENCH	TATA spare parts
3215890237	RING PISTON A.C.PLIER	TATA spare parts
3215890339	ARBOR	TATA spare parts
3215890415	DRIFT	TATA spare parts
3215890421	CHECKING DEVICE	TATA spare parts
3215890433	PULLER	TATA spare parts
3215890435	SUPPORT	TATA spare parts
3215890439	DRIFT	TATA spare parts
3215890463	DIAL GAUGE HOLDER	TATA spare parts
3215890507	PRONGED WRENCH	TATA spare parts
3215890515	DRIFT	TATA spare parts
3215890607	SPECIAL WRENCH	TATA spare parts
3215890639	DRIFT	TATA spare parts
3215890733	SPINDLE	TATA spare parts
3215891233	EXTRACT DEVICE	TATA spare parts
3215891433	PULLER	TATA spare parts
3215891533	PULLER	TATA spare parts
32180507	Tipping Valve O Ring	TATA spare parts
32180516	Adaptor 3/4INCH BSP Mx 1-3/16INCH UNF ORS	TATA spare parts
32180610	ADAPTOR 1INCH BSP(M)X1 3/16INCH	TATA spare parts
32180620	ADAPTOR 1INCH BSP(M)X1 7/16INCH	TATA spare parts
32180720	ADAPTOR 1 1/4INCH BSP(M)X1 7/16INCH	TATA spare parts
32180820	Adaptor 1 1/2INCH BSP Male x1-7/6INCH UN	TATA spare parts
3219-Y-C025	BRAKE DRUM	TATA spare parts
32190421	ADAPTOR M33X2X1*7/16INCH UNF	TATA spare parts
32191016	ADAPTOR M22X1.5X1 3/16INCH UNF	TATA spare parts
32191110	Adaptor M26x1-1/2INCHx1-3/16INCH UNF ORS	TATA spare parts
32191720	Adaptor 1INCH BSP Male X M39	TATA spare parts
3219900050	COLLAR NUT M12X1.75	TATA spare parts
3219900096	HALF ROUND RIVET	TATA spare parts
3219900251	SPECIAL NUT M-6	TATA spare parts
3219900251DB	NUT	TATA spare parts
3219900401	SCREW M10X35.5	TATA spare parts
3219901501	HEX BOLT M10X1X28	TATA spare parts

3219901601	HEX SCREW	TATA spare parts
3219901901	HEX.SCREW M14X1.5X40	TATA spare parts
3219920025	CLAMPING SLEEVE CYL BLOCK	TATA spare parts
3219930601	PRESSURE SPRING	TATA spare parts
3219930601DB	PRESSURE SPRING	TATA spare parts
3219930610	RETURN SPRING	TATA spare parts
3219930701	COMPRESSION SPRING	TATA spare parts
3219931201	COMPRESSION SPRING	TATA spare parts
3219931701	PRESSURE SPRING	TATA spare parts
3219932201	PRESSURE SPRING	TATA spare parts
3219940009	LOCKING PLATE	TATA spare parts
3219940040	SNAP RING 2.68	TATA spare parts
3219940140	SNAP RING 2.73MM	TATA spare parts
3219940240	SNAP RING 2.78MM	TATA spare parts
3219940440DB	SNAP RING 2.88	TATA spare parts
3219970020	LOCKING COVER	TATA spare parts
3219970103	SLOTTED PLUG	TATA spare parts
3219970103DB	SLOTTED PLUG	TATA spare parts
3219970640	RUBBER RING	TATA spare parts
3219970740	GASKET RING	TATA spare parts
3220000080	TACHO SENSOR	TATA spare parts
32200514	Adaptor 3/4INCH BSP Male X M 30 X 2	TATA spare parts
32200714	Adaptor 1-1/4INCH BSP Male X M30 X 2	TATA spare parts
3220530125	LOCK RETAINER	TATA spare parts
3220530420	VALVE SPRING	TATA spare parts
3221100100	PEDAL A-ACCEL	TATA spare parts
3221100101	PEDAL A-ACCEL	TATA spare parts
3221100110	PEDAL-ACCEL	TATA spare parts
3221100111	PEDAL-ACCELERATOR	TATA spare parts
3221100120	HINGE ASSY. ACCELERATOR PEDAL	TATA spare parts
3221100130	CABLE	TATA spare parts
3221300019	CYL HEAD AIR COMP 77D	TATA spare parts
3221310019	A/C.CYL.HEAD	TATA spare parts
3221310022	PISTON PIN 70/77 D	TATA spare parts
3221310279	GASKET CYL.HD.SLEEVE	TATA spare parts
3221410070	ACCEL CONTROL MECHANISM	TATA spare parts
3221410071	ACCEL CONTROL MECHANISM	TATA spare parts
3221600620	CABLE A-ENGINE CONTROL	TATA spare parts
3221600630	CABLE A-ENGINE CONTROL	TATA spare parts
3221600650	BRKT-ENG CTRL CABLE MTG	TATA spare parts
3221600670	BRKT-I/P LEVER	TATA spare parts
3221600680	BRKT-RETURN SPRING I/P	TATA spare parts
3221600690	RETURN SPRING-ACCEL CONTROL	TATA spare parts
3221600700	COVER-RETURN SPRING	TATA spare parts
3221810206	GEAR DRIVE SHAFT	TATA spare parts
3221810306	GEAR OIL PUMP PC	TATA spare parts
3222010263	INSERT	TATA spare parts

3222100200	KNOB-IDLING	TATA spare parts
3222100210	SET SCREW	TATA spare parts
3222100220	CABLE A-IDLING CONTROL	TATA spare parts
3222110010	CABLE A-IDLING CONTROL	TATA spare parts
3222110011	CABLE A-IDLING CONT	TATA spare parts
3222500215	CLUTCH REL BRG W/SLEEVE	TATA spare parts
3222600021	ASSY GEAR BOX HOUSING COVER FRONT TOP	TATA spare parts
3222600040	ASSY.GR.SHIFT KNOB/G32G40	TATA spare parts
3222600344	ASSY HELICAL GEAR 2ND SPEED BS6-PH2	TATA spare parts
3222600435	SYNCRO SLEEVE 2ND/3RD	TATA spare parts
3222600545	ASSY.SYNCHRONISING SLEEVE 2ND&3RD SPEED	TATA spare parts
3222600625	ASSY REV GEAR MAIN SHAFT 36T GBS40	TATA spare parts
3222600644	3RD SPEED GEAR 25T HELICAL GBS40 BS1- 4	TATA spare parts
3222600644DF	GEAR THIRD SPEED 25T HELICAL - GB40	TATA spare parts
3222600725	REV. IDLER GEAR -20 T GBS40	TATA spare parts
3222620034	SYNCHRO RING 5TH SPEED BS3/4	TATA spare parts
3222620045	COUPLING FLANGE	TATA spare parts
3222620072	COLLAR NUT M28X1.5 SS8400 FOR AGB	TATA spare parts
3222620112	2ND GEAR HELICAL (32T) GBS40 BS1/2/3/4	TATA spare parts
3222620112DF	GEAR SECOND SPEED 32T HELICAL - GB40	TATA spare parts
3222620113	HELICAL GEAR 3RD SPEED(8.02/8.98)	TATA spare parts
3222620134	SYNCHRO RING GB	TATA spare parts
3222620134AE	SYNCHRONISING RING-3RD 4TH 713	TATA spare parts
3222620137	SYNCHRONISING CONE	TATA spare parts
3222620435	SYNCHRO SLEEVE 2ND/3RD SPEED BS1/2/3/4	TATA spare parts
3222620435DF	SYNCHRO SLEEVE 2/3 - GB40	TATA spare parts
3222620435DFNG	SYNCHRO SLEEVE 2/3 WITH HOLE - GB40	TATA spare parts
3222623950	COLLAR BUSH	TATA spare parts
3222624050	COLLAR BUSH 44.5 MM LONG (3RD SPEED) BS2	TATA spare parts
3222624050DF	COLLAR BUSHING 3RD SPEED GEAR-44.5MM LON	TATA spare parts
3222624150	COLLAR BUSHING 44.6 MM.LONG	TATA spare parts
3222624150DF	COLLAR BUSHING 3RD SPEED GEAR-44.6MM LON	TATA spare parts
3222630313	TWIN GEAR - 17/23 T COUNTERSHAFT GBS40	TATA spare parts
3222630313DF	GEAR TWIN 2/3 SPEED C/SHAFT-17T/23T-GB40	TATA spare parts
3222630333	REV. GEAR MAIN SHAFT 36T GBS40 BS1/2/3/4	TATA spare parts
3222630333DF	GEAR REVERSE MAIN SHAFT 36T-GB40	TATA spare parts
3222630333DFNG	GEAR REVERSE MAIN SHAFT 36T-GB40 MODIFIE	TATA spare parts
3222650123	GEAR SHIF DOG BS4	TATA spare parts
3222650305	SELECTOR.SHAFT REV. SPEED	TATA spare parts
3222800521DB	DRIVE SHAFT	TATA spare parts
3222800821	ASSY.DRIVE SHAFT	TATA spare parts
3222801121	DRIVE SHAFT	TATA spare parts
3222801121DB	DRIVE SHAFT	TATA spare parts
3222803333	ASSY. FRONT COVER BS6	TATA spare parts
3222810063	OIL GUIDING TUBE	TATA spare parts
3222820123	SHIFTER SLEEVE AGB	TATA spare parts
3222820211	GEAR REAR	TATA spare parts

3222820211DB	GEAR REAR	TATA spare parts
3222820301	DRIVE SHAFT	TATA spare parts
3222830102	COUNTER SHAFT (AUX GEAR BOX) BS1/2/3/4	TATA spare parts
3222830102DB	COUNTER SHAFT	TATA spare parts
3222830605	DRIVE SHAFT FRT.AXLE	TATA spare parts
3222830605AE	DRIVE SHAFT FRONT AXLE-1415-715	TATA spare parts
3222830605DB	DRIVEN SHAFT	TATA spare parts
3222830723	SHIFTER SLEEVE DRIVE	TATA spare parts
3222830723AE	SHIFTER SLEEVE 715	TATA spare parts
3222830723DB	SHIFTING SLEEVE	TATA spare parts
3222831106	DRIVE SHAFT REAR AXLE	TATA spare parts
3222840148	LOCK BOLT	TATA spare parts
3222840401	SHIFTER FORK LOWER	TATA spare parts
3222850082	RUBBER BUSH	TATA spare parts
3222850082AE	RUBBER BUSH 1628	TATA spare parts
3222900234	BRAKE SHAFT LEVER	TATA spare parts
3222900939	CONTROL ROD	TATA spare parts
3222930077	WASHER BRAKE PEDAL	TATA spare parts
322301130001	PASSENGER DOOR ASSEMBLY	TATA spare parts
3223121052	SUPPORT	TATA spare parts
32232107	ADAPTOR 1/2INCH BSP(M)X3/4INCH BSP	TATA spare parts
32232111	ADAPTOR 1/2INCH BSP(M)X3/4INCH BSP	TATA spare parts
32232113	ADAPTOR 1INCH BSP(M)X1INCH BSP(M)	TATA spare parts
3223250717	SLIDE SUPPORT	TATA spare parts
3223300435	ASSY JOINT CROSS LEFT	TATA spare parts
3223300535	ASSY JOINT CROSS RIGHT	TATA spare parts
3223301401	ASSY DRIVESHAFT LEFT INNER	TATA spare parts
3223301501	ASSY DRIVESHAFT RIGHT INNER	TATA spare parts
3223302901	ASSY DRIVE SHAFT OUTER	TATA spare parts
3223310009	SEAL HOLDER INNER	TATA spare parts
3223310080	RUBBER SEAL	TATA spare parts
3223310351	SPACER RING	TATA spare parts
3223320816	SUPPORTING SLEEVE LEFT	TATA spare parts
3223320916	SUPPORTING SLEEVE RIGHT	TATA spare parts
3223370030	COVER	TATA spare parts
3223370051	SUPPORTING RING	TATA spare parts
3223370062	STOP WASHER	TATA spare parts
3223370074	JOINT PIN	TATA spare parts
3223370118	BEARING HOUSING BS1/2/3/4	TATA spare parts
3223370180	SEALING RING	TATA spare parts
3223370217	FOLLOWER RING	TATA spare parts
3223370280	SEALING RING	TATA spare parts
3223370380	SEALING RING	TATA spare parts
3223370411	JOINT CROSS RIGHT	TATA spare parts
3223370417	FOLLOWER	TATA spare parts
3223370511	JOINT CROSS LEFT	TATA spare parts
3223370606	HOUSING F/AXLE LEFT	TATA spare parts

3223370706	HOUSING F/AXLE RIGHT	TATA spare parts
3223501139	SET-CROWN & PINION 48/7 GLEASON	TATA spare parts
3223510080	GASKET	TATA spare parts
3223510171	THRUST SCREW	TATA spare parts
3223530049	SLIDER	TATA spare parts
3223530051	SPACER RING 342	TATA spare parts
3223530073	LOCKING PLATE	TATA spare parts
3223530076	PIN ADJUSTING	TATA spare parts
3223530152	SPACER 10.28 MM	TATA spare parts
3223530252	SPACER RING 10.30 MM.THK.	TATA spare parts
3223530273	LOCKING PLATE	TATA spare parts
3223530352	SPACER 10.32 MM	TATA spare parts
3223530452	SPACER 10.34 MM	TATA spare parts
3223530552	SPACER RING 10.36 MM.THK.	TATA spare parts
3223530652	SPACER 10.38 MM	TATA spare parts
3223530752	SPACER 10.40 MM	TATA spare parts
3223530852	SPACER 10.42 MM	TATA spare parts
3223530952	SPACER 10.44 MM	TATA spare parts
3223531052	SPACER RING 1046 MM.THK.	TATA spare parts
3223531152	SPACER 10.48 MM	TATA spare parts
3223531252	SPACER RING 10.50MM.THK.	TATA spare parts
3223531352	SPACER RING 10.10MM.THK.	TATA spare parts
3223531452	SPACER 10.12 MM	TATA spare parts
3223531552	SPACER 10.14 MM	TATA spare parts
3223531652	SPACER RING 10.16 MM THK	TATA spare parts
3223531710	PINION - CWP:48/7-1139GL	TATA spare parts
3223531752	SPACER 10.18 MM	TATA spare parts
3223531852	SPACER 10.20 MM	TATA spare parts
3223531952	SPACER 10.22 MM	TATA spare parts
3223532052	SPACER RING 10.24 MM THK	TATA spare parts
3223532152	SPACER 10.26 MM	TATA spare parts
3223560015	PRESSURE RING LH	TATA spare parts
3223560053	SPACER TUBE	TATA spare parts
3223560079	GASKET	TATA spare parts
3223560115	PRESSURE RING RH	TATA spare parts
3223560179	GASKET	TATA spare parts
3223570501	REAR AXLE SHAFT	TATA spare parts
3224100142	ASSY.BEARING CUP	TATA spare parts
3224110072	HEX.NUT M28X1.5	TATA spare parts
3224110080	PACKING RING	TATA spare parts
3224110131	CROSS U/JOINT	TATA spare parts
3224110242	BEARING CUP	TATA spare parts
3224110331	CROSS UNIVERSAL JOINT	TATA spare parts
3224200042	DOUBLE LEVER	TATA spare parts
3224200347	ASSY FORK	TATA spare parts
3224200778	SUPPORT REAR	TATA spare parts
3224201216	PLATE FRONT LH	TATA spare parts

3224201316	ANCHOR PLATE RH	TATA spare parts
3224210074	SPRING BOLT	TATA spare parts
3224210094	BRACKET RETURN SPRING	TATA spare parts
3224210392	RETURN SPRING	TATA spare parts
3224230010	BRAKE LINING STD	TATA spare parts
3224230110	BRAKE LINING RS1	TATA spare parts
3224230210	BRAKE LINING RS2	TATA spare parts
3224260183	BEARING HALF RING	TATA spare parts
3224260183DB	BEARING RING	TATA spare parts
3224620023	COVER	TATA spare parts
3224620151	ADJUSTING RING	TATA spare parts
3224900130	PROTECTIVE SHIELD	TATA spare parts
3224920039	STOPPER	TATA spare parts
3224920704	EXHAUST PIPE REAR	TATA spare parts
3224920804	EXH PIPE REAR RR PORTION	TATA spare parts
3224922404	EXH PIPE REAR RR PORTION	TATA spare parts
322501160001	DOOR ASSY	TATA spare parts
3225400973DB	BRACKET	TATA spare parts
3225744	CONNECTOR FEMALE	TATA spare parts
3225890033	ROCKER	TATA spare parts
3228910211	CLAMPING PLATE-CAB MTG.SPRING	TATA spare parts
3229810112	NEEDLE BEARING	TATA spare parts
3229810181	INNER RING	TATA spare parts
3229810512	NEEDLE BEARING	TATA spare parts
3229810612	BEARING NEEDLE CAGE	TATA spare parts
3229810712	NEEDLE BEARING	TATA spare parts
3229810812	BEARING NEEDLE CAGE	TATA spare parts
3229900014	SET SCREW	TATA spare parts
3229900019	NECKED DOWN BOLT M8X45 10.9	TATA spare parts
3229900102	HEX HEAD SCREW	TATA spare parts
3229900114	HEX BOLT SCREW	TATA spare parts
3229900214	HEX BOLT	TATA spare parts
3229900314	SET SCREW	TATA spare parts
3229900505	STUD BOLT	TATA spare parts
3229900801	CENTRAL SCREW	TATA spare parts
3229901101	HEX SCREW	TATA spare parts
3229901901	HEX SCREW M12 X 1.5 X 35	TATA spare parts
3229901940	WASHER	TATA spare parts
3229901940DB	WASHER	TATA spare parts
3229930310	RELEASE SPRING	TATA spare parts
3229930310AE	RETURN SPRING 713	TATA spare parts
3229931701	COMPRESSION SPRING	TATA spare parts
3229940025	LOCKING PLATE	TATA spare parts
3229940034	SNAP RING	TATA spare parts
3229940115	LOCKING PLATE	TATA spare parts
3229940125	LOCKING PLATE	TATA spare parts
3229940130	LOCKING PLATE LH	TATA spare parts



3229940137	LOCKING WIRE	TATA spare parts
3229940230	LOCKING PLATE RH	TATA spare parts
3229970135	CLOSING PLUG	TATA spare parts
3229970330	PLUG	TATA spare parts
3229970330DB	SCREW PLUG	TATA spare parts
32300023	TEE ADAPTOR M18XM16X1/8INCH	TATA spare parts
32300031	ELBOW 1 1/2INCH BSP(M)XM1 1/2INCH	TATA spare parts
32300062	ADAPTOR 1/2 INCH	TATA spare parts
323010040001	EMERGENCY DOOR ASSY	TATA spare parts
3230131	CAP SCREW	TATA spare parts
32310CEP	RED OUTER EMERGENCY PUSH- BUTTON	TATA spare parts
3232992	ADAPTOR	TATA spare parts
323310160001	DRIVER DOOR ASSY	TATA spare parts
323310170001	DRIVER DOOR ASSEMBLY	TATA spare parts
323310180001	DRIVER S DOOR ASSEMBLY	TATA spare parts
3233500239	CROWNWHEEL PINION 41/6 LPT807	TATA spare parts
3234230092	RETURN SPRING	TATA spare parts
3235438	CAP SCREW(M8X40)	TATA spare parts
3235451	NUT REGULAR HEXAGON	TATA spare parts
3235454	NUT	TATA spare parts
3235458	WASHER LOCK	TATA spare parts
323610070001	FRONT FRP PANEL	TATA spare parts
323610090001	FRONT FRP PANEL	TATA spare parts
323610130001	FRONT FRP PANEL	TATA spare parts
323610170001	FRONT FACIA ASSY BS6	TATA spare parts
323610180001	F.R.P. FRONT PANEL BS6	TATA spare parts
3236331	CAP SCREW	TATA spare parts
3236332	CAP SCREW	TATA spare parts
3236460	NUT HEXAGON	TATA spare parts
3237092	PROBE	TATA spare parts
3239900101	HEX.BOLT M14X1X30	TATA spare parts
324020130001	PEEP GLASS	TATA spare parts
324020140001	PEEP GLASS	TATA spare parts
324030090003	SIDE WINDOW ASSY 1/3 FIX 2/3 SLD CLR TNT	TATA spare parts
324030110004	PASS DOOR GLASS	TATA spare parts
324030210001	SIDE WIN ASSY-SM22-FULL SLD-CLR GLASS-PC	TATA spare parts
324030240001	SIDE WINDOW ASSY (SM 22)	TATA spare parts
324030240002	SIDE WINDOW ASSY (SM 22)	TATA spare parts
324030240003	SIDE WINDOW ASSY (OWS) FOR 909	TATA spare parts
324030240004	SIDE WINDOW ASSY (OWS) FOR 909	TATA spare parts
324030250001	SIDE WINDOW ASSY (SM 22)	TATA spare parts
324030260001	SIDE WINDOW DRIVER DOOR	TATA spare parts
324030270001	SIDE WINDOW ASSY EMG (OWS) FOR 909	TATA spare parts
324030290002	SIDE WINDOW ASSY (OWS)	TATA spare parts
324030290003	SIDE WINDOW ASSY (OWS)	TATA spare parts
324030300002	SIDE WINDOW ASSY (OWS)	TATA spare parts
324030310002	SIDE WINDOW DRIVER DOOR (OWS)	TATA spare parts

324030320002	EMG WINDOW ASSY (OWS)	TATA spare parts
3241600170	DRAIN VALVE-AIR INTAKE	TATA spare parts
3241600462	SEAL A-INTAKE DUCT	TATA spare parts
3241600550	BAND CLAMP-RUBBER SEAL	TATA spare parts
3241600703	DUCT-AIR INTAKE	TATA spare parts
3241600712	SCREEN-INTAKE DUCT	TATA spare parts
3241600720	ELBOW A-AIR INTAKE	TATA spare parts
3241600741	BRACKET-INTAKE ELBOW	TATA spare parts
3241600764	DUCT A-AIR INTAKE	TATA spare parts
3241600880	BAND CLAMP	TATA spare parts
3241800132	ISOLATOR-INTAKE DUCT	TATA spare parts
3241800202	BRACKET-DUCT MTG UPPER	TATA spare parts
3241800210	BRACKET-DUCT MTG LOWER	TATA spare parts
3241800240	ISOLATOR-INTAKE DUCT	TATA spare parts
3243000219	AIR CLEANER A-DOUBLE	TATA spare parts
3243100000	AIR FILTER ELEMENT SECONDARY	TATA spare parts
3243100142	PACKING-A/CLNR CVR	TATA spare parts
3243100384	COVER-AIR CLEANER FRT	TATA spare parts
3243100421	WING NUT-ELEMENT	TATA spare parts
3243500119	ELEMENT A-INR	TATA spare parts
3243500120	AIR FILTER ELEMENT PRIMARY	TATA spare parts
3243500129	ELEMENT A-OTR	TATA spare parts
3243500630	ELEMENT A-OTR	TATA spare parts
3243700040	VACATER VALVE	TATA spare parts
3243800136	MEMBER-AIR CLEANER SUPPORT	TATA spare parts
3243800142	BAND A-AIR CLEANER MOUNTING	TATA spare parts
3243800156	BRACKET-AIR CLEANER MOUNTING	TATA spare parts
3243800181	RUBBER BAND-AIR CLEANER MTG	TATA spare parts
3244100401	PROP SHAFT COMP	TATA spare parts
3244100610	RUBBER HOSE-AIR CLEANER OUTLET	TATA spare parts
3244100690	RUBBER HOSE-TURBO CHARGER	TATA spare parts
3244100700	CONN PIPE-AIR CLEANER	TATA spare parts
3244425	FILTER WRENCH	TATA spare parts
3244800031	WIRE CLAMP PAI140	TATA spare parts
3244800032	WIRE CLAMP	TATA spare parts
3245103100	EXH PIPE FRT	TATA spare parts
3245503780	EXHAUST PIPE ENGINE	TATA spare parts
3245503930	EXH PIPE FLEX	TATA spare parts
3245718	RING PISTON	TATA spare parts
3245800140	CLAMP-FLEX PIPE	TATA spare parts
3245800141	CLAMP-FLEX PIPE	TATA spare parts
3245800620	BRACKET-SILENCER MTG RR	TATA spare parts
3245800720	BRACKET-SILENCER MTG FRT	TATA spare parts
3245801120	CLAMP A-SILENCER RR	TATA spare parts
3245801123	CLAMP A-SILENCER RR	TATA spare parts
3245802220	BRACKET-EXHAUST FRAME FRT	TATA spare parts
3245802260	BRKT-EXH FRM FRT	TATA spare parts

3245802480	BRKT-EXH FRM RR	TATA spare parts
3245802790	BRKT-SIL MTG FRT	TATA spare parts
3245802860	BRKT-SIL MTG RR	TATA spare parts
3245804570	BRACKET-EXHAUST FLEX	TATA spare parts
3245805230	BRKT-EXH FRM RR	TATA spare parts
3245805240	BRKT-EXH FRM RR	TATA spare parts
3245805900	BRKT - EXH PIPE TAIL	TATA spare parts
3245805910	BRKT-EXH PIPE TAIL	TATA spare parts
3245805920	BRKT-SIL MTG FRT	TATA spare parts
3245805930	BRKT-EXH PIPE FLEX	TATA spare parts
3247600410	BRACKET A-EXHAUST BRAKE	TATA spare parts
3247600411	BRACKET ASSY. EXHAUST BRAKE	TATA spare parts
3247600430	CYLINDER A	TATA spare parts
3247600440	ASSY EXHAUST BRAKE	TATA spare parts
3247600630	EXH BRAKE A	TATA spare parts
3247601050	ASM EXHAUST BRAKE	TATA spare parts
3247601180	ASM EXHAUST BRAKE	TATA spare parts
3247601180AE	EXH BRAKE A 1628 1828	TATA spare parts
3247601280	EXHAUST BRAKE A	TATA spare parts
3249800300	GASKET	TATA spare parts
3249800300AE	GASKET 1628 1828	TATA spare parts
3249800370	GASKET-EXHAUST BRAKE SIDE	TATA spare parts
3249800373	GASKET-EXHAUST BRAKE SIDE	TATA spare parts
3249800441	CUSHION RUBBER	TATA spare parts
3249800450	DISTANCE TUBE(FOR BRKT-SIL MTG/BRKT-EXH	TATA spare parts
3249800451	DISTANCE TUBE	TATA spare parts
3249800460	DISTANCE TUBE(FOR BRKT-EXH FLEX)	TATA spare parts
3249800461	DISTANCE TUBE	TATA spare parts
3249800470	GASKET	TATA spare parts
3249800473	GASKET	TATA spare parts
3249800510	GASKET	TATA spare parts
3249800511	GASKET	TATA spare parts
3249800710	CUSHION RUBBER	TATA spare parts
32500101	Adaptor 1/8INCH X 1/8INCH	TATA spare parts
32510001	Straight Coupling 1/8INCH	TATA spare parts
3251001090	BRKT-N/CVR UNDER RR(LH)	TATA spare parts
3251001100	BRKT-N/CVR UNDER RR(RH)	TATA spare parts
3251002240	BRKT-N/CVR CONNECT(RH)	TATA spare parts
3251002440	NOISE COVER A-UNDER FRT	TATA spare parts
3251002520	NOISE COVER-UNDER SIDE	TATA spare parts
3251002530	NOISE COVER-UNDER SIDE	TATA spare parts
3251002540	NOISE COVER A-UNDER RR	TATA spare parts
3251002740	BRKT-N/CVR CONNECT(LH)	TATA spare parts
3251002940	N/CVR A-UNDER FRT	TATA spare parts
3251002960	N/CVR A-UNDER RR	TATA spare parts
3251002970	BRKT-UNDER CVR FRT	TATA spare parts
3251500170	N/CVR UPR	TATA spare parts

3251500171	NOISE COVER-UPR	TATA spare parts
3251500220	N/CVR UPR	TATA spare parts
3251500222	NOISE COVER-UPR	TATA spare parts
3251500330	N/CVR UPR	TATA spare parts
3251500340	N/CVR UPR	TATA spare parts
3251500350	N/CVR A UPR	TATA spare parts
3251500360	N/CVR A UPR	TATA spare parts
3251500720	STRIP-N/CVR UPR	TATA spare parts
3251500770	NOISE COVER A-UPR(LH)	TATA spare parts
3251500780	NOISE COVER A-UPR(RH)	TATA spare parts
3251700070	NOISE COVER-LWR RR(LH)	TATA spare parts
3251700074	NOISE COVER-LWR RR	TATA spare parts
3251700114	MUD LINING-AIR CLEANER	TATA spare parts
3251700160	NOISE COVER-LWR RR(RH)	TATA spare parts
3251700163	NOISE COVER-LWR RR	TATA spare parts
3251700190	PATCH	TATA spare parts
3251700191	PATCH	TATA spare parts
3251700221	RUBBER PLATE REAR	TATA spare parts
3251700390	RUBBER SEAL(LH)	TATA spare parts
3251700391	RUBBER SEAL	TATA spare parts
3251700400	RUBBER SEAL	TATA spare parts
3251700480	RUBBER PLATE-SHOCK ABSORBER	TATA spare parts
3251700481	RUBBER PLATE-SHOCK ABSORBER	TATA spare parts
3251700800	PLATE-MUD LINING FRONT	TATA spare parts
3251700920	NOISE COVER-LWR FRT(RH)	TATA spare parts
3251700921	NOISE COVER-LWR FRT	TATA spare parts
3251700950	NOISE COVER-LWR FRT(LH)	TATA spare parts
3251700951	NOISE COVER-LWR FRT	TATA spare parts
3251701980	NOISE COVER-LWR RR OUTBD	TATA spare parts
3251900010	BACK COVER-ENGINE	TATA spare parts
3251900016	BACK COVER-ENGINE	TATA spare parts
3251900910	BACK COVER-ENGINE	TATA spare parts
3251900911	BACK COVER-ENGINE	TATA spare parts
3252700030	INSULATION-NOISE COVER LWR RR(RH)	TATA spare parts
3252700033	INSULATION-NOISE COVER LWR RR	TATA spare parts
3252700040	INSULATION-NOISE COVER LWR RR(LH)	TATA spare parts
3252700043	INSULATION-NOISE COVER LWR RR	TATA spare parts
3252700050	INSL-BACK COVER	TATA spare parts
3252700056	INSULATION-BACK COVER	TATA spare parts
3252700130	INSULATION-NOISE COVER LWR FRT	TATA spare parts
3252700220	INSULATION-NOISE COVER LWR FRT	TATA spare parts
3252900070	BRACKET-NOISE COVER LWR `A`	TATA spare parts
3252900072	BRACKET-NOISE COVER LWR A	TATA spare parts
3252900100	BRKT-NOISE COVER LWR CONNECT(RH)	TATA spare parts
3252900101	BRKT-NOISE COVER LWR CONNECT	TATA spare parts
3252900120	BRACKET-NOISE COVER LWR RR(RH)	TATA spare parts
3252900122	BRACKET-NOISE COVER LWR RR	TATA spare parts

3252900350	BRKT-N/CVR FENDER	TATA spare parts
3253888	SCREW HEX. HEAD CAP	TATA spare parts
32560002	PVC Flexible Tube	TATA spare parts
32561001	AIR TUBE 6X4- PER METER	TATA spare parts
3261000900	COOLING MODULE SUB ASM	TATA spare parts
3261000920	COOLING MODULE	TATA spare parts
3261001200	COOLING MODULE	TATA spare parts
3261001210	COOLING MODULE SUB ASM	TATA spare parts
3261001290	COOLING MODULE SUB ASM	TATA spare parts
3261100980	RADIATOR A	TATA spare parts
3261100990	COOLING MODULE MTG BRACKET	TATA spare parts
3261101000	COOLING MODULE MTG BRACKET	TATA spare parts
3261101290	AIR PROTECTOR-RAD UPR	TATA spare parts
3261101300	RADIATOR A	TATA spare parts
32611300530	C.A.C HOSE-COLD SIDE	TATA spare parts
3261800310	AIR PROTECTOR-RAD UPR	TATA spare parts
3261801080	CUSHION RUBBER-RADIATOR MTG	TATA spare parts
3261801100	WASHER-RADIATOR MTG	TATA spare parts
3261801120	DISTANCE TUBE-RADIATOR LWR MTG	TATA spare parts
3261801400	STAY-RADIATOR LWR FIX	TATA spare parts
3261801410	STAY-RADIATOR LWR FIX	TATA spare parts
3261801540	STAY-RADIATOR LWR FIX	TATA spare parts
3262100250	SHROUD ASSY.	TATA spare parts
3262700030	COVER-FAN	TATA spare parts
3262700032	COVER-FAN	TATA spare parts
3262700050	CLAMP A-FAN COVER	TATA spare parts
3262700054	CLAMP A-FAN COVER	TATA spare parts
3262700110	CUSHION RUBBER-FAN GUIDE	TATA spare parts
3262700120	DISTANCE TUBE	TATA spare parts
3262700340	BRKT-FAN GUIDE UPPER	TATA spare parts
3262700360	BRKT-FAN GUIDE LWR	TATA spare parts
3262700460	BRKT-FAN GUIDE LWR	TATA spare parts
3262700470	FAN GUIDE ASM	TATA spare parts
3263000360	CHARGE AIR COOLING(C.A.C) A	TATA spare parts
3265000040	V-BELT-ENG COOLING FAN	TATA spare parts
3265000360	COOLING FAN ASM	TATA spare parts
3265000370	FAN CLUTCH ASM-S710	TATA spare parts
3265000380	SPACER-F/CLUTCH FRT	TATA spare parts
3265000390	SPACER-F/CLUTCH RR	TATA spare parts
3265000391	SPACER-F/CLUTCH RR	TATA spare parts
3266100680	CAP A-S/TANK	TATA spare parts
3266101050	BODY A-SURGE TANK	TATA spare parts
3266101100	BODY A-SURGE TANK	TATA spare parts
3266101110	BODY A-SURGE TANK	TATA spare parts
3266101220	BODY A-SURGE TANK	TATA spare parts
3266800293	BRACKET-SURGE TANK	TATA spare parts
3266800411	BAND-SURGE TANK	TATA spare parts

3266800430	PACKING-SURGE TANK BAND	TATA spare parts
3266800510	BRACKET-SURGE TANK	TATA spare parts
3267101420	WATER HOSE-RAD OUTLET	TATA spare parts
3267101430	WATER PIPE-RAD OUTLET	TATA spare parts
3267101450	BRKT-WATER HOSE FIX	TATA spare parts
3267101460	CLIP ASM-WATER HOSE	TATA spare parts
3267101520	WATER HOSE-RAD OUTLET RAD	TATA spare parts
3267101560	WATER HOSE-RAD INLET	TATA spare parts
3267101570	WATER HOSE-RAD INLET.RAD	TATA spare parts
3267101580	WATER PIPE-RAD INLET	TATA spare parts
3267300110	BAND CLAMP-OVERFLOW HOSE	TATA spare parts
3267300160	BAND CLAMP-WATER HOSE	TATA spare parts
3267300311	BAND CLAMP-CAC HOSE	TATA spare parts
3267300430	BAND CLAMP-WATER HOSE	TATA spare parts
3267300520	C.A.C HOSE-HOT SIDE	TATA spare parts
3267300521	C.A.C HOSE-HOT SIDE	TATA spare parts
3267300530	C.A.C HOSE-COLD SIDE	TATA spare parts
3267500160	CLAMP-WIRE (D=46)	TATA spare parts
3267500162	CLAMP-WIRE (D=46)	TATA spare parts
3267500610	BRKT-RAD PROTECTOR MID	TATA spare parts
3267500690	VINYL HOSE-SURGE TANK	TATA spare parts
3267500691	VINYL HOSE-SURGE TANK	TATA spare parts
3267500740	BRKT-DOWNCOMER HOSE	TATA spare parts
3267500742	BRKT-DOWNCOMER HOSE	TATA spare parts
3267500820	CLIP-DOWNCOMER HOSE	TATA spare parts
3267500930	CLAMP-WIRE	TATA spare parts
3267500931	CLAMP-WIRE	TATA spare parts
3267502150	HOSE-OVER FLOW RR	TATA spare parts
3267502301	BRACKET-RADIATOR STAY MTG	TATA spare parts
3267502320	CONN PIPE-CAC OUTLET CAC	TATA spare parts
3267502330	BRKT-CAC CONN PIPE FIX	TATA spare parts
3267502340	BRKT-RAD PROTECTOR FRT	TATA spare parts
3267502350	BRKT-RAD PROTECTOR FRT	TATA spare parts
3267502360	CONNECTING PIPE-CAC INLET	TATA spare parts
3267502370	HOSE-OVERFLOW FRONT	TATA spare parts
3267502380	ELBOW-ENGINE INTAKE	TATA spare parts
3267502440	PROTECTOR-RAD LWR	TATA spare parts
3267502450	BRKT-RAD PROTECTOR RR	TATA spare parts
3267502460	BRKT-RAD PROTECTOR RR	TATA spare parts
3267502670	BRKT-RAD PROTECTOR RR	TATA spare parts
3267502680	BRKT-RAD PROTECTOR RR	TATA spare parts
3267502740	PROTECTOR-RAD LWR	TATA spare parts
3267502780	PROTECTOR-RAD LWR	TATA spare parts
3267502820	PROTECTOR ASM-RAD LWR FRT	TATA spare parts
3267503150	HOSE-OVERFLOW FRONT	TATA spare parts
3268800700	DOWNCOMER PIPE ASM	TATA spare parts
3268800750	DOWNCOMER HOSE-S/TANK	TATA spare parts

3268800760	HOSE-DOWNCOMER PIPE	TATA spare parts
3269930401	SPRING OIL PR RELIEFVALVE	TATA spare parts
3269970430DB	SCREW PLUG	TATA spare parts
3271000460	FUEL TANK A-400L(INCLUDES 2 TO 5)	TATA spare parts
3271000463	FUEL TANK A-400L	TATA spare parts
3271000464	FUEL TANK A-400L	TATA spare parts
3271001000	F/TANK A-300L	TATA spare parts
3271001520	FUEL TANK A-AL300L	TATA spare parts
3271600030	STRAINER A	TATA spare parts
3271700040	KEY LOCK CAP ASM-AL	TATA spare parts
3271700070	KEY LOCK CAP A-FUEL TANK	TATA spare parts
3271700071	CAP A-KEY LOCK FUEL TANK	TATA spare parts
3271700072	CAP A-KEY LOCK FUEL TANK	TATA spare parts
3272510033	COVER	TATA spare parts
32730	DOWEL BUSHING	TATA spare parts
32732	BRG CAP SCREW	TATA spare parts
3273300401	ASSY TIE ROD	TATA spare parts
3273300403	ASSY. TIE ROD BS2/3/4	TATA spare parts
3273300520	STUB AXLE 312/342	TATA spare parts
3273320006	KING PIN STD	TATA spare parts
3273320029	SEALING CAP STUB AXLE	TATA spare parts
3273320052	THRUST WASHER 0.5MM	TATA spare parts
3273320106	KING PIN STD1	TATA spare parts
3273320152	THRUST WASHER 0.80 MM	TATA spare parts
3273320206	KING PIN RS1	TATA spare parts
3273320252	THRUST WASHER 0.90 MM	TATA spare parts
3273320306	KING PIN RS2	TATA spare parts
3273320352	THRUST WASHER 1.2 MM THICK	TATA spare parts
3273320452	THRUST WASHER 1.3 MM THICK	TATA spare parts
3273320552	THRUST WASHER 1.40 MM	TATA spare parts
3273320652	THRUST WASHER 1.10 MM	TATA spare parts
3273320752	THRUST WASHER 1.0 MM THICK	TATA spare parts
3273320852	THRUST WASHER 1.5 MM THICK	TATA spare parts
3273320952	THRUST WASHER 1.60 MM	TATA spare parts
3273321052	THRUST WASHER 1.70 MM	TATA spare parts
3273321662	THRUST WASHER	TATA spare parts
3273380208	STEERING LEVER LH	TATA spare parts
3273381708DB	STEERING LEVER LH	TATA spare parts
3273381908DB	STEERING LEVER RH	TATA spare parts
3273500245	COUPLING FLANGE 342	TATA spare parts
3273530172	HEX NUT M40X1.5	TATA spare parts
3273530272	COLLAR NUT M35	TATA spare parts
3273530291	DUST COVER	TATA spare parts
3273531025	THREADED RING	TATA spare parts
3273532262	SHIM 0.15 MM THK	TATA spare parts
3273532362	SHIM 1.50 MM THK	TATA spare parts
3273536252	SHIM 0.10MM	TATA spare parts

3273536352	SHIM 0.2MM	TATA spare parts
3273536452	SHIM 0.50MM	TATA spare parts
3273600030	VALVE A-FUEL CHECK	TATA spare parts
3273600033	VALVE A-FUEL CHECK	TATA spare parts
3274010071	WHEEL MOUNTING PIN	TATA spare parts
3274200227	THRUST LINK	TATA spare parts
3274270054	GUIDE TUBE	TATA spare parts
3274600154	CROSS	TATA spare parts
3274600157	ASSY.UNIVERSAL JOINT	TATA spare parts
3274606101	STEERING GEAR BOX L342LH	TATA spare parts
3275045082	RUBBER BUFFER	TATA spare parts
3275300020	GROMMET-FUEL HOSE	TATA spare parts
3275300021	GROMMET-FUEL HOSE	TATA spare parts
3275700280	DRAIN PLUG	TATA spare parts
3275700290	GASKET-DRAIN PLUG	TATA spare parts
3276100170	BRACKET-SPACER FUEL TANK RR	TATA spare parts
3276100171	BRKT-SPACER FUEL TANK RR	TATA spare parts
3276100270	BRACKET-SPACER FUEL TANK FRT	TATA spare parts
3276100272	BRACKET-SPACER FUEL TANK FRT	TATA spare parts
3276100280	BRKT-SPACER FUEL TANK RR	TATA spare parts
3276100281	BRACKET-SPACER FUEL TANK RR	TATA spare parts
3276100500	HEAT PROTECTOR-FUEL TANK	TATA spare parts
3276100620	BRKT-FUEL TANK	TATA spare parts
3276100621	BRACKET-FUEL TANK	TATA spare parts
3276102770	BRACKET-SPACER FUEL TANK FRT	TATA spare parts
3276102800	BRKT-FUEL TANK	TATA spare parts
3276102850	BRKT-SPACER FUEL TANK FRT	TATA spare parts
3276200020	PACKING-BRKT TO TANK	TATA spare parts
3276200022	PACKING-BRACKET TO TANK	TATA spare parts
3276300050	PACKING-BAND TO TANK	TATA spare parts
3276400040	BAND A-FUEL TANK	TATA spare parts
3277401370	FUEL LINE A-SUCTION(L=2700MM)	TATA spare parts
3277401661	FUEL LINE A-SUCTION	TATA spare parts
3277401700	FUEL LINE A-SUCTION	TATA spare parts
3277402760	FUEL LINE A-RETURN(L=3480MM)	TATA spare parts
3277403320	FUEL LINE A-SUCTION	TATA spare parts
3277403330	FUEL LINE A-RETURN	TATA spare parts
3277403730	FUEL LINE A-RETURN	TATA spare parts
3277404670	FUEL LINE A-RETURN	TATA spare parts
3277404870	FUEL LINE ASM RETURN	TATA spare parts
3277405160	FUEL LINE A-SUCTION	TATA spare parts
3277500051	VINYL HOSE-BREATHER	TATA spare parts
3277500060	VINYL HOSE-BREATHER	TATA spare parts
3277700380	CLAMP-BREATHER HOSE	TATA spare parts
3277700383	CLAMP-BREATHER HOSE	TATA spare parts
3278423	CLAMP	TATA spare parts
3278448	SCREW TWELVE POINT CAP	TATA spare parts



3278464	ELBOW PLAIN ADAPTER	TATA spare parts
3278481	HOSE FLEXIBLE-4021	TATA spare parts
3279027	HOSE ELBOW	TATA spare parts
3279029	TUBE AIR	TATA spare parts
3279043	NUT HEXAGON FLANGE	TATA spare parts
3279061	COVER INTAKE MANIFOLD	TATA spare parts
3279104	TUBE	TATA spare parts
3279116	PLATE COVER	TATA spare parts
3279117	GASKET COVER PLATE	TATA spare parts
3279246	HOSE PLAIN	TATA spare parts
3279810805	BEARING TAPER ROLLER	TATA spare parts
3279810905	BEARING TAPER ROLLER	TATA spare parts
3279811005	BEARING TAPER ROLLER	TATA spare parts
3279900050	COLLAR NUT M12X1.5	TATA spare parts
3279900114	SET SCREW M12X1.5X49	TATA spare parts
3279900137	COTTER PIN	TATA spare parts
3279970026	SPHERICAL WASHER	TATA spare parts
3279970145	GASKET RING	TATA spare parts
3280089	INJECTOR-125HP	TATA spare parts
3280885	TUBE OIL GAUGE	TATA spare parts
3281012	BRACKET LIFTING	TATA spare parts
32810507	Valve Block Mounting O Ring	TATA spare parts
32811505	O Ring 23.52 X 1.78	TATA spare parts
32811506	O Ring 18.77 X 1.78	TATA spare parts
3281199	HOUSING FLYWHEEL	TATA spare parts
3281246	BRACKET LIFTING	TATA spare parts
3281248	CONNECTION TUR OIL DRAIN	TATA spare parts
3281249	TUBE TURBO OIL DRAIN	TATA spare parts
3281345	BRACE TUBE	TATA spare parts
3281504	HOSE FLEXIBLE	TATA spare parts
3281692	SCREW DRIVE	TATA spare parts
3281825	INJECTOR-4021	TATA spare parts
3281840	SEAL INJECTOR	TATA spare parts
3281881	COVER INTAKE MANIFOLD	TATA spare parts
3281929	PUMP INJECTION	TATA spare parts
3281941	BRACE FUEL PUMP-4021	TATA spare parts
3282000	FUEL INJ PUMP 145HP	TATA spare parts
3282054	STUD	TATA spare parts
3282059	CLIP	TATA spare parts
3282081	SCREW HEX HEAD CAP	TATA spare parts
3282111	BRACE TUBE	TATA spare parts
3282113	GASKET OIL DRAIN	TATA spare parts
3282133	SEAL O RING	TATA spare parts
3282133AE	SEAL O RING 713	TATA spare parts
3282141	SCREW BANJO CONNECTOR	TATA spare parts
3282165	HOSE FLEXIBLE	TATA spare parts
3282166	HOSE FLEXIBLE	TATA spare parts

3282266	THREADED PLUG	TATA spare parts
3282370	STUD	TATA spare parts
3282371	STUD	TATA spare parts
3282372	STUD	TATA spare parts
3282401	PILOT BEARING	TATA spare parts
3282404	SUPPORT ALTERNATOR	TATA spare parts
3282406	TEE STREET PIPE	TATA spare parts
3282433	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3282437	TUBE AIR FUEL CONTROL	TATA spare parts
3282462	FUEL INJ PUMP-4021	TATA spare parts
3282610	PUMP FUEL INJECTION	TATA spare parts
3282699	SCREW HEX FLANGE HD CAP	TATA spare parts
3282706	PIPE AIR INLET	TATA spare parts
3282708	CONNECTION EXH OUTLET	TATA spare parts
3282722	PIN THROTTLE LEVER PIVOT	TATA spare parts
3282731	MOTOR STARTING 24 VOLTS	TATA spare parts
3282745	TUBE INJ FUEL SUP	TATA spare parts
3282746	TUBE INJ FUEL SUP	TATA spare parts
3282800101	AUX GEAR BOX ASSY	TATA spare parts
3282805	GASKET CYLINDER HEAD	TATA spare parts
3282810	TUBE OIL GAUGE	TATA spare parts
3282894	DIPSTICK 1000 MM	TATA spare parts
3282895	TUBE OIL GAUGE 1000 MM	TATA spare parts
3282900	TUBE OIL GAUGE 1330 MM	TATA spare parts
3282906	DIPSTICK 1330 MM	TATA spare parts
3282928	HARNES WIRING 12V INLINE	TATA spare parts
3282929	WIRING HARNES 24V INLINE	TATA spare parts
3283137	TUBE OIL FILTER	TATA spare parts
3283155	TEE HOSE CONNECTOR	TATA spare parts
3283159	TUBE AIR FUEL CONTROL	TATA spare parts
3283179	CAMSHAFT	TATA spare parts
3283337	GASKET CYL. HEAD 0.15	TATA spare parts
3283339	GASKET CYL. HEAD 0.5	TATA spare parts
3283517	PUMP FUEL INJECTION 230HP ENGINE	TATA spare parts
3283550	FLY WHEEL BRG	TATA spare parts
3283562	INJECTOR	TATA spare parts
3283570	GASKET CYLINDER HEAD	TATA spare parts
3283589	THERMOSTAT	TATA spare parts
3283602	PUMP WATER	TATA spare parts
32840140031	BURR M 12 M 06 IS11943 P1 P40	TATA spare parts
3284100080	ASSY.PROTECTIVE CAP	TATA spare parts
3284110051	RING	TATA spare parts
3284110097	PROTECTIVE CAP	TATA spare parts
3284216	SCREW FLAT HEAD CAP	TATA spare parts
3284244	CONNECTION FEMALE	TATA spare parts
3284377	ROD PUSH	TATA spare parts
3284623	GASKET PUSH ROD COVER	TATA spare parts

3285098	BRACKET BELT TENSION	TATA spare parts
3285102	HOUSING THERMOSTAT	TATA spare parts
3285410	WATER PUMP	TATA spare parts
3285721	CONNECTOR MALE	TATA spare parts
3285949	SUPPORT FAN	TATA spare parts
3286275	KIT WATER PUMP	TATA spare parts
3286293	PUMP WATER	TATA spare parts
3286499	HOSE PLAIN	TATA spare parts
3287023	FLYWHEEL	TATA spare parts
3287206	TUBE CPR WATER OUTLET	TATA spare parts
3287273	CONNECTOR QCK DISCONNECT	TATA spare parts
3287318	FLYWHEEL	TATA spare parts
3287408	TUBE CPR WATER OUTLET	TATA spare parts
3287410	TUBE CPR WATER INLET	TATA spare parts
3287561	WASHER SEALING	TATA spare parts
3287573	CONNECTION TUR OIL DRAIN - 4992206	TATA spare parts
3287623	BRACKET EXH CONNECTION	TATA spare parts
3287699	HARNESS WIRING	TATA spare parts
3287727	CLIP WIRE RETAINING	TATA spare parts
3287893	NUT REGULAR HEXAGON	TATA spare parts
3288812	BELT - LPK 2516 AC MODEL	TATA spare parts
3289001	BELT V RIBBED	TATA spare parts
3289157	BELT V RIBBED	TATA spare parts
3289831	BELT V RIBBED	TATA spare parts
3289970081	GROMMET	TATA spare parts
3290083	BELT ADDITIONAL ALTERNATOR FOR AC	TATA spare parts
32912	FLASH WASHER	TATA spare parts
33010330501	TAPS BOTTOMING.M5X0.8	TATA spare parts
33106A00	REG. SCREW 12 X 1.5	TATA spare parts
3312000350	DRIVEN PLATE A	TATA spare parts
3313100330	PRESSURE PLATE A	TATA spare parts
3313100331	PRESSURE PLATE A	TATA spare parts
3314100061	RELEASE BEARING A	TATA spare parts
3314100062	RELEASE BEARING A	TATA spare parts
3315001130	PEDAL A CPL-CLUTCH	TATA spare parts
3315001135	PEDAL A CPL-CLUTCH	TATA spare parts
3315101010	BUSH-RELAY LEVER	TATA spare parts
3315101020	RUBBER-PEDAL STOP	TATA spare parts
3315101030	BUSH-CLUTCH PEDAL	TATA spare parts
3315101042	SPACER-CLUTCH PEDAL	TATA spare parts
3315111021	BOLT-PIVOT	TATA spare parts
3315111040	RETURN SPRING	TATA spare parts
3315111042	RETURN SPRING	TATA spare parts
3315111140	COVER-PEDAL PAD	TATA spare parts
3315111160	PEDAL A-CLUTCH	TATA spare parts
3315111162	PEDAL ASSY. CLUTCH	TATA spare parts
3315811092	BRKT ASSY. CLUTCH PEDAL	TATA spare parts

33160330657	TAPS BOTTOMING.M6.0X1.0	TATA spare parts
33160330851	TAPS BOTTOMING.M8.0X1.25	TATA spare parts
33160331041	TAPS BOTTOMING.M10X1.5	TATA spare parts
33160331203	TAPS BOTTOMING.M12X1.75	TATA spare parts
33160331602	TAPS BOTTOMING.M16X2.0	TATA spare parts
33160731244	TAPS BOTTOMING.M12X1.5	TATA spare parts
33160731601	TAPS BOTTOMING.M16X1.5	TATA spare parts
3316100340	MASTER CYL ASSY CLUTCH	TATA spare parts
3316100380	MASTER CYL CLUTCH	TATA spare parts
3316101310	MASTER CYL A-CLUTCH	TATA spare parts
3317100220	C/BOOSTER-AUTO.	TATA spare parts
3318101019	BODY-RESERVOIR	TATA spare parts
3318101020	GROMMET	TATA spare parts
3318101040	CLAMP-HOSE	TATA spare parts
3318101050	RESERVOIR A-CLUTCH	TATA spare parts
3318101059	RESERVOIR A-CLUTCH	TATA spare parts
3318101060	HOSE-RESERVOIR	TATA spare parts
3318101062	HOSE-RESERVOIR	TATA spare parts
3318101070	CLAMP-HOSE	TATA spare parts
3318101520	CAP-OIL W/PACKING	TATA spare parts
3318101522	CAP-OIL W/PACKING	TATA spare parts
3318400460	CLUTCH OIL PIPE A-FLEX:2W	TATA spare parts
3318400860	CLUCH OIL PIPE ASM-2W:FLEX	TATA spare parts
3318400900	C/OIL PIPE ASM-2W:FLEX	TATA spare parts
3318401050	CLIP-CLUTCH OIL PIPE	TATA spare parts
3318401330	CLUTCH OIL PIPE A-M/CYL:FLEX	TATA spare parts
3318401331	CLUTCH OIL PIPE A-M/CYL:FLEX	TATA spare parts
3318600100	FLEXIBLE HOSE-CLUTCH OIL	TATA spare parts
3318601050	GASKET	TATA spare parts
3318601150	FLEXIBLE HOSE A-CLUTCH OIL	TATA spare parts
3318601300	CONNECTOR-M14XM16	TATA spare parts
3318601390	FLEX HOSE A-C/OIL	TATA spare parts
3319801040	BRACKET-FLEX HOSE	TATA spare parts
3319801130	BRACKET-FLEX HOSE	TATA spare parts
3319801131	BRACKET-FLEX HOSE	TATA spare parts
3321016860	T/M CPT-T14S10 W/PTO	TATA spare parts
332101686B	T/M CPT-T W/PTO	TATA spare parts
3321017930	T/M CPT-T14S10 W/PTO	TATA spare parts
3321017940	T/M CPT-T14S10 WO/PTO	TATA spare parts
33210801	HOSE 1/4INCH X 700 MM L-TG CYLINDER	TATA spare parts
33210805	HOSE 1/4INCH X 325 MM L-TG CYLINDER	TATA spare parts
33212503	Suction Hose 1INCH - 1500	TATA spare parts
33212506	HOSE 1INCH IDX1500 R1 1*7/16INCH UNF	TATA spare parts
33212507	HOSE 1INCH ID X 1850MM 1 7/16INCH UN	TATA spare parts
33212509	HOSE 1INCH X 1400 1 7/16INCH UNF FS90	TATA spare parts
33212514	HOSE 1INCH I.DX600 R1 1 7/16INCH UNF	TATA spare parts
33212524	HOSE 1INCH X 1000MM 1 7/16INCH UNF F	TATA spare parts

33213206	HOSE 1500	TATA spare parts
33222003	Hose 3/4INCH-HP-12-1100-FS90 SAE100R2 WP	TATA spare parts
33222011	HOSE 3/4INCH ID X 1150MM L 1 3/16INCH	TATA spare parts
33222015	HOSE 3/4INCH ID X 1000MM L 1 3/16INCH	TATA spare parts
33222022	HOSE 3/4INCH IDX2050R2 1 3/16INCH UN	TATA spare parts
33222029	HOSE 3/4INCH X300 MM L R2 1 3/16INCH	TATA spare parts
33222031	HOSE 3/4INCH IDX1500 R2 1*3/16INCH	TATA spare parts
33222501	HOSE 2000	TATA spare parts
33222502	HOSE OIL TANK TO HYD CYLINDER	TATA spare parts
3329102440	OIL COOLER A-T/M	TATA spare parts
3329102570	CONNECTOR-OIL COOLER A	TATA spare parts
3329102580	BRACKET-OIL COOLER A	TATA spare parts
3329104260	BOLT-T/M MTG M10X1.5	TATA spare parts
3329104280	BOLT-T/M MTG M10X1.5	TATA spare parts
3329104770	FLEXIBLE HOSE-T/M OUT (L=2880 RED)	TATA spare parts
3329104771	FLEXIBLE HOSE-T/M OUT	TATA spare parts
3329105640	CONNECTOR-ELBOW PT1/2 M20	TATA spare parts
3329105660	FLEXIBLE HOSE-T/M IN	TATA spare parts
33300006	Hose 3/4INCH-HP-12-2120-FS90 SAE100R2 WP	TATA spare parts
33300012	HOSE 3/4INCH ID X 2400MM 1INCH BSP (	TATA spare parts
33300039	HOSE 3/4INCH X 2400 1 3/16INCH UNF FS9	TATA spare parts
33300041	HOSE 3/4INCH ID X 2400MM 1INCH BSP (M)	TATA spare parts
33300042	HOSE 3/4INCH ID X 1850R1 1 3/16INCH UNF	TATA spare parts
33300045	HOSE ( VALVE TO CYLINDER)	TATA spare parts
33300076	HOSE 3/4INCH IDX2600 R2 1*3/16INCH	TATA spare parts
33300091	HOSE 1INCH I.D X 1100R2 1 7/16INCH UNF	TATA spare parts
33300092	HOSE 3/4INCH I.D X 2400R2 1 3/16INCH U	TATA spare parts
33300107	HOSE ( VALVE TO TANK )	TATA spare parts
33300108	HOSE ( TANK TO PUMP )	TATA spare parts
3330159	SEAL O-RING	TATA spare parts
3330202	SEAL O RING	TATA spare parts
3330638	GAS MASS FLOW SENSOR	TATA spare parts
3330941	SEAL 'O' RING	TATA spare parts
3330942	SEAL 'O' RING	TATA spare parts
3332242	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3335076	WASHER BEVEL	TATA spare parts
3340520101	COVER	TATA spare parts
3349910615	BALL PIN	TATA spare parts
3351100640	CHANGE LEVER A	TATA spare parts
3351100650	1ST RELAY A	TATA spare parts
3351100651	1ST RELAY A	TATA spare parts
3351100720	2ND RELAY A	TATA spare parts
3351102940	IDLER A	TATA spare parts
3351103430	CHANGE LEVER A	TATA spare parts
3351300050	BOOT-INNER	TATA spare parts
3351300054	BOOT-INNER	TATA spare parts
3351300100	RETAINER-COVER	TATA spare parts

3351300101	RETAINER-COVER	TATA spare parts
3351300120	RETURN SPRING	TATA spare parts
3351300210	BOOT-OUTER	TATA spare parts
3351300210DB	BOOT-OUTER(BEIGE)	TATA spare parts
3351300214	BOOT-OUTER	TATA spare parts
3351300214DB	BOOT-OUTER	TATA spare parts
3351300420	KNOB A	TATA spare parts
3351300420DB	KNOB A(BEIGE)	TATA spare parts
3351300421	KNOB ASSY.	TATA spare parts
3351300421DB	KNOB ASSY.	TATA spare parts
3351300920	PATTERN-5 SPEED	TATA spare parts
3351300920DB	PATTERN-5 SPEED	TATA spare parts
3351301080	MAGNETIC VALVE A-3/2	TATA spare parts
3351301090	MAGNETIC VALVE A-3/2	TATA spare parts
3351302040	PATTERN-10 SPEED	TATA spare parts
3351302040DB	PATTERN-10 SPEED(BEIGE)	TATA spare parts
3351407710	BALL SEAT	TATA spare parts
3351500011	ROD A-CHANGE LEVER SHIFT	TATA spare parts
3351500031	ROD A-2ND SHIFT	TATA spare parts
3351500301	ROD A-CHANGE LEVER SELECT	TATA spare parts
3351500421	ROD A-1ST SHIFT	TATA spare parts
3351500501	ROD A-1ST SELECT	TATA spare parts
3351500690	BALL JOINT M8X1.25	TATA spare parts
3351500700	BALL JOINT M8X1.25	TATA spare parts
3351500710	BALL JOINT M10X1.25	TATA spare parts
3351500720	BALL JOINT M10X1.25	TATA spare parts
3351500730	HEX NUT M10X1.25	TATA spare parts
3351502230	ROD A-IDLER SHIFT	TATA spare parts
3351502240	ROD A-2ND SELECT	TATA spare parts
3351502350	BALL JOINT M10X1.25 (RH)	TATA spare parts
3351502360	BALL JOINT M10X1.25 (LH)	TATA spare parts
3351502370	BALL JOINT M8X1.25 (RH)	TATA spare parts
3351502380	BALL JOINT M8X1.25 (LH)	TATA spare parts
3351502550	ROD A-CHANGE LEVER SELECT (L = 606 MM)	TATA spare parts
3351502590	ROD A-1ST SELECT	TATA spare parts
3351503000	ROD A-CHANGE LEVER SHIFT (L = 610MM)	TATA spare parts
3351503010	ROD A-1ST SHIFT	TATA spare parts
3351503030	ROD A-2ND SHIFT (L=1099MM)	TATA spare parts
3351503320	ROD A-IDLER SHIFT (L=386MM)	TATA spare parts
3351503330	ROD A-2ND SELECT (L=1606MM)	TATA spare parts
3354061	HOUSING THERMOSTAT	TATA spare parts
3354866	CONNECTOR WATER INLET	TATA spare parts
3355966	HOSE PLAIN	TATA spare parts
3357102	SUPPORT AIR COMPRESSOR	TATA spare parts
3357107	COMPRESSOR AIR	TATA spare parts
3358101540	LEAD-SEAL	TATA spare parts
3358101550	WIRE-SEAL	TATA spare parts

3358101600	WIRE-SEAL	TATA spare parts
3362102990	PROPELLER SHAFT A-END	TATA spare parts
3362103000	PROPELLER SHAFT A-END	TATA spare parts
336210300A	PROPELLER SHAFT ASSY. END	TATA spare parts
336210304A	PROPELLER SHAFT A-END	TATA spare parts
3362103900	PROPELLER SHAFT A-END	TATA spare parts
3362104060	PROPELLER SHAFT A-END(HYOLIM S-1810)	TATA spare parts
3363100200	INTER DRIVE SHAFT A	TATA spare parts
3363100210	INTER DRIVE SHAFT A	TATA spare parts
3364802850	GUARD-P/SHAFT	TATA spare parts
33662000	TIPPING CYLINDER	TATA spare parts
3371110990	REAR AXLE CPT ASM-FWD	TATA spare parts
3371113420	REAR AXLE CPT ASM-FWD	TATA spare parts
3371122050	REAR AXLE CPT ASM-FWD	TATA spare parts
3371122060	REAR AXLE CPT ASM-FWD(R7.733)	TATA spare parts
3371122080	REAR AXLE A-FWD	TATA spare parts
3371122100	REAR AXLE CPT ASM-FWD(R6.833)	TATA spare parts
3371201510	HOUSING ASSY. R/A FORWARD	TATA spare parts
3371203630	HOUSING A-R/A FWD	TATA spare parts
3371204700	HOUSING A-R/A,FWD	TATA spare parts
3371204710	HOUSING A-R/A FWD	TATA spare parts
3371300980	FINAL DRIVE ASSY.-FWD	TATA spare parts
3371302250	FINAL DRIVE A-FWD (R7.333)	TATA spare parts
3371302260	FINAL DRIVE A-FWD (R6.833)	TATA spare parts
3372610120	GEAR CASE COVER REAR	TATA spare parts
3372650007	SWING LEVER 1ST SHIFTFORK	TATA spare parts
3372670096	RUBBER BELLOW GEAR LEVER	TATA spare parts
3375044	TORQUE WRENCH ( 0-150 LB-IN )	TATA spare parts
3375049	WRENCH FILTER	TATA spare parts
3375066	PIPE SEALANT - USED ON CAPSCREW THREADS	TATA spare parts
3375068	CUP PLUG SEALANT - USED WHILE INSTALLING	TATA spare parts
3375114580	REAR AXLE CPT ASM-RWD	TATA spare parts
3375115140	REAR AXLE CPT ASM-RWD T16/HT	TATA spare parts
3375118350	REAR AXLE CPT ASM-RWD	TATA spare parts
3375120450	REAR AXLE CPT ASM-RWD(R6.166)	TATA spare parts
3375133500	REAR AXLE CPT A-RWD	TATA spare parts
3375133510	REAR AXLE CPT ASM-RWD(R7.733)	TATA spare parts
3375133530	REAR AXLE A-RWD	TATA spare parts
3375133550	REAR AXLE CPT ASM-RWD(R6.833)	TATA spare parts
3375203040	HOUSING A-R/A RWD	TATA spare parts
3375203710	HOUSING A-R/A RWD	TATA spare parts
3375203720	HOUSING A-R/A RWD(ABS)	TATA spare parts
3375275	PRESSURE GAUGE - [0 TO 160 PSI ] - TO ME	TATA spare parts
3375301140	FINAL DRIVE ASSY. REARWARD	TATA spare parts
3375301660	FINAL DRIVE A-RWD (R7.333)	TATA spare parts
3375301670	FINAL DRIVE A-RWD (R6.833)	TATA spare parts
3375326	WATER PUMP BRG SEPARATOR	TATA spare parts

3375962	VALVE SPRING COMPRESSOR	TATA spare parts
3376015	CYL. LINER PULLER	TATA spare parts
3376050	DIAL INDICATOR AND SLEEVE ASSEMBLY	TATA spare parts
3376592	TORQUE WRENCH PRELOAD	TATA spare parts
3376593	SERVICE ENGINEERS TOOL KIT - MM	TATA spare parts
3376619	DIAL BORE GAUGE - TO MEASURE CYLINDER BO	TATA spare parts
3376663	COUPLING PULLER - TO REMOVE SPLINE COUPL	TATA spare parts
3376812	CUP PLUG DRIVER - FLYWHEEL HOUSING	TATA spare parts
3376859	COUPLER QCK DISCONNECT	TATA spare parts
3376881	THREAD INSERT KIT METRIC	TATA spare parts
3376936	SLEEVE FP	TATA spare parts
3377259	TIMING FP	TATA spare parts
3377371	ENGINE BARRING TOOL	TATA spare parts
3377399	MAGNETIC BASE DIAL INDICATOR HOLDER	TATA spare parts
3377415	AIR COMPRESSOR SEAT INSTALLATION TOOL	TATA spare parts
3377416	AIR COMPRESSOR SEAT REMOVAL TOOL	TATA spare parts
3377462	TACHOMETER	TATA spare parts
3379870014	RUBBER PACKING	TATA spare parts
3381002125	FRONT AXLE ASM	TATA spare parts
3381004610	FRONT AXLE ASSEMBLY	TATA spare parts
3381004930	FRONT AXLE ASM	TATA spare parts
3381005530	FRONT AXLE ASM - 7.5TON	TATA spare parts
3381005540	FRONT AXLE ASM	TATA spare parts
3381006920	FRONT AXLE ASM-7.5TON	TATA spare parts
3381008050	FRONT AXLE ASM - 7.5TON	TATA spare parts
3381008060	FRONT AXLE ASM-7.5TON	TATA spare parts
3383429	ASSY. BALL JOINT	TATA spare parts
3384100010	KNUCKLE(LH)	TATA spare parts
3384100011	KNUCKLE	TATA spare parts
3384100020	KNUCKLE(RH)	TATA spare parts
3384100090	KNUCKLE	TATA spare parts
3384100100	KNUCKLE	TATA spare parts
3384100630	KNUCKLE	TATA spare parts
3384100640	KNUCKLE	TATA spare parts
3384100670	KNUCKLE(LH)	TATA spare parts
3384100680	KNUCKLE(RH)	TATA spare parts
3384210006	SUPPORT BRAKE	TATA spare parts
3385890021	DEVICE	TATA spare parts
3387100010	BEARING-UPR	TATA spare parts
3387100020	BEARING-LWR	TATA spare parts
3387100030	BEARING-THRUST ROLLER	TATA spare parts
3387100080	CUP-HUB BRG OTR	TATA spare parts
3387100090	CONE-HUB BRG OTR	TATA spare parts
3387100110	CUP-HUB BRG INR	TATA spare parts
3387100120	CONE-HUB BRG INR	TATA spare parts
3387100190	CONE HUB BRG INNER	TATA spare parts
3387100200	CUP-HUB BRG INR	TATA spare parts



3387100220	CUP-HUB BEARING INNER	TATA spare parts
3387100230	CONE-HUB BEARING INNER	TATA spare parts
3387100240	CUP-HUB BEARING OUTER	TATA spare parts
3387100250	CONE-HUB BEARING OUTER	TATA spare parts
3387100490	CUP-HUB BRG INR	TATA spare parts
3387100500	CONE-HUB BRG INR	TATA spare parts
3387500010	SEAL-KING PIN	TATA spare parts
3387500020	PACKING:KING PIN COVER	TATA spare parts
3387500040	OIL SEAL-KING PIN	TATA spare parts
3388100030	FRONT AXLE	TATA spare parts
3388100032	FRONT AXLE	TATA spare parts
3388100050	FRONT AXLE	TATA spare parts
3389800010	KEY BOLT-KING PIN	TATA spare parts
3389800020	SNAP RING	TATA spare parts
3389800050	LOCK WASHER-FRT HUB BEARING	TATA spare parts
3389800060	BEARING NUT-FRT HUB	TATA spare parts
3389800070	LOCK WASHER-BEARING NUT	TATA spare parts
3389800090	PACKING-HUB CAP	TATA spare parts
3389800110	COVER-HUB BEARING INNER	TATA spare parts
3389800120	SNAP RING-HUB	TATA spare parts
3389800130	OIL SEAL-FRT HUB	TATA spare parts
3389800140	CAP-HUB	TATA spare parts
3389800150	PLUG-PLATE KNUCKLE	TATA spare parts
3389800170	HUB CAP-W/PACKING	TATA spare parts
3389800180	KING PIN	TATA spare parts
3389800181	KING PIN	TATA spare parts
3389800200	THRUST WASHER (T=4.90)	TATA spare parts
3389800201	THRUST WASHER	TATA spare parts
3389800210	THRUST WASHER (T=4.95)	TATA spare parts
3389800211	THRUST WASHER	TATA spare parts
3389800220	THRUST WASHER (T=5.00)	TATA spare parts
3389800221	THRUST WASHER	TATA spare parts
3389800230	THRUST WASHER (T=5.05)	TATA spare parts
3389800231	THRUST WASHER	TATA spare parts
3389800240	THRUST WASHER (T=5.10)	TATA spare parts
3389800241	THRUST WASHER	TATA spare parts
3389800250	THRUST WASHER (T=5.15)	TATA spare parts
3389800251	THRUST WASHER	TATA spare parts
3389800260	THRUST WASHER (T=5.20)	TATA spare parts
3389800261	THRUST WASHER	TATA spare parts
3389800270	THRUST WASHER (T=5.25)	TATA spare parts
3389800271	THRUST WASHER	TATA spare parts
3389800630	BOLT-STOPPER KNUCKLE	TATA spare parts
3389800640	COVER HUB BRG INNER	TATA spare parts
3389800650	OIL SEAL FRT HUB	TATA spare parts
3389800660	SNAP RING HUB	TATA spare parts
3389800740	BUSH-KING PIN 65	TATA spare parts

3389800900	BUSH-KING PIN 62	TATA spare parts
3389800910	BUSH-KING PIN 50	TATA spare parts
3389800920	COVER-KING PIN	TATA spare parts
3389800930	O-RING	TATA spare parts
3389801010	BEARING NUT-FRT HUB	TATA spare parts
3389801080	CAP-HUB	TATA spare parts
3389801090	PACKING-HUB CAP	TATA spare parts
3389801390	LOCK WASHER-BEARING NUT	TATA spare parts
3389801400	BOLT-STOPPER KNUCKLE	TATA spare parts
3400157	Oil filter wrench	TATA spare parts
3400158	Engine coolant and fuel filter wrench	TATA spare parts
3400162	DIGITAL MULTIMETER	TATA spare parts
3400817	RING RETAINING	TATA spare parts
3401544	ELEMENT LUB OIL FILTER	TATA spare parts
3402620134	SYNCHRO RING 5TH SPEED BS 1/2/3/4	TATA spare parts
34031002	TIPPING VALVE LPK 2516TC 6X4	TATA spare parts
3403240335	SUPPORT PLATE	TATA spare parts
3403310020	STOPPER	TATA spare parts
3403310050	BUSH FRONT AXLE SWIVEL	TATA spare parts
3403320062	THRUST WASHER	TATA spare parts
3403320262	THRUST WASHER	TATA spare parts
3403320362	THRUST WASHER	TATA spare parts
3403320462	THRUST WASHER	TATA spare parts
3403320562	THRUST WASHER	TATA spare parts
3403320662	THRUST WASHER	TATA spare parts
3403320762	THRUST WASHER	TATA spare parts
3403320862	THRUST WASHER	TATA spare parts
3403320962	THRUST WASHER	TATA spare parts
3403321062	THRUST WASHER	TATA spare parts
3403321162	THRUST WASHER	TATA spare parts
3403321206	KING PIN UPPER	TATA spare parts
3403321262	THRUST WASHER	TATA spare parts
3403321306	KING PIN LOWER BS1/2/3/4	TATA spare parts
3403321306AE	KING PIN LOWER 715	TATA spare parts
3403321362	THRUST WASHER	TATA spare parts
3403321462	THRUST WASHER	TATA spare parts
3403321562	THRUST WASHER	TATA spare parts
3403340051	SPACER RING	TATA spare parts
3403340373DB	SEALING RING	TATA spare parts
3403370071	STOP SCREW	TATA spare parts
3404280240	BKT BRAKE HOSE	TATA spare parts
3408503	SENSOR POSITION	TATA spare parts
3408645	SWITCH THERMO	TATA spare parts
3409900201	BOLT (M14X1.5X45) (CROSS MEMBER SUPPORT	TATA spare parts
3410016340	FRAME ASSY COMPLETE NOVUS	TATA spare parts
3410016342	FRAME ASSY COMPLETE NOVUS	TATA spare parts
3410019760	FRAME ASM	TATA spare parts

3410020080	FRAME ASM	TATA spare parts
34102050	BALL VALVE	TATA spare parts
3411200180	BRKT-1ST BMPR BOUND	TATA spare parts
3411300031	HOOK	TATA spare parts
3411300193	LOCK PLATE	TATA spare parts
3411300370	TOWING HOOK	TATA spare parts
3411300380	SUPPORT BRKT-TOWING HOOK	TATA spare parts
3412100611	D/PLATE-C/MBR CTR LWR(6T)	TATA spare parts
3412100650	CROSS MEMBER A-'I' END	TATA spare parts
3412100653	C/MBR A- I END	TATA spare parts
3412101578	GUSSET-TRUN UPR	TATA spare parts
3412104940	CROSS MEMBER A-'F' CTR	TATA spare parts
3412104943	C/MBR A- F CTR	TATA spare parts
3412104970	CROSS MEMBER A-'R' CTR	TATA spare parts
3412104972	CROSS MEMBER A- R CTR	TATA spare parts
3412105223	GUSSET-TRUN LWR	TATA spare parts
3412105370	CROSS MEMBER A-'B' 2ND	TATA spare parts
3412105376	C/MBR A- B 2ND	TATA spare parts
3412105400	CROSS MEMBER A-'N' 2ND	TATA spare parts
3412105407	CROSS MEMBER A- N 2ND	TATA spare parts
3412105470	CROSS MEMBER A-'S' R/S RR & END	TATA spare parts
3412105471	CROSS MEMBER A- S R/S RR & END	TATA spare parts
3412106521	CROSS MEMBER A- A 1ST	TATA spare parts
3412111130	CROSS MEMBER A-'A' 1ST	TATA spare parts
3412111700	GUSSET-TRUN UPR	TATA spare parts
3412111710	GUSSET-TRUN LWR	TATA spare parts
3412113010	C/MBR ASM-2ND	TATA spare parts
3412113170	GUSSET	TATA spare parts
3412113180	SPACER C/ MBR FIX	TATA spare parts
3412113210	SPACER C/MBR FIX	TATA spare parts
3412320	CLAMP HOSE	TATA spare parts
3412620002	DRIVE SHAFT	TATA spare parts
3412620005	MAIN SHAFT	TATA spare parts
3412620011	GEAR 1ST SPEED	TATA spare parts
3412620012	2ND SPEED GEAR-28T GBC30	TATA spare parts
3412620013	3RD SPEED GEAR-22T GBC30	TATA spare parts
3412620014	GEAR 4TH SPEED	TATA spare parts
3412620023	SHIFTER SLEEVE BIG -26T GBC30	TATA spare parts
3412620123	SHIFTER SLEEVE SMALL-23T GBC30	TATA spare parts
3412630014	DOUBLE GEAR C/SHAFT 4TH	TATA spare parts
3413000230	SPARE TIRE CARRIER BRKT A	TATA spare parts
3413000232	BRKT A-S/TIRE CARRIER	TATA spare parts
3413200260	SPACER-FRAME	TATA spare parts
3413200580	BRACKET-SPARE TIRE RR	TATA spare parts
3414000130	TOOL BOX A	TATA spare parts
3414000138	TOOL BOX A	TATA spare parts
3414000170	PATCH-TOOL BOX	TATA spare parts

3414000171	PATCH-TOOL BOX	TATA spare parts
3414000190	CUSHION PLATE-TOOL BOX	TATA spare parts
3414000191	CUSHION PLATE-T/BOX	TATA spare parts
3414000220	TOOL BOX A	TATA spare parts
3414000223	TOOL BOX A	TATA spare parts
3414000240	CUSHION PLATE-TOOL BOX	TATA spare parts
3414000241	CUSHION PLATE-TOOL BOX	TATA spare parts
3414000420	BRACKET-TOOL BOX FRT	TATA spare parts
3414000430	BRACKET-TOOL BOX RR	TATA spare parts
3414100010	HANDLE-SPARE TIRE CARRIER	TATA spare parts
3414100040	TOOL BAG	TATA spare parts
3414100050	PLIER-200 MM	TATA spare parts
3414100060	WRENCH MONKEY-250 MM	TATA spare parts
3414100080	HANDLE-WRENCH	TATA spare parts
3414100100	SPANNER 7 X 8	TATA spare parts
3414100110	SPANNER 10X12	TATA spare parts
3414100120	SPANNER 14X17	TATA spare parts
3414100130	SPANNER 19 X 22	TATA spare parts
3414100150	SCREW DRIVER A	TATA spare parts
3414100160	DRIVER-SCREW+/:150MM	TATA spare parts
3414100280	OIL JACK A-22TON W/LEVER	TATA spare parts
3414100430	PIN-TOWING HOOK	TATA spare parts
3414100600	TOOL SET	TATA spare parts
3414100670	WRENCH-10 WHEEL NUT	TATA spare parts
3414100720	OIL JACK A-15TON W/LEVER	TATA spare parts
3414200632	BOSS	TATA spare parts
3414200701	STAY-MUD FLAP	TATA spare parts
3414200711	PLUG-FENDER STAY	TATA spare parts
3414200751	BRACKET-FENDER MTG FRT	TATA spare parts
3414200891	MUD FLAP-REAR	TATA spare parts
3414200902	BRACKET A-FENDER MTG REAR(LH)	TATA spare parts
3414200912	BRACKET A-FENDER MTG REAR(RH)	TATA spare parts
3414201032	SPACER-RUBBER MTG	TATA spare parts
3414201043	RUBBER-RR FENDER	TATA spare parts
3414201052	PATCH-RUBBER MTG FRT(LH)	TATA spare parts
3414201561	REAR FENDER-2ND B(LH)	TATA spare parts
3414201571	PATCH-RUBBER MTG FRT(RH)	TATA spare parts
3414201581	PATCH-RUBBER MTG RR(LH)	TATA spare parts
3414201591	PATCH-RUBBER MTG RR(RH)	TATA spare parts
3414202250	SPRING FENDER MTG	TATA spare parts
3414202311	BRACKET-FENDER 1ST CTR	TATA spare parts
3414202321	BRACKET-FENDER 1ST CTR	TATA spare parts
3414202350	REAR FENDER A-1ST	TATA spare parts
3414202400	REAR FENDER-2ND A	TATA spare parts
3414203270	SPACER TAPE	TATA spare parts
3414203620	BRKT-RR FENDER A CTR K	TATA spare parts
3414203640	BRKT-RR FENDER A FRT/RR	TATA spare parts

3414203710	BRKT-RR FENDER A CTR J	TATA spare parts
3414300530	STAY-SIDE PROTECTOR A FRT(LH)	TATA spare parts
3414300536	STAY-S/P ASM FRT	TATA spare parts
3414300550	STAY-SIDE PROTECTOR A RR(LH)	TATA spare parts
3414300555	STAY-S/P ASM RR	TATA spare parts
3414300700	SPACER-TOOL BOX MTG	TATA spare parts
3414300701	SPACER-TOOL BOX MTG	TATA spare parts
3414300770	SPACER A-W/PLATE MTG(RH)	TATA spare parts
3414300772	SPACER A-W/PLATE MTG	TATA spare parts
3414300780	SPACER A-W/PLATE MTG(LH)	TATA spare parts
3414300782	SPACER A-W/PLATE MTG	TATA spare parts
3414300800	PLUG-STAY RR	TATA spare parts
3414301510	BRACKET A-W/PLATE RR 'A'	TATA spare parts
3414301511	BRKT A-W/PLATE RR A	TATA spare parts
3414301530	WORKING PLATE-CENTER	TATA spare parts
3414301532	W/PLATE-CTR	TATA spare parts
3414301540	WORKING PLATE(RH)	TATA spare parts
3414301541	W/PLATE	TATA spare parts
3414301720	BRACKET A-W/PLATE FRT	TATA spare parts
3414301721	BRKT A-W/PLATE FRT	TATA spare parts
3414301840	WORKING PLATE(LH)	TATA spare parts
3414301841	W/PLATE	TATA spare parts
3414302920	PROTECTOR-SIDE(EURO)	TATA spare parts
3414303240	PROTECTOR-SIDE(EURO)	TATA spare parts
3414303250	STAY FRT-S/P ASM RH	TATA spare parts
3414303260	STAY MID-S/P ASM RH	TATA spare parts
3414303270	STAY RR-S/P ASM RH	TATA spare parts
3414400160	STAY-REFLECTOR ASM MTG	TATA spare parts
3414400172	REFLECTOR	TATA spare parts
3414400441	PROTECTOR A REAR LPK2530	TATA spare parts
3421105930	LEAF SPRING A-FRT	TATA spare parts
3421105950	CASTER PLATE	TATA spare parts
3421105990	LEAF SPRING NO.1	TATA spare parts
3421106000	LEAF SPRING NO.2	TATA spare parts
3421106010	LEAF SPRING NO.3	TATA spare parts
3421106020	LEAF SPRING NO.4	TATA spare parts
3421106030	LEAF SPRING NO.5	TATA spare parts
3421106040	LEAF SPRING NO.6	TATA spare parts
3421106050	LEAF SPRING NO.7	TATA spare parts
3421106060	LEAF SPRING NO.8	TATA spare parts
3421106070	LEAF SPRING NO.9	TATA spare parts
3421106080	LEAF SPRING NO.10	TATA spare parts
3421106090	LEAF SPRING NO.11	TATA spare parts
3421106100	LEAF SPRING NO.12	TATA spare parts
3421106110	CENTRE BOLT	TATA spare parts
3421108040	LEAF NO.1	TATA spare parts
3421108050	LEAF NO.2	TATA spare parts

3421108060	LEAF NO.3	TATA spare parts
3421108070	LEAF NO.4	TATA spare parts
3421108080	LEAF NO.5	TATA spare parts
3421108090	LEAF NO.6	TATA spare parts
3421108100	LEAF NO.7	TATA spare parts
3421108110	LEAF NO.8	TATA spare parts
3421108120	LEAF NO.9	TATA spare parts
3421108130	LEAF NO.10	TATA spare parts
3421108140	LEAF NO.11	TATA spare parts
3421108150	CENTER BOLT(L=231)	TATA spare parts
3421108160	LEAF SPRING A-FRT	TATA spare parts
3421108290	LEAF SPRING A-FRT	TATA spare parts
3421108300	LEAF NO.1	TATA spare parts
3421108310	LEAF NO.2	TATA spare parts
3421108320	LEAF NO.3	TATA spare parts
3421108330	LEAF NO.4	TATA spare parts
3421108340	LEAF NO.5	TATA spare parts
3421108350	LEAF NO.6	TATA spare parts
3421108360	LEAF NO.7	TATA spare parts
3421108370	LEAF NO.8	TATA spare parts
3421108380	LEAF NO.9	TATA spare parts
3421108390	LEAF NO.10	TATA spare parts
3421108400	LEAF NO.11	TATA spare parts
3421108410	CENTER BOLT	TATA spare parts
3421108420	CASTER PLATE	TATA spare parts
3421109440	LEAF SPRING A-FRT	TATA spare parts
3421300010	BRACKET-FRT SPRING RR(LH)	TATA spare parts
3421300012	BRACKET-FRT SPRING RR	TATA spare parts
3421300020	BRACKET-FRT SPRING RR(RH)	TATA spare parts
3421300022	BRACKET-FRT SPRING RR	TATA spare parts
3421300030	WASHER-SPRING PIN	TATA spare parts
3421300100	SHACKLE-SPRING	TATA spare parts
3421300103	SHACKLE-SPRING	TATA spare parts
3421300150	SHACKLE A	TATA spare parts
3421300153	SHACKLE A	TATA spare parts
3421300180	BRACKET-FRT SPRING FRT(RH)	TATA spare parts
3421300182	BRACKET-FRT SPRING FRT	TATA spare parts
3421300270	BRACKET-FRT SPRING FRT(LH)	TATA spare parts
3421300273	BRACKET-FRT SPRING FRT	TATA spare parts
3421300340	PIN-FRT SPRING	TATA spare parts
3421300350	CLAMP PLATE	TATA spare parts
3421300370	BUSH-SHACKLE	TATA spare parts
3421300540	U BOLT-FRT SPRING	TATA spare parts
3421300570	U BOLT-FRT SPRING	TATA spare parts
3421300670	BRKT-S/ABS UPR	TATA spare parts
3421302960	BRACKET-FRT SPRING FRT(LH)	TATA spare parts
3421302980	BRACKET-FRT SPRING FRT(RH)	TATA spare parts

3421303650	BRKT-FRT SPRING FRT LH	TATA spare parts
3421303660	BRKT-FRT SPRING FRT RH	TATA spare parts
3421309700	BRKT-FRT SPRING FRT LH	TATA spare parts
3421309710	BRKT-FRT SPRING FRT RH	TATA spare parts
3421309720	BRKT-FRT SPRING RR LH	TATA spare parts
3421309730	BRKT-FRT SPRING RR RH	TATA spare parts
3421309740	PIN-FRT SPRING	TATA spare parts
3421309750	U BOLT-FRT SPRING	TATA spare parts
3422600046	STOP PLATE	TATA spare parts
3423000020	PIN-PLATE SHAFT	TATA spare parts
3423000040	THRUST WASHER	TATA spare parts
3423000041	THRUST WASHER	TATA spare parts
3423000050	PIN-KNOCK TRUNNION BRACKET	TATA spare parts
3423000120	PIPE-TRUNNION BRACKET	TATA spare parts
3423000170	PIN-STRAIGHT	TATA spare parts
3423000180	LOCK PLATE-KNOCK PIN	TATA spare parts
3423000320	BRACKET-TORQUE ROD	TATA spare parts
3423000330	BOLT-BRACKET FIX LWR	TATA spare parts
3423000480	PIN-TRUN SHAFT FIX	TATA spare parts
3423000720	BOLT-TRUNNION SHAFT FIX	TATA spare parts
3423000740	BOLT-TRUNNION BRACKET FIX	TATA spare parts
3423000750	BOLT-TRUNNION BRACKET FIX	TATA spare parts
3423000760	BOLT-TRUN BRKT FIX	TATA spare parts
3423000850	CUSHION RUBBER-REAR(LH)(FWD)	TATA spare parts
3423000852	CUSHION RUBBER-REAR	TATA spare parts
3423000860	CUSHION RUBBER-REAR(RH)(FWD)	TATA spare parts
3423000862	CUSHION RUBBER-REAR	TATA spare parts
3423000870	FLANGE-NUT M27X3.0	TATA spare parts
3423000871	FLANGE-NUT M27X3.0	TATA spare parts
3423000980	SHAFT A-TRUNNION	TATA spare parts
3423000990	SHAFT-TRUNNION	TATA spare parts
3423001240	HEX BOLT	TATA spare parts
3423001290	RUBBER BUSH	TATA spare parts
3423001292	RUBBER BUSH	TATA spare parts
3423001293	RUBBER BUSH	TATA spare parts
3423001410	TRUNNION BRACKET ASM	TATA spare parts
3423001412	TRUNNION BRACKET ASM	TATA spare parts
3423001430	SHIM-SIDE PLATE SHAFT	TATA spare parts
3423001441	PAD-REAR SPRING	TATA spare parts
3423001450	SIDE PLATE-SHAFT	TATA spare parts
3423001460	LOCK PLATE	TATA spare parts
3423001461	LOCK PLATE	TATA spare parts
3423001470	BOLT-SIDE PLATE SHAFT	TATA spare parts
3423001472	BOLT-SIDE PLATE SHAFT	TATA spare parts
3423001480	HUCK PIN	TATA spare parts
3423001490	COLLAR	TATA spare parts
3423001500	TRUNNION BRACKET	TATA spare parts

3423001501	TRUNNION BRACKET	TATA spare parts
3423001530	VALVE-GREASE ESCAPE	TATA spare parts
3423001560	CUSHION RUBBER-REAR	TATA spare parts
3423001570	CUSHION RUBBER-REAR	TATA spare parts
3423001630	BOLT-TORQUE ROD FIX	TATA spare parts
3423001631	BOLT-TORQUE ROD FIX	TATA spare parts
3423001640	BOLT-TORQUE ROD FIX	TATA spare parts
3423001650	NUT	TATA spare parts
3423001660	BUSH	TATA spare parts
3423004360	SPRING SEAT-WITHOUT BUSH	TATA spare parts
3423004370	SPRING SEAT-WITH BUSH	TATA spare parts
3423004380	COVER A-SPRING SEAT	TATA spare parts
3423004610	PAD-RR SPRING	TATA spare parts
3423004920	RUBBER BUSH	TATA spare parts
3423005360	OIL SEAL	TATA spare parts
3423005630	COVER-TRUNNION SHAFT	TATA spare parts
3423005990	TORQUE ROD A(L=476)	TATA spare parts
3423006020	TORQUE ROD A-RWD LWR	TATA spare parts
3423006030	TORQUE ROD	TATA spare parts
3423006080	TORQUE ROD A-FWD UPR (L=487 WITH 22A)	TATA spare parts
3423006090	TORQUE ROD (L=487)	TATA spare parts
3423006140	TORQUE ROD A-FWD UPR	TATA spare parts
3423006150	TORQUE ROD	TATA spare parts
3423006230	TORQUE ROD A-RWD LWR(L=502 WITH 22A)	TATA spare parts
3423006260	TORQUE ROD A-RWD LWR (L=505 WITH 22A)	TATA spare parts
3423006270	TORQUE ROD (L=505)	TATA spare parts
3423006300	TORQUE ROD(L=508)	TATA spare parts
3423006350	TORQUE ROD A-FWD LWR (L=515 WITH 22A)	TATA spare parts
3423006360	TORQUE ROD(L=515)	TATA spare parts
3423006380	TORQUE ROD A-FWD LWR	TATA spare parts
3423006390	TORQUE ROD	TATA spare parts
3423006450	TORQUE ROD(L=528)	TATA spare parts
3423006770	TORQUE ROD A(L=596)	TATA spare parts
3423006900	TORQUE ROD A-RWD LWR	TATA spare parts
3423006920	TORQUE ROD A-FWD UPR (L=487 WITH 22B)	TATA spare parts
3423006940	TORQUE ROD A-FWD UPR	TATA spare parts
3423006970	TORQUE ROD A-RWD LWR(L=502 WITH 22B)	TATA spare parts
3423006980	TORQUE ROD A-RWD LWR (L=505 WITH 22B)	TATA spare parts
3423007010	TORQUE ROD A-FWD LWR (L=515 WITH 22B)	TATA spare parts
3423007020	TORQUE ROD A-FWD LWR	TATA spare parts
3423007530	TORQUE ROD A (L=496)	TATA spare parts
3423007710	TORQUE ROD A-RWD UPR	TATA spare parts
3423007720	TORQUE ROD A-RWD UPR	TATA spare parts
3423007730	TORQUE ROD	TATA spare parts
3423008160	TORQUE ROD A-RWD UPR (L=626 WITH 22A)	TATA spare parts
3423008170	TORQUE ROD A-RWD UPR (L=626 WITH 22B)	TATA spare parts
3423008180	TORQUE ROD(L=626)	TATA spare parts



3423008580	TORQUE ROD A-RWD UPR(L=621 WITH 22A)	TATA spare parts
3423008590	TORQUE ROD A-RWD UPR(L=621 WITH 22B)	TATA spare parts
3423009020	TORQUE ROD A(L=524)	TATA spare parts
3423009040	TORQUE ROD (L=524)	TATA spare parts
3423009150	TORQUE ROD(L=635)	TATA spare parts
3423010170	SPRING SEAT-WO/BUSH	TATA spare parts
3423010180	SPRING SEAT-W/BUSH	TATA spare parts
3423010260	TRUNNION BRKT	TATA spare parts
3423010270	TRUN BRKT ASM	TATA spare parts
3423010280	SPACER INNER	TATA spare parts
3423010290	SPACER	TATA spare parts
3423010330	TORQUE ROD A(L=508)	TATA spare parts
3423010340	TORQUE ROD A(L=528)	TATA spare parts
3423010350	TORQUE ROD A(L=635)	TATA spare parts
3423010360	TORQUE ROD A(L=524)	TATA spare parts
3423010370	RUBBER BUSH	TATA spare parts
3423010460	HUCK PIN	TATA spare parts
3423010470	COLLAR	TATA spare parts
3423011990	SPRING SEAT-W/BUSH	TATA spare parts
3423101790	RR SPRING & SEAT SUB A	TATA spare parts
3423104310	LEAF SPRING A-TRUNNION REAR	TATA spare parts
3423104330	LEAF SPRING NO.1	TATA spare parts
3423104340	LEAF SPRING NO.2	TATA spare parts
3423104350	LEAF SPRING NO.3	TATA spare parts
3423104360	LEAF SPRING NO.4	TATA spare parts
3423104370	LEAF SPRING NO.5	TATA spare parts
3423104380	LEAF SPRING NO.6	TATA spare parts
3423104390	LEAF SPRING NO.7	TATA spare parts
3423104400	LEAF SPRING NO.9	TATA spare parts
3423104410	LEAF SPRING NO.10	TATA spare parts
3423104420	LEAF SPRING NO.11	TATA spare parts
3423104430	CENTRE BOLT	TATA spare parts
3423104620	U BOLT-REAR SPRING	TATA spare parts
3423104630	LEAF SPRING NO.8	TATA spare parts
3423106330	CENTRE BOLT	TATA spare parts
3423106350	NUT-CENTER BOLT	TATA spare parts
3423106370	LEAF NO.1	TATA spare parts
3423106380	LEAF NO.2	TATA spare parts
3423106390	LEAF NO.3	TATA spare parts
3423106420	LEAF NO.6	TATA spare parts
3423106430	LEAF NO.7	TATA spare parts
3423106440	LEAF NO.8	TATA spare parts
3423106450	LEAF NO.9	TATA spare parts
3423106460	LEAF NO.10	TATA spare parts
3423106470	LEAF NO.11	TATA spare parts
3423106480	LEAF NO.12	TATA spare parts
3423106490	CENTER BOLT(L=291)	TATA spare parts

3423106500	LEAF SPRING A-TRUN RR	TATA spare parts
3423106510	U BOLT-RR SPRING	TATA spare parts
3423106860	LEAF NO.4	TATA spare parts
3423106870	LEAF NO.5	TATA spare parts
3423106880	LEAF SPRING A-RR	TATA spare parts
3423106890	LEAF NO.1	TATA spare parts
3423106900	LEAF NO.2	TATA spare parts
3423106910	LEAF NO.3	TATA spare parts
3423106920	LEAF NO.4	TATA spare parts
3423106930	LEAF NO.5	TATA spare parts
3423106940	LEAF NO.6	TATA spare parts
3423106950	LEAF NO.7	TATA spare parts
3423106960	LEAF NO.8	TATA spare parts
3423106970	LEAF NO.9	TATA spare parts
3423106980	LEAF NO.10	TATA spare parts
3423106990	LEAF NO.11	TATA spare parts
3423107010	REAR SPRING&SEAT SUB A	TATA spare parts
3423107020	CENTER BOLT	TATA spare parts
3423107090	U BOLT-RR SPRING	TATA spare parts
3423107100	U BOLT-REAR SPRING	TATA spare parts
3423107690	CENTRE BOLT 302 MM	TATA spare parts
3423107820	REAR SPRING&SEAT SUB ASSY	TATA spare parts
3423150005	COUPLING MOUTH	TATA spare parts
3423200062	SPRING SHACKLE FRONT	TATA spare parts
3423200063	SPG SHACKLE RR	TATA spare parts
3423200902	FRONT SPRING ASSY	TATA spare parts
3423210212	2 LEAF FRT SPG	TATA spare parts
3423210213	LEAF SPRING 3RD	TATA spare parts
3423210711	1 LEAF FRONT SPRING	TATA spare parts
34232107114	ASSY FRST LEAF WITH LEAF	TATA spare parts
3423210712	SECOND LEAF	TATA spare parts
3423210713	LEAF SPRING 4RD	TATA spare parts
3423210714	LEAF SPRING 5TH	TATA spare parts
3423210715	LEAF SPRING 6TH	TATA spare parts
3423210716	LEAF SPRING 7TH	TATA spare parts
3423210717	LEAF SPRING 8TH	TATA spare parts
3423210718	LEAF SPRING 9TH	TATA spare parts
3423210719	LEAF SPRING 10TH	TATA spare parts
3423210720	TENTH LEAF	TATA spare parts
3423220030	SPRING EYE PIN	TATA spare parts
3423220084	CASTER PLATE	TATA spare parts
3423240815	LEAF SPRING 5TH	TATA spare parts
3423240816	LEAF SPRING 6TH	TATA spare parts
3423240913	LEAF SPRING 3RD	TATA spare parts
3423240916	LEAF SPRING 4TH	TATA spare parts
3423240919	LEAF SPRING 7TH	TATA spare parts
3423241011	LEAF SPRING 1ST	TATA spare parts

3423241012	LEAF SPRING 2ND	TATA spare parts
3423241013	LEAF SPRING 3RD	TATA spare parts
3423241014	LEAF SPRING 4TH	TATA spare parts
3423300174	ASSY.SUPT.RUBER BUFFR.R	TATA spare parts
3424000290	SHOCK ABSORBER	TATA spare parts
3424100002	PROP SHAFT REAR 70X3X563	TATA spare parts
3424100110	BRKT-2ND S/ABS LWR	TATA spare parts
3424100120	BRKT-2ND S/ABS LWR	TATA spare parts
3424100730	BRACKET-SHOCK ABSORBER UPR FRT	TATA spare parts
3424100750	BRACKET-SHOCK ABSORBER LWR	TATA spare parts
3424100760	BRACKET-SHOCK ABSORBER LWR	TATA spare parts
3424130011	SPACER PLATE	TATA spare parts
3424200086	BRACKET BRAKE ROD	TATA spare parts
3424230001	BRAKE DRUM REAR 807	TATA spare parts
3424620075	WASHER STEERING SPINDLE BRG.LOWER	TATA spare parts
3431000110	NUT-STRG WHEEL FIX M20X1.5	TATA spare parts
3431000130	HOUSING A-STEERING COLUMN UPR	TATA spare parts
3431000140	HOUSING-STRG COLUMN UPR RR	TATA spare parts
3431000140BK	HOUSING-STRG COLUMN UPR RR (BLACK)	TATA spare parts
3431000142	HOUSING-STRG COLUMN UPR RR	TATA spare parts
3431000142SB	HOUSING-STRG COLUMN UPR RR	TATA spare parts
3431010030	RUBBER SEAL-COLUMN HOUSING	TATA spare parts
3431010030BK	RUBBER SEAL-COLUMN HOUSING (BLACK)	TATA spare parts
3431010033	RUBBER SEAL-COLUMN HOUSING	TATA spare parts
3431010033BK	RUBBER SEAL-COLUMN HOUSING	TATA spare parts
3431010210	HOUSING-STRG COLUMN UPR FRT	TATA spare parts
3431010210BK	HOUSING-STRG COLUMN UPR FRT (BLACK)	TATA spare parts
3431010217	HOUSING-STRG COLUMN UPR FRT	TATA spare parts
3431010217SB	HOUSING-STRG COLUMN UPR FRT	TATA spare parts
3431010230	BOOT-STEERING COLUMN	TATA spare parts
3431010230BK	BOOT-STEERING COLUMN (BLACK)	TATA spare parts
3431010232	BOOT-STEERING COLUMN	TATA spare parts
3431010232BK	BOOT-STEERING COLUMN	TATA spare parts
3431010240	SEAL-STRG COLUMN TO FLOOR	TATA spare parts
3431010240BK	SEAL-STRG COLUMN TO FLOOR (BLACK)	TATA spare parts
3431010241	SEAL-STRG COLUMN TO FLOOR	TATA spare parts
3431010241BK	SEAL-STRG COLUMN TO FLOOR	TATA spare parts
3431010260	HOUSING-STEERING COLUMN LOWER	TATA spare parts
3431010260BK	HOUSING-STEERING COLUMN LWR (BLACK)	TATA spare parts
3431010260SB	HOUSING-STEERING COLUMN LOWER	TATA spare parts
3431010320	COVER-RUBBER SEAL	TATA spare parts
3431010320BK	COVER-RUBBER SEAL	TATA spare parts
3431100010	BODY A-STEERING WHEEL	TATA spare parts
3431100010BK	BODY A-STEERING WHEEL (BLACK)	TATA spare parts
3431100013	BODY ASSY. STEERING WHEEL	TATA spare parts
3431100013BK	BODY ASSY. STEERING WHEEL	TATA spare parts
3431100090	PAD A-HORN	TATA spare parts

3431100090BK	PAD A-HORN (BLACK)	TATA spare parts
3431100092	PAD ASSY. HORN	TATA spare parts
3431100092BK	PAD ASSY. HORN	TATA spare parts
3431300030	BOLT-COLUMN FIX	TATA spare parts
3431300031	BOLT-COLUMN FIX	TATA spare parts
3431300032	BOLT-COLUMN FIX	TATA spare parts
3431300080	SNAP RING	TATA spare parts
3431300100	SPLINE SHAFT	TATA spare parts
3431300140	YOKE ASSY. 2ND	TATA spare parts
3431300150	BOLT-HEX M10X1.25	TATA spare parts
3431300180	STRG COLUMN ASM	TATA spare parts
3431300186	STEERING COLUMN A	TATA spare parts
3431300192	CASE TUBE ASSY. STEERING SHAFT	TATA spare parts
3431300201	SHAFT ASSY. STEERING COLUMN	TATA spare parts
3431300223	BRACKET-COLUMN	TATA spare parts
3431300231	YOKE TUBE A	TATA spare parts
3431300460	HOUSING A-STEERING COLUMN UPR	TATA spare parts
3431400010	BEARING-BALL	TATA spare parts
3431500010	BALANCE SPRING	TATA spare parts
3431500020	BOLT-TILT	TATA spare parts
3431500030	LEVER A-TILT	TATA spare parts
3431500080	WASHER-TILT PLATE	TATA spare parts
3431500090	BOLT-HEX M10X1.25	TATA spare parts
3431500110	BOLT-TILT CENTER	TATA spare parts
3431500120	SLOT NUT	TATA spare parts
3431500130	SPLIT PIN	TATA spare parts
3431500140	NUT-TILT LEVER	TATA spare parts
3431500150	SPACER-TILT	TATA spare parts
3433100040	BOLT-POWER STEERING GEAR FIX	TATA spare parts
3433100080	POWER STEERING GEAR A	TATA spare parts
3433100083	POWER STEERING GEAR A	TATA spare parts
3433100210	BRACKET-STREERING GEAR	TATA spare parts
3433101630	BRACKET-STREERING GEAR	TATA spare parts
3433300410	POWER STEERING PUMP	TATA spare parts
3433400090	PACKING	TATA spare parts
3433400091	PACKING	TATA spare parts
3433400100	SPRING	TATA spare parts
3433400110	SPRING HOLDER	TATA spare parts
3433400122	CAP ASSY.	TATA spare parts
3433400130	FILTER A-P/STRG OIL TANK	TATA spare parts
3433400131	FILTER A	TATA spare parts
3433400140	STRAINER	TATA spare parts
3433400183	P/STRG OIL TANK A	TATA spare parts
3433400193	CAP	TATA spare parts
3433400350	P/STRG OIL TANK A	TATA spare parts
3433400380	P/STRG OIL TANK A	TATA spare parts
3433400420	P/STRG OIL TANK A	TATA spare parts

3434105480	POWER STRG OIL PIPE-SUCTION(1)	TATA spare parts
3434105490	POWER STRG OIL PIPE-SUCTION(2)	TATA spare parts
3434105500	POWER STRG OIL PIPE-SUCTION(3)	TATA spare parts
3434105510	POWER STEERING OIL PIPE-DELIVERY	TATA spare parts
3434105520	POWER STEERING OIL PIPE-RETURN	TATA spare parts
3434105880	POWER STEERING OIL PIPE-DELIVERY	TATA spare parts
3434105890	POWER STEERING OIL PIPE-RETURN	TATA spare parts
3434300590	RUBBER HOSE-SUCTION(1)	TATA spare parts
3434300594	RUBBER HOSE-SUCTION(1)	TATA spare parts
3434300650	RUBBER HOSE-RETURN	TATA spare parts
3434300654	RUBBER HOSE-RETURN	TATA spare parts
3434300880	RUBBER HOSE-DELIVERY	TATA spare parts
3434301650	RUBBER HOSE-RETURN	TATA spare parts
3434301800	RUBBER HOSE-SUCTION(2)	TATA spare parts
3434301810	RUBBER HOSE-SUCTION(3)	TATA spare parts
3434401220	BRKT-POWER STEERING PIPE	TATA spare parts
3434500180	JOINT BOLT M26X1.5(PUMP IN)	TATA spare parts
3434500182	JOINT BOLT M26X1.5	TATA spare parts
3434500190	JOINT BOLT M18X1.5(PUMP OUT/GEAR IN)	TATA spare parts
3434500192	JOINT BOLT M18X1.5	TATA spare parts
3434500210	GASKET(D=26.5)	TATA spare parts
3434500220	GASKET(D=18.5)	TATA spare parts
3434500260	JOINT BOLT-RETURN(GEAR OUT)	TATA spare parts
3434500262	JOINT BOLT-RETURN	TATA spare parts
3435000010	DROP ARM	TATA spare parts
3435000030	KNUCKLE ARM	TATA spare parts
3435000031	KNUCKLE ARM	TATA spare parts
3435000270	TIE ROD ARM(LH)	TATA spare parts
3435000280	TIE ROD ARM(RH)	TATA spare parts
3435000770	TIE ROD ARM(RH)	TATA spare parts
3435000771	TIE ROD ARM	TATA spare parts
3435000780	TIE ROD ARM(LH)	TATA spare parts
3435000781	TIE ROD ARM	TATA spare parts
3435001860	DRAG LINK A	TATA spare parts
3435002610	TIE ROD ASM-1769	TATA spare parts
3435002620	TIE ROD ASM-1723	TATA spare parts
3435005120	DRAG LINK ASM	TATA spare parts
3435005190	DROP ARM	TATA spare parts
3435200070	BOLT	TATA spare parts
3435200071	BOLT	TATA spare parts
3435200270	SLOT NUT	TATA spare parts
3435200530	BOLT-TIE ROD ARM FIX	TATA spare parts
3435200540	HEX NUT-KNUCKLE ARM FIX	TATA spare parts
3435200541	HEX NUT-KNUCKLE ARM FIX	TATA spare parts
3435200560	BOLT-KNUCKLE ARM FIX	TATA spare parts
3435200561	BOLT-KNUCKLE ARM FIX	TATA spare parts
3435202210	TIE ROD END A	TATA spare parts

3435202220	TIE ROD END A	TATA spare parts
3435202230	END BODY-TIE ROD	TATA spare parts
3435202240	END BODY-TIE ROD	TATA spare parts
3435202320	BOLT-HEX	TATA spare parts
3435202330	NUT-HEX M12X1.25	TATA spare parts
3435202340	SPRING WASHER	TATA spare parts
3435202640	TIE ROD	TATA spare parts
3435202650	TIE ROD	TATA spare parts
3435203720	LINK ROD	TATA spare parts
34368	BEARING CONE-4021	TATA spare parts
3441000190	SIDE RING 7.5VX20	TATA spare parts
3441000510	VALVE EXTENSION RR-INNER	TATA spare parts
3441000750	DISC WHEEL A-7.5VX20:WP10S	TATA spare parts
3441001040	DISC WHEEL A-7.5VX20:WP10S	TATA spare parts
3443100570	STUD BOLT-89MM	TATA spare parts
3443100580	STUD BOLT-100MM	TATA spare parts
3443100650	RING-WHEEL STUD	TATA spare parts
3443100690	BOLT-HUB WHEEL	TATA spare parts
3443100720	STUD BOLT-89MM	TATA spare parts
3443100730	STUD BOLT-95MM	TATA spare parts
34463005	PVC Hose Clamp	TATA spare parts
34490001	OIL LEVEL INDICATOR	TATA spare parts
34490004	OIL LEVEL INDICATOR 1*1/4INCH BSP	TATA spare parts
3449977446	OIL SEAL TIMING G H	TATA spare parts
3453100050	SNAP RING	TATA spare parts
3453100100	BUSH-BRAKE SHOE FRT	TATA spare parts
3453100170	PIN-ANCHOR	TATA spare parts
3453100190	PLATE-ANCHOR PIN LOCK	TATA spare parts
3453100200	WASHER-ANCHOR PIN LOCK	TATA spare parts
3453100730	RIVET SHOE & LINING	TATA spare parts
3453100800	HUB & DRUM A-FRT 155	TATA spare parts
3453100830	HUB-FRT	TATA spare parts
3453100990	HUB & DRUM A-FRT 155	TATA spare parts
3453101000	BRAKE DRUM-FRT 155	TATA spare parts
3453101001	BRAKE DRUM-FRT 155	TATA spare parts
3453101020	HUB & DRUM A-FRT 155	TATA spare parts
3453101022	HUB & DRUM A-FRT 155	TATA spare parts
3453101030	HUB-FRT	TATA spare parts
3453101031	HUB-FRT	TATA spare parts
3453200040	BUSH-BRAKE SHOE RR	TATA spare parts
3453200170	PIN-ANCHOR	TATA spare parts
3453200430	GROMMET-CHECK HOLE	TATA spare parts
3453200440	HUB & DRUM A-RR 203 (FOR 10 STUD STL DI	TATA spare parts
3453200442	HUB & DRUM A-RR 203	TATA spare parts
3453200510	HUB & DRUM A-RR 203 (FOR 10 STUD OF STEE	TATA spare parts
3453200512	HUB & DRUM A-RR	TATA spare parts
3453201155	BRAKE DRUM ASSY	TATA spare parts

3453201160	BRAKE DRUM-RR 203	TATA spare parts
3453201162	DRUM-BRAKE	TATA spare parts
3453201171	REAR HUB	TATA spare parts
3453201200	HUB (ABS STEEL)(FOR 10 STUD OF STEEL DI	TATA spare parts
3453301970	QUICK RELEASE VALVE	TATA spare parts
3453301980	DOUBLE CHECK VALVE	TATA spare parts
3453302010	DRAIN COCK A	TATA spare parts
3453401300	PRESSURE CONTROL VALVE	TATA spare parts
3453401310	DIFF CONTROL VALVE ASR	TATA spare parts
3453401360	BRAKE VALVE COMPLETE A	TATA spare parts
3454100030	BOLT	TATA spare parts
3454100100	BUSH-CAM SHAFT	TATA spare parts
3454100110	OIL SEAL	TATA spare parts
3454100170	CAM SHAFT-FRT S	TATA spare parts
3454100180	CAM SHAFT-FRT S	TATA spare parts
3454100390	SHOE A-FRT	TATA spare parts
3454100400	ROLLER-CAM	TATA spare parts
3454100410	PIN-ROLLER	TATA spare parts
3454100420	SNAP RING-ROLLER PIN	TATA spare parts
3454100440	PIN-SHOE RETURN SPRING	TATA spare parts
3454100460	RETURN SPRING-FRT	TATA spare parts
3454100520	LINING-FRT	TATA spare parts
3454100521	LINING-FRT	TATA spare parts
3454100522	LINING-FRT	TATA spare parts
3454100590	DUST COVER A-FRT	TATA spare parts
3454100591	DUST COVER A-FRT	TATA spare parts
3454100680	SHOE & LINING A-FRT	TATA spare parts
3454100683	SHOE & LINING A-FRT	TATA spare parts
3454100780	COLLAR-CAM SHAFT	TATA spare parts
3454100840	AUTO SLACK ADJUSTER-FRT (RH)	TATA spare parts
3454100850	AUTO SLACK ADJUSTER-FRT (LH)	TATA spare parts
3454100920	BRACKET-A.S.A FRT LWR (LH)	TATA spare parts
3454100921	BRACKET-A.S.A FRT LWR	TATA spare parts
3454100930	BRACKET-A.S.A FRT LWR (RH)	TATA spare parts
3454100931	BRACKET-A.S.A FRT LWR	TATA spare parts
3454100940	BRACKET-A.S.A FRT UPR	TATA spare parts
3454100941	BRACKET-A.S.A FRT UPR	TATA spare parts
3454100950	STUD BOLT-SLACK ADJUSTER	TATA spare parts
3454100960	BRKT-POWER CHAMBER	TATA spare parts
3454100980	BRKT-POWER CHAMBER	TATA spare parts
3454101080	SPACER A -CAM SHAFT	TATA spare parts
3454101090	SPACER B -CAM SHAFT	TATA spare parts
3454102180	ANCHOR BRACKET A-FRT	TATA spare parts
3454102190	ANCHOR BRACKET A-FRT	TATA spare parts
3454102200	BRAKE ASSY. FRT	TATA spare parts
3454102210	BRAKE ASSY. FRT	TATA spare parts
3454102280	BRAKE CPL-FRT A.S.A	TATA spare parts

3454102290	BRAKE CPL-FRT A.S.A	TATA spare parts
3454103610	CAM SHAFT-FRT S	TATA spare parts
3454103620	CAM SHAFT-FRT S	TATA spare parts
3454103820	BRAKE A-FRT	TATA spare parts
3454103830	BRAKE A-FRT	TATA spare parts
3454103860	ANCHOR BRKT A-FRT	TATA spare parts
3454103870	ANCHOR BRKT A-FRT	TATA spare parts
3454103910	BRAKE CPL-FRT A.S.A	TATA spare parts
3454103920	BRAKE CPL-FRT A.S.A	TATA spare parts
3454103940	BRKT-ANCHOR	TATA spare parts
3454103960	BRKT-ANCHOR	TATA spare parts
3454103970	SPRING-SHOE RETURN FRT	TATA spare parts
3454104030	SHOE & LINING A-FRT LE	TATA spare parts
3454104040	SHOE & LINING A-FRT TR	TATA spare parts
3454104050	SHOE A-FRT LE	TATA spare parts
3454104060	SHOE A-FRT TR	TATA spare parts
3454104070	PIN-RETURN SPRING	TATA spare parts
3454105260	HUB & DRUM A-FRT 155	TATA spare parts
3454105270	HUB & DRUM A-FRT 155	TATA spare parts
3454106230	HUB & DRUM A-FRT 155	TATA spare parts
3454106280	HUB & DRUM A-FRT 155	TATA spare parts
3454106290	HUB & DRUM A-FRT 155	TATA spare parts
3454106300	SPACER - DISC & DRUM	TATA spare parts
3454200143	BRAKE A-REAR	TATA spare parts
3454200153	BRAKE A-REAR	TATA spare parts
3454200250	CHAMBER BRACKET A	TATA spare parts
3454200260	CHAMBER BRACKET A	TATA spare parts
3454200510	SHOE A-RR	TATA spare parts
3454200520	ROLLER-CAM	TATA spare parts
3454200590	RETURN SPRING-RR	TATA spare parts
3454200640	HEX BOLT M14X1.5	TATA spare parts
3454200660	LINING-RR	TATA spare parts
3454200662	LINING-RR	TATA spare parts
3454200690	ANCHOR BRACKET A-REAR	TATA spare parts
3454200730	BRACKET-A.S.A RR LWR(FWD)	TATA spare parts
3454200731	BRACKET-A.S.A RR LWR	TATA spare parts
3454200740	BRACKET-A.S.A RR UPR(FWD)	TATA spare parts
3454200741	BRACKET-A.S.A RR UPR	TATA spare parts
3454200750	SHOE & LINING A-RR	TATA spare parts
3454200753	SHOE & LINING A-RR	TATA spare parts
3454200780	PIN-SHOE RETURN SPRING	TATA spare parts
3454200790	PIN-ROLLER	TATA spare parts
3454200800	BOLT-ANCHOR BRACKET	TATA spare parts
3454200810	S-CAM SHAFT RR	TATA spare parts
3454200820	S-CAM SHAFT RR	TATA spare parts
3454200840	SPRING WASHER	TATA spare parts
3454200933	BRAKE COMPLETE-RR A.S.A	TATA spare parts



3454200943	BRAKE COMPLETE-RR A.S.A	TATA spare parts
3454201000	BOLT-CHAMBER BRACKET B	TATA spare parts
3454201030	BOLT-CHAMBER BRACKET A	TATA spare parts
3454201500	AUTOSLACK ADJUSTER-RR	TATA spare parts
3454201640	ANCHOR BRACKET ASSY. REAR	TATA spare parts
3454201650	ANCHOR BRACKET ASSY. REAR	TATA spare parts
3454201660	BRAKE A-REAR (RH)	TATA spare parts
3454201670	BRAKE A-REAR (LH)	TATA spare parts
3454201780	BRAKE COMPLETE-RR A.S.A (RH)	TATA spare parts
3454201790	BRAKE COMPLETE-RR A.S.A (LH)	TATA spare parts
3454201960	BRACKET-A.S.A RR UPR	TATA spare parts
3454201980	BRACKET ASSY. SPRING CHAMBER	TATA spare parts
3454201990	BRACKET ASSY. SPRING CHAMBER	TATA spare parts
3454202020	S-CAM SHAFT RR	TATA spare parts
3454202030	S-CAM SHAFT RR	TATA spare parts
3454202170	BRKT A-P/CHAMBER	TATA spare parts
3454202180	BRKT A-P/CHAMBER	TATA spare parts
3454202380	S-CAM SHAFT RR	TATA spare parts
3454202770	S-CAM SHAFT RR	TATA spare parts
3454203040	AUTO S/ADJUSTER A	TATA spare parts
3454203050	AUTO S/ADJUSTER A	TATA spare parts
3454203430	BRAKE COMPLETE-RR A.S.A	TATA spare parts
3454203440	BRAKE COMPLETE-RR A.S.A	TATA spare parts
3454203490	BRAKE ASSY. REAR A.S.A	TATA spare parts
3454203500	BRAKE ASSY. REAR A.S.A	TATA spare parts
3454203930	DUST COVER	TATA spare parts
3454203940	DUST COVER	TATA spare parts
3454205570	BRAKE COMPLETE-RR A.S.A (LH)	TATA spare parts
3454205580	BRAKE COMPLETE-RR A.S.A (RH)	TATA spare parts
3454205590	BRAKE A-REAR A.S.A (LH)	TATA spare parts
3454205600	BRAKE A-REAR A.S.A (RH)	TATA spare parts
3454205610	BRKT A-ANCHOR RR	TATA spare parts
3454205620	BRKT A-ANCHOR RR	TATA spare parts
3454205690	HUB & DRUM A-RR 203 (FOR 10 STUD OF STEE	TATA spare parts
3454205700	HUB & DRUM A-RR 203 (FOR 10 STUD STL D	TATA spare parts
3454205760	BRAKE CPT A-RR A.S.A LH	TATA spare parts
3454205770	BRAKE CPT A-RR A.S.A RH	TATA spare parts
3454205780	BRAKE A-RR 203	TATA spare parts
3454205790	BRAKE A-RR 203	TATA spare parts
3454205800	BRKT A-ANCHOR RR	TATA spare parts
3454205810	BRKT A-ANCHOR RR	TATA spare parts
3454205820	BRKT-ANCHOR RR	TATA spare parts
3454205830	BRKT-ANCHOR RR	TATA spare parts
3454205840	BRKT A-S/CHAMBER	TATA spare parts
3454205850	BRKT A-S/CHAMBER	TATA spare parts
3454205860	BRKT-S/CHAMBER	TATA spare parts
3454205870	BRKT-S/CHAMBER	TATA spare parts

3454205880	S-CAM SHAFT RR	TATA spare parts
3454205890	S-CAM SHAFT RR	TATA spare parts
3454210260	AUTO S/ADJUSTER-RR	TATA spare parts
3454210270	AUTO S/ADJUSTER-RR	TATA spare parts
3454300290	BAND A-AIR TANK LONG	TATA spare parts
3454300293	BAND A-AIR TANK LONG	TATA spare parts
3454300300	BAND A-AIR TANK SHORT	TATA spare parts
3454300301	BAND A-AIR TANK SHORT	TATA spare parts
3454300350	BRACKET-AIR TANK	TATA spare parts
3454300353	BRACKET-AIR TANK	TATA spare parts
3454300360	BRACKET-AIR TANK	TATA spare parts
3454300410	SPACER-AIR TANK	TATA spare parts
3454300440	CLAMP-AIR TANK	TATA spare parts
3454300442	CLAMP-AIR TANK	TATA spare parts
3454300450	TENSIONER	TATA spare parts
3454300470	BRACKET A-WELD BOLT	TATA spare parts
3454300471	BRACKET A-WELD BOLT	TATA spare parts
3454300480	BRACKET A-WELD BOLT	TATA spare parts
3454300481	BRKT A-WELD BOLT	TATA spare parts
3454300711	BRKT-CONNECTOR	TATA spare parts
3454300890	LABEL-SERVICE	TATA spare parts
3454300900	LABEL-EMERGENCY	TATA spare parts
3454301810	AIR TANK A-MAIN	TATA spare parts
3454301820	AIR TANK A-F.R.P	TATA spare parts
3454303290	AIR TANK A-MAIN BLACK COLOUR	TATA spare parts
3454303300	AIR TANK A-F.R.P BLACK COLOUR	TATA spare parts
3454303380	A/TANK A-MAIN FRT (FOR A/TANK-REAR)	TATA spare parts
3454303960	A/TANK A-PARK & PURGE (FOR A/TANK-PARK &	TATA spare parts
3454401160	A.L.S.V A	TATA spare parts
3454401390	CONTROL VALVE-TRAILER	TATA spare parts
3454401410	HOSE COUPLING-RED	TATA spare parts
3454401420	HOSE COUPLING-YELLOW	TATA spare parts
3454401460	TEST COUPLING M16X1.5	TATA spare parts
3454401470	TEST COUPLING M22	TATA spare parts
3454401480	SILENCER-VALVE EXHAUST	TATA spare parts
3454401640	PURGE TANK A	TATA spare parts
3454401643	PURGE TANK ASM	TATA spare parts
3454401991	ROD A-A.L.S.V	TATA spare parts
3454402010	AIR DRYER	TATA spare parts
3454402120	FOUR CIRCUIT PROTECTION VALVE	TATA spare parts
3454402240	RELAY VALVE	TATA spare parts
3454402280	RELAY VALVE	TATA spare parts
3454402290	DUAL RELAY VLV	TATA spare parts
3454402510	DUAL RELAY VALVE	TATA spare parts
3454402520	HAND BRAKE VALVE	TATA spare parts
3454402530	HAND BRAKE VALVE	TATA spare parts
3454402600	SAFETY VALVE A	TATA spare parts

3454402900	ROD A-A.L.S.V	TATA spare parts
3454601630	BRKT-SPRING CHAMBER FRT	TATA spare parts
3454601640	BRKT-SPRING CHAMBER FRT	TATA spare parts
3454601700	SPRING CHAMBER 3030 (RH)(FWD)	TATA spare parts
3454601701	SPRING CHAMBER 3030	TATA spare parts
3454601710	SPRING CHAMBER 3030 (LH)(FWD)	TATA spare parts
3454601711	SPRING CHAMBER 3030	TATA spare parts
3454601720	POWER CHAMBER 24	TATA spare parts
3454601730	POWER CHAMBER 24	TATA spare parts
3454602240	SPRING CHAMBER 2024	TATA spare parts
3454602250	SPRING CHAMBER 2024	TATA spare parts
3454602260	SPRING CHAMBER 2430	TATA spare parts
3454602270	SPRING CHAMBER 2430	TATA spare parts
3454602300	SPRING CHAMBER 3030 (RH)(RWD)	TATA spare parts
3454602310	SPRING CHAMBER 3030 (LH)(RWD)	TATA spare parts
3454602460	SPRING CHAMBER	TATA spare parts
3454602470	SPRING CHAMBER	TATA spare parts
3454602560	POWER CHAMBER LH 30	TATA spare parts
3454602570	POWER CHAMBER RH 30	TATA spare parts
346020140001	FRONT BUMPER ASSEMBLY	TATA spare parts
3473203270	AIR PIPE A-UNION 2W:UNION 2W	TATA spare parts
3473203280	AIR PIPE A-A/COMP:UNION 2W	TATA spare parts
3473203281	AIR PIPE A-A/COMP:UNION 2W	TATA spare parts
3473300380	GROMMET-D40 T8	TATA spare parts
3473300381	GROMMET-D40 T8	TATA spare parts
3473300390	GROMMET-D40 T15	TATA spare parts
3473300490	FLEX HOSE-AIR GAUGE	TATA spare parts
3473400461	CORRUGATE-TUBE	TATA spare parts
3473402660	CORRUGATE-TUBE	TATA spare parts
3473702120	BRKT-NYLON TUBE E1	TATA spare parts
3473702121	BRKT-NYLON TUBE E1	TATA spare parts
3473702260	BAND CLIP	TATA spare parts
3473702270	BAND CLIP	TATA spare parts
3473702310	BAND CLIP	TATA spare parts
3473702350	CLAMP-GUIDE	TATA spare parts
3473703090	BUSHING-FRT AXLE	TATA spare parts
3473703210	BRKT-ASR DIFF VLV	TATA spare parts
3473703430	BRKT-F/HOSE	TATA spare parts
3473703490	IMPULSE RING-FRONT AXLE	TATA spare parts
3473703491	IMPULSE RING-FRONT AXLE	TATA spare parts
3473703500	PULSE RING	TATA spare parts
3473703510	SENSOR BUSH	TATA spare parts
3474203020	AIR PIPE A-UNION 2W:F/HOSE	TATA spare parts
3474203410	AIR PIPE A-F/HOSE:A/DRY IN	TATA spare parts
3474203420	AIR PIPE A-A/DRY OUT:4-CIRCUIT	TATA spare parts
3474205550	A/PIPE A-UN ELB:4-CIRCUIT	TATA spare parts
3474207630	AIR PIPE A-F/HOSE:A/DRY IN	TATA spare parts

3474207640	AIR PIPE A-A/DRY OUT:4-CIRCUIT	TATA spare parts
3474208790	A/PIPE A-F/HOSE:UNION ELB	TATA spare parts
3474208800	A/PIPE A-UNION ELB:A/D IN	TATA spare parts
3474208810	A/PIPE A-A/D OUT:UNION ELB	TATA spare parts
3474300030	FLEX HOSE A-DIFF LOCK(L=646MM)	TATA spare parts
3474300310	FLEX HOSE-FRT	TATA spare parts
3474300320	FLEX HOSE-S/CHAMBER RR FWD	TATA spare parts
3474300330	FLEX HOSE-S/CHAMBER RR FWD	TATA spare parts
3474300360	FLEX HOSE-SPRING CHAMBER PARK	TATA spare parts
3474300370	FLEX HOSE-POWER CHAMBER	TATA spare parts
3474500311	BRKT-F/HOSE T/M FIX	TATA spare parts
3474501120	FLEX HOSE A-AIR CHARGE	TATA spare parts
3474607010	6 MM DIA NYLON TUBE 100 MTR ROLL_NOVUS	TATA spare parts
3474607030	8 MM DIA NYLON TUBE 100 MTR ROLL_NOVUS	TATA spare parts
3474607040	10 MM DIA NYLON TUBE 100 MTR ROLL_NOVUS	TATA spare parts
3474607050	12 MM DIA NYLON TUBE 100 MTR ROLL_NOVUS	TATA spare parts
3474607060	15 MM DIA NYLON TUBE 100 MTR ROLL_NOVUS	TATA spare parts
3474629332	N/TUBE A-H.B.V:UNION-2W	TATA spare parts
3474629390	N/TUBE A-B/VLV:R/VLV FRT	TATA spare parts
3474629402	N/TUBE A-A/T PARK:D.R/VLV	TATA spare parts
3474629730	N/TUBE A-H.B.V UN:D.R/VLV	TATA spare parts
3474630071	N/TUBE A-T.C.V:TRAIL SUPP	TATA spare parts
3474632040	N/TUBE A-H.B.V UN:D.R/VLV	TATA spare parts
3474632050	N/TUBE A-B/VLV:R/VLV FRT	TATA spare parts
3474632060	N/TUBE A-A/T D.R/VLV	TATA spare parts
3474632070	N/TUBE A-R/V RR:S/CH-RR	TATA spare parts
3474700010	NUT FOR 6 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700020	NUT FOR 8 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700030	NUT FOR 10 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700040	NUT FOR 12 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700050	NUT FOR 15 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700060	SLEEVE FOR 6 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700070	SLEEVE FOR 8 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700080	SLEEVE FOR 10 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700090	SLEEVE FOR 12 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700100	SLEEVE FOR 15 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700110	INSERT FOR 6 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700120	INSERT FOR 8 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700130	INSERT FOR 10 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700140	INSERT FOR 12 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700150	INSERT FOR 15 MM DIA NYLON TUBE FITMENT_NOVUS	TATA spare parts
3474700200	MALE CONNECTOR 10-R1/4	TATA spare parts
3474700240	MALE CONNECTOR	TATA spare parts
3474700260	MALE CONNECTOR 15-R1/2	TATA spare parts
3474700320	MALE ELBOW 8-R 1/4	TATA spare parts
3474700330	MALE ELBOW 10-R 1/4	TATA spare parts
3474700350	MALE ELBOW 10-R 1/2	TATA spare parts

3474700370	MALE ELBOW 12-R3/8	TATA spare parts
3474700380	MALE ELBOW 12-R1/2	TATA spare parts
3474700390	MALE ELBOW 15-R 1/2	TATA spare parts
3474700420	BRKT-A.L.S.V	TATA spare parts
3474700650	MALE CONNECTOR 8-R3/8	TATA spare parts
3474700660	MALE CONNECTOR 10-R1/4	TATA spare parts
3474700700	MALE CONNECTOR 12-R1/2	TATA spare parts
3474700740	MALE ELBOW 8-R 1/4	TATA spare parts
3474700750	MALE ELBOW 8-R3/8	TATA spare parts
3474700770	MALE ELBOW 10-R 3/8	TATA spare parts
3474700790	MALE ELBOW 12-R3/8	TATA spare parts
3474700920	MALE RUN TEE 6-R 1/4	TATA spare parts
3474701070	FEMALE 4 PORTS	TATA spare parts
3474701980	NIPPLE-5W NPTF1/8	TATA spare parts
3474702260	UNION CONNECTOR 8-8	TATA spare parts
3474702310	MALE ELBOW 8-M16	TATA spare parts
3474702850	BRKT-JUMPER HOSE	TATA spare parts
3474703120	BRKT-NYLON TUBE E5	TATA spare parts
3474703150	NIPPLE-4W 2-PT1/2 3/8 1/4	TATA spare parts
3474703220	NIPPLE-4W PT3/4	TATA spare parts
3474703490	BRACKET-NYLON TUBE E6	TATA spare parts
3474703690	CLAMP-NYLON TUBE	TATA spare parts
3474703950	GASKET	TATA spare parts
3474703960	GASKET	TATA spare parts
3474703961	GASKET	TATA spare parts
3474704100	UNION 3W 3-PT 1/4	TATA spare parts
3474704150	NIPPLE-3W 2-PT1/2 1/4	TATA spare parts
3474704850	CONNECTOR-3W 2-PT1/2 1/4	TATA spare parts
3474704890	ADAPTER-PT 1/4 M16X1.5	TATA spare parts
3474705751	BRKT-T.C.V	TATA spare parts
3474705950	CHECK VALVE-ELBOW	TATA spare parts
3474706171	ADAPTER-M12 PT3/8	TATA spare parts
3474706310	BRKT-W/ADAPTER	TATA spare parts
3474706320	ADAPTER-M16 PT1/2	TATA spare parts
3474706360	CONNECTOR-2W M22 PT3/8	TATA spare parts
3474706460	CONNECTOR-3W PT3/8 M20 M16	TATA spare parts
3474706480	NIPPLE-3W 2-PT3/8 M16	TATA spare parts
3474706970	CONN ELB-M20 M18 PT1/2	TATA spare parts
3474707070	CHECK VALVE-ELBOW	TATA spare parts
3474707230	JUMPER HOSE A-RED	TATA spare parts
3474707240	JUMPER HOSE A-BLUE	TATA spare parts
3474707860	NIPPLE-4W PT3/4 1/2 1/4 M16	TATA spare parts
34810010	CYLINDER MOUNTING BRACKET	TATA spare parts
34810015	CYLINDER MOUNTING BRACKET	TATA spare parts
34810020	CYLINDER MOUNTING BRACKET	TATA spare parts
348110510001	SEAT ASSY (3)	TATA spare parts
348110520001	SEAT ASSY (3)	TATA spare parts

348110530001	SEAT ASSY. (3)	TATA spare parts
348110550001	SEAT ASSY (2)	TATA spare parts
348110550002	SEAT ASSY (2)	TATA spare parts
348110560001	SEAT ASSY. (2)	TATA spare parts
348110570001	SEAT ASSY. (2)	TATA spare parts
348110580001	SEAT ASSY. (2)	TATA spare parts
348110590001	SEAT ASSY (3)	TATA spare parts
348110600001	SEAT ASSY (2S)	TATA spare parts
348110610001	SEAT ASSY. (2)	TATA spare parts
348110620001	SEAR ASSY RH	TATA spare parts
348110630001	SEAT ASSY REAR LH	TATA spare parts
348110790001	SEAT ASSY. (3)	TATA spare parts
348110850001	SEAT ASSY - 2	TATA spare parts
348110860001	SEAT ASSY - 2	TATA spare parts
348110870001	SEAT ASSY - 2	TATA spare parts
348110900001	SEAT ASSY REAR LH	TATA spare parts
348110910001	SEAT ASSY. RH	TATA spare parts
348110950001	SEAT ASSY. (3) FOR MAXICAB SCHOOL	TATA spare parts
348120200001	SEAT ASSY 1S FLR MOUNTED	TATA spare parts
34820002	RETN. LINE FILTER BODY M/C	TATA spare parts
3485100120	WASHER-SPECIAL RR	TATA spare parts
3485100121	WASHER-SPECIAL RR	TATA spare parts
3485100130	METALO BUSH-FRT CAB SUSP RR	TATA spare parts
3485100132	METALO BUSH-FRT CAB SUSP RR	TATA spare parts
3485100230	STOPPER-BUMPER FRT CAB SUSP	TATA spare parts
3485100329	BRACKET-SUPT FRT CAB SUSP LWR	TATA spare parts
3485100420	DUST COVER	TATA spare parts
3485100421	DUST COVER	TATA spare parts
3485100430	SPACER	TATA spare parts
3485100440	BEARING BOLT-FRT	TATA spare parts
3485100444	BEARING BOLT-FRT	TATA spare parts
3485100450	BEARING BOLT-RR	TATA spare parts
3485100451	BEARING BOLT-RR	TATA spare parts
3485100468	BRACKET-SUPT FRT CAB SUSP LWR	TATA spare parts
3485100470	TAPER ROLLER BEARING	TATA spare parts
3485100903	PIVOT ARM A-FRT CAB SUSP LWR	TATA spare parts
3485100950	BRKT-FRT CAB SUSP DAMPER	TATA spare parts
3485101040	STOPPER-BPR	TATA spare parts
3485101080	SPACER-FRT CAB SUSP	TATA spare parts
3485101081	SPACER-FRT CAB SUSP	TATA spare parts
3485101321	BRACKET A-SUPT FRT CAB SUSP UPR	TATA spare parts
3485101331	BRACKET A-SUPT FRT CAB SUSP UPR	TATA spare parts
3485101550	THRUST BUSH-FRT CAB SUSP RR	TATA spare parts
3485101560	PIVOT ARM A-FRT C/SUSP UPR	TATA spare parts
3485101562	PIVOT ARM A-FRT CAB SUSP UPR	TATA spare parts
3485102110	PIVOT ARM A- FRT SUSP LWR	TATA spare parts
3485102140	LOCK PLATE-FRT BRG BOLT	TATA spare parts

3485102170	BRKT A-SUPT FRT C/SUSP UPR	TATA spare parts
3485102180	BRACKET A-SUPT FRT CAB SUSP UPR (RH)	TATA spare parts
3485102230	BRKT-SUPT FRT CAB SUSP LWR	TATA spare parts
3485102240	BRKT-SUPT FRT CAB SUSP LWR	TATA spare parts
3485102350	TAPER ROLLER BEARING	TATA spare parts
3485103220	SPACER-FRT STRUT LWR	TATA spare parts
3485103260	RUBBER COVER-STRUT BOLT	TATA spare parts
3485104280	BUSH A-FRT C/SUSP RR	TATA spare parts
3485105140	CLIP-CAB TILT PIVOT	TATA spare parts
3485106050	BUSH A-FRT C/SUSP RR	TATA spare parts
3485210010	SPRING-FRT CAB SUSP	TATA spare parts
3485210014	SPRING-FRT CAB SUSP	TATA spare parts
3485300040	S/ABS-CAB SUSP	TATA spare parts
3485600170	BRKT A-CUSHION RUBBER RR C/SUSP	TATA spare parts
3485600173	BRKT A-CUSHION RUBBER RR C/SUSP	TATA spare parts
3485600860	CROSS MEMBER A-RR CAB SUSP	TATA spare parts
3485600864	CROSS MEMBER A-RR CAB SUSP	TATA spare parts
3485602772	CAB SUSPENSION COMPLETE-REAR	TATA spare parts
3485602780	CAB SUSPENSION COMPLETE-REAR	TATA spare parts
3485602782	CAB SUSPENSION COMPLETE-REAR	TATA spare parts
3485602980	MEMBER A-REAR CAB SUSPENSION	TATA spare parts
3485602982	MEMBER ASSY. REAR CAB SUSPENSION	TATA spare parts
3485602990	MEMBER A-REAR CAB SUSPENSION	TATA spare parts
3485602992	MEMBER ASSY. REAR CAB SUSPENSION	TATA spare parts
3485603900	CAB SUSP COMPLETE-RR SUB ASM	TATA spare parts
3485604070	STABILIZER A RR	TATA spare parts
3485604100	CAB SUSPENSION COMPLETE-REAR	TATA spare parts
3485610580	STABILIZER A RR CAB SUSPENSION	TATA spare parts
3485610582	STABILIZER A-RR CAB SUSPENSION	TATA spare parts
3485710010	SPRING-RR CAB SUSPENSION	TATA spare parts
3485710013	SPRING-RR CAB SUSPENSION	TATA spare parts
3487100280	BRKT A-CAB TILT CYL UPR	TATA spare parts
3487100490	BRKT-CAB TILT PIPE 1	TATA spare parts
3487200071	CYL A-CAB TILT	TATA spare parts
3487200072	CYL A-CAB TILT	TATA spare parts
3487200080	CYL A-CAB TILT	TATA spare parts
3487200250	NIPPLE-CAB TILT CYLINDER	TATA spare parts
3487200310	NIPPLE-CAB TILT CYLINDER UP(PULL PORT)	TATA spare parts
3487300262	HAND PUMP A-CAB TILT	TATA spare parts
3487300272	ELEC PUMP A-CAB TILT	TATA spare parts
3487300340	RELAY-CAB TILT	TATA spare parts
3487300761	HAND PUMP A-CAB TILT	TATA spare parts
3487301040	HAND PUMP A-CAB TILT	TATA spare parts
3487301120	ELEC PUMP A-CAB TILT	TATA spare parts
3487301270	ELECTRIC PUMP A-CAB TILT	TATA spare parts
3487301310	SUPPORT A-FRT MUD GUARD (RH)	TATA spare parts
3487310070	SUPPORT A-FRT MUD GUARD (LH)	TATA spare parts

3487310072	SUPPORT A-FRT MUD GUARD	TATA spare parts
3487310160	BRACKET ASSY. SUPPORT FRT MUD GUARD	TATA spare parts
3487310234	SUPPORT A-FRT MUD GUARD	TATA spare parts
3487400010	HOSE A-CAB TILT(L=240 UP)	TATA spare parts
3487400017	HOSE A-CAB TILT	TATA spare parts
3487400030	BRACKET-CAB TILT HOSE	TATA spare parts
3487400032	BRACKET-CAB TILT HOSE	TATA spare parts
3487400391	PIPE A-CAB TILT SUCTION	TATA spare parts
3487400470	COUPLER	TATA spare parts
3487400471	COUPLER	TATA spare parts
3487400950	BRKT-CAB LATCH HOSE CTR	TATA spare parts
3487400951	BRKT-CAB LATCH HOSE CTR	TATA spare parts
3487401430	PIPE A-CAB TILT DOWN1 PUMP	TATA spare parts
3487401440	PIPE A-CAB TILT UP1 PUMP	TATA spare parts
3487401570	PIPE A-CAB TILT DOWN1 CYLINDER	TATA spare parts
3487401690	HOSE A-CAB TILT	TATA spare parts
3487402300	PIPE A-CAB TILT ELECTRIC	TATA spare parts
3487402570	PIPE A-CAB TILT DOWN1 CYLINDER	TATA spare parts
3487402580	PIPE A-CAB TILT UP1 CYLINDER	TATA spare parts
3487403640	PIPE A-CAB TILT SUCTION	TATA spare parts
3487403650	PIPE A-CAB TILT ELECTRIC	TATA spare parts
3487403870	PIPE A-CAB TILT UP1 PUMP	TATA spare parts
3487403880	PIPE A-CAB TILT DN1 PUMP	TATA spare parts
3487500030	SAFETY LOCK A-CAB LATCH	TATA spare parts
3487500033	SAFETY LOCK A-CAB LATCH	TATA spare parts
3487500180	ACTUATING ROD-CAB LATCH	TATA spare parts
3487500181	ACTUATING ROD-CAB LATCH	TATA spare parts
3487500190	CONNECTING ROD A-CAB LATCH	TATA spare parts
3487500210	GUIDE-CONNECTING ROD	TATA spare parts
3487500211	GUIDE-CONNECTING ROD	TATA spare parts
3487500320	CUSHION A-CAB LATCH	TATA spare parts
3487500330	CAB LATCH COMPLETE-CAB TILT	TATA spare parts
3487500331	CAB LATCH COMPLETE-CAB TILT	TATA spare parts
3487500340	CAB LATCH A (LH)	TATA spare parts
3487500341	CAB LATCH A	TATA spare parts
3487500350	CAB LATCH A (RH)	TATA spare parts
3487500351	CAB LATCH A	TATA spare parts
3487501050	CUSHION A-CAB L	TATA spare parts
3487510360	PIN-CONNECTING ROD	TATA spare parts
3487510361	PIN-CONNECTING ROD	TATA spare parts
3491000160	COUPLER A-UNIVERSAL TYPE	TATA spare parts
3491001650	GUIDE BRKT-FRT R/LESS.TYPE(LH)	TATA spare parts
3491001651	GUIDE BRKT-FRT R/LESS.TYPE	TATA spare parts
3491001660	GUIDE BRKT-FRT R/LESS.TYPE(RH)	TATA spare parts
3491001661	GUIDE BRKT-FRT R/LESS.TYPE	TATA spare parts
3491004000	SPACER MTG PLATE;LWR	TATA spare parts
3491004010	BRKT-COUPLER MTG SIDE	TATA spare parts



3491004020	BRKT-COUPLER MTG SIDE	TATA spare parts
3491004050	GUIDE BRKT ASM RR	TATA spare parts
3491004060	GUIDE BRKT ASM RR	TATA spare parts
3491004090	SPACER MTG PLATE;UPR	TATA spare parts
3491004140	BRACKET-COUPLER MTG SIDE(LH)	TATA spare parts
3491004150	BRACKET-COUPLER MTG SIDE(RH)	TATA spare parts
3491004160	SPACER MTG PLATE;LWR(LH)	TATA spare parts
3491004170	SPACER MTG PLATE;LWR(RH)	TATA spare parts
3491004180	SPACER(22T)	TATA spare parts
349951500376	T/KIT W/O APP 2 CYL 95 mm	TATA spare parts
349951500379	T/KIT With APP 2 CYL 95 mm	TATA spare parts
349951500380	T/KIT W/O APP 1 CYL 95 mm	TATA spare parts
349951500381	T/KIT With APP 1CYL 95 mm	TATA spare parts
349951500382	T/KIT W/O APP 1 CYL 120 mm	TATA spare parts
349951500383	T/KIT With APP 1CYL 120 mm	TATA spare parts
349951500384	T/KIT W/O APP 2 CYL 120 mm	TATA spare parts
349951500385	T/KIT With APP 2 CYL 120 mm	TATA spare parts
349951500453	SUCTION HOSE(1X490) TANK TO PUMP	TATA spare parts
349951500454	RETURN LINE HOSE(1ID X1590) MCV TO TA	TATA spare parts
349951500455	RETURN LINE HOSE(1/2ID X2310) CYL TO	TATA spare parts
349951500465	COPPER WASHER	TATA spare parts
349951500467	T' CONNECTOR (M 26X 1.5/M26X1.5/M26X1.5)	TATA spare parts
349951500876	17/16 UNF X M39X2 ADAPTER	TATA spare parts
349951500877	DOWTY WASHER 1 1/4IN BSP	TATA spare parts
349951501032	PNEUMATIC CAB CONTROL	TATA spare parts
349951510004	PNEUMATIC AIR TUBE (OD 6 X ID 4MM)	TATA spare parts
349951510246	MCV SEAL KIT	TATA spare parts
349951510569	PNEUMATICALLY CONTROLLED D C VALVE	TATA spare parts
349951577007	HYDRAULIC TANK	TATA spare parts
349951587161	SUCTION HOSE TANK TO PUMP	TATA spare parts
349951587162	PRESSURE HOSE 3/4IN IDX1150 OL	TATA spare parts
349951587164	M26X113/16IN UNF ADAPTER	TATA spare parts
349951587182	RETURN LINE HOSE ASSY	TATA spare parts
35000006597	3/4INC ADAPTERSADAPTOR3/4INC FEMALETO1/2	TATA spare parts
3500001080	BODY SHELL PAINTED LPK2530 NOVUS	TATA spare parts
3500001110SP	BARE CABIN NOVUS	TATA spare parts
350081100105	ASSY RR VIEW MIRROR	TATA spare parts
35010308109	D E SPANNER C 8 X 10	TATA spare parts
35010309113	SPANNER DEA C 9X11 IS2028-CR. PLATED	TATA spare parts
35010312149	SPANNER DEA C12X14 IS2028-CR.PLATED	TATA spare parts
35010313161	SPANNER DEA C13X16 IS2028 CR PLATED	TATA spare parts
35010313170	SPANNER DEA C13X17 IS2028-CR.PLATED	TATA spare parts
35010318210	SPANNER DEA C18X21 IS2028 CR PLATED	TATA spare parts
35010319224	D E SPANNER C 19 X 22	TATA spare parts
35010398001	SPANNER DEA C8X10 IS2028 SS8451S2-Y	TATA spare parts
35010398019	SPANNER DEA C12X14 IS2028 SS8451S2-Y	TATA spare parts
35010398027	SPANNER DEA C13X16 IS2028 SS8451S2-Y	TATA spare parts

35010398043	RING SPANNER B-O 8X9 IS2029 SS8451S2-Y	TATA spare parts
35010508094	RING SPANNER B-O 8X9 IS2029 CROME PLATED	TATA spare parts
35010510111	RINGSPANNERS10X11MM	TATA spare parts
35010512130	RINGSPANNERS12X13MM	TATA spare parts
35010524278	RING SPANNER B-O 24X27 IS2029 CR.PLATED	TATA spare parts
35010599057	RINGSPANNERS16X17MM	TATA spare parts
35010599138	RINGSPANNERS18X19MM	TATA spare parts
35011219916	SOCKETS1/2INC IMPACTNORMALEXTENSION250-	TATA spare parts
35011219924	SOCKETS1/2INC IMPACTNORMALEXTENSION125N	TATA spare parts
35011219941	REVRATCHET10.1/2IN.1993U2-1/2IN	TATA spare parts
35011219975	SOCKETS1/2INC IMPACTNORMAL1/2INC X1/2INC	TATA spare parts
35011317195	D E SPANNER 17 X 19 IS203	TATA spare parts
35011417190	TUBE SPANNER D E 17 X 19	TATA spare parts
35011424277	TUBULAR SPANNER DE 24X27 IS2030	TATA spare parts
35011900273	TUBE SPANNER S E 27MM	TATA spare parts
35012010115	OPENSANNER10X11MM	TATA spare parts
35012012134	OPENSANNER12X13MM	TATA spare parts
35012018191	OPENSANNER18X19MM	TATA spare parts
35012099043	OPENSANNER16X17MM	TATA spare parts
35012108107	D E SPANNER C 8 X 10	TATA spare parts
35012113178	D E SPANNER C 13 X 17	TATA spare parts
35012119222	D E SPANNER C 19 X 22	TATA spare parts
35012214179	SPANNER14X17	TATA spare parts
35013011280	HEX SOC DEEP 8A/FX3/8SQDR HGISD108 HIPRO	TATA spare parts
35013011301	SOCKETS3/8INC IMPACTTYPE10MMDEEP	TATA spare parts
35013011310	SOCKETS3/8INC IMPACTTYPE11MMDEEP	TATA spare parts
35013012103	SOCKETS1/2INC IMPACTNORMAL10MM	TATA spare parts
35013012138	SOCKETS1/2INC IMPACTNORMAL13MM	TATA spare parts
35013012162	SOCKETS1/2INC IMPACTNORMAL16MM	TATA spare parts
35013012189	SOCKETS1/2INC IMPACTNORMAL18MM	TATA spare parts
35013012219	SOCKETS1/2INC IMPACTNORMAL21MM	TATA spare parts
35013013100	SOCKETS1/2INC IMPACTDEEP10MMDEEP	TATA spare parts
35013013118	SOCKETS1/2INC IMPACTDEEP11MMDEEP	TATA spare parts
35013013134	SOCKETS1/2INC IMPACTDEEP13MMDEEP	TATA spare parts
35013013169	SOCKETS1/2INC IMPACTDEEP16MMDEEP	TATA spare parts
35013013177	SOCKETS1/2INC IMPACTDEEP17MMDEEP	TATA spare parts
35013013185	SOCKETS1/2INC IMPACTDEEP18MMDEEP	TATA spare parts
35013013240	SOCKETS1/2INC IMPACTDEEP24MMDEEP	TATA spare parts
350132060102	SHOCK ABSORBER CAB	TATA spare parts
350132060103	SHOCK ABSORBER CAB	TATA spare parts
350132060104	SHOCK ABSORBER CAB	TATA spare parts
350162028201	RETAINER	TATA spare parts
350167082301	GLASS REAR WINDOW	TATA spare parts
350167086303	RUB MOLDING RR WINDOW	TATA spare parts
350169050101	ROOF LINING	TATA spare parts
350172030108	HANDLE WINDOW REGULATOR	TATA spare parts
350172037702	RUBBER PAD REAR	TATA spare parts

350172037704	RUBBER PAD FRONT	TATA spare parts
350172038601	SPACER WASHER LPTA 713	TATA spare parts
350182020103	INTERIOR LAMP	TATA spare parts
350199000101	NYLOC CAGE NUT	TATA spare parts
35020002296	CLICK T/WRENCH 50-120NM PH9120T1NOVATOR	TATA spare parts
35020005015	TPWR 50 TORQUE WRENCH 1 - 6 KGM TAPARIA	TATA spare parts
350200300001	TML SKOOL ROOF HARNESS LP 410/407	TATA spare parts
350200350001	ROOF HARNESS BS6	TATA spare parts
350200490001	ROOF HARNESS COMPLETE BS6	TATA spare parts
350200500001	ROOF HARNESS - 410 NEO SKOOL BS6	TATA spare parts
350210100001	METER PANEL HARNESS- MAXICAB BS VI BS6	TATA spare parts
350210200001	METER PANEL HARNESS- BSVI STAFF BS6	TATA spare parts
350210310001	METER PANEL HARNESS - STAFF CX BS6	TATA spare parts
350210360001	W/H EMG SWITCH AIS 140-410/36	TATA spare parts
350220510001	TML SKOOL ROOF HARNESS LP 410/407	TATA spare parts
350220520001	ROOF HARNESS COMPLETE- MAXICAB	TATA spare parts
35023303009	WRENCH A300 IS6149 GRADE 2	TATA spare parts
350272300107	KNOB CENTRE FLAP	TATA spare parts
350272300111	LOCK CENTRE FLAP	TATA spare parts
350272300112	DOOR HANDLE INNER LH	TATA spare parts
350272300113	ASSY HANDLE INNER DOOR RH	TATA spare parts
350272300114	DOOR HANDLE INNER LH	TATA spare parts
350272300115	ASSY HANDLE INNER DOOR RH	TATA spare parts
350272300120	DOOR HANDLE INNER LH	TATA spare parts
350272300121	ASSY HANDLE INNER DOOR RH	TATA spare parts
350272300122	ASSY.HANDLE INNER DOOR L.H.	TATA spare parts
350272300123	ASSY HANDLE INNER DOOR RH	TATA spare parts
350272300124	ASSY DOOR HANDLE W/KEY	TATA spare parts
350272300125	ASSY DOOR HANDLE OUTER	TATA spare parts
350272305602	HANDLE LH INNER DOOR	TATA spare parts
350272305603	HANDLE RH INNER DOOR	TATA spare parts
350272500101	WINDOW REGULATOR LH	TATA spare parts
350272500102	WINDOW REGULATOR RH	TATA spare parts
350272500103	WINDOW REGULATOR LH	TATA spare parts
350272500104	WINDOW REGULATOR RH	TATA spare parts
350281100105	ASSY REAR VIEW MIRROR	TATA spare parts
350281100107	RV MIRROR	TATA spare parts
350281100108	RV MIRROR	TATA spare parts
350291000110	SEAT DRIVER MKI	TATA spare parts
350291000122	SEAT DRIVER MKI	TATA spare parts
350291018704	SHOCK ABSORBER	TATA spare parts
350291098701	SPRING/KNOB TO FIXED FRAME	TATA spare parts
35033921509	SCREWDRIVER 0.8X5.5X125	TATA spare parts
35033922106	ENGINEERS SCR.DRIVER 1.2X8X150 PR-IS844	TATA spare parts
35033922556	ENGINEERSSCRDRIVER1.6X10X200PRIS844	TATA spare parts
35033999095	SCR.DRIVER 0.8X5.5X125PR-IS844SS8451S2-Y	TATA spare parts
35033999109	SCR.DRIVER 1.2X8X150 PR-IS844 SS8451S2-Y	TATA spare parts

35034010500	SCREW DRIVER 0.4X2.5X50	TATA spare parts
35034020505	ELEC.SCR.DRIVER 0.4X50PR IS844/911	TATA spare parts
35034030022	TORQUE WRENCH 5-23KGS	TATA spare parts
35034030049	TORQUE WRENCH 14-57 KGM	TATA spare parts
35034099501	SCR.DRIVER 0.4X2.5X50PR IS844 SS8451S2-Y	TATA spare parts
35034201101	CR RECESSED HD SCR DRIVER A1X75 IS844 P3	TATA spare parts
35034202204	PHILIPSHDSCRDRIVERA2X250IS844/863L	TATA spare parts
35034203006	PHILIPSHDSCRDRIVERA3X150IS844/863	TATA spare parts
35045000506	HEXAGONAL (ALLEN) KEY 5 IS3082	TATA spare parts
35045000603	HEXAGONAL (ALLEN) KEY 6 IS3082	TATA spare parts
35045001201	HEXAGONAL (ALLEN) KEY 12 IS3082	TATA spare parts
35045001405	HEXAGONAL KEY 14 IS3082	TATA spare parts
35045099502	HEXAGONAL KEY 12 IS3082 SS8451S2-Y	TATA spare parts
350526017801	COVER	TATA spare parts
350530017801	RUB COVER ACCELERATOR	TATA spare parts
350530017802	COVER PLATE ACCEL	TATA spare parts
350531000101	BRACKET ASSY	TATA spare parts
350532107101	LEAF SPRING 1ST CAB	TATA spare parts
350532107102	LEAF SPRING 2ND	TATA spare parts
350532107103	LEAF 3RD	TATA spare parts
350532107104	LEAF 4TH	TATA spare parts
350532107105	LEAF 5TH	TATA spare parts
350532107106	LEAF 6TH	TATA spare parts
350546017803	BELLOW STRG COLUMN	TATA spare parts
350546027804	COVER PLATE STRG	TATA spare parts
350552050106	ASSY.BUMPER	TATA spare parts
350552070101	SIDE BONNET LH	TATA spare parts
350552070102	SIDE BONNET RH	TATA spare parts
350552070109	BONNET CENTRE	TATA spare parts
350552070111	RADIATOR SHELL	TATA spare parts
350552070119	ASSY BOLT PLATE BS6	TATA spare parts
350552070124	SIDE BONNET FR LH	TATA spare parts
350552070125	SIDE BONNET FR RH	TATA spare parts
350552070126	AIR SCOOP W/TUBE LH	TATA spare parts
350552070127	ASSY AIR SCOOP W TUBE RH	TATA spare parts
350552070129	RUBBER BUFFER BONNET	TATA spare parts
350552070129AE	ASSY.RUBBER BUFFER COMPLETE-1628	TATA spare parts
350552070166	ASSY AIR SCOOP LH WITH TUBE	TATA spare parts
350552070167	ASSY AIR SCOOP RH WITH TUBE	TATA spare parts
350552070172	BONNET CENTRE	TATA spare parts
350552070177	BONNET SIDE LH	TATA spare parts
350552070178	BONNET SIDE RH	TATA spare parts
350552070179	ASSY BONNET SIDE FRT LH DI	TATA spare parts
350552070180	BONNET SIDE FRT RH	TATA spare parts
350552070183	AIR SCOOP LH	TATA spare parts
350552070184	AIR SCOOP RH	TATA spare parts
350552070185	BONNET CENTRE	TATA spare parts

350552070196	ASSY.BONNET SIDE LH.	TATA spare parts
350552070197	BONNET SIDE RH	TATA spare parts
350552070198	BONNET SIDE LH	TATA spare parts
35055207019835	ASSY. BONNET SIDE LH CED+SEAL BS1/2/3/4	TATA spare parts
350552070199	BONNET SIDE RH	TATA spare parts
35055207019935	ASSY. BONNET SIDE RH CED+SEAL BS1/2/3/4	TATA spare parts
350552073801	CUP	TATA spare parts
350552074201	RUBBER FASTENER	TATA spare parts
350552074202	RUBBER FASTENER	TATA spare parts
350552078201	ENGINE HOOD TOP BS6	TATA spare parts
350552078202	RADIATOR SHELL/SFCOWL	TATA spare parts
350552078205	BONNET SIDE LH REAR	TATA spare parts
350552078206	BONNET SIDE RH REAR	TATA spare parts
350552078207	RADIATOR GRILL	TATA spare parts
350552078209	REINFORCEMENT SIDE-L.H.(RADIATOR SHELL)	TATA spare parts
350552078210	REINFORCEMENT SIDE-R.H.(RADIATOR SHELL)	TATA spare parts
350552078211	PANEL INNER ENGINE HOOD-L.H. BS6	TATA spare parts
350552078212	PANEL INNER ENGINE HOOD-R.H. BS6	TATA spare parts
350552078214	REINFORCEMENT(ENGINE HOOD) BS6	TATA spare parts
350552078230	REINFORCEMENT L H BS6	TATA spare parts
350552078231	REINFORCEMENT R H BS6	TATA spare parts
350552078232	GUSSET LH BS6	TATA spare parts
350552078233	GUSSET R H BS6	TATA spare parts
350552078288	BONNET SIDE LH	TATA spare parts
350552078289	BONNET SIDE RH	TATA spare parts
350552078301	SHIM	TATA spare parts
350552178206	BONNET SIDE FRONT L	TATA spare parts
350552178207	BONNET SIDE FRONT RH	TATA spare parts
350559050104	MARKER POLE SFC	TATA spare parts
350559050105	MARKER POLE	TATA spare parts
350559050107	BRACKET MARKER POLE	TATA spare parts
350559050110	MARKER POLE	TATA spare parts
350559057702	RUBBER PAD	TATA spare parts
350560010109	ASSY.SUPPORT L.H. BS6	TATA spare parts
350560010110	ASSY.SUPPORT R.H. BS6	TATA spare parts
350560010115	TIE MEMBER BOTTOM	TATA spare parts
350560010118	BONNET STAY	TATA spare parts
350560010123	TIE MEMBER TOP	TATA spare parts
350560010124	TIE MEMBER BOTTOM	TATA spare parts
350560010128	TIE MEMBER TOP	TATA spare parts
350560010138	ASSY BRACKET LH BS6	TATA spare parts
350560010139	ASSY BRACKET RH BS6	TATA spare parts
350560010145	ASSY. BRACKET.(SEAT BELTS).	TATA spare parts
350560013314	RUBBER FASTENER	TATA spare parts
350560016702	HINGE PIN	TATA spare parts
350560018204	REINFORCEMENT LH	TATA spare parts
350560018205	REINFORCEMENT RH	TATA spare parts

350560018206	TIE MEMBER	TATA spare parts
350560018217	GUSSET BS6	TATA spare parts
350560018225	TIE MEMBER TOP	TATA spare parts
350560018229	TIE MEMBER TOP	TATA spare parts
350560100122	ASSY COWL COMPLETE SE/R W/O TAND M CYL	TATA spare parts
350560100165	ASSY.COWL WELDED-RHD	TATA spare parts
350560100194	COWL COMPLT RHD SK	TATA spare parts
350560120156	COWL BARE	TATA spare parts
350560120161	ASSY BARE COWL	TATA spare parts
350560120197	ASSY.COWL COMPL.RHD	TATA spare parts
350560130141	CAB COMPLT SFC	TATA spare parts
350560130142	CAB COMPLT SFC	TATA spare parts
350560130146	CAB COMPLT W/ROOF HATCH	TATA spare parts
350560130149	ASSY.COWL COMP.RHD	TATA spare parts
350560140175	COWL COMPLT RHD 1612SFC	TATA spare parts
350560140176	COWL BARE RHD SFC1612	TATA spare parts
350560140179	ASSY.COWL COMP.RHD DUAL CIRCUIT	TATA spare parts
350560150177	ASSY CAB COMPLETE SK 1613 CMVR 2000	TATA spare parts
350560150178	ASSY BARE CAB SK 1613 CMVR 2000	TATA spare parts
350560150182	SE 1612 CAB	TATA spare parts
350560150186	COWL COMPLT RHD S CAM	TATA spare parts
350560150193	ASSY CAB COMPLT-SK1613 CMVR2000	TATA spare parts
350560150195	BARE COWL 1612SK/SCAM	TATA spare parts
350560160113	ASSY BARE COWL SE 1613 SCAM	TATA spare parts
350560160129	COWL COMPLT RHD	TATA spare parts
350560160137	ASSY BODY COMPLT.-SA1313 LHD	TATA spare parts
350560160151	SE 1613TC CMVR CAB	TATA spare parts
350560160155	ASSY. CAB SHELL PAINTED	TATA spare parts
350560160156	SE 1613 CMVR 2000 CAB PAINTED-RHD	TATA spare parts
350561062201	FELT STRIP SHORT	TATA spare parts
350561062202	FELT STRIP LONG	TATA spare parts
350561068214	MUDGUARD R.H.	TATA spare parts
350561068215	SUPPORT L H	TATA spare parts
350561068216	SUPPORT R H	TATA spare parts
350561068218	MUDGUARD L.H.	TATA spare parts
350562018209	GUSSET BOTTOM L H BS6	TATA spare parts
350562018210	GUSSET BOTTOM REAR RH BS6	TATA spare parts
350562024301	CLIP	TATA spare parts
350562028202	CHANNEL	TATA spare parts
350562060146	ASSY.TUBE REAR COMPLETE L.H.(AIR SCOOP)	TATA spare parts
350562060147	CLAMP RH	TATA spare parts
350562168223	SUPPORT FRONT (CAB) BS6	TATA spare parts
350564000101	REAR WALL ASSY	TATA spare parts
350564000121	REAR WALL COMP RHD	TATA spare parts
350564000124	REAR WALL COMP	TATA spare parts
350565070120	ASSY RUBBER PACKING	TATA spare parts
350565070121	ASSY BRACKET (ROOF HATCH)	TATA spare parts

350565073308	HINGE BRACKET	TATA spare parts
350565078211	LOCK SUPPORT	TATA spare parts
350565078213	ROOF PANEL	TATA spare parts
350565306301	CLAMP	TATA spare parts
350565307702	SEALING RING BOTTOM	TATA spare parts
350565307703	SEALING RING TOP	TATA spare parts
350566040140	ASSY SEAT BOX	TATA spare parts
350566040144	ASSY SEAT FRAME (CO-DRIVER) LHD	TATA spare parts
350566068222	STEP ADDITIONAL	TATA spare parts
350566068228	STEP-ADDITIONAL	TATA spare parts
350567012301	W/S GLASS SE SHEET	TATA spare parts
350567012302	W/S GLASS SE PLATE	TATA spare parts
350567012308	W/S GLASS	TATA spare parts
350567012309	WINDSHIELD GLASS LAMINATED BS2/3/4	TATA spare parts
350567012503	FILLER PROFILE	TATA spare parts
350567012505	FILLER PROFILE	TATA spare parts
350567016301	RUBBER MOULDING W/SHIELD	TATA spare parts
350567016305	RUBBER MOULDING W/S GLASS	TATA spare parts
350567082301	GLASS REAR WINDOW	TATA spare parts
350568040108	ASY.FLOOR MAT SIDE COMPL. R.H.	TATA spare parts
350568040153	ASY.FLOOR MAT SIDE L.H.	TATA spare parts
350568090101	HANDLE GLOVE BOX	TATA spare parts
350568090102	INSTRUMENT PANEL	TATA spare parts
350568090105	GLOVE BOX LID	TATA spare parts
350568090108	LID CENTRE	TATA spare parts
350568090112	GLOVE BOX LID	TATA spare parts
350568090118	LID CENTRE	TATA spare parts
350568090131	ASSY GLOVE BOX	TATA spare parts
350568090133	INSTRUMENT PANEL RHD	TATA spare parts
350568090135	INSTRUMENT PANEL LHD	TATA spare parts
350568090146	INSTRUMENT PANEL RHD	TATA spare parts
350568090153	ASSY PROTECTIVE COVER-INSTRUMENT PANEL	TATA spare parts
350568092505	BEADING INSTRUMENT PANEL	TATA spare parts
350568096302	RUBBER BUFFER(GLOVE BOX LID)	TATA spare parts
350568097601	BEADING	TATA spare parts
350568900102	ASSY. KIT FOR GLOVE BOX LOCK & KEY	TATA spare parts
350569040105	ASSY.REAR WALL PADDING	TATA spare parts
350569050101	ASSY ROOF LINING	TATA spare parts
350569058218	CORNER PANEL INNER LH	TATA spare parts
350569058219	CORNER PANEL INNER RH RHD	TATA spare parts
350569062101	ROOF BOW(CENTRE) BS6	TATA spare parts
350569062102	ROOF BOW(INTERMEDIATE)	TATA spare parts
350569062103	ROOF BOW (SIDE)	TATA spare parts
350569088201	DECORATIVE BEADING GRILL	TATA spare parts
350572000105	DOOR ASSY COMPLT LH	TATA spare parts
350572000106	DOOR ASSY COMPLT RH	TATA spare parts
350572000109	DOOR ASSY COMPLT LH	TATA spare parts

350572000110	DOOR ASSY COMPLT RH	TATA spare parts
350572000113	DOOR ASSY COMPLT LH RHD	TATA spare parts
350572000114	DOOR ASSY COMPLT RH RHD	TATA spare parts
350572000115	DOOR COMP LH LHD	TATA spare parts
350572000116	ASSY.DOOR COMP.RH-LHD	TATA spare parts
350572000117	KIT FOR ASSY. DOOR COMPLETE LH	TATA spare parts
350572000118	KIT FOR ASSY. DOOR COMPLETE RH	TATA spare parts
350572006301	SEALING RUBBER	TATA spare parts
350572010109	GUIDE FRAME LH	TATA spare parts
350572010110	GUIDE FRAME RH	TATA spare parts
350572012301	GLASS REGULATING WINDOW	TATA spare parts
350572020106	DOOR OUTER PANEL RH	TATA spare parts
350572020107	ASSY DOOR	TATA spare parts
350572020108	DOOR SHELL RH	TATA spare parts
350572020137	DOOR SHELL LH	TATA spare parts
350572020138	DOOR SHELL RH	TATA spare parts
350572020141	ASSY. DOOR PADDING RH	TATA spare parts
350572020142	ASSY. DOOR PADDING LH	TATA spare parts
350572020143	ASSY. DOOR PADDING LH	TATA spare parts
350572020144	ASSY. DOOR PADDING RH	TATA spare parts
350572028230	COVER LH	TATA spare parts
350572030102	HINGE LH	TATA spare parts
350572030103	HINGE RH	TATA spare parts
350572030106	DOOR HANDLE OUT LH W/KEY	TATA spare parts
350572030107	ASSY OUTER HANDLE DOOR COMPL. R.H.	TATA spare parts
350572030110	DOOR LOCK COMP LH RHD	TATA spare parts
350572030111	DOOR LOCK COMP RH RHD	TATA spare parts
350572030120	ASSY.KIT FOR LOCKS & KEY	TATA spare parts
350572037701	DOOR STRAP	TATA spare parts
350572050101	FRAME LH	TATA spare parts
350572050102	FRAME RH	TATA spare parts
350572050103	FRAME LH TURNING WINDOW	TATA spare parts
350572050105	TURNING WINDOW LH	TATA spare parts
350572050106	TURNING WINDOW RH	TATA spare parts
350572050108	WINDOW REGULATOR LH	TATA spare parts
350572050109	WINDOW REGULATOR RH	TATA spare parts
350572050110	ASSY WINDOW REGULATOR LH	TATA spare parts
350572050111	ASSY WINDOW REGULATOR RH	TATA spare parts
350572052301	GLASS TURNING WINDOW	TATA spare parts
350572057701	SEALING RUBBER BOTTOM	TATA spare parts
350572057702	SEALING RUBBER LH	TATA spare parts
350572057703	SEALING RUBBER RH	TATA spare parts
350572057704	SEALING RUBBER	TATA spare parts
350572058801	PIN	TATA spare parts
350572076301	SEALING RUBBER BOTTOM	TATA spare parts
350572076302	SEALING RUBBER TOP	TATA spare parts
350572076303	SEALING RUBBER SFC CAB	TATA spare parts



350572077701	SEALING RUBBER BOTTOM	TATA spare parts
350572077702	SEALING RUBBER TOP	TATA spare parts
350572077703	SEALING RUBBER CORNER	TATA spare parts
350581000101	TATA BADGE SFC	TATA spare parts
350581000102	T EMBLEM SFC	TATA spare parts
350581000103	T EMBLEM	TATA spare parts
350581000104	T EMBLEM 1210	TATA spare parts
350581000107	T EMBLEM	TATA spare parts
350581000108	T EMBLEM	TATA spare parts
350581000111	TATA BADGE	TATA spare parts
350581010101	SUNVISOR	TATA spare parts
350581010112	ASSY SUN VISOR	TATA spare parts
350581013311	BKT TOP RV MIRROR	TATA spare parts
350581100106	RV MIRROR INNER	TATA spare parts
350581900101	ASSY.SOCKET RIFLE BUTT	TATA spare parts
350581900102	ASSY.CLIP (GUN MTG)	TATA spare parts
350582020103	BLINKER LAMP LH	TATA spare parts
350582020104	BLINKER LAMP RH	TATA spare parts
350582040101	WIPER ARM SFC RHD	TATA spare parts
350582040103	LINK	TATA spare parts
350582040104	WIPER BLADE SFC	TATA spare parts
350582040105	BRACKET WIPER MOTOR	TATA spare parts
350582040106	WIPER ARM	TATA spare parts
350582040110	WIPER BLADE	TATA spare parts
350582046003	LINK	TATA spare parts
350582046004	LINK	TATA spare parts
350582049201	WASHER W/MOTOR MTG BKT	TATA spare parts
350582050101	ENGINE BAY LAMP	TATA spare parts
350583030103	CABLE AIR SCOOP	TATA spare parts
350583030110	CABLE AIR SCOOP	TATA spare parts
350583035601	HANDLE VENT FLAP	TATA spare parts
350583035603	HANDLE VENT FLAP	TATA spare parts
350583038701	SPRING CLIP VENT DUCT	TATA spare parts
350583067702	SEALING RUBBER VENT DUCT	TATA spare parts
350583067703	SEALING RUBBER AIR SCOOP	TATA spare parts
350583070104	VENTILATOR FLAP LH	TATA spare parts
350583070105	VENTILATOR FLAP RH	TATA spare parts
350586090121	WASHER UNIT W/BKT	TATA spare parts
350586096930	PLASTIC TUBE	TATA spare parts
350586096931	PLASTIC TUBE	TATA spare parts
350588010105	FENDER LH SFC	TATA spare parts
350588010106	FENDER RH SFC	TATA spare parts
350588016301	FENDER FRONT LH IN FRP	TATA spare parts
350588016302	FENDER FRONT RH IN FRP	TATA spare parts
350588016307	FENDER LH	TATA spare parts
350588016308	FENDER RH 1210SD	TATA spare parts
350588017701	BEADING FENDER	TATA spare parts

350588017703	BEADING FENDER	TATA spare parts
350588018201	FENDER LH SFC	TATA spare parts
350588018202	FENDER RH SFC	TATA spare parts
350588018207	FENDER LH	TATA spare parts
350588019101	WASHER	TATA spare parts
350588050112	SUPPORT LH SFC	TATA spare parts
350588050114	BUMPER SFC	TATA spare parts
350588050118	SUPPORT RH SFC	TATA spare parts
350588050140	BUMPER ASSY W/PLATFORM	TATA spare parts
350588050143	BRACKET LH	TATA spare parts
350588050144	BRACKET RH	TATA spare parts
350588050157	BUMPER ASSY W/PLATFORM	TATA spare parts
350588050166	ASSY SUPPORT LH	TATA spare parts
350588050167	ASSY SUPPORT RH	TATA spare parts
350588050187	ASSY.BUMPER	TATA spare parts
350588050187B3	BUMPER PAINTED ARMY COLOUR	TATA spare parts
350588050192	ASSY COVER BUMPER LH	TATA spare parts
350588050193	ASSY COVER BUMPER RH	TATA spare parts
350588050198	ASSY BUMPER COMPLETE	TATA spare parts
350588050198C0	ASSY. BUMPER W/REFLECTOR- BLACK BS/2/4/6	TATA spare parts
350588058219	SUPPORT LH SFC	TATA spare parts
350588070105	ENGINE HOOD	TATA spare parts
350588070108	HINGE LH	TATA spare parts
350588070112	RUBBER BUFFER TOP	TATA spare parts
350588070113	RUB BUFFER FRT ENG HOOD	TATA spare parts
350588070114	ENGINE HOOD W/PIN	TATA spare parts
350588070117	HINGE RH	TATA spare parts
350588070118	ASSY.HINGE L.H.	TATA spare parts
350588070119	ASSY.HINGE R.H.	TATA spare parts
350588070120	HINGE LEAF BONNET SIDE SE	TATA spare parts
350588070138	ASSY HINGE L H	TATA spare parts
350588070139	ASSY HINGE R H	TATA spare parts
350588070140	HINGE LH	TATA spare parts
350588070141	ASSY HINGE/RH/SF/COWL	TATA spare parts
350588072001	INSULATION	TATA spare parts
350588072902	HINGE LEAF BONNET SIDE SE	TATA spare parts
350588074201	CLAMP ENGINE HOOD	TATA spare parts
350588074202	HOOK ENGINE HOOD	TATA spare parts
350588076304	GRIP BONNET CENTRE	TATA spare parts
350588077501	RUBBER GROMMET	TATA spare parts
350588077701	SEALING RUBBER ENG HOOD	TATA spare parts
350588510105C0	ASSY BUMPER WITH REFLECTOR - BLACK	TATA spare parts
350588518207	BKT REFLECTOR MTG	TATA spare parts
350589010101	BRACKET LH FRONT	TATA spare parts
350589010102	BRACKET RH FRONT	TATA spare parts
350589010104	BRACKET LH CAB MTG REAR	TATA spare parts
350589010105	BRACKET RH CAB MTG REAR	TATA spare parts

350589010106	BKT COWL MTG REAR	TATA spare parts
350589010111	BRACKET LH FRONT	TATA spare parts
350589010112	BRACKET RH FRONT	TATA spare parts
350589010114	SPRING ASSY CAB MTG REAR	TATA spare parts
350589010116	BRACKET LH FRONT CAB MTG	TATA spare parts
350589010117	BRACKET RH FRONT CAB MTG	TATA spare parts
350589010126	BRACKET LH FRONT CAB MTG	TATA spare parts
350589010127	BRACKET RH FRONT CAB MTG	TATA spare parts
350589010129	X MEMBER COWL MNTG.RR	TATA spare parts
350589010131	MOUNTING BRKT RH CAB REAR	TATA spare parts
350589010134	ASSY BRKT. CAB MTG. LH	TATA spare parts
350589010135	ASSY BRKT CAB MTG. RH	TATA spare parts
350589013304	BKT COWL MTG REAR	TATA spare parts
350589013701	CUP FRONT MOUNTING	TATA spare parts
350589013703	CUP FRONT MOUNTING	TATA spare parts
350589016302	COVER	TATA spare parts
350589018201	CROSS MEMBER COWL MTG RR	TATA spare parts
350589018203	CLAMP PLATE CAB MTG SPG	TATA spare parts
350589018217	PLATE FRONT CAB MTG	TATA spare parts
350589018603	SPACER TUBE	TATA spare parts
350589019901	WASHER SS 8451-11	TATA spare parts
350589050101	ASY ACID TRAY	TATA spare parts
350589050103	ASSY ACID TRAY RHD	TATA spare parts
350589054701	COVER BATTERY	TATA spare parts
350589056301	BATTERY ACID TRAY	TATA spare parts
350589056302	BATTERY TRAY	TATA spare parts
350589058205	SUPPORT - BATTERY CLAMP	TATA spare parts
350591010111	ASSY MIDDLE SEAT COMPLT.	TATA spare parts
350591040116	SEAT CO DRIVER	TATA spare parts
350591040119	ASSY CO-DRIVER SEAT	TATA spare parts
350591040121	ASSY BACK REST CO DRIVER SEAT	TATA spare parts
350591040122	ASSY.BACK REST COMP.CO-DRIVER RHD	TATA spare parts
350591070101	ASSY.TUBULAR FRAME	TATA spare parts
350591076701	HINGE PIN	TATA spare parts
350591500117	KIT SEAT BELT BOND	TATA spare parts
350591500119	KIT SEAT BELT	TATA spare parts
350591500126	ASSY. SEAT BELT KIT COMPL.	TATA spare parts
350591500140	ASSY SEAT BELT KIT	TATA spare parts
350591500150	ASSY SEAT BELT KIT	TATA spare parts
350598080103	LOCK WITH KEY	TATA spare parts
350598080107	MASCOT 1210SE	TATA spare parts
350598080110	MASCOT TATA 1210 SD	TATA spare parts
350598080115	MASCOT 1210	TATA spare parts
350598080116	ASSY.LOCK W/KEY GLOVE BOX	TATA spare parts
350598700001	PROFILE VELVETISED RUBBER CHANNEL (DOOR)	TATA spare parts
350599010102	HEX BOLT W/NYLOCK INSERT	TATA spare parts
350599010103	HEX BOLT W/NYLOCK INSERT	TATA spare parts

35066300151	DOUBLE FACE SLEDGE HAMMER 1.5 KG	TATA spare parts
35067312552	BRASSHAMMER1.25KGWITHHANDLE	TATA spare parts
35070501803	COMBI PLIER 180 IS3650	TATA spare parts
35079440173	PLIERS/CUTTERS/DIAOGONALCUTTINGNIPPERS	TATA spare parts
35100000014	ABDRUECKER	TATA spare parts
35100000022	HOLDING FIXTURE	TATA spare parts
35100000031	MONTAGEWAGEN	TATA spare parts
35100000049	LOCATING PAD	TATA spare parts
35100000057	INSERT	TATA spare parts
35100000065	RADBOLZ ANZIEH	TATA spare parts
35100000073	LOCATING PAD	TATA spare parts
35100000081	HANDLE	TATA spare parts
35100000090	LOCATING PAD	TATA spare parts
35100000103	SCHLUPFBUCHSE	TATA spare parts
35100000111	HEISLUFTGEBL	TATA spare parts
35100000120	BLOWER	TATA spare parts
35100000138	SCHNELLGREIFER	TATA spare parts
35100000146	GRUNDGERAET	TATA spare parts
35100000154	HAMMER	TATA spare parts
35100000162	SPRING BALANCE	TATA spare parts
35100000171	HEBELBUEGEL	TATA spare parts
35100000189	EXTRACTOR	TATA spare parts
35100000197	COUNTER SUPPORT	TATA spare parts
35100000201	CENTERING PUNCH	TATA spare parts
35100000219	INNEN ZANGEN	TATA spare parts
35100000227	DRAW BAR	TATA spare parts
35100000235	PRESSURE PLATE	TATA spare parts
35100000243	HYDROSPINDLE	TATA spare parts
35100000251	PUMPE LUFT/OEL	TATA spare parts
35100000260	LOCATING PAD	TATA spare parts
35100000278	HANDLE	TATA spare parts
35100000308	HOLDING FIXTURE	TATA spare parts
35100000316	SCHLAGABZIEHER	TATA spare parts
35100000324	DIGIT TIEFENM	TATA spare parts
35100000332	LIFTING TACKLE	TATA spare parts
35100000341	BREMSEN-SET	TATA spare parts
35110111256	MARKING PUNCH SET CAPITAL 12.5 IS6864	TATA spare parts
35110131257	HANDSTAMPSHANDPUNCHO-912MM	TATA spare parts
3511100480	SILL INNER A-FRT (RH)	TATA spare parts
3511100483	SILL INNER A-FRT	TATA spare parts
3511100600	SILL INNER A-FRT	TATA spare parts
3511100610	FLOOR PANEL ASSY. SIDE	TATA spare parts
3511100620	FLOOR PANEL ASSY. SIDE	TATA spare parts
3511110102	SILL INNER A	TATA spare parts
3511110120	SILL INNER ASSY.	TATA spare parts
3517010022	UNDER FRAME ASSY.	TATA spare parts
3517110016	LONGI MEMBER ASSY.	TATA spare parts

3517110023	LONGI MEMBER ASSY.	TATA spare parts
3517110300	CROSS MEMBER A-RR	TATA spare parts
3517200280	SUPPORT MEMBER A-FLOOR RR	TATA spare parts
3517200290	SUPPORT MEMBER A-FLOOR RR	TATA spare parts
3517210190	CLOSER-RR CROSS MEMBER	TATA spare parts
3517210191	CLOSER-RR CROSS MEMBER	TATA spare parts
3517210610	SUPPORT MEMBER A-FLOOR FRT	TATA spare parts
3517210614	SUPPORT MEMBER A-FLOOR FRT	TATA spare parts
3517210760	CROSS MEMBER A-FRT LWR	TATA spare parts
3519807	GASKET TURBOCHARGER	TATA spare parts
3520100019	ASSY. PLUG	TATA spare parts
3520100168	OIL FILLER CAP	TATA spare parts
3520100416	PUSH ROD CHAMBER COVER	TATA spare parts
3520100617	FRONT ASSY COVER	TATA spare parts
3520100823	ASSY M B CAP NOS 1 2 3 5 & 6	TATA spare parts
3520101023	ASSY M B CAP REAR	TATA spare parts
3520101980	GASKET OIL SUMP TO CYL BLOCK BS1/2/3/4	TATA spare parts
3520110171	BOLT M15X2X121 MAIN BEARING	TATA spare parts
3520110235	SCREW PLUG	TATA spare parts
3520110335	SCREW PLUG	TATA spare parts
3520140922	GASKET	TATA spare parts
3520141022	GASKET LEFT	TATA spare parts
3520141122	GASKET RIGHT	TATA spare parts
3520150001	COVER TIMING GEAR HSG.	TATA spare parts
3520150201	TIMING GEAR HSG.COVER	TATA spare parts
3520150320	GASKET TGH COVER	TATA spare parts
3520150402	TIMING GEAR HOUSING	TATA spare parts
3520150520	GASKET	TATA spare parts
3520160105	COVER CYLINDER HEAD	TATA spare parts
3520160220	GASKET-CYL HD	TATA spare parts
3520160280	GASKET LPO	TATA spare parts
3520160421	CYL.HEAD CVR GASKET EXPORT	TATA spare parts
3520160620	CYLINDER HEAD GASKET	TATA spare parts
3520160720	CYLINDER HEAD GASKET	TATA spare parts
3520180144	RETAINING FLANGE/MALL	TATA spare parts
3520180180	GASKET	TATA spare parts
3520180244	FLANGE LOWER	TATA spare parts
3520180380	GASKET BS4	TATA spare parts
3520303103	ASSY.VIBRATION DAMPER	TATA spare parts
3520305120	ASSY.CON ROD W/O BRG.SHELLS	TATA spare parts
3520310271	CWT BOLT M12X44.5	TATA spare parts
3520321105	RING GEAR BS1/2/3/4	TATA spare parts
3520330001	MAIN BRG UPPER STD	TATA spare parts
3520330002	MAIN BRG LOWER STD	TATA spare parts
3520330007	THRUST BRG UPP HALF STD	TATA spare parts
3520330007DB	MAINBRG	TATA spare parts
3520330008	THRUST BRG LOW HALF STD	TATA spare parts

3520330008DB	MAIN BEARING	TATA spare parts
3520330101	MAIN BRG UPPER STD1	TATA spare parts
3520330102	MAIN BRG LOWER STD1	TATA spare parts
3520330107	THRUST BRG UPPER HALF NORMAL-1	TATA spare parts
3520330107DB	BRG SHELL 4TH UPPER	TATA spare parts
3520330108	THRUST BRG LOWER HALF NORMAL I	TATA spare parts
3520330108DB	4 COL BRG LOW HALF STD-I	TATA spare parts
3520330201	MAIN BRG UPPER RS1	TATA spare parts
3520330202	MAIN BRG LOWER RS1	TATA spare parts
3520330207	THRUST BRG UPP HALF RS1	TATA spare parts
3520330207DB	BRG. SHELL	TATA spare parts
3520330208	THRUST BRG LOW HALF RS1	TATA spare parts
3520330208DB	BRG. SHELL 4TH	TATA spare parts
3520330301	MAIN BRG HALF UPPER REPAIR SIZE II	TATA spare parts
3520330302	MAIN BRG LOWER RS2	TATA spare parts
3520330308	THRUST BRG LOW HALF RS2	TATA spare parts
3520330308DB	BEARING SHELL	TATA spare parts
3520330401	MAIN BRG UPPER RS3	TATA spare parts
3520330402	MAIN BRG LOWER RS3	TATA spare parts
3520330407DB	4 COL BRG UP HALF RS-3	TATA spare parts
3520330408DB	4 COL BRG LOW HALF RS-3	TATA spare parts
3520330501	MAIN BRG HALF UPPER REPAIR SIZE IV	TATA spare parts
3520330502	MAIN BRG HALF LOWER REPAIR SIZE IV	TATA spare parts
3520330507DB	BRG SHELL 4TH U	TATA spare parts
3520330508DB	4 COL BRG LOW HALF RS-4	TATA spare parts
3520330709DB	495 SHELL MAIN BRG UPPER	TATA spare parts
3520330909DB	495 SHELL MAIN BRG UPPER	TATA spare parts
3520370420	GUDGEON PIN	TATA spare parts
3520380076	CYLINDRICAL PIN	TATA spare parts
3520380572	HEX NUT	TATA spare parts
3520380610	CON ROD BRG HALF	TATA spare parts
3520380710	CON ROD BRG	TATA spare parts
3520380810	CON ROD BEARING	TATA spare parts
3520380910	CONROD BRG HALF REPAIR SIZE II	TATA spare parts
3520381150	CON ROD BUSH	TATA spare parts
3520381250	CON.ROD BUSH NORMAL-1- 697 ENGINE	TATA spare parts
3520382271	BOLT CON ROD	TATA spare parts
3520382771	SCREW CON ROD	TATA spare parts
3520500004	GEAR CAMSHAFT	TATA spare parts
3520500634	ASSY ROCKER ARM RH W BUSH	TATA spare parts
3520501033	ASSY.ROCKER ARM LH W BUSH	TATA spare parts
3520510010	CAMSHAFT BEARING NO 1	TATA spare parts
3520510062	BUTTING RING	TATA spare parts
3520520003	CRANKSHAFT GEAR	TATA spare parts
3520520004	GEAR CAMSHAFT	TATA spare parts
3520520201	GEAR CAMSHAFT	TATA spare parts
3520520301	GEAR CAMSHAFT	TATA spare parts

3520520762	THRUST WASHER	TATA spare parts
3520530032	VALVE SEAT RING EXH STD	TATA spare parts
3520530101	VALVE INLET	TATA spare parts
3520530132	VALVE SEAT RING EXH STD1	TATA spare parts
3520531505	VALVE EXHAUST	TATA spare parts
3520531532	VALVE SEAT RING EXH STD	TATA spare parts
3520531631	VALVE SEAT RING INLET STD	TATA spare parts
3520531632	VALVE SEAT RING EXH STD1	TATA spare parts
3520531731	VALVE SEAT RING NORMAL-1	TATA spare parts
3520540205	PUSH ROD BS1/2/3/4	TATA spare parts
3520550186	SHIM	TATA spare parts
3520550410	ROCKER ARM SUPPORT NO-2	TATA spare parts
3520550510	ROCKER ARM SUPPORT NO.2&3	TATA spare parts
3520550610	ROCKER ARM SUPPORT	TATA spare parts
3520700236	SET HIGH PRESSURE LINE	TATA spare parts
3520701113	DRIVE GEAR FIP	TATA spare parts
3520701645	TIMER	TATA spare parts
3520750035	TIMERFLYWEIGHT	TATA spare parts
3520750071	PIN INJECTOR TIMER MTG	TATA spare parts
3520750374	PIN INJECTOR TIMER	TATA spare parts
3520751025	TOOTH SEGMENT	TATA spare parts
3520770314	PUMP GEAR	TATA spare parts
3521300116	CON ROD 94D	TATA spare parts
3521300117	ASSY.PISTON NORMAL	TATA spare parts
3521300216	ASSY CON ROD W/O BRG	TATA spare parts
3521300319	ASSY.CYL.HEAD AIR COMPRESOR	TATA spare parts
3521310028	SPRING HSGP/VLV	TATA spare parts
3521310050	BUSH CON.ROD	TATA spare parts
3521310107	PISTON 94D	TATA spare parts
3521310111	D RING STD 77D	TATA spare parts
3521310114	RING PISTON 77D	TATA spare parts
3521310280	GASKET-SLEEVE TO HEAD	TATA spare parts
3521310380	GASKET-SLEEVE TO HEAD	TATA spare parts
3521310411	N RING STD 77 DIA	TATA spare parts
3521311033	BRG HALF UPPER STD SCAM	TATA spare parts
3521311133	BRG HALF LOWER STD SCAM	TATA spare parts
3521311602	SLEEVE CYLINDER STD 77D	TATA spare parts
3521311702	SLEEVE CYLINDER STD1 77D	TATA spare parts
3521420180	GASKET	TATA spare parts
3521440314	THROTTLE SHAFT	TATA spare parts
3521441250	BUSH	TATA spare parts
3521441350	BUSH	TATA spare parts
3521550172	CLAMPING NUT	TATA spare parts
3521550272	NUT	TATA spare parts
3521800015	PRESSURE RELIEF VALVE	TATA spare parts
3521800315	PRESSURE RELIEF VALVE	TATA spare parts
3521800411	BOWL WITH INSULATOR	TATA spare parts

3521800611	OIL FILTER HOUSING	TATA spare parts
3521801610	OIL FILTER	TATA spare parts
3521810401	HOUSING OIL PUMP	TATA spare parts
3521811220	COVER OIL PUMP	TATA spare parts
3521840032	PRESSURE RELIEF VALVE	TATA spare parts
3521840171	CENTRE PIN	TATA spare parts
3521840329	VALVE HOUSING OIL PR REL VALVE	TATA spare parts
3521840608	FILTER HEAD COVER	TATA spare parts
3521880780	GASKET	TATA spare parts
3522000205	ROLLED PULLEY-WATER PUMP	TATA spare parts
3522000605	ASSY WATER PUMP PULLEY	TATA spare parts
3522003423	ASSY.FAN	TATA spare parts
3522004151	ASSY. UPPER COOLING WATER LINE	TATA spare parts
3522010039	HUB	TATA spare parts
3522010105	SHAFT WATER PUMP	TATA spare parts
3522010258	HOLDER SEALING	TATA spare parts
3522010480	GASKET	TATA spare parts
3522010480AE	GASKET WATER PUMP 713	TATA spare parts
3522010601	WATER PUMP HOUSING	TATA spare parts
3522030080	GASKET(COOLING WATER LINE	TATA spare parts
3522030480	GASKET	TATA spare parts
3522030678	GASKET UPP. WATER COOLING LINE	TATA spare parts
3522030680	GASKET	TATA spare parts
3522030780	GASKET	TATA spare parts
3522030873	THERMOSTAT HOUSING	TATA spare parts
3522033301	UPPER COOLING WATER LINE	TATA spare parts
3522050106	FAN	TATA spare parts
3522053306	FAN BLADE PLASTIC	TATA spare parts
3522420409	TORQUE SUPPORT REAR	TATA spare parts
3522420509	TORQUE SUPPORT-FRONT	TATA spare parts
3522500243	BRACKET OUTER	TATA spare parts
3522540040	BRACKET	TATA spare parts
3522540097	RUBBER BELLOW	TATA spare parts
3522540135	BEARING OUTER RACE	TATA spare parts
3522610780	GASKET RR COVER TO HSG BS4	TATA spare parts
3522640130	SPEEDO GEAR STEEL BIG LHD	TATA spare parts
3522800003	HSG W/INTMEDIATE FLANGE	TATA spare parts
3522800245	GEAR SHIFT LEVER	TATA spare parts
3522800245DB	GEAR SHIFT LEVER	TATA spare parts
3522810104	INTERMEDIATE FLANGE	TATA spare parts
3522810114	COVER FRONT AUXILLARY	TATA spare parts
3522810115	COVER REAR	TATA spare parts
3522810179	GASKET	TATA spare parts
3522810179AE	GASKET 713	TATA spare parts
3522810380	GASKET	TATA spare parts
3522810380AE	GASKET 713	TATA spare parts
3522810480	GASKET	TATA spare parts



3522840011	SHIFTER LEVER HALF UPPER	TATA spare parts
3522840015	BEARING PIN	TATA spare parts
3522840111	SHIFTER LEVER BOTTOM	TATA spare parts
3522900243	SUPPORT	TATA spare parts
3523200063	ASSY.SPRING SHACKLE FRONT SPRING	TATA spare parts
3523200063AE	ASSY SPRING SHACKLE FRONT 1415	TATA spare parts
3523200163	SPRING SHACKLE REAR	TATA spare parts
3523220050	BUSH	TATA spare parts
3523220050DF	BUSH - FRONT SPRING	TATA spare parts
3523220530	SPRING PIN FR SHACKLE	TATA spare parts
3523220530AE	SPRING PINç-1415	TATA spare parts
3523230376	SPACER	TATA spare parts
3523230476	SPACER 40X4.2	TATA spare parts
3523230976	SPACER	TATA spare parts
3523231076	SPACER 4.20 MM	TATA spare parts
3523231276	SPACER 3.90 MM	TATA spare parts
3523231476	SPACER40X3.9	TATA spare parts
3523250001	BRACKET REAR SPRING	TATA spare parts
3523250101	BRACKET REAR SPRING RR	TATA spare parts
3523250101AE	REAR SPRING BRACKET 1628	TATA spare parts
3523250150	BUSH.NORMAL/REAR SPRING	TATA spare parts
3523250150DF	BUSH - REAR SPRING	TATA spare parts
3523250530	SHACKLE PIN	TATA spare parts
3523250530AE	SPRING PIN (REAR) 1628	TATA spare parts
3523310044	RUBBER BUFFER	TATA spare parts
3523380101	STEERING ARM	TATA spare parts
3523510174	PIN	TATA spare parts
3527600036	INSULATION-ENG HOOD	TATA spare parts
3527600040	BRACKET-INSULATION ENG HOOD	TATA spare parts
3527600051	CLIP-INSULATION ENG HOOD	TATA spare parts
3527600090	UNDER COVER A-CHANGE LEVER	TATA spare parts
3527600091	UNDER COVER A-CHANGE LEVER	TATA spare parts
3527600220	INSULATION-ENG HOOD(RH)	TATA spare parts
3527600230	INSULATION-ENG HOOD(LH)	TATA spare parts
3527600240	CLIP-INSULATION ENG HOOD	TATA spare parts
3528204	NUT LOCK	TATA spare parts
3529900163	HOLLOW SCREW	TATA spare parts
3529900604	HEX HEAD COLLAR BOLT	TATA spare parts
3529902040	WASHER VALVE SPRING	TATA spare parts
3529930701	PRESSURE SPRING	TATA spare parts
3529930710	RELEASE SPRING ENGINE BRAKE	TATA spare parts
3529970130	SCREW PLUG	TATA spare parts
3529970271	ADAPTER KIKI PUMP	TATA spare parts
3529970730	PLUG-OIL PRESSURE RELIEF VALVE	TATA spare parts
3531002062	PATCH A-WASHER TANK MTG UPR	TATA spare parts
3531002080	FRONT PANEL-INNER	TATA spare parts
3531002150	FRONT PANEL A-INNER	TATA spare parts

3531002152	FRONT PANEL ASSY.-INNER	TATA spare parts
3531002160	CROSS MEMBER A-FRT INR	TATA spare parts
3531002170	BRACE-STEERING COLUMN MTG	TATA spare parts
3531002171	BRACE-STEERING COLUMN MTG	TATA spare parts
3531002220	STRUT COMPLETE-W/SUPPORT	TATA spare parts
3531002330	PANEL A-FRT LAMP MTG (LH)	TATA spare parts
3531002332	PANEL A-FRT LAMP MTG	TATA spare parts
3531002340	PANEL A-FRT LAMP MTG (RH)	TATA spare parts
3531002341	PANEL A-FRT LAMP MTG	TATA spare parts
3531002430	REINFORCE-CLUTCH PEDAL MTG	TATA spare parts
3531010200	BRKT-FRT INNER HARNESS MTG	TATA spare parts
3531010422	REINFORCE A-W/PIVOT MTG	TATA spare parts
3531010440	REINFORCE A-W/MOTOR MTG	TATA spare parts
3531010442	REINFORCE A-W/MOTOR MTG	TATA spare parts
3531010550	BRACKET A-STEERING COLUMN MTG	TATA spare parts
3532423	HOUSING COMPRESSOR	TATA spare parts
3532763	GASKET ADOPTOR	TATA spare parts
3534291	SCREW HEXAGON HEAD SET	TATA spare parts
3535601	PLUG THREADED	TATA spare parts
3536010040	WEATHERSTRIP A-WIPER PANEL	TATA spare parts
3536010049	WEATHERSTRIP A-WIPER PANEL	TATA spare parts
3536470	TURBOCHARGER 1615TC	TATA spare parts
3536472	TURBOCHARGER-4021	TATA spare parts
3536474	TURBOCHARGER	TATA spare parts
3536675	TURBO CHARGER	TATA spare parts
3537285	TURBOCHARGER	TATA spare parts
3537817	CORE ASSY	TATA spare parts
3538530	TURBOCHARGER	TATA spare parts
3538935	TURBOCHARGER LP1312TC	TATA spare parts
354010020001	FRP DASHBOARD FOR KIDZ	TATA spare parts
354010070001	FRP DASHBOARD FOR MAXICAB	TATA spare parts
354010080001	FRP DASHBAORD ZEAL MODEL	TATA spare parts
3541000410	WIPER PANEL(RH)	TATA spare parts
3541000413	WIPER PANEL	TATA spare parts
3541000641	STAY A-FRT LID	TATA spare parts
3541000670	SEAL-FRT LID HINGE	TATA spare parts
3541000671	SEAL-FRT LID HINGE	TATA spare parts
3541000680	RELEASE CABLE A-FRT LID	TATA spare parts
3541000690	WIPER PANEL CENTER ASSY.	TATA spare parts
3541000700	LOCK A-FRT LID	TATA spare parts
3541000770	SEAL-WIPER PANEL CENTER	TATA spare parts
3541000790	DAMPER-WIPER PIVOT	TATA spare parts
3541000840	WIPER PANEL CENTER ASSY.	TATA spare parts
3541001040	FRT LID COMPLETE ASSY.	TATA spare parts
3541001040AW	FRT LID COMPLETEASSY.	TATA spare parts
3541001040GS	FRT LID COMPLETE ASSY.	TATA spare parts
3541001040IV	FRT LID COMPLETE ASSY.	TATA spare parts

3541001040OR	FRT LID COMPLETE ASSY.	TATA spare parts
3541001280	STAY A-FRT LID	TATA spare parts
3541001281	STAY A-FRT LID	TATA spare parts
3541001290	STAY-FRT LID	TATA spare parts
3541010021	BRACKET-GAS STAY UPPER	TATA spare parts
3541010031	BRACKET-GAS STAY LOWER	TATA spare parts
3541010300	BUFFER HOOD	TATA spare parts
3541010330	REINFORCE A-HANDLE ASST FRT LID (LH)	TATA spare parts
3541010332	REINFORCE A-HANDLE ASST FRT LID	TATA spare parts
3541010340	REINFORCE A-HANDLE ASST FRT LID (RH)	TATA spare parts
3541010342	REINFORCE A-HANDLE ASST FRT LID	TATA spare parts
3541010490	HINGE A-FRT LID(LH)	TATA spare parts
3541010492	HINGE A-FRT LID	TATA spare parts
3541010500	HINGE A-FRT LID(RH)	TATA spare parts
3541010502	HINGE A-FRT LID	TATA spare parts
3541010640	SPRING-LEVER FRT LID	TATA spare parts
3541010780	WIPER PANEL(LH)	TATA spare parts
3541010785	WIPER PANEL	TATA spare parts
3541010870	STRIKER A-FRT LID	TATA spare parts
3541010878	STRIKER A-FRT LID	TATA spare parts
3541010902	BRACKET A-GRILL SUPPORT	TATA spare parts
3541010980	FRT LID COMPLETE	TATA spare parts
3541010980AW	FRT LID COMPLETE(ALASKAN WHITE)	TATA spare parts
3541100270	FRONT CLOSER A(LH)	TATA spare parts
3541100275	FRONT CLOSER ASSY.	TATA spare parts
3541100275BK	FRONT CLOSER ASSY.	TATA spare parts
3541100280	FRONT CLOSER A(RH)	TATA spare parts
3541100285	FRONT CLOSER ASSY.	TATA spare parts
3541100285BK	FRONT CLOSER ASSY.	TATA spare parts
3541100460	LINING-FENDER SURGE TANK (RH)	TATA spare parts
3541100462	LINING-FENDER SURGE TANK	TATA spare parts
3541100690	SUPPORT A-FENDER	TATA spare parts
3541100691	SUPPORT A-FENDER	TATA spare parts
3541100780	LINING-FENDER FRT (LH)	TATA spare parts
3541100781	LINING-FENDER FRT	TATA spare parts
3541100800	LINING-FENDER FRT (RH)	TATA spare parts
3541100801	LINING-FENDER FRT	TATA spare parts
3541101181	FENDER ASSY. RH	TATA spare parts
3541101230	PIPE A-LINING FENDER FRT	TATA spare parts
3541101240	PIPE A-LINING FENDER FRT	TATA spare parts
3541101340	FENDER ASSY. LH	TATA spare parts
3541101350	FENDER A (RH)	TATA spare parts
3541101351	FENDER ASSY. RH	TATA spare parts
3541101352	FENDER ASSY. RH	TATA spare parts
3541101550	CORNER VANE ASSY.	TATA spare parts
3541101550AW	CORNER VANE ASSY.	TATA spare parts
3541101550GS	CORNER VANE ASSY.	TATA spare parts

3541101550IV	CORNER VANE ASSY.	TATA spare parts
3541101550OR	CORNER VANE ASSY.	TATA spare parts
3541101560	CORNER VANE ASSY.	TATA spare parts
3541101560AW	CORNER VANE ASSY.	TATA spare parts
3541101560GS	CORNER VANE ASSY.	TATA spare parts
3541101560IV	CORNER VANE ASSY.	TATA spare parts
3541101560OR	CORNER VANE ASSY.	TATA spare parts
3541101760	STAY A-FENDER (LH)	TATA spare parts
3541101761	STAY A-FENDER	TATA spare parts
3541101770	STAY A-FENDER (RH)	TATA spare parts
3541101771	STAY A-FENDER	TATA spare parts
3541101810	FRONT FENDER SUB A	TATA spare parts
3541101940	LINING-FENDER FRT	TATA spare parts
3541101950	LINING-FENDER FRT	TATA spare parts
3541110070	LINING-FENDER RR (LH)	TATA spare parts
3541110079	LINING-FENDER RR	TATA spare parts
3541110080	LINING-FENDER RR (RH)	TATA spare parts
3541110089	LINING-FENDER RR	TATA spare parts
3542600110	1ST 2ND STEP LH	TATA spare parts
3542600720	1ST 2ND STEP RH	TATA spare parts
3542600730	3RD STEP RH	TATA spare parts
3542600920	ASSY LINER BRKT FRONT LH	TATA spare parts
3542600930	ASSY LINER BRKT FRONT RH	TATA spare parts
3542600980	PIPE A-F FENDER FRT LH	TATA spare parts
3542600990	PIPE A-F FENDER FRT RH	TATA spare parts
3542601140	SUPT A-F/FENDER LH	TATA spare parts
3542601150	SUPT A-F FENDER RH	TATA spare parts
3542601180	EXTN-F/FENDER SUPT	TATA spare parts
3542601250	BRKT-FRT FENDER RR	TATA spare parts
35428	CAMSHAFT SHIM WASHER	TATA spare parts
3542800090	PANEL A-3RD STEP LH	TATA spare parts
3542800100	PANEL A-3RD STEP RH	TATA spare parts
3542800130	SUPT-3RD STEP LH	TATA spare parts
3542800310	SUPT-PNL 3RD STEP FRT RH	TATA spare parts
3545399	REPAIR KIT TURBO	TATA spare parts
3545652	REPAIR KIT TURBO	TATA spare parts
3550000111	ROOF COMPLETE ASSY.	TATA spare parts
3551100150	ROOF PANEL A-FRT OUTER	TATA spare parts
3551100151	ROOF PANEL A-FRT OUTER	TATA spare parts
3551100510	BRACKET-EXTERNAL SUNVISOR SIDE	TATA spare parts
3551100520	BRACKET-EXTERNAL SUNVISOR SIDE	TATA spare parts
3551100530	EXTERNAL SUNVISOR	TATA spare parts
3551100542	FRAME A-EXTERNAL SUNVISOR	TATA spare parts
3551100732	ROOF PANEL-OUTER	TATA spare parts
3551100740	CROSS MEMBER ASSY. ROOF FRT	TATA spare parts
3551100750	CROSS MEMBER A-ROOF RR	TATA spare parts
3551100790	ROOF PANEL-OUTER	TATA spare parts

3551110310	PLATE A-RADIO ANTENNA	TATA spare parts
3551200010	FRONT HEADER INNER	TATA spare parts
3558097	COMPRESSOR AIR	TATA spare parts
3558211	COMPRESSOR AIR	TATA spare parts
3559047	HEAD COMPRESSOR	TATA spare parts
3559049	GASKET AIR COMPRESSOR	TATA spare parts
356020220001	DC TO DC CONVERTOR 12V TO 24V 10A	TATA spare parts
356020590001	LED ROOF LAMP FLAT 12V - 720MM BS6	TATA spare parts
356020600001	LED ROOF LAMP FLAT 12V 300MM BS6	TATA spare parts
356020610001	LED ROOF LAMP FLAT 12V 1040MM BS6	TATA spare parts
356020620001	LED ROOF LAMP N.L FLAT 12V 1040MM BS6	TATA spare parts
356020630001	LED ROOF LAMP 12V 720MM WITH N.L BS6	TATA spare parts
356030130001	MOB. CHARGER SOCKET WT RUBBER COVER 12V	TATA spare parts
356030530001	SALOON LED LAMP 12V(POWER)	TATA spare parts
356030930001	DOOR SWITCH TWO TERMINAL	TATA spare parts
356030950001	LED ROOF LAMP / NA 12 /24 V POWER	TATA spare parts
356030970001	LED ROOF LAMP 24V (W/O DRIVERS	TATA spare parts
356030990001	LED ROOF LAMP 24V (W/O DRIVERS) 700MM	TATA spare parts
356031000001	LED ROOF LAMP W/O N.L W/O DRV 700MM 24V	TATA spare parts
356031030001	LED LIGHT AXE - 29 875MM 24V WITH NIGT B	TATA spare parts
356031040001	LED LIGHT AXE -29 875MM 24V W/O NIGHT BS	TATA spare parts
356031050001	LED ROOF LAMP	TATA spare parts
356031060001	LED ROOF LAMP	TATA spare parts
356031080001	LED AEX-29 570MM 12V W/O N.L	TATA spare parts
356040070001	AIS 140 INFO FITTMENT -LP 407/34 WB	TATA spare parts
3561010014	CAB COMPLETE-REAR	TATA spare parts
3561100350	CAB PANEL-INNER REAR	TATA spare parts
3561110080	CAB PANEL-REAR OUTER	TATA spare parts
3561110088	CAB PANEL-OUTER REAR	TATA spare parts
3561110120	REINFORCE-AIR INTAKE DUCT MTG	TATA spare parts
3561110121	REINFORCE-AIR INTAKE DUCT MTG	TATA spare parts
3561110190	REINFORCE-BACK PANEL OTR A	TATA spare parts
3561110191	REINFORCE-BACK PANEL OTR A	TATA spare parts
3570000030	BODY SIDE ASSY. COMPLETED	TATA spare parts
3570010040	BODY SIDE ASSY. COMPLETED	TATA spare parts
3572100150	QUARTER ASSY. OUTER	TATA spare parts
3572100160	QUARTER ASSY. OUTER	TATA spare parts
3572100180	QUARTER ASSY. OUTER	TATA spare parts
3572100260	RAIL ROOF SIDE A-OUTER (RH)	TATA spare parts
3572100262	RAIL ROOF SIDE A-OUTER	TATA spare parts
3572101020	A PILLAR A-OUTER	TATA spare parts
3572110070	A' PILLAR A-OUTER (LH)	TATA spare parts
3572110073	A PILLAR A-OUTER	TATA spare parts
3572110172	QUARTER ASSY. OUTER	TATA spare parts
3572110210	SILL-OUTER PANEL (LH)	TATA spare parts
3572110218	SILL-OUTER PANEL	TATA spare parts
3572110220	SILL-OUTER PANEL (RH)	TATA spare parts

3572110223	SILL-OUTER PANEL	TATA spare parts
3572110250	RAIL ROOF SIDE A-OUTER (LH)	TATA spare parts
3572110252	RAIL ROOF SIDE A-OUTER	TATA spare parts
3572110310	REINFORCE A-'A' PILLAR (LH)	TATA spare parts
3572110313	REINFORCE A- A PILLAR	TATA spare parts
3572110320	REINFORCE A-'A' PILLAR (RH)	TATA spare parts
3572110323	REINFORCE A- A PILLAR	TATA spare parts
3572110390	REINFORCE A-'A' PILLAR HANDLE MTG (LH)	TATA spare parts
3572110392	REINFORCE A- A PILLAR HANDLE MTG	TATA spare parts
3572110400	REINFORCE A-'A' PILLAR HANDLE MTG (RH)	TATA spare parts
3572110402	REINFORCE A- A PILLAR HANDLE MTG	TATA spare parts
3572110450	REINFORCE ASM-DOOR HINGE	TATA spare parts
3572110630	SILL INNER A-RR (LH)	TATA spare parts
3572110631	SILL INNER A-RR	TATA spare parts
3572110640	SILL INNER A-RR (RH)	TATA spare parts
3572110641	SILL INNER A-RR	TATA spare parts
3572110730	BRACKET-'A' PILLAR TRIM UPR	TATA spare parts
3572110732	BRACKET- A PILLAR TRIM UPR	TATA spare parts
3572110750	FILLER ASM-'A' PILLAR REINFORCE (LH)	TATA spare parts
3572110754	FILLER ASM- A PILLAR REINFORCE	TATA spare parts
3572110760	FILLER ASM-'A' PILLAR REINFORCE (RH)	TATA spare parts
3572110764	FILLER ASM- A PILLAR REINFORCE	TATA spare parts
3572210090	RAIL ROOF SIDE A-INNER (LH)	TATA spare parts
3572210093	RAIL ROOF SIDE A-INNER	TATA spare parts
3572210100	RAIL ROOF SIDE A-INNER (RH)	TATA spare parts
3572210101	RAIL ROOF SIDE A-INNER	TATA spare parts
3572410050	QUARTER PANEL A-INNER (LH)	TATA spare parts
3572410051	QUARTER PANEL A-INNER	TATA spare parts
3572410080	QUARTER PANEL A-INNER	TATA spare parts
3573210030	A' PILLAR A-INNER (LH)	TATA spare parts
3573210037	A PILLAR A-INNER	TATA spare parts
3573210040	'A' PILLAR A-INNER (RH)	TATA spare parts
3573210043	A PILLAR A-INNER	TATA spare parts
3575169	MINOR REPAIR KIT TURBOCHARGER	TATA spare parts
3575217	CORE ASSY	TATA spare parts
3583250001	BRACKET REAR SPRING FRT	TATA spare parts
35841502009	TIGHTENING TOOL (NEW ) -CNG VALVE (MOON)	TATA spare parts
3590794	TURBO CHARGER	TATA spare parts
3592671	TURBOCHARGEER	TATA spare parts
3594310	TURBO CHARGER FOR EURO II ENGINE BUS APP	TATA spare parts
3598110	TURBO CHARGER FOR EURO II ENGINE TIPPER	TATA spare parts
3598566	TURBO CHARGER FOR 6BT SE/SK	TATA spare parts
3599491	TURBOCHARGER	TATA spare parts
3599492	TURBOCHARGER	TATA spare parts
3599718	TURBO CHARGER FOR 100HP FRONT ENG BUS AP	TATA spare parts
3599865	TURBO CHARGER FOR 100HP REAR ENG BUS APP	TATA spare parts
3606534	GASKET CONNECTION	TATA spare parts

3606619	COVER FUEL CONTROL	TATA spare parts
3606653	UNION MALE	TATA spare parts
3606711	HEAD FUEL FILTER	TATA spare parts
3606713	ELBOW MALE UNION	TATA spare parts
3606986	HOSE PLAIN	TATA spare parts
3607140	FUEL FILTER - CNG BUS-LEAN BURN	TATA spare parts
3607142	FUEL CLEANER	TATA spare parts
3607164	CONNECTION ADAPTER	TATA spare parts
3607166	ELEMENT BREATHER	TATA spare parts
3607167	BREATHER CRANKCASE	TATA spare parts
3607269	VALVE CHECK	TATA spare parts
3607276	VALVE PRESSURE REGULATOR	TATA spare parts
3607278	VALVE PRESSURE REGULATOR	TATA spare parts
3607279	CONNECTOR FEMALE	TATA spare parts
3607282	BRACKET BREATHER	TATA spare parts
3607945	SENSOR KNOCK	TATA spare parts
3609867	DATAPLATE	TATA spare parts
3610000080	DOOR A (RH)	TATA spare parts
3610000084	DOOR ASSY. RH	TATA spare parts
3610000120	DOOR A (LH)	TATA spare parts
3610000124	DOOR ASSY. LH	TATA spare parts
3611000490	BRACKET-MIRROR MTG LWR	TATA spare parts
3611000500	BRKT-MIRROR MTG UPR	TATA spare parts
3611010150	BRACKET-MIRROR MTG LWR	TATA spare parts
3611010154	BRACKET-MIRROR MTG LWR	TATA spare parts
3611010160	BRACKET-MIRROR MTG UPR	TATA spare parts
3611010165	BRACKET-MIRROR MTG UPR	TATA spare parts
3612000620	PATCH-CHANNEL DOOR GLASS RR LWR	TATA spare parts
3612000630	PATCH-CHANNEL DOOR GLASS RR LWR	TATA spare parts
3612010190	REINFORCE A-DOOR HINGE (LH)	TATA spare parts
3612010194	REINFORCE A-DOOR HINGE	TATA spare parts
3612010200	REINFORCE A-DOOR HINGE (RH)	TATA spare parts
3612010204	REINFORCE A-DOOR HINGE	TATA spare parts
3613547	SENSOR COOLANT TEMPERATURE-LEAN BURN EN	TATA spare parts
3614000050	OUTSIDE MOULDING	TATA spare parts
3614000080	OUTSIDE MOULDING	TATA spare parts
3614000200	GLASS RUN A-UPR (LH)	TATA spare parts
3614000204	GLASS RUN A-UPR	TATA spare parts
3614000210	GLASS RUN A-UPR (RH)	TATA spare parts
3614000214	GLASS RUN A-UPR	TATA spare parts
3614000220	GLASS RUN FRT LWR	TATA spare parts
3614000221	GLASS RUN FRT LWR	TATA spare parts
3614000230	GLASS RUN RR LWR	TATA spare parts
3614000231	GLASS RUN RR LWR	TATA spare parts
3614000350	CHANNEL A-DOOR GLASS FRT LWR (LH)	TATA spare parts
3614000352	CHANNEL A-DOOR GLASS FRT LWR	TATA spare parts
3614000353	CHANNEL A-DOOR GLASS FRT LWR	TATA spare parts

3614000360	CHANNEL A-DOOR GLASS FRT LWR (RH)	TATA spare parts
3614000362	CHANNEL A-DOOR GLASS FRT LWR	TATA spare parts
3614000363	CHANNEL A-DOOR GLASS FRT LWR	TATA spare parts
3614000370	CHANNEL A-DOOR GLASS RR LWR (LH)	TATA spare parts
3614000371	CHANNEL A-DOOR GLASS RR LWR	TATA spare parts
3614000380	CHANNEL A-DOOR GLASS RR LWR (RH)	TATA spare parts
3614000382	CHANNEL A-DOOR GLASS RR LWR	TATA spare parts
3614000670	GLASS RUN FRT LWR	TATA spare parts
3614000680	GLASS RUN RR LWR	TATA spare parts
3614000770	SEAL OUTSIDE MOULDING	TATA spare parts
3614010090	CHANNEL-DOOR GLASS UPR (LH)	TATA spare parts
3614010091	CHANNEL-DOOR GLASS UPR	TATA spare parts
3614010100	CHANNEL-DOOR GLASS UPR (RH)	TATA spare parts
3614010101	CHANNEL-DOOR GLASS UPR	TATA spare parts
3614010130	CHANNEL-DOOR GLASS FRT UPR (LH)	TATA spare parts
3614010132	CHANNEL-DOOR GLASS FRT UPR	TATA spare parts
3614010140	CHANNEL-DOOR GLASS FRT UPR (RH)	TATA spare parts
3614010142	CHANNEL-DOOR GLASS FRT UPR	TATA spare parts
3614010170	CHANNEL-DOOR GLASS RR UPR (LH)	TATA spare parts
3614010172	CHANNEL-DOOR GLASS RR UPR	TATA spare parts
3614010180	CHANNEL-DOOR GLASS RR UPR (RH)	TATA spare parts
3614010182	CHANNEL-DOOR GLASS RR UPR	TATA spare parts
3616000210	ADD ON DOOR ASM LH	TATA spare parts
3616000220	ADD ON DOOR ASM RH	TATA spare parts
3617000140	WATER TIGHT FORM-DOOR UPR	TATA spare parts
3617000150	WATER TIGHT FORM-DOOR LWR	TATA spare parts
3617000450	TRIM PAD ASSY. DOOR LH	TATA spare parts
3617000450DB	TRIM PAD A-DOOR(LH)(WINDOW-MANUAL)& CO	TATA spare parts
3617000450SB	TRIM PAD ASSY. DOOR LH	TATA spare parts
3617000480	TRIM PAD ASSY. DOOR RH	TATA spare parts
3617000480DB	TRIM PAD ASSY.	TATA spare parts
3617000480SB	TRIM PAD ASSY. DOOR RH	TATA spare parts
3617000550	TRIM PAD A-DOOR(LH)(WINDOW-MANUAL)	TATA spare parts
3617000550DB	TRIM PAD ASSY.	TATA spare parts
3617010230	BRACKET-'E'	TATA spare parts
3617010231	BRACKET- E	TATA spare parts
3617810020	WATER BARRIER SHEET-DOOR	TATA spare parts
3617810023	WATER BARRIER SHEET-DOOR	TATA spare parts
3617810090	WATER PROOF SHEET-DOOR	TATA spare parts
3617810092	WATER PROOF SHEET-DOOR	TATA spare parts
3617959	WASHER LOCK	TATA spare parts
3627695	SEAL O RING	TATA spare parts
3628605	PLUG PIPE	TATA spare parts
3628607	PLUG PIPE	TATA spare parts
36400	CAP SCREW-LONG	TATA spare parts
3641100580	DOOR LOCK UNIT A (LH)	TATA spare parts
3641100581	DOOR LOCK UNIT A	TATA spare parts



3641100590	DOOR LOCK UNIT A (RH)	TATA spare parts
3641100591	DOOR LOCK UNIT A	TATA spare parts
3641100600	HOLDER-ROD	TATA spare parts
3641100730	DOOR LOCK UNIT ASM	TATA spare parts
3641100740	CENTER DOOR LOCK UNIT ASSY LHD RH	TATA spare parts
3641100750	CENTER DOOR LOCK UNIT ASSY RHD LH	TATA spare parts
3641100760	CENTER DOOR LOCK UNIT ASSY RHD RH	TATA spare parts
3642100210	STRIKER A-DOOR	TATA spare parts
3642100211	STRIKER A-DOOR	TATA spare parts
3642200170	ROD-LOCK HANDLE DOOR OTR	TATA spare parts
3642200172	ROD-LOCK HANDLE DOOR OTR	TATA spare parts
3642200190	ROD-LOCK KEY CYLINDER DOOR OTR (LH)	TATA spare parts
3642200191	ROD-LOCK KEY CYLINDER DOOR OTR	TATA spare parts
3642200200	ROD-LOCK KEY CYLINDER DOOR OTR (RH)	TATA spare parts
3642200201	ROD-LOCK KEY CYLINDER DOOR OTR	TATA spare parts
3642210080	BUTTON A-LOCKING DOOR	TATA spare parts
3642210080SB	BUTTON A-LOCKING DOOR	TATA spare parts
3642210120	ESCUTCHEON-REMOTE LOCK	TATA spare parts
3642210120SB	ESCUTCHEON-REMOTE LOCK	TATA spare parts
3642310010	HANDLE A-DOOR OUTER (LH)	TATA spare parts
3642310017	HANDLE A-DOOR OUTER	TATA spare parts
3642310020	HANDLE A-DOOR OUTER (RH)	TATA spare parts
3642310027	HANDLE A-DOOR OUTER	TATA spare parts
3642310100	GASKET FRT-HANDLE DOOR OUTER	TATA spare parts
3642310101	GASKET FRT-HANDLE DOOR OUTER	TATA spare parts
3642310110	GASKET RR-HANDLE DOOR OUTER	TATA spare parts
3642310111	GASKET RR-HANDLE DOOR OUTER	TATA spare parts
3642400180	ADJUST CLIP-INSIDE DOOR	TATA spare parts
3642400181	ADJUST CLIP-INSIDE DOOR	TATA spare parts
3642400210	ROD-LOCK HANDLE DOOR INR (LH)	TATA spare parts
3642400215	ROD-LOCK HANDLE DOOR INR	TATA spare parts
3642400220	ROD-LOCK HANDLE DOOR INR (RH)	TATA spare parts
3642400225	ROD-LOCK HANDLE DOOR INR	TATA spare parts
3642400230	ROD-LOCK REMOTE DOOR INNER	TATA spare parts
3642400240	ROD-LOCK REMOTE DOOR INNER	TATA spare parts
3642410010	HANDLE A-DOOR INSIDE (LH)	TATA spare parts
3642410010DB	HANDLE A-DOOR INSIDE (LH)(DARK BEIGE)	TATA spare parts
3642410013	HANDLE ASSY. DOOR INSIDE	TATA spare parts
3642410013DB	HANDLE A-DOOR I/S	TATA spare parts
3642410013SB	HANDLE ASSY. DOOR INSIDE	TATA spare parts
3642410020	HANDLE A-DOOR INSIDE (RH)	TATA spare parts
3642410020DB	HANDLE A-DOOR INSIDE (RH)(DARK BEIGE)	TATA spare parts
3642410023	HANDLE ASSY. DOOR INSIDE	TATA spare parts
3642410023SB	HANDLE ASSY. DOOR INSIDE	TATA spare parts
3642410080	HANDLE DOOR INNER(LH)	TATA spare parts
3642410080DB	ESCUTCHEON-HANDLE DOOR INNER(LH)(INT COL	TATA spare parts
3642410082	ESCUTCHEON-HANDLE DOOR INNER	TATA spare parts

3642410082SB	ESCUTCHEON-HANDLE DOOR INNER	TATA spare parts
3642410090	HANDLE DOOR INNER(RH)	TATA spare parts
3642410090DB	ESCUTCHEON-HANDLE DOOR INNER(RH)(INT COL	TATA spare parts
3642410092	ESCUTCHEON-HANDLE DOOR INNER	TATA spare parts
3642410092SB	ESCUTCHEON-HANDLE DOOR INNER	TATA spare parts
3644000010	DOOR REGULATOR A-MANUAL (LH)	TATA spare parts
3644000013	DOOR REG A-MANUAL	TATA spare parts
3644000014	DOOR REG A-MANUAL	TATA spare parts
3644000020	DOOR REGULATOR A-MANUAL (RH)	TATA spare parts
3644000023	DOOR REG A-MANUAL	TATA spare parts
3644001520	REG ASSY-DR PWR WDW LH	TATA spare parts
3645100110	CRANK A-WINDOW LIFTER	TATA spare parts
3645100110SB	CRANK A-WINDOW LIFTER(SOLARIS BEIGE)	TATA spare parts
3645100111	CRANK ASSY. WINDOW LIFTER	TATA spare parts
3645100111SB	CRANK ASSY. WINDOW LIFTER	TATA spare parts
3645400010	DOOR REGULATOR	TATA spare parts
3645400010SB	ESCUTCHEON-DOOR REGULATOR(SOLARIS BEIGE)	TATA spare parts
3645400011	ESCUTCHEON-DOOR REGULATOR	TATA spare parts
3645400011SB	ESCUTCHEON-DOOR REGULATOR	TATA spare parts
3647100090	SPLIT SLEEVE	TATA spare parts
3647100110	HINGE A-DOOR	TATA spare parts
3647110050	CHECK ARM A	TATA spare parts
3647110056	CHECK ARM A	TATA spare parts
3651001330	BRKT A-FRAME I/P CENTER	TATA spare parts
3651001331	BRKT A-FRAME I/P CENTER	TATA spare parts
3651001620	FRAME A-I/P(LH)	TATA spare parts
3651001622	FRAME A-I/P	TATA spare parts
3651001730	I/P FRAME-LWR RR(LH)	TATA spare parts
3651001731	I/P FRAME-LWR RR	TATA spare parts
3651001770	FRAME A-I/P CENTER	TATA spare parts
3651001930	FRAME A-I/P	TATA spare parts
3651002300	ASSIST GRIP A-ENTRY(RH)	TATA spare parts
3651002300DB	ASSIST GRIP A-ENTRY(RH)(DARK BEIGE)	TATA spare parts
3651002301	ASSIST GRIP ASSY. ENTRY	TATA spare parts
3651002301DB	ASSIST GRIP ASSY. ENTRY	TATA spare parts
3651002320	ASSIST GRIP A-ENTRY(LH)	TATA spare parts
3651002320DB	ASSIST GRIP A-ENTRY(LH)(DARK BEIGE)	TATA spare parts
3651002321	ASSIST GRIP ASSY. ENTRY	TATA spare parts
3651002321DB	ASSIST GRIP ASSY. ENTRY	TATA spare parts
3651002420	BADGE-BINNACLE SWITCH	TATA spare parts
3651002420BK	BADGE-BINNACLE SWITCH	TATA spare parts
3651002930BK	BINNACLE A(BLACK)	TATA spare parts
3651002960	FRAME A-I/P(RH)	TATA spare parts
3651010029	BINNACLE ASSY.	TATA spare parts
3651010029BK	BINNACLE ASSY.	TATA spare parts
3651011410	SUPPORT BRKT A-I/P FRAME	TATA spare parts
3651012410	UPPER PANEL-PASSENGER	TATA spare parts

3651012410DB	UPPER PANEL-PASSENGER(DARK BEIGE)	TATA spare parts
3651012411	UPPER PANEL-PASSENGER	TATA spare parts
3651012411SB	UPPER PANEL-PASSENGER	TATA spare parts
3651012420	LOWER PANEL ASSY. PASSENGER	TATA spare parts
3651012420DB	LOWER PANEL A-PASSENGER(DARK BEIGE)	TATA spare parts
3651012420SB	LOWER PANEL ASSY. PASSENGER	TATA spare parts
3651012440	LOWER PANEL ASSY. CTR CONSOLE PASS	TATA spare parts
3651012440DB	LOWER PANEL A-CTR CONSOLE PASS(DARK BEIG	TATA spare parts
3651012440SB	LOWER PANEL ASSY. CTR CONSOLE PASS	TATA spare parts
3651012470	END CAP A	TATA spare parts
3651012470DB	END CAP A(LH)(DARK BEIGE)	TATA spare parts
3651012470SB	END CAP A	TATA spare parts
3651012490	FUSE BOX LID A	TATA spare parts
3651012490DB	FUSE BOX LID A(DARK BEIGE)	TATA spare parts
3651012491	FUSE BOX LID A	TATA spare parts
3651012491SB	FUSE BOX LID A	TATA spare parts
3651014280	COVER-BINNACLE BACK ASSY.	TATA spare parts
3651014280DB	COVER-BINNACLE BACK A(DARK BEIGE)	TATA spare parts
3651014280SB	COVER-BINNACLE BACK ASSY.	TATA spare parts
3651014320	FACIA END CAP ASSY.	TATA spare parts
3651014320BK	FACIA END CAP ASSY.	TATA spare parts
3651014340	LOWER PANEL ASSY. DRIVER	TATA spare parts
3651014340DB	LOWER PANEL A-DRIVER(DARK BEIGE)	TATA spare parts
3651014340SB	LOWER PANEL ASSY. DRIVER	TATA spare parts
3651014370	END CAP ASM(RH)	TATA spare parts
3651014370DB	END CAP ASM(RH)(DARK BEIGE)	TATA spare parts
3651014371	END CAP ASSY.	TATA spare parts
3651014371SB	END CAP ASSY.	TATA spare parts
3651014390	ACCESS PANEL A-DRIVER(LH)	TATA spare parts
3651014390DB	ACCESS PANEL A-DRIVER(LH)(DARK BEIGE)	TATA spare parts
3651014392	ACCESS PANEL ASSY. DRIVER	TATA spare parts
3651014392SB	ACCESS PANEL ASSY. DRIVER	TATA spare parts
3651014400	ACCESS PANEL A-DRIVER(RH)	TATA spare parts
3651014400DB	ACCESS PANEL A-DRIVER(RH)(DARK BEIGE)	TATA spare parts
3651014402	ACCESS PANEL ASSY. DRIVER	TATA spare parts
3651014402SB	ACCESS PANEL ASSY. DRIVER	TATA spare parts
3651014410	BINNACLE SWITCH ASSY.	TATA spare parts
3651014410BK	BINNACLE SWITCH ASSY.	TATA spare parts
3652300040	CLIP-LOCK LID GLOVE BOX	TATA spare parts
36523001	PENDANT SWITCH	TATA spare parts
3652300110	CENTER CONSOLE BOX	TATA spare parts
3652300110SB	CENTER CONSOLE BOX	TATA spare parts
3652300290DB	CENTER CONSOLE BOX(DARK BEIGE)	TATA spare parts
3652300300DB	CTR CONSOLE SWITCH A	TATA spare parts
3652310140	CAP-STOWAGE BOX	TATA spare parts
3652310140DB	CAP-STOWAGE BOX(DARK BEIGE)	TATA spare parts
3652310290	STRIKER PLATE-GLOVE BOX	TATA spare parts

3652310291	STRIKER PLATE-GLOVE BOX	TATA spare parts
3652310440	ASHTRAY ASSY. DRIVER	TATA spare parts
3652310440DB	ASHTRAY A-DRIVER(DARK BEIGE)	TATA spare parts
3652310440SB	ASHTRAY ASSY. DRIVER	TATA spare parts
3653100060DB	GLOVE BOX COMPLETE(DARK BEIGE)	TATA spare parts
3653100061	GLOVE BOX COMPLETE	TATA spare parts
3653100061SB	GLOVE BOX COMPLETE	TATA spare parts
3653100062	GLOVE BOX COMPLETE	TATA spare parts
3653100062DB	GLOVE BOX COMPLETE	TATA spare parts
3653500030	LOCK A-GLOVE BOX	TATA spare parts
3655000010	COVER ASM-DASH SIDE LH	TATA spare parts
3655000030	COVER ASM-DASH SIDE RH	TATA spare parts
3655000210	COVER ASSY FUSE BOX	TATA spare parts
3655000270	ARMATURE ASSY DASH PASS	TATA spare parts
3655000310	ARMATURE ASSY DASH CTR C CAB	TATA spare parts
3655000310OB	ARMATURE ASSY DASH CTR C CAB	TATA spare parts
3655000400	TOP CVR ASM-DASH CTR C SOFT	TATA spare parts
3655000540	TOP COVER ASM-DASH SIDE LH	TATA spare parts
3655000570	TOP COVER ASM-DASH SIDE RH	TATA spare parts
3655000600	SHROUD ASM-IP CLUSTER	TATA spare parts
3655000630	CENTER CLUSTER ASM-DASH C CAB	TATA spare parts
3655001750	STORAGE	TATA spare parts
3655001850	UTILITY TRAY ASM DASH CTR	TATA spare parts
3655001980	COVER ASM-DASH CTR UPR C CAB	TATA spare parts
3655002710	SELF TAPPING SCREW GLOVE BOX	TATA spare parts
3655800010	NACELLE TOP	TATA spare parts
3655800020	NACELLE BOTTOM	TATA spare parts
3655800050	COVER SKIRT NACELLE	TATA spare parts
3658544	COVER PROTECTIVE	TATA spare parts
3661000390	FRT BUMPER A-CTR	TATA spare parts
3661000390AW	FRT BUMPER A-CTR	TATA spare parts
3661000620	CTR BRKT A-FRT BUMPER	TATA spare parts
3661000623	CTR BRKT A-FRT BUMPER	TATA spare parts
3661000681	BEZEL-FRT BUMPER	TATA spare parts
3661000691	BEZEL-FRT BUMPER	TATA spare parts
3661000720	PROTECTOR A-FRT BUMPER	TATA spare parts
3661000722	PROTECTOR A-FRT BUMPER	TATA spare parts
3661000780	BRKT A-FRT BUMPER(RH)	TATA spare parts
3661000783	BRKT A-FRT BUMPER	TATA spare parts
3661000810	STOPPER-FRT HOOK	TATA spare parts
3661000920	FRT BUMPER A-SIDE	TATA spare parts
3661000920AW	FRT BUMPER A-SIDE(LH)	TATA spare parts
3661000921	FRT BUMPER A-SIDE	TATA spare parts
3661000921AW	FRT BUMPER A-SIDE	TATA spare parts
3661000980	FRT BUMPER A-SIDE(RH)	TATA spare parts
3661000980AW	FRT BUMPER A-SIDE(RH)	TATA spare parts
3661000981	FRT BUMPER A-SIDE	TATA spare parts

3661000981AW	FRT BUMPER A-SIDE	TATA spare parts
3661008220	BRKT ASSY. HEAD LAMP UPR LH	TATA spare parts
3661008230	BRKT ASSY. HEAD LAMP UPR RH	TATA spare parts
3661008260	BRKT A-HEAD LAMP LWR(LH)	TATA spare parts
3661008261	BRKT ASSY. HEAD LAMP LWR LH	TATA spare parts
3661008270	BRKT A-HEAD LAMP LWR(RH)	TATA spare parts
3661008271	BRKT ASSY. HEAD LAMP LWR RH	TATA spare parts
3661008300	BEZEL-FRT BUMPER(LH)	TATA spare parts
3661008310	BEZEL-FRT BUMPER(RH)	TATA spare parts
3661008403	FRT BUMPER ASSY.	TATA spare parts
3661008403AW	FRT BUMPER ASSY.	TATA spare parts
3661010070	STEP-BUMPER FRT	TATA spare parts
3662100020	ASSY STRUCTURE MIDDLE BUMPER	TATA spare parts
3662100030	FACIA A-BUMPER SIDE LH	TATA spare parts
3662100040	FACIA A-BUMPER SIDE RH	TATA spare parts
3662100150	PANEL A-HEAD LAMP LH	TATA spare parts
3662100160	PANEL A-HEAD LAMP RH	TATA spare parts
3662100240	CROSS MBR A-BUMPER LWR	TATA spare parts
3666112	LITERATURE SERVICEE	TATA spare parts
3666118	LITERATURE TRAINING SER.	TATA spare parts
3666119	LITERATURE SERVICE	TATA spare parts
3666164	LITERATURE SERVICE	TATA spare parts
3672079	CATALOG PARTS	TATA spare parts
3678500081	STAY-MUD FLAP	TATA spare parts
3678500882	MUD FLAP-REAR BODY	TATA spare parts
3678603	SEAL O RING	TATA spare parts
3678912	SEAL O RING	TATA spare parts
3678921	PLUG THREADED	TATA spare parts
3678922	PLUG THREADED	TATA spare parts
3678923	PLUG THREADED	TATA spare parts
3678924	PLUG THREADED	TATA spare parts
3678925	SEAL O RING	TATA spare parts
3679139	SEAL O RING	TATA spare parts
3680997	UNION MALE	TATA spare parts
3681400110	BRACKET-ROLLER	TATA spare parts
3681400250	RETURN SPRING-ROD	TATA spare parts
3681400260	HOOK-SPRING	TATA spare parts
3681400290	BRACKET-SLIDE LEVER	TATA spare parts
3681400300	BRACKET-RETURN SPRING	TATA spare parts
3681400730	TURN BUCKLE	TATA spare parts
3681400810	HOOK PLATE-ROD	TATA spare parts
3681400820	JAW JOINT	TATA spare parts
3681400861	ROD-REAR GATE CONTROL	TATA spare parts
3681401190	JOINT PIN	TATA spare parts
3681401360	ROLLER A	TATA spare parts
3681401370	ROLLER A	TATA spare parts
3681401381	SLIDE LEVER A	TATA spare parts

3681401391	SLIDE LEVER A	TATA spare parts
3681402161	SPRING CASE A	TATA spare parts
36815001	GEAR PUMP	TATA spare parts
3684000090	DUMP SHOCK ABSORBER	TATA spare parts
3684000100	DUMP SHOCK ABSORBER RR	TATA spare parts
3684000180	DUMP SHOCK ABSORBER FRT	TATA spare parts
3684100410	DRIVE SHAFT A	TATA spare parts
3684300033	FLANGE A-HIGH	TATA spare parts
3684300060	HOSE SUB A-HIGH PRESSURE	TATA spare parts
3684300070	HOSE SUB A-LOW PRESSURE	TATA spare parts
3684300303	PIPE SUB A-LOWER	TATA spare parts
3684300480	FLANGE ASM-LOW	TATA spare parts
3684300510	HOSE	TATA spare parts
3684300541	PIPE SUB A	TATA spare parts
3684300560	RESERVOIR A	TATA spare parts
3684300590	BAND	TATA spare parts
3684400210	BRACKET-TRUNNION	TATA spare parts
3684400220	BRACKET-TRUNNION	TATA spare parts
3684400230	BRACKET-BODY	TATA spare parts
3684400240	BRACKET-BODY	TATA spare parts
3684400250	BUSH-TRUNNION	TATA spare parts
3684400260	BUSH-BODY	TATA spare parts
3684400280	PIN-TENSION LINK	TATA spare parts
3684800221	CLAMP-PIPE LOW PRESSURE	TATA spare parts
3686500540	BRKT-HP HOSE	TATA spare parts
3686800071	SET BRACKET A-NO.1	TATA spare parts
3686800111	SET BRACKET A-NO.2	TATA spare parts
3686800140	U BOLT A	TATA spare parts
3686800240	U BLOCK-SUB FRAME	TATA spare parts
3686800250	U BLOCK-CHASSIS FRAME	TATA spare parts
3686800360	PLATE- U BOLT	TATA spare parts
3686800371	CUSHION RUBBER-DUMP	TATA spare parts
3686800380	STOPPER A	TATA spare parts
3686800390	STOPPER A	TATA spare parts
3687000041	DUMP CONTROL LEVER A	TATA spare parts
3687100640	JAW JOINT	TATA spare parts
3687300460	WIRE CONTROL CABLE A W/GROMMET	TATA spare parts
3687500190	BRACKET A-GEAR PUMP	TATA spare parts
3688000100	WINCH A-SPARE TIRE	TATA spare parts
3688000190	HANDLE-SPARE TIRE	TATA spare parts
3688000610	HANDLE A	TATA spare parts
3688000661	ARM A-SPARE TIRE	TATA spare parts
3688000720	GUIDE PLATE	TATA spare parts
3688000740	WIRE ROPE A	TATA spare parts
3688001410	HOLDER A	TATA spare parts
3688001420	SUB HOLDER	TATA spare parts
3688100230	HINGE A-UPR	TATA spare parts

3688100240	HINGE A-UPR	TATA spare parts
3688201592	STAY A-RR COMBI LAMP	TATA spare parts
3688201602	STAY A-RR COMBI LAMP	TATA spare parts
3688300771	PROTECTOR-SIDE	TATA spare parts
3688300782	PROTECTOR-SIDE	TATA spare parts
3688300790	STAY ASM-PROTECTOR	TATA spare parts
3688300800	STAY ASM-PROTECTOR	TATA spare parts
3688300860	STAY-PROTECTOR FRT	TATA spare parts
3688300970	STAY-PROTECTOR FRT	TATA spare parts
3688301100	PROTECTOR-SIDE	TATA spare parts
3688301110	PROTECTOR-SIDE	TATA spare parts
3698701	LITERATURE SALES	TATA spare parts
37003700098	FEELER GAUGE 0.02-1.00MM 4602-17 INSIZE	TATA spare parts
3712501441	DECAL-FRT LID	TATA spare parts
3712501451	DECAL-FRT LID	TATA spare parts
3712501461	DECAL-RADIATOR GRILLE	TATA spare parts
3712501471	DECAL-RADIATOR GRILLE	TATA spare parts
3712502200	DECAL-QTR UPR(LH)	TATA spare parts
3712502210	DECAL-QTR UPR(RH)	TATA spare parts
3712502220	DECAL-QTR LWR(LH)	TATA spare parts
3712502230	DECAL-QTR LWR(RH)	TATA spare parts
3712502240	DECAL-DOOR UPR(LH)	TATA spare parts
3712502250	DECAL-DOOR UPR(RH)	TATA spare parts
3712502260	DECAL-DOOR LWR(LH)	TATA spare parts
3712502270	DECAL-DOOR LWR(RH)	TATA spare parts
3712502280	DECAL-OK GLASS(LH)	TATA spare parts
3712502290	DECAL-OK GLASS(RH)	TATA spare parts
3712502410	LETTERING-NOVUS	TATA spare parts
3712502490	EMBLEM-TATA	TATA spare parts
3712502500	PLATE-EMBLEM TATA	TATA spare parts
3712502530	LETTERING-LOGO TATA	TATA spare parts
3712502540	LETTERING-MODEL CODE	TATA spare parts
3712502800	LETTERING-2530	TATA spare parts
3712502870	LETTERING-LOGO TATA	TATA spare parts
3714100040	BRACKET A-FENDER (LH)	TATA spare parts
3714100047	BRACKET A-FENDER	TATA spare parts
3714100050	BRACKET A-FENDER (RH)	TATA spare parts
3714100057	BRACKET A-FENDER	TATA spare parts
3714100160	BASE PLATE-1ST STEP NO.6	TATA spare parts
3714100210	BASE PLATE A-1ST STEP	TATA spare parts
3714100211	BASE PLATE A-1ST STEP	TATA spare parts
3714100220	BASE PLATE-1ST STEP NO.6	TATA spare parts
3714100230	BRACKET A-BASE PLATE (LH)	TATA spare parts
3714100231	BRACKET A-BASE PLATE	TATA spare parts
3714100240	BRACKET A-BASE PLATE` (RH)	TATA spare parts
3714100241	BRACKET A-BASE PLATE	TATA spare parts
3714100340	BASE PLATE A-1ST STEP	TATA spare parts

3714100341	BASE PLATE A-1ST STEP	TATA spare parts
3714100440	STEP PLATE-CAB 1ST	TATA spare parts
3714100450	STEP PLATE-CAB 1ST (RH)	TATA spare parts
3714100460	STEP PLATE-CAB 2ND (LH)	TATA spare parts
3714100470	STEP PLATE-CAB 2ND (RH)	TATA spare parts
3714100610	ADD ON STEP A LH	TATA spare parts
3714100620	ADD ON STEP A RH	TATA spare parts
3714110014	STEP PLATE-CAB 1ST	TATA spare parts
3714110025	STEP PLATE-CAB 2ND	TATA spare parts
3714110050	STEP PLATE-QTR PANEL	TATA spare parts
3714110054	STEP PLATE A-QTR PANEL	TATA spare parts
3714110060	STEP PLATE-QTR PANEL	TATA spare parts
3714110064	STEP PLATE A-QTR PANEL	TATA spare parts
3714110230	STEP PLATE-CAB 1ST	TATA spare parts
3714110240	STEP PLATE-CAB 2ND	TATA spare parts
3714500050	ASSIST HANDLE A-SIDE	TATA spare parts
3714500055	ASSIST HANDLE A-SIDE	TATA spare parts
3714500300	COVER-ASSIST HANDLE SIDE	TATA spare parts
3714500320	GASKET-ASSIST HANDLE SIDE	TATA spare parts
3714500324	GASKET-ASSIST HANDLE SIDE	TATA spare parts
3714510030	ASSIST HANDLE-FRT LID	TATA spare parts
3714510031	ASSIST HANDLE-FRT LID	TATA spare parts
3714510035	ASSIST HANDLE-FRT LID	TATA spare parts
3714510090	HINGE PIN-ASSIST HANDLE FRT	TATA spare parts
3714510091	HINGE PIN-ASSIST HANDLE FRT	TATA spare parts
3714510100	HINGE COVER-ASSIST HANDLE FRT LID	TATA spare parts
3714510101	HINGE COVER-ASSIST HANDLE FRT LID	TATA spare parts
3714510180	CAP-HANDLE ASSIST FRT LID	TATA spare parts
3715110010	MUD GUARD-FRT (LH)	TATA spare parts
3715110013	MUD GUARD-FRT	TATA spare parts
3715110020	MUD GUARD-FRT (RH)	TATA spare parts
3715110025	MUD GUARD-FRT	TATA spare parts
3715110040	BRKT A-FRT MUDGUARD	TATA spare parts
3715110050	MUD FLAP-FRT MUD GUARD	TATA spare parts
3715110054	MUD FLAP-FRT MUD GUARD	TATA spare parts
3715110100	BRACKET A-FRT MUD GUARD END	TATA spare parts
3715110102	BRACKET A-FRT MUD GUARD END	TATA spare parts
3721100490	TRIM-RR QUARTER PANEL(LH)	TATA spare parts
3721100490SB	TRIM-RR QUARTER PANEL	TATA spare parts
3721100500	TRIM-RR QUARTER PANEL(RH)	TATA spare parts
3721100500SB	TRIM-RR QUARTER PANEL	TATA spare parts
3721410010	TRIM-'A' PILLAR A(LH)	TATA spare parts
3721410010SB	TRIM-'A' PILLAR A(LH)(INT COLOR-BEIGE)(S	TATA spare parts
3721410012SB	TRIM- A PILLAR ASSY.	TATA spare parts
3721410020	TRIM-'A' PILLAR A(RH)	TATA spare parts
3721410020SB	TRIM-'A' PILLAR A(RH)(INT COLOR-BEIGE)(S	TATA spare parts
3721410022SB	TRIM- A PILLAR ASSY.	TATA spare parts



3721410030	TRIM-SIDE RAIL A(LH)	TATA spare parts
3721410030SB	TRIM-SIDE RAIL A(LH)(INT COLOR-BEIGE)(SO	TATA spare parts
3721410031SB	TRIM-SIDE RAIL ASSY.	TATA spare parts
3721410040	TRIM-SIDE RAIL A(RH)	TATA spare parts
3721410040SB	TRIM-SIDE RAIL A(RH)(INT COLOR-BEIGE)(SO	TATA spare parts
3721410041SB	TRIM-SIDE RAIL ASSY.	TATA spare parts
3721600050	PU FOAM-RR VENT	TATA spare parts
3721610020	TRIM-BACK PANEL LWR	TATA spare parts
3721610020SB	TRIM-BACK PANEL LWR(INT COLOR-BEIGE)(S	TATA spare parts
3721610027SB	TRIM-BACK PANEL LOWER	TATA spare parts
3721610030	TRIM-BACK PANEL UPR	TATA spare parts
3721610030SB	TRIM-BACK PANEL UPR(INT COLOR-BEIGE)(S	TATA spare parts
3721610031SB	TRIM-BACK PANEL UPPER	TATA spare parts
3721610080	VENT A-REAR	TATA spare parts
3721610082	VENT A-REAR	TATA spare parts
3721610100	GASKET-BAFFLE VENT RR	TATA spare parts
3721610101	GASKET-BAFFLE VENT RR	TATA spare parts
3722100030LB	HEADLINING A(LIGHT BEIGE)	TATA spare parts
3722110036LB	HEADLINING ASSY.	TATA spare parts
3722400170	SPEAKER GRILLE A-FRT	TATA spare parts
3722400170LB	SPEAKER GRILLE A-FRT(LIGHT BEIGE)	TATA spare parts
3722400171	SPEAKER GRILLE ASSY. FRT LH	TATA spare parts
3722400171LB	SPEAKER GRILLE ASSY. FRT RH	TATA spare parts
3722400380	DOOR ASSY. OVERHEAD STOWAGE	TATA spare parts
3722400380LB	DOOR ASSY. OVERHEAD STOWAGE	TATA spare parts
3722400401	HINGE A-OVERHEAD STWG DOOR	TATA spare parts
3722400451	OVERHEAD STOWAGE ASSY.	TATA spare parts
3722400451LB	OVERHEAD STOWAGE ASSY.	TATA spare parts
3722400540LB	OVERHEAD STOWAGE A(LIGHT BEIGE)	TATA spare parts
3722410160	STORAGE BOX-OVERHEAD STWG SIDE	TATA spare parts
3722410160SB	STORAGE BOX-OVERHEAD STWG SIDE(INT COLOR	TATA spare parts
3722410163	STORAGE BOX-OVERHEAD STWG SIDE	TATA spare parts
3722410163SB	STORAGE BOX-OVERHEAD STWG SIDE	TATA spare parts
3722410204	LATCH-OVERHEAD STOWAGE DOOR	TATA spare parts
3722410204LB	LATCH-OVERHEAD STOWAGE DOOR	TATA spare parts
3722410383	DOOR ASSY. OVERHEAD STOWAGE	TATA spare parts
3722410383LB	DOOR ASSY. OVERHEAD STOWAGE	TATA spare parts
3723100010	CURTAIN RAIL-FRONT	TATA spare parts
3723100020	CURTAIN RAIL-FRONT	TATA spare parts
3723110010	CURTAIN RAIL A-CENTER	TATA spare parts
3723110015	CURTAIN RAIL A-CENTER	TATA spare parts
3723110020	CURTAIN RAIL A-REAR(LH)	TATA spare parts
3723110026	CURTAIN RAIL A-REAR	TATA spare parts
3723110100	GUIDE-CURTAIN RAIL	TATA spare parts
3723110102	GUIDE-CURTAIN RAIL	TATA spare parts
3723110140	CURTAIN RAIL-REAR(RH)	TATA spare parts
3723110145	CURTAIN RAIL-REAR	TATA spare parts

3723110150	END CURTAIN RAIL	TATA spare parts
3723110160	HOLDER-CURTAIN	TATA spare parts
3723310030	SUNVISOR(LH)	TATA spare parts
3723310030LB	SUNVISOR(LH)(LIGHT BEIGE)	TATA spare parts
3723310035	SUNVISOR	TATA spare parts
3723310035LB	SUNVISOR LH	TATA spare parts
3723310040	SUNVISOR(RH)	TATA spare parts
3723310040LB	SUNVISOR(RH)(LIGHT BEIGE)	TATA spare parts
3723310044	SUNVISOR	TATA spare parts
3723310044LB	SUNVISOR RH	TATA spare parts
3723500080	DOOR ASSIST GRIP A-ENTRY	TATA spare parts
3723500080DB	DOOR ASSIST GRIP A-ENTRY	TATA spare parts
3723500090	DOOR ASSIST GRIP MOULDING	TATA spare parts
3723500090DB	DOOR ASSIST GRIP MOULDING(DARK BEIGE)	TATA spare parts
3723500110	CAP-DOOR ASSIST GRIP	TATA spare parts
3723500110DB	CAP-DOOR ASSIST GRIP(DARK BEIGE)	TATA spare parts
3723500112	CAP-DOOR ASSIST GRIP	TATA spare parts
3723500112DB	CAP-DOOR ASSIST GRIP	TATA spare parts
3723500120	ASSIST HANDLE-ENTRY	TATA spare parts
3723500120DB	ASSIST HANDLE-ENTRY	TATA spare parts
3723510100SB	GRILLE-DOOR AIR VENT FRT LWR(INT COLOR	TATA spare parts
3723510103	GRILLE-DOOR AIR VENT FRT LOWER	TATA spare parts
3723510103SB	GRILLE-DOOR AIR VENT FRT LOWER	TATA spare parts
3724100200	KICKING PLATE(LH)	TATA spare parts
3724100200DB	KICKING PLATE(LH)(DARK BEIGE)	TATA spare parts
3724100204SB	KICKING PLATE	TATA spare parts
3724100210	KICKING PLATE(RH)	TATA spare parts
3724100210DB	KICKING PLATE(RH)(DARK BEIGE)	TATA spare parts
3724100214SB	KICKING PLATE	TATA spare parts
3724100220	TRIM-'A' PILLAR LWR(LH)	TATA spare parts
3724100220DB	TRIM-'A' PILLAR LWR(LH)(DARK BEIGE)	TATA spare parts
3724100224DB	TRIM- A PILLAR LOWER	TATA spare parts
3724100230	TRIM-'A' PILLAR LWR(RH)	TATA spare parts
3724100230DB	TRIM-'A' PILLAR LWR(RH)(DARK BEIGE)	TATA spare parts
3724100234DB	TRIM- A PILLAR LOWER	TATA spare parts
3724100890	CARPET-FLOOR LWR	TATA spare parts
3724101090	CARPET-FLOOR UPR(RH)	TATA spare parts
3724101091	CARPET-FLOOR UPR	TATA spare parts
3724101120	CARPET-FLOOR	TATA spare parts
3724101230	CARPET-CENTER	TATA spare parts
3724101231	CARPET-CENTER	TATA spare parts
3724110070	SCREW-SELF TAPPING	TATA spare parts
3724110073	SCREW-SELF TAPPING	TATA spare parts
3724400020	FOOT REST	TATA spare parts
3724400110	SPACER-ENGINE HOOD	TATA spare parts
3730003330	SEAT ASSY. ASSIST	TATA spare parts
3730003430	SEAT COMPLETE-DRIVER	TATA spare parts

3730003450	SEAT ASSY. DRIVER	TATA spare parts
3730003510	SEAT COMPLETE-ASSIST	TATA spare parts
3730003970	SEAT COMPLETE-ASSIST	TATA spare parts
3730004090	SEAT COMPLETE-DRIVER	TATA spare parts
3730004170	SEAT A-DRIVER	TATA spare parts
3730004210	SEAT A-ASSIST	TATA spare parts
3730004520	SEAT COMPLETE-ASSIST	TATA spare parts
3730004530	SEAT A-ASSIST	TATA spare parts
3730004540	SEAT COMPLETE-DRIVER	TATA spare parts
3730004550	SEAT A-DRIVER	TATA spare parts
3731000870	SEAT CUSHION ASSY. ASSIST	TATA spare parts
3731000920	SEAT CUSHION ASSY. DRIVER	TATA spare parts
3731001090	SEAT CUSHION A-DRIVER	TATA spare parts
3731001200	SEAT CUSHION A-ASSIST	TATA spare parts
3733000900	SEAT BACK ASSY. ASSIST	TATA spare parts
3733000940	SEAT BACK ASSY. DRIVER	TATA spare parts
3733001200	SEAT BACK A-DRIVER	TATA spare parts
3733001310	SEAT BACK A-ASSIST	TATA spare parts
3735000040	GUIDE-HEAD REST	TATA spare parts
3735000040DB	GUIDE-HEAD REST	TATA spare parts
3735000040SB	GUIDE-HEAD REST	TATA spare parts
3735000520	SUPPORT ASSY. DRIVER	TATA spare parts
3735000520BK	SUPPORT ASSY. DRIVER	TATA spare parts
3735000600	SUPPORT ASSY. ASSIST SEAT	TATA spare parts
3735000600BK	SUPPORT ASSY. ASSIST SEAT	TATA spare parts
3735000710	SUPPORT A-ASSIST SEAT	TATA spare parts
3735000710BK	SUPPORT A-ASSIST SEAT(BLACK)	TATA spare parts
3738000370	HEADREST ASSY.	TATA spare parts
3738000420	HEADREST A	TATA spare parts
3738600020	BOARD-SLEEP BED	TATA spare parts
3738600025	BOARD-SLEEP BED	TATA spare parts
3738600180	PAD-BOARD	TATA spare parts
3738600660	BED ASSY.	TATA spare parts
3738600660PC	BED ASSY.	TATA spare parts
3741000130	COVER-MECHANISM	TATA spare parts
3741000130BK	COVER-MECHANISM	TATA spare parts
3741100040	RECLINING DEVICE	TATA spare parts
3741100060	BUSH-HINGE	TATA spare parts
3741100140	RECLINING DEVICE	TATA spare parts
3741100180	COVER-RECLINER SEAT	TATA spare parts
3741100180DB	COVER-RECLINER SEAT(DARK BEIGE)	TATA spare parts
3741100180SB	COVER-RECLINER SEAT	TATA spare parts
3741400010	SLIDER-DRIVER	TATA spare parts
3741400050	SLIDER-DRIVER	TATA spare parts
3742100070	HEIGHT ADJUSTER ASSY.	TATA spare parts
3745200040	TONGUE A	TATA spare parts
3745200060	TONGUE A-DRIVER	TATA spare parts

3745400010	HEIGHT ADJUSTER	TATA spare parts
3745600060	BUCKLE A-DRIVER	TATA spare parts
3745600062	BUCKLE A-DRIVER	TATA spare parts
3746000070	BUCKLE A-ASSIST	TATA spare parts
3746000074	BUCKLE A-ASSIST	TATA spare parts
375000900009	FRONT STRUCTURE ASSY	TATA spare parts
375000900010	REAR STRUCTURE ASSY	TATA spare parts
375000900120	UPPER STOP ASM	TATA spare parts
375000900121	LOWER STOP ASM	TATA spare parts
375000900123	DOOR LOCK HUMIN	TATA spare parts
375000900127	CHECK RING	TATA spare parts
375000900128	LOCKNUT CONNECTOR-AIR TANK	TATA spare parts
375000900129	DASHBOARD SWITCH-RED	TATA spare parts
375000900131	GUIDE ASM-HUMIN	TATA spare parts
375000900132	LOWER SUPPORT ASM	TATA spare parts
375000900136	DASHBOARD SWITCH-GREEN	TATA spare parts
375000900363	DRIVER DOOR ASSY	TATA spare parts
375000913001	PARTITION BELT FOR DISABLED	TATA spare parts
375001002001	FRONT STRUCTURE COMPLETE	TATA spare parts
375001002002	REAR STRUCTURE COMPLETE	TATA spare parts
375001003001	WINDSHIELD LOWER ROOF STICK ASSY	TATA spare parts
375001003002	A' PILLAR - LH	TATA spare parts
375001003003	A' PILLAR - RH	TATA spare parts
375001013001	FRONT COLUMN	TATA spare parts
375001013002	FRONT COLUMN	TATA spare parts
375001013003	FRONT UPPER COLUMN	TATA spare parts
375001013004	WINDSHIELD UPPER ROOF STICK	TATA spare parts
375001083001	JOINT GUSSET UPPER FRONT	TATA spare parts
375001083002	JOINT GUSSET UPPER FRONT	TATA spare parts
375001085003	WINDSHIELD WIPER BEARING SUPPORT	TATA spare parts
375001091015	TOP SHAFT BRACKET	TATA spare parts
375001091016	BOTTOM SHAFT BRACKET	TATA spare parts
375001091017	FLOATING JOINT WITH BOLT AND NUT	TATA spare parts
375001170001	MARKER LAMP INTERNAL UPPER COVERING(ABS)	TATA spare parts
375001170002	MARKER LAMP MAINTENANCE COVER (ABS)	TATA spare parts
375001170003	MARKER LAMP FRONT MARKER	TATA spare parts
375001170004	COVER FOR SWITCH HOLE	TATA spare parts
375002002002	REAR STRUCTURE ASSEMBLY	TATA spare parts
375002003002	REAR WINDOW LOWER ROOFSTICK	TATA spare parts
375002003003	ENGINE SHUTTER SIDE ROOFSTICK	TATA spare parts
375002003004	ENGINE SHUTTER SIDE ROOFSTICK	TATA spare parts
375002013001	REAR WINDOW UPPER ROOFSTICK	TATA spare parts
375002013002	REAR SIDE PILLAR	TATA spare parts
375002013003	REAR SIDE PILLAR	TATA spare parts
375002013004	REAR WINDOW SIDE PILLAR	TATA spare parts
375002013005	REAR WINDOW SIDE PILLAR	TATA spare parts
375002013006	REAR SEMI ROOFSTICK	TATA spare parts

375002013007	REAR SEMI ROOFSTICK	TATA spare parts
375002013009	REAR SEMI ROOFSTICK	TATA spare parts
375002013010	REAR SEMI ROOFSTICK	TATA spare parts
375002083001	ROOF REVITMENT ATTACHING PLATE	TATA spare parts
375002084004	HINGED DOORS PISTON COUPLING PLATE	TATA spare parts
375005083039	SMALL_HARNESS_TRAY_1422	TATA spare parts
375005083063	HARNESS TRAY_1460	TATA spare parts
375005083064	HARNESS TRAY_1273MM	TATA spare parts
375005083066	SMALL HARNESS TRAY_680	TATA spare parts
375005083067	SMALL HARNESS TRAY_1427	TATA spare parts
375005083071	HARNESS TRAY_1171	TATA spare parts
375005083072	SMALL HARNESS TRAY_680	TATA spare parts
375005083073	HARNESS TRAY_1460	TATA spare parts
375007084160	CABEL CUP SUPPORT L ANGLE ROOF_4X12	TATA spare parts
375007084161	CABLE CUP SUPPORT PLATE ROOF_4X12	TATA spare parts
375008003002	GAS-CNG CYLINDER SUPPORT COLUMN ASSEMBL	TATA spare parts
375010231001	FRONT WINDSHIELD W/O IR CUT -GEN 5 WP	TATA spare parts
375010900001	PLATE ASM	TATA spare parts
375010900004	SENSOR	TATA spare parts
375010900007	SOLENOID VALVE	TATA spare parts
375010900008	VALVE BODY	TATA spare parts
375010900010	CUSHION VALVE	TATA spare parts
375010900011	AIR FILTER SUB-HUMIN	TATA spare parts
375010900012	CRANK SUB	TATA spare parts
375010900013	SPLINED SHAFT SUB	TATA spare parts
375010900014	AIR CYLIDER	TATA spare parts
375010900015	SEALER	TATA spare parts
375010900016	ROD END BEARING	TATA spare parts
375010900017	MAGNETOR SENSOR	TATA spare parts
375010900018	MICRO COMPUTER CONTROLLER	TATA spare parts
375010900020	WIRING HARNESS	TATA spare parts
375010900021	AIR PRESSURE SWITCH	TATA spare parts
375010900048	RESET SWITCH	TATA spare parts
375010900050	INTERNAL PNEUMATIC EMERGENCY SWITCH	TATA spare parts
375010900052	U TYPE CONNECTOR	TATA spare parts
375010901001	PULLEY COMPRESSOR	TATA spare parts
375010901002	RAW EDGE BANDED ALTERNATOR BELT	TATA spare parts
375010901003	RAW EDGE BANDED COMPRESSOR BELT	TATA spare parts
375010901008	RED ILL.PUSH BUTTON24 V DC	TATA spare parts
375010901009	ELEMENT NO CONTACT	TATA spare parts
375010901010	JOCKEY PULLEY ASSY RH SIDE	TATA spare parts
375010901011	JOCKEY PULLEY WITH BEARING	TATA spare parts
375010901012	ADJUSTER BOLT M16	TATA spare parts
375010901013	PULLEY HOLDER RH SIDE	TATA spare parts
375010901014	JOCKEY PULLEY SHAFT	TATA spare parts
375010901015	TOP SHAFT BRACKET	TATA spare parts
375010901016	BOTTOM SHAFT BRACKET	TATA spare parts

375010901017	FLOATING JOINT WITH BOLT&NUT	TATA spare parts
375010901018	PCB MASTER (PC225C)	TATA spare parts
375010901019	PCB SLAVE (PC225B)	TATA spare parts
375010901020	CASE & COVER	TATA spare parts
375010901021	LEMS WINDOW IP65/GLASS	TATA spare parts
375010901022	PCB MASTER (PC224C)	TATA spare parts
375010901023	PCB SLAVE (PC224B)	TATA spare parts
375010901024	CASE & COVER	TATA spare parts
375010901025	LEMS WINDOW IP65/GLASS	TATA spare parts
375010901026	PCB MASTER (PC161B)	TATA spare parts
375010901027	PCB POWER CARD (PC162B)	TATA spare parts
375010901028	PCB SLAVE MODULE (PC226)	TATA spare parts
375010901029	14W-70MM MOLEX CABLE	TATA spare parts
375010901030	14W-280MM MOLEX CABLE	TATA spare parts
375010901031	CASE & COVER	TATA spare parts
375010901032	¿LEMS WINDOW IP65/GLASS	TATA spare parts
375010901033	114 16 INTERIOR LED WINDOW	TATA spare parts
375010901034	¿ERIC FRONT PANEL	TATA spare parts
375010901035	¿ERIC MASTER CARD	TATA spare parts
375010901036	ERIC POWER CARD	TATA spare parts
375010901037	ERIC BACK PANEL	TATA spare parts
375010901038	ERIC TWO PIN CONNECTOR	TATA spare parts
375010901039	ERIC THREE PIN CONNECTOR	TATA spare parts
375010901040	ERIC CONNECTOR LUGS	TATA spare parts
375010901041	DERIC FRONT PANEL	TATA spare parts
375010901042	DERIC MASTER CARD	TATA spare parts
375010901043	HANVOX MOTHER BOARD	TATA spare parts
375010901044	MP3 PLAYER CARD	TATA spare parts
375010901045	HANVOX VOICE REGULATOR	TATA spare parts
375010901046	MAX 232 MODULE PCB	TATA spare parts
375010901047	¿FRONT SIGN INTERNAL WIRING HARNESS	TATA spare parts
375010901048	SIDE/REAR SIGN INT WIRING HARNESS	TATA spare parts
375010901049	INTERNAL SIGN INT WIRING HARNESS	TATA spare parts
375010901050	POWER CABLE 6.3 MM CONNECTOR	TATA spare parts
375010901051	POWER CABLE 2.8 MM CONNECTOR	TATA spare parts
375010901052	DATE CABLE ERIC/DERIC TO FRONT SIGN	TATA spare parts
375010901053	DATA CABLE 5 MTR (FRNT TO INTERNAL SIGN)	TATA spare parts
375010901054	DATA CABLE 10 MTR (INT TO SIDE SIGN)	TATA spare parts
375010901055	DATA CABLE 13 MTR (SIDE TO REAR SIGN)	TATA spare parts
375010901056	ERIC TO HANVOX - WHITE CABLE	TATA spare parts
375010901057	GPS INTERCONNECT DB 25 CABLE	TATA spare parts
375010901058	GPS MALE /FEMALE MOLEX CABLE	TATA spare parts
375010901059	POWER TO SIGN WIRING HARNESS (4NOS)	TATA spare parts
375010901060	POWER TO ERIC CABLE	TATA spare parts
375010901061	DRIVER CONTROLLER ERIC	TATA spare parts
375010901062	DRIVER CONTROLLER ERIC	TATA spare parts
375010901063	GPS ANTENNA	TATA spare parts

375010901064	VOICE ANNOUNCEMENT	TATA spare parts
375010901065	GPS ANTENNA & RECEIVER	TATA spare parts
375010901066	DRIVER CONTROLLER DERIC	TATA spare parts
375010901067	DRIVER CONTROLLER	TATA spare parts
375010901068	SPEAKER	TATA spare parts
375010901069	SPACER HMM007 FOR HATCH	TATA spare parts
375010901070	BOVA 2M3 WIRE	TATA spare parts
375010901071	EMERGENCY AXEL	TATA spare parts
375010901072	DOVE ABS FR	TATA spare parts
375010901073	INNER PROJECTED SHEET ABS FR	TATA spare parts
375010901074	OUTER FRAME PU FR	TATA spare parts
375010901075	INNER FRAME ABS FR	TATA spare parts
375010901076	EMERGENCY HANDLE COVER	TATA spare parts
375010901077	OUTER EMERGENCY HANDLE	TATA spare parts
375010901078	MECHANISM HMM BKT PLASTIC	TATA spare parts
375010901079	HOUSING	TATA spare parts
375010901080	LID	TATA spare parts
375010901081	MICROSWITCH LEVER	TATA spare parts
375010901082	INNER EMERGENCY HANDLE	TATA spare parts
375010901083	STEEL BRACKET	TATA spare parts
375010901084	BOVA HATCH AXEL	TATA spare parts
375010901085	HMM MECHANISM COMPLETE	TATA spare parts
375010901086	RUBBER PROFILE BOVE(HATCH)	TATA spare parts
375010901087	SAFETY BELT (STRAP)	TATA spare parts
375010901088	EMERGENCY STICKER	TATA spare parts
375010901089	AC CAPACITOR RELAY 24V	TATA spare parts
375010901103	PVC SLEEVE 6 MTRS	TATA spare parts
375010901106	COMPRESSOR MODEL	TATA spare parts
375010901107	SHAFT SEAL	TATA spare parts
375010901108	BELT XPB 1675 (BX -64)	TATA spare parts
375010901109	WIRE HARNESS	TATA spare parts
375010901110	SUCTION PIPE-I	TATA spare parts
375010901111	PRESSURE PIPE	TATA spare parts
375010901112	SUCTION PIPE-II	TATA spare parts
375010901113	CONDENSER -RECEIVER PIPE 5/8INCH	TATA spare parts
375010901114	EVAPORATOR TUBE LEFT	TATA spare parts
375010901115	EVAPORATOR TUBE RIGHT	TATA spare parts
375010901116	FLUID PIPE ASSEMBLY	TATA spare parts
375010901117	SUCTION HOSE ASSY	TATA spare parts
375010901118	DISCHARGE HOSE ASSY COMP.END	TATA spare parts
375012003001	WHEELHOUSING ASSEMBLY	TATA spare parts
375012003002	WHEELHOUSING ASSEMBLY	TATA spare parts
375012083001	WHEEL FLAP 201	TATA spare parts
375012083002	WHEEL FLAPS 203	TATA spare parts
375012083003	WHEEL FLAP	TATA spare parts
375012083004	WHEEL FLAP	TATA spare parts
375012083005	WHEEL HOUSE CLOSING COVER	TATA spare parts

375012083006	WHEEL HOUSE CLOSING COVER	TATA spare parts
375012083007	WHEEL HOUSE CLOSING COVER (RH)	TATA spare parts
375012083008	WHEEL HOUSE CLOSING COVER	TATA spare parts
375012083009	WHEEL HOUSE CLOSING COVER	TATA spare parts
375012083010	WHEEL HOUSE CLOSING COVER	TATA spare parts
375012083011	WHEEL HOUSE CLOSING COVER	TATA spare parts
375012083012	WHEEL HOUSE CLOSING COVER	TATA spare parts
375012083013	WHEEL HOUSE CLOSING COVER	TATA spare parts
375012083014	WHEEL HOUSE CLOSING COVER	TATA spare parts
375012283001	RUBBER FLAPS	TATA spare parts
375012912004	FRONT MUD FLAP (RUBBER) ASSY	TATA spare parts
375012912005	REAR MUD FLAP (RUBBER) ASSY	TATA spare parts
375012913001	WHEEL FLAPS ASSY 4X12 EV	TATA spare parts
375013002003	BATTERY BOX & TROLLEY COMPARTMENT	TATA spare parts
375013003002	BATTERY BOX COMPARTMENT RAIL ASSY	TATA spare parts
375013003005	BATTERY BOX BASE ASSEMBLY	TATA spare parts
375013003006	BATTERY BOX PLATE ASSEMBLY	TATA spare parts
375013003007	BATTERY BOX COMPARTMENT RAIL ASSY	TATA spare parts
375013084021	PANEL	TATA spare parts
375014004002	RADIATOR PROTECTOR FLAP ASSY.	TATA spare parts
375014073001	COMMAND CLOSING COVER COUPLER	TATA spare parts
375014083001	RADIATOR & BATTERY BOX PARTITION PLATE	TATA spare parts
375014084004	FRONT COVER SHEET	TATA spare parts
375014084005	INSIDE UPPER COVER SHEET	TATA spare parts
375014084006	INSIDE LOWER COVER SHEET	TATA spare parts
375014084008	RADIATOR & BATTERY BOX PARTITION PLATE	TATA spare parts
375014084009	CLOSING PLATE	TATA spare parts
375014085001	BASE PLATE	TATA spare parts
375014085002	L-PROFILE SUPPORT	TATA spare parts
375014284001	BLACK RUBBER	TATA spare parts
375015003001	HINGED DOOR ASSY.	TATA spare parts
375015003002	HINGE KIT	TATA spare parts
375015003005	DOOR STOPPER	TATA spare parts
375015004005	DRIVER DOOR EXT PANEL & HINGE ASSY	TATA spare parts
375015073001	LOCK OPERATING PIN	TATA spare parts
375015073002	MS ROD DIA 4X265LN	TATA spare parts
375015073003	SECURITY TOP STAFF	TATA spare parts
375015083001	DOOR SEALING SUPPORT	TATA spare parts
375015083002	DOOR SEALING SUPPORT	TATA spare parts
375015083003	DOOR SEALING SUPPORT	TATA spare parts
375015083005	EMERGENCY DOOR LOCKING GUIDE	TATA spare parts
375015083006	EMERGENCY DOOR LOCKING ARM	TATA spare parts
375015083007	LATCH ATTACHMENT SUPPORT	TATA spare parts
375015083008	LH DOOR OPERATED ROD LOOP	TATA spare parts
375015084001	FEMALE CATCHER PLATE	TATA spare parts
375015183001	RH CENTRAL DOOR LOWER FINISHING	TATA spare parts
375015183002	DRIVER DOOR LOWER FINISHING-DRIVER DOOR	TATA spare parts



375015303001	DOOR LIGHT COVERING 203	TATA spare parts
375015303002	DRIVER COLUMN FINISHING 205	TATA spare parts
375015303003	DRIVER COLUMN FINISHING 206	TATA spare parts
375015303004	DOOR BOLT COVERING	TATA spare parts
375015303005	EMERGENCY ARM COVERING	TATA spare parts
375015303006	DRIVER DOOR HANDLE	TATA spare parts
375015303007	EXTERNAL HANDLE	TATA spare parts
375015303008	EXTERNAL HANDLE LOCKING ROD	TATA spare parts
375015303009	DOOR FACING	TATA spare parts
375015303010	DRIVER DOOR INTERNAL FINSHING	TATA spare parts
375015303011	DRIVER DOOR LATCH COVERING 211	TATA spare parts
375015304001	MALE CATCHER	TATA spare parts
375015304002	FEMALE CATCHER	TATA spare parts
375015323001	CATCHER COVER	TATA spare parts
375015912003	DOORS FINISHING	TATA spare parts
375015912004	DRIVER DOOR ASSY	TATA spare parts
375016002001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
375016003002	EMERGENCY HINGED DOOR ASSY.	TATA spare parts
375016003005	DOOR LATCH ATTACHMENT SUPPORT ASSY	TATA spare parts
375016003006	LOCK SUPPORT ASSEMBLY	TATA spare parts
375016004003	LOCK ARM ATTACHMENT BASE ASSY	TATA spare parts
375016073001	BOLT WITH SCREW-M8X1.25-AS PER DRG	TATA spare parts
375016073002	BOLT WITH SCREW	TATA spare parts
375016083001	DOOR SEALING SUPPORT	TATA spare parts
375016083002	DOOR SEALING SUPPORT	TATA spare parts
375016083003	SUPPORT	TATA spare parts
375016083004	DOOR SEALING SUPPORT	TATA spare parts
375016303001	EMERGENCY DOOR INTERNAL FINSHING (ABS)	TATA spare parts
375016303002	EMERGENCY DOOR LATCH COVERING 208	TATA spare parts
375016303003	EMERGENCE DOOR COVERING	TATA spare parts
375016912001	EMERGENCY DOOR ASSY	TATA spare parts
375017003001	MECHANISM FRONT	TATA spare parts
375017003002	MECHANISM REAR	TATA spare parts
375017003003	DUBLE JK DOOR 1210X1983	TATA spare parts
375017003004	REAR DOOR MECHANISM 1210DOOR	TATA spare parts
375017003005	FRONT DOOR MECHANISM	TATA spare parts
375017003013	DOUBLE JK DOOR PNEUMATIC DOOR MECHANISM	TATA spare parts
375017003036	1210_INSWING FRONT DOOR	TATA spare parts
375017003039	FRONT DOOR TREE ASSY	TATA spare parts
375017003040	REAR DOOR TREE ASSY	TATA spare parts
375017003041	FRONT DOOR BRUSH ASSY	TATA spare parts
375017003043	FRONT DOOR EXTRUSION LH & RH	TATA spare parts
375017003045	SIDE GASKET	TATA spare parts
375017003046	CESL 4X12 DOOR HARNESS	TATA spare parts
375017004031	FRONT DOOR SHELF PLATE ASSY	TATA spare parts
375017004032	REAR DOOR SHELF PLATE ASSY	TATA spare parts
375017004033	FRONT & REAR DOOR RH FLAP ASSY	TATA spare parts

375017004034	FRONT & REAR DOOR LH FLAP ASSY	TATA spare parts
375017235001	GLASS FOR CESL 4X12	TATA spare parts
375017313001	T LOCKNUT CONNECTOR	TATA spare parts
375017313002	I LOCKNUT CONNECTOR	TATA spare parts
375017912005	PNEUMATICS AND MECHANICS COMPONENTS	TATA spare parts
375017964012	LIMITSWITCH ROD FOR DIA 63/100	TATA spare parts
375017964013	CONNECTOR PLATE FOR CYLINDER ROD 63	TATA spare parts
375017964014	REAR LIMIT SWITCH BRACKET	TATA spare parts
375017964015	FRONT LIMITSWITCH BRACKET	TATA spare parts
375017964016	FLOW CONTROL VALVE 6 3/8INCH	TATA spare parts
375017964017	FORK WITH PIN	TATA spare parts
375017964018	CYLINDER DIA 63/100 SU	TATA spare parts
375017964019	MALE CLEVICE HINGE DIA 63	TATA spare parts
375017964020	CYLINDER DIA 63/70 SU	TATA spare parts
375017964021	ADJUSTMENT SCREW	TATA spare parts
375017964022	BOTTOM COVER BRACKET FOR LH FLAP	TATA spare parts
375017964023	BOTTOM COVER BRACKET FOR RH FLAP	TATA spare parts
375017964024	TOP MTG BRACKET	TATA spare parts
375017964025	DELRIN ROLLER	TATA spare parts
375017964026	SUPPORT SHAFT RD - LH	TATA spare parts
375017964027	SUPPORT SHAFT RD - RH	TATA spare parts
375017964028	SUPPORT SHAFT RD - LH	TATA spare parts
375017964029	SUPPORT SHAFT RD - RH	TATA spare parts
375017964030	GLASS FOR FD INSWING DOOR	TATA spare parts
375017964031	SPACER PLATE FOR FRONT DOOR OF 4X12 CESL	TATA spare parts
375017964033	BOTTOM BRACKET FOR 4X12 CESL	TATA spare parts
375017964034	FRONT DOOR SHELF PLATE	TATA spare parts
375017964035	HANDLE FOR CESL 4/12 INSWING DOOR	TATA spare parts
375017964036	ROLLER SHAFT BRACKET	TATA spare parts
375017964037	ROLLER SHAFT	TATA spare parts
375017964038	LOWER PIVOT ASSEMBLY	TATA spare parts
375017964039	BEARING GE 20ES	TATA spare parts
375017964040	ROD END BEARING SA17ES	TATA spare parts
375017964041	DIA 14 SS BALL	TATA spare parts
375017964042	SHELF PLATE REAR FOR 4X12 CESL	TATA spare parts
375017964043	SPACER PLATE FOR REAR DOOR OF 4X12 L	TATA spare parts
375017964044	INTERNAL EMERGENCY WITH 3/2 VALVE	TATA spare parts
375017964045	EXTERNAL EMERGENCY WITH 3/2 VALVE	TATA spare parts
375017964046	SIDE GASKET	TATA spare parts
375017964047	CENTER GASKET 2	TATA spare parts
375017964048	CENTER GASKET 1	TATA spare parts
375017964049	BRUSH ASSEMBLY FOR JBM TARMAC	TATA spare parts
375017965001	SHELF PLATE BRACKET LH	TATA spare parts
375017965002	SHELF PLATE BRACKET RH	TATA spare parts
375018003003	L SHAPE PLATE	TATA spare parts
375018003004	FLAP STOPPER ASSY.	TATA spare parts
375018003007	HINGE MECHANISM LH SIDE	TATA spare parts

375018003008	HINGE MECHANISM RH SIDE	TATA spare parts
375018003009	FLAP SUPP. ASSY.	TATA spare parts
375018003010	RIGHT CORNER FRONT BUMPER	TATA spare parts
375018003011	LEFT CORNER FRONT BUMPER	TATA spare parts
375018003012	FRONT BUMPER	TATA spare parts
375018003013	FRONT FACE ASSY WITH FRP FOR L.E CNG GEN	TATA spare parts
375018003014	FRONT FRP FLAP	TATA spare parts
375018003019	FRONT FACE _STEEL	TATA spare parts
375018003031	FRONT FACE & FLAP WITH BUMPER ASSY-GEN 5	TATA spare parts
375018004001	FRONT FRP FLAP	TATA spare parts
375018004006	FRONT BUMPER MTG. BRACKET - LH & RH	TATA spare parts
375018073001	MS ROD D8	TATA spare parts
375018084013	FOG LAMP SUPPORT	TATA spare parts
375018264001	EXTERNAL FRP FLAP	TATA spare parts
375018264013	FRONT TOW HOOK COVER GEN5_4X12	TATA spare parts
375018303001	END CAP (HIG DENSITY POLYETHYLENE)	TATA spare parts
375018303002	CLAMP (FRONT FLAP STAY ROD)	TATA spare parts
375018912005	FRONT FLAP ASSY	TATA spare parts
375019002003	REAR FLAP ASSY	TATA spare parts
375019003002	ROD COUPLING BOLT ASSEMBLY	TATA spare parts
375019003006	ENGINE FLAP SAFETY LOCK SUPP. BASE ASS.	TATA spare parts
375019003009	REAR FACE ASSY WITH FRP FOR L.E CNG GEN	TATA spare parts
375019003010	LEFT CORNER REAR BUMPER	TATA spare parts
375019003011	RIGHT CORNER REAR BUMPER	TATA spare parts
375019003012	REAR BUMPER	TATA spare parts
375019003017	REAR FACE-AL	TATA spare parts
375019003031	REAR FACE WITH BUMPER ASSY-GEN 5 4X12	TATA spare parts
375019004028	REAR FLAP STR PANEL CESL 4X12	TATA spare parts
375019004032	REAR TOP FLAP STR & PANEL ASSY	TATA spare parts
375019083001	SHUTTER LATCH CLOSING COUPLING	TATA spare parts
375019083002	LUGGAGE DOOR LATCH CLOSNG COUPLER	TATA spare parts
375019912001	REAR FLAP ASSY PARTS ON REAR STRUCTURE	TATA spare parts
375019912008	REAR BATTERY FLAP INFO _RELE	TATA spare parts
375019912009	REAR TOP FLAP ASSY INFO	TATA spare parts
375019963001	GAS PISTON	TATA spare parts
375020003003	FLAP JAMB ASSY	TATA spare parts
375020003004	ENGINE (CNG VALVE) SIDE HINGED DOOR ASSY	TATA spare parts
375020003005	ENGINE (AIR FILTER) SIDE HINGED DOOR ASS	TATA spare parts
375020003009	ENGINE SIDE HINGES	TATA spare parts
375020003013	BATTERY BOX HINGED DOOR (FLAP) ASSEMBLY	TATA spare parts
375020003030	SERVICE FLAP PANEL ASSY 315X230	TATA spare parts
375020003037	BATTERY FRAME & PANEL ASSY	TATA spare parts
375020003039	AUX DRIVE PANEL & FRAME ASSY	TATA spare parts
375020003042	BCS PANEL & FRAME ASSY	TATA spare parts
375020003044	RADIATOR FLAP FRM & PNL ASSY CESL 4X12	TATA spare parts
375020003048	CHARGER FRAME & PANEL ASSY	TATA spare parts
375020083001	FLAP HINGE SHIM	TATA spare parts

375020083002	FLAP LATCH COUPLING	TATA spare parts
375020083003	FLAP LATCH COUPLING	TATA spare parts
375020083004	SUPPORTING PLATE	TATA spare parts
375020303001	KNOB FOR HINGED DOOR ITEMS	TATA spare parts
375020912003	ENGINE SIDE FLAP (AIR FILTER SIDE) MAIN	TATA spare parts
375020912005	ENGINE SIDE FLAP (BATTERY FLAP) MAIN ASS	TATA spare parts
375022003001	RAMP STRUCTURE ASSY	TATA spare parts
375022003002	HANDICAPPED RAMP HINGE ASSY	TATA spare parts
375022003003	COVER RECESSED HANDLE	TATA spare parts
375022083001	RAMP STRUCTURE PROFILE	TATA spare parts
375022083002	L PROFILE 890X40X1 THK.	TATA spare parts
375022183001	CLAMP UPPER PLATE	TATA spare parts
375022213001	RAMP FINISH PROFILE	TATA spare parts
375022213002	RAMP FINISH PROFILE	TATA spare parts
375022213003	RAMP FINISH PROFILE	TATA spare parts
375027003009	Y1_9X9_AJL_EV_BCS UNIT SERVICE FLAP ASSY	TATA spare parts
375027003010	FRONT END SHOW COVER GEN 5 4X12	TATA spare parts
375027003013	REAR END SHOW COVER ASMBLY GEN5-4X12	TATA spare parts
375027003014	BATTERY TOP COVER 1 PANEL ASSY-GEN5 4X12	TATA spare parts
375027003015	BATTERY TOP COVER 2 PANEL ASSY-GEN5 4X12	TATA spare parts
375027085026	BCS MOUNTING REINFORCEMNT PLATE	TATA spare parts
375027183001	ROOF EXTERNAL PANELING PLATE 101	TATA spare parts
375027183009	BATTERY COVER REAR LOUVER MESH-GEN 5 4X1	TATA spare parts
375027263003	TOP CABLE COVER GEN5_4X12	TATA spare parts
375028003001	PANELING BETWEEN WINDOW ASSY. 201	TATA spare parts
375028003002	PANELING BETWEEN WINDOW ASSY. 202	TATA spare parts
375028003003	PANELING BETWEEN WINDOW ASSY. 203	TATA spare parts
375028003004	PANELING BETWEEN WINDOW ASSY. 204	TATA spare parts
375028003006	PANELING BETWEEN WINDOW ASSY. 206	TATA spare parts
375028003007	PANELING BETWEEN WINDOW ASSY. 207	TATA spare parts
375028003008	PANELING BETWEEN WINDOW ASSY.205	TATA spare parts
375028003009	RIVETMENT BETWEEN WINDOWS ASSY	TATA spare parts
375028083002	UPPER SIDE EXTERNAL STRETCH PANELING209	TATA spare parts
375028083004	UPPER SIDE EXTERNAL PANELING 211	TATA spare parts
375028083005	UPPER SIDE EXTERNAL STRETCH PANELING 215	TATA spare parts
375028083006	UPPER SIDE EXTERNAL STRETCH PANELING 217	TATA spare parts
375028083007	UPPER SIDE EXTERNAL PANELING 208	TATA spare parts
375028083008	UPPER SIDE EXTERNAL PANELING 227	TATA spare parts
375028083034	LH SKIRT PANEL 01	TATA spare parts
375028083035	LH SKIRT PANEL 02	TATA spare parts
375028083036	LH SKIRT PANEL	TATA spare parts
375028083037	RH SKIRT PANEL 07	TATA spare parts
375028083038	LH SKIRT PANEL 03	TATA spare parts
375028083039	LH SKIRT PANEL	TATA spare parts
375028083040	LH SKIRT PANEL	TATA spare parts
375028083042	LH SKIRT PANEL 04	TATA spare parts
375028083043	LH SKIRT PANEL 05	TATA spare parts

375028083045	LH SKIRT PANEL 06	TATA spare parts
375028083046	LH SKIRT PANEL 07	TATA spare parts
375028083047	RH SKIRT PANEL 01	TATA spare parts
375028083048	RH SKIRT PANEL 02	TATA spare parts
375028083049	RH SKIRT PANEL 03	TATA spare parts
375028083050	RH SKIRT PANEL 04	TATA spare parts
375028083051	RH SKIRT PANEL 05	TATA spare parts
375028083052	RH SKIRT PANEL	TATA spare parts
375028083053	LH SKIRT PANEL	TATA spare parts
375028083054	LH SKIRT PANEL	TATA spare parts
375028083055	LH SKIRT PANEL	TATA spare parts
375028083056	LH SKIRT PANEL	TATA spare parts
375028083057	LH SKIRT PANEL	TATA spare parts
375028083058	LH SKIRT PANEL	TATA spare parts
375028083059	LH SKIRT PANEL	TATA spare parts
375028083068	GI SHEET EXT PANEL	TATA spare parts
375028083069	GI SHEET EXT PANEL	TATA spare parts
375028083070	GI SHEET EXT PANEL	TATA spare parts
375028083071	GI SHEET EXT PANEL	TATA spare parts
375028083072	GI SHEET EXT PANEL	TATA spare parts
375028083073	GI SHEET EXT PANEL	TATA spare parts
375028083074	GI SHEET EXT PANEL_RH	TATA spare parts
375028083075	C CHANNLE	TATA spare parts
375028083076	L-PROFILE	TATA spare parts
375028083085	RH SKIRT PANEL	TATA spare parts
375028083086	BOTTOM SKIRT PANEL	TATA spare parts
375028083088	LH SKIRT PANEL 02	TATA spare parts
375028083089	LH SKIRT PANEL	TATA spare parts
375028083090	RH STRETCH PANEL	TATA spare parts
375028083091	LH SKIRT PANEL	TATA spare parts
375028083092	WINDOW PILLAR PANEL RH 06	TATA spare parts
375028083093	WINDOW PILLAR PANEL RH 06	TATA spare parts
375028083094	WINDOW PILLAR PANEL RH 06	TATA spare parts
375028083095	WINDOW PILLAR PANEL RH 07	TATA spare parts
375028083096	WINDOW PILLAR PANEL RH 06	TATA spare parts
375028083097	WINDOW PILLAR PANEL RH 08	TATA spare parts
375028083099	WINDOW PILLAR PANEL RH 03	TATA spare parts
375028083100	WINDOW PILLAR PANEL RH 04	TATA spare parts
375028083101	WINDOW PILLAR PANEL RH 04	TATA spare parts
375028083103	WINDOW PILLAR PANEL RH 05	TATA spare parts
375028083104	WINDOW PILLAR PANEL RH 06	TATA spare parts
375028083106	CCS CHARGING SEALING PANEL	TATA spare parts
375028083107	L-PROFILE PANEL	TATA spare parts
375028083108	C-PROFILE PANEL	TATA spare parts
375028083109	LH FRONT PILLAR PANEL	TATA spare parts
375028083110	RH FRONT PILLAR PANEL	TATA spare parts
375028183002	SKIRT EXTERNAL PANELING 202	TATA spare parts

375028183004	SKIRT EXTERNAL PANELING 204	TATA spare parts
375028183005	SKIRT EXTERNAL PANELING 205	TATA spare parts
375028183008	PANELING OVER THE DOOR 212	TATA spare parts
375028183009	SIDE FRAME RIVETMENT PLATE	TATA spare parts
375028183010	SIDE FRAME RIVETMENT PLATE	TATA spare parts
375028183028	FRONT PASSENGER DOOR APERTURE COVER FRO	TATA spare parts
375028183029	FRONT PASSENGER DOOR APERTURE COVER REA	TATA spare parts
375028183032	SKIRT EXTERNAL PANELING 216	TATA spare parts
375028183034	SKIRT EXTERNAL PANELING 218	TATA spare parts
375028183035	SKIRT EXTERNAL PANELING 219	TATA spare parts
375028183036	SKIRT EXTERNAL PANELING 220	TATA spare parts
375028183037	PANELING OVER THE DOOR 221	TATA spare parts
375028183038	SIDEFAME REVETTING PLATES	TATA spare parts
375028183039	SIDEFAME REVETTING PLATES	TATA spare parts
375028183040	SKIRT EXTERNAL PANELING 222	TATA spare parts
375028183041	UPPER SIDE EXTERNAL PANELING 223	TATA spare parts
375028183042	PANELING OVER THE DOOR 224	TATA spare parts
375028183043	UPPER SIDE EXTERNAL PANELING 225	TATA spare parts
375028183045	UPPER SIDE EXTERNAL PANELING 227	TATA spare parts
375028183046	UPPER SIDE EXTERNAL PANELING 228	TATA spare parts
375028183049	SKIRT EXTERNAL PANELING 231	TATA spare parts
375028183050	SKIRT EXTERNAL PANELING 233	TATA spare parts
375028183051	SKIRT EXTERNAL PANELING 234	TATA spare parts
375028183052	UPPER SIDE EXTERNAL PANELING 235	TATA spare parts
375028183053	1.00 ALUMINIUM PLATES	TATA spare parts
375028183054	1.00 ALUMINIUM PLATES	TATA spare parts
375028183055	1.00 ALUMINIUM PLATES	TATA spare parts
375028183056	1.00 ALUMINIUM PLATES	TATA spare parts
375028183058	SKIRT EXTERNAL PANELING 224	TATA spare parts
375028183059	SKIRT EXTERNAL PANELING 225	TATA spare parts
375028183060	SKIRT EXTERNAL PANELING 207	TATA spare parts
375028183061	PANELING OVER THE DOOR 211	TATA spare parts
375028183062	UPPER SIDE EXTERNAL PANELING 229	TATA spare parts
375028183063	SKIRT EXTERNAL PANELING 222	TATA spare parts
375028183064	UPPER SIDE EXTERNAL PANELING 229	TATA spare parts
375028183065	SIDEFAME PANELING PLATE 223	TATA spare parts
375028183066	UPPER SIDE EXTERNAL PANELING 228	TATA spare parts
375028184004	SIDEFAME PANELING PLATE 304	TATA spare parts
375028184005	SIDEFAME PANELING PLATE 305	TATA spare parts
375028184009	SIDEFAME PANELING PLATE 307	TATA spare parts
375029003068	INSPECTION COVER ASSY_APP_349X280	TATA spare parts
375029003069	INSPECTION COVER ASSY APP 590X296	TATA spare parts
375029003070	INSPECTION COVER ASSY EV APP 280X270	TATA spare parts
375029003071	INSPECTION COVER ASSY APP 786X246	TATA spare parts
375029003072	INSPECTION COVER ASSY APP 149X215	TATA spare parts
375029003073	CESL_4X12 INSPECTION LID_149X280	TATA spare parts
375029003074	CESL_4X12 INSPECTION LID_149X315	TATA spare parts

375029073001	BUSH FOR CUTOUT	TATA spare parts
375029083001	SIDEWALL SKIRTING-BOARD	TATA spare parts
375029083002	MAINTENANCE COVER	TATA spare parts
375029083003	MAINTENANCE COVER	TATA spare parts
375029083004	MAINTENANCE COVER	TATA spare parts
375029083005	MAINTENANCE COVER	TATA spare parts
375029912005	MAINTENANCE CUTOUTS POSITION DRG	TATA spare parts
375042002002	ELECTRIC COMMAND COVERING ASSEMBLY	TATA spare parts
375042003012	FRONT FOG LAMP ASSY	TATA spare parts
375042003014	REAR FOG LAMP ASSY	TATA spare parts
375042083009	VOICE ANNOUNCEMENT SOFTWARE AND HARDW	TATA spare parts
375042083022	BRACKET OF FRONT SIGN& 2 MM THICK	TATA spare parts
375042083024	SUPPORT PLATE FOR INTERNAL DESTINATION B	TATA spare parts
375042083025	SUPPORT PLATE - SIDE LH	TATA spare parts
375042083026	SUPPORT PLATE - SIDE RH	TATA spare parts
375042183001	CHANNEL BETWEEN LUMINARIES	TATA spare parts
375042183002	CHANNEL BETWEEN LUMINARIES	TATA spare parts
375042183003	CHANNEL BETWEEN LUMINARIES	TATA spare parts
375042183004	CHANNEL BETWEEN LUMINARIES	TATA spare parts
375042183005	LUMINARY CONDUIT	TATA spare parts
375042183006	LUMINARY CONDUIT	TATA spare parts
375042183007	CHANNEL BETWEEN LUMINARIES	TATA spare parts
375042362009	HARNESS OBU BDC 12M GEN 5_CHEMITO	TATA spare parts
375042362011	CABLE REVERSE CAMERA EXTENSION_CHEMITO	TATA spare parts
375042362012	HARNESS ITS COMPONENT 12M GEN5_CHEMITO	TATA spare parts
375042363001	LOWER ELECTRIC HARNESS	TATA spare parts
375042363002	SWITCH PIGTAIL HARNESS	TATA spare parts
375042363003	SMLH-LH-AFTER REAR AXLE	TATA spare parts
375042363004	SMLH-LH BEFORE REAR AXLE.	TATA spare parts
375042363005	SMLH-LH-2 LAMPS AFTER FRONT AXLE	TATA spare parts
375042363006	SML-2 LAMPS BEORE FRONT AXLE	TATA spare parts
375042363007	SML-RH AFTER REAR AXLE	TATA spare parts
375042363008	SML-RH BEFORE REAR AXLE.	TATA spare parts
375042363009	SML-RH 2 LAMPS AFTER FRONT AXLE	TATA spare parts
375042363010	SIDE MARKER LAMPS ELECTRIC HARNESS	TATA spare parts
375042363011	ROOF MARKER LAMP LH & RH	TATA spare parts
375042363012	LICENSE PLATE ELECTRIC HARNESS	TATA spare parts
375042363013	EMERGENCY DOOR ELECTRIC HARNESS	TATA spare parts
375042363014	ROOF ELECTRIC HARNESS	TATA spare parts
375042363015	UPPER FRONT ELECTRIC HARNESS	TATA spare parts
375042363016	DASHBOARD ELECTRIC HARNESS	TATA spare parts
375042363017	LH INTERNAL LIGHTING W/H	TATA spare parts
375042363018	RH INTERNAL LIGHTING W/ H	TATA spare parts
375042363019	MAINENANCE LIGHT ELECTRIC HARNESS	TATA spare parts
375042363021	FUSE BOX	TATA spare parts
375042363029	DRIVER CONTROLLER (CANRUN)	TATA spare parts
375042363058	FUSE BOX ELECTRIC W/H	TATA spare parts

375042363061	RH VENTILATOR ELECTRIC HARNESS	TATA spare parts
375042363062	LH VENTILATOR ELECTRIC HARNESS	TATA spare parts
375042363072	EXAUST FAN HARNESS	TATA spare parts
375042363074	FUSE BOX HARNESS FOR EXAUST FAN	TATA spare parts
375042363094	ELECTRIC POWER PLANT HARNESS	TATA spare parts
375042363095	FUSE WATER PUMP PIGTAIL HARNESS	TATA spare parts
375042363141	FRONT CBCU HARNESS_G5 CSEL 4/12	TATA spare parts
375042363142	REAR CBCU HARNESS_G5 CSEL 4/12	TATA spare parts
375042363143	STOP REQUEST HARNESS 6 NOS EV4X12 GEN5	TATA spare parts
375042363145	PIGTAIL RAMP SWITCH	TATA spare parts
375042363146	AIR PURIFIRE PIGATIL_EV G5	TATA spare parts
375042363147	INTERNAL LAMP HARNESS 4/12 CSEL_DS	TATA spare parts
375042363149	STOP REQUEST HARNESS	TATA spare parts
375042363150	AIS140 W/H 4/12 GEN5	TATA spare parts
375042363183	W. HARNESS MOOD LIGHT EV 4X12 GEN5	TATA spare parts
375042372005	STOP REQUEST SWITCH	TATA spare parts
375042372010	EMERGENCY LIGHT CUM BUZZER	TATA spare parts
375042372011	EMERGENCY LLIHGT CUM BUZZER_PACOLINE	TATA spare parts
375042373006	DESTINATION BOARD SWITCH	TATA spare parts
375042373007	DRIVER FAN SWITCH	TATA spare parts
375042373008	STOP REQUEST RESET SWITCH	TATA spare parts
375042373009	DRIVER LAMP SWITCH	TATA spare parts
375042373010	INTERNAL LAMP SWITCH	TATA spare parts
375042373011	FRONT TURN SIGNAL LAMP RH	TATA spare parts
375042373012	FRONT TURN SIGNAL LAMP LH	TATA spare parts
375042373015	INTERIOR LAMP ACRYLIC COVER (RED)	TATA spare parts
375042373016	EMERGENCY RESET SWITCH MUX	TATA spare parts
375042373017	CEILING LIGHT LENS (WHITE)	TATA spare parts
375042373019	SIDE MARKER LAMP	TATA spare parts
375042373020	SIDE REPEATER LAMP	TATA spare parts
375042373038	RED LUMINARY COVER	TATA spare parts
375042373039	EMERGENCY DOOR ALARM SWITCH	TATA spare parts
375042373040	DOOR CLOSING INDICATOR SUB-ASSEMBLY	TATA spare parts
375042373044	FRONT DESTINATION BOARD	TATA spare parts
375042373045	SIDE DESTINATION BOARD	TATA spare parts
375042373046	INTERNAL DESTINATION BOARD-ABOVE GANG W	TATA spare parts
375042373047	DESTINATION BOARD CONTROLLER WITH CABLE	TATA spare parts
375042373048	GPS ANTENNA & RECIEVER	TATA spare parts
375042373061	BEACON FLASHER LAMP_24V	TATA spare parts
375042912047	ASSY AIS140 HARNESS EV4/12 GEN5	TATA spare parts
375042912048	ELECTRICAL HARNESS ASSY CSEL_4/12	TATA spare parts
375044083005	LADDER MOUNTING SUPPORT PLATE	TATA spare parts
375045003014	FRONT UNION ASSEMBLY	TATA spare parts
375045003058	DESTINATION BOARD MTG BRKT ASSY	TATA spare parts
375045004017	WIPER MOTOR COVER	TATA spare parts
375045083009	FOR ABS SUPP IN FRT OF WINDSHIELD	TATA spare parts
375045083024	JOINT GUSSET OF THE CHASSIS SUPERSTRUCT.	TATA spare parts



375045084031	WIPER MOTOR COVER	TATA spare parts
375045084049	REAR BUMPER ATTACHMENT SUPPORT	TATA spare parts
375045084050	REAR BUMPER ATTACHMENT SUPPORT	TATA spare parts
375046003002	AIR BALOON PROTECTING ASSY	TATA spare parts
375050003042	WINDOW SIDE AL PROFILE RH FRONT_EV 4X12	TATA spare parts
375050003043	WINDOW SIDE AL PROFILE RH REAR_EV 4X12	TATA spare parts
375050003044	WINDOW SIDE AL PROFILE LH FRONT_EV 4X12	TATA spare parts
375050003045	WINDOW SIDE AL PROFILE LH REAR_EV 4X12	TATA spare parts
375050003052	RH AC DUCT SUB ASSY FRONT_EV 4X12	TATA spare parts
375050003053	LH AC DUCT SUB ASSY_FRONT_EV 4X12	TATA spare parts
375050003054	LH AC DUCT SUB ASSY REAR_EV 4X12	TATA spare parts
375050003055	RH AC DUCT SUB ASSY REAR_EV 4X12	TATA spare parts
375050003056	WND SD AL PRFL LH REAR END_EV4X12	TATA spare parts
375050003057	WND SD AL PRFL RH REAR END_EV4X12	TATA spare parts
375050304001	AC DUCT ACRYLIC COVER_WHITE	TATA spare parts
375050324038	AC DUCT PANE 1_EV 4X12	TATA spare parts
375050324039	AC DUCT PANEL LH_EV 4X12	TATA spare parts
375050324041	AC DUCT PANEL REAR RH_EV 4X12	TATA spare parts
375050324042	AC DUCT PANEL ABOVE DOOR FRONT_EV 4X12	TATA spare parts
375050324043	AC DUCT PANEL FRONT RH 1_EV 4X12	TATA spare parts
375050324044	AC DUCT PANEL ABOVE DOOR REAR_EV 4X12	TATA spare parts
375050324045	AC DUCT PANEL MID FRONT EV 4X12	TATA spare parts
375050324051	AC DUCT PANEL FRONT RH 1_EV 4X12	TATA spare parts
375050324052	AC DUCT PANE 1_EV 4X12	TATA spare parts
375050324055	AC DUCT PANEL LH_EV 4X12	TATA spare parts
375050324057	AC DUCT PANEL REAR RH_EV 4X12	TATA spare parts
375050324059	AC DUCT PANEL REAR RH_EV 4X12	TATA spare parts
375050324060	AC DUCT PANEL RH_EV 4X12	TATA spare parts
375050324061	LH AC DUCT PANEL 1 FRONT_EV 4X12	TATA spare parts
375050324062	LH AC DUCT PANEL 2 FRONT_EV 4X12	TATA spare parts
375050324063	LH AC DUCT PANEL 3 FRONT_EV 4X12	TATA spare parts
375050324064	LH AC DUCT PANEL ABOVE DOOR_EV 4X12	TATA spare parts
375050324065	RH AC DUCT PANEL MIDDLE EV 4X12	TATA spare parts
375050324066	AC DUCT FRONT END CAP LH	TATA spare parts
375050963004	A/C SPH. W/O HEATING	TATA spare parts
375050963010	AITTR HVAC UNIT GEN5 4X12	TATA spare parts
375050963012	FRONT MIDDLE COVER	TATA spare parts
375050963013	DC-DC(3KW)	TATA spare parts
375050963014	CONDENSER CORE	TATA spare parts
375050963015	LEFT SUPPORT PLATE OF FANS	TATA spare parts
375050963016	RIGHT SUPPORT PLATE OF FANS	TATA spare parts
375050963017	CONDENSER COVER UNIT	TATA spare parts
375050963019	FAN	TATA spare parts
375050963020	RIGHT SIDE COVER	TATA spare parts
375050963021	SEALING PLATE OF BLOWER	TATA spare parts
375050963022	BLOWER	TATA spare parts
375050963023	BLOWER WIRE HARNESS	TATA spare parts

375050963024	RIGHT EVAPORATOR CORE	TATA spare parts
375050963025	5 INCHES HINGES	TATA spare parts
375050963026	2-INCH HINGES	TATA spare parts
375050963027	CONTROL BOX	TATA spare parts
375050963028	FUSE BOX	TATA spare parts
375050963029	HV BOX FOR PTC	TATA spare parts
375050963030	FRESH AIR UNIT ASSEMBLY	TATA spare parts
375050963031	LEFT SIDE COVER	TATA spare parts
375050963032	LEFT EVAPORATOR CORE	TATA spare parts
375050963033	AC HOUSING	TATA spare parts
375050963034	COMPRESSOR SUPPORT UNIT	TATA spare parts
375050963035	VAPOR-LIQUID SEPARATOR	TATA spare parts
375050963036	COMPRESSOR BRACKET	TATA spare parts
375050963037	COMPRESSOR DAMPING PAD	TATA spare parts
375050963038	COMPRESSOR	TATA spare parts
375050963039	FOUR-WAY VALVE LH & R H	TATA spare parts
375050963040	SEPARATOR TO COMPRESSOR PIPE LH	TATA spare parts
375050963041	SEPARATOR TO COMPRESSOR PIPE RH	TATA spare parts
375050963042	EXV TO EVAPORATOR LH	TATA spare parts
375050963043	EXV TO EVAPORATOR RH	TATA spare parts
375050963044	CONDENSER TO EXV LH	TATA spare parts
375050963045	CONDENSER TO EXV RH	TATA spare parts
375050963046	EVAPORATOR TO FOUR-WAY VALVE LH	TATA spare parts
375050963047	EVAPORATOR TO FOUR-WAY VALVE RH	TATA spare parts
375050963048	COMPRESSOR OUT TO FOUR-WAY VALVE LH	TATA spare parts
375050963049	COMPRESSOR OUT TO FOUR-WAY VALVE RH	TATA spare parts
375050963050	FOUR-WAY VALVE TO CONDENSER LH	TATA spare parts
375050963051	FOUR-WAY VALVE TO CONDENSER RH	TATA spare parts
375050963052	FOUR-WAY VALVE TO SEPARATOR LH	TATA spare parts
375050963053	FOUR-WAY VALVE TO SEPARATOR RH	TATA spare parts
375050963054	FILTER/DRIER WELDED UNIT	TATA spare parts
375050963055	COMPRESSOR COVER	TATA spare parts
375050963056	ECU WIRING HARNESS	TATA spare parts
375050963057	HIGH PRESSURE SWITCH	TATA spare parts
375050963058	MIDDLE PRESSURE SWITCH	TATA spare parts
375050963059	LOW PRESSURE SWITCH	TATA spare parts
375050963060	TEMPERATURE SENSOR	TATA spare parts
375050963061	CONDENSER FAN WIRE HARNESS	TATA spare parts
375050963062	COMPRESSOR LH HV WIRE HARNESS	TATA spare parts
375050963063	COMPRESSOR RH HV WIRE HARNESS	TATA spare parts
375050963064	HV CABLE WIRING HARNESS	TATA spare parts
375050963065	HV CABLE CUT-OUT GROMMET	TATA spare parts
375050963066	HV GROUND CABLE(9X12M)	TATA spare parts
375050963067	UV AIR PURIFIER	TATA spare parts
375050963068	PTC LH	TATA spare parts
375050963069	PTC RH	TATA spare parts
375050963070	FRAME	TATA spare parts

375050963071	GRILL	TATA spare parts
375050963072	RAG HINGE	TATA spare parts
375050963073	RAG FILTER	TATA spare parts
375050963074	FILTER SUPPORT	TATA spare parts
375051003003	HAND HOLD TUBE MS 4715 BENDED ASSY	TATA spare parts
375051003006	HAND HOLD TUBE MS 850 ASSY	TATA spare parts
375051003007	HAND HOLD TUBE MS 550 ASSY	TATA spare parts
375051003008	HAND HOLD TUBE MS 3849 BENDED ASSY	TATA spare parts
375051003009	HAND HOLD TUBE MS 2430 ASSY	TATA spare parts
375051003010	HAND HOLD TUBE MS 1810 ASSY	TATA spare parts
375051003011	HAND HOLD TUBE MS 820 ASSY	TATA spare parts
375051003014	HAND HOLD MS 1300 ASSY	TATA spare parts
375051003015	HAND HOLD TUBE MS 80 ASSY	TATA spare parts
375051003020	HAND HOLD TUBE MS 725 ASSY	TATA spare parts
375051003022	HAND HOLD TUBE MS 1304 BENDED ASSY	TATA spare parts
375051003023	HAND HOLD TUBE MS 1565 ASSY	TATA spare parts
375051003024	HANDHOLD TUBE MS 1802 BENDED ASSY	TATA spare parts
375051003026	HAND HOLD TUBE MS 655 ASSY	TATA spare parts
375051003027	HAND HOLD M.S 1957 BENDED ASSY	TATA spare parts
375051003028	HAND HOLD TUBE ASSY 540	TATA spare parts
375051003029	HAND HOLD TUBE MS 820 ASSY	TATA spare parts
375051003032	HANDHOLD	TATA spare parts
375051003109	PACOLINE HANDHOLD STRAP BLUE	TATA spare parts
375051003161	DRIVER PARTITION ASSY	TATA spare parts
375051003162	MIDDLE PARTITION ASSY	TATA spare parts
375051003163	GRAB RAIL LH WH ASSY	TATA spare parts
375051003164	REAR DECK STANCHION TUBE ASSY-3	TATA spare parts
375051004003	HANDHOLD TUBE MS 1758 ASSY	TATA spare parts
375051004004	HAND HOLD TUBE MS 2184 BENDED ASSY	TATA spare parts
375051004005	HAND HOLD TUBE MS 1864 BENDED ASSY	TATA spare parts
375051004006	HAND HOLD TUBE MS 753 ASSY	TATA spare parts
375051004007	HANDHOLD TUBE M.S 800 ASSY	TATA spare parts
375051004008	HANHOLD TUBE MS 785 ASSY	TATA spare parts
375051004009	HANDHOLD TUBE MS 1794 BENDED ASSY	TATA spare parts
375051004011	PARTITION WALL COMPONENT	TATA spare parts
375051004012	HEADREST ASSEMBLY FOR DISABLED	TATA spare parts
375051004013	STRUCT. OF AREA DESIGNATED FOR DISABLED	TATA spare parts
375051004014	HANDHOLDS	TATA spare parts
375051004054	40 DIA STANCHION TUBE ASSY	TATA spare parts
375051004055	MS DIA. 40 STANCHION TUBE ASSY	TATA spare parts
375051004056	MS STANCHION TUBE 194 MM ASSY	TATA spare parts
375051004058	MS DIA. 32 STANCHION TUBE-834 MM ASSY	TATA spare parts
375051004059	MS DIA. 32 STANCHION TUBE-RH WH ASSY	TATA spare parts
375051004060	MS DIA. 32 STANCHION TUBE-748 MM ASSY	TATA spare parts
375051004061	MS GRAB RAIL ASSY	TATA spare parts
375051004062	MS DIA. 40 STANCHION TUBE ASSY	TATA spare parts
375051004063	MS DIA. 32 PARTITION TUBE-785 MM	TATA spare parts

375051004064	MS DIA. 32 STANCHION TUBE ASSY	TATA spare parts
375051063002	HANDHOLD CHINESE MODELINCHBUS AD HANDL	TATA spare parts
375051214003	AL PROFILE 830	TATA spare parts
375051214004	AL PROFILE LN 530	TATA spare parts
375051214005	AL PROFILE LN 780	TATA spare parts
375051214007	AL PROFILE LN 750	TATA spare parts
375051214010	AL PROFILE LN 665	TATA spare parts
375051214011	AL PROFILE 805	TATA spare parts
375051234001	WALL GLASS BEHIND OF DRIVER	TATA spare parts
375051234002	WALL GLASS BEHIND OF DRIVER TINTED	TATA spare parts
375051244002	PARTITION WALL WOOD	TATA spare parts
375051303001	STOP REQUESTED SWITCH	TATA spare parts
375051303002	STOP REQUESTED SWITCH ADAPTER	TATA spare parts
375052002002	DASH BOARD ASSY (BASE PANEL NON-AC)	TATA spare parts
375052003002	GAS TANK FLAP ASSEMBLY	TATA spare parts
375052003003	HINGED DOORS OPENING LIMITER	TATA spare parts
375052003004	PANEL PLATE	TATA spare parts
375052003015	FRP ON INSTRUMENTATION PANEL	TATA spare parts
375052003016	DASHBOARD	TATA spare parts
375052003044	DRIVER DOOR COVER GEN 5 4X12	TATA spare parts
375052004001	DASH BOARD LH SIDE	TATA spare parts
375052004002	CENTRAL STATION ATTACHING BASE	TATA spare parts
375052004003	DASH BOARD MAINTENANCE COVER	TATA spare parts
375052004004	INSTRUMENTAL PANEL BOX	TATA spare parts
375052004006	HINGES	TATA spare parts
375052004007	HEAD LAMP BEZEL RH	TATA spare parts
375052004009	HEAD LAMP BEZEL LH	TATA spare parts
375052004024	DASHBOARD WITH FLAP ASSY_GEN5 4X12	TATA spare parts
375052004026	WHEEL HOUSING ASSEMBLY LH GEN5 - 4X12	TATA spare parts
375052004027	WHEEL HOUSING RH ASSEMBLY GEN5 - 4X12	TATA spare parts
375052084001	SWITCHES PLATE 1 RH	TATA spare parts
375052084002	SWITCHES PLATE 2 LH	TATA spare parts
375052084015	FLAP FOR PNEUMATIC BOX MIDDLE DOOR	TATA spare parts
375052183001	CNG PLATFORM FLOOR PLATE	TATA spare parts
375052183002	CNG PLATFORM FLOOR PLATE	TATA spare parts
375052263001	WHEEL HOUSE COVERING (FRP ASSY RHS SIDE)	TATA spare parts
375052263002	WHEEL HOUSE COVERING (FRP ASSY LHS SIDE)	TATA spare parts
375052284002	WHEEL HUMP LH RUBBER MAT GEN 5 - 4X12	TATA spare parts
375052284003	WHEEL HUMP RH RUBBER MAT GEN 5 - 4X12	TATA spare parts
375052323001	PANEL FINISHING 212	TATA spare parts
375052323002	PANEL FINISHING 210	TATA spare parts
375052323024	A-PILLAR COVER LH GEN 5 - 4X12	TATA spare parts
375052323025	A-PILLAR COVER RH GEN 5 - 4X12	TATA spare parts
375052323041	FRONT INNER LH GEN5 4X12	TATA spare parts
375052323042	FRONT INNER RH GEN5 4X12	TATA spare parts
375052324001	FUSE BOX FLAP	TATA spare parts
375052324003	FRONT DOOR COVER GEN 5 - 4X12	TATA spare parts

375052324004	MIDDLE DOOR COVER GEN 5 - 4X12	TATA spare parts
375052324005	REAR INNER GEN5_ 4X12	TATA spare parts
375052324011	ITS COVER GEN5 4X12	TATA spare parts
375052325001	FRONT INNER GEN5 4X12	TATA spare parts
375052325002	FRONT INNER FRONT PART GEN5 4X12	TATA spare parts
375052912003	LAMPS HARNESS/SOCKET KIT	TATA spare parts
375052912004	LUMINOUS INDICATOR ASSY	TATA spare parts
375052913001	HEAD LIGHT BEZEL RH	TATA spare parts
375052913002	HEAD LIGHT BEZEL LH	TATA spare parts
375053003001	STOP REQUEST BOX KIT	TATA spare parts
375053003002	AIR DUCT HINGE KIT	TATA spare parts
375053003003	DUCT COVER ATTACHMENT SUPPORT ASSEMBLY	TATA spare parts
375053003004	DUCT COVER ATTACHMENT SUPPORT ASSY.	TATA spare parts
375053003005	DUCT COVER ATTACHMENT SUPPORT ASSY.	TATA spare parts
375053083001	LUGGAGE RACK PROFILE PATCH	TATA spare parts
375053183001	2 MM PLATE	TATA spare parts
375053183002	ALUMINIUM SHEET	TATA spare parts
375053303001	LUMINARY ACRYLIC	TATA spare parts
375053303002	ACRYLIC PROFILE	TATA spare parts
375054063001	WINDOW GUARD RAIL-LN 2825MM	TATA spare parts
375054063005	WINDOW GUARD RAIL-LN 2375MM	TATA spare parts
375054063010	WINDOW GUARD RAIL-LN 4871 MM	TATA spare parts
375054063011	WINDOW GUARD RAIL-LN 4600MM	TATA spare parts
375054083001	WINDOW GUARD RAIL REINFORCEMENT PLATE	TATA spare parts
375054083002	WINDOW GUARD RAIL REINFORCEMENT PLATE	TATA spare parts
375055303001	ACRYLIC SHEET EMER. DOOR SWITCH COVER	TATA spare parts
375058073001	HINGED DOOR LIMITER SUPPORT(DRIVER DOOR)	TATA spare parts
375058083001	REAR PLATFORM WIRE HARNESS SEAL PLATE	TATA spare parts
375058083002	MULTIPLEXING SUPPORTING PLATE	TATA spare parts
375058183001	NUMBER PLATE REAR	TATA spare parts
375058183004	RAMP FINISH PROFILE BETWEEN RAMP & FLOOR	TATA spare parts
375058183005	L PLATE USING IN ABS MOULDED PROFILE FOR	TATA spare parts
375058263001	WHEEL ARCH - GEN 5 - 4X12	TATA spare parts
375058283001	RUBBER SUPPORT FOR FUEL TANK ATTACHMENT	TATA spare parts
375058283002	RUBBER PROFILE FOR SKIRT PANELING	TATA spare parts
375058303001	SIDE FLAPS LIMITER BELT (DRIVER DOOR)	TATA spare parts
375058303002	RUB RAIL SUPPORT COVER	TATA spare parts
375058303003	END COVER FOR RUB RAIL	TATA spare parts
375058303004	5.5X50 PAN PHILLIPS	TATA spare parts
375058912019	CESL 4X12 EXT. ADHESIVE STICKER ASSY.	TATA spare parts
375059002001	CERTIFICATE HOLDER	TATA spare parts
375059003001	DRIVER ROLL-TYPE SUNSHADE ASSY SIDE	TATA spare parts
375059003002	SUN VISOR ASSY (FRONT)	TATA spare parts
375059003003	PISTON BOX FINISHING COVER ASSY	TATA spare parts
375059303001	PLASTIC SHEET	TATA spare parts
375059303002	HANDLE FOR DRIVER AT DRIVER PORTION	TATA spare parts
375059323001	FLOOR FINISHING COVERING 201	TATA spare parts

375059323002	CELLULAR PHONE CHARGER COVERING 202	TATA spare parts
375059323003	PISTON BOX FINISHING 214	TATA spare parts
375059323004	GAS PISTON STAY	TATA spare parts
375059323006	FRONT UPPER COVERING	TATA spare parts
375059323007	FRONT UPPER COVERING	TATA spare parts
375059323008	FRONT UPPER COVERING	TATA spare parts
375059323009	DOOR UPPER CORNER COVERING 207	TATA spare parts
375059323010	UPPER FRONT MAINTENANCE COVER 209	TATA spare parts
375059323011	WINDSHIELD INTERNAL FINISH	TATA spare parts
375059323012	AIR INTAKE FINISHING	TATA spare parts
375059323013	REAR INTERNAL REVETMENT	TATA spare parts
375059323014	REAR INTERNAL REVETMENT	TATA spare parts
375059323015	REAR INTERNAL REVETMENT	TATA spare parts
375059323017	ECU SUPPORT PLATE COVERING 0231	TATA spare parts
375059323018	AIR INTAKE ABS COVER	TATA spare parts
375059333001	EMERGENCY DOOR STICKER 1	TATA spare parts
375059333002	EMERGENCY DOOR STICKER 2	TATA spare parts
375059333003	EMERGENCY DOOR STICKER 3	TATA spare parts
375059333004	EMERGENCY DOOR STICKER 4	TATA spare parts
375059333005	EMERGENCY DOOR STICKER 5	TATA spare parts
375059333006	EMERGENCY WINDOW STICKER	TATA spare parts
375059333007	EMERGENCY EXIT STICKER 6	TATA spare parts
375059333008	EMERGENCY EXIT STICKER 7	TATA spare parts
375059333009	MARCOPOLO RESINED STICKER	TATA spare parts
375059333010	STICKER - LADIES	TATA spare parts
375059333011	SENIOR CITIZEN STICKER	TATA spare parts
375059333012	HINDI KEEP BUS CLEAN STICKER	TATA spare parts
375059333018	JNNURM LOGO	TATA spare parts
375059333030	FIRE EXTINGUISHER STICKER BS6	TATA spare parts
375059912004	ABS TRIM FINISH FOR 1210	TATA spare parts
375060083001	REARVIEW MIRROR SUPPORT	TATA spare parts
375060233001	ER AUXILIARY MIRROR	TATA spare parts
375060233002	INTERNAL MIRROR	TATA spare parts
375061003007	SEAT COUPLING SUPPORT ASSEMBLY (RPLAT)	TATA spare parts
375061003009	LH TWIN SEATER_475CH_ARM REST	TATA spare parts
375061003010	RH TWIN SEATER_475CH_ARM REST	TATA spare parts
375061003011	LH 2 SEATER_475CH_ARM REST_LAP BELT	TATA spare parts
375061003012	RH 2 SEATER_475CH_ARM REST_LAP BELT	TATA spare parts
375061003013	RH 2 SEATER_FRONT DICKY_A REST_LAP B	TATA spare parts
375061003014	TWIN SEATER_REAR DICKY MOUNTING	TATA spare parts
375061003015	REAR 1 SEATER_REAR DICKY_LAP BELT	TATA spare parts
375061003021	LH TWIN SEATER_475CH_ARM REST_AC	TATA spare parts
375061003022	RH TWIN SEATER_475CH_ARM REST_AC	TATA spare parts
375061003023	LH 2 SEATER_475CH_A REST_L BELT_AC	TATA spare parts
375061003024	RH 2 SEATER_475CH_A REST_L BELT_AC	TATA spare parts
375061003025	RH 2 SEATER_F DICKY_A REST_L BELT_AC	TATA spare parts
375061003026	TWIN SEATER_REAR DICKY MOUNTING_AC	TATA spare parts

375061003027	REAR SINGLE SEATER_R DICKY_L BELT_AC	TATA spare parts
375061003036	SEAT	TATA spare parts
375061003037	RH 2 SEATER_465CH_AR_HSSL_WB	TATA spare parts
375061003038	LH 2 SEATER_465CH_AR_LB_HSSL_URBANO_WB	TATA spare parts
375061003039	RH 2 SEATER_465CH_AR_LB_HSSL_URBANO_WB	TATA spare parts
375061003040	RH 2 SEATER_F.DICKY_AR_LB_HSSL_URBANO_WB	TATA spare parts
375061003041	TWIN SEATER_REAR DICKEY_HSSL_URBANO_WB	TATA spare parts
375061003042	SINGLE SEAT_RE.DICKEY_LB_HSSL_URBANO_WB	TATA spare parts
375062003001	CONDUCTOR BOX	TATA spare parts
375062003002	SAFETY BELT 3 POINT	TATA spare parts
375062003003	REAR SEATS SAFETY BELT	TATA spare parts
375062003005	FIRE EXTINGUISHER BOX ASSY	TATA spare parts
375062003006	FIRE EXTINGUISHER BOX ABS COVER	TATA spare parts
375062003008	ROOF HATCH	TATA spare parts
375062233001	FIRE EXTINGUISHER BOX GLASS	TATA spare parts
375062912002	FIRST AID BOX ASSY	TATA spare parts
375062912008	ROOF HATCH WITH EXHAUST FAN 24 V WEBASTO	TATA spare parts
375062964003	FDAS_PANELLING KIT_CESL_EV_4X12	TATA spare parts
375062964004	FDAS TRIM KIT EV_4X12_CESL	TATA spare parts
375062964005	FDAS_PANELLING KIT_CESL_NAC_EV_4X12	TATA spare parts
375062964006	FDAS_TRIM_KIT_CESL_NAC_EV_4X12	TATA spare parts
375063083001	SUPPORT PLATE	TATA spare parts
375063083002	SUPPORT PLATE	TATA spare parts
375063083003	SUPPORT PLATE	TATA spare parts
375063083004	SUPPORT PLATE	TATA spare parts
375063083005	1.95 (14) STEEL PLATES	TATA spare parts
375063083006	TAIL LAMP SUPPORT	TATA spare parts
375063083007	L PLATE	TATA spare parts
375064003006	URBAN WINDOW	TATA spare parts
375064003007	DRIVER WINDOW ASSEMBLY	TATA spare parts
375064003009	R.H FRONT WINDOW ASSY-1(1476X1175)	TATA spare parts
375064003010	DOOR GLASS ASSEMBLY	TATA spare parts
375064003014	SERVICE DOOR GLASS ASSEMBLY	TATA spare parts
375064003026	DRIVER DOOR WINDOW RH 1103X770MM	TATA spare parts
375064003027	TOP FIXED BOTTOM SLIDING RH 1192X1494MM	TATA spare parts
375064003028	EMERGENCY DOOR WINDOW SLIDING RH 975X56	TATA spare parts
375064003029	TOP FIXED BOTTOM SLIDING RH 1018X1194MM	TATA spare parts
375064003030	TOP FIXED BOTTOM SLIDING RH 1018X1494MM	TATA spare parts
375064003031	TOP SLIDING BOTTOM FIXED REAR RH 1018X12	TATA spare parts
375064003032	TOP FIXED BOTTOM SLIDING LH 1192X1294MM	TATA spare parts
375064003033	TOP FIXED BOTTOM SLIDING LH 1192X1494MM	TATA spare parts
375064003034	TOP FIXED BOTTOM SLIDING LH 1018X744MM	TATA spare parts
375064003035	TOP FIXED BOTTOM SLIDING LH 1018X1494MM	TATA spare parts
375064003036	TOP SLIDING BOTTOM FIXED REAR LH 1018X12	TATA spare parts
375064003048	URBAN WINDOW ASSY. -1	TATA spare parts
375064003049	URBAN WINDOW ASSY. -2	TATA spare parts
375064003050	URBAN WINDOW ASSY. -3	TATA spare parts

375064003051	URBAN WINDOW ASSY. -4	TATA spare parts
375064003052	URBAN WINDOW ASSY. -5	TATA spare parts
375064003053	EMERGENCY WINDOW ASSY	TATA spare parts
375064003054	URBAN WINDOW ASSY. - 8	TATA spare parts
375064003055	URBAN WINDOW ASSY. - 9	TATA spare parts
375064003085	DRIVER RUBBER M WIND_782X1149_CLEAR GLS	TATA spare parts
375064003086	RH_1500X1255_CLEAR GLS_TSBS_RUBER_MOUN	TATA spare parts
375064003087	RH_1418X1230_CLEAR GLS_TSBS_RUBER_MOUN	TATA spare parts
375064003088	RH_640X1058_CLEAR GLS_TSBS_RUBER_MOUNT	TATA spare parts
375064003089	RH_1176X1058_CLEAR GLS_TSBS_RUBER_MOUN	TATA spare parts
375064003090	RH_646X872_CLEAR GLS_TSBS_RUBER_MOUNT	TATA spare parts
375064003091	4X12_RH&LH_907X245_REAR FIX_RUBERMOUNT	TATA spare parts
375064003092	LH_1276X1230_CLEAR GLS_TSBS_RUBER_MOUN	TATA spare parts
375064003093	LH_1418X1230_CLEAR GLS_TSBS_RUBER_MOUN	TATA spare parts
375064003094	LH_711X1058_CLEAR GLS_TSBS_RUBER_MOUNT	TATA spare parts
375064003095	LH_1176X1058_CLEAR GLS_TSBS_RUBER_MOUN	TATA spare parts
375064003096	LH_646X872_CLEAR GLS_TSBS_RUBER_MOUNT	TATA spare parts
375064083001	RH G.I RVM SHEET_182X191X1.55MM	TATA spare parts
375064083002	LH G.I RVM SHEET_165X176X1.55MM	TATA spare parts
375064233022	PASTED WINDOW GLASS LH 6TH	TATA spare parts
375064233086	LH ABV PASS_DR_1240X300_FULL CERAMIC CSL	TATA spare parts
375064233090	LH RVM PASTED_1242X251_FULL CERAMIC_CSL	TATA spare parts
375064233094	RH RVM PASTED_907X274_FULL CERAMIC_CSL	TATA spare parts
375064233095	LH REAR TOP GLS_605X81_FULL CERAMIC CSL	TATA spare parts
375064233098	LH FRNT PASTED GLS_1585X1363_50PERC GRAY	TATA spare parts
375064233099	LH PASTED GLS_1512X1363_50PERC GRAY_CSL	TATA spare parts
375064233100	LH PASTED GLS_1612X1363_50PERC GRAY_CSL	TATA spare parts
375064233101	LH PASTED GLS_925X1363_50PERC GRAY TNT_C	TATA spare parts
375064233102	LH PASTED GLS_1311X1190_50PERC GRAY TNT_	TATA spare parts
375064233103	LH REAR PASTED GLS_1210X1190_50PERC GRAY	TATA spare parts
375064233104	RH FRNT PASTED GLS_1923X1363_50PERC GRAY	TATA spare parts
375064233105	RH PAST_754X1363_50PERC GRAY TNT_CSL_NIR	TATA spare parts
375064233106	RH REAR PASTED GLS_1210X1190_50PERC GRAY	TATA spare parts
375064233109	LH/RH REAR TOP GLS_670X81_FULL CERA CSL	TATA spare parts
375064233110	LH RVM PASTED_1248X272_FULL CERAMIC_CESL	TATA spare parts
375064233111	RH RVM PASTED_910X274_FULL CERAMIC_CESL	TATA spare parts
375064234002	DOOR GLASS	TATA spare parts
375064234003	URBAN WINDOW GLASS -1	TATA spare parts
375064234004	URBAN WINDOW GLASS -2	TATA spare parts
375064234005	URBAN WINDOW GLASS -3	TATA spare parts
375064234006	URBAN WINDOW GLASS -4	TATA spare parts
375064234007	URBAN WINDOW GLASS -5	TATA spare parts
375064234008	EMERGENCY DOOR GLASS	TATA spare parts
375064234009	URBAN WINDOW GLASS -8	TATA spare parts
375064234044	FRONT TILTING GLASS_367X805_5MM_CLEAR	TATA spare parts
375064234045	REAR SLIDING GLASS_392X808_5MM_CLEAR	TATA spare parts
375064234046	BOTTOM FIXED GLASS_755X251_5MM_CLEAR	TATA spare parts



375064284009	DOOR GLASS RUBBER	TATA spare parts
375064284018	LUXURY URBAN PASSENGER WINDOW RUBBER	TATA spare parts
375064284019	RUBBER	TATA spare parts
375064284020	RUBBER	TATA spare parts
375064284021	LUXURY URBAN PASSENGER WINDOW RUBBER	TATA spare parts
375064284022	RUBBER	TATA spare parts
375064284024	LUXURY URBAN PASSENGER WINDOW RUBBER	TATA spare parts
375064284025	RUBBER	TATA spare parts
375064912016	EV_4X12_63WB_PAST_50PERC GRAY_AC_CESL_N	TATA spare parts
375065002001	WIPER ASSY	TATA spare parts
375065003001	WIPER ARM ASSY WITH BLADE (LH)	TATA spare parts
375065003002	WIPER ARM ASSY WITH BLADE (RH)	TATA spare parts
375065003006	RH WIPER ARM-24V	TATA spare parts
375065003007	LH WIPER ARM-24V	TATA spare parts
375065003008	WIPER BLADE-24V	TATA spare parts
375065003009	PANORAMIC LINKAGE ASSY-24V	TATA spare parts
375065003010	ROTATIVE MOTOR-24V	TATA spare parts
375065003011	ASSEMBLY WASHER TANK 3L-24V	TATA spare parts
375065003012	WASHER TANK AND PIGTAIL ASSY BS6	TATA spare parts
375065003015	FRONT WINDSHIELD ASSBLY W/O IR CUT-GEN 5	TATA spare parts
375065083001	AL PALTE FOR WINDSHIELD CLEANING - AT B	TATA spare parts
375065083002	HANDLE USED TO CLEAN WIND SHIELD	TATA spare parts
375065233001	FRONT WINDSHIELD	TATA spare parts
375065233002	FRONT ITINERARY GLASS	TATA spare parts
375065233003	REAR WINDSHIELD GLASS	TATA spare parts
375065233004	FRONT WINDSHIELD GLASS WITH CRMC PRINT	TATA spare parts
375065233005	FRONT ITINERARY GLASS WITH CRMC PRINT	TATA spare parts
375065233006	REAR WINDSHIELD GLASS WITH CRMC PRINT	TATA spare parts
375065233009	ITERNARY WINDSHIELD_ W/O IR CUT- GEN 5	TATA spare parts
375065233010	REAR WINDSHIELD W/O IR CUT- GEN 5	TATA spare parts
375065234005	FRONT WINDSHIELD	TATA spare parts
375065283001	RUBBER BIDDING FR W/SHLD GLASS	TATA spare parts
375065283002	RUBBER- ITINERARY OUTLINED WINDSHIELD	TATA spare parts
375065283003	RUBBER- REAR OUTLINED WINDSHIELD	TATA spare parts
375065283004	FRONT INTERNAL FINISH RUBBER	TATA spare parts
375065284002	FRONT W/S RUBBER GEN 5 4X12	TATA spare parts
375065912004	WINDSHIELD CLEANING ASSY	TATA spare parts
375065912007	WIPER ASSY RHD-24V_DOGA_RELE	TATA spare parts
375065912011	REAR WINDSHIELD FITMENT W/O IR CUT GEN 5	TATA spare parts
3751100090	GLASS-W/SHIELD	TATA spare parts
3751110030	GLASS-W/SHIELD	TATA spare parts
3751210010	GLASS BACK WINDOW	TATA spare parts
3751210012	GLASS BACK WINDOW	TATA spare parts
3751210040	GLASS BACK WINDOW	TATA spare parts
3751300070	GLASS QTR WINDOW	TATA spare parts
3751300080	GLASS QTR WINDOW	TATA spare parts
3751300090	GLASS QTR WINDOW	TATA spare parts

37515550004	FEELER GAUGE SET0.05-1.0/13PCS IS3179	TATA spare parts
3752100050	GLASS-OK W/D	TATA spare parts
3752100060	GLASS-OK W/D	TATA spare parts
3752100090	GLASS HOLDER CHANNEL	TATA spare parts
3752100091	GLASS HOLDER-CHANNEL	TATA spare parts
3752100120	SEAL A-DOOR SECONDARY	TATA spare parts
3752100122	SEAL A-DOOR SECONDARY	TATA spare parts
3752100130	SEAL A-DOOR SECONDARY(RH)	TATA spare parts
3752100132	SEAL A-DOOR SECONDARY	TATA spare parts
3752100230	GLASS-OK W/D	TATA spare parts
3752100240	GLASS-OK W/D	TATA spare parts
3752100360	GLASS-OK W/D	TATA spare parts
3752100440	GLASS DOOR (LH)	TATA spare parts
3752100450	GLASS-DOOR	TATA spare parts
3752110150	GLASS DOOR (LH)	TATA spare parts
3752110154	GLASS-DOOR	TATA spare parts
3752110160	GLASS-DOOR	TATA spare parts
3752110164	GLASS-DOOR	TATA spare parts
3754000040	MOULDING A-QTR WINDOW INR	TATA spare parts
3754000110	W/STRIP-BACK WINDOW	TATA spare parts
3754000115	W/STRIP-BACK WINDOW	TATA spare parts
3754010010	W/STRIP-OK WINDOW	TATA spare parts
3754010015	WEATHERSTRIP-OK WINDOW	TATA spare parts
3754010170	SEAL-OK WINDOW DAM UPR	TATA spare parts
3754010174	SEAL-OK WINDOW DAMPER UPR	TATA spare parts
3754010180	SEAL-OK WINDOW DAMPER UPR(RH)	TATA spare parts
3754010184	SEAL-OK WINDOW DAMPER UPR	TATA spare parts
3754010190	SEAL-MIRROR MTG LWR	TATA spare parts
3754010200	SEAL-MIRROR MTG UPR	TATA spare parts
3754110010	W/STRIP-WINDSHIELD	TATA spare parts
3754110013	W/STRIP-WINDSHIELD	TATA spare parts
3755100080	WEATHERSTRIP A-DOOR OPENING	TATA spare parts
3755100090	W/STRIP A-DOOR OPENING	TATA spare parts
3755843	GASKET TURBOCHARGER	TATA spare parts
3757000130	GROMMET	TATA spare parts
3757000230	SLEEVE	TATA spare parts
3757000240	CAP	TATA spare parts
3761000480	MIRROR A-RR UNDER VIEW	TATA spare parts
3761000490	CLOSE PROXIMITY MIRROR A	TATA spare parts
3761000800	HOUSING CAP	TATA spare parts
3761000920	MIRROR A-REAR VIEW	TATA spare parts
3761000940	MIRROR A-REAR VIEW	TATA spare parts
3761001280	MIRROR A-REAR VIEW	TATA spare parts
3761001290	MIRROR A-REAR VIEW	TATA spare parts
3761300220	END PIECE-STAY COVER	TATA spare parts
3761300640	FRAME A-MIRROR PASSENGER(LH)	TATA spare parts
3761300644	FRAME A-MIR PASS	TATA spare parts

3761300700	FRAME A-MIRROR DRIVER (RH)	TATA spare parts
3761300703	FRAME A-MIR DRIVER	TATA spare parts
3761301160	FRAME A-MIRROR DRIVER RH	TATA spare parts
3761500045	BRACKET-MIRROR SUB STAY A	TATA spare parts
3761500130	BRACKET-MIRROR SUB STAY A	TATA spare parts
3761900071	SEAL-BRKT OUTSIDE MIRROR A	TATA spare parts
3765000070	MIRROR-INSIDE ASM	TATA spare parts
3765000080	STAY-ROOM MIRROR	TATA spare parts
3765000080BK	STAY-ROOM MIRROR	TATA spare parts
3765000090	ROOM MIRROR ASSY.	TATA spare parts
3765000090BK	ROOM MIRROR ASSY.	TATA spare parts
377010901001	ARM PAD	TATA spare parts
377010901002	ASSY BR FOAM - REXINE BLUE	TATA spare parts
377010901003	ASSY S/B FOAM - REXINE BLUE	TATA spare parts
377010901004	ASSY S/B FOAM - REXINE RED	TATA spare parts
377010901005	ASSY BR FOAM - REXINE RED	TATA spare parts
377010901007	COMPRESSOR SHAFT SEAL ASSEMBLY	TATA spare parts
377010901008	SET GASKET COMPRESSOR	TATA spare parts
377010901009	JOINT GASKET	TATA spare parts
377010901010	HEAD GASKET (BOTTOM)	TATA spare parts
377010901011	HOSE GASKET	TATA spare parts
377010901012	HEAD GASKET (TOP)	TATA spare parts
377016003001	EMERGANCY HINGED DOOR ASSY	TATA spare parts
377020003004	BATTERY FLAP ASSY_DIESEL	TATA spare parts
377020084003	BATTERY BOX FLAP	TATA spare parts
377028083002	STRECH PANEL IN REAR SIDE _NEW BTRY SIDE	TATA spare parts
377028183010	SIDEFAME PANELING PLATE 223	TATA spare parts
377042002008	DESTINATION BOARD KIT	TATA spare parts
377042373001	NUMBER PLATE LIGHT ASSY_24V	TATA spare parts
377046283001	FIRE EXTINGUISHER GLASS RUBBER	TATA spare parts
377052002003	DASH BOARD ASSY	TATA spare parts
377054063005	WINDOW GUARD RAIL-LN 1450 MM	TATA spare parts
377061003001	ASSY 2S-460 SIDE WALL MTG LH_A REST	TATA spare parts
377061003002	ASSY 2S-460 SIDE WALL MTG RH_A REST	TATA spare parts
377061003003	ASSY 2S-460SIDE WALL MTG LH_A/R L/B	TATA spare parts
377061003004	ASSY 2S-460SIDE WALL MTG RH_A/R L/B	TATA spare parts
377061003005	ASSY 2S-DICKY MTG RH WITH A/R & S/B	TATA spare parts
377061003006	ASSY 2S DICKY MTG	TATA spare parts
377061003007	ASSY 1S DICKY MTG WITH SEAT BELT	TATA spare parts
377061003008	ASSY 2S -DICKY MTG LH WITH AR SB	TATA spare parts
377061003009	ASSY 2S -460SIDE WALL MTG RH AR	TATA spare parts
377061003010	ASSY 2S -460SIDE WALL MTG RH AR SB	TATA spare parts
377061003011	ASSY 2S -460SIDE WALL MTG LH AR SB	TATA spare parts
377061003012	ASSY 2S DICKY MTG -BLUE SEATS	TATA spare parts
377061003013	ASSY 1S DICKY MTG WITH SB -BLUE	TATA spare parts
377061003014	ASSY 2S -DICKY MTG RH WITH RH AR SB	TATA spare parts
377061003015	ASSY 1S-560 FLOOR MTG AR SB-BLUE	TATA spare parts

377062084001	FIRE EXTINGUISHER COVER(G.I)	TATA spare parts
377062084002	HAMMER SUPPORT PLATE	TATA spare parts
377062233001	FIRE EXTINGUISHER GLASS	TATA spare parts
377062912001	ROOF HATCH WITH EXHAUST FAN ABOVE DRIVER	TATA spare parts
377064003001	LEFT SIDE FRONT WINDOW ASSY-1(1276X1175)	TATA spare parts
377064233001	PASSENGER DOOR UPPER PASTED GLASS	TATA spare parts
377064233002	PASTED WINDOW GLASS-1 (LEFT SIDE)	TATA spare parts
377064233003	PASTED WINDOW GLASS-2 (LEFT SIDE)	TATA spare parts
377064233004	PASTED WINDOW GLASS-3 (LEFT SIDE)	TATA spare parts
377064233005	PASSENGER DOOR UPPER PASTED GLASS	TATA spare parts
377064233006	PASTED WINDOW GLASS-4 (LEFT SIDE)	TATA spare parts
377064233007	PASTED WINDOW GLASS-5 (LEFT SIDE)	TATA spare parts
377064233008	PASTED WINDOW GLASS-6 (LEFT SIDE)	TATA spare parts
377064233009	PASTED WINDOW GLASS-6 (RIGHT SIDE)	TATA spare parts
377064233010	PASTED WINDOW GLASS-5 (RIGHT SIDE)	TATA spare parts
377064233011	PASTED WINDOW GLASS-4 (RIGHT SIDE)	TATA spare parts
377064233012	EMERGENCY DOOR UPPER PASTED GLASS	TATA spare parts
377064233013	PASTED WINDOW GLASS-3 (RIGHT SIDE)	TATA spare parts
377064233014	PASTED WINDOW GLASS-2 (RIGHT SIDE)	TATA spare parts
377064233015	PASTED WINDOW GLASS-1 (RIGHT SIDE)	TATA spare parts
377064233016	DRIVER DOOR UPPER PASTED GLASS	TATA spare parts
377064233017	EMERGENCY DOOR WINDOW PASTED GLASS	TATA spare parts
377064233018	PASTED GLASS (LEFT SIDE)	TATA spare parts
377064233019	PASTED GLASS (RIGHT SIDE)	TATA spare parts
377064303001	END PROFILE	TATA spare parts
37746	DOWEL BUSHING LH	TATA spare parts
3779010050	INSULATION-BACK PANEL CENTER	TATA spare parts
3779010070	INSULATION-BACK PANEL SIDE	TATA spare parts
37800101001	DIALGAUGE 0.01X10LIFT W/O BACKLUG	TATA spare parts
37800300011	PLUNGER DIAL GAUGE 0.1/10MM K05 BAKER	TATA spare parts
3781100190	WIPER LINK AND MOTOR A-C CAB	TATA spare parts
3781100670	DUST-SEAL	TATA spare parts
3781100672	DUST-SEAL	TATA spare parts
3781100840	WIPER LINK A	TATA spare parts
3781100842	WIPER LINK A	TATA spare parts
3781300170	WIPER ARM A-DRIVER C CAB	TATA spare parts
3781300180	WIPER ARM A-ASSIST C CAB	TATA spare parts
3781300210	WIPER ARM A	TATA spare parts
3781300213	WIPER ARM A	TATA spare parts
3781300223	WIPER ARM SUB ASSY.	TATA spare parts
3781400100	WIPER BLADE ASM	TATA spare parts
3781400120	WIPER	TATA spare parts
3781400130	WIPER	TATA spare parts
3781400140	WIPER BLADE A-24INCH_LH	TATA spare parts
3781400150	WIPER BLADE A-24INCH_RH	TATA spare parts
3785000060	HOSE A-WINDSHIELD WASHER	TATA spare parts
3785100030	MOTOR A-WINDSHIELD WASHER TANK	TATA spare parts

3785100031	MOTOR A-WINDSHIELD WASHER TANK	TATA spare parts
3785100050	TANK A-W/S WASHER W/MOTOR	TATA spare parts
3785100120	TANK A-W/S WASHER W/MOTOR	TATA spare parts
3785600203	NOZZLE A-WINDSHIELD WASHER	TATA spare parts
3785800010	CONNECTION A-W/S WASHER HOSE	TATA spare parts
3785800011	CONNECTION A-W/S WASHER HOSE	TATA spare parts
3785900090	MOTOR A-WINDSHIELD WIPER	TATA spare parts
3785900150	WIPER MOTOR	TATA spare parts
3790 7005160	DOOR FRAME PROFILE	TATA spare parts
379000900082	LUMINARY ACRYLIC LAMP COVER	TATA spare parts
379000900084	ABS COVER FOR INVERTERS	TATA spare parts
379000900094	WIPER JET HOSE	TATA spare parts
379000900182	RETRO KIT FOR GEARBOX MAINT COVER MCV BU	TATA spare parts
379001003004	¿FRONT STRUCTURAL_1613_CNG	TATA spare parts
379001084007	WINDSHIELD ROOFSTICK GUSSET - 01	TATA spare parts
379001084008	WINDSHIELD ROOFSTICK GUSSET - 02	TATA spare parts
379001084010	WINDSHIELD ARCH EAION GUSSET	TATA spare parts
379001084011	WINDSHIELD ARCH EAION GUSSET	TATA spare parts
379002004003	REAR BUMPER ANCHORAGE ASSY. KIT	TATA spare parts
379002005001	BUMPER ANCHORAGE ATTACHMENT ASSY.	TATA spare parts
379003004003	FOOT SUPPORT ASSEMBLY	TATA spare parts
379003004124	DOOR STRUCTURE ASSY	TATA spare parts
379003004125	REAR VIEW MIRROR ¿SUPPORT ASSY	TATA spare parts
379003004153	SIDE STRUCTURE R.H_RHD_A PILLAR	TATA spare parts
379003005023	C CHANEL WITH ROLLER	TATA spare parts
379003005024	FRONT DOOR SKIRT	TATA spare parts
379003014312	SIDE STRUCTURE L.H FRONT END PILLAR	TATA spare parts
379003014461	SIDE STRUCTURE L.H_FRONT END PILLAR	TATA spare parts
379003084059	C CHANNEL 25X60X25 LEN 1079MM	TATA spare parts
379004084002	SIDE GUSSET	TATA spare parts
379004084014	WINDOW GUSSET	TATA spare parts
379007014181	TUBE GUSSET FOR ROOF CORNER	TATA spare parts
379010231003	FRONT W/S-SINGLE GLASS CERAMIC SM W/P BS	TATA spare parts
379010901021	VINYL BL CANOPUS TYPE 2MM SHADE 24 SQ.MT	TATA spare parts
379010901024	VINYL CNPS SCBA BL 3MMTHK 24SQMT	TATA spare parts
379010901115	FRONT PANEL COMPLETE (ICU-602)	TATA spare parts
379010901116	MOTHER BOARD (ICU-602)	TATA spare parts
379010901120	FLEX RUBBER PRFL FOR WHEEL ARCH 6MTR	TATA spare parts
379010901123	REAR DOOR GLASS	TATA spare parts
379010901124	FRONT GLASS PANEL	TATA spare parts
379010901171	STEP FINISHING PVC PROF (YELLOW) 6MTR	TATA spare parts
379010901172	ALUMINIUM PROFILE 206 3 MTR	TATA spare parts
379010901178	AIR FILTER - SLAVE ENGINE	TATA spare parts
379010901179	FUEL FILTER - SLAVE ENGINE	TATA spare parts
379010901180	OIL FILTER - SLAVE ENGINE	TATA spare parts
379010901181	V BELT - SLAVE ENGINE	TATA spare parts
379010901360	PVC TUBE O.D 32.5X1.5THK - 3MTRS	TATA spare parts

379010901372	H' PROFILE 6M BS6	TATA spare parts
379010901373	RAIN GUTTER ALUMINIUM PROFILE 6M	TATA spare parts
379010901374	AL.EXTRUSION INSPC LID 6M	TATA spare parts
379010901375	STEPS FINISHING ALU PROFILE 6M BS6	TATA spare parts
379010901376	STEP FINISHING PVC PROFILE (YELLOW) 50M	TATA spare parts
379010901377	SEAT RAIL FINISHING TRIM 6M BS6	TATA spare parts
379010901379	SILVER STICKER (MATCHING RAL 7001) 25M	TATA spare parts
379010901381	AL PROFILE FOR CUTOUT PLYWOOD(19 MM) 3M	TATA spare parts
379010911001	RUBBER FOR CUTOUT SEALED 1.5MTR	TATA spare parts
379012002008	FRONT AND REAR MUD FLAP ASSY(RUBBER)	TATA spare parts
379012003003	RUBBER FLAP ASSY 500X300X6.5 THK	TATA spare parts
379012003009	MUD FLAP CAGE ASSY- FRONT FLAP	TATA spare parts
379012003010	MUD FLAP CAGE ASSY- REAR FLAP	TATA spare parts
379012083007	MUDGUARD ATTACHING PROFILE	TATA spare parts
379012083119	MUDGUARD ATTACHING PROFILE BS6	TATA spare parts
379012303001	MUD FLAP	TATA spare parts
379012303002	SPRAY SUPPRESSION MUD FLAP 600X340 FS	TATA spare parts
379012303003	SPRAY SUPPRESSION MUD FLAP 720X430 RS	TATA spare parts
379012303005	LLDPE MCV MUD FLAP 620X300X4	TATA spare parts
379013003012	SHUTTER UPHOLDING STALK ASSEMBLY	TATA spare parts
379013003018	AIR TANK FLAP ASSEMBLY	TATA spare parts
379013003022	BATTERY BOX FLAP ASSEMBLY	TATA spare parts
379013003032	TOOL BOX ASSEMBLY DETAIL	TATA spare parts
379013003042	BATTERY HOLDING PLATE ASSEMBLY	TATA spare parts
379013003084	TOOL BOX ASSY	TATA spare parts
379013004001	HINGER DOOR JAMP SUPPORT PLATE ASSEMBLY	TATA spare parts
379013004009	BATTERY BOX TROLLY ASSEMBLY	TATA spare parts
379013083001	FLAP LATCH COUPLING	TATA spare parts
379013085001	HINGER DOOR JAMP SUPPORT PLATE	TATA spare parts
379015002006	EMERGENCY DOOR ASSY	TATA spare parts
379015002011	EMERGENCY DOOR ASSY_LHD870	TATA spare parts
379015002014	DRIVER DOOR FINISHING ASSY_LHD870 1582	TATA spare parts
379015003012	DRIVER DOOR LOCK ASSY_RHD870	TATA spare parts
379015003014	EMERGENCY DOOR & LOCK ASSY	TATA spare parts
379015003016	DRIVER DOOR & LOCK ASSY_LHD870*1582	TATA spare parts
379015003018	EMERGENCY DOOR & LOCK ASSY_LHD870	TATA spare parts
379015003019	DRIVER DOOR & LOCK ASSY_RHD970*1582	TATA spare parts
379015003024	DRIVER DOOR & LOCK ASSY	TATA spare parts
379015003032	DRIVER DOOR AND LOCK ASSY.	TATA spare parts
379015003035	DRIVER DOOR & LOCK ASSY RHD870 1582	TATA spare parts
379015003040	DRIVER DOOR LOCK KIT ASSY	TATA spare parts
379015003060	RAILWAY LOCK LATCH ASSEMBLY	TATA spare parts
379015003078	DRIVER DOOR AND LOCK ASSLY RHD	TATA spare parts
379015003093	LIFT DR WITH HINGE & LOCK ASSY 1210X1718	TATA spare parts
379015004026	DRIVER DOOR EXT PANEL ASSY_RHD870*1582 B	TATA spare parts
379015004037	LOCK ASSEMBLY RH	TATA spare parts
379015004038	DRIVER DOOR EXT PANEL ASSY RHD870 1465	TATA spare parts

379015004045	DD EXT PANEL & STR ASSLY_RHD_800X1465	TATA spare parts
379015073004	DRIVER LIMITER SUPPORT	TATA spare parts
379015083010	EMG DOOR INTERNAL PANEL RHD870	TATA spare parts
379015083011	DD INTERNAL PANEL_LHD	TATA spare parts
379015083012	ED INTERNAL PANEL_LHD	TATA spare parts
379015083013	DD INTERNAL PANEL_RHD970*1582	TATA spare parts
379015083014	DD INTERNAL PANEL RHD	TATA spare parts
379015083022	DD INTERNAL PANEL_LHD	TATA spare parts
379015083037	DD INTERNAL PANEL RHD	TATA spare parts
379015083047	DD INTERNAL PANEL RHD 800X1465	TATA spare parts
379015083048	INTERNAL PANEL	TATA spare parts
379015183005	DRIVER DOOR INTERNAL PANEL	TATA spare parts
379015183006	LIFT DR INTERNAL PANEL_ALUMA	TATA spare parts
379015263002	LIMIT SWITCH COVER_LIFT DOOR	TATA spare parts
379015303001	DOOR CATCHER PLASTIC PART	TATA spare parts
379015313001	DOOR CATCHER ALUMINIUM PART	TATA spare parts
379015323001	DRIVER DOOR CANOPY (ABS/PP)	TATA spare parts
379016003002	WINDOW 1500X1078(TOP FIXED& BOTTOMSLID.)	TATA spare parts
379016003006	WINDOW1500X1078(TOP FIXED&BOTTOMSLID.)	TATA spare parts
379016003008	EMERGENCY WINDOW MECHAN. HANDLE KIT	TATA spare parts
379016003009	EMERGENCY WINDOW MECHAN. HANDLE KIT	TATA spare parts
379016003018	WINDOW 1075X1078(TOP FIXED& BOTTOMSLID.)	TATA spare parts
379016003019	WINDOW 1075X1078(TOP FIXED& BOTTOMSLID.)	TATA spare parts
379016003022	WINDOW LH 1376X1056_2/3TS&1/3BF_TIN 50%	TATA spare parts
379016003023	WINDOW LH 1476X1056_2/3TS&1/3BF_TINT 50%	TATA spare parts
379016003024	WINDOW RH 1376X1056_2/3TS&1/3BF_TINT 50%	TATA spare parts
379016003026	WINDOW RH_1476X1056_1/3TS2/3BF_T50%_100	TATA spare parts
379016003029	WINDOW LH_1476X1056_1/3TS2/3BF_T50%_100	TATA spare parts
379016003030	WINDOW LH_1376X1056_1/3TS2/3BF_T50%_100	TATA spare parts
379016003031	WINDOW_L.H_1350X1078_H.S_TOP FIXED	TATA spare parts
379016003032	WINDOW_L.H_1290X1078_H.S_TOP FIXED	TATA spare parts
379016003033	WINDOW_R.H_1300X1078_H.S_TOP FIXED	TATA spare parts
379016003034	WINDOW_RH_1300X1078_VERTICAL SLIDING	TATA spare parts
379016003035	WINDOW_RH_1500X1078_VERTICAL SLIDING	TATA spare parts
379016003036	WINDOW_RH_1075X1078_VERTICAL SLIDING	TATA spare parts
379016003037	WINDOW_LH_700X1078_VERTICAL SLIDING	TATA spare parts
379016003038	WINDOW_LH_445X1078_VERTICAL SLIDING	TATA spare parts
379016003039	WINDOW_LH_1500X1078_VERTICAL SLIDING	TATA spare parts
379016003040	WINDOW_LH_1350X1078_VERTICAL SLIDING	TATA spare parts
379016003041	WINDOW_LH_870X1078_VERTICAL SLIDING	TATA spare parts
379016003042	DRIVER WINDOW_RH_820X813_SLIDING_OPENA	TATA spare parts
379016003043	PEEP WINDOW 326X426_RUBBER MOUNT_TN M	TATA spare parts
379016003044	WINDOW RH 1106X1056_TF BS_550 CV_TINTED	TATA spare parts
379016003045	WINDOW RH SLID	TATA spare parts
379016003046	WINDOW RH 656X1056_TF BS_550 CV_TINTED	TATA spare parts
379016003048	DRIVER WINDOW_LHD_706X789_SLIDING_CLEAR	TATA spare parts
379016003049	WINDOW LH SLID	TATA spare parts

379016003053	WINDOW RH 1376X1056_TF BS_550 CV _TINTED	TATA spare parts
379016003054	WINDOW RH 1476X1056_TF BS_550 CV _TINTED	TATA spare parts
379016003055	WINDOW LH 1376X1056_TF BS_550 CV _TINTED	TATA spare parts
379016003056	WINDOW LH 1476X1056_TF BS_550 CV _TINTED	TATA spare parts
379016003064	WINDOW LH SLIDING	TATA spare parts
379016003065	WINDOW LH SLIDIN	TATA spare parts
379016003066	WINDOW LH SLIDING	TATA spare parts
379016003067	WINDOW RH SLIDIN	TATA spare parts
379016003068	WINDOW RH SLIDIN	TATA spare parts
379016003069	WINDOW RH SLIDING	TATA spare parts
379016003070	DRIVER WINDOW_RH_SLIDING_OPENABL	TATA spare parts
379016003071	DRI. DOOR SL WINDOW_LCV PROFILE	TATA spare parts
379016003072	WINDOW RH 1476X1056_2/3TS&1/3BF_TINT 50%	TATA spare parts
379016003073	WINDOW RH 1106X1056_2/3TS&1/3BF_TINT 50%	TATA spare parts
379016003074	WINDOW RH 656X1056_2/3TS&1/3BF_TINT 50%	TATA spare parts
379016003075	DRIVER DOOR WINDOW LHD_813X709_SLI_CLEA	TATA spare parts
379016003076	WINDOW RH SLIDIN	TATA spare parts
379016003077	EMERGENCY DOOR WINDOW_RHS_706X789	TATA spare parts
379016003078	WINDOW RH_1376X1056_1/3TS2/3BF_T50%_10	TATA spare parts
379016003080	EME DOOR WINDOW_LHD_706X789_SLI_TINT 50	TATA spare parts
379016003082	DRIVER WINDOW_RHD_806X789_SLID&OPEN_CL	TATA spare parts
379016003083	WINDOW RH_1276X1056_1/3TS&2/3BF_TINT 50	TATA spare parts
379016003084	WINDOW RH_1476X1056_1/3TS&2/3BF_TINT 50	TATA spare parts
379016003085	WINDOW RH_1051X1056_1/3TS&2/3BF_TINT 50	TATA spare parts
379016003086	WINDOW LH_1051X1056_1/3TS&2/3BF_TINT 50%	TATA spare parts
379016003087	WINDOW LH_1476X1056_1/3TS&2/3BF_TINT 50%	TATA spare parts
379016003088	WINDOW LH_1376X1056_1/3TS&2/3BF_TINT 50%	TATA spare parts
379016003092	WINDOW LH_716X1056_1/3TS2/3BF_T50%_100	TATA spare parts
379016003093	WINDOW LH_1216X1056_1/3TS2/3BF_T50%_100	TATA spare parts
379016003094	WINDOW RH_1376X1056_1/3TS&2/3BF_TINT 30	TATA spare parts
379016003095	WINDOW RH_1476X1056_1/3TS&2/3BF_TINT 30	TATA spare parts
379016003096	WINDOW RH_1656X1056_1/3TS&2/3BF_TINT 30	TATA spare parts
379016003097	WINDOW LH_716X1056_1/3TS&2/3BF_TINT 30%	TATA spare parts
379016003098	EME DOOR WINDOW_LHD_706X789_SLI_TINT 30	TATA spare parts
379016003099	WINDOW LH_1376X1056_1/3TS&2/3BF_TINT 30%	TATA spare parts
379016003100	WINDOW LH_1476X1056_1/3TS&2/3BF_TINT 30%	TATA spare parts
379016003108	WINDOW RH 1376X1056	TATA spare parts
379016003109	WINDOW RH 1476X1056	TATA spare parts
379016003110	WINDOW RH 841X1056 1/3TF&2/3BS TINT 50	TATA spare parts
379016003111	EMERGENCY DOOR WINDOW 706X789	TATA spare parts
379016003112	WINDOW RH 716X1056 1/3TF&2/3BS TINT 50	TATA spare parts
379016003113	WINDOW LH 1051X1056 1/3TF&2/3BS TINT 50	TATA spare parts
379016003114	WINDOW LH 1476X1056	TATA spare parts
379016003115	WINDOW LH 1376X1056 1/3TF&2/3BS TINT 50	TATA spare parts
379016003118	EME DOOR WINDOW_RHD_706X789_SLI_CLEAR	TATA spare parts
379016003124	WINDOW RH 1376X1056	TATA spare parts
379016003125	WINDOW RH 1476X1056	TATA spare parts



379016003128	WINDOW LH 1476X1056	TATA spare parts
379016003129	WINDOW LH 1376X1056	TATA spare parts
379016003130	WINDOW RH 1376X1056 1/3TF&2/3BS 50% GREY	TATA spare parts
379016003131	WINDOW RH 1476X1056 1/3TF&2/3BS 50% GREY	TATA spare parts
379016003132	WINDOW RH 1166X1056 1/3TF&2/3BS 50% GREY	TATA spare parts
379016003133	EME DOOR WINDOW RH 706X789 SLI 50%GREY	TATA spare parts
379016003134	WINDOW RH 716X1056 1/3TF&2/3BS 50% GREY	TATA spare parts
379016003135	WINDOW LH 1376X1056 1/3TF&2/3BS 50% GREY	TATA spare parts
379016003136	WINDOW LH 1476X1056 1/3TF&2/3BS 50% GREY	TATA spare parts
379016003137	WINDOW LH 631X1056 1/3TF&2/3BS 50% GREY	TATA spare parts
379016003138	WINDOW LH 1081X1056 1/3TF&2/3BS 50% GREY	TATA spare parts
379016003139	WINDOW LH 946X1056R 1/3TF&2/3BS 50% GREY	TATA spare parts
379016003150	WINDOW RH 740X1080_1/3TF&2/3BS_CLEAR	TATA spare parts
379016003151	WINDOW LH 656X1056_1/3TF&2/3BS_CLEAR	TATA spare parts
379016003153	WINDOW RH 1166X1056_1/3TF&2/3BS_CLEAR	TATA spare parts
379016003154	WINDOW LH 1106X1056_1/3TF&2/3BS_CLEAR	TATA spare parts
379016003165	WINDOW RH 1156X1056_2/3TS&1/3BF_LGT 50%	TATA spare parts
379016003166	WINDOW LH FIX 336X1056_RUBBER MOUNT_DP	TATA spare parts
379016003172	WINDOW RH (PEEP)_313X402_SLIDING	TATA spare parts
379016003173	DRIVER WIN RHD 706X789 SLI&OPEN CLEAR LC	TATA spare parts
379016003181	WINDOW LH FIX 352X798_RUBBER MOUNT	TATA spare parts
379016003182	PEEP WINDOW 370X475_FIXED_CLEAR	TATA spare parts
379016003185	DRI. DOOR WINDOW_824X807	TATA spare parts
379016003204	EMERGENCY DOOR & LOCK ASSY_RHD	TATA spare parts
379016003213	WIN RH 1276X1056_1/3TF_50PERC GT&2/3BS_3	TATA spare parts
379016003214	WIN RH 1476X1056_1/3TF_50PERC GT&2/3BS_3	TATA spare parts
379016003215	WIN LH 1476X1056_1/3TF_50PERC GT&2/3BS_3	TATA spare parts
379016003216	WIN LH 856X1056_1/3TF_50PERC GT&2/3BS_30	TATA spare parts
379016003217	WIN LH 666X1056_1/3TF_50PERC GT&2/3BS_30	TATA spare parts
379016003218	WIN LH 871X1056_1/3TF_50PERC GT&2/3BS_30	TATA spare parts
379016003219	WIN FIXED 282X801_RUB MTG_CLEAR	TATA spare parts
379016003220	WIN FIXED 282X692_RUB MTG_CLEAR	TATA spare parts
379016003227	WINDOW RH 1276X1056	TATA spare parts
379016003229	PEEP WIN 326X426 RUBBER MOUNT CLR 4MMTH	TATA spare parts
379016003231	WIN RH 1301X1078 TF BS 550 CV CLEAR 4MMT	TATA spare parts
379016003232	WIN RH 1500X1078 TF BS 550 CV CLR 4MMTHK	TATA spare parts
379016003233	WIN LH 1500X1078 TF BS 550 CV CLR 4MMTHK	TATA spare parts
379016003234	WIN LH 1301X1078 TF BS 550 CV CLR 4MMTHK	TATA spare parts
379016003236	WIN LH 931X1078 TF BS 550 CV CLR 4MMTHK	TATA spare parts
379016003241	EME DOOR WINDOW RHD 706X789 SLI CLEAR	TATA spare parts
379016003242	WIN RH 739X1078 TF BS 550 CV CLR 4MMTHK	TATA spare parts
379016003245	WIN RH 1400X1078 TF BS 550 CV CLR 4MMTHK	TATA spare parts
379016003246	WIN LH 1400X1078 TF BS 550 CV CLR 4MMTHK	TATA spare parts
379016003247	WIN RH 1500X1078 TF BS 550CV 50PERCNT 4	TATA spare parts
379016003248	WIN LH 1500X1078 TF BS 550CV 50PERCNT 4	TATA spare parts
379016003249	WIN RH 1400X1078 TF BS 550CV 50PERCNT 4	TATA spare parts
379016003250	WIN LH 1400X1078 TF BS 550CV 50PERCNT 4	TATA spare parts

379016003251	WINDOW LH (PEEP)_313X402_SLIDING	TATA spare parts
379016003252	DRI. DOOR WINDOW 725X808 LHD	TATA spare parts
379016003255	WIN_RH_927X1078_TFBS_550CV_CLR_4MMTHK	TATA spare parts
379016003256	WIN RH 1301X1078 TFBS 550CV CLR 4MM SC	TATA spare parts
379016003264	WIN LH 852X1078 TF BS 550 CV CLR 4MM SC	TATA spare parts
379016003265	WIN LH 931X1078 TF BS 550 CV CLR 4MM SC	TATA spare parts
379016003266	EME DOOR WINDOW RHD 706X789 SLI CLEAR SC	TATA spare parts
379016003268	WIN RH_1376X1056_1/3TS2/3BF_T30 PERC_10C	TATA spare parts
379016003269	WIN RH_1476X1056_1/3TS2/3BF_T30 PERC_10C	TATA spare parts
379016003270	WIN RH_1476X1056_FIXED GLS_T30	TATA spare parts
379016003271	WIN LH_716X1056_1/3TS2/3BF_T30 PERC_10CM	TATA spare parts
379016003272	E DOOR WIN_LHD_706X789_FIX GLS_TINT 30 P	TATA spare parts
379016003273	WIN LH_1216X1056_1/3TS2/3BF_T30 PERC_10C	TATA spare parts
379016003274	WIN LH_1476X1056_1/3TS2/3BF_30 PERC_10CM	TATA spare parts
379016003275	WIN LH_1376X1056_1/3TS2/3BF_30 PERC_10CM	TATA spare parts
379016003293	WIN RH 941X1056 40PERCTF&60PERCBS CLEAR	TATA spare parts
379016003294	WIN LH 1430X1056 40PERCTF&60PERCBS CLEAR	TATA spare parts
379016003301	WINDOW FIXD 314X795MM CLEAR RUBBER MNT	TATA spare parts
379016003309	FIX AL PROFILE WINDOW_321X680_5MMTHK	TATA spare parts
379016003341	WINDOW RH_740X1055_CLEAR_EPDM BS6	TATA spare parts
379016003342	WIN RH 1070X1078 TF BS 550 CV CLR 4MMTHK	TATA spare parts
379016003353	WIN LH 1130X1078 TF BS 550 CV CLR 4MMTHK	TATA spare parts
379016003354	WIN LH 680X1078 TF BS 550 CV CLR 4MMTHK	TATA spare parts
379016003358	WINDOW LH FIX 336X1056	TATA spare parts
379016003362	WINDOW LH 856X1056	TATA spare parts
379016003363	WINDOW LH 856X1056	TATA spare parts
379016003364	WINDOW LH 871X1056	TATA spare parts
379016003365	WIN_RH_1400X1078_TFBS_550 CV_CLR_4MM_S	TATA spare parts
379016003366	WIN_LH_1400X1078_TFBS_550 CV_CLR_4MM_S	TATA spare parts
379016003367	WIN_LH_666X1056_TF_VRS_CV_CLR_4MM_SC	TATA spare parts
379016003371	DRIVER WIN RHD 706X789 VRSL CLEAR LC	TATA spare parts
379016003372	WIN RH 595X1056 TF BS 550 CV CLR 4MM SC	TATA spare parts
379016003373	WIN LH 505X1056 TF VRS CV CLR 4MM SC	TATA spare parts
379016003374	WIN LH 720X1056 TF BS 550 CV CLR 4MM SC	TATA spare parts
379016003375	WIN LH 1276X1056 TF BS 550 CV CLR 4MM SC	TATA spare parts
379016003376	WIN LH 763X1056 TF BS 550 CV CLR 4MM SC	TATA spare parts
379016003378	WIN RH 595X1056 TF VRS CV CLR 4MM SC	TATA spare parts
379016003380	RH3SEAT 446CH SM2NL CVG HB AR 1250W	TATA spare parts
379016003382	WIN_RH_715X1056_TF_VRS_CV_CLR_4MM_SC	TATA spare parts
379016003440	DRIVER WIN RHD 636X789 SLDNG 4MM CLEAR	TATA spare parts
379016003442	WIN RH 561X1078 TF VRS CV CLR	TATA spare parts
379016003443	WINDOW FIXD 258X795MM CLEAR RUBBER MNT	TATA spare parts
379016003456	PEEP WINDOW 345X600_FIXED_CLEAR	TATA spare parts
379016003458	WIN LH 599X1056 40TF 60BS CLR 4MM	TATA spare parts
379016003461	WINDOW_1ST RHS_1116X1056_30PERC_GRN	TATA spare parts
379016003462	WINDOW_5TH RHS_926X1056_30PERC_GRN	TATA spare parts
379016003463	WINDOW_6TH RHS_770X1056_30PERC_GRN	TATA spare parts

379016003464	WINDOW_7TH RHS_1166X1056_30PERC_GRN	TATA spare parts
379016003465	WINDOW_3RD & 4TH LHS_1166X1056_30PERC_	TATA spare parts
379016003466	WINDOW_1ST LHS_930X1056_30PERC_GRN	TATA spare parts
379016003467	WIN_RH_1070X1078_1/3TF 2/3BS_CLR	TATA spare parts
379016003484	PEEP LH FIX WINDOW_362X513_CLEAR	TATA spare parts
379016003556	WINDOW LH_1146X1055_CLEAR_EPDM BS6	TATA spare parts
379016003559	WINDOW LH_861X1055_CLEAR_EPDM BS6	TATA spare parts
379016003564	TOP FIX BOTTOM VERTICAL SLIDING WINDOW B	TATA spare parts
379016004009	MCV_LOCK ASSY	TATA spare parts
379016004032	LOCK ASSY SPACER BS6	TATA spare parts
379016083004	ED INTERNAL PANEL RHD	TATA spare parts
379016083012	EME INTERNAL PANEL	TATA spare parts
379016084004	EMER.EXIT WINDOW MECHANISM UPPER BEARIN	TATA spare parts
379016084005	EMER.EXIT WINDOW MECHANISM LOWER BEARI	TATA spare parts
379016183009	EMG DOOR INT PANEL_ALUMA_870X1667	TATA spare parts
379016233040	PASTED GLASS LH_530X880_CLEAR_FE	TATA spare parts
379016233041	PASTED GLASS LH_516X307X267_CLEAR_FE	TATA spare parts
379016233042	PASTED GLASS LH_864X394_CLEAR_FE	TATA spare parts
379016233043	PASTED GLASS LH_1046X1155_50%GREY_FE	TATA spare parts
379016233046	PASTED GLASS 1552X1155 50PERCGREY FE	TATA spare parts
379016233047	PASTED GLASS LH_1151X1155_50%GREY_FE	TATA spare parts
379016233048	PASTED GLASS RH_1151X1155_50%GREY_FE	TATA spare parts
379016233049	PASTED GLASS RH_1461X1155_50%GREY_FE	TATA spare parts
379016233050	PASTED GLASS RH_243X767X971_CLEAR_FE	TATA spare parts
379016233054	PASTED GLASS_RH_870X240_CLR	TATA spare parts
379016233071	PASTED GLASS LH_530X880_CLEAR_FE_6MMTHK	TATA spare parts
379016233072	PASTED GLS LH_516X307X267_CLR_FE_6MMTHK	TATA spare parts
379016233073	PASTED GLASS LH_864X394_CLR_FE_6MMTHK	TATA spare parts
379016233074	PSTED GLS LH_1046X1155_50%GREY_FE_6MMTH	TATA spare parts
379016233075	PSTED GLS_1552X1155_50%GREY_FE_6MMTHK	TATA spare parts
379016233076	PSTED GLS LH_1151X1155_50%GREY_FE_6MMTH	TATA spare parts
379016233077	PSTED GLS RH_1151X1155_50%GREY_FE_6MMTH	TATA spare parts
379016233078	PSTED GLS RH_1461X1155_50%GREY_FE_6MMTH	TATA spare parts
379016233079	PSTED GLS RH_243X767X971_CLEAR_FE_6MMTH	TATA spare parts
379016233081	TOP PASTED GLASS 879X369 CLEAR	TATA spare parts
379016233082	PASTED GLASS 1560X1155 50PERC GREY	TATA spare parts
379016233083	PASTED GLASS 1820X1155 50PERC GREY	TATA spare parts
379016233084	TOP PASTED GLASS 869X246 CLEAR	TATA spare parts
379016233085	PASTED GLASS 1561X1155 50PERC GREY	TATA spare parts
379016233086	PASTED GLASS 1820X1155 50PERC GREY	TATA spare parts
379016233105	PASTED GLASS LH_425X871_CLEAR_FE	TATA spare parts
379016233107	PASTED GLASS_LH-1151X1155_50PERC GREY	TATA spare parts
379016233108	PASTED GLASS_LH-1552X1155_50PERC GREY	TATA spare parts
379016233109	PASTED GLASS_LH-1552X1155_50PERC GREY	TATA spare parts
379016233110	PASTED GLASS_LH-1307X1155_50PERC GREY	TATA spare parts
379016233111	PASTED GLASS_LH-1007X1155_50PERC GREY	TATA spare parts
379016233112	PASTED GLASS_LH-1035X1155_50PERC GREY	TATA spare parts

379016233113	PASTED GLASS_RH-1336X1155_50PERC GREY	TATA spare parts
379016233114	PASTED GLASS_RH_864X369_CLR	TATA spare parts
379016233115	PASTED GLASS_RH-1150X1155_50PERC GREY	TATA spare parts
379016233249	PASTED GLASS_RH ABV.DR DOOR_230X805_CLR	TATA spare parts
379016233250	PASTED GLS RH_1681X1155_50PERCGREY TIN_E	TATA spare parts
379016233251	PASTED GLS RH_1130X1155_50PERCGRY TNT_EL	TATA spare parts
379016233252	PASTED GLS_VENT RH_1370X1155_50PERCGREY	TATA spare parts
379016233255	PASTED GLS_RH_863X235_CLR_ELEC	TATA spare parts
379016233256	ED PAS GLS RH_856X910_50PERC GREY TINT_E	TATA spare parts
379016233260	PASTED GLS LH_1515X1155_50PERC GREY TNT_	TATA spare parts
379016233261	PASTED GLASS LH_389X1155_CLEAR	TATA spare parts
379016233262	PASTED GLS LH_1030X1155_50PERC GREY TNT_	TATA spare parts
379016233263	PASTED GLS LH_1225X1155_50PERC GREY TNT_	TATA spare parts
379016233264	PASTED GLASS LH_305X1155_CLEAR	TATA spare parts
379016233266	PASTED GLASS LH_495X898_CUTOUT_CLR_ELE	TATA spare parts
379016233267	PASTED GLASS ABV.PAS DOOR_1370X368_CLR	TATA spare parts
379016233268	PASTED GLASS RH_415X889_CUTOUT_CLR_ELE	TATA spare parts
379016233269	PASTED GLASS_LH_860X378_CLR_ELE	TATA spare parts
379016233271	PASTED GLS_VENT LH_1130X1155_50PERC GREY	TATA spare parts
379016233272	PAS GLS_RH_1543X1155)_50PERC GREY TINT	TATA spare parts
379016233274	PAS GLS_LH/RH_VENT_1420X1155_50PERC GREY	TATA spare parts
379016233276	PASTED GLASS_LH_1543X1155_50PERCGREY TNT	TATA spare parts
379016233277	PASTED GLS_RH_853X1155_50PERCGRAY TINT	TATA spare parts
379016233278	PASTED GLASS_RH_1220X1155_50PERCGRAY TIN	TATA spare parts
379016233279	TOP PASTED GLS RH_5X247X261_CLR_ELE_MCV	TATA spare parts
379016233280	TOP PASTED GLS LH_5X247X350_CLR_ELE_MCV	TATA spare parts
379016234008	FIXED GLASS_1476X430MM_1500MM WINDOW	TATA spare parts
379016234009	SLIDING GLASS_734X590MM_1500MM WINDOW	TATA spare parts
379016234010	FIXED GLASS_1326X430MM_1350MM WINDOW	TATA spare parts
379016234011	SLIDING GLASS_659X590MM_1350MM WINDOW	TATA spare parts
379016234012	FIXED GLASS_1276X430MM_1300MM WINDOW	TATA spare parts
379016234013	FIXED GLASS_1266X430MM_1290MM WINDOW	TATA spare parts
379016234014	SLIDING GLASS_634X590MM_1300/1290MM WIND	TATA spare parts
379016234015	FIXED GLASS_1051X430MM_1075MM WINDOW	TATA spare parts
379016234016	SLIDING GLASS_552X590MM_1075MM WINDOW	TATA spare parts
379016234017	FIXED GLASS_366X722MM_DRIVER DOOR WINDO	TATA spare parts
379016234018	SLIDING GLASS_394X751MM_DRIVER DOOR WIN	TATA spare parts
379016234036	FRONT SLIDING GLASS_RH_292X210	TATA spare parts
379016234037	REAR FIXED GLASS_RH_292X210	TATA spare parts
379016234107	GLAS_1476X1056_30PERC TNT_EPDM TYPE FIX	TATA spare parts
379016234108	GLAS_706X789_30PERC TNT_EPDM TYPE FIX WI	TATA spare parts
379016234116	FIXED GLASS_30PERC GREN TINT_1476X687	TATA spare parts
379016234117	FIXED GLASS_30PERC GREN TINT_1376X687	TATA spare parts
379016234118	FIXED GLASS_30PERC GREN TINT_716X687	TATA spare parts
379016234119	FIXED GLASS_30PERC GREN TINT_1216X687	TATA spare parts
379016234120	FS GLAS FOR LH & RRS GLAS FOR RH 734X339	TATA spare parts
379016234121	FS GLAS FOR LH & RRS GLAS FOR RH 684X339	TATA spare parts

379016234122	FS GLAS FOR LH & RRS GLAS FOR RH 354X339	TATA spare parts
379016234123	FS GLAS FOR LH & RRS GLAS FOR RH 604X339	TATA spare parts
379016234124	RRS GLAS FOR LH & FS GLAS FOR RH 734X339	TATA spare parts
379016234125	RRS GLAS FOR LH & FS GLAS FOR RH 684X339	TATA spare parts
379016234126	RRS GLAS FOR LH & FS GLAS FOR RH 354X339	TATA spare parts
379016234127	RRS GLAS FOR LH & FS GLAS FOR RH 604X339	TATA spare parts
379016234128	FS GLAS FOR LH & RRS GLAS FOR RH 730X813	TATA spare parts
379016234129	RRS GLAS FOR LH & FS GLAS FOR RH 730X813	TATA spare parts
379016234154	SIDE WINDOW GLASS_282X801	TATA spare parts
379016234158	DRIVER DOOR WINDOW GLASSES	TATA spare parts
379016234159	DRIVER DOOR WINDOW GLASSES	TATA spare parts
379016234202	WINDOW GLASSES(LH)294X627 TYPE C	TATA spare parts
379016234203	WINDOW GLASSES(LH)294X627 TYPE B	TATA spare parts
379016234204	WINDOW GLASSES(LH)595X398 TYPE A	TATA spare parts
379016234205	WINDOW GLASSES(LH)356X627 TYPE C	TATA spare parts
379016234206	WINDOW GLASSES(LH)356X627 TYPE B	TATA spare parts
379016234207	WINDOW GLASSES(LH)720X398 TYPE A	TATA spare parts
379016234208	WINDOW GLASSES(LH)378X627 TYPE C	TATA spare parts
379016234209	WINDOW GLASSES(LH)378X627 TYPE B	TATA spare parts
379016234210	WINDOW GLASSES(LH)763X398 TYPE A	TATA spare parts
379016234211	WINDOW GLASSES(LH)410X627 TYPE C	TATA spare parts
379016234212	WINDOW GLASSES(LH)410X627 TYPE B	TATA spare parts
379016234213	WINDOW GLASSES(LH)828X398 TYPE A	TATA spare parts
379016234214	WINDOW GLASSES(RH)448X627	TATA spare parts
379016234215	WINDOW GLASSES(RH)448X627	TATA spare parts
379016234216	WINDOW GLASSES(RH)903X398	TATA spare parts
379016234217	WINDOW GLASSES(RH/LH)634X627 TYPE C	TATA spare parts
379016234218	WINDOW GLASSES(RH/LH)634X627 TYPE B	TATA spare parts
379016234219	WINDOW GLASSES(RH/LH)1276X398 TYPE A	TATA spare parts
379016234220	WINDOW GLASSES(RH/LH)684X627	TATA spare parts
379016234221	WINDOW GLASSES(RH/LH)684X627	TATA spare parts
379016234222	WINDOW GLASSES(RH/LH)1376X398	TATA spare parts
379016234223	CO DRIVER WINDOW FLAT SLIDING GLASS	TATA spare parts
379016234224	CO-DRIVER WINDOW FLAT SLIDING GLASSES	TATA spare parts
379016234226	EMG.WDW SLIDING GLASSES AP730X813	TATA spare parts
379016234227	EMG.WDW SLIDING GLASSES AP730X813	TATA spare parts
379016234230	TWOWAY UPLIFT WDW AP529X1080 TYPEB	TATA spare parts
379016234231	TWOWAY UPLIFT WDW AP529X1080 TYPEA	TATA spare parts
379016234232	TWOWAY UL WDW GLASSES AP619X1080 TYPEB	TATA spare parts
379016234233	TWOWAY UL WDW GLASSES AP619X1080 TYPEA	TATA spare parts
379016234236	TWO WAY WINDOW GLASSES AP739X1080	TATA spare parts
379016234237	TWO-WAY UL WINDOW GLASSES 739X1080	TATA spare parts
379016234238	TWOWAY UL WDW GLASSES AP730X813 TYPEB	TATA spare parts
379016234239	TWOWAY UL WDW GLASSES AP730X813 TYPEA	TATA spare parts
379016234240	SIDE WINDOW GLASS_336X1056 GREEN 70PERC	TATA spare parts
379016234241	SIDE WINDOW GLASS_282X692	TATA spare parts
379016234242	WIN GLS RR.SL RH_F.SL LH_70PERC GLT_734X	TATA spare parts

379016234243	WIN GLS RR.SL RH_F.SL LH_70PERC GLT_734X	TATA spare parts
379016234244	TOP FIXED GLASS_50PERC GRN_1476X338	TATA spare parts
379016234245	WIN GLS RR.SL RH_F.SL LH_70PERC GLT_634X	TATA spare parts
379016234246	WIN GLS RR.SL RH_F.SL LH_70PERC GLT_634X	TATA spare parts
379016234247	TOP FIXED GLASS_50PERC GRN_1276X338	TATA spare parts
379016234248	WIN GLS RR.SL RH_F.SL LH_70PERC GLT_329X	TATA spare parts
379016234249	WIN GLS RR.SL RH_F.SL LH_70PERC GLT_329X	TATA spare parts
379016234250	TOP FIXED GLASS_50PERC GRN_666X338	TATA spare parts
379016234251	WIN GLS RR.SL RH_F.SL LH_70PERC GLT_432X	TATA spare parts
379016234252	WIN GLS RR.SL RH_F.SL LH_70PERC GLT_432X	TATA spare parts
379016234253	TOP FIXED GLASS_50PERC GRN_871X338	TATA spare parts
379016234254	WIN GLS RR.SL RH_F.SL LH_70PERC GLT_424X	TATA spare parts
379016234255	WIN GLS RR.SL RH_F.SL LH_70PERC GLT_424X	TATA spare parts
379016234256	TOP FIXED GLASS_50PERC GRN_856X338	TATA spare parts
379016234258	RH RR SLD CLEAR GLAS 364X752 TYPE A NMMT	TATA spare parts
379016234259	RH FR TILTITG CLR GLS 347X748 TYP B NMMT	TATA spare parts
379016234260	WINDOW GLASSES(LH/RH)1476X398 TYPE A	TATA spare parts
379016234261	WINDOW GLASSES(LH/RH)734X627 TYPE B	TATA spare parts
379016234262	WINDOW GLASSES(LH/RH)734X627 TYPE C	TATA spare parts
379016234263	WINDOW GLASSES(LH/RH)1376X398 TYPE A	TATA spare parts
379016234264	WINDOW GLASSES(LH/RH)684X627 TYPE B	TATA spare parts
379016234265	WINDOW GLASSES(LH/RH)684X627 TYPE C	TATA spare parts
379016234266	WINDOW GLASSES(LH)1106X398 TYPE A	TATA spare parts
379016234267	WINDOW GLASSES(LH)549X627 TYPE B	TATA spare parts
379016234268	WINDOW GLASSES(LH)549X627 TYPE C	TATA spare parts
379016234269	WINDOW GLASSES(LH)656X398 TYPE A	TATA spare parts
379016234270	WINDOW GLASSES(LH)324X627 TYPE B	TATA spare parts
379016234271	WINDOW GLASSES(LH)324X627 TYPE C	TATA spare parts
379016234272	FIXED WINDOW GLASS_316X795	TATA spare parts
379016234334	LH_PEEP WIND GLASS_EX_4THK_CLR	TATA spare parts
379016284011	RUB_1476X1056_EPDM TYPE FIX WIN PER-4725	TATA spare parts
379016284013	RUBBER 1106X1056 EPDM TYPE FIX WINDOW	TATA spare parts
379016284015	RH FIRST WINDOW RUBBER	TATA spare parts
379016284018	EMERGENCY DOOR WINDOW RUBBER	TATA spare parts
379016284019	WINDOW ( BEHIND FRONT PASSENGER DOOR ) R	TATA spare parts
379016284020	WINDOW ( BEFORE REAR PASSENGER DOOR ) RU	TATA spare parts
379016284021	WINDOW (BEHIND EMERGENCY DOOR) RUBBER	TATA spare parts
379016284031	RUBBER PROFILE_PERI-2126MM_EPDM	TATA spare parts
379016284033	RUBBER_806X789_EPDM WINDOW	TATA spare parts
379016284035	RUBBER PROFILE 927X1080	TATA spare parts
379016284036	RUBBER PROFILE_1300X1080_EPDM_PERI4325	TATA spare parts
379016284037	RUBBER PROFILE 1376X1056 EPDM PERI4525	TATA spare parts
379016284038	RUBBER PROFILE 730X813 EPDM PERI2695	TATA spare parts
379016284039	R.PROFILE 852/499/931X1080 EPDM PERI3440	TATA spare parts
379016284040	RUBBER PROFILE_690X1080_EPDM_PERI3140	TATA spare parts
379016284041	RUBBER PROFILE 739X1080	TATA spare parts
379016284042	RUBBER PROFILE 619X1080 EPDM PERI3000	TATA spare parts

379016284043	RUBBER PROFILE 787X1080 EPDM PERI3335	TATA spare parts
379016284044	RUBBER PROFILE 744X1080 EPDM PERI3250	TATA spare parts
379016284045	RUBBER PROFILE 529X1080 EPDM PERI2830	TATA spare parts
379016284046	RUBBER PROFILE_PERI 2495MM_EPDM	TATA spare parts
379016284047	RUBBER PROFILE_PERI.1909MM_EPDM	TATA spare parts
379016284048	RUBBER_880X1080_EPDM TYP FIX WIN-PER3495	TATA spare parts
379016284049	RUBBER_895X1080_EPDM TYP FIX WIN-PER3520	TATA spare parts
379016284050	RUBBER PROFILE 656X1056 EPDM PERI3130	TATA spare parts
379016303001	EMERGENCY MECHANISM FINISH	TATA spare parts
379016303002	EMERGENCY MECHANISM FINISH	TATA spare parts
379017003018	JK PASSENGER DOOR 1210X1983 APERTURE	TATA spare parts
379017003019	920 & 1420 PNEUMATIC KIT	TATA spare parts
379017003020	1210+1210 PNEUMATIC KIT	TATA spare parts
379017003021	920 PASSENGER DOOR WITH SENSITIVITY	TATA spare parts
379017003022	1420 PASSENGER DOOR WITH SENSITIVITY	TATA spare parts
379017003039	PNEUMATIC MECHANISM_SD	TATA spare parts
379017003040	870X2003 DOOR WITH SENSITIVITY	TATA spare parts
379017003041	1210X1983 DOOR WITH SENSITIVITY	TATA spare parts
379017003042	1210 X 1950 DOORS WITH SENSITIVITY	TATA spare parts
379017003043	870_1210_1210&1210 PNEUMATIC KIT	TATA spare parts
379017003049	PNEUMATIC KIT COVER_870_LHD_ISD	TATA spare parts
379017003054	FRONT PASSENGER DOOR ASSY	TATA spare parts
379017003055	PNEUMATIC MECHANISM SD	TATA spare parts
379017003056	DOOR ASSY	TATA spare parts
379017003059	JK DOOR	TATA spare parts
379017003073	FRONT PASSENGER DOOR ASSEMBLY	TATA spare parts
379017003074	PARTATION DOOR ASSLY	TATA spare parts
379017003102	PASSENGER DOOR MITECH 2255 ( COMPLETE SE	TATA spare parts
379017003145	PASSENGER DOOR (720 X 2140)	TATA spare parts
379017003162	WIRE HARNESS DATAILS	TATA spare parts
379017003163	920 FRONT ELEC PNEUMATIC ASSY HUIMINWS	TATA spare parts
379017003164	1350 REAR ELEC PNEUMATIC ASSY HUIMINS	TATA spare parts
379017003217	870 FRONT INSWING PASS DOOR_HUIMINS	TATA spare parts
379017003218	870 INSWING PASS DOOR TREE ASSLY_HUIMINS	TATA spare parts
379017003229	ELEC-PNEUMATIC ASSY WITH SENSITIVITY 24V	TATA spare parts
379017003230	WIRING HARNESS INSWING & OUTSWING¿ DOOR	TATA spare parts
379017003255	1350X1983 BRTS OUTSWING DOOR_HUIMINS	TATA spare parts
379017003256	1350 BRTS OUTSWING DOOR TREE ASSLY	TATA spare parts
379017003257	1350 OUTSWING BRTS ELEC PNEU CIRCUIT	TATA spare parts
379017003280	JK DOOR ASSY 920X2005 APP	TATA spare parts
379017003281	MIDDLE JK DOOR 1350X1983	TATA spare parts
379017003285	1350 JK DOOR TOP SEALING BRUSH ASSY	TATA spare parts
379017003286	REAR JK DOOR ASSY 1210X1983 APP BS6	TATA spare parts
379017004007	BRUSH ASSEMBLY OVER THE DOOR	TATA spare parts
379017004008	BRUSH 340L	TATA spare parts
379017004009	PNEUMATIC CYLINDER 733-500	TATA spare parts
379017004019	BRUSH 865L	TATA spare parts

379017004020	BRT PASSENGER DOOR PNEUMATIC BOX	TATA spare parts
379017004021	BRT PASSENGER DOOR PNEUMATIC BOX FLAP	TATA spare parts
379017004022	FRONT PASSENGER PNEUMATIC DOOR BOX	TATA spare parts
379017004023	PASSENGER DOOR PNEUMATIC BOX FLAP	TATA spare parts
379017004024	REAR PASSENGER PNEUMATIC DOOR BOX	TATA spare parts
379017004025	REAR PASSENGER DOOR PNEUMATIC BOX FLAP	TATA spare parts
379017004029	FRONT PASSENGER DOOR ASSEMBLY TINT GLASS	TATA spare parts
379017004039	FRONT PASSENGER DOOR_ASSEMBLY	TATA spare parts
379017004040	REAR PASSENGER DOOR ASSEMBLY	TATA spare parts
379017004041	FRONT PASSENGER DOOR ASSEMBLY	TATA spare parts
379017004048	JK DOOR GRAB HANDLE & CLAMP ASSY	TATA spare parts
379017004054	PARTITION DOOR LOCK ASSY.	TATA spare parts
379017004058	FRONT PASSENGER DOOR ASSEMBLY	TATA spare parts
379017004059	FRONT PASSENGER DOOR	TATA spare parts
379017004071	FRONT PNEUMATIC ASSY	TATA spare parts
379017004073	MIDDLE LEFT PNEUMATIC ASSY	TATA spare parts
379017004078	PASSENGER DOOR ASSY	TATA spare parts
379017004079	PASSENGER DOOR ASSY	TATA spare parts
379017004080	FRONT PASSENGER DOOR ASSY	TATA spare parts
379017004103	HEAVY DUTY HINGE ASSLY A	TATA spare parts
379017004104	HEAVY DUTY HINGE ASSLY B	TATA spare parts
379017004114	HEAVY DUTY LOCK ASSLY LH	TATA spare parts
379017004121	HEAVY DUTY HINGE ASSLY A_HRTC_100WD	TATA spare parts
379017004122	HEAVY DUTY HINGE ASSLY B_HRTC_100WD	TATA spare parts
379017004123	FRONT PASS DOOR STR. & PANEL ASSLY_52WB	TATA spare parts
379017004124	REAR PASS DOOR STR. & PANEL ASSLY_52WB	TATA spare parts
379017004131	PASSENGER DOOR ASSY HUIMINS	TATA spare parts
379017004132	DOOR SHAFT BEARING-IGUS MAKE BS6	TATA spare parts
379017004151	JK DOOR UPPER LATCH_1230	TATA spare parts
379017004166	FRONT 920 APP SHELF PLATE ASSY BS6	TATA spare parts
379017004167	SUPPLY-M/S SHAVO	TATA spare parts
379017004169	920 FRONT JK DOOR GLASS	TATA spare parts
379017004170	1350 MIDDLE DOOR LH LEAF	TATA spare parts
379017004171	1350 MIDDLE DOOR RH LEAF	TATA spare parts
379017004172	1210 JK DOOR SHELF PLATE BS6	TATA spare parts
379017004173	FRONT 920 & REAR 1210 PNEU DIKITING BS6	TATA spare parts
379017005005	FRONT PASSENGER DOOR_RH FLAP	TATA spare parts
379017005006	FRONT PASSENGER DOOR_LH FLAP	TATA spare parts
379017005023	PASSENGER DOOR GLASS WITH RUBBER	TATA spare parts
379017005045	FRONT PASSENGER DOOR_RIGHT FLAP_ASSY	TATA spare parts
379017005046	FRONT PASSENGER DOOR_LH FLAP ASSY	TATA spare parts
379017005054	PASSENGER DOOR CLEAR GLASS WITH RUBBER	TATA spare parts
379017005067	SATCH BRACKET ASSLY	TATA spare parts
379017005068	CATCHER BRACKET ASSLY	TATA spare parts
379017005083	DW50 AIR SENSOR	TATA spare parts
379017005091	SOLENOID VALVE	TATA spare parts
379017005094	AIR FILTER	TATA spare parts



379017005112	DIRECTION CHANGE VALVE	TATA spare parts
379017005122	FAST RELEASE VALVE	TATA spare parts
379017005123	DASHBOARD SWITCH-RED	TATA spare parts
379017005124	DASHBOARD SWITCH-GREEN	TATA spare parts
379017005125	RESET SWITCH	TATA spare parts
379017005126	DASHBOARD SWITCH-WHITE	TATA spare parts
379017005127	AIRLINE PIPE BLACK	TATA spare parts
379017005129	EXTERNAL EMERGENCY VALVE	TATA spare parts
379017005130	INTERNAL EMERGENCY VALVE	TATA spare parts
379017005133	T CONNECTOR	TATA spare parts
379017005134	I LOCKNUT CONNECTOR	TATA spare parts
379017005139	AIRLINE PIPE BLUE	TATA spare parts
379017005140	SLIDE WAY	TATA spare parts
379017005141	GUIDE ROLLER	TATA spare parts
379017005142	TIGHTEN BRACKET	TATA spare parts
379017005143	GUIDE BRACKET	TATA spare parts
379017005144	SHELF PLATE	TATA spare parts
379017005145	UPPER ARM BALLJOINT WITH BRACKET	TATA spare parts
379017005146	DRIVESHAFT-FRONT	TATA spare parts
379017005147	LOCK-FRONT	TATA spare parts
379017005148	UPPER SWING-ARM FRONT	TATA spare parts
379017005149	CYLINDER WITH MAGNETIC SENSOR	TATA spare parts
379017005150	DRIVESHAFT-REAR	TATA spare parts
379017005151	LOCK-REAR	TATA spare parts
379017005152	UPPER SWING-ARM REAR	TATA spare parts
379017005153	CYLINDER-REAR	TATA spare parts
379017005154	CUSHION VALVE	TATA spare parts
379017005155	CRANK	TATA spare parts
379017005156	JOINT FORK	TATA spare parts
379017005157	SPEED-ADJUST CONNECTOR	TATA spare parts
379017005158	PRESSURE SWITCH 22PSI	TATA spare parts
379017005159	CONTROL BOX	TATA spare parts
379017005161	DOOR FRAME RUBBER	TATA spare parts
379017005162	MIDDLE RUBBER FRONT WITH PIPE GLUE AND C	TATA spare parts
379017005163	MIDDLE RUBBER REAR WITH PIPE GLUE AND CO	TATA spare parts
379017005164	DOOR SIDE RUBBER	TATA spare parts
379017005165	BOTTOM MOVABLE BRUSH-FRONT WITH PROFILE	TATA spare parts
379017005166	BOTTOM MOVABLE BRUSH-REAR WITH PROFILE	TATA spare parts
379017005167	BOTTOM FIXED BRUSH	TATA spare parts
379017005168	RAIN DRIP-PROFILE	TATA spare parts
379017005169	UPPER BRUSH	TATA spare parts
379017005170	GLASS-FRONT	TATA spare parts
379017005171	GLASS-REAR	TATA spare parts
379017005172	HANDLE	TATA spare parts
379017005173	SHELF PLATE	TATA spare parts
379017005174	UPPER DRIVESHAFT-FRONT	TATA spare parts
379017005175	UPPER SWINGARM-FRONT	TATA spare parts

379017005176	LOWER SWINGARM-FRONT	TATA spare parts
379017005177	LOWER DRIVESHAFT-FRONT	TATA spare parts
379017005178	UPPER ROD-FRONT	TATA spare parts
379017005179	UPPER ROD-REAR	TATA spare parts
379017005180	UPPER DRIVESHAFT-REAR	TATA spare parts
379017005181	UPPER SWINGARM-REAR	TATA spare parts
379017005182	UPPER BRACKET	TATA spare parts
379017005183	LOWER BRACKET	TATA spare parts
379017005184	LOWER SWINGARM-REAR	TATA spare parts
379017005185	LOWER DRIVESHAFT-REAR	TATA spare parts
379017005186	UPPER ROD BRACKET-FRONT	TATA spare parts
379017005187	UPPER ROD BRACKET-REAR	TATA spare parts
379017005188	GEAR PART	TATA spare parts
379017005189	RACK	TATA spare parts
379017005190	FRONT CYLINDER WITH MAGNETIC SENSOR	TATA spare parts
379017005191	FRONT CYLINDER BRACKET	TATA spare parts
379017005192	REAR CYLINDER BRACKET	TATA spare parts
379017005193	REAR AIR CYLINDER	TATA spare parts
379017005194	SPLINE SHAFT	TATA spare parts
379017005195	CONTROL BOX	TATA spare parts
379017005196	DOOR PANEL-FRONT	TATA spare parts
379017005197	DOOR PANEL-REAR	TATA spare parts
379017005198	GLASS-FRONT	TATA spare parts
379017005199	DOOR FRAME PROFILE-FRONT	TATA spare parts
379017005200	GLASS-REAR	TATA spare parts
379017005201	MIDDLE RUBBER-FRONT	TATA spare parts
379017005202	MIDDLE RUBBER-REAR	TATA spare parts
379017005203	DOOR FRAME SEALING RUBBER	TATA spare parts
379017005204	DOOR FRAME TOP PROFILE	TATA spare parts
379017005205	DOOR FRAME RUBBER	TATA spare parts
379017005206	DOOR PANEL RUBBER	TATA spare parts
379017005207	DOOR LOCK-FRONT	TATA spare parts
379017005208	DOOR LOCK-REAR	TATA spare parts
379017005209	DOOR FRAME PROFILE-REAR	TATA spare parts
379017005210	DOOR PANEL-FRONT(WITH GLASS BRUSH LOCKS	TATA spare parts
379017005211	DOOR PANEL-REAR(WITH GLASS BRUSH LOCKS	TATA spare parts
379017005213	PANELING STAGE DIKITING PARTS	TATA spare parts
379017005214	TRIM STAGE DIKITING PARTS	TATA spare parts
379017005215	COUPLING STAGE PNEU DIKITING	TATA spare parts
379017005216	1350 MIDDLE DOOR MTG PLATE ASSY	TATA spare parts
379017005217	920 FRONT DOOR MTG PLATE ASSY	TATA spare parts
379017006002	DOOR BOTTOM PIVOT SUPPORT KIT R	TATA spare parts
379017006007	DOOR BOTTOM PIVOT SUPPORT KIT L	TATA spare parts
379017083010	INTERNAL PANEL -BOTTOM	TATA spare parts
379017083014	INTERNAL PANEL -BOTTOM	TATA spare parts
379017083017	160X300X2.7MM G.I SHEET	TATA spare parts
379017083019	FRONT INTERNAL PANEL_HRTC_52WB	TATA spare parts

379017083020	REAR INTERNAL PANEL_HRTC_52WB	TATA spare parts
379017084062	PASS DOOR BOTTOM PVC GI INTERNAL PANEL	TATA spare parts
379017084063	PASS DOOR TOP PVC GI INTERNAL PANEL	TATA spare parts
379017084064	PASS DOOR SIDE LH&RH PVC GI INNER PANEL	TATA spare parts
379017174001	PASSENGER DOOR AL. HANDLE	TATA spare parts
379017183002	REAR DOOR PNEUMATIC HARNESS COVER_ABS	TATA spare parts
379017184002	FRONT PASSENGER DOOR EXTERNAL PANEL	TATA spare parts
379017184003	REAR PASSENGER DOOR EXTERNAL PANEL	TATA spare parts
379017185026	FRONT PASSENGER DOOR EXTERNAL PANEL_52W	TATA spare parts
379017185027	REAR PASSENGER DOOR EXTERNAL PANEL_52WB	TATA spare parts
379017233001	PARTITION GLASS 1105X693 30PERC GREY	TATA spare parts
379017233002	PARTN.DOOR.GLASS_680X965_CLEAR	TATA spare parts
379017234017	1350 JK DOOR GLASS	TATA spare parts
379017236001	PASSENGER DOOR CLEAR GLASS	TATA spare parts
379017236002	PASSENGER DOOR TINTED GLASS	TATA spare parts
379017236005	DOOR GLASS	TATA spare parts
379017236009	DOOR GLASS	TATA spare parts
379017264001	FRONT PASSENGER PNEUMATIC DOOR BOX	TATA spare parts
379017264002	FRONT PASSENGER PNEUMATIC DOOR BOX FLAP	TATA spare parts
379017264003	REAR PASSENGER PNEUMATIC DOOR BOX	TATA spare parts
379017264004	REAR PASSENGER DOOR PNEUMATIC BOX FLAP	TATA spare parts
379017284005	JK DOOR RUBBR PROFILE (DOOR AXLE SIDEBOT	TATA spare parts
379017285003	PASSENGER DOOR RUBBER PROFILE_1	TATA spare parts
379017285004	PASSENGER DOOR RUBBER PROFILE_2	TATA spare parts
379017285007	RUBBER-OUTLINED EDGE PROFILE	TATA spare parts
379017285008	RUBBER-OUTLINED EDGE PROFILE	TATA spare parts
379017285012	PARTITION DOOR GLASS RUBBER	TATA spare parts
379017286001	WEATH.STRIP(PASS.DR-GLASS)	TATA spare parts
379017323001	FRONT PASSENGER PNEUMATIC DOOR BOX	TATA spare parts
379017323002	FRONT PASSENGER PNEUMATIC DOOR BOX FLAP	TATA spare parts
379017323003	PASSENGER DOOR PNEUMATIC BOX	TATA spare parts
379017323010	DOUBLE PASSANGER DOOR (ABS/PP)	TATA spare parts
379017323011	PASSENGER DOOR CANOPY (ABS/PP)	TATA spare parts
379017914001	PNEUMATIC MECHANISM_DOUBLE DOOR_CIRCU	TATA spare parts
379017964001	870 DOOR PANEL	TATA spare parts
379017964002	BOTTOM MOVABLE BRUSH WITH PROFILE FRONT	TATA spare parts
379017964003	BOTTOM FIXED BRUSH FRONT	TATA spare parts
379017964004	DOOR GUIDE ROLLER BRACKET	TATA spare parts
379017964006	870 DRIVE SHAFT	TATA spare parts
379017964008	870 SLIDE WAY_FRONT	TATA spare parts
379017964009	SHELF PLATE_FRONT	TATA spare parts
379017964010	CRANK	TATA spare parts
379017964011	DOOR GLASS OUTSWING DOOR 1350X1983 APP	TATA spare parts
379017964012	TOP BRACKET	TATA spare parts
379017964013	BOTTOM BRACKET	TATA spare parts
379017964016	DOOR PANEL	TATA spare parts
379017964017	DOOR PANEL REAR	TATA spare parts

379017964018	DRIVE SHAFT FRONT	TATA spare parts
379017964019	DRIVE SHAFT REAR	TATA spare parts
379017964020	UPPER SWING ARM FRONT	TATA spare parts
379017964021	LOWER SWING ARM FRONT	TATA spare parts
379017964022	UPPER ROD FRONT	TATA spare parts
379017964023	UPPER ROD REAR	TATA spare parts
379017964024	UPPER SWING ARM REAR	TATA spare parts
379017964025	LOWER SWING ARM REAR	TATA spare parts
379017964026	SHELF PLATE	TATA spare parts
379017964027	FRONT CYLINDER BRACKET	TATA spare parts
379017964028	REAR CYLINDER BRACKET	TATA spare parts
379017964038	DOOR SIDE RUBBER	TATA spare parts
379017965075	TIMER CONTROLLER 24 V	TATA spare parts
379018002001	FRONT FACE FRP ASSEMBLY	TATA spare parts
379018002002	FRONT FACE FRP ASSY	TATA spare parts
379018002007	SM FRONT FACE WITH HEAD LAMP BRACKET	TATA spare parts
379018003005	FRP FRONT BUMPER ASSY-LHD	TATA spare parts
379018003009	FRP FRONT FACE WITH EXTRA LAMPS ASSY-LHD	TATA spare parts
379018003010	FRP FRONT FLAP ASSY	TATA spare parts
379018003014	SHEET METAL FRONT FACE	TATA spare parts
379018003015	FRONT FLAP SHEET METAL	TATA spare parts
379018003016	SHEET METAL FRONT BUMPER ASSEMBLY	TATA spare parts
379018003017	SHEET METAL FT BUMPER ASSY WIT FOG LAMP	TATA spare parts
379018003018	MCV FR BUMPER WIT FOGLAMP ASSY	TATA spare parts
379018003019	SM REAR BUMPER WIT FOGLAMP ASSY	TATA spare parts
379018003020	FRP FRONT FACE WITH HEAD LAMP BRACKET	TATA spare parts
379018003021	SM FRP FRONT BUMPER 522 ASSEMBLY	TATA spare parts
379018003022	FRP FRONT FLAP ASSEMBLY	TATA spare parts
379018003023	SHEET METAL FRONT FLAP ASSY	TATA spare parts
379018003024	SM FRP FRONT BUMPER 522 ASSY W/O FOGLAMP	TATA spare parts
379018003027	SM FRP FRONT BUMPER 372 ASSEMBLY	TATA spare parts
379018003029	FRP FRONT FACE WITH HEAD LAMP BRACKET SM	TATA spare parts
379018003032	FRP FRONT BUMPER	TATA spare parts
379018003048	FRONT FACE WITH FLAP ASSY_MCV_9X12	TATA spare parts
379018003049	FRONT BUMPER ASSY_MCV_9X12	TATA spare parts
379018003054	FRP FRONT BUMPER ASSY DETAIL BS6	TATA spare parts
379018004005	FRP FRONT CENTER BUMPER ASSY-LHD	TATA spare parts
379018004007	FRP FRONT FLAP WITH STRUCTURE ASSEMBLY	TATA spare parts
379018004012	SM FRP FRONT FLAP WITH STRUCTURE ASSY	TATA spare parts
379018005003	FRP FRONT FLAP WITH MESH ASSY	TATA spare parts
379018005010	SM FRP FRONT FLAP STRUCTURE	TATA spare parts
379018184001	ALU HONEY COMB MESH FOR SW FRONT FACE	TATA spare parts
379018186001	SM SW FRONT FLAP TOP HONEY COMB MESH	TATA spare parts
379018186002	SM SW FRONT FLAP BOTTOM HONEY COMB MESH	TATA spare parts
379018263001	FRONT EXTERNAL REVETMENT	TATA spare parts
379018263013	FRONT DOOR	TATA spare parts
379018264004	FRONT EXTERNAL REVERTMENT	TATA spare parts

379018264005	FRONT BUMPER CENTER PART ASSY	TATA spare parts
379018264006	FRONT BUMPER RH ASSY	TATA spare parts
379018264007	FRONT BUMPER LH ASSY	TATA spare parts
379018264008	FRONT BUMPER RH ASSY	TATA spare parts
379018264009	FRONT BUMPER LH ASSY	TATA spare parts
379018264010	FRP FRONT CORNER BUMPER -RH-LHD	TATA spare parts
379018264011	FRP FRONT CORNER BUMPER -LH-LHD	TATA spare parts
379018264016	FRONT EXTERNAL REVETMENT	TATA spare parts
379018265004	FRONT BUMPER CENTER PART ASSY	TATA spare parts
379018266001	FRP FRONT FLAP	TATA spare parts
379019002001	REAR FACE FRP ASSEMBLY	TATA spare parts
379019002004	REAR FACE FRP ASSY	TATA spare parts
379019003004	FRP REAR BUMPER ASSY-LHD	TATA spare parts
379019003016	SHEET METAL REAR FACE WITHOUT RLB	TATA spare parts
379019003018	SHEET METAL REAR BUMPER ASSY	TATA spare parts
379019003020	REAR FLAP MAIN ASSY	TATA spare parts
379019003022	LOCK ASSY.	TATA spare parts
379019003023	REAR FLAP ASSY	TATA spare parts
379019003024	REAR BUMPER APPLICABLE TO 1512 BIHAR BUS	TATA spare parts
379019003025	SHEET METAL REAR FACE W/O RLB ASSY	TATA spare parts
379019003030	REAR BUMPER ASSY	TATA spare parts
379019003032	REAR WINDSHIELD PROTECTION TUBE ASSY	TATA spare parts
379019003041	G.I. REAR FACE ASSY	TATA spare parts
379019003043	RLB FLAP ASSEMBLY	TATA spare parts
379019003045	G.I. REAR FACE W/O RLB ASSY	TATA spare parts
379019003048	RLB FLAP ASSEMBLY	TATA spare parts
379019003049	REAR WINDSHIELD AL GRILL WITH FRAME ASSY	TATA spare parts
379019003050	SM 237 FRP REAR BUMPER ASSEMBLY	TATA spare parts
379019003054	FRP REAR SINGLE PIECE BUMPER 1230 ASSY	TATA spare parts
379019003057	MCV -9X12 EV- REAR BUMPER _409002000105	TATA spare parts
379019004012	REAR BUMPER CENTRAL FRP	TATA spare parts
379019004013	FRP REAR CENTER BUMPER ASSY-LHD	TATA spare parts
379019004019	FRP REAR CENTER BUMPR ASSY-2LICLAMP-RHD	TATA spare parts
379019004023	REAR FLAP HINGE ASSEMBLY - RH	TATA spare parts
379019004024	REAR FLAP HINGE ASSEMBLY - LH	TATA spare parts
379019063001	FRONT GRILLE UPHOLDING STALK	TATA spare parts
379019083016	LOCK COVER	TATA spare parts
379019083024	RLB FLAP CANOPY	TATA spare parts
379019263001	REAR EXTERNAL REVETMENT	TATA spare parts
379019263002	REAR EXTERNAL REVETMENT	TATA spare parts
379019263003	FRP REAR FACE WIT RLB-1050	TATA spare parts
379019263004	FRP REAR FACE WITH EXTRA LAMPS-LHD	TATA spare parts
379019263007	FRP REARFACE WIT RLB	TATA spare parts
379019263009	LICENSE PLATE LAMP FINISHING COVER	TATA spare parts
379019263013	REAR FACE_MCV_EV(9X12)	TATA spare parts
379019263014	FRP_FLAP_APERATURE_MCV 9X12_EV	TATA spare parts
379019264002	BUMPER CORNER RH	TATA spare parts

379019264003	BUMPER CORNER LH	TATA spare parts
379019264004	FRP REAR CORNER BUMPER -RH-LHD	TATA spare parts
379019264005	FRP REAR CORNER BUMPER -LH-LHD	TATA spare parts
379019264011	FRP REAR TAIL LAMP CLUSTER - LH	TATA spare parts
379019264012	FRP REAR TAIL LAMP CLUSTER - RH	TATA spare parts
379019265005	REAR BUMPER CENTRAL FRP	TATA spare parts
379019265006	BUMPER CORNER RH	TATA spare parts
379019265007	BUMPER CORNER LH	TATA spare parts
379019265009	FRP REAR CENTER BUMPER -LHD	TATA spare parts
379019913001	FRONT GRILLE HINGE ASSEMBLY RH	TATA spare parts
379019913003	FRONT GRILLE HINGE ASSEMBLY LH	TATA spare parts
379019913004	FRONT FLAP ASSY	TATA spare parts
379020002004	BATTERY FLAP ASSLY	TATA spare parts
379020002005	SPARE WHEEL FLAP ASSLY	TATA spare parts
379020002006	AIR FILTER FLAP ASSY	TATA spare parts
379020002007	SIDE LAGGAGUE FLAP ASSY.	TATA spare parts
379020002012	MAINTENANCE FLAP ASSY-LH	TATA spare parts
379020002013	MAINTENANCE FLAP ASSY-RH	TATA spare parts
379020002023	AIR FILTER FLAP ASSY	TATA spare parts
379020002024	SIDE LUGGAGE FLAP FINAL ASSY	TATA spare parts
379020002034	AIR FILTER FLAP	TATA spare parts
379020002036	AIR FILTER FLAP ASSY	TATA spare parts
379020002047	BATTERY FLAP ASSY	TATA spare parts
379020002048	BATTERY FLAP ASSY	TATA spare parts
379020002055	SIDE LUGGAGE FLAP ASSLY_750X745	TATA spare parts
379020003002	STAY ROD ASSY_MCV	TATA spare parts
379020003003	FLAP ASSEMBLY& POWER PACK ENGINE	TATA spare parts
379020003004	STAY ROD ASSY 429	TATA spare parts
379020003005	SHUTTER UPHOLDING STALK ASSEMBLY-RH	TATA spare parts
379020003007	BATTERY FLAP ASSY LH SIDE_MCV	TATA spare parts
379020003008	STAY ROD ASSY_RH	TATA spare parts
379020003009	SPARE& WHEEL& FLAP ASSY STR&PANELING_RHS	TATA spare parts
379020003010	BATTERY FLAP ASSY_LH SIDE	TATA spare parts
379020003013	AIR FILTER FLAP ASSY_LH SIDE	TATA spare parts
379020003014	AIR FILTER FLAP STR ASSY	TATA spare parts
379020003016	GAS PISTON HOLDER RH ASSY	TATA spare parts
379020003017	GAS PISTON HOLDER RH ASSY	TATA spare parts
379020003018	HINGE RH ASSY	TATA spare parts
379020003019	HINGE LH ASSY	TATA spare parts
379020003020	AIR FILTER FLAP ASSY	TATA spare parts
379020003021	SIDE LUGGAGE FLAP FINAL ASSY	TATA spare parts
379020003025	SPARE& WHEEL& FLAP ASSY STR&PANELING	TATA spare parts
379020003026	BATTERY FLAP ASSY	TATA spare parts
379020003074	AIR FILTER& FLAP STRUCTURE ASSY	TATA spare parts
379020003083	HINGE ASSY	TATA spare parts
379020003094	BATTERY FLAP ASSY	TATA spare parts
379020003103	BATTERY FLAP ASSY	TATA spare parts

379020003104	SPARE¿ WHEEL¿ FLAP ASSY STR&PANELING	TATA spare parts
379020003105	FLAP ASSEMBLY	TATA spare parts
379020003107	MAINTENANCE FLAP ASSY	TATA spare parts
379020003108	MAINTENANCE FLAP ASSEMBLY	TATA spare parts
379020003109	MAINTENANCE FLAP ASSY	TATA spare parts
379020003110	MAINTANANCE FLAP ASSY	TATA spare parts
379020003117	BATTERY FLAP ASSY	TATA spare parts
379020003118	SPARE WHEEL FLAP ASSY STR&PANELLING	TATA spare parts
379020003123	FLAP ASSEMBLY	TATA spare parts
379020003125	FLAP ASSEMBLY	TATA spare parts
379020003126	SPARE¿ WHEEL¿ FLAP ASSY STR&PANELING	TATA spare parts
379020003127	BATTERY FLAP ASSY	TATA spare parts
379020003150	KSRTC_FLAP LOCK ASSEMBLY	TATA spare parts
379020003160	SPARE WHEEL FLAP ASSY STR & PANELING	TATA spare parts
379020003168	SPARE WHEEL FLAP ASSY STR & PANELING	TATA spare parts
379020003171	BATTERY FLAP ASSY WITH BUDGET LOCK	TATA spare parts
379020003172	SPARE WHEEL FLAP ASSY WT BUDGET LOCK	TATA spare parts
379020003174	SPARE WHEEL FLAP STR & PANEL ASSY	TATA spare parts
379020003192	SPARE WHEEL FLAP ASSY BUDGET 1300X640	TATA spare parts
379020003195	AIR FILTER FLAP STR ASSLY	TATA spare parts
379020003212	AIR FILTER FLAP ASSLY_470X410	TATA spare parts
379020003219	SIDE FLAP PANEL FRAME ASSY 356X1000	TATA spare parts
379020003228	FLAP PANEL & FRAME ASSY 330X700 APP	TATA spare parts
379020003230	BATTERY FLAP ASSY BS6	TATA spare parts
379020003234	CNG FLAP ASSY BS6	TATA spare parts
379020004001	CNG FLAP STR¿ ASSY_MCV 529X254	TATA spare parts
379020004006	BATTERY FLAP STR ASSY	TATA spare parts
379020004014	SLF STRUCTURE ASSY	TATA spare parts
379020004021	SPARE WHEEL¿ FLAP STRUCTURE ASSY	TATA spare parts
379020004084	BATTERY FLAP STR ASSY	TATA spare parts
379020083002	FLAP LOCK PLATE NEW	TATA spare parts
379020083003	UPHOLDING ROD COUPLING PLATE	TATA spare parts
379020084004	FLAP LOCK L PLATE	TATA spare parts
379020084006	SPECIAL WASHER BS6	TATA spare parts
379020084009	L PLATE FOR FLAP_2 BS6	TATA spare parts
379020084010	PANELING SHEET_1282 X 558_RH SIDE	TATA spare parts
379020084012	AIR FILTER FLAP PANELING SHEET	TATA spare parts
379020085001	STAY ROD HOLDING PLATE	TATA spare parts
379020085006	BATTERY FLAP PANELING SHEET_LH SIDE	TATA spare parts
379020314001	EXTERNAL HINGE LH_NEW BS6	TATA spare parts
379020314002	EXTERNAL HINGE RH_NEW BS6	TATA spare parts
379020314003	EXTERNAL HINGE RH	TATA spare parts
379020314004	EXTERNAL HINGE LH	TATA spare parts
379020912008	BATTERY FLAP INF DRG_LHD MCV_RHS	TATA spare parts
379020912120	BATTERY FLAP INFO 330X1765 APP	TATA spare parts
379020912122	MCV_EV_9/12 BATTERY FLAP INFO 330X1765	TATA spare parts
379020912126	AUX DRI FLAP FITTMENT 1000X398 APP	TATA spare parts

379022083030	DOOR MIRROR LH	TATA spare parts
379022083031	DOOR MIRROR RH	TATA spare parts
379027003005	BATTERY COVER WITH FLAP ASSY_ MCV_ 9X12	TATA spare parts
379027004001	BCS SERVICE FLAP ASSY_ MCV (9X12)	TATA spare parts
379027004002	LH SIDE BATTERY SERVICE FLAP ASSY_ 9X12	TATA spare parts
379027004003	REAR LH SIDE SERVICE FLAP ASSY_ MCV(9X12)	TATA spare parts
379027083010	MCV_ BATTERY COVER FRONT LOUVER MESH	TATA spare parts
379027083011	MCV_ BATTERY COVER REAR LOUVER MESH	TATA spare parts
379027265002	BATTERY COVER MCV 9X12	TATA spare parts
379028003011	SIDE EXT.PANELING BETWEEN WINDOW ASSY	TATA spare parts
379028003012	SIDE EXT.PANELING BETWEEN WINDOW ASSY	TATA spare parts
379028003013	SIDE EXT.PANELING BETWEEN WINDOW ASSY	TATA spare parts
379028003014	SIDE EXT.PANELING BETWEEN WINDOW ASSY	TATA spare parts
379028003016	SIDE EXT.PANELING BETWEEN WINDOW ASSY	TATA spare parts
379028003038	PASSENGER DOOR CANOPY ASSY	TATA spare parts
379028003039	PASSENGER DOOR CANOPY ASSY	TATA spare parts
379028003043	DRIVER FOOT STEP ASSY	TATA spare parts
379028003048	FRONT PASSENGER DOOR (920) CANOPY BS6	TATA spare parts
379028083011	UPPER SIDE EXTERNAL PANELING TYPE - 01	TATA spare parts
379028083012	UPPER SIDE EXTERNAL PANELING TYPE - 02	TATA spare parts
379028083015	SKIRT EXTERNAL PANELING TYPE - 12	TATA spare parts
379028083016	UPPER SIDE EXTERNAL PANELING TYPE - 04	TATA spare parts
379028083021	SKIRT EXTERNAL PANELING TYPE 02	TATA spare parts
379028083027	SKIRT EXTERNAL PANELING TYPE 07	TATA spare parts
379028083031	SKIRT EXTERNAL PANELING TYPE - 09	TATA spare parts
379028083037	UPPER SIDE EXTERNAL PANELING TYPE - 15	TATA spare parts
379028083040	SIDE EXT PANELING ABOVE WINDOW - 05	TATA spare parts
379028083042	SIDE EXT PANELING ABOVE WINDOW - 07	TATA spare parts
379028083043	EXTERNAL PANELING ABOVE DOOR - 01	TATA spare parts
379028083048	STRETCH PANELING REAR LH SIDE	TATA spare parts
379028083050	SKIRT EXTERNAL PANELING BEHIND BATTERY B	TATA spare parts
379028083051	SKIRT EXTERNAL PANELING BEHIND REAR AXI	TATA spare parts
379028083054	SKIRT EXTERNAL PANELING INFRONT OF REAR	TATA spare parts
379028083056	SIDE EXT.PANELING ABOVE WINDOW -10	TATA spare parts
379028083059	SKIRT EXTERNAL PANELING AIR TANK FLAP BO	TATA spare parts
379028083062	EXTRNAL PANELING ABOVE THE MIDDLE PASSEN	TATA spare parts
379028083063	EXTERNAL PANELLING ABOVE DRIVER DOOR	TATA spare parts
379028083064	SKIRT EXTERNAL PANELING BEHIND AIR TANK	TATA spare parts
379028083065	SKIRT EXTERNAL PANELING BEHIND REAR AXIL	TATA spare parts
379028083067	SKIRT EXTERNAL PANELING AIR TANK FLAP IN	TATA spare parts
379028083069	EXTERNAL PANELING BATTERY BOX TOP COVER	TATA spare parts
379028083071	MIDDLE DOOR BOTTOM PANELING	TATA spare parts
379028083073	BOTTOM COVER PLATE NEAR MIDDLE DOOR LHS	TATA spare parts
379028083074	BOTTOM COVER PLATE NEAR MIDDLE DOOR RHS	TATA spare parts
379028083083	SKIRT EXTERNAL PANELING	TATA spare parts
379028083086	SKIRT PANELING	TATA spare parts
379028083089	SKIRT EXTERNAL PANELING	TATA spare parts



379028083091	SIDE EXTERNAL PANELING ABOVE WINDOW MID	TATA spare parts
379028083096	EXTERNAL STRETCH PANELING RH SIDE	TATA spare parts
379028083097	SIDE EXT.PANELING ABOVE WINDOW -11	TATA spare parts
379028083098	SKIRT EXTERNAL PANELING	TATA spare parts
379028083099	SIDE EXT.PANELING ABOVE WINDOW 05	TATA spare parts
379028083100	EXTERNAL PANELING ABOVE DRIVER DOOR	TATA spare parts
379028083101	FRONT DOOR BOTTOM PANELING	TATA spare parts
379028083102	EXTERNAL PANELING FRONT PASSENGER DOOR	TATA spare parts
379028083103	STRETCH PANEL	TATA spare parts
379028083104	SIDE EXT.PANELING ABOVE WINDOW	TATA spare parts
379028083105	SKIRT EXTERNAL PANELING	TATA spare parts
379028083106	MIDDLE DOOR BOTTOM PANELING	TATA spare parts
379028083107	SKIRT EXTERNAL PANELING	TATA spare parts
379028083108	STRETCH PANEL	TATA spare parts
379028083109	STRETCH PANEL	TATA spare parts
379028083110	STRETCH PANEL	TATA spare parts
379028083111	SKIRT EXTERNAL PANELING	TATA spare parts
379028083112	SKIRT EXTERNAL PANELING	TATA spare parts
379028083113	SKIRT EXTERNAL PANELING	TATA spare parts
379028083114	SKIRT EXTERNAL PANELING	TATA spare parts
379028083115	SKIRT EXTERNAL PANELING	TATA spare parts
379028083116	SIDE EXT.PANELING ABOVE WINDOW	TATA spare parts
379028083117	SKIRT EXTERNAL PANELING	TATA spare parts
379028083118	SIDE EXT.PANELING ABOVE WINDOW	TATA spare parts
379028083120	SIDE EXT.PANELING ABOVE WINDOW	TATA spare parts
379028083121	SIDE EXT.PANELING ABOVE WINDOW	TATA spare parts
379028083124	SIDE PANEL NEXT TO AIR TANK TOWARDS F.A.	TATA spare parts
379028083125	SIDE PANEL_BELOW AIR TANK	TATA spare parts
379028083128	SIDE PANEL_BELOW PASSENGER DOOR	TATA spare parts
379028083129	SIDE PANEL_RH_REAR - 2	TATA spare parts
379028083130	SIDE PANEL ABOVE PASSENGER DOOR	TATA spare parts
379028083137	EXTERNAL PANELING ABOVE DOOR	TATA spare parts
379028083145	SIDE PANEL_ABOVE PASSENGER DOOR	TATA spare parts
379028083146	ABOVE FRONT PASSENGER DOOR	TATA spare parts
379028083147	REAR PASSENGER DOOR LEFT SIDE-PANELING	TATA spare parts
379028083148	REAR PASSENGER DOOR RIGHT SIDE-PANELING	TATA spare parts
379028083151	SIDE EXT.PANELING BETWEEN RH PASSENGER D	TATA spare parts
379028083152	SIDE EXT.PANELING ABOVE WINDOW	TATA spare parts
379028083159	SIDE PANEL_RH_REAR	TATA spare parts
379028083161	SKIRT EXTERNAL PANELING	TATA spare parts
379028083162	BOTTOM COVER	TATA spare parts
379028083163	SKIRT EXTERNAL PANELING	TATA spare parts
379028083164	SKIRT EXTERNAL PANELING	TATA spare parts
379028083165	SIDE PANEL_ABOVE PASSENGER DOOR	TATA spare parts
379028083166	SKIRT EXTERNAL PANELING	TATA spare parts
379028083167	SKIRT EXTERNAL PANELING	TATA spare parts
379028083168	SKIRT EXTERNAL PANELING	TATA spare parts

379028083169	SIDE PANEL_LH_REAR	TATA spare parts
379028083170	SKIRT PANEL-BETWN FRONT FACE & AIR TANK	TATA spare parts
379028083171	SIDE SKIRT RH REAR - 3	TATA spare parts
379028083172	SIDE EXT.PANELING BETWEEN WINDOWS-1	TATA spare parts
379028083173	SIDE EXT.PANELING BETWEEN WINDOWS-2	TATA spare parts
379028083174	SIDE EXT.PANELING BETWEEN WINDOW-03	TATA spare parts
379028083175	SIDE EXT.PANELING BETWEEN WINDOW-04 BS6	TATA spare parts
379028083176	SIDE EXT.PANELING BETWEEN WINDOW-05 BS6	TATA spare parts
379028083180	PANELING ABOVE EMERGENCY DOOR BS6	TATA spare parts
379028083181	SIDE EXT.PANELING ABOVE WINDOW	TATA spare parts
379028083189	EXT.PANEL BELOW EMERGENCY DOOR	TATA spare parts
379028083196	SIDE PANEL_BELOW AIR TANK-410	TATA spare parts
379028083206	TUBE COVER	TATA spare parts
379028083208	EXT.LH SIDE STRETCH PANEL	TATA spare parts
379028083209	SIDE PANEL_LH_REAR	TATA spare parts
379028083210	SKIRT EXTERNAL PANELING-260	TATA spare parts
379028083211	COVER-748	TATA spare parts
379028083212	BTM.COVER-748	TATA spare parts
379028083213	SKIRT EXTERNAL PANELING-1221	TATA spare parts
379028083214	COVER-1498	TATA spare parts
379028083215	SKIRT EXTERNAL PANELING-1112	TATA spare parts
379028083216	SKIRT EXTERNAL PANELING-790	TATA spare parts
379028083217	SIDE PANEL_BELOW PASSENGER DOOR	TATA spare parts
379028083218	SKIRT EXTERNAL PANELING-580	TATA spare parts
379028083219	COVER-469	TATA spare parts
379028083220	COVER-468	TATA spare parts
379028083221	SKIRT EXTERNAL PANELING-694	TATA spare parts
379028083222	SKIRT EXTERNAL PANELING-694	TATA spare parts
379028083223	COVER-1498	TATA spare parts
379028083224	SKIRT EXTERNAL PANELING-3272	TATA spare parts
379028083225	SIDE PANEL_RH_REAR	TATA spare parts
379028083231	SIDE EXT.PANELING ABOVE WINDOW 05	TATA spare parts
379028083256	SIDE PANEL LH REAR	TATA spare parts
379028083257	SKIRT EXTERNAL PANELLING	TATA spare parts
379028083258	SIDE PANEL_BELOW PASSENGER DOOR	TATA spare parts
379028083259	SKIRT EXTERNAL PANELING	TATA spare parts
379028083260	COVER PLATE-414	TATA spare parts
379028083261	SKIRT EXTERNAL PANELLING	TATA spare parts
379028083262	SKIRT EXTERNAL PANELLING	TATA spare parts
379028083263	SKIRT EXTERNAL PANELLING	TATA spare parts
379028083264	SIDE PANEL RH REAR	TATA spare parts
379028083268	SKIRT EXTERNAL PANELLING	TATA spare parts
379028083269	SKIRT EXTERNAL PANELLING	TATA spare parts
379028083270	EXT.PANELING ABOVE PASSENGER DOOR(300X11	TATA spare parts
379028083271	EXT.PNLG.266X890	TATA spare parts
379028083272	EXT.PNLG.230X890	TATA spare parts
379028083273	SIDE PANEL_ABOVE PASSENGER DOOR	TATA spare parts

379028083274	EXT.PNLG.207X890	TATA spare parts
379028083275	SIDE PANEL_LH_REAR	TATA spare parts
379028083276	SKIRT EXTERNAL PANELING 1112	TATA spare parts
379028083277	SKIRT EXTERNAL PANELING-2680	TATA spare parts
379028083278	SKIRT EXTERNAL PANELING-490	TATA spare parts
379028083279	EXT.PANELING COVER	TATA spare parts
379028083280	SIDE PANEL	TATA spare parts
379028083281	EXTERNAL PANELING -ABOVE FRONT PASSENGER	TATA spare parts
379028083282	EXT.PNLG.266X760	TATA spare parts
379028083283	EXT.PANLG.545	TATA spare parts
379028083284	SKIRT EXTERNAL PANELING-740	TATA spare parts
379028083285	SKIRT EXTERNAL PANELING -1890	TATA spare parts
379028083286	SKIRT EXTERNAL PANELING-480	TATA spare parts
379028083287	SIDE PANEL_RH_REAR	TATA spare parts
379028083288	SKIRT EXTERNAL PANELING -1550	TATA spare parts
379028083290	EXT.PANELING COVER	TATA spare parts
379028083295	EXT.PNLG.207X737	TATA spare parts
379028083296	EXT.PNLG.535 X 420	TATA spare parts
379028083297	SIDE EXT. PANELINH-1158 X 320 X 0.65	TATA spare parts
379028083298	EXT.PNLG.266 X 738 X 0.65	TATA spare parts
379028083299	CANOPY FOR 1283 X 870 DOOR	TATA spare parts
379028083300	SIDE EXT.PANELING 1158 X 207 X 0.65	TATA spare parts
379028083301	SIDE EXT.PANELING 897 X 519 X 0.95	TATA spare parts
379028083302	SIDE EXT.PANELING 1048 X 63 X 0.95	TATA spare parts
379028083303	SIDE EXT.PANELING 780 X 610 X 0.95	TATA spare parts
379028083304	SIDE EXT.PANELING 1490 X 612 X 0.95	TATA spare parts
379028083305	SIDE EXT.PANELING 1574 X 63 X 0.95	TATA spare parts
379028083306	SIDE EXT.PANELING 529 X 614 X 0.95	TATA spare parts
379028083307	SIDE EXT.PANELING 243 X 86 X 0.95	TATA spare parts
379028083308	SIDE EXT.PANELING 661 X 335 X 0.95	TATA spare parts
379028083309	SIDE EXT.PANELING 1191 X 638 X 0.95	TATA spare parts
379028083310	EXT.PNLG.207X890X0.65	TATA spare parts
379028083311	SIDE PANEL ABOVE PASSENGER DOOR	TATA spare parts
379028083312	EXT.PNLG-266 X 890 X 0.65	TATA spare parts
379028083313	DRIVER DOOR CANOPY (870 X 1582)	TATA spare parts
379028083314	EXT.PNLG.-0.65 X 78 X 1580	TATA spare parts
379028083315	SIDE EXT.PANELING-0.95 X 679 X 545	TATA spare parts
379028083316	SIDE EXT.PANELING 436 X 118 X 0.95	TATA spare parts
379028083317	SIDE EXT.PANELING 415 X 132 X 0.95	TATA spare parts
379028083318	SIDE EXT.PANELING-0.95 X 640 X 309	TATA spare parts
379028083319	SIDE EXT.PANELING 530 X 612 X 0.95	TATA spare parts
379028083320	SIDE EXT.PANELING 92 X 748 X 0.95	TATA spare parts
379028083321	SIDE EXT.PANELING 1490 X 612 X 0.95	TATA spare parts
379028083322	SIDE EXT.PANELING 2664 X 612 X 0.95	TATA spare parts
379028083337	SKIRT EXT. PANELING-740	TATA spare parts
379028083338	DRIVER DOOR CANOPY(870) RH SIDE	TATA spare parts
379028083339	SIDE EXT PANELLING	TATA spare parts

379028083340	SKIRT PANELLING	TATA spare parts
379028083354	SIDE SKIRT PAN 0.95 X 500 X 691	TATA spare parts
379028083358	SIDE SKIRT PANEL 0.95X2871X740	TATA spare parts
379028083359	SIDE SKIRT PANEL 0.95X555X520	TATA spare parts
379028083360	SIDE SKIRT PANEL 0.95X490X267	TATA spare parts
379028083361	SIDE SKIRT PANELING-0.95X634X760	TATA spare parts
379028083369	SIDE SKIRT PANELING-0.95X691X544	TATA spare parts
379028083370	SIDE SKIRT PANELING- 0.95X1119X746	TATA spare parts
379028083396	SKIRT EXTERNAL PANEL_1742	TATA spare parts
379028083397	SKIRT EXTERNAL PANELING_1782	TATA spare parts
379028083400	SIDE EXTERNAL PANELLING	TATA spare parts
379028083404	EXT.PANELING 1108X207X0.65	TATA spare parts
379028083405	SIDE .EXT PANELING-1108X320X0.65	TATA spare parts
379028083406	DRIVER DOOR CANOPY(870X1582)	TATA spare parts
379028083409	SIDE EXT.PANELING_1158X265X0.65	TATA spare parts
379028083418	SIDE EXT. PANELING ABOVE WINDOW-DIMITS	TATA spare parts
379028083419	SIDE EXT PANEL	TATA spare parts
379028083420	SIDE EXT PANEL	TATA spare parts
379028083443	SKIRT EXT PANELLING	TATA spare parts
379028083457	SIDE EXT PANELLING	TATA spare parts
379028083462	L-PROFILE SUPPORT 60X30X100	TATA spare parts
379028083463	SKIRT PANEL 606X645X0.65	TATA spare parts
379028083470	SKIRT EXTERNAL PANELING 753X585X0.95	TATA spare parts
379028083471	SKIRT EXTERNAL PANELING 800X800X0.95	TATA spare parts
379028083472	SKIRT EXTERNAL PANELING 799X3670X0.95	TATA spare parts
379028083473	SIDE EXT.PANELING 2960 X 785 X 0.95	TATA spare parts
379028083474	GI PLATE 280X54X0.95	TATA spare parts
379028083475	SKIRT EXTERNAL PANELING-413 X 264 X 0.95	TATA spare parts
379028083476	SKIRT EXTERNAL PANELING 810X585X0.95	TATA spare parts
379028083477	SKIRT EXTERNAL PANELING 800X560X0.95	TATA spare parts
379028083478	SIDE EXT.PANELING 2960 X 785 X 0.95(M)	TATA spare parts
379028083480	EXTERNAL PANELLING	TATA spare parts
379028083483	SIDE EXTERNAL PANELLING	TATA spare parts
379028083498	SKIRT EXTERNAL PANELING	TATA spare parts
379028083499	SKIRT EXTERNAL PANELING	TATA spare parts
379028083501	SKIRT EXT PANEL	TATA spare parts
379028083502	SKIRT EXT PANEL	TATA spare parts
379028083503	SKIRT EXT PANEL	TATA spare parts
379028083504	SKIRT EXT PANEL	TATA spare parts
379028083506	SIDE EXT PANEL	TATA spare parts
379028083507	SIDE EXT PANEL	TATA spare parts
379028083508	SIDE EXT PANEL	TATA spare parts
379028083509	SIDE EXT PANEL	TATA spare parts
379028083510	SIDE EXT PANEL	TATA spare parts
379028083511	SIDE EXT PANEL	TATA spare parts
379028083513	SIDE EXT PANELING ABOVE WINDOW 05	TATA spare parts
379028083515	SKIRT EXT PANEL	TATA spare parts

379028083516	REAR SKIRT EXT PANEL	TATA spare parts
379028083517	DRIVER DOOR CANOPY	TATA spare parts
379028083518	FRONT DRIVER PILLAR PANEL	TATA spare parts
379028083519	SIDE EXT PANEL ABOVE CO DRIVER	TATA spare parts
379028083520	EXTERNAL PANELING	TATA spare parts
379028083541	SIDE EXTERNAL PANELING	TATA spare parts
379028083545	SIDE EXTERNAL PANELING	TATA spare parts
379028083561	SIDE SKIRT PANELLING	TATA spare parts
379028083569	SKIRT EXT PANEL-752X776X.095	TATA spare parts
379028083571	A-PILLAR COVER PANEL	TATA spare parts
379028083572	SKIRT EXT PANEL	TATA spare parts
379028083576	SKIRT EXT PANEL	TATA spare parts
379028083578	SKIRT EXTERNAL PANELING	TATA spare parts
379028083579	SKIRT EXTERNAL PANELING	TATA spare parts
379028083580	SKIRT EXTERNAL PANELING	TATA spare parts
379028083581	SIDE EXTERNAL PANELING	TATA spare parts
379028083582	L-PROFILE SHEET	TATA spare parts
379028083583	SKIRT EXTERNAL PANELING	TATA spare parts
379028083584	SKIRT EXTERNAL PANELING	TATA spare parts
379028083585	SKIRT EXTERNAL PANELING	TATA spare parts
379028083586	SKIRT EXTERNAL PANELING	TATA spare parts
379028083587	SIDE EXTERNAL PANELING	TATA spare parts
379028083588	SIDE EXTERNAL PANELING	TATA spare parts
379028083593	SKIRT PANEL	TATA spare parts
379028083594	PANEL	TATA spare parts
379028083596	SKIRT EXTERNAL PANELING	TATA spare parts
379028083597	SKIRT EXTERNAL PANELING	TATA spare parts
379028083598	SIDE EXTERNAL PANELING	TATA spare parts
379028083603	SKIRT EXTERNAL PANELLING	TATA spare parts
379028083604	SKIRT EXTERNAL PANELLING	TATA spare parts
379028083605	SKIRT EXTERNAL PANELLING C SECTION	TATA spare parts
379028083607	PASS DOOR CANOPY (870) RH SIDE.	TATA spare parts
379028083608	DRIVER DOOR CANOPY	TATA spare parts
379028083609	SIDE PANEL_RH_REAR	TATA spare parts
379028083610	EXTERNAL PANEL	TATA spare parts
379028083611	SKIRT EXTERNAL PANELLING 580X751X0.95	TATA spare parts
379028083612	SKIRT EXTERNAL PANELING580X755X0.95 THK	TATA spare parts
379028083613	SKIRT EXTERNAL PANELING 753X555X0.95 THK	TATA spare parts
379028083614	SKIRT EXTERNAL PANELING409X265X0.95 THK	TATA spare parts
379028083615	COVER PLATE0.95 X 70 X 409	TATA spare parts
379028083616	SIDE SKIRT PANEL	TATA spare parts
379028083617	SIDE SKIRT PANEL	TATA spare parts
379028083624	SIDE EXT.PANELING	TATA spare parts
379028083643	SIDE EXT.PANELING 0.95 X 689 X 3437	TATA spare parts
379028083644	SIDE EXT.PANELING 0.95 X 750 X 1503	TATA spare parts
379028083645	SIDE EXT.PANELING 0.95 X 748 X 1428	TATA spare parts
379028083646	SIDE EXT.PANELING 0.95 X 748 X 835	TATA spare parts

379028083647	SIDE EXT.PANELING 0.95 X 689 X 827	TATA spare parts
379028083648	SIDE EXT.PANELING 0.95 X 690 X 2775	TATA spare parts
379028083649	SIDE EXT.PANELING 0.95 X 690 X 2775	TATA spare parts
379028083650	EXTERNAL PANEL	TATA spare parts
379028083651	CANOPY FOR DOOR	TATA spare parts
379028083652	SIDE EXT.PANELING 0.95 X 689 X 1619	TATA spare parts
379028083683	SIDE EXT PANELING BETWEEN WINDOW	TATA spare parts
379028083684	SIDE EXT PANELING BETWEEN WINDOWS 1	TATA spare parts
379028083687	SIDE EXT PANELING BETWEEN WINDOW	TATA spare parts
379028083695	SKIRT EXTERNAL PANELLINC C SECTION	TATA spare parts
379028083697	LH FRONT SKIRT PANELING 01	TATA spare parts
379028083698	LH FRONT SKIRT PANELING 02	TATA spare parts
379028083703	FRONT PASSANGER DOOR BOTTOM COVER	TATA spare parts
379028083761	DRIVER DOOR CANOPY NMMT 1195X440	TATA spare parts
379028083762	SIDE EXT PANEL	TATA spare parts
379028083763	SIDE EXTERNAL PANEL	TATA spare parts
379028083764	SIDE EXTERNAL PANEL	TATA spare parts
379028083765	SIDE EXTERNAL PANEL	TATA spare parts
379028083767	SIDE SKIRT PANEL	TATA spare parts
379028083768	SIDE EXT PANELLING	TATA spare parts
379028083770	PASTED SHEET_RH_879X369X2.7	TATA spare parts
379028083774	SIDE EXT PANEL	TATA spare parts
379028083775	SKIRT EXTERNAL PANELLING	TATA spare parts
379028083782	A PILLAR PANEL	TATA spare parts
379028083783	SIDE EXT PANELING BETWEEN WINDOWS 1	TATA spare parts
379028083797	SKIRT PANEL_HRTC	TATA spare parts
379028083798	SKIRT EXTERNAL PANELING_HRTC	TATA spare parts
379028083799	SKIRT EXTERNAL PANELING_HRTC	TATA spare parts
379028083800	DOOR UPPER PANELING_HRTC	TATA spare parts
379028083801	SKIRT SIDE EXTERNAL PANELING	TATA spare parts
379028083802	DRIVER DOOR UPPER PANELING	TATA spare parts
379028083803	SKIRT EXTERNAL PANELING_HRTC	TATA spare parts
379028083805	EMERGENCY DOOR UPPER PANELING_HRTC	TATA spare parts
379028083806	DOOR SIDE SKIRT PANEL	TATA spare parts
379028083807	SIDE PANEL BELOW PASSENGER DOOR	TATA spare parts
379028083808	DOOR CANOPY	TATA spare parts
379028083809	PASSENGER DOOR CANOPY	TATA spare parts
379028083810	SIDE EXT PANELLING	TATA spare parts
379028083815	WINDOW PILLAR EXT PANEL	TATA spare parts
379028083816	DOOR UPPER PANELLING	TATA spare parts
379028083817	WINDOW PILLAR EXT PANEL	TATA spare parts
379028083818	SKIRT EXT PANEL	TATA spare parts
379028083819	SKIRT EXT PANEL	TATA spare parts
379028083820	SKIRT EXT PANEL	TATA spare parts
379028083821	SKIRT EXT PANEL	TATA spare parts
379028083822	SKIRT EXT PANEL	TATA spare parts
379028083823	SKIRT EXTERNAL PANELLING	TATA spare parts

379028083824	DOOR UPPER PANELLING	TATA spare parts
379028083825	SKIRT EXTERNAL PANELING	TATA spare parts
379028083826	DRIVER DOOR CANOPY_HRTC	TATA spare parts
379028083827	SKIRT EXTERNAL PANELING	TATA spare parts
379028083832	SIDE EXT PANELING BETWEEN WINDOWS 1	TATA spare parts
379028083835	LH FRONT SKIRT PANELING	TATA spare parts
379028083838	COVER-785	TATA spare parts
379028083839	SKIRT EXTERNAL PANELING	TATA spare parts
379028083842	SIDE EXT PANEL-¿ 1050 FLOOR HT	TATA spare parts
379028083844	42 WB SIDE EXT PANELLING	TATA spare parts
379028083846	SIDE EXT PANELLING 1050 FLOOR HT	TATA spare parts
379028083847	SIDE EXT PANELLING 1050 FLR HT	TATA spare parts
379028083848	SIDE EXT PANEL 1050 FLOOR HT	TATA spare parts
379028083850	SKIRT EXTERNAL PANELLING	TATA spare parts
379028083853	SIDE EXT PANELLING 2960	TATA spare parts
379028083854	SIDE EXTERNAL SKIRT PANEL	TATA spare parts
379028083855	SKIRT EXT PANELLING	TATA spare parts
379028083856	SKIRT EXTERNAL PANEL	TATA spare parts
379028083863	SKIRT EXTERNAL PANELING	TATA spare parts
379028083912	PASSENGER DOOR UPPER PANEL_HRTC_52WB	TATA spare parts
379028083914	SKIRT EXTERNAL PANELLING	TATA spare parts
379028083915	EXT PANEL	TATA spare parts
379028083916	DOOR UPPER PANELLING	TATA spare parts
379028083917	SIDE EXT PANEL	TATA spare parts
379028083918	SIDE EXT PANEL	TATA spare parts
379028083921	SKIRT EXT PANELLING	TATA spare parts
379028083922	SKIRT EXT PANEL	TATA spare parts
379028083923	SIDE EXTERNAL PANELLING	TATA spare parts
379028083924	SIDE EXTERNAL PANELLING	TATA spare parts
379028083925	DOOR UPPER PANELLING	TATA spare parts
379028083926	EXT PANELLING	TATA spare parts
379028083927	EXT PANELLING	TATA spare parts
379028083929	DOOR CANOPY	TATA spare parts
379028083939	SKIRT EXTERNAL PANELING	TATA spare parts
379028083941	DRIVER DOOR UPPER PANELING	TATA spare parts
379028083942	SIDE EXTERNAL PANELING	TATA spare parts
379028083953	SIDE EXTERNAL PANELLING	TATA spare parts
379028083956	DRIVER DOOR CANOPY (800 X 1465)	TATA spare parts
379028083975	PASTED SHEET_LH_405X267X2.7	TATA spare parts
379028083976	SIDE EXTERNAL PANEL	TATA spare parts
379028083977	SIDE EXTERNAL PANEL	TATA spare parts
379028083978	SIDE EXTERNAL PANEL	TATA spare parts
379028083979	SIDE EXTERNAL PANEL	TATA spare parts
379028083992	SIDE PANEL_BELOW PASSENGER DOOR	TATA spare parts
379028083999	SIDE EXTERNAL PANEL	TATA spare parts
379028084064	SIDE EXT PANEL	TATA spare parts
379028084067	RH FRONT SKIRT PANELING	TATA spare parts

379028084068	SKIRT PANEL REAR LH	TATA spare parts
379028084069	SKIRT PANEL RH REAR	TATA spare parts
379028084070	SKIRT PANEL LH	TATA spare parts
379028084071	SKIRT PANEL	TATA spare parts
379028084072	SKIRT PANEL FRONT LH	TATA spare parts
379028084073	SKIRT PANEL RH	TATA spare parts
379028084078	SIDE EXTERNAL PANEL	TATA spare parts
379028084079	SIDE EXTERNAL PANEL	TATA spare parts
379028084081	SIDE EXTERNAL PANEL	TATA spare parts
379028084195	PASSENGER DOOR(1210) CANOPY ASSY BS6	TATA spare parts
379028084293	A- PILLAR PANEL	TATA spare parts
379028084294	EXT PANEL 190X60X0.65	TATA spare parts
379028084295	A- PILLAR PANEL	TATA spare parts
379028084296	A- PILLAR PANEL	TATA spare parts
379028084375	SKIRT PANEL	TATA spare parts
379028084376	SKIRT PANEL	TATA spare parts
379028084377	SKIRT PANEL-LH	TATA spare parts
379028084378	SKIRT PANEL-LH	TATA spare parts
379028084379	STRETCH PANEL-RH	TATA spare parts
379028084380	STRETCH PANEL-LH	TATA spare parts
379028084401	RH SIDE SKIRT PANAL	TATA spare parts
379028084402	SKIRT PANEL_RH	TATA spare parts
379028084403	RH_SKIRT PANEL	TATA spare parts
379028084404	L-PROFILE SHEET	TATA spare parts
379028084405	RH SKIRT SHEET	TATA spare parts
379028084406	RH_SKIRT PANEL	TATA spare parts
379028084407	SKIRT PANEL_RH	TATA spare parts
379028084408	SKIRT PANEL_LH	TATA spare parts
379028084409	LH_SKIRT PANEL	TATA spare parts
379028084410	LH_SKIRT PANEL	TATA spare parts
379028084411	L ANGLE(NOTCH)-748MM	TATA spare parts
379028084412	L ANGLE(NOTCH)-1568MM	TATA spare parts
379028084413	L ANGLE(NOTCH)-408MM	TATA spare parts
379028084414	L ANGLE(NOTCH)-798MM	TATA spare parts
379028084415	L ANGLE(NOTCH)-868MM	TATA spare parts
379028084416	L ANGLE(NOTCH)-358MM	TATA spare parts
379028084417	SKIRT PANEL_LH	TATA spare parts
379028084418	SKIRT PANEL_LH	TATA spare parts
379028084419	C_(NOTCH)-PANEL	TATA spare parts
379028084420	C_(NOTCH)-PANEL	TATA spare parts
379028084421	SKIRT PANEL_RH	TATA spare parts
379028084422	C_(NOTCH)-PANEL	TATA spare parts
379028084423	C_(NOTCH)-PANEL	TATA spare parts
379028084463	SIDE EXT. PANELING ABOVE WINDOW	TATA spare parts
379028084466	SIDE EXTERNAL PANEL ABOVE DRIVER DOOR BS	TATA spare parts
379028084475	LIFT TOP EXTERNAL PANEL	TATA spare parts
379028084481	SKIRT EXTERNAL PANELING BS6	TATA spare parts



379028084482	SKIRT EXTERNAL PANELING BS6	TATA spare parts
379028084483	RH REAR SKIRT PANELING BS6	TATA spare parts
379028084484	SKIRT EXTERNAL PANELING BS6	TATA spare parts
379028084485	SKIRT EXTERNAL PANELING BS6	TATA spare parts
379028084486	SKIRT EXTERNAL PANELING BS6	TATA spare parts
379028084487	SIDE EXT.PANELING BETWEEN WINDOW BS6	TATA spare parts
379028084488	SIDE EXT. PANELING ABOVE WINDOW BS6	TATA spare parts
379028084489	EXT PANEL(ABOVE FRONT PASSENGER DOOR) BS	TATA spare parts
379028084490	SKIRT EXTERNAL PANELING BS6	TATA spare parts
379028084491	SKIRT EXTERNAL PANELING BS6	TATA spare parts
379028084492	SKIRT EXTERNAL PANELING BS6	TATA spare parts
379028084493	SKIRT EXTERNAL PANELING BS6	TATA spare parts
379028084494	SIDE EXT.PANELING BETWEEN WINDOW BS6	TATA spare parts
379028084495	SIDE EXT.PANELING ABOVE WINDOW BS6	TATA spare parts
379028084496	EXTERNAL PANEL ABOVE WINDOW BS6	TATA spare parts
379028084497	SKIRT EXTERNAL PANEL BELOW DRIVER DOOR B	TATA spare parts
379028084503	LH REAR SKIRT PANELING BS6	TATA spare parts
379028084505	SKIRT EXTERNAL PANELING BS6	TATA spare parts
379028084512	SIDE EXT.PANELING BETWEEN WINDOWS-1 BS6	TATA spare parts
379028084521	SKIRT EXTERNAL PANELING BS6	TATA spare parts
379028084522	GI PLATE 526X830X0.65 THK BS6	TATA spare parts
379028183010	LH REAR SKIRT PANELING-1613-CNG	TATA spare parts
379028183011	REAR PASSENGER DOOR BOTTOM COVER	TATA spare parts
379028183013	REAR PASSENGER DOOR LEFT SIDE-SKIRT PANE	TATA spare parts
379028183014	SKIRT EXTERNAL PANELING	TATA spare parts
379028183015	SKIRT EXTERNAL PANELING-BOTTOM COVER	TATA spare parts
379028183016	SKIRT EXTERNAL PANELING-BOTTOM COVER	TATA spare parts
379028183017	LH SIDE BEHIND FRONT AXIL-SKIRT PANEL	TATA spare parts
379028183018	SKIRT EXTERNAL PANELING NEAR FRONT PASSE	TATA spare parts
379028183019	SKIRT EXTERNAL PANELING FRONT PASSENGER	TATA spare parts
379028183023	SKIRT EXTERNAL PANELING-LH SIDE BEHIND F	TATA spare parts
379028183024	SKIRT EXTERNAL PANELING-RH SIDE NEAR MID	TATA spare parts
379028183025	SKIRT EXTERNAL PANELING01-RH SIDE NEAR M	TATA spare parts
379028183026	SKIRT EXTERNAL PANELING-LH SIDE BEHIND F	TATA spare parts
379028183027	RH REAR SKIRT PANELING	TATA spare parts
379028183028	SKIRT EXTERNAL PANELING- BOTTOM COVER	TATA spare parts
379028183029	SKIRT EXTERNAL PANELING- BOTTOM COVER	TATA spare parts
379028183035	SKIRT EXTERNAL PANELING BS6	TATA spare parts
379028183056	SKIRT EXTERNAL PANELING	TATA spare parts
379028183058	SKIRT EXT PANELING	TATA spare parts
379028183070	AL-L PROFILE 870	TATA spare parts
379028183073	SKIRT PANEL 1088X789X1.5	TATA spare parts
379028183074	L PROFILE 2440X63X1.5	TATA spare parts
379028183075	L PROFILE 1801X63X1.5	TATA spare parts
379028183076	SKIRT PANEL 458X789X1.5	TATA spare parts
379028183077	SKIRT PANEL 458X726X1.5 M	TATA spare parts
379028183078	L PROFILE 877X63X1.5	TATA spare parts

379028183079	SKIRT PANEL 1636X691X1.5	TATA spare parts
379028183080	SKIRT PANEL 680X753X1.5	TATA spare parts
379028183081	L PROFILE 409 X 63 X 1.5	TATA spare parts
379028183082	C COVER FOR SKIRT PANEL 409	TATA spare parts
379028183083	SKIRT PANEL 871X733X1.5	TATA spare parts
379028183084	SKIRT PANEL 789X701X1.5	TATA spare parts
379028183085	L PROFILE 2185X63X1.5	TATA spare parts
379028183086	SKIRT PANEL 458X789X1.5 RS	TATA spare parts
379028183087	SKIRT PANEL 458X726X1.5 RH M	TATA spare parts
379028183088	SKIRT PANEL 1636X691X1.5 M	TATA spare parts
379028183117	SKIRT PANEL	TATA spare parts
379028183118	SKIRT PANEL	TATA spare parts
379028183131	SKIRT EXTERNAL PANELING WITH SLOTS	TATA spare parts
379028183132	SKIRT EXTERNAL PANELING	TATA spare parts
379028183133	SIDE PANEL_LH_REAR	TATA spare parts
379028183134	SKIRT EXTERNAL PANELING	TATA spare parts
379028183135	SKIRT EXTERNAL PANELING	TATA spare parts
379028183136	SKIRT EXTERNAL PANELING	TATA spare parts
379028183137	EXT PLATE_278X53X1.5	TATA spare parts
379028183138	SIDE EXTERNAL PANELING	TATA spare parts
379028183139	SIDE EXTERNAL PANELING	TATA spare parts
379028183140	SIDE EXTERNAL PANELING	TATA spare parts
379028183141	SIDE EXTERNAL PANELING	TATA spare parts
379028183142	SIDE EXTERNAL PANEL	TATA spare parts
379028183143	SIDE EXTERNAL PANEL	TATA spare parts
379028183144	SIDE EXTERNAL PANEL	TATA spare parts
379028183145	SIDE EXTERNAL PANEL	TATA spare parts
379028183146	SIDE EXTERNAL PANEL	TATA spare parts
379028183147	SIDE EXTERNAL PANEL	TATA spare parts
379028183148	SIDE EXTERNAL PANEL	TATA spare parts
379028183153	SIDE PANEL_LH_REAR	TATA spare parts
379028183229	DOOR CANOPY 800	TATA spare parts
379028183230	DOOR CANOPY 870	TATA spare parts
379028183235	DRIVER DOOR CANOPY 970 BS6	TATA spare parts
379028183316	AL. LH SKIRT PANEL	TATA spare parts
379028183328	SKIRT PANEL	TATA spare parts
379028183334	SKIRT EXTERNAL PANELING	TATA spare parts
379028183346	EMERGENCY FINISHING PROFILE-B	TATA spare parts
379028183367	DRIVER DOOR FINISHING PROFILE-LH	TATA spare parts
379028183368	DRIVER DOOR FINISHING PROFILE-RH	TATA spare parts
379028183369	EMERG. DOOR FINISHING PROFILE-LH	TATA spare parts
379028183370	EMERG. DOOR FINISHING PROFILE-RH	TATA spare parts
379028183389	LH FRONT SKIRT PANNELING	TATA spare parts
379028183392	LH DOOR FRONT SKIRT PANELING	TATA spare parts
379028183393	LH REAR SKIRT PANELING	TATA spare parts
379028183396	LH FRONT SKIRT PANELING	TATA spare parts
379028183401	SKIRT PANEL	TATA spare parts

379028183402	RH_SKIRT PANELING	TATA spare parts
379028183404	AL. RH SKIRT PANEL @ DRIVER SIDE	TATA spare parts
379028183405	SKIRT FLAP PANEL	TATA spare parts
379028183406	SKIRT FLAP PANEL	TATA spare parts
379028183407	SKIRT FLAP TOP PANEL	TATA spare parts
379028183408	LH REAR SKIRT PANELING	TATA spare parts
379028183409	RH FRONT SKIRT PANELING	TATA spare parts
379028183410	LH REAR SKIRT PANELING	TATA spare parts
379028183412	RH FRONT SKIRT PANELING	TATA spare parts
379028183415	RH SKIRT PANELING_1	TATA spare parts
379028183416	RH SKIRT PANELING_2	TATA spare parts
379028183417	SKIRT EXTERNAL PANELING	TATA spare parts
379028183418	RH REAR SKIRT PANELING_1	TATA spare parts
379028183419	SKIRT FLAP TOP PANEL_1	TATA spare parts
379028183420	SKIRT FLAP TOP PANEL_2	TATA spare parts
379028183421	EMERGENCY DOOR L-PROFILE	TATA spare parts
379028183422	EMERGENCY DOOR L-PROFILE	TATA spare parts
379028183423	EMERGENCY DOOR L-PROFILE	TATA spare parts
379028183424	EMERGENCY DOOR L-PROFILE 2	TATA spare parts
379028183425	EMERGENCY DOOR L-PROFILE	TATA spare parts
379028183426	DRIVER DOOR L-PROFILE	TATA spare parts
379028183427	DRIVER DOOR L-PROFILE	TATA spare parts
379028183428	DRIVER DOOR L-PROFILE	TATA spare parts
379028183429	RH FRONT SKIRT PANELING 01	TATA spare parts
379028263001	DRIVER FOOT STEP	TATA spare parts
379028912003	FOLDABLE FOOT STEP ASSY INSTALLATION	TATA spare parts
379029003015	DRAIN PLUG ASSEMBLY	TATA spare parts
379029003027	INSPECTION COVER ABOVE GEAR BOX	TATA spare parts
379029003030	INSPECTION COVER ABOVE GEAR BOX	TATA spare parts
379029003038	INSPECTION COVER ASSY OVER GEAR BOX	TATA spare parts
379029003039	INSPECTION COVER ASSY OVER GEAR BOX	TATA spare parts
379029003040	INSPECTION COVER ABOVE GEAR BOX	TATA spare parts
379029003061	INSPECTION COVER ASSLY FE	TATA spare parts
379029003064	INSPECTION COVER ASSLY 1230 AT	TATA spare parts
379029003068	REAR INSPECTION COVER ASSY	TATA spare parts
379029003072	FRONT INSPECTION COVER WITH CHEQ. PL	TATA spare parts
379029003073	REAR INSPECTION COVER WITH CHEQ. PL	TATA spare parts
379029003074	INSPECTION COVER	TATA spare parts
379029003094	FRONT INSPECTION COVER WITH CHEQ PLATE	TATA spare parts
379029003099	FRONT INSPEC LEAD	TATA spare parts
379029003153	ARTICULATION BELLOW INSPECTION COVER ASY	TATA spare parts
379029003157	REAR INSPECTION LID	TATA spare parts
379029003164	INSPECTION COVER_1	TATA spare parts
379029003165	INSPECTION COVER_8	TATA spare parts
379029003166	INSPECTION COVER_9	TATA spare parts
379029003167	INSPECTION COVER_10	TATA spare parts
379029003170	FRONT INSPECTION SHEET ASSY BS6	TATA spare parts

379029004025	REAR MIDDLE INSPECTION ASSY	TATA spare parts
379029083011	SIDE COVERING PLATE	TATA spare parts
379029183060	ALUMINUM CHEQ SHEET_798X524X2.2 THK	TATA spare parts
379029183061	ALUMINUM CHEQ SHEET 882X596X2.2 THK	TATA spare parts
379029183068	ALUMINUM CHEQUERRED SHEET	TATA spare parts
379029183070	ALUMINUM CHEQUERRED SHEET	TATA spare parts
379029183072	ALUMINUM CHEQ SHEET 105X819X2.2 THK	TATA spare parts
379029183073	ALUMINUM CHEQ SHEET 147X650X2.2 THK	TATA spare parts
379029183074	AL. CHEQUERED PLATE 100X685X2.2	TATA spare parts
379029183075	ALUMINUM CHEQ SHEET 1186X105X2.2 THK	TATA spare parts
379029183076	ALUMINUM CHEQ SHEET 798X55X2.2 THK	TATA spare parts
379029183077	ALUMINUM CHEQ SHEET_1295X50X2.2 THK	TATA spare parts
379029183078	ALUMINUM CHEQ SHEET_1880X50X2.2 THK	TATA spare parts
379029183107	ALUMINUM CHEQ SHEET 929X522X2.2 THK	TATA spare parts
379029183108	ALUMINUM CHEQ SHEET 705X213X2.2 THK	TATA spare parts
379029183109	ALUMINUM CHEQ SHEET 930X215X2.2 THK	TATA spare parts
379029183133	ALUMINUM CHEQ SHEET	TATA spare parts
379029183137	ALUMINUM CHEQ SHEET	TATA spare parts
379029183138	ALUMINUM CHEQ SHEET	TATA spare parts
379029183139	ALUMINUM CHEQ SHEET	TATA spare parts
379029183140	ALUMINUM CHEQ SHEET	TATA spare parts
379029183141	ALUMINUM CHEQ SHEET	TATA spare parts
379029183142	ALUMINUM CHEQ SHEET	TATA spare parts
379029183143	ALUMINUM CHEQ SHEET	TATA spare parts
379029183144	ALUMINUM CHEQ SHEET	TATA spare parts
379029183145	ALUMINUM CHEQ SHEET	TATA spare parts
379029183146	ALUMINUM CHEQ SHEET	TATA spare parts
379029183147	ALUMINUM CHEQ SHEET	TATA spare parts
379029183148	ALUMINUM CHEQ SHEET	TATA spare parts
379029183149	ALUMINUM CHEQ SHEET	TATA spare parts
379029183150	ALUMINUM CHEQ SHEET	TATA spare parts
379029183151	ALUMINUM CHEQ SHEET	TATA spare parts
379029183152	ALUMINUM CHEQ SHEET	TATA spare parts
379029183153	ALUMINUM CHEQ SHEET	TATA spare parts
379029183155	ALUMINUM CHEQ SHEET	TATA spare parts
379029183156	ALUMINUM CHEQ SHEET	TATA spare parts
379029183157	ALUMINUM CHEQ SHEET	TATA spare parts
379029183158	ALUMINUM CHEQ SHEET	TATA spare parts
379029183159	ALUMINUM CHEQ SHEET	TATA spare parts
379029183160	ALUMINUM CHEQ SHEET	TATA spare parts
379029183161	ALUMINUM CHEQ SHEET	TATA spare parts
379029183162	ALUMINUM CHEQ SHEET	TATA spare parts
379029183164	ALUMINUM CHEQ SHEET	TATA spare parts
379029183165	ALUMINUM CHEQ SHEET	TATA spare parts
379029183166	ALUMINUM CHEQ SHEET	TATA spare parts
379029183167	ALUMINUM CHEQ SHEET	TATA spare parts
379029183168	ALUMINUM CHEQ SHEET	TATA spare parts

379029183170	ALUMINUM CHEQ SHEET	TATA spare parts
379029183171	ALUMINUM CHEQ SHEET	TATA spare parts
379029183176	ALUMINIUM CHEQ PLATE	TATA spare parts
379029183179	AL. CHEQUERED PLATE	TATA spare parts
379029183180	AL. CHEQUERED PLATE	TATA spare parts
379029183181	AL. CHEQUERED PLATE	TATA spare parts
379029183182	AL. CHEQUERED PLATE	TATA spare parts
379029183184	AL. CHEQUERED PLATE	TATA spare parts
379029183185	AL. CHEQUERED PLATE	TATA spare parts
379029183186	AL. CHEQUERED PLATE	TATA spare parts
379029183187	AL. CHEQUERED PLATE	TATA spare parts
379029183188	AL. CHEQUERED PLATE	TATA spare parts
379029183189	AL. CHEQUERED PLATE	TATA spare parts
379029183190	AL. CHEQUERED PLATE 240X845X2.2	TATA spare parts
379029183191	AL. CHEQUERED PLATE 237X842X2.2	TATA spare parts
379029183192	AL. CHEQUERED PLATE 236X842X2.2	TATA spare parts
379029183193	AL. CHEQUERED PLATE	TATA spare parts
379029183194	AL. CHEQUERED PLATE	TATA spare parts
379029183195	AL. CHEQUERED PLATE	TATA spare parts
379029183196	AL. CHEQUERED PLATE 239X844X2.2	TATA spare parts
379029183197	AL. CHEQUERED PLATE	TATA spare parts
379029183198	AL. CHEQUERED PLATE	TATA spare parts
379029183199	SIDE COVERING PLATE	TATA spare parts
379029183200	SIDE COVERING PLATE	TATA spare parts
379029183201	SIDE COVERING PLATE	TATA spare parts
379029183203	ALUMINIUM CHEQ PLATE	TATA spare parts
379029183204	ALUMINUM CHEQ SHEET	TATA spare parts
379029183205	AL. CHEQUERED PLATE	TATA spare parts
379029183206	AL. CHEQUERED PLATE	TATA spare parts
379029183207	AL. CHEQUERED PLATE	TATA spare parts
379029183208	AL. CHEQUERED PLATE	TATA spare parts
379029183209	AL. CHEQUERED PLATE	TATA spare parts
379029183211	ALUMINIUM CHEQUERED PLATE-757X878	TATA spare parts
379029183212	ALUMINIUM CHEQUERED PLATE	TATA spare parts
379029183213	ALUMINIUM CHEQUERED PLATE-660X231	TATA spare parts
379029183215	AL. CHEQUERED PLATE 1217X2828X2.2	TATA spare parts
379029183216	AL. CHEQUERED PLATE 1217X2828X2.2	TATA spare parts
379029183217	AL. CHEQUERED PLATE	TATA spare parts
379029183218	AL. CHEQUERED PLATE	TATA spare parts
379029183219	AL. CHEQUERED PLATE 790X1395X2.2	TATA spare parts
379029183220	AL. CHEQUERED PLATE 790X1505X2.2	TATA spare parts
379029183221	ALUMINIUM CHEQUERED PLATE	TATA spare parts
379029183222	ALUMINIUM CHEQUERED PLATE	TATA spare parts
379029183223	AL. CHEQUERED PLATE	TATA spare parts
379029183224	AL. CHEQUERED PLATE 55X1505X2.2	TATA spare parts
379029183225	ALUMINIUM CHEQUERED PLATE-879X518	TATA spare parts
379029183226	AL. CHEQUERED PLATE 240X640X2.2	TATA spare parts

379029183227	AL. CHEQUERED PLATE 236X845X2.2	TATA spare parts
379029183228	AL. CHEQUERED PLATE 749X731X2.2	TATA spare parts
379029183229	AL. CHEQUERED PLATE 813X731X2.2	TATA spare parts
379029183230	AL. CHEQUERED PLATE 178X845X2.2	TATA spare parts
379029183232	ALUMINIUM CHEQ SHEET	TATA spare parts
379029183233	AL CHEQ PLATE	TATA spare parts
379029183236	AL. CHEQUERED PLATE	TATA spare parts
379029183237	AL. CHEQUERED PLATE	TATA spare parts
379029183238	AL. CHEQUERED PLATE	TATA spare parts
379029183239	AL. CHEQUERED PLATE	TATA spare parts
379029183240	AL. CHEQUERED PLATE	TATA spare parts
379029183241	AL. CHEQUERED PLATE 20X1440X2.2	TATA spare parts
379029183242	AL. CHEQUERED PLATE	TATA spare parts
379029183243	INSPECTION COVER AL CHEQ	TATA spare parts
379029183245	AL CHEQ PLATE	TATA spare parts
379029183246	AL. CHEQUERED PLATE 1218X3383X2.2	TATA spare parts
379029183247	AL. CHEQUERED PLATE 1218X3383X2.2	TATA spare parts
379029183248	AL. CHEQUERED PLATE 2270X1218X2.2	TATA spare parts
379029183249	AL. CHEQUERED PLATE 2270X1218X2.2	TATA spare parts
379029183250	AL. CHEQUERED PLATE 1243X781X2.2	TATA spare parts
379029183251	AL. CHEQUERED PLATE 1242X523X2.2	TATA spare parts
379029183252	AL. CHEQUERED PLATE 791X1398X2.2	TATA spare parts
379029183253	AL. CHEQUERED PLATE 791X1178X2.2	TATA spare parts
379029183254	ALUMINIUM CHEQUERED PLATE	TATA spare parts
379029183255	AL. CHEQUERED PLATE 123X898X2.2	TATA spare parts
379029183256	AL. CHEQUERED PLATE 123X256X2.2	TATA spare parts
379029183257	AL. CHEQUERED PLATE 49X123X2.2	TATA spare parts
379029183258	AL. CHEQUERED PLATE 430X123X2.2	TATA spare parts
379029183259	AL. CHEQUERED PLATE 251X842X2.2	TATA spare parts
379029183260	AL. CHEQUERED PLATE 20X2284X2.2	TATA spare parts
379029183261	AL. CHEQUERED PLATE 20X1565X2.2	TATA spare parts
379029183262	AL. CHEQUERED PLATE 20X629X50	TATA spare parts
379029183263	AL. CHEQUERED PLATE 20X140X2.2	TATA spare parts
379029183265	ALUMINIUM CHEQUERED PLATE	TATA spare parts
379029183266	ALUMINIUM CHEQUERED PLATE	TATA spare parts
379029183267	AL. CHEQUERED PLATE 178X792X2.2	TATA spare parts
379029183268	AL. CHEQUERED PLATE 178X1398X2.2	TATA spare parts
379029183269	AL. CHEQUERED PLATE 178X1178X2.2	TATA spare parts
379029183270	AL. CHEQUERED PLATE 40X625X2.2	TATA spare parts
379029183271	AL. CHEQUERED PLATE 28X730X2.2	TATA spare parts
379029183272	AL. CHEQUERED PLATE 249X844X2.2	TATA spare parts
379029183273	AL. CHEQUERED PLATE 236X844X2.2	TATA spare parts
379029183274	ALUMINIUM CHEQUERED PLATE	TATA spare parts
379029183275	ALUMINIUM CHEQUERED PLATE	TATA spare parts
379029183276	ALUMINIUM CHEQUERED PLATE	TATA spare parts
379029183277	AL. CHEQUERED PLATE 40X730X2.2	TATA spare parts
379029183278	ALUMINIUM CHEQ INSPECTION COVER	TATA spare parts

379029183279	AL. CHEQUERED PLATE 750X620X2.2	TATA spare parts
379029183280	AL. CHEQUERED PLATE 855X747X2.2	TATA spare parts
379029183281	AL. CHEQUERED PLATE 842X255X2.2	TATA spare parts
379029183282	AL. CHEQUERED PLATE 205X842X2.2	TATA spare parts
379029183283	AL. CHEQUERED PLATE 260X842X2.2	TATA spare parts
379029183284	AL. CHEQUERED PLATE 197X842X2.2	TATA spare parts
379029183285	AL. CHEQUERED PLATE 838X249X2.2	TATA spare parts
379029183286	AL. CHEQUERED PLATE 195X517X2.2	TATA spare parts
379029183287	AL. CHEQUERED PLATE 845X559X2.2	TATA spare parts
379029183288	AL. CHEQUERED PLATE 706X231X2.2	TATA spare parts
379029183289	AL. CHEQUERED PLATE 275X666X2.2	TATA spare parts
379029183290	AL. CHEQUERED PLATE 1217X3393X2.2	TATA spare parts
379029183291	AL. CHEQUERED PLATE 1217X3393X2.2	TATA spare parts
379029183308	AL.CHEQ PLATE	TATA spare parts
379029183311	ALUMINUM CHEQ SHEET 1395X55X2.2 THK	TATA spare parts
379029183312	AL. CHEQUERED PLATE	TATA spare parts
379029183313	AL. CHEQUERED PLATE	TATA spare parts
379029183318	AL CHEQUERED SHEET	TATA spare parts
379029184002	ALUMINUM CHEQ SHEET 801X283X2.2 THK	TATA spare parts
379029184003	ALUMINUM CHEQ SHEET 828X595X2.2 THK	TATA spare parts
379040003014	2LHRH 2LM 430C850W TM	TATA spare parts
379040003018	2RH 2LM 430C850W 2LB TM	TATA spare parts
379040003020	2LHRH 2LM 121C850W 2LB TM	TATA spare parts
379040003021	2RH 2LM 121C850W TM	TATA spare parts
379040003089	2RH 2LM 430C850W 1LB TM	TATA spare parts
379040003090	2RH 2LM 430C850W AR 2LB TM	TATA spare parts
379040003091	2LHRH 2LM 490C850W 2LB TM	TATA spare parts
379040003092	2RH 2LM 430C850W AR TM	TATA spare parts
379040003106	2LH_2LM 121C850W AR 2LB TM	TATA spare parts
379040003107	1RH 2LM 430C400W AR TM	TATA spare parts
379040003108	2RH 2LM 490C850W AR 2LB USB TM	TATA spare parts
379040003109	2RH 2L 430CH810W USB TM	TATA spare parts
379040003110	2LHRH 2LM 430C850W USB TM	TATA spare parts
379040003111	2RH 2LM_360CH850W_2LB AR PMS_CVG BS6	TATA spare parts
379040003112	2RH SM1LM_460CH850W_2LB PMS_CVG BS6	TATA spare parts
379040003113	2RH SM1LM_460CH850W_PMS_CVG BS6	TATA spare parts
379040003114	2RH RLB_150CH850W_AR_PMS_CVG BS6	TATA spare parts
379040003116	2RH SM1LM_460CH850W_AR_LB_PMS_CVG BS6	TATA spare parts
379040003117	2RH 2LM_460CH850W_AR_PMS_CVG BS6	TATA spare parts
379040003118	1RM 2LM_410CH405W_LB_PMS_CVG BS6	TATA spare parts
379040003119	2LH SM1LM_410CH850W_AR_LB_PMS_CVG BS6	TATA spare parts
379040003120	2LH RLB_150CH850W_AR_PMS_CVG BS6	TATA spare parts
379040003121	2LH DM_460CH850W_PMS_CVG BS6	TATA spare parts
379040003122	1LH 2LM_360CH405W_AR_PMS_CVG BS6	TATA spare parts
379040003123	1LH SM1LM_410CH405W_AR_LB_PMS_CVG BS6	TATA spare parts
379040003140	1RH 2LM 415CH400W 1AR LB PMS ST	TATA spare parts
379040003141	1RH 2LM 415CH400W 1AR PMS ST	TATA spare parts

379040003142	2RH 2LM 366CH810W 1LB PMS ST	TATA spare parts
379040003143	2LH/RH 2LM 485CH810W PMS ST	TATA spare parts
379040003145	1LH/RH 2LM 415CH400W LB PMS ST	TATA spare parts
379040003146	2LH 2LM 366CH810W 1LB PMS ST	TATA spare parts
379040003147	1LH 2LM 415CH400W 1AR PMS ST	TATA spare parts
379040003148	1RH 2LM 415CH400W 1AR STC PMS ST	TATA spare parts
379040003149	2RH 2LM 415CH810W STC PMS ST	TATA spare parts
379040003150	2LH 2LM 415CH810W STC PMS ST	TATA spare parts
379040003151	2LH/RH 2LM 415CH810W PMS ST	TATA spare parts
379040003152	2RH 2LM 155CH 850W AR LB STC PMS ST	TATA spare parts
379040003153	2RH SLM 415CH 850W PMS ST	TATA spare parts
379040003154	2RH SLM 415CH 850W STC PMS ST	TATA spare parts
379040003155	2RH 2LM 155CH 850W LB STC PMS ST	TATA spare parts
379040003156	2RH 2LM 415CH 850W AR LB PMS ST	TATA spare parts
379040003157	2RH 2LM 415CH 850W AR STC PMS ST	TATA spare parts
379040003158	2RH 2LM 132CH 850W PMS ST	TATA spare parts
379040003159	1MID 2LM 132CH 850W LB PMS ST	TATA spare parts
379040003160	2LH 2LM 415CH 850W AR STC PMS ST	TATA spare parts
379040003161	2LH 2LM 415CH 850W AR LB PMS ST	TATA spare parts
379040003163	2LH SLM 415CH 850W PMS ST	TATA spare parts
379040003164	2LH SLM 415CH 850W STC PMS ST	TATA spare parts
379040003271	2RH 2LM 425CH 850W AR LB PMS ST	TATA spare parts
379040003274	2LH 2LM 425CH 850W AR LB PMS ST	TATA spare parts
379040003275	2RH 2LM 155CH 850W AR LB STC PMS ST	TATA spare parts
379040003276	2RH SLM 425CH 850W PMS ST	TATA spare parts
379040003277	2RH SLM 425CH 850W STC PMS ST	TATA spare parts
379040003278	2RH 2LM 155CH 850W LB PMS ST	TATA spare parts
379040003279	2RH 2LM 425CH 850W AR STC PMS ST	TATA spare parts
379040003280	2LH 2LM 425CH 850W AR STC PMS ST	TATA spare parts
379040003281	2LH SLM 425CH 850W PMS ST	TATA spare parts
379040003282	2LH SLM 425CH 850W STC PMS ST	TATA spare parts
379040003283	2RH/LH 2LM 113CH 850W PMS ST	TATA spare parts
379040003284	1MID 2LM 113CH 850W LB PMS ST	TATA spare parts
379040003292	BASE CUHION SUB ASSLY KIT BLUE	TATA spare parts
379040003294	BASE CUSHION SUB ASSLY KIT PINK	TATA spare parts
379042002006	DRIVER FAN ASSEMBLY	TATA spare parts
379042002009	BOX FOR MONITOR	TATA spare parts
379042002013	CONTROLLER	TATA spare parts
379042002018	STOP REQUEST DISPLAY ASSY	TATA spare parts
379042002029	KPIT ITS KIT MOUDII	TATA spare parts
379042002043	PANEL PLATE BS VI LH BS6	TATA spare parts
379042003003	INTERNAL LAMP ASSY	TATA spare parts
379042003006	PANEL PLATE ASSEMBLY	TATA spare parts
379042003008	PANEL PLATE ASSY_LHD	TATA spare parts
379042003009	PANEL PLATE ASSY_LHD	TATA spare parts
379042003011	PANEL PLATE ASSY	TATA spare parts
379042003012	PANEL PLATE ASSY	TATA spare parts



379042003015	PANEL PLATE ASSY LHD_NAC	TATA spare parts
379042003016	INTERNAL LAMP ASSEMBLY_24V	TATA spare parts
379042003022	PANEL PLATE ASSEMBLY RH	TATA spare parts
379042003028	PANEL PLATE ASSY	TATA spare parts
379042003029	PANEL PLATE ASSY	TATA spare parts
379042003033	PANEL PLATE ASSEMBLY FE	TATA spare parts
379042003034	PANEL PLATE ASSEMBLY LHD	TATA spare parts
379042003037	PANEL PLATE ASSEMBLY LHD	TATA spare parts
379042003041	PANEL PLATE ASSY NMMT	TATA spare parts
379042003045	DESTINATION BOARD BRACKET ASSY	TATA spare parts
379042003047	KPIT W/H KIT ITS-09-004-A (M & HCV)	TATA spare parts
379042003050	LUMAX SIDE DEST. BOARD BKT ASSY	TATA spare parts
379042003056	PANEL PLATE ASSEMBLY LP 1613	TATA spare parts
379042003076	REAR INT DESTI BOARD SUPP BRKT ASSY_LH	TATA spare parts
379042003077	REAR INT DESTI BOARD SUPP BRKT ASSY_RH	TATA spare parts
379042004005	PANEL PLATE ASSY	TATA spare parts
379042083003	SWITCH COVER PLATE	TATA spare parts
379042083007	FUSE BOX BRACKET	TATA spare parts
379042083008	CONNECTOR FITTING BRACKET	TATA spare parts
379042083009	RAMP FINISH ALUMINIUM PROFILE AT SENSORS	TATA spare parts
379042083036	PANEL PLATE LHD - LH	TATA spare parts
379042083039	PANEL PLATE LHD - RH	TATA spare parts
379042083070	FRONT DESTINATION BOARD BKT LH	TATA spare parts
379042083071	FRONT DESTINATION BOARD BKT RH	TATA spare parts
379042083072	DESTINATION BOARD CONTROLLER BRACKET	TATA spare parts
379042083077	DESTINATION BOARD BRACKET ASSY. RHS	TATA spare parts
379042083078	DESTINATION BOARD BRACKET ASSY. LHS	TATA spare parts
379042083080	PANEL PLATE RH	TATA spare parts
379042083081	STAND BDC (HEIGHT ADJUST)	TATA spare parts
379042083084	ITS EMERGENCY SWITCH PANEL PLATE	TATA spare parts
379042083096	REAR DESTINATION BOARD BRKT_RH	TATA spare parts
379042083097	REAR DESTINATION BOARD BRKT_LH	TATA spare parts
379042083128	MTG BRACKET_INT DESTI BOARD RH	TATA spare parts
379042083129	MTG BRKT INT DESTI BOARD_RH	TATA spare parts
379042083137	RH_PANEL_PLATE_BSVI BS6	TATA spare parts
379042084009	DESTI BOARD SUPPORT PLT REAR	TATA spare parts
379042084018	HARNESS ROUTING BRACKET BS6	TATA spare parts
379042084021	PANEL PLATE	TATA spare parts
379042363009	SIDE MARKER LAMPS ELECTRIC HARNESS	TATA spare parts
379042363010	SIDE MARKER LAMPS ELECTRIC HARNESS	TATA spare parts
379042363024	FUSE BOX POWER FEED CABLE	TATA spare parts
379042363027	BATTERY CABLE*GROUND CONNECTION	TATA spare parts
379042363031	BAT. CABLE BATTERY TO CUT-OFF SW	TATA spare parts
379042363033	REAR ELECTRIC HARNESS (MCV) - RH	TATA spare parts
379042363034	REAR ELECTRIC HARNESS (MCV) - LH	TATA spare parts
379042363035	HEADLAMPS WIRE HARNESS L.H.	TATA spare parts
379042363036	HEADLAMPS WIRE HARNESS R.H.	TATA spare parts

379042363037	DASHBOARD ELECTRIC HARNESS	TATA spare parts
379042363038	UPPER FRONT ELETRIC HARNESS (MCV)	TATA spare parts
379042363041	SIDE MARKER LAMPS ELECTRIC HARNESS	TATA spare parts
379042363045	FLASHER LIGHT HARNESS	TATA spare parts
379042363046	BAT. CABLE - BATTERY TO CUTOFF SWITCH	TATA spare parts
379042363047	BAT. CABLE - CUTOFF SWITCH TO STARTER	TATA spare parts
379042363048	INTERNAL LAMPS HARNESS - LH	TATA spare parts
379042363049	INTERNAL LAMPS HARNESS - RH	TATA spare parts
379042363053	MCV_AC DUCT LAMPS HARNESES LH/RH	TATA spare parts
379042363054	MCV_AC DUCT LAMPS CONNECTING HARNESS	TATA spare parts
379042363064	SIDE MARKER LAMPS MULTIPLEX HARNESS	TATA spare parts
379042363065	EXTERNAL LAMPS HARNESS	TATA spare parts
379042363068	DASHBOARD MULTIPLEX HARNESS - MCV	TATA spare parts
379042363069	UPPER FRONT MULTIPLEX HARNESS (MCV)	TATA spare parts
379042363072	SIDE MARKER LAMP HARNESS	TATA spare parts
379042363073	INTERNAL LIGHTING HARNESS - RH	TATA spare parts
379042363074	INTERNAL LIGHTING HARNESS - LH	TATA spare parts
379042363075	STOP REQUEST HARNESS	TATA spare parts
379042363077	FRONT DOOR ELECTRIC HARNESS	TATA spare parts
379042363080	RADIO ELECTRIC HARNESS-UPPER FRONT	TATA spare parts
379042363081	UPPER FRONT ELETRIC HARNESS	TATA spare parts
379042363082	DOORS ELECTRIC HARNESS FRONT AND REAR	TATA spare parts
379042363083	MCV_AC DUCT LAMPS HARNESES LH/RH	TATA spare parts
379042363084	DASHBOARD ELECTIC HARNESS	TATA spare parts
379042363086	DESTINATION BOARD ELECTRIC HARNESS.	TATA spare parts
379042363087	AC DUCT CONNECTING HARNESS	TATA spare parts
379042363088	INTERNAL LIGHTING ELECTIRC HARNESS LH	TATA spare parts
379042363089	DESTINATION BOARD ELECTRIC HARNESS SIDE	TATA spare parts
379042363092	INVERTOR POWER SUPPLY ELECTRIC HARNESS	TATA spare parts
379042363097	PASSENGER FAN ELECT.HARNESS-UPPER FRONT	TATA spare parts
379042363099	SPEAKERS ELECTRIC HARNESS_DS	TATA spare parts
379042363100	SPEAKERS ELECTRIC HARNESS_CDS	TATA spare parts
379042363102	EMERGENCY DOOR ELECT HARNESS	TATA spare parts
379042363103	STOP REQUEST HARNESS	TATA spare parts
379042363104	INTERNAL LAMP HARNESS_CDS_ROOF	TATA spare parts
379042363105	INTERNAL LAMP HARNESS_DS_ROOF	TATA spare parts
379042363109	EMERGENCY DOOR ELECTRIC HARNESS	TATA spare parts
379042363114	INTERNAL LIGHTING HARNESS_CDS_ROOF MOUN	TATA spare parts
379042363115	INTERNAL LIGHTING HARNESS_DS_ROOF MOUNT	TATA spare parts
379042363123	STEP LAMP HARNESS	TATA spare parts
379042363124	REAR ELECTRIC HARNESS_2 BREAK LAMPS- RH	TATA spare parts
379042363125	REAR ELECTRIC HARNESS_2 BREAK LAMPS- LH	TATA spare parts
379042363127	SLB LAMP HARNESS	TATA spare parts
379042363128	INVERTER TO LCD & CAMERA HARNESS	TATA spare parts
379042363129	INVERTER OUTPUT SUPPLY HARNESS	TATA spare parts
379042363131	FUSE BOX POWER FEED +VE CABLE_3000MM EV	TATA spare parts
379042363133	DASHBOARD ELECTRIC HARNESS	TATA spare parts

379042363134	UPPER FRONT ELECTRIC HARNESS	TATA spare parts
379042363135	INTERNAL LIGHTING HARNESS RH	TATA spare parts
379042363138	STEP LAMP HARNESS	TATA spare parts
379042363139	SPEAKER ELECTRIC HARNESS	TATA spare parts
379042363140	SPEAKER ELECTRIC HARNESS	TATA spare parts
379042363141	HEADLAMPS HARNESS_LH_LHD	TATA spare parts
379042363142	HEADLAMPS HARNESS_RH_LHD	TATA spare parts
379042363143	PASSENGER FAN HARNESS_5 FANS	TATA spare parts
379042363144	CO DRIVER WIPER COMPLEMENTARY HARNESS	TATA spare parts
379042363146	DRIVER SALOON LAMP HARNESS	TATA spare parts
379042363149	INVERTER OUTPUT CONNECTION W/H	TATA spare parts
379042363150	SWC BB SLB RLB LAMPS HARNESS	TATA spare parts
379042363151	LICENCE PLATE LAMP HARNESS RLB	TATA spare parts
379042363157	INTERNAL ROOF CENTER LIGHTING W/H DS	TATA spare parts
379042363159	STOP ARM HARNESS_WITH SWITCH CONTROL	TATA spare parts
379042363160	INVERTER I/P HARNESS 150W	TATA spare parts
379042363164	LED NIGHT LAMP HARNESS 3 LAMPS	TATA spare parts
379042363172	INTERNAL ROOF CENTER LIGHTING W/H CDS	TATA spare parts
379042363174	FOG LAMP PIG TAIL HARNESS	TATA spare parts
379042363176	INTERNAL LIGHTING HARNESS LH	TATA spare parts
379042363177	SIDE MARKER LAMPS HARNESS	TATA spare parts
379042363180	LED LAMP PIGTAIL HARNESS	TATA spare parts
379042363181	MOBILE CHARGER HARNESS	TATA spare parts
379042363182	SIGNAL & POWER CABLE FOR MONITOR HARNESS	TATA spare parts
379042363183	PIGTAIL HARNESS FOR FOG LAMP	TATA spare parts
379042363184	UPPER FRONT ELECTRIC HARNESS	TATA spare parts
379042363185	SIGNAL CABLE FOR MONITOR HARNESS	TATA spare parts
379042363194	EMERGENCY DOOR LOWER ELECTRIC HARNESS	TATA spare parts
379042363195	2 EXHAUST FAN ELECTRICAL HARNESS	TATA spare parts
379042363196	REAR HIGH MOUNTED STOP LAMP HARNESS	TATA spare parts
379042363197	WIPER MOTOR HARNESS	TATA spare parts
379042363198	MAIN SWITCH INDICATOR ELECTRICAL HARNESS	TATA spare parts
379042363199	DRIVER SEAT BELT & HAND BREAK HARNESS	TATA spare parts
379042363222	PIGTAIL REAR NODE	TATA spare parts
379042363223	PIGTAIL FOR REAR NODE MULTIPLEX	TATA spare parts
379042363224	TOP MOUNTED WIPER PIGTAIL	TATA spare parts
379042363225	PIGTAIL HANOVER DESTINATION	TATA spare parts
379042363232	REVERSE GEAR HORN HARNESS	TATA spare parts
379042363234	PIGTAIL FOR FRONT NODE 16 PIN	TATA spare parts
379042363235	PIGTAIL FOR FRONT NODE 14 PIN	TATA spare parts
379042363238	WIPER MOTOR HARNESS BOTTOM MOUNTED	TATA spare parts
379042363244	STOP REQUESTED HARNESS	TATA spare parts
379042363247	SIDE MARKER LAMP HARNESS LH	TATA spare parts
379042363256	DASHBOARD MULTIPLEX HARNESS	TATA spare parts
379042363257	UPPER FRONT MULTIPLEX HARNESS	TATA spare parts
379042363258	LH ROOF MULTIPLEX HARNESS	TATA spare parts
379042363260	LOWER ELECTRICAL MULTIPLEX HARNESS	TATA spare parts

379042363266	PIGTAIL HARNESS SPEAKER & INTERNAL LAMP	TATA spare parts
379042363268	STOP REQUEST HARNESS IN HAT RACK	TATA spare parts
379042363276	SIDE MARKER LAMP HARNESS LH	TATA spare parts
379042363277	SIDE MARKER LAMP HARNESS RH	TATA spare parts
379042363282	RH ROOF MULTIPLEX HARNESS	TATA spare parts
379042363313	POWER FEED ELECTRIC HARNESS MC	TATA spare parts
379042363326	PNEUMATIC DOOR LAMP CONNECTION PIGTAIL	TATA spare parts
379042363327	SIDE MARKER TO PARKING LAMP PIGTAIL BS6	TATA spare parts
379042363338	ROOF MARKER TO RVM LAMP PIGTAIL HARNESS	TATA spare parts
379042363339	RVM HARNESS_IVORY COAST	TATA spare parts
379042363340	UPPER FRONT HARNESS_FE COACH	TATA spare parts
379042363341	DASHBOARD ELECTRIC HARNESS_FE COACH	TATA spare parts
379042363343	DVR SYSTEM POWER SUPPLY	TATA spare parts
379042363346	INTERNAL LAMP HARNESS_FE COACH	TATA spare parts
379042363347	LICENSE PLATE PIGTAIL HARNESS 3MTR BS6	TATA spare parts
379042363348	EMERGENCY DECLARATION HARNESS_24V	TATA spare parts
379042363349	PIGTAIL FOR ROOF MARKER LAMP REAR	TATA spare parts
379042363350	ETM CHARGER HARNESS MSRTC	TATA spare parts
379042363351	FDSS POWER SUPPLY HARNESS TO CCU	TATA spare parts
379042363352	AUDIO CABLE FROM AMPLIFER TO SERVER	TATA spare parts
379042363353	VIDEO CABLE TV TO SERVER	TATA spare parts
379042363354	VIDEO CABLE FROM REAR TV TO SERVER	TATA spare parts
379042363362	STOP REQUEST HARNESS EV 9/12	TATA spare parts
379042363363	REAR ROOF MULTIPLEX W/H_EV_9/12	TATA spare parts
379042363364	FRONT ROOF MULTIPLEX W/H_EV_9/12	TATA spare parts
379042363365	AIS140 EMERGENCY SW HARNESS_62WB_EV 9/12	TATA spare parts
379042363369	PIGTAIL FOR POWER CONNECTION EV 9/12	TATA spare parts
379042363370	PIGTAIL FOR CAN CINNECTION EV 9/12	TATA spare parts
379042363371	PIGTAIL FOR REAR CAMERA EV 9/12	TATA spare parts
379042363376	SIDE LAMPS ELECTRIC HARNESS-LH BS6	TATA spare parts
379042363377	SIDE LAMPS ELECTRIC HARNESS-LH BS6	TATA spare parts
379042363378	SIDE LAMPS ELECTRIC HARNESS BS6	TATA spare parts
379042363385	ITS WIRING HARNESS_12MTR_CHEMITO	TATA spare parts
379042363386	LIFT_WH_EV9X12	TATA spare parts
379042363387	PASSENGER USB CHARGER HARNESS	TATA spare parts
379042363388	STOP REQUEST W\H (MIDDLE & FRONT DOOR) B	TATA spare parts
379042363389	PIGTAIL FOR NIGHT LAMPS BS6	TATA spare parts
379042363391	UPPER FRONT MULTIPLEX HARNESS BSVI BS6	TATA spare parts
379042363392	LOWER HARNESS BS6	TATA spare parts
379042363395	DASHBOARD MULTIPLEX HARNESS BSVI BS6	TATA spare parts
379042363396	LH ROOF MULTIPLEX HARNESS_BSVI BS6	TATA spare parts
379042363397	RH ROOF MULTIPLEX HARNESS BSVI BS6	TATA spare parts
379042373007	REACTOR/INVERTER F/ 15/20W LAMP	TATA spare parts
379042373008	CHANNELS AND COMPONENTS	TATA spare parts
379042373011	BRACKET FOR LAMP ACRYLIC COVER	TATA spare parts
379042373012	STOP REQUEST LUMINOUS SIGN	TATA spare parts
379042373013	LOUDSPEAKER SUPPORT	TATA spare parts

379042373014	HEADLAMP_LOWBEAM_RH SIDE_24V_RHD	TATA spare parts
379042373015	HEADLAMP_LOWBEAM_LH SIDE_24V_RHD	TATA spare parts
379042373016	STEPS LIGHTING ASSEMBLY	TATA spare parts
379042373017	STOP REQUEST LAMP SUPPORT ASSY	TATA spare parts
379042373020	STEP LAMP ASSEMBLY - 12V	TATA spare parts
379042373023	STOP REQUEST LAMP 24V	TATA spare parts
379042373025	JUNCTION CUP FOR LED LIGHTING ASSY	TATA spare parts
379042373026	SIDE CUP FOR LED LIGHTING ASSY	TATA spare parts
379042373027	LED PROFILE ASSY	TATA spare parts
379042373028	LED PROFILE ASSY	TATA spare parts
379042373029	LED NIGHT LAMP (18 TO 32V)	TATA spare parts
379042373032	MIKE WITH HOLDER	TATA spare parts
379042373039	CPU CONTROLLER - LUMAX	TATA spare parts
379042373050	DESTINATION BOARD WITH CONTROLLER	TATA spare parts
379042373060	LAPL LED LAMP 1181MM ROOF MOUNTED 12-24	TATA spare parts
379042373062	STEP LAMP ROUND TYPE	TATA spare parts
379042373068	DC-AC POWER INVERTER 24V/1500W	TATA spare parts
379042373072	ERIC PLUS PLUS CONTROLLER 24V JNNURM2	TATA spare parts
379042373073	GPS ANTENNA	TATA spare parts
379042374001	TAIL LAMP HOLDER/HARNESS	TATA spare parts
379042912063	ELECTRICAL HARNESS ASSEMBLY_55WB_LHD_AC	TATA spare parts
379042912497	HANDICAP STOP REQUEST BS6	TATA spare parts
379044003009	FIXED LADDER ASSLY	TATA spare parts
379044003010	RLC ASSEMBLY	TATA spare parts
379044003017	RLC ASSEMBLY 1	TATA spare parts
379044003018	RLC ASSEMBLY 2	TATA spare parts
379044003019	RLC ASSEMBLY 3	TATA spare parts
379044003020	FIXED LADDER ASSEMBLY	TATA spare parts
379044003022	RLC ASSEMBLY 2 42WB	TATA spare parts
379044003023	RLC ASSEMBLY 1 42WB	TATA spare parts
379044003025	FIXED LADDER ASSEMBLY 42 WB	TATA spare parts
379044003030	RLC FRONT BOARD SUPPORT ASSEMBLY	TATA spare parts
379044003031	RLC FRONT BOARD SUPPORT ASSEMBLY	TATA spare parts
379044083003	G.I SHEET FOR RLC	TATA spare parts
379044083004	G.I SHEET FOR RLC	TATA spare parts
379044083005	G.I SHEET FOR RLC	TATA spare parts
379044083006	COVERING SHEET FOR RLC	TATA spare parts
379044083007	COVERING SHEET FOR RLC	TATA spare parts
379044083008	COVERING PLATE FOR RLC	TATA spare parts
379044083017	COVERING SHEET FOR RLC	TATA spare parts
379044083019	FRONT COVERING SHEET FOR RLC	TATA spare parts
379044084007	CORRUGATED SHEET	TATA spare parts
379044084008	CORRUGATED SHEET	TATA spare parts
379044084010	CORRUGATED SHEET	TATA spare parts
379044183001	ALUMINIUM CHEQUERED PLATE RLC	TATA spare parts
379044183002	ALUMINIUM CHEQUERED PLATE RLC	TATA spare parts
379044184006	ALU CHEQUERED PLATE RLC(RH)	TATA spare parts

379044184007	ALU CHQ PLARE RLC MID 2 (RH)	TATA spare parts
379044184008	ALU CHQ PLATE RLC (LH)	TATA spare parts
379044184009	ALU CHQ PLATE RLC MID (LH)	TATA spare parts
379044184018	AL CHEQUERED SHEET_745X895X2.2THK	TATA spare parts
379044184022	AL CHEQUERED SHEET_745X895X2.2THK	TATA spare parts
379045003173	WINDSHIELD LOWER ROOFSTICK ASSEMBLY	TATA spare parts
379045003227	REINFORCEMENT PLATE	TATA spare parts
379045003513	EV_BUS_WINDSHIELD LOWER ROOF STICK ASSLY	TATA spare parts
379045013035	FRONT UPPER ARCHED PIPE	TATA spare parts
379045013078	FRONT UPPER W/S ARCHED TUBE	TATA spare parts
379045014089	FRONT STABILIZER LH TUBE	TATA spare parts
379045083202	REINFORCEMENT_S.WINDSHIELD FRONT STR	TATA spare parts
379045083203	REINFORCEMENT_S.WINDSHIELD FRONT STR	TATA spare parts
379045083204	REINFORCEMENT_S.WINDSHIELD FRONT STR	TATA spare parts
379045083205	REINFORCEMENT_S.WINDSHIELD FRONT STR	TATA spare parts
379045083206	REINFORCEMENT_S.WINDSHIELD FRONT STR	TATA spare parts
379045083548	W/S BOTTOM GUSSET_RH	TATA spare parts
379045083549	W/S BOTTOM GUSSET_LH	TATA spare parts
379045083631	REINFORCEMENT_FRONT STR_MIDDLE	TATA spare parts
379045083661	REINFORCEMENT_FRONT STR_LH	TATA spare parts
379045083662	REINFORCEMENT_FRONT STR_RH	TATA spare parts
379045083878	LV BATTERY CLOSING PANEL	TATA spare parts
379046083312	CHASSIS PLATE AT AIR BELLOW	TATA spare parts
379049263001	REAR INTERNAL REVETMENT	TATA spare parts
379050003016	AC DUCT GRILL ASSY	TATA spare parts
379050003024	DRIVER SIDE AC DUCT	TATA spare parts
379050003025	CO-DRIVER SIDE AC DUCT ASSY	TATA spare parts
379050003028	AIR TRANSITION BOX ASSEMBLY	TATA spare parts
379050003034	DRIVER SIDE AC DUCT FE SPH 400CC	TATA spare parts
379050003035	CO DRIVER SIDE AC DUCT FE SPH 400CC.	TATA spare parts
379050003041	FE-TRANSITION BOX ASSY-II	TATA spare parts
379050003045	AC DUCT GRILL ASSY	TATA spare parts
379050003046	DRIVER SIDE AC DUCT	TATA spare parts
379050003047	CO-DRIVER SIDE AC DUCT ASSY	TATA spare parts
379050003048	1940_FRONT & REAR COVER FOR TR	TATA spare parts
379050003126	HATRACK ROOF SUPPORT ASSEMBLY	TATA spare parts
379050003129	AC DUCT ASSEMBLY -RH	TATA spare parts
379050003130	AC DUCT ASSEMBLY -LH	TATA spare parts
379050003160	FIXED PANEL_1 ASSY	TATA spare parts
379050003161	FIXED PANEL_2 ASSY	TATA spare parts
379050003162	FIXED PANEL_3 ASSY	TATA spare parts
379050003163	WINDOW EXTRUSION -LH FRONT_1	TATA spare parts
379050003164	WINDOW EXTRUSION -LH FRONT_2	TATA spare parts
379050003165	WINDOW EXTRUSION -LH REAR_1	TATA spare parts
379050003166	WINDOW EXTRUSION -LH REAR_2	TATA spare parts
379050003168	WINDOW EXTRUSION -RH_1	TATA spare parts
379050003169	WINDOW EXTRUSION -RH_2	TATA spare parts

379050003173	ROOF EXTRUSION CUT-OUT LH_1	TATA spare parts
379050003174	ROOF EXTRUSION CUT-OUT LH_2	TATA spare parts
379050003175	ROOF EXTRUSION CUT-OUT LH_3	TATA spare parts
379050003176	ROOF EXTRUSION CUT-OUT RH_1	TATA spare parts
379050003177	ROOF EXTRUSION CUT-OUT RH_2	TATA spare parts
379050003178	ROOF EXTRUSION CUT-OUT RH_3	TATA spare parts
379050003192	WINDOW EXTRUSION -LH REAR_3	TATA spare parts
379050003193	WINDOW EXTRUSION -RH_3	TATA spare parts
379050003194	WINDOW EXTRUSION -RH_4	TATA spare parts
379050003195	WINDOW EXTRUSION -RH_5	TATA spare parts
379050003196	AC DUCT PANEL ASSY-LH FRONT	TATA spare parts
379050003197	AC DUCT PANEL ASSY-LH REAR	TATA spare parts
379050003198	AC DUCT PANEL ASSY-RH FRONT	TATA spare parts
379050003199	AC DUCT PANEL ASSY-RH REAR	TATA spare parts
379050003204	EV 9X12 AC DUCT PANEL ASSY-RH FRONT	TATA spare parts
379050003205	EV 9X12 AC DUCT PANEL ASSY-LH FRONT	TATA spare parts
379050003206	EV 9X12 AC DUCT PANEL ASSY-LH REAR	TATA spare parts
379050003207	AC DUCT PANEL ASSY-RH REAR	TATA spare parts
379050003208	ROOF EXTRUSION CUT-OUT LH FRONT	TATA spare parts
379050003209	ROOF EXTRUSION CUT-OUT LH MIDDLE	TATA spare parts
379050003210	ROOF EXTRUSION CUT-OUT LH REAR	TATA spare parts
379050003211	ROOF EXTRUSION CUT-OUT RH FRONT	TATA spare parts
379050003212	ROOF EXTRUSION CUT-OUT RH REAR	TATA spare parts
379050003213	WINDOW EXTRUSION -LH FRONT_1	TATA spare parts
379050003214	WINDOW EXTRUSION -LH FRONT_2	TATA spare parts
379050003215	WINDOW EXTRUSION -LH FRONT_3	TATA spare parts
379050003216	WINDOW EXTRUSION -LH REAR_4	TATA spare parts
379050003217	WINDOW EXTRUSION -LH REAR_5	TATA spare parts
379050003218	WINDOW EXTRUSION -RH_1	TATA spare parts
379050003219	WINDOW EXTRUSION -RH_2	TATA spare parts
379050003220	WINDOW EXTRUSION -RH_3	TATA spare parts
379050003221	WINDOW EXTRUSION -RH_4	TATA spare parts
379050003222	WINDOW EXTRUSION -RH_5	TATA spare parts
379050003224	FABRIC DUCT RH	TATA spare parts
379050004001	ELECTCTIC POWER HOUSING BOX FLAP	TATA spare parts
379050004007	ENGINE HOOD SUPPORT CHAIN ASSEMBLY	TATA spare parts
379050184023	AC DUCT SHEET FOR -DRIVER & CO-DRIVER	TATA spare parts
379050184036	AC DUCT COMMON SHEET FOR -DRIVER & CO-DRIVER	TATA spare parts
379050184037	AC DUCT SHEET FOR -DRIVER & CO-DRIVER	TATA spare parts
379050184038	AC DUCT SHEET FOR -DRIVER & CO-DRIVER	TATA spare parts
379050184046	AC DUCT SHEET 506.5 X 778	TATA spare parts
379050184047	AC DUCT SHEET 2020X778 6H 7S	TATA spare parts
379050184048	AC DUCT SHEET 2020X778 4H 6S.	TATA spare parts
379050184049	AC DUCT SHEET 2020X778 6H 1S	TATA spare parts
379050184050	AC DUCT SHEET 1920X778 6H 7S	TATA spare parts
379050184051	AC DUCT SHEET 506.5X778 C	TATA spare parts
379050184052	AC DUCT SHEET 2020X778 6H 7S C	TATA spare parts

379050184053	AC DUCT SHEET 2020X778	TATA spare parts
379050184054	AC DUCT SHEET 975X778 1H 4S C	TATA spare parts
379050184055	AC DUCT SHEET 2020X778 6H 1S C	TATA spare parts
379050184065	AC DUCT SHEET	TATA spare parts
379050184066	AC DUCT SHEET	TATA spare parts
379050184067	AC DUCT SHEET	TATA spare parts
379050184068	AC DUCT SHEET	TATA spare parts
379050184069	AC DUCT SHEET	TATA spare parts
379050184070	AC DUCT SHEET	TATA spare parts
379050184071	AC DUCT SHEET	TATA spare parts
379050184072	AC DUCT SHEET	TATA spare parts
379050184073	AC DUCT SHEET	TATA spare parts
379050184074	AC DUCT SHEET	TATA spare parts
379050264001	FRONT UPPER COVERING	TATA spare parts
379050264002	AC DUCT END CAP LH	TATA spare parts
379050264003	AC DUCT END CAP -RH	TATA spare parts
379050265007	FUSE BOX FLAP	TATA spare parts
379050323001	AC DUCT END COVER-RH	TATA spare parts
379050323003	AC DUCT END COVER-LH	TATA spare parts
379050324001	FRONT ROOF MARKER MAINTENANCE COVER	TATA spare parts
379050324005	HATRACK END CAP	TATA spare parts
379050324013	AC DUCT REAR END CAP_EV 9X12	TATA spare parts
379050962002	AC COOLING UNIT	TATA spare parts
379050962014	AC UNIT REVO-E-GLOBAL	TATA spare parts
379050962015	HVAC UNIT-CC355_1618	TATA spare parts
379050962016	HVAC UNIT-CC355 FOR 1623 CHASSIS	TATA spare parts
379050963007	HVAC UNIT SPHEROS REVO-EG + COND FAN	TATA spare parts
379050963008	CONTROL PANEL	TATA spare parts
379050963009	WIRING HARNESS_REVO EG	TATA spare parts
379050963010	COMPRESSOR_SCROLL C-SWS225H00A	TATA spare parts
379050963011	INVERTOR REVO E (11121625A)	TATA spare parts
379050963012	EVAP. BLOWER 24V WG-14081-00 (BLDC)	TATA spare parts
379050963013	AXIAL FAN 24V (11113528C)	TATA spare parts
379050963014	THERMAL EXPANSION VALVE_11121853A	TATA spare parts
379050963015	THERMAL EXPANSION VALVE_11121854A	TATA spare parts
379050963016	CONDENSER COIL_REVO EG	TATA spare parts
379050963017	EVAPORATOR COIL RH_REVO EG	TATA spare parts
379050963018	EVAPORATOR COIL LH_REVO EG	TATA spare parts
379050963021	HYBRID LV PIG TAIL	TATA spare parts
379050963022	GRILLE ASSY ROOF AC	TATA spare parts
379050964003	REVO EG FILTER	TATA spare parts
379051002071	DRIVER PARTION WALL	TATA spare parts
379051003009	ENGINE HOOD HANDHOLD ASSY	TATA spare parts
379051003027	HANDHOLD TUBE ASSY	TATA spare parts
379051003038	HANDHOLD TUBE ASSY	TATA spare parts
379051003126	PARTITION WALL ASSY BS6	TATA spare parts
379051003138	HANDHOLD TUBE ASSY	TATA spare parts



379051003146	PARTITION WALL ASSY BS6	TATA spare parts
379051003149	HANDHOLD TUBE ASSEMBLY-1400	TATA spare parts
379051003162	FRONT BEND GRAB RAIL ASSY	TATA spare parts
379051003163	HANDHOLD TUBE ASSEMBLY-4160MM	TATA spare parts
379051003164	HANDHOLD TUBE ASSEMBLY-2175MM	TATA spare parts
379051003165	HANDHOLD TUBE ASSEMBLY-230MM	TATA spare parts
379051003166	DRIVER PARTITION WALL ASSEMBLY	TATA spare parts
379051003169	FRONT PARTITION WALL ASSEMBLY	TATA spare parts
379051003170	HANDHOLD TUBE ASSEMBLY-187MM	TATA spare parts
379051003188	PARTITION WALL ASSEMBLY	TATA spare parts
379051003189	PARTITION WALL ASSEMBLY	TATA spare parts
379051003197	FRONT PARTITION WALL ASSY	TATA spare parts
379051003198	HANDHOLD TUBE ASSY	TATA spare parts
379051003199	GRAB RAIL	TATA spare parts
379051003204	HANDHOLD TUBE ASSEMBLY-1650	TATA spare parts
379051003205	HANDHOLD TUBE ASSEMBLY-1650	TATA spare parts
379051003214	TRIANGULAR HANDHOLD STRAP	TATA spare parts
379051003215	DRIVER PARTITION WALL ASSY	TATA spare parts
379051003216	HANDHOLD TUBE ASSY	TATA spare parts
379051003217	FRONT PARTITION WALL ASSY	TATA spare parts
379051003252	HAND HOLD ASSEMBLY4585	TATA spare parts
379051003267	HANDHOLD ASSEMBLY 3152	TATA spare parts
379051003288	DRIVER PARTITION WALL UPSRTC	TATA spare parts
379051003289	FRONT PARTITION WALL ASSY	TATA spare parts
379051003290	HANDHOLD ASSEMBLY 5903	TATA spare parts
379051003291	HANDHOLD TUBE ASSEMBLY 2955	TATA spare parts
379051003294	HAND HOLD TUBE ASSY	TATA spare parts
379051003295	HANDHOLD TUBE ASSY	TATA spare parts
379051003318	STEP PARTITION FOR SRF	TATA spare parts
379051003323	STEP PARTITION_LHD 1618	TATA spare parts
379051003333	DRIVER PARTITION WALL ASSEMBLY	TATA spare parts
379051003347	SW 1618 LHD DASHBOARD HANDHOLD TUBE	TATA spare parts
379051003348	HAND HOLD TUBE	TATA spare parts
379051003385	HAD HOLD TUBE ASSEMBLY 2180	TATA spare parts
379051003386	HAD HOLD TUBE ASSEMBLY 1965	TATA spare parts
379051003387	HAND HOLD TUBE ASSEMBLY 2150	TATA spare parts
379051003388	HAD HOLD TUBE ASSEMBLY 1980	TATA spare parts
379051003395	PASSENGER PARTITION ASSEMBLY	TATA spare parts
379051003396	PASSENGER PARTITION ASSEMBLY	TATA spare parts
379051003398	GRAB RAIL TUBE ASSEMBLE FOR PASSENGER	TATA spare parts
379051003399	GRAB RAIL TUBE ASSEMBLE FOR PASSENGER	TATA spare parts
379051003400	HAD HOLD TUBE ASSEMBLY 2890	TATA spare parts
379051003401	HANDHOLD TUBE ASSEMBLY NMMT	TATA spare parts
379051003402	HAD HOLD TUBE ASSEMBLY 1200 BEND	TATA spare parts
379051003408	HAND HOLD TUBE	TATA spare parts
379051003409	HAND HOLD TUBE ASSY	TATA spare parts
379051003410	HAND HOLD TUBE	TATA spare parts

379051003417	HANDHOLD TUBE ASSEMBLY-1145	TATA spare parts
379051003418	HANDHOLD TUBE ASSEMBLY-905	TATA spare parts
379051003419	HANDHOLD TUBE ASSEMBLY-1405	TATA spare parts
379051003420	HANDHOLD TUBE ASSEMBLY-1060	TATA spare parts
379051003421	HANDHOLD TUBE ASSEMBLY-1390	TATA spare parts
379051003422	HANDHOLD TUBE ASSEMBLY-1385	TATA spare parts
379051003423	HANDHOLD TUBE ASSEMBLY-1605	TATA spare parts
379051003424	PASSENGER DOOR AREA TUBE 2415	TATA spare parts
379051003425	HAND HOLD ASSEMBLY 2450	TATA spare parts
379051003426	FRONT PARTITION WALL ASSEMBLY 1230(SR)	TATA spare parts
379051003427	BEND GRAB RAIL ASSY	TATA spare parts
379051003428	HANDHOLD TUBE ASSEMBLY-965	TATA spare parts
379051003429	HANDHOLD TUBE ASSEMBLY-2175	TATA spare parts
379051003431	HANDHOLD TUBE ASSEMBLY-1595	TATA spare parts
379051003448	HANDHOLD TUBE ASSEMBLY	TATA spare parts
379051003449	HANDHOLD TUBE ASSEMBLY 765	TATA spare parts
379051003450	HANDHOLD TUBE ASSY	TATA spare parts
379051003459	PARTITION WALL ASSY	TATA spare parts
379051003460	PARTITION WALL ASSY	TATA spare parts
379051003461	PARTITION WALL ASSY	TATA spare parts
379051003462	DRIVER PARTITION ASSY	TATA spare parts
379051003478	HANDHOLD BEND TUBE ASSY	TATA spare parts
379051003479	HANDHOLD TUBE	TATA spare parts
379051003623	STANCHION PIPE_4 ASSY	TATA spare parts
379051003624	STEP PARTITION_ASSY	TATA spare parts
379051003625	DRIVER PARTITION_ASSY	TATA spare parts
379051003653	TUBE ASSEMBLY FOR PARTITION WALL	TATA spare parts
379051003654	DRIVER PARTITION ASSY	TATA spare parts
379051003655	STEP PARTITION_CENTER	TATA spare parts
379051003656	STEP PARTITION_REAR	TATA spare parts
379051003657	STANCHION TUBE DIA. 40X 3_1740LEN SLEEVE	TATA spare parts
379051003658	DIA. 32-HANDHOLD TUBE ASSY-725	TATA spare parts
379051003659	DIA. 32-HANDHOLD TUBE ASSY-392	TATA spare parts
379051003660	DIA. 32-HANDHOLD TUBE ASSY-683	TATA spare parts
379051003661	WHEEL CHAIR SUPPORT PARTITION	TATA spare parts
379051003662	WHEEL CHAIR SUPPORT PARTITION WALL.	TATA spare parts
379051003664	TUBE ASSEMBLY FOR PARTITION WALL	TATA spare parts
379051003667	DIA. 32-HANDHOLD TUBE ASSY-750	TATA spare parts
379051003668	DIA. 32-HANDHOLD TUBE ASSY-723	TATA spare parts
379051003669	DRIVER PARTITION WALL ASSY	TATA spare parts
379051004007	HANDHOLD TUBE ASSEMBLY	TATA spare parts
379051004015	TUBE FOR DRIVER PARTITION WALL	TATA spare parts
379051004017	TUBE ASSY FOR PARTITION WALL	TATA spare parts
379051004024	STANCHIONS TUBE FOR PARTITION WALL	TATA spare parts
379051004025	STANCHIONS TUBE FOR PARTITION WALL	TATA spare parts
379051004026	STANCHIONS TUBE FOR PARTITION WALL	TATA spare parts
379051004030	HANDHOLD TUBE ASSEMBLY 665	TATA spare parts

379051004031	HANDHOLD TUBE ASSEMBLY 715	TATA spare parts
379051004035	HANDHOLD TUBE ASSEMBLY 1400	TATA spare parts
379051004037	HAND HOLD TUBE-2070	TATA spare parts
379051004039	STANCHIONS TUBE FOR PARTITION WALL	TATA spare parts
379051004041	STANCHION TUBE FOR FRONT PARTITION WALL	TATA spare parts
379051004042	HANDHOLD TUBE ASSEMBLY	TATA spare parts
379051004044	TUBE ASSEMBLY FOR PARTITION WALL	TATA spare parts
379051004045	HANDHOLD TUBE ASSEMBLY 703	TATA spare parts
379051004046	HANDHOLD TUBE ASSEMBLY 669	TATA spare parts
379051004047	STANCHIONS TUBE FOR PARTITION WALL -2021	TATA spare parts
379051004048	STANCHIONS TUBE FOR PARTITION WALL	TATA spare parts
379051004049	STANCHIONS TUBE FOR FRONT PARTITION WALL	TATA spare parts
379051004050	TUBE ASSEMBLY FOR PARTITION WALL	TATA spare parts
379051004052	STANCHION TUBE FOR PARTITION WALL	TATA spare parts
379051004053	HANDHOLD ASSY	TATA spare parts
379051004060	HANDHOLD TUBE ASSEMBLY-620	TATA spare parts
379051004061	HAND HOLD TUBE ASSEMBLY 790	TATA spare parts
379051004063	HANDHOLD TUBE ASSEMBLY 500	TATA spare parts
379051004082	STACHIONS TUBE FR FRNT PRTN WALL 1980	TATA spare parts
379051004084	HANDHOLD TUBE ASSY	TATA spare parts
379051004085	HANDHOLD TUBE ASSY	TATA spare parts
379051004086	HANDHOLD TUBE ASSY	TATA spare parts
379051004087	HANDHOLD TUBE ASSY	TATA spare parts
379051004088	HANDHOLD TUBE ASSY	TATA spare parts
379051004090	HANDHOLD TUBE ASSY	TATA spare parts
379051004091	HANDHOLD TUBE ASSY	TATA spare parts
379051004093	HANDHOLD TUBE ASSY	TATA spare parts
379051004094	TUBE ASSEMBLY FOR PARTITION WALL	TATA spare parts
379051004096	HANDHOLD TUBE ASSEMBLY	TATA spare parts
379051004101	STANTION PIPE FOR PARTITION	TATA spare parts
379051004103	BEND TUBE ASSY	TATA spare parts
379051004109	HAND HOLD TUBE ASSY	TATA spare parts
379051004110	HANDHOLD TUBE ASSY	TATA spare parts
379051004114	HANDHOLD TUBE-2035	TATA spare parts
379051004126	VERTICAL STANCION PIPE	TATA spare parts
379051004130	STANCHIONS TUBE FOR PARTITION WALL -2021	TATA spare parts
379051004136	VERTICAL STANCION PIPE BEND 2050	TATA spare parts
379051004137	HAND HOLD TUBE ASSEMBLY 1150	TATA spare parts
379051004138	STANCHIONS TUBE FOR PARTITION WALL -2030	TATA spare parts
379051004139	HANDHOLD TUBE ASSEMBLY	TATA spare parts
379051004142	HANDHOLD TUBE ASSY	TATA spare parts
379051004144	HANDHOLD TUBE ASSEMBLY 435	TATA spare parts
379051004145	STANCHIONS TUBE FOR PARTITION WALL -2050	TATA spare parts
379051004146	HANDHOLD TUBE ASSEMBLY 717	TATA spare parts
379051004147	PARTITION WALL ASSEMBLY	TATA spare parts
379051004156	HANDHOLD TUBE ASSEMBLY	TATA spare parts
379051004158	STANCHION TUBE ASSY-2151	TATA spare parts

379051004160	VERTICAL STANCHION PIPE	TATA spare parts
379051004172	HANDHOLD TUBE ASSY	TATA spare parts
379051004176	STANCHIONS TUBE FOR PARTITION WALL 2021	TATA spare parts
379051004177	PARTITION WALL ASSEMBLY	TATA spare parts
379051004182	SANCTION TUBE FOR PARTITION WALL 2025	TATA spare parts
379051004267	TUBE ASSY FOR PASS STEP PARTITION WALL	TATA spare parts
379051004268	VERTICAL SUPPORT TUBE	TATA spare parts
379051063007	CONNECTING TUBE	TATA spare parts
379051063008	HAND HOLD TUBE ASSY	TATA spare parts
379051063012	HANDHOLD TUBE _LHD_ ENGINE HOOD	TATA spare parts
379051063013	ENGINE HOOD HAND HOLD TUBE-SABS-RHD	TATA spare parts
379051063070	HANDHOLD TUBE RHD ENGINEHOOD	TATA spare parts
379051064065	CONNECTING TUBE	TATA spare parts
379051064172	GRABRAIL TUBE-980	TATA spare parts
379051064179	HANDHOLD TUBE-1962.	TATA spare parts
379051064197	HAND HOLD TUBE - 1575MM	TATA spare parts
379051064335	PARTITION BEND TUBE OD 32	TATA spare parts
379051064417	PASS PARTATION TUBE	TATA spare parts
379051064420	STEP PARTITION TUBE	TATA spare parts
379051064421	DRIVER PARTITION TUBE	TATA spare parts
379051064422	DRIVER PARTATION TUBE	TATA spare parts
379051065017	TUBE FOR PARTITION WALL BS6	TATA spare parts
379051065030	HANDHOLD TUBE 715	TATA spare parts
379051065035	HAND HOLD TUBE -2090	TATA spare parts
379051065038	HANDHOLD TUBE-1248	TATA spare parts
379051065042	TUBE FOR PARTITION WALL	TATA spare parts
379051065043	HANDHOLD TUBE 703	TATA spare parts
379051065044	HANDHOLD TUBE 669	TATA spare parts
379051065048	HANDHOLD TUBE-1930	TATA spare parts
379051065052	TUBE FOR PARTITION-1847	TATA spare parts
379051184001	PARTITION WALL PROFILE	TATA spare parts
379051184002	PARTITION WALL PROFILE	TATA spare parts
379051184003	PARTITION WALL PROFILE	TATA spare parts
379051184004	PARTITION WALL PROFILLE TYPE 02	TATA spare parts
379051184006	PARTITION WALL PROFILE	TATA spare parts
379051184015	PARTITION WALL PROFILE-810	TATA spare parts
379051185001	PARTITION WALL PROFILE	TATA spare parts
379051214004	ALUMINIUM PROFILE-620	TATA spare parts
379051214008	ALUMINIUM PROFILE	TATA spare parts
379051214009	ALUMINIUM PROFILE	TATA spare parts
379051214014	ALUMINIUM PROFILE- FOR HOLDING PLYWOOD	TATA spare parts
379051214017	ALUMINIUM PROFILE-585	TATA spare parts
379051214018	ALUMINIUM PROFILE-757	TATA spare parts
379051214019	ALUMINIUM PROFILE	TATA spare parts
379051214020	ALUMINIUM PROFILE-254	TATA spare parts
379051214021	ALUMINIUM PROFILE-242	TATA spare parts
379051214022	ALUMINIUM PROFILE	TATA spare parts

379051214024	ALUMINIUM PROFILE	TATA spare parts
379051214025	ALUMINIUM PROFILE	TATA spare parts
379051214027	ALUMINIUM PROFILE-792	TATA spare parts
379051214052	ALUMINIUM PROFILE	TATA spare parts
379051214053	ALUMINIUM PROFILE	TATA spare parts
379051214056	ALUMINIUM PROFILE	TATA spare parts
379051214057	ALUMINIUM PROFILE	TATA spare parts
379051233002	PASTED GLASS 884X754	TATA spare parts
379051234001	GLASS	TATA spare parts
379051234002	DRIVER PARTITION WALL GLASS	TATA spare parts
379051234004	WALL GLASS BEHIND OF DRIVER	TATA spare parts
379051234007	WALL GLASS BEHIND OF DRIVER	TATA spare parts
379051234011	WALL GLASS FOR PARTITION	TATA spare parts
379051244001	PARTITION WALL WOOD	TATA spare parts
379051244004	PARTITION WALL WOOD	TATA spare parts
379051244008	PARTITION WALL	TATA spare parts
379051313007	32MM PIPE ROOF SOCKET(OPEN)	TATA spare parts
379051313010	HAND HOLD T BRACKET	TATA spare parts
379051313011	BASE BRACKET FOR 32MM DIA PIPE	TATA spare parts
379051313012	BASE BRACKET FOR 40 MM DIA PIPE	TATA spare parts
379051393009	GRAB RAIL PIPE 3040	TATA spare parts
379051393010	ENGINEHOOD HANDHOLD TUBE RHD_LOWERED	TATA spare parts
379051394001	HAND HOLD TUBE	TATA spare parts
379051395003	GRAB RAIL SUPPORT TUBE	TATA spare parts
379051404001	ALUMINIUM PROFILE	TATA spare parts
379052003009	PANEL PLATE ASSEMBLY	TATA spare parts
379052003011	HOOD ASSEMBLY	TATA spare parts
379052003015	CLUSTER & FLAP ASSY	TATA spare parts
379052003017	GEAR SHIFT LEVER TRIMMING PLATE	TATA spare parts
379052003036	FRP DASHBOARD ASSY _LHD-GEN 1	TATA spare parts
379052003040	FRP ENGINE HOOD ASSY	TATA spare parts
379052003045	FRP ENGINE HOOD ASSY LHD-GEN 1	TATA spare parts
379052003048	FRP DASHBOARD ASSY RHD LOWERED ENG	TATA spare parts
379052003049	FRP FRONT INNER ASSEMBLY RHD & LHD	TATA spare parts
379052003050	FRP FUSE BOX RHD ASSY	TATA spare parts
379052003051	FRP DASH BOARD ASSY	TATA spare parts
379052003052	FRP DASHBOARD ASSY	TATA spare parts
379052003053	FRP ENGINEHOOD ASSY 1512 RHD	TATA spare parts
379052003055	FRP FRONT INEER SW ASSY	TATA spare parts
379052003062	FRP DASHBOARD ASSY	TATA spare parts
379052003063	LCD TV BOX WITH VENT GRILL ASSY	TATA spare parts
379052003064	FRP SW FUSE BOX ASSEMBLY	TATA spare parts
379052003065	FRP FUSE BOX ASSEMBLY _LHD	TATA spare parts
379052003068	FRP FE AC DASHBOARD ASSY	TATA spare parts
379052003069	FRP FE AC ENGINEHOOD ASSY	TATA spare parts
379052003070	FRP 1512 SW DASHBOARD ASSY RHD	TATA spare parts
379052003071	PNEUMATIC DOOR BOX ASSY FRP 1210 REAR	TATA spare parts

379052003073	FRP 870 PNEUMATIC DOOR BOX ASSEMBLY	TATA spare parts
379052003074	PNEUMATIC JK DOOR BOX ASSY	TATA spare parts
379052003078	FRP 1512 DASHBOARD ASSY RHD	TATA spare parts
379052003079	ENGINE HOOD ASSY	TATA spare parts
379052003080	FRP ENGINEHOOD ASSEMBLY	TATA spare parts
379052003082	GEAR FINISHING COVER ASSEMBLY	TATA spare parts
379052003084	FRP FUSE BOX ASSEMBLY - LHD	TATA spare parts
379052003086	FRP SW 1618 LHD ENGINEHOOD ASSY	TATA spare parts
379052003088	FRP DASHBOARD ASSY RHD	TATA spare parts
379052003111	FRP DASHBOARD ASSY	TATA spare parts
379052003112	FRP ENGINE HOOD ASSY	TATA spare parts
379052003128	FRP_FUSE BOX ASSLY BS6	TATA spare parts
379052003138	FRP FRONT INNER ASSY.	TATA spare parts
379052003139	EV_9/12_FRONT DOOR COVER ASSEMBLY	TATA spare parts
379052003141	MCV_9X12_DASHBOARD & FLAPS ASSLY	TATA spare parts
379052003143	EV_9/12_FRONT INNER ASSEMBLY	TATA spare parts
379052003145	EV_9/12_MIDDLE DOOR COVER ASSEMBLY	TATA spare parts
379052003148	TOP_CABLE_COVER&PLATE_ASSY_9X12_EV	TATA spare parts
379052003150	VENT COVERING ASSY (LH) BS6	TATA spare parts
379052003151	VENT COVERING ASSY (RH) BS6	TATA spare parts
379052003153	MCV 9X12_FRONT INNER ASSEMBLY	TATA spare parts
379052003154	DASHBOARD & ENGINE HOOD ASSY_1613_CNG B	TATA spare parts
379052004001	ENGINE HOOD SUPPORT CHAIN	TATA spare parts
379052004002	RADIATOR MAINTENANCE TANK FLAP	TATA spare parts
379052004003	MAINTENANCE COVER	TATA spare parts
379052004006	RADIATOR MAINTENANCE TANK FLAP	TATA spare parts
379052004008	FRP RADIATOR FLAP ASSY_ LHD GEN 1	TATA spare parts
379052004009	ENGINE HOOD ASSEMBLY	TATA spare parts
379052004010	GLOVE BOX FLAP ASSEMBLY	TATA spare parts
379052004012	FRP RADIATOR FLAP ASSY-1512	TATA spare parts
379052004013	FRP ENGINE HOOD	TATA spare parts
379052004016	INT TV GLASS BKT WITH HINGE	TATA spare parts
379052004018	FRP SW FUSE BOX WITH BRACKET ASSY	TATA spare parts
379052004020	FRP FE RADIATOR FLAP ASSY	TATA spare parts
379052004021	FRP FE AC COMPRESSOR FLAP ASSY	TATA spare parts
379052004022	FRP FE AC ENGINEHOOD INTERNAL ASSY	TATA spare parts
379052004026	RADIATOR FLAP ASSY	TATA spare parts
379052004027	RADIATOR FLAP ASSY	TATA spare parts
379052004028	FRP AIR FILTER MAINT FLPA ASSY	TATA spare parts
379052004033	FRP SW 1618 LHD DSHBRD INSLTN CLAMP ASSY	TATA spare parts
379052004034	FRP SW 1618 LHD RADIATOR FLAP ASSY	TATA spare parts
379052004035	FRP SW 1618 LHD ENGINEHOOD INTERNAL ASSY	TATA spare parts
379052004036	SM BOX ASSEMBLY	TATA spare parts
379052004059	MCV EV 9/12 TOP SERVICE FLAP ASSLY	TATA spare parts
379052004061	MCV 9/12 FUSE BOX CLAMP ASSLY	TATA spare parts
379052004062	MCV 9X12 AUX INVTR FLAP CLAMP ASSLY	TATA spare parts
379052004063	MCV 9X12 DASHBOARD CLAMP ASSLY	TATA spare parts

379052063003	ENGINE HOOD EXTERNAL STAY ROD	TATA spare parts
379052063004	ENGINEHOOD EXT STAY ROD BUSH	TATA spare parts
379052083007	CNG VENT PIPE COVER FIXING PLATE BS6	TATA spare parts
379052083011	RADIO PANEL PLATE	TATA spare parts
379052083017	ENGINEHOOD EXT STAY ROD MOUNT PLATE	TATA spare parts
379052083030	CLUTCH OIL TANK COVER BASE PLATE	TATA spare parts
379052084012	ENGINE HOOD SUPPORT CHAIN	TATA spare parts
379052183011	IBDC CONTROLLER BOX-MSRTC	TATA spare parts
379052263005	WINDSHIELD FRONT COLUMN FINISHING	TATA spare parts
379052263006	WINDSHIELD FRONT COLUMN FINISHING	TATA spare parts
379052263007	DASHBOARD BASE	TATA spare parts
379052263011	¿A PILLAR-LH	TATA spare parts
379052263012	¿A PILLAR-RH	TATA spare parts
379052263014	FRP REAR INTERNAL FINISH -AC	TATA spare parts
379052263015	FRP NON MULTPX INSTRNT CUSTER BOX-LHD	TATA spare parts
379052263016	A PILLAR	TATA spare parts
379052263017	A PILLAR	TATA spare parts
379052263018	FRP NONMULTPX INSTRNT CUSTERBOX RHD	TATA spare parts
379052263022	MCV FRP REAR INNER W/O WINDSHIELD	TATA spare parts
379052263023	RP WINDSHIELD COLUMN FINISH-LH BS6	TATA spare parts
379052263024	RH A-PILLAR FOR LPO1613 BS6	TATA spare parts
379052263026	FRP 1512 SW A- PILLAR-LH	TATA spare parts
379052263033	FRP¿¿ INSTRUMENT CLUSTER BOX-RHD	TATA spare parts
379052263034	FRP GEAR FINISHING COVER	TATA spare parts
379052263036	FRONT INTERNAL EMERGENCY	TATA spare parts
379052263039	FRP STOP REQUEST COVER	TATA spare parts
379052263067	EV_9/12_HARNESS CABLE COVER	TATA spare parts
379052263068	MCV_9X12_A-PILLAR COVER-LH	TATA spare parts
379052263069	MCV_9X12_A-PILLAR COVER-RH	TATA spare parts
379052263070	CABLE_COVER_BOTTOM_MCV_9X12_EV	TATA spare parts
379052264002	ITINERARY COVER	TATA spare parts
379052264015	DASHBOARD	TATA spare parts
379052264016	FUSE BOX_ABOVE DRIVER_LHD	TATA spare parts
379052264021	DASHBOARD	TATA spare parts
379052264022	EXTERNAL ENGINE HOOD	TATA spare parts
379052264023	INTERNAL ENGINE HOOD	TATA spare parts
379052264024	EXTERNAL ENGINE HOOD	TATA spare parts
379052264027	FUSE BOX	TATA spare parts
379052264028	FUSE BOX FLAP	TATA spare parts
379052264029	DESTINATION BOARD FLAP	TATA spare parts
379052264030	DESTINATIN BOARD BOX	TATA spare parts
379052264031	FRP ENGINE HOOD EXTERNAL LHD-GEN-1	TATA spare parts
379052264032	FRP ENGINE HOOD INTERNAL -LHD-GEN-1	TATA spare parts
379052264033	FRP DASHBOARD BASE_LHD- GEN 1	TATA spare parts
379052264034	870 PNEUMATIC DOOR BOX (FRONT DOOR)-RHD	TATA spare parts
379052264037	FRP ENGINEHOOD EXTERNAL RHD	TATA spare parts
379052264038	FRP ENGINEHOOD INTERNAL RHD	TATA spare parts

379052264040	FRP FRONT INNER BOX LHD & RHD	TATA spare parts
379052264041	FRP FUSE BOX	TATA spare parts
379052264044	FRP FRONT INNER SW BS6	TATA spare parts
379052264047	FRP DASHBOARD	TATA spare parts
379052264050	FRP FE AC DASHBOARD 1618	TATA spare parts
379052264051	FRP FE ENGINEHOOD EXTERNAL	TATA spare parts
379052264052	FRP SW DASHBOARD RHD	TATA spare parts
379052264054	REAR PNEUMATIC DOOR BOX FLAP	TATA spare parts
379052264058	FRP 870 PNEUMATIC DOOR BOX FLAP	TATA spare parts
379052264069	FRP SW DASHBOARD RHD	TATA spare parts
379052264070	FRP SW 1618 LHD ENGINEHOOD EXTERNAL	TATA spare parts
379052264088	FRP ENGINE HOOD SPLIT PART	TATA spare parts
379052264093	FRP DRIVER FOOT STEP	TATA spare parts
379052265006	ITINERARY FLAP	TATA spare parts
379052265008	FRP RADIATOR FLAP EXTERNAL RHD GEN 1	TATA spare parts
379052265012	FRP RADIATOR FLAP EXTERNAL _LHD GEN 1	TATA spare parts
379052265013	FRP RADIATOR FLAP INTERNAL _LHD GEN 1	TATA spare parts
379052265017	FRP RADIATOR FLAP EXTERNAL	TATA spare parts
379052265018	FRP RADIATOR FLAP INTERNAL	TATA spare parts
379052265019	FRP ENGINEHOOD INTERNAL-1512-RHD	TATA spare parts
379052265020	FRP ENGINEHOOD EXTERNAL-1512-RHD	TATA spare parts
379052265023	FRP SW FUSE BOX RHD	TATA spare parts
379052265024	FRP SW FUSE BOX FLAP	TATA spare parts
379052265034	FRP BATTERY BOX CASING	TATA spare parts
379052283001	RUBBER INSULATION FOR GEAR LEVER	TATA spare parts
379052283002	INTERNAL INSULATION BOOT	TATA spare parts
379052294001	ELECTRIC POWER PLANT HOUSING	TATA spare parts
379052303004	MCV 9X12_ACRYLIC PLATE-DESTINATION	TATA spare parts
379052304006	MCV CLUCTH FLUID COVER	TATA spare parts
379052304007	PP FLAP LOCKING INTERNAL WASHER	TATA spare parts
379052304008	PP FLAP LOCKING EXTERNAL CAP	TATA spare parts
379052323001	PNEUMATIC HARNESS COVER ABS	TATA spare parts
379052323002	GEAR FINISHING SUPPORT BRACKET	TATA spare parts
379052323003	ABS CLUSTER FINISHING COVER	TATA spare parts
379052324003	ABS DRIVER FOOTSTEP	TATA spare parts
379052912047	DASHBOARD KEY ASSEMBLY LHD - AC	TATA spare parts
379052912163	ENGINEHOOD HANDHOLD FIT_LOWERED ENG RH	TATA spare parts
379053003010	HAT RACK ASSY (MOULDED TYPE)	TATA spare parts
379053003011	HAT RACK ASSY (MOULDED TYPE)	TATA spare parts
379053003014	CO DRIVER HAT RACK ASSY LH	TATA spare parts
379053003015	DRIVER HAT RACK ASSY	TATA spare parts
379053003031	HAT RACK ASSEY UPSRTC(DRIVER SIDE)	TATA spare parts
379053003032	HAT RACK ASSY UPSRTC(CO DRIVER)	TATA spare parts
379053003039	DRIVER SIDE HATRACK ASSEMBLY	TATA spare parts
379053003040	CO-DRIVER SIDE HATRACK ASSEMBLY	TATA spare parts
379053003041	DRIVER SIDE HATRACK ASSEMBLY	TATA spare parts
379053003042	CODRIVER SIDE HATRACK ASSEMBLY	TATA spare parts



379053003047	HATRACK PADDING ASSEMBLY	TATA spare parts
379053003065	HAT RACK-LP-1512 DOUBLE DOOR CO-DRIVER	TATA spare parts
379053003066	DRIVER SIDE HATRACK ASSY 6718MM	TATA spare parts
379053003067	CO-DRIVER HATRACK ASSEMBLY LH SIDE-2831	TATA spare parts
379053003068	DRIVER SIDE HATRACK ASSY 5102MM	TATA spare parts
379053214001	HAT RACK ALUMINIUM PROFILE	TATA spare parts
379053324001	HATRACK END COVER RH	TATA spare parts
379053324002	HATRACK END COVER LH	TATA spare parts
379054063001	WINDOW GUARD RAILS	TATA spare parts
379054063002	WINDOW GUARD RAILS	TATA spare parts
379054063003	WINDOW GUARD RAILS	TATA spare parts
379054063004	WINDOW GUARD RAILS	TATA spare parts
379054063005	WINDOW GUARD RAILS	TATA spare parts
379054063006	WINDOW GUARD RAILS	TATA spare parts
379054063007	WINDOW GUARD RAIL TUBE-1	TATA spare parts
379054063008	WINDOW GUARD RAIL TUBE-2	TATA spare parts
379054063009	WINDOW GUARD RAIL TUBE-3	TATA spare parts
379054063010	WINDOW GUARD RAIL TUBE-4	TATA spare parts
379054063012	WINDOW GUARD RAIL TUBE-6	TATA spare parts
379054063029	19MM GUARD RAIL TUBE	TATA spare parts
379054063030	WINDOW GUARD RAIL TUBE-DIA19.05 4591	TATA spare parts
379054063031	WINDOW GUARD RAIL TUBE DIA19.05 822	TATA spare parts
379054063034	WINDOW GUARD RAIL TUBE DIA19.05 1476	TATA spare parts
379054063035	WINDOW GUARD RAIL TUBE DIA19.05 1560MM	TATA spare parts
379054063037	WINDOW GUARD RAIL TUBE DIA19.05 2205MM	TATA spare parts
379054063044	GUARD RAIL TUBE DIA 19.5X2280	TATA spare parts
379054063045	WINDOW GUARDRAIL DIA 19.5X2820	TATA spare parts
379054063046	WINDOW GUARD RAIL TUBE DIA19.05 2940	TATA spare parts
379054063047	WINDOW GUARD RAIL TUBE DIA19.05 1450 LG	TATA spare parts
379054063051	GUARD RAIL-DIA 19.05-3300	TATA spare parts
379054063052	GUARD RAIL DIA 19.05 4500 LG	TATA spare parts
379054063053	GUARD RAIL DIA 19.05 4680 LG	TATA spare parts
379054063054	GUARD RAIL DIA 19.05 1985 LG	TATA spare parts
379054063069	WINDOW GUARD RAIL TUBE DIA19.05 820MM	TATA spare parts
379054063071	WINDOW GUARD RAIL TUBE DIA19.05_5275MM	TATA spare parts
379054063072	WINDOW GUARD RAIL TUBE DIA19.05_1000MM	TATA spare parts
379054063082	WINDOW GUARD RAIL TUBE DIA19.05_930MM	TATA spare parts
379054214001	WINDOW GUARD RAIL BRACKET BS6	TATA spare parts
379054214002	WINDOW GUARD RAIL BRACKET BS6	TATA spare parts
379056083463	DRIVER PARTITION PANELING-1100X611	TATA spare parts
379056083464	DRIVER PARTITION PANELING-1099X1078	TATA spare parts
379056083465	DRIVER PARTITION PANELING-1129X1080	TATA spare parts
379056083466	DRIVER PARTITION PANELING-1100X592	TATA spare parts
379056083512	DRIVER PARTITION PANELING1	TATA spare parts
379056083513	DRIVER PARTITION PANELING2	TATA spare parts
379056083514	DRIVER PARTITION PANELING3	TATA spare parts
379056083515	DRIVER PARTITION PANELING4	TATA spare parts

379058002001	REAR LICENCE PLATE ASSLY	TATA spare parts
379058003001	REAR LICENCE PLATE WITH HINGE	TATA spare parts
379058183004	FRONT BUMPER LIC PLATE - D	TATA spare parts
379058184001	FRONT LICENCE PLATE	TATA spare parts
379058323001	MCV EV_FRONT DOOR CANOPY BS6	TATA spare parts
379058333001	JNNURM STICKER_RESLF_MCV_BMTC	TATA spare parts
379058333002	JNNURM LOGO	TATA spare parts
379058333003	JNNURM STICKER MCV	TATA spare parts
379058333004	EXTERNAL STICKER RH	TATA spare parts
379058333005	EXTERNAL STICKER LH	TATA spare parts
379058333006	FRONT EXTERNAL STICKER	TATA spare parts
379058333007	TOP EXTERNAL STICKER	TATA spare parts
379058333008	INTERNAL STICKER	TATA spare parts
379058333009	LOGO OF?? BUS	TATA spare parts
379058333010	JNNURM LOGO WHITE & RED REFLECTIVE	TATA spare parts
379058912013	REAR LICENCE PLATE ASSY	TATA spare parts
379058912017	REAR LICENCE PLATE ASSLY	TATA spare parts
379058962001	FE COACH GREY & SILVER DECAL KIT RH & LH	TATA spare parts
379058963001	INTERNAL STICKERS	TATA spare parts
379058963002	SEAT NUMBERING STICKERS_52WB	TATA spare parts
379058963003	SEAT NUMBERING STICKERS 42WB	TATA spare parts
379058963004	IN?? OUT EXTERNAL STICKERS	TATA spare parts
379059003009	SUGGESTION BOX ASSEMBLY DETAIL	TATA spare parts
379059003010	ROLLER TYPE SUNVISOR-800MM	TATA spare parts
379059003015	SLB GUARD RAIL RUBE ASSY.	TATA spare parts
379059003018	SUN VISOR ROLLER TYPE	TATA spare parts
379059003031	DESTINATION BOARD BOX ASSEMBLY	TATA spare parts
379059003032	DESTINATION DISPLAY BOARD PANEL ASSEMBLY	TATA spare parts
379059003035	DUCT PANEL ASSY-HV	TATA spare parts
379059003036	DUCT PANEL ASSY-LV	TATA spare parts
379059083002	BRACKET FOR TRADITIONAL STEEL BELL	TATA spare parts
379059213001	AL PROFILE BS6	TATA spare parts
379059263001	BOTTOM COVER-HV	TATA spare parts
379059303005	PLASTIC ROPE - GREY DIA 8MM	TATA spare parts
379059323003	ABS FINISHING COVER FOR REAR STOP LAMP	TATA spare parts
379059323034	MIDDLE COVER-HV	TATA spare parts
379059323035	BOTTOM COVER-LV	TATA spare parts
379059323036	MIDDLE COVER-LV	TATA spare parts
379059323037	MCV 9X12-TOP HV CABLE COVER	TATA spare parts
379059324001	HANOVER DISPLAYS CONTROLER COVER	TATA spare parts
379059324003	FE PARTITION DOOR FINISHING COVER ABS	TATA spare parts
379059333001	MARCOPOLO EMBLEM	TATA spare parts
379059333009	AUTOMATIC DOOR	TATA spare parts
379059333010	FIRE EXTINGUISHER STICKER	TATA spare parts
379059333011	EMERGENCY EXIT	TATA spare parts
379059333013	SCHOOL_BUS_STICKER_MCV_ENGLISH	TATA spare parts
379059333014	SCHOOL_BUS_STICKER_MCV_ENGLISH_SMALL	TATA spare parts

379059333015	STAR BUS DECAL FOR 55WB LHD	TATA spare parts
379059333017	STARBUS STICKER	TATA spare parts
379059333018	SUGGESTION STICKER BS6	TATA spare parts
379059333019	STAR BUS DECAL FOR 62WB	TATA spare parts
379059333027	EMERGENCY EXIT STICKER BS6	TATA spare parts
379059333028	EMERGENCY EXIT STICKER BS6	TATA spare parts
379059333029	EMERGENCY DOOR EXIT STICKER BS6	TATA spare parts
379059333031	EMERGENCY EXIT STICKER BS6	TATA spare parts
379059333032	STICKER FOR LIFT HANDLE TO UNLOCK BS6	TATA spare parts
379059333033	EMERGENCY DOOR STICKER EXTERNAL BS6	TATA spare parts
379059333035	EMEGENCY STICKER TO BREAK THE GLASS BS6	TATA spare parts
379059333036	MARCOPOLO RESINED STICKER BS6	TATA spare parts
379059403001	CITY FEB TEX 1170X780	TATA spare parts
379059403002	CITY FEB TEX (INDIA) 1170X580	TATA spare parts
379059963001	SUNVISOR ASSEMBLY	TATA spare parts
379059963002	MSRTC DECAL KIT PART	TATA spare parts
379060002013	MOTORISED RVM _LH_ PACOLINE _24V	TATA spare parts
379060002014	MOTORISED RVM _RH_ PACOLINE _24V	TATA spare parts
379060003002	REAR VIEW MIRROR SUPPORT PASSENGER SIDE	TATA spare parts
379060003003	RVM BRACKET LEFT	TATA spare parts
379060003004	REAR VIEW MIRROR SUPPORT DRIVER SIDE RHD	TATA spare parts
379060003007	REAR VIEW MIRROR SUPPORT-DRIVER SIDE LHD	TATA spare parts
379060003008	REAR VIEW MIRROR SUPPORT-PASNGR LHD BUS	TATA spare parts
379060003010	EXT.RVM RH LH BO66 ASSY COACH	TATA spare parts
379060003011	EXTERNAL REAR VIEW MIRROR RH & LH ASSY	TATA spare parts
379060003022	MCV SUNVISER BRACKET ASSEMBLY BS6	TATA spare parts
379060004002	RVM MIRROR SUPPORT ASSY	TATA spare parts
379060084001	MIRROR HOLDING ARM BRACKET	TATA spare parts
379060233001	AUXILIARY MIRROR ASSEMBLY _PIPL	TATA spare parts
379060912003	MIRROR AND SUN SHADE ASSEMBLY DETAILS	TATA spare parts
379060963001	SUNVISOR ASSEMBLY	TATA spare parts
379061002022	SEAT LAYOUT 49+1D SEATER-MCV-LPO1618 LHD	TATA spare parts
379061003010	2 SEATER ON FRONT WHEEL ARCH (RH SIDE)	TATA spare parts
379061003011	2 SEATER NEXT TO FRONT WHEEL ARCH (RH)	TATA spare parts
379061003012	2 SEATER ON RH SIDE	TATA spare parts
379061003014	REAR CENTRAL SINGLE SEATER	TATA spare parts
379061003015	2 SEATER ON LH SIDE	TATA spare parts
379061003018	SINGLE SEATER ON FRONT WHEEL ARCH (LH)	TATA spare parts
379061003019	SINGLE SEATER AT LEFT SIDE	TATA spare parts
379061003021	2 _SEATER_ _RH_ _SIDE_ _NEXT_ _TO_ _FRONT_ _WHEELAR	TATA spare parts
379061003023	2 SEATER ON LH SIDE	TATA spare parts
379061003027	2 SEATER ON RH SIDE	TATA spare parts
379061003032	2 SEATER NEXT TO WHEEL ARCH (LH SIDE)	TATA spare parts
379061003033	2 SEATER NEXT TO WHEEL ARCH (RH SIDE)	TATA spare parts
379061003034	SINGLE SEATER LEFT SIDE WITH SEAT BELT	TATA spare parts
379061003035	2 SEATER ON RH SIDE _WITH LAP BELT	TATA spare parts
379061003060	LH 2 SEATER ON WH_200MMCH_AR&LB_BMTC N	TATA spare parts

379061003061	RH STD 2 SEATER_460MMCH_AR&LB_BMTC MCV	TATA spare parts
379061003062	RH 2 SEATER ON WH_200MMCH_AR&LB_BMTC N	TATA spare parts
379061003063	RH 1 SEATER ON WH_200MMCH_AR&LB_BMTC N	TATA spare parts
379061003064	LH 1 SEATER ON WH_200MMCH_AR&LB_BMTC N	TATA spare parts
379061003075	LH 3 SEAT_560CH_SM2L_AR_LB(1220W)	TATA spare parts
379061003076	LH 3 SEAT 465CH_SM2L(1220W)	TATA spare parts
379061003077	LH 3 SEAT 465CH_SM2L_285SL(1220W)	TATA spare parts
379061003078	LH 3 SEAT 560CH_SM2L_380SL(1220W)	TATA spare parts
379061003079	RH 2 SEAT 560CH_SM1L_380SL_(810W)	TATA spare parts
379061003080	RH 2 SEAT 560CH_SM1L_AR_LB(810W)	TATA spare parts
379061003081	RH 1 SEAT 360CH 2L_AR_LB_(400W)	TATA spare parts
379061003085	LH 2 SEAT_435HT_SM1L_AR_W/O REXINE	TATA spare parts
379061003089	RH 2 SEAT_435HT_SM1L_AR_W/O REXINE	TATA spare parts
379061003093	LH 1 SEAT_286CH_LB_FWA_VSPL HB_400W	TATA spare parts
379061003094	LH 1 SEAT_390CH_LB_FWA_VSPL HB_400W	TATA spare parts
379061003095	LH 2 SEAT_256CH_LB_RWA_VSPL HB_810W	TATA spare parts
379061003096	LH 2 SEAT_545CH_LB_ULEG_RWA_VSPL HB_810W	TATA spare parts
379061003097	REAR 3 SEATER_LB_ON RLB_VSPL HB_1200W	TATA spare parts
379061003098	RH 3 SEAT_446CH_LB_VSPL HB_1200W	TATA spare parts
379061003099	RH 3 SEAT_545CH_LB_ULG_RWA_VSPL HB_1200W	TATA spare parts
379061003100	RH 3 SEAT_446CH_LB_CLG_RWA_VSPL HB_1200W	TATA spare parts
379061003101	RH 2 SEAT_390CH_LB_FWA_VSPL HB_810W	TATA spare parts
379061003104	RH 2 SEAT_360CH 2L_AR_LB(810W)	TATA spare parts
379061003105	LH 3 SEAT 560CH_SM2L(1220W)	TATA spare parts
379061003106	RH 3 SEAT 465CH_SM2L(1220W)	TATA spare parts
379061003107	RH 2 SEAT 560CH_SM1L(810W)	TATA spare parts
379061003108	RH 2 SEAT 465CH_SM1L_285SL_(810W)	TATA spare parts
379061003109	RH 2 SEAT 465CH_SM1L(810W)	TATA spare parts
379061003110	MECHANICAL SUSPENDED DRIVER SEAT_LHD	TATA spare parts
379061003113	RH 1 SEAT_340CH 2LM_AR_W/O REXINE	TATA spare parts
379061003114	RH 1 SEAT_560CH_SM1L_AR_W/O REXINE	TATA spare parts
379061003115	RH 2 SEAT_340CH 2LM_AR_W/O REXINE	TATA spare parts
379061003116	RH 2 SEAT_560CH_SM1L_AR_W/O REXINE	TATA spare parts
379061003117	REAR 2 SEAT_435CH 2LM_W/O REXINE	TATA spare parts
379061003118	LH 2 SEAT_340CH 2LM_AR_W/O REXINE	TATA spare parts
379061003119	1 SEAT_250CH 2LM_2AR_W/O REXINE	TATA spare parts
379061003125	RH 1 SEAT_385HT_SM1L_LB_FWA_DUBAI	TATA spare parts
379061003126	RH 2 SEAT_460HT_SM1L_1LB_DUBAI	TATA spare parts
379061003127	RH 2 SEAT_460HT_SM1L_DUBAI	TATA spare parts
379061003128	RH 2 SEAT_405HT_SM1L_RWA_DUBAI	TATA spare parts
379061003130	LH 2 SEAT_460HT_SM1L_DUBAI	TATA spare parts
379061003131	LH 2 SEAT_460HT_2LM_ED_DUBAI	TATA spare parts
379061003132	LH 2 SEAT_405HT_SM1L_RWA_DUBAI	TATA spare parts
379061003133	LH 2 SEAT_460HT_SM1L_2LB_DUBAI	TATA spare parts
379061003135	RH 2 SEAT (810W)	TATA spare parts
379061003136	LH 3 SEAT (1220W)	TATA spare parts
379061003137	LH 3 SEAT (1220W)	TATA spare parts

379061003138	LH 2 SEAT (810W)	TATA spare parts
379061003139	SINGLE SEAT RH FRONT	TATA spare parts
379061003140	RH 1 SEAT (810W)	TATA spare parts
379061003141	LH 3 SEAT (1230W)	TATA spare parts
379061003145	RH 1 SEAT 360CH SM1L AR LB	TATA spare parts
379061003146	RH 3 SEAT 450CH SM2L AR 2LB	TATA spare parts
379061003147	RH 3 SEAT 450CH SM2L AR	TATA spare parts
379061003148	RH 3 SEAT F450/W270CH SM2L AR	TATA spare parts
379061003149	RH 3 SEAT F540/W360CH SM2L AR	TATA spare parts
379061003150	RH 3 SEAT 450CH 3LM AR	TATA spare parts
379061003151	RH REAR 3 SEAT 450CH SM2L AR	TATA spare parts
379061003152	LH REAR 2 SEAT 450CH SM1L AR	TATA spare parts
379061003153	LH 2 SEAT F540/W360CH SM1L AR	TATA spare parts
379061003154	LH 2 SEAT F450/W270CH SM1L AR	TATA spare parts
379061003155	LH 2 SEAT 450CH SM1L AR 1LB	TATA spare parts
379061003156	LH 1 SEAT 360CH SM1L AR LB	TATA spare parts
379061003161	BH.3 SEAT_460HT_SM1_DUBAI	TATA spare parts
379061003163	RH 2SEATERç HB 810W	TATA spare parts
379061003164	RH 3SEATERç HB 1200W	TATA spare parts
379061003165	RH 3SEATERç HB 1200W. ON WH 266	TATA spare parts
379061003166	RH 3 SEAT 540CH SM1S1HLç HB 1200W	TATA spare parts
379061003167	LH 1SEATERç HB 400 LB ARMREST	TATA spare parts
379061003168	LH 3SEATERç HB 1200W	TATA spare parts
379061003169	LH 2SEATERç HB 810W	TATA spare parts
379061003170	LH 2SEATERç HB 810W. ON WH 360	TATA spare parts
379061003171	LH 2SEATERç HB 810W. ON WH 266	TATA spare parts
379061003179	GROUP ASSLY SEATSçç MCV	TATA spare parts
379061003191	LH 2 SEAT 442CH SM1NL 1LBç HB 810W	TATA spare parts
379061003192	RH 3 SEAT 442CH SM2NL 1LBç HB 1200W	TATA spare parts
379061003207	RH 3 SEAT 442CH 3NLM HB 1200W	TATA spare parts
379061003246	RH 1 SEAT_400W410CH350D_SM1L_LB	TATA spare parts
379061003247	RH 2 SEATER_800W465CH350D_SM1L_LB	TATA spare parts
379061003248	RH 2 SEATER_800W465CH350D_SM1L	TATA spare parts
379061003249	RH 2 SEATER_800W410CH350D_SM1L	TATA spare parts
379061003250	REAR 3 SEATER_ON RLB_1200W350D	TATA spare parts
379061003251	LH 3 SEATER_1200W465CH350D_SM2L	TATA spare parts
379061003252	LH 3 SEATER_1200W465CH350D_SM1SL	TATA spare parts
379061003253	LH 2 SEATER_800W465CH350D_SM1L_1LB	TATA spare parts
379061003259	LH 3 SEATER_1200W465CH350D_SM2L_1LB	TATA spare parts
379061003262	REAR 3 SEATER_ON RLB_1200W350D_3LB	TATA spare parts
379061003275	RH 3 SEAT 442CH AR SM2L 221çç HB	TATA spare parts
379061003276	BENCH SEAT 460CH 2BL 2SL HB	TATA spare parts
379061003283	BENCH SEAT/BIRTH FRAME ASSY 1600X450MM	TATA spare parts
379061003291	RH 2 PLASTIC SEAT 360CH SM1L LB AR	TATA spare parts
379061003297	LH 1 PLASTIC SEAT 410CH SM1L AR	TATA spare parts
379061003298	LH 1 PLASTIC SEAT 240CH SM1L LB AR	TATA spare parts
379061003303	RH 3SEAT 540CH AR SM1NL2UL WBH HB	TATA spare parts

379061003304	RH 3 SEAT 442CH AR SM2L WBH HB	TATA spare parts
379061003305	RH 3 SEAT 442CH SM2NL HB WBH 1200W	TATA spare parts
379061003306	RH 3SEAT 540CH SM1S1HL HB WBH 1200W	TATA spare parts
379061003307	RH 3 SEAT 442CH 3NLM HB WBH 1200W	TATA spare parts
379061003308	LH 2 SEAT 442CH SM1NL HB WBH 810W	TATA spare parts
379061003309	LH 2 SEAT 540CH 2UL HB WBH 810W	TATA spare parts
379061003310	LH 2 SEAT 360CH SM1SL HB WBH 810W	TATA spare parts
379061003319	RH 2 SEAT DLX 1025W 3AR&LP FE.CH	TATA spare parts
379061003320	RH 2 SEAT DLX 1025W 3AR FE.CH	TATA spare parts
379061003321	REAR RH 2 SEAT DLX 1000W 3AR FE.CH	TATA spare parts
379061003322	REAR LH 2 SEAT DLX 1000W 3AR FE.CH	TATA spare parts
379061003323	REAR MID 1 SEAT LP DLX FE.COACH	TATA spare parts
379061003324	LH 2 SEAT DLX 1025W 3AR FE COACH	TATA spare parts
379061003325	LH 2 SEAT DLX 1025W 3AR 1LP FE.CH	TATA spare parts
379061003326	LH 1 SEAT DLX 1AR LP FE.CH	TATA spare parts
379061003327	DRIVER SEAT_RHD-MECHANICAL SUSPENDED	TATA spare parts
379061003328	DRIVER BED SEAT FE COACH	TATA spare parts
379061003329	CO DRIVER FOLDABELE SEAT FE COACH	TATA spare parts
379061003339	RH 2 SEAT DLX 1025W 3AR 2LM	TATA spare parts
379061003345	RH 2 SEATER 450CH SM1NL HB 810W	TATA spare parts
379061003348	LH 1 SEAT 450CH SM1NL AR LB HB 410W	TATA spare parts
379061003349	SH 2 PLASTIC SEAT 410CH SM1L AR WH	TATA spare parts
379061003350	LH 2 PLASTIC SEAT 410CH SM1L AR WH	TATA spare parts
379061003351	LH 2 PLASTIC SEAT 360CH SM1L AR WH	TATA spare parts
379061003352	RH 2 SEAT DLX 1025W 3AR	TATA spare parts
379061003354	REAR 2SEAT 460CH 810W 2LM PMS CVG	TATA spare parts
379061003356	LH 2 SEAT DLX 1025W 3AR	TATA spare parts
379061003357	LH 2 SEAT DLX 1025W 3AR 2LB	TATA spare parts
379061003367	REAR RH 3 SEAT 442CH SM2NL HB 1200W	TATA spare parts
379061003382	RH3SET 442H SMNL 1CL 1LB AR HB 1250W	TATA spare parts
379061003383	RH 3SEAT 442CH SM1SL 1CL WH HB 1200W	TATA spare parts
379061003384	LH 2 SEAT 391CH SM1SL WH HB 810W	TATA spare parts
379061003385	LH 1 SEAT 391CH SM1SL AR WH HB 410W	TATA spare parts
379061003388	RH 3 SEAT 442CH SM2LG 1CL HB 1200W	TATA spare parts
379061003389	RH 2SEAT DLX 1025W 3AR&LP BLUE FAB	TATA spare parts
379061003390	RH 2 SEAT DLX 1025W 3AR BLUE FAB	TATA spare parts
379061003395	LH 2SEAT DLX 1025W 3AR BLUE FAB	TATA spare parts
379061003407	RR RH 2SEAT DLX 990W 2AR BLUE FAB	TATA spare parts
379061003408	REAR MID 1 SEAT LP 2LM DLX BLUE FAB	TATA spare parts
379061003409	RR LH 2SEAT DLX 990W 2AR BLUE FAB	TATA spare parts
379061003410	LH 2SEAT DLX 1025W 3AR&LP BLUE FAB	TATA spare parts
379061003421	LH 1 SEATER 545W 2LM 3PLB 2AR	TATA spare parts
379061003422	RH 2 SEATER 1025W 2LM 3PLB 3AR	TATA spare parts
379061003423	REAR 5 SEAT 4LM 3PLB 6AR	TATA spare parts
379061003424	LH 2 SEATER 1025W 2LM 3PLB 3AR	TATA spare parts
379061003443	BOX TYPE BENCH SEAT FRAME ASSY	TATA spare parts
379061003444	BENCH TOP CUSHION ASSY 1245X445MM	TATA spare parts

379061003449	RH 1 SEATER_HB RECLINING_1SM1LGM_LB	TATA spare parts
379061003450	SH 2 SEATER_HB_LB_810W_1SM1LGM_DUBAI	TATA spare parts
379061003451	RH 2 SEATER_HB_810W_1SM1LGM_DUBAI	TATA spare parts
379061003452	RH 3 HB SEATER_1200W_1SM2LGM_LB_DUBAI	TATA spare parts
379061003453	LH 3 HB SEATER_1200W_1SM2LGM_DUBAI	TATA spare parts
379061003454	LH 3 HB SEATER_3LGM_1200W_DUBAI	TATA spare parts
379061003455	LH 3 HB SEATER_2LGMISM_1200W_1LB_DUBAI	TATA spare parts
379061003456	LH 2 SEATER_HB RECLINING_2LGM	TATA spare parts
379061003459	REAR LH 3 SEATER_1200W_SM2L_HB	TATA spare parts
379061003483	DRIVER BERTH ASYç 53WB	TATA spare parts
379061003552	RH 2 PLASTIC SEAT 460CH SM1LM 890W	TATA spare parts
379061003553	LH 2 PLASTIC SEAT 460CH SM1LM 890W	TATA spare parts
379061003554	RAER 2 PLASTIC SEAT 460CH 2LM 830W	TATA spare parts
379061003555	RAER MID 2 PMS 460CH 2LM LB 830W	TATA spare parts
379061003558	RH 2SEAT 500CH 810W PMS 1SM1LG	TATA spare parts
379061003560	LH 2SEAT 360CH 90SM1L 810 WH AR PMS	TATA spare parts
379061003561	SEAT RH 3 446CH SMNL 1CL AR JCIB 1250W	TATA spare parts
379061003562	SEAT RH3 446CH SM2NL JC HB 1200W	TATA spare parts
379061003563	SEAT RH3 446CH SMNL 1CL JCIB 1200W	TATA spare parts
379061003565	SEAT RH3 446CH 3LM AR JC HB 1200W	TATA spare parts
379061003566	SEAT LH 2 391CH SM1NL JCIB 810W	TATA spare parts
379061003567	SEAT LH 2 446CH SM1NL JCIB 810W	TATA spare parts
379061003569	SH3SET 446CH SMNL 1CL AR CVGIB 1250W	TATA spare parts
379061003570	RH3SEAT 446CH SM2NL CVG HB 1200W	TATA spare parts
379061003571	RH3SET 446CH SMNL 1CL CVGIB 1200W	TATA spare parts
379061003572	RH3SEAT_446CH_3LM_CVGHB_1200W	TATA spare parts
379061003573	RH3SEAT 446CH 3LM AR CVGHB 1200W	TATA spare parts
379061003574	LH2SEAT 391CH SM1NL CVGIB 810W	TATA spare parts
379061003575	LH2SEAT 446CH SM1NL CVGIB 810W	TATA spare parts
379061003576	LH1SEAT 446CH SM1SL AR CVGIB 410W	TATA spare parts
379061003578	3SEATER BIRTH WITH TOPMOUNTING CVG	TATA spare parts
379061003583	SEAT RH3 446CH 3LMNL 1CL JCIB 1200W	TATA spare parts
379061003584	RH3SET 446CH 3LMNL 1CL CVGIB 1200W	TATA spare parts
379061003585	CHAIN BRT. ASSLY FOR REAR BERTH	TATA spare parts
379061003586	CHAIN BRT. ASSLY FOR REAR BERTH	TATA spare parts
379061003588	RH 2SEAT 500CH 850W PMS 1SM1LG CVG	TATA spare parts
379061003598	RH 2 SEAT_460CH_SM1L_850W/O AR_PLSC	TATA spare parts
379061003599	2 SEATER WH 850W 2LGM CVG	TATA spare parts
379061003600	LH 2SEAT 460CH SM1L 850W/O AR PLSC(CVG)	TATA spare parts
379061003606	RH 2 360CH 810 90SM1L WH LP AR PMS	TATA spare parts
379061003607	RH 2SEAT 360CH 810 90SM1L WH AR PMS	TATA spare parts
379061003608	RH 2SEAT 412CH 810 WH AR 132SM1L PMS	TATA spare parts
379061003609	LH 2SEAT 412CH 810 WH 132SM1L PMS	TATA spare parts
379061003612	REAR 6SEATER_2450W_BENCH SEAT ASSY_CVG	TATA spare parts
379061003614	RH3SET 360CH SMNL 1CL AR CVGIB 1250W	TATA spare parts
379061003618	RH3SET 360CH 3LMNL 1CL CVGIB 1200W	TATA spare parts
379061003620	REAR 6SEATER 2450W 4LM SEAT ASSY CVG	TATA spare parts

379061003622	LH2SEAT 360CH SM 1CL CVGIB 810W	TATA spare parts
379061003624	LH2SEAT 446CH SM 1LM CVGIB 810W	TATA spare parts
379061003638	LH1SEAT 446CH 2LM AR CVGIB 410W	TATA spare parts
379061003672	REAR LH 3 442CH SM2NL 6DEG CVG HB 1200W	TATA spare parts
379061003673	REAR RH 3 442CH SM2NL 6DEG CVG HB 1200W	TATA spare parts
379061003674	MECH SUS DRI SEAT LHD HSSL_RELI BLUE FAB	TATA spare parts
379061003746	RR RH 2SEAT DLX 990W 2AR BLUE GREY	TATA spare parts
379061003747	RR MID 1 SEAT LP 2LM DLX BLUE GREY	TATA spare parts
379061003748	RR LH 2SEAT DLX 990W 2AR BLUE GREY	TATA spare parts
379061003757	RH 3SEAT SM/391L/446L HB 1200W	TATA spare parts
379061003769	RH 2 SEATER 500CH 850W PMS 1SM1LG AR CVG	TATA spare parts
379061003770	LH 2 SEATER 500CH 850W PMS 1SM1LG AR CVG	TATA spare parts
379061003771	RH 2 SEATER ON WH 850W 2LGM AR CVG	TATA spare parts
379061003772	LH 2 SEATER ON WH 850W 2LGM AR CVG	TATA spare parts
379061003773	RH 2 SEATER_460CH_SM1L_850W_AR	TATA spare parts
379061003774	LH 2 SEATER 460CH SM1L 850W AR CVG	TATA spare parts
379061003873	2RH SIDE MOUNT 1LEG 490CH1025W AR LB BS1	TATA spare parts
379061003874	2RH SM1L 490CH1025W AR BS13FB PB CVG	TATA spare parts
379061003875	2RR 260CH1000W AR RLB BS13FB PB CVG	TATA spare parts
379061003876	1RM 260CH430W BS13FB RLB PB CVG	TATA spare parts
379061003877	CO DR.FOLDABLE SEAT_FBBS13_CVG	TATA spare parts
379061003878	2LH SM1L 490CH1025W AR BS13FB PB CVG	TATA spare parts
379061003879	2LH SM1L 490CH1025W AR LB BS13FB PB CVG	TATA spare parts
379061003880	2RH 2LM 490CH1025W AR BS13FB PB CVG	TATA spare parts
379061003887	2LH 1SM1LM 460CH850W VN HB2 NDX CVG BS6	TATA spare parts
379061003888	2LH 1SM1LM 460CH850W 1LB VN HB2 NDX CVG	TATA spare parts
379061003889	1LH 2LM 460CH410W AR VN HB2 NDX CVG BS6	TATA spare parts
379061003890	2RH 1SM1LM 460CH850W AR VN HB2 NDX CVG B	TATA spare parts
379061003891	2RH 1SM1LM 460CH850W VN HB2 NDX CVG BS6	TATA spare parts
379061003894	2RH 2LM 460CH850W AR VN HB2 ED NDX CVG B	TATA spare parts
379061003918	1LH 2LM 460CH410W AR VN HB2 LB NDX CVG B	TATA spare parts
379061003959	2RH 2LM 415C850W STER SEAT	TATA spare parts
379061003960	2LHRH 2LM 115C850W WH STER SEAT	TATA spare parts
379061003963	2LH 2LM 415C850W LP STER SEAT	TATA spare parts
379061003964	2RH 2LM 415C850W AR STER SEAT	TATA spare parts
379061003965	2LHRH 2LM 115C850W LB STER SEAT	TATA spare parts
379061003991	2RM 2L 350C810W LP STER	TATA spare parts
379061003992	2RL RR 2L 350C810W STER	TATA spare parts
379061003993	2LHRH 2L 250C850W LP STER	TATA spare parts
379061003995	2RHLH 2L 350C850W STER	TATA spare parts
379061004005	BERTH SEAT LOCK CATCHER	TATA spare parts
379061004017	WHEEL CHAIR BELTS	TATA spare parts
379061084009	TOP HOOK	TATA spare parts
379062003002	ROOF HATCH	TATA spare parts
379062003005	AIR INTAKE FRAME WITH EMERGENCY EXIT	TATA spare parts
379062003006	HOLDER ASSY	TATA spare parts
379062003015	ROOF HATCH ASSEMBLY BS6	TATA spare parts



379062004002	SOLID RUBBER PROFILE	TATA spare parts
379062004010	HANDLE MODUS L TYPE	TATA spare parts
379062084003	FIRE EXTINGUISHER BRACKET	TATA spare parts
379062184001	AL PROFILE 780	TATA spare parts
379062263001	ROOF EXTERNAL CONTOUR(SIMBA)	TATA spare parts
379062263002	AIR HATCH CONTOUR(SIMBA)	TATA spare parts
379062912007	FIRE SUPPRESSION SYSTEM	TATA spare parts
379062912015	FRP ROOF HATCH ASSEMBLY	TATA spare parts
379062963004	EV-9/12 FDAS KIT FOR PANELING STAGE	TATA spare parts
379062963005	EV-9/12 FDAS EV-BYPASS KIT	TATA spare parts
379062963006	SAFEX TRIM KIT	TATA spare parts
379063283001	HARNESS PROTECTION RUBBER	TATA spare parts
379064003002	LH PASS.DOOR 610X640 SLIDING SERVICE CLR	TATA spare parts
379064003005	LIFT WIND_1077X870_50PERCGRAY TNT SLDG	TATA spare parts
379064004009	GLASS ASSEMBLY & SUB PARTS_HINGED	TATA spare parts
379064233005	PASTED GLASS_LH_5X384X910MM	TATA spare parts
379064233006	PASTED GLASS LH_446X888_CLEAR	TATA spare parts
379064233007	PASTED GLASS 1345X387MM	TATA spare parts
379064233008	PASTED GLASS LH 1525X1155_50PERCGREY	TATA spare parts
379064233009	PASTED GLASS 335X1155MM_CLEAR	TATA spare parts
379064233010	PASTED GLASS LH 1029X1155_50PERCGREY	TATA spare parts
379064233011	PASTED GLASS RH_1591X1155_50PERC GREY TI	TATA spare parts
379064233012	PASTED GLASS RH_1363X1155_50PERC GREY TI	TATA spare parts
379064233013	PASTED GLASS RH_515X889_CLEAR	TATA spare parts
379064233014	TOP PASTED GLASS_RH_5X256X286MM	TATA spare parts
379064233015	LH_PASTED GLS_309X247_CLEAR FULL CERAMIC	TATA spare parts
379064234010	WIN GLS FR EXT LH&RR INT RH CLR 328X590	TATA spare parts
379064234011	WIN GLS FR EXT LH&RR INT LH CLR 328X590	TATA spare parts
379064234012	SLI.GL_735X687_LH EXT/RH INT_CLR	TATA spare parts
379064234013	SLI.GL_735X687_RH EXT/LH INT_CLR	TATA spare parts
379064234014	TOP FIX GL._1474X337_CLR	TATA spare parts
379064234022	WIND GLS RH FR EXT/LH RR INT_CLR_349X752	TATA spare parts
379064234026	WIND GLS RH RR INT/LH FR EXT_CLR_349X752	TATA spare parts
379064234027	RH_REAR INT GLS_SLI_329X752_DR.D_CLR	TATA spare parts
379064234029	WIND GLS RR INT LH&FR EXT RH_680X687_CLR	TATA spare parts
379064234030	WIND GLS FR EXT LH&RR INT RH_680X687_CLR	TATA spare parts
379064234031	TOP FIXED_1376X337_CLR	TATA spare parts
379064234032	WIND GLS RR INT LH&FR EXT RH_355X687_CLR	TATA spare parts
379064234033	WIND GLS FR EXT LH&RR INT RH_355X687_CLR	TATA spare parts
379064234034	TOP FIXED GLS_716X337_CLR	TATA spare parts
379064234035	WIND GLS RR INT LH&FR EXT RH_325X687_CLR	TATA spare parts
379064234036	WIND GLS FR EXT LH&RR INT RH_325X687_CLR	TATA spare parts
379064234037	TOP FIXED GLS_656X337_CLR	TATA spare parts
379064234038	WIND GLS RR INT LH&FR EXT RH_580X687_CLR	TATA spare parts
379064234039	WIND GLS FR EXT LH&RR INT RH_580X687_CLR	TATA spare parts
379064234040	TOP FIXED GLS_1166X337_CLR	TATA spare parts
379064234041	WIND GLS RR INT LH&FR EXT RH_550X687_CLR	TATA spare parts

379064234042	WIND GLS FR EXT LH&RR INT RH_550X687_CLR	TATA spare parts
379064234043	TOP FIXED GLS_1106X337_CLR	TATA spare parts
379064234044	WIND GLS RR INT LH&FR EXT RH_520X687_CLR	TATA spare parts
379064234045	WIND GLS FR EXT LH&RR INT RH_520X687_CLR	TATA spare parts
379064234046	TOP FIXED GLS_1046X337_CLR	TATA spare parts
379064234116	FRNT EXT GLS RH_548X849_50PERCGRAY TNT	TATA spare parts
379064234117	REAR INT GLS_LH_548X849_50PERCGRAY	TATA spare parts
379064235001	RH_FR.EXT GLS_HINGED_312X748_DR.D_CLR	TATA spare parts
379065002002	WINDSHIELD WIPER ASSEMBLY	TATA spare parts
379065002006	COMPLETE WIPER ASSEMBLY AS A KIT	TATA spare parts
379065003001	WINDSHIELD¿ WIPER BEARING	TATA spare parts
379065003002	WINDSHIELD¿ WIPER BEARING	TATA spare parts
379065003003	WINDSHILED WIPER TRANS MISSION_1	TATA spare parts
379065003004	WIPER ARM MCV_ CODRIVER SIDE	TATA spare parts
379065003006	WIPER MOTOR 24V BS2/3/4	TATA spare parts
379065003009	WASHER BOTTLE TANK 2.5 LTRS	TATA spare parts
379065003010	WIPER ARM MCV_DRIVER SIDE	TATA spare parts
379065003012	WINDSHIELD WIPER BEARING SUPPORT ASSY	TATA spare parts
379065003013	WIPER WASHER TANK 24V_3LTR	TATA spare parts
379065003016	LINK MOTION KIT ASSY	TATA spare parts
379065003017	FRONT SINGLE WINDSHIELD WITH RUBBER SM	TATA spare parts
379065003018	WIPER MOTOR 24VDC_150W_90NM	TATA spare parts
379065003027	MCV REAR WINDSHIELD¿ ASSEMBLY	TATA spare parts
379065003028	MCV BOTTOM MOUNTING WIPER¿ LINK ASSY DR	TATA spare parts
379065003030	WIPER WASHER TANK_24V	TATA spare parts
379065003040	REAR RUBBER OUTLINED WINDSHIELD	TATA spare parts
379065003042	SPLIT SW REAR W/S & RUBBER ASSY	TATA spare parts
379065003044	SW SPLIT FRT ITINERARY GLASS ASSY	TATA spare parts
379065003045	FRONT SINGLE W/S & RUBBER ASSEMBLY	TATA spare parts
379065003049	MCV BOTTOM MOUNTING WIPER LINK ASSY DRG	TATA spare parts
379065003051	MCV WIPER LINKAGE ASSY DRG	TATA spare parts
379065003052	WIPER MOTOR 24VDC 180W 120NM	TATA spare parts
379065004001	WIPER BLADE MCV	TATA spare parts
379065004006	WIPER BLADE ASSY	TATA spare parts
379065004007	WIPER ARM ASSY DRIVER SIDE	TATA spare parts
379065004008	WIPER ARM ASSY CO-DRIVER SIDE	TATA spare parts
379065004010	BUSH BRACKET ASSEMBLY	TATA spare parts
379065004019	WIPER ARM ASSY DRIVER SIDE	TATA spare parts
379065004020	WIPER ARM ASSY CO-DRIVER SIDE	TATA spare parts
379065004029	WIPER BLADE	TATA spare parts
379065004032	WIPER MOTOR COVER ASSEMBLY	TATA spare parts
379065004033	WIPER ARM ASSY CO-DRIVER SIDE	TATA spare parts
379065004035	WIPER ARM ASSY DRIVER SIDE	TATA spare parts
379065004039	WIPER ARM ASSY CO-DRIVER SIDE	TATA spare parts
379065004040	WIPER ARM ASSY DRIVER SIDE	TATA spare parts
379065004041	WIPER BLADE ASSEMBLY	TATA spare parts
379065083002	WASHER TANK SUPPORT PLATE	TATA spare parts

379065234001	REAR WINDOW GLASS	TATA spare parts
379065234002	FRONT ITINERARY GLASS	TATA spare parts
379065234003	FRONT WINDSHIELD RH	TATA spare parts
379065234004	FRONT WINDSHIELD LH	TATA spare parts
379065234005	FRONT WIND SHIELD - SINGLE GLASS	TATA spare parts
379065234009	FRONT WINDSHIELD-SINGLE GLASS CERAMIC SM	TATA spare parts
379065234010	FRONT WINDSHIELD-SINGLE GLASS CERAMIC	TATA spare parts
379065234011	MCV REAR WINDSHIELD GLASS	TATA spare parts
379065234021	MCV REAR SPLIT WINDSHIELD GLASS LH	TATA spare parts
379065234022	MCV REAR SPLIT WINDSHIELD GLASS RH	TATA spare parts
379065234025	SW FRONT ITINERARY GLASS	TATA spare parts
379065234026	MCV FRONT SINGLE WINDSHIELD	TATA spare parts
379065234035	REAR WIND SHIELD_MCV_9X12	TATA spare parts
379065284001	REAR WINDOW RUBBER	TATA spare parts
379065284002	ITINERARY RUBBER-OUTLINED GLASS	TATA spare parts
379065284003	RUBBER-OUTLINED WINDSHIELD	TATA spare parts
379065284004	RUBBER FOR SINGLE FRONT WINDSHIELD	TATA spare parts
379065284006	FRONT RUBBER OUTLINE-SINGLE GLASS SM	TATA spare parts
379065284012	MCV SW FRONT WS RUBBER OUTLINE	TATA spare parts
379065284014	MCV SW FRONT ITINERARY GLASS RUBBER	TATA spare parts
379065912002	WIPER JET HOSE MOUNTING ASSEMBLY-2.5L	TATA spare parts
379065912003	WIPER 2.5LTR WATER TANK ASSY	TATA spare parts
379065912006	WIPER ASSY RHD-24V	TATA spare parts
379065912021	WIPER ASSY_LHD-24V	TATA spare parts
379065912033	BOTTOM MTG WIPER ASSY	TATA spare parts
379065912037	WIPER ASSY_RHD-24V_PANAROMIC_ALMIGHTY	TATA spare parts
379065913001	REAR WINDOW ASSEMBLY	TATA spare parts
379065913002	ITERNARY GLASS ASSEMBLY	TATA spare parts
379065913004	WINDSHIELD ASSEMBLY - SINGLE GLASS	TATA spare parts
379068003006	DOUBLE ARM LIFT MECHANISM	TATA spare parts
3792000032	BRACKET A-ENGINE STOP MOTOR	TATA spare parts
3792000110	MOTOR A-ENG STOP	TATA spare parts
3792000112	MOTOR A-ENG STOP	TATA spare parts
3792500260	CABLE A-ENG STOP MOTOR	TATA spare parts
3794500310	BRACKET-ENGINE STOP CABLE	TATA spare parts
3800328	LINER CYLINDER	TATA spare parts
3800558	SET LOWER ENGINE GASKET	TATA spare parts
3800828	KIT LUBE PUMP	TATA spare parts
3800976	KIT WATER PUMP	TATA spare parts
3802070	SET MAIN BEARING STD	TATA spare parts
3802071	SET MAIN BEARING RS-1	TATA spare parts
3802072	SET MAIN BEARING RS2	TATA spare parts
3802073	SET MAIN BEARING RS3	TATA spare parts
3802074	SET MAIN BEARING RS-4	TATA spare parts
3802085	VALVE EXHAUST	TATA spare parts
3802246	KIT INJECTOR	TATA spare parts
3802249	KIT ENG PISTON 0.5 MM O/S	TATA spare parts

3802272	KIT TURBOCHARGER	TATA spare parts
3802273	KIT THERMOSTAT	TATA spare parts
3802310	TURBOCHARGER	TATA spare parts
3802358	WATER PUMP	TATA spare parts
3802361	GASKET SET UPPER	TATA spare parts
3802363	GASKET SET UPPER	TATA spare parts
3802363AE	GASKET SET UPPER 713	TATA spare parts
3802375	GASKET SET LOWER	TATA spare parts
3802376	GASKET SET LOWER	TATA spare parts
3802384	KIT TURBOCHARGER	TATA spare parts
3802421	SET PISTON RINGS STD	TATA spare parts
3802422	SET PISTON RINGS 0.50MM	TATA spare parts
3802423	SET PISTON RINGS 1.00MM	TATA spare parts
3802429	RING SET	TATA spare parts
3802429N	RING SET	TATA spare parts
3802441	INJECTOR	TATA spare parts
3802463	VALVE INTAKE	TATA spare parts
3802648	INJECTOR	TATA spare parts
3802657	PISTON ENGINE	TATA spare parts
3802812	KIT INTAKE VALVE	TATA spare parts
3802813	KIT EXHAUST VALVE	TATA spare parts
3802820	SLEEVE WEAR	TATA spare parts
3809320155	FIXED ENGAGE COWL	TATA spare parts
3809320156	SLIDING ENGAGE COWL	TATA spare parts
3809320157	CIRCLE NUT	TATA spare parts
3809320158	LOCKING WASHER	TATA spare parts
3809320159	DIFFERENTIAL BEAR ADJUSTING NUT	TATA spare parts
380932157	CIRCLE NUT	TATA spare parts
3811102690	WIRING HARNESS SUB-VDO TACHO	TATA spare parts
3811301650	SUB HARNESS-SPEED LIMITER DASH	TATA spare parts
3811302053	WIRING HARNESS DASH	TATA spare parts
3811302054	WIRING HARNESS DASH	TATA spare parts
3811302062	WIRING HARNESS-DASH	TATA spare parts
3811302650	WIRING HARNESS-DASH	TATA spare parts
3811302660	WIRING HARNESS-DASH	TATA spare parts
3811302663	WIRING HARNESS-DASH	TATA spare parts
3811402650	WIRING HARNESS-DASH	TATA spare parts
3812090	PLUG EXPANSION	TATA spare parts
3812092	PLUG EXPANSION	TATA spare parts
3812217	COIL IGNITION	TATA spare parts
3812219	DISTRIBUTOR	TATA spare parts
3812233	BALL BEARING	TATA spare parts
3812300132	WIRING HARNESS-ROOF	TATA spare parts
3812300170	SUB HARN-S/BELT T/REDUCER	TATA spare parts
3812300190	WIRING HARNESS-ROOF	TATA spare parts
3813237	HUMP HOSE	TATA spare parts
3813400040	WIRING HARNESS-DOOR	TATA spare parts

3813400041	WIRING HARNESS-DOOR RH	TATA spare parts
3813400120	WIRING HARNESS-DOOR	TATA spare parts
3813400121	WIRING HARNESS-DOOR LH	TATA spare parts
3814300200	WIRING HARNESS-ENGINE	TATA spare parts
3814300202	WIRING HARNESS-ENGINE	TATA spare parts
3814454	LPR REGULATOR	TATA spare parts
3814455	CATALYTIC CONVERTER	TATA spare parts
3814457	COVER INTAKE MANIFOLD	TATA spare parts
3814458	MANIFOLD EXHAUST	TATA spare parts
3814469	MIXER AIR FUEL	TATA spare parts
3814470	SPEED CONTROLLER	TATA spare parts
3814471	VALVE SHUTOFF	TATA spare parts
3814472	IGNITION CABLE	TATA spare parts
3814473	WIRING HARNESS	TATA spare parts
3814474	SENSOR OXYGEN	TATA spare parts
3814481	CARBURATOR ASSY.	TATA spare parts
3814489	SOLENOID VALVE	TATA spare parts
3814490	VALVE CARBURATOR	TATA spare parts
3814524	ELBOW MALE-ASSY	TATA spare parts
3814525	ELBOW MALE-ASSY	TATA spare parts
3814526	TUBE AIR	TATA spare parts
3814527	EXHAUST MANIFOLD	TATA spare parts
3814601	GASKET EXHAUST PIPE CNG	TATA spare parts
3814624	NYLON TUBE	TATA spare parts
3814625	HOSE	TATA spare parts
3814627	NYLON TUBE	TATA spare parts
3814628	HOSE	TATA spare parts
3814630	HOSE	TATA spare parts
3814631	HOSE	TATA spare parts
3814634	HOSE	TATA spare parts
3814635	HOSE	TATA spare parts
3814636	HOSE FOR GAS ID 15.9MM X 20INCH LONG	TATA spare parts
3814637	HOSE FOR GAS ID 25.4MM X 47 INCH LONG	TATA spare parts
3814638	HOSE	TATA spare parts
3814882	ADAPTER FILTER HEAD	TATA spare parts
3814895	DISTRIBUTOR CONTACTLESS W/ IGNITOR	TATA spare parts
3814896	IGNITOR	TATA spare parts
3814897	COIL IGNITION	TATA spare parts
3814950	HARNESS WIRING ENGINE & TIMER	TATA spare parts
3814962	IGNITION CABLE-1510CNG	TATA spare parts
3814963	HOSE COOLANT ID 7.9 X 173INCH LONG	TATA spare parts
3814964	HOSE GATES ID 7.9MM X 173 INCH LONG	TATA spare parts
3814965	HOSE GATES ID 7.9MM X 146 INCH LONG	TATA spare parts
3815004	TIMER	TATA spare parts
3815005	HARNESS WIRING TIMER	TATA spare parts
3815012	HOSE FOR GAS ID 15.9MM X 20INCH LONG	TATA spare parts
3815013	HOSE GAS SHUT OFF TO LP FILTER	TATA spare parts

3815014	HOSE FOR GAS ID 25.4MM X 47 INCH LONG	TATA spare parts
3815084	PULLEY ALTERNATOR	TATA spare parts
3815104620	W/HARNESS-JOINT/EURO	TATA spare parts
3815110261	W/HARNESS-JOINT/EURO	TATA spare parts
3815112410	EARTH WIRE-STARTER RELAY	TATA spare parts
3815112450	W/HARNESS SUB-STARTER RELAY	TATA spare parts
3815122	HOSE GAS SHUT OFF TO LP FILTER	TATA spare parts
3815123	HOSE LPR TO GAS SHUTOFF	TATA spare parts
3815124	HOSE LP FILTER TO HPR	TATA spare parts
3815159	HOSE LPR TO GAS AIR MIXER CARBURATOR	TATA spare parts
3815202	HOSE-SOL. TO MANIFOLD	TATA spare parts
3815203	HOSE-SOL.TO CARBURETOR	TATA spare parts
3815204	WIRING HARNESS ENGINE	TATA spare parts
3815281	TEE	TATA spare parts
3815303820	SUB HARNESS-SPEED LIMITER FRAME	TATA spare parts
3815306230	SUB HARNESS-AMP 4PIN (3)	TATA spare parts
3815306240	SUB HARNESS-AMP 4PIN (2)	TATA spare parts
3815306260	EARTH WIRE-STARTER RELAY	TATA spare parts
3815306290	W/HARNESS SUB-S/SENSOR PS	TATA spare parts
3815306990	WIRING HARNESS-FRAME	TATA spare parts
3815307000	WIRING HARNESS-FRAME	TATA spare parts
3815307310	WIRING HARNESS-FRAME	TATA spare parts
3815307311	WIRING HARNESS-FRAME	TATA spare parts
3815308830	WIRING HARNESS-FRAME	TATA spare parts
3815308840	WIRING HARNESS-FRAME	TATA spare parts
3815308870	WIRING HARNESS-FRAME	TATA spare parts
3815309800	WIRING HARNESS-FRAME	TATA spare parts
3815415310	SUB-HAR RR COMBI	TATA spare parts
3815520	TUBE AIR	TATA spare parts
3815548	O RING	TATA spare parts
3815549	SPRING CONICAL	TATA spare parts
3815550	DIAPHGRAM	TATA spare parts
3815552	DISTRIBUTOR CONTACTLESS W/ IGNITOR	TATA spare parts
3815553	COIL IGNITION	TATA spare parts
3815610	SUPPORT ALTEROTOR	TATA spare parts
3815617	GASKET GEAR COVER	TATA spare parts
3815689	SET HT CABLE	TATA spare parts
3815740	COIL ELECTRICAL	TATA spare parts
3815894	NUT LOCK	TATA spare parts
3816021	FAN ENGINE	TATA spare parts
3816888	EXHAUST MANIFOLD	TATA spare parts
3816939	ALTERNATOR	TATA spare parts
3816995	CATALYTIC CONVERTER	TATA spare parts
3817047	ADAPTER PLAIN	TATA spare parts
3817048	TUBE COMPRESSOR AIR INLET	TATA spare parts
3817100010	FUSE A-10 AMP	TATA spare parts
3817100020	FUSE A-15 AMP	TATA spare parts

3817100030	FUSE A-20 AMP	TATA spare parts
3817100100	FUSE & RELAY BOX	TATA spare parts
3817100490	FUSE A-30 AMP	TATA spare parts
3817100510	COVER A-AUXILIARY FUSE BOX	TATA spare parts
3817100510BK	COVER A-AUXILIARY FUSE BOX	TATA spare parts
3817100513	COVER ASSY. AUXILIARY FUSE BOX	TATA spare parts
3817100513BK	COVER ASSY. AUXILIARY FUSE BOX	TATA spare parts
3817100520	GASKET-AUXILIARY FUSE BOX	TATA spare parts
3817100521	GASKET-AUXILIARY FUSE BOX	TATA spare parts
3817100580	MAXI FUSE A-20AMP	TATA spare parts
3817100590	MAXI FUSE A-30AMP	TATA spare parts
3817100600	MAXI FUSE A-50AMP	TATA spare parts
3817400110	FUSE BOX A-AUXILIARY	TATA spare parts
3817400120	FUSE BOX A-AUXILIARY	TATA spare parts
3818268	HOSE PLAIN	TATA spare parts
3818823	STUD	TATA spare parts
3818824	NUT HEX FLANGE	TATA spare parts
3818885	SEAL O RING	TATA spare parts
3820000060	BULB CHECK SWITCH ASM	TATA spare parts
3820000070	LENS	TATA spare parts
3820000130	BULB-T10 W/SOCKET	TATA spare parts
3820000140	BULB-T5 W/SOCKET 24V 1.2W	TATA spare parts
3820000150	BULB CAP/T10	TATA spare parts
3820000190	BULB-T5 W/SOCKET 24V 2W	TATA spare parts
3820000230	BULB CAP/T5	TATA spare parts
3820000770	ILLUMINATION CONT A	TATA spare parts
3820000890	METER COMPLETE-CLUSTER	TATA spare parts
3820000894	METER COMPLETE-CLUSTER	TATA spare parts
3820664	HOSE PLAIN	TATA spare parts
3820672	CLAMP HOSE	TATA spare parts
3821100240	CHARTS(7DAYS)	TATA spare parts
3821100350	ELEC TACHOGRAPH A	TATA spare parts
3821100360	BULB 24V 12W-TACHOGRAPH	TATA spare parts
3821101340	NUT	TATA spare parts
3821101400	HOLDER-TACHOGRAPH	TATA spare parts
3821200190	ELEC SPEEDOMETER ASM	TATA spare parts
3821200270	BULB-24V 3W	TATA spare parts
3821300090	TACHOMETER A	TATA spare parts
3821300091	TACHOMETER A	TATA spare parts
3821500050	FUEL-OIL GAUGE(NONMEMORY)	TATA spare parts
3821500051	FUEL-OIL GAUGE(NONMEMORY)	TATA spare parts
3822100020	AIR PRESSURE GAUGE	TATA spare parts
3822100023	AIR PRESSURE GAUGE	TATA spare parts
3822300032	AIR-TEMP GAUGE	TATA spare parts
3822300040	AIR-TEMP GAUGE	TATA spare parts
3822476	Blowby checking tool - to be used with S	TATA spare parts
3822513	TAPPET REMOVAL TOOL KIT	TATA spare parts

3822566	BLOW BY TOOL 0.302 ORIFICE	TATA spare parts
3822608	WEATHER PACK TERMINAL REMOVAL TOOL	TATA spare parts
3822709	BLIND THREAD INS KIT METR	TATA spare parts
3822746	BLOWBY TOOL	TATA spare parts
3822759	REPLACER ELC TERMINAL	TATA spare parts
3822930	REMOVER WIRE INSULATION	TATA spare parts
3822934	GREASE	TATA spare parts
3822985	COMBUSTION GAS LEAK TESTER	TATA spare parts
3823024	INJECTOR PULLER	TATA spare parts
3823031	VALVE SEAT INSERT TOOL	TATA spare parts
3823137	PISTON RING EXPANDER	TATA spare parts
3823208	TORQUE WRENCH INJECTOR TERMINAL NUTS	TATA spare parts
3823225	CON ROD MANDRELS	TATA spare parts
3823494	LIQUID GASKET 3BOND 1207	TATA spare parts
3823521	EXPANSION PLUG DRIVER	TATA spare parts
3823522	EXPANSION PLUG DRIVER	TATA spare parts
3823523	EXPANSION PLUG DRIVER	TATA spare parts
3823524	EXPANSION PLUG DRIVER	TATA spare parts
3823528	AIR COMPRESSOR SEAT SOCKET - TO REMOVE E	TATA spare parts
3823709	BLIND THREAD INSERT KIT	TATA spare parts
3823799	WASTE GATE PRESSURE TEST KIT FOR B & C	TATA spare parts
3823875	DIPSTICK INSTALL REMOVE	TATA spare parts
3823876	Lubricating oil cooler pressure test kit	TATA spare parts
3823879	TORQUE ANGLE GAUGE - 3/4 INCH DRIVE	TATA spare parts
3823891	GEAR LOCKING TOOL - TO PREVENT ROTATION	TATA spare parts
3823892	OFFSET WRENCH - USED TO TIGHTEN THE HIDD	TATA spare parts
3823893	BEARING RACE DRIVER - USED TO INSTALL OU	TATA spare parts
3823921	CAPSCREW LENGTH GAUGE	TATA spare parts
3823923	SPACER - USED WITH PULLER	TATA spare parts
3823983	Gauge compression	TATA spare parts
3823984	DETECTOR COMDUSTIBLE GAS	TATA spare parts
3824078	WEAR SLEEVE INSTALLATION TOOL - CRANKSHA	TATA spare parts
3824438	2-PIN WEATHER-PACK & CIGARETTE PLUG	TATA spare parts
3824469	REMOVER	TATA spare parts
3824498	OIL SEAL INSTALLATION TOOL	TATA spare parts
3824500	WEAR SLEEVE INSTALLATION TOOL - CRANKSHA	TATA spare parts
3824510	QD Contact cleaner - to clean electrical	TATA spare parts
3824591	BARRING TOOL	TATA spare parts
3824645	PRESSURE VACUUM MODULE	TATA spare parts
3824648	AUTOMOTIVE METER	TATA spare parts
3824732	COMPOUND	TATA spare parts
3824811	LEAD ELECTRICAL TEST	TATA spare parts
3824812	LEAD ELECTRICAL TEST	TATA spare parts
3824876	SOCKET	TATA spare parts
3824936	EPS HOUSING LOCATING TOOL	TATA spare parts
3826094	STRAINER FUEL	TATA spare parts
3831000100	HALOGEN BULB-75/70W	TATA spare parts



3831000130	HALOGEN BULB-70W(H3)	TATA spare parts
3831000590	LAMP A-FOG FRONT LH	TATA spare parts
3831000600	LAMP A-FOG FRONT RH	TATA spare parts
3831000650	LAMP A HEAD(LH)	TATA spare parts
3831000651	LAMP-HEAD	TATA spare parts
3831000660	LAMP A HEAD(RH)	TATA spare parts
3831000661	LAMP-HEAD	TATA spare parts
3831852	VALVE DRAIN FUEL WATER	TATA spare parts
3832000170	LAMP A-END OUTLINE MARKER	TATA spare parts
3832000190	BRKT-EOL MARKER LAMP	TATA spare parts
3832000201	LAMP-END OUTLINE MARKER	TATA spare parts
3832000220	LAMP-END OUTLINE MARKER	TATA spare parts
3832000300	LAMP A FRONT SIGNAL	TATA spare parts
3832000310	BRKT-FRT COMB LAMP	TATA spare parts
3832000320	BRKT-FRT COMB LAMP	TATA spare parts
3832005200	LAMP A-FRT T/SIGNAL LH	TATA spare parts
3832005201	LAMP A-FRT T/SIGNAL	TATA spare parts
3832005210	LAMP A-FRT T/SIGNAL	TATA spare parts
3832005211	LAMP A-FRT T/SIGNAL	TATA spare parts
3832010030	BRACKET A-D.I LAMP MTG(LH)	TATA spare parts
3832010032	BRACKET A-D.I LAMP MTG	TATA spare parts
3832010033	BRACKET A-D.I LAMP MTG	TATA spare parts
3832010040	BRACKET A-D.I LAMP MTG(RH)	TATA spare parts
3832010042	BRACKET A-D.I LAMP MTG	TATA spare parts
3832100010	LAMP-FRT FOG	TATA spare parts
3832500010	LAMP-SIDE MARKER	TATA spare parts
3832500040	BRKT-SIDE MARKER LAMP	TATA spare parts
3832500070	LAMP ASM-SIDE MARKER	TATA spare parts
3832500080	BRKT-SIDE MARKER LAMP	TATA spare parts
3832500090	BRKT-SIDE MARKER LAMP	TATA spare parts
3832500100	BULB-24V 5W(W5W)	TATA spare parts
3832840401	GEAR SHIFT FORK UPPER	TATA spare parts
3833100200	BULB-24V 12W	TATA spare parts
3833972	SEAL O RING	TATA spare parts
3834006010	LAMP-REAR COMB	TATA spare parts
3834006020	LAMP-REAR COMB	TATA spare parts
3835300040	BRKT-REAR COMB LAMP	TATA spare parts
3835300044	BRKT-REAR COMB LAMP	TATA spare parts
3835300110	BRKT-NO PLATE	TATA spare parts
3835300111	BRKT-NO PLATE	TATA spare parts
3835300390	STAY A-RR COMBI LAMP(LH)	TATA spare parts
3835300400	STAY A-RR COMBI LAMP(RH)	TATA spare parts
3835500020	BULB-24V 40W	TATA spare parts
3835500030	LAMP A-WORKING	TATA spare parts
3836000080	LAMP A-SIDE T SIGNAL AND MARKER	TATA spare parts
3836000090	LAMP A-SIDE T SIGNAL AND MARKER	TATA spare parts
3836100010	LAMP ASSY. DOOR T/SIGNAL	TATA spare parts

3836100020	LAMP ASSY. DOOR T/SIGNAL	TATA spare parts
3837100110	LAMP A-ROOM & SPOT	TATA spare parts
3837100110LB	LAMP A-ROOM & SPOT	TATA spare parts
3837100111	LAMP A-ROOM & SPOT	TATA spare parts
3837100111LB	LAMP A-ROOM & SPOT	TATA spare parts
3837500010	LAMP A-READING	TATA spare parts
3837500010SB	LAMP ASM-READING	TATA spare parts
3837500020	BULB-24V 10W	TATA spare parts
3837700100	BULB-10W	TATA spare parts
3837700110	LAMP A-LARGE ROOM	TATA spare parts
3837700110LB	LAMP A-LARGE ROOM	TATA spare parts
3837700114	LAMP A-LARGE ROOM	TATA spare parts
3837700114LB	LAMP A-LARGE ROOM	TATA spare parts
3837900010	LAMP A-STEP	TATA spare parts
3837900020	BULB-24V 10W	TATA spare parts
3840000020	BUZZER A-BACK UP	TATA spare parts
3840000021	BUZZER A-BACK UP	TATA spare parts
3841100200	HOLE COVER-RECEIVER	TATA spare parts
3841100200BK	HOLE COVER-RECEIVER	TATA spare parts
3841100200LB	HOLE COVER-RECEIVER	TATA spare parts
3841400250	PLUG-ANTENNA	TATA spare parts
3841409010	ANTENNA & LEAD A	TATA spare parts
3841409013	ANTENNA & LEAD A	TATA spare parts
3841700020	DC-DC CONVERTOR	TATA spare parts
3841700080	DC-DC CONVERTER	TATA spare parts
3844100060	SPEAKER A-STEREO FRT	TATA spare parts
3844100070	SPEAKER A-STEREO REAR	TATA spare parts
3844100110	SPEAKER A-STEREO FRT	TATA spare parts
3844100120	SPEAKER A-STEREO RR	TATA spare parts
3846100050	HORN ASSY. EURO	TATA spare parts
3846100470	BRKT-HORN EURO	TATA spare parts
3846100510	HORN A-EURO	TATA spare parts
3846300070	CHIME BELL A	TATA spare parts
3846300072	CHIME BELL A	TATA spare parts
3846300090	BUZZER	TATA spare parts
3847100060	SOCKET A-POWER 12V	TATA spare parts
3847100080	CIGAR LIGHTER A	TATA spare parts
3847100100	CIGAR LIGHTER A	TATA spare parts
3847100101	CIGAR LIGHTER A	TATA spare parts
3847100130	LIGHTER RING-WITH BULB SOCKET	TATA spare parts
3847100140	BULB	TATA spare parts
3847100160	DUMMY-POWER SOCKET	TATA spare parts
3847100350	CIGAR LIGHTER A	TATA spare parts
3848100023	DIGITAL CLOCK-WITHOUT ALARM	TATA spare parts
3848100023LB	DIGITAL CLOCK-WITHOUT ALARM	TATA spare parts
3848100032	LENS-DIGITAL CLOCK	TATA spare parts
3848100040	DIGITAL CLOCK	TATA spare parts

3848100040LB	DIGITAL CLOCK	TATA spare parts
3851000020	CAR LOCK SET A	TATA spare parts
3853000010BK	SWITCH A-COMBINATION(BLACK)	TATA spare parts
3853000016	SWITCH A-COMBINATION	TATA spare parts
3853000016BK	SWITCH A-COMBINATION	TATA spare parts
3853000160	ASSY. COMBI. SWITCH W/FLAT CABLE BS3/4	TATA spare parts
3853000160AE	SW A-COMB EXH W/FLAT CBL -1628	TATA spare parts
3853000160C	SWITCH A-COMB EXH W/FLAT CBLCORE	TATA spare parts
3853000170	SWITCH A-COMB JAKE W/FLAT CBL	TATA spare parts
3853000180	SWITCH A-COMB RETARDER W/FLAT	TATA spare parts
3853100010BK	SWITCH A-TURN MAIN LIGHT(BLACK)	TATA spare parts
3853100013	SWITCH ASSY. TURN MAIN LIGHT	TATA spare parts
3853100013BK	SWITCH ASSY. TURN MAIN LIGHT	TATA spare parts
3853300010BK	SWITCH A-WIPER EXHAUST HAZARD(BLACK)	TATA spare parts
3853300013	SWITCH ASSY. WIPER EXHAUST HAZARD	TATA spare parts
3853300013BK	SWITCH ASSY. WIPER EXHAUST HAZARD	TATA spare parts
38540	CAP SCREW	TATA spare parts
3854700050	SWITCH-AIR PRESSURE	TATA spare parts
3854700070	SWITCH A-STOP LAMP	TATA spare parts
3855300020	SWITCH ASSY. DOOR CONTACT	TATA spare parts
3855300020BK	SWITCH ASSY. DOOR CONTACT	TATA spare parts
3855700020	SWITCH A-AIR CON	TATA spare parts
3855700020BK	SWITCH A-AIR CON	TATA spare parts
3855700040	SWITCH A-FOG LAMP	TATA spare parts
3855700040BK	SWITCH A-FOG LAMP	TATA spare parts
3855700050	SWITCH A-PTO	TATA spare parts
3855700050BK	SWITCH A-PTO	TATA spare parts
3855700080BK	SWITCH A-WORKING LAMP(BLACK)	TATA spare parts
3855700090	SWITCH A-MIRROR HEATED	TATA spare parts
3855700100BK	SWITCH A-BLANK COVER(BLACK)	TATA spare parts
3855700102	SWITCH ASSY. BLANK COVER	TATA spare parts
3855700102BK	SWITCH ASSY. BLANK COVER	TATA spare parts
3855700110	SWITCH A-DIFF LOCK	TATA spare parts
3855700110BK	SWITCH A-DIFF LOCK F/R	TATA spare parts
3855700180BK	SWITCH A-REAR FOG(BLACK)	TATA spare parts
3856500020	SWITCH ASSY. LEVELING DEVICE	TATA spare parts
3856500020BK	SWITCH ASSY. LEVELING DEVICE	TATA spare parts
3856500050BK	BRKT-L/DEVICE SW(BLACK)	TATA spare parts
3856500080	SWITCH-DUMMY L DEVICE	TATA spare parts
3858900010	SWITCH A-ACCEL CLUTCH	TATA spare parts
3858900011	SWITCH A-ACCEL CLUTCH	TATA spare parts
3861100090	SWITCH A-SUB STARTER	TATA spare parts
3861100091	SWITCH A-SUB STARTER	TATA spare parts
3861100100	SWITCH A-CAB TILT(P.B.S)	TATA spare parts
3861100101	SWITCH A-CAB TILT(P.B.S)	TATA spare parts
3862000060	SENDER A-AIR PRESSURE(2P)	TATA spare parts
3862000070	SENDER A-AIR PRESSURE(2P)	TATA spare parts

3863100080	SWITCH A-AIR CLEANER	TATA spare parts
3863131	SCREW BANJO CONNECTOR	TATA spare parts
3863454	CAP FILLER	TATA spare parts
3863500050	SWITCH A-LOW PRESSURE 4.2 BAR	TATA spare parts
3863500060	SWITCH A-LOW PRESSURE 5.3 BAR	TATA spare parts
3863500070	SWITCH A-LOW PRESSURE 2.0 BAR	TATA spare parts
3863500080	SWITCH A-LOW PRESSURE 6.0 BAR	TATA spare parts
3863500090	SWITCH A-LOW PRESS 2.0 BAR	TATA spare parts
3863500120	SWITCH A-LOW PR	TATA spare parts
3863500130	SWITCH A-LOW PRESS 5.3 BAR	TATA spare parts
3863500140	SWITCH A-LOW PRESSURE 6.0 BAR	TATA spare parts
3863942	CLIP	TATA spare parts
3863988	WASHER SEALING	TATA spare parts
3864201	BREATHER CRANKCASE	TATA spare parts
3864202	SEAL O RING	TATA spare parts
3864205	HOSE PLAIN	TATA spare parts
3864217	CLAMP HOSE	TATA spare parts
3867646	SEAL O RING	TATA spare parts
3868500050	SWITCH A-CAB LOCK	TATA spare parts
3871100010	BLINKER UNIT	TATA spare parts
3871100012	BLINKER UNIT	TATA spare parts
3871300030	RELAY A-MINI	TATA spare parts
3871300060	RELAY A-MICRO	TATA spare parts
3871300070	RELAY A-TWIN MAKE CONTACT	TATA spare parts
3871300100	RELAY A-POWER(70A)	TATA spare parts
3871300160	RELAY A-1M 1T	TATA spare parts
3871300170	RELAY-1M 1T(4P)	TATA spare parts
3871300180	RELAY A-1M 1T(W/BRKT)	TATA spare parts
3871300290	RELAY (W/BRKT)	TATA spare parts
3872100020	TIMER A-DOOR ROOM LAMP	TATA spare parts
3872458	CAP SCREW (M4X20)	TATA spare parts
3872700020	RELAY A-WIPER INT	TATA spare parts
3872700021	RELAY A-WIPER INT	TATA spare parts
3872800020	DIODE ARRAY/EURO	TATA spare parts
3873300032	BRKT-RELAY START MOTOR	TATA spare parts
3873300111	RELAY-STARTER	TATA spare parts
3874500047	FUEL SENDER A-400L	TATA spare parts
3874500290	FUEL SENDER A-400L STEEL	TATA spare parts
3874500320	LAMP A BED SIDE READING (SNAKE TYPE)	TATA spare parts
3874500990	FUEL SENDERA-INTEGRATED F	TATA spare parts
3875000012	CONTROL UNIT-MIRROR HEAT	TATA spare parts
3875378	CLAMP DISTRIBUTOR	TATA spare parts
3877000150	BRKT A-INVERTER	TATA spare parts
3878200030	SPEED SENSOR A(8P)	TATA spare parts
3878500110	SENDER-OIL PRESSURE	TATA spare parts
3878700101	SENSOR-COOLANT TEMP	TATA spare parts
3878900050	ADAPTER-COOLANT SENSOR	TATA spare parts

3878900090	ADAPTER-COOLANT SENSOR	TATA spare parts
3879300130	BRKT-SPEED UNIT(H)	TATA spare parts
3879300140	BRKT-SPEED UNIT(L)	TATA spare parts
3879300520	ECU A-SPEED LIMITER	TATA spare parts
3879300690	BRKT-SPEED LIMITER	TATA spare parts
3879300710	ACTUATOR A-SPEED LIMITER	TATA spare parts
3879300780	BRKT-SPEED LIMITER	TATA spare parts
3879500150	ECU-ABS(4S/4M)	TATA spare parts
3879500220	BRKT A-ECU ABS	TATA spare parts
3879500223	BRKT A-ECU ABS	TATA spare parts
3879500262	SENSOR A-FRT RR AXLE	TATA spare parts
3879500290	SENSOR	TATA spare parts
3879500320	SOCKET-PARKING ISO7638	TATA spare parts
3879500330	COILED CABLE-ISO7638	TATA spare parts
3879500480	CABLE A-ISO7638	TATA spare parts
3879500481	CABLE A-ISO7638	TATA spare parts
3879900130	PLATE ASM-ELEC MODULE	TATA spare parts
3879900131	PLATE ASM-ELEC MODULE	TATA spare parts
3882000230	PROTECTOR A-BATTERY	TATA spare parts
3882000400	COVER-BATTERY	TATA spare parts
3882000400BK	COVER-BATTERY(BLACK)	TATA spare parts
3882000403	COVER-BATTERY	TATA spare parts
3882000403BK	COVER-BATTERY	TATA spare parts
3882000450	TENSION ROD	TATA spare parts
3882000451	TENSION ROD	TATA spare parts
3882000550	CLIP-BATTERY COVER	TATA spare parts
3882000551	CLIP-BATTERY COVER	TATA spare parts
3882001000	BRACKET A-BATTERY(FOR 90 DEG)	TATA spare parts
3882001006	BRACKET ASSY. BATTERY	TATA spare parts
3882001080	PROTECTOR A-BATT CUT OFF SW	TATA spare parts
3882005000	BRACKET A-BATTERY(FOR 90 DEG)	TATA spare parts
3882500010	SPACER-MF BATTERY	TATA spare parts
3882500011	SPACER-MF BATTERY	TATA spare parts
3883100290	CABLE-BATTERY TO STARTER(3000MM)	TATA spare parts
3883100292	CABLE-BATT TO STARTER	TATA spare parts
3883100350	CABLE-BATTERY TO STARTER(1660MM)	TATA spare parts
3883100352	CABLE-BATTERY TO STARTER	TATA spare parts
3883105360	CABLE-EARTH TO CUT OFF S/W	TATA spare parts
3883105370	CABLE-SW TO BATTERY(-)	TATA spare parts
3883284	SEAL O RING	TATA spare parts
3883500310	CABLE-BATT(-)	TATA spare parts
3883500314	CABLE-BATT(-)	TATA spare parts
3883502000	CABLE-EARTH(40SQ)	TATA spare parts
3883700210	CABLE-BATT(+) TO BATT(-)	TATA spare parts
3883700315	CABLE-BATT(+) TO BATT(-)	TATA spare parts
3883977	PIPE AIR TRANSFER	TATA spare parts
3885646	B59G	TATA spare parts

3886089	ESDN KIT	TATA spare parts
3886388	INSITE LITE/PRO	TATA spare parts
3886391	NSITE 5.4 PRO(CLIENT)REG	TATA spare parts
3890063	FUEL FILTER SEC ELEMENT	TATA spare parts
389010901497	ALTERNATOR BELT	TATA spare parts
3890206	SEPERATOR FUEL WATER	TATA spare parts
3891700150	COCK-HEATER	TATA spare parts
3891700160	HEATER HOSE CONNECTOR ASM	TATA spare parts
3891700300	SCREW GROMMET	TATA spare parts
3891700370	BRKT-HEATER HOSE MTG	TATA spare parts
3891700376	BRKT-HEATER HOSE MTG	TATA spare parts
3891700423	HEATER HOSE CONNECTOR ASM	TATA spare parts
3891700440	PIPE-HOSE CONNECTOR	TATA spare parts
3891700442	PIPE-HOSE CONNECTOR	TATA spare parts
3891700450	BRKT-COMP MTG FRT LWR	TATA spare parts
3891700460	BRKT-COMP MTG RR HOLDER	TATA spare parts
3891700510	COCK-HEATER	TATA spare parts
3891700520	BRKT- A PARTS MTG	TATA spare parts
3892000200	HEATER CORE A-W/WATER VALVE	TATA spare parts
3892371	HOSE FLEXIBLE	TATA spare parts
3893000020	COOLING UNIT A	TATA spare parts
3893000026	COOLING UNIT A	TATA spare parts
3893000180	COOLING UNIT ASM	TATA spare parts
3893200010	EVAP A-Y W/EXP V/V	TATA spare parts
3893300010	THERMOSTAY	TATA spare parts
3893400150	DRAIN HOSE A	TATA spare parts
3893400152	DRAIN HOSE A	TATA spare parts
3893400180	RESISTANCE A	TATA spare parts
3893400181	RESISTANCE A	TATA spare parts
3893400210	AIR FILTER ASM	TATA spare parts
3893401010	FREON HOSE-LIQUID 'B'	TATA spare parts
3893401014	FREON HOSE-LIQUID B	TATA spare parts
3894000060	HEATER UNIT A	TATA spare parts
3894000062	HEATER UNIT A	TATA spare parts
3894000070	HEATER CORE ASSY. W/O WATER VALVE	TATA spare parts
3894000150	BLOWER UNIT A	TATA spare parts
3894100010	CASE-BLOWER UPPER	TATA spare parts
3894100020	CASE-BLOWER LOWER	TATA spare parts
3894100030	BELLMOUTH	TATA spare parts
3894200010	BLOWER A	TATA spare parts
3894300020	M/ACT A-BWR	TATA spare parts
3894400010	AIR HOSE	TATA spare parts
3894500100	FILTER A-REC	TATA spare parts
3894500270	WATER HOSE-HEATER INLET B	TATA spare parts
3894500280	WATER HOSE-HEATER OUTLET B	TATA spare parts
3894500440	EYE BOLT BLOCK SLEEVE	TATA spare parts
3894500461	EYE BOLT BLOCK-ALT	TATA spare parts

3894500710	BRKT-FREON B	TATA spare parts
3894500930	EYE BOLT ASSY-COMP	TATA spare parts
3894500932	EYE BOLT ASSY-COMP	TATA spare parts
3894501450	SPACER-COMP	TATA spare parts
3894501810	WATER HOSE-HEATER INLET C	TATA spare parts
3894501820	WATER HOSE-HEATER INLET A	TATA spare parts
3894501830	WATER HOSE-HEATER OUTLET A	TATA spare parts
3894501840	BRKT-COMPRESSOR	TATA spare parts
3894501860	FREON HOSE-SUCTION A+B	TATA spare parts
3894501870	FREON HOSE-DISCHARGE A+C	TATA spare parts
3894502890	FREON HOSE-SUCTION	TATA spare parts
3894502900	FREON HOSE-DISCHARGE COMP	TATA spare parts
3894502910	FREON HOSE-DISCHARGE COND	TATA spare parts
3894502920	FREON HOSE-LIQUID	TATA spare parts
3894502980	WATER HOSE-HEAT	TATA spare parts
3894600010	SHAFT-BLOWER	TATA spare parts
3894700010	DOOR ASSY. BLOWER	TATA spare parts
3894800010	HARNES-BLOWER M/ACT	TATA spare parts
3895100070	COMPRESSOR A	TATA spare parts
3895100072	COMPRESSOR A	TATA spare parts
3895600110	CONDENSER COMPLETE ASM	TATA spare parts
3895600130	BRACKET-CONDENSER	TATA spare parts
3895600140	REINF-BRKT CONDENSER	TATA spare parts
3895600160	CONDENSER COMPLETE ASM	TATA spare parts
3895600200	BRACKET-CONDENSER	TATA spare parts
3895600340	INSERT ASSY. OUTER NOZZLE	TATA spare parts
3895600340SB	INSERT ASSY. OUTER NOZZLE	TATA spare parts
3895600400	CONDENSER A-PFC	TATA spare parts
3895600410	BRACKET-RECIVER DRYER	TATA spare parts
3895600420	RECEIVER DRYER	TATA spare parts
3895600430	CLAMP-RECIVER DRYER	TATA spare parts
3895600440	SHROUD ASSY.	TATA spare parts
3895600450	MOTOR A-CONDENSER	TATA spare parts
3895600460	FAN-CONDENSER	TATA spare parts
3895600530	CONDENSER ASM COMPLETE	TATA spare parts
3895600540	BASE PLATE-CONDENSER	TATA spare parts
3895600560	BRKT-CONDENSER REAR	TATA spare parts
3895600570	REINF-CONDENSER	TATA spare parts
3895600580	PROTECTOR-CONDENSER	TATA spare parts
3895600590	BRKT-CONDENSER UNDER	TATA spare parts
3895600610	BRKT ASM-CONDENSER FRT	TATA spare parts
3895700231	EYE BOLT	TATA spare parts
3895800460	HVAC CONTROL SWITCH A	TATA spare parts
3895800460BK	HVAC CONTROL SW A	TATA spare parts
3896100100	DUCTING-CENTER NO1	TATA spare parts
3896100110	DUCTING-CENTER NO2	TATA spare parts
3896100111	DUCTING-CENTER NO2	TATA spare parts

3896100120	DUCTING-PASS NO1	TATA spare parts
3896100130	DUCTING-PASS NO2	TATA spare parts
3896100600	DUCTING A-FOOTWELL	TATA spare parts
3896100830	DUCTING A-FOOTWELL(RH)	TATA spare parts
3896100831	DUCTING A-FOOTWELL	TATA spare parts
3896100860	DUCTING A-DEFROSTER	TATA spare parts
3896100880	DUCTING A-DEFROSTER	TATA spare parts
3896100890	DUCTING A-DEF DOOR	TATA spare parts
3896100900	DUCTING A-DEF DOOR	TATA spare parts
3896100910	DUCTING A-VENT NO1	TATA spare parts
3896100912	DUCTING A-VENT NO1	TATA spare parts
3896100920	DUCTING A-VENT NO2	TATA spare parts
3896100922	DUCTING A-VENT NO2	TATA spare parts
3896100960	AIR HOSE-DRV	TATA spare parts
3896100970	AIR HOSE-DRV	TATA spare parts
3896100980	AIR HOSE-PASS	TATA spare parts
3896100990	AIR HOSE-PASS CTR	TATA spare parts
3896101050	DUCTING A-CTR VENT NO1	TATA spare parts
3896101052	DUCTING A-CTR VENT NO1	TATA spare parts
3896101080	DUCTING-DRIVER	TATA spare parts
3896101090	DUCTING-DRIVER	TATA spare parts
3896410044	GRILLE ASSY. VENT PASS UPR CENTER	TATA spare parts
3896410044SB	GRILLE ASSY. VENT PASS UPR CENTER	TATA spare parts
3896410070	DUCTING-FLEXIBLE I/P TO DR	TATA spare parts
3896410071	DUCTING-FLEXIBLE I/P TO DR	TATA spare parts
3897100060	FINISHER ASSY. DEFROST	TATA spare parts
3897100060DB	FINISHER A-DEFROST(RH)(DARK BEIGE)	TATA spare parts
3897100060SB	FINISHER ASSY. DEFROST	TATA spare parts
3897110090	FINISHER A-DEFROST(LH)	TATA spare parts
3897110090DB	FINISHER A-DEFROST(LH)(DARK BEIGE)	TATA spare parts
3897110091	FINISHER ASSY. DEFROST	TATA spare parts
3897110091SB	FINISHER ASSY. DEFROST	TATA spare parts
3897310020	GRILLE A-VENT PASS UPR PANEL(RH)	TATA spare parts
3897310020DB	GRILLE A-VENT PASS UPR PANEL(RH)(DARK BE	TATA spare parts
3897310024	GRILLE ASSY. VENT PASS UPR PANEL	TATA spare parts
3897310024SB	GRILLE ASSY. VENT PASS UPR PANEL	TATA spare parts
3897310050	GRILLE A-AIR VENTILATION DRIVER(LH)	TATA spare parts
3897310050DB	GRILLE A-AIR VENTILATION DRIVER(LH)(DARK	TATA spare parts
3897310051	GRILLE ASSY. AIR VENTILATION DRIVER	TATA spare parts
3897310051SB	GRILLE ASSY. AIR VENTILATION DRIVER	TATA spare parts
3897310060	GRILLE A-AIR VENTILATION DRIVER(RH)	TATA spare parts
3897310060DB	GRILLE A-AIR VENTILATION DRIVER(RH)(DARK	TATA spare parts
3897310061	GRILLE ASSY. AIR VENTILATION DRIVER	TATA spare parts
3897310061SB	GRILLE ASSY. AIR VENTILATION DRIVER	TATA spare parts
3897331	HEAD FUEL FILTER	TATA spare parts
3897810010	GRILLE-BACK PANEL	TATA spare parts
3897810010SB	GRILLE-BACK PANEL(SOLARIS BEIGE)	TATA spare parts



3897810016	GRILLE-BACK PANEL	TATA spare parts
3897810016SB	GRILLE-BACK PANEL	TATA spare parts
3897810020	GRILLE-BACK PANEL	TATA spare parts
3897810020SB	GRILLE-BACK PANEL(SOLARIS BEIGE)	TATA spare parts
3897810026	GRILLE-BACK PANEL	TATA spare parts
3897810026SB	GRILLE-BACK PANEL	TATA spare parts
3897910020	PANEL-BLANK BACK PANEL GRILLE	TATA spare parts
3897910020SB	PANEL-BLANK BACK PANEL GRILLE	TATA spare parts
3898000200	PIPE-STAY	TATA spare parts
3898000201	PIPE-STAY	TATA spare parts
3898020	LITERATURE TRAINING SER.	TATA spare parts
3898021	LITERATURE TRAINING SER.	TATA spare parts
3898022	LITERATURE TRAINING SER.	TATA spare parts
3898024	LITERATURE TRAINING SER.	TATA spare parts
3898045	LITERATURE TRAINING SER.	TATA spare parts
3899000330	SUB HARN -HVAC MODULE MANUAL	TATA spare parts
3899100010	HVAC CONTROL MANUAL	TATA spare parts
3899100020	HVAC CONTROL FATC	TATA spare parts
3899100030	SENSOR ASSY-INCAR	TATA spare parts
3899100040	SENSOR ASSY-MULTI	TATA spare parts
3899100050	SENSOR ASSY-AMB	TATA spare parts
3899400010	GRILLE W/S-DEFROST CTR	TATA spare parts
3899400020	GRILLE W/S-DEFROST LH	TATA spare parts
3899400030	GRILLE W/S-DEFROST RH	TATA spare parts
3899400060	AIR VENT COVER DASH LH	TATA spare parts
3899400070	AIR VENT COVER DASH RH	TATA spare parts
3899400570	DUCT ASM-DEFROST CONNECT_CTR	TATA spare parts
3899401080	AIR VENT ASM-DASH SIDE RH	TATA spare parts
3899401640	DUCT ASM-FOOTWELL_DRV NO 2	TATA spare parts
3900068	DOWEL RING	TATA spare parts
3900215	PLUG THREADED	TATA spare parts
3900227	SCREW HEX HEAD CAP	TATA spare parts
3900240	NUT REGULAR HEXAGON	TATA spare parts
3900242	RETAINING RING	TATA spare parts
3900245	PLAIN WASHER	TATA spare parts
3900250	COLLET VALVE	TATA spare parts
3900257	DOWEL PIN	TATA spare parts
3900267	SEAL GROMMET	TATA spare parts
3900269	WASHER PLAIN	TATA spare parts
3900276	SPRING VALVE	TATA spare parts
3900299	RETAINER VALVE SPRING	TATA spare parts
3900589	NUT HEX FLANGE	TATA spare parts
3900625	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3900626	CAPSCREW	TATA spare parts
3900628	SCREW HEX HEAD CAP	TATA spare parts
3900629	SCREW HEX FLANGE	TATA spare parts
3900630	SCREW HEX FLANGE HEAD	TATA spare parts

3900631	SCREW HEX FLANGE HEAD	TATA spare parts
3900632	SCREW	TATA spare parts
3900633	SCREW HEX FLANGE HEAD	TATA spare parts
3900634	SCREW HEX HEAD CAP	TATA spare parts
3900635	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3900637	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3900677	SCREW HEX FLANGE HEAD	TATA spare parts
3900678	SCREW HEX FLANGE HEAD	TATA spare parts
3900679	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3900687	PLUG EXPANSION	TATA spare parts
3900705	INSERT	TATA spare parts
3900706	SCREW SLOTTED SET	TATA spare parts
3900709	SEAL OIL	TATA spare parts
3900919	SCREW CON ROD CAP	TATA spare parts
3900955	PLUG EXPANSION	TATA spare parts
3900956	PLUG EXPANSION	TATA spare parts
3900958	PLUG EXPANSION	TATA spare parts
3900965	PLUG EXPANSION	TATA spare parts
3900967	CAP MAIN BRG	TATA spare parts
3901085	BUSH	TATA spare parts
3901090	BEARING MAIN	TATA spare parts
3901097	SEAL VALVE STEM	TATA spare parts
3901150	BEARING MAIN	TATA spare parts
3901170	BEARING CON ROD	TATA spare parts
3901171	BRG CON ROD RS1	TATA spare parts
3901172	BEARING CON ROD RS2	TATA spare parts
3901173	BEARING-OVER SIZE	TATA spare parts
3901174	BEARING CONNECTING ROD	TATA spare parts
3901177	COLLET VALVE	TATA spare parts
3901221	SCREW HEXAGON HD CAP	TATA spare parts
3901249	SCREW HEX FLANGE (M12 X 1.75 X 25)	TATA spare parts
3901306	BUSH	TATA spare parts
3901356	GASKET TURBOCHARGER	TATA spare parts
3901383	ROD ENGINE CONNECTING	TATA spare parts
3901395	SCREW HEXAGON HD CAP	TATA spare parts
3901430	BEARING CONNECTING ROD	TATA spare parts
3901445	SCREW HEX FLANGE HEAD CAP (M 8 X 1.25 X	TATA spare parts
3901446	SCREW HEX FLANGE HD CAP	TATA spare parts
3901447	SCREW HEX FLANGE	TATA spare parts
3901448	SCREW	TATA spare parts
3901567	ROD ENGINE CONNECTING	TATA spare parts
3901617	SCREW TWELVE POINT CAP	TATA spare parts
3901693	CLAMP RETAINING	TATA spare parts
3901717	LEVER ROCKER	TATA spare parts
3901757	SCREW HEX FLANGE HEAD	TATA spare parts
3901764	RING RETAINING	TATA spare parts
3901774	RING GEAR FLYWHEEL	TATA spare parts

3901846	DOWEL PIN	TATA spare parts
3901865	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3901895	CAP FILLER	TATA spare parts
3901937	SCREW HEX FLANGE HD CAP	TATA spare parts
3901969	PLUG EXPANSION	TATA spare parts
3902023	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3902089	SEAL O RING	TATA spare parts
3902112	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3902114	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3902286	RING COMPRESSION PISTON	TATA spare parts
3902332	KEY PLAIN WOODRUFF	TATA spare parts
3902343	DOWEL RING	TATA spare parts
3902363	SEAL RECT RING	TATA spare parts
3902400	RING COMPRESSION PISTON	TATA spare parts
3902425	WASHER SEALING	TATA spare parts
3902451	SCREW HEX FLANGE HD CAP	TATA spare parts
3902460	SCREW HEX HEAD CAP	TATA spare parts
3902466	SEAL RECTANGULAR RING	TATA spare parts
3902468	CAP FILLER	TATA spare parts
3902469	SPACER MOUNTING	TATA spare parts
3902604	COVER	TATA spare parts
3902606	PLUG EXPANSION	TATA spare parts
3902662	NUT HEXAGONAL FLANGE	TATA spare parts
3902666	GASKET VALVE COVER	TATA spare parts
3903035	SCREW BANJO CONNECTOR	TATA spare parts
3903036	CONNECTOR BANJO	TATA spare parts
3903089	BRACE ALTERNATOR	TATA spare parts
3903096	SCREW HEX FLANGE HEAD	TATA spare parts
3903102	CONNECTION WATER INLET	TATA spare parts
3903112	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3903118	SCREW HEX FLANGE HEAD	TATA spare parts
3903200	SCREW HEXAGON HEAD CAP (M12 X 1.75 X 25)	TATA spare parts
3903210	NUT HEXAGON FLANGE	TATA spare parts
3903242	BUSH	TATA spare parts
3903269	NUT HEXAGONAL FLANGE	TATA spare parts
3903293	NUT	TATA spare parts
3903297	SEAL O RING	TATA spare parts
3903309	GEAR FLYWHEEL RING	TATA spare parts
3903380	SEAL BANJO CONNECTOR	TATA spare parts
3903384	RING OIL PISTON-4021	TATA spare parts
3903463	COVER	TATA spare parts
3903464	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3903475	SEAL RECT RING	TATA spare parts
3903492	CAP MAIN BRG	TATA spare parts
3903546	SEAL O RING BIG	TATA spare parts
3903575	SOLENOID 12 V	TATA spare parts
3903576	KIT SOLONOID	TATA spare parts

3903640	FUEL FILTER	TATA spare parts
3903652	CLAMP V BAND	TATA spare parts
3903663	COVER GEAR	TATA spare parts
3903723	WASHER PLAIN	TATA spare parts
3903744	TURBO OIL DRAIN PIPE	TATA spare parts
3903745	DRAIN LINE TURBO	TATA spare parts
3903757	BRACKET LIFTING	TATA spare parts
3903794	COVER GEAR EURO II	TATA spare parts
3903834	SCREW 12PT CAP	TATA spare parts
3903846	SEAL O RING SMALL	TATA spare parts
3903857	SCREW HEX FLANGE HD CAP	TATA spare parts
3903924	PIN TIMING	TATA spare parts
3903990	SCREW HEX FLANGE	TATA spare parts
3904046	PLATE COVER	TATA spare parts
3904105	INSERT VALVE EXHAUST	TATA spare parts
3904166	SLEEVE SALVAGE	TATA spare parts
3904181	PLUG THREADED	TATA spare parts
3904217	SCREW HEX HEAD CAP	TATA spare parts
3904230	CLAMP SPRING HOSE	TATA spare parts
3904347	RING COMPRESSION PISTON	TATA spare parts
3904353	KIT CRANK SHAFT SEAL	TATA spare parts
3904369	CAM BUSH NO 1 OVER SIZE	TATA spare parts
3904374	PUMP LIFT	TATA spare parts
3904408	GUIDE VALVE STEM	TATA spare parts
3904409	GUIDE VALVE STEM	TATA spare parts
3904446	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3904483	DOWEL PIN	TATA spare parts
3904519	BRACE TUBE	TATA spare parts
3904711	BRACE TUBE	TATA spare parts
3904849	RING RETAINING	TATA spare parts
3905194	ROD PUSH	TATA spare parts
3905216	CLAMP V BAND	TATA spare parts
3905307	SCREW BANJO CONNECTOR	TATA spare parts
3905313	BRACE FUEL PUMP EURO II	TATA spare parts
3905351	SEAL GROMMET	TATA spare parts
3905371	STUD	TATA spare parts
3905388	TEE MALE UNION	TATA spare parts
3905401	PLUG EXPANSION	TATA spare parts
3905408	TUBE OIL FILTER	TATA spare parts
3905443	GASKET EXHAUST MANIFOLD OTHER THAN 3521	TATA spare parts
3905449	SEAL ROCKER LEVER COVER	TATA spare parts
3905701	TUBE FUEL DRAIN	TATA spare parts
3905771	COVER INTAKE MANIFOLD	TATA spare parts
3905776	CLIP	TATA spare parts
3905786	DIPSTICK	TATA spare parts
3905800	TUBE OIL GAUGE	TATA spare parts
3905802	END OIL GAUGE TUBE	TATA spare parts

3905804	BRACE TUBE	TATA spare parts
3905860	SCREW BANJO CONNECTOR	TATA spare parts
3905870	SUPPORT ROCKER LEVER	TATA spare parts
3906080	KIT CRANK SHAFT SEAL	TATA spare parts
3906081	REAR CRANK SEAL SERVICE	TATA spare parts
3906100	WASHER SPRING	TATA spare parts
3906206	GUIDE VALVE STEM	TATA spare parts
3906216	NUT HEXAGON FLANGE	TATA spare parts
3906231	RING OIL PISTON	TATA spare parts
3906251	COMPRESSOR AIR	TATA spare parts
3906252	SEAL AIR COMPRESSOR	TATA spare parts
3906254	BRACE AIR COMPRESSOR	TATA spare parts
3906284	COVER AIR COMPRESSOR	TATA spare parts
3906285	SEAL O RING	TATA spare parts
3906391	SCREW SOCKET HEAD CAP	TATA spare parts
3906412	SPRING VALVE	TATA spare parts
3906439	PLATE CLAMPING	TATA spare parts
3906440	BRACKET LIFTING	TATA spare parts
3906474	SCREEN OIL SUCTION	TATA spare parts
3906619	PLUG PIPE	TATA spare parts
3906659	SEAL INJECTOR	TATA spare parts
3906696	SEAL RECTANGULAR RING	TATA spare parts
3906697	SEAL RECT RING	TATA spare parts
3906698	SEAL RECTLR WATER	TATA spare parts
3906704	SEAL O RING	TATA spare parts
3906733	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3906854	INSERT VALVE INLET	TATA spare parts
3907049	SCREW HEX FLANGE HD CAP	TATA spare parts
3907177	SEAL RECTANGULAR RING	TATA spare parts
3907206	WASHER PLAIN	TATA spare parts
3907240	TAPPET VALVE	TATA spare parts
3907308	GEAR FLYWHEEL RING	TATA spare parts
39074	CAMSHAFT ROLLER	TATA spare parts
3907431	GEAR CAMSHAFT	TATA spare parts
3907451	MANIFOLD EXHAUST	TATA spare parts
3907454	CONNECTION TUR OIL DRAIN	TATA spare parts
39075	CAMSHAFT PIN	TATA spare parts
3907504	CONNECTOR BANJO	TATA spare parts
3907555	PLUG EXPANSION	TATA spare parts
3907582	TUBE FULE SUPPLY	TATA spare parts
3907586	BAFFLE BREATHER	TATA spare parts
3907617	GASKET PUSH ROD COVER	TATA spare parts
3907769	SCREW HEXAGON HEAD CAP (M10 X 1.75 X 70)	TATA spare parts
3907804	CRANKSHAFT ENGINE	TATA spare parts
3907860	Screw H.F.M8x1.25x25	TATA spare parts
3907861	BRACKET LIFTING	TATA spare parts
3907982	PULLEY CRANK	TATA spare parts

3907998	SCREW ROUND HEAD CAP	TATA spare parts
3908032	CRANKSHAFT ASSEMBLY	TATA spare parts
3908086	COVER & INTAKE MANIFOLD	TATA spare parts
3908095	PLATE COVER	TATA spare parts
3908110	PLUG THREADED	TATA spare parts
3908226	SCREW HEX FLANGE HD CAP	TATA spare parts
3908314	DIPSTICK	TATA spare parts
3908321	SCREW TWELVE POINT CAP	TATA spare parts
3908546	RING GEAR 145/160 HP	TATA spare parts
3908560	PULLEY ALTERNATOR	TATA spare parts
3908615	OIL FILTER	TATA spare parts
3908830	INSERT VALVE	TATA spare parts
3908985	UNION MALE	TATA spare parts
3908988	TUBE FUEL SUPPLY	TATA spare parts
3909025	SCREW HEX. FLANGE HEAD CAP	TATA spare parts
3909310	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3909355	ADAPTER FILTER HEAD	TATA spare parts
3909356	SEAL RECT RING	TATA spare parts
3909373	CONNECTION OIL SUCTION	TATA spare parts
3909395	CLAMP SPRING HOSE (1/2 INCH ID)	TATA spare parts
3909397	SEAL O RING	TATA spare parts
3909410	REAR CRANK SEAL SERVICE	TATA spare parts
3909552	CONNECTOR MALE	TATA spare parts
3909557	BUSHING REDUCING PIPE	TATA spare parts
3909582	SCREW HEX HEAD CAP	TATA spare parts
3909669	TUBE BREATHER	TATA spare parts
3909696	MANIFOLD FUEL	TATA spare parts
3909886	SEAL INJECTOR	TATA spare parts
3910248	PLUG O RING	TATA spare parts
3910260	SEAL O RING	TATA spare parts
3910265	ELBOW MALE ADAPTER	TATA spare parts
3910279	CLAMP INJECTOR	TATA spare parts
3910495	SCREW HEX FLANGE HD CAP	TATA spare parts
39105052	FLEXIBLE TUBE PVC 20MM- PER MTR	TATA spare parts
3910509	CLAMP HOSE	TATA spare parts
3910530	SEAL RECTANGULAR RING	TATA spare parts
3910715	SPACER MOUNTING	TATA spare parts
3910739	BEARING	TATA spare parts
3910780	PIPE AIR INLET	TATA spare parts
3910787	CONNECTION OIL SUCTION	TATA spare parts
3910810	LEVER ROCKER	TATA spare parts
3910811	LEVER ROCKER	TATA spare parts
3910815	ROCKER LEVER ASSY	TATA spare parts
3910824	SEAL O RING	TATA spare parts
3910881	MANIFOLD EXHAUST	TATA spare parts
3910901	SCREW	TATA spare parts
3910960	WASHER PLAIN	TATA spare parts

3910993	TUBE EXHAUST OUTLET	TATA spare parts
3911002220	DRIVE SHAFT A-P.T.O	TATA spare parts
39112003	Locking Pin Bolts M10x20	TATA spare parts
3911203	SUPPORT FAN	TATA spare parts
3911318	ASSY FAN	TATA spare parts
3911423	SUPPORT ROCKER LEVER	TATA spare parts
3911447	CONNECTOR BANJO	TATA spare parts
3911536	GASKET OIL PAN	TATA spare parts
3911557	BELT V RIBBED	TATA spare parts
3911562	BELT	TATA spare parts
3911587	BELT V RIBBED	TATA spare parts
3911901	VALVE CHECK	TATA spare parts
3911924	HUB FAN	TATA spare parts
3911925	COUPLING PLAIN HOSE	TATA spare parts
3911941	GASKET TURBOCHARGER	TATA spare parts
3912072	SCREW SELF TAP METAL	TATA spare parts
3912473	SEAL RECTANGULAR RING	TATA spare parts
3912558	GASKET CONNECTION	TATA spare parts
3912599	HOSE FLEX TC SUPPLY	TATA spare parts
3912646	LEVER THROTTLE	TATA spare parts
3912751	FAN ENGINE	TATA spare parts
3912753	FAN BLADE	TATA spare parts
3912900	PLUG EXPANSION	TATA spare parts
3913019	SUPPORT FRONT ENGINE	TATA spare parts
3913025	GASKET THERMOSTATE HOUSING	TATA spare parts
3913027	GASKET SUPPORT	TATA spare parts
3913028	THERMOSTAT	TATA spare parts
3913030	CONNECTION WATER OUTLET	TATA spare parts
3913032	GASKET CONNECTION	TATA spare parts
3913034	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3913352	GASKET CONNECTION	TATA spare parts
3913366	SCREW HEX FLANGE HEAD	TATA spare parts
3913372	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3913433	SUPPORT FAN	TATA spare parts
3913443	FUEL INJ PUMP	TATA spare parts
3913638	SCREW	TATA spare parts
3913990	BUSHING	TATA spare parts
3913994	SEAL O RING	TATA spare parts
3914029	GASKET INTAKE MANIFOLD	TATA spare parts
3914035	PLUG EXPANSION	TATA spare parts
3914118	SCREW HEX FLANGE HEAD CAP (M14 X 1.50 X	TATA spare parts
3914136	CAP FILLER	TATA spare parts
3914177	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3914284	SPACER MOUNTING	TATA spare parts
3914304	GASKET LIFT PUMP	TATA spare parts
3914383	GASKET FLANGE	TATA spare parts
3914385	GASKET GEAR COVER	TATA spare parts

3914386	GASKET	TATA spare parts
3914389	GASKET FUEL PUMP	TATA spare parts
3914407	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3914420	CLAMP HOSE (10.5 - 13 MM)	TATA spare parts
3914452	DAMPER VIBRATION	TATA spare parts
3914454	DAMPER VIBRATION	TATA spare parts
3914462	PULLEY FAN	TATA spare parts
3914708	LOCK PLATE	TATA spare parts
3914738	TUBE OIL FILLER	TATA spare parts
3914753	TUBE FUEL SUPPLY	TATA spare parts
3915082	CLAMP HOSE (3/4 - 1-1/8 INCH)	TATA spare parts
3915240	HEAD FUEL FILTER W/ADA	TATA spare parts
3915488	COUPLING ELBOW HOSE	TATA spare parts
3915489	HOSE PLAIN	TATA spare parts
3915703	PAN OIL FOR CNG ENGINE	TATA spare parts
3915772	SEAL RECT RING	TATA spare parts
3915787	PLUG THREADED	TATA spare parts
3915872	BRACE ALTERNATOR	TATA spare parts
3916048	HOSE FLEXIBLE	TATA spare parts
3916051	HOSE FLEXIBLE	TATA spare parts
3916131	GASKET GEAR HSG	TATA spare parts
3916348	CONNECTION OIL DRAIN TC	TATA spare parts
3916361	SCREW BANJO CONNECTOR	TATA spare parts
3916369	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3916438	HOSE PLAIN	TATA spare parts
3916518	SCREW HEX FL.HD CAP FOR AC VEH	TATA spare parts
3916563	BRACE FUEL PUMP	TATA spare parts
3916588	SPRING VALVE	TATA spare parts
3916625	CONNECTION WATER INLET	TATA spare parts
3916691	SPRING COMPRESSION	TATA spare parts
3916788	ISOLATOR VIBRATION	TATA spare parts
3917320	CRANKSHAFT ENGINE	TATA spare parts
3917324	THERMOSTAT	TATA spare parts
3917620	PISTON-4021	TATA spare parts
3917700	EXHAUST MANIFOLD	TATA spare parts
3917707	PISTON BARE	TATA spare parts
3917717	BRACE TUBE	TATA spare parts
3917729	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3917746	ISOLATOR VIBRATION	TATA spare parts
3917801	COVER GEAR	TATA spare parts
3917995	CLAMP SPRING HOSE	TATA spare parts
3918002	SCREW BANJO CONNECTOR	TATA spare parts
3918109	SCREW HEX FLANGE HD CAP	TATA spare parts
3918113	SHIELD DUST	TATA spare parts
3918153	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3918174	GASKET OIL COOLER CORE	TATA spare parts
3918182	BRACE TUBE	TATA spare parts



3918188	WASHER SEALING	TATA spare parts
3918190	WASHER SEALING	TATA spare parts
3918191	WASHER SEALING	TATA spare parts
3918192	WASHER SEALING	TATA spare parts
3918256	GASKET LUB COOLER CORE	TATA spare parts
3918257	GASKET LUB FILTER HEAD	TATA spare parts
3918287	GASKET HYDRAULIC PUMP	TATA spare parts
3918315	RING COMPRESSION PISTON	TATA spare parts
3918334	HEAD LUB OIL FILTER	TATA spare parts
3918367	CAP FILLER	TATA spare parts
3918427	SPRING REGULATOR	TATA spare parts
3918428	PLUNGER PRESS REGULATOR	TATA spare parts
3918521	CLAMP HOSE	TATA spare parts
3918536	HOSE FLEXIBLE	TATA spare parts
3918539	TUBE FUEL SUPPLY	TATA spare parts
3918542	SPACER MOUNTING	TATA spare parts
3918583	CONNECTION TUR OIL DRAIN	TATA spare parts
3918614	HOSE PLAIN	TATA spare parts
3918640	TUBE FUEL SUPPLY	TATA spare parts
3918641	TUBE FUEL SUPPLY	TATA spare parts
3918673	GASKET	TATA spare parts
3918675	GEAR HOUSING COVER	TATA spare parts
3918685	PIPE AIR TRANSFER	TATA spare parts
3918776	GEAR CRANK SHAFT	TATA spare parts
3918777	GEAR CAMSHAFT	TATA spare parts
3918880	TUBE FUEL SUPPLY	TATA spare parts
3918954	OIL FILTER HEAD	TATA spare parts
3918965	INJECTOR	TATA spare parts
3918986	CRANKSHAFT,ENGINE WITH GEAR	TATA spare parts
3918995	SUPPORT ENGINE FRONT	TATA spare parts
3918999	VIBRATION DAMPER	TATA spare parts
3919002	NOZZLE PISTON COOLING	TATA spare parts
3919010	INJECTOR	TATA spare parts
391901203076	SHIM 0.5THK X63X20	TATA spare parts
3919013	SUPPORT FRONT ENGINE	TATA spare parts
3919041	PISTON ENGINE	TATA spare parts
3919042	PISTON ENGINE	TATA spare parts
3919044	PISTON ENGINE-0.5 O/S	TATA spare parts
3919045	PISTON ENGINE	TATA spare parts
3919050	RING COMPRESSION PISTON	TATA spare parts
3919053	PIN PISTON	TATA spare parts
3919369	GASKET TURBOCHARGER	TATA spare parts
3919422	SOLENOID 12V	TATA spare parts
3919434	RIVET	TATA spare parts
3919435	SHAFT ROCKER LEVER	TATA spare parts
3919449	COTTER PIN	TATA spare parts
3919452	BRACKET SOLENOID	TATA spare parts

3919545	DIPSTICK	TATA spare parts
3919591	TURBO OIL SUPPLY HOSE	TATA spare parts
3919601	GASKET ACC DRIVE COVER	TATA spare parts
3919624	PULLEY ACCESSORY DRIVE	TATA spare parts
3919644	CONNECTOR BANJO	TATA spare parts
3919677	MANIFOLD OIL	TATA spare parts
3919680	GEAR CRANKSHAFT	TATA spare parts
3919683	HOUSING TIMING PIN	TATA spare parts
3919686	PLUG THREADED	TATA spare parts
3919687	CONNECTOR ASSEMBLY	TATA spare parts
3919864	SCREW HEX FLANGE HD CAP	TATA spare parts
3919918	RING COMPRESSION	TATA spare parts
3919995	SCREW HEX HEAD CAP	TATA spare parts
3920123	CONNECTION WATER OUTLET	TATA spare parts
3920191	COUPLING PLAIN HOSE	TATA spare parts
3920194	HOSE PLAIN	TATA spare parts
3920217	TUBE INJ FUEL SUPPLY	TATA spare parts
3920218	TUBE INJ FUEL SUPPLY	TATA spare parts
3920220	TUBE INJ.FUEL SUPPLY	TATA spare parts
3920224	TUBE INJ.FUEL SUPPLY	TATA spare parts
3920231	SET TUBE INJ FUEL SUPPLY	TATA spare parts
3920232	SET TUBE INJ FUEL SUPPLY	TATA spare parts
3920233	TUBE INJECTOR SUPPLY	TATA spare parts
3920234	TUBE INJECTOR SUPPLY	TATA spare parts
3920235	TUBE INJECTOR SUPPLY	TATA spare parts
3920236	TUBE INJECTOR SUPPLY	TATA spare parts
3920237	TUBE INJECTOR SUPPLY	TATA spare parts
3920238	TUBE INJECTOR SUPPLY	TATA spare parts
3920344	SCREW HEX HEAD CAP	TATA spare parts
3920346	SCREW HEX FLANGE HD CAP	TATA spare parts
3920348	CLIP	TATA spare parts
3920419	ISOLATOR VIBRATION	TATA spare parts
3920420	BRACE TUBE	TATA spare parts
3920443	PLUG EXPANSION	TATA spare parts
3920447	SCREW HEX FLANGE HD CAP	TATA spare parts
3920518	HOUSING GEAR	TATA spare parts
3920519	HOUSING GEAR	TATA spare parts
3920551	COVER INTAKE MANIFOLD	TATA spare parts
3920552	BRACKET FILTER	TATA spare parts
3920593	GEAR FUEL PUMP	TATA spare parts
3920595	MANIFOLD FUEL	TATA spare parts
3920603	TURBO SUPPLY LINE	TATA spare parts
3920622	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3920628	TUBE INJ FUEL SUPPLY	TATA spare parts
3920631	TUBE INJ.FUEL SUPPLY	TATA spare parts
3920678	ALTERNATOR SA 23 24 VOLTS	TATA spare parts
3920679	ALTERNATOR SA 23 12 VOLTS	TATA spare parts

3920686	HOSE PLAIN	TATA spare parts
3920691	RING RETAINING	TATA spare parts
3920692	RING RETAINING	TATA spare parts
3920706	PLUG EXPANSION	TATA spare parts
3920719	CLAMP HOSE	TATA spare parts
3920758	HOUSING GEAR EURO-II	TATA spare parts
3920762	HOSE ELBOW	TATA spare parts
3920773	WASHER SEALING	TATA spare parts
3920779	SCREW HEX FLANGE HD CAP	TATA spare parts
3920780	SCREW HEX FLANGE HD CAP	TATA spare parts
3920781	SCREW HEX FLANGE HD CAP	TATA spare parts
3920801	CONNECTOR FEMALE	TATA spare parts
3920802	PLUG THREADED	TATA spare parts
3920803	CONNECTOR MALE	TATA spare parts
3920831	HARNESS WIRING	TATA spare parts
3920854	SCREW HEX HEAD	TATA spare parts
3920867	VALVE INTAKE	TATA spare parts
3920868	VALVE EXHAUST	TATA spare parts
3921043	DUST COVER	TATA spare parts
3921250	FLYWHEEL 145/160 HP	TATA spare parts
3921263	FLYWHEEL	TATA spare parts
3921296	FLYWHEEL HOUSING	TATA spare parts
3921357	BRACE FUEL PUMP	TATA spare parts
3921394	GASKET CYLINDER HEAD	TATA spare parts
3921440	GASKET INT MANIFOLD COVE	TATA spare parts
3921444	VALVE EXHAUST	TATA spare parts
3921533	SHIELD DUST	TATA spare parts
3921556	CAP TUBE	TATA spare parts
3921557	COOLER LUB OIL	TATA spare parts
3921558	CORE OIL COOLER	TATA spare parts
3921640	SEAL VALVE STEM	TATA spare parts
3921642	SWITCH THERMO	TATA spare parts
3921644	CONNECTION OIL FILTER	TATA spare parts
3921652	TUBE FUEL DRAIN	TATA spare parts
3921816	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3921832	TUBE FUEL SUPPLY	TATA spare parts
3921919	RING OIL PISTON	TATA spare parts
3921981	TUBE AIR FUEL CONTROL	TATA spare parts
3921992	CONNECTION OIL SUCTION	TATA spare parts
3922072	PLUG EPANSION 58 MM	TATA spare parts
3922073	PLUG EPANSION	TATA spare parts
3922163	FLYWHEEL GB-60	TATA spare parts
3922484	CONNECTOR SPACER	TATA spare parts
3922487	SHAFT ROCKER LEVER	TATA spare parts
3922488	SHAFT ROCKER LEVER	TATA spare parts
3922503	COUPLING PLAIN HOSE	TATA spare parts
3922639	SCREW HEX FLANGE HEAD CAP	TATA spare parts

3922686	RING COMPRESSION PISTON	TATA spare parts
3922687	PISTON ENGINE	TATA spare parts
3922691	HEAD CYLINDER W/O VALVES-1510 CNG	TATA spare parts
3922701	COIL INJECTION	TATA spare parts
3922702	SPACER MOUNTING	TATA spare parts
3922704	GASKET CARBURATOR	TATA spare parts
3922706	ELEMENT STRAINER	TATA spare parts
3922713	VALVE INTAKE	TATA spare parts
3922714	VALVE EXHAUST	TATA spare parts
3922715	INSERT VALVE INTAKE 1510 CNG	TATA spare parts
3922716	INSERT VALVE EXHAUST 1510 CNG	TATA spare parts
3922718	SENSOR FUEL FLOW	TATA spare parts
3922728	MANIFOLD EXHAUST	TATA spare parts
3922739	HEAD CYLINDER-1510 CNG	TATA spare parts
3922741	SCREW HEXAGON HEAD CAP	TATA spare parts
3922745	TUBE WATER OUTLET	TATA spare parts
3922747	COUPLING ELBOW HOSE (3/4-16 (INT) X 1/2	TATA spare parts
3922754	SHIELD HEAT	TATA spare parts
3922755	BRACKET SENSOR	TATA spare parts
3922756	PLUG SPARK	TATA spare parts
3922761	STUD	TATA spare parts
3922789	CONNECTOR MALE	TATA spare parts
3922794	SEAL O RING	TATA spare parts
3922842	CLAMP HOSE	TATA spare parts
3922848	CLAMP HOSE	TATA spare parts
3922863	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3922900	TENSIONER BELT	TATA spare parts
3922952	WASHER PLAIN	TATA spare parts
3922953	SCREW TWELVE POINT CAP	TATA spare parts
3923022	SCREW HEX. FLANGE HEAD CAP	TATA spare parts
3923041	NUT LOCK	TATA spare parts
3923044	RETAINER FAN HUB	TATA spare parts
3923054	GASKET COVER PLATE	TATA spare parts
3923060	CLAMP V BAND	TATA spare parts
3923178	PIPE AIR TRANSFER	TATA spare parts
3923261	SEAL INJECTOR	TATA spare parts
3923262	ROD PUSH	TATA spare parts
3923303	HARNESS WIRING	TATA spare parts
3923331	GASKET THM HOUSING COVER	TATA spare parts
3923369	CLAMP SPRING HOSE	TATA spare parts
3923387	SUPPORT ALTERNATOR	TATA spare parts
3923478	CAMSHAFT	TATA spare parts
3923548	ELBOW PLAIN STREET PIPE	TATA spare parts
3923839	COVER GEAR	TATA spare parts
3923889	RING OIL PISTON	TATA spare parts
3923890	RING OIL PISTON	TATA spare parts
3923896	COVER GEAR	TATA spare parts

3923898	GEAR COVER	TATA spare parts
3924141	PUMP WATER	TATA spare parts
3924146	BUSHING REDUCING PIPE	TATA spare parts
3924147	DRAIN PLUG	TATA spare parts
3924148	PLUG THREADED	TATA spare parts
3924189	GEAR ACCESSORY DRIVE	TATA spare parts
3924338	HEAD OIL FILTER W/O ADA	TATA spare parts
3924346	TEE FEMALE BRANCH	TATA spare parts
3924389	WASHER SEALING	TATA spare parts
3924410	MOTOR STARTING 12VOLTS	TATA spare parts
3924473	HOUSING THERMOSTAT	TATA spare parts
3924492	VALVE INTAKE	TATA spare parts
3924571	CONNECTION WATER TRANSFER	TATA spare parts
3924582	INSERT VALVE	TATA spare parts
3924584	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3924632	COUPLING PLAIN HOSE	TATA spare parts
3924633	COUPLING ELBOW HOSE	TATA spare parts
3924636	HOSE PLAIN	TATA spare parts
3924638	HOSE PLAIN	TATA spare parts
3924681	KIT SOLENOID	TATA spare parts
3924720	PUMP LUBE OIL	TATA spare parts
3924724	SCREW BANJO CONNECTOR	TATA spare parts
3924725	SCREW	TATA spare parts
3924726	VALVE CHECK	TATA spare parts
3924867	HOSE FLEXIBLE	TATA spare parts
3924908	HOSE FLEXIBLE	TATA spare parts
3924962	SCREW HEX HEAD CAP	TATA spare parts
3924990	CONNECTOR AIR INTAKE	TATA spare parts
3925009	SPRING REGULATOR	TATA spare parts
3925089	CLAMP SPRING HOSE	TATA spare parts
3925130	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
3925186	SCREW FLAT HEAD	TATA spare parts
3925207	BRACKET BELT TENSIONER	TATA spare parts
3925223	HOUSING FLYWHEEL	TATA spare parts
3925226	CONNECTION WATER TRANSFER	TATA spare parts
3925232	ROD ENGINE CONNECTING	TATA spare parts
3925234	PLATE COVER	TATA spare parts
3925272	SPRING VALVE	TATA spare parts
3925273	ROTAR VALVE	TATA spare parts
3925274	FILTER FUEL	TATA spare parts
3925324	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
3925340	PULLEY CRANKSHAFT	TATA spare parts
3925343	FT SEAL SER KIT W/SLEEVE (FRONT)	TATA spare parts
3925344	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3925389	HEAD CYLINDER W/O VALVES	TATA spare parts
3925402	SCREW HEX FLANGE HEAD	TATA spare parts
3925429	TEE STREET PIPE	TATA spare parts

3925499	FLYWHEEL	TATA spare parts
3925529	KIT OIL SEAL	TATA spare parts
3925566	DAMPER VIBRATION	TATA spare parts
3925569	DAMPER VIBRATION	TATA spare parts
3925667	SPRING VALVE	TATA spare parts
3925855	HOSE PLAIN TURBO COOLANT	TATA spare parts
3925856	PUMP LIFT	TATA spare parts
3925860	TUBE FUEL DRAIN	TATA spare parts
3925863	GUIDE VALVE STEM	TATA spare parts
3925883	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3925955	ADAPTER FILTER HEAD	TATA spare parts
3926034	PUMP FUEL TRANSFER	TATA spare parts
3926038	HOSE FLEXIBLE	TATA spare parts
3926047	SEAL O RING	TATA spare parts
3926048	SEAL O RING	TATA spare parts
3926094	SUPPORT THERMOSTAT HOUSING	TATA spare parts
3926103	TUBE FUEL DRAIN	TATA spare parts
3926126	SLEEVE WEAR	TATA spare parts
3926203	PUMP LUBRICATING OIL	TATA spare parts
3926207	HOUSING FLYWHEEL	TATA spare parts
3926273	SUPPORT FUEL PUMP	TATA spare parts
3926411	SOLENOID FUEL PUMP 12V	TATA spare parts
3926412	SOLENOID FUEL PUMP 24V	TATA spare parts
3926484	BRACKET FAN	TATA spare parts
3926493	SPEACER FAN PILOT	TATA spare parts
3926518	HOUSING GEAR	TATA spare parts
3926632	PISTON	TATA spare parts
3926700	SPRING VALVE	TATA spare parts
3926704	CLAMP SPRING HOSE	TATA spare parts
3926722	SEAL RECTANGULAR RING	TATA spare parts
3926739	TUBE AIR FUEL CONTROL	TATA spare parts
3926760	GASKET OIL COOLER CORE	TATA spare parts
3926781	SUPPORT FUEL PUMP	TATA spare parts
3926788	HEAD FUEL FILTER	TATA spare parts
3926846	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3926847	COVER GEAR	TATA spare parts
3926855	PULLEY FAN	TATA spare parts
3926863	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3926865	SPACER MOUNTING	TATA spare parts
3926926	BRACKET BELT TENSIONER	TATA spare parts
3926972	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3927063	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3927154	GASKET EXHAUST MANIFOLD-3521TC ONLY	TATA spare parts
3927155	SUPPORT CAMSHAFT THRUST	TATA spare parts
3927167	PLATE CYL BLOCK STIFFENER	TATA spare parts
3927173	GASKET CONNECTION	TATA spare parts
3927213	SCREW HEX FLANGE HEAD	TATA spare parts

3927256	INSERT VALVE	TATA spare parts
3927282	CYLINDER HEAD W/VALVES	TATA spare parts
3927300	HEAD CYLINDER	TATA spare parts
3927317	COUPLING ELBOW HOSE	TATA spare parts
3927325	COUPLING ELBOW	TATA spare parts
3927328	HOSE PLAIN	TATA spare parts
3927368	TUBE AIR FUEL CONTROL	TATA spare parts
3927606	PLATE CYL BLOCK STIFFNER	TATA spare parts
3927611	BRACE TUBE	TATA spare parts
3927622	VALVE BYPASS	TATA spare parts
3927642	SEAL VALVE	TATA spare parts
3927692	NUT	TATA spare parts
3927693	CAMSHAFT	TATA spare parts
3927772	BRG CRANKSHAFT THRUST	TATA spare parts
3927773	BRG CRANKSHAFT THRUST RS1	TATA spare parts
3927813	HARNESS WIRING	TATA spare parts
3927814	HARNESS WIRING	TATA spare parts
3927816	CONNECTION ADAPTOR	TATA spare parts
3927825	GASKET COVER PLATE	TATA spare parts
3927827	JUMPER PIPE FROM GAS MASS FLOW SENSOR TO	TATA spare parts
3927829	CAP FILLER	TATA spare parts
3927841	VALVE AIR FUEL THROTTLE	TATA spare parts
3927847	TUBE COMPRESSOR AIR INLET	TATA spare parts
3927913	COVER PUSH ROD	TATA spare parts
3927948	MAIN BEARING BOLT	TATA spare parts
3928019	HOUSING GEAR	TATA spare parts
3928031	NOZZLE PISTON COOLING	TATA spare parts
3928143	PUMP FUEL LIFT ROTARY	TATA spare parts
3928174	INSERT VALVE	TATA spare parts
3928282	SLEEVE	TATA spare parts
3928283	SLEEVE	TATA spare parts
3928304	CAP FILLER	TATA spare parts
3928309	SCREW SOCKET HEAD CAP	TATA spare parts
3928321	ELBOW PLAIN UNION	TATA spare parts
3928342	BODY WASTEGATE VALVE	TATA spare parts
3928396	PUMP WATER	TATA spare parts
3928404	VALVE COVER	TATA spare parts
3928405	VALVE COVER	TATA spare parts
3928406	ISOLATOR NOISE	TATA spare parts
3928407	BRACE FUEL PUMP	TATA spare parts
3928408	BRACE FUEL PUMP	TATA spare parts
3928423	TUBE FUEL SUPPLY	TATA spare parts
3928425	TUBE FUEL SUPPLY	TATA spare parts
3928493	GASKET REAR COVER	TATA spare parts
3928533	COUPLING ELBOW HOSE	TATA spare parts
3928624	SEAL O RING	TATA spare parts
3928673	PISTON ENGINE	TATA spare parts

3928737	BRACE TUBE	TATA spare parts
3928759	SEAL GROMMET	TATA spare parts
3928788	CYLINDER BLOCK	TATA spare parts
3928797	BLOCK CYL.ASSY	TATA spare parts
3928828	CONNECTION OIL SUCTION	TATA spare parts
3928832	GASKET PUSH ROD COVER	TATA spare parts
3928857	COUPLING PLAIN HOSE	TATA spare parts
3928866	FAN CLUTCH ASSY 12V	TATA spare parts
3928870	BOLT CONNECTING ROD	TATA spare parts
3928873	SCREW HEX. FLANGE HEAD CAP	TATA spare parts
3928900	ISOLATOR VIBRATION	TATA spare parts
3928919	GASKET OIL DRAIN	TATA spare parts
3929005	INSERT VALVE	TATA spare parts
3929011	COVER	TATA spare parts
3929012	GASKET EXHAUST MANIFOLD	TATA spare parts
3929016	BEARING MAIN	TATA spare parts
3929017	BEARING MAIN	TATA spare parts
3929018	BEARING MAIN	TATA spare parts
3929021	BEARING MAIN	TATA spare parts
3929022	BEARING MAIN RS1	TATA spare parts
3929023	BEARING MAIN	TATA spare parts
3929027	GEAR CRANKSHAFT	TATA spare parts
3929028	GEAR CAMSHAFT	TATA spare parts
3929029	GEAR CAMSHAFT	TATA spare parts
3929031	GEAR FUEL PUMP	TATA spare parts
3929032	GEAR FUEL PUMP	TATA spare parts
3929035	GEAR FUEL PUMP	TATA spare parts
3929037	CRANKSHAFT ENGINE	TATA spare parts
3929042	CAMSHAFT	TATA spare parts
3929102	TUBE AIR FUEL CONTROL	TATA spare parts
3929152	TUBE AIR INLET	TATA spare parts
3929159	SCREEN	TATA spare parts
3929418	SUPPORT ALTERNATOR	TATA spare parts
3929457	SEAL O RING	TATA spare parts
3929460	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
3929461	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
3929490	INJECTOR	TATA spare parts
3929537	SCREW HEXAGON HEAD CAP	TATA spare parts
3929565	HOUSING GEAR	TATA spare parts
3929751	GASKET ACC DRIVE COVER	TATA spare parts
3929792	GASKET FILTER HEAD	TATA spare parts
3929795	GASKET VALVE COVER	TATA spare parts
3929842	HOUSING THERMOSTAT	TATA spare parts
3929881	GASKET EXHAUST MANIFOLD	TATA spare parts
3929886	CAMSHAFT	TATA spare parts
3929926	RING RETAINING	TATA spare parts
3929932	HOSE FLEXIBLE	TATA spare parts



3929935	SENSOR MASS FLOW	TATA spare parts
3929938	GASKET PRESSURE MODULE	TATA spare parts
3929964	PLATE COVER	TATA spare parts
3929985	CONNECTION WATER TRANSFER	TATA spare parts
3929996	COVER INTAKE MANIFOLD	TATA spare parts
3930036	BRACKET MODULE	TATA spare parts
3930037	HOSE FLEXIBLE	TATA spare parts
3930057	SEAL VALVE STEM	TATA spare parts
3930135	PUMP FUEL TRANSFER INLINE	TATA spare parts
3930139	NOZZLE PISTON COOLING	TATA spare parts
3930238	FAN ENGINE	TATA spare parts
3930242	FAN ENGINE	TATA spare parts
3930243	FAN ENGINE	TATA spare parts
3930244	SWITCH TEMP WATER 12V	TATA spare parts
3930245	SWITCH TEMPERATURE AIR	TATA spare parts
3930246	HARNESS WIRING	TATA spare parts
3930249	SCREW HEX FLANGE HEAD CAP (M 10 X 1.50 X	TATA spare parts
3930250	SCREW HEX FLANGE HEAD CAP (M 10 X 1.50 X	TATA spare parts
3930278	FAN CLUTCH ASSY 24V	TATA spare parts
3930279	SWITCH TEMP WATER 24V	TATA spare parts
3930280	HARNESS WIRING	TATA spare parts
3930282	PAN OIL	TATA spare parts
3930337	PUMP LUBE OIL	TATA spare parts
3930347	CAMSHAFT	TATA spare parts
3930408	GASKET OIL PAN	TATA spare parts
3930509	LEVER CONTROL LINKAGE	TATA spare parts
3930514	VALVE PRESSURE	TATA spare parts
3930543	ISOLATOR NOISE	TATA spare parts
3930675	SUPPORT FRONT ENGINE	TATA spare parts
3930697	TUBE VENT	TATA spare parts
3930708	SCREW HEXAGON HEAD CAP	TATA spare parts
3930789	TEE STREET PIPE	TATA spare parts
3930806	HOSE PLAIN	TATA spare parts
3930825	HOSE PLAIN	TATA spare parts
3930827	HOSE PLAIN	TATA spare parts
3930903	COVER VALVE	TATA spare parts
3930906	GASKET VALVE COVER	TATA spare parts
3930910	PLUG THREADED	TATA spare parts
3930911	SEAL O RING	TATA spare parts
3930969	HEAD FUEL FILTER	TATA spare parts
3931014	COUPLING PLAIN HOSE	TATA spare parts
3931084	PLUG THREADED	TATA spare parts
3931265	TUBE OIL GAUGE	TATA spare parts
3931266	DIPSTICK	TATA spare parts
3931267	CLAMP SPRING HOSE	TATA spare parts
3931346	GASKET OIL PAN	TATA spare parts
3931380	GEAR FUEL PUMP	TATA spare parts

3931382	GEAR FUEL PUMP	TATA spare parts
3931440	MANIFOLD EXHAUST	TATA spare parts
3931450	GEAR FUEL PUMP	TATA spare parts
3931607	GASKET FUEL PUMP	TATA spare parts
3931623	TAPPET VALVE	TATA spare parts
3931678	SPARK PLUG WIRE	TATA spare parts
3931688	SEAL O RING	TATA spare parts
3931689	SEAL O RING	TATA spare parts
3931709	VALVE FULE CONTROL	TATA spare parts
3931710	VALVE FULE SHUT OFF	TATA spare parts
3931711	SENSOR OXYGEN.	TATA spare parts
3931744	EXHAUST MANIFOLD	TATA spare parts
3931824	SEAL O RING	TATA spare parts
3931827	TUBE TUR OIL DRAIN	TATA spare parts
3931835	FUEL INJECTION PUMP	TATA spare parts
3931836	FUEL INJ PUMP 145HP INLINE	TATA spare parts
3931837	FUEL INJECTION PUMP	TATA spare parts
3931839	MTG BKT SOL SWITCH 2516	TATA spare parts
3931840	BRACE AIR COMPRESSOR	TATA spare parts
3931841	SPACER PUMP SUPPORT	TATA spare parts
3931842	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
3931843	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
3931844	TUBE INJ FUEL SUPPLY	TATA spare parts
3931845	TUBE INJ FUEL SUPPLY	TATA spare parts
3931846	TUBE INJ FUEL SUPPLY	TATA spare parts
3931850	ADAPTER LEVER	TATA spare parts
3931851	HOSE FLEXIBLE	TATA spare parts
3931853	TUBE FUEL SUPPLY	TATA spare parts
3931858	LONG BLOCK ROTARY	TATA spare parts
3931860	ADAPTER BRAKE OVER LEVER	TATA spare parts
3931861	SEAL INJECTOR	TATA spare parts
3931862	INJECTOR	TATA spare parts
3931864	HOSE PLAIN	TATA spare parts
3931865	CLAMP HOSE	TATA spare parts
3931866	WATER SEPARATOR	TATA spare parts
3931867	STUD	TATA spare parts
3931868	STRAINER FUEL	TATA spare parts
3931870	HOSE PLAIN	TATA spare parts
3931871	WASHER PLAIN	TATA spare parts
3931872	TUBE OIL FILLER	TATA spare parts
3931874	FLY WHEEL BEARING GB-60	TATA spare parts
3931875	PILOT BEARING	TATA spare parts
3931881	TUBE DIPSTICK	TATA spare parts
3931882	TUBE OIL GAUGE	TATA spare parts
3931883	TUBE OIL GAUGE	TATA spare parts
3931886	AIR COMPRESSOR	TATA spare parts
3931887	DIPSTICK	TATA spare parts

3931888	DIPSTICK	TATA spare parts
3931889	DIPSTICK	TATA spare parts
3931890	SNUBBER	TATA spare parts
3931891	HOSE FLEXIBLE	TATA spare parts
3931892	HEAD FUEL FILTER	TATA spare parts
3931896	AIR COMPRESSOR	TATA spare parts
3931897	AIR COMPRESSOR	TATA spare parts
3931898	SPACER FAN PILOT	TATA spare parts
3931900	PIN THROTTLE LEVER PIVOT	TATA spare parts
3931901	LONG BLOCK INLINE FIP	TATA spare parts
3931902	BRACKET SOLENIOD	TATA spare parts
3931903	CONNECTION SPACER	TATA spare parts
3931904	Liquid Gasket	TATA spare parts
3931910	KIT CONVERSION ROTARY TO INLINE	TATA spare parts
3931911	LIFT PUMP CONVERSION KIT	TATA spare parts
3931914	HOSE PLAIN	TATA spare parts
3931967	GASKET OIL PAN	TATA spare parts
3932063	GASKET EXHAUST MANIFOLD	TATA spare parts
3932120	GEAR HOUSING	TATA spare parts
3932217	ELEMENT LUB OIL	TATA spare parts
3932224	PUMP FUEL TRANS 210HP IN	TATA spare parts
3932225	PUMP FUEL TRANSFERE INLIN	TATA spare parts
3932228	PUMP FUEL TRANSFER	TATA spare parts
3932430	ISOLATOR NOISE	TATA spare parts
3932520	RING OIL PISTON	TATA spare parts
3932728	MANIFOLD EXHAUST	TATA spare parts
3933068	SEAL O RING	TATA spare parts
3933069	SEAL O RING	TATA spare parts
3933070	O' RING	TATA spare parts
3933071	O' RING	TATA spare parts
3933072	SEAL O RING	TATA spare parts
3933073	SEAL O RING	TATA spare parts
3933074	FUEL CONTROL VALVE	TATA spare parts
3933077	LOW VALVE PRESSURE REGULATOR	TATA spare parts
3933080	VALVE FUEL SHUT OFF	TATA spare parts
3933087	BRACKET IGNITION COIL	TATA spare parts
3933088	INSERT VALVE	TATA spare parts
3933198	CONNECTION TUR OIL DRAIN	TATA spare parts
3933253	PUMP	TATA spare parts
3933256	PUMP FUEL TRANSFER	TATA spare parts
3933262	KIT OIL SEAL	TATA spare parts
3933348	LEVER THROTTLE	TATA spare parts
3933384	COVER REAR	TATA spare parts
3933463	VALVE AIR FUEL THROTTLE	TATA spare parts
3933519	HOSE PLAIN	TATA spare parts
3933524	TUBE BREATHER	TATA spare parts
3933549	ADAPTER AIR INLET	TATA spare parts

3933552	COVER OIL DRAIN BACK	TATA spare parts
3933558	SCREW HEX FLANGE HEAD	TATA spare parts
3933559	MODULE ELECTEONIC CONTROL	TATA spare parts
3933564	TUBE COUPLING	TATA spare parts
3933566	HOSE PLAIN	TATA spare parts
3933571	HOSE PLAIN	TATA spare parts
3933572	TUBE COUPLING	TATA spare parts
3933577	MODULE INGNITION CONTROL	TATA spare parts
3933841	VALVE FUEL FLOW	TATA spare parts
3933846	VALVE WASTEGATE CONTROL-LEAN BURN ENGIN	TATA spare parts
3934041	SPACER STARTING MOTOR	TATA spare parts
3934046	PIN PISTON	TATA spare parts
3934047	PIN PISTON	TATA spare parts
3934054	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3934171	SOLENOID 12V	TATA spare parts
3934221	WIRE SPARK PLUG	TATA spare parts
3934410	VALVE BYPASS	TATA spare parts
3934486	RR CRANKSEAL SERV KIT	TATA spare parts
3934636	GEAR FUEL PUMP	TATA spare parts
3934659	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3934681	HOSE PLAIN COMPRESSOR COOLANT	TATA spare parts
3934683	MODULE ELECTRONIC CONTROL-LEAN BURN ENG	TATA spare parts
3934686	HARNES WIRING	TATA spare parts
3934703	HOUSING FUEL CONTROL	TATA spare parts
3934864	NUT CONNECTING ROD	TATA spare parts
3934877	CONNECTION W/INLET	TATA spare parts
3934881	ELBOW MALE UNION	TATA spare parts
3934920	ROCKER LEVER	TATA spare parts
3934921	LEVER ROCKER	TATA spare parts
3934942	CONNECTION OIL SUCTION	TATA spare parts
3935113	CONNECTION VENT	TATA spare parts
3935229	SHAFT IDLER	TATA spare parts
3935234	PLUG EXPANSION	TATA spare parts
3935266	CONNECTOR ENGINE VENT	TATA spare parts
3935267	CLAMP	TATA spare parts
3935268	SCREW	TATA spare parts
3935269	LEVER FUEL SHUT-OFF	TATA spare parts
3935270	BRACKET	TATA spare parts
3935271	SCREW	TATA spare parts
3935272	BRACKET	TATA spare parts
3935280	BRACKET HEAT SHIELD	TATA spare parts
3935283	HOSE	TATA spare parts
3935285	SUPPORT FRT ENGINE ASSY	TATA spare parts
3935298	ADAPTER	TATA spare parts
3935302	TUBE OIL FILTER	TATA spare parts
3935306	SPACER - FAN	TATA spare parts
3935307	TUBE FUEL DRAIN	TATA spare parts

3935319	PUMP	TATA spare parts
3935320	TUBE	TATA spare parts
3935321	TUBE	TATA spare parts
3935322	GASKET	TATA spare parts
3935325	ALTERNATOR 12V	TATA spare parts
3935326	ALTERNATOR 24V	TATA spare parts
3935327	MOTOR STARTING 12V	TATA spare parts
3935328	MOTOR STARTING 24 VOLTS	TATA spare parts
3935332	FAN ENGINE	TATA spare parts
3935334	CYLINDER BLOCK R/S I	TATA spare parts
3935335	BELT V RIBBED	TATA spare parts
3935338	CLAMP V BAND	TATA spare parts
3935339	CLAMP V BAND	TATA spare parts
3935340	CLUTCH VISCOUS FAN	TATA spare parts
3935341	FAN	TATA spare parts
3935347	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3935349	CONNECTING ROD	TATA spare parts
3935350	TUBE FUEL SUPPLY	TATA spare parts
3935361	AIR TRANSFER TUBE	TATA spare parts
3935362	GEAR FLYWHEEL RING	TATA spare parts
3935363	PULLEY FAN CAST IRON	TATA spare parts
3935364	ASSY FLYWHEEL	TATA spare parts
3935365	FAN ENGINE	TATA spare parts
3935449	ISOLATOR NOISE	TATA spare parts
3935582	COVER GEAR	TATA spare parts
3935878	GASKET VALVE COVER	TATA spare parts
3935959	OIL SEAL	TATA spare parts
3936021	GEAR FUEL PUMP	TATA spare parts
3936178	HEAD CYLINDER	TATA spare parts
3936180	GASKET OIL PAN	TATA spare parts
3936201	TENSIONER BELT	TATA spare parts
3936213	TENSIONER BELT	TATA spare parts
3936236	SPACER	TATA spare parts
3936256	HOUSING GEAR	TATA spare parts
3936292	HEAD CYLINDER	TATA spare parts
3936316	PUMP FUEL TRANSFER	TATA spare parts
3936317	PUMP FUEL TRANS 210HP IN	TATA spare parts
3936365	VALVE BYPASS	TATA spare parts
3936552	CLAMP HOSE	TATA spare parts
3936553	CLAMP HOSE	TATA spare parts
3936554	CLAMP HOSE	TATA spare parts
3936561	MANIFOLD FUEL	TATA spare parts
3936562	KIT UPPER GASKET	TATA spare parts
3936563	KIT LOWER GASKET	TATA spare parts
3936565	KIT MANUAL FUEL SHUT OFF	TATA spare parts
3936566	KIT VISCOUS FAN	TATA spare parts
3936567	KIT FIXED FAN	TATA spare parts

3936572	RETAINER VALVE SPRING	TATA spare parts
3936575	FLYWHEEL GB-60	TATA spare parts
3936578	COVER PUSH ROD	TATA spare parts
3936581	SPACER FAN PILOT - 30 mm	TATA spare parts
3936583	CLAMP HOSE	TATA spare parts
3936584	CONNECTION WATER OUTLET	TATA spare parts
3936586	COVER INTAKE MANIFOLD	TATA spare parts
3936592	KIT WATER PUMP	TATA spare parts
3936593	BANJO CONNECTOR	TATA spare parts
3936594	HOSE PIPE	TATA spare parts
3936599	OIL PAN	TATA spare parts
3936600	BLOCK CYLINDER	TATA spare parts
3936607	CONNECTION EXH OUTLET	TATA spare parts
3936608	FLY WHEEL HOUSING	TATA spare parts
3936609	FIP (ROTARY) 125HP	TATA spare parts
3936611	HOUSING FLYWHEEL	TATA spare parts
3936612	KEY PLAIN WOODRUFF	TATA spare parts
3936616	ADAPTOR AIR INLET	TATA spare parts
3936617	BRACKET	TATA spare parts
3936618	FIP (ROTARY) 145HP EUROII 24V	TATA spare parts
3936619	FIP (ROTARY) 160HP EUROII 24V	TATA spare parts
3936628	FIP (ROTARY) 125HP EUROII 12V	TATA spare parts
3936630	HOSE PLAIN	TATA spare parts
3936631	HOSE PLAIN	TATA spare parts
3936632	HOSE PLAIN	TATA spare parts
3936633	HOSE ELBOW	TATA spare parts
3936634	FIP (ROTARY) 145HP EUROII 12V	TATA spare parts
3936635	FIP (ROTARY) 160HP	TATA spare parts
3936636	INJECTOR-125HP	TATA spare parts
3936637	INJECTOR 145 HP EURO II	TATA spare parts
3936638	INJECTOR 160 HP EURO II	TATA spare parts
3936641	PLUG PIPE	TATA spare parts
3936642	PLUG PIPE	TATA spare parts
3936646	BRACE FUEL PUMP	TATA spare parts
3936651	RING SET STD 210 HP	TATA spare parts
3936652	SET PISTON BARE STD	TATA spare parts
3936653	SET PISTON BARE RS-I	TATA spare parts
3936654	SET PISTON BARE R/S 2	TATA spare parts
3936655	SET PISTON BARE STD-210HP	TATA spare parts
3936658	KIT-DIPSTICK LP/LPO 1512TC	TATA spare parts
3936659	KIT-DIPSTICK LPT1615TC/2516TC	TATA spare parts
3936660	KIT-DIPSTICK SE/SK 1613/1615TC	TATA spare parts
3936661	HOUSING FLYWHEEL	TATA spare parts
3936663	HOSE FLEXIBLE	TATA spare parts
3936665	TEE MALE UNION	TATA spare parts
3936667	SUPPORT-ALTERNATOR	TATA spare parts
3936668	SPACER FAN PILOT - 45 mm	TATA spare parts

3936669	MANIFOLD FUEL	TATA spare parts
3936670	TUBE AIR FUEL CON	TATA spare parts
3936671	TUBE FUEL SUPPLY	TATA spare parts
3936672	TUBE FUEL DRAIN	TATA spare parts
3936673	TUBE FUEL DRAIN	TATA spare parts
3936680	ALTERNATOR 12V 55 A	TATA spare parts
3936757	HOSE PLAIN	TATA spare parts
3936832	HOSE PLAIN TURBO COOLANT	TATA spare parts
3936838	TUBE CPR WATER OUTLET	TATA spare parts
3936876	SEAL RECTAGULAR RING	TATA spare parts
3936895	COVER REAR	TATA spare parts
3936953	CONNECTION MALE	TATA spare parts
3936993	GASKET INT MANIFOLD COVER	TATA spare parts
3937122	STUD	TATA spare parts
3937123	STUD (M10 X 1.50 (BOTH ENDS) X 50	TATA spare parts
3937181	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3937214	NOZZLE PISTON COOLING	TATA spare parts
3937298	HOSE ELBOW	TATA spare parts
3937301	COIL IGNITION	TATA spare parts
3937309	BRACKET WIRING RETAINE	TATA spare parts
3937324	HAMESS WIRING - CNG BUS	TATA spare parts
3937327	CONNECTION EXHAUST OUTLET	TATA spare parts
3937404	OIL PUMP	TATA spare parts
3937405	TUBE OIL FILLER	TATA spare parts
3937438	SCREW ROCKER LEVER ADJUSTING	TATA spare parts
3937613	HOSE ELBOW	TATA spare parts
3937706	GASKET OIL DRAIN	TATA spare parts
3937743	CARTRIDGE LUB. OIL FILTER	TATA spare parts
3938036	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3938056	HOSE PLAIN	TATA spare parts
3938077	NUT LOCK	TATA spare parts
3938091	SUPPORT FUEL PUMP	TATA spare parts
3938152	GASKET INT MANIFOLD COVER	TATA spare parts
3938156	GASKET GEAR HOUSING	TATA spare parts
3938160	GASKET OIL PAN	TATA spare parts
3938267	GASKET CYLINDER HEAD	TATA spare parts
3938331	TUBE PRESSURE SENSING	TATA spare parts
3938669	CONNECTION EXHAUST OUTLET	TATA spare parts
3938693	V BELT	TATA spare parts
3938821	HOUSING FUEL CONTROL	TATA spare parts
3938841	STUD	TATA spare parts
3938871	AIR FUEL MIXER	TATA spare parts
3938872	HOUSING FUEL CONTROL	TATA spare parts
3938873	BRACKET SENSOR	TATA spare parts
3938875	BRACKET MODULE	TATA spare parts
3938881	COVER INTAKE MANIFOLD	TATA spare parts
3938918	CONNECTION AIR INTAKE	TATA spare parts

3938920	HARNESS WIRING	TATA spare parts
3938921	BRACKET WIRING RETAINER	TATA spare parts
3939202	TUBE AIR FUEL CONTROL	TATA spare parts
3939258	GASKET COVER PLATE	TATA spare parts
3939313	BLOCK CYLINDER	TATA spare parts
3939352	GASKET OIL SUC CONNECTION	TATA spare parts
3939353	GASKET REAR COVER	TATA spare parts
3939580	BELT - LPK 2516 AC MODEL	TATA spare parts
3939859	BEARING CONNECTING ROD	TATA spare parts
3940059	BUSHING	TATA spare parts
3940123	COLLET VALVE	TATA spare parts
3940245	GASKET HYDRAULIC PUMP	TATA spare parts
3940288	BRACKET LIFTING	TATA spare parts
3940386	SEAL O RING	TATA spare parts
3940632	THERMOSTAT	TATA spare parts
3940639	CLAMP INJECTOR	TATA spare parts
3940734	VALVE EXHAUST	TATA spare parts
3940735	VALVE INTAKE	TATA spare parts
3940777	RING COMPRESSION PISTON	TATA spare parts
3940817	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3941253	ROD PUSH	TATA spare parts
3941437	COVER INTAKE MANIFOLD	TATA spare parts
3941472	UNION MALE	TATA spare parts
3941476	BUSHING	TATA spare parts
3941556	PLATE CYL BLOCK STIFFNER	TATA spare parts
3941742	OIL PUMP	TATA spare parts
3941976	STUD	TATA spare parts
3942247	SCREW ROUND HEAD CAP	TATA spare parts
3942535	SEAL OIL	TATA spare parts
3942565	TAPPET VALVE	TATA spare parts
3942659	SCREW CPT ISOLATOR CAP	TATA spare parts
3942896	SUPPORT FAN	TATA spare parts
3942911	BRACE AIR COMPRESSOR	TATA spare parts
3942914	GASKET LUB COOLER	TATA spare parts
3942915	GASKET FILTER HEAD	TATA spare parts
3943161	SPRING VALVE	TATA spare parts
3943198	RETAINER VALVE SPRING	TATA spare parts
3943215	BRACKET LIFTING	TATA spare parts
3943300	CONNECTION WATER OUTLET	TATA spare parts
3943447	RING COMPRESSION	TATA spare parts
3943449	INSERT VALVE	TATA spare parts
3943450	INSERT VALVE	TATA spare parts
3943520	CLAMP TUBE	TATA spare parts
3943591	PULLEY FAN	TATA spare parts
3943603	BRACE AIR COMPRESSOR	TATA spare parts
3943626	CROSSHEAD VALVE	TATA spare parts
3943670	FITTING ORIFICE	TATA spare parts



3943808	PLUG EXPANSION	TATA spare parts
3943828	CONNECTION TUR OIL DRAIN	TATA spare parts
3943871	MANIFOLD EXHAUST	TATA spare parts
3943875	MANIFOLD EXHAUST	TATA spare parts
3943885	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3944000	SPACER MOUNTING	TATA spare parts
3944061	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3944152	SCREW HEX FLANGE HEAD	TATA spare parts
3944153	BEARING MAIN	TATA spare parts
3944158	BEARING MAIN	TATA spare parts
3944163	BEARING CRANKSHAFT THRUST	TATA spare parts
3944293	GASKET GEAR HOUSING	TATA spare parts
3944429	CONNECTION WATER OUTLET	TATA spare parts
3944516	GEAR ACCESSORY DRIVE	TATA spare parts
3944593	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3944655	SCREW HEAD FLANGE HEAD CAP	TATA spare parts
3944720	CONNECTION WATER INLET	TATA spare parts
3944816	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3944874	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3945094	PLUG EXPANSION	TATA spare parts
3945095	PLUG EXPANSION	TATA spare parts
3945212	ELBOW PLAIN UNION	TATA spare parts
3945252	SPACER MOUNTING	TATA spare parts
3945329	BUSHING	TATA spare parts
3945603	GASKET CONNECTION	TATA spare parts
3945799	COVER VALVE	TATA spare parts
3945827	RING COMPRESSION	TATA spare parts
3945851	HOSE FLEXIBLE	TATA spare parts
3945917	BEARING MAIN	TATA spare parts
3945926	BEARING CRANKSHAFT THRUST (0.25MM OVER	TATA spare parts
3945927	BEARING CRANKSHAFT THRUST (0.50MM OVER	TATA spare parts
3945928	BEARING THRUST (0.50MM OVERSIZE JOURNA	TATA spare parts
3945967	PLUNGER PRS REGULATOR	TATA spare parts
3946168	SCREW CPT ISOLATOR CAP	TATA spare parts
3946625	RETAINER INJ FUL SUP CNR	TATA spare parts
3947759	TAPPET VALVE	TATA spare parts
3948044	COVER GEAR	TATA spare parts
3948072	PUMP LUBRICATING OIL	TATA spare parts
3948083	PLATE COVER	TATA spare parts
3948095	LINER CYLINDER	TATA spare parts
3949326	DOWEL RING	TATA spare parts
3949419	STUD	TATA spare parts
3949830	SCREW ROUND HEAD CAP	TATA spare parts
3950661	BEARING CONNECTING ROD	TATA spare parts
3954111	DOWEL RING	TATA spare parts
3954949	PULLEY CRANKSHAFT	TATA spare parts
3955069	RING SPEED INDICATOR	TATA spare parts

3955152	GEAR CAMSHAFT	TATA spare parts
3955153	GEAR FUEL PUMP	TATA spare parts
3955219	ISOLATOR VIBRATION	TATA spare parts
3955220	ISOLATOR VIBRATION	TATA spare parts
3955339	GASKET EXHAUST MANIFOLD	TATA spare parts
3955393	SEAL VALVE STEM	TATA spare parts
3955394	SEAL VALVE STEM	TATA spare parts
3957290	VALVE CHECK	TATA spare parts
3957849	SCREW SOCKET HEAD CAP	TATA spare parts
3957912	OIL SEAL VALVE STEM	TATA spare parts
3957913	VALVE RETAINER	TATA spare parts
3957914	ROTATOR VALVE	TATA spare parts
3958414	ASSY. PROPELLER SHAFT	TATA spare parts
3958753	ASSLY ROCKER LEVER	TATA spare parts
3959052	GASKET OIL PAN	TATA spare parts
3959079	PISTON RING 2ND COMPRESSION	TATA spare parts
3960043	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3963668	SPACER MOUNTING	TATA spare parts
3963669	SCREW HEXAGON HEAD CAP	TATA spare parts
3963983	WASHER SEALING	TATA spare parts
3964020	COVER INTAKE	TATA spare parts
3964337	CONNECTOR QCK DISCONNECT	TATA spare parts
3964422	GEAR HOUSING	TATA spare parts
3964547	COIL IGNITION	TATA spare parts
3964817	SCREW BANJO CONNECTOR	TATA spare parts
3965146	PULLEY ALTERNATOR	TATA spare parts
3965147	PULLEY ALTERNATOR	TATA spare parts
3965818	CLAMP TUBE	TATA spare parts
3965953	MODULE ELECTRONIC CONTROL	TATA spare parts
3966154	PUMP FUEL TRANSFER FOR EURO II ROTARY FI	TATA spare parts
3966404	WIRE SPARK PLUG	TATA spare parts
3966856	TUBE AIR TRANSFER	TATA spare parts
3966859	COUPLING PLAIN HOSE	TATA spare parts
3966976	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3967195	THERMOSTAT	TATA spare parts
3967611	GEAR ACCESSORY DRIVE	TATA spare parts
3967613	GEAR CAMSHAFT	TATA spare parts
3967615	GEAR CAMSHAFT	TATA spare parts
3967952	TUBE CPR WATER INLET	TATA spare parts
3968013	TUBE CPR WATER OUTLET	TATA spare parts
3968025	MODULE INGNITION CONTROL	TATA spare parts
3968202	CAP FILLER	TATA spare parts
3968264	BRACKET SENSOR	TATA spare parts
3968266	HARNESS ETR CNT MDL WR	TATA spare parts
3968267	HARNESS WIRING	TATA spare parts
3968466	SCREW TWELVE POINT CAP	TATA spare parts
3968563	SEAL OIL	TATA spare parts

3968732	KIT CYLINDER BLOCK	TATA spare parts
3969069	SPACER MOUNTING	TATA spare parts
3969110	COMPRESSOR AIR	TATA spare parts
3969344	HOSE FLEXIBLE	TATA spare parts
3969698	SEAL O RING	TATA spare parts
3970548	KIT OIL SEAL	TATA spare parts
3970618	HOUSING FUEL CONTROL	TATA spare parts
3970655	SPRING COMPRESSION	TATA spare parts
3970806	ACTUATOR	TATA spare parts
3970807	ACTUATOR	TATA spare parts
3970810	SCREW HEX FLANGE HEAD CAP (M14 X 2.00 13	TATA spare parts
3970880	PUMP FUEL TRANSFER FOR EURO II ROTARY FI	TATA spare parts
3970886	GASKET BREATHER	TATA spare parts
3970951	BUSHING	TATA spare parts
3970955	CAP MAIN BEARING	TATA spare parts
3971371	TUBE BREATHER	TATA spare parts
3971394	ROD ENGINE CONNECTING	TATA spare parts
3971411	BLOCK CYLINDER	TATA spare parts
3971520	GEAR ACCESSORY DRIVE	TATA spare parts
3972386	BELT V RIBBED	TATA spare parts
3972757	RETAINER VALVE SPRING	TATA spare parts
3972811	ELBOW PLAIN UNION	TATA spare parts
3973087	MODULE IGNITION CONTROL	TATA spare parts
3973114	PUMP WATER	TATA spare parts
3973509	GASKET OIL PAN	TATA spare parts
3973745	KIT OIL SEAL	TATA spare parts
3973779	HOSE PLAIN 1150 MM	TATA spare parts
3974157	CAP MAIN BEARING	TATA spare parts
3974159	CAP MAIN BEARING	TATA spare parts
3974292	PAN OIL	TATA spare parts
3974325	HEAD LUB OIL FILTER	TATA spare parts
3974393	COUPLING ELBOW HOSE	TATA spare parts
3974815	CORE COOLER	TATA spare parts
3975240	TEE PLAIN ADAPTER	TATA spare parts
3975656	BRACE AIR COMPRESSOR	TATA spare parts
3975662	SPACER MOUNTING	TATA spare parts
3975703	CONNECTOR INJ FUEL SUPPLY - ( IMS 49032	TATA spare parts
3975818	COOLER OIL	TATA spare parts
3976172	COVER VALVE	TATA spare parts
3976366	COMPRESSOR AIR	TATA spare parts
3976370	CLAMP INJECTOR	TATA spare parts
3976417	HOSE FLEXIBLE	TATA spare parts
3976600	TUBE PRESSURE SENSING	TATA spare parts
3976834	TENSIONER BELT	TATA spare parts
3976947	SEAL O RING	TATA spare parts
3976948	SEAL O RING	TATA spare parts
3976949	SEAL O RING	TATA spare parts

3976999	DIPSTICK	TATA spare parts
3977063	GASKET CYLINDER HEAD	TATA spare parts
3977194	HARNESS ETR CNT MDL WRG	TATA spare parts
3977298	CONNECTOR MALE	TATA spare parts
3977357	WIRE GROUND	TATA spare parts
3977410	SUPPORT CONNECTION	TATA spare parts
3977530	MANIFOLD FUEL	TATA spare parts
3977572	SCREW ROUND HEAD CAP	TATA spare parts
3977790	TUBE LUB OIL SUCTION	TATA spare parts
3977854	PLUG THREADED	TATA spare parts
3977855	PLUG THREADED	TATA spare parts
3977986	MODULE ELECTRONIC CONTROL-LEAN BURN ENG	TATA spare parts
3978022	TENSIONER BELT	TATA spare parts
3978031	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
3978032	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
3978034	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
3978036	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
3978324	PULLEY IDLER	TATA spare parts
3978473	SUPPORT FRONT ENGINE	TATA spare parts
3978478	FLANGE CRANKSHAFT	TATA spare parts
3979211	MANIFOLD EXHAUST	TATA spare parts
3979349	GASKET GEAR HOUSING	TATA spare parts
3979420	NUT REGULAR HEXAGON	TATA spare parts
3979506	CAMSHAFT	TATA spare parts
399002002001	REAR STRUCTURAL ASSEMBLY	TATA spare parts
399002002002	REAR STRUCTURE ASSEMBLY WITHç RLB	TATA spare parts
399002002011	REAR STRUCTURE ASSEMBLY_Y1 52WB	TATA spare parts
399002003011	SIDE PILLER ASSEMBLY LH SIDE_Y1 BS6	TATA spare parts
399002003019	UPPER ARC WINDSHIELD TUBE ASSY. BS6	TATA spare parts
399002003021	ROOF ARCH ASSY.	TATA spare parts
399002013030	TOP ROOF CENTRE TUBE_Y1	TATA spare parts
399002013031	TOP ROOF TUBE_Y1	TATA spare parts
399002013032	FRONT TOP TUBE_Y1	TATA spare parts
399002013033	CROSS CONNECTING TUBE LH SIDE_Y1	TATA spare parts
399002013034	CROSS CONNECTING TUBE RH SIDE_Y1	TATA spare parts
399002083009	FRONT STRUCTURE SUPPORT PLATE._Y1 BS6	TATA spare parts
399002083012	UNION PLATE FOR ROOF SIDE STRUCTRE LH_Y1	TATA spare parts
399002083013	UNION PLATE FOR ROOF SIDE STRUCURE RH_Y1	TATA spare parts
399002083014	FRONT STRUCTURE SUPPORT PLATE._Y1 BS6	TATA spare parts
399002083015	GUSSET SIDE	TATA spare parts
399003003014	A PILLAR - LH	TATA spare parts
399003003015	A PILLAR - RH	TATA spare parts
399003003029	DOOR TUBE ASSY 42 RHD	TATA spare parts
399003003030	DOOR TUBE ASSEMBLY 49 RHD	TATA spare parts
399003004047	DOOR SIDE RUBE RH ASSY	TATA spare parts
399003013099	WHEEL ARCH UPPER TUBE R.H FRONT	TATA spare parts
399003013435	PASSENGER DOOR FRONT COLUMN BS6	TATA spare parts

399003013467	30X40 SOLE BAR 417 LONG	TATA spare parts
399003014020	DRIVER DOOR PILLAR TUBE	TATA spare parts
399003014074	A FILLER	TATA spare parts
399003083008	FUEL TANK FILLER NECK STRUCTURE	TATA spare parts
399003083015	WHEEL ARCH FRONT OF L.H	TATA spare parts
399003083039	WHEEL ARCH FRONT OF R.H	TATA spare parts
399003083049	WHEEL ARCH REAR OF L.H_49WB	TATA spare parts
399003083052	SIDE STR LH GUSSET BS6	TATA spare parts
399003083053	WHEEL ARCH REAR OF R.H_49WB	TATA spare parts
399003083374	WHEEL ARCH REAR OF L.H_BANJO AXLE BS6	TATA spare parts
399005013027	CROSS MEMEMBER BASE TUBE	TATA spare parts
399005013028	CROSS MEMEMBER BASE TUBE	TATA spare parts
399007013010	ROOF STRUCTURE TUBE	TATA spare parts
399007013018	ROOF ARCH TUBE- 50X40X1.95	TATA spare parts
399007013020	ROOF STRUCTURE TUBE AT FRONT RIGHT	TATA spare parts
399007013021	ROOF STRUCTURE TUBE AT FRONT LEFT	TATA spare parts
399007013022	WINDSHIELD UPPER ROOF STRUCTURE TUBE	TATA spare parts
399007083074	INNER MIRROR HOLDING BRACKET	TATA spare parts
399007084003	ROOF STRUCTURE CHANNEL	TATA spare parts
399010002012	PNEUMATIC SINGLE COMPLETE KIT ASSY	TATA spare parts
399010239001	WINDSHIELD FRONT LCV WP BS1/2/3/4	TATA spare parts
399010900012	CONDENSER COIL LHS	TATA spare parts
399010900013	CONDENSER COIL RHS	TATA spare parts
399010900075	FILTER DRIER HOSE CLAMP	TATA spare parts
399010900252	THERMAL MASS	TATA spare parts
399010900253	EVAPORATOR COIL	TATA spare parts
399010900254	EVAPORATOR COIL	TATA spare parts
399010900255	CONDENSER COIL	TATA spare parts
399010900256	CONDENSER COIL	TATA spare parts
399010900257	CONDENSER COIL	TATA spare parts
399010900258	CONDENSER COIL	TATA spare parts
399010900259	EVAPORATOR COIL	TATA spare parts
399010900260	EVAPORATOR COIL	TATA spare parts
399010900261	TEPERATURE SENSOR	TATA spare parts
399010900262	RELAY BOARD 24V	TATA spare parts
399010900263	RELAY BOARD GL 12V	TATA spare parts
399010900264	DASH CONTROL	TATA spare parts
399010900265	FUSE 100A	TATA spare parts
399010900266	ALTERNATOR 150A 12V	TATA spare parts
399010900267	ALTERNATOR 120A - 24V	TATA spare parts
399010900268	SWITCH PRESSURE HIGH	TATA spare parts
399010900269	SWITCH PRESSURE LOW	TATA spare parts
399010900270	REUSABLE STRAIGHT NUT 20 FITTING (SUCTION	TATA spare parts
399010900271	REUSABLE 90 NUT 20 FITTING (SUCTION FITT	TATA spare parts
399010900272	REUSABLE STRAIGHT NUT 16 FITTING (DISCHA	TATA spare parts
399010900273	REUSABLE 90 NUT 16 FITTING (DISCHARGE FI	TATA spare parts
399010900274	REUSABLE U BEND NUT 16 FITTING (DISCHARG	TATA spare parts

399010900275	SIGHT GLASS 5/8IN	TATA spare parts
399010900276	EXPANSION VALVE FLANGE	TATA spare parts
399010900277	STOP VALVE 5/8IN	TATA spare parts
399010900278	FILTER DRIER	TATA spare parts
399010900279	ASSY. COMPRESSOR24V GROOVE PULLEY BS3	TATA spare parts
399010900280	COMPRESSOR ASSEMBLY 24V - 2A GROOVE PUL	TATA spare parts
399010900281	COMPRESSOR ASSEMBLY 12V - 2B GROOVE PULL	TATA spare parts
399010900282	FUSE BLOCK W/O CU PLATE FOR 125A/100A	TATA spare parts
399010900283	COMPRESSOR W/H	TATA spare parts
399010900284	BATTERY WIRE	TATA spare parts
399010900285	CONDENSER WIRING HARNESS	TATA spare parts
399010900286	MAIN W/H	TATA spare parts
399010900287	EVAPORATOR WIRING HARNESS	TATA spare parts
399010900288	BLOCK BLOWERS	TATA spare parts
399010900289	EVAPORATOR BLOWER 24V	TATA spare parts
399010900290	CONDENSER FAN 24V	TATA spare parts
399010900291	EVAPORATOR BLOWER 12V	TATA spare parts
399010900292	CONDENSER FAN 12V	TATA spare parts
399010900293	COMPRESSOR OIL	TATA spare parts
399010900294	WATER HOSE ID 16MM	TATA spare parts
399010900295	GAS HOSE 20 AEROQUIP (DISCHARGE)	TATA spare parts
399010900296	GAS HOSE 20 AEROQUIP (SUCTION)	TATA spare parts
399010900297	CONDENSER FAN GRILL	TATA spare parts
399010900298	COVER	TATA spare parts
399010900300	RECEIVER BOTTLE 3L	TATA spare parts
399010900301	RETURN AIR GRILL	TATA spare parts
399010900302	COMPRESSOR BRAKET KIT 613	TATA spare parts
399010900303	COMPRESSOR BRAKET KIT 713E1	TATA spare parts
399010900304	COMPRESSOR BRAKET KIT TATA912BS3	TATA spare parts
399010900305	COMPRESSOR BRAKET KIT 713E2	TATA spare parts
399010900306	REUSABLE FLAT 45 16 FITTING	TATA spare parts
399010900307	REUSABLE FLAT 45 20 FITTING	TATA spare parts
399010900309	ALTERNATOR 110A 24V	TATA spare parts
399010900334	COMPRESSOR ALTERNATOR BRACKET COMPLETE	TATA spare parts
399010900335	COMPRESSOR ALTERNATOR MAIN BRACKET	TATA spare parts
399010900336	COMPRESSOR BRACKET	TATA spare parts
399010900337	SUPPORT BRACKET MAIN LONG	TATA spare parts
399010900338	SUPPORT BRACKET MAIN SHORT	TATA spare parts
399010900339	COMPRESSOR SETTING BRACKET	TATA spare parts
399010900340	ALTERNATOR SETTING BRACKET	TATA spare parts
399010900341	COMPRESSOR BELT SETTING DOVEL	TATA spare parts
399010900342	ALTERNATOR BELT SETTING DOVEL	TATA spare parts
399010900343	IDLER PULLEY SUB ASSY	TATA spare parts
399010900344	IDDLER PULLEY SPACER	TATA spare parts
399010900345	IDDLER PULLEY BUSH	TATA spare parts
399010900346	IDDLER PULLEY BOLT	TATA spare parts
399010900347	WATER PUMP PULLEY	TATA spare parts

399010900348	COMPLETE BOLTS NUT ACCESSORIES KIT	TATA spare parts
399010900349	COMPRESSOR BELT	TATA spare parts
399010900350	ALTERNATOR BELT	TATA spare parts
399010900351	WATER PUMP BELT	TATA spare parts
399010900352	ALTERNATOR ASSEMBLY WITH PULLEY 24V140AN	TATA spare parts
399010900353	RADIATOR TOP HOSE	TATA spare parts
399010900354	COOLANT BYPASS HOSE	TATA spare parts
399010900459	BATTERY STAY ROD SET	TATA spare parts
399010900645	PIN GROOVED	TATA spare parts
399010900646	CAP SEALING	TATA spare parts
399010900647	PLUG TAPERED	TATA spare parts
399010900648	NUT CONNECTING-ROD	TATA spare parts
399010900649	CAP OIL FILLER	TATA spare parts
399010900650	BOLT CONNECTING-ROD	TATA spare parts
399010900651	CAP SEALING	TATA spare parts
399010900652	PLUG TAPERED	TATA spare parts
399010900654	PLUG DRAIN	TATA spare parts
399010900655	SEAL VALVE STEM	TATA spare parts
399010900656	SHIM T=1.25	TATA spare parts
399010900657	SHIM T=1.30	TATA spare parts
399010900658	SHIM T=1.35	TATA spare parts
399010900659	SHIM T=1.40	TATA spare parts
399010900660	SHIM T=1.45	TATA spare parts
399010900661	SHIM T=1.50	TATA spare parts
399010900662	SHIM T=1.55	TATA spare parts
399010900663	SHIM T=1.60	TATA spare parts
399010900664	SHIM T=1.65	TATA spare parts
399010900665	SHIM T=1.70	TATA spare parts
399010900666	NOZZLE ASSY	TATA spare parts
399010900667	PIN DOWEL	TATA spare parts
399010900668	KEY SUNK	TATA spare parts
399010900669	KEY WOODRUFF	TATA spare parts
399010900670	PLUG EXPANSION	TATA spare parts
399010900671	CAP SEALING	TATA spare parts
399010900672	CAP SEALING	TATA spare parts
399010900673	CAP SEALING	TATA spare parts
399010900674	CAP SEALING	TATA spare parts
399010900677	PIN KNOCK	TATA spare parts
399010900678	HANGER ENGINE	TATA spare parts
399010900679	SHIM T=0.2	TATA spare parts
399010900680	SHIM T=0.7	TATA spare parts
399010900681	SHIM T=0.8	TATA spare parts
399010900682	SHIM T=0.9	TATA spare parts
399010900683	SHIM T=1.0	TATA spare parts
399010900693	COVER TIE ROD	TATA spare parts
399010900694	PUMP ASSY WATER	TATA spare parts
399010900695	JOINT WATER PUMP	TATA spare parts

399010900697	PLATE WATER PUMP	TATA spare parts
399010900698	PIN DOWEL	TATA spare parts
399010900699	SCREEN ASSY OIL	TATA spare parts
399010900700	GUIDE OIL LEVEL GAGE	TATA spare parts
399010900703	SPRING GOVERNOR	TATA spare parts
399010900706	SCREW HOLLOW	TATA spare parts
399010900707	SLEEVE CONTROL	TATA spare parts
399010900708	TAPPET SUB ASSY INJ	TATA spare parts
399010900709	PIN TAPPET GUIDE	TATA spare parts
399010900710	PLATE	TATA spare parts
399010900711	SHIM T=0.60	TATA spare parts
399010900712	SHIM T=0.20	TATA spare parts
399010900713	SHIM T=0.30	TATA spare parts
399010900714	SHIM T=0.40	TATA spare parts
399010900715	SHIM T=0.50	TATA spare parts
399010900716	SHIM T=0.25	TATA spare parts
399010900717	SHIM T=0.35	TATA spare parts
399010900718	SEAT SPRING	TATA spare parts
399010900719	SPRING PLUNGER	TATA spare parts
399010900721	SEAT SPRING UPPER	TATA spare parts
399010900722	SCREW AIR BLEEDER	TATA spare parts
399010900724	SHIM T=0.45	TATA spare parts
399010900725	RACK ASSY CONTROL	TATA spare parts
399010900728	SHIM T=0.55	TATA spare parts
399010900729	SHIM T=0.65	TATA spare parts
399010900730	PIN PRESSURE	TATA spare parts
399010900731	PIECE DISTANCE	TATA spare parts
399010900732	BUSHING KNOCK	TATA spare parts
399010900733	BUSHING KNOCK	TATA spare parts
399010900734	BUSHING KNOCK	TATA spare parts
399010900735	PLUG TAPERED	TATA spare parts
399010900736	PLUG TAPERED	TATA spare parts
399010900800	THERMOSTAT	TATA spare parts
399010900801	SEAL OIL	TATA spare parts
399010900802	LOCK VALVE SPRING	TATA spare parts
399010900803	GASKET OIL DRAIN	TATA spare parts
399010900804	GASKET FUEL RETURN	TATA spare parts
399010900805	GASKET HOLDER	TATA spare parts
399010900806	RING SNAP	TATA spare parts
399010900807	GASKET	TATA spare parts
399010900808	TANK RESERVOIR	TATA spare parts
399010900809	BRACKET RESEVE	TATA spare parts
399010900810	CAP RESERVOIR	TATA spare parts
399010900811	PLUG DRAIN	TATA spare parts
399010900814	GASKET WATER PUMP	TATA spare parts
399010900815	SWITCH THERMO	TATA spare parts
399010900816	SPACER FAN	TATA spare parts



399010900819	GASKET DELIVERY	TATA spare parts
399010900820	RECTIFIER ASSY	TATA spare parts
399010900821	BRUSH SET	TATA spare parts
399010900822	PULLEY ASSY	TATA spare parts
399010900823	HOLDER ASSY	TATA spare parts
399010900824	SPRING PRESSURE	TATA spare parts
399010900825	BODY SUB ASSY	TATA spare parts
399010900826	PLATE ADJUSTING	TATA spare parts
399010900827	NUT NOZZLE RETAINING	TATA spare parts
399010900852	WASHER	TATA spare parts
399010900853	WASHER	TATA spare parts
399010900854	NUT	TATA spare parts
399010900855	BEARING RADIAL BALL	TATA spare parts
399010900856	BOLT	TATA spare parts
399010900857	BOLT	TATA spare parts
399010900858	BOLT	TATA spare parts
399010900859	BOLT	TATA spare parts
399010900860	BOLT	TATA spare parts
399010900861	BOLT FLANGE	TATA spare parts
399010900862	BOLT FLANGE	TATA spare parts
399010900863	BOLT W/WASHER	TATA spare parts
399010900864	BOLT W/WASHER	TATA spare parts
399010900865	BOLT W/WASHER	TATA spare parts
399010900866	BOLT W/WASHER	TATA spare parts
399010900867	BOLT W/WASHER	TATA spare parts
399010900868	BOLT W/WASHER	TATA spare parts
399010900869	BOLT W/WASHER	TATA spare parts
399010900870	BOLT W/WASHER	TATA spare parts
399010900871	BOLT W/WASHER	TATA spare parts
399010900872	BOLT W/WASHER	TATA spare parts
399010900873	BOLT W/WASHER	TATA spare parts
399010900874	BOLT W/WASHER	TATA spare parts
399010900875	BOLT W/WASHER	TATA spare parts
399010900876	BOLT W/WASHER	TATA spare parts
399010900877	BOLT W/WASHER	TATA spare parts
399010900878	BOLT W/WASHER	TATA spare parts
399010900879	BOLT W/WASHER	TATA spare parts
399010900880	STUD	TATA spare parts
399010900881	NUT	TATA spare parts
399010900882	NUT	TATA spare parts
399010900883	NUT	TATA spare parts
399010900884	NUT JAM	TATA spare parts
399010900886	WASHER PLAIN	TATA spare parts
399010900887	WASHER PLAIN	TATA spare parts
399010900888	WASHER SPRING	TATA spare parts
399010900889	WASHER SPRING	TATA spare parts
399010900890	WASHER SPRING	TATA spare parts

399010900893	HOSE	TATA spare parts
399010900895	BREATHER PIPE	TATA spare parts
399010900896	HOSE ASSY FUEL	TATA spare parts
399010900897	BOLT STARTER	TATA spare parts
399010900900	CLAMP(B)	TATA spare parts
399010900901	CLAMP(A)	TATA spare parts
399010900902	FILTER ASSY FUEL	TATA spare parts
399010900903	WASHER PIPE UNION	TATA spare parts
399010900904	NUT	TATA spare parts
399010900905	BOLT SET	TATA spare parts
399010900906	SCREW SET	TATA spare parts
399010900907	BEARING REAR	TATA spare parts
399010900908	NUT SET	TATA spare parts
399010900909	BOLT WASHER HEAD	TATA spare parts
399010900911	HOSE FUEL	TATA spare parts
399010900912	HOSE FUEL	TATA spare parts
399010900914	HOSE FUEL	TATA spare parts
399010900915	CLIP HOSE	TATA spare parts
399010900916	CLIP HOSE	TATA spare parts
399010900928	GAGE OIL LEVEL	TATA spare parts
399010900929	ENGINE CONTROL PANEL SET WITH WIRING HAR	TATA spare parts
399010900939	V BELT BX 47	TATA spare parts
399010900940	ALTERNATOR PULLEY	TATA spare parts
399010900941	COMPRESSOR CLUTCH & PULLEY ASSLY	TATA spare parts
399010900942	SEAT INLET VALVE	TATA spare parts
399010900943	SEAT EXHAUST VALVE	TATA spare parts
399010900944	GUIDE EXHAUST VALVE	TATA spare parts
399010900945	GUIDE INLET VALVE	TATA spare parts
399010900946	BOLT CYLINDER HEAD	TATA spare parts
399010900947	GASKET CYLINDER HEAD	TATA spare parts
399010900948	VALVE INLET	TATA spare parts
399010900949	VALVE EXHAUST	TATA spare parts
399010900950	SPRING VALVE	TATA spare parts
399010900951	RETAINER VALVE	TATA spare parts
399010900952	CAP VALVE STEM	TATA spare parts
399010900953	BOLT	TATA spare parts
399010900954	ROCKER ASSY	TATA spare parts
399010900955	NUT JAM	TATA spare parts
399010900956	SCREW ROCKER	TATA spare parts
399010900957	SHAFT ASSY ROCKER	TATA spare parts
399010900958	BRACKET ROCKER SHAFT	TATA spare parts
399010900959	BRACKET ROCKER SHAFT	TATA spare parts
399010900960	SPRING ROCKER	TATA spare parts
399010900961	BOLT ROCKER BRACKET	TATA spare parts
399010900962	COVER ASSY ROCKER	TATA spare parts
399010900963	GASKET ROCKER	TATA spare parts
399010900964	CAMSHAFT	TATA spare parts

399010900965	PLATE THRUST	TATA spare parts
399010900966	TAPPET	TATA spare parts
399010900967	ROD PUSH	TATA spare parts
399010900968	CAP SEALING	TATA spare parts
399010900969	CAP SEALING	TATA spare parts
399010900970	BOLT BEARING CAP	TATA spare parts
399010900971	BUSH CAMSHAFT	TATA spare parts
399010900972	PLUG TAPERED	TATA spare parts
399010900973	SHAFT ASSY IDLER	TATA spare parts
399010900974	PIN DOWEL	TATA spare parts
399010900975	SEAL SIDE	TATA spare parts
399010900976	SHAFT OIL FILTER	TATA spare parts
399010900977	CASE OIL SEAL	TATA spare parts
399010900978	GASKET OIL SEAL CASE	TATA spare parts
399010900979	SEAL OIL	TATA spare parts
399010900980	BEARING SET MAINSTD	TATA spare parts
399010900981	BEARING SET MAINU.S 0.25	TATA spare parts
399010900982	BEARING SET MAINU.S 0.50	TATA spare parts
399010900983	BEARING SET MAINU.S 0.75	TATA spare parts
399010900984	PLATE FRONT	TATA spare parts
399010900985	GASKET FRONT PLATE	TATA spare parts
399010900986	CASE GEAR	TATA spare parts
399010900987	GASKET GEAR CASE	TATA spare parts
399010900988	HOUSING FLYWHEEL	TATA spare parts
399010900989	PLUG	TATA spare parts
399010900990	PAN ASSY OIL	TATA spare parts
399010900991	PISTON STD	TATA spare parts
399010900992	PISTON O.S 0.25	TATA spare parts
399010900993	PISTON O.S 0.50	TATA spare parts
399010900994	RING SET PISTON STD	TATA spare parts
399010900995	RING SET PISTON O.S 0.25	TATA spare parts
399010900996	RING SET PISTON O.S 0.50	TATA spare parts
399010900997	PIN PISTON	TATA spare parts
399010900998	ROD ASSY CONNECTING	TATA spare parts
399010900999	BEARING SET CON-ROD STD	TATA spare parts
399010901000	BEARING SET CON-ROD U.S 0.25	TATA spare parts
399010901092	BEARING SET CON-ROD U.S 0.50	TATA spare parts
399010901093	BEARING SET CON-ROD U.S 0.75	TATA spare parts
399010901094	CRANKSHAFT	TATA spare parts
399010901095	FLYWHEEL SUB ASSY	TATA spare parts
399010901096	BOLT DRIVE PLATE	TATA spare parts
399010901097	GEAR CRANKSHAFT	TATA spare parts
399010901098	GEAR CAMSHAFT	TATA spare parts
399010901099	GEAR INJECTION PUMP	TATA spare parts
399010901100	GEAR ASSY IDLER	TATA spare parts
399010901101	COVER ASSY INLET	TATA spare parts
399010901103	PIPE INLET	TATA spare parts

399010901104	GASKET INLET PIPE	TATA spare parts
399010901105	MANIFOLD EXH	TATA spare parts
399010901106	GASKET EXH	TATA spare parts
399010901107	BOLT	TATA spare parts
399010901108	PUMP ASSY OIL	TATA spare parts
399010901109	PACKING BODY	TATA spare parts
399010901110	VALVE ASSY RELIEF	TATA spare parts
399010901111	GASKET	TATA spare parts
399010901112	FILTER ASSY OIL	TATA spare parts
399010901113	GASKET WATER PUMP	TATA spare parts
399010901114	PULLEY WATER PUMP	TATA spare parts
399010901115	COVER THERMOSTAT	TATA spare parts
399010901116	CASE ASSY THERMOSTAT	TATA spare parts
399010901117	GASKET THERMOSTAT	TATA spare parts
399010901118	GASKET THERMO CASE	TATA spare parts
399010901119	HOSE ASSY	TATA spare parts
399010901120	HOSE BY-PASS	TATA spare parts
399010901121	CLAMP HOSE	TATA spare parts
399010901122	FAN COOLING	TATA spare parts
399010901123	PIPE INJ NO.1	TATA spare parts
399010901124	PIPE INJ NO.2	TATA spare parts
399010901125	PIPE INJ NO.3	TATA spare parts
399010901126	PIPE INJ NO.4	TATA spare parts
399010901127	PIPE FUEL	TATA spare parts
399010901128	HOSE ASSY AIR VENT	TATA spare parts
399010901129	HOSE RUBBER	TATA spare parts
399010901130	JOINT THREE WAY	TATA spare parts
399010901131	NOZZLE & HOLDER ASSY	TATA spare parts
399010901132	SUPPORT FUEL FILTER	TATA spare parts
399010901133	CLAMP FILTER	TATA spare parts
399010901134	NUT TORQUE SET	TATA spare parts
399010901135	SCREW RACK SET	TATA spare parts
399010901136	BOLT ASSY HIGH SPEED	TATA spare parts
399010901137	BOLT HIGH SPEED SET	TATA spare parts
399010901138	NUT HIGH SPEED SET	TATA spare parts
399010901139	C-RING	TATA spare parts
399010901140	C-RING	TATA spare parts
399010901141	TIE-ROD	TATA spare parts
399010901142	SPRING TIE ROD	TATA spare parts
399010901143	COVER GOVERNOR SHAFT	TATA spare parts
399010901144	SHAFT GOVERNOR	TATA spare parts
399010901145	LEVER GOVERNOR	TATA spare parts
399010901146	SPRING START	TATA spare parts
399010901147	BOLT LOW IDLE SET	TATA spare parts
399010901148	LEVER SPEED CONTROL	TATA spare parts
399010901149	SHIM GOVERNOR SHAFT	TATA spare parts
399010901150	LEVER GOVERNOR	TATA spare parts

399010901151	CASE GOVERNOR	TATA spare parts
399010901152	PIN SPRING	TATA spare parts
399010901153	O-RING	TATA spare parts
399010901154	GASKET GOVERNOR CASE	TATA spare parts
399010901155	SHAFT SLIDING SLEEVE	TATA spare parts
399010901156	SLEEVE SLIDING	TATA spare parts
399010901157	WEIGHT ASSY GOVERNOR	TATA spare parts
399010901158	BOLT GOVERNOR CASE	TATA spare parts
399010901159	GASKET TIE ROD	TATA spare parts
399010901161	WASHER SEAL	TATA spare parts
399010901162	PUMP ASSY FUEL INJ	TATA spare parts
399010901163	HOUSING SUB ASSY	TATA spare parts
399010901164	HOLDER DELIVERY	TATA spare parts
399010901165	SPRING DELIVERY	TATA spare parts
399010901166	VALVE SUB ASSY	TATA spare parts
399010901167	ELEMENT SUB ASSY	TATA spare parts
399010901168	SHAFT FUEL INJ PUMP	TATA spare parts
399010901169	STARTER	TATA spare parts
399010901171	SCREW SET	TATA spare parts
399010901172	BRACKET ASSY FRONT	TATA spare parts
399010901173	LEVER ASSY	TATA spare parts
399010901174	SWITCH ASSY	TATA spare parts
399010901175	BALL	TATA spare parts
399010901176	PACKING SET	TATA spare parts
399010901177	ARMATURE ASSY	TATA spare parts
399010901178	BEARING	TATA spare parts
399010901179	BOLT SET	TATA spare parts
399010901180	PINION SET	TATA spare parts
399010901181	STOPPER SET	TATA spare parts
399010901182	SHAFT ASSY CLUTCH	TATA spare parts
399010901183	CLUTCH OVER RUNNING	TATA spare parts
399010901184	GEAR ASSY INTERNAL	TATA spare parts
399010901185	WASHER SET	TATA spare parts
399010901186	SHAFT ASSY GEAR	TATA spare parts
399010901187	GEAR ASSY	TATA spare parts
399010901188	YOKE ASSY	TATA spare parts
399010901189	BRUSH	TATA spare parts
399010901190	HOLDER ASSY BRUSH	TATA spare parts
399010901191	SPRING BRUSH	TATA spare parts
399010901192	BRACKET ASSY REAR	TATA spare parts
399010901193	PLUG GLOW	TATA spare parts
399010901194	PLATE CONNECTION	TATA spare parts
399010901195	ALTERNATOR ASSY	TATA spare parts
399010901196	PLATE ADJUSTING	TATA spare parts
399010901197	BOLT ALTERNATOR	TATA spare parts
399010901199	BRACKET ASSY FRONT	TATA spare parts
399010901200	BEARING FRONT	TATA spare parts

399010901201	ROTOR ASSY	TATA spare parts
399010901202	STATOR ASSY	TATA spare parts
399010901203	BRACKET ASSY REAR	TATA spare parts
399010901204	REGULATOR SET	TATA spare parts
399010901205	SOLENOID & NUT SET	TATA spare parts
399010901206	NUT	TATA spare parts
399010901207	WASHER SEALING	TATA spare parts
399010901208	SWITCH OIL	TATA spare parts
399010901209	CONNECTOR	TATA spare parts
399010901210	CONNECTOR	TATA spare parts
399010901211	CLEANER ASSY AIR	TATA spare parts
399010901212	ELEMENT	TATA spare parts
399010901213	TANK ASSY RESERVOIR	TATA spare parts
399010901214	CLAMP HOSE	TATA spare parts
399010901232	PRE FILTER	TATA spare parts
399010901233	ENGINE BASE FRAME ASSLY	TATA spare parts
399010901234	YELLOW REFL TAPE 50 MM WIDE AS PER AIS09	TATA spare parts
399010901235	VINYL STICKER BROWN COLOUR FOR SCHOOL 6	TATA spare parts
399010901236	AL PROFILE FOR STRETCH & SKIRT PNL PRFL2	TATA spare parts
399010901237	AL PROFILE 3MTR	TATA spare parts
399010901238	SPONGY RUBBER PROFILE FOR WINDSHIELD 4.2	TATA spare parts
399010901239	VINYL FLOOR(SCUBA BLUE VOL-004) 2M WIDTH	TATA spare parts
399010901242	1_SEATER_VINYL CVR_BKRST_2TONE	TATA spare parts
399010901243	SCHOOL TWIN CUSHION TRIM & POLYTHENE	TATA spare parts
399010901245	VINYL FLOOR RED CLR 53295084 24SQ.MTR	TATA spare parts
399010901246	V BELT	TATA spare parts
399010901247	Wheel Arch Flexible rubber profile 3Mtr	TATA spare parts
399010901248	RAIN GUTTER ALLUMINIUM PROFILE 3MTR	TATA spare parts
399010901249	MCV WHEEL ARCH FLEXIBLE RUBBER PROF 3MTR	TATA spare parts
399010901250	RUBBER PROFILE 5 5MTR	TATA spare parts
399010901251	SOLID RUBBER PROFILE 5MTR	TATA spare parts
399010901252	RAIN GUTTER FINISHING RU PRFL BLK 6MTR	TATA spare parts
399010901253	PRE CRIMPED SUCTION HOSE	TATA spare parts
399010901254	PRE CRIMPED DISCHARGE HOSE	TATA spare parts
399010901255	COMPRESSOR IDLER PULLEY OD 98MM 2BGROOV	TATA spare parts
399010901256	PRE CRIMPED SUCTION HOSE 613E1	TATA spare parts
399010901257	PRE CRIMPED DISCHARGE HOSE 613E1	TATA spare parts
399010901258	PRE CRIMPED SUCTION HOSE 613E2	TATA spare parts
399010901259	PRE CRIMPED DISCHARGE HOSE 613E2	TATA spare parts
399010901260	PRE CRIMPED SUCTION HOSE 713E1	TATA spare parts
399010901261	PRE CRIMPED DISCHARGE HOSE 713E1	TATA spare parts
399010901262	PRE CRIMPED SUCTION HOSE 713E2	TATA spare parts
399010901263	PRE CRIMPED DISCHARGE HOSE 713E2	TATA spare parts
399010901264	COMPRESSOR PULLEY-2B GROOVE	TATA spare parts
399010901265	COMPRESSOR PULLEY-2A GROOVE	TATA spare parts
399010901267	COMPRESSOR CLUTCH ASSY 24V (COIL +CLUTCH	TATA spare parts
399010901270	AIR FILTER FOAM GIV 810MMX405MMX10MM	TATA spare parts

399010901271	HOSE SUCTION 16MM	TATA spare parts
399010901272	HOSE SUCTION 19MM	TATA spare parts
399010901273	PRESSURE SWITCH HIGH	TATA spare parts
399010901274	PRESSURE SWITCH LOW	TATA spare parts
399010901275	O RING 5/8 NO12	TATA spare parts
399010901276	O-RING	TATA spare parts
399010901277	RELAY 12V 50 AMPS OEN(531-1A-12TO	TATA spare parts
399010901278	FILTER DRIER	TATA spare parts
399010901279	MOTOR SUTRAK 12V	TATA spare parts
399010901280	FAN BLADE T LEAF	TATA spare parts
399010901281	DIG.CAB COMM.D.AC310 CL W/SC 12V	TATA spare parts
399010901282	ALTERNATOR FUSE 125 AMPS	TATA spare parts
399010901283	FUSE HOLDER FOR BUS AC	TATA spare parts
399010901284	SPEED CONTROLLER- 12V	TATA spare parts
399010901285	DUAL SHAFT BLOWER 12V	TATA spare parts
399010901286	SUCTNO12 FTG ORING 90DG W/PT	TATA spare parts
399010901287	THERMO EXPANSION VALVE AC310	TATA spare parts
399010901288	FTG SUCTION - 1 1/16INC X 14 UNF	TATA spare parts
399010901289	BASE PLATE LOCK WITH BOLT ASSEMBLY	TATA spare parts
399010901290	CLUTCH TM31 12VDC 2SPB	TATA spare parts
399010901291	COMPRESSOR TM31 12V 2B GROOVE PULLEY	TATA spare parts
399010901292	COVER CONDENSER (AC310)	TATA spare parts
399010901293	COVER EVAPORATOR (AC310)	TATA spare parts
399010901294	5/8INC ID O RING TYPE (DISCHARGE) ST.NIP	TATA spare parts
399010901295	3/4INC ID O RING TYPE (SUCTION) ST. NIPP	TATA spare parts
399010901296	FLTRFOAM PP15/20	TATA spare parts
399010901297	FLTRFOAM PPI30/5 020*15M	TATA spare parts
399010901298	DD BRACKET	TATA spare parts
399010901299	IDLER BRACKET WITH PULLEY 2B DIA 98 X 36	TATA spare parts
399010901300	ALT PULLEY 2A DIA 80ç X 37 THK	TATA spare parts
399010901301	ADD ON PULLEY 2B DIA 230 X 55 THK	TATA spare parts
399010901302	FAN SPACER OD 80 X 65	TATA spare parts
399010901303	RADIATOR SPACER DIA 30 X ID 9 X 30 L	TATA spare parts
399010901304	BELT XPB 1700(ADD ON PULLEY + COMPRESSOR	TATA spare parts
399010901305	BELT XPA 48 (CRANK + ALTERNATOR + WATER	TATA spare parts
399010901306	COMP. MTG. BRKT SIDE SUPPORT	TATA spare parts
399010901307	TATA 712 BS- IV BRACKET	TATA spare parts
399010901308	TATA 712 BS- IV ADD-ON PULLEY	TATA spare parts
399010901309	TATA 712 BS-IV FAN SPACER	TATA spare parts
399010901310	TATA 712 BS-IV IDLER BRACKET ASSY	TATA spare parts
399010901311	TATA 712 BS-IV BELT XPB 1800 (ADD ON + C	TATA spare parts
399010901312	DRIVE SET ASSY TATA 712 BS III	TATA spare parts
399010901313	DRIVE SETç ASSY TATA 712BS IV	TATA spare parts
399010901314	DRIVER DOOR FINISHING AL PROF 3MTR	TATA spare parts
399010901315	ALUMINUM PROFILE 3MTR	TATA spare parts
399010901316	SPONGY RUBBER PROFILE 5MTR	TATA spare parts
399010901327	40X40X1.95ç GI TUBE 3 MTRS	TATA spare parts

399010901328	30X40X1.95ç GI TUBE 3 MTRS	TATA spare parts
399010901329	20X40X1.95ç GI TUBE 3 MTRS	TATA spare parts
399010901330	50X40X1.95ç GI TUBE 3 MTRS	TATA spare parts
399010901331	30X30X1.55ç GI TUBE 3 MTRS	TATA spare parts
399010901342	SOLID RUBBER PROFILE 3MTR	TATA spare parts
399010901343	ABS+PVC R PROFILE 6MTR	TATA spare parts
399010901346	PULLEY ALTERNATOR 70MM 2A GROOVE	TATA spare parts
399010901347	CONTITECH BELT XPA 1250	TATA spare parts
399010901348	COMPRESSOR BELT	TATA spare parts
399010901349	ALTERNATOR BELT	TATA spare parts
399010901350	WATER PUMP BELT	TATA spare parts
399010901351	ALTERNATOR ASSEMBLY WITH PULLEY 24V140AM	TATA spare parts
399010901352	RADIATOR TOP HOSE	TATA spare parts
399010901353	COOLANT BYPASS HOSE	TATA spare parts
399010901363	ROOF INTERNAL PVC FINISHING PROOF SMALL	TATA spare parts
399010901364	ALUMINIUM PROFILE 202 3MTR.	TATA spare parts
399010901365	AL AND RUBBER WIPER SEAL FOR GLASS	TATA spare parts
399010901366	DOOR SEALING RUBBER 5MTR	TATA spare parts
399010901367	PU PNEUMATIC TUBE BLUE 10MTR	TATA spare parts
399010901368	PU PNEUMATIC TUBE YELLOW 10MTR	TATA spare parts
399010901369	CORRUGATED PIPE 3/4 IN(19MM) 12MTR	TATA spare parts
399010901373	V BELT (ALTERNATOR BELT)	TATA spare parts
399010901374	V BELT (COMP. BELT)	TATA spare parts
399010901375	V BELT (FAN BELT)	TATA spare parts
399010901376	V BELT (ALTERNATOR BELT)	TATA spare parts
399010901377	V BELT (FAN BELT)	TATA spare parts
399010901378	V BELT (COMP. BELT)	TATA spare parts
399010901379	V BELT (COMP. BELT)	TATA spare parts
399010901380	V BELT (COMP. BELT)	TATA spare parts
399010901381	ALT POLY BELT	TATA spare parts
399010901382	V BELT (COMP. BELT)	TATA spare parts
399010901383	V BELT (ALTERNATOR BELT)	TATA spare parts
399010901392	ROOF EXTERNAL JOINT AL PRFL 3MTR	TATA spare parts
399010901393	AL PR FL INT PANELING JOINT 3MTR	TATA spare parts
399010901394	FIRE RTDNT GREY CLR CARPET 4MM THK 5SQM	TATA spare parts
399010901395	JK DOOR RUBBER PRFL FOR GLASS 8MTR	TATA spare parts
399010901396	ALTERNATOR CONNECTOR - 24V 120A	TATA spare parts
399010901397	RETURN AIR GRILL FILTER	TATA spare parts
399010901398	REUSABLE FITTING GASKET	TATA spare parts
399010901399	PORT ASSEMBLY SUCTION WITH ADAPTERS	TATA spare parts
399010901400	PORT ASSEMBLY DISCHARGE WITH ADAPTERS	TATA spare parts
399010901401	ROUND THIMBLE 25/10MM	TATA spare parts
399010901402	ROUND BAR (SPACER)	TATA spare parts
399010901403	FAN SPACER	TATA spare parts
399010901404	WATER VALVE PULLEY-FAN PULLEY	TATA spare parts
399010901405	CRANK PULLEY	TATA spare parts
399010901406	CRANK PULLEY	TATA spare parts



399010901407	CRANK ADD ON PULLEY	TATA spare parts
399010901408	ADDITIONAL PULLEY- B GROOVE	TATA spare parts
399010901409	AC - CRANK PULLEY	TATA spare parts
399010901410	PULLEY-B SINGLE GROOVE-ALTERNATOR	TATA spare parts
399010901411	COOLANT HOSE-1	TATA spare parts
399010901412	COOLANT HOSE-2	TATA spare parts
399010901413	COOLANT HOSE	TATA spare parts
399010901414	TURBO HOSE	TATA spare parts
399010901415	COOLANT HOSE-3	TATA spare parts
399010901416	O RING 5/8	TATA spare parts
399010901417	O RING 3/4	TATA spare parts
399010901418	PORT ASSEMBLY O RING - DIA 17.17 X TH 1.	TATA spare parts
399010901419	ALTERNATOR ADJUSTER PLATE	TATA spare parts
399010901420	SUPPORT PLATE	TATA spare parts
399010901421	SUPPORT PLATE	TATA spare parts
399010901422	PLATE SUPPORT	TATA spare parts
399010901423	IDLER MTG. BKT. ASSY WITH PULLEY	TATA spare parts
399010901424	IDLER PLATE ASSEMBLY WITH IDLER PULLEY	TATA spare parts
399010901425	IDLER MTG. BKT. ASSY WITH PULLEY	TATA spare parts
399010901426	IDLER MTG BKT ASSY WITH PULLEY	TATA spare parts
399010901427	TENSIONER ROD ASSEMBLY-BEND TYPE	TATA spare parts
399010901428	BKT. ASSY-01	TATA spare parts
399010901429	BKT. ASSY-02	TATA spare parts
399010901430	COMP. MTG. BKT. ASSY	TATA spare parts
399010901431	ALT. MTG. BKT	TATA spare parts
399010901432	TENSIONER ROD	TATA spare parts
399010901433	IDLER MTG. BKT. ASSY	TATA spare parts
399010901434	COMPRESSOR MTG. BKT. ASSLY	TATA spare parts
399010901435	COMP. MTG. BKT. ASSY	TATA spare parts
399010901436	FRONT HOUSING	TATA spare parts
399010901437	ROTOR	TATA spare parts
399010901438	STATOR	TATA spare parts
399010901439	REAR HOUSING	TATA spare parts
399010901440	RECTIFIER ASSY.	TATA spare parts
399010901441	REGULATOR	TATA spare parts
399010901442	REAR COVER	TATA spare parts
399010901443	BEARING	TATA spare parts
399010901444	PULLEY RETAINER KIT	TATA spare parts
399010901445	HARDWARE KIT	TATA spare parts
399010901446	SLIP RING	TATA spare parts
399010901447	IDLER MTG. BKT. ASSY 613E2	TATA spare parts
399010901448	IDLER MTG BKT ASSY 713E2	TATA spare parts
399010901457	ASSY BODY COMPLETE	TATA spare parts
399010901460	VINYL ECO RIDE 1MM LCV SKL 12 SQ.MTR	TATA spare parts
399010901461	FIRE RET MARINE PLY WOOD 12MM 2.97SQ.MTR	TATA spare parts
399010901480	PU PNEUMATIC TUBE RED 6MTR	TATA spare parts
399010901481	WINDOWS FINISH PRFL L SHAPED 6MTR	TATA spare parts

399010901485	COMPRESSOR ALTERNATOR BRACKET COMPLETE	TATA spare parts
399010901486	COMPRESSOR ALTERNATOR MAIN BRACKET	TATA spare parts
399010901487	SUPPORT BRACKET ç MAIN LONG	TATA spare parts
399010901489	ALTERNATOR SUPPORT BRACKET	TATA spare parts
399010901490	IDLER PULLEY SUB ASSY	TATA spare parts
399010901491	IDLER PULLEY BIG SPACER	TATA spare parts
399010901492	IDDLER PULLEY SMALL SPACER	TATA spare parts
399010901493	IDLER PULLEY BOLT	TATA spare parts
399010901494	CRANK PULLEY	TATA spare parts
399010901495	COMPLETE BOLTS NUT WASHERS ACCESSORIES K	TATA spare parts
399010901496	COMPRESSOR BELT	TATA spare parts
399010901497	ALTERNATOR BELT	TATA spare parts
399010901498	ALTERNATOR ASSEMBLYç 24V -140AMP	TATA spare parts
399010901499	IDLER PULLEY BRACKET	TATA spare parts
399010901500	FAN SPACER	TATA spare parts
399010901501	IDLER PULLEY BRACKET	TATA spare parts
399010901507	ROOF EXTERNAL PANEL	TATA spare parts
399010901514	GASKET SET	TATA spare parts
399010901515	HEAD GASKET	TATA spare parts
399010901516	PISTON RING	TATA spare parts
399010901517	PISTON RING	TATA spare parts
399010901518	SHAFT SEAL	TATA spare parts
399010901519	PRESSURE RELIEF VALVE	TATA spare parts
399010901520	VALVE PLATE	TATA spare parts
399010901521	CONNECTING ROD PISTON COMPLETE	TATA spare parts
399010901522	SHUT OF VALVES - SUCTION	TATA spare parts
399010901523	SHUT OF VALVE - DISCHARGE	TATA spare parts
399010901524	GASKET FOR SHUT OFF VALVES	TATA spare parts
399010901525	COMPRESSOR WITH 2A PULLEY	TATA spare parts
399010901527	LOW PRESSURE SWITCH	TATA spare parts
399010901528	NYLON FLOCKED CHANNEL 1.2MTRS	TATA spare parts
399010901529	DASHBOARD FINISHING PROF-PVC 3MTR	TATA spare parts
399010901536	COMPRESSOR 12V WITH 2A GROOVE	TATA spare parts
399010901551	PU PNEUMATIC TUBE BLUE 100MTR	TATA spare parts
399010901552	CONTROL PANEL ASSY	TATA spare parts
399010901553	L AL PROF FOR VINYL FINISHING 3MTR	TATA spare parts
399010901562	EPDM FLOCK CHANL NON SER WIND 100MTR	TATA spare parts
399010901569	MAGNETIC CLUTCH 73.2 G BS6	TATA spare parts
399010901573	STEP FINISHING PVC PROFILE - 3MTRS	TATA spare parts
399010901580	HALF ROUND PROFILE-PVC 7 MTRS	TATA spare parts
399010901583	DRIVER DOOR COMPLETE	TATA spare parts
399010901593	GI COIL (0.65X706) ç 32.5 KG	TATA spare parts
399010901639	PRE CRIMPED SUCTION HOSE ASSY	TATA spare parts
399010901640	PRE CRIMPED DISCHARGE HOSE ASSY	TATA spare parts
399010901653	EPE FOAM TAPE - 3.2MM 15 MTRS	TATA spare parts
399010901662	RAIN GUTTER ALUMINIUM PROFILE NEW 3MTR	TATA spare parts
399010901668	MAIN WIRING HARNESS CC225	TATA spare parts

399010901669	RADIOTOR ASSY S4L2	TATA spare parts
399010901671	SIDE EXT JOINT FINSHNG PROF-2 6MTR	TATA spare parts
399010901672	SOLID RUBBER PROF WITH LEAF FOR DOOR 5MT	TATA spare parts
399010901676	SIKA FLEX 252 - 600ML	TATA spare parts
399010901677	FOAM NBR 35MMX25MMX1MTR	TATA spare parts
399010901678	FUSE 100 AMP(SPECIAL FUSE)	TATA spare parts
399010901679	FUSE BOX W/O CU PLATE(125A/100A)	TATA spare parts
399010901680	FEMALE THIMBLE 1.5MM	TATA spare parts
399010901681	MALE THIMBLE 1.5MM	TATA spare parts
399010901682	COUPLER 2-POLE MALE FEMAL	TATA spare parts
399010901683	COUPLER 6-POLE MALE-FEMALE	TATA spare parts
399010901684	BATTERY WIRE (25SQ MM RED COLOUR)	TATA spare parts
399010901685	WASHER PLAIN M10	TATA spare parts
399010901686	RETURN AIR GRILL CC-225_ (GREY)	TATA spare parts
399010901687	EVAPORATOR COIL LH CC225-REV03	TATA spare parts
399010901688	EVAPORATOR COIL RH CC225-REV03	TATA spare parts
399010901689	EVAPORATOR COVER RTM CC225	TATA spare parts
399010901690	RD BOTTLE (NEW) CC225 WIDE	TATA spare parts
399010901691	FAN PLATE SPAL TYPE CC-225 (3HOLE)	TATA spare parts
399010901692	HOSES SET 6.6MTR	TATA spare parts
399010901693	HOSES SET 7.7MTR	TATA spare parts
399010901694	INT UNIONS FINISHING PROF EVO-1 6MTR	TATA spare parts
399010901705	ALT. POLY BELT	TATA spare parts
399010901710	IDLER MOUNTING BRACKET ASSY WITH PULLEY	TATA spare parts
399010901711	COMP. MTG BKT. ASSY	TATA spare parts
399010901865	NEW VERTICAL WIPER_TPE 0.66 MTR	TATA spare parts
399010901872	VINYL FLR_ BUTN TYPE -1.2THK 24 SQM	TATA spare parts
399010901873	VINYL 1.0 MM YELLOW CANOPUS PLUS 2SQM	TATA spare parts
399010901874	SIDE INTERNAL PANEL 2020X560	TATA spare parts
399010901876	WATER HOSE DIA 16MM LENGTH IN 30 MTR	TATA spare parts
399010901877	WATER HOSE DIA 16MM LENGTH IN 24 MTR	TATA spare parts
399010901878	WATER HOSE DIA 16MM LENGTH IN 25 MTR	TATA spare parts
399010901879	WATER HOSE ID 16MM LENGTH IN 35 MTR	TATA spare parts
399010901881	NEW LCV VERTICAL WIPER_TPE 660MM	TATA spare parts
399010901898	DD LOCK WITH KEY	TATA spare parts
399010901899	PASS DOOR LOCK WITH KEY	TATA spare parts
399010901900	FUSE BOX LOCK WITH KEY_SPD	TATA spare parts
399010901902	DRIVER DOOR_WITH_KEY	TATA spare parts
399010901903	DRIVER DOOR LOCK KIT ASSY_LHD&KEY	TATA spare parts
399010901904	EXTERNAL LATCH FOR DOOR&KEY	TATA spare parts
399010901906	8519 EDGE SEALING TAPE-3M BS6	TATA spare parts
399010901907	SPD TOOL BOX WITH KEY BS6	TATA spare parts
399010901909	DRIVER DOOR KIT PART FOR VC 39901709018R	TATA spare parts
399010901910	DOUBLE INSU-NBR13249 STOP REQ CABLE 2M	TATA spare parts
399010902031	SCHOOL BACK TRIM & POLYTHENE(NO CUSHION)	TATA spare parts
399010911001	ALUMINUM PROFILE INTERNAL PANELING 6MTR	TATA spare parts
399010961001	LCV_34 WB EX AIS 140 RETRO KIT 2	TATA spare parts

399010961002	LCV_42 WB EX AIS 140 RETRO KIT 2	TATA spare parts
399010961003	LCV_49 WB EX AIS 140 RETRO KIT 2	TATA spare parts
399010961004	LCV_31 WB AIS 140 RETRO KIT 2	TATA spare parts
399010961005	LCV_34 WB AIS 140 RETRO KIT 2	TATA spare parts
399010961006	LCV_42 WB AIS 140 RETRO KIT 2	TATA spare parts
399010961007	LCV_49 WB AIS 140 RETRO KIT 2	TATA spare parts
399012002003	FRONT MUD FLAP ASSEMBLY (LLDPE)	TATA spare parts
399012002004	REAR MUD FLAP ASSEMBLY (LLDPE)	TATA spare parts
399012002011	REAR MUD FLAP ASSEMBLY (LLDPE_NEW)	TATA spare parts
399012074001	WHEEL FLAP SUPPORT REINFORCEMENT	TATA spare parts
399012083001	MUDGUARD ATTACHING PROFILE	TATA spare parts
399012083002	INTERNAL REAR-VIEW MIRROR	TATA spare parts
399012283001	REAR MUD FLAP 250X350X3THK	TATA spare parts
399012283003	FLAP FRONT	TATA spare parts
399012283004	FLAP REAR	TATA spare parts
399013004005	BATTERY TRAY BASE ASSEMBLY	TATA spare parts
399013005001	BATTERY BOX LATCH KIT	TATA spare parts
399013073001	BATTERY CUTOFF SWITCH	TATA spare parts
399013084001	BATTERY SHUTTER BACKSTOP ATTACH. PLATE	TATA spare parts
399013084006	UPHOLDING ROD COUPLING PLATE	TATA spare parts
399013085001	STUD BOLT FIXING	TATA spare parts
399013304001	VENTILLATION PLASTIC GRILL	TATA spare parts
399014083003	BUS IDENTIFICATION PLATE	TATA spare parts
399015001002	DRIVER DOOR ASSEMBLY	TATA spare parts
399015001003	DRIVER DOOR STRUCTURE	TATA spare parts
399015002003	DRIVER DOOR ASSEMBLY RHD	TATA spare parts
399015002004	DRIVER DOOR FINISHING ASSEMBLY RHD	TATA spare parts
399015002005	DRIVER DOOR FINSHING ASSY LCV LHD	TATA spare parts
399015002006	DRIVER DOOR ASSY DETAIL _LCV_LHD	TATA spare parts
399015002010	DRIVER DOOR ASSY_LCV_RHD_SA	TATA spare parts
399015002013	DRIVER DOOR FINISHING ASSEMBLY *RHD	TATA spare parts
399015002043	LCV EX DRIVER DOOR ASSEMBLY RHD	TATA spare parts
399015003002	DRIVER DOOR INNER HANDLE	TATA spare parts
399015003005	HANDHOLD ASSEMBLY	TATA spare parts
399015003006	DRIVER DOOR STRUCTURE	TATA spare parts
399015003007	DRIVER DOOR UPPER HINGE	TATA spare parts
399015003008	DRIVER DOOR LOWER HINGE	TATA spare parts
399015003009	DRIVER DOOR PANNELING ASSEMBLY ĳ RHD	TATA spare parts
399015003015	DRIVER DOOR STR & LOCK KIT ASSY RHD	TATA spare parts
399015003016	DRIVER DOOR STR & LOCK KIT ASSY LHD	TATA spare parts
399015003021	DRIVER DOOR & LOCK KIT ASSY	TATA spare parts
399015003058	DRIVER DOOR STR+PANEL & LOCK ASSEMBLY	TATA spare parts
399015003068	LATCH ASSY	TATA spare parts
399015003070	DRIVER DOOR ASSLY WITH LOCK & HINGE	TATA spare parts
399015003080	DRIVER DOOR ASSY DETAILĳ LCV LHD	TATA spare parts
399015003087	DRIVER DOOR WITH LCV LOCK ASSEMBLY	TATA spare parts
399015004014	DRIVER DOOR LOCK KIT ASSY_LHD	TATA spare parts

399015004015	DRIVER DOOR LOCK KIT ASSY_RHD	TATA spare parts
399015004044	DRIVER DOOR PANEL AND STR FOR EXT. HINGE	TATA spare parts
399015004050	DRIVER DOOR-LH OUTER PANEL ASSY	TATA spare parts
399015004051	DRIVER DOOR-LH LATCH ASSY	TATA spare parts
399015004052	ASSY WITH INNER HANDLE LH	TATA spare parts
399015004057	TOPLINKASSY	TATA spare parts
399015004058	BOTTOMLINK&ASSY	TATA spare parts
399015004061	LCV EX DRIVER DOOR STR & PANEL ASSLY	TATA spare parts
399015063001	DRIVER HANDHOLD ASSEMBLY	TATA spare parts
399015082001	LIMITER BRACKET	TATA spare parts
399015083021	DRIVER DOOR SEALING PLATE_LEFT SIDE	TATA spare parts
399015083022	DRIVER DOOR SEALING PLATE_UPPR&BOTM SIDE	TATA spare parts
399015083023	DRIVER DOOR SEALING PLATE_RIGHT SIDE	TATA spare parts
399015083024	DRIVER DOOR INTERNAL PANEL	TATA spare parts
399015083026	DOOR LATCH ATTACHMENT SUPPORT PLATE	TATA spare parts
399015083029	DRIVER DOOR INT PANEL LCV_LHD	TATA spare parts
399015083038	DRIVER DOOR INTERNAL REVITMENT	TATA spare parts
399015083039	DRIVER DOOR INTERNAL PANEL	TATA spare parts
399015083040	DRIVER DOOR SEELING SUPORT BOTTOM	TATA spare parts
399015083061	DRIVER DOOR INTERNAL PANEL NEW	TATA spare parts
399015083074	DD INTERNAL PANEL FOR EXT. RUBBER	TATA spare parts
399015083094	INTERNAL PANEL	TATA spare parts
399015083095	INTERNAL PANEL_PVC LAMINATED	TATA spare parts
399015083100	LCV EX INTERNAL PANEL WITH LCV LOCK	TATA spare parts
399015084009	DRIVER DOOR UPPER EXTERNAL PANNEL	TATA spare parts
399015303001	DRIVER DOOR HANDHOLD	TATA spare parts
399015303002	HANDHOLD'S	TATA spare parts
399015303003	DOOR BOLT COVER	TATA spare parts
399015303005	DRIVER DOOR LOCK COVER RH	TATA spare parts
399015303009	NYLON BELT L220	TATA spare parts
399015303010	DRIVER DOOR CANOPY - PP	TATA spare parts
399015323001	DRIVER DOOR COVER	TATA spare parts
399015323002	MAINATNCE COVER	TATA spare parts
399015323003	DOOR BOLT COVERING	TATA spare parts
399015323004	DRIVER DOOR COVER	TATA spare parts
399015323005	MAINATNCE COVER	TATA spare parts
399015323007	ABS DRIVER DOOR LOCK COVER_3THIK	TATA spare parts
399015323009	DRIVER DOOR HINGE SUPPORT PLATE COVER	TATA spare parts
399015323011	DRIVER DOOR INNER LOCK COVER ABS	TATA spare parts
399015323012	MAGAZINE HOLDER RHD	TATA spare parts
399015323014	ABS COVER	TATA spare parts
399015323015	ABS DRIVER DOOR LOCK COVER	TATA spare parts
399015323016	DOOR BOLT COVER	TATA spare parts
399015323021	WATER BOTTLE HOLDER_RAL 7040 BS6	TATA spare parts
399015323022	DRIVER DOOR CANOPY -ABS	TATA spare parts
399015323025	DRIVER DOOR LOCK CATCHER COVER ABS	TATA spare parts
399015323026	LCV-EX DRI DOOR MAGAZINE COVER ABS	TATA spare parts

399015323027	LCV EX-DRIVER DOOR CANOPY (ABS)	TATA spare parts
399015323031	DRIVER DOOR LOCK MECHANSIM COVER LHD	TATA spare parts
399015323032	LHD EX-DRIVER DOOR CANOPY -ABS	TATA spare parts
399015323033	DRIVER DOOR LOCK MECHANSIM COVER RHD_LC	TATA spare parts
399016002001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
399016002002	EMERGENCY DOOR FINISHING ASSEMBLY	TATA spare parts
399016002003	EMERGENCYDOORASSEMBLY	TATA spare parts
399016002014	EMERGENCY DOOR FINISHING ASS-EX	TATA spare parts
399016003001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
399016003002	EMERGENCY DOOR LOCK COVER-ABS	TATA spare parts
399016003003	EMERGENCY DOOR LOCK COVER	TATA spare parts
399016003004	EMERGENCY DOOR EXTERNAL PANELING	TATA spare parts
399016003021	EMG DOOR EXT PANEL FLUSH TYPE_705X1614	TATA spare parts
399016003028	RAILWAY LATCH CATCHER ASSLY	TATA spare parts
399016003029	RAILWAY LOCK LATCH ASSLY	TATA spare parts
399016004001	EMERGENCY DOOR EXTERNAL PANELING	TATA spare parts
399016004002	EMERGENCY DOOR SEALING SUPPORT ASSY	TATA spare parts
399016004021	LOCK KIT ASSEMBLY	TATA spare parts
399016006002	EMERGENCY DOOR LOCK KIT	TATA spare parts
399016083001	EMERGENCY DOOR INTERNAL PANEL	TATA spare parts
399016083002	EMERGENCY DOOR INTERNAL PANEL 1	TATA spare parts
399016083014	EMERGENCY DOOR INTERNAL PANEL	TATA spare parts
399016083016	EMERGENCY DOOR INT PANEL EX& PVC	TATA spare parts
399016083022	LOCK FINISHING COVER BS6	TATA spare parts
399016084001	SENSOR SUPPORT& E DOOR LOCK COVER	TATA spare parts
399016084022	LIMIT SWITCH MTG BKT EV	TATA spare parts
399016085002	EMERGENCY DOOR SEALING SUPPORT	TATA spare parts
399016085003	EMERGENCY DOOR SEALING SUPPORT	TATA spare parts
399016085004	EMERGENCY DOOR SEALING SUPPORT	TATA spare parts
399016085005	EMERGENCY DOOR SEALING SUPPORT	TATA spare parts
399016234002	EMERGENCY DOOR GLASS NEW	TATA spare parts
399016303001	EMERGENCY DOOR LOCK COVER-ABS	TATA spare parts
399016303003	EMERGENCY DOOR CANOPY - PP	TATA spare parts
399016303006	LIMIT SWITCH COVER_ EME DOOR EV	TATA spare parts
399016303014	EMERGENCY DOOR INNER COVER	TATA spare parts
399016323004	EMERGENCY DOOR KNOB COVER	TATA spare parts
399016323006	EMERGENCY DOOR LOCK COVER-LHD-ABS	TATA spare parts
399016323007	EMERGENCY DOOR KNOB COVER	TATA spare parts
399016323010	EMERGENCY DOOR CANOPY -ABS	TATA spare parts
399016323011	EMERGENCY DOOR INNER COVER	TATA spare parts
399017002003	COMPLETE DOOR AS A KIT	TATA spare parts
399017002017	DRIVER DOOR HINGE ASSEMBLY.	TATA spare parts
399017002018	DRIVER DOOR HINGE ASSEMBLY.	TATA spare parts
399017002019	JK PASSENGER DOOR	TATA spare parts
399017002022	REAR STEP ASSY	TATA spare parts
399017002026	PASSENGER DOOR ASSY	TATA spare parts
399017002033	JK DOOR NEW CONCEPT	TATA spare parts

399017002034	LHD JK PASSENGER DOOR	TATA spare parts
399017003001	BEARING CASE/LOWER	TATA spare parts
399017003003	PASSENGER DOOR	TATA spare parts
399017003004	J K DOOR ASSY FOR LHD BUSES	TATA spare parts
399017003005	PNEUMATIC CYLINDER HOLDER	TATA spare parts
399017003006	PNEUMATIC DOOR ATTACHMENT PLATE ASSEMB	TATA spare parts
399017003007	PNEUMATIC SYSTEM ASSY	TATA spare parts
399017003008	JENETICS DOOR PNEUMATIC SYSTEM	TATA spare parts
399017003009	PASSENGER DOOR	TATA spare parts
399017003010	SKOOL BUS STOP PLATE ASSY	TATA spare parts
399017003015	PASSANGER DOOR LOCK ASSY	TATA spare parts
399017003016	J K DOOR LOWER BRG ASSY	TATA spare parts
399017003017	JK DOOR UPPER BEARING ASSEMBLY	TATA spare parts
399017003018	JK DOOR UPPER LATCH	TATA spare parts
399017003022	JK DOOR	TATA spare parts
399017003029	PNEUMATIC DOOR FRONT BOX	TATA spare parts
399017003030	PNEUMATIC DOOR REAR BOX	TATA spare parts
399017003032	BOTOM BRACKET ASSY_DOOR	TATA spare parts
399017003033	TOP BRACKET ASSY_DOOR	TATA spare parts
399017003034	TOP BRACKET WITH BEARING ASSY	TATA spare parts
399017003038	PNEUMATIC CYLINDER COVER ASSY	TATA spare parts
399017003054	PASSENGER DOOR 830X1970_Y1 RHD	TATA spare parts
399017003074	JK DOOR ASSY-RHD	TATA spare parts
399017003082	LHD MI-TECH JK PAS. DOOR 30% GREEN TINT	TATA spare parts
399017003084	PNEUMATIC SYSTEM ASSEMBLY	TATA spare parts
399017003086	REAR DOOR LH SIDE PANELING	TATA spare parts
399017003089	PASSENGER DOOR LHD	TATA spare parts
399017003091	MI-TECK JK PASSENGER DOOR LOW COST	TATA spare parts
399017003095	UPPER REAR HINGE LH	TATA spare parts
399017003096	UPPER REAR DOOR HINGE RH	TATA spare parts
399017003097	RHD JK PAS. DOOR 30PERC GREEN TINT	TATA spare parts
399017003117	PNUEMATIC DOOR ATTACHMENT PLATE ASSY	TATA spare parts
399017003118	PNEUMATIC CYLINDER HOLDER	TATA spare parts
399017003125	WIRE MESH FRAME FOR DRIVER DOOR	TATA spare parts
399017003133	ELEC-PNEUMATIC ASSY WITH SENSITIVITY	TATA spare parts
399017003134	WIRE HARNESS WITH SWITCH	TATA spare parts
399017003138	PNEUMATIC CYLINDER COVER ASSY LHD	TATA spare parts
399017003141	FLAP TYPE PASS DOOR WITH HINGE AND LOCK	TATA spare parts
399017003157	5/2 SOLE NOID VALVE 12-V	TATA spare parts
399017003158	5/2 RESET VALVE ASSEMBLY 12-V	TATA spare parts
399017004011	CYLINDER	TATA spare parts
399017004012	1/4-3/2 NO PUSH PULL DETENT VALVE WIT	TATA spare parts
399017004013	1/4-5/2 PUSH PULL DETENT VALVE WITH F	TATA spare parts
399017004014	1/4-3/2 NO PUSH PULL DETENT VALVE WIT	TATA spare parts
399017004015	FLOW CONTROL VALVE 1/4 X DIA 6	TATA spare parts
399017004016	UNION TEE DIA6	TATA spare parts
399017004017	PE CONVERTOR WITH CLAMP	TATA spare parts

399017004018	SEAL KIT ( DIA 63)	TATA spare parts
399017004019	SEAL KIT	TATA spare parts
399017004020	SEAL KIT	TATA spare parts
399017004021	3/ 2 SPOOL VALVE 1/4 X DIA 6	TATA spare parts
399017004039	PNEUMATIC CYLINDER COVER ASSY	TATA spare parts
399017004040	PNEUMATIC CYLINDER COVER ASSY-LCV	TATA spare parts
399017004050	JK DOOR UPPER LATCH BS1/2/3/4/6	TATA spare parts
399017004058	PASSENGER DOOR HINGE	TATA spare parts
399017004059	PASSENGER DOOR HANDLE	TATA spare parts
399017004060	PASSENGER ROLLER BEARING	TATA spare parts
399017004061	PASSENGER TOP PIVOT HINGE	TATA spare parts
399017004062	PASSENGER DOOR BOTTOM HINGE	TATA spare parts
399017004082	PASSENGER DOOR HINGE WITH HANDLE	TATA spare parts
399017004085	PASS DOOR TOP BEARING ASSLY	TATA spare parts
399017004092	PASS DOOR TOP BEARING ASSLY BS6	TATA spare parts
399017005024	LOCK HANDLE	TATA spare parts
399017005025	TOWER BOLT WITH HANDLE	TATA spare parts
399017005041	TOWER BOLT ASSY	TATA spare parts
399017064001	JK DOOR GRAB HANDLE	TATA spare parts
399017074002	JK DOOR TOP MOVING AXLE	TATA spare parts
399017074003	JK DOOR BOTTOM AXLE	TATA spare parts
399017074004	BEARING	TATA spare parts
399017074005	JK DOOR TOP FIXED AXLE	TATA spare parts
399017074006	HINGE ASSY (WITH HANDLE)	TATA spare parts
399017074007	HINGE ASSY (WITHOUT HANDLE)	TATA spare parts
399017074008	LATCH ASSY (TOWER BOLT)	TATA spare parts
399017074009	PNEUMATIC CYLINDER HOLDER BASE PIN	TATA spare parts
399017074020	PIVOT BUSH BS6	TATA spare parts
399017074021	THREADED PIVOT BUSH BS6	TATA spare parts
399017076004	UPPER LOCK SUPPORT PART	TATA spare parts
399017076005	CIRCULAR BUSH	TATA spare parts
399017083001	DOOR ATTACHMENT PLATE SUPPORT	TATA spare parts
399017083002	STOP PLATE FOR SKOOL BUS	TATA spare parts
399017083006	LOCK LOCATOR	TATA spare parts
399017083009	SKOOL BUS STOP PLATE	TATA spare parts
399017083011	INTERNAL PANEL	TATA spare parts
399017083023	INTERNAL PANEL OF DOOR	TATA spare parts
399017084002	PNEUMATIC CYLINDER HOLDER BASE PLATE	TATA spare parts
399017084003	PNEUMATIC DOOR ATTACHMENT PLATE BS6	TATA spare parts
399017084058	EXTERNAL PANNEL	TATA spare parts
399017084068	SPACER	TATA spare parts
399017084093	INTERNAL LOCK COVER BLACK	TATA spare parts
399017184010	REAR DOOR INT PANEL	TATA spare parts
399017184011	REAR DOOR EXT PANEL	TATA spare parts
399017184012	REAR DOOR INT PANEL	TATA spare parts
399017234001	GLASS CLEAR (225X1646X5 THK)	TATA spare parts
399017234002	JK DOOR 30% GREEN TINTED GLASS	TATA spare parts



399017234003	REAR DOOR GLASS	TATA spare parts
399017234004	GLASS	TATA spare parts
399017234005	NOTE 30PERC GREEN TINTED GLASS	TATA spare parts
399017234011	PASSENER DOOR GLASS	TATA spare parts
399017235001	GLASS CLEAR (225X1646X5 THK)	TATA spare parts
399017283001	PU TUBE (RED)	TATA spare parts
399017283002	PU TUBE (BLUE)	TATA spare parts
399017283003	PU TUBE (YELLOW)	TATA spare parts
399017284001	WEAT.STRIP(PASS.DOOR.BIG BULB)	TATA spare parts
399017284002	WEAT.STRIP(PASS.DR-MDL.SMALL D)	TATA spare parts
399017284003	WEAT.STRIP(PASS.DR-FLAP/SHAFT)	TATA spare parts
399017284004	JK DOOR RUBBER STOPPER	TATA spare parts
399017284006	JK DOOR¿ RUBBR PROFILE (OPOSIT TO AXLE)	TATA spare parts
399017284007	JK DOOR¿ RUBBR PROFILE (BETWEEN DOORS)	TATA spare parts
399017284008	JK DOOR RUBBER PROFILES( GLASS BASE)	TATA spare parts
399017285001	WEATH.STRIP(PASS.DR-GLASS KEY)	TATA spare parts
399017303001	PASSENGER DOOR CANOPY - PP	TATA spare parts
399017304001	UPPER BEARING PART	TATA spare parts
399017304002	UPPER BEARING PART	TATA spare parts
399017305001	DOOR BRUSH	TATA spare parts
399017306001	HANDLE GRIPPER	TATA spare parts
399017314004	BALL BEARING	TATA spare parts
399017323008	HINGE FINISHING COVER TOP	TATA spare parts
399017323009	HINGE FINISHING COVER BOTTOM	TATA spare parts
399017323010	HINGE FINISHING COVER SIDE	TATA spare parts
399017323011	PASSENGER DOOR CANOPY -ABS	TATA spare parts
399018003004	FRONT GRILLE	TATA spare parts
399018003008	HINGE ASSEMBLY LH	TATA spare parts
399018003009	HINGE ASSEMBLY RH	TATA spare parts
399018003010	FLAP GUIDE LOCK ASSY-LH	TATA spare parts
399018003011	FLAP GUIDE LOCK ASSY-RH	TATA spare parts
399018003012	FLAP LIMIT ROD	TATA spare parts
399018003013	FRONT FLAP LIMIT ROD	TATA spare parts
399018003015	FRONT FLAP WITH STRUCTURE	TATA spare parts
399018003019	FRONT FLAP WITH STRUCTURE	TATA spare parts
399018003021	FRONT FLAP WITH STRUCTURE LOCKING CATCHE	TATA spare parts
399018003022	FRONT FLAP LIMIT ROD ASSEMBLY	TATA spare parts
399018003024	FLAP GUIDE LOCK ASSY	TATA spare parts
399018003025	ASSY. FRT BUMPER SINGLE FRP PIECE BS1- 4	TATA spare parts
399018003026	SINGLE PIECE BUMPER FRONT	TATA spare parts
399018003027	SINGLE PIECE BUMPER FRONT	TATA spare parts
399018003028	FRONT BUMPER	TATA spare parts
399018003029	FRP FRONT FACE W/HEAD LAMP BKT BS1/2/3/4	TATA spare parts
399018003032	FRP FRONT FACE AND FLAP ASSY	TATA spare parts
399018003036	CNG FRP FRONT FLAP WITH HINGE ASSY	TATA spare parts
399018003037	FRP FRONT FACE AND FLAP ASSY	TATA spare parts
399018003038	FRP FRONT BUMPER SINGLE PIECE ASSY	TATA spare parts

399018003039	LC FRP FRONT FACE WT LAMP REINFORCEMENT	TATA spare parts
399018003040	FRP FRONT BUMPER ASSEMBLY	TATA spare parts
399018003041	FRONT FLAP ASSEMBLY	TATA spare parts
399018003042	LC FRONT FLAP LIMIT ROD ASSY	TATA spare parts
399018003046	FRP FRONT BUMPER WITH LAMP BRACKET_AMB	TATA spare parts
399018003049	FRP FRONT FACE AND FLAP ASSY	TATA spare parts
399018003060	FRP FRONT FACE ASSEMBLY	TATA spare parts
399018003061	BUMPER GRILL ASSEMBLY-LCV EX	TATA spare parts
399018003062	LCV-EX FRONT BUMPER GRILL ASSEMBLY	TATA spare parts
399018003063	FRONT FLAP ASSEMBLY	TATA spare parts
399018003065	LH ARM GUIDE BRACKET ASSY	TATA spare parts
399018003066	RH ARM GUIDE BRACKET ASSY	TATA spare parts
399018003069	FRONT BUMPER ASSY WITH FOG LAMP	TATA spare parts
399018003078	FRP FRONT BUMPER ASSY (NEW MOUNTING BRT)	TATA spare parts
399018004003	HEADLAMP ATTACHING SUPPORT-RH	TATA spare parts
399018004004	HEADLAMP ATTACHING SUPPORT-LH	TATA spare parts
399018004006	FRONT BUMPER(LEFT)	TATA spare parts
399018004007	FRONT BUMPER(RIGHT)	TATA spare parts
399018004008	FRONT BUMPER(CENTER)	TATA spare parts
399018004009	FRONT BUMPER(LEFT)	TATA spare parts
399018004010	FRONT BUMPER(RIGHT)	TATA spare parts
399018004011	FRONT BUMPER(CENTER)	TATA spare parts
399018004018	CNG FLAP WITH STRUCTURE FITMENT	TATA spare parts
399018004021	FRONT FLAP CATCHER-MALE ASSY	TATA spare parts
399018004023	LC HINGE ASSEMBLY LH	TATA spare parts
399018004024	LC HINGE ASSEMBLY RH	TATA spare parts
399018004040	LCV-EX FRONT BUMPER ASSEMBLY	TATA spare parts
399018005008	FRONT FLAP STRUCTURE FOR CNG FLAP	TATA spare parts
399018064004	FLAP LIMIT ROD	TATA spare parts
399018064005	LIMIT LOCK SUPPORT PLATE	TATA spare parts
399018083006	BUS BODY IDENTIFICATION PLATE	TATA spare parts
399018083008	HINGE MOUNTING L-PROFILE LH	TATA spare parts
399018083009	HINGE MOUNTING L-PROFILE RH	TATA spare parts
399018083033	SP FRONT METAL BUMPER ASSY 42 49WB	TATA spare parts
399018084011	FLAP HOLDING LOCK PLATE	TATA spare parts
399018085024	FOG LAMP BRACKET	TATA spare parts
399018186003	TOP MESH GRILL FOR FLAP	TATA spare parts
399018186004	LOW COST BOTTOM MESH GRILL FOR FLAP	TATA spare parts
399018213008	LCV-EX FRONT RAIN GUTTER-LH	TATA spare parts
399018213009	LCV-EX FRONT RAIN GUTTER-RH	TATA spare parts
399018263001	FRONT EXTERNAL REVETMENT	TATA spare parts
399018263002	FRONT EXTERNAL REVETMENT	TATA spare parts
399018264001	FRONT GRILLE	TATA spare parts
399018264002	FRONT BUMPER SINGLE PIECE	TATA spare parts
399018264003	FRP FRONT BUMPER SINGLE PIECE 42/49WB	TATA spare parts
399018264006	FRP FRONT BUMPER SINGLE PIECE	TATA spare parts
399018264007	FRP FRONT FACE	TATA spare parts

399018264012	LCV-EX FRONT BUMPER FRP	TATA spare parts
399018265005	LCV-EX FRONT FACE FRP	TATA spare parts
399018912005	FRONT FLAP HINGE MECHANISM ASSY	TATA spare parts
399018912029	FRP FACE WITH CNG FLAP FITMENT	TATA spare parts
399019002006	REAR LUGGAGE FLAP ASSY	TATA spare parts
399019002008	REAR EXT FACE WITH W/S REINFORCEMENT	TATA spare parts
399019002009	REAR EXT FACE WITH W/S REINFORCEMENT	TATA spare parts
399019003001	REAR FLAP LATCH ASSEMBLY	TATA spare parts
399019003004	REAR FLAP ASSY	TATA spare parts
399019003007	SINGLE PIECE BUMPER REAR	TATA spare parts
399019003010	ASSY. REAR BUMPER FRP PIECE SFC BS1- 4	TATA spare parts
399019003012	FRP REAR FACE INT BUMPER ASSY	TATA spare parts
399019003017	REAR BUMPER ASSY	TATA spare parts
399019003018	FRP REAR BUMPER SUB ASSEMBLY	TATA spare parts
399019003021	REAR EXTERNAL FACE WITH WS REINFORCEMENT	TATA spare parts
399019003026	FRP REAR FACE INT BUMPER	TATA spare parts
399019003029	REAR BUMPER ASSY	TATA spare parts
399019003033	LCV-EX REAR BUMPER WITH FOG LAMP ASSY	TATA spare parts
399019003035	REAR FACE ASSY WITH MESH REINFORCEMENT	TATA spare parts
399019004001	REAR BUMPER(CENTER)	TATA spare parts
399019004002	REAR BUMPER LH	TATA spare parts
399019004003	REAR BUMPER RH	TATA spare parts
399019004004	REAR BUMPER(RIGHT)	TATA spare parts
399019004005	REAR BUMPER(LEFT)	TATA spare parts
399019004006	UPHOLDING PISTON COUPLING ASSEMBLY RH	TATA spare parts
399019004007	REAR FLAP HINGE ASSEMBLY LH	TATA spare parts
399019004008	REAR FLAP HINGE ASSEMBLY RH	TATA spare parts
399019004009	UPHOLDING PISTON COUPLING ASSEMBLY LH	TATA spare parts
399019004010	REAR FLAP STRUCTURE ASSEMBLY	TATA spare parts
399019063001	WINDSHIELD WIPER AXLE BUSHING	TATA spare parts
399019074002	SIDE FLAP LATCH DRIVER ROD	TATA spare parts
399019083012	SP REAR METAL BUMPER ASSY 42 49WB	TATA spare parts
399019084002	REAR FLAP LATCH SUPPORT	TATA spare parts
399019184001	REAR FLAP PANEL PLATE	TATA spare parts
399019213003	LCV-EX REAR RAIN GUTTER-LH	TATA spare parts
399019213004	REAR RAIN GUTTER -RH	TATA spare parts
399019263002	REAR EXTERNAL REVETMENT	TATA spare parts
399019263003	REAR EXT. FACE(TAIL LAMP DOWN&LUG.CARR)	TATA spare parts
399019263011	REAR EXTERNAL FACE WITH REAR DOOR	TATA spare parts
399019264001	FRP REAR BUMPER SINGLE PIECE	TATA spare parts
399019264002	REAR BUMPER SINGLE PIECE	TATA spare parts
399019264004	FRP REAR BUMPER SINGLE PIECE SFC	TATA spare parts
399019264010	FRP SINGLE PIECE REAR BUMPER	TATA spare parts
399019264018	REAR FACE FRP W/O RLB	TATA spare parts
399019264019	LCV-EX REAR BUMPER FRP W/O FOG LAMP	TATA spare parts
399019303001	REAR FLAP LOCK & HANDLE	TATA spare parts
399019314001	REAR FLAP LATCH COUPLING	TATA spare parts

399020002023	BATTERY FLAP ASSY	TATA spare parts
399020002025	BATTERY FLAP ASSY. FOR SFC BUS	TATA spare parts
399020002046	SIDE LUGGAGE FLAP RUBBER ASSY	TATA spare parts
399020002047	SIDE LUGGAGE FLAP RUBBER& ASSY	TATA spare parts
399020002048	SIDE LUGGAGE FLAP ASSY	TATA spare parts
399020002049	BATTERY FLAP ASSY	TATA spare parts
399020002051	AIR FILTER FLAP	TATA spare parts
399020002052	BATTERY FLAP ASSY	TATA spare parts
399020002055	BATTERY FLAP ASSEMBLY	TATA spare parts
399020002056	AIR FILTER FLAP ASSEMBLY	TATA spare parts
399020002057	FUEL PRIMING FLAP ASSEMBLY	TATA spare parts
399020002061	SPARE WHEELFLAP ASSEMBLY	TATA spare parts
399020002065	JERRY CAN FLAP ASSEMBLY	TATA spare parts
399020002068	OXYGEN CYLINDER FLAP ASSEMBLY	TATA spare parts
399020002069	RLB FLAP ASSEMBLY	TATA spare parts
399020002071	GENSET FLAP ASSEMBLY	TATA spare parts
399020003001	BATTERY BOX HINGED DOOR ASSEMBLY	TATA spare parts
399020003002	SHUTTER UPHOLDING STALK	TATA spare parts
399020003003	HINGE RH	TATA spare parts
399020003004	HINGE LH	TATA spare parts
399020003005	BATTERY BOX HINGED DOOR ASSEMBLY	TATA spare parts
399020003009	AIR INTAKE HINGED DOOR ASSY	TATA spare parts
399020003020	BATTERY BOX HINGED DOOR ASSEMBLY	TATA spare parts
399020003021	SIDE SPARE WHEEL CARRIER FLAP	TATA spare parts
399020003022	FLAP STAY ROD	TATA spare parts
399020003023	STAY ROD ASSY	TATA spare parts
399020003024	FLAP	TATA spare parts
399020003033	ALU.AUXILARY ENGINE FLAP ASSEMBLY	TATA spare parts
399020003040	STAY ROD ASSY	TATA spare parts
399020003051	SLB FLAP ASSEMBLY	TATA spare parts
399020003054	SIDE LUGGAGE BOTH FLAP LOCK PLATE ASSY	TATA spare parts
399020003063	SLF STRUCTURE ASSY	TATA spare parts
399020003064	FLAP ASSY FOR CNG BUS	TATA spare parts
399020003067	CNG & BATTERY FLAP ASSY	TATA spare parts
399020003068	SIDE LUGGAGE FLAP ASSY	TATA spare parts
399020003073	SIDE FLAP LATCH ASSEMBLY	TATA spare parts
399020003075	SLB FLAP ASSY	TATA spare parts
399020003082	AIR FILTER FLAP ASSY	TATA spare parts
399020003101	RUBBER ASSEMBLY	TATA spare parts
399020003102	RUBBER ASSEMBLY	TATA spare parts
399020003140	FLAP ASSY	TATA spare parts
399020003144	BATTERY BOX FLAP ASSY	TATA spare parts
399020003150	AIR FILTER FLAP PANEL ASSY 430X650	TATA spare parts
399020003153	BATTERY FLAP SUB ASSLY_580X500 IB	TATA spare parts
399020003154	LOCK ROD & LEVER ASSY FOR SLB FLAP IB	TATA spare parts
399020003156	BATTERY FLAP SUB ASSLY 650X390	TATA spare parts
399020003159	SPARE WHEEL FLAP ASSLY_920X428	TATA spare parts

399020003160	SLB FLAP ASSLY WITH RUBBER_990X500 IB	TATA spare parts
399020003170	BATTERY FLAP WITH KEY LOCK ASSLY	TATA spare parts
399020004001	INTERNAL HINGE WITH BOLT	TATA spare parts
399020004004	HINGED DOORS LATCH ASSEMBLY	TATA spare parts
399020004065	LOCK ROD ASSY FOR SLB FLAP BS6	TATA spare parts
399020004069	AIR FILTER FLAP ASSLY_296X313_29WB	TATA spare parts
399020005013	LH GAS PISTON HOLDER FOR SLB FLAP BS6	TATA spare parts
399020063001	STAY ROD	TATA spare parts
399020073001	ADJUSTABLE JAMB ROD	TATA spare parts
399020073002	C_COTT_SPLIT PIN_1.6_25_DIN94_SS304_E_X	TATA spare parts
399020073003	LOCKS AND LATCHES	TATA spare parts
399020073004	LOCK ASSY	TATA spare parts
399020074001	SHUTTER UPHOLDING STALK	TATA spare parts
399020074007	SLC	TATA spare parts
399020083002	SUPPORT FOR UPHOLDING ROD COUPLING PLATE	TATA spare parts
399020083004	FLAP LATCH COUPLING	TATA spare parts
399020083008	LCV LC BUS SLF -CLAMP 1	TATA spare parts
399020083009	SLF CLAMP 2	TATA spare parts
399020083011	FLAP LOCK BRACKET 2	TATA spare parts
399020083068	CANOPY	TATA spare parts
399020084004	BATTERY STALK ATTACHMENT PLATE	TATA spare parts
399020084016	SLB FLAP	TATA spare parts
399020084081	FLAP LOCK REINFORCEMENT PLATE _LCV BS6	TATA spare parts
399020084082	FLAP LOCK ASSY PLATE _ LCV BS6	TATA spare parts
399020084083	FLAP LOCK PLATE _ LCV	TATA spare parts
399020084104	KEY LOCK HOLDER FOR BATTERY FLAP BS6	TATA spare parts
399020086003	LOCK SUPPORT PLATE BLACK COLOR	TATA spare parts
399020303002	STAY ROD HOLDER	TATA spare parts
399020303003	LOCK COVER	TATA spare parts
399020304001	HINGED DOORS ROD BEARING BASE	TATA spare parts
399020304002	HINGED DOORS ROD BEARING COVER	TATA spare parts
399020304003	SEALING JOINT	TATA spare parts
399020314001	HINGED DOORS LATCH COVER	TATA spare parts
399020404001	BUDGET LOCK KEY	TATA spare parts
399020912001	BATTERY BOX FLAP ASSY	TATA spare parts
399020912002	BATTERY BOX FLAP ASSEMBLY-LHD	TATA spare parts
399020912006	SPARE WHEEL FLAP ASSY	TATA spare parts
399020912007	BATTERY BOX FLAP ASSEMBLY	TATA spare parts
399021003002	INSPECTION COVER ASSEMBLY FOR GEAR BOX	TATA spare parts
399021082001	COOLANT TANK COVER	TATA spare parts
399021083017	CLUTCH RESERVOIR MTG BRACKET	TATA spare parts
399021084002	WINDSHIELD WIPER TANK SUPPORT	TATA spare parts
399021912014	DRIVER PLATFORM ASSEMBLY DETAIL	TATA spare parts
399022003019	PASSENGER STEPS ASSEMBLY 42 WB	TATA spare parts
399022003036	PASSENGER FOOT STEP ASSEMBLY_Y1	TATA spare parts
399022003065	SLIDEING STEPS FINISHING ASSY	TATA spare parts
399022003091	SLIDING TRAY WITH STOPPER BS6-PH2	TATA spare parts

399022083023	DOOR MIRROR-L.H_Y1 BS6	TATA spare parts
399022083024	DOOR MIRROR-R.H_Y1 BS6	TATA spare parts
399022083036	BOTTOM FIXED L LH	TATA spare parts
399022083037	BOTTOM FIXED L RH	TATA spare parts
399022087003	TOOL BOX COVER	TATA spare parts
399027083002	ROOF EXTERNAL PANELLING PLATE FRONT	TATA spare parts
399027083003	ROOF EXTERNAL PANELLING PLATE REAR	TATA spare parts
399027083005	ROOF EXTERNAL PANELLING PLATE REAR	TATA spare parts
399027083018	ROOF EXTERNAL PANELLING PLATE	TATA spare parts
399027083019	ROOF EXTERNAL PANELLING PLATE_3800	TATA spare parts
399028003001	FUEL TANK NOZZLE COVER	TATA spare parts
399028003002	DRIVER STEP FRP	TATA spare parts
399028003004	FUEL TANK NOZZLE ASSY	TATA spare parts
399028003005	FOLDABLE FOOT STEP ASSY	TATA spare parts
399028003008	FULE TANK FLAP WITH KEY	TATA spare parts
399028004001	FUEL TANK NOZZLE COVER ASSEMBLY	TATA spare parts
399028083001	STRETCH PANEL R.H SIDE	TATA spare parts
399028083002	EXT PANELLING SHEET RIGHT SIDE TO PASSEN	TATA spare parts
399028083003	MIDDLE SKIRT PANEL RIGHT SIDE	TATA spare parts
399028083004	REAR SKIRT PANEL RIGHT SIDE	TATA spare parts
399028083005	STRETCH PANEL AHEAD OF DRIVER DOOR	TATA spare parts
399028083006	EXTERNAL PANEL ON WINDOW TUBES	TATA spare parts
399028083007	EXTERNAL PANEL BEHIND DRIVER DOOR	TATA spare parts
399028083008	EXT REVETMENT PLATES BETWEEN WINDOWS	TATA spare parts
399028083009	EXTERNAL PANEL AT EXTREME END OF R.H SID	TATA spare parts
399028083010	STRETCH PANEL AT L.H SIDE BEHIND THE PAS	TATA spare parts
399028083011	SKIRT PANEL 3 ON L.H SIDE	TATA spare parts
399028083012	STRETCH PANEL ON L.H SIDE AHEAD OF PASSE	TATA spare parts
399028083013	EXTERNAL PANEL AT EXTREME END OF L.H SID	TATA spare parts
399028083014	EXTERNAL PANEL AHEAD OF PASSENGER DOOR	TATA spare parts
399028083015	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
399028083017	EXT PANELLING PLATE BETWEEN TRIANGULAR	TATA spare parts
399028083018	DOOR LOWER EXTERNAL PLATE	TATA spare parts
399028083021	SKIRT EXTERNAL PANELLING R.H FRONT	TATA spare parts
399028083022	SKIRT EXTERNAL PANELLING L.H FRONT	TATA spare parts
399028083023	SKIRT PANEL AT BATTERY BOX	TATA spare parts
399028083024	MIDDLE SKIRT PANEL ON L.H SIDE	TATA spare parts
399028083025	MIDDLE SKIRT PANET RIGHT SIDE	TATA spare parts
399028083026	REAR SKIRT PANEL RIGHT SIDE	TATA spare parts
399028083028	EXTERNAL PANEL AT EXTREME END OF R.H SID	TATA spare parts
399028083030	SKIRT PANEL 3 ON L.H SIDE	TATA spare parts
399028083031	EXTERNAL PANEL AT EXTREME END OF L.H SID	TATA spare parts
399028083032	SKIRT EXTERNAL PANELLING R.H FRONT	TATA spare parts
399028083034	SKIRT EXTERNAL PANELLING L.H MIDDLE	TATA spare parts
399028083035	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
399028083040	SKIRT PANEL LH FRONT	TATA spare parts
399028083041	SKIRT PANEL LH MIDDLE	TATA spare parts

399028083042	SKIRT PANEL RH FRONT	TATA spare parts
399028083043	SKIRT PANEL NEAR FRONT DOOR RH	TATA spare parts
399028083044	SKIRT PANEL RH MIDDLE	TATA spare parts
399028083045	SKIRT PANEL NEAR REAR DOOR RH	TATA spare parts
399028083046	SKIRT PANEL RH REAR	TATA spare parts
399028083047	STRETCH PANEL ON LH SIDE	TATA spare parts
399028083048	STRETCH PANEL RH MIDDLE	TATA spare parts
399028083049	STRETCH PANEL RH REAR	TATA spare parts
399028083050	STRETCH PANEL RH BEHIND PEEP WINDOW	TATA spare parts
399028083051	STRETCH PANEL LH FRONT	TATA spare parts
399028083053	EXTERNAL PANEL AT LH FRONT TOP	TATA spare parts
399028083054	STRETCH PANEL R.H SIDE	TATA spare parts
399028083055	MIDDLE SKIRT PANEL RIGHT SIDE	TATA spare parts
399028083056	END SKIRT PANEL RIGHT SIDE	TATA spare parts
399028083057	EXTERNAL PANEL AT EXTREME END OF R.H SID	TATA spare parts
399028083058	STRETCH PANEL AT L.H SIDE BEHIND THE PAS	TATA spare parts
399028083059	SKIRT PANEL 3 ON L.H SIDE	TATA spare parts
399028083060	EXTERNAL PANEL AT EXTREME END OF L.H SID	TATA spare parts
399028083061	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
399028083063	SKIRT EXTERNAL PANELLING MIDDLE OF L.H	TATA spare parts
399028083064	SKRIT PANEL RH REAR	TATA spare parts
399028083065	SKRIT PANEL RH MIDDLE	TATA spare parts
399028083066	SKIRT EXTERNAL PANELLING R.H FRONT	TATA spare parts
399028083067	STRECH PANEL RH	TATA spare parts
399028083068	STRETCH PANEL AHEAD OF DRIVER DOOR	TATA spare parts
399028083069	SKIRT PANEL AT BATTERY BOX	TATA spare parts
399028083072	STRETCH PANEL LH	TATA spare parts
399028083073	SKIRT PANEL LH MIDDLE	TATA spare parts
399028083074	SKIRT PANEL LH REAR	TATA spare parts
399028083075	EXTERNAL PANEL AT DRIVER DOOR	TATA spare parts
399028083076	SKIRT PANEL LH REAR	TATA spare parts
399028083077	STRETCH PANEL RH FRONT-3	TATA spare parts
399028083078	STRETCH PANEL RH FRONT-2	TATA spare parts
399028083079	STRETCH PANEL AHEAD OF PEEP WINDOW	TATA spare parts
399028083080	SKIRT PANEL AT BATTERY BOX	TATA spare parts
399028083081	SKIRT PANEL AT SIDE FLAP	TATA spare parts
399028083082	STRETCH PANEL RH FRONT	TATA spare parts
399028083083	SKIRT PANEL OF BATTERY BOX	TATA spare parts
399028083084	STRETCH PANEL LH MIDDLE	TATA spare parts
399028083085	STRETCH PANEL LH REAR	TATA spare parts
399028083086	SKIRT PANEL LH REAR	TATA spare parts
399028083087	SKIRT PANEL LH	TATA spare parts
399028083088	SKIRT PANEL L.Hç MIDDLE	TATA spare parts
399028083090	STRETCH PANEL RH MIDDLE	TATA spare parts
399028083091	SKIRT PANEL BEHIND SPARE WHEEL FLAP	TATA spare parts
399028083092	SKIRT PANEL LH MIDDLE	TATA spare parts
399028083094	STRETCH PANEL RIGHTSIDE TO PASSENGER DOO	TATA spare parts

399028083095	STRETCH PANEL RIGHTSIDE TO PEEP WINDOW	TATA spare parts
399028083096	SKIRT PANEL LH FRONT	TATA spare parts
399028083097	SKIRT PANEL LH AHEAD OF BATTERY FLAP	TATA spare parts
399028083098	SKIRT PANEL RH FRONT	TATA spare parts
399028083099	SKIRT PANEL NEAR FRONT DOOR RH	TATA spare parts
399028083100	SKIRT PANEL LH FRONT	TATA spare parts
399028083101	SKIRT PANEL RH FRONT-5	TATA spare parts
399028083102	SKIRT PANEL LH FRONT	TATA spare parts
399028083103	SKIRT PANEL RH FRONT BEHIND FRONT WHEEL	TATA spare parts
399028083104	SKIRT PANEL RH FRONT AHEAD OF FRONT WHEEL	TATA spare parts
399028083105	STRETCH PANEL ON L.H FRONT	TATA spare parts
399028083106	SKIRT PANEL RIGHTSIDE TO PASSENGER DOOR	TATA spare parts
399028083107	SKIRT PANEL LH FRONT-11	TATA spare parts
399028083108	STRETCH PANEL R.H SIDE	TATA spare parts
399028083109	MIDDLE SKIRT PANEL RIGHT SIDE	TATA spare parts
399028083110	END SKIRT PANEL RIGHT SIDE	TATA spare parts
399028083111	EXTERNAL PANEL AT EXTREME END OF R.H SIDE	TATA spare parts
399028083112	STRETCH PANEL LEFT SIDE TO PASSENGER DOOR	TATA spare parts
399028083113	SKIRT PANEL 3 ON L.H SIDE	TATA spare parts
399028083114	EXTERNAL PANEL AT EXTREME END OF L.H SIDE	TATA spare parts
399028083115	SKIRT PANEL RH-2	TATA spare parts
399028083116	SKIRT PANEL LEFT SIDE TO PASSENGER DOOR	TATA spare parts
399028083123	STRETCH PANEL ON LH SIDE	TATA spare parts
399028083125	SKIRT PANEL ON R.H REAR	TATA spare parts
399028083126	SKIRT PANEL LH FRONT	TATA spare parts
399028083127	SKIRT PANEL RH FRONT	TATA spare parts
399028083128	SKIRT PANEL AT AIR TANK	TATA spare parts
399028083131	SKIRT PANEL NEAR FRONT DOOR RH	TATA spare parts
399028083132	SKIRT PANEL RH FRONT	TATA spare parts
399028083133	SKIRT PANEL LH FRONT	TATA spare parts
399028083134	SKIRT PANEL LH FRONT	TATA spare parts
399028083135	SKIRT PANEL AT SIDE FLAP	TATA spare parts
399028083137	SKIRT PANEL AT BATTERY BOX	TATA spare parts
399028083138	SKIRT PANEL LH MIDDLE-FOR SLB BUS	TATA spare parts
399028083139	SKIRT PANEL LH MIDDLE-FOR SLB BUS	TATA spare parts
399028083140	SKIRT PANEL AT SLB-FOR SLB BUS	TATA spare parts
399028083141	SKIRT PANEL FOR SLB	TATA spare parts
399028083142	SKIRT PANEL MIDDLE FOR SLB	TATA spare parts
399028083143	SKIRT PANEL AT SLB-FOR SLB BUS	TATA spare parts
399028083144	SKIRT PANEL-4 ON L.H SIDE-FOR BIGGER WH.	TATA spare parts
399028083145	SKIRT PANEL ON L.H REAR- FOR BIG WH. ARC	TATA spare parts
399028083146	MIDDLE SKIRT PANEL RIGHT SIDE-FOR BIG WH	TATA spare parts
399028083147	SKIRT PANEL NEAR REAR DOOR RH	TATA spare parts
399028083163	SKIRT PANEL LH-FOR BIGGER WH.ARCH	TATA spare parts
399028083165	STRETCH PANEL LH FRONT	TATA spare parts
399028083168	SKIRT PANEL DRIVER SIDE FRONT	TATA spare parts
399028083170	STRETCH PANEL RH MIDDLE_PAS SIDE	TATA spare parts



399028083199	SKIRT PANEL RH MIDDLE AT SPARE WHEEL	TATA spare parts
399028083200	SKIRT PANEL AT EMERGENCY DOOR	TATA spare parts
399028083201	STRETCH PANEL R.H SIDE	TATA spare parts
399028083202	STRETCH PANEL RH SIDE REAR	TATA spare parts
399028083203	PANEL AT EMERGENCY DOOR	TATA spare parts
399028083204	EXTERNAL PANEL AT EXTREME END OF R.H SID	TATA spare parts
399028083205	SKIRT PANEL LH FRONT	TATA spare parts
399028083206	SKIRT PANEL LH FRONT	TATA spare parts
399028083207	SKIRT PANEL-4 ON R.H SIDE	TATA spare parts
399028083208	SKIRT PANEL LH FRONT	TATA spare parts
399028083209	SKIRT PANEL AT EMERGENCY DOOR-42	TATA spare parts
399028083211	STRETCH PANEL RH	TATA spare parts
399028083212	MIDDLE SKIRT PANEL RIGHT SIDE	TATA spare parts
399028083213	SKIRT PANEL RH FRONT	TATA spare parts
399028083214	MIDDLE SKIRT PANEL LEFT SIDE	TATA spare parts
399028083215	SKIRT PANEL NEAR FRONT DOOR REAR	TATA spare parts
399028083246	SIDE EXTERNAL ABOVE DRIVER DOOR	TATA spare parts
399028083247	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
399028083248	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
399028083249	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
399028083252	STRETCH PANEL R.H SIDE	TATA spare parts
399028083254	SKIRT PANEL FRONT RH SIDE	TATA spare parts
399028083255	STRETCH PANEL FRONT L.H SIDE	TATA spare parts
399028083256	STRETCH PANEL L.H SIDE	TATA spare parts
399028083257	STRETCH PANEL L.H SIDE	TATA spare parts
399028083258	SKIRT PANEL MIDDLE R.H SIDE	TATA spare parts
399028083259	SKIRT PANEL REAR R.H SIDE	TATA spare parts
399028083260	SKIRT PANEL REAR L.H SIDE	TATA spare parts
399028083261	SKIRT PANEL L.H SIDE	TATA spare parts
399028083262	STRETCH PANEL L.H SIDE	TATA spare parts
399028083263	STRETCH PANEL DOOR L.H SIDE	TATA spare parts
399028083264	SKIRT PANEL FRONT LH	TATA spare parts
399028083265	L ANGLE¿ AT SLB	TATA spare parts
399028083266	SKIRT PANEL RH MIDDLE	TATA spare parts
399028083267	SKIRT PANEL RH MIDDLE	TATA spare parts
399028083268	SKIRT PANEL AT BATTERY BOX	TATA spare parts
399028083269	STRETCH PANEL EMER DOOR RH	TATA spare parts
399028083270	SKIRT PANEL RH REAR -EMER DOOR PANEL	TATA spare parts
399028083271	SKIRT PANEL LH MIDDLE-AT SPARE WHEEL	TATA spare parts
399028083274	A PILLER PANEL LH SIDE.	TATA spare parts
399028083275	RVM PANEL PLATE LH SIDE.	TATA spare parts
399028083277	RVM PANEL PLATE RH SIDE	TATA spare parts
399028083290	SKIRT PANEL RH FRONT-8	TATA spare parts
399028083291	SKIRT PANEL RH MIDDLE	TATA spare parts
399028083292	SKIRT PANEL RH-2	TATA spare parts
399028083293	SKIRT PANEL RH MIDDLE	TATA spare parts
399028083295	SKIRT PANEL LH FRONT	TATA spare parts

399028083297	SKIRT PANEL RH REAR	TATA spare parts
399028083298	SKIRT PANEL L SECTION	TATA spare parts
399028083299	STRETCH PANEL LH	TATA spare parts
399028083301	SKIRT PANEL REAR LH SIDE	TATA spare parts
399028083303	SKIRT PANEL REAR LH SIDE2	TATA spare parts
399028083304	SKIRT PANEL REAR LH SIDE2	TATA spare parts
399028083305	SKIRT PANEL	TATA spare parts
399028083307	STRETCH PANEL R.H SIDE	TATA spare parts
399028083308	STRETCH PANEL R.H SIDE	TATA spare parts
399028083309	L ANGLE R.H SIDE	TATA spare parts
399028083310	SKIRT PANEL LH SIDE 2	TATA spare parts
399028083311	STRETCH PANEL L.H SIDE	TATA spare parts
399028083312	SKIRT PANEL MIDDLE R.H SIDE	TATA spare parts
399028083313	SKIRT PANEL 3 ON L.H SIDE	TATA spare parts
399028083314	SKIRT PANEL L.H SIDE	TATA spare parts
399028083315	SKIRT PANEL L.H SIDE	TATA spare parts
399028083316	SKIRT PANEL DOOR L.H SIDE	TATA spare parts
399028083318	SKIRT PANEL REAR R.H SIDE	TATA spare parts
399028083320	SKIRT PANEL AT SLB	TATA spare parts
399028083321	STRETCH PANEL	TATA spare parts
399028083322	SKIRT PANEL RH-2	TATA spare parts
399028083323	SKIRT PANEL RH REAR	TATA spare parts
399028083324	C SECTION	TATA spare parts
399028083325	SKIRT PANEL AT SLB	TATA spare parts
399028083327	SKIRT PANEL AT BATRY BOX	TATA spare parts
399028083328	STRETCH PANEL L.H SIDE	TATA spare parts
399028083329	SKIRT PANEL L.H SIDE-NEAR SLB	TATA spare parts
399028083330	SKIRT PANEL L.H WH FRONT	TATA spare parts
399028083331	SKIRT PANEL L.H WH REAR	TATA spare parts
399028083332	SKIRT PANEL FRONT LH	TATA spare parts
399028083333	SKIRT PANEL FRONT LH	TATA spare parts
399028083334	STRETCH PANEL R.H SIDE	TATA spare parts
399028083335	SKIRT PANEL FRONT RH	TATA spare parts
399028083336	SKIRT PANEL AT SLB	TATA spare parts
399028083337	SKIRT PANEL MIDDLE R.H SIDE	TATA spare parts
399028083338	SKIRT PANEL R.H WH REAR	TATA spare parts
399028083344	EXTERNAL PANNELING SUPPORT 1ST INNER	TATA spare parts
399028083345	A PILLAR EXTERNAL PANEL-LH SIDE	TATA spare parts
399028083346	A PILLAR EXTERNAL PANEL(RH-DRIVER-SIDE)	TATA spare parts
399028083361	STRTCH PANEL ON LH WITHOUT DRIVER DOOR	TATA spare parts
399028083362	EXTERNAL PANEL AT EMER DOOR	TATA spare parts
399028083363	SKIRT PANEL AT EMER DOOR	TATA spare parts
399028083364	STRETCH PANEL RH	TATA spare parts
399028083365	STRETCH PANEL RH AT END-980X570X0.65	TATA spare parts
399028083366	SKIRT PANEL FRONT LH	TATA spare parts
399028083367	SKIRT PANEL FRONT LH	TATA spare parts
399028083368	SKIRT PANEL L.H -WH FRONT	TATA spare parts

399028083369	SKIRT PANEL LH	TATA spare parts
399028083370	STRETCH PANEL	TATA spare parts
399028083372	STRETCH PANEL RH	TATA spare parts
399028083373	SKIRT PANEL REAR RH	TATA spare parts
399028083374	SKIRT PANEL	TATA spare parts
399028083375	SKIRT PANEL	TATA spare parts
399028083376	SKIRT PANEL	TATA spare parts
399028083391	SKIRT PANEL REAR RH SFC	TATA spare parts
399028083392	SKIRT PANEL REAR LH SFC	TATA spare parts
399028083393	STRETCH PANEL	TATA spare parts
399028083394	STRETCH PANEL LH	TATA spare parts
399028083395	SKIRT PANEL AT AIR INTAKE FLAP	TATA spare parts
399028083396	SKIRT PANEL LH FRONT-VAVE SLB	TATA spare parts
399028083398	STRETCH PANEL R.H SIDE WITHOUT EMER DOOR	TATA spare parts
399028083399	STRETCH PNL R.H SIDE-WIOUT EMER DOOR-34	TATA spare parts
399028083400	STRETCH PANEL R.H-WITOUT-EMER DOOR	TATA spare parts
399028083401	STRETCH PANEL FORNT	TATA spare parts
399028083402	STRETCH PANEL PEEP WINDOW	TATA spare parts
399028083403	SKIRT PANEL LH 1	TATA spare parts
399028083404	SKIRT PANEL LH 2	TATA spare parts
399028083410	SKIRT PANEL ON L.H SIDE 1	TATA spare parts
399028083411	SKIRT PANEL ON L.H SIDE 2	TATA spare parts
399028083414	STRETCH PANEL FRONT RH	TATA spare parts
399028083415	STRETCH PANEL FRONT LH	TATA spare parts
399028083427	STRETCH PANEL FRONT SIDE LH	TATA spare parts
399028083428	STRETCH PANEL RH SIDE	TATA spare parts
399028083429	EXTERNAL PANEL REAR RH	TATA spare parts
399028083430	PLNEL BELOW EMERGENCY EXIT	TATA spare parts
399028083435	SIDE PANEL ABOVE AIR FILTER LH	TATA spare parts
399028083438	STRETCH PANEL RH FRONT	TATA spare parts
399028083439	SKIRT PANEL FRONT RH	TATA spare parts
399028083440	STRETCH PANEL FRONT L.H SIDE	TATA spare parts
399028083442	SKIRT PANEL L.H SIDE	TATA spare parts
399028083444	SKIRT PANEL FRONT LH	TATA spare parts
399028083445	EXTERNAL PANELLING PLATE BETWEEN	TATA spare parts
399028083446	A PILLAR EXTERNAL PANEL	TATA spare parts
399028083455	EXT PANELLING SHEET	TATA spare parts
399028083456	SKIRT PANEL LH FRONT	TATA spare parts
399028083460	SKIRT PANEL FRONT LH	TATA spare parts
399028083461	SKIRT PANEL LH	TATA spare parts
399028083462	SKIRT PANEL LH RA FRONT	TATA spare parts
399028083463	SKIRT PANEL L.H -RA REAR	TATA spare parts
399028083464	SKIRT PANEL RH RA REAR	TATA spare parts
399028083465	SKIRT PANEL RH RA FRONT	TATA spare parts
399028083466	SKIRT PANEL RH FA REAR	TATA spare parts
399028083467	SKIRT PANEL RH FA FRONT	TATA spare parts
399028083468	STRETCH PANEL RH	TATA spare parts

399028083469	SKIRT PANEL R.H SIDE	TATA spare parts
399028083470	SKIRT PANEL AT BATTERY BOX	TATA spare parts
399028083480	SKIRT PANEL L.H SIDE	TATA spare parts
399028083481	SKIRT PANEL AT SLB	TATA spare parts
399028083482	SKIRT PANEL L.H SIDE	TATA spare parts
399028083483	SKIRT PANEL DOOR L.H SIDE	TATA spare parts
399028083484	SKIRT PANEL REAR LH SIDE	TATA spare parts
399028083485	STRETCH PANEL L.H SIDE	TATA spare parts
399028083486	STRETCH PANEL LH MIDDLE	TATA spare parts
399028083492	STRETCH PANEL LH FRONT	TATA spare parts
399028083494	SKIRT PANEL AT BATTERY BOX	TATA spare parts
399028083495	SKIRT PANEL AT AIR INTAKE FLAP	TATA spare parts
399028083508	STRETCH PNL R.H SIDE-38 VAVE	TATA spare parts
399028083509	STRETCH PANEL L.H SIDE-38 VAVE	TATA spare parts
399028083523	STRETCH PANEL LH MIDDLE 840X3772X.65	TATA spare parts
399028083524	SKIRT PANEL DOOR L.H SIDE 467X492X.95	TATA spare parts
399028083525	SKIRT PANEL REAR LH SIDE 806X492X0.95	TATA spare parts
399028083526	STRETCH PANEL L.H SIDE 801X840X0.65	TATA spare parts
399028083527	SKIRT PANEL FRONT LH-38-VAVE-LHD	TATA spare parts
399028083528	SKIRT PANEL L.H SIDE-LHD	TATA spare parts
399028083531	SKIRT PANEL AT DOOR FRONT LHD-38	TATA spare parts
399028083532	SKIRT PANEL R.H SIDE-LHD FRONT WHL FRONT	TATA spare parts
399028083533	SKIRT PANEL AT DOOR	TATA spare parts
399028083535	STRETCH PANEL RH LC LCV	TATA spare parts
399028083537	SIDE EXT PANEL_LP31_LHD_LH	TATA spare parts
399028083538	SIDE EXT PANEL_LP31_LHD_RH	TATA spare parts
399028083539	SKIRT PNEL L.H SIDE-LHD-BN WHL&AIR_LP31	TATA spare parts
399028083540	SKIRT PANEL R.H -WH REAR 31 VAVE	TATA spare parts
399028083541	SKIRT PANEL L.H -WH REAR-31 VAVE	TATA spare parts
399028083542	SKIRT PANEL R.H -WH FRONT-31 VAVE	TATA spare parts
399028083543	PLNEL BELOW EMERGENCY EXIT_LP31_LHD	TATA spare parts
399028083557	MIDDLE SKIRT PANEL RIGHT SIDE	TATA spare parts
399028083558	SKIRT PANEL REAR WHEEL ARC RH	TATA spare parts
399028083560	SKIRT PANEL RH FRONT	TATA spare parts
399028083561	SKIRT PANEL AT BATTERY BOX	TATA spare parts
399028083562	SKIRT PANEL LH REAR	TATA spare parts
399028083563	SKIRT PANEL RH REAR	TATA spare parts
399028083565	SKIRT PANEL RH MIDDLE EI(MC) 38WB	TATA spare parts
399028083566	SKIRT PANEL LH FRONT EI(MC)	TATA spare parts
399028083567	SKIRT PANEL LH MIDDLE EI(MC)	TATA spare parts
399028083568	EXT REVETMENT PLATE	TATA spare parts
399028083576	SKIRT PANEL L.H WH FRONT	TATA spare parts
399028083577	SKIRT PANEL L.H SIDE	TATA spare parts
399028083578	SKIRT PANEL L.H SIDE	TATA spare parts
399028083579	SIDE PANEL RH	TATA spare parts
399028083589	STRETCH PANEL FRONT L.H SIDE	TATA spare parts
399028083593	STRETCH PANEL LH SIDE 34	TATA spare parts

399028083600	SIDE EXTERNAL PANELLING	TATA spare parts
399028083602	SKIRT PANEL RH SIDE	TATA spare parts
399028083603	SKIRT PANEL AT BATTERY BOX	TATA spare parts
399028083604	SIDE SKIRT PANEL	TATA spare parts
399028083605	STRETCH PANEL L.H SIDE	TATA spare parts
399028083606	STRETCH PANEL L.H SIDE	TATA spare parts
399028083607	SKIRT PANEL REAR L.H SIDE	TATA spare parts
399028083608	SKIRT PANEL REAR L.H SIDE	TATA spare parts
399028083609	SKIRT PANEL	TATA spare parts
399028083610	STRETCH PANEL	TATA spare parts
399028083612	SKIRT PANEL REAR	TATA spare parts
399028083613	EXTERNAL PANEL ON WINDOWS TUBE	TATA spare parts
399028083624	DRIVER DOOR BOTTOM PANEL	TATA spare parts
399028083625	SKIRT PANEL RH WH	TATA spare parts
399028083628	SKIRT PANEL RH FRONT	TATA spare parts
399028083629	SKIRT PANEL RH FRONT	TATA spare parts
399028083630	SKIRT PANEL LH FRONT	TATA spare parts
399028083631	SKIRT PANEL LH FRONT	TATA spare parts
399028083634	SKIRT PANEL MIDDLE R.H SIDE	TATA spare parts
399028083635	SKIRT PANEL RH WH REAR	TATA spare parts
399028083636	SKIRT PANEL LH WH REAR	TATA spare parts
399028083638	SKIRT PANEL FRONT LH	TATA spare parts
399028083652	SKIRT PANEL MIDDLE RH SIDE	TATA spare parts
399028083653	SKIRT PANEL REAR RH SIDE	TATA spare parts
399028083654	SKIRT PANEL 3 ON LH SIDE	TATA spare parts
399028083655	SKIRT PANEL L.H SIDE	TATA spare parts
399028083656	SKIRT PANEL FRONT LH	TATA spare parts
399028083657	SKIRT PANEL LH SIDE	TATA spare parts
399028083658	SKIRT PANEL PANEL LH SIDE	TATA spare parts
399028083659	SKIRT PANEL MIDDLE RH SIDE	TATA spare parts
399028083660	SKIRT PANEL REAR RH SIDE	TATA spare parts
399028083661	SKIRT PANEL REAR LH SIDE	TATA spare parts
399028083663	SKIRT PANEL LH SIDE	TATA spare parts
399028083665	SKIRT PANEL REAR LH SIDE	TATA spare parts
399028083667	SKIRT PANEL L.H SIDE BS6	TATA spare parts
399028083678	DOOR CANOPY FOR 750 DOOR	TATA spare parts
399028083683	SKIRT PANEL LH SIDE	TATA spare parts
399028083686	STRETCH PANEL DOOR LH SIDE	TATA spare parts
399028083687	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
399028083688	EXT PANEL BESIDE PASS DOOR	TATA spare parts
399028083698	EXT PANELLING SHEET	TATA spare parts
399028083699	SKIRT PANEL FRONT LH	TATA spare parts
399028083700	SKIRT PANEL RH WH REAR	TATA spare parts
399028083701	SKIRT PANEL MIDDLE RH SIDE	TATA spare parts
399028083729	STRETCH PANEL LH-29WB	TATA spare parts
399028083739	SKIRT PANEL LH SIDE	TATA spare parts
399028083740	SHIRT PANEL FRONT RH 42WB	TATA spare parts

399028083742	SKIRT PANEL LH SIDE 34WB	TATA spare parts
399028083743	SKIRT PANEL RH-REAR WIH EME.CUT	TATA spare parts
399028083744	SKIRT PANEL FRONT RH DRIVER FOOTSTEP	TATA spare parts
399028083745	SKIRT PANEL MIDDLE RH	TATA spare parts
399028083746	SKIRT PANEL LH REAR	TATA spare parts
399028083763	EXT PANEL PASSENGER DOOR	TATA spare parts
399028083764	SKIRT PANEL LH FRONT	TATA spare parts
399028083765	SKIRT PANEL FRONT	TATA spare parts
399028083767	STRETCH PANEL RH SIDE	TATA spare parts
399028083769	SKIRT PANEL REAR EME	TATA spare parts
399028083775	SKIRT PANEL FRONT LH	TATA spare parts
399028083777	FRONT RH PANEL	TATA spare parts
399028083778	STRECTCH PANEL LH FRONT	TATA spare parts
399028083780	PANEL ON LH A PILLAR	TATA spare parts
399028083781	A PILLAR EXTERNAL PANEL	TATA spare parts
399028083782	SKIRT PANEL FRONT RH	TATA spare parts
399028083789	SKIRT PANEL LH SIDE NEAR DOOR (42WB)	TATA spare parts
399028083794	SKIRT PANEL FRONT RH	TATA spare parts
399028083795	SKIRT PANEL FRONT RH	TATA spare parts
399028083799	EXT PANELLING SHEET	TATA spare parts
399028083802	DRIVER SIDE FINISHING L-SECTION	TATA spare parts
399028083803	SIDE EXT PANEL ABOVE DRIVER DOOR(ARAI)	TATA spare parts
399028083804	SIDE EXT PANEL ABOVE CO DRIVER	TATA spare parts
399028083805	SKIRT PANEL LH-SIDE 49 WB	TATA spare parts
399028083806	SKIRT PANEL FRONT LH	TATA spare parts
399028083807	EXTERNAL PANEL ON WINDOWS TUBE	TATA spare parts
399028083810	WINDOW PILLAR PANEL	TATA spare parts
399028083812	WINDOW PILLAR PANEL	TATA spare parts
399028083813	WINDOW PILLAR PANEL	TATA spare parts
399028083814	WINDOW PILLAR PANEL	TATA spare parts
399028083815	WINDOW PILLAR PANEL	TATA spare parts
399028083816	WINDOW PILLAR PANEL	TATA spare parts
399028083817	WINDOW PILLAR PANEL	TATA spare parts
399028083818	WINDOW PILLAR PANEL	TATA spare parts
399028083819	WINDOW PILLAR PANEL	TATA spare parts
399028083820	WINDOW PILLAR PANEL	TATA spare parts
399028083821	WINDOW PILLAR PANEL	TATA spare parts
399028083823	SKIRT PANEL LH SIDE BETWEEN WB	TATA spare parts
399028083824	SKIRT PANEL FRONT OF DOOR	TATA spare parts
399028083825	SKIRT PANEL DOOR LH SIDE	TATA spare parts
399028083826	SKIRT PANEL LH SIDE - 42WB NEW	TATA spare parts
399028083831	WINDOW PILLAR PANEL	TATA spare parts
399028083833	EXTERNAL PANEL ON ED	TATA spare parts
399028083834	STRETCH PANEL RH SIDE AT REAR	TATA spare parts
399028083837	EXTERNAL PANEL ON ED DOOR LP712	TATA spare parts
399028083839	STRETCH PANEL RH SIDE	TATA spare parts
399028083847	STRETCHPANELR.HSIDE-34	TATA spare parts

399028083849	EXT PANEL	TATA spare parts
399028083850	DRIVER SIDE WINDOW PANEL	TATA spare parts
399028083851	WINDOW PILLAR PANEL	TATA spare parts
399028083852	WINDOW PILLAR PANEL	TATA spare parts
399028083853	WINDOW PILLAR PANEL	TATA spare parts
399028083854	WINDOW PILLAR PANEL	TATA spare parts
399028083855	WINDOW PILLAR PANEL	TATA spare parts
399028083856	WINDOW PILLAR PANEL IB	TATA spare parts
399028083857	EXTERNAL PANEL ON ED EX	TATA spare parts
399028083858	SKIRT PANEL REAR LH SIDE	TATA spare parts
399028083859	SKIRT PANEL MIDDLE LH SIDE	TATA spare parts
399028083860	SKIRT PANEL FRONT LH SIDE	TATA spare parts
399028083861	SKIRT PANEL FRONT RH	TATA spare parts
399028083862	SKIRT PANEL REAR RH SIDE	TATA spare parts
399028083863	SKIRT PANEL MIDDLE RH SIDE A	TATA spare parts
399028083867	SKIRT PANEL MIDDLE RH SIDE B	TATA spare parts
399028083873	SKIRT PANEL FRONT RH SIDE	TATA spare parts
399028083877	SKIRT PANEL R.H SIDE-LHD FRONT WHL FRONT	TATA spare parts
399028083878	SKIRT PANEL L-PROFILE	TATA spare parts
399028083879	SKIRT PANEL L-PROFILE	TATA spare parts
399028083896	STRETCH PNL R.H-34WB	TATA spare parts
399028083898	STRETCH PANEL BELOW EME DOOR 34WB	TATA spare parts
399028083904	STRETCH PANEL L.H SIDE-34 PASTED GLASS	TATA spare parts
399028083905	STRETCH PNL R.H SIDE-34WB_ PASTED GLASS	TATA spare parts
399028083907	STRETCH PANEL L.H SIDE	TATA spare parts
399028083908	STRETCH PANEL R.H SIDE	TATA spare parts
399028083911	STRETCH PANEL R.H SIDE	TATA spare parts
399028083912	STRETCH PANEL L.H SIDE	TATA spare parts
399028083913	SKIRTPANELR.H-REARE34WB-EME-CUTOUT	TATA spare parts
399028083915	SKIRT PANEL REAR R.H SID_42WB-EME-CUTOUT	TATA spare parts
399028083916	SKIRT PANEL REAR R.H SID_49WB-EME-CUTOUT	TATA spare parts
399028083917	STRETCH PANEL L.H SIDE	TATA spare parts
399028083922	EXTERNAL PANEL ON WINDOW TUBE EX	TATA spare parts
399028083923	SIDE EXTERNAL PANEL ON WINDOWS 42EX	TATA spare parts
399028083925	SKIRT PANEL RH -WH REAR 31WB	TATA spare parts
399028083926	EXTERNAL PANEL OVER PASSENGER DOOR -EX	TATA spare parts
399028083931	SKIRT PANEL MIDDLE R.H SIDE	TATA spare parts
399028083935	STRETCH PANEL R.H REAR SIDE	TATA spare parts
399028083936	STRETCH PANEL FRONT L.H SIDE	TATA spare parts
399028083937	SKIRT PANEL RH	TATA spare parts
399028083954	WINDOWPILLARPANEL	TATA spare parts
399028083955	WINDOW PILLAR PANEL	TATA spare parts
399028083965	SKIRT OANEL FRONT RH SIDE	TATA spare parts
399028083966	SKIRT PANEL REAR R.H SIDE	TATA spare parts
399028083967	SKIRT PANEL	TATA spare parts
399028083968	SKIRT PANEL MIDDLE	TATA spare parts
399028083971	SKIRT PANEL MIDDLE LH SIDE 49EX	TATA spare parts

399028083972	SKIRT PANEL MIDDLE RH SIDE	TATA spare parts
399028083974	STRETCH PANEL RH SIDE 775X6380	TATA spare parts
399028083975	STRETCH PANEL RH SIDE 775X7480	TATA spare parts
399028083978	SIDE WINDOW PANEL 155	TATA spare parts
399028083980	STRETCHPNLR.HSIDE-34WB	TATA spare parts
399028083981	STRETCH PNL R.H SIDE-34WB	TATA spare parts
399028083982	WINDOWPILLARPANELEMEDOOR	TATA spare parts
399028083983	EXTERNAL PANEL PASSY STEP	TATA spare parts
399028083984	SKIRT PANEL AT BATRY BOX 650	TATA spare parts
399028083985	SKIRT PANEL R.H -WH REAR CUTOUT	TATA spare parts
399028083986	STRETCH PANEL RH SIDE	TATA spare parts
399028083987	WINDOW PILLAR PANEL	TATA spare parts
399028083988	FRONT STRETCH PANEL RH SIDE	TATA spare parts
399028083990	FRONT LH PANEL LHD	TATA spare parts
399028083992	SIDE EXTERNAL PANEL ABOVE DRIVER DOOR	TATA spare parts
399028083993	SKIRTPANELMIDDLER.HSIDE	TATA spare parts
399028083996	STRETCH PANEL L.H SIDE	TATA spare parts
399028083997	STRECTCH PANEL LH FRONT	TATA spare parts
399028083998	SKIRT PANEL REAR LH SIDE	TATA spare parts
399028083999	WINDOW PILLAR PANEL	TATA spare parts
399028084005	WINDOW PILLAR PANEL	TATA spare parts
399028084006	SKIRT PANEL	TATA spare parts
399028084007	SKIRT PANEL REAR RH SIDE	TATA spare parts
399028084011	SKIRT PANEL FRONT	TATA spare parts
399028084012	SKIRT PANEL MIDDLE R.H SIDE	TATA spare parts
399028084013	SKIRT PANEL MIDDLE R.H SIDE 38 VAVE	TATA spare parts
399028084014	SKIRT PANEL R.H -WH REAR 38VAVE	TATA spare parts
399028084015	SKIRT PANEL RH	TATA spare parts
399028084016	SKIRT PANEL LH REAR	TATA spare parts
399028084017	SKIRT PANEL LH FRONT	TATA spare parts
399028084018	SKIRT PANEL R.H FRONT	TATA spare parts
399028084019	SKIRT PANEL RH	TATA spare parts
399028084021	WINDOWPILLAR&STRETCHPANELR.HSIDE	TATA spare parts
399028084023	SKIRT PANEL FRONT LH.	TATA spare parts
399028084024	SKIRT PANEL R.H SIDE	TATA spare parts
399028084028	STRETCH PANEL L.H SIDE-34WB	TATA spare parts
399028084029	STRETCH PANEL FRONT L.H SIDE	TATA spare parts
399028084031	STRETCH PANEL L.H SIDE	TATA spare parts
399028084032	STRETCH PANEL R.H SIDE	TATA spare parts
399028084033	STRETCH PANEL R.H SIDE	TATA spare parts
399028084034	STRETCH PANEL 3195	TATA spare parts
399028084037	SKIRT PANEL 1245	TATA spare parts
399028084038	SKIRT PANEL 1251	TATA spare parts
399028084039	SKIRT PANEL REAR RH 4SPCR	TATA spare parts
399028084040	SKIRT PANEL REAR LH 4SPCR	TATA spare parts
399028084046	SKIRT PANEL	TATA spare parts
399028084047	SKIRT PANEL	TATA spare parts



399028084048	SKIRT PANEL	TATA spare parts
399028084049	SKIRT PANEL	TATA spare parts
399028084050	STRETCH PANEL	TATA spare parts
399028084051	STRETCH PANEL	TATA spare parts
399028084052	STRETCH PANEL	TATA spare parts
399028084053	SKIRT PANEL	TATA spare parts
399028084054	SKIRT PANEL FRONT	TATA spare parts
399028084055	SKIRT PANEL	TATA spare parts
399028084056	SKIRT PANEL REAR	TATA spare parts
399028084057	SKIRT PANEL RH FRONT	TATA spare parts
399028084058	SKIRT PANEL RH REAR	TATA spare parts
399028084065	STRETCH PANEL FRONT L.H SIDE	TATA spare parts
399028084068	WINDOW PILLAR & STRETCH PANEL R.H SIDE	TATA spare parts
399028084074	SKIRT PANEL RH SIDE_LHD_REAR	TATA spare parts
399028084075	SKIRT PANEL BETWEEN FLAPS_LHD	TATA spare parts
399028084076	EXTERNAL PANEL ON EME DOOR_1	TATA spare parts
399028084077	EXTERNAL PANEL ON EME DOOR_2	TATA spare parts
399028084080	L ANGLE R.H SIDE	TATA spare parts
399028084082	STRETCH PANEL FRONT L.H SIDE	TATA spare parts
399028084084	SKIRTPANEL.HSIDE49WBSKL	TATA spare parts
399028084086	STRETCH PANEL FRONT PEEP WINDOW	TATA spare parts
399028084087	STRETCH PANEL FRONT L.H SIDE	TATA spare parts
399028084088	SKIRT PANEL R.H SIDE IB	TATA spare parts
399028084092	SKIRT PANEL R.H SIDE IB	TATA spare parts
399028084093	SKIRT PANEL L.H SIDE IB	TATA spare parts
399028084094	SKIRT PANEL RH REAR IB	TATA spare parts
399028084095	SKIRT PANEL LH REAR IB	TATA spare parts
399028084096	SKIRT PANEL AT SLB IB	TATA spare parts
399028084101	STRETCH PNL R.H SIDE-38 VAVE	TATA spare parts
399028084102	STRETCH PNL R.H SIDE-34WB	TATA spare parts
399028084103	STRETCH PNL R.H SIDE-34WB	TATA spare parts
399028084104	STRETCH PANEL R.H SIDE	TATA spare parts
399028084108	STRETCH PANEL FRONT L.H SIDE	TATA spare parts
399028084114	DRIVER SIDE WINDOW PANEL EX	TATA spare parts
399028084123	CO-DRIVER EXTERNAL PANEL-2	TATA spare parts
399028084124	FINISHING PROFILE	TATA spare parts
399028084125	FINISHING PROFILE	TATA spare parts
399028084130	STRETCH PANEL FRONT PEEP WINDOW_STD	TATA spare parts
399028084131	SKIRT PANEL FRONT LH	TATA spare parts
399028084132	SKIRT PANEL REAR R.H SIDE	TATA spare parts
399028084133	STRETCH PANEL LH	TATA spare parts
399028084136	SKIRT PANEL L.H -WH REAR	TATA spare parts
399028084137	STRETCH PANEL L.H SIDE-29WB	TATA spare parts
399028084138	SKIRT PANEL R.H -WH REAR	TATA spare parts
399028084139	STRETCH PANEL R.H SIDE-29WB	TATA spare parts
399028084140	WINDOW PILLAR & STRETCH PANEL R.H SIDE	TATA spare parts
399028084141	EXTERNAL PANEL-REAR RH SIDE	TATA spare parts

399028084143	SKIRT PANEL FRONT LH	TATA spare parts
399028084144	SKIRT PANEL L.H -WH FRONT	TATA spare parts
399028084146	SKIRT PANEL REAR R.H SIDE	TATA spare parts
399028084147	STRETCH PANEL R.H SIDE	TATA spare parts
399028084148	STRETCH PANEL R.H REAR SIDE	TATA spare parts
399028084155	GI- FINISHING PROFILE - DRIVER DOOR	TATA spare parts
399028084156	GI-FINISHING PROFILE - EX DRIVER DOOR	TATA spare parts
399028084157	GI FINISHING PROFILE -	TATA spare parts
399028084163	RH MIDDLE PANNEL WITH FUEL TANK CUTOUT	TATA spare parts
399028084173	CO-DRIVER EXTERNAL PANEL	TATA spare parts
399028084174	FRONT STRETCH PANEL RH SIDE	TATA spare parts
399028084203	SKIRT PANEL MIDDLE R.H SIDE IB	TATA spare parts
399028183007	SIDE SKIRT PANEL¿ BATTERY SIDE LH	TATA spare parts
399028183008	SIDE SKIRT PANEL¿ ABOVE BATTERY LH	TATA spare parts
399028183010	SIDE SKIRT PANEL	TATA spare parts
399028183011	SIDE SKIRT PANEL C-SEC	TATA spare parts
399028183015	SIDE SKIRT PANEL REAR WHEEL SIDE RH	TATA spare parts
399028183016	SKIRT PANEL FRONT RH	TATA spare parts
399028183017	SKIRT PANEL FRONT LH	TATA spare parts
399028183018	SKIRT PANEL R.H -WH REAR	TATA spare parts
399028183019	SKIRT PANEL L.H -WH REAR	TATA spare parts
399028183020	SKIRT PANEL FRONT LH	TATA spare parts
399028183021	SKIRT PANEL - RH SIDE	TATA spare parts
399028183022	SIDE SKIRT PANEL REAR WHEEL SIDE LH	TATA spare parts
399028183023	SKIRT PANEL - RH SIDE	TATA spare parts
399028183024	SIDE SKIRT PANEL C-SEC	TATA spare parts
399028183066	EME DOOR FINISHING PROFILE_560LG	TATA spare parts
399028183067	EME DOOR FINISHING PROFILE_430LG	TATA spare parts
399028183068	EME DOOR FINISHING PROFILE_300LG	TATA spare parts
399028183069	EME DOOR FINISHING PROFILE_770LG	TATA spare parts
399028183071	PASSENGER DOOR FINISHING PROFILE_1350LG	TATA spare parts
399028183072	EME DOOR FINISHING PROFILE	TATA spare parts
399028183073	PASS DOOR FINISHING PROFILE	TATA spare parts
399028183074	EME DOOR FINISHING PROFILE	TATA spare parts
399028183075	PASS DOOR FINISHING PROFILE	TATA spare parts
399028183078	DOOR FINISHING PROFILE RH 650	TATA spare parts
399028183079	DOOR FINISHING PROFILE_LH_650	TATA spare parts
399028183080	DOOR FINISHING PROFILE 884	TATA spare parts
399028183084	PASS DOOR FINISHING PROFILE	TATA spare parts
399028183085	EME DOOR FINISHING PROFILE	TATA spare parts
399028183088	AL SKIRT PANEL LH FRONT	TATA spare parts
399028183089	AL SKIRT PANEL FRONT LH	TATA spare parts
399028183090	AL SKIRT PANEL AT DOOR-38	TATA spare parts
399028183091	AL SKIRT PANEL L.H -WH REAR 38VAVE	TATA spare parts
399028183092	AL SKIRT PANEL L.H	TATA spare parts
399028183093	AL SKIRT PANEL R.H -WH REAR 38VAVE	TATA spare parts
399028183094	AL SKIRT PANEL MIDDLE R.H SIDE	TATA spare parts

399028183095	AL SKIRT PANEL R.H SIDE	TATA spare parts
399028183096	AL SKIRT PANEL R.H FRONT	TATA spare parts
399028184001	WINDOW PILLAR & STRETCH PANEL R.H SIDE	TATA spare parts
399028213006	ALUMINUM PROFILE (DRIVER DOOR FINISHING	TATA spare parts
399028213019	FRONT SHOW RHS RAIN CHANNEL	TATA spare parts
399028213020	EXTERNAL FINISHING PROFILE RH FRONT	TATA spare parts
399028213021	EXTERNAL FINISHING PROFILE LH REAR	TATA spare parts
399028213022	EXTERNAL FINISHING PROFILE RH REAR	TATA spare parts
399028213034	EXTERNAL FINISHING PROFILE LH FRONT	TATA spare parts
399028213035	EXTERNAL FINISHING PROFILE RH FRONT	TATA spare parts
399028213036	EXTERNAL FINISHING PROFILE LH REAR	TATA spare parts
399028213037	EXTERNAL FINISHING PROFILE RH REAR	TATA spare parts
399028213043	REAR RAIN GUTTER-LH	TATA spare parts
399028213044	REAR RAIN GUTTER-RH	TATA spare parts
399028213045	FRONT RAIN GUTTER LH	TATA spare parts
399028213046	FRONT RAIN GUTTER RH	TATA spare parts
399028263002	LHD DRIVER FOOT STEP	TATA spare parts
399028263003	FRP DRIVER FOOT STEP	TATA spare parts
399028264001	FRP FOOT STEP-RHD	TATA spare parts
399028284001	TANK DOOR RUBBER JAMB	TATA spare parts
399028912035	SIDE PANELLING ASY-EURO-2-ANALYSYS	TATA spare parts
399028912055	SIDE EXT PANLIG ASY EMER..DOR-34 CNG	TATA spare parts
399029002007	FLAP FOR FUSE BOX ASSEMBLY OPT 2 RHD	TATA spare parts
399029002008	FRONT BUMPER(CENTER)	TATA spare parts
399029003001	FUEL TANK NOZZLE MAINTENANCE COVER ASSY	TATA spare parts
399029003005	INSPECTION COVERS	TATA spare parts
399029003008	ELECTRIC BOX CLOSING COVER ASSY	TATA spare parts
399029003010	GEAR BOX CUT OUT-49WB	TATA spare parts
399029003011	GEAR BOX MAINTENANCE COVER	TATA spare parts
399029003012	TOOL BOX ASSEMBLY	TATA spare parts
399029003014	ELECTRICAL BOX CLOSING COVER-RHD	TATA spare parts
399029003015	FUSE BOX FLAP	TATA spare parts
399029003017	INSPECTION COVER GEAR BOX CUTOOUT	TATA spare parts
399029003018	GEAR BOX INSPECTION COVER ASSY	TATA spare parts
399029003025	SERVICE COVER	TATA spare parts
399029003026	SPARE WHEEL INSPECTION COVER	TATA spare parts
399029003027	GEAR BOX CUT-OUT ASSY	TATA spare parts
399029003032	INSPECTION COVER FOR GEAR BOX	TATA spare parts
399029003046	SPARE WHEEL INSPECTION COVER	TATA spare parts
399029003067	GEAR BOX CUT-OUT ASSY	TATA spare parts
399029004002	FUSE BOX COVER ( SMALL )	TATA spare parts
399029004020	ELECTRICAL BOX CLOSING COVER ASSY-RHD	TATA spare parts
399029083002	FUSE BOX MOUNTING L PLATE	TATA spare parts
399029083003	L PLATE FOR FIXING ELECTRIC COMPONENTS	TATA spare parts
399029084002	L-PLATE FOR LOCKING (TOOL BOX ASSY)	TATA spare parts
399029084005	FLOOR COVER FINISHING	TATA spare parts
399029085001	TOOL BOX CAP FINISHING PPGI PROFILE 0.65	TATA spare parts

399029085002	L-CLAMP FOR TOOL BOX GI 1.95X30X50MM	TATA spare parts
399029085004	ELECTRICAL BOX CLOSING PLATE-RHD	TATA spare parts
399029085007	TOOLBOX CAP FINISHING PROFILE 15X15X0.65	TATA spare parts
399029085008	TOOL BOX LOCK SUPPORT PLATE	TATA spare parts
399029183043	CHEQ PLATE 383X705X2.2	TATA spare parts
399029183044	CHEQ PLATE 255X402X2.2	TATA spare parts
399029243043	PLYWOOD FOR INSPECTION COVER-1	TATA spare parts
399029243044	PLYWOOD FOR INSPECTION COVER-2	TATA spare parts
399029284001	INSPECTION COVER SEALING PROFILE	TATA spare parts
399029284004	INSPECTION COVER SEALING PROFILE	TATA spare parts
399029284006	INSPECTION COVER SEALING PROFILE	TATA spare parts
399029284007	INSPECTION COVER SEALING PROFILE	TATA spare parts
399029284010	INSPECTION COVER SEALING PROFILE	TATA spare parts
399029303004	MAGNET LOCK	TATA spare parts
399029303006	DRAIN PLUG	TATA spare parts
399029304001	FUEL LEVEL FLOAT MAINTENANCE COVER	TATA spare parts
399029304002	FUEL LEVEL FLOAT MAINTENANCE COVER	TATA spare parts
399029912021	VINYL FLOOR-38 WB	TATA spare parts
399029912039	INSPECTION COVER ASSY	TATA spare parts
399029912066	SPARE WHEEL SERVICE COVER RUBBER PROFILE	TATA spare parts
399030003044	DOCTOR FOLD.SEAT MTG BKT_ARMY AMBULANC	TATA spare parts
399030003059	REAR WHEEL HOUSING BANJO AXLE BS6	TATA spare parts
399035002009	TATA ACE AL CHUQUERED FITMENT ASSEMBLY B	TATA spare parts
399035003006	TATA ACE FOLDABLE SEAT_LEG SUPPORT_CVG B	TATA spare parts
399035003016	FLAP SUPPORT CHAIN ASSY BS6	TATA spare parts
399035003017	VELCROW BS6	TATA spare parts
399035004001	HEAVY DUTY HINGE ASSLY BS6	TATA spare parts
399035004003	REAR TOP OPENING FLAP ASSLY BS6	TATA spare parts
399035004004	DISTRIBUTION DOOR ASSLY BS6	TATA spare parts
399035004005	REAR BOTTOM OPENING FLAP ASSLY BS6	TATA spare parts
399035004006	CASH BOX BS6	TATA spare parts
399035004007	GRAIN WEIGHING SCALE BS6	TATA spare parts
399035004010	LH SIDE LOADING DOOR ASSLY BS6	TATA spare parts
399035005001	RH GAS PISTON HOLDER FOR SLB FLAP ASSY B	TATA spare parts
399035005003	REAR TOP FLAP STR BS6	TATA spare parts
399035005004	DISTRUBUTION DOOR STR BS6	TATA spare parts
399035005005	LOADING DOOR STR BS6	TATA spare parts
399035005006	REAR BOTTOM FLAP STR BS6	TATA spare parts
399035006001	CHAIN 4MM THICK _ 200KG CAPACITY BS6	TATA spare parts
399035006002	TOWER BOLT 5 BS6	TATA spare parts
399035006006	NOTICE BOARD 450X450 WHITE BS6	TATA spare parts
399035006007	SS WEIGHING BIN MUG BS6	TATA spare parts
399035015006	TUBE 40X20X140MM BS6	TATA spare parts
399035076001	LIFTING HOOK BS6	TATA spare parts
399035083001	TOP LH SIDE PANEL BS6	TATA spare parts
399035084027	BOTTOM PANEL REAR BS6	TATA spare parts
399035084028	ROOF EXT PANEL BS6	TATA spare parts

399035084029	REAR TOP PANEL BS6	TATA spare parts
399035084030	LH SIDE FRONT PANEL BS6	TATA spare parts
399035084031	FRONT PANEL BS6	TATA spare parts
399035084032	RH SIDE FRONT PANEL BS6	TATA spare parts
399035084033	RH SIDE REAR PANEL BS6	TATA spare parts
399035084037	LH SIDE MID PANEL BS6	TATA spare parts
399035084038	LH SIDE SMALL DOOR BOTTOM BS6	TATA spare parts
399035084039	LH SIDE BIG DOOR BOTTOM BS6	TATA spare parts
399035084041	LH SIDE DIST DOOR FINISHER BS6	TATA spare parts
399035084042	REAR RH SIDE CORNER PANEL BS6	TATA spare parts
399035084043	REAR TOP CANOPY PANEL BS6	TATA spare parts
399035085003	REAR TOP FLAP PANEL BS6	TATA spare parts
399035085004	DISTRIBUTION DOOR PANEL BS6	TATA spare parts
399035085005	LOADING DOOR ASSLY BS6	TATA spare parts
399035085006	REAR BOTTOM FLAP PANEL BS6	TATA spare parts
399035085020	LAMP BRACKET BS6	TATA spare parts
399035086010	LIFT HOOK BRACKET BS6	TATA spare parts
399035086012	J HOOK BS6	TATA spare parts
399035183003	AL.CHUQUERED PLATE560X1300X2.2MM BS6	TATA spare parts
399035185001	L PALTE 2MMX63X1300 BS6	TATA spare parts
399035266002	FRP WIND DEFLECTOR COVER BS6	TATA spare parts
399035335001	POUCH FOR TICKETING MACHINE BS6	TATA spare parts
399035363001	SWITCH HARNESS TATA ACE BS6	TATA spare parts
399035363002	CONTAINER HARNESS TATA ACE BS6	TATA spare parts
399035363003	SPEAKER EXTENSION CABLE_ACE BS6	TATA spare parts
399035363004	MIC EXTENSION CABLE_ACE BS6	TATA spare parts
399035363005	MIC CONNECTING CABLE WITH BRACKET_ACE BS	TATA spare parts
399035363006	AC SOCKET PIGTAIL_ACE BS6	TATA spare parts
399035373001	AMPLIFIER FOR PA SYSTEM (150*150*60)_ACE	TATA spare parts
399035373002	SPEAKER SIREN (10W)_ACE BS6	TATA spare parts
399035373003	MIC 60M_ACE BS6	TATA spare parts
399035373004	INTERNAL LAMP SWITCH_ACE BS6	TATA spare parts
399035373005	EXTERNAL LAMP SWITCH_ACE BS6	TATA spare parts
399035963001	TATA ACE DECAL_RH 01_1094X1800 BS6	TATA spare parts
399035963002	TATA ACE DECAL_RH 02_1110X1800 BS6	TATA spare parts
399035963003	TATA ACE DECAL_LH 01_85X1800 BS6	TATA spare parts
399035963004	TATA ACE DECAL_LH 02_1085X1800 BS6	TATA spare parts
399035963005	TATA ACE DECAL_LH 03_360X1800 BS6	TATA spare parts
399035963006	TATA ACE DECAL_LH 04_635X1800 BS6	TATA spare parts
399035963007	TATA ACE DECAL_LH 05_45X1800 BS6	TATA spare parts
399035963008	TATA ACE DECAL KIT PART BS6	TATA spare parts
399035963009	TATA ACE DECAL_REAR 01 BS6	TATA spare parts
399035963011	TATA ACE DECAL_REAR 03 BS6	TATA spare parts
399035963013	TATA ACE DECAL_DEFLECTOR LH-SIDE BS6	TATA spare parts
399035963014	TATA ACE DECAL_DEFLECTOR RH-SIDE BS6	TATA spare parts
399035963015	TATA ACE DECAL_DEFLECTOR FRONT-SIDE BS6	TATA spare parts
399035963016	TATA ACE DECAL_LH DOOR 1 BS6	TATA spare parts

399035963017	TATA ACE DECAL_ RH DOOR 1 BS6	TATA spare parts
399035963018	TATA ACE DECAL_ CABIN LH-SIDE BS6	TATA spare parts
399035963019	TATA ACE DECAL_ CABIN RH-SIDE BS6	TATA spare parts
399035963020	TATA ACE DECAL_ CABIN FRONT-01 BS6	TATA spare parts
399035963021	TATA ACE DECAL_ CABIN FRONT-02 BS6	TATA spare parts
399035963022	TATA ACE DECAL_ CABIN FRONT-03 BS6	TATA spare parts
399035966001	SIDE FLAP LOCK BS6	TATA spare parts
399035966003	RUBBER MAT 4X 1387X 2130MM BS6	TATA spare parts
399036002001	AMB REAR DOOR FITMENT APP 1473X1496	TATA spare parts
399036003004	XENON AMBULANCE CONDENSOR ASSY	TATA spare parts
399036003005	XENON AMBULANCE EVAPORATOR ASSY	TATA spare parts
399036003006	XENON AMBULANCE EVAPORATOR COVER ASSY	TATA spare parts
399036003009	FOLDABLE STEP WITH PANEL ASSY	TATA spare parts
399036003011	AMB REAR CATCHER DOOR ASSY	TATA spare parts
399036003019	AMB REAR DOOR SS HANDLE	TATA spare parts
399036003020	AMB REAR LOCK SIDE DOOR EXT PANEL	TATA spare parts
399036004001	FOLDABLE STEP FRAME ASSY BS6	TATA spare parts
399036083013	AMB CATCHER DOOR INT PANEL	TATA spare parts
399036083014	AMB REAR LOCK DOOR INTERNAL PANEL	TATA spare parts
399036083015	AMB CATCHER DOOR INTERNAL PANEL	TATA spare parts
399036083016	AMB LOCK DOOR INTARNAL APNEL	TATA spare parts
399036083017	AMB LOCK DOOR TOP INTERNAL PANEL	TATA spare parts
399036083019	AMB TOWER BOLT BKT INTERNAL PANEL	TATA spare parts
399036083020	AMB CATCHER DOOR TOP INTERNAL PANEL	TATA spare parts
399036083021	AMB TOWER BOLT BKT INTERNAL PANEL	TATA spare parts
399036083022	AMB LOCK DOOR INTARNAL APNEL	TATA spare parts
399036084005	FOLDABLE STEP HOLDING BKT	TATA spare parts
399036184001	AL CHEQUERED PLATE_ BOTTOM BS6	TATA spare parts
399036184002	AL CHEQUERED PLATE_ TOP BS6	TATA spare parts
399036263001	AMB LOCK CATCHER COVER	TATA spare parts
399040003005	TWIN SEATER RH	TATA spare parts
399040003006	TWIN SEATER LH	TATA spare parts
399040003007	TWIN SEATER RH WITH ARM REST	TATA spare parts
399040003008	CO DRIVER SEAT WITH ARM REST	TATA spare parts
399040003009	R.H.SIDE TWIN SEATER	TATA spare parts
399040003010	L.H.SIDE TWIN SEATER WITHOUT LAP BELT	TATA spare parts
399040003011	R.H. SIDE REAR TWIN SEATER	TATA spare parts
399040003012	L.H. SIDE REAR TWIN SEATER	TATA spare parts
399040003013	RH SIDE TWIN SEATER ON WHEEL ARCH	TATA spare parts
399040003014	CO-DRIVER SEAT	TATA spare parts
399040003015	DRIVER SEAT	TATA spare parts
399040003018	RH REAR TWIN SEATER (12DEG)	TATA spare parts
399040003019	LH REAR TWIN SEATER (12DEG)	TATA spare parts
399040003026	TWIN SEATER RH WITH ARM REST	TATA spare parts
399040003027	TWIN SEATER RH	TATA spare parts
399040003028	TWIN SEATER LH	TATA spare parts
399040003029	REAR TWIN SEATER RH	TATA spare parts

399040003030	REAR TWIN SEATER LH	TATA spare parts
399040003031	REAR MIDDLE SINGLE SEATER	TATA spare parts
399040003032	CO DRIVER SEAT WITH ARM REST	TATA spare parts
399040003033	LH SIDE TWIN SEATER ON WHEEL ARCH	TATA spare parts
399040003034	RH SIDE REAR TWIN SEATER	TATA spare parts
399040003035	LH SIDE REAR TWIN SEATER	TATA spare parts
399040003036	REAR SINGLE SEATER	TATA spare parts
399040003037	CO DRIVER SEAT	TATA spare parts
399040003038	TWIN SEATER RH WITH ARM REST	TATA spare parts
399040003039	TWIN SEATER RH	TATA spare parts
399040003040	TWIN SEATER LH	TATA spare parts
399040003041	REAR TWIN SEATER LH	TATA spare parts
399040003042	REAR TWIN SEATER RH	TATA spare parts
399040003043	REAR SINGLE SEATER	TATA spare parts
399040003044	CO-DRIVER RH SEAT_ARM REST LHD	TATA spare parts
399040003045	LH TWIN SEATER_ARM REST LHD	TATA spare parts
399040003048	RH TWIN SEATER_A REST(850WIDTH)	TATA spare parts
399040003049	RH TWIN SEATER (850WIDTH)	TATA spare parts
399040003050	LH TWIN SEATER (850WIDTH)	TATA spare parts
399040003051	RH REAR TWIN SEATER (620)	TATA spare parts
399040003052	LH REAR TWIN SEATER (620)	TATA spare parts
399040003053	REAR MIDDLE SINGLE SEATER(620)	TATA spare parts
399040003054	CO-DRIVER LH SEAT_ARM REST (620)	TATA spare parts
399040003055	R.H.SIDE TWIN SEATER	TATA spare parts
399040003056	L.H.SIDE TWIN SEATER	TATA spare parts
399040003060	CO DRIVER RH SEAT_ARM REST(2TONE)	TATA spare parts
399040003061	REAR 5 SEAT_ON RLB_MID LAP BELT	TATA spare parts
399040003062	REAR 5 SEAT_ON RLB_ALL LAP BELT	TATA spare parts
399040003064	RH TWIN SEAT_ARM REST(810W)	TATA spare parts
399040003065	RH TWIN SEATER JUMP SEAT	TATA spare parts
399040003071	CO-DRIVER LH SEAT_LAP BELT	TATA spare parts
399040003072	RH SIDE TWIN SEATER	TATA spare parts
399040003073	L.H.TWIN SEATER	TATA spare parts
399040003074	RH TWINSEAT WITH ARMREST LAPBELT(SKOOL)	TATA spare parts
399040003075	R.H. SIDE REAR TWIN SEATER	TATA spare parts
399040003076	L.H.REAR TWIN SEATER	TATA spare parts
399040003077	MIDDLE SINGLE SEAT_LAP BELT	TATA spare parts
399040003078	RH TWIN SEATER_WHEEL ARCH	TATA spare parts
399040003079	LH TWIN SEATER_WHEEL ARCH	TATA spare parts
399040003080	CO-DRIVER LH SEAT	TATA spare parts
399040003084	R.H. SIDE TWIN SEATER WITHOUT LAP BELT	TATA spare parts
399040003085	SAFETY LAP BELT ASSEMBLY	TATA spare parts
399040003086	PASSENGER SEAT	TATA spare parts
399040003087	PASSENGER SEAT	TATA spare parts
399040003088	PASSENGER SEAT	TATA spare parts
399040003089	PASSENGER SEAT	TATA spare parts
399040003090	PASSENGER SEAT	TATA spare parts

399040003091	CO- SEAT	TATA spare parts
399040003093	LH TWIN SEATER_850MM WITH AR	TATA spare parts
399040003094	RH REAR TWIN SEATER LAP BELT	TATA spare parts
399040003095	LH REAR TWIN SEATER LAP BELT	TATA spare parts
399040003096	REAR MID 1 SEATER_LAP BELT	TATA spare parts
399040003097	SEAT	TATA spare parts
399040003098	REAR PASSENGER SEAT	TATA spare parts
399040003099	RH TWIN SEATER A REST LAP BELT (¿ HB)	TATA spare parts
399040003100	RH TWIN SEATER LAP BELT (¿ HB 620MM)	TATA spare parts
399040003101	LH TWIN SEATER LAP BELT (¿ HB 620MM)	TATA spare parts
399040003102	RH REAR TWIN SEATER_LAP BELT (VSPL_HB)	TATA spare parts
399040003103	LH REAR TWIN SEATER_LAP BELT (VSPL_HB)	TATA spare parts
399040003104	REAR MID SINGLE SEATER_LAP BELT	TATA spare parts
399040003105	RH CO-DRIVER SEAT	TATA spare parts
399040003106	RH 2 SEAT	TATA spare parts
399040003107	LH 2 SEAT	TATA spare parts
399040003108	LH 3 SEAT	TATA spare parts
399040003109	REAR 3 SEAT	TATA spare parts
399040003111	LH 1 SEAT_ARM REST ON RH SIDE	TATA spare parts
399040003117	2 SEAT_890W_RH ARM REST_2LEG_UJJAIN¿ SEA	TATA spare parts
399040003121	2 SEAT_890W_LH ARM REST_2LEG_UJJAIN	TATA spare parts
399040003127	RETRACTABLE DRI SEAT BELT_ELECTR SENSOR	TATA spare parts
399040003128	RH 2SEAT 890W_LH AR_SBM_LB PLASTIC	TATA spare parts
399040003129	RH 2SEAT 890W_LH AR_SBM PLASTIC	TATA spare parts
399040003130	LH 1SEAT 455W RH AR SBM PLASTIC	TATA spare parts
399040003131	LH 1SEAT 455W RH AR SBM ON WA PLASTI SEA	TATA spare parts
399040003132	LH CO-DRI SEAT_2 LEGS_400SW_AR_PLAS	TATA spare parts
399040003133	RH 2 SEATER 810MM SW_AR_VSPL PLASTIC	TATA spare parts
399040003134	LH 2 SEATER 810MM SW_AR_VSPL PLASTIC	TATA spare parts
399040003135	REAR 5 SEATER_RLB_ALL LAP BELTS	TATA spare parts
399040003136	REAR 5 SEATER_RLB_MID LAP BELTS	TATA spare parts
399040003137	LH 2 SEATER_720LEG MOUNT PITCH	TATA spare parts
399040003140	LH 2 SEAT 450CH810W SM1L AR LB 2T¿¿ IB	TATA spare parts
399040003141	LH 2 SEAT 450CH810W SM1L LB 2T	TATA spare parts
399040003142	RH 2 SEAT 450CH810W SM1L LB 2T¿¿ IB	TATA spare parts
399040003144	MID REAR 1 SEAT_400W_2SM_LB_2T_TJC IB	TATA spare parts
399040003146	CO-DRIVER SEAT RH_AR)_2 TONE	TATA spare parts
399040003147	RH TWIN SEATER_A REST_LAP BELT	TATA spare parts
399040003148	RH TWIN SEATER WITH LAP BELT	TATA spare parts
399040003149	LH TWIN SEATER WITH LAP BELT	TATA spare parts
399040003150	RH 2 SEATER_2 LEGS (HB_850W)	TATA spare parts
399040003151	RH REAR 2 SEATER_2 LEGS SYMETRIC	TATA spare parts
399040003152	LH REAR 2 SEATER_2 LEGS SYMETRIC	TATA spare parts
399040003153	RH 2 SEATER_2 LEGS (VSPL_HB_850W)	TATA spare parts
399040003154	RH REAR 2 SEATER_2 LEGS SYMETRIC	TATA spare parts
399040003155	LH REAR 2 SEATER_2 LEGS SYMETRIC	TATA spare parts
399040003156	RH 2 SEATER_2 LEGS	TATA spare parts



399040003157	RH REAR 3 SEATER_3 LEGS	TATA spare parts
399040003158	RH 2 SEATER_2 LEGS	TATA spare parts
399040003159	RH REAR 2 SEATER_2 LEGS	TATA spare parts
399040003160	PASSENGER SEAT	TATA spare parts
399040003161	PASSENGER SEAT	TATA spare parts
399040003162	PASSENGER SEAT	TATA spare parts
399040003163	PASSENGER SEAT	TATA spare parts
399040003164	PASSENGER SEAT	TATA spare parts
399040003165	PASSENGER SEAT	TATA spare parts
399040003166	PASSENGER SEAT	TATA spare parts
399040003167	PASSENGER SEAT	TATA spare parts
399040003168	PASSENGER SEAT	TATA spare parts
399040003178	LH 2 SEAT LP_JUMP SEAT(810W)	TATA spare parts
399040003179	RH TWIN SEAT 800W 19DT AR&C CITYRIDE	TATA spare parts
399040003180	H TWIN SEAT_800W_19DT CITYRIDE	TATA spare parts
399040003181	RH TWIN SEAT_800W_19DT_ CITYRIDE	TATA spare parts
399040003182	CO-DRI SEAT LH AR 400W 19DT&C CITYRID	TATA spare parts
399040003183	RH REAR TWIN SEAT_800W_10DT_VSPL CITYRID	TATA spare parts
399040003184	LH REAR TWIN SEAT 800W 10DT&C CITYRID	TATA spare parts
399040003185	REAR MID 1 SEAT_400W_10DT_VSPL CITYRIDE	TATA spare parts
399040003186	RH 2 SEATER 2LM AR LB&C SKOOL	TATA spare parts
399040003187	RH 2 SEATER SM1L AR LB WA&C SKOOL	TATA spare parts
399040003188	RH REAR 3 SEATER SM2L LB&C SKOOL	TATA spare parts
399040003189	LH 2 SEATER SM1L AR LB&C SKOOL	TATA spare parts
399040003190	LH 2 SEATER SM1L AR LB WA&C SKOOL	TATA spare parts
399040003191	LH REAR 2 SEATER SM1L LB&C SKOOL	TATA spare parts
399040003217	CO-DRIVER RH SEAT_AR_2L_PLASTIC	TATA spare parts
399040003218	RH 1 SEAT_460CH_SM1L_PLASTIC	TATA spare parts
399040003220	RH 1 SEAT_460CH_2L_PLASTIC	TATA spare parts
399040003221	REAR 2 SEAT_DICKEY_PLASTIC	TATA spare parts
399040003222	LH 2 SEAT_460CH_SM1L_PLASTIC	TATA spare parts
399040003223	RH 2 SEAT_SM1L_AR LB BH_850W	TATA spare parts
399040003224	RH 2 SEAT_SM1L_LB BH_850W	TATA spare parts
399040003225	RH 2 SEAT_2L_LB BH_850W	TATA spare parts
399040003226	LH 2 SEAT_SM1L_LB BH_850W	TATA spare parts
399040003233	LH 2 SEAT(C 513 810W) L BELT JUMP SEAT	TATA spare parts
399040003237	LH 2 SEAT_SM1L_AR_850W_FPS SKL	TATA spare parts
399040003244	RH 2 SEAT RECL 1AR SM1L BLUE	TATA spare parts
399040003245	RH 2 SEAT RECL 1AR 2L BLUE	TATA spare parts
399040003246	LH 2 SEAT RECL 1AR SM1L BLUE	TATA spare parts
399040003251	RH 2 SEAT_SM1L_LB BH_850W	TATA spare parts
399040003252	LH 2 SEAT_SM1L_LB BH_850W	TATA spare parts
399040003256	RH 2 SEAT TYPE-2 HB SM1L	TATA spare parts
399040003258	REAR MID 1 SEAT TYPE-2 HB	TATA spare parts
399040003260	LH 2 SEAT TYPE-2 HB SM1L	TATA spare parts
399040003261	LH 1 SEAT(COD) TYPE-2 HB 2L AR	TATA spare parts
399040003269	LH 2 SEAT JUMP 450CH810W SM1L 2T&C IB	TATA spare parts

399040003270	RH 2 SEATER_2 TONE	TATA spare parts
399040003272	RH 2 SEAT RR_450CH810W_SM1L_2T	TATA spare parts
399040003273	MID REAR 1 SEAT_400W_2SM_2T	TATA spare parts
399040003274	LH 2 SEAT RR_450CH810W_SM1L_2T	TATA spare parts
399040003276	LH 2 SEAT 2 TONE	TATA spare parts
399040003277	RH TWIN SEATER (FPS_HB_850WIDTH)	TATA spare parts
399040003278	LH TWIN SEATER (FPS_HB_850WIDTH)	TATA spare parts
399040003279	RH 2 SEATER_2 LEGS (FPS_HB_850W)	TATA spare parts
399040003280	RH TWIN SEATER_A REST(FPS_HB_850WIDTH)	TATA spare parts
399040003281	CO-DRIVER LH SEAT_ARM REST (FPS_HB_620)	TATA spare parts
399040003282	RH REAR 2 SEATER 2 LEGS SYMETRIC(FPS HB)	TATA spare parts
399040003283	LH REAR 2 SEATER_2 LEGS SYMETRIC(FPS_HB)	TATA spare parts
399040003284	REAR MIDDLE SINGLE SEATER(FPS_HB_620))	TATA spare parts
399040003299	RH 2 SEAT_450CH810W_SM1L_AR_2T_FP IB	TATA spare parts
399040003300	REAR 5 SEAT ON RLB ALL LB 2T& IB	TATA spare parts
399040003301	RH 2 SEAT_450CH810W_SM1L_2T_FP IB	TATA spare parts
399040003302	RH 2 SEAT RR_450CH810W_SM1L_2T_FP IB	TATA spare parts
399040003303	LH 2 SEAT_450CH810W_SM1L_AR_2T_FP IB	TATA spare parts
399040003308	RH 2 SEAT_450CH810W_SM1L_AR_2T	TATA spare parts
399040003309	CO-DRIVER SEAT LH_400W_2LM_AR_2T	TATA spare parts
399040003310	LH 1 SEATER_450 CH_SMILG_TJC	TATA spare parts
399040003311	LH 1 SEATER WH SMILG TJC	TATA spare parts
399040003312	LH 1 SEATER_450 CH_SMILG_VSPL	TATA spare parts
399040003313	LH 1 SEATER_WH_SMILG_VSPL	TATA spare parts
399040003314	LH REAR 2 SEAT_2LM BH LB	TATA spare parts
399040003315	RH REAR 2 SEAT_2LM BH LB	TATA spare parts
399040003321	RH 2 HB SEAT SM1L 850W380D465CH	TATA spare parts
399040003322	LH 2 HB SEAT SM1L 850W380D465CH	TATA spare parts
399040003323	RH 2 HB SEAT SM1L AR 850W380D465CH	TATA spare parts
399040003324	CO DRIVER HB SEAT LH 400W ARM REST	TATA spare parts
399040003325	RH REAR 2SEAT HB SM1L 810W380D465CH	TATA spare parts
399040003326	LH REAR 2SEAT HB SM1L 810W380D465CH	TATA spare parts
399040003327	MID REAR 1 SEAT HB NL 400W380D465CH	TATA spare parts
399040003328	RH REAR 2 SEAT HB_SM1L_810W380D465CH_FPS	TATA spare parts
399040003329	LH 2 SEATER_AR_2 TONE	TATA spare parts
399040003330	LH REAR 2 SEAT HB_SM1L_810W380D465CH_FPS	TATA spare parts
399040003331	LH 2 SEAT_450CH810W_SM1L_2T_FP IB	TATA spare parts
399040003332	REAR 5 SEAT_RLB_MIDSEAT LB2TONE	TATA spare parts
399040003333	LH 2 SEAT RR_450CH810W_SM1L_2T_FP IB	TATA spare parts
399040003334	RH 2 SEAT_460CH_SM1L_PLASTIC	TATA spare parts
399040003335	RH 1 SEAT 335CH 2L WH PLASTIC	TATA spare parts
399040003336	RH 2 SEAT 450CH810W SM1L AR LB 2T	TATA spare parts
399040003337	CO-DRIVER SEAT LH_AR_(TJC_513)_2 TONE	TATA spare parts
399040003341	REAR 5 SEAT_ON RLB_MID LB_2T_FP IB	TATA spare parts
399040003342	CO-DRIVER SEAT RH_400W_2LM_AR_2T_FP IB	TATA spare parts
399040003351	CO-DRIVER SEAT LH_400W_2LM_AR_2T_FP IB	TATA spare parts
399040003354	RH 2SEAT_460CH_850W/O AR_2LM_PLSTC	TATA spare parts

399040003355	RH 2SEAT_460CH_SM1L_850W/O AR_PLSC	TATA spare parts
399040003356	LH 2SEAT_460CH_SM1L_850W/O AR_PLSC	TATA spare parts
399040003357	RH RR 3SEAT450CH1230W3LM1LBSKL	TATA spare parts
399040003358	REAR MID 1SEAT_460CH_400 W_2LM_PLTC(VSPL	TATA spare parts
399040003368	LH REAR 2 SEATERSM1L SKOOL	TATA spare parts
399040003389	RH 2 SEATER AR 2LG 850W PMS	TATA spare parts
399040003400	RH 2 SEAT_SM1L_AR BH_850W_VSPL HB	TATA spare parts
399040003401	RH 2 SEAT_SM1L_BH_850W_HB	TATA spare parts
399040003402	RH 2 SEAT_SM1L_BH_850W_WH	TATA spare parts
399040003403	RH 2 SEAT_2LG_BH_850W_HB	TATA spare parts
399040003404	LH 2 SEAT_SM1L_BH_850W	TATA spare parts
399040003405	LH 2 SEAT_SM1L_BH_850W_WH	TATA spare parts
399040003406	LH REAR 2 SEAT_2LM BH	TATA spare parts
399040003407	RH REAR 2 SEAT_2LM BH	TATA spare parts
399040003409	RH 2 ST_460CH_850W_2LM_PMS_VSPL_W/O CU	TATA spare parts
399040003413	RR MID 1ST_400W_2LM_LB_PMS_VSPL_W/O CU	TATA spare parts
399040003422	RH COD ST_2LG_450W_AR_PMS_VSPL_W/O CUS	TATA spare parts
399040003433	RH 2 SEAT 800W ECO SKL	TATA spare parts
399040003434	RH 2 SEAT 800 WH ECO SKL	TATA spare parts
399040003435	RH 2 SEAT 800W 2LG ECO SKL	TATA spare parts
399040003436	REAR RH2SEAT 800W 2LG ECO SKL	TATA spare parts
399040003437	REAR MID SEAT LB 400W ECO SKL	TATA spare parts
399040003438	REAR LH 2 SEAT 800W ECO SKL	TATA spare parts
399040003439	LH 2 SEAT 800W ECO SKL	TATA spare parts
399040003440	LH 2 SEAT 800W WH ECO SKL	TATA spare parts
399040003441	CO-DRI SEAT LH AR 400W ECO SKL	TATA spare parts
399040003443	LH 1SEAT 455W_RH_SBM_VSPL PLASTIC	TATA spare parts
399040003444	LH 1SEAT 455W RH SBM WH PLASTIC	TATA spare parts
399040003445	RH 2 SEAT AR 850W ECO SKL	TATA spare parts
399040003447	LH RR 2 SEAT_800W_10DT_2LG_CR	TATA spare parts
399040003448	LH 2 SEAT_800W_19DT_WH_2LG_CR	TATA spare parts
399040003449	CO-DRI SEAT RH_AR_400W_19DT_VSPL CITYRID	TATA spare parts
399040003457	RH 2 SEAT_AR_B.FAB_HB_900W_SM1LG_	TATA spare parts
399040003458	RH 2 SEAT_B.FAB_HB_850W_SM1LG_	TATA spare parts
399040003459	RR RH2 SEAT_B.FAB_HB_850W_SM1LG	TATA spare parts
399040003460	RR MID SEAT_B.FAB_HB_400W_VSPL	TATA spare parts
399040003461	RR LH 2 SEAT_B.FAB_HB_850W_SM1LG	TATA spare parts
399040003462	LH 2 SEAT_B.FAB_HB_850W_SM1LG	TATA spare parts
399040003463	CO-DRI SEAT_B.FAB_HB_2LG_VSPL	TATA spare parts
399040003474	REAR MID 1SEAT_400W_AR_LB_VSPL_PMS	TATA spare parts
399040003478	RH 1 SEAT 460CH SM1L PLASTIC	TATA spare parts
399040003481	LH 2 SEAT 460CH SM1L PLASTIC	TATA spare parts
399040003482	COD SEAT LH AR 400W 400CH¿¿ CITYRID	TATA spare parts
399040003545	1 SEAT_2ARM REST_2LM_460CH_(620)	TATA spare parts
399040003553	RH 2 SEAT 420CH SM1SL AR 800W LC	TATA spare parts
399040003554	RH 2 SEAT 420CH SM1SL 800W LC	TATA spare parts
399040003555	REAR 2 SEATER ONRLB BENCH SEATER LC	TATA spare parts

399040003556	LH 2 SEAT 420CH SM1SL 800W LC	TATA spare parts
399040003557	LH 1 SEAT 450CH 2LM AR 400W LC	TATA spare parts
399040003558	RH 2 SEAT PB SM1L 1025W 3AR LB 1T LCV	TATA spare parts
399040003559	RH 2 SEAT PB REAR 1025W 3AR LB 1T LCV	TATA spare parts
399040003560	LH 2 SEAT PB REAR 990W 3AR LB 1T LCV	TATA spare parts
399040003561	LH 1 SEAT PB SM1L 550W 2AR LB 1T LCV	TATA spare parts
399040003562	LH 1 SEAT 550W 360CH 3AR LB WH 1T	TATA spare parts
399040003563	CO DIVER LH SEAT HB	TATA spare parts
399040003570	REAR MID SEAT LB 400W ONRLB LC	TATA spare parts
399040003580	REAR LH 2 SEATER 450CH W/O BH 800W	TATA spare parts
399040003581	REAR RH 2 SEATER 450CH W/O BH 800W	TATA spare parts
399040003582	RH 2 SEATER 450CH W/O BH 800W	TATA spare parts
399040003583	LH 2 SEATER 450CH W/O BH 800W	TATA spare parts
399040003584	RH 2 SEATER 450CH WH AR W/O BH 800W	TATA spare parts
399040003585	RH 2 SEAT_AR_2L_866W_465CH_PMS_HSSL	TATA spare parts
399040003586	RH 2 SEAT_2L_866W_465CH_PMS_HSSL	TATA spare parts
399040003587	LH 2 SEAT_AR_1LB_2L_866W_465CH_PMS_HSSL	TATA spare parts
399040003588	LH 1 SEAT_2L_465CH_PMS_HSSL	TATA spare parts
399040003589	LH 1 SEAT_AR_2L_465CH_PMS_HSSL	TATA spare parts
399040003590	RH 1 SEAT 335CH 2L WH PLASTIC	TATA spare parts
399040003596	LH 1 SEAT 350CH 2LM WH PMS CVG	TATA spare parts
399040003597	LH 2 SEATER AR 2LG 850W PMS CVG	TATA spare parts
399040003607	RH 2 SEAT 450CH760W SM1L AR 2T CVG	TATA spare parts
399040003608	RH TWIN SEAT	TATA spare parts
399040003609	RH 2 SEAT RR 450CH810W SM1L 2T CVG	TATA spare parts
399040003610	MID REAR 1 SEAT 400W 2SM 2T CVG	TATA spare parts
399040003611	LH 2 SEAT RR 450CH810W SM1L 2T CVG	TATA spare parts
399040003613	CO-DRIVER SEAT LH 400W 2LM AR 2T CVG	TATA spare parts
399040003619	RH 2 SEATER 810MM SW AR FAB	TATA spare parts
399040003624	LH 1SEAT 330W RH SBM WH FAB	TATA spare parts
399040003625	LH 1SEAT 455W RH SBM FAB	TATA spare parts
399040003633	LH TWIN SEATER SEAT	TATA spare parts
399040003634	LH TWIN SEATER A REST LAP BELT (JC HB)	TATA spare parts
399040003659	RH 3 SEAT_950MM_SM2L_AR LB BH_PSPL_LCV	TATA spare parts
399040003660	RH 3 SEAT_950MM_SM2L_BH_PSPL_LCV	TATA spare parts
399040003661	LH 2 SEATER_760MM_SM1L_BH_PSPL_LCV	TATA spare parts
399040003662	RH 3 SEAT_950MM_SM2L_BH_WA_PSPL_LCV	TATA spare parts
399040003663	LH 2 SEAT_760MM_SM1L_BH_WA_PSPL_LCV	TATA spare parts
399040003665	RH 3 SEAT 1050MM SM2L AR LB BH	TATA spare parts
399040003666	RH 3 SEAT 1050MM SM2L BH	TATA spare parts
399040003667	LH 2 SEATER 700MM SM1L BH	TATA spare parts
399040003668	RH 3 SEAT 1050MM SM2L BH WA	TATA spare parts
399040003669	LH 2 SEAT 700MM SM1L BH WA	TATA spare parts
399040003670	RH 3 SEAT 1050MM 3LM AR BH ED	TATA spare parts
399040003680	BENCH SEAT AR 1000X300MM 3LM	TATA spare parts
399040003681	RH 3 SEAT 1050MM 3LM BH NO GH	TATA spare parts
399040003682	LH 3 SEAT 1050MM 3LM BH NO GH	TATA spare parts

399040003718	COD RH 1 SEAT RH 2L AR PLASTIC	TATA spare parts
399040003735	RR SEAT 2000MM 4LM LP BENCH SEAT	TATA spare parts
399040003736	RR SEAT_2000MM_4LM_LP_BENCH_SEAT_PSPL	TATA spare parts
399040003737	RR RH 2 SEATER SIDE MOUNTING 1 LEG MOUNT	TATA spare parts
399040003768	LH 2SEAT 850W 510CH SM1LM HB1	TATA spare parts
399040003769	RH 2SEAT 850W 510CH SM1LM HB1	TATA spare parts
399040003772	LH_2SEAT_SM1L_PMS_AR_LB_REXINE_CVG	TATA spare parts
399040003774	2SEAT ASSY_RHS_850W_510CH	TATA spare parts
399040003776	2SEAT ASSY_LHS_850W_510CH	TATA spare parts
399040003787	RH REAR 2 SEAT 2LM LBç HB	TATA spare parts
399040003788	LH REAR 2 SEAT 2LM LBç HB	TATA spare parts
399040003792	REAR 5 SEATER RLB MID LB TYPE 2 VSPL HB	TATA spare parts
399040003802	LH 2 SEAT_760MM_SM1L_TUBULAR BH_WA_FPS	TATA spare parts
399040003804	RH 2 SEAT_760MM_SM1L_AR_LB_BH_SKL_PSPL	TATA spare parts
399040003807	RH 2 SEAT 760MM SM1L AR LB BH SKL	TATA spare parts
399040003808	RH 2 SEAT 760MM SM1L BH SKL	TATA spare parts
399040003809	RH 2 SEAT 7600MM SM1L BH WA SKL	TATA spare parts
399040003810	RH 2ST 2LM 450C760W BH SKL TM	TATA spare parts
399040003812	RH 2 SEAT_760MM_SM1L_BH_AR_SKL_CVG	TATA spare parts
399040003814	RH 2 SEATER_760MM_SM1L_BH_WH_AR_CVG_L	TATA spare parts
399040003816	LH 2 SEAT_760MM_SM1L_BH_AR_SKL_CVG	TATA spare parts
399040003818	LH 2 SEATER_760MM_SM1L_BH_WH_AR_CVG_L	TATA spare parts
399040003821	RR SEAT_2000_4LM_LP_BENCH_TBH_SEAT_FPS	TATA spare parts
399040003825	RH 2 SEAT 760MM SIDE MOUNT 1LEG AR LB TB	TATA spare parts
399040003826	RH 2 SEAT 760MM SIDE MOUNT 1LEG TUBELAR	TATA spare parts
399040003827	LH 2 SEATER_450CH_760W_SM1L_TUBE BH_FPS	TATA spare parts
399040003828	RH 2 SEAT 760MM SIDE MOUNT 1LEG TUB BH W	TATA spare parts
399040003837	LH 2 SEATER_450CH_760W_SM1L_TUBE BH_HSS	TATA spare parts
399040003838	LH 2 SEAT_760MM_SM1L_TUBULAR BH_WA_HSS	TATA spare parts
399040003839	RR SEAT_2000_4LM_LP_BENCH_TBH_SEAT_HSSL	TATA spare parts
399040003840	RH 2 SEATç SIDE MOUNT 1LEG 760MM AR LB T	TATA spare parts
399040003841	RH 2 SEAT SIDE MOUNT 1LEG 760MM TUBELAR	TATA spare parts
399040003842	RH 2 SEAT SIDE MOUNT 1LEG 7600MMç TUB BH	TATA spare parts
399040003843	RH 3 SEAT_950MM_SM2L_AR_LB_TUB BH_HSSL	TATA spare parts
399040003844	RH 3 SEAT_950MM_SM2L_TUBULAR BH_HSSL	TATA spare parts
399040003845	RH 3 SEAT_950MM_SM2L_TUBULAR BH_WA_HSS	TATA spare parts
399040003853	RH 2SEAT 850W 510CH SM1LM HB2 AR	TATA spare parts
399040003855	RH REAR 2 SEAT TYPE-2 HB 2L	TATA spare parts
399040003857	LH REAR 2 SEAT TYPE-2 HB 2L	TATA spare parts
399040003859	RH 2SEAT 850W 510CH SM1LM WH HB	TATA spare parts
399040003860	LH 2SEAT 850W 510CH SM1LM WH HB	TATA spare parts
399040003865	RH 2SEAT 850W 510CH SM1LM AR HB	TATA spare parts
399040003867	RH 2SEAT 850W 510CH SIDE MOUNT 1 LEG MOU	TATA spare parts
399040003869	REAR MID 1 SEATER LAP BELT	TATA spare parts
399040003873	RH3SEATSIDEMOUNT2LEGMOUNT	TATA spare parts
399040003874	RH 3SEAT 950MM SM2L BH WA(BANJO)ç SKL	TATA spare parts
399040003876	RH 3SEAT_950MM_SM2L_BH_WA(BANJO)_HSSL	TATA spare parts

399040003877	REAR MID SEAT_LB_400W_JC ECO_SKL	TATA spare parts
399040003878	REAR LH 2 SEATER 450CH W/O_BH 800W JC	TATA spare parts
399040003879	REAR RH 2 SEATER 450CH W/O_BH 800W JC	TATA spare parts
399040003880	RH 2 SEATER 450CH W/O_BH 800W JC	TATA spare parts
399040003881	LH 2 SEATER 450CH W/O_BH 800W JC	TATA spare parts
399040003882	RH 2 SEATER 450CH WH_AR W/O_BH 800W JC	TATA spare parts
399040003883	LH 1 SEAT_450CH_2LM_AR_400W_JC	TATA spare parts
399040003900	LH 2ST SM1L 450CH850W BEFORE WA HB2 CVG	TATA spare parts
399040003902	RH 2ST SM1L 510CH850W AR HB2 HSSL	TATA spare parts
399040003903	RH 2ST SM1L 450CH850W HB2 HSSL	TATA spare parts
399040003904	LH 1ST(COD) 2LM 430CH400W AR HB2 HSSL	TATA spare parts
399040003908	LH 2 SEAT TYPE-2 HB SM1L HSSL	TATA spare parts
399040003909	RH 2ST SM1L 450CH850W BEFORE WA HB2 CVG	TATA spare parts
399040003910	LH 2ST SM1L 450CH850W BEFORE WA HB1 CVG	TATA spare parts
399040003911	RH 2ST SM1L 450CH850W BEFORE WA HB1 CVG	TATA spare parts
399040003913	RH 1ST 2LEG MOUNT 465CH 410W PMS PSPL	TATA spare parts
399040003925	LH 2ST SM1L 485CH850W BEFORE WA HB2 HSSL	TATA spare parts
399040003926	RH 2ST SM1L 485CH850W BEFORE WA HB2 HSSL	TATA spare parts
399040003927	1CL 2LM 460C410W AR HB1 TM	TATA spare parts
399040003928	3RH SM2L 450C950W AR LB BH SKL TM	TATA spare parts
399040003929	3RH SM2L 450C950W BH SKL TM	TATA spare parts
399040003930	2LH SM1L 450C760W BH SKL TM	TATA spare parts
399040003931	2LH SM1L 320C760W WA BH SKL TM	TATA spare parts
399040003932	RR ST 4LM 450C2000W LB BH SKL TM	TATA spare parts
399040003933	3LEGMOUNT¿450C950WWBH SKLTM	TATA spare parts
399040003934	2RH SM1L 450C760W AR LB BH SKL TM	TATA spare parts
399040003935	2RH SM1L 450C760W BH SKL TM	TATA spare parts
399040003936	2RH SM1L 320C760W WA BH SKL TM	TATA spare parts
399040003952	LH 2ST SM1L 450CH850W BEFORE WA HB1 HSSL	TATA spare parts
399040003953	RH 2ST SM1L 450CH850W BEFORE WA HB1 HSSL	TATA spare parts
399040003962	RH 3 SEAT_950MM_3LM NEAR.ED_BH_CVG_LCV	TATA spare parts
399040003963	RH 2 SEAT 760W 2LEG MOUNT NEAR ED	TATA spare parts
399040003968	LH 2ST SM1L 450CH850W BEFORE WA NHB1 CVG	TATA spare parts
399040003969	RH 2ST SM1L 450CH850W BEFORE WA NHB1 CVG	TATA spare parts
399040003970	RH 2ST 2LEG MOUNT 450C760W ED BH	TATA spare parts
399040003971	RH 3ST 3LM 450C950W ED BH SKL HSSL	TATA spare parts
399040003974	CODRIVERLH1SEATER2LEGMOUNT	TATA spare parts
399040003975	RH2SEATERSIDEMOUNT1LEGMOUNT	TATA spare parts
399040003976	RH 2 SEATER SIDE MOUNTING 1 LEG MOUNT	TATA spare parts
399040003977	LH 2 SEATER SIDE MOUNTING 1 LEG MOUNT	TATA spare parts
399040003978	RR MIDDLE 1 SEATER 2 LEG MOUNT	TATA spare parts
399040003979	RRRH2SEATER2LEGMOUNT	TATA spare parts
399040003980	RR LH 2 SEATER SIDE MOUNTING 1 LEG MOUNT	TATA spare parts
399040003981	RH 2ST SM1L 500CH850W NHB1 CVG	TATA spare parts
399040003982	LH 2ST SM1L 500CH850W NHB1 CVG	TATA spare parts
399040003984	3RH SM2L 450C950W WA BH SKL TM	TATA spare parts
399040004001	LAP BELT ASSY_2 POINT_PASSENGER SEATS	TATA spare parts

399040004010	ARM REST DETAILS_CVG	TATA spare parts
399040004011	ARM REST PAD	TATA spare parts
399040004016	DOLPHIN ARMREST 40MM WIDTH	TATA spare parts
399040004017	GRAB HANDLE GREY	TATA spare parts
399040004018	VALANCE COVER LH WITH ELIPTICAL SLOT	TATA spare parts
399040004019	VALANCE COVER RH WITH ELIPTICAL SLOT	TATA spare parts
399040084039	CUSHION PLASTIC COVER TMML JUMP SEAT	TATA spare parts
399040300001	BACK PANEL	TATA spare parts
399040300002	GRAB HANDLE	TATA spare parts
399040300003	PLASTIC END CAP	TATA spare parts
399040300004	TRIM COVER FSC	TATA spare parts
399040300005	ARMREST ASSY ( ONLY FOR SEAT OPPOSITE TO	TATA spare parts
399040300006	TRIM COVER FSB	TATA spare parts
399040410001	CUSHION FOAM PAD	TATA spare parts
399040410002	ASSY BACK FOAM PAD	TATA spare parts
399040912011	DRIVER SEAT ASSY	TATA spare parts
399042003003	PANEL PLATE ASSEMBLY-RH	TATA spare parts
399042003005	INTERNAL DISPLAY BOARD SUPPORT ASSY	TATA spare parts
399042003017	SIDE DESTINATION BOARD BRKT ASSY_RH	TATA spare parts
399042003018	SIDE DESTINATION BOARD BRKT ASSY_LH	TATA spare parts
399042003019	FRONT DESTINATION BOARD BRKT_LH	TATA spare parts
399042003020	FRONT DESTINATION BOARD BRKT_RH	TATA spare parts
399042003021	SIDE DESTINATION BOARD BRKT ASSY_LH	TATA spare parts
399042003022	SIDE DESTINATION BOARD BRKT ASSY_RH	TATA spare parts
399042003027	ELS MOUNTING ASSEMBLY	TATA spare parts
399042003029	INTERNAL DESTINATION BOARD BRKT LH BS6	TATA spare parts
399042003030	INTERNAL DESTINATION BOARD BRKT RH BS6	TATA spare parts
399042083002	SUPPORT FOR LAMP	TATA spare parts
399042083005	DISPLAY BOARD BRACKER REAR_1-SIKKIM	TATA spare parts
399042083006	DISPLAY BOARD BRACKER REAR_2-SIKKIM	TATA spare parts
399042083017	PANEL PLATE LH EME DOOR	TATA spare parts
399042083018	PANEL PLATE LH	TATA spare parts
399042083019	PANEL PLATE-LH	TATA spare parts
399042083020	PANEL PLATE_SFC-RH	TATA spare parts
399042083021	PANEL PLATE_SFC-LH	TATA spare parts
399042083023	PANEL PLATE_SFC_MC_RH	TATA spare parts
399042083026	CONTROL PANEL HOLDING BRACKET	TATA spare parts
399042083029	DASHBOARD PANEL PATEL_AMBULANCE-LH	TATA spare parts
399042083030	DASHBOARD PANEL PLATE COWL BUS LH	TATA spare parts
399042083031	CHANGE OVER SWITCH PLATE_AMBULANCE	TATA spare parts
399042083033	PANEL PLATE-LH	TATA spare parts
399042083038	INTERNAL DISPLAY BOARD SUPPORT_RH	TATA spare parts
399042083041	PANEL PLATE-LH¿ EMER DOOR MOBILE CHARGER	TATA spare parts
399042083044	PANEL PLATE RH	TATA spare parts
399042083046	PANEL PLATE RH	TATA spare parts
399042083062	PANEL PLATE LH	TATA spare parts
399042083065	CLUSTER PANEL PLATE RH	TATA spare parts

399042083083	PANEL PLATE LH	TATA spare parts
399042083088	PANEL PLATE LH LHD	TATA spare parts
399042083090	PANEL PLATE RH_EX	TATA spare parts
399042083093	PANEL PLATE_LH	TATA spare parts
399042083094	PANEL PLATE LH	TATA spare parts
399042083097	PANEL PLATE-LH	TATA spare parts
399042083100	PANEL PLATE_LH	TATA spare parts
399042083101	PANEL PLATE_RADIO_DVD_RH	TATA spare parts
399042083102	PANEL PLATE RH	TATA spare parts
399042083103	CLOSING PLATE FOR HAND BRAKE	TATA spare parts
399042083106	LCV EX PANEL PLATE_RH	TATA spare parts
399042083107	SIDE DESTINATION BOARD SUPPORT BRKT	TATA spare parts
399042083109	PANEL PLATE LH	TATA spare parts
399042083114	PANEL PLATE 29WB	TATA spare parts
399042083120	DASHBOARD HAND BRAKE PLATE LCV	TATA spare parts
399042083123	PANEL PLATE LCV EX AC	TATA spare parts
399042084005	DASHBOARD PANEL PLATE_RH_AMBULANCE	TATA spare parts
399042084006	PANEL PLATE RH	TATA spare parts
399042084008	DASHBOARD PANEL PLATE LH	TATA spare parts
399042084042	INTERNAL DESTINATION BOARD BRKT_LH	TATA spare parts
399042084043	INTERNAL DESTINATION BOARD BRKT_RH	TATA spare parts
399042283001	HARNESS PROTECTION RUBBER	TATA spare parts
399042283004	HARNESSPROTECTIONRUBBER75MM	TATA spare parts
399042283005	HARNESSPROTECTIONRUBBER60MM	TATA spare parts
399042283010	RUBBER GROMMET FOR RAR FOG LAMP	TATA spare parts
399042304002	LUMINARY ACRYLIC COVER	TATA spare parts
399042324001	LUMINARY FRAME	TATA spare parts
399042361001	PIGTAIL FOR HORN	TATA spare parts
399042362002	BATTERY CABLE +VE MEGA FUSE	TATA spare parts
399042362003	PIGTAIL HARNESS FOR WASHER TANK	TATA spare parts
399042362004	STOP REQUEST HARNESS PRIORITY SEAT	TATA spare parts
399042363001	ROOF ELECTRIC HARNESS	TATA spare parts
399042363002	REAR ELECTRIC HARNESS-RH	TATA spare parts
399042363003	REAR ELECTRIC HARNESS-LH	TATA spare parts
399042363004	SIDE LAMPS ELECTRIC HARNESS-DRIVER SIDE	TATA spare parts
399042363005	SIDE LAMPS ELECTRIC HARNESS-DRIVER OPPO	TATA spare parts
399042363006	LH HEAD LAMP ELECTRIC HARNESS	TATA spare parts
399042363007	RH HEAD LAMP ELECTRIC HARNESS	TATA spare parts
399042363008	DASH BOARD ELECTRIC HARNESS	TATA spare parts
399042363009	LOWER ELECTIRC HARNESS 38 WB SINGLE DOOR	TATA spare parts
399042363010	BATTERY CABLE	TATA spare parts
399042363011	BATTERY CABLE(CUT OFF SWITCH-BATTERY +VE	TATA spare parts
399042363012	FEED ELECTRIC HARNESS( BATTERY CUT-OFF T	TATA spare parts
399042363013	LOWER ELECTRIC HARNESS ( DOUBLE DOOR)	TATA spare parts
399042363015	ROOF ELECTRIC HARNESS	TATA spare parts
399042363017	ROOF ELECTRIC HARNESS	TATA spare parts
399042363018	BATTERY CABLE (ENGINE STARTER TO BATTERY	TATA spare parts



399042363019	WIPER MOTOR ELECTRIC HARNESS	TATA spare parts
399042363020	DRIVER FAN HARNESS	TATA spare parts
399042363021	HEADLAMP WIRE HARNESS - LH (LHD BUS) WIT	TATA spare parts
399042363022	HEADLAMP WIRE HARNESS - RH (LHD BUS) WIT	TATA spare parts
399042363023	DEFROSTER HARNESS	TATA spare parts
399042363024	HARNESS FOR PNEMATIC SYSTEM ( INDICATOR	TATA spare parts
399042363025	HARNESS FOR PE CONVERTER INTER CONNECTIO	TATA spare parts
399042363026	DOOR OPENED INDICATION HARNESS_1 DOOR	TATA spare parts
399042363027	DOOR OPENED INDICATION HARNESS_DD	TATA spare parts
399042363028	POWER SUPPLY ELECTRIC HARNESS	TATA spare parts
399042363029	EMERGENCY DOOR_LOWER ELECTRIC HARNESS	TATA spare parts
399042363034	STOP REQUEST HARNESS	TATA spare parts
399042363036	FRONT FOG LAMP HARNESS 1	TATA spare parts
399042363037	ROOF ELECTRIC HARNESS	TATA spare parts
399042363038	BATTERY CABLE	TATA spare parts
399042363039	ROOF ELECTRIC HARNESS	TATA spare parts
399042363040	AC INTERNAL LAMP HARNESS LH	TATA spare parts
399042363041	AC INTERNAL LAMP HARNESS RH - 38 & 42WB	TATA spare parts
399042363043	DRIVER SEAT BELT HARNESS	TATA spare parts
399042363044	ROOF ELECTRIC HARNESS_49-UJJAIN_DD	TATA spare parts
399042363045	TICKET VENDING M/C HARNESS_24V	TATA spare parts
399042363046	PASSENGER FAN HARNESS	TATA spare parts
399042363048	PASSENGER FAN HARNESS	TATA spare parts
399042363049	DASHBOARD HARNESS FOR PASSENGER FANS	TATA spare parts
399042363053	AC INTERNAL ROOF HARNESS_49WB	TATA spare parts
399042363055	LICENSE PLATE HARNESS	TATA spare parts
399042363056	ROOF ELECTRIC HARNESS	TATA spare parts
399042363057	DASHBOARD ELECTRIC HARNESS	TATA spare parts
399042363058	GPS SYSTEM ELECTRICAL HARENESS	TATA spare parts
399042363061	DASHBOARD ELECTRIC HARNESS_LUXURY	TATA spare parts
399042363072	TICKET VENDING SINGLE MACHINE HARNESS	TATA spare parts
399042363073	INVERTER OUTPUT SUPPLY HARNESS	TATA spare parts
399042363074	SIDE TURN INDICATOR ELECT HARNESS_RH_SFC	TATA spare parts
399042363075	EMERGENCY DOOR LOWER ELEC HARNESS	TATA spare parts
399042363080	HAT RACK STOP REQUEST HARNESS	TATA spare parts
399042363081	STOP REQUEST SWITCH ELECTRICAL HARNESS	TATA spare parts
399042363085	TAIL LAMPS PIG TAIL ELECTRICAL HARNESS	TATA spare parts
399042363087	DC TO DC CONVETER I/P HARNESS	TATA spare parts
399042363091	STEP LAMP TO SIDE MARKER LAMP HARNESS	TATA spare parts
399042363092	MULTI PURPOSE PIG TAIL HARNESS GREY	TATA spare parts
399042363093	MULTI PURPOSE PIG TAIL HARNESS BLACK	TATA spare parts
399042363094	MULTI PURPOSE PIG TAIL HARNESS BROWN	TATA spare parts
399042363095	MULTI PURPOSE HARNESS PINK & BLUE	TATA spare parts
399042363096	MULTI PURPOSE HARNESS YELLOW & BROWN	TATA spare parts
399042363106	REAR EXTERNAL LIGHTING W/H RH	TATA spare parts
399042363107	REAR EXTERNAL LIGHTING	TATA spare parts
399042363108	MONITOR POWER SUPPLY HARNESS	TATA spare parts

399042363111	SPEAKERS ELECTRIC HARNESS	TATA spare parts
399042363112	DASHBOARD ELECTRIC HARNESS	TATA spare parts
399042363113	ROOF ELECTRIC HARNESS	TATA spare parts
399042363116	DESTINATION BOARD HARNESS	TATA spare parts
399042363117	DASHBOARD ELECTRICAL HARNESS	TATA spare parts
399042363118	UPPER FRONT HARNESS	TATA spare parts
399042363119	REAR RH HARNESS	TATA spare parts
399042363120	STOP REQUEST HARNESS	TATA spare parts
399042363125	PIGTAIL HARNESS FOR SIDE MARKER LAMP	TATA spare parts
399042363128	REAR CENTER MOUNTED STOP LAMP HARNESS	TATA spare parts
399042363129	AMPLIFIER POWER SUPPLY	TATA spare parts
399042363130	AMPLIFIER TO SPEAKER HARNESS	TATA spare parts
399042363131	PIGTAIL ADAPTER	TATA spare parts
399042363132	AMPLIFIER TO SPEAKER HARNESS	TATA spare parts
399042363138	DOOR HAZARD WARNING ELECTRICAL HARNESS	TATA spare parts
399042363139	INTERNAL LAMP HARNESS LH	TATA spare parts
399042363140	INTERNAL LAMP HARNESS RH	TATA spare parts
399042363143	ROOF ELECTRIC HARNESS	TATA spare parts
399042363147	EMERGENCY DECLARATION ELECTRICAL HARNESS	TATA spare parts
399042363152	INTERNAL LAMP HARNESS LH	TATA spare parts
399042363153	INTERNAL LAMP HARNESS RH	TATA spare parts
399042363154	DASHBOARD SWITCH ELECTRIC HARNESS	TATA spare parts
399042363155	FUSE BOX HARNESS	TATA spare parts
399042363156	ROOF ELECTRIC HARNESS	TATA spare parts
399042363157	TAIL ELECTRIC HARNESS	TATA spare parts
399042363158	ROOF ELECTRIC HARNESS	TATA spare parts
399042363162	TAIL TO EMERGENCY DOOR PIGTAIL HARNESS	TATA spare parts
399042363163	AC INTERNAL LAMP PIGTAIL HARNESS	TATA spare parts
399042363164	ROOF ELECTRICAL HARNESS AC ABS	TATA spare parts
399042363167	INTERNAL LAMP HARNESS ABS	TATA spare parts
399042363168	ROOF ELECTRIC HARNESS_34WB_ABS	TATA spare parts
399042363169	PIGTAIL FOR BLINKER CONNECTION	TATA spare parts
399042363171	PIGTAIL FOR SIDE MARKER LAMP	TATA spare parts
399042363172	WIPER MOTOR PIGTAIL HARNESS_EX	TATA spare parts
399042363173	PIGTAIL HARNESS FOR 600 MM LED STRIPEX	TATA spare parts
399042363174	EMG. DECLARATION SYSTEM PIGTAIL	TATA spare parts
399042363176	AMPLIFIER TO SPEAKER ELECTRIC HARNESS	TATA spare parts
399042363177	AC SUPPLY ELECTRICAL HARNESS	TATA spare parts
399042363179	READING LAMP HARNESS	TATA spare parts
399042363180	INVERTER OUTPUT ELECTRICAL HARNESS	TATA spare parts
399042363181	REAR HIGH MOUNTED STOP LAMP HARNESS	TATA spare parts
399042363182	DESTINATION BOARD LAMP HARNESS	TATA spare parts
399042363183	INTERNAL LAMP HARNESS CO-DRIVER SIDE	TATA spare parts
399042363184	INTERNAL LAMP HARNESS DRIVER SIDE	TATA spare parts
399042363186	INTERNAL ILLUMINATION HARNESS EX LHD	TATA spare parts
399042363187	INTERNAL LAMP HARNESS_DS	TATA spare parts
399042363188	INTERNAL LAMP HARNESS_CDS	TATA spare parts

399042363189	DASHBOARD ELECTRIC HARNESS _49WB_EX	TATA spare parts
399042363190	INTERNAL LAMP HARNESS_NEPAL	TATA spare parts
399042363192	DESTINATION BOARD SUPPLY HARNESS	TATA spare parts
399042363193	CONTROLLER TO SPEAKER CONN. HARNESS	TATA spare parts
399042363194	RH SPEAKER ELECTRICAL HARNESS	TATA spare parts
399042363195	DB CONT. TO 5 PIN DIN MIC P/G HARNESS	TATA spare parts
399042363201	MOBILE CHARGER HARNESS FOR LCV	TATA spare parts
399042363206	READING LAMP SUPPLY HARNESS-2	TATA spare parts
399042363207	DESTINATION BOARD SUPPLY HARNESS	TATA spare parts
399042363209	DEST BOARD HANOVER COMM CABLE 10MTR	TATA spare parts
399042363210	SUPPLY HARNESS FOR MONITOR BS6	TATA spare parts
399042363212	DESTINATION BOARD SUPPLY HARNESS	TATA spare parts
399042363215	AIS140 CONTROLLER HARNESS	TATA spare parts
399042363216	AIS140 EMERGENCY SWITCH HARNESS 49WB	TATA spare parts
399042363219	AIS140 EMERGENCY SWITCH HARNESS-34WB	TATA spare parts
399042363220	AIS140 EMERGENCY SWITCH HARNESS_42WB	TATA spare parts
399042363222	AIS140 EMERGENCY SW HARNESS 31WB	TATA spare parts
399042363234	PIGTAIL HARNESS FOR SPEAKER	TATA spare parts
399042363237	INTERNAL LAMP HARNESS	TATA spare parts
399042363246	PASSENGER FAN HARNESS_CDS_4FANS	TATA spare parts
399042363247	SUPPLY HARNESS FOR AIS 153 LCV	TATA spare parts
399042363249	MOBILE CHARGER HARNESS_CDS_29WB	TATA spare parts
399042363256	STOP REQUEST HARNESS 4 NOS BS6	TATA spare parts
399042363266	PIGTAIL FOR SPEAKERS TO IBDC CONTROLLER	TATA spare parts
399042363269	PIGTAIL FOR IBDC BS6	TATA spare parts
399042363271	W/H PASSENGER FAN POWER SUPPLY LHD	TATA spare parts
399042373001	STEPS LIGHTING LAMP	TATA spare parts
399042373004	DOUBLE PARABOLA LUMINARY	TATA spare parts
399042373005	STOP REQUEST BUTTON SWITCH	TATA spare parts
399042373010	SOUND BUZZER	TATA spare parts
399042373011	FUSE 10 A	TATA spare parts
399042373012	FUSE 15 A	TATA spare parts
399042373013	NORMAL CONTACT RELAY_12V	TATA spare parts
399042373014	PASS. BELL BUZZER RELAY	TATA spare parts
399042373015	HEADLAMP - HIGH BEAM WITH PARKING LAMP -	TATA spare parts
399042373016	HEADLAMP - HIGH BEAM WITH PARKING LAMP -	TATA spare parts
399042373017	HEADLAMP - LOW BEAM - 12V RH	TATA spare parts
399042373018	HEADLAMP - LOW BEAM - 12V LH	TATA spare parts
399042373019	FRT TURN SIGNAL LAMP - 12V (AMBER)BS1- 4	TATA spare parts
399042373020	TAIL LAMP - BRAKE AND POSITION LAMP - 12	TATA spare parts
399042373021	REAR PARKING LAMP	TATA spare parts
399042373022	TAIL LAMP - TURN SIGNAL - 12V (AMBER)	TATA spare parts
399042373023	REAR ROOF MARKER LAMP - 12V	TATA spare parts
399042373024	SIDE MARKER LAMP - POSITION AND / OR BLI	TATA spare parts
399042373026	REAR REFLECTOR RETRO-RED	TATA spare parts
399042373027	LICENCE PLATE LAMP ASSEMBLY - 12V	TATA spare parts
399042373028	MARKER LAMP - FRONT ROOF MARKER LAMP - 1	TATA spare parts

399042373029	LUMINARY ASSEMBLY 12 VOLT	TATA spare parts
399042373031	DOUBLE INSU-NBR13249 STOP REQ CABLE	TATA spare parts
399042373032	STEPS LIGHTING ASSEMBLY * 24V	TATA spare parts
399042373033	HEADLAMP HIGH BEAM LEFT SIDE -24V	TATA spare parts
399042373034	HEADLAMP LOW BEAM RIGHT SIDE -24V	TATA spare parts
399042373035	HEADLAMP LOW BEAM LEFT SIDE -24V	TATA spare parts
399042373036	TAIL LAMP - BRAKE AND POSITION LAMP - 24	TATA spare parts
399042373037	TAIL LAMP - REVERSE GEAR - 24V	TATA spare parts
399042373038	TAIL LAMP - TURN SIGNAL - 24V	TATA spare parts
399042373039	REAR ROOF MARKER LAMP - 24V	TATA spare parts
399042373040	SIDE MARKER LAMP - POSITION AND / OR BLI	TATA spare parts
399042373041	LICENCE PLATE LAMP ASSEMBLY - 24V	TATA spare parts
399042373042	MARKER LAMP - FRONT ROOF MARKER LAMP - 2	TATA spare parts
399042373044	FRONT TURN SIGNAL LAMP ASSEMBLY	TATA spare parts
399042373048	DOUBLE PARABOLA LUMINARY	TATA spare parts
399042373049	PASS. ROOF LAMP ASSY	TATA spare parts
399042373050	HEADLAMP HIGH BEAM RIGHT SIDE -24V	TATA spare parts
399042373051	FRONT FOG LAMP ( FIEM -24 V)	TATA spare parts
399042373052	LUMINARY ASSEMBLY	TATA spare parts
399042373053	INTERNAL LUMINARY BASE SUB-ASSEMBLY-24V	TATA spare parts
399042373054	FRONT FOG LAMP	TATA spare parts
399042373903	CONNECTION TERMINAL-CHASSIS	TATA spare parts
399042373904	NIGHT LAMP_12V_5W	TATA spare parts
399042373916	HEADLAMP - LOW BEAM LHD-RH 12V	TATA spare parts
399042373917	HEADLAMP - LOW BEAM LHD - LH 12V	TATA spare parts
399042373918	RADIO ANTENNA CABLE	TATA spare parts
399042373919	RADIO ANTENNA	TATA spare parts
399042373921	CENTRIFUGAL PUMP_24V	TATA spare parts
399042373922	SPOT LIGHT 24 V	TATA spare parts
399042373923	LED TUBE LIGHT 2 FEET	TATA spare parts
399042373926	LED SPOT LIGHT - 24V	TATA spare parts
399042373927	HIGH INTENSITY PATIENT LAMP 24V	TATA spare parts
399042373929	LICENSE PLATE LAMP_24V	TATA spare parts
399042373934	EMBDC CONTROLLER	TATA spare parts
399042373935	LICENSE PLATE LAMP_12V	TATA spare parts
399042373940	SOUND BUZZER	TATA spare parts
399042373941	GPS ANTENNA BS6	TATA spare parts
399042912001	STEPS LIGHTING ASSEMBLY 24V	TATA spare parts
399042912012	FRONT FOG LAMP ASSY-12V	TATA spare parts
399042912013	FRONT FOG LAMP ASSY-24V	TATA spare parts
399042912015	DRIVER FAN ASSY-24V	TATA spare parts
399042912026	STEP LAMP ASSEMBLY_12V	TATA spare parts
399042912037	DRIVER FAN ASSY-12V	TATA spare parts
399042912287	KPIT ITS_KIT_MOUUD-II (MINI)	TATA spare parts
399042963006	LCV_SFC 31/29 WB AIS 140 RETRO KIT	TATA spare parts
399042963007	LCV_34 WB AIS 140 RETRO KIT	TATA spare parts
399042963008	LCV_42 WB AIS 140 RETRO KIT	TATA spare parts

399042963010	LCV_49 WB AIS 140 RETRO KIT	TATA spare parts
399043214001	STEP EXT END CAP-1	TATA spare parts
399043214002	STEP EXT END CAP-2	TATA spare parts
399044003005	RLC COMPLETE STR ASSY	TATA spare parts
399044003006	RLC LADDER ASSY	TATA spare parts
399044003007	RLC COMPLETE STRUCTURE ASSEMBLY- 42WB	TATA spare parts
399044184002	ALUMINIUM CHEQUERED PLATE FRONT	TATA spare parts
399044184003	ALUMINIUM CHEQUERED PLATE FRONT	TATA spare parts
399044184004	ALUMINIUM CHEQUERED PLATE FRONT	TATA spare parts
399044184005	AL CHQD PLATE¿ RLC BASE¿ 1	TATA spare parts
399044184007	AL CHQD PLATE¿ RLC REAR	TATA spare parts
399044184011	AL.CHEQUERED PLATE RLC BASE 2700X625	TATA spare parts
399044303001	RLC BOLT COVER (POLYAMIDE 6)	TATA spare parts
399045003001	WINDSHIELD LOWER ROOFSTICK ASSEMBLY	TATA spare parts
399045003022	TOP PLATE WITH BOLT ASSY	TATA spare parts
399045004001	WINDSHIELD WIPER ENGINE SUPPORT ASSEMBLY	TATA spare parts
399045014001	FRONT TUBE	TATA spare parts
399045064001	WINDSHIELD WIPER AXLE BUSHING	TATA spare parts
399045083230	L SECTION REINFORCEMENT FOR MESH	TATA spare parts
399045083231	L SECTION REINFORCEMENT	TATA spare parts
399046003002	TRAILING CABLE ASSEMBLY	TATA spare parts
399046004004	SPARE WHEEL CARRIER ASSY	TATA spare parts
399046004005	SAPRE WHEEL CARRIER LATCH MECHANISM	TATA spare parts
399046013002	SQUARE TUBE 50X50X832	TATA spare parts
399046015014	DRIVER PLATFORM TUBE	TATA spare parts
399046073001	TOWING HOOK	TATA spare parts
399046074001	TOWING COUPLING SUPPORT	TATA spare parts
399049002001	INTERNAL FRP REAR SIDE	TATA spare parts
399049083001	REAR INTERNAL REVETMENT	TATA spare parts
399049263001	REAR INTERNAL REVETMENT	TATA spare parts
399049323001	REAR WINDOW LOWER REAR CLOSING RH	TATA spare parts
399049323002	REAR WINDOW LOWER REAR CLOSING LH	TATA spare parts
399049912004	FRP REAR INNER _E.HAMMER ASSY _LHD/RHD	TATA spare parts
399050003001	FRONT UPPER COVERING	TATA spare parts
399050003002	SUN VISOR ASSY	TATA spare parts
399050003003	INTERNAL REAR-VIEW MIRROR	TATA spare parts
399050003017	SIDE PLYWOOD COVER FOR TRANSITION BOX DR	TATA spare parts
399050003020	SIDE PLYWOOD COVER FOR TRANSITION BOX FO	TATA spare parts
399050003022	AC DUCT ASSEMBLY¿ DRIVER SIDE	TATA spare parts
399050003023	AC DUCT ASSEMBLY CO-DRIVER SIDE 42WB RHD	TATA spare parts
399050003024	AIR TRANSITION BOX ASSEMBLY 42WB RHD	TATA spare parts
399050003025	SIDE PLYWOOD COVER FOR TRANSITION BOX 42	TATA spare parts
399050003030	SIDE PLYWOOD COVER FOR TRANSITION BOX	TATA spare parts
399050003031	CO DRIVER SIDE AC DUCT ASSEMBLY	TATA spare parts
399050003032	DRIVER SIDE AC DUCT ASSEMBLY	TATA spare parts
399050003033	AIR TRANSITION BOX ASSEMBLY	TATA spare parts
399050003043	FRONT PLYWOOD COVER FOR TRANSITION BOX	TATA spare parts

399050003063	CO-DRIVER SIDE AC DUCT ASSLY	TATA spare parts
399050003064	AC DUCT ASSEMBLY DRIVER SIDE	TATA spare parts
399050003066	SIDE PLYWOOD COVER FOR TRANSITION BOX	TATA spare parts
399050003068	AC DUCT GRILL ASSY	TATA spare parts
399050003072	AC DUCT ASSEMBLY RH SIDE	TATA spare parts
399050003073	AC DUCT ASSEMBLY LH SIDE	TATA spare parts
399050003087	AIR TRANSITION BOX ASSEMBLY CC225	TATA spare parts
399050003091	AC DUCT ASSY CO-DRIVER SIDE FOR LHD BUS	TATA spare parts
399050003092	AC DUCT ASSEMBLY DRIVER SIDE FOR LHD BUS	TATA spare parts
399050003094	AC DUCT ASSY	TATA spare parts
399050003098	CO-DRIVER SIDE AC DUCT ASSY	TATA spare parts
399050003099	DRIVER SIDE AC DUCT ASSY	TATA spare parts
399050003100	SIDE PLYWOOD FOR TRANSITION BOX ASSY	TATA spare parts
399050003101	SIDE PLYWOOD COVER FOR TRANSITION BOX	TATA spare parts
399050003110	CO-DRIVER SIDE AC DUCT ASSY	TATA spare parts
399050003111	DRIVER SIDE AC DUCT ASSY	TATA spare parts
399050003117	AC DUCT ASSEMBLY DRIVER SIDE	TATA spare parts
399050003118	AC DUCT ASSEMBLY CO-DRIVER SIDE	TATA spare parts
399050003121	TRANSITION DUCT ASSY FOR BASRUR HAT-RACK	TATA spare parts
399050003122	AC DUCT ASSEMBLY 34WB	TATA spare parts
399050003123	AC DUCT ASSEMBLY 34WB LH	TATA spare parts
399050003125	AC DUCT ASSEMBLY DRIVER SIDE	TATA spare parts
399050003126	CO-DRIVER AC DUCT ASSEMBLY	TATA spare parts
399050003127	AC DUCT ASSEMBLY	TATA spare parts
399050003132	AC DUCT WITH HATRACK SUB-ASSY RH	TATA spare parts
399050003133	AC DUCT WITH HATRACK SUB-ASSY LH	TATA spare parts
399050003134	AC DUCT WITH HATRACK SUB-ASSY RH	TATA spare parts
399050003135	AC DUCT WITH HATRACK SUB-ASSY LH	TATA spare parts
399050003136	AC DUCT WITH HATRACK SUB-ASSY_LH	TATA spare parts
399050003137	AC DUCT WITH HATRACK SUB-ASSY_RH	TATA spare parts
399050003141	AC DUCT WITH HATRACK SUB-ASSY_LH	TATA spare parts
399050003142	AC DUCT WITH HATRACK SUB-ASSY_RH	TATA spare parts
399050003143	AC DUCT & HATRACK ASSY-LH	TATA spare parts
399050003144	AC & HATRACK ASSY-RH	TATA spare parts
399050003145	AC DUCT & HATRACK ASSEMBLY LH	TATA spare parts
399050003146	AC DUCT & HATRACK ASSY RH	TATA spare parts
399050003153	AC DUCT & HATRACK ASSY ¿LH	TATA spare parts
399050003154	AC DUCT & HATRACK ASSY-RH	TATA spare parts
399050003157	AC DUCT ASSEMBLY DRIVER SIDE	TATA spare parts
399050003158	AC DUCT ASSEMBLY CO-DRIVER SIDE	TATA spare parts
399050003166	AC DUCT ASSEMBLY_DRIVER SIDE	TATA spare parts
399050003167	AC DUCT ASSY_CO DRIVER SIDE	TATA spare parts
399050003172	HATRACK SUPPORT ASSY WITH COVER TYPE 1	TATA spare parts
399050003182	AC DUCT WITH HATRACK SUB-ASSY_RH	TATA spare parts
399050003183	AC DUCT WITH HATRACK SUB-ASSY_LH	TATA spare parts
399050003211	AC DUCT WITH HATRACK SUB-ASSY_RH	TATA spare parts
399050003212	AC DUCT WITH HATRACK SUB-ASSY_LH	TATA spare parts

399050004002	HAT RACK SUPPORT ASSEMBLY_49WB	TATA spare parts
399050004007	REAR PLYWOOD FINISHING COVER	TATA spare parts
399050074001	T BOLT FOR HAT RACK BS6	TATA spare parts
399050083018	HOSE COVER	TATA spare parts
399050083025	CONTROL PANEL HOLDING BRKT CC-200	TATA spare parts
399050083026	HOSE COVER FINISHING PROFILE	TATA spare parts
399050084039	BRACKET MOUNTING INSIDE AC DUCT	TATA spare parts
399050084050	AC DUCT SECOND SHEET DRIVER SIDE	TATA spare parts
399050084053	AC DUCT FIRST SHEET CO-DRIVER SIDE	TATA spare parts
399050084054	AC DUCT SHEET CO-DRIVER SIDE SECOND SHE	TATA spare parts
399050084061	AC DUCT SHEET DRIVER SIDE REAR SHEET	TATA spare parts
399050084062	AC DUCT SHEET CO-DRIVER SIDE REAR SHEET	TATA spare parts
399050084063	AC DUCT FRIST SHEET DRIVER SIDE	TATA spare parts
399050084064	AC DUCT SECOND SHEET DRIVER SIDE	TATA spare parts
399050084066	AC DUCT SHEET DRIVER REAR SHEET	TATA spare parts
399050084067	AC DUCT SHEET CO-DRIVER SIDE REAR	TATA spare parts
399050084068	AC DUCT SHEET CO-DRIVER SIDE SECONDSHEET	TATA spare parts
399050084069	AC DUCT SHEET CO-DRIVER SIDE FIRST SHEET	TATA spare parts
399050084086	AC DUCT SHEET CO DRIVER SIDE FIRST SHEE	TATA spare parts
399050084088	AC DUCT CO DRIVER SIDE SECOND SHEET	TATA spare parts
399050084089	AC DUCT DRIVER SIDE FIRST SHEET	TATA spare parts
399050084090	AC DUCT DRIVER SIDE SECOND SHEET	TATA spare parts
399050084092	AC DUCT DRIVER SIDE REAR SHEET	TATA spare parts
399050084153	AC DUCT SHEET	TATA spare parts
399050084164	AC DUCT SHEET_DRIVER SIDE FIRST SHEET	TATA spare parts
399050084165	AC DUCT SHEET_DRIVER SIDE-SECOND SHEET	TATA spare parts
399050084166	AC DUCT SHEET_CO-DRIVER SIDE-FIRST SHEET	TATA spare parts
399050084167	AC DUCT SHEET CO-DRIVERSIDE SECOND SHEET	TATA spare parts
399050084214	SEAT RAIL PROFILE EV03	TATA spare parts
399050084236	EXTRUSION REINFORCEMNT	TATA spare parts
399050085001	PP MS BRACKET	TATA spare parts
399050085018	PP MS BRACKET-Y1	TATA spare parts
399050184023	DRIVER SIDE FIRST SHEET	TATA spare parts
399050184026	DRIVER SIDE REAR SHEET	TATA spare parts
399050184027	CO-DRIVER SIDE REAR SHEET	TATA spare parts
399050184030	CO-DRIVER SIDE REAR SHEET	TATA spare parts
399050184062	AC DUCT SHEET DRIVER SIDE FIRST SHEET	TATA spare parts
399050184063	AC DUCT SHEET DRIVER SIDE MIDDLE SHEET	TATA spare parts
399050184064	AC DUCT SHEET DRIVER SIDE REAR SHEET	TATA spare parts
399050184065	AC DUCT SHEET CO-DRIVER SIDE FIRST SHEET	TATA spare parts
399050184066	AC DUCT SHEET CO-DRIVER SIDE REAR SHEET	TATA spare parts
399050184067	AC DUCT SHEET CO DRIVER SIDE REAR SHEET	TATA spare parts
399050184075	AC DUCT SHEET RH SIDE	TATA spare parts
399050184076	AC DUCT SHEET RH 3RD SHEET	TATA spare parts
399050184077	AC DUCT SHEET LH SIDE	TATA spare parts
399050184078	AC DUCT SHEET LH SIDE	TATA spare parts
399050184099	AC DUCT CO DRIVER SIDE REAR SHEET	TATA spare parts

399050184100	AC DUCT CO-DRIVER SIDE FRONT SHEET	TATA spare parts
399050184101	AC DUCT DRIVER SIDE FRONT SHEET	TATA spare parts
399050184102	AC DUCT DRIVER SIDE MIDDLE SHEET	TATA spare parts
399050184103	AC DUCT DRIVER SIDE REAR SHEET	TATA spare parts
399050184108	AC DUCT SHEET	TATA spare parts
399050184109	AC DUCT SHEET	TATA spare parts
399050184110	AC DUCT SHEET	TATA spare parts
399050184111	AC DUCT SHEET	TATA spare parts
399050184112	AC DUCT SHEET	TATA spare parts
399050184125	AC DUCT DRIVER SIDE 1ST SHEET	TATA spare parts
399050184126	AC DUCT DRIVER SIDE 2ND SHEET	TATA spare parts
399050184127	AC DUCT DRIVER SIDE 3RD SHEET	TATA spare parts
399050184128	AC DUCT DRIVER SIDE REAR SHEET	TATA spare parts
399050184129	AC DUCT SHEET CO-DRIVER SIDE REAR SHEET	TATA spare parts
399050184130	AC DUCT CO-DRIVER SIDE 3RD SHEET	TATA spare parts
399050184131	AC DUCT CO-DRIVER SIDE 2ND SHEET	TATA spare parts
399050184132	AC DUCT CO-DRIVER SIDE 1ST SHEET	TATA spare parts
399050184138	AC DUCT SHEET DRIVER SIDE-1ST	TATA spare parts
399050184139	AC DUCT SHEET DRIVER SIDE-2ND	TATA spare parts
399050184140	AC DUCT SHEET DRIVER SIDE-3RD	TATA spare parts
399050184141	AC DUCT SHEET CODRIVER SIDE 1ST	TATA spare parts
399050184142	AC DUCT SHEET CODRIVER SIDE 2ND	TATA spare parts
399050184143	AC DUCT SHEET CODRIVER SIDE 3RD	TATA spare parts
399050184165	AC DUCT SHEET	TATA spare parts
399050184166	AC DUCT SHEET	TATA spare parts
399050184167	AC DUCT SHEET	TATA spare parts
399050184168	AC DUCT SHEET	TATA spare parts
399050184169	AC DUCT SHEET	TATA spare parts
399050184170	AC DUCT SHEET	TATA spare parts
399050184171	AC DUCT SHEET	TATA spare parts
399050184172	AC DUCT SHEET	TATA spare parts
399050184173	AC DUCT SHEET	TATA spare parts
399050184174	AC DUCT SHEET _2	TATA spare parts
399050184175	AC DUCT SHEET _3	TATA spare parts
399050184176	AC DUCT SHEET 1_CO DRIVER	TATA spare parts
399050184177	AC DUCT SHEET 2_CO DRIVER SIDE	TATA spare parts
399050184178	AC DUCT SHEET 3_CO DRIVER SIDE	TATA spare parts
399050214002	ALUMINIUM PROFILE FOR AC DUCT	TATA spare parts
399050214006	ALUMINIUM PROFILE FOR AC DUCT	TATA spare parts
399050214007	ALUMINIUM PROFILE FOR AC DUCT	TATA spare parts
399050244010	FRONT PLYWOOD COVER FOR TRANSITION BOX	TATA spare parts
399050263002	TRANSITION DUCT RH-GSO(LCV EX LHD)	TATA spare parts
399050263004	TRANSITION DUCT LH (LCV EX RHD)	TATA spare parts
399050263005	TRANSITION DUCT RH (LCV EX RHD)	TATA spare parts
399050303003	VENTILLATION PLASTIC GRILL_RAL 7040	TATA spare parts
399050303007	PLASTIC INSERT COVERING BS6	TATA spare parts
399050304003	HATRACK BRACKET COVER	TATA spare parts



399050323002	COVER ABOVE REAR PASSENGER DOOR	TATA spare parts
399050323003	ABS HOSE COVER	TATA spare parts
399050323004	COVER ABOVE FRONT PASSENGER DOOR	TATA spare parts
399050323005	COVER ABOVE FRONT PASSENGER DOOR	TATA spare parts
399050324028	HAT RACK END COVER	TATA spare parts
399050324029	AC SERVICE SET WITH BUZZER.	TATA spare parts
399050324044	AC DUCT SERVICE SET MEDIUM GREY BS6	TATA spare parts
399050912001	INTERNAL FRP ABOVE THE DRIVER	TATA spare parts
399050912002	AC 12V	TATA spare parts
399050912003	AC KIT ASSY CC200 E I AL110V 24V	TATA spare parts
399050912010	INTERNAL FRP ABOVE THE DRIVER	TATA spare parts
399050962011	AC UNIT_24V	TATA spare parts
399050962016	AC EBERSPAECHER¿ CC 310 12V BS4	TATA spare parts
399050962020	MBA 160RN FROM TML	TATA spare parts
399050962022	BKT AND ALT.KIT CR160	TATA spare parts
399050962025	AC_WEBESTO_SPHEROS_CC 225 12V_BS3	TATA spare parts
399050962028	AC_SPHEROS_CC225 24V_120AMP_LP613 E-II	TATA spare parts
399050962029	AC AND HEATING SYSTEM	TATA spare parts
399050962036	AC SYSTEM - SPHEROS CC225 24V	TATA spare parts
399050962037	AC KIT EURO-1	TATA spare parts
399050962039	POWER PACK KIT ENGINE & COMP	TATA spare parts
399050962049	ROOF UNIT_AC_SPHEROS_CC225	TATA spare parts
399050962056	REFRIGERANT HOSES 7.6 MTR_LCV_49WB	TATA spare parts
399050962057	REFRIGERANT HOSES 6.7 MTR	TATA spare parts
399050962071	SPHEROS AC CC225 12V-HVAC UNIT	TATA spare parts
399050962073	SUCTION HOSE 6.8 MTR 613EII	TATA spare parts
399050962074	DISCHARGE HOSE 6.8 MTR 613EII	TATA spare parts
399050962075	SUCTION HOSE 6 MTR 713 EII	TATA spare parts
399050962076	DISCHARGE HOSE 6 MTR 713 EII	TATA spare parts
399050962080	AC_SPHEROS_CC225 24V_LP_913_CNG	TATA spare parts
399050963015	DEMISTER	TATA spare parts
399050963031	ROOF TOP AC UNIT_CC-175_12V	TATA spare parts
399050963045	ALTERNATOR 150 AMP 12V W/O PUMP	TATA spare parts
399050963046	COMPRESSOR TM21-12V	TATA spare parts
399050964028	ASSY AIR COND COMP-24V-6PK	TATA spare parts
399050964042	CONTITECH BELT L_1000 MM	TATA spare parts
399050964043	SUC./DISCHG ADOPTOR D5/8IN	TATA spare parts
399050964044	AL 1/2IN DISCHARGE ADAPTOR	TATA spare parts
399050964047	GROMMET-DRAIN(KAJU)	TATA spare parts
399050964052	EVAP BLOWER SPAL	TATA spare parts
399050964053	COND FAN	TATA spare parts
399050964055	LIQUID LINE ASSY-1 CC225/275/175 BS6	TATA spare parts
399050964058	PLUG SEAL DIA 45	TATA spare parts
399050964059	RUBBER PROFILE BASE	TATA spare parts
399050964060	EVAP. DIVISON PLATE CC-225 BS6	TATA spare parts
399050964062	BRACKET RD BOTTLE(NEW) - REV01 BS6	TATA spare parts
399050964063	FRONT GRID CC225 BS6	TATA spare parts

399050964064	SIDE GRID CC225 BS6	TATA spare parts
399050964065	FAN PLATE CC175 (SPAL FAN 2 HOLE) BS6	TATA spare parts
399050964066	BELT POLY V 8PK-1800	TATA spare parts
399050964073	MAIN WIRING HARNESS CC225 3L	TATA spare parts
399050964075	IDLER WITH BEARING	TATA spare parts
399050964076	PULLEY ALT 8PK	TATA spare parts
399050964077	ALT MTG BKT ASSY WITH IDLER	TATA spare parts
399050964078	COMP MOUNTING BKT ASSY	TATA spare parts
399050964079	PORT¿ TM-21	TATA spare parts
399050964080	COMP MTG BRACKET	TATA spare parts
399050964081	ALTERNATOR CONNECTOR110AMP / 120AMP	TATA spare parts
399050964082	ALTERNATOR IGNITION WIRE	TATA spare parts
399050964083	RUBBER LONG PROFILE (PATTI)	TATA spare parts
399050964085	COMP MOUNTING BKT ASSY	TATA spare parts
399050964095	FOAM NBR 35MMX25MMX1MTR BS6	TATA spare parts
399050964105	DASH CONTROL 12/24V GL-W210	TATA spare parts
399050964117	RELAY BOARD 12V GL-W142 BS6	TATA spare parts
399050964119	DASH CONTROLLER SBU 410 24V	TATA spare parts
399050964121	IDLER PULLEY WITH BEARING	TATA spare parts
399050964124	BANDED V BELT_ TWIN GROOVE 1572	TATA spare parts
399050964125	COMP MOUNTING BKT TATA LP913/CNG	TATA spare parts
399050964126	FUSE BOX W/O PLATE(125A/100A)	TATA spare parts
399050964127	RLY BOARD GRND TO EARTH CABLE ASY	TATA spare parts
399050964128	POWER CABLE ASSY 25 SQMM RED(11M)	TATA spare parts
399050964129	MAIN WIRING HARNESS 913	TATA spare parts
399050964130	COMP EARTH WIRE (1.5 SQMM 0.5 MTR	TATA spare parts
399050964131	RETURN AIR GRILL CC-225_ (CREAM)	TATA spare parts
399050964132	SUCTION HOSE ASSEMBLY_ TATA-913 CNG	TATA spare parts
399050964133	DISCHARGE HOSE ASSEMBLY_ TATA-913CNG	TATA spare parts
399050964134	BATTERY WIRE ASSY (RED COLOR)-0.5M	TATA spare parts
399050964135	SETBUS CONTROLLER BRACKET	TATA spare parts
399050964136	MFC COIL FOR CC225	TATA spare parts
399050964137	DUCT/RETURN AIR SENSOR(11118005A)	TATA spare parts
399050964138	RELAY BOARD SBF243	TATA spare parts
399050964139	CONNECTION PAD-DISCHARGE CC-225	TATA spare parts
399050964140	CC225 BLOWER WH WITH SETBUS	TATA spare parts
399050964141	TEMPERATURE SENSOR PIGTAIL	TATA spare parts
399050964142	AIR FILTER	TATA spare parts
399050964143	FILTER SUPPORT BRACKET	TATA spare parts
399050964144	CENTRAL FIXING SUPPORT	TATA spare parts
399050964145	CENTRAL FIXING SUPPORT	TATA spare parts
399050964147	IDLER MTG. BKT ASSY.TATA-613-38E-II	TATA spare parts
399051002002	CONDUCTOR CABIN CAGE ASSEMBLY	TATA spare parts
399051003003	PARTITION WALL¿ ASSEMBLY LH SIDE OF DOOR	TATA spare parts
399051003008	DRIVER PARTITION ASSEMBLY	TATA spare parts
399051003009	HANDHOLD TUBE- PASSENGER PARTITION-RH SI	TATA spare parts
399051003010	HANDHOLD TUBE- PASSENGER PARTITION-RH SI	TATA spare parts

399051003011	HAND HOLD TUBE ASSY (PAASNGER L.H)	TATA spare parts
399051003012	HANDHOLD TUBE	TATA spare parts
399051003013	STEP WELL PARTITION WALL ASSEMBLY	TATA spare parts
399051003015	DRIVER PARTITION WALL ASSEMBLY	TATA spare parts
399051003016	HANDHOLD TUBE	TATA spare parts
399051003017	HANDHOLD STRAPS	TATA spare parts
399051003018	HANDLE STRAP ASSY LOCAL SUPPLY_YELLOW SKO	TATA spare parts
399051003019	ROOF GRABRAIL TUBE(3600)38WB RHD RLB	TATA spare parts
399051003020	STANCHION PIPE WITH PVC SLEEVE	TATA spare parts
399051003021	STANCHION PIPE WITH PVC SLEEVE 5100MM	TATA spare parts
399051003022	STEPWELL BEND PARTITION_42WB SKOOL BUS	TATA spare parts
399051003023	HAND HOLD TUBE ASSY (GANGWAY ROOF)	TATA spare parts
399051003040	HANDHOLD TUBE WITH SLEEVE	TATA spare parts
399051003041	DRIVER PARTITION ASSY_COST REDUCTION	TATA spare parts
399051003043	GRAB RAIL TUBE WITH PVC SLEEVE_LN 5590.	TATA spare parts
399051003044	PASSENGER PARTITION ASSY_CR_STOP SWITCH	TATA spare parts
399051003051	DRIVER PARTITION ASSY	TATA spare parts
399051003052	ROOF STANCHION PIPE	TATA spare parts
399051003053	STEPWELL BEND PARTITION_2 SKOOL BUS	TATA spare parts
399051003055	STEP WELL PARTITION WALL ASSY	TATA spare parts
399051003056	ROOF STANCHION PIPE 2475MM LENGTH	TATA spare parts
399051003059	ROOF GRAB RAIL ASSEMBLY 4000MM	TATA spare parts
399051003063	STEP WELL PARTITION WALL	TATA spare parts
399051003066	STEP WELL PARTITION WALL - LHD	TATA spare parts
399051003067	STEP WELL PARTITION WALL-LHD WITHOUT SRS	TATA spare parts
399051003070	HAND HOLD TUBE WITH PVC SLEEVE-692	TATA spare parts
399051003072	HAND HOLD TUBE WITH PVC SLEEVE	TATA spare parts
399051003073	DRIVER PARTITION ASSY WITH OUT TOP GLASS	TATA spare parts
399051003082	DRIVER PARTITION ASSY LAM. WHITE BOARD	TATA spare parts
399051003091	CONDUCTOR CABIN ASSY_2 FRONT DOOR	TATA spare parts
399051003098	STEP PARTITION MINI	TATA spare parts
399051003104	HAND HOLD TUBE WITH PVC SLEEVE	TATA spare parts
399051003109	HAND HOLD TUBE WITH PVC SLEEVE GRAY	TATA spare parts
399051003112	DRIVER PARTITION WALL ASSEMBLY	TATA spare parts
399051003114	HOCKEY STICK PARTITION WALL	TATA spare parts
399051003115	STEP WELL PARTITION WALL	TATA spare parts
399051003120	DRIVER PARTITION	TATA spare parts
399051003129	STEP WALL PARTITION WALL AIS 052 STEEL	TATA spare parts
399051003130	DRIVER PARTITION ASSY	TATA spare parts
399051003135	HAND HOLD TUBE WITH PVC SLEEVE 730	TATA spare parts
399051003136	HAND HOLD TUBE WITH PVC SLEEVE 450	TATA spare parts
399051003137	DRIVER PARTITION ASSY_SFC_31WB	TATA spare parts
399051003140	STEP WELL PARTITION	TATA spare parts
399051003143	DRIVER PARTITION WALL PROTECTION	TATA spare parts
399051003151	DRIVER PARTITION ASSY SENEGAL	TATA spare parts
399051003152	STEP WELL PARTITION WALL-LHD	TATA spare parts
399051003158	STEP WALL PARTITION LHD	TATA spare parts

399051003166	DRIVER PARTITION ASSY WITH FDSS	TATA spare parts
399051003167	CONDUCTOR CABIN ASSEMBLY_SENEGAL.	TATA spare parts
399051004002	HANDHOLD TUBE	TATA spare parts
399051004003	HANDHOLD TUBE	TATA spare parts
399051004005	PLATE	TATA spare parts
399051004006	HANDHOLD TUBE WITH PVC SLEEVE	TATA spare parts
399051004007	HANDHOLD TUBE RIGHT	TATA spare parts
399051004008	PARTITION WALL BEND_SKOOL BUS 42WB	TATA spare parts
399051004014	HAND HOLD TUBE FOR PARTITION	TATA spare parts
399051004015	HANDHOLD TUBE ASSEMBLY	TATA spare parts
399051004022	HAND HOLD TUBE	TATA spare parts
399051004023	HAND HOLD TUBE	TATA spare parts
399051004031	PARTITION WALL STRUCTURE ASSLY (LHD)	TATA spare parts
399051004032	HAND HOLD TUBE WITH PVC SLEEVE-682	TATA spare parts
399051004036	PARTITION WALL STRUCTURE ASSY	TATA spare parts
399051004038	SUPPORT TUBE CO DRIVER SIDE LN 134	TATA spare parts
399051004039	CO DRIVER HAND HOLD TUBE ASSY	TATA spare parts
399051004040	REAR HAND HOLD TUBE ASSY	TATA spare parts
399051004041	SUPPORT TUBE ASSY REAR SIDE LN 655	TATA spare parts
399051004042	HAND HOLD TUBE BOTH SIDE BEND ASSY	TATA spare parts
399051004043	SUPPORT TUBE DRIVER PARTITION 330	TATA spare parts
399051004044	SUPPORT TUBE DRIVER PARTITION 640 ASSY	TATA spare parts
399051004052	HAND HOLD AND SLEEVE ASSY	TATA spare parts
399051004054	PARTIOTION WALL STRUCTURE ASSEMBLY	TATA spare parts
399051004057	PARTITION WALL STRUCTURE ASSY	TATA spare parts
399051004058	HAND HOLD TUBE ASSY	TATA spare parts
399051004062	HAND HOLD TUBE WITH PVC SLEEVE 555	TATA spare parts
399051004066	HAND HOLD TUBE 1730MM	TATA spare parts
399051004067	HAND HOLD TUBE 1434MM	TATA spare parts
399051004068	HAND HOLD TUBE ASSEMBLY 1920MM	TATA spare parts
399051004069	HAND HOLD TUBE ASSEMBLY 560MM	TATA spare parts
399051004074	HAND HOLD TUBE FOR PARTITION	TATA spare parts
399051004077	HAND HOLD BEND TUBE_845	TATA spare parts
399051004087	HANDHOLD TUBE ASSEMBLY_620 BS6	TATA spare parts
399051063005	HANDHOLD TUBE	TATA spare parts
399051063009	GRAB RAIL 49 WB	TATA spare parts
399051063013	ROOF STANCTION PIPE	TATA spare parts
399051063020	HANDHOLD TUBE	TATA spare parts
399051063023	HAND HOLD SUPPORT TUBE ENG HOOD	TATA spare parts
399051064001	HANDHOLD TUBE	TATA spare parts
399051064010	HANDHOLD TUBE WITHOUT SLEEVE	TATA spare parts
399051064027	HAND HOLD TUBE DRIVER PARTITION	TATA spare parts
399051064028	HAND HOLD TUBE BEND DRIVER PARTITION	TATA spare parts
399051065002	HANDHOLD TUBE	TATA spare parts
399051065005	HAND HOLD TUBE RIGHT DRIVER PARTITION	TATA spare parts
399051065006	HAND HOLD TUBE DRIVER PARTITION	TATA spare parts
399051083002	CRUTCH HOLDING SUPPORT PLATE	TATA spare parts

399051085002	PARTITION WALL ATTACHMENT SUPPORT	TATA spare parts
399051214001	PARTITION WALL GLASS	TATA spare parts
399051214002	PROFILE TO SUPPORT GLASS ON TOP AND BOTT	TATA spare parts
399051214003	C CHANNEL BESIDES GLASS	TATA spare parts
399051214004	PROFILE TO SUPPORT GLASS AND HARDBOARD	TATA spare parts
399051214005	PROFILE TO SUPPORT GLASS AND HARDBOARD	TATA spare parts
399051214006	ALUMINIUM PROFILE FOR PASSENG PARTITION	TATA spare parts
399051214007	ALUMINIUM PROFILE FOR PASS PARTITION 695	TATA spare parts
399051214008	ALUMINIUM FOR PASSENGER STEP PARTITION	TATA spare parts
399051214012	ALUMINIUM PROFILE FOR DRIVER PARTITION	TATA spare parts
399051214013	AL PROFILE FOR DRIVER PARTITION	TATA spare parts
399051214016	ALUMINIUM PROFILE FOR DRIVER PARTITION	TATA spare parts
399051214017	ALUMINIUM PROFILE 371MM	TATA spare parts
399051214018	ALUMINIUM C PROFILE 590MM	TATA spare parts
399051215001	ALUMINUM TUBE PROFILE FOR DRIVER PARTIT	TATA spare parts
399051215002	ALUMINUM PROFILE FOR DRIVER PARTITION	TATA spare parts
399051215004	C-CHANNEL_DRI PA GLASS RH&LH_POW COATED	TATA spare parts
399051215007	ALUMINIUM H PROFILE FOR PARTITION 739	TATA spare parts
399051234001	DRIVER PARTITION WALL GLASS	TATA spare parts
399051244001	LAMINATED HARDBOARD FOR DRIVER PARTITION	TATA spare parts
399051244003	LAMINATED WHITE BOARD	TATA spare parts
399051303005	STOP REQUEST BUTTON SWITCH	TATA spare parts
399051304001	DRIVER PARTITION WALL GLASS	TATA spare parts
399051394012	GRAB RAIL 3150	TATA spare parts
399051394013	GRAB RAIL 1900	TATA spare parts
399052002001	ENGINE HOOD FRP ASSY	TATA spare parts
399052002005	DASHBOARD & SIDE PILLAR ASSEMBLY	TATA spare parts
399052002006	ENGINE HOOD FRP ASSEMBLY LHD	TATA spare parts
399052002008	ENGINE HOOD ASSY	TATA spare parts
399052002017	ENGINE HOOD ASSEMBLY	TATA spare parts
399052002018	CABINET (BELOW STREATCHER)	TATA spare parts
399052003002	ENGINE COVER HINGE ASSEMBLY	TATA spare parts
399052003003	COVER LATCH ASSEMBLY	TATA spare parts
399052003004	DASHBOARD PANEL PLATE LH ASSY	TATA spare parts
399052003006	CLUTCH OIL TANK CLOSING COVER	TATA spare parts
399052003008	GLOVE BOX ASSEMBLY	TATA spare parts
399052003009	TRANSMISSION CASE FINISHING ASSY	TATA spare parts
399052003014	FRP ENGINE HOOD WITH INSULATION-RHD	TATA spare parts
399052003017	FRP DASH& AC CONTROL CLUSTER ASSY-LHD	TATA spare parts
399052003018	DASHBOARD ASSEMBLY	TATA spare parts
399052003019	EURO-4 ENGINE HOOD ASSEMBLY	TATA spare parts
399052003020	PANEL PLATE ASSY-RH- EME DOOR_BS-IV	TATA spare parts
399052003021	FRP ENGINE HOOD WITH INSULATION-LHD	TATA spare parts
399052003022	FRP ENGINE HOOD WITH INSULATION RHD	TATA spare parts
399052003025	ENGINE HOOD ASSEMBLY-4T	TATA spare parts
399052003026	DASHBOARD ASSY	TATA spare parts
399052003027	ENGINE HOOD ASSY	TATA spare parts

399052003028	DASHBOARD ASSEMBLY	TATA spare parts
399052003031	MAIN ASSEMBLY OF INT & EXT ENG SFC	TATA spare parts
399052003032	DASHBOARD ASSEMBLY-SFC	TATA spare parts
399052003035	FRP ENGINE HOOD WITH INSULATION-RHD	TATA spare parts
399052003040	MAIN ENGINEHOOD ASSEMBLY_AMB	TATA spare parts
399052003042	FRP FRONT INNER ASSEMBLY	TATA spare parts
399052003043	LH & RH DASHBOARD ASSEMBLY LCLCV	TATA spare parts
399052003044	FRP DASHBOARD WITH DIFFUSERS.	TATA spare parts
399052003045	FRP DASHBOARD WITH DIFFUSERS RHD	TATA spare parts
399052003048	TOOL BOX ASSEMBLY	TATA spare parts
399052003051	FRP REAR INNER SUB ASSY WITHOUT SPEAKER	TATA spare parts
399052003052	GEAR LEVER EXTENSION FINISHING COVER	TATA spare parts
399052003053	ENGINE HOOD SUB ASSEMBLY-LHD	TATA spare parts
399052003058	FRP ABOVE DRIVER DOOR FITMENT ASSY	TATA spare parts
399052003059	FRP FRONT INTERNAL SUB ASSEMBLY	TATA spare parts
399052003060	FRP DASHBOARD ASSLY	TATA spare parts
399052003061	ENGINEHOOD AND PODEST ASSLY	TATA spare parts
399052003065	FRP FRONT INNER ASSY	TATA spare parts
399052003068	DASHBOARD ASSEMBLY (CHEMITO)	TATA spare parts
399052003070	ENGINE HOOD ASSEMBLY DETAIL	TATA spare parts
399052003086	LCV FRP 1210 PNEUMATIC DOOR ASSEMBLY	TATA spare parts
399052003098	ITS BOX FINISHING COVER ASSY	TATA spare parts
399052003099	ENGINE HOOD & PODEST SUB ASSEMBLY	TATA spare parts
399052003100	INTERNAL FRP ABOVE DRIVER	TATA spare parts
399052003103	ENGINE HOOD PODEST ASSY-4T	TATA spare parts
399052003106	REAR INNER & SPEAKER GRILL ASSY	TATA spare parts
399052003107	DASHBOARD&INSULASSY713RHDNONA/C	TATA spare parts
399052003108	LCV-EX 912RHD NONAC DASHBOARD ASSY	TATA spare parts
399052003109	TOOL BOX & HINGES ASSEMBLY ĳ PP	TATA spare parts
399052003113	FRONT INNER ASSEMBLY	TATA spare parts
399052003114	LCV EX DASHBOARD & ENGINEHOOD ASSY	TATA spare parts
399052003115	LCV-EX REAR INNER & SPEAKER GRILL ASSY	TATA spare parts
399052003116	LCV-EX(RHD) FRONT INNER ASSEMBLY	TATA spare parts
399052003117	ENGINEHOOD ASSLY -LCV 29WB	TATA spare parts
399052003120	DASHBOARD SUB ASSLY-LCV29WB	TATA spare parts
399052003138	LCV EX DASHBOARD & ENGINEHOOD ASSY	TATA spare parts
399052003142	LCV EX FRONT INNER SUB ASSY_AC	TATA spare parts
399052004003	PANEL PLATE ASSEMBLY	TATA spare parts
399052004004	PANEL PLATE ASSY	TATA spare parts
399052004007	PANEL PLATE ASSEMBLY - RH	TATA spare parts
399052004012	REXENE COVER FOR GEAR LEVER	TATA spare parts
399052004013	PANEL PLATE ASSYĳ RH LHD MC	TATA spare parts
399052004017	EURO-4 ENGINE HOOD SUB-ASSEMBLY	TATA spare parts
399052004018	EURO-4 FUSE FLAP ASSEMBLY	TATA spare parts
399052004019	EURO-4 GLOVE BOX FLAP ASSEMBLY	TATA spare parts
399052004020	EURO-4 GEAR SHIFT LEVER FINISHING ASSY	TATA spare parts
399052004023	ENGINE HOOD SUB ASSEMBLYĳ\	TATA spare parts

399052004025	ASSEMBLY OF INT & EXT ENGINEHOOD SFC	TATA spare parts
399052004029	ASSEMBLY OF INT & EXT ENGINEHOOD	TATA spare parts
399052004030	ECU FRONT FLAP ASSEMBLY_AMB	TATA spare parts
399052004037	ENGINEHOOD ASSY (EXT. AND INT.)	TATA spare parts
399052004038	PODEST ASSY. WITH INSULATION	TATA spare parts
399052004044	ENGINE HOOD PODEST ASSY	TATA spare parts
399052004054	GLOVE BOX FLAP ASSEMBLY	TATA spare parts
399052004055	FUSE BOX FLAP ASSEMBLY	TATA spare parts
399052004059	LCV-EX FRP FRT INNER CABNT & FLAP ASSY	TATA spare parts
399052004061	LCV EX DASHBOARD ADDON ASY	TATA spare parts
399052004062	LCV EX ENGINE HOOD EXT & INT ASSY	TATA spare parts
399052004063	LCV-EX ABS FRT INNER CABNT & FLAP ASSY	TATA spare parts
399052083002	ENGINE HOOD STAY CHAIN CLAMP	TATA spare parts
399052083004	GEAR SHIFT CONTROL PLATE	TATA spare parts
399052083005	PANEL PLATE ASSY RH	TATA spare parts
399052083006	GEAR SHIFT CONTROL PLATE	TATA spare parts
399052083016	PANEL PLATE-LH- EME DOOR_BS-IV	TATA spare parts
399052083020	PANEL PLATE-LH- NON EME-DOOR_BS-IV	TATA spare parts
399052083024	PANEL PLATE LH¿ EME DOOR MC	TATA spare parts
399052083040	PARTITION PANELLING SHEET	TATA spare parts
399052083042	PARTITION PANELLING LH SHEET	TATA spare parts
399052083056	PARTITION PANELLING MIDDLE SHEET	TATA spare parts
399052083057	PARTITION SMALL PANELLING RH SHEET	TATA spare parts
399052083058	PARTITION PANELLING LH SHEET	TATA spare parts
399052083063	GEAR SHIFT CONTROL SUB PLATE	TATA spare parts
399052083070	PANELPLATELH	TATA spare parts
399052084002	ENGINE HOOD LOCK SUPPORT	TATA spare parts
399052084008	PANEL PLATE RH	TATA spare parts
399052084016	PANEL PLATE LH	TATA spare parts
399052084017	PANEL PLATE-LH- EMERGENCY DOOR	TATA spare parts
399052084026	PANEL PLATE-LH	TATA spare parts
399052084031	PANEL PLATE -RH	TATA spare parts
399052084032	PANEL PLATE-LH- EMER DOOR_ MOBILE CHARGER	TATA spare parts
399052084033	PANEL PLATE - LH	TATA spare parts
399052084034	PANEL PLATE-RH- EME DOOR_BS-IV	TATA spare parts
399052085003	PANEL PLATE LH	TATA spare parts
399052085016	PANEL PLATE LH	TATA spare parts
399052085021	FINISHING COVER REINFORCEMENT-1	TATA spare parts
399052085022	FINISHING COVER REINFORCEMENT-2	TATA spare parts
399052262007	AC EVAPORATOR COVER	TATA spare parts
399052262012	PCB & CANTROLL COVER	TATA spare parts
399052262016	SNORKEL COVER ASSY	TATA spare parts
399052263001	PANEL CONTOUR FIBER	TATA spare parts
399052263002	EXTERNAL ENGINE HOOD	TATA spare parts
399052263003	INTERNAL ENGINE HOOD	TATA spare parts
399052263004	WINDSHIELD COLUMN(RH)	TATA spare parts
399052263005	WINDSHIELD COLUMN (LH)	TATA spare parts

399052263006	PANEL ASSEMBLY	TATA spare parts
399052263007	EXTERNAL ENGINE HOOD	TATA spare parts
399052263008	INTERNAL ENGINE HOOD	TATA spare parts
399052263011	PANEL CONTOUR FIBER	TATA spare parts
399052263016	FRP DASH BOARD WITH AIR DUCT INLET	TATA spare parts
399052263017	BASE PANEL ASSEMBLY	TATA spare parts
399052263018	FRP DASHBOARD WITH AIR DUCT INLET	TATA spare parts
399052263019	PANEL CONTOUR FIBER	TATA spare parts
399052263020	EXTERNAL ENGINE HOOD	TATA spare parts
399052263021	INTERNAL ENGINE HOOD	TATA spare parts
399052263024	FRP NACELLE (STEERING FINISH)	TATA spare parts
399052263027	INTERNAL ENGINE HOOD	TATA spare parts
399052263038	EXTERNAL ENGINE HOOD-LHD	TATA spare parts
399052263039	FRP INTERNAL ENGINE HOOD-LHD	TATA spare parts
399052263040	COVER FOR O2 DELIVERY SYSTEM	TATA spare parts
399052263041	AC HOSE COVER	TATA spare parts
399052263042	AC HOSE COVER CONNECTOR	TATA spare parts
399052263054	AC EVAPORATOR COVER FLAP	TATA spare parts
399052263056	FLOOD LAMP FRP COVER	TATA spare parts
399052263058	GENSET COVER ASSY	TATA spare parts
399052263063	ROOF TOP CABINET ASSY	TATA spare parts
399052263068	O2 CYLINDRE COVER (VERTICLE)	TATA spare parts
399052263069	NIBP UNIT BOX ASSY	TATA spare parts
399052263070	TAIL LAMP GRILL RH	TATA spare parts
399052263071	TAIL LAMP GRILL LH	TATA spare parts
399052263072	HEAD LAMP GRILL-RH	TATA spare parts
399052263073	HEAD LAMP GRILL-LH	TATA spare parts
399052263114	A-PILLAR RH	TATA spare parts
399052263115	A-PILLAR LH	TATA spare parts
399052263119	LCV EX FUSE BOX FLAP (FRP)	TATA spare parts
399052263121	DASHBOARD LCV-29WB	TATA spare parts
399052263124	DASHBOARD BOX FLAP-LCV29WB	TATA spare parts
399052263125	DASHBOARD MAINTENANCE FLAP-LCV29WB	TATA spare parts
399052264001	FRP AIR DUCT FOR DASH BOARD	TATA spare parts
399052264003	EURO-4 DASHBOARD	TATA spare parts
399052264006	EURO-4 ENGINE HOOD PODEST	TATA spare parts
399052264008	ENGINE HOOD PODEST-4T	TATA spare parts
399052264009	DASHBOARD	TATA spare parts
399052264013	SFC FRP PODEST	TATA spare parts
399052264014	FRP DASHBOARD FOR SFC	TATA spare parts
399052264015	CLUSTER MAINTENANCE FLAP FOR SFC	TATA spare parts
399052264016	CNG FRP REAR INTERNAL	TATA spare parts
399052264018	ENGINE HOOD PODEST 4T	TATA spare parts
399052264019	ENGINE HOOD PODEST_ AMB	TATA spare parts
399052264020	FRP DASHBOARD_ AMB	TATA spare parts
399052264023	LH DASHBOARD JOINERY	TATA spare parts
399052264024	RH DASHBOARD JOINERY	TATA spare parts



399052264032	FRP FRONT INTERNAL	TATA spare parts
399052264033	NEW DASHBOARD FRP	TATA spare parts
399052264035	FRP DASHBOARD FUSE BOX FLAP	TATA spare parts
399052264064	LCV FRP 1210 PNEUMATIC DOOR BOX	TATA spare parts
399052264066	LCV FRP 1210 PNEUMATIC DOOR BOX FLAP	TATA spare parts
399052264067	DASHBOARD	TATA spare parts
399052264069	ITS BOX FINISHING COVER	TATA spare parts
399052264070	ITS BOX FINISHING BOX	TATA spare parts
399052265001	EURO-4 ENGINE HOOD EXTERNAL	TATA spare parts
399052265002	EURO-4 ENGINE HOOD INTERNAL	TATA spare parts
399052265003	EURO-4 FUSE FLAP	TATA spare parts
399052265004	EURO-4 GLOVE BOX FLAP	TATA spare parts
399052265005	EURO-4 GEAR SHIFT LEVER FINISHING	TATA spare parts
399052265009	ENGINE HOOD EXTERNAL	TATA spare parts
399052265010	ENGINE HOOD INTERNAL	TATA spare parts
399052265011	EXTERNAL ENGINEHOOD-SFC	TATA spare parts
399052265012	INTERNAL ENGINEHOOD-SFC	TATA spare parts
399052283004	ENGINE HOOD SUPPORT CHAIN BELT ASSEMBLY	TATA spare parts
399052303001	AIR DIFFUSER FINISH	TATA spare parts
399052304002	FUSE BOX FLAP LOCK FINISHING	TATA spare parts
399052323005	REAR INNER CENTER PART	TATA spare parts
399052323006	REAR INNER RH PART	TATA spare parts
399052323007	REAR INNER LH PART	TATA spare parts
399052323008	REAR DOOR LOCK COVER	TATA spare parts
399052323015	ABS A¿ PILLAR LH RAL 7040	TATA spare parts
399052323016	ABS A PILLAR RH RAL 7040	TATA spare parts
399052323021	EURO 4 GEAR FINISHING ABS COVER	TATA spare parts
399052323027	LCV EX-A PILLAR RH ABS	TATA spare parts
399052323028	LCV EX- A PILLAR LH ABS	TATA spare parts
399052323029	ABS DRIVER FOOTSTEP YELLOW BS6	TATA spare parts
399052324003	REAR CAMERA COVER	TATA spare parts
399052324023	LCV EX-ABS REAR INNER	TATA spare parts
399052325004	LCV-EX FRONT INNER	TATA spare parts
399052333001	REXENE BELLOW GR SHIFT LEVER	TATA spare parts
399052333004	SPONGE FOR GEAR SHIFT CONTROL PLATE	TATA spare parts
399052335001	GEAR LEVER¿ EXT FINISHING ACCESSORIES	TATA spare parts
399052335005	LCV EX STEERING COLUMN FINISHING	TATA spare parts
399053002027	RH MODULAR HATRACK ASSY 38WB RHD/LHD SD	TATA spare parts
399053002030	HAT RACK ASSY_ DRIVER SIDE & CO DRIVER SI	TATA spare parts
399053002031	HAT RACK ASSEMBLY LH SIDE_ COST REDUCTION	TATA spare parts
399053002034	HAT RACK ASSEMBLY_ 42WB	TATA spare parts
399053002036	HATRACK ASSEMBLY RH SIDE 6153	TATA spare parts
399053002040	HAT RACK ASSEMBLY(MODULAR TYPE)	TATA spare parts
399053002041	HATRACK ASSEMBLY (MODULARTYPE) CO-DRIVER	TATA spare parts
399053002048	HATRACK ASSY	TATA spare parts
399053002049	HATRACK ASSY	TATA spare parts
399053002052	MODULAR HATRACK ASSY RH&LH 42WB	TATA spare parts

399053002053	HATRACK ASSY SFC 31	TATA spare parts
399053002056	HATRACK ASSY(MOULDED) 3.92M	TATA spare parts
399053002058	HATRACK ASSEMBLY LH SIDE 4772	TATA spare parts
399053003005	LUGGAGE RACK SUPPORT ASSY.	TATA spare parts
399053003006	HATRACK PADDING ASSEMBLY_SKOOL BUS	TATA spare parts
399053003010	HATRACK ASSEMBLY	TATA spare parts
399053003035	HAT RACK ROOF SUPPORT ASSEMBLY	TATA spare parts
399053003036	HATRACK ASSY 1832 LN	TATA spare parts
399053003040	GRILL HATRACK ASSY-LH	TATA spare parts
399053003041	GRILL HATRACK ASSY-RH	TATA spare parts
399053003042	GRILL HATRACK ASSY-LH	TATA spare parts
399053003043	GRILL HATRACK ASSY-RH	TATA spare parts
399053083012	HATRACK CROSS BRACKET SUPPORT	TATA spare parts
399053083014	PVC LAMINATED G.I SHEET COLOR EV01	TATA spare parts
399053084001	MS BRACKET FOR LUGGAGE RACK SUPPORT	TATA spare parts
399053084002	PLYWOOD HOLDING BRACKET	TATA spare parts
399053214001	ALUMINUM PROFILE (LUGGAGE RACK)	TATA spare parts
399053303001	LUGGAGE-RACK ASSEMBLY COVER	TATA spare parts
399053323001	HAT RACK END COVERS	TATA spare parts
399053324001	PP SUPPORT BRACKET COVERING_ABS	TATA spare parts
399054003001	WINDOW GUARD RAIL	TATA spare parts
399054003004	WIN GUARD RAIL TUBE ASSY 19.05DIA_7300MM	TATA spare parts
399054003005	WIN GUARD RAIL TUBE ASSY 19.05DIA_6170MM	TATA spare parts
399054003006	WIN GUARD RAIL TUBE ASSY 19.05DIA_6020MM	TATA spare parts
399054003007	WIN GUARD RAIL TUBE ASSY 19.05DIA_5330MM	TATA spare parts
399054003008	WIN GUARD RAIL TUBE ASSY 19.05DIA_6470MM	TATA spare parts
399054003023	WIRE MESH NEAR REAR SIDE WINDOW(1139X838)	TATA spare parts
399054003024	WIRE MESH NEAR DRIVER DOOR	TATA spare parts
399054003025	WIRE MESH (1239X838)	TATA spare parts
399054003026	WIRE MESH (WINDOW 1339X838)	TATA spare parts
399054003027	WIRE MESH CO DRIVER	TATA spare parts
399054063001	WINDOW GUARD RAIL M.S TUBE LENGTH 4354	TATA spare parts
399054063002	WINDOW GUARD RAIL M.S TUBE LENGTH 1072	TATA spare parts
399054063003	WINDOW GUARD RAIL M.S TUBE LENGTH 1054	TATA spare parts
399054063004	WINDOW GUARD RAIL M.S TUBE LENGTH 5500	TATA spare parts
399054063005	WINDOW GUARD RAIL M.S TUBE LENGTH 4905	TATA spare parts
399054063006	WINDOW GUARD RAIL TUBE ASSEMBLY (DRIVER	TATA spare parts
399054063007	GUARD RAIL	TATA spare parts
399054063008	GUARD RAIL	TATA spare parts
399054063009	GUARD RAIL	TATA spare parts
399054063010	GUARD RAIL	TATA spare parts
399054063011	WINDOW GUARD RAIL	TATA spare parts
399054063012	WINDOW GUARD RAIL	TATA spare parts
399054063013	WINDOW GUARD RAIL (DRIVER SIDE)	TATA spare parts
399054063024	WINDOW GUARD RAIL TUBE DIA19.05 4790MM	TATA spare parts
399054063025	WINDOW GUARD RAIL TUBE	TATA spare parts
399054063027	WINDOW GUARD RAIL TUBE DIA19.05_4900MM	TATA spare parts

399054063028	WINDOW GUARD RAIL TUBE DIA19.05_1270MM	TATA spare parts
399054063029	WINDOW GUARD RAIL TUBE DIA15.88_75MM	TATA spare parts
399054063030	WINDOW GUARD RAIL TUBE	TATA spare parts
399054063031	WINDOW GUARD RAIL TUBE DIA19.05_1120MM	TATA spare parts
399054063032	WINDOW GUARD RAIL TUBE DIA19.05_1680MM	TATA spare parts
399054063033	WINDOW GUARD RAIL TUBE DIA19.05_2820MM	TATA spare parts
399054063034	WINDOW GUARD RAIL TUBE	TATA spare parts
399054063036	WINDOW GUARD RAIL TUBE 2420MM	TATA spare parts
399054063037	WINDOW GUARD RAIL_2580 LENGTH	TATA spare parts
399054063038	WINDOW GUARD RAIL_2925 LENGTH	TATA spare parts
399054064003	WIDNDOW GUARD RAIL CONNECT	TATA spare parts
399054064004	GUARD RAIL	TATA spare parts
399054064016	WINDOW GAURD RAIL TUBE DIA12.8 75	TATA spare parts
399054264001	DASHBOARD	TATA spare parts
399054912079	WINDOW GAURD RAIL ASSY 42 WB	TATA spare parts
399056083004	SIDE INTERNAL REVETMENT	TATA spare parts
399056083061	SIDE INT PANLING FRONT TOP CORNER SIDE	TATA spare parts
399056083079	SIDE INTERNAL PANELING PPGI	TATA spare parts
399056083081	SIDE INTERNAL PANELING 900X560X0.65	TATA spare parts
399056083085	SIDE INTERNAL PANEL BETWEEN WINDOW	TATA spare parts
399056083086	SIDE INT PAEL SHT BESIDE CODRVER FIX WIN	TATA spare parts
399056083094	PANEL PLATE ABOVE CO -DRIVER	TATA spare parts
399056083095	SIDE INTERNAL PANELING SHEET PVC 40X645	TATA spare parts
399056083127	SIDE INTERNAL PANELLING LH SIDE	TATA spare parts
399056083134	SIDE INTERNAL PANELING	TATA spare parts
399056083136	SIDE INTERNAL PANELING	TATA spare parts
399056083215	SIDE INTL PANEL ABOVE PASS DOOR AIS052	TATA spare parts
399056912048	SIDE INTERNAL PANELLING 38WB	TATA spare parts
399057083016	ROOF INTERNAL PANELING RH REAR SHEET	TATA spare parts
399057083017	ROOF INTERNAL PANELING RH FRONT SHEET	TATA spare parts
399057083018	ROOF INTERNAL PANELING RH MIDDLE SHEET	TATA spare parts
399057083019	ROOF INTERNAL PANELING LH FRONT SHEET	TATA spare parts
399057083021	ROOF INTERNAL PANELING LH REAR SHEET	TATA spare parts
399057083022	ROOF INTERNAL PANELING RH SHEET	TATA spare parts
399057083029	INT_ROOF PANELING RH SHEET_42WB	TATA spare parts
399057083069	ROOF INT PANELING REAR SHEET_1225X1170MM	TATA spare parts
399057083072	ROOF INTERNAL PANELING LH FRONT SHEET	TATA spare parts
399057083073	ROOF INTERNAL PANELING LH FRONT SHEET	TATA spare parts
399057083074	ROOF INTERNAL PANELING LH FRONT SHEET	TATA spare parts
399057083075	ROOF INTERNAL PANELING LH FRONT SHEET	TATA spare parts
399057083125	ROOF INTERNAL PANEL	TATA spare parts
399057083126	ROOF INTERNAL PANEL	TATA spare parts
399057083127	ROOF INTERNAL PANEL	TATA spare parts
399057083128	ROOF INTERNAL PANEL	TATA spare parts
399057083129	ROOF INTERNAL PANEL	TATA spare parts
399057083325	ROOF INTL PANEL_PVC GI-2020	TATA spare parts
399057083326	ROOF INTL PANEL_PVC GI-1910	TATA spare parts

399057083327	ROOF INTL PANEL_PVC GI-1893	TATA spare parts
399057083443	ROOF INTL PANEL_PVC GI-1155	TATA spare parts
399058003002	FRONT FACE MARCOPOLO LOGO AND DOME	TATA spare parts
399058003003	REAR MARCOPOLO LOGO	TATA spare parts
399058003004	FRONT NO. PLATE	TATA spare parts
399058003005	SCHOOL BUS INSIGNIA	TATA spare parts
399058003006	WHITE REFLECTIVE TAPE(50MM WIDTH)2MTS	TATA spare parts
399058003007	RED REFLECTIVE TAPE 50 MM WIDTH 2MTS	TATA spare parts
399058003008	REAR FACE MARCOPOLO DOME	TATA spare parts
399058003009	STARBUS DECAL	TATA spare parts
399058003012	FRONT LICENSE PLATE ASSY	TATA spare parts
399058003013	REAR LICENSE PLATE ASSLY	TATA spare parts
399058003019	75 SPEED INDICATING STICKER	TATA spare parts
399058083003	REAR LICENSE PLATE YELLOW	TATA spare parts
399058083004	REAR LICENSE PLATE WHITE	TATA spare parts
399058084003	FRONT NUMBER PLATE MTG. HINGES	TATA spare parts
399058183001	BUMPER STEP PLATE	TATA spare parts
399058183002	REAR NO. PLATE	TATA spare parts
399058183004	REAR NUMBER PLATE	TATA spare parts
399058183008	AIR INTAKE CANOPY	TATA spare parts
399058183010	ALUMINIUM PLATE	TATA spare parts
399058263011	FRP WHEEL ARCH REAR RH & LH	TATA spare parts
399058333001	TATA DOME STICKER FRONT	TATA spare parts
399058333002	TATA DOME STICKER REAR	TATA spare parts
399058333006	TATA STARBUS FONT DECAL	TATA spare parts
399058333038	SENBUS STICKER FRONT	TATA spare parts
399058333041	SENBUS STICKER REAR	TATA spare parts
399058333042	TATA CITYRIDE FONT DECAL_339X109_STD	TATA spare parts
399058333043	CITYRIDE EX SIDE & REAR VINYL STICKER	TATA spare parts
399058333044	CITYRIDE EX FRONT VINYL STICKER	TATA spare parts
399058903001	T-EMBLEM (TML PART)	TATA spare parts
399058962015	DECAL KIT ASSEMBLY_LCV-EX_HOP ON HOP OFF	TATA spare parts
399059003001	INTERNAL ABS ABOVE DRIVER ASSEMBLY	TATA spare parts
399059003002	REAR INNER ABS WITH SPEAKER GRILL	TATA spare parts
399059003003	ABS FRONT INTERNAL SUB ASSY DETAIL	TATA spare parts
399059003006	CURTAIN MOUNTING BRACKET LH	TATA spare parts
399059003007	CURTAIN MOUNTING BRACKET RH	TATA spare parts
399059003009	DESTINATION BOARD BOX ASSEMBLY	TATA spare parts
399059003017	ABS TOOL BOX & HINGE ASSEMBLY	TATA spare parts
399059003022	ABS REAR INTERNAL ASSEMBLY FOR RLB	TATA spare parts
399059003023	ABS PARTITION SUB ASSLY_RHD BS6	TATA spare parts
399059003027	ABS FRONT INNER ASSY IB	TATA spare parts
399059003029	ABS PARTITION SUB ASSLY_LHD_EVO-03 BS6	TATA spare parts
399059004001	STOP¿ STCIKER¿ (SKOOL BUS)	TATA spare parts
399059004003	ABS PARTITION STR ASSLY_RHD BS6	TATA spare parts
399059004006	ABS PARTITION STR ASSLY_LHD BS6	TATA spare parts
399059264001	ECU COVER FRAME	TATA spare parts

399059264002	ECU FLAP	TATA spare parts
399059303004	ACRYLIC (CLEAR)	TATA spare parts
399059303005	ACRYLIC (CLEAR)	TATA spare parts
399059303013	CURTAIN HOOK ASSY	TATA spare parts
399059303025	SEAT BELT FINISHING COVER RAL 7040	TATA spare parts
399059303026	PANIC SWITCH FINISHING COVER	TATA spare parts
399059304001	PVC SCREW CAP WITH WASHER	TATA spare parts
399059323001	ABS-LCV A- PILLAR-LH	TATA spare parts
399059323002	ABS-LCV A- PILLAR-RH	TATA spare parts
399059323004	ABS 3 POINT SEAT BELT FINISHING COVER	TATA spare parts
399059323013	PNEUMATIC CYLINDER COVER BOX	TATA spare parts
399059324004	INTERNAL ABS COVER ABOVE DRIVER	TATA spare parts
399059324005	REAR INTERNAL REVETMENT	TATA spare parts
399059324022	ABS COVER FOR PARTITION_LH BS6	TATA spare parts
399059324023	ABS COVER FOR PARTITION_RH BS6	TATA spare parts
399059324029	ABS COVER FOR PARTITION_RH_EVO-03	TATA spare parts
399059324030	ABS COVER FOR PARTITION_LH_EVO-03	TATA spare parts
399059333001	EMERGENCY DOOR STICKER	TATA spare parts
399059333004	SKOOL STICKER	TATA spare parts
399059333005	DECAL STICKER 42 WB STD BUS	TATA spare parts
399059333006	STAR BUS DECAL	TATA spare parts
399059333007	EURO II TCIC STICKER	TATA spare parts
399059333008	ABS STICKER	TATA spare parts
399059333009	EMERGENCY EXIT STICKER	TATA spare parts
399059333013	DECAL STICKER_34 SINGLE DOOR	TATA spare parts
399059333014	STICKER FOR CNG BUS-1	TATA spare parts
399059333015	STICKER FOR CNG BUS-2	TATA spare parts
399059333016	TCIC STICKER	TATA spare parts
399059333021	EMERGENCY STICKER_FRENCH LETTERS_190X80	TATA spare parts
399059333024	CURTAIN FABRIC BLUE 625X900	TATA spare parts
399059333025	CURTAIN FABRIC BLUE 640X1610	TATA spare parts
399059333026	CURTAIN FOR LH&RH WIN 890X905_ARMY AMBU	TATA spare parts
399059333027	CURTAIN ON REAR DOORS 694X731_ARMY AMBU	TATA spare parts
399059333028	CURTAIN FOR COMM.WINDOW_ARMY AMBU	TATA spare parts
399059333030	EXIT STICKER	TATA spare parts
399059333041	ENJOYCITY REAR DECAL 875X580	TATA spare parts
399059333042	ENJOYCITY LH/RH DECAL 1715X1070	TATA spare parts
399059912006	DECAL STICKER ASSY_49WB( LH AND RH)	TATA spare parts
399059912007	DECAL STICKER ASSY 42 SINGLE DOOR	TATA spare parts
399059962002	REFLECTIVE TAPE KIT 42WB SKL STD	TATA spare parts
399059962003	REFLECTIVE TAPE KIT_49WB_SKL_STD	TATA spare parts
399059962004	REFLECTIVE TAPE KIT_31WB_STD	TATA spare parts
399059962005	REFLECTIVETAPEKIT34WBSKL	TATA spare parts
399059962006	REFLECTIVE TAPE KIT 49WB EX STD	TATA spare parts
399059962008	REFLECTIVE TAPE KIT_42WB_EX_STD	TATA spare parts
399059962010	REFLECTIVE TAPE KIT_34WB_W/O ED_EX_STD	TATA spare parts
399059962011	REFLECTIVE TAPE KIT_42WB_W/O ED_EX_STD	TATA spare parts

399059962012	REFLECTIVE TAPE KIT_34WB_W/O EME_DOM	TATA spare parts
399059962014	REFLECTIVE TAPE KIT_42WB_SKL_STD_AIS-153	TATA spare parts
399059963001	SPARK DECAL STICKER KIT PART LH & RH SID	TATA spare parts
399060003003	EXT REARVIEW MIRROR SUPPORT ASSEMBLY	TATA spare parts
399060084001	ERVM CLAMP SUPPORT	TATA spare parts
399060233001	EXTERNAL REAR VIEW MIRROR RH	TATA spare parts
399060233002	EXTERNAL REAR VIEW MIRROR LH	TATA spare parts
399060373001	MIRROR SUPPORTING ARM	TATA spare parts
399060373002	MIRROR SUPPORTING ARM	TATA spare parts
399062004005	EMERGENCY WINDOW HAMMER ASSEMBLY	TATA spare parts
399062304001	EMERGENGE HAMMER COVER	TATA spare parts
399062304003	HAMMER IDENTIFICATION STICKER	TATA spare parts
399062333001	EMERGENCY EXIT STICKER FOR GLASS BREAKIN	TATA spare parts
399062333002	EMERGENCY EXIT STICKER	TATA spare parts
399064003009	DRIVER OPENABLE WINDOW RH	TATA spare parts
399064003010	WINDOW RH 1095X790 SLIDING	TATA spare parts
399064003011	WINDOW RH 1195X790 SLIDING	TATA spare parts
399064003012	WINDOW RH 545X790 SLIDING	TATA spare parts
399064003013	WINDOW LH 545X790 SLIDING_RHD	TATA spare parts
399064003014	LH WINDOW SLIDING	TATA spare parts
399064003015	WINDOW LH 1087X790 SLIDING	TATA spare parts
399064003016	WINDOWLH309X314PEEP_RHD	TATA spare parts
399064003017	DRIVER DOOR WINDOW RH 623X743 SLIDING	TATA spare parts
399064003018	WINDOW SLIDING	TATA spare parts
399064003019	WINDOW LH 309X314 (FIXED)	TATA spare parts
399064003020	WINDOWRH1087X790SLIDING	TATA spare parts
399064003021	WINDOWRH1195X790SLIDING	TATA spare parts
399064003022	WINDOWRH460X790SLIDING	TATA spare parts
399064003023	WINDOWLH545X790SLIDING	TATA spare parts
399064003024	WINDOWLH1195X790SLIDING	TATA spare parts
399064003025	WINDOWLH1095X790SLIDING	TATA spare parts
399064003026	DRIVERDOORWINDOWLH623X743SLIDING	TATA spare parts
399064003027	DRIVEROPENABLEWINDOWLH280X636	TATA spare parts
399064003028	DRIVER OPENABLE WINDOW RH 280X636	TATA spare parts
399064003029	DRIVER DOOR WINDOW RH 623X738 SLIDING	TATA spare parts
399064003030	WINDOW RH 1095X790MM	TATA spare parts
399064003031	WINDOW RH 1195X790MM	TATA spare parts
399064003032	WINDOW RH 545X790MM	TATA spare parts
399064003033	WINDOW LH 545X790MM	TATA spare parts
399064003034	WINDOW LH 1195X790	TATA spare parts
399064003035	WINDOW LH 1087X790	TATA spare parts
399064003036	FIXWINDOW(264X790)RH	TATA spare parts
399064003037	PEEP WINDOW	TATA spare parts
399064003038	FIXED WINDOW INFRONT OF DRIVER DOOR	TATA spare parts
399064003039	PEEP WINDOW	TATA spare parts
399064003040	WINDOW RH_1095X790MM_SLIDING_CANOPY	TATA spare parts
399064003041	WINDOW RH_1195X790MM_SLIDING_CANOPY	TATA spare parts

399064003042	WINDOW RH_545X790MM_SLIDING_CANOPY	TATA spare parts
399064003043	WINDOW LH_545X790MM_SLIDING_CANOPY	TATA spare parts
399064003044	WINDOW LH_1195X790MM_SLIDING_CANOPY	TATA spare parts
399064003045	WINDOW LH_1087X790MM_SLIDING_CANOPY	TATA spare parts
399064003046	WINDOW LH_395X790MM_SLIDING_CANOPY	TATA spare parts
399064003047	WINDOW LH_1045X790MM_SLIDING_CANOPY	TATA spare parts
399064003048	WINDOW LH_264X790_FIXED_CANOPY	TATA spare parts
399064003051	DRI.DOOR WINDOW RH 610X738	TATA spare parts
399064003052	WINDOW SLIDING	TATA spare parts
399064003055	WINDOW LH_395X790MM_SLIDING_RHD	TATA spare parts
399064003060	ASSY WINDOW	TATA spare parts
399064003061	DRI DOOR WINDOW 610X738 SLID TINTED RHD	TATA spare parts
399064003068	WINDOW RH 1095X790 SLIDING_GREEN TINTED	TATA spare parts
399064003069	ASSY WINDOW	TATA spare parts
399064003070	WINDOW LH_1087X790 SLIDING TINTED	TATA spare parts
399064003074	WINDOW RH 455X790MM SLIDING_CLEAR GL_RH	TATA spare parts
399064003075	EMRGNCY DOOR WINDOW RH 590X712 SLIDING	TATA spare parts
399064003076	WINDOW RH 995X790MM SLIDING_CLEAR GL_RH	TATA spare parts
399064003086	DRIVER DOOR WINDOW	TATA spare parts
399064003087	WINDOW PASSENGER SALOON RH	TATA spare parts
399064003088	FIXED WINDOW LH SIDE	TATA spare parts
399064003089	CO DRIVER WINDOW	TATA spare parts
399064003092	SCOOP WINDOW RH_280X636_SERVICABLE	TATA spare parts
399064003093	DRI DOOR WINDOW RH_610X738_SERVICABLE	TATA spare parts
399064003094	WINDOW RH_1095X790MM_SERVICABLE	TATA spare parts
399064003095	WINDOW RH_1195X790MM_SERVICABLE	TATA spare parts
399064003096	WINDOW LH_1095X790MM_SERVICABLE	TATA spare parts
399064003097	WINDOW LH_1195X790MM_SERVICABLE	TATA spare parts
399064003098	FIX WINDOW LH_264X790MM_SERVICABLE	TATA spare parts
399064003099	WINDOW LH (CO-DRI)_1087X790MM_SERVICABLE	TATA spare parts
399064003100	PEEP WINDOW LH_310X470MM_SERVICABLE	TATA spare parts
399064003102	WINDOW RH 345X790MM SLIDING_CLEAR	TATA spare parts
399064003103	WINDOW RH_345X790MM_SERVICABLE	TATA spare parts
399064003104	EME DOOR WINDOW RH 590X712_SLIDING_SERV	TATA spare parts
399064003105	WINDOW RH_455X790MM_SERVICABLE	TATA spare parts
399064003106	WINDOW RH 995X790_SLIDING_SERVICEABLE_CL	TATA spare parts
399064003108	WINDOW RH 995X790MM SERVICABLE	TATA spare parts
399064003111	WINDOW LH 395X790_SLIDING_SERVICE_CLEAR	TATA spare parts
399064003112	WINDOW LH 1045X790_SLIDING_SERVICE_CLEAR	TATA spare parts
399064003113	WINDOW RH 1095X790 13F23S SER CAN CLEAR	TATA spare parts
399064003114	WINDOW RH 1195X790 13F23S SER CAN CLEAR	TATA spare parts
399064003115	WINDOW RH 545X790 13F23S SER CAN CLEAR	TATA spare parts
399064003116	WINDOW LH 545X790 13F23S SER CAN CLEAR	TATA spare parts
399064003117	WINDOW LH 1195X790 13F23S SER CAN CLEAR	TATA spare parts
399064003118	FIX WINDOW 264X790 SERVICEABLE CAN CLEAR	TATA spare parts
399064003119	WINDOW LH 1087X790 13F23S SER CAN CLEAR	TATA spare parts
399064003122	PEEP WINDOW 310X470_SERVICEABLE_30%TINT	TATA spare parts

399064003123	WINDOW RH 1087X790_SLIDG_SERVICE_30%TINT	TATA spare parts
399064003124	FIX WINDOW 264X790_SERVICEABLE_30%TINT	TATA spare parts
399064003125	WINDOW RH 1195X790_SLIDG_SERVICE_30%TINT	TATA spare parts
399064003126	WINDOW RH 545X790_SLIDG_SERVICE_30%TINT	TATA spare parts
399064003127	WINDOW LH 545X790_SLIDG_SERVICE_30%TINT	TATA spare parts
399064003128	WINDOW LH 1195X790_SLIDG_SERVICE_30%TINT	TATA spare parts
399064003129	WINDOW LH 1095X790_SLIDG_SERVICE_30%TINT	TATA spare parts
399064003130	DD WINDOW LH 610X738_SLI_SERVICE_30%TINT	TATA spare parts
399064003131	SCOOP WINDOW LH 280X636_SERVICE_30%TINT	TATA spare parts
399064003132	WINDOW RH 455X790_SLIDG_SERVICE_30PERC T	TATA spare parts
399064003133	SCOOP WINDOW RH 276X645_SERVICE_30PERC	TATA spare parts
399064003134	DD WINDOW RH 610X740_SLI_SERVICE_30PERC	TATA spare parts
399064003135	WINDOW RH 1095X790_SLIDG_SERVICE_30%TINT	TATA spare parts
399064003136	WIN LH 810/1085X790_SLIDG_SERVICE_30 PER	TATA spare parts
399064003137	WINDOW RH 995X790_SLIDG_SERVICE_30PERCT	TATA spare parts
399064003138	DD WINDOW RH 610X688_SLI_SERVICE_30 PERC	TATA spare parts
399064003139	WINDOW RH 1055X790_13S23F_SERVICE_30 PER	TATA spare parts
399064003140	WINDOW RH 1195X790_13S23F_SERVICE_30 PER	TATA spare parts
399064003141	WINDOW RH 545X790_13S23F_SERVICE_30 PERC	TATA spare parts
399064003142	WINDOW LH 545X790_13S23F_SERVICE_30 PERC	TATA spare parts
399064003143	WINDOW LH 1195X790_13S23F_SERVICE_30 PER	TATA spare parts
399064003144	FIX WINDOW 235X740_SERVICEABLE_30 PERC T	TATA spare parts
399064003145	WIN LH 1085/835X740_13S23F_SRVICE_30 PER	TATA spare parts
399064003146	WINDOW RH 723X790_SLIDING_SERVICE_CLEAR	TATA spare parts
399064003147	WINDOW RH 586X790_SLIDING_SERVICE_CLEAR	TATA spare parts
399064003149	WINDOW LH 995X790_SLIDING_SERVICE_CLEAR	TATA spare parts
399064003150	WINDOW LH 1035X790_SLIDING_SERVICE_CLEAR	TATA spare parts
399064003151	WINDOW RH_1087X790_1/3F2/3S_SER_30%TINT	TATA spare parts
399064003152	WINDOW RH_1195X790_1/3F2/3S_SER_30%TINT	TATA spare parts
399064003153	WINDOW RH_995X790_1/3F2/3S_SER_30%TINT	TATA spare parts
399064003154	WINDOW RH_455X790_1/3F2/3S_SER_30%TINT	TATA spare parts
399064003155	WINDOW LH_1095X790_1/3F2/3S_SER_30%TINT	TATA spare parts
399064003156	WINDOW LH_1195X790_1/3F2/3S_SER_30%TINT	TATA spare parts
399064003157	WINDOW LH_1087X790_1/3F2/3S_SER_30%TINT	TATA spare parts
399064003158	WINDOW RH 1095X790_SLI_SERVICE_50%GREY T	TATA spare parts
399064003159	WINDOW RH 1195X790_SLI_SERVICE_50%GREY T	TATA spare parts
399064003162	E.D WINDOW RH 590X712_SLI_SERVIC_50%GREY	TATA spare parts
399064003163	WINDOW LH 1095X790_SLI_SERVICE_50%GREY T	TATA spare parts
399064003164	WINDOW LH 1195X790_SLI_SERVICE_50%GREY T	TATA spare parts
399064003166	WINDOW RH 815X790_SLI_SERVICE_50%GREY T	TATA spare parts
399064003167	WINDOW RH 775X790_SLI_SERVICE_50%GREY T	TATA spare parts
399064003168	WINDOW RH 395X790_SLIDING_SERVICE_CLEAR	TATA spare parts
399064003170	WINDOW RH 395X790_SLI_SERVICE_50PERCGREY	TATA spare parts
399064003179	FIX WINDOW 264X790_SERVICEABLE_50 PERC	TATA spare parts
399064003182	WINDOW RH 723X790_SLIDING_NON-SER_CLEAR	TATA spare parts
399064003183	WINDOW RH 395X790_SLIDING_NON-SER_CLEAR	TATA spare parts
399064003184	WINDOW LH 1035X790_SLIDING_NON-SER_CLEA	TATA spare parts



399064003192	WINDOW RH 646X795_SLIDG_SERVICE_30PERC T	TATA spare parts
399064003193	WINDOW LH 646X795_SLIDG_SERVICE_30PERC T	TATA spare parts
399064003195	WINDOW RH 745X790_SLIDG_SERVICE_CLEAR	TATA spare parts
399064003196	WINDOW RH 545X790 1/3F2/3S SER 30PERC TI	TATA spare parts
399064003197	SCOOP WINDOW RH 302X605 SERVIC CLEAR	TATA spare parts
399064003198	WIN RH 988X790 SLIDING SERVICEABLE CLEAR	TATA spare parts
399064003199	WIN COD LH 1003X790 SLDNG SERVICE CLEAR	TATA spare parts
399064003203	FIX WINDOW_1095X790_SERVICEABLE_50PERCT	TATA spare parts
399064003211	FIX WINDOW 300X790 CLEAR	TATA spare parts
399064003212	FIXED WINDOW 345X790_CLEAR	TATA spare parts
399064003213	WINDOW LH 840X790_SLIDING_SERVICE_CLR	TATA spare parts
399064003214	WINDOW LH 620X790_SLIDING_SERVICE_CLR	TATA spare parts
399064003215	PASS. DOOR_565X485_SLIDING_SERVICE_CLR	TATA spare parts
399064003216	FIXED WINDOW 345X790 50 PERC GRAY TINT	TATA spare parts
399064003221	WIN RH 455X790_SLIDING_SERVICEABLE_CLEAR	TATA spare parts
399064003222	WINDOW RH 840X790_SLIDING_SERVICE_CLR	TATA spare parts
399064003223	WIN RH 1085X790(COD)_SLIDING_SERVICE_CLR	TATA spare parts
399064003224	SCOOP WIN LH 276X645_SERVICEABLE_CLEAR	TATA spare parts
399064003225	DRI DOR WIN LH 610X740_SLID_SERVICE_CLR	TATA spare parts
399064003226	WINDOW LH 813X790_SLIDING_SERVICE_CLEAR	TATA spare parts
399064003227	EME DOOR WIN LH 590X712_SLID_SERVICE_CLR	TATA spare parts
399064003228	WINDOW RH_1095X790_1/3F2/3S_SER_CLEAR	TATA spare parts
399064003229	WINDOW RH_1195X790_1/3F2/3S_SER_CLEAR	TATA spare parts
399064003230	WINDOW LH_1087X790_1/3F2/3S_SER_CLEAR	TATA spare parts
399064003231	WINDOW LH_1195X790_1/3F2/3S_SER_CLEAR	TATA spare parts
399064003232	WINDOW LH_1045X790_1/3F2/3S_SER_CLEAR	TATA spare parts
399064003233	WINDOW LH_455X790_1/3F2/3S_SER_CLEAR	TATA spare parts
399064003242	DRI DOR WIN RH 610X740 SLI SER CLR WOSTP	TATA spare parts
399064003243	WINDOW RH 723X790 SLI SER CLR WO STP	TATA spare parts
399064003244	WINDOW RH 840X790 SLIDING SER CLR WO STP	TATA spare parts
399064003245	WINDOW LH 840X790 SLIDING SER CLR WO STP	TATA spare parts
399064003246	WINDOW LH 1035X790 SLI SER CLR WO STP	TATA spare parts
399064003247	WIN RH 1195X790 SLD SERV CLR WO STP	TATA spare parts
399064003248	WIN LH 1095X790 SLD SERV CLR WO STP	TATA spare parts
399064003249	WIN LH 1195X790 SLD SERV CLR WO STP	TATA spare parts
399064003250	EME WIN RH 590X712 SLD SER CLR WO STP	TATA spare parts
399064003251	WIN RH 1095X790_SLD_SERV_CLR_WO STP	TATA spare parts
399064003255	SCOOP LH FIX WINDOW_270X612_CLEAR	TATA spare parts
399064003256	COMMUNICATION WINDOW_326X656_ARMY AN	TATA spare parts
399064003260	WIN LH 1400X790(COD) SLI NON-SERVICE CLR	TATA spare parts
399064003267	WINDOW LH 1095X790 1/3F2/3S SER CLEAR	TATA spare parts
399064003268	WINDOW LH 705X790 1/3F2/3S SER CLEAR	TATA spare parts
399064003270	WINDOW LH 1095X790 13F23S SER CAN CLEAR	TATA spare parts
399064003276	WIDOW LHç 395X790 1/3F2/3S SER CLEAR	TATA spare parts
399064003308	WIN RH 345X790_SLIDING_SERVICEABLE_50%GT	TATA spare parts
399064003314	FIX WINDOW 197X790_SERVICEABLE_CLEAR	TATA spare parts
399064003315	DRIVER DOOR WINDOW RH_569X824X738_SLIDN	TATA spare parts

399064003316	WIN LH 1085X790(COD)_SLIDING_SERVICE_CLR	TATA spare parts
399064003317	COD WIN LH 1085/835X740 SLDG SERVICE CLE	TATA spare parts
399064003318	FIX WINDOW 235X740 SERVICEABLE CLEAR	TATA spare parts
399064003319	WIN RH_1045X790_CLEAR_SLIDING_SREV	TATA spare parts
399064003326	DRIVER DOOR WINDOW RH 610X688 CLEAR	TATA spare parts
399064003329	E.D WINDOW RH 590X712 SLI SERVIC 30PERCG	TATA spare parts
399064003330	FIX WINDOW 1095X790 SERVICEABLE CLR	TATA spare parts
399064003331	FIX WINDOW_723X790_SERVICEABLE_CLR	TATA spare parts
399064003332	FIX WINDOW 1045X790 SERVICEABLE CLEAR	TATA spare parts
399064003334	WINDOW RH 1085X790 1/3F2/3S SER CLEAR	TATA spare parts
399064003335	WINDOW LH 1085X790 1/3F2/3S SER CLEAR	TATA spare parts
399064003336	WIN RH 965X790 SLIDG SERVICE 30PERCGRN T	TATA spare parts
399064003337	SERVICE DOOR GLASS ASSEMBLY	TATA spare parts
399064003341	DRIVER DOOR WIND LH 568X824X737	TATA spare parts
399064003352	RH PEEP WINDOW W224&513XH362 CLEAR	TATA spare parts
399064003353	LH/RH VENT WIND ASSY 1240X840 50PERCGRAY	TATA spare parts
399064003355	WINDOW RH 995X790_SLIDG_SERVICE_50%TINT	TATA spare parts
399064003356	WINDOW LH 995X790_SLIDG_SERVICE_50%TINT	TATA spare parts
399064003358	GI_0.65THKSHAPE-1_650	TATA spare parts
399064003362	RH VENT WIND ASSY 1295X840 50PERCGRAY TI	TATA spare parts
399064003371	PASS. DOOR_590X500_SLIDING_SERVICE_CLR	TATA spare parts
399064003373	WIN LH 455X790 VERTICAL SLIDING SER CLR	TATA spare parts
399064003375	RH WIND 840X790 T1/3FB2/3S CLR	TATA spare parts
399064003376	LH WIND 840X790 T1/3FB2/3S CLR	TATA spare parts
399064003377	RH WIND 723X790 T1/3FB2/3S CLR	TATA spare parts
399064003378	LH WIND COD 1035X790 T1/3FB2/3S CLR	TATA spare parts
399064003382	RH WIND 840X790 T1/3F B2/3S CLR LCV LOCK	TATA spare parts
399064003383	LH WIND 840X790 T1/3F B2/3S CLR LCV LOCK	TATA spare parts
399064003384	RH WIN 723X790 T1/3FB2/3S CLR LCV LOCK	TATA spare parts
399064003385	WINDOW RH 1045X790_SLI_SER_50%GREY TINT	TATA spare parts
399064003387	FIX WINDOW 197X790_50% GRAY TINT	TATA spare parts
399064003391	WINDOW RH 620X790 SLIDING SERVICE CLEAR	TATA spare parts
399064003392	FIX WINDOW LH\rH 235X790 50PERC GRAY TIN	TATA spare parts
399064003395	WINDOW RH 814X790_SLIDING_SERVICE_CLEAR	TATA spare parts
399064003396	WINDOW LH_681X790_SLIDING_SERVICE_CLEAR	TATA spare parts
399064003400	WIN RH 965X790_SLIDG_SERVICE_CLEAR TYPE	TATA spare parts
399064003404	WIN RH 965X790_SLIDG_SERVICE_50PERCGRY T	TATA spare parts
399064003405	WINDOW RH 586X790_SLD_SER_50PERC GRY.TN	TATA spare parts
399064003423	WIND_SLIDING_754X790_50%GRAY TINT_SERV	TATA spare parts
399064004020	OPENING WINDOW MECHANISM ASSEMBLY	TATA spare parts
399064004021	LOCK ASSEMBLY	TATA spare parts
399064004022	LOCKING SET	TATA spare parts
399064004034	OPENABLE WINDOW HANDLE ASSY-RHD	TATA spare parts
399064004035	OPENABLE WINDOW HANDLE ASSY-LHD	TATA spare parts
399064084002	CATCH PLATE	TATA spare parts
399064084003	LOCK CATCH PLATE	TATA spare parts
399064233018	LH/RH PASTED GLASS 220X840 CLEAR	TATA spare parts

399064233023	LH/RH PASTED GLASS 335X840 CLEAR	TATA spare parts
399064233024	RH COD PASTED GL W691&1130XH840 CLEAR	TATA spare parts
399064233028	PASTED GLASS LH/RH 365X840 CLEAR TINT	TATA spare parts
399064233029	LH PASTED GLASS 1295X840 50PERC GRAY TIN	TATA spare parts
399064233030	LH/RH PASTED GLASS 1045X840 50PERC GRAY	TATA spare parts
399064233031	LH PASTED GLASS 1480X840 50PERC GRAY TIN	TATA spare parts
399064233032	RH PASTED GLASS 680X840 50PERC GRAY TINT	TATA spare parts
399064233033	RH PASTED GLASS 1145X840 50PECR GRAY TIN	TATA spare parts
399064233034	RH PASTED GLASS 1240X840 GRAY TINT	TATA spare parts
399064233035	RH PASTED GLASS 1175X840 50 GRAY TINT	TATA spare parts
399064233036	RH PASTED ED WINDOW GLASS 681X790 TIN	TATA spare parts
399064233037	PASTED GLASS LH/RH 710X222 CLEAR GLASS	TATA spare parts
399064233038	RH PASTED GLASS 1175X840 50PERC GRAY TIN	TATA spare parts
399064233039	RH PASTED GLASS 445X840 50PERC GRAY TINT	TATA spare parts
399064233040	RH PASTED ED WINDOW GLASS_682X811_50PER	TATA spare parts
399064233041	RH PASTED GLASS 1227X840 50PERC GRAY TIN	TATA spare parts
399064233042	RH PASTED GLASS 1140X840 50PERC GRAY TIN	TATA spare parts
399064233043	RH PASTED GLASS 1310X840 50PERC GRAY TIN	TATA spare parts
399064233044	LH PASTED GLASS 1310X840 50 GRAY TINT	TATA spare parts
399064233045	PASTED GLASS LH/RH 710X188 CLEAR GLASS	TATA spare parts
399064233046	PASTED GLASS LH/RH 710X159 CLEAR GLASS	TATA spare parts
399064233053	RH PASTED GLASS 685X840 GRAY TINT	TATA spare parts
399064233054	LH PASTED GLASS 685X840 GRAY TINT	TATA spare parts
399064233055	LH PASTED GLASS 800X840 GRAY TINT	TATA spare parts
399064233057	RH PASTED GLASS 1295X840 50 GRAY TINT	TATA spare parts
399064233058	LH PASTED GLASS 1223X840 50 GRAY TINT	TATA spare parts
399064233059	RH PASTED GLASS 1223X840 50 GRAY TINT	TATA spare parts
399064233060	PASTED GLASS LH/RH 710X245 CLEAR GLASS	TATA spare parts
399064233063	LH PASTED GLASS 163X840 CLEAR TINT	TATA spare parts
399064233067	RH PASTED GLASS 1290X840 50PERC GRAY TIN	TATA spare parts
399064233068	RH PASTED GLASS 1145X840 50PERC GRAY TIN	TATA spare parts
399064233069	RH PAST GLS 800X840 151CERAMç GRAY	TATA spare parts
399064233070	RH PAST GLS 345X840 FULL CERAM CLR	TATA spare parts
399064233075	RH SCOOP PASTED GLS 320X697 CLEAR	TATA spare parts
399064233099	REAR RH PASTED GLASS_127X840_CLEAR TINT	TATA spare parts
399064234006	DRIVER OPENABLE WINDOW GLASS	TATA spare parts
399064234007	WINDOW GLASS INTERNAL	TATA spare parts
399064234008	WINDOW GLASS EXTERNAL	TATA spare parts
399064234009	WINDOW GLASS INTERNAL	TATA spare parts
399064234010	WINDOW GLASS EXTERNAL	TATA spare parts
399064234011	WINDOW GLASS INTERNAL	TATA spare parts
399064234012	WINDOW GLASS EXTERNAL	TATA spare parts
399064234013	WINDOW GLASS INTERNAL	TATA spare parts
399064234014	WINDOW GLASS EXTERNAL	TATA spare parts
399064234015	WINDOW GLASS INTERNAL	TATA spare parts
399064234016	WINDOW GLASS EXTERNAL	TATA spare parts
399064234017	PEEP WINDOW GLASS	TATA spare parts

399064234018	WINDOW GLASS EXTERNAL	TATA spare parts
399064234019	WINDOW GLASS INTERNAL	TATA spare parts
399064234020	WINDOW GLASS FIXED	TATA spare parts
399064234021	WINDOW GLASS EXTERNAL	TATA spare parts
399064234022	WINDOW GLASS INTERNAL	TATA spare parts
399064234023	WINDOW GLASS EXTERNAL	TATA spare parts
399064234024	WINDOW GLASS INTERNAL	TATA spare parts
399064234025	WINDOW GLASS INTERNAL	TATA spare parts
399064234026	WINDOW GLASS EXTERNAL	TATA spare parts
399064234027	WINDOW GLASS INTERNAL	TATA spare parts
399064234028	WINDOW GLASS EXTERNAL	TATA spare parts
399064234029	WINDOW GLASS INTERNAL	TATA spare parts
399064234030	WINDOW GLASS EXTERNAL	TATA spare parts
399064234031	WINDOW GLASS INTERNAL	TATA spare parts
399064234032	WINDOW GLASS EXTERNAL	TATA spare parts
399064234041	WINDOW GLASS EXTERNAL	TATA spare parts
399064234042	WINDOW GLASS INTERNAL	TATA spare parts
399064234043	WINDOW GLASS EXTERNAL	TATA spare parts
399064234044	WINDOW GLASS INTERNAL	TATA spare parts
399064234045	WINDOW GLASS EXTERNAL RH	TATA spare parts
399064234046	WINDOW GLASS INTERNAL	TATA spare parts
399064234047	WINDOW GLASS EXTERNAL	TATA spare parts
399064234069	WINDOW GLASS EXTERNAL RH	TATA spare parts
399064234070	WINDOW GLASS EXTERNAL	TATA spare parts
399064234071	WINDOW GLASS EXTERNAL	TATA spare parts
399064234085	WINDOW GLASS EXTERNAL RH	TATA spare parts
399064234086	WINDOW GLASS INTERNAL RH	TATA spare parts
399064234087	WINDOW GLASS EXTERNAL	TATA spare parts
399064234088	WINDOW GLASS INTERNAL	TATA spare parts
399064234095	WINDOW GLASS INTERNAL	TATA spare parts
399064234099	WINDOW GLASS FIXED	TATA spare parts
399064234107	WINDOW GLASS EXTERNAL	TATA spare parts
399064234125	WINDOW GLASS INTERNAL RH	TATA spare parts
399064234126	WINDOW GLASS INTERNAL	TATA spare parts
399064234127	WINDOW GLASS INTERNAL	TATA spare parts
399064234133	WIN GLS_OPENABLE RH_CLR_257X626	TATA spare parts
399064234135	WIN GLS_FR EXT RH&RR INT LH_CLR_318X715	TATA spare parts
399064234136	WIN GLS_FR EXT LH&RR INT RH_CLR_318X715	TATA spare parts
399064234137	WIN GLS FR EXT LH&RR INT RH_CLR_557X769	TATA spare parts
399064234138	WIN GLS FR EXT RH&RR INT LH_CLR_557X769	TATA spare parts
399064234139	WIN GLS FR EXT LH&RR INT RH_CLR_607X769	TATA spare parts
399064234140	WIN GLS FR EXT RH&RR INT LH_CLR_607X769	TATA spare parts
399064234141	WIN GLS_FIXED_CLR_255X782	TATA spare parts
399064234142	WIN GLS_FR EXT LH COD_CLR_415/688X769	TATA spare parts
399064234143	WIN GLS_RR INT LH COD_549X769	TATA spare parts
399064234146	WIN GLS_FIXED_CLR_302X467	TATA spare parts
399064234147	WIN GLS_RR INT RH_CLR_143X769	TATA spare parts

399064234148	WIN GLS_FR EXT RH_220X769	TATA spare parts
399064234149	WIN GLS_RR INT RH_CLR_302X689	TATA spare parts
399064234150	WIN GLS_FR EXT RH_CLR_302X689	TATA spare parts
399064234151	WIN GLS_RR EXT RH_CLR_222X769	TATA spare parts
399064234152	WIN GLS_FR EXT RH_CLR_250X769	TATA spare parts
399064234153	WIN GLS FR EXT LH&RR INT RH_CLR_507X769	TATA spare parts
399064234154	WIN GLS FR EXT RH&RR INT LH_CLR_507X769	TATA spare parts
399064234158	WIN GLS_RR INT LH_CLR_195X769	TATA spare parts
399064234159	WIN GLS_FR EXT LH_CLR_217X769	TATA spare parts
399064234160	WIN GLS_RR INT RH_CLR_195X769	TATA spare parts
399064234161	WIN GLS_FR EXT RH_CLR_217X769	TATA spare parts
399064234162	WIN GLS FR EXT LH¿ CLR 531X769	TATA spare parts
399064234163	WIN GLS RR INT LH CLR 531X769	TATA spare parts
399064234164	WIN GLS_FR ENT RH_CLR_371X769	TATA spare parts
399064234165	WIN GLS_FR EXT RH_CLR_371X769	TATA spare parts
399064234166	WIN GLS FR EXT LH&RR INT RH_CLR_302X769	TATA spare parts
399064234167	WIN GLS FR EXT RH&RR INT LH_CLR_302X769	TATA spare parts
399064234168	WIN GLS_FR EXT LH COD_CLR_390/660X770	TATA spare parts
399064234169	WIN GLS_RR INT LH COD_CLR_390X769	TATA spare parts
399064234172	WIN GLS FIXED 30PERC TINT 302X467	TATA spare parts
399064234173	WINDOW GLASS FRONT 418/688X769	TATA spare parts
399064234174	WINDOW GLS RR INT RH COD 30 PERC TINT 41	TATA spare parts
399064234175	WIN GLS FR ENT LH COD 30 PERC TINT 688X7	TATA spare parts
399064234176	WIN GLS RR INT LH COD 30 PERC TINT 410X7	TATA spare parts
399064234177	WIN GLS FIXED 30PERC TINT 257X782	TATA spare parts
399064234178	WIN GLS FR ET RH&RR IT LH 30PERC TNT 607	TATA spare parts
399064234179	WIN GLS FR ET&RR IT 30PERC TNT 607X769	TATA spare parts
399064234180	WIN GLS FR ET&RR IT 30PERC TNT 282X769	TATA spare parts
399064234181	WIN GLS FR ET LH&RR IT RH 30PERC TNT 282	TATA spare parts
399064234182	WIN GLS FR ET RH&RR IT LH 30PERC TNT 577	TATA spare parts
399064234183	WIN GLS FR ET LH&RR IT RH 30PERC TNT 557	TATA spare parts
399064234184	WIN GLS FR ET RH&RR IT LH 30%TNT 318X715	TATA spare parts
399064234185	WIN GLS FR ET LH&RR IT RH 30%TNT 318X715	TATA spare parts
399064234186	WIN GLS RH OPENABLE 30PERC TINT 47/252X6	TATA spare parts
399064234187	WIN GLS OPENABLE LH 30PERC TNT 47/252X63	TATA spare parts
399064234188	WIN GLS_FR ET RH&RR IT LH_30PERCTNT_507X	TATA spare parts
399064234189	WIN GLS_FR ET LH&RR IT RH_30PERCTNT_507X	TATA spare parts
399064234193	WIN GLS FR ET RH&RR IT LH 50PERC TNT 557	TATA spare parts
399064234194	WIN GLS FR ET LH&RR IT RH 50PERC TNT 557	TATA spare parts
399064234195	WIN GLS FR ET RH&RR IT LH 50PERC TNT 607	TATA spare parts
399064234196	WIN GLS FR ET LH&RR IT RH 50PERC TNT 607	TATA spare parts
399064234203	WIN GLS RR INT RH 50PERC TINT 416X769	TATA spare parts
399064234204	WIN GLS FR EXT RH 50PERC TINT 416X769	TATA spare parts
399064234205	WIN GLS RR INT RH 50PERC TINT 397X769	TATA spare parts
399064234206	WIN GLS FR EXT RH 50PERC TINT 397X769	TATA spare parts
399064234211	WIN GLS_RR INT FIXED¿ RH_50PERCTINT_155X	TATA spare parts
399064234212	WIN GLS_FR EXT RH_50PERCTINT_260X769	TATA spare parts

399064234215	WIN GLS FR ET LH&RR IT RH 30PERC TNT 407	TATA spare parts
399064234216	WIN GLS FR ET RH&RR IT LH 30PERC TNT 407	TATA spare parts
399064234218	WIN GLS FR ET RH CLEAR 382X769	TATA spare parts
399064234219	WIN GLS RR INT RH CLEAR 382X769	TATA spare parts
399064234221	WIN GLS RR EXT RH 30PERC TNT 198X769	TATA spare parts
399064234222	WIN GLS FR EXT RH 30PERC TNT 275X769	TATA spare parts
399064234223	WIN GLS RR INT RH 50PERC TNT 302X689	TATA spare parts
399064234224	WIN GLS FR EXT RH 50PERC TNT 302X689	TATA spare parts
399064234225	WIN GLS FIXED 50PERC TINT 255X782	TATA spare parts
399064234238	WIN GLS_OPENABLE RH_CLR_279X597	TATA spare parts
399064234239	WIN GLS_FR EXT RH&RR INT LH_CLR_504X769	TATA spare parts
399064234240	WIN GLS_FR EXT LH&RR INT RH_CLR_504X769	TATA spare parts
399064234241	WIN GLS_FR EXT LH COD_CLR_648/346X769	TATA spare parts
399064234242	WIN GLS_RR INT LH COD_CLR_367X769	TATA spare parts
399064234246	WIN GLS FR EXT RH&RR INT LH CLR 560X493	TATA spare parts
399064234247	WIN GLS FR EXT LH&RR INT RH CLR 560X493	TATA spare parts
399064234248	PASTED GLASS CAN CLEAR 1084X266	TATA spare parts
399064234249	WIN GLS FR EXT RH&RR INT LH CLR 610X493	TATA spare parts
399064234250	WIN GLS FR EXT LH&RR INT RH CLR 610X493	TATA spare parts
399064234251	PASTED GLASS CAN CLEAR 1184X266	TATA spare parts
399064234252	WIN GLS FR EXT RH&RR INT LH CLR 285X493	TATA spare parts
399064234253	WIN GLS FR EXT LH&RR INT RH CLR 285X493	TATA spare parts
399064234254	PASTED GLASS CAN CLEAR 534X266	TATA spare parts
399064234255	WIN GLS FIXED CLEAR 255X782	TATA spare parts
399064234256	WIN GLS FR EXT RH RR INT LH CLR 210X493	TATA spare parts
399064234257	WIN GLS FR EXT LH RR INT RH CLR 210X493	TATA spare parts
399064234259	WIN GLS FR EXT RH RR INT LH CLR 535X493	TATA spare parts
399064234260	WIN GLS FR EXT LH RR INT RH CLR 535X493	TATA spare parts
399064234262	WIN GLS COD FRONT EXT LH CLEAR 627X493	TATA spare parts
399064234263	WIN GLS COD REAR INT LH CLEAR 480X493	TATA spare parts
399064234264	PASTED GLASS COD CAN CLEAR 922X266	TATA spare parts
399064234268	FIXED GLASS_50PERCTINT_1083X782	TATA spare parts
399064234295	WIN GLS FIXED CLR 292X782	TATA spare parts
399064234296	WIN GLS_FIXED_CLR_337X782	TATA spare parts
399064234297	WIN GLS FR EXT LH&RR INT RH_CLR_429X769	TATA spare parts
399064234298	WIN GLS FR EXT RH&RR INT LH_CLR_429X769	TATA spare parts
399064234299	WIN GLS FR EXT LH&RR INT RH_CLR_319X769	TATA spare parts
399064234300	WIN GLS FR EXT RH&RR INT LH_CLR_319X769	TATA spare parts
399064234303	WIN GLS FIXED 50PERC GRAY TINT 337X782	TATA spare parts
399064234309	WIN GLS FR EXT LH&RR INT RH_CLR_491X769	TATA spare parts
399064234310	WIN GLS FR EXT RH&RR INT LH_CLR_491X769	TATA spare parts
399064234311	WIN GLS_FR EXT RH COD_CLR_418/684X770	TATA spare parts
399064234312	WIN GLS_RR INT RH COD_418X769	TATA spare parts
399064234313	WIN GLS_OPENABLE LH_CLR_252/47X634	TATA spare parts
399064234314	WIN GLS FR EXT LH&RR INT RH_CLR_415X769	TATA spare parts
399064234315	WIN GLS FR EXT RH&RR INT LH_CLR_415X769	TATA spare parts
399064234316	WIN GLASS RH FIX 1084X266 CLR GLASS	TATA spare parts

399064234317	WIN GLASS RH&LH FIX 1184X266 CLR GLASS	TATA spare parts
399064234318	WIN GLASS LH FIX 922X266 CLR GLASS	TATA spare parts
399064234319	WIN GLASS LH FIX 1034X266 CLR GLASS	TATA spare parts
399064234339	COMMU WIN SLD GLASS RH 326X656 ARMY AMB	TATA spare parts
399064234340	COMMU WIN SLD GLASS LH 326X656 ARMY AMB	TATA spare parts
399064234341	FRONT SLIDING GLASS	TATA spare parts
399064234342	REAR SLIDING GLASS	TATA spare parts
399064234343	FIXED GLASS	TATA spare parts
399064234359	WIN GLS FIXED CLR 262X604MM CLEAR	TATA spare parts
399064234360	WIN GLS FR EXT LH&RR INT LHCLR467X769	TATA spare parts
399064234361	WIN GLS FR EXT LH&RR INT RHCLR467X769	TATA spare parts
399064234362	FRONT SLIDING GLASS	TATA spare parts
399064234365	FIXED GLASS CLEAR 384X266	TATA spare parts
399064234382	WIN GLS FR EXT RH&RR INT LH CLR 432X493	TATA spare parts
399064234383	WIN GLS FR EXT LH&RR INT RH CLR 432X493	TATA spare parts
399064234385	WIN GLS FR EXT RH&RR INT LH CLR 373X493	TATA spare parts
399064234386	WIN GLS FR EXT LH&RR INT RH CLR 373X493	TATA spare parts
399064234388	WIN GLS COD FRONT EXT LH CLEAR 600X493	TATA spare parts
399064234389	WIN GLS COD REAR INT LH CLEAR 454X493	TATA spare parts
399064234395	WIN GLS_FIXED_CLR_186X778	TATA spare parts
399064234399	WIN GLS_FR EXT LH COD_CLR_342/754X770	TATA spare parts
399064234400	WIN GLS_RR INT LH COD_342X769	TATA spare parts
399064234401	WIN GLS_FR EXT RH_CLR_297X716	TATA spare parts
399064234402	WIN GLS_RR INT RH_CLR_297X715	TATA spare parts
399064234403	FIXED GLASS	TATA spare parts
399064234404	FRONT SLIDING GLASS	TATA spare parts
399064234405	REAR SLIDING GLASS	TATA spare parts
399064234406	FRONT SLIDING GLASS	TATA spare parts
399064234407	REAR SLIDING GLASS	TATA spare parts
399064234408	FIXED GLASS_CLR GLASS_1083X778	TATA spare parts
399064234409	FIXED GLASS_CLR GLASS_709X778	TATA spare parts
399064234418	FIXED GLASS_COD LH_CLEAR 922X266	TATA spare parts
399064234433	LH/RH PASTED GL+VENT 1240X840 GRAY	TATA spare parts
399064234440	WINDOWRH380X790_SLIDING_SERVICE_CLEAR	TATA spare parts
399064234443	RH PASTED GL+VENT 1295X840 GRAY	TATA spare parts
399064234452	PEEP WINDOW GLASS 254X423X4_CURVED CLEAR	TATA spare parts
399064234454	OPENABLE WINDOW GLASS	TATA spare parts
399064234460	WIN GLS FR EXT LH&RR INT RH_CLR_304X476	TATA spare parts
399064234461	WIN GLS FR EXT RH&RR INT LH_CLR_304X476	TATA spare parts
399064234463	BOTTOM SLIDING GLASS 417 X 441_CLEAR	TATA spare parts
399064234464	TOP FIXED GLASS 389 X 441_CLEAR	TATA spare parts
399064234466	LH TOP FIXED GLASS 870X266 CLEAR	TATA spare parts
399064234467	TOP FIXED GLASS 712X266 CLR	TATA spare parts
399064234468	TOP FIXED GLASS 830X266 CLEAR	TATA spare parts
399064234469	RH SIDE PASTED WINDOW GLASS_1264X840	TATA spare parts
399064234470	RH SIDE RAER PASTED WIN GLASS_581X840	TATA spare parts
399064234483	WIN GLS FR EXT LH& RR INT RH_CLR_417X769	TATA spare parts

399064234484	WIN GLS FR EXT RH& RR INT LH_CLR_417X769	TATA spare parts
399064234485	WIN GLS FR EXT LH& RR INT_RH_CLR_350X769	TATA spare parts
399064234486	WIN GLS FR EXT RH& RR INT LH_CLR_350X769	TATA spare parts
399064234499	W.G_FR ET RH&RR IT LH_50PERCGRY.TNT_491X	TATA spare parts
399064234500	W.G_FR ET LH&RR IT RH_50PERCGRY TNT_491X	TATA spare parts
399064234501	W.GL FR EXT LH&RR INT RH_50PERCGY.T_302X	TATA spare parts
399064234502	W.GL FR EXT RH&RR INT LH_50PERCGY.T_302X	TATA spare parts
399064284002	RUBBER 326X656 EPDM TYPE SLIDING WINDOW	TATA spare parts
399064284004	DOOR BREAK GLASS RUBBER - KEY RUBBER	TATA spare parts
399065002001	WIPER ASSEMBLY SET	TATA spare parts
399065002004	COMPLETE WIPER KIT	TATA spare parts
399065002009	WIPER ASSYç 12V	TATA spare parts
399065002010	COMPLETE WIPER ASSEMBLY AS A KIT	TATA spare parts
399065003001	WINDSHIELD WIPER MOTOR - 12V	TATA spare parts
399065003002	WINDSHIELD WIPER MECHANISM	TATA spare parts
399065003003	WIPER ARM ASSEMBLY	TATA spare parts
399065003008	WINDSHIELD WIPER ENGINE 24V	TATA spare parts
399065003010	WIPER ARM ASSEMBLY	TATA spare parts
399065003011	WIPER MOTOR 12V	TATA spare parts
399065003012	WIPER MECHANISM	TATA spare parts
399065003013	WIPER ARM WITH BLADE	TATA spare parts
399065003014	WIPER MOTOR 24V	TATA spare parts
399065003015	WIPER ARM&BLDAE ASSY	TATA spare parts
399065003018	WIPER ARM & BLADE ASSEMBLY	TATA spare parts
399065004005	WINDSHIELD WIPER ARM	TATA spare parts
399065004006	WINDSHIELD WIPER BLADE	TATA spare parts
399065004008	WIPER JET HOSE ASSEMBLY	TATA spare parts
399065004012	CLEANER ARM	TATA spare parts
399065004014	WIPER ARM ASSEMBLY	TATA spare parts
399065004015	WIPER BLADE ASSEMBLY	TATA spare parts
399065004020	WIPER LINKAGE_LCV EX_LTVS_12V	TATA spare parts
399065233001	REAR WINDSHIELD GLASS BS1/2/3/4	TATA spare parts
399065233002	FRONT WINDSHIELD	TATA spare parts
399065233003	FRONT WINDSHIELD_TOP 220 MM SHADE BAND	TATA spare parts
399065233004	REAR WINDSHIELD_GREEN TINTED_70% TRANSP	TATA spare parts
399065233009	REAR WINDSHIELD_GREY TINTED_50PERC TRANS	TATA spare parts
399065233010	FRONT WIND SHIELD DET	TATA spare parts
399065233016	REAR WINDSHIELD - GRAY TINTED	TATA spare parts
399065283001	REAR WINDSHIELD RUBBER	TATA spare parts
399065283002	FRONT WINDSHIELD RUBBER	TATA spare parts
399065283003	PRESSED RUBBER	TATA spare parts
399065283004	FRONT WIND SHIELD RUBBER	TATA spare parts
399065304009	TEE CONNECTORS	TATA spare parts
399065912005	WINDSHIELD WIPER ASSEMBLY -LHD-24V	TATA spare parts
399065912007	WINDSHIELD WIPER ASSEMBLY -LHD-12V	TATA spare parts
399065912011	WIPER SYSTEMç LCV	TATA spare parts
399067962057	DASHBOARD ASSEMBLY	TATA spare parts



399068003001	AUTO-LOADING STRETCHER	TATA spare parts
399068003004	WASTE WATER TANK	TATA spare parts
399068003013	TRAY ASSY-RADIO EQUIPMENT	TATA spare parts
399068003018	REFRIGERATOR MOUNTING PLATFORM	TATA spare parts
399068003019	WATER CHAMPER MOUNTING PLATFORM ASSY	TATA spare parts
399068083006	WASH BASIN MOUNTING BRACKET	TATA spare parts
399068083007	WATER LINE ROUTING COVER	TATA spare parts
399068912003	GUN MOUNTING BRACKETS INFO DWG	TATA spare parts
399068962001	OXYGEN DELIVERY EQUIPMENTS	TATA spare parts
399068963020	STRETCHER MTG BKT ASSY	TATA spare parts
399068963022	GRAB HANDLE - FOLDABLE STRECTHER	TATA spare parts
399068963023	LATCH ASSY FOR FOLDABLE STRETCHER	TATA spare parts
399068963030	DUSTBIN	TATA spare parts
399068963033	COVER FOR WASH BASIN	TATA spare parts
399068963035	TOWEL HANDLE	TATA spare parts
399068963036	SOAP DISPENSER WITH BKT	TATA spare parts
399068963037	SOAP CASE	TATA spare parts
399068963046	POUCH	TATA spare parts
399068963053	COVER - HEATERS	TATA spare parts
399068963107	HOOK	TATA spare parts
399068963110	COVER FOR JACK	TATA spare parts
399068963138	WASH BASIN WITH TAP	TATA spare parts
3990733	COVER PUSH ROD	TATA spare parts
3991029	HOSE PLAIN	TATA spare parts
3991039	HOSE PLAIN	TATA spare parts
3991044	HOSE PLAIN	TATA spare parts
3991046	HOSE PLAIN	TATA spare parts
3991051	HOSE PLAIN	TATA spare parts
3991085	SPRING VALVE	TATA spare parts
3991306	SCREW HEX FLANGE HEAD CAP	TATA spare parts
3991350	CARTRIDGE SINGLE TYPE	TATA spare parts
3991517	TUBE AIR FUEL CONTROL	TATA spare parts
3991772	ASSLY CYLINDER HEAD	TATA spare parts
3991773	ASSLY CYLINDER HEAD	TATA spare parts
3992092	GASKET CONNECTION	TATA spare parts
3992125	STUD	TATA spare parts
3992127	STUD	TATA spare parts
3992178	UNION MALE	TATA spare parts
3992179	CONNECTION EXHAUST OUTLET	TATA spare parts
3992219	CONNECTION AIR INTAKE	TATA spare parts
3992221	HARNES WIRING	TATA spare parts
399510231001	FRONT WINDSHIELD-G2	TATA spare parts
399510239001	FRONT WINDSHIELD	TATA spare parts
399510900091	GAS PISTON	TATA spare parts
399515003010	DRIVER DOOR HINGE	TATA spare parts
399515003011	DRIVER DOOR HINGE ASSEMBLY	TATA spare parts
399515003015	ASSY OUTER HANDLE FRONT DOOR LH	TATA spare parts

399515003016	ASSY OUTER HANDLE FRONT DOOR RH	TATA spare parts
399515003019	DRIVER DOOR KEYS	TATA spare parts
399515003030	LOCK SECRET RH	TATA spare parts
399515264001	DRIVER DOOR HANDLE COVER	TATA spare parts
399517083003	STRIKER PLATE SUPPORT	TATA spare parts
399517305001	PARTITION DOOR HANDLE	TATA spare parts
399519003001	7 POINT HINGE ASSY	TATA spare parts
399521003003	PARTITION DOOR LOCK ASSEMBLY	TATA spare parts
399521003004	ROLLER LATCH ASSEMBLY	TATA spare parts
399521003005	ROLLER CATCHER ASSY	TATA spare parts
399521004001	PARTITION DOOR HINGE	TATA spare parts
399521004002	PARTITION DOOR LOCK FINISHING	TATA spare parts
399521004003	LATCH ATTACHING SUPPORT	TATA spare parts
399528083014	AIR INTAKE CUTOFF PLATE	TATA spare parts
399540003028	2LH SM1L 480C850W NHB2 GRAY FB VN TM	TATA spare parts
399540003029	2LH SM1L 480C850W BWA NHB2 GRAY FBVN TM	TATA spare parts
399540003030	2RH SM1L 480C850W BWA NHB2 GRAY FBVN TM	TATA spare parts
399540003056	2RH SM1L 530C850W AR NHB2 GRAY FB VN TM	TATA spare parts
399540003057	2RH SM1L 480C850W NHB2 GRAY FB VN TM	TATA spare parts
399540003058	1CD 2LM 480C410W NHB2 GRAY FB VN TM	TATA spare parts
399540003059	2RR 2LM 480C810W LB NHB2 GRAY FB VN TM	TATA spare parts
399540003060	1RM 480C410W LB NHB2 GRAY FB VN TM	TATA spare parts
399540003061	2RH SM1L 450C850W AR HB1 TM	TATA spare parts
399540003062	2RH SM1L 450C850W HB1 TM	TATA spare parts
399540003063	2RR SM1L 450C810W HB1 TM	TATA spare parts
399540003064	1RM 450C410W LB HB1 TM	TATA spare parts
399540003065	2RL SM1L 450C810W HB1 TM	TATA spare parts
399540003066	2LH SM1L 450C850W HB1 TM	TATA spare parts
399540003072	2RL SM1L 480C810W NHB2 GRAY FB VN TM	TATA spare parts
399540003073	2RH SM1L 485C850W FB AR HB2 CVG	TATA spare parts
399540003074	2RH SM1L 485C850W FB HB2 CVG	TATA spare parts
399540003075	1LH 2LM 485C410W AR FB HB2 CVG	TATA spare parts
399540003076	2RL SM1L 485810 FB HB2 CVG	TATA spare parts
399540003077	2LH SM1L 485C850W FB HB2 CVG	TATA spare parts
399540003078	2LH SM1L 485C850W BFOR WA FB HB2 CVG	TATA spare parts
399540003079	2RH SM1L 485C850W BFOR WA FB HB2 CVG	TATA spare parts
399540003080	2RH SM1L 460C850W FB AR HB1 CVG	TATA spare parts
399540003081	2RH SM1L 460C850W FB HB1 CVG	TATA spare parts
399540003082	2RR SM1L 460C810W FB HB1 CV	TATA spare parts
399540003083	1RM 460C410W LB FB HB1 CVG	TATA spare parts
399540003084	2RL SM1L 460C810W FB HB1 CVG	TATA spare parts
399540003085	2LH SM1L 460C850W FB HB1 CVG	TATA spare parts
399540003086	1LH 2LM 460C410W AR FB HB1 CV	TATA spare parts
399540003087	2RH 2LM 510C850W FB HB1 CVG	TATA spare parts
399540003088	2LH SM1L 460C850W BFOR WA FB HB1 CVG	TATA spare parts
399540003089	2RH SM1L 460C850W BFOR WA FB HB1 CVG	TATA spare parts
399540003090	2LH SM1L 510C850W FB HB1 CVG	TATA spare parts

399540003091	2RH SM1L 510C850W FB HB1 CVG	TATA spare parts
399540003092	2RH SM1L 510C850W AR FB HB1 CVG	TATA spare parts
399540003099	2RH SM1L 510C850W AR FB HB1 CVG	TATA spare parts
399540003100	2RH SM1L 460C850W FB HB1 CVG	TATA spare parts
399540003101	2RR SM1L 460C810W FB HB1 CV	TATA spare parts
399540003102	1RM 460C410W LB FB HB1 CVG	TATA spare parts
399540003103	2RL SM1L 460C810W FB HB1 CVG	TATA spare parts
399540003104	2LH SM1L 460C850W FB HB1 CVG	TATA spare parts
399540003105	1LH 2LM 460C410W AR FB HB1 CV	TATA spare parts
399540003106	2RH SM1L 510C850W FB HB1 CVG	TATA spare parts
399540003107	2LH SM1L 460C850W BFOR WA FB HB1 CVG	TATA spare parts
399540003108	2RH SM1L 460C850W BFOR WA FB HB1 CVG	TATA spare parts
399540003109	2LH SM1L 510C850W FB HB1 CVG	TATA spare parts
399540003119	2LH SM1L 450C850W LB HB1 HSSL	TATA spare parts
399540003139	LH 2 SEATER 1 LEG MOUNT-ARM REST	TATA spare parts
399540003140	CO-DRIVER 1 SEATR 2 LEG MOUNT - ARM REST	TATA spare parts
399540003141	2RH SIDE MOUNT 1LEG 465CH850W AR LB BFB	TATA spare parts
399540003142	2RH SIDE MOUNT 1LEG 465CH850W ARLB WOFR	TATA spare parts
399540003143	CD RH 1ST 2LEG MOUNT 460C400W AR NHB1 BF	TATA spare parts
399540003144	2LH SIDE MOUNT 1LEG 465CH850W AR LB BFB	TATA spare parts
399540003145	2LH SIDE MOUNT 1LEG 465CH850W ARLB WOFR	TATA spare parts
399540003151	3RH 3LM 450C950W WA BH SKL TM	TATA spare parts
399540003163	2LH SM1L 460C850W AR LB FB NHB1 CVG BS14	TATA spare parts
399540003168	2RR SM1L 460C850W NHB1 GFB CVG	TATA spare parts
399540003169	1RM 2LM 460C410W LB NHB1 GFB CVG	TATA spare parts
399540003170	2RL SM1L 460C850W NHB1 GFB CVG	TATA spare parts
399540003171	1RM 480C410W LB NHB2 FB BS13 CVG	TATA spare parts
399540003172	1CL 2LM 480C410W NHB2 FB BS13 CVG	TATA spare parts
399540003175	RH2SEATER2LEG	TATA spare parts
399540003186	2RH SM1L 530C850W AR NHB2 BS-13 CVG	TATA spare parts
399540003187	2RH SM1L 480C850W NHB2 BS-13 CVG	TATA spare parts
399540003188	2RR 2LM 480C810W LB NHB2 BS-13 CVG	TATA spare parts
399540003189	2RL SM1L 480C810W NHB2 BS-13 CVG	TATA spare parts
399540003190	2LH SM1L 480C850W NHB2 BS-13 CVG	TATA spare parts
399540003191	2LH SM1L 480C850W BWA NHB2 BS-13 CVG	TATA spare parts
399540003192	2RH SM1L 480C850W BWA NHB2 BS-13 CVG	TATA spare parts
399540003206	1RM 450C410W HB1 TM	TATA spare parts
399540003207	2RH SM1L 450C850W AR LB HB1 TM	TATA spare parts
399540003208	2RH SM1L 450C850W LB HB1 TM	TATA spare parts
399540003209	2LH SM1L 450C850W LB HB1 TM	TATA spare parts
399540003210	2RR SM1L 450C810W LB HB1 TM	TATA spare parts
399540003211	2RL SM1L 450C810W LB HB1 TM	TATA spare parts
399540003213	2RH SM1L 460CH850W AR BS-13 FB NHB1 CVG	TATA spare parts
399540003214	2RH SM1L 460CH850W BS-13 FB NHB1 CVG	TATA spare parts
399540003215	2RH SM1L 460CH850W BEF WH BS13 NHB1 CVG	TATA spare parts
399540003216	2RH SM1L 510CH850W WH BS13 FB NHB1 CVG	TATA spare parts
399540003217	2RR SM1L 460CH810W BS-13 FB NHB1 CVG	TATA spare parts

399540003218	1MD 2SM 460CH400W LB BS-13 NHB1 FB CVG	TATA spare parts
399540003219	2RL SM1L 460CH810W BS-13 FB NHB1 CVG	TATA spare parts
399540003220	2LH SM1L 460CH850W BS-13 FB NHB1 CVG	TATA spare parts
399540003221	2LH SM1L 510CH850W WH BS13 FB NHB1 CVG	TATA spare parts
399540003222	2LH SM1L 460CH850W BEF WH BS13 NHB1 CVG	TATA spare parts
399540003223	1COD 2LM 450CH400W AR BS-13 FB NHB1 CVG	TATA spare parts
399540003225	2RH SM1L 460CH850W AR REXIN NHB1 CVG	TATA spare parts
399540003236	2RH SM1L 530C850W AR NHB2 GRAY FB VN CVG	TATA spare parts
399540003237	2RH SM1L 480C850W NHB2 GRAY FB VN CVG	TATA spare parts
399540003238	1CD 2LM 480C410W NHB2 GRAY FB VN CVG	TATA spare parts
399540003239	2RR 2LM 480C810W LB NHB2 GRAY FB VN CVG	TATA spare parts
399540003240	1RM 480C410W LB NHB2 GRAY FB VN CVG	TATA spare parts
399540003241	2RL SM1L 480C810W NHB2 GRAY FB VN CVG	TATA spare parts
399540003242	2LH SM1L 480C850W NHB2 GRAY FB VN CVG	TATA spare parts
399540003243	2LH SM1L 480C850W BWA NHB2 GRAY FBVN CVG	TATA spare parts
399540003244	2RH SM1L 480C850W BWA NHB2 GRAY FBVN CVG	TATA spare parts
399540003247	2RH SM1L 450C760W AR LB SKL CVG	TATA spare parts
399540003248	2RH SM1L 450C760W SKL CVG	TATA spare parts
399540003249	2LH SM1L 450C760W SKL CVG	TATA spare parts
399540003251	2RH SM1L 450C760W WA SKL CVG	TATA spare parts
399540003252	2LH SM1L 450C760W WA SKL CVG	TATA spare parts
399540003253	2RH SM1L 450C760W AR LB SKL HSSL	TATA spare parts
399540003254	2RH SM1L 450C760W SKL HSSL	TATA spare parts
399540003255	2LH SM1L 450C760W SKL HSSL	TATA spare parts
399540003257	2RH SM1L 450C760W WA SKL HSSL	TATA spare parts
399540003258	2LH SM1L 450C760W WA SKL HSSL	TATA spare parts
399540003259	2RH SM1L 450C760W AR LB SKL TM	TATA spare parts
399540003260	2RH SM1L 450C760W SKL TM	TATA spare parts
399540003261	2LH SM1L 450C760W SKL TM	TATA spare parts
399540003263	2RH SM1L 450C760W WA SKL TM	TATA spare parts
399540003264	2LH SM1L 450C760W WA SKL TM	TATA spare parts
399540003265	3RH SM1L 450C950W AR LB SKL HSSL	TATA spare parts
399540003266	3RH SM1L 450C950W SKL HSSL	TATA spare parts
399540003267	3RH SM1L 450C950W WA SKL HSSL	TATA spare parts
399540003268	3RH SM1L 450C950W AR LB SKL CVG	TATA spare parts
399540003269	3RH SM1L 450C950W SKL CVG	TATA spare parts
399540003270	3RH SM1L 450C950W AR LB SKL TM	TATA spare parts
399540003271	3RH SM1L 450C950W WA SKL CVG	TATA spare parts
399540003272	3RH SM1L 450C950W SKL TM	TATA spare parts
399540003273	3RH SM1L 450C950W WA SKL TM	TATA spare parts
399540003274	2RH 2LM 450C760W SKL_HSSL	TATA spare parts
399540003276	2RH 2LM 450C760W SKL CVG	TATA spare parts
399540003277	2RH 2LM 450C760W SKL_TM	TATA spare parts
399540003279	3RH 2LM 450C950W ED SKL TM	TATA spare parts
399540003283	3RH 2LM 450C950W ED SKL CVG	TATA spare parts
399540003287	3RH 2LM 450C950W ED SKL HSSL	TATA spare parts
399540003293	2RH SM1L 450CH760W AR LB VN HB IB CVG	TATA spare parts

399540003295	2RR SM1L 450CH810W LB VN HB IB CVG	TATA spare parts
399540003296	1RM 2SM 450CH410W LB VN HB IB CVG	TATA spare parts
399540003297	2RL SM1L 450CH810W LB VN HB IB CVG	TATA spare parts
399540003298	2LH SM1L 450CH760W LB VN HB IB CVG	TATA spare parts
399540003302	3RL 2LM 450C950W LB SKL TM	TATA spare parts
399540003303	4RR 3LM 450C1060W 1LB SKL TM	TATA spare parts
399540003327	3RL 2LM 450C950W LB SKL CVG	TATA spare parts
399540003328	4RR 3LM 450C1060W 1LB SKL CVG	TATA spare parts
399540003329	3RL 2LM 450C950W LB SKL HSSL	TATA spare parts
399540003330	4RR 3LM 450C1060W 1LB SKL HSSL	TATA spare parts
399540003331	4RR 3LM 350C1060W 4LB SKL CVG	TATA spare parts
399540003332	4RR 3LM 450C1060W 4LB SKL HSSL	TATA spare parts
399540003333	4RR 3LM 450C1060W 4LB SKL TM	TATA spare parts
399540003334	3RR 3LM 450C1060W 3LB SKL TM	TATA spare parts
399540003335	3RR 3LM 450C1060W 3LB SKL HSSL	TATA spare parts
399540003336	3RR 3LM 450C1060W 1LB SKL CVG	TATA spare parts
399540003337	4RR 3LM 350C1060W 2LB SKL CVG	TATA spare parts
399540003338	4RR 3LM 350C1060W 2LB SKL HSSL	TATA spare parts
399540003339	4RR 3LM 450C1060W 2LB SKL TM	TATA spare parts
399540003340	2RH 2LM 510C850W WA BS-13 NHB1 CVG	TATA spare parts
399540003395	1RH CD 2LEG MOUNT W/OCU PMS PSPL	TATA spare parts
399540003396	1RH 1LEG 1SIDE MOUNT W/OCUS PMS PSPL	TATA spare parts
399540003397	2RH RR 450CH880W RLB IB W/OCUS PMS PSPL	TATA spare parts
399540003398	2LH RR 450CH880W W/OCUS IB RLB PMS PSPL	TATA spare parts
399540003399	2LH 1LEG 1SIDE MOUNT W/OCUS IB PMS PSPL	TATA spare parts
399540003401	2LH 1LEG 1SIDE MOUNT 450C880W W/OCUS IB	TATA spare parts
399540003408	1LH_360CH_2LM_AR_LB_PMS_400W_CVG_W/O	TATA spare parts
399540003409	2RH_SM1L_465CH850W_AR_LB_FR_HBR_CVG	TATA spare parts
399540003410	2RH_SM1L_465CH_850W_AR_LB_W/OFR_HBR_C	TATA spare parts
399540003411	RR_2RH_465C850W_RLB_AR_LB_W/OFR_HBR_C	TATA spare parts
399540003421	2RH SM1L 460CH850W AR LB VNFAB NHB1 CVG	TATA spare parts
399540003457	2RH_SM1LM_460C850W_AR_FR_HBR BS13 CVG	TATA spare parts
399540003458	2RH_SM1LM_460C850W_AR_WO FR_HBR BS13 C	TATA spare parts
399540003459	2RR_2LM_460C850W_AR_WO FR_HBR BS13 CVG	TATA spare parts
399540003460	2RL_SM1LM_460C850W_AR_WO FR_HBR BS13 C	TATA spare parts
399540003461	2LH_SM1LM_460C850W_AR_FR_HBR BS13 CVG	TATA spare parts
399540003462	2LH_SM1LM_460C850W_AR_WO FR_HBR BS13 C	TATA spare parts
399540003479	2RH SM1L 460C850W AR LB FB HB1 TM	TATA spare parts
399540003484	1RM 2LM 460C410W LB FB HB1 TM	TATA spare parts
399540003491	2RR_SM1LM_460C850W_AR_WO FR_HBR BS13 C	TATA spare parts
399540003513	3RH SM2L 450C950W LB BH SKL TM	TATA spare parts
399540003535	RH 2ST SM1L 460CH850W AR NHB1 TM	TATA spare parts
399540003536	RH 2ST SM1L 460CH850W NHB1 TM	TATA spare parts
399540003537	RH 2ST SM1L 450CH850W BEFORE WA NHB1 TM	TATA spare parts
399540003539	RR RH 2ST 2LM 460CH810W NHB1 TM	TATA spare parts
399540003540	RR MD 1ST 2LM 460CH400W LB NHB1 TM	TATA spare parts
399540003541	RR LH 2ST SM1L 460CH810W NHB1 TM	TATA spare parts

399540003542	LH 2ST SM1L 460CH850W NHB1 TM	TATA spare parts
399540003544	LH 2ST SM1L 450CH850W BEFORE WA NHB1 TM	TATA spare parts
399540003545	CD LH 1ST 2LM 460C400W AR_NHB1_TM	TATA spare parts
399540003575	2RH SM1L 460CH850W AR BS-13 FB NHB1 TM	TATA spare parts
399540003576	2RH SM1L 460CH850W BS-13 FB NHB1 TM	TATA spare parts
399540003577	2RH SM1L 460CH850W BEF WH BS13 NHB1 TM	TATA spare parts
399540003578	2RH SM1L 510CH850W WH BS13 FB NHB1 TM	TATA spare parts
399540003579	2RR SM1L 460CH810W BS-13 FB NHB1 TM	TATA spare parts
399540003580	1MD 2SM 460CH400W LB BS-13 NHB1 FB TM	TATA spare parts
399540003581	2RL SM1L 460CH810W BS-13 FB NHB1 TM	TATA spare parts
399540003582	2LH SM1L 460CH850W BS-13 FB NHB1 TM	TATA spare parts
399540003583	2LH SM1L 510CH850W WH BS13 FB NHB1 TM	TATA spare parts
399540003584	2LH SM1L 460CH850W BEF WH BS13 NHB1 TM	TATA spare parts
399540003585	1COD 2LM 450CH400W AR BS-13 FB NHB1 TM	TATA spare parts
399540003616	2RH 2LM 510C850W WA BS-13 NHB1 TM	TATA spare parts
399540003627	2RH SIDE MOUNT 1LEG MOUNT 460CH810W AR	TATA spare parts
399540003628	2RH SIDE MOUNT 1LEG MOUNT 460CH810W LB	TATA spare parts
399540003629	2RH 2LEG MOUNT 460CH810W LB BLUE REX PMS	TATA spare parts
399540003630	2LH SIDE MOUNT 1LEG MOUNT 460CH810W LB	TATA spare parts
399540003637	2RH SIDE MOUNT 1LEG 490CH1025W AR LB BS1	TATA spare parts
399540003638	2RR 2LEG MOUNT 490CH1025W AR LB BS13 PB	TATA spare parts
399540003639	2RL SIDE MOUNT 1LEG 490CH1025W AR LB BS1	TATA spare parts
399540003640	1LH SIDE MOUNT 1LEG 360CH555W AR LB BS13	TATA spare parts
399540003641	1LH SIDE MOUNT 1LEG 490CH555W AR LB BS13	TATA spare parts
399540003654	2RL_850W_RLB_AR_BS-13_HBR_CVG	TATA spare parts
399540003658	2RH SM1L 450CH800W W/O_BH TM	TATA spare parts
399540003659	2RR SM1L 450CH800W W/O_BH TM	TATA spare parts
399540003660	RR MID SEAT_LB_400W_ECO_SKL_TM	TATA spare parts
399540003661	2RL SM1L 450CH800W W/O_BH TM	TATA spare parts
399540003662	2LH SM1L 450CH800W W/O_BH TM	TATA spare parts
399540003663	1LH 2LM_450CH400W_AR_TM	TATA spare parts
399540003664	2RH SM1L 450CH800W W/O_BH_AR_TM	TATA spare parts
399540003680	2RH_SM1LM_460C850W_LB_HBI_BS-13_TM IB	TATA spare parts
399540003681	RR_2RH_2LM_460C810W_LB_HBI_BS-13_TM IB	TATA spare parts
399540003682	1RM 460C410W LB FB HB1 TM IB	TATA spare parts
399540003683	RR_2LH_SM1LM_460C810W_LB_HBI_BS-13_TM	TATA spare parts
399540003684	2LH_SM1LM_460C850W_LB_HBI_BS-13_TM IB	TATA spare parts
399540003685	1LH 2LM 460C410W AR FB HB1 TM IB	TATA spare parts
399540003690	2RH 2LM 475C1025W AR 3PLB BLFB PB USB HS	TATA spare parts
399540003692	1LH 2LM CH475W550 AR 3PLB BLFB PB HS USB	TATA spare parts
399540003707	2RH SM1LM 480CH850 NHB2 3PLB BS-13 CVG	TATA spare parts
399540003711	2LH SM1LM 485CH850 NHB2 3PLB CVG	TATA spare parts
399540003716	5RR_190CH2045W_3LB_RLB_BLUE REX_NHBI_CV	TATA spare parts
399540003720	2LH_SM1L_460CH850W_AR_BL_REXENE_NHBI_C	TATA spare parts
399540003729	RR_2RH_285C1025W_AR_BLFB_3PLB_RLB_USB_	TATA spare parts
399540003730	RR_2LH_285C1025W_AR_BLFB_3PLB_RLB_USB_	TATA spare parts
399540003731	2RH_SM1L_460CH760W_LB_IB_JS_REX_CVG	TATA spare parts

399540003743	CO-DRIV SEAT LH_400W_2LM_AR_2T_IB_HSSL B	TATA spare parts
399540003744	RR_2RH_2LM_465C850_ARLB_W/FR_HBR_BS13C	TATA spare parts
399540003745	RR_2LH_SM1L_465C850W_AR_LB_HBR_BS13_CV	TATA spare parts
399540003746	2LH_SM1L_465C850W_AR_FR_LB_HBR_BS13_CV	TATA spare parts
399540003747	2LH_SM1L_465C850_AR_W/FR_LB_HBR_BS13_C	TATA spare parts
399540003780	2LH_1L1SM_460C880W_W/O CUS_IB_AR_PMS_C	TATA spare parts
399540003782	1RH_1L1SM_460CH410W_IB_W/OCUS_PMS_CV	TATA spare parts
399540003783	2REAR_450CH880W_RLB_IB_W/OCUS_PMS_CV	TATA spare parts
399540003784	2LH_1L1SM_460CH880W_W/OCUS_IB_PMS_CV	TATA spare parts
399540003785	RH_1ST_2LM_465CH_410W_PMS_CV	TATA spare parts
399540003863	1LH SM1LM 330C410W AR BS-13_FB_PMS CVG B	TATA spare parts
399540003922	1RH 2LM 430C400W AR LB TM EV	TATA spare parts
399540003923	1RH 2LM 430C400W AR TM EV	TATA spare parts
399540003926	2RH 2LM 490C810W AR TM EV	TATA spare parts
399540003929	2LH 2LM 430C810W AR TM EV	TATA spare parts
399540003930	2LH 2LM 490C810W AR TM EV	TATA spare parts
399540003932	2RH 2L 360C810W AR TM EV	TATA spare parts
399540003933	2LH 2L 360C810W AR TM EV	TATA spare parts
399540003934	2LH 2L 430C810W AR(3HOLE) TM EV	TATA spare parts
399540003937	2RH 2LM 430C810W AR USB TM EV	TATA spare parts
399540003940	2RH 2LM 380C810W TM EV	TATA spare parts
399540003946	1RH 2LM 380C410W AR LB NHBT2_FB_RX_CV	TATA spare parts
399540003947	5RR 3LM 160C2045W 5LB NHBT2_FB_RX_CV	TATA spare parts
399540003948	2RH 2LM 490C810W W/O.CUSH 3HOLE_TM	TATA spare parts
399540003949	2RH 2LM 430C810W W/O.CUSH 3HOLE_TM	TATA spare parts
399540003950	2RL 2LM 430C810W W/O.CUSH_TM	TATA spare parts
399540003951	2LH 2LM 430C810W W/O.CUSH 3HOLE_TM	TATA spare parts
399540003952	2LH 2LM 490C810W W/O.CUSH 3HOLE_TM	TATA spare parts
399540003953	2LH 2LM 350C810W 2LB W/O.CUSH_TM	TATA spare parts
399540003960	1RH_SM1LM_460CH410W_USB_W/OCUS_PMS	TATA spare parts
399540003961	1RH\LH_2LM_460CH410W_USB_WCUS_PMS	TATA spare parts
399540003962	2RR\RL_170CH880W_DICKEY_PMS	TATA spare parts
399540003963	2LH_SM1LM_460CH880W_W/OCUS_USB_PMS	TATA spare parts
399540003964	2LH_SM1LM_460CH880W_W/OCU_AR_USB_PM	TATA spare parts
399540003965	2 SEATER_WH_850W_2LGM_CV_G_PINK	TATA spare parts
399540003966	LH 2SEAT_500CH_850W_PMS_1SM1LG_CV_G_PIN	TATA spare parts
399540003967	LH 2 SEATER_850W_PMS_1SM1LG_AR_CV_G_PIN	TATA spare parts
399540003968	RH 2 SEATER_ON WH_850W_2LGM_AR_CV_G_PIN	TATA spare parts
399542083003	PANEL PLATE RADIO DVD-RHD	TATA spare parts
399542083004	PANEL PLATE¿ LH	TATA spare parts
399542083005	PANEL PLATE¿ RH	TATA spare parts
399542083015	PANEL PLATE RADIO DVD RH	TATA spare parts
399542363002	DASHBOARD ELECTRIC HARNESS	TATA spare parts
399542363017	SIDE MARKER ELECTRICAL HARNESS	TATA spare parts
399542373004	FRONT ROOF MARKER LAMP CLEAR 24V	TATA spare parts
399542373011	REAR STOP LAMP RED 24V	TATA spare parts
399542374003	INTERRUPTOR 24V	TATA spare parts

399545003018	LCV-EX_LTVS WIPER_FRONT TUBE ASSY	TATA spare parts
399550003022	MODULE RHD/LHD DOUBLE WITH SPEAKER-24V	TATA spare parts
399550003023	MODULE DOUBLE WITH OUT SPEAKER-24V	TATA spare parts
399550324011	AC LOUVER SMALL_RAL-7046	TATA spare parts
399550962001	ASSY AC 12V BS4	TATA spare parts
399552003004	SUNVISOR ASSEMBLY BS6	TATA spare parts
399552003006	ENGINE HOOD & PODEST ASSY	TATA spare parts
399552003008	GEAR SHIFT LEVER COVER ASSY	TATA spare parts
399552003011	DASH BOARD ASSEMBLY-LHD	TATA spare parts
399552003014	ENGINE HOOD & PODEST ASSY-LHD	TATA spare parts
399552003019	ENGINEHOODANDPODESTASSY713RHD	TATA spare parts
399552004002	PODEST ASSY	TATA spare parts
399552004003	ENGINE HOOD ASSY-LHD	TATA spare parts
399552004004	PODEST INSULATION-LHD	TATA spare parts
399552004006	PODESTINSULATION713RHD	TATA spare parts
399552005001	ENGINE HOOD	TATA spare parts
399552005003	ENGINEHOODINTANDEXTASSY713RHD	TATA spare parts
399552264006	PODEST	TATA spare parts
399552264007	LCV 912 RHD DASHBOARD FRP	TATA spare parts
399552264011	DASHBOARD FUSEBOX LID	TATA spare parts
399552264014	DASHBOARD FUZE BOX LID-LHD	TATA spare parts
399552264016	DASHBOARD 713 RHD	TATA spare parts
399552265002	PODEST 713 RHD	TATA spare parts
399553003006	SEAT DISPLAY	TATA spare parts
399553304001	MAIN MODULE BS6	TATA spare parts
399553304004	SPEAKER GRILL OPENED BS6	TATA spare parts
399553304005	SPEAKER GRILL CLOSED BS6	TATA spare parts
399553304006	BLIND COVER BS6	TATA spare parts
399553305001	DIFFUSER & READING LIGHT SET SUPPORT BS6	TATA spare parts
399553305005	FOCUS SET	TATA spare parts
399558263007	AIR INTAKE AREA FINISHING COVER	TATA spare parts
399559323011	DRIVER DOOR INTERIOR COVER PART	TATA spare parts
399564004001	VENTILATION WINDOW 2 HANDLE PASTED G2 G7	TATA spare parts
399565003007	BUSH BRACKET ASSEMBLY	TATA spare parts
399565003009	WIPER AXLE BRACKET ASSY	TATA spare parts
399565003011	WIPER_LINKAGE_MECHANISM_LHD	TATA spare parts
399565003012	LH_WIPER ARM ASSY. 666MM LH	TATA spare parts
399565003013	RH_WIPER ARM ASSY. 760MM	TATA spare parts
399565003016	WIPER_BLADE_28 IN	TATA spare parts
399565004003	WIPER MECHANISM BRACKET	TATA spare parts
399565004004	WIPER BRACKET	TATA spare parts
399565004008	G2_LTVS_SYNDICATE RH WIPER ARM BLADE	TATA spare parts
399565004009	G2_LTVS_SYNDICATE LH WIPER ARM BLADE	TATA spare parts
399565233001	FRONT WINDSHIELD	TATA spare parts
399565233002	REAR WINDSHIELD-G2	TATA spare parts
399565283001	FRONT WINDSHIELD RUBBER	TATA spare parts
399565283002	REAR WINDSHIELD RUBBER PROFILE	TATA spare parts



399565912003	WIPER ASSY	TATA spare parts
39990017	PROPELLER SHAFT GEAR BOX TO PTO PUMP	TATA spare parts
40-X-C041	CAP WHEEL BOLT	TATA spare parts
400028100210	REAR ELECTRIC HARNESS	TATA spare parts
400044403201	HEX HEAD BOLT (M12X45)	TATA spare parts
400044403202	HEX HEAD BOLT (M8X75)	TATA spare parts
400044403301	PUMP MOUNTING BRACKET	TATA spare parts
400044403302	VALVE MOUNTING BRACKET	TATA spare parts
400044403303	VALVE OPERATING LEVER & BRACKET S/A	TATA spare parts
400044405802	RETURN LINE HOSE 1INCHX660 LONG	TATA spare parts
400044405803	PRESSURE HOSE 1/2 INCHX600 LONG	TATA spare parts
400044405805	PRESSURE HOSE 1/2 INCHX1000 LONG	TATA spare parts
400044406501	NYLOC NUT	TATA spare parts
400044406502	NYLOC NUT (3/8INCH BSF)	TATA spare parts
400044406503	NYLOC NUT (M8X1.25)	TATA spare parts
400044407901	PROPELLER SHAFT	TATA spare parts
400044408001	HEX. HEAD SCREW (3/8 INCH BSF X1-1/2INCH	TATA spare parts
400044408002	HEX.HD.SCREW	TATA spare parts
400044409201	SPRING WASHER	TATA spare parts
400044409202	PLAIN WASHER ( PUNCHED 8.5)	TATA spare parts
400044409203	SEALING WASHER	TATA spare parts
400044409204	SEALING WASHER(27.3X31.9)	TATA spare parts
400044409901	2 STAGE TELESCOPIC CYLINDER	TATA spare parts
400044409902	HYDRAULIC PUMP	TATA spare parts
400044409903	ADAPTOR(PUMP)	TATA spare parts
400044409904	ADAPTOR(PTO)	TATA spare parts
400044409905	LINEAR SPOOL VALVE ASSY.	TATA spare parts
400044409906	PUSH PULL CABLE	TATA spare parts
400044409907	HYDRAULIC TANK ASSY.	TATA spare parts
400044409908	TANK MOUNTING STRIP	TATA spare parts
400044409909	RUBBER STRIP	TATA spare parts
400044409910	STRAIGHT ADAPTOR (M33X2 / M30X2)	TATA spare parts
400044409911	PARALLEL MALE STUP COUPLING	TATA spare parts
400044409912	PARALLEL MALE STUP COUPLING	TATA spare parts
400044409914	SWIVEL ELBOW WITH PMSC M22X1.5(16 PIPE)	TATA spare parts
400044409915	PARALLEL MALE STUP COUPLING	TATA spare parts
400044409916	VALVE ELBOW WITH SWIVEL NUT	TATA spare parts
400044409917	BONDED SEAL(TO SUIT M33X2 THREADS)	TATA spare parts
400044409918	HOSE CLIP (TO SUIT 38 OD HOSE)	TATA spare parts
400044409922	SEAL KIT LINEAR SPOOL VALVE	TATA spare parts
400045000103	HYD TANK COMPLETE	TATA spare parts
400045000104	PUMP & PTO	TATA spare parts
400045109901	PUSH PULL CABLE	TATA spare parts
400045309001	MAGNETIC SOLENOID VALVE	TATA spare parts
400045309901	HYD. CYLINDER	TATA spare parts
400045309902	VALVE ELBOW WITH SWIVEL NUT	TATA spare parts
400045309903	HYDRAULIC VALVE	TATA spare parts

400144400101	OIL TANK ASSY 40 L	TATA spare parts
400144990107	FORK PIN	TATA spare parts
400144990115	TEE ADAPTOR M18XM16X1/8INCH	TATA spare parts
400144990117	HOSE 1INCH X 1400 1 7/16INCH UNF FS90	TATA spare parts
400144990119	HOSE 1INCH X 1000MM 1 7/16INCH UNF F	TATA spare parts
400144990120	HOSE 3/4INCH ID X 1150MM L 1 3/16INCH	TATA spare parts
400144990121	HOSE 3/4INCH ID X 1000MM L 1 3/16INCH	TATA spare parts
400144990122	HOSE 3/4INCH X300 MM L R2 1 3/16INCH	TATA spare parts
400144990123	HOSE 3/4INCH IDX1500 R2 1*3/16INCH	TATA spare parts
400144990124	HOSE 3/4INCH X 2400 1 3/16INCH UNF FS9	TATA spare parts
400144990128	SEAMLESS TUBE ASSY.KIT	TATA spare parts
400144990129	SEAMLESS TUBE ASSY.KIT	TATA spare parts
400144990130	COMPLETE PACKSET	TATA spare parts
400144990131	SEAL KIT	TATA spare parts
400144990132	SLIDER SET DIA	TATA spare parts
400144990133	SLIDER SET DIA	TATA spare parts
400144990134	SLIDER SET DIA	TATA spare parts
400144990135	SLIDER SET DIA	TATA spare parts
400144990144	PACKSET FOR STAGE	TATA spare parts
400144990145	PACKSET FOR STAGE	TATA spare parts
400144990146	PACKSET FOR STAGE	TATA spare parts
400144990147	COMPLETE PACKSET	TATA spare parts
400144990148	TIPPING CYLINDER	TATA spare parts
400144990149	STAGE	TATA spare parts
400144990150	STAGE	TATA spare parts
400144990151	BASE	TATA spare parts
400144990152	COVER	TATA spare parts
400144990153	BASE O RING 100 X 3	TATA spare parts
400144990154	PISTON	TATA spare parts
40014499127	OIL LEVEL INDICATOR	TATA spare parts
400161500101	BODY LIFTING BRACKET LH	TATA spare parts
400161500102	BODY LIFTING BRACKET RH	TATA spare parts
4001675	SENSOR OXYGEN	TATA spare parts
400170600101	CYLINDER MOUNTING BRACKET	TATA spare parts
400244100101	VALVE BLOCK	TATA spare parts
400244100102	PNEUMATIC COVER	TATA spare parts
400244100103	SPRING HOUSING	TATA spare parts
400244100104	SPOOL	TATA spare parts
400244100105	SPRING SEAT	TATA spare parts
400244100106	SPRING SEAT	TATA spare parts
400244100107	BALL SEAT	TATA spare parts
400244100108	SPACER	TATA spare parts
400244100110	ALLOY STEEL BALL	TATA spare parts
400244100111	SPRING	TATA spare parts
400244100112	SPOOL EYE	TATA spare parts
400244100113	RELIEF ADJ. SCREW	TATA spare parts
400244100114	PISTON	TATA spare parts

400244100115	CIRCLIP	TATA spare parts
400244100116	PORT PLUG	TATA spare parts
400244100117	HEX.SOC.SET SCREW	TATA spare parts
400244100126	SPACER	TATA spare parts
400244100127	SEALING WASHER	TATA spare parts
400244100128	PRESS PIECE	TATA spare parts
400244100132	SHAFT	TATA spare parts
400244100134	PIN	TATA spare parts
400244100135	CHECK VALVE HOUSING	TATA spare parts
400244100136	CHECK VALVE	TATA spare parts
400244100137	PUMP HOUSING	TATA spare parts
400244100138	BEARING HOUSING	TATA spare parts
400244100139	PLUNGER	TATA spare parts
400244100140	PLUNGER SEAT	TATA spare parts
400244100141	HARNESS PLATE	TATA spare parts
400244100142	SPRING	TATA spare parts
400244100143	SPRING	TATA spare parts
400244100144	RETAINING RING	TATA spare parts
400244100145	RETAINING RING	TATA spare parts
400244100146	GASKET (PTO)	TATA spare parts
400244100149	TAPER ROLLER BEARING	TATA spare parts
400244100151	INNER RING	TATA spare parts
400244100152	CIRCLIP	TATA spare parts
400244100153	HEX.SOC.HD.SCREW	TATA spare parts
400244100154	SEALING WASHER	TATA spare parts
400244100155	HEX.SOC.HD.CAP SCREW	TATA spare parts
400244100161	SPRING DOWEL SLEEVE	TATA spare parts
400244100166	HEAD END COVER-1 (DIA 105)	TATA spare parts
400244100167	HEAD END COVER-2 (DIA 78)	TATA spare parts
400244100169	SPHERICAL BEARING	TATA spare parts
400244100170	CLEVIS BUSH	TATA spare parts
400244100173	LOCK WASHER-1	TATA spare parts
400244100190	GREASE NIPPLE	TATA spare parts
400244100194	HYDRAULIC CYLINDER	TATA spare parts
400244100196	HEX. HD. SCREW	TATA spare parts
400244100204	SPRING WASHER	TATA spare parts
400244100205	POLYURETHANE TUBE	TATA spare parts
400244100206	Nipple	TATA spare parts
400244100213	HEX.HEAD SCREW M10X30	TATA spare parts
400244100215	NYLOC NUT M10X1.5	TATA spare parts
400244100228	COPPER WASHER (ID27.3XOD31.9X1.5THK)	TATA spare parts
400244100236	EXHAUST PIPE	TATA spare parts
400244100238	PRESSURE HOSE (3/4 INCH X850 LONG)	TATA spare parts
400244100239	CABIN CONTROL VALVE	TATA spare parts
400244100240	HOSE STRAP	TATA spare parts
400244100241	COUPLING BODY - 2	TATA spare parts
400244100243	SUCTION HOSE (1 INCHX850 LONG)	TATA spare parts

400244100244	ADAPTOR (M27X2 / 3/4 BSP)	TATA spare parts
400244100245	COLLAR	TATA spare parts
400244100246	BODY LOCK ASSY.	TATA spare parts
400244100247	COMPLETE HYDRAULIC TANK	TATA spare parts
400244100248	PRESSURE HOSE (1/2 INCHX1550 LONG)	TATA spare parts
400244100249	NIPPLE	TATA spare parts
400244100250	RUBBER PAD	TATA spare parts
400244100251	Washer	TATA spare parts
400244100252	SUCTION HOSE (1ID X 1000 LONG)	TATA spare parts
400244100253	PRESSURE HOSE ASSY. (1/2ID X 1750 LON	TATA spare parts
400244100254	Polyurethane tube (OD6x1THK) 15 Mts. LON	TATA spare parts
400244100255	ADAPTOR (3/4BSP / 3/4BSP)	TATA spare parts
400244100256	Collar (Cylinder top eye)	TATA spare parts
400244100257	ADAPTOR (1BSP / M30X2)	TATA spare parts
400244100259	Adaptor (M26x1.5 / M26x1.5)	TATA spare parts
400244100260	ADAPTOR (M22X1.5 / 3/4BSP)	TATA spare parts
400244100261	STRAIGHT ADAPTOR (M39X2 / 1PIPE)	TATA spare parts
400244100262	Pin (Cylinder top Mounting)	TATA spare parts
400244100263	MOUNTING BRACKET (CABIN CONTROL MOUNTIN	TATA spare parts
400244100264	Hydraulic Tank COMPLETE	TATA spare parts
400244100265	Cylinder	TATA spare parts
400244100266	Cylinder Mounting bracket	TATA spare parts
400244103101	BEARING	TATA spare parts
400244103102	BEARING	TATA spare parts
400244103103	Metallic Piston BRG (Dia 77)	TATA spare parts
400244104201	C.E Cover Clamping Ring	TATA spare parts
400244104301	Circlip	TATA spare parts
400244104701	Cap end Cover	TATA spare parts
400244105801	HOSE 1INCH ID X 1850MM 1 7/16INCH UNF	TATA spare parts
400244105802	HOSE 3/4INCH ID X 2400MM 1INCH BSP (M)	TATA spare parts
400244105803	HOSE 3/4INCH ID X 2400MM 1INCH BSP (M)	TATA spare parts
400244106501	NYLOC NUT M16X1.5 FINE PITCH	TATA spare parts
400244106502	NYLOC NUT M6	TATA spare parts
400244106601	Piston Rod-1 (Dia 110)	TATA spare parts
400244106602	Piston Rod-2 (Dia 91)	TATA spare parts
400244106603	Piston Rod-3 (Dia 72)	TATA spare parts
400244106604	Rod eye	TATA spare parts
400244106702	Split pin (Dia 10 x 70L)	TATA spare parts
400244106801	Tube s/a	TATA spare parts
400244106901	Flexible hose (5 Mts. LONG)	TATA spare parts
400244107101	BOTTOM PLATE DIA 162	TATA spare parts
400244108001	HEX. HEAD SCREW M6X20 - 8.8	TATA spare parts
400244108002	HEX. HEAD SCREW M8X30 - 8.8	TATA spare parts
400244108003	Hex.Hd.Bolt (M16x55)	TATA spare parts
400244108004	Nyloc Nut (M16x2)	TATA spare parts
400244109001	PRESSURE CATRIDGE	TATA spare parts
400244109002	NON RETURN VALVE	TATA spare parts

400244109003	O RING KIT - PT VALVE	TATA spare parts
400244109004	BALL VALVE (1BSP THREAD ON BOTH SIDES	TATA spare parts
400244109201	M16 HARDENED WASHER (30/17*3)	TATA spare parts
400244109202	M8 STAR WASHER	TATA spare parts
400244109203	M8 SPRING WASHER SQ. SECTION	TATA spare parts
400244109204	Sealing washer	TATA spare parts
400244109205	Sealing washer	TATA spare parts
400244109206	Stopper Ring (Dia 72)	TATA spare parts
400244109207	Stopper Ring (Dia 110)	TATA spare parts
400244109208	Stopper Ring (Dia 110)	TATA spare parts
400244109209	Spherical Bearing	TATA spare parts
400244109211	Stopper Ring (Dia 91)	TATA spare parts
400244109901	CYLINDER	TATA spare parts
400244109903	VALVE	TATA spare parts
400244109904	TIPPING VALVE MOUNTING BLOCK	TATA spare parts
400244109905	OIL TANK	TATA spare parts
400244109906	DRAIN PLUG 3/4INCH BSP WITH O-RING	TATA spare parts
400244109907	RETN. LINE FILTER BODY M/C	TATA spare parts
400244109908	HOSE 1INCH I.DX600 R1 1 7/16INCH UNF F	TATA spare parts
400244109911	ADAPTOR 1 1/4INCH BSP(M)X1 7/16INCH	TATA spare parts
400244109912	ADAPTOR 1INCH BSP(M)X1 3/16INCH	TATA spare parts
400244109913	ADAPTOR 1INCH BSP(M)X1 7/16INCH	TATA spare parts
400244109914	ADAPTOR 1INCH BSP(M)X1INCH BSP(M)	TATA spare parts
400244109916	PT VALVE REPAIR KIT	TATA spare parts
400244109917	SEAL KIT	TATA spare parts
400244109918	THRUST PLATE	TATA spare parts
400244109919	PACKSET DIA 162	TATA spare parts
400244109920	BASE DIA	TATA spare parts
400244109922	STAGE DIA	TATA spare parts
400244109924	PISTON DIA	TATA spare parts
400244109925	BASE TUBE 162-1480414-190	TATA spare parts
400244109927	SECOND STAGE TUBE 120-1510-DS-HC	TATA spare parts
400244400101	Hydraulic Tank BARE	TATA spare parts
400244406701	HYFIX PIN - 1 (DIA31.5X110L)	TATA spare parts
400244406702	HYFIX PIN - 2 (DIA25X85L)	TATA spare parts
400244406703	HYFIX SECURE(SPRING DOWEL)PIN	TATA spare parts
400244406704	HYFIX PIN - 3 (DIA31.5X80L)	TATA spare parts
400244408801	HYFIX STUD SET(M20 NUT+PIN)	TATA spare parts
400244409901	ASSY HYD OIL TANK 50 LTRS	TATA spare parts
400244990101	TUBE S/A	TATA spare parts
400244990102	PISTON	TATA spare parts
400244990103	PISTON ROD-1 (DIA 105)	TATA spare parts
400244990104	PISTON-2 (DIA 78)	TATA spare parts
400244990105	PISTON ROD-2 (DIA 78)	TATA spare parts
400244990106	PISTON ROD-3 (DIA 55)	TATA spare parts
400244990107	HEAD END COVER-3 ( DIA 55)	TATA spare parts
400244990108	ROD EYE	TATA spare parts

400244990109	LOCK WASHER-2	TATA spare parts
400244990110	LOCK WASHER-3	TATA spare parts
400244990111	LOCK WASHER	TATA spare parts
400244990112	PRESS PIECE	TATA spare parts
400244990113	HEX SOC SET SCREW	TATA spare parts
400244990124	SEAL KIT HYDRAULIC CYLINDER	TATA spare parts
400244990125	HYDRAULIC TANK BARE	TATA spare parts
400244990126	OIL LEVEL GAUGE ASSY.	TATA spare parts
400244990126N	OIL LEVEL GAUGE	TATA spare parts
400244990127	RETURN LINE FILTER ASSY.	TATA spare parts
400244990128	FILTER	TATA spare parts
400244990128N	FILTER	TATA spare parts
400244990129	VALVE MOUNTING PLATE	TATA spare parts
400244990130	BREATHER CAP	TATA spare parts
400244990130N	BREATHER CAP	TATA spare parts
400244990131	DRAIN PLUG	TATA spare parts
400244990131N	DRAIN PLUG	TATA spare parts
400244990132	HEX.HD.SCREW	TATA spare parts
400244990132N	HEX.SOC.HD.SCREW	TATA spare parts
400244990133	O'RING	TATA spare parts
400244990134	HEX.HD.SCREW	TATA spare parts
400244990135	METALLIC STRAINER	TATA spare parts
400244990135N	METALLIC STRAINER	TATA spare parts
400244990136	HEX.HD.SCREW	TATA spare parts
400244990137	PLAIN WASHER	TATA spare parts
400244990138	STRAIGHT ADAPTOR (M22X1.5 / M26X1.5)	TATA spare parts
400244990139	BONDED SEAL (TO SUIT M33 THREAD)	TATA spare parts
400244990139N	BONDED SEAL TO SUIT M33 THREAD	TATA spare parts
400244990140	BONDED SEAL	TATA spare parts
400244990141	BONDED SEAL	TATA spare parts
400244990142	LINEAR SPOOL VALVE	TATA spare parts
400244990143	POLYURETHANE TUBE (OD6X1THK) - 18MTS. LO	TATA spare parts
400244990144	FLEXIABLE HOSE ID 3/4INCH 9 MTS. LONG	TATA spare parts
400244990145	ELBOW (PNEUMATIC)	TATA spare parts
400244990146	AXIAL PISTON PUMP	TATA spare parts
400244990147	SEAL KIT APP	TATA spare parts
400244990148	KIDNEY PLATE (LEFT)	TATA spare parts
400244990148N	KIDNEY PLATE (LEFT)	TATA spare parts
400244990149	NEEDLE ROLLER BEARING	TATA spare parts
400244990149N	NEEDLE ROLLER BEARING	TATA spare parts
400244990150	HEX.HD.SCREW	TATA spare parts
400244990150N	HEX.HD.BOLT	TATA spare parts
400244990151	SPACER	TATA spare parts
400244990152	SPRING	TATA spare parts
400244990152N	SPRING	TATA spare parts
400244990153	COMPLETE PTO ASSEMBLY GBS 40 LPK 1613	TATA spare parts
400244990154	PTO HOUSING	TATA spare parts

400244990155	SPLINE COUPLING	TATA spare parts
400244990156	SHIFTING FORK	TATA spare parts
400244990157	SHIFTING SHOE	TATA spare parts
400244990158	SHIFTING CLEVIS	TATA spare parts
400244990159	HEX.HD.SCREW	TATA spare parts
400244990160	HEX.NUT	TATA spare parts
400244990160N	HEX.NUT	TATA spare parts
400244990161	OIL SEAL	TATA spare parts
400244990162	MOUNTING PIN	TATA spare parts
400244990163	CLAMP	TATA spare parts
400244990164	PNEUMATIC CYLINDER BS2/3	TATA spare parts
400244990165	SPRING WASHER	TATA spare parts
400244990166	HEX. HD. SCREW	TATA spare parts
400244990167	GASKET PTO	TATA spare parts
400244990168	SEALING WASHER	TATA spare parts
400287100104	SUB FRAME ASSY	TATA spare parts
400287100106	ASSY TAIL DOOR LPK2530TC 6X4	TATA spare parts
400287103201	HEX. HEAD BOLT M8X75 - 8.8	TATA spare parts
400287103401	REAR HINGE BUSH ASSEMBLY	TATA spare parts
400287105601	HYFIX HOOK	TATA spare parts
400287105602	HYFIX MOUNTING EYE (MACHINED)	TATA spare parts
400287106101	REAR HINGE SHAFT SNAP RING DIA60	TATA spare parts
400287106502	NYLOC NUT M10	TATA spare parts
400287106503	NYLOC NUT M8	TATA spare parts
400287106701	BODY PROP MOUNTING PIN	TATA spare parts
400287106702	REAR HINGE SHAFT LOCKING PIN	TATA spare parts
400287106703	HAMMER PIN DIA40X70L	TATA spare parts
400287107101	OIL TANK MTG. BKT	TATA spare parts
400287107102	HYFIX COMPRESSION PLATE	TATA spare parts
400287107901	REAR HINGE SHAFT DIA60 X 970L	TATA spare parts
400287108003	HEX. HEAD SCREW M10X40 - 8.8	TATA spare parts
400287108701	SPRINGS (PIVOT) FL57	TATA spare parts
400287109201	M10 SPRING WASHER SQ. SECTION	TATA spare parts
400287303203	HEX. HEAD BOLT M16X220 - 10.9	TATA spare parts
400287303204	HEX. HEAD BOLT M16X160 - 10.9	TATA spare parts
400287306001	FORK LH THREADED	TATA spare parts
400287306501	LOCK NUT M16	TATA spare parts
400287306502	PLAIN NUT M16 LH THREAD	TATA spare parts
400287306503	EYE BOLT WITH NUT	TATA spare parts
400287306504	NYLOC NUT M14	TATA spare parts
400287306701	FORK PIN	TATA spare parts
400287306702	LOCKING PIN	TATA spare parts
400287306703	SPLIT PIN DIA8X45	TATA spare parts
400287309913	GEAR PUMP	TATA spare parts
400298809901	GREASE NIPPLE - 45 DEGREE	TATA spare parts
400298809903	HOSE 3/4INCH IDX2050R2 1 3/16INCH UN	TATA spare parts
400298809904	HOSE 3/4INCH ID X 1850R1 1 3/16INCH UNF	TATA spare parts

400298809905	TIPPING VALVE LPK 2516TC 6X4	TATA spare parts
400298809906	SEAL KIT - (NEW TYPE)	TATA spare parts
400298809907	BASE 141 X 1480	TATA spare parts
400298809908	STAGE 120 X 1446-HC	TATA spare parts
400298809909	STAGE 099 X 1446	TATA spare parts
4010488	SEAL O RING	TATA spare parts
4010519	SEAL O-RING	TATA spare parts
401098004901	EMERGENCY SWITCH	TATA spare parts
401098005301	WELD RING GASKET	TATA spare parts
401098005302	PAF VALVE GASKET	TATA spare parts
401098008201	EXHAUST SILENCER 1/4 INCH	TATA spare parts
401098008202	EXHAUST SILENCER 1/8 INCH	TATA spare parts
401098009001	PUSH PULL VALVE	TATA spare parts
401098009002	PRESSURE PROTECTION VALVE	TATA spare parts
401098009003	AIR INTERLOCK VALVE	TATA spare parts
401098009004	QUICK EXHAUST VALVE	TATA spare parts
401098009005	MANUAL AIR VALVE	TATA spare parts
401098009901	MALE CONNECTOR 1/4 INCH	TATA spare parts
401098009902	MALE CONNECTOR 1/8 INCH	TATA spare parts
401098009903	ELBOW T CONNECTOR 1/8 INCH	TATA spare parts
401098009904	PRESSURE INDICATOR	TATA spare parts
401098009905	F R L	TATA spare parts
401098009906	P U PIPE 6 OD / 4 ID _10 MTRS	TATA spare parts
401098808001	SCREW HEX HEAD	TATA spare parts
401098809201	WASHER 1/4 INCH	TATA spare parts
401098809202	WASHER 1/8 INCH	TATA spare parts
4022703	UNION MALE	TATA spare parts
4022705	ELBOW MALE ADAPTER	TATA spare parts
402270900101	PRESSURE GUAGE_ TRANSIT MIXER	TATA spare parts
402270900102	HOUR METER_ TRANSIT MIXER	TATA spare parts
402270900103	DC MOTOR(OILCOOLER MOTOR)_ TRANSIT MIXER	TATA spare parts
402270900104	THERMO SWITCH(SS)_ TRANSIT MIXER	TATA spare parts
402270900105	THERMO SWITCH(ZF)_ TRANSIT MIXER	TATA spare parts
402270903101	WATER PUMP BEARING_ TRANSIT MIXER	TATA spare parts
402270903102	ROLLER BEARING SUPPORT_ TRANSIT MIXER	TATA spare parts
402270904901	CONTROL CABLE(ENGINE)_ TRANSIT MIXER	TATA spare parts
402270904902	CONTROL CABLE(DRUM)_ TRANSIT MIXER	TATA spare parts
402270904903	RELAY_ TRANSIT MIXER	TATA spare parts
402270904904	KEY SWITCH(IGNITION)_ TRANSIT MIXER	TATA spare parts
402270905301	WATER PUMP GASKET_ TRANSIT MIXER	TATA spare parts
402270906101	RING NILO_ TRASIT MIXER	TATA spare parts
402270907801	WATER PUMP MECHANICAL SEAL_ TRANSIT MIXER	TATA spare parts
402270907802	WATER PUMP OIL SEAL_ TRANSIT MIXER	TATA spare parts
402270909901	FILTER ELEMENT_ TRANSIT MIXER	TATA spare parts
402270909902	FILTER ELEMENT_ TRANSIT MIXER	TATA spare parts
402270909903	WATER PUMP_ TRANSIT MIXER	TATA spare parts
4024883	SEAL OIL	TATA spare parts



4025236	PLUG SPARK	TATA spare parts
4025270	KIT FRONT SEAL SERVICE	TATA spare parts
4025290	SET PISTON RING	TATA spare parts
4025392	SENSOR OXYGEN	TATA spare parts
4027137	KIT TURBOCHARGER BRACK	TATA spare parts
4027309	REPAIR KIT TURBOCHARGER	TATA spare parts
4027410	TURBO CHARGER CORE ASSY	TATA spare parts
4027490	REPAIR KIT	TATA spare parts
4030033	TURBOCHARGER ACTUATOR KIT	TATA spare parts
4030087	KIT WASTEGATE ACTUATOR	TATA spare parts
4031502	U CLAMP	TATA spare parts
403231500101	TWIST LOCK ASSEMBLY	TATA spare parts
403231500102	LANDING LEG SET ASSEMBLY	TATA spare parts
403231508201	OUTER TWIST LOCK	TATA spare parts
403231508202	INNER TWIST LOCK	TATA spare parts
403231508203	LANDING LEG MOUNTING BRACKETS	TATA spare parts
403232500101	LEAF SPRING	TATA spare parts
403232500104	EQUILIZER HANGER ASSEMBLY	TATA spare parts
403232500106	FIXED TORQUE ARM - (FRONT RH)	TATA spare parts
403232500107	FIXED TORQUE ARM - (REAR RH)	TATA spare parts
403232500108	ADJUSTABLE TORQUE ARM ASSY	TATA spare parts
403232500109	ADJUSTABLE TORQUE ARM ASSY	TATA spare parts
403232500110	TORQUE ARM BUSH ASSEMBLY	TATA spare parts
403232503201	U BOLT 400 WITH NUT	TATA spare parts
403232503202	HEX BOLT M12X150	TATA spare parts
403232503401	EQUALISER BUSH RUBBER	TATA spare parts
403232503402	TORQUE ARM PIN BUSH RUBBER	TATA spare parts
403232503403	EQUALISER BUSH POLY.	TATA spare parts
403232503701	SPRING SEAT - 100MM	TATA spare parts
403232503702	FRONT HANGER BRACKET	TATA spare parts
403232503703	REAR HANGER BRACKET	TATA spare parts
403232503704	EQUILISER HANGER BRACKET	TATA spare parts
403232503705	EQUALISER	TATA spare parts
403232506501	EQUALISER SHAFT LOCK NUT M24X3	TATA spare parts
403232506502	LOCK NUT M12X1.75	TATA spare parts
403232506701	EQUALISER SHAFT	TATA spare parts
403232506702	TORQUE ARM PIN M24	TATA spare parts
403232507101	CLAMP PLATE	TATA spare parts
403232509201	EQUALISER SHAFT WASHER	TATA spare parts
403232509202	TORQUE ARM PIN WASHER	TATA spare parts
403234106701	KING PIN	TATA spare parts
403239000101	AXLE ASSEMBLY	TATA spare parts
403239107901	AXLE BEAM	TATA spare parts
403239200101	CAM SHAFT REPAIR KIT	TATA spare parts
403239203101	OUTER BEARING	TATA spare parts
403239203102	INNER BEARING	TATA spare parts
403239203201	FLANGE BOLT HUB CAP	TATA spare parts

403239203701	HUB	TATA spare parts
403239203702	HUB CAP	TATA spare parts
403239206501	SPINDLE ADJUSTMENT NUT	TATA spare parts
403239206502	SPINDLE LOCK NUT	TATA spare parts
403239207501	DUST COVER PLUG	TATA spare parts
403239207801	HUB SEAL	TATA spare parts
403239207802	O RING HUB CAP	TATA spare parts
403239207901	CAM SHAFT LH	TATA spare parts
403239207902	CAM SHAFT RH	TATA spare parts
403239208201	DUST COVER SET	TATA spare parts
403239209201	LOCK WASHER SPINDLE	TATA spare parts
403239209202	TAB LOCK WASHER SPINDLE	TATA spare parts
403240209201	CONE WASHER	TATA spare parts
403242200101	RIM 20X7.50 SPLIT TYPE	TATA spare parts
403242203201	WHEEL STUD LH 10X7/8INCHX335	TATA spare parts
403242203202	WHEEL STUD RH 10X7/8INCHX335	TATA spare parts
403242206501	WHEEL NUT LH	TATA spare parts
403242206502	WHEEL NUT RH	TATA spare parts
403242300101	SLACK ADJUSTER	TATA spare parts
403242300102	BRAKE CHAMBER T-30	TATA spare parts
403242300103	BRAKE SHOE ASSEMBLY	TATA spare parts
403242300104	BRAKE SHOE REPAIR KIT	TATA spare parts
403242303701	BRAKE DRUM	TATA spare parts
403242305301	ANCHOR LINING NON ASBESTOS	TATA spare parts
40324230530102DF	BRAKE LINING(WHEEL SET-Y) KIT WITH RIVET	TATA spare parts
403242305302	CAM LINING NON ASBESTOS	TATA spare parts
403242307401	LINING RIVET	TATA spare parts
403243200101	PALM COUPLING RED	TATA spare parts
403243200102	PALM COUPLING YELLOW	TATA spare parts
403243200103	BULK HEAD COUPLING	TATA spare parts
403243200104	COMPRESSION COUPLING	TATA spare parts
403243206801	HOSE NIPPLE	TATA spare parts
403243206802	HOSE CLIP	TATA spare parts
403243206803	REDUCER	TATA spare parts
403243206804	HEXAGONAL NIPPLE 3/4	TATA spare parts
403243207801	PALM COUPLING SEAL	TATA spare parts
403243709001	RE 6 RELAY VALVE	TATA spare parts
403243709002	DRAIN VALVE	TATA spare parts
403243805801	NYLON HOSE 3/8 YELLOW 11 MTRS LONG	TATA spare parts
403243805802	NYLON HOSE 3/8 RED 11 MTRS LONG	TATA spare parts
403243805803	BRAKE HOSE (RUBBER)	TATA spare parts
403252507701	REAR BUMBER RUBBER	TATA spare parts
403254404901	TAIL LIGHT LEFT SIDE	TATA spare parts
403254404902	TAIL LIGHT RIGHT SIDE	TATA spare parts
403254404903	NUMBER PLATE LIGHT	TATA spare parts
403254504901	7 PIN CONNECTOR	TATA spare parts
403254504902	JUNCTION BOX	TATA spare parts

403258100101	AXLE NUT SPANNER SPL TOOL DLT	TATA spare parts
403431506700	KING PIN 2 INCH	TATA spare parts
403432500100	REAR HANGER BRACKET ASSY	TATA spare parts
403432500101	EQUILISER HANGER BRACKET ASSY	TATA spare parts
403432500102	FRONT HANGER BRACKET ASSY	TATA spare parts
403432500103	EQUILISER ASSY	TATA spare parts
403432500104	TORQUE ARM ASSY-FIXED	TATA spare parts
403432500105	TORQUE ARM ASSY-ADJUSTABLE	TATA spare parts
403432503200	U BOLT WITH NUT	TATA spare parts
403432503400	EQUILISER BUSH	TATA spare parts
403432503401	TORQUE ARM BUSH	TATA spare parts
403432507100	SPRING SEAT	TATA spare parts
403438700100	LANDING LEG ASSY	TATA spare parts
403445105800	BOOSTER HOSE 75 X 10 WITH CLIP	TATA spare parts
403445105801	AIR CONNECTION HOSE 63 X 8	TATA spare parts
403445207500	BLANK CAP-AIR FEED COUPLING	TATA spare parts
403445207501	BLANK CAP-MATL OUTLET COUPLING	TATA spare parts
403445207800	SEALING RING-AIR FEED COUPLING	TATA spare parts
403445207801	SEALING RING-MATL OUTLET COUPLING	TATA spare parts
403445309000	NON RETURN VALVE	TATA spare parts
403445309001	BOOSTER VALVE 2.5 INCH	TATA spare parts
403445309002	SHUT OFF VALVE	TATA spare parts
403445309003	VALVE 2 INCH FOR AERATION SYSTEM	TATA spare parts
403445309004	SAFETY VALVE 1.25 INCH_ 2.5 BAR	TATA spare parts
403445309005	PRESSURE RELAESE VALVE 1.5 INCH	TATA spare parts
403445909900	MANOMETER 0 TO 4 BAR	TATA spare parts
403489907802	MANHOLE SEALING RING DIA 485 MM	TATA spare parts
403489908200	MANHOLE COVER	TATA spare parts
403499003200	EYE BOLT WITH NUT	TATA spare parts
403499008000	MANHOLE SCREW BOLT NUT & PIN	TATA spare parts
403499504200	CLAMP 4X	TATA spare parts
403499504201	CLAMP 3X	TATA spare parts
403499504202	PIPING CLAMP	TATA spare parts
4035100	TURBOCHARGER	TATA spare parts
403670400101	LOCKING MECHANISM-FULL ASSY	TATA spare parts
403670508200	WATER SHED	TATA spare parts
403670803200	U BOLT 395 MM	TATA spare parts
403670803201	U BOLT 440 MM	TATA spare parts
403670803202	U BOLT 465MM	TATA spare parts
403670803800	ALUMINIUM PACKING	TATA spare parts
403670900100	SUPD ASSY	TATA spare parts
403670900101	SUPD ASSY	TATA spare parts
403670902900	DOOR HINGES	TATA spare parts
403682504900	INSIDE LIGHT AND SWITCH	TATA spare parts
403682604900	HEIGHT MARKER LAMPS	TATA spare parts
403682604901	SIDE INDICATOR	TATA spare parts
403682604902	REFLECTOR	TATA spare parts

403688200100	ALUMINIUM MUDGUARD ASSY	TATA spare parts
403688200101	ALUMINIUM MUDGUARD ASSY	TATA spare parts
403688300100	REAR STEP ASSY	TATA spare parts
4038908	TURBOCHARGER	TATA spare parts
4038909	TURBOCHARGER BS2	TATA spare parts
4038964	TURBOCHARGER	TATA spare parts
4038965	TURBOCHARGER 180 HP BS2	TATA spare parts
4042027	TURBOCHARGER	TATA spare parts
4043982	TURBOCHARGER	TATA spare parts
405154400101	CABIN LAMP	TATA spare parts
405154400102	PATIENT DIFFUSED LAMP	TATA spare parts
405167302301	SIDE FIXED GLASS	TATA spare parts
405167305201	SIDE GLASS RUBBER BEADING	TATA spare parts
405167802301	REAR FIXED GLASS	TATA spare parts
405167805201	REAR GLASS RUBBER BEADING	TATA spare parts
405172306301	DRIVER DOOR CLIMBING HANDLES	TATA spare parts
405173302901	HINGE REAR DOOR LH	TATA spare parts
405173302902	JK DOOR - PARTITION HINGES	TATA spare parts
405181100101	SUNVISOR	TATA spare parts
405181100102	INNER VIEW MIRROR	TATA spare parts
405181900101	STRETCHER BEDS	TATA spare parts
405181900102	SIREN - 2 TONE & BEACON - RED FLASHING	TATA spare parts
405181900103	JERRY CAN-20 LTS	TATA spare parts
405181900104	STAINLESS STEEL WATER TANK 50 LTS	TATA spare parts
405181900105	PICKAXE	TATA spare parts
405181900106	SHOVEL	TATA spare parts
405181900107	DOUBLE COAT HOOK HANGER	TATA spare parts
405181900108	DUSTBIN	TATA spare parts
405181900109	WASH BASIN	TATA spare parts
405181900110	TOWEL HOLDER	TATA spare parts
405181900111	TISSUE PAPER HOLDER	TATA spare parts
405181900112	DOCTOR'S CHAIR	TATA spare parts
405267106301	FRONT WINDSHIELD RUBBER BEADING_52 SKOOL	TATA spare parts
405288600101	REAR BUMPER_ STARBUS 32 SKOOL	TATA spare parts
405337300117	ENTRANCE DOOR ASSY.	TATA spare parts
405354300101	BUZZER	TATA spare parts
405354300102	BUZZER	TATA spare parts
405354300103	SOLENOID VALVE (12V)	TATA spare parts
405354300105	BUZZER (24)	TATA spare parts
405354304901	ELECTRIC BUZZER	TATA spare parts
405354304902	PUSH BELL SWITCH	TATA spare parts
405354400105	DOOR LAMP_HCBS	TATA spare parts
405354400106	HEIGHT MARKER LAMP(WHITE)_HCBS	TATA spare parts
405354400107	SIDE MARKER LAMP_HCBS	TATA spare parts
405354400108	SIDE BLINKER_HCBS	TATA spare parts
405354400109	REAR NUMBER PLATE LAMP_HCBS	TATA spare parts
405354400110	SPOT LAMP_HCBS	TATA spare parts

405354400111	FLOOR LAMP_HCBS	TATA spare parts
405354400112	REAR FOG LAMP_HCBS	TATA spare parts
405354400113	HEIGHT MARKER LAMP(RED)_HCBS	TATA spare parts
405354400114	HEAD LAMP WITH PARKING LAMP	TATA spare parts
405354400115	HEAD LAMP WITHOUT PARKING LAMP_HCBS	TATA spare parts
405354400116	FLOURO LAMP HCBS BEST BS1/2/3/4	TATA spare parts
405354400117	REVERSE HORN HCBS BEST	TATA spare parts
405354400118	BELL SWITCH PIPE MTD HCBS BEST	TATA spare parts
405354400119	BELL SWITCH PNL MTD HCBS BEST	TATA spare parts
405354400120	PASSENGER BELL HCBS BEST	TATA spare parts
405354400121	DRIVER CABIN LAMP HCBS BEST	TATA spare parts
405354400122	SOLOINOID VALVE - S.COIL - 24V HCBS BUS	TATA spare parts
405354400123	DOOR LIMIT SWITCH MICROSW	TATA spare parts
405354400124	BULB 24VX21W HCBS	TATA spare parts
405354400125	BULB 24VX10W HCBS	TATA spare parts
405354400126	SIDE PARKING BULB 24V 5 W	TATA spare parts
405354400127	PARKING BULB HCBS	TATA spare parts
405354400128	FOG LAMP RECTANGULAR	TATA spare parts
405354400129	ROUND HEAD LAMP RHD	TATA spare parts
405354400130	ROUND HEAD LAMP LHD	TATA spare parts
405354400131	FAN (24V)	TATA spare parts
405354400132	FLOUROCENT LAMP 24V	TATA spare parts
405354400133	MINI ROUND LAMP	TATA spare parts
405354400134	ROUND HEAD LAMP RHD	TATA spare parts
405354400135	ROUND HEAD LAMP LHD	TATA spare parts
405354400136	PILOT LAMP RED	TATA spare parts
405354400137	SIDE MARKER LAMP	TATA spare parts
405354400138	ROUND DOME LAMP	TATA spare parts
405354400139	CURVED TAIL LAMP 6HD AMBER	TATA spare parts
405354400140	ROUND CEILING LAMP	TATA spare parts
405354400141	NIGHT LAMP BLUE LENS	TATA spare parts
405354400142	HEIGHT MARKER LAMP	TATA spare parts
405354400143	LINE LIGHT 24V	TATA spare parts
405354400144	FRONT COMBINATION LAMP ASSY	TATA spare parts
405354400145	HEAD LAMP/RH	TATA spare parts
405354400146	HEAD LAMP/LH	TATA spare parts
405354400147	INSTRUMENT CLUSTER	TATA spare parts
405354400148	INTEREIOR ROOF LAMP	TATA spare parts
405354400149	STEP LIGHT	TATA spare parts
405354400151	SIDE INDICATOR LAMP - CLEAR	TATA spare parts
405354400152	SIDE INDICATOR LAMP - RED	TATA spare parts
405354400153	SIDE INDICATOR LAMP - YELLOW	TATA spare parts
405354400154	LICENCE PLATE LAMP	TATA spare parts
405354400155	PUSH BUTTON SWITCH PNEUMATIC DOOR-GREEN	TATA spare parts
405354400156	PUSH BUTTON SWITCH PNEUMATIC DOOR RED	TATA spare parts
405354400158	H L HAL BLB 75/70W - HCBS	TATA spare parts
405354400159	REFLECTOR ORANGE	TATA spare parts

405354400160	HEIGHT MARKER	TATA spare parts
405354400161	FLASHING LAMP AMBER 24 V	TATA spare parts
405354400163	RECT. LAMP	TATA spare parts
405354400164	FOG LAMP (RECT. )	TATA spare parts
405354400177	HEAD LAMP(CLR+W/O MOTOR+PARK)	TATA spare parts
405354400178	HEAD LAMP(CLR+MOTOR+PARK)	TATA spare parts
405354400179	TAIL LAMP	TATA spare parts
405354404901	BUZZER	TATA spare parts
405354404902	PASSENGER FAN (12V)	TATA spare parts
405354404903	PASSENGER BELL (12V)	TATA spare parts
405354404904	LINE LIGHT (12V)	TATA spare parts
405354404905	FLOUROSCENT LAMP (12V)	TATA spare parts
405354404906	BATTERY CABLE	TATA spare parts
405354404907	FUSE BOX	TATA spare parts
405354404908	AUTO FUSE	TATA spare parts
405354404909	ELECTRIC BUZZER	TATA spare parts
405354404910	DRIVER FAN	TATA spare parts
405354404911	PUSH BELL SWITCH	TATA spare parts
405354404912	DASHBOARD SWITCH	TATA spare parts
405354404913	NIGHT LAMP	TATA spare parts
405354404914	RED COLOR FOG LAMP ON REAR DOOM	TATA spare parts
405354404915	AMBER COLOR FOG LAMP ON FRONT DOOM	TATA spare parts
405354404916	HELLA LIGHT (MARKER LIGHT)	TATA spare parts
405354404917	DRIVER CABIN ROOF LAMP	TATA spare parts
405354404918	STEP LIGHT	TATA spare parts
405354404919	NUMBER PLATE LIGHT	TATA spare parts
405354404920	AMBER REFLECTOR (RECT)	TATA spare parts
405354404921	RED REFLECTOR (RECT)	TATA spare parts
405354404922	WHITE REFLECTOR (RECT)	TATA spare parts
405354404923	PLASTIC COVER FOR ROOF LAMP	TATA spare parts
405354404924	DESTI.TUBELIGHT	TATA spare parts
405354404925	TUBE LIGHT	TATA spare parts
405354404926	PASS DOOR LIGHT	TATA spare parts
405354404927	NIGHT LAMP	TATA spare parts
405354404928	DECKY LIGHT	TATA spare parts
405354407701	WHITE REFLECTOR (RECT)	TATA spare parts
405354408201	NUMBER PLATE LIGHT	TATA spare parts
405354409901	MARKER LIGHT	TATA spare parts
405354409902	ROOF LIGHT	TATA spare parts
405354409903	STEP LIGHT	TATA spare parts
405354409904	RED REFLECTOR (RECT)	TATA spare parts
405354409905	PLASTIC COVER ROOF LAMP	TATA spare parts
405354409906	DESTINATION TUBELIGHT	TATA spare parts
405354500101	TOGGLE SWITCH/ JOYSTICK TYPE	TATA spare parts
405354500102	5 POLE CONNECTOR WHEEL BOX	TATA spare parts
405354500103	BELL SWITCH	TATA spare parts
405354500104	SWITCH ( 12P-TOGGLE)	TATA spare parts

405354500105	FAN SWITCH	TATA spare parts
405354500106	DOOR PUSH SWITCH	TATA spare parts
405354500107	SWITCH PIANO TYPE	TATA spare parts
405354500108	AIR HORN SWITCH	TATA spare parts
405354500109	SWITCH (2P - ON/OFF)	TATA spare parts
405354500110	BELL SWITCH	TATA spare parts
405354500111	BELL PUSH SWITCH	TATA spare parts
405354500112	DASHBOARD SWITCH FOR LAMPS	TATA spare parts
405354500116	FAN	TATA spare parts
405354700131	PASSENGER FAN 24V	TATA spare parts
405354704901	DRIVER FAN	TATA spare parts
405354800101	SPEAKER	TATA spare parts
405358006301	REAR VIEW MIRROR ASSY/LH	TATA spare parts
405358006302	REAR VIEW MIRROR ASSY/RH	TATA spare parts
405361200101	RETRO FIT KIT FOR 32 SEATER STAR BUS	TATA spare parts
405361503206	U BOLT BIG	TATA spare parts
405361503207	U BOLT SMALL	TATA spare parts
405361503208	U BOLT FOR PRO SHAFT	TATA spare parts
405361503804	ALU PACKING FOR U BOLT (BIG)	TATA spare parts
405361503805	ALU PACKING FOR U BOLT (SMALL)	TATA spare parts
405361505201	U BOLT PADDING : BIG	TATA spare parts
405361505202	U BOLT PADDING : SMALL	TATA spare parts
405361507703	BALATA PACKING (SMALL)	TATA spare parts
405361507704	BALATA PACKING (BIG)	TATA spare parts
405362000102	FRONT BUMPER ASSEMBLY	TATA spare parts
405362000104	SUNVISOR ASSEMBLY	TATA spare parts
405362000107	DIGITAL CLOCK	TATA spare parts
405362004901	SIDE BLINKER FRONT	TATA spare parts
405362004902	REFLECTOR (WHITE)	TATA spare parts
405362004903	STOP SIGNAL	TATA spare parts
405362006301	FRONT FRP STRUCTURE COMPL	TATA spare parts
405362006302	FRP FRONT GRILL ASSEMBLY	TATA spare parts
405362006303	FRP FRONT FLAP ASSEMBLY	TATA spare parts
405362006304	FRONT PANEL	TATA spare parts
405362006305	FRP DASHBOARD	TATA spare parts
405362006306	DASH BOARD RESLF	TATA spare parts
405362009901	FRONT BUMPER WITH BRACKET	TATA spare parts
405362500101	FRP FRONT STRUCTURE(6HDS-MODF)	TATA spare parts
405362500102	FRP FRONT CTR PEICE (6HDS)	TATA spare parts
405362500103	FRONT CP FLAP FOR 6HDS MODEL	TATA spare parts
405362500104	FRP LAMP BEZEL-RH (MODEL 6HDS)	TATA spare parts
405362500105	FRP LAMP BEZEL-LH (MODEL 6HDS)	TATA spare parts
405362502303	FRONT WINDSHIELD ( RE SLF HMM)	TATA spare parts
405362602301	DESTINATION GLASS	TATA spare parts
405362702301	FRONT WINDSHIELD GLASS	TATA spare parts
405362706306	FRONT FRP INSPECTION LID	TATA spare parts
405362706307	FRP HEADLAMP COVER (RH)	TATA spare parts

405362706308	FRP HEADLAMP COVER (LH)	TATA spare parts
405362706309	FRONT PLASTIC GRILL	TATA spare parts
405362706310	FRP FRONT PANEL	TATA spare parts
405363000105	RVM ARM ASSEMBLY	TATA spare parts
405363000106	RVM ARM ASSEMBLY (DRIVER)	TATA spare parts
405363000107	HUB CAP MTG CAP	TATA spare parts
405363000108	SOLENOID VALVE S. COIL	TATA spare parts
405363002301	PASSENGER DOOR GLASS	TATA spare parts
405363002302	PASSENGER DOOR GLASS	TATA spare parts
405363002303	PASSENGER DOOR GLASS	TATA spare parts
405363002304	SWING PARTITION GLASS	TATA spare parts
405363002305	PASSENGER DOOR GLASS	TATA spare parts
405363002306	WINDOW ASSEMBLY DRIVER	TATA spare parts
405363200112	HINGE ASSEMBLY	TATA spare parts
405363605201	WAIST RAIL BEADING	TATA spare parts
405363605601	FRONT DOOR ASSIST HANDLE MS (I'DIA)	TATA spare parts
405363700104	FOOT STEP BOX INSTL	TATA spare parts
405363700105	SKIRT PANEL COMP.	TATA spare parts
405363700107	PANEL	TATA spare parts
405363700110	PANEL	TATA spare parts
405363700111	SKIRT PANEL COMP.	TATA spare parts
405363700112	SKIRT PANEL COMP.	TATA spare parts
405363700114	SKIRT PANEL W/A COMPL	TATA spare parts
405363700115	SKIRT PANEL W/A COMPL	TATA spare parts
405363700118	SKIRT PANEL	TATA spare parts
405363700119	FLAP ASSY COMPLETE FUEL TANK	TATA spare parts
405363702301	J/K DOOR GLASS	TATA spare parts
405363702302	QUARTER GLASS	TATA spare parts
405363702303	DRIVER PARTITION GLASS	TATA spare parts
405363702304	MAIN WINDOW BOTTOM FIX GLASS	TATA spare parts
405363702305	MAIN WINDOW SLIDING GLASS	TATA spare parts
405363702306	MAIN WINDOW SLIDING GLASS	TATA spare parts
405363702307	MID WINDOW BOTTOM FIX GLASS	TATA spare parts
405363702308	MID WINDOW SLIDING GLASS	TATA spare parts
405363702309	NEAR DRIVER DOOR WINDOW BOTTOM FIX GLAS	TATA spare parts
405363702310	NEAR DRIVER DOOR WINDOW SLIDING GLASS	TATA spare parts
405363702311	NEAR DRIVER DOOR SLIDING GLASS	TATA spare parts
405363702312	SMALL WINDOW BOTTOM FIX GLASS	TATA spare parts
405363702313	SMALL WINDOW SLIDING GLASS	TATA spare parts
405363702314	SMALL & DRIVER DOOR FOR WINDOW SLIDING G	TATA spare parts
405363702315	WINDOW TOP FIX GLASS	TATA spare parts
405363702316	WINDOW SLIDING GLASS	TATA spare parts
405363702317	EMERGENCY DOOR BOTTOM FIX GLASS	TATA spare parts
405363702318	EMERGENCY DOOR WINDOW SLIDING GLASS	TATA spare parts
405363702319	WINDOW SLIDING GLASS	TATA spare parts
405363705201	RUB RAIL BEADING	TATA spare parts
405364000103	REAR BUMPER ASSEMBLY	TATA spare parts



405364002301	REAR WINDSHIELD	TATA spare parts
405364004901	REFLECTOR (RED)	TATA spare parts
405364006301	FRP REAR STRUCTURE	TATA spare parts
405364006302	REAR FLAP ASSEMBLY	TATA spare parts
405364006303	REAR WINDSHIELD MOULDING	TATA spare parts
405364006304	REAR FRP STRUCTURE	TATA spare parts
405364006305	REAR FRP STRUCTURE	TATA spare parts
405364200103	FRP REAR STRUCTURE	TATA spare parts
405364200104	FRP REAR STRUCTURE	TATA spare parts
405364700102	FRP FLAP COMP. (RE)	TATA spare parts
405364702301	REAR GLASS/LH (TEMPERED)	TATA spare parts
405364702302	REAR GLASS/RH (TEMPERED)	TATA spare parts
405364702303	TAIL LAMP BASE - RH	TATA spare parts
405364702304	TAIL LAMP BASE - LH	TATA spare parts
405364702305	REAR WINDSHIELD GLASS	TATA spare parts
405364706301	FLAPLOCK	TATA spare parts
405365609901	GRAB RAIL SOCKET	TATA spare parts
405367000106	WINDOW ASSEMBLY EMERGENCY	TATA spare parts
405367000107	SD.WIN.ASSY(CTB/TOPFIX(1/2)/GREEN)	TATA spare parts
405367000108	SD.WIN.ASSY(CTB/TOPFIX(1/2)/GREEN)	TATA spare parts
405367000109	SD.WIN.ASSY(CTB/TOPFIX(1/2)/GREEN)	TATA spare parts
405367000110	SD.WIN.ASSY(CTB/TOPFIX(1/2)/GREEN)	TATA spare parts
405367000111	SD.WIN.ASSY(CTB/TOPFIX(1/2)/GREEN)	TATA spare parts
405367000112	SD.WIN.ASSY(CTB/TOPFIX(1/2)/GREEN)	TATA spare parts
405367000113	DR DOOR WINDOW(CTB-GREEN-2PC)	TATA spare parts
405367000114	EMG.WIN.ASSY(CTB TOP1/2 FIX BOTTM SLID/G	TATA spare parts
405367000115	SD WIN ASSY(TOP/BOTT SLD/CTB/GREEN.	TATA spare parts
405367000116	SD WIN ASSY(TOP/BOTT SLD/CTB/GRN)	TATA spare parts
405367000117	WINDOW ASSY(CTB-VER.SLD-GREEN)	TATA spare parts
405367000118	WINDOW ASSY(CTB-VER.SLD-GREEN)	TATA spare parts
405367000119	SD.WIN.ASSY(CTB/CLR/TOPFIX/PC)	TATA spare parts
405367000120	SD.WIN.ASSY(CTB/CLR/TOPFIX/PC)	TATA spare parts
405367000121	SD.WIN.ASSY(CTB/CLR/TOPFIX/PC)	TATA spare parts
405367000122	SIDE EMG WIN ASSY/TOP FIX CLEAR	TATA spare parts
405367000123	SIDE WIN ASSY/TOP FIX CLEAR.	TATA spare parts
405367000124	SIDE WIN ASSY/TOP FIX CLEAR.	TATA spare parts
405367000125	SD WINDOW ASSY(CTB/2PC/CLEAR/RH)	TATA spare parts
405367000126	SD WIN ASSY(TOPFIX BOTTM SLD/GRN)	TATA spare parts
405367000127	SD WIN ASSY(TOP FIX BOTTM SLD/GRN)	TATA spare parts
405367000128	SD.WIN.ASSY(CTB/TOPFIX/GREEN/EMG.)	TATA spare parts
405367000129	DRIV.DOOR WINDOW (2PC/CTB/GREEN/RHD)	TATA spare parts
405367000130	WINDOW SLIDINGEN	TATA spare parts
405367000131	WINDOW SLIDING	TATA spare parts
405367000132	WINDOW SLIDING	TATA spare parts
405367000133	WINDOW SLIDING	TATA spare parts
405367000134	WINDOW SLIDING	TATA spare parts
405367000135	WINDOW SLIDING	TATA spare parts

405367000141	SIDE WINDOW ASSEMBLY	TATA spare parts
405367002301	FIX GLASS	TATA spare parts
405367002302	SLIDING GLASS	TATA spare parts
405367002303	FIX GLASS	TATA spare parts
405367002304	SLIDING GLASS	TATA spare parts
405367002305	FIX GLASS	TATA spare parts
405367002306	SLIDING GLASS	TATA spare parts
405367002307	FIX GLASS	TATA spare parts
405367002308	SLIDING GLASS	TATA spare parts
405367002309	SLIDING GLASS	TATA spare parts
405367002310	SLIDING GLASS	TATA spare parts
405367005201	MAIN WINDOW (CO-DRIVER SIDE)	TATA spare parts
405367005202	MAIN WINDOW (DRIVER SIDE)	TATA spare parts
405367005203	SMALL WINDOW (CO-DRIVER SIDE)	TATA spare parts
405367005204	SMALL WINDOW (DRIVER SIDE)	TATA spare parts
405367005205	DRIVER DOOR WINDOW	TATA spare parts
405367005206	WINDOW	TATA spare parts
405367009901	WINDOW:LASTBAY:LHS	TATA spare parts
405367009903	WINDOW:SIDEEMERGENCYEXIT	TATA spare parts
405367009904	WINDOW:MAIN:LHS	TATA spare parts
405367100103	FRONT WINDSHIELD_HCBS	TATA spare parts
405367100104	SIDE WINDOW ASSY DRV DOOR HCBS BEST	TATA spare parts
405367102306	WINDSHIELD GLASS (LAMINATED) BS1/2/4	TATA spare parts
405367102307	FRONT W/S GLASS (LAMINATED)	TATA spare parts
405367102308	DESTINATION GLASS	TATA spare parts
405367102309	FRONT W/S GLASS	TATA spare parts
405367102310	FRONT SLIDING GLASS	TATA spare parts
405367102311	FRONT SLIDING GLASS	TATA spare parts
405367102312	REAR SIDE WINDOW (FRONT)	TATA spare parts
405367102313	FRONT W/S 1210/LH (3PC-TUF)	TATA spare parts
405367102314	FRONT W/S 1210/RH (3PC-TUF)	TATA spare parts
405367300002	SD WIN ASSY(CTB/3PC/GREEN/PC)	TATA spare parts
405367300003	SD WIN ASSY(CTB/3PC/GREEN/PC)	TATA spare parts
405367300004	SD WIN ASSY(CTB/3PC/GREEN/PC)	TATA spare parts
405367300005	SD WIN ASSY(CTB/3PC/GREEN/PC)	TATA spare parts
405367300006	SD WINDOW ASSY(CTB/2PC/DRV.DOOR/PC)	TATA spare parts
405367300007	S.WIN.ASSY(FLOCK/2PC/CURVED/GREEN)	TATA spare parts
405367300008	S.WIN.ASSY(FLOCK/2PC/CURVED/GREEN)	TATA spare parts
405367300009	S.WIN.ASSY(FLOCK/2PC/CURVED/GREEN)	TATA spare parts
405367300010	S.WN.ASSY(613/CUR/RH/TAP/GR/PC)	TATA spare parts
405367300102	SIDE WINDOW ASSEMBLY_HCBS	TATA spare parts
405367300103	SIDE WINDOW ASSEMBLY_HCBS	TATA spare parts
405367300104	SIDE WINDOW ASSEMBLY_HCBS	TATA spare parts
405367300105	SIDE WINDOW ASSEMBLY_HCBS	TATA spare parts
405367300106	SIDE WINDOW ASSEMBLY_HCBS	TATA spare parts
405367300107	SIDE WINDOW ASSEMBLY_HCBS	TATA spare parts
405367300109	SIDE WINDOW ASSY HCBS BEST	TATA spare parts

405367300110	SIDE WINDOW ASSY HCBS BEST	TATA spare parts
405367300111	SIDE WINDOW ASSY HCBS BEST	TATA spare parts
405367300112	SIDE WINDOW ASSY HCBS BEST	TATA spare parts
405367300113	SIDE WINDOW ASSY HCBS BEST	TATA spare parts
405367300114	SIDE WINDOW ASSY HCBS BEST	TATA spare parts
405367300132	SIDE WINDOW ASSY	TATA spare parts
405367300133	SIDE WINDOW ASSY	TATA spare parts
405367300134	SIDE WINDOW ASSY	TATA spare parts
405367300135	SIDE WINDOW ASSY	TATA spare parts
405367300136	SIDE WINDOW ASSY	TATA spare parts
405367300137	EMG. SIDE WINDOW ASSY	TATA spare parts
405367300138	SIDE WINDOW ASSY	TATA spare parts
405367300139	DRIVER DOOR WINDOW GLASS	TATA spare parts
405367300140	SIDE WINDOW ASSEMBLY	TATA spare parts
405367300141	SIDE WINDOW ASSEMBLY	TATA spare parts
405367300142	SIDE WINDOW ASSEMBLY	TATA spare parts
405367300143	SIDE WINDOW DRIVER	TATA spare parts
405367300144	SIDE WINDOW ASSY( 1378 X 965 )	TATA spare parts
405367300145	SIDE WINDOW ASSY ( 1379 X 965 )	TATA spare parts
405367300146	SIDE WINDOW ASSY ( 1464 X 965 )	TATA spare parts
405367300147	SD WINDOW ASSY(OPTYPE-TOP SLD-GRN-PC)	TATA spare parts
405367300148	SIDE WINDOW ASSY ( 1464 X 965 )	TATA spare parts
405367300149	SIDE WINDOW ASSY - EMG ( 609 X 903 )	TATA spare parts
405367300150	DR. DOOR WINDOW ASSY ( 750/1043X712 )	TATA spare parts
405367300151	GLASS TINTED (522X722X5 THK)	TATA spare parts
405367300152	GLASS TINTED (704X722X5 THK)	TATA spare parts
405367300153	SD WINDOW ASSY(OPTYPE-3PC-GREEN)	TATA spare parts
405367300154	SD WINDOW ASSY(OPTYPE-3PC-GREEN)	TATA spare parts
405367300155	SD WINDOW ASSY(OPTYPE-3PC-GREEN)	TATA spare parts
405367300156	SD WINDOW ASSY(OPTYPE-3PC-GREEN)	TATA spare parts
405367300157	SD WINDOW ASSY(OPTYPE-EMG-3PC-GREEN)	TATA spare parts
405367300158	SD WINDOW ASSY(OPTYPE-2PC-CLEAR)	TATA spare parts
405367300159	SD WINDOW ASSY(OPTYPE-TAP-3PC-GRN)	TATA spare parts
405367300160	SD WINDOW ASSY(OPTYPE-TOP SLD)	TATA spare parts
405367300161	SD WINDOW ASSY(OPTYPE-3PC-GREEN)	TATA spare parts
405367300162	SD WINDOW ASSY(DRV DOOR-OPTYPE)	TATA spare parts
405367300163	SIDE WINDOW ASSY ( 1458 X 967 )	TATA spare parts
405367300164	SIDE WINDOW ASSY( 1373 X 967 )	TATA spare parts
405367300165	SIDE WINDOW ASSY EMG ( 609 X 896 )	TATA spare parts
405367300166	DR. DOOR WINDOW ASSY ( 737 /1018 X 710 )	TATA spare parts
405367300167	SIDE WIN ASSY(CTB/TOP FIX/CLEAR)	TATA spare parts
405367300168	SIDE WIN ASSY(CTB/TOP FIX/CLEAR)	TATA spare parts
405367300169	SIDE WIN ASSY/TOP FIX CLEAR.	TATA spare parts
405367300170	SIDE EMG WIN ASSY/TOP FIX CLEAR	TATA spare parts
405367300171	GLASS TINTED (281X1610X5 THK)	TATA spare parts
405367300172	SD.WIN.ASSY(CTB/TOPFIX(1/2)/GREEN)	TATA spare parts
405367300173	SD.WIN.ASSY(CTB/TOPFIX(1/2)/GREEN)	TATA spare parts

405367300174	SD.WIN.ASSY(CTB/TOPFIX(1/2)/GREEN)	TATA spare parts
405367300175	SD.WIN.ASSY(CTB/TOPFIX(1/2)/GREEN)	TATA spare parts
405367300176	SD.WIN.ASSY(CTB/TOPFIX(1/2)/GREEN)	TATA spare parts
405367300177	EMG.WIN.ASSY(CTB TOP1/2 FIX BOTTM SLID/G	TATA spare parts
405367302304	QUARTER GLASS	TATA spare parts
405367302305	MAIN WINDOW SLIDING GLASS	TATA spare parts
405367302306	MAIN WINDOW SLIDING GLASS	TATA spare parts
405367302307	NR DR'S DOOR WINDOW SLIDING GLASS	TATA spare parts
405367302308	NR DR'S DOOR WINDOW SLIDING GLASS	TATA spare parts
405367302309	EMER DOOR WINDOW SLIDING GLASS	TATA spare parts
405367302310	EMER DOOR WINDOW SLIDING GLASS	TATA spare parts
405367302311	DRIVER DOOR SLIDING GLASS	TATA spare parts
405367302312	DRIVER DOOR SLIDING GLASS	TATA spare parts
405367302313	J/K DOOR GLASS	TATA spare parts
405367302314	TOP FIXED GLASS	TATA spare parts
405367302315	BOTTOM FIXED GLASS	TATA spare parts
405367302316	TOP FIXED GLASS	TATA spare parts
405367302317	BOTTOM FIXED GLASS	TATA spare parts
405367302318	ENTERENCE DOOR	TATA spare parts
405367302319	MAIN WINDOW (TOP FIXED)	TATA spare parts
405367302320	MAIN WINDOW (BOTTOM SLIDING)	TATA spare parts
405367302324	QARTER GLASS-RH	TATA spare parts
405367302325	QUARTER GLASS-LH	TATA spare parts
405367302359	WINDOW:DRIVER'SDOOR:LHS	TATA spare parts
405367302361	BOTTOMFIXEDGLASS	TATA spare parts
405367302364	TOPSLIDINGGLASS:FRONT	TATA spare parts
405367302365	TOPSLIDINGGLASS:REAR	TATA spare parts
405367302368	BOTTOMFIXEDGLASS	TATA spare parts
405367302369	BOTTOMFIXEDGLASS	TATA spare parts
405367302372	TOPSLIDINGGLASS	TATA spare parts
405367302373	TOPSLIDINGGLASS	TATA spare parts
405367302388	SIDE WINDOW GLASS	TATA spare parts
405367302389	QUARTER GLASS (DRIVER)	TATA spare parts
405367302390	QUARTER GLASS (DRIVER)	TATA spare parts
405367302391	SIDE WINDOW GLASS¿¿	TATA spare parts
405367302392	SIDE WINDOW	TATA spare parts
405367302394	GLASS (290X1142X5 THK)	TATA spare parts
405367302395	GLASS (265X1764X5 THK)	TATA spare parts
405367302396	GLASS TINTED (265X1598X5 THK)	TATA spare parts
405367302397	GLASS TINTED (397X722X5 THK)	TATA spare parts
405367302398	GLASS REAR/LH (TUF)(609)	TATA spare parts
405367302399	REAR WINDSHIELD GLASS/CTR(2150WD)	TATA spare parts
405367309901	GLASS FOR MASAT DOOR(REAR)	TATA spare parts
405367312301	GLASS TINTED (265X1945X5 THK)	TATA spare parts
405367312302	GLASS TINTED (1087X441X5 THK)	TATA spare parts
405367312303	GLASS TINTED (265X2095X4 THK)	TATA spare parts
405367502310	GLASS (301X1610X4 THK)	TATA spare parts

405367502312	GLASS DARK GREY/5MM(PART-1210)	TATA spare parts
405367702301	MAIN WINDOW TOP FIX GLASS	TATA spare parts
405367702302	NR DR'S DOOR WINDOW TOP FIX GLASS	TATA spare parts
405367702303	EMER DOOR WINDOW TOP FIX GLASS	TATA spare parts
405367800102	REAR WINDSHIELD	TATA spare parts
405367802310	W/S GLASS (TEMP-SINGLE PC-6HD)	TATA spare parts
405367802311	W/S GLASS LH (TEMPERED)	TATA spare parts
405367802312	W/S GLASS RH (TEMPERED)	TATA spare parts
405367802313	W/S GLASS CENTER (TEMPERED)	TATA spare parts
405367802314	W/S GLASS/ CENTER (TEMPERED)	TATA spare parts
405367802315	W/S GLASS/ LH (TEMPERED)	TATA spare parts
405367802316	W/S GLASS RH (TEMPERED)	TATA spare parts
405367802317	REAR W/S GLASS	TATA spare parts
405367802318	REAR SLIDING GLASS	TATA spare parts
405367802319	REAR SLIDING GLASS	TATA spare parts
405367802320	REAR SIDE FIXED	TATA spare parts
405367802321	REAR CENTRE FIXED	TATA spare parts
405367802322	REAR SIDE WINDOW (TOP FIXED)	TATA spare parts
405367802323	REAR SIDE WINDOW (REAR)	TATA spare parts
405367802324	EMERGENCY EXIT WINDOW (TOP)	TATA spare parts
405367802325	EMERGENCY EXIT WINDOW (FRONT)	TATA spare parts
405367802326	EMERGENCY EXIT WINDOW (REAR)	TATA spare parts
405367802327	REAR EMERGENCY DOOR GLASS (609)	TATA spare parts
405367802328	REAR CENTER GLASS (TEMPERED)	TATA spare parts
405367802329	GLASS REAR/CENTRE (5MM)(5E MODEL)	TATA spare parts
405367802330	GLASS REAR/LH(TUF)(5E MODEL)	TATA spare parts
405367802331	GLASS REAR/RH(TUF)(5E MODEL)	TATA spare parts
405368900103	DASHBOARD	TATA spare parts
405368900104	FRP DASHBOARD COMPLETE	TATA spare parts
405369205203	T-BEADING FOR WINDSHIELD	TATA spare parts
405369705201	FLAT BEADING	TATA spare parts
405369705202	WAIST RAIL BEADING	TATA spare parts
405369705203	RUB RAIL BEADING	TATA spare parts
405369705204	GUTTER BEADING FOR SIDE	TATA spare parts
405369705205	FRONT & REAR GUTTER BEADING	TATA spare parts
405369705206	FRONT SHOW W/RAIL BEADING	TATA spare parts
405369705207	REAR SHOW W/RAIL BEADING	TATA spare parts
405369705208	WIRING BEADING	TATA spare parts
405369805201	ROOF TOP BEADING	TATA spare parts
405369805203	BEADING END2676	TATA spare parts
405371102301	MODESTY PARTITION GLASS	TATA spare parts
405371102302	MODESTY PARTITION GLASS	TATA spare parts
405371102303	DR'S PARTITION GLASS	TATA spare parts
405372000102	DRIVER DOOR ASSY LHD	TATA spare parts
405372000103	FRONT PASSENGER J/K DOOR	TATA spare parts
405372000104	DRIVER DOOR	TATA spare parts
405372008201	DRIVER DOOR ASSEMBLY	TATA spare parts

405372300104	DRIVER DOOR LOCK_HCBS	TATA spare parts
405372300105	DRIVER DOOR LOCK_HCBS	TATA spare parts
405372300106	DRIVER DOOR LOCK_HCBS	TATA spare parts
405372300107	DRIVER DOOR LOCK_HCBS	TATA spare parts
405372300108	DRIVER DOOR LOCK RHD	TATA spare parts
405372300109	DRIVER DOOR LOCK LHD	TATA spare parts
405372300110	ASSY DOOR STRIKER	TATA spare parts
405372300111	ASSY INNER HANDLE	TATA spare parts
405372300112	DOOR HANDLE WITH KEY (RH) RHD	TATA spare parts
405372300113	ASSY OUTER HANDLE - LH	TATA spare parts
405372300114	LINK - LH (INNER HANDLE)	TATA spare parts
405372300115	FORK FOR LOCK	TATA spare parts
405372300116	ASSY WINDING REGULATOR LH	TATA spare parts
405372300117	ASSEMBLY HANDLE (WINDING REGULATOR)	TATA spare parts
405372300118	DRIVER DOOR COMPL ASSY	TATA spare parts
405372300119	LOCK ASSEMBLY	TATA spare parts
405372300120	OUTER HANDLE WITH KEYS	TATA spare parts
405372300121	INNER HANDLE	TATA spare parts
405372300122	STRIKER PLATE	TATA spare parts
405372300123	DOVE TAIL	TATA spare parts
405372300124	MIRROR	TATA spare parts
405372300125	DOOR ROLLER	TATA spare parts
405372300126	PIVOT FEMALE	TATA spare parts
405372300127	OUTSIDE MIRROR	TATA spare parts
405372300133	DRIVER CAB MIRROR	TATA spare parts
405372302301	FRONT DOOR GLASS	TATA spare parts
405372302901	HINGES	TATA spare parts
405372302902	HINGES	TATA spare parts
405372303301	MIRROR BRACKET	TATA spare parts
405372303302	DRIVER CAB MIRROR BRACKET	TATA spare parts
405372305601	KNOB (INNER LOCK)	TATA spare parts
405372305602	DRIVER DOOR HANDLE	TATA spare parts
405372306001	LINK - OUTER HANDLE	TATA spare parts
405372306002	LINK POPUP KNOB - LH	TATA spare parts
405372306003	MS LEVER FOR J/K DOOR	TATA spare parts
405372306301	PVC BLACK HANDLE	TATA spare parts
405372306701	DOOR GUIDE PIN	TATA spare parts
405372306702	DOOR LOCKING PIN	TATA spare parts
405372307901	MS SPINDLE FOR J/K DOOR	TATA spare parts
405372308201	PLATE WELDED BUSH (MALE)	TATA spare parts
405372308501	GRAB RAIL SOCKET	TATA spare parts
405372309001	SOLENOID AIR CONTROL VALVE	TATA spare parts
405372309901	SNAP CONNECTOR - LH	TATA spare parts
405372309902	HOLDER (REGULATING GLASS)	TATA spare parts
405372309903	SPACER (REGULATING GLASS)	TATA spare parts
405372309904	REGULATING GLASS - LH	TATA spare parts
405372309905	HINGE WITHOUT HANDLE	TATA spare parts

405372309906	HINGE WITH HANDLE	TATA spare parts
405372309907	ALUMINIUM BASE SOCKET WITH GUM METAL BU	TATA spare parts
405372309908	PNEUMATIC AIR CYLINDER 5 STROKE	TATA spare parts
405372309909	1' ALUMINIUM BEND SOCKET FOR ASSIST HAND	TATA spare parts
405372309910	MS PIPE DOR DOOR ASSIST HANDLE	TATA spare parts
405372309911	HEAVY DUTY LOCK LH	TATA spare parts
405372309912	LOCK COVER	TATA spare parts
405372309913	HEAVY DUTY LOCK (RH)	TATA spare parts
405372500101	DRIVER DOOR WINDOW ASSY_HCBS	TATA spare parts
405372500102	REAR VIEW MIRROR	TATA spare parts
405372500103	REAR VIEW MIRROR ARM ASSY	TATA spare parts
405372500104	REAR VIEW MIRROR ARM ASSY	TATA spare parts
405372500105	RVM ARM ASSY(6HD/613-LHD-LH)	TATA spare parts
405372500106	RVM ARM ASSY(6HD/613-LHD-RH)	TATA spare parts
405372500107	REAR VIEW MIRROR ARM ASSY	TATA spare parts
405372502301	W/S GLASS (LAM-SINGLE PC-6HD)	TATA spare parts
405372502302	W/S GLASS/ RH (TEMPERED)	TATA spare parts
405372502303	W/S GLASS/ CENTER (TEMPERED)	TATA spare parts
405372502304	W/S GLASS/ RH (TEMPERED)	TATA spare parts
405372509901	WINDOW FOR DOOR	TATA spare parts
405372509902	WINDOW LOCK FOR WINDOW	TATA spare parts
405373000105	REAR LH SIDE PASSENGER DOOR	TATA spare parts
405373000106	REAR RH SIDE PASSENGER DOOR	TATA spare parts
405373000107	PASSENGER DOOR ASSY	TATA spare parts
405373000108	EMERGENCY DOOR ASSY (LHD)	TATA spare parts
405373000109	PASSENGER DOOR ASSY	TATA spare parts
405373000110	PASSENGER DOOR ASSY	TATA spare parts
405373000111	PASSENGER DOOR ASSY	TATA spare parts
405373000112	PASSENGER DOOR ASSY	TATA spare parts
405373000113	PASSENGER DOOR ASSY	TATA spare parts
405373000114	PASSENGER DOOR ASSY	TATA spare parts
405373000115	ENTRANCE DOOR ASSY	TATA spare parts
405373000116	ENTRANCE DOOR ASSY	TATA spare parts
405373000118	PASSENGER DOOR ASSY COMPLETE	TATA spare parts
405373000119	ENTRANCE DOOR ASSY	TATA spare parts
405373000120	ENTRANCE DOOR ASSY	TATA spare parts
405373000121	PASSENGER DOOR ASSY	TATA spare parts
405373000122	ENTRANCE DOOR ASSY	TATA spare parts
405373000123	ENTRANCE DOOR ASSY	TATA spare parts
405373000125	ENTRANCE DOOR ASSY	TATA spare parts
405373008201	PASSENGER DOOR ASSEMBLY COMPL	TATA spare parts
405373008202	PASSENGER DOOR ASSEMBLY COMPL	TATA spare parts
405373100108	PASSENGER DOOR FRAME (TRIANGLE CUT)	TATA spare parts
405373100109	PASSENGER DOOR FRAME (RECTANGULAR)	TATA spare parts
405373300106	PNEUMATIC CYLINDER HCBS BS1/2/3/4	TATA spare parts
405373300113	DOOR BRUSH	TATA spare parts
405373300114	DOUBLE ROLLER BEARING	TATA spare parts

405373300115	BEARING CASE/LOWER (RHD)	TATA spare parts
405373300116	BEARING CASE/LOWER (LHD)	TATA spare parts
405373300117	PROTECTOR FOR DOOR GLASS	TATA spare parts
405373300118	PROTECTOR FOR DOOR GLASS	TATA spare parts
405373300119	SHAFT	TATA spare parts
405373300120	SHAFT	TATA spare parts
405373300121	GRAB HANDLE PIPE	TATA spare parts
405373300122	END BUSH	TATA spare parts
405373300123	BUZZER COVER	TATA spare parts
405373300124	BRACKET	TATA spare parts
405373300125	STOPPER ARM	TATA spare parts
405373300126	STOPPER ARM SHAFT	TATA spare parts
405373300127	SLIDE BEARING	TATA spare parts
405373300128	STOPPER LOCK	TATA spare parts
405373300129	EMERGENCY DOOR RAIL	TATA spare parts
405373300130	MS UNION	TATA spare parts
405373300131	MS T - UNION	TATA spare parts
405373300132	CYLINDER BRACKET RHD	TATA spare parts
405373300133	CYLINDER BRACKET LHD	TATA spare parts
405373300134	LEVER COMPLETE RHD	TATA spare parts
405373300135	LEVER COMPLETE LHD	TATA spare parts
405373300136	DOOR ENGINE BRACKET	TATA spare parts
405373300137	DOOR ENGINE BRKT	TATA spare parts
405373300138	CYLINDER BRACKET	TATA spare parts
405373300139	BEAM	TATA spare parts
405373300140	BEAM	TATA spare parts
405373300141	LINK ROD	TATA spare parts
405373300142	ROD END BEARING	TATA spare parts
405373300143	FLEXIBLE TUBE (6 DIA LENGTH 10 MTR)	TATA spare parts
405373300144	POLYMER TUBE (6 DIA LENGTH 10 MTR)	TATA spare parts
405373300145	PUSH PULL VALVE	TATA spare parts
405373300146	NUT + FERRULE + SLEEVE	TATA spare parts
405373300147	SPEED CONTROL VALVE	TATA spare parts
405373300148	ADAPTER	TATA spare parts
405373300149	REPAIR KIT FOR 6MM POLYMER TUB	TATA spare parts
405373300150	STUD COUPLING	TATA spare parts
405373300151	CONNECTOR	TATA spare parts
405373300152	INNER HANDLE	TATA spare parts
405373300153	STRIKER PLATE	TATA spare parts
405373300154	WINDOW LOCK : EMERGENCY	TATA spare parts
405373300155	HINGES SECTION	TATA spare parts
405373300156	LOCK ASSEMBLY	TATA spare parts
405373300157	STRIKER PLATE	TATA spare parts
405373300165	SEAL KIT FOR VALVE	TATA spare parts
405373300166	SEAL KIT FOR CYLINDER	TATA spare parts
405373300167	REPAIR KIT FOR DC SOLENOID	TATA spare parts
405373300191	GLASS TINTED (265X1613X5 THK)	TATA spare parts



405373300192	GLASS (265X1947X5 THK)	TATA spare parts
405373300193	GLASS (265X2080X4 THK)	TATA spare parts
405373302905	HINGES SECTION	TATA spare parts
405373304601	BRASS SWIVEL COUPLING	TATA spare parts
405373304602	BRASS COUPLING	TATA spare parts
405373304901	YELLOW SWITCH FOR PNEUMATIC DOOR	TATA spare parts
405373304902	GREEN SWITCH FOR PNEUMATIC DOOR	TATA spare parts
405373305001	SEAT TOP RAIL	TATA spare parts
405373306501	BRASS COUPLING NUT	TATA spare parts
405373306801	BRAKE HOSE PIPE	TATA spare parts
405373306802	PVC PIPR FOR PNEUMATIC DOOR	TATA spare parts
405373307706	WEAT.STRIP(PASS.DOOR-BIG BULB)	TATA spare parts
405373307707	TRIM STRIP (TRIM RAIL)	TATA spare parts
405373307708	WEAT.STRIP(PASS.DR-MDL-SMALL D)	TATA spare parts
405373307709	WEAT.STRIP(PASS.DR-FLAP/SHAFT)	TATA spare parts
405373307710	END CAP	TATA spare parts
405373307711	WEATH.STRIP(PASS.DR-GLASS KEY)	TATA spare parts
405373307712	WEAT.STRIP(PASS.DOOR GLASS)	TATA spare parts
405373307713	WEAT.STRIP(PASS.DR-FLAP/SHAFT)	TATA spare parts
405373307714	WEAT.STRIP(PASS.DR-MDL.SMALL D)	TATA spare parts
405373307715	WEAT.STRIP(PASS.DOOR.BIG BULB)	TATA spare parts
405373307716	WEATHER STRIP(PAS.DR-BIG BULB)	TATA spare parts
405373309001	BRASS FORGE NEEDLE VALVE	TATA spare parts
405373309901	UNION TEE	TATA spare parts
405373309902	FRP SWITCH STAND	TATA spare parts
405373502303	PASSENGER DOOR GLASS_HCBS	TATA spare parts
405373502304	PASSENGER DOOR GLASS_HCBS	TATA spare parts
405373502305	PASSENGER DOOR GLASS_HCBS	TATA spare parts
405373502307	PASSENGER_DOOR_GLASS_HCBS_BEST	TATA spare parts
405373502308	PASSENGER DOOR GLASS HCBS BEST	TATA spare parts
405373502309	PASSENGER DOOR GLASS	TATA spare parts
405373502310	FRONT PASSENGER DOOR GLASS	TATA spare parts
405373502311	REAR PASSENGER DOOR GLASS	TATA spare parts
405373502317	PASSENGER DOOR GLASS	TATA spare parts
405373502319	GLASS TINTED (281X1610X4 THK)	TATA spare parts
405373502320	GLASS TINTED (301X1610X4 THK)	TATA spare parts
405373502323	GLASS (252X1870X5 THK)	TATA spare parts
405373509901	WINDOW FOR DOOR	TATA spare parts
405373700101	INSP DOOR PANEL	TATA spare parts
405373700102	INSP DOOR PANEL	TATA spare parts
405374303301	HATRACK BKT CASTING	TATA spare parts
405374303302	HATRACK BRACKET	TATA spare parts
405374307701	PACKING FOR HATRACK (TOP)	TATA spare parts
405374309901	CLOSE GROMMET FOR HATRACK	TATA spare parts
405374309902	OPEN GROMMET FOR HATRACK	TATA spare parts
405376006001	WINDOW LOCK	TATA spare parts
405376009901	MAIN WINDOW WEATHER SHADE	TATA spare parts

405376009902	SMALL WINDOW WEATHER SHADE	TATA spare parts
405376602901	PVC ROUND HINGES COVER	TATA spare parts
405376603401	PVC END BUSH FOR WINDOW LOCK	TATA spare parts
405376603402	5/8INCH CLOSE BUSH	TATA spare parts
405376603403	1INCH SQUARE BUSH	TATA spare parts
405376605201	ABS BEADING END BLACK (REAR W/RAIL BEADI	TATA spare parts
405376605202	ABS BEADING END APPLE WHITE(ROOF-BEADING	TATA spare parts
405376605203	WINDOW NYLON RUNNER	TATA spare parts
405376605204	NYLON GUIDE RING FOR TOWER BOLT	TATA spare parts
405376605601	PLAIN BLACK HANDLE	TATA spare parts
405376605901	PVC KEY BIG	TATA spare parts
405376605902	PVC KEY SMALL	TATA spare parts
405376607701	PVC PACKING FOR BRASS LATCHES	TATA spare parts
405376607702	PACKING FOR HATRACK (BOTTOM)	TATA spare parts
405376607703	PVC PACKING 3INCH FOR GRAB RAIL SOCKET	TATA spare parts
405376607704	PVC PACKING FOR ALU 2676 BEADING	TATA spare parts
405376607705	PVC INSERT BLACK	TATA spare parts
405376607706	PVC INSERT APPLE WHITE	TATA spare parts
405376607707	PVC SECTION FOR WINDOW	TATA spare parts
405376607708	PVC T SECTION FOR WINDOW	TATA spare parts
405376608501	PVC PACKING FLAT FOR 1INCH BASE SOCKET	TATA spare parts
405376609901	FRP WEATHER SHADE (BIG)	TATA spare parts
405376609902	TERLYEN FELT	TATA spare parts
405376609903	DOVE TAIL MALE	TATA spare parts
405376609904	DOVE TAIL FEMALE	TATA spare parts
405376609905	DOOR CATCHER	TATA spare parts
405376800101	WINDOW LOCK : MAIN	TATA spare parts
405381000103	DOOR CLOSER CYLINDER 12V	TATA spare parts
405381000104	DOOR CLOSER VALVE 12V	TATA spare parts
405381000105	NIPPLE	TATA spare parts
405381000107	DOOR CLOSER CYLINDER 24V	TATA spare parts
405381000108	DOOR CLOSER VALVE 24V	TATA spare parts
405381000109	HOOK COMPLETE	TATA spare parts
405381009901	TROLLY WHEEL FOR BATT BOX	TATA spare parts
405381100104	SUNVISOR	TATA spare parts
405381100105	RVM MIRROR_HCBS	TATA spare parts
405381100106	UNDERVIEW MIRROR_HCBS	TATA spare parts
405381100107	REAR VIEW MIRROR	TATA spare parts
405381100108	MIRROR BRACKET	TATA spare parts
405381100109	MIRROR CLAMP	TATA spare parts
405381100110	INSIDE MIRROR	TATA spare parts
405381100111	ROUND MIRROR	TATA spare parts
405381100112	SUN VISOR 36INCH	TATA spare parts
405381100113	RUBBER BUFFER 1INCH	TATA spare parts
405381100114	RUBBER GROMMET 3INCH FOR BATTERY BOX	TATA spare parts
405381100115	MUD FLAP	TATA spare parts
405381100116	RUBBER PACKING TAPER FOR 1 3/8INCH BASE	TATA spare parts

405381100117	RUBBER PACKING FLAT FOR 1 3/8INCH BASE	TATA spare parts
405381100118	J/K DOOR SIDE RUBBER BIG	TATA spare parts
405381100119	J/K DOOR SIDE RUBBER SMALL	TATA spare parts
405381100120	J/K DOOR SWEEP RUBBER	TATA spare parts
405381100121	RUBBER CUSHION - MALE FOR J/K DOOR	TATA spare parts
405381100122	RUBBER CUSHION FEMALE - FOR J/K DOOR	TATA spare parts
405381100123	RUBBER FOR RUB RAIL BEADING	TATA spare parts
405381100124	RUBBER FOR WIRING CHANNEL	TATA spare parts
405381100125	RUBBER GLAZING FOR J/K DOOR	TATA spare parts
405381100126	RUBBER FOR DESTI	TATA spare parts
405381100127	RUBBER FOR WINDOW .	TATA spare parts
405381100128	U CHANNEL RUBBER FOR WINDOW SLIDING	TATA spare parts
405381100129	RUBBER FRAME FOR DRIVER & EMERDOOR	TATA spare parts
405381100130	RUBBER BUFFER 3/4INCH	TATA spare parts
405381100131	SUNVISOR	TATA spare parts
405381100132	SUNVISOR CLIP	TATA spare parts
405381100133	SUNVISOR ROLLER TYPE (36 INCH)	TATA spare parts
405381100134	SALOON MIRROR ARM	TATA spare parts
405381100135	RVM CVM RH	TATA spare parts
405381100136	RVM CVM LH	TATA spare parts
405381100137	ARM FOR UNDERVIEW MIRROR	TATA spare parts
405381100138	MIRROR BRACKET	TATA spare parts
405381100139	REAR VIEW MIRROR ARM LH	TATA spare parts
405381100140	RVM ARM ASSY(613-LHD-CO DRV SD)	TATA spare parts
405381100141	REAR VIEW MIRROR ARM RH	TATA spare parts
405381100146	EXTERNAL REAR VIEW MIRROR	TATA spare parts
405381102301	RVMIRROR ROUND 5 1/2INCH DIA	TATA spare parts
405381103301	RVM ARMS LH HCBS BEST	TATA spare parts
405381103302	RVM ARMS RH HCBS BEST	TATA spare parts
405381103303	REAR VIEW MIRROR BKT 15INCH	TATA spare parts
405381106301	MOULDING END FOR OPTYP OUTER(RH)	TATA spare parts
405381109901	SUN VISOR 36'	TATA spare parts
405381200101	CURTAIN RAIL SOCKET	TATA spare parts
405381200102	FAST TRACK CURTAIN HOOK	TATA spare parts
405381200103	HOOK FOR CURTAIN (RING TYPE)	TATA spare parts
405381200104	REARCENTREFIXED	TATA spare parts
405381202901	ROUND HINGES LH	TATA spare parts
405381202902	ROUND HINGES RH	TATA spare parts
405381202903	FORGED HINGES LH	TATA spare parts
405381202904	ALUMINIUM HINGES FOR DESTINATION PNEUMA	TATA spare parts
405381202905	HINGE (PASSENGER DOOR)	TATA spare parts
405381300101	HANDLE PAD	TATA spare parts
405381300102	BRACKET COMPLETE	TATA spare parts
405381305001	SIDE INNER/OUTER EXTRUSION	TATA spare parts
405381305201	PVC EXTRUSION(BLACK-WAIST RAIL	TATA spare parts
405381500108	HAND STRAP	TATA spare parts
405381500109	NON RETURN VALVE	TATA spare parts

405381506904	GRAB RAIL PIPE	TATA spare parts
405381506905	HATRACK PIPE	TATA spare parts
405381506906	WINDOW GUARD RAIL	TATA spare parts
405381506907	PU TUBE	TATA spare parts
405381506908	PNEUMATIC PVC TEE	TATA spare parts
405381506909	PVC ELBOW	TATA spare parts
405381506910	BRASS TEE	TATA spare parts
405381508501	GRAB RAIL SOCKET	TATA spare parts
405381508502	WINDOW GUARD RAIL SOCKET	TATA spare parts
405381700101	DESTINATION INDICATOR_HCBS	TATA spare parts
405381700102	DESTINATION INDICATOR HCBS BEST	TATA spare parts
405381700103	FR WHEEL HUB COVER HCBS BEST	TATA spare parts
405381700104	RR WHEEL HUB COVER HCBS BEST	TATA spare parts
405381700105	MUD FLAP (EXPORT)(620X400)	TATA spare parts
405381700107	DESTINATION INDICATOR BRACKET	TATA spare parts
405381707701	RUBBER MATING BLACK	TATA spare parts
405381707702	MUD FLAP	TATA spare parts
405381707703	J/K DOOR SIDE RUBBER BIG	TATA spare parts
405381707704	J/K DOOR SIDE RUBBER SMALL	TATA spare parts
405381707705	J/K DOOR SWEEP RUBBER	TATA spare parts
405381707706	RUBBER CUSHION MALE FOR J/K DOOR	TATA spare parts
405381707707	RUBBER CUSHION FEMALE FOR J/K DOOR	TATA spare parts
405381707708	RUBBER FOR RUB RAIL BEADING	TATA spare parts
405381707709	RUBBER GLAZING FOR FRONT WINDSCREEN	TATA spare parts
405381707710	RUBBER GLAZING FOR J/K DOOR GLASS	TATA spare parts
405381707711	RUBBER FOR DESTINATION WINDOW & REAR WINDOW	TATA spare parts
405381709901	J/K DOOR BOTTOM BUSH(MALE)	TATA spare parts
405381838001	ROTARY AIR VENTOLATOR	TATA spare parts
405381900106	REAR DICKEY LOCK_HCBS	TATA spare parts
405381900108	REAR DICKEY LOCK HCBS BEST	TATA spare parts
405381900109	STOPPER ENTRANCE DOOR	TATA spare parts
405381900110	STOPPER ENTRANCE DOOR	TATA spare parts
405381900111	STOPPER ENTRANCE DOOR HINGE	TATA spare parts
405381900112	SIDE WINDOW LOCK	TATA spare parts
405381900113	LATCH ASSY (TOWER BOLT)	TATA spare parts
405381900114	PASSENGER DOOR LOCK	TATA spare parts
405381900115	LOCK COMPLETE	TATA spare parts
405381900116	HAND STRAP	TATA spare parts
405381900117	609 HANDLE	TATA spare parts
405381900118	FRONT WHEEL HUB COVER	TATA spare parts
405381900119	REAR WHEEL HUB COVER	TATA spare parts
405381900120	CENTRE BOLT FOR HUB COVER	TATA spare parts
405381900121	GAS STAY	TATA spare parts
405381900122	HALF PARTITION GLASS	TATA spare parts
405381900123	TOWING HOOK PIN	TATA spare parts
405381900124	PASSENGER DOOR BUSHING	TATA spare parts
405381900125	HALF PARTITION GLASS ASSY	TATA spare parts

405381900126	FIRE EXTINGUISHER (10 KG)	TATA spare parts
405381900127	SUNVISOR ASSEMBLY	TATA spare parts
405381900128	UNDER VIEW MIRROR	TATA spare parts
405381900129	REFLECTOR	TATA spare parts
405381900130	REFLECTOR	TATA spare parts
405381900131	HANDLE - FRONT/REAR	TATA spare parts
405381900132	DRIVER'S SEAT BELT	TATA spare parts
405381900133	ENGINE HOOD CLAMP	TATA spare parts
405381900134	KNOB FOR HUB COVER	TATA spare parts
405381900135	FRP DASH BOARD COMPL	TATA spare parts
405381900136	WIPER SYSTEM	TATA spare parts
405381900137	SPRING LOCK	TATA spare parts
405381900138	SIDE WINDOW LOCK	TATA spare parts
405381900139	LATCH ASSEMBLY(TOWER BOLT)	TATA spare parts
405381900140	REAR EMERGENCY DOOR HANDLE	TATA spare parts
405381900141	FIRST AID BOX	TATA spare parts
405381900142	HALF PARTITION GLASS ASSY	TATA spare parts
405381900143	FIRE EXTINGUSHIOR	TATA spare parts
405381900144	1/2INCH X3INCH TOWER BOLT	TATA spare parts
405381900145	TOWER BOLT 15INCH	TATA spare parts
405381900146	BRASS VENTILATOR LATCHES	TATA spare parts
405381900147	DIESEL TANK COVER	TATA spare parts
405381900148	TOOL BOX	TATA spare parts
405381900149	HANDLE FOR INSPECTION LID	TATA spare parts
405381900150	ARM (ROOM MIRROR)	TATA spare parts
405381900151	SALOON MIRROR	TATA spare parts
405381900152	GLASS BREAKING HAMMER	TATA spare parts
405381900153	FRP FOOT STEP	TATA spare parts
405381900154	SIKKA PRIMER 206(G+P)	TATA spare parts
405381900155	SIKAFLEX BLACK 255	TATA spare parts
405381900156	DRIVER PARTITION WINDOW	TATA spare parts
405381900157	KNOB FOR FUSE BOX FLAP	TATA spare parts
405381902301	PARTITION GLASS	TATA spare parts
405381902302	DESTINATION GLASS (CLEAR-5MM)	TATA spare parts
405381902901	ROUND HINGES	TATA spare parts
405381902902	FORGED HINGES	TATA spare parts
405381902903	3INCH HINGES	TATA spare parts
405381902904	ALUPIANO HINGES FOR DESTI	TATA spare parts
405381902905	1 1/2INCH HINGES	TATA spare parts
405381902906	6INCH HINGES	TATA spare parts
405381903301	GUARD RAIL BRACKET 19 DIA	TATA spare parts
405381903302	NYLON GUARD RAIL BRACKET 19 DIA	TATA spare parts
405381903303	GUAR RAIL BRACKET 25 DIA	TATA spare parts
405381903304	45DEG PIPE BRACKET 38 DIA	TATA spare parts
405381903305	BRACKET CASTING	TATA spare parts
405381903306	VENTILATOR BRACKET	TATA spare parts
405381903307	STOPPER WINDOW	TATA spare parts

405381903308	RING 38 DIA	TATA spare parts
405381903309	GRAB PIPE END BRACKET 25 DIA	TATA spare parts
405381903310	GRAB PIPE HANDLE/BRACKET 25 DIA	TATA spare parts
405381903311	PIPE BRACKET 38 BASE	TATA spare parts
405381903312	PIPE BRACKET 32 BASE	TATA spare parts
405381903313	PIPE JOINT/T (38X32)	TATA spare parts
405381903314	PIPE JOINT/T (32X32)	TATA spare parts
405381903315	PIPE JOINT/T (32X25)	TATA spare parts
405381903316	PIPE JOINT/T (25X25)	TATA spare parts
405381903317	FOOT STEP CASTING	TATA spare parts
405381903318	GRAB RAIL BRACKET (25 DIA)	TATA spare parts
405381903319	PIPE BRKT (38 DIA)	TATA spare parts
405381903320	PIPE BRKT (32 DIA)	TATA spare parts
405381903321	DRIVER DOOR CHECK BELT BRACKET	TATA spare parts
405381903322	DUBAI TYPE MIRROR BRACKET RH SIDE	TATA spare parts
405381905001	CANTT RAIL EXTRUSION 4 MTRS	TATA spare parts
405381905002	NON SKID EXTRUSION 4 MTRS	TATA spare parts
405381905003	VINYLE FLOOR EXTRUSION (LENGTH 4000MM)	TATA spare parts
405381905004	ROOF INNER EXTRUSION 2.3 METERS	TATA spare parts
405381905005	SIDE OUTER EXTRUSION 4 MTRS	TATA spare parts
405381905006	SKIRT RAIL EXTRUSION (LENGTH 4000MM)	TATA spare parts
405381905007	STEP FLOOR EXTRUSION 4 MTRS	TATA spare parts
405381905008	OUTER EXTRUSION 4 MTRS	TATA spare parts
405381905009	WEAR STRIP EXTRUSION (LENGTH 4000MM)	TATA spare parts
405381905010	SIDE OUTER EXTRUSION CTB 4 MTRS	TATA spare parts
405381905011	H SECTION (LENGTH 4000MM)	TATA spare parts
405381905012	AL EXTRUSION ROOF HATCH/INNER (3750MM)	TATA spare parts
405381905013	AL EXTRUSION ROOF HATCH (LENGTH 3750MM)	TATA spare parts
405381905014	SIDE OUTER EXTRUSION 4 MTRS	TATA spare parts
405381905015	SIDE INNER EXTRUSION 4 MTRS	TATA spare parts
405381905016	EXTRUTION - (LENGTH 4000MM)	TATA spare parts
405381905017	SIDE REAR EXTRUSION	TATA spare parts
405381905020	AL-EXTRUSION (OATYPE-OUTER LENGTH 3.5	TATA spare parts
405381905021	AL-EXTR(BOT FIX/INNER WAIST)(PC)	TATA spare parts
405381905022	AL-EXTRUSION (OUTER)(PCOAT)	TATA spare parts
405381905023	AL.EXTRUSION(ANNODISED/OP TYPE)	TATA spare parts
405381905201	PVC EXTRUSION (BLACK WAIST RAIL)	TATA spare parts
405381905601	BRASS HANDLE NEAR DRIVER DOOR	TATA spare parts
405381905602	OUTSIDE HANDLE WITH KEY	TATA spare parts
405381905603	INSIDE HANDLE WITH KEY	TATA spare parts
405381905604	BRASS HANDLE 11INCH	TATA spare parts
405381905605	OUTSIDE HANDLE WITH KEY (RH)	TATA spare parts
405381905606	INSIDE HANDLE	TATA spare parts
405381905607	3INCH BRASS HANDLE	TATA spare parts
405381905608	MS FLOOR HANDLE	TATA spare parts
405381905609	ALUMINIUM HANDLE FOR J/K DOOR	TATA spare parts
405381906101	BUDGET LOCK	TATA spare parts

405381906102	BUDGET LOCK KEY	TATA spare parts
405381906103	BUDGET LOCK COVER	TATA spare parts
405381906304	MUD FLAP	TATA spare parts
405381906305	MOULDING END CAP LH	TATA spare parts
405381906306	MOULDING END CAP RH	TATA spare parts
405381906901	GROOVED PIPE 4 MTRS	TATA spare parts
405381907101	TATA NAME PLATE	TATA spare parts
405381907701	GE STRIP (LENGTH 10 MTR)	TATA spare parts
405381907702	WEDGE STRIP (LENGTH 10 MTR)	TATA spare parts
405381907703	WEATHER STRIP (LENGTH 5 MTR.)	TATA spare parts
405381907704	WEATHER STRIP (LENGTH 10 MTR)	TATA spare parts
405381907705	WEATHER STRIP ENTRANCE DOOR	TATA spare parts
405381907706	WEATHER STRIP ENTRANCE DOOR	TATA spare parts
405381907707	VINYLE TUBE	TATA spare parts
405381907708	TRIP STRIP REAR	TATA spare parts
405381907709	FRINGE WHITE	TATA spare parts
405381907710	FRINGE GREY	TATA spare parts
405381907711	FRINGE	TATA spare parts
405381907712	T BEADING FOR WINDSHIELD 10 MTRS	TATA spare parts
405381907713	CUSHION (LENGTH 10 MTR)	TATA spare parts
405381907714	TRIM STRIP WHITE	TATA spare parts
405381907715	TRIM STRIP GREY	TATA spare parts
405381907716	PVC FRINGE	TATA spare parts
405381907717	DUST SEAL SINGLE FLANGE	TATA spare parts
405381907718	DUST SEAL	TATA spare parts
405381907719	DUST SEAL	TATA spare parts
405381907720	DUST SEAL	TATA spare parts
405381907721	FRONT WINDSHIELD BEADING 6HD	TATA spare parts
405381907722	WEATHER STRIP	TATA spare parts
405381907723	REAR WINDSHIELD BEADING	TATA spare parts
405381907724	TAIL LAMP BEADING	TATA spare parts
405381907725	RUBBER PROFILE	TATA spare parts
405381907726	STOPPER FLAP	TATA spare parts
405381907727	WHEEL ARCH BEADING (LENGTH 2.3 MTR)	TATA spare parts
405381907728	MOULDING END	TATA spare parts
405381907729	MOULDING END RH	TATA spare parts
405381907730	MOULDING END LH	TATA spare parts
405381907731	PIPE END	TATA spare parts
405381907732	SLEEVE	TATA spare parts
405381907733	KNOB	TATA spare parts
405381907734	MOULDING END	TATA spare parts
405381907735	ACRYLIC PALTE FOR EMERGENCY DOOR	TATA spare parts
405381907736	ACRYLIC FOR DEST FLAP	TATA spare parts
405381907737	END MOULDING OUTER LH	TATA spare parts
405381907738	END MOULDING OUTER RH	TATA spare parts
405381907739	BUSH	TATA spare parts
405381907740	VINYL TUBE	TATA spare parts

405381907741	WEATHER STRIP	TATA spare parts
405381907742	WEATHER STRIP	TATA spare parts
405381907743	ABS VENTILATOR FOR DRIVER	TATA spare parts
405381907744	DOVE TAIL MALE	TATA spare parts
405381907745	DOVE TAIL FEMALE	TATA spare parts
405381907746	DOOR CATCHER	TATA spare parts
405381907747	PVC ARM REST 1INCH	TATA spare parts
405381907748	PVC DOOR STRAP 8 INCH	TATA spare parts
405381907749	GOLDSEAL BEADING	TATA spare parts
405381907750	HAND STRAP	TATA spare parts
405381907751	FRP HUBCAP FOR FRONT WHEEL	TATA spare parts
405381907752	FRP HUBCAP FOR REAR WHEEL	TATA spare parts
405381907753	FRP WEATHER SHADE FOR FRONT DOOR	TATA spare parts
405381907754	FRP WEATHER SHADE FOR REAR DOOR	TATA spare parts
405381907755	DUST SEAL(SPONGE-DRIVER VENT)	TATA spare parts
405381908201	STRIKER PLATE	TATA spare parts
405381908202	CASHBOX FOR CONDUTOR	TATA spare parts
405381908501	1INCH BASE SOCKET W/OUT SLOT	TATA spare parts
405381908502	1INCH ALU BEND SOCKET FOR ASSIST HANDLE	TATA spare parts
405381908503	1 3/8INCH BASE SOCKET	TATA spare parts
405381908504	AL ANOD T SOCKET1INCH *1INCH	TATA spare parts
405381908505	1INCH BASE SOCKET	TATA spare parts
405381908506	1INCH TO 1 3/8INCH 'T' SOCKET	TATA spare parts
405381909901	EMERGENCY DOOR & CONDCABIN DOOR TOWER	TATA spare parts
405381909902	TOWER BOLT FOR J/K DOOR	TATA spare parts
405381909903	FRP TAPE RECORDER BOX	TATA spare parts
405381909904	FRP MAGAZINE TRAY WITH WATER BOTTEL HOOK	TATA spare parts
405381909905	FRP DASH BOARD SWITCH STAND	TATA spare parts
405381909906	HANDSTRAP	TATA spare parts
405382109901	MAIN WIRING HARNESS	TATA spare parts
405382109902	COUPLER HARNESS	TATA spare parts
405382200101	RVM OUTER	TATA spare parts
405382300101	CHAIN (BATTERY BOX)	TATA spare parts
405382400106	WIPER ARM ASSEMBLY RH- RHD/LHD	TATA spare parts
405382400107	WIPER ARM ASSEMBLY LH- RHD/LHD	TATA spare parts
405382400108	WIPER BLADE ASSEMBLY LH/RH- RHD/LHD	TATA spare parts
405382400109	CAP WIPER ARM HEAD LH/RH- RHD/LHD	TATA spare parts
405382400110	WIPER LINKAGE ASSY RHD/ LHD	TATA spare parts
405382400111	WIPER MOTOR ASSY	TATA spare parts
405382400112	WASHER ASSY WITH RESERVOIR	TATA spare parts
405382400113	WHEEL BOX (50.8)TELCO STD ITM.	TATA spare parts
405382400114	SINGLE SPINDLE(CD=50.8)+BUSH28	TATA spare parts
405382400115	WIPER ARM (370X210 LHD)	TATA spare parts
405382400116	WIPER ARM (370X295 LHD)	TATA spare parts
405382400117	WIPER BLADE W/SPRAY KIT(28 ) BS2	TATA spare parts
405382400118	WIPER BLADE (L=711)	TATA spare parts
405382400119	WIPER WHEEL BOX LH	TATA spare parts



405382400120	WIPER WHEEL BOX RH	TATA spare parts
405388006302	REAR BUMPER ASSEMBLY	TATA spare parts
405388100101	FRONT BUMPER	TATA spare parts
405388200101	REAR BUMPER	TATA spare parts
405388203301	REAR BUMPER BRACKET	TATA spare parts
405388403301	SIDE PIECE JOINT BRACKET	TATA spare parts
405388403302	CENTRE PIECE JOINT BRACKET	TATA spare parts
405388403303	FRONT BUMPER ALUMINIUM BRACKET	TATA spare parts
405388403304	REAR BUMPER JOINT BRACKET	TATA spare parts
405388403305	REAR BUMPER WEARING STRIP	TATA spare parts
405388403306	PVC PACKING FOR REAR BUMPER	TATA spare parts
405388407701	PVC PACKING FOR REAR BUMPER	TATA spare parts
405388500102	FRONT BUMPER_HCBS	TATA spare parts
405388500106	FRONT BUMPER_HCBS_BEST	TATA spare parts
405388500107	FRONT BUMPER	TATA spare parts
405388500108	CENTRE PIECE FOR FRONT BUMPER	TATA spare parts
405388500109	LH SIDE PIECE FOR FRONT BUMPER	TATA spare parts
405388500110	RH SIDE PIECE FOR FRONT BUMPER	TATA spare parts
405388500111	FRONT BUMPER LPO1610RESLF STARBUS	TATA spare parts
405388500112	FRT. FRP STRUCTURE LPO1610RESLF STARBUS	TATA spare parts
405388506302	FRONT FRP BUMPER CENTRE PIECE	TATA spare parts
405388506303	FRONT FRP BUMPER END (LH)(LP)	TATA spare parts
405388506304	FRONT FRP BUMPER END (RH)(LP)	TATA spare parts
405388506305	FRP FRT.BUMP.END.BLADE-LPO(LH)	TATA spare parts
405388506306	FRP FRT BUMP END BLADE-LPO(RH)	TATA spare parts
405388506307	FRP FRONT BUMPER	TATA spare parts
405388506308	GARNISH LH	TATA spare parts
405388506309	GARNISH RH	TATA spare parts
405388506310	GARNISH CENTRE	TATA spare parts
405388508201	FRONT GRILL	TATA spare parts
405388508202	FRONT FLAP SMALL	TATA spare parts
405388509901	FRONT BUMPER	TATA spare parts
405388509902	FRONT BUMPER	TATA spare parts
405388600103	REAR BUMPER_HCBS	TATA spare parts
405388600107	REAR BUMPER LH _STARBUS 32 STD	TATA spare parts
405388600108	REAR BUMPER RH _STARBUS 32 STD	TATA spare parts
405388600109	REAR BUMPER HCBS BEST	TATA spare parts
405388600110	REAR FRP BUMPER END(LH)	TATA spare parts
405388600111	REAR FRP BUMPER END(RH)	TATA spare parts
405388600112	REAR FRP BUMPER CENTRE PIECE	TATA spare parts
405388600113	REAR FRP BUMPER END(LH)	TATA spare parts
405388600114	REAR FRP BUMPER END(RH)	TATA spare parts
405388600115	REAR FRP BUMPER CENTRE PIECE	TATA spare parts
405388600116	REAR BUMPER	TATA spare parts
405388600117	CENTRE PIECE FOR REAR BUMPER	TATA spare parts
405388600118	LH SIDE PIECE FOR FRONT BUMPER	TATA spare parts
405388600119	RH SIDE PIECE FOR FRONT BUMPER	TATA spare parts

405388600120	FRP REAR STRUCTURE	TATA spare parts
405388600121	FRP REAR BUMPER COMPLETE	TATA spare parts
405388606301	FULL BUMPER ASSEMBLY (REAR)	TATA spare parts
405388700101	ENGINE HOOD ASSY	TATA spare parts
405391409901	SEAT FABRIC MAURITIUS BUS	TATA spare parts
405391503301	DR'S DOOR CHECK BELT BRACKET	TATA spare parts
405392000103	SIX SEATER SEAT	TATA spare parts
405392000104	SIX SEATER SEAT	TATA spare parts
405392106901	SIX SEATER SEAT FRAME	TATA spare parts
405392209901	SIX SEATER SEAT CUSHION	TATA spare parts
405392309901	SIX SEATER SEAT BACK	TATA spare parts
405393000101	TWO SEATER SEAT RH	TATA spare parts
405393000102	TWO SEATER SEAT LH	TATA spare parts
405393000103	TWO SEATER SEAT (CABIN SEAT)	TATA spare parts
405393000104	TWO SEATER SEAT RH (WITH ARM REST)	TATA spare parts
405393000105	TWO SEATER SEAT LH (WITH ARM REST)	TATA spare parts
405394000103	CONDUCTOR SEAT	TATA spare parts
405394106901	CONDUCTOR SEAT FRAME	TATA spare parts
405394106902	CONDUCTOR SEAT LEG RH	TATA spare parts
405394106903	CONDUCTOR SEAT LEG LH	TATA spare parts
405394209901	CONDUCTOR SEAT CUSHION	TATA spare parts
405394309901	CONDUCTOR SEAT BACK	TATA spare parts
405395000104	TWO SEATER SEAT RH	TATA spare parts
405395000105	TWO SEATER SEAT LH	TATA spare parts
405395000106	TWO SEATER SEAT RH WITH ARM REST	TATA spare parts
405395000107	TWO SEATER SEAT LH WITH ARM REST	TATA spare parts
405395106901	TWO SEATER SEAT FRAME RH	TATA spare parts
405395106902	TWO SEATER SEAT FRAME LH	TATA spare parts
405395106903	TWO SEATER SEAT FRAME RH WITH ARM REST	TATA spare parts
405395106904	TWO SEATER SEAT FRAME LH WITH ARM REST	TATA spare parts
405395106905	SEAT LEG RH	TATA spare parts
405395106906	SEAT LEG LH	TATA spare parts
405395109901	SEAT RAIL GUSSET RH	TATA spare parts
405395109902	SEAT RAIL GUSSET LH	TATA spare parts
405395209901	TWO SEATER SEAT CUSHION	TATA spare parts
405395309901	TWO SEATER SEAT BACK	TATA spare parts
405397003401	SEAT TOP BUSH	TATA spare parts
405397003403	1INCH PVC BUSH FOR GRAB RAIL & SEAT	TATA spare parts
405397107701	PVC ARM REST 1INCH	TATA spare parts
405397107702	T PVC FOR SEAT RAIL & FRONT W/RAIL	TATA spare parts
405397109901	MS ARM REST	TATA spare parts
405398404201	TOMY CLAMP	TATA spare parts
405398409901	ANTI RATTILING DISC	TATA spare parts
405398500101	TOOL BOX	TATA spare parts
405454000101	BLINKER LAMP ASSY RH	TATA spare parts
405454000102	FOG LAMP ASSY	TATA spare parts
405454000103	BLINKER LAMP ASSY LH	TATA spare parts

405454000104	SIDE MARKER ASSY	TATA spare parts
405454000105	TAIL LAMP ASSY LH	TATA spare parts
405454000106	TAIL LAMP ASSY RH	TATA spare parts
405454204901	STOP SWITCH (PANEL MOUNTING)	TATA spare parts
405454204902	SWITCHES PIANO TYPE	TATA spare parts
405454204903	REVERSE HORN (24 V)	TATA spare parts
405454204904	SPRING LOADED P-SW (2P ON OFF)	TATA spare parts
405454204906	SPEED CONTROL VALVE	TATA spare parts
405454304901	BUZZER	TATA spare parts
405454304902	INTERMITTENT BUZZER	TATA spare parts
405454304903	PASSENGER BELL (24 V)	TATA spare parts
405454404901	HEADLAMP SET RH	TATA spare parts
405454404902	HEADLAMP SET LH	TATA spare parts
405454404903	HEIGHT MARKER LAMP (WHITE)	TATA spare parts
405454404904	REAR FOG LAMP 24 V	TATA spare parts
405454404905	HEIGHT MARKER LAMP (RED)	TATA spare parts
405454404906	NUMBER PLATE LAMP	TATA spare parts
405454404907	STEP LAMP	TATA spare parts
405454404908	FLOU. LAMP (24 V)	TATA spare parts
405454704901	PASSENGER FAN (24 VOLTS)	TATA spare parts
405455107701	LETTER TATA	TATA spare parts
405455107703	STARBUS MASCOT	TATA spare parts
405462000101	FRP FRT. STR. UPPER	TATA spare parts
405462000102	FRONT WINDSHIELD LAMINATED	TATA spare parts
405463205001	RVM ARM (DRIVER SIDE)	TATA spare parts
405463606301	WHEEL ARCH BEADING	TATA spare parts
405463606302	WHEEL SIDE COVER / R	TATA spare parts
405463606303	WHEEL SIDE COVER	TATA spare parts
405463606304	WHEEL SIDE COVER / R	TATA spare parts
405463706801	GUARD RAIL PIPE(25.4DIA) (LENGTH 4000MM)	TATA spare parts
405463708202	SKIRT PANEL COMPLETE / B.B	TATA spare parts
405463708203	WHEEL SIDE COVER	TATA spare parts
405463708204	DRIVER FOOT STEP PANEL	TATA spare parts
405463708205	SKIRT PANEL COMPLETE / F.T.	TATA spare parts
405463708206	SKIRT PANEL COMPLETE	TATA spare parts
405463708207	SKIRT PANEL COMPLETE	TATA spare parts
405463708208	SKIRT PANEL COMPLETE	TATA spare parts
405464000001	FRP REAR STR. COMP. (916)	TATA spare parts
405467002301	PARTITION GLASS ASSY.	TATA spare parts
405467002302	ARM (ROOM MIRROR)	TATA spare parts
405467007703	WEAT. STRIP (P/D BIG BULB)	TATA spare parts
405467007704	WEAT. STRIP (P. D. GLASS)	TATA spare parts
405467007705	WEAT. STRIP (P/D KEY)	TATA spare parts
405467007706	WEAT. STRIP (P/D EMG. DR) LENGTH 10 MTR.	TATA spare parts
405467102301	PEEP GLASS	TATA spare parts
405467300101	LATCH WINDOW WITH STRIKER	TATA spare parts
405467300102	SIDE WINDOW ASSY	TATA spare parts

405467300103	SIDE WINDOW ASSY	TATA spare parts
405467300104	SIDE WINDOW ASSY	TATA spare parts
405467300105	SIDE WINDOW ASSY	TATA spare parts
405467300106	SIDE WINDOW ASSY ( DRV )	TATA spare parts
405467300107	SIDE WINDOW (CO DRV )	TATA spare parts
405467300108	SIDE WINDOW (ASSY EMG DOOR )	TATA spare parts
405467300109	SIDE WINDOW ASSY ( FIXED )	TATA spare parts
405467302318	GLASS FOR MASAT DOOR (FRONT)	TATA spare parts
405467302319	PASS DOOR APERTURE GLASS	TATA spare parts
405469107701	T-BEADING (LENGTH 10 MTR.)	TATA spare parts
405469407701	AL-EXRUSION REAR (PC) (LENGTH 4000MM)	TATA spare parts
405472302801	BUDGET LOCK	TATA spare parts
405472302802	BUDGET KEY	TATA spare parts
405472305001	STOPPER (LATCH)	TATA spare parts
405472305002	STOPPER/LOCK	TATA spare parts
405472306901	PNEUMATIC CONNECTOR(6X8 TUBING)	TATA spare parts
405472306902	6MM TUBE FOR PNEU. DOOR (LENGTH 10 MTR)	TATA spare parts
405472309901	3-WAY COCK D/E	TATA spare parts
405474000101	DOOR ASSY. S.T.	TATA spare parts
405474000102	DOOR ASSY.C.U.	TATA spare parts
405474309901	MAGNETIC CATCHER FOR EMG. COVER	TATA spare parts
405475100101	FRONT FLAP	TATA spare parts
405481000001	FIRE EXTINGUISHER A/B/C-2 KGS	TATA spare parts
405481000002	FIRE EXTINGUISHER A/B/C-5 KGS	TATA spare parts
405481100101	SUNVISOR ROLLER TYPE (24)	TATA spare parts
405481106901	NYLON GUARD RAIL BRACKET 25 DIA	TATA spare parts
405481507701	BLACK PVC EXTR. REAR	TATA spare parts
405481507702	DUST SEAL SPONGE	TATA spare parts
405488000101	FRT. BUMP. ASSY WITH GRILL	TATA spare parts
405488000102	REAR BUMPER ASSY (916)	TATA spare parts
405554300101	BUZZER 12V 709 DELUXE	TATA spare parts
405554300102	HORN REVERSE 24V	TATA spare parts
405554300103	HEAD LAMP LEVELLING S/W	TATA spare parts
405554300104	DOOR ADOPTER	TATA spare parts
405554400101	SIDE INDICATOR 709 DELUXE	TATA spare parts
405554400104	LIGHT FOG 12V DIA 65MM	TATA spare parts
405554400105	COMPLETE STUDY LIGHT	TATA spare parts
405554400106	FAN CABIN 12V 8 INCH-BLUE	TATA spare parts
405554400107	BULB CNG _ 709 DELUXE	TATA spare parts
405554400108	FOOT STEP LIGHT _ 709 DELUXE	TATA spare parts
405554400109	LIGHT 12V _ 709 DELUXE	TATA spare parts
405554400110	FR INDICATOR - 12V 709 DELUXE	TATA spare parts
405554400111	LIGHT HEAD COMP. _709 DELUXE	TATA spare parts
405554400112	CAR DEC LIGHT _ 709 DELUXE	TATA spare parts
405554400113	BLINKER LH_1616	TATA spare parts
405554400114	BLINKER RH_1616	TATA spare parts
405554400115	FOG LAMP LH/RH_1616	TATA spare parts

405554400116	REAR NUMBER PLATE LAMP _LPO1616	TATA spare parts
405554400117	CURVED TAIL LAMP 6HD WHITE	TATA spare parts
405554400118	CURVED TAIL LAMP 6HD RED	TATA spare parts
405554400119	STEP LAMP SUNKEN TYPE	TATA spare parts
405554400120	SIDE INDICATOR - 24 V	TATA spare parts
405554400121	TOP INDICATOR NET PLAST CLEAR- 24 V	TATA spare parts
405554400122	TOP INDICATOR NET PLAST RED- 24 V	TATA spare parts
405554400123	LIGHT FOG 24 V- DIA 65 MM	TATA spare parts
405554400124	LIGHT PCA 916 (24 V)	TATA spare parts
405554400125	FRONT INDICATOR (24 V)	TATA spare parts
405554400126	LIGHT TAIL	TATA spare parts
405554400127	INDICATOR	TATA spare parts
405554400128	NUMBER PLATE LIGHT	TATA spare parts
405554400129	MOTORISED LAMP W/OUT MOTOR W/ PARKING	TATA spare parts
405554400130	MOTORISED LAMP W/OUT MOTOR W/ PARKING	TATA spare parts
405554400131	AIR-HORN (24 V)	TATA spare parts
405554400132	PIANO SWITCH	TATA spare parts
405554400134	ON-OFF TOGGLE SWITCH	TATA spare parts
405554500101	PIANO SWITCH 709 DELUXE	TATA spare parts
405554500102	SWITCH STOP PANEL _ 709 DELUXE	TATA spare parts
405554500103	TERMINAL BATTERY +VE	TATA spare parts
405554500104	SWITCH BATTERY CUT OFF 24 V	TATA spare parts
405554500105	PUSH TYPE SWITH RED	TATA spare parts
405554500106	PUSH TYPE SWITCH GREEN	TATA spare parts
405554600101	BATTERY CABLE RED	TATA spare parts
405554600102	BATTERY LEG	TATA spare parts
405554600103	BATTERY TERMINAL -VE	TATA spare parts
405554700101	FAN CABIN 24 V 8 (BLUE)	TATA spare parts
405554800101	SPEAKER (OVEL SHAPE) _ 709 DELUX	TATA spare parts
405555107701	GLOBUS MASCOT MCV	TATA spare parts
405555107702	TATA MASCOT MCV	TATA spare parts
405555107703	GLOBUS MASCOT	TATA spare parts
405562006301	FRONT FRP COMPLETE	TATA spare parts
405562700101	FRONT BUMPER COMPL_TATA709 GLOBUS	TATA spare parts
405563707701	OUTER PANEL RUBBER BEEDING UPP_GLOBUS	TATA spare parts
405563707702	OUTER PANEL RUBBER BEEDING LOWER_GLOBUS	TATA spare parts
405564006301	EXTERNAL COMP. FOR TATA LUXURY REAR FRP	TATA spare parts
405567100101	GLASS FRONT_1616	TATA spare parts
405567102301	FRONT WIND SHEILD GLASS	TATA spare parts
405567102302	GLASS D. GRY. LH	TATA spare parts
405567102303	GLASS D. GRY. RH	TATA spare parts
405567102304	GLASS D. GRY LH	TATA spare parts
405567102305	GLASS 5 D. GRY RH	TATA spare parts
405567102306	GLASS D. GRY LH	TATA spare parts
405567102307	GLASS D. GRY RH	TATA spare parts
405567102308	GLASS D. GRY	TATA spare parts
405567102309	GLASS D GRY. FCP EM	TATA spare parts

405567102310	GLASS D. GRY- CP	TATA spare parts
405567102311	GLASS D. GRY	TATA spare parts
405567102312	GLASS D. GRY P/D	TATA spare parts
405567102313	WINDOW FRAME KIT	TATA spare parts
405567300001	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
405567300002	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
405567300003	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
405567300004	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
405567300005	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
405567300006	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
405567300007	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
405567300008	SD WINDOW ASSY(3PC/EMG/GREEN/PC)	TATA spare parts
405567302301	SMALL WINDOW FIX GLASS RH	TATA spare parts
405567302302	SMALL WINDOW FIX GLASS LH	TATA spare parts
405567302303	SMALL WINDOW RHS FIX GLASS RH	TATA spare parts
405567302304	COMMON WINDOW FIX GLASS LH	TATA spare parts
405567302305	COMMON WINDOW FIX GLASS RH	TATA spare parts
405567302306	PASS DOOR UPPER FIX GLASS LH	TATA spare parts
405567302307	REAR LAST WINDOW FIX GLASS LH	TATA spare parts
405567302308	REAR LAST WINDOW FIX GLASS RH	TATA spare parts
405567302309	GLASS-1 SIDE_1616	TATA spare parts
405567302310	GLASS-2 SIDE_1616	TATA spare parts
405567302311	GLASS-3 SIDE_1616	TATA spare parts
405567302312	GLASS TINTED (296X1930X4 THK)	TATA spare parts
405567302313	GLASS TINTED (265X2080X4 THK)	TATA spare parts
405567302314	GLASS TINTED (572X722X5 THK)	TATA spare parts
405567302315	GLASS TINTED (276X1930X4 THK)	TATA spare parts
405567802301	REAR EMERGENCY GLASS	TATA spare parts
405567807701	GLASS BEADING	TATA spare parts
405572300102	HANDLE-DRIVER DOOR GLOBUS45	TATA spare parts
405572300103	FLOW CONTROL VALVE	TATA spare parts
405572300104	PUSH LOCK	TATA spare parts
405572300105	PNEUMATIC CYLINDER 50 250	TATA spare parts
405572306901	PNEUMATIC PIPE DIA. 6 MM	TATA spare parts
405572307701	DOOR SEAL	TATA spare parts
405572307702	INNER SEALING DRIVER DOOR GLOBUS45	TATA spare parts
405572307703	OUTER SEAL DRIVER DOOR GLOBUS45 4.2 MTR	TATA spare parts
405572500101	DRIVER DOOR WINDOW ASSY_1616	TATA spare parts
405573000103	ENTRANCE DOOR ASSY	TATA spare parts
405573300101	PNEUMATIC DOOR ASSY(COMPLETE)MODEL - 12V	TATA spare parts
405573300102	PASSENGER DOOR MECHANISM_1616	TATA spare parts
405573307701	PASS DOOR	TATA spare parts
405573500101	SWING DOOR WINDOW_1616	TATA spare parts
405573502301	PASS DOOR FIX GLASS	TATA spare parts
405581000103	AC LOUVER FIX TYPE	TATA spare parts
405581000104	LOUVER (AC)	TATA spare parts
405581100101	SUNVISOR SHUTTER TYPE	TATA spare parts

405581100102	MIRROR	TATA spare parts
405581100103	OUTER RVM LH_1616	TATA spare parts
405581100104	OUTER RVM RH_1616	TATA spare parts
405581100105	INNER REAR VIEW MIRROR_1616	TATA spare parts
405581100106	MUDFLAP REAR NEW	TATA spare parts
405581100107	LOCK BATTERY	TATA spare parts
405581100108	RVM BRKT	TATA spare parts
405581202901	HINGE FOR SKIRT PANELS	TATA spare parts
405581202902	HINGE ASSY FOR REAR DICKY	TATA spare parts
405581202903	HINGE ASSY FOR REAR DICKY	TATA spare parts
405581300101	GEAR KNOB	TATA spare parts
405581500101	T SOCKET DIA 40-DIA 34 MM	TATA spare parts
405581500102	T SOCKET DIA 34- DIA 34 MM	TATA spare parts
405581500103	BASE SOCKET DIA 40	TATA spare parts
405581500104	BASE SOCKET DIA 34	TATA spare parts
405581500105	MODESTY PARTITION	TATA spare parts
405581500106	HANDLE GRAIB RAIL SAFARI	TATA spare parts
405581505001	INNER CHANNEL	TATA spare parts
405581505002	OUTER CHANNEL	TATA spare parts
405581506901	AL. PIPE OD 40X2MM (GREY POWDER COATED)	TATA spare parts
405581506902	AL. PIPE OD 32X2MM (GREY POWDER COATED)	TATA spare parts
405581706301	LOGO T AMBLEM	TATA spare parts
405581706302	WHEEL COVER (2 FRONT+2 REAR)	TATA spare parts
405581900101	GAS SPRING	TATA spare parts
405581900102	DRIVER PARTITION FIX_1616	TATA spare parts
405581900103	PARTITION DOOR_1616	TATA spare parts
405581900104	PARTITION DOOR_1616	TATA spare parts
405581900105	REAR DICKEY DOOR_1616	TATA spare parts
405581900107	GAS STAY (SKIRT PANEL)	TATA spare parts
405581900108	GAS STAY	TATA spare parts
405581900109	FUEL TANK FLAP LOCK	TATA spare parts
405581902301	PARTITION FIX GLASS	TATA spare parts
405581902302	PARTITION FIX GLASS	TATA spare parts
405581902303	PARTITION SLIDING GLASS	TATA spare parts
405581902304	PARTITION SLIDING GLASS	TATA spare parts
405581902801	LOCK- LUGGAGE COMPARTMENT	TATA spare parts
405581905001	REAR/SIDE DICKY HINGE	TATA spare parts
405581905002	REAR/SIDE DICKY HINGE	TATA spare parts
405581905003	AL-EXTRUSION(SIDE OUTER/INNER (3.5 MTR)	TATA spare parts
405581907701	SEALING - LUGGAGE COMPARTMENT	TATA spare parts
405581907702	SIDE DICKY RUBBER	TATA spare parts
405581907703	RUBBER SEAL _ 709 DELUXE	TATA spare parts
405581907704	WEATHER STRIP ENTRANCE DOOR	TATA spare parts
405581907707	WEATHER STRIP	TATA spare parts
405581907708	WEATHER STRIP	TATA spare parts
405582400101	WIPER SYSTEM	TATA spare parts
405583400101	AC LOUVER ADJUSTABLE TYPE	TATA spare parts

405588500101	FRONT BUMPER _1616	TATA spare parts
405588500102	FRONT BUMPER_GLOBUS_18	TATA spare parts
405588600101	REAR BUMPER _1616	TATA spare parts
405588600102	REAR BUMPER ASSY_GLOBUS-18	TATA spare parts
405591500101	SEAT BELT WITH BUZZER	TATA spare parts
405591900101	SEAT GAS SPRING LPO1616_GLOBUS	TATA spare parts
4055955	DATAPLATE	TATA spare parts
4056106	SCREW HEXAGON HEAD CAP	TATA spare parts
405643700111	SKIRT PANEL ASSEMBLY L= 1371 MM	TATA spare parts
405654300001	BODY RELAY	TATA spare parts
405654400101	PILOT INDICATOR (WITH LED)	TATA spare parts
405654400103	BULB 24V/21W	TATA spare parts
405654407701	RIGHT HAND SIDE HEADLAMP BAZEL	TATA spare parts
405654407702	LEFT HAND SIDE HEADLAMP BAZEL	TATA spare parts
405654407703	SIDE DIRECTION INDICATOR	TATA spare parts
405654407704	SIDE INDICATOR.	TATA spare parts
405654407705	PARKING LAMP	TATA spare parts
405654407706	TAIL LAMP ROUND (WHITE)	TATA spare parts
405654407707	BRAKE LAMP	TATA spare parts
405654407708	PARKING LAMP	TATA spare parts
405654407709	FOG LAMP ROUND (DIA 100)	TATA spare parts
405654407710	TAIL LAMP ROUND (AMBER)	TATA spare parts
405654407712	REAR HEIGHT MARKER (RED)	TATA spare parts
405654407713	FRONT HEIGHT MARKER	TATA spare parts
405654407714	LUGGAGE LAMP	TATA spare parts
405654407715	HEAD LAMP (RH)	TATA spare parts
405654407716	HEAD LAMP (LH)	TATA spare parts
405654407717	ROOF LIGHT LED TYPE ROUND	TATA spare parts
405654507701	REAR VIEW MIRROR ELECTRONIC CONTROL UNIT	TATA spare parts
405654507702	LIMIT SWITCH	TATA spare parts
405654800101	MICROPHONE	TATA spare parts
405658400101	SWITCH PLATE	TATA spare parts
405662000101	FRONT FACE ASSY FRP STR WITHOUT BUMPER	TATA spare parts
405662500101	FRONT SIDE DEFLECTOR	TATA spare parts
405662500102	FRONT SIDE DEFLECTOR	TATA spare parts
405662502301	FRONT WINDSHIELD	TATA spare parts
405662607701	A PILLAR INNER COVER-LH	TATA spare parts
405662607702	A PILLAR INNER COVER-RH	TATA spare parts
405662607703	FRONT INNER FRP PANEL	TATA spare parts
405662607704	FRONT FACE FRP	TATA spare parts
405662700101	FRONT FRP FLAP	TATA spare parts
405663000101	HUB COVER MTG CAP.	TATA spare parts
405663200101	HINGE ASSEMBLY	TATA spare parts
405663200102	HINGE ASSEMBLY COMPLETE	TATA spare parts
405663700101	REAR FLAP ASSEMBLY	TATA spare parts
405663700102	WINDOW GARNISH - RH	TATA spare parts
405663700103	WINDOW GARNISH - LH	TATA spare parts



405663700104	SKIRT PANEL ASSEMBLY (MOTOR AIR- INTAKE)	TATA spare parts
405663700105	SKIRT PANEL ASSEMBLY L= 855 MM	TATA spare parts
405663700106	SKIRT PANEL ASSEMBLY (REAR WHEEL ARCH) L	TATA spare parts
405663700107	SKIRT PANEL ASSEMBLY L= 1745 MM	TATA spare parts
405663700108	SKIRT PANEL ASSEMBLY L= 1505 MM	TATA spare parts
405663700109	SKIRT PANEL ASSEMBLY (FRONT WHEEL ARCH)	TATA spare parts
405663700110	SKIRT PANEL ASSEMBLY (MOTOR AIR- INTAKE)	TATA spare parts
405663700112	SKIRT PANEL ASSEMBLY L= 855 MM	TATA spare parts
405663700113	SKIRT PANEL ASSEMBLY L= 1745 MM	TATA spare parts
405663700114	SKIRT PANEL ASSEMBLY L= 1505 MM	TATA spare parts
405663700115	SKIRT PANEL ASSEMBLY (FRONT WHEEL ARCH)	TATA spare parts
405663700116	SKIRT PANEL ASSEMBLY L= 476 MM	TATA spare parts
405663700118	SKIRT PANEL ASSEMBLY L= 1344 MM	TATA spare parts
405663700119	SKIRT PANEL ASSEMBLY L= 1344 MM	TATA spare parts
405664000101	REAR FACE FRP STRUCTURE ASSEMBLY	TATA spare parts
405664502301	REAR WINDSHIELD	TATA spare parts
405664607701	REAR FACE INNER PANEL	TATA spare parts
405664607702	REAR FRP FACE	TATA spare parts
405664700102	REAR FRP FLAP	TATA spare parts
405667102301	FRONT WINDSCREEN	TATA spare parts
405667302302	FIXED GLASS - GREY TINT	TATA spare parts
405667302304	QUARTER GLASS DRV.	TATA spare parts
405667302305	FIXED GLASS - GREY TINT	TATA spare parts
405667302306	RIGHT REAR LATERAL GLASS	TATA spare parts
405667302307	RECTANGULAR SIDE GLASS (TOUGHENED)	TATA spare parts
405667302308	FRONT RIGHT SIDE GLASS	TATA spare parts
405667302309	SIDE WINDOW GLASS	TATA spare parts
405667302310	DRIVER&S POWER WINDOW GLASS	TATA spare parts
405667302311	RIGHT FRONT GLASS	TATA spare parts
405667302312	RIGHT TOP ABOVE DOORWAY GLASS	TATA spare parts
405667302313	LEFT TOP ABOVE DOORWAY GLASS	TATA spare parts
405667302314	LEFT FRONT DOOR FIXED GLASS	TATA spare parts
405667302315	SIDE WINDOW GLASS (LEFT)	TATA spare parts
405667302316	LEFT FRONT LATERAL GLASS	TATA spare parts
405667302317	LEFT REAR LATERAL GLASS	TATA spare parts
405667802301	REAR WINDSCREEN	TATA spare parts
405668900101	DASH BOARD (SINGLE PIECE)	TATA spare parts
405668900102	DASHBOARD LID	TATA spare parts
405668900103	DASHBOARD BOTTOM GARNISH	TATA spare parts
405668900104	GUAGE PLATE	TATA spare parts
405668906301	DASHBOARD	TATA spare parts
405672200101	DOOR COVER RH (DRIVER SIDE)	TATA spare parts
405672200102	DRIVER DOOR INNER FRP	TATA spare parts
405672302301	GLASS FOR MASATS DOOR (FRONT)	TATA spare parts
405672307701	DRIVER DOOR REAR GARNISH	TATA spare parts
405672307702	DRIVER SIDE LOWER GARNISH	TATA spare parts
405672700101	DRIVER SIDE UPPER TRIANGULAR GARNISH	TATA spare parts

405673200101	DOOR COVER LH (PASSENGER SIDE)	TATA spare parts
405673307701	PASSENGER DOOR REAR GARNISH	TATA spare parts
405673700101	PASSENGER DOOR UPPER GARNISH	TATA spare parts
405673700102	PASSENGER SIDE UPPER TRIANGULAR GARNISH	TATA spare parts
405673700117	DRIVER DOOR UPPER GARNISH	TATA spare parts
405681100101	REFLEX REFLECTOR (WHITE)	TATA spare parts
405681100102	T EMBLEM	TATA spare parts
405681100103	SUNVISOR ROLLER TYPE	TATA spare parts
405681100105	RHS REAR VIEW MIRROR ASSY	TATA spare parts
405681100106	LHS REAR VIEW MIRROR ASSY	TATA spare parts
405681107701	SUNVISER RH	TATA spare parts
405681107702	SUNVISER FRONT RH	TATA spare parts
405681107703	SUNVISER LH	TATA spare parts
405681107704	SINGLE PIECE FRONT SUNVISOR FOR HI DECK	TATA spare parts
405681500101	HAND STRAP	TATA spare parts
405681500102	STEP GRAB RAIL	TATA spare parts
405681900103	ARM COMPLETE	TATA spare parts
405681900104	DRIVER DOOR WINDOW	TATA spare parts
405681900107	FRONT TFT SCREEN	TATA spare parts
405681900108	HINGE ASSEMBLY (FRONT FLAP)	TATA spare parts
405681900109	GAS STAY(440N)	TATA spare parts
405681900110	GAS STAY(43KG)	TATA spare parts
405681900111	GAS STAY(220N)	TATA spare parts
405681902301	PARTITION GLASS	TATA spare parts
405681905001	SEAT MOUNTING EXTRUSION	TATA spare parts
405681905002	T- RAIL AL. EXTRUSION	TATA spare parts
405681905003	WAIST RAIL EXTRUSION	TATA spare parts
405681906301	GRAB HANDLE PIPE	TATA spare parts
405681906303	CUT- OFF SWITCH FRP COVER	TATA spare parts
405681907702	RUBBER DUST SEAL (SEAT MOUNTING EXTRUSIO	TATA spare parts
405681907703	BAGGAGE LOCK	TATA spare parts
405682400101	WINDSCREEN WIPER EQUIPMENT	TATA spare parts
405688500104	FRP FRONT STR W/O BUMP HCBS/R	TATA spare parts
405688500106	FRP FRONT BUMPER- HCBS	TATA spare parts
405688500110	FRONT BUMPER ASSEMBLY	TATA spare parts
405688600101	REAR BUMPER CENTER PIECE	TATA spare parts
405688600102	REAR SIDE BLADE- LH	TATA spare parts
405688600103	REAR SIDE BLADE- RH	TATA spare parts
405688600106	REAR BUMPER ASSEMBLY	TATA spare parts
405691000101	CO- DRIVER&S FOLDABLE SEAT	TATA spare parts
4058964	RESISTOR CORROSION	TATA spare parts
405900000001	S.S.PIANO HINGE (L=1830MM)	TATA spare parts
405900000002	PARTITION GLASS ASSY.	TATA spare parts
405900000003	PIPE BRACKET ASSY(MS PIPE-32DIA)	TATA spare parts
405900000004	PIPE BRACKET ASSY-MS PIPE(38 DIA)(PC)	TATA spare parts
405900000005	6HD FRP FRONT STRU.COMPL(RED+LHD)	TATA spare parts
405900000006	MIRROR ARM COMPLETE (LHD-DRIVER SIDE)	TATA spare parts

405900000007	REAR BUMPER COMPLETE	TATA spare parts
405900000008	FRP DASHBOARD (BAHRAIN TYPE)	TATA spare parts
405900000009	WIPER ARM(370X210LHD)+SPRAYKIT	TATA spare parts
405900000010	WIPER ARM(370X295LHD)+SPRAYKIT	TATA spare parts
405900000011	ASSY DOOR H.TP LH	TATA spare parts
405900000012	ASSY DOOR H.BT. LH	TATA spare parts
405900000013	WEAT.STRIP(REG.GL	TATA spare parts
405900000014	WEAT.STRIP(REG.GL	TATA spare parts
405900000015	ASSY ASH TRAY	TATA spare parts
405900000016	BRACKET FOR DOOR CYLINDER	TATA spare parts
405900000017	ASSY PAD.DOOR LH	TATA spare parts
405900000018	VEL.CHANNEL.RG.GL	TATA spare parts
405900000019	HOUSING ASH TRAY	TATA spare parts
405900000020	FRP REAR BUMPER FOR LCV BUSES	TATA spare parts
405900000021	BELL SW COVER	TATA spare parts
405900000022	BEARING CASE/LOWER	TATA spare parts
405900000023	HEIGHT MARKER LAMP(RED)AMBULANCE	TATA spare parts
405900000024	HEIGHT MARKER LAMP(WHITE)AMBULANCE	TATA spare parts
405900000025	SPEAKER	TATA spare parts
405900000026	PARTITION GLASS ASSY (PCOAT)	TATA spare parts
405900000027	FAN SWITCH	TATA spare parts
405900000028	TUBE LIGHT FOR LINE LIGHT(1 FT	TATA spare parts
405900000029	DOOR E/G BRACKET	TATA spare parts
405900000030	BEAM	TATA spare parts
405900000032	MIRROR ARM COMPL./DRIVERS	TATA spare parts
405900000033	MIRROR ARM ASSY./PASSENGER	TATA spare parts
405900000034	LICENCE PLATE LAMP	TATA spare parts
405900000035	REAR FRP STRUCTURE FOR RESLF BUS	TATA spare parts
405900000036	ACRYLIC MINI LAMP (ROUND)	TATA spare parts
405900000037	WIPER LINK END CONNECTOR(LH/RH)	TATA spare parts
405900000038	BLACK EPDM WASHER MOTOR TUBE	TATA spare parts
405900000039	FRP DSHBRD FOR 6HD WD BODY RHD	TATA spare parts
405900000040	FRP PANEL REAR	TATA spare parts
405900000041	6HD REAR DICKY LOCK	TATA spare parts
405900000042	6HD FRONT STRUC COMPL(REDA+RHD)	TATA spare parts
405900000043	PARTITION GLASS ASSY.	TATA spare parts
405900000044	ROOM MIRROR ARM	TATA spare parts
405900000045	RVM ARM ASSY(6HD-RHD-CO-DRV SD)	TATA spare parts
405900000046	MIRROR ARM COMPL-DRV'S SD/RHD	TATA spare parts
405900000047	SEAT ASSY(SEATER+BELT)	TATA spare parts
405900000048	SEAT ASSY(SINGLE+BELT)	TATA spare parts
405900000049	WIPER BLADE (NEW)L=711	TATA spare parts
405900000050	WIPER ARM (370X210 RHD)+SPRAYKT	TATA spare parts
405900000051	WIPER ARM (370X295RHD)+SPRAYKT	TATA spare parts
405900000052	WIPER LINKAGE END CONNECTOR/LH	TATA spare parts
405900000053	WIPER LINKAGE END CONNECTOR/RH	TATA spare parts
405900000054	REVERSE HORN (12V)	TATA spare parts

405900000055	ASSY DOOR H.TP RH	TATA spare parts
405900000056	ASSY DOOR H.BT RH	TATA spare parts
405900000057	SEAL DD.IN.BLB.MI	TATA spare parts
405900000058	ASSY WIND.REGL.RH	TATA spare parts
405900000059	DR.DOOR GLS/609RH	TATA spare parts
405900000060	LNK POPUP KNOB RH	TATA spare parts
405900000061	SNAP CONNECTOR RH	TATA spare parts
405900000062	HINGE ASSY (REAR BAGGAGE)	TATA spare parts
405900000063	REVOLVING LAMP	TATA spare parts
405900000064	609 REAR VIEW MIRROR	TATA spare parts
405900000065	HINGE ASSY	TATA spare parts
405900000066	HINGE ASSY RHD EMG. DOOR	TATA spare parts
405900000067	HINGE ASSY FOR DRIVER'S DOOR	TATA spare parts
405900000068	PARTITION GLASS ASSEMBLY	TATA spare parts
405900000069	ARM COMPL.	TATA spare parts
405900000070	BEARING CASE/LOWER	TATA spare parts
405900000073	INSPECTION LID (RADIATOR)	TATA spare parts
405900000074	WIPER BLADE ASSY. 508 MM	TATA spare parts
405900000075	HINGE ASSY (RADIATOR)	TATA spare parts
405900000076	WEATHER STRIP(MOULDING-REAR 5E	TATA spare parts
405900000077	ARM (ROOM MIRROR)	TATA spare parts
405900000078	MIRROR COMPLETE (ORDINARY)	TATA spare parts
405900000079	RVM ARM ASSY (5E-RHD-DRV SD)	TATA spare parts
405900000080	RVM ARM ASSY (5E-RHD-CO DRV SD)	TATA spare parts
405900000081	UNDER VIEW MIRROR	TATA spare parts
405900000082	LAMP BEZEL/LH	TATA spare parts
405900000083	LAMP BEZEL/RH	TATA spare parts
405900000084	REGULATOR VENTILATOR	TATA spare parts
405900000085	END BLADE FRONT/RH	TATA spare parts
405900000086	END BLADE FRONT/LH	TATA spare parts
405900000087	WIPER ARM (LH)	TATA spare parts
405900000088	REAR FRP STRUCTURE	TATA spare parts
405900000089	NYLON GUARD RAIL BKT(GREY/25DIA)OUTER	TATA spare parts
405900000090	HAND STRAP-TRIANGULAR L=420	TATA spare parts
405900000091	LH RVM ARM ASSY WITH BRKT	TATA spare parts
405900000092	RH RVM ARM ASSY WITH BRACKET	TATA spare parts
405900000093	DES.INDICATOR(W/O TUBE)	TATA spare parts
405900000094	VENTILATOR ASSY COMPLETE	TATA spare parts
405900000095	CENTER PIECE RESLF	TATA spare parts
405900000096	FRP ENGINE HOOD FOR 6HD BUS	TATA spare parts
405900000097	FRP PODEST FOR 6HD BUS	TATA spare parts
405900000098	FRP REAR STRUCTURE FOR6HD-MOD	TATA spare parts
405900000099	MAGAZINE POUCH IN ABS (LHD)	TATA spare parts
405900000100	HINGE FOR DRIVER'S DOOR(CITYRIDE)	TATA spare parts
405900000101	FRP DASH BOARD FOR 6HD BUS	TATA spare parts
405900000102	FRP FIRE WALL(AIR CLN PANEL)-6HD BUS	TATA spare parts
405900000103	MIRROR ARM ASSY-PASSENGER(LHD)	TATA spare parts

405900000104	MIRROR ARM COMPLETE-DRIVER(LHD)	TATA spare parts
405900000105	FRP FRONT BUMPER(NEW)FOR 6HD BUS	TATA spare parts
405900000106	HIGH MOUNT STOP LAMP WITH LED INDICATOR	TATA spare parts
405900000107	LEVER TYPE SW/PNEUMATIC DOOR BS1/2/3/4	TATA spare parts
405900000159	FRP LAMP BEZEL (NEW)LH FOR 6HD BUS	TATA spare parts
405900000160	FRP LAMP BEZEL (NEW) FOR 6HD BUS	TATA spare parts
405900000161	FRP FRONT FLAP(NEW) FOR 6HD BUS	TATA spare parts
405900000162	FRP PANEL FRONT	TATA spare parts
405900000163	DRIVER DOOR ASSY	TATA spare parts
406060011	O STYLE PACKING RING	TATA spare parts
406062000101	FRONT STEEL FACE	TATA spare parts
406062700105	STEEL FLAP	TATA spare parts
406064000101	REAR FACE	TATA spare parts
406075027001	INNER BEARING	TATA spare parts
4062315	SENSOR HUMIDITY	TATA spare parts
4063376	HOUSING GEAR	TATA spare parts
4063378	TUBE LUB OIL SUPPLY	TATA spare parts
4063455	TUBE BREATHER	TATA spare parts
4063496	GASKET LUB OIL CLR COVER	TATA spare parts
4063505	HOSE PLAIN	TATA spare parts
4063520	PLATE COVER	TATA spare parts
4063544	COVER VALVE	TATA spare parts
4063960	WASHER PLAIN	TATA spare parts
4063961	SEAL ROCKER LEVER COVER	TATA spare parts
4071636	RESTRICTION INDICATOR	TATA spare parts
4076493	SENSOR PRESSURE	TATA spare parts
4076930	SWITCH PRESSURE	TATA spare parts
4080631	THERMOSTAT	TATA spare parts
4080640	BRACE TUBE	TATA spare parts
4080645	MOTOR STARTING 12V	TATA spare parts
4080668	TUBE FUEL SUPPLY	TATA spare parts
4080670	AIR COMPRESSOR	TATA spare parts
4080671	AIR COMPRESSOR	TATA spare parts
4080677	GASKET RECTANGULARF/FILTER E-II	TATA spare parts
4080693	TUBE FUEL SUPPLY	TATA spare parts
4080700	PULLEY FAN	TATA spare parts
4080701	TENSOR BELT NEW LPT2515TC	TATA spare parts
4080702	SET BEARING CON ROD STD	TATA spare parts
4080703	SET BEARING CON ROD RS1	TATA spare parts
4080704	SET BEARING CON ROD RS2	TATA spare parts
4080705	SET BEARING CON ROD RS 3	TATA spare parts
4080706	SET BEARING CON ROD RS 4	TATA spare parts
4080707	SET MAIN BRG STD	TATA spare parts
4080708	SET MAIN BRG RS I	TATA spare parts
4080709	KIT BREATHER CRANKCASE	TATA spare parts
4080710	KIT PISTON ENGINE CNG	TATA spare parts
4080711	SET PISTON RING CNG	TATA spare parts

4080715	ADAPTOR FILTER HEAD	TATA spare parts
4080720	FUEL STRAINER	TATA spare parts
4080725	TUBE FUEL SUPPLY	TATA spare parts
4080727	FAN ENGINE	TATA spare parts
4080728	FAN ENGINE 22 INCH VISCOUS	TATA spare parts
4080729	FAN ENGINE 20 INCH VISCOUS	TATA spare parts
4080735	ALTERNATOR 12VOLT FOR AC VEH	TATA spare parts
4080736	SUPPORT ALTERNATOR BS2	TATA spare parts
4080737	BRACE ALTERNATOR FOR AC VEH	TATA spare parts
4080738	SPACER FOR AC VEH	TATA spare parts
4080741	RING GEAR	TATA spare parts
4080742	RING GEAR	TATA spare parts
4080743	GEAR FLYWHEEL RING	TATA spare parts
4080744	ASSY FLYWHEEL	TATA spare parts
4080746	GEAR FLYWHEEL RING	TATA spare parts
4080753	CONNECTION AIR INTAKE	TATA spare parts
4080780	CONNECTION WATER OUTLET	TATA spare parts
4080781	CONNECTION WATER OUTLET	TATA spare parts
4080786	Breather Assy	TATA spare parts
4080791	ALTERNATOR 24V 75 AMP BS 2	TATA spare parts
4080792	SPACER FOR AC VEH	TATA spare parts
4080795	FIP INLINE 100 HP EURO 2	TATA spare parts
4080796	PUMP FUEL INJECTION 125HP EURO I	TATA spare parts
4080797	FUEL INJ PUMP 145HP EURO I INLINE	TATA spare parts
4080798	ASSY FIP 160 HP 6BT ENGINE	TATA spare parts
4080800	FLYWHEEL HOUSING	TATA spare parts
4080803	SUPPORT ALTERNATOR BS2	TATA spare parts
4080812	KIT GUIDE VALVES STEM EXHAUST	TATA spare parts
4080813	KIT EXHAUST INSERT VALVE	TATA spare parts
4080814	INJECTOR	TATA spare parts
4080816	KIT GUIDE VALVES STEM INTAKE	TATA spare parts
4080817	KIT INTAKE INSERT VALVE	TATA spare parts
4088451	SCREW HEX FLANGE HEAD CAP	TATA spare parts
408901010027	CURVED TAIL LAMP RHD (AMBER)	TATA spare parts
4089085	KIT SPARK PLUG	TATA spare parts
4089086	SPARK PLUG	TATA spare parts
4089208	HEAD ASM. KIT SINGLE 75MM US PORTS	TATA spare parts
4089209	PISTON ASM. KIT SINGLE 85MM MAJOR	TATA spare parts
4089210	PISTON ASM. KIT SINGLE 75MM MAJOR	TATA spare parts
4089211	CONN ROD ASM. KIT SINGLE 85MM MAJOR	TATA spare parts
4089212	CONN ROD ASM. KIT SINGLE 75MM MAJOR	TATA spare parts
4089222	REAR SEAL / ADAPTER KIT MAJOR	TATA spare parts
4089238	HEAD GASKET KIT SINGLE 85MM MAJOR	TATA spare parts
4089240	HEAD GASKET KIT SINGLE 75MM MAJOR	TATA spare parts
4089342	KIT CRANKSHAFT SEAL	TATA spare parts
4089346	KIT ENG PISTON	TATA spare parts
4089556	RINGS 85MM MINOR	TATA spare parts

4089675	SUMP PLUG KIT	TATA spare parts
4089677	SPLINE ADAPTER 11TH	TATA spare parts
40900002514	DASH BOARD KIT	TATA spare parts
409001000101	FRONT STRUCTURE ASSY.	TATA spare parts
409001000122	SHEET METAL FRONT BUMPER ASSEMBLY	TATA spare parts
409001000125	SM FRP FRONT FLAP ASSEMBLY	TATA spare parts
409001000201	WINDSHIELD LOWER ROOFSTICK ASSY.	TATA spare parts
409001000202	WINDSHIELD LOWER ROOFSTICK ASSY.	TATA spare parts
409001000203	FRONT COLUMN ASSY	TATA spare parts
409001000204	FRONT BUMPER	TATA spare parts
409001000205	FRONT BUMPER	TATA spare parts
409001000218	SHEET METAL FRONT FACE	TATA spare parts
409001000221	FRP FRONT BUMPER ASSY -FOG LAMPS	TATA spare parts
409001000223	FRP FRONT FACE WITH HEAD LAMP BRACKET	TATA spare parts
409001000224	SM FRP FRONT FLAP ASSEMBLY	TATA spare parts
409001000225	FRONT BUMPER ASSY. KIT	TATA spare parts
409001000237	FRP SP REAR BUMPER WITH FOG LAMP ASSY	TATA spare parts
409001000239	FRP SP REAR BUMPER WITH FOG LAMP ASSY	TATA spare parts
409001000255	FRONT BUMPER BRACKET ASSEMBLY	TATA spare parts
409001000305	FRP FRONT FLAP STRUCTURE	TATA spare parts
409001000307	FRP FRONT CENTER BUMPER ASSY-LHD	TATA spare parts
409001000308	FRP FRONT CORNER BUMPER -LH-LHD	TATA spare parts
409001000309	FRP FRONT CORNER BUMPER -RH-LHD	TATA spare parts
409001000339	FRONT FLAP HING ASSY	TATA spare parts
409001000417	FRONT BUMPER CONRER-LH EV	TATA spare parts
409001000418	FRONT BUMPER-CENTER EV	TATA spare parts
409001000419	FRONT BUMPER CORNER-RH EV	TATA spare parts
409001000501	ASSY FR. BUMPER	TATA spare parts
409001000502	Font bumper assy - Pista Green	TATA spare parts
409001000601	RIGHT CORNER FRONT BUMPER	TATA spare parts
409001000602	LEFT CORNER FRONT BUMPER	TATA spare parts
409001000603	FRONT BUMPER	TATA spare parts
409001000607	FRONT BUMPER CENTRE	TATA spare parts
409001100201	FRONT COLUMN	TATA spare parts
409001100202	FRONT COLUMN	TATA spare parts
409001100203	FRONT LOWER COLUMN	TATA spare parts
409001100204	FRONT LOWER COLUMN	TATA spare parts
409001100205	FRONT UPPER COLUMN	TATA spare parts
409001100206	WINDSHIELD UPPER ROOFSTICK	TATA spare parts
409001200301	ADJUSTABLE JAMB ROD_50MM	TATA spare parts
409001500302	HONEY COMB MESH FOR SW FRONT FACE	TATA spare parts
409001500308	L-ANGLE SUPPORT	TATA spare parts
409001500309	L-ANGLE SUPPORT FOR FRP FRONT FLAP	TATA spare parts
409001500501	FRONT FLAP TOP HONEY COMB MESH	TATA spare parts
409001500502	FRONT FLAP BOTTOM HONEY COMB MESH	TATA spare parts
409001700201	WINDSHIELD ARCH UNION GUSSET	TATA spare parts
409001700202	WINDSHIELD ARCH UNION GUSSET	TATA spare parts

409001700203	JOINT GUSSET UPPER FRONT	TATA spare parts
409001700204	JOINT GUSSET UPPER FRONT	TATA spare parts
409001700205	FRONT UPPER CLOSING	TATA spare parts
409001700206	FRONT UPPER CLOSING	TATA spare parts
409001700207	FRONT LOWER CLOSING	TATA spare parts
409001700208	FRONT LOWER CLOSING	TATA spare parts
409001700209	WINDSHIELD ARCH UNION GUSSET	TATA spare parts
409001700210	WINDSHIELD ARCH UNION GUSSET	TATA spare parts
409001700211	FRONT LOWER COLUMN	TATA spare parts
409001700212	FRONT LOWER COLUMN	TATA spare parts
409001700215	SUPPORT PLATE	TATA spare parts
409001700216	FRONT GRILL JAMB PLATE	TATA spare parts
409001700226	WINDSHIELD ROOFSTICK GUSSET	TATA spare parts
409001700312	MCV FR FOG LAMP BRACKET RH	TATA spare parts
409001700313	MCV FR FOG LAMP BRACKET LH	TATA spare parts
409001700333	FRONT FACE MESH_02_G3 BS6	TATA spare parts
409001700407	FRONT FLAP SHEET METAL	TATA spare parts
409002000107	REAR STRUCTURE	TATA spare parts
409002000114	SM REAR BUMPER WIT FOGLAMP FITMENT	TATA spare parts
409002000138	REAR BUMPER ASSY. KIT	TATA spare parts
409002000201	ENGINE SHUTTER LOWER ROOFSTICK ASSEMBLY	TATA spare parts
409002000202	REAR WINDOW LOWER ROOFSTICK ASSY.	TATA spare parts
409002000203	ENGINE SHUTTER SIDE ROOFSTICK ASSEMBLY	TATA spare parts
409002000204	ENGINE SHUTTER SIDE ROOFSTICK ASSEMBLY	TATA spare parts
409002000205	REAR BUMPER ANCHORAGE ASSY. KIT	TATA spare parts
409002000207	ENGINE SHUTTER SIDE ROOFSTICK ASSEMBLY R	TATA spare parts
409002000208	ENGINE SHUTTER SIDE ROOFSTICK ASSEMBLY L	TATA spare parts
409002000209	REAR BUMPER	TATA spare parts
409002000210	REAR BUMPER	TATA spare parts
409002000219	FRP LIC PLATE ATTACHING BASE W/O RLB	TATA spare parts
409002000225	FRP REAR SINGLE PIECE BUMPER 1050 ASSY	TATA spare parts
409002000228	REAR EXTERNAL REVTMENT	TATA spare parts
409002000229	FRP REAR TAIL LAMP CLUSTER - LH	TATA spare parts
409002000230	FRP REAR TAIL LAMP CLUSTER - RH	TATA spare parts
409002000231	FRP ROOF MARKER LAMP MOUNTING-RH	TATA spare parts
409002000232	FRP ROOF MARKER LAMP MOUNTING-LH	TATA spare parts
409002000260	TAIL LAMP GRILL ASSY	TATA spare parts
409002000264	REAR BUMPER BRACKET ASSEMBLY	TATA spare parts
409002000302	ROD COUPLING BOLT ASSY.	TATA spare parts
409002000321	MCV REAR SINGLE WINDSHIELD GLASS	TATA spare parts
409002000405	REAR BUMPER CORNER-LH EV	TATA spare parts
409002000406	REAR BUMPER CENTER EV	TATA spare parts
409002000407	REAR BUMPER CORNER-R EV	TATA spare parts
409002000501	RR BUMPER	TATA spare parts
409002000503	Rear bumper assy - Pista Green	TATA spare parts
409002000601	REAR BUMPER	TATA spare parts
409002000602	LEFT CORNER REAR BUMPER	TATA spare parts



409002000603	RIGHT CORNER REAR BUMPER	TATA spare parts
409002000607	REAR BUMPER CENTRE	TATA spare parts
409002000608	RIGHT CORNER REAR BUMPER	TATA spare parts
409002000609	LEFT CORNER REAR BUMPER	TATA spare parts
409002100201	REAR WINDOW UPPER ROOFSTICK	TATA spare parts
409002100202	REAR SIDE PILLAR	TATA spare parts
409002100203	REAR SIDE PILLAR	TATA spare parts
409002100204	HEAR WINDOW SIDE PILLAR	TATA spare parts
409002100205	REAR WINDOW SIDE PILLAR	TATA spare parts
409002100206	REAR SEMI ROOFSTICK	TATA spare parts
409002100207	REAR SEMI ROOFSTICK	TATA spare parts
409002100208	REAR SEMI ROOFSTICK	TATA spare parts
409002100209	REAR SEMI ROOFSTICK	TATA spare parts
409002100210	REAR SEMI ROOFSTICK	TATA spare parts
409002100211	REAR SEMI ROOFSTICK	TATA spare parts
409002100212	REAR STRUCTURE ATTACHMENT REINFORCEMEN	TATA spare parts
409002100213	REAR STRUCTURE ATTACHMENT REINFORCEMEN	TATA spare parts
409002100214	REAR STRUCTURE ATTACHMENT REINFORCEMEN	TATA spare parts
409002100215	REAR STRUCTURE ATTACHMENT REINFORCEMEN	TATA spare parts
409002100216	SIDE RAIL (FOR PU INJECTION)	TATA spare parts
409002100217	SIDE RAIL ( FOR PU INJECTOR)	TATA spare parts
409002200201	SIDE FLAP LIMITER COUPLING PIN	TATA spare parts
409002300303	MCV REAR SINGLE WINDSHIELD GLASS	TATA spare parts
409002400201	RUBBERS FLAPS	TATA spare parts
409002400202	RUBBERS FLAPS 500X300X4THK	TATA spare parts
409002400204	4X1000-MM BLACK RUBBER SHEET W/3 LININGS	TATA spare parts
409002500201	WHEEL FLAP SUPPORT	TATA spare parts
409002500202	MUDGUARD ATTACHING PROFILE	TATA spare parts
409002500203	MUDGUARD ATTACHING PROFILE	TATA spare parts
409002500206	MUDGUARD ATTACHING PROFILE	TATA spare parts
409002700201	ROOF REVITMENT ATTACHING PLATE	TATA spare parts
409002700202	REINFORCEMENT BETWEEN COLUMN	TATA spare parts
409002700203	REINFORCEMENT BETWEEN COLUMN	TATA spare parts
409002700204	AMENDMENT REINFORCEMENT OF THE REAR CO	TATA spare parts
409002700205	REINFORCEMENT BETWEEN COLUMN	TATA spare parts
409002700211	REAR BUMPER BRACKET	TATA spare parts
409002700212	AMENDMENT REINFORCEMENT OF THE REAR COND.	TATA spare parts
409002700214	REAR BUMPER ATTACHMENT SUPPORT 1	TATA spare parts
409002700217	SHEET METAL REAR FACE W/O RLB	TATA spare parts
409002700235	REAR FACE W/O RLB ASSY	TATA spare parts
409002700236	REAR FACE RIENFORCEMENT LH	TATA spare parts
409002700237	REAR FACE RIENFORCEMENT RH	TATA spare parts
409002700280	HARNESS COVERING PLATE	TATA spare parts
409002700303	BUMPER ANCHORAGE ATTTACHMENT ASSY.	TATA spare parts
409002900901	M8X1.25X60-CLASSE 8.8 - ZN- HEXAGONAL SC	TATA spare parts
409003000202	DOOR STRUCTURE ASSY.	TATA spare parts
409003000203	DOOR STRUCTURE ASSY.	TATA spare parts

409003000204	DOOR STRUCTURE ASSY.	TATA spare parts
409003000205	DOOR STRUCTURE ASSY.	TATA spare parts
409003000206	AXLE CLOSING ASSY.	TATA spare parts
409003000207	AXLE CLOSING ASSY.	TATA spare parts
409003000208	AXLE CLOSING ASSY.	TATA spare parts
409003000209	WINDOW UPPER RAIL ASSY.	TATA spare parts
409003000210	WINDOW SILL	TATA spare parts
409003000211	PILLAR ASSY. BETWEEN WINDOWS	TATA spare parts
409003000212	ASSY. BETWEEN WINDOW	TATA spare parts
409003000213	SKIRT LOWER JAMB W/ CLOSING	TATA spare parts
409003000214	SKIRT LOWER JAMB W/ CLOSING	TATA spare parts
409003000215	REAR FRAME OVERHANG JAMB	TATA spare parts
409003000216	RAMP STRUCTURE ATTACHMENT REINFORCEMEN	TATA spare parts
409003000217	RAMP STRUCTURE ATTACHMENT REINFORCEMEN	TATA spare parts
409003000218	REAR FRAME OVERHANG JAMB	TATA spare parts
409003000219	WINDOW GUSSET ASSY.	TATA spare parts
409003000220	SAFETY BELT BUSHING SUPPORT	TATA spare parts
409003000221	SIDE RECTANGULAR TUBE	TATA spare parts
409003000222	AXLE CLOSING ASSY.(R.H FRONT)	TATA spare parts
409003000223	AXLE CLOSING ASSY.(R.H REART)	TATA spare parts
409003000224	AXLE CLOSING ASSY.(L.H FRONT)	TATA spare parts
409003000225	DOOR STRUCTURE ASSY.	TATA spare parts
409003000226	SIDE RECTANGULAR TUBE (80X40X2.75X1604IN	TATA spare parts
409003000227	SIDE RECTANGULAR TUBE (80X40X2.75X1400IN	TATA spare parts
409003000228	SIDE RECTANGULAR TUBE (80X40X2.75X1300IN	TATA spare parts
409003000229	SIDE RECTANGULAR TUBE ( 80X40X2.75X1556I	TATA spare parts
409003000230	SIDE RECTANGULAR TUBE (80X40X2.75X1179IN	TATA spare parts
409003000231	SIDE RECTANGULAR TUBE (80X40X1.95X1585IN	TATA spare parts
409003000232	SIDE RECTANGULAR TUBE (80X40X2.75X734IN)	TATA spare parts
409003000233	WINDOW SUPPORT TUBE	TATA spare parts
409003000235	RAMP STRUCTURE ATTACHMENT REINFORCEMEN	TATA spare parts
409003000236	RAMP STRUCTURE ATTACHMENT REINFORCEMEN	TATA spare parts
409003000237	AXLE CLOSING ASSY.	TATA spare parts
409003000238	REAR FRAME OVERHANGING JAMP	TATA spare parts
409003000247	AXLE CLOSING ASSY.(R.H REAR)	TATA spare parts
409003000265	ASSEMBLY BETWEEN WINDOW	TATA spare parts
409003000356	LH SIDE STRUCTURE ASSEMBLY	TATA spare parts
409003010231	RH SIDE STRUCTURE 1613 55WB DIMITS	TATA spare parts
409003100201	RECTANGULAR TUBE	TATA spare parts
409003100202	RECTANGULAR TUBE	TATA spare parts
409003100203	RECTANGULAR TUBE	TATA spare parts
409003100204	RECTANGULAR TUBE	TATA spare parts
409003100205	WHEEL RIM SIDE PILLAR	TATA spare parts
409003100206	REAR SIDE PILLAR	TATA spare parts
409003100207	RECTANGULAR TUBE	TATA spare parts
409003100208	RECTANGULAR TUBE	TATA spare parts
409003100209	RECTANGULAR TUBE	TATA spare parts

409003100210	RECTANGULAR TUBE	TATA spare parts
409003100211	SIDE RAIL (FOR PU INJECTION)	TATA spare parts
409003100212	RECTANGULAR TUBE	TATA spare parts
409003100213	ENGINE HINGED DOOR SIDE PILLAR	TATA spare parts
409003100214	ENGINE HINGED DOOR SIDE PILLAR	TATA spare parts
409003100215	WHEEL RIM SIDE PILLAR	TATA spare parts
409003100216	RECTANGULAR TUBE	TATA spare parts
409003100217	SIDE SUPPORT TUBE	TATA spare parts
409003100218	RECTANGULAR TUBE	TATA spare parts
409003100219	RECTANGULAR TUBE	TATA spare parts
409003100220	RECTANGULAR TUBE	TATA spare parts
409003100221	RECTANGULAR TUBE	TATA spare parts
409003100222	RECTANGULAR TUBE	TATA spare parts
409003100223	RECTANGULAR TUBE	TATA spare parts
409003100224	RECTANGULAR TUBE	TATA spare parts
409003100225	SIDE SUPPORT TUBE	TATA spare parts
409003100226	SIDE SUPPORT TUBE	TATA spare parts
409003100227	SIDE SUPPORT TUBE	TATA spare parts
409003100228	SIDE SUPPORT TUBE	TATA spare parts
409003100229	SIDE SUPPORT TUBE	TATA spare parts
409003100230	SIDE SUPPORT TUBE	TATA spare parts
409003100231	UPPER FIX GLASS SUPPORT	TATA spare parts
409003100232	RECTANGULAR TUBE	TATA spare parts
409003100233	RECTANGULAR TUBE	TATA spare parts
409003100234	RECTANGULAR TUBE	TATA spare parts
409003100235	RECTANGULAR TUBE	TATA spare parts
409003100236	RECTANGULAR TUBE	TATA spare parts
409003100237	RECTANGULAR TUBE	TATA spare parts
409003100238	RECTANGULAR TUBE	TATA spare parts
409003100239	RECTANGULAR TUBE	TATA spare parts
409003100240	WHEEL RIM SIDE PILLAR	TATA spare parts
409003100241	RECTANGULAR TUBE	TATA spare parts
409003100242	RECTANGULAR TUBE	TATA spare parts
409003100243	SIDE SUPPORT TUBE	TATA spare parts
409003100244	G.I. TUBE 40X40X1.95X564	TATA spare parts
409003100245	G.I. TUBE 40X40X1.95X355	TATA spare parts
409003100246	G.I. TUBE 40X20X1.55X210	TATA spare parts
409003100247	G.I. TUBE 40X20X1.55X254	TATA spare parts
409003100248	G.I. RECTANGULAR TUBE	TATA spare parts
409003100249	80X40X2.7 SIDE FRAME (F/PU INJECTION)	TATA spare parts
409003100256	PILLAR BETWEEN WINDOWS (FRONT END) 80X40	TATA spare parts
409003100257	WINDOW PILLAR TUBE (60X40X3.75X1656IN)	TATA spare parts
409003100258	REAR END WINDOW PILLAR (60X40X3.75X1228I	TATA spare parts
409003100267	SIDE RECTANGULAR TUBE(50X40X1.95)	TATA spare parts
409003100271	SIDE RECTANGULAR TUBE (80X40X1.95X254IN)	TATA spare parts
409003100272	SIDE RECTANGULAR TUBE (80X40X1.95X70IN)	TATA spare parts
409003100273	SIDE RECTANGULAR TUBE(50X40X1.95)	TATA spare parts

409003100275	WINDOW SUPPORT TUBE	TATA spare parts
409003100277	SIDE RECTANGULAR TUBE (80X40X1.95X1585IN	TATA spare parts
409003100278	RECTANGULAR TUBE	TATA spare parts
409003100280	RECTANGULAR TUBE	TATA spare parts
409003100281	SIDE RECTANGULAR TUBE	TATA spare parts
409003100282	RECTANGULAR TUBE	TATA spare parts
409003100283	SIDE RECTANGULAR TUBE (80X40X1.95X1198IN	TATA spare parts
409003100284	RECTANGULAR TUBE	TATA spare parts
409003100285	WINDOW SUPPORT TUBE	TATA spare parts
409003100286	REAR SIDE PILLAR	TATA spare parts
409003100287	WHEEL RIM SIDE PILLAR	TATA spare parts
409003100288	WHEEL RIM SIDE PILLAR	TATA spare parts
409003100289	ENGINE HINGED DOOR SIDE PILLAR	TATA spare parts
409003100295	GI RECTANGULAR TUBE	TATA spare parts
409003100296	SIDE RECTANGULAR TUBE (80X40X1.95X70 LN)	TATA spare parts
409003100319	WINDOW UPPER TUBE	TATA spare parts
409003110213	SUPPORT TUBE ABOVE BATTERY BOX.	TATA spare parts
409003110223	WINDOW PILLAR TUBE (60X40X3.75THK)	TATA spare parts
409003110224	SIDE RECTANGULAR TUBE	TATA spare parts
409003110225	SIDE SUPPORT TUBE	TATA spare parts
409003110229	SIDE RAIL (FOR PU INJECTION)	TATA spare parts
409003110251	GI TUBE - 45X35X1.95_1077 LN	TATA spare parts
409003110252	GI TUBE - 45X35X1.95_975 LN	TATA spare parts
409003110253	GI TUBE - 45X35X1.95_845 LN	TATA spare parts
409003120262	35X45X1.95 GI_TUBE_CUT 45_1048	TATA spare parts
409003120263	35X45X1.95 GI_TUBE_CUT 45_812	TATA spare parts
409003120264	35X45X1.95 GI_TUBE_CUT 45_713	TATA spare parts
409003120267	35X45X1.95 GI_TUBE_CUT 45_1406	TATA spare parts
409003120274	SIDE TUBE	TATA spare parts
409003500201	SKIRT LOWER JAMB W/ CLOSING	TATA spare parts
409003500202	SKIRT PROTECTION L-PROFILE 40X30X3THK.51	TATA spare parts
409003500203	L-PROFILE 40X30X3THK.3230 LN	TATA spare parts
409003500204	L-PROFILE 40X30X3THK.685 LN.	TATA spare parts
409003500222	L-PROFILE 1491	TATA spare parts
409003700201	SHEET	TATA spare parts
409003700202	SHEET	TATA spare parts
409003700203	SHEET	TATA spare parts
409003700204	SHEET	TATA spare parts
409003700205	SHEET	TATA spare parts
409003700206	SHEET	TATA spare parts
409003700207	WINDOW GUSSET	TATA spare parts
409003700208	SHEET	TATA spare parts
409003700209	SHEET	TATA spare parts
409003700210	SHEET	TATA spare parts
409003700211	DOOR ATTACHMENT COLUMN	TATA spare parts
409003700212	GUSSET H.R. SHEET 150X103X2.7 THK.	TATA spare parts
409003700215	U-SHAPPED PLATE(199X140.8X7THK)	TATA spare parts

409003700216	WINDOW SUPPORT C-PROFIED	TATA spare parts
409003700217	STEEL PLATE 300X75X4.25TK	TATA spare parts
409003700218	REINFORCEMENT FOR SWITCH	TATA spare parts
409003700347	STEEL PLATE	TATA spare parts
409004000101	HANDICAPPED RAMP ASSEMBLY	TATA spare parts
409004000201	RAMP STRUCTURE ASSEMBLY	TATA spare parts
409004000202	HANDICAPPED RAMP HINGE ASSEMBLY	TATA spare parts
409004000203	RAMP STRUCTURE ASSY.	TATA spare parts
409004000204	HANDICAPPED RAMP HINGE ASSY	TATA spare parts
409004000206	RAMP STRUCTURE ASSEMBLY	TATA spare parts
409004100201	RAMP SWITCH_24V	TATA spare parts
409004300101	RAMP FINISH ALUMINIUM PROFILE AT SENSORS	TATA spare parts
409004300201	RAMP UPPER PLATE FOR DISABLED	TATA spare parts
409004300202	RAMP FINISH PROFILE	TATA spare parts
409004300203	RAMP FINISH PROFILE	TATA spare parts
409004300204	RAMP FINISH PROFILE	TATA spare parts
409004300207	RAMP UPPER PLATE	TATA spare parts
409004300211	L-PROFILE 890X40X1 THK.	TATA spare parts
409004300212	RAMP UPPER PLATE	TATA spare parts
409004300214	L-PROFILE 900X40X1 THK	TATA spare parts
409004500201	RAMP STRUCTURE PROFILE	TATA spare parts
409004500202	RAMP STRUCTURE PROFILE	TATA spare parts
409004990202	COVER RECESSED HANDLE	TATA spare parts
409005000201	ROOF FRONTAL REINFORCEMENT ASSY	TATA spare parts
409005100201	ROOFSTICK TUBE	TATA spare parts
409005100202	ROOFSTICK TUBE	TATA spare parts
409005100203	ROOF STRUCTURAL .	TATA spare parts
409005100204	ROOFSTICK TUBE	TATA spare parts
409005100205	CONDUIT TUBE	TATA spare parts
409005100206	LOWER UNDERFRAME OF THE ROOF	TATA spare parts
409005100207	LOWER UNDERFRAME OF THE ROOF	TATA spare parts
409005100208	ROOFSTICK TUBE	TATA spare parts
409005100210	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100211	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100212	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100213	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100214	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100215	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100216	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100217	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100218	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100219	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100220	ROOF UPPER REINFORCED TUBE 220	TATA spare parts
409005100221	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100222	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100223	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100224	ROOF UPPER REINFORCED TUBE	TATA spare parts

409005100226	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100227	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100228	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100229	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100230	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100231	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100232	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100233	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100234	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100235	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100236	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100237	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100238	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100242	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100252	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100254	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100264	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100265	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100266	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100267	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100268	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100269	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100270	ROOF UPPER REIN 40X30X1.95 TUBE	TATA spare parts
409005100271	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100272	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100273	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100274	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100275	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100276	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100277	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100278	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100279	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100280	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100281	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100282	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100284	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100285	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005100288	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005110208	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005110209	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005110210	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005110211	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005110212	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005110213	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005110214	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005110215	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005110216	ROOF UPPER REINFORCED TUBE REAR END	TATA spare parts

409005200214	HARNESS SUPPORT	TATA spare parts
409005200223	BEACOM LAMP MOUNTING SHEET(FRONT)	TATA spare parts
409005200224	BEACOM LAMP MOUNTING SHEET(REAR)	TATA spare parts
409005500201	ROOF UPPER C PROFILE	TATA spare parts
409005500202	ROOF UPPER C PROFILE	TATA spare parts
409005500203	AIR CONDITIONING SUPPORT PROFILE	TATA spare parts
409005500204	AIR CONDITIONING SUPPORT PROFILE	TATA spare parts
409005500205	AIR CONDITIONING SUPPORT PROFILE	TATA spare parts
409005500206	AIR CONDITIONING SUPPORT PROFILE	TATA spare parts
409005500207	AIR CONDITIONING SUPPORT PROFILE	TATA spare parts
409005500208	AIR CONDITIONING SUPPORT PROFILE	TATA spare parts
409005500209	ROOF UPPER C PROFILE	TATA spare parts
409005500210	ROOF UPPER C PROFILE	TATA spare parts
409005500211	ROOF UPPER C PROFILE	TATA spare parts
409005500212	ROOF UPPER C PROFILE	TATA spare parts
409005500213	ROOF UPPER C PROFILE	TATA spare parts
409005500214	AIR CONDITIONING AIR ATTACHMENT U PROFIL	TATA spare parts
409005500215	L-PROFILE-257X126X1.95	TATA spare parts
409005500216	AIR CONDITIONING AIR ATTACHMENT U PROF	TATA spare parts
409005500217	AIR CONDITIONING AIR ATTACHMENT U PROF	TATA spare parts
409005500218	AIR CONDITIONING AIR ATTACHMENT U PROF	TATA spare parts
409005500219	AIR CONDITIONING AIR ATTACHMENT U PROF	TATA spare parts
409005500220	AIR CONDITIONING AIR ATTACHMENT U PROF	TATA spare parts
409005500221	AIR CONDITIONING AIR ATTACHMENT U PROF	TATA spare parts
409005500222	AIR CONDITIONING AIR ATTACHMENT U PROF	TATA spare parts
409005500223	AIR CONDITIONING SUPPORT PROFILE	TATA spare parts
409005500225	AIR CONDITIONING SUPPORT PROFILE	TATA spare parts
409005500226	AIR CONDITIONING SUPPORT PROFILE	TATA spare parts
409005500227	AIR CONDITIONING SUPPORT PROFILE	TATA spare parts
409005500228	AIR CONDITIONING AIR ATTACHMENT U PRO.	TATA spare parts
409005500229	AIR CONDITIONING AIR ATTACHMENT U PROF	TATA spare parts
409005500230	AIR CONDITIONING SUPPORT PROFILE	TATA spare parts
409005500231	L-PROFILE-257X126X1.95	TATA spare parts
409005500232	AIR CONDITIONING AIR ATTACHMENT U PROF	TATA spare parts
409005500233	AIR CONDITIONING AIR ATTACHMENT U PROF	TATA spare parts
409005500234	AIR CONDITIONING AIR ATTACHMENT U PROF	TATA spare parts
409005500253	ROOFSTICK CLOSING	TATA spare parts
409005500257	ROOF UPPER REINFORCED TUBE	TATA spare parts
409005500269	AIR CONDITIONING AIR ATTACHMENT U PROFIL	TATA spare parts
409005500270	AIR CONDITIONING AIR ATTACHMENT U PROFIL	TATA spare parts
409005500271	AIR CONDITIONING AIR ATTACHMENT U PROFIL	TATA spare parts
409005500272	AIR CONDITIONING AIR ATTACHMENT U PROF	TATA spare parts
409005700201	SHEET	TATA spare parts
409005700202	ROOF UPPER C PROFILE	TATA spare parts
409005700203	ROOF UPPER C PROFILE	TATA spare parts
409005700204	ROOF UPPER C PROFILE	TATA spare parts
409005700205	ROOF UPPER REINFORCEMENT	TATA spare parts

409005700206	STEEL PLATES	TATA spare parts
409005700208	STEEL PLATES	TATA spare parts
409005700209	STEEL PLATES	TATA spare parts
409005700210	STEEL PLATES	TATA spare parts
409005700211	STEEL PLATES	TATA spare parts
409005700212	STEEL PLATES	TATA spare parts
409005700213	ROOF REINFORCEMENT STEEL PLATE	TATA spare parts
409005700223	ROOF UPPER C PROFILE	TATA spare parts
409005700231	ROOF UPPER C PROFILE	TATA spare parts
409005700232	ROOF UPPER C PROFILE	TATA spare parts
409005700244	ROOF UPPER C PROFILE	TATA spare parts
409005700245	ROOF UPPER C PROFILE	TATA spare parts
409005700246	ROOF UPPER C PROFILE	TATA spare parts
409005700247	ROOF UPPER C PROFILE	TATA spare parts
409005700249	ROOF UPPER REINFORCEMENT	TATA spare parts
409005700250	ROOFSTICK CLOSING	TATA spare parts
409005700251	ROOFSTICK CLOSING	TATA spare parts
409005700252	ROOFSTICK CLOSING	TATA spare parts
409005700253	ROOFSTICK CLOSING	TATA spare parts
409005700256	ROOFSTICK CLOSING	TATA spare parts
409005700257	ROOFSTICK CLOSING	TATA spare parts
409005700258	ROOFSTICK CLOSING	TATA spare parts
409005700259	ROOFSTICK CLOSING	TATA spare parts
409005700260	ROOFSTICK CLOSING	TATA spare parts
409005700261	ROOFSTICK CLOSING	TATA spare parts
409005700262	ROOFSTICK CLOSING	TATA spare parts
409005700265	BOX TYPE GUSSET	TATA spare parts
409005700266	ROOF UPPER C PROFILE	TATA spare parts
409005700267	ROOF UPPER C PROFILE	TATA spare parts
409005700269	STEEL PLATES	TATA spare parts
409005700274	STEEL PLATES	TATA spare parts
409005700275	STEEL PLATES	TATA spare parts
409005700286	STEEL PLATES	TATA spare parts
409005700287	MS PLATE 98X64X2.7	TATA spare parts
409005700288	ROOF UPPER REINFORCEMENT	TATA spare parts
409005700401	ROOFSTICK CLOSING	TATA spare parts
409005700402	ROOFSTICK CLOSING	TATA spare parts
409005700403	ROOFSTICK CLOSING	TATA spare parts
409005700404	ROOFSTICK CLOSING	TATA spare parts
409005700405	ROOFSTICK CLOSING	TATA spare parts
409005700406	ROOFSTICK CLOSING	TATA spare parts
409005700407	ROOFSTICK CLOSING	TATA spare parts
409005700408	ROOFSTICK CLOSING	TATA spare parts
409005700409	ROOF ARCHED PIPE CLOSING REINFORCEMENT	TATA spare parts
409005700410	ROOFSTICK CLOSING	TATA spare parts
409006000102	FRONT UNION ASSEMBLY	TATA spare parts
409006000110	CROSS MEMBER FASTNING ASSY	TATA spare parts



409006000111	CROSS MEMBER FASTNING ASSY	TATA spare parts
409006000201	WHEEL BASE STRUCTURE ASSY.	TATA spare parts
409006000202	WHEEL BASE STRUCTURE ASSY.	TATA spare parts
409006100201	CHASSIS LENGTHENING RAIL	TATA spare parts
409006100202	CHASSIS LENGTHENING RAIL	TATA spare parts
409006100203	FRAME REINFORCEMENT	TATA spare parts
409006100204	FRAME REINFORCEMENT	TATA spare parts
409006100205	FRAME REINFORCEMENT	TATA spare parts
409006100206	FRAME REINFORCEMENT	TATA spare parts
409006100207	FRAME REINFORCEMENT	TATA spare parts
409006100208	FRAME REINFORCEMENT	TATA spare parts
409006100209	RECTANGULAR TUBE	TATA spare parts
409006100218	G.I TUBE 60X40X3.75THK.2472 LN	TATA spare parts
409006200201	CABLE SUPPORT	TATA spare parts
409006300201	RUBBER GROMMET 66X164X12MM	TATA spare parts
409006300202	RUBBER GROMMET 60X165X12MM.	TATA spare parts
409006300203	RUBBER GROMMET 55X95X12MM	TATA spare parts
409006500201	BASE LOWER PROFILE	TATA spare parts
409006500202	CHASSIS CROSSMEMBER FASTNING PROFILE	TATA spare parts
409006500203	CHASSIS CROSSMEMBER FASTNING PROFILE	TATA spare parts
409006500204	CHASSIS CROSSMEMBER FASTNING PROFILE	TATA spare parts
409006500205	CHASSIS CROSSMEMBER FASTNING PROFILE	TATA spare parts
409006500206	CHASSIS CROSSMEMBER FASTNING PROFILE	TATA spare parts
409006500207	CHASSIS CROSSMEMBER FASTNING PROFILE	TATA spare parts
409006500208	CHASSIS CROSSMEMBER FASTNING PROFILE	TATA spare parts
409006500209	PROFILE	TATA spare parts
409006500210	PROFILE	TATA spare parts
409006700201	BASE LOWER GUSSET	TATA spare parts
409006700202	BASE LOWER CHANNEL 202	TATA spare parts
409006700203	BASE LOWER CHANNEL 203	TATA spare parts
409006700204	BASE LOWER CHANNEL 204	TATA spare parts
409006700205	BASE LOWER CHANNEL 205	TATA spare parts
409006700206	BASE LOWER CHANNEL 206	TATA spare parts
409006700207	AIR PIPING SUPPORT 207	TATA spare parts
409006700208	AIR PIPING SUPPORT 208	TATA spare parts
409006700209	BASE LOWER CHANNEL 209	TATA spare parts
409006700210	END PLATE FLOOR LONGITUDE	TATA spare parts
409006700212	PLATE 355	TATA spare parts
409006700304	SUPPORT PLATE-1	TATA spare parts
409006700305	SUPPORT PLATE-2	TATA spare parts
409006700307	SUPPORT PLATE 1170	TATA spare parts
409006700308	SUPPORT PLATE LN 1700	TATA spare parts
409006700309	SUPPORT PLATE LN 1120	TATA spare parts
409006700310	SUPPORT PLATE LN 765	TATA spare parts
409006700311	SUPPORT PLATE LN 280	TATA spare parts
409007700101	ROOF EXTRNAL PANELING PLATE 101	TATA spare parts
409007700201	ROOF EXTERNAL CURVE PANELING	TATA spare parts

409007700202	ALUMINIUM PROFILE	TATA spare parts
409007700203	AL PROFILE AT EXT JOINTS	TATA spare parts
409007700204	EXTERNAL ROOF CORNER AL PROFILE	TATA spare parts
409008100201	FINISH PROFILE BELOW DRIVER DOOR	TATA spare parts
409008200215	RH REAR STRETCH PANEL-7	TATA spare parts
409008200217	SQUARE WASHER 2.7THK	TATA spare parts
409008500201	RH REAR SKIRT PANELING_2555X450X0.95THK	TATA spare parts
409008700262	RH SKIRT PANELING_1	TATA spare parts
409008700263	RH SKIRT PANELING_2	TATA spare parts
409008700266	RH SKIRT PANELING_5	TATA spare parts
409008700267	RH SKIRT PANELING_6	TATA spare parts
409008700275	RH SKIRT PANELING_3	TATA spare parts
409008700276	RH SKIRT PANELING_4	TATA spare parts
409009000201	PANELING BETWEEN WINDOW ASSY.	TATA spare parts
409009000202	PANELING BETWEEN WINDOW ASSY.	TATA spare parts
409009000203	PANELING BETWEEN WINDOW ASSY.	TATA spare parts
409009000204	PANELING BETWEEN WINDOW ASSY.	TATA spare parts
409009000205	PANELING BETWEEN WINDOW ASSY.	TATA spare parts
409009000206	PANELING BETWEEN WINDOW ASSY.	TATA spare parts
409009000207	PANELING BETWEEN WINDOW ASSY.	TATA spare parts
409009000208	PANELING BETWEEN WINDOW ASSY.	TATA spare parts
409009000209	PANELING BETWEEN WINDOW ASSY	TATA spare parts
409009000217	PANELING BETWEEN WINDOW ASSY	TATA spare parts
409009000218	PANELING BETWEEN WINDOW ASSY.	TATA spare parts
409009000219	PANELING BETWEEN WINDOW ASSY	TATA spare parts
409009000220	PANELING BETWEEN WINDOW ASSY	TATA spare parts
409009000221	PANELING BETWEEN WINDOW ASSY	TATA spare parts
409009000222	PANELING BETWEEN WINDOW ASSY	TATA spare parts
409009000230	PASSENGER DOOR CANOPY ASSY	TATA spare parts
409009000232	PASSENGER DOOR(800)CANOPY ASSY	TATA spare parts
409009000233	PASSENGER DOOR(870) CANOPY ASSY	TATA spare parts
409009000234	PASSENGER DOOR(1210) CANOPY ASSY	TATA spare parts
409009000501	Z-SHAPE PLATE ASSY_103X1640	TATA spare parts
409009200206	LH STRETCH PANEL-5	TATA spare parts
409009300205	WINDOW PANELING DRIVER SIDE	TATA spare parts
409009300207	SKIRT EXTERNAL PANELING	TATA spare parts
409009300208	SIDE EXT. PANELING	TATA spare parts
409009300211	EXTERNAL PANELING	TATA spare parts
409009300212	SIDE EXT.PANELING	TATA spare parts
409009300213	SIDE EXT.PANELING	TATA spare parts
409009300215	EXTERNAL PANELING	TATA spare parts
409009400201	SKIRT EXTERNAL PANELING	TATA spare parts
409009400203	RH REAR SKIRT PANELING-PMPML-2	TATA spare parts
409009400223	SIDE EXT. PANELINH-1158 X 320 X 0.65	TATA spare parts
409009400224	EXT.PNLG.266 X 738 X 0.65	TATA spare parts
409009400230	GI PLATE 0.65MM THK	TATA spare parts
409009400232	SKIRT EXTERNAL PANELING	TATA spare parts

409009400233	SKIRT EXTERNAL PANELING	TATA spare parts
409009400257	PASSENGER DOOR CANOPY (ABS/PP)_920	TATA spare parts
409009500201	ALUMINIUM PROFILE	TATA spare parts
409009500202	WAIST RAIL OUTER	TATA spare parts
409009500203	ALUMINIUM PROFILE 203	TATA spare parts
409009500205	WAIST RAIL INNER	TATA spare parts
409009500206	ALUMINIUM PROFILE	TATA spare parts
409009500207	FR FACE MTG	TATA spare parts
409009500208	APERTURE EDGE BEADING	TATA spare parts
409009500219	COVER PLATE-414	TATA spare parts
409009500278	SKIRT EXTERNAL PANELING	TATA spare parts
409009500279	SKIRT EXTERNAL PANELING	TATA spare parts
409009500280	SKIRT EXTERNAL PANELING C-SECTION	TATA spare parts
409009600217	PANELING ABOVE EMERGENCY DOOR	TATA spare parts
409009600218	SIDE EXT.PANELING ABOVE WINDOW 05	TATA spare parts
409009600219	EXTERNAL PANELING ABOVE DRIVER DOOR	TATA spare parts
409009600225	GI_0.65 THK SHAPE-1_625	TATA spare parts
409009600227	SIDE EXT. PANELING ABOVE WINDOW	TATA spare parts
409009600228	EXTERNAL PANELING	TATA spare parts
409009600229	SIDE EXT.PANELING BETWEEN WINDOW	TATA spare parts
409009600230	SIDE EXT. PANELING ABOVE WINDOW	TATA spare parts
409009600231	SIDE EXT.PANELING BETWEEN WINDOW	TATA spare parts
409009600232	SKIRT PANELING	TATA spare parts
409009600233	SKIRT EXTERNAL PANELING	TATA spare parts
409009600277	DRIVER DOOR CANOPY	TATA spare parts
409009600278	XT.PNLG	TATA spare parts
409009600280	REAR SKIRT PANEL	TATA spare parts
409009600283	FRONT DRIVER PILLAR	TATA spare parts
409009600284	SIDE EXT.PANELING ABOVE WINDOW 05	TATA spare parts
409009600285	EXTERNAL PANELING	TATA spare parts
409009600286	SIDE EXT.PANELING ABOVE WINDOW 05	TATA spare parts
409009600287	SIDE EXT. PANELING ABOVE WINDOW	TATA spare parts
409009600289	SIDE SKIRT PANELING	TATA spare parts
409009600290	SIDE EXT. PANELLING	TATA spare parts
409009600291	IDE EXT. PANELLING	TATA spare parts
409009600292	SIDE EXT. PANELLING	TATA spare parts
409009600293	SIDE PANEL	TATA spare parts
409009600294	COVER PLATE	TATA spare parts
409009600296	SIDE SKIRT PANELING	TATA spare parts
409009600297	SIDE EXT. PANELLING	TATA spare parts
409009600298	SIDE SKIRT PANELING	TATA spare parts
409009600299	REAR SKIRT PANEL	TATA spare parts
409009600301	SIDE SKIRT PANEL_2310X485X0.95	TATA spare parts
409009600302	SIDE SKIRT PANEL_2145X485X0.95	TATA spare parts
409009610245	GI_0.65 THK SHAPE-1_965X60	TATA spare parts
409009610250	SKIRT EXTERNAL PANELING	TATA spare parts
409009610295	SIDE EXT.PANELING BETWEEN WINDOW	TATA spare parts

409009610296	SIDE EXT.PANELING BETWEEN WINDOWS-1	TATA spare parts
409009610327	EXT PANEL ABOVE-FRONT PASS DOOR	TATA spare parts
409009610328	EXT PNL ABVE MID PASSDOOR	TATA spare parts
409009610330	EX PANEL ABOVE DRIVER DOOR	TATA spare parts
409009610332	A- PILLAR PANEL	TATA spare parts
409009610333	A- PILLAR PANEL	TATA spare parts
409009610334	A- PILLAR PANEL	TATA spare parts
409009610335	A- PILLAR PANEL	TATA spare parts
409009610338	GI EXT L-PANEL 30X35X550	TATA spare parts
409009610342	GI PANEL 825X1160X0.95	TATA spare parts
409009610344	GI PANEL 825X2370X0.95	TATA spare parts
409009610345	GI PANEL 825X430X0.95	TATA spare parts
409009610346	A- PILLAR PANEL	TATA spare parts
409009610347	A- PILLAR PANEL	TATA spare parts
409009610349	EXT PANEL 850X50X0.65	TATA spare parts
409009610350	EXT PANEL 1065X60	TATA spare parts
409009610351	EXT PANEL 190X60X0.65	TATA spare parts
409009610352	EXT PANEL 610X60X0.65	TATA spare parts
409009610353	EXT PANEL 910X60X0.65	TATA spare parts
409009610354	SIDE EXT.PANELING	TATA spare parts
409009610359	SIDE EXT.PANELING BETWEEN WINDOWS-1	TATA spare parts
409009610360	SIDE EXT.PANELING BETWEEN WINDOW	TATA spare parts
409009610366	GI SHEET THK-0.65	TATA spare parts
409009610368	GI PLATE 0.65MM THK	TATA spare parts
409009610370	RH MIDDLE SKIRT PANELING	TATA spare parts
409009610371	RH FRONT SKIRT PANELING	TATA spare parts
409009610372	RH FRONT SKIRT PANELING	TATA spare parts
409009610373	SKIRT EXTERNAL PANELING TYPE12	TATA spare parts
409009610375	LH FRONT SKIRT PANELING_01	TATA spare parts
409009610376	LH FRONT SKIRT PANELING_02	TATA spare parts
409009610381	SKIRT EXTERNAL PANELING	TATA spare parts
409009610382	SIDE EXT PANEL	TATA spare parts
409009610383	SIDE EXT PANEL	TATA spare parts
409009610384	EXTERNAL PANEL 970X25X0.95	TATA spare parts
409009610385	SIDE EXT PANEL L-30X23X150	TATA spare parts
409009610386	SIDE EXT PANEL 1210X35X0.95	TATA spare parts
409009610387	PANEL ABOVE BRT DOOR 1210X120	TATA spare parts
409009610388	LH FRONT SKIRT PANELING	TATA spare parts
409009610410	LH FRONT SKIRT PANELING	TATA spare parts
409009610411	SKIRT RAIL C-SECTION	TATA spare parts
409009610412	SIDE EXT.PANELING BETWEEN WINDOWS-1	TATA spare parts
409009610414	SIDE EXT.PANELING 1108X207X0.65	TATA spare parts
409009610415	SIDE EXT. PANELINH-1108 X 320 X 0.65	TATA spare parts
409009610417	EXT PANEL 850X90X0.65	TATA spare parts
409009610418	SIDE EXT.PANELING BETWEEN WINDOWS-1	TATA spare parts
409009610419	EXTERNAL PANELING	TATA spare parts
409009610421	EXTERNAL PANELING	TATA spare parts

409009610425	LH FRONT SKIRT PANELING	TATA spare parts
409009610426	LH JK DOOR FRONT SKIRT PANELING	TATA spare parts
409009610427	LH JK DOOR REAR SKIRT PANELING	TATA spare parts
409009610428	LH REAR SKIRT PANELING	TATA spare parts
409009610429	SKIRT EXTERNAL PANELING	TATA spare parts
409009610449	G.I.SHEET_270X85X0.95_EXTERNAL PANEL.	TATA spare parts
409009610450	G.I.SHEET_825X188X0.95_EXTERNAL PANEL.	TATA spare parts
409009610525	G.I.SHEET(1333X172X0.65)_SIDE EXT PANEL	TATA spare parts
409009610526	SIDE EXT PANEL 825X143X0.65	TATA spare parts
409009610528	GI SKIRT PANEL 2635X505X0.95	TATA spare parts
409009610532	SKIRT EXTERNAL PANELING	TATA spare parts
409009610533	SKIRT EXTERNAL PANELING	TATA spare parts
409009610535	SIDE EXT.PANELING	TATA spare parts
409009610536	EXTERNAL PANELING	TATA spare parts
409009610537	SIDE EXT.PANELING BETWEEN WINDOWS-1	TATA spare parts
409009610539	GI EXT PANEL	TATA spare parts
409009610540	GI-SKIRT EXT PANEL	TATA spare parts
409009610541	SKIRT EXTERNAL PANELING	TATA spare parts
409009610542	GI-SKIRT EXT PANEL	TATA spare parts
409009610543	GI-SKIRT EXT PANEL	TATA spare parts
409009610545	SIDE EXT PANEL	TATA spare parts
409009610546	SKIRT EXTERNAL PANELING	TATA spare parts
409009610547	G.I EXT PANEL	TATA spare parts
409009610548	WINDOW PANEL 1350X120X0.65	TATA spare parts
409009610551	GI PLATE 0.65MM THK 60X830	TATA spare parts
409009610552	GI PLATE 0.65MM THK 60X995	TATA spare parts
409009610553	GI PLATE 0.65MM THK 60X640	TATA spare parts
409009610554	GI EXT PANEL	TATA spare parts
409009610557	GI PANEL	TATA spare parts
409009610558	SKIRT PANEL BELOW AIR FILTER FLAP	TATA spare parts
409009610580	GI PLATE 870X227X0.65MM THK	TATA spare parts
409009610581	GI PLATE 1350X390X0.65MM THK	TATA spare parts
409009610582	GI PLATE 920X370X0.65MM THK	TATA spare parts
409009610584	RH REAR SKIRT PANELIN	TATA spare parts
409009610587	LH FRONT SKIRT PANELING	TATA spare parts
409009610589	SIDE EXTERNAL PANEL	TATA spare parts
409009610590	DOOR CANOPY 800	TATA spare parts
409009610591	DOOR CANOPY	TATA spare parts
409009610592	SIDE EXTERNAL PANEL	TATA spare parts
409009610593	RH MIDDLE SKIRT PANELING	TATA spare parts
409009610594	RH FRONT SKIRT PANELING	TATA spare parts
409009610596	SIDE EXTERNAL PANEL	TATA spare parts
409009610597	SIDE EXTERNAL PANEL	TATA spare parts
409009610598	LH REAR SKIRT PANELING	TATA spare parts
409009610604	EXT.PNLG.256 X 738 X 0.65	TATA spare parts
409009610605	SIDE EXT PANEL 560X64X0.95	TATA spare parts
409009610612	REAR PASSENGER DOOR CANOPY	TATA spare parts

409009610625	SIDE EXT.PANELING BETWEEN WINDOW	TATA spare parts
409009610626	SIDE EXT.PANELING ABOVE WINDOW	TATA spare parts
409009610627	SKIRT RAIL BELOW DRIVER DOOR	TATA spare parts
409009610628	EXTERNAL PANELING RH_BELOW PEEP WINDOW	TATA spare parts
409009610637	GI SHEET 0.65MM THK_WINDOW PILLAR	TATA spare parts
409009610640	GI PLATE_570X470_0.95THK	TATA spare parts
409009610641	SIDE EXT PANEL BET WINDOW-1	TATA spare parts
409009610647	EXTERNAL PANEL ABOVE WINDOW	TATA spare parts
409009610648	SIDE EXTERNAL PANEL ABOVE DRIVER DOOR	TATA spare parts
409009610661	SIDE EXT PANEL	TATA spare parts
409009610662	EXTERNAL PANEL BEHIND DRIVER DOOR	TATA spare parts
409009610663	EXTERNAL PANELING 1614X308X0.65	TATA spare parts
409009610664	GI_SKIRT EXTERNAL PANELING	TATA spare parts
409009610665	GI-SKIRT EXT PANEL	TATA spare parts
409009610666	SKIRT EXTERNAL PANELING	TATA spare parts
409009610668	GI SKIRT PANEL 2060X487X0.95	TATA spare parts
409009610669	GI SKIRT PANEL 2445X505X0.95	TATA spare parts
409009610670	GI_SKIRT EXTERNAL PANELING	TATA spare parts
409009610671	GI_SKIRT EXTERNAL PANELING	TATA spare parts
409009610672	GI_SKIRT EXTERNAL PANELING	TATA spare parts
409009610675	BOTTOM SIDE EXTERNAL PANELING	TATA spare parts
409009700201	SKIRT PANEL (AHEAD OF FRONT AXLE)	TATA spare parts
409009700202	SKIRT PANEL (BEHIND FRONT AXLE)	TATA spare parts
409009700203	SKIRT EXTERNAL PANELING	TATA spare parts
409009700204	SKIRT EXTERNAL PANELING	TATA spare parts
409009700205	SKIRT EXTERNAL PANELING	TATA spare parts
409009700206	SKIRT EXTERNAL PANELING	TATA spare parts
409009700207	SKIRT EXTERNAL PANELING	TATA spare parts
409009700208	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009700209	EXTERNAL PANELING ( STRETCH PANEL)	TATA spare parts
409009700210	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009700211	PANELING OVER THE DOOR 211	TATA spare parts
409009700212	PANELING OVER THE DOOR 212	TATA spare parts
409009700213	DOOR MIRROR	TATA spare parts
409009700214	SIDEFAME PANELING PLATE	TATA spare parts
409009700215	EXTERNAL PANELING (STRETCH PANEL)	TATA spare parts
409009700216	SKIRT EXTERNAL PANELING	TATA spare parts
409009700217	SIDE EXTERNAL PANELING(STRETCG PANEL)	TATA spare parts
409009700218	SKIRT EXTERNAL PANELING	TATA spare parts
409009700219	SKIRT EXTERNAL PANELING	TATA spare parts
409009700220	SKIRT EXTERNAL PANELING	TATA spare parts
409009700221	PANELING OVER THE DOOR 221	TATA spare parts
409009700222	SKIRT EXTERNAL PANELING	TATA spare parts
409009700223	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009700224	PANELING OVER THE DOOR 224	TATA spare parts
409009700225	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009700226	UPPER SIDE EXTERNAL PANELING 226	TATA spare parts

409009700227	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009700228	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009700229	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009700230	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009700231	SKIRT EXTERNAL PANELING	TATA spare parts
409009700232	UPPER SIDE EXTERNAL PANELING 232	TATA spare parts
409009700233	SKIRT EXTERNAL PANELING	TATA spare parts
409009700234	SKIRT EXTERNAL PANELING	TATA spare parts
409009700235	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009700236	UPPER SIDE EXTERNAL PANELING 236	TATA spare parts
409009700237	UPPER SIDE EXTERNAL PANELING 237	TATA spare parts
409009700238	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009700239	FRONT PASSENGER DOOR APERTURE COVER FRO	TATA spare parts
409009700246	SIDE FRAME REVETTING PLATE	TATA spare parts
409009700247	SIDE FRAME REVETTING PLATE	TATA spare parts
409009700248	1.00 ALUMIUM PLATE	TATA spare parts
409009700249	1.00 ALUMIUM PLATE	TATA spare parts
409009700250	1.00 ALUMIUM PLATE	TATA spare parts
409009700251	1.00 ALUMIUM PLATE	TATA spare parts
409009700252	SIDE EXTERNAL STRETCH PANELING(L.H. REAR	TATA spare parts
409009700253	SIDE EXTERNAL STRETCH PANELING(R.H. FRON	TATA spare parts
409009700254	SIDE EXTERNAL STRETCH PANELING(R.H. REAR	TATA spare parts
409009700256	1.00 ALUMINIUM PLATES	TATA spare parts
409009700257	1.00 ALUMINIUM PLATES	TATA spare parts
409009700258	1.00 ALUMINIUM PLATES	TATA spare parts
409009700259	1.00 ALUMINIUM PLATES	TATA spare parts
409009700260	1.00 ALUMINIUM PLATES	TATA spare parts
409009700261	1.00 ALUMINIUM PLATES	TATA spare parts
409009700262	1.00 ALUMINIUM PLATES	TATA spare parts
409009700263	1.00 ALUMINIUM PLATES	TATA spare parts
409009700321	SIDE FRAME REVETMENT PLATE	TATA spare parts
409009700322	SIDE FRAME REVETMENT PLATE	TATA spare parts
409009700393	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009700395	AL SKIRT EXT PANEL	TATA spare parts
409009700396	AL SKIRT EXT PANEL	TATA spare parts
409009700398	AL SKIRT PANEL	TATA spare parts
409009700399	AL SKIRT EXT PANEL	TATA spare parts
409009700401	AL-SKIRT EXT PANEL	TATA spare parts
409009700402	AL-SKIRT EXT PANEL	TATA spare parts
409009700403	SIDE EXT PANEL 473X201X1.5	TATA spare parts
409009700404	SIDE EXT PANEL 349X150X1.5	TATA spare parts
409009700405	SIDE EXT PANEL 349X113X1.5	TATA spare parts
409009710222	SKIRT EXTERNAL PANELING	TATA spare parts
409009710223	SIDE FRAME PANELLING PLATE	TATA spare parts
409009710224	SKIRT EXTERNAL PANELING	TATA spare parts
409009710225	SKIRT EXTERNAL PANELING	TATA spare parts
409009710226	SKIRT EXTERNAL PANELING	TATA spare parts

409009710227	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009710228	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009710229	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009710238	SKIRT EXTERNAL PANELLING	TATA spare parts
409009710239	SKIRT EXTERNAL PANELING	TATA spare parts
409009710240	SKIRT EXTERNAL PANELING	TATA spare parts
409009710242	SKIRT EXTERNAL PANELING	TATA spare parts
409009710243	SKIRT EXTERNAL PANELING	TATA spare parts
409009710249	IDE EXTERNAL PANELLING	TATA spare parts
409009710250	SKIRT EXTERNAL PANELING	TATA spare parts
409009710251	SKIRT EXTERNAL PANELING	TATA spare parts
409009710252	PANELLING BETWEEN WINDOW	TATA spare parts
409009710253	PANELING BETWEEN WINDOW	TATA spare parts
409009710254	PANELLING BETWEEN WINDOW	TATA spare parts
409009710255	PANELLING BETWEEN WINDOW	TATA spare parts
409009710256	PANELLING BETWEEN WINDOW	TATA spare parts
409009710257	PANELLING BETWEEN WINDOW	TATA spare parts
409009710258	WINDOW PANELLING DRIVER SIDE	TATA spare parts
409009710261	UPPER SIDE PANELING	TATA spare parts
409009710262	UPPER SIDE PANELING	TATA spare parts
409009710263	SKIRT EXTERNAL PANELING LH	TATA spare parts
409009710264	SKIRT EXTERNAL PANELING RH	TATA spare parts
409009710265	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009710266	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009710267	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009710268	UPPER SIDE EXTERNAL PANELING	TATA spare parts
409009710279	DRIVER DOOR TOP PANLEING LHD BUS	TATA spare parts
409009710281	WINDOW PANELING REAR SIDE	TATA spare parts
409009710283	SKIRT EXTERNAL PANELING	TATA spare parts
409009710286	SKIRT EXTERNAL PANELING	TATA spare parts
409009710288	DOOR EXTERNAL PANELING	TATA spare parts
409009710289	PANELING OVER THE DOOR	TATA spare parts
409009710291	DOOR APERTURE	TATA spare parts
409009710292	DOOR APERTURE	TATA spare parts
409009710294	SKIRT EXTERNAL PANELING	TATA spare parts
409009710296	SKIRT EXTERNAL PANELING	TATA spare parts
409009710298	SKIRT EXTERNAL PANELING NEAR DRIVER DOOR	TATA spare parts
409009710299	SKIRT EXTERNAL PANELING-PMPML2	TATA spare parts
409009710303	AL SKITR PANEL C-PROFILE	TATA spare parts
409009710304	AL SKIRT EXT PANEL	TATA spare parts
409009710305	AL SKIRT EXT PANEL	TATA spare parts
409009710306	AL SKIRT EXT PANEL-AJL AUTO TRANS	TATA spare parts
409009710307	AL SKIRT EXT PANEL - AUTO TRANS	TATA spare parts
409009710308	L SKIRT EXT PANEL	TATA spare parts
409009710309	AL SKIRT PANEL C-PROFILE_30X45X16_735	TATA spare parts
409009710310	AL SKIRT PANEL C-PROFILE	TATA spare parts
409009710312	AL SKIRT PANEL L-PROFILE_35X15X735	TATA spare parts



409009720215	SKIRT EXTERNAL PANELING	TATA spare parts
409009720216	SKIRT EXTERNAL PANELING	TATA spare parts
409009720217	SKIRT EXTERNAL PANELING	TATA spare parts
409009720218	SKIRT EXTERNAL PANELING	TATA spare parts
409009720219	SKIRT EXTERNAL PANELING	TATA spare parts
409009720220	SKIRT EXTERNAL PANELING	TATA spare parts
409009720221	SKIRT EXTERNAL PANELING	TATA spare parts
409009720222	SKIRT EXTERNAL PANELING	TATA spare parts
409009720225	PANELING OVER THE DOOR	TATA spare parts
409009720226	BOTTOM SIDE EXTERNAL PANELING	TATA spare parts
409009720227	SKIRT EXTERNAL PANELING_1350_DOOR	TATA spare parts
409009720228	UPPER SIDE EXTERNALPANELING	TATA spare parts
409009720237	PANELING BETWEEN WINDOW	TATA spare parts
409009720238	PANELING BETWEEN WINDOW	TATA spare parts
409009720239	PANELING BETWEEN WINDOW	TATA spare parts
409009720240	PANELING BETWEEN WINDOW	TATA spare parts
409009720241	PANELING BETWEEN WINDOW	TATA spare parts
409009720242	PANELING BETWEEN WINDOW	TATA spare parts
409009720244	DRIVER DOOR CANOPY 970	TATA spare parts
409009720247	SKIRT EXTERNAL PANEL BELOW DRIVER DOOR	TATA spare parts
409009720248	ALUMINIUM SHEET	TATA spare parts
409009720249	SKIRT EXTERNAL PANELING	TATA spare parts
409009720250	FRONT DOOR EXTERNAL PANELING	TATA spare parts
409009720251	SIDE EXTERNAL PANELING	TATA spare parts
409009720252	PASSENGER DOOR TOP PANELING	TATA spare parts
409009720253	SKIRT EXTERNAL PANELING	TATA spare parts
409009720254	SKIRT EXTERNAL PANELING	TATA spare parts
409009720264	SIDE EXTERNAL PANELING	TATA spare parts
409009720280	LH SKIRT PANELING_1	TATA spare parts
409009720281	LH SKIRT PANELING_2	TATA spare parts
409009720282	LH SKIRT PANELING_3	TATA spare parts
409009720283	LH SKIRT PANELING_4	TATA spare parts
409009720284	LH SKIRT PANELING_5	TATA spare parts
409009720285	LH SKIRT PANELING_6	TATA spare parts
409009720286	LH SKIRT PANELING_7	TATA spare parts
409009720287	LH SKIRT PANELING_8	TATA spare parts
409009720288	LH SKIRT PANELING_9	TATA spare parts
409009800201	END COVER	TATA spare parts
409010000201	TARMAC BUS PNEUMATIC DOOR ASSY	TATA spare parts
409010000205	FRP FRONT INNER SW ASSY.	TATA spare parts
409010000207	FRP FRONT INNER ASSEMBLY RHD & LHD	TATA spare parts
409010100201	FLOOR FINISHING COVERING 201	TATA spare parts
409010100202	CELLULAR PHONE CHARGER COVERING 202	TATA spare parts
409010100203	DOOR LIGHT COVERING	TATA spare parts
409010100205	DRIVER COLUMN FINISHING	TATA spare parts
409010100206	DRIVER COLUMN FINISHING 206	TATA spare parts
409010100207	DOOR UPPER CORNER COVERING	TATA spare parts

409010100208	EMERGENCY DOOR LATCH COVERING 208	TATA spare parts
409010100209	UPPER FRONT MAINTENANCE COVER	TATA spare parts
409010100210	PANEL FINISHING	TATA spare parts
409010100211	DRIVER DOOR LATCH COVERING	TATA spare parts
409010100212	PANEL FINISHING	TATA spare parts
409010100214	PISTON BOX FINISHING	TATA spare parts
409010100215	WINDSHIELD INTERNAL FINISH	TATA spare parts
409010100216	FRONT UPPER COVERING	TATA spare parts
409010100217	FRONT UPPER COVERING	TATA spare parts
409010100218	AIR INTAKE FINISHING	TATA spare parts
409010100219	REAR INTERNAL REVETMENT	TATA spare parts
409010100220	REAR INTERNAL REVETMENT	TATA spare parts
409010100221	REAR INTERNAL REVETMENT	TATA spare parts
409010100222	PISTON BOX FINISHING COVER	TATA spare parts
409010100223	FRONT UPPER COVERING	TATA spare parts
409010100225	DOOR BOLT COVERING	TATA spare parts
409010100226	DRIVER DOOR INTERNAL FINISHING	TATA spare parts
409010100227	EMERGENCY DOOR INTERNAL FINISHING	TATA spare parts
409010100228	EMERGENCY ARM COVERING	TATA spare parts
409010100229	DOORS HINGE COVERING	TATA spare parts
409010100230	HINGE COMPLEMENT COVERING	TATA spare parts
409010100231	MUX 2B SUPPORT PLATE COVERING 0231	TATA spare parts
409010100232	AIR INTAKE COVER RH SIDE	TATA spare parts
409010100233	REAR INTERNAL REVETMENT RH SIDE	TATA spare parts
409010100236	FRONT UPPER COVERING	TATA spare parts
409010100237	FRONT UPPER COVERING LH SIDE	TATA spare parts
409010100242	COVER FOR VEH TRACKING CONTROLER(AIS140)	TATA spare parts
409010200201	PNEUMATIC DOOR BOX FOR AIR CURTAIN	TATA spare parts
409010200205	FRONT INNER ROOF MARKER LAMP COVER	TATA spare parts
409010400301	FRONT INNER DESTINATION HARNESS COVER	TATA spare parts
409010700201	HINGED DOOR LIMITER SUPPORT	TATA spare parts
409010700301	HINGED DOOR LIMITER SUPPORT	TATA spare parts
409010900201	SIDE FLAPS LIMITER BELT	TATA spare parts
409010990201	QUICK ACTING LATCH STANDARD	TATA spare parts
409011100206	REAR FACE LOWER REINFORCEMENT	TATA spare parts
409011100207	REAR FACE LOWER REINFORCEMENT LH	TATA spare parts
409011100214	INVERTER COVER ABS	TATA spare parts
409011200207	ABS AC HOSE COVER 1	TATA spare parts
409011200208	ABS AC HOSE COVER 2	TATA spare parts
409012100223	SIDE INTERNAL PANELING	TATA spare parts
409012100224	SIDE INTERNAL PANELING	TATA spare parts
409012100225	SIDE INTERNAL PANELING	TATA spare parts
409012100228	PLASTIC SHEET	TATA spare parts
409012300201	AL PROFILE	TATA spare parts
409012500301	PLATE 60X24X2 THK.	TATA spare parts
409012600301	VELCRO ASSY (MALE & FEMALE)	TATA spare parts
409012800201	SOLID RUBBER PROFILES FOR ABS SPE PROFIL	TATA spare parts

409012800301	SOLID RUBBER PROFILE	TATA spare parts
409014500201	AL. PROFILE	TATA spare parts
409014500202	AL. PROFILE	TATA spare parts
409014500203	AL. PROFILE	TATA spare parts
409014700202	ABS LIGHT GREY 1600 X 1080 X 4 MM IS7078	TATA spare parts
409015000202	INSPECTION COVER ASSEMBLY	TATA spare parts
409015000203	INSPECTION COVER ASSEMBLY	TATA spare parts
409015000204	INSPECTION COVER ASSEMBLY	TATA spare parts
409015000206	INSPECTION COVER ASSEMBLY	TATA spare parts
409015000207	RIVER INSPECTION COVER ASSEMBLY	TATA spare parts
409015000218	INSPECTION COVER ASSEMBLY	TATA spare parts
409015010302	FRONT INSPECTION SHEET ASSY	TATA spare parts
409015100312	INSPECTION COVER PLATE_GEAR BOX	TATA spare parts
409015100313	INSPECTION COVER SHEET_1.95THK	TATA spare parts
409015100318	UREA TANK COVER GI SHEET 580X270	TATA spare parts
409015200307	BOTTOM PLATE FOR INSPECTION LID	TATA spare parts
409015300301	AL BEADING	TATA spare parts
409015300302	INSPECTION COVER SEALING PROFILE	TATA spare parts
409015300304	INSPECTION COVER SEALING PROFILE	TATA spare parts
409015300309	INSPECTION COVER SEALING PROFILE	TATA spare parts
409015300312	INSPECTION COVER SEALING PROFILE	TATA spare parts
409015300314	INSPECTION COVER SEALING PROFILE	TATA spare parts
409015300318	INSPECTION COVER CLOSING PLATE	TATA spare parts
409015300319	INSPECTION COVER SEALING PROFILE	TATA spare parts
409015300320	INSPECTION COVER CLOSING PLATE	TATA spare parts
409015300321	INSPECTION COVER SEALING PROFILE	TATA spare parts
409015300325	INSPECTION COVER CLOSING PLATE	TATA spare parts
409015300326	INSPECTION COVER SEALING PROFILE	TATA spare parts
409015400301	ISO 40 ART CUSTIC MASTIQUE BARRIER	TATA spare parts
409015500202	MAINTENANCE COVER PLATE	TATA spare parts
409015500203	MAINTENANCE COVER PLATE	TATA spare parts
409015500305	BOTTOM PLATE FOR INSPECTION LID	TATA spare parts
409015800318	HIGH CARPET RESIST	TATA spare parts
409015990202	RUBBER FOR CUTOUT SEALENT	TATA spare parts
409015990203	RUBBER SEALING	TATA spare parts
409016000161	WIN LH 1190X1078 TF BS 550 CV CLR 5MMTHK	TATA spare parts
409016000168	PEEP WINDOW_605X262 MM	TATA spare parts
409016000201	URBAN WINDOW	TATA spare parts
409016000202	URBAN WINDOW	TATA spare parts
409016000203	URBAN WINDOW	TATA spare parts
409016000204	URBAN WINDOW	TATA spare parts
409016000205	URBAN WINDOW	TATA spare parts
409016000206	DRIVER WINDOW ASSEMBLY	TATA spare parts
409016000207	URBAN WINDOW	TATA spare parts
409016000208	DOOR GLASS ASSEMBLY	TATA spare parts
409016000209	URBAN WINDOW	TATA spare parts
409016000210	URBAN WINDOW	TATA spare parts

409016000211	WINDOW ASSY(1276X1000)	TATA spare parts
409016000212	SERVICE DOOR GLASS ASSEMBLY	TATA spare parts
409016000226	LEFT SIDE FRONT WINDOW ASSY 1(1276X1175)	TATA spare parts
409016000227	LEFT SIDE FRONT WINDOW ASSY 2(1376X1175)	TATA spare parts
409016000228	LEFT SIDE REAR WINDOW ASSY 4(710X1000)	TATA spare parts
409016000229	LEFT SIDE REAR WINDOW ASSY 5(1376X1000)	TATA spare parts
409016000230	RIGHT SIDE FRONT WINDOW ASSY1(1476X1175)	TATA spare parts
409016000231	RIGHT SIDE REAR WINDOW ASSY11(1155X1000)	TATA spare parts
409016000232	EMER DOOR WINDOW GLASS ASSY (548X959)	TATA spare parts
409016000242	WINDOW ASSY (1376X1175)	TATA spare parts
409016000243	WINDOW ASSY (1376X1000)	TATA spare parts
409016000244	TOP WINDOW ASSY. (1276 X 371 )	TATA spare parts
409016000245	TOP WINDOW ASSY. (1476 X 371 )	TATA spare parts
409016000246	TOP WINDOW ASSY. ( 730X 371 ÷)	TATA spare parts
409016000247	TOP WINDOW ASSY. (1476 X 371 )	TATA spare parts
409016000248	TOP WINDOW ASSY. (1176 X 371 )	TATA spare parts
409016000251	WINDOW ASSY. (1276 X 1175 )L.H.	TATA spare parts
409016000252	WINDOW ASSY. (1476 X 1175 )L.H.	TATA spare parts
409016000253	WINDOW ASSY. ( 738 X 1000 )L.H.	TATA spare parts
409016000254	WINDOW ASSY. (1476 X 1000 )L.H.	TATA spare parts
409016000255	WINDOW ASSY. (1476 X 1175 )R.H.	TATA spare parts
409016000256	WINDOW ASSY. (1176 X 1000 )R.H.	TATA spare parts
409016000257	WINDOW ASSY. (1476 X 1000 )R.H.	TATA spare parts
409016000265	LEFT SIDE FRONT WINDOW ASSY(1276X1175)	TATA spare parts
409016000266	LEFT SIDE FRONT WINDOW ASSY(1376X1175)	TATA spare parts
409016000267	LEFT SIDE REAR WINDOW ASSY(710X1000)	TATA spare parts
409016000268	LEFT SIDE REAR WINDOW ASSY(1376X1000)	TATA spare parts
409016000269	RIGHT SIDE FRONT WINDOW ASSY(1476X1175)	TATA spare parts
409016000270	RIGHT SIDE FRONT WINDOW ASSY(1376X1175)	TATA spare parts
409016000271	LEFT SIDE FRONT WINDOW ASSY(1476X1175)	TATA spare parts
409016000272	LEFT SIDE LAST WINDOW ASSY(1276X1000)	TATA spare parts
409016000273	DRIVER WINDOW ASSY(752.5X1092)	TATA spare parts
409016000274	EMER. DOOR WINDOW GLASS ASSY(548X959)	TATA spare parts
409016000275	RIGHT SIDE REAR WINDOW ASSY(1155X1000)	TATA spare parts
409016000276	RIGHT SIDE REAR WINDOW ASSY(1376X1000)	TATA spare parts
409016000277	LH SIDE FRONT WINDOW(1500X1198)	TATA spare parts
409016000278	LH SIDE FRONT WINDOW(1300X1198)	TATA spare parts
409016000279	LH SIDE REAR WINDOW(755X1024)	TATA spare parts
409016000280	LH SIDE REAR WINDOW(1500X1024)	TATA spare parts
409016000281	LH SIDE REAR LAST WINDOW	TATA spare parts
409016000282	RH SIDE REAR LAST WINDOW	TATA spare parts
409016000284	RH SIDE FRONT WINDOW(1500X1198)	TATA spare parts
409016000285	RH SIDE REAR WINDOW(755X1024)	TATA spare parts
409016000286	RH SIDE REAR WINDOW(1500X1024)	TATA spare parts
409016000288	RH SIDE FRONT WINDOW TOP FIX (1500X1198)	TATA spare parts
409016000289	WINDOW RH 1276X1056_1/3TS&2/3BS_CLEAR	TATA spare parts
409016000290	WINDOW RH 1476X1056_1/3TS&2/3BS_CLEAR	TATA spare parts

409016000291	EME DOOR WINDOW_RHD_706X789_SLI_CLEAR	TATA spare parts
409016000292	WINDOW RH 716X1056_1/3TS&2/3BS_CLEAR	TATA spare parts
409016000293	WINDOW LH 716X1056_1/3TS&2/3BS_CLEAR	TATA spare parts
409016000294	WINDOW LH 1146X1056_1/3TS&2/3BS_CLEAR	TATA spare parts
409016000295	WINDOW LH 1476X1056_1/3TS&2/3BS_CLEAR	TATA spare parts
409016000301	WINDOW LOCK ON FRONT SWINGING GLASS	TATA spare parts
409016000331	OPENABLE FRAME WITH GLASS	TATA spare parts
409016000345	OPENABLE FRAME WITH GLASS	TATA spare parts
409016000360	DRIVER WINDOW ASSEMBLY	TATA spare parts
409016000363	WINDOW LH 336X1056_RUBBER MOUNT_DPS	TATA spare parts
409016000364	SCOOP WINDOW RH 280X636_SERVICABLE_CLEA	TATA spare parts
409016000365	DRI DOR WIN RH 610X738_SLIDNG_SRV CABL_CL	TATA spare parts
409016000366	WIN RH 1095X790_SLIDNG_SERVCEABLE_CL	TATA spare parts
409016000367	WIN RH 1195X790_SLIDNG_SERVICABLE_CL	TATA spare parts
409016000371	DRIVER WINDOW_RHD_796X789_SLI&OPEN_CLE	TATA spare parts
409016000372	WINDOW LH 860X1056_1/3TS&2/3BS_CLEAR	TATA spare parts
409016000373	WINDOW LH FIX 352X798_RUBBER MOUNT	TATA spare parts
409016000374	PEEP WINDOW 370X475_FIXED_CLEAR	TATA spare parts
409016000375	INDOW RH (PEEP)_313X402_SLIDING	TATA spare parts
409016000376	DRIVER WINDOW_RHD_806X789_SLID&OPEN_CL	TATA spare parts
409016000377	WINDOW RH_1276X1056_1/3TS&2/3BF_TINT 50	TATA spare parts
409016000378	WINDOW RH_1476X1056_1/3TS&2/3BF_TINT 50	TATA spare parts
409016000379	WINDOW RH_1051X1056_1/3TS&2/3BF_TINT 50	TATA spare parts
409016000380	WINDOW LH_1051X1056_1/3TS&2/3BF_TINT 50	TATA spare parts
409016000381	WINDOW LH_1476X1056_1/3TS&2/3BF_TINT 50	TATA spare parts
409016000382	WINDOW LH_1376X1056_1/3TS&2/3BF_TINT 50	TATA spare parts
409016000383	WINDOW_LH_1476X1056_1/3TF&2/3BS_CLEAR C	TATA spare parts
409016000399	WINDOW RH 1476X1056 1/3TF&2/3BS CLEAR GL	TATA spare parts
409016000402	WINDOW LOCKS	TATA spare parts
409016000417	WIN RH 1276X1056_1/3TF_50%GT&2/3BS_30%G	TATA spare parts
409016000418	WIN RH 1476X1056_1/3TF_50%GT&2/3BS_30%G	TATA spare parts
409016000419	WIN RH 1476X1056_1/3TF_50%GT&2/3BS_30%G	TATA spare parts
409016000420	WIN LH 856X1056_1/3TF_50%GT&2/3BS_30%GT	TATA spare parts
409016000421	WIN LH 666X1056_1/3TF_50%GT&2/3BS_30%GT	TATA spare parts
409016000422	WIN LH 871X1056_1/3TF_50%GT&2/3BS_30%GT	TATA spare parts
409016000423	WIN FIXED 282X796_RUB MTG_CLEAR	TATA spare parts
409016000424	WIN FIXED 282X692_RUB MTG_CLEAR	TATA spare parts
409016000440	FIXED WINDOW 345X790 CLEAR	TATA spare parts
409016000447	WINDOW ASSY_EPDM FIX GLASS_1276X1056	TATA spare parts
409016000448	WINDOW ASSY_EPDM FIX GLASS_1476X1056	TATA spare parts
409016000464	WIN_LH_1400X1078_TF	TATA spare parts
409016000491	WIN RH 1300X1078 TF BS 550 CV CLR 5MMTHK	TATA spare parts
409016000492	WIN_RH_1500X1078_TF BS_550 CV_CLR_5MMTH	TATA spare parts
409016000493	WIN RH 950X1078 TF BS 550 CV CLR 5MMTHK	TATA spare parts
409016000494	WIN RH 794X1078 TF BS 550 CV CLR 5MMTHK	TATA spare parts
409016000495	WIN RH 1190X1078 TF BS 550 CV CLR 5MMTHK	TATA spare parts
409016000496	WIN LH 940X1078 TF BS 550 CV CLR 5MMTHK	TATA spare parts

409016000497	WIN LH 1500X1078 TF BS 550 CV CLR 5MMTHK	TATA spare parts
409016000503	FIX AL PROFILE WINDOW CLR 335X680 5MMTHK	TATA spare parts
409016000505	WINDOW LH_222X820_FIXED_CLEAR	TATA spare parts
409016000519	WINDOW LH 1195X790	TATA spare parts
409016000520	WINDOW LH 915X790	TATA spare parts
409016000532	RH WIN T/S B/S CL GL RM(1456X1175)	TATA spare parts
409016000533	LH WIN T1/3F B2/3S CL GL RM(1276X1175)	TATA spare parts
409016000536	WINDOW RH_1476X1056_1/3TF&2/3BS_TINT 50	TATA spare parts
409016000539	WINDOW LH_1476X1056_1/3TF&2/3BS_TINT 50	TATA spare parts
409016000569	WINDOW_RH_1047X1056_1/3TF&2/3BS_50PERC	TATA spare parts
409016000570	WINDOW_RH_911X1056_1/3TF&2/3BS_50PERC	TATA spare parts
409016000571	WINDOW_RH_646X1056_1/3TF&2/3BS_50PERC	TATA spare parts
409016000572	WINDOW_LH_646X1056_1/3TF&2/3BS_50PERC	TATA spare parts
409016000573	WINDOW_LH_451X1056_FIXED TYPE_50PERCGT	TATA spare parts
409016000576	EME DOOR WINDOW_RHD_706X789_SLI_CL_5M	TATA spare parts
409016000593	VERTICAL SLIDING WINDOW	TATA spare parts
409016000596	WIN RH 1476X1056 100MMTS & BF CLEAR	TATA spare parts
409016000605	WINDOW RH 876X1056 1/3TS&2/3BS CLEAR	TATA spare parts
409016000606	RH SIDE FRONT WINDOW(1260X1198)	TATA spare parts
409016000612	GLASS 1226X1056 EPDM TYPE FIX WINDOW	TATA spare parts
409016000613	GLASS 1476X1056 EPDM TYPE FIX WINDOW	TATA spare parts
409016000614	GLASS 588X804 EPDM TYPE FIX WINDOW	TATA spare parts
409016000615	GLASS 776X1056 EPDM TYPE FIX WINDOW	TATA spare parts
409016000616	RUBBER 776X1056 EPDM TYPE FIX WINDOW	TATA spare parts
409016000617	GLASS 1026X1056 EPDM TYPE FIX WINDOW	TATA spare parts
409016000618	RUBBER 1026X1056 EPDM TYPE FIX WINDOW	TATA spare parts
409016000619	WINDOW RH 320X826 FULL FIXED CLEAR GL	TATA spare parts
409016000620	WINDOW RH 1001X1056 1/3TF&2/3BS CLEAR GL	TATA spare parts
409016000621	WINDOW RH 1426X1056 1/3TF&2/3BS CLEAR GL	TATA spare parts
409016000622	WIN RH 666X1056 1/3TF&2/3BS CLEAR	TATA spare parts
409016000623	WIN LH 1196X1056 1/3TF&2/3BS CLR COD	TATA spare parts
409016000624	WINDOW LH 981X1056 1/3TF&2/3BS CLEAR GL	TATA spare parts
409016000625	WINDOW LH FIX 336X1056 RUBBER MOUNT CG	TATA spare parts
409016000641	WINDOW LH_1326X1056_1/3TF&2/3BS_TINT 50	TATA spare parts
409016000692	WINDOW IDEALE 1295 BS6	TATA spare parts
409016000717	WINDOW RH 1431X1056_1/3TS&2/3BS_CLEAR	TATA spare parts
409016010208	WIND LH COD 1200X818 SLIDING CLEAR GLASS	TATA spare parts
409016010235	RUBBER MOUNTED_DRIVER WINDOW ASSEMBLY	TATA spare parts
409016100210	PASTED GLASS LH_1046X1155_50 PERCGREY_FE	TATA spare parts
409016100211	PASTED GLASS_1552X1155_50 PERCGREY_FE	TATA spare parts
409016100212	PASTED GLASS LH_1151X1155_50 PERCGREY_FE	TATA spare parts
409016100213	PASTED GLASS RH_1151X1155_50 PERCGREY_FE	TATA spare parts
409016100214	PASTED GLASS RH_1461X1155_50 PERCGREY_FE	TATA spare parts
409016100250	DRIVER WIN RHD 636X789 SLDNG 4MM CLEAR	TATA spare parts
409016100251	WINDOW FIXD 314X795MM CLEAR RUBBER MNT	TATA spare parts
409016100289	PASTED GLASS_RH_1485X1070_50PERCGRAY BS6	TATA spare parts
409016100290	PASTED GLASS_LH_940X1070_50PERC GRAY TNT	TATA spare parts

409016100297	RH_PASTED GLASS_839X1328_45PERC BRONZE T	TATA spare parts
409016100298	RH/LH_PASTED GLASS_45PERC BRONZE TINT	TATA spare parts
409016100299	RH/LH_PASTED GLASS_45PERC BRONZE TINT	TATA spare parts
409016100302	LUXURY URBAN WINDOW FIXED GLASS	TATA spare parts
409016100303	LUXURY URBAN WINDOW FIXED GLASS	TATA spare parts
409016100306	DOOR GLASS	TATA spare parts
409016100309	LUXURY URBAN WINDOW FIXED GLASS	TATA spare parts
409016100310	LUXURY URBAN WINDOW FIXED GLASS	TATA spare parts
409016100311	DRIVER WINDOW LOWER FIXED GLASS	TATA spare parts
409016100312	LUXURY URBAN WINDOW FIXED GLASS	TATA spare parts
409016100313	LUXURY URABAN WINDOW MOBILE GLASS	TATA spare parts
409016100314	URBAN WINDOW GLASS ( LHS 1 )	TATA spare parts
409016100315	LUXURY URBAN WINDOW FIXED GLASS	TATA spare parts
409016100316	DOOR GLASS	TATA spare parts
409016100317	URBAN WINDOW GLASS ( RHS 1 2 3 LHS 2	TATA spare parts
409016100318	URBAN WINDOW GLASS ( RHS 6 AND LHS 6 )	TATA spare parts
409016100319	URBAN WINDOW GLASS ( LHS 4 )	TATA spare parts
409016100320	URBAN WINDOW GLASS ( RHS 5 AND LHS 5 )	TATA spare parts
409016100321	URBAN WINDOW GLASS ( RHS 4 )	TATA spare parts
409016100323	URBAN WINDOW GLASS-(548X959)	TATA spare parts
409016100324	LUXURY WINDOW FIXED GLASS (1175X1376)	TATA spare parts
409016100325	URBAN WINDOW GLASS-(1376X1001)	TATA spare parts
409016100326	LUXURY WINDOW FIXED GLASS (1001X710)	TATA spare parts
409016100327	LUXURY WINDOW FIXED GLASS (1001X1155)	TATA spare parts
409016100337	GLASS 1276X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016100338	GLASS 1476X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016100347	WINDOW ASSY_EPDM FIX GLASS_1044X1056	TATA spare parts
409016100348	GLASS 844X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016100349	GLASS 1116X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016100350	GLASS 430X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016100351	GLASS 1426X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016100352	GLASS 1176X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016100367	GLASS 802X413 EPDM TYPE FIX WINDOW	TATA spare parts
409016100379	GLASS 1476X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016100380	GLASS 876X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016100381	GLASS 588X804_EPDM TYPE FIX WINDOW	TATA spare parts
409016100382	GLASS 1226X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016100383	GLASS 1176X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016100384	GLASS 1076X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016100403	LUXURY URABAN WINDOW MOBILE GLASS	TATA spare parts
409016100404	LUXURY URABAN WINDOW MOBILE GLASS	TATA spare parts
409016100405	LUXURY URABAN WINDOW MOBILE GLASS	TATA spare parts
409016100406	LUXURY URABAN WINDOW MOBILE GLASS	TATA spare parts
409016100407	LUXURY URABAN WINDOW MOBILE GLASS	TATA spare parts
409016100408	TOP SLIDING GLASS REAR	TATA spare parts
409016100409	TOP SWINGING GLASS FRONT	TATA spare parts
409016120205	RH_PASTED GLASS_1923X1328_45PERCBRONZE	TATA spare parts

409016120206	RH_PASTED GLASS_1205X1153_45PERCBRONZE	TATA spare parts
409016120207	RH_PASTED GLASS_1510X1328_45PERCBRONZE	TATA spare parts
409016120208	LH_PASTED GLASS_1625X1328_45PERCBRONZE	TATA spare parts
409016120209	LH_PASTED GLASS_1205X1153_45PERCBRONZE	TATA spare parts
409016120210	LH_PASTED GLASS_925X1153_45PERC BRONZE	TATA spare parts
409016120211	LH_PASTED GLASS_1694X1328_45PERCBRONZE	TATA spare parts
409016120212	RH FRNT RVM GLS_870X239_CLEAR GLASS	TATA spare parts
409016120213	LH/RH REAR PASTED GLASS_CLEAR GLASS	TATA spare parts
409016120214	LH FRNT RVM GLS_1183X239_CLEAR GLASS	TATA spare parts
409016120215	LH_MIDDLE PASTED GLS_1190X265_CLEAR GLS	TATA spare parts
409016200211	SNOKREL PANELING PLATE	TATA spare parts
409016300206	LH SIDE FIX WINDOW GLASS RUBBER BEADING	TATA spare parts
409016300303	RUBBER_1276X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016300304	RUBBER_1476X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016300307	MOUNTING RUBBER FOR RHS FIRST SECOND T	TATA spare parts
409016300308	MOUNTING RUBBER FOR LHS FOURTH WINDOW	TATA spare parts
409016300309	MOUNTING RUBBER FOR LHS FIRST WINDOW	TATA spare parts
409016300312	MOUNTING RUBBER FOR RHS FIFTH AND LHS FI	TATA spare parts
409016300313	MOUNTING RUBBER FOR RHS SIXTH AND LHS SI	TATA spare parts
409016300314	LUXURY URBAN PASSENGER WINDOW RUBBER	TATA spare parts
409016300316	MOUNTING RUBBER FOR EMERGENCY DOOR WIN	TATA spare parts
409016300317	MOUNTING RUBBER FOR RHS FOURTH WINDOW	TATA spare parts
409016300318	DOOR GLASS RUBBER BEADING	TATA spare parts
409016300319	LUXURY URBAN PASSENGER WINDOW RUBBER	TATA spare parts
409016300320	LUXURY URBAN PASSENGER WINDOW RUBBER	TATA spare parts
409016300321	LUXURY URBAN PASSENGER WINDOW RUBBER	TATA spare parts
409016300322	LUXURY URBAN PASSENGER WINDOW RUBBER	TATA spare parts
409016300329	RUBBER_1044X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016300330	RUBBER_844X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016300331	RUBBER_1116X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016300332	RUBBER_430X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016300333	RUBBER_1426X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016300334	RUBBER_1176X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016300342	RUBBER 1226X1056 EPDM TYPE FIX WINDOW	TATA spare parts
409016300343	RUBBER_876X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016300345	RUBBER 588X804 EPDM TYPE FIX WINDOW	TATA spare parts
409016300346	RUBBER_1076X1056_EPDM TYPE FIX WINDOW	TATA spare parts
409016300347	RUBBER 802X413 EPDM TYPE FIX WINDOW	TATA spare parts
409016400401	WINDOW HANDLE WASHER	TATA spare parts
409016700201	END PROFILE	TATA spare parts
409016700403	WINDOW HANDLE	TATA spare parts
409016800202	PASTED WINDOW GLASS-1 (LEFT SIDE)	TATA spare parts
409016800203	PASTED WINDOW GLASS-2 (LEFT SIDE)	TATA spare parts
409016800207	PASTED WINDOW GLASS-5 (LEFT SIDE)	TATA spare parts
409016800208	PASTED WINDOW GLASS-6 (LEFT SIDE)	TATA spare parts
409016800209	PASTED WINDOW GLASS-6 (RIGHT SIDE)	TATA spare parts
409016800210	PASTED WINDOW GLASS-5 (RIGHT SIDE)	TATA spare parts



409016800213	PASTED WINDOW GLASS-3 (RIGHT SIDE)	TATA spare parts
409016800214	PASTED WINDOW GLASS-2 (RIGHT SIDE)	TATA spare parts
409016800215	PASTED WINDOW GLASS-1 (RIGHT SIDE)	TATA spare parts
409016800218	PASTED GLASS (LEFT SIDE)	TATA spare parts
409016800219	PASTED GLASS (RIGHT SIDE)	TATA spare parts
409016800226	PASTED WINDOW GLASS-6(RIGHT SIDE)	TATA spare parts
409016800227	PASTED WINDOW GLASS-6 (LEFT SIDE)	TATA spare parts
409016800232	PASTED WINDOW GLASS (RIGHT SIDE)	TATA spare parts
409016800233	PASTED WINDOW GLASS (RIGHT SIDE)	TATA spare parts
409016800234	PASTED WINDOW GLASS-3(LEFT SIDE)	TATA spare parts
409016800236	PASTED WINDOW GLASS-4	TATA spare parts
409016800242	FRT PASSENGER DOOR UPPER PASTED GLASS	TATA spare parts
409016800243	DRIVER DOOR UPPER PASTED GLASS	TATA spare parts
409016800244	REAR PASSENGER DOOR UPPER PASTED GLASS	TATA spare parts
409016800270	PASTED WINDOW GLASS RH SIDE 1ST	TATA spare parts
409016800271	PASTED WINDOW GLASS RH & LH (2ND)	TATA spare parts
409016800272	PASTED WINDOW GLASS RH SIDE 3RD	TATA spare parts
409016800273	PASTED WINDOW GLASS PASSENGER DOOR	TATA spare parts
409016800274	PASTED WINDOW GLASS RH SIDE 4TH	TATA spare parts
409016800275	PASTED WINDOW GLASS 5TH	TATA spare parts
409016800277	PASTED WINDOW GLASS LH SIDE 1ST	TATA spare parts
409016800278	PASTED WINDOW GLASS LH SIDE 3RD	TATA spare parts
409016800279	PASTED WINDOW GLASS L.H. SDIE 4TH	TATA spare parts
409016800280	PASTED WINDOW GLASS LH 6TH	TATA spare parts
409016800281	PASTED GLASS OF FRONT PASSENGER DOOR	TATA spare parts
409016800282	PASTED GLASS OF DRIVER DOOR	TATA spare parts
409016800283	PASTED WINDOW GLASS OF COOLANT	TATA spare parts
409016800284	PASTED WINDOW GLASS OF AIR FILTER	TATA spare parts
409016800317	PASTED WINDOW GLASS_RH	TATA spare parts
409016800318	PASTED WINDOW GLASS_LH	TATA spare parts
409016800320	PASTED WINDOW_1654X1328	TATA spare parts
409016800321	PASTED WINDOW_1550X1328	TATA spare parts
409016800322	PASTED WINDOW - 895X1328	TATA spare parts
409016800324	PASTED WINDOW_1654X1328	TATA spare parts
409016810226	PASTED GLS_LH_REAR_703X1070_	TATA spare parts
409017000107	FRONT DOOR MECHANISM	TATA spare parts
409017000108	REAR DOOR MECHANISM	TATA spare parts
409017000112	PASSENGER DOOR ASSY	TATA spare parts
409017000114	SUPPORT PLATE ASSEMBLY FOR CUTOUT	TATA spare parts
409017000117	DOOR MECHANISM-LHD	TATA spare parts
409017000135	DOOR 870	TATA spare parts
409017000136	MITECH 1210 DOOR	TATA spare parts
409017000137	PNEUMATIC KIT 1210 & 870	TATA spare parts
409017000148	1210MM PASSENGER DOOR ASSY	TATA spare parts
409017000149	ELECTRO PNEUMATIC KIT	TATA spare parts
409017000204	EXTERNAL KIT ASSY	TATA spare parts
409017000205	DOOR KIT-OUTSWING	TATA spare parts

409017000206	DOOR KIT-GLIDING	TATA spare parts
409017000207	SHELF PLATE ASSY-O/S	TATA spare parts
409017000208	PLATE ASSY-GLIDING	TATA spare parts
409017000209	APR SEALING KIT-(SEAL-OS)	TATA spare parts
409017000225	PU TUBE FOR PNEUMATIC SYS YELLOW COLOR	TATA spare parts
409017000232	JK SINGLE DOOR DOUBLE LEAVES LH	TATA spare parts
409017000233	JK SINGLE DOOR SINGLE LEAVES LH	TATA spare parts
409017000234	JK PNEUMATIC KIT	TATA spare parts
409017000256	1/4IN 5/2 PUSH PULL DETENT VALVE	TATA spare parts
409017000257	1/4IN 3/2 NO PUSH PULL DETENT VALVE	TATA spare parts
409017000258	FLOW VALVE 1/4IN X DIA 6IN	TATA spare parts
409017000259	1/4IN 3/2 NO PUSH PULL DETENT VALVE	TATA spare parts
409017000260	UNION TEE DIA6	TATA spare parts
409017000299	WIRING HARNESS INSWING & OUTSWING¿ DOOR	TATA spare parts
409017000342	DOOR LOCK COVER	TATA spare parts
409017000347	PASSENGER DOOR¿ ASSY	TATA spare parts
409017000348	FRONT PNEUMATIC ASSY	TATA spare parts
409017000349	PASSENGER DOOR¿ ASSY	TATA spare parts
409017000350	MIDDLE PNEUMATIC ASSY	TATA spare parts
409017000518	BRTS DOOR GLASS	TATA spare parts
409017010215	JK PASSENGER DOOR CLEAR GLASS 1210X1983	TATA spare parts
409017010216	PNEUMATIC LAYOUT EV 4X12 JK DOOR 1210	TATA spare parts
409017100103	MASAT MECHANISM WIRE HARNESS	TATA spare parts
409017100201	MECHANISM DTC FRONT	TATA spare parts
409017100202	MECHANISM DTC REAR	TATA spare parts
409017100203	FRONT DOOR MECHANISM	TATA spare parts
409017100204	REAR¿ DOOR MECHANISM	TATA spare parts
409017100205	ELECTROVALVE 2V. NC	TATA spare parts
409017100206	ALUMINIUM WASHER 13X17X2	TATA spare parts
409017100207	ALUMINIUM WASHER 12X17X2	TATA spare parts
409017100208	LOWER PART SUPPORT KIT	TATA spare parts
409017100209	LOWER PLASTIC CENTERING DEVICE	TATA spare parts
409017100210	ELECTROVALVE 3V NC	TATA spare parts
409017100211	ANTIDUMPING VALVE	TATA spare parts
409017100212	FAE CONTACTOR	TATA spare parts
409017100213	DIODE CONNECTOR(6 PIN)	TATA spare parts
409017100214	INTERIOR EMERGENCY PUSH-BUTTON	TATA spare parts
409017100215	RIGHT GUIDEWHEEL SUPPORT	TATA spare parts
409017100216	LEFT GUIDEWHEEL SUPPORT	TATA spare parts
409017100217	PNEUMATIC SWITCH	TATA spare parts
409017100218	EMERGENCY INTERNAL_ C7098(SQUARE TYPE)_J	TATA spare parts
409017100219	EMERGENCY EXTERNAL_ C7099(ROUND TYPE)_J	TATA spare parts
409017100220	FRONT ELEC-PNEUMATIC ASSY	TATA spare parts
409017100221	REAR ELEC-PNEUMATIC ASSY	TATA spare parts
409017100301	SPHERICAL BEARING FOR PLATE SWINGING EQU	TATA spare parts
409017100302	BEARING	TATA spare parts
409017100303	LOWER CENTERING DEVICE	TATA spare parts

409017100304	CYLINDER 140 STROKE	TATA spare parts
409017100305	MANUAL VALVE 3V	TATA spare parts
409017100306	ELECTROVALE 5/5 (1 COIL)	TATA spare parts
409017100307	ELECTROVALVE 3V NV	TATA spare parts
409017100308	5/2 ELECTOVALVE	TATA spare parts
409017100309	ELECTROVALVE 2V NV	TATA spare parts
409017100310	ELECTROVALVE 2V NV	TATA spare parts
409017100311	ANTI RETURN VALVE	TATA spare parts
409017100312	SENSITIVITY VALVE	TATA spare parts
409017100313	SENSITIVITY MICROSWITCH	TATA spare parts
409017100314	CONTACTOR	TATA spare parts
409017100315	SLIDING COMPONENT WITH BEARING	TATA spare parts
409017100316	CONTACTO NA 0.2 KG	TATA spare parts
409017100317	CONNECTING	TATA spare parts
409017100318	ELECTRONIC RELAY WITH CONNCET AND FUSE	TATA spare parts
409017100319	SENSITIVITY MICROSWITCH	TATA spare parts
409017100320	BEARING	TATA spare parts
409017100321	PLASTIC PUSH BUTTON PROTECTOR	TATA spare parts
409017100322	BUZZER	TATA spare parts
409017100323	CLOSING TEMPORISER	TATA spare parts
409017100324	RELAY	TATA spare parts
409017100325	CIRCUIT SELECT VLAVE	TATA spare parts
409017100326	ELECTRIC PUSH BUTTON (BLACK)	TATA spare parts
409017100327	ELECTRIC PUSH BUTTON (RED)	TATA spare parts
409017100328	ELECTRIC PUSH BUTTON (GREEN)	TATA spare parts
409017100329	SWITCH 2 POSITIONS	TATA spare parts
409017100331	BLADE ASSY (LH)	TATA spare parts
409017100333	WIPER NOZZLE	TATA spare parts
409017100335	CAP WIPER ARM HEAD LH/RH	TATA spare parts
409017100336	LOWER PART SUPPORT KIT F/SWING	TATA spare parts
409017100344	PLATE ASM	TATA spare parts
409017100345	HIGH PRESSURE PIPE	TATA spare parts
409017100346	BUZZER	TATA spare parts
409017100347	PNEUMATIC SENSOR (WITH PVC PIPE AND BUSH	TATA spare parts
409017100348	SOLENOID VALVE SUB	TATA spare parts
409017100349	CUSHION VALVE ASM	TATA spare parts
409017100350	AIR FILTER SUB	TATA spare parts
409017100351	CRANK SUB (65-36 TEETH)	TATA spare parts
409017100352	SPLINED SHAFT SUB	TATA spare parts
409017100353	AIR CYLINDER SUB	TATA spare parts
409017100354	MICRO-COMPUTER CONTROLLER	TATA spare parts
409017100355	AIR PRESSURE SWITCH	TATA spare parts
409017100356	SOLENOID VALVE SUB(WITH END CAP)	TATA spare parts
409017100357	GUIDE ASM	TATA spare parts
409017100357C	GUIDE ASM HUMIN 0403Z-890002CORE	TATA spare parts
409017100358	BASE PLATE SUB	TATA spare parts
409017100359	LOWER SUPPORT ASM	TATA spare parts

409017100360	UPPER STOP ASM	TATA spare parts
409017100361	LOWER STOP ASM	TATA spare parts
409017100362	CHECK RING-FT	TATA spare parts
409017100363	EMERGENCY VALVE ASM	TATA spare parts
409017100364	DASHBOARD SWITCH-RED	TATA spare parts
409017100365	DASHBOARD SWITCH-GREEN	TATA spare parts
409017100366	DASHBOARD SWITCH-YELLOW	TATA spare parts
409017100367	DASHBOARD SWITCH-BLUE	TATA spare parts
409017100368	DASHBOARD SWITCH-BLACK	TATA spare parts
409017100369	PUSH SWITCH(WITH COVER)	TATA spare parts
409017100370	LOCKNUT CONNECTOR-AIR TANK	TATA spare parts
409017100371	T LOCKNUT CONNECTOR	TATA spare parts
409017100372	DOOR LOCK	TATA spare parts
409017100373	CONNECTOR (IN PAIRS)	TATA spare parts
409017100374	SEALINGS	TATA spare parts
409017100375	PNEUMATIC EMERGENCY SWITCH(WITH COVER)	TATA spare parts
409017100376	ROD-END BEARING	TATA spare parts
409017100377	MAGNETIC SENSOR	TATA spare parts
409017100436	DOOR SLIDE GUIDE ROLLER	TATA spare parts
409017100440	FRONT DOOR WIRING	TATA spare parts
409017110201	REG. SCREW 12X1.5	TATA spare parts
409017110202	RED OUTER EMERGENCY PUSH-BUTTON	TATA spare parts
409017110203	ALLEN SCREW M8X25	TATA spare parts
409017110204	WASHER FOR M8	TATA spare parts
409017110205	EMERGENCY SWITCH COVER-ABS	TATA spare parts
409017110310	HIGH PRESSURE PIPE-G	TATA spare parts
409017110311	LOCKNUT CONNECTOR	TATA spare parts
409017110318	FRONT PASS.DOOR HANDLE	TATA spare parts
409017110401	SENSITIVITY	TATA spare parts
409017110402	PVC PIPE	TATA spare parts
409017110403	STAINLESS STEEL BUSH	TATA spare parts
409017110404	VALVE BODY	TATA spare parts
409017110405	SOLENOID	TATA spare parts
409017110406	SEALERS	TATA spare parts
409017110407	ROD-END BEARING	TATA spare parts
409017110408	MAGNETIC SENSOR	TATA spare parts
409017110409	CONTROLLER BOX	TATA spare parts
409017110410	WIRING HARNESS	TATA spare parts
409017110411	VALVE BODY	TATA spare parts
409017200001	DOOR ASSY-FRONT	TATA spare parts
409017200032	BOTTOM BRUSH	TATA spare parts
409017200033	BOTTOM BRUSH	TATA spare parts
409017200037	PASSENGER DOOR GLASSES	TATA spare parts
409017200038	LOCK FOR PASSENGER DOOR	TATA spare parts
409017200039	HINGE ASSY (WITHOUT HANDLE)	TATA spare parts
409017200040	HINGE ASSY (WITH HANDLE)	TATA spare parts
409017200042	WEATHER STRIP(PASS DOOR)	TATA spare parts

409017200044	WEATHER STRIP(PASS DOOR)	TATA spare parts
409017200049	MOUNTING RUBBER FOR PASSENGER DOOR GLASS	TATA spare parts
409017200050	WEATHER STRIP(PASS DOOR-KEY)	TATA spare parts
409017200055	GRAB PIPE FOR PASSENGER DOOR	TATA spare parts
409017200056	GUARD RAIL BRACKET (PC)	TATA spare parts
409017200059	DOOR ASSY-REAR	TATA spare parts
409017200100	TOP DOOR BRUSH	TATA spare parts
409017200101	AL-EXTRUSION FOR DOOR BRUSH ( 4 MTR)	TATA spare parts
409017200102	STOPPER (ENTRANCE DOOR)	TATA spare parts
409017200104	RUBBER CAP WITHOUT SLEEVE	TATA spare parts
409017200105	RUBBER CAP WITH SLEEVE	TATA spare parts
409017200106	SILICON TUBE FOR SENSITIVITY KIT	TATA spare parts
409017200107	SPRING FOR SENSITIVE KIT	TATA spare parts
409017200110	MOULDED WEATHER STRIP(DOOR)	TATA spare parts
409017200111	WEATHER STRIP(PASS DOOR)	TATA spare parts
409017200112	MOULDED WEATHER STRIP	TATA spare parts
409017200113	WEATHER STRIP ( ENTR.DOOR)	TATA spare parts
409017200114	WEDGE STRIP (ENTR.DOOR GLASS)	TATA spare parts
409017200115	WEATHER STRIP (PASS.DOOR)	TATA spare parts
409017200116	WEATHER STRIP (PASS/DOOR BIG BULB)	TATA spare parts
409017200118	GLASS FIXING INSERT	TATA spare parts
409017200120	TAP SCREW/CSK HEAD (M04X30)	TATA spare parts
409017200121	WASHER (12ODX5.5IDX0.8THK)	TATA spare parts
409017200122	GRAB HANDLE	TATA spare parts
409017200123	BOTTOM BRUSH	TATA spare parts
409017200124	LOCK SYSTEM	TATA spare parts
409017200125	RUBBER PROFILES(FOR GLASS FIX)	TATA spare parts
409017200126	TOWER BOLT	TATA spare parts
409017200201	PASSENGER DOOR	TATA spare parts
409017200202	PASSENGER DOOR	TATA spare parts
409017200203	PASSENGER DOOR ASSY-FRONT & RR-SET	TATA spare parts
409017200205	PASSENGER DOOR ASSY(ACGL)	TATA spare parts
409017200206	EV 4X12 WIRING HARNESS FR & MID JK DOOR	TATA spare parts
409017200301	JK DOOR UPPER BEARING ASSY	TATA spare parts
409017300101	SEAT BASE CUSHION PAD	TATA spare parts
409017300102	SEAT BACKREST CUSHION PAD	TATA spare parts
409017300103	SEAT BASE SHELL WITH GRAB HANDLE-GREY GL	TATA spare parts
409017300104	SEAT BASE UPHOLSTERY COVER	TATA spare parts
409017300105	SEAT BACKREST UPHOLSTERY COVER	TATA spare parts
409017300107	PLASTIC ARM REST PAD	TATA spare parts
409017300108	LAP BELT ASSY UNIT	TATA spare parts
409017300110	M8 WASHER	TATA spare parts
409017300111	ARMREST ASSY	TATA spare parts
409017300112	COUNTER SUNK SCREW M6X 35	TATA spare parts
409017300113	GRAB HANDLE	TATA spare parts
409017300114	SEAT BACK ASSY ( BLUE )	TATA spare parts
409017300115	SEAT CUSHION ASSY ( BLUE )	TATA spare parts

409017300116	PLASTIC SHELL	TATA spare parts
409017300117	M8X45 HEX BOLT	TATA spare parts
409017300118	SCREW M6X20 PHILIPS HEAD	TATA spare parts
409017300119	GRAB HANDLE	TATA spare parts
409017300120	PLASTIC END CAP FOR REINFORCEMENT TUBE H	TATA spare parts
409017300121	PLASTIC END CAP GREY	TATA spare parts
409017300122	M6X40 HEX BOLT	TATA spare parts
409017300123	M6 WASHER	TATA spare parts
409017300124	M6 NYLOCK NUT	TATA spare parts
409017300125	ARM REST PAD ASSY	TATA spare parts
409017300127	SEAT CUSHION ASSY ( RED )	TATA spare parts
409017300128	SEAT BACK ASSY ( RED )	TATA spare parts
409017300130	DICKEY PASSENGER SEAT FRAME WITHOUT ARM	TATA spare parts
409017300131	LH PASSENGER SEAT FRAME WITH SEAT BELT	TATA spare parts
409017300134	RH PASSENGER SEAT FRAME WITHOUT SEAT BEL	TATA spare parts
409017300135	LH PASSENGER SEAT FRAME WITHOUT SEAT BEL	TATA spare parts
409017300139	SINGLE DICKEY PASSENGER SEAT FRAME	TATA spare parts
409017301405	BACK REST UPHOLSTERY RH & LH	TATA spare parts
409017301406	2 STR SEAT BOTTOM UPHOLSTERY RH	TATA spare parts
409017301409	NET PLAST ASSY BR PU PAD PRINT BLUE PVC	TATA spare parts
409017301410	NET PLAST ASSY CU PU PAD PRINT BLUE PVC	TATA spare parts
409017400101	DOME ASSYMBLY	TATA spare parts
409017400102	OUTER EMERGENCY HANDLE ASSY	TATA spare parts
409017400103	EMERGENCY HANDLE COVER ASSY	TATA spare parts
409017400104	OUTER FRAME ASSY W/O MECHANISM	TATA spare parts
409017400105	MECHANISM	TATA spare parts
409017400106	STRAP	TATA spare parts
409017400107	INNER FRAME ABS	TATA spare parts
409017400108	STICKERS	TATA spare parts
409017400306	BELT XPB 1675 (FROM CRANK TO IDLER)	TATA spare parts
409017400307	V BELT XPB - 1010 (FROM IDLER TO COMPRES	TATA spare parts
409017500101	PUSH BUTTON WITH INDICATOR - EMERGENCY(R	TATA spare parts
409017500102	PUSH BUTTON WITH INDICATOR - REAR DOOR (	TATA spare parts
409017500103	PUSH BUTTON WHITE	TATA spare parts
409017500104	PUSH BUTTON WITH INDICATOR - FRONT DOOR(	TATA spare parts
409017500107	SILENCER 1/4INC BSP	TATA spare parts
409017500108	1/8INC BSP ELBOW (8/6 TUBE) WITH O RING	TATA spare parts
409017500110	SILENCER 1/8INC BSP	TATA spare parts
409017500111	SVAJ 213 24V DC	TATA spare parts
409017500112	DSA210 (PILOT OPERATED)	TATA spare parts
409017500114	SPL. EQUAL T (8/6 TUBE)	TATA spare parts
409017500115	NON-RETURN VALVE 1/4	TATA spare parts
409017500116	ORIFICE FOR NON-RETURN VALVE 1230002040	TATA spare parts
409017500117	BEEPER	TATA spare parts
409017500118	AIRWAVE SWITCH	TATA spare parts
409017500120	PUSH PULL VALVE (3/2)	TATA spare parts
409017500121	KNOB WITH M PRINT	TATA spare parts

409017500123	14 EMERGENCY VALVE COVER (PLASTIC)	TATA spare parts
409017500124	EMERGENCY VALVE (2/2) - ASSLY	TATA spare parts
409017500125	EMERGENCY VALVE COVER (METAL) - ASSLY	TATA spare parts
409017500128	EXTERNAL CIRCLIP (SHAFT DIA 12)	TATA spare parts
409017500148	1/4INC ST. CONNECTOR (F) X 8/6 TUBE	TATA spare parts
409017500201	SLIDING GLASS-1	TATA spare parts
409017500202	SLIDING GLASS-2	TATA spare parts
409017500203	SLIDING GLASS-3	TATA spare parts
409017500204	SLIDING GLASS-4	TATA spare parts
409017500230	LOCK ASSY	TATA spare parts
409017500231	LOCK ASSY BIG ( DRIVER WINDOW )	TATA spare parts
409017500232	FIXED GLASS(1476X377)	TATA spare parts
409017500233	GLASS SLIDING(734X765)	TATA spare parts
409017500234	GLASS SLIDING	TATA spare parts
409017500235	FIXED GLASS(1276X599)	TATA spare parts
409017500236	GLASS SLIDING(634X371)	TATA spare parts
409017500237	GLASS FIXED	TATA spare parts
409017500238	GLASS NO 1 SLIDING(R.H.)	TATA spare parts
409017500239	GLASS SLIDING	TATA spare parts
409017500240	GLASS SLIDING	TATA spare parts
409017500241	SLIDING GLASS-C.D	TATA spare parts
409017500242	SLIDING GLASS-CD	TATA spare parts
409017500243	SLIDING GLASS-C.D.	TATA spare parts
409017500244	SLIDING GLASS-C.D.	TATA spare parts
409017500245	LEVER ASSY ( DRIVER WINDOW )	TATA spare parts
409017500246	EMERGENCY WINDOW GLASS(UPPER)	TATA spare parts
409017500247	EMERGENCY WINDOW GLASS(LOWER)	TATA spare parts
409017500248	GLASS SLIDING	TATA spare parts
409017500249	GLASS SLIDING(A)	TATA spare parts
409017500250	GLASS SLIDING(B)	TATA spare parts
409017500251	SCOOP GLASS	TATA spare parts
409017500252	BOTTOM FIXED GLASS	TATA spare parts
409017500268	WINDOW RUBBER BEEDING	TATA spare parts
409017500269	WINDOW RUBBER BEEDING	TATA spare parts
409017500270	WINDOW RUBBER BEEDING	TATA spare parts
409017500271	WINDOW RUBBER BEEDING	TATA spare parts
409017500272	WINDOW RUBBER BEEDING	TATA spare parts
409017500273	WINDOW RUBBER BEEDING	TATA spare parts
409017500274	WINDOW RUBBER BEEDING	TATA spare parts
409017500275	WINDOW RUBBER BEEDING	TATA spare parts
409017500276	WINDOW RUBBER BEEDING	TATA spare parts
409017500277	LOCK SET	TATA spare parts
409017500278	CATCHER PLATE FRONT	TATA spare parts
409017500279	CATCHER PLATE REAR	TATA spare parts
409017500282	TOGGLE CLAMP	TATA spare parts
409017500287	TOP FIXED GLASS	TATA spare parts
409017500288	BOTTOM FIXED GLASS	TATA spare parts

409017500301	SWEEP SECTION 804MM (LS)	TATA spare parts
409017500302	SWEEP SECTION 630MM (LS)	TATA spare parts
409017500303	SWEEP SECTION 371MM (US)	TATA spare parts
409017500304	INTERNAL CATCHER	TATA spare parts
409017500305	EXTERNAL CATCHER	TATA spare parts
409017500306	DRIVER TILT SECTION	TATA spare parts
409017500307	DRIVER C FRAME	TATA spare parts
409017500308	TOP SLIDING FRONT	TATA spare parts
409017500309	BOTTOM SLIDING FRONT	TATA spare parts
409017500310	TOP SLIDING FRONT	TATA spare parts
409017500311	BOTTOM SLIDING FRONT	TATA spare parts
409017500312	TOP SLIDING FRONT	TATA spare parts
409017500313	BOTTOM SLIDING FRONT	TATA spare parts
409017500314	TOP SLIDING FRONT	TATA spare parts
409017500315	BOTTOM SLIDING FRONT	TATA spare parts
409017500316	TOP SLIDING FRONT	TATA spare parts
409017500317	BOTTOM SLIDING FRONT	TATA spare parts
409017500318	BOTTOM SLIDING FRONT	TATA spare parts
409017500319	BOTTOM SLIDING FRONT	TATA spare parts
409017500320	BOTTOM FIXED GLASS	TATA spare parts
409017500321	TOP SLIDING FRONT	TATA spare parts
409017500322	UP LIFT GLASS	TATA spare parts
409017500323	BOTTOM FIXED GLASS	TATA spare parts
409017500324	TOP SLIDING FRONT	TATA spare parts
409017500325	TOP SLIDING REAR	TATA spare parts
409017500329	OUTSWINGING DOOR GLASS	TATA spare parts
409017500401	WINDOW HANDLE	TATA spare parts
409017500402	WINDOW LATCH ASSY	TATA spare parts
409017500403	HANDLE WASHER	TATA spare parts
409017500404	3/16 ZINC PLATED BRASS	TATA spare parts
409017500405	DRIVER WINDOW HANDLE	TATA spare parts
409017600201	L CONNECTOR WIPER	TATA spare parts
409017600202	T CONNECTOR	TATA spare parts
409017700201	PASSENGER DOOR LIMIT BRACKET	TATA spare parts
409017700301	PASSENGER DOOR LIMIT BRACKET	TATA spare parts
409017900101	SPC-D-W-SU-MP4-50/100	TATA spare parts
409017900102	SPC-D-W-MP4-63/100 1 3735	TATA spare parts
409017900103	DSA213 24V DC	TATA spare parts
409017900104	P/E CONVERTOR (PRESSURE SWITCH)	TATA spare parts
409017900106	EQUAL T (8/6 TUBE)	TATA spare parts
409017900107	1/4 BSP(M) ST CONNECTR 8/6 TUBE	TATA spare parts
409017900108	1/4INC BSP ELBOW (8/6 TUBE) WITH O RING	TATA spare parts
409017900109	1/4INC FLOW CONTROL (8/6 TUBE) WITH O RI	TATA spare parts
409017900110	DOOR MOUNTING PLATE 870	TATA spare parts
409017900111	DOOR MOUNTING PLATE 1210	TATA spare parts
409017900112	BEARING ( B.O) 35X20X16 THK.	TATA spare parts
409017900113	INTERNAL CIRCLIP DIA (BORE DIA 35)	TATA spare parts



409017900114	DOOR MOUNTING SUPPORT PLAT 1230002027	TATA spare parts
409017900115	DOOR MOUNTING SUPPORT PLAT 1230002028	TATA spare parts
409017900116	DOOR STOPER ( L SHAPE)	TATA spare parts
409017900124	MOUNTING PLATE FOR BOTTOM DOOR BRACK	TATA spare parts
409017900125	BOTTOM DOOR BRACKET ARM (1230002017)	TATA spare parts
409017900126	DERLIN BUSH FOR BRACKET (1230002018)	TATA spare parts
409017900127	BALL DIA. 14 ( B.O) 9742114000	TATA spare parts
409017900128	PACKING (SUPPORT PLATE) (1230002023)	TATA spare parts
409017900130	SPLINE SHAFT FOR DOOR MTG PLAT1230002026	TATA spare parts
409017900131	LINKAGE FOR BUS DOOR ASSY. (1230002025	TATA spare parts
409017900132	BUSH 1 FOR SPLINE SHAFT (1230002033)	TATA spare parts
409017900133	BUSH 2 FOR SPLINE SHAFT (1230002034)	TATA spare parts
409017900137	PIN FOR LINKAGE 1230002031	TATA spare parts
409017900139	DOOR SUPPORT END BKT. ( L ) (1230002021)	TATA spare parts
409017900140	DERLIN BUSH ( SMALL ) 1230002016	TATA spare parts
409017900142	BRACKET FOR DOOR SUPPORT BOTTOM	TATA spare parts
409017900143	ECCENTRIC BOLT FOR DOOR S.END BOTTOM	TATA spare parts
409017900147	SUPPORT PLATE FOR BOTTOM SUPPORT	TATA spare parts
409017900153	CONTROLLER WITH VMS	TATA spare parts
409017900154	HARNESS WITH VMS	TATA spare parts
409017900155	PLC	TATA spare parts
409017900156	DOOR SENSOR	TATA spare parts
409017900157	DOOR LEAF ASSY R.H.	TATA spare parts
409017900158	DOOR LEAF ASSY L.H.	TATA spare parts
409017900159	DOOR SHAFT ASSEMBLY-FRONT R.H	TATA spare parts
409017900160	DOOR SHAFT WITH HANDLE ASSEMBLY	TATA spare parts
409017900161	REAR DOOR LEAF RH	TATA spare parts
409017900162	REAR DOOR LEAF LH	TATA spare parts
409017900163	REAR DOOR SHAFT R.H	TATA spare parts
409017900164	REAR DOOR SHAFT L.H	TATA spare parts
409017900165	BOTTOM BEARING	TATA spare parts
409017900166	BOTTOM BEARING	TATA spare parts
409017900167	BOTTOM BRUSH ASSY	TATA spare parts
409017900168	GUIDE ROLLER PLATE ASSY	TATA spare parts
409017900169	TOP BRUSH ASSY	TATA spare parts
409017900170	R.H.PIVOT SHAFT ASSY	TATA spare parts
409017900171	L.H. PIVOT SHAFT ASSY	TATA spare parts
409017900172	PIVOT SHAFT ASSY	TATA spare parts
409017900173	CYLINDER	TATA spare parts
409017900174	CYLINDER	TATA spare parts
409017900175	SOLENOID VALVE	TATA spare parts
409017900176	CLEVIS	TATA spare parts
409017900177	REED SWITCH	TATA spare parts
409017900178	REED SWITCH BRACKET	TATA spare parts
409017900179	PARALLEL LINK ASSY	TATA spare parts
409017900180	PARALINK BKT. R.H.	TATA spare parts
409017900181	PARALINK BKT. L.H.	TATA spare parts

409017900182	DUMP VALVE	TATA spare parts
409017900183	FILTER REGULATER	TATA spare parts
409017900184	OUTER EMERGENCY BOX ASSY	TATA spare parts
409017900185	INTERNAL EMERGENCY BOX ASSY	TATA spare parts
409017900186	SINGLE KNUCKLE JOINT	TATA spare parts
409017900187	VALVE	TATA spare parts
409017900188	PNEUMATIC ELECTRIC RELAY	TATA spare parts
409017900189	WIRE HARNESS	TATA spare parts
409017900190	WIRE HARNESS	TATA spare parts
409017900191	DRIVER CONTROL PANEL	TATA spare parts
409017900192	POLYURETHANE TUBE	TATA spare parts
409017900193	TUBE	TATA spare parts
409017900194	SHUTTLE VALVE	TATA spare parts
409017900195	SPEED CONTROLLER	TATA spare parts
409017900196	ONE TOUCH FITTINGS	TATA spare parts
409017900197	FITTING	TATA spare parts
409017900198	ONE TOUCH FITTINGS	TATA spare parts
409017900199	ONE TOUCH FITTINGS	TATA spare parts
409017900211	CARBON BRUSH WITH SPRING	TATA spare parts
409017900220	FLUSH HEAD PUSH BUTTON (RED)	TATA spare parts
409017900221	FLUSH HEAD PUSH BUTTON (GREEN)	TATA spare parts
409017900222	FLUSH HEAD PUSH BUTTON (BLACK)	TATA spare parts
409017900223	MODULAR CONTACT BLOCK-NC BLOCK	TATA spare parts
409017900228	PASSENGER DOOR	TATA spare parts
409017900230	WASHER CIRCLIP	TATA spare parts
409017900231	WASHER CIRCLIP	TATA spare parts
409017900232	PUSH BUTTON BLACK NO	TATA spare parts
409017900233	PUSH BUTTON GREEN NO	TATA spare parts
409017900234	PUSH BUTTON YELLOW	TATA spare parts
409017900235	PUSH BUTTON RED NO	TATA spare parts
409017900236	REAR DOOR LEAF ASSY LEFT HAND	TATA spare parts
409017900237	REAR DOOR LEAF ASSY LEFT HAND	TATA spare parts
409017900238	PUSH BUTTON ILLUMINATION NO	TATA spare parts
409017900239	GREEN WITH LED PUSH BUTTON	TATA spare parts
409017900240	POLYURETHANE TUBE	TATA spare parts
409017900245	FRONT PASSENGER¿ DOOR ASSY	TATA spare parts
409017900247	1210 FRONT DOOR FLAP ASSY_ MOUD II	TATA spare parts
409017900248	1210 FRONT ELEC-PNEUMATIC ASSY_ MOUD II	TATA spare parts
409017900249	1350 REAR DOOR FLAP ASSY LE_ MOUD II	TATA spare parts
409017900250	1350 REAR ELEC-PNEUMATIC ASSY LE_ MOUD II	TATA spare parts
409017900251	WIRE HARNESS WITH SWITCH_ MOUD II LE	TATA spare parts
409017900252	1350 REAR ELEC-PNEUMATIC ASSY_ MOUD II	TATA spare parts
409017900253	1350 REAR DOOR FLAP ASSY_ MOUD II	TATA spare parts
409017900254	WIRE HARNESS WITH SWITCH_ MOUD II MCV	TATA spare parts
409017900255	920 FRONT ELEC-PNEUMATIC ASSY_ MOUD II	TATA spare parts
409017900256	920 FRONT DOOR FLAP ASSY_ MOUD II	TATA spare parts
409017900258	MALE ELBOW 1/4 X 6	TATA spare parts

409017900259	MALE ELBOW 1/8 X 6	TATA spare parts
409017900260	FRONT DOOR FLAP ASSY	TATA spare parts
409017900261	REAR DOOR FLAP ASSY	TATA spare parts
409017900283	870X2003 APP FRONT JK -PNEUMATIC ASSY	TATA spare parts
409017900284	1210X1982 APP REAR JK-PNEUMATIC CIRCUIT	TATA spare parts
409017900301	PNEUMATIC SENSOR(WITH PIPE & BUSH)	TATA spare parts
409017900317	PASS DOOR HUMMINS WIRE HARNESS 1350&800	TATA spare parts
409017900318	PNEUMATIC PASSENGER DOOR ASSY	TATA spare parts
409017900319	920 FRONT ELEC-PNEUMATIC ASSY_MOU D II	TATA spare parts
409017900320	1350 REAR ELEC-PNEUMATIC ASSY_MOU D II	TATA spare parts
409017990201	PASSENGER DOOR STOPER WASHER	TATA spare parts
409017990214	TOP SEALING BRUSH 1210 DOOR	TATA spare parts
409018000116	FRP 920 PNEUMATIC JK DOOR BOX ASSY	TATA spare parts
409018000142	FRP FUSE BOX ASSEMBLY	TATA spare parts
409018000154	FRP 1621 AT AC ENGINEHOOD ASSEMBLY	TATA spare parts
409018000168	SCU COVER ASSEMBLY LE	TATA spare parts
409018000169	SCU COVER ASSEMBLY FOR MCV	TATA spare parts
409018000204	RH WHEEL HOUSING W/O TEXTURE RELE	TATA spare parts
409018000206	WHEEL HOUSE COVERING (FRP ASSY)	TATA spare parts
409018000216	INSTR CLUSTR WIT CLUTHFLUID COV ASSY	TATA spare parts
409018000223	FRP 1210 REAR PNEUMATIC BOX ASSY	TATA spare parts
409018000227	MCV FRP BUMPER WIT FOGLAMP ASSY	TATA spare parts
409018000229	DASHBOARD ASSY	TATA spare parts
409018000230	FRP REAR BUMPER ASSY- LHD	TATA spare parts
409018000233	FRP ENGINE HOOD ASSEMBLY	TATA spare parts
409018000245	MCV FRP GEAR FINISHING COVER	TATA spare parts
409018000246	MCV GEAR FINISHING COVER ASSEMBLY	TATA spare parts
409018000251	ENGINE HOOD GLOVE BOX FLAP ASSEMBLY	TATA spare parts
409018000275	MCV FUSEBOX ASSY	TATA spare parts
409018000276	CBCU COVER FRP	TATA spare parts
409018000277	BRTS DOOR BOX ASSY_1350	TATA spare parts
409018000279	FRP FRONT BUMPER 372 ASSEMBLY	TATA spare parts
409018000293	REAR DOOR BOX FOR RESLF SOTRA	TATA spare parts
409018000294	FRONT DOOR BOX FOR RESLF SOTRA	TATA spare parts
409018000295	FRONT DOOR BOX FOR LPO1621_AMRITSAR	TATA spare parts
409018000324	ROOF MARKER LAMP SUPP PLATE ASSY-RH	TATA spare parts
409018000325	ROOF MARKER LAMP SUPP PLATE ASSY	TATA spare parts
409018010205	FRONT FACE & FLAP ASSY BS6	TATA spare parts
409018010207	DASHBOARD & ENG HOOD ASSLY BS6	TATA spare parts
409018010208	DASHBOARD & EH ASSLY BS6	TATA spare parts
409018100103	R.H. INTERNAL SWITCH COVER FOR 1621 AJL	TATA spare parts
409018100201	FRP FRONT INNER SW	TATA spare parts
409018100202	REAR EXT FACE WITH W/S REINFORCEMENT	TATA spare parts
409018100214	RP LH A-PILLAR FOR LPO1621_BRTS	TATA spare parts
409018100217	BRTS DOOR BOX ATTACHMENT COVER LH	TATA spare parts
409018100218	BRTS DOOR BOX ATTACHMENT COVER RH	TATA spare parts
409018100223	FRP WHEEL ARCH FINISHING COVER	TATA spare parts

409018200101	ABS LPO 1621/1620 A-PILLAR RH	TATA spare parts
409018200102	ABS LPO 1621/1620 A-PILLAR LH	TATA spare parts
409018300404	THERMOCOL 40MM THK	TATA spare parts
409018500201	GEAR FINISHING SUPPORT BRACKET	TATA spare parts
409020100201	3-MM STICKING ASPHALTIC LAMINATED	TATA spare parts
409020100202	ISO 25 ART CUSTIC W/ MASTIQUE BARRIER	TATA spare parts
409020100205	12.5 THK 610MM WIDE CERAMIC FIBRE 128KG	TATA spare parts
409020100207	REAR BACK SIDE INSULATION	TATA spare parts
409020100208	ACCOSOUND NVH ALP(1000X1000X20MMTHK.)	TATA spare parts
409020100303	INSULATION	TATA spare parts
409021000201	DRIVER POST SIDE FINISHING ASSY	TATA spare parts
409021000202	WHEELHOUSING ASSEMBLY RH	TATA spare parts
409021000203	WHEELHOUSING ASSEMBLY LH	TATA spare parts
409021000204	DRIVER POST STEP ASSEMBLY	TATA spare parts
409021000207	DRIVER POST STEP ASSY.(NEW DTC)	TATA spare parts
409021000223	FRONT STEP ASSY	TATA spare parts
409021100201	DRIVER FOOT STEP	TATA spare parts
409021500201	DRIVER POST SIDE CLOSING PLATE	TATA spare parts
409021500202	WHEEL HOUSE CLOSING COVER	TATA spare parts
409021500203	WHEEL HOUSE CLOSING COVER	TATA spare parts
409021500204	WHEEL HOUSE CLOSING COVER (RH)	TATA spare parts
409021500205	WHEEL HOUSE CLOSING COVER	TATA spare parts
409021500206	WHEEL HOUSE CLOSING COVER	TATA spare parts
409021500207	WHEEL HOUSE CLOSING COVER	TATA spare parts
409021500208	WHEEL HOUSE CLOSING COVER	TATA spare parts
409021500209	WHEEL HOUSE CLOSING COVER	TATA spare parts
409021500210	WHEEL HOUSE CLOSING COVER	TATA spare parts
409021500211	WHEEL HOUSE CLOSING COVER	TATA spare parts
409021500213	WHEEL HOUSE CLOSING COVER R.H TOP - MODI	TATA spare parts
409021500214	WHEEL HOUSE CLOSING COVER R.H FRONT	TATA spare parts
409021500215	WHEEL HOUSE CLOSING COVER R.H REAR	TATA spare parts
409021500220	REAR CLOSING WHEEL FLAP SHEET(RH)	TATA spare parts
409021500221	WHEEL FLAP SHEET	TATA spare parts
409021500223	FRONT WHEEL HOUSE CLOSING COVER L.H TOP	TATA spare parts
409021500224	FRONT WHEEL HOUSE CLOSING COVER L.H	TATA spare parts
409021500225	FRONT WHEEL HOUSE CLOSING COVER L.H	TATA spare parts
409021500226	MUD FLAP SHEET(LH)	TATA spare parts
409021500227	MUD FLAP SHEET(RH)	TATA spare parts
409021700201	DRIVER POST SIDE CLOSING PLATE	TATA spare parts
409021700202	DRIVER POST SIDE CLOSING PLATE	TATA spare parts
409021700203	DRIVER POST SIDE CLOSING PLATE	TATA spare parts
409021800401	OVAL HEAD SCRW M8X1.25X25X25	TATA spare parts
409022000102	CNG PIPING PASSAGEWAY ASSEMBLY	TATA spare parts
409022000201	AIR INTAKE BOX ASSEMBLY	TATA spare parts
409022000208	INSPECTION COVER CONTOUR ASSY.	TATA spare parts
409022000209	INSPECTION COVER CONTOUR ASSY. BEHIND DR	TATA spare parts
409022000210	FLOOR INSPECTION CONTOUR ASSY.	TATA spare parts

409022000211	FLOOR INSPECTION CONTOUR ASSY.	TATA spare parts
409022000212	FLOOR INSPECTION CONTOUR ASSY.	TATA spare parts
409022000213	FLOOR INSPECTION CONTOUR ASSY.	TATA spare parts
409022000214	FLOOR INSPECTION CONTOUR ASSY.	TATA spare parts
409022000215	AIR INTAKE BOX ASSY.	TATA spare parts
409022000217	FLOOR INSPECTION CONTOUR ASSEMBLY	TATA spare parts
409022000219	INSPECTION COVER CONTOUR ASSEMBLY	TATA spare parts
409022000220	INSPECTION COVER CONTOUR ASS.BEHIND DRIV	TATA spare parts
409022000221	FLOOR INSPECTION CONTOUR ASSEMBLY	TATA spare parts
409022000222	FLOOR INSPECTION CONTOUR ASSEMBLY	TATA spare parts
409022000223	FLOOR INSPECTION CONTOUR ASSEMBLY	TATA spare parts
409022000224	FLOOR INSPECTION CONTOUR ASSEMBLY	TATA spare parts
409022000233	FLOOR INSPECTION CONTOUR ASSEMBLY	TATA spare parts
409022000234	AIR INTAKE BOX ASSY	TATA spare parts
409022000239	FLOOR INSPECTION CONTOUR ASSEMBLY	TATA spare parts
409022100201	RECTAGUALAR PIPE	TATA spare parts
409022200301	BUSH FOR CUTOUT	TATA spare parts
409022700204	PLATE FOR ELEC. CABLE AT REAR PLATFORM	TATA spare parts
409022700312	MS PLATE	TATA spare parts
409023000101	SEAT ASSEMBLY	TATA spare parts
409023000201	SEAT COUPLING SUPPORT ASSEMBLY (REAR PLA	TATA spare parts
409023000204	RH 2 SEAT 460CH SM1L AR BLUE REX	TATA spare parts
409023000207	REAR 1 SEAT 460CH 2LM AR LB BLUE REX	TATA spare parts
409023000208	LH 2 SEAT 460CH SM1L AR BLUE REX	TATA spare parts
409023000218	H 2 PLASTIC SEAT 360CH SM1L LB	TATA spare parts
409023000219	RH 2 PLASTIC SEAT 205CH SM1L AR	TATA spare parts
409023000220	RH 2 PLASTIC SEAT 410CH SM1L AR	TATA spare parts
409023000221	R 2 PLASTIC SEAT 460CH 2LM AR	TATA spare parts
409023000222	LH 2 PLASTIC SEAT 410CH SM1L AR	TATA spare parts
409023000223	LH 2 PLASTIC SEAT 205CH SM1L AR	TATA spare parts
409023000224	LH 1 PLASTIC SEAT 410CH SM1L AR	TATA spare parts
409023000225	LH 1 PLASTIC SEAT 240CH SM1L LB	TATA spare parts
409023000236	LH 2 SEAT 460CH 235SM1L AR& LB	TATA spare parts
409023000237	RH 2 SEAT 460CH 235SM1L AR& LB	TATA spare parts
409023000251	RH 2 PLASTIC SEAT 410CH_SM1L_AR_WH	TATA spare parts
409023000252	LH 2 PLASTIC SEAT 410CH_SM1L_AR_WH	TATA spare parts
409023000253	LH 2 PLASTIC SEAT 360CH_SM1L_AR_WH	TATA spare parts
409023000301	STAINLEY LEATHER FOR PASSENGER SEAT	TATA spare parts
409023000302	STAINLEY LEATHER FOR DRIVER SEAT	TATA spare parts
409023000328	RH 2 SEAT 460CH SM1L AR BLUE REX CVG	TATA spare parts
409023000329	REAR 1 SEAT 460CH 2LM AR LB BLUE REX CVG	TATA spare parts
409023000330	LH 2 SEAT 460CH SM1L AR BLUE REX CVG	TATA spare parts
409023000331	RH 2 PLASTIC SEAT 360CH SM1L LB CVG	TATA spare parts
409023000332	RH 2 PLASTIC SEAT 205CH SM1L AR CVG	TATA spare parts
409023000333	RH 2 PLASTIC SEAT 410CH SM1L AR CVG	TATA spare parts
409023000334	RH 2 PLASTIC SEAT 460CH 2LM AR CVG	TATA spare parts
409023000335	LH 2 PLASTIC SEAT 410CH SM1L AR CVG	TATA spare parts

409023000337	LH 1 PLASTIC SEAT 410CH SM1L AR CVG	TATA spare parts
409023000338	LH 1 PLASTIC SEAT 240CH SM1L LB CVG	TATA spare parts
409023000339	LH 2 SEAT 460CH 235SM1L AR CVG LB	TATA spare parts
409023000340	RH 2 SEAT 460CH 235SM1L AR CVG LB	TATA spare parts
409023000342	RH 2SEAT 460CH SM1L 850W/O AR PLSC	TATA spare parts
409023000343	2 SEATER WH 850W 2LGM	TATA spare parts
409023000344	LH 2SEAT 460CH SM1L 850W/O AR PLSC	TATA spare parts
409023000346	RH 2SEAT 500CH 850W PMS 1SM1LG	TATA spare parts
409023000347	LH 2SEAT 500CH 850W PMS 1SM1LG	TATA spare parts
409023000365	RH 2SEAT_460CH_2LM 573MM_850W_PMS(CVG	TATA spare parts
409023000389	RR 2 SEAT_2LM SYM_PMS 460CH_BLUE FAB_CVG	TATA spare parts
409023000430	RH 2SEAT_360CH_83SM1L_WH_LP_AR_PMS	TATA spare parts
409023000431	RH 2SEAT_360CH_83SM1L_WH_AR_PMS	TATA spare parts
409023000432	RH_2SEAT_460CH_221SM1L_850_PM	TATA spare parts
409023000433	RH 2SEAT_200CH_WH_68SM1L_850_PMS	TATA spare parts
409023000434	RH 2SEAT_412CH_WH_68M1L_PMS_LB	TATA spare parts
409023000435	REAR MID SEAT_460CH_2L232_LB_PMS	TATA spare parts
409023000436	LH_2SEAT_460CH_221SM1L_850_PMS	TATA spare parts
409023000437	LH_2SEAT_412CH_WH_68SM1L_PMS_LB	TATA spare parts
409023000438	LH_2SEAT_200CH_WH_68SM1L_850_PMS	TATA spare parts
409023000439	LH_1SEAT_200CH_68SM1L_WH_LB_AR_PMS	TATA spare parts
409023000462	ARM REST ASSY RH SEAT_PMS_CVG	TATA spare parts
409023000512	1 SEATER LH 1 LEG MOUNT WITH ARM REST	TATA spare parts
409023000513	1SEATER RH 1 LEG MOUNT WITH ARM REST	TATA spare parts
409023000514	2 SEATER LH 1 LEG MOUNT WITH ARM REST	TATA spare parts
409023000515	2 SEATER RH 1 LEG MOUNT WITH ARM REST	TATA spare parts
409023000516	2 SEAT LH 1 LEG MOUNT ARM REST LAP BELT	TATA spare parts
409023000517	2 SEAT RH 1 LEG MOUNT ARM REST LAP BELT	TATA spare parts
409023000518	2 SEAT LH 2 LEG MOUNT ARM REST LAP BELT	TATA spare parts
409023000519	2 SEAT RH 2 LEG MOUNT-ARM REST-LAP BELT	TATA spare parts
409023000520	2 REAR SEAT LH & RH 2 LEG MOUNT LAP BELT	TATA spare parts
409023000521	2 SEATER REAR 2 LEG MOUNT; REAR LEG BELT	TATA spare parts
409023000612	2RH 2LM 155C860W AR LB WA PMS PN	TATA spare parts
409023000613	2LH SM1L 460C890W AR LB PMS PN	TATA spare parts
409023000614	2RH SM1L 460C890W AR LB PMS PN	TATA spare parts
409023000615	2RH SM1L 460C890W AR PMS PN	TATA spare parts
409023000616	2LH/RH 2LM 155C790W RLB PMS PN	TATA spare parts
409023000617	2RM 2LM 155C790W LB RLB PMS PN	TATA spare parts
409023000618	3LH SM2L 460C1220W LB PMS PN	TATA spare parts
409023000619	3LH SM2L 460C1220W LB PMS PN	TATA spare parts
409023000620	2LH SM1L 460C890W AR PMS PN	TATA spare parts
409023000622	2RH SM1L 460C810W PMS PN	TATA spare parts
409023000623	3LH SM2L 460C1220W PMS PN	TATA spare parts
409023000624	2LH SM1L 460C810W LB PMS PN	TATA spare parts
409023000625	2RH SM1L 460C810W LB PMS PN	TATA spare parts
409023010291	2RH 2LM 155C850W AR LP TM	TATA spare parts
409023010292	2RH 2LM 430C850W AR LP TM	TATA spare parts

409023010293	2RH 2LM 430C850W AR TM	TATA spare parts
409023010294	2RH 2LM 125C410W LB TM	TATA spare parts
409023010295	2RH 2LM 125C850W AR TM	TATA spare parts
409023010296	2LH 2LM 125C850W AR TM	TATA spare parts
409023010297	2LH 2LM 430C850W AR TM	TATA spare parts
409023010298	2LH 2LM 430C850W AR LP TM	TATA spare parts
409023010299	2LH 2LM 155C850W AR LP TM	TATA spare parts
409023020201	2RH 2LM 430C880W AR LB TM	TATA spare parts
409023020202	2LH 2LM 430C880W AR LB TM	TATA spare parts
409023020203	2RH 2LM 430C880W AR LB TM	TATA spare parts
409023020204	2RH 2LM 430C880W AR TM	TATA spare parts
409023100210	ASSY 2S - 460 SIDE WALL MTG LH WITH F A	TATA spare parts
409023100211	ASSY 2S - 460 SIDE WALL MTG RH WITH F A	TATA spare parts
409023100212	ASSY 2S - 460 SIDE WALL MTG LH WITH F A/	TATA spare parts
409023100213	ASSY 2S - 460 SIDE WALL MTG RH WITH F A/	TATA spare parts
409023100216	ASSY 2S - DICKY MTG RH WITH F A/R & SEAT	TATA spare parts
409023100217	ASSY 2S DICKY MTG	TATA spare parts
409023100218	ASSY 1S DICKY MTG WITH SEAT BELT	TATA spare parts
409023100224	ASSY 2S -460SIDE WALL MTG LH AR	TATA spare parts
409023100225	ASSY 2S -460SIDE WALL MTG RH AR	TATA spare parts
409023100226	ASSY 2S -460SIDE WALL MTG LHARSB	TATA spare parts
409023100227	ASSY 2S -460SIDE WALL MTG RH AR SB	TATA spare parts
409023100228	ASSY 2S -DICKY MTG RH WITH RH AR SB	TATA spare parts
409023100229	ASSY 2S DICKY MTG	TATA spare parts
409023100230	ASSY 1S DICKY MTG WITH SB	TATA spare parts
409023100244	ASSY 1S DICKY MTG WITH SB (RED)	TATA spare parts
409023100245	ASSY 2S DICKY MTG - (RED)	TATA spare parts
409023100246	ASSY 2S-DICKY MTG RH WITH RH AR SB	TATA spare parts
409023100247	ASSY2S-460SIDE WALL MTG RH AR SB-(RED)	TATA spare parts
409023100248	ASSY2S-460SIDE WALL MTG LH AR SB(RED)	TATA spare parts
409023100249	ASSY2S-460SIDE WALL MTG RH AR (RED)	TATA spare parts
409023100250	ASSY2S-460SIDE WALL MTG LH AR (RED)	TATA spare parts
409023100265	2S- SEAT 460 LH WALL MTG	TATA spare parts
409023100266	2S- SEAT 460 RH WALL MTG	TATA spare parts
409023100267	2S-SEAT 460 LH WALL MTG	TATA spare parts
409023100268	2S-SEAT 460 RH WALL MTG	TATA spare parts
409023100269	2S-SEAT DICKY MTG RH	TATA spare parts
409023100270	2S-SEAT DICKY MTG	TATA spare parts
409023100271	1S-SEAT DICKY MTG	TATA spare parts
409023100359	REAR MID 1 SEAT_LP_DLX	TATA spare parts
409023100403	ASSY 1S DICKY MTG WITH SB	TATA spare parts
409023100404	ASSY 2S DICKY MTG 850	TATA spare parts
409023100405	ASSY 2S -850 SIDE WALL MTG LH.SB	TATA spare parts
409023100406	ASSY 2S-850 SIDE WALL MTK. RH	TATA spare parts
409023100407	ASSY 2S 850 SIDE WALL MTG.RH.SB	TATA spare parts
409023100408	ASSY 2S -DICKY MTG RH WITH RH.SB 850	TATA spare parts
409023100409	ASSY 2S -850 SIDE WALL MTG LH	TATA spare parts

409023100441	SEAT 2_STR_HB_DICKY_810_RH_AR_LB_BLUE_RE	TATA spare parts
409023200236	RH TWIN SEATER _HB_850W	TATA spare parts
409023200237	LH TWIN SEATER_HB_850W	TATA spare parts
409023200239	RH TWIN SEATER_AR_HB_850W	TATA spare parts
409023200240	LH CO-DRIVER SEAT_AR	TATA spare parts
409023200251	2 SEATER WH 810W 2LGM	TATA spare parts
409023200253	LH REAR TWIN SEATER (HB_620)	TATA spare parts
409023200254	RH REAR TWIN SEATER (HB_620)	TATA spare parts
409023200271	LH 2SET 460CH 221 SM1L 850 PMS LB	TATA spare parts
409023200272	RH 2SET 460CH 221 SM1L 850 PMS LB	TATA spare parts
409023200321	LH 2 SEATER_500CH_850W_PMS_1SM1LG_AR_C	TATA spare parts
409023200322	LH 2 SEATER_ON WH_850W_2LGM_AR_CVG	TATA spare parts
409023200323	RH 2 SEATER_ON WH_850W_2LGM_AR_CVG	TATA spare parts
409023200324	RH 2 SEATER_460CH_SM1L_850W_AR_CVG	TATA spare parts
409023200325	LH 2 SEATER_460CH_SM1L_850W_AR_CVG	TATA spare parts
409023200326	RH 2 SEATER_500CH_850W_PMS_1SM1LG_AR_C	TATA spare parts
409023200367	RH 2 SEAT_360CH_LB_2LM 573MM_850W (CVG)	TATA spare parts
409023200368	LH 1 SEAT_360CH_LB_2LM 232MM_405W(CVG)	TATA spare parts
409023200369	REAR_2SEAT_460CH_LB_810W_2LM_CVG	TATA spare parts
409023300207	ARM REST ASSY LH SEAT_PMS_CVG	TATA spare parts
409023800201	ASSY 2SEATER FRAME WITH AR LH	TATA spare parts
409023800202	ASSY 2SEATER FRAME WITH AR RH	TATA spare parts
409023800203	ASSY 2SEATER FRAME AR&SB RH	TATA spare parts
409023800204	ASSY 2SEATER FRAME AR&SB LH	TATA spare parts
409023900202	SAFETY BELT 3 POINT	TATA spare parts
409023900203	REAR SEATS SAFETY BELT	TATA spare parts
409024000101	BATTERY FLAP	TATA spare parts
409024000102	RADIATOR FLAP	TATA spare parts
409024000103	ENGINE (AIR FILTER) SIDE HINGED DOOR ASS	TATA spare parts
409024000105	ENGINE SIDE FLAP	TATA spare parts
409024000125	BATTERY FLAP ASSY	TATA spare parts
409024000127	BATTERY FLAP ASSY(CNG BUS)	TATA spare parts
409024000133	SIDE FLAP ASSY	TATA spare parts
409024000162	BATTERY FLAP ASSY	TATA spare parts
409024000167	AIR FILTER FLAP	TATA spare parts
409024000178	AIR FILTER FLAP ASSY	TATA spare parts
409024000182	AIR FILTER FLAP ASSY	TATA spare parts
409024000183	MAINTENANCE FLAP ASSY	TATA spare parts
409024000184	BATTERY FLAP ASSY.1623_DI	TATA spare parts
409024000188	BATTERY FLAP ASSY	TATA spare parts
409024000189	CBCU FLAP ASSY	TATA spare parts
409024000204	ENGINE SIDE HINGE	TATA spare parts
409024000207	FUEL TANK NOZZLE ASSEMBLY	TATA spare parts
409024000208	HINGED DOORS PISTON SUPPORT ASSEMBLY	TATA spare parts
409024000209	HINGED DOORS PISTON COUPLING BOLT ASMB.	TATA spare parts
409024000210	HINGED DOORS PISTON SUPPORT ASSEMBLY	TATA spare parts
409024000212	FLAP JAMB ASSY	TATA spare parts



409024000213	ENGINE SIDE FLAP ASSEMBLY	TATA spare parts
409024000215	ENGINE (CNG VALVE) SIDE HINGED DOOR ASSY	TATA spare parts
409024000216	ENGINE(AIR FILTER) SIDE HINGED FLAP ASSY	TATA spare parts
409024000220	ENGINE SIDE FLAP ASSY.	TATA spare parts
409024000242	AIR FILTER SIDE FLAP ASSY	TATA spare parts
409024000243	BATTERY FLAP ASSY	TATA spare parts
409024000268	FLAP UPHOLDING ROD ASSEMBLY	TATA spare parts
409024000309	FUEL TANK NOZZLE ASSY.	TATA spare parts
409024000366	BATTERY FLAP ASSY	TATA spare parts
409024000369	FUEL TANK NOZZLE ASSY - LOCK PROVISION	TATA spare parts
409024010109	CNG FLAP ASSY	TATA spare parts
409024010203	SIDE FLAP AIR FOR AIR DRIER	TATA spare parts
409024010204	DIESEL TANK FLAP ASSY	TATA spare parts
409024010214	AIR FILTER FLAP ASSY_590X450	TATA spare parts
409024010216	BATTERY FLAP ASSY_630X395MM	TATA spare parts
409024010228	SHUTTER UPHOLDING STALK ASSEMBLY LH SIDE	TATA spare parts
409024010231	LOCK HOUSING	TATA spare parts
409024010239	AUX DRIVE PANEL & FRAME ASSY	TATA spare parts
409024010240	BATTERY FRAME & PANEL ASSY 515X1038 APP	TATA spare parts
409024010241	BCS PANEL & FRAME ASSY 595X620	TATA spare parts
409024010242	CHARGER FLAP PANEL & FRAME ASSY	TATA spare parts
409024010243	FRAME & PANEL FITMENT ASSY	TATA spare parts
409024010246	CYLINDER PIVOT ASSEMBLY RH	TATA spare parts
409024010248	CYLINDER PIVOT ASSEMBLY	TATA spare parts
409024010328	SERVICE FLAP PANEL ASSY 315X230	TATA spare parts
409024500101	FLAP LATCH COUPLING	TATA spare parts
409024500201	FLAP HINGE SHIM	TATA spare parts
409024500202	SUPPORTING PLATE	TATA spare parts
409024500203	COUPLING PLATE	TATA spare parts
409024500205	BATTERY FLAP PISTON COUPLING PLATE	TATA spare parts
409024500308	L SHAPE PLATE	TATA spare parts
409024700202	MS PLATE 4.25MM THK_100X100	TATA spare parts
409024700203	FLAP LATCH COUPLING	TATA spare parts
409024700204	FLAP LOCK PLATE _VETICAL AXIS OPENINGS	TATA spare parts
409024990201	LOCK FOR RAD. FLAP ASSY	TATA spare parts
409024990203	GAS PISTON 11KG	TATA spare parts
409024990204	GAS PISTON 27KG	TATA spare parts
409025000101	REAR FLAP ASSY	TATA spare parts
409025000103	REAR FLAP ASSY	TATA spare parts
409025000107	PISTA GREEN FRONT FLAP ASSY	TATA spare parts
409025000203	ENGINE SHUTTER INT. HINGE ASSEMBLY	TATA spare parts
409025000204	ENGINE FLAP PISTON SUPPORT BASE ASSEMBL	TATA spare parts
409025000205	ENGINE FLAP SAFETY LOCK SUPP. BASE ASS.	TATA spare parts
409025000208	FRONT GRILLE MECHANISM ASSEMBLY	TATA spare parts
409025000209	ROD COUPLING BOLT ASSEMBLY	TATA spare parts
409025000211	FLAP STOPPER ASSY.	TATA spare parts
409025000216	HINGE MECHANISM LH SIDE	TATA spare parts

409025000217	HINGE MECHANISM RH SIDE	TATA spare parts
409025000219	FLAP SUPP. ASSY.	TATA spare parts
409025000239	REAR BATTERY FLAP LOCK ASSY	TATA spare parts
409025000240	REAR TOP FLAP LOCK ASSY	TATA spare parts
409025000241	LOCK ROD & GAS PISTON BKT	TATA spare parts
409025000310	FRP FLAP ASSY	TATA spare parts
409025000320	FRP FLAP ASSY.	TATA spare parts
409025200201	MS ROD DIA 8	TATA spare parts
409025400301	FRONT FRP FLAP LE GEN-1	TATA spare parts
409025600204	HINGED DOORS LATCH COVER	TATA spare parts
409025600206	HINGED DOORS LATCH ASSEMBLY	TATA spare parts
409025700203	Z-SHAPED SUPPORT WITH HOLES	TATA spare parts
409025700204	FRONT GRILLE OPENING SUPPORT	TATA spare parts
409025700218	REINFORCEMENT BRACKET	TATA spare parts
409025700219	BOTTOM JAMB ROD BKT	TATA spare parts
409025700220	LIMIT SWITCH BRACKET	TATA spare parts
409025700224	GAS PISTON REINFORCEMENT	TATA spare parts
409025700225	BUDJET LOCK CATCHER	TATA spare parts
409025700226	BOOTOM JAMB ROD BKT	TATA spare parts
409025800201	CLAMP (FRONT FLAP STAY ROD)	TATA spare parts
409025990301	GAS PISTON	TATA spare parts
409026000103	FRONT FLOOR STRUCTURE ASSEMBLY	TATA spare parts
409026000201	BEAM VERTICAL SUPPORT ASSY.	TATA spare parts
409026000202	REAR PLATFORM CROSSMEMBER ASSEMBLY	TATA spare parts
409026000204	REAR PLATFORM CROSS MEMBER ASSY	TATA spare parts
409026100201	SQUARE TUBE	TATA spare parts
409026100203	G.I. RECTANGULAR TUBE	TATA spare parts
409026100204	RECTANGULAR TUBE	TATA spare parts
409026100205	50X30X1.55 RECTANGULAR STEEL TUBE	TATA spare parts
409026100206	SQUARE TUBE	TATA spare parts
409026100208	RECTANGULAR TUBE	TATA spare parts
409026100209	G.I. RECTANGULAR TUBE	TATA spare parts
409026100210	RECTANGULAR TUBE	TATA spare parts
409026100212	RECTANGULAR TUBE	TATA spare parts
409026100213	INTERMID. CROSSMEMBER OF THE REAR PLATF.	TATA spare parts
409026100214	INTERMID. CROSSMEMBER OF THE REAR PLATF.	TATA spare parts
409026100215	REAR PLATFORM STRUCTURE TUBE	TATA spare parts
409026100216	REAR PLATFORM STRUCTURE TUBE	TATA spare parts
409026100217	30 X 30 X 1.55 SQUARE STEEL TUBE	TATA spare parts
409026100218	30 X 30 X 1.55 SQUARE STEEL TUBE	TATA spare parts
409026100219	SQUARE STEEL TUBE 30 X 30 X 1.55	TATA spare parts
409026100220	50 X 30 X 1.55 RECTANGULAR STEEL TUBE	TATA spare parts
409026100221	30 X 30 X 1.55 SQUARE STEEL TUBE	TATA spare parts
409026100222	60 X 40 X 2.70 RECTANGULAR STEEL TUBE	TATA spare parts
409026100223	60 X 40 X 2.70 RECTANGULAR STEEL TUBE	TATA spare parts
409026100224	40 X 40 X 1.95 SQUARE STEEL TUBE	TATA spare parts
409026100225	40 X 40 X 1.95 SQUARE STEEL TUBE	TATA spare parts

409026100226	60 X 40 X 2.70 RECTANGULAR STEEL TUBE	TATA spare parts
409026100227	60 X 40 X 2.70 RECTANGULAR STEEL TUBE	TATA spare parts
409026100228	60 X 40 X 2.70 RECTANGULAR STEEL TUBE	TATA spare parts
409026100229	30 X 30 X 1.55 SQUARE STEEL TUBE	TATA spare parts
409026100230	30 X 30 X 1.55 SQUARE STEEL TUBE	TATA spare parts
409026100231	50 X 30 X 1.55 RECTANGULAR STEEL TUBE	TATA spare parts
409026100232	30 X 30 X 1.55 SQUARE STEEL TUBE	TATA spare parts
409026100233	30 X 30 X 1.55 SQUARE STEEL TUBE	TATA spare parts
409026100234	30 X 50 X 1.55 RECTANGULAR STEEL TUBE	TATA spare parts
409026100235	30 X 30 X 1.55 SQUARE STEEL TUBE	TATA spare parts
409026100236	30 X 30 X 1.55 SQUARE STEEL TUBE	TATA spare parts
409026100237	50 X 30 X 1.55 RECTANGULAR STEEL TUBE	TATA spare parts
409026100238	30 X 30 X 1.55 SQUARE STEEL TUBE	TATA spare parts
409026100241	50 X 30 X 1.55X317LN RECTANGULAR STEEL T	TATA spare parts
409026100242	80X40 X 1.55X100LN RECTANGULAR STEEL TUB	TATA spare parts
409026100243	30X30X1.55 SQUARE STEEL TUBE	TATA spare parts
409026100266	G.I. RECT. TUBE 50X50X3.75	TATA spare parts
409026100267	GI RECTANGULAR TUBE	TATA spare parts
409026100268	GI RECTANGULAR TUBE	TATA spare parts
409026100269	G.I. RECT. TUBE 50X50X3.75X168	TATA spare parts
409026100271	G.I TUBE	TATA spare parts
409026100295	GI TUBE 80X50X3.75	TATA spare parts
409026500201	PROFILE	TATA spare parts
409026500202	PROFILE	TATA spare parts
409026500203	PROFILE	TATA spare parts
409026500204	PROFILE	TATA spare parts
409026500205	PROFILE OF REAR PLATFORM REINFORCEMENT	TATA spare parts
409026500206	PROFILE OF REAR PLATFORM REINFORCEMENT	TATA spare parts
409026500207	PROTECTION PLATE OF THE ENGINE	TATA spare parts
409026500208	PROTECTION PLATE OF THE ENGINE	TATA spare parts
409026500209	PROTECTION PLATE OF THE ENGINE	TATA spare parts
409026500210	PROTECTION PLATE OF THE ENGINE	TATA spare parts
409026500211	PROFILE OF REAR PLATFORM REINFORCEMENT	TATA spare parts
409026500212	PROFILE OF REAR PLATFORM REINFORCEMENT	TATA spare parts
409026500229	U PROFILE FOR REINFORCEMENT(L 432)	TATA spare parts
409026500230	U PROFILE FOR REINFORCEMENT(L 221)	TATA spare parts
409026500231	U PROFILE FOR REINFORCEMENT(L 696)	TATA spare parts
409026500232	U PROFILE FOR REINFORCEMENT	TATA spare parts
409026500233	FRONT RAMP SHEET (760X1210X1.5 THK)	TATA spare parts
409026500234	STEEL PLATES	TATA spare parts
409026500235	STEEL PLATES	TATA spare parts
409026500246	M.S PLATE 200X30X4.25THK.	TATA spare parts
409026500247	PROTECTION PLATE OF THE ENGINE	TATA spare parts
409026500250	PROTECTION PLATE OF THE ENGINE	TATA spare parts
409026500251	PROTECTION PLATE OF THE ENGINE	TATA spare parts
409026500252	PROTECTION PLATE OF THE ENGINE	TATA spare parts
409026500253	PROTECTION PLATE OF THE ENGINE	TATA spare parts

409026500256	PROTECTION PLATE OF THE ENGINE	TATA spare parts
409026500257	PROTECTION PLATE OF THE ENGINE	TATA spare parts
409026700201	UPPER BASE AISLE BASEBOARD	TATA spare parts
409026700202	UPPER BASE AISLE BASEBOARD	TATA spare parts
409026700203	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409026700204	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409026700205	UPPER BASE AISLE BASEBOARD	TATA spare parts
409026700206	UPPER BASE AISLE BASEBOARD	TATA spare parts
409026700207	UPPER BASE AISLE BASEBOARD	TATA spare parts
409026700208	REAR RENFORCEMENT CROSSMEMBER OF THE U	TATA spare parts
409026700209	REAR RENFORCEMENT CROSSMEMBER OF THE U	TATA spare parts
409026700210	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409026700211	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409026700213	PROTECTION PLATE OF THE ENGINE	TATA spare parts
409026700214	6.30 STEEL PLATES (1/4)	TATA spare parts
409026700215	6.30 STEEL PLATES (1/4)	TATA spare parts
409026700220	STEEL PLATES 50X317X6.3 THK	TATA spare parts
409026700221	STEEL PLATES 432X100X6.3THK	TATA spare parts
409026700222	STEEL PLATES 426X100X6.3THK	TATA spare parts
409026700223	GI PLATE 120X310X0.95	TATA spare parts
409026700224	LADDER MOUNTING SUPPORT PLATE	TATA spare parts
409026700225	STEEL PLATE 100X290X6.3THK	TATA spare parts
409026700226	STEEL PLATE 100X95X6.3THK	TATA spare parts
409026700227	G.I. SHEET 345X235X0.95THK	TATA spare parts
409026700228	TRIANGLE GUSSET 60X60X3THK.	TATA spare parts
409026700235	GI SHEET	TATA spare parts
409026700236	GI SHEET	TATA spare parts
409026700239	GI RECTANGULAR TUBE	TATA spare parts
409027000102	FRONT FACE WITH FRP FOR L E CNG	TATA spare parts
409027000104	FRP FRONT FACE WITH PASTED WINDSHIELD	TATA spare parts
409027000105	FRP REAR FACE WITH PASTED WINDSHIELD	TATA spare parts
409027000107	FRP REAR FACE WITH ROUND TAIL LAMPS	TATA spare parts
409027000203	FRP MCV REAR FACE SPOILER ASSY	TATA spare parts
409027000207	FRP REARFACE WIT RLB AND W/O WINDSHIELD	TATA spare parts
409027000217	REAR FACE WITH BUMPER_EV_4X12	TATA spare parts
409027000225	REAR FACE_G3_2.34 BS6	TATA spare parts
409027000231	FRONT FACE AND FLAP ASSY EV 4X12	TATA spare parts
409027200201	FRONT FACE TOP PART	TATA spare parts
409027200202	FRONT FACE MIDDLE PART R.H. SIDE	TATA spare parts
409027200203	FRONT FACE MIDDLE PART L.H. SIDE	TATA spare parts
409027200204	FRONT FACE BOTTOM PART	TATA spare parts
409027300201	REAR FACE TOP PART	TATA spare parts
409027300202	REAR FACE MIDDLE PART	TATA spare parts
409027300203	REAR FACE R.H. TAIL SIDE PART	TATA spare parts
409027300204	REAR FACE L.H. TAIL SIDE PART	TATA spare parts
409027500201	FRONT FIBER REINFORCEMENT (HEAD LAMP)	TATA spare parts
409027500202	FRONT FIBER REINFORCEMENT	TATA spare parts

409027500203	REINFORCEMENT FOR BLINKERS	TATA spare parts
409028000201	DASHBOARD MULTIPLEX HARNESS - MCV	TATA spare parts
409028000204	DASHBOARD ELECTRIC HARNESS	TATA spare parts
409028000205	FUSE BOX UPPER FRONT HARNESS	TATA spare parts
409028000206	RH ROOF HARNESS	TATA spare parts
409028000207	LOWER ELECTRIC HARNESS	TATA spare parts
409028000210	KPIT W/H KIT ITS-09-032-D(MCV)	TATA spare parts
409028000218	DATA CABLES FOR DEST. BOARD	TATA spare parts
409028100103	LOWER HARNESS	TATA spare parts
409028100112	LOWER ELECTRIC HARNESS IVORY COAST	TATA spare parts
409028100114	STOP REQUEST W\H (MIDDLE & FRONT DOOR)	TATA spare parts
409028100201	LOWER ELECTRIC HARNESS	TATA spare parts
409028100202	SIDE MARKER LAMPS ELECTRIC HARNESS	TATA spare parts
409028100203	SIDE MARKER LAMPS ELECTRIC HARNESS	TATA spare parts
409028100204	SIDE MARKER LAMPS ELECTRIC HARNESS	TATA spare parts
409028100205	SIDE MARKER LAMPS ELECTRIC HARNESS	TATA spare parts
409028100206	SIDE MARKER LAMPS ELECTRIC HARNESS	TATA spare parts
409028100207	SIDE MARKER LAMPS ELECTRIC HARNESS	TATA spare parts
409028100208	SIDE MARKER LAMPS ELECTRIC HARNESS	TATA spare parts
409028100209	SIDE MARKER LAMPS ELECTRIC HARNESS	TATA spare parts
409028100210	RR ELECT HARNESS-ROOF MARKER LAMPS LH&RH	TATA spare parts
409028100211	LICENSE PLATE ELECTRIC HARNESS	TATA spare parts
409028100212	EMERGENCY DOOR ELECTRIC HARNESS	TATA spare parts
409028100215	HARNESS LOWER	TATA spare parts
409028100216	REAR ELECTRIC HARNESS	TATA spare parts
409028100225	STOP REQUEST HARNESS	TATA spare parts
409028100228	SIDE MARKER LAMP HARNESS A 5 SIDE	TATA spare parts
409028100249	COST REDUCTION_ HARNESS 600MM LED STRIP	TATA spare parts
409028200204	EMERGENCY SW& INTERFACE PIGTAIL	TATA spare parts
409028200304	CABLE SCU TO BDC	TATA spare parts
409028300101	UPPER FRONT MULTIPLEX HARNESS (MCV)	TATA spare parts
409028300102	POWER SUPPLY PIGTAIL MCV	TATA spare parts
409028300103	DASHBOARD MULTIPLEX HARNESS	TATA spare parts
409028300104	UPPER FRONT HARNESS	TATA spare parts
409028300106	ENGINE COMP. MAINTENANCE LIGHT PIGTAIL	TATA spare parts
409028300110	GROUND PIGTAIL	TATA spare parts
409028300111	DASHBOARD ELECTRIC HARNESS	TATA spare parts
409028300112	FUSE BOX-UPPER FRONT HARNESS	TATA spare parts
409028300113	DESTINATION BOARD ELECTRICAL HARNESS	TATA spare parts
409028300115	DASHBOARD MULTIPLEX HARNESS	TATA spare parts
409028300118	PIGTAIL FOR KPIT HEADSET	TATA spare parts
409028300119	DASHBOARD MUX HARNESS	TATA spare parts
409028300120	UPPER FRONT MUX HARNESS	TATA spare parts
409028300127	UPPER FRONT MULTIPLEX HARNESS ABS	TATA spare parts
409028300128	WIRE HARNESS KIT INBUILT GPS	TATA spare parts
409028300130	UPPER FRONT HARNESS(BOTH SIDE BRTS)	TATA spare parts
409028300201	UPPER FRONT ELECTRIC HARNESS	TATA spare parts

409028300202	DASHBOARD ELECTRIC HARNESS	TATA spare parts
409028300213	DASHBOARD ELE HARNESS (MASAT+CANR) AC	TATA spare parts
409028300215	HARNESS DASH BOARD	TATA spare parts
409028300216	HARNESS DASH BOARD	TATA spare parts
409028300217	HARNESS DASH BOARD	TATA spare parts
409028300218	DASHBOARD ELE HARNESS (CONT+HUIMIN+CANR)	TATA spare parts
409028300220	HARNESS UPPER FRONT	TATA spare parts
409028300225	UPPER FRONT ELE. HARNESS(CONT.+HUMI+CAN)	TATA spare parts
409028300232	FRONT NIGHT LAMP HARNESS	TATA spare parts
409028300233	REAR NIGHT LAMP HARNESS	TATA spare parts
409028300234	DASH BOARD NON MUX HUIMIN W/H	TATA spare parts
409028300236	EXHAUST FAN HARNESS	TATA spare parts
409028300241	DASHBOARD MUX HARNESS AC HUIMIN	TATA spare parts
409028300242	UPPER FRONT MUX HARNESS	TATA spare parts
409028300243	DASHBOARD MUX HARNESS NAC HUIMIN	TATA spare parts
409028300250	PIGTAIL FRONT FOG LAMP	TATA spare parts
409028300274	DASHBOARD MUX HARNESS NAC	TATA spare parts
409028300275	UPPERFRONT MUX HARNESS NAC	TATA spare parts
409028300276	WIRE HARNESS KIT ASSY	TATA spare parts
409028300291	UPPER FRONT ELE. W/H (MASAT+CANRUN)	TATA spare parts
409028300293	HARNESS UPPER FRONT	TATA spare parts
409028300311	STOP REQUEST HARNESS	TATA spare parts
409028300327	AIS140 CONTROLLER HARNESS BS6	TATA spare parts
409028300347	DRIVER USB CHARGER HARNESS	TATA spare parts
409028300348	FRONT ROOF MULTIPLEX HARNESS	TATA spare parts
409028300349	AIS140 EMERGENCY SW HARNESS_EV 4/12	TATA spare parts
409028300350	SCU POWER SUPPLU WH EV 4X12	TATA spare parts
409028400209	STOP REQUEST INVERTER HARNESS	TATA spare parts
409028500102	EMERGENCY STOP REQUEST HARNESS	TATA spare parts
409028500202	REAR ELECTRIC HARNESS (MCV) - RH	TATA spare parts
409028500205	MCV PIGTAIL LAMP HARNESS	TATA spare parts
409028500208	PIG TAIL MUX 2B LAMPS	TATA spare parts
409028500223	REAR ROOF MULTIPLEX_ W/H	TATA spare parts
409028500301	LOWER ELECTRICAL HARNESS G3 CNG BS6	TATA spare parts
409028700107	DASH CONTROL WIRING HARNESS	TATA spare parts
409028700108	ROOF MULTIPLEX HARNESS MCV-RH	TATA spare parts
409028700111	WIRING HARNESS FOR INTERCONNECTION	TATA spare parts
409028700112	HARNESS FOR TICKETING MACHINE	TATA spare parts
409028700113	LH ROOF MULTIPLEX HARNESS	TATA spare parts
409028700114	RH ROOF MULTIPLEX HARNESS	TATA spare parts
409028700115	SIDE LAMPS ELECTRIC HARNESS	TATA spare parts
409028700116	SIDE LAMPS ELECTRIC HARNESS-LH	TATA spare parts
409028700117	SIDE LAMPS ELECTRIC HARNESS-LH	TATA spare parts
409028700119	RH ROOF HARNESS	TATA spare parts
409028700120	FRONT DOOR CONNECTION PIGTAIL	TATA spare parts
409028700135	DASHBOARD MULTIPLEX HARNESS	TATA spare parts
409028700136	INTERNAL LIGHTING HARNESSç RH	TATA spare parts

409028700140	ROOF MULTIPLEX HARNESS	TATA spare parts
409028700143	RH ROOF MULTIPLEX W\H(BRTS BOTH SIDE)	TATA spare parts
409028700144	EMERGENCY DECLARATION PIGTAIL	TATA spare parts
409028700201	ROOFELECTRICHARNESS	TATA spare parts
409028700202	INTERNALLIGHTINGELECTRICHARNESS	TATA spare parts
409028700203	INTERNAL LIGHTING ELECTRIC HARNESS	TATA spare parts
409028700204	MAINTENANCE LIGHT ELECTRIC HARNESS	TATA spare parts
409028700210	HARNESS RH SIDE LAMP	TATA spare parts
409028700215	RH MUX INTERNAL LAMPS	TATA spare parts
409028700216	LH MUX INTERNAL LAMPS	TATA spare parts
409028700218	CANRUN TO MOBITEC CONVERSION HARNESS	TATA spare parts
409028700220	HARNESS ROOF	TATA spare parts
409028700221	HARNESS LH SIDE LAMP	TATA spare parts
409028700222	ROOF ELECTRIC HARNES(CONT+MASAT+MOBITEC	TATA spare parts
409028700224	ROOF ELECTRIC HARNESS (MASATS+CANRUN)	TATA spare parts
409028700225	HARNESS ROOF	TATA spare parts
409028700226	ROOF ELECTRIC HARNESS (CONTI+HUIM+CAN)	TATA spare parts
409028700227	ROOF EXAUST FAN PIGTAIL HARNESS	TATA spare parts
409028700230	ROOF MUX HARNESS	TATA spare parts
409028700231	DASHBOARD MULTIPLEX HARNESS	TATA spare parts
409028700232	UPPER FRONT MULTIPLEX HARNESS	TATA spare parts
409028700233	INTERNAL LIGHTING HARNESS - RH	TATA spare parts
409028700234	INTERNAL LIGHTING HARNESS - LH	TATA spare parts
409028700235	SIDE MARKER LAMPS MULTIPLEX HARNESS_MUX	TATA spare parts
409028700236	FUSE BOX POWER FEED CABLE	TATA spare parts
409028700254	INVERTER OUT PUT CONNECTION W/H	TATA spare parts
409028700268	INTERNAL LIGHTING HARNESS LH LED	TATA spare parts
409028700272	LED LAMP HARNESS - LH	TATA spare parts
409028700285	MAIN WIRING HARNESS	TATA spare parts
409028700301	INVERTER OUTPUT ELECTRICAL HARNESS	TATA spare parts
409028700303	DESTINATION BOARD HARNESS	TATA spare parts
409028700304	SIDE MARKER LAMPS MULTIPLEX HARNESS	TATA spare parts
409028700306	RH SIDE MUX HARNESS	TATA spare parts
409028700307	LH SIDE MUX HARNESS	TATA spare parts
409028700308	ROOF MUX HARNESS	TATA spare parts
409028700321	INTERNAL LIGHTING HARNESS - RH	TATA spare parts
409028700322	INTERNAL LIGHTING HARNESS - LH	TATA spare parts
409028700340	POWER ELECTRONIC ITS HARNESS UBS2	TATA spare parts
409028700344	RH ROOF MULTIPLEX HARNESS	TATA spare parts
409028700345	LH ROOF MULTIPLEX HARNESS WITH REAR DOOR	TATA spare parts
409028700381	AIS140 EMERGENCY SW HARNESS_M_DOOR_54V	TATA spare parts
409028700382	AIS140 EMERGENCY SW HARNES	TATA spare parts
409028700388	PIGTAIL HARNESS FOR 600MM LED STRIP	TATA spare parts
409028700389	PASSENGER FAN HARNESS_4NOS LH_4X12	TATA spare parts
409028700390	PASSENGER FAN HARNESS_7NOS LH_4X12	TATA spare parts
409029000102	WIPER ASSY	TATA spare parts
409029000104	WIPER MOTOR COVER ASSY	TATA spare parts

409029000135	WIPER ASSY INF DRG _RHD-24V	TATA spare parts
409029000207	PASSENGER DOOR EMERGENCY RESET SWITCH	TATA spare parts
409029000209	LHS WIPER ARM	TATA spare parts
409029000210	RHS WIPER ARM	TATA spare parts
409029000211	ASSY. WIPER LINK MECHANISM BS3/4	TATA spare parts
409029000212	WIPER MOTOR BS3/4	TATA spare parts
409029000213	WASHER ASSEMBLY WITH RESERVOIR	TATA spare parts
409029000214	FRONT FOG LAMP ASSEMBLY	TATA spare parts
409029000215	DASHBOARD SWITCHES ASSEMBLY	TATA spare parts
409029000225	HEADLAMP LOW BEAM RIGHT SIDE -24V	TATA spare parts
409029000226	HEADLAMP LOW BEAM LEFT SIDE -24V	TATA spare parts
409029000227	HEADLAMP HIGH BEAM LEFT SIDE -24V	TATA spare parts
409029000228	HEADLAMP HIGH BEAM RIGHT SIDE -24V	TATA spare parts
409029000229	HEADLAMP LOW BEAM RIGHT SIDE -24V LHD	TATA spare parts
409029000230	HEADLAMP LOW BEAM LEFT SIDE -24V LHD	TATA spare parts
409029000257	WIRING HARNESS AT INPUT FOR LED LUMINARY	TATA spare parts
409029000258	JUNCTION CAP	TATA spare parts
409029000259	SIDE CAP	TATA spare parts
409029000272	CAMERA SUPPORT BKT ASSY	TATA spare parts
409029000290	KPIT ITS KIT MOUD-II (RELE)	TATA spare parts
409029000291	KPIT ITS KIT MOUD-II	TATA spare parts
409029000292	SPEAKER WO GRILL	TATA spare parts
409029000302	BULB 10W 24V (FOR STOP REQUEST DISPLAY T	TATA spare parts
409029000303	LUMINOUS INDICATOR ASSEMBLY	TATA spare parts
409029000304	BUTTON SWITCH ASSY	TATA spare parts
409029000305	BUTTON SWITCH ASSY	TATA spare parts
409029000306	BUTTON SWITCH ASSY	TATA spare parts
409029000307	BUTTON SWITCH ASSY	TATA spare parts
409029000308	BUTTON SWITCH ASSY	TATA spare parts
409029000309	FUSE BOX BRACKET	TATA spare parts
409029000313	LUMAX REAR DEST.BOARD BRACKET(LH & RH)	TATA spare parts
409029000314	INTERNAL DEST. BOARD BKT(LH & RH)	TATA spare parts
409029000320	WIPER BLADE (CHLOROPRENE RUBBER) BS3/4	TATA spare parts
409029000401	DOOR CLOSING INDICATOR SUB-ASSEMBLY	TATA spare parts
409029000408	NOZZLE	TATA spare parts
409029000409	ARM CLIP	TATA spare parts
409029000410	CONNECTOR CAP	TATA spare parts
409029000411	BLACK PVC TUBE	TATA spare parts
409029000442	MICROPHONE (MODEL NO. - ALMIC 2121)	TATA spare parts
409029000443	REVERSE CAMERA (MODEL NO. - ALAC 2121)	TATA spare parts
409029000444	SURVEILLANCE CAMERA(MODEL NO.-ALAC 2121)	TATA spare parts
409029000445	BUS DRIVER CONSOLE(MODEL NO.-ALTM 2121)	TATA spare parts
409029000448	GPRS/GPS/WIFI ANTENNA	TATA spare parts
409029000450	SCU AMPLIFIER & POWER SUPPLY ASS	TATA spare parts
409029000491	DRIVER &CO DRIVER LAMP _GRENTO BS6	TATA spare parts
409029000530	FRONT ROOF MARKER LAMP _24V _G3	TATA spare parts
409029000601	SPEAKER ASSEMBLY WITH GRILL	TATA spare parts



409029100001	SIDE DIREC INDIC LAMP_LH_12V	TATA spare parts
409029100002	SIDE DIREC INDIC LAMP_RH_12V	TATA spare parts
409029100003	SIDE DIREC INDIC LAMP LH	TATA spare parts
409029100004	SIDE DIREC INDIC LAMP RH	TATA spare parts
409029100203	BULB IN SIDE BOTH BLINKER MARKER LAMP- 5	TATA spare parts
409029100205	FUSE BOX MAINTANACE BULB 21W/24V	TATA spare parts
409029100206	BULB IN ROOF MARKER LAMP- 5W - 24 VOLT	TATA spare parts
409029100207	FRONT TURN SIGNAL LAMP LH	TATA spare parts
409029100208	FRONT TURN SIGNAL LAMP RH	TATA spare parts
409029100209	TAIL LAMP - BRAKE AND POSITION LAMP - 24	TATA spare parts
409029100210	TAIL LAMP - REVERSE GEAR - 24V	TATA spare parts
409029100211	TAIL LAMP - TURN SIGNAL - 24V	TATA spare parts
409029100212	REAR ROOF MARKER LAMP - 24V	TATA spare parts
409029100213	FRONT ROOF MARKER LAMP -24V	TATA spare parts
409029100215	FLASHER LAMP_24V	TATA spare parts
409029100217	BULB P21/5W 24V	TATA spare parts
409029100220	FRONT FOG LAMP 24V	TATA spare parts
409029100221	SIDE DIRECTION INDICATOR LAMP-LH	TATA spare parts
409029100222	SIDE DIRECTION INDICATOR LAMP-RH	TATA spare parts
409029100225	FRONT DIRECTION INDICATOR	TATA spare parts
409029100301	TURN SIGNAL LAMP	TATA spare parts
409029100302	TURN SIGNAL LAMP	TATA spare parts
409029100303	MARKER LAMP	TATA spare parts
409029100304	TURN SIGNAL LAMP	TATA spare parts
409029100305	SIDE MARKER LIGHT	TATA spare parts
409029100306	NUMBER PLATE LIGHT	TATA spare parts
409029100310	SIDE MARKER LAMP	TATA spare parts
409029100311	SIDE REPEATER LAMP	TATA spare parts
409029100314	FRONT FOG LAMP ASSY	TATA spare parts
409029100315	REAR FOG LAMP ASSY	TATA spare parts
409029100401	MARKER LAMP	TATA spare parts
409029100601	SIDE DIREC INDICATOR LAMP_LH_12V	TATA spare parts
409029100602	SIDE DIREC INDICATOR LAMP_LH_12V	TATA spare parts
409029200108	LED DOOR LAMP	TATA spare parts
409029200202	TOP REQUEST LAMP	TATA spare parts
409029200203	ROOF LUMANARY ASSEMBLY 24V	TATA spare parts
409029200206	LED PROFILE	TATA spare parts
409029200207	LED LAMPS	TATA spare parts
409029200213	DRIVER LAMP SWITCH AS PER AIS047 N MUX	TATA spare parts
409029200215	LED LUMINARY ASSY	TATA spare parts
409029200216	LAPL LED STRIP FOR RELE	TATA spare parts
409029200217	WIRING HARNESS FOR I/P CONNECTION 3POLE	TATA spare parts
409029200219	WIRING HARNESS FOR INTERCONNECTION 200M	TATA spare parts
409029200229	LAPL LED LAMP ROOF MOUNTED 12-24V	TATA spare parts
409029200235	LED LAMP_(PE)_645MM	TATA spare parts
409029200238	INVEL LED LAMP 1180MM	TATA spare parts
409029200249	DOOR CLOSING LAMP_24V	TATA spare parts

409029200260	REAR ROOF MARKER LAMP_24V_G3	TATA spare parts
409029200263	LED STRIP	TATA spare parts
409029200301	REACTOR/INVERTER F/ 15/20W LAMP	TATA spare parts
409029200302	LAMP	TATA spare parts
409029200303	LAMP	TATA spare parts
409029200304	24V LAMP FOR DOOR CLOSING INDICATOR	TATA spare parts
409029200306	TUBE LIGHT 20 W	TATA spare parts
409029200310	LUMINARY BASE SUB-ASSEMBLY 24V	TATA spare parts
409029200311	LED STRIP MOUNTING BRACKET	TATA spare parts
409029200401	BULB 10W 24V	TATA spare parts
409029300201	EMERGENCY DOOR ALARM SWITCH	TATA spare parts
409029300202	LAMP ATTACHING SUPPORT	TATA spare parts
409029300203	CONNECTION TERMINAL	TATA spare parts
409029300204	2 X 1.0 MM PP CABLE 750V NBR13249	TATA spare parts
409029300207	REAR PLATFORM WIRE HARNESS SEAL PLATE	TATA spare parts
409029300208	SPLIT RUBBER GROMMET ID 30	TATA spare parts
409029300209	ECU SUPPORTING PLATE	TATA spare parts
409029300210	DOUBLE INSULATION	TATA spare parts
409029300212	TAIL LAMP BRACKET	TATA spare parts
409029300219	FOG LAMP SUPPORT PLATE -II	TATA spare parts
409029300222	COVER FOR SWITCH HOLE	TATA spare parts
409029300225	DUMMY COVER FOR DASHBOARD INDICATOR	TATA spare parts
409029300229	FOG LAMP BASE MOUNTING BRACKET	TATA spare parts
409029300235	SCU MOUNTING BRACKET RH	TATA spare parts
409029300236	SCU MOUNTING BRACKET LH	TATA spare parts
409029300301	TAIL LAMP SUPPORT	TATA spare parts
409029300302	INTERIOR LAMP ACRYLIC COVER	TATA spare parts
409029300303	CEILING LIGHT LENS	TATA spare parts
409029300304	CHANNEL BETWEEN LUMINARIES	TATA spare parts
409029300305	CHANNEL BETWEEN LUMINARIES	TATA spare parts
409029300306	CHANNEL BETWEEN LUMINARIES	TATA spare parts
409029300307	CHANNEL BETWEEN LUMINARIES	TATA spare parts
409029300308	CHANNEL BETWEEN LUMINARIES	TATA spare parts
409029300309	LUMINARY CONDUIT	TATA spare parts
409029300310	LUMINARY CONDUIT	TATA spare parts
409029300311	CONNECTOR FITTING BRACKET	TATA spare parts
409029300312	BRACKET FOR LAMP ACRYLIC COVER	TATA spare parts
409029300313	CHANNELS AND COMPONENTS	TATA spare parts
409029300314	HARNESS PROTECTION RUBBER	TATA spare parts
409029300315	LOUDSPEAKER SUPPORT	TATA spare parts
409029300316	SEALING RUBBER	TATA spare parts
409029300317	SEALING RUBBER	TATA spare parts
409029300318	SEALING RUBBER	TATA spare parts
409029300319	COVER FOR SWITCH HOLE	TATA spare parts
409029300320	SEALING RUBBER	TATA spare parts
409029300321	EMERGENCY DOOR SWITCH EXTERNAL COVER	TATA spare parts
409029300322	COVER FOR SWITCH	TATA spare parts

409029300325	FRONT FOGLAMP MOUNTING L PLATE	TATA spare parts
409029300326	REAR FOGLAMP MOUNTING L-PLATE	TATA spare parts
409029300328	FOG LAMP BKT.	TATA spare parts
409029300329	FOG LAMP BKT.	TATA spare parts
409029300338	RUBBER GROMMET FOR REAR FOG	TATA spare parts
409029300401	MARKER LAMP INTERNAL UPPER COVERING(ABS)	TATA spare parts
409029300402	MARKER LAMP MAINTENANCE COVER (ABS)	TATA spare parts
409029300403	1.95 (14) STEEL PLATES	TATA spare parts
409029300404	1.2X15-MM DOUBLE FACE TAPE	TATA spare parts
409029300405	1.2X15MM DOUBLE FACE TAPE	TATA spare parts
409029300407	STOP REQUEST LAMP SUPPORT SUB- ASSY	TATA spare parts
409029300408	FAN MOUNTING BRACKET	TATA spare parts
409029300502	HARNESS SUPPORT L SHAPE PLATE	TATA spare parts
409029300503	HARNESS PROTECTION RUBBER	TATA spare parts
409029300504	HARNESS PROTECTION RUBBER	TATA spare parts
409029400108	KPIT ITS_KIT_MOUD-II (Y1_DL)	TATA spare parts
409029400115	7INCH LED MONITOR_CARBON	TATA spare parts
409029400116	REAR VIEW CAMERA WITH NIGHT VISION	TATA spare parts
409029400117	VIDEO+POWER CABLE WITH 4-PIN DIN CONN	TATA spare parts
409029400222	SOUND BUZZER	TATA spare parts
409029400226	ON BOARD CONTROLLER DISPLAY	TATA spare parts
409029400227	SPEAKER WO GRILL	TATA spare parts
409029400301	SPEAKERS	TATA spare parts
409029500108	EMERGENCY DECLARATION BOX ASSY	TATA spare parts
409029500203	CARBON CLC-1000 DIGITAL CLOCK	TATA spare parts
409029500204	ELECTRONIC POWER INTERVER_150W_24V	TATA spare parts
409029500213	DC-DC CONVERTER (12V TO 24V)	TATA spare parts
409029500215	STAND BDC (HEIGHT ADJUST)	TATA spare parts
409029500225	FRONT DESTINATION BOARD	TATA spare parts
409029500226	SIDE_REAR DEST. BOARD	TATA spare parts
409029500227	INNER DESTINATION BOARD	TATA spare parts
409029500229	CONTROL UNIT DIN 1	TATA spare parts
409029500230	INNER DESTINATION BOARD 910MM	TATA spare parts
409029500231	EMERGENCY DOOR OPEN_ INDICATOR 24V_RED	TATA spare parts
409029500247	7INCH TFT SCREEN (BDC) FOR CAMERA_CHEMIT	TATA spare parts
409029500251	SPEAKER ASSEMBLY WITHOUT GRILL	TATA spare parts
409029500252	TFT MOUNTING BRACKET (DFWM-140	TATA spare parts
409029500253	DASHBOARD INDICATOR LAMP	TATA spare parts
409029500301	DESTINATION BOARD SET	TATA spare parts
409029500302	INVERTOR FOR MOBILE CHARGING(24V/150VA)	TATA spare parts
409029500401	CONTROL UNIT	TATA spare parts
409029500402	VOICE UNIT	TATA spare parts
409029500403	FRONT DESTINATION BOARD	TATA spare parts
409029500404	SIDE DESTINATION BOARD	TATA spare parts
409029500405	REAR DESTINATION BOARD	TATA spare parts
409029500406	INTERNAL DESTINATION BOARD	TATA spare parts
409029500407	AMPLIFIER	TATA spare parts

409029600202	BUZZEE FAN 24V	TATA spare parts
409029600203	FAN SWITCH AS PER AIS047 N MUX	TATA spare parts
409029600205	ELECTRIC FAN (12VDC)	TATA spare parts
409029600207	PASSENGER FAN WITH SWITCH 24V	TATA spare parts
409029600210	ELECTRIC FAN_12/24V_WITH REGULATOR	TATA spare parts
409029600301	ELECTRIC FAN (24VDC)	TATA spare parts
409029600302	DIODE	TATA spare parts
409029600305	ELECTRIC FAN (24V DC)	TATA spare parts
409029700104	MAINTENANCE LAMP SWITCH	TATA spare parts
409029700105	ADAPTOR FOR ITS EMERGENGY SWITCH	TATA spare parts
409029700106	ITS EMERGENCY SWITCH	TATA spare parts
409029700108	REVERSE PARKING SENSOR	TATA spare parts
409029700111	MOBILE CHARGER(DUAL USB)	TATA spare parts
409029700114	EMERGENCY HELP SWITCH_24V	TATA spare parts
409029700201	ASSY.TOGGLE SWITCH (ON-OFF)	TATA spare parts
409029700202	DOOR OPENING LIMIT S/W	TATA spare parts
409029700208	EMERGENCEY DOOR OPENİ INDICATOR 24V RED	TATA spare parts
409029700213	DESTINATION BOARD SWITCH AIS047 N MUX	TATA spare parts
409029700218	INVERTER SWITCH AIS047 N MUX	TATA spare parts
409029700228	EMERGENCY EXIT SWITCH	TATA spare parts
409029700245	STOP LIGHT SWITCH	TATA spare parts
409029700301	MAGNETIC SENSOR	TATA spare parts
409029700302	MAGNET FOR MAGNETIC SENSOR	TATA spare parts
409029700303	MAGNETIC SENSOR FITTING BRACKET	TATA spare parts
409029700304	TIMER RELAY	TATA spare parts
409029700305	MAIN FUSE 50A	TATA spare parts
409029700306	PASSENGER DOOR EMERGENCY RESET SWITCH	TATA spare parts
409029700307	STOP REQUESTED SWITCH	TATA spare parts
409029700308	RELAY	TATA spare parts
409029700309	FUSE 5A	TATA spare parts
409029700310	FUSE 10A	TATA spare parts
409029700311	FUSE 15A	TATA spare parts
409029700312	STOP REQUESTED RELAY	TATA spare parts
409029700313	DESTINATION BOARD	TATA spare parts
409029700314	EMERGENCY RESET SWITCH MUX (MARQUARDT)	TATA spare parts
409029700315	DRIVER FAN	TATA spare parts
409029700316	STOP REQUEST	TATA spare parts
409029700317	DRIVER LAMP	TATA spare parts
409029700318	INTERNAL LAMP	TATA spare parts
409029700327	STOP REQUEST SWITCH	TATA spare parts
409029700331	PASSENGER LAMP SWITCH AIS 047 N MUX	TATA spare parts
409029700332	EXHUAST FAN SWITCH_10A	TATA spare parts
409029800101	220V 6AMP 3PIN SOCKET WITH SWITCH	TATA spare parts
409029800103	VANDAL PROOF CAMERA	TATA spare parts
409029800108	EMERGENCY LAMP MOUNTING BKT	TATA spare parts
409029800113	REVERSE GEAR ALARM 24V	TATA spare parts
409029800209	ON BOARD COMPUTER	TATA spare parts

409029800235	PASSENGER FAN BRACKET	TATA spare parts
409029800301	STOP REQUEST LUMINOUS SIGN	TATA spare parts
409029800302	FEMALE TERMINAL	TATA spare parts
409029800303	CONNECTOR FOR MALE TERMINAL	TATA spare parts
409029800304	MALE TERMINAL	TATA spare parts
409029800305	FEMALE CONNECTOR	TATA spare parts
409029800306	MALE CONNECTOR	TATA spare parts
409029800307	FEMALE TERMINAL	TATA spare parts
409029800308	MALE TERMINAL	TATA spare parts
409029800309	CONNECTOR FOR FEMALE TERMINAL	TATA spare parts
409029800310	CONNECTOR FOR MALE TERMINAL	TATA spare parts
409029800311	MALE TERMINAL	TATA spare parts
409029800312	FEMALE TERMINAL	TATA spare parts
409029800313	MALE TERMINAL	TATA spare parts
409029800314	CONNECTOR FOR FEMALE TERMINAL	TATA spare parts
409029800315	CONNECTOR FOR FEMALE TERMINAL	TATA spare parts
409029800316	CONNECTOR FOR MALE TERMINAL	TATA spare parts
409029800317	MALE TERMINAL	TATA spare parts
409029800318	FEMALE TERMINAL	TATA spare parts
409029800319	REVERSE GEAR ALARM	TATA spare parts
409029800320	MAIN FUSE HOLDER	TATA spare parts
409029800321	LAMPS HARNESS/SOCKET KIT	TATA spare parts
409029800322	DOORS LAMP SET (24 V)	TATA spare parts
409029800323	STOP REQUESTED SWITCH ADAPTER	TATA spare parts
409029800324	MODULED FUSE BOX	TATA spare parts
409029800325	HARNESS	TATA spare parts
409029800328	MALE CONNECTOR	TATA spare parts
409029800330	MALE TERMINAL	TATA spare parts
409029800334	HARNESS FUSE BOX	TATA spare parts
409029800335	FUSE BOX MULT. W/H (AC BUS)	TATA spare parts
409029800338	TWO POLE FEMALE CONNECTOR	TATA spare parts
409029800341	TWO POLE MALE TERMINAL	TATA spare parts
409029800343	FEMALE TERMINAL	TATA spare parts
409029800345	SIDE MARKER HOLDER RELE	TATA spare parts
409029800402	DOOR CLOSING LAMP HOLDER	TATA spare parts
409029900102	WIPER ARM ASSY DRIVER SIDE	TATA spare parts
409029900103	WIPER ARM ASSY CO-DRIVER SIDE	TATA spare parts
409029900104	WIPER ASSY 24V	TATA spare parts
409029900203	MCV BOTTOM MOUNTING WIPER LINK ASSY	TATA spare parts
409029900204	WIPER MOTOR 24VDC_150W_90NM	TATA spare parts
409029900211	WIPER WASHER TANK	TATA spare parts
409029900216	WIPER BLADE ASSEMBLY	TATA spare parts
409029900217	WIPER ASSY RHD-24V_DOGA_RELE	TATA spare parts
409029900301	WIPER BLADE ASSY	TATA spare parts
409029900302	WIPER ARM ASSY DRIVER SIDE	TATA spare parts
409029900303	WIPER ARM ASSY CO-DRIVER SIDE	TATA spare parts
409029900305	PANORAMIC LINKAGE ASSY-24V	TATA spare parts

409029900306	LH WIPER ARM-24V	TATA spare parts
409029900307	WIPER BLADE-24V	TATA spare parts
409029900308	RH WIPER ARM-24V	TATA spare parts
409029900310	ROTATIVE MOTOR-24V	TATA spare parts
409029990201	SOUND SIGN	TATA spare parts
409030000106	WHEEL HOUSE COVERING (FRP ASSY)	TATA spare parts
409030000107	WHEEL HOUSE COVERING (FRP ASSY)	TATA spare parts
409030000201	HANDHOLD TUBE ASSY	TATA spare parts
409030000202	HAND HOLD TUBE 202	TATA spare parts
409030000203	HAND HOLD TUBE 203	TATA spare parts
409030000204	HAND HOLD TUBE 204	TATA spare parts
409030000205	HAND HOLD TUBE 205	TATA spare parts
409030000206	HAND HOLD TUBE 206	TATA spare parts
409030000207	HAND HOLD TUBE 207	TATA spare parts
409030000208	HAND HOLD TUBE 208	TATA spare parts
409030000209	HAND HOLD TUBE 209	TATA spare parts
409030000210	HAND HOLD TUBE 210	TATA spare parts
409030000211	HAND HOLD TUBE 211	TATA spare parts
409030000212	HAND HOLD TUBE 212	TATA spare parts
409030000213	HAND HOLD TUBE 213	TATA spare parts
409030000214	HAND HOLD TUBE 214	TATA spare parts
409030000215	HAND HOLD TUBE 215	TATA spare parts
409030000216	HAND HOLD TUBE 216	TATA spare parts
409030000217	HAND HOLD TUBE 217	TATA spare parts
409030000218	HAND HOLD TUBE 218	TATA spare parts
409030000219	AL HANDHOLD TUBE ASSY	TATA spare parts
409030000220	HAND HOLD TUBE MS 753 ASSY	TATA spare parts
409030000222	SUN VISOR ASSY (FRONT)	TATA spare parts
409030000223	DRIVER ROLL-TYPE SUNSHADE ASSY	TATA spare parts
409030000224	HANDHOLD TUBE STRAIGHT MS 540MM	TATA spare parts
409030000225	HANDHOLD TUBE STRAIGHT MS 655MM	TATA spare parts
409030000236	HANDHOLD TUBE STRAIGHT MS 820MM	TATA spare parts
409030000237	HANDHOLD TUBE STRAIGHT MS 1625MM	TATA spare parts
409030000240	BARRIER GATE ASSY.	TATA spare parts
409030000242	HANDHOLD TUBE AL 1802 BENDED ASSY	TATA spare parts
409030000243	HAND HOLD TUBE BENDED ASSY	TATA spare parts
409030000245	HAND HOLD TUBE MS 2204 BENDED ASSY	TATA spare parts
409030000246	HAND HOLD TUBE MS 1304 BENDED ASSY	TATA spare parts
409030000248	HAND HOLD TUBE MS 2286 BENDED ASSY	TATA spare parts
409030000249	HANDHOLD	TATA spare parts
409030000251	HAND HOLD TUBE MS 725 ASSY	TATA spare parts
409030000252	HAND HOLD TUBE AL 1565 ASSY	TATA spare parts
409030000255	HANHOLD TUBE MS 785 ASSY	TATA spare parts
409030000256	HANDHOLD TUBE M.S 800 ASSY	TATA spare parts
409030000257	HANDHOLD TUBE MS 1794 BENDED ASSY	TATA spare parts
409030000258	HANDHOLD TUBE MS 1516 BENDED ASSY	TATA spare parts
409030000259	HANDHOLD TUBE MS 290 ASSY	TATA spare parts

40903000266	LUGGAGE RACK ASSY	TATA spare parts
40903000267	BARRIER GATE MECHANISM	TATA spare parts
40903000301	ROOF HANDHOLD STRAP ASSY.	TATA spare parts
40903000302	HEADREST ASSEMBLY FOR DISABLED	TATA spare parts
40903000303	STRUCT. OF AREA DESIGNATED FOR DISABLED	TATA spare parts
40903000304	PARTITION WALL COMPONENT	TATA spare parts
40903000325	BASE PLATE AND SUPPORT PLATE ASSY	TATA spare parts
40903000335	EMERGENCY LOCK ASSY_3	TATA spare parts
40903000336	LOCK ASSY FOR EMERGENCY DOOR_1	TATA spare parts
40903000337	LOCK ASSY FOR EMERGENCY DOOR_2	TATA spare parts
40903000342	CONNECTING TUBE	TATA spare parts
40903000413	ENGINE HOOD HANDHOLD ASSEMBLY	TATA spare parts
40903000605	STR FOR WHEEL CHAIR SUP_PARTITION WALL	TATA spare parts
409030010114	TOP CLAMP FOR HANDICAPPED RAMP	TATA spare parts
409030010204	STR. OF AREA DESIGNATED FOR DISABLED	TATA spare parts
409030010213	SUNVISOR ASSEMBLY	TATA spare parts
409030010250	HANHOLD TUBE OVER ENGINEHOOD	TATA spare parts
409030010253	DOOR STEP GRABRAIL TUBE	TATA spare parts
409030010274	GRAB RAIL SUPPORT BRACKET_LN150_DIA36	TATA spare parts
409030010292	END CORNER EXTERNAL FINISHING	TATA spare parts
409030010293	CORNER INTERNAL FINISHING PART	TATA spare parts
409030010319	BOTTOM SUPPORT PLATE	TATA spare parts
409030010339	BENDED STANCHION FOR PARTITION 2200	TATA spare parts
409030010350	STR. OF AREA DESIGNATED FOR DISABLED	TATA spare parts
409030100311	HAND HOLD TUBE 2430 (40 DIA)	TATA spare parts
409030100312	HAND HOLD TUBE 550 (40 DIA)	TATA spare parts
409030100313	Hand Hold Tube 1200 (32 dia)	TATA spare parts
409030100314	HAND HOLD TUBE 1610 (40 DIA)	TATA spare parts
409030100315	HAND HOLD TUBE 1810 (40 DIA)	TATA spare parts
409030100316	HAND HOLD TUBE 100 (40 DIA)	TATA spare parts
409030100317	HAND HOLD TUBE 1780 (40 DIA)	TATA spare parts
409030100318	HAND HOLD TUBE 2186 (40 DIA)	TATA spare parts
409030100319	HAND HOLD TUBE 1866 (40 DIA)	TATA spare parts
409030100325	U-GATE	TATA spare parts
409030100333	HANDHOLD TUBE FOR DRIVER BARRIER	TATA spare parts
409030100346	PARTITION PIPE INSERT TUBE	TATA spare parts
409030110301	32 DIA HAND HOLD TUBE MS BENDED	TATA spare parts
409030110302	HAND HOLD TUBE	TATA spare parts
409030110303	HAND HOLD TUBE	TATA spare parts
409030110304	HAND HOLD TUBE	TATA spare parts
409030110305	32 DIA HAND HOLD TUBE BENDED	TATA spare parts
409030110306	HAND HOLD TUBE	TATA spare parts
409030110307	HAND HOLD TUBE	TATA spare parts
409030110308	32 DIA HAND HOLD TUBE	TATA spare parts
409030110309	32 DIA HAND HOLD TUBE	TATA spare parts
409030110310	32 DIA HAND HOLD TUBE	TATA spare parts
409030110311	40 DIA HAND HOLD TUBE	TATA spare parts

409030110312	HAND HOLD TUBE	TATA spare parts
409030110313	32 DIA HAND HOLD TUBE	TATA spare parts
409030110314	40 DIA HAND HOLD TUBE	TATA spare parts
409030110315	HAND HOLD TUBE	TATA spare parts
409030110316	HAND HOLD TUBE	TATA spare parts
409030110317	HAND HOLD TUBE	TATA spare parts
409030110319	40 DIA HANDHOLD TUBE	TATA spare parts
409030110321	HAND HOLD TUBE	TATA spare parts
409030110329	40 DIA HANDHOLD TUBE	TATA spare parts
409030110330	32 DIA HANDHOLD TUBE	TATA spare parts
409030110334	32 DIA HAND HOLD TUBE	TATA spare parts
409030110341	32 DIA HAND HOLD TUBE	TATA spare parts
409030110342	32 DIA HAND HOLD TUBE	TATA spare parts
409030110346	40 DIA HAND HOLD TUBE	TATA spare parts
409030110380	32 DIA HANDHOLD TUBE L-2500	TATA spare parts
409030110391	HANDHOLD TUBE	TATA spare parts
409030110392	32 DIA BEND TUBE ON WHEEL HOUSING (L.H)	TATA spare parts
409030110393	32 DIA HANDHOLD ON WHEEL COVER (R.H.)	TATA spare parts
409030110406	HANDHOLD TUBE BENT 1686	TATA spare parts
409030110419	HANDHOLD TUBE	TATA spare parts
409030110548	HAND HOLD TUBE	TATA spare parts
409030110550	HAND HOLD TUBE	TATA spare parts
409030110554	HAND HOLD TUBE	TATA spare parts
409030110555	HAND HOLD TUBE	TATA spare parts
409030110556	HAND HOLD TUBE	TATA spare parts
409030110567	HANDHOLD TUBEç 1796	TATA spare parts
409030110568	HANDHOLD TUBEç 2137	TATA spare parts
409030110594	HANDHOLD ASSEMBLY BEND TUBE 2090	TATA spare parts
409030110702	HAND HOLD TUBE	TATA spare parts
409030120202	HANDHOLD TUBE _1758LN	TATA spare parts
409030120203	HANDHOLD TUBE _1751LN	TATA spare parts
409030120204	HANDHOLD TUBE _2541 MM	TATA spare parts
409030120205	HANDHOLD TUBE _808	TATA spare parts
409030120206	HANDHOLD TUBE _1831LN MM	TATA spare parts
409030120208	HANDHOLD TUBE _1618LN MM	TATA spare parts
409030120210	HANDHOLD TUBE _570LN MM	TATA spare parts
409030120211	HANDHOLD TUBE _135LN	TATA spare parts
409030120213	HANDHOLD TUBE _4591 MM	TATA spare parts
409030120214	HANDHOLD TUBE _3541	TATA spare parts
409030120215	HANDHOLD TUBE _2454LN MM	TATA spare parts
409030120216	HANDHOLD TUBE _900	TATA spare parts
409030120219	HANDHOLD TUBE _BENDED _1304 MM	TATA spare parts
409030120220	HANDHOLD TUBE _820 MM	TATA spare parts
409030120221	HANDHOLD TUBE _BENDED _2265 MM	TATA spare parts
409030120222	HANDHOLD TUBE _1330 MM	TATA spare parts
409030120223	HANDHOLD TUBE _114	TATA spare parts
409030120224	HANDHOLD TUBE 570	TATA spare parts



409030120225	HANDHOLD TUBE _850 MM	TATA spare parts
409030120227	BENDED TUBE ABOVE DASHBOARD 1700 MM	TATA spare parts
409030120228	HANDHOLD TUBE _195	TATA spare parts
409030120229	HANDHOLD TUBE _1790LN	TATA spare parts
409030120302	HANDHOLD TUBE _2137	TATA spare parts
409030120303	HANDHOLD TUBE _1370 MM	TATA spare parts
409030120304	HANDHOLD TUBE 753	TATA spare parts
409030120306	HANDHOLD TUBE _785 MM	TATA spare parts
409030120307	HANDHOLD TUBE _1395 MM	TATA spare parts
409030120308	HAND HOLD TUBE 709	TATA spare parts
409030120317	MIDDLE DOOR PARTATION TUBE _900	TATA spare parts
409030120318	MIDDLE DOOR PARTATION TUBE _880	TATA spare parts
409030120319	MIDDLE DOOR PARTATION TUBE _840	TATA spare parts
409030120320	GRAB RAIL PIPE 1950	TATA spare parts
409030120321	GRAB RAIL PIPE L - 1420	TATA spare parts
409030120322	GRAB RAIL PIPE 1680	TATA spare parts
409030120324	HANDHOLD TUBE _1434	TATA spare parts
409030120325	FRONT DOOR PARTATION TUBE _300	TATA spare parts
409030120326	HAND HOLD TUBE 1670	TATA spare parts
409030120327	HANDHOLD TUBE _1459 BENDED	TATA spare parts
409030120328	DRIVER PARTITION TUBE _780	TATA spare parts
409030120614	HANDHOLD TUBE _1964	TATA spare parts
409030120615	MIDDLE DOOR PARTATION SUPP TUBE _190	TATA spare parts
409030120616	HANDHOLD TUBE _2380	TATA spare parts
409030120617	HANDHOLD TUBE 2140	TATA spare parts
409030120624	HANDHOLD TUBE	TATA spare parts
409030120626	GRAB RAIL PIPE L - 2970	TATA spare parts
409030120627	GRAB RAIL PIPE _1560	TATA spare parts
409030200201	HAND HOLD PLASTIC JOINT	TATA spare parts
409030200202	PILLAR-HANDHOLD-DOOR-PARTIT. WALL COMP.	TATA spare parts
409030200203	HAND HOLD PLASTIC JOINT	TATA spare parts
409030200204	HANDHOLD PLASTIC JOINT	TATA spare parts
409030200205	PLASTIC JOINT	TATA spare parts
409030200206	ROOF HAND HOLD TUBE	TATA spare parts
409030200207	PLASTIC BASE FOR HANDHOLD TUBE	TATA spare parts
409030200208	PLASTIC BASE FOR HANDHOLD TUBE	TATA spare parts
409030200209	HANDHOLD ATTACHING PLASTIC SUPPORT	TATA spare parts
409030200210	PILLAR ATTACHING SUPPORT BUSHING	TATA spare parts
409030200211	PILLAR ATTACHING SUPPORT BUSHING	TATA spare parts
409030200212	HAND HOLD ATTACHING PLASTIC SUPPORT	TATA spare parts
409030200215	SUNSHADE STALK ATTACHMENT BASE	TATA spare parts
409030200216	PLASTIC BASE SUPPORT FOR HANDHOLD TUBE	TATA spare parts
409030200217	PILLAR ATTACHING SUPPORT BUSHING	TATA spare parts
409030200221	HANDHOLD PLASTIC JOINT	TATA spare parts
409030200222	HANDHOLD PLASTIC JOINT	TATA spare parts
409030200223	LASTIC GROMET UNDER DRIVER SEAT	TATA spare parts
409030200234	HANDHOLD PLASTIC JOINT 36 DIA/44 DIA	TATA spare parts

409030200236	HANDHOLD PLASTIC JOINT 44DIA/36 DIA	TATA spare parts
409030200238	PLASTIC BASE FOR HANDHOLD TUBE 46 DIA	TATA spare parts
409030200239	PLASTIC BASE FOR HANDHOLD TUBE 38 DIA	TATA spare parts
409030200242	GANG WAY GRAB RAIL SUPPORT(GRAY)	TATA spare parts
409030200243	GRAB RAIL END FINISHING COVER( DIA 35)	TATA spare parts
409030200245	FRP COVR FOR TIME DISPLAY	TATA spare parts
409030200267	HAND HOLD PLASTIC JOINT	TATA spare parts
409030200295	CHASSIS SWITCH HOLDER Y1	TATA spare parts
409030200385	BASE BRACKET FOR 40 MM DIA PIPE	TATA spare parts
409030200386	SPLIT BRACKET FOR 32(H) X 40(V) TUBES	TATA spare parts
409030200387	SPLIT BRACKET FOR 40(H) X 32(V) TUBES	TATA spare parts
409030200388	BASE BRACKET FOR 32MM DIA PIPE	TATA spare parts
409030200395	REAR CAMERA COVER ABS	TATA spare parts
409030200399	EMERGENCY STOP REQUEST SWITCH	TATA spare parts
409030200411	DRIVER DOOR LOCK COVER RH	TATA spare parts
409030300101	EMERGENCE DOOR COVERING	TATA spare parts
409030300102	RH CENTRAL DOOR LOWER FINISHING	TATA spare parts
409030300201	AL HANDHOLD TUBE	TATA spare parts
409030300202	HANDHOLD TUBE	TATA spare parts
409030300203	HANDHOLD TUBE	TATA spare parts
409030300204	HANDHOLD TUBE	TATA spare parts
409030300205	AL HANDHOLD TUBE	TATA spare parts
409030300206	AL HANDHOLD TUBE	TATA spare parts
409030300207	AL HANDHOLD TUBE	TATA spare parts
409030300208	AL PROFILE	TATA spare parts
409030300209	AL PROFILE	TATA spare parts
409030300210	AL PROFILE 805	TATA spare parts
409030300211	ADVERTISEMENT PANEL	TATA spare parts
409030300212	ADVERTISEMENT PANEL REINFORCEMENT	TATA spare parts
409030300215	ADVERTISEMENT PANEL	TATA spare parts
409030300305	PARTITION WALL PROFILE	TATA spare parts
409030400201	WALL GLASS BEHIND OF DRIVER	TATA spare parts
409030400202	PARTITION GLASS BEHIND OF DRIVER	TATA spare parts
409030400306	WALL GLASS BEHIND OF DRIVER 500 X 418	TATA spare parts
409030500202	SOLID RUBBER PROFILE	TATA spare parts
409030500204	GROMET RUBBER	TATA spare parts
409030500301	SOLID RUBBER PROFILES	TATA spare parts
409030600202	PARTITION WALL WOOD	TATA spare parts
409030600204	PARTITION WALL WOOD	TATA spare parts
409030600302	PARTITION WALL	TATA spare parts
409030700102	EMERGENCE DOOR LOCKING GUIDE	TATA spare parts
409030700103	EMERGENCCE DOOR LOCKING ARM	TATA spare parts
409030700201	SUN VISOR ASSY SUPPORT	TATA spare parts
409030700202	SUN VISOR ASSY SUPPORT	TATA spare parts
409030700203	RH PD1200 LOWER SUNSHADE STALK	TATA spare parts
409030700204	ROLL-TYPE SUNSHADE GUIDE ROD	TATA spare parts
409030700205	CENTRAL SUNSHADE STALK	TATA spare parts

409030700206	ROLL-TYPE SUNSHADE GUIDE ROD	TATA spare parts
409030700207	DRIVER DOOR SUNSHADE ATTACH.SUPPORT	TATA spare parts
409030700208	MULTIPLEXING SUPPORTING PLATE	TATA spare parts
409030700209	ECU SUPPORTING PLATE	TATA spare parts
409030700210	WIRE PROTECTION COVER	TATA spare parts
409030700211	SUOORT PLATE FOR SPRING CLAMP	TATA spare parts
409030700212	LADDER MOUNTING SUPPORT PLATE	TATA spare parts
409030700216	SUPPORT PLATE OF TIME DISPLAY	TATA spare parts
409030700221	Z PLATE FOR MOBILE MOUNTING	TATA spare parts
409030700222	MOBILE CHARGER BOX COVER	TATA spare parts
409030700244	MCV SUNVISER BRACKET ASSEMBLY	TATA spare parts
409030700304	MASATS EMERGENCY DOOR OPENING SWITCH BO	TATA spare parts
409030700305	EMERGENCY DOOR OPENING SWITCH BOX	TATA spare parts
409030700306	SWITCH COVER PLATE	TATA spare parts
409030700307	SWITCH COVER PLATE 155X105X2 THK	TATA spare parts
409030900101	PARTITION BELT-AREA DESIGNATED	TATA spare parts
409031000103	LHS BAZEL	TATA spare parts
409031000104	HEADLAMP EXTERNAL REVETMENT	TATA spare parts
409031000105	LICENSE PLATE OPENING SUPPORT ATTACH ASS	TATA spare parts
409031000110	FRONT MUD FLAP (RUBBER) ASSY	TATA spare parts
409031000111	AIR BALOON PROTECTING ASSY	TATA spare parts
409031000114	WEBESTO ROOF HATCH	TATA spare parts
409031000122	ROOF HATCH ASSY 8600625 A(2M3VGV4WJAS)	TATA spare parts
409031000128	HEADLAMP EXTERNAL REVETMENT(L.H.)	TATA spare parts
409031000129	HEADLAMP EXTERNAL REVETMENT(R.H.)	TATA spare parts
409031000151	FRONT LICENCE PLATE OPENING	TATA spare parts
409031000205	INTERNAL ACCESSORIES	TATA spare parts
409031000207	ASSY GRAB HANDLE	TATA spare parts
409031000209	L- PROFILE WITH NUT	TATA spare parts
409031000210	FRP ROUND HEAD LAMP FINISHER FOR LE-RH	TATA spare parts
409031000211	FRP ROUND HEAD LAMP FINISHER FOR LE-LH	TATA spare parts
409031000214	ROOF HATCH BRACKET	TATA spare parts
409031000216	HEAD LAMP ATTACHMENT SUPPORT-LH	TATA spare parts
409031000218	DRIVER SIDE SUNVISOR ASSY (LHD)	TATA spare parts
409031000222	MUD FLAP CAGE ASSY FRONT FLAP	TATA spare parts
409031000223	MUD FLAP CAGE ASSY¿ REAR FLAP	TATA spare parts
409031000228	ROOF HATCH WITH EXHAUST FAN	TATA spare parts
409031000313	MECHANISM & TOP LEAD ASSY	TATA spare parts
409031010212	FRONT RVM MIRROR ARM	TATA spare parts
409031010301	WINDOW GUARD RAIL TUBE M.S 75	TATA spare parts
409031010302	WINDOW GUARD RAIL TUBE RPVC 980LN	TATA spare parts
409031010303	WINDOW GUARD RAIL TUBE RPVC 4725LN	TATA spare parts
409031010304	WINDOW GUARD RAIL TUBE RPVC 785LN	TATA spare parts
409031010305	WINDOW GUARD RAIL TUBE RPVC 582LN	TATA spare parts
409031010306	WINDOW GUARD RAIL TUBE RPVC 825LN	TATA spare parts
409031010307	WINDOW GUARD RAIL TUBE RPVC 4075LN	TATA spare parts
409031010308	WINDOW GUARD RAIL TUBE RPVC 2815LN	TATA spare parts

409031100201	FRONT WINDSHIELD BS3/4	TATA spare parts
409031100202	DESTINATION BOARD GLASS	TATA spare parts
409031100203	REAR WINDSHIELD	TATA spare parts
409031100204	REAR WINDSHIELD GLASS 6MM THK.	TATA spare parts
409031100205	FRONT ITINERARY GLASS	TATA spare parts
409031100206	FRONT WINDSHIELD PASTED GLASS	TATA spare parts
409031100207	REAR WINDSHIELD PASTED GLASS	TATA spare parts
409031100208	FRONT PASTED WINDSHIELD	TATA spare parts
409031100211	FRONT WINDSHIELD GLASS CERAMIC SM BS3/4	TATA spare parts
409031100215	TOP WINDSHIELD_EV-4X12	TATA spare parts
409031100217	MCV 4X12-REAR FLAP GLASS	TATA spare parts
409031100218	LPO 1618 REAR WINDSHIELD BS6	TATA spare parts
409031100301	REAR WINDSHIELD GLASS	TATA spare parts
409031100306	FRONT WIND SHIELD GLASSBS6	TATA spare parts
409031100307	REAR WIND SHIELD GLASS BS6	TATA spare parts
409031100311	MAGNA FRONT WINDSHIELD GLASS BS6	TATA spare parts
409031200102	AL PROFILE BELOW WHEEL ARCH SOLID RUBBER	TATA spare parts
409031200103	ALUMINIUM PROFILE	TATA spare parts
409031200206	WINDOW GAURAD RAIL TUBE-2945	TATA spare parts
409031200207	WINDOW GAURD RAIL TUBE	TATA spare parts
409031200219	WINDOW GUARD RAIL TUBE	TATA spare parts
409031200220	WINDOW GUARD RAIL TUBE DIA19.05_3990MM	TATA spare parts
409031200311	GUARD RAIL TUBE DIA 19.05_5040	TATA spare parts
409031200316	WINDOW GUARD RAIL 3775	TATA spare parts
409031300202	WINDO GUARD RAIL BRKT	TATA spare parts
409031300203	WINDO GUARD RAIL BRKT	TATA spare parts
409031400101	WHEEL ARCH SOLID RUBBER PROFILES	TATA spare parts
409031400102	RUBBER GROMMET	TATA spare parts
409031400201	RUBBER- FRONT OUTLINED WINDSHIELD	TATA spare parts
409031400202	RUBBER- ITIRARY OUTLINED WINDSHIELD	TATA spare parts
409031400203	RUBBER FOR RR WIND	TATA spare parts
409031400204	SOLID RUBBER PROFILES	TATA spare parts
409031400205	RUBBER SUPPORT FOR FUEL TANK ATTACHMENT	TATA spare parts
409031400208	FRT RUBBER OUTLINE-SINGLE GLASS SM BS3/4	TATA spare parts
409031400209	FRONT SPRAY SUPPRESSION MUD FLAP	TATA spare parts
409031400210	REAR SPRAY SUPPRESSION MUD FLAP	TATA spare parts
409031400303	FRONT W/S RUBBER_G3-2.34 BS6	TATA spare parts
409031400304	REAR W/S RUBBER_G3-2.34 BS6	TATA spare parts
409031400306	FRONT W/S RUBBER MAGNA BS6 FACE LIFT	TATA spare parts
409031500201	ROOF EXTERNAL CONTOUR	TATA spare parts
409031500203	1500-MM DOORS SIDE INTERNAL TRIM - RAMP	TATA spare parts
409031500204	RAMP FINISH PROFILE-INBETWEEN RAMP & FLO	TATA spare parts
409031500206	L-PRO. USING IN ABS MOULD	TATA spare parts
409031500207	WINDOW GUARD RAIL REINFORCEMENT PLATE	TATA spare parts
409031500209	ROOF EXTERNAL CONTOUR	TATA spare parts
409031500213	ALUMINIUM PLATE RAL3001	TATA spare parts
409031500214	SPPED INDICATING STICKER	TATA spare parts

409031600206	WINDOW GUARD RAIL	TATA spare parts
409031600207	WINDOW GUARD RAIL-LN 1597MM	TATA spare parts
409031600208	WINDOW GUARD RAIL	TATA spare parts
409031600209	AL TUBE OD 25 ID X LENGTH 4600 P COATED	TATA spare parts
409031600210	WINDOW GUARD RAIL-LN 2375MM	TATA spare parts
409031600211	WINDOW GAURD RAIL-LN 1350 MM	TATA spare parts
409031600212	WINDOW GAURD RAIL-LN 1590 MM	TATA spare parts
409031600215	WINDOW GUARD RAIL-LN 1364 MM	TATA spare parts
409031700201	MAINTENANCE COVER	TATA spare parts
409031700202	MAINTENANCE COVER	TATA spare parts
409031700203	MAINTENANCE COVER	TATA spare parts
409031700204	NUMBER PLATE(FRONT)	TATA spare parts
409031700205	NUMBER PLATE(REAR)	TATA spare parts
409031700206	MAINTENANCE COVER	TATA spare parts
409031700208	MAINTENANCE CUTOUT COVER FOR DRIVER SIDE	TATA spare parts
409031700224	MUDGUARD ATTACHING PROFILE	TATA spare parts
409031800201	AIR INTAKE FRAME COVER	TATA spare parts
409031800202	ROOF INTERNAL CONTOUR	TATA spare parts
409031800203	7.6-MM WIDE BLACK POLYAMIDE BRACKET	TATA spare parts
409031800204	POLYAMIDE CLAMP	TATA spare parts
409031800205	FINISHING PROFILE	TATA spare parts
409031800207	END COVER FOR RUB RAIL	TATA spare parts
409031800208	RUBRAIL SUPPORT COVER	TATA spare parts
409031800212	AIRINTAKE FRAME COVER	TATA spare parts
409031800213	AIR HATCH CONTOUR	TATA spare parts
409031800214	WINDOW GUARD RAIL CLAMP -OPEN END	TATA spare parts
409031800215	WINDOW GUARD RAIL CLAMP-CLOSED END	TATA spare parts
409031800216	HALF ROUND PROFILE-PVC	TATA spare parts
409031890301	OIL ISO VG 32+3% BISSOLFETO MOLIBDEN	TATA spare parts
409031990201	END CAP (HIG DENSITY POLYETHYLENE)	TATA spare parts
409031990203	EMERGENCY MECHANISM FINISH	TATA spare parts
409031990205	AIR HATCH SEALING RUBBER	TATA spare parts
409031990206	AIR SYSTEM LUBRICATOR FILTER	TATA spare parts
409031990210	MUD FLAP	TATA spare parts
409031990214	LLDPE MCV MUD FLAP 620X300X4	TATA spare parts
409032010114	EV_4/12 DECAL DETAILS	TATA spare parts
409032200101	JNNURM STICKER BLUE_1512JABALPUR	TATA spare parts
409032200102	RFID TAG	TATA spare parts
409032200116	PRIORITY STICKER ON LH/RH SIDE WALL	TATA spare parts
409032200201	EMERGENCY DOOR STICKER 1	TATA spare parts
409032200202	EMERGENCY DOOR STICKER 2	TATA spare parts
409032200203	EMERGENCY DOOR STICKER 3	TATA spare parts
409032200204	EMERGENCY DOOR STICKER 4	TATA spare parts
409032200205	EMERGENCY DOOR STICKER 5	TATA spare parts
409032200206	AIR BLOCKING VALVE STICKER	TATA spare parts
409032200207	220 VOLTS STICKER	TATA spare parts
409032200208	MARCOPOLO RESINED STICKER	TATA spare parts

409032200209	WHEEL CHAIR STICKER	TATA spare parts
409032200210	EMERGENCY WINDOW STICKER	TATA spare parts
409032200212	CENTRAL STATION STICKER	TATA spare parts
409032200213	EMERGENCY EXIT STICKER 6	TATA spare parts
409032200214	EMERGENCY EXIT ADHESIVE	TATA spare parts
409032200215	MARCOPOLO RESINED STICKER	TATA spare parts
409032200218	AUTOMATIC DOOR	TATA spare parts
409032200220	75 MM WIDE WHITE TAPE FOR BUMPER	TATA spare parts
409032200221	HANDICAPPED BARRIER	TATA spare parts
409032200222	FIRE EXTINGUISHER STICKER	TATA spare parts
409032200223	INSIDE PASSENGER EMERGENCY INSTRUCTIONS	TATA spare parts
409032200224	DTC STICKER ( HINDI + ENGLISH )	TATA spare parts
409032200225	LADIES STICKER	TATA spare parts
409032200226	STICKER - SENIOR CITIZEN	TATA spare parts
409032200227	HANDICAPPED	TATA spare parts
409032200228	NO SMOKING LOGO	TATA spare parts
409032200230	HINDI KEEP BUS CLEAN STICKER	TATA spare parts
409032200231	ASSY& TATA& MASCOT	TATA spare parts
409032200232	PROIORITY SEAT STICKER	TATA spare parts
409032200234	EMERGENCY EXIT STICKER FOR GLASS BREAKIN	TATA spare parts
409032200235	ENTRANCE STICKER	TATA spare parts
409032200236	EXIT STICKER	TATA spare parts
409032200237	WHITE CONSPICUITY TAPE AS PER AIS 090	TATA spare parts
409032200238	RED CONSPICUITY TAPE AS PER AIS 090	TATA spare parts
409032200239	YELLOW CONSPICUITY TAPE AS PER AIS 090	TATA spare parts
409032200246	FIRE EXTINGUISER STICKERS	TATA spare parts
409032200247	EMERGENCY EXIT	TATA spare parts
409032200248	EMERGENCY DOOR EXIT STICKER	TATA spare parts
409032200249	INSIDE PASSENGER DOOR EMERGENCY INSTR.	TATA spare parts
409032200252	EXTERNAL EMERGENCY DOOR STICKER	TATA spare parts
409032200255	FIRE EXTINGUISHER STICKER-1	TATA spare parts
409032200256	FIRE EXTINGUISHER STICKER	TATA spare parts
409032200258	TATA STICKER 60MM.	TATA spare parts
409032200259	ARROW STICKER	TATA spare parts
409032200260	STICKER FOR EMERGENCY WINDOW LEVER	TATA spare parts
409032200261	STICKER FOR HAMMER	TATA spare parts
409032200262	STICKER FOR ROOF HATCH	TATA spare parts
409032200263	EMERGENCY STICKER FOR HAMMER	TATA spare parts
409032200270	JNNURM STICKER WHITE	TATA spare parts
409032200271	EMERGEENCY SWITCH STICKER(FRONT)	TATA spare parts
409032200275	AIR BLOCKING VALVE STICKER	TATA spare parts
409032200281	MARCOPOLO RESINED STICKER	TATA spare parts
409032200282	DECALS GO-AIRWAYS BUS	TATA spare parts
409032200299	MULTIPLEX FUSE BOX STICKER	TATA spare parts
409032200306	STICKER OF DELHI TRANSIT BUS	TATA spare parts
409032200320	JNNURM STICKER	TATA spare parts
409032200322	EMERGENCY DOOR STICKER	TATA spare parts

409032200323	UREA TANK STICKER	TATA spare parts
409032200324	DIESEL TANK STICKER	TATA spare parts
409032200325	STICKER FOR LIFT HANDLE TO UNLOCK	TATA spare parts
409032200326	EMERGENCY DOOR OPEN INSTRUCTION(OUTSIDE	TATA spare parts
409032200327	EMERGENCY STICKER TO BREAK THE GLASS	TATA spare parts
409032200328	EMERGENCY DOOR EXIT STICKER	TATA spare parts
409032200329	EMERGENCY EXIT STICKER	TATA spare parts
409032200330	EMERGENCY EXIT STICKER	TATA spare parts
409032200336	BBC_FIRE EXTIGUISHER STICKER	TATA spare parts
409032200337	HAMMER IDENTIFICATION STICKER	TATA spare parts
409032200338	EMERGENCY WINDOW STICKER FRENCH	TATA spare parts
409032200339	STICKER EMERGENCY WINDOW LEVER FRENCH	TATA spare parts
409032200340	EMERGENCY EXIT STICKER FRENCH	TATA spare parts
409032200341	EMERGENCY EXIT STICKER FRENCH	TATA spare parts
409032200342	EMERGENCY DOOR STICKER 2 FRENCH	TATA spare parts
409032200343	FIRE EXTINGUISHER STICKER 2 FRENCH	TATA spare parts
409032200344	AUTOMATIC DOOR STICKER FRENCH	TATA spare parts
409032210204	MARCOPOLO EMBLEM	TATA spare parts
409032210211	JNNURM LOGO	TATA spare parts
409032210226	CNG STICKER	TATA spare parts
409032210230	JNNURM LOGO	TATA spare parts
409032210235	TATA DOME STICKER SMALL BLACK	TATA spare parts
409032210236	MARCOPOLO DOME STICKER BLACK BIG LOGO	TATA spare parts
409032210237	TATA DOME STICKER BLACK BIG	TATA spare parts
409032210238	MARCOPOLO DOME STICKER BLACK SMALL LOGO	TATA spare parts
409032210239	DMRC LOGO RED VINYL STICKER	TATA spare parts
409032210240	BDC CAUTION STICKER	TATA spare parts
409032210241	MARCOPOLO ABS DOME STICKER BLACK 400MM	TATA spare parts
409032210244	EMERGENCY STOP STICKER	TATA spare parts
409032210277	RH WHEEL CHAIR STICKER-AIS-153	TATA spare parts
409032210294	EV LOGO D STICKER LH/RH	TATA spare parts
409032210295	EV FRONT SIDE_1	TATA spare parts
409032210297	EV LOGO LETTERS	TATA spare parts
409032210298	EV LOGO LH_1	TATA spare parts
409032210301	STOP STICKER	TATA spare parts
409032300211	EV LOGO REAR SIDE	TATA spare parts
409032300212	EV LOGO RH_1	TATA spare parts
409032500302	SKOOL BUS STOP PLATE	TATA spare parts
409033000101	FIRE EXTINGUISHER BOX ASSY	TATA spare parts
409033000104	FIRST AID BOX	TATA spare parts
409033000202	EMERGENCY WINDOW HAMMER ASSEMBLY	TATA spare parts
409033000203	EMERGENCY WINDOW MECHAN. HANDLE KIT	TATA spare parts
409033000204	EMERGENCY WINDOW MECHAN. HANDLE KIT	TATA spare parts
409033000206	FIRE EXTINGUISHER BOX ASSY REAR	TATA spare parts
409033000207	FIRE EXTINGUISHER BOX ASSY(FRONT)	TATA spare parts
409033000208	FIRE EXTINGUISHER PAD ASSY	TATA spare parts
409033000211	FRONT SUN VISOR ASSY FOR LHD	TATA spare parts

409033000220	ROLLER TYPE SUNVISOR	TATA spare parts
409033000222	INTERNAL REAR-VIEW MIRROR	TATA spare parts
409033000228	FIRE EXTINGUISHER 4 KG	TATA spare parts
409033000244	HOOTER_12V_FDAS_GREEN FUEL BS6	TATA spare parts
409033000250	FDAS_12V_GREEN FUEL_TRIM STAGE BS6	TATA spare parts
409033000258	SPRING HAMMER ASSY	TATA spare parts
409033000302	RVM MIRROR SUPPORT ASSY	TATA spare parts
409033000306	RVM MIRROR SUPPORT ASSY	TATA spare parts
409033200201	EMERGENCY EXIT WINDOW MECHANISM UPPER	TATA spare parts
409033200202	EMERGENCY EXIT WINDOW MECHANISM LOWER	TATA spare parts
409033200203	FIRE EXTINGUISHER COVER	TATA spare parts
409033200204	HAMMER SUPPORT PLATE	TATA spare parts
409033200320	GI PLATE 70X70X2.7	TATA spare parts
409033200323	SUPPORT BRACKET OF SUNVISOR LH	TATA spare parts
409033300201	ABS 3 POINT SEAT BELT FINISHING COVER	TATA spare parts
409033400201	EMERGENCY GLASS RUBBER	TATA spare parts
409033500201	FIRE EXTINGUISHER BOX GLASS	TATA spare parts
409033500202	FIRE EXTINGUISHER GLASS	TATA spare parts
409033600202	EXIT/ENTRANCE PASSENGER DOOR HANDLE ASSY	TATA spare parts
409033600208	FDSS SOUNDER CUM FLASHER_SAFEX	TATA spare parts
409033600401	SUNVISOR ASSEMBLY	TATA spare parts
409033800201	EMERGENCY HAMMER COVER	TATA spare parts
409033800202	EMERGENCY MECHANISM FINISH	TATA spare parts
409033800203	EMERGENCY MECHANISM FINISH	TATA spare parts
409033900103	FIRE DETECTION & ALARMING SYSTEM 12V KIT	TATA spare parts
409033900202	FIRST AID BOX	TATA spare parts
409033900203	CONDUCTOR BOX	TATA spare parts
409033900204	FIRE EXTINGUISHER -IS: 13849-2KG	TATA spare parts
409033900205	LOCK METALIC FIRST AID BOX	TATA spare parts
409034100301	TOOL BOX COVER	TATA spare parts
409034300502	TOOL BOX TOP COVER	TATA spare parts
409036000101	CNG ACCESS PLATFORM ASSEMBLY	TATA spare parts
409036000103	CNG CYLINDER FIXER ASSEMBLY	TATA spare parts
409036000104	CNG CYLINDER FIXER ASSEMBLY	TATA spare parts
409036000105	LOW ENTRY ROOF ACCESS STAIR	TATA spare parts
409036000106	Ladder NON AC	TATA spare parts
409036000107	ROOF ACESS PLATFORM	TATA spare parts
409036000115	LOW ENTRY ROOF ACCESS STAIR	TATA spare parts
409036000116	LADDER ASSY CNG AC BUS	TATA spare parts
409036000202	GAS-CNG CYLINDER SUPPORT COLUMN ASSEMBL	TATA spare parts
409036000203	GAS-CNG CYLINDER INT. SUPPORT ASSEMBLY	TATA spare parts
409036000204	COLUMN ASSEMBLY OF GAS-CNG CYLINDER	TATA spare parts
409036000209	CNG COVER REINFORCEMENT ASSY.	TATA spare parts
409036000210	STAIR CLAMPING ASSY BKT ASSY (LONG)	TATA spare parts
409036000211	STAIR CLAMPING ASSY BKT ASSY (SMALL)	TATA spare parts
409036000214	GAS CYLINDER SUPPORT COLUM ASSY	TATA spare parts
409036100205	40 X 40 X 2.30 SQUARE STEEL TUBE	TATA spare parts



409036100206	40 X 40 X 1.55 SQUARE STEEL TUBE	TATA spare parts
409036100207	40X80X1-5 DUAL PHASE RET. STEEL TUBE	TATA spare parts
409036100208	40X80X1-5 DUAL PHASE RET. STEEL TUBE	TATA spare parts
409036100209	40 X 40 X 1.55 SQUARE STEEL TUBE	TATA spare parts
409036100210	40 X 40 X 1.55 SQUARE STEEL TUBE	TATA spare parts
409036100211	40X80X1-5 DUAL PHASE RET. STEEL TUBE	TATA spare parts
409036100217	CROSS GI TUBES	TATA spare parts
409036100218	CROSS GI TUBES	TATA spare parts
409036100219	CROSS GI TUBES	TATA spare parts
409036100220	CROSS GI TUBES	TATA spare parts
409036400201	GAS CYLINDER RUBBER REVETMENT	TATA spare parts
409036500101	GAS CYLINDER REVETMENT REINFORCEMENT	TATA spare parts
409036500102	CNG CYLINDER ATTACHMENT PROFILE	TATA spare parts
409036500201	GAS-CNG CYLINDER SUPPORT UNION GUSSET	TATA spare parts
409036500202	GAS-CNG CYLINDER SUPPORT UNION GUSSET	TATA spare parts
409036500203	38 X 2.70 L-SHAPED STEEL PROFILES	TATA spare parts
409036500204	38 X 2.70 L-SHAPED STEEL PROFILES	TATA spare parts
409036500205	COVERING ATTACHING SUPPORT OF THE GAS	TATA spare parts
409036500207	GUSSET	TATA spare parts
409036500208	END PLATE	TATA spare parts
409036500209	END PLATE	TATA spare parts
409036600101	GAS TUBE COVERING	TATA spare parts
409036600102	GAS TUBE COVERING	TATA spare parts
409036600103	CNG PLATFORM JOINING PLATE AT ROOF	TATA spare parts
409036600104	ATTACHMENT PLATE F/GAS-CNG KIT SUPPORT	TATA spare parts
409036600105	ATTACHMENT PLATE F/GAS-CNG KIT SUPPORT	TATA spare parts
409036600207	ATTACHMENT PLATE F/GAS-CNG KIT SUPPORT	TATA spare parts
409036700201	4.25 STEEL PLATES	TATA spare parts
409036700212	BASE PLATE	TATA spare parts
409036700213	CLOSING PLATE 36X36	TATA spare parts
409036700307	SPRING CLAMP	TATA spare parts
409037000201	HINGED DOOR ASSY.	TATA spare parts
409037000203	Hinge Kit	TATA spare parts
409037000214	DRIVER DOOR EXT PANEL ASSY_RHD870X1582	TATA spare parts
409037000220	DRIVER DOOR RUBBER SUPPORT	TATA spare parts
409037000254	DRIVER DOOR ASSEMBLY	TATA spare parts
409037300201	CATCHER COVER	TATA spare parts
409037300204	GRAB HAND HOLD BLACK	TATA spare parts
409037300207	DOOR BOLT COVER	TATA spare parts
409037300211	GRAB HANDLE_250MM CD	TATA spare parts
409037300213	DOOR UPPER CORNER COVERING	TATA spare parts
409037300301	MALE CATCHER	TATA spare parts
409037400301	FEMALE CATCHER	TATA spare parts
409037700101	PALTE FOR WINDSHIELD CLEANING	TATA spare parts
409037700201	DOOR SEALING SUPPORT	TATA spare parts
409037700202	DOOR SEALING SUPPORT	TATA spare parts
409037700203	DOOR SEALING SUPPORT	TATA spare parts

409037700204	DD INTERNAL PANEL RHD	TATA spare parts
409037700206	DOOR SEALING SUPPORT	TATA spare parts
409037700214	DRIVER DOOR INTERNAL RIVETMENT	TATA spare parts
409037700306	MALE CATCHER REINFORCEMENT PLATE	TATA spare parts
409037700406	FEMALE CATCHER PLATE	TATA spare parts
409037800101	HANDLE USED TO CLEAN WIND SHIELD	TATA spare parts
409038000101	EMERGENCY DOOR	TATA spare parts
409038000104	PAINTED AND TRIMED EMERGENCY DOOR	TATA spare parts
409038000203	LOCK ARM ATTACHMENT BASE ASSY	TATA spare parts
409038000204	HINGE ASSY	TATA spare parts
409038000205	DOOR LATCH ATTACHMENT SUPPORT ASSY	TATA spare parts
409038000207	EMERGENCY HINGED DOOR ASSY.	TATA spare parts
409038000208	EMERGENCY HINGED DOOR ASSY	TATA spare parts
409038700202	DOOR SEALING SUPPORT	TATA spare parts
409038700203	DOOR SEALING SUPPORT	TATA spare parts
409039000102	BATTERY BOX AND TROLLEY COMPARTMENT	TATA spare parts
409039000106	ELECTRIC COMMAND COVERING ASSEMBLY	TATA spare parts
409039000108	BATTERY BOX COMPART TUBE ASSEMBLY	TATA spare parts
409039000114	ELECTRIC COMMAND COVERING ASSEMBLY	TATA spare parts
409039000117	BATTERY BOX & TROLLEY COMPARTMENT	TATA spare parts
409039000129	BATTERY BOX COMPARTMENT ASSY.	TATA spare parts
409039000166	WATER SEPARATER FLAP ASSY	TATA spare parts
409039000202	REAR-VIEW MIRROR SUPPORT-RH	TATA spare parts
409039000203	RADIATOR PROTECTION ASSEMBLY	TATA spare parts
409039000211	BASE SHEET ASSY	TATA spare parts
409039000212	BATTERY BOX PLATE ASSEMBLY	TATA spare parts
409039000213	ELECTRIC COMMAND BOX ASSEMBLY	TATA spare parts
409039000214	FRONT COVER SHEET ASSY	TATA spare parts
409039000215	INSIDE UPPER COVER SHEET ASSY.	TATA spare parts
409039000216	INSIDE LOWER COVER SHEET ASSY	TATA spare parts
409039000218	BATTERY BOX COMPARTMENT RAIL ASSY	TATA spare parts
409039000219	BATTERY BOX BASE ASSEMBLY	TATA spare parts
409039000220	BATTERY BOX COMPARTMENT RAIL ASSY	TATA spare parts
409039000231	MOVABLE BATTERY BOX ASSY.	TATA spare parts
409039000232	BATTERY BOX COMPARTMENT RAIL ASSY	TATA spare parts
409039000259	FRP SUPPORT ASSY	TATA spare parts
409039000260	BATTERY HOLDING TUBE ASSY	TATA spare parts
409039000263	LOCK PLATE ASSY-LH	TATA spare parts
409039000264	LOCK PLATE ASSY-RH	TATA spare parts
409039000280	REAR VIEW MIRROR SUPPORT	TATA spare parts
409039000281	REAR VIEW MIRROR SUPPORT RH	TATA spare parts
409039000295	BATTERY BOX COMPARTMENT ASSY	TATA spare parts
409039000304	RADIATOR PROTECTOR FLAP ASSY.	TATA spare parts
409039000307	BASE SHEET ASSY	TATA spare parts
409039000313	BASE SHEET ASSY	TATA spare parts
409039000403	BATTERY ATTACHMENT PLATE ASSY.	TATA spare parts
409039200201	WHEEL FLAP SUPPORT REINFORCEMENT	TATA spare parts

409039200301	COMMAND CLOSING COVER COUPLER	TATA spare parts
409039200306	BATTERY MOUNTING ROD	TATA spare parts
409039400201	REARVIEW MIRROR SUPPORT-LH	TATA spare parts
409039400202	LHS RVM	TATA spare parts
409039400203	RHS RVM	TATA spare parts
409039400204	BUMPER VIEW MIRROR	TATA spare parts
409039400205	SALOON VIEW MIRROR	TATA spare parts
409039400206	REARVIEW MIRROR SUPPORT	TATA spare parts
409039500218	COVERING PLATE B/W RADIATOR & BODY	TATA spare parts
409039500219	COVERING PLATE B/W CHASSIS & BODY	TATA spare parts
409039500305	FRONT COVER SHEET	TATA spare parts
409039500308	RADIATOR PROTECTOR PLATE (FLAP)	TATA spare parts
409039500310	COUPLER AND CLOSING ASSLY.	TATA spare parts
409039500314	BATTERY BOX BOTTOM	TATA spare parts
409039500316	INSIDE LOWER COVER SHEET	TATA spare parts
409039500317	BASE SHEET	TATA spare parts
409039500318	FRONT COVER SHEET	TATA spare parts
409039500319	INSIDE UPPER COVER SHEET	TATA spare parts
409039500326	UPPER CLOSING SHEET	TATA spare parts
409039500327	RADIATOR AND BATTERY PARTITION SHEET	TATA spare parts
409039500328	RADIATOR AND BATTERY PARTITION SHEET	TATA spare parts
409039500329	CLOSING PLATE	TATA spare parts
409039500330	L-PROFILE SUPPORT	TATA spare parts
409039500453	INSPECTION COVER BOTTOM PLATE	TATA spare parts
409039600201	DOOR MECHANISM ROLLER	TATA spare parts
409039700101	CBCU FIXING BOX COVER	TATA spare parts
409039700201	WHEEL FLAP	TATA spare parts
409039700202	WHEEL FLAPS	TATA spare parts
409039700203	WHEEL FLAP	TATA spare parts
409039700204	WHEEL FLAPS	TATA spare parts
409039700205	CENTRAL STATION COVER	TATA spare parts
409039700206	WHEEL FLAP	TATA spare parts
409039700207	WHEEL FLAP	TATA spare parts
409039700217	WHEEL FLAP	TATA spare parts
409039700218	WHEEL FLAP	TATA spare parts
409039700323	LOCK PLATE	TATA spare parts
409039700325	L-PROFILE	TATA spare parts
409039800307	SOLID RUBBER PROFILES	TATA spare parts
409039800308	SPL RUBBER WATER OUTLET TAP	TATA spare parts
409039800316	BATTERY BOX FRP	TATA spare parts
409039990201	DOOR MECHANISM ROLLING AXLE	TATA spare parts
409041000101	COMPLETE UNIT (AEROSPHERE)	TATA spare parts
409041000103	AEROSPHERE A/C	TATA spare parts
409041000107	AC SYSTEM W/O HEATING	TATA spare parts
409041100107	COMPRESSOR ASSY	TATA spare parts
409041100108	AC COMPRESSOR V-BELT	TATA spare parts
409041100201	RUBBER PLUG	TATA spare parts

409041100202	COVER SIDE PART	TATA spare parts
409041100203	GRID	TATA spare parts
409041100204	HINGE	TATA spare parts
409041100205	SUPPORT LEFT HAND SIDE	TATA spare parts
409041100206	SUPPORT RIGHT HAND SIDE	TATA spare parts
409041100207	COND. SUPPORT BRACKET	TATA spare parts
409041100208	CENTRAL COND. BRACKET	TATA spare parts
409041100209	FAN GRILL	TATA spare parts
409041100210	FAN ASSY	TATA spare parts
409041100211	CONDENSER COIL	TATA spare parts
409041100212	COVER AEROSPHERE	TATA spare parts
409041100213	COND.COVER	TATA spare parts
409041100214	RUBBER GROMMET	TATA spare parts
409041100215	RUBBER GROMMET	TATA spare parts
409041100216	PIPE INTERFACE HEATING	TATA spare parts
409041100217	RECEIVER DRYER PIPE	TATA spare parts
409041100218	FLUID PIPE ASSY	TATA spare parts
409041100219	EVAPORATOR PIPE LEFT	TATA spare parts
409041100220	EVAPORATOR PIPE RIGHT	TATA spare parts
409041100221	COND. RECEIVER PIPE	TATA spare parts
409041100222	PRESSURE PIPE	TATA spare parts
409041100223	SUCTION PIPE II	TATA spare parts
409041100224	SUCTION PIPE I	TATA spare parts
409041100225	WATER VALVE MOTOR	TATA spare parts
409041100226	TXV	TATA spare parts
409041100227	DRYER HOLDER	TATA spare parts
409041100228	LEFT HAND SIDE	TATA spare parts
409041100229	RIGHT HAND SIDE	TATA spare parts
409041100230	FILTER DRYER	TATA spare parts
409041100231	RECEIVER BOTTLE	TATA spare parts
409041100232	COND. ASSY	TATA spare parts
409041100233	EVAP. ASSY	TATA spare parts
409041100234	COVER LEFT	TATA spare parts
409041100235	COVER RIGHT	TATA spare parts
409041100236	RUBBER GROMMET	TATA spare parts
409041100237	BELT TENSIONER ASSY WITH ALL PART	TATA spare parts
409041100238	TENSIONER ROD ASSY.WITH KT.(ADJ)	TATA spare parts
409041100239	REAR CUSHION BASE ASSY	TATA spare parts
409041100240	COVER SUPPORT	TATA spare parts
409041100241	FLAP MOTOR	TATA spare parts
409041100242	AXEL AIR FLAP	TATA spare parts
409041100243	SUPPORT FRESH AIR FLAP	TATA spare parts
409041100244	SUPPORT FRESH AIR FLAP	TATA spare parts
409041100245	AIR FLAP	TATA spare parts
409041100246	BLOWER MTG BLOCK	TATA spare parts
409041100247	BLOWER ASSY	TATA spare parts
409041100248	HEATING COIL LEFT SIDE	TATA spare parts

409041100249	HEATING COIL RIGHT SIDE	TATA spare parts
409041100250	EVAP.COIL LEFT SIDE	TATA spare parts
409041100251	EVAP.COIL RIGHT SIDE	TATA spare parts
409041100252	EVAP. BASE LEFT SIDE	TATA spare parts
409041100253	EVAP. BASE RIGHT SIDE	TATA spare parts
409041100254	BULKHEAD V	TATA spare parts
409041100255	BULKHEAD IV	TATA spare parts
409041100256	BULKHEAD III	TATA spare parts
409041100257	BULKHEAD II	TATA spare parts
409041100258	WATER DEFLECTOR PLATE	TATA spare parts
409041100259	DOUBLE BIG HEAD	TATA spare parts
409041100260	DRAIN NIPPLE	TATA spare parts
409041100261	PCB	TATA spare parts
409041100262	RELAY PLATE	TATA spare parts
409041100263	ELECTRONIC PLATE SUPPORT	TATA spare parts
409041100264	EVAP.WATER PLATE	TATA spare parts
409041100265	ELECTRIC INTERFACE	TATA spare parts
409041100266	FIXING ASSY	TATA spare parts
409041100271	CAPACITOR BOX	TATA spare parts
409041100273	WH ALTERNATOR PROTECTION RELAY	TATA spare parts
409041100274	WH AC CLUTCH DIRECT SUPPLY	TATA spare parts
409041100275	FILTER RETURN AIR	TATA spare parts
409041100276	RECTANGULAR CUSHION ASSY	TATA spare parts
409041100279	ADJUSTER BOLT SET	TATA spare parts
409041100288	COUPLER 1 POLE MALE FEMALE	TATA spare parts
409041100289	ADJESTER PLATE	TATA spare parts
409041100290	DIODE(008-L037-00)	TATA spare parts
409041100294	COMP PORT GASKET	TATA spare parts
409041100297	JOINT GASKET	TATA spare parts
409041100298	LAMP PANEL 24 V/1.2 WC/SQM	TATA spare parts
409041100301	CONDENSER AXIAL FAN 24V	TATA spare parts
409041100302	CONDENSER COIL	TATA spare parts
409041100303	FILTER DRIER	TATA spare parts
409041100304	GLOBE VALVE	TATA spare parts
409041100305	RECEVIER	TATA spare parts
409041100306	EVAPORATOR BLOWER 24V	TATA spare parts
409041100307	RIGHT EVAPORATOR COIL	TATA spare parts
409041100308	LEFT EVAPORATOR COIL	TATA spare parts
409041100309	EXPANSION VALVE	TATA spare parts
409041100310	TEMPERATURE SENSOR	TATA spare parts
409041100311	RELAY PLATE 24V	TATA spare parts
409041100312	RELAY PLATE GL-T046 24V	TATA spare parts
409041100314	BODY	TATA spare parts
409041100315	ECCENTRIC SHAFT	TATA spare parts
409041100316	FRONT BALANCE	TATA spare parts
409041100317	BACK BALANCE	TATA spare parts
409041100318	SET OF GASKET	TATA spare parts

409041100319	BOTTOM PLATE	TATA spare parts
409041100320	OIL STRAINER	TATA spare parts
409041100321	CONN. ROD /PISTON COMPLETE	TATA spare parts
409041100322	CYLINDER LINE RIGHT	TATA spare parts
409041100323	CYLINDER LINE LEFT	TATA spare parts
409041100324	SHUT-OFF VALVE	TATA spare parts
409041100325	VALVE PLATE	TATA spare parts
409041100326	OIL PUMP	TATA spare parts
409041100327	BEARING CAP	TATA spare parts
409041100328	SHAFT SEAL COVER	TATA spare parts
409041100329	CYLINDER ROLLER BEARING	TATA spare parts
409041100330	CYLINDER HEAD	TATA spare parts
409041100331	SHAFT SEAL WITH O RING	TATA spare parts
409041100332	PRESSURE RELIEF VALVE	TATA spare parts
409041100333	ELECTRO-MAGNETIC CLUTCH	TATA spare parts
409041100334	PULLEY 2A/2B DIA METER 200 MM	TATA spare parts
409041100335	ROTOR	TATA spare parts
409041100336	MAGNET	TATA spare parts
409041100337	CYLINDER ROLLER BEARING	TATA spare parts
409041100338	STRAINING S	TATA spare parts
409041100339	DUMPER RELAY 24V GL	TATA spare parts
409041100340	TEMPERATURE SENSOR REF. GLOBUS	TATA spare parts
409041100341	HEATING MODULE	TATA spare parts
409041100342	FUSE 125A MIDIVAL	TATA spare parts
409041100343	ANTIFREEZING THERMOSTAT	TATA spare parts
409041100344	WATER VALVE BUSH 7/8	TATA spare parts
409041100345	FUSE BOX KAE	TATA spare parts
409041100346	BLOCK BLOWERS	TATA spare parts
409041100347	HINGE	TATA spare parts
409041100348	FLAP MOTOR 24V	TATA spare parts
409041100349	WATER HOSE X5/8IN	TATA spare parts
409041100350	HEATING HOSE 3/4 INCH	TATA spare parts
409041100351	CONDENSER FAN GRILL	TATA spare parts
409041100352	COVER	TATA spare parts
409041100353	STICKER	TATA spare parts
409041100354	FRESH AIR FLAP	TATA spare parts
409041100355	CONDENSER COVER	TATA spare parts
409041100356	SIGHT GLASS 5/8 INCH	TATA spare parts
409041100357	FITTING 1/8 IN NPT X 1/4 IN BRASS W/VENT	TATA spare parts
409041100358	BITZER COMPRESSOR 650CM3 24V	TATA spare parts
409041100359	CLUTCH	TATA spare parts
409041100360	ALTERNATOR 150 AMPS	TATA spare parts
409041100361	PNEUMATIC TENSIONER	TATA spare parts
409041100362	V BELT ALTERNATOR	TATA spare parts
409041100363	WATER PUMP WITH BUCKET	TATA spare parts
409041100364	DASH CONTROL 12/24V	TATA spare parts
409041100365	HOSE	TATA spare parts

409041100366	REUSABLE STRAIGHT FLAT FITTING	TATA spare parts
409041100367	REUSABLE FLAT 45DEG FITTING	TATA spare parts
409041100368	REUSABLE STRAIGHT FLAT FITTING	TATA spare parts
409041100369	REUSABLE FLAT 45DEG FITTING	TATA spare parts
409041100370	MAIN FUSE BOX	TATA spare parts
409041100371	HEATING HOSE 19MM I.D	TATA spare parts
409041100372	RUBBER REDUCER 35 -19MM	TATA spare parts
409041100373	V BELT	TATA spare parts
409041100374	MALE THIMBLE 2.5 SQ	TATA spare parts
409041100375	FEMALE THIMBLE 2.5SQ	TATA spare parts
409041100376	TENSIONER ADOPTER	TATA spare parts
409041100377	TENSIONER HOSE 6MM	TATA spare parts
409041100378	MAIN WIRING HARNESS	TATA spare parts
409041100379	AEROSPHERE MAIN W/H	TATA spare parts
409041100380	SWITCH PRESSURE HIGH	TATA spare parts
409041100381	SWITCH PRESSURE LOW	TATA spare parts
409041100382	REFRIGERANT GAS	TATA spare parts
409041100383	RUBBER PROFILE COVER	TATA spare parts
409041100384	RUBBER PROFILE BASE -COVER	TATA spare parts
409041100385	HOSE ASSY	TATA spare parts
409041100386	ALTERNATOR PULLEY	TATA spare parts
409041100387	INSULATION COVER FOAM	TATA spare parts
409041100388	BELT	TATA spare parts
409041100389	FUSE 10 AMPS	TATA spare parts
409041100390	FUSE 15 AMPS	TATA spare parts
409041100391	COMP & ALTERNATOR BRACKET ASSY	TATA spare parts
409041100392	BELT	TATA spare parts
409041100393	HOSE	TATA spare parts
409041100394	COMPRESSOR OIL	TATA spare parts
409041100395	BANDED BELT	TATA spare parts
409041100396	BANDED BELT	TATA spare parts
409041100397	BANDED BELT	TATA spare parts
409041100402	THERMAL EXPANSION VALVE TOES	TATA spare parts
409041100403	REUSABLE END FITTING FLANGE	TATA spare parts
409041100404	FUSE 10 AMPS	TATA spare parts
409041100405	COVER LEFT/RIGHT	TATA spare parts
409041100406	CONDENSER COVER	TATA spare parts
409041100407	HARDWARE KIT	TATA spare parts
409041100408	ROTOR	TATA spare parts
409041100409	RECTIFIER	TATA spare parts
409041100410	OVERHOUL KIT	TATA spare parts
409041100411	STATOR	TATA spare parts
409041100412	BRUSH KIT	TATA spare parts
409041100413	HIGH RPM PROTECTION	TATA spare parts
409041100414	WIRING HARNESS HIGH RPM (WB380100)	TATA spare parts
409041100415	COVER BOLT ASSY SET M6	TATA spare parts
409041100416	RELAY-24V	TATA spare parts

409041100417	STOP VALVE 3/4 INC	TATA spare parts
409041100418	RETANGULAR CUSHION ASSY (COMP.)	TATA spare parts
409041100419	O RING 1/4 INC	TATA spare parts
409041100420	O RING 1/2 INC	TATA spare parts
409041100421	O RING 5/8 INC	TATA spare parts
409041100422	HEATING COIL (RIGHT SIDE)	TATA spare parts
409041100423	HEATING COIL (LEFT SIDE)	TATA spare parts
409041100424	FOAM AIR FLAP PU+FILM	TATA spare parts
409041100425	EVAPORATOR HARNESS WB120303	TATA spare parts
409041100426	CONDENSER WIRING HARNESS	TATA spare parts
409041100427	SET GASKET COMPRESSOR	TATA spare parts
409041100428	COMPRESSOR SHAFT SEAL ASSY	TATA spare parts
409041100429	COPPER PIPE ASSEMBLY DISCHARGE 25MM ID	TATA spare parts
409041100430	COPPER PIPE ASSEMBLY SUCTION 35.00MM	TATA spare parts
409041100431	RETURN AIR GRILL	TATA spare parts
409041100432	PLASTIC PROFILE	TATA spare parts
409041100433	COVER	TATA spare parts
409041100434	SIKA FLEX 600ML	TATA spare parts
409041100435	COMP. TENSIONER SPRING ASSY	TATA spare parts
409041100436	DRAIN NIPPLE CU	TATA spare parts
409041100437	COMPRESSOR PULLEY 4 GROOVE	TATA spare parts
409041100439	COMPRESSOR OIL	TATA spare parts
409041100440	C SHINE	TATA spare parts
409041100442	ROUND THIMBEL 25X 8	TATA spare parts
409041100468	BANDED BELT	TATA spare parts
409041100476	BANDED BELT (ALT)	TATA spare parts
409041105004	RAW EDGE BANDED BELT_2150	TATA spare parts
409041200201	AC COMPRESSOR BELT	TATA spare parts
409041200202	AC ALTERNATER BELT	TATA spare parts
409042000108	FRONT JACK SUPP ARRG ASSY	TATA spare parts
409042000109	REAR JACK SUPP ARRG ASSY	TATA spare parts
409042000201	LATERAL BASEBOARD ASSEMBLY	TATA spare parts
409042000202	LATERAL BASEBOARD ASSEMBLY	TATA spare parts
409042000203	LATERAL BASEBOARD ASSEMBLY	TATA spare parts
409042000204	LATERAL BASEBOARD ASSEMBLY	TATA spare parts
409042000205	LATERAL BASEBOARD ASSEMBLY	TATA spare parts
409042000206	LATERAL BASEBOARD ASSEMBLY	TATA spare parts
409042000207	LATERAL BASEBOARD ASSEMBLY	TATA spare parts
409042000208	REINFORCEMENT TUBE ASSY	TATA spare parts
409042000231	LATERAL BASEBOARD ASSY	TATA spare parts
409042000251	WINDSHIELD LOWER ROOFSTICK ASSEMBLY	TATA spare parts
409042000263	UPPER FLOOR GUSSET ASSY	TATA spare parts
409042000275	HPR SUPPORT BRACKET ASSY.	TATA spare parts
409042000287	FUEL TANK SUPPORT	TATA spare parts
409042000299	SEAT BELT MOUNTING BRKT ASSY-RH	TATA spare parts
409042000370	SUPPORT PLATE L.H ASSY.	TATA spare parts
409042000371	SUPPORT PLATE .R.H ASSY.	TATA spare parts



409042010108	SCU HORIZONTAL MOUNTING BKT ASSY	TATA spare parts
409042010211	ITS MOUNTING SUPPORT TUBE 40*40MM	TATA spare parts
409042010212	ITS MOUNTING SUPPORT TUBE 40X20MM	TATA spare parts
409042010216	DRIVER FAN BRACKET ASSY (MCV)	TATA spare parts
409042010243	FRONT DESTINATION BOARD BKT ASSY	TATA spare parts
409042010244	FRONT DESTINATION BOARD TUBE ASSY	TATA spare parts
409042010401	WIPER MOTOR COVER PANEL PLATE ASSY	TATA spare parts
409042100201	50 X 40 X 2.70 RECTANGULAR STEEL TUBE	TATA spare parts
409042100205	BUS BODY STRUCTURE AND FRONT JOINT TUBE	TATA spare parts
409042100206	BUS BODY STRUCTURE AND FRONT JOINT TUBE	TATA spare parts
409042100207	G.I.TUBE 30X50X2.7X487	TATA spare parts
409042100208	30 X 40 X 1.95 RECTANGULAR STEEL TUBE	TATA spare parts
409042100209	RECT TUBE FOR AIR INTAKE ASSY	TATA spare parts
409042100210	RECT TUBE FOR AIR INTAKE ASSY	TATA spare parts
409042100212	50 X 40 X 2.70 X 884 LN RECTANGULAR STEE	TATA spare parts
409042100216	GI RECTANGULAR TUBE	TATA spare parts
409042100251	FRONT UPPER ARCHED PIPE	TATA spare parts
409042100310	CROSS MEMBER FASTNING ASSY	TATA spare parts
409042100311	CROSS MEMBER FASTNING ASSY	TATA spare parts
409042200403	WINDSHIELD WIPER AXLE INTERNAL BUSH	TATA spare parts
409042500202	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042500203	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042500204	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042500205	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042500206	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042500207	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042500209	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042500210	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042500211	JOINT GUSSET OF THE CHASSIS SUPERSTRUCT.	TATA spare parts
409042500212	JOINT GUSSET OF THE CHASSIS SUPERSTRUCT.	TATA spare parts
409042500213	JOINT GUSSET OF THE CHASSIS SUPERSTRUCT.	TATA spare parts
409042500214	ENTRANCE PLATFORM REINFORCEMENT	TATA spare parts
409042500215	GUSSET-78X78X1.95 THK	TATA spare parts
409042500216	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042500217	LOWER AND SIDE BASE GUSSET	TATA spare parts
409042500218	COVER SHEET	TATA spare parts
409042500223	ACCELERATOR CABLE FIX. SUPPORT	TATA spare parts
409042500225	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042500227	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042500229	BASEBOARD CLOSING	TATA spare parts
409042500236	FRONT WINDSHIELD REINFORCEMENT	TATA spare parts
409042500237	FRONT WINDSHIELD REINFORCEMENT	TATA spare parts
409042500238	FRONT WINDSHIELD REINFORCEMENT	TATA spare parts
409042500240	FRONT WINDSHIELD REINFORCEMENT	TATA spare parts
409042500242	FRONT WINDSHIELD REINFORCEMENT	TATA spare parts
409042500243	FRONT WINDSHIELD REINFORCEMENT	TATA spare parts
409042500244	DESTINATION WINDSHIELD REINFORCEMENT PLA	TATA spare parts

409042500245	DESTINATION WINDSHIELD REINFORCEMENT PLA	TATA spare parts
409042500247	REAR WINDSHIELD REINFORCEMENT PLATE	TATA spare parts
409042500249	REAR WINDSHIELD REINFORCEMENT PLATE	TATA spare parts
409042500250	REAR WINDSHIELD REINFORCEMENT PLATE	TATA spare parts
409042500252	BODY IDENTIFICATION NUMBER PLATE	TATA spare parts
409042500253	INTERNAL FINISHING SUPPORT	TATA spare parts
409042500255	REAR WINDSHIELD REINFORCEMENT PLATE	TATA spare parts
409042500257	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042500258	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042500259	BASE JOINT GUSSET ASSEMBLY	TATA spare parts
409042500260	2.70 STEEL PLATES (12)	TATA spare parts
409042500262	GUEESTS FOR CLOSING OF LATERAL BASE BOAR	TATA spare parts
409042500263	FRONT WINDSHIELD REINFORCEMENT	TATA spare parts
409042500264	FRONT WINDSHIELD REINFORCEMENT	TATA spare parts
409042500265	FRONT WINDSHIELD REINFORCEMENT	TATA spare parts
409042500266	FRONT WINDSHIELD REINFORCEMENT	TATA spare parts
409042500267	BASEBOARD CLOSING	TATA spare parts
409042500268	SHELL BODY IDENTIFICATION NUMBER	TATA spare parts
409042500274	SUPPORT PROFILE	TATA spare parts
409042500281	U-PROFILE	TATA spare parts
409042500297	BOX TYPE GUSSET	TATA spare parts
409042500298	L-PLATE	TATA spare parts
409042510467	REINFORCEMENT FRONT STR MIDDLE	TATA spare parts
409042600239	AIR FILTER GAUGE BKT	TATA spare parts
409042700201	JOINT GUSSET OF THE CHASSIS SUPERSTRUCT.	TATA spare parts
409042700202	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042700204	SIDE CLOSING PLATE	TATA spare parts
409042700206	BASEBOARD CLOSING	TATA spare parts
409042700207	JOINT GUSSET LOWER BASE W/ UPPER BASE	TATA spare parts
409042700209	WHEELBASE RAMP REINFORCEMENT	TATA spare parts
409042700210	WHEELBASE RAMP REINFORCEMENT	TATA spare parts
409042700211	FLOOR L PROFILE	TATA spare parts
409042700212	REAR BUMPER ATTACHMENT SUPPORT	TATA spare parts
409042700213	REAR BUMPER ATTACHMENT SUPPORT	TATA spare parts
409042700214	REAR BUMPER ATTACHMENT SUPPORT	TATA spare parts
409042700215	CABLE SUPPORT	TATA spare parts
409042700216	315X50X3 PLATE	TATA spare parts
409042700217	L-PROFILE 130 X 190 X 750 LN X 2 THK.	TATA spare parts
409042700218	L-PROFILE 40 X 30 X 580 LN X 2 THK.	TATA spare parts
409042700219	M.S PLATE 300 X 55 X 3 THK.	TATA spare parts
409042700220	L-PROFILE 35 X 35 X 2 THK.	TATA spare parts
409042700221	L-PROFILE 35 X 35 X 2 THK.	TATA spare parts
409042700222	L-PROFILE 35 X 35 X 2 THK.	TATA spare parts
409042700223	L-PROFILE 30 X 30 X 2 THK.	TATA spare parts
409042700224	M.S PLATE 900 X 30 X 3 THK.	TATA spare parts
409042700225	L-PROFILE 40 X 40 X 110 LN X 2 THK.	TATA spare parts
409042700226	L-PROFILE 40 X 40 X 570 LN X 2 THK.	TATA spare parts

409042700227	L-PROFILE 50 X 30 X 580 LN X 2 THK.	TATA spare parts
409042700228	L-PROFILE 30 X 30 X 800 LN X 2 THK.	TATA spare parts
409042700229	LH DASHBOARD SUPPORT PLATE	TATA spare parts
409042700231	MS PLATE 700 X 80 X 2 THK.	TATA spare parts
409042700232	RH DASHBOARD SUPPORT PLATE	TATA spare parts
409042700233	PLATE 500 X 90 X 2 THK.	TATA spare parts
409042700234	PLATE 120 X 60 X 3 THK.	TATA spare parts
409042700235	PLATE 130 X 30 X 3 THK.	TATA spare parts
409042700236	M.S PLATE 120 X 70 X 4 THK.	TATA spare parts
409042700238	GUSSET PLATE	TATA spare parts
409042700239	CLOSING COVER FOR FOOT STEP AT PASSENGER	TATA spare parts
409042700240	L-PROFILE40 X 30 X 640 LN X 2 THK.	TATA spare parts
409042700241	L-PROFILE40 X 35 X 325 LN X 2 THK.	TATA spare parts
409042700243	C-PROFILE40 X 42 X 720 LN X 2 THK.	TATA spare parts
409042700244	L-PROFILE35 X 35 X 740 LN X 2 THK.	TATA spare parts
409042700245	L-PROFILE45 X 25 X 645 LN X 2 THK.	TATA spare parts
409042700246	L-PROFILE30 X 30 X 350 LN X 2 THK.	TATA spare parts
409042700247	L-PROFILE30 X 30 X 190 LN X 2 THK.	TATA spare parts
409042700248	L-PROFILE35 X 35 X580 LN X 2 THK.	TATA spare parts
409042700249	PLATE-140 X 110 X 2 THK.	TATA spare parts
409042700250	PLATE-100 X 80 X 2 THK.	TATA spare parts
409042700251	PLATE-180 X100 X 2 THK.	TATA spare parts
409042700252	REINFORCEMENT PLATE	TATA spare parts
409042700253	REINFORCEMENT PLATE	TATA spare parts
409042700260	JOINT GUSSET LOWER BASE W/UPPER BASE	TATA spare parts
409042700269	MS PLATE 100X60X5 THK.	TATA spare parts
409042700275	COVERING SHEET	TATA spare parts
409042700288	UPPER BASE AXLE BASEBOARD-1	TATA spare parts
409042700290	RISER UPPER SUPPORT	TATA spare parts
409042700294	SUPPORT PLATE BELOW THE UPPER FLOOR(LH)	TATA spare parts
409042700295	SUPPORT PLATE BELOW THE UPPER FLOOR(RH)	TATA spare parts
409042700303	BASEBOARD CLOSING	TATA spare parts
409043000201	GAS CYLINDER EXTERNAL REVETMENT	TATA spare parts
409043000202	GAS TANK FLAP ASSEMBLY	TATA spare parts
409043000203	HINGED DOORS OPENING LIMITER	TATA spare parts
409043000204	GAS CYLINDER EXTERNAL REVETMENT	TATA spare parts
409043000205	GAS CYLINDER EXTERNAL REVETMENT	TATA spare parts
409043000208	VENT COVERING ASSY (LH)	TATA spare parts
409043000209	VENT COVERING ASSY (RH)	TATA spare parts
409043000213	BATTERY COVER WITH FLAP ASSY_EV_4X12	TATA spare parts
409043300201	CNG PLATFORM FLOOR PLATE	TATA spare parts
409043300202	CNG PLATFORM FLOOR PLATE	TATA spare parts
409043300203	CNG PLATFORM PLATE	TATA spare parts
409043300304	CNG PLATFORM FLOOR PLATE 560X402X1.25 TH	TATA spare parts
409043300305	CNG PLATEFORM PLATE 560X248X2.2 THK	TATA spare parts
409043500301	CHAIN FIXING SUPPORT	TATA spare parts
409043990305	HINGE FOR PISTON BOX COVER	TATA spare parts

409044100201	2 MM ANTI-SKID WITH SILICON GRAIN CANOPU	TATA spare parts
409044100202	VINYL FLOOR YELLOW (TML REF NO 532000944	TATA spare parts
409044100203	VINYL FLOOR CANOPUS RED	TATA spare parts
409044100205	CANOPUS GRAY VINYL WITHOUT TEX.	TATA spare parts
409044100206	PLAIN RED VINYL RESPONSIVE	TATA spare parts
409044100209	ANTI SKID VINYL 2 MM (CANOPUS-53295054)	TATA spare parts
409044100215	VINYL FLR.3MM.THK_RE CANOPUS 5329-506-4	TATA spare parts
409044100219	VINYL FLOOR 1.5MM THK_5329-519-4GREY	TATA spare parts
409044300201	STAIR FINISHING TRIM (YELLOW)	TATA spare parts
409044300202	TRIANGULAR PVC WELDING ROD RED(4MM THK.)	TATA spare parts
409044300203	ROUND PVC WELDING ROD RED.	TATA spare parts
409044700301	INSPECTION COVER PLATE_2.7 THK	TATA spare parts
409045000102	DESTINATION DISPLAY UNIT KIT	TATA spare parts
409045000106	MOBITEC MOBI MASTER	TATA spare parts
409045000108	DESTINATION BOARD (3 BOARD)	TATA spare parts
409045000116	GPS/GPRS VEHICLE TRACKING MODEM	TATA spare parts
409045000130	4 DESTINATION SIGNS ASSY MOBITEC ICU 602	TATA spare parts
409045000156	ASSY DWG FOR SUPPORT BKT FOR SIDE D.B.	TATA spare parts
409045000160	FRONT DESTINATION BOARD BS4	TATA spare parts
409045000161	FRONT INNER DESTINATION BOARD	TATA spare parts
409045000162	SIDE & REAR DESTINATION BOARD BS4	TATA spare parts
409045000164	FRONT DESTINATION BOARD BRACKET ASSY	TATA spare parts
409045000165	FRONT DESTINATION BOARD BRACKET ASSY LH	TATA spare parts
409045000171	DISPLAY CONTROLLER EURO3	TATA spare parts
409045000172	GPS ANTENNA	TATA spare parts
409045000174	INNER DESTINATION BOARD BKT ASSY LH	TATA spare parts
409045000175	INNER DESTINATION BOARD BKT ASSY RH	TATA spare parts
409045000178	FRONT DESTINATION BOARD BRKT LH	TATA spare parts
409045000179	FRONT DESTINATION BOARD BRKT RH	TATA spare parts
409045000180	INTERNAL DESTINATION BOARD BRKT RH	TATA spare parts
409045000181	REAR DESTINATION BOARD BRKT RH	TATA spare parts
409045000182	REAR DESTINATION BOARD BRKT LH	TATA spare parts
409045000183	INTERNAL DESTINATION BOARD BRKT LH	TATA spare parts
409045000184	SIDE DESTI BOARD SUPPORTING BRKT ASSY_RH	TATA spare parts
409045000185	SIDE DESTI BOARD SUPPORTING BRKT ASSY_LH	TATA spare parts
409045000192	ROOF ANTENA MOUNTING BKT KPIT	TATA spare parts
409045000201	DRIVER CONTROLLER	TATA spare parts
409045000202	FRONT DISPLAY BOARD	TATA spare parts
409045000203	SIDE DISPLAY BOARD	TATA spare parts
409045000204	REAR DISPLAY BOARD	TATA spare parts
409045000205	INSIDE DISPLAY BOARD	TATA spare parts
409045000206	POWER MODULE	TATA spare parts
409045000207	POWER MODULE	TATA spare parts
409045000208	FUSE 2A	TATA spare parts
409045000209	FUSE 5A	TATA spare parts
409045000210	FUSE 6A	TATA spare parts
409045000211	IN4148	TATA spare parts

409045000212	INDUCTOR LH30	TATA spare parts
409045000213	INDUCTOR LH100	TATA spare parts
409045000214	FLASH MEMORY	TATA spare parts
409045000215	FLASH MEMORY	TATA spare parts
409045000216	IC4953	TATA spare parts
409045000217	STC89C54RD+ OR AT89S52	TATA spare parts
409045000218	HM62256	TATA spare parts
409045000219	74HC595	TATA spare parts
409045000220	MBI5026GF	TATA spare parts
409045000221	DJ7031-6.3-11	TATA spare parts
409045000222	DJ7031-6.3-21	TATA spare parts
409045000223	DRIVE BOARD	TATA spare parts
409045000224	DRIVE BOARD	TATA spare parts
409045000225	CONTRO BOARD	TATA spare parts
409045000226	CONTRO BOARD	TATA spare parts
409045000227	BRIGHT SENSOR	TATA spare parts
409045000228	MICROPHONE PLASTIC	TATA spare parts
409045000229	PLAS ENCL OF FRONT SIGN ANTI-STATIC PMM	TATA spare parts
409045000230	PLAS ENCL OF SIDE SIGN ANTI-STATIC PMMA	TATA spare parts
409045000231	PLASTIC ENCLOSURE OF REAR SIGN ANTI-STA	TATA spare parts
409045000232	PLASTIC ENCLOSURE OF INSIDE INDICATOR A	TATA spare parts
409045000233	ARCH PLASTIC SUPPORT	TATA spare parts
409045000234	RVVP 2¿28/0.15 15M WITH CONNECTORS	TATA spare parts
409045000235	RVVP 2¿28/0.15 8M WITH CONNECTORS	TATA spare parts
409045000242	FRONT BOARD HANOVER	TATA spare parts
409045000243	REAR AND SIDE BOARD HANOVER (AS MOUD)	TATA spare parts
409045000244	INTERNAL BOARD HANOVER	TATA spare parts
409045000245	ERIC CONTROLLER HANOVER	TATA spare parts
409045000247	VOICE ANNOUNCEMENT SOFTWARE AND HARDW	TATA spare parts
409045000248	MIKE MM 60M	TATA spare parts
409045000251	GOOSENECK DRIVER MICROPHONE	TATA spare parts
409045000272	REAR DESTINATION BOARD SUPPORT BKT	TATA spare parts
409045000274	FRONT DEST. BOARD BKT ASSY RH SIDE	TATA spare parts
409045000275	FRONT DEST. BOARD BKT ASSY LH SIDE	TATA spare parts
409045000291	FRONT DESTINATION BOARD	TATA spare parts
409045000292	INTERNAL DESTINATION BOARD	TATA spare parts
409045000293	SIDE DESTINATION BOARD	TATA spare parts
409045000294	SIDE AND REAR DESTINATION BOARD	TATA spare parts
409045000301	BUS SPEAKER	TATA spare parts
409045000302	DRIVE BOARD	TATA spare parts
409045000303	DISPLAY BOARD	TATA spare parts
409045000304	DRIVE BOARD	TATA spare parts
409045000305	DISPLAY BOARD	TATA spare parts
409045000306	20 CORED SHORT FLAT	TATA spare parts
409045000307	CONTRO BOARD	TATA spare parts
409045000308	RVVP 4¿28/0.15	TATA spare parts
409045000309	POWER MODULE	TATA spare parts

409045000310	DISPLAY BOARD	TATA spare parts
409045000311	20 CORED LONG FLAT	TATA spare parts
409045000330	REAR DEST. BOARD BKT ASSY	TATA spare parts
409045100233	SPEAKER WITH GRILL	TATA spare parts
409045100234	SPEAKER W/O GRILL	TATA spare parts
409045100236	IP CAMERA	TATA spare parts
409045100237	MICROPHONE	TATA spare parts
409045100238	BUS DRIVER CONSOLE	TATA spare parts
409045100240	SCU WITH ENCLOSURE	TATA spare parts
409045100248	WH SCU TO SPEAKER	TATA spare parts
409045100249	MICROPHONE WITH SPEAKER	TATA spare parts
409045500105	DESTINATION BOARD SUPPORT PLATE-RH	TATA spare parts
409045500106	DESTINATION BOARD SUPPORT PLATE-LH	TATA spare parts
409045500201	SUPPORT PLATE	TATA spare parts
409045500202	SUPPORT PLATE	TATA spare parts
409045500203	BRACKET OF REAR SIGN 2 MM THICK	TATA spare parts
409045500204	BRACKET OF REAR SIGN 2 MM THICK	TATA spare parts
409045500205	BRACKET OF SIDE SIGN 2 MM THICK	TATA spare parts
409045500206	BRACKET OF SIDE SIGN 2 MM THICK	TATA spare parts
409045500207	BRACKET OF FRONT SIGN 2 MM THICK	TATA spare parts
409045500208	BRACKET OF FRONT SIGN 2 MM THICK	TATA spare parts
409045500209	BRACKET OF INSIDE INDICATOR 2 MM THICK	TATA spare parts
409045500214	DESTINATION BOARD SUPPORT PLATE 1	TATA spare parts
409045500215	DESTINATION BOARD SUPPORT PLATE 2	TATA spare parts
409045500222	INSIDE BRACKET LH	TATA spare parts
409045500234	DESTINATION BOARD BARCKET REAR LH	TATA spare parts
409045500235	DESTINATION BOARD BRACKET REAR RH	TATA spare parts
409045500241	FRONT DESTINATION BRACKET	TATA spare parts
409045500242	FRONT DESTINATION BRACKET	TATA spare parts
409045500252	FRONT DESTINATION BOARD RH BRKT (MIDI)	TATA spare parts
409045500253	FRONT DESTINATION BOARD LH BRKT (MIDI)	TATA spare parts
409045500275	REAR INT DESTI BOARD SUPP BRKT ASSY_LH	TATA spare parts
409045500277	REAR DESTINATION BOARD ASSY RH	TATA spare parts
409045800301	CABLE CONNECT BOX/ SIGN 3 5M	TATA spare parts
409045800302	CABLE CONNECT BOX/ SIGN 7 0M	TATA spare parts
409045800303	CABLE CONNECT BOX/ SIGN 16 0M	TATA spare parts
409045800304	CABLE CONNECT BOX/ SIGN 6 0M	TATA spare parts
409045800305	CONNECT BOX - CB-8	TATA spare parts
409045800306	CABLE POWER SUPPLY 0 5M	TATA spare parts
409045800307	CABLE CONTROL UNIT (ICU)/ CONNECT BOX 7	TATA spare parts
409045800308	CABLE¿ TACHO-DOOR 3M	TATA spare parts
409045800309	CAB DVA CONECT BOX MIC OUTPUT	TATA spare parts
409045800310	CABLE DOOR TACHO SIGNAL	TATA spare parts
409045800311	CAB C.BOX/ JOIN 5 0M	TATA spare parts
409045800312	ADDRESS PLATE (LB) NEW SIGNS	TATA spare parts
409045800313	SIDE PROFILE LEFT	TATA spare parts
409045800314	SIDE PROFILE RIGHT	TATA spare parts

409045800315	FUSE MINI-CAR 5A	TATA spare parts
409046000101	DASH BOARD ASSY	TATA spare parts
409046000181	FRP LPO 1621 AT AC DASHBOARD ASSY	TATA spare parts
409046000201	PANEL PLATE ASSY	TATA spare parts
409046000202	PANEL PLATE ASSY	TATA spare parts
409046000203	PANEL ASSEMBLY	TATA spare parts
409046000204	PANEL ASSEMBLY	TATA spare parts
409046000205	FRP DUCT DASH BOARD ASSY	TATA spare parts
409046000215	DASHBOARD CLUSTER PANEL ASSY NON-AC	TATA spare parts
409046000218	DASH BOARD ASSY L.H.SIDE (WITHOUT TEX.)	TATA spare parts
409046000219	DASH BOARD ASSY L.H.SIDE	TATA spare parts
409046000221	DASH BOARD ASSY L.H.SIDE(DTC N-AC-BS4)	TATA spare parts
409046000223	ASSY DASHBOARD	TATA spare parts
409046000228	DASHBOARD INFORMATION DRG HYBRID	TATA spare parts
409046000229	FRP ENGINE HOOD ASSY	TATA spare parts
409046000230	FRP DASHBOARD ASSY	TATA spare parts
409046000233	FRP NONMULTPX INSTRNT CUSTERBOX RHD	TATA spare parts
409046000236	FRP WINDSHIELD COLUMN FINISH-LH	TATA spare parts
409046000237	FRP WINDSHIELD COLUMN FINISH-RH	TATA spare parts
409046000254	FRP LOWERED ENGINE DASHBOARD ASSY	TATA spare parts
409046000292	PANEL PLATE ASSEMBLY	TATA spare parts
409046000340	LH PANEL PLATE ASSY	TATA spare parts
409046010201	CLUSTER ASSY BS6	TATA spare parts
409046100103	ABS CLUSTER FINISHING COVER	TATA spare parts
409046100201	DASH BOARD LH SIDE	TATA spare parts
409046100202	ELE MAINTENANCE COVER	TATA spare parts
409046100203	ELE CENTRAL BOX	TATA spare parts
409046100204	INSTRUMENTAL PANEL BOX	TATA spare parts
409046100205	MAINTENANCE COVER FOR INSTRUMENTAL PANEL	TATA spare parts
409046100206	MIDDLE CEILING FINISHING TRIM	TATA spare parts
409046100207	DASH BOARD LH SIDE	TATA spare parts
409046100208	HMI SWITCH MOUNTING BASE PLATE	TATA spare parts
409046100209	HMI SWITCH MOUNTING BASE PLATE	TATA spare parts
409046100216	HMI SWITCH MOUN.BASE PLATE(WITHOUT TEX)	TATA spare parts
409046100217	HMI SWITCH SUPPORT PLATE(WITHOUT TEX)	TATA spare parts
409046100225	DASH BOARD & FLAP ASSY_EV	TATA spare parts
409046100301	FRP MULTIPLEX INSTRUMENT CLUSTER	TATA spare parts
409046100307	FRP MULTIPLEXING CLUSTER(WITHOUT TEX)	TATA spare parts
409046500116	PANEL PLATE-LH	TATA spare parts
409046500136	LH PANEL PLATE BKT ASSY	TATA spare parts
409046500137	DASHBOARD SWITCH PLATE FOR LHD (LH)	TATA spare parts
409046500138	DASHBOARD SWITCHES PLATE¿ LHD (LH)	TATA spare parts
409046500139	RH PLATE FOR HANOVER CONTROLLER	TATA spare parts
409046500141	HANDBRAKE PLATE ASSY	TATA spare parts
409046500142	DASHBOARD HAND BRAKE PLATE	TATA spare parts
409046500144	PANEL PLATE-LH	TATA spare parts
409046500201	PANEL PLATE	TATA spare parts

409046500202	PANEL PLATE	TATA spare parts
409046500203	SIDE BASEBOARD	TATA spare parts
409046500206	RH DASHBOARD SWITCHES PLATE	TATA spare parts
409046500207	RH DASHBOARD SWITCHES PLATE	TATA spare parts
409046500209	RH DASHBOARD SWITCHES PLATE	TATA spare parts
409046500221	CHASSIS PANE PLATE	TATA spare parts
409046500227	DVD PANEL PLATE	TATA spare parts
409046500249	DASHBOARD PLATE LH RHD VIEW DIMITS	TATA spare parts
409046500257	PANEL PLATE ASSY MUX	TATA spare parts
409046500258	RADIO PANEL PLATE	TATA spare parts
409046500261	Z PLATE FOR CLUSTER SUPPORT LE	TATA spare parts
409046500268	PANEL PLATE-LH	TATA spare parts
409046500271	PANEL PLATE-LH_AT	TATA spare parts
409046500272	PANEL PLATE-RH	TATA spare parts
409046500281	RH SIDE CHASSIS SWITCH PLATE	TATA spare parts
409046500307	SWITCHES PLATE 1 (RH)	TATA spare parts
409046500308	SWITCHES PLATE 2 (LH)	TATA spare parts
409046500310	CHASSIS SW PLATE 2 LH	TATA spare parts
409046500401	FAST COUPLING CENTER AXLE	TATA spare parts
409046990401	FAST COUPLING LATCH	TATA spare parts
409046990402	VENTILATION FINISHING GRILLE	TATA spare parts
409047000201	LOCK SUPPORT ASSEMBLY	TATA spare parts
409047100101	INTERNAL LOCK	TATA spare parts
409047100102	EXTERNAL LOCK	TATA spare parts
409047100106	LOCKSANDLATCHES	TATA spare parts
409047100107	KEY	TATA spare parts
409047400101	DOOR STOPPER	TATA spare parts
409047500101	SECURITY TOP STAFF	TATA spare parts
409047500102	LATCH ATTACHMENT SUPPORT	TATA spare parts
409047500103	LUGGAGE DOOR LATCH CLOSING COUPLER	TATA spare parts
409047500104	SHUTTER LATCH CLOSING COUPLING	TATA spare parts
409047500105	FLAP LATCH COUPLING	TATA spare parts
409047500106	INTERNAL STAFF HANDLE START	TATA spare parts
409047500107	LOCK OPERATING PIN	TATA spare parts
409047500108	LH DOOR OPERATED ROD LOOP	TATA spare parts
409047500109	MS ROD Dia 4X265 LONG	TATA spare parts
409047700101	KNOB FOR HINGED DOOR ITEMS	TATA spare parts
409047700102	DRIVER DOOR HANDLE	TATA spare parts
409047700103	EXTERNAL HANDLE	TATA spare parts
409047700104	EXTERNAL HANDLE LOCKING ROD	TATA spare parts
409047700201	SPONGY RUBBER PROFILE	TATA spare parts
409047800101	GAS PISTON	TATA spare parts
409047800102	GAS PISTON	TATA spare parts
409047800103	GAS PISTON	TATA spare parts
409047800104	GAS PISTON 41KG	TATA spare parts
409047990101	DOOR FACING	TATA spare parts
409047990102	DOOR LOCK BUTTON	TATA spare parts



409048000101	FUEL TANK NOZZLE ASSEMBLY	TATA spare parts
409049100201	POLYAMIDE TUBE - CIRCULAR SECTION	TATA spare parts
409049100202	6-MM DIAMETER 1-MM THICK ROUND RED POLY	TATA spare parts
409049100203	TE0806Y YELLOW SMC 8 DIA POLYE. PIPE	TATA spare parts
409049100204	8 DIA POLYETHYLENE PIPE	TATA spare parts
409049100205	BLACK SMC 8 DIA POLYETH.PIPE	TATA spare parts
409049200201	STAINLESS BRACKET WITH RUBBER TRIM	TATA spare parts
409049200202	STAINLESS BRACKET WITH RUBBER TRIM	TATA spare parts
409049200203	STEEL BRACKET WITH RUBBER TRIM	TATA spare parts
409049200204	CLAMP	TATA spare parts
409049200205	Z-PLATE FOR WIRE HARNESS	TATA spare parts
409049300201	BLACK POLYAMIDE BRACKET - 7.6MM WIDTH	TATA spare parts
409049300202	2.6-MM WIDE BLACK POLYAMIDE BRACKET	TATA spare parts
409049300203	12.5-MM WIDE BLACK POLYAMIDE BRACKET	TATA spare parts
409049300204	POLYAMIDE CLAMP	TATA spare parts
409049300205	19-MM WIDE BLACK POLYAMIDE BRACKET	TATA spare parts
409049300206	15.7-MM WIDE BLACK POLYAMIDE BRACKET	TATA spare parts
409049300207	12.5-MM WIDE BLACK POLYAMIDE BRACKET	TATA spare parts
409049300208	27 UP TO 31.8-MM BLACK POLYAMIDE BRACKET	TATA spare parts
409049300209	STAINLESS BRACKET WITH RUBBER TRIM	TATA spare parts
409049300211	ROUND CLAMP FOR WIRING HARNESS	TATA spare parts
409049300301	CABLE TIE	TATA spare parts
409049400201	CRYSTAL FLEXIBLE PVC HOSE	TATA spare parts
409049800201	STRAIGHT JOIN FOR THERMOPLASTIC TUBE	TATA spare parts
409049900201	6-MM DIAMETER PIPE BRASS INSERT	TATA spare parts
409052010139	FRONT UNION ASSEMBLY	TATA spare parts
409077100203	BUS BODY PRIMER	TATA spare parts
409077200201	CAULKING COMPOUND	TATA spare parts
409077200202	SPRAY ADHESIVE	TATA spare parts
409077200203	CAULKER	TATA spare parts
409077200204	ADHESIVE FOR FODDER	TATA spare parts
409077200210	ADHESIVE 600ML WHITE	TATA spare parts
409077200215	CAULKER	TATA spare parts
409077200217	SIKA BOOM	TATA spare parts
409077200218	SYN ADHESIVES 196	TATA spare parts
409077200219	SYN ADHESIVES 222	TATA spare parts
409077200221	MCCOY PU FOAM	TATA spare parts
409077200224	ANABOND 666 BLACK CARTRIDGE	TATA spare parts
409077300209	ADHESIVE TAPE FOR SEALING-3X20X15000-MM	TATA spare parts
409077300211	6MM WIDE DOUBLE FACE TAPE(1.1MM THICK)	TATA spare parts
409077300212	6X50X15000MM-ADHESIVE TAPE FOR SEALING	TATA spare parts
409077300213	CRAPE PROTECTOR TAPE 25MM WIDTH	TATA spare parts
409077600201	GEL SOAP FOR WINDOWS ASSLY.	TATA spare parts
409077700201	SURFACE ACTIVATOR	TATA spare parts
409077990201	BLACK STICKER PLASTIC FILM	TATA spare parts
409077994501	ROYAL BOND SPTM	TATA spare parts
409078100101	TOP COAT	TATA spare parts

409078100102	HARDNER FOR TOP COAT	TATA spare parts
409078100105	SILVER GREY	TATA spare parts
409078100107	MATT BLACK PAINT	TATA spare parts
409078100108	TOP COAT MAROON	TATA spare parts
409078100115	BILUX WHITE EFT PAINT	TATA spare parts
409078100117	PURPLE COLOUR PAINT	TATA spare parts
409078200101	ETCH PRIMER	TATA spare parts
409078200102	ETCH HARDNER	TATA spare parts
409078200103	PRIMER SURAFCE	TATA spare parts
409078200109	STRUCTURAL PRIMER	TATA spare parts
409078200110	STRUCTURAL PR HARDNER	TATA spare parts
409078300101	CLEANING THINNER	TATA spare parts
409078300102	DEGREASER	TATA spare parts
409078300104	THINNER	TATA spare parts
409078300109	THINNER FOR UNDER BODY COATING	TATA spare parts
409078400101	PUTTY	TATA spare parts
409078400103	PUTTY FOR PLYWOOD JOINT	TATA spare parts
409078400105	POLYESTER PUTTY	TATA spare parts
409078500101	UNDERCOATING	TATA spare parts
409078500102	UNDER COATING BLACK	TATA spare parts
409078900201	AUTOFROTH B5(A SIDE)	TATA spare parts
409078900202	AUTOFROTH B5(B SIDE)	TATA spare parts
409080000101	KIT PART NO FOR DIMTS	TATA spare parts
409087010007	AIR DRIVING GUIDE	TATA spare parts
409087010008	AIR DRIVING GUIDE	TATA spare parts
409087010009	AIR DUCT CLOSING	TATA spare parts
409087010010	AIR DRIVING GUIDE	TATA spare parts
409087010011	AIR DRIVING GUIDE	TATA spare parts
409087010012	LOUDSPEAKER GRILLE	TATA spare parts
409087010013	AIR OUTLET DEFLECTOR	TATA spare parts
409087010020	AIR OUTLET FINISH	TATA spare parts
409087010035	AIR CURTAIN TRAY	TATA spare parts
409087010051	DEMISTER	TATA spare parts
409087010057	DEFROSTER ATTACHMENT CONTOUR	TATA spare parts
409087010101	BATTERY BOX RETRO KIT	TATA spare parts
409087010108	DISCHARGE HOSE 40INC	TATA spare parts
409087010119	ROUND THIMBLE	TATA spare parts
409087010120	MALE THIMBLE 1.5MM	TATA spare parts
409087010121	FEMALE THIMBLE 1.5MM	TATA spare parts
409087010130	GRIIL LOCK BOLT	TATA spare parts
409087010202	PANEL PLATE	TATA spare parts
409087020003	LIGHT SET AIR OUTLET	TATA spare parts
409087020005	POWER ATTACHING SUPPORT	TATA spare parts
409087020008	FIXING CLIP BRACKET	TATA spare parts
409087020133	AIR CURTAIN LOUVER	TATA spare parts
409087050005	APERTURE EDGE BEADING	TATA spare parts
409087050012	SUNSHADE STALK ATTACHMENT BASE	TATA spare parts

409087050033	EMERGENCY HAMMER COVER	TATA spare parts
409087050034	EMERGENCY WINDOW HAMMER ASSY.	TATA spare parts
409087050040	ALUMINIUM PROFILE	TATA spare parts
409087050062	LUMINARY ACRYLIC	TATA spare parts
409087050067	FLUORESCENT LAMP CLAMP	TATA spare parts
409087050076	LUGGAGE RACK PROFILE PATCH	TATA spare parts
409087050078	LAMP	TATA spare parts
409087050084	ALUMINIUM PROFILE	TATA spare parts
409087050090	ALUMINIUM PLATE 2.00	TATA spare parts
409087050091	ALUMINIUM PLATE FOLDED IN L 2MM	TATA spare parts
409087050275	RH VENTILATORS ELECTRIC HARNESS	TATA spare parts
409087050276	LH VENTILATORS ELECTRIC HARNESS	TATA spare parts
409087050277	UPPER FRONT ELECTRIC HARNESS	TATA spare parts
409087050278	DASHBOARD ELECTRIC HARNESS	TATA spare parts
409087050279	ELECTRIC POWER PLANT HARNESS	TATA spare parts
409087050302	INTERNAL GREEN 1.5 X 29.5 FLEXIBLE PVC H	TATA spare parts
409087050303	INTERNAL GREEN 1.5 X 37.5 FLEX PVC HOSE	TATA spare parts
409087050310	PLACARDS PLATES AND ADHESIVES	TATA spare parts
409087050315	FUSE PIG TAIL HARNESS	TATA spare parts
409087050323	KIT TO CONVERT DISABLE FRIENDLY BUS	TATA spare parts
409087050325	KIT DIGITAL CLOCK ASSY	TATA spare parts
409087050401	CLAMP (DASHBOARD STAY ROD)	TATA spare parts
409087060004	HEXAGON BOX NUTS	TATA spare parts
409087060005	8.4X14X1.0-MM TOOTHED WASHER	TATA spare parts
409087060007	BOX NUT - DIN 1587	TATA spare parts
409087060009	FLAT HEAD SCREWS	TATA spare parts
409087060015	SQUARE HEAD SCREWS	TATA spare parts
409087060018	SPECIAL SCREW	TATA spare parts
409087070003	KIT FRONT STRUCTURE ASSY	TATA spare parts
409087070004	KIT REAR STRUCTURE ASSY	TATA spare parts
409087070102	KIT FOR RETRO (ENGINE HOOD)	TATA spare parts
409087100101	SOLENOID VALVE ( PILOT OPERATED)	TATA spare parts
409087100102	DOOR SUPPORT END BKT. ( R ) (1230002022)	TATA spare parts
409087100103	ECCENTRIC BOLT FOR DOOR	TATA spare parts
409088000194	EXT REVETMENT PLATES BETWEEN WINDOWS	TATA spare parts
409088000198	STRETCH PANEL LH FRONT-4	TATA spare parts
409088000199	STRETCH PANEL LH FRONT	TATA spare parts
409088000208	EXTERNAL PANEL AT EXTREME END L.H SIDE	TATA spare parts
409088000211	EXT REVETMENT PLATES BETWEEN WINDOWS	TATA spare parts
409088000212	EXT REVETMENT PLATES BETWEEN WINDOWS	TATA spare parts
409088000213	STRECH PANEL RH	TATA spare parts
409088000215	DRIVER DOOR STIRRUP	TATA spare parts
409088000216	EXTERNAL PANEL AT DRIVER DOOR	TATA spare parts
409088000217	EXTERNAL FINISHING PROFILE RH REAR	TATA spare parts
409088000219	SKRIT PANEL AT BATTERY BOX	TATA spare parts
409088000225	SIDE EXTERNAL ABOVE DRIVER DOOR	TATA spare parts
409088000227	EXTERNAL FINISHING PROFILE LH FRONT	TATA spare parts

409088000228	GI PLATE 600X50X.65	TATA spare parts
409088000229	EXTERNAL FINISHING PROFILE LH REAR	TATA spare parts
409088000230	EXTERNAL FINISHING PROFILE RH FRONT	TATA spare parts
409088000234	SPRING CLAMP	TATA spare parts
409088000236	FLAP GUIDE LOCK ASSY RH	TATA spare parts
409088000237	GUIDE LOCK ASSY LH	TATA spare parts
409088000238	HINGH ASSY. LH	TATA spare parts
409088000240	FRONT BUMPER ATTACHMENT SUPPORT	TATA spare parts
409088000242	SP FRONT BUMPER ASSY 42 49WB	TATA spare parts
409088000243	HINGE ASSY RH	TATA spare parts
409088000244	FRP REAR BUMPER SINGLE PIECE ASSY	TATA spare parts
409088000245	REAR BUMPER ATTACHMENT SUPPORT	TATA spare parts
409088000254	REAR EXTERNAL REVETMENT LAMP MODIFIED	TATA spare parts
409088000259	HEADLAMP ATTACHING SUPPORT	TATA spare parts
409088000262	INTERNAL FRP ABOVE THE DRIVER	TATA spare parts
409088000263	ENGINE COVER HINGE ASSEMBLY	TATA spare parts
409088000264	COVER LATCH ASSEMBLY	TATA spare parts
409088000266	SEALING RUBBER	TATA spare parts
409088000268	DOOR SEALING RUBBER	TATA spare parts
409088000269	ENGINE HOOD SUPPORT CHAIN BELT ASSEMBLY	TATA spare parts
409088000273	BASE PANEL(DASH BOARD)	TATA spare parts
409088000287	GUSSET (NEW PART)	TATA spare parts
409088000316	ENGINE COVER HINGE ASSEMBLY-OPTION2	TATA spare parts
409088000353	REAR ROOF MARKER LAMP - 12V	TATA spare parts
409088000354	SIDE MARKER LAMP AND BLINKER - 12V	TATA spare parts
409088000355	LICENSE PLATE LAMP 12V	TATA spare parts
409088000356	FRONT ROOF MARKER LAMP - 12V	TATA spare parts
409088000359	ROOF ELECTRIC HARNESS 49	TATA spare parts
409088000362	SIDE MARKER LAMPS ELECTRIC HARNESS RH	TATA spare parts
409088000363	SIDE MARKER LAMPS ELECTRIC HARNESS LH	TATA spare parts
409088000366	DASHBOARD ELECTRIC HARNESS	TATA spare parts
409088000370	LOWER ELECTRIC HARNESS	TATA spare parts
409088000376	DOOR OPENED INDICATION HARNESS	TATA spare parts
409088000377	ROOF LUMINAR ASSY	TATA spare parts
409088000392	NORMAL CONTACT RELAY-12V	TATA spare parts
409088000397	PANEL PLATE-RH	TATA spare parts
409088000398	MAGNET LOCK	TATA spare parts
409088000399	CLUTCH OIL TANK CLOSING COVER ASSY.	TATA spare parts
409088000401	DASHBOARD PANEL PLATE_LH	TATA spare parts
409088000402	RADIO PROVISION COVER	TATA spare parts
409088000403	DASHBOARD INDICATOR LAMP - 12V	TATA spare parts
409088000407	STEP LAMP ASSEMBLY	TATA spare parts
409088000426	DRAIN PLUG ASSEMBLY	TATA spare parts
409088000428	DOUBLE PARABOLA LUMINARY - 12V	TATA spare parts
409088000430	LOUD-SPEAKER GRILLE	TATA spare parts
409088000432	HAT RACK CROSS BRACKET SUPPORT	TATA spare parts
409088000456	INSPECTION COVER SUPPORT PLATE	TATA spare parts

409088000458	FUEL LEVEL FLOAT MAINTENANCE COVER	TATA spare parts
409088000459	FUEL LEVEL FLOAT MAINTENANCE COVER	TATA spare parts
409088000464	FIRE RETARDENT MARINE PLY WOOD 12 MM	TATA spare parts
409088000465	HEX_NUT_M6X1_DIN985_FE/ZN12C4_BLACK	TATA spare parts
409088000469	PLAIN_WASHER_ID5XOD12XT1.5_DIN125_12C3	TATA spare parts
409088000473	FLEXIBLE RUBBER PROFILE FOR WHEEL ARCH	TATA spare parts
409088000482	EXT REARVIEW MIRROR SUPPORT ASSEMBLY	TATA spare parts
409088000487	WINDOW RH 1195X790 SLIDING_RHD_(SH)	TATA spare parts
409088000488	WINDOW LH 1095X790 SLIDING_RHD	TATA spare parts
409088000520	WINDOW GUARD RAIL TUBE DIA15.88 75MM	TATA spare parts
409088000521	WINDOW GUARD RAIL TUBE DIA19.05_1072MM	TATA spare parts
409088000523	WINDOW GUARD RAIL TUBE DIA19.05_3650MM	TATA spare parts
409088000525	WINDOW GUARD RAIL AL BRKT 20DIA_OPEN END	TATA spare parts
409088000526	WINDOW GUARDRAIL AL BRKT 20DIA_CLOSE END	TATA spare parts
409088000531	EMERGENCY EXIT STICKER	TATA spare parts
409088000532	STICKER FOR CNG BUS-1	TATA spare parts
409088000533	STICKER FOR CNG BUS-2	TATA spare parts
409088000542	PARTITION WALL GLASS 575X270X5	TATA spare parts
409088000544	GRAB RAIL RUBBER BASE EXTERNAL DIA 22.5	TATA spare parts
409088000550	BUTTON SWITCH	TATA spare parts
409088000553	PARTITION WALL STRUCTURE ASSLY	TATA spare parts
409088000556	HAND HOLD TUBE LENGTH	TATA spare parts
409088000568	DRIVER DOOR_INTERNAL PANEL	TATA spare parts
409088000569	DOOR BOLT COVER	TATA spare parts
409088000570	DRIVER DOOR HINGE SUPPORT PLATE COVER	TATA spare parts
409088000572	TOOL BOX ASSEMBLY (PLYWOOD&VINYL)	TATA spare parts
409088000577	PASSENGER DOOR	TATA spare parts
409088000581	PRESSED RUBBER	TATA spare parts
409088000582	REAR WINDOW GLASS	TATA spare parts
409088000583	FRONT WINDSHIELD RUBBER	TATA spare parts
409088000584	FRONT WINDSHIELD	TATA spare parts
409088000587	VINYL FLOOR(SCUBA BLUE VOL-004) 2M WIDTH	TATA spare parts
409088000591	TOOL BOX CAP FINISHING PPGI PROFILE 0.65	TATA spare parts
409088000592	TOOLBOX CAP FINISHING PROFILE 15X15X0.65	TATA spare parts
409088000593	TOOL BOX LOCK SUPPORT PLATE	TATA spare parts
409088000599	L-CLAMP FOR TOOL BOX GI 1.95X30X50MM	TATA spare parts
409088000601	L-PLATE FOR LOCKING (TOOL BOX ASSY)	TATA spare parts
409088000607	DRIVER DOOR SEALING PLATE_LEFT SIDE	TATA spare parts
409088000608	DRIVER DOOR SEALING PLATE_UPPR&BOTM SIDE	TATA spare parts
409088000609	DRIVER DOOR SEALING PLATE_RIGHT SIDE	TATA spare parts
409088000610	DOOR LATCH ATTACHMENT SUPPORT PLATE	TATA spare parts
409088000611	DRIVER DOOR STR AND LOCK KIT ASSY_R.H.D	TATA spare parts
409088000626	FLAP ASSY FOR CNG BUS	TATA spare parts
409088000627	SHUTTER UPHOLDING STALK ASSEMBLY-RH	TATA spare parts
409088000628	HINGE SUPPORT KIT	TATA spare parts
409088000629	HINGE SUPPORT KIT	TATA spare parts
409088000631	L PLATE FOR FLAP	TATA spare parts

409088000637	SHUTTER UPHOLDING STALK ASSEMBLY	TATA spare parts
409088000641	LLDPE FLAP 250X350X3 THICK FRONT	TATA spare parts
409088000644	LLDPE FLAP 250X400X3 THICK REAR	TATA spare parts
409088000651	ELECTRICAL BOX CLOSING COVER-RHD	TATA spare parts
409088000652	FUSE BOX LOCK WITH KEY	TATA spare parts
409088000653	ELECTRICAL BOX CLOSING COVER ASSY-RHD	TATA spare parts
409088000654	FUSE BOX MOUNTING L PLATE	TATA spare parts
409088000655	L PLATE FOR FIXING ELECTRIC COMPONENTS	TATA spare parts
409088000657	ABS A PILLAR LH	TATA spare parts
409088000658	ABS A PILLAR RH	TATA spare parts
409088000663	HAT RACK ASSY_ DRIVERSIDE & CODRIVERSIDE	TATA spare parts
409088000679	WINDOW GUARD RAIL TUBE DIA19.05_3940MM	TATA spare parts
409088000681	EMERGENCY DOOR INTERNAL PANEL	TATA spare parts
409088000697	EMERGENCY DOOR LOCK COVER-ABS ASSY	TATA spare parts
409088000711	EMERGENCY DOOR KNOB COVER-OPTION 2	TATA spare parts
409088000714	RH TWIN SEATER (VSPL_HB_850WIDTH)	TATA spare parts
409088000716	LH TWIN SEATER (VSPL_HB_850WIDTH)	TATA spare parts
409088000718	CO-DRIVER LH SEAT_ARM REST (620)	TATA spare parts
409088000721	DRIVER PARTITION ASSY_COST REDUCTION	TATA spare parts
409088000724	PASSENGER PARTITION ASSY_CR_STOP SWITCH	TATA spare parts
409088000727	HAND HOLD TUBE ASSY (GANGWAY ROOF)	TATA spare parts
409088000741	EMERGENCY DOOR STICKER	TATA spare parts
409088000743	DECAL STICKER	TATA spare parts
409088000757	FRONT FLAP WITH STRUCTURE	TATA spare parts
409088000758	FRONT FLAP LIMIT ROD ASSY	TATA spare parts
409088000759	HINGE MOUNTING L-PROFILE LH	TATA spare parts
409088000760	HINGE MOUNTING L-PROFILE RH	TATA spare parts
409088000770	VINYL FLOOR_BUTTON TYPE -1.5THK_SLB LCV	TATA spare parts
409088000778	FRP FRONT BUMPER SINGLE PIECE ASSY	TATA spare parts
409088000780	FUEL TANK NOZZLE ASSEMBLY	TATA spare parts
409088000781	STRETCH PANEL R.H SIDE-EMER DOOR	TATA spare parts
409088000782	SKIRT PANEL RH MIDDLE	TATA spare parts
409088000783	SKIRT PANEL RH REAR	TATA spare parts
409088000785	STRETCH PANEL _ L.H SIDE BEHIND_PASGER	TATA spare parts
409088000786	SKIRT PANEL RH REAR	TATA spare parts
409088000788	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
409088000789	SKIRT PANEL RH-2	TATA spare parts
409088000790	SKIRT PANEL LH FRONT	TATA spare parts
409088000791	SKIRT PANEL RH MIDDLE	TATA spare parts
409088000793	SKIRT PANEL LH FRONT-6	TATA spare parts
409088000794	SKIRT PANEL RH-2	TATA spare parts
409088000795	SKIRT PANEL LH FRONT	TATA spare parts
409088000796	SKIRT PANEL L SECTION	TATA spare parts
409088000797	C SECTION	TATA spare parts
409088000798	STRETCH PANEL R.H SIDE REAR	TATA spare parts
409088000802	EMERGENCY DOOR SEALING SUPPORT ASSY	TATA spare parts
409088000803	EMERGENCY DOOR SEALING SUPPORT	TATA spare parts

409088000804	EMERGENCY DOOR SEALING SUPPORT	TATA spare parts
409088000805	EMERGENCY DOOR SEALING SUPPORT	TATA spare parts
409088000806	EMERGENCY DOOR SEALING SUPPORT	TATA spare parts
409088000807	EMERGENCY DOOR EXTERNAL PANELING	TATA spare parts
409088000809	FLAP ASSY FOR CNG BUS	TATA spare parts
409088000812	CNG & BATTERY FLAP ASSY	TATA spare parts
409088000829	EMERGENCY DOOR LOWER ELECTRIC HARNESS	TATA spare parts
409088000838	WINDOW RH 995X790MM SLIDING_CLEAR_GL_RH	TATA spare parts
409088000848	FLAT_HEAD_SCREW_M8X1.25X25X25_DIN7991	TATA spare parts
409088001128	DOOR SIDE FINISHING PROFILE	TATA spare parts
409088001213	LOCKING BRACKET FOR DOOR	TATA spare parts
409088001221	UPPER HINGE ASSEMBLY FOR DRIVER DOOR	TATA spare parts
409088001230	LOWER HINGE ASSEMBLY FOR DRIVER DOOR	TATA spare parts
409088001236	BUMPER FIBER REINFORCEMENT	TATA spare parts
409088001268	FRP FRONT FACE WITH HEADLAMP BRACKET	TATA spare parts
409088001270	CNG FRP FRONT FLAP WITH HINGE ASSY	TATA spare parts
409088001271	CNG FLAP WITH STRUCTURE FITMENT	TATA spare parts
409088001304	RH TWIN SEATER_A REST(VSPL_HB_850WIDTH)	TATA spare parts
409088001306	RH REAR 2 SEATER_2 LEGS SYMETRIC	TATA spare parts
409088001307	LH REAR 2 SEATER_2 LEGS SYMETRIC	TATA spare parts
409088001308	REAR MIDDLE SINGLE SEATER(VSPL_HB_620)	TATA spare parts
409088001362	FLAP LATCH COUPLING	TATA spare parts
409088001379	BATTERY SHUTTER BACKSTOP ATTACH. PLATE	TATA spare parts
409088001431	EME DOOR WINDOW RH 590X712_SLIDING_SERV	TATA spare parts
409088001433	WINDOW LH_1095X790MM_SERVICABLE	TATA spare parts
409088001435	WINDOW LH_1195X790MM_SERVICABLE	TATA spare parts
409088001439	FIX WINDOW LH_264X790MM_SERVICABLE	TATA spare parts
409088001443	WINDOW LH (CO-DRI)_1087X790MM_SERVICABL	TATA spare parts
409088001448	PEEP WINDOW LH_310X470MM_SERVICABLE	TATA spare parts
409088001455	SCHOOL BUS INSIGNIA	TATA spare parts
409088001456	SKOOL STICKER	TATA spare parts
409088001473	HANDLE STRAP ASSY LOCAL SUPPLY_YELLOW SKO	TATA spare parts
409088001513	FRONT UPPER COVERING	TATA spare parts
409088001522	FRP CNG VENT PIPE COVER RH	TATA spare parts
409088001523	FRP CNG VENT PIPE COVER LH	TATA spare parts
409088001526	CNG FRP REAR INTERNAL	TATA spare parts
409088001532	EXTERNAL PANEL AT EXTREME END OF R.H SID	TATA spare parts
409088001533	SKIRT PANEL RH FRONT_CUTOUT ADDED	TATA spare parts
409088001534	SIDE EXTERNAL PANELLING FINISH ALU PROFI	TATA spare parts
409088001535	EXT REVETMENT PLATES BETWEEN WINDOWS	TATA spare parts
409088001537	A PILLAR EXTERNAL PANEL(LH-PAS-DOR-SIDE)	TATA spare parts
409088001538	A PILLAR EXTERNAL PANEL(RH-DRIVER-SIDE)	TATA spare parts
409088001542	FRP FRONT BUMPER SINGLE PIECE ASSY	TATA spare parts
409088001543	FRP REAR BUMPER SINGLE PIECE ASSY-SFC	TATA spare parts
409088001614	WINDOW RH_345X790MM_SERVICABLE	TATA spare parts
409088001627	RH REAR TWIN SEATER	TATA spare parts
409088001630	LH REAR TWIN SEATER	TATA spare parts

409088001734	SKIRT PANEL FRONT RH SIDE	TATA spare parts
409088001735	STRETCH PANEL FRONT L.H SIDE	TATA spare parts
409088001740	SKIRT PANEL AT BATRY BOX 400APP COST RED	TATA spare parts
409088001745	STRETCH PANEL DOOR L.H SIDE	TATA spare parts
409088001767	POLYAMIDE BUSH_ OD 10_ ID8_ LN20	TATA spare parts
409088001772	SLF STRUCTURE ASSY_LCOST BUS	TATA spare parts
409088001776	GUSSET SIDE	TATA spare parts
409088001810	SKIRT PANEL AT SLB FOR SLB BUS	TATA spare parts
409088001838	LOCK HOLDER	TATA spare parts
409088001839	ENGINE HOOD ASSEMBLY DETAILS	TATA spare parts
409088001889	FRP REAR BUMPER SINGLE PIECE ASSY	TATA spare parts
409088001891	SKIRT PANEL LH FRONT	TATA spare parts
409088001894	SCHOOL BUS INSIGNIA	TATA spare parts
409088001898	EXT PANELLING SHEET	TATA spare parts
409088001916	STAR BUS DECAL	TATA spare parts
409088002162	CNG FLAP ASSY	TATA spare parts
409088002164	DOOR ATTACHEMENT PLATE SUPPORT	TATA spare parts
409088002165	CNG FLAP ASSY	TATA spare parts
409088002166	CNG FLAP ASSY	TATA spare parts
409088002169	ENGINEHOOD ASSEMBLY 913 CNG	TATA spare parts
409088002177	BATTERY FLAP ASSY	TATA spare parts
409088002178	BATTERY BOX BOTTOM SUPPORT	TATA spare parts
409088002190	RADIATOR COOLENT OIL MAINT.FLAP ASSY.	TATA spare parts
409088002191	SKIRT PANEL MIDDLE R.H SIDE	TATA spare parts
409088002193	SKIRT PANEL MIDDLE R.H SIDE	TATA spare parts
409088002194	SKIRT PANEL R.H SIDE	TATA spare parts
409088002195	SKIRT PANEL R.H SIDE	TATA spare parts
409088002196	SKIRT PANEL MIDDLE L.H SIDE	TATA spare parts
409088002197	SKIRT PANEL MIDDLE L.H SIDE	TATA spare parts
409088002198	SKIRT PANEL MIDDLE L.H SIDE	TATA spare parts
409088002201	EXTERNAL PANEL AHEAD OF PASSENGER DOOR	TATA spare parts
409088002202	ECU BOX FLAP ASSEMBLY	TATA spare parts
409088002208	FRP DASHBOARD 913 CNG	TATA spare parts
409088002294	PNEUMATIC DOOR ATTACHMENT PLATE ASSEMB	TATA spare parts
409088002295	PNEUMATIC CYLINDER HOLDER ASSY	TATA spare parts
409088002297	CYLINDER	TATA spare parts
409088002307	TATA STARBUS FRONT DECAL	TATA spare parts
409088002385	DRIVER FAN ELECTRIC HARNESS	TATA spare parts
409088002398	REAR LICENSE PLATE_YELLOW	TATA spare parts
409088002407	EMERGENCY DOOR LOCK COVER	TATA spare parts
409088002424	LH CO DRI SEAT 2 LEGS 400SW ARç PLAS	TATA spare parts
409088002425	RH 2 SEATER 810MM SW ARç PLASTIC	TATA spare parts
409088002426	RH 2SEAT 460CH 850W/O AR 2LM PLSTC	TATA spare parts
409088002427	RH 2SEAT 460CH SM1L 850W/O AR PLSC	TATA spare parts
409088002428	LH 2SEAT 460CH SM1L 850W/O AR PLSC	TATA spare parts
409088002429	REAR MID 1SEAT 460CH 400 W 2LM PLTC	TATA spare parts
409088002431	LH 1SEAT 455W RH SBMç PLASTIC	TATA spare parts



409088002432	LH 1SEAT 455W RH SBM WHç PLASTIC	TATA spare parts
409088002453	PNEUMATIC CULINDER COVER BOX	TATA spare parts
409088002606	BASE RUNNER 864 LN SEAT REINFORCEMENT	TATA spare parts
409088002660	SIDE STRUCTURE LH 49WB-SD	TATA spare parts
409088002692	FINISHING COVER BELOW STEERING COLUMN	TATA spare parts
409088002695	JK DOOR UPPER LATCH	TATA spare parts
409088002792	SCHOOL BUS INSIGNIA ADHESIVE FROM BOTTOM	TATA spare parts
409088002837	FRP FRONT BUMPER SINGLE PIECE ASSY.	TATA spare parts
409088002905	CNG ACCESS PLATFORM ASSY	TATA spare parts
409088002918	DRIVER DOOR LOCK FINISHING COVER	TATA spare parts
409088002919	DOOR BOLT FINISHING COVER	TATA spare parts
409088002926	EMERGENCY DOOR LOCK COVER	TATA spare parts
409088002928	PNEUMATIC KIT 1210	TATA spare parts
409088002929	PNEUMATIC PASSENGER DOOR ASSY 1210 MM	TATA spare parts
409088002930	FRP FRONT FLAP WIT STR HING ASSY	TATA spare parts
409088002931	FLAP GUIDE LOCK ASSY RH	TATA spare parts
409088002939	FRP FR BUMPER HR WI FOGLAMP ASSY	TATA spare parts
409088002940	REAR BUMPER FITMENT DETAILS	TATA spare parts
409088002942	GI PLATE 0.65MMX78X1136	TATA spare parts
409088002955	MAINTENANCE LAMP LIGHT	TATA spare parts
409088002958	WALL GLASS BEHIND OF DRIVER	TATA spare parts
409088002959	FRP LARGE WS REAR FACE WITH RW	TATA spare parts
409088002960	AIR FILTER FLAP ASSY	TATA spare parts
409088002970	LOCK ASSY	TATA spare parts
409088002973	FLAP LOCK ASSY PLATE	TATA spare parts
409088002974	FLAP LOCK PLATE	TATA spare parts
409088002976	LOCK COVER	TATA spare parts
409088002979	BATTERY FLAP ASSEMBLY	TATA spare parts
409088002982	STEERING GEAR BOX MAINTENANCE FLAP ASSY	TATA spare parts
409088002984	FRP REAR INTERNAL(CNG) FINISHING	TATA spare parts
409088002985	LOUD SPEAKER GRILL	TATA spare parts
409088002994	RVM PANEL PLATE PASSENGER SIDE	TATA spare parts
409088002996	LH 2SEAT 460CH 810W 2LM PLSTC	TATA spare parts
409088002999	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
409088003001	EXTERNAL PANELLING PLATE 2	TATA spare parts
409088003002	FRP 1210 PNEUMATIC DOOR ASSY	TATA spare parts
409088003003	FRP CNG CASCADE COVER ASSY	TATA spare parts
409088003004	FRP CNG HP COVER 1	TATA spare parts
409088003005	FRP CNG HP COVER 2	TATA spare parts
409088003006	WINDOW GUARD RAIL 19.05 DIA 2676MM	TATA spare parts
409088003007	WINDOW GUARD RAIL 19.05 DIA 2455MM	TATA spare parts
409088003038	EXTERNAL PANEL OVER PASSENGER DOOR	TATA spare parts
409088003039	RVM PANEL PLATE	TATA spare parts
409088003059	FRONT REAR LIC PLATE 520 X 120	TATA spare parts
409088003064	WINDOW LH 1397X880MM	TATA spare parts
409088003065	WINDOW EME.DOOR 587X690MM	TATA spare parts
409088003069	WINDOW DRV.DOOR 786X800MM	TATA spare parts

409088003071	FRONT WINDSHIELD	TATA spare parts
409088003072	FRONT RUBBER OUTLINE SINGLE GLASS	TATA spare parts
409088003073	REAR RUBBER OUTLINE SINGLE GLASS	TATA spare parts
409088003074	REAR WINDSHIELD	TATA spare parts
409088003075	SKIRT PANEL LH SIDE-2	TATA spare parts
409088003079	STRETCH PANEL LH	TATA spare parts
409088003081	SKIRT PANEL LH SIDE-4	TATA spare parts
409088003082	SKIRT PANEL LH SIDE-5	TATA spare parts
409088003083	SKIRT PANEL LH SIDE-6	TATA spare parts
409088003084	SKIRT PANEL LH SIDE 7	TATA spare parts
409088003085	SKIRT PANEL LH SIDE 8	TATA spare parts
409088003088	GI PLATE 48 X 1136 X 0.65MM THK	TATA spare parts
409088003116	WINDOW RH 993X1070MM	TATA spare parts
409088003120	WINDOW LH 868X1070MM	TATA spare parts
409088003122	WINDOW RH 1238X1070MM	TATA spare parts
409088003313	FRP FRT FACE WIT RW ASSY	TATA spare parts
409088003523	AIR FILTER FLAP ASSY	TATA spare parts
409088003532	SKIRT PANEL MIDDLE L.H SIDE 1000 DOOR	TATA spare parts
409088003533	SKIRT FRONT PANEL L.H SIDE AT AIR FILTER	TATA spare parts
409088003564	WINDOW GUARD RAIL TUBE DIA19.05 1120MM	TATA spare parts
409088003582	SKIRT PANEL LH SIDE	TATA spare parts
409088003583	SKIRT PANEL MIDDLE R.H SIDE	TATA spare parts
409088003730	PEEP WINDOW 208X1070MM	TATA spare parts
409088003732	PASTED WINDOW GLASS 4X462X143 IN CUTOUT	TATA spare parts
409088003733	PASTED WINDOW GLASS 4X254X199 IN CUTOUT	TATA spare parts
409088003734	PEEP WINDOW 290X350MM	TATA spare parts
409088003735	WINDOW LH 1008X1070MM	TATA spare parts
409088003736	WINDOW LH 1023X1070MM	TATA spare parts
409088003737	WINDOW LH 1253X1070MM	TATA spare parts
409088003738	WINDOW RH 1023X1070MM	TATA spare parts
409088003739	WINDOW RH 1268X1070MM	TATA spare parts
409088003740	WINDOW RH 1141X1070MM	TATA spare parts
409088003759	SKIRT PANEL LH SIDE 5	TATA spare parts
409088003761	SKIRT PANEL LH SIDE 4	TATA spare parts
409088003762	SKIRT PANEL LH SIDE 3	TATA spare parts
409088003770	SKIRT PANEL RH SIDE 6	TATA spare parts
409088003771	SKIRT PANEL RH SIDE 4	TATA spare parts
409088003772	SKIRT PANEL RH SIDE 3	TATA spare parts
409088003773	SKIRT PANEL LH SIDE 1	TATA spare parts
409088003774	SKIRT PANEL LH SIDE 2	TATA spare parts
409088003775	SKIRT PANEL RH SIDE 2	TATA spare parts
409088003776	SKIRT PANEL RH SIDE 1	TATA spare parts
409088003777	A PILLER PANEL PLATE	TATA spare parts
409088003779	SKIRT PANEL LH SIDE 6	TATA spare parts
409088003782	SKIRT PANEL LH SIDE 9	TATA spare parts
409088003784	SKIRT PANEL LH SIDE 10	TATA spare parts
409088003785	SKIRT PANEL RH SIDE	TATA spare parts

409088003786	SKIRT PANEL RH SIDE 6	TATA spare parts
409088003788	GI PLATE 0.65MM THK LN 1136	TATA spare parts
409088003811	GI PLATE 0.65MM THK LN 780	TATA spare parts
409088003844	ABS A PILLAR LH	TATA spare parts
409088003845	ABS A PILLAR RH	TATA spare parts
409088003849	FRP CLUSTER	TATA spare parts
409088003850	ABS CLUSTER FINISH COVER	TATA spare parts
409088003852	FRP DASHBOARD ASSY	TATA spare parts
409088003861	FRP ENGINE HOOD ASSEMBLY	TATA spare parts
409088003872	SKIRT EXTERNAL PANELING BOTTOM COVER	TATA spare parts
409088003986	BATTERY FLAP ASSY	TATA spare parts
409088004129	DRIVER DOOR WINDOW 780X921MM	TATA spare parts
409088004269	HANDHOLD TUBE 1632	TATA spare parts
409088004295	CONTROL PANEL HOLDING BRACKET	TATA spare parts
409088004296	HOSE PIPE FINISHING PROFILE	TATA spare parts
409088004644	WINDOW GUARD RAIL_W/SLEEV_4900	TATA spare parts
409088004650	WINDOW GUARD RAIL CLAMP -OPEN END	TATA spare parts
409088004651	WINDOW GUARD RAIL TUBE DIA12.8_75MM	TATA spare parts
409088004652	WINDOW GUARD RAIL CLAMP-CLOSED END	TATA spare parts
409088004696	WINDOW GUARD RAIL W/SLEEV_3635	TATA spare parts
409088004758	DASHBOARD ASSEMBLY-4T	TATA spare parts
409088004828	A PILLAR EXTERNAL PANEL_662X264X0.65THK	TATA spare parts
409088004829	A PILLAR EXTERNAL PANEL(821X335X0.65THK)	TATA spare parts
409088004872	INTERNAL ABS COVER ABOVE DRIVER	TATA spare parts
409088005014	FRP REAR BUMPER ASSY	TATA spare parts
409088005123	WINDOW GUARD RAIL 3650LN	TATA spare parts
409088005124	WINDOW GUARD RAIL_1270LN	TATA spare parts
409088005126	WINDOW GUARD RAIL 1120LN	TATA spare parts
409088005158	REAR PNEUMATIC PASSENGER DOOR ASSY 830M	TATA spare parts
409088005277	HINGE COVER	TATA spare parts
409088005279	STARBUS ULTRA STICKER	TATA spare parts
409088005282	WINDOW RH 993X1070MM	TATA spare parts
409088005286	PEEP WINDOW-193X1070MM	TATA spare parts
409088005289	WINDOW RH 1238X1070MM	TATA spare parts
409088005296	WINDOW RH 1208X1070MM	TATA spare parts
409088005311	SERVICEABLE TYPE SECTION	TATA spare parts
409088005316	FRP REAR INNER ASSY	TATA spare parts
409088005319	FRP PNEUMATIC DOOR ASSY	TATA spare parts
409088005321	PNEUMATIC DOOR ASSY	TATA spare parts
409088005325	GEAR SHIFT LIVER COVER ASSY	TATA spare parts
409088005336	CLUSTER ASSY	TATA spare parts
409088005341	ENGINE HOOD ASSY	TATA spare parts
409088005352	DASHBOARD ASSY	TATA spare parts
409088005353	WINDOW GUARD RAIL	TATA spare parts
409088005361	FRP FRONT INNER ASSY	TATA spare parts
409088005375	WINDOW LH 868X1070MM	TATA spare parts
409088005386	WINDOW LH 1238X1070MM	TATA spare parts

409088005387	WINDOW LH 993X1070MM	TATA spare parts
409088005388	WINDOW LH 693X1070MM	TATA spare parts
409088005396	PEEP WINDOW-383X1070MM	TATA spare parts
409088005433	SKIRT PANEL RH SIDE 275X74X0.95THK	TATA spare parts
409088005435	SKIRT PANEL LH SIDE 606X37X0.95THK	TATA spare parts
409088005437	SKIRT PANEL LH SIDE- 464X96X0.95 THK	TATA spare parts
409088005438	SKIRT PANEL LH SIDE 1206X56X0.95 THK	TATA spare parts
409088005442	SKIRT PANEL LH SIDE 830X378X0.95 THK	TATA spare parts
409088005443	SKIRT PANEL LH SIDE 828X46X0.95 THK	TATA spare parts
409088005444	SKIRT PANEL LH SIDE 369X523X0.95	TATA spare parts
409088005445	SKIRT PANEL RH SIDE 600X66X0.95 THK	TATA spare parts
409088005446	SKIRT PANEL RH SIDE 229X96X0.95 THK	TATA spare parts
409088005449	SKIRT PANEL RH SIDE 2090X378X.95 THK	TATA spare parts
409088005450	SKIRT PANEL RH SIDE 708X545X.65THK	TATA spare parts
409088005451	SKIRT PANEL RH SIDE-2190X378X.95THK	TATA spare parts
409088005452	SKIRT PANEL RH 1935X378X.95 THK	TATA spare parts
409088005454	SKIRT PANEL RH SIDE 789X692X0.95 THK	TATA spare parts
409088005455	GI PLATE 880X370X0.65MM THK	TATA spare parts
409088005456	GI PLATE 1370X190X0.65MM THK	TATA spare parts
409088005457	GI PLATE 990X190X0.65MM THK	TATA spare parts
409088005458	RVM PANEL PLATE 827X172X0.95THK	TATA spare parts
409088005459	DOOR CANOPY FOR DOOR 1338X86X1.25THK	TATA spare parts
409088005460	DOOR CANOPY FOR DOOR 848X86X1.25THK	TATA spare parts
409088005462	SKIRT PANEL LH SIDE 638X586X0.95 THK	TATA spare parts
409088005506	RH 2 SEAT 2LG PMS 460CH BLUE FAB	TATA spare parts
409088005507	2 SEATER WH 810W 2LGM	TATA spare parts
409088005508	FRONT FOLDABLE 1 SEAT 2L 400SW	TATA spare parts
409088005509	REAR MID SEAT 2L LB PLASTIC BLUE FAB	TATA spare parts
409088005510	RH 2 SEAT 2LG PMS 460CH AR BLUE FAB	TATA spare parts
409088005511	2 SEATER WH 810W 2LGM 2LB	TATA spare parts
409088005593	PRIORITY SEAT STICKER RH	TATA spare parts
409088005637	RVM PANEL PLATE 216X1126X0.95THK	TATA spare parts
409088005781	FRONT PNEUMATIC KIT FOR 1210MM PASS DOOR	TATA spare parts
409088005782	REAR PNEUMATIC KIT FOR 830MM PASS DOOR	TATA spare parts
409088005783	WIRE HARNESS WITH SWITCH	TATA spare parts
409088005856	SAFETY BELT REINFORCEMENT PL	TATA spare parts
409088005857	BRACKET TOP COVER PANEL3	TATA spare parts
409088005858	SAFETY BELT L-PLATE ASSY	TATA spare parts
409088005860	DRIVER PLATFORM FRONT PLATE R.H	TATA spare parts
409088005861	GI SHEET	TATA spare parts
409088005868	SKIRT PANEL LH SIDE-6	TATA spare parts
409088005914	RH 3 SEAT_850MM_SM2L_AR	TATA spare parts
409088005916	RH 3 SEAT_850MM_SM2L_BH_AR_CVG_LCV	TATA spare parts
409088005920	RH 3 SEAT_850MM_AR_SM2L_BH	TATA spare parts
409088005943	EMERGENCY WINDOW HAMMER ASSY KIT	TATA spare parts
409088005945	FIRE EXT._6KG	TATA spare parts
409088005947	DRAIN PLUG	TATA spare parts

409088005973	ABS DRIVER FOOT STEP	TATA spare parts
409088005974	DRIVER FOOT STEP SUPPORT BRACKET	TATA spare parts
409088005984	EMERGENCY EXIT STICKER	TATA spare parts
409088005993	INSPECTION COVER SUPPORT PLATE	TATA spare parts
409088006029	DOOR CANOPY FOR DRIVER DOOR	TATA spare parts
409088006046	SIDE STRUCTURE ASSEMBLY - RH EMER DOOR	TATA spare parts
409088006124	WINDOW GUARD RAIL W/SLEEV_2930	TATA spare parts
409088006445	REAR MID SINGLE SEATER_LAP BELT	TATA spare parts
409088006533	BOTTOM SEALING BOXING PLATE	TATA spare parts
409088006566	RH 2SEAT_760MM_SM1L_BH_AR_SKL_CVG	TATA spare parts
409088006632	EMERGENCY DOOR SEALING SUPPORT	TATA spare parts
409088006633	EMERGENCY DOOR SEALING SUPPORT	TATA spare parts
409088006634	PLY WOOD SUPPORT	TATA spare parts
409088006682	PASSENGER DOUBLE DOOR CANOPY	TATA spare parts
409088006727	PASTED GLASS RH TOP_1157X980	TATA spare parts
409088006729	PASTED GLASS RH TOP_1157X1355	TATA spare parts
409088006730	PASTED GLASS RH TOP_1157X1070	TATA spare parts
409088007640	PASSENGER FOOT STEP ASSEMBLY	TATA spare parts
409088007672	FIXED WINDOW 1095X790MM	TATA spare parts
409088007680	RH 2ST SM1L 450CH850W BEFORE WA HB1	TATA spare parts
409088007681	LH 2ST SM1L 450CH850W BEFORE WA HB1	TATA spare parts
409088007730	SLIDING STEPS ASSEMBLY	TATA spare parts
409088007950	REAR MID SINGLE SEATER_LAP BELT	TATA spare parts
409088007953	LH 2ST SM1L 450CH850W BEFORE WA HB1	TATA spare parts
409088007954	RH 2ST SM1L 450CH850W BEFORE WA HB1	TATA spare parts
409088007979	SIDE STRUCTURE ASSY-RH EMERGENCY DOOR	TATA spare parts
409088007996	CO EXTRUDED WIPER CHANNEL	TATA spare parts
409088008082	DASHBOARD & ENGINEHOOD ASSY	TATA spare parts
409088008148	CLUSTER FRP	TATA spare parts
409088008152	NON MULTI CLUSTER COVER FRP	TATA spare parts
409088008256	LOCK CATCHER	TATA spare parts
409088008515	REAR WINDSHIELD_GREY TINTED_50PERC	TATA spare parts
409088009026	REAR SUPPORTING PLATE	TATA spare parts
409088009079	FRP FRONT BUMPER SINGLE PIECE ASSY	TATA spare parts
409088010194	3RL 2LM 450C950W LB SKL TM	TATA spare parts
409088010195	2LH SM1L 450C760W AR WA SKL TM	TATA spare parts
409088010196	2RH SM1L 450C760W AR WA SKL TM	TATA spare parts
409088010197	4RR 3LM 450C1060W 4LB SKL TM	TATA spare parts
409088010198	2LH SM1L 450C760W AR SKL TM	TATA spare parts
409088010199	2RH SM1L 450C760W AR SKL TM	TATA spare parts
409088010201	ROOF ELECTRIC HARNESS_34WB	TATA spare parts
409088040101	BATTERY BOX LOCK HAT-SECTION	TATA spare parts
409089010032	INSPECTION COVERS PLYWOOD SUPPORTING PLA	TATA spare parts
409089010093	RUBBER PROFILE FOR INSPECTION COVER	TATA spare parts
409089010146	WINDOW LH 861X1056_1/3FIX&2/3BOT SLIDING	TATA spare parts
409089010147	WINDOW LH 1476X1056_1/3 FIX 2/3 BOT SLID	TATA spare parts
409089010148	WINDOW LH 1146X1056_1/3FIX&2/3BOT SLIDIN	TATA spare parts

409089010149	WINDOW LH 716X1056_1/3FIX&2/3BOT SLIDING	TATA spare parts
409089010194	WINDOW RH 1476X1056_1/3 FIX 2/3 BOT SLID	TATA spare parts
409089010196	WINDOW RH 861X1056_1/3FIX&2/3BOT SLIDING	TATA spare parts
409089010197	DRIVER WINDOW_RH_730X813_SLIDING_OPENA	TATA spare parts
409089010198	DRI. DOOR SL WINDOW_313X402_LCV PROFILE	TATA spare parts
409089010210	REAR INTERNAL REVETMENT	TATA spare parts
409089010225	FUSE BOX POWER FEED CABLE	TATA spare parts
409089010231	SIDE MARKER LAMPS MULTIPLEX HARNESS_MUX	TATA spare parts
409089010236	EXTERNAL LAMPS HARNESS_MUX	TATA spare parts
409089010237	SWITCH FOR MAINTENANCE LIGHT	TATA spare parts
409089010249	WINDSHIELD WIPER ASSEMBLY	TATA spare parts
409089010257	DRIVER PARTITION WALL GLASS	TATA spare parts
409089010265	REFLECTOR RETRO	TATA spare parts
409089010269	GRAB RAIL END FINSHING COVER	TATA spare parts
409089010271	GANGWAY GRAB RAIL SUPPORT	TATA spare parts
409089010276	SIDE MARKER LAMP	TATA spare parts
409089010277	LICENSE PLATE LAMP 24V	TATA spare parts
409089010279	SPEAKERS 4INC WITH GRILLE	TATA spare parts
409089010283	SUPPORT FOR LAMP	TATA spare parts
409089010338	DASHBOARD MULTIPLEX HARNESS - MCV	TATA spare parts
409089010339	UPPER FRONT MULTIPLEX HARNESS (MCV)	TATA spare parts
409089010340	INTERNAL LIGHTING HARNESS - RH	TATA spare parts
409089010341	INTERNAL LIGHTING HARNESS - LH	TATA spare parts
409089010359	PAN HEAD SCREWS	TATA spare parts
409089010387	SIDE EXT PANELING ABOVE WINDOW - 07	TATA spare parts
409089010388	REAR PASSENGER DOOR LEFT SIDE-PANELING	TATA spare parts
409089010389	EXTRNAL PANELING ABOVE THE MIDDLE PASSEN	TATA spare parts
409089010390	REAR PASSENGER DOOR RIGHT SIDE-PANELING	TATA spare parts
409089010393	LH REAR SKIRT PANELING	TATA spare parts
409089010396	REAR PASSENGER DOOR LEFT SIDE-SKIRT PANE	TATA spare parts
409089010398	SKIRT EXTERNAL PANELING-BOTTOM COVER	TATA spare parts
409089010399	SKIRT EXTERNAL PANELING-BOTTOM COVER	TATA spare parts
409089010401	WINDSHIELD WIPER ASSY	TATA spare parts
409089010403	TEE CONNECTIONS	TATA spare parts
409089010404	WIPER JET HOSE ASSEMBLY	TATA spare parts
409089010407	W/S WASHER BOTTLE TANK	TATA spare parts
409089010408	OVAL HEAD SCREW	TATA spare parts
409089010412	SKIRT EXTERNAL PANELING FRONT PASSENGER	TATA spare parts
409089010420	UPPER SIDE EXTERNAL PANELING TYPE - 02	TATA spare parts
409089010427	SKIRT EXTERNAL PANELING-LH SIDE BEHIND F	TATA spare parts
409089010430	AL PROFILE FOR STRETCH & SKIRT PNL PRFL2	TATA spare parts
409089010431	DRIVER FOOT STEP	TATA spare parts
409089010435	SKIRT EXTERNAL PANELING- BOTTOM COVER	TATA spare parts
409089010443	HINGER DOOR JAMP SUPPORT PLATE ASSEMBLY	TATA spare parts
409089010449	DRIVER DOOR LOCK ASSY_RHD870	TATA spare parts
409089010456	DOOR 1210X1983 WITH SENSITIVITY	TATA spare parts
409089010460	FLAP STRUCTURE ASSY	TATA spare parts

409089010461	SHUTTER UPHOLDING STALK ASSEMBLY	TATA spare parts
409089010462	CNG FLAP ASSY MCVç LH SIDE	TATA spare parts
409089010464	STAY ROD ASSY _RH	TATA spare parts
409089010465	FLAP LOCK PLATE NEW	TATA spare parts
409089010466	UPHOLDINGç ROD COUPLING PLATE	TATA spare parts
409089010467	FLAP LOCK L PLATE	TATA spare parts
409089010468	L PLATE FOR FLAP 2	TATA spare parts
409089010493	ABS DRIVER DOOR LOCK COVER_3THIK	TATA spare parts
409089010494	REAR FLAP LOCK COVER AND HANDLE	TATA spare parts
409089010496	1.6X20MM STAINLESS STEEL COTTER PIN	TATA spare parts
409089010499	SPONGY RUBBER PROFILE DRIVER DOOR	TATA spare parts
409089010511	STEP LAMP WHITE COLOUR (24V)	TATA spare parts
409089010540	SUNSHADE ASSLY	TATA spare parts
409089010541	INTERNAL REAR-VIEW MIRROR	TATA spare parts
409089010549	FLEXIBLE RUBBER PROFILE FOR WHEEL ARCH	TATA spare parts
409089010551	RAIN GUTTER FINISHING RU. PRFL. BLACK	TATA spare parts
409089010557	OVAL HEAD SCRW M 8X1.25X25	TATA spare parts
409089010558	AL PROFILE 3MTR	TATA spare parts
409089010559	PAN-HEAD _M4X25 _DIN7981 _12C1(WHITE)	TATA spare parts
409089010581	SAFETY BELT ATTACHING SUPPORT	TATA spare parts
409089010585	REAR ROOF MARKER LAMP - 24V	TATA spare parts
409089010586	FRONT ROOF MARKER LAMP - 24V	TATA spare parts
409089010619	STOP REQUEST HARNESS	TATA spare parts
409089010621	PLAIN WASHER ID 6.4X OD 17XT3 DIN 7349	TATA spare parts
409089010632	HANOVER ANTENNA BRACKET	TATA spare parts
409089010633	HEX_HEAD_SILO_SCREW_M8X1.25X25X25_12C2	TATA spare parts
409089010636	HANDHOLD ATTACHMENT REINFORCEMENT	TATA spare parts
409089010637	REAR FIBER ATTACHMENT REINFORCEMENT	TATA spare parts
409089010638	REAR FIBER ATTACHMENT REINFORCEMENT	TATA spare parts
409089010639	REAR FIBER ATTACHMENT REINFORCEMENT	TATA spare parts
409089010641	REAR FIBER ATTACHMENT REINFORCEMENT	TATA spare parts
409089010643	REAR FIBER ATTACHMENT REINFORCEMENT	TATA spare parts
409089010687	REAR WINDOW GLASS	TATA spare parts
409089010688	REAR WINDOW RUBBER	TATA spare parts
409089010689	FRONT ITINERARY GLASS	TATA spare parts
409089010690	ITINERARY RUBBER-OUTLINED GLASS	TATA spare parts
409089010691	RUBBER OUTLINED WINDSHIELD	TATA spare parts
409089010692	FRONT WINDSHIELD BS1/2/3/4	TATA spare parts
409089010705	REAR LICENCE PLATE	TATA spare parts
409089010725	FRONT EXTERNAL REVETMENT	TATA spare parts
409089010745	REAR EXTERNAL REVETMENT	TATA spare parts
409089010752	FRONT GRILLE UPHOLDING STALK	TATA spare parts
409089010759	FRONT FLAP ASSY	TATA spare parts
409089010764	PLAIN_WASHER_ID6.4XOD17XT3_DIN 7349_12C2	TATA spare parts
409089010766	DASH BOARD LOCK	TATA spare parts
409089010787	SUGGESTION BOX ASSEMBLY DETAIL	TATA spare parts
409089010789	FUSE BOX LOCK WITH KEY	TATA spare parts

409089010793	ROOF MARKER LAMP MAINTANANCE ABS	TATA spare parts
409089010795	FLOOR COVER FINISHING	TATA spare parts
409089010796	EXTERNAL INSULATION BOOT	TATA spare parts
409089010798	FIRE EXTINGUISER	TATA spare parts
409089010802	FRONT PLATES AND ADHESIVES	TATA spare parts
409089010820	TUBE FOR PARTITION WALL	TATA spare parts
409089010828	PLASTIC BASE FOR HANDHOLD TUBE	TATA spare parts
409089010849	T JOINT FOR GRABRAIL	TATA spare parts
409089010853	GRABRAIL SUPPORT BRACKET	TATA spare parts
409089010856	PAN_HEAD_SCREW_B4.8X38X38_DIN7981_12C4	TATA spare parts
409089010862	PVC TUBE FOR HAND HOLD DIA 26.4 (ID)	TATA spare parts
409089010865	FLOOR FINISHING ALUMINIUM PROFILE	TATA spare parts
409089010869	GANGWAY GRAB RAIL SUPPORT	TATA spare parts
409089010871	TOOL BOX ASSEMBLY	TATA spare parts
409089010872	REAR DOOR PNEUMATIC HARNESS COVER_ABS	TATA spare parts
409089010880	REINFORCEMENT FOR DASHBOARD BASE MOUNT	TATA spare parts
409089010887	BUMPER BACKING WASHER	TATA spare parts
409089010891	FRP FRONT BUMPER ASSY-RHD	TATA spare parts
409089010894	A PILLAR-LH	TATA spare parts
409089010896	A PILLAR-RH	TATA spare parts
409089010899	FRP CNG VENT PIPE COVER-LH	TATA spare parts
409089010902	FRP CNG VENT PIPE COVER-RH	TATA spare parts
409089010906	MCV WIPER ARM RH	TATA spare parts
409089010910	MCV WIPER BLADE ASSY	TATA spare parts
409089010918	LOCK LOCATOR	TATA spare parts
409089010945	DRIVER DOOR LOCK KIT ASSY_RHD	TATA spare parts
409089010977	FITMENT OF SUPPORT FRONT BUMPER	TATA spare parts
409089010990	STOP REQUEST HARNESS	TATA spare parts
409089011005	WINDOW GAURAD RAIL CLAMP(CLOSED END)	TATA spare parts
409089011007	WINDOW GUARD RAIL BRACKET (OPEN END)	TATA spare parts
409089011009	WINDOW GAURAD RAIL TUBE-830	TATA spare parts
409089011051	SIDE EXT.PANELING BETWEEN WINDOWS-1	TATA spare parts
409089011052	SIDE EXT.PANELING BETWEEN WINDOWS-2	TATA spare parts
409089011053	SIDE EXT.PANELING BETWEEN WINDOW-03	TATA spare parts
409089011054	SIDE EXT.PANELING BETWEEN WINDOW-04	TATA spare parts
409089011055	SIDE EXT.PANELING BETWEEN WINDOW-05	TATA spare parts
409089011070	WIPER CONNECTOR ADAPTER HARNESS	TATA spare parts
409089011074	5.5X60 PAN PHILLIPS HEAD SCREW	TATA spare parts
409089011078	MULTIPLEXING BOX ASSY	TATA spare parts
409089011085	MS PLATE 4.25MM THK_60X50	TATA spare parts
409089011087	FRONT MARKER LAMP SUPPORT	TATA spare parts
409089011122	EMERGENCY DOOR & LOCK ASSY 870	TATA spare parts
409089011124	FAST COUPLING SUPPORT	TATA spare parts
409089011186	WINDOW GUARD RAIL TUBE-3160	TATA spare parts
409089011225	EMG DOOR INTERNAL PANEL_RHD870	TATA spare parts
409089011243	WINDOW GAURD RAIL TUBE-2815	TATA spare parts
409089011244	SOLID RUBBER PROFILES_FOR INSWING DOOR	TATA spare parts



409089011256	MULTIPLEXING BOX ASSY	TATA spare parts
409089011260	MULTIPLEXING BOX COVER	TATA spare parts
409089011261	HANDHOLD ASSEMBLY	TATA spare parts
409089011268	CO DRIVER WIPER COMPLEMENTARY HARNESS	TATA spare parts
409089011269	WIPER TWO STAGE SWITCH	TATA spare parts
409089011273	SUGGESTION STICKER	TATA spare parts
409089011277	FRP FRONT FLAP WITH STRUCTURE ASSEMBLY	TATA spare parts
409089011301	MS ERW TUBE 28.58 DIA 1.9THK LENGTH 3000	TATA spare parts
409089011304	REAR INTERNAL EMERGENCY SWITCH COVER	TATA spare parts
409089011305	FRONT INTERNAL EMERGENCY SWITCH COVER	TATA spare parts
409089011333	WINDSHIELD WIPER AXLE BUSHING	TATA spare parts
409089011348	GI COIL THK- 0.95 X 825 MM	TATA spare parts
409089011383	WINDOW GAURD RAIL TUBE-1450	TATA spare parts
409089011438	ROLLER TYPE SUNVISOR 800MM	TATA spare parts
409089011494	WINDOW GUARDRAIL TUBE_2555 MM	TATA spare parts
409089011503	DOORS CONTROL STICKER(MCV)	TATA spare parts
409089011504	EMERGENCY DOOR ELECTRIC HARNESS	TATA spare parts
409089011505	GLASS WOOL SEALING SUPPORT ASSY	TATA spare parts
409089011506	GLASSWOOL FOR ENGINEHOOD SEALING	TATA spare parts
409089011510	PANEL PLATE-RH-RHD	TATA spare parts
409089011511	PNEUMATIC HARNESS COVER ABS	TATA spare parts
409089011519	FRONT BUMPER LICENCE PLATE	TATA spare parts
409089011520	HOOD UPHOLDING ASSEMBLY OVER ENGINE	TATA spare parts
409089011526	MCV ENGINEHOOD EXT STAY ROD MOUNTING	TATA spare parts
409089011527	MCV ENGINE HOOD EXTERNAL STAY ROD	TATA spare parts
409089011528	MCV ENGINEHOOD EXT STAY ROD BUSH	TATA spare parts
409089011582	GEAR SHIFT LEVER PLATE	TATA spare parts
409089011802	DISCHARGE HOSE ASSY ( COMP END)	TATA spare parts
409089011803	SUCTION HOSE ASSY (UNIT END)	TATA spare parts
409089011804	DISCHARGE HOSE ASSY (UNIT END)	TATA spare parts
409089011805	SUCTION HOSE ASSY (COMP END)	TATA spare parts
409089030202	HAZARD WARNING SWITCH PIGTAIL	TATA spare parts
409090070201	M8X1.25X45-MM EGGHEAD SCREW	TATA spare parts
409090070202	S-M8X1.25X25-DIN 966-COATING FE/ZN 12C4	TATA spare parts
409090070203	5.5X50 PAN PHILLIOP	TATA spare parts
409090080201	M6X1X25-ZN 12 C2-TRIBOLAR BOLTS	TATA spare parts
409090080202	HEX COLLARED TRIBOULAR BOLT M 8X1.25X68	TATA spare parts
409090080203	HEX COLLARED TRIBOULAR BOLT M 8X1.25X25	TATA spare parts
409090090201	B 6.3 X 31-12 C1- ZN-PAN HEAD SCREW	TATA spare parts
409090090202	B 6.3X52-12C2-ALLEN SCREW	TATA spare parts
409090100106	HEX BOLT M8X110 IS1364P1 8.8 SS8451-8C	TATA spare parts
409090100107	HEX BOLT M6X50 IS1364P1 10.9 SS9400	TATA spare parts
409090100201	B 4.2X22- FASTNER	TATA spare parts
409090100203	HEX SCREW M6X25 IS1364P2-8.8-SS8451-8CDI	TATA spare parts
409090100204	M6X1X10LN-CL 8.8 - HEX BOLT	TATA spare parts
409090100205	HEX BOLT M12X130 IS1364P1-8.8-SS8451-8C	TATA spare parts
409090100206	HEXAGONAL HEAD SCREW - DIN 933	TATA spare parts

409090100207	HEX SCREWS-M8X1.25X25-DIN 933 -COATING F	TATA spare parts
409090100208	965 DIN - 8.8 CL - YELLOW ZINCPLATED	TATA spare parts
409090100212	HEX BOLT M5X0.8 X 20LN	TATA spare parts
409090100213	HEXAGONAL BOLT M8X70	TATA spare parts
409090100216	HEX BOLT M6X1X15 LENGTH IS:1364	TATA spare parts
409090100302	HEXAGONAL HEAD SCREW M8X1.25X25-CLASS 8.	TATA spare parts
409090100303	HEXAGONAL SCREW M6 X 1 X 20 _CCL 8.8	TATA spare parts
409090100304	M6 X 1.0 -HEX NUT	TATA spare parts
409090100401	NYLOCK BOLT-M8X1.25X25 CLAS. 5.6.ZA 12C2	TATA spare parts
409090100402	HEX SCREW M6X20 IS1364P2-8.8-SS8451-8C	TATA spare parts
409090100403	M8X20 HEX BOLT	TATA spare parts
409090100404	M6 X 1.0 X 30 CLASSE 8.8ZN 12C2	TATA spare parts
409090100501	NYLOCK BOLT-M8X1.25X45 CLAS. 5.6.ZA 12C2	TATA spare parts
409090110201	SCREW STS 5X35 CSK PH	TATA spare parts
409090110202	M8 CSK ALLEN BOLT	TATA spare parts
409090120201	B3.9X16-MM FLATHEAD SCREW	TATA spare parts
409090120204	FLAT HEAD SCREW - DIN 7982-B5.5X38-ZN 12	TATA spare parts
409090130202	M8X1.25X25CLASSE 5.6 ZN FLAT HEAD SCREW	TATA spare parts
409090130203	B 4.8X25 CLASSE 8.8 ZN 12C2 -FLAT HEAD S	TATA spare parts
409090130205	M4X0.7X15- CL 5.6-FLAT HEAD SCREWS	TATA spare parts
409090130206	M4X0.7X25-MM FLATHEAD SCREW	TATA spare parts
409090130207	M8X1.25X25.CLAS.8.8.ZN. FLAT HEAD SCREW	TATA spare parts
409090140201	STAR SCREW	TATA spare parts
409090140302	M5X0.8X25-MM ROUND HEAD SCREW	TATA spare parts
409090150101	M8X1.25X34.5LN-CL 10.9-ALLEN SCREW	TATA spare parts
409090150102	FLAT HEAD(ALLEN)SCREW-M6X1X55-CL8.8	TATA spare parts
409090150103	PAN HEAD SCREW - DIN 7981-B5.5X22 LN	TATA spare parts
409090150201	M10X1.50X45MM-CLASSE 12.9	TATA spare parts
409090150202	B 6.3X42-12C2-ALLEN SCREW	TATA spare parts
409090150203	PAN HEAD SCREWS-B 4.8X16-DIN 7981	TATA spare parts
409090150204	HEX. SOCKET HEAD CAP SCREW M8X1.25X90LN	TATA spare parts
409090150205	HEX. SOCKET HEAD CAP SCREW M8X1.25X60LN	TATA spare parts
409090150206	HEX. SOCKET HEAD CAP SCREW M8X20	TATA spare parts
409090150402	B 4.8X22-ZN-PAN HEAD SCREW	TATA spare parts
409090160201	AB 6.3X16-CL 8.8-ZN 12 C4-HEX FLANGED BO	TATA spare parts
409090160202	AB 6.3X25-HEX FLANGED BOLT	TATA spare parts
409090180301	HEX SCREW 7/16IN X 20 LN- UNF X 3/4-CLAS	TATA spare parts
409090180302	UNF SETSCREW 7/16 INCH- 25.4 LN(THRD LN	TATA spare parts
409090190101	BOLT WITH SCREW	TATA spare parts
409090190102	B4.8X32-MM EGGHEAD SCREW-ZN 12C4	TATA spare parts
409090190103	M8X1.25X45-CL8.8-ZN 12 C2-SILO SCREW	TATA spare parts
409090190104	TRIBOLAR HEX HEAD SCREW-M6X1X20-ZN 12 C2	TATA spare parts
409090190105	SPECIAL SCREWS	TATA spare parts
409090190106	BOLT WITH SCREW-M8X1.25	TATA spare parts
409090190201	B 6.3--22LN-ZN 12 C1 -PAN HEAD SCREW	TATA spare parts
409090190202	B 6.3X25- 12C1- TROX PAN HEAD SCREW	TATA spare parts
409090190204	B4.8 X 25-ZN 12C4 -PANHEAD SCREW	TATA spare parts

409090190205	B 4.2 X 19MM-ZN 12C4 - EGG HEAD SCREW	TATA spare parts
409090190207	B6.3X38-MM PANHEAD SCREW	TATA spare parts
409090190208	B4.2X25-ZN 12 C4-OVAL HEAD SCREWS	TATA spare parts
409090190209	B 4.2X20-CL 4.8-ZN 12 C4	TATA spare parts
409090190210	B3.5X13-CL5.8-ZN 12 C4	TATA spare parts
409090190211	ADJUSTABLE JAMB ROD	TATA spare parts
409090190212	SCREW HEAD WITH FLANGE-B4.2X32	TATA spare parts
409090190302	SCREW HEAD WITH FLANGE- B 4.2X32(AS PER	TATA spare parts
409090190303	B 3.9X19-ZN 12 C4- PAN HEAD SCREWS	TATA spare parts
409090190304	B 4.2X16-TRET :SUP ALUSEALPAN HEAD SCREW	TATA spare parts
409090190305	SPECIAL FLAT HEAD SCREW B4.8X25	TATA spare parts
409090190306	CHEESE HEAD SCREW B4.2 X 16	TATA spare parts
409090190309	RUBBER HEAD SCREW	TATA spare parts
409090190310	B 4.2X22.5-ZN 12 C1-FLAT HEAD SCREWS	TATA spare parts
409090190311	B3.5X13-MM-ZN 12C1- PANHEAD SCREW	TATA spare parts
409090190402	PAN HEAD SCREW -B 3.5X13 LN	TATA spare parts
409090200101	HEX NUT -M4X0.7- FE/ZN 12C2-CL 8.8-DIN 9	TATA spare parts
409090200102	NYLOC NUT M8 IS7002-8-SS8451-8C C8- CL 8	TATA spare parts
409090200105	HEX NUT M10 X 1.5 CL 8 FE/ZN 12C3	TATA spare parts
409090200106	HEX NUT M5 IS1364P3-8-SS8451-8C	TATA spare parts
409090200202	HEXAGONAL NUT M12 IS 1364P3-8-SS8451-8C	TATA spare parts
409090200203	HEX NUT M6 IS1364P3-8-SS8451-8C	TATA spare parts
409090200204	HEX NUT M8 IS1364P3-8-SS8451-8C	TATA spare parts
409090200206	HEX NUT M10 IS1364P3-8-SS8451-8C	TATA spare parts
409090200207	HEXAGONAL BOLT M8	TATA spare parts
409090200301	M8 X 1.25 -CLASSE 8-ZN 12C2 -HEXAGONAL N	TATA spare parts
409090200302	HEXAGONAL NUT M6X1.0	TATA spare parts
409090200303	HEX NUT M12 X 1.75- CLASSE 10.9-ZN 12C2	TATA spare parts
409090200304	NYLOCK NUT M6X1 IS:7002-2005	TATA spare parts
409090230201	PAN HEAD SCREWS	TATA spare parts
409090230202	M6 X 1_FE/ZN 12C2-YELLOW_POP NUT	TATA spare parts
409090270201	M8X1.25 WING NUT-DIN 315-ZN 12C2	TATA spare parts
409090270301	M6X1-ZN 12 C2-BUTTERFLY NUTS	TATA spare parts
409090280201	M12 HEX FLANGE NUT - DIN 6927	TATA spare parts
409090290201	M6X1 0- SPECIAL HEX NUT (BLIND DOM NUT)	TATA spare parts
409090290202	HEXAGONAL NUT 1/4 X 20 UNC	TATA spare parts
409090290203	DOME NUT M10	TATA spare parts
409090290204	NYLON INSERT NUT - M14	TATA spare parts
409090290401	3/16' BLACK ZINC PLATED BRASS HEXAGONAL	TATA spare parts
409090300102	BRIGHT WASHER 10.5-IS2016-ST-SS8451-8C	TATA spare parts
409090300103	PLAIN WASHER 10.5 DIN 125 FEZN 12 C4	TATA spare parts
409090300201	BRIGHT WASHER 6.4 IS2016 ST SS8451-8C	TATA spare parts
409090300202	FLAT WASHER-12X28X2.5-ZN 12C2	TATA spare parts
409090300203	WASHER ID13 OD40 THK 3-IS:5370	TATA spare parts
409090300204	WASHER A8.4 IS5370 ST SS8451-8C	TATA spare parts
409090300301	PLANE WASHER-8.4X17X16 -ZN 12C3	TATA spare parts
409090300302	BRIGHT WASHER 8.4-IS2016-ST-SS8451-8C	TATA spare parts

409090300303	PLAIN WASHER	TATA spare parts
409090300401	SMOOTH WASHER DIN 125	TATA spare parts
409090300501	BRIGHT WASHER 10.5-IS2016-ST-SS8451-8C	TATA spare parts
409090330101	SPRING WASHER B10 IS3063 SS8451-8C	TATA spare parts
409090330201	SPRING WASHER B6 IS3063 SS8451-8C	TATA spare parts
409090330202	PRESSURE WASHER- 8-1X14.8X2-ZN 12C3	TATA spare parts
409090330203	LOCK WASHER	TATA spare parts
409090330204	SPRING WASHER B6 IS3063 SS8451-8C	TATA spare parts
409090330301	SPRING WASHER B8 IS3063 SS8451-8C12C2	TATA spare parts
409090330302	2X6.6X24.7-MM FLAT WASHER W/ YELLOW ZIN	TATA spare parts
409090350202	WAVE WASHER M5	TATA spare parts
409090400101	DIA 3.18X12-MM BUTTON HEAD ALUMINUM RIVET	TATA spare parts
409090400102	OD 4.8X21.6-MM OPEN SNAP RIVET	TATA spare parts
409090400201	DIA 4.8X13 LN-POP RIVET	TATA spare parts
409090400203	HOLLOW RIVET- OD 4.8 X 17 1LN	TATA spare parts
409090400204	ROUND HEAD RIVET DIA 3.18 X 10	TATA spare parts
409090400301	HOLLOW RIVET-DIA 3.2X10.2 LN-MANDREL LN	TATA spare parts
409090430201	HOLLOW RIVET- OD 4.8X ID 2.7X21.6 LN	TATA spare parts
409090430202	PRESS RIVET-OD 10- COLLAR COLOUR : GRAY	TATA spare parts
409090430203	HOLLOW RIVET_ID 3.2X15.2LN-MANDREL LN 25	TATA spare parts
409090430204	HOLLOW RIVET-OD 3.2 X 15.2 LN	TATA spare parts
409090430205	BRIGHT WASHER 6.4 IS2016-ST-SS8451-13D	TATA spare parts
409090430208	ROUND HEAD TYPE RIVET DIA 4.8X23 L	TATA spare parts
409090430209	ROUND HEAD TYPE RIVET DIA 4.8 X 18 L	TATA spare parts
409090430210	SEALED RIVET4.8X20LN(REF.NO.CE113-04820)	TATA spare parts
409090500301	SPECIAL WASHER	TATA spare parts
409090600301	COUNTERPINS-EXTERNAL DIA 2X 25 LN	TATA spare parts
409090700207	DOOR SEALING SUPPORT	TATA spare parts
409090700501	DIA 3.2X25LN-CYL PIN	TATA spare parts
409091004801	3X25X2500MM MULTI-USO MASS	TATA spare parts
409091100101	WELDING ROD BLUE ROUND	TATA spare parts
409091100102	TRIANGULAR PVC WELDING ROD(4 MM THICK)	TATA spare parts
409091100103	GLASS WOOL 50 MM THK 40 KG /M3 IS3690	TATA spare parts
409091100110	TRIANGULAR PVC WELDING ROD GRAY-4MM THK	TATA spare parts
409091100111	WELDING ROD GRAY ROUND	TATA spare parts
409091100301	MS ERW TUBE 32 DIA 3 THK LENGTH 3000MM	TATA spare parts
409091100302	MS ERW TUBE 40 DIA 3 THK LENGTH 3000 M	TATA spare parts
409091200103	AL PROFILE USING IN RAMP ASSY- LN 2332	TATA spare parts
409091200104	AL PROFILE - LN 6750	TATA spare parts
409091200106	DRIVER DOOR LOWER FINISHING	TATA spare parts
409091200109	AL PROFILE - LN 17808 MM	TATA spare parts
409091200110	AL PROFILE - LN 3376 MM	TATA spare parts
409091200113	AL PROFILE - LN 2187 MM	TATA spare parts
409091200114	AL PROFILE - LN 3376 MM	TATA spare parts
409091200115	AL PROFILE -LN 34140	TATA spare parts
409091200116	RAMP FINISH PROFILE	TATA spare parts
409091200119	AL PROFILE BELOW WHEEL ARCH SOLID RUBBER	TATA spare parts

409091200121	AL PROFILE FOR SKIRT PANELING	TATA spare parts
409091200127	AL PROFILE FOR CUTOUT PLYWOOD	TATA spare parts
409091200130	AL PROFILE FOR CUTOUT PLYWOOD (12 MM)	TATA spare parts
409091200209	AL PROFILE FOR VINYL FINISHING	TATA spare parts
409091300101	7.40 ID CORRUGATED TUBE FR TYPE	TATA spare parts
409091300102	11.8 ID CORRUGATED TUBE FR TYPE	TATA spare parts
409091400103	MARINE PLY FR 19MM AS PER IS:710 & 15061	TATA spare parts
409091500103	PVC PROFILE	TATA spare parts
409091500104	PVC PROFILE	TATA spare parts
409091500105	FINISHING PROFILE	TATA spare parts
409091500106	DOOR UPPER PVC PROFILE	TATA spare parts
409091500107	PVS PROFILE-(EVO-1)	TATA spare parts
409091500115	JOINING PROFILE	TATA spare parts
409091500116	PVC PROFILE FOR WINDOW FINISHING	TATA spare parts
409091500201	SEAT RAIL	TATA spare parts
409091500202	SIDE INTERNAL PANELING	TATA spare parts
409091500204	MIDDLE CEILING FINISHING TRIM	TATA spare parts
409091700110	PVC COATED GI SHEET(EVO 1)0.72X1220X2020	TATA spare parts
409091700255	PVC PROFILE	TATA spare parts
409091800105	RUBBER SEALING	TATA spare parts
409091800106	RUBBER FOR CUTOUT SEALANT	TATA spare parts
409091800107	GAS CYLINDER SUPPORT RUBBER	TATA spare parts
409091800108	SOLID RUBBER PROFILES	TATA spare parts
409091800109	SOLID RUBBER PROFILE	TATA spare parts
409091800110	RUBBER PROFILE-RADIATOR ASSY	TATA spare parts
409091800111	SOLID RUBBER PROFILE	TATA spare parts
409091800112	RUBBER PROFILE FOR SKIRT PANELING	TATA spare parts
409091800113	PASTED GLASSES RUBBER PROFILE-1	TATA spare parts
409091800114	PASTED GLASSES RUBBER PROFILE-2	TATA spare parts
409091800115	RUBBER PROFILE FOR SKIRT PANELING	TATA spare parts
409091800116	SOLID RUBBER PROF.FOR WIND.MOUNTING	TATA spare parts
409091800117	SPONGY RUBBER PROFILE FOR WINDSHIELD	TATA spare parts
409091800120	ROOF HATCH RUBBER PROFILE	TATA spare parts
409091800203	RUBBER PROFILE FOR PASSENGER DOOR	TATA spare parts
409091900101	SILICON SEALANT(CLEAR CARTRIDGE) TS25409	TATA spare parts
409092000201	STOP REQUEST BOX KIT	TATA spare parts
409092000202	DUCT COVER ATTACHMENT SUPPORT ASSEMBLY	TATA spare parts
409092000203	AIR DUCT HINGE KIT	TATA spare parts
409092000204	DUCT COVER ATTACHMENT SUPPORT ASSEMBLY	TATA spare parts
409092000205	DUCT COVER ATTACHMENT SUPPORT ASSY	TATA spare parts
409092000206	DUCT COVER ATTACHMENT SUPPORT ASSY.	TATA spare parts
409092000207	DUCT SUPPORT ( LEFT SIDE)	TATA spare parts
409092000208	DUCT SUPPORT(RIGHT SIDE)	TATA spare parts
409092000209	DUCT SUPPORT	TATA spare parts
409092000213	AIR CURTAIN SUPPORT ASSY	TATA spare parts
409092000217	AIR CURTAIN SUPPORT ASSY	TATA spare parts
409092000222	AC_LOUVER SMALL ROUND-EVO-3	TATA spare parts

409092000340	DUCT SUPPORT PLATE RH REAR & LH FRONT	TATA spare parts
409092000341	DUCT SUPPORT PLATE LH REAR & RH FRONT	TATA spare parts
409092200201	LUMINARY REACTOR COVER	TATA spare parts
409092200202	ACRYLIC PROFILE	TATA spare parts
409092200203	AIR CONDITIONING DUCT EXTREMITY FINISH	TATA spare parts
409092200204	AIR CONDITIONING DUCT EXTREMITY FINISH.	TATA spare parts
409092200205	VENTILATION GRILL	TATA spare parts
409092200209	SINGLE AC LOUVER MIDDLE	TATA spare parts
409092200210	AIR DUCT COVER LEFT SIDE	TATA spare parts
409092200211	AIR DUCT COVER RIGHT SIDE	TATA spare parts
409092200213	SPEAKER FINISHING	TATA spare parts
409092200217	DUCT CLOSING WITHOUT LOUVERS	TATA spare parts
409092200218	ACRYLIC COVER (WHITE)	TATA spare parts
409092200264	RH REAR JOINERY DUCT	TATA spare parts
409092200265	LH REAR JOINERY DUCT	TATA spare parts
409092200342	ABS DUCT PANEL LH 1	TATA spare parts
409092200343	ABS DUCT PANEL LH 2	TATA spare parts
409092200344	ABS DUCT PANEL LH 3	TATA spare parts
409092200345	ABS DUCT PANEL LH 4	TATA spare parts
409092200346	ABS DUCT PANEL LH 5	TATA spare parts
409092200347	ABS DUCT PANEL LH 6	TATA spare parts
409092200348	AC DUCT END CAP LH REAR	TATA spare parts
409092200349	ABS DUCT PANEL RH 1	TATA spare parts
409092200350	ABS DUCT PANEL RH 2	TATA spare parts
409092200351	ABS DUCT PANEL RH 3	TATA spare parts
409092200352	ABS DUCT PANEL RH 4	TATA spare parts
409092200353	ABS DUCT PANEL RH 5	TATA spare parts
409092200354	ABS DUCT PANEL RH 6	TATA spare parts
409092200355	AC DUCT END CAP RH REAR	TATA spare parts
409092300202	ALUMINIUM PROFILE	TATA spare parts
409092600201	DUCT COVER ATTACHMENT SUPPORT ASSEMBLY	TATA spare parts
409092600202	DEMISTER	TATA spare parts
409092700201	DUCT COMPLEMENTARY CLOSING	TATA spare parts
409092700202	AIR DEFLECTION PLATE	TATA spare parts
409092700203	Z- SHAPE PLATE	TATA spare parts
409092700204	DUCT STRUCTURE REINFORCEMENT	TATA spare parts
409092700205	MODULE SUPPORT	TATA spare parts
409092700207	PLATE FOR JOINING AL PROFILE	TATA spare parts
409092700339	Z SHAPE PLATE_2500L	TATA spare parts
409092700340	AC DUCT MOUNTING Z-PLATE 1933L	TATA spare parts
409092700341	AC DUCT MOUNTING Z-PLATE	TATA spare parts
409092990101	SELF ADHESIVE KINI FOAM FR 35 KG/CM 6	TATA spare parts
409092990102	SELF ADHESIVE KINI FOAM FR 35 KG/CM3 .10	TATA spare parts
409092990201	AC_SPHEROS	TATA spare parts
409092990303	ANG.CONTCT BALL BEARING	TATA spare parts
409094010101	SPONGY RUBBER PROFILE FOR WINDSHIELD	TATA spare parts
409094010102	ALUMINIUM PROFILE 206 3 MTR	TATA spare parts

409094010103	SPONGY RUBBER PROFILE	TATA spare parts
409094010104	WHITE CONSPICUITY TAPE AS PER AIS 090	TATA spare parts
409094010105	RED CONSPICUITY TAPE AS PER AIS 090	TATA spare parts
409094010106	YELLOW CONSPICUITY TAPE AS PER AIS 090	TATA spare parts
409094010107	FLEXIBLE RUBBER PROFILE WHEEL ARCH-6 MTR	TATA spare parts
409094010108	AL PROFILE W/ARCH SOLID RUBBER 3MTR	TATA spare parts
409094010109	RUBBER PROFILE FOR SKIRT PANELING-6 MTR	TATA spare parts
409094010110	AL PROFILE FOR CUTOUT PLYWOOD 4 MTR	TATA spare parts
409094010111	DOOR SEALING RUBBER	TATA spare parts
409094010112	HANDHOLD ASSY FOR 28 DIA	TATA spare parts
409094010113	HANDHOLD ASSY FOR 40 DIA	TATA spare parts
409094010114	MIDDLE CEILING PVC PROFILE(EVO-3)	TATA spare parts
409094010115	SEAT RAIL FINISHING PROFILE (EVO-3)-3MTR	TATA spare parts
409094010116	SIDE INTERNAL PVC PROFILE(EVO-1)	TATA spare parts
409094010119	DOUBLE INSULATION-NBR13249 STOP REQ	TATA spare parts
409094030103	PVC ROLLAR OF GUIDE ASM	TATA spare parts
409099100101	RUBBER JAMB	TATA spare parts
409099120101	JAMB BOLT	TATA spare parts
409099120201	B 4.8X22-ZN 12 C4-FLAT HEAD SCREW	TATA spare parts
4093648	PUMP FUEL INJECTION	TATA spare parts
4093671	CONNECTION OIL SUMP	TATA spare parts
4093674	SCREW BANJO CONNECTOR	TATA spare parts
4093678	PISTON ENGINE EUROII	TATA spare parts
4093685	FAN PULLEY 1:2 RATIO	TATA spare parts
4093687	FAN 7BLADES	TATA spare parts
4093743	CONNECTION TURBO OIL DRAIN	TATA spare parts
4093770	STUD M10X1.5X67	TATA spare parts
4093784	TUBE DIPSTICK	TATA spare parts
4093785	TUBE DIPSTICK	TATA spare parts
4093786	TUBE DIPSTICK	TATA spare parts
4093789	DIPSTICK	TATA spare parts
4093790	DIPSTICK	TATA spare parts
4093791	DIPSTICK	TATA spare parts
4093793	SEAL O RING	TATA spare parts
4093805	HOSE FLEXIBLE	TATA spare parts
4093806	HOSE FLEXIBLE	TATA spare parts
4093816	HOUSING THERMOSTAT	TATA spare parts
4093821	CONTROL FUEL	TATA spare parts
4093825	PUMP FUEL TRANSFER	TATA spare parts
4093828	SUPPORT-ALTERNATOR	TATA spare parts
4093831	CYL HEAD ASSY W/ VALVES 1510CNG	TATA spare parts
4093833	BRACE ALTERNATOR	TATA spare parts
4093839	BRACE ALTERNATOR	TATA spare parts
4093842	FAN ENGINE	TATA spare parts
409384200	FAN ENGINE	TATA spare parts
4093844	SET PISTON BARE EURO II RS-I	TATA spare parts
4093845	SET-BARE PISTON-R/SII EURO II	TATA spare parts

4093846	INJECTOR	TATA spare parts
4093857	PLUG PIPE	TATA spare parts
4093859	TUBE FUEL DRAIN	TATA spare parts
4093865	TUBE OIL GAUGE	TATA spare parts
4093866	TUBE OIL GAUGE	TATA spare parts
4093887	RING GEAR-4.9THK	TATA spare parts
4093888	STARTER 24 VOLTS	TATA spare parts
4093889	FLYWHEEL 125 HP	TATA spare parts
4093896	PUMP FUEL INJECTION	TATA spare parts
4093903	KIT OIL SEALS	TATA spare parts
4093904	KIT GASKET FULL ENGINE	TATA spare parts
4093941	STARTER MOTOR 12V	TATA spare parts
4093943	MOTOR STARTING 12 VOLTS	TATA spare parts
4093944	ALTERNATOR 12 VOLTS	TATA spare parts
4093946	BRACE ALTERNATOR	TATA spare parts
4093948	CONNECTION AIR INTAKE	TATA spare parts
4093950	ELBOW MALE ADAPTER	TATA spare parts
4093952	CONNECTION WATER INLET	TATA spare parts
4093964	TUB INJECTOR FUEL SUPPLY	TATA spare parts
4093965	TUB INJECTOR FUEL SUPPLY	TATA spare parts
4093980	TUBE FUEL SUPPLY	TATA spare parts
4093982	TUBE FUEL DRAIN	TATA spare parts
4093985	TUBE FUEL DRAIN	TATA spare parts
4093989	TUBE FUEL DRAIN	TATA spare parts
4093998	BRACKET FUEL FILTER	TATA spare parts
4094004	TUBE FUEL SUPPLY	TATA spare parts
4094007	INJECTOR	TATA spare parts
4094018	COVER PUSH ROD	TATA spare parts
4094027	FUEL INJ PUMP 125 HP BSIII	TATA spare parts
4094028	FAN ENGINE 24 INCH	TATA spare parts
4094029	LINER CYLINDER COLLERED	TATA spare parts
4094034	PUMP WATER	TATA spare parts
4094036	COMPRESSOR AIR	TATA spare parts
4094038	FAN ENGINE	TATA spare parts
4094043	PIPE AIR TRANSFER	TATA spare parts
4094047	TUBE OIL GAUGE	TATA spare parts
4094048	DIPSTICK	TATA spare parts
4094049	KIT, OIL PUMP	TATA spare parts
4094050	ALTERNATOR (12V 40AMPS. 2GRV.PULLEY)	TATA spare parts
4094053	CONNECTION SPACER	TATA spare parts
4094054	SEAL BANJO CONNECTOR	TATA spare parts
4094055	SCREW CAPTIVE WASHER CAP	TATA spare parts
4094069	CAMSHAFT	TATA spare parts
4094072	PISTON E-III	TATA spare parts
4094073	PISTON ENGINE EIII	TATA spare parts
4094077	COUPLING PLAIN HOSE	TATA spare parts
4094079	FLYWHEEL-LPS4923-380D CL	TATA spare parts



4094089	ALTERNATOR 90 AMP	TATA spare parts
4094094	FLYWHEEL	TATA spare parts
4094103	CONNECTION AIR INTAKE	TATA spare parts
409801010001	RVM ARM ASSY COMP LHD/RH	TATA spare parts
409801010002	MUD FLAP PANEL	TATA spare parts
409801010003	FRONT PANEL (LPO 1610 FE)	TATA spare parts
409801010004	TATA BIG MASCOT 51 MM	TATA spare parts
409801010005	OPP.REAR DOOR WINDOW SKRIT PANEL	TATA spare parts
409801010007	FRONT BUMPER (LPO 1610FE)	TATA spare parts
409801010010	STARBUS BIG MASCOT 51 MM	TATA spare parts
409801010011	FRT. W/S W/O S. BAND	TATA spare parts
409801010014	SIDE-OUTER AL-EXTRUSION	TATA spare parts
409801010016	AL-EXTRUSION(REAR)	TATA spare parts
409801010021	FOOT STEP CASTING	TATA spare parts
409801010024	FRP REAR STRUCTURE (W/O DICKEY + STARBUS	TATA spare parts
409801010025	REAR WINDSHIELD	TATA spare parts
409801010027	TAIL LAMP CURVED (AMBER)	TATA spare parts
409801010028	TAIL LAMP CURVED (WHITE)	TATA spare parts
409801010029	ROUND REFLECTOR E/E MARK	TATA spare parts
409801010030	REAR BUMPER	TATA spare parts
409801010031	REAR NO PLATE LAMP ASSY	TATA spare parts
409801010032	REFLECTIVE PLATE	TATA spare parts
409801010033	TAIL LAMP CURVED (RED)	TATA spare parts
409801010036	REAR WINDSHILD BEADING	TATA spare parts
409801010038	PASSENGER FAN (24 VOLTS)	TATA spare parts
409801010045	TOGGLE SW/JOY STICK TYPE	TATA spare parts
409801010047	ASSY DOOR LOCK LH	TATA spare parts
409801010062	GRAB HANDLE (SAFARI)	TATA spare parts
409801010065	FIRE EXTINGUISHER A/B/C-5 KGS	TATA spare parts
409801010066	ARM ASSY FOR FRONT FLAP	TATA spare parts
409801010067	ARM ASSY FOR FRONT FLAP (RH)	TATA spare parts
409801010071	GAS SPRING FOR FRONT FLAP	TATA spare parts
409801010073	SIDE WINDOW ASSY	TATA spare parts
409801010074	SIDE WINDOW ASSY	TATA spare parts
409801010075	SIDE WINDOW ASSY	TATA spare parts
409801010076	SIDE WINDOW ASSY	TATA spare parts
409801010077	SIDE WINDOW ASSY	TATA spare parts
409801010078	SKIRT PANEL COMPLETE	TATA spare parts
409801010079	SKIRT PANEL COMPLETE	TATA spare parts
409801010080	DOOR ASSY/ST	TATA spare parts
409801010081	SKIRT PANEL COMPLETE	TATA spare parts
409801010083	SKIRT PANEL COMPLETE	TATA spare parts
409801010084	SKIRT PANEL COMPLETE	TATA spare parts
409801010085	DOOR ASSY/BT	TATA spare parts
409801010086	SKIRT PANEL COMPLETE	TATA spare parts
409801010088	WHEEL SIDE COVER / F	TATA spare parts
409801010089	WHEEL SIDE COVER / R	TATA spare parts

409801010090	WHEEL SIDE COVER / F	TATA spare parts
409801010091	SKIRT PANEL COMPLETE/FT	TATA spare parts
409801010092	WHEEL SIDE COVER	TATA spare parts
409801010093	SKIRT PANEL	TATA spare parts
40CX003Z00	LEAF SPRING ASSY	TATA spare parts
40CX004Z00	TOP PAD	TATA spare parts
410124100101	ASSY.RUBBER SUPPORT REAR	TATA spare parts
410124103707	ENGINE MTG ARM FOR SAE 1 HSG - RH	TATA spare parts
410124103708	ENGINE MTG ARM FOR SAE 1 HSG - LH	TATA spare parts
410124105101	ENGINE MOUNTING ARM RH FRONT	TATA spare parts
410124105102	ENGINE MOUNTING ARM LH FRONT	TATA spare parts
410124107101	TORQUE SUPPORT	TATA spare parts
410126000108	COOLER SET FOR GEAR BOX	TATA spare parts
410126800101	ASSY PGS KIT COMPLETE	TATA spare parts
410126800102	ALUMINIUM BLOCK ASSY	TATA spare parts
410126800103	SHIFTER CABLE ASSY-9.6 METER	TATA spare parts
410126800105	GEAR LEVER KNOB ASSY	TATA spare parts
410126800113	ASSY CLAMP FOR PGS CABLE	TATA spare parts
410126805101	BALL JOINT	TATA spare parts
410126806001	ROTATION ROD-380 MM	TATA spare parts
410126807501	VINIL BELLOW	TATA spare parts
410126808201	BRACKET PGS MTG	TATA spare parts
410126808203	MTG. BKT. FOR OIL COOLER -LH	TATA spare parts
410126808204	MTG. BKT. FOR OIL COOLER -RH	TATA spare parts
410126809901	VIBRATION DAMPER	TATA spare parts
410126809902	SHIFT PATTERN R-LB	TATA spare parts
410126900101	ASSY HOSE FOR OIL COOLER-1	TATA spare parts
410126900102	ASSY HOSE FOR OIL COOLER-2	TATA spare parts
410126900103	ASSY HOSE FOR OIL COOLER-3	TATA spare parts
410126900104	ASSY HOSE FOR OIL COOLER-4	TATA spare parts
410126900105	ASSY HOSE FOR OIL COOLER-5	TATA spare parts
410126906902	TUBE-1 FOR OIL COOLERR	TATA spare parts
410126908201	BKT-1 FOR PRESSURE VALVE (OIL COOLER)	TATA spare parts
410126908202	BKT-2 FOR PRESSURE VALVE	TATA spare parts
410128100213	FEEDING ELECTRIC HARNESS	TATA spare parts
410129000101	CLUTCH BOOSTER	TATA spare parts
410129000102	CLUTCH BOOSTER 3 INCH (PUSH ROD LENGTH -	TATA spare parts
410129100108	ASSY. PIPE (8 O.D.) WITH END FITTINGS	TATA spare parts
410129100109	ASSY. PIPE (8 O.D.) WITH END FITTINGS	TATA spare parts
410129100111	ASSY. PIPE (8 O.D.) WITH END FITTINGS	TATA spare parts
410129100115	ASSY.CLUTCH PEDAL COMPLETE	TATA spare parts
410129100116	ASSY. SUPPORT COMPLETE (CLUTCH)	TATA spare parts
410129100124	ASSY.MASTER CYLINDER-25.4DIA(WITHSPOT	TATA spare parts
410129108206	L-BRACKET (DRIVER STATION END) BS6	TATA spare parts
410129108207	TWIST BRACKET (PGS TOWER BKT. END)	TATA spare parts
410130100102	ASSY.FRONT BELL CRANK WITH BUSH	TATA spare parts
410130100103	BRKT. ACC. PEDAL MTG.	TATA spare parts

410130100104	ASSY. ACCELETOR PEDAL UNIT BS3/4	TATA spare parts
410130100106	CABLE ACCELERATOR	TATA spare parts
410130100107	SUB ASSY BELL CRANK LEVER (WELDED)	TATA spare parts
410130100111	ASSY. ACCELERATOR PEDAL COMPLETE	TATA spare parts
410130100112	ASSY. ENGINE STOP BRACKET	TATA spare parts
410130103304	CABLE HOLDING BRACKET FRONT	TATA spare parts
410130406001	LEVER-RETARDER ON/OFF SWITCH	TATA spare parts
410131100103	ASSY FOR NOISE SHIELD & BRACKET	TATA spare parts
410131107111	RIB FOR REINFORCEMENT	TATA spare parts
410131107114	PLATE 5 THK BSK46	TATA spare parts
410131107115	PLATE 5 THK BSK46	TATA spare parts
410131107116	RIB BKT	TATA spare parts
410131200102	ASSY CROSS MEMBER (FRONT MODULE)	TATA spare parts
410131200103	ASSY CROSS MEMBER-FRONT (FRONT MODULE)	TATA spare parts
410131207108	CROSS MEMBER (C-TYPE)	TATA spare parts
410131700103	ASSY. RETARDER MTG. OUTER BKT . LH	TATA spare parts
410131700106	ASSY. SUPPORT BRACKET 4	TATA spare parts
410131700118	ASSY. BRACKET FOR WIRE AND CABLE (AIR BE	TATA spare parts
410131700119	ASSY. BRKT PIPE AND CABLE FRONT MODULE	TATA spare parts
410131700120	ASSY. BRKT PIPE AND CABLE CROSS MEMBER	TATA spare parts
410131700124	ASSY. NOISE SHEILD RH SIDE	TATA spare parts
410131700125	ASSY. NOISE SHEILD LH SIDE	TATA spare parts
410131700126	ASSY. NOISE SHEILD BOTTOM	TATA spare parts
410131703334	BKT-3(HARNESS MTG.)	TATA spare parts
410131703342	BKT-10 (HARNESS MTG.)	TATA spare parts
410131703344	BKT-12 (HARNESS MTG.)	TATA spare parts
410131708228	SUPPORT BRACKET NOISE SHEILD	TATA spare parts
410132100103	ASSY. BRACKET FRONT ANTI ROLL BAR MTG.	TATA spare parts
410132100104	ASSY. AIR SPRING (FRONT SUSPENSION)	TATA spare parts
410132300101	ASSY. FRONT SHOCK ABSORBER	TATA spare parts
410132400101	ASSY FRONT AIR SPRING MTG BRACKET	TATA spare parts
410132400102	ASSY FRONT AIR SPRING MTG BRACKET	TATA spare parts
410132400104	ASSY. REAR AIR SPRING BKT RH	TATA spare parts
410132400105	PARALLEL LINK BKT - LH	TATA spare parts
410132400106	ASSY PARALLEL LINK BRACKET-RH	TATA spare parts
410132400107	ASSY REAR SUSPENSION COMPLETE	TATA spare parts
410132400111	10 INCH AIR SPRING ASSY	TATA spare parts
410132400112	LEVELLING VALVE ASSY-LH	TATA spare parts
410132400115	LEVELLING VALVE ASSY-RH	TATA spare parts
410132403201	M6 X 1 X 25MM HEX BOLT	TATA spare parts
410132403202	M8X1.25X55MM HEX BOLT	TATA spare parts
410132403203	M14 X 1.5 X 35MM HEX BOLT	TATA spare parts
410132403204	M14 X 1.5 X 50MM HEX BOLT	TATA spare parts
410132403205	M14 X 1.5 X 60MM HEX BOLT	TATA spare parts
410132403206	M16 X 1.5 X 45MM HEX BOLT	TATA spare parts
410132403207	M16 X 1.5 X 70MM HEX BOLT	TATA spare parts
410132403210	HEX. SCREW M20X1.5X75	TATA spare parts

410132403211	M20X1.5X55MM HEX SCREW	TATA spare parts
410132403212	M24X3X190MM HEX BOLT	TATA spare parts
410132403214	M20X2.5X140MM HEX BOLT	TATA spare parts
410132403215	M12X1.75X85 STUD	TATA spare parts
410132403301	BRACKET ON AXLE-TOP LINK	TATA spare parts
410132403302	CROSS LINK	TATA spare parts
410132403401	SPHERILASTIC BUSH	TATA spare parts
410132403402	SPHERILASTIC BUSH	TATA spare parts
410132404801	COWHORN DOWEL	TATA spare parts
410132406501	M6 X 1 HEX NUT	TATA spare parts
410132406502	M8X1.25 HEX NUT	TATA spare parts
410132407101	HANGER&LINK&PLATE	TATA spare parts
410132408303	SHIM - 2MM (ARB)	TATA spare parts
410132408304	SHIM - 3MM (ARB)	TATA spare parts
410132409202	M8 SPRING WASHER	TATA spare parts
410132409203	M8 MACHINED WASHER	TATA spare parts
410132807101	CLAMP FRONT ANTIROLL BAR	TATA spare parts
410132807701	BUSH FRONT ANTIROLL BAR 1	TATA spare parts
410132900101	HANGER LINK ASSY	TATA spare parts
410132900102	ASSY. SPLIT BUSH HANGER LINK BS2/3/4	TATA spare parts
410132905101	ANTI ROLL BAR END LINK	TATA spare parts
410132907901	ANTI ROLL BAR	TATA spare parts
410132990102	KIT-ANTI-ROLL BAR STOPPER	TATA spare parts
410141100102	DRIVE SHAFT-LUBE FOR LIFE	TATA spare parts
410143700110	ASSY. BRACKET (CONCEP UNIT MTG.)	TATA spare parts
410143708205	RELAY VALVE MTG. BRACKET	TATA spare parts
410143800101	ASSY PIPE CLAMP (RETARDER PIPE)	TATA spare parts
410143900130	ASSY NYLON PIPE BUNCH LPO 1628	TATA spare parts
410143900183	RUBBER HOSE FOR HBV	TATA spare parts
410143906901	AIR COMPRESSOR PIPE - 1	TATA spare parts
410143906902	AIR COMPRESSOR PIPE - 2	TATA spare parts
410143906903	AIR COMPRESSOR PIPE - 3	TATA spare parts
410146100102	ASSY BRACKET (BEVEL G.B MTG)	TATA spare parts
410146600101	ASSY. STEERING PUMP (WITH ADAPTORS)	TATA spare parts
410146800101	ASSY. HOSE - CRIMPED (STG. TANK TO STG.	TATA spare parts
410146800102	ASSY HOSE - CRIMPED (STG. TANK TO STG. G	TATA spare parts
410146800108	HP HOSE ASSY (STG. PUMP TO STG. GEAR BOX	TATA spare parts
410146800109	ASSY. PIPE (15 O.D.) WITH END FITTINGS	TATA spare parts
410146800110	ASSY. PIPE (15 O.D.) WITH END FITTINGS	TATA spare parts
410146800111	ASSY PIPE (15 O.D.) WITH END FITTINGS	TATA spare parts
410146808203	L-BRACKET (ON AC COMPRESSOR MTG BKT)	TATA spare parts
410147000101	KIT FUEL VOSS CONNECTIONS FOR HD285	TATA spare parts
410147100104	ASSY FUEL TANK COMPLETE	TATA spare parts
410147600112	HOSE FOR FUEL FILLER	TATA spare parts
410147708202	BKT. FOR FUEL FILLER	TATA spare parts
410149000101	ASSY. BRACKET (FOR EXHAUST MTG)	TATA spare parts
410149100101	EXHAUST SILENCER ASSY.	TATA spare parts

410149100102	EXHAUST SILENCER ASSY HI DECK BUS	TATA spare parts
410149200101	ASSY. PIPE - EXHAUST	TATA spare parts
410150000101	RADIATOR INTERCOOLER ASSY	TATA spare parts
410150100101	RESERVE TANK ASSY	TATA spare parts
410150100102	RADIATOR ASSEMBLY	TATA spare parts
410150100103	INTERCOOLER ASSEMBLY	TATA spare parts
410150115801	HOSE RADIATOR BOTTOM	TATA spare parts
410150115802	HOSE RADIATOR BOTTOM	TATA spare parts
410150115803	HOSE ID-60	TATA spare parts
410150115804	Z-HOSE ENGINE BYPASS	TATA spare parts
410150116805	PIPE RETARDER TO ENGINE	TATA spare parts
410150116806	PIPE SURGE TANK	TATA spare parts
410150116814	PIPE RADIATOR TO RETARDER1 FOR SAE 1 HSG	TATA spare parts
410150116815	PIPE 2 RETARDER TO ENGINE SAE 1 HSG	TATA spare parts
410150116816	VENT TUBE RADIATOR TO SURGE TANK	TATA spare parts
410150116817	VENT TUBE ENGINE TO SURGE TANK	TATA spare parts
410150116819	PIPE ENGINE TO INTERCOOLER	TATA spare parts
410150116820	CAST PIPE ENGINE TO INTERCOOLER	TATA spare parts
410150116821	PIPE RADIATOR TO RETARDER FOR SAE 1 HSG	TATA spare parts
410150400101	ASSY MTG BRKT FOR RADIATOR	TATA spare parts
410150400105	ASSY RUBBER CLAMP	TATA spare parts
410150403315	PIPE THERMO BYPASS MTG	TATA spare parts
410150403324	BRACKET 6(COOLING PIPIES MTG)	TATA spare parts
410150403326	BRACKET 8(COOLING PIPIES MTG)	TATA spare parts
410150403328	ASSY BRKT-10(COOLING PIPIES MTG)	TATA spare parts
410150403339	Z-HOSE	TATA spare parts
410150403341	HOSE PLUG FOR X28.5 PIPE	TATA spare parts
410150405801	MOLDED HOSE HUMP ENGINE TO INTERCOOLER	TATA spare parts
410150508202	FAN SHROUD	TATA spare parts
410154007501	WIRING HARNESS ROUTING RING	TATA spare parts
410154107501	RUBBER GROMMET 24MM	TATA spare parts
410154108202	ATO FUSE MOUNTING BRACKET	TATA spare parts
410154108203	MAXI FUSE MTG BRACKET	TATA spare parts
410154200105	INSTRUMENT CLUSTER MIDLINE HIDECK	TATA spare parts
410154208202	INST. CLUSTER ASSY. MTG. PLATE	TATA spare parts
410154208204	REAR SWITCHES.MTG.BOX WITH PECOSW	TATA spare parts
410154304901	REAR BRAKE PAD WEAR IND	TATA spare parts
410154304902	FRONT AND REAR BRAKE PAD WEAR IND	TATA spare parts
410154500101	REAR ENGINE START SWITCH GREEN	TATA spare parts
410154500102	REAR ENGINE STOP SWITCH RED	TATA spare parts
410154500105	SW. ASSY STG WHEEL PAD M.F.D - DUMMY	TATA spare parts
410154500106	SW. ASSY STG WHEEL PAD AUDIO DUMMY	TATA spare parts
410154500107	REAR ENGINE START SW	TATA spare parts
410154500108	REAR ENGINE STOP SW	TATA spare parts
410154600101	WIPER MOTOR HARNESS	TATA spare parts
410154600104	W/H ENGINE POWER SUPPLY	TATA spare parts
410154600105	W/H ENGINE SIGNAL	TATA spare parts

410154600106	W/H ACCELERATOR PEDAL	TATA spare parts
410154600107	W/H PIG TAIL WITH CAN CONN.FOR ABS ECU	TATA spare parts
410154600109	ALTERNATOR STARTER W/H	TATA spare parts
410154600113	W/H MAIN WITH CONTI.MULTIPLEX SYSTEM	TATA spare parts
410154600114	W/H TAIL WITH CONTI.MULTIPLEX SYSTEM	TATA spare parts
410154600115	W/H BACKBONE WITH CONTI.MULTIPLEX SYSTEM	TATA spare parts
410154600116	POSITIVE SUPPLY CABLE	TATA spare parts
410154600117	MCAN WIRING HARNESS	TATA spare parts
410154600119	WIRING HARNESS FOR FRONT BRAKE PAD WEAR	TATA spare parts
410154600121	WEAR SENSOR CABLE CLOCK WISE	TATA spare parts
410154600122	WEAR SENSOR CABLE COUNTER-CLOCK WISE	TATA spare parts
410158902601	ATTACHMENT GR BOX / LPO1628 DIVO	TATA spare parts
410161507501	GROMMET	TATA spare parts
410166400102	ASSY SEAT BOX	TATA spare parts
410227200103	SLINGER	TATA spare parts
410227203201	BOLT M10X1.5X30LG	TATA spare parts
410227600103	ACCUMULATOR ASSY	TATA spare parts
410227600104	TPS UNIT	TATA spare parts
410227604907	TEMPERATURE GUAGE KIT	TATA spare parts
410241100101	ASSY. PROP. SHAFT COMP. WITH C.B. FRONT	TATA spare parts
410241100102	ASSY. PROP. SHAFT COMP. WITH C.B. MIDDLE	TATA spare parts
410241100103	ASSY. PROP. SHAFT COMP. REAR	TATA spare parts
410241303301	BRACKET (PROP. SHAFT C.B.BKT-1)	TATA spare parts
410241303302	BRACKET (PROP. SHAFT C.B. BKT-2)	TATA spare parts
410242600101	BRACKET RETARDER SWITCH	TATA spare parts
410242609901	MOUNTING BLOCK (RETARDER CONTROL SWITCH)	TATA spare parts
410242900129	ASSY 15 DIA PIPE FOR DDU ARRANGEMENT	TATA spare parts
410242900130	SY 15 DIA PIPE FOR DDU ARRANGEMENT	TATA spare parts
410243200101	ASSY AIR TANK 30 LIT.(VOSS COMP.)	TATA spare parts
410243200102	ASSY AIR TANK 30 LIT.(VOSS COMP.)	TATA spare parts
410243200103	ASSY AIR TANK 20 LIT.(VOSS COMP.)	TATA spare parts
410250105801	RUBBER HOSE - RADIATOR OUTLET	TATA spare parts
410250105802	REDUCER HOSE (ON OIL COOLER)	TATA spare parts
410250106903	PIPE (ENGINE OUTLET TO RADIATOR INLET)	TATA spare parts
410254100102	ASSY.BATT.CABLE POSITIVE.	TATA spare parts
410254110102	ASSY. BATT. CABLE NEGATIVE .	TATA spare parts
410254200102	STARTER RELAY COVER	TATA spare parts
410254209904	INSTR.CLUST. LPO1618TC/62	TATA spare parts
410254821602	W/H MAIN -LPO1618 TC/62 AUTO TRANS	TATA spare parts
410254821603	W/H TAIL LPO1618TC/62 AUTO TRANS.	TATA spare parts
410257000101	CENTRALISED LUB. SYS. - KIT	TATA spare parts
410309135801	RUBBER HOSE(INTER COOLER TO AC HEAD)	TATA spare parts
410309139901	ADAPTER M26X1.5	TATA spare parts
410314603801	CAST PIPE INTERCOOLER TO ENGINE	TATA spare parts
410315209901	HIGH TENSION CABLE	TATA spare parts
410324103701	BKT FRT ENG MTG ENG SIDE RH	TATA spare parts
410324200105	BRACKET ASSY ENGINE MTG REAR-LH BS6	TATA spare parts

410324200111	BRACKET ASSY ENGINE MTG REAR-RH BS6	TATA spare parts
410324203201	HEX BOLT M12X1.75X65 (10.9)	TATA spare parts
410324203301	ENGINE MOUNTING BKT RH REAR	TATA spare parts
410324203302	ENGINE MOUNTING BKT LH REAR	TATA spare parts
410324203701	BKT ENG MTG RR LOWER RH	TATA spare parts
410324203702	BKT ENG MTG RR LOWER LH	TATA spare parts
410324203703	BKT ENG MTG RR F/W HSG LH	TATA spare parts
410324203704	BKT ENG MTG RR F/W HSG RH	TATA spare parts
410324203705	ENGINE MOUTING BKT (RH REAR F/W HSG)	TATA spare parts
410324203706	ENGINE MTG BKT (LH REAR F/W HSG)	TATA spare parts
410324203709	ENGINE MTG ASSY REAR-LH BS6	TATA spare parts
410324203710	ENGINE MTG ASSY REAR-RH BS6	TATA spare parts
410326800103	SHIFTER CABLE ASSY 9.6 METER	TATA spare parts
410327000101	ASSY KIT AUTO TRANS	TATA spare parts
410327000106	AUTOMATIC TRANSMISSION ASSY	TATA spare parts
410327000120	ASSY KIT AUTO TRANS	TATA spare parts
410327000124	ASSY KIT AUTO TRANS	TATA spare parts
410327000125	ASSY KIT AUTO TRANS	TATA spare parts
410327000126	TRANSMISSION	TATA spare parts
410327000128	ASSY KIT AUTO TRANS	TATA spare parts
410327000131	KIT FOR T280R WITH 413TC	TATA spare parts
410327000140	ASSY KIT FOR T270R WITH TC 413	TATA spare parts
410327000147	KIT-AUTOMATIC TRANSMISSION BS6	TATA spare parts
410327103201	BOLT TYPE B HEX LOCK	TATA spare parts
410327103704	HOUSING CONVERTER	TATA spare parts
410327103705	STATOR HOUSING	TATA spare parts
410327103706	HOUSING ASSEMBLY-PUMP (STD)	TATA spare parts
410327103707	HOUSING - C4 CL	TATA spare parts
410327103708	HOUSING - C3 CLUTCH	TATA spare parts
410327103709	HOUSING ASSEMBLY - MAIN	TATA spare parts
410327103710	HOUSING ASSEMBLY- RETARDER	TATA spare parts
410327108201	TRANS HOSE HOLDING BRACKET	TATA spare parts
410327200101	TURB. ASM	TATA spare parts
410327200102	STATOR AND CAM ASSY	TATA spare parts
410327200103	MODULE	TATA spare parts
410327200104	DRUM-ROT. CLUTCH	TATA spare parts
410327200111	ROTOR ASSY	TATA spare parts
410327200112	CARRIER-P1	TATA spare parts
410327200113	CARRIERANDBUSHING ASSY P2 CR	TATA spare parts
410327200114	CARRIER P3 (CR RET.)	TATA spare parts
410327200120	ENGINE ADAPTATION KIT	TATA spare parts
410327203001	BALL- 3/4 DIA	TATA spare parts
410327203002	ROLLER- STATOR	TATA spare parts
410327203003	RACE- STATOR	TATA spare parts
410327203101	BEARING ASSY- ROLLER	TATA spare parts
410327203102	BEARING ASSY- THRUST PUMP	TATA spare parts
410327203103	BRG ASM	TATA spare parts

410327203104	CONE AND ROLLER ASSY- BRG	TATA spare parts
410327203105	CUP ROLLER BRG	TATA spare parts
410327203106	BEARING ASSY- THRUST	TATA spare parts
410327203107	BEARING ASSY- THRUST	TATA spare parts
410327203108	BEARING ASSY- THRUST	TATA spare parts
410327203109	BEARING ASSY- THRUST	TATA spare parts
410327203110	BEARING ASSEMBLY P3-CR	TATA spare parts
410327203111	P2 CR PINION BEARING ASSEMBLY	TATA spare parts
410327203112	P1 PINION BEARING ASSEMBLY	TATA spare parts
410327203202	HEX BOLT M12X50	TATA spare parts
410327203203	PIN- SPRING 5 X 45 LG	TATA spare parts
410327203204	BOLT- M10 X 1.5 X 30 LG	TATA spare parts
410327203205	BOLT- M10 X 1.5 X 65 LG	TATA spare parts
410327203206	BOLT- M10 X 1.5 X 90 LG	TATA spare parts
410327203207	BOLT- M10 X 1.5 X 25 LG	TATA spare parts
410327203208	BOLT- M10 X 1.5 X 35 LG	TATA spare parts
410327203209	BOLT- METRIC HVY HEX HD M6 X 1.0 X 60 LG	TATA spare parts
410327203210	BOLT- M6 X 1.0 X 95 LG	TATA spare parts
410327203211	BOLT- M6 X 1.0 X 20 LG	TATA spare parts
410327203212	BOLT- M6X1X30H	TATA spare parts
410327203213	BOLT- M8 X 1.25 X 25 LG	TATA spare parts
410327203214	BOLT- M8 X 1.25 X 90 LG	TATA spare parts
410327203215	BOLT- L HEX FLANGE HEAD M6X1 45 LG	TATA spare parts
410327203216	PIN- SPRING 5 X 55 LG	TATA spare parts
410327203217	BOLT- HEX HD M16 X 2 X 30 LG	TATA spare parts
410327203218	PIN- RET 5 OD X 43 LG	TATA spare parts
410327203219	BOLT T-HEAD M8 X 1.25 X 25	TATA spare parts
410327203220	PIN-RET 2.5 OD X 40 LG	TATA spare parts
410327203222	BOLT - 6-32 X 7/16 T10	TATA spare parts
410327203223	BOLT-M14 X 2.0 X 70 LG	TATA spare parts
410327203224	SHOULDER BOLT	TATA spare parts
410327203225	BOLT-HVYHEXFLGM8X1.25 20LG	TATA spare parts
410327203226	BOLT M10X1.5X100 MM	TATA spare parts
410327203227	BOLT M10X1.5X55 MM	TATA spare parts
410327203228	BOLT-M10X1.5X192 12 PT HEAD	TATA spare parts
410327203229	BOLT-M10X1.5X182.5	TATA spare parts
410327203230	BOLT- M12 X 1.75 X 190 LG	TATA spare parts
410327203231	BOLT - M12 X 1.75 X 130MM	TATA spare parts
410327203232	BOLT - M8 X 1.25 X 65 LG	TATA spare parts
410327203233	PIN - RET 2.5 OD X 46 LG	TATA spare parts
410327203234	BOLT - TIE ROD	TATA spare parts
410327203401	BUSHING-99ID	TATA spare parts
410327203402	BUSHING-68ID	TATA spare parts
410327203403	BUSHING-45ID	TATA spare parts
410327203404	BUSHING TORQUE	TATA spare parts
410327203405	BUSHING - GEROTOR PUMP	TATA spare parts
410327203406	BUSHING - SHAFT	TATA spare parts



410327203407	BUSHING CONVERTOR COVER	TATA spare parts
410327204301	CLIP - VALVE STOP	TATA spare parts
410327204302	CLIP- RETAINING KNOB	TATA spare parts
410327204601	COUPLING FLANGE TRANS OUTPUT	TATA spare parts
410327204701	COVER FILTER	TATA spare parts
410327204702	CAP-CYLINDER END (HYDRAULIC)	TATA spare parts
410327204703	CAP-CYLINDER END (GAS)	TATA spare parts
410327204704	COVER ASSY - BUSHING	TATA spare parts
410327204705	COVER-RET HSG	TATA spare parts
410327204706	INC COVER SENSOR SHIPPINGINC	TATA spare parts
410327204707	COVER OUT PUT SHIPPING	TATA spare parts
410327204801	PIN-DOWEL 10 X 50 LG	TATA spare parts
410327204802	PIN- DOWEL 10 X 32 LG	TATA spare parts
410327204803	DOWEL PIN	TATA spare parts
410327204804	PIN - DOWEL	TATA spare parts
410327205301	INC GASKET CASEINC	TATA spare parts
410327205302	GASKET CONVERTER HOUSING	TATA spare parts
410327205303	GASKET FILTER COVER	TATA spare parts
410327205304	INC GASKET RETARDER HOUSING COVERINC	TATA spare parts
410327205305	INC GASKET RETARDER HOUSINGINC	TATA spare parts
410327205306	INC GASKET JUMPER MANIFOLDINC	TATA spare parts
410327205307	INC GASKET SUCTION FILTERINC	TATA spare parts
410327205308	GASKET STATOR HOUSING	TATA spare parts
410327205309	GASKET - MD CHANNEL PLATE	TATA spare parts
410327205310	GASKET - CHANNEL PLATE MD6	TATA spare parts
410327205401	GEAR SET-PINION 3000 P2CR/EV DRIVE P1/P2	TATA spare parts
410327205402	GEAR ASSY- MATCHED(6)	TATA spare parts
410327205403	GEAR- P2 SUN	TATA spare parts
410327205404	GEAR- P3 SUN	TATA spare parts
410327205405	GEAR SET- MATCHED(4)	TATA spare parts
410327205406	GEAR- P2 PLNT RING	TATA spare parts
410327205407	GEAR- P3 PLNT RING	TATA spare parts
410327205408	GEAR ASSY- SUN (COMPL)	TATA spare parts
410327205409	RING-INDEXING P1	TATA spare parts
410327205410	RING-INDEXING P2/P3 WR	TATA spare parts
410327205411	RING-INDEXING P3 CR	TATA spare parts
410327205412	GEAR SET ASSY	TATA spare parts
410327205413	MD P1 RING GEAR	TATA spare parts
410327205414	GEAR ADAPTER ASSY	TATA spare parts
410327205415	RING GEAR	TATA spare parts
410327205501	HUB-C1 DRIVE	TATA spare parts
410327205502	HUB - C2 DRIVE	TATA spare parts
410327205503	HUB ASSY-ROT CL(COMPLETE)	TATA spare parts
410327205601	KNOB ASSY.- LSS FRONT FACING	TATA spare parts
410327206001	LINK SLIP - THROTTLE SEN	TATA spare parts
410327206002	LEVER	TATA spare parts
410327206003	BEZEL LEVER RIGHT	TATA spare parts

410327206004	LEVER ASSY 5LLRF	TATA spare parts
410327206501	NUT	TATA spare parts
410327206502	NUT - OUTPUT	TATA spare parts
410327206601	PISTON BALANCE ROTATING CLUTCH	TATA spare parts
410327206602	PISTON-C2	TATA spare parts
410327206603	PISTON CLUTCH	TATA spare parts
410327206604	PISTON	TATA spare parts
410327206605	PISTON C1	TATA spare parts
410327206606	PISTON - LOCKUP (MACHINING)	TATA spare parts
410327206607	PISTON C1	TATA spare parts
410327206608	PISTON BALANCE	TATA spare parts
410327206609	PISTON C3/C4	TATA spare parts
410327207101	PLATE- CL PRESSURE	TATA spare parts
410327207102	FRONT SUPPORT	TATA spare parts
410327207104	PLATE ASSY- STATOR THRUST	TATA spare parts
410327207105	PLATE- WEAR	TATA spare parts
410327207106	PLATE- LU CL BACKING (MAC	TATA spare parts
410327207107	PLATE- STIFFENING	TATA spare parts
410327207108	PLATE CHANNEL	TATA spare parts
410327207109	PLATE-APPLY C1	TATA spare parts
410327207110	PLATE RETAINING	TATA spare parts
410327207111	PLATE - CL FRICTION C1	TATA spare parts
410327207112	PLATE-FRICTION C2	TATA spare parts
410327207113	PLATE FRICTION C3/C4	TATA spare parts
410327207114	PLATE - FRICTION C5	TATA spare parts
410327207115	PLATE-REACTION C1	TATA spare parts
410327207116	PLATE-REACTION C2	TATA spare parts
410327207117	PLATE-REACTION C5	TATA spare parts
410327207118	PLATE - THRUST GEAR	TATA spare parts
410327207119	PLATE ASSEMBLY - BACKING	TATA spare parts
410327207120	PLATE-BACKING C1	TATA spare parts
410327207121	PLATE - REACTION C3/C4	TATA spare parts
410327207122	PLATE ASSY-PISTON RET C3/C4	TATA spare parts
410327207123	PLATE - RETARDER SEPARATOR	TATA spare parts
410327207124	PLATE - SEPARATOR	TATA spare parts
410327207125	PLATE - CHANNEL	TATA spare parts
410327207126	PLATE - SEPARATOR SOLENOID	TATA spare parts
410327207127	PLATE-IDENTIFICATION	TATA spare parts
410327207128	PLATE - IDENTIFICATION	TATA spare parts
410327207129	PLATE SEPARATOR	TATA spare parts
410327207201	PLUG ASSY PRESSURE TAP	TATA spare parts
410327207202	PLUG ASSY	TATA spare parts
410327207203	PLUG END CONV	TATA spare parts
410327207204	PLUG- TACHOGRAPH	TATA spare parts
410327207205	PLUG-FLOW VALVE-RET	TATA spare parts
410327207206	PLUG ASSY	TATA spare parts
410327207207	PLUG SHIPPING	TATA spare parts

410327207208	PLUG-OIL FILL HOLE	TATA spare parts
410327207209	PLUG - SV 2 SV 3	TATA spare parts
410327207210	PLUG ASSY OIL DRAIN	TATA spare parts
410327207211	PLUG PILOT THREADED	TATA spare parts
410327207212	PLUG-ACCUMULATOR	TATA spare parts
410327207213	PLUG ASSEMBLY STRAIGHT THREAD O-RING 7	TATA spare parts
410327207901	SHAFT MAIN CR	TATA spare parts
410327207902	SHAFT ASSY TUR.STD	TATA spare parts
410327207903	SPINDLE-P1	TATA spare parts
410327207904	SPINDLE-P2 PLANET CR	TATA spare parts
410327207905	SPINDLE P3 PLANET CR	TATA spare parts
410327207906	SHAFT ASSY OUTPUT	TATA spare parts
410327208001	SCREW	TATA spare parts
410327208002	SCREW - M5 X .08 X 16LG	TATA spare parts
410327208003	SCREW TAPPING M8X25	TATA spare parts
410327208004	SCREW - STOP MOUNTING	TATA spare parts
410327208301	SHIM CONVERTER SELECTIVE 0.715 MM (0.028	TATA spare parts
410327208302	SHIM COVERTER SELECTIVE 0.485 MM (0.019	TATA spare parts
410327208303	SHIM COVERTER SELECTIVE 0.254 MM (0.010	TATA spare parts
410327208304	SHIM SELECTIVE 0.27 MM (0.01 INCH)	TATA spare parts
410327208305	SHIM SELECTIVE 0.54 MM (0.02 INCH)	TATA spare parts
410327208306	SHIM SELECTIVE 0.81 MM (0.03 INCH)	TATA spare parts
410327208307	SHIM SELECTIVE 1.08 MM (0.04 INCH)	TATA spare parts
410327208308	SHIM SELECTIVE 1.35 MM (0.05 INCH)	TATA spare parts
410327208309	SHIM SELECTIVE 1.62 MM (0.06 INCH)	TATA spare parts
410327208310	SHIM SELECTIVE 1.89 MM (0.07 INCH)	TATA spare parts
410327208311	SHIM TURBINE SELECTIVE 4.203 MM (0.165 I	TATA spare parts
410327208312	SHIM TURBINE SELECTIVE 4.381 MM (0.172 I	TATA spare parts
410327208313	SHIM TURBINE SELECTIVE 4.559 MM (0.179 I	TATA spare parts
410327208314	SHIM TURBINE SELECTIVE 4.736 MM (0.186 I	TATA spare parts
410327208315	SHIM TURBINE SELECTIVE 4.914MM (0.193 IN	TATA spare parts
410327208316	SHIM TURBINE SELECTIVE 5.092 MM (0.200 I	TATA spare parts
410327208317	SHIM TURBINE SELECTIVE 4.000 MM (0.157 I	TATA spare parts
410327208401	SLEEVE-GROUND	TATA spare parts
410327208501	TERM-SOCKET	TATA spare parts
410327208601	SPACER- BEARING	TATA spare parts
410327208701	SPRING ASSY- C1 RETURN	TATA spare parts
410327208702	SPRING- 14.1 OD X 42.1 LG	TATA spare parts
410327208703	SPRING- 11.10 OD X 46.3 L	TATA spare parts
410327208704	SPRING- 7.80 OD X 29.2 LG	TATA spare parts
410327208705	SPRING- STATOR	TATA spare parts
410327208706	SPRING- 22 OD X 98.5 LG	TATA spare parts
410327208707	SPRING ASSY- RETURN	TATA spare parts
410327208708	SPRING- 11 OD X 30.3 LG	TATA spare parts
410327208709	SPRING 11.48 ID X 53.20 MM	TATA spare parts
410327208710	RETAINER ASSY-SPRING	TATA spare parts
410327208711	SPRING	TATA spare parts

410327208712	SPRING DETENT	TATA spare parts
410327208713	SPRING	TATA spare parts
410327208714	SPRING - CONTROL MAIN	TATA spare parts
410327208715	SPRING - TCC TRIM	TATA spare parts
410327208716	SPRING - DIAGNOSTIC	TATA spare parts
410327208717	SPRING - LATCH C1/C2	TATA spare parts
410327208718	SPRING - FILTER LIFE 25 PSI	TATA spare parts
410327208719	SPRING - ACCUMULATOR	TATA spare parts
410327208720	SPRING TRIM	TATA spare parts
410327209001	VALVE- LOCKUP	TATA spare parts
410327209002	VALVE LUBE REGULATOR	TATA spare parts
410327209003	VALVE EXHAUST BACK	TATA spare parts
410327209004	STOP- LOCKUP VALVE	TATA spare parts
410327209005	STOP- LUBE RGLTR	TATA spare parts
410327209006	STOP- VALVE	TATA spare parts
410327209007	STOP- MAIN RGLTR	TATA spare parts
410327209008	VALVE- CONVERTER REGULATO	TATA spare parts
410327209009	VALVE-SUMP COOLER AUTOFLO	TATA spare parts
410327209010	INC VALVE REGULATORINC	TATA spare parts
410327209011	INC VALVE RELAYINC	TATA spare parts
410327209012	VALVE - CONTROL MAIN	TATA spare parts
410327209013	VALVE - MAIN REGULATOR	TATA spare parts
410327209014	VALVE - C1 LATCH	TATA spare parts
410327209015	STOP - LATCH	TATA spare parts
410327209016	VALVE - TCC TRIM	TATA spare parts
410327209017	VALVE - CLUTCH TRIM	TATA spare parts
410327209018	VALVE - DIAGNOSTIC	TATA spare parts
410327209019	VALVE - LATCH C2	TATA spare parts
410327209020	BODY - VALVE MAIN	TATA spare parts
410327209021	VALVE - FILTER LIFE	TATA spare parts
410327209022	STOP - CONVERTER REGULATOR	TATA spare parts
410327209023	BODY - VALVE MAIN	TATA spare parts
410327209202	WASHER-STATOR THRUST FRNT	TATA spare parts
410327209203	WASHER	TATA spare parts
410327209204	WASHER-THRUST P2/EV P1/P2	TATA spare parts
410327209205	WASHER- P1 THRUST	TATA spare parts
410327209206	WASHER-TANGED THRST BRG 2	TATA spare parts
410327209207	WASHER - M5 FLAT	TATA spare parts
410327209208	P3 THRUST WASHER	TATA spare parts
410327209209	WASHER- PLUG TACHOGRAPH	TATA spare parts
410327209210	WASHER OUTPUT BELLEVILLE	TATA spare parts
410327400102	FLEX PLATE ASSY BS6	TATA spare parts
410327403201	BOLT BS6	TATA spare parts
410327405503	ADAPTER HUB BS6	TATA spare parts
410327405504	ADAPTER FLEX PLATE BS6	TATA spare parts
410327407102	WEAR PLATE BS6	TATA spare parts
410327407103	FLEX PLATE BS6	TATA spare parts

410327408601	SPACER HOUSING TRANSMISSION BS6	TATA spare parts
410327600119	OIL COOLER ELEMENT	TATA spare parts
410327600120	HOSE TRANS. TO COOLER(2400)	TATA spare parts
410327600121	HOSE COOLER TO TRANS (2500MM)	TATA spare parts
410327600128	TRASMISSION HOSE 1160 MM	TATA spare parts
410327600129	TRASMISSION HOSE 850 MM	TATA spare parts
410327600131	HOSE RETARDER (650MM - 45DEG)	TATA spare parts
410327600133	VENT ASSY- OIL	TATA spare parts
410327600139	HOSE ASSY OIL COOLER TO TRANSMISSION	TATA spare parts
410327600144	HOSE ASSY OILCOOLER BS6	TATA spare parts
410327603301	BASE PLATE GEAR SHIFT PUSH BUTTON	TATA spare parts
410327604923	PRESSURE SWITCH 2PSI	TATA spare parts
410327604924	PRESSURE SWITCH 10PSI	TATA spare parts
410327604925	RESISTANCE MODULE 3 STEP APPLY AUTOMATIC	TATA spare parts
410327604930	TCM CALIBRATED	TATA spare parts
410327604939	TRANSMISSION CONTROL MODULE CALIBRATED	TATA spare parts
410327604941	PRESSURE SWITCH 7 PSI.	TATA spare parts
410327604944	HARNESS-MD GEN4	TATA spare parts
410327604945	HARNESS-TCM	TATA spare parts
410327604947	INC SENSOR TEMPERATURE (OLD T)INC	TATA spare parts
410327604948	INC SENSOR ASSEMBLY TEMPERATUREINC	TATA spare parts
410327604949	RETARDER SOLENOID CONNECTOR	TATA spare parts
410327604950	CONNECTOR ACCUMULATOR	TATA spare parts
410327604951	CONNECTOR SHO 3-WAY	TATA spare parts
410327604952	SEAL-CONNECTOR	TATA spare parts
410327604953	CONNECTOR - 2-WAY	TATA spare parts
410327604954	LOCK	TATA spare parts
410327604955	TERMINAL-FEM	TATA spare parts
410327604956	LOCK - SECONDARY	TATA spare parts
410327604957	CONNECTOR	TATA spare parts
410327604958	TERMINAL	TATA spare parts
410327604959	CONNECTOR	TATA spare parts
410327604960	TERMINAL - FEMALE	TATA spare parts
410327604961	TERMINAL FEM	TATA spare parts
410327604962	CONNECTOR SE	TATA spare parts
410327604963	CONNECTOR	TATA spare parts
410327604964	INC RETAINER SPEED SENSORINC	TATA spare parts
410327604965	RESISTOR 24V TEMPRATURE GUAGE	TATA spare parts
410327604966	HARNESS AND SOCKET ASSY	TATA spare parts
410327604967	TEMPRATURE GUAGE BULB	TATA spare parts
410327604968	INIDICATOR OIL LEVEL	TATA spare parts
410327604969	SWITCH	TATA spare parts
410327604970	TEMP. GAGE	TATA spare parts
410327604971	SENSOR ASSY- TPS CH58X	TATA spare parts
410327604972	VIM - 24V	TATA spare parts
410327604973	CONNECTOR	TATA spare parts
410327604974	RELAY-24 VOLT	TATA spare parts

410327604975	MANIFOLD-JUMPER	TATA spare parts
410327604976	CONNECTOR - 2 WAY 280 M/P	TATA spare parts
410327604977	TEMP. SENSOR - ENGINE WATER	TATA spare parts
410327604978	SENSOR ASSEMBLY-SPEED ROTATIONAL	TATA spare parts
410327604979	SENSOR TURBINE SPEED	TATA spare parts
410327604980	SENSOR ASSY SPEED RETARDER	TATA spare parts
410327604981	INC CAP. INTERNAL HARNESS 20WINC	TATA spare parts
410327604982	SOLENOID - CENL VBS	TATA spare parts
410327604983	TCM	TATA spare parts
410327604984	SOLENOID ASSEMBLY - FORWARD	TATA spare parts
410327604985	SWITCH ASSY PRESSURE	TATA spare parts
410327604986	HARNESS INTERNAL	TATA spare parts
410327604987	INT HARNESS	TATA spare parts
410327604988	SWITCH ASSEMBLY PRESSURE	TATA spare parts
410327604989	SENSOR ASSEMBLY - OIL LEVEL	TATA spare parts
410327604990	SENSOR ASSY OIL	TATA spare parts
410327604991	HARNESS TCM	TATA spare parts
410327604992	GPVI HARNESS	TATA spare parts
410327604998	TRANS. CONTROL MODULE LPO 1924 EURO3	TATA spare parts
410327606009	COMMOM PB SHIFT SELECTOR	TATA spare parts
410327606802	CONNECTOR STRAIGHT TRANS	TATA spare parts
410327606807	CONNECTOR ELBOW	TATA spare parts
410327606816	NIPPLE- AUTOMOTIVE PIPE	TATA spare parts
410327606817	FERRULE - ONE PIECE	TATA spare parts
410327606901	TUBE- OIL FILL	TATA spare parts
410327607201	SCREW PLUG 0.125-27 NPT (MALE)	TATA spare parts
410327607701	SEAL-O-RING	TATA spare parts
410327607702	PACKING O RING	TATA spare parts
410327607703	INC O-RING 16.4 MM IDINC	TATA spare parts
410327607704	PACKING- O RING .299 ID	TATA spare parts
410327607705	PACKING- O RING 8.92 ID	TATA spare parts
410327607706	INC SEALRING EXTERNALINC	TATA spare parts
410327607707	RING- RET EXT 104 DIA	TATA spare parts
410327607708	PACKING- O RING 25.1 ID	TATA spare parts
410327607709	RING- RET INT 281 DIA	TATA spare parts
410327607710	SEAL - FACE	TATA spare parts
410327607711	PACKING- O RING 11.48 ID	TATA spare parts
410327607712	PACKING- O RING 110 ID	TATA spare parts
410327607713	PACKING- O RING 368.8 ID	TATA spare parts
410327607714	SEAL RING	TATA spare parts
410327607715	RING- RET INT 159.2 DIA	TATA spare parts
410327607716	RING- RET INT 190.2 DIA	TATA spare parts
410327607717	INC O-RING 66.3 MM IDINC	TATA spare parts
410327607718	O-RING UNIFORM NO. -126	TATA spare parts
410327607719	RING- RET INT 45.82 OD	TATA spare parts
410327607720	RING- RETAINING	TATA spare parts
410327607721	PACKING-O-RING 13.82 ID	TATA spare parts

410327607722	PACKING-O-RING 15.37 ID	TATA spare parts
410327607723	PACKING-O-RING 18.54 MM I	TATA spare parts
410327607724	SEALRING- ROTATING	TATA spare parts
410327607725	SEAL QUAD RING	TATA spare parts
410327607726	RING- RET EXT 48 DIA	TATA spare parts
410327607727	PACKING O RING	TATA spare parts
410327607728	SEALRING-INT 140 DIA	TATA spare parts
410327607729	O RING	TATA spare parts
410327607730	INC O-RING 12.3 MM IDINC	TATA spare parts
410327607731	RING-RET EXT 128 DIA	TATA spare parts
410327607732	SEAL-LIP	TATA spare parts
410327607733	RING	TATA spare parts
410327607734	SEAL-END CAP	TATA spare parts
410327607735	ORING SOLENOID	TATA spare parts
410327607736	RING-RETAINING EXT	TATA spare parts
410327607737	SNAPRING	TATA spare parts
410327607738	SEAL - WT HARNESS STANDOFF	TATA spare parts
410327607739	ORING - PACKING 10.65 ID	TATA spare parts
410327607740	SEAL-FACE	TATA spare parts
410327607741	ORING	TATA spare parts
410327607742	SEALRING - PISTON (SEE CHART 23046404)	TATA spare parts
410327607743	SEALRING - PISTON (SEE CHART 23046404)	TATA spare parts
410327607744	SEALRING - PISTON (SEE CHART 23046404)	TATA spare parts
410327607745	SEALRING - PISTON	TATA spare parts
410327607746	SEALRING - PISTON	TATA spare parts
410327607747	SEALRING - PISTON	TATA spare parts
410327607748	SEALRING - PISTON (SEE CHART 23046404)	TATA spare parts
410327607749	SEAL - FILL TUBE	TATA spare parts
410327607750	SEAL ASSEMBLY - OUTPUT	TATA spare parts
410327607751	O-RING 85.3 MM ID	TATA spare parts
410327607801	SEAL - DUST/DIRT	TATA spare parts
410327607802	SEAL ASSEMBLY - OIL	TATA spare parts
410327607803	SEAL ASSEMBLY - OIL	TATA spare parts
410327609901	INC SOLENOID PCS1 VARIABLE BLEED CENH	TATA spare parts
410327609902	LABEL - MODE DISPLAY DUA	TATA spare parts
410327609903	SOLENOID & CONNECTION ASSY.	TATA spare parts
410327609904	BODY ASSEMBLY -PIN/SOLENOID	TATA spare parts
410327609905	BODY - RETARDER CONTROL	TATA spare parts
410327609906	SUCTION FILTER AND SEAL ASSY	TATA spare parts
410327609907	DAMPER ASSEMBLY - COMPLETE	TATA spare parts
410327609908	BODY - CYLINDER	TATA spare parts
410327609909	BODY FILTER LIFE	TATA spare parts
410327609910	SOLENOID	TATA spare parts
410327609911	PIN/SOLENOID BODY	TATA spare parts
410327609912	SUCTION FILTER & SEAL ASSY	TATA spare parts
410327706002	ASSY SHIFT SELECTOR 1-5LRRF	TATA spare parts
410327800101	ASSY MTG BKT TRANS OIL COOLER (AL)	TATA spare parts

410327800104	ASSY. ACCOMULATOR MTG BKT FRONT	TATA spare parts
410327800105	ASSY BRACKET (TRANS. HOSE)	TATA spare parts
410327800106	ASSY MTG BKT TRANS OIL COOLER	TATA spare parts
410327800108	BRACKET-OIL FILL TUBE	TATA spare parts
410327800109	BRACKET-CONV SHIPPING	TATA spare parts
410327800112	BRACKET OIL COOLER ASSY	TATA spare parts
410327800115	BRACKET ASSY OIL COOLER MTG BS6	TATA spare parts
410327803202	BOLT -ç ACCUMLATOR	TATA spare parts
410327803301	TNANSMISSION HOSE MTG BKT	TATA spare parts
410327803304	TRANS HOSE HOLDING BRKT	TATA spare parts
410327803308	INC BRACKET TEMPERATURE SENSORINC	TATA spare parts
410327803309	BRACKET - SOLENOID RIGHT SIDE	TATA spare parts
410327803310	CHANNEL ASSEMBLY	TATA spare parts
410327803311	ACCUMULATOR MTG BKT REAR	TATA spare parts
410327803312	BRACKET ACCUMULATOR MTG REAR BS6	TATA spare parts
410327807124	BRACKET BS6	TATA spare parts
410327808207	SHIELD OIL-COOLER (RADIATOR COMPARTMENT)	TATA spare parts
410327808209	SHIELD OIL COOLER BS6	TATA spare parts
410327900102	ASSY MTG BRACKET (OIL COOLER)	TATA spare parts
410327900103	PUMP ASSY CONVERTER COMPLETE	TATA spare parts
410327900104	PUMP ASSY-CO	TATA spare parts
410327900105	PUMP - ASSY.	TATA spare parts
410327990102	ASSY KIT AUTO TRANS T-270R(ALLISON)	TATA spare parts
410327990107	ASSY KIT AUTO TRANS	TATA spare parts
410327990112	KIT-TRANSMISSION FLUID SAMPLING AND ANAL	TATA spare parts
410327990113	KIT - FILTER ASSEMBLY SUCTION	TATA spare parts
410327990144	UNCALIBRATED TCM	TATA spare parts
410327990151	VENT ASSEMBLY OIL .	TATA spare parts
410327993202	OUTPUT FLANGE RETAINER BOLTS KIT	TATA spare parts
410327993401	INC BUSHING GEAR SET(SEE SIL 28-WT-94)I	TATA spare parts
410327994901	KIT GT 150 SPEED SENSOR	TATA spare parts
410327994902	TEMP. GUAGE - KIT	TATA spare parts
410327994903	HARNESS-CONNECTOR SERVICE KIT -2M 90 DEG	TATA spare parts
410327994904	VIWX HARNESS KIT	TATA spare parts
410327994906	OIL LEVEL INDICATOR	TATA spare parts
410327996601	KIT C1 BALANCE PISTON	TATA spare parts
410327996602	PISTON CLUTCH	TATA spare parts
410327996801	TRANSMISSION MAIN CONNECTOR UPDATE KIT	TATA spare parts
410327997701	INC SEALRING KIT EXTERNALINC	TATA spare parts
410327997702	KIT-SEALRING	TATA spare parts
410327997703	KIT-SEALRING	TATA spare parts
410327997704	KIT CONROL MODULE SEAL & GASKET	TATA spare parts
410327997705	KIT - SEAL & GASKET RETARDER	TATA spare parts
410327997706	KIT-SEAL AND GASKET 3000 CONT. MOD	TATA spare parts
410327997707	KIT - SEAL AND GASKET STRAIGHT-THRU	TATA spare parts
410327997708	ACCUMULATOR SEAL KIT	TATA spare parts
410327997710	KIT SEAL& GASKET CONTROL MODULE	TATA spare parts



410327998301	KIT-SHIM	TATA spare parts
410327998302	KIT SHIM	TATA spare parts
410327998601	KIT-SPACER	TATA spare parts
410327999001	KIT - MAIN VALVE BODY 6 SPEED	TATA spare parts
410327999902	MASTER OVERHAUL KIT	TATA spare parts
410327999903	KIT-SEAL AND GASKET MD CONT. MOD. (91 CN	TATA spare parts
410327999904	KIT-FILTER BS3/4	TATA spare parts
410329100116	ASSY PIPE 5TH	TATA spare parts
410329100117	ASSY PIPE 4TH	TATA spare parts
410330100101	ASSY ACCELETOR PEDAL UNIT	TATA spare parts
410330100102	ASSY ACC PADEL MTG BKT	TATA spare parts
410330100105	ASSY BELL CRANK WITH BUSH	TATA spare parts
410330100106	ASSY BKT ACC. CABLE(MTG ENGINE END)	TATA spare parts
410330100107	ASSY BRACKET (ON ENGINE)	TATA spare parts
410330100108	THRUST ROD	TATA spare parts
410330100111	ASSY BRACKET FOR MOUNTING TPS CABLE	TATA spare parts
410330100112	ASSY LEVER	TATA spare parts
410330100113	BRACKET ASSY-ACCELERATOR MTG BS6	TATA spare parts
410330100114	ASSY CABLE ACCELERATOR	TATA spare parts
410330100117	ASSY ACC CABLE (EXCEL)	TATA spare parts
410330100126	ASSY LEVER	TATA spare parts
410330100130	ASSY LOCK PLATE	TATA spare parts
410330100131	ASSY ACCELERATOR CABLE ON ENGINE	TATA spare parts
410330100135	ASSY ACC MTG BKT (ENGINE END)	TATA spare parts
410330100137	ASSY MTG PLATE (FOR SPEED LIMITER)	TATA spare parts
410330100151	ASSY ACCELETOR PEDAL UNIT	TATA spare parts
410330103305	BRACKET FOR TPS MOUNTING	TATA spare parts
410330103307	BRACKET FOOTREST MTG	TATA spare parts
410330103310	BRACKET(STOPPER ACC.PEDAL)	TATA spare parts
410330103320	BRACKET (FOR MTG TPS AND FLEX CABLE)	TATA spare parts
410330106701	PIN	TATA spare parts
410331000111	ASSY FRAME COMPLETE	TATA spare parts
410331000132	ASSY FRAME COMPLETE-REAR MODULE	TATA spare parts
410331000150	ASSY FRAME FRONT MODULE	TATA spare parts
410331000151	ASSY REAR MODULE-FRAME ASSY LPO1623 RELE	TATA spare parts
410331000153	ASSY FRAME COMPLETE - REAR MODULE	TATA spare parts
410331000154	FRONT FRAME	TATA spare parts
410331000158	FRAME ASSY WITH FRONT STRUCTURE BS6	TATA spare parts
410331000161	FRAME ASSY REAR MODULE BS6	TATA spare parts
410331100125	ASSY REAR ENG MTG BKT RH INNER	TATA spare parts
410331100142	ASSY SUPPORT CENTER RH	TATA spare parts
410331100145	ASSY SUPPORT RH BELLOW MTG BRACKET	TATA spare parts
410331100148	ASSY SUPPORT RH BELLOW MTG BRACKET	TATA spare parts
410331100149	ASSY SUPPORT LH BELLOW MTG BRACKET	TATA spare parts
410331100185	ASSY HEAT SHIELD ( FOR AIR DRYER )	TATA spare parts
410331100211	ASSY REINFORCEMENT BLOCK	TATA spare parts
410331100218	ASSY MGT FOR PARALLEL ROD	TATA spare parts

410331105101	BRACKET EV	TATA spare parts
410331107115	REINFORCEMENT BKT FOR REAR ENGINE MTG RH	TATA spare parts
410331107116	REINFORCEMENT BKT FOR REAR ENGINE MTG RH	TATA spare parts
410331107152	REINFORCEMENT BKT FOR REAR ENGINE MTG RH	TATA spare parts
410331107153	REINFORCEMENT BKT FOR REAR ENGINE MTG LH	TATA spare parts
410331107159	REAR VERTICAL CONNECTION LONG MEMBER(RH)	TATA spare parts
410331107160	REAR VERTICAL CONNECTION LONG MEMBER(LH)	TATA spare parts
410331107166	REAR VERTICAL CONNECTION LONG MEMBER(RH)	TATA spare parts
410331107167	REAR VERTICAL CONNECTION LONG MEMBER(LH)	TATA spare parts
410331107181	HEAT SHIELD MOUNTING BRACKET	TATA spare parts
410331117127	PLATE ( FRAME JOINERY)	TATA spare parts
410331117128	C CHANNEL ( OUTER)	TATA spare parts
410331117129	C CHANNEL ( INNER)	TATA spare parts
410331117138	C CHANNEL 25X140X5 (430 LONG)	TATA spare parts
410331117139	C CHANNEL 25X140X5 (595 LONG)	TATA spare parts
410331117142	REINFORCEMENT (REAR ARB MTG BKT)	TATA spare parts
410331117143	REINFORCEMENT LH (REAR ARB MTG BKT)	TATA spare parts
410331117144	REINFORCEMENT-RH (TOP)	TATA spare parts
410331117145	REINFORCEMENT-LH (TOP)	TATA spare parts
410331117146	REINFORCEMENT REAR RH (BOTTOM)	TATA spare parts
410331117147	REINFORCEMENT REAR LH (BOTTOM)	TATA spare parts
410331117155	C-FLITCH FRONT LH	TATA spare parts
410331117156	C-FLITCH FRONT RH	TATA spare parts
410331200105	ASSY BELLOW MTG BKT RH (FRONT MODULE)	TATA spare parts
410331200106	ASSY BELLOW MTG BKT LH (FRONT MODULE)	TATA spare parts
410331200109	AIR BELLOW & SHOCK ABSORBER MTG BKT - RH	TATA spare parts
410331200110	AIR BELLOW & SHOCK ABSORBER MTG BKT - LH	TATA spare parts
410331200114	ASSY SUPPORT REAR	TATA spare parts
410331200115	ASSY SUPPROT FRONT	TATA spare parts
410331200116	ASSY CROSS MEMBER (4TH 5TH AND 6TH)	TATA spare parts
410331200119	ASSY CONNECTING BRACKET RH (LONGMEMBER)	TATA spare parts
410331200120	ASSY CONNECTING BRACKET LH (LONGMEMBER)	TATA spare parts
410331200123	ASSY V ROD MTG BRACKET RH	TATA spare parts
410331200124	ASSY V ROD MTG BRACKET LH	TATA spare parts
410331200128	ASSY FRT BUMPER WITH TOW HOOK MTG	TATA spare parts
410331200130	ASSY V-ROD CROSS MEMBER	TATA spare parts
410331200136	END PIECE (RH) VERTICAL	TATA spare parts
410331200137	END PIECE (LH) VERTICAL	TATA spare parts
410331200139	ASSY. CROSS MEMBER.(7TH)	TATA spare parts
410331200140	ASSY FRONT OUTRIGGER RH	TATA spare parts
410331200141	ASSY FRONT OUTTRIGER LH	TATA spare parts
410331200142	.ASSY REAR OUTRIGGER RH	TATA spare parts
410331200143	ASSY REAR OUTRIGGER LH	TATA spare parts
410331200147	ASSY MTG BKT (CROSS MEMBER)	TATA spare parts
410331200148	ASSY FRT BUMPER WITH TOW HOOK MTG	TATA spare parts
410331200157	REINFORCEMENT RH (CROSS MEMBER)	TATA spare parts
410331200158	REINFORCEMENT LH (CROSS MEMBER)	TATA spare parts

410331200180	ASSY. OUTRIGGER FOR BRAKE ACTUATION VALV	TATA spare parts
410331200182	ASSY FRONT BUMPER (WITH TOE HOOK MTG)	TATA spare parts
410331200183	ASSY BEVEL GEAR-BOX MTG BKT	TATA spare parts
410331200216	ASSY CROSS MEMBER	TATA spare parts
410331200217	ASSY CROSS MEMBER (KNEELING)	TATA spare parts
410331200225	ASSY OUTRIGGER	TATA spare parts
410331200226	ASSY OUTRIGGER	TATA spare parts
410331200228	ASSY END C/M (FRNT MODULE)	TATA spare parts
410331200231	ASSY SUPPORT BKT - RH	TATA spare parts
410331200232	ASSY SUPPORT BKT - LH	TATA spare parts
410331200233	ASSY FRONT BLOCK	TATA spare parts
410331200234	ASSY PARALLEL ROD MTG BKT RH	TATA spare parts
410331200235	ASSY PARALLEL ROD MTG BKT LH	TATA spare parts
410331200238	ASSY BELLOW MTG BKT - RH (FRONT FRAME)	TATA spare parts
410331200239	ASSY BELLOW MTG BKT - LH (FRONT FRAME)	TATA spare parts
410331200242	ASSY REINF LH(FRONT AND MIDDLE LM JOINT)	TATA spare parts
410331200245	ASSY. FRONT OUTRIGGER (LH)	TATA spare parts
410331200247	ASSY. FRONT OUTRIGGER (RH)	TATA spare parts
410331200249	ASSY MTG BKT (CROSS MEMBER -3)	TATA spare parts
410331200256	ASSY SUPPORT BKT RH(ENGINE C/M)	TATA spare parts
410331200257	ASSY SUPPORT BRACKET LH (ENGINE C/M)	TATA spare parts
410331200263	ASSY SUPPORT BKT (ENGINE C/M)	TATA spare parts
410331200265	SUPPORT ASSY ENGINE CROSS MEMBER BS6	TATA spare parts
410331200267	END CROSS MEMBER ASSY-FRONT MODULE BS6	TATA spare parts
410331200268	OUTRIGGER ASSY FRONT WHEEL ARC LH BS6	TATA spare parts
410331200269	OUTRIGGER ASSY FRONT WHEEL ARC RH BS6	TATA spare parts
410331200273	CROSS MEMBER ASSY WITH TOW HOOK FRONT B	TATA spare parts
410331200274	OUTRIGGER ASSY BS6	TATA spare parts
410331200320	AIR BELLOW & SHOCK ABSORBER MTG BKT-LH	TATA spare parts
410331200322	ASSY LONG MEMBER ATTACHMENT	TATA spare parts
410331200323	ASSY OUTRIGGER REAR	TATA spare parts
410331200324	ASSY BELLOW MTG BKT RH (FRT MOD)	TATA spare parts
410331200325	ASSY 2ND CROSS MEMBER	TATA spare parts
410331200326	ASSY BEVEL GEAR BOX <sub>2</sub> MTG <sub>2</sub> BRKT	TATA spare parts
410331200328	ASSY VERTICAL SUPPORT BRKT-3	TATA spare parts
410331200329	ASSY REAR OUTRIGGER	TATA spare parts
410331200330	SIDE BOX FOR MTG BKT	TATA spare parts
410331200331	ASSEMBLY CHANNEL	TATA spare parts
410331200332	ASSEMBLY CHANNEL	TATA spare parts
410331206903	SUPPORT TUBE	TATA spare parts
410331206904	SUPPORT TUBE	TATA spare parts
410331206905	SUPPORT TUBE	TATA spare parts
410331207130	SUPPROT BOTTOM	TATA spare parts
410331207134	CONNECTING BRACKET OUTER (LONGMEMBER R	TATA spare parts
410331207135	CONNECTING BRACKET OUTER(LONGMEMBER LH	TATA spare parts
410331207136	CONNECTING BRACKET INNER LONGMEMBER RH	TATA spare parts
410331207137	CONNECTING BRACKET INEER LONGMEMBER LH	TATA spare parts

410331207140	CONNECTOR PLATE	TATA spare parts
410331207143	C CHANNEL (2ND)	TATA spare parts
410331207144	REINFORCEMENT RH	TATA spare parts
410331207145	REINFORCEMENT LH	TATA spare parts
410331207147	REINFORCEMENT FRONT RH	TATA spare parts
410331207148	REINFROCEMENT FRONT LH	TATA spare parts
410331207149	REINFORCEMENT MIDDLE RH	TATA spare parts
410331207150	REINFORCEMENT MIDDLE LH	TATA spare parts
410331207153	REINFORCEMENT RH	TATA spare parts
410331207154	REINFORCEMENT LH	TATA spare parts
410331207160	V ROD MTG BLOCK - 1 FRONT RH	TATA spare parts
410331207161	V ROD MTG BLOCK -2 FRONT RH	TATA spare parts
410331207162	REINFORCEMENT PLATE-I V-ROD MTG FRT RH	TATA spare parts
410331207163	REINFORCEMENT PLATE -II V-ROD MTG FRT RH	TATA spare parts
410331207164	V-ROD MTG BLOCK-I FRT LH	TATA spare parts
410331207166	V-ROD MTG BLOCK-2 FRONT LH	TATA spare parts
410331207167	REINFORCEMENT PLATE-I V-ROD MTG FRT LH	TATA spare parts
410331207168	REINFORCEMENT PLATE-II V-ROD MTG FRT LH	TATA spare parts
410331207170	SUPPORT (3RD CORSS MEMBER)	TATA spare parts
410331207172	PARALLEL ROD MTG BKT SUPPORT	TATA spare parts
410331207185	CONNECTOR PLATE BOTTOM	TATA spare parts
410331208205	STIFFENER RH	TATA spare parts
410331208206	STIFFENER LH	TATA spare parts
410331208217	CROSS MEMBER	TATA spare parts
410331210101	SUPPORT BRACKET ASSY,ENGINE SIDE,RH	TATA spare parts
410331210102	SUPPORT BRACKET ASSY,ENGINE SIDE,LH	TATA spare parts
410331210105	KNEELING CROSS MEMBER ASSY BS6	TATA spare parts
410331217106	PLATE (BODY OUTRIGGER)	TATA spare parts
410331217115	BRACKET (FOR AIR TANK MTG ON L/M)	TATA spare parts
410331217157	SHIM	TATA spare parts
410331217173	SUPPORT TOP - RH (CM)	TATA spare parts
410331217174	SUPPORT TOP - LH (CM)	TATA spare parts
410331217175	PARALLEL ROD MTG. BKT.	TATA spare parts
410331217180	PLATE - I (BODY CONNECTION)	TATA spare parts
410331217181	PLATE - II (BODY CONNECTION)	TATA spare parts
410331217182	PLATE - III (BODY CONNECTION)	TATA spare parts
410331217183	C-CHANNEL RH (FRONT LM JOINT)	TATA spare parts
410331217185	REINFORCEMENT	TATA spare parts
410331217186	REINFORCEMENT - LH (3RD CM)	TATA spare parts
410331217195	V ROD MTG BLOCK FRONT RH	TATA spare parts
410331217196	V ROD MTG BLOCK FRONT LH	TATA spare parts
410331300103	BUMPER & LONG MEM. GUSSET	TATA spare parts
410331300128	ASSY OUTRIGGER RH (FOR REAR JACK POINT)	TATA spare parts
410331300129	ASSY OUOTRIGGER LH (FOR REAR JACK POINT)	TATA spare parts
410331300135	ASSY V ROD MGT	TATA spare parts
410331300136	ASSY SGT MGT	TATA spare parts
410331300143	ASSY V-ROD CM	TATA spare parts

410331303307	SPACER	TATA spare parts
410331305101	V ROD MGT BRKT RH	TATA spare parts
410331307155	V ROD MGT BRKT	TATA spare parts
410331307161	SUPPORT PLATE	TATA spare parts
410331307163	SUPPORT PLATE	TATA spare parts
410331308211	REINFORCEMENT TOW HOOK REAR BS6	TATA spare parts
410331317101	REINFORCEMENT RH	TATA spare parts
410331317102	REINFORCEMENT LH	TATA spare parts
410331317107	PLATE (BODY OUTRIGGER)	TATA spare parts
410331505101	TOW HOOK HOLDING BLOCK (REAR MODULE)	TATA spare parts
410331505103	TOWING HOOK	TATA spare parts
410331700102	ASSY BRACKET RH FOR HEAD LAMP MTG	TATA spare parts
410331700103	ASSY BRACKET LH FOR HEAD LAMP MTG	TATA spare parts
410331700104	CROSS BEAM SUPPORT	TATA spare parts
410331700108	ASSY WHEEL ARC MGT	TATA spare parts
410331700109	ASSY WHEEL ARC MGT	TATA spare parts
410331700150	ASSY BKT (FOR TRAY MTG REAR)	TATA spare parts
410331700161	ASSY FRAME CONNECTOR	TATA spare parts
410331700164	ASSY FRAME CONNECTOR	TATA spare parts
410331700165	ASSY SUPPORT BRACKET	TATA spare parts
410331700166	ASSY BRACKET LH	TATA spare parts
410331700167	REINFORCEMENT ASSY - LH	TATA spare parts
410331700168	ASSY BRACKET LH	TATA spare parts
410331700169	REINFORCEMENT ASSY - RH	TATA spare parts
410331703301	BRACKET WIRING HARNESS TRAY REAR	TATA spare parts
410331703304	BRACKET FOR FRONT HARNESS TRAY	TATA spare parts
410331707142	BRACKET	TATA spare parts
410331707154	SUPPORT PLATE	TATA spare parts
410331707155	CHANNEL BODY - LH	TATA spare parts
410331707156	CHANNEL BODY - RH	TATA spare parts
410331708210	TRAY WIRING HARNESS FRONT	TATA spare parts
410331708211	TRAY HARNESS REAR	TATA spare parts
410331708213	TRAY POWER STEERING HOSE REAR	TATA spare parts
410331708217	HARNESS TRAY (FRONT)	TATA spare parts
410331900101	L-BRACKET ASSY STONE GUARD MTG	TATA spare parts
410331900102	L-BRACKET ASSY STONE GUARD MTG	TATA spare parts
410331900103	L-BRACKET ASSY STONE GUARD MTG	TATA spare parts
410331900104	L-BRACKET ASSY STONE GUARD MTG	TATA spare parts
410331900105	L-BRACKET ASSY STONE GUARD MTG	TATA spare parts
410331900106	STONE GUARD ASSY FRONT	TATA spare parts
410331900107	STONE GUARD ASSY REAR	TATA spare parts
410331903305	L-BRACKET STONE GUARD MTG	TATA spare parts
410331903307	BASE PLATE BS6	TATA spare parts
410331990106	RETRO FOR LPO 1618 RESLF FOR CM CRACK	TATA spare parts
410331990107	RETRO FOR LPO 1618 RESLF FOR HOLES OBLON	TATA spare parts
410331990110	RETRO KIT FOR REAR FRAME REINFORCEMENT	TATA spare parts
410331990112	REAR FRAME REINFORCEMENT ASSY	TATA spare parts

410331990114	RETRO KIT OF REAR FRAME (FOR SINGLE JACK	TATA spare parts
410331990116	RETRO KIT OF REAR FRAME (FOR DOUBLE JACK	TATA spare parts
410332100106	AIR SPRING VIBRACOUSTIC BS3/4	TATA spare parts
410332100106DF	AIR BELLOW RUBBER FRONT - RE BUSES	TATA spare parts
410332100107	ASSY TORQUE ROD	TATA spare parts
410332100108	ASSY. BUSH	TATA spare parts
410332100118	ASSY CONNECTING LINK(LEVELING VALVE)	TATA spare parts
410332100119	CONNECTING ROD ASSY	TATA spare parts
410332103304	BRACKET LEVELLING ROD-FRONT AXLE	TATA spare parts
410332103501	ANTI ROLL BAR STOPPER TOP	TATA spare parts
410332103703	BRACKET FRONT AIR BELLOW MTG LH EV	TATA spare parts
410332103704	BRACKET FRONT AIR BELLOW MTG RH EV	TATA spare parts
410332103705	BRACKET FWD AXLE V-ROD MTG	TATA spare parts
410332104201	U-BOLT ARB STOPPER	TATA spare parts
410332106101	TOP PLATE	TATA spare parts
410332106301	BELLOW BS3/4	TATA spare parts
410332106302	BUMPER	TATA spare parts
410332106303	BELLOW FOR FRT AIR SPRING	TATA spare parts
410332106304	BUMP STOPPER	TATA spare parts
410332107901	PISTON	TATA spare parts
410332109201	WASHER	TATA spare parts
410332200103	ASSY BKT. HEIGHT SENSOR MTG. ON FRAME	TATA spare parts
410332200107	ASSY. LEVELING VALVE WITH CONNECTORS	TATA spare parts
410332200109	VOSSADAPTOR-M12 BS6	TATA spare parts
410332203301	BRKT CHASSIS FRONT LEVELLING VALVE	TATA spare parts
410332206001	ASSY ROD LEVELLING (LEVER TO FRONT AXLE)	TATA spare parts
410332207103	SUSPENSION PIPE INLET CONNECTOR BKT	TATA spare parts
410332207105	BRACKET FRONT CONNECTING ROD MTG	TATA spare parts
410332207106	BRACKET FRONT CONNECTING ROD MTG	TATA spare parts
410332300102	ASSY SHOCK ABSORBER FRONT	TATA spare parts
410332300105	ASSY SHOCK ABSORBER FRONT	TATA spare parts
410332400101	ASSY NYLON CLUSTER COMPLETE FOR AIR SUSP	TATA spare parts
410332400104	FRONT AIR SPRINGS CROSS MEMBER ASSY	TATA spare parts
410332400107	ASSY. PARALLEL LINK PIVOT-AIR SPRG BKT L	TATA spare parts
410332400108	ASSY. PARALLEL LINK PIVOT-AIR SPRG BKT R	TATA spare parts
410332400109	SUBFRAME & ARB ASSY	TATA spare parts
410332400111	REAR AIR SUSPENSION SYSTEM LAYOUT	TATA spare parts
410332400119	SUBFRAME & ANTI ROLL BAR ASSY BS6	TATA spare parts
410332400121	PARALLEL LINK ASSY - LH	TATA spare parts
410332400122	PARALLEL LINK ASSY - RH	TATA spare parts
410332400132	TORQUE ROD ASSEMBLY	TATA spare parts
410332400138	LEVELLING VALVE ASSY - LH	TATA spare parts
410332400139	LEVELLING VALVE ASSY - RH	TATA spare parts
410332400601	REAR LEVELLING VALVE LH	TATA spare parts
410332403201	HEX. SCREW M20X2.5X75	TATA spare parts
410332403204	M14X1.5X35MM HEX FLANGE BOLT	TATA spare parts
410332403205	M14X1.5X50MM HEX FLANGE BOLT	TATA spare parts

410332403206	M16X1.5X60MM HEX FLANGE BOLT	TATA spare parts
410332403207	M16X1.5X70MM HEX FLANGE BOLT	TATA spare parts
410332403208	M20X2.5X140MM HEX FLANGE BOLT	TATA spare parts
410332403209	M20X2.5X75MM HEX FLANGE SCREW	TATA spare parts
410332403210	M16 X2X150MM HEX NUT	TATA spare parts
410332403212	ALLEN BOLT M16X2X130MM(GR.12.9)	TATA spare parts
410332403301	LEV.VAL CHASIS BKT LH	TATA spare parts
410332403302	LEV VAL CHASIS BKT RH	TATA spare parts
410332403401	SPHERILASTIC BUSH	TATA spare parts
410332403402	SPHERILASTIC BUSH FOR ARB	TATA spare parts
410332404202	U-BOLT BS6	TATA spare parts
410332405104	TAPER PIVOT-SPIGOT	TATA spare parts
410332406502	M14X1.5 HEX FLANGE NUT	TATA spare parts
410332406503	M16X1.5 HEX FLANGE NUT	TATA spare parts
410332406504	M20X2.5 HEX FLANGE NUT	TATA spare parts
410332406601	STEEL PISTON 12 INCH	TATA spare parts
410332406801	VOSS ADAPTOR - M12	TATA spare parts
410332406802	ELBOW CONNECTOR M14X1.5 - 8 DIA. PIPE	TATA spare parts
410332407101	REAR FLITCH - RH	TATA spare parts
410332407111	STEEL CLAMP PLATE 12 IN	TATA spare parts
410332407114	LEVER LEVELLING VALVE	TATA spare parts
410332407115	REAR FLITCH - LH	TATA spare parts
410332407701	ROLLING DIAPRAM 12 IN BS3/4	TATA spare parts
410332407901	CONNECTING ROD	TATA spare parts
410332603301	BRACKET RH SHOCK ABSORBER MTG.	TATA spare parts
410332603302	BRACKET LH SHOCK ABSORBER MTG.	TATA spare parts
410332800101	ASSY ANTI ROLL BAR FRT WITH CRIMPED EYE	TATA spare parts
410332800102	ASSY FRONT ANTI ROLL BAR -MERITOR AXLE	TATA spare parts
410332800103	ANTI ROLL BAR (FRONT)	TATA spare parts
410332800105	ASSY BALL JOINT LINK - 120 MM CD	TATA spare parts
410332807102	CLAMP FRONT ANTI ROLL	TATA spare parts
410332807701	BUSH ((ANTIROLL BAR)	TATA spare parts
410332807706	RUBBER PACKING	TATA spare parts
410332807905	ANTI ROLL BAR(DIA 38) LPO1623 DTC	TATA spare parts
410332900104	SUB FRAME ASSY	TATA spare parts
410332900105	ANTI-ROLL BAR SUB ASSEMBLY	TATA spare parts
410332905101	ARB END LINK	TATA spare parts
410332907901	ANTI-ROLL BAR	TATA spare parts
410332950103	PIPE ASSY BUNCH COMPLETE	TATA spare parts
410332950130	ASSY NYLON PIPE BUNCH COMPLETE	TATA spare parts
410332950131	PIPE ASSY CONNECTOR TO T-CONN 1	TATA spare parts
410332950137	PIPE ASSY T-CONN 1 TO T-CONN 5	TATA spare parts
410332950139	PIPE ASSY T-CONN 3 TO RIV 1 RES PORT	TATA spare parts
410332950142	PIPE ASSY LVR LH DEL PORT1 TO TEE 6	TATA spare parts
410332950146	PIPE ASSY LV DEL PORT 2 RH TO RWD ELBOW	TATA spare parts
410332950147	PIPE ASSY RR ELBOW TO FWD AIR SPRING RH	TATA spare parts
410332950148	PIPE ASSY RR ELBOW TO RWD AIR SPRING RH	TATA spare parts

410332950151	PIPE ASSY RR ELBOW TO FWD AIR SPRING LH	TATA spare parts
410332950152	PIPE ASSY RR ELBOW TO RWD AIR SPRING LH	TATA spare parts
410332950155	PIPE ASSY FR LV LH TO RIV 2 RES PORT	TATA spare parts
410332950156	PIPE ASSY FR LV RH TO FRT AIR SPRING RH	TATA spare parts
410332950157	PIPE ASSY RIV2 DEL PORT TO FR AIR SPG LH	TATA spare parts
410332950158	PIPE ASSY FR RV DEL PORT TO RIV2 EM PORT	TATA spare parts
410332950164	PIPE ASSY RR RV DEL PORT TO RIV3 EM PORT	TATA spare parts
410332950198	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
410332960104	PIPE ASSY RIV3 DEL PORT2 TO RWD ELBOW LH	TATA spare parts
410332960105	PIPE ASSY T-CONN 5 TO RR LV INLET LH	TATA spare parts
410332960106	PIPE ASSY T-CONN 5 TO RR LV INLET RH	TATA spare parts
410332960107	PIPE ASSY,T-CONN 6 TO RIV3 RES PORT	TATA spare parts
410332960108	PIPE ASSY LVR DEL PORT 1 RH TO FWD ELBOW	TATA spare parts
410332960110	PIPE ASSY,RIV3 DEL PORT1 TO FWD ELBOW,LH	TATA spare parts
410333000102	ASSY FRONT AXLE NON ABS	TATA spare parts
410333000106	S KIT-1000	TATA spare parts
410333000107	KIT KING PIN BUSH	TATA spare parts
410333000108	KIT TIE ROD END	TATA spare parts
410333000109	KIT KNUCKLE LH	TATA spare parts
410333000110	KIT KNUCKLE RH	TATA spare parts
410333000111	KIT STEERING ARM	TATA spare parts
410333000112	KIT TIE ROD ARM LH	TATA spare parts
410333000113	KIT TIE ROD ARM RH	TATA spare parts
410333000114	ASSY FRONT AXLE LHD WITH ABS	TATA spare parts
410333000116	SLEEVE	TATA spare parts
410333000117	SENSOR ABS	TATA spare parts
410333000118	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
410333000119	KNUCKLE ASSY RH	TATA spare parts
410333000120	NUT	TATA spare parts
410333000121	KNUCKLE ASSY LH	TATA spare parts
410333000122	S_KIT-1007_L	TATA spare parts
410333000127	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
410333103101	THRUST BEARING	TATA spare parts
410333103201	BOLT/CAP SCREW (HUB ADAPTER ROTOR &BRG	TATA spare parts
410333103202	BOLT/CAP SCREW	TATA spare parts
410333103203	BOLT/CAP SCREW	TATA spare parts
410333103301	BRACKET TORQUE ROD	TATA spare parts
410333103302	BRACKET AIR RIDE LH	TATA spare parts
410333103303	BRACKET AIR RIDE RH	TATA spare parts
410333103304	PLATE TORQUE LH	TATA spare parts
410333103305	PLATE TORQUE RH	TATA spare parts
410333103401	BUSHING	TATA spare parts
410333103402	BUSHING	TATA spare parts
410333104801	DOWEL	TATA spare parts
410333104802	DOWEL	TATA spare parts
410333105102	CENTER-AXLE	TATA spare parts
410333105103	FRONT AXLE BEAM	TATA spare parts



410333105901	UPPER DRAW KEY	TATA spare parts
410333105902	LOWER DRAW KEY	TATA spare parts
410333105903	KEY	TATA spare parts
410333106001	ASSY. ROD-END AND TIE BS3/4	TATA spare parts
410333106002	ASSY. TIE ROD END LH BS4	TATA spare parts
410333106003	ASSY. TIE ROD END RH BS2	TATA spare parts
410333106501	FLANGE NUT-DRAW KEYS	TATA spare parts
410333106502	NUT	TATA spare parts
410333106701	PIN-STEERING KNUCKLE	TATA spare parts
410333107101	PLATE	TATA spare parts
410333108001	STOP SCREW	TATA spare parts
410333108301	SHIM	TATA spare parts
410333108302	SHIM	TATA spare parts
410333108303	SHIM	TATA spare parts
410333108801	WHEEL STUD M22X1.5	TATA spare parts
410333109210	WASHER FLAT	TATA spare parts
410333109211	WASHER FLAT	TATA spare parts
410333109212	WASHER FLAT	TATA spare parts
410333109901	CAP KING PIN	TATA spare parts
410333109902	FITTING GREASE UPPER	TATA spare parts
410333109903	FITTING GREASE LOWER	TATA spare parts
410333109905	ELBOW-FITTING GREASE	TATA spare parts
410333200102	STUB AXLE ASSY ABS RH	TATA spare parts
410333200103	STUB AXLE ASSY ABS LH	TATA spare parts
410333205103	KNUCKLE STEERING LH	TATA spare parts
410333205104	KNUCKLE STEERING RH	TATA spare parts
410333403101	ASSY. BEARING BS3/4	TATA spare parts
410333403201	BOLT/CAPSCREW	TATA spare parts
410333403202	BOLT/CAP SCREW-TORQUE PLATE MTG	TATA spare parts
410333403203	BOLT/CAP SCREW(DUST SHIELD MTG)	TATA spare parts
410333405502	HUB ADAPTER	TATA spare parts
410333406501	SPINDLE NUT	TATA spare parts
410333406502	NUT LOCK-TORQUE PLATE MTG	TATA spare parts
410333406503	NUT-SLOTTED	TATA spare parts
410333407801	OIL SEAL ASSY -KING PIN	TATA spare parts
410333409201	WASHER FLAT-HUB AND ROTOR MTG	TATA spare parts
410333409202	WASHER-WHEEL BRG NUT	TATA spare parts
410333409203	WASHER FLAT	TATA spare parts
410333409204	WASHER FLAT(TORQUE PLATE MTG)	TATA spare parts
410333409205	SPRING WASHER	TATA spare parts
410333409901	KEEPER	TATA spare parts
410333409902	PLUG	TATA spare parts
410333409903	SHIELD DUST ASSY-LH/RH	TATA spare parts
410333800112	TIE ROD ASSY EV	TATA spare parts
410333803201	BOLT/CAP SCREW-STEERING ARM	TATA spare parts
410333803202	ROD ASSY-CLAMP & TIE	TATA spare parts
410333803203	CLAMP ASSEMBLY	TATA spare parts

410333805104	TIE ROD ARM RH EV	TATA spare parts
410333805106	TIE ROD ARM LH EV	TATA spare parts
410333805109	STEERING ARM EV	TATA spare parts
410333806001	ARM-STEERING	TATA spare parts
410333806002	ARM TIE ROD-LH	TATA spare parts
410333806003	ARM TIE ROD-RH	TATA spare parts
410333806004	ARM TIE ROD LH	TATA spare parts
410333806005	STEERING ARM	TATA spare parts
410333806501	NUT-LOCK FIN(STEERING ARM)	TATA spare parts
410333806701	SPLIT COTTER PIN	TATA spare parts
410333806702	SPLIT COTTER PIN	TATA spare parts
410333808402	DOWEL	TATA spare parts
410334200111	CABLE SUPPORT ASSY	TATA spare parts
410335990102	KIT-REAR AXLE ASSY	TATA spare parts
410340100101	WHEEL NUT 33 MAX	TATA spare parts
410340100102	ASSY WHEEL NUT	TATA spare parts
410340106301	TUBELESS TYRE 295/80 R22.5	TATA spare parts
410340200105	ASSY HOLDER	TATA spare parts
410340200108	ASSY FLEXIBLE EXTENSION VALVE	TATA spare parts
410340209901	FLEXIBLE EXTENSION VALVE	TATA spare parts
410341000101	ASSY PROPELLER SHAFT COMPLETE	TATA spare parts
410341004601	SLIP YOKE ASSEMBLY	TATA spare parts
410341100101	ASSY PROPELLER SHAFT COMPLETE	TATA spare parts
410341100102	ASSY BKT PROP SHAFT GUARD	TATA spare parts
410341100110	ASSY. PROPELLER SHAFT	TATA spare parts
410341100111	SERVICE FREE PROPELLER SHAFT	TATA spare parts
410341100122	ASSY PROP SHAFT	TATA spare parts
410341100126	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
410341100127	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
410341108201	GUARD PROPELLER SHAFT	TATA spare parts
410341114601	FLANGE YOKE	TATA spare parts
410341120101	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
410341120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
410341303301	BRACKET CENTER BRG MTG	TATA spare parts
410341303302	BRACKET CENTER BRG MTG	TATA spare parts
410341303303	BRACKET CENTER BRG MTG	TATA spare parts
410341308201	SPACER PLATE	TATA spare parts
410341404601	TUBE YOKE	TATA spare parts
410341404603	TUBE SHAFT	TATA spare parts
410341994601	U J KIT	TATA spare parts
410342100108	DISC BRAKE LH	TATA spare parts
410342100109	DISC BRAKE RH	TATA spare parts
410342900101	HOSE ASSY (FROM AIR DUCT TO COMPRESSOR)	TATA spare parts
410342903301	HOSE CLAMP(AIR INTAKE TO COMPRESSOR)	TATA spare parts
410343103306	BRAKE ACTUATOR HOSE HOLDING BKT	TATA spare parts
410343200102	30 LIT. AIR TANK ASSY. COMPLETE	TATA spare parts
410343200109	AIR TANK ASSY WITH STRAP BS6	TATA spare parts

410343200110	ASSY AIR TANK COPMLETE LH(20 LTR VOSS)	TATA spare parts
410343200111	ASSY. 30 LIT AIR TANK(VOSS+METRIC ADAPT)	TATA spare parts
410343200114	ASSY AIR TANK 30 LIT.(METRIC VERSION)	TATA spare parts
410343200122	TANK 30 LTR (VOSS)	TATA spare parts
410343200123	ASSY. AIR TANK (15 LTR)--DOSING UNIT AIR	TATA spare parts
410343200124	HEAT SHIELD BS6	TATA spare parts
410343200135	ASSY PING TANK 1.5 LIT	TATA spare parts
410343200148	BRACKET ASSY AIR TANK MTG COMPLETE	TATA spare parts
410343200149	AIR TANK ASSY WITH BKT 79 PITCH	TATA spare parts
410343200152	AIR TANK ASSY - 30 LTR	TATA spare parts
410343208203	BRACKET (15LTR AIR TANK)	TATA spare parts
410343606801	ELBOW 3/8 NPT X M12	TATA spare parts
410343700105	ASSY CONSEPMTG BKT	TATA spare parts
410343700131	ASSY CONCEP UNIT MTG BKT	TATA spare parts
410343700140	ASSY QRV MOUNTING BRACKET	TATA spare parts
410343700141	AIR DRYER (9 BAR-VOSS)	TATA spare parts
410343700146	ASSY QRV MTG BKT	TATA spare parts
410343700154	PISTON KIT FOR 360CC COMPRESSOR	TATA spare parts
410343700155	GASKET KIT FOR 360CC COMPRESSOR	TATA spare parts
410343700156	CYLINDER HEAD KIT FOR 360CC COMPRESSOR	TATA spare parts
410343700157	COOLING PLATE KIT FOR 360CC COMPRESSOR	TATA spare parts
410343700158	VALVE PLATE KIT FOR 360CC COMPRESSOR	TATA spare parts
410343700184	AIR DRYER MTG BRKT	TATA spare parts
410343700186	BRACKET FOT ACRV & RELAY VALVE	TATA spare parts
410343700206	BRACKET ASSY MODULATOR VALVE FRONT	TATA spare parts
410343700207	BRACKET ASSY QRV MTG	TATA spare parts
410343700209	RELAY VALVE & MODULATOR VALVE ASSY BS6	TATA spare parts
410343700213	BRACKET ASSY APDA MTG BS6	TATA spare parts
410343700221	RELAY VALVE BS6	TATA spare parts
410343700222	SPRING BRAKE ACTUATOR BS6-PH2	TATA spare parts
410343700223	AIR DRYER BS6	TATA spare parts
410343703305	BRACKET (FOR PRV 6.0 BAR)	TATA spare parts
410343703309	BRACKET MODULATOR VALVE MTG	TATA spare parts
410343703316	BRACKET BS6	TATA spare parts
410343707702	OIL CONCEP SPOUT	TATA spare parts
410343707703	SPOUT ASSY FOR AIR DRYER	TATA spare parts
410343708201	CONDENSATE OIL SEPRETOR MTG. BKT	TATA spare parts
410343708206	OIL SEPRETOR SPOUT CLAMP	TATA spare parts
410343708208	PRV MOUNTING BRACKET FOR DTC	TATA spare parts
410343708702	CONICAL SPRING	TATA spare parts
410343709908	SILENCER ASSEMBLY-AIR DRYER-100311480	TATA spare parts
410343709910	REPAIR KIT QUICK RELEASE VALVE	TATA spare parts
410343709912	CLAMP RING	TATA spare parts
410343709914	CONDENSATE BODY - M/C	TATA spare parts
410343709915	CONDENSATE HEAD - M/C	TATA spare parts
410343710123	COMPRESSOR AIR 318CC BS3/4	TATA spare parts
410343710123AE	COMP. B-MECH B-GAS ENG. 318CC	TATA spare parts

410343710124	COMP. BG+/6BT ENG. 318CC	TATA spare parts
410343710125	COMP.ISBE ENGINE MTD 318CC	TATA spare parts
410343710126	CYLINDER HEAD REPAIR KIT	TATA spare parts
410343710127	PISTON ASSY REPAIR KIT STD 85 DIA	TATA spare parts
410343710128	MAJOR KIT	TATA spare parts
410343710129	COMP.RING KIT 85 DIA-3000 318CC	TATA spare parts
410343710130	CYLINDER HEAD ISBE6.7 BS2/3/4	TATA spare parts
410343710134	REPAIR KIT FOR AIR DRYER (WITH VITON SEA	TATA spare parts
410343710135	REPAIR KIT FOR AIR DRYER WITH VITON SEAL	TATA spare parts
410343710141	AIR DRYER WITH OSC CART METRIC VER	TATA spare parts
410343710142	DISC BRAKE CHAMBER TYPE 24-LH	TATA spare parts
410343710143	DISC BRAKE CHAMBER TYPE 24-RH	TATA spare parts
410343900108	ASSY AC INTAKE HOSE- AIR FILTER SIDE	TATA spare parts
410343900109	ASSY AC INTAKE HOSE -AC SIDE	TATA spare parts
410343900115	ASSY NYLON CLUSTER COMPLETE (AUTO TRANS)	TATA spare parts
410343900116	ASSY PIPE FROM QRV TO FRONT BRAKE RH	TATA spare parts
410343900117	ASSY PIPE FROM QRV TO FRONT BRAKE LH	TATA spare parts
410343900118	ASSY PIPE FROM RELAY TO BRAKE RH	TATA spare parts
410343900119	ASSY PIPE FROM RELAY TO BRAKE LH	TATA spare parts
410343900121	ASSY PIPE5 OD 18X1.5 COMP TO CONSEP	TATA spare parts
410343900122	ASSY PIPE OD 18X1.5 CONSEP TO AIR DRIER	TATA spare parts
410343900136	ASSY NYLON CLUSTER COMPLETE	TATA spare parts
410343900137	ASY PIPE OD12X1 SUSP TNK TO AUX TNK T	TATA spare parts
410343900138	ASY PIPE OD12X1 AUX TNK TO RETARD. TNK	TATA spare parts
410343900139	ASSY PIPE OD12X1 PIPE TEE TO NRV(AUX TN)	TATA spare parts
410343900144	ASSY. 6 OD PIPE COMPLETE. (FROM INTERMED	TATA spare parts
410343900146	ASSY. METAL PIPE FRONT BRAKE CHAMBER	TATA spare parts
410343900151	PVC NYLON PIPE FOR OIL SEPARATOR	TATA spare parts
410343900153	OIL SEPRTETOR SPOUT HOSE 375 MM	TATA spare parts
410343900160	ASSY. 18 DIA. FIRST METAL PIPE FROM COMP	TATA spare parts
410343900161	ASSY. 18 DIA. SECOND METAL PIPE FROM COM	TATA spare parts
410343900162	ASSY. 18 DIA. THIRD METAL PIPE FROM COMP	TATA spare parts
410343900163	ASSY. 18 DIA. FORTH METAL PIPE FROM COMP	TATA spare parts
410343900164	ASSY. 18 DIA. FIFTH METAL PIPE FROM COMP	TATA spare parts
410343900167	ASSY. 12 DIA. FIRST METAL PIPE FROM AIR	TATA spare parts
410343900177	KIT-SPRING BRAKE ACTUATOR	TATA spare parts
410343900178	OIL SEPERATOR SPOUT HOSE FOR AXLE	TATA spare parts
410343900183	AIR DRYER TO SPV-15DIA - 1ST PIPE	TATA spare parts
410343900184	AIR DRYER TO SPV- 15DIA - 2ND PIPE	TATA spare parts
410343900185	AIR DRYER TO SPV- 15DIA - 3RD PIPE	TATA spare parts
410343900186	AIR DRYER TO SPV- 15DIA - 4TH PIPE	TATA spare parts
410343900187	AIR DRYER TO SPV- 15DIA - 5TH PIPE	TATA spare parts
410343900188	AIR DRYER TO SPV- 15DIA - 6TH PIPE	TATA spare parts
410343900189	AIR DRYER TO SPV- 15DIA - 7TH PIPE	TATA spare parts
410343900190	30L AIR TANK T CON TO SPV-15DIA-1ST PIPE	TATA spare parts
410343900191	30L AIR TANK T CON TO SPV-15DIA-2ND PIPE	TATA spare parts
410343900192	30L AIR TANK T CON TO SPV-15DIA-3RD PIPE	TATA spare parts

410343900194	30L AIR TANK T CON TO SPV-15DIA-5TH PIPE	TATA spare parts
410343900195	30L AIR TANK T CON TO SPV-15DIA-6TH PIPE	TATA spare parts
410343900196	30L AIR TANK T CON TO SPV-15DIA-7TH PIPE	TATA spare parts
410343900197	T CONNECTION TO NRV & 6BAR PRV- 15DIA	TATA spare parts
410343900198	REAR QRV TO LH BRAKE CHAMBER- 15DIA	TATA spare parts
410343900199	REAR QRV TO RH BRAKE CHAMBER- 15DIA	TATA spare parts
410343900365	COMPRESSOR TO TEFLON HOSE 18 OD PIPE	TATA spare parts
410343900370	6 OD METALLIC PIPE (EXHAUST BRAKE INLET)	TATA spare parts
410343900375	ASSY PIPE 18ODX1.5THK COMP. TO CONSEP	TATA spare parts
410343900402	TEFLON HOSE TO OIL SEPARATOR 18 OD PIPE	TATA spare parts
410343903303	BRACKET AIR-COMP.INLET PIPE	TATA spare parts
410343903304	CLAMP (AIR COMP. PIPE)	TATA spare parts
410343904201	CLAMP DIA.25 PIPE	TATA spare parts
410343906802	ADAPTOR M33X1.5-25 OD TUBE END	TATA spare parts
410343906803	AIR COMPRESSOR INLET PIPE ASSY ID 25	TATA spare parts
410343906804	AIR COMP.INTAKE PIPE ASY (INTERCOOL.OUT)	TATA spare parts
410343906805	AIR COMP INTAKE PIPE (INTRCOOLER OUTLET)	TATA spare parts
410343906806	PLUG M33X2	TATA spare parts
410343907701	O-RING 2.65 X 34.5	TATA spare parts
410343908204	COMP.18 DIA PIPE MTG.BKT.	TATA spare parts
410343910103	ASSY PIPE2 OD6X0.7 SPV23 TO HBV	TATA spare parts
410343910107	ASSY PIPE 6ODX1.5THK-COMPRESSOR CONTROL	TATA spare parts
410343910108	TCV TO COMP CONTROL PORT 06 DIA-1ST PIPE	TATA spare parts
410343910109	TCV TO COMP CONTROL PORT 06 DIA-2ND PIPE	TATA spare parts
410343910123	ASY PIPE4 OD 18X1.5 COMP-HOSE TO CONSEP	TATA spare parts
410343910124	ASY PIPE4 OD 18X1.5 COMP-HOSE TO CONSEP	TATA spare parts
410343910125	ASY PIPE4 OD 18X1.5 COMP-HOSE TO CONSEP	TATA spare parts
410343910126	ASY PIPE4 OD 18X1.5 COMP-HOSE TO CONSEP	TATA spare parts
410343910142	ASSY.6OD NYLON PIPE 12X1.5 WITH CAP NUT	TATA spare parts
410343910143	ASSY.6OD METAL PIPE 12X1.5 WITH CAP NUT	TATA spare parts
410343910145	ASSY.15 OD PIPE FROM AIR DRIER TO TEE	TATA spare parts
410343910146	ASSY.15 OD PIPE FROM TEE TO SPV	TATA spare parts
410343910147	ASSY. TANK TO RELAY 12 DIA. METAL 1ST PI	TATA spare parts
410343910148	ASSY. TANK TO RELAY 12 DIA. METAL 2ND PI	TATA spare parts
410343910149	ASSY. TANK TO RELAY 12 DIA. METAL 3RD PI	TATA spare parts
410343910152	PIPE ASSY 4TH METAL PIPE	TATA spare parts
410343910219	ASSY.18 DIA PIPE COMP. OUTLET	TATA spare parts
410343910221	ASSY METAL PIPE OD25 FOR NATURAL ASPIRET	TATA spare parts
410343910223	METAL PIPE ASSY BS6	TATA spare parts
410343910229	ASY PIPE1 OD 12X1 HAND BRAKE V TO QRV H	TATA spare parts
410343910290	METAL PIPE ASSY BS6	TATA spare parts
410343910291	METAL PIPE ASSY BS6	TATA spare parts
410343910292	METAL PIPE ASSY BS6	TATA spare parts
410343910294	METAL PIPE ASSY BS6	TATA spare parts
410343910295	METAL PIPE ASSY BS6	TATA spare parts
410343910299	METAL PIPE ASSY BS6	TATA spare parts
410343920124	ADAPTOR	TATA spare parts

410343920179	PIPE ASSY 1ST	TATA spare parts
410343920180	PIPE ASSY 2ND	TATA spare parts
410343920181	PIPE ASSY 3RD	TATA spare parts
410343920182	PIPE ASSY 4TH	TATA spare parts
410343920183	PIPE ASSY 5TH	TATA spare parts
410343920184	PIPE ASSY 6TH	TATA spare parts
410343920185	PIPE ASSY 7TH	TATA spare parts
410343920205	METAL PIPE ASSY BS6	TATA spare parts
410343920206	METAL PIPE ASSY BS6	TATA spare parts
410343920247	PIPE ASSY BS6	TATA spare parts
410343920248	PIPE ASSY BS6	TATA spare parts
410343930120	PIPE BUNCH ASSY FOR LPO1623 BSIII	TATA spare parts
410343930121	PIPE BUNCH ASSY FOR LPO1623 BS-IV	TATA spare parts
410343930136	PIPE ASSY FR. RV TO MOD VALVE FR/RH	TATA spare parts
410343930137	PIPE ASSY FR. RV TO MOD VALVE FR/LH	TATA spare parts
410343930138	PIPE ASSY MOD VALVE FR/LH TO BC HOSE	TATA spare parts
410343930139	PIPE ASSY MOD VALVE FR/RH TO BC HOSE	TATA spare parts
410343930140	PIPE ASSY RR. RV TO MOD VALVE RR/RH	TATA spare parts
410343930141	PIPE ASSY RR. RV TO MOD VALVE RR/LH	TATA spare parts
410343930142	PIPE ASSY TEE 7 TO SBA PORT 12 LH	TATA spare parts
410343930143	PIPE ASSY TEE 7 TO SBA PORT 12 RH	TATA spare parts
410343930162	PIPE ASSY SPV 22 TO FR. AIR TANK	TATA spare parts
410343930170	PIPE ASSY MAG SWITCH TO EX BRAKE	TATA spare parts
410343930171	PIPE BUNCH ASSY FOR LPO1924 LHD	TATA spare parts
410343930176	PIPE ASSY 6TH METAL PIPE	TATA spare parts
410343930182	PIPE ASSY COMPRESSOR INTAKE	TATA spare parts
410343930183	PIPE ASSY PARTITION BKT TO TEE-1ST PIPE	TATA spare parts
410343930184	PIPE ASSY PARTITION BKT TO PRV-2ND PIPE	TATA spare parts
410343930185	PIPE ASSY PARTITION BKT TO PRV-3RD PIPE	TATA spare parts
410343930186	PIPE ASSY 12 DIA COUPLING 50 MM	TATA spare parts
410343930187	PIPE ASSY PARTITION BKT TO PRV-4TH PIPE	TATA spare parts
410343930188	PIPE ASSY SUP. METAL PIPE TO I/M JOINT	TATA spare parts
410343930189	PIPE ASSY TEE TO RET AIR TANK INLET	TATA spare parts
410343930190	PIPE ASSY TEE TO AUX AIR TANK INLET	TATA spare parts
410343930191	PIPE ASSY PARTITION BKT TO R/V INLET	TATA spare parts
410343930192	PIPE ASSY PARTITION BKT TO RE R/V SIGNAL	TATA spare parts
410343930193	PIPE ASSY PARTITION BKT TO QRV HOSE	TATA spare parts
410343930196	PIPE ASSY INTERMEDIATE PIPE 12 DIA	TATA spare parts
410343930197	PIPE ASSY RE RELAY INLET - FIRST	TATA spare parts
410343930198	PIPE ASSY AUX.CIRCUIT FIRST METAL PIPE	TATA spare parts
410343940101	PIPE ASSY COMP. TO AIR DRYER-FIFTH	TATA spare parts
410343940103	PIPE ASSY ADAPTOR	TATA spare parts
410343940105	PIPE ASSY REAR SIGNAL-FIRST PIPE	TATA spare parts
410343940107	PIPE ASSY COMP. TO AIR DRYER - NINTH	TATA spare parts
410343940108	PIPE ASSY COMP. TO AIR DRYER - EIGHTH	TATA spare parts
410343940109	PIPE ASSY COMP. TO AIR DRYER - SIXTH	TATA spare parts
410343940110	PIPE ASSY COMP. TO AIR DRYER-FOURTH	TATA spare parts

410343940111	PIPE ASSY COMP. TO AIR DRYER-THIRD	TATA spare parts
410343940112	PIPE ASSY AUX AIR TANK O/L TO TEE	TATA spare parts
410343940115	PIPE ASSY REAR QRV TO LH SBA	TATA spare parts
410343940116	PIPE ASSY REAR QRV TO RH SBA	TATA spare parts
410343940118	PIPE ASSY COMP. TO AIR DRYER-TENTH	TATA spare parts
410343940139	PIPE ASSY COMP. TO DRYER FIRST	TATA spare parts
410343940140	PIPE ASSY COMP. TO AIR DRYER-SECOND	TATA spare parts
410343940148	PIPE BUNCH ASSY FOR LPO1623 BSIV ABS	TATA spare parts
410343940152	PIPE BUNCH ASSY	TATA spare parts
410343940158	PIPE ASSY FROM RELAY TO BRAKE	TATA spare parts
410343940198	PIPE ASSY SUPENSION TANK TO I/M JT	TATA spare parts
410343950130	PIPE ASSY 5TH METAL PIPE	TATA spare parts
410343950131	PIPE ASSY 1ST METAL PIPE (18 OD)	TATA spare parts
410343950132	PIPE ASSY 2ND METAL PIPE	TATA spare parts
410343990003	MANIFOLD	TATA spare parts
410343990004	DISCHARGE VALVE	TATA spare parts
410343990006	PISTON ASSEMBLY	TATA spare parts
410343990009	ADAPTER	TATA spare parts
410343990013	ADAPTER	TATA spare parts
410343990127	KIT FOR DUAL BRAKE VALVE BIAS CONVERSION	TATA spare parts
410343993301	PRESSURE RED. VALVE MTG. BKT	TATA spare parts
410346100101	ASSY PIPE CLAMP FOR STEERING HOSE	TATA spare parts
410346100102	ASSY PIPE CLAMP FOR STEERING HOSE	TATA spare parts
410346200108	SPINDLE ASSY BOTTOM BS6	TATA spare parts
410346305101	PITMAN ARM	TATA spare parts
410346305104	PITMAN ARM	TATA spare parts
410346305107	PITMAN ARM BS6	TATA spare parts
410346306001	PITMAN ARM	TATA spare parts
410346600109	ASSY STEERING GEAR BOX	TATA spare parts
410346600114	ASSY DRAG LINK	TATA spare parts
410346600116	VANE PUMP ASSEMBLY	TATA spare parts
410346600117	ASSY VANE PUMP	TATA spare parts
410346600123	DRAG LINK ASSY (SEALED TYPE)	TATA spare parts
410346600125	STEERING GEAR BOX ASSY	TATA spare parts
410346700101	BRACKET ASSY STG GEAR BOX MTG	TATA spare parts
410346700103	BRACKET ASSY STG GEAR BOX MTGBS6	TATA spare parts
410346800103	HOSE ASSY GB TO TANK	TATA spare parts
410346800104	HOSE ASSY (TANK TO VANE PUMP)	TATA spare parts
410346800115	SUCTION LINE ASSY	TATA spare parts
410346800116	RETURN LINE ASSY	TATA spare parts
410346800117	PRESSURE LINE ASSY	TATA spare parts
410346800118	PRESSURE LINE ASSY	TATA spare parts
410346800119	PRESSURE LINE ASSY	TATA spare parts
410346800120	PRESSURE LINE ASSY	TATA spare parts
410346800121	PRESSURE LINE ASSY	TATA spare parts
410346800122	PRESSURE LINE ASSY	TATA spare parts
410346800123	PRESSURE LINE ASSY	TATA spare parts

410346800124	PRESSURE LINE ASSY	TATA spare parts
410346800125	RETURN LINE ASSY	TATA spare parts
410346800126	RETURN LINE ASSY	TATA spare parts
410346800127	RETURN LINE ASSY	TATA spare parts
410346800128	RETURN LINE ASSY	TATA spare parts
410346800129	RETURN LINE ASSY	TATA spare parts
410346800130	RETURN LINE ASSY	TATA spare parts
410346800131	RETURN LINE ASSY	TATA spare parts
410346800132	RETURN LINE ASSY	TATA spare parts
410346800133	SUCTION LINE ASSY	TATA spare parts
410346800142	PRESSURE LINE ASSY BS6	TATA spare parts
410346800143	SUCTION LINE ASSY BS6	TATA spare parts
410346800144	SUCTION LINE ASSY BS6	TATA spare parts
410346800145	PRESSURE LINE ASSY BS6	TATA spare parts
410346800146	RETURN LINE ASSY BS6	TATA spare parts
410346800147	RETURN LINE ASSY BS6	TATA spare parts
410346800148	RETURN LINE ASSY BS6	TATA spare parts
410346800150	RETURN LINE ASSY BS6	TATA spare parts
410346800151	RETURN LINE ASSY BS6	TATA spare parts
410346800152	RETURN LINE ASSY BS6	TATA spare parts
410346800153	PRESSURE LINE ASSY BS6	TATA spare parts
410346800155	PRESSURE LINE ASSY BS6	TATA spare parts
410346900101	ASSY. DRAG LINK EURO3	TATA spare parts
410346900102	DRAG LINK ASSY	TATA spare parts
410346900103	DRAG LINK ASSY	TATA spare parts
410346900107	END ASSY RH	TATA spare parts
410346900110	DRAG LINK ASSY	TATA spare parts
410346900112	DRAG LINK ASSY BS6	TATA spare parts
410347000101	VOSS CONNECTORS KIT FOR FUEL LINE	TATA spare parts
410347000103	NYLON PIPES KIT-FUEL SYSTEM	TATA spare parts
410347100104	ASSY. FUEL TANK COMPLETE 200 LTRS	TATA spare parts
410347100106	ASSY FUEL TANK COMPLETE (SEAM WELDED)	TATA spare parts
410347100111	FUEL TANK ASSY WITH CAP;200 LTRS	TATA spare parts
410347100114	FUEL TANK ASSY W/O TANK UNIT BS6	TATA spare parts
410347500102	ASSY HPR MOUNTING BRACKET	TATA spare parts
410347500103	ASSY BRACKET - 1 (FUEL TANK MTG)	TATA spare parts
410347500104	ASSY BRACKET - 2 (FULE TANK MTG)	TATA spare parts
410347500113	VENT TUBE CLAMPING BRACKET	TATA spare parts
410347503320	VENT CAP LOCKING BKT.	TATA spare parts
410347507606	LP FILTER MOUNTING ASSY	TATA spare parts
410347600103	ASSY FUEL LINE (INT JOINT TO BODY FILTER	TATA spare parts
410347600104	ASSY FUEL LINE (INT JOINT TO RETURN LINE	TATA spare parts
410347600105	ASSY HOSE 1/2 LPF TO ENGINE	TATA spare parts
410347600106	ASSY HOSE (HPR COOLANT)	TATA spare parts
410347600109	ASSY HOSE HPR COOLANT LINE(ENG TO HPR)	TATA spare parts
410347600111	FUEL PIPE ASSY;FILTER TO ENGINE	TATA spare parts
410347600112	FUEL PIPE ASSY;FUEL TANK TO FILTER	TATA spare parts



410347600113	FUEL PIPE LINE ASSY;RETURN LINE	TATA spare parts
410347600123	LP HOSE ASSY REGULATOR TO LP FILTER	TATA spare parts
410347600124	LP HOSE ASSY LP FILTER TO ENGINE	TATA spare parts
410347600128	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600131	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600132	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600133	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600134	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600151	FUEL LINES ASSY FUEL TANK TO FWS	TATA spare parts
410347600152	FUEL LINES ASSY (FWS TO ENGINE)	TATA spare parts
410347600153	FUEL LINES ASSY (ENGINE TO FUEL TANK)	TATA spare parts
410347600162	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600163	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600164	BRACKET HP & VENT LINE CLAMP BS6	TATA spare parts
410347600167	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600168	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600169	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600170	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600171	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600173	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600174	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600175	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600176	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600180	VENT TUBE ASSY BS6	TATA spare parts
410347600183	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600184	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
410347600185	CLAMP ASSY HP PIPE BS6	TATA spare parts
410347603309	SUPPORT PLATE FOR ASSY FUEL LINE	TATA spare parts
410347603310	BRACKET CLAMP BS6	TATA spare parts
410347603801	VENT CAP FOR CNG FUEL SYSTEM	TATA spare parts
410347604201	PLASTIC TUBE CLAMP (DIA. 22)	TATA spare parts
410347604701	HP SOLENOID LOWER COVER	TATA spare parts
410347604702	HP SOLENOID TOP COVER	TATA spare parts
410347605849	TUBE BS6	TATA spare parts
410347606901	HP GAS TUBE 1/4IN OD WITH PVC SLEEVE	TATA spare parts
410347606994	ASSY HOSE (HPR COOLANT LINE)	TATA spare parts
410347616915	TUBE ASSY OD 12 X 1 THICK	TATA spare parts
410347700101	ASSY HPR (CLH I STAGE)	TATA spare parts
410347700103	FUEL FILTER MTG BRACKET	TATA spare parts
410347990106	VOSS CONNECTORS; NYLON PIPES KIT - FUEL	TATA spare parts
410347990107	KIT FOR FUEL TANK CAP & KEY BS3/4	TATA spare parts
410347990107AE	FUEL TANK CAP ASM 1628 1828	TATA spare parts
410347990108	KIT - FUEL TANK CAP & KEY	TATA spare parts
410349100102	ASSY. EXHAUST PIPE WITH FLEXIBLE BELLOW	TATA spare parts
410349100103	ASSY SILENCER MTG BKT	TATA spare parts
410349100104	REAR CLAMP ASSY HEAT SHIELD CATCON	TATA spare parts
410349100105	FRONT CLAMP ASSY HEAT SHIELD CATCON	TATA spare parts

410349100106	FRONT CLAMP LH ASSY HEAT SHIELD MUFFLER	TATA spare parts
410349100107	FRONT CLAMP RH ASSY HEAT SHIELD MUFFLER	TATA spare parts
410349100108	REAR CLAMP ASSY HEAT SHIELD MUFFLER	TATA spare parts
410349100109	ASSY HEAT SHIELD CATCON	TATA spare parts
410349100110	ASSY HEAT SHIELD MUFFLER	TATA spare parts
410349100111	ASSY SILENCER PIPE (AUTO TRANS)	TATA spare parts
410349100114	ASSY EXHAUST PIPE	TATA spare parts
410349100116	ASSEMBLY EXHAUST PIPE EX. BRAKE TO DECOM	TATA spare parts
410349100120	MUFFLER FLANGE ASSY	TATA spare parts
410349100141	ASSY BRACKET (FLEXI SUPPORT)	TATA spare parts
410349100146	ASSY MTG BKT (SILENCER)	TATA spare parts
410349104201	CLAMP SILENCER MTG BS6	TATA spare parts
410349106901	EXHAUST MUFFLER LPO1625CNG	TATA spare parts
410349106906	TAIL PIPE	TATA spare parts
410349106907	TAIL PIPE	TATA spare parts
410349106915	TAIL PIPE	TATA spare parts
410349106920	TAIL PIPE	TATA spare parts
410349106921	TAIL PIPE	TATA spare parts
410349200101	EXHAUST PIPE INTERMEDIATE	TATA spare parts
410349200103	ASSY EXHASUT PIPE TURBO TO CATCON	TATA spare parts
410349200105	ASSY HANGER SILECER	TATA spare parts
410349200107	ASSY HANGER CATCON FRT	TATA spare parts
410349200108	ASSY HEAT SHIELD MUFFLER	TATA spare parts
410349200110	ASSY HEAT SHIELD REAR BELLOW LH	TATA spare parts
410349200111	ASSY PIPE - EXHAUST	TATA spare parts
410349200115	EXHAUST GAS PROCESSOR SIDE IN END OUT(ON	TATA spare parts
410349200116	BRACKET (ON ENGINE BLOCK)	TATA spare parts
410349200120	SUCTION LINE,TANK TO SM BS6	TATA spare parts
410349200121	PRESSURE LINE,SM TO DM BS6	TATA spare parts
410349200122	ASSY U-PIPE INTERMEDIATE	TATA spare parts
410349200123	ASSY TURBO TO CATCON	TATA spare parts
410349200124	ASSY TAIL PIPE	TATA spare parts
410349200138	ASSY TAIL PIPE	TATA spare parts
410349200148	ASSY. PIPE CONNECTOR	TATA spare parts
410349200149	ASSY EXHAUST PIPE	TATA spare parts
410349200150	ASSY EXHAUST PIPE	TATA spare parts
410349200151	ASSY PIPE - EXHAUST	TATA spare parts
410349200152	ASSY. TAIL PIPE	TATA spare parts
410349200153	PIPE ASSY EXHAUST	TATA spare parts
410349200154	PIPE ASSY DECOMP	TATA spare parts
410349200156	TAIL PIPE	TATA spare parts
410349200159	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
410349200160	EXHAUST PIPE ASSY BS6	TATA spare parts
410349200161	EXHAUST PIPE ASSY BS6	TATA spare parts
410349200162	TAIL PIPE BS6	TATA spare parts
410349200163	BRACKET ASSY BS6	TATA spare parts
410349200164	BRACKET ASSY BS6	TATA spare parts

410349203302	CLAMP	TATA spare parts
410349203303	HANGER CATCON END	TATA spare parts
410349203305	L-BKT 1 AIR MIX LINE	TATA spare parts
410349203306	L-BKT 2 AIR MIX LINE	TATA spare parts
410349203309	CLAMP(TAIL PIPE)	TATA spare parts
410349203310	BRACKET BS6	TATA spare parts
410349203317	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
410349203318	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
410349203320	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
410349203322	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
410349203323	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
410349204202	CLAMP SILENCER MTG FRONT	TATA spare parts
410349204203	CLAMP SILENCER END	TATA spare parts
410349204204	CLAMP CATCON MTG FRONT	TATA spare parts
410349204205	EXHAUST CLAMP	TATA spare parts
410349204206	DECOMP PIPE SUPPORT CLAMP	TATA spare parts
410349204207	STAINLESS STEEL RUBBERISED CLAMP	TATA spare parts
410349204210	CLAMP BS6	TATA spare parts
410349205001	HANGER FOR MUFFLER HEAT SHIELD FRONT	TATA spare parts
410349205002	HANGER (FOR MUFFLER HEAT SHEILD)	TATA spare parts
410349205301	GASKET 1	TATA spare parts
410349205302	GASKET 2	TATA spare parts
410349205303	GASKET (BETWEEN EGP AND DECOMP PIPE)	TATA spare parts
410349205307	GASKET ASSY BS6	TATA spare parts
410349205308	GASKET ASSY BS6	TATA spare parts
410349205801	UREA AIR MIX LINE	TATA spare parts
410349205802	AIR PIPE LINE AIR OIL FILTER TO DU	TATA spare parts
410349206904	TAIL PIPE	TATA spare parts
410349207115	SUPPORT BKT DECOMP PIPE	TATA spare parts
410349207116	BKT FOR DECOMP MTG	TATA spare parts
410349207118	BRACKET FOR EXHAUST PIPE	TATA spare parts
410349207129	BRACKET (EXHAUST ELBOW)	TATA spare parts
410349207130	SUPPORT CHANNEL	TATA spare parts
410349207131	BRACKET FOR EXHAUST PIPE	TATA spare parts
410349207132	BRACKET FOR MUFLER MTG	TATA spare parts
410349207135	BRACKET EXHAUST BRAKE MOUNTING	TATA spare parts
410349207136	L-BRACKET SILENCER MOUNTING	TATA spare parts
410349207702	RUBBER PACKING (30 LIT UREA TANK)	TATA spare parts
410349208201	BRKT EXHAUST MTG	TATA spare parts
410349208203	SPL CLAMP FOR CATCON	TATA spare parts
410349208204	SPL CLAMP FOR MUFFLER	TATA spare parts
410349208211	EGP CLAMP	TATA spare parts
410349208212	NOZZLE PROTECTION SHIELD	TATA spare parts
410349208213	U-BOLT BS6	TATA spare parts
410349208230	CLAMP (SILENCER MTG.)	TATA spare parts
410349600101	HEAT SHIELD ASSY CATCON BS6	TATA spare parts
410349600102	HEAT SHIELD ASSY SILENCER BS6	TATA spare parts

410349600103	HEAT SHIELD ASSY EXHAUST PIPE BS6	TATA spare parts
410349990101	ASSY HEAT SHIELD	TATA spare parts
410349990107	ASSY HEAT SHIELD	TATA spare parts
410349990115	ASSY HEAT SHIELD	TATA spare parts
410350000101	ASSY RADIATOR KIT COMPLETE	TATA spare parts
410350000102	ASSY RADIATOR WITH FRAME	TATA spare parts
410350000103	ASSY INTER COOLER	TATA spare parts
410350000104	RADIATOR INTERCOOLER ASSY	TATA spare parts
410350000112	RADIATOR & I/C ASSY	TATA spare parts
410350100101	ASSY PIPE - RADIATOR TO TRANS OIL COOLER	TATA spare parts
410350100102	ASSY PIPE RENGINE TO RADIATOR	TATA spare parts
410350100105	ASSY AUX TANK FOR RADIATOR	TATA spare parts
410350100106	ASSY. RADIATOR BS3/4	TATA spare parts
410350100107	INTERCOOLER ASSY FOR LPO1624C	TATA spare parts
410350100108	ASSY PIPE RADIATOR TO TRANS OIL COOLER	TATA spare parts
410350100109	ASSY PIPE ENGINE TO RADIATOR	TATA spare parts
410350100110	ASSY PIPE RADIATOR TO TRANS OIL COOLER	TATA spare parts
410350100111	ASSY PIPE ENGINE TO RADIATOR	TATA spare parts
410350100117	BOLT ASSY M6X1.0X14 L	TATA spare parts
410350100118	FILLER NECK	TATA spare parts
410350100119	PRESSURE CAP 1.0	TATA spare parts
410350100120	ASSY BRACKET	TATA spare parts
410350100124	RADIATOR ASSY	TATA spare parts
410350100125	INTERCOOLER ASSY	TATA spare parts
410350103302	SUPPORT PLATE	TATA spare parts
410350103304	SUPPORT BRACKET	TATA spare parts
410350103305	SUPPORT BRACKET	TATA spare parts
410350103306	SUPPORT BRACKET	TATA spare parts
410350103313	BKT (RADIATOR MTG)	TATA spare parts
410350103802	CAST PIPE INTERCOOLER TO ENGINE	TATA spare parts
410350105801	HOSE RADIATOR OUTLET	TATA spare parts
410350105803	RUBBER HOSE ID 60	TATA spare parts
410350105804	REDUCER HOSE COOLER OUTLET	TATA spare parts
410350105805	HOSE ID 28	TATA spare parts
410350105806	HOSE ID 38	TATA spare parts
410350105808	HOSE (OIL COOLER TO ENGINE)	TATA spare parts
410350105810	PIPE (INTERCOOLER TO ENGINE)	TATA spare parts
410350105811	REDUCER HOSE (OIL COOLER TO ENGINE PIPE)	TATA spare parts
410350105812	HOSE WATER PUMP INLATE	TATA spare parts
410350105813	HOSE-2 (OILCOOLER TO ENGINE)	TATA spare parts
410350105814	HOSE RADIATOR IN	TATA spare parts
410350105817	REDUCER HOSE (OIL COOLER TO ENGINE PIPE)	TATA spare parts
410350105818	REDUCER HOSE(PIPE RAD TO OIL COOLER)	TATA spare parts
410350105822	HOSE (OIL COOLER TO ENGINE)	TATA spare parts
410350105858	RUBBER HOSE (WATER PUMP INLET)	TATA spare parts
410350105863	REDUCER HOSE	TATA spare parts
410350106801	PIPE ENGINE TO RADIATOR	TATA spare parts

410350106802	PIPE RADIATOR TO OIL COOLER	TATA spare parts
410350106803	PIPE OIL COOLER TO ENGINE	TATA spare parts
410350106804	PIPE AUX TANK TO RADIATOR BOTTEM PIPE	TATA spare parts
410350106805	PIPE INTERCOOLER TO ENGINE	TATA spare parts
410350106806	PIPE ENGINE TO INTERCOOLER	TATA spare parts
410350106807	VENT TUBE ENG TO SURGE TANK	TATA spare parts
410350106808	VENT TUBE RAD TO SURGE TANK	TATA spare parts
410350106825	PIPE OIL COOLER TO ENGINE	TATA spare parts
410350106826	PIPE RADIATOR TO OIL COOLER	TATA spare parts
410350106828	PIPE AUX TANK TO RADIATOR BOTTOM	TATA spare parts
410350106829	PIPE INTERCOOLER TO ENGINE	TATA spare parts
410350106830	PIPE (AUX TANK TO LCL)	TATA spare parts
410350106831	PIPE RADIATOR TO TRANS OIL COOLER	TATA spare parts
410350106851	PIPE (ENGINE TO RADIATOR)	TATA spare parts
410350106852	PIPE (RADIATOR TO ENGINE)	TATA spare parts
410350106854	PIPE	TATA spare parts
410350106855	PIPE (OIL COOLER TO ENGINE)	TATA spare parts
410350106856	VENT TUBE (ENGINE TO AUX TANK)	TATA spare parts
410350106857	VENT TUBE (RADIATOR TO AUX TANK)	TATA spare parts
410350106858	PIPE	TATA spare parts
410350106859	PIPE ENGINE TO INTERCOOLER	TATA spare parts
410350106901	VENT PIPE AUX TANK TO LCL	TATA spare parts
410350106902	VENT TUBE RAD TO AUX TANK	TATA spare parts
410350106904	PIPE OIL COOLER TO ENGINE	TATA spare parts
410350106905	PIPE THERMOSTATE BY PASS	TATA spare parts
410350106915	WATER FILL PIPE	TATA spare parts
410350106916	PIPE AUX TANK TO RADIATOR	TATA spare parts
410350106923	VENT TUBE ENGINE TO AUX TANK	TATA spare parts
410350106924	VENT TUBE RAD TO AUX TANK	TATA spare parts
410350106943	PIPE ENGINE TO RADIATOR	TATA spare parts
410350109902	O RING	TATA spare parts
410350200101	ASSY. DUST SHIELD	TATA spare parts
410350200103	ASSEMBLY DUST SHIELD	TATA spare parts
410350207817	CLAMP FOR INTERCOOLER PIPE	TATA spare parts
410350400102	ASSY MTG BRAKET FOR RADIATOR	TATA spare parts
410350400106	ASSY BKT RADIATOR MTG LOWER RH	TATA spare parts
410350400107	RUBBERIZED O CLAMP (DIA76.2)	TATA spare parts
410350400108	RUBBERIZED O CLAMP (ID 45)	TATA spare parts
410350400109	P CLAMP (58 ID)	TATA spare parts
410350400114	ASSY MOUNTING BKT (RADIATOR LH SIDE)	TATA spare parts
410350400115	BRACKET ASSY COOLING PIPES	TATA spare parts
410350400118	BASE BRACKET	TATA spare parts
410350400119	SUPPORT TUBE	TATA spare parts
410350400121	BRACKET ASSY	TATA spare parts
410350400122	BRACKET ASSY	TATA spare parts
410350400123	BRACKET ASSY	TATA spare parts
410350403301	BRACKET RADIATOR MTG RH SIDE	TATA spare parts

410350403302	SUPPORT BKT (RADIATOR TO OIL COOLER PIPE	TATA spare parts
410350403304	SUPPORT BKT-PIPE INTERCOOLER TO ENGINE	TATA spare parts
410350403307	BRACKET-PIPE SURGE TANK MTG	TATA spare parts
410350403309	SUPPORT BKT (RADIATOR TO OILCOOLER PIPE)	TATA spare parts
410350403313	RADIATOR MTG BRACKET RH BOTTOM SIDE	TATA spare parts
410350403323	BRACKET (INTERCOOLER TO ENGINE PIPE)	TATA spare parts
410350403324	BRACKET SURGE TANK PIPE MTG	TATA spare parts
410350403325	BRACKET LCL MOUNTING	TATA spare parts
410350403350	BRACKET (RADIATOR MTG LH)	TATA spare parts
410350403366	GUSSET	TATA spare parts
410350506301	FAN SHROUD (COOLING SYSTEM)	TATA spare parts
410350506304	FAN & SHROUD ASSY	TATA spare parts
410350508201	FAN SHAROUD	TATA spare parts
410350606801	ENGINE HEATING UNIT CONNECTOR (1/2 NPTF)	TATA spare parts
410350606803	ENGINE HEATING UNIT CONNECTOR (1/2 NPTF)	TATA spare parts
410350996801	CONNECTOR THERMOSTAT BYPASS	TATA spare parts
410351000105	ASSY REAR STRUCTURE COMPLETE LH	TATA spare parts
410351000108	ASSY REAR STREUCTURE MIDDLE	TATA spare parts
410351000109	ASSY REAR TUBULAR STRUCTURE	TATA spare parts
410351000111	ASSY REAR OUTRIGGER(WITH HEATSHEILD)	TATA spare parts
410351000116	ASSY REAR OUTRIGGER WITH HEAT SHIELD	TATA spare parts
410351100112	DUST SHIELD RADIATOR BOTTOM	TATA spare parts
410351100188	ASSY DUST SHIELD (RADIATOR BOTTOM)	TATA spare parts
410351200129	ASSY BRKT A/C COMP MTG	TATA spare parts
410351200135	ASSYOUTRIGGERREARRH	TATA spare parts
410351200136	ASSY OUTRIGGER FRONT RH	TATA spare parts
410351200137	ASSY OUTRIGGER FRONT LH	TATA spare parts
410351200138	ASSY OUTRIGGER REAR LH	TATA spare parts
410351200139	ASSY AC COMPRESSOR MTG BKT	TATA spare parts
410351200141	ASSY L-BKT (REAR LH BOX OUTRIGGER)	TATA spare parts
410351200146	SUPPORT STRCTURE (AIR TANK MTG.)	TATA spare parts
410351200156	ELECTRIC PANEL UNIT MTG BKT	TATA spare parts
410351200165	ASSY OUTRIGGER FRONT RH	TATA spare parts
410351200166	SUPPORT STRUCTURE (AIR TANK MTG.)	TATA spare parts
410351200172	OUTRIGGER ASSY	TATA spare parts
410351200185	L TYPE ASSY OUTTRIGER (180 X 75 X 10)	TATA spare parts
410351200234	ASSY OUTRIGGER REAR LH	TATA spare parts
410351200237	ASSY TUBULAR STRUCTURE	TATA spare parts
410351200241	ASSY OUTRIGGER REAR-RH	TATA spare parts
410351200255	OUTRIGGER ASSY,RH	TATA spare parts
410351200256	OUTRIGGER ASSY,LH	TATA spare parts
410351200264	TUBULAR STRUCTURE ASSY-REAR BS6	TATA spare parts
410351207502	PVC TRIM	TATA spare parts
410351208255	HARNESS CLAMP	TATA spare parts
410351210101	REAR RH OUTTRIGGER ASSY BS6	TATA spare parts
410351210103	REAR TUBULAR STRUCTURE ASSY	TATA spare parts
410354000106	ASSY. KIT FIRE DETECTION SYS	TATA spare parts

410354100100	ASSY. BATT. CABLE +VE(STR MOTOR)	TATA spare parts
410354100103	ASSY. BATT. CABLE +VE(CUT OFF SW)	TATA spare parts
410354100104	ASSY. BATT. CABLE +VE 700MM (CUTOFF SW)	TATA spare parts
410354100105	BATTERY CUT-OFF SW. TO FUSE BOX CABLE	TATA spare parts
410354100106	CONTINENTAL CLUSTER MOUNTING FRAME	TATA spare parts
410354100108	BATTERY +VE CABLE	TATA spare parts
410354100109	ASSY FRONT PANEL FOR ELECTRICAL ITEMS	TATA spare parts
410354100110	ELECTRICAL HARNESS MNTG L-BKT.	TATA spare parts
410354100117	ASSY. MOUNTING FRAME FOR TCM AND MUX	TATA spare parts
410354100123	ASSY. BATT. CABLE +VE 1100MM (CUTOFF SW)	TATA spare parts
410354100136	WEATHER PROOF BACK BOX	TATA spare parts
410354100137	JUNCTION BOX	TATA spare parts
410354100138	ASSY. CONTROL PANEL 3 ZONE	TATA spare parts
410354100139	END OF LINE (E.O.L)	TATA spare parts
410354100146	CUT-OFF SW. CABLE	TATA spare parts
410354100147	ASSY. BATT. CABLE LINK 400MM	TATA spare parts
410354100148	ASSY BATTERY CABLE +VE 1800MM	TATA spare parts
410354100149	ASSY BATT. CABLE +VE WITH HDPE SLEEVE	TATA spare parts
410354100150	ASSY CABLE +VE WITH HDPE SLEEVE	TATA spare parts
410354100154	ASSY. BATT. CABLE +VE (STR. MOT.)	TATA spare parts
410354100156	ASSY BATTERY CABLE LINK(+VE)FOR MEGA FUS	TATA spare parts
410354100157	ASSY BATTERY CABLE	TATA spare parts
410354100158	ASSY CUT-OFF SW. CABLE	TATA spare parts
410354100159	BATTERY CABLE (+VE) TO MEGA FUSE	TATA spare parts
410354100160	BATT CABLE +VE MEGA FUSE TO CUT OFF SW.	TATA spare parts
410354100161	BATT CABLE (+VE) FOR CUTOFF SW	TATA spare parts
410354100162	BATT CABLE +VE MEGA FUSE TO MENBER CUT O	TATA spare parts
410354100163	BATT CABLE VE CUTOFF SW (MENBER) TO STAR	TATA spare parts
410354100164	CABLE +VE ALT 1 TO ALT 2	TATA spare parts
410354100165	CABLE +VE ALT 1 TO CUT OFF SW	TATA spare parts
410354100167	ASSY OF HOUR METER MTG. BOX	TATA spare parts
410354100168	BATT CABLE +VE CUTOFF SW (MENBER) TO ST	TATA spare parts
410354100172	KIT HORN CONTACT PIN HOLDER	TATA spare parts
410354100173	ASSY. HORN PIN HOLDER WITH WIRE	TATA spare parts
410354100175	CABLE +VE ALT 1 TO CUT OFF SW	TATA spare parts
410354100177	BATT CABLE +VE	TATA spare parts
410354100183	BATT CABLE +VE	TATA spare parts
410354100186	BATT. CABLE +VE TO MEGA FUSE BS6	TATA spare parts
410354100187	BATT CABLE (+VE) FOR RBCS TO MBCS	TATA spare parts
410354100194	ASSY. BATT. CABLE LINK 305MM	TATA spare parts
410354100196	ASSY. BATT. CABLE LINK 400MM	TATA spare parts
410354100201	BATTERY CABLE + VE CUT-OFF SW TO M FUSE	TATA spare parts
410354103301	SUPPORT BRACKET-FRONT (BATTERY MOUNTING	TATA spare parts
410354103303	HARNESS HOLDING BKT-1 (LH)	TATA spare parts
410354103304	HARNESS HOLD BKT-1(RH)	TATA spare parts
410354103305	HARNESS HOLDING BKT-2(RH)	TATA spare parts
410354103306	HARNESS HOLD BKT-3 (LH)	TATA spare parts

410354103307	HARNESS HOLD BKT-2(LH)	TATA spare parts
410354103308	HARNESS HOLD BKT-3(RH)	TATA spare parts
410354103309	HARNESS HOLDING BKT-3 (LH)	TATA spare parts
410354103310	HARNESS BKT TRANSMISSION	TATA spare parts
410354103311	HARNESS BKT MIDDLE-2	TATA spare parts
410354103312	HARNESS HOLDING BKT 4(LH)	TATA spare parts
410354103313	HARNESS HOLDING BKT-2 (LH)	TATA spare parts
410354103314	HARNESS HOLDING BKT-3 (LH)	TATA spare parts
410354103315	HOOTER MTG. BKT. (FIRE DETECTION SYS.)	TATA spare parts
410354103316	HOLDING BRACKET- HARNESS	TATA spare parts
410354103317	HOLDING BRACKET-BATT CABLE	TATA spare parts
410354103318	MTG BRACKET FOR BATT CUT OFF SW	TATA spare parts
410354104201	METALIC CLAMP-RUBBER COATED	TATA spare parts
410354104901	REAR SWITCHES MTG. BOX	TATA spare parts
410354104904	MOUNTING BRACKET FOR HOUR METER	TATA spare parts
410354107501	BATTERY TERMINAL CAP (POS)	TATA spare parts
410354107502	BATTERY TERMINAL CAP (NEG)	TATA spare parts
410354107503	BATTER TERMINAL CAP(POS)	TATA spare parts
410354107504	BATTERY TERMINAL CAP -VE	TATA spare parts
410354107507	WIRE SEAL (1 SQMM)	TATA spare parts
410354107508	TERMINAL CAP (POS)	TATA spare parts
410354107509	TERMINAL CAP (NEG)	TATA spare parts
410354107701	MICA SHEET POWER SUPPLY SPLITTER BS6-PH2	TATA spare parts
410354107702	ROUND DUMMY CAP	TATA spare parts
410354107703	AUTO CANCELLATION ROTER	TATA spare parts
410354107704	HORN CONT HOLDER	TATA spare parts
410354108204	TCM & MUX MOUNTING PLATE	TATA spare parts
410354108205	MOUNTING BRACKET LH FOR INST. CLUSTER	TATA spare parts
410354108206	MTG.BRKT.FOR DEUTSCH CONN	TATA spare parts
410354108208	ASSY REAR PLATE FOR ELECTRICAL ITEMS	TATA spare parts
410354108209	SUPPORT BRKT FOR REAR ASSY PLATE	TATA spare parts
410354108210	CLAMP	TATA spare parts
410354108211	CLAMP	TATA spare parts
410354108212	CLAMP	TATA spare parts
410354108213	WIRING HARNESS CLAMP	TATA spare parts
410354108214	CLAMP	TATA spare parts
410354108217	HARNESS SHIELD-1	TATA spare parts
410354108218	HARNESS SHIELD-2	TATA spare parts
410354108219	BRACKET	TATA spare parts
410354108220	CLAMP	TATA spare parts
410354108221	CLAMP	TATA spare parts
410354108223	CLAMP	TATA spare parts
410354108224	CLAMP	TATA spare parts
410354108225	CLAMP	TATA spare parts
410354108226	L BRACKET 85X70MM BATTERY CABLE	TATA spare parts
410354108227	L BRACKET 70X30MM BATTERY CABLE	TATA spare parts
410354108228	L BRACKET 120X60 BATTERY CABLE	TATA spare parts



410354108232	WH CLIP MOUNTING L TWIST BRKT	TATA spare parts
410354108233	WH_CLIP_MOUNTING_L_BRKT	TATA spare parts
410354108235	TUBULAR CHANNEL FOR BATT CLAMPING	TATA spare parts
410354108236	W/H ROUTING RING	TATA spare parts
410354108237	TOP CLAMP FOR BATTERY WITH RUBBER PAD	TATA spare parts
410354108240	MTG BRKT FOR SIX POLE MAXI FUSE BOX	TATA spare parts
410354108245	SNAP TIE MOUNTING BKT FOR DOSING UNIT WH	TATA spare parts
410354108246	SNAP TIE MOUNTING BKT FOR DOSING UNIT WH	TATA spare parts
410354108249	CABLE HOLDING BRACKET	TATA spare parts
410354108250	W/H ROUTING RING DIA 100 BS6	TATA spare parts
410354108801	POWER SUPPLY SPLITTER	TATA spare parts
410354109935	FUSE BOX BASE OT NON AC	TATA spare parts
410354109937	FUSE BOX BASE OT AC	TATA spare parts
410354109942	FUSE BOX BASE NT BS 4	TATA spare parts
410354109944	FUSE BOX COVER OT NON AC	TATA spare parts
410354109946	FUSE BOX COVER OT AC	TATA spare parts
410354109951	FUSE BOX COVER NT BS 4	TATA spare parts
410354109956	FUSE BOX BASE NT BS 3	TATA spare parts
410354109960	FUSE BOX COVER NT BS 3	TATA spare parts
410354109962	INLINE FUSE HOLDER FOR AUTO FUSE	TATA spare parts
410354109963	WIRE TER. FOR FEMALE CONNECTOR(1 SQ MM)	TATA spare parts
410354109964	WIRE TERMINAL FOR INLINE FUSE HOLDER (1	TATA spare parts
410354109965	WIRE TER. FOR MALE CONNECTOR(1 SQ MM)	TATA spare parts
410354109966	MALE CONNECTOR 3 POLE (WATER PROOF)	TATA spare parts
410354110100	ASSY. BATT. CABLE -VE(STR MOTOR)	TATA spare parts
410354110101	ASSY. BATTERY CABLE -VE	TATA spare parts
410354110102	ASSY. BATTERY CABLE -VE	TATA spare parts
410354110105	ASSY. BATT. CABLE -VE 70SQMM	TATA spare parts
410354110106	ASSY. BATT. CABLE -VE 35 SQMM	TATA spare parts
410354110107	ASSY BATTERY CABLE -VE 1800MM	TATA spare parts
410354110108	ASSY BATTERY CABLE -VE	TATA spare parts
410354110109	ASSY BATTERY CABLE LINK -VE FOR MEGA FUS	TATA spare parts
410354110110	CABLE -VE ALT 1 TO ALT 2	TATA spare parts
410354110111	CABLE -VE ALT 1 NEGATIVE HOLE ON LM	TATA spare parts
410354110118	CABLE -VE FOR BODY	TATA spare parts
410354110139	BATTERY CABLE -VE ALT 1 TO ST MOTOR	TATA spare parts
410354110141	BATTERY CABLE -VE ALT 1 TO ST MOTOR	TATA spare parts
410354110143	CABLE FOR POWER SUPPLY AND GROUND	TATA spare parts
410354120103	ASSY. CABLE ALTERNATOR-1 +VE	TATA spare parts
410354200102	KIT CNG PRESS. TRANS.WITH VOLT O/P	TATA spare parts
410354200108	INSTRUMENT CLUSTER MIDLINE LPO 1624 RELE	TATA spare parts
410354200110	ASSY HOOTER/STROBE	TATA spare parts
410354200111	INSTRUMENT CLUSTER MIDLINE LPO 1624 RELE	TATA spare parts
410354200113	INSTRUMENT CLUSTER MID-LINE FOR LPO 1924	TATA spare parts
410354200115	INSTRUMENT CLUSTER MID-LINE	TATA spare parts
410354203301	BRKT-1 FOR WIRE HARNESS HLDG	TATA spare parts
410354203302	BKT-2 FOR WIRE HARNESS HLDG	TATA spare parts

410354203303	BKT-3 FOR WIRE HARNESS HLDG	TATA spare parts
410354203304	TRNS HOSE TWIST BKT	TATA spare parts
410354203305	PLATE FOR BKT HLDG	TATA spare parts
410354203307	BRACKET TPMS UNIT MTG	TATA spare parts
410354204901	AIR PRESS. SENSOR	TATA spare parts
410354208202	OBD-II CONNECTOR MOUNTING PLATE	TATA spare parts
410354209900	INST.CLUSTER LPO1623/63CNG BSIII	TATA spare parts
410354209901	ELECT. SPPEDOMETER-15646 PULSES/KM	TATA spare parts
410354209902	ELECT RPM 592HZ W/O LCD HOUR METER	TATA spare parts
410354209903	INST. CLUSTER WITH ELEC.SPEEDO	TATA spare parts
410354209904	INSTRUMENT CLUSTER FOR LE1618 AUTO TRANS	TATA spare parts
410354209907	INSTRUMENT CLUSTER FOR LPO1624RE ATS&ABS	TATA spare parts
410354209919	BATTERY CUT OFF SW. RELAY OPERATED BS3/4	TATA spare parts
410354209920	ELECT. SPEEDOMETER(16190 PULSES/KM)	TATA spare parts
410354209935	HORN CONTACT PIN	TATA spare parts
410354304904	CBCU-E CONTINENTAL	TATA spare parts
410354304905	MUX-2B CONTINENTAL BS3/4	TATA spare parts
410354304909	STARTER MOTOR 24V WITH TCO	TATA spare parts
410354304913	FRONT BRAKE PAD WEAR INDICATOR WITH MERI	TATA spare parts
410354304914	RESISTOR ASSY -250 OHM 5W	TATA spare parts
410354304915	DIODE ASSY 6AMP	TATA spare parts
410354304917	DIODE ASSY 1AMP	TATA spare parts
410354309901	TEMP. TRANSDUCER-ENG. OIL	TATA spare parts
410354309902	BUSHING SENSOR	TATA spare parts
410354309904	BI-POLAR TEMPERATURE TRANSDUCER	TATA spare parts
410354309905	SPARK PLUG	TATA spare parts
410354400101	ASSY HEAD LAMP WITH LEVEL MOTOR 24V RH	TATA spare parts
410354400102	ASSY HEAD LAMP WITH LEVEL MOTOR 24V LH	TATA spare parts
410354400103	ASSY HEAD LAMP WITH LEVEL MOTOR 24V RH	TATA spare parts
410354400104	ASSY HEAD LAMP WITH LEVEL MOTOR 24V LH	TATA spare parts
410354400105	ASSY BI-POLAR ENGINE LAMP	TATA spare parts
410354400106	ASSY TAIL LAMP RH	TATA spare parts
410354400107	ASSY TAIL LAMP LH	TATA spare parts
410354400109	BIPOLAR ENGINE LAMP WITH SWITCH	TATA spare parts
410354400121	HEADLAMP ASSY LH	TATA spare parts
410354400122	HEADLAMP ASSY RH	TATA spare parts
410354400123	CABIN LAMP ASSY	TATA spare parts
410354408101	SNAP TIE	TATA spare parts
410354408103	MOUNTING BRACKET OF CUT OFF SW	TATA spare parts
410354500107	ASSYF.BOX(14P)WTPIGTAIL(218654660111)	TATA spare parts
410354500109	ASSYF.BOX(14P)WTPIGTAIL(410354660100)	TATA spare parts
410354500114	ASSYF.BOX(14P)WTPIGTAIL(410354660157)	TATA spare parts
410354500120	ASSYF.BOX(14P)WTPIGTAIL(410354660111)	TATA spare parts
410354500126	EMERGENCY HELP SWITCH ASSY	TATA spare parts
410354504905	ELECTRICAL BATTERY CUT OFF SWITCH ASSY	TATA spare parts
410354506302	ADAPTER BS6	TATA spare parts
410354506917	KNEELING FRONT LO CURR SW.	TATA spare parts

410354506918	KNEELING REAR LO CUR SW.	TATA spare parts
410354506919	KNEELING BOTH LO CURR SW.	TATA spare parts
410354506920	ENGINE SD OR LO CURR. SW.	TATA spare parts
410354506921	REAR FOG LAMP LO CURR. SW.	TATA spare parts
410354506922	FRONT FOG LAMP LO CURR SW.	TATA spare parts
410354506923	BATT CUT-OFF LO CURR SW (RED)	TATA spare parts
410354506924	ALARM RESET LO CURR. SW.	TATA spare parts
410354506925	RETARDER ON LOW CURR. SW.	TATA spare parts
410354506926	ENGINE LAMP LOW CURR SW.	TATA spare parts
410354506927	EMERGENCY IGNITION LO CURR.SW.	TATA spare parts
410354506928	EMER. START LO CURR. SW	TATA spare parts
410354506941	EXHAUST BRAKE SW. LO CURRENT- MARQUARDT	TATA spare parts
410354506942	STG WHEEL ADJ LOW CURRENT SW. MARQUARDT	TATA spare parts
410354509904	BLADE TYPE FUSE 20AMP	TATA spare parts
410354509905	400 AMP MEGA FUSE BS1/2/3/4/6	TATA spare parts
410354509906	FLEX- MEGA FUSE HOLDER	TATA spare parts
410354509908	STARTER PREVENTION SWITCH	TATA spare parts
410354509915	HOUSING ASSY BS6	TATA spare parts
410354510101	ASSY LOW CURRENT COMBI-SW.	TATA spare parts
410354510102	ASSY LOW CURRENT COMBI-SW.	TATA spare parts
410354600101	PIGTAIL FOR HORN WITH BLADE TERMINAL	TATA spare parts
410354600104	PIGTAIL FOR MARQUARDT SWITCHES	TATA spare parts
410354600105	AIR PRESSURE SENSOR-PIGTAIL	TATA spare parts
410354600106	W/H ENGINE SIGNAL-LPO1624 RE BSIII	TATA spare parts
410354600114	PIGTAIL FOR GPS CONN	TATA spare parts
410354600116	BRAKE PAD WEAR IND. HARNESS	TATA spare parts
410354600123	DIMMER SW. WH	TATA spare parts
410354600125	BRAKE PAD WEAR IND. PLUG	TATA spare parts
410354600131	WH ENGINE POWER SUPPLY-LPO1624 RE BSIII	TATA spare parts
410354600133	PIGTAIL FOR BATT.CUT OFF SW.	TATA spare parts
410354600137	WIRING HARNESS MAIN	TATA spare parts
410354600139	WIRING HARNESS CENTER	TATA spare parts
410354600151	LHDS CABLE 138C ENGINE AREA	TATA spare parts
410354600152	LHDS CABLE 88C FUSE BOX AREA	TATA spare parts
410354600154	PIGTAIL - EXHAUST BRAKE SOLENOID	TATA spare parts
410354600157	ADD ON TWISTED PAIR WIRING SENSOR HARNES	TATA spare parts
410354600158	PIGTAIL FOR BATT. CHARGING	TATA spare parts
410354600159	BRAKE PAD WEAR SENSOR WIRING HARNESS	TATA spare parts
410354600161	DISC BRAKE WEAR SENSOR CABLE	TATA spare parts
410354600162	PIGTAIL STARTER PREVENTION SWITCH	TATA spare parts
410354600163	WIRING HARNESS REAR BRAKE PAD WEAR SENSO	TATA spare parts
410354600175	PIGTAIL FOR STARTER MOTOR	TATA spare parts
410354600181	PIGTAIL FOR HOURMETER	TATA spare parts
410354600187	W/H - MERITOR FRONT BRAKE PAD WEAR SENSO	TATA spare parts
410354600189	PIGTAIL FOR ELECTRONIC HORN	TATA spare parts
410354600203	WIRING HARNESS AUTO TRANSMISSION	TATA spare parts
410354600207	WIRING HARNESS MAIN	TATA spare parts

410354600209	WIRING HARNESS P-CAN	TATA spare parts
410354600211	WIRING HARNESS	TATA spare parts
410354606305	6 POLE MAXI FUSE BOX ASSY	TATA spare parts
410354607501	PROTECTIVE BOOT (AT STARTER MOTOR TR.)	TATA spare parts
410354610101	CAN PIGTAIL	TATA spare parts
410354610110	WIRING HARNESS TAIL	TATA spare parts
410354610118	W/H ITS	TATA spare parts
410354610123	KIT WIRING HARNESS (RELE)	TATA spare parts
410354610154	WIRING HARNESS SWITCH BS6	TATA spare parts
410354610155	WIRING HARNESS MAIN BS6	TATA spare parts
410354610156	WIRING HARNESS CAN BS6	TATA spare parts
410354610159	WIRING HARNESS ACCELERATOR PEDALBS6	TATA spare parts
410354610160	WIRING HARNESS AUTO TRANSMISSION BS6	TATA spare parts
410354610161	WIRING HARNESS TAIL BS6	TATA spare parts
410354610162	WIRING HARNESS MAXIFUSE TO ALTB6	TATA spare parts
410354610164	WIRING HARNESS CUT-OFF SW TO FUSEBOX IP	TATA spare parts
410354610165	CABLE BS6	TATA spare parts
410354610166	W/H CENTER BS6	TATA spare parts
410354610168	W/H CNG PRES AND IGNITION KILL SYSTEM BS	TATA spare parts
410354610169	WIRING HARNESS REVERSE PARK ASSIST BS6	TATA spare parts
410354610171	WIRING HARNESS EMS SIGNAL BS6	TATA spare parts
410354610172	WIRING HARNESS GAS LEAK INDICATOR BS6	TATA spare parts
410354610173	CABLE BATTERY -VE BS6	TATA spare parts
410354610174	CAN PIGTAIL-GPS BS6	TATA spare parts
410354610181	WIRING HARNESS TAIL BS6	TATA spare parts
410354620101	WIRING HARNESS MAIN	TATA spare parts
410354620102	WIRING HARNESS TAIL	TATA spare parts
410354620103	WIRING HARNESS CENTER	TATA spare parts
410354620104	WIRING HARNESS P-CAN	TATA spare parts
410354620105	WH ICAN RE CNG BSIV	TATA spare parts
410354620106	WH MAIN RE DIESEL BS-IV	TATA spare parts
410354620107	WH CENTER RE DIESEL BS-IV	TATA spare parts
410354620108	WH TAIL RE DIESEL BS-IV	TATA spare parts
410354620109	WH PCAN RE DIESEL BS-IV	TATA spare parts
410354620110	WH TAIL RE DIESEL BS-III	TATA spare parts
410354620111	W/H SWITCH	TATA spare parts
410354660100	W/H TAIL	TATA spare parts
410354660101	W/H ELEC. ACC. PEDAL	TATA spare parts
410354660102	W/H CNG CLUT. SOLENOID	TATA spare parts
410354660103	ELECT. ACC. PEDAL PIGTAIL	TATA spare parts
410354660104	W/H MAIN LE1618 RE DIESEL; ELEC.SPEEDO	TATA spare parts
410354660105	W/H TAIL LE1618 RE DIESEL ELEC.SPEEDO	TATA spare parts
410354660106	W/H BODY LE1618 RE DIESEL BSIII	TATA spare parts
410354660110	W/H MAIN CONTINENTAL MULTIPLEX SYSTEM	TATA spare parts
410354660111	W/H TAIL CONTINENTAL MULTIPLEX SYSTEM	TATA spare parts
410354660112	W/H BODY CONTINENTAL MULTIPLEX SYSTEM	TATA spare parts
410354660113	POWER SUPPLY CABLE 25 MM2	TATA spare parts

410354660114	GROUND CABLE 25MM2	TATA spare parts
410354660115	CAN BACKBONE HARNESS FOR MULTIPLEXING	TATA spare parts
410354660116	STARTER ALTERNATOR W/H FOR LPO 1623 DTC	TATA spare parts
410354660117	MCAN W/H -CONTINENTAL MULTIPLEX SYSTEM	TATA spare parts
410354660118	K-TYPE THERMOCOUPLE COMP. CABLES(CATCON	TATA spare parts
410354660128	W/H MAIN FOR LPO1624 RE MULIPLIX SYSTEM	TATA spare parts
410354660129	W/H BODY FOR LPO1624 RE MULTIPLEX SYSTEM	TATA spare parts
410354660130	W/H TAIL FOR LPO1624 RE MULTIPLEX SYSTEM	TATA spare parts
410354660131	ALTERNATOR NEGATIVE CABLE	TATA spare parts
410354660132	ALTERNATOR POSITIVE CABLE WITH 150A FUSE	TATA spare parts
410354660136	CAN BACK BONE FOR LPO 1624 RE BS-III	TATA spare parts
410354660140	WIRING HARNESS TAIL LPO-1624 BS-IV W/MUX	TATA spare parts
410354660141	W/H ENGINE POWER SUPPLY LPO1624 TC BS IV	TATA spare parts
410354660142	W/H TRANSMISSION-LPO1623 WITH MULTIPLEX	TATA spare parts
410354660143	W/H TRANSMISSION-LPO1624 WITH MULTIPLEX	TATA spare parts
410354660145	WIRING HARNESS MAIN LPO1624 RE MUX W/WT	TATA spare parts
410354660146	W/H HOOTER	TATA spare parts
410354660147	W/H POWER & ZONES	TATA spare parts
410354660148	BATTERY -VE CABLE	TATA spare parts
410354660154	W/H MAIN FOR LPO 1923 RE CNG LHD	TATA spare parts
410354660157	W/H TAIL FOR DTC BS IV	TATA spare parts
410354660158	W/H BODY FOR DTC BS IV	TATA spare parts
410354660159	CAN BACKBONE FOR LPO1923 RE CNG LHD	TATA spare parts
410354660160	WH MAIN FOR LPO 1924 RE LHD DIESEL BS-II	TATA spare parts
410354660161	WH BODY FOR LPO 1924 RE LHD DIESEL BS-II	TATA spare parts
410354660162	W/H TAIL FOR LPO 1623 RE CNG WITH BG PLU	TATA spare parts
410354660168	W/H-TYRE LH TO RH SIDE	TATA spare parts
410354660169	PIGTAIL FOR HOUR METER	TATA spare parts
410354660178	WH TAIL FOR LPO 1924 RE LHD BS-III DIESE	TATA spare parts
410354660191	W/H DOSING UNIT FOR LCCR REAR ENGINE	TATA spare parts
410354700103	BRACKET ASSY GAS LEAK DETECT SENSOR MTG	TATA spare parts
410354708203	BRACKET BS6	TATA spare parts
410354990102	KIT MULTIPLEXING	TATA spare parts
410354990124	RETRO KIT FOR 400AMP BATT POSITIVE FUSE	TATA spare parts
410354990130	ASSY KIT SPEED LIMITER AUTO TRANS	TATA spare parts
410354990144	KIT-RETRO FITMENT BATTERY CABLES	TATA spare parts
410354990145	KIT-RETRO FITMENT BATTERY CABLES	TATA spare parts
410358304003	STAINLESS STEEL PIPE 12X1 MM 3 MTR	TATA spare parts
410358304010	NOZZLES TYPE DN1	TATA spare parts
410358408201	CAUTION STICKER FOR EMERGENCY START/IGN	TATA spare parts
410358408202	TR. LABEL -(CAUTION -BHARAT STAGE IV)	TATA spare parts
410358408205	SPEED LIMIT LABEL BS6-PH2	TATA spare parts
410358408206	SPEED LIMIT LABEL BS6-PH2	TATA spare parts
410358409915	INSTRUCTIONS PLATE	TATA spare parts
410358904601	SERVO TESTER - REMOVAL AND FITMENT	TATA spare parts
410358904602	TONGUE FOR PISTON ASSEMBLY - REMOVAL AND	TATA spare parts
410358904603	ASSEMBLY VICE FOR STEERING GEAR	TATA spare parts

410358904604	TONGUE MEASURING DEVICE	TATA spare parts
410358904605	INSERT FOR TONGUE MEASURING DEVICE	TATA spare parts
410358904606	ENTRY BUSH FOR INPUT SHAFT SEAL	TATA spare parts
410358904607	SLEEVE FOR SHAFT SEAL	TATA spare parts
410360000101	ASSY DRIVER STATION	TATA spare parts
410360000109	ASSY DRIVER STATION	TATA spare parts
410360000116	ASSY DRIVER STATION COMPLETE	TATA spare parts
410360000170	DRIVER STATION ASSY WITH CED COATING	TATA spare parts
410360000171	ASSY DRIVER STATION COMPLETE	TATA spare parts
410360100155	ASSY ANGLE (AIR TANK MTG.)	TATA spare parts
410360100170	ASSY ANGLE (AIR TANK MTG)	TATA spare parts
410360106306	BALATA PACKING (DRIVER STATION)	TATA spare parts
410383403306	AC COMPRESSOR MTG BKT	TATA spare parts
410383406302	BANDED V-BELT (COMP TO ALTER)	TATA spare parts
410383407002	PULLEY ALTERNATOR 150A	TATA spare parts
410383554901	LOW PRESSURE SWITCH EXPORT	TATA spare parts
410383554902	HIGH PRESSURE SWITCH EXPORT	TATA spare parts
410391000101	ASSY DRIVER SEAT WITH HEAD REST	TATA spare parts
410391000102	ASSY DRIVER SEAT WITH HR FOR DTC BUS	TATA spare parts
410391000103	TYPE 1 BACKREST WITH RED VINYL SP/KIT	TATA spare parts
410391000104	TYPE II BACKREST WITH BLUE VINYL SP/KIT	TATA spare parts
410391000105	SEAT HEIGHT ADJUSTER MECH. KIT	TATA spare parts
410391000106	TYPE 1 HR WITH RED VINYL SPARE KIT	TATA spare parts
410391000107	TYPE II HR WITH BLUE VINYL SPARE KIT	TATA spare parts
410391000108	TYPE 1 CUSHION WITH RED VINYL SP/ KIT	TATA spare parts
410391000109	TYPE II CUSHION WITH BLUE VINYL SP/KIT	TATA spare parts
410391000110	SEAT SLIDER MECHANISM KIT WITH FASTNERS	TATA spare parts
410391000111	TYPE 1 BACKREST FOAM WITH RED VINYL	TATA spare parts
410391000112	TYPE 2 BACKREST FOAM WITH BLUE VINYL	TATA spare parts
410391000122	NEW ASSY DRIVER SEAT WITH HR (BLUE	TATA spare parts
410391000123	NEW ASSY DRIVER SEAT WITH HR (RED)	TATA spare parts
410391000124	TYPE-1 CUSHION FOAM WITH RED VINYL	TATA spare parts
410391000125	TYPE-2 CUSHION FOAM WITH BLUE VINYL	TATA spare parts
410391100101	ASSY SEAT STAND	TATA spare parts
410430100102	ACCELERATOR PEDAL ASSY	TATA spare parts
410432101606	BALL JOINT M8	TATA spare parts
410432103201	HEX. FL. BOLT M12X1.5X55-10.9	TATA spare parts
410432103203	HEX. FL. BOLT M14X1.5X105-10.9	TATA spare parts
410432103204	HEX. FL. BOLT M16X1.5X60-10.9	TATA spare parts
410432103205	HEX FL BOLT M20X1.5X60 - 10.9	TATA spare parts
410432103206	HEX FL BOLT M20X1.5X100-10.9	TATA spare parts
410432103207	HEX. FL. BOLT M20X1.5X110-10.9	TATA spare parts
410432103209	HEX FL BOLT M20X1.5X130-10.9	TATA spare parts
410432106501	HEX. FL. NUT M12X1.5 - 10 ISO12126	TATA spare parts
410432204903	PRESSURE SENSOR - ECAS	TATA spare parts
410432403201	HEX. FL. BOLT M16X1.5X150-10.9	TATA spare parts
410432403202	HEX. FL. BOLT M16X1.5X160 - 10.9	TATA spare parts

410432407117	SOLENOID VALVE BRK.3 AXLE COACH	TATA spare parts
410432416501	HEX. FL. NUT M18X1.5	TATA spare parts
410433105101	FRONT AXLE BEAM 7.5T 6.5 KPI	TATA spare parts
410433405501	WHEEL HUB FRONT (DISC BRAKE)	TATA spare parts
410433805102	TIE ROD ARM LH	TATA spare parts
410433805103	TIE ROD ARM RH	TATA spare parts
410439208801	WHEEL STUD	TATA spare parts
410442100107	DISC BRAKE LH	TATA spare parts
410442100108	DISC BRAKE RH	TATA spare parts
410442100109	CONTINUOUS WEARSONSORMERITOR1500MM	TATA spare parts
410442103703	ROTOR	TATA spare parts
410442990102	KIT BRAKE PAD	TATA spare parts
410442990108	BUSH	TATA spare parts
410446600105	STG OIL RESERVOIR	TATA spare parts
410447606804	CONNECTOR BS6	TATA spare parts
410449200144	ASSY RUBBER BUFFER -EXHAUST SYSTEM	TATA spare parts
410450105810	HOSE (RETARDER IN)	TATA spare parts
410450400117	ASSY CLAMP	TATA spare parts
410451208217	L-BRACKET BS6-PH2	TATA spare parts
410454200107	TFT DISPLAY UNIT	TATA spare parts
410454209911	ADAPTOR - BRAKE PAD WEAR INDICATOR	TATA spare parts
410454209912	ADAPTER - DIMMER SWITCH	TATA spare parts
410454209913	ADAPTER - HAZARD SWITCH	TATA spare parts
410454209914	ADAPTER - DUMMY COVER	TATA spare parts
410454209915	ADAPTER - BRAKE PAD WEAR INDICATOR	TATA spare parts
410454500101	REAR SWITCH MTG BOX	TATA spare parts
410454504901	PIANO KEY SWITCH REAR ENGINE START	TATA spare parts
410454504902	PIANO KEY SWITCH REAR ENGINE STOP	TATA spare parts
410454507101	PLATE SWITCH MTG	TATA spare parts
410460208224	L BKT (GSL MTG) BS6	TATA spare parts
4104821	RESISTOR CORROSION	TATA spare parts
4104822	FILTER FUEL	TATA spare parts
410524200101	BRACKET ASSY ENGINE MTG TOP REAR-LH	TATA spare parts
410524200102	BRACKET ASSY FRAME SIDE LH	TATA spare parts
410524200105	ENGINE MOUNT ASSY REAR BS6	TATA spare parts
410524203705	ENGINE MTG ARM RH BS6	TATA spare parts
410524203706	ENGINE MTG ARM RH BS6	TATA spare parts
410526800101	TURNING TUBE ASSY	TATA spare parts
410526800104	GEAR SHIFT LEVER ASSY WITH SHIFT YOKE	TATA spare parts
410526800110	GEARSHIFTLEVERASSYWITHSHIFTYOKE BS6	TATA spare parts
410526813701	BRACKET GEAR SHIFT LEVER MTG	TATA spare parts
410529100101	BUNDY TUBE ASSY CLUTCH PIPE	TATA spare parts
410529300102	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
410529300105	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
410531000102	FRAME ASSY WITH FITMENT	TATA spare parts
410531000103	FRAME ASSY WITH FITMENT BS6	TATA spare parts
410531000107	FRAME ASSY WITH FITMENT	TATA spare parts

410531000110	FRAME ASSY WITH FITMENT	TATA spare parts
410531000112	FRAME ASSY WITH FITMENT	TATA spare parts
410531000114	FRAME ASSY WITH FITMENT	TATA spare parts
410531000122	FRAME ASSY WITH FITMENT BS6	TATA spare parts
410531000125	FRAME ASSY WITH FITMENT BS6	TATA spare parts
410531000130	FRAME ASSY WITH FITMENT BS6	TATA spare parts
410531000133	FRAME ASSY WITH FITMENT BS6	TATA spare parts
410531000150	FRAME ASSY WITH FITMENT	TATA spare parts
410531000152	FRAME ASSY WITH FITMENT BS6	TATA spare parts
410531000154	FRAME ASSY WITH FITMENT BS6	TATA spare parts
410531200101	ASSY. BRACKET RH BS4	TATA spare parts
410531200102	ASSY. BRACKET LH BS4	TATA spare parts
410531200103	CROSS MEMBER ASSY	TATA spare parts
410531200106	CROSS MEMBER ASSY BS6	TATA spare parts
410531200110	CROSS MEMBER ASSY SHOCK ABSORBER MTG BS6	TATA spare parts
410531200114	BRACKET ASSY CROSS MEMBER MTG BS6	TATA spare parts
410531200116	CROSS MEMBER ASSY BS6	TATA spare parts
410531200117	CROSSMEMBERASSY BS6	TATA spare parts
410531200120	SUPPORT ASSY ENGINE CROSS MEMBER BS6	TATA spare parts
410531200121	CROSS MEMBER ASSY TUBULAR BS6	TATA spare parts
410531207104	CROSS MEMBER REAR BUMPER BS6	TATA spare parts
410531207106	CROSS MEMBER BUMPER BS6	TATA spare parts
410531207111	SUPPORT CROSS MEMBER MTG RH BS6	TATA spare parts
410531207112	SUPPORT CROSS MEMBER MTG LH BS6	TATA spare parts
410531300102	GUSSET ASSY RH BS6	TATA spare parts
410531300103	GUSSET ASSY LH BS6	TATA spare parts
410531300108	REINFORCEMENT ASSY TOW HOOK LH BS6	TATA spare parts
410531308201	REINFORCEMENT RH BS6	TATA spare parts
410531308202	REINFORCEMENT LH BS6	TATA spare parts
410531308206	L-REINFORCEMENT BS6	TATA spare parts
410531308207	L-REINFORCEMENTBOTTOM-LH BS6	TATA spare parts
410531308215	L-REINFORCEMENT TOP-RH BS6	TATA spare parts
410531308216	L-REINFORCEMENT TOP-LH BS6	TATA spare parts
410531308224	REINFORCEMENT FRONT-BOTTOM-RH BS6	TATA spare parts
410531308225	REINFORCEMENT FRONT-BOTTOM-LH BS6	TATA spare parts
410531308226	REINFORCEMENT FRONT SPRING BKT REAR-RH B	TATA spare parts
410531308227	REINFORCEMENT FRONT SPRING BKT REAR-LH B	TATA spare parts
410531308228	SUPPORTCROSSMEMBERMTGRH BS6	TATA spare parts
410531308229	SUPPORTCROSSMEMBERMTGLH BS6	TATA spare parts
410531707101	PLATE TOW HOOK FRONT BS6	TATA spare parts
410532100101	LEAF SPRING ASSY FRONT BS6	TATA spare parts
410532100102	LEAF SPRING ASSY FRONT BS6	TATA spare parts
410532100104	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
410532100106	BRACKET ASSY SPRING HANGER REAR BS6	TATA spare parts
410532100107	PARABOLIC LEAF SPRING ASSY FRONT BS6	TATA spare parts
410532100108	PARABOLIC LEAF SPRING ASSY FRONT BS6	TATA spare parts
410532100109	1STLEAFASSYWITHBUSH BS6	TATA spare parts



410532100111	RUBBER BLOCK ASSY FRONT BS6	TATA spare parts
410532100112	BRACKET ASSY BUMP STOPPER BS6	TATA spare parts
410532100114	BRACKET ASSY BUMP STOPPER BS6	TATA spare parts
410532100123	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
410532100125	PARABOLIC LEAF SPRING ASSY FRONT BS6	TATA spare parts
410532100126	PARABOLIC LEAF SPRING ASSY FRONT BS6	TATA spare parts
410532103202	CENTER BOLT BS6	TATA spare parts
410532103203	CENTER BOLT BS6	TATA spare parts
410532103702	BRACKET SPRING HANGER FRONT BS6	TATA spare parts
410532103703	BRACKET SPRING HANGER FRONT-REAR BS6	TATA spare parts
410532103705	BRACKET FRONT SPRING HANGER BS6	TATA spare parts
410532103706	BRACKET FRONT SPRING HANGER REAR-LH BS6	TATA spare parts
410532103707	BRACKET FRONT SPRING HANGER REAR-RH BS6	TATA spare parts
410532104204	U-BOLT BS6-PH2	TATA spare parts
410532104205	U-BOLT BS6	TATA spare parts
410532104207	U-CLAMP FRONT BS6-PH2	TATA spare parts
410532104301	SPRING CLIP BS6	TATA spare parts
410532107102	2ND LEAF BS6	TATA spare parts
410532107103	3RD LEAF BS6	TATA spare parts
410532107104	SPACER BS6	TATA spare parts
410532107110	2NDLEAF BS6	TATA spare parts
410532107111	3RDLEAF BS6	TATA spare parts
410532107112	4THLEAF BS6	TATA spare parts
410532107113	5THLEAF BS6	TATA spare parts
410532107114	6THLEAF BS6	TATA spare parts
410532107115	7THLEAF BS6	TATA spare parts
410532107116	8THLEAF BS6	TATA spare parts
410532107117	9THLEAF BS6	TATA spare parts
410532107118	10THLEAF BS6	TATA spare parts
410532107119	11THLEAF BS6	TATA spare parts
410532107120	12THLEAF BS6	TATA spare parts
410532107123	SPACER BS6	TATA spare parts
410532107143	CASTER PLATE BS6	TATA spare parts
410532107150	1ST LEAF BS6	TATA spare parts
410532107151	2ND LEAF BS6	TATA spare parts
410532107152	3RD LEAF BS6	TATA spare parts
410532107153	4TH LEAF BS6	TATA spare parts
410532107155	CASTER PLATE BS6	TATA spare parts
410532107702	RUBBER BLOCK FRONT BS6	TATA spare parts
410532108301	CENTER LINER BS6	TATA spare parts
410532300101	BRACKET ASSY FRONT SHOCK ABSORBER MTG BS	TATA spare parts
410532303301	BRACKET SHOCK ABSORBER MTG BS6	TATA spare parts
410532400103	KIT-REAR AIR SUSPENSION	TATA spare parts
410532400104	PARALLEL LINK PIVOT & AIR SPRING BKT LH	TATA spare parts
410532400105	PARALLEL LINK PIVOT & AIR SPRING BKT RH	TATA spare parts
410532400106	CROSS MEMBER ASSY REAR AIR SPRING	TATA spare parts
410532400107	REAR AIR SPRING CROSS MEMBER FLITCH-LH	TATA spare parts

410532400108	REAR AIR SPRING CROSS MEMBER FLITCH-RH	TATA spare parts
410532400109	BRACKET ASSY REAR AIR SPRING MTG LH	TATA spare parts
410532400110	BRACKET ASSY REAR AIR SPRING MTG RH	TATA spare parts
410532400111	SUBFRAME & ANTI ROLL BAR ASSY	TATA spare parts
410532400112	PARALLEL LINK ASSY LH	TATA spare parts
410532400113	PARALLEL LINK ASSY RH	TATA spare parts
410532400117	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
410532400119	BRACKET ASSY SPRING HANGER REAR BS6	TATA spare parts
410532400122	PAD SPRING BS6	TATA spare parts
410532400123	PARABOLIC LEAF SPRING ASSY REAR BS6	TATA spare parts
410532400124	LEAF SPRING ASSY REAR BS6	TATA spare parts
410532400125	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
410532400127	RUBBER BLOCK ASSY REAR BS6	TATA spare parts
410532400128	KIT-REAR AIR SUSPENSION BS6	TATA spare parts
410532400130	SUBFRAMEASSYWITHANTIROLLBARASSY BS6	TATA spare parts
410532400131	GUSSETREARCROSSMEMBERLH BS6	TATA spare parts
410532400132	LINKASSYPIVOT-AIRSPRINGMTGLH BS6	TATA spare parts
410532400133	GUSSETREARCROSSMEMBERRH BS6	TATA spare parts
410532400134	LINKASSYPIVOT-AIRSPRINGMTGRH BS6	TATA spare parts
410532400135	BRACKETASSYREARAIRSPRINGMTGLH BS6	TATA spare parts
410532400136	BRACKETASSYREARAIRSPRINGRH BS6	TATA spare parts
410532400140	SUBFRAMEASSY BS6	TATA spare parts
410532400141	ANTIROLLBARASSY BS6	TATA spare parts
410532400147	SUPPORTBRACKETASSYLH BS6	TATA spare parts
410532400148	SUPPORTBRACKETASSYRH BS6	TATA spare parts
410532400149	PARABOLIC LEAF SPRING ASSY REAR	TATA spare parts
410532400151	AIR SPRING ASSY REAR BS6	TATA spare parts
410532400156	KIT-FRAME COMP ASSY AIR SUSPENSION	TATA spare parts
410532400157	KIT-ZERO STATION COMP AIR SUSPENSION	TATA spare parts
410532403203	CENTER BOLT BS6	TATA spare parts
410532403701	BRACKET REAR SPRING HANGER FRONT BS6	TATA spare parts
410532403702	BRACKET SPRING HANGER REAR BS6	TATA spare parts
410532403703	GUIDE PLATE BS6	TATA spare parts
410532404201	U-BOLT BS6	TATA spare parts
410532404204	U-BOLT BS6	TATA spare parts
410532404301	SPRING CLIP BS6	TATA spare parts
410532404303	CLAMP BS6	TATA spare parts
410532407101	REAR AIR SPRING CROSS MEMBER CROSS BEAM	TATA spare parts
410532407102	2ND LEAF BS6	TATA spare parts
410532407103	3RD LEAF BS6	TATA spare parts
410532407105	4TH LEAF BS6	TATA spare parts
410532407106	5TH LEAF BS6	TATA spare parts
410532407108	CASTER PLATE BS6	TATA spare parts
410532407109	PLATE SHACKLE BS6	TATA spare parts
410532407110	PLATE SHACKLE BS6	TATA spare parts
410532407111	1ST LEAF BS6	TATA spare parts
410532407112	2NDLEAF BS6	TATA spare parts

410532407113	3RDLEAF BS6	TATA spare parts
410532407114	4THLEAF BS6	TATA spare parts
410532407116	5THLEAF BS6	TATA spare parts
410532407117	6THLEAF BS6	TATA spare parts
410532407119	7THLEAF BS6	TATA spare parts
410532407120	8THLEAF BS6	TATA spare parts
410532407121	9THLEAF BS6	TATA spare parts
410532407124	10THLEAF BS6	TATA spare parts
410532407125	11THLEAF BS6	TATA spare parts
410532407126	12THLEAF BS6	TATA spare parts
410532407127	13THLEAF BS6	TATA spare parts
410532407128	14THLEAF BS6	TATA spare parts
410532407147	FLITCHFRONT-LH BS6	TATA spare parts
410532407148	FLITCHFRONT-RH BS6	TATA spare parts
410532407155	HANGERLINKMTGBKT BS6	TATA spare parts
410532407702	RUBBER BLOCK REAR BS6	TATA spare parts
410532408301	CENTER PADBS6	TATA spare parts
410532600102	SHOCK ABSORBER ASSY REAR BS6	TATA spare parts
410532800102	LINK ASSY BS6	TATA spare parts
410532800104	ANTI ROLL BAR ASSY BS6	TATA spare parts
410532800109	LINK ASSY ANTI ROLL BAR BS6	TATA spare parts
410532800112	RUBBER BUSH ASSY ANTI ROLL BAR BS6	TATA spare parts
410532803301	BRACKET¿BS6	TATA spare parts
410532803701	BRACKET ANTI ROLL BAR FRAME MTG BS6	TATA spare parts
410532803702	BRACKET ANTI ROLL BAR MTG LH BS6	TATA spare parts
410532803703	BRACKET ANTI ROLL BAR MTG RH BS6	TATA spare parts
410532807904	ANTI ROLL BAR BS6	TATA spare parts
410532903301	BRACKET ANTI ROLL BAR MTG LOWER BS6	TATA spare parts
410532906001	CONNECTING LINK BS6	TATA spare parts
410532950101	NYLON PIPE BUNCH ASSY RR AIR SUSPENSION	TATA spare parts
410533000101	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
410533000110	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
410533000111	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
410533000112	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
410533000117	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
410533000118	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
410533000120	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
410533105101	FRONT AXLE BEAM BS6	TATA spare parts
410533800101	TIE ROD ASSY BS6	TATA spare parts
410533800103	TIE ROD ASSY BS6	TATA spare parts
410533800104	TIE ROD ASSY	TATA spare parts
410533800105	TIE ROD ASSY BS6-PH2	TATA spare parts
410533805101	TIE ROD ARM RH BS6	TATA spare parts
410533805102	TIE ROD ARM LH BS6	TATA spare parts
410533805103	STEERING ARM BS6	TATA spare parts
410533805104	STEERING ARM	TATA spare parts
410533805105	STEERING ARM BS6	TATA spare parts

410533990101	BALLJOINTASSY RH BS6	TATA spare parts
410533990102	BALLJOINTASSY LH BS6	TATA spare parts
410541100101	PROPELLER SHAFT ASSY WITH CB FRONT	TATA spare parts
410541100102	PROPELLER SHAFT ASSY WITH CB MIDDLE	TATA spare parts
410541100103	PROPELLER SHAFT ASSY WITH CB FRONT	TATA spare parts
410541108201	SUPPORT PROPELLER SHAFT GUARD	TATA spare parts
410541110103	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
410541110106	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
410541110109	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
410541110111	PROPELELR SHAFT ASSY COUPLING BS6	TATA spare parts
410541110113	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
410541110114	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
410541110117	SHORTFORKTUBE&FRONTENDPIECEASSY BS6	TATA spare parts
410541110118	SHORTFORKTUBE&FRONTENDPIECEASSY BS6	TATA spare parts
410541110127	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
410541110128	SHORTFORKTUBE&FRONTENDPIECEASSY BS6	TATA spare parts
410541110129	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
410541110130	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
410541110133	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
410541110134	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
410541110136	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
410541110138	SHORT FORK TUBE FRONT END PIECE BS6	TATA spare parts
410541110139	COUPLING YOKE SUB ASSLY BS6	TATA spare parts
410541110143	PROPELLER SHAFT ASSY BS6	TATA spare parts
410541110145	SHORT FORK TUBE FRONT END PIECE BS6	TATA spare parts
410541110147	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
410541110148	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
410541110149	PROPELLER SHAFT ASSY BS6	TATA spare parts
410541110156	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
410541110160	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
410541110161	SHORT FORK TUBE REAR END PIECE ASSY BS6	TATA spare parts
410541120101	PROPELLER SHAFT ASSY REAR	TATA spare parts
410541120102	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
410541120103	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
410541120104	PROPELLER SHAFT ASSY REAR	TATA spare parts
410541120105	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
410541120107	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
410541120109	PROPELELR SHAFT ASSY DRIVE BS6	TATA spare parts
410541120115	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
410541120119	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
410541120120	SHORT FORK TUBE& REAR HSG SUB ASSY BS6	TATA spare parts
410541120121	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
410541120127	PROPELLER SHAFT ASSY-DRIVE BS6	TATA spare parts
410541120130	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
410541120131	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
410541120132	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
410541120134	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts

410541300104	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
410541300106	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
410541303301	BRACKET CENTER BRG MTG 1ST	TATA spare parts
410541303302	BRACKET CENTER BRG MTG 2ND	TATA spare parts
410541303303	BRACKET CENTER BRG MTG BS6	TATA spare parts
410541303304	BRACKET CENTER BRG MTG BS6	TATA spare parts
410541307101	BRACKET CENTER BRG MTG BS6	TATA spare parts
410541307102	BRACKET CENTER BRG	TATA spare parts
410541307103	BRACKET CENTER BRG MTG	TATA spare parts
410541307104	BRACKET CENTER BRG MTG BS6	TATA spare parts
410541307105	BRACKET CENTER BRG MTG BS6	TATA spare parts
410541307109	BRACKET CENTER BRG MTG BS6	TATA spare parts
410541990101	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
410541990102	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
410541990103	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
410541990104	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
410541990106	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
410541990111	SHORT FORK TUBE AND FRT END PIECE FRT PR	TATA spare parts
410541990112	SHORT FORK TUBE AND FRT END PIECE MIDDLE	TATA spare parts
410541990113	SHORT FORK TUBE AND REAR END PIECE-REAR	TATA spare parts
410541990120	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
410541990121	SHORTFORKTUBE&REARENDPIECEASSY BS6	TATA spare parts
410542100123	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
410542100124	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
410542100140	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
410542100141	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
410542100148	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
410542100149	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
410542100167	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
410542100168	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
410542103701	BRAKE DRUM BS6	TATA spare parts
410542300102	BRAKE ASSY REAR-LH	TATA spare parts
410542300103	BRAKE ASSY REAR-RH	TATA spare parts
410542300108	BRACKET ASSY BRAKE CHAMBER MTG LH BS6	TATA spare parts
410542300109	BRACKET ASSY BRAKE CHAMBER MTG RH BS6	TATA spare parts
410542300132	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
410542300133	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
410542300152	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
410542300153	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
410542300173	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
410542300174	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
410542303701	BRACKET BRAKE CHAMBER MTG REAR-LH	TATA spare parts
410542303702	BRACKET ACTUATOR MTG RH BS6	TATA spare parts
410542303707	BRAKE DRUM	TATA spare parts
410542990121	KIT SHIMS BS6	TATA spare parts
410542990142	KIT CALIPER	TATA spare parts
410542990143	SEAL	TATA spare parts

410542990144	KIT BOLT	TATA spare parts
410542990145	KIT BRAKE	TATA spare parts
410542990146	HEX BOLT	TATA spare parts
410542990147	SCREW	TATA spare parts
410542990150	KIT BRAKE LINING (FAB SHOE) 410X180	TATA spare parts
410542990160	BRAKE LINING KIT OS2 410X180 (AF3939) BS	TATA spare parts
410542990161	BRAKE LINING KIT OS1 410X180 (AF3939) BS	TATA spare parts
410542990169	KIT BUSH BS6-PH2	TATA spare parts
410542990178	BRAKE LINING KIT OS2 410X180 (AF1040) BS	TATA spare parts
410542990179	KIT SPRING BS6	TATA spare parts
410542990184	KIT-BRAKE SHOE BS6	TATA spare parts
410542990186	KIT-BRAKE (HC AF 1040G) BS6	TATA spare parts
410542990190	KIT-CAMSHAFT LH BS6	TATA spare parts
410542990191	KIT-CAMSHAFT RH BS6	TATA spare parts
410542990194	BRAKE LINING KIT STD 410X180 (AF3939) BS	TATA spare parts
410542990196	KIT-CAMSHAFT BS6-PH2	TATA spare parts
410542990198	BRAKE LINING KIT STD 410X180 (AF1040) BS	TATA spare parts
410542990199	BRAKE LINING KIT OS1 410X180 (AF1040) BS	TATA spare parts
410542990207	KIT-BRAKE LINER BS6	TATA spare parts
410542990208	BRAKE LINING OS1-394X200 SFS AFF0020 BS6	TATA spare parts
410542990209	BRAKE LINING OS2-394X200 SFS AFF0020 BS6	TATA spare parts
410542993402	KIT-CAMSHAFT LH BS6	TATA spare parts
410542993403	KIT-CAMSHAFT RH BS6	TATA spare parts
410542993405	KIT-CAMSHAFT BS6	TATA spare parts
410542993407	KIT-CAMSHAFT RH BS6	TATA spare parts
410542993408	KIT-CAMSHAFT LH BS6	TATA spare parts
410542993409	KIT-DUST SHIELD MOUNTING FASTNER BS6	TATA spare parts
410542993410	RETURN SPRING BRAKE SHOE(SS MATERIAL) BS	TATA spare parts
410542993411	SPRING-SHOE RETAINING BS6	TATA spare parts
410542993412	KIT-ANCHOR PIN BS6	TATA spare parts
410542993413	KIT-CAMSHAFT RH BS6	TATA spare parts
410542993415	KIT-SPIDER RH BS6	TATA spare parts
410542993416	KIT-SPIDER MACHINED BS6	TATA spare parts
410542993417	KIT-CAMSHAFT RH BS6	TATA spare parts
410542993418	KIT-CAMSHAFT LH BS6	TATA spare parts
410542993419	KIT-CAMSHAFT RH BS6-PH2	TATA spare parts
410542993420	KIT-CAMSHAFT LH BS6	TATA spare parts
410542993424	KIT-CAMSHAFT LH BS6	TATA spare parts
410542993427	KIT BUSH BS6	TATA spare parts
410542993429	KIT-CAMSHAFT RH BS6	TATA spare parts
410542993431	KIT RIVET (STIFFENED) BS6	TATA spare parts
410542996317	BRAKE SHOE AND LINER KIT BS6	TATA spare parts
410542996318	KIT-BRAKE SHOE WITH LINER BS6	TATA spare parts
410542996327	BRAKE SPIDER LH BS6	TATA spare parts
410542996328	BRAKE SPIDER RH BS6	TATA spare parts
410542996333	TORQUE PLATE ASSY LH BS6	TATA spare parts
410542996334	TORQUE PLATE ASSY RH BS6	TATA spare parts

410542996335	KIT BRAKE SPRING BS6	TATA spare parts
410542996336	KIT- CAMSHAFT WASER W/O SPACER BS6	TATA spare parts
410542998206	KIT-SPIDER LH BS6	TATA spare parts
410542998207	CAM SHAFT SERVICE KIT BS6	TATA spare parts
410542998211	KIT-BRAKE LINED SHOE (TVS AF 3939) BS6	TATA spare parts
410542998301	KIT CAMSHAFT LH BS6	TATA spare parts
410542998306	KIT CAMSHAFT RH BS6	TATA spare parts
410542998309	KIT-DUST SHIELD ASSY BS6	TATA spare parts
410542998312	KIT-BRACKET MTG. FASTNER BS6-PH2	TATA spare parts
410542998314	KIT-DUST SHIELD ASSY BS6	TATA spare parts
410543200122	AIR TANK ASSY WITH MTG BKT BS6-PH2	TATA spare parts
410543200124	AIR TANK ASSY WITH BKTS & STRAP BS6-PH2	TATA spare parts
410543200125	BRACKET ASSY AIR TANK MTG LH BS6	TATA spare parts
410543200126	BRACKET ASSY AIR TANK MTG RH BS6	TATA spare parts
410543700110	BRACKET BS6	TATA spare parts
410543700113	AIR PROCESSING UNIT BS6	TATA spare parts
410543900101	PIPE BUNCH ASSY	TATA spare parts
410543900120	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
410543900124	PIPE ASSY	TATA spare parts
410543900125	PIPE ASSY 3RD METAL PIPE (18 OD)	TATA spare parts
410543900126	METAL PIPE ASSY THIRD	TATA spare parts
410543900136	NYLON PIPE BUNCH ASSY	TATA spare parts
410543900144	METAL PIPE ASSY COMPRESSOR TO INT JOINT	TATA spare parts
410543900171	PIPE ASSY¿ BUNCH	TATA spare parts
410543900174	PIPE ASSY	TATA spare parts
410543900180	NYLON PIPE ASSY	TATA spare parts
410543900183	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
410543900202	PIPE ASSY BS6	TATA spare parts
410543900205	PIPE ASSY PRV 21 TO TEE BS6	TATA spare parts
410543900211	PIPE ASSY AUX. TANK TO TEE BS6	TATA spare parts
410543900212	PIPE ASSY DBV PORT-22 JOINT TO FR.RV SER	TATA spare parts
410543900213	PIPE ASSY TEE TO BC-LH BS6	TATA spare parts
410543900214	PIPE ASSY TEE TO BC-RH BS6	TATA spare parts
410543900215	PIPE ASSY TEE TO FR. RV SUPPLY BS6	TATA spare parts
410543900233	PIPE ASSY BS6	TATA spare parts
410543900269	METAL PIPE ASSY BS6	TATA spare parts
410543900270	PIPE ASSY BS6	TATA spare parts
410543900271	METAL PIPE ASSY¿¿BS6	TATA spare parts
410543900298	METAL PIPE ASSY¿¿BS6	TATA spare parts
410543900302	PIPE ASSY BS6	TATA spare parts
410543900317	PIPE ASSY BS6	TATA spare parts
410543900319	PIPE ASSY BS6	TATA spare parts
410543900351	PIPE ASSY BS6	TATA spare parts
410543900352	PIPE ASSY BS6	TATA spare parts
410543900353	PIPE ASSY BS6	TATA spare parts
410543900356	PIPE ASSY BS6	TATA spare parts
410543900389	PIPE ASSY BS6	TATA spare parts

410543900396	NYLON BUNCH COMPLETE BS6	TATA spare parts
410543900398	PIPE ASSY BS6	TATA spare parts
410543910120	NYLON BUNCH COMPLETE FOR COWL BS6	TATA spare parts
410543910330	NYLON BUNCH COMPLETE FOR COWL BS6	TATA spare parts
410546305101	PITMAN ARM BS6	TATA spare parts
410546305104	PITMAN ARM BS6	TATA spare parts
410546305105	PITMAN ARM BS6	TATA spare parts
410546703301	BRACKET STG GEAR BOX MTG BS6	TATA spare parts
410546800101	SUCTION LINE ASSY BS6	TATA spare parts
410546800102	PRESSURE LINE ASSY BS6	TATA spare parts
410546800103	RETURN LINE ASSY BS6	TATA spare parts
410546800104	SUCTION LINE ASSY BS6	TATA spare parts
410546800105	PRESSURE LINE ASSY BS6	TATA spare parts
410546800106	RETURN LINE ASSY BS6	TATA spare parts
410546900101	DRAG LINK ASSYBS6	TATA spare parts
410546900102	DRAG LINK ASSYBS6	TATA spare parts
410546900103	DRAG LINK ASSYBS6	TATA spare parts
410546900104	DRAG LINK ASSY BS6	TATA spare parts
410546990108	KIT-BALL JOINT ASSY OUTER-RH BS6	TATA spare parts
410547100102	FUEL TANK ASSY W/O TANK UNIT BS6-PH2	TATA spare parts
410547500101	BRACKET ASSY FUEL TANK MTG BS6-PH2	TATA spare parts
410547500104	STRAP ASSY BS6	TATA spare parts
410547507701	RUBBER PACKINGBS6	TATA spare parts
410547507702	RUBBER PACKINGBS6	TATA spare parts
410547600101	FUEL PIPE ASSY TANK TO FILTER BS6	TATA spare parts
410547600102	SUCTION PIPE ASSY BS6	TATA spare parts
410547600103	RETURN LINE ASSY BS6	TATA spare parts
410547600104	FUEL PIPE ASSY TANK TO FILTER BS6	TATA spare parts
410547600105	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
410547600107	FUEL RETURN PIPE ASSY BS6	TATA spare parts
410547600108	FUEL PIPE ASSY TANK TO FILTER BS6	TATA spare parts
410547600109	FUEL RETURN PIPE ASSY BS6	TATA spare parts
410547600110	FUEL PIPE ASSY TANK TO FILTER BS6	TATA spare parts
410547600112	RETURN LINE ASSY BS6	TATA spare parts
410547600119	FUELSUCTIONPIPEASSY BS6	TATA spare parts
410549106901	TAIL PIPE	TATA spare parts
410549200101	EXHAUSTPIPEASSYWITHFLEXBELLOWFRONT BS6	TATA spare parts
410549200103	EXHAUSTPIPEFRONT BS6	TATA spare parts
410549200104	BRACKET ASSY BS6	TATA spare parts
410549200105	BRACKET ASSY EGP MTG BS6	TATA spare parts
410549200106	PRESSURE LINE,SM TO DM BS6	TATA spare parts
410549200107	BRACKET ASSY EGP MTG BS6	TATA spare parts
410549200108	EXHAUSTPIPEASSYCENTER BS6	TATA spare parts
410549200110	BRACKET ASSY EXHAUST MTG BS6	TATA spare parts
410549200112	TAIL PIPE ASSY BS6	TATA spare parts
410549200115	TAIL PIPE ASSY BS6	TATA spare parts
410549203301	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts



410549203303	BRACKET BS6	TATA spare parts
410549203305	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
410549203306	BRACKET BS6	TATA spare parts
410549203307	BRACKET EXHAUST PIPE MTG	TATA spare parts
410549203308	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
410549206908	TAILPIPEEXHAUST BS6	TATA spare parts
410554200101	BRACKET ASSY LEVEL GAUGE	TATA spare parts
410554504904	FUEL SELECTOR SWITCH BS6-PH2	TATA spare parts
410554600103	WIRING HARNESS MAIN	TATA spare parts
410554600105	WIRING HARNESS TAIL	TATA spare parts
410554600126	WIRING HARNESS MAIN	TATA spare parts
410554600133	WIRING HARNESS P-CAN	TATA spare parts
410554600135	WIRING HARNESS P-CAN	TATA spare parts
410554600141	WIRING HARNESS MAIN	TATA spare parts
410554601606	PIGTAIL VEHICLE SPEED SENSOR	TATA spare parts
410554601609	WIRING HARNESS MAIN	TATA spare parts
410554610131	CABLE ASSY STARTER MOTOR +VE BS6	TATA spare parts
410554610132	CABLE ASSY STARTER MOTOR -VE BS6	TATA spare parts
410554610136	WIRING HARNESS ABS BS6	TATA spare parts
410554610137	WIRING HARNESS ABS BS6	TATA spare parts
410554610142	WIRING HARNESS PANEL BS6	TATA spare parts
410554610143	WIRING HARNESS TAIL BS6	TATA spare parts
410591000106	DRIVER SEAT ASSY BS6	TATA spare parts
410591000108	RISER ASSY FRONT BS6	TATA spare parts
410591000111	RISER ASSY BS6	TATA spare parts
410591100111	RISER ASSY BS6	TATA spare parts
410600990104	RETRO KIT FOR LPO 1618/62 BSIV MSRTC	TATA spare parts
410624100101	ENGINE MOUNT ASSY FRONT BS6	TATA spare parts
410624107102	LOCKPLATE BS6	TATA spare parts
410624200101	BRACKET ASSY ENGINE MTG REAR BOTTOM-LH	TATA spare parts
410624200102	BRACKET ASSY ENGINE MTG TOP RH	TATA spare parts
410624200103	BRACKET ASSY ENGINE MTG REAR BOTTOM-RH	TATA spare parts
410624200104	BRACKET ASSY ENGINE MTG TOP LH	TATA spare parts
410624203701	ENGINE MTG ASSY REAR-LH¿BS6	TATA spare parts
410624203702	ENGINE MTG ASSY REAR-RH¿BS6	TATA spare parts
410624208801	STUD 10.9 GRADE BS6	TATA spare parts
410624208802	STUD 10.9 GRADE BS6	TATA spare parts
410626800101	TURNING TUBE ASSY BS6	TATA spare parts
410626800104	TURNING TUBE ASSY	TATA spare parts
410626800108	GEAR SHIFT LEVER ASSY WITH SHIFT YOKE	TATA spare parts
410626810101	BRACKET ASSY BALL JOINT	TATA spare parts
410626810102	SUPPORT TUBE ASSY	TATA spare parts
410626810103	BRACKET ASSY GEAR SHIFT LEVER MTG	TATA spare parts
410626820101	ANCHOR BRACKET ASSY SHIFT CABLE BS6-PH2	TATA spare parts
410626820102	ANCHOR BRACKET ASSY SHIFT CABLE BS6-PH2	TATA spare parts
410629100101	CLUTCH PEDAL ASSY WITH BUSH BS6	TATA spare parts
410629100107	CLUTCH PEDAL ASSY WITH BUSH BS6	TATA spare parts

410629100111	LP HOSE ASSY - BS6	TATA spare parts
410629100112	CLUTCH FLUID RESERVOIR ASSY WITH CLAMP B	TATA spare parts
410629200101	BRAKE PEDAL ASSY WITH BUSH BS6	TATA spare parts
410629200104	BRAKE PEDAL ASSY WITH BUSH BS6	TATA spare parts
410629300103	CLUTCH MASTER CYLINDER ASSYBS6	TATA spare parts
410629300104	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
410629300105	BUNDY TUBE ASSY BS6	TATA spare parts
410629300106	BUNDY TUBE ASSY CMC TO LONG MEMBER	TATA spare parts
410629300107	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
410629300109	NYL PIPE ASSY T-CONN TO CLUTCH BOOSTER B	TATA spare parts
410629300110	MAJOR KIT-MASTER CYLINDER BS6	TATA spare parts
410629300111	MINOR KIT-MASTER CYLINDER BS6	TATA spare parts
410629300112	BUNDY TUBE ASSY BS6	TATA spare parts
410629300113	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
410629300114	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
410629300116	CLUTCH MASTER CYLINDER WITH RESERVOIR BS	TATA spare parts
410629500101	BRACKET ASSY BRAKE PEDAL MTG BS6	TATA spare parts
410629500103	BRACKET ASSY CLUTCH PEDAL & SENSOR MTG B	TATA spare parts
410629503311	BRACKET BS6	TATA spare parts
410629503312	BRACKET BS6	TATA spare parts
410630100103	BRACKET ASSY ACCELERATOR MTG BS6	TATA spare parts
410630100104	ACCELERATOR PEDAL ASSY BS6	TATA spare parts
410630100107	ACCELERATOR PEDAL ASSY BS6 PH2	TATA spare parts
410631000102	FRAME ASSY WITH FITMENT	TATA spare parts
410631000103	ASSY. FRAME LPO1618 (FAB 4 HOLE BKT) BS4	TATA spare parts
410631000107	FRAME ASSY WITH FITMENT BS6	TATA spare parts
410631000114	FRAME ASSY WITH FITMENT BS6	TATA spare parts
410631000138	FRAME ASSY WITH FITMENT BS6	TATA spare parts
410631000142	FRAME ASSY WITH FITMENT BS6	TATA spare parts
410631000143	FRAME ASSY WITH FITMENT BS6	TATA spare parts
410631000146	FRAME ASSY WITH FITMENT BS6	TATA spare parts
410631107108	LONG MEMBER RH BS6	TATA spare parts
410631107109	LONG MEMBER LH BS6	TATA spare parts
410631107110	LONG MEMBER RH BS6	TATA spare parts
410631107111	LONG MEMBER LH BS6	TATA spare parts
410631107112	LONG MEMBER RH BS6	TATA spare parts
410631107113	LONG MEMBER LH BS6	TATA spare parts
410631200101	CROSS MEMBER ASSY BUMPER	TATA spare parts
410631200102	SUPPORT ASSY	TATA spare parts
410631200103	SUPPORT ASSY ENGINE CROSS MEMBER RH	TATA spare parts
410631200104	SUPPORT ASSY ENGINE CROSS MEMBER LH	TATA spare parts
410631200105	CROSS MEMBER ASSY BS6	TATA spare parts
410631200107	CROSS MEMBER ASSY BS6	TATA spare parts
410631200108	CROSS MEMBER ASSY BS6	TATA spare parts
410631200109	REINFORCEMENT ASSY TOW HOOK LH BS6	TATA spare parts
410631200113	CROSS MEMBER ASSY REAR SUSPENSION BS6	TATA spare parts
410631200114	SUPPORT ASSY BUMP STOPPER RH BS6	TATA spare parts

410631200121	CROSS MEMBER ASSYBS6	TATA spare parts
410631200125	SUPPORT ASSY ENGINE CROSS MEMBER RH BS6	TATA spare parts
410631200126	SUPPORT ASSY ENGINE CROSS MEMBER LH BS6	TATA spare parts
410631200133	REINFORCEMENT ASSY FRONT SPRING RH BS6	TATA spare parts
410631200134	REINFORCEMENT ASSY FRONT SPRING LH BS6	TATA spare parts
410631200138	REINFORCEMENT ASSY FRONT SPRING RH BS6	TATA spare parts
410631200139	REINFORCEMENT ASSY FRONT SPRING LH BS6	TATA spare parts
410631200140	BRACKET ASSY CROSS MEMBER MTG FRONT-RH BS6	TATA spare parts
410631200141	BRACKET ASSY CROSS MEMBER MTG FRONT-LH BS6	TATA spare parts
410631200144	CROSS MEMBER ASSY BS6	TATA spare parts
410631200145	CROSS MEMBER ASSY BS6	TATA spare parts
410631200146	CROSS MEMBER ASSY ENGINE MTG FRONT BS6	TATA spare parts
410631200149	PLATE MTG ASSY FRONT-LH BS6	TATA spare parts
410631200151	CROSS MEMBER ASSY BS6	TATA spare parts
410631200152	CROSS MEMBER ASSY BS6	TATA spare parts
410631207102	CROSS MEMBER BUMPER BS6	TATA spare parts
410631207103	CROSS MEMBER REAR SUSPENSION BS6	TATA spare parts
410631207122	L-REINFORCEMENT SUSPN FRONT-INNER-RH BS6	TATA spare parts
410631207123	L-REINFORCEMENT SUSPN FRONT-INNER-LH BS6	TATA spare parts
410631207131	SPACER BS6	TATA spare parts
410631208202	BEND PLATE	TATA spare parts
410631208203	GUSSET BUMPER CROSS MEMBER RH	TATA spare parts
410631208204	GUSSET BUMPER CROSS MEMBER LH	TATA spare parts
410631208215	SPACER BS6	TATA spare parts
410631300111	REINFORCEMENT ASSY TOW HOOK LH&BS6	TATA spare parts
410631307106	SUPPORT PLATE BS6	TATA spare parts
410631307107	SUPPORT REAR SPRING CROSS MEMBER BS6	TATA spare parts
410631308203	L-REINFORCEMENT BS6	TATA spare parts
410631308204	REINFORCEMENT FRONT-BOTTOM-RH BS6	TATA spare parts
410631308205	REINFORCEMENT FRONT-BOTTOM-LH BS6	TATA spare parts
410631308206	L-REINFORCEMENT TOP-RH BS6	TATA spare parts
410631308207	L-REINFORCEMENT TOP-LH BS6	TATA spare parts
410631308208	L-REINFORCEMENT BOTTOM-RH BS6	TATA spare parts
410631308209	L-REINFORCEMENT BOTTOM-LH BS6	TATA spare parts
410631308233	REINFORCEMENT FRONT-BOTTOM-RH BS6	TATA spare parts
410631308234	REINFORCEMENT FRONT-BOTTOM-RH BS6	TATA spare parts
410631308236	L-REINFORCEMENT TOP-RH BS6	TATA spare parts
410631308237	L-REINFORCEMENT TOP-LH BS6	TATA spare parts
410631308238	L-REINFORCEMENT TOP-RH BS6	TATA spare parts
410631308239	L-REINFORCEMENT TOP-LH BS6	TATA spare parts
410631308240	L-REINFORCEMENT TOP-RH BS6	TATA spare parts
410631308241	L-REINFORCEMENT TOP-LH BS6	TATA spare parts
410631308242	L-REINFORCEMENT BOTTOM-RH BS6	TATA spare parts
410631308243	L-REINFORCEMENT BOTTOM-LH BS6	TATA spare parts
410631308244	L-REINFORCEMENT BOTTOM-RH BS6	TATA spare parts
410631308245	L-REINFORCEMENT BOTTOM-LH BS6	TATA spare parts
410631505101	TOW HOOK FRONT&BS6	TATA spare parts

410631505102	TOWHOOK BS6	TATA spare parts
410631540101	BRACKET ASSY BATTERY MTG RH	TATA spare parts
410631540102	BRACKET ASSY BATTERY MTG LH	TATA spare parts
410631540108	BRACKET ASSY BATTERY MTG BS6	TATA spare parts
410631707132	PLATE TOW HOOK FRONT BS6	TATA spare parts
410632100106	2ND LEAF ASSY BS6	TATA spare parts
410632100107	1ST LEAF ASSY BS6	TATA spare parts
410632100110	LEAF SPRING ASSY FRONT BS6	TATA spare parts
410632100111	LEAF SPRING ASSY FRONT BS6	TATA spare parts
410632100112	RUBBER BLOCK ASSY FRONT BS6	TATA spare parts
410632100131	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
410632100132	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
410632100133	PARABOLIC LEAF SPRING ASSY BS6	TATA spare parts
410632100134	PARABOLIC LEAF SPRING ASSY BS6	TATA spare parts
410632103202	CENTER BOLT M12X172 BS6	TATA spare parts
410632103204	CENTER BOLT M12 X187 BS6	TATA spare parts
410632103702	BRACKET FRONT SPRING HANGER BS6	TATA spare parts
410632103703	BRACKET LOWER CAP BS6	TATA spare parts
410632103704	GUIDE PLATE BS6	TATA spare parts
410632103705	BRACKET FRONT SPRING HANGER BS6	TATA spare parts
410632103706	CASTER PLATE BS6	TATA spare parts
410632104203	CLAMP BS6	TATA spare parts
410632107101	5TH LEAF BS6	TATA spare parts
410632107103	3RD LEAF BS6	TATA spare parts
410632107105	6TH LEAF BS6	TATA spare parts
410632107106	7TH LEAF BS6	TATA spare parts
410632107107	8TH LEAF BS6	TATA spare parts
410632107109	SPRING CLIP BS6	TATA spare parts
410632107111	SPACER PLATE BS6	TATA spare parts
410632107112	4TH LEAF BS6	TATA spare parts
410632107145	1ST LEAF BS6	TATA spare parts
410632107146	2ND LEAF BS6	TATA spare parts
410632107148	3RD LEAF BS6	TATA spare parts
410632107149	4TH LEAF BS6	TATA spare parts
410632107150	5TH LEAF BS6	TATA spare parts
410632107155	2ND LEAF BS6	TATA spare parts
410632107156	3RD LEAF BS6	TATA spare parts
410632107157	4TH LEAF BS6	TATA spare parts
410632107158	5TH LEAF BS6	TATA spare parts
410632107160	CASTER PLATE BS6	TATA spare parts
410632107703	RUBBER BLOCK FRONT BS6	TATA spare parts
410632108602	CENTER PAD BS6	TATA spare parts
410632300101	BRACKET ASSY SHOCK ABSORBER BS6	TATA spare parts
410632300102	BRACKET ASSY FRONT SHOCK ABSORBER MTG BS	TATA spare parts
410632400101	PNEUMATIC REAR SUSPENSION ASSY¿BS6	TATA spare parts
410632400104	CROSS MEMBER ASSY FRONT AIR SPRING BS6	TATA spare parts
410632400106	BRACKET ASSY REAR AIR SPRING MTG LH BS6	TATA spare parts

410632400107	BRACKET ASSY REAR AIR SPRING MTG RH BS6	TATA spare parts
410632400109	SUBFRAME ASSY BS6	TATA spare parts
410632400110	LEVELLING VALVE ASSY LH BS6	TATA spare parts
410632400111	LEVELLING VALVE ASSY RH BS6	TATA spare parts
410632400112	CONNECTING LINK ASSY BS6	TATA spare parts
410632400114	PISTON	TATA spare parts
410632400116	PARALLEL LINK & AIR SPRING BKT ASSY LH B	TATA spare parts
410632400117	PARALLEL LINK & AIR SPRING BKT ASSY RH B	TATA spare parts
410632400122	CROSS MEMBER ASSY FRONT AIR SPRING BS6	TATA spare parts
410632400123	CROSS MEMBER ASSY FRONT AIR SPRING BS6	TATA spare parts
410632403202	HEX FL BOLT M16X1.5X65 BS6	TATA spare parts
410632403301	BRACKET BS6	TATA spare parts
410632404201	U-CLAMP REAR	TATA spare parts
410632406301	BELLOW AIR SPRING	TATA spare parts
410632406301DF	AIR BELLOW RUBBER REAR - FE/RE BUSES	TATA spare parts
410632406302	BUMP STOPPER	TATA spare parts
410632406501	NYLOC NUT	TATA spare parts
410632406901	CROSSLINK BS6	TATA spare parts
410632407101	FLITCH FRONT-LH BS6	TATA spare parts
410632407102	FLITCH FRONT-LH BS6	TATA spare parts
410632407111	REAR AIR SPRING CROSS MEMBER CROSS BEAM	TATA spare parts
410632407113	BRACKET BS6	TATA spare parts
410632408801	STUD	TATA spare parts
410632800111	ANTI ROLL BAR ASSY WITH BUSH BS6	TATA spare parts
410632800113	LINK ASSY ANTI ROLL BAR BS6-PH2	TATA spare parts
410632800116	RUBBER BUSH ASSY BS6	TATA spare parts
410632800117	RUBBER BUSH ASSY BS6-PH2	TATA spare parts
410632803301	BRACKET ANTI ROLL BAR MTG LH BS6	TATA spare parts
410632803302	BRACKET ANTI ROLL BAR MTG RH BS6	TATA spare parts
410632803701	BRACKET ANTI ROLL BAR MTG LH BS6-PH2	TATA spare parts
410632803702	BRACKET ANTI ROLL BAR MTG RH BS6-PH2	TATA spare parts
410632807105	CLAMP PLATE BS6-PH2	TATA spare parts
410632807904	ANTI ROLL BAR BS6-PH2	TATA spare parts
410632808601	SPACER BS6-PH2	TATA spare parts
410632900101	HANGERLINKASSYREARANTIROLLBAR BS6	TATA spare parts
410632950101	PIPE BUNCH ASSY BS6	TATA spare parts
410633000107	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
410633000108	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
410633000110	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
410633000116	FRONT AXLE ASSY WITH BRAKE ABSBS6	TATA spare parts
410633000117	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
410633000120	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
410633400102	FRONT HUB ASSY WITH BEARING	TATA spare parts
410633400103	FRONT HUB ASSY ABS	TATA spare parts
410633405501	FRONT HUB	TATA spare parts
410633800101	TIE ROD ASSY BS6	TATA spare parts
410633800102	TIE ROD ASSY BS6	TATA spare parts

410633800103	TIE ROD ASSY BS6	TATA spare parts
410633800104	TIE ROD ASSY BS6	TATA spare parts
410633805101	TIE ROD ARM RH BS6	TATA spare parts
410633805102	TIE ROD ARM LH BS6	TATA spare parts
410633990102	SET-FRONT AXLE ASSY BS6	TATA spare parts
410640300101	BRACKET SPARE WHEEL MTG BS6	TATA spare parts
410641100103	PROPELLER SHAFT ASSY COUPLING-SPICER	TATA spare parts
410641108201	SUPPORT PROPELLER SHAFT GUARD BS6	TATA spare parts
410641110104	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
410641110105	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
410641110110	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
410641110111	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
410641110112	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
410641110113	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
410641110115	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
410641110116	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
410641110124	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
410641110127	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
410641110157	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
410641110158	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
410641110162	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
410641119901	COUPLING FLANGE BS6	TATA spare parts
410641120102	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
410641120105	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
410641120106	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
410641120107	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
410641120110	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
410641120111	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
410641120112	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
410641120119	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
410641120129	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
410641120131	PROPELLER SHAFT ASSY DRIVE (RSB) BS6	TATA spare parts
410641300104	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
410641300105	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
410641300106	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
410641300107	SUPPORT ASSY CENTER BRG CROSS MEMBER BS6	TATA spare parts
410641303301	BRACKET CENTER BRG MTG BS6	TATA spare parts
410641303302	BRACKET CENTER BRG MTG BS6	TATA spare parts
410641307111	BRACKET CENTER BRG MTG BS6	TATA spare parts
410641307116	BRACKET CENTER BRG MTG BS6	TATA spare parts
410641307117	BRACKET CENTER BRG MTG BS6	TATA spare parts
410641308201	BRACKET CENTER BRG SUPPORT BS6	TATA spare parts
410642100107	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
410642100108	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
410642100114	DRUMBRAKEASSYWITHDCFRONT-LH BS6	TATA spare parts
410642100115	DRUMBRAKEASSYWITHDCFRONT-RH BS6	TATA spare parts
410642100138	DRUM BRAKE ASSY FRONT -LH	TATA spare parts

410642100139	DRUM BRAKE ASSY FRONT -RH	TATA spare parts
410642100159	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
410642100160	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
410642103703	BRAKE DRUM BS6	TATA spare parts
410642103704	BRAKE DRUM BS6	TATA spare parts
410642103707	BRAKE DRUM	TATA spare parts
410642103723	BRAKE DRUM BS6-PH2	TATA spare parts
410642300146	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
410642300147	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
410642300160	BRACKET ASSY ACTUATOR MTG REAR-LH BS6	TATA spare parts
410642300161	BRACKET ASSY ACTUATOR MTG REAR-RH BS6	TATA spare parts
410642303709	BRACKET BRAKE CHAMBER MTG REAR-LH	TATA spare parts
410642303710	BRACKETBRAKE CHAMBER MTGREAR-RH	TATA spare parts
410642305103	CAMSHAFT REAR BRAKE LH	TATA spare parts
410642305104	CAMSHAFT REAR BRAKE RH	TATA spare parts
410642990108	KIT-BRAKE	TATA spare parts
410642990109	KIT-BRAKE	TATA spare parts
410642990117	CAMSHAFT LH	TATA spare parts
410642990118	CAMSHAFT RH	TATA spare parts
410642990136	KIT-CAMSHAFT LH BS6	TATA spare parts
410642990137	KIT-CAMSHAFT RH BS6	TATA spare parts
410642990144	KIT-BRAKE LINER FRONT	TATA spare parts
410642990145	KIT-BRAKE LINER FRONT	TATA spare parts
410642990149	KIT-BRAKE LINER REAR	TATA spare parts
410642990155	KIT-BRAKE LINER REAR	TATA spare parts
410642990156	KIT-BRAKE LINER REAR	TATA spare parts
410642990157	KIT-BRAKE LINER REAR	TATA spare parts
410642990160	KIT-BUSH BS6-PH2	TATA spare parts
410642990161	KIT SPRING BS6	TATA spare parts
410642990169	KIT- DUST COVER BS6	TATA spare parts
410642990175	KIT-BRAKE SHOE BS6	TATA spare parts
410642990181	KIT-BRAKE SHOE & LINER	TATA spare parts
410642990188	KIT - BRAKE	TATA spare parts
410642990192	KIT - BRAKE	TATA spare parts
410642990193	KIT - BRAKE	TATA spare parts
410642990194	KIT - BRAKE	TATA spare parts
410642990195	KIT BRAKE LINING (CAST SHOE) 410X160	TATA spare parts
410642990196	KIT BRAKE LINING (CAST SHOE) 410X180	TATA spare parts
410642990201	KIT-TORQUE PLATE ASSY LH BS6	TATA spare parts
410642990202	KIT-TORQUE PLATE ASSY RH BS6	TATA spare parts
410642990206	KIT-DUST SHIELD ASSY BS6	TATA spare parts
410642990209	KIT-BUSH BS6	TATA spare parts
410642990210	SHIM BRAKE ASSY BS6	TATA spare parts
410642990211	KIT-CAMSHAFT LH BS6	TATA spare parts
410642990212	KIT-CAMSHAFT RH BS6	TATA spare parts
410642990215	KIT-SHOE ASSY BS6	TATA spare parts
410642990220	KIT-SHOE ASSY BS6	TATA spare parts

410642990221	FULCRUM PIN BS6	TATA spare parts
410642990222	KIT-TORQUE PLATE ASSY LH BS6	TATA spare parts
410642990223	KIT-TORQUE PLATE ASSY RH BS6	TATA spare parts
410642990230	KIT-TORQUE PLATE ASSY LH BS6	TATA spare parts
410642990231	KIT-TORQUE PLATE ASSY RH BS6	TATA spare parts
410642990234	KIT-BRACKET ASSY LH BS6	TATA spare parts
410642990235	KIT-BRACKET ASSY RH BS6	TATA spare parts
410642990238	KIT-DUST SHIELD ASSY BS6	TATA spare parts
410642990241	KIT-BUSH BS6	TATA spare parts
410642990242	KIT-CAMSHAFT LH BS6	TATA spare parts
410642990243	KIT-CAMSHAFT RH BS6	TATA spare parts
410642990246	KIT-BOLT BS6	TATA spare parts
410642990247	KIT-SHOE ASSY BS6	TATA spare parts
410642990248	SHOE ASSY LINED BS6	TATA spare parts
410642990249	SPRING CAM END BS6	TATA spare parts
410642990253	SHOE ASSY BS6	TATA spare parts
410642990255	BRAKE LINING KIT(STD)394X200 AF TL70 BS6	TATA spare parts
410642990256	BRAKE LINING KIT(OS1)394X200 AF TL70 BS6	TATA spare parts
410642990257	BRAKE LINING KIT(OS2)394X200 AF TL70 BS6	TATA spare parts
410642990265	KIT-BRAKE SHOE CAST (TVS AF 3838J) BS6	TATA spare parts
410642990268	KIT ROLLER (CAST SHOE) BS6	TATA spare parts
410642990278	BRAKE LINING KIT(STD)394X200 AF3838J BS6	TATA spare parts
410642990279	BRAKE LINING KIT(OS1)394X200 AF3838J BS6	TATA spare parts
410642990280	BRAKE LINING KIT(OS2)394X200 AF3838J BS6	TATA spare parts
410642990287	BRAKE LINING STD-394X200-SFS-AF3838J BS6	TATA spare parts
410642990288	BRAKE LINING OS1-394X200-SFS-AF3838J BS6	TATA spare parts
410642990289	BRAKE LINING OS2-394X200-SFS-AF3838J BS6	TATA spare parts
410642990297	KIT-BRAKE SHOE CAST (TVS AF 3838J) BS6	TATA spare parts
410643200133	AIR TANK ASSY WITH MTG BKT BS6	TATA spare parts
410643200138	AIR TANK ASSY WITH MTG BKT BS6	TATA spare parts
410643400108	BRACKET ASSY RETARDER MTG BS6	TATA spare parts
410643400109	BRACKET ASSY RETARDER MTG BS6	TATA spare parts
410643400111	RETARDER ASSYBS6	TATA spare parts
410643403801	FLANGE RETARDER BS6	TATA spare parts
410643408201	BRACKET BS6	TATA spare parts
410643408202	BRACKET BS6	TATA spare parts
410643700135	BRACKET RELAY VALVE MTG BS6	TATA spare parts
410643700183	DUAL BRAKE VALVE BS6	TATA spare parts
410643700197	DUAL BRAKE VALVE¿BS6	TATA spare parts
410643700202	RELAY VALVE & MODULATOR VALVE ASSY¿BS6	TATA spare parts
410643700210	AIR PROCESSING UNIT BS6	TATA spare parts
410643700211	RELAY VALVEBS6	TATA spare parts
410643700213	BRACKET ASSY APU MTG BS6	TATA spare parts
410643700216	RELAY VALVE	TATA spare parts
410643700230	RELAY VALVE & MODULATOR VALVE ASSY - BS6	TATA spare parts
410643700232	RELAY VALVE BS6	TATA spare parts
410643700233	RELAY VALVE BS6	TATA spare parts



410643700237	ANTI COMPOUNDING RELAY VALVE BS6	TATA spare parts
410643700239	RELAY VALVE BS6	TATA spare parts
410643700245	BRACKET ASSY APU MTG WITH SPACER BS6	TATA spare parts
410643700255	BRACKET ASSY APU MTG BS6	TATA spare parts
410643700260	BRACKET ASSY MODULATOR VALVE (FRONT) BS6	TATA spare parts
410643703308	BRACKET BS6	TATA spare parts
410643703310	BRACKET BS6-PH2	TATA spare parts
410643708201	BRACKET	TATA spare parts
410643900146	PIPE BUNCH ASSY	TATA spare parts
410643900151	PIPE ASSY BUNCH COMPLETE	TATA spare parts
410643900204	PIPE ASSY (INTAKE PIPE AIR COMP)	TATA spare parts
410643900267	PIPE ASSY	TATA spare parts
410643900284	PIPE ASSY BS6	TATA spare parts
410643900289	PIPE ASSY 3RD METAL PIPE (18 OD) BS6	TATA spare parts
410643903301	BRACKET BS6	TATA spare parts
410643903302	BRACKET BS6	TATA spare parts
410643903303	BRACKET¿BS6	TATA spare parts
410643903304	BRACKET¿BS6	TATA spare parts
410643903305	BRACKET¿BS6	TATA spare parts
410643903306	BRACKET BS6	TATA spare parts
410643903310	BRACKET	TATA spare parts
410643903311	BRACKET	TATA spare parts
410643907501	RUBBER GROMMET¿BS6	TATA spare parts
410643910105	PIPE ASSY-SET	TATA spare parts
410643910151	PIPE ASSY-NYLON	TATA spare parts
410643910165	BRACKET ASSY	TATA spare parts
410643910166	BRACKET ASSY BS6	TATA spare parts
410643910173	PIPE ASSY THIRD METAL PIPE (18 OD)	TATA spare parts
410643910175	PIPE ASSY FOURTH METAL PIPE (18 OD)	TATA spare parts
410643910176	PIPE ASSY (COMP TO AIR DRYER)	TATA spare parts
410643910177	PIPE ASSY SECOND METAL PIPE (18 OD)	TATA spare parts
410643910179	PIPE ASSY FOURTH METAL PIPE (18 OD)	TATA spare parts
410643910180	PIPE ASSY SECOND METAL PIPE (18 OD)	TATA spare parts
410643920102	PIPE ASSY-NYLON	TATA spare parts
410643920177	PIPE ASSY COMP TO AIR DRYER-5TH	TATA spare parts
410643920178	PIPE ASSY COMP.TO AIR DRYER-4TH	TATA spare parts
410643920179	PIPE ASSY COMP.TO AIR DRYER-3RD	TATA spare parts
410643920180	PIPE ASSY COMP.TO AIR DRYER-2ND	TATA spare parts
410643920182	NYLON PIPE BUNCH ASSY	TATA spare parts
410643930101	PIPE ASSY 1ST METAL PIPE (TEFLON HOSE)	TATA spare parts
410643930187	PIPE ASSY BS6	TATA spare parts
410643930188	PIPE ASSY BS6	TATA spare parts
410643930189	PIPE ASSY BS6	TATA spare parts
410643930199	METAL PIPE ASSY¿¿BS6	TATA spare parts
410643930200	PIPE ASSY¿ BS6	TATA spare parts
410643930208	PIPE ASSY BS6	TATA spare parts
410643940103	PIPE ASSY BS6	TATA spare parts

410643940108	PIPE ASSY TEE TO ACRV SUPPLY BS6	TATA spare parts
410643940112	PIPE ASSY RE. MOD.VALVE TO RH SBA-11 BS6	TATA spare parts
410643940113	PIPE ASSY RE. MOD.VALVE TO LH SBA-11 BS6	TATA spare parts
410643940115	PIPE ASSY FST TO TEE BS6	TATA spare parts
410643940116	PIPE ASSY ACRV DEL LH TO SBA-12 BS6	TATA spare parts
410643940117	PIPE ASSY ACRV DEL RH TO SBA-12 BS6	TATA spare parts
410643940121	PIPE ASSY SUSP. TANK TO AIR SUSPENSION B	TATA spare parts
410643940123	PIPE ASSY TEE TO NRV-1 BS6	TATA spare parts
410643940126	PIPE ASSY TEE TO DBV PORT-12 JOINT BS6	TATA spare parts
410643940127	PIPE ASSY HBV 2 JOINT TO ACRV 41 BS6	TATA spare parts
410643940128	PIPE ASSY TEE TO HBV PORT-1 JOINT BS6	TATA spare parts
410643940130	PIPE ASSY NRV-2 TO SUSP. TANK BS6	TATA spare parts
410643940131	PIPE ASSY TEE TO AUX. TANK BS6	TATA spare parts
410643940132	PIPE ASSY SPV-21 TO RST BS6	TATA spare parts
410643940133	PIPE ASSY PRV-21 TO TEE BS6	TATA spare parts
410643940134	PIPE ASSY SPV-22 TO FST BS6	TATA spare parts
410643940135	PIPE ASSY TEE TO TEE BS6	TATA spare parts
410643940136	PIPE ASSY RST TO TEE BS6	TATA spare parts
410643940138	PIPE ASSY TEE TO DBV PORT-11 JOINT BS6	TATA spare parts
410643940139	PIPE ASSY TEE TO ACRV PORT 42 BS6	TATA spare parts
410643940155	PIPE ASSY TEE TO RE. RV BS6	TATA spare parts
410643940165	PIPE ASSY BS6	TATA spare parts
410643940178	PIPE ASSY TEE JOINT TO TEE BS6	TATA spare parts
410643940181	PIPE ASSY BS6	TATA spare parts
410643940182	PIPE ASSY BS6	TATA spare parts
410643940189	PIPE ASSY BS6	TATA spare parts
410643940190	PIPE ASSY JOINT TO DBV PORT-12 BS6	TATA spare parts
410643940191	PIPE ASSY HBV PORT 2 TO JOINT BS6	TATA spare parts
410643940192	PIPE ASSY JOINT TO HBV PORT-1 BS6	TATA spare parts
410643940193	PIPE ASSY DBV PORT-22 TO JOINT BS6	TATA spare parts
410643940194	PIPE ASSY JOINT TO DBV PORT-11 BS6	TATA spare parts
410643940196	PIPE ASSY TEE TO TEE BS6	TATA spare parts
410643940197	PIPE ASSY FR. RV DEL TO MV BS6	TATA spare parts
410643940198	PIPE ASSY TEE TO RE. RV SUPPLY BS6	TATA spare parts
410643940199	PIPE ASSY TEE TO RE. RV SUPPLY BS6	TATA spare parts
410643940201	PIPE ASSY TEE TO FR. RV SUPPLY BS6	TATA spare parts
410643940202	PIPE ASSY FR. MV DEL TO TEE BS6	TATA spare parts
410643940203	PIPE ASSY SPV-23 TO PRV 11 BS6	TATA spare parts
410643940204	PIPE ASSY SPV-24 TO PRV 11 BS6	TATA spare parts
410643940206	PIPE ASSY BS6	TATA spare parts
410643940232	AIR BR HOSE WITH ANTI KINK SPR BS6-PH2	TATA spare parts
410643945840	PIPE BS6	TATA spare parts
410643950113	PIPE ASSY NYLON BUNCH COMPLETE FOR CHASS	TATA spare parts
410643950137	PIPE ASSY BS6	TATA spare parts
410643950138	PIPE ASSY DBV PORT-21 TO JOINT BS6	TATA spare parts
410646100108	RUBBER BELLOW ASSY BS6	TATA spare parts
410646107101	SPACER BS6	TATA spare parts

410646208203	PLATE RUBBER BELLOW MTG BS6-PH2	TATA spare parts
410646304101	RELAY ARM	TATA spare parts
410646305101	PITMAN ARM	TATA spare parts
410646305103	RELAY ARM BS6	TATA spare parts
410646305104	PITMAN ARM BS6	TATA spare parts
410646305105	PITMAN ARM	TATA spare parts
410646305106	RELAY ARM	TATA spare parts
410646305112	RELAY ARM BS6	TATA spare parts
410646305113	PITMAN ARM BS6	TATA spare parts
410646600101	POWER STEERING GEAR ASSLY-RANE	TATA spare parts
410646600104	STEERING GEAR BOX ASSY	TATA spare parts
410646600106	STEERING GEAR BOX ASSY BS6	TATA spare parts
410646600108	POWER STEERING PUMP ASSY BS6	TATA spare parts
410646600110	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
410646609901	ROTOR BS6-PH2	TATA spare parts
410646609902	HOUSING ASSY BS6	TATA spare parts
410646609903	VANE PUMP BS6-PH2	TATA spare parts
410646700103	COVER PLATE ASSY BS6	TATA spare parts
410646700104	COVER PLATE ASSY BS6-PH2	TATA spare parts
410646700106	COVER PLATE ASSY BS6-PH2	TATA spare parts
410646703301	BRACKET STG GEAR BOX MTG	TATA spare parts
410646703302	BRACKET STG GEAR BOX MTG	TATA spare parts
410646703305	BRACKET STG GEAR BOX MTG BS6-PH2	TATA spare parts
410646705101	BRACKET BS6-PH2	TATA spare parts
410646705102	RELAY ARM BS6-PH2	TATA spare parts
410646708201	COVER RELAY ARM HUB	TATA spare parts
410646708204	COVER RELAY ARM HUB BS6	TATA spare parts
410646709201	WASHER BS6-PH2	TATA spare parts
410646800101	PRESSURE LINE ASSY	TATA spare parts
410646800102	SUCTION LINE ASSY	TATA spare parts
410646800103	RETURN LINE ASSY	TATA spare parts
410646800104	PRESSURE LINE ASSY	TATA spare parts
410646800105	RETURN LINE ASSY	TATA spare parts
410646800106	SUCTION LINE ASSY	TATA spare parts
410646800107	SUCTION LINE ASSY BS6	TATA spare parts
410646800108	PRESSURE LINE ASSY BS6	TATA spare parts
410646800109	RETURN LINE ASSY BS6	TATA spare parts
410646800117	SUCTION LINE ASSY BS6	TATA spare parts
410646800118	RETURN LINE ASSY BS6	TATA spare parts
410646800119	PRESSURE LINE ASSY BS6	TATA spare parts
410646800125	PRESSURE LINE ASSY BS6	TATA spare parts
410646800130	SUCTION LINE ASSY BS6	TATA spare parts
410646800131	RETURN LINE ASSY RESERVOIR END BS6	TATA spare parts
410646800132	RETURN LINE ASSY	TATA spare parts
410646800135	PRESSURE LINE ASSY	TATA spare parts
410646800136	SUCTION LINE ASSY	TATA spare parts
410646800147	PRESSURE LINE ASSY BS6-PH2	TATA spare parts

410646800148	RETURN LINE ASSY BS6-PH2	TATA spare parts
410646803301	BRACKET BS6	TATA spare parts
410646900101	DRAG LINK ASSY	TATA spare parts
410646900104	DRAG LINK ASSY (REAR)	TATA spare parts
410646900108	DRAG LINK ASSY REAR BS6	TATA spare parts
410646900109	DRAG LINK ASSY FRONT BS6	TATA spare parts
410646900116	DRAG LINK ASSY FRONT BS6	TATA spare parts
410646900118	DRAG LINK ASSY REAR BS6	TATA spare parts
410646990145	HOUSING ASSY	TATA spare parts
410646990146	KIT SEAL	TATA spare parts
410646990147	WORM AND VALVE HSG WITH RACK ASSY	TATA spare parts
410646990149	SECTOR SHAFT ASSY	TATA spare parts
410646990170	SECTOR SHAFT ASSY BS6	TATA spare parts
410647100102	FUEL TANK ASSY W/O TANK UNIT BS6-PH2	TATA spare parts
410647600101	FUEL SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
410647600102	FUEL SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
410647600103	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
410647600104	FUEL PIPE ASSY TANK TO FILTER BS6	TATA spare parts
410647600105	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
410647600106	RETURN LINE ASSY BS6	TATA spare parts
410647600107	FUEL PIPE ASSY TANK TO FILTER BS6	TATA spare parts
410647600108	RETURN LINE ASSY BS6	TATA spare parts
410647607501	GROMMET BS6	TATA spare parts
410649100101	BRACKET ASSY SIENCER MTG	TATA spare parts
410649100102	BRACKET ASSY SIENCER MTG	TATA spare parts
410649100103	SUPPORT ASSY CATCON	TATA spare parts
410649200101	EXHAUST PIPE ASSY	TATA spare parts
410649200103	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
410649200104	EXHAUST BRAKE MTG BKT ASSY	TATA spare parts
410649200105	BRACKET ASSY EGP MTG	TATA spare parts
410649200106	BRACKET ASSY EGP MTG	TATA spare parts
410649200108	EXHAUST TAIL PIPE ASSY	TATA spare parts
410649200111	EXHAUST PIPE ASSY MANIFOLD TO CATCON	TATA spare parts
410649200113	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
410649200114	EXHAUST PIPE ASSY BS6	TATA spare parts
410649200115	BRACKET ASSY EXHAUST PIPE BS6	TATA spare parts
410649200117	BRACKET ASSY TAIL PIPE MTG BS6	TATA spare parts
410649200118	BRACKET ASSY EGP MTG BS6	TATA spare parts
410649200121	CLAMP ASSY EGP MTG BS6	TATA spare parts
410649200122	PIPE ASSY BS6	TATA spare parts
410649200123	RETURN LINE,DM TO TANK BS6	TATA spare parts
410649200134	BRACKET ASSY EXHAUST MTG BS6	TATA spare parts
410649200135	RETURN LINE;DM TO TANK BS6	TATA spare parts
410649200142	BRACKET ASSY EGP MTG BS6	TATA spare parts
410649200143	PRESSURE LINE SM TO DM BS6-PH2	TATA spare parts
410649200146	TAIL PIPE ASSY BS6	TATA spare parts
410649200148	BRACKET ASSY EGP MTG BS6	TATA spare parts

410649200149	BRACKET ASSY EGP MTG BS6	TATA spare parts
410649203303	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
410649203304	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
410649203305	BRACKET BS6	TATA spare parts
410649203307	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
410649203319	BRACKET SUPPORT BS6	TATA spare parts
410649203320	BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
410649204201	CLAMP EGP MTG BS6	TATA spare parts
410649205801	AIR PIPE LINE AIR OIL FILTER TO DU	TATA spare parts
410649206913	TAIL PIPE BS6	TATA spare parts
410649600102	HEAT SHIELD ASSY¿BS6	TATA spare parts
410649600103	HEAT SHIELD ASSY¿BS6	TATA spare parts
410649600104	HEAT SHIELD ASSY FLEX BELLOW BS6	TATA spare parts
410649609907	HEAT SHIELD EXHAUST	TATA spare parts
410649609908	HEAT SHIELD EXHAUST	TATA spare parts
410649609909	HEAT SHIELD EXHAUST	TATA spare parts
410649980101	KIT-EXHAUST PIPE HEAT SHIELD ASSY	TATA spare parts
410649980102	KIT-EXHAUST TAIL PIPE HEAT SHIELD	TATA spare parts
410649990102	KIT-EXHAUST HEAT SHIELD	TATA spare parts
410654103301	CLAMP BATTERY MTG TOP BS6-PH2	TATA spare parts
410654109901	BATTERY TRAY BS6-PH2	TATA spare parts
410654201604	INDICATOR BATTERY CHARGE	TATA spare parts
410654201605	INDICATOR BATTERY CHARGE	TATA spare parts
410654206301	COVER-INSTRUMENT CLUSTER BS6	TATA spare parts
410654400101	COVER ASSY FRONT HEADLAMP LH BS6	TATA spare parts
410654400102	COVER ASSY FRONT HEADLAMP RH BS6	TATA spare parts
410654400103	TURN INDICATOR LAMP REAR BS6-PH2	TATA spare parts
410654400104	STOP/TAIL LAMP BS6-PH2	TATA spare parts
410654400106	REVERSE LAMP ASSY BS6-PH2	TATA spare parts
410654403304	BRACKET TAIL LAMP MTG BS6-PH2	TATA spare parts
410654406301	COVER HEADLAMP LH BS6	TATA spare parts
410654406304	COVER HEADLAMP RH BS6	TATA spare parts
410654406305	COVER HEADLAMP BS6	TATA spare parts
410654406306	COVER HEADLAMP BS6	TATA spare parts
410654500101	SWITCH HEAVY MODE BS6	TATA spare parts
410654500102	SWITCH LIGHT MODE BS6	TATA spare parts
410654500104	BRACKET ASSY SWITCH MTG BS6	TATA spare parts
410654500105	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
410654500106	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
410654503305	BRACKET BATT CUT OFF SW MTG BS6	TATA spare parts
410654503306	BRACKET BS6	TATA spare parts
410654503307	BRACKET BS6-PH2	TATA spare parts
410654504902	SWITCH REGENERATION START MANUAL BS6	TATA spare parts
410654504903	RETARDER ON/OFF SWITCH BS6	TATA spare parts
410654600101	WIRING HARNESS CAN BACKBONE FRONT	TATA spare parts
410654600103	WIRING HARNESS MAIN	TATA spare parts
410654600105	WIRING HARNESS MAXI FUSE	TATA spare parts

410654600107	WIRING HARNESS ENGINE	TATA spare parts
410654600109	WIRING HARNESS AFTER TREATMENT	TATA spare parts
410654600111	SUPPLYCABLE BS6	TATA spare parts
410654600112	WIRING HARNESS MAIN	TATA spare parts
410654600114	WIRING HARNESS POWER CABLE	TATA spare parts
410654600115	WIRINGHARNESSPANEL BS6	TATA spare parts
410654600116	CABLE ASSY BATTERY +VE	TATA spare parts
410654600117	CABLE ASSY BATTERY -VE	TATA spare parts
410654600135	WIRING HARNESS AFTER TREATMENT BS6	TATA spare parts
410654600137	WIRINGHARNESSENGINE BS6	TATA spare parts
410654600141	WIRING HARNESS ASSY	TATA spare parts
410654600144	WIRING HARNESS ENGINE	TATA spare parts
410654600145	PIGTAIL POWER SUPPLY AIS140	TATA spare parts
410654600146	PIGTAIL CAN AIS140	TATA spare parts
410654600147	PIGTAIL POWER SUPPLY AIS140	TATA spare parts
410654600148	WIRINGHARNESSMAIN BS6	TATA spare parts
410654600151	WIRING HARNESS PANEL BS6	TATA spare parts
410654600159	WIRING HARNESS RETARDER BS6	TATA spare parts
410654600161	WIRING HARNESS PANEL BS6	TATA spare parts
410654600162	WIRING HARNESS MAXI FUSE	TATA spare parts
410654600163	WIRING HARNESS MAXIFUSE TO ALT BS6	TATA spare parts
410654600164	WIRING HARNESS CUT_OFF SW TO FUSEBOX IP	TATA spare parts
410654600165	WIRING HARNESS RETARDER ECU TO DASHBOARD	TATA spare parts
410654600167	WIRING HARNESS MAIN	TATA spare parts
410654600173	WIRING HARNESS MAIN BS6	TATA spare parts
410654600174	WIRING HARNESS MAIN	TATA spare parts
410654600176	WIRING HARNESS P-CAN	TATA spare parts
410654600177	WIRING HARNESS MAIN	TATA spare parts
410654600180	WIRING HARNESS TAIL BS6	TATA spare parts
410654600181	WIRING HARNESS REVERSE PARK ASSIST BS6	TATA spare parts
410654600182	WIRING HARNESS ASSY BS6	TATA spare parts
410654600185	WIRING HARNESS CAN PIGTAIL BS6	TATA spare parts
410654600186	WIRING HARNESS MAIN BS6	TATA spare parts
410654600187	WIRING HARNESS MAIN BS6	TATA spare parts
410654600188	WIRING HARNESS ABS BS6	TATA spare parts
410654600189	WIRINGHARNESS ABS BS6	TATA spare parts
410654600192	WIRING HARNESS TAIL BS6	TATA spare parts
410654600193	WIRING HARNESS ABS BS6	TATA spare parts
410654600199	KIT-CONNECTOR BS6	TATA spare parts
410654601614	W/H PIGTAIL WIF	TATA spare parts
410654601615	WIRING HARNESS MAIN	TATA spare parts
410654601616	WIRING HARNESS TAIL	TATA spare parts
410654604601	MICRO RELAY BS6	TATA spare parts
410654608201	BRACKET CONNECTOR MTG BS6	TATA spare parts
410654610101	WIRING HARNESS MAIN	TATA spare parts
410654610103	WIRING HARNESS PANEL	TATA spare parts
410654610104	WIRING HARNESS TCU SYSTEM CONN BS6	TATA spare parts

410654610106	WIRING HARNESS EMERGENCY SWITCH BS6	TATA spare parts
410654610107	WIRING HARNESS EMERGENCY SWITCH BS6	TATA spare parts
410654610108	WIRING HARNESS EMERGENCY SWITCH BS6	TATA spare parts
410654610109	WIRING HARNESS EMERGENCY SWITCH BS6	TATA spare parts
410654610110	WIRING HARNESS EMERGENCY SWITCH BS6	TATA spare parts
410654610112	WIRING HARNESS TAIL	TATA spare parts
410654709901	FASTAG	TATA spare parts
410654804901	ECU RETARDER	TATA spare parts
410654850101	DMS CAMERA BS6-PH2	TATA spare parts
410658990102	KIT-AIS 140 PARTS	TATA spare parts
410658990103	KIT-AIS 140 PARTS	TATA spare parts
410658990104	KIT-AIS 140 PARTS	TATA spare parts
41066000001R40	ASSEMBLY BODY FITTED	TATA spare parts
410683550101	BRACKET ASSY COMPRESSOR MTG BS6	TATA spare parts
410683550110	BRACKET ASSY AC COMPRESSOR MTG BS6	TATA spare parts
410683550122	COMPRESSOR ASSY BS6	TATA spare parts
41068355301	PACKING BS6	TATA spare parts
410683906301	PACKING BS6	TATA spare parts
410683906302	PACKING BS6	TATA spare parts
41100445	BELLOW KIT	TATA spare parts
41100446	IBJ & BELLOW KIT	TATA spare parts
41100447	MOUNTING KIT ASSY	TATA spare parts
416011127004	AXLE RESTRAINT STRAP POLYESTER BS6	TATA spare parts
416012150016	HUB 10*335	TATA spare parts
416012180017	AXLE 1850-TL NON ABS BS6	TATA spare parts
416012180019	AXLE 1850-TL ABS BS6	TATA spare parts
416013150013	AXLE SQUARE 5023/6023 ECO WITH TW-1850	TATA spare parts
416013150014	AXLE SQUARE 5023/6023 ECO BS6	TATA spare parts
416013150026	YORK ECO AXLE	TATA spare parts
416013150041	BRAKE SHOE ȳ 420 X 180 P TYPE	TATA spare parts
416013150044	BRAKE LINING ȳ 420 X 180 AF237	TATA spare parts
416013150045	CAMSHAFT (525MM)	TATA spare parts
416013150046	TOP PLATE (6 IN SQ)	TATA spare parts
416013150047	SPRING SEAT (50MM)-6 IN SQ.	TATA spare parts
416013150048	REAR HANGER	TATA spare parts
416013150049	FIXED TORQUE ARM (395MM)	TATA spare parts
416013150052	FIXED TORQUE ARM (550MM)	TATA spare parts
416013150055	EQUALIZER SHAFT M24 X 1.5	TATA spare parts
416013150063	ANCHOR PIN WASHER	TATA spare parts
416013150066	CAMSHAFT-LH(525MM)	TATA spare parts
416013150067	CAMSHAFT-RH(525MM)	TATA spare parts
416013150080	POLE WHEEL KROSS AXLE WITH SENSOR BS6	TATA spare parts
416016150012	TATA AXLE 135 X 150 WITH 1817-14MM BS6	TATA spare parts
416020750008	LEAF SPRING YTE 75 HOOK	TATA spare parts
416020750013	LEAF SPRING WITH 10 LEAF 16MM THICK BS6	TATA spare parts
416020750101	LEAF SPRING YTE 75 TOP	TATA spare parts
416020759015	LEAF SPRING MOUNTING PLATE ASSY BS6	TATA spare parts

416020759016	LEAF SPRING MOUNTING TOP PLATE ASSY BS6	TATA spare parts
416020759017	LEAF SPRING SET ASSY FOR SUSPENSION BS6	TATA spare parts
416020759018	LEAF SPRING SET ASSY BS6	TATA spare parts
416020759019	LEAF SPRING MTG TOP PLATE ASSY BS6	TATA spare parts
416025750371	U-BOLT SET BS6	TATA spare parts
416025750373	U-BOLT 6INCH SQ.M24*2.0 OVER SLUNG BS6	TATA spare parts
416025750375	U-BOLT 6INCHSQ M22x2.0 375 MM LENGTH	TATA spare parts
416025750392	U-BOLT SET-12 T (AXLE TUBE 135X150) BS6	TATA spare parts
416025750395	U-BOLT 6INCHSQ M22x2.0 395 MM LENGTH	TATA spare parts
416025750408	U BOLT + WASHER + NUT BS6	TATA spare parts
416025750504	U BOLT 450MM(YTE75/90) BS6	TATA spare parts
416030075010	FRONT HANGER	TATA spare parts
416030750014	FRONT HANGER ASSY	TATA spare parts
416030750020	EQUILIZER HANGER YTE 75 CASTED	TATA spare parts
416030750024	FRONT HANGER ASSY BS6	TATA spare parts
416030750030	REAR HANGER YTE 75 BS6	TATA spare parts
416030750032	HANGER BRACKET LH ASSEMBLY BS6	TATA spare parts
416030750033	REAR HANGER ASSY	TATA spare parts
416030750046	EQUALIZER	TATA spare parts
416030750060	HANGER BRACKET RH ASSEMBLY BS6	TATA spare parts
416030750065	HANGER WITH EQUALIZER ASSY BS6	TATA spare parts
416030750066	EQUALISER ASSY FOR 13T SUSPENSION BS6	TATA spare parts
416030750072	EQUALISER ASSEMBLY BS6	TATA spare parts
416030750075	MIDDLE HANGER ASSEMBLY BS6	TATA spare parts
416030759025	EQUALIZER HANGER	TATA spare parts
416035750053	SPRING SEAT (50 MM) 6INCHSQ	TATA spare parts
416036750050	SPRING SEAT 5INCH ROUND AXLE (20MM) BS6	TATA spare parts
416050750360	FIXED TORQUE ARM SMALL 350 MM BS6	TATA spare parts
416050750362	ADJUSTABLE TORQUE ARM SMALL L-380MM BS6	TATA spare parts
416050750364	FIXED TORQUE ARM BIG 470MM BS6	TATA spare parts
416050750368	ADJUSTABLE TORQUE ARM BIG L -470MM BS6	TATA spare parts
416050750371	SILENT BUSH Z PARABOLIC SPRING AIR SUS.	TATA spare parts
416050750381	SILENT BUSH Z PARABOLIC SPRING AIR SUS.	TATA spare parts
416050750395	FIXED TORQUE ARM (FRONT)	TATA spare parts
416050750550	FIXED TORQUE ARM (CENTER AND REAR)	TATA spare parts
416051001260	ADJUSTABLE TORQUE ARM (SCREW 260 MM)	TATA spare parts
416051001420	ADJUSTABLE TORQUE ARM (SCREW 420 MM)	TATA spare parts
416051750395	ADJUSTABLE TORQUE ARM (350MM) BS6	TATA spare parts
416065750056	FIXED TORQUE ARM (CENTER & REAR AXLE) BS	TATA spare parts
416066000003	EQUALIZER BUSH POLY TAPER BUSH RED	TATA spare parts
416066000006	LL EQUALIZER BUSH BS6	TATA spare parts
416066000009	EQUALIZER POLY BUSH 03 (PU) L-110MM BS6	TATA spare parts
416066000010	TORQUE ARM POLY BUSH(PU) L-80MM BS6	TATA spare parts
416066000011	TORQUE ARM POLY BUSH(PU) L-59MM BS6	TATA spare parts
416070000000	LANDING GEAR SET YT 28A	TATA spare parts
416070000003	TWO SPEED LANDING	TATA spare parts
416070000015	LANDING GEAR SET 28T BS6	TATA spare parts



416075002001	SLACK ADJUSTER	TATA spare parts
416075002002	NON ABS AXLE W/MANUAL SLACK ADJUSTER BS6	TATA spare parts
416075003001	ANCHORE LINING 480*180	TATA spare parts
416075005007	DRUM MACHINING 420x180 10x335 OB	TATA spare parts
416075005019	DRUM MACHINING 420X180 10X335OB	TATA spare parts
416075006002	LINED SHOE ASSY	TATA spare parts
416075007001	LINING RIVET	TATA spare parts
416075012001	O RING	TATA spare parts
416075012011	GASKET BS6	TATA spare parts
416075013001	HUB SEAL	TATA spare parts
416075014118	CIRCLIP (11/2INCH)	TATA spare parts
416075014122	CIRCLIP AXLE ID 70.5	TATA spare parts
416075015001	DUST SEAL CAMSHAFT	TATA spare parts
416075016001	DUST COVER-UPPER R SQUARE	TATA spare parts
416075016004	DUST COVER-LOWER R SQUARE	TATA spare parts
416075016007	DUST COVER-UPPER R SQUARE	TATA spare parts
416075017001	DUST COVER-LOWER L SQUARE	TATA spare parts
416075018001	DUST COVER PLUG	TATA spare parts
416075022001	SPACER WASHER	TATA spare parts
416075026001	SPINDLE LOCKNUT-FORGING	TATA spare parts
416075027001	INNER BEARING	TATA spare parts
416075028001	OUTER BEARING	TATA spare parts
41607503002	HUB CAP-3 HOLES DIA 150 PCD	TATA spare parts
416075032014	CAM ROLLER (11/4INCH)	TATA spare parts
416075034001	ANCHOR PIN P TYPE	TATA spare parts
416075034002	CIRCLIP (11/4INCH) ANCHOR PIN	TATA spare parts
416075034004	ANCHOR PIN	TATA spare parts
416075036001	M8x1.25x16 FLANE BOLT GALVANISED O	TATA spare parts
416075041002	EQUALIZER SHAFT WASHER	TATA spare parts
416075043001	GREASE NIPPLE EXTENTION 52	TATA spare parts
416075043002	GREASE NIPPLE M10 X 1 BS6	TATA spare parts
416075046007	ROLLER RETAINER SPRING BS6	TATA spare parts
416075048003	RADIUS ROD BUSH (POLY-RED)	TATA spare parts
416075052001	WASHER (TORQUE ARM )	TATA spare parts
416075053001	TORQUE ARM PIN NM	TATA spare parts
416075053017	FLANGED BOLT AT AXLE PAD & FRONT HANGER	TATA spare parts
416075053018	FLANGED BOLT AT MIDDLE -M24X3XL250 BS6	TATA spare parts
416075053019	FLANGED BOLT EQUALIZER-M24X3XL342 BS6	TATA spare parts
416075053029	FLANGED BOLT EQUALIZER M24X3XL 342MM BS6	TATA spare parts
416075054003	WHEEL STUD	TATA spare parts
416075054004	M22x2.5x98 WHEEL STUD	TATA spare parts
416075054016	WHEEL NUT	TATA spare parts
416075055001	CENTRE BOLT BS6	TATA spare parts
416075055008	M22x2.0 HEX THIN NUT U-BOLT	TATA spare parts
416075061001	ROLLER RETAINER SPRING	TATA spare parts
416075061007	RETURN SPRING	TATA spare parts
416075066003	GREASE NIPPLE -1/8INCH BSPT STRAIGHT BS1	TATA spare parts

416075066017	ADJUSTABLE TORQUE ARM END RH-900024R	TATA spare parts
416075066018	ADJUSTABLE TORQUE ARM END LH-900024L	TATA spare parts
416075066020	TAB LOCK WASHER TORQUE ARM	TATA spare parts
416075066021	KIT EQUALIZER SHAFT YTE 75/90 BS6	TATA spare parts
416075066023	KIT WEAR PAD EQUALIZER 75/90 BS6	TATA spare parts
416075066026	WEAR PAD	TATA spare parts
416075066028	HEX LOCK NUT M24	TATA spare parts
416075066041	LOCK NUT M24X3 L = 12 MM - CL 10 BS6	TATA spare parts
416075066042	LOCK NUT M30X3.5 L = 15 MM - CL 10 BS6	TATA spare parts
416075500014	BRAKE REPAIR KIT (1 WHEEL) BS6	TATA spare parts
416075500021	KIT SINGLE NUT (EACH 2 NOS 789257 KEY 78	TATA spare parts
416076000045	ROLLER RETAINER SPRING	TATA spare parts
416076000048	BRAKE SHOE-420 $\phi$ 180 BRAKE AF237	TATA spare parts
416076000062	HUB SEAL YORK 786114	TATA spare parts
416076000069	HUB CAP GASKET/ O RING	TATA spare parts
416076000080	WASHER M12 5 MM	TATA spare parts
416076000100	M24 FLAT WASHER-HARDENED YORK BS6	TATA spare parts
416076000310	M30 FLAT WASHER-HARDENED BS6	TATA spare parts
416076000311	HUB BS6	TATA spare parts
416076000312	BRAKE DRUM BS6	TATA spare parts
416076000313	HUB SEAL BS6	TATA spare parts
416076000314	HUB BOLTS BS6	TATA spare parts
416076000315	HUB NUTS BS6	TATA spare parts
416076000316	SPINDLE NUT BS6	TATA spare parts
416076000317	SPINDLE WASHER BS6	TATA spare parts
416076000318	SPINDLE NUT LOCK BS6	TATA spare parts
416076000319	HUB CAP GASKET BS6	TATA spare parts
416076000320	HUB CAP BS6	TATA spare parts
416076000321	ANCHOR PIN CIRCLIP BS6	TATA spare parts
416076000322	ANCHOR PIN WASHER BS6	TATA spare parts
416076000323	ANCHOR PIN BS6	TATA spare parts
416076000324	ANCHOR PIN BUSH BS6	TATA spare parts
416076000325	CAMSHAFT CIRCLIP BS6	TATA spare parts
416076000326	CAMSHAFT WASHER BS6	TATA spare parts
416076000327	O-RING CYLINDRICAL BUSH BS6	TATA spare parts
416076000328	CYLINDRICAL NYLON BUSH BS6	TATA spare parts
416076000329	DUST CAP - CAMSHAFT BS6	TATA spare parts
416076000330	SPHERICAL NYLON BUSH BS6	TATA spare parts
416076000331	COVER - SPHERICAL NYLON BUSH BS6	TATA spare parts
416076000332	CAMSHAFT LH BS6	TATA spare parts
416076000333	CAMSHAFT RH BS6	TATA spare parts
416076000334	CAM ROLLER BS6	TATA spare parts
416076000336	BRAKE PIN BS6	TATA spare parts
416076000337	ROLLER RETURN SPRING BS6	TATA spare parts
416076000339	BRAKE SHOE ASSEMBLY BS6	TATA spare parts
416076000342	RIVIT BS6	TATA spare parts
416076000344	GREASE NIPPLE BS6	TATA spare parts

416076000350	SLACK ADJUSTOR (MANUAL) BS6	TATA spare parts
416076000351	SLACK ADJUSTOR SPRING BS6	TATA spare parts
416076000352	BEARING 518445 BS6	TATA spare parts
416076000353	M8 SPRING WASHER BS6	TATA spare parts
416076000363	HEX BOLT - M24X3.0XL-195MM P-10.9 BS6	TATA spare parts
416076000407	SPINDLE BS6	TATA spare parts
416076000438	TOP AIR BAG BASE PLATE_NEW BS6	TATA spare parts
416080002006	KING PIN 2INCH WELDABLE BS6	TATA spare parts
416080002009	KING PIN 2INCH 162KN BOLT BS6	TATA spare parts
416080002010	BEAM - 1850 BS6	TATA spare parts
416080002011	BEAM - 1950 BS6	TATA spare parts
416080002012	M10 - STAR WASHER BS6	TATA spare parts
416080002014	ANCHOR SPIDER BS6	TATA spare parts
416080002015	INNER CAM BRACKET BS6	TATA spare parts
416080002016	CAM ROLLER ASSEMBLY BS6	TATA spare parts
416080002017	CAM LINNER ASSEMBLY BS6	TATA spare parts
416080002018	ANCHOR LINNER ASSEMBLY BS6	TATA spare parts
416080002019	CAMSHAFT REPAIR KIT BS6	TATA spare parts
416080002020	CAMSHAFT BUSH REPAIR KIT BS6	TATA spare parts
416080002021	BRAKE LINER KIT BS6	TATA spare parts
416080002022	BRAKE REPAIR KIT (1 WHEEL) BS6	TATA spare parts
416080002023	DUST COVER SET BS6	TATA spare parts
416080002024	HUB MAINTANENCE KIT BS6	TATA spare parts
416080020001	KING PIN DIA 2INCH (WELDABLE) YORK BS6	TATA spare parts
416082000017	PTO KIT GB 1150 BS6	TATA spare parts
416082000093	GEAR PUMP 082L-LH-4H0-16BSP16 BS6	TATA spare parts
416091750003	SUSPENSION SET - YORK 75	TATA spare parts
416091750017	TRIDEM AXLE FABRICATED SUSPENSION SET WI	TATA spare parts
416091750022	TRIDEM HD CASTED SUSPENSION SET WITH 10	TATA spare parts
416091750024	9 LEAF TRIDEM AXLE SUSPENSION SET	TATA spare parts
416091759004	TRIDEM FABRICATED 75/90 SUSPENSION BS6	TATA spare parts
416092400133	PIPING KIT FOR 3A DLT AIR SUSP BS6	TATA spare parts
416092750001	SHOCK ABSORBER (RAMBAL) BS6	TATA spare parts
416525100200	FLAP 10.00 X 20.00 BS6	TATA spare parts
416530075200	WHEEL RIM 7.5 X 20	TATA spare parts
416540000001	MUDGUARD-FRP	TATA spare parts
416540000011	MUDGUARD-PLASTIC	TATA spare parts
416550560560	SPRAY SUPPRESSION 560 X 560	TATA spare parts
417011008025	PIVOT BOLT - M30X3.5XL-195MM P-10.9 BS6	TATA spare parts
417011008047	HEX BOLT M16X2X40 CL 10.9 BS6	TATA spare parts
417011010007	HEX BOLT (M10*16) BS6	TATA spare parts
417011012007	M12x1.75x50 HEX BOLT	TATA spare parts
417011012016	M12x1.75x130 HEX BOLT	TATA spare parts
417011012048	BOLT M12 X 60 GRADE 10.9 BS6	TATA spare parts
417011012059	HEX BOLT M12X1.75X90 CL 10.9 BS6	TATA spare parts
417011012063	HEX BOLT M12X1.75X45 CL 10.9 BS6	TATA spare parts
417011024007	HEX BOLT - M24X3.0XL-150MM P-10.9 BS6	TATA spare parts

417012010002	M10*16 HEX BOLT BS6	TATA spare parts
417012016047	M16X2X150 - 10.9G HALF THREAD HEX BOLT B	TATA spare parts
417040012002	M12x1.75 NYLON LOCK NUT	TATA spare parts
417040022004	M22*2.0 NUT FOR U-BOLT	TATA spare parts
417041003002	NYLOCK NUT - M30X3.5 P10.0 BS6	TATA spare parts
417041008010	NYLOC NUT M8 X 1.0 BS6	TATA spare parts
417041012010	NYLOC NUT M12 BS6	TATA spare parts
417041014005	WASHER SHOCK ABSORBER OD40XID25X4 BS6	TATA spare parts
417041016004	M12X1.75 NYLOC LOCKNUT BS6	TATA spare parts
417041016005	M16 X 2 CL10 NYLOC NUT BS6	TATA spare parts
417041024002	M24 X 3 CL10 NYLOC NUT BS6	TATA spare parts
417041024023	SINGLE LOCK NUT	TATA spare parts
417050012048	TAB LOCK WASHER BS6	TATA spare parts
417050016001	WASHER M-16 BS6	TATA spare parts
417050016002	M22 & 7/8INCH WASHER FOR U-BOLT	TATA spare parts
417050016022	M16 FLAT WASHER-HARDENED BS6	TATA spare parts
417050024002	WASHER - M24 OD 63 BS6	TATA spare parts
417050024003	WASHER OD-100 X ID-26 X 8MM THICK BS6	TATA spare parts
417051060042	SPLIT PIN 4X50 FOR C.C. BS6	TATA spare parts
417058040001	DIA 3x25L SPLIT PIN	TATA spare parts
417533050061	HEX BOLT M12x1.75x30	TATA spare parts
417535008103	TOP SUPPORT ASSY LIFT AXLE ARANGMENT BS6	TATA spare parts
417535010104	BOTTOM SUPPORT ASSY TDLT LIFT AXLE BS6	TATA spare parts
417535080004	FB TOP CLAMP PLATE (75/90 SUSP) BS6	TATA spare parts
417535080046	LANDING LEG BKT.RH	TATA spare parts
417535080047	LANDING LEG BKT.LH	TATA spare parts
417535080089	BOTTOM Z BRACKET ASSEMBLY - LH BS6	TATA spare parts
417535080095	SUPPORT PLATE TO HANGER BRACKET BS6	TATA spare parts
417535080099	BOTTOM Z BRACKET ASSY LEAF SPRING_ RH BS6	TATA spare parts
417535120042	TOP U BOLT BRACKET BS6	TATA spare parts
417535120043	BOTTOM U BOLT BRACKET BS6	TATA spare parts
417535120406	AIR CHAMBER MOUNTING BRACKET BS6	TATA spare parts
417535160034	TOP LEAF	TATA spare parts
417535160049	HOOK LEAF	TATA spare parts
417540008006	PLATE- LONG VEHICLE (200X340X0.8 MM)	TATA spare parts
417540008007	PLATE- NUMBER PLAIN (200X340X0.8 MM) BS6	TATA spare parts
417540008034	TATA DLT ALUMINIUM NAME PLATE (500X100X0	TATA spare parts
417540008056	NAME PLATE FOR AIR SUSPENSION BS6	TATA spare parts
417560010001	SEAMLESS PIPE OD 25 ID 20 L=92 MM BS6	TATA spare parts
417560048010	BUSH WEAR PAD	TATA spare parts
417570050017	FLOOR BUSH OD 40 ID 30 L 34MM BS6	TATA spare parts
417570050018	REAR HINGE PIN BUSH OD 40 ID 30 L 20MM B	TATA spare parts
417570050019	INNER BUSH OD 40 ID 30 L 60MM BS6	TATA spare parts
417570050020	OUTER BUSH OD 50 ID 40 L 60MM BS6	TATA spare parts
417570050021	PARTITION LOCK BUSH OD20 X ID10 X L20MM	TATA spare parts
417580025005	REAR HINGE PIN OD 40 OD 29.5 L 130MM BS6	TATA spare parts
417580025006	CYL BOT MTG PIN OD 50 OD 39.5 L 160MM BS	TATA spare parts

417580025007	TD HINGE PIN OD 30 OD 19.5 L 40MM BS6	TATA spare parts
417580080001	REAR LOCKING PIN -1 L=55 DIA 80MM BS6	TATA spare parts
417580080002	REAR LOCKING PIN-2 L=190 DIA 35MM	TATA spare parts
417585000026	HANDLE LH	TATA spare parts
417585000027	HANDLE RH	TATA spare parts
417585001504	DUST COVER MOUNTING PLATE BS6	TATA spare parts
417590000005	SPARE WHEEL CARRIER ASSLY ( SWC ASSE- 04	TATA spare parts
417590000015	RUPD	TATA spare parts
417590000016	SUPD ASSLY (7)	TATA spare parts
417590000017	SUB ASSY 1.9 - PARKING BRAKE BRACKET BS6	TATA spare parts
417590000023	TWIST LOCK OUTER	TATA spare parts
417590000024	TWIST LOCK INNER	TATA spare parts
417590000026	SUPD ASSLY 40FT - 3AFB	TATA spare parts
417590000028	SUPD ASSLY 40 - 3ASK	TATA spare parts
417590000056	SUPD ASSLY. 10M SW BS6	TATA spare parts
417590000061	TOOL BOX ASSEMBLY MM BS6	TATA spare parts
417590000090	TARPAULIN BOX - 1220 X 412 X 412 BS6	TATA spare parts
417590000129	SUB ASSY 1.9 - PARKING BRAKE BRACKET FOR	TATA spare parts
417590000162	1300 EQUALISER ASSLY LH BS6	TATA spare parts
417590000163	1300 EQUALISER ASSLY RH BS6	TATA spare parts
417590000176	REAR PANEL ASSY 9M/7M CLASSIC 2480*850 M	TATA spare parts
417590000195	FRONT PANEL ASSLY FOR 30FT3ASW-4 FT HEIG	TATA spare parts
417590000214	SIDE PANEL ASSLY 30FTSW-4 FT HEIGHT-WITH	TATA spare parts
417590000313	FRONT PANEL ASSY 10.4M 3AXLE BS6	TATA spare parts
417590000404	SUPD ASSLY-LH 40FT - 3AFB	TATA spare parts
417590000467	SIDE PANEL CORROGATED PANEL BS6	TATA spare parts
417590000534	PANEL SUPP. ASSY (CORRUGATED PANEL) BS6	TATA spare parts
417590000603	SIDE PANEL L=10345* H=1220 MM CORROGATED	TATA spare parts
417590000635	5FT SIDE PANEL ASSEMBLY WITH DOOR BS6	TATA spare parts
417590000693	REAR BRACKET ASSY-13T SUSPENSION BS6	TATA spare parts
417590000833	TORQUE ARM BRACKET ASSY SUSPENSION BS6	TATA spare parts
417590000854	FRONT BRACKET ASSY BS6	TATA spare parts
417590000920	FRONT BRACKET ASSEMBLY BS6	TATA spare parts
417590000924	REAR BRACKET ASSEMBLY BS6	TATA spare parts
417590000939	EQUALIZER HANGER BS6	TATA spare parts
417590001056	SPRING SEAT ASSEMBLY BS6	TATA spare parts
417590001501	SIDE PANEL BS6	TATA spare parts
417590001546	HYD CYLINDER WITH TC0180- PTT905001X050	TATA spare parts
417590001737	U-BOLT HOLDING BRACKET BS6	TATA spare parts
417590001738	Z-SPRING ASSEMBLY BUSH DIA-68 BS6	TATA spare parts
417593003003	HINGES ASSY FOR 10M SW	TATA spare parts
418010000007	7 PIN CONNECTOR	TATA spare parts
418010000012	BRAKE SPIDER (L)	TATA spare parts
418010000028	REDUCER FOR T-CONNECTOR	TATA spare parts
418020024001	TAIL LAMP LH	TATA spare parts
418020024002	TAIL LAMP RH	TATA spare parts
418021024001	TOP MARKER LAMP	TATA spare parts

418021024035	LAMP - 24 V FIEM SIDE MARKER LAMP	TATA spare parts
418021024038	SIDE MARKER LAMP-24V(HILUX) BS6	TATA spare parts
418025000002	REFLECTOR-WHITE	TATA spare parts
418035000002	WIRING HARNESS ĩ DLT TRAILER 9.2 M	TATA spare parts
418035000004	WIRING HARNESS -12M SK	TATA spare parts
418035000005	WIRING HARNESS -12M FB	TATA spare parts
418035000008	WIRING HARNESS - 10M SW BS6	TATA spare parts
418100990106	RETRO KIT FOR COMPRESSOR PLUMBING IMPROV	TATA spare parts
418100990111	RETRO KIT-FAN SUPPORT BEARING	TATA spare parts
418101000102	ENGINE 6BTAA-EII 24V-45A 180HP	TATA spare parts
418101000103	ENGINE 6BTAA.180@2500.24V.LMFO.BS-3	TATA spare parts
418101000104	ASSY ENGINE COMPLETE 6 BTAA(180 H.P) BS-	TATA spare parts
418101000110	ENGINE OPTION 6BTA.242 2500	TATA spare parts
418101000112	ENGINE LPO 1618 RE A/T WITH N	TATA spare parts
418101000118	ENGINE ISBE5.9 230HP BS4 (FOR AT)	TATA spare parts
418101000121	ENGINE ISBE 5.9 230 HP DSL BS3 N/AC	TATA spare parts
418101000122	ENGINE COMPLETE ISBE 230 HP DSL BS4 N/AC	TATA spare parts
418101000124	ENGINE ASSY	TATA spare parts
418101040101	ASSY ENGINE FOR 1624LE	TATA spare parts
418101050101	ENGINE KIT ISB6.7 E245 BS-IV 1624LE	TATA spare parts
418103114701	BOTTOM COVER (FLYWHEEL HOUSING)	TATA spare parts
418105010102	ASSY ENGINE C8.3G CNG BSIII	TATA spare parts
418105030102	ASSY ENGINE - B.5.9G(BG PLUS230) BSIII	TATA spare parts
418105080101	ENGINE ASSY 6BG+ 5.9G (BG PLUS230) B	TATA spare parts
418105080102	ENGINE G6BT5.9 HELIOS 230HP BSIV	TATA spare parts
418109130108	RESTRICTION INDICATOR PIPE ASSY	TATA spare parts
418109130110	ASSY BRACKET AIR PRECLEANER MTG	TATA spare parts
418109130111	ASSY AIR COMPRESSOR INLET PIPE	TATA spare parts
418109130114	ASSY. AIR FILTER	TATA spare parts
418109130122	ASSY BRACKET (FOR PRECLEANER MTG.)	TATA spare parts
418109130124	CLAMP ASSY AIR INTAKE PIPE	TATA spare parts
418109133801	CAST PIPE AIR FILTER TO TC	TATA spare parts
418109133803	AIR INTAKE PIPE (AIR FILTER TO TURBO)	TATA spare parts
418109135802	RUBBER BELLOW ON AIR FILTER	TATA spare parts
418109135804	HOSE REDUCER (140 ID TO 102 ID)	TATA spare parts
418109135805	RUBBER HOSE	TATA spare parts
418109135807	ELBOW-2	TATA spare parts
418109135808	HOSE PRECLEANER EXTENSION	TATA spare parts
418109135810	HOSE REDUCER (140 ID TO 102 ID)	TATA spare parts
418109135813	HOSE ELBOW 130 DEGREE 152 ID	TATA spare parts
418109135814	HOSE ELBOW 90 DEGREE 152.9 ID	TATA spare parts
418109136901	PIPE (PRECLEANER TO AIR FILTER)	TATA spare parts
418109136902	FLEXIBLE HOSE	TATA spare parts
418109136903	AIR INTAKE PIPE (AIR FILTER TO TURBO)	TATA spare parts
418109136904	PIPE-1 ( PRE - CLEANER TO AIR FILTER)	TATA spare parts
418109136905	PIPE-II (PRE-CLEANER TO AIR FILTER)	TATA spare parts
418109136906	PIPE AIR FILTER TO TURBO	TATA spare parts

418109136907	FLEXIBLE HOSE	TATA spare parts
418109136909	PIPE- I (PRE-CLEANER TO AIR FILTER)	TATA spare parts
418109136910	PIPE- II (PRE-CLEANER TO AIR FILTER)	TATA spare parts
418109136915	PIPE AIR INTAKE FILTER TO TURBO	TATA spare parts
418109136916	PIPE AIR INTAKE PRE FILTER TO FILTER	TATA spare parts
418109136921	PIPE (PRE CLEANER TO AIR FILTER)	TATA spare parts
418109138202	L - BRACKET (AIR INTAKE PIPE SUPPORT)	TATA spare parts
418109138207	L-BRACKET	TATA spare parts
418109139904	ADAPTOR (M10X1 FEMALE TO 1/8 INCH FEMALE)	TATA spare parts
418109139906	FEMALE ADAPTOR M10 X 7/16IN-20 UNF CLASS	TATA spare parts
418113130103	HOSE 18MM ID COMPRESSOR	TATA spare parts
418114580101	HEAT SHIELD ASSY (TC LUB OIL DRAIN HOSE)	TATA spare parts
418114587101	BRACKET - L	TATA spare parts
418114603801	PIPE-INTERCOOLER TO TURBOCHARGER	TATA spare parts
418114603802	PIPE-INTERCOOLER TO ENGINE	TATA spare parts
418114603804	PIPE TURBO OUT TO INTERCOOLER FOR LPO 16	TATA spare parts
418114603805	CAST PIPE INTERCOOLER TO ENGINE	TATA spare parts
418114603806	PIPE TURBO TO INTERCOOLER	TATA spare parts
418114603808	CAST PIPE CAC TO INTAKE	TATA spare parts
418120150101	ASSY BRACKET (FAN DRIVE)	TATA spare parts
418120150103	ASSY BRACKET	TATA spare parts
418120150105	ASSY BRACKET (FOR FAN IDLER)	TATA spare parts
418120150106	ASSY FAN 28 INCH	TATA spare parts
418120150107	ASSY BRKT IDLER PULLEY MTG	TATA spare parts
418120150110	ASSY IDLER FAN PULLEY MTG BKT	TATA spare parts
418120150111	ASSY SPRING TENSION ADJUSTING BKT	TATA spare parts
418120150118	ASSY. FAN DRIVE MTG. ARRANGEMENT	TATA spare parts
418120150119	SWING ARM ASSEMBLY FOR IDLER PULLEY	TATA spare parts
418120150120	ASSY.¿ BEARING HOUSING (FAN DRIVE)	TATA spare parts
418120150122	IDLER PULLEY ASSY. MTG. BRACKET	TATA spare parts
418120150123	RING MOUNTING BRACKET ASSY	TATA spare parts
418120150131	ASSY IDLER PULLEY MTG. BRACKET	TATA spare parts
418120150132	ASSY IDLER FAN PULLEY MTG BKT	TATA spare parts
418120150134	ASSY FAN DRIVE BEARING HOUSING - LH	TATA spare parts
418120150135	ASSY FAN DRIVE MTG ARRANGEMENT LH	TATA spare parts
418120150136	ASSY RING MTG BKT - LH	TATA spare parts
418120150137	ASSY STOPPER PLATE	TATA spare parts
418120153801	ALUMINIUM RING (FAN SHROUD)	TATA spare parts
418120154201	HOSE CLAMP(760 ID)	TATA spare parts
418120156301	COGGED V BELT TWIN GROOVE	TATA spare parts
418120156304	COGGED V BELT TWIN GROOVE	TATA spare parts
418120156305	COGGED V BELT TWIN GROOVE	TATA spare parts
418120156306	FAN	TATA spare parts
418120156308	COGGED V BELT TWIN GROOVE BS3	TATA spare parts
418120156313	COGGED V BELT TWIN GROOVE	TATA spare parts
418120156319	TWIN GROOVE V-BELT	TATA spare parts
418120156322	FAN DRIVE BELT	TATA spare parts

418120156323	COGGED V-BELT	TATA spare parts
418120157001	PULLEY FAN	TATA spare parts
418120157002	FAN PULLEY (145 DIA)	TATA spare parts
418120157003	PULLEY (ENGINE)	TATA spare parts
418120157009	PULLEY 189 DIA (FAN DRIVE SYSTEM)	TATA spare parts
418120157010	IDLER PULLEY (FAN DRIVE)	TATA spare parts
418120157501	RUBBER BUSH FAN BKT. MTG	TATA spare parts
418120157701	RUBBER RING (FAN DRIVE SYSTEM)	TATA spare parts
418120157901	SHAFT (FOR 28 IN VISCOUS FAN MTG)	TATA spare parts
418120158203	SPACER PLATE (IDLER PULLEY MTG BKT)	TATA spare parts
418120990101	RETRO KIT FOR FAN DRIVE ARRENGEMENT	TATA spare parts
418123120101	ASSY BRACKET (COMPRESSOR MOUNTING)	TATA spare parts
418123127001	PULLEY (AC COMPR.) CNC M/CED	TATA spare parts
418150106901	PIPE RADIATOR TO OIL COOLER	TATA spare parts
418150106902	PIPE OIL COOLER TO ENGINE WATER PUMP	TATA spare parts
418209130214	ASSY SNORKEL BOX	TATA spare parts
418301000103	ENGINE ISBE WITH SAE1 HSG	TATA spare parts
418309130109	ASSY. AIR FILTER	TATA spare parts
418309135802	RIBBED HOSE ELBOW	TATA spare parts
418309136903	AIR INTAKE PIPE AIR FILER TO TURBOCHARGE	TATA spare parts
418309136904	PIPE (PRE-CLEANER TO AIR FILTER)	TATA spare parts
418309138203	BKT AIR FILTER HOSE	TATA spare parts
418309139903	ASSY RESTRICTION INDICATOR ELECTROMECHAN	TATA spare parts
418313130101	HOSE ASSY (18MM ID)	TATA spare parts
418313130105	ASSY PIPE(AIR COMP OUTLET)	TATA spare parts
418313130110	SUCTION PIPE-1	TATA spare parts
418313130113	HOSE 18MM ID 318CC COMP	TATA spare parts
418313139901	CONNECTOR ( AIR COMPRESSOR INLET )	TATA spare parts
418320150101	SWING ARM ASSY. (FOR IDLER PULLEY)	TATA spare parts
418320150102	ASSY. BRACKET (FAN PULLEY MTG.)	TATA spare parts
418320150103	ASSY BRKT IDLER PULLEY MTG	TATA spare parts
418320150104	ASSY BRKT IDLER SPRING MTG	TATA spare parts
418320150107	FAN 28 INCH HIGHDECK BS3/4	TATA spare parts
418320150124	FAN DRIVE ASSY	TATA spare parts
418320153303	Z BKT (HOSE CLAMPING) BS6	TATA spare parts
418320153405	SHOULDER BOLT	TATA spare parts
418320153406	BUSH DIA28 SWING ARM BS4	TATA spare parts
418320156301	COGGED V BELT TWIN GROOVE	TATA spare parts
418320156304	COGGED V BELT TWIN GRROVE	TATA spare parts
418320157001	PULLEY (ENGINE)	TATA spare parts
418320157002	PULLEY (ENGINE)	TATA spare parts
418323120101	ASSY COMPRESSOR AC	TATA spare parts
418323126301	COGGED V-BELT (AC DRIVE) TWIN GROOVE	TATA spare parts
418510000001	PALM COUPLING -SUPPLY (RED)	TATA spare parts
418510000002	PALM COUPLING -CONTROL (YELLOW)	TATA spare parts
418515000038	3/8 $\times$ RUBBER BRAKE HOSE	TATA spare parts
418516038014	NYLON TUBE 3/8INCHX 1/4INCH - RED	TATA spare parts



418517038014	NYLON TUBE 3/8INCHX 1/4INCH- YELLOW	TATA spare parts
418520040001	AIR RECEIVER TANK 40 LTR. WITH DRAIN VAL	TATA spare parts
418520050001	AIR RECEIVER TANK 50 LTR W/DRAIN VALVE B	TATA spare parts
418530000001	RELAY EMERGENCY VALVE	TATA spare parts
418532000001	DRAIN VALVE FOR AIR TANK BS6	TATA spare parts
418535014039	CONNECTOR WITH FERULE M14 X	TATA spare parts
418536016001	BULK HEAD COUPLING M16 X 1.5MM	TATA spare parts
418538014038	HOSE NIPPLE 1/4INCH X 3/8INCH	TATA spare parts
418538016015	HOSE NIPPLE M16 X 1.5	TATA spare parts
418542000001	HOSE CLIP	TATA spare parts
418550030223	CONNECTOR M22 X 1.5	TATA spare parts
418550060001	BRAKE CHAMBER TYPE 30 YORK	TATA spare parts
418550060002	BRAKE CHAMBER TYPE 24	TATA spare parts
418550060005	BRAKE CHAMBER PUSH ROD 75MM(100850610)	TATA spare parts
418567000030	TRIDEM ABS KIT WITH SBA PROVISION BS6	TATA spare parts
418900000027	STICKER TATA LOGO (SIZE-170X150 MM.) BS6	TATA spare parts
418900000034	REFLECTIVE TAPE -RED-1.45 MTR BS6	TATA spare parts
418900000035	REFLECTIVE TAPE YELLOW 3.8 MTR BS6	TATA spare parts
422310250001	SHAFT BS6	TATA spare parts
423320320001	GRAB HANDLE PIPE (L=420 25.4 DIA)	TATA spare parts
423320340001	INNER GRAB HANDLE 207DI (VIPUL)	TATA spare parts
423320440001	GRAB HANDLE (CASTING)	TATA spare parts
426025000030	AIR SPRING (W01M588106) BS6	TATA spare parts
426040650001	PLASIC MUDGUARD	TATA spare parts
426040650004	AIR SPRING ASSEMBLY BS6	TATA spare parts
426070000000	LANDING GEAR SET 28T BS6	TATA spare parts
42684000RF	MOULDING	TATA spare parts
4280573	HOSE HOLDER SUPPORT BS6-PH2	TATA spare parts
429201003008	A PILLAR ASSY LH BS6	TATA spare parts
429201003016	A PILLAR ASSY RH BS6	TATA spare parts
429201003018	WIPER MOUNTING BRKT ASSY_2.34 BS6	TATA spare parts
429201003035	WIPER MOUNTING BRKT ASSY_2.34 BS6	TATA spare parts
429201004007	FRONT BOTTOM TUBE ASSY BS6	TATA spare parts
429201013019	FRONT STR VERTICAL TUBE BS6	TATA spare parts
429202002011	REAR STRUCTURE ASSY_ WIDER_ ROLL OVER	TATA spare parts
429203002042	SIDE STRUCTURE ASSEMBLY RH 45WB_4SPCR B	TATA spare parts
429203003156	LH SIDE SOLEBAR ASSEMBLY -LPO-54WB BS6	TATA spare parts
429203003158	RH SIDE SOLEBAR SUB ASSEMBLY-LPO-54WB BS	TATA spare parts
429203004014	DOOR A_PILLER SUPPORT TUBE ASSY BS6	TATA spare parts
429203083099	SKIRT RAIL G-PROFILE BS6	TATA spare parts
429206004024	FLOOR CROSS MEMBER SUB ASSEMBLY BS6	TATA spare parts
429210231001	WS FRONT WNDSHLD LPO_G3_2.34 WP BS6	TATA spare parts
429210231002	WS FRONT WNDSHLD LPO_WDR_G3_2.55 WP BS	TATA spare parts
429210231003	WS FRONT WNDSHLD LP_G3_3-2.20 WP BS6	TATA spare parts
429210231004	WS CX G3-2.2 FRONT WINDSHIELD WP BS6	TATA spare parts
429210901002	G3 DD LOCK WITH KEY BS6	TATA spare parts
429210901003	VINYL FLOOR 1.5MM THK BS6	TATA spare parts

429210901004	RAIN GUTTER ALUMINIUM PROFILE 6 MTRS BS6	TATA spare parts
429210901005	EXTERNAL PANELING PROFILE 6 MTRS BS6	TATA spare parts
429210901006	SIDE EXT PANELLING FINISH AL PROFILE 6M	TATA spare parts
429210901007	ALUMINIUM PROFILE 6MTRS BS6	TATA spare parts
429210901008	PU TUBE RED OD6 X ID3 SHAVO 20M	TATA spare parts
429210901009	PU TUBE YELLOW OD6 X ID3 SHAVO 15M	TATA spare parts
429210901010	PU TUBE 6MM OD X 3MM ID (BLUE COLOR) 10M	TATA spare parts
429210901011	ALUMINIUM PROFILE 201 6 MTR BS6	TATA spare parts
429210901013	PASTED GLASS SUPPORT EXTRUSION 6 MTR BS6	TATA spare parts
429210901014	2INCH BUTYL TAPE FOR ROOF PANELING 10M	TATA spare parts
429210901015	Grey finishing rubber profile_MP type 6M	TATA spare parts
429210901016	ROOF EXT JOINT FINISHING AL PROFILE 6M B	TATA spare parts
429210901017	ALUMINIUM PROFILE 202 6M	TATA spare parts
429210901018	ROOF EXT JOINT FINISHING AL PROFILE 6M B	TATA spare parts
429210901019	INTERNAL WINDOW PROFILE 5M	TATA spare parts
429210901020	ENGINEHOOD SEALING RUBBER 25M BS6	TATA spare parts
429210901021	ALUMINIUM PROFILE 6M	TATA spare parts
429210901022	AL PROFILE FOR VINYL FINISHING 3M BS6	TATA spare parts
429210901025	ALUMINIUM PROFILE FOR INSPECTION LID 6M	TATA spare parts
429210901026	RUBBER BEADING FIXED(PEEP) GLASS 10M	TATA spare parts
429210901027	VINYL FLOOR 1.5THK_RE CANOPUS 24SQM	TATA spare parts
429210901028	WLDNG ROD FOR BLUE SHADE VNYL_TRINGL10M	TATA spare parts
429210901029	VINYL FLOOR 1.5 MM THK_GREY 24SQM	TATA spare parts
429210901030	WELDING ROD GREY (TRIANGLE) 10M	TATA spare parts
429210901031	VINYL 1.0 MM YELLOW CANOPUS PLUS 24SQM	TATA spare parts
429210901032	NEW FLOCK CHANNEL_TPE 6M	TATA spare parts
429210901034	STEP FINISHING AL. PROFILE FOR FESLF 3M	TATA spare parts
429210901035	PVC FOR STEP FINISHING PROFILE FESLF 3M	TATA spare parts
429210901036	SEAT RAIL FINISH CVER_BEIGEBRAUN 6M	TATA spare parts
429210901037	SIDE INT PANELING PVC PRFL B/W SHEETS 6M	TATA spare parts
429210901038	HALF ROUND PROFILE-PVC (RAL 8024) 3M	TATA spare parts
429210901039	VINYL FLOOR 1.5THK_RE CANOPUS 24SQM	TATA spare parts
429210901040	TOP CLOSING WINDOW PRFL_RAL 8024 5MTR	TATA spare parts
429210901041	INTERNAL WINDOW PROFILE_RAL-8024 5MTR	TATA spare parts
429210901047	NEW FLOCK CHANNEL_TPE_4MM GLASS 25MTR	TATA spare parts
429210901053	VINYL 1.2 MM THK BUTTON GREY 24SQM BS6	TATA spare parts
429210901055	SIDE INTERNAL PANELING RH SIDEAB 2.02 M	TATA spare parts
429210901056	SOLID RUBBER PROFILE (BLACK)_50M BS6-P	TATA spare parts
429210901057	NEW LCV VERTICAL WIPER_TPE 25M BS6-PH2	TATA spare parts
429210901058	CORRUGATED TUBE 3/8INCH (10MM) DIA 30M	TATA spare parts
429210901059	CORRUGATED TUBE 3/8INCH (10MM) DIA 60 M	TATA spare parts
429210901060	ALUMINIUM PROFILE	TATA spare parts
429215003005	DRIVER DOOR EXT PANEL ASSY BS6	TATA spare parts
429215003006	DRIVER DOOR LOCK ASSY BS6	TATA spare parts
429215003015	DRIVER DOOR PANELLING ASSY 750 APP BS6	TATA spare parts
429215003016	DRIVER DOOR EXT PANEL WITH LOCK ASSY BS6	TATA spare parts
429215004013	DRIVER DOOR LOCK ASSY BS6	TATA spare parts

429215004024	DRIVER DOOR EXT PANEL ASSY	TATA spare parts
429215004032	LIFT DR STR & PANEL ASSY BS6	TATA spare parts
429215083006	DRIVER DOOR INTERNAL PANEL BS6	TATA spare parts
429215083010	DRIVER DOOR INTERNAL PANEL BS6	TATA spare parts
429215085032	LIFT DOOR INTERNAL PANEL BS6	TATA spare parts
429215263001	DRI DOOR BOTTOM FINISHING PROFILE BS6	TATA spare parts
429215263004	DRIVER DOOR BOTTLE HOLDER COVER	TATA spare parts
429215264001	DRIVER DOOR LOCK COVER BS6	TATA spare parts
429215264002	DRIVER DOOR BOTTLE HOLDER COVER BS6	TATA spare parts
429215264003	CO-DRI DOOR LOCK COVER-LH	TATA spare parts
429215304001	DRIVER DOOR LOCK COVER_INJ.MOULD_PP BS6	TATA spare parts
429215323001	BIG HANDLE_CD_250 BS6	TATA spare parts
429215323002	GRAB HANDLE CAP_RH	TATA spare parts
429215323003	GRAB HANDLE CAP_LH	TATA spare parts
429215324008	MAGAZINE POCKET GREY RH BS6	TATA spare parts
429216003001	EMG DOOR & LOCK ASSY_APP 705X1500MM BS6	TATA spare parts
429216003006	EMG DOOR & LOCK ASSY-APP 705X1500MM	TATA spare parts
429216003012	EMG DOOR & LOCK ASSY_APP 705X1500MM BS6	TATA spare parts
429216083001	EMERGENCY DOOR INTERNAL PANEL BS6	TATA spare parts
429216083003	LOCK FINISHING COVER BS6	TATA spare parts
429216083005	EMERGENCY DOOR INTERNAL PANEL-LHD	TATA spare parts
429216083010	EMERGENCY DOOR INTERNAL PANEL BS6	TATA spare parts
429216083012	EMERGENCY DOOR INTERNAL LOCK COVER BS6	TATA spare parts
429216263001	FRP LOCK CATCHER COVER BS6	TATA spare parts
429216264001	SEALING PLATE LOCK FRP COVER BS6	TATA spare parts
429216264002	SEALING PLATE LOCK FRP COVER BS6	TATA spare parts
429216264003	SEALING PLATE LOCK FRP COVER BS6	TATA spare parts
429216283001	FINISHING RUBBER PROFILE BS6	TATA spare parts
429217003001	G3 JK DOOR ASSY_830 X 1935 APP BS6	TATA spare parts
429217003004	TOP SLIDING BEARING ASSY BS6	TATA spare parts
429217003005	G3 JK DOOR ASSY BS6	TATA spare parts
429217003008	JK DOOR ASSY FOR G3 LP APP BS6	TATA spare parts
429217003009	TOP SLIDING BEARING ASSY BS6	TATA spare parts
429217003012	JK DOOR BRNG & BRNG HLDR ASSY FOR LPO BS	TATA spare parts
429217003036	AIS 153_12V_SHAVO PNEUMATIC LAYOUT BS6	TATA spare parts
429217003037	AIS 153_12V_PNEUMATIC DOOR HARNESS BS6	TATA spare parts
429217003038	G3 JK DOOR ASSY_830 X 1930 APP BS6	TATA spare parts
429217003039	AIS 153_24V_SHAVO PNEUMATIC LAYOUT BS6	TATA spare parts
429217003040	AIS 153_24V_PNEUMATIC DOOR HARNESS BS6	TATA spare parts
429217003042	JK DOOR MANUAL APP 1210 X 1970 BS6	TATA spare parts
429217003044	24V FRONT REAR PNU DOOR G3 LP HARNESS BS	TATA spare parts
429217003045	G3 JK DOOR ASSY_830 X 1935 APP BS6	TATA spare parts
429217003047	JK DOOR MANUAL APP 920 X 1930 BS6	TATA spare parts
429217003050	EXTERNAL GRAB HANDLE YELLOW BS6	TATA spare parts
429217003052	PNEUMATIC HARN4ESS FOR 1210 & 720 APP BS	TATA spare parts
429217003054	JK DOOR ASSY G3 LHD 830 X 1930 APP	TATA spare parts
429217003063	JK DOOR 720X1900 TOP TOWER BOLT BS6	TATA spare parts

429217004007	PASSENGER DOOR HANDLE YELLOW COLOR BS6	TATA spare parts
429217004008	CYLINDER COVER FOR ELECTRO PNEU BS6	TATA spare parts
429217004009	CYLINDER C/L 386 X O/L 512 X S/L 125 BS6	TATA spare parts
429217004010	5/2 SOV ASSEMBLY - 12VDC BS6	TATA spare parts
429217004011	3/2 SINGLE SOV WITH PILOT BS6	TATA spare parts
429217004012	SLOW START VALVE BS6	TATA spare parts
429217004013	PRESSURE SWITCH BS6	TATA spare parts
429217004020	8 X 6 REDUCER BS6	TATA spare parts
429217004021	6 X 6 STRAIGHT CONNECTOR BS6	TATA spare parts
429217004022	5/2 SOV ASSEMBLY - 24VDC BS6	TATA spare parts
429217004023	3/2 SINGLE SOV WITH PILOT 24V BS6	TATA spare parts
429217004026	FLOW CONTROL VALVE 3/8INCH 6MM PU PIPE	TATA spare parts
429217004032	SUPPLY-M/S SHAVO BS6	TATA spare parts
429217004033	SUPPLY-M/S SHAVO BS6	TATA spare parts
429217004038	TRIM PNEUMATIC DIKTING PARTS BS6	TATA spare parts
429217004042	DOUBLE DOOR RELAY PIGTAIL 24V BS6	TATA spare parts
429217005003	PRESSURE DIFFERENTIAL VALVE BS6	TATA spare parts
429217005004	FLOW CONTROL VALVE 1/4 INCH 6 MM TUBE BS	TATA spare parts
429217005005	12VDC COIL WITH LED BS6	TATA spare parts
429217005006	1/4INCH ELBOW 6 MM BS6	TATA spare parts
429217005007	1/8INCH ELBOW 6 MM TUBE BS6	TATA spare parts
429217005008	24VDC COIL WITH LED BS6	TATA spare parts
429217005009	COUPLING DIKTING PNEUMATIC PARTS BS6	TATA spare parts
429217005010	PANELING DIKTING PNEUMATIC PARTS BS6	TATA spare parts
429217005011	TRIM DIKTING PNEUMATIC PARTS BS6	TATA spare parts
429217005012	COUPLING DIKITING PNEUMATIC PARTS BS6	TATA spare parts
429217005013	PANELLING DIKITING PNEUMATIC PATRS BS6	TATA spare parts
429217005014	TRIM DIKITING PNEUMATIC PARTS BS6	TATA spare parts
429217005017	TRIM DIKITTING PARTS(12V) BS6	TATA spare parts
429217005018	TRIM DIKITING PNEUMATIC PARTS BSRTC BS6	TATA spare parts
429217005019	CYL C/L 387 X O/L 512 X S/L 125_LHD BS6	TATA spare parts
429217005021	PNEUMATIC PLATE FOR FRONT DOOR BS6	TATA spare parts
429217006001	PNEUMATIC PLATE FOR FRONT DOOR BS6	TATA spare parts
429217006002	PNEUMATIC PLATE FOR REAR DOOR BS6	TATA spare parts
429217006003	PNEUMATIC PLATE FOR FRONT DOOR BS6	TATA spare parts
429217083005	LIMIT SWITCH PLUNGER PUSHER BS6	TATA spare parts
429217083006	LIMIT SWITCH BRACKET PLATE BS6	TATA spare parts
429217084020	G3 LP JK DOOR BUZZER PUSHING PLATE BS6	TATA spare parts
429217084027	G3 LP LIMIT SWITCH BRACKET BS6	TATA spare parts
429217234001	PASS DOOR TAPER GLASS BS6	TATA spare parts
429217234002	PASSENGER DOOR GLASS BS6	TATA spare parts
429217234005	JK DOOR GLASS FOR G3 LP BS6	TATA spare parts
429217234009	PASSENGER DOOR GLASS BS6	TATA spare parts
429217234010	JK DOOR GLASS APP 920X1930 BS6	TATA spare parts
429217234011	JK DOOR TAPER GLASS _ LHD	TATA spare parts
429217284002	BOTTOM RUBBER FOR PASSENGER DR_282L BS6	TATA spare parts
429217284003	JK DOOR BOTTOM RUBBER APP 920X1930 BS6	TATA spare parts

429217965006	ROCKER SWITCH- GREEN BS6	TATA spare parts
429217965007	ROCKER SWITCH- RED BS6	TATA spare parts
429217965008	ROCKER SWITCH- OFF WHITE BS6	TATA spare parts
429217965009	ROCKER SWITCH- AMBER BS6	TATA spare parts
429217965010	ROCKER SWITCH YELLOW BS6	TATA spare parts
429218003006	FRONT FACE & FLAP ASSLY _G3_ 2.34 BS6	TATA spare parts
429218003009	FRONT FLAP STR BRACKET ASSY RHBS6	TATA spare parts
429218003010	FRONT FLAP STR BRACKET ASSY LHBS6	TATA spare parts
429218003012	FRONT FLAP HINGE ASSYBS6	TATA spare parts
429218003014	FRONT FLAP WITH FRAME ASSY _G3_ 2.34 BS6	TATA spare parts
429218003016	FRONT FACE & FLAP ASSY _G3 2.55 BS6	TATA spare parts
429218003019	FRONT FACE & FLAP ASSY _G3_ 2.2 BS6	TATA spare parts
429218003030	FRT FACE & FLAP ASSY-2.34 (COMB.. LAMPS)	TATA spare parts
429218003032	FRT FACE & FLAP ASSY-2.55(COMB.. LAMPS)	TATA spare parts
429218003036	FRT FACE & FLP ASY 2.34(RL & FG LMP BKT)	TATA spare parts
429218003038	FRT FACE & FLP ASY 2.55(RL & FG LMP BKT)	TATA spare parts
429218003051	FRT FACE AND FALP G3 CX 2.20 BS6	TATA spare parts
429218003057	F F & FLAP ASSY-2.34 (RL)_RDE BS6-PH2	TATA spare parts
429218003071	FRT FC&FLP 2.34(RL&FG LMP ) _DUBAI	TATA spare parts
429218004001	FRONT FLAP FRAME ASSYBS6	TATA spare parts
429218004002	FRONT FLAP WITH FRAME ASSY _2.55 BS6	TATA spare parts
429218004003	FRONT FLAP WITH FRAME ASSY G3 _W2.2 BS6	TATA spare parts
429218005002	FRONT FLAP FRAME ASSY G3 _W2.2 BS6	TATA spare parts
429218074001	STAY RODBS6	TATA spare parts
429218083007	FRT BUMPER SUPPORT BKT-01	TATA spare parts
429218083011	FRONT FLAP MESH _G3_ 2340 BS6	TATA spare parts
429218083012	FRONT FACE MESH_ 01_ G3_ 2340 BS6	TATA spare parts
429218083013	FRONT FACE MESH_ 02_ G3_ 2340 BS6	TATA spare parts
429218083014	FRONT FLAP MESH_ G3_ 2550 BS6	TATA spare parts
429218083015	FRONT FACE MESH_ 02_ G3_ 2550 BS6	TATA spare parts
429218083016	FRONT FACE MESH_ 01_ G3_ 2550 BS6	TATA spare parts
429218083017	FRONT FACE MESH-01-G3-2200	TATA spare parts
429218083018	FRONT FACE MESH-02-G3-2200	TATA spare parts
429218083019	FRONT FLAP MESH_ G3_ 2200 BS6	TATA spare parts
429218083026	G3 FRONT FACE MESH-02_ _CX BS6	TATA spare parts
429218083030	G3 FRONT FACE MESH_ CX_ 03 BS6	TATA spare parts
429218084005	JAMB ROD ADJUSTABLE PLATE BS6	TATA spare parts
429218084021	FRONT FLAP STR BRACKET_ LH BS6	TATA spare parts
429218084022	FRONT FLAP STR BRACKET_ RH BS6	TATA spare parts
429218213001	RAIN GUTTER FRONT LHBS6	TATA spare parts
429218213002	RAIN GUTTER FRONT RHBS6	TATA spare parts
429218213005	RAIN GUTTER FRONT LH BS6	TATA spare parts
429218213006	RAIN GUTTER FRONT RH BS6	TATA spare parts
429218213011	RAIN GUTTER FRONT RH_ 2.2 BS6	TATA spare parts
429218213012	RAIN GUTTER FRONT LH_ 2.2 BS6	TATA spare parts
429219003008	LOCK ROD ASSY BS6	TATA spare parts
429219003014	GAS PISTON FOR RLB FLAP BS6	TATA spare parts

429219004003	RLB FLAP STRUCTURE BS6	TATA spare parts
429219083019	RLB FLAP GAS PISTON HOLDING BKT LH BS6	TATA spare parts
429219083020	RLB FLAP GAS PISTON HOLDING BKT RH BS6	TATA spare parts
429219083021	RLB FLAP LOCK SPACER FOR RLB FLAP BS6	TATA spare parts
429219183001	RLB PLAP PANEL BS6	TATA spare parts
429219213001	RAIN GUTTER REAR LH BS6	TATA spare parts
429219213002	RAIN GUTTER REAR RH BS6	TATA spare parts
429219263003	G3_CNG VENT PIPE COVER RH BS6	TATA spare parts
429219263004	G3_CNG VENT PIPE COVER LH BS6	TATA spare parts
429219264004	REAR FACE_G3_2.34 BS6	TATA spare parts
429219264005	REAR FACE_G3_2.55 BS6	TATA spare parts
429219264006	REAR FACE_G3_2.20 BS6	TATA spare parts
429219264009	REAR FACE_G3_2.34 (COMBINATION LAMPS) BS	TATA spare parts
429219264010	REAR FACE_G3_2.55(COMBINATION LAMPS) BS6	TATA spare parts
429219264015	REAR FACE_RLB_2.34 (ROUND LAMPS) BS6	TATA spare parts
429219264025	REAR FACE G3-2.34(RL W/O RPAS & FG LMP B	TATA spare parts
429219264027	REAR FACE_G3_CX BS6	TATA spare parts
429219264031	REAR FC_G3_2.34 (ROUND LAMPS)_RDE BS6-PH	TATA spare parts
429219264038	R FC_2.34(RL W/O RPAS & FG LMP)_DUBAI	TATA spare parts
429220003001	AIR FILTER FLAP ASSY BS6	TATA spare parts
429220003005	AIR FILTER FLAP FINISHING PROFILE ASSY B	TATA spare parts
429220003006	HINGE ASSEMBLY LHBS6	TATA spare parts
429220003007	HINGE ASSEMBLY RHBS6	TATA spare parts
429220003008	HINGE BUSH ASSEMBLY BS6	TATA spare parts
429220003009	BATTERY FLAP PANEL ASSEMBLY BS6	TATA spare parts
429220003019	BATTERY FLAP PANEL ASSEMBLY BS6	TATA spare parts
429220003020	AIRFILTER FLAP ASSY DWG BS6	TATA spare parts
429220003021	G3 AIR FILTER FLAP FOR LP_APR 530X413 BS	TATA spare parts
429220003022	BATTERY FLAP PANEL ASSEMBLY APP 860X475	TATA spare parts
429220003023	STR WITH PANEL FOR APP 1400X460 BS6	TATA spare parts
429220003024	SLB FLAP LOCK & RUBBER ASSY BS6	TATA spare parts
429220003025	BATTERY FLAP PANEL ASSEMBLY BS6	TATA spare parts
429220003026	BATTERY FLAP PANEL ASSEMBLYBS6	TATA spare parts
429220003037	STR WITH PANEL FOR APP 743X479 BS6	TATA spare parts
429220003044	BATTERY FLAP_BUDGET LOCK ASSY 860X477 BS	TATA spare parts
429220003045	AIR FILTER FLAP WITH BUDGET LOCK LP BS6	TATA spare parts
429220003046	BATTERY FLAP PANEL ASSY APP 860X476_916	TATA spare parts
429220003048	FRP AIR FILTER FLAP SUB ASSY-LHD	TATA spare parts
429220003053	BATRY FLP ASSY 860X476 W\O SIDE MRKR BS6	TATA spare parts
429220003054	BATRY FLP ASSY 860X477_COMB INDI/MKR BS6	TATA spare parts
429220003066	BATTERY FLAP_BUDGET LOCK ASSY 860X477 BS	TATA spare parts
429220003069	STR WITH PANEL FOR APP 743X479 BS6-PH2	TATA spare parts
429220003072	BATTERY FLAP_BUDGET LOCK ASSY BS6-PH2	TATA spare parts
429220073001	ADJUSTABLE JAMB ROD_50MM BS6	TATA spare parts
429220074002	STAY ROD FOR BATTERY FLAP BS6	TATA spare parts
429220084026	G3 AIR FILTER FLAP APR 530X413 BS6	TATA spare parts
429220084039	BATTERY STALK ATTACHMENT PLATE_DIA 15MM	TATA spare parts

429220912008	AIR FILTER FLAP FITMENT LP APR_530X413 B	TATA spare parts
429222003007	STEP ASSEMBLY BS6	TATA spare parts
429222083002	DOOR MIRROR BS6	TATA spare parts
429222083003	DOOR MIRROR BS6	TATA spare parts
429227083018	ROOF EXTERNAL PANELLING SHEET	TATA spare parts
429227083090	ROOF EXTERNAL PANEL BS6-PH2	TATA spare parts
429227263001	ROOF CORNER_2340_PROTO BS6	TATA spare parts
429228003016	RH FRONT SKIRT PANEL ASSEMBLY BS6	TATA spare parts
429228003018	REAR SKIRT PANEL ASSY BS6	TATA spare parts
429228003019	REAR SKIRT PANEL ASSY BS6	TATA spare parts
429228003022	RH FRONT SKIRT PANEL ASSEMBLY	TATA spare parts
429228003025	RH FRONT SKIRT PANEL ASSEMBLY_NEO BS6-PH	TATA spare parts
429228003030	REAR SKIRT PANEL ASSY_NEO BS6-PH2	TATA spare parts
429228083020	EXT PANEL LH BS6	TATA spare parts
429228083116	EMG DOOR PANEL R.H SIDE_BOOGIEBS6	TATA spare parts
429228083127	EX PANEL RH SIDE_BOOGIE BS6	TATA spare parts
429228083129	EXT PANEL BOOGIEBS6	TATA spare parts
429228083138	SKIRT PANEL LH REAR BS6	TATA spare parts
429228083142	DRIVER FOOT STEP SUPPORTBS6	TATA spare parts
429228083143	DRIVER FOOT STEP SUPPORTBS6	TATA spare parts
429228083165	PASS DOOR TOP PANEL BS6	TATA spare parts
429228083175	STRETCH PANEL LH SIDE BS6	TATA spare parts
429228083176	STRETCH PANEL R.H SIDE BS6	TATA spare parts
429228083178	DRIVER DOOR TOP PANELBS6	TATA spare parts
429228083180	SIDE EXTERNAL PANELBS6	TATA spare parts
429228083181	SIDE EXTERNAL PANELBS6	TATA spare parts
429228083182	SIDE EXTERNAL PANELBS6	TATA spare parts
429228083183	SIDE EXTERNAL PANELBS6	TATA spare parts
429228083184	SIDE EXTERNAL PANELBS6	TATA spare parts
429228083185	SIDE EXTERNAL PANELBS6	TATA spare parts
429228083191	SKIRT PANEL LH BS6	TATA spare parts
429228083192	SKIRT PANEL LH BS6	TATA spare parts
429228083196	SKIRT PANEL BS6	TATA spare parts
429228083201	PANEL SHEET BS6	TATA spare parts
429228083210	STRETCH PANEL LH SIDE BS6	TATA spare parts
429228083211	STRETCH PANEL LH SIDEB6	TATA spare parts
429228083219	PASSENGER DOOR PILLAR PANEL BS6	TATA spare parts
429228083220	STRETCH PANEL RH SIDE BS6	TATA spare parts
429228083225	PASS DOOR TOP PANELBS6	TATA spare parts
429228083226	EXTERNAL PANEL ON A PILLERBS6	TATA spare parts
429228083227	EXTERNAL PANEL ON WINDOWS TUBE BS6	TATA spare parts
429228083229	EXTERNAL PANEL ON WINDOWS TUBEBS6	TATA spare parts
429228083231	STRETCH PANEL LH SIDEB6	TATA spare parts
429228083237	SKIRT PANELBS6	TATA spare parts
429228083243	PASSENGER DOOR PILLAR FINISHER BS6	TATA spare parts
429228083258	STRECH PANEL LH SIDE 54 WB BS6	TATA spare parts
429228083259	STRECH PANEL RH SIDE 54 WB BS6	TATA spare parts

429228083263	STRETCH PANEL FRONT RH BS6	TATA spare parts
429228083264	PANEL RH FRONT BS6	TATA spare parts
429228083265	WINDOW PANEL _LH BS6	TATA spare parts
429228083266	STRETCH PANEL RH BS6	TATA spare parts
429228083267	DOOR PANEL_RH BS6	TATA spare parts
429228083268	WINDOW PANEL RH FRONT BS6	TATA spare parts
429228083269	PANEL RH TOP BS6	TATA spare parts
429228083270	STRETCH PANEL RH BS6	TATA spare parts
429228083271	WINDOW PANEL _LH REAR BS6	TATA spare parts
429228083272	DOOR-WINDOW PANEL _FRONT BS6	TATA spare parts
429228083274	WINDOW PANEL_LH BS6	TATA spare parts
429228083275	SRETCH PANEL_LH BS6	TATA spare parts
429228083278	WINDOW PANEL _LH BS6	TATA spare parts
429228083283	STRETCH PANEL LH SIDE BS6	TATA spare parts
429228083284	STRETCH PANEL RH BS6	TATA spare parts
429228083286	SIDE EXTERNAL PANELBS6	TATA spare parts
429228083309	EXTERNAL PANELBS6	TATA spare parts
429228083313	FINISHING PROFILEBS6	TATA spare parts
429228083319	STRECH PANEL REAR BS6	TATA spare parts
429228083330	LH SKIRT PANELBS6	TATA spare parts
429228083344	PASS DOOR TOP PANEL_SKL BS6	TATA spare parts
429228083350	LH FRONT WHEEL SKIRT PANEL BS6	TATA spare parts
429228083357	SKIRT PANEL LH REAR BS6	TATA spare parts
429228083358	SKIRT PANEL RH BS6	TATA spare parts
429228083359	SKIRT PANEL_LH BS6	TATA spare parts
429228083360	SKIRT PANEL LH REAR BS6	TATA spare parts
429228083361	SKIRT PANEL LH_SPARE WHEEL BS6	TATA spare parts
429228083362	SKIRT PANEL_LH BS6	TATA spare parts
429228083363	SIDE EXTERNAL PANEL BS6	TATA spare parts
429228083365	LH STRETCH PANEL-FRONT BS6	TATA spare parts
429228083392	PANEL FRONT TOP BS6	TATA spare parts
429228083396	LH SIDE SKIRT PANEL_36WB_CNG BS6	TATA spare parts
429228083397	SKIRT PANEL RH BS6	TATA spare parts
429228083398	SKIRT PANEL LH BS6	TATA spare parts
429228083399	SKIRT PANEL RH BS6	TATA spare parts
429228083401	REAR SKIRT PANEL LH_36WB BS6	TATA spare parts
429228083402	REAR SKIRT PANEL RH 36WB CNG BS6	TATA spare parts
429228083403	LH FRONT WHEEL SKIRT PANELBS6	TATA spare parts
429228083404	SKIRT PANEL LHBS6	TATA spare parts
429228083405	SKIRT PANEL RHBS6	TATA spare parts
429228083406	SKIRT PANEL LHBS6	TATA spare parts
429228083407	REAR SKIRT PANEL LH_52WBBS6	TATA spare parts
429228083408	SKIRT PANEL RHBS6	TATA spare parts
429228083409	SKIRT PANEL RHBS6	TATA spare parts
429228083410	REAR SKIRT PANEL LH_52WBBS6	TATA spare parts
429228083411	SKIRT PANEL RH WHEEL ARCHBS6	TATA spare parts
429228083412	SKIRT PANEL LH WHEEL ARCHBS6	TATA spare parts



429228083414	REAR SKIRT PANEL RH BS6	TATA spare parts
429228083415	REAR SKIRT PANELBS6	TATA spare parts
429228083416	LH SIDE SKIRT PANELBS6	TATA spare parts
429228083417	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083418	REAR SKIRT PANEL LH BS6	TATA spare parts
429228083420	AIR FILTER SIDE PANELBS6	TATA spare parts
429228083421	EXTERNAL PANELBS6	TATA spare parts
429228083422	FRONT SKIRT PANELBS6	TATA spare parts
429228083426	PASSENGER TOP PANELBS6	TATA spare parts
429228083433	RH SIDE SKIRT PANEL BS6	TATA spare parts
429228083434	RH SKIRT PANEL BS6	TATA spare parts
429228083435	REAR SKIRT PANEL RH BS6	TATA spare parts
429228083436	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083437	REAR SKIRT PANEL LH BS6	TATA spare parts
429228083439	SKIRT PANEL RH SIDEB6	TATA spare parts
429228083441	RH SIDE SKIRT PANEL BS6	TATA spare parts
429228083442	RH SKIRT PANEL BS6	TATA spare parts
429228083443	REAR SKIRT PANEL RH BS6	TATA spare parts
429228083444	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083446	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083453	SKIRT PANEL RH REAR_29_1650ROH BS6	TATA spare parts
429228083454	SKIRT PANEL LH REAR_29_1650ROH BS6	TATA spare parts
429228083455	SRETCH PANEL_29WB_1650ROH BS6	TATA spare parts
429228083456	DOOR-WINDOW PANEL_FRONT BS6	TATA spare parts
429228083457	DOOR-WINDOW PANEL_BACK BS6	TATA spare parts
429228083458	SKIRT PANEL LH FRONT BS6	TATA spare parts
429228083459	SKIRT PANELLING RH FRONT BS6	TATA spare parts
429228083460	L SIDE BRAKET_341MM BS6	TATA spare parts
429228083461	L SIDE BRAKET_297MM BS6	TATA spare parts
429228083462	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083463	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083464	REAR SKIRT PANEL LH BS6	TATA spare parts
429228083465	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083466	RH SIDE SKIRT PANEL BS6	TATA spare parts
429228083467	RH SKIRT PANEL BS6	TATA spare parts
429228083468	REAR SKIRT PANEL RH BS6	TATA spare parts
429228083469	EXTERNAL PANEL ON WINDOWS TUBE BS6	TATA spare parts
429228083470	SKIRT PANEL RH SIDE BS6	TATA spare parts
429228083472	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083473	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083474	RH SIDE SKIRT PANEL BS6	TATA spare parts
429228083476	REAR SKIRT PANEL LH BS6	TATA spare parts
429228083477	REAR SKIRT PANEL RH BS6	TATA spare parts
429228083478	RH SKIRT PANEL BS6	TATA spare parts
429228083479	RH SIDE SKIRT PANEL BS6	TATA spare parts
429228083480	RH SIDE SKIRT PANEL BS6	TATA spare parts
429228083481	REAR SKIRT PANEL LH BS6	TATA spare parts

429228083483	RH SIDE SKIRT PANEL BS6	TATA spare parts
429228083484	RH SIDE SKIRT PANEL BS6	TATA spare parts
429228083485	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083486	REAR SKIRT PANEL LH BS6	TATA spare parts
429228083487	RH SIDE STRETCH PANEL_LP_45WB_3.3L BS6	TATA spare parts
429228083488	REAR SKIRT PANEL RH BS6	TATA spare parts
429228083489	RH REAR SIDE EXTERNAL PANELBS6	TATA spare parts
429228083490	EMERGENCY DOOR TOP EXTERNAL PANELBS6	TATA spare parts
429228083491	RH SIDE STRETCH PANEL BS6	TATA spare parts
429228083492	SKIRT_PANEL_2.2_33WB_SPAREWHEEL BS6	TATA spare parts
429228083493	SKIRT PANEL DIESEL_2.2_33 BS6	TATA spare parts
429228083494	STRETCH PANEL_33WB_2.2 BS6	TATA spare parts
429228083495	REAR SKIRT PANEL LH BS6	TATA spare parts
429228083498	PANEL ABOVE PASSENGER DOOR BS6	TATA spare parts
429228083499	STRECH PANEL RH SIDE BS6	TATA spare parts
429228083500	STRECH PANEL RH SIDE BS6	TATA spare parts
429228083504	RH SKIRT PANEL BS6	TATA spare parts
429228083505	STRETCH PANEL RH SIDE BS6	TATA spare parts
429228083506	PASS DOOR TOP PANEL BS6	TATA spare parts
429228083507	LH A PILLAR PANEL BS6	TATA spare parts
429228083508	DRIVER DOOR TOP PANEL BS6	TATA spare parts
429228083509	EMERGENCY DOOR PILLAR EXT PANEL BS6	TATA spare parts
429228083510	SIDE EXT PANEL BS6	TATA spare parts
429228083511	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083512	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083517	RH SKIRT PANEL BS6	TATA spare parts
429228083518	SKIRT PANEL RH SIDE BS6	TATA spare parts
429228083523	PASSENGER DOOR PILLAR PANEL BS6	TATA spare parts
429228083525	LH A PILLAR PANEL BS6	TATA spare parts
429228083528	EXTERNAL PANEL-RH BS6	TATA spare parts
429228083529	RH SIDE SKIRT PANEL BS6	TATA spare parts
429228083539	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083540	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083541	EXTERNAL PANEL_REAR WINDOW 44WB BS6	TATA spare parts
429228083543	REAR SKIRT PANEL LH_52WB BS6	TATA spare parts
429228083544	REAR SKIRT PANEL LH_52WB BS6	TATA spare parts
429228083545	REAR SKIRT PANEL RH BS6	TATA spare parts
429228083546	REAR SKIRT PANEL LH BS6	TATA spare parts
429228083548	DRIVER DOOR PILLAR PANEL BS6	TATA spare parts
429228083549	DRIVER DOOR TOP PANEL BS6	TATA spare parts
429228083586	REAR SKIRT PANEL LH BS6	TATA spare parts
429228083590	STRETCH PANEL LH SIDE 54WB BS6	TATA spare parts
429228083591	STRETCH PANEL LH SIDE 54WB BS6	TATA spare parts
429228083592	PASSENGER TOP PANEL BS6	TATA spare parts
429228083593	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083594	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083595	EXTERNAL PANEL BS6	TATA spare parts

429228083602	REAR SKIRT PANEL LH BS6	TATA spare parts
429228083624	PASSENGER DOOR PILLAR PANEL BS6	TATA spare parts
429228083626	SKIRT PANEL RH BS6	TATA spare parts
429228083631	FRONT SKIRT PANEL BS6	TATA spare parts
429228083640	SKIRT PANEL LH SIDE BS6-PH2	TATA spare parts
429228083645	STRETCH PANEL LH SIDE BS6	TATA spare parts
429228083647	LH REAR SKIRT PANEL BS6	TATA spare parts
429228083648	SKIRT CLOSING PANEL BS6	TATA spare parts
429228083649	SKIRT CLOSING PANEL BS6	TATA spare parts
429228083650	REAR SKIRT PANEL RH BS6	TATA spare parts
429228083651	WINDOW EXTERNAL PANEL BS6	TATA spare parts
429228083654	PASS DOOR TOP PANEL BS6-PH2	TATA spare parts
429228083655	LH A PILLAR PANEL BS6-PH2	TATA spare parts
429228083658	FRONT WHL REAR LH SIDE SKIRT-42WB	TATA spare parts
429228083659	LH SIDE SKIRT PANEL	TATA spare parts
429228083660	LH SIDE SKIRT PANEL	TATA spare parts
429228083661	REAR SKIRT PANEL LH	TATA spare parts
429228083666	SKIRT PANEL RH NEAR PASS. DOOR	TATA spare parts
429228083667	SKIRT PANEL RH SIDE-FRONT WHL REAR	TATA spare parts
429228083668	RH SKIRT PANEL RH REAR WHL FRONT	TATA spare parts
429228083670	REAR SKIRT PANEL RH-42WB-916	TATA spare parts
429228083671	RH A PILLAR PANEL-42WB-916 LHD	TATA spare parts
429228083672	SIDE EXTERNAL PANEL-LH DRIVER DOOR FRONT	TATA spare parts
429228083673	STRETCH PANEL LH-42WB-916-LHD	TATA spare parts
429228083674	STRETCH PANEL RH-42WB-916-LHD	TATA spare parts
429228083675	RH FRONT EXTERNAL PANEL BS6-PH2	TATA spare parts
429228083683	PASS DOOR BOTOM PANEL LH LPO	TATA spare parts
429228083698	SKIRT PANEL LH_REAR WHEEL ARCH BS6	TATA spare parts
429228083699	LH REAR SKIRT PANEL BS6	TATA spare parts
429228083701	STRETCH PANEL LH SIDE BS6	TATA spare parts
429228083702	LH SKIRT PANEL BS6	TATA spare parts
429228083703	PASSENGER TOP PANEL BS6	TATA spare parts
429228083704	PASSENGER TOP PANEL BS6	TATA spare parts
429228083706	SKIRT PANEL LH_REAR WHEEL ARCH BS6	TATA spare parts
429228083707	STRETCH PANEL LENGTH_7170 BS6	TATA spare parts
429228083708	LH SIDE SKIRT PANEL_1576 BS6	TATA spare parts
429228083709	PASSENGER TOP PANEL_1260L BS6	TATA spare parts
429228083710	PASSENGER DOOR SIDE PANEL BS6	TATA spare parts
429228083722	REAR SKIRT PANEL RH BS6	TATA spare parts
429228083723	REAR SKIRT PANEL LH BS6	TATA spare parts
429228083724	STRECH PANEL REAR_HOP BS6	TATA spare parts
429228083725	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083726	STRETCH PANEL RH SIDE_HOP BS6	TATA spare parts
429228083727	SKIRT PANEL LH BS6	TATA spare parts
429228083728	SKIRT PANEL LH SPARE WHEEL BS6	TATA spare parts
429228083735	RH SKIRT PANEL_NEO BS6-PH2	TATA spare parts
429228083736	REAR SKIRT PANEL RH_NEO BS6-PH2	TATA spare parts

429228083737	LH SIDE SKIRT PANEL_ NEO BS6-PH2	TATA spare parts
429228083738	REAR SKIRT PANEL LH_ NEO BS6-PH2	TATA spare parts
429228083742	SKIRT PANEL RH SIDE_ NEO BS6-PH2	TATA spare parts
429228083781	CO DRIVER SIDE PANEL BS6	TATA spare parts
429228083782	CO DRIVER TOP PANEL BS6	TATA spare parts
429228083783	FRONT SKIRT PANEL BS6	TATA spare parts
429228083784	DRIVER SIDE PANEL BS6	TATA spare parts
429228083785	DRIVER DOOR TOP PANEL BS6	TATA spare parts
429228083786	AIR FILTER SIDE PANEL BS6	TATA spare parts
429228083787	EXTERNAL PANEL BS6	TATA spare parts
429228083788	RH SIDE STRETCH PANEL BS6	TATA spare parts
429228083789	REAR SKIRT PANEL RH BS6	TATA spare parts
429228083814	PASSENGER DOOR TOP PANEL	TATA spare parts
429228083816	PARTITION OUTER PANEL BS6	TATA spare parts
429228083817	DRIVER DOOR TOP PANEL BS6	TATA spare parts
429228083818	DRIVER DOOR SIDE PANEL BS6	TATA spare parts
429228083819	LH FRONT TOP PANEL_LP REGULAR_COMBINE BS	TATA spare parts
429228083863	STRECH PANEL_808X4405X0.65 BS6	TATA spare parts
429228083864	EXTERNAL PANEL DOOR MIDDLE_1566X125X0.65	TATA spare parts
429228083865	LH FRONT TOP PANEL_LP WC&LM_COMBINE BS6	TATA spare parts
429228083866	EXTERNAL PANEL ON WINDOWS TUBE BS6	TATA spare parts
429228083867	EXTERNAL PANEL ON DOOR TUBE BS6	TATA spare parts
429228083875	LH SIDE SKIRT PANEL BS6	TATA spare parts
429228083877	RH SIDE SKIRT PANEL_ NEO BS6-PH2	TATA spare parts
429228083895	LH FRONT TOP PANEL LP 909 CNG COMBINE BS	TATA spare parts
429228083905	RH SIDE SKIRT PANEL FUEL NECK CUTOUT BS6	TATA spare parts
429228083906	REAR SKIRT PANEL RH BS6-PH2	TATA spare parts
429228083907	RH SKIRT PANEL BS6-PH2	TATA spare parts
429228083908	REAR SKIRT PANEL LH BS6-PH2	TATA spare parts
429228083909	FRONT SKIRT PANEL BS6-PH2	TATA spare parts
429228083910	LH SIDE SKIRT PANEL BS6-PH2	TATA spare parts
429228083920	LH A PILLAR PANEL_233X2075X0.65 BS6-PH2	TATA spare parts
429228083925	REAR SKIRT PANEL RH_ NEO_RDE BS6-PH2	TATA spare parts
429228083928	FRONT SKIRT PANEL_ NEO_RDE BS6-PH2	TATA spare parts
429228083930	LH SIDE SKIRT PANEL_ NEO_RDE BS6-PH2	TATA spare parts
429228083931	LH SIDE SKIRT PANEL_ NEO BS6-PH2	TATA spare parts
429228083932	RH SIDE SKIRT PANEL_ NEO BS6-PH2	TATA spare parts
429228083933	REAR SKIRT PANEL LH_ NEO BS6-PH2	TATA spare parts
429228083934	REAR SKIRT PANEL RH_ NEO BS6-PH2	TATA spare parts
429228083935	RH SKIRT PANEL_ NEO BS6-PH2	TATA spare parts
429228083936	FRONT SKIRT PANEL_ NEO BS6-PH2	TATA spare parts
429228083949	RH SKIRT PANEL_ NEO_RDE BS6-PH2	TATA spare parts
429228083950	RH SIDE SKIRT PANEL_ NEO_RDE BS6-PH2	TATA spare parts
429228083952	PASS DOOR TOP PANEL BS6-PH2	TATA spare parts
429228083965	REAR SKIRT PANEL LH_LP710_ NEO_RDE BS6-PH	TATA spare parts
429228083970	LH FRT TOP PANEL_LP REGULAR_COMBINE_PNU	TATA spare parts
429228083972	STRETCH PANEL LH SIDE BS6	TATA spare parts

429228083973	REAR STRETCH PANEL LH BS6	TATA spare parts
429228083974	SKIRT PANEL LH_REAR WHEEL ARCH BS6	TATA spare parts
429228083975	LH REAR SKIRT PANEL BS6	TATA spare parts
429228083976	REAR SKIRT PANEL RH BS6	TATA spare parts
429228083977	REAR PASSENGER TOP PANEL_45NAC_PNU BS6	TATA spare parts
429228083978	REAR WINDOW EXTERNAL PANEL_45NAC BS6	TATA spare parts
429228083979	LH SIDE SKIRT PANEL_NEO BS6-PH2	TATA spare parts
429228083982	PASSENGER DOOR SIDE PANEL BS6-PH2	TATA spare parts
429228083989	SKIRT PANEL LH_REAR WHEEL ARCH BS6-PH2	TATA spare parts
429228083990	SKIRT PANEL LH_REAR WHEEL ARCH BS6-PH2	TATA spare parts
429228083991	LH REAR SKIRT PANEL BS6-PH2	TATA spare parts
429228083992	LH REAR SKIRT PANEL BS6-PH2	TATA spare parts
429228083993	RH DRIVER DOOR TOP EXTERNAL PANEL BS6-PH	TATA spare parts
429228083994	EMERGENCY DOOR TOP EXTERNAL PANEL BS6-PH	TATA spare parts
429228083995	EXTERNAL PANEL ON WINDOWS TUBE BS6-PH2	TATA spare parts
429228083996	LH SIDE SKIRT PANEL	TATA spare parts
429228083998	PASSENGER DOOR TOP PANEL	TATA spare parts
429228083999	SKIRT PANEL RH NEAR PASS. DOOR	TATA spare parts
429228084002	CLOSING PANEL BS6	TATA spare parts
429228084010	RH SIDE STRETCH PANEL BS6	TATA spare parts
429228084011	GLASS RELEASE BS6	TATA spare parts
429228084018	PASS DOOR BOTOM PANEL RH LPO	TATA spare parts
429228084019	RH A PILLAR PANEL-42WB-916 LHD	TATA spare parts
429228084020	SKIRT PANEL_FUEL TANK RH BS6-PH2	TATA spare parts
429228084021	SKIRT PANEL RH SIDE BS6-PH2	TATA spare parts
429228084024	PASS DOOR TOP PANEL_TMBSL BS6-PH2	TATA spare parts
429228183024	EXTERNAL PANEL_REAR PASS. DOOR BOTTOM BS	TATA spare parts
429228264001	DRI DOOR BOTTOM FINISHING PROFILE	TATA spare parts
429228264002	H3 LHD LPO DRI DOOR BOTTOM FINISHER	TATA spare parts
429229003013	INP COVER ASSY G3_APP_153X410 BS6	TATA spare parts
429229003023	INP COVER ASSY G3_APP_308X368	TATA spare parts
429229003056	INP COVER ASSY G3_IB APP_375X416	TATA spare parts
429229003060	INSPECTION COVER FOR G3_AMTS BS6	TATA spare parts
429229003062	INSPECTION COVER FOR G3_916	TATA spare parts
429229003069	INP COVER ASSY G3 IB APP 375X416 BS6	TATA spare parts
429229004006	INSPECTION COVER STRUCTURE BS6	TATA spare parts
429229004010	INP COVER BOTTOM PLATE ASSY BS6	TATA spare parts
429229004011	INSPECTION COVER STRUCTURE ASSY BS6	TATA spare parts
429229084018	INSPECTION COVER BOTTOM PLATE BS6	TATA spare parts
429229084025	INSPECTION COVER BOTTOM PLATE_G3_IB BS6	TATA spare parts
429229244095	PLY WOOD FOR G3_IB INP COVER BS6	TATA spare parts
429229245010	INSPECTION COVER PLYWOOD BS6	TATA spare parts
429229912151	INSPECTION COVER FOR APP 375X416 G3_IB B	TATA spare parts
429229912171	INSPECTN CVR FOR G3_AMTS FITMENT INFO BS6	TATA spare parts
429229912290	INSPECTION COVER FOR APP 375X416 G3 IB B	TATA spare parts
429235374003	DRIVER/DOOR LAMP PARABOLA TYPE_INVEL BS6	TATA spare parts
429235374004	BLDC FAN PLASTIC HSG 12V_INVEL BS6	TATA spare parts

429240003019	2RH 1SM1L 480C850W NHB T2 RX CVG	TATA spare parts
429240003020	2RH 1SM1L 480C 850W RX BWH NHB T2 CVG	TATA spare parts
429240003022	2RR 2LM 480C810W RX LB NHB T2 CVG	TATA spare parts
429240003023	1RM 2LM 480C410W LB RX NHB T2 CVG	TATA spare parts
429240003024	2RL 2LM 480C810W RX NHB T2 CVG	TATA spare parts
429240003025	2RH 1SM1L 480C850W AR RX NHB T2 CVG	TATA spare parts
429240003045	2LH 1SM1L 480C850W AR RX NHB T2 CVG	TATA spare parts
429240003046	2LH 1SM1L 480C 850W RX BWH NHB T2 CVG	TATA spare parts
429240003047	RH 2ST SM1L 480CH875W LB NHB1 CVG BS6	TATA spare parts
429240003048	RH 2ST SM1L 480CH875W NHB1 CVG BS6	TATA spare parts
429240003050	RR 2ST 2LM 480CH810W LB NHB1 CVG BS6	TATA spare parts
429240003051	REAR MID 1ST 2LM 480CH410W LB NHB1 CVG B	TATA spare parts
429240003052	RL 2ST 2LM 480CH810W LB NHB1 CVG BS6	TATA spare parts
429240003053	LH 2ST SM1L 480CH875W NHB1 CVG BS6	TATA spare parts
429240003055	LH 2ST SM1L 480CH875W 1LB NHB1 CVG BS6	TATA spare parts
429240003056	LH 1ST 2LM 360CH410W LB NHB1 CVG BS6	TATA spare parts
429240003057	3RH SM2LM 450C1050W 3LB SKL TM BS6	TATA spare parts
429240003058	3RH SM2LM 450C1050W SKL TM BS6	TATA spare parts
429240003059	3RH SM2LM 450C1050W WA SKL TM BS6	TATA spare parts
429240003060	4RR 3LM 450C1060W 1LB SKL TM BS6	TATA spare parts
429240003061	3RL 2LM 450C950W 1LB SKL TM BS6	TATA spare parts
429240003062	2LH SM1LM 450C760W SKL TM BS6	TATA spare parts
429240003063	2LH SM1LM 450C760W WA SKL TM BS6	TATA spare parts
429240003086	1COD 2LM 450CH400W AR LB NHB1 CVG BS6	TATA spare parts
429240003097	3RH SM1LM 450C950W 3LB AR SKL TM BS6	TATA spare parts
429240003098	3RH SM1LM 450C950W SKL TM BS6	TATA spare parts
429240003099	3RH SM1LM 450C950W WA SKL TM BS6	TATA spare parts
429240003100	4RR SM2LM 450C1060W 1LB SKL TM BS6	TATA spare parts
429240003101	3RL SM1LM 450C950W 1LB SKL TM BS6	TATA spare parts
429240003102	CO-DRIV SEAT LH_400W_2LM_AR_IB_TM BS6	TATA spare parts
429240003111	3LH SM1LM 450C950W SKL TM BS6	TATA spare parts
429240003112	3LH SM1LM 450C950W WA SKL TM BS6	TATA spare parts
429240003114	1LH 2LM 360C410W WA HBT1 TM BS6	TATA spare parts
429240003123	3RH SM1LM 450C950W AR SKL TM BS6-PH2	TATA spare parts
429240003124	2RH SM1L 480C900W AR LB USB HBR CVG BS6	TATA spare parts
429240003125	2RH SM1L 480C900W AR USB HBR CVG BS6	TATA spare parts
429240003126	2RH SM1L 480C900W WA AR USB HBR CVG BS6	TATA spare parts
429240003127	2RR 2LM 480C870W AR LB USB HBR CVG BS6	TATA spare parts
429240003128	1MID 2LM 480C410W LB USB HBR CVG BS6	TATA spare parts
429240003129	2RL SM1L 480C870W AR USB HBR CVG BS6	TATA spare parts
429240003130	2LH SM1L 480C900W AR USB HBR CVG BS6	TATA spare parts
429240003131	2LH SM1L 480C900W WA AR USB HBR CVG BS6	TATA spare parts
429240003132	2LH SM1L 480C900W AR LB USB HBR CVG BS6	TATA spare parts
429240003133	1LH 2LM 360C410W AR LB USB HBR CVG BS6	TATA spare parts
429240003148	2RH SM1L 480CH910W LB ERGONT1 CVG BS6	TATA spare parts
429240003154	LH 1ST 2LM 480CH410W AR ERGONT1 CVG BS6	TATA spare parts
429240003170	4RL 3LM 450C 1060W LB SKL TM BS6	TATA spare parts

429240003176	5REAR 3LM 135CH2000W LB NDXT2 CVG BS6	TATA spare parts
429240003177	3RH 3LM 460C1050W AR LB SKL TM BS6	TATA spare parts
429240003178	2LH SM1LM 460C760W LB SKL TM BS6	TATA spare parts
429240003180	RH 2ST SM1L 480CH910W SDXT2 CVG BS6	TATA spare parts
429240003181	RR 2ST 2LM 480CH820W LB SDXT2 CVG BS6	TATA spare parts
429240003182	1MID 2LM 480CH410W LB SDXT2 CVG BS6	TATA spare parts
429240003183	RL 2ST 2LM 480CH410W SDXT2 CVG BS6	TATA spare parts
429240003184	LH 2ST SM1LM 480CH910W SDXT2 CVG BS6	TATA spare parts
429240003186	LH 1ST 2LM 360CH410W AR 1LB SDXT2 CVG BS	TATA spare parts
429240003190	REAR MID 1ST 2LM 480CH410W LB SDX1 CVG B	TATA spare parts
429240003197	RH 2ST SM1L 480CH910W LB SDXT2 CVG BS6	TATA spare parts
429240003198	1LH CD 2LM 480C410W AR SDXT2 CVG BS6	TATA spare parts
429240003200	RH 3ST SM2L 480CH1230W SDX T2 CVG BS6	TATA spare parts
429240003202	RR 3ST 3LM 480CH1170W 3LB SDX T2 CVG BS6	TATA spare parts
429240003204	RL 3ST 3LM 480CH1170W 1LB SDX T2 CVG BS6	TATA spare parts
429240003205	LH 2ST SM1LM 480C850W SDX T2 CVG BS6	TATA spare parts
429240003207	2RH SM1LM 350C850W LB AR SDX T1 CVG BS6	TATA spare parts
429240003208	2RH SM1LM 380C810W SDX T1 CVG BS6	TATA spare parts
429240003209	2RR SM1LM 460C810W SDX T1 CVG BS6	TATA spare parts
429240003210	REAR LH SM1LM 460C810W SDX T1 CVG BS6	TATA spare parts
429240003211	2LH SM1LM 460C850W SDX T1 CVG BS6	TATA spare parts
429240003212	1CD 2LM 460C410W AR SDX T1 CVG BS6	TATA spare parts
429240003214	2RH 2LM 460CH910W LB AR SDXT2 CVG BS6	TATA spare parts
429240003215	3RH SM2LM 450C1050W AR SKL TMBS6	TATA spare parts
429240003216	3RH SM2LM 450C1050W WA AR SKL TMBS6	TATA spare parts
429240003217	2LH SM1LM 450C760W AR SKL TMBS6	TATA spare parts
429240003218	2LH SM1LM 450C760W WA AR SKL TMBS6	TATA spare parts
429240003255	3RH 3LM 460C1050W AR LB SKL CVG BS6	TATA spare parts
429240003256	3RH SM2LM 450C1050W SKL CVG BS6	TATA spare parts
429240003257	3RH SM2LM 450C1050W WA SKL CVG BS6	TATA spare parts
429240003258	4RR 3LM 450C1060W 1LB SKL CVG BS6	TATA spare parts
429240003259	4RL 3LM 450C 1060W LB SKL CVG BS6	TATA spare parts
429240003260	2LH SM1LM 450C760W SKL CVG BS6	TATA spare parts
429240003261	2LH SM1LM 450C760W WA SKL CVG BS6	TATA spare parts
429240003262	2LH SM1LM 460C760W LB SKL CVG BS6-PH2	TATA spare parts
429240003264	3RH SM1LM 450C950W 3LB AR SKL CVG BS6	TATA spare parts
429240003265	3RH SM1LM 450C950W SKL CVG BS6	TATA spare parts
429240003266	3RH SM1LM 450C950W WA SKL CVG BS6	TATA spare parts
429240003267	4RR SM2LM 450C1060W 1LB SKL CVG BS6	TATA spare parts
429240003268	3RL SM1LM 450C950W 1LB SKL CVG BS6	TATA spare parts
429240003269	CO-DRIV SEAT LH_400W_2LM_AR_LB_CVG BS6	TATA spare parts
429240003270	1COD 2LM 450CH400W AR LB NHB1 TM BS6	TATA spare parts
429240003271	3RH SM2LM 450C1050W 3LB SKL CVG BS6	TATA spare parts
429240003276	3RL 2LM 450C950W 1LB SKL CVG BS6-PH2	TATA spare parts
429240003277	3RH 3LM 460C1050W AR LB SKL HSSL BS6	TATA spare parts
429240003278	3RH SM2LM 450C1050W SKL HSSL BS6	TATA spare parts
429240003279	3RH SM2LM 450C1050W WA SKL HSSL BS6	TATA spare parts

429240003280	4RR 3LM 450C1060W 1LB SKL HSSL BS6	TATA spare parts
429240003281	4RL 3LM 450C 1060W LB SKL HSSL BS6	TATA spare parts
429240003282	2LH SM1LM 450C760W SKL HSSL BS6	TATA spare parts
429240003283	2LH SM1LM 450C760W WA SKL HSSL BS6	TATA spare parts
429240003284	2LH SM1LM 460C760W LB SKL HSSL BS6-PH2	TATA spare parts
429240003285	1LH 2LM 360C410W WA HBT1 HSSL BS6-PH2	TATA spare parts
429240003286	3RH SM1LM 450C950W 3LB AR SKL HSSL BS6	TATA spare parts
429240003287	3RH SM1LM 450C950W SKL HSSL BS6	TATA spare parts
429240003288	3RH SM1LM 450C950W WA SKL HSSL BS6	TATA spare parts
429240003289	4RR SM2LM 450C1060W 1LB SKL HSSL BS6	TATA spare parts
429240003290	3RL SM1LM 450C950W 1LB SKL HSSL BS6	TATA spare parts
429240003291	CO-DRIV SEAT LH_400W_2LM_AR_LB_HSSL BS6	TATA spare parts
429240003292	1COD 2LM 450CH400W AR LB NHB1 HSSL BS6	TATA spare parts
429240003293	3RH SM2LM 450C1050W 3LB SKL HSSL BS6	TATA spare parts
429240003294	BASE CUHION SUB ASSLY KIT PINK	TATA spare parts
429240003404	1MID 2LM 480CH410W LB SDXT2 TM BS6	TATA spare parts
429240003405	RL 2ST 2LM 480CH810W SDXT2 TM BS6	TATA spare parts
429240003406	LH 2ST SM1LM 480CH910W SDXT2 TM BS6	TATA spare parts
429240003408	RH 2ST SM1L 480CH910W SDXT2 TM BS6	TATA spare parts
429240003409	RR 2ST 2LM 480CH820W LB SDXT2 TM BS6	TATA spare parts
429240003410	1LH CD 2LM 480C410W AR SDXT2 TM BS6	TATA spare parts
429240003413	LH 1ST 2LM 360CH410W AR 1LB SDXT2 TM	TATA spare parts
429240003514	2RH 2LM 460CH910W AR SDXT2 TM BS6	TATA spare parts
429240003518	3LH SM1LM 450C950W SKL CVG BS6	TATA spare parts
429240003519	3LH SM1LM 450C950W WA SKL CVG BS6	TATA spare parts
429240003520	3LH SM1LM 450C950W SKL HSSL BS6	TATA spare parts
429240003521	3LH SM1LM 450C950W WA SKL HSSL BS6	TATA spare parts
429240003522	3RH SM1LM 450C950W AR LB SKL TM BS6	TATA spare parts
429240003523	3RH SM1LM 450C950W AR LB SKL CVG BS6-PH2	TATA spare parts
429240003524	3RH SM1LM 450C950W AR LB SKL HSSL BS6-PH	TATA spare parts
429240003525	4RL 3LM 450C 1060W 1LB SKL TM BS6	TATA spare parts
429240003526	4RL 3LM 450C 1060W 1LB SKL CVG BS6	TATA spare parts
429240003527	4RL 3LM 450C 1060W 1LB SKL HSSL BS6	TATA spare parts
429240003592	LH 2ST SM1LM 480C850W 1LB SDX T2 CVG BS6	TATA spare parts
429240003593	RH 3ST 3LM 480CH1200W AR SDX T2 CVG BS6	TATA spare parts
429240003594	RH 3ST SM2LM 480CH1230W 3LB SDX T2 CVG B	TATA spare parts
429240003595	RH 3ST SM2LM 480CH1200W AR SDX T2 CVG BS	TATA spare parts
429240003597	3RR 160CH1200W RLB 3LB SDXT2 RX CVG BS6	TATA spare parts
429240003598	3RL 160CH1200W RLB 1LB SDXT2 RX CVG BS6	TATA spare parts
429240003599	2RH 2LM 360CH910W AR USB FAB SDXT2 CVG B	TATA spare parts
429240003600	RH 2ST SM1L 480CH910W USB FAB SDXT2 CVG	TATA spare parts
429240003601	RR 2ST 2LM 480CH820W LB USBFAB SDXT2 CVG	TATA spare parts
429240003602	1MID 2LM 480CH410W LB USB FAB SDXT2 CVG	TATA spare parts
429240003603	RL 2ST 2LM 480CH810W USB FAB SDXT2 CVG B	TATA spare parts
429240003604	LH 2ST SM1LM 480CH910W USB FAB SDXT2 CVG	TATA spare parts
429240003605	LH 2ST SM1L 480CH910W 1LB FAB SDXT2 CVG	TATA spare parts
429240003606	LH 1ST 2LM 360CH410W AR LB FAB SDXT2 CVG	TATA spare parts



429240003607	2RH 2LM 360C870W AR USB HBR CVG BS6	TATA spare parts
429240003615	2RH\LH 2LM 360CH810W WOCU CVG BS6	TATA spare parts
429240003616	2RH\LH SEAT 2LM460CH 2LB WOCU CVG BS6	TATA spare parts
429240003617	2LH 2LM 460CH810W 1LB WOCU CVG BS6	TATA spare parts
429240003643	2LH_2LM_460C810W_1LB_PMS_CUS_REX_CVG B	TATA spare parts
429240003650	2RH SM1L 480CH930W AR LB ERGONT1 FB CVG	TATA spare parts
429240003651	2RH SM1L 460CH935W AR ERGONT1 FB CVG BS6	TATA spare parts
429240003652	2RR 2LM 460CH810W LB ERGONT1 FB CVG BS6	TATA spare parts
429240003653	1MID 2LM 480CH410W LB USB FB ERGON 1 CVG	TATA spare parts
429240003654	2RL 2LM 460CH810W LB ERGONT1 USB FB CVG	TATA spare parts
429240003655	2LH SM1L 460CH935W AR ERGONT1 USB FB CVG	TATA spare parts
429240003656	1LH 2LM 460CH410W AR USB ERGONT1 FB CVG	TATA spare parts
429240003658	RH 3ST SM2L 480CH1230W SDX T2 CVG BS6-PH	TATA spare parts
429240003659	RH 3ST SM2LM 480CH1230W 3LB SDX T2 TM BS	TATA spare parts
429240003660	RR 3ST 3LM 480CH1170W 3LB SDX T2 TM	TATA spare parts
429240003661	RL 3ST 3LM 480CH1170W 1LB SDX T2 TM BS6-	TATA spare parts
429240003662	LH 2ST SM1LM 480C850W SDX T2 TM BS6-PH2	TATA spare parts
429240003663	LH 2ST SM1LM 480C850W 1LB SDX T2 TM BS6-	TATA spare parts
429240003664	RH 3ST 3LM 480CH1200W AR SDX T2 TM BS6-P	TATA spare parts
429240003668	LH 1ST 2LM 460CH410W AR USB SDXT2 CVG BS	TATA spare parts
429240003722	2RH SM1LM 480CH935W AR LB USB FB T2 CVG	TATA spare parts
429240003723	2LH SM1LM 480CH935W AR LB USB FB T2 CVG	TATA spare parts
429240003728	2RH SM2LM 450C760W 2LB AR SKL TM BS6	TATA spare parts
429240003741	3RH SM2L 480CH1230W FB USB SDXT2 CVG BS6	TATA spare parts
429240003742	3RH SM2L 480CH1230W LB FB USB SDXT2 CVG	TATA spare parts
429240003743	3RH 3LM 480CH1200W LB FB USB SDXT2 CVG B	TATA spare parts
429240003744	3LH 3LM 480CH1200W FB USB SDXT2 CVG BS6	TATA spare parts
429240003745	2LH SM1L 480CH850W FB USB SDXT2 CVG BS6	TATA spare parts
429240003746	2LH SM1L 480CH850W 1LB FB USB SDXT2 CVG	TATA spare parts
429240003755	RH 3ST SM2L 480CH1230W SDX T2 CVG BS6	TATA spare parts
429240003759	2LH SM1L 480C900W AR LB USB HBR CVG BS6	TATA spare parts
429240003761	1LH 2LM 460CH410W AR USB ERGONT1 FB CVG	TATA spare parts
429240003765	USB PORT WITH HARNESS LENGTH-908MM BS6	TATA spare parts
429240003804	2RH 2LM 460CH850W AR VN HB2 ED NDX CVG B	TATA spare parts
429240003805	2RH 1SM1LM 460CH850W VN HB2 NDX CVG BS6	TATA spare parts
429240003806	2RR 2LM 460CH810W VL NDXT2 CVG BS6	TATA spare parts
429240003807	2LH 1SM1LM 460CH850W VN HB2 NDX CVG BS6	TATA spare parts
429240003808	2LH 1SM1LM 460CH850W 1LB VN HB2 NDX CVG	TATA spare parts
429240003814	REAR 1MID_460CH_410W_LB_NDXT2_CVG BS6	TATA spare parts
429240003815	RR LH 2LM_460CH_810W_NDXT2_CVG BS6	TATA spare parts
429240003816	2RH 2LM 460CH850W AR VN HB2 NDX CVG BS6	TATA spare parts
429240003817	2REAR 2LM 460CH810W LB NDXT2 CVG BS6	TATA spare parts
429240003818	2LH 2LM 360CH910W AR USB FAB SDXT2 CVG	TATA spare parts
429240003829	2RH 2LM 365C1025W AR LB WA BLFB USB PB B	TATA spare parts
429240003830	2RH 2LM 475C1025W ARLB FB W\O FR PB USB	TATA spare parts
429240003832	2LH 2LM 365C1025W ARLB WA 89167 USB PB B	TATA spare parts
429240003833	2LH 2LM 475C1025W ARLB FB W\O FR USB PB	TATA spare parts

429240003834	1LH 2LM 345C525W ARLB WA 89167 PB USB HM	TATA spare parts
429240003837	RR_2RH_205C870W_AR_LB_RLB_FB89093_2PLB	TATA spare parts
429240003838	RR_2LH_205C870W_AR_LB_RLB_FB89093_2PLB	TATA spare parts
429240003839	2RH 2LM 460C940W AR LB BLFB89093_2PLB BS	TATA spare parts
429240003840	2RH_2LM_360C940W_WH_AR_LB_FB89093_2PL	TATA spare parts
429240003841	2LH 2LM 460C940W AR LB BL89093_2PLB BS6	TATA spare parts
429240003842	2LH_2LM_360C940W_WH_AR_LB_FB89093_2PL	TATA spare parts
429240003852	2RH SM1L 480C900W WH AR 3LB USB HBR CVG	TATA spare parts
429240003853	2RH SM1L 480C900W WH AR 3LB USB HBR CVG	TATA spare parts
429240003854	2RH SM1L 480C900W WH AR 3LB USB HBR CVG	TATA spare parts
429240003855	2REAR 2LM 480C870W AR 3LB USB HBR CVG BS	TATA spare parts
429240003856	1MID 2LM 480C410W 3LB USB HBR CVG BS6	TATA spare parts
429240003857	2REAR 2LM 480C870W AR 3LB USB HBR CVG BS	TATA spare parts
429240003858	2LH SM1L 480C900W WH AR 3LB USB HBR CVG	TATA spare parts
429240003859	2LH SM1L 480C900W WH AR 3LB USB HBR CVG	TATA spare parts
429240003864	2RH SM1LM 450C 760W SKL CVG BS6	TATA spare parts
429240003865	2RH SM1LM 450C760W WA SKL CV BS6	TATA spare parts
429240003866	4RR 3LM 450C1060W 1LB SKL CVG BS6	TATA spare parts
429240003867	3RL 2LM 450C950W 1LB SKL CVG BS6	TATA spare parts
429240003868	2LH SM1LM 450C760W SKL CVG BS6	TATA spare parts
429240003869	2LH SM1LM 450C760W WA SKL CVG BS6	TATA spare parts
429240003871	3RH SM1LM 450C950W 3LB AR SKL CVG BS6	TATA spare parts
429240003872	3RH SM1LM 450C950W SKL CVG BS6	TATA spare parts
429240003873	3RH SM1LM 450C950W WA SKL CVG BS6	TATA spare parts
429240003874	2RH_SM1LM_450C950W_2LB_VNL_SKL_CVG BS6	TATA spare parts
429240003875	2RH SM1LM 450C760W 2LB VNL SKL CVG BS6	TATA spare parts
429240003881	2RH SM2LM 450C760W WA AR 2LB SKL TM BS6	TATA spare parts
429240003882	4RR 3LM 450C1060W 4LB SKL TM BS6	TATA spare parts
429240003883	4RL 3LM 450C1060W 4LB SKL TM BS6	TATA spare parts
429240003884	2LH SM1LM 450C760W AR 2LP SKL TM BS6	TATA spare parts
429240003885	2LH SM1LM 450C760W WA AR 2LP SKL TM BS6	TATA spare parts
429240003898	2RH_SM1LM_450C950W_2LB_VNL_SKL_TM	TATA spare parts
429240003926	1MID 2LM 480CH410W LB SDXT2 CVG BS6-PH2	TATA spare parts
429240003927	RL 2ST 2LM 480CH810W SDXT2 CVG BS6-PH2	TATA spare parts
429240003928	1LH CD 2LM 480C410W AR SDXT2 CVG BS6-PH2	TATA spare parts
429240003945	RR 2ST 2LM 480CH820W LB USB FAB SDXT2 TM	TATA spare parts
429240003946	MID 2LM 480CH410W LB USB FABRIC SDXT2 TM	TATA spare parts
429240003952	2RH SM1LM 480CH935W AR LB USB FB T2 TM B	TATA spare parts
429240003972	3RR 3LM 480CH1200W AR 3LB SDX T2 CVG BS6	TATA spare parts
429240003973	3RL 2LM 480CH410W AR 2LB SDXT2 CVG BS6	TATA spare parts
429240004006	VINYL -BACK SEAT COVER_CVG BS6	TATA spare parts
429240004011	CO DRIVER- VINYL BACK SEAT COVER_TM BS6	TATA spare parts
429240004012	T2 VINYL-CUSHION SEAT COVER_CVG BS6	TATA spare parts
429240004013	T2 VINYL-CUSHION SEAT COVER_TM BS6	TATA spare parts
429242002003	PANEL PLATE ASSEMBLY 2550 BS6	TATA spare parts
429242003003	PANEL PLATE ASSY_RH BS6	TATA spare parts
429242003004	PANEL PLATE ASSY_LH BS6	TATA spare parts

429242003009	LH PANEL PLATE_LPO_NAC BS6	TATA spare parts
429242003011	PANEL PLATE LP_LH_AC_2200 BS6	TATA spare parts
429242003012	PANEL PLATE LP_LH_NAC_2200 BS6	TATA spare parts
429242003013	PANEL PLATE LP_RH_2200 BS6	TATA spare parts
429242003017	RH PANEL PLATE_PNEU_2340 BS6	TATA spare parts
429242003019	PANEL PLATE LH ASSY-LHD-2340	TATA spare parts
429242003020	LH PANEL PLATE_G3_NAC/IBDC BS6	TATA spare parts
429242003021	PANEL PLATE ASSY_RH_2200 BS6	TATA spare parts
429242003022	PANEL PLATE LH ASSY LHD_2340	TATA spare parts
429242083004	LH PANEL PLATE_LPO BS6	TATA spare parts
429242083005	LH_PANEL_PLATE_HUL BS6	TATA spare parts
429242083006	LH PANEL PLATE AMTS_2340 BS6	TATA spare parts
429242083007	DESTINATION BOARD SUPPORT BKT BS6	TATA spare parts
429242083010	PANEL PLATE LH_2340 BS6	TATA spare parts
429242083011	LH PANEL PLATE AC/NAC W/O DVD BS6	TATA spare parts
429242083013	LH_PANEL_PLATE_IBDC BS6	TATA spare parts
429242083016	PANEL PLATE RH-AC LHD	TATA spare parts
429242083017	LH PANEL PLATE_G3_VAVE BS6	TATA spare parts
429242083019	RH PANEL PLATE RDE BS6-PH2	TATA spare parts
429242083020	LH PANEL PLATE RDE BS6-PH2	TATA spare parts
429242083021	LH PANEL PLATE LP	TATA spare parts
429242083024	LH PANEL PLATE_RDE_LPO BS6-PH2	TATA spare parts
429242083025	PANEL PLATE RH_RDE_54WB BS6-PH2	TATA spare parts
429242084017	FRONT DEST BOARD BKT	TATA spare parts
429242363001	UPPER FRONT HARNESS G3 BS6	TATA spare parts
429242363002	DASHBOARD ELECTRIC HARNESS G3 BS6	TATA spare parts
429242363003	LOWER ELECTRIC HARNESS G3 BS6	TATA spare parts
429242363004	ROOF ELECTRIC INTERNAL LAMP HARNESS G3 B	TATA spare parts
429242363008	ROOF INTERNAL LAMP HARNESS 52WB G3 BS6	TATA spare parts
429242363011	PIGTAIL FOR STEP LAMP BS6	TATA spare parts
429242363012	PIGTAIL FOR STEP LAMP_2 DOOR BS6	TATA spare parts
429242363015	POWER SUPPLY HATRACK_READING LAMP	TATA spare parts
429242363017	PASSENGER MOBILE CHARGER HARNESS_CDS US	TATA spare parts
429242363018	INTERNAL LAMP HARNESS_29WB BS6	TATA spare parts
429242363019	UPPER FRONT W/H_LV BS6	TATA spare parts
429242363020	DASHBOARD W/H_LV BS6	TATA spare parts
429242363026	AIS 140 CONTROLLER HARNESS BS6	TATA spare parts
429242363027	UPPER FRONT HARNESS_HV_G3_24V BS6	TATA spare parts
429242363028	UPPER FRONT HARNESS G3_24V BS6	TATA spare parts
429242363030	DIGITAL CLOCK PIGTAIL	TATA spare parts
429242363031	DESTINATION BOARD PIGTAIL BS6	TATA spare parts
429242363032	EMERGENCY DECLARATION PIGTAIL BS6	TATA spare parts
429242363033	TV PIGTAIL BS6	TATA spare parts
429242363036	SHORTING PIGTAIL ELS BS6	TATA spare parts
429242363038	INTERNAL ILLUMINATION HARNESS_6NOS_G3 BS	TATA spare parts
429242363041	MICRO SWITCH HARNESS_G3 BS6	TATA spare parts
429242363042	FAN_SWITCH_PIGTAIL_G3 BS6	TATA spare parts

429242363044	DRIVER LAMP PIGTAIL_G3_IB BS6	TATA spare parts
429242363048	PIGTAIL FOR RPAS INTERCONNECTION BS6	TATA spare parts
429242363049	LOWER ELECTRICAL HARNESS G3 CNG BS6	TATA spare parts
429242363050	UPPER FRONT W/H SKL G3 BS6	TATA spare parts
429242363051	DASHBOARD HARNESS SKL G3 BS6	TATA spare parts
429242363052	LOWER ELECTRIC HARNESS SKL G3 BS6	TATA spare parts
429242363053	UPPER FRONT W/H STAFF G3 BS6	TATA spare parts
429242363054	DASHBOARD HARNESS STD G3 BS6	TATA spare parts
429242363059	AIS140 EMERGENCY SW HARNESS_M_DOOR_54V	TATA spare parts
429242363060	AIS140 EMERGENCY SW HARNESS BS6	TATA spare parts
429242363065	TURN IND & MARKER PIGTAIL FOR NEO LAMPS	TATA spare parts
429242363067	TOP MARKER PIGTAIL_G3_NEOLITE	TATA spare parts
429242363071	MANUAL DOOR REAR STEP LAMP PIGTAIL BS6	TATA spare parts
429242363073	READING LAMP HARNESS G3 BS6	TATA spare parts
429242363077	ADDITIONAL INTERNAL LAMP HARNESS_G3 BS6	TATA spare parts
429242363081	TAIL LAMP PIGTAIL_NEO LAMP BS6-PH2	TATA spare parts
429242363083	WIPER PIGTAIL-LP613	TATA spare parts
429242363089	PASSENGER MOBILE CHARGER HARNESS 6NOS BS6	TATA spare parts
429242363090	PASSENGER MOBILE CHARGER HARNESS 7NOS BS6	TATA spare parts
429242363091	READING LAMP HARNESS_G3_8NOS	TATA spare parts
429242363092	READING LAMP HARNESS_G3_5NOS BS6	TATA spare parts
429242363107	WIRING HARNESS G3 LIFT BS6	TATA spare parts
429242363108	BATTERY CABLE BS6	TATA spare parts
429242363112	AIS 140 EMERGENCY SW ASSY_RDE_DS_6NOS BS6	TATA spare parts
429242363113	HARNESS AIS140 SW 5NOS CDS RDE BS6-PH2	TATA spare parts
429242363114	WIRING HARNESS AIS 140 SW 4NOS DS RDE BS6	TATA spare parts
429242363115	WIRING HARNESS AIS 140 SW 3NOS CDS RD BS6	TATA spare parts
429242363116	HARNESS AIS 140 SW 7 NOS DS RDE BS6-PH2	TATA spare parts
429242363117	SHORTING HARNESS_AIS140 SWITCH BS6-PH2	TATA spare parts
429242363122	WIRING HARNESS UPPER FRONT 12V MID G3 RD	TATA spare parts
429242363123	W HARNESS UPPER FRONT 12V HIGH G3 BS6-PH2	TATA spare parts
429242363129	WIRING HARNESS SALOON LAMP 4 NO RR TOP MARKER	TATA spare parts
429242363130	W HARNESS SALOON LAMP 6NO_RR TOP MARKER	TATA spare parts
429242363131	POWER SUPPLY W/H ACRYLIC DEST BOARD BS6-PH2	TATA spare parts
429242363132	CHASSIS TO HMSL POWER SUPPLY HARNESS BS6-PH2	TATA spare parts
429242363134	HARNESS AIS140 SW 6NOS CDS RDE BS6-PH2	TATA spare parts
429242363135	W HARNESS DASHBOARD LV G3 RDE BS6-PH2	TATA spare parts
429242363137	W HARNESS SALOON LAMP 5NO_RR TOP MARKER	TATA spare parts
429242363138	W/H PIGTAIL ACRYLIC DEST. BOARD	TATA spare parts
429242363140	W/H EXT LAMP_REV SIGNAL& DOOR OPEN IND.	TATA spare parts
429242363143	PIGTAIL FOR SPOT LIGHT BS6-PH2	TATA spare parts
429242363144	W/H PIGTAIL SUPPLY TO TFT&DVD BS6-PH2	TATA spare parts
429242363146	W/H_CONTROL STP ARM TOP MARKER BLINK	TATA spare parts
429242363147	W/H INT LAMP 5BRANCH_RR TOP MARKER	TATA spare parts
429242363148	PIGTAIL IGN BATTERY REVE SIGNAL TO MNVR	TATA spare parts
429242363149	W/H RFID PROVISION	TATA spare parts
429242363150	W/H NO CHILD SLEEP BUTTON PROVISION	TATA spare parts

429242373005	HEAD LAMP_LH_12V_NEO-1535L BS6-PH2	TATA spare parts
429242373006	HEAD LAMP_RH_12V_NEO-1535R BS6-PH2	TATA spare parts
429242373013	TAIL LAMP_LH_12V_NEO 1541L BS6-PH2	TATA spare parts
429242373014	TAIL LAMP_RH_12V_NEO 1541R BS6-PH2	TATA spare parts
429245073001	LIFTING HOOK_FES BS6	TATA spare parts
429250003096	MIDDLE BRACKET ASSLY- GRILLED HATRACK BS	TATA spare parts
429250003097	WINDOW PILLER SUPPORT BRACKET BS6	TATA spare parts
429250003110	JOINERY DUCT ASSEMBLY-RH BS6	TATA spare parts
429250003112	JOINERY DUCT ASSEMBLY LH BS6	TATA spare parts
429250084090	DOUBLE HOLE PLATE WASHER BS6	TATA spare parts
429250184236	REAR TR BOX PLATE CC165 BS6	TATA spare parts
429250323005	HOSE COVER - BASE BS6	TATA spare parts
429250323006	HOSE COVER BS6	TATA spare parts
429250324030	HATRACK END COVER- G3	TATA spare parts
429250962001	ROOF AC UNIT CC 175 - 12V BS6	TATA spare parts
429250962002	ROOF AC UNIT CC 225 WIDER - 24V BS6	TATA spare parts
429250962003	ROOF AC UNIT CC 225 - 24V BS6	TATA spare parts
429250962007	G3 45WB AC HOSE PIPE AND FITTING INFO BS	TATA spare parts
429250962008	G3 52WB AC HOSE PIPE AND FITTING INFO BS	TATA spare parts
429250962011	ROOF AC UNIT CC 165 - 12V BS6	TATA spare parts
429250964016	PLASTIC GRILL 539X359 BS6	TATA spare parts
429250964019	DASH CONTROL SBU410 (SW2) BS6	TATA spare parts
429250964020	SETBUS 4-HOLE DASH CONTROLLER BTK BS6	TATA spare parts
429250964021	S/W PRESSURE HIGH PS80-01-1195 BS6	TATA spare parts
429250964022	S/W PRESSURE LOW PS80-02-F1427 BS6	TATA spare parts
429250964026	FITTING GASKET SEAL BS6	TATA spare parts
429250964034	BATTERY WIRE ASSY25SQMM(RED 12 MTR) BS6	TATA spare parts
429250964050	BATTERY WIRE ASSY 25SQM(BLACK-0.5M) BS6	TATA spare parts
429250964061	FUSE BOX W/O PLATE(125A/100A) BS6	TATA spare parts
429250964062	INTERCONNECTION WH PIG TAIL 12 V BS6	TATA spare parts
429250964067	O.RING DIA 10.82 X TH 1.78 1/2 BS6	TATA spare parts
429250964069	VALVE SUCTION LINE	TATA spare parts
429250964084	DUCT/RETURN AIR SENSOR(11118005A) BS6	TATA spare parts
429250964085	RELAY BOARD SBF243 BS6	TATA spare parts
429250964086	CONNECTION PAD-DISCHARGE CC-225 BS6	TATA spare parts
429250964087	PIN VALVE BS6	TATA spare parts
429250964088	TERMINAL BLOCKM-8 BS6	TATA spare parts
429250964089	PIGTAIL ASSY SFA 12V BS6	TATA spare parts
429250964090	EVAP-COND WIRING HARNES_CC225 REV02 BS6	TATA spare parts
429250964091	CC225 BLOWER WH WITH SETBUS BS6	TATA spare parts
429250964092	TEMPERATURE SENSOR PIGTAIL BS6	TATA spare parts
429250964093	MAIN WIRING HARNESS FICD BS6	TATA spare parts
429250964094	PLATE RETAINER ASSY BS6	TATA spare parts
429250964095	AXIAL FAN 24V BASICWG-14034-00 BS6	TATA spare parts
429250964096	RADIAL BLOWER 24V BASIC WG-14092-00 BS6	TATA spare parts
429250964097	AIR FILTER (MASS) BS6	TATA spare parts
429250964098	DEAD PLUG WITH VALVE 7/16 BS6	TATA spare parts

429250964099	LIQUID LINE ASSY.-1 CC225 WIDE BS6	TATA spare parts
429250964100	DISCHARGE LINE ASSY. CC225 WIDE BS6	TATA spare parts
429250964101	SUCTION LINE ASSY. CC225 WIDE BS6	TATA spare parts
429250964102	COVER FIBER_CC225 WIDE-RTM BS6	TATA spare parts
429250964103	CONDENSER BRACKET_CC225 WIDE BS6	TATA spare parts
429250964104	FIXING SUP. EVAP COVER RIGHT CC-225 BS6	TATA spare parts
429250964105	FIXING SUP. EVAP COVER LEFT CC-225 BS6	TATA spare parts
429250964106	EVAP WATER PLATE CC-225 BS6	TATA spare parts
429250964107	SEALING PLATE TOP-COND. CC225 BS6	TATA spare parts
429250964108	SEALING PLATE BOTTOM-COND. CC225 BS6	TATA spare parts
429250964109	BKT - SC600 SENSOR CC225 RETURN AIR BS6	TATA spare parts
429250964110	FILTER SUPPORT BRACKET BS6	TATA spare parts
429250964111	CENTRAL FIXING SUPPORT BS6	TATA spare parts
429250964112	TERMINAL BLOCK M-8 BS6	TATA spare parts
429250964138	STOP VALVE 3/4	TATA spare parts
429250964139	HEATING ADOPTOR 3/4_19MM HOSE	TATA spare parts
429250964140	BATTERY WIRE ASSY 35 SQMM(BLACK- 0.	TATA spare parts
429250964141	MAIN WIRING HARNESS SC600 FOR CC275	TATA spare parts
429250964142	TATA CC275 SC600 8 POLE TO 6 POLE P	TATA spare parts
429250964143	RED 35MM POWER CABLE 6.3 MTR	TATA spare parts
429250964144	INTERCONNECTING PIPE 3/4 HEATING	TATA spare parts
429250964145	REDUCER RUBBER 35MM TO 19 MM	TATA spare parts
429250964146	SUCTION HOSE ASSEMBLY_TATA LPO 916	TATA spare parts
429250964147	DISCHARGE HOSE ASSEMBLY TATA LPO916	TATA spare parts
429250964148	HEATER HOSE 19MM	TATA spare parts
429250964150	FLAP MOTOR 0132.801.141.-000	TATA spare parts
429250964151	EVAPORATOR COIL LH CC275 AC	TATA spare parts
429250964152	EVAPORATOR COIL RH CC275 AC	TATA spare parts
429250964153	HEATING COIL LH-CC275	TATA spare parts
429250964154	AMBIENT SENSOR(11118004A)	TATA spare parts
429250964155	ICE SENSOR (83186A)	TATA spare parts
429250964156	WATER VALVE BUSCHJOST 24V	TATA spare parts
429250964157	CONDENSOR W/H CC355/SC600	TATA spare parts
429250964158	ROOF W/H SC600 CC275 WITH HEATING	TATA spare parts
429250964159	XM BRUSHLESS FAN (11126147A)	TATA spare parts
429250964160	AIR FILTER	TATA spare parts
429250964161	AXEL FRESH AIR FLAP	TATA spare parts
429250964162	EVAPORATOR COVER CC-275	TATA spare parts
429250964163	RUBBER PROFILE BASE CC-275	TATA spare parts
429250964164	SIDE BKT_FRESH AIR CC225	TATA spare parts
429250964165	AIR-FLAP_FOR FRESH AIR CC-225	TATA spare parts
429250964166	MOTOR BKT_FRESH AIR_CC-225	TATA spare parts
429250964167	CONDENSER FAN PLATE_CC-275 CO-UP	TATA spare parts
429250964168	FEED PLATE ASSEMBLY_CC275 LHD	TATA spare parts
429250964169	DISCHARGE PIPE ASSEMBLY_LH	TATA spare parts
429250964170	PIPE ASSEMBLY_R/D INLET	TATA spare parts
429250964171	PIPE ASSEMBLY_RD OUTLET	TATA spare parts

429250964172	LIQUID LINE ASSEMBLY_1 LH	TATA spare parts
429250964173	SUCTION LINE ASSEMBLY LH	TATA spare parts
429250964174	HEATING PIPE ASSEMBLY_INLET RH	TATA spare parts
429250964175	HEATING PIPE ASSEMBLY_OUTLET RH	TATA spare parts
429250964176	MOUNTING BRACKET FOR TEMP. SENSOR	TATA spare parts
429250964201	CONDENSER FAN SPAL BRUSHLESS - BIG SIZE	TATA spare parts
429251003010	DRIVER PARTITION ASSY BS6	TATA spare parts
429251003014	DRIVER PARTITION ASSY 44WB BS6	TATA spare parts
429251003015	DRIVER PARTITION ASSY BS6	TATA spare parts
429251003017	DRIVER PARTITION ASEMBLY LPO_2550 BS6	TATA spare parts
429251003025	GRAB RAIL TUBE WITH PVC SLEEVE BS6	TATA spare parts
429251003027	DRIVER PARTITION ASSEMBLY BS6	TATA spare parts
429251003028	STEP WELL PARTITION WALL ASSY BS6	TATA spare parts
429251003031	DRIVER PARTITION ASSEMBLY_LP_2.34 BS6	TATA spare parts
429251003032	DRIVER PARTITION BEND TUBE ASM BS6	TATA spare parts
429251003033	STEP WELL PARTITION ASSY BS6	TATA spare parts
429251003038	DRIVER PARTITION ASSEMBLY_LP-2550 BS6	TATA spare parts
429251003039	DRIVER PARTITION ASSY_LP912_WIDER BS6	TATA spare parts
429251003042	DRIVER PARTITION_LPO_AC BS6	TATA spare parts
429251003044	STEP WELL PARTITION WALL ASSY_RAL1003 BS	TATA spare parts
429251003045	STANCHION TUBE ASSEMBLY BS6	TATA spare parts
429251003048	STANCHION TUBE ASSEMBLY BS6	TATA spare parts
429251003050	DRIVER PARTITION ASSEMBLY_LPO_RAL1003 BS	TATA spare parts
429251003053	STEP WELL PARTITION BS6	TATA spare parts
429251003060	STEP WELL PARTITION WALL ASSY BS6	TATA spare parts
429251003090	STEP WELL PARTITION WALL ASSY BS6	TATA spare parts
429251003091	STEP WELL PARTITION WALL ASSY BS6	TATA spare parts
429251003092	STEP WELL PARTITION WALL ASSY BS6	TATA spare parts
429251004003	HANDHOLD TUBE ASSEMBLY_03 BS6	TATA spare parts
429251004013	DRIVER PARTITION TUBE ASSY_LP BS6	TATA spare parts
429251004014	DRIVER PARTITION TUBE ASSY BS6	TATA spare parts
429251004016	HANDHOLD YUBE ASSY BS6	TATA spare parts
429251004017	DRIVER PARTITION TUBE ASSY BS6	TATA spare parts
429251004018	DRIVER PARTITION TUBE ASSY BS6	TATA spare parts
429251004019	DRIVER PARTITION TUBE ASSY BS6	TATA spare parts
429251004020	DRIVER PARTITION TUBE ASSY BS6	TATA spare parts
429251004021	HANDHOLD TUBE ASSEMBLY_LPO-2550 BS6	TATA spare parts
429251004024	DRIVER PARTITION TUBE ASSEMBLY L1924MM B	TATA spare parts
429251004026	HANDHOLD TUBE ASSY L681MM BS6	TATA spare parts
429251004028	HANDHOLD TUBE ASSEMBLY BS6	TATA spare parts
429251004029	HANDHOLD TUBE ASSEMBLY BS6	TATA spare parts
429251004031	DRIVER PARTION TUBE BS6	TATA spare parts
429251004032	DRIVER PARTITION STRIGHT TUBE ASM BS6	TATA spare parts
429251004033	DRIVER PARTITION BEND TUBE BS6	TATA spare parts
429251004034	PARTITION TUBE BS6	TATA spare parts
429251004036	STEP PARTITION TUBE ASSY BS6	TATA spare parts
429251004037	PARTITION WALL STRUCTURE ASSY BS6	TATA spare parts

429251004039	HAND HOLD TUBE ASSY BS6	TATA spare parts
429251004040	DRIVER PARTITION PIPE_635 BS6	TATA spare parts
429251004041	VERTICAL PIPE_DRIVER PARTITION BS6	TATA spare parts
429251004042	HAND HOLD TUBE ASSY_1917 BS6	TATA spare parts
429251004043	HAND HOLD TUBE ASSY_420 BS6	TATA spare parts
429251004044	HAND HOLD TUBE ASSY_533 BS6	TATA spare parts
429251004045	STEP PARTITION TUBE ASSY_RAL1003 BS6	TATA spare parts
429251004046	HANDHOLD TUBE ASSEMBLY_L620_RAL1003 BS6	TATA spare parts
429251004047	DRIVER PARTITION TUBE ASSY BS6	TATA spare parts
429251004051	PARTITION WALL STRUCTURE ASSY BS6	TATA spare parts
429251004052	HAND HOLD TUBE ASSY_1917 BS6	TATA spare parts
429251004057	HANDHOLD YUBE ASSY BS6	TATA spare parts
429251004060	STEP PARTITION ASSEMBLY LPO BS6	TATA spare parts
429251004062	HANDHOLD TUBE WITH YELLOW PVC L-465 BS6	TATA spare parts
429251004063	DRIVER PARTITION TUBE ASSY BS6	TATA spare parts
429251004064	STEP PARTITION TUBE ASSY BS6	TATA spare parts
429251004065	DRIVER PARTITION TUBE ASSY BS6	TATA spare parts
429251004067	DRIVER PARTITION TUBE ASM BS6	TATA spare parts
429251004068	DRIVER PARTITION TUBE ASSEMBLY L-1914 BS	TATA spare parts
429251004070	DRIVER PARTITION ASSEMBLY BS6	TATA spare parts
429251004071	STEP PARTITION ASSEMBLY LPO_RAL 1003 BS6	TATA spare parts
429251004072	STEP PARTITION ASSEMBLY LPO_RAL 1003 BS6	TATA spare parts
429251004074	HAND HOLD TUBE ASSY L-505 BS6	TATA spare parts
429251004076	DRIVER PARTITION TUBE ASSY BS6	TATA spare parts
429251233001	NOTICE BOARD GLASS 450X300X5 BS6-PH2	TATA spare parts
429252003012	FRONT INNER ASSLY_G3_2.34 BS6	TATA spare parts
429252003013	REAR INNER & SPEAKER GRILL ASSY_G3_2.34	TATA spare parts
429252003014	REAR INNER ASSLY_G3_2.55 BS6	TATA spare parts
429252003015	DASHBOARD & ENGINE HOOD ASSLY_G3-2.34 BS	TATA spare parts
429252003016	TOP FUSE BOX ASSLY_G3 BS6	TATA spare parts
429252003017	FRONT INNER ASSLY_G3_2.55 BS6	TATA spare parts
429252003018	CLUSTER ASSLY_G3_2.34 BS6	TATA spare parts
429252003021	FRONT INNER ASSLY_G3_2.34_AC BS6	TATA spare parts
429252003022	CLUSTER ASSLY_G3_2.55 BS6	TATA spare parts
429252003023	DASHBOARD & ENGINE HOOD ASSLY_G3_2.	TATA spare parts
429252003025	FRONT INNER ASSLY_G3_2.2 BS6	TATA spare parts
429252003026	REAR INNER ASSY_G3_2.20 BS6	TATA spare parts
429252003028	CLUSTER ASSLY_G3_2.34_LPO BS6	TATA spare parts
429252003029	DASHBOARD & ENGINE HOOD ASSLY_2.34_LPO B	TATA spare parts
429252003030	CLUSTER ASSLY_G3_2.55_LPO BS6	TATA spare parts
429252003031	DASHBOARD & ENGINE HOOD ASSLY_2.55_LPO B	TATA spare parts
429252003032	DASHBOARD & ENGINE HOOD ASSLY_G3-2.2 BS6	TATA spare parts
429252003034	G3 2.34 ENGINE HOOD&DASHBOARD ASSY BS6	TATA spare parts
429252003035	DASHBOARD & ENG HOOD ASSY_CNG_407/909 B	TATA spare parts
429252003036	DASHBOARD & EH ASSLY_G3-2.34 CNG 913 BS6	TATA spare parts
429252003037	CLUSTER ASSLY G3-2.34 CNG 913 BS6	TATA spare parts
429252003039	CLUSTER ASSLY_G3-2.55-LP_CNG 913 BS6	TATA spare parts



429252003040	DASHBOARD & EH ASSLY_G3-2.55-LP_CNG 913	TATA spare parts
429252003041	G3 2340 REAR INNER ASSY WITH DB BS6	TATA spare parts
429252003042	G3_2550 REAR INNER ASSLY WITH DB BS6	TATA spare parts
429252003045	CLUSTER & INS ASSLY_G3_2.34 BS6	TATA spare parts
429252003046	CLUSTER & INSU ASSLY_G3_2.55 BS6	TATA spare parts
429252003048	CLUSTER & INSU ASSLY_G3_2.55_LPO BS6	TATA spare parts
429252003052	FRONT INNER ASSY-G3-2.34-LHD	TATA spare parts
429252003054	DASHBOARD & ENGINE HOOD ASSLY G3 IB LHD	TATA spare parts
429252003061	DASHBOARD & EH ASSY 2.34-916-LPO-LHD	TATA spare parts
429252003062	TOP FUSE BOX ASSLY_LPO_2.34_LHD	TATA spare parts
429252003066	ENGINE HOOD&DASHBOARD ASSY_G3_CX BS6	TATA spare parts
429252003067	CLUSTER ASSLY_G3_CX BS6	TATA spare parts
429252003075	FRONT INNER ASSLY_G3_2.34_LHD	TATA spare parts
429252003076	REAR INNER ASSY_G3_2.34_DUBAI	TATA spare parts
429252003077	CLUSTER & INSU ASSLY_LPO_2.34_LHD PR	TATA spare parts
429252004005	FUSE BOX FLAP ASSLY_LH_G3 BS6	TATA spare parts
429252004006	FUSE BOX FLAP ASSLY_RH_G3 BS6	TATA spare parts
429252004007	GLOVE BOX FLAP ASSLY_RH_G3 BS6	TATA spare parts
429252004008	DASHBOARD ASSLY_G3_2.34 BS6	TATA spare parts
429252004009	FUSE BOX FLAP ASSLY_G3 BS6	TATA spare parts
429252004012	ENGINE HOOD ASSLY_G3 BS6	TATA spare parts
429252004014	DASHBOARD ASSLY_G3_2.55 BS6	TATA spare parts
429252004016	FUSE BOX FLAP ASSLY_G3_LPO BS6	TATA spare parts
429252004017	DASHBOARD ASSLY_G3_2.34_LPO BS6	TATA spare parts
429252004019	ENGINE HOOD ASSLY_G3_LPO BS6	TATA spare parts
429252004020	DASHBOARD ASSLY_G3_2.55_LPO BS6	TATA spare parts
429252004022	FUSE BOX FLAP ASSLY_G3_2.2 BS6	TATA spare parts
429252004023	GLOVE BOX FLAP ASSLY_G3_2.2 BS6	TATA spare parts
429252004024	DASHBOARD ASSLY_G3_2.2 BS6	TATA spare parts
429252004026	ENGINE HOOD ASSLY_G3_2.2 BS6	TATA spare parts
429252004027	G3_2.34 DASHBOARD ASSLY (4SPCR) BS6	TATA spare parts
429252004029	G3_2.34 ENGINE HOOD ASSLY (4SPCR) BS6	TATA spare parts
429252004032	DASHBOARD ASSLY_G3-2.34-LP CNG 913 BS6	TATA spare parts
429252004033	ENGINE HOOD ASSLY BS6	TATA spare parts
429252004034	DASHBOARD ASSLY BS6	TATA spare parts
429252004047	FUSE BOX FLAP ASSLY_G3_LPO_LHD	TATA spare parts
429252005013	G3_GEAR LEVER EXT FINISHING COVER BS6	TATA spare parts
429252005015	GSL COVER ASSLY_G3 BS6	TATA spare parts
429252063001	G3 ENGINE HOOD STAY ROD BS6	TATA spare parts
429252074001	STAY ROD BS6	TATA spare parts
429252263015	G3_BRAKE BOOSTER COVER BS6	TATA spare parts
429252264012	CLUSTER_G3_2.34 BS6	TATA spare parts
429252264013	CLUSTER_G3_2.55 BS6	TATA spare parts
429252264016	EXT ENGINEHOOD_G3_LPO BS6	TATA spare parts
429252264019	CLUSTER_G3_2.55_LPO BS6	TATA spare parts
429252264023	EXT ENGINEHOOD_G3_2.2 BS6	TATA spare parts
429252264026	GLOVE BOX_G3 2.34 & 2.55 BS6	TATA spare parts

429252264027	G3 USB HARNESS COVER	TATA spare parts
429252264029	CLUSTER_G3-2.34 CNG 913 BS6	TATA spare parts
429252264040	GLOVE BOX_G3 2.34 & 2.55_LHD	TATA spare parts
429252265007	GLOVE BOX_G3 2.2 BS6	TATA spare parts
429252265009	ENGINE HOOD TOP FLAP BS6	TATA spare parts
429252304001	G3 CLUTCH FLUID LID_BLACK BS6	TATA spare parts
429252323002	A-PILLAR COVER_LH BS6	TATA spare parts
429252323003	A-PILLAR COVER_RH BS6	TATA spare parts
429252323004	CLUSTER FINISHING_G3 BS6	TATA spare parts
429252323007	A-PILLAR COVER_G3 2.2 LH BS6	TATA spare parts
429252323008	A-PILLAR COVER_G3 2.2 RH BS6	TATA spare parts
429252323013	A-PILLAR COVER-RH G3-IB	TATA spare parts
429252323014	A-PILLAR COVER-LH G3-IB	TATA spare parts
429252324001	FRONT INNER_G3_2.34 BS6	TATA spare parts
429252324003	REAR INNER_G3_2.34 BS6	TATA spare parts
429252324008	FRONT INNER_G3_2.2 BS6	TATA spare parts
429252324009	REAR INNER_G3_2.20 BS6	TATA spare parts
429252324010	G3_2340 REAR INNER WITH DB BS6	TATA spare parts
429252324017	G3 PANIC SWITCH SPACER BS6	TATA spare parts
429252325006	GSL COVER_G3BS6	TATA spare parts
429252325011	GLOVE BOX FLAP-G3-IB LHD	TATA spare parts
429252325012	FUSE BOX FLAP-G3-2.2-IB	TATA spare parts
429252912010	DASHBOARD FIT_G3-LP-2.34 BS6	TATA spare parts
429252912029	DASHBOARD FIT G3 LP 2550 PR BS6	TATA spare parts
429253003008	TUBULAR HATRACK ASSY LH & RH BS6	TATA spare parts
429253003009	TUBULAR HATRACK ASSY RH BS6	TATA spare parts
429253003010	TUBULAR HATRACK ASSY RH BS6	TATA spare parts
429253003011	TUBULAR HATRACK ASSY LH BS6	TATA spare parts
429253003014	TUBULAR HATRACK ASSY LH_36 WB BS6	TATA spare parts
429253003015	TUBULAR HATRACK ASSY RH_36 WB BS6	TATA spare parts
429253003016	TUBULAR HATRACK ASSY LH_54 WB BS6	TATA spare parts
429253003017	TUBULAR HATRACK ASSY RH_54 WB BS6	TATA spare parts
429253003020	TUBULAR HATRACK ASSY LH BS6	TATA spare parts
429253003025	PADDED HATRACK SUB ASSY- RH BS6	TATA spare parts
429253003026	PADDED HATRACK SUB ASSY -LH BS6	TATA spare parts
429253003027	PADDED HATRACK SUB ASSY -LH BS6	TATA spare parts
429253003028	PADDED HATRACK SUB ASSY - RH BS6	TATA spare parts
429253003029	PADDED HATRACK SUB ASSY - LH BS6	TATA spare parts
429253003030	PADDED HATRACK SUB ASSY - RH BS6	TATA spare parts
429253003031	PADDED HATRACK SUB ASSY - LH BS6	TATA spare parts
429253003032	PADDED HATRACK SUB ASSY - RH BS6	TATA spare parts
429253003033	PADDED HATRACK SUB ASSY -LH BS6	TATA spare parts
429253003046	GRILLED HATRACK SUB ASSY RH BS6	TATA spare parts
429253003047	GRILLED HATRACK SUB ASSY LH BS6	TATA spare parts
429253003050	GRILL HATRACK SUB ASSY - LH BS6	TATA spare parts
429253003065	PADDED HATRACK SUB ASSY - RH BS6	TATA spare parts
429253003108	PADDED HATRACK SUB ASSY - RH BS6	TATA spare parts

429253003110	GRILL HATRACK SUB ASSY - RH BS6	TATA spare parts
429253003111	GRILL HATRACK SUB ASSY - RH	TATA spare parts
429253003112	GRILL HATRACK SUB ASSY - LH	TATA spare parts
429253003113	GRILL HATRACK SUB ASSY - RH BS6-PH2	TATA spare parts
429253003138	TUBULAR HATRACK ASSLY RH BS6-PH2	TATA spare parts
429253083001	HATRICK ARM TYPE-2	TATA spare parts
429253303001	HAT RACK GRILL TYPE- 2 BS6	TATA spare parts
429256083057	CENTER INTERNAL PANEL BS6	TATA spare parts
429256083105	SIDE INTERIOR PANEL LH1 BS6	TATA spare parts
429256083136	RH SIDE PANEL BS6	TATA spare parts
429256083150	RH SIDE PANEL BS6	TATA spare parts
429256083216	CENTER INTERNAL PANEL BS6	TATA spare parts
429256083217	CENTER INTERNAL PANEL BS6	TATA spare parts
429256083500	DRIVER PARTION PANEL LH PASS SIDE BS6	TATA spare parts
429256083501	DRIVER PARTION PANEL LH DRIVER BS6	TATA spare parts
429256083506	DRIVER PARTION PANEL RH PASS SIDE BS6	TATA spare parts
429256083507	DRIVER PARTION PANEL RH PASS SIDE BS6	TATA spare parts
429256083508	DRIVER PARTITION PASS SIDE BOTTOM BS6	TATA spare parts
429256083509	DRIVER PARTION PANEL RH PASS SIDE BS6	TATA spare parts
429256083510	DRIVER PARTION TOP PANEL LH PASS SIDE BS	TATA spare parts
429256083511	DRIVER PARTION TOP PANEL LH DRI. SIDE BS	TATA spare parts
429256083512	DRIVER PARTION TOP PANEL LH PASS. SIDE B	TATA spare parts
429256083513	DRIVER PARTION TOP PANEL LH PASS. SIDE B	TATA spare parts
429256083515	DRIVER PARTION LH PANEL PASS. SIDE BS6	TATA spare parts
429256083516	DRIVER PARTION PANEL RH DRIV. SIDE BS6	TATA spare parts
429256083517	DRIVER PARTITION DRIV. SIDE BOTTOM BS6	TATA spare parts
429258083001	REAR LICENSE PLATE_ WHITE	TATA spare parts
429259333001	EMERGENCY DOOR EXIT STICKER_ G3 BS6	TATA spare parts
429259333079	EURO III STICKER	TATA spare parts
429259333094	FRONT DOOR STICKER FOR SWITCH BS6	TATA spare parts
429259333095	REAR DOOR STICKER FOR SWITCH BS6	TATA spare parts
429259333096	ALL DOOR STICKER FOR SWITCH BS6	TATA spare parts
429259333097	DOOR RESET STICKER FOR SWITCH BS6	TATA spare parts
429259962002	REFLECTIVE TAPE G3_ 54WB_ SKL_ STD BS6	TATA spare parts
429260003001	RVM MIRROR LH ASSY BS6	TATA spare parts
429260003008	CO DRIVER SIDE RVM ARM G3 LHD	TATA spare parts
429260075001	RVM BUSH WITH M8 TAP	TATA spare parts
429261003042	RH 2ST SM1L 480CH850W LB AR SDXT2 CVG	TATA spare parts
429261003043	RH 2ST SM1L 480CH850W AR SDXT2 CVG	TATA spare parts
429261003044	LH 2ST SM1L 480CH850W AR SDXT2 CVG	TATA spare parts
429261003063	1RH_ 350CH405W_ LM_ PMS_ REXIN_ CVG BS6	TATA spare parts
429261003085	1COD 2LM 450CH400W AR NDX CVG BS6	TATA spare parts
429261003089	1COD 2LM 450CH400W AR LB NDX BS6	TATA spare parts
429261003093	SEAT 2RH 2LM 360 810W PMS CUS AR REX CVG	TATA spare parts
429261003094	RR 3ST 3LM 480CH1200W SDX T2 CVG BS6-PH2	TATA spare parts
429261003095	RR 3ST 3LM 480CH1200W SDX T2 TM BS6-PH2	TATA spare parts
429261003169	RH 2ST SM1L 380CH935W AR 2LP SDXT2 CVG B	TATA spare parts

429261003170	RH 2ST SM1L 480CH935W AR REX SDXT2 CVG B	TATA spare parts
429261003171	LH 2ST SM1L 480CH935W AR REX SDXT2 CVG B	TATA spare parts
429261003172	RH SM1L 480CH935W AR LB REX SDXT2 CVG BS	TATA spare parts
429261003173	RH 2ST SM1L 480CH935W AR REX SDXT2 CVG B	TATA spare parts
429261003174	LH 2ST SM1L 480CH935W AR REX SDXT2 CVG B	TATA spare parts
429261003177	RH 2ST LM 490CH1050W AR 3PLB PB SLR BS6	TATA spare parts
429261003178	RH 2S LM 490CH1050W AR 3PLB W/OFR PB SLR	TATA spare parts
429261003179	LH 1ST LM 490CH540W AR 3PLB PB SLR BS6	TATA spare parts
429261003180	RR 2ST LM 490CH960W AR 3PLB PB SLR BS6	TATA spare parts
429261003181	LH 2ST LM 490CH1050W AR 3PLB PB SLR BS6	TATA spare parts
429261003182	LH 2ST LM 380CH1050W AR 3PLB PB SLR BS6	TATA spare parts
429261003183	LH 2S LM 490CH1050W AR 3PLB W/OFR PB SLR	TATA spare parts
429261003184	RH 2ST LM 570CH1050W AR 3PLB PB SLR BS6	TATA spare parts
429261003185	LH SM1L 480CH935W AR 1LB REX HBT2 RDECVG	TATA spare parts
429261003186	RH 2ST SM1L 480CH935W AR REX HBT2 RDETM	TATA spare parts
429261003187	LH 2ST SM1L 480CH935W AR REX HBT2 RDETM	TATA spare parts
429261003188	LH SM1L 480CH935W AR 1LB REX HBT2 RDETM	TATA spare parts
429261003202	RR 2ST 2LM 480CH820W 3PLB USB HBT2 TM	TATA spare parts
429261003203	1MID 2LM 480CH410W 3PLB USB FAB HBT2 TM	TATA spare parts
429261003216	2RH SM1LM 480CH850W AR 3PL USB FB HBT2TM	TATA spare parts
429261003217	2LH SM1LM 480CH850W AR 3PL USB FB HBT2TM	TATA spare parts
429262003006	HAMMER WITH SEAT BELT CUTTER	TATA spare parts
429262005001	SUPPRESSION TUBE ASSY BS6	TATA spare parts
429262005002	FDSS WIRING HARNESS BS6	TATA spare parts
429262005005	HEAT SENSING CABLE BS6	TATA spare parts
429262005006	SUPPRESSION TUBE ASSY 54WB G3 BS6	TATA spare parts
429262005007	SUPPRESSION TUBE ASSY 29&33WB G3 BS6	TATA spare parts
429262005008	CLAMP DIA 18 BS6	TATA spare parts
429262005010	SUPPRESSION TUBE ASSY 36WB CNG BS6	TATA spare parts
429262005011	FDAS_HOOTER_12V/24V_GREEN FUEL BS6	TATA spare parts
429262005012	FDAS_CONTRO UNIT 12V/24V_GREENFUEL BS6	TATA spare parts
429262005013	FDAS_LHS CABLE ASSEMBLY_12V & 24V BS6	TATA spare parts
429262005014	FDAS_WIRING HARNESS_12V/24V_GREEN FUEL	TATA spare parts
429262006001	SUPPRESSION TUBE FITMENT BS6	TATA spare parts
429262006002	FDSS WIRING HARNESS BS6	TATA spare parts
429262006003	CLAMP DIA8 BS6	TATA spare parts
429262006004	CLAMP DIA 11 BS6	TATA spare parts
429262006005	CLAMP_DIA 18 BS6	TATA spare parts
429262006006	FDSS_CONTROL UNIT_SAFEX BS6	TATA spare parts
429262006007	FDSS SOUNDER CUM FLASHER_SAFEX BS6	TATA spare parts
429262006008	SV-I FORREX CYLINDER BS6	TATA spare parts
429262006009	FDSS_HOSE_SAFEX BS6	TATA spare parts
429262006011	SV-I CYLINDER MOUNTING BKT BS6	TATA spare parts
429262006013	SUPPRESSION TUBE FITMENT BS6	TATA spare parts
429262006016	SUPPRESSION TUBE ASSY 45 WB-G3 BS6	TATA spare parts
429262006017	SUPPRESSION TUBE FITMENT BS6	TATA spare parts
429262006018	SUPPRESSION TUBE FITMENT_1 BS6-PH2	TATA spare parts

429262006019	SUPPRESSION TUBE FITMENT_2 BS6-PH2	TATA spare parts
429262006022	HOSE PIPE 4M BS6	TATA spare parts
429262365001	ELECTRIC ACTUATOR WIRE BS6	TATA spare parts
429262963005	FDSS KIT_45WB_SAFEX BS6	TATA spare parts
429262964001	FDSS_SAFEX_PANELING BS6	TATA spare parts
429262964002	FDSS_SAFEX_TRIM BS6	TATA spare parts
429262964004	FDSS_PANELING_36 &52 WB_SAFEX BS6	TATA spare parts
429262964005	FDSS_TRIM KITG3_36 & 52WB_SAFEX BS6	TATA spare parts
429262964006	FDSS PANELING G3 54 WB SAFEX BS6	TATA spare parts
429262964008	FDSS_PANELING_G3_29 & 33 WB_SAFEX BS6	TATA spare parts
429262964010	FDSS_PANELING_G3_45 WB_SAFEX BS6	TATA spare parts
429262964012	FDSS PANELING G3 36 WB SAFEX CNG BS6	TATA spare parts
429262964015	FDAS_PANELING KIT_12V/24V_GREENFUEL BS6	TATA spare parts
429262964016	FDAS_TRIM KIT_12V/24V_GREENFUEL BS6	TATA spare parts
429262964019	G3SKL PANELING KIT 36 45 52 NAC 4SPCR GF	TATA spare parts
429262964020	G3 SKL TRIM KIT 36 45 52 NAC 4SPCR GF BS	TATA spare parts
429262964032	FDAS_12V & 24V_CLH_PANELING_KIT BS6-PH2	TATA spare parts
429262964033	FDAS_12V_CLH_TRIM KIT BS6-PH2	TATA spare parts
429264003004	RH WINDOW 1008X980 BS6	TATA spare parts
429264003009	SERVICABLE WINDOW 1015X982_RH BS6	TATA spare parts
429264003012	RH EMERGENCY DOOR WINDOW 578X734 BS6	TATA spare parts
429264003014	DRIVER DOOR SERVICABLE WINDOW_802X726 BS6	TATA spare parts
429264003015	SCOOP WINDOW RH 213X181X715MM BS6	TATA spare parts
429264003016	WIND_ASSY_RH_TFBS_943X977_CLEAR_SER BS6	TATA spare parts
429264003017	WIND_ASSY_RH_TFBS_773X977_CLEAR_SER BS6	TATA spare parts
429264003018	FIXED WIND LH_383X977MM_CLEAR BS6	TATA spare parts
429264003020	WIND_LH_COD_1200X810_SLIDING_CLR GLS BS6	TATA spare parts
429264003021	PEEP WINDOW_345X398MM_CLEAR GLS BS6	TATA spare parts
429264003022	LH FIXED WIND_233X818MM_CLEAR GLS BS6	TATA spare parts
429264003023	RH_WIN_TFBS_498X980_CLEAR GLS_SERV BS6	TATA spare parts
429264003024	LH_WIN_TFBS_1228X980_CLEAR GLS BS6	TATA spare parts
429264003027	WIND_LH_COD_SLIDING_1009X818_CLEAR GLS BS6	TATA spare parts
429264003028	DRIVER DR WIND_SLIDING_611X769_CLEAR GLS BS6	TATA spare parts
429264003029	SCOOP WINDOW RH_362X823_CLEAR GLASS BS6	TATA spare parts
429264003030	VENTI WINDOW ASSY RH/LH_1340X1070_30PERC	TATA spare parts
429264003039	WINDOW ASSY_RH_TFBS_777X977_CLEAR GLS BS6	TATA spare parts
429264003040	RH_FIXED WIND GLS ASSY_408X977MM_CLEAR BS6	TATA spare parts
429264003041	WIND_ASSY_LH_633X977_CLEAR BS6	TATA spare parts
429264003042	WIND_ASSY_RH_943X977_CLEAR BS6	TATA spare parts
429264003043	WIND_ASSY_RH_1023X977_CLEAR BS6	TATA spare parts
429264003044	DRIVER DOOR ASSY_802X726_CLEAR GLS_4MM BS6	TATA spare parts
429264003045	RH WINDOW ASSY_1008X980_CLEAR GLS_4MM BS6	TATA spare parts
429264003046	RH WINDOW ASSY 4MM BS6	TATA spare parts
429264003048	RH EMG.DOOR WIND_578X734_CLEAR GLS_4MM BS6	TATA spare parts
429264003050	LH_WINDOW_TFBS_1293X980_CLEAR GLS_4MM BS6	TATA spare parts
429264003051	LH FIXED WINDOW_GLS_233X818_CLEAR_4MM BS6	TATA spare parts
429264003052	WIND_LH_COD_1200X818_SLDING_CLEAR GLS BS6	TATA spare parts

429264003053	WIND_ASSY_LH_1178X977_CLEAR BS6	TATA spare parts
429264003054	WIND_ASSY_LH_583X977_CLEAR_GLS BS6	TATA spare parts
429264003056	LH PEEP WIND_345X398_CLEAR_GLS_DELM POLY	TATA spare parts
429264003057	RH_FIXED WIND_GLS_ASSY_403X977MM_CLEAR B	TATA spare parts
429264003058	WIND_ASSY_RH_TFBS_908X977_CLEAR_SER BS6	TATA spare parts
429264003059	WIND_ASSY_RH_TFBS_633X977_CLEAR_GLS BS6	TATA spare parts
429264003060	WIND_ASSY_RH_TFBS_543X977_CLEAR_GLS BS6	TATA spare parts
429264003061	WIND_ASSY_LH_TFBS_1008X977_CLEAR_GLS BS6	TATA spare parts
429264003062	WIND_ASSY_RH_TFBS_903X977_CLEAR_GLS BS6	TATA spare parts
429264003063	WIND_ASSY_RH_TFBS_1158X977_CLEAR_GLS BS6	TATA spare parts
429264003069	VENT WINDOW ASSY RH/LH_1340X1070_50PERC	TATA spare parts
429264003070	WIND_ASSY_RH_TFBS_968X977_CLEAR_GLS BS6	TATA spare parts
429264003077	WIND_ASSY_RH_TFBS_498X980_CLEAR_GLS_4MM	TATA spare parts
429264003079	WIND_ASSY_RH_TFBS_633X977_CLEAR_GLS BS6	TATA spare parts
429264003080	WIND_ASSY_RH_TFBS_543X977_CLEAR_GLS_4MM	TATA spare parts
429264003081	WIND_ASSY_RH_TFBS_1108X977_CLEAR_GLS BS6	TATA spare parts
429264003083	WIND_LH_TFBS_1293X980_CLEAR_GLS_CANOPY	TATA spare parts
429264003093	DRIVER WIND ASSY_611X767_CLEAR_4MM THK B	TATA spare parts
429264003095	LH_CO-DRIVER WIND_611X767_CLEAR_4MM TH	TATA spare parts
429264003096	WIND_RH_TFBS_968X977_CLEAR_GLS_4MM THK	TATA spare parts
429264003097	RH_FIXED WIND_403X977MM_CLEAR_4MM THK	TATA spare parts
429264003098	WIND_LH_ASSY_1178X977_CLEAR_4MM THK BS6	TATA spare parts
429264003100	RH PEEP WINDOW_345X398_CLEAR_GLS BS6	TATA spare parts
429264003102	LH DRIVER DR.WIND_802X726_CLEAR_GLS	TATA spare parts
429264003108	FIXED WINDOW RH_323X980_50PERC GRN_4MM	TATA spare parts
429264003109	WIND_ASSY_LH_TFBS_777X977_50PERCGRN TNT	TATA spare parts
429264003110	LH WIND ASSY_TFBS_1293X977_50PERCGREEN T	TATA spare parts
429264003111	WIND_ASSY_RH_TFBS_943X977_50PERCGREEN T	TATA spare parts
429264003112	RH_WIND_TFBS_1293X977MM_50PERCGREEN T	TATA spare parts
429264003113	WIND_ASSY_RH_1023X977_50PERCGREEN TNT B	TATA spare parts
429264003114	RH EMER DR. WIND_578X734_50PERC GREEN TN	TATA spare parts
429264003115	SCOOP WIND RH_218X251X715MM_CLEAR 4MM	TATA spare parts
429264003117	FIXED DRIVER PRT.WIND_355X935_CLEAR_EPDM	TATA spare parts
429264003123	WIND_ASSY_LH_TFBS_773X977_CLEAR_GLS BS6	TATA spare parts
429264003124	WIND_ASSY_LH_TFBS_803X977_CLEAR GLASS BS	TATA spare parts
429264003126	SCOOP WIND LH_199X167X715MM-CLEAR 4MM	TATA spare parts
429264003127	WIND_RH_TFBS_1293X980_CLEAR_GLS_CANOPY	TATA spare parts
429264003134	LH_CO-DRIVER WIND_1241X818_CLEAR_4MM BS	TATA spare parts
429264003136	WINDOW_LH_TFBS_498X977_CLEAR_GLS_4MM B	TATA spare parts
429264003139	WIND_ASSY_LH_583X977_50PERC GRAY TNT_GL	TATA spare parts
429264003140	LH WIND_ASSY_TFBS_758X977_50PERCGRAY TN	TATA spare parts
429264003141	RH WIND_ASSY_TFBS_758X977_50PERCGRAY TN	TATA spare parts
429264003142	LH WIND ASSY_TFBS_1293X977_50PERCGRAY TI	TATA spare parts
429264003143	RH_WIND_TFBS_1293X977MM_50PERCGRAY TN	TATA spare parts
429264003144	WIND_ASSY_RH_1023X977_50PERCGRAY TNT BS	TATA spare parts
429264003145	RH EMER DR. WIND_578X734_50PERC GRAY TNT	TATA spare parts
429264003149	LH FIXED WIND_203X977_50PERCGRAY TNT_4MM	TATA spare parts

429264003150	RUBBER MOUNT-CASSETTE TYPE WIND_955X935	TATA spare parts
429264003153	LH CO-DRIVER WIND_1240X818_CLEAR_5MM BS	TATA spare parts
429264003174	LH LIFT WIND ASSY_1077X863_SDL_CLEAR_4MM	TATA spare parts
429264003183	RH_WIND_TFBS_903X977_CLEAR GLS_CANOPY	TATA spare parts
429264003184	RH_WIND_TFBS_1108X977_CLEAR GLS_CANOPY	TATA spare parts
429264003185	LH_WIND_ASSY_583X977_CLEAR_GLS_CANOPY	TATA spare parts
429264003186	LH_WIND_TFBS_1008X977_CLEAR_GLS_CANOPY	TATA spare parts
429264003189	LH_WIND_TFBS_1235X977MM_50PERCGRAR TN	TATA spare parts
429264003190	RH_WIND_TFBS_975X977MM_50PERCGRAY TNT	TATA spare parts
429264003191	RH_WIND_TFBS_410X977MM_50PERCGREEN TN	TATA spare parts
429264003192	PASTED GLASS RH_1410X1070_30PERC GREEN T	TATA spare parts
429264003193	PASTED GLASS RH_1340X1070_30PERC GREEN T	TATA spare parts
429264003194	PASTD GLS REAR RH_1541X1070_30PERC GREN	TATA spare parts
429264003195	PASTED GLASS LH_1118X1070_30PERC GREEN T	TATA spare parts
429264003196	PASTED GLASS LH_1340X1070_30PERC GREEN T	TATA spare parts
429264003197	PASTED GLS REAR LH_1541X1070_30PERC GREE	TATA spare parts
429264003198	WIND_ASSY_LH_TFBS_1008X977_CLEAR_GLS BS6	TATA spare parts
429264003199	WIND_ASSY_RH_TFBS_903X977_50PERCGRAY GL	TATA spare parts
429264003200	WIND_ASSY_RH_TFBS_1108X977_50PERCGRAY G	TATA spare parts
429264083002	PANEL ABOVE PASSENGER DOOR BS6	TATA spare parts
429264233025	RH PASTED GLS_286X1105_CLR_FULL CERA BS6	TATA spare parts
429264233028	RH PAST_695X245_CLEAR GLASS BS6	TATA spare parts
429264233029	RH EMG PAST_1062X685_30PERCGRN TINT BS6	TATA spare parts
429264233037	PASTED GLS_1062X1395MM_30PERC GREEN TIN	TATA spare parts
429264233041	PASTED GLASS_RH_1055X1070_30PERCGRN BS6	TATA spare parts
429264233042	PASTED GLASS_RH\LH_1340X1070_30PERCGRN B	TATA spare parts
429264233043	PASTED GLASS_RH_1105X1070_30PERCGRN BS6	TATA spare parts
429264233044	PASTED GLASS_LH_1395X1070_30PERCGRN BS6	TATA spare parts
429264233045	PASTED GLASS_LH_781X1070_30PERCGRN BS6	TATA spare parts
429264233047	PASTED GLASS_RH_306X1070_CLEAR BS6	TATA spare parts
429264233048	DRIVER PASTED GLS_924X805_CLEAR	TATA spare parts
429264233052	PASTED GLASS_RH_1120X1070_30PERCGRN BS6	TATA spare parts
429264233053	PASTED GLASS_RH_350X1070_30PERCGRN BS6	TATA spare parts
429264233054	LH PASTED GLS_1374X1070_30PERCGREEN TINT	TATA spare parts
429264233055	PASTED GLASS_LH_1395X1070_30PERCGRN BS6	TATA spare parts
429264233056	LH_PASTED GLS_710X308_CLEAR FULL CERAMIC	TATA spare parts
429264233057	LH_PAST GLS_330X1070_CLEAR FULL CERAMIC	TATA spare parts
429264233066	LH_PAST GLS_175X1070_CLEAR FULL CERAMIC	TATA spare parts
429264233071	PASTED GLASS_RH_1120X1070_50PERCGRAY BS6	TATA spare parts
429264233072	PASTED GLASS_LH_1395X1070_50PERCGRAY BS6	TATA spare parts
429264233073	PASTED GLASS_LH_1512X1070_50PERCGRAY BS6	TATA spare parts
429264233074	PASTED GLASS_RH_625X1070_50PERCGRAY BS6	TATA spare parts
429264233075	PAST GLASS_RH\LH_1340X1070_50PERCGRAY BS	TATA spare parts
429264233076	PASTED GLASS_RH_EMG_685X808_50PERCGRAY	TATA spare parts
429264233077	RH REAR PASTED_172X1070_CLEAR GLASS BS6	TATA spare parts
429264233083	PASTED GLASS_RH_1121X1070_50PERCGRAY BS6	TATA spare parts
429264233084	PASTED GLASS_RH_485X1070_50PERCGRAY BS6	TATA spare parts

429264233085	LH PASTED GLS_1378X1070_50PERC GRAY TINT	TATA spare parts
429264233086	LH PASTED GLS_190X1099_CLEAR_FULL CERA B	TATA spare parts
429264233087	PASTED GLASS_LH_1395X1070_50PERCGRAY BS6	TATA spare parts
429264233088	PASTED GLASS_LH_779X1070_50PERCGRAY BS6	TATA spare parts
429264233089	PASTED GLASS_RH_1055X1070_50PERCGRAY BS6	TATA spare parts
429264233090	PASTED GLASS_RH_1240X1070_50PERCGRAY BS6	TATA spare parts
429264233101	PASTED GLASS_RH_1105X1070_50PERCGRAY BS6	TATA spare parts
429264233102	REAR PASTED GLASS_RH_308X1070_CLEAR BS6	TATA spare parts
429264233111	PASTED GLASS_RH_490X1070_50PERCGRAY BS6	TATA spare parts
429264233113	LH PASTED GLS 710X419 CLEAR FULL CERAMIC	TATA spare parts
429264233116	PASTED GLASS_RH_580X1070_50PERCGRAY BS6	TATA spare parts
429264233117	PASTED GLASS_LH_1603X1070_50PERCGRAY BS6	TATA spare parts
429264233118	PASTED GLASS_RH_350X1070_50PERC GRAY BS6	TATA spare parts
429264233119	LH PASTED GLS_1374X1070_50PERC GRAY TINT	TATA spare parts
429264233120	LH-PASTED GLS-1118X1070-30 PER GREEN TIN	TATA spare parts
429264233121	PASTED GLASS-LH-1541X1070-30 PER GRN	TATA spare parts
429264233122	LH PASTED GLS-1112X288-CLEAR GLS	TATA spare parts
429264233123	LH-PASTED GLS-1410X1070-30 PER GREEN TIN	TATA spare parts
429264233124	PASTED GLS-RH-1540X1070-30 PER GREEN TNT	TATA spare parts
429264233125	RH PASTED GLS-488X306-CLEAR GLS	TATA spare parts
429264233126	PASTED GLASS_RH_715X1070_50PERC GRAY BS6	TATA spare parts
429264233127	PASTED GLASS_RH_232X1070_50PERC GRAY BS6	TATA spare parts
429264233128	REAR PAST GLASS_RH_650X1070_50PERCGRAY B	TATA spare parts
429264233133	PASTED GLASS_LH_1415X1070_50PERCGRAY BS6	TATA spare parts
429264233134	PASTED GLASS_LH_983X1070_50PERC GRAY BS6	TATA spare parts
429264233135	LH_PASTED GLS_710X383_CLEAR FULL CERAMIC	TATA spare parts
429264233136	LH PASTED GLS_187X826_CLEAR_FULL CERA BS	TATA spare parts
429264233137	PASTED GLASS_RH_1365X1070_50PERCGRAY BS6	TATA spare parts
429264233138	RH REAR PASTED_983X1070_50PERCGRAY TINT	TATA spare parts
429264233139	H PASTED GLS_186X1075_CLEAR_FULL CERA BS	TATA spare parts
429264233140	RH PASTED GLS_293X1167_CLEAR GLS BS6-PH2	TATA spare parts
429264233144	LH REAR PASTED GLS 1048X1070 50PERCGRAY	TATA spare parts
429264233149	LH PASTED GLS_186X1139_CLEAR (40EXT) BS6	TATA spare parts
429264233178	RH PASTED GLS_591X323_FULL CERAMIC GLS	TATA spare parts
429264234001	EXTERNAL GLASS	TATA spare parts
429264234002	INTERNAL GLASS	TATA spare parts
429264234003	FIXED WINDOW GLASS 236X920_CLEAR	TATA spare parts
429264234004	FIXED WINDOW GLASS 215X805	TATA spare parts
429264234005	EXTERNAL GLASS BS6	TATA spare parts
429264234006	INTERNALGLASS BS6	TATA spare parts
429264234007	TOP FIXED GLASS BS6	TATA spare parts
429264234008	EXTERNAL GLASS	TATA spare parts
429264234009	INTERNAL GLASS	TATA spare parts
429264234010	TOP FIXED GLASS	TATA spare parts
429264234011	EXTERNAL GLASS	TATA spare parts
429264234012	INTERNAL GLASS	TATA spare parts
429264234014	TOP FIXED GLASS	TATA spare parts



429264234015	EXTERNAL GLASS	TATA spare parts
429264234016	INTERNAL GLASS	TATA spare parts
429264234017	FIXED GLASS BS6	TATA spare parts
429264234020	FIXED WINDOW GLASS 414X969	TATA spare parts
429264234021	EMERGENCY DOOR WINDOW GLASS 290X709 BS6	TATA spare parts
429264234022	EMERGENCY DOOR WINDOW GLASS 290X709 BS6	TATA spare parts
429264234023	EXTERNAL GLASS_438X702_CLEAR GLS BS6	TATA spare parts
429264234024	INTERNAL GLASS_380X702_CLEAR GLS BS6	TATA spare parts
429264234025	SCOOP WIN GLS_277X187X151X708_CLEAR BS6	TATA spare parts
429264234027	FRT EXTGLS_RH&RR INTGLS_LH_480X619_CLR B	TATA spare parts
429264234028	RR INT RH&FNT EXT LH_480X619_CLR BS6	TATA spare parts
429264234029	TOP FIXED GLS_918X322MM_CLR BS6	TATA spare parts
429264234030	TOP FIXED GLS_748X322_CLEAR BS6	TATA spare parts
429264234031	RR INT LH&AMP FRNT EXT RH_395X619_CLR BS	TATA spare parts
429264234032	RR INT RH&AMP FRNT EXT LH_395X619_CLEAR	TATA spare parts
429264234033	FIXED WIND GLASS ASSY_374X969MM_CLEAR BS	TATA spare parts
429264234037	FRNT EXT GLS_LH_643X789_CLEAR GLS BS6	TATA spare parts
429264234038	REAR INT GLS LH_643X789_CLEAR GLS BS6	TATA spare parts
429264234039	FIXED WINDOW GLS_337X390MM_CLEAR BS6	TATA spare parts
429264234040	LH_FIXED GLASS_224X811_CLEAR BS6	TATA spare parts
429264234041	RR INT GLS RH_244X619_CLEAR GLS BS6	TATA spare parts
429264234042	FRNT EXT GLS RH_270X619_CLEAR GLS BS6	TATA spare parts
429264234043	TOP FIXED GLS_473X322_CLEAR GLS BS6	TATA spare parts
429264234044	FRNT EXT GLS LH_622X619_CLEAR GLS BS6	TATA spare parts
429264234045	RR INT LH_622X619_CLEAR GLS BS6	TATA spare parts
429264234046	TOP FIXED GLS_1203X322_CLEAR GLS BS6	TATA spare parts
429264234047	FRNT RH EXT&LH INT GLS_656X619_CLEAR GLS	TATA spare parts
429264234048	RR INT RH&LH EXT GLS_656X619_CLEAR GLS B	TATA spare parts
429264234050	FRONT EXT GLS_657X797_CLEAR GLS BS6	TATA spare parts
429264234051	REAR INT GLS_371X797_CLEAR GLASS BS6	TATA spare parts
429264234052	WIN FRNT GLS_RH_315X745_CLEAR GLASS BS6	TATA spare parts
429264234053	WIN RR INT GLS RH_315X745_CLEAR GLASS BS	TATA spare parts
429264234054	SCOOP WINDOW GLASS_370X85X806MM_CLEAR	TATA spare parts
429264234055	VENTI WINDOW_RH/LH_1340X1070_30PERCGRN	TATA spare parts
429264234075	FIXED WIND GLASS ASSY_399X969MM_CLEAR BS	TATA spare parts
429264234076	WINDOW GLASS_FRONT_325X619_CLEAR BS6	TATA spare parts
429264234077	WINDOW GLASS_REAR_325X619_CLEAR BS6	TATA spare parts
429264234078	TOP FIXED GLASS_608X322_CLEAR BS6	TATA spare parts
429264234079	WINDOW GLASS_FRONT_480X619_CLEAR BS6	TATA spare parts
429264234080	WINDOW GLASS_REAR_480X619_CLEAR BS6	TATA spare parts
429264234081	TOP FIXED GLASS_918X322_CLEAR BS6	TATA spare parts
429264234082	WINDOW GLASS_FRONT_520X619_CLEAR	TATA spare parts
429264234083	WINDOW GLASS_REAR_520X619_CLEAR	TATA spare parts
429264234084	TOP FIXED GLASS_998X322_CLEAR BS6	TATA spare parts
429264234085	FRNT EXT GLS_RH_438X702_4MM_CLEAR GLS BS	TATA spare parts
429264234086	REAR INT GLS RH_380X702X4MM_CLEAR GLS BS	TATA spare parts
429264234091	FRNT EXT GLS_RH_290X709X4MM_CLEAR GLS BS	TATA spare parts

429264234092	REAR INT GLS_RH_290X709X4MM_CLEAR GLS BS	TATA spare parts
429264234099	FRONT EXT GLS_RH_512X619X4MM_CLEAR GLAS	TATA spare parts
429264234100	REAR INT GLS_RH_512X619X4MM_CLEAR GLASS	TATA spare parts
429264234101	FULL FIXED WINDOW GLS_259X969_4MM_CLEAR	TATA spare parts
429264234102	FRNT_EXT GLS_LH_622X619X4MM_CLEAR GLS BS	TATA spare parts
429264234103	RR INT GLS_LH_622X619X4MM_CLEAR GLS BS6	TATA spare parts
429264234104	LH_FULL FIXED GLS_224X811X4MM_CLEAR GLS	TATA spare parts
429264234105	FRNT EXT GLS_LH_643X797_4MM_CLEAR GLS BS	TATA spare parts
429264234106	RR INT GLS_LH_643X797X_4MM_CLEAR GLS BS6	TATA spare parts
429264234108	LH_FRNT EXT GLS_300X619_CLEAR GLS BS6	TATA spare parts
429264234109	REAR INT GLS_LH_300X619_CLEAR GLS BS6	TATA spare parts
429264234110	WINDOW GLASS_FRONT_597X619_CLEAR BS6	TATA spare parts
429264234111	TOP FIXED GLASS_558X322_CLEAR GLS BS6	TATA spare parts
429264234112	WINDOW GLASS_REAR_597X619_CLEAR BS6	TATA spare parts
429264234113	TOP FIXED GLASS_1153X322_CLEAR BS6	TATA spare parts
429264234114	FIXED WINDOW GLASS 327X374MM BS6	TATA spare parts
429264234115	FIXED WIND GLASS ASSY_394X969MM_CLEAR BS	TATA spare parts
429264234116	FRONT EXT GLS_462X619_CLEAR GLS BS6	TATA spare parts
429264234117	REAR INT GLS_462X619_CLEAR GLS BS6	TATA spare parts
429264234118	TOP FIXED GLASS_883X322_CLEAR GLS BS6	TATA spare parts
429264234119	WINDOW GLASSES_CLEAR GLS BS6	TATA spare parts
429264234120	REAR INTERNAL GLASS BS6	TATA spare parts
429264234121	TOP FIXED GLASS_608X322_CLEAR GLS BS6	TATA spare parts
429264234122	WINDOW GLASSES_CLEAR GLS BS6	TATA spare parts
429264234123	WINDOW GLASSES_CLEAR GLS BS6	TATA spare parts
429264234124	WINDOW GLASSES_CLEAR GLASS BS6	TATA spare parts
429264234125	WINDOW GLASS_CLEAR BS6	TATA spare parts
429264234126	429264234126 BS6	TATA spare parts
429264234127	429264234127 BS6	TATA spare parts
429264234128	WINDOW GLASSES_CLEAR BS6	TATA spare parts
429264234129	WINDOW GLASSE_CLEAR BS6	TATA spare parts
429264234130	WINDOW GLASSES_CLEAR BS6	TATA spare parts
429264234132	VENTI WINDOW_RH/LH_1340X1070_50PERCGRA	TATA spare parts
429264234133	FRNT EXT GLS_492X619_CLEAR GLS BS6	TATA spare parts
429264234134	REAR INT GLS_492X619_CLEAR GLS BS6	TATA spare parts
429264234135	TOP FIXED GLS BS6	TATA spare parts
429264234144	WINDOW SLIDING GLASS_CLEAR_4MM THK BS6	TATA spare parts
429264234145	WINDOW SLIDING GLASS_CLEAR_4MM THK BS6	TATA spare parts
429264234147	WIN GLASSES_CLEAR GLS_4MM THK BS6	TATA spare parts
429264234148	WINDOW GLASSES_CLEAR GLS_4MM THK BS6	TATA spare parts
429264234149	WINDOW GLASSES_CLEAR GLS_4MM BS6	TATA spare parts
429264234150	WINDOW GLASSES_CLEAR GLS_4MM BS6	TATA spare parts
429264234151	WINDOW SLIDING_CLEAR GLASS BS6	TATA spare parts
429264234152	WIND SLIDING CLEAR GLS BS6	TATA spare parts
429264234153	TOP FIXED GLASS_1083X322MM_CLEAR BS6	TATA spare parts
429264234159	SCOOP WINDOW GLASS_187X708_CLEAR_DELMC	TATA spare parts
429264234172	WIN GLS RR INT RH 315X745MM CLEAR GLS BS	TATA spare parts

429264234173	WIN GLS FRNT EXT RH 315X745MM CLEAR GLS	TATA spare parts
429264234175	FRONT EXTERNAL GLASS 657X797 CLEAR 4MM T	TATA spare parts
429264234176	REAR INTERNAL GLASS 401X797 CLEAR 4MM TH	TATA spare parts
429264234177	FRNT EXT GLS 4MM THK BS6	TATA spare parts
429264234178	REAR INT GLS BS6	TATA spare parts
429264234179	FIXED WIND GLS CLEAR 4MM THK BS6	TATA spare parts
429264234180	FRNT EXT GLS LH BS6	TATA spare parts
429264234181	RR INT GLS LH BS6	TATA spare parts
429264234187	FRNT EXT GLS_LH_438X701_CLEAR GLS	TATA spare parts
429264234188	RR INTERNAL GLS_LH_380X701_CLEAR GLS	TATA spare parts
429264234201	REAR INT GLS_656X619_50PERCGREEN TINT BS	TATA spare parts
429264234211	SCOOP WINDOW GLS_195X234X707_4MM CLEAR	TATA spare parts
429264234226	FRNT EXT GLS_LH_395X619_CLEAR GLASS BS6	TATA spare parts
429264234227	REAR INT GLS_LH_395X619_CLEAR GLASS BS6	TATA spare parts
429264234228	TOP FIXED GLS_748X322_CLEAR GLASS BS6	TATA spare parts
429264234233	SCOOP WIND_GLS_173X141X707_CLEAR GLS	TATA spare parts
429264234244	FRNT EXT GLS_XXX X797_CLEAR_4MM THK BS6	TATA spare parts
429264234245	REAR INT GLS_XXX X797_CLEAR_4MM THK BS6	TATA spare parts
429264234250	LH_FRNT EXT GLS_300X619_50PERC GRAY BS6	TATA spare parts
429264234251	REAR INT GLS_LH_300X619_50PERC GRAY BS6	TATA spare parts
429264234252	TOP FIXED GLASS_558X322_50PERC GRAY BS6	TATA spare parts
429264234253	FRNT EXT GLS_LH_387X619_50PERC GRAY TNT	TATA spare parts
429264234254	REAR INT GLS_LH_387X619_50PERC GRAY TNT	TATA spare parts
429264234255	TOP FIXED GLS_733X322_50PERC GRAY TNT BS	TATA spare parts
429264234256	LH WIND ASSY_TFBS_1293X977_50PERCGRAY TI	TATA spare parts
429264234257	FRNT EXT GLS BS6	TATA spare parts
429264234258	TOP FIXED GLS_1268X322_50PERCGRAY TINT B	TATA spare parts
429264234259	TOP FIXED GLASS_998X322_50PERCGRAY TNT B	TATA spare parts
429264234260	RR INT GLS_RH_520X619_50PERCGRAY TINT BS	TATA spare parts
429264234261	FRNT EXT GLS_RH_520X619_50PERCGRAY TNT B	TATA spare parts
429264234262	REAR INT GLS_290X709_50PERC GRAY TNT BS6	TATA spare parts
429264234263	FRNT EXT GLS_RH_290X709_50PERCGRAY TNT B	TATA spare parts
429264234270	LH/RH_FIXED WIND GLS_194X969_CLEAR_4MM T	TATA spare parts
429264234276	FRNT EXT GLS_663X797_CLEAR_5MM BS6	TATA spare parts
429264234277	REAR INT GLS_579X797_CLEAR_5MM BS6	TATA spare parts
429264234320	FRNT EXT GLS_549X839_CLEAR_4MM THK BS6	TATA spare parts
429264234321	REAR INT GLS_549X839_CLEAR_4MM THK BS6	TATA spare parts
429265003016	DRIVER SIDE SPINDLE ASSY_2550 BS6	TATA spare parts
429265003017	CO-DRIVER SIDE SPINDLE ASSY_2550 BS6	TATA spare parts
429265084017	WIPER MOTOR BRACKET_2.55	TATA spare parts
429265084026	WIPER MOTOR BRACKET COVER FOR 2.2BS6	TATA spare parts
429265234001	FRONT WINDSHIELD_G3-2.34 BS6	TATA spare parts
429265234002	REAR WINDSHIELD_G3-2.34 BS6	TATA spare parts
429265234004	REAR WINDSHIELD_G3-2.55 BS6	TATA spare parts
429265234006	FRONT WINDSHIELD_G3-2.20 BS6	TATA spare parts
429265234007	REAR_WINDSHIELD_G3-2.20 BS6	TATA spare parts
429265234015	REAR WINDSHIELD G3-2.34-IB	TATA spare parts

429265234016	CX G3-2.2 FRONT WINDSHIELD BS6	TATA spare parts
429265284001	FRONT W/S RUBBER_G3-2.34 BS6	TATA spare parts
429265284002	REAR W/S RUBBER_G3-2.34 BS6	TATA spare parts
429265284003	FRONT W/S RUBBER_G3-2.55 BS6	TATA spare parts
429265284004	REAR W/S RUBBER_G3-2.55 BS6	TATA spare parts
429265284005	FRONT W/S RUBBER_G3-2.20 BS6	TATA spare parts
429265284006	REAR W/S RUBBER_G3-2.20 BS6	TATA spare parts
429265284007	REAR W/S RUBBER_G3-2200 BS6	TATA spare parts
429265284008	FRONT W/S RUBBER_CX G3-2.2 BS6	TATA spare parts
429268003004	DOUBLE ARM LIFT MECHANISM BS6	TATA spare parts
43178	SUN GEAR RETAINER	TATA spare parts
43271	THRUST WASHER LH GR SUPPO	TATA spare parts
435203621000000	PIPE BRACKET (SQUARE -30x	TATA spare parts
43764	ADAPTOR	TATA spare parts
43828	CLAMP HOSE	TATA spare parts
43828A	CLAMP HOSE	TATA spare parts
43943	SLACK ADJ INR WASHER	TATA spare parts
43CX001Z00	RUBBER BOLSTER SPRING	TATA spare parts
44358	BOLT	TATA spare parts
4474375001	KNUCKLE CARRIER LINKS 35 880 P	TATA spare parts
4474375002	KNUCKLE CARRIER RECHTS 35	TATA spare parts
4474375004	TRACK LEVER RECHTS 5 080 P	TATA spare parts
4474385019	KING PIN	TATA spare parts
4474385038	SPRING CARRIER RH	TATA spare parts
4474385044	SPRING CARRIER LH	TATA spare parts
4474385057	FRONT HUB LOCK NUT	TATA spare parts
4474385106	COVER	TATA spare parts
4474385118	FRONT HUB	TATA spare parts
44CX002Z00	UPPER DAMPER MOUNT	TATA spare parts
44CX005C01	HWS DAMPER	TATA spare parts
453220050001	NO PLATE LAMP (NET PLAST MAKE)	TATA spare parts
453621	BALL 0.750 INCH	TATA spare parts
45521	SHIFT UNIT COVER	TATA spare parts
45604005EN000000	STEP LAMP	TATA spare parts
45661000CF	MARKER LAMP (ORANGE)	TATA spare parts
456610060001	HT MARKER LAMP (WHITE) E MARK	TATA spare parts
45661006CF000000	HEIGHT MARKER LAMP (WHITE)	TATA spare parts
456610070001	HT MARKER LAMP (RED) E MARK	TATA spare parts
45661007CF000000	HEIGHT MARKER LAMP (RED)	TATA spare parts
46-X-C001	FITTING GREASE	TATA spare parts
4890404	CLIP WIRE RETAINING	TATA spare parts
4890832	SEAL OIL	TATA spare parts
4891178	BUSHING	TATA spare parts
4891179	RING COMPRESSION PISTON	TATA spare parts
4891252	PUMP WATER	TATA spare parts
4891288	GASKET OIL DRAIN	TATA spare parts
4891385	WASHER SEALING	TATA spare parts

4892239	PLATE COVER	TATA spare parts
4892320	ALTERNATOR	TATA spare parts
4892338	MOTOR STARTING	TATA spare parts
4893494	GASKET COVER PLATE	TATA spare parts
4893936	NUT HEXAGON FLANGE	TATA spare parts
4894100	BRACKET LIFTING	TATA spare parts
4894641	SCREW CAPTIVE WASHER CAP	TATA spare parts
4895459	CAP FILLER	TATA spare parts
4895710	SEAL O RING	TATA spare parts
4895877	SCREW SOCKET HEAD CAP	TATA spare parts
4896404	PLUNGER PRS REGULATOR	TATA spare parts
4896768	SCREW HEX FLANGE HEAD CAP	TATA spare parts
4896991	STUD	TATA spare parts
4897457	SUPPORT CAMSHAFT THRUST	TATA spare parts
4897833	FUEL FILTER CARTRIDGE	TATA spare parts
4897898	LUBE FILTER CARTRIDGE	TATA spare parts
4898037	PAN OIL	TATA spare parts
4898301	GASKET OIL SUC CONNECTION	TATA spare parts
4898372	SEAL O RING	TATA spare parts
4899226	GASKET VALVE COVER	TATA spare parts
4899231	GASKET RKR LEVER HOUSING	TATA spare parts
4899239	ISOLATOR NOISE	TATA spare parts
4899705	PLATE COVER	TATA spare parts
4899743	CLIP	TATA spare parts
4899794	HOSE FLEXIBLE	TATA spare parts
4918186	Ignition Diagnostic Tester kit	TATA spare parts
4918190	Inline IV adapter kit	TATA spare parts
4918294	PISTON RING COMPRESSOR	TATA spare parts
4918343	Ignition coil testing kit	TATA spare parts
4918416	KIT DATALINK ADAPTER	TATA spare parts
4918857	CABLE ELECTRICAL	TATA spare parts
4921322	SENSOR PRS TEMPERATURE	TATA spare parts
4921479	SENSOR PRS TEMPERATURE	TATA spare parts
4921483	SENSOR PRS TEMPERATURE	TATA spare parts
4921489	SENSOR PRESSURE	TATA spare parts
4921495	SENSOR PRESSURE	TATA spare parts
4921503	SENSOR PRESSURE	TATA spare parts
4921684	SENSOR POSITION	TATA spare parts
4926715	BEARING BALL	TATA spare parts
4926779	GOVERNER ELECTRIC	TATA spare parts
4926780	WIRING HARNESS	TATA spare parts
4926781	VALVE SOLENOID	TATA spare parts
4926782	MIXER AIR FUEL	TATA spare parts
4926783	OXIGEN SENSOR	TATA spare parts
4926784	HOSE FLEXIBLE	TATA spare parts
4926785	HOSE FLEXIBLE	TATA spare parts
4926788	ADAPTOR PLAIN	TATA spare parts

4926790	BRACKET SOLENOID	TATA spare parts
4926792	BRACKET MODULE	TATA spare parts
4926865	CONNECTION EXHAUST OUTLET	TATA spare parts
4926866	TUBE CPR WATER INLET	TATA spare parts
4926868	TUBE CPR WATER OUTLET	TATA spare parts
4926870	TUBE CORROSION RESISTOR	TATA spare parts
4926872	TUBE CORROSION RESISTER	TATA spare parts
4926879	VALVE SHUTOFF	TATA spare parts
4926880	SEAL KIT - G303-3	TATA spare parts
4926882	O RING SEAL KIT (O RING + DIAPHRAM)	TATA spare parts
4926883	COIL ELECTRICAL (G - 50)	TATA spare parts
4926884	PLUNGER & TUBE ASSY	TATA spare parts
4926889	BRACE ALTEROTOR	TATA spare parts
4926910	TUBE FUEL SUPPLY	TATA spare parts
4926911	TUBE FUEL SUPPLY	TATA spare parts
4926912	TUBE FUEL SUPPLY	TATA spare parts
4927000	LP FILTER OUT. CONN.	TATA spare parts
4927019	BKT MNTG	TATA spare parts
4927020	ELBOW	TATA spare parts
4927021	CLAMPS	TATA spare parts
4927022	STEP CONNECTION	TATA spare parts
4927023	STEP CONNECTION	TATA spare parts
4927027	ALTERNATOR	TATA spare parts
4927029	HOSE	TATA spare parts
4927050	COVER VALVE	TATA spare parts
4927098	TUBE CPR WATER INLET	TATA spare parts
4927099	TUBE CPR WATER OUTLET	TATA spare parts
4927100	TUBE CORROSION RESISTOR	TATA spare parts
4928698	ASSEMBLY ROCKER LEVER	TATA spare parts
4929642	THERMOSTAT	TATA spare parts
4930058	TUBE FUEL SUPPLY	TATA spare parts
4930060	TUBE FUEL SUPPLY	TATA spare parts
4930847	COVER FRONT	TATA spare parts
4930918	MANIFOLD AIR INTAKE	TATA spare parts
4931041	PIN PISTON	TATA spare parts
4931643	PLUG PIPE (3/4 NPT)	TATA spare parts
4932210	GASKET CYLINDER HEAD	TATA spare parts
4932211	CLIP	TATA spare parts
4932559	BRACE ALTERNATOR	TATA spare parts
4932713	GEAR FUEL PUMP	TATA spare parts
4933232	BRACKET LIFTING	TATA spare parts
4933317	PLUG PIPE (1/4 NPT)	TATA spare parts
4933503	HARNESS WIRING	TATA spare parts
4933532	PLUG PIPE	TATA spare parts
4933627	BRACE AIR COMPRESSOR	TATA spare parts
4933777	PIPE AIR TRANSFER	TATA spare parts
4933782	COMPRESSOR AIR	TATA spare parts

4934344	GASKET OIL PAN	TATA spare parts
4934861	CRANKSHAFT ENGINE	TATA spare parts
4934994	ASSY. PROPELLER SHAFT	TATA spare parts
4936026	THERMOSTAT	TATA spare parts
4936049	COMPRESSOR AIR	TATA spare parts
4936080	SPRING VALVE	TATA spare parts
4936081	HEAD CYLINDER	TATA spare parts
4936218	COMPRESSOR AIR	TATA spare parts
4936226	KIT AIR COMPRESSOR REPAIR	TATA spare parts
4936423	HOUSING GEAR	TATA spare parts
4936879	ALTERNATOR	TATA spare parts
4937065	INJECTOR	TATA spare parts
4937308	NOZZLE PISTON COOLING	TATA spare parts
4937420	SCREW ROUND HEAD CAP	TATA spare parts
4937694	COUPLING PLAIN HOSE	TATA spare parts
4938189	PLUG EXPANSION	TATA spare parts
4938655	ADAPTER OIL PAN	TATA spare parts
4938657	HOUSING ROCKER LEVER	TATA spare parts
4938989	CLAMP V BAND	TATA spare parts
4939408	CONNECTION EXHAUST OUTLET	TATA spare parts
4939588	PUMP LUBRICATING OIL	TATA spare parts
4940183	UNION MALE	TATA spare parts
4940552	TUBE FUEL SUPPLY	TATA spare parts
4940658	HEAD CYLINDER	TATA spare parts
4942494	CONNECTION WATER INLET	TATA spare parts
4942495	HOUSING STARTING AID	TATA spare parts
4943731	BRACE TUBE	TATA spare parts
4943771	TUBE FUEL DRAIN	TATA spare parts
4943979	ROD ENGINE CONNECTING	TATA spare parts
4944710	PUMP FUEL TRANSFER	TATA spare parts
4944711	PUMP FUEL TRANSFER	TATA spare parts
4944718	HEAD FUEL FILTER	TATA spare parts
4945783	STIFFENER CYLINDER BLOCK	TATA spare parts
4946176	STUD	TATA spare parts
4946178	COVER REAR	TATA spare parts
4946179	VALVE INTAKE	TATA spare parts
4946180	VALVE EXHAUST	TATA spare parts
4946294	COMPRESSOR AIR	TATA spare parts
4946295	COMPRESSOR AIR	TATA spare parts
4946426	CYL HEAD WITH VALVE ROTATOR	TATA spare parts
4946586	BLOCK CYLINDER	TATA spare parts
4946651	ADAPTER FUEL CONNECTOR	TATA spare parts
4946714	NUT LOCK	TATA spare parts
4947063	FAN ENGINE	TATA spare parts
4947708	ASSLY CYLINDER HEAD	TATA spare parts
4947710	ASSLY CYLINDER HEAD	TATA spare parts
4947829	DAMPER VIBRATION	TATA spare parts

4947898	ROD ENGINE CONNECTING	TATA spare parts
4948391	HOUSING FLYWHEEL	TATA spare parts
4954905	SENSOR TEMPERATURE	TATA spare parts
4955125	SENSOR HUMIDITY	TATA spare parts
4955521	SET MAIN BEARING	TATA spare parts
4962810	FILTER FUEL	TATA spare parts
4962811	WIRING HARNESS ENGINE LPO1510 CNG BSIII	TATA spare parts
4962859	CONVERTOR CATALYTIC	TATA spare parts
4962933	SPRING - THROTTLE RETURN	TATA spare parts
4962942	VALVE SHUT OFF	TATA spare parts
4963085	HOUSING FLYWHEEL CAST IRON	TATA spare parts
4963226	GOVERNOR ELECTRIC	TATA spare parts
4963269	BLOCK CYLINDER	TATA spare parts
4963307	CLAMP V BAND	TATA spare parts
4963357	CATCON	TATA spare parts
4963419	BRACKET MODULE	TATA spare parts
4963494	LPR DIAPHRAGM KIT	TATA spare parts
4963495	AIR FUEL MIXER DIAPFRAGM KIT	TATA spare parts
4963520	BRACKET	TATA spare parts
4963521	BRACKET	TATA spare parts
4963522	SELF LOCKING ROUTERS	TATA spare parts
4981331	MANIFOLD AIR INTAKE	TATA spare parts
4981723	FLYWHEEL	TATA spare parts
4983059	KIT BREATHER	TATA spare parts
4983351	TUBE FUEL SUPPLY	TATA spare parts
4983355	HEAD LUB OIL FILTER	TATA spare parts
4984223	SENSOR POSITION	TATA spare parts
4988595	PUMP FUEL	TATA spare parts
4988747	PUMP FUEL TRANSFER	TATA spare parts
4988748	PUMP FUEL TRANS 210HP IN	TATA spare parts
4988820	MODULE ELECTRONIC CONTROL	TATA spare parts
4988952	oil seal	TATA spare parts
4989116	HEAD FUEL FILTER	TATA spare parts
4989131	BOOT SPARK PLUG	TATA spare parts
4990173	ELBOW MALE ADAPTER	TATA spare parts
4990591	BRACKET MODULE	TATA spare parts
4990696	COVER INTAKE MANIFOLD	TATA spare parts
499101003001	FRONT STRUCTURE_ IDEALE BS6	TATA spare parts
499101014003	A-PILLAR LH_ IDEALE BS6	TATA spare parts
499101014004	A-PILLAR RH_ IDEALE BS6	TATA spare parts
499103004005	FRONT WHEELARCH ASSY-RH BS6	TATA spare parts
499103004034	DRIVER DOOR APARTURE ASSY BS6	TATA spare parts
499107003006	FRONT ROOF STUCTURE	TATA spare parts
499110231001	FRONT WINDSHIELD_ RUBBER MOUNTED W/P BS6	TATA spare parts
499110901008	SOLID RUBBER PRFL FOR HALF PARTITION 6M	TATA spare parts
499110901009	M PVC PROFILE RAL 7024 6M BS6	TATA spare parts
4991131	DAMPER VIBRATION	TATA spare parts



499115003003	DRIVER DOOR EXT PANEL WITH LOCK ASSY	TATA spare parts
499115003007	DRIVER DOOR EXT PANEL WITH LOCK ASSY LHD	TATA spare parts
499115003014	DRIVER DOOR PANELLING ASSY 800X1598 APP	TATA spare parts
499115003018	INTERNAL GRAB HANDLE BS6	TATA spare parts
499115083005	DOOR INTERNAL PANEL	TATA spare parts
499115083007	DRIVER DOOR INTERNAL PANEL LHD	TATA spare parts
499115083012	DRIVER DOOR INTERNAL PANEL BS6	TATA spare parts
499115303001	DRIVER DR CANOPY_PP_IDEALE BS6	TATA spare parts
499116003001	EMG DOOR & FLUSH TYPE LOCK ASSY_NON AC	TATA spare parts
499116003005	EMG DOOR & LOCK ASSY APP 705X1500MM	TATA spare parts
499116003011	EMG DOOR & LOCK ASSY_APP 705X1500MM BS6	TATA spare parts
499116083001	EMG DOOR INTERNAL PANEL FLUSH TYPE N/AC	TATA spare parts
499116083003	EMERGENCY DOOR INTERNAL PANEL	TATA spare parts
499117003001	TAPER JK DOOR ASSEMBLY -800 APP IDEALE	TATA spare parts
499117003006	FRONT TAPER JK PASS DOOR ASSY_LHD	TATA spare parts
499117003015	PARTITION DOOR STRUCTURE ASSEMBLY BS6	TATA spare parts
499117004006	INSWING DOOR STRUCTURE PANEL ASSY BS6	TATA spare parts
499117074001	THREADED PIVOTE BUSH BS6	TATA spare parts
499117074002	PIVOT BUSH BS6	TATA spare parts
499117083001	STOPPER FOR IDEALE J K DOOR	TATA spare parts
499117233001	PARTITION DOOR GLASS	TATA spare parts
499117234001	PASSENGER DOOR GLASS -800 APP IDEALE	TATA spare parts
499117234002	PASS DOOR TPER GLASS -800 APP IDEALE	TATA spare parts
499117234004	FRONT TAPER JK DOOR FRONT GLASS_LHD	TATA spare parts
499117284001	BOTTOM RUBBER FOR PASSENGER DOOR BS6	TATA spare parts
499117414001	PASSENGER DOOR MIDDLE INTERNAL PANEL BS6	TATA spare parts
499117414002	BOTTOM INTERNAL PANEL BS6	TATA spare parts
499117414003	TOP INTERNAL PANEL BS6	TATA spare parts
499117414004	DOOR FINISHING LH SIDE BS6	TATA spare parts
499117414005	DOOR FINISHING RH SIDE BS6	TATA spare parts
499118003002	IDEALE_FRONT FACE & FRONT FLAP ASSLY	TATA spare parts
499118003010	FRONT FACE & FRONT FLAP ASSLY	TATA spare parts
499118004001	FRP FRONT FLAP IDEALE	TATA spare parts
499118083013	HINGE MOUNTING L-PROFILE RH BS6	TATA spare parts
499118083014	HINGE MOUNTING L-PROFILE LH BS6	TATA spare parts
499118213001	RAIN GUTTER FRINT LH	TATA spare parts
499118213002	RAIN GUTTER FRONT RH	TATA spare parts
499118213003	FRONT FINISHING PROFILE LH	TATA spare parts
499118213004	FRONT FINISHING PROFILE RH	TATA spare parts
499119264001	FRP_REAR FACE_IDEALE	TATA spare parts
499119264005	REAR FACE_IDEALE( WITH FOG LAMP) BS6	TATA spare parts
499120003002	AIR FILTER FLAP ASSY	TATA spare parts
499120003005	LOCK ROD & GAS PISTON BRACKET	TATA spare parts
499120003007	SPARE WHEEL FLAP OF APERTURE 850X670	TATA spare parts
499120003008	BATTERY FLAP ASSEMBLY OF APR 740X650MM	TATA spare parts
499120003031	SLB FLAP OF APERTURE 1200X744 BS6	TATA spare parts
499121002001	DRIVER PARTITION DOOR ASSEMBLY	TATA spare parts

499121324001	IDEALE ABS PARTITION DOOR FINISH SS BS6	TATA spare parts
499121324002	IDEALE ABS PARTITION DOOR FINISH DS BS6	TATA spare parts
499128083010	LH SKIRT PANLE-03	TATA spare parts
499128083012	SKIRT PANLE-05	TATA spare parts
499128083016	WINDOW PILLAR SHEET-02	TATA spare parts
499128083024	DRIVER DR INCHLINCH PROFILE	TATA spare parts
499128083025	DRIVER DR INCHLINCH PROFILE-02	TATA spare parts
499128083026	EMERG DR INCHLINCH PROFILE-01	TATA spare parts
499128083027	EMERG DR INCHLINCH PROFILE-02	TATA spare parts
499128083029	EMERG DR PILLAR PANEL	TATA spare parts
499128083033	DRIVER DR FRONT PANEL-01	TATA spare parts
499128083038	DRIVER DOOR PANEL-06	TATA spare parts
499128083039	EMERGDOR PANEL-05	TATA spare parts
499128083043	EXT PANEL PILLAR	TATA spare parts
499128083045	SKIRT PANEL-02	TATA spare parts
499128083046	STREATCH PANEL LH	TATA spare parts
499128083047	SKIRT PANEL	TATA spare parts
499128083049	SKIRT PANEL	TATA spare parts
499128083055	SKIRT PANEL	TATA spare parts
499128083056	LH SKIRT PANEL-01	TATA spare parts
499128083057	LH SKIRT PANEL-2	TATA spare parts
499128083059	WINDOW PILLAR SHEET 2	TATA spare parts
499128083063	WINDOW PANEL	TATA spare parts
499128083064	CANOPY PASS DOOR	TATA spare parts
499128083066	EXT PANEL L	TATA spare parts
499128083067	EXT PANEL PASS DOOR	TATA spare parts
499128083068	EXT PANEL	TATA spare parts
499128083069	EXT PANEL DOOR	TATA spare parts
499128083071	DOOR CANOPY FOR 800 DRIVER DOOR	TATA spare parts
499128083080	RH SIDE CENTRE SKIRT PANEL	TATA spare parts
499128083082	WINDOW PILLAR SHEET	TATA spare parts
499128083083	WINDOW PILLAR SHEET_03	TATA spare parts
499128083084	RH SIDE REAR SKIRT PANEL	TATA spare parts
499128083085	STRETCH PANEL	TATA spare parts
499128083087	RH SKIRT PANEL-02	TATA spare parts
499128083088	LH SKIRT PANLE-03	TATA spare parts
499128083089	LH SKIRT PANLE-05	TATA spare parts
499128083090	RH SKIRT PANEL-6	TATA spare parts
499128083091	EMERG DR TOP PANEL	TATA spare parts
499128083092	EMERG DOOR¿ PANEL	TATA spare parts
499128083093	DRVER FOOT STEP PANEL	TATA spare parts
499128083095	PASSENGER DOOR FRONT PANNEL	TATA spare parts
499128083096	DR DOOR L PROFILE-02	TATA spare parts
499128083097	DR DOOR L PROFILE-03	TATA spare parts
499128083099	RH SIDE CENTRE SKIRT PANEL	TATA spare parts
499128083102	LH SKIRT PANEL	TATA spare parts
499128083103	RH SKIRT PANEL	TATA spare parts

499128083108	RH SKIRT PANEL	TATA spare parts
499128083109	EXTERNAL PANEL FRONT	TATA spare parts
499128083110	DRIVER FOOT STEP PANEL	TATA spare parts
499128083111	LH SIDE CENTRE SKIRT PANEL	TATA spare parts
499128083112	LH SKIRT PANEL	TATA spare parts
499128083114	RH SIDE SKIRT PANEL	TATA spare parts
499128083116	EMERGENCY DOOR PANEL BS6	TATA spare parts
499128083117	DRIVER DOOR L PROFILE	TATA spare parts
499128083123	DRIVER DOOR L PROFILE	TATA spare parts
499128083124	DRIVER DOOR L PROFILE	TATA spare parts
499128083125	DRIVER DOOR L PROFILE	TATA spare parts
499128083126	DRIVER DOOR L PROFILE	TATA spare parts
499128083128	DOOR FINISHING PROFILE	TATA spare parts
499128083130	DOOR FINISHING PROFILE	TATA spare parts
499128083133	DRIVER FOOT STEP SUPPORT BRACKET	TATA spare parts
499128083137	STRETCH PANEL	TATA spare parts
499128083138	RH SIDE REAR SKIRT PANEL	TATA spare parts
499128083141	FRONT DRIVER SIDE EXTERNAL PANEL	TATA spare parts
499128083142	DRIVER DOOR TOP PANEL_STD	TATA spare parts
499128083143	PASSENGER DOOR TOP PANEL_STD	TATA spare parts
499128083144	EXTERNAL PANEL_LHD	TATA spare parts
499128083169	EMG DOOR L PROFILE	TATA spare parts
499128083170	EMG DOOR REAR PANEL	TATA spare parts
499128083190	WINDOW PILLAR SHEET 1	TATA spare parts
499128083191	RH SIDE CENTRE SKIRT PANEL	TATA spare parts
499128083192	RH SIDE REAR SKIRT PANEL	TATA spare parts
499128083193	STRETCH PANEL	TATA spare parts
499128083194	STRETCH PANEL	TATA spare parts
499128083195	RH SKIRT PANEL-6	TATA spare parts
499128083196	LH SKIRT PANEL-07	TATA spare parts
499128083197	RH SIDE SKIRT PANLE-05	TATA spare parts
499128083198	LH SIDE SKIRT PANLE-08	TATA spare parts
499128083199	EMERG DR TUBE PANEL	TATA spare parts
499128083200	EMERG DR TOP PANEL	TATA spare parts
499128083201	LH REAR SKIRT PANEL	TATA spare parts
499128083202	LH SIDE REAR SKIRT PANEL	TATA spare parts
499128083203	RH SIDE REAR SKIRT PANEL	TATA spare parts
499128083204	LH SKIRT PANEL	TATA spare parts
499128083205	LH SKIRT PANEL	TATA spare parts
499128083206	LH SKIRT PANEL	TATA spare parts
499128083207	LH SKIRT PANEL	TATA spare parts
499128083208	RH SIDE REAR SKIRT PANEL	TATA spare parts
499128083209	STRETCH PANEL	TATA spare parts
499128083215	SKIRT PANEL L-PROFILE BS6	TATA spare parts
499128083216	SKIRT PANEL BS6	TATA spare parts
499128083218	SKIRT PANEL L PROFILE BS6	TATA spare parts
499128083219	SKIRT PANEL BS6	TATA spare parts

499128083226	STRETCH PANEL_9M BS6	TATA spare parts
499128083227	STRETCH PANEL_10M BS6	TATA spare parts
499128083228	FRONT DRIVER SIDE EXTERNAL PANEL BS6	TATA spare parts
499128083229	PASS DOOR FRONT EXT PANEL BS6	TATA spare parts
499128083231	DRIVER DR INCHLINCH PROFILE BS6	TATA spare parts
499128083232	DRIVER DR INCHLINCH PROFILE BS6	TATA spare parts
499128083233	DRIVER DR INCHLINCH PROFILE BS6	TATA spare parts
499128083234	DRIVER DR INCHLINCH PROFILE BS6	TATA spare parts
499128083235	DRIVER DR INCHLINCH PROFILE BS6	TATA spare parts
499128083236	EMERG DR INCHLINCH PROFILE BS6	TATA spare parts
499128083237	EMERG DR INCHLINCH PROFILE BS6	TATA spare parts
499128083238	EMERG DR INCHLINCH PROFILE BS6	TATA spare parts
499128083239	RH SIDE CENTRE SKIRT PANEL 02	TATA spare parts
499128083244	LH SIDE RA SKIRT PANEL BS6	TATA spare parts
499128083247	RH SKIRT PANEL-02 BS6	TATA spare parts
499128083251	PASS DOOR FRONT SKIRT PANEL BS6	TATA spare parts
499128083259	RH SIDE RA SKIRT PANEL_62 WB BS6	TATA spare parts
499128083262	EMERG DR INCHLINCH PROFILE-NAC-W/O CUTOU	TATA spare parts
499128083264	LH SKIRT PANEL-2 BS6	TATA spare parts
499128083268	EMERG DR TOP PANEL BS6	TATA spare parts
499128083270	EMERG DOOR PANEL BS6	TATA spare parts
499128083277	DRIVER FOOT STEP PANEL_EXT DOOR BS6	TATA spare parts
499128083278	EXT PANEL_BELOW DR DOOR BS6	TATA spare parts
499128083279	DRIVER DR L PROFILE BS6	TATA spare parts
499128083280	DRIVER DR L PRFL_2 BS6	TATA spare parts
499128083287	RH SIDE CENTRE SKIRT PANEL-02 BS6	TATA spare parts
499128083288	DRVER FOOT STEP PANEL BS6	TATA spare parts
499128083290	LH SKIRT PANEL BS6	TATA spare parts
499128083291	EXT PANEL BELOW DR DOOR BS6	TATA spare parts
499128083299	SKIRT PANEL ABOVE FLAP - 1198 BS6	TATA spare parts
499128083303	SKIRT RAIL PANEL - 1198 BS6	TATA spare parts
499128083311	RH SIDE REAR SKIRT PANEL BS6	TATA spare parts
499128083312	RH SKIRT PANEL BS6	TATA spare parts
499128083313	LH SKIRT PANEL-04 BS6	TATA spare parts
499128083314	LH SKIRT PANEL-05 BS6	TATA spare parts
499128083315	LH SKIRT PANEL- REAR AXLE FRONT BS6	TATA spare parts
499128083316	RH SIDE CENTRE SKIRT PANEL-02 BS6	TATA spare parts
499128083318	RH SIDE RA SKIRT PANEL-57 WB BS6	TATA spare parts
499128083319	WINDOW PILLAR SHEET BS6	TATA spare parts
499128083320	STRETCH PANEL LH SIDE_57 WB BS6	TATA spare parts
499128083321	STRETCH PANEL RH SIDE_57 WB BS6	TATA spare parts
499128083322	SKIRT PANLE	TATA spare parts
499128083323	LH SKIRT PANEL- REAR AXLE FRONT BS6	TATA spare parts
499128083324	LH SKIRT PANEL-05 BS6	TATA spare parts
499128083325	WINDOW PILLAR SHEET-666 BS6	TATA spare parts
499128083326	RH SIDE REAR SKIRT PANEL	TATA spare parts
499128083342	RH SIDE CENTRE SKIRT PANEL-02 BS6	TATA spare parts

499128083343	SKIRT PANEL BS6	TATA spare parts
499128083344	SKIRT PANEL-L PROFILE BS6	TATA spare parts
499128083345	EXT PANEL DOOR BS6	TATA spare parts
499128083350	LH SIDE REAR SKIRT PANEL BS6	TATA spare parts
499128083351	RH SIDE REAR SKIRT PANEL BS6	TATA spare parts
499128083352	DRIVER DOOR TOP PANEL BS6	TATA spare parts
499128083353	FOOTSTEP SUPPORT L ANGLE BS6	TATA spare parts
499128083354	LH SKIRT PANEL BS6	TATA spare parts
499128083356	RH SKIRT PANEL-02 BS6	TATA spare parts
499128083357	RH SIDE CENTRE SKIRT PANEL-02 BS6	TATA spare parts
499129003001	INSPECTION COVER ASSEMBLY DETAIL	TATA spare parts
499142003003	PANEL PLATE ASSEMBLY_IDEALE 1515	TATA spare parts
499142003004	PANEL PLATE ASSY_IDEALE_LHD	TATA spare parts
499142003010	PANEL PLATE BS6_MARQ	TATA spare parts
499142003012	PANEL PLATE ASSEMBLY BS6 NAC BS6	TATA spare parts
499142362003	PIGTAIL HARNESS FOR AIS140 EMERGENCY SW	TATA spare parts
499142363002	DASHBOARD ELECTRIC HARNESS	TATA spare parts
499142363003	UPPER FRONT HARNESS	TATA spare parts
499142363004	SIDE MARKER & EMERGENCY DOOR HARNESS	TATA spare parts
499142363005	HEAD LAMP WIRING HARNESS	TATA spare parts
499142363006	RH TAIL LAMP HARNESS	TATA spare parts
499142363007	LH TAIL LAMP HARNESS	TATA spare parts
499142363008	POWER FEED ELECTRIC HARNESS	TATA spare parts
499142363009	EMERGENCY DOOR ELECTRIC HARNESS	TATA spare parts
499142363011	ROOF HARNESS RH	TATA spare parts
499142363014	PA SYSTEM & AMP SPEAKERS BS6	TATA spare parts
499142363015	PA SYSTEM & AMP MONITOR POWER SUPPLY BS6	TATA spare parts
499142363018	EMEGY DECLARATION& HARNESS	TATA spare parts
499142363019	SLB LAMP WIRING HARNESS	TATA spare parts
499142363020	WIPER MOTOR PIGTAIL HARNESS	TATA spare parts
499142363022	INTERNAL LAMP HARNESS_LHD	TATA spare parts
499142363024	AIS140 EMERGENCY SW HARNESS 55WB	TATA spare parts
499142363025	FRONT DOOR OPENED INDICATION HARNESS	TATA spare parts
499142363026	SIDE MARKER & EMERGENCY DOOR HARNESS	TATA spare parts
499142363028	POWER SUPPLY HARNESS FOR WIFI	TATA spare parts
499142363029	PA SYSTEM & SPEAKERS HARNESS	TATA spare parts
499142363033	DESTINATION BOARD SUPPLY HARNESS_IDEALE	TATA spare parts
499142363039	MOBILE CHARGER HARNESS USB CDS	TATA spare parts
499142363040	MOBILE CHARGER HARNESS USB DS	TATA spare parts
499142363044	RLB SIDE FLAMP HARNESS-IDEALE	TATA spare parts
499142363045	SPEAKER HARNESS IDEALE LHD	TATA spare parts
499142363047	PIGATIL HARNESS FOR DEST. BOARD	TATA spare parts
499142363050	PIGTAIL HARNESS FOR INTERNAL LAMP_ BS6	TATA spare parts
499142363053	DOOR ELECTRIC HARNESS_MANUAL BS6	TATA spare parts
499142363057	MOBILE CHARGER HARNESS USB TYPE BS6	TATA spare parts
499142363058	PASSENGER MOBILE CHARGER HARNESS 11 NOS	TATA spare parts
499142363059	POWER SUPPLY FOR MOBILE CHARGER USB BS6	TATA spare parts

499142363062	UPPER FRONT HARNESS_BS6_IDEALE BS6	TATA spare parts
499142363063	DASH BOARD HARNESS_BS6 BS6	TATA spare parts
499142363064	AMPLIFIER SPEAKER DVD & MONITOR HARNESS	TATA spare parts
499142363065	INTERNAL ILLUMINATION HARNESS BS6	TATA spare parts
499142363068	ROOF SPEAKER HARNESS 06 NOS BS6	TATA spare parts
499142363069	MONITOR TO SPEAKER HARNESS WITH 06 SPKR	TATA spare parts
499142363070	PIGTAIL MAINTENANCE LAMP & SLB RLB BS6	TATA spare parts
499142363079	SPEAKER W/H FOR PA SYSTEM	TATA spare parts
499145003021	REAR DEST. BOARD SUPPORT TUBE ASSY BS6	TATA spare parts
499145003022	REAR DEST. BOARD BOTTOM TUBE ASSY BS6	TATA spare parts
499145003042	LH SIDE PARTITION_RHD	TATA spare parts
499145003044	RH SIDE PARTITION_RHD	TATA spare parts
499145013003	FRONT STABILIZER TUBE BOTTOM	TATA spare parts
499145083009	FRONT STABILIZER GUSSET	TATA spare parts
499145083010	FRONT STABILIZER GUSSET FRONT	TATA spare parts
499145083011	STABILIZER TUBE SUPPORT GUSSET LH	TATA spare parts
499150003017	AC DUCT WITH HATRACK ASSY-LH	TATA spare parts
499150003018	AC DUCT WITH HATRACK ASSY-RH	TATA spare parts
499150003062	SMARTLINE AC DUCT WITH HATRACK ASSY-LH	TATA spare parts
499150003063	SMARTLINE AC DUCT WITH HATRACK ASSY-RH	TATA spare parts
499150003067	SMARTLINE AC DUCT WITH HATRACK ASSY-LH B	TATA spare parts
499150003068	SMARTLINE AC DUCT WITH HATRACK ASSY-RH B	TATA spare parts
499150003077	PARTITION DUCT ASSY-TWO VENT BS6	TATA spare parts
499150003080	AC DUCT WITH HATRACK ASSY-LH BS6	TATA spare parts
499150003081	AC DUCT WITH HATRACK ASSY-RH BS6	TATA spare parts
499150084009	END COVER SUPPORT BRACKET TYPE 2 BS6	TATA spare parts
499150084010	LUGGAGE -SUPPORT PLATE	TATA spare parts
499150084017	SINGLE HOLE PLATE WASHER BS6	TATA spare parts
499150962008	AC UNIT-CC 355 -62WB BS6	TATA spare parts
499151003006	PASSENGER DOOR PARTISION ASSY	TATA spare parts
499151003007	PASS DR PARTITION TUBE ASSY	TATA spare parts
499151004001	PASS DR PARTITION TUBE ASSY_02	TATA spare parts
499151063003	HANDHOLD TUBE IDEALE RHD	TATA spare parts
499151063004	HANDHOLD TUBE_IDEALE_RHD	TATA spare parts
499151063005	HANDHOLD MIDDLE TUBE IDEALE	TATA spare parts
499151063006	HANDHOLD TUBE IDEALE RHD-02	TATA spare parts
499151063007	HANDHOLD MIDDLE TUBE_IDEALE BS6	TATA spare parts
499152003003	IDEALE_FRONT INNER ASSLY	TATA spare parts
499152003005	DASH BOARD ASSLY IDEALE	TATA spare parts
499152003006	ENGINE HOOD ASSY IDEALE	TATA spare parts
499152003007	DASHBOARD AND ENGINE HOOD ASSLY_IDEALE	TATA spare parts
499152003008	ENGINEHOOD_ASSY_LHD_SIDE	TATA spare parts
499152003009	LHD_DASHBOARD ASSLY_IDEALE	TATA spare parts
499152003010	DASHBOARD & ENG HOOD ASSLY_LHD_IDEALE	TATA spare parts
499152003011	FRONT INNER ASSLY_IDEALE_AC_LHD	TATA spare parts
499152003015	FRT INNER ASSY_IDEALE(WITH HATCH CUTOUT)	TATA spare parts
499152003024	FUSE BOX FLAP ASSLY_IDEALE_BSVI BS6	TATA spare parts

499152003027	FRONT INNER ASSLY_IDEALE_AC_RHD_AIS153 B	TATA spare parts
499152003033	BS6_DASHBOARD & ENGINE HOOD ASSY BS6	TATA spare parts
499152003034	DASHBOARD & ENGINGOOD ASSY_1845 BS6	TATA spare parts
499152004006	FLAP ASSEMBLY IDEALE	TATA spare parts
499152004007	FLAP ASSLY_LHD_IDEALE	TATA spare parts
499152004014	FLAP ASSLY_IDEALE_LPO BS6	TATA spare parts
499152004024	DASHBOARD INSULATION ASSY_1845 BS6	TATA spare parts
499152263011	FUSE BOX COVER_DRIVER SIDE BS6	TATA spare parts
499152323001	A-PILLAR COVER_LH_IDEALE	TATA spare parts
499152323002	A-PILLAR COVER_RH_IDEALE	TATA spare parts
499152324001	REAR INNER_IDEALE	TATA spare parts
499152324008	ABS DRIVER DOOR BOTTLE HOLDER BS6	TATA spare parts
499153003007	LUGGAGE RACK SUPPORT ASSY.	TATA spare parts
499153003009	MODULAR HATRACK 39 PB	TATA spare parts
499153003015	MODULAR HATRACK ASSY-WOODS GREY FABRIC	TATA spare parts
499153003022	TUBULAR HATRACK ASSY LH & RHç 57 WB	TATA spare parts
499153324001	HATRACK END COVER-RH	TATA spare parts
499153324002	HATRACK END COVER-LH	TATA spare parts
499157083021	ROOF INTERNAL PANEL	TATA spare parts
4991571	LINER CYLINDER COLLERED	TATA spare parts
499158903001	T EMBLEM TML LOGO HEXA	TATA spare parts
499159003001	PARTITION ASSLY-01_IDEALE	TATA spare parts
499159003002	PARTITION ASSLY-02_IDEALE	TATA spare parts
499159324005	PARTISION COVER_RH-02	TATA spare parts
499159324006	PARTISION COVER_RH-01	TATA spare parts
499159324008	STEPWELL PARTITION_01_IDEALE	TATA spare parts
499159324009	STEPWELL PARTITION_02_IDEALE	TATA spare parts
499159333001	EMERGENCY DOOR EXIT STICKER	TATA spare parts
499160003001	ORVM ASSY TOP MOUNTED (RHD) RH-235	TATA spare parts
499160003004	FRONT PROXIMITY MIRROR ASSY (R-200)	TATA spare parts
499160003005	ASSY ORVM MIRROR LH WITH AUXILARY	TATA spare parts
499160003006	DOOR MOUNTED RH ORVM	TATA spare parts
499160003007	MOTORIZED RVM LH SIDE	TATA spare parts
499160003008	MOTORIZED RVM RH SIDE	TATA spare parts
499160064001	CLASS VI RVM ARM BS6	TATA spare parts
499161002017	MECH SUSPENDED DRIVER SEAT 55WB RHD	TATA spare parts
499161003005	2LH SM1L 480C1200W NHBT2 CVG	TATA spare parts
499161003022	3RH SM2L 480C1200W NHBT2_FB_RX_CVG	TATA spare parts
499161003023	3RH SM2L 480C1200W LB NHBT2_FB_RX_CVG	TATA spare parts
499161003024	3RR 3LM 480C1200W NHBT2_FB_RX_CVG	TATA spare parts
499161003025	3RL SM2L 480C1200W LB NHBT2_FB_RX_CVG	TATA spare parts
499161003026	2LH SM1L 480C1200W LB NHBT2_FB_RX_CVG	TATA spare parts
499161003038	2LH SM1L 480C850W NHB2 GRAY FB VN CVG	TATA spare parts
499161003043	5RL/RL4LM 475C1025W AR 3PLB BLFB PB	TATA spare parts
499161003044	2LH 2LM 475C1025W AR 3PLB BLFB PB	TATA spare parts
499161003072	5REAR 4LM 475C2400W 3PLB BLFB PB	TATA spare parts
499161003073	1RH 2LM 475C530W 3PLB BLFB PB	TATA spare parts

499161003090	2LM 480C410W AR LP NHB2 FB RX CVG BS6	TATA spare parts
499161003091	2LH SM1L 480C850W LP NHB2 FB RX CVG	TATA spare parts
499161003123	3RH SM2L 480C1200W NHBT2_FB_RX_USB CVG BS6	TATA spare parts
499161003124	3RH SM2L 480C1200W LB NHBT2_FBRX_USBCVG	TATA spare parts
499161003125	3RR 3LM 480C1200W NHBT2_FB_RX_USB CVG BS6	TATA spare parts
499161003126	3RL SM2L 480C1200W LB NHBT2_FBRX_USBCVG	TATA spare parts
499161003127	2LH SM1L 480C850W NHB2 FBVN USB CVG BS6	TATA spare parts
499161003128	2LH SM1L 480C1200W LB NHBT2_FBRX_USBCVG	TATA spare parts
499161003154	1LH SM1L 480C410W AR FB_RX_USB NHBT2 CVG	TATA spare parts
499161003155	3RH SM2L 480C1200W NHBT2_LB_USB_CVG	TATA spare parts
499161003156	3RH SM2L 480C1200W NHBT2_USB_M_PO_CVG	TATA spare parts
499161003159	2LH SM1L 480C850W NHBT2_USB_CVG	TATA spare parts
499161003160	2LH SM1L 480C850W NHBT2_LB_USB_CVG	TATA spare parts
499161003169	2LH SM1L 480C850W 1LB NHBT2 USB CVG BS6	TATA spare parts
499161003170	1LH SM1L 480C410W AR NHBT2 USB CVG BS6	TATA spare parts
499161003178	5R_LM_475C2400W_ARLB_FB89167_USB_PB_HS	TATA spare parts
499162003001	ROOF HATCH HINGE	TATA spare parts
499162003002	MECHANISM & TOP LEAD ASSY	TATA spare parts
499162004012	ROOF HINGE OPENABLE	TATA spare parts
499162004013	ROOF HINGE FIX	TATA spare parts
499162004014	LHS SENSOR KIT FDAS GREEN FUEL BS6	TATA spare parts
499162004017	HARNESS KIT FDAS GREEN FUEL BS6	TATA spare parts
499162264001	ROOF HATCH TOP COUNTER APP 420X405 BS6	TATA spare parts
499162964001	FDAS_GREEN FUEL_24V_PANELING-KIT_IDEALE	TATA spare parts
499163003002	FRNT DESTN BRD SPRT AYYS-RH BS6	TATA spare parts
499164003001	WINDOW_942	TATA spare parts
499164003002	WINDOW_IDEALE_1295	TATA spare parts
499164003003	EMERGENCY WIDOW	TATA spare parts
499164003005	DVR_WINDOW_IDEALE	TATA spare parts
499164003006	WINDOW ASSEMBLY_IDEALE	TATA spare parts
499164003007	SCOOP WINDOW RH 97X257X581MM	TATA spare parts
499164003008	PEEP WINDOW LH RH	TATA spare parts
499164003011	RH WINDOW_1293X980_30%GRN	TATA spare parts
499164003012	"WIND_T1/3F,B2/3S_RH 941X980MM_30%GRN"	TATA spare parts
499164003013	EMER. WIND_RH_595X654_30%GRN	TATA spare parts
499164003014	LH_T1/3F B2/3S_1293X977_30%GRN	TATA spare parts
499164003015	"WIND_T1/3F,B2/3S_LH 941X980MM_30%GRN"	TATA spare parts
499164003016	"WIND_T1/3F,B2/3S_LH 777X977_30%GRN"	TATA spare parts
499164003019	DRIVER DOOR WINDOW LH SIDE 664X678	TATA spare parts
499164003020	WINDOW LH 941X980MM	TATA spare parts
499164003021	WINDOW LH 777X980MM	TATA spare parts
499164003029	RH EMERGENCY DOOR WINDOW 595X765	TATA spare parts
499164003031	WINDOW LH 845X980 CLEAR GLASS	TATA spare parts
499164003032	PASTED GLASS+VENT WINASSY_1350X1072 50PE	TATA spare parts
499164003036	LH SIDE PASSANGER DOOR WINDOW ASSY	TATA spare parts
499164003039	FIXED WINDOW RH 295X980_CLEAR BS6	TATA spare parts
499164003040	WINDOW RH 1175X977MM BS6	TATA spare parts



499164003041	WINDOW LH 659X977MM_CLEAR GLASS BS6	TATA spare parts
499164003043	RH_EMERGENCY_DR_595X765_50PERC GRAY_T	TATA spare parts
499164004013	VENTILATION WINDOW ASSY_PASTED GLASS	TATA spare parts
499164083001	RH_GI PLATE_1.55THK_172X138_BLACK P.	TATA spare parts
499164083002	LH_GI PLATE_1.55THK_170X129_BLACK P.	TATA spare parts
499164083003	RH_G.I SHEET_1.55MM THICK	TATA spare parts
499164083004	LH_G.I SHEET_1.5MM THICK	TATA spare parts
499164233007	PASTED GLASS 790X568_CLR BS6	TATA spare parts
499164233008	PASTED GLASS 410X1072_CLR BS6	TATA spare parts
499164233014	LH PASTED GLS_708X306_CLR	TATA spare parts
499164233015	LH PASTED GLS_464X753_CLR	TATA spare parts
499164233016	RH PASTED GLS_1200X494_CLR	TATA spare parts
499164233017	RH_PASTED GLASS_425X565_CLR	TATA spare parts
499164233020	WINDOW PASTED GLASS BS6	TATA spare parts
499164233022	PASTED WINDOW GLASS BS6	TATA spare parts
499164233025	WINDOW PASTED GLASS BS6	TATA spare parts
499164233026	WINDOW PASTED GLASS BS6	TATA spare parts
499164233029	WINDOW GLASS PASTED BS6	TATA spare parts
499164233032	LH_PASTED GLASS_803X306 BS6	TATA spare parts
499164233033	LH_PASTED GLASS 486X1058 BS6	TATA spare parts
499164233034	LH_PASTED GLASS_1202X494 BS6	TATA spare parts
499164233035	LH PASTED WINDOW GLASS_1349X1072 BS6	TATA spare parts
499164233036	LH PASTED WINDOW GLASS_685X828 BS6	TATA spare parts
499164233037	LH PASTED WINDOW GLASS_807X231 BS6	TATA spare parts
499164233038	PASTED WINDOW GLASS_102X833 BS6	TATA spare parts
499164233039	RH PASTED WIND GLASS_1500X1072 50PERCGRE	TATA spare parts
499164233040	RH PASTED WIN GLAS_1300X1072 50PERCGREE	TATA spare parts
499164233041	PASTED WINDOW GLASS_1300X1093 50PERCGRE	TATA spare parts
499164233042	PASTED WINDOW GLASS 1280X1072 50PERCGRE	TATA spare parts
499164233043	PASTED WINDOW GLASS 877X1072 50PERCGREE	TATA spare parts
499164233044	RH PASTED WIN GLAS 1350X1072 50PERCGREEN	TATA spare parts
499164233045	RH PASTED WIN GLAS 1410X1072 50PERCGREEN	TATA spare parts
499164233046	RH PAST WIN GLASS_685X848_50PERCGREEN T	TATA spare parts
499164233047	RH PAST WIND GLASS_1073X425_50PERCGREEN	TATA spare parts
499164233048	RH PAST WIN GLASS_1073X481_CLEAR	TATA spare parts
499164233049	RH_PASTED GLASS_820X292_CLEAR	TATA spare parts
499164233050	RH PAST WIN GLASS_717X481_CLEAR	TATA spare parts
499164233051	LH PAST WIN GLASS_1226X1073_50PERCGREEN T	TATA spare parts
499164233053	LH_PASTED GLASS_845X389 CLEAR	TATA spare parts
499164233054	LH PAST WIN GLASS 954X504_CLEAR	TATA spare parts
499164233055	RH PAST WIN GLASS_859X88_CLEAR	TATA spare parts
499164233056	RH PAST WIN GLASS_788X209_CLEAR	TATA spare parts
499164233057	LH PAST WIN GLASS_666X620_CLEAR	TATA spare parts
499164233059	PASTED GLS_LH_877X1072_50PERCGRN	TATA spare parts
499164233060	RH PASTED GLS_947X1072_30%GRN TINT BS6	TATA spare parts
499164234007	DVR WINDOW GLASS	TATA spare parts
499164234008	DVR WINDOW GLASS	TATA spare parts

499164234009	WINDOW GLASS IDEALE	TATA spare parts
499164234010	WINDOW GLASS	TATA spare parts
499164234011	WINDOW GLASS	TATA spare parts
499164234013	OPENABLE WINDOW GLASS	TATA spare parts
499164234014	PEEP VENTILATION WINDOW GLASSES	TATA spare parts
499164234015	PEEP VENTILATION WINDOW GLASSES	TATA spare parts
499164234043	LH/RH PASTED WINDOW GLASS _1350X1072 BS6	TATA spare parts
499164234053	EMERGENCY DOOR WINDOW GLASS 298X741	TATA spare parts
499164234054	EMERGENCY DOOR WINDOW GLASS 298X741	TATA spare parts
499164234056	EXTERNAL GLASS	TATA spare parts
499164234057	INTERNAL GLASS	TATA spare parts
499164234058	TOP FIXED GLASS	TATA spare parts
499164234059	LH/RH SIDE PASTED WIN GLAS _1350X1072 50P	TATA spare parts
499164234061	PASSANGER DOOR PASTED GLASS 861X666)	TATA spare parts
499164234067	FRNT EXT GLS_RH_596X619_CLEAR GLS BS6	TATA spare parts
499164234068	REAR INT GLASS RH BS6	TATA spare parts
499164234069	TOP FIXED GLASS_RH_1150X322_CLEAR GLS BS	TATA spare parts
499164234070	FRONT EXT GLS_LH_338X619_CLEAR GLS BS6	TATA spare parts
499164234071	RR INT GLS_LH_338X619_CLEAR GLS BS6	TATA spare parts
499164234072	TOP FIXED GLASS_634X322_CLEAR GLS BS6	TATA spare parts
499165003006	WIPER LINKAGE ASSY LHD	TATA spare parts
499165003007	WIPER ARM ASSY LH	TATA spare parts
499165003008	WIPER ARM ASSY RH	TATA spare parts
499165003009	WIPER BLADE ASSY	TATA spare parts
499165003010	WIPER LINKAGE ASSY-RHD	TATA spare parts
499165003018	WIPER BLADE ASSY	TATA spare parts
499165003019	WIPER MOTOR 24VDC-150W-MOTOR 259	TATA spare parts
499165003020	WIPER ARM ASSY DRIVER SIDE	TATA spare parts
499165003021	WIPER ARM ASSY CO-DRIVER SIDE	TATA spare parts
499165003022	WIPER LINKAGE ASSY-RHD BS6	TATA spare parts
499165004007	SHAFT ASSY LEN 187.6 BS6	TATA spare parts
499165234001	FRONT WINDSHIELD_RUBBER MOUNTED	TATA spare parts
499165234002	IDEALE_REAR WINDSHIELD_RUBBER MOUNTED	TATA spare parts
499165284001	FRONT WINDSHIELD RUBBER_IDEALE	TATA spare parts
499165284002	REAR WINDSHIELD RUBBER_IDEALE	TATA spare parts
499165284005	REAR W/S RUBBER_IDEALE	TATA spare parts
499165912010	WIPER ASSY_RHD-24V_DOGA_IDEALE	TATA spare parts
4992795	HOSE FLEXIBLE	TATA spare parts
4993343	ALTERNATOR	TATA spare parts
4993966	BRACKET ETR CNT MODULE	TATA spare parts
4994678	FAN ENGINE	TATA spare parts
4994705	FAN ENGINE	TATA spare parts
4994706	CLUTCH FAN	TATA spare parts
4994934	BUSHING	TATA spare parts
4994952	TUBE FUEL SUPPLY	TATA spare parts
4995138	FLYWHEEL	TATA spare parts
4995594	ALTERNATOR (12V 40AMPS. 2GRV.PULLEY)	TATA spare parts

4995602	SCREW HEX FLANGE HEAD CAP	TATA spare parts
500331200104	ASSY CROSS MBR END	TATA spare parts
500331200106	ASSY CROSS MBR C	TATA spare parts
500331207101	ASSY CROSS MBR END	TATA spare parts
500331207103	CROSS MEMBER C 7TH	TATA spare parts
500331307103	GUSSET FOR 7TH CROSS MEMBER	TATA spare parts
500331307105	GUSSET 1ST FORç CM ASSY END	TATA spare parts
500331307106	GUSSET 2ND FORç CM ASSY END	TATA spare parts
500331307109	GUSSET	TATA spare parts
500331307111	ENG.MTG. FRT.C/M BKT.-LH	TATA spare parts
500331307112	ENG.MTG. FRT. C/M BKT.-RH	TATA spare parts
500348207801	UREA TANK DRAIN PLUG GASKET	TATA spare parts
500349100110	ASSEMBLY DECOMP TUBE WITH NOZZLE SEAT	TATA spare parts
500349100127	BRACKET ASSEMBLY-LH FOR UREA TANK MTG-30	TATA spare parts
500349100128	BRACKET ASSEMBLY - RH FOR UREA TANK MTG-	TATA spare parts
500349100129	UREA TANK ASSY 30L	TATA spare parts
500349100130	STRAP ASSY FOR UREA TANK-30L	TATA spare parts
500349100131	ASSEMBLY ADBLUE RETURN LINE DOSING PUMP	TATA spare parts
500349100132	ADBLUE SUPPLY LINE UREA TANK-30L TO DOSI	TATA spare parts
500349100134	PLASTIC CAP FOR UREA TANK WITH LOCK	TATA spare parts
500349100135	WEMA SENSOR FOR 30L UREA TANK	TATA spare parts
500349100138	ADBLUE QUALITY SENSOR	TATA spare parts
500349100147	ASSY UQS SHIELD AND BASE PLATE	TATA spare parts
500349100149	SRRAP ASSY	TATA spare parts
500349100152	LEVEL SENSOR CES LCCR BS4	TATA spare parts
500349100162	BRACKET ASSY-1 FOR CES TANK MTG-35L	TATA spare parts
500349100163	BRACKET ASSY-2 FOR CES TANK MTG-35L	TATA spare parts
500349100164	CES AUS32 TANK ASSY(35L) FOR LCCR BSIV	TATA spare parts
500349100165	TANK ASSEMBLY CES 35L TANK WITH LEVEL SE	TATA spare parts
500349106305	BREATHER ASSY	TATA spare parts
500349107201	DRAIN PLUG	TATA spare parts
500349108207	CLAMP FOR THIRD PIPE	TATA spare parts
500349108208	CLAMP FOR THIRD PIPE	TATA spare parts
500349206304	UREA TANK WASHER	TATA spare parts
500349206307	GROMET FOR UREA TANK STRAP MTG BKT	TATA spare parts
500349206701	CLEVIS PIN	TATA spare parts
500349207701	RUBBER PACKING BASE OF UREA TANK-30L	TATA spare parts
500349207702	RUBBER PACKING FOR TOP STRAP	TATA spare parts
500349207703	RUBBER PACKING OF CES AUS 32 TANK	TATA spare parts
500349207704	RUBBER PACKING TOP OF CES AUS 32 TANK	TATA spare parts
500349207705	RUBBER PACKING BASE OF CES AUS 32 TANK	TATA spare parts
500349207801	AUS TANK DRAIN PLUG GASKET	TATA spare parts
500349208212	BRACKET AIR OIL SEPRATOR	TATA spare parts
500349208217	STRAP MOUNTING BKT UREA TANK	TATA spare parts
500349208220	CLAMP FOR THIRD PIPE	TATA spare parts
500349208229	UREA TANK BASE BKT-30L	TATA spare parts
500349208231	UREA TANK SIDE SHIELD-30L	TATA spare parts

500349208252	CES AUS 32 TANK FRONT STRAP-35L	TATA spare parts
500349208253	CES AUS 32 TANK BASE BKT-35L	TATA spare parts
500349208254	BRACKET CES AUS 32 TANK BACK SUPPORT	TATA spare parts
500349208255	CES AUS 32 TANK TOP STRAP-35L	TATA spare parts
500400990101	KIT FULLY TRIMMED CABIN FOR PRIMA 2538.K	TATA spare parts
500426010104	GS ASSY WITH CABLE	TATA spare parts
500426808201	Z CLAMP	TATA spare parts
500426808202	L-BRACKET	TATA spare parts
500426900102	HOSE ASSY OIL COOLER OUTLET	TATA spare parts
500426900103	HOSE ASSY OIL COOLER INTAKE	TATA spare parts
500426900105	ASSLY HOSE OUTLET	TATA spare parts
500426900106	ASSY HOSE INLET	TATA spare parts
500429300101	ASSY. CLUTCH BOOSTER (TYPE-2)	TATA spare parts
500431000104	ASSY FRAME 2538.K LHD-45WB	TATA spare parts
500431000105	FRAME ASSY COMPLETE	TATA spare parts
500431000107	FRAME ASSY	TATA spare parts
500431200102	ASSY FIRST CROSS MEMBER COMPLETE	TATA spare parts
500431200104	ASM ALLIGATED CROSS MEMBER	TATA spare parts
500431200111	CROSS MEMBER ASSY PROPELLER SHAFT	TATA spare parts
500431307105	GUSSET FOR ALLIGATED CROSS MEMBER LWR	TATA spare parts
500431307106	GUSSET FOR ALLIGATED CROSS MEMBER UPR	TATA spare parts
500431700121	FUPD ASSY CROSS BEAM	TATA spare parts
500431700126	BRACKET ASSY FUPD MTG RH	TATA spare parts
500431700127	BRACKET ASSY FUPD MTG LH	TATA spare parts
500431707105	REINFORCEMENT FUPD RH	TATA spare parts
500431707106	REINFORCEMENT FUPD LH	TATA spare parts
500431708201	BRACKET FOR NOISE SHIELD-LHD	TATA spare parts
500432103202	CENTER BOLT M16X1.5X185	TATA spare parts
500432103203	CENTER BOLT M16X1.5X165	TATA spare parts
500432104201	SPRING CLIP	TATA spare parts
500432106501	HEX.NUT M10X1.5(SELF LOCKING TYPE)	TATA spare parts
500432106503	HEX NUT M16X1.5(SELF LOCKING TYPE)	TATA spare parts
500432106504	HEX NUT M12X1.5(SELF LOCKING TYPE)	TATA spare parts
500432107116	SPRING SPACER	TATA spare parts
500432107117	SPRINGSPACER	TATA spare parts
500432107118	CASTER PLATE	TATA spare parts
500432107119	SPRING SPACER	TATA spare parts
500432108602	CENTER LINER	TATA spare parts
500432108603	SPECER TUBE	TATA spare parts
500432108604	CENTER LINER	TATA spare parts
500441100104	ASSY PROP SHAFT FRONT 2538 ISLE-4570	TATA spare parts
500441100106	ASSY PROPELLER MAIN SHAFT	TATA spare parts
500441107101	GAURD-P/SHAFT	TATA spare parts
500441107102	GUARD P/SHAFT	TATA spare parts
500443900130	PIPE ASSY BUNCH COMPLETE	TATA spare parts
500443900136	PIPE BUNCH ASSEMBLY COMPLETE	TATA spare parts
500443900173	PIPE METAL PIPE CONNECTOR TO COMPRESSOR	TATA spare parts

500443900252	ASSY. METAL PIPE COMPRESSOR END	TATA spare parts
500443910147	BUNCH ASSY PIPE	TATA spare parts
500443910151	METAL PIPE ASSY WITH CRIMPED TEFLON HOSE	TATA spare parts
500443920106	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
500443920107	METAL PIPE ASSY JOINT 1 TO JOINT 2	TATA spare parts
500443920108	METAL PIPE ASSY	TATA spare parts
500443930215	PIPE BUNCH ASSY	TATA spare parts
500446305101	PITMAN ARM	TATA spare parts
500446603301	STEERING RESERVOIR MTG. BRKT. FOR ISLE	TATA spare parts
500446800107	PRESSURE LINE ASM.PUMP END TYPE II	TATA spare parts
500446800108	RETURN LINE ASSY. AT RES. END TYPE-II	TATA spare parts
500446800109	SUCTION LINE ASM TYPE-II	TATA spare parts
500446800111	SUCTION PIPE LINE	TATA spare parts
500446800112	ASSY PRESSURE LINE & HOSES	TATA spare parts
500446800115	ASSY RETURN LINE AT STG GB END	TATA spare parts
500446800120	PRESSURE LINE ASSY GEAR BOX END	TATA spare parts
500446800121	PRESSURE LINE ASSY PUMP END TYPE II	TATA spare parts
500447600104	SUCTION PIPE ASSY FILTER TO FIP	TATA spare parts
500447600105	RETURN PIPE ASSY	TATA spare parts
500447600106	ASSY FUEL RETURN LINE ENGINE TO FUEL TAN	TATA spare parts
500447600109	ASSY SUCTION LINE F/TANK TO W/S	TATA spare parts
500447600110	ASSY SUCTION LINE W/S TO ENGINE	TATA spare parts
500447600119	SUCTION LINE ASSY (TANK TO FILTER)	TATA spare parts
500447600120	RETURN LINE ASSY ON TANK (FROM ENGINE)	TATA spare parts
500447600124	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
500447608201	BRACKET (FUEL LINE CLAMPING)	TATA spare parts
500447700101	HEAD & FUEL WATER SEPARATOR & HEATER	TATA spare parts
500447700101AE	Hd & Fuel Wat Sep & Heater 2523	TATA spare parts
500447700103	HEATER & HEAD ASSY	TATA spare parts
500458900101	ASSY SADDLE LOCKING CLIP	TATA spare parts
500458906001	SADDLE FOR JACK	TATA spare parts
500529300101	ASSY. CLUTCH BOOSTER (TYPE-2)	TATA spare parts
500530100101	ASSY ACCELERATOR PEDAL UNIT -RHD	TATA spare parts
500531107107	REINFORCEMENT-LH	TATA spare parts
500531107108	REINFORCEMENT RH	TATA spare parts
500540000102	ASSY.WHEEL RIM WITH VALVE	TATA spare parts
500541107102	BRACKET (P/SHAFT GUARD)	TATA spare parts
500546803303	BRACKET PIPE SUPPORT BS6	TATA spare parts
500600990101	KIT FULLY TRIMMED CABIN FOR PRIMA 3338.K	TATA spare parts
500624100102	FRONT RUBBER MOUNT ASM	TATA spare parts
500624103704	ENG MTG BRKT FRT FRAME LH	TATA spare parts
500624103706	ENG MTG BRKT FRT FRAME RH	TATA spare parts
500624203701	ENG MTG BRKT REAR FRAME	TATA spare parts
500624203702	ENG MTG BRKT REAR FRAME	TATA spare parts
500626800101	HORIZONTAL GEAR SHIFT UNIT ASSY	TATA spare parts
500626800102	ASSY AIR PIPING COMP FOR GEARBOX	TATA spare parts
500626800103	ASSY GEARSHIFT UNIT WITH CABLES	TATA spare parts

500626806901	NYLON PIPE 8 OD (SOL VALVE TO PR.REGULAT	TATA spare parts
500626806902	NYLON PIPE 8 OD( TRNT TO IAS)	TATA spare parts
500626806903	PNEUMATIC PIPE (TRN TO TO SOL.VALVE)	TATA spare parts
500626806904	PNEUMATIC PIPE ( SOL.VALVE TO PR.REG.)	TATA spare parts
500626808201	CABLE CLAMP	TATA spare parts
500626808201AE	CABLE CLAMPING BKT 1628	TATA spare parts
500626808202	CABLE CLAMP	TATA spare parts
500626808203	DOUBLE CLAMP	TATA spare parts
500626808204	CLAMP 50 DIA	TATA spare parts
500626808205	Z-BRACKET	TATA spare parts
500626808206	CLAMP FOR CABLE	TATA spare parts
500626808207	L-BRACKET	TATA spare parts
500626808208	Z BRACKET	TATA spare parts
500626808209	BKT FOR HOSE MOUNTING	TATA spare parts
500626900111	ASSY OIL COOLER HOSE(INLET)	TATA spare parts
500626900112	ASSY HOSE OIL COOLER (OUTLET)	TATA spare parts
500626900113	ASSY OIL COOLER HOSE(INLET)	TATA spare parts
500626900114	ASSY HOSE OIL COOLER (OUTLET)	TATA spare parts
500629000101	ASSY. INTEGRATED PEDAL UNIT	TATA spare parts
500629000107	ASSY INTERGRATED PEDAL UNIT	TATA spare parts
500629000108	ASSY. CLUTCH BOOSTER (TYPE-1)	TATA spare parts
500629000112	INTEGRATED PEDAL UNIT	TATA spare parts
500629100101	CLUTCH PEDAL ASSEMBLY	TATA spare parts
500629100103	CLUTCH SWITCH	TATA spare parts
500629100106	ASSY PNEUMATIC PIPE FOR CLUTCH BOOSTER	TATA spare parts
500629107501	LOWER STOPPER	TATA spare parts
500629108701	EXTENSION SPRING	TATA spare parts
500629200101	BRAKE PEDAL ASSEMBLY	TATA spare parts
500629300101	ASSY. CLUTCH BOOSTER (TYPE-1)	TATA spare parts
500629300102	ASSY. CLUTCH MASTER CYLINDER BS3/4	TATA spare parts
500629503301	BRACKET-TOP	TATA spare parts
500629503302	BRACKET-BOTTOM	TATA spare parts
500629990101	MAJOR KIT ASSY. IPU (TYPE-1)	TATA spare parts
500629990102	MINOR KIT ASSY. IPU (TYPE-1)	TATA spare parts
500629990103	SPARE KIT CLUTCH BOOSTER (TYPE-1)	TATA spare parts
500629990104	SPARE KIT CMC(TYPE-1)	TATA spare parts
500631000103	ASSEMBLY FRAME	TATA spare parts
500631000106	FRAME ASSY	TATA spare parts
500631000107	FRAME ASSEMBLY	TATA spare parts
500631200102	ASSY CROSS MBR 4TH	TATA spare parts
500631200103	ASSY CROSS MEMBER 1ST	TATA spare parts
500631200104	ASSY END CROSS MBR	TATA spare parts
500631200105	ASSEMBLY CROSS MEMBER CTR	TATA spare parts
500631207101	CROSS MBR 4TH	TATA spare parts
500631207102	CROSS MBR -END	TATA spare parts
500631207103	CROSS MBR FIRST	TATA spare parts
500631207104	ALLIGATED CROSS MEMBER LOWER	TATA spare parts

500631207105	CROSS MEMBER CTR	TATA spare parts
500631307103	GUSSET FOR 4 CROSS MBR 4TH	TATA spare parts
500631307105	GUSSET LWR FOR 4TH CROSS MBR	TATA spare parts
500631307115	GUSSET IST FOR END CM	TATA spare parts
500631307116	GUSSET 2ND FOR END CM	TATA spare parts
500631307119	FRONT ENG MTG C/M BRACKET	TATA spare parts
500631307122	LH TOP GUSSET FOR CTR CROSS MEMBER	TATA spare parts
500631307123	LH BOTTOM GUSSET FOR CTR CROSS MEMBER	TATA spare parts
500631307124	RH TOP GUSSET FOR CTR CROSS MEMBER	TATA spare parts
500631307125	RH BOTTOM GUSSET FOR CTR CROSS MEMBER	TATA spare parts
500631307126	GUSSET FOR CTR CROSSMEMBER	TATA spare parts
500631700111	ASSY BRACKET SUMP GUARD	TATA spare parts
500631700114	ASSY. SUMP GUARD PLATE	TATA spare parts
500631700129	ASSEMBLY BRKT FOR SUMP GUARD	TATA spare parts
500631700137	ASSY MAIN BRACKET-LH	TATA spare parts
500631700138	ASSY MAIN BRACKET-RH	TATA spare parts
500631707110	BUMP STOPPER INNER STIFFNER	TATA spare parts
500631707114	SIDE PLATE	TATA spare parts
500631708209	BRACKET OF NOISE SHIELD	TATA spare parts
500631708217	BRACKET FOR NOISE SHIELD	TATA spare parts
500631708223	CLAMP	TATA spare parts
500632100107	ASSY. BELL CRANK LEVER FRONT LH	TATA spare parts
500632100108	ASSY. BELL CRANK LEVER FRONT RH	TATA spare parts
500632100111	ASSY. BUMP STOPPER (EQUALISING MACHANISM)	TATA spare parts
500632100112	ASSY. BELL CRANK LEVER REAR LH	TATA spare parts
500632100113	ASSY. BELL CRANK LEVER REAR RH	TATA spare parts
500632100116	ASSY. BUMP STOPPER (FRONT RWD)	TATA spare parts
500632100119	ASSY PARABOLIC SPRING FRONT RWD	TATA spare parts
500632100120	ASSY MAIN LEAF RWD	TATA spare parts
500632100121	ASSY PARABOLIC SPRING FRONT FWD	TATA spare parts
500632100122	ASSY MAIN LEAF FWD	TATA spare parts
500632100137	ASSY. SPRING HANGER BRACKET (MIDDLE - LH	TATA spare parts
500632100138	ASSY. SPRING HANGER BRACKET (MIDDLE - RH	TATA spare parts
500632100140	ASSY. FRONT SPRING (FRONT FORWARD)	TATA spare parts
500632100141	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
500632100142	ASSY. FRONT SPRING (FRONT REARWARD)	TATA spare parts
500632100143	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
500632100151	ASSY.LINK ROD	TATA spare parts
500632103207	CENTER BOLT M16X1.5X135	TATA spare parts
500632103208	CENTER BOLT	TATA spare parts
500632103302	SPRING HANGER BKT (FRONT FWD)	TATA spare parts
500632103306	SPRING HANGER BRACKET (FRONT FORWARD)	TATA spare parts
500632103309	SPRING HANGER BRACKET FRONT REARWARD	TATA spare parts
500632103401	BUSH	TATA spare parts
500632103402	BUSH	TATA spare parts
500632103403	BUSH	TATA spare parts
500632103405	BUSH	TATA spare parts

500632103407	BUSH	TATA spare parts
500632103709	SPRING SHACKLE (FRONT SPRING)	TATA spare parts
500632103715	BELL CRANK LEVER FRONT - LH	TATA spare parts
500632103716	BELL CRANK LEVER FRONT RH	TATA spare parts
500632103717	BELL CRANK LEVER REAR - LH	TATA spare parts
500632103718	BELL CRANK LEVER REAR RH	TATA spare parts
500632103719	SPRING SHACKLE FRONT	TATA spare parts
500632104205	SPRING CLIP	TATA spare parts
500632106501	FLANGE NUT (U BOLT FRT. SPRING)	TATA spare parts
500632106701	PIN SPRING MOUNTING	TATA spare parts
500632106701AE	PIN SPRING MNTNG 1628	TATA spare parts
500632106702	PIN SPRING MOUNTING(FOR RWD FRT SPRING)	TATA spare parts
500632106704	PIN BELL CRANK LEVER MTG.	TATA spare parts
500632106705	SPRING PIN	TATA spare parts
500632106706	SPRING PIN	TATA spare parts
500632106707	SPRING PIN	TATA spare parts
500632107133	BUMP STOPPER BKT. FRONT FWD	TATA spare parts
500632107134	PLATE ANTI-ROLL BAR FRONT (ON AXLE BKT.)	TATA spare parts
500632107135	SECOND LEAF RWD	TATA spare parts
500632107136	THIRD LEAF RWD	TATA spare parts
500632107139	SECOND LEAF FWD	TATA spare parts
500632107140	THIRD LEAF FWD	TATA spare parts
500632107151	FIRST LEAF	TATA spare parts
500632107152	SECOND LEAF	TATA spare parts
500632107153	THIRD LEAF	TATA spare parts
500632107154	FOURTH LEAF	TATA spare parts
500632107155	FIRST LEAF	TATA spare parts
500632107156	SECOND LEAF	TATA spare parts
500632107157	THIRD LEAF	TATA spare parts
500632107158	FOURTH LEAF	TATA spare parts
500632107159	CASTER PLATE	TATA spare parts
500632107164	CASTER PLATE	TATA spare parts
500632107501	BUSH ANTI-ROLL BAR (ON AXLE)	TATA spare parts
500632108602	WASHER	TATA spare parts
500632108603	WASHER	TATA spare parts
500632300101	SHOCK ABSORBER FRONT	TATA spare parts
500632300106	ASSY. SHOCK ABSORBER FRONT BS3/4	TATA spare parts
500632300106AE	ASSY SHOCK ABSORBER F-1628-1828	TATA spare parts
500632300107	ASSY. SHOCK ABSORBER FRONT BS3/4	TATA spare parts
500632400117	ASSY. REAR TANDEM BOGIE SUSP. COMPLETE	TATA spare parts
500632400118	ASSY. TRUNNION SUPPORT	TATA spare parts
500632400120	ASSY. TRUNNION PIVOT HSG. BS3	TATA spare parts
500632400121	ASSY. LEAF SPRING (REAR)	TATA spare parts
500632400124	ASSY. LINK (TIE ROD) BS3	TATA spare parts
500632400125	LINK SUBASSEMBLY (TORQUE ROD)	TATA spare parts
500632400126	ASSY. BUSH PIN BS3/4	TATA spare parts
500632400128	SUBASSEMBLY V ROD	TATA spare parts



500632400129	ASSY. CENRER BUSH (V ROD) BS3	TATA spare parts
500632400130	ASSY. RUBBER BOLSTER SPRING BS3	TATA spare parts
500632400130AE	RUBBER BOLSTER SPRING ASSY-1828	TATA spare parts
500632400133	ASSLY.TRUNNION HOUSING	TATA spare parts
500632400135	REAR TANDEM BOGIE SUSPENSION ASSY	TATA spare parts
500632400140	ASSY TORQUE ROD	TATA spare parts
500632400142	ASSEMBLY V ROD	TATA spare parts
500632400144	LEAF SPRING ASSY WITH TRUNNION HSG	TATA spare parts
500632400145	RUBBER BOLSTER SPRING ASSY (48T)	TATA spare parts
500632400146	CENTRE BUSH A FRAME BS3/4	TATA spare parts
500632400152	REAR SPRING ASSY BS6	TATA spare parts
500632403207	HEX FL BOLT M16X2X85	TATA spare parts
500632403213	HEX FL BOLT M16X2X70	TATA spare parts
500632403214	HEX FL BOLT M16X2X150	TATA spare parts
500632403215	CENTER BOLT	TATA spare parts
500632403216	HEX BOLT M24X3X85	TATA spare parts
500632403217	HEX.FL.BOLT M24X3X150	TATA spare parts
500632403218	HEX.FL.BOLT M24X3X260	TATA spare parts
500632403221	CENTER BOLT BS6-PH2	TATA spare parts
500632403402	TRUNNION BUSH BS3/4	TATA spare parts
500632403705	ARTICULATION STOPPER	TATA spare parts
500632403710	BRACKET TORQUE ROD MOUNTING (BOTTOM LH)	TATA spare parts
500632403711	BRACKET TORQUE ROD MOUNTING (BOTTOM RH)	TATA spare parts
500632403712	BRACKET V ROD MOUNTING REAR REARWARD AX	TATA spare parts
500632403713	BRACKET LH RUBBER BOLSTER AND ARB MTG.	TATA spare parts
500632403714	BRACKET RH RUBBER BOLSTER AND ARB MTG.	TATA spare parts
500632403715	BRACKET LH RUBBER BOLSTER AND S/ABSORBER	TATA spare parts
500632403716	BRACKET RH RUBBER BOLSTER AND S/ABSORBER	TATA spare parts
500632403717	BRACKET V ROD MOUNTING REAR FORWARD AX	TATA spare parts
500632403719	PIVOT HOUSING (TRUNNION)	TATA spare parts
500632403720	GUIDE PLATE	TATA spare parts
500632403721	V-ROD MTG. BKT.	TATA spare parts
500632403725	BRACKET TORQUE ROD MOUNTING REAR REARW	TATA spare parts
500632403726	BRACKET TORQUE ROD MOUNTING REAR FORWA	TATA spare parts
500632403727	BRACKET SHOCK ABSORBER MOUNTING (CAST AX	TATA spare parts
500632403728	BRACKET ANTIROLL BAR MOUNTING LH (CAST A	TATA spare parts
500632403729	BRACKET ANTIROLL BAR MOUNTING RH (CAST A	TATA spare parts
500632403731	TRUNNION BRACKET BS6	TATA spare parts
500632403732	BRACKET ANTI ROLL BAR LINK LH BS6	TATA spare parts
500632403733	BRACKET ANTI ROLL BAR LINK RH BS6	TATA spare parts
500632403734	BRACKET TORQUE ROD MTG BS6	TATA spare parts
500632403736	BRACKET-PIVOT MTG BS6	TATA spare parts
500632403737	GUIDE PLATE BS6	TATA spare parts
500632403738	BRACKET V-ROD MTG BS6	TATA spare parts
500632403739	BRACKET ARTICULATION STOPPER BS6	TATA spare parts
500632403748	BRACKET-PIVOT MTG BS6	TATA spare parts
500632403749	BRACKET V-ROD MTG RH BS6	TATA spare parts

500632404201	SPRING CLIP	TATA spare parts
500632404203	U BOLT REAR	TATA spare parts
500632404207	U-BOLT-REAR BS6	TATA spare parts
500632404209	SPRING CLIP BS6-PH2	TATA spare parts
500632404305	EXTERNAL CIRCLIP	TATA spare parts
500632404306	INTERNAL CIRCLIP EYE END	TATA spare parts
500632404802	DOWEL TORQUE ROD MTG.BRACKET (40MM)	TATA spare parts
500632405104	LOCK PLATE BS6	TATA spare parts
500632406502	HEX FL NUT M24X3	TATA spare parts
500632406507	M27X3 (GRD. 10.0 ALL METAL PREVALLING TO	TATA spare parts
500632406509	HEX FLANGE NUT BS6-PH2	TATA spare parts
500632407113	SPACER PLATE (CORNER BKT)	TATA spare parts
500632407114	FIRST LEAF REAR SPRING BS3/4	TATA spare parts
500632407115	SECOND LEAF REAR SPRING? BS3/4	TATA spare parts
500632407116	THIRD LEAF	TATA spare parts
500632407117	FOURTH LEAF	TATA spare parts
500632407118	FIFTH LEAF	TATA spare parts
500632407119	SIXTH LEAF	TATA spare parts
500632407120	SEVENTH LEAF	TATA spare parts
500632407121	EIGHTH LEAF	TATA spare parts
500632407122	NINETH LEAF	TATA spare parts
500632407123	TENTH LEAF	TATA spare parts
500632407124	ELEVENTH LEAF	TATA spare parts
500632407125	TWELTH LEAF	TATA spare parts
500632407127	1ST LEAF BS6-PH2	TATA spare parts
500632407128	2ND LEAF BS6-PH2	TATA spare parts
500632407129	3RD LEAF BS6-PH2	TATA spare parts
500632407130	4TH LEAF BS6-PH2	TATA spare parts
500632407131	5TH LEAF BS6-PH2	TATA spare parts
500632407132	6TH LEAF BS6-PH2	TATA spare parts
500632407133	7TH LEAF BS6-PH2	TATA spare parts
500632407134	8TH LEAF BS6-PH2	TATA spare parts
500632407135	9TH LEAF BS6-PH2	TATA spare parts
500632407136	10TH LEAF BS6-PH2	TATA spare parts
500632407137	11TH LEAF BS6-PH2	TATA spare parts
500632407138	12TH LEAF BS6-PH2	TATA spare parts
500632407139	CENTER PAD BS6-PH2	TATA spare parts
500632407140	SPACER PLATE BS6	TATA spare parts
500632407401	CLIP RIVET	TATA spare parts
500632407802	OIL SEAL BS3/4	TATA spare parts
500632408205	CAP END CLOSURE190 OD	TATA spare parts
500632408206	END CAP CLOSURE BS6	TATA spare parts
500632408304	SHIM (0.76 THICK)	TATA spare parts
500632408305	SHIM (1.52 THICK)	TATA spare parts
500632408306	SHIM (3.05 THICK)	TATA spare parts
500632408310	SHIM BS6	TATA spare parts
500632408311	SHIM BS6	TATA spare parts

500632408603	SPACER EYE END	TATA spare parts
500632409201	THRUST WASHER BS6	TATA spare parts
500632409206	THRUST WASHER (INNER)	TATA spare parts
500632409207	M27 HARDENED WASHER	TATA spare parts
500632409208	THRUST WASHER OUTER	TATA spare parts
500632409209	M24 HARDENED WASHER	TATA spare parts
500632409214	THRUST WASHER OUTER BS6	TATA spare parts
500632600101	REAR SHOCK ABS ASSY.	TATA spare parts
500632600103	REAR SHOCK ABSORBER ASSY	TATA spare parts
500632607101	BRACKET REAR SHOCK ABSORBER MOUNTING	TATA spare parts
500632800103	ASSY. ANTIROLLBAR	TATA spare parts
500632800103AE	ASSY. ANTIROLLBAR	TATA spare parts
500632800104	ASSY ANTIROLL BAR DIA 50 (WITH CRIMPED E	TATA spare parts
500632800105	ASSY. BALL JOINT LINK (FRT ANTI ROLL BAR	TATA spare parts
500632800106	ASSY.ANTIROLL BAR CRIMPED	TATA spare parts
500632805104	BRACKET (ARB MOUNTING ON AXLE)	TATA spare parts
500632900101	ASSY. REAR ANTIROLL BAR LINK BS3/4	TATA spare parts
500632903701	ARB - TOP BRACKET	TATA spare parts
500632903702	ARB - BOTTOM BRACKET	TATA spare parts
500632903704	BRACKET ANTI ROLL BAR BS6	TATA spare parts
500632907101	CLAMP (ANTI ROLL BAR)	TATA spare parts
500632907702	ARB BUSH	TATA spare parts
500632907901	ANTIROLL BAR REAR	TATA spare parts
500632907902	ANTI ROLL BAR BS6	TATA spare parts
500633000104	FRONT AXLE ASSY WITH BRAKE FRT FWD	TATA spare parts
500633000105	FRONT AXLE ASSY.COMP.WITH BRAKES (FRW)	TATA spare parts
500633105101	FRONT AXLE BEAM 6.5DEG.15MM DROP BS3/4	TATA spare parts
500633200101	ASSY.KNUCKLE LH FRWD (LPK3128 / LPT3128)	TATA spare parts
500633200102	ASSY.KNUCKLE RH FRWD (LPK3128 / LPT3128)	TATA spare parts
500633200103	ASSY. KNUCKLE LH (FRT FWD)-STUB AXL BS3	TATA spare parts
500633200104	ASSY. KNUCKLE RH (FRONT FORWARD) BS3	TATA spare parts
500633200105	ASSY.KNUCKLE LH (FRONT REARWARD)	TATA spare parts
500633200106	ASSY.KNUCKLE RH (FRONT REARWARD)	TATA spare parts
500633200107	ASSY. KNUCKLE LH(PLUMMER BLOCK)	TATA spare parts
500633200108	ASSY. KNUCKLE RH(PLUMMER BLOCK)	TATA spare parts
500633400101	ASSY. WHEEL HUB FRONT COMPLETE	TATA spare parts
500633800101	ASSY.TIE ROD	TATA spare parts
500633805102	KNUCKLE ARM RH	TATA spare parts
500633805103	TIE ROD ARM LH	TATA spare parts
500633805104	TIE ROD ARM RH	TATA spare parts
500640000101	ASSY WHEEL RIM 8.5X24 STEEL	TATA spare parts
500640000104	ASSY WHEEL RIM 8.5X24 (DOUBLE LOCK)	TATA spare parts
500640100101	ASSY WHEEL RIM 8.5-24 IN	TATA spare parts
500640109906	TUBE ASSY WITH VALVE	TATA spare parts
500640109924	TYRE,RIB TYPE 12-R-24	TATA spare parts
500640109925	FLAP ASSY	TATA spare parts
500640209901	TYRE,LUG TYPE 12-R-24	TATA spare parts

500641100101	ASSY.PROP SHAFT FRONT WITH EATON GB	TATA spare parts
500641110102	PROPELLER SHAFT ASSY FRONT	TATA spare parts
500641115101	FLANGE YOKE	TATA spare parts
500641119901	KIT-CENTER BEARING EURO3	TATA spare parts
500641120102	ASSY.PROP SHAFT INTERAXLE WITH	TATA spare parts
500641307101	SPACER BRACKET	TATA spare parts
500641307102	SUPPORT BRACKET	TATA spare parts
500642100106	FRONT BRAKE ASSY. LH FOR ST AXL	TATA spare parts
500642100107	FRONT BRAKE RH FOR ST. AXLE	TATA spare parts
500642100117	ASSY. FRONT FWD AXLE LH BRAKE COMPLETE W	TATA spare parts
500642100118	ASSY. FRONT FWD AXLE RH BRAKE COMPLETE W	TATA spare parts
500642100119	ASSY. FRONT RWD AXLE LH BRAKE COMPLETE W	TATA spare parts
500642100120	ASSY. FRONT RWD AXLE RH BRAKE COMPLETE W	TATA spare parts
500642100121	AUTO SLACK ADJUSTER STRAIGHT CD150MM	TATA spare parts
500642100124	CHAMBER MOUNTING BRACKET LH (FABRICATED	TATA spare parts
500642100125	CHAMBER MOUNTING BRACKET RH (FABRICATED	TATA spare parts
500642100126	FRONT CHAMBER MOUNTING BRACKET ASSY LH	TATA spare parts
500642100127	FRONT CHAMBER MOUNTING BRACKET ASSY RH	TATA spare parts
500642100153	ACTUATOR MOUNTING BRACKET LH (FABRICATED	TATA spare parts
500642100154	ACTUATOR MOUNTING BRACKET RH (FABRICATED	TATA spare parts
500642100155	ASSY. LINED SHOE BS2/3/4	TATA spare parts
500642100156	SHIELD ASSY	TATA spare parts
500642100157	SHIELD ASSY	TATA spare parts
500642103709	TORQUE PLATE LH	TATA spare parts
500642103710	KIT TORQUE PLATE FRH	TATA spare parts
500642103711	BRAKE DRUM BS6	TATA spare parts
500642107901	CAM SHAFT - LH	TATA spare parts
500642107902	CAM SHAFT - RH	TATA spare parts
500642108223	ANCHOR BRACKET RH	TATA spare parts
500642108224	ANCHOR BRACKET-LH	TATA spare parts
500642108227	ANCHOR BRACKET LH FOR FRONT RWD AXLE BRA	TATA spare parts
500642108228	ANCHOR BRACKET RH FOR FRONT RWD AXLE	TATA spare parts
500642108601	SPACER FOR FRONT STRAIGHT AXLE	TATA spare parts
500642109901	POLE WHEEL - 120 TEETH (FRONT)	TATA spare parts
500642300106	ASSY. REAR AXLE BRAKE WITH DUST LH COVER	TATA spare parts
500642300107	ASSY. REAR AXLE BRAKE WITH DUST RH COVER	TATA spare parts
500642300110	REAR CHAMBER MOUNTING BRACKET LH	TATA spare parts
500642300111	REAR CHAMBER MOUNTING BRACKET RH	TATA spare parts
500642300121	AUTO SLACK ADJ. LH 60MM OFFSET/CD1 BS3-6	TATA spare parts
500642300122	AUTO SLACK ADJ. RH 60MM OFFSET/CD1 BS3-6	TATA spare parts
500642303701	PLUMMER BLOCK FOR REAR BRAKE ASSY	TATA spare parts
500642303701AE	PLUMMER BLK RR BRK ASSY. -1628	TATA spare parts
500642303702	BRACKET BRAKE CHAMBER MTG LH	TATA spare parts
500642303703	BRACKET BRAKE CHAMBER MTG RH	TATA spare parts
500642307901	CAM SHAFT - LH	TATA spare parts
500642307902	CAM SHAFT - RH	TATA spare parts
500642308205	ANCHOR BRACKET LH	TATA spare parts

500642308206	ANCHOR BRACKET RH	TATA spare parts
500642308601	SPACER	TATA spare parts
500642308602	CONNECTOR FOR SPRING BRAKE ACTUATOR PUSH	TATA spare parts
500642309901	POLE WHEEL - 120 TEETH (REAR)	TATA spare parts
500643200102	ASSY. BRACKET (AIR TANK MTG.)	TATA spare parts
500643200104	SUB ASSY. AIR TANK (20L) WITH BRACKET	TATA spare parts
500643200106	ASSY.BRACKET FOR AIR TANK MTG(LPK3138)	TATA spare parts
500643208201	BRACKET FOR PIPE HOLDING	TATA spare parts
500643208207	MODULATOR VALVE MTG BRACKET	TATA spare parts
500643700102	HAND BRAKE VALVE WITHOUT TRAILER CHECK	TATA spare parts
500643700108	AIR PROCESSING UNIT 10 BAR BS3/4	TATA spare parts
500643700108AE	APU 10 BAR WABCO(IMP 1628 1828	TATA spare parts
500643700109	AIR PROCESSING UNIT 10 BAR BS3/4	TATA spare parts
500643700109AE	APU KB 10 BAR(LOCAL) 1628	TATA spare parts
500643700132	CARTRIDGE	TATA spare parts
500643703301	BRACKET	TATA spare parts
500643708201	BRACKET RELAY VALVE	TATA spare parts
500643708205	BRACKET-RELAY VALVE	TATA spare parts
500643708205AE	BRACKET RELAY VALVE(KB) 1628	TATA spare parts
500643900103	ASSY. NYLON PIPE APU TO REAR TANK	TATA spare parts
500643900108	ASSY NYLON PIPE. REAR AIR TANK TO TEE	TATA spare parts
500643900109	ASSY. NYLON PIPE AIR TANK PARKING TO NRV	TATA spare parts
500643900110	ASSY. NYLON PIPE TEE TO RELAY VALVE	TATA spare parts
500643900111	ASSY NYLON PIPE TEE-13 TO SBA REAR FWD L	TATA spare parts
500643900116	ASSY NYLON PIPE TEE-14 TO SBA REAR RWD L	TATA spare parts
500643900117	ASSY. NYLON PIPE TEE TO TEE	TATA spare parts
500643900122	ASSY. NYLON PIPE TEE -10 TO RELAY VALVE	TATA spare parts
500643900124	ASSY. NYLON PIPE TEE-10 TO REAR LH RV	TATA spare parts
500643900125	ASSY. NYLON PIPE TEE-9 TO ACRV PORT-41	TATA spare parts
500643900126	ASSY. NYLON PIPE TEE-12 TO SBA REAR FWD	TATA spare parts
500643900127	ASSY. NYLON PIPE TEE-12 TO SBA REAR RWD	TATA spare parts
500643900128	ASSY. NYLON PIPE TEE-15 TO SBA REAR FWD	TATA spare parts
500643900129	ASSY NYLON PIPE TEE-15 TO SBA REAR RWD L	TATA spare parts
500643900131	ASSY NYLON PIPE TEE-14 TO SBA REAR RWD R	TATA spare parts
500643900132	ASSY NYLON PIPE TEE TO REAR REARWARD	TATA spare parts
500643900135	ASSY NYLON PIPE AIR TANK PARKING TO ACRV	TATA spare parts
500643900137	ASSY. NYLON PIPE MOD. VALVE TO TEE	TATA spare parts
500643900138	ASSY. NYLON PIPE TEE TO SPRING BRAKE ACT	TATA spare parts
500643900143	ASSY.NYLON PIPE TEE-1 TO MOD VALVE LH FR	TATA spare parts
500643900145	ASSY. NYLON PIPE DBV TO TEE-8	TATA spare parts
500643900147	ASSY NYLON PIPE R14 VALVE TO SBA REAR	TATA spare parts
500643900148	ASSY NYLON PIPE	TATA spare parts
500643900151	ASSY NYLON PIPE TEE-13 TO SBA REAR FWD R	TATA spare parts
500643900155	ASSY OF REAR TEE-7 TO REAR RV LH	TATA spare parts
500643900156	ASSY OF NYLON PIPE TEE-7 TO REAR RV RH.	TATA spare parts
500643900158	ASSY. OF NYLON PIPE DBV PORT-22 TO TEE	TATA spare parts
500643900159	ASSY. OF NYLON PIPE TEE-4 TO FRONT LH RV	TATA spare parts

500643900164	ASSY OF NYLON PIPE TEE-4 TO TEE-3	TATA spare parts
500643900172	ASSY. OF METAL PIPE TO APU	TATA spare parts
500643900173	ASSY NYLON PIPE APU PORT-23 TO NRV	TATA spare parts
500643900177	ASSY NYLON PIPE DBV TO TEE-3	TATA spare parts
500643900181	ASSY. METAL PIPE SECOND	TATA spare parts
500643900185	ASSY METAL PIPE COMPRESSOR END	TATA spare parts
500643900301	ASSY. NYLON PIPE BUNCH FOR 10 BAR WITH	TATA spare parts
500643900302	ASSY.NYLON FROM FR RH MV TO TEE-1	TATA spare parts
500643900304	ASSY. OF NYLON PIPE DBV TO TEE-9	TATA spare parts
500643900305	ASSY. OF NYLON PIPE & HBV ADAPTOR TO PARK	TATA spare parts
500643900308	ASSY.NYLON PIPE FRT LH RV TO FRT LH MV	TATA spare parts
500643900309	ASSY.NYLON PIPE FROM TEE-1 TO FRONT LH M	TATA spare parts
500643900310	ASSY.NYLON PIPE FROM FR.RH RV TO MOD.VAL	TATA spare parts
500643900311	ASSY.NYLON PIPE FROM LH RV(FR) TO HOSE M	TATA spare parts
500643900312	ASSY.NYLON PIPE FROM RH RV(FR) TO HOSE M	TATA spare parts
500643900313	ASSY.METAL PIPE FROM COMPR CONT.PORT TO	TATA spare parts
500643900319	ASSY.NYLON PIPE T1 TO MOD VALVE RH FRT	TATA spare parts
500643900390	ASSY NYLON PIPE BUNCH-3138.K.LHD	TATA spare parts
500643900392	NYLON PIPE BUNCH ASSY	TATA spare parts
500643910172	PIPE BUNCH ASSY	TATA spare parts
500645100101	AUXILIARY TANK - SOLENOID (NYLON PIPE DI	TATA spare parts
500645100102	SOLENOID - AIR CONTROL VALVE (NYLON PIPE	TATA spare parts
500645100103	AIR CONTROL VALVE - PTO (NYLON PIPE DIA	TATA spare parts
500645100104	AIR CONTROL VALVE - PT VALVE UP PORT (NY	TATA spare parts
500645100105	AIR CONTROL VALVE - PT VALVE DOWN PORT N	TATA spare parts
500645100108	AUXILIARY TANK - TEE 1 (NYLON PIPE DIA	TATA spare parts
500645100109	TEE 1 - SOLENOID 1 (NYLON PIPE DIA 6)	TATA spare parts
500645100110	TEE 1 - SOLENOID 2 (NYLON PIPE DIA 6)	TATA spare parts
500645100111	SOLENOID 1 - TEE 2 (NYLON PIPE DIA 6)	TATA spare parts
500645100112	TEE 2 - FWD AXLE (NYLON PIPE DIA 6)	TATA spare parts
500645100113	TEE 2 - RWD AXLE (NYLON PIPE DIA 6)	TATA spare parts
500645100114	SOLENOID 2 - INTER AXLE DIFF LOCK (NYLON	TATA spare parts
500645100115	SET ASSY. COMPLETE NYLON PIPE BUNCH FOR	TATA spare parts
500645100117	SET ASSY. COMPLETE NYLON PIPE BUNCH FOR	TATA spare parts
500645100127	SET ASSY.COMPLETE NYLON PIPE BUNCH FOR S	TATA spare parts
500646204201	PLATE RUBBER BELLOW	TATA spare parts
500646207701	RUBBER BELLOW TELESCOPIC SHAFT	TATA spare parts
500646300108	P/CYL BALL JOINT ASM	TATA spare parts
500646300111	ASSY. DRAG LINK-1ST	TATA spare parts
500646300112	ASSY. RELAY ROD-1ST	TATA spare parts
500646300113	ASSY. RELAY ROD-2ND	TATA spare parts
500646300114	ASSY. DRAG LINK-2ND	TATA spare parts
500646300115	DRAG LINK 1ST ASM - LHD	TATA spare parts
500646300116	RELAY ROD 1ST ASM - LHD	TATA spare parts
500646300118	DRAG LINK 2ND ASM - LHD	TATA spare parts
500646304104	RELAY ARM LPK 3138	TATA spare parts
500646304106	RELAY ARM-LHD	TATA spare parts

500646600101	GEAR PUMP ISLE	TATA spare parts
500646600103	POWER CYLINDER ASM	TATA spare parts
500646600105	STEERING ASSY LIMITER KIT	TATA spare parts
500646600106	STEERING ASSY PRV KIT	TATA spare parts
500646600107	SEAL KIT	TATA spare parts
500646600109	VANE PUMP ASSY	TATA spare parts
500646600113	KIT-SEAL	TATA spare parts
500646600116	POWER CYLINDER ASM	TATA spare parts
500646600117	KIT-ROTOR WITH FR PLATE & PRESSURE PLATE	TATA spare parts
500646603307	BRKT-MAIN STRG RESERVOIR	TATA spare parts
500646605301	GEAR PUMP GASKET-ISLE ENGINE	TATA spare parts
500646606501	LOCK NUT	TATA spare parts
500646606602	PISTON ROD	TATA spare parts
500646606901	POWER CYLINDER TUBE S/A	TATA spare parts
500646703302	BRKT-POWER CYLINDER MTG	TATA spare parts
500646703303	IDLER ARM MTG BRKT	TATA spare parts
500646703305	BRKT-POWER CYLINDER MTG LHD	TATA spare parts
500646800122	PRESSURE LINE ASM - G. B. END	TATA spare parts
500646800123	PRESSURE LINE ASM - PUMP END	TATA spare parts
500646800124	SUCTION LINE ASM	TATA spare parts
500646800125	RETURN LINE ASM - G.B. END	TATA spare parts
500646800126	RETURN LINE ASM - INTERMEDIATE	TATA spare parts
500646800127	RETURN LINE ASM - RESERVOIR END	TATA spare parts
500646800128	PRESSURE LINE ASM - P/CYL G B END	TATA spare parts
500646800129	PRESSURE LINE ASM - P/CYL G B END	TATA spare parts
500646800130	PRESSURE LINE ASM - P/CYL END	TATA spare parts
500646800131	PRESSURE LINE ASM - P/CYL END	TATA spare parts
500646800139	OIL COOLER RUBBER MOUNT	TATA spare parts
500646800140	OIL COOLER RUBBER MOUNT	TATA spare parts
500646800141	PRESSURE LINE ASM - TYPE I	TATA spare parts
500646800142	RETURN LINE ASM - G.B. END	TATA spare parts
500646800143	RETURN LINE ASM - INTERMEDIATE	TATA spare parts
500646800144	RETURN LINE ASM - RESERVOIR END	TATA spare parts
500646800145	PRESSURE LINE ASM - P/CYL G B END	TATA spare parts
500646800146	PRESSURE LINE ASM - P/CYL G B END	TATA spare parts
500646800147	PRESSURE LINE ASM - P/CYL END	TATA spare parts
500646800148	PRESSURE LINE ASM - P/CYL END	TATA spare parts
500646800151	PRESSURE LINE ASSY INTERMEDIATE	TATA spare parts
500646800158	ADAPTOR M26XM18	TATA spare parts
500646800159	ELBOW ADAPTOR-M26XM18	TATA spare parts
500646800160	ELBOW ADAPTOR M22X1.5-M18X1.5	TATA spare parts
500646800161	ELBOW K15 M16X1.5	TATA spare parts
500646800202	RETURN LINE ASSY	TATA spare parts
500646803306	OIL COOLER BRACKET	TATA spare parts
500646803307	OIL COOLER SIDE BRACKET LH	TATA spare parts
500646803308	BRACKET-POWER STEERING LINES SUPPORT	TATA spare parts
500646803309	BRKT-STRG PIPE MTG	TATA spare parts

500646803310	BRACKET-OIL COOLER MOUNTING CENTRE	TATA spare parts
500647100104	ASSY. FUEL TANK(SEM WELDED)LH-260 LTRS.	TATA spare parts
500647100105	ASSY.FUEL TANK COMPLETE(INTEGRATED SENDE	TATA spare parts
500647100154	FUEL TANK RH 260 L T-1 NECK (GALVANNEALE	TATA spare parts
500647100164	FUEL TANK LH 260 L T-1 NECK (GALVANNEALE	TATA spare parts
500647600108	ASSY. FUEL RETURN LINE- ENGINE TO F/TANK	TATA spare parts
500647600109	ASSY FUEL SUCTION LINE FT-W/S	TATA spare parts
500647600110	ASSY FUEL SUCTION LINE W/S-ENGINE	TATA spare parts
500647603301	SUPPORT PLATE FOR FUEL LINES	TATA spare parts
500647603302	FUEL LINE SUPPORT BRACKET	TATA spare parts
500647703301	BRKT-FUEL FILTER	TATA spare parts
500649100106	ASSY STRUCTURE SILENCER MOUNTING	TATA spare parts
500649100110	EXHAUST MUFFLER	TATA spare parts
500649100116	STAY ROD ASSY	TATA spare parts
500649100120	ASSY STRAP	TATA spare parts
500649100123	V BAND CLAMP FOR LPK 3138 ISLE ENG AT TU	TATA spare parts
500649100127	ASSY HEAT SHIELD FOR SILENCER	TATA spare parts
500649100133	EXH PIPE ASM FROM SILENCER TO FLEX CONN.	TATA spare parts
500649100138	FLEX CONNECTOR	TATA spare parts
500649106908	EXHUAST TAIL PIPE	TATA spare parts
500649106917	FIRST PIPE FROM FLEX CONNECTOR TO TURBO	TATA spare parts
500649107132	TAIL PIPE CLAMPING BRACKET	TATA spare parts
500649108207	FIRST PIPE SUPPORT BRACKET	TATA spare parts
500649108209	STAY ROD SUPPORT BRACKET	TATA spare parts
500649108212	BRACKET ( STAY ROD )	TATA spare parts
500649108218	STAY ROD BRACKET	TATA spare parts
500654600102	WIRING HARNESS DASHBOARD	TATA spare parts
500654600103	WIRING HARNESS DOOR LH	TATA spare parts
500654600104	WIRING HARNESS DOOR RH	TATA spare parts
500654600106	WIRING HARNESS AUXILIARY FUSE BOX	TATA spare parts
500654600109	BATTERY CABLE +VE BCS TO MEGA FUSE	TATA spare parts
500654600110	BATTERY CABLE +VE BATTERY TO BCS OFF I/P	TATA spare parts
500700990101	KIT FULLY TRIMMED CABIN LPK 2518 BSIV	TATA spare parts
500700990102	KIT FULLY BUILD CABIN LPT 2518 BS4 BLW	TATA spare parts
500700990103	KIT FOR CABIN LPTK 2518 CR BSIV	TATA spare parts
50071048000R40	CAB COMPLETE	TATA spare parts
50071148000R40	6OR_RESTRUCTURE_FOR_CVBU_IN_APL_VIEW	TATA spare parts
500724200101	ASSY.BRACKET-LH(ENG.MTG.-REAR BOTTOM)	TATA spare parts
500724200102	ASSY.BRACKET-RH(ENG.MTG.-REAR BOTTOM)	TATA spare parts
500729100101	CLUTCH PEDAL ASSY	TATA spare parts
500729100102	CLUTCH PEDAL ASSY WITH BUSH	TATA spare parts
500729100104	SEAL MASTER CYLINDER BACK PLATE	TATA spare parts
500729100105	FOAM CLUTCH PEDAL	TATA spare parts
500729300101	BUNDY TUBE ASSY CMC TO LONG MEMBER	TATA spare parts
500729500103	BRACKET ASSY CLUTCH PEDAL MTG	TATA spare parts
500730100101	BRACKET ASSY ACCELERATOR PEDAL	TATA spare parts
500730100102	ACCELERATOR CABLE (L=560+2880+145) BS1/3	TATA spare parts



500730100109	BRACKET ASSY ACCELERATOR MTG BS6	TATA spare parts
500730100111	ACCELERATOR CABLE ASSY	TATA spare parts
500730100115	ACCELERATOR CABLE ASSY	TATA spare parts
500731000101	ASSY.FRAME COMPLETE ( SANDWICH 888 )	TATA spare parts
500731000102	FRAME ASSY WITH FITMENT	TATA spare parts
500731000103	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
500731000106	FRAME ASSY WITH FITMENT BS6	TATA spare parts
500731200103	ASSY.SUPPORT-RH ( 2 ND CROSS MEMBER )	TATA spare parts
500731200104	ASSY.SUPPORT-LH ( 2 ND C.M.)	TATA spare parts
500731200105	ASSY.CROSS MEMBER ( 4 TH & 5 TH )	TATA spare parts
500731200107	ASSY.CROSS MEMBER ( 8 TH C.M.)	TATA spare parts
500731200108	ASSY.CROSS MEMBER ( 7 TH BACK TO BACK )	TATA spare parts
500731200109	ASSY.CROSS MEMBER ( 6 TH C.M.)	TATA spare parts
500731200110	ASSY.CROSS MEMBER ( 6 TH A C.M.)	TATA spare parts
500731207110	SPACER PLATE	TATA spare parts
500731207115	SUPPORT (REAR SPRING FRONT BKT.)	TATA spare parts
500731207116	SUPPORT RH (8TH CROSS MEMBER)	TATA spare parts
500731207120	GUSSET (4TH CROSS MEMBER)	TATA spare parts
500731308201	REINFORCEMENT RH (FRONT SPRING REAR BKT)	TATA spare parts
500731308202	REINFORCEMENT LH (FRONT SPRING REAR BKT)	TATA spare parts
500731700101	ASSY. END CROSS MEMBER	TATA spare parts
500731700102	ASSY.REAR UNDERRUN PROTECTIVE DEVICE COM	TATA spare parts
500733000101	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
500741100101	ASSY.PROP.SHAFT FRONT (L=1407)	TATA spare parts
500741109901	CROSS ASSY (REGULAR GREASING)	TATA spare parts
500741109901DF	UJ CROSS-52X147-2518/3118/3718/4623/4923	TATA spare parts
500741120101	ASSY.PROP.SHAFT REAR.(1009CLOSED)	TATA spare parts
500741120102	ASSY.INTERAXLE PROP.SHAFT(660 CL)	TATA spare parts
500741120103	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
500741129901	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
500741300101	ASSY.BRACKET RH (PROP.SHAFT GUARD MTG.)	TATA spare parts
500741300102	ASSY.BRACKET LH (PROP.SHAFT GUARD MTG.)	TATA spare parts
500741303301	BRACKET (CENTER BRG.FRONT PROP.SHAFT)	TATA spare parts
500741303302	CENTRE BEARING BRACKET	TATA spare parts
500742300105	BRAKE ASSY- REAR LH	TATA spare parts
500742300106	BRAKE ASSY- REAR RH	TATA spare parts
500742300109	BRACKET ASSY- CAM SHAFT- LH	TATA spare parts
500742300110	BRACKET ASSY- CAM SHAFT- RH	TATA spare parts
500743200102	AIR TANK ASSY WITH BKTS & STRAP BS6	TATA spare parts
500743200103	AIR TANK ASSY WITH BRACKET	TATA spare parts
500743200104	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
500743200105	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
500743200106	BRACKET ASSY AIR TANK MTG	TATA spare parts
500743200107	AIR TANK ASSY WITH MTG BKT	TATA spare parts
500743200108	BRACKET ASSY AIR TANK MTG TOP	TATA spare parts
500743200111	AIR TANK ASSY	TATA spare parts
500743700107	HAND BREAK VALVE MOUNTING BRACKET	TATA spare parts

500743700117	BRACKET ASSY AIR TANK MTG BOTTOM	TATA spare parts
500743700118	ANTI COMPOUNDING RELAY VALVE	TATA spare parts
500743707101	PLATE DTV MOUNTING	TATA spare parts
500743900109	PIPE BUNCH ASSY COMP LPT 2518 TC 48 WB	TATA spare parts
500743900111	2ND MEATAL PIPE	TATA spare parts
500743900112	THIRD METAL PIPE	TATA spare parts
500743900148	BUNCH ASSY PIPE	TATA spare parts
500743900187	PIPE ASSY JOINT-3 TO DDU	TATA spare parts
500743900188	PIPE ASSY COMP. JOINT-1 TO JOINT-2	TATA spare parts
500743900189	PIPE ASSY COMPRESSOR TO JOINT 1	TATA spare parts
500743900195	BUNCH ASSY PIPE	TATA spare parts
500743900199	PIPE ASSY JOINT-2 TO JOINT-3	TATA spare parts
500743903301	BRACKET HOSE MTG	TATA spare parts
500743903304	BRACKET COMP INLET PIPE	TATA spare parts
500743903305	BRACKET (FOR RA109RR AXLE)	TATA spare parts
500743906801	COUPLING BODY M22 X M36	TATA spare parts
500743910102	BUNCH ASSY PIPE	TATA spare parts
500743910125	BUNCH ASSY PIPE	TATA spare parts
500743910127	BUNCH ASSY PIPE	TATA spare parts
500743910150	PIPE ASSY JOINT-3 TO DDU	TATA spare parts
500743910151	PIPE ASSY JOINT-2 TO JOINT-3	TATA spare parts
500743910152	PIPE ASSY COMP. JOINT-1 TO JOINT-2	TATA spare parts
500743910157	PIPE ASSY JOINT-3 TO DDU	TATA spare parts
500743910161	BUNCH ASSY PIPE	TATA spare parts
500743910162	BUNCH ASSY PIPE	TATA spare parts
500743910181	BUNCH ASSY PIPE	TATA spare parts
500743920102	BUNCH ASSY PIPE	TATA spare parts
500743920120	PIPE ASSY JOINT-3 TO DDU	TATA spare parts
500743920122	BUNCH ASSY PIPE	TATA spare parts
500743920124	BUNCH ASSY PIPE	TATA spare parts
500743920131	PIPE BUNCH ASSY	TATA spare parts
500743920139	PIPE ASSY THIRD METAL PIPE	TATA spare parts
500743920144	PIPE ASSY INT JOINT TO INT JOINT	TATA spare parts
500743920156	PIPE BUNCH ASSY BS6	TATA spare parts
500743930105	BUNCH ASSY PIPE	TATA spare parts
500747507105	BRACKET (FILTER MTG)	TATA spare parts
500747600104	SUCTION LINE (TANK TO FILTER)	TATA spare parts
500747600105	SUCTION LINE (FUEL FILTER TO ENG)	TATA spare parts
500747600106	RETURN LINE ASSY ON TANK	TATA spare parts
500747600107	FUEL SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
500747600108	ASSY. SUCTION PIPE FILTER TO ENGINE BS4	TATA spare parts
500747600109	RETURN FUEL PIPE ASSY	TATA spare parts
500749200101	ASSY.EXHAUST PIPE (INTERMEDIATE)	TATA spare parts
500749200102	EXHAUST PIPE ASSY INT	TATA spare parts
500749200103	BRACKET ASSY EGP MTG	TATA spare parts
500749200104	ASSY. EXHAUST PIPE W/FLEX BELLOW BS4	TATA spare parts
500749200105	BRACKET ASSY TAIL PIPE MTG	TATA spare parts

500749200107	PIPE ASSY AIR OIL FILTER TO DU	TATA spare parts
500749200108	PIPE ASSY T-CONNECTOR TO AIR OIL FILTER	TATA spare parts
500749200109	BRACKET ASSY TAIL PIPE MTG	TATA spare parts
500749200110	BRACKET ASSY UREA TANK MTG	TATA spare parts
500749203301	BRACKET (EXHAUST MOUNTING)	TATA spare parts
500749203302	BRACKET (EXHAUST MTG.)	TATA spare parts
500749203303	BRACKET	TATA spare parts
500749203304	BRACKET (EXHAUST MTG.)	TATA spare parts
500749203307	BRACKET EGP MTG	TATA spare parts
500749203308	BRACKET AIR OIL SEPARATOR MTG	TATA spare parts
500749203309	BRACKET EXHAUST PIPE CLAMPING	TATA spare parts
500749203310	BRACKET NOX SENSOR MTG	TATA spare parts
500749203312	BRACKET UREA LINE SUPPORT	TATA spare parts
500754209904	INST CLUSTER 1:1.04	TATA spare parts
500754209907	ASSY. INSTRUMENT CLUSTER BS4 BS6	TATA spare parts
500754303301	BRACKET HORN MTG	TATA spare parts
500754600106	WIRING HARNESS ABS	TATA spare parts
500754600110	WIRING HARNESS ABS	TATA spare parts
500754600112	WIRING HARNESS ABS BS3/4	TATA spare parts
500754600113	WIRING HARNESS ABS	TATA spare parts
500754600116	WIRING HARNESS RSL FRAME	TATA spare parts
500754600120	WIRING HARNESS RSL SPLIT	TATA spare parts
500754600126	WIRING HARNESS TAIL	TATA spare parts
500754600129	WIRING HARNESS TAIL	TATA spare parts
500754600138	WIRING HARNESS TAIL	TATA spare parts
500754601619	WIRING HARNESS MAIN	TATA spare parts
500754601620	WIRING HARNESS ENGINE	TATA spare parts
500754601622	WIRING HARNESS SCR UNIT	TATA spare parts
500754601628	WIRING HARNESS TAIL	TATA spare parts
500754603302	BRACKET INLINE CONN MTG	TATA spare parts
500754603303	BRACKET INLINE CONN MTG	TATA spare parts
500754620105	W/H MAIN	TATA spare parts
500754620111	WIRING HARNESS TAIL	TATA spare parts
500754620113	WIRING HARNESS MAIN BS4	TATA spare parts
500754620114	WIRING HARNESS ENGINE BS4	TATA spare parts
500754620115	WIRING HARNESS TAIL	TATA spare parts
500754620116	WIRING HARNESS SCR UNIT BS4	TATA spare parts
500754620118	WIRING HARNESS TAIL	TATA spare parts
500754620120	WIRING HARNESS TAIL	TATA spare parts
500754620121	WIRING HARNESS TAIL	TATA spare parts
500754630101	WIRING HARNESS TAIL	TATA spare parts
500754660101	W/H MAIN (LPT2518TC BS-II 24V)	TATA spare parts
500754660102	W/H TAIL (LPT2518TC/48 BS-II)	TATA spare parts
500754707101	PLATE SPEED LIMITER DEVICE MOTOR MTG	TATA spare parts
500754709901	SPEED SENSOR BS3/4	TATA spare parts
500770000101	KIT ASSY.SUPD	TATA spare parts
50079138300RCK	ASSY CAB KIT WITH FITMENT LPK 2518 BS4	TATA spare parts

500826800101	SELECT CABLE COMP.	TATA spare parts
500826800103	ASSY. CABLE SHIFT SYSTEM	TATA spare parts
500826803302	BRACKET	TATA spare parts
500826803701	BRACKET (SELECTION ANCHOR)	TATA spare parts
500826803703	BRACKET (SHIFT)	TATA spare parts
500829000101	ASSY. INTEGRATED PEDAL UNIT	TATA spare parts
500829100107	ASSY. PIPE COMPLETE FROM MASTER CYLINDER	TATA spare parts
500829106002	CLUTCH RELEASE LEVER	TATA spare parts
500829106002AE	CLUTCH RELEASE LEVER 1628	TATA spare parts
500829300102	ASSY. CLUTCH BOOSTER (TYPE-2)	TATA spare parts
500829990103	MAJOR KIT ASSY. PEDAL UNIT	TATA spare parts
500829990104	MINOR KIT ASSY. PEDAL UNIT	TATA spare parts
500829990105	MAJOR KIT ASSY. CMC	TATA spare parts
500829990106	MINOR KIT ASSY. CMC	TATA spare parts
500831000102	ASSY FRAME-LPS4038-ISLE-LHD	TATA spare parts
500831000103	ASSY FRAME-4038.S SOUTH AFRICA	TATA spare parts
500831000106	ASSY FRAME 4038.S-RACING	TATA spare parts
500831000111	FRAME ASSY	TATA spare parts
500831000119	FRAME ASSY	TATA spare parts
500831107113	REINFORCEMENT-LH	TATA spare parts
500831107114	REINFORCEMENT RH	TATA spare parts
500831107147	REINFORCEMENT LH	TATA spare parts
500831107148	REINFORCEMENT RH	TATA spare parts
500831200101	ASSY ENG MTG C/MBR	TATA spare parts
500831207101	ENGINE CROSS MEMBER FRONT	TATA spare parts
500831307111	GUSSET PLATE	TATA spare parts
500831700105	FUPD BRACKET ASSY.COMPLETE RH	TATA spare parts
500831700106	FUPD BRACKET ASSY.COMPLETE LH	TATA spare parts
500831700112	ASSY FUPD BEAM WITH CAB MTG BKT	TATA spare parts
500831700115	ASSLY ENGINE UNDER NOISE SHIELD	TATA spare parts
500832404202	U-BOLT REAR SPRING	TATA spare parts
500834200101	ASSEMBLY SUB-STRUCTURE FOR FIFTH WHEEL C	TATA spare parts
500834200102	ASSEMBLY FIFTH WHEEL COUPLING AND CORRUG	TATA spare parts
500834207107	BRACKET COUPLER - LH	TATA spare parts
500834207108	BRACKET COUPLER - RH	TATA spare parts
500834207111	STOPPER FOR FIFTH WHEEL COUPLING	TATA spare parts
500834207112	MOUNTING PLATE FOR FIFTH WHEEL COUPLING	TATA spare parts
500840106302	ASSY FRONT RIB TYRE 315/80 R 22.5	TATA spare parts
500840300102	BRACKET ASSY SPARE WHEEL CARRIER MTG	TATA spare parts
500841100101	ASSY PROPELLER SHAFT MAIN	TATA spare parts
500841120101	ASSY MAIN SHAFT WITH SLIDING JOINT	TATA spare parts
500841120103	PROPELELRSHAFTASSY DRIVE	TATA spare parts
500841990101	FLANGE YOKE	TATA spare parts
500843139901	BC TYPE 24 DISC REPAIR KIT	TATA spare parts
500843200101	ASSY APU MTG BKT	TATA spare parts
500843200102	ASSY AIR TANK SUPPORT	TATA spare parts
500843200104	BRACKET ASSY APDA MTG	TATA spare parts

500843208201	BRACKET APU MTG.	TATA spare parts
500843700133	LINK ASSY LCRV	TATA spare parts
500843700142	SPRING BRAKE ACTUATOR	TATA spare parts
500843707701	O-RING	TATA spare parts
500843900101	ASSY NYLON PIPE COMPLETE	TATA spare parts
500843900102	ASSY. METAL PIPES	TATA spare parts
500843900111	FRONT MODULATOR TO BRAKE CHAMBER (RH)	TATA spare parts
500843900116	APU TO FRONT AIR TANK (30LI)	TATA spare parts
500843900117	AIR TANK PARKING (20LIT) TO TEE-2	TATA spare parts
500843900132	NYLON PIPE APU PORT 21 TO REAR AIR TANK	TATA spare parts
500843900139	TEE-6 TO RELAY VALVE (R14)	TATA spare parts
500843900140	TEE- 6 TO TRAILER CONTROL VALVE	TATA spare parts
500843900141	ASSY METAL PIPE OIL SEPERATOR TO JOINT	TATA spare parts
500843900142	PIPE METAL ASSY. COMPRESSOR TO HOSE	TATA spare parts
500843900143	ASSY. METAL PIPE FROM JOINT TO HOSE	TATA spare parts
500843900154	METAL PIPE ASSY INT JOINT TO INT JOINT	TATA spare parts
500843900169	ASSY. METAL PIPE THIRD	TATA spare parts
500843900170	ASSY METAL PIPE SECOND	TATA spare parts
500843900171	ASSY METAL PIPE COMPRESSOR END	TATA spare parts
500843900173	ASSY METAL PIPE COMPRESSOR END	TATA spare parts
500843900176	ASSY METAL PIPE	TATA spare parts
500843900178	ASSY METAL PIPE SECOND TO HOSE- THIRD PI	TATA spare parts
500843900179	ASSY METAL PIPE SECOND- SECOND PIPE	TATA spare parts
500843900216	ASSY NYLON PIPE APU CONTROL PORT(4) TO J	TATA spare parts
500843900217	ASSY NYLON PIPE APU TO OIL SEPERATOR	TATA spare parts
500843900244	ASSY. METAL PIPE FROM COMPRESSOR CONTROL	TATA spare parts
500843900250	BUNCH ASSY PIPE	TATA spare parts
500843900301	ASSY. NYLON PIPE BUNCH LPS 4038	TATA spare parts
500843900305	NYLON PIPE BUNCH FOR LPS 4038 RHD SA RAC	TATA spare parts
500843900331	NYLON PIPE ASSY APU CONT PORT TO JOINT	TATA spare parts
500843900379	METAL PIPE ASSY	TATA spare parts
500843900380	METAL PIPE ASSY	TATA spare parts
500843900381	NYLON BUNCH ASSY	TATA spare parts
500843900397	METAL PIPE ASSY APU END- FIFTH PIPE	TATA spare parts
500843910147	PIPE BUNCH ASSY	TATA spare parts
500843910157	BUNCH ASSY PIPE	TATA spare parts
500843920101	ASSY. NYLON PIPE BUNCH FOR LPS 4038 RHD	TATA spare parts
500843990101	SPARE KIT SBA TYPE 24/24	TATA spare parts
500845907101	BRACKET SOLENOID MOUNTING	TATA spare parts
500846108001	HEX SCREW M20X1.5X45	TATA spare parts
500846608201	BASE PLATE RESERVOIR MTG BRACKET	TATA spare parts
500846800107	SUCTION LINE ASM-TYPE I	TATA spare parts
500846800108	PRESSURE LINE ASM-TYPE I	TATA spare parts
500846800109	RETURN LINE ASM G B END-TYPE I	TATA spare parts
500846800110	RETURN LINE ASM RESERVOIR END -TYPE II	TATA spare parts
500846800114	AUXILIARYPIPEASM-INSIDECABIN	TATA spare parts
500847500121	BRACKET ASSY (TDCV TANK)	TATA spare parts

500847500124	RUBBER PACKING STRAP ASSY (TDCV TANK)	TATA spare parts
500847507704	RUBBER PACKING (TDCV TANK MTG)	TATA spare parts
500847600105	FUEL SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
500847600129	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
500847600130	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
500847600131	FUEL SUCTION PIPE ASSY FILTER TO FIP	TATA spare parts
500847600132	FUEL INTER CONNECTION PIPE ASSY	TATA spare parts
500847600133	SUCTION PIPE ASSY	TATA spare parts
500847600134	RETURN FUEL PIPE ASSY	TATA spare parts
500849100101	ASSY. STAY ROD	TATA spare parts
500849100103	ASSY.VERTICAL STRUCTURE FOR-TAIL PIPE SU	TATA spare parts
500849100104	EXHAUST MUFFLER	TATA spare parts
500849100105	ASSY.TAIL PIPE WITH BRACKET	TATA spare parts
500849100111	BRACKET ASSY EGP MTG	TATA spare parts
500849100114	STRAP ASSY FOR MUFFLER	TATA spare parts
500849100116	AIR PIPE AIR TANK TO PUMP	TATA spare parts
500849100126	STAYRODASSY	TATA spare parts
500849100145	BRACKET ASSY	TATA spare parts
500849100161	AIR PIPE LINE AIR OIL FILTER TO DU	TATA spare parts
500849107501	GROMMET UREA TANK	TATA spare parts
500849108206	BRACKET FOR TAIL PIPE CLAMP	TATA spare parts
500849108207	BOTTOM HEAT SHIELD FOR TAIL PIPE	TATA spare parts
500849108208	MIDDLE HEAT SHIELD FOR TAIL PIPE	TATA spare parts
500849108209	TOP HEAT SHIELD FOR TAIL PIPE	TATA spare parts
500849108210	SIDE HEAT SHIELD- FOR MUFFLER	TATA spare parts
500849108227	SIDE HEAT SHIELD FOR SILENCER	TATA spare parts
500849108250	ASBESTOS	TATA spare parts
500849200101	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
500849200108	EXHAUST PIPE INT	TATA spare parts
500849200109	EXHAUST PIPE INTERMEDIATE	TATA spare parts
500849201601	V-BAND CLAMP	TATA spare parts
500849208201	CLAMP-1 FOR EXHAUST PIPE	TATA spare parts
500849208202	CLAMP-2 FOR EXHAUST PIPE	TATA spare parts
500849208203	BRACKET FOR EXHAUST PIPE ON LM	TATA spare parts
500849208215	SHIELD SILENCER	TATA spare parts
500852206302	MUD FLAP REAR	TATA spare parts
500852990102	RUPD ASSY	TATA spare parts
500852990103	SUPD ASSY-LH	TATA spare parts
500852990104	SUPD ASSY-RH	TATA spare parts
500852990108	EXHAUST PIPE (TURBOCHARGER TO FLEXIPIPE)	TATA spare parts
500852990109	EXHAUST PIPE MTG.BKT. 1	TATA spare parts
500852990110	FUEL TANK ASSY	TATA spare parts
500852990111	FUEL TANK MTG STRUCTURE ASSY 2	TATA spare parts
500852990112	FUEL LINE ASSY	TATA spare parts
500852990113	STRAPS FOR FUEL TANKS 4	TATA spare parts
500852990116	BATTERY MTG STRUCTURE ASSY 1	TATA spare parts
500852990117	BATTERY CUTOFF SWITCH MTG BRACKET ASSY	TATA spare parts

500852990118	INSTRUMENT CLUSTER MTG BRACKET ASSY 1	TATA spare parts
500852990119	STEERING COLUMN 1	TATA spare parts
500852990122	FIRE EXTINGUISHER MTG.BKT. 1	TATA spare parts
500852990123	REAR WATER SPRINKLER (JET) MTG. BKTS	TATA spare parts
500852990124	FRONT WATER SPRINKLER (JET) MTG. BKTS LH	TATA spare parts
500852990125	FRONT WATER SPRINKLER (JET) MTG. BKTS	TATA spare parts
500852990126	REAR WATER SPRINKLER (BOTTLE) MTG. BKTS	TATA spare parts
500852990127	FRONT WATER SPRINKLER (BOTTLE) MTG. BKTS	TATA spare parts
500852990128	FRONT WATER SPRINKLER (BOTTLE) MTG. BKTS	TATA spare parts
500852990133	ROUND TAIL LAMPS 2	TATA spare parts
500852990135	SEAT FRAME	TATA spare parts
500852990139	FIRE EXTINGUISHER 1	TATA spare parts
500852990140	ASSY TYRE FOR RACING	TATA spare parts
500852990143	BUMP STOPPER REAR SUSPENSION	TATA spare parts
500852990146	STEERING WHEEL	TATA spare parts
500852990149	BRKT ASSY ABS ECU MTG 1	TATA spare parts
500852990150	BRKT ASSY HAND BRAKE MTG 1	TATA spare parts
500852990153	BRKT ASSY SWITCH MTG 1	TATA spare parts
500852990154	BRACKET ASSY BRAKE LAMP MTG	TATA spare parts
500852990155	GUARD ASSY PROPELLER SHAFT	TATA spare parts
500852990156	HARNESS WIRING REAR SPRINKLERS 1	TATA spare parts
500852990157	HARNESS WIRING BATTERY CUTOFF SWITCH 1	TATA spare parts
500852990158	ASSY CABIN WITH ROLL CAGE	TATA spare parts
500852990159	ASSY RACING SEAT 1	TATA spare parts
500852990160	5 POINT MTG.SEAT BELT 1	TATA spare parts
500852990161	WINDOW CLOTH STRAP (40MM WIDTH) 25 MTS.	TATA spare parts
500852990170	CAP FUEL TANK 1	TATA spare parts
500852990171	WARNING TRIANGLE BATTERY CUT OFF SWITCH	TATA spare parts
500852990177	STEERING RETURN LINE- GB END 1	TATA spare parts
500852990178	STEERING RETURN LINE- RESERVOIR END 1	TATA spare parts
500852990181	MOUNTING BRACKET TAIL LAMP 1	TATA spare parts
500852990195	BRACKET ASSY FENDER FIXING 4	TATA spare parts
500852990196	BRACKET ASSY PROXIMITY MIRROR MTG 1	TATA spare parts
500852990197	FIFTH WHEEL COUPLING DUMMY	TATA spare parts
500852990198	BRACKET ASSY FIFTH WHEEL COUPLING MTG	TATA spare parts
500852990216	SEAT FRAME TOP 1	TATA spare parts
500852990217	BRACKET ASSY FIFTH WHEEL MTG-RH 1	TATA spare parts
500852990218	SPACER BRACKET FENDER MTG. 2	TATA spare parts
500852990219	REBOUND STOPPER 2	TATA spare parts
500852990220	SKIRT LH	TATA spare parts
500852990221	SKIRT RH	TATA spare parts
500852990232	FOOT STEP LH	TATA spare parts
500852990233	FOOT STEP RH	TATA spare parts
500852990238	AERO CORNER ASSY LH	TATA spare parts
500852990239	AERO CORNER ASSY RH	TATA spare parts
500854303303	BRACKET BEEPER MTG	TATA spare parts
500854709901	TATA RECEIVER MODULE	TATA spare parts

500854800102	MUSIC SYSTEM TOUCH SCREEN	TATA spare parts
500854800104	ANTENNA	TATA spare parts
500858903501	MOUNTING BS6	TATA spare parts
500858903503	SOCKET HUB LOCK NUT BS6	TATA spare parts
500858903504	PULLER HUB ASSY BS6	TATA spare parts
500858903505	PULLER ASSY BS6	TATA spare parts
500858903506	DRIFT BS6	TATA spare parts
500858903508	DRIFT BS6	TATA spare parts
500931700107	ASSY SHIELD UNDER ENGINE	TATA spare parts
500931707101	REINFORCEMENT	TATA spare parts
500931707701	SHIELD UNDER ENGINE	TATA spare parts
500932100103	ASSY. SPRING HANGER BRACKET MIDDLE RH	TATA spare parts
500932100104	ASSY MIDDLE SPRING HANGER BKT LH	TATA spare parts
500932100106	ASSY. SPRING HANGER BRACKET REAR	TATA spare parts
500932100122	ASSY BUMP STOPPER	TATA spare parts
500932100125	BUMP STOPPER ASSY FRT FWD	TATA spare parts
500932104201	U BOLT	TATA spare parts
500932104202	U BOLT M22X1.5X195	TATA spare parts
500932104203	U BOLT	TATA spare parts
500932307102	BRACKET SHOCK ABSORBER FRONT	TATA spare parts
500932307103	BRACKET SHOCK ABSORBER FRONT	TATA spare parts
500932403203	HEX FL BOLT M12X1.75X55	TATA spare parts
500932403205	HEX FL BOLT M18X2.5X100	TATA spare parts
500932803301	BRACKET ANTI ROLL BAR (TOP MTG)	TATA spare parts
500933800102	ASSY.TIE ROD COMP.	TATA spare parts
500933805103	TIE ROD ARM LH	TATA spare parts
500933805104	TIE ROD ARM RH	TATA spare parts
500940300111	ASSY. BRACKET -SPARE WHEEL CARRIER	TATA spare parts
500940300114	ASSY.HOLDING BRACKET (SPARE WHEEL)	TATA spare parts
500940301601	ASSY.WORM GEAR BOX	TATA spare parts
500940305601	HANDLE	TATA spare parts
500940309901	POLYESTER ROPE	TATA spare parts
500941107101	GUARD P/SHAFT REAR	TATA spare parts
500941107102	BRACKET P/SHAFT GUARD MIDDLE	TATA spare parts
500941107103	GUARD-P/SHAFT REAR	TATA spare parts
500941107104	GUARD P/SHAFT REAR	TATA spare parts
500941300105	BRKT ASSY P/SHAFT MTG REAR	TATA spare parts
500942100111	ASSY. CHAMBER MOUNTING BRACKET - LH	TATA spare parts
500942100112	ASSY. CHAMBER MOUNTING BRACKET - RH	TATA spare parts
500946300101	1ST DRAG LINK ASM	TATA spare parts
500946300102	1ST RELAY ROD ASM	TATA spare parts
500946300103	2ND RELAY ROD ASM	TATA spare parts
500946300104	2ND DRAG LINK ASM	TATA spare parts
500946304101	RELAY ARM	TATA spare parts
500946304102	IDLER ARM	TATA spare parts
500946304104	PITMAN ARM	TATA spare parts
500946304106	IDLER ARM	TATA spare parts



500946304110	PITMAN ARM LPK 3138-LHD	TATA spare parts
500946304111	IDLER ARM-LPK 3138 LHD	TATA spare parts
500946304112	RELAY ARM	TATA spare parts
500946304113	IDLER ARM	TATA spare parts
500946600101	GEAR PUMP	TATA spare parts
500946600103	P/CYL ASM	TATA spare parts
500946600116	POWER CYLINDER ASM. BS3/4	TATA spare parts
500946700101	SPACER RELAY ARM MTG BRKT	TATA spare parts
500946703301	BRKT-RELAY ARM MOUNTING	TATA spare parts
500946703303	IDLER ARM MTG BRKT	TATA spare parts
500946703304	BRKT-POWER CYLINDER MTG-WO-EQL-F2 FRAME	TATA spare parts
500946703305	BRKT-RELAY ARM MOUNTING LHD	TATA spare parts
500946708201	RELAY ARM HUB COVER	TATA spare parts
500947500101	FUEL TANK MOUNTING BRACKET	TATA spare parts
500947606803	VOSS ADAPTER M12 NG8	TATA spare parts
500949100109	FLEX CONNECTOR	TATA spare parts
501029300101	ASSY. CLUTCH BOOSTER BS3/4	TATA spare parts
501079	SPRING - THROTTLE RETURN	TATA spare parts
501100990102	ASSY KIT FULLY BUILD SIGNA CAB 4923 BS I	TATA spare parts
501100990102IP	ASSY. CABIN KIT SIGNA SUNRISE ORAG BS4	TATA spare parts
501100990102JS	ASSY. CABIN KIT SIGNA TITAN WH BS4	TATA spare parts
501100990103	ASSY FULLY BUILD SIGNA CAB 4923 AC	TATA spare parts
501100990103IP	ASSY. CABIN KIT SIGNA SUNRISE ORAG BS4	TATA spare parts
501100990103JS	ASSY. CABIN KIT SIGNA TITANIUM WHITE BS4	TATA spare parts
501100990104	ASSY FULLY BUILD SIGNA CAB 4923 BL	TATA spare parts
501100990104IP	ASSY. CABIN KIT SIGNA SUNRISE ORAG BS4	TATA spare parts
501100990104JS	ASSY. CABIN KIT SIGNA TITANIUM WHITE BS4	TATA spare parts
501100990106	SPARE KIT VTS & EMERG HELP SWITCH LPS492	TATA spare parts
501100990107	RETRO PART FITMENT KIT FOR SIGNA 4923.S	TATA spare parts
501124200102	ASSY.BRACKET-LH (ENG.MTG REAR-BOTTOM)	TATA spare parts
501124200103	ASSY.BRACKET-RH (ENG.MTG REAR-BOTTOM)	TATA spare parts
501124203701	BRACKET ENGINE MTG REAR-LH BS6	TATA spare parts
501124203702	BRACKET ENGINE MTG REAR-RH BS6	TATA spare parts
501124203703	BRACKET ENGINE MTG REAR FRAME LH BS6	TATA spare parts
501124203704	BRACKET ENGINE MTG REAR FRAME RH BS6	TATA spare parts
501126800102	ASSY TURNING TUBE(W/O BALL JOINT)	TATA spare parts
501126800109	ASSY TURNING TUBE (W/O BALL JOINT)	TATA spare parts
501126800110	ASSY. BRACKET	TATA spare parts
501126807102	BRACKET (LINK ROD MTG FOR OLD HSG)	TATA spare parts
501126807103	BRACKET (LINK ROD MTG-FOR NEW HSG)	TATA spare parts
501126807901	LINK ROD	TATA spare parts
501129100102	ASSY. CLUTCH LEVER	TATA spare parts
501129100103	ASSY. FORK W/CLUTCH BOOSTER BS2/3	TATA spare parts
501129100107	ASSY. CLUTCH FLUID RESERVOIR WITH CLAMP	TATA spare parts
501129106001	CLUTCH RELEASE LEVER	TATA spare parts
501129108202	CLAMP (CLUTCH FLUID RESERVOIR) BS6	TATA spare parts
501129150102	ASSY. TUBE (6 O.D. X 2450 LG.)	TATA spare parts

501129200101	BRACKET ASSY.(FOR CLUTCH BOOSTER MTG.)	TATA spare parts
501129300101	HYD PIPE LINE (FROM M.CYL TO C.B.PIPE-2	TATA spare parts
501129305801	HOSE PIPE(FROM RES. TO MC)	TATA spare parts
501129500101	ASSY.CTRL.MTG.BRKT WITH M.CYL.MTG.BRKT.	TATA spare parts
501129990101	CLUTCH BOOSTER REPAIR KIT	TATA spare parts
501130100101	ASSY. PUSH ROD (L = 383)	TATA spare parts
501130100102	ASSY. BRACKET (ON ENGG. RFOB)	TATA spare parts
501130100103	ASSY. BRKT.(ENGG. STOP CABLE MTG.)	TATA spare parts
501130103302	L-BRACKET (RETURN SPG.MTG-FIP STP.LEVER)	TATA spare parts
501131000101	ASSY. FRAME 4923 (CAST 6 HOLE BKT) BS2/3	TATA spare parts
501131000104	ASSY. FRAME LPS4923	TATA spare parts
501131000105	ASSY. FRAME WITH FITMENT BS3/4	TATA spare parts
50113100010504	ASSY FRAME 4923.S(FAB 4 HOLE BRKT)BS3/4	TATA spare parts
50113100010506	ASSY FRAME (CAST TYPE 6 HOLE BRKT)	TATA spare parts
501131000108	FRAME ASSY	TATA spare parts
501131000109	ASSY. FRAME WITH FITMENT BS4	TATA spare parts
501131000110	ASSY. FRAME LPS4923	TATA spare parts
501131000111	ASSY. FRAME WITH FITMENT BS4	TATA spare parts
501131000115	ASSY. FRAME WITH FITMENT BS2/3	TATA spare parts
501131107103	REINFORCEMENT (LONG MEMBER) - RH	TATA spare parts
501131107104	REINFORCEMENT (LONG MEMBER) - LH	TATA spare parts
501131200101	GEAR BOX MOUNTING BRACKET	TATA spare parts
501131200102	ASSY. BRACKET - LH (G.B MTG.)	TATA spare parts
501131200103	ASSY. BRACKET - RH (G.B MTG.)	TATA spare parts
501131200106	DOUBLE X-MBR ASSY. (6TH CROSS MEMBER)	TATA spare parts
501131200107	ASSY. 5TH CROSS MEMBER	TATA spare parts
501131200108	ASSY. CHANNEL (SPARE WHEEL SUPPORT)	TATA spare parts
501131200109	RADIATOR MOUNTING BRKT-RH (FRT.SPR.BRKT)	TATA spare parts
501131200110	ASSY BRACKET-RH (CHEQUERED SUPPORT)	TATA spare parts
501131200112	ASSY BRACKET-LH(CHEQUERED SUPPORT)	TATA spare parts
501131200113	RADIATOR MOUNTING BRKT-LH (FRT.SPR.BRKT)	TATA spare parts
501131200114	ASSY. ENGINE CROSS MEMBER - REAR	TATA spare parts
501131200116	ASSY. 4TH CROSS MEMBER	TATA spare parts
501131200120	ASSY. CHANNEL (FOR BATTERY SUPPORT)	TATA spare parts
501131200123	ASSY RADIATOR GRILL SUPPORT FRONT RH	TATA spare parts
501131200124	ASSY.RADIATOR GRILL SUPPORT FRONT LH	TATA spare parts
501131200125	ASSY RADIATOR GRILL SUPPORT REAR RH	TATA spare parts
501131200126	ASSY RADIATOR GRILL SUPPORT REAR LH	TATA spare parts
501131200129	ASSY RADIATOR PROTECTIVE GRILL	TATA spare parts
501131200133	ASSY.BRKT.FOR 5TH SUPPORT ON L.M-RH	TATA spare parts
501131200134	ASSY.BRKT.FOR 5TH SUPPORT ON L.M-LH	TATA spare parts
501131200135	ASSY.BRKT.FOR 5TH SUPPORT ON G.B	TATA spare parts
501131200159	CROSS MEMBER ASSY TUBULAR	TATA spare parts
501131200167	ASSY.CHEQUERED PLATE	TATA spare parts
501131200171	CROSS MEMBER ASSY WITH GUSSETE	TATA spare parts
50113120017160	STAGE PART 50113120017160	TATA spare parts
501131200172	L-BRACKET ASSY LH	TATA spare parts

501131200173	L-BRACKET ASSY RH	TATA spare parts
501131200179	CHANNEL ASSY BATTERY SUPPORT	TATA spare parts
501131200180	BRACKET ASSY WITH PLATE LH	TATA spare parts
501131200181	BRACKET ASSY WITH PLATE RH	TATA spare parts
501131200193	CROSS MEMBER ASSY WITH GUSSET	TATA spare parts
501131207103	SUPPORT - TOP (6TH CROSS MEMBER)	TATA spare parts
501131207104	SUPPORT - BOTTOM (6TH CROSS MEMBER)	TATA spare parts
501131207105	C-CHANNEL (6TH CROSS MEMBER)	TATA spare parts
501131207106	REINFORCEMENT (SUB-STRUCTURE - REAR)	TATA spare parts
501131207107	REINFORCEMENT (SUB-STRUCTURE - MIDDLE)	TATA spare parts
501131207108	REINFORCEMENT (SUB-STRUCTURE - FRONT)	TATA spare parts
501131207109	Z-BRACKET - RH (V-WHEEL COUPLING)	TATA spare parts
501131207110	Z-BRACKET - LH (V-WHEEL COUPLING)	TATA spare parts
501131207120	TOP C CHANNEL (GEAR BOX MOUNTING)	TATA spare parts
501131207121	BOTTOM C CHANNEL (GEAR BOX MOUNTING)	TATA spare parts
501131207126	CHEQUERED PLATE	TATA spare parts
501131207135	CROSS MEMBER (BRIDGE)	TATA spare parts
501131207142	Z BRACKET	TATA spare parts
501131207143	SUPPORT PLATE - RH (FOR Z BRKT.)	TATA spare parts
501131207144	CHEQUERED PLATE	TATA spare parts
501131207145	SUPPORT PLATE - LH (FOR Z BRKT.)	TATA spare parts
501131207146	STEEL CHEQUERED PLATE (BATTERY MTG.)	TATA spare parts
501131207147	STEEL CHEQUERED PLATE	TATA spare parts
501131208217	PACKING PLATE BS6	TATA spare parts
501131217113	L-PLATE LH	TATA spare parts
501131217114	L-PLATE RH	TATA spare parts
501131217126	PLATE BATTERY MTG	TATA spare parts
501131307101	REINFORCEMENT - RH (FRONT SPRING BRKT.)	TATA spare parts
501131307102	REINFORCEMENT - LH (FRONT SPRING BRKT.)	TATA spare parts
501131307106	SUPPORT REAR SPRING MTG RH	TATA spare parts
501131307107	SUPPORT REAR SPRING MTG LH	TATA spare parts
501131307111	REINFORCEMENT RH	TATA spare parts
501131307112	REINFORCEMENT LH	TATA spare parts
501131307119	SUPPORT REAR SPRING MTG LH	TATA spare parts
501131307120	SUPPORT REAR SPRING MTG RH	TATA spare parts
501131307121	SUPPORT REAR SPRING MTG RH	TATA spare parts
501131307122	SUPPORT REAR SPRING MTG LH	TATA spare parts
501131307123	SUPPORT CROSS MEMBER MTG RH	TATA spare parts
501131307124	SUPPORT CROSS MEMBER MTG LH	TATA spare parts
501131540102	BATTERY BOX ASSY	TATA spare parts
501131543301	C-CHANNEL BATTERY FIXING TOP	TATA spare parts
501131600101	ASSY. RAMP - RH (V-WHEEL COUPLING)	TATA spare parts
501131600102	ASSY. RAMP - LH (V-WHEEL COUPLING)	TATA spare parts
501131600103	ASSY MOUNTING PLATE(5TH WHEEL COUPLING)	TATA spare parts
501131600104	ASSY MTG PLATE WITH 5TH WHL COUPLING	TATA spare parts
501131600112	RAMP ASSY 5TH WHEEL COUPLING RH	TATA spare parts
501131600113	RAMP ASSY 5TH WHEEL COUPLING LH	TATA spare parts

501131600115	PLATE ASSY 5TH WHEEL COUPLING	TATA spare parts
501131607128	MOUNTING PLATE (FIFTH WHEEL COUPLING)	TATA spare parts
501131608701	HELICAL COMPRESSION SPRING (G B MTG.)	TATA spare parts
501131700101	ASSY. BOTTOM SHIELD (RADIATOR SIDE)	TATA spare parts
501131700102	ASSY. BOTTOM SHIELD (ENGINE SIDE)	TATA spare parts
501131700104	ASSY. SUPPORT BRKT.-LH (ENGINE SIDE)	TATA spare parts
501131700105	ASSY. SUPPORT BRKT.-RH (ENGINE SIDE)	TATA spare parts
501131700106	ASSY SUPPORT BRKT.-RH (FRT. TRANS SIDE)	TATA spare parts
501131700107	ASSY SUPPORT BRKT.-LH (FRT. TRANS SIDE)	TATA spare parts
501131700113	ASSY. BRKT - LH (CAB REAR SHIELD)	TATA spare parts
501131700114	ASSY. NOISE SHIELD (CAB REAR)	TATA spare parts
501131700115	ASSY. BRKT - RH (CAB REAR SHIELD)	TATA spare parts
501131700116	ASSY. BOTTOM SHIELD (ENGINE SIDE)	TATA spare parts
501131700117	ASSY NOISE SHIELD (CAB REAR)	TATA spare parts
501131700124	ASSY MTG BRACKET (CAB REAR NOISE SHIELD)	TATA spare parts
501131700133	SUPPORT BRACKET CHEQUERED PLATE	TATA spare parts
501132100117	AXLE STOPPER ASSY BS6	TATA spare parts
501132100118	1ST LEAF WITH BUSH ASSY BS6	TATA spare parts
501132100123	PARABOLIC LEAF SPRING ASSY FRONT BS6	TATA spare parts
501132100130	PARABOLIC LEAF SPRING ASSY FRONT BS6	TATA spare parts
501132100131	MAIN LEAF ASSY WITH BUSH BS6	TATA spare parts
501132103203	CENTER BOLT BS6	TATA spare parts
501132103205	CENTER BOLT BS6	TATA spare parts
501132104204	U-BOLT BS6	TATA spare parts
501132104205	SPRING CLIP BS6	TATA spare parts
501132106501	NYLOC NUT BS6	TATA spare parts
501132107117	3RD LEAF BS6	TATA spare parts
501132107118	1ST LEAF BS6	TATA spare parts
501132107120	2ND LEAF BS6	TATA spare parts
501132107121	CASTERPLATE BS6	TATA spare parts
501132107136	3RD LEAF BS6	TATA spare parts
501132107138	2ND LEAF BS6	TATA spare parts
501132107139	CASTER PLATE BS6	TATA spare parts
501132108601	CENTER PAD BS6	TATA spare parts
501132300101	BRACKET ASSY SHOCK ABSORBER MTG UPPER	TATA spare parts
501132400101	REAR TANDEM BOGIE SUSP COMP.	TATA spare parts
501132400102	ASSLY REAR TANDEM SUSP COMPLETE	TATA spare parts
501132400103	ASSLY-TRUNNION SUPPORT	TATA spare parts
501132400105	LEAF SPRING ASSY	TATA spare parts
501132400106	RUBBER BOLSTER SPRING	TATA spare parts
501132400107	ASSLY-TRUNNION PIVOT HOUSING	TATA spare parts
501132400108	CAP-END CLOSURE & SEAL	TATA spare parts
501132400110	LINK TORQUE ROD	TATA spare parts
501132400111	TORQUE ROD BAR PIN BUSH	TATA spare parts
501132400113	LINK A FRAME	TATA spare parts
501132400114	BELL CRANK LEVER ASSY	TATA spare parts
501132400115	ASSY. CENTER BUSH -V ROD BS2/3	TATA spare parts

501132400115AE	CENTER BUSH ASSLY-V ROD 1828	TATA spare parts
501132400116	ASSLY-ADAPTOR PLATE & DOWEL	TATA spare parts
501132400117	ASSLY-ADAPTOR PLATE	TATA spare parts
501132400118	KIT-BELL CRANK LEVER & LINK ROD & SHACKL	TATA spare parts
501132400120	ASSEMBLY 26TON BOGIE SUSPENSION 4923.S	TATA spare parts
501132400148	TORQUE ROD ASSY	TATA spare parts
501132400149	V-ROD ASSY	TATA spare parts
501132400151	SPRING ASSY REAR	TATA spare parts
501132400152	1ST LEAF SPRING ASSY WITH BUSH	TATA spare parts
501132400162	BRACKET ASSY SHOCK ABSORBER MTG LOWER	TATA spare parts
501132400167	RUBBER BUSH ASSY BS6	TATA spare parts
501132400176	RUBBER BOLSTER ASSY BS6	TATA spare parts
501132403201	HEX FLANGE BOLT M14X2X35	TATA spare parts
501132403202	HEX FLANGE BOLT M14X2X55 109	TATA spare parts
501132403203	HEX FLANGE BOLT M14X2X65 109	TATA spare parts
501132403204	HEX FLANGE BOLT M14X2X85 109	TATA spare parts
501132403205	HEX FLANGE BOLT M14X2X180 109	TATA spare parts
501132403206	HEX FLANGE BOLT M16X2X50 199	TATA spare parts
501132403207	HEX FLANGE BOLT M16X2X60 109	TATA spare parts
501132403208	HEX FLANGE BOLT M18X25X60 109	TATA spare parts
501132403209	HEX FLANGE BOLT M20X2.5X75	TATA spare parts
501132403210	HEX FLANGE BOLT M20X25X130 109 BS2/3/4	TATA spare parts
501132403211	HEX FLANGE BOLT M20X25X250 109	TATA spare parts
501132403212	HEX FLANGE BOLT M12X175X65 109	TATA spare parts
501132403213	HEX FLANGE BOLT M14X2X60 10.9	TATA spare parts
501132403214	HEX FL BOLT DIN EN 1665 M14X2X170-10.9	TATA spare parts
501132403217	HEX FLANGE BOLT M16X2X90 10.9	TATA spare parts
501132403218	HEX FLANGE BOLT M18X2.5X70 10.9	TATA spare parts
501132403221	HEX FLANGE BOLT M20X2.5X65 10.9	TATA spare parts
501132403222	HEX FL BOLT DIN EN 1665 M14X2X70-10.9	TATA spare parts
501132403223	HEX FLANGE BOLT M20X2.5X235 10.9	TATA spare parts
501132403224	HEX FLANGE BOLT M20X2.5X175 10.9	TATA spare parts
501132403230	BOLT	TATA spare parts
501132403308	SPRING HANGER BRACKET REAR LH	TATA spare parts
501132403309	SPRING HANGER BRACKET REAR RH	TATA spare parts
501132403401	BUSHING POLYMER BS2/3	TATA spare parts
501132403402	BUSH	TATA spare parts
501132403403	BUSH	TATA spare parts
501132403701	AXLE CLAMP UPPER	TATA spare parts
501132403702	BRACKET-TORQUE ROD MTG (BOTTOM-RH)	TATA spare parts
501132403703	BRACKET-TORQUE ROD MTG (BOTTOM-LH)	TATA spare parts
501132403704	BRACKET-V ROD MTG (FWD-AXLE)	TATA spare parts
501132403705	BRACKET-V ROD MTG (RWD AXLE)	TATA spare parts
501132403707	TOP PAD	TATA spare parts
501132403708	TRUNNION PIVOT HOUSING	TATA spare parts
501132403709	CORNER BRACKET	TATA spare parts
501132403710	AXLE STOP	TATA spare parts

501132403712	PLATE CORNER BRACKET	TATA spare parts
501132403716	BRACKET-V ROD MTG (FWD AXLE)	TATA spare parts
501132403717	BRACKET-V ROD MTG (RWD AXLE)	TATA spare parts
501132403728	SHACKLE BELL CRANK-CASTING	TATA spare parts
501132403755	BRACKET PIVOT MTG BS6	TATA spare parts
501132403756	BRACKET PIVOT MTG BS6	TATA spare parts
501132403757	BRACKET ARTICULATION STOPPER	TATA spare parts
501132403760	TRUNNION BRACKET BS6	TATA spare parts
501132404201	M24 X 2.0 CLASS 10.9 U BOLT	TATA spare parts
501132404201AE	UBOLT M24X2 - REAR SPRING 1828	TATA spare parts
501132404203	SPRING CLIP	TATA spare parts
501132404204	SPRING CLIP	TATA spare parts
501132404205	SPRING CLIP	TATA spare parts
501132404301	CIRCLIP ROD END	TATA spare parts
501132404302	EXTERNAL CIRCLIP	TATA spare parts
501132404303	INTERNAL CIRCLIP	TATA spare parts
501132404803	DOWEL	TATA spare parts
501132406501	HEX FLANGE NUT SELF LOCKING M12X1.75	TATA spare parts
501132406502	HEX FLANGE NUT SELF LOCKING M14X2 10.9	TATA spare parts
501132406503	HEX FLANGE NUT SELF LOCKING M16X2	TATA spare parts
501132406504	HEX FLANGE NUT SELF LOCKING M18X2.5	TATA spare parts
501132406505	HEX FLANGE NUT SELF LOCK M20X2.5 BS2-6	TATA spare parts
501132406506	M24 X 2 AMPT HEX NUT	TATA spare parts
501132406702	LEVER PIN	TATA spare parts
501132407101	RETAINER PLATE A-FRAME	TATA spare parts
501132407111	SPACER PLATE RUBBER BOLSTER	TATA spare parts
501132407142	2ND LEAF	TATA spare parts
501132407143	3RD LEAF	TATA spare parts
501132407144	4TH LEAF	TATA spare parts
501132407145	5TH LEAF	TATA spare parts
501132407146	6TH LEAF	TATA spare parts
501132407147	7TH LEAF	TATA spare parts
501132407148	8TH LEAF	TATA spare parts
501132407149	9TH LEAF	TATA spare parts
501132407162	BRACKET SHOCK ABSORBER MTG UPPER	TATA spare parts
501132407801	SEAL - TRUNNION	TATA spare parts
501132408201	PLUG - END CAP	TATA spare parts
501132408202	END CAP PIVOT HOUSING BS6	TATA spare parts
501132408604	SPACER	TATA spare parts
501132409201	THRUST WASHER - INNER	TATA spare parts
501132409202	THRUST WASHER - OUTER	TATA spare parts
501132409203	M24 HARDENED WASHER	TATA spare parts
501132409205	THRUST WASHER BS6	TATA spare parts
501132409902	KIT-SHOCK ABSORBER	TATA spare parts
501133000101	ASSY.FRONT AXLE WITH BRAKES-4923	TATA spare parts
501133000102	ASSY. FRONT AXLE WITH BRAKES (ABS)	TATA spare parts
501133000107	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts

501133105102	FRONT AXLE BEAM	TATA spare parts
501133200101	STUB AXLE ASSY BS6-PH2	TATA spare parts
501133200102	STUB AXLE ASSY BS6-PH2	TATA spare parts
501134100101	ASSY.V.WHEEL.COUPLING	TATA spare parts
501134100103	STOPPER FIFTH WHEEL COUPLING BS6	TATA spare parts
501134100106	STOPPER FIFTH WHEEL COUPLING BS6	TATA spare parts
501134100110	FIFTH WHEEL COUPLING ASSY BS6	TATA spare parts
501134200102	RAMP ASSY FIFTH WHEEL COUPLING RH	TATA spare parts
501134200103	RAMP ASSY FIFTH WHEEL COUPLING LH	TATA spare parts
501134200105	GUIDE BRACKET ASSY LH	TATA spare parts
501134200106	GUIDE BRACKET ASSY RH	TATA spare parts
501134200110	C-CHANNEL ASSY FIFTH WHEEL MTG STRUCTURE	TATA spare parts
501134200111	SUBSTRUCTURE ASSY FIFTH WHEEL COUPLING	TATA spare parts
501134200112	FIFTH WHEEL ASSY WITH STRUCTURE	TATA spare parts
501134207115	CORRUGATED PLATE FIFTH WHEEL MTG	TATA spare parts
501134207118	L-BRACKET FIFTH WHEEL SUBSTRUCTURE LH	TATA spare parts
501134207119	L-BRACKET FIFTH WHEEL SUBSTRUCTURE RH	TATA spare parts
50113638000R40SJ	ASSY. CAB COMPLETE SIGNA 4923.S BS3	TATA spare parts
501140106703	HUB PIN	TATA spare parts
501140300106	BRACKET ASSY	TATA spare parts
501140307102	PLATE	TATA spare parts
501141106101	LOCKING PLATE (150 PCD 70 DEG. & M14)	TATA spare parts
501141120101	ASSY.PROP SHAFT FRONT(1245 CLOSED)	TATA spare parts
501141120102	ASSY.PROP SHAFT-IN-AXL(550 CLOSED)	TATA spare parts
501141120103	CROSS ASSY.	TATA spare parts
501141120104	CROSS ASSY (FRONT AND REAR)	TATA spare parts
501141120105	SHORT FORK, TUBE & REAR HOUSING ASSY.	TATA spare parts
501141120106	DUST COVER	TATA spare parts
501141120107	ASSY. PROP. SHAFT-INT-AXL(565 CL) BS2/3	TATA spare parts
501141120108	LONG FORK SUB ASSY	TATA spare parts
501141120109	SHORT FORK AND REAR HOUSING ASSY	TATA spare parts
501141120110	CROSS ASSY	TATA spare parts
501141120111	ASSY.PROP SHAFT-INT.-AXL(600 CLOSED)	TATA spare parts
501141120112	SHORT FORK & REAR HOUSING ASSY.	TATA spare parts
501141120113	ASSY.PROP SHAFT FRONT(1210 CLOSED)	TATA spare parts
501141120115	ASSY. PROP. SHAFT-INT-AXL(625-CL)BS2/3/4	TATA spare parts
501141120116	LONG FORK SUB ASSY	TATA spare parts
501141120117	SHORT FORK AND REAR HOUSING ASSY	TATA spare parts
501141120118	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
501141120119	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
501141120130	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
501141120131	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
501141125101	FLANGE YOKE	TATA spare parts
501141125102	FLANGE YOKE (FRONT AND REAR)	TATA spare parts
501141125103	SHORT FORK	TATA spare parts
501141125104	SHORT FORK(FRONT AND REAR)	TATA spare parts
501141125105	REAR HOUSING WITH GN	TATA spare parts

501141125106	REAR HOUSING (REAR)	TATA spare parts
501141125107	LONG FORK	TATA spare parts
501141125108	LONG FORK (REAR)	TATA spare parts
501141125109	FLANGE YOKE	TATA spare parts
501141129905	FLANGE YOKE	TATA spare parts
501141990101	KIT-PROPELLER SHAFT	TATA spare parts
501142100102	BRAKE CHAMBER TYPE 27	TATA spare parts
501142300108	BRAKE ASSY- REAR	TATA spare parts
501142300111	BRAKE ASSY- REAR	TATA spare parts
501142300113	BRACKET ASSY- CAM SHAFT- LH	TATA spare parts
501142300114	BRACKET ASSY- CAM SHAFT- RH	TATA spare parts
501142300124	BRAKE ASSY- REAR FWD	TATA spare parts
501142300128	BRAKE ASSY- REAR FWD	TATA spare parts
501142303703	BRAKE DRUM	TATA spare parts
501142303703AE	BRAKE DRUMS REAR 2523	TATA spare parts
501142303704	BRKT ASSY LH	TATA spare parts
501142303705	BRKT ASSY RH	TATA spare parts
501142305104	S-CAM SHAFT LH.	TATA spare parts
501142305105	S-CAM SHAFT RH.	TATA spare parts
501143200102	ASSY. STRAP COMPLETE(FOR AIR TANK MTG)	TATA spare parts
501143200103	ASSY. AIR TANK (30LX3) BS2/3/4	TATA spare parts
501143200104	ASSY BRACKET (AIR TANK MTG.)	TATA spare parts
501143200105	AIR TANK SUPPORT CHANNEL ASSY.(LPS4923)	TATA spare parts
501143200106	SUB ASSY. AIR TANK(30LX2)-LPS4923	TATA spare parts
501143200108	ASSY. AIR TANK WITH BRACKET (15 LTRS.)	TATA spare parts
501143200109	ASSY. AIR TANK WITH BRACKET (15 LTRS.)	TATA spare parts
501143200130	BRACKET ASSY LCRV LINK MTG ON AXLE	TATA spare parts
501143200137	BRACKET ASSY LCRV MTG	TATA spare parts
501143400004	TRANSFER LABLE LCRV BS6	TATA spare parts
501143400101	ASSY. LINK-FOR LCRV(LPS4923)	TATA spare parts
501143400102	LINK ASSY LCRV	TATA spare parts
501143406001	PULL ROD	TATA spare parts
501143700103	AUTO LOAD SENSING VALVE(VOSS)	TATA spare parts
501143700114	PURGE TANK (SUITABLE FOR VOSS)- 5 LTR.	TATA spare parts
501143700115	NON-RETURN VALVE VOSS	TATA spare parts
501143700116	REPAIR KIT BRAKE CHAMBER (TYPE-27)	TATA spare parts
501143700117	SERVICE KIT (SERVICE SIDE) MAJOR KIT	TATA spare parts
501143700118	SERVICE KIT (SERVICE SIDE) MINOR KIT	TATA spare parts
501143700119	SERVICE KIT (PARKING SIDE) MAJOR KIT-2K0	TATA spare parts
501143700120	SERVICE KIT (PARKING SIDE) MINOR KIT	TATA spare parts
501143700132	KIT-BRAKE CHAMBER	TATA spare parts
501143700143	RELAY VALVE & MODULATOR VALVE ASSY BS6	TATA spare parts
501143700145	MODULATOR VALVE BS6	TATA spare parts
501143703304	BRACKET BS6	TATA spare parts
501143707101	BRACKET RELAY VALVE MTG	TATA spare parts
501143708601	SPACER (FOR ALSV MTG. BRKT.)	TATA spare parts
501143900101	ASSY. LCRV LEVER(LPS4923)	TATA spare parts



501143900116	SET ASSY.NYLON PIPE WITH PLASTIC CONN.	TATA spare parts
501143900121	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
501143900127	NYLON PIPE BUNCH COMPLETE	TATA spare parts
501143900175	PIPE ASSY COMP 2ND JOINT-1 TO JOINT-2	TATA spare parts
501143900176	PIPE ASSY METAL JOINT-2 TO AIR DRYER	TATA spare parts
501143900178	BRACKET (FOR LCRV MTG.)	TATA spare parts
501143900195	BUNCH ASSY PIPE	TATA spare parts
501143900199	BUNCH ASSY PIPE	TATA spare parts
501143903301	MOUNTING BRACKET(QRV)-LPS4923	TATA spare parts
501143906101	BRACKET-FOR LCRV MOUNTING(LPS4923)	TATA spare parts
501143906102	BRACKET FOR TRAILER CONTROL VALVE MTG.	TATA spare parts
501143906801	COUPLING BODY (FOR COMP. OUTLET)	TATA spare parts
501143910106	BUNCH ASSY PIPE	TATA spare parts
501143920110	BUNCH PIPE ASSY	TATA spare parts
501143930104	METAL PIPE ASSY INT JOINT TO INT JOINT	TATA spare parts
501143930105	METAL PIPE ASSY INT JOINT TO AIR DRYER	TATA spare parts
501143930130	METAL PIPE ASSY INT JOINT TO INT JOINT	TATA spare parts
501143930169	PIPE BUNCH ASSY COMPLETE	TATA spare parts
501143930189	PIPE BUNCH ASSY	TATA spare parts
501143930191	BUNCH ASSY PIPE	TATA spare parts
501143940114	METAL PIPE ASSY INT JOINT	TATA spare parts
501143990101	RETROFITMENT KIT(LPS4923 WITH GB)	TATA spare parts
501143990106	MINORSPAREKIT-PARKING BS6	TATA spare parts
501143990107	MAJORSPAREKIT-PARKING BS6	TATA spare parts
501146100101	BRACKET STG. GEAR BOX MTG. BS1/3	TATA spare parts
501146100102	RUBBER BELLOW ASSY BS6	TATA spare parts
501146100109	COLUMN ASSY UPPER	TATA spare parts
501146100111	STEERING COLUMN ASSY TILT & TELESCOPIC	TATA spare parts
501146100112	INTERMEDIATE SHAFT ASSY BS6	TATA spare parts
501146103401	BUSH	TATA spare parts
501146107701	RUBBER BELLOW	TATA spare parts
501146108201	CLAMPING RING	TATA spare parts
501146150102	KIT ASSY.P/STG.PIPE LINES & CONNECTOR	TATA spare parts
501146150104	KIT ASSY PIPES POWER STG. LPS 4923	TATA spare parts
501146150105	KIT ASSY PIPES POWER STG. LPS 4923	TATA spare parts
501146150106	KIT ASSY PIPES	TATA spare parts
501146200101	STEERING SPINDLE ASSY TOP BS6	TATA spare parts
501146208201	CUP SPRING SEAT	TATA spare parts
501146600101	ASSY.MTG BKT POWER STG FLUID RESERVOIR	TATA spare parts
501146600103	POWER STEERING PUMP ASSY	TATA spare parts
501146703302	BRACKET STG GEAR BOX MTG	TATA spare parts
501146800104	SUCTION LINE HOSE ASSY.	TATA spare parts
501146800113	SUCTION LINE ASSY	TATA spare parts
501146800114	RETURN LINE ASSY (RESERVOIR SIDE)	TATA spare parts
501146800120	SUCTION LINE ASSY	TATA spare parts
501146800121	RETURN LINE ASSY	TATA spare parts
501146800123	RETURN LINE ASSY RESERVOIR END	TATA spare parts

501146800124	ASSY. PRESSURE LINE BS3/4	TATA spare parts
501146800125	RETURN LINE ASSY	TATA spare parts
501146800126	RETURN LINE ASSY RESERVOIR END	TATA spare parts
501146800127	SUCTION LINE ASSY	TATA spare parts
501146800128	PRESSURE LINE ASSY	TATA spare parts
501146800129	RETURN LINE ASSY	TATA spare parts
501146990103	KIT-PIPE & ADAPTER BS3/4	TATA spare parts
501146990106	KIT-PIPE & ADAPTER BS3/4	TATA spare parts
501147100102	ASSY. FUEL TANK COMPLETE-RH(300 LTRS.)	TATA spare parts
501147100103	ASSY. FUEL TANK COMPLETE-LH(300 LTRS.)	TATA spare parts
501147100104	ASSY. FUEL TANK 100L ROUND BS3/4	TATA spare parts
501147100106	ASSY. FUEL TANK 200LTR BS4	TATA spare parts
501147109903	VALVE ASSY FUEL VAPOUR LINE	TATA spare parts
501147500101	ASSY BRKT FUEL TANK MTG.	TATA spare parts
501147500102	ASSY L SUPPORT (RECT FUEL TANK 300 LTR)	TATA spare parts
501147507701	RUBBER PROFILE FOR RECT.F.T.-LG 2228MM	TATA spare parts
501147600102	ASSY. SUCTION LINE	TATA spare parts
501147600103	ASSY. RETURN LINE	TATA spare parts
501147600104	ASSY. FUEL PIPE LINE (RH TANK TO VALVE)	TATA spare parts
501147600105	ASSY. FUEL PIPE LINE (VALVE TO VALVE)	TATA spare parts
501147600106	ASSY. FUEL PIPE LINE (LH TANK TO VALVE)	TATA spare parts
501147600107	ASSY. SUCTION LINE	TATA spare parts
501147600108	ASSY RETURN LINE	TATA spare parts
501147600114	ASSY SUCTION LINE(FUEL TANK TO FUEL W/S)	TATA spare parts
501147600115	ASSY SUCTION LINE(FUEL W/S TO ENGINE)	TATA spare parts
501147600116	ASSY FUEL RETURN LINE(ENGINE TO RH TANK)	TATA spare parts
501147600130	PIPE ASSY TANK TO INT JOINT	TATA spare parts
501147600131	SUCTION PIPE ASSY TANK TO FILTER	TATA spare parts
501147600132	FUEL SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
501147600134	PIPE ASSY FUEL TANK-1 TO FUEL TANK-2	TATA spare parts
501147600136	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
501147600137	FUEL SUCTION PIPE ASSY ENGINE TO W/SEP	TATA spare parts
501147600139	PIPE ASSY TANK TO INT JOINT	TATA spare parts
501147600140	PIPE ASSY TANK TO INT JOINT	TATA spare parts
501147603303	BRACKET FUEL PIPE MTG	TATA spare parts
501147700101	ASSY FUEL WATER SEPERATOR MTG BRACKET	TATA spare parts
501147700103	BRACKET ASSY FUEL FILTER MTG	TATA spare parts
501147990101	KIT-FUEL TANK & RUBBER BEAD-RH BS2/3/4	TATA spare parts
501147990102	KIT-ASSY. FUEL TANK & RBR BDNG LH BS2/3	TATA spare parts
501149100105	ASSY. EXHAUST SILENCER BS2/3	TATA spare parts
501149100106	ASSY. STRAP (SILENCER)	TATA spare parts
501149100106AE	ASSY STRAP ( FOR SILENCER )-1628	TATA spare parts
501149107103	GASKET	TATA spare parts
501149200107	EXHAUST BRAKE MTG. BRKT.(TC OUTLET)	TATA spare parts
501149200111	ASSY. EXHAUST PIPE-II	TATA spare parts
501149200113	BRACKET ASSY EGP MTG	TATA spare parts
501149200117	MTG. SUPPORT TOP	TATA spare parts

501149200118	ASSY. SILENCER MTG. BRKT-LH	TATA spare parts
501149200119	ASSY. SILENCER MTG. BRKT-RH	TATA spare parts
501149200120	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
501149200122	SILENCER MOUNTING BRKT-RH	TATA spare parts
501149200125	SILENCER MOUNTING BRKT-LH	TATA spare parts
501149200127	ASSY. EXHAUST PIPE-II (FOR NELSON) BS3	TATA spare parts
501149200134	BRACKET ASSY	TATA spare parts
501149200140	BRACKET ASSY EXHAUST MTG	TATA spare parts
501149200142	ASSY. EXHAUST PIPE WITH FLEX BELLOW BS4	TATA spare parts
501149200144	PIPE ASSY AIR OIL FILTER TO DU	TATA spare parts
501149200145	PIPE ASSY T-CONNECTOR TO AIR OIL FILTER	TATA spare parts
501149200148	BRACKET ASSY EGP MTG	TATA spare parts
501149200149	STRAP ASSY EGP MTG	TATA spare parts
501149203309	L BRACKET	TATA spare parts
501149203320	COVER NOX SENSOR	TATA spare parts
501149203321	BRACKET EXHAUST SUPPORT	TATA spare parts
501149203327	BRACKET AIR OIL SEPARATOR MTG	TATA spare parts
501149203334	BRACKET EXHAUST PIPE SUPPORT	TATA spare parts
501149203335	BRACKET EXHAUST SUPPORT	TATA spare parts
501149203336	BRACKET NOX SENSOR MTG	TATA spare parts
501149203338	BRACKET EXHAUST SUPPORT	TATA spare parts
501149204204	CLAMP (EXH. PIPE MTG.)	TATA spare parts
501149204205	CLAMP (EXH. PIPE MTG.)	TATA spare parts
501149204207	CLAMP	TATA spare parts
501149208206	BRACKET (EXH. PIPE SUPPORT)	TATA spare parts
501149208207	COVER NOX CONTROLLER	TATA spare parts
501149208226	COVER NOX CONTROLLER	TATA spare parts
501149208601	SPACER (5MM)	TATA spare parts
501149604202	CLAMP HEAT SHIELD FRONT BS6	TATA spare parts
501149990104	KIT-HEAT SHIELD FOR SILENCER & EXH PIPE	TATA spare parts
501149990105	KIT-HEAT SHIELD FOR SILENCER & EXH PIPE	TATA spare parts
501149990106	KIT-AFTER TREATMENT CES ASSY	TATA spare parts
501150408201	BRACKET	TATA spare parts
50115138000R40	CAB LPS 4923 SIGNA	TATA spare parts
501152200105	ASSY BRKT LH-FRONT(REAR MUDGUARD FRONT)	TATA spare parts
501152200106	ASSY BRKT RH-FRONT (REAR MUDGUARD FRONT)	TATA spare parts
501152200107	ASSY BRKT LH-REAR(REAR MUDGUARD FRONT)	TATA spare parts
501152200108	ASSY BRKT RH-REAR (REAR MUDGUARD FRONT)	TATA spare parts
501152200109	ASSY BRKT LH-FRONT(REAR MUDGUARD REAR)	TATA spare parts
501152200110	ASSY BRKT RH-FRONT (REAR MUDGUARD REAR)	TATA spare parts
501152200111	ASSY BRKT LH-REAR(REAR MUDGUARD REAR)	TATA spare parts
501152200112	ASSY BRKT RH-REAR(REAR MUDGUARD REAR)	TATA spare parts
501152200117	WHEEL ARCH LOCATOR BRKT ASSY	TATA spare parts
501152200137	BRACKET ASSY FENDER MTG REAR-LH	TATA spare parts
50115220013735	BRACKET ASSY FENDER MTG REAR-LH	TATA spare parts
501152200138	BRACKET ASSY FENDER MTG REAR-RH	TATA spare parts
50115220013835	BRACKET ASSY FENDER MTG REAR-RH	TATA spare parts

501152206301	MUDFLAP REAR -LH (LOWER)	TATA spare parts
501152206302	MUDFLAP REAR -RH (LOWER)	TATA spare parts
501152206303	MUDFLAP REAR UPPER-LH	TATA spare parts
501152206304	MUDFLAP REAR UPPER-RH	TATA spare parts
501152206305	REAR MUDGUARD FRONT - LH	TATA spare parts
501152206306	REAR MUDGUARD -FRONT RH	TATA spare parts
501152206307	REAR MUDGUARD REAR-LH	TATA spare parts
501152206308	REAR MUDGUARD -REAR RH	TATA spare parts
501152206309	MUD FLAP REAR REAR-LH (UPPER)	TATA spare parts
501152206310	MUD FLAP REAR REAR-RH (UPPER)	TATA spare parts
501152207106	LOCATOR CLAMP BS6	TATA spare parts
501152208201	COVER PLATE (MUDFLAP)	TATA spare parts
50115238000R40	60R_RESTRUCTURE_FOR_CVBU_IN_APL_VIEW	TATA spare parts
501152400109	BRACKET ASSY LH	TATA spare parts
501152400110	BRACKET ASSY RH	TATA spare parts
501152990101	RETRO-FITMENT KIT FOR LPS 4923TC	TATA spare parts
501154108203	CLAMP	TATA spare parts
501154200108	INSTRUMENT CLUSTER INTERFACE HARDWARE	TATA spare parts
501154203301	BRACKET DISPLAY MTG	TATA spare parts
501154203302	BRACKET DISPLAY MTG	TATA spare parts
501154209904	ASSY. INSTRUMENT CLUSTER 24V 41/7 BS3/4	TATA spare parts
501154209905	ELECT INSTR CLSTR 7040PULSES 552HZ	TATA spare parts
501154400101	BRACKET ASSY TAIL LAMP & LICENCE PLATE B	TATA spare parts
501154400105	BRACKET ASSY TAIL LAMP MTG LH	TATA spare parts
501154400106	BRACKET ASSY TAIL LAMP MTG RH	TATA spare parts
501154403303	BRACKET TAIL LAMP MTG	TATA spare parts
501154600104	WIRING HARNESS ABS FRAME BS4	TATA spare parts
501154600110	WIRING HARNESS ABS SPLIT	TATA spare parts
501154600121	WIRING HARNESS ABS SPLIT	TATA spare parts
501154600127	WIRING HARNESS ENGINE BS4	TATA spare parts
501154600128	WIRING HARNESS MAIN BS4	TATA spare parts
501154600131	PIGTAIL ASSY EMS WIRING HARNESS	TATA spare parts
501154600132	WIRING HARNESS ABS FRAME	TATA spare parts
501154600143	PIGTAIL ASSY EMS WIRING HARNESS	TATA spare parts
501154600154	JUMPER CABLE ABS CONNECTION	TATA spare parts
501154600155	JUMPER CABLE LIGHTING CONNECTION	TATA spare parts
501154600156	PIGTAIL TAIL LAMP	TATA spare parts
501154600160	WIRING HARNESS MAIN	TATA spare parts
501154600161	WH PIGTAIL AIS140	TATA spare parts
501154600162	WH PIGTAIL AIS140	TATA spare parts
501154600164	WH PIGTAIL AIS140	TATA spare parts
501154601605	WIRING HARNESS ROOF	TATA spare parts
501154601611	WIRING HARNESS TAIL BS4	TATA spare parts
501154601612	WIRING HARNESS SCR UNIT BS4	TATA spare parts
501154620102	WIRING HARNESS TAIL(LPS4923TC/38 BS-II)	TATA spare parts
501154620105	WIRING HARNESS ROOF	TATA spare parts
501154620106	WIRING HARNESS MAIN BS3	TATA spare parts

501154709903	VOICE MESSAGING SYSTEM	TATA spare parts
501154903301	BRACKET SENSOR MTG	TATA spare parts
501213689	REPAIR KIT	TATA spare parts
501229106001	CLUTCH RELEASE LEVER	TATA spare parts
501229106301	BUSH (CLUTCH CONTROL)	TATA spare parts
501246600101	STEERING GEAR BOX ASSY	TATA spare parts
501254608203	L BKT FOR WH MTG	TATA spare parts
501300990101	FULLY TRIMMED CAB NS LPK3118 SP Limit	TATA spare parts
501300990102	FULLY TRIMMED CAB NS LPK3118	TATA spare parts
501300990103	KIT FULLY TRIMMED CABIN FOR LPK3118	TATA spare parts
501300990105	KIT-CABIN COMP. LPK 3118 BLOWER? BS4	TATA spare parts
501300990106	KIT FULLY TRIMMED CAB FOR LPTK 3118	TATA spare parts
501300990107	KIT FULLY TRIMMED CAB FOR LPTK3118	TATA spare parts
501319947	REPAIR KIT	TATA spare parts
501329100101	ASSY. BRACKET CLUTCH BOOSTER MTG. BS3	TATA spare parts
501331000101	ASSY. FRAME WITH FITMENT BS3	TATA spare parts
501331000102	ASSY. FRAME LPK3118 (FAB 4 HOLE BKT) BS3	TATA spare parts
501331000104	ASSY. FRAME WITH FITMENT BS3/4	TATA spare parts
501331000105	ASSY. FRAME WITH FITMENT BS4	TATA spare parts
501331000106	FRAME ASSY WITH FITMENT	TATA spare parts
501331000108	ASSY. FRAME 3118 (FAB 4 HOLE BKT) BS3/4	TATA spare parts
501331000110	ASSY. FRAME WITH FITMENT BS4	TATA spare parts
501331000111	ASSY. FRAME WITH FITMENT BS4	TATA spare parts
501331000113	FRAME ASSY WITH FITMENT	TATA spare parts
501331107105	REINFORCEMENT-RH (LONG MEMBER)	TATA spare parts
501331107106	REINFORCEMENT-LH(LONG MEMBER)	TATA spare parts
501331200101	ASSY CROSS MEMBER (5TH)	TATA spare parts
501331200102	ASSY 4TH X-MEMBER WITH GUSSET	TATA spare parts
501331200103	CROSS MEMBER ASSY WITH GUSSETE	TATA spare parts
501331200104	ASSY BRACKET GB MTG	TATA spare parts
501331200105	ASSY BRACKET GB MTG	TATA spare parts
501331200106	ASSY REINF-RH(FRT SPRING BKT)	TATA spare parts
501331200107	ASSY REINF-LH(FRT SPRING BKT)	TATA spare parts
501331200110	ASSY. 6TH CROSS MEMBER	TATA spare parts
501331200113	CROSS MEMBER ASSY ENGINE	TATA spare parts
501331307101	REINFORCEMENT-RH(SPR HAN BKT-MIDDLE)	TATA spare parts
501331307102	REINFORCEMENT-LH (SPR HAN BKT-MIDDLE)	TATA spare parts
501331308201	GUSSET TOP RH(BUMPER CROSS MEMBER)	TATA spare parts
501331308202	GUSSET TOP LH(BUMPER CROSS MEMBER)	TATA spare parts
501331308203	GUSSET TOP RH (BUMPER CROSS MEMBER)	TATA spare parts
501331308204	GUSSET TOP LH (BUMPER CROSS MEMBER)	TATA spare parts
501331700102	NOISE SHEILD ASSY (CAB REAR)	TATA spare parts
501331700103	NOISE SHIELD ASSY ENGINE BOTTOM	TATA spare parts
501331700104	BRACKET ASSY	TATA spare parts
501331708204	BRACKET	TATA spare parts
501331708210	BRACKET	TATA spare parts
501332100102	ASSY SPRING HANGER BKT FR MIDDLE - LH	TATA spare parts

501332100103	ASSY SPRING HANGER BKT FR MIDD - RH	TATA spare parts
501332100104	ASSY. SPRING HANGER BKT FRONT RWD	TATA spare parts
501332100105	ASSY BUMP STOPPER MTG. BKT.FFWD TOP.	TATA spare parts
501332100106	ASSY BELL CRANK LEVER FRONT FWD-LH	TATA spare parts
501332100107	ASSY BELL CRANK LEVER FRONT FWD-RH	TATA spare parts
501332100108	ASSY BELL CRANK LEVER FRONT RWD-LH	TATA spare parts
501332100109	ASSY BELL CRANK LEVER FRONT RWD-RH	TATA spare parts
501332100110	ASSY BUMP STOPPER FRONT FWD TOP-LH	TATA spare parts
501332100111	ASSY BUMP STOPPER FRONT FWD TOP-RH	TATA spare parts
501332100112	ASSY BUMP STOPPER FRWD TOP-LH	TATA spare parts
501332100115	ASSY BUMP STOPPER FFWD MTG BRACKET (ON C	TATA spare parts
501332100116	ASSY BUMP STOPPER - LH	TATA spare parts
501332100117	ASSY BUMP STOPPER - RH	TATA spare parts
501332100121	ASSY 4 LEAF PARABOLIC SPRING	TATA spare parts
501332100127	ASSY BRACKET AXLE STOPPER FFWD-LH	TATA spare parts
501332100128	ASSY BRACKET AXLE STOPPER FFWD-RH	TATA spare parts
501332100141	PARABOLIC LEAF SPRING ASSY	TATA spare parts
501332100142	PARABOLIC LEAF SPRING ASSY	TATA spare parts
501332100144	BRACKET ASSY SPRING HANGER FRONT-LH	TATA spare parts
501332100145	BRACKET ASSY SPRING HANGER FRONT-RH	TATA spare parts
501332100150	BRACKET ASSY BUMP STOPPER	TATA spare parts
501332100159	BRACKET ASSY AXLE STOPPER MTG	TATA spare parts
50133210015935	BRACKET ASSY AXLE STOPPER MTG_UNPAINTED	TATA spare parts
501332100162	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
501332100165	PARABOLIC LEAF SPRING ASSY BS6-PH2	TATA spare parts
501332100166	PARABOLIC LEAF SPRING ASSY BS6-PH2	TATA spare parts
501332100167	PARABOLIC LEAF SPRING ASSY BS6-PH2	TATA spare parts
501332103201	HEX FL BOLT DIN EN 1665ç M16X2X75 - 10.9	TATA spare parts
501332103202	HEX FL BOLT DIN EN 1665 M16X2X85-10.9	TATA spare parts
501332103203	HEX FL BOLT DIN EN 1665 M16X2X95-10.9	TATA spare parts
501332103204	HEX FL BOLT DIN EN 1665ç M16X2X100-10.9	TATA spare parts
501332103207	CENTER BOLT	TATA spare parts
501332103208	CENTER BOLT	TATA spare parts
501332103210	CENTER BOLT BS6-PH2	TATA spare parts
501332103212	CENTER BOLT BS6-PH2	TATA spare parts
501332104201	U-BOLT M22X1.5X270	TATA spare parts
501332104202	U-BOLT L220	TATA spare parts
501332104206	U-BOLT M22X1.5X280	TATA spare parts
501332104212	CLAMP BS6-PH2	TATA spare parts
501332107146	SPACER (THK-14MM)	TATA spare parts
501332107147	SPACER	TATA spare parts
501332107148	SPACER	TATA spare parts
501332107158	2ND LEAF BS6-PH2	TATA spare parts
501332107159	3RD LEAF BS6-PH2	TATA spare parts
501332107160	4TH LEAF BS6-PH2	TATA spare parts
501332107166	CASTER PLATE BS6-PH2	TATA spare parts
501332204201	SPRING CLIPBS6	TATA spare parts

501332300101	ASSY SHOCK ABSORBER BKT FFWD TOP	TATA spare parts
501332300104	ASSY.SHOCK ABSORBER BRACKET-TOP	TATA spare parts
501332300108	BRACKET ASSY FRONT SHOCK ABSORBER MTG	TATA spare parts
501332303301	BRACKET SHOCK ABSORBER MTG LOWER-RH	TATA spare parts
501332303302	BRACKET SHOCK ABSORBER MTG LOWER-LH	TATA spare parts
501332303303	SHOCK ABSORBER BRACKET-LH (ON AXLE)	TATA spare parts
501332303304	SHOCK ABSORBER BRACKET-RH (ON AXLE)	TATA spare parts
501332405101	LOWER SADDLE BS6 PH2	TATA spare parts
501332800101	ASSY BALL JOINT LINK	TATA spare parts
501332800103	BALL JOINT LINK ASSY	TATA spare parts
501332800106	BALL JOINT LINK ASSY BS6	TATA spare parts
501332800108	BALL JOINT LINK ASSY	TATA spare parts
501332800109	BALL JOINT LINK ASSY BS6	TATA spare parts
501332803301	ANTIROLL BAR MTG BRACKET (ON CHASSIS)	TATA spare parts
501332803701	BRACKET ANTI ROLL BAR MTG FRONT	TATA spare parts
501332807902	ANTIROLL BAR-FORGED	TATA spare parts
501333000101	ASSY FRONT FWD AXLE COMPLETE WITH BRAKES	TATA spare parts
501333000102	ASSY.FRONT RWD AXLE COMPLETE WITH BRAKES	TATA spare parts
501333000107	FRONT AXLE ASSY WITH BRAKE FRT RWD	TATA spare parts
501333000109	FRONT AXLE ASSY WITH BRAKE FRT FWD	TATA spare parts
501333105101	FRONT AXLE BEAM 7.5T 848 SPCD BS3/4	TATA spare parts
501333805101	TIE ROD ARM RH	TATA spare parts
501333805102	TIE ROD ARM LH	TATA spare parts
501341100101	ASSY. PROP SHAFT WITH CENTER BRG	TATA spare parts
501341100102	CENTER BEARING ASSY	TATA spare parts
501341100103	COUPLING FLANGE & DUST COVER	TATA spare parts
501341100105	ASSY. COUPLING SHAFT	TATA spare parts
501341100107	ASSY PROP SHAFT WITH HONEYCOMB CB	TATA spare parts
501341100108	CENTRE BEARING WITH HONEYCOMB BS6	TATA spare parts
501341100109	SHORT FORK TUBE AND FRT END PIECE	TATA spare parts
501341100112	ASSY COUPLING SHAFT	TATA spare parts
501341100114	PROPELLER SHAFT ASSY FRONT	TATA spare parts
501341100117	COUPLING FLANGE AND DUST COVER	TATA spare parts
501341100124	PROPELLER SHAFT ASSY-COUPLING BS6	TATA spare parts
501341105102	FLANGE YOKE	TATA spare parts
501341108201	PROP SHAFT GUARD TOP	TATA spare parts
501341109901	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
501341109902	COUPLING FLANGE & DUST COVER	TATA spare parts
501341109903	CENTER BEARING WITH HONEYCOMB	TATA spare parts
501341110101	PROPELLER SHAFT ASSY FRONT	TATA spare parts
501341110103	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
501341110106	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
501341120101	ASSY. PROP SHAFT REAR	TATA spare parts
501341120103	DRIVE SHAFT	TATA spare parts
501341120104	PROPELLER ASSY. INTERAXLE PROP. SHAFT (L	TATA spare parts
501341120105	LONG FORK SUB ASSY-180 SLIP	TATA spare parts
501341120107	PROPELLER SHAFT ASSY REAR	TATA spare parts

501341120111	PROPELLER SHAFT ASSY REAR	TATA spare parts
501341120112	PROPELLER SHAFT ASSY	TATA spare parts
501341120114	PROPELLER SHAFT ASSY REAR	TATA spare parts
501341120117	PROPELLER SHAFT ASSY REAR	TATA spare parts
501341120118	SHORT FORK TUBE AND REAR END PIECE	TATA spare parts
501341120122	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
501341120124	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
501341300101	BRACKET ASSY;CENTER BEARING	TATA spare parts
501341303301	CENTER BEARING MTG. BKT.	TATA spare parts
501341303302	CENTER BEARING MTG. BKT	TATA spare parts
501341308201	SPACER PLATE	TATA spare parts
501341990102	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
501341990107	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
501342300109	BRAKE ASSY -LH REAR 410X180	TATA spare parts
501342300110	BRAKE ASSY -RH REAR 410X180	TATA spare parts
501342305101	CAMSHAFT LH	TATA spare parts
501342305102	CAMSHAFT RH	TATA spare parts
501343200109	ASSY AIR-TANK WITH BKT 40LTR	TATA spare parts
501343200110	ASSY AIR-TANK WITH BKT 40LTR (REAR)	TATA spare parts
501343200112	SUB ASSY AIR TANK WITH BKT 40L	TATA spare parts
501343200113	ASSY AIR-TANK MTG BKT LH	TATA spare parts
501343200118	AIR TANK SUB ASSY COMP 40-LTR	TATA spare parts
501343200120	AIR TANK SUB ASSY COMP (V+M)CD-333	TATA spare parts
501343200121	AIR TANK ASSY	TATA spare parts
501343200122	AIR TANK ASSY 3 PORT (2 VOSS+1 METRIC)	TATA spare parts
501343700104	SPRING BRAKE ACTUATOR TYPE 20/24	TATA spare parts
501343700123	BRACKET ASSY REAR	TATA spare parts
501343700129	SPRING BRAKE ACTUATOR-KB	TATA spare parts
501343700130	SPRING BRAKE ACTUATOR	TATA spare parts
501343703301	PLATE FOR R-12 RELAY VALVE MTG	TATA spare parts
501343900110	ASSY. COMPRESSOR 2ND PIPE	TATA spare parts
501343900111	ASSY COMPRESSOR 3RD PIPE	TATA spare parts
501343900112	ASSY. NYLON PIPE COMPLETE	TATA spare parts
501343900138	METAL PIPE ASSY	TATA spare parts
501343900170	BUNCH ASSY PIPE	TATA spare parts
501343900172	PIPE ASSY BUNCH	TATA spare parts
501343900202	PIPE ASSY BUNCH COMPLETE	TATA spare parts
501343910143	METAL PIPE ASSY TEFLON HOSE TO 2ND JOINT	TATA spare parts
501343910153	PIPE ASSY BUNCH	TATA spare parts
501343910160	PIPE ASSY BUNCH	TATA spare parts
501343910164	PIPE ASSY BUNCH COMPLETE	TATA spare parts
501343910167	METAL PIPE ASSY	TATA spare parts
501343910179	METAL PIPE ASSY	TATA spare parts
501343920101	PIPE ASSY NYLON BUNCH COMPLETE LPK-3118	TATA spare parts
501343920103	PIPE ASSY COMP 2ND OUTLET	TATA spare parts
501343920104	PIPE ASSY COMP OUTLET 3RD	TATA spare parts
501343920149	PIPE ASSY COMP OUTLET 1ST	TATA spare parts



501343920150	SET-NYLON PIPE BUNCH ASSY COMPLETE	TATA spare parts
501343920200	BUNCH ASSY PIPE	TATA spare parts
501343930101	PIPE ASSY METAL COMP OUTLET TO 1ST JOINT	TATA spare parts
501343930102	PIPE ASSY METAL TEFLON HOSE TO 2ND JOINT	TATA spare parts
501343930103	PIPE ASSY METAL JOINT-2 TO AIR DRYER-1	TATA spare parts
501346100101	ASSY STEERING G/B & CONTROL MTG BKT	TATA spare parts
501346300101	ASSY. 1ST DRAG LINK BS3/4	TATA spare parts
501346300102	ASSY 2ND DRAG LINK	TATA spare parts
501346300103	ASSY. RELAY ROD BS3/4	TATA spare parts
501346300107	ASSY 2ND DRAG LINK (STRAIGHT)	TATA spare parts
501346304101	RELAY ARM - LPK3118	TATA spare parts
501346703301	BRACKET RELAY ARM MTG BS6	TATA spare parts
501346800102	ASSY.PRESSURE LINE-I(STG GB TO POWER CYL	TATA spare parts
501346800103	ASSY. PRESSURE LINE (PUMP TO STG GB)	TATA spare parts
501346800104	ASSY PRESSURE LINE-II(STG GB TO POWER CY	TATA spare parts
501346800105	ASSY RETURN LINE	TATA spare parts
501346800106	ASSY SUCTION LINE	TATA spare parts
501346800113	HIGH PRESSURE LINE ASSY P/CYL	TATA spare parts
501346800114	HIGH PRESSURE LINE ASSY P/CYL	TATA spare parts
501346900101	DRAG LINK ASSY FRONT	TATA spare parts
501346900102	DRAG LINK ASSY REAR BS6	TATA spare parts
501346900103	RELAY ROD ASSY BS6	TATA spare parts
501346900106	DRAG LINK ASSY FRONT BS6	TATA spare parts
501346990103	END ASSEMBLY-LH	TATA spare parts
501346990104	END ASSEMBLY-RH	TATA spare parts
501346990105	END ASSEMBLY-RH	TATA spare parts
501346990107	KIT-PIPE & ADAPTER	TATA spare parts
501347108201	BRACKET PRIMING PUMP MTG	TATA spare parts
501347500102	BRACKET ASSY FUEL TANK MTG	TATA spare parts
501347500103	BRACKET ASSY FUEL TANK MTG	TATA spare parts
501347500104	BRACKET ASSY FUEL TANK MTG BS6	TATA spare parts
501347600101	ASSY. TUBE WITH CRIMPED R/HOSE SUCTION P	TATA spare parts
501347600102	ASSY. TUBE WITH CRIMPED R/HOSE RETURN PI	TATA spare parts
501347600105	SUCTION LINE (TANK TO FILTER)	TATA spare parts
501347600106	SUCTION LINE (FILTER TO ENG.)	TATA spare parts
501347600107	RETURN LINE ASSY ON TANK	TATA spare parts
501347600111	SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
501347600112	SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
501347600113	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
501347600114	SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
501347600115	SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
501347600116	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
501347600117	SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
501347600118	SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
501347600119	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
501349008201	CLAMP	TATA spare parts
501349008203	CLAMP	TATA spare parts

501349008205	CLAMP	TATA spare parts
501349008208	CLAMP	TATA spare parts
501349008209	CLAMP	TATA spare parts
501349200101	EXHAUST PIPE 2ND	TATA spare parts
501349200102	ASSY. EXHAUST PIPE (4TH)	TATA spare parts
501349200103	ASSY EXHAUST PIPE 3RD	TATA spare parts
501349200105	ASSY. BRACKET(EXHAUST MTG.)	TATA spare parts
501349200107	ASSY BKT (EXHAUST MTG)	TATA spare parts
501349200110	ASSY BKT (EXHAUST MTG)	TATA spare parts
501349200118	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
501349200119	EXHAUST PIPE ASSY INERMEDIATE TO MUFFLER	TATA spare parts
501349200121	PIPE ASSY T-CONNECTOR TO AIR OIL FILTER	TATA spare parts
501349200123	BRACKET ASSY EGP MTG	TATA spare parts
501349200125	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
501349200126	EXHAUST PIPE ASSY INT	TATA spare parts
501349200128	BRACKET ASSY EXHAUST MTG	TATA spare parts
501349200139	BRACKET ASSY EGP MTG	TATA spare parts
501349203305	L-BRACKET EXHAUST PIPE MTG	TATA spare parts
501349203306	BRACKET EXHAUST PIPE MTG	TATA spare parts
501349203307	L-BRACKET EXHAUST PIPE MTG	TATA spare parts
501349203308	L-BRACKET EXHAUST PIPE MTG	TATA spare parts
501349203312	BRACKET EXHAUST PIPE CLAMPING	TATA spare parts
501349206903	TAIL PIPE (EXHAUST MUFFLER)	TATA spare parts
501349206917	TAIL PIPE	TATA spare parts
501349208203	BRACKET (EXHAUST PIPE)	TATA spare parts
501349208204	BRACKET EXHAUST MTG (X-M 3RD)	TATA spare parts
501354100101	ASSEMBLY BATTERY CARRIER COMPLETE	TATA spare parts
501354209901	ASSY. INSTRUMENT CLUSTER BS3/4	TATA spare parts
501354209902	INSTRUMENT CLUSTER ASSY	TATA spare parts
501354600105	WIRING HARNESS ABS FRAME	TATA spare parts
501354600107	WIRING HARNESS ABS SPLIT	TATA spare parts
501354600108	WIRING HARNESS ABS FRAME	TATA spare parts
501354600109	WIRING HARNESS ENGINE BS4	TATA spare parts
501354600114	WIRING HARNESS TAIL	TATA spare parts
501354600115	WIRING HARNESS MAIN	TATA spare parts
501354600116	WIRING HARNESS TAIL	TATA spare parts
501354600118	WIRING HARNESS ENGINE	TATA spare parts
501354600120	WIRING HARNESS TAIL	TATA spare parts
501354600121	WIRING HARNESS ABS FRAME	TATA spare parts
501354601609	WIRING HARNESS ENGINE	TATA spare parts
501354601616	WIRING HARNESS ENGINE BS4	TATA spare parts
501354603301	BRACKET INLINE CONN MTG	TATA spare parts
501354620109	WIRING HARNESS TAIL	TATA spare parts
501354620110	WIRING HARNESS SCR UNIT BS4	TATA spare parts
501354660108	W/H PIGTAIL H/L LEVELLING	TATA spare parts
501354709901	FASTAG	TATA spare parts
501358902601	DOLLY FOR G1150 INTERLOCK PIN PRESSING	TATA spare parts

5013600002R40	ASSEMBLY BODY FITTED	TATA spare parts
50136556000R40	CAB COMPLETE WITH FITMENTS FOR LPTK3118	TATA spare parts
50136656000R40	ASSY CAB COMPLETE	TATA spare parts
50139656100R40	60R_RESTRUCTURE_FOR_CVBU_IN_APL_VIEW	TATA spare parts
501432403202	HEX FLANGE BOLT M16X2X70	TATA spare parts
501432403204	HEX FL BOLT DIN EN 1665 M24X3X135-10.9 B	TATA spare parts
501441120102	ASSY. PROPELLER SHAFT INT. AXLE BS3/4	TATA spare parts
501442100114	ASSY DRUM BRAKE RH WT D/C	TATA spare parts
501442100118	ASSY DRUM BRAKE LH WT D/C	TATA spare parts
501442100123	ASSY DRUM BRAKE RH WT D/C	TATA spare parts
501442100127	ASSY DRUM BRAKE LH WT D/C	TATA spare parts
501442100142	DRUM BRAKE ASSY FRONT LH W/T D/C	TATA spare parts
501442100143	DRUM BRAKE ASSY FRONT RH W/T D/C	TATA spare parts
501442100149	TUBE -ç FLANGE AND BRACKET ASSY. - LH	TATA spare parts
501442100150	TUBE -ç FLANGE AND BRACKET ASSY. - RH	TATA spare parts
501442103701	DRUM BRAKE -SPIGOTTED	TATA spare parts
501442103702	BRAKE DRUM FRONT BS3/4	TATA spare parts
501442103703	BRAKE DRUM SPIGOTTED BS1/2/3/4	TATA spare parts
501442103704	TORQUE PLATE - LH	TATA spare parts
501442103705	TORQUE PLATE - RH	TATA spare parts
501442104302	CIRCLIP-BRTS BRAKE	TATA spare parts
501442105101	CAM SHAFT FLH	TATA spare parts
501442105102	CAM SHAFT FRH	TATA spare parts
501442108301	SHIM - 0.3 MM	TATA spare parts
501442108302	SHIM - 0.5 MM	TATA spare parts
501442108303	SHIM - 1.0 MM	TATA spare parts
501442108304	SHIM-2.0 MM THK	TATA spare parts
501442108701	SPRING CAM END	TATA spare parts
501442109202	WASHER-1.0 MM	TATA spare parts
501442109203	WASHER-1.5 MM THK	TATA spare parts
501442109902	KIT-CAM END SPRING BS3/4	TATA spare parts
501442300109	AUTO SLACK ADJUSTER -RH 140CD 60 OFFSET	TATA spare parts
501442300115	AUTO SLACK ADJUSTER -LH 140CD 60 OFFSSET	TATA spare parts
501442303701	BRAKE DRUM SPIGOTTED REAR	TATA spare parts
501442303701AE	BRAKE DRUMS REAR 1628 1828	TATA spare parts
501442990101	BRAKE DRUM LINED SHOE ASSY	TATA spare parts
501626800101	ASSY BRACKET(FOR MOUNTING OF PRESSURE RE	TATA spare parts
501626804201	CLAMP	TATA spare parts
501629000101	ASSY. INTEGRATED PEDAL UNIT (TYPE-1)	TATA spare parts
501629000101AE	ASSY. INTGRTD PEDAL -1628-1828	TATA spare parts
501629200101	BRAKE SWITCH	TATA spare parts
501629990101	MAJOR KIT	TATA spare parts
501631700101	ASSY CHASSIS PLATE REAR	TATA spare parts
501643906801	FIRTEE 8X8X12	TATA spare parts
501646800107	PIPE ASSY MAGNETIC VALVE SIDE	TATA spare parts
501646800108	PIPE ASSY AUXILIARY AIR TANK SIDE	TATA spare parts
501647606802	VOSS ELBOW	TATA spare parts

501649100110	SILENCER FOR LPS4938	TATA spare parts
501726800103	ASSY PRESSURE REGULATOR (5.5 BAR)	TATA spare parts
501726806901	AIR PIPE (FROM FIRST T)	TATA spare parts
501726806902	PIPE (TRN T TO SOL.VALVE)	TATA spare parts
501726806903	PIPE (SOL VALVE TO PR.REGULATR)	TATA spare parts
501726806904	PIPE( TRN T TO IAS)	TATA spare parts
501726806904AE	PIPE( TRN T TO IAS) 1628	TATA spare parts
501726806905	NYLON PIPE PR.REG. TO POWER SHIFT	TATA spare parts
501731200101	ASSLY 1ST CROSSMEMBER	TATA spare parts
501732100102	ASSY.BUMP STOPPER BRACKET (FRT RWD)	TATA spare parts
501732100104	SPRING HANGER BRACKET MIDDLE - LH	TATA spare parts
501732100105	ASSY. SPRING HANGER BRACKET MIDDLE - RH	TATA spare parts
501732100106	ASSY. SPRING HANGER BRACKET (FRONT REARW	TATA spare parts
501732100111	ASSY. FIRST LEAF W/BUSH BS3/4	TATA spare parts
501732100111DF	MAIN LEAF W/BUSH FR FWD-LPK3118/3123-LPT	TATA spare parts
501732100112	ASSY. FIRST LEAF W/BUSH BS3/4	TATA spare parts
501732100112DF	MAIN LEAF W/BUSH FR RWD-LPK3118/3123-LPT	TATA spare parts
501732100113	ASSY PARABOLIC SPRING FRONT FWD	TATA spare parts
501732100114	ASSY PARABOLIC SPRING FRONT RWD	TATA spare parts
501732100115	ASSY.BUMP STOPPER (FRONT FWD)	TATA spare parts
501732103201	HEX FLANGE BOLT	TATA spare parts
501732103202	HEX FLANGE BOLT M14X1.5X75	TATA spare parts
501732103301	SPRING HANGER BRACKET (FRONT FORWARD)	TATA spare parts
501732103302	SPRING HANGER BRACKET MIDDLE - LH	TATA spare parts
501732103303	SPRING HANGER BRACKET MIDDLE - RH	TATA spare parts
501732103304	SPRING HANGER BRACKET (FRONT REARWARD)	TATA spare parts
501732103401	BUSH	TATA spare parts
501732104201	U BOLT (L - 230)	TATA spare parts
501732104202	U BOLT (L - 205)	TATA spare parts
501732104203	SPRING CLIP	TATA spare parts
501732107106	SECOND LEAF	TATA spare parts
501732107106DF	SECOND LEAF FR FWD-LPK3118/3123-LPT3718	TATA spare parts
501732107107	THIRD LEAF FRONT SPRING BS3/4	TATA spare parts
501732107107DF	THIRD LEAF FR FWD-LPK3118/3123-LPT3718	TATA spare parts
501732107108	FOURTH LEAF FRONT FWD	TATA spare parts
501732107108DF	FOURTH LEAF FR FWD-LPK3118/3123-LPT3718	TATA spare parts
501732107110	SECOND LEAF	TATA spare parts
501732107110DF	SECOND LEAF FR RWD-LPK3118/3123-LPT3718	TATA spare parts
501732107111	THIRD LEAF BS3/4	TATA spare parts
501732107111DF	THIRD LEAF FR RWD-LPK3118/3123-LPT3718	TATA spare parts
501732107112	FOURTH LEAF FRONT RWD	TATA spare parts
501732108602	SPACER	TATA spare parts
501732108603	SPACER	TATA spare parts
501732303301	BRACKET SHOCK ABS. MTG. ON AXLE - LH (FR	TATA spare parts
501732303302	BRACKET SHOCK ABS. MTG. ON AXLE - RH (FR	TATA spare parts
501732303303	BRACKET SHOCK ABS. MTG. ON AXLE - LH	TATA spare parts
501732303304	BRACKET SHOCK ABS. MTG. ON AXLE - RH	TATA spare parts

501732307101	BRACKET SHOACK ABSORBER TOP (FRT RWD)	TATA spare parts
501732307102	BRACKET SHOCK ABSORBER TOP (FRT FWD)	TATA spare parts
501732800101	ASSY BALL JOINT LINK ARB	TATA spare parts
501732803301	ANTIROLLBAR BRACKET FRONT	TATA spare parts
501733000101	ASSY. FRONT AXLE COMP. WITH BRAKES (FRON	TATA spare parts
501733000102	ASSY. FRONT AXLE COMP. WITH BRAKES (FRON	TATA spare parts
501743200101	ASSY.AIR TANK FOR 30 LITRES	TATA spare parts
501743200103	ASSY.AIR TANK 40L WITH 3 PORTS BS6	TATA spare parts
501743200104	ASSY. AIR TANK(40L)	TATA spare parts
501743700113	ASSY. BRACKET FOR MV MTG BKT	TATA spare parts
501743708203	BKT FOR MTG RELAY & MOD VALVE ON CM	TATA spare parts
501743708204	L- BRACKET	TATA spare parts
501743900112	ASSY. NYLON PIPE AUXILARY TANK TO NRV	TATA spare parts
501743900115	ASSY. NYLON PIPE FRONT AIR TANK TO TEE-4	TATA spare parts
501743900143	ASSY NYLON PIPE REAR LH MV TO TEE-15	TATA spare parts
501743900144	ASSY NYLON PIPE REAR RH MV TO TEE-12	TATA spare parts
501743900173	ASSY. NYLON PIPE FROM AUX. TANK TO TEE20	TATA spare parts
501743900174	ASSY NYLON PIPE FROM T20 TO T21	TATA spare parts
501743900175	ASSY NYLON PIPE FROM T21 TO T22	TATA spare parts
501743900176	ASSY. NYLON PIPE FROM T22 TO T23	TATA spare parts
501743900213	ASSY.NYLON PIPE TEE-13 TO TEE-25	TATA spare parts
501743900215	ASSY NYLON PIPE TEE-14 TO TEE-25	TATA spare parts
501743900222	ASSY.NYLON PIPE TEE-26 TO SBA RH FRONT R	TATA spare parts
501743900223	ASSY NYLON PIPE TEE-26 TO ACRV	TATA spare parts
501743900224	ASSY NYLON PIPE TEE-26 TO SBA FRONT LH R	TATA spare parts
501743900225	ASSY.NYLON PIPE¿ ACRV TO TEE-25	TATA spare parts
501743906802	TEE M22X1.5XM18X1.5XM12X1.5	TATA spare parts
501743907102	COMMAN BKT FOR HOLDING NYLON & STERING P	TATA spare parts
501743907105	BRACKET FOR HOSE MTG.	TATA spare parts
501743907501	GROMMET ON LM	TATA spare parts
501743907502	GROMMET ON LM	TATA spare parts
501743907503	GROMMET ON LM	TATA spare parts
501746800111	NYLON PIPE ASM FOR L2 CAB-SOLENOID VALVE	TATA spare parts
501746803301	BRKT-STRG PIPE MTG BS6	TATA spare parts
501746803302	BRKT-STRG PIPE MTG	TATA spare parts
501746803303	BRACKET STG PIPE MTG BS6	TATA spare parts
501746803304	BRKT-STRG PIPE MTG BS6	TATA spare parts
501746803306	BRKT-STRG PIPE MTG	TATA spare parts
501746803307	BRKT-STRG PIPE MTG	TATA spare parts
501746803313	BRACKET STG PIPE MTG BS6	TATA spare parts
501746803315	BRKT-STRG PIPE MTG	TATA spare parts
501746900101	TWIN OIL COOLER ASM	TATA spare parts
501749108216	FIRST PIPE CLAMPING BRACKET	TATA spare parts
501749108217	FIRST PIPE BRACKET	TATA spare parts
501758300101	HYDRAULIC JACK ASSY WITH HANDLE	TATA spare parts
501758900113	ASSY. STORAGE BOX COMPLETE	TATA spare parts
501758900114	ASSY. KNOB	TATA spare parts

501758900117	SPACER ASSEMBLY	TATA spare parts
501758901601	ASSY HYD JACK 20T	TATA spare parts
501758906016	RUBBER BEAD (STORAGE BOX)	TATA spare parts
501758906022	CLAMP	TATA spare parts
501826800101	ASSY BRACKET (PRESSURE REGULATOR)	TATA spare parts
501826800103	ASSY KNOB (9SPD SINGLE-H)	TATA spare parts
501833000101	ASSY.FRONT AXLE COMP.WITH BRAKES	TATA spare parts
501843208202	BRACKET MTG. ASR ON LM	TATA spare parts
501843607501	GROMMET	TATA spare parts
501843700102	135 DEGREE ELBOW FOR HAND BRAKE VALVE	TATA spare parts
501845204201	SOLENOID MOUNTING BRACKET	TATA spare parts
501849100116	FLEX CONNECTOR OF 400MM LENGTH FOR 4.5IN	TATA spare parts
501849208212	SUPPORT BKT FROM GB	TATA spare parts
501849208213	CLAMP FOR PIPE	TATA spare parts
501926900105	BRACKET (OIL COOLER)	TATA spare parts
501926900106	ASSY OIL COOLER	TATA spare parts
501932100103	ASSY. FIRST LEAF W/BUSH BS3/4	TATA spare parts
501932100104	ASSEMBLY SPRING	TATA spare parts
501932100106	ASSEMBLY SPRING	TATA spare parts
501932100112	FIRST LEAF ASSY WITH BUSH	TATA spare parts
501932100115	FRONT LEAF SPRING ASSY	TATA spare parts
501932103201	CENTER BOLT M16X1.5X162	TATA spare parts
501932103202	CLAMP BOLT	TATA spare parts
501932103203	CENTER BOLT	TATA spare parts
501932103207	CENTRE BOLT M16X1.5X185	TATA spare parts
501932103301	SPRING HANGER BRACKET	TATA spare parts
501932103302	BRACKET-FRONT SPRING LH	TATA spare parts
501932103303	BRACKET-FRONT SPRING RH	TATA spare parts
501932104201	CLAMP	TATA spare parts
501932104202	U BOLT	TATA spare parts
501932104203	U BOLT	TATA spare parts
501932104205	SPRING CLIP	TATA spare parts
501932104209	U BOLT	TATA spare parts
501932104210	SPRING CLIP BS6	TATA spare parts
501932106501	NUT	TATA spare parts
501932107101	FIRST LEAF	TATA spare parts
501932107102	SECOND LEAF	TATA spare parts
501932107103	THIRD LEAF	TATA spare parts
501932107104	FOURTH LEAF	TATA spare parts
501932107105	CASTER PLATE	TATA spare parts
501932107106	FIFTH LEAF	TATA spare parts
501932107121	SECOND LEAF	TATA spare parts
501932107122	THIRD LEAF	TATA spare parts
501932107123	FOURTH LEAF	TATA spare parts
501932107124	FIFTH LEAF	TATA spare parts
501932107125	REBOUND LEAF	TATA spare parts
501932107127	CASTER PLATE	TATA spare parts

501932107401	RIVET SPRING CLIP BS6	TATA spare parts
501932108601	SPACER TUBE	TATA spare parts
501932108602	CENTER LINER	TATA spare parts
501932800101	ASSY BALL JOINT LINK ARB	TATA spare parts
501933000101	ASSY.FRONT AXLE TML BEAM 7.5T 6.5 DEG WI	TATA spare parts
501933805101	KNUCKLE ARM LH	TATA spare parts
501946300101	DRAG LINK LPK2538 LHD	TATA spare parts
501946304101	PITMAN ARM LHD	TATA spare parts
501958900102	ASSY. STORAGE BOX COMPLETE (LHD)	TATA spare parts
502000990102	KIT FULLYTRIMMED CABIN PRIMA 5530.S BSIV	TATA spare parts
502000990105	CABIN KIT PRIMA 4930.S	TATA spare parts
50202138000RCK	CABIN KIT FOR PRIMA 4928_S_LX Cab	TATA spare parts
502026800101	ASSY. COMPLETE GEARSHIFT UNIT	TATA spare parts
502026800102	ASSY. COMPLETE CABLE SHIFT	TATA spare parts
502026800103	ASSY . COMPLETE CABLE SELECTION	TATA spare parts
502026809901	TRANSFER LABLE (GEARSHIFT PATTERN USAGE)	TATA spare parts
502031000101	ASSY FRAME LPS 4928(6X4)	TATA spare parts
502031700101	ASSY KIT OF NOISE SHIELD	TATA spare parts
502032107104	CASTER PLATE BS6-PH2	TATA spare parts
502034100101	JOST 5TH WHEEL COUP 3.5 32T PRESSED	TATA spare parts
502034200103	PLATE & FIFTH WHEEL COUPLING ASSY	TATA spare parts
502041100102	ASSY PROPELLER SHAFT MAIN	TATA spare parts
502041100103	ASSY PROPELLER SHAFT MAIN	TATA spare parts
502041110101	UNIVERSAL JOINT BS3/4	TATA spare parts
502041110101DF	UJ CROSS 57X152-LPK2518/3118/2523/3123-L	TATA spare parts
502041115101	FLANGE YOKE	TATA spare parts
502041120102	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
502041120104	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
502041120115	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
502043200101	ASSY. LCRV MTG. BKT ON REAR FWD AXLE-LH	TATA spare parts
502043200102	ASSY. LCRV MTG. BKT ON REAR RWD AXILE-RH	TATA spare parts
502043200103	PULL ROD ASSY	TATA spare parts
502043203401	BUSH FOR MTG MODULATOR VALVE	TATA spare parts
502043203402	BUSH FOR FITMENT OF MODULATOR VALVE ON F	TATA spare parts
502043203403	BUSH FOR MTG MODULATOR VALVE ON FRAME	TATA spare parts
502043400101	ASSY. LINK FOR LCRV (LPS4928)	TATA spare parts
502043700136	BRAKE CHAMBER BS6-PH2	TATA spare parts
502043700148	SOLENOID VALVE BS6	TATA spare parts
502043700151	BRAKE CHAMBER BS6-PH2	TATA spare parts
502043700153	BRAKE CHAMBER BS6-PH2	TATA spare parts
502043700154	BRAKE CHAMBER BS6	TATA spare parts
502043700155	BRAKE CHAMBER BS6-PH2	TATA spare parts
502043700156	BRAKE CHAMBER BS6-PH2	TATA spare parts
502043700157	BRAKE CHAMBER BS6	TATA spare parts
502043703304	BRACKET FOR L.C.R.V	TATA spare parts
502043708203	BRACKET QRV MTG	TATA spare parts
502043708204	BRACKET BS6	TATA spare parts

502043900104	ASSY. NYLON PIPE ACRV PORT-42 TO VOSS AD	TATA spare parts
502043900112	ASSY. NYLON PIPE TEE-4 TO TEE-7	TATA spare parts
502043900117	ASSY. NYLON PIPE APU CONTROL PORT (4) TO	TATA spare parts
502043900118	ASSY. METAL PIPE FROM COMPRESSOR CONTROL	TATA spare parts
502043900122	ASSY. NYLON PIPE TEE-7 TO L.C.R.V. PORT	TATA spare parts
502043900127	ASSY. NYLON PIPE TEE-2 TO ANTI COMPOUNDI	TATA spare parts
502043900128	ASSY. NYLON PIPE TEE -7 TO ANTI COMPOUND	TATA spare parts
502043900129	ASSY. METAL PIPE COMPRESSOR	TATA spare parts
502043900135	ASSY. NYLON PIPE DBV PORT 21 TO TEE 4	TATA spare parts
502043900136	ASSY. NYLON PIPE DBV PORT 12 TO FRONT AI	TATA spare parts
502043900138	ASSY. NYLON PIPE DBV ADDITIONAL PORT 22	TATA spare parts
502043900150	ASSY. NYLON PIPE APU(24) TO NRV	TATA spare parts
502043900153	ASSY. NYLON PIPE TEE 4 TO TCV PORT 41	TATA spare parts
502043900155	ASSY. NYLON PIPE DBV TO PRESSURE SENSER	TATA spare parts
502043900157	ASSY. NYLON PIPE TEE-3 TO FRT.MODULATOR	TATA spare parts
502043900158	ASSY. NYLON PIPE DBV 22 TO TEE-1	TATA spare parts
502043900159	ASSY. NYLON PIPE FRONT RH MODULATOR VALV	TATA spare parts
502043900163	ASSY NYLON PIPE TEE- 16 TO TEE-17	TATA spare parts
502043900167	ASSY NYLON PIPE HBV PORT-21 TO VOSS ADAP	TATA spare parts
502043900178	ASSY METAL PIPE JOINT TO HOSE END	TATA spare parts
502043900179	ASSY. METAL PIPE COMPRESSER TO JOINT	TATA spare parts
502043900180	ASSY. NYLON PIPE MOD.VALVE TO RELAY VALV	TATA spare parts
502043900181	ASSY. NYLON PIPE RELAY VALVE TO MOD.VALV	TATA spare parts
502043900182	ASSY. NYLON PIPE RELAY VALVE R12 TO LCRV	TATA spare parts
502043900183	ASSY. NYLON PIPE ACRV TO QRV	TATA spare parts
502043900184	ASSY. NYLON PIPE ACRV TO QRV(REAR)	TATA spare parts
502043900185	ASSY. NYLON PIPE FRT QRV TO FWD REAR SBA	TATA spare parts
502043900186	ASSY. NYLON PIPE FRT QRV TO FWD LH SBA	TATA spare parts
502043900187	ASSY. NYLON PIPE QRV(R) TO RWD LH SBA	TATA spare parts
502043900188	ASSY. NYLON PIPE QRV (R) TO RWD RH SBA	TATA spare parts
502043900189	ASSY NYLON PIPE REAR MODULATOR VALVE RH	TATA spare parts
502043900191	ASSY NYLON PIPE SBA RR FWD RH TO TEE 22	TATA spare parts
502043900192	ASSY NYLON PIPE SBA RR RWD RH TO TEE-22	TATA spare parts
502043900193	ASSY NYLON PIPE REAR MOD.VALVE LH TO TEE	TATA spare parts
502043900194	ASSY NYLON PIPE SBA RR RWD LH TO TEE-21	TATA spare parts
502043900195	ASSY NYLON PIPE SBA RR FWD LH TO TEE-21	TATA spare parts
502043900196	ASSY. NYLON PIPE AIR TANK(R)TO AIR TANK	TATA spare parts
502043900197	ASSY. NYLON PIPE APU TO FRONT AIR TANK	TATA spare parts
502043900198	ASSY. NYLON PIPE RELAY VALVE TO AIR TANK	TATA spare parts
502043900199	ASSY. NYLON PIPE DBV TO REAR AIR TANK-1	TATA spare parts
502043900202	ASSY. NYLON PIPE AUXILLARY AIR TANK TO P	TATA spare parts
502043900203	ASSY. NYLON PIPE TEE-15 TO TEE-19	TATA spare parts
502043900204	ASSY. NYLON PIPE TEE-15 TO TEE-16	TATA spare parts
502043900205	ASSY. NYLON PIPE PARKING AIR TANK TO TEE	TATA spare parts
502043900206	ASSY. NYLON PIPE NRV PARKING TO TEE 9	TATA spare parts
502043900207	ASSY. NYLON PIPE REAR AIR TANK-I TO APU	TATA spare parts
502043900208	ASSY. NYLON PIPE TEE-9 TO TCV	TATA spare parts



502043900209	ASSY. NYLON PIPE AUXI. AIR TANK TO TEE-1	TATA spare parts
502043900210	ASSY. NYLON PIPE PARKING TANK TO PRV	TATA spare parts
502043900302	ASSY. NYLON PIPES	TATA spare parts
502043903301	BRACKET - METAL PIPE HOLDING	TATA spare parts
502043907901	PULL ROD(FITMENT OF LCRV LEVER)	TATA spare parts
502043910103	PIPE BUNCH ASSY BS6	TATA spare parts
502043910147	METAL PIPE ASSY INT JOINT TO INT JOINT B	TATA spare parts
502043910148	METAL PIPE ASSY TEFLON HOSE TO JOINT BS6	TATA spare parts
502043910149	METAL PIPE ASSY JOINT-3 TO APU BS6	TATA spare parts
502043910152	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
502047600101	ASSY.FUEL SUCTION LINE-F/TANK TO W/S	TATA spare parts
502047600102	ASSY.FUEL SUCTION LINE-W/S TO ENGINE	TATA spare parts
502047600103	ASSY.FUEL RETURN LINE-ENGINE TO F/TANK	TATA spare parts
502047600104	ASSY FUEL INTERCONNECTION LINE	TATA spare parts
502047600107	FUEL PIPE ASSY FUEL TANK INTERCONNECTION	TATA spare parts
502047600113	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
502047603301	BRACKET FUEL FILTER MTG	TATA spare parts
502049100101	ASSY SECOND PIPE FROM MUFFLER TO FLEX CO	TATA spare parts
502049100102	ASSY FIRST PIPE FROM TURBO TO FLEX CONNE	TATA spare parts
502049100106	ASSYEXHPIPEFROMFLEXTOSILENCER	TATA spare parts
502049108201	BRACKET FOR EXHAUST BRAKE SUPPORT	TATA spare parts
502049108203	BARCKET FOR EXHAUST ELBOW SUPPORT	TATA spare parts
502049108204	SUPPORT BRACKET FOR EXHAUST BRAKE	TATA spare parts
502049200104	SUCTION LINE TANK TO SM	TATA spare parts
502049200105	SUCTION LINE TANK TO SM BS6-PH2	TATA spare parts
502054600114	WIRING HARNESS TAIL BS6	TATA spare parts
502054630102	WIRING HARNESS TAIL BS6	TATA spare parts
502054720102	REAR VIEW CAMERA	TATA spare parts
50206250M10101	BRACKET ASSY AERO CORNER MTG LH BS6-PH2	TATA spare parts
50206250M10102	BRACKET ASSY AERO CORNER MTG RH BS6-PH2	TATA spare parts
50206320M10101	REINFORCEMENT ASSY DOOR HINGE LH BS6-PH2	TATA spare parts
50206320M10102	REINFORCEMENT ASSY DOOR HINGE RH BS6-PH2	TATA spare parts
50206320M10104	ASSY REINF STRIKER BS6-PH2	TATA spare parts
50206360M10107	A-PILLAR ASSY LH BS6-PH2	TATA spare parts
50206360M10108	A-PILLAR ASSY RH BS6-PH2	TATA spare parts
50206510M10160	ROOF RAIL ASSY BS6-PH2	TATA spare parts
50206538000RCK	ASSY CABIN KIT W/FITMENT PRIMA 5530 BS6	TATA spare parts
50207220M10103	OUTER PANEL ASSY FRONT DOOR LH BS6-PH2	TATA spare parts
50207220M10104	OUTER PANEL ASSY FRONT DOOR RH BS6-PH2	TATA spare parts
50207220M10177	PANEL ASSY FRONT DOOR INNER-LH BS6-PH2	TATA spare parts
50207220M10194	DOOR SHELL ASSY LH BS6-PH2	TATA spare parts
50207220M10195	DOOR SHELL ASSY RH BS6-PH2	TATA spare parts
502077	CIRCLIP	TATA spare parts
50208410M10152	BRACKET ASSY HEADBOX MTG LH BS6-PH2	TATA spare parts
50208410M10153	BRACKET ASSY HEADBOX MTG RH BS6-PH2	TATA spare parts
50208410M10154	BRACKET ASSY HEADBOX MTG LH BS6-PH2	TATA spare parts
50208410M10155	BRACKET ASSY HEADBOX MTG RH BS6-PH2	TATA spare parts

502100990102	ASSY CABIN KIT FOR PRIMA LX 2528.K BS3	TATA spare parts
502100990103	ASSY. CABIN KIT PRIMA 2528.K SLP BLW BS3	TATA spare parts
502100990104	FULLY TRIMMED CABIN PRIMA2530.K upgrade	TATA spare parts
502100990105	KIT FULLY TRIMMED CABIN- PRIMA3428.T LHD	TATA spare parts
502100990106	KIT FULLY TRIMMED CABIN FOR PRIMA 3328.K	TATA spare parts
502124208301	SHIM 1 MM THK	TATA spare parts
502126800101	BRACKET (SELECT CABLE)	TATA spare parts
502126803701	BRACKET(SHIFT CABLE)	TATA spare parts
502126808201	CLAMP (OIL COOLER HOSE)	TATA spare parts
502126808201AE	CLAMP (OIL COOLER HOSE)	TATA spare parts
502126808202	OIL COOLER HOSE CLAMP BKT	TATA spare parts
502126808204	HOSE CLAMP	TATA spare parts
502126900102	ASSY METAL PIPE (OIL COOLER)	TATA spare parts
502126900103	ASSY METAL PIPE (OIL COOLER)	TATA spare parts
502126900104	ASSY. HOSE (OIL COOLER )	TATA spare parts
502126900105	ASSY. HOSE (OIL COOLER )	TATA spare parts
502126900106	ASSY BRACKET (OIL PIPE MOUNTING)	TATA spare parts
502126900116	ASSY. HOSE (OIL COOLER LPK2528 INT. SERV	TATA spare parts
502126900117	ASSY. HOSE (OIL COOLER LPK2528 INT. SERV	TATA spare parts
502126900120	OIL COOLER METAL PIPE LPK2528 INT. SERVO	TATA spare parts
502126900121	OIL COOLER METAL PIPE LPK2528 INT. SERVO	TATA spare parts
502126900125	PIPE ASSY	TATA spare parts
502126906801	BANJO M16X1.5	TATA spare parts
502126907103	CLIP FOR MOUNTING	TATA spare parts
502129100103	ASSY PNEUMATIC PIPE FOR CLUTCH BOOSTER	TATA spare parts
502131000101	ASSY FRAME LPK2528(6X4) 39WB	TATA spare parts
502131000102	ASSY FRAME LPK2528(6X4) 45WB	TATA spare parts
502131000103	FRAME ASSY COMPLETE	TATA spare parts
502131000106	FRAME ASSY COMPLETE (F2 TYPE)	TATA spare parts
502131000109	FRAME ASSY	TATA spare parts
502131000110	FRAME ASSY WITH FITMENT	TATA spare parts
502131000113	FRAME ASSY FOR LX 2528.K	TATA spare parts
502131000114	FRAME ASSY	TATA spare parts
502131000116	FRAME ASSY	TATA spare parts
502131000118	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
502131000126	FRAME ASSY	TATA spare parts
502131000129	FRAME ASSY	TATA spare parts
502131000130	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
502131107103	REINFORCEMENT- LH	TATA spare parts
502131107104	REINFORCEMENT -RH	TATA spare parts
502131107107	REINFORCEMENT- LH	TATA spare parts
502131107108	REINFORCEMENT-RH	TATA spare parts
502131107157	REINFORCEMENT LH	TATA spare parts
502131107158	REINFORCEMENT RH	TATA spare parts
502131107171	REINFORCEMENT FRONT	TATA spare parts
502131200104	ASSEMBLY 1ST CROSS MEMBER FOR M0 BUMPER	TATA spare parts
502131540102	BRACKET ASSY BATTERY TRAY MTG	TATA spare parts

502131540103	BRACKET ASSY BATTERY TRAY MTG	TATA spare parts
502131700105	BATTERY CARRIER & AIR TANK MTG ASSY	TATA spare parts
502131700111	ASSY HEAT SHILED FOR TURBO CHARGER	TATA spare parts
502131700113	ASSEMBLY HEAT SHILED COMPLETE	TATA spare parts
502131700114	ASSLY BUMP STOPPER BRKT FOR LPK2528	TATA spare parts
502131700116	ASSY MAIN RUPD 2528.K 6 X 4 45WB	TATA spare parts
502131700117	BEAM ASSY RUPD	TATA spare parts
502131700121	ASSY MAIN BRACKET-LH	TATA spare parts
502131700122	ASSY MAIN BRACKET-RH	TATA spare parts
502131700123	BRACKET ASSY GEAR BOX MTG LH	TATA spare parts
502131700124	BRACKET ASSY GEAR BOX MTG RH	TATA spare parts
502131700126	ASSEMBLY SUMP GUARD	TATA spare parts
502131700127	SUMP GUARD ASSY COMPLETE	TATA spare parts
502131700128	SUMP GUARD ASSY	TATA spare parts
502131700129	BEAM ASSY RUPD	TATA spare parts
502131700132	BRACKET ASSY RUPD MTG	TATA spare parts
502131707113	SIDE PLATE	TATA spare parts
502132408302	SHIM	TATA spare parts
502133000102	ASSY. FRONT AXLE COMPLETE WITH BRAKE	TATA spare parts
502133000103	FA LPK2528 45WB 15MM DR. FAB/100T PW/ KB	TATA spare parts
502133000105	ASSY.FRONT AXLE FOR VEH 2523 K FOR SA	TATA spare parts
502133000108	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
502133000110	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
502133200101	STUB AXLE ASSY LH (PLUMMER BLOCK)	TATA spare parts
502133200102	STUB AXLE ASSY RH (PLUMMER BLOCK)	TATA spare parts
502133800101	TIE ROD ASSEMBLY	TATA spare parts
502133805103	TIE ROD ARM-LH	TATA spare parts
502133805104	TIE ROD ARM-RH	TATA spare parts
502133805105	TIE ROD ARM RH BS6	TATA spare parts
502133805106	TIE ROD ARM LH BS6	TATA spare parts
502133990101	TIE ROD END ASSY LH	TATA spare parts
502133990102	TIE ROD END ASSY RH	TATA spare parts
502140100118	WHEEL RIM ASSY	TATA spare parts
502140300101	SPARE TYRE MOUNTING BRACKET	TATA spare parts
502140300102	S/TYRE MNTG BRKT WITH LOCKING ARRANGEMN	TATA spare parts
502140300103	BRACKET ASSY WITH WELDED NUT	TATA spare parts
502140300106	SPARE WHEEL MTG ASSY BS6	TATA spare parts
502140300107	SPARE WHEEL MTG ASSY BS6	TATA spare parts
502141100101	ASSY.PROP SHAFT FRONT	TATA spare parts
502141100104	PROPELLER SHAFT ASSY FRONT BS6	TATA spare parts
502141100105	ASSY PROP SHAFT FRONT 2528.K SA 45 WB	TATA spare parts
502141100108	PROPELLER SHAFT ASSY REAR	TATA spare parts
502141100109	ASSY PROP SHAFT MAIN	TATA spare parts
502141110103	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
502141110104	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
502141120101	ASSY. PROP SHAFT INTERAXLE BS3/4	TATA spare parts
502141120106	PROPELLER SHAFT ASSY INTERAXLE	TATA spare parts

502141120109	LONG FORK SUB ASSY	TATA spare parts
502141120110	SHORT FORK & REAR HSG SUB ASSY	TATA spare parts
502141120121	SEALED UNIVERSAL JOINT ASSY	TATA spare parts
502141120122	LONG_FORK SUB ASSY (110)	TATA spare parts
502141120126	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
502141120131	UNIVERSAL JOINT ASSY	TATA spare parts
502141120132	PROPELLER SHAFT DRIVE ASSY	TATA spare parts
502141120136	PROPELLER SHAFT ASSY INTERAXLE	TATA spare parts
502141120137	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
502141120140	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
502141120141	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
502141120142	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
502141120144	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
502141120145	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
502141120148	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
502141125101	FLANGE	TATA spare parts
502141125103	FLANGE YOKE	TATA spare parts
502141129901	BELLOW	TATA spare parts
502141300101	BRACKET ASSY CENTER BRG MTG	TATA spare parts
502141303301	BRACKET CENTER BRG MTG	TATA spare parts
502142100111	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
502142100112	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
502142100118	ASSY.FRONT BRAKE WITH D/C RH	TATA spare parts
502142100119	ASSY.FRONT BRAKE WITH D/C LH	TATA spare parts
502142100141	DRUM BRAKE ASSY FRONT -LH.DIA410X200 M16	TATA spare parts
502142100142	DRUM BRAKE ASSY FRONT -RH.DIA410X200 M16	TATA spare parts
502142103701	BRAKE DRUM	TATA spare parts
502142308201	ANCHOR BRACKET-AUTO SLACK ADJUSTER	TATA spare parts
502142308601	CONNECTOR SPRING BRAKE ACTUATOR	TATA spare parts
502142990103	BRACKET ASSY -LH (100 DEG)	TATA spare parts
502142990104	BRACKET ASSY -RH (100 DEG)	TATA spare parts
502142990105	TUBE - FLANGE AND BRACKET ASSY - LH	TATA spare parts
502142990106	TUBE - FLANGE AND BRACKET ASSY - RH	TATA spare parts
502142990119	DRUM BRAKE -LINED SHOE ASSY NA1707	TATA spare parts
502142990121	BRAKE LINING STD-410X200 NA1707 BS6-PH2	TATA spare parts
502142990128	DRUM BRAKE -TUBE FLANGE BRACKET ASSY RH	TATA spare parts
502142990129	KIT-TUBE FLANGE BRACKET ASSY LH	TATA spare parts
502142990130	KIT-TUBE FLANGE BRACKET ASSY RH	TATA spare parts
502143200101	AIR TANK ASSY WITH BKTS & STRAP 15 LIT	TATA spare parts
502143200102	AIR TANK ASSY	TATA spare parts
502143200103	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
502143200109	SUB ASSY.AIR TANK-20LIT (VOSS)	TATA spare parts
502143700111	BRACKET ASSY MODULATOR VALVE MTG	TATA spare parts
502143700112	BRAKE CHAMBER WITH VOSS PORT TYPE 24 KB	TATA spare parts
502143700130	SPRING BRAKE ACTUATOR TYPE-16/24 S/O-350	TATA spare parts
502143700131	SPRING BRAKE ACTUATOR BS6	TATA spare parts
502143700171	SPRING BRAKE ACTUATOR	TATA spare parts

502143703301	BRACKET QRV MTG	TATA spare parts
502143703303	BRACKET RELAY VALVE MTG	TATA spare parts
502143703304	BRACKET	TATA spare parts
502143708205	BRACKET ACRV MOUNTING	TATA spare parts
502143900102	ASSY NYLON BUNCH FOR LPK 2528 45(WB) LHD	TATA spare parts
502143900116	NYLON PIPE BUNCH ASSY	TATA spare parts
502143900127	PIPE BUNCH ASSY	TATA spare parts
502143900129	NYLON PIPE BUNCH ASSY	TATA spare parts
502143900131	PIPE BUNCH ASSY	TATA spare parts
502143900190	METAL PIPE ASSY 1ST PIPE TO TEFLON HOSE	TATA spare parts
502143900201	ASSY NYLON PIPE BUNCH FOR LPK2528(39WB)	TATA spare parts
502143900203	ASSY. METAL PIPE	TATA spare parts
502143900207	ASSY NYLON PIPE AIR TANK PARKING TO PRV	TATA spare parts
502143900209	ASSY.NYLON PIPE APU PORT-24 TO NRV	TATA spare parts
502143900210	ASSY NYLON PIPE NRV TO PRV (AUXILLARY)	TATA spare parts
502143900211	ASSY NYLON PIPE AIR TANK AUXILARY TO PRV	TATA spare parts
502143900212	ASSY NYLON PIPE APU PORT-22 TO FRONT AIR	TATA spare parts
502143900213	ASSY NYLON PIPE APU PORT-21 TO REAR AIR	TATA spare parts
502143900214	ASSY. NYLON PIPE APU PORT-23 TO NRV (PAR	TATA spare parts
502143900215	ASSY. NYLON PIPE NRV TO PRV PARKING	TATA spare parts
502143900216	ASSY. NYLON PIPE TEE-3 TO TEE-4	TATA spare parts
502143900217	ASSY. NYLON PIPE TEE-3 TO REAR RH RV	TATA spare parts
502143900218	ASSY. NYLON PIPE TEE-3 TO REAR LH RV	TATA spare parts
502143900219	ASSY. NYLON PIPE TEE-6 TO REAR LH RV	TATA spare parts
502143900220	ASSY. NYLON PIPE TEE-6 TO REAR RH RV	TATA spare parts
502143900221	ASSY. NYLON PIPE AIR TANK PARKING TO TEE	TATA spare parts
502143900222	ASSY. NYLON PIPE TEE-2 TO ACRV PORT-1	TATA spare parts
502143900224	METAL PIPE ASSY	TATA spare parts
502143900225	ASSY NYLON PIPE TEE-4 TO REAR AIR TANK	TATA spare parts
502143900226	ASSY NYLON PIPE TEE-1 TO DBV PORT 22	TATA spare parts
502143900227	ASSY NYLON PIPE TEE-1 TO FRONT MV RH	TATA spare parts
502143900228	ASSY NYLON PIPE TEE-1 TO FRONT MV LH	TATA spare parts
502143900230	ASSY NYLON PIPE DBV PORT-11 TEE-4	TATA spare parts
502143900231	ASSY NYLON PIPE DBV PORT-12 TO FRONT AIR	TATA spare parts
502143900232	ASSY NYLON PIPE DBV PORT-21 TO TEE-5	TATA spare parts
502143900233	ASSY NYLON PIPE HBV TO TEE-2	TATA spare parts
502143900234	ASSY NYLON PIPE HBV TO ACRV PORT-42	TATA spare parts
502143900235	ASSY NYLON PIPE AIR TANK PARKING TO PRV	TATA spare parts
502143900236	ASSY.NYLON PIPE AIR TANK AUXILARY TO TEE	TATA spare parts
502143900237	METAL PIPE ASSY	TATA spare parts
502143900238	ASSY NYLON PIPE TEE-5 TO ACRV PORT-41	TATA spare parts
502143900239	ASSY NYLON PIPE TEE-5 TO TEE-6	TATA spare parts
502143900241	ASSY NYLON PIPE ACRV PORT-2 TO TEE-15	TATA spare parts
502143900243	ASSY NYLON PIPE REAR MV RH TO TEE-7	TATA spare parts
502143900244	ASSY NYLON PIPE TEE-7 TO SBA REAR FWD RH	TATA spare parts
502143900245	ASSY NYLON PIPE TEE-7 TO SBA REAR RWD RH	TATA spare parts
502143900246	ASSY NYLON PIPE TEE-9 TO REAR MV LH	TATA spare parts

502143900247	ASSY NYLON PIPE TEE-9 TO SBA REAR FWD LH	TATA spare parts
502143900248	ASSY NYLON PIPE TEE-9 TO SBA REAR RWD LH	TATA spare parts
502143900249	ASSY. NYLON PIPE TEE-15 TO SBA RR. FWD L	TATA spare parts
502143900250	ASSY NYLON PIPE HBV TO ACRV PORT-42	TATA spare parts
502143900256	ASSY. NYLON PIPE TEE-15 TO SBA RR. RWD L	TATA spare parts
502143900257	ASSY NYLON PIPE ACRV PORT-2 TO TEE-8	TATA spare parts
502143900258	ASSY.NYLON PIPE SBA RR FWD RH TO TEE-8	TATA spare parts
502143900259	ASSY. NYLON PIPE TEE-8 TO SBA REAR RWD (	TATA spare parts
502143900264	ASSY METAL PIPE TO APU	TATA spare parts
502143900267	ASSY NYLON PIPE TEE-23 TO TEE-24	TATA spare parts
502143900271	ASSY NYLON PIPE TEE-22 TO TEE-23	TATA spare parts
502143900272	ASSY NYLON PIPE TEE 20 TO TEE 21	TATA spare parts
502143900273	ASSY NYLON PIPE TEE 21 TO TEE 22	TATA spare parts
502143900276	ASSY NYLON PIPE ACRV PORT-2 TO TEE-8	TATA spare parts
502143900277	ASSY NYLON PIPE ACRV PORT-2 TO TEE-15	TATA spare parts
502143900278	ASSY NYLON PIPE TEE-5 TO ACRV PORT-41	TATA spare parts
502143900279	ASSY. NYLON PIPE TEE-2 TO ACRV PORT-1	TATA spare parts
502143900281	ASSY. NYLON PIPE AIR TANK PARKING TO TEE	TATA spare parts
502143900282	ASSY NYLON PIPE TEE-5 TO TEE-6	TATA spare parts
502143900283	ASSY. NYLON PIPE TEE-6 TO REAR RH RV	TATA spare parts
502143900284	ASSY. NYLON PIPE TEE-6 TO REAR LH RV	TATA spare parts
502143900287	ASSY. NYLON PIPE TEE-3 TO TEE-4	TATA spare parts
502143900288	ASSY. NYLON PIPE TEE-3 TO REAR RH RV	TATA spare parts
502143900289	ASSY. NYLON PIPE TEE-3 TO REAR LH RV	TATA spare parts
502143900296	ASSY NYLON PIPE TEE-24 TO SOLENOID VALVE	TATA spare parts
502143900297	ASSY NYLON PIPE SOLENOID VALVE TO EXHAUS	TATA spare parts
502143900298	ASSY NYLON PIPE DBV PORT-21 TO TEE-5	TATA spare parts
502143900299	ASSY. METAL PIPE FROM 1ST PIPE TO HOSE	TATA spare parts
502143900301	ASSY. OF NYLON BUNCH	TATA spare parts
502143900306	ASSY. NYLON PIPE APU PORT-21 TO REAR AIR	TATA spare parts
502143900308	ASSY. OF NYLON PIPE APU PORT 24 TO PRV	TATA spare parts
502143900385	ASSY NYLON PIPE APU SIGNAL PORT TO COMPR	TATA spare parts
502143900394	ASSY NYLON PIPE FROM TEE-1 TO FRONT MVLH	TATA spare parts
502143903301	BRACKET FOR HOLDING METAL PIPES	TATA spare parts
502143903302	BRACKET METAL PIPE MTG	TATA spare parts
502143908601	SPACER 7 MM THK 26MM OUTER DIA & 13MM IN	TATA spare parts
502143910101	NYLON PIPE BUNCH ASSY	TATA spare parts
502143910104	ASSY NYLON PIPE FROM TEE6 TO RELAY VALVE	TATA spare parts
502143910105	ASSY NYLON PIPE FROM TEE-6 TO RELAY VAL	TATA spare parts
502143910107	ASSY NYLON PIPE FROM MODULATOR VALVE RR	TATA spare parts
502143910108	ASSY NYLON PIPE FROM TEE-3 TO REAR RH RV	TATA spare parts
502143910109	ASSY.NYLON PIPE FROM TEE-3 TO REAR RWD R	TATA spare parts
502143910110	METAL PIPE ASSY COMP OUTLET 4TH	TATA spare parts
502143910118	ASSY NYLON PIPE FROM TEE 2 TO VOSS ADAPT	TATA spare parts
502143910134	ASSY NYLON PIPE TEE-5 TO ACRV PORT-41	TATA spare parts
502143910135	ASSY. NYLON PIPE FROM TEE-4 TO TEE-3	TATA spare parts
502143910136	ASSY NYLON PIPE FROM REAR AIR TANK TO TE	TATA spare parts

502143910203	ASSY BUNCH 2528K 45WB R F2 FOR DROP AXLE	TATA spare parts
502143910205	ASSY NYLON PIPE TEE-5 TO ACRV PORT-41	TATA spare parts
502143910206	ASSY NYLON PIPE TEE-5 TO TEE-6	TATA spare parts
502143910207	ASSY NYLON PIPE FROM A C R.V PORT 2 TO T	TATA spare parts
502143910208	ASSY NYLON PIPE FROM TEE-8 TO SBA RR FWD	TATA spare parts
502143910209	ASSY. NYLON PIPE APU PORT-23 TO NRV (PAR	TATA spare parts
502143910210	ASSY NYLON PIPE FROM PRV TO NRV OF AIR T	TATA spare parts
502143910212	ASSY NYLON PIPE AIR TANK AUXILARY TO TEE	TATA spare parts
502143910213	ASSY NYLON PIPE FROM APU SIGNAL PORT TO	TATA spare parts
502143910214	ASSY NYLON PIPE FROM TEE-9 TO BRAKE CHAM	TATA spare parts
502143910215	ASSY NYLON PIPE TEE-7 TO BRAKE CHAMBER L	TATA spare parts
502143910216	ASSY NYLON PIPE FROM TEE-8 TO SBA REAR F	TATA spare parts
502143910217	ASSY NYLON PIPE FROM TEE-7 TO SBA REAR F	TATA spare parts
502143910218	ASSY NYLON PIPE FROM TEE-9 TO SBA REAR F	TATA spare parts
502143910219	ASSY NYLON PIPE FROM AIR TANK PARKING TO	TATA spare parts
502143910220	ASSY NYLON PIPE HBV TO ACRV PORT-42	TATA spare parts
502143910221	ASSY NYLON PIPE FROM ACRV PORT-2 TO TEE-	TATA spare parts
502143910225	ASSY NYLON PIPE TEE-2 TO ACRV PORT-1	TATA spare parts
502143910226	ASSY NYLON PIPE FROM APU PORT-22 TO FRON	TATA spare parts
502143910230	ASSY NYLON PIPE FROM TEE1 TO MODULATOR V	TATA spare parts
502143910232	ASSY NYLON PIPE TEE-4 TO DBV PORT 11	TATA spare parts
502143910233	ASSY NYLON PIPE DBV PORT-22 TO TEE-1	TATA spare parts
502143910234	ASSY NYLON PIPE DBV 21 TO TEE5	TATA spare parts
502143910235	ASSY NYLON PIPE FRONT AIR TANK TO DBV PO	TATA spare parts
502143910248	ASSY NYLON PIPE SOLENOID VALVE TO EXHAUS	TATA spare parts
502143920106	PIPEBUNCHASSY	TATA spare parts
502143920107	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
502143920126	NYLON PIPE BUNCH ASSY	TATA spare parts
502143940104	BUNCH PIPE ASSY	TATA spare parts
502143940157	PIPE ASSY THIRD METAL PIPE	TATA spare parts
502143940158	PIPE ASSY FOURTH METAL PIPE	TATA spare parts
502143940161	PIPE BUNCH ASSY FOR APU	TATA spare parts
502143950122	PIPE ASSY MOD VALVE TO TEE-4	TATA spare parts
502143950124	PIPE ASSY MOD VALVE TO TEE-5	TATA spare parts
502143950145	PIPE ASSY APDA-4 TO CONTROL PORT JOINT	TATA spare parts
502143950150	NYLON PIPE BUNCH ASSY	TATA spare parts
502143960111	PIPE BUNCH ASSY COMPLETE FOR APU	TATA spare parts
502143960132	PIPE ASSY TCV TO CONTROL PORT JOINT	TATA spare parts
502143960145	PIPE ASSY	TATA spare parts
502143960151	PIPE ASSY FOURTH METAL PIPE	TATA spare parts
502143960152	PIPE ASSY FIFTH METAL PIPE	TATA spare parts
502143960153	METAL PIPE ASSY JOINT TO APU	TATA spare parts
502143960155	PIPE ASSY THIRD METAL PIPE	TATA spare parts
502143960162	METAL PIPE ASSY JOINT TO APDA	TATA spare parts
502143960180	METAL PIPE ASSY COMP OUTLET 3RD	TATA spare parts
502143980103	NYLON PIPE BUNCH ASSY	TATA spare parts
502145100102	SET ASSY. COMP.NYLON PIPE BUNCH FOR SOLE	TATA spare parts

502145100118	ASSY. PIPE BUNCH FOR PNEUMATIC CONNECTIO	TATA spare parts
502145100145	NYLON BUNCH FOR SOLENOID - DIFF LOCK	TATA spare parts
502145903301	L-BRACKET	TATA spare parts
502146100101	STG GEAR BOX - 8046 TYPE 1 - CONSTANT RA	TATA spare parts
502146100102	STEERING GEAR BOX	TATA spare parts
502146200101	INTERMEDIATE SHAFT - STRG	TATA spare parts
502146300101	ASSY. DRAG LINK BS3/4/6	TATA spare parts
502146304101	DROP ARM	TATA spare parts
502146304102	DROP ARM	TATA spare parts
502146600102	HOUSING ASSY	TATA spare parts
502146600103	STEERING GEAR BOX ASSY BS6	TATA spare parts
502146603302	BRKT-STG RESERVOIR MTG	TATA spare parts
502146603303	STG RESERVOIR MTG BRKT	TATA spare parts
502146800101	PRESSURE LINE ASM G.B END	TATA spare parts
502146800103	PRESSURE LINE ASM. PUMP END	TATA spare parts
502146800104	RETURN LINE ASM RESERVOIR END	TATA spare parts
502146800105	SUCTION LINE ASM	TATA spare parts
502146800106	PRESSURE LINE HOSE & PIPE ASSY. GEAR BOX	TATA spare parts
502146800107	PRESSURE LINE HOSE & PIPE ASSY. PUMP END	TATA spare parts
502146800108	RETURN LINE HOSE & PIPE ASSY. GEAR BOX E	TATA spare parts
502146800109	RETURN LINE HOSE & PIPE ASSY. RES. END	TATA spare parts
502146800110	SUCTION LINE HOSE & PIPE ASSY.	TATA spare parts
502146800111	PIPING AUXILIARY TANK END	TATA spare parts
502146800112	PRESSURE LINE ASSY STG GEAR BOX END	TATA spare parts
502146800113	AUXILIARY PIPING SOLENOID VALVE END	TATA spare parts
502146800116	RETURN LINE ASM-G B END	TATA spare parts
502146800118	ASSY RETURN LINE AND HOSES AT GB END	TATA spare parts
502146800119	HIGH PRESSURE LINE ASSY	TATA spare parts
502146800128	ASSY PNEUMATIC PIPE FOR L2 VERSION	TATA spare parts
502146800129	SUCTION LINE ASM. TYPE-I	TATA spare parts
502146800130	RETURN LINE ASSLY RESERVOIR END TYPE-I	TATA spare parts
502146800131	PRESSURE LINE GEAR BOX END TYPE-I	TATA spare parts
502146800132	RETURN LINE HOSE & PIPE ASSY(I)	TATA spare parts
502146800133	PRESSURE LINE ASSY. PUMP END TYPE-I	TATA spare parts
502146800141	RETURN LINE ASSY RESERVOIR END	TATA spare parts
502146800142	RETURN LINE ASSY STG GEAR BOX END	TATA spare parts
502146803301	BRKT STG PIPE MTG	TATA spare parts
502146803302	BRKT STG PIPE MTG	TATA spare parts
502147600101	ASSY FUEL SUCTION LINE FUEL TANK TO W/S	TATA spare parts
502147600102	ASSY FUEL SUCTION LINE W/S TO ENGINE	TATA spare parts
502147600103	ASSY FUEL RETURN LINE ENGINE TO FUEL TAN	TATA spare parts
502147600104	ASSY FUEL SUCTION LINE(W/S TO ENGINE)	TATA spare parts
502147600106	ASSY FUEL LINE FUEL TANK TO FUEL FILTER	TATA spare parts
502147600107	ASSY FUEL SUCTION LINE FUEL FILTER TO EN	TATA spare parts
502147600108	ASSY FUEL LINE FUEL TANK TO FUEL FILTER	TATA spare parts
502147600109	SUCTION LINE ASSY (TANK TO FILTER)	TATA spare parts
502147600110	RETURN LINE ASSY ON TANK(FROM ENGINE)	TATA spare parts



502147600111	SUCTION LINE (FUEL TANK TO W/S)	TATA spare parts
502147600112	RETURN LINE ASSY ON TANK	TATA spare parts
502147600113	SUCTION LINE (W/S TO ENGINE)	TATA spare parts
502147600114	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
502147600115	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
502147600116	FUEL SUCTION PIPE ASSY TANK TO P/FILTER	TATA spare parts
502147600117	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
502147600118	FUEL SUCTION PIPE ASSY P/FILTER TO W/SEP	TATA spare parts
502147600119	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
502147600120	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
502147600121	FUEL SUCTION PIPE ASSY P/FILTER TO W/SEP	TATA spare parts
502147600123	SUCTION PIPE ASSY	TATA spare parts
502147600124	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
502147700101	BRACKET ASSY FUEL FILTER MTG	TATA spare parts
502149100101	ASSY. FIRST PIPE BS3	TATA spare parts
502149100102	SECOND PIPE ASSY	TATA spare parts
502149100103	SOLENOID VALVE MOUNTING ASSY	TATA spare parts
502149100109	ASSY STRUCTURE SILENCER MOUNTING	TATA spare parts
502149100114	V BAND CLAMP FOR TURBACHARGER	TATA spare parts
502149100120	ASSY STAY ROD MOUNTING BRACKET LPK 2528	TATA spare parts
502149100122	HEAT SHIELD ASSY	TATA spare parts
502149108205	HEAT SHIELD ON FIRST PIPE	TATA spare parts
502149108212	EXHAUST BRAKE SUPPORT BRACKET	TATA spare parts
502149200101	TAIL PIPE ASSEMBLY	TATA spare parts
502149200105	EXHAUST PIPE ASSY	TATA spare parts
502149200106	BRACKET ASSY EXHAUST PIPE MTG	TATA spare parts
502149200109	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
502149203301	BRACKET	TATA spare parts
502149203701	EXHAUST PIPE FRONT (T/C TO EXH. BRAKE)	TATA spare parts
502149206904	EXHAUST TAIL PIPE	TATA spare parts
502149207101	BRACKET SUPPORT (EXHAUST BRAKE UNIT)	TATA spare parts
502154600104	WIRING HARNESS DOSING UNIT	TATA spare parts
502154600105	WIRING HARNESS TAIL	TATA spare parts
502154600106	WIRING HARNESS ENGINE	TATA spare parts
502154600107	WIRING HARNESS SIDE REPEATER	TATA spare parts
502154600108	WIRING HARNESS DASHBOARD	TATA spare parts
502154600109	BATTERY CABLE LINK BS6 PH2	TATA spare parts
502154600112	BATTERY CABLE +VE MEGA FUSE O/P TO SM	TATA spare parts
502154600113	WIRING HARNESS FRAME	TATA spare parts
502154600114	WIRING HARNESS DASHBOARD BS6	TATA spare parts
502154600115	WIRING HARNESS WIPER BS6	TATA spare parts
502154600121	WIRING HARNESS ABS FRAME	TATA spare parts
502154600123	WIRING HARNESS DASHBOARD	TATA spare parts
502154600124	BATTERY CABLE +VE MEGA FUSE O/P TO SM	TATA spare parts
502154700102	BRACKET ASSY VECU MTG	TATA spare parts
502154709911	FLASHER	TATA spare parts
502224203701	ENGINE MTG. BRKT. REAR FRAME	TATA spare parts

502224203702	REAR ENGINE MTG. PLATE	TATA spare parts
502224203703	BRKT-ENG MTG RR F/W HSG	TATA spare parts
502224203704	ENG MTG BRKT REAR F/W HSG.	TATA spare parts
502226715101	COUNTER WEIGHT	TATA spare parts
502226800103	ASSY. PIPE BUNCH FOR PNEUMATIC CONNECTIO	TATA spare parts
502226800105	COMPLETE ASSY. SHIFT CABLE FOR LPK3128	TATA spare parts
502226800106	ASSY.COMP SEL CABLE 3128K	TATA spare parts
502226800107	GEARSHIFT UNIT WITH CABLES	TATA spare parts
502226800108	CABLE GEAR SHIFT UNIT	TATA spare parts
502226800109	SHIFT CABLE ASSY	TATA spare parts
502226800113	SHIFT CABLE ASSY	TATA spare parts
502226800114	SELECTION CABLE ASSY	TATA spare parts
502226800115	CABLE ASSY GEAR SHIFT UNIT	TATA spare parts
502226900106	ASSY OIL COOLER HOSE	TATA spare parts
502226900107	ASSY OIL COOLER	TATA spare parts
502226900113	ASSY PIPE (FOR BYPASS VALVE)	TATA spare parts
502229000103	ASSY. INTEGRATED PEDAL UNIT (TYPE-1)	TATA spare parts
502229100103	ASSY PNEUMATIC PIPE FOR CLUTCH BOOSTER	TATA spare parts
502229100104	ASSY PNEUMATIC PIPE FOR CLUTCH BOOSTER	TATA spare parts
502231000101	ASSY. FRAME	TATA spare parts
502231000104	ASSEMBLY FRAME	TATA spare parts
502231000105	FRAME ASSY	TATA spare parts
502231000108	FRAME ASSY	TATA spare parts
502231200101	ASSEMBLY CROSS MEMBER (PROP SHAFT)	TATA spare parts
502231307101	GUSSET UPPER(PROP SHAFT)	TATA spare parts
502231307103	GUSSET LH	TATA spare parts
502231307104	GUSSET RH	TATA spare parts
502231307105	GUSSET FOR CTR CROSSMEMBER	TATA spare parts
502231700115	ASSEMBLY HEAT SHILED COMPLETE	TATA spare parts
502231990101	UNDERBODY ENGINE GUARD RETRO SUMP GUAR	TATA spare parts
502232100102	ASSY.LINK ROD FRONT	TATA spare parts
502232100103	ASSLY.SPRING HANGER BKT.FRONT RWD	TATA spare parts
502232100105	ASSY PARABOLIC SPRING FRONT FWD	TATA spare parts
502232100106	ASSY PARABOLIC SPRING FRONT RWD	TATA spare parts
502232103201	CENTER BOLT M16X1.5X140 BS6	TATA spare parts
502232103202	CENTER BOLT FRONT FWD	TATA spare parts
502232104201	U BOLT FRONT	TATA spare parts
502232104202	U BOLT FRONT	TATA spare parts
502232107101	CASTER PLATE	TATA spare parts
502232107102	SPRING SPACER	TATA spare parts
502232307101	BRACKET SHOCK ABSORBER TOP RWD	TATA spare parts
502232307102	BRACKET SHOCK ABSORBER TOP FWD	TATA spare parts
502232903701	ARB MOUNTING BRACKET ON FRAME(LPK3128)	TATA spare parts
502233000101	ASSY. FRONT AXLE COMP. WITH BRAKES FWD A	TATA spare parts
502233000102	ASSY. FRONT AXLE COMP. WITH BRAKES RWD A	TATA spare parts
502233200101	ASSY.KNUCKLE LH-NON ABS	TATA spare parts
502233200102	ASSY.KNUCKLE RH-NON ABS	TATA spare parts

502233400102	ASSY WHEEL HUB W/O POLE WHEEL	TATA spare parts
50223752000RCK	ASSY CAB KIT PRIMA LX 2830/3130.K BS4 AC	TATA spare parts
502240106301	TYRE REAR 11-20 LUG	TATA spare parts
502240107701	FLAP FRONT 11-20	TATA spare parts
502240109901	TUBE REAR 11-20 LUG	TATA spare parts
502240206301	TYRE 11.20 R NYLON TYPE	TATA spare parts
502241100101	ASSY PROPELLER SHAFT MAIN	TATA spare parts
502241100102	ASSY PROP SHAFT SECOND FOR LX 3128.K	TATA spare parts
502241100103	ASSY PROP SHAFT FRONT FOR 3128.K	TATA spare parts
502241115101	COMPANION FLANGE	TATA spare parts
502241120101	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
502241120102	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
502241120116	PROPELLER SHAFT ASSY-DRIVE BS6	TATA spare parts
502241300101	CENTER BEARING BKT ASSY FOR P/SHAFT MTG	TATA spare parts
502241990101	OUTER SLINGER	TATA spare parts
502241990103	ASSY. CENTER BEARING BS3/4	TATA spare parts
502241990104	COMPANION FLANGE	TATA spare parts
502241990105	WASHER	TATA spare parts
502241990106	BOLT	TATA spare parts
502241990110	CENTRE BEARING KIT	TATA spare parts
502242300131	DRUM BRAKE REAR W/T PLUMMER BLK RH	TATA spare parts
502242300132	DRUM BRAKE REAR W/T PLUMMER BLK LH	TATA spare parts
502242300133	BRAKE ASSY REAR-RH	TATA spare parts
502242300134	BRAKE ASSY REAR-LH	TATA spare parts
50224252000R40	ASSLY CAB PRIMA LX 3130.K BS-IV	TATA spare parts
502243200101	ASSY. CLUSTER MTG. BRACKET	TATA spare parts
502243200102	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
502243208202	BRACKET FOR PIPES CLAMPING	TATA spare parts
502243208203	BRACKET ON FIREWALL	TATA spare parts
502243208205	CLAMP	TATA spare parts
502243700113	BRACKET ASSY APDA MTG	TATA spare parts
502243900115	ASSY. NYLON PIPE TEE-2 TO PARKING AIR TA	TATA spare parts
502243900128	NYLON PIPE BUNCH ASSY	TATA spare parts
502243900136	ASSY.NYLON PIPE FROM DBV-12 TO T-3	TATA spare parts
502243900137	ASSY.NYLON PIPE FROM DBV-11 TO T-7	TATA spare parts
502243900138	ASSY.NYLON PIPE FROM APU TO RR.TANK	TATA spare parts
502243900141	ASSY.NYLON PIPE FROM REAR TANK TO TEE-8	TATA spare parts
502243900143	ASSY.NYLON PIPE FROM T-7 TO T-8	TATA spare parts
502243900146	ASSY.NYLON PIPE FROM APU PORT-22 TO FRT	TATA spare parts
502243900148	ASSY.NYLON PIPE FROM T-3 TO FR.RH RV	TATA spare parts
502243900149	ASSY.NYLON PIPE FROM NRV TO PRV(PARKING)	TATA spare parts
502243900150	ASSY.NYLON PIPE FROM PRV TO PARKING TANK	TATA spare parts
502243900151	FIRST METAL PIPE FROM COMPR	TATA spare parts
502243900153	ASSY.NYLON PIPE FROM COMPR PORT TO APU	TATA spare parts
502243900159	ASSY METAL PIPE	TATA spare parts
502243900162	PIPE ASSY APDA-4 TO CONTROL PORT JOINT	TATA spare parts
502243900171	METAL PIPE ASSY APU TO JOINT	TATA spare parts

502243900175	ASSY. METAL PIPE APU TO JOINT (15 OD)	TATA spare parts
502243900182	ASSY METAL PIPE FROM COMPR PORT-4 TO NYL	TATA spare parts
502243900202	ASSY NYLON PIPE BUNCH COMPLETE	TATA spare parts
502243900212	ASSY. NYLON PIPE HBV TO ACRV PORT-42	TATA spare parts
502243900213	ASSY. NYLON PIPE DBV TO TEE 9	TATA spare parts
502243900215	ASSY. NYLON PIPE FROM TEE-10 TO REAR LH	TATA spare parts
502243900216	ASSY. NYLON PIPE FROM T-7 TO REAR RV LH	TATA spare parts
502243900217	ASSY.NYLON PIPE FROM TEE-12 TO SBA RR	TATA spare parts
502243900218	ASSY. NYLON PIPE FROM RR.MV RH TO TEE-12	TATA spare parts
502243900219	ASSY.NYLON PIPE FROM TEE-12 TO SBA RR	TATA spare parts
502243900220	ASSY.NYLON PIPE FROM TEE-10 TO RV RR.RH	TATA spare parts
502243900221	ASSY. NYLON PIPE FROM T-7 TO REAR RH RV	TATA spare parts
502243900222	ASSY.NYLON PIPE FROM RR. MV LH TO TEE-15	TATA spare parts
502243900223	ASSY.NYLON PIPE FROM T-14 TO SBA RR.FWD	TATA spare parts
502243900224	ASSY. NYLON PIPE TEE 15 TO SBA REAR FWD	TATA spare parts
502243900225	ASSY.NYLON PIPE TEE 13 TO SBA REAR FWD L	TATA spare parts
502243900226	ASSY. NYLON PIPE TEE 15 TO SBA REAR RWD	TATA spare parts
502243900227	ASSY.NYLON PIPE TEE13 TO SBA REAR RWD LH	TATA spare parts
502243900228	ASSY.NYLON PIPE TEE 14 TO REAR RH ACTUA	TATA spare parts
502243900230	ASSY NYLON PIPE HBV PORT-1 TO VOSS ADAPT	TATA spare parts
502243900231	ASSY NYLON PIPE HBV PORT-21 TO VOSS ADAP	TATA spare parts
502243900246	ASSY. NYLON PIPE VOSS ADAPTOR TO TEE 2	TATA spare parts
502243900250	ASSY NYLON PIPE T-2 TO ACRV PORT-1	TATA spare parts
502243900259	ASSY NYLON PIPE SOLENOIDE VALVE TO EXH.V	TATA spare parts
502243900260	ASSY NYLON PIPE FROM T-24 TO SOL.VALVE	TATA spare parts
502243900261	ASSY.NYLON PIPE FROM T23 TO T24	TATA spare parts
502243900310	NYLON PIPE ASSY NYLON PIPE BUNCH	TATA spare parts
502243906801	DOUBLE SOCKET M26X1.5 AND M22X1.5	TATA spare parts
502243907501	GROMMET(25DIA HOLE) ON LONG MEMBER	TATA spare parts
502246600101	ASSY. STEERING GEAR BOX BS3/4 BS6	TATA spare parts
502246800101	PRESSURE LINE HOSE & PIPE ASSY. GEAR BOX	TATA spare parts
502246800102	PRESSURE LINE HOSE AND PIPE ASSY. PUMP E	TATA spare parts
502246800103	AUX. PIPING FROM MAGNETIC VALVE END	TATA spare parts
502246800104	AUX. PIPING AUX TANK END	TATA spare parts
502246800105	SUCTION LINE HOSE & PIPE ASSY	TATA spare parts
502246800106	RETURN LINE ASM-G B END	TATA spare parts
502246800107	RETURN LINE ASM-INTERMEDIATE	TATA spare parts
502246800108	RETURN LINE ASM-TANK END	TATA spare parts
502246800109	PRESSURE LINE ASM-P/CYL	TATA spare parts
502246800110	PRESSURE LINE ASM-P/CYL	TATA spare parts
502246800111	PRESSURE LINE ASM-P/CYL	TATA spare parts
502246800112	PRESSURE LINE ASM-P/CYL	TATA spare parts
502246800113	RETURN LINE ASM - G B END	TATA spare parts
502246800114	RETURN LINE ASSY INTERMEDIATE	TATA spare parts
502246803303	OIL COOLER BRACKET	TATA spare parts
502246803304	OIL COOLER SIDE BRACKET LH	TATA spare parts
502246900102	OIL COOLER	TATA spare parts

502247600101	ASSY FUEL SUCTION LINE FUEL TANK TO W/S	TATA spare parts
502247600102	ASSY FUEL SUCTION LINE W/S TO ENGINE	TATA spare parts
502247600103	ASSY FUEL RETURN LINE ENGINE - FUEL TANK	TATA spare parts
502247600104	SUCTION LINE (WS TO ENG)	TATA spare parts
502247600106	RETURN LINE ASSY ON TANK	TATA spare parts
502254709901	VEHICLE SPEED SENSOR	TATA spare parts
502315400101	ALTERNATOR 24V 150AMP BS3/4	TATA spare parts
502315409901	PULLEY	TATA spare parts
502315409904	D.E. FAN	TATA spare parts
502315409905	ROTOR ASSY	TATA spare parts
502315409906	STATOR ASSY	TATA spare parts
502315409907	S.R.E BRACKET BS6	TATA spare parts
502315409908	THROUGH BOLT	TATA spare parts
502315409909	RECTIFIER ARRNG. BS6	TATA spare parts
502315409910	REGULATOR ASSY	TATA spare parts
502315409911	TERMINAL MOULDING	TATA spare parts
502315409913	REAR COVER	TATA spare parts
502315409914	D.E BRACKET ASSY	TATA spare parts
502315409915	BEARING COLLAR	TATA spare parts
502315409917	M6 NUT BS6	TATA spare parts
502316104911	ECU HYBRID	TATA spare parts
502316172001	ECU ABS BS6-PH2	TATA spare parts
502324100107	BRACKET ASSY FRAME SIDE RH	TATA spare parts
502324100108	BRACKET ASSY FRAME SIDE LH	TATA spare parts
502324100109	BRACKET ASSY ENGINE MTG FRONT-RH	TATA spare parts
502324100110	BRACKET ASSY ENGINE MTG FRONT-LH	TATA spare parts
502324100115	STIFFENER ENGINE MTG	TATA spare parts
502324100116	STIFFENER ENGINE MTG	TATA spare parts
502324100117	BRACKET ASSY,FRAME SIDE,LH	TATA spare parts
502324100118	BRACKET ASSY,FRAME SIDE,RH	TATA spare parts
502324100135	BRACKET ASSY FRAME SIDE LH	TATA spare parts
502324100136	BRACKET ASSY FRAME SIDE RH	TATA spare parts
502324100201	FRONT RUBBER MOUNT ASM	TATA spare parts
502324106902	SLEEVE EV	TATA spare parts
502324200104	REAR ENGINE RUBBER MOUNT	TATA spare parts
502324200128	BRACKET ASSY ENGINE MTG REAR	TATA spare parts
502324200130	SUPPORT BRACKET ASSY ENGINE MTG REAR	TATA spare parts
502330100103	ASSY FLOOR MTD ACCELERATOR PEDAL UNIT	TATA spare parts
502330100104	ACCELERATOR PEDAL MODULE EV	TATA spare parts
502330100106	BRACKET ASSY ACCELERATOR PEDAL MTG	TATA spare parts
502331000125	FRAME ASSY	TATA spare parts
502331000132	FRAME ASSY FRONT COMPLETE	TATA spare parts
502331000138	FRAME ASSY REAR	TATA spare parts
502331000147	FRAME ASSY	TATA spare parts
502331000150	BATTERY SUPPORT ASSY	TATA spare parts
502331000151	FRAME ASSY REAR MODULE	TATA spare parts
502331000153	FRAME ASSY WITH FITMENT	TATA spare parts

502331000159	FRAME ASSY WITH FRONT STRUCTURE	TATA spare parts
502331000162	FRAME ASSY REAR MODULE	TATA spare parts
502331000166	BATTERY SUPPORT ASSY	TATA spare parts
502331100119	GUSSET ASSY	TATA spare parts
502331100153	SUPPORT ASSY FRONT	TATA spare parts
502331107113	PLATE REINFORCEMENT LONG MEMBER	TATA spare parts
502331200114	SUPPORT ASSY BS6	TATA spare parts
502331200139	CROSS MEMBER ASSY FRONT	TATA spare parts
502331200140	TUBE ASSY	TATA spare parts
502331200147	CROSS MEMBER ASSY	TATA spare parts
502331200184	CROSS MEMBER ASSY REAR	TATA spare parts
502331200199	CROSS MEMBER ASSY	TATA spare parts
502331200208	CROSS MEMBER ASSY	TATA spare parts
502331200209	OUTRIGGER ASSY	TATA spare parts
502331200210	OUTRIGGER ASSY	TATA spare parts
502331200211	OUTRIGGER ASSY	TATA spare parts
502331200212	OUTRIGGER ASSY	TATA spare parts
502331200215	CROSS MEMBER ASSY	TATA spare parts
502331200220	CROSS MEMBER ASSY,RH	TATA spare parts
502331200221	CROSS MEMBER ASSY RH	TATA spare parts
502331200231	SUPPORT BRACKET ASSY	TATA spare parts
502331200232	SUPPORT BRACKET ASSY	TATA spare parts
502331200250	SUPPORT ASSY C-CHANNEL	TATA spare parts
502331200252	SUPPORT ASSY C-CHANNEL LH	TATA spare parts
502331200278	OUTRIGGER ASSY	TATA spare parts
502331200279	OUTRIGGER ASSY	TATA spare parts
502331200289	BRACKET ASSY AIR BELLOW MTG FRONT -RH	TATA spare parts
502331200290	BRACKET ASSY AIR BELLOW MTG FRONT -LH	TATA spare parts
502331200291	OUTRIGGER ASSY	TATA spare parts
502331200294	OUTRIGGER ASSY	TATA spare parts
502331200299	OUTRIGGER ASSY	TATA spare parts
502331206803	SQUARE TUBE	TATA spare parts
502331206944	CROSS TUBE SUPPORT	TATA spare parts
502331207114	SUPPORT MEMBER RH	TATA spare parts
502331207154	TUBE SUPPORT	TATA spare parts
502331207194	TUBE SUPPORT	TATA spare parts
502331207218	FLITCH FRONT-RH	TATA spare parts
502331207219	FLITCH FRONT-LH	TATA spare parts
502331207241	BRACKET	TATA spare parts
502331208233	REINFORCEMENT RH	TATA spare parts
502331208241	REINFORCEMENT LH	TATA spare parts
502331208258	SUPPORT BOTTOM	TATA spare parts
502331210127	END CROSS MEMBER ASSY	TATA spare parts
502331210128	CROSS MEMBER ASSY	TATA spare parts
502331210130	CROSS MEMBER ASSY REAR	TATA spare parts
502331217101	SUPPORT BRACKET - OUTER (FRONT MODULE)	TATA spare parts
502331217103	BRACKET	TATA spare parts

502331217115	REINFORCEMENT FRONT-RH	TATA spare parts
502331217116	REINFORCEMENT FRONT-LH	TATA spare parts
502331217142	SUPPORT RH	TATA spare parts
502331217143	SUPPORT LH	TATA spare parts
502331300110	SUPPORT BRACKET ASSY CROSS MEMBER	TATA spare parts
502331300128	SUPPORT ASSY BS6	TATA spare parts
502331300131	END CROSS MEMBER ASSY	TATA spare parts
502331300133	L-BRACKET ASSY	TATA spare parts
502331307154	V-ROD MTG BRKT LH(FRONT MODULE)	TATA spare parts
502331307156	V-ROD MTG BKT RH	TATA spare parts
502331307158	SUPPORT TUBE	TATA spare parts
502331307180	BRACKET REAR TOWING HOOK	TATA spare parts
502331307196	TUBE SUPPORT	TATA spare parts
502331320101	BRACKET AIR BELLOW MTG FRONT-RH	TATA spare parts
502331320102	BRACKET AIR BELLOW MTG FRONT-LH	TATA spare parts
502331320103	SUSPENSION SUPPORT ASSY WHEEL ARC RH	TATA spare parts
502331320104	SUSPENSION SUPPORT ASSY WHEEL ARC LH	TATA spare parts
502331320105	WHEEL ARCH ASSY FRONT-RH	TATA spare parts
502331320106	WHEEL ARCH ASSY FRONT-LH	TATA spare parts
502331400120	ASSY.SUPPORT UPR.BKT.-FOR CRADLE ASSY.	TATA spare parts
502331400122	ASSY.CRADLE COMP-FOR TRACTION MOTOR MTG	TATA spare parts
502331400123	BRACKET ASSY SUPPORT	TATA spare parts
502331400127	CROSS MEMBER ASSY WITH TOW HOOK FRONT	TATA spare parts
502331407163	L-BRACKET	TATA spare parts
502331407164	L-BRACKET	TATA spare parts
502331408602	SPACER (FOR CRADLE ASSY.)	TATA spare parts
502331460101	BASE PLATE	TATA spare parts
502331468201	BRACKET GUARD MTG	TATA spare parts
502331468202	BASE PLATE BRACKET	TATA spare parts
502331493302	BRACKET ENGINE ASSY MTG RH	TATA spare parts
502331540111	BATTERY CARRIER & PLATFORM ASSY	TATA spare parts
502331540113	BATTERY CARRIER - PLATFORM ASSY	TATA spare parts
502331700138	RUBBER ISOLATOR ASM	TATA spare parts
502331700142	ASSY REAR OUTRIGGER LH	TATA spare parts
502331700143	OUTRIGGER ASSY REAR-RH	TATA spare parts
502331700146	SUSPENSION SUPPORT ASSY WHEEL ARC RH	TATA spare parts
502331700147	SUSPENSION SUPPORT ASSY WHEEL ARC LH	TATA spare parts
502331700148	BRACKET ASSY RH	TATA spare parts
502331700157	BRACKET ASSY BODY MTG RH	TATA spare parts
502331700158	BRACKET ASSY BODY MTG LH	TATA spare parts
502331700160	BRACKET ASSY LH	TATA spare parts
502331700161	BRACKET ASSY RH	TATA spare parts
502331700169	BRACKET ASSY RH	TATA spare parts
502331700179	TUBE ASSY LH	TATA spare parts
502331700180	SUPPORT ASSY	TATA spare parts
502331700182	OUTRIGGER ASSY	TATA spare parts
502331700183	OUTRIGGER ASSY	TATA spare parts

502331700185	BRACKET ASSY RH	TATA spare parts
502331700186	BRACKET ASSY LH	TATA spare parts
502331700187	L-BRACKET ASSY	TATA spare parts
502331700188	BRACKET ASSY	TATA spare parts
502331700189	OUTRIGGER ASSY	TATA spare parts
502331700190	CROSS MEMBER ASSY BUMPER	TATA spare parts
502331700198	OUTRIGGER ASSY	TATA spare parts
502331700199	TUBE ASSY RH	TATA spare parts
502331703309	BRACKET SOLENOID VALVE MTG	TATA spare parts
502331705101	SOLID BKT	TATA spare parts
502331706971	RUBBER ISOLATOR- TUBE	TATA spare parts
502331707152	C-BRACKET SUPPORT	TATA spare parts
502331708233	C-CHANNEL RH	TATA spare parts
502331710118	OUTRIGGER ASSY FRONT WHEEL ARC RH	TATA spare parts
502331710119	OUTRIGGER ASSY FRONT WHEEL ARC LH	TATA spare parts
502331710120	OUTRIGGER ASSY REAR-RH	TATA spare parts
502331710121	OUTRIGGER ASSY REAR-LH	TATA spare parts
502331710122	OUTRIGGER ASSY	TATA spare parts
502331710123	OUTRIGGER ASSY REAR	TATA spare parts
502331710126	OUTRIGGER ASSY REAR	TATA spare parts
502331710128	OUTRIGGER ASSY	TATA spare parts
502331710129	OUTRIGGER ASSY	TATA spare parts
502331710130	OUTRIGGER ASSY	TATA spare parts
502331710131	OUTRIGGER ASSY	TATA spare parts
502331710132	OUTRIGGER ASSY	TATA spare parts
502331710133	OUTRIGGER ASSY REAR-RH	TATA spare parts
502331710140	CROSS MEMBER ASSY BATTERY MTG	TATA spare parts
502331710141	REINFORCEMENT ASSY LH	TATA spare parts
502331710142	REINFORCEMENT ASSY RH	TATA spare parts
502331710145	OUTRIGGER ASSY	TATA spare parts
502331718235	C-CHANNEL	TATA spare parts
502331718250	SHIM	TATA spare parts
502331718251	SHIM	TATA spare parts
502331718252	SHIM	TATA spare parts
502331726902	SQUARE TUBE	TATA spare parts
502331726906	SQUARE TUBE	TATA spare parts
502331726907	C-CHANNEL	TATA spare parts
502331726908	SQUARE TUBE	TATA spare parts
502332100109	BRACKET ASSY ANTI ROLL BAR MTG FRONT	TATA spare parts
502332103201	HEX FL BOLT M18X1.5X65-10.9	TATA spare parts
502332103202	HUCK SPIN BOLT MBT-DT12-70	TATA spare parts
502332103203	HUCK SPIN BOLT M12-75	TATA spare parts
502332103301	BRACKET V-ROD MTG LH	TATA spare parts
502332103302	BRACKET V-ROD MTG RH	TATA spare parts
502332103503	ARB STOPPER BOTTOM	TATA spare parts
502332106501	HUCK SPIN COLLAR MBTC-R12	TATA spare parts
502332107110	BASE PLATE	TATA spare parts



502332200101	ECAS SYSTEM-WABCO (WITH CAN)	TATA spare parts
502332200113	ASSY. HEIGHT SENSOR LINK FRONT	TATA spare parts
502332200114	ASSY. HIGHT SENSOR LINK REAR	TATA spare parts
502332200121	LEVER ASSY (LEVELING VALVE)	TATA spare parts
502332204903	SOLENOID VALVE FRONT	TATA spare parts
502332204904	PRESSURE SWITCH	TATA spare parts
502332204906	HEIGHT SENSOR	TATA spare parts
502332206003	CONNECTING ROD FRONT	TATA spare parts
502332206004	CONNECTING ROD REAR	TATA spare parts
502332206008	CONNECTING ROD FRONT	TATA spare parts
502332206801	ELBOW CONNECTOR FRONT (M14X1.5 TE - M10X	TATA spare parts
502332206803	CON.ACOD. TRAS. (M14X1.5 TE - M10X1 SE)	TATA spare parts
502332207103	HEIGHT SENSOR LINK FRONT	TATA spare parts
502332207111	CONNECTING ROD BKT. ON AXLE LH	TATA spare parts
502332207112	CONNECTING ROD BKT. ON AXLE RH	TATA spare parts
502332207114	LEVER LEVELLING VALVE	TATA spare parts
502332207119	BRACKET HEIGHT SENSOR FRONT	TATA spare parts
502332209002	CHARGING VALVE	TATA spare parts
502332209201	WASHER	TATA spare parts
502332209202	WASHER	TATA spare parts
502332300102	ASSY. SHOCK ABSORBER FRONT BS3/4	TATA spare parts
502332300103	BRACKET ASSY FRONT SHOCK ABSORBER	TATA spare parts
502332400107	BRACKET ASSY SHOCK ABSORBER MTG.	TATA spare parts
502332400113	STRUCTURE ASSY REAR	TATA spare parts
502332400117	JOINT	TATA spare parts
502332400119	REPAIR KIT	TATA spare parts
502332400120	REPAIR KIT	TATA spare parts
502332400134	TRAILING LINK	TATA spare parts
502332400135	TRAILING LINK	TATA spare parts
502332400136	PNEUMATIC SPRING	TATA spare parts
502332400138	JOINT	TATA spare parts
502332400141	CROSS MEMBER ASSY REAR AIR SPRING BS6	TATA spare parts
502332400144	CROSS MEMBER ASSY FRONT AIR SPRING BS6	TATA spare parts
502332400147	BRACKET ASSY REAR AIR SPRING LH BS6	TATA spare parts
502332400148	BRACKET ASSY REAR AIR SPRING RH BS6	TATA spare parts
502332400150	RADIUS ROD ASSY BS6	TATA spare parts
502332400153	PARALLEL LINK & AIR SPRING BKT ASSY LH B	TATA spare parts
502332400154	PARALLEL LINK & AIR SPRING BKT ASSY RH B	TATA spare parts
502332400156	KIT-REAR SUSPENSION ASSY	TATA spare parts
502332403201	HEX. FL. BOLT M18X1.5X70 - 10.9	TATA spare parts
502332403202	PERNO HEXAGONAL M18X1.5X225	TATA spare parts
502332403203	PERNO HEXAGONAL M16X1.5X165	TATA spare parts
502332403206	HEXAGON BOLT	TATA spare parts
502332403207	HEXAGON BOLT	TATA spare parts
502332403208	HEXAGON BOLT	TATA spare parts
502332403303	SPRING CARRIER	TATA spare parts
502332403304	SPRING CARRIER	TATA spare parts

502332403701	BRACKET V_ROD MTG.	TATA spare parts
502332404202	CLAMP	TATA spare parts
502332404901	SOLENOID VALVE REAR	TATA spare parts
502332407163	HEIGHT SENSOR LINK REAR	TATA spare parts
502332408301	SHIM - 1 THK.	TATA spare parts
502332408302	SHIM - 2 THK.	TATA spare parts
502332408303	SHIM - 3 THK.	TATA spare parts
502332408701	AIR SPRING BELLOWS	TATA spare parts
502332409201	WASHER	TATA spare parts
502332417122	BRACKET	TATA spare parts
502332417129	BRACKET	TATA spare parts
502332600103	SHOCK ABSORBER	TATA spare parts
502332800103	ARB ASSY BALL JOINT	TATA spare parts
502332800104	ASSY RUBBER BUSH ARB (DIA-38)	TATA spare parts
502332800106	ANTI ROLL BAR ASSY	TATA spare parts
502332800107	CONNECTING LINK ASSY REAR	TATA spare parts
502332803301	ARB CLAMP BRACKET (DIA 38)	TATA spare parts
502332803501	FRONT ARB MTG. BKT. ON FRAME	TATA spare parts
502332803502	ARB STOPPER TOP	TATA spare parts
502332806001	CONNECTING LINK	TATA spare parts
502332807102	CLAMP PLATE FRONT ARB (DIA38)	TATA spare parts
502332807701	RUBBER BUSH FRONT ARB	TATA spare parts
502332807903	ANTI ROLL BAR (DIA 38)	TATA spare parts
502332900101	ASSY BUSH REAR ARB	TATA spare parts
502332900102	ASSY. BALL JOINT LH	TATA spare parts
502332900103	ASSY. BALL JOINT RH	TATA spare parts
502332900109	ASSY. ANTIROLL BAR	TATA spare parts
502332903701	BRACKET ARB MTG. LH	TATA spare parts
502332903702	BRACKET ARB MTG. RH	TATA spare parts
502332907113	CLAMP REAR ANTIROLL BAR	TATA spare parts
502332907114	STOPPER CLAMP(REAR ARB)	TATA spare parts
502332950104	NYLON PIPE BUNCH ASSY EV	TATA spare parts
502332950144	NYLON PIPE BUNCH ASSY AIR SUSPENSION	TATA spare parts
502332950181	NYLON PIPE ASSY T-CONN 1 TO T-CONN 2	TATA spare parts
502332950182	NYLON PIPE ASSY T-CONN 2 TO T-CONN 3	TATA spare parts
502332950183	NYLON PIPE ASSY T-CONN 3 TO T-CONN 4	TATA spare parts
502332950184	NYLON PIPE ASSY T-CONN 4 TO RR MV INLET	TATA spare parts
502332950185	NYLON PIPE ASSY FR MV DEL PORT TO FR RV	TATA spare parts
502332950186	NYLON PIPE ASSY T-CONN 4 TO FRT MV INLET	TATA spare parts
502332950187	NYLON PIPE ASSY T-CONN 2 TO T-CONN 7	TATA spare parts
502332950188	NYLON PIPE ASSY T-CONN 7 TO LV INLET LH	TATA spare parts
502332950189	NYLON PIPE ASSY T-CONN 7 TO LV INLET RH	TATA spare parts
502332950190	NYLON PIPE ASSY RIV DEL PORT TO T-CONN 8	TATA spare parts
502332950191	NYLON PIPE ASSY T-CONN8 TO FR RV RES PORT	TATA spare parts
502332950193	NYLON PIPE ASSY T-CONN8 TO RR RV RES PORT	TATA spare parts
502332950196	NYLON PIPE ASSY RR MV DEL PORT TO RR RV	TATA spare parts
502332950197	PIPE ASSY LVR LH DEL PORT2 TO TEE 6	TATA spare parts

502332950198	NYLON PIPE BUNCH ASSY	TATA spare parts
502333000101	ASSY. FRONT AXLE COMP.	TATA spare parts
502333000102	FRONT AXLE ASSY	TATA spare parts
502333000105	FRONT AXLE ASSY WITH BRAKE-LH ABS	TATA spare parts
502333100131	LUBRICATING NIPPLE	TATA spare parts
502333800101	TIE ROD ASSY BS6	TATA spare parts
502333800103	BALL JOINT ASSY RH BS6	TATA spare parts
502333800104	BALL JOINT ASSY LH BS6	TATA spare parts
502333800105	BALL JOINT ASSY;RH BS6	TATA spare parts
502333800106	BALL JOINT ASSY;LH BS6	TATA spare parts
502341100101	ASSY. PROPELLER SHAFT(LPO1925 RE LF DIES	TATA spare parts
502341110101	UNIT PACK	TATA spare parts
502341110106	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
502341110107	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
502341110108	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
502341110109	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
502341115101	FLANGE YOKE	TATA spare parts
502341120103	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
502341120105	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
502341120106	PROPELLER SHAFT ASSY,DRIVE	TATA spare parts
502341120108	SHORT FORK TUBE& REAR HSG SUB ASSY	TATA spare parts
502341125101	FLANGE YOKE	TATA spare parts
502341300101	BRACKET ASSY CENTER BRG MTG	TATA spare parts
502342990105	PRESSURE PART	TATA spare parts
502342990106	BRAKE CARRIER LH	TATA spare parts
502342990107	BRAKE CARRIER RH	TATA spare parts
502342990108	REPAIR KIT	TATA spare parts
502342990114	ADJUSTING KIT	TATA spare parts
502342990116	ASSEMBLY GREASE	TATA spare parts
502343200105	ASSY PROPORTIONAL REALY VALVE MTG. BKT	TATA spare parts
502343200106	ASSY. AXILE MODULATOR VAVLE MTG. BKT	TATA spare parts
502343200121	BRACKET ASSY AXLE MODULATOR VALVE FRONT	TATA spare parts
502343200122	BRACKET ASSY AXLE MODULATOR VALVE REAR	TATA spare parts
502343200126	BASE SUPPORT WITH AIR COMP.& HYD.PUMP	TATA spare parts
502343200128	AIR TANK ASSY	TATA spare parts
502343200147	AUX DRIVE UNIT ASSY	TATA spare parts
502343200150	AIR TANK ASSY	TATA spare parts
502343200151	BRACKET ASSY MODULATOR VALVE	TATA spare parts
502343200156	AIR TANK ASSY WITH BKT	TATA spare parts
502343200159	BRACKET ASSY	TATA spare parts
502343200160	CHOKE INDICATOR ASSY EV	TATA spare parts
502343200173	BRACKET ASSY AIR OIL SEPARATOR MTG	TATA spare parts
502343200176	SUPPORT ASSY -	TATA spare parts
502343200180	BRACKET ASSY AIR TANK MTG	TATA spare parts
502343200181	BRACKET ASSY RELAY VALVE MOUNTING	TATA spare parts
502343203304	SPACER EV	TATA spare parts
502343203338	HEX SCREW REDUCER	TATA spare parts

502343203339	L BRACKET	TATA spare parts
502343206912	APU MTG BKT FOR LPO1925 CNG	TATA spare parts
502343208246	BRACKET (AIR TANK MTG.)	TATA spare parts
502343208247	BRACKET COMPRESSOR BELT TENSIONING	TATA spare parts
502343208250	BRACKET	TATA spare parts
502343208251	BRACKET PRESSURE SWITCH	TATA spare parts
502343208285	BRACKET FLICK VALVE	TATA spare parts
502343209901	WIRE FOR ACCESSING DRAIN PLUG	TATA spare parts
502343406801	PRESSURE SWITCH BLOCK	TATA spare parts
502343700107	ASSY BRAKE AGGREGATES (KIT PART NUMBER)	TATA spare parts
502343700117	NONRETURNVALVE	TATA spare parts
502343700117C	NON RETURN VALVECORE	TATA spare parts
502343700131	FOOT CONTROL VALVE	TATA spare parts
502343700132	MODULATOR VALVE ABS	TATA spare parts
502343700133	MODULATOR VALVE ABS	TATA spare parts
502343700134	AIR COMPRESSOR	TATA spare parts
502343700134C	AIR COMPRESSORCORE	TATA spare parts
502343700135	V BELT 3VX433- Air Compressor	TATA spare parts
502343700138	BRAKE SIGNAL TRANSMITTER	TATA spare parts
502343700191	BRACKET ASSY	TATA spare parts
502343700192	BRACKET ASSY	TATA spare parts
502343700199	AIR COMPRESSOR	TATA spare parts
502343700202	COVER ASSY	TATA spare parts
502343700205	ANTI COMPOUNDING RELAY VALVE	TATA spare parts
502343700211	BRACKET ASSY ACRV AND MV MOUNTING	TATA spare parts
502343700213	BRACKET ASSY APU MTG	TATA spare parts
502343700217	CHANNEL ASSY AUXDRIVE MTG.	TATA spare parts
502343700243	AIR DRYER ASSY WITH CONTROL PORT	TATA spare parts
502343700247	BRACKET ASSY	TATA spare parts
502343700257	SYSTEM PROTCTION VALVE	TATA spare parts
502343700259	BRACKET ASSY AXLE MODULATOR VALVE FRONT	TATA spare parts
502343700289	BRACKET ASSY AXLE MODULATOR VALVE REAR	TATA spare parts
502343703377	BRACKET AIR TANK MTG	TATA spare parts
502343708228	MODULATOR VALVE MTG. BRACKET	TATA spare parts
502343710107	BRACKET ASSY AXLE MODULATOR VALVE REAR	TATA spare parts
502343710110	AUX DRIVE UNIT ASSY	TATA spare parts
502343710115	BRACKET ASSY APU MTG	TATA spare parts
502343710119	BRACKET ASSY	TATA spare parts
502343710120	BRACKET ASSY	TATA spare parts
502343710203	BRACKET ASSY ABS MODULATOR MTG RH	TATA spare parts
502343710217	BRACKET ASSY PURGE TANK MTG	TATA spare parts
502343900280	ASSY. NYLON PIPE BUNCH	TATA spare parts
502343900302	ASSY METAL PIPE	TATA spare parts
502343900360	ASSY METAL PIPE	TATA spare parts
502343905807	AIR INTAKE HOSE AIR FILTER SIDE	TATA spare parts
502343906802	VOSS ADAPTOR NG12 X M16 X 1.5	TATA spare parts
502343906803	TEE-SOCKET (M18X1.5XM16X1.5XM12X1.5)	TATA spare parts

502343906805	COUPLING BODY - AIR COMPRESSOR OUTLET	TATA spare parts
502343906806	ADAPTER COMPRESSOR	TATA spare parts
502343906808	COUPLING BODY FOR AIR COMPRESSOR	TATA spare parts
502343906810	ADAPTER	TATA spare parts
502343908253	BRACKET	TATA spare parts
502343910184	METAL PIPE ASSY 5TH TO APU	TATA spare parts
502343910185	METAL PIPE ASSY 4TH	TATA spare parts
502343910186	METAL PIPE ASSY 3RD	TATA spare parts
502343910191	PIPE ASSY	TATA spare parts
502343910192	PIPE ASSY	TATA spare parts
502343910194	PIPE ASSY	TATA spare parts
502343910195	PIPE ASSY	TATA spare parts
502343910196	PIPE ASSY	TATA spare parts
502343910291	NYLON PIPE BUNCH ASSY	TATA spare parts
502343910298	NYLON PIPE BUNCH ASSY	TATA spare parts
502343910307	PIPE ASSY	TATA spare parts
502343910309	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
502343910310	PIPE ASSY NYLON BUNCH COMPLETE	TATA spare parts
502343910311	PIPE ASSY ADAPTER JOINT TO ADAPTER JOINT	TATA spare parts
502343910312	PIPE ASSY ADAPTER JOINT TO ADAPTER JOINT	TATA spare parts
502343910313	PIPE ASSY 15L RST ADAPTER JOINT TO ADAPT	TATA spare parts
502343910314	PIPE ASSY ADAPTER JOINT TO ADAPTER JOINT	TATA spare parts
502343910315	PIPE ASSY ADAPTER JOINT(DTV-21) TO ADAPT	TATA spare parts
502343910316	PIPE ASSY ADAPTER JOINT TO ADAPTER JOINT	TATA spare parts
502343910317	PIPE ASSY ADAPTER JOINT TO ADAPTER JOINT	TATA spare parts
502343910318	PIPE ASSY TEE(PARKING ACRV) TO ADAPTER J	TATA spare parts
502343910319	PIPE ASSY ADAPTER JOINT TO TEE(DCV 1)	TATA spare parts
502343910320	PIPE ASSY 15L RST TO ADAPTER JOINT	TATA spare parts
502343910321	PIPE ASSY ADAPTER JOINT TO R12 RELAY VAL	TATA spare parts
502343910322	PIPE ASSY ADAPTER JOINT(DTV-21) TO TEE	TATA spare parts
502343910323	PIPE ASSY TEE(PRV) TO ADAPTER JOINT	TATA spare parts
502343910324	PIPE ASSY ADAPTER JOINT TO ACRV(SERVICE)	TATA spare parts
502343910325	PIPE ASSY 15L RST TO R12 RELAY VALVE	TATA spare parts
502343910326	PIPE ASSY TEE TO DCV	TATA spare parts
502343910327	PIPE ASSY TEE TO PRESSURE SENSOR	TATA spare parts
502343910328	PIPE ASSY TEE TO PARKING ACRV	TATA spare parts
502343910329	PIPE ASSY TEE TO LEVER CONTROL VALVE	TATA spare parts
502343910330	PIPE ASSY TEE 11 TO REAR RV 1	TATA spare parts
502343910331	PIPE ASSY AIR TANK 15LIT TO FIL VAL 1	TATA spare parts
502343910332	PIPE ASSY TEE TO AUXILARY AIR TANK	TATA spare parts
502343910333	PIPE ASSY PRV 11 TO TEE	TATA spare parts
502343910334	PIPE ASSY SUSPENSION AIR TANK TO NRV	TATA spare parts
502343910335	PIPE ASSY EV	TATA spare parts
502343910336	PIPE ASSY EV	TATA spare parts
502343910370	METAL PIPE ASSY EV	TATA spare parts
502343910371	RUBBER HOSE	TATA spare parts
502343910372	RUBBER HOSE EXHAUST	TATA spare parts

502343915805	AIR INTAKE HOSE COMPRESSOR SIDE EV	TATA spare parts
502343915806	AIR INTAKE HOSE AIR FILTER SIDE EV	TATA spare parts
502343920101	PIPE BUNCH ASSY FOR LPO1625 RHD	TATA spare parts
502343920105	PIPE ASSY MOD VAL RH TO BRAKE CHAMBER RH	TATA spare parts
502343920108	PIPE ASSY PROP REL VAL TO MOD VAL LH	TATA spare parts
502343920111	PIPE ASSY PROP REL VAL TO MOD VAL RH	TATA spare parts
502343920121	PIPE ASSY MOD. VAL. LH TO BC LH	TATA spare parts
502343920136	PIPE ASSY AIR TANK SUSP. TO AIR TANK SUS	TATA spare parts
502343920141	PIPE ASSY SOLENOIDE VALVE TO EXH. BREAKE	TATA spare parts
502343920190	PIPE ASSY	TATA spare parts
502343920192	PIPE ASSY	TATA spare parts
502343920203	PIPE ASSY 1ST METAL PIPE (18OD)	TATA spare parts
502343920204	PIPE ASSY 2ND METAL PIPE (18OD)	TATA spare parts
502343920205	PIPE ASSY 3RD METAL PIPE (18OD)	TATA spare parts
502343920206	PIPE ASSY 4TH METAL PIPE(18 OD)	TATA spare parts
502343920207	PIPE ASSY 5TH METAL PIPE (18 OD)	TATA spare parts
502343920208	PIPE ASSY 6TH METAL PIPE (18 OD)	TATA spare parts
502343920209	PIPE ASSY 7TH METAL PIPE (18 OD)	TATA spare parts
502343920210	PIPE ASSY 8TH METAL PIPE (18 OD)	TATA spare parts
502343920211	PIPE ASSY 9TH METAL PIPE (18 OD)	TATA spare parts
502343920212	PIPE ASSY 10TH METAL PIPE (18 OD)	TATA spare parts
502343920213	PIPE ASSY 11TH METAL PIPE (18 OD)	TATA spare parts
502343920216	PIPE ASSY TEE 8 TO PRV 11	TATA spare parts
502343920217	PIPE ASSY R12 RELAY VALVE+ MV TO SBA 11R	TATA spare parts
502343920218	PIPE ASSY TEE TO NRV	TATA spare parts
502343920219	PIPE ASSY TEE TO ACRV(BALANCE)	TATA spare parts
502343920220	PIPE ASSY TEE TO DCV 2	TATA spare parts
502343920221	PIPE ASSY TEE TO DCV 1	TATA spare parts
502343920222	PIPE ASSY TEE TO SOLENOID VALVE ASSY 2	TATA spare parts
502343920223	PIPE ASSY TEE-12 TO DOOR ACTUATOR	TATA spare parts
502343920224	PIPE ASSY TEE TO TEE (SEAT)	TATA spare parts
502343920225	PIPE ASSY AIR TANK 15LIT TO AIR TANK 15L	TATA spare parts
502343920226	PIPE ASSY TEE TO PRV 11	TATA spare parts
502343920227	PIPE ASSY NRV TO AIR TANK 15LIT	TATA spare parts
502343920228	PIPE ASSY R12 RELAY VALVE+ MV TO SBA 11	TATA spare parts
502343920229	PIPE ASSY ACRV TO SBA 12 LH	TATA spare parts
502343920230	PIPE ASSY PRV 21 TO NRV	TATA spare parts
502343920231	PIPE ASSY SPV-21 TO TEE	TATA spare parts
502343920232	PIPE ASSY TEE TO 30L RST	TATA spare parts
502343920233	PIPE ASSY TEE TO ADAPTER JOINT	TATA spare parts
502343920234	PIPE ASSY 30L RST TO TEE	TATA spare parts
502343920235	PIPE ASSY TEE TO DTV-11	TATA spare parts
502343920236	PIPE ASSY TEE TO ADAPTER JOINT	TATA spare parts
502343920237	PIPE ASSY SPV-22 TO FST	TATA spare parts
502343920238	PIPE ASSY FST TO TEE	TATA spare parts
502343920239	PIPE ASSY PRV 21 TO AUX AIR TANK	TATA spare parts
502343920240	PIPE ASSY SUS AIR TANK TO AIR BELLOWS	TATA spare parts

502343920241	PIPE ASSY ACRV TO SBA 12 RH	TATA spare parts
502343920242	PIPE ASSY TEE TO SOLENOID VALVE ASSY 1	TATA spare parts
502343920243	PIPE ASSY ADAPTER JOINT TO TEE-12	TATA spare parts
502343920244	PIPE ASSY TEE-12 TO SEAT	TATA spare parts
502343920248	PIPE ASSY	TATA spare parts
502343920249	PIPE ASSY	TATA spare parts
502343920250	PIPE ASSY TEE TO DTV-12	TATA spare parts
502343920251	PIPE ASSY TEE TO FRONT ACRV	TATA spare parts
502343920252	PIPE ASSY FRONT ACRV TO FRONT MOD VALVE	TATA spare parts
502343920253	PIPE ASSY FRONT MOD VALVE TO TEE	TATA spare parts
502343920254	PIPE ASSY TEE TO BC RH	TATA spare parts
502343920255	PIPE ASSY TEE TO BC LH	TATA spare parts
502343920256	PIPE ASSY DTV-22 TO FRONT ACRV-42	TATA spare parts
502343920257	PIPE ASSY SPV-23 TO TEE	TATA spare parts
502343920258	PIPE ASSY TEE TO HBV-1	TATA spare parts
502343920259	PIPE ASSY TEE TO ADAPTER JOINT	TATA spare parts
502343920260	PIPE ASSY HBV-2 TO TEE	TATA spare parts
502343920261	PIPE ASSY TEE TO ADAPTER JOINT	TATA spare parts
502343920262	PIPE ASSY DTV-21 TO ADAPTER JOINT	TATA spare parts
502343920263	PIPE ASSY SPV-24 TO ADAPTER JOINT	TATA spare parts
502343920264	PIPE ASSY ADAPTER JOINT TO PRV-11	TATA spare parts
502343920265	PIPE ASSY PRV-21 TO FRONT ACRV-41	TATA spare parts
502343920266	PIPE ASSY ADAPTER JOINT TO SEAT JOINT	TATA spare parts
502343920314	METAL PIPE ASSY EV	TATA spare parts
502343920315	METAL PIPE ASSY EV	TATA spare parts
502343930181	PIPE ASSY AIR DRYER TO PURGE TANK	TATA spare parts
502343930182	PIPE ASSY AIR DRYER TO SPV PORT 1	TATA spare parts
502343940185	METAL PIPE ASSY	TATA spare parts
502343940186	METAL PIPE ASSY	TATA spare parts
502343940197	METAL PIPE ASSY	TATA spare parts
502343940198	METAL PIPE ASSY	TATA spare parts
502343960124	METAL PIPE ASSY EV	TATA spare parts
502343960125	METAL PIPE ASSY APU TO OIL SEPARATOR EV	TATA spare parts
502343990104	CLUTCH COMPRESSOR	TATA spare parts
502343990104C	CLUTCH COMPRESSORCORE	TATA spare parts
502343990106	METAL PIPE ASSY (KIT ASSY)	TATA spare parts
502343990139	METAL PIPE ASSY - RETRO KIT	TATA spare parts
502343993301	FILTER ELEMENT	TATA spare parts
502345408202	L-BRACKET	TATA spare parts
502345903301	L-BRACKET	TATA spare parts
502346100103	STEERING GEAR BOX - LPO1925 LF HYBRID	TATA spare parts
502346100105	STEERING COLUMN HYBRID BUS	TATA spare parts
502346100141	BRACKETASSY	TATA spare parts
502346100142	BRACKETASSY	TATA spare parts
502346100143	BRACKETASSYSTGCOLUMNMTG EV	TATA spare parts
502346106301	RUBBER BELLOW	TATA spare parts
502346107101	BASE PLATE	TATA spare parts

502346109901	PIPE FOR PNEUMATIC CYLINDER	TATA spare parts
502346109902	PIPE FOR PNEUMATIC CYLINDER	TATA spare parts
502346109903	STUD	TATA spare parts
502346109904	BEARING BUSH	TATA spare parts
502346109906	RUBBER BEEDING	TATA spare parts
502346109907	SPECIAL NUT	TATA spare parts
502346109910	SPECIAL NUT	TATA spare parts
502346200101	I-SHAFT ASSEMBLY	TATA spare parts
502346200102	STEERING SPINDLE BEVEL GB TO STEERING GB	TATA spare parts
502346200103	I-SHAFT ASSEMBLY LF HYBRID LPO1925	TATA spare parts
502346200106	SPINDLE	TATA spare parts
502346300103	DRAG LINK ASSY	TATA spare parts
502346300104	DRAG LINK ASSY	TATA spare parts
502346304102	DROP ARM	TATA spare parts
502346304104	PITMAN ARM	TATA spare parts
502346305101	STEERING ARM	TATA spare parts
502346305105	PITMAN ARM	TATA spare parts
502346600103	AUXILIARY DRIVE UNIT	TATA spare parts
502346600106	HOUSINGASSY	TATA spare parts
502346600107	SECTOR SHAFT ASSY BS6	TATA spare parts
502346600108	PNEUMATIC CYLINDER	TATA spare parts
502346600112	STEERING COLUMN MTG. BKT. ASSY	TATA spare parts
502346600113	GUIDE PLATE ASSY.	TATA spare parts
502346600114	GUIDE PLATE ASSY	TATA spare parts
502346600125	VANE PUMP ASSY	TATA spare parts
502346600126	STEERING GEAR BOX ASSY	TATA spare parts
502346600128	HOUSING COVER ASSY	TATA spare parts
502346600129	PISTON ASSY BS6	TATA spare parts
502346600134	POWER STEERING PUMP ASSY	TATA spare parts
502346600138	BRACKET ASSY RESERVOIR MTG	TATA spare parts
502346600140	STEERING GEAR BOX ASSY BS6	TATA spare parts
502346600143	BRACKET ASSY	TATA spare parts
502346600144	STEERING GEAR BOX ASSY	TATA spare parts
502346600149	POWER STEERING PUMP ASSY EV	TATA spare parts
502346600151	BRACKET PUMP MTG	TATA spare parts
502346600152	BEVEL GEAR BOX ASSY	TATA spare parts
502346603309	DASHBOARD MTG BRKT	TATA spare parts
502346603310	STEERING COLUMN MTG BRKT	TATA spare parts
502346603311	SUPPORT BRKT STEERING	TATA spare parts
502346604601	COUPLING	TATA spare parts
502346609202	SPACER 5THK	TATA spare parts
502346609902	HOUSING ASSY	TATA spare parts
502346700103	BEVEL GB MTG BRKT	TATA spare parts
502346700104	ASSY. RUBBER PAD	TATA spare parts
502346700107	STEERING COVER MTG. BKT	TATA spare parts
502346700112	STEERING COVER MTG. BKT	TATA spare parts
502346700115	BRACKET ASSY STG GEAR BOX MTG	TATA spare parts



502346700119	BRACKET ASSY	TATA spare parts
502346700123	BRACKET ASSY BEVEL GEAR BOX MTG	TATA spare parts
502346700127	BRACKET ASSY BEVEL GEAR BOX MTG	TATA spare parts
502346703310	STEERING OIL RESERVOIR PLASTIC	TATA spare parts
502346703311	OIL RESERVOIR TANK	TATA spare parts
502346703313	FILTER	TATA spare parts
502346703315	COVER PLATE FOR RUBBER BELLOW	TATA spare parts
502346703320	BRACKET	TATA spare parts
502346703321	BRACKET	TATA spare parts
502346703338	BRACKET IDLER ARM MTG	TATA spare parts
502346703339	BRACKET STG GEAR BOX MTG	TATA spare parts
502346703340	BRACKET BS6-PH2	TATA spare parts
502346703348	BRACKET STG GEAR BOX MTG	TATA spare parts
502346703354	BRACKET STG GEAR BOX MTG EV	TATA spare parts
502346800121	PRESSURE LINE	TATA spare parts
502346800122	RETURN LINE	TATA spare parts
502346800123	SUCTION LINE	TATA spare parts
502346800127	TUBE	TATA spare parts
502346800128	TUBE	TATA spare parts
502346800129	PNEUMATIC PIPE	TATA spare parts
502346800131	PIPE	TATA spare parts
502346800132	PNEUMATIC PIPE	TATA spare parts
502346800135	ELBOW ADAPTOR M22X1.5-M18X1.5	TATA spare parts
502346800136	RETURN LINE ASSY	TATA spare parts
502346800139	MALE ADAPTER	TATA spare parts
502346800140	ASSY PNEUMATIC PIPE	TATA spare parts
502346800146	PRESSURE LINE ASSY	TATA spare parts
502346800147	PRESSURE LINE ASSY	TATA spare parts
502346800153	SUCTION LINE ASSY	TATA spare parts
502346800154	PRESSURE LINE ASSY	TATA spare parts
502346800155	RETURN LINE ASSY	TATA spare parts
502346800158	PRESSURE LINE ASSY	TATA spare parts
502346800159	RETURN LINE ASSY	TATA spare parts
502346800160	PRESSURE LINE ASSY	TATA spare parts
502346800161	RETURN LINE ASSY	TATA spare parts
502346800162	PRESSURE LINE ASSY	TATA spare parts
502346800163	RETURN LINE ASSY	TATA spare parts
502346800178	RETURN LINE ASSY	TATA spare parts
502346800179	PRESSURE LINE ASSY	TATA spare parts
502346800180	RETURN LINE ASSY	TATA spare parts
502346800184	RETURN LINE ASSY	TATA spare parts
502346800185	PRESSURE LINE ASSY	TATA spare parts
502346800186	AUXILIARY PIPE	TATA spare parts
502346800187	PRESSURE LINE ASSY	TATA spare parts
502346800189	RETURN LINE ASSY	TATA spare parts
502346800192	SUCTION LINE ASSY	TATA spare parts
502346800193	RETURN LINE ASSY	TATA spare parts

502346800194	SUCTION LINE ASSY	TATA spare parts
502346800195	PRESSURE LINE ASSY	TATA spare parts
502346800196	RETURN LINE ASSY	TATA spare parts
502346800197	RETURN LINE ASSY	TATA spare parts
502346800198	RETURN LINE ASSY	TATA spare parts
502346803307	BRACKET ASSY RESERVOIR MTG	TATA spare parts
502346803308	BRACKET BS6-PH2	TATA spare parts
502346803309	BRACKET	TATA spare parts
502346803310	BRACKET	TATA spare parts
502346803311	BRACKET PIPE CLAMP	TATA spare parts
502346806801	MALE ADAPTER (M22X1.5-3/4IN -16 TPI UNF)	TATA spare parts
502346806803	MALE ADAPTER	TATA spare parts
502346810111	RETURN LINE ASSY	TATA spare parts
502346810112	PRESSURE LINE ASSY	TATA spare parts
502346810114	PRESSURE LINE ASSY	TATA spare parts
502346810123	PRESSURE LINE ASSY	TATA spare parts
502346810124	RETURN LINE ASSY	TATA spare parts
502346810125	PRESSURE LINE ASSY	TATA spare parts
502346810175	PRESSURE LINE ASSY EV	TATA spare parts
502346810176	RETURN LINE ASSY EV	TATA spare parts
502346810180	PRESSURE LINE ASSY EV	TATA spare parts
502346810182	RETURN LINE ASSY EV	TATA spare parts
502346810183	RETURN LINE ASSY EV	TATA spare parts
502346810186	PRESSURE LINE ASSY EV	TATA spare parts
502346810188	SUCTION LINE ASSY EV	TATA spare parts
502346810190	RETURN LINE ASSY EV	TATA spare parts
502346810192	PRESSURE LINE ASSY EV	TATA spare parts
502346810195	RETURN LINE ASSY EV	TATA spare parts
502346810196	PRESSURE LINE ASSY EV	TATA spare parts
502346900102	DRAG LINK ASSY	TATA spare parts
502346900110	DRAG LINK ASSY	TATA spare parts
502346900112	DRAG LINK ASSY	TATA spare parts
502346980101	KIT-POWER STEERING PUMP	TATA spare parts
502346990147	PISTON ASSY	TATA spare parts
502346990148	SECTOR SHAFT ASSY	TATA spare parts
502346990149	KIT-SEAL	TATA spare parts
502347100121	FUEL TANK ASSY WITH TANK UNIT	TATA spare parts
502347500169	STRAP ASSY FUEL TANK MTG	TATA spare parts
502347507704	RUBBER STRAP TOP	TATA spare parts
502347507705	RUBBER STRAP BOTTOM	TATA spare parts
502347507706	RUBBER STRAP BOTTOM	TATA spare parts
502347600114	RECEPTACLE (TN5)	TATA spare parts
502347600116	CNG MANUAL VALVE FOR 16 OD TUBE	TATA spare parts
502347600121	ASSY HP HOSE FROM CYL TO 16MM UNION	TATA spare parts
502347600124	ASSY HP HOSE FROM RECEPTACLE TO TO CYL C	TATA spare parts
502347600125	ASSY HOSE ENG TO HPR (HEATING LINE	TATA spare parts
502347600126	ASSY HOSE HPR TO RAD(HEATING LINE)	TATA spare parts

502347600132	CNG HIGH PRESSURE GAUGE	TATA spare parts
502347600182	FUEL PIPE ASSY SUCTION LINE	TATA spare parts
502347600183	RETURN LINE PIPE ASSY	TATA spare parts
502347600185	FUEL RETURN PIPE ASSY	TATA spare parts
502347600186	FUEL SUCTION PIPE ASSY	TATA spare parts
502347600187	FUEL PIPE ASSY SUCTION LINE	TATA spare parts
502347600188	RETURN FUEL PIPE ASSY	TATA spare parts
502347600189	FUEL SUCTION PIPE ASSY FILTER TO HP PUMP	TATA spare parts
502347600190	FUEL SUCTION PIPE ASSY	TATA spare parts
502347600191	FUEL PIPE ASSY SUCTION LINE	TATA spare parts
502347603340	L BKT BS6	TATA spare parts
502347605801	CNG LP HOSE (HPR TO LPF)	TATA spare parts
502347605802	CNG LP HOSE (LPF TO ENG)	TATA spare parts
502347606814	MALE CONNECTOR 8MM OD X1/4INNPT-SWAGEL	TATA spare parts
502347606815	FEMALE BRANCH TEE 1/4IN NPT X 8MM OD	TATA spare parts
502347606816	FEMALE CONNECTOR 3/8IN NPT & 8MM OD TUBE	TATA spare parts
502347606817	MALE TUBE ADAPTER 8MM ODX1/4IN MALE NPT	TATA spare parts
502347606818	FEMALE CONNECTOR 8MM ODX1/4IN FEMALE NPT	TATA spare parts
502347606819	UNION TEE 16 MM OD TUBE ALL SIDE	TATA spare parts
502347606821	REDUCING UNION 16MM ODX8MM OD	TATA spare parts
502347606823	MALE CONN 3/4IN THRD SAE(O-RING)X8OD TUBE	TATA spare parts
502347606824	UNION 16MM OD TUBE	TATA spare parts
502347606826	REDUCING TEE 16MM ODX16MM OD X 8 MM OD	TATA spare parts
502347606827	COUPLING NUT ON RECEPTACLE	TATA spare parts
502347606828	REDUCER 8MMX 1/4INC	TATA spare parts
502347606830	PORT CONNECTOR	TATA spare parts
502347700105	ASSY HPR WITH CONNECTORS	TATA spare parts
502349000109	ASSY EXHAUST FIRST PIPE WITH FLEX PIPE	TATA spare parts
502349100172	CLAMP ASSY CATCON	TATA spare parts
502349100174	BRACKET ASSY SILENCER MTG	TATA spare parts
502349100175	BRACKET ASSY	TATA spare parts
502349100181	ASSY CATCON 1925 CNG HYB	TATA spare parts
502349100182	ASSY STRAP FOR HEAT SHIELD MTG	TATA spare parts
502349109201	WASHER	TATA spare parts
502349200112	EXHAUST PIPE ASSY WITH BELLOW	TATA spare parts
502349200119	EXHAUST PIPE ASSY WITH BOSS	TATA spare parts
502349200123	EXHAUST PIPE ASSY DPS SENSOR OUTLET	TATA spare parts
502349200124	EXHAUST PIPE ASSY DPS SENSOR INTAKE	TATA spare parts
502349200182	ASSY TAIL PIPE LF CNG HYB	TATA spare parts
502349200183	ASSY HT SHIELD FOR SILENCER	TATA spare parts
502349206920	TUBE	TATA spare parts
502349208203	CLAMP FOR EXH PIPE MTG	TATA spare parts
502349208256	CLAMP FOR SILENCER MTG	TATA spare parts
502349208266	CLAMP FOR EX PIPE MTG	TATA spare parts
502349209901	HEAT SHIELD (BEND 01 AT CATCON)	TATA spare parts
502349209902	HEAT SHIELD (AFTER BEND01)	TATA spare parts
502349209903	HEAT SHIELD (BEND 02 FROM CATCON)	TATA spare parts

502349209904	HEAT SHIELD (AFTER BEND02)	TATA spare parts
502349209905	HEAT SHIELD (BEFORE BEND03)	TATA spare parts
502349209906	HEAT SHIELD (BEND 03 FROM CATCON)	TATA spare parts
502349209907	HEAT SHIELD (BEFORE BEND 04)	TATA spare parts
502349209908	HEAT SHIELD (BEND 04 AT TURBO)	TATA spare parts
502349600101	HEAT SHIELD SILENCER	TATA spare parts
502349600102	HEAT SHIELD DOC POC	TATA spare parts
502349990103	KIT-EXHAUST PIPE HEAT SHIELD	TATA spare parts
502350000109	STAND ALONE BATTERY COOLING CIRCUIT	TATA spare parts
502350009201	WASHER B16.5 (47 OD)	TATA spare parts
502350100103	AUX. TANK (FOR BATTERY COOLING SYSTEM)	TATA spare parts
502350109906	FILLER NECK	TATA spare parts
502350109907	PRESSURE CAP ASSY AUX WATER TANK	TATA spare parts
502350400106	TRACTION RADIATOR	TATA spare parts
502350400118	HOSE (MOTOR1 INLET)	TATA spare parts
502350400119	HOSE (MOTOR2 INLET)	TATA spare parts
502350400121	HOSE (MOTOR1 OUTLET)	TATA spare parts
502350400122	HOSE (MOTOR2 OUTLET)	TATA spare parts
502350400151	PIPE 2(TRACTION MOTOR TO RADIATOR)	TATA spare parts
502350400152	PIPE 1(TRACTION MOTOR TO RADIATOR)	TATA spare parts
502350400153	PIPE 1 (TRACTION MOTOR TO PUMP)	TATA spare parts
502350400155	CLAMP ASSY	TATA spare parts
502350400158	PIPE 2 (TRACTION MOTOR TO PUMP)	TATA spare parts
502350400159	HOSE (GENERATOR INLET)	TATA spare parts
502350400168	PIPE 3(TRACTION MOTOR TO RADIATOR)	TATA spare parts
502350400169	HOSE (GENERATOR OUTLET)	TATA spare parts
502350400170	HOSE (INVERTER 1 INLET)	TATA spare parts
502350400171	HOSE (INVERTER 1 & 2 OUTLET)	TATA spare parts
502350400172	HOSE (INVERTER 2 INLET)	TATA spare parts
502350400173	HOSE (INVERTER 3 & 4 INLET)	TATA spare parts
502350400174	HOSE (INVERTER 3 OUTLET)	TATA spare parts
502350400175	HOSE (INVERTER 4 OUTLET)	TATA spare parts
502350400176	HOSE 2 (AUX. TANK TO PUMP)	TATA spare parts
502350400177	HOSE 1 (AUX. TANK TO PUMP)	TATA spare parts
502350400178	ASSY RUBBER CLAMP	TATA spare parts
502350400180	ASSY JUNCTION PIPE (RADIATOR TO PUMP)	TATA spare parts
502350400181	ASSY BKT PUMP MTG	TATA spare parts
502350400182	ASSY JUNCTION PIPE (PUMP TO INVERTER)	TATA spare parts
502350400183	ASSY JUNCTION PIPE (INVERTER TO TRACTION	TATA spare parts
502350400186	ASSY JUNCTION PIPE (BATTERY 1&2 TO PUMP)	TATA spare parts
502350400187	ASSY JUNCTION PIPE(PUMP TO BATTERY 1&2)	TATA spare parts
502350400192	ASSY. JUNCTION PIPE	TATA spare parts
502350400193	ASSY. JUNCTION PIPE	TATA spare parts
502350403307	L - BRACKET BS6	TATA spare parts
502350403310	C BRACKET (PIPE CLAMP)	TATA spare parts
502350403329	L BRACKET	TATA spare parts
502350403351	L-SOPORTE	TATA spare parts

502350404210	CLAMP(FOR PIPE CLAMPING)	TATA spare parts
502350405809	HOSE(HEXMANIFOLD CONNECTING)	TATA spare parts
502350405845	HOSE (PUMP TO SABCU)	TATA spare parts
502350405850	HOSE (BATTERY 1 TO PUMP)	TATA spare parts
502350405851	HOSE (BATTERY 1 & 2 TO PUMP)	TATA spare parts
502350405852	HOSE (AUX. TANK TO PUMP)	TATA spare parts
502350405853	HOSE (SABCU TO BAT. 1&2))	TATA spare parts
502350405854	HOSE (SABCU TO BAT. 1)	TATA spare parts
502350405855	HOSE (SABCU TO BAT. 2)	TATA spare parts
502350405856	HOSE (BATTERY 2 TO PUMP)	TATA spare parts
502350405860	REDUCER HOSE (PUMP INLET)	TATA spare parts
502350405866	HOSE (SABCU OUTLET)	TATA spare parts
502350405868	HOSE (BATTERY OUTLET)	TATA spare parts
502350405869	HOSE (BATTERY INLET)	TATA spare parts
502350405872	HOSE (CON 25OD TO SABCU INLET)	TATA spare parts
502350405874	HOSE (SABCU TO BATTERY)	TATA spare parts
502350406804	HOSE(RADIATOR INLET)	TATA spare parts
502350406807	HOSE(TRACTION PUMP INLET)	TATA spare parts
502350406813	HOSE(TRACTION PUMP OUTLET)	TATA spare parts
502350406814	HOSE RAD INLET	TATA spare parts
502350406816	HOSE (RADIATOR OUTLET)	TATA spare parts
502350406817	HOSE (VENT PIPE TO AUX. TANK)	TATA spare parts
502350406818	HOSE (RAD TO VENT PIPE)	TATA spare parts
502350406820	PLUG HOSE (AUX. TANK)	TATA spare parts
502350406821	ELBOW HOSE	TATA spare parts
502350406921	PIPE (AUX. TANK TO PUMP)	TATA spare parts
502350406977	PIPE (SABCU TO BATTERY)	TATA spare parts
502350410101	ASSY METAL CONNECTOR (25 OD)	TATA spare parts
502350410102	HOSE (AUX. TANK)	TATA spare parts
502350410103	ASSY. BKT HOSE SUPPORT	TATA spare parts
502350410104	RADIATOR ASSY.	TATA spare parts
502350420101	SHROUD ASSY.	TATA spare parts
502350420102	FM ASSY.	TATA spare parts
502350990110	COMPRESSOR	TATA spare parts
502350990111	CONDENSER FAN	TATA spare parts
502350990112	MULTIFLOW MFC	TATA spare parts
502350990113	THERMAL EXPANSION VALVE	TATA spare parts
502350990114	TEMPERATURE SENSOR	TATA spare parts
502350990115	PRESSURE SWITCH	TATA spare parts
502350990116	FRAME ASSEMBLY -COMPRESSOR MTG	TATA spare parts
502350990117	CONTROL UNIT-HEATING MODULE GL-S0CSP001	TATA spare parts
502350990118	RECEIVER DRIER -2710559 B	TATA spare parts
502350990119	SUCTION PIPE ASSY-1	TATA spare parts
502350990120	SUCTION PIPE ASSY-2	TATA spare parts
502350990121	DISCHARGE PIPE ASSY	TATA spare parts
502350990122	LIQUID PIPE ASSY	TATA spare parts
502350990123	RECEIVER OUTLET PIPE ASSY	TATA spare parts

502350990124	TXV OUTLET PIPE ASSY	TATA spare parts
502350990125	WATER INLET PIPE ASSY PLATE HEAT EXCHGR	TATA spare parts
502350990126	WATER OUTLET PIPE ASSY PLATE HEAT EXCHGR	TATA spare parts
502350999901	TRACTION COOLING PUMP	TATA spare parts
502350999901C	TRACTION COOLING PUMPCORE	TATA spare parts
502350999902	PLATE LH SIDE	TATA spare parts
502350999903	BASE PLATE	TATA spare parts
502350999904	PLATE RH SIDE	TATA spare parts
502350999905	CONDENSER FAN PLATE	TATA spare parts
502350999906	COVER PLATE	TATA spare parts
502350999907	CLAMPING PLATE-HEAT EXCHANGER	TATA spare parts
502350999908	SUPPORT PLATE-HEAT EXCHANGER	TATA spare parts
502350999909	BRACKET-RECIEVER DRIER	TATA spare parts
502350999910	CLAMPING PAD	TATA spare parts
502350999911	FIXING BRACKET(BASE CHANNEL)	TATA spare parts
502350999912	PLATE HEAT EXCHANGER AC30EQ-14H	TATA spare parts
502350999913	GROMMET- COMPRESSOR MTG.	TATA spare parts
502350999914	BRACKET -COMPRESSOR MTG	TATA spare parts
502350999915	SLEEVE	TATA spare parts
502350999916	PIPE CLAMP	TATA spare parts
502354108219	CLAMP	TATA spare parts
502354109901	BATTERY 12V/200AH	TATA spare parts
502354131606	BATTERY LINK	TATA spare parts
502354151601	BATT +VE TO I/P OF MANUAL CUT OFF	TATA spare parts
502354151602	BATT -VE TO STARTER MOTOR -VE	TATA spare parts
502354151603	SM +VE TO O/P OF ELEC CUT OFF	TATA spare parts
502354151604	ALT +VE TO O/P OF MANUAL CUT OFF	TATA spare parts
502354151605	O/P OF MANUAL TO I/P OF ELEC CUT OFF	TATA spare parts
502354151606	O/P OF ELEC CUT OFF TO I/P OF MAXI FUSE	TATA spare parts
502354151608	BATT -VE TO PANEL -VE SPLITTER	TATA spare parts
502354151609	SM -VE TO CHASSIS	TATA spare parts
502354151610	MAXI FUSE BOX O/P TO PANEL +VE SPLITTER	TATA spare parts
502354151611	MAXI FUSE BOX LINK	TATA spare parts
502354151612	BATT -VE TO CHASSIS	TATA spare parts
502354200108	ABS SENSOR CABLE	TATA spare parts
502354200111	INSTRUMENT CLUSTER MIDLINE PARALLEL HYBR	TATA spare parts
502354200117	BRACKET ASSLY; START STOP BOX	TATA spare parts
502354200119	ABS SENSOR CABLE REAR LH	TATA spare parts
502354200120	ABS SENSOR CABLE REAR LH	TATA spare parts
502354200121	TELL-TALE HYBRID ERROR&HV HAZARD WARNING	TATA spare parts
502354200126	TELL-TALE INDICATOR ENGINE	TATA spare parts
502354200131	TELL-TALE INDICATOR STEERING WARNING	TATA spare parts
502354200134	INSTRUMENT CLUSTER INTERFACE HARDWARE	TATA spare parts
502354200152	ECU ABS E4.5 BSC 24V 4S/4M 4S/3M BS2/3/4	TATA spare parts
502354200164	INSTRUMENT CLUSTER ASSY EV	TATA spare parts
502354201605	INDICATOR LAMP	TATA spare parts
502354201606	INDICATOR LAMP	TATA spare parts

502354204904	INDICATOR LAMP	TATA spare parts
502354204905	INDICATOR LAMP	TATA spare parts
502354208207	PLATE REAR SWITCH MTG	TATA spare parts
502354230107	ASSY REAR PANEL CNG LF SERIES HYBRID BUS	TATA spare parts
502354303302	BRACKET HORN MTG	TATA spare parts
502354400108	ENGINE LAMP ASSY	TATA spare parts
502354500106	BRACKET ASSY,BATTERY CUT OFF SWITCH MTG	TATA spare parts
502354500111	SWITCH KNEELING FRONT LEFT/REAR LEFT	TATA spare parts
502354500126	BRACKET ASSY,BATTERY CUT OFF SWITCH MTG	TATA spare parts
502354504902	SWITCH BODY BUILDER EMERGENCY	TATA spare parts
502354504903	SWITCH DRIVER LAMP	TATA spare parts
502354504904	SWITCH DESTINATION BOARD	TATA spare parts
502354504905	SWITCH STOP REQUEST BUZZER RESET	TATA spare parts
502354504906	SWITCH INTERNAL STAGE LAMP 1 & 2	TATA spare parts
502354504907	SWITCH DRIVER FAN	TATA spare parts
502354504908	SWITCH NIGHT LAMP	TATA spare parts
502354504909	SWITCH FRONT/REAR DOOR OPEN	TATA spare parts
502354504915	SWITCH EMERGENCY DOOR RESET	TATA spare parts
502354504916	SWITCH FRONT DOOR OPEN/CLOSE	TATA spare parts
502354504917	SWITCH REAR DOOR OPEN/CLOSE	TATA spare parts
502354504920	SWITCH¿ ASR CUT-OFF	TATA spare parts
502354504924	SWITCH¿BATTERY¿CUT¿OFF	TATA spare parts
502354504925	SWITCHALLDOOROPEN/CLOSE EV	TATA spare parts
502354504926	SWITCH,FRONT DOOR OPEN/CLOSE	TATA spare parts
502354504927	SWITCH GEAR RANGE SELECTOR EV	TATA spare parts
502354504930	SWITCH HALT BRAKE EV	TATA spare parts
502354504931	SWITCH ASR CUT-OFF EV	TATA spare parts
502354504932	SWITCH FRONT DOOR OPEN/CLOSE EV	TATA spare parts
502354504933	SWITCH KNEELING FRONT EV	TATA spare parts
502354504936	SWITCH KNEELING REAR EV	TATA spare parts
502354504937	SWITCH KNEELING BOTH EV	TATA spare parts
502354506308	CARRIER PLATE FASCIA SWITCH	TATA spare parts
502354506309	CARRIER PLATE FASCIA SWITCH	TATA spare parts
502354506901	KNEELING BOTH SW (SPRING RETURN MARQUAR	TATA spare parts
502354506902	FERRY LIFT UP SW (SPRING RETURN MARQUARD	TATA spare parts
502354506903	SUSPENSION NORMAL LEVEL SW(SPRING RETURN	TATA spare parts
502354506904	HALT BRAKE SW (SPRING RETURN MARQUART)	TATA spare parts
502354506905	HILL HOLDER SW (SPRING RETURN MARQUART)	TATA spare parts
502354506906	ASR OFFROAD SW (SPRING RETURN MARQUART)	TATA spare parts
502354506907	LOWER LEVEL SW (SPRING RETURN MARQUART)	TATA spare parts
502354506908	FERRY LIFT UP/DOWN	TATA spare parts
502354506910	SWITCH KNEELING/NORMAL LEVEL	TATA spare parts
502354506914	SWITCH¿ HALT BRAKE	TATA spare parts
502354506915	SWITCH¿ HILL HOLDER	TATA spare parts
502354506918	SWITCH¿ FERRY LIFT UP/DOWN	TATA spare parts
502354506920	KNEELING/NORMAL LEVEL(WITH BACK ILLUM)	TATA spare parts
502354506921	SWITCH¿ BATTERY CUTOFF	TATA spare parts

502354506922	SWITCH¿ STEERING WHEEL ADJUSTMENT	TATA spare parts
502354506923	SWITCH¿ ENGINE LAMP	TATA spare parts
502354506924	SWITCH¿ HAZARD	TATA spare parts
502354509902	CAN BASED GEAR RANGE SELECTOR SWITCH	TATA spare parts
502354509902C	GEAR RANGE SELECTOR(DNR) SWCORE	TATA spare parts
502354603303	BRACKET DIAGNOSTIC CONNECTOR MTG	TATA spare parts
502354603308	BRACKET FOR FUSE BOX MTG	TATA spare parts
502354603312	BRACKET MAXI FUSE BOX PLATE MTG	TATA spare parts
502354603315	BRACKET CONNECTOR MTG	TATA spare parts
502354603320	BRACKET MAXI FUSE BOX PLATE MTG	TATA spare parts
502354608205	U BRKT	TATA spare parts
502354608221	BRKT¿FOR¿OBD¿CONNECTOR	TATA spare parts
502354608222	BRKT FOR MEGA FUSE BOX	TATA spare parts
502354609941	CABLE	TATA spare parts
502354609956	RESISTOR BANK EV	TATA spare parts
502354610146	WIRING HARNESS INVERTOR	TATA spare parts
502354610192	W/H BATTERY COOLING SYSTEM COMP	TATA spare parts
502354610193	WIRING HARNESS TAIL	TATA spare parts
502354610194	WIRING HARNESS E-CAN REAR	TATA spare parts
502354610196	WIRING HARNESS E-CAN FRONT	TATA spare parts
502354610197	WIRING HARNESS P-CAN REAR	TATA spare parts
502354610198	WIRING HARNESS P-CAN FRONT	TATA spare parts
502354610199	WIRING HARNESS S-CAN	TATA spare parts
502354611666	BATTERY CABLE SHORT LINK	TATA spare parts
502354611679	CABLE BATTERY +VE TO MANUAL CUT OFF	TATA spare parts
502354611680	CABLE MECH CUT OFF O/P TO STR FUSE I/P	TATA spare parts
502354611681	CABLE STR FUSE O/P TO ELEC CUT OFF I/P	TATA spare parts
502354611682	CABLE ELEC CUT OFF SW O/P TO SM +VE	TATA spare parts
502354611683	CABLE ELEC CUT OFF SW O/P TO DC-DC +VE	TATA spare parts
502354611685	CABLE ELEC CUT OFF SW O/P TO SM -VE	TATA spare parts
502354611686	CABLE BATT -VE TO ELEC CUT OFF SW I/P	TATA spare parts
502354611687	CABLE ELEC CUT OFF SW O/P TO DC-DC -VE	TATA spare parts
502354620119	WIRING HARNESS CONTROL	TATA spare parts
502354620121	WIRING HARNESS MAIN	TATA spare parts
502354620122	WIRING HARNESS ECAS	TATA spare parts
502354620123	WIRING HARNESS ROOF	TATA spare parts
502354620125	WIRING HARNESS EBS	TATA spare parts
502354620126	WIRING HARNESS BODY	TATA spare parts
502354620127	WIRING HARNESS SWITCH	TATA spare parts
502354620128	WIRING HARNESS ENGINE	TATA spare parts
502354620130	WIRING HARNESS REAR PANEL	TATA spare parts
502354620134	WIRING HARNESS HEADLAMP & BLINKER	TATA spare parts
502354620136	WIRING HARNESS EMERGENCY STEERING SYSTEM	TATA spare parts
502354620185	CABLE BATTERY -VE TO CHASSIS	TATA spare parts
502354620189	WIRING HARNESS HEADLAMP & BLINKER	TATA spare parts
502354620194	BATTERY CABLE SHORT LINK	TATA spare parts
502354620195	CABLE BATTERY +VE TO BATTERY CUT OFF SW	TATA spare parts



502354621622	CABLE BATTERY -VE TO CHASSIS	TATA spare parts
502354630102	ASSY U BRKT INVERTER TRAY MOUNTING	TATA spare parts
502354630107	WIRING HARNESS FES	TATA spare parts
502354630108	WIRING HARNESS E-CAN FRONT	TATA spare parts
502354630110	CABLE ELEC CUT OFF SW O/P TO DC-DC -VE	TATA spare parts
502354630111	WIRING HARNESS MAXI FUSE	TATA spare parts
502354630114	WIRING HARNESS TAIL	TATA spare parts
502354630115	CABLE ELEC CUT OFF SW O/P TO DC-DC +VE	TATA spare parts
502354630116	WIRING HARNESS P-CAN FRONT	TATA spare parts
502354630117	WIRING HARNESS SWITCH	TATA spare parts
502354630124	WIRING HARNESS ABS	TATA spare parts
502354630126	WIRING HARNESS CONTROL	TATA spare parts
502354630131	WIRING HARNESS PIGTAIL HV BATTERY	TATA spare parts
502354630132	WIRING HARNESS P-CAN REAR	TATA spare parts
502354630133	WIRING HARNESS ROOF	TATA spare parts
502354630134	WIRING HARNESS E-CAN REAR	TATA spare parts
502354630137	WIRING HARNESS TAIL	TATA spare parts
502354630138	WIRING HARNESS CONTROL	TATA spare parts
502354630139	WIRING HARNESS, ROOF	TATA spare parts
502354630141	CABLE, BATTERY +VE TO BATTERY CUT OFF SW	TATA spare parts
502354630142	CABLE, MECH CUT OFF TO ELEC CUT OFF SW I/	TATA spare parts
502354630143	WIRING HARNESS, E-CAN, FRONT	TATA spare parts
502354630144	WIRING HARNESS, CONTROL	TATA spare parts
502354630145	WIRING HARNESS, MAXI FUSE	TATA spare parts
502354630146	CABLE, ELEC CUT OFF SW O/P TO DC-DC +VE	TATA spare parts
502354630147	WIRING HARNESS, POWER CABLE	TATA spare parts
502354630149	WIRING HARNESS, P-CAN	TATA spare parts
502354630150	CABLE, BATTERY -VE TO DC-DC CONVERTER -VE	TATA spare parts
502354630152	WIRING HARNESS EV CAN FRONT	TATA spare parts
502354630155	WIRING HARNESS, E-CAN, REAR	TATA spare parts
502354630157	CABLE BATTERY +VE TO BATTERY CUT OFF SW	TATA spare parts
502354630158	WIRING HARNESS, TAIL	TATA spare parts
502354630161	BRACKET ASSY FUSE & RELAY MTG	TATA spare parts
502354630163	FRONT PANEL ASSY	TATA spare parts
502354630164	WIRING HARNESS, ACCELERATOR PEDAL	TATA spare parts
502354630165	WIRING HARNESS, REVERSE PARK ASSIST	TATA spare parts
502354630170	WIRING HARNESS E-CAN REAR	TATA spare parts
502354630172	CABLE, BATTERY -VE TO CHASSIS	TATA spare parts
502354630176	WIRING HARNESS CHASSIS CAN FRONT	TATA spare parts
502354630183	WIRING HARNESS FES	TATA spare parts
502354638204	TRAY-CABLE MTG INVERTER	TATA spare parts
502354638209	TRAY FOR HV CNG LE	TATA spare parts
502354638210	BRKT FOR STARTER RELAY MTG	TATA spare parts
502354640105	CABLE BATTERY -VE TO CHASSIS	TATA spare parts
502354640106	CABLE MECH CUT OFF O/P TO ELEC CUT OFF I	TATA spare parts
502354640123	WIRING HARNESS REVERSE PARK ASSIST	TATA spare parts
502354640124	WIRING HARNESS SWITCH	TATA spare parts

502354640125	WIRING HARNESS MAXI FUSE	TATA spare parts
502354640135	BRACKET MEGA FUSE BOX MTG	TATA spare parts
502354640141	WIRING HARNESS,MAIN	TATA spare parts
502354640142	WIRING HARNESS,BODY	TATA spare parts
502354640143	WIRING HARNESS,HEADLAMP	TATA spare parts
502354640144	WIRING HARNESS,ABS	TATA spare parts
502354640145	WIRING HARNESS,SWITCH	TATA spare parts
502354640157	BRACKET MEGA FUSE BOX MTG	TATA spare parts
502354640165	CABLE BATTERY +VE TO BATTERY CUT OFF SW	TATA spare parts
502354650102	WIRING HARNESS REVERSE PARK ASSIST	TATA spare parts
502354650111	CABLE ELEC CUT OFF SW O/P TO DC-DC +VE E	TATA spare parts
502354650112	CABLE BATTERY -VE TO DC-DC CONVERTER -VE	TATA spare parts
502354650113	CABLE BATTERY CUT OFF SWITCH EV	TATA spare parts
502354650124	WIRING HARNESS MAIN	TATA spare parts
502354650125	WIRING HARNESS SWITCH	TATA spare parts
502354650126	WIRING HARNESS CHASSIS CAN REAR	TATA spare parts
502354650127	WIRING HARNESS EV CAN REAR	TATA spare parts
502354650128	WIRING HARNESS CONTROL	TATA spare parts
502354650129	WIRING HARNESS ROOF	TATA spare parts
502354650132	WIRING HARNESS BODY	TATA spare parts
502354650133	WIRING HARNESS MAXI FUSE	TATA spare parts
502354650134	WIRING HARNESS TAIL	TATA spare parts
502354651601	W/H MAIN FOR LF CNG SERIES HYBRID BUS	TATA spare parts
502354651602	W/H TAIL FOR LF CNG SERIES HYBRID BUS	TATA spare parts
502354651603	W/H BODY FOR LF CNG SERIES HYBRID BUS	TATA spare parts
502354651604	W/H ENGINE FOR LF CNG SERIES HYBRID BUS	TATA spare parts
502354651605	W/H P CAN MAIN	TATA spare parts
502354651606	W/H P CAN CONTROL	TATA spare parts
502354651607	W/H P CAN HV BATT	TATA spare parts
502354651608	W/H PANEL FOR LF CNG SERIES HYBRID BUS	TATA spare parts
502354651609	W/H E CAN ENGINE	TATA spare parts
502354651610	W/H S CAN	TATA spare parts
502354651611	W/H CONTROL	TATA spare parts
502354651612	W/H STEERING WHEEL	TATA spare parts
502354651613	W/H STARTER ALTERNATOR	TATA spare parts
502354651614	BATTERY CABLE SHORT LINK(+VE)	TATA spare parts
502354651615	BATTERY CABLE SHORT LINK(-VE)	TATA spare parts
502354651618	W/H BATT COOL SYS COMPR	TATA spare parts
502354651620	W/H ROOF	TATA spare parts
502354700111	ECU,VEHICLE TRACKING ASSY	TATA spare parts
502354700114	REAR PANEL ASSY	TATA spare parts
502354700116	FRONT PANEL ASSY	TATA spare parts
502354700117	BRACKET ASSY YAW RATE SENSOR MTG	TATA spare parts
502354704901	ELECTRONICS STABILITY CONTROL MODULE	TATA spare parts
502354709901	WHEEL SPEED SENSOR BS1/2/3/4/6	TATA spare parts
502354709909	CONTROLLER BATTERY COOLING SYSTEM	TATA spare parts
502354709909C	CONTROLLER BATTERY COOLING SYSTEMCORE	TATA spare parts

502354709911	CONTROLLER BATTERY COOLING SYSTEM	TATA spare parts
502354709912	VEHICLE ELECTRONIC CONTROLLER UNIT	TATA spare parts
502354800107	BRACKET ASSY ECU MTG	TATA spare parts
502354800108	BRACKET ASSY ECU MTG	TATA spare parts
502354800110	BRACKET ASSY CBCU MTG	TATA spare parts
502354800114	PANEL ELECRITICAL AGGREGATE MTG	TATA spare parts
502354803309	BRACKET CBCU MTG	TATA spare parts
502354804901	ECU ELECTRONIC BRAKING SYSTEM-3	TATA spare parts
502354808601	SPACER FUSE BOX MTG	TATA spare parts
502354900110	PANEL ASSY ECU	TATA spare parts
502354903302	BRACKET CONNECTOR MTG	TATA spare parts
502354990101	ASSY KIT FOR IVTM ELECTRICAL SYSTEM	TATA spare parts
502354990102	ASSY.KIT GAS LEAK DETECTION SYSTEM	TATA spare parts
502358604001	CLAMP	TATA spare parts
502360100134	OUTRIGGER ASSY DRIVER SIDE	TATA spare parts
502360100140	DRIVER STATION ASSY WITH CED COATING	TATA spare parts
502360100150	OUTRIGGER ASSY CO-DRIVER SIDE	TATA spare parts
502360100167	CHANNEL ASSY	TATA spare parts
502360100171	DRIVER STATION ASSY WITH CED COATING	TATA spare parts
502360100184	DRIVER STATION ASSY WITH CED COATING	TATA spare parts
502360100187	DRIVER STATION ASSY	TATA spare parts
502360100198	DRIVER STATION ASSY WITH CED COATING	TATA spare parts
502360108284	PANEL FRONT	TATA spare parts
502360108285	PANEL FRONT	TATA spare parts
502360108287	PANEL FRONT	TATA spare parts
502360108293	PANEL FRONT	TATA spare parts
502380000101	3 PHASE AC DISTRIBUTION BOX	TATA spare parts
502380000105	ASSY JUNCTION BOX	TATA spare parts
502380000106	ASSY SUMMATION GEAR BOX	TATA spare parts
502380100202	EV LV POWER AND CAN WIRING HARNESS	TATA spare parts
502380101643	CABLE GND HV AUX DRIVE TO CHASSIS GND	TATA spare parts
502380101644	CABLE GND HV BATT 1 TO BCS STRUCTURE	TATA spare parts
502380101645	CABLE GND HV BATT 2 TO BCS STRUCTURE	TATA spare parts
502380101646	CABLE HV BATTERY-1 TO HV JUNCTION BOX	TATA spare parts
502380101647	CABLE HV DC-DC CONV TO HV JUNCTION BOX	TATA spare parts
502380101649	CABLE HV 3-PHASE DB C-2 AUX TO AUX DRIVE	TATA spare parts
502380101650	CABLE HV INV1-L1 TO MOTOR1-U	TATA spare parts
502380101651	CABLE HV INV1-L2 TO MOTOR1-V	TATA spare parts
502380101652	CABLE HV INV1-L3 TO MOTOR1-W	TATA spare parts
502380101653	CABLE HV INV2-L1 TO MOTOR2-U	TATA spare parts
502380101654	CABLE HV INV2-L2 TO MOTOR2-V	TATA spare parts
502380101655	CABLE HV INV2-L3 TO MOTOR2-W	TATA spare parts
502380101659	CABLE HV INV4-L1 TO 3PH DB-U	TATA spare parts
502380101660	CABLE HV INV4-L2 TO 3PH DB-V	TATA spare parts
502380101661	CABLE HV INV4-L3 TO 3PH DB-W	TATA spare parts
502380101662	CABLE HV INV1-P2 TO HV J/B-PA	TATA spare parts
502380101663	CABLE HV INV1-M2 TO HV J/B-MA	TATA spare parts

502380101664	CABLE HV INV1-P1 TO INV3-P1	TATA spare parts
502380101665	CABLE HV INV1-M1 TO INV3-M1	TATA spare parts
502380101666	CABLE HV INV2-P1 TO HV INV3-P2	TATA spare parts
502380101667	CABLE HV INV2-M1 TO HV INV3-M2	TATA spare parts
502380101668	CABLE HV INV2-P2 TO HV INV4-P1	TATA spare parts
502380101669	CABLE HV INV2-M2 TO HV INV4-M1	TATA spare parts
502380101674	CABLE GND HV INV1 TO CHASSIS GND	TATA spare parts
502380101675	CABLE GND HV INV2 TO CHASSIS GND	TATA spare parts
502380101676	CABLE GND HV INV3 TO CHASSIS GND	TATA spare parts
502380101677	CABLE GND HV INV4 TO CHASSIS GND	TATA spare parts
502380101679	CABLE GND HV 3PH DB TO CHASSI GND	TATA spare parts
502380101680	CABLE GND HV DC JB TO CHASSI GND	TATA spare parts
502380101681	CABLE GND HV MOTOR1 TO MOTOR2	TATA spare parts
502380101682	CABLE GND HV MOTOR1 TO CHASSIS GND	TATA spare parts
502380101688	CABLE HV SIGNAL INV1 TO MOTOR1	TATA spare parts
502380101689	CABLE HV SIGNAL INV2 TO MOTOR2	TATA spare parts
502380103302	L-BRACKET¿CABLE¿SUPPORT	TATA spare parts
502380103305	L-BRACKET¿CABLE¿SUPPORT	TATA spare parts
502380103306	L-BRACKET¿CABLE¿SUPPORT	TATA spare parts
502380103308	Z-BRACKET CABLE SUPPORT	TATA spare parts
502380103315	Z-BRACKET,CABLE SUPPORT	TATA spare parts
502380103316	L-BRACKET,CABLE SUPPORT	TATA spare parts
502380103317	PLATE	TATA spare parts
502380103318	Z-BRACKET CABLE SUPPORT	TATA spare parts
502380103319	L-BRACKET,CABLE SUPPORT	TATA spare parts
502380103320	Z-BRACKET,CABLE SUPPORT	TATA spare parts
502380103337	L-BRACKET CABLE SUPPORT	TATA spare parts
502380103338	BRACKET CABLE SUPPORT	TATA spare parts
502380103340	L-BRACKET CABLE SUPPORT	TATA spare parts
502380103341	BRACKET CABLE SUPPORT	TATA spare parts
502380103348	L-BRACKET,CABLE SUPPORT	TATA spare parts
502380103351	L-BRACKET CABLE SUPPORT	TATA spare parts
502380103356	L-BRACKET CABLE SUPPORT	TATA spare parts
502380103372	L-BRACKET CABLE SUPPORT	TATA spare parts
502380103377	Z-BRACKET CABLE SUPPORT	TATA spare parts
502380111611	CLAMP CABLE HV 2 POSITION	TATA spare parts
502380111612	CLAMP CABLE HV 4 POSITION	TATA spare parts
502380111617	CABLE GND HV DC DC CONV TO BCS STR GND	TATA spare parts
502380111621	CABLE HV INV3-L1 TO GENRATOR-U	TATA spare parts
502380111622	CABLE HV INV3-L2 TO GENRATOR-V	TATA spare parts
502380111623	CABLE HV INV3-L3 TO GENRATOR-W	TATA spare parts
502380111624	CABLE SIGNAL HV INV3 TO GENRATOR	TATA spare parts
502380111625	CABLE GND GENERATOR TO CHASSIS	TATA spare parts
502380111661	CABLE HV JUNCTION BOX TO AC COMPRESSOR	TATA spare parts
502380111662	CABLE GND HV AC COMP TO BCS STRUCTURE	TATA spare parts
502380120142	CABLE HV MOTOR INVERTER-6 TO MOTOR-A1	TATA spare parts
502380120143	CABLE HV MOTOR INVERTER-5 TO MOTOR-B1	TATA spare parts

502380120144	CABLE HV MOTOR INVERTER-4 TO MOTOR-C1	TATA spare parts
502380120145	CABLE HV MOTOR INVERTER-3 TO MOTOR-A2	TATA spare parts
502380120146	CABLE HV MOTOR INVERTER-2 TO MOTOR-B2	TATA spare parts
502380120147	CABLE HV MOTOR INVERTER-1 TO MOTOR-C2	TATA spare parts
502380120149	CABLE HV GND MOTOR TO CHASSIS GND	TATA spare parts
502380120150	CABLE HV GND INVERTER TO CHASSIS GND	TATA spare parts
502380120153	CABLE HV GND AUX INV TO CHASSIS GND	TATA spare parts
502380120154	CABLE HV GND DC JB ETS TO CHASSIS GND	TATA spare parts
502380120155	CABLE HV AUX INV TO AUX DRIVE MOTOR	TATA spare parts
502380120167	CABLE HV JB ETS TO GBT CHARGER	TATA spare parts
502380120189	CABLE GND HV AUX DRIVE TO CHASSIS GND	TATA spare parts
502380120190	CABLE HV DC JB ETS TO HV DC JB BAT	TATA spare parts
502380120191	CABLE HV JB BAT TO HVAC UNIT	TATA spare parts
502380120192	CABLE HV BATTERY TO HV JUNCTION BOX	TATA spare parts
502380120193	CABLE HV BATTERY TO HV JUNCTION BOX	TATA spare parts
502380120194	CABLE HV BATTERY TO HV JUNCTION BOX	TATA spare parts
502380120196	BRACKET ASSY	TATA spare parts
502380120199	CABLE GND HV BATT-3 TO ROOF STR GND	TATA spare parts
502380121628	CLAMP ASSY	TATA spare parts
502380121637	CLAMP ASSY CABLE SUPPORT 2 POSITION	TATA spare parts
502380130101	BRACKET ASSY	TATA spare parts
502380130102	CABLE GND HVAC TO ROOF STR GND	TATA spare parts
502380130103	CABLE,HV MOTOR INVERTER-1 TO MOTOR-C2	TATA spare parts
502380130104	CABLE,HV MOTOR INVERTER-2 TO MOTOR-B2	TATA spare parts
502380130105	CABLE,HV MOTOR INVERTER-3 TO MOTOR-A2	TATA spare parts
502380130106	CABLE,HV MOTOR INVERTER-4 TO MOTOR-C1	TATA spare parts
502380130107	CABLE,HV MOTOR INVERTER-5 TO MOTOR-B1	TATA spare parts
502380130108	CABLE,HV MOTOR INVERTER-6 TO MOTOR-A1	TATA spare parts
502380130109	CABLE,HV AUX INV TO AUX DRIVE MOTOR	TATA spare parts
502380130110	CABLE,HV JB ROOF TO HVAC UNIT	TATA spare parts
502380130111	CABLE,HV JB ROOF TO HV JB ETS 1	TATA spare parts
502380130112	CABLE,HV JB ETS 1 TO GBT CHARGER 1	TATA spare parts
502380130113	CABLE,HV MOTOR INVERTER TO HV JB ETS 1	TATA spare parts
502380130114	CABLE,HV SIGNAL INVERTER TO MOTOR	TATA spare parts
502380130115	CABLE,HV AUX INV TO HV JB ETS 1	TATA spare parts
502380130116	CABLE,HV JB BATT TO GBT CHARGER 2	TATA spare parts
502380130118	CABLE,HV BAT-2 ROOF TO HV JB ROOF	TATA spare parts
502380130120	CABLE,GND HV BATT-1 TO ROOF STR GND	TATA spare parts
502380130121	CABLE,HV BAT-4 CHASSIS TO HV JB BATTERY	TATA spare parts
502380130124	CABLE,HV BAT-1 ROOF TO HV JB ROOF	TATA spare parts
502380130125	CABLE,HV BAT-3 CHASSIS TO HV JB BATTERY	TATA spare parts
502380130129	CABLE,HV ROOF STRUCTURE TO CHASSIS GND	TATA spare parts
502380130130	CABLE,GND HV BATT-2 TO ROOF STR GND	TATA spare parts
502380130131	CABLE,HV GND DC JB BAT TO ROOF STR GND	TATA spare parts
502380130132	CABLE,GND HVAC TO ROOF STR GND	TATA spare parts
502380130134	CABLE,HV GND DC JB BAT TO CHASSIS GND	TATA spare parts
502380130135	CABLE,GND HV BATT-3 TO CHASSIS GND	TATA spare parts

502380130136	CABLE,GND HV BATT-4 TO CHASSIS GND	TATA spare parts
502380130138	CABLE,HV GND DC JB ETS TO CHASSIS GND	TATA spare parts
502380130139	CABLE,HV ETS INVERTER TO CHASSIS GND	TATA spare parts
502380130140	CABLE,GND HV ETS MOTOR TO CHASSIS GND	TATA spare parts
502380130141	CABLE,HV GND AUX INV TO CHASSIS GND	TATA spare parts
502380130142	CABLE,GND HV AUX DRIVE TO CHASSIS GND	TATA spare parts
502380130165	CABLE HV AUX INV TO AUX DRIVE MOTOR	TATA spare parts
502380130166	CABLE HV JB ETS TO GBT CHARGER	TATA spare parts
502380130167	CABLE HV AUX INV TO HV JB ETS	TATA spare parts
502380130168	CABLE HV DC JB ETS TO HV DC JB BAT	TATA spare parts
502380130169	CABLE GND BCS TO ROOF STR GND	TATA spare parts
502380130171	CABLE ASSY	TATA spare parts
502380130173	CABLE ASSY	TATA spare parts
502380140102	CABLE ASSY	TATA spare parts
502380140103	BRACKET ASSY	TATA spare parts
502380140104	CABLE HV GND MOTOR TO CHASSIS GND	TATA spare parts
502380140105	CABLE HV GND INVERTER TO CHASSIS GND	TATA spare parts
502380140106	CABLE HV GND AUX INV TO CHASSIS GND	TATA spare parts
502380140107	CABLE HV GND DC JB ETS TO CHASSIS GND	TATA spare parts
502380140109	CABLE HV JB BAT TO HVAC UNIT	TATA spare parts
502380140110	CABLE HV BATTERY TO HV JUNCTION BOX	TATA spare parts
502380140111	CABLE GND HV AUX DRIVE TO CHASSIS GND	TATA spare parts
502380140180	PLATE ASSY	TATA spare parts
502380140196	BRACKET ASSY HV CABLE SUPPORT	TATA spare parts
502380150103	CABLE HV MOTOR INVERTER-1 TO MOTOR-C2 EV	TATA spare parts
502380150104	CABLE HV MOTOR INVERTER-2 TO MOTOR-B2 EV	TATA spare parts
502380150105	CABLE HV MOTOR INVERTER-3 TO MOTOR-A2 EV	TATA spare parts
502380150106	CABLE HV MOTOR INVERTER-4 TO MOTOR-C1 EV	TATA spare parts
502380150107	CABLE HV MOTOR INVERTER-5 TO MOTOR-B1 EV	TATA spare parts
502380150108	CABLE HV MOTOR INVERTER-6 TO MOTOR-A1 EV	TATA spare parts
502380150109	CABLE HV SIGNAL INVERTER TO MOTOR EV	TATA spare parts
502380150111	CABLE HV JB ROOF TO HV JB DUAL CHARGER E	TATA spare parts
502380150116	CABLE HV JB CHARGER TO CCS-2 CHARGER 2 E	TATA spare parts
502380150117	CABLE HV JB CHARGER TO CCS-2 CHARGER 1 E	TATA spare parts
502380150118	CABLE ASSY EV	TATA spare parts
502380150119	CABLE HV MOTOR INV TO HV JB CHARGER EV	TATA spare parts
502380150120	CABLE HV GND AIR COMP TO CHASSIS GND EV	TATA spare parts
502380150122	CABLE GND HV JB DUAL CHARGER TO CHASSIS	TATA spare parts
502380150124	CABLE HV BAT-1 ROOF TO HV JB ROOF EV	TATA spare parts
502380150125	CABLE HV BAT-2 ROOF TO HV JB ROOF EV	TATA spare parts
502380150126	CABLE HV BAT-3 CHASSIS TO HV JB BATTERY	TATA spare parts
502380150127	CABLE HV BAT-4 CHASSIS TO HV JB REAR EV	TATA spare parts
502380150128	CABLE HV ETS INVERTER TO CHASSIS GND EV	TATA spare parts
502380150129	CABLE GND HV ETS MOTOR TO CHASSIS GND EV	TATA spare parts
502380150130	CABLE GND HV BATT-1 TO ROOF STR GND EV	TATA spare parts
502380150131	CABLE GND HV BATT-2 TO ROOF STR GND EV	TATA spare parts
502380150132	CABLE GND HV BATT-3 TO CHASSIS GND EV	TATA spare parts

502380150133	CABLE GND HV BATT-4 TO CHASSIS GND EV	TATA spare parts
502380150134	CABLE HVGND STEERING PUMP TO CHASSIS GND	TATA spare parts
502380150135	CABLE HV GND DC JB BAT TO ROOF STR GND E	TATA spare parts
502380150147	BRACKET ASSY HV CABLE SUPPORT	TATA spare parts
502380150178	BRACKET ASSY HV CABLE SUPPORT	TATA spare parts
502380150192	CABLE ASSY EV	TATA spare parts
502380150193	CABLE ASSY EV	TATA spare parts
502380150194	CABLE ASSY EV	TATA spare parts
502380150195	CABLE ASSY EV	TATA spare parts
502380150196	CABLE HV JB - DC-DC COBVERTER	TATA spare parts
502380150197	BRACKET ASSY HV CABLE SUPPORT	TATA spare parts
502380150198	CABLE ASSY EV	TATA spare parts
502380150199	BRACKET ASSY HV CABLE SUPPORT	TATA spare parts
502380200189	JUNCTION BOX	TATA spare parts
502380200196	BRACKET ASSY JUNCTION BOX MTG	TATA spare parts
502380200198	JUNCTION BOX BATTERY	TATA spare parts
502380204910	CONTACTOR-A/C COMP	TATA spare parts
502380204911	CONTACTOR-AUX & SPARE	TATA spare parts
502380209903	LITTLE FUSE-MEGA FUSE HOLDER	TATA spare parts
502380209944	2 POLE CONNECTOR HVC2P10MV101 (CODE A)	TATA spare parts
502380209945	2 POLE CONNECTOR HVC2P10MV201 CODE B	TATA spare parts
502380209980	2 POLE CONNECTOR 50SQMM HVC2P80MV218 (C	TATA spare parts
502380210101	JUNCTION BOX,TRACTION	TATA spare parts
502380210103	JUNCTION BOX,DUAL CHARGER	TATA spare parts
502380210108	JUNCTION BOXTRACTION	TATA spare parts
502380210109	JUNCTION BOXBATTERY	TATA spare parts
502380210112	JUNCTION BOX,BATTERY	TATA spare parts
502380210114	JUNCTION BOX DUAL CHARGER	TATA spare parts
502380400101	ASSY TRACTION MOTOR	TATA spare parts
502380400114	MOTOR AUXILIARY DRIVE UNIT	TATA spare parts
502380400123	BRACKET ASSY	TATA spare parts
502380403302	CLAMP CLUTCH STOPPER	TATA spare parts
502380404901	ELECTRO MAGNETIC CLUTCH AUXILIARY MOTOR	TATA spare parts
502380404901C	ELECTRO MAGNETIC CLUTCH AUXILIARY MOTORC	TATA spare parts
502380405102	FLANGE TRACTION¿MOTOR	TATA spare parts
502380444901	DATA LOGGER ASSY	TATA spare parts
502380500101	ASSY INVERTER	TATA spare parts
502380500109	BRACKET¿ASSY¿INVERTER¿MTG	TATA spare parts
502380500110	BRACKET¿ASSY¿INVERTER¿MTG	TATA spare parts
502380500125	BRACKET ASSY	TATA spare parts
502380500127	BRACKET ASSY	TATA spare parts
502380504901	CONTROLLER DICO	TATA spare parts
502380504903	FLASH ECM	TATA spare parts
502380507701	RUBBER PAD	TATA spare parts
502380509908	BETA HVLP-20 LIQUID COOLED AC CONTROLLER	TATA spare parts
502380509909	BETA HVLP-20 LIQUID COOLED AC CONTROLLER	TATA spare parts
502380580103	DC-DC CONVERTER	TATA spare parts

502380600126	BATTERY PACK ASSY	TATA spare parts
502380600132	BATTERY BOX ASSEMBLY	TATA spare parts
502380601608	W/H JUNCTION BOX	TATA spare parts
502380604933	SHIELDED EXTERNAL LOOP	TATA spare parts
502380604934	SHIELDED EXTERNAL INTER CONNECT	TATA spare parts
502380651617	DC-DC TO JB HV CABLE	TATA spare parts
502380651626	400A FUSE BOX TO DC-DC CONVERTER	TATA spare parts
502380651627	80A FUSE BOX TO EQUALIZER	TATA spare parts
502380651628	125A FUSE BOX TO EQUALIZER	TATA spare parts
502380651640	AC COMP	TATA spare parts
502380651641	AUX MOTOR	TATA spare parts
502380651653	AC COMP TO GND STUD	TATA spare parts
502380651654	GND CABLE AUX DRIVE TO CHASSIS	TATA spare parts
502380651655	GND CABLE DC DC CONV TO CHASSIS	TATA spare parts
502380651656	GND CABLE HV BATT FRAME TO CHASSIS	TATA spare parts
502380700101	ASSY.GENERATOR	TATA spare parts
502380700103	GENERATOR ASSY	TATA spare parts
502380700105	GENERATOR COUPLING	TATA spare parts
502380710102	REAR PANEL ASSY	TATA spare parts
502380900142	ISOLATOR CONTROLLER MTG	TATA spare parts
502380900148	JUNCTION PIPE	TATA spare parts
502380900151	JUNCTION PIPE HOT LINE ASSY	TATA spare parts
502380900152	CONNECTOR	TATA spare parts
502380900155	BRACKET ASSY	TATA spare parts
502380900171	JUNCTION PIPE ASSY BATTERY OUTLET	TATA spare parts
502380900172	JUNCTION PIPE ASSY BATTERY INTAKE	TATA spare parts
502380900189	JUNCTION PIPE ASSY	TATA spare parts
502380900206	AUXILLARY TANK ASSY MOTORCOOLING	TATA spare parts
502380900212	BRACKET PUMP MTG	TATA spare parts
502380900214	JUNCTION PIPE COOL LINE ASSY	TATA spare parts
502380900215	JUNCTION PIPE HOT LINE ASSY	TATA spare parts
502380900218	BRACKET ASSY.PUMP MTG	TATA spare parts
502380900223	BRACKET ASSY,PUMP MTG	TATA spare parts
502380900229	BRACKET,RADIATOR MTG	TATA spare parts
502380900230	BRACKET,RADIATOR MTG	TATA spare parts
502380900232	BRACKET,RADIATOR MTG	TATA spare parts
502380900235	PIPE ASSY	TATA spare parts
502380900236	PIPE ASSY	TATA spare parts
502380900237	PIPE ASSY	TATA spare parts
502380900238	PIPE ASSY	TATA spare parts
502380900253	PIPE ASSY	TATA spare parts
502380900255	BRACKET ASSY	TATA spare parts
502380900256	BRACKET ASSY	TATA spare parts
502380900257	BRACKET ASSY	TATA spare parts
502380900260	PIPE ASSY	TATA spare parts
502380900261	PIPE ASSY	TATA spare parts
502380900263	BRACKET ASSY PUMP MTG	TATA spare parts



502380900264	BRACKET	TATA spare parts
502380900265	PIPE ASSY	TATA spare parts
502380900266	BRACKET ASSY	TATA spare parts
502380900267	BRACKET ASSY	TATA spare parts
502380900268	BRACKET ASSY	TATA spare parts
502380900269	PIPE ASSY	TATA spare parts
502380900270	PIPE ASSY	TATA spare parts
502380900271	PIPE ASSY	TATA spare parts
502380900272	PIPE ASSY	TATA spare parts
502380903309	BRACKET HOSE MTG	TATA spare parts
502380903318	BRACKET PIPE MTG	TATA spare parts
502380903330	BRACKET RADIATOR MTG	TATA spare parts
502380903331	BRACKET RADIATOR MTG	TATA spare parts
502380903351	BRACKET	TATA spare parts
502380903375	BRACKET	TATA spare parts
502380903376	BRACKET	TATA spare parts
502380903377	BRACKET	TATA spare parts
502380903378	BRACKET	TATA spare parts
502380903379	BRACKET	TATA spare parts
502380903380	BRACKET	TATA spare parts
502380903382	BRACKET	TATA spare parts
502380903383	BRACKET	TATA spare parts
502380903384	BRACKET	TATA spare parts
502380905837	HOSE	TATA spare parts
502380905838	HOSE	TATA spare parts
502380905839	HOSE	TATA spare parts
502380905840	HOSE	TATA spare parts
502380905841	HOSE AUXILLARY TANK TO PUMP MANIFOLD	TATA spare parts
502380905842	HOSE	TATA spare parts
502380905845	HOSE	TATA spare parts
502380905846	HOSE	TATA spare parts
502380905847	HOSE	TATA spare parts
502380905848	HOSE	TATA spare parts
502380905849	COOLANT HOSE ASSY	TATA spare parts
502380905850	COOLANT HOSE ASSY	TATA spare parts
502380905857	HOSE MOTOR TO RADIATOR	TATA spare parts
502380905858	HOSE TRACTION MOTOR OUTLET	TATA spare parts
502380905864	HOSE	TATA spare parts
502380906905	PIPE	TATA spare parts
502380907132	BRACKET COOLING TUBE SUPPORT MTG	TATA spare parts
502380907133	BRACKET COOLING TUBE SUPPORT MTG	TATA spare parts
502380907139	SPACER	TATA spare parts
502380907701	RUBBER PAD	TATA spare parts
502380909903	AUXILLARY TANK ASSY,MOTOR COOLING	TATA spare parts
502380909904	RADIATOR	TATA spare parts
502380909905	SHROUD MOTOR COOLING FAN	TATA spare parts
502380909908	FAN ASSY	TATA spare parts

502380909913	COOLANT PUMP EV	TATA spare parts
502380910102	ASSY RADIATOR WITH FAN ASSY & SHROUD	TATA spare parts
502380910103	TCS STRUCTURE WITH CLAMPS	TATA spare parts
502380910108	TCS STRUCTURE WITH CLAMPS	TATA spare parts
502380913306	BRACKET	TATA spare parts
502380913323	BRACKET	TATA spare parts
502380913328	BRACKET	TATA spare parts
502380913348	BRACKET	TATA spare parts
502380913354	BRACKET	TATA spare parts
502380913355	BRACKET	TATA spare parts
502380913356	BRACKET	TATA spare parts
502380913384	BRACKET	TATA spare parts
502380915801	HOSE TRACTION MOTOR OUTLET	TATA spare parts
502380915802	HOSE RADIATOR AUXILLARY	TATA spare parts
502380915803	HOSE OUTLET MANIFOLD TO PUMP	TATA spare parts
502380915804	HOSE ASSY INVERTER INTAKE	TATA spare parts
502380915805	HOSE ASSY INVERTER INTAKE	TATA spare parts
502380915806	HOSE ASSY INVERTER OUTLET	TATA spare parts
502380915807	HOSE TRACTION MOTOR INTAKE	TATA spare parts
502380915808	HOSE ASSY INVERTER OUTLET	TATA spare parts
502380915809	VENT HOSE MOTOR COOLING	TATA spare parts
502380915810	VENT HOSE MOTOR COOLING	TATA spare parts
502380915811	HOSE	TATA spare parts
502380915812	HOSE	TATA spare parts
502380915814	HOSE	TATA spare parts
502380915815	HOSE	TATA spare parts
502380915816	HOSE	TATA spare parts
502380915817	HOSE	TATA spare parts
502380915818	HOSE	TATA spare parts
502380915819	HOSE	TATA spare parts
502380915820	HOSE	TATA spare parts
502380915821	HOSE	TATA spare parts
502380915822	HOSE	TATA spare parts
502380915823	HOSE	TATA spare parts
502380915824	HOSE	TATA spare parts
502380915825	HOSE	TATA spare parts
502380915826	HOSE	TATA spare parts
502380915827	HOSE	TATA spare parts
502380915828	HOSE	TATA spare parts
502380915857	HOSE	TATA spare parts
502380915858	HOSE	TATA spare parts
502380915859	HOSE	TATA spare parts
502380915860	HOSE	TATA spare parts
502380915861	HOSE	TATA spare parts
502380915862	HOSE	TATA spare parts
502380915866	HOSE	TATA spare parts
502380915867	HOSE	TATA spare parts

502380915869	HOSE	TATA spare parts
502380915870	HOSE	TATA spare parts
502380915871	HOSE	TATA spare parts
502380915872	HOSE	TATA spare parts
502380915873	HOSE	TATA spare parts
502380915874	HOSE	TATA spare parts
502380915875	HOSE	TATA spare parts
502380915876	HOSE	TATA spare parts
502380915877	HOSE	TATA spare parts
502380915878	HOSE	TATA spare parts
502380915879	HOSE	TATA spare parts
502380915893	HOSE	TATA spare parts
502380915894	HOSE	TATA spare parts
502380915897	HOSE	TATA spare parts
502380915899	HOSE	TATA spare parts
502380916903	PIPE	TATA spare parts
502380916905	PIPE EV	TATA spare parts
502380916906	PIPE	TATA spare parts
502380916910	PIPE	TATA spare parts
502380916911	PIPE	TATA spare parts
502380916912	PIPE	TATA spare parts
502380916913	PIPE	TATA spare parts
502380916933	PIPE	TATA spare parts
502380916934	PIPE	TATA spare parts
502380916940	PIPE	TATA spare parts
502380916943	PIPE	TATA spare parts
502380916944	PIPE EV	TATA spare parts
502380916946	PIPE	TATA spare parts
502380916958	PIPE	TATA spare parts
502380916961	PIPE	TATA spare parts
502380925801	HOSE	TATA spare parts
502380925802	HOSE	TATA spare parts
502380990101	KIT CABLE SET HV SIEMENS	TATA spare parts
502383106301	DUCT	TATA spare parts
502383400106	HVAC UNIT ASSY	TATA spare parts
502383400107	EVAPERATOR COIL ASSY	TATA spare parts
502383400109	EVAPERATOR COIL ASSY	TATA spare parts
502383400111	BLOWER	TATA spare parts
502383400112	AC¿UNIT¿ASSY	TATA spare parts
502383400114	BATTERY COOLING UNIT	TATA spare parts
502383400116	BATTERY COOLING UNIT	TATA spare parts
502383400123	BATTERY COOLING UNIT	TATA spare parts
502383400129	BATTERY COOLING SYSTEM	TATA spare parts
502383400137	BATTERY COOLING SYSTEM	TATA spare parts
502383403601	AIR FILTER	TATA spare parts
502383403602	AIR FILTER	TATA spare parts
502383404901	CONTROL PANEL	TATA spare parts

502383404902	INVERTOR	TATA spare parts
502383404903	FAN ASSY	TATA spare parts
502383404904	WIRING HARNESS AC	TATA spare parts
502383404905	WIRING HARNESS	TATA spare parts
502383404906	SENSOR	TATA spare parts
502383404907	CONTROL&PANEL	TATA spare parts
502383404908	CONNECTOR	TATA spare parts
502383404912	AC&CONTROL&SYSTEM	TATA spare parts
502383404913	CONTROL&PANEL&ASSY	TATA spare parts
502383404914	PRESSURE&SWITCH	TATA spare parts
502383404915	MODULE MODE&OPERATION	TATA spare parts
502383404916	THERMO&AMPLIFIER	TATA spare parts
502383404918	PRESSURE&SWITCH	TATA spare parts
502383404919	TERMINALS	TATA spare parts
502383404920	SENSOR	TATA spare parts
502383404921	WIRING HARNESS	TATA spare parts
502383404923	EXPANSION VALVE ASSY EV	TATA spare parts
502383405001	EVAPORATOR&CORE	TATA spare parts
502383405002	EVAPORATOR	TATA spare parts
502383406301	BLOWER&ASSY	TATA spare parts
502383406303	FRESH&AIR&KINEMATIC&LINK	TATA spare parts
502383406305	FAN&COVER	TATA spare parts
502383406306	FAN&ASSY	TATA spare parts
502383406909	TUBE	TATA spare parts
502383408202	AIR&GRILLE	TATA spare parts
502383408203	SUPPORT	TATA spare parts
502383409001	THERMO EXPANSION VALVE	TATA spare parts
502383409002	THERMO EXPANSION VALVE	TATA spare parts
502383409003	EXPANSION&VALVE	TATA spare parts
502383409005	VALVE&ASSY	TATA spare parts
502383409101	RECEIVER&DRIER&ASSY	TATA spare parts
502383409102	FILTER&WITH&FOAM	TATA spare parts
502383409902	INDICATOR	TATA spare parts
502383409903	GRILLE ASSY ROOF AC	TATA spare parts
502383450101	CONDENSER	TATA spare parts
502383455001	CONDENSER	TATA spare parts
502383456301	CONDENSER&FAN	TATA spare parts
502383550101	COMPRESSOR ASSY	TATA spare parts
502383550102	COMPRESSOR&ASSY	TATA spare parts
502383605809	HOSE ASSY	TATA spare parts
502383605810	HOSE ASSY	TATA spare parts
502383605811	HOSE ASSY	TATA spare parts
502383605812	HOSE ASSY OUTLET	TATA spare parts
502383605813	HOSE	TATA spare parts
502383605817	HOSE	TATA spare parts
502383605818	HOSE	TATA spare parts
502383605819	HOSE	TATA spare parts

502383605821	HOSE	TATA spare parts
502383605822	HOSE	TATA spare parts
502383605823	HOSE	TATA spare parts
502383605824	HOSE	TATA spare parts
502383605825	HOSE	TATA spare parts
502383606801	CONNECTOR	TATA spare parts
502383615835	HOSE	TATA spare parts
502383615836	HOSE BATTERY OUTLET TO BCS INLET	TATA spare parts
502383655801	HOSE	TATA spare parts
502383655802	HOSE EV	TATA spare parts
502383655804	HOSE	TATA spare parts
502383655805	HOSE	TATA spare parts
502383656901	CONNECTOR HOSE	TATA spare parts
502383656902	CONNECTOR	TATA spare parts
502383656903	T-CONNECTOR	TATA spare parts
502383750107	BRACKET ASSY	TATA spare parts
502383750109	BRACKET ASSY	TATA spare parts
502383750122	BRACKET ASSY	TATA spare parts
502383750123	BRACKET ASSY	TATA spare parts
502383750124	BRACKET ASSY	TATA spare parts
502383753315	BRACKET	TATA spare parts
502383753318	BRACKET	TATA spare parts
502383753319	BRACKET	TATA spare parts
502383753321	BRACKET	TATA spare parts
502383753324	BRACKET	TATA spare parts
502383753325	BRACKET	TATA spare parts
502383753333	BRACKET	TATA spare parts
502383753346	BRACKET	TATA spare parts
502383753347	BRACKET	TATA spare parts
502383783301	BRACKET	TATA spare parts
502383783302	BRACKET	TATA spare parts
502383783303	BRACKET	TATA spare parts
502391000102	SEAT&BOX&ASSY	TATA spare parts
502398804602	GENERATOR COUPLING TYPE II	TATA spare parts
502399706801	BREATHER HOSE-REAR AXLE	TATA spare parts
50241358000RCK	CABIN KIT FOR 50241358000R	TATA spare parts
502424200102	ASSY. BRACKET LH (ENG.MTG.RR.BOTTOM)	TATA spare parts
502424200102AE	ASSY BRKT LH(E.MTG.R.BTTM)-1628	TATA spare parts
502424200105	ASSY. BRACKET RH (ENG.MTG.RR.BOTTOM)	TATA spare parts
502424200105AE	ASSY BRKT RH(E.MTG.R.BTTM)-1628	TATA spare parts
502426800101	ASSY ANCHOR BRACKET (SELECTION CABLE)	TATA spare parts
502426800108	ASSY GEAR SHIFT KNOB (SINGLE H SHIFT PAT	TATA spare parts
502426800116	ASSY ANCHOR BRACKET FOR SHIFT CABLE	TATA spare parts
502426800118	COVER ASSY.PLATE FOR MAGNETIC VALVE	TATA spare parts
502426806801	ELBOW QUICK FIX FITTING (1/4INCH BSPT X	TATA spare parts
502426806906	PIPE VALVE TO CYL	TATA spare parts
502426806907	PIPE VALVE TO CYL	TATA spare parts

502426806908	PIPE VALVE TO CYL	TATA spare parts
502426806909	PIPE VALVE TO CYL	TATA spare parts
502426808206	COVER PLATE MAGNETIC VALVE FOR RANGE	TATA spare parts
502426808208	COVER PLATE MAGNETIC VALVE FOR LOW LOW	TATA spare parts
502428500101	AGB MTG ASSY BRACKET RH	TATA spare parts
502428500102	AGM MTG ASSY BRACKET ON CHASSIS RH	TATA spare parts
502428500103	AGB MTG ASSY BRACKET LH	TATA spare parts
502428500104	AGB MTG ASSY BRACKET ON CHASSIS LH	TATA spare parts
502428500109	AGB MTG ASSY PLATE RH WITH BEND PLATE RH	TATA spare parts
502428500110	AGB MTG ASSY PLATE WITH BEND PLATE LH	TATA spare parts
502428500111	ASSY BAR(AGB MTG)	TATA spare parts
502428500112	AGB 3RD MTG ASSY BRACKET WITH BEND PLATE	TATA spare parts
502428500114	AGB 3RD MTG ASSY BRACKET WITG BEND PLATE	TATA spare parts
502428500115	ASSY.BKT.COMP.LH (AGB BOTTOM MTG.)	TATA spare parts
502428500117	ASSY.BKT.COMP-RH (AGB BOTTOM MTG.)	TATA spare parts
502428500119	ASSY.BAR AGB MTG.	TATA spare parts
502428506715	PIN(AGB MTG)	TATA spare parts
502429000101	CLUTCH BOOSTER ASSY (TYPE-1)	TATA spare parts
502431000113	FRAME ASSY	TATA spare parts
502431000122	FRAME ASSY	TATA spare parts
502431000123	FRAME ASSY	TATA spare parts
502431000124	FRAME ASSY	TATA spare parts
502431107105	REINFORCEMENT REAR R.H.	TATA spare parts
502431107106	REINFORCEMENT REAR L.H.	TATA spare parts
502431107111	REINFORCEMENT RH (IDLER ARM BRACKET)	TATA spare parts
502431107120	REINFORCEMENT LH	TATA spare parts
502431107121	REINFORCEMENT RH	TATA spare parts
502431107168	REINFORCEMENT FRONT RWD LH	TATA spare parts
502431107169	REINFORCEMENT FRONT RWD RH	TATA spare parts
502431117130	REINFORCEMENT FRONT RWD RH	TATA spare parts
502431117131	REINFORCEMENT FRONT RWD LH	TATA spare parts
502431200101	ASSY. BUMPER CROSS MEMBER	TATA spare parts
502431200101AE	ASSY BUMPR CROSS MMBR COMPL-1628	TATA spare parts
502431200103	ASSY. END CROSS MEMBER COMPLETE	TATA spare parts
502431200110	ASSY.SUPPORT RH(ENG.C/M)	TATA spare parts
502431200111	ASSY. SUPPORT LH(ENG.MTG.C/M)	TATA spare parts
502431200124	CROSS MEMBER ASSY BUMPER	TATA spare parts
502431207108	SUPPORT PLATE (C.M. MIDDLE)	TATA spare parts
502431300104	CROSS MEMBER ASSY BUMPER	TATA spare parts
502431307103	GUSSET UPPER 4TH CROSS MEMBER	TATA spare parts
502431307108	GUSSET UPR 3RD CROSS MEMBER	TATA spare parts
502431307109	GUSSET LWR FOR 3RD CROSS MEMBER	TATA spare parts
502431307110	GUSSET - CTR. UPR. LH	TATA spare parts
502431307111	GUSSET - CTR. UPR. RH	TATA spare parts
502431307116	GUSSET LWR RH 3RD CROSS MEMBER	TATA spare parts
502431307117	GUSSEET UPR - RH 3RD CROSS MEMBER	TATA spare parts
502431307128	GUSSET UPPER L.H. 4TH CROSS MEMBER	TATA spare parts

502431307129	GUSSET UPPER R.H. 4TH CROSS MEMBER	TATA spare parts
502431307130	GUSSET LOWER L.H. 4TH CROSS MEMBER	TATA spare parts
502431307131	GUSSET LOWER R.H. 4TH CROSS MEMBER	TATA spare parts
502431307148	GUSSET UPPER-LH 4TH CROSS MEMBER	TATA spare parts
502431307149	GUSSET UPPER-RH 4TH CROSS MEMBER	TATA spare parts
502431307150	GUSSET LOWER-LH 4TH CROSS MEMBER	TATA spare parts
502431307151	GUSSET LOWER-RH 4TH CROSS MEMBER	TATA spare parts
502431307188	GUSSET PLATE BOTTOM-RH	TATA spare parts
502431307189	GUSSET PLATE BOTTOM-LH	TATA spare parts
502431307190	GUSSET PLATE UPPER-RH	TATA spare parts
502431307191	GUSSET PLATE UPPER-LH	TATA spare parts
502431600127	ASSY. TOOL BOX (WITH SUPPORTS)	TATA spare parts
502431608245	STOPPER BRACKET HYD. JACK MTG.	TATA spare parts
502431707141	SUPPORT BRACKET	TATA spare parts
502432100101	ASSY SPRING (FRT RWD)	TATA spare parts
502432100102	ASSY SPRING (FRT FWD)	TATA spare parts
502432100108	ASSY CLAMP PLATE-U BOLT	TATA spare parts
502432100113	BRACKET ASSY SPRING HANGER FRONT-LH	TATA spare parts
502432100114	BRACKET ASSY SPRING HANGER FRONT-RH	TATA spare parts
502432100115	SPRING HANGER BKT FRONT ASSY (RWD)	TATA spare parts
502432100118	BRACKET ASSY BUMP STOPPER FRT FWD	TATA spare parts
502432100127	BELL CRANK LEVER ASSY FRONT FWD-LH	TATA spare parts
502432100128	BELL CRANK LEVER ASSY FRONT FWD-RH	TATA spare parts
502432100132	BELL CRANK LEVER ASSY FRONT RWD-LH	TATA spare parts
502432100133	BELL CRANK LEVER ASSY FRONT RWD-RH	TATA spare parts
502432100144	LINK ROD ASSY FRONT	TATA spare parts
502432100166	1ST LEAF ASSY WITH BUSH	TATA spare parts
502432100167	PARABOLIC LEAF SPRING ASSY FRONT FWD	TATA spare parts
502432100169	BRACKET BUMP STOPPER ASSY REAR	TATA spare parts
502432100170	1ST LEAF ASSY WITH BUSH	TATA spare parts
502432100171	PARABOLIC LEAF SPRING ASSY FRONT RWD	TATA spare parts
502432103201	CENTER BOLT M16X1.5X105	TATA spare parts
502432103210	CENTER BOLT	TATA spare parts
502432103305	SPRING HANGER BRACKET (FRONT FWD)	TATA spare parts
502432103306	SPRING HANGER BKT FRONT (FWD)	TATA spare parts
502432106505	HEX FL NUT SELF LOCKING M16X2	TATA spare parts
502432107127	2ND LEAF	TATA spare parts
502432107128	3RD LEAF	TATA spare parts
502432107129	4TH LEAF	TATA spare parts
502432107136	2ND LEAF	TATA spare parts
502432107137	3RD LEAF	TATA spare parts
502432107138	4TH LEAF	TATA spare parts
502432204201	U-BOLT	TATA spare parts
502432204202	U-BOLT	TATA spare parts
502432300101	ASSY BRACKET-LH (S/A-UPPER)	TATA spare parts
502432300102	ASSY BRACKET-RH (S/A-UPPER)	TATA spare parts
502432300104	ASSY SHOCK ABSORBER BRKT FRT RWD UPPER-L	TATA spare parts

502432300106	ASSY SHOCK ABSORBER BRKT FRT RWD UPPER-R	TATA spare parts
502432300107	S/A BOTTOM BRACKET ASSY FRONT LH	TATA spare parts
502432300108	S/A BOTTOM BRACKET ASSY FRONT RH	TATA spare parts
502432300109	BRACKET ASSY SHOCK ABSORBER UPPER LH FWD	TATA spare parts
502432300110	BRACKET ASSY SHOCK ABSORBER UPPER RH FWD	TATA spare parts
502432300115	BRACKET ASSY FRONT SHOCK ABSORBER MTG LH	TATA spare parts
502432300116	BRACKET ASSY FRONT SHOCK ABSORBER MTG RH	TATA spare parts
502432303201	HEX BOLT	TATA spare parts
502432400102	ASSY SPRING REAR	TATA spare parts
502432400103	LEAF SPRING ASSY WITH TRUNNION HSG	TATA spare parts
502432400105	ASSY. TORQUE ROD	TATA spare parts
502432400106	ASSY. TUBE-EYE (TORQUE ROD)	TATA spare parts
502432400110	ASSY FIFTH LEAF WITH CLIP	TATA spare parts
502432400122	ASSY TANDEM BOGIE SUSPENSION	TATA spare parts
502432400124	ASSLY-V ROD	TATA spare parts
502432400139	REAR SPRING ASSY	TATA spare parts
502432400140	TORQUE ROD ASSY	TATA spare parts
502432403202	BOLT( FOR SPRING CLAMP)	TATA spare parts
502432403302	BRACKET -RH (TORQUE ROD)	TATA spare parts
502432403303	BRACKET -LH (TORQUE ROD)	TATA spare parts
502432403305	CORNER BRACKET(RF-RH RR-LH)	TATA spare parts
502432403306	CORNER BRACKET(RF-LH RR-RH)	TATA spare parts
502432403307	CORNER BRACKET	TATA spare parts
502432403701	SPACER (B/W BOLSTER AND REAR FWD AXLE)	TATA spare parts
502432403704	SPACER (B/W REAR RWD AXLE AND BOLSTER)	TATA spare parts
502432404201	CLAMP	TATA spare parts
502432405105	GUIDE PLATE-FRONT	TATA spare parts
502432407101	FORTH LEAF	TATA spare parts
502432407102	FIFTH LEAF	TATA spare parts
502432407103	SIXTH LEAF	TATA spare parts
502432407104	SEVENTH LEAF	TATA spare parts
502432407106	1ST LEAF	TATA spare parts
502432407107	2ND LEAF	TATA spare parts
502432407108	3RD LEAF	TATA spare parts
502432407109	4TH LEAF	TATA spare parts
502432407110	ARTICULATION STOPPER SPACER	TATA spare parts
502432407112	THIRD LEAF	TATA spare parts
502432407114	5TH LEAF	TATA spare parts
502432407115	6TH LEAF	TATA spare parts
502432407127	7TH LEAF	TATA spare parts
502432407128	1ST LEAF	TATA spare parts
502432407129	2ND LEAF	TATA spare parts
502432408601	SLEEVE	TATA spare parts
502432603302	S/A TOP MTG BKT	TATA spare parts
502440100102	ASSY WHEEL RIM 11.25-21	TATA spare parts
502440100103	ASSY. TUBE 15.00-21	TATA spare parts
502440100107	WHEEL RIM ASSY WITH VALVE	TATA spare parts



502440100113	WHEEL RIM ASSY WITH VALVE	TATA spare parts
502440106301	TYRE (15.00-21 APOLLO 16PR)	TATA spare parts
502440106302	FLAP	TATA spare parts
502440109906	TUBELESS TYRE	TATA spare parts
502440300109	ASSY BRACKET SPARE WHEEL SUPPORT SPARE W	TATA spare parts
502440300164	ASSY RUBBER SUPPORT	TATA spare parts
502440300171	ASSY DC VALVE	TATA spare parts
502440300177	ASSY HYDRAULIC CYL (FOR SPARE WHEEL)	TATA spare parts
502440300177AE	ASSY HYD CYLINDER 1628	TATA spare parts
502440300245	ASSY.SUPPORT BKT. (SP.WH.LIFTING UNIT)	TATA spare parts
502440300251	KIT SWC ACTUATION UNIT	TATA spare parts
502440303202	U-BOLT	TATA spare parts
502440303203	HEX SCR M22X1.5X110 IS13725 8.8 SS8451-8	TATA spare parts
502440303405	CIRCULAR PIN (FOR SPARE WHEEL LIFTING LE	TATA spare parts
502440306718	PIN PULLEY	TATA spare parts
502440307501	BALATA PACKING	TATA spare parts
502440307503	BALATA PACKING -	TATA spare parts
502440307505	BALATA PACKING -	TATA spare parts
502440307507	BALATA PACKING -	TATA spare parts
502440308201	CLAMPING PLATE	TATA spare parts
502440309204	BRIGHT WASHER 21	TATA spare parts
502440309205	BRIGHT WASHER 21	TATA spare parts
502440309903	PACKING (FOR U BOLT)	TATA spare parts
502440310216	SPARE WHEEL ACTUATION UNIT ASSY	TATA spare parts
502440318212	BRACKET (FOR ROPE GUIDE)	TATA spare parts
502440806803	1/4IN BSP BOTH END ADAPTOR	TATA spare parts
502440806804	3/8IN X 1/4IN BSP CONNECTOR	TATA spare parts
502440900103	KIT FOR SP.WHEEL MTG. STR. 15-21 TYRE	TATA spare parts
502441000101	ASSLY PROP. SHAFT GEARBOX TO TC	TATA spare parts
502441000102	ASSLY PROP.SHAFT TC TO 1ST REAR AXLE	TATA spare parts
502441000103	ASSLY PROP. SHAFT 1ST REAR TO 2ND REAR	TATA spare parts
502441000103AE	PROP SHAFT 1ST RA TO 2ND RA 1828	TATA spare parts
502441000104	ASSLY PROP. SHAFT TC TO 2ND FRONT	TATA spare parts
502441000105	ASSLY PROP. SHAFT 1ST FRONT TO 2ND FRONT	TATA spare parts
502441000108	PROPELLER SHAFT ASSY TC TO REAR FWD AXLE	TATA spare parts
502441000118	1ST PROPELLER SHAFT ASSY	TATA spare parts
502441000119	3RD PROPELLER SHAFT ASSY	TATA spare parts
502441000120	2ND PROPELLER SHAFT	TATA spare parts
502441109902	UNIT PACK	TATA spare parts
502441109905	FLANGE YOKE	TATA spare parts
502441109906	YOKE SHAFT ASSY	TATA spare parts
502441109910	YOKE SHAFT ASSY	TATA spare parts
502441109912	FLANGE YOKE	TATA spare parts
502441109913	YOKE SHAFT ASSY	TATA spare parts
502441109916	UNIT PACK (2060 SERIES110 SLIP)	TATA spare parts
502441109921	UNIT PACK	TATA spare parts
502441109922	FLANGE YOKE	TATA spare parts

502441109923	UNIT PACK	TATA spare parts
502441125101	FLANGE YOKE	TATA spare parts
502441995101	FLANGE YOKE	TATA spare parts
502442100125	ASSY.SPRING BRAKE ACTUATOR TYPE30/30-RH	TATA spare parts
502442100127	AUTO SLACK ADJUSTER 160CD 16 OFFSET RH B	TATA spare parts
502442100128	AUTO SLACK ADJUSTER 160CD 16 OFFSET LH B	TATA spare parts
502442100129	ASSY. BRACKET-RH (ACTUATOR MTG. BRACKET)	TATA spare parts
502442100129AE	ASY BRKT-R(ACTUTR MTG BRKT)-1628	TATA spare parts
502442100130	ASSY. BRACKET-LH (ACTUATOR MTG.)	TATA spare parts
502442100130AE	ASSY.BRKT-LH (ACTUATOR MTG)-1628	TATA spare parts
502442100135	ASSY. SPRING BRAKE ACTUATOR TYPE 24/24	TATA spare parts
502442100136	ASSY SBA TY 30/30	TATA spare parts
502442100157	SPRING BRAKE ACTUATOR ASSY - LH	TATA spare parts
502442100158	SPRING BRAKE ACTUATOR ASSY - RH	TATA spare parts
502442100159	"BRACKET ASSY,ACTUATOR MTG,RH BS6"	TATA spare parts
502442100160	"BRACKET ASSY,ACTUATOR MTG,LH BS6"	TATA spare parts
502442100163	DRUM BRAKE ASSY WITH DC FRONT-LH --	TATA spare parts
502442100164	DRUM BRAKE ASSY WITH DC FRONT-RH --	TATA spare parts
502442108204	ANCHOR BRACKET RH (AUTO. SLACK ADJUSTER)	TATA spare parts
502442108205	ANCHOR BRACKET LH (AUTO. SLACK ADJUSTER)	TATA spare parts
502442108216	ANCHOR BKT,AUTO SLACK ADJ SUPPORT,RH BS	TATA spare parts
502442108217	ANCHOR BKT,AUTO SLACK ADJ SUPPORT,LH BS	TATA spare parts
502442108301	SHIM PLUMMER BLOCK (1)	TATA spare parts
502442108302	SHIM PLUMMER BLOCK (0.5)	TATA spare parts
502442108303	SHIM PLUMMER BLOCK (0.2)	TATA spare parts
502442108304	SHIM PLUMMER BLOCK (0.1)	TATA spare parts
502442303701	BRACKET BRAKE CHAMBER MTG LH --	TATA spare parts
502442303702	BRACKET BRAKE CHAMBER MTG RH	TATA spare parts
502443200103	ASSY. BRACKET (AIR TANK MTG.)	TATA spare parts
502443200117	AIR TANK ASSY	TATA spare parts
502443700105	ASSY. BRACKET (ANTI COMPOUNDING VLV. MTG)	TATA spare parts
502443700106	ASSY. BRACKET (ASR/DCV MTG.)	TATA spare parts
502443700110	ASSY. BRACKET (HAND BRAKE VALVE MTG.)	TATA spare parts
502443700110AE	ASSY. BRACKET (HBV MTG.) 1628	TATA spare parts
502443700112	BRACKET ASSY.RH (MODULATOR VALVE MTG.)	TATA spare parts
502443700113	BRACKET ASSY.LH MODULATOR VALVE MTG.	TATA spare parts
502443700114	ASSY. BRACKET (PALM COUPLING MTG.)	TATA spare parts
502443700115	ASSY. BRACKET-PALM COUPLING MTG	TATA spare parts
502443700116	ASSY. BRACKET-APU MTG.	TATA spare parts
502443703305	BRACKET LH-DOUBLE CHECK VALVE MTG.	TATA spare parts
502443703306	BRACKET-DOUBLE CHECK VALVE MTG	TATA spare parts
502443703309	BRACKET RH-DOUBLE CHECK VALVE MTG.	TATA spare parts
502443708203	BRACKET (ANTI COMPOUNDING VLV. MTG.)	TATA spare parts
502443708206	BRACKET-RELAY VALVE MTG	TATA spare parts
502443900102	ASSY. METAL PIPE WITH CRIMPED HOSE	TATA spare parts
502443900172	AIR BRAKE COIL HOSE WITH RED ANTI-KINK	TATA spare parts
502443900173	AIR BRAKE COIL HOSE	TATA spare parts

502443903301	BRACKET-HOSE MTG.	TATA spare parts
502443903302	BRACKET (HOSE MTG.) BS6	TATA spare parts
502443903310	BRACKET BS6	TATA spare parts
502443906801	COUPLING BODY (COMPRESSOR OUTLET PORT)	TATA spare parts
502443906803	TEE CONNECTOR M22XM18XM16	TATA spare parts
502443906805	TEE-MODULATOR OUTLET M22XM22XM16	TATA spare parts
502443907101	BRACKET	TATA spare parts
502443907102	BRACKET (FOR HOSE MTG.)	TATA spare parts
502443908201	BRACKET -LH HOSE MTG.	TATA spare parts
502443908202	BRACKET - RH HOSE MTG.	TATA spare parts
502443908203	BRACKET-RH (HOSE MTG.)	TATA spare parts
502443908204	BRACKET-LH (HOSE MTG.)	TATA spare parts
502443908601	SPACER-30X15X4THK.	TATA spare parts
502443930102	PIPE ASSY SECOND COMPRESSOR TO APU	TATA spare parts
502443930106	BUNCH ASSY PIPE	TATA spare parts
502443960103	PIPE ASSY THIRD COMPRESSOR TO APU	TATA spare parts
502443960106	PIPE ASSY SET COMPLETE FOR HMV REAR MTG	TATA spare parts
502443980101	PIPE ASSY	TATA spare parts
502443990147	PIPE BUNCH ASSY	TATA spare parts
502443990177	PIPE BUNCH ASSY	TATA spare parts
502443990179	PIPE ASSY	TATA spare parts
502445100147	ASSY HOSE (ST-ELBOW)	TATA spare parts
502445100148	ASSY HOSE(ELBOW-ELBOW)	TATA spare parts
502445100150	ASSY 1/4 IN PNEUMATIC HOSE (ELBOW/ST)	TATA spare parts
502445100151	ASSY 3/16 PNEUMATIC HOSE (ELBOW/ST)	TATA spare parts
502445100152	ASSY 1/4 IN PNEUMATIC HOSE (ELBOW/ELBOW)	TATA spare parts
502445100153	ASSY 3/16 PNEUMATIC HOSE (ELBOW/ELBOW)	TATA spare parts
502445100164	ASSY.PIPE BREATHER FILTER TO HUB DIFFERE	TATA spare parts
502445100171	ASSY 3/16 PNEUMATIC HOSE (ELBOW/STRAIGHT)	TATA spare parts
502445100172	ASSY 1/4 IN PNEUMATIC HOSE	TATA spare parts
502445110113	NYLON PIPE BUNCH PNEUMATIC SYSTEM	TATA spare parts
502445110163	NYLON PIPE BUNCH PNEUMATIC SYSTEM	TATA spare parts
502445300132	BRACKET KB VALVE	TATA spare parts
502445300133	BRACKET VALVE	TATA spare parts
502445300137	ASSY. CTIS VALVE WITH PLATE & SPACER	TATA spare parts
502445300142	CENTRAL TYRE INFLATION SYSTEM KIT 8X8	TATA spare parts
502445300152	BRACKET ASSY CTIS PCU MTG	TATA spare parts
502445300167	ASSY MOUNTING BRACKET (CTIS)	TATA spare parts
502445300175	ASSY. MTG BRACKET (PCU-CTIS)	TATA spare parts
502445300182	PIPE ASSY STG COLUMN & CLUTCH BOOSTER	TATA spare parts
502445303311	MTG. BRACKET (BREATHER)	TATA spare parts
502445306807	MALE CONNECTOR (PTO)	TATA spare parts
502445306808	MALE CONNECTOR	TATA spare parts
502445306810	CONNECTOR (AIR BREATHER)	TATA spare parts
502445306811	CONNECTOR (AIR BREATHER)	TATA spare parts
502445307162	WINCH CONTROL (PTO)	TATA spare parts
502445307168	MTG. BRKT (AIR HORN)	TATA spare parts

502445307169	KB SOLENOID VALVE	TATA spare parts
502445307172	OCP UNIT (8X8)	TATA spare parts
502445307173	PCU UNIT FOR CTIS 8X8	TATA spare parts
502445307176	MALE CONNECTOR	TATA spare parts
502445307177	FLEXIBLE TUBING FROM AXLE TO CTIS VALVE	TATA spare parts
502445307178	FLEXIBLE TUBING FROM CTIS VALVE TO TYRE	TATA spare parts
502445307191	MTG BKT (PRV)	TATA spare parts
502445307195	MOUNTING BRACKET (PRESSURE PROTECTION VALVE)	TATA spare parts
502445309903	EXHAUST HOSE (CTIS)	TATA spare parts
502445907101	BRACKET ( HOSE MTG)	TATA spare parts
502445907102	BRACKET REMOTE BREATHER MTG.	TATA spare parts
502445907103	MTG. BRACKET (PRESSURE REDUCTION VALVE)	TATA spare parts
502445907105	BRACKET (FOR HOSE MTG.)	TATA spare parts
502445907106	BRACKET (FOR HOSE MTG.)	TATA spare parts
502445990101	KIT FOR CTIS PIPES & CONNECTORS	TATA spare parts
502445990102	KIT OF PIPES & CONNECTORS FOR PTO	TATA spare parts
502445990103	KIT FOR HOSES AND CONNECTORS	TATA spare parts
502445990104	KIT-HOSES & CONNECTORS (SOLENOID & DIFF)	TATA spare parts
502445990113	KIT-HOSES & CONNECTORS BREATHERS	TATA spare parts
502446100101	STEERING GEAR BOX (DUAL CIRCUIT)	TATA spare parts
502446200103	STEERING INTERMEDIATE SHAFT	TATA spare parts
502446200103AE	STEERING INTERMEDIATE SFT -1628	TATA spare parts
502446204201	PLATE FOR RUBBER BELLOW	TATA spare parts
502446300111	DRAG LINK 1 (FROM PITMAN ARM BTM. TO FRT)	TATA spare parts
502446300111AE	DRAG LINK 1 -1628-1828	TATA spare parts
502446300112	RELAY ROD 1 (FROM PITMAN ARM TOP TO IDL)	TATA spare parts
502446300113	RELAY ROD 2 (FROM IDLER ARM BTM. TO RELAY)	TATA spare parts
502446300114	DRAG LINK 2 (FROM RELAY ARM TO FRT 2)	TATA spare parts
502446300115	ASSY.TIE ROD (FRT.FWD.AXLE)	TATA spare parts
502446300116	ASSY.TIE ROD (FRT.RWD.AXLE)	TATA spare parts
502446300131	ASSY TIE ROD ARM-LH	TATA spare parts
502446300132	ASSY TIE ROD ARM-RH	TATA spare parts
502446300141	DRAG LINK 1 (FROM PITMAN ARM BTM. TO FRT)	TATA spare parts
502446300142	DRAG LINK ASSY - 2	TATA spare parts
502446300143	RELAY ROD ASSY - 2	TATA spare parts
502446300146	DRAG LINK END ASSY RH	TATA spare parts
502446300147	DRAG LINK END ASSY LH	TATA spare parts
502446304102	IDLER ARM	TATA spare parts
502446304104	TIE ROD MOUNTING ARM LH (FRONT FORWARD)	TATA spare parts
502446304104AE	TIE ROD MNTNG ARM LH-1628-1828	TATA spare parts
502446304105	TIE ROD MOUNTING ARM-RH (FRONT FORWARD)	TATA spare parts
502446304106	TIE ROD MOUNTING ARM-LH (FRONT REARWARD)	TATA spare parts
502446304107	TIE ROD MOUNTING ARM-RH (FRONT REARWARD)	TATA spare parts
502446304109	STEERING ARM TOP	TATA spare parts
502446304115	PITMAN ARM	TATA spare parts
502446304116	RELAY ARM	TATA spare parts
502446304117	STEERING ARM TOP	TATA spare parts

502446304118	STEERING ARM TOP (LHD)	TATA spare parts
502446305101	PITMAN ARM	TATA spare parts
502446306901	TIEROD-SOLID(FRONTRWDAXLE)	TATA spare parts
502446306902	CASTLENUTM24X1.5	TATA spare parts
502446306903	CLAMP	TATA spare parts
502446306904	HEXBOLTM12X1.75X75LIS 1364	TATA spare parts
502446306905	HEXNUTM12X1.75IS 1364	TATA spare parts
502446306906	SPLITPIN	TATA spare parts
502446308301	SHIM STEERING LOCK	TATA spare parts
502446308601	SPACER STEERING LOCK	TATA spare parts
502446600118	STEERING GEAR BOX	TATA spare parts
502446600119	POWER STEERING PUMP	TATA spare parts
502446600120	BRACKET VALVE BLOCK ASSY	TATA spare parts
502446600130	STEERING GEAR BOX ASSY	TATA spare parts
502446600131	VALVE BLOCK	TATA spare parts
502446603301	BEND PLATE OIL COOLER MTG RH	TATA spare parts
502446603302	BEND PLATE OIL COOLER MTG LH	TATA spare parts
502446603305	OIL TANK MTG. BRACKET	TATA spare parts
502446603401	BEARING BUSH	TATA spare parts
502446607807	SHAFT SEAL	TATA spare parts
502446609002	VALVE BLOCK	TATA spare parts
502446703301	STEERING GEAR BOX MTG. BKT	TATA spare parts
502446703303	L BRACKET	TATA spare parts
502446703304	Z BRACKET	TATA spare parts
502446703310	BKT- IDLER ARM MTG	TATA spare parts
502446703316	BRACKET (STEERING GEAR BOX MTG.)	TATA spare parts
502446705101	IDLER ARM	TATA spare parts
502446707701	O-RING	TATA spare parts
502446709201	LOCK WASHER	TATA spare parts
502446800110	LINE FOR TANK 1 TO TANK 2	TATA spare parts
502446800120	M33X2-M26X1.5 MALE ADAPTER	TATA spare parts
502446800128	ELBOW BODY K	TATA spare parts
502446800129	FLEXIBLE HOSE FOR HYDRO.TANK	TATA spare parts
502446800130	FLEXIBLE RUBBER HOSE	TATA spare parts
502446800202	COUPLING BODY ASSY WITH O-RING	TATA spare parts
502446800291	PRESSURE LINE ASSY	TATA spare parts
502446803301	BRACKET MTG STG PIPE BS6	TATA spare parts
502446803302	MTG.¿BRACKET¿(STEERING¿PIPE)	TATA spare parts
502446805894	HOSE	TATA spare parts
502446806902	O-RING 33.5X2.65 IS 9975 P1	TATA spare parts
502446900122	DRAG LINK ASSY FRONT	TATA spare parts
502446900123	RELAY ROD ASSY	TATA spare parts
502446900125	DRAG LINK END ASSY BS6-PH2	TATA spare parts
502446904201	PIPE CLAMP TYPE 8 -18X18	TATA spare parts
502446990118	KIT-HYD STEERING PIPE	TATA spare parts
502446990129	KIT-PIPE	TATA spare parts
502447100101	DIPSTICK ASSY	TATA spare parts

502447100102	DIPSTICK ASSY	TATA spare parts
502447100111	FUEL TANK ASSY WITH BAFFLES (400 LITRE)	TATA spare parts
502447100112	ASSY FUL TANK COMPLETE (400 LTR RECT)	TATA spare parts
502447100112AE	ASSY FUEL TANK COMP(400 L.)-1628	TATA spare parts
502447209901	WEMA SENDOR WITHOUT HEATER PORT	TATA spare parts
502447209902	WEMA SENDOR WITH HEATER PORT	TATA spare parts
502447209902AE	WEMA SENDOR W/HEATER PORT -1628	TATA spare parts
502447500101	ASSY.SUPPORT(RECT.FUEL TANK 400LTRS.)	TATA spare parts
502447500103	BRKT-FUEL TANK MTG.	TATA spare parts
502447500104	ASSY.WEBASTO HEATER MTG. BKT. 1	TATA spare parts
502447500105	ASSY.WEBASTO HEATER MTG.BKT.2	TATA spare parts
502447500106	BRACKET ASSY FUEL TANK MTG	TATA spare parts
502447507701	RUBBER PACKING	TATA spare parts
502447507701AE	RUBBER PACKING 1628	TATA spare parts
502447600101	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
502447600102	SUCTION LINE ASSY FUEL FILTER TO ENGINE	TATA spare parts
502447600103	RETURN LINE ASSY ENGINE TO FUEL TANK	TATA spare parts
502447600132	FUEL SUCTION LINE ASSY (FILTER TO ENG)	TATA spare parts
502447600133	FUEL SUCTION LINE ASSY FT TO HEATER	TATA spare parts
502447600134	FUEL RETURN LINE ASSY HEATER TO FT	TATA spare parts
502447600135	FUEL RETURN LINE ASSY ENG TO FUEL TANK	TATA spare parts
502447600136	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
502447600156	FUEL SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
502447600157	FUEL PIPE ASSY SUCTION FUEL FTR TO ENG	TATA spare parts
502447600158	FUEL RETURN PIPE ASSY FIP TO FUEL TANK	TATA spare parts
502449100104	ASSY FLEX CONNECTOR	TATA spare parts
502449100105	EXHAUST MUFFLER	TATA spare parts
502449100107	ASSY.SUPPORT BRACKET FOR SILENCER MTG.	TATA spare parts
502449100116	KIT-EXHAUST PIPE HEAT SHIELD ASSY	TATA spare parts
502449109975	HEAT SHIELD ASSY SILENCER REAR	TATA spare parts
502449109976	HEAT SHIELD ASSY SILENCER FRONT	TATA spare parts
502449200105	FRONT PIPE ASSY	TATA spare parts
502449200106	ASSY THIRD PIPE (FOR EXHAUST SYSTEM)	TATA spare parts
502449200107	ASSY. SUPPORT EXHAUST PIPE INTERMEDIATE	TATA spare parts
502449200118	ASSY. SECOND PIPE (FOR EXHAUST SYSTEM)	TATA spare parts
502449200122	EXHAUST TAIL PIPE ASSY	TATA spare parts
502449200123	SUPPORT ASSY EXHAUST PIPE	TATA spare parts
502449200124	PIPE ASSY MIDDLE	TATA spare parts
502449200132	PIPE ASSY MAIN SILENCER INTAKE	TATA spare parts
502449200133	EXHAUST PIPE ASSY REAR	TATA spare parts
502449200134	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
502449200135	ASSY EXHAUST TAIL PIPE	TATA spare parts
502449200145	BRACKET ASSY EXHAUST PIPE SUPPORT	TATA spare parts
502449200146	BRACKET ASSY EXHAUST MTG	TATA spare parts
502449200148	TAIL PIPE ASSY	TATA spare parts
502449200152	BRACKET ASSY EXHAUST PIPE MTG	TATA spare parts
502449200153	EXHAUST PIPE ASSY MIDDLE FRONT	TATA spare parts

502449207134	BRACKET TAIL PIPE CLAMP	TATA spare parts
502449990106	KIT FOR EXHAUST SHIELD	TATA spare parts
502449990112	KIT-HEAT SHIELD FOR SILENCER & EXH PIPE	TATA spare parts
502449990113	KIT-HEAT SHIELD FOR SILENCER & EXH PI	TATA spare parts
502449990114	HEAT SHIELD ASSY	TATA spare parts
502449990115	HEAT SHIELD ASSY	TATA spare parts
502452200101	ASSY. REAR FRONT FENDER MTG. LH	TATA spare parts
502452200102	ASSY REAR REAR FENDER MTG. LH	TATA spare parts
502452200103	ASSY REAR REAR FENDER MTG. RH	TATA spare parts
502452206301	REAR FENDER FRONT-RH	TATA spare parts
502454100157	BATT CARRIER STRUCTURE	TATA spare parts
502454110101	ASSY.BATTERY CABLE -VE (CUTOFF SW TO SM	TATA spare parts
502454150101	ASSY BATTREY CABLE POSITIVE-CUTOFF TO ST	TATA spare parts
502454200102	ASSY TWIN HORN MTG BKT	TATA spare parts
502454201602	WARN INDICATOR	TATA spare parts
502454209901	AIR PR. TRANSDUCER (M16 & 0-12BAR)	TATA spare parts
502454209901AE	AIR PR. TRANSDUCER(0-12BAR)-1628	TATA spare parts
502454400101	ASSY HEAD LAMP MTG. BKT.RH	TATA spare parts
502454400101AE	ASSY HEAD LAMP MTG. BKT. 1628	TATA spare parts
502454400102	ASSY HEAD LAMP MTG BKT.LH	TATA spare parts
502454400102AE	ASSY HEAD LAMP MTG BKT.LH 1628	TATA spare parts
502454400104	ASSY TAIL LAMP BRACKET (RH)	TATA spare parts
502454400104AE	ASSY TAIL LAMP BRKT (RH) -1628	TATA spare parts
502454400105	TAIL LAMP BRACKET LH	TATA spare parts
502454400105AE	TAIL LAMP BRACKET LH 1628	TATA spare parts
502454400117	ASSY TOW HOOK LAMP MOUNTING BRACKET	TATA spare parts
502454400122	ASSY LAMP GUARD	TATA spare parts
502454400124	ASSY BASE (WORK AREA LAMP)	TATA spare parts
502454400128	WARN INDICATOR COOLANT LEV & WINCH ROPE	TATA spare parts
502454400149	BRACKET ASSY	TATA spare parts
502454400150	GRILL FRAME	TATA spare parts
502454401602	WARNING IND.DANDA MAN & WINCH ROPE	TATA spare parts
502454401602AE	WARNING IND.& WINCH ROPE -1628	TATA spare parts
502454401603	WARNING IND.-HIGH RANGE & LOW RANGE	TATA spare parts
502454401604	WARN IND-DEEP RANGE &POWER STEERING FAIL	TATA spare parts
502454401607	WARN IND-TRANSMISSION FAULT & LOW RANGE	TATA spare parts
502454408201	CONVEY LAMP BRACKET	TATA spare parts
502454408201AE	CONVEY LAMP BRACKET 1628	TATA spare parts
502454408208	LOAD AREA LAMP BRACKET	TATA spare parts
502454420101	BLACKOUT HEADLAMP	TATA spare parts
502454440101	ASSY.HEAD LAMP LH 24V AUTOLITE LPTA3138	TATA spare parts
502454440102	ASSY.HEAD LAMP RH 24V AUTOLITE LPTA3138	TATA spare parts
502454440103	ASSY.LOAD AREA LAMP 24V	TATA spare parts
502454440105	ASSY.LOAD AREA LAMP 24V	TATA spare parts
502454440106	TOW HOOK AR. LAMP 24V	TATA spare parts
502454440109	REVOLVING LAMP ASSY	TATA spare parts
502454440125	BLACKOUT CONVOY LAMP	TATA spare parts

502454440126	STOP & PARK BLACKOUT LAMP	TATA spare parts
502454480101	MAP READING LAMP ASSY	TATA spare parts
502454504904	INDICATOR SWITCH HIGH-LOW SHIFTING	TATA spare parts
502454504905	INDICATOR SWITCH DIFFLOCK SHIFTING	TATA spare parts
502454506301	PIANO SW (ABS SW)	TATA spare parts
502454506302	PIANO SW (TRANSMISSION NEUTRAL HIGH LOW)	TATA spare parts
502454506303	PIANO SW(REMOTE THROTTLE SW)	TATA spare parts
502454506304	PIANO SW(PTO SW)	TATA spare parts
502454506305	PIANO SW(DIFFERENTIAL LOCK INTERAXLE SW)	TATA spare parts
502454506306	PIANO SW(DIFFERENTIAL LOCK INTERWHEEL SW)	TATA spare parts
502454506307	PIANO SW(STEER ADJUST SW)	TATA spare parts
502454506308	PIANO SW(FRONT FOG LAMP SW)	TATA spare parts
502454506308AE	PIANO SW(FRONT FOG LAMP SW)-1628	TATA spare parts
502454506309	PIANO SW(REAR FOG LAMP SW)	TATA spare parts
502454506310	PIANO SW(LOAD AREA LAMP SW)	TATA spare parts
502454506310AE	PIANO SW(LOAD AREA LAMP SW)-1628	TATA spare parts
502454506311	PIANO SW(BEACON LAMP SW)	TATA spare parts
502454506312	PIANO SW(HAZARD WARNING SW)	TATA spare parts
502454506313	PIANO SW(MIRROR HEATER SW)	TATA spare parts
502454506314	PIANO SW (WIND WINCH UNWIND SW)	TATA spare parts
502454506315	PIANO SW (EMS DIAGNOSTIC SW)	TATA spare parts
502454506315AE	PIANO SW (EMS DIAGNO SW) -1628	TATA spare parts
502454506316	PIANO SW ( BATTERY CUT OFF ON OFF SW)	TATA spare parts
502454506318	PIANO SW (6X6 SWITCH)	TATA spare parts
502454506320	PIANO SWITCH (DUMMY)	TATA spare parts
502454506321	PIANO SW (ABS ON/OFF)	TATA spare parts
502454506324	PIANO SWITCH PTO CRANE-OFF-PTO WINCH	TATA spare parts
502454509901	PIANO KEY SWIRCH(AIR PRESSURE HORN)	TATA spare parts
502454509902	PIANO KEY SW.(ELEVATED HEAD LAMP)	TATA spare parts
502454509906	BATTERY CUT OFF SWITCH	TATA spare parts
502454509907	INDICATOR SWITCH (HIGH-LOW SHIFTING)NO C	TATA spare parts
502454509908	INDICATOR SWITCH (DIFFLOCK SHIFTING)NC C	TATA spare parts
502454509909	PIANO KEY SW(AIR PRESSURE HORN)	TATA spare parts
502454509910	PIANO KEY SW.(ELEVATED HEAD LAMP)	TATA spare parts
502454509911	PIANO KEY SW.(BEACON LAMP)	TATA spare parts
502454509912	PIANO KEY SW.(LOAD AREA LAMP)	TATA spare parts
502454600101	ASSY FUSEBOX MOUNTING BRACKET	TATA spare parts
502454600102	ASSY FUSEBOX MOUNTING BRACKET II	TATA spare parts
502454600103	ABS FRAME WIRING HARNESS LPTA3138 8X8	TATA spare parts
502454600136	WIRING HARNESS TAIL	TATA spare parts
502454600138	WIRING HARNESS ENGINE	TATA spare parts
502454600141	WIRING HARNESS ABS FRAME	TATA spare parts
502454600142	WIRING HARNESS BUMPER	TATA spare parts
502454600143	WIRING HARNESS MAIN	TATA spare parts
502454600147	WIRING HARNESS TAIL	TATA spare parts
502454600148	WIRING HARNESS MAIN	TATA spare parts
502454600149	WIRING HARNESS ROOF	TATA spare parts



502454600151	WIRING HARNESS TAIL	TATA spare parts
502454600152	WIRING HARNESS MAIN	TATA spare parts
502454600155	WIRING HARNESS ENGINE	TATA spare parts
502454600156	BATTERY CABLE +VE CUT OFF SW TO SM	TATA spare parts
502454600157	BATTERY CABLE -VE CUT OFF SW TO SM	TATA spare parts
502454600158	WIRING HARNESS ROOF	TATA spare parts
502454600159	WIRING HARNESS ENGINE	TATA spare parts
502454600160	WIRING HARNESS MAIN	TATA spare parts
502454600171	WIRING HARNESS ENGINE	TATA spare parts
502454600173	WIRING HARNESS MAIN	TATA spare parts
502454600177	WIRING HARNESS ROOF	TATA spare parts
502454600180	WIRING HARNESS TAIL	TATA spare parts
502454600188	WIRING HARNESS BUMPER	TATA spare parts
502454600189	PIGTAIL SIDE INDICATOR & MARKER LAMP	TATA spare parts
502454600190	WIRING HARNESS ABS	TATA spare parts
502454600199	WIRING HARNESS SWITCH	TATA spare parts
502454600212	WIRING HARNESS ABS FRAME	TATA spare parts
502454608215	TOW HOOK AREA LAMP BRACKET	TATA spare parts
502454620106	WIRING HARNESS PIGTAIL FOR CHANGE OVER S	TATA spare parts
502454620106AE	W/H PIGTAIL CHANGE OVER SW -1628	TATA spare parts
502454660101	WH MAIN LPTA3138TC 8X8	TATA spare parts
502454660105	WH SWITCH LPTA3138 8X8	TATA spare parts
502454660106	PIGTAIL FOR CHANGEOVER SW	TATA spare parts
502454660108	W/H MAIN LPTA3138TC8X8RHDSINGLE H PATTERN	TATA spare parts
502454660111	PIGTAIL FOR 16A POWER SOCKET LPTA31388X8	TATA spare parts
502454660120	WIRING HARNESS ROOF	TATA spare parts
502456000101	ASSY.CROSS MEMBER (WINCH MOUNTING)	TATA spare parts
502456000102	ASSY. WINCH CROSS MEMBER COMPLETE	TATA spare parts
502456000103	ASSY.WINCH	TATA spare parts
502456200105	NYLON PIPE AIR VALVE TO WINCH	TATA spare parts
502456200106	NYLON PIPE TEE CONNECTOR TO AIR VALVE	TATA spare parts
502456200118	BARE HOSE (BOTH END)	TATA spare parts
502456200119	ASSY. HYD PUMP WITH SUCTION FITTING	TATA spare parts
502456200154	HOSE ASSY WITH END FITTINGS	TATA spare parts
502456200160	BSP BOTH END ADAPTOR 1/2 IN ELBOW AND ST	TATA spare parts
502456200161	BSP BOTH END ADAPTOR 3/4 IN ELBOW AND ST	TATA spare parts
502456200162	BSP BOTH END ADAPTOR 3/4 IN BOTH END ST.	TATA spare parts
502456203342	BRACKET (WINCH PIPE CLAMPING)	TATA spare parts
502456204301	2INC HOSE CLIP(SUCTION LINE)	TATA spare parts
502456204901	CONNECTION BOX (FOR WINCH)	TATA spare parts
502456206802	COUPLING BODY L15 IS9390 SS8451-8C	TATA spare parts
502456206803	COUPLING BODY L18 IS9390 SS8451-8C	TATA spare parts
502456206819	T UNION	TATA spare parts
502456206820	COUPLING BODY	TATA spare parts
502456206821	COUPLING BODY	TATA spare parts
502456206824	MALE CONNECTOR M36X2 - 3/4	TATA spare parts
502456206825	MALE CONNECTOR M24X1.5 - 1/2IN	TATA spare parts

502456209901	AIR VALVE	TATA spare parts
502456400101	ASSY WIRE ROPE	TATA spare parts
502456400102	ASSY.DEE SHACKLE	TATA spare parts
502456400103	WIRE ROPE ASSY WINCH	TATA spare parts
502456404201	ASSY.DEE SHACKLE	TATA spare parts
502456500104	ASSY BRACKET (FOR CONTROL VALVE)	TATA spare parts
502456500106	ASSY COVER WITH SUPPORT PLATES	TATA spare parts
502456500120	WINCH CONTROLER MTG BKT	TATA spare parts
502456500123	ASSY COMPLETE (ROPE ROLLER MTG BKT)	TATA spare parts
502456500125	ASSY.BKT.COMPLETE PULLEY MTG.FOR ROPE	TATA spare parts
502456500127	ASSY COMPLETE CONTROL VALVE MTG.	TATA spare parts
502456500129	PRESSURE HOSE (HYD. PUMP TO DC VALVE)	TATA spare parts
502456500134	ASSY COMPLETE (ROPE SUPPORT ROLLER)	TATA spare parts
502456500140	ASSY COVER WINCH CONTROL BOX	TATA spare parts
502456500166	BRACKET ASSY WINCH ROPE GUIDE MTG	TATA spare parts
502456503201	HEX SCREW	TATA spare parts
502456504901	CONNECTION BOX FOR WINCH	TATA spare parts
502456504902	AUDIO VISUAL 4-WRAP ROPE WARNING	TATA spare parts
502456504903	CABLE ASSY.FOUR POLL CONNECTOR FOR CONTR	TATA spare parts
502456505301	GASKET(FOR PTO PUMP MTG.)	TATA spare parts
502456507114	SUPPORT BRACKET (RETURN & PRESSURE LINE)	TATA spare parts
502456509002	CONTROL VALVE	TATA spare parts
502456509004	BALL VALVE 1/2	TATA spare parts
502456600101	ASSY.BRACKET FOR WINCH MTG.	TATA spare parts
502456600117	ASSY HYDRAULIC TANK WITH BRACKET	TATA spare parts
502456607103	STIFFNER	TATA spare parts
502456607108	WINCH MOUNTING PLATE (BOTTOM)	TATA spare parts
502456607109	SHIM (FOR WINCH MTG.)	TATA spare parts
502456609201	WASHER FOR 1/2 INC END FITTING	TATA spare parts
502456609202	WASHER FOR 3/4INC END FITTING	TATA spare parts
502458902601	DRIFT INSTALL MAINSHAFT BEARING	TATA spare parts
502458902602	DRIFT INST. COUNTERSHAFT BEARING	TATA spare parts
502458902603	DRIFT INST. INPUT SHAFT BEARING	TATA spare parts
502458902604	DRIFT INST. COUNTERSHAFT BEARING	TATA spare parts
502458902605	DRIFT INST. REAR OIL SEALANT	TATA spare parts
502458902606	DRIFT INST. REVERSE IDLE SHAFT	TATA spare parts
502458902607	DRIFT INST. COUNTERSHAFT BEARING	TATA spare parts
502458902608	DRIFT (UNIVERSAL)	TATA spare parts
502458902609	SLIDING HAMMER	TATA spare parts
502458902610	PULLER COUNTER SHAFT BEARING	TATA spare parts
502458902611	PULLER COUNTER SHAFT BEARING	TATA spare parts
502458902612	PULLER INPUT SHAFT BEARING	TATA spare parts
502458902613	PULLER LOW GEAR BEARING	TATA spare parts
502458902614	PULLER COUNTERSHAFT BEARING	TATA spare parts
502458902615	LEVER LOCK OUTPUT SHAFT	TATA spare parts
502458902616	PLATE SUPPORT COUNTERSHAFT	TATA spare parts
502458902617	PLATE SUPPORT LOW GEAR	TATA spare parts

502458902618	DRIFT INST. MAIN SHAFT BEARING	TATA spare parts
502458902619	DRIFT INST. COUNTERSHAFT BEARING	TATA spare parts
502458902620	EXTRACTOR TWO CLAWS SPINDLE	TATA spare parts
502458902621	PULLER MAINSHAFT BEARING	TATA spare parts
502458902622	PULLER AUX HOUSING	TATA spare parts
502458902623	PULLER OUNTERSHAFT BEARING RACE	TATA spare parts
502458902624	AL SNAP PLIER	TATA spare parts
502458902625	EXTRACTOR REVERSE IDLER SHAFT	TATA spare parts
502458902626	EXTRACTOR SPINDLE	TATA spare parts
502458902627	EXTRACTOR REVERSE PIN SNAP RING	TATA spare parts
502458902628	LIFT DEVICE SHAFT	TATA spare parts
502458902629	SUPPORT MAINSHAFT KEY	TATA spare parts
502458902630	SUP. FRONT HOUSING COUNTER SHAFT	TATA spare parts
502458902631	SUP. FRONT HOUSING COUNTER SHAFT	TATA spare parts
502458902801	MOUNTING DEVICE	TATA spare parts
502458902802	CLAMPING DEVICE	TATA spare parts
502458902803	HOLDING DEVICE	TATA spare parts
502458902804	LIFTING AND MEASURING DEVICE	TATA spare parts
502458902805	LIFTING DEVICE	TATA spare parts
502458902806	SUPPORTING DISK	TATA spare parts
502458902807	SUPPORTING DISK	TATA spare parts
502458902808	LIFTER	TATA spare parts
502458902809	SETTING TOOL	TATA spare parts
502458902810	STRIKING WEIGHT	TATA spare parts
502458902811	SETTING TOOL	TATA spare parts
502458902812	SETTING TOOL	TATA spare parts
502458902813	SETTING TOOL	TATA spare parts
502458902814	SETTING TOOL	TATA spare parts
502458902815	UNIVERSAL HANDLE	TATA spare parts
502458902816	BASE	TATA spare parts
502458902817	CENTERING TOOL	TATA spare parts
502458902818	EXTRACTOR FOR OIL PUMP	TATA spare parts
502458902819	FLANGE PULLER	TATA spare parts
502458902820	WRENCH	TATA spare parts
502458902821	RELEASE DEVICE	TATA spare parts
502458902822	BLOCKING DEVICE	TATA spare parts
502458902823	TWO- ARM EXTRACTOR	TATA spare parts
502458902824	EXTRACTION HOOK	TATA spare parts
502458902825	TWO- ARM EXTRACTOR	TATA spare parts
502458902826	SCREW EXTRACTOR	TATA spare parts
502458902827	COUNTER SUPPORT	TATA spare parts
502458902828	SEPARATOR	TATA spare parts
502458902829	PULLING-OFF DEVICE	TATA spare parts
502458902830	PRY BARS (2PCS.)	TATA spare parts
502458902831	TORQUE WRENCH	TATA spare parts
502458902832	TORQUE MULTIPLIER	TATA spare parts
502458902833	DEPTH GAUGE	TATA spare parts

502458902834	INTERNAL MEASURING INSTRUMENT 15/200 MM	TATA spare parts
502458902835	MICROMETER 100/200 MM	TATA spare parts
502458902836	DIAL GAUGE WITH MAGNETIC POST	TATA spare parts
502482400101	ASSY WIPER MOTOR & MTG BRACKET	TATA spare parts
502482400103	KIT-WIPER MOTOR WITH BKT	TATA spare parts
502482401602	WIPER MOTOR 24V 2 SPEED	TATA spare parts
502482401603	WASHER TANK ASSY	TATA spare parts
502482401604	T-CONNECTOR	TATA spare parts
502482401605	STRAIGHT CONNECTOR	TATA spare parts
502482401606	ELBOW ASSY.	TATA spare parts
502482401607	HOSE ID3.5MM & OD6.5MM.(5MTR.LENGTH)	TATA spare parts
502482401608	WASHER PUMP(24V)	TATA spare parts
502482401609	WASHER CAP	TATA spare parts
502482403301	BRACKET WIPER MOTOR MTG	TATA spare parts
502482408201	WIPER MOTOR MTG BRACKET	TATA spare parts
502482901601	ASSY WASHER BOTTLE	TATA spare parts
502615400102	ROTOR	TATA spare parts
502615400103	REGULATOR ASSY	TATA spare parts
502615400104	FASTENERS KIT	TATA spare parts
502615400105	PLUG MOULDING ASSY	TATA spare parts
502615409902	D.E BRACKET M/C	TATA spare parts
502615409904	STATOR ASSY FINAL	TATA spare parts
502615409905	S.R.E BRACKET M/C	TATA spare parts
502615409906	RECTIFIER ASSY	TATA spare parts
502615409908	BEARING ASSY KIT	TATA spare parts
502615409911	PULLEY	TATA spare parts
502615440101	ALTERNATOR(24V 90A TWIN GRV PUL)1613CNG	TATA spare parts
502630107107	TORSION SPRING	TATA spare parts
502716100103	CONTAINER (ECU 697TCIC BS3 100KW-490NM)	TATA spare parts
502716100110	CONTAINER(ECU 697TCIC BS3)	TATA spare parts
502729100101	ASSY.HYDRALIC.PIPE(M/CYL.TO BOOSTER)	TATA spare parts
502729100102	ASSEMBLY STOPPER.	TATA spare parts
502729100104	ASSY PEDAL BOX W/O PEDAL LEVER	TATA spare parts
502729100104AE	PEDAL BOX WITH CMC MTG LPA 1415/	TATA spare parts
502729100107	ASSY.CLUTCH PEDAL COMPLETE.	TATA spare parts
502729100108	ASSY.STOPPER.	TATA spare parts
502729100111	ASSY CLUTCH PEDAL MTG.BKT WITH STOPPER	TATA spare parts
502729100114	ASSY. HOSE PIPE(LENGTH 550)	TATA spare parts
502729100114AE	HOSE PIPE(LENGTH 550)LPA 1415	TATA spare parts
502729100116	ASSY.HYD.PIPE(M/CYL.TO BOOSTER FIRST PIP	TATA spare parts
502729100117	ASSY.HYD.PIPE(M/CYL.TO BOOSTER 2ND PIPE)	TATA spare parts
502729100119	ASSY. PEDAL BOX WITH PEDAL LEVER.	TATA spare parts
502729100128	ASSY FOOTREST	TATA spare parts
502729100129	ASSY FOOTREST WITH RUBBER PAD	TATA spare parts
502729100138	METTALIC PIPE ASSY	TATA spare parts
502729107501	RUBBER GROMMET	TATA spare parts
502729108208	BRACKET(FOR HYD.PIPE MOUNTING.	TATA spare parts

502729300101	CLUTCH BOOSTER 70 DIA	TATA spare parts
502729300102	CLUTCH BOOSTER ASSY	TATA spare parts
502729300103	ELBOW CONNECTOR ASSY	TATA spare parts
502729500101	BRACKET ASSY CLUTCH BOOSTER MTG	TATA spare parts
502729500102	SUPPORT BRACKET ASSY CLUTCH BOOSTER MTG	TATA spare parts
502730100101	ASSY ACCE. PEDAL STOPPER BRACKET	TATA spare parts
502730107501	RUBBER GROMMET	TATA spare parts
502731200101	ASSY RADIATOR BKT WITH SPACER RH	TATA spare parts
502731200102	ASSY RADIATOR BKT WITH SPACER LH	TATA spare parts
502733000101	ASSY.FRONT AXLE COMPLETE WITH BRAKES	TATA spare parts
502733000111	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
502741110101	FRONT PROP-SHAFT 1613/42 697TCIC	TATA spare parts
502741110103	PROPELLER SHAFT ASSY FRONT	TATA spare parts
502741110104	FRONT PROP-SHAFT 1613/42 697TCI	TATA spare parts
502741110105	FRONT PROP-SHAFT 1613/48 697TCI	TATA spare parts
502741110107	ASSY FRONT PROP SHAFT	TATA spare parts
502741110201	FRONT SHAFT TUBE LPT-1613/42	TATA spare parts
502741119901	SHORT FORK TUBE&FRONT END PIECE ASSY	TATA spare parts
502741119902	SHORT FORK TUBE&FRONT END PIECE ASSY	TATA spare parts
502741119903	COUPLING FLANGE ASSY	TATA spare parts
502741120101	REAR PROP-SHAFT 1613/42 697TCIC	TATA spare parts
502741120102	REAR PROP-SHAFT 1613/48 697TCIC	TATA spare parts
502741120103	PROPELLER SHAFT ASSY REAR	TATA spare parts
502741120104	REAR PROP-SHAFT 1613/42697TCIC	TATA spare parts
502741120105	REAR PROP-SHAFT	TATA spare parts
502741120106	REAR PROP-SHAFT 1613/52 697TCIC	TATA spare parts
502741120107	ASSY REAR PROP SHAFT	TATA spare parts
502741120201	REAR SHAFT TUBE LPT-1613/42 BS-3	TATA spare parts
502741129901	LONG FORK SUB ASSY	TATA spare parts
502741129902	SHORT FORK TUBE &REAR HOUSING ASSY.	TATA spare parts
502741129903	SHORT FORK TUBE & REAR HSG SUB ASSY	TATA spare parts
502741129904	SHORT FORK TUBE &REAR HOUSING ASSY.	TATA spare parts
502741303301	CENTRE BEARING MOUNTING BRACKET	TATA spare parts
502741990101	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
502741990102	LONG FORK SUB ASSY 140SLIP	TATA spare parts
502743900139	ASSY. CHASSIS SET COMPLETE 1613-TC-CAB	TATA spare parts
502743900167	ASSY NYLON BUNCH SET COMPLETE LPT1613	TATA spare parts
502743900199	PIPE ASSY BUNCH COMPLETE	TATA spare parts
502743900202	NYLON PIPE BUNCH ASSY	TATA spare parts
502743900217	PIPE ASSY BUNCH COMPLETE	TATA spare parts
502743910102	NYLON PIPE BUNCH ASSY	TATA spare parts
502746800105	ASSY.PRES.PIPE PUMP TO GB	TATA spare parts
502746800106	ASSY.RETN. PIPE(GB.TO TANK)	TATA spare parts
502746800107	ASSY.SUCT.PIPE (TANK TO PUMP)	TATA spare parts
502747600101	ASSY.RETURN LINE(F.TANK-OVERFLOW LINE)	TATA spare parts
502747600102	ASSY.SUCTION LINE(F.TANK-BABY FILTER)	TATA spare parts
502747600103	ASSY.SUCTION LINE(BABY FILTER-FEED PUMP)	TATA spare parts

502747603301	ASSY.SUPPORT PLATE FOR ASSY FUEL LINES	TATA spare parts
502749200104	ASSY THIRD EXHAUST PIPE	TATA spare parts
502749200105	ASSY. THIRD EXHAUST PIPE	TATA spare parts
502749200106	ASSY EXHAUST THIRD PIPE	TATA spare parts
502749200107	ASSY EXHAUST THIRD PIPE	TATA spare parts
502749200108	ASSY. THIRD EXHAUST PIPE	TATA spare parts
502749200110	ASSY EXHAUST SECOND PIPE	TATA spare parts
502754109902	BATTERY 12V 120A M/S TATA A.G.B.	TATA spare parts
502754208205	ECU COVER (FOR COWL VERSION)	TATA spare parts
502754209902	R.P.M.METER 12V (BACKLIT)	TATA spare parts
502754209907	INST CLUST (ELECT)12V (1:0.88)	TATA spare parts
502754209908	INST CLUST (ELECT)12V (1:0.88)	TATA spare parts
502754400101	ASSY LAMP-WARNING IND-12V	TATA spare parts
502754400102	ASSY MOUNTING BRACKET (BEEPER WIF & BUF)	TATA spare parts
502754401602	ASSY LAMP WARNING IND. 12V WITH ABS	TATA spare parts
502754600106	ASSY BRACKET-FOR CHANNEL MTG	TATA spare parts
502754600113	WIRING HARNESS ABS FRAME	TATA spare parts
502754600132	WIRING HARNESS ABS FRAME	TATA spare parts
502754601602	W/H TAIL LPT1613/42697BSIII12V	TATA spare parts
502754601603	W/H SENSOR LPT1613/4212V697 BS2/3	TATA spare parts
502754601604	W/H ENGINE LPT1613/42697BSIII12V	TATA spare parts
502754601636	W/H MAIN LPT1613 697 BSIII 12V	TATA spare parts
502754608209	TWISTED BRACKET	TATA spare parts
502754608210	BRACKET E (FOR W/H ROUTING)	TATA spare parts
502754608211	BRACKET (FOR NBF PARKING)	TATA spare parts
502754608214	CLIP FOR ROTARY FIP CONNECTOR MTG	TATA spare parts
502754608216	L BRACKET FOR WH MTG	TATA spare parts
502754608218	L BRACKET FOR CONNECTOR MTG	TATA spare parts
502754616301	WIRING HARNESS CHANNEL	TATA spare parts
502754620102	W/H TAIL LPT1613/42 697 BSIII 1	TATA spare parts
502754620103	WIRING HARNESS SENSOR	TATA spare parts
502754620104	W/H ENGINE LPT1613/42 12V BSIII	TATA spare parts
502754620108	WIRING HARNESS MAIN LPT1613/42 697 BSIII	TATA spare parts
502754620138	W/H MAIN LPT1613 697 BSIII 12V	TATA spare parts
502754660102	W/H TAIL LPT1613/42BSII	TATA spare parts
502754660103	W/H SENSOR LPT1613/4212V697BSIII	TATA spare parts
502754660104	W/H ENGINE LPT1613/42697BSIII12V	TATA spare parts
502754660138	W/H MAIN LPT1613/42 697 BSIII 12V COWL	TATA spare parts
502754660141	W/H ENGINE - LPT1613/2515/1616 697 BSIII	TATA spare parts
502754660142	W/H ENGINE LPT 1613 697	TATA spare parts
502754660143	W/H MAIN LPT1613 697 BSIII 12V	TATA spare parts
502754660144	W/H MAIN LPT1613 697 BSIII 12V (WITH ABS	TATA spare parts
502754660146	W/H ENGINE - LPT1613/2515/1616 697 BSIII	TATA spare parts
502754660147	WIRING HARNESS ENGINE	TATA spare parts
502754660148	W/H MAIN LPT1613 697 BSIII 12V COWL	TATA spare parts
502754660158	WIRING HARNESS MAIN	TATA spare parts
502754660160	WIRING HARNESS MAIN	TATA spare parts

502782249901	TWO SPEED WIPER MOTOR 17W-24V BS3/4/6	TATA spare parts
502782249904	ARMATURE ASSY BS6	TATA spare parts
502782249905	BRUSH PLATE & SWITCH ASSY BS6	TATA spare parts
502782400101	KIT FOR ELECT. W/S. WASHER UNIT 12V	TATA spare parts
502824200101	ENGINE MTG. BKT-RH (REAR TOP)	TATA spare parts
502824200105	ENGINE MTG. BKT-LH (REAR TOP)	TATA spare parts
502824200106	ASSY ENGINE MTG. REAR BOTTOM - RH	TATA spare parts
502824200107	ASSY ENGINE MTG. BRACKET REAR - LH	TATA spare parts
502824207108	SPACER PLATE(ENGINE MTG.REAT-LH	TATA spare parts
502830100102	ASSY.ACCELERATOR PEDAL COMPLETE	TATA spare parts
502830100106	ASSY. ACCELERATOR PULL CABLE 3269MM BS3	TATA spare parts
502830100108	ACCELERATOR CABLE	TATA spare parts
502830100109	ACCELERATOR CABLE 3309MM BS2/3	TATA spare parts
502830108203	CABLE HOLDER (ACCE.CABLE)	TATA spare parts
502830108204	BRACKET (ACCE.CABLE MTG.)	TATA spare parts
502830109903	PIVOT PIN ACCELERATOR PEDAL	TATA spare parts
502830308701	TENSION SPRING	TATA spare parts
502830308702	TENSION SPRING FOR ACC CONTROL(NEAR FIP)	TATA spare parts
502831000101	ASSY FRAME(LPT-1613TC/42 BS-III CWL)	TATA spare parts
502831000104	ASSY. FRAME	TATA spare parts
502831000108	ASSY. FRAME LPT1613/52WB 60% ROH	TATA spare parts
502831000111	FRAME ASSY	TATA spare parts
502831000112	FRAME ASSY WITH FITMENT	TATA spare parts
502831100101	ASSY BUMPER CROSS MEMBER(TOWING HOOK)	TATA spare parts
502831200105	ASSY SUPPORT(ENGINE C/M REAR)	TATA spare parts
502831200106	ASSY SPACER (REAR ENG CROSS MEMBER)	TATA spare parts
50283120010635	ASSY SPACER(REAR ENG X-MEMBER)_UNPAINTED	TATA spare parts
502831200108	ASSY SUPPORT(ENG CROSS MEMBER FRONT)	TATA spare parts
502831200109	ASSY SUPPORT(ENG CROSS MEMBER FRONT-LH)	TATA spare parts
502831200113	ASSY GUSSET-RH	TATA spare parts
502831200114	ASSY GUSSET-LH	TATA spare parts
502831200115	ASSY.FRONT CROSS MEMBER-WITH TOWING HOC	TATA spare parts
502831200118	ASSY EXTENSION PIECE -RH	TATA spare parts
502831200119	ASSY EXTENSION PIECE - LH	TATA spare parts
502831200120	ASSY STIFFNER FOR ENGINE C/M REAR	TATA spare parts
502831207105	BRACKET FOR SUPPORT(ENG REAR_C/M)	TATA spare parts
502831207118	STIFFNER PLATE (ENG C.M FRONT)	TATA spare parts
50283120711835	STIFFNER PLATE (ENG C.M FRONT)_UNPAINTED	TATA spare parts
502831208202	PACKING SHEET	TATA spare parts
502831300101	GUSSET ASSY RH	TATA spare parts
502831300102	GUSSET ASSY LH	TATA spare parts
502831700102	ASSY FUPD BRACKET COMPLETE- RH	TATA spare parts
502831700103	ASSY BRACKET FUPD COMPLETE LH	TATA spare parts
502831700104	ASSY FUPD BRACKET COMPLETE-RH	TATA spare parts
502831700105	ASSY FUPD BRACKET COMPLETE-LH	TATA spare parts
502831700106	ASSY SUPPORT BRACKET-RH	TATA spare parts
502831700107	ASSY SUPPORT BRACKET-LH	TATA spare parts

502831700108	ASSY RADIATOR BKT&FRONT C/M GUSSET-RH	TATA spare parts
502831700109	ASSY RADIATOR BKT &FRONT C/M GUSSET-LH	TATA spare parts
502831700113	ASSY EXTENSION PIECE FOR FRAME-RH	TATA spare parts
502831700114	ASSY EXTENSION PIECE FOR FRAME-LH	TATA spare parts
502831707120	SPACER	TATA spare parts
502833000102	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
502841100102	ASSY. PROP. SHAFT FRONT	TATA spare parts
502841110101	FRONT PROP-SHAFT	TATA spare parts
502841110102	PROP SHAFT FRONT 1613/48&52 TC BS-3	TATA spare parts
502841110202	FRONT SHAFT TUBE LPT-1613TC/48&5	TATA spare parts
502843900150	METAL PIPE WITH CRIMPED HOSE	TATA spare parts
502843900152	ASSY METAL PIPE 2ND	TATA spare parts
502843900154	ASSY METAL PIPE 3RD LPT1613TC 42WB	TATA spare parts
502846700101	ASSY BRACKET STEERING GB MOUNTING	TATA spare parts
502846800106	KIT ASSY PIPE&CLAMPS COWL	TATA spare parts
502846800109	ASSY SUCTION LINE (TANK TO PUMP)	TATA spare parts
502846800110	ASSY PRES LINE (PUMP TO GB)	TATA spare parts
502846800111	ASSY RETURN LINE (GB TO TANK)	TATA spare parts
502847600107	ASSY SUCTION LINE LPT-1613/42 TC BS_3	TATA spare parts
502847600108	ASSY RETURN LINE LPT-1613/42 TC BS_3	TATA spare parts
502847600110	SUCTION LINE PIPE ASSY (FILTER TO ENG)	TATA spare parts
502847600114	BRACKET FUEL WATER SEPARATOR MTG	TATA spare parts
502847600121	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
502847600122	SUCTION PIPE ASSY FUEL TANK TO W/SEP	TATA spare parts
502849200101	ASSY 1ST EXHAUST PIPE(FROM T/C TO EXH-BR	TATA spare parts
502849200102	ASSY EXHAUST SECOND PIPE	TATA spare parts
502849200103	ASSY BRACKET (EXHAUST BRAKE)	TATA spare parts
502849200105	ASSY EXHAUST THIRD PIPE	TATA spare parts
502849200107	ASSY EXHAUST THIRD PIPE	TATA spare parts
502849200108	PIPE ASSY	TATA spare parts
502854106301	BATTERY TRAY 100AH BATT BS6	TATA spare parts
502854209901	INST.CLUSTER (ELECT.)(0.88)	TATA spare parts
502854209902	INST.CLUSTER (ELECT.)(0.88)	TATA spare parts
502854500101	OIL PRESSURE SWITCH BIPOLAR	TATA spare parts
503000990101	KIT FULLY BUILD COWL LPT 2518 CLM BS4	TATA spare parts
503000990102	KIT FULLY BUILD COWL LPT 2518 BS4 BLOWER	TATA spare parts
503000990103	KIT FULLY BUILD STCAB LPT 2518 BS4 BLW	TATA spare parts
503000990106	KIT FULLY BUILD COWL LPT 2518 BSIII	TATA spare parts
503000990107	KIT FULLY BUILD SIGNA LPT 2818.T BS4 BLW	TATA spare parts
503000990108	KIT FULLY BUILD COWL LPT 2518 BS4 AC	TATA spare parts
503016132001	TCU LOADED WITH CALIBRATION SOFTWARE	TATA spare parts
50302148000RCK	ASSY CAB KIT W/FITMENTS LPT 2518 SIGNA	TATA spare parts
503024200101	ASSY.BRACKET-LH (ENG.REAR MOUNTING)	TATA spare parts
503024200102	ASSY.BRACKET-RH (ENG.REAR MOUNTING)	TATA spare parts
503024200103	ASSY.BRKT.ENGINE MTG-LH(REAR BOTTOM)	TATA spare parts
503024200104	ASSY.BRKT.ENGINE MTG-RH(REAR BOTTOM)	TATA spare parts
503024200105	ASSY.BRACKET-LH (ENG.REAR MOUNTING)	TATA spare parts



503024200106	ASSY.BRACKET-RH (ENG.REAR MOUNTING)	TATA spare parts
503026800101	BASE PLATE CONSOLE BELLOW	TATA spare parts
503026800102	RUBBER SEALING	TATA spare parts
503026807701	RUBBER BELLOW	TATA spare parts
503026810101	BRACKET ASSY	TATA spare parts
503026810103	PIPE ASSY	TATA spare parts
503026810110	BRACKET ASSY WITH BASE PLATE	TATA spare parts
503026820101	SUPPORT TUBE ASSY	TATA spare parts
503029100105	ASSY PEDAL BOX WITH CMC MOUNTING W/O PEDAL	TATA spare parts
503029100106	ASSY.HYD.PIPE(M/CYL.TO BOOSTER 1ST PIPE)	TATA spare parts
503029100108	ASSY.METAL PIPE(INTERMEDIATE)	TATA spare parts
503029100111	ASSY.METAL PIPE(FROM MC)	TATA spare parts
503029100112	ASSY.FORK WITH PUSH ROD(MASTER CYLINDER)	TATA spare parts
503029100114	ASSY PIPE (CLUTCH BOOSTER)	TATA spare parts
503029100116	ASSY.CLUTCH PEDAL COMPLETE	TATA spare parts
503029100118	ASSY.HYD.PIPE(M/CYL.TO BOOSTER LAST PIPE)	TATA spare parts
503029100119	ASSY.HYD.PIPE(M/CYL.TO BOOSTER 2ND PIPE)	TATA spare parts
503029100120	ASSY.CLUTCH PEDAL BOX WITH PEDAL	TATA spare parts
503029100125	ASSY.SUPPORT	TATA spare parts
503029100136	ASSY CLUTCH PIPE REAR	TATA spare parts
503029100138	HYD PIPE ASSY (FIRST PIPE FROM M/CYL TO	TATA spare parts
503029100140	ASSY RUBBER HOSE	TATA spare parts
503029100145	ASSY.HOSE(CLUTCH)	TATA spare parts
503029100158	ASSEMBLY METAL PIPE	TATA spare parts
503029100164	CLUTCH MASTER CYL. 25.4 DIA BS3/4	TATA spare parts
503029105801	RUBBER HOSE(FLUID CONTAINER TO M.CYL)	TATA spare parts
503029300102	CLUTCH BOOSTER ASSY (TYPE-3)	TATA spare parts
503029300103	MAJOR KIT-CLUTCH BOOSTER	TATA spare parts
503029300105	MINOR KIT-CLUTCH BOOSTER	TATA spare parts
503029300107	MAJOR REPAIR KIT FOR M/CYL.	TATA spare parts
503029300108	MINOR REPAIR KIT FOR M/CYL.	TATA spare parts
503029350103	ASSY C.B. MTG BRACKET	TATA spare parts
503029504202	BRACKET	TATA spare parts
503029504203	BRACKET	TATA spare parts
503029508201	BRACKET FOR CLUTCH HOSE MTG	TATA spare parts
503029508202	L BRACKET FOR CLUTCH HOSE MOUNTING BS6	TATA spare parts
503029508203	BRACKET FOR CLUTCH PIPE MTG	TATA spare parts
503030100108	ACCELERATOR PEDAL MODULE BS4/6	TATA spare parts
503030100109	BRACKET ASSY ACCELERATOR PEDAL MTG	TATA spare parts
503030100110	ACCELERATOR CABLE (L=500+3100+132) BS3	TATA spare parts
503030100111	ACCELERATOR CABLE ASSY	TATA spare parts
503030100113	ACCELERATOR PEDAL ASSY BS6	TATA spare parts
503030104201	CLAMP ACCELERATOR CABLE MTG	TATA spare parts
503030107102	PLATE ACCELERATOR CABLE MTG	TATA spare parts
503030107103	PLATE ACCELERATOR CABLE MTG	TATA spare parts
503031000101	ASSY FRAME LPT-2518/48 TC BS-3 CAB	TATA spare parts
503031000102	ASSY FRAME LPT3118(CAST 6 HOLE BRKT)BS3	TATA spare parts

50303100010204	ASSY FRAME LPT3118(FAB 4 HOLE BRKT)BS3	TATA spare parts
50303100010206	ASSY FRAME (CAST TYPE 6 HOLE BRKT)	TATA spare parts
503031000103	ASSY. FRAME COMPLETE	TATA spare parts
503031000109	FRAME ASSY WITH FITMENT	TATA spare parts
503031000110	FRAME ASSY WITH FITMENT	TATA spare parts
503031000119	ASSY. FRAME LPT2518 (CAST 6 HOLE BKT)BS4	TATA spare parts
503031000121	ASSY FRAME COMPLETE	TATA spare parts
503031000124	ASSY. FRAME LPT 2518 (CAST BRKT) BS4	TATA spare parts
503031000135	FRAME ASSY	TATA spare parts
503031000136	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
503031000141	FRAME ASSY WITH FITMENT	TATA spare parts
503031000143	FRAME ASSY WITH FITMENT	TATA spare parts
503031000144	FRAME ASSY WITH FITMENT	TATA spare parts
503031000156	FRAME ASSY WITH FITMENT	TATA spare parts
503031000157	FRAME ASSY WITH FITMENT	TATA spare parts
503031000158	FRAME ASSY WITH FITMENT	TATA spare parts
503031000161	FRAME ASSY WITH FITMENT BS6	TATA spare parts
503031000163	FRAME ASSY WITH FITMENT BS6	TATA spare parts
503031000181	FRAME ASSY WITH FITMENT	TATA spare parts
503031107109	LONG MEMBER RH RIVIGO	TATA spare parts
503031200102	ASSY. SUPPORT-RH(ENG. C.M. FRONT)	TATA spare parts
503031200103	ASSY. SUPPORT-L.H(ENG. C.M. FRONT)	TATA spare parts
503031200104	ASSY.BRACKET-RH(RADIATOR MOUNTING)	TATA spare parts
503031200105	ASSY.BRACKET-LH(RADIATOR MOUNTING)	TATA spare parts
503031200107	ASSY.SUPPORT(ENG.FRONT CROSS MEMBER)-RH	TATA spare parts
503031200110	ASSY.SUPPORT(ENG.FRONT CROSS MEMBER)-LH	TATA spare parts
503031200111	ASSY.ENG.CROSS MEMBER (FRONT)	TATA spare parts
503031200120	ASSY.ENGINE CROSS MEMBER (FRONT)	TATA spare parts
503031200165	CROSS MEMBER ASSY ENGINE MTG REAR	TATA spare parts
503031200174	REINFORCEMENT ASSY CROSS MEMBER RH	TATA spare parts
503031200175	REINFORCEMENT ASSY CROSS MEMBER LH	TATA spare parts
503031207110	SUPPORT SHEET	TATA spare parts
50303120711035	SUPPORT SHEET_UNPAINTED	TATA spare parts
503031207122	SPACER PLATE (ENG. C.M. FRONT)	TATA spare parts
503031207140	END CROSS MEMBER	TATA spare parts
503031208201	PACKING SHEET (1.6 THK)	TATA spare parts
503031208202	PACKING SHEET (3.15 THK)	TATA spare parts
503031307110	FRONT CROSS MEMBER SUPPORT	TATA spare parts
503031307160	REINFORCEMENT FRONT SPRING BKT REAR-RH	TATA spare parts
503031307161	REINFORCEMENT FRONT SPRING BKT FRONT-LH	TATA spare parts
503031327101	SPACER PLATE REAR FRONT	TATA spare parts
50303132710135	SPACER PLATE REAR FRONT UNPAINTED	TATA spare parts
503031327102	SPACER PLATE REAR MIDDLE	TATA spare parts
50303132710235	SPACER PLATE REAR MIDDLE UNPAINTED	TATA spare parts
503031327103	SPACER PLATE REAR	TATA spare parts
50303132710335	SPACER PLATE REAR UNPAINTED	TATA spare parts
503031700108	BRACKET ASSY RADIATOR MTG	TATA spare parts

503031700109	BRACKET ASSY RADIATOR MTG	TATA spare parts
503031700110	ASSY FUPD BRACKET RH	TATA spare parts
503031700111	ASSY FUPD BRACKET LH	TATA spare parts
503031700112	ASSY.FUPD CROSS BEAM	TATA spare parts
503031700115	ASSY STIFFNER BRACKET (FUPD CROSS BEAM)	TATA spare parts
503031700117	ASSY. BEAM RUPD BS3/4/6	TATA spare parts
503031700118	BRACKET ASSY RUPD MTG LH	TATA spare parts
503031700119	BRACKET ASSY RUPD MTG RH	TATA spare parts
503031700125	BRACKET ASSY RADIATOR MTG RH BS6	TATA spare parts
503031700126	BRACKET ASSY RADIATOR MTG LH BS6	TATA spare parts
503031700130	BRACKET ASSY FUPD RH	TATA spare parts
503031700131	BRACKET ASSY FUPD LH	TATA spare parts
503031700134	FUPD CROSS BEAM ASSY	TATA spare parts
503031700138	FUPD ASSY CROSS BEAM BS6	TATA spare parts
503031708217	SPACER	TATA spare parts
503031990101	KIT-REINFORCEMENT FRAME	TATA spare parts
503032100115	ASSY BUMP STOPPER RH	TATA spare parts
503032100116	ASSY BUMP STOPPER LH	TATA spare parts
503032100123	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
503032100129	1ST LEAF ASSY WITH BUSH	TATA spare parts
503032100130	PARABOLIC LEAF SPRING ASSY BS6	TATA spare parts
503032100144	SPACER BLOCK ASSY WITH SPIGOT	TATA spare parts
503032103202	CENTER BOLT BS6	TATA spare parts
503032103204	CLAMP BOLT BS6	TATA spare parts
503032104201	SPRING CLIP BS6 ( SIDE CLANP - 25X6XH74)	TATA spare parts
503032106501	HEX NUT BS6 (CENTER BOLT NUT- M12X1.75)	TATA spare parts
503032106502	HEX NUT BS6 (SIDE CLAMP BOLT NUT - M8X1.	TATA spare parts
503032106701	COTTER PIN	TATA spare parts
503032107110	2ND LEAF	TATA spare parts
503032107111	3RD LEAF	TATA spare parts
503032107112	4TH LEAF PARABOLIC LEAF SPRING	TATA spare parts
503032107113	5TH LEAF PARABOLIC LEAF SPRING	TATA spare parts
503032107116	2ND LEAF BS6	TATA spare parts
503032107117	3RD LEAF BS6	TATA spare parts
503032107118	4TH LEAF BS6	TATA spare parts
503032107120	CENTER PAD BS6	TATA spare parts
503032107121	SPACER PLATE	TATA spare parts
503032107401	RIVET SPRING CLIP BS6	TATA spare parts
503032108602	SPACER TUBE BS6	TATA spare parts
503032300103	ASSY. BRACKET (FRONT SHOCK ABSORBER)	TATA spare parts
503032300104	BRACKET ASSY SHOCK ABSORBER MTG UPPER	TATA spare parts
503032400116	LEAF SPRING ASSY REAR	TATA spare parts
503032400117	1ST LEAF ASSY WITH BUSH	TATA spare parts
503032403203	CENTER BOLT	TATA spare parts
503032403306	BRACKET REAR SPRING HANGER	TATA spare parts
503032403341	SPRING HANGER BRACKET REAR - LH	TATA spare parts
503032403342	SPRING HANGER BRACKET REAR - RH	TATA spare parts

503032404202	SPRING CLIP	TATA spare parts
503032406501	HEX NUT CLINCH M16X1.5	TATA spare parts
503032407110	2ND LEAF	TATA spare parts
503032407111	3RD LEAF	TATA spare parts
503032407112	9TH LEAF	TATA spare parts
503032407113	4TH LEAF	TATA spare parts
503032407114	10TH LEAF	TATA spare parts
503032407116	5TH LEAF	TATA spare parts
503032407117	7TH LEAF	TATA spare parts
503032407118	8TH LEAF	TATA spare parts
503032407119	6TH LEAF	TATA spare parts
503032800101	CONNECTING LINK ASSY	TATA spare parts
503032803301	BRACKET ANTI ROLL BAR MTG FRONT	TATA spare parts
503033000101	ASSY FRONT AXLE WITH BRAKES	TATA spare parts
503033000103	ASSY FRONT AXLE COMP.BRAKES ABS	TATA spare parts
503033000108	STOPPER BOLT ASSY.	TATA spare parts
503033000111	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
503033000112	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
503033000114	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
503033000117	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
503033407801	OIL SEAL BS2/3/4	TATA spare parts
503033408301	SHIM FRONT HUB 1.5 MM THK	TATA spare parts
503033408302	SHIM FRONT HUB 1.00 MM	TATA spare parts
503033408303	SHIM FRONT HUB 0.85 MM THK	TATA spare parts
503033408304	SHIM FRONT HUB 0.9 MM THK	TATA spare parts
503033408305	SHIM FRONT HUB 0.95 MM THK	TATA spare parts
503033408306	SHIM FRONT HUB 1.05 MM THK	TATA spare parts
503033408307	SHIM FRONT HUB 1.10 MM THK	TATA spare parts
503033408308	SHIM FRONT HUB 1.15 MM THK	TATA spare parts
503033408309	SHIM FRONT HUB 1.20 MM THK	TATA spare parts
503033408310	SHIM FRONT HUB 1.25 MM THK	TATA spare parts
503033408311	SHIM FRONT HUB 1.30 MM THK	TATA spare parts
503033408312	SHIM FRONT HUB 1.35 MM THK	TATA spare parts
503033408313	SHIM FRONT HUB 1.40 MM THK	TATA spare parts
503033408314	SHIM FRONT HUB 1.45 MM THK	TATA spare parts
503033408315	SHIM FRONT HUB 1.55 MM THK	TATA spare parts
503033408316	SHIM FRONT HUB 1.60 MM THK	TATA spare parts
503033408317	SHIM FRONT HUB 1.65 MM THK	TATA spare parts
503033408601	SPACER TUBE	TATA spare parts
503033805101	STEERING ARM	TATA spare parts
503033900115	BRACKET ASSY MAIN BELLOW MTG	TATA spare parts
503033900143	PRESSURE REGULATOR ASSY	TATA spare parts
503033900155	BRACKET ASSY HLV MTG	TATA spare parts
503033900160	GATE VALVE ASSY	TATA spare parts
503033900191	BUSH ASSY	TATA spare parts
503033900193	LIFT AXLE ASSY BS6	TATA spare parts
503033900198	LIFT AXLE LINK ARM ASSY LH	TATA spare parts

503033900199	LIFT AXLE LINK ARM ASSY RH	TATA spare parts
503033900204	LIFT AXLE ASSY BS6	TATA spare parts
503033900206	LIFT AXLE ASSY WITH BRAKE BS6	TATA spare parts
503033900207	LIFT AXLE ASSY WITH BRAKE BS6	TATA spare parts
503033900255	BRACKET ASSY LIFT AXLE WITH BUSH LH	TATA spare parts
503033900259	BRACKET ASSY LIFT AXLE WITH BUSH RH	TATA spare parts
503033903202	BOLT M30X3.5X325 LG - 10.9	TATA spare parts
503033903206	HUCK SPIN BOLT PIN BS6	TATA spare parts
503033903209	HEX BOLT M30X2X311 LG	TATA spare parts
503033906101	WASHER	TATA spare parts
503033906504	NUT M30X3.5	TATA spare parts
503033906506	HEX NUT M30 X 2	TATA spare parts
503033907143	CROSS MEMBER	TATA spare parts
503033907155	BUSH	TATA spare parts
503033907166	ASSY. LIFT AIR SPRING BS2/4	TATA spare parts
503033907166DF	AIR SPRING LIFT-12.5T LIFT AXLE-LPT4825	TATA spare parts
503033907183	HANGER OUTER BUSH	TATA spare parts
503033907701	BUMP STOPPER PLATE	TATA spare parts
503033908601	WEAR PAD	TATA spare parts
503033909904	MAIN AIR SPRING BS4	TATA spare parts
503033909904DFEH	AIR SPRING MAIN ELONG HEIGHT-12.5T LA-48	TATA spare parts
503033909904DFNH	AIR SPRING MAIN NORM HEIGHT-12.5T LA-482	TATA spare parts
503033909906	REBOUND STRAP	TATA spare parts
503041100102	ASSY.PROP.SHAFT FRONT	TATA spare parts
503041100103	ASSY.PROP.SHAFT REAR 2518TC	TATA spare parts
503041100105	ASSY.PROP.SHAFT FRONT	TATA spare parts
503041100106	ASSY.PROP.SHAFT REAR	TATA spare parts
503041100107	ASSY. PROP SHAFT FRONT	TATA spare parts
503041100108	ASSY. PROP SHAFT REAR	TATA spare parts
503041100113	ASSY PROP SHAFT FRONT	TATA spare parts
503041100115	ASSY PROP SHAFT MIDDLE	TATA spare parts
503041100119	ASSY.PROP.SHAFT FRONT 2518C G600	TATA spare parts
503041100121	ASSY.PROP.SHAFT FRONT	TATA spare parts
503041100134	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
503041110102	PROPELLER SHAFT ASSY MIDDLE(SPICER)	TATA spare parts
503041110103	PROPELLER SHAFT ASSY FRONT(SPICER)	TATA spare parts
503041110104	PROPELLER SHAFT ASSY FRONT	TATA spare parts
503041110109	SHORT FORK TUBE&FRONT END PIECE ASSY	TATA spare parts
503041110111	SHORT FORK TUBE FRONT END PIECE ASSY (FR	TATA spare parts
503041110112	SHORT FORK TUBE FRONT END PIECE ASSY (MI	TATA spare parts
503041110115	PROPELLER SHAFT ASSY FRONT	TATA spare parts
503041110117	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
503041110118	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
503041110119	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
503041110121	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
503041110123	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
503041110124	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts

503041110125	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
503041110127	PROPELLER SHAFT ASSY-COUPLING BS6	TATA spare parts
503041119903	SHORT FORK TUBE & FRT END PIECE	TATA spare parts
503041120101	SHORT FORK TUBE & REAR HOUSING ASSY	TATA spare parts
503041120104	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
503041120105	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
503041120106	PROPELLER SHAFT ASSY REAR	TATA spare parts
503041120108	PROPELLER SHAFT ASSY REAR	TATA spare parts
503041120114	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
503041120117	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
503041120119	SHORT FORK TUBE REAR HSG. ASSY	TATA spare parts
503041129902	UNIT PACK	TATA spare parts
503041129904	SHORT FORK TUBE & REAR END TUBE PIECE AS	TATA spare parts
503041200116	ASSY PROPSHAFT REAR	TATA spare parts
503041200117	ASSY PROPSHAFT REAR 62WB	TATA spare parts
503041303301	CENTRE BEARING MTG. BKT.	TATA spare parts
503041303302	CENTRE BEARING MTG. BKT.	TATA spare parts
503041303303	BRACKET CENTER BRG MTG BS6	TATA spare parts
503041303306	BRACKET CENTER BRG MTG BS6	TATA spare parts
503041303313	CENTRE BEARING MOUNTING BRACKET-FRONT	TATA spare parts
503041303314	CENTRE BEARING MOUNTING BRACKET-MIDDLE	TATA spare parts
503041303315	CENTER BEARING MTG.BRACKET BS6	TATA spare parts
503041308201	PROP SHAFT GUARD -LH (REAR)	TATA spare parts
503041308202	PROP SHAFT GUARD -RH (REAR)	TATA spare parts
503041308205	SPACER PLATE	TATA spare parts
503041990103	SHORT FORK TUBE & FRT END PIECE	TATA spare parts
503042100107	F/A BRAKE W/DC -LHNA1707	TATA spare parts
503042100108	F/A BRAKE W/DC -RHNA1707	TATA spare parts
503042100116	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
503042100117	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
503042100120	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
503042100121	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
503042100122	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
503042100123	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
503042103401	BUSHING- CAM	TATA spare parts
503042109001	RELIEF VALVE	TATA spare parts
503042109901	CAM SHAFT REPAIR KIT-FRONT	TATA spare parts
503042130101	LINED SHOE ASSY	TATA spare parts
503042138701	SPRING - CAM END	TATA spare parts
503042300121	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
503042300122	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
503042300126	DRUM BRAKE ASSY 6262ITH/CH	TATA spare parts
503042300127	DRUM BRAKE ASSY 6262 ITH /CH	TATA spare parts
503042300132	ASSY.R/A BRAKE W/DC -LH NA1707	TATA spare parts
503042300133	ASSY.R/A BRAKE W/DC -RH NA1707	TATA spare parts
503042300138	BRAKE ASSY -SPIDER ASSY	TATA spare parts
503042300142	DRUM BRAKE ASSY REAR -LH DIA 410X180	TATA spare parts

503042300143	DRUM BRAKE ASSY REAR -RH DIA 410X180	TATA spare parts
503042300147	BRAKE ASSY -LH REAR 410X180 W/PLB	TATA spare parts
503042300148	BRAKE ASSY -RH REAR 410X180 W/PLB	TATA spare parts
503042300159	DRUM BRAKE ASSY W/T DC REAR-LH	TATA spare parts
503042300160	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
503042300161	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
503042300162	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
503042300163	BRAKE ASSY REAR-LH	TATA spare parts
503042300164	BRAKE ASSY REAR-RH	TATA spare parts
503042300165	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
503042300166	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
503042300175	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
503042300176	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
503042300177	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
503042300178	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
503042303201	HEX BOLT -M16X1.5X51 IS1367 10.9	TATA spare parts
503042303202	HEX BOLT -M14X1.5X51 IS1367 10.9	TATA spare parts
503042303405	BI-METAL BUSH	TATA spare parts
503042303407	BUSH-S-CAM SHAFT	TATA spare parts
503042303408	BUSH-S-CAM SHAFT MERITOR BRAKE	TATA spare parts
503042303703	BRAKE ASSY -TORQUE PLATE NON-ABS	TATA spare parts
503042303704	TORQUE PLATE LH	TATA spare parts
503042303705	TORQUE PLATE RH	TATA spare parts
503042303706	BRAKE ASSY -TORQUE PLATE MACHINING	TATA spare parts
503042305103	CAMSHAFT LH	TATA spare parts
503042305104	CAMSHAFT RH	TATA spare parts
503042306501	HEX NUT -W/FL PREVAILING TRQ TYP M16X1.5	TATA spare parts
503042306502	HEX NUT -W/FL PREVAILING TRQ TYP M14X1.5	TATA spare parts
503042308201	BRAKE ASSY -DUST SHIELD TOP	TATA spare parts
503042308202	BRAKE ASSY -DUST SHIELD BOTTOM	TATA spare parts
503042309902	MINOR O/H KIT	TATA spare parts
503042309903	CAM SHAFT REPAIR KIT	TATA spare parts
503042993401	BUSHING CAM	TATA spare parts
503042998001	CAP SCREW -DUST SHILED	TATA spare parts
503042999201	WASHER -DUST SHIELD	TATA spare parts
503043200106	AIR TANK ASSY WITH BKT	TATA spare parts
503043200107	AIR TANK SUB ASSY.(15LTR)	TATA spare parts
503043200110	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
503043200112	AIR TANK ASSY	TATA spare parts
503043200114	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
503043700114	FOOT BRAKE VALVE VOSS	TATA spare parts
503043700118	FOOT BRAKE VALVE VOSS	TATA spare parts
503043700121	DUAL TREADLE VALVE VOSS BS1/3	TATA spare parts
503043700122	DUAL TREADLE VALVE VOSS	TATA spare parts
503043700123	DRYING & DISTRIBUTION UNIT	TATA spare parts
503043700180	DUAL TREADLE VALVE	TATA spare parts
503043700186	BRACKET ASSY ABS MODULATOR MTG	TATA spare parts

503043700199	AIR COMPRESSOR ASSY	TATA spare parts
503043700207	AIR TANK ASSY	TATA spare parts
503043707101	PLATE AIR TANK MTG	TATA spare parts
503043900104	ASSY.NY.PIPE SET CHASSIS COMPL-2518/VOSS	TATA spare parts
503043900113	ASSY.NY.PIPE SET CHASSIS COMPL-2518	TATA spare parts
503043900136	ASSY. NYLON PIPE SET CHASSIS-2518TC	TATA spare parts
503043900198	ASSY NYLON PIPE DDU-4 TO COMPRESSOR	TATA spare parts
503043903301	BRACKET FRONT HOSE MTG DIA.15	TATA spare parts
503043903302	BRACKET HOSE MTG DIA.13	TATA spare parts
503043903305	BRACKET HOSE MTG LONG MEMBER RH	TATA spare parts
503043903306	BRACKET FOR NYLON PIPE MTG	TATA spare parts
503043903314	BRACKET	TATA spare parts
503043910105	ASSY COMP.PIPE 3RD	TATA spare parts
503043910162	2ND METAL PIPE JOINT 1 TO 2	TATA spare parts
503043930177	PIPE ASSY BUNCH COMPLETE	TATA spare parts
503043940139	PIPE ASSY BUNCH	TATA spare parts
503043940170	PIPE ASSY BUNCH	TATA spare parts
503043950106	PIPE ASSY	TATA spare parts
503043950107	PIPE ASSY	TATA spare parts
503043950108	PIPE ASSY.SECOND METAL PIPE	TATA spare parts
503043950109	PIPE ASSY INT JOINT TO INT JOINT	TATA spare parts
503043950111	BUNCH ASSY PIPE	TATA spare parts
503043950128	PIPE BUNCH ASSY	TATA spare parts
503043950142	BUNCH ASSY PIPE	TATA spare parts
503043950144	PIPE BUNCH ASSY	TATA spare parts
503043960101	PIPE BUNCH ASSY	TATA spare parts
503043960117	PIPE BUNCH ASSY	TATA spare parts
503043960130	METAL PIPE ASSY	TATA spare parts
503043960134	METAL PIPE ASSY	TATA spare parts
503043960185	PIPE BUNCH ASSY	TATA spare parts
503043990102	SYSTEM PROTCTION VALVE REPAIR KIT BS6	TATA spare parts
503046100106	STEERING GEAR BOX ASSY	TATA spare parts
503046100107	ASSY. STEERING GEAR BOX BS3/4	TATA spare parts
503046304102	PITMAN ARM	TATA spare parts
503046304103	PITMAN ARM	TATA spare parts
503046305101	PITMAN ARM	TATA spare parts
503046600101	ASSY. POWER STEERING PUMP BS3/4	TATA spare parts
503046600104	ASSY. STG. PLASTIC RESERVOIR	TATA spare parts
503046600105	ASSY. STG. PLASTIC RESERVOIR BS1/2/3/4	TATA spare parts
503046600106	POWER STEERING GEAR BOX ASSY	TATA spare parts
503046600107	KIT-FILTER BS1/2/3/4/6	TATA spare parts
503046600108	HOUSING ASSY	TATA spare parts
503046600109	PISTON ASSY.	TATA spare parts
503046600110	FILTER ASSY	TATA spare parts
503046800101	ASSY.PIPE LINES CLAMPS & BKTS	TATA spare parts
503046800102	ASSY.PIPES CLAMPS & BKTS	TATA spare parts
503046800104	ASSY.PRES.PIPE PUMP TO GB	TATA spare parts



503046800105	ASSY RETN PIPE(GB TO RESERVOIR)	TATA spare parts
503046800109	ASSY. SUCT. PIPE (TANK TO PUMP)	TATA spare parts
503046800110	ASSY.PRES.PIPE LINE (PUMP TO GB)	TATA spare parts
503046800111	ASSY.RETURN PIPE LINE (GB TO TANK)	TATA spare parts
503046800112	ASSY.PRES.PIPE LINE (PUMP TO GB)	TATA spare parts
503046800113	ASSY.RETURN PIPE LINE (GB TO TANK)	TATA spare parts
503046803301	TWISTED BRACKET	TATA spare parts
503046803302	BRACKET	TATA spare parts
503046900101	DRAG LINK ASSY FRONT BS6	TATA spare parts
503046990101	KIT-FILTER BS4	TATA spare parts
503046990102	HOUSING ASSY	TATA spare parts
503046990103	KIT-CAP	TATA spare parts
503046990104	KIT-SHELL	TATA spare parts
503046990105	ASSY. FILTER STEERING RESERVIOR BS2/3	TATA spare parts
503046990111	HOUSING ASSY	TATA spare parts
503046990112	KIT-SEAL INPUT SHAFT	TATA spare parts
503046990113	WORM & RACK ASSY	TATA spare parts
503046990114	MAJOR KIT-SEAL BS6	TATA spare parts
503046990116	VALVE HSG ASSY LH BS6	TATA spare parts
503046990118	MINOR KIT-SEAL BS6	TATA spare parts
503046997503	BREATHER RUBBER	TATA spare parts
503047100102	FUEL TANK ASSY RIVIGO	TATA spare parts
503047100103	FUEL TANK ASSY WITH BAFFLES	TATA spare parts
503047107201	BANJO BOLT	TATA spare parts
503047600110	SUCTION LINE (FUEL TANK TO FILTER)	TATA spare parts
503047600111	SUCTION LINE (FUEL FILTER TO ENG)	TATA spare parts
503047600112	ASSY RETURN LINE (FUEL TANK TO ENG)	TATA spare parts
503047600113	SUCTION PIPE ASSY FUEL FILTER TO ENGINE	TATA spare parts
503047600116	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
503047600117	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
503047600118	SUCTION PIPE TANK TO FILTER 1 RIVIGO	TATA spare parts
503047600119	RETURN PIPE ENG TO FUEL TANK 1 RIVIGO	TATA spare parts
503047600120	BRACKET (FUEL FILTER MTG.)	TATA spare parts
503047600122	SUCTION LINE (FUEL FILTER TO ENG)	TATA spare parts
503047600123	ASSY RETURN LINE (FUEL TANK TO ENGINE)	TATA spare parts
503047600125	PIPE ASSY TANK TO INT JOINT 1 RIVIGO	TATA spare parts
503047600126	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
503047600127	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
503047600128	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
503047600133	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
503047600134	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
503047600135	FUEL RETURN PIPE ASSY	TATA spare parts
503047600139	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
503047600140	SUCTION FUEL PIPE W/SEP TO FIP	TATA spare parts
503047600142	FUEL INTER CONNECTION PIPE ASSY	TATA spare parts
503047600143	FUEL TANK INTER CONNECTION HOSE ASSY	TATA spare parts
503047700102	BRACKET ASSY FUEL FILTER MTG	TATA spare parts

503047700103	HEAD & FUEL WATER SEPARATOR ASSY	TATA spare parts
503047709901	FUEL WATER SEPARATOR	TATA spare parts
503049200104	ASSY.EXHAUST THIRD PIPE	TATA spare parts
503049200110	ASSY.EXHAUST PIPE-FIRST(TURBO-EXH.BRAKE)	TATA spare parts
503049200111	ASSY.EXHAUST PIPE-SECOND(EX/BRKT OUTLET)	TATA spare parts
503049200112	ASSY. EXHAUST PIPE-THIRD(TO SILENCER)	TATA spare parts
503049200113	ASSY.HEAT SHIELD	TATA spare parts
503049200122	HEAT SHIELD ASSY	TATA spare parts
503049200123	EXHAUST PIPE ASSY- INTERMEDIATE	TATA spare parts
503049200126	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
503049200127	BRACKET ASSY UREA TANK & DOSING UNIT MTG	TATA spare parts
503049200129	BRACKET ASSY EGP MTG	TATA spare parts
503049200130	BRACKET ASSY EGP MTG	TATA spare parts
503049200131	BRACKET ASSY TAIL PIPE MTG	TATA spare parts
503049200132	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
503049200133	PIPE ASSY T-CONNECTOR TO AIR OIL FILTER	TATA spare parts
503049200135	PIPE ASSY AIR OIL FILTER TO DU	TATA spare parts
503049200150	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
503049203302	BRACKET (TAIL PIPE MTG.)	TATA spare parts
503049203303	BRACKET EXHAUST PIPE MTG	TATA spare parts
503049203305	BRACKET (EXHAUST PIPE CLAMPING)	TATA spare parts
503049203306	BRACKET (TAIL PIPE CLAMPING)	TATA spare parts
503049203311	BRACKET NOX SENSOR MTG	TATA spare parts
503049203312	BRACKET EXHAUST PIPE CLAMPING	TATA spare parts
503049203313	BRACKET AIR OIL SEPARATOR MTG	TATA spare parts
503049206922	TAIL PIPE BS4	TATA spare parts
503049605306	HEAT SHIELD SILENCER	TATA spare parts
503049605307	HEAT SHIELD SILENCER	TATA spare parts
503049990102	KIT-HEAT SHIELD FOR SILENCER & EXH PIPE	TATA spare parts
503054100104	ASSY. BATT.CABLE 50 SQ.MM WITH MEGA FUSE	TATA spare parts
503054100118	CABLE ASSY BATTERY-VE	TATA spare parts
503054100119	BATTERY CABLE NEGATIVE	TATA spare parts
503054100120	CABLE ASSY BATTERY +VE	TATA spare parts
503054100121	BATTERY +VE CABLE ASSY	TATA spare parts
503054200106	DISPLAY UNIT	TATA spare parts
503054209901	INST. CLUSTER (ELECT.) (0.88)	TATA spare parts
503054209902	INST. CLUSTER (ELECT.) (0.93)	TATA spare parts
503054209903	INST.CLUSTER (ELECT.)(0.88)	TATA spare parts
503054209904	INST.CLUSTER (ELECT.)(0.93)	TATA spare parts
503054209912	WATER IN FUEL INDICATOR	TATA spare parts
503054209913	PRESSURE TRANSDUCER	TATA spare parts
503054304901	AIR PRESSURE TRANSDUCER	TATA spare parts
503054441601	ASSY WARNING LAMP IND(24V)	TATA spare parts
503054501602	SWITCH DUMMY KNOB	TATA spare parts
503054504901	NEUTRAL SWITCH	TATA spare parts
503054600103	WIRING HARNESS ABS FRAME	TATA spare parts
503054600112	WIRING HARNESS TAIL	TATA spare parts

503054600131	WIRING HARNESS ABS FRAME	TATA spare parts
503054600132	WIRING HARNESS ABS SPLIT	TATA spare parts
503054600133	WIRING HARNESS ABS FRAME	TATA spare parts
503054600134	WIRING HARNESS ABS	TATA spare parts
503054600135	WIRING HARNESS TAIL	TATA spare parts
503054600138	WIRING HARNESS ABS FRAME	TATA spare parts
503054600139	WIRING HARNESS ABS FRAME	TATA spare parts
503054600140	WIRING HARNESS ABS SPLIT	TATA spare parts
503054600143	WIRING HARNESS RSL VSS SPLIT	TATA spare parts
503054600144	WIRING HARNESS RSL VSS SPLIT	TATA spare parts
503054600145	WIRING HARNESS RSL MOTOR	TATA spare parts
503054600146	WIRING HARNESS RSL MOTOR	TATA spare parts
503054600148	WIRING HARNESS ABS FRAME	TATA spare parts
503054600149	WIRING HARNESS RSL VSS FRAME	TATA spare parts
503054600150	WIRING HARNESS RSL VSS FRAME	TATA spare parts
503054600151	WIRING HARNESS ASSY MAIN	TATA spare parts
503054600152	WIRING HARNESS ASSY MAIN	TATA spare parts
503054600182	WIRING HARNESS MAIN BS4	TATA spare parts
503054600191	WIRING HARNESS TAIL	TATA spare parts
503054600192	WIRING HARNESS MAIN	TATA spare parts
503054600193	WIRING HARNESS FRONT	TATA spare parts
503054600194	WIRING HARNESS AMT	TATA spare parts
503054600195	WIRING HARNESS ABS SPLIT	TATA spare parts
503054600196	WIRING HARNESS SCR UNIT	TATA spare parts
503054600197	WIRING HARNESS ENGINE	TATA spare parts
503054601667	WIRING HARNESS TAIL	TATA spare parts
503054601687	WIRING HARNESS SCR UNIT RIVIGO	TATA spare parts
503054601691	"WIRING HARNESS,SCR UNIT"	TATA spare parts
503054601692	WIRING HARNESS MAIN	TATA spare parts
503054610101	WIRING HARNESS TAIL	TATA spare parts
503054611607	WIRING HARNESS TAIL	TATA spare parts
503054611609	WIRING HARNESS MAIN	TATA spare parts
503054611610	WIRING HARNESS TAIL	TATA spare parts
503054611611	WIRING HARNESS ENGINE	TATA spare parts
503054620101	WIRING HARNESS MAIN - TLT CAB WIT	TATA spare parts
503054620102	WIRING HARNESS TAIL - TLT CAB - M	TATA spare parts
503054620103	WIRING HARNESS ENGINE - TLT CAB	TATA spare parts
503054620115	WIRING HARNESS ABS FRAME	TATA spare parts
503054620133	WIRING HARNESS INST. CONSOLE	TATA spare parts
503054620138	W/H PIGTAIL FOR WIPER MOTOR	TATA spare parts
503054620142	W/H TAIL LPT2518TC 48WB BSIII COWL 6X2	TATA spare parts
503054620143	W/H TAIL LPT2518TC(60/62WB) BSIII COWL	TATA spare parts
503054620146	W/H MAIN LPT2518TC BSIII 24V	TATA spare parts
503054620147	W/H TAIL LPT2518TC 48WB BSIII COWL	TATA spare parts
503054620160	WIRING HARNESS TAIL LPT1613TC/42WB BSIII	TATA spare parts
503054620163	W/H TAIL LPT1613TC/52 BSIII CWL 60PERC R	TATA spare parts
503054620175	WIRING HARNESS MAIN BS4	TATA spare parts

503054620178	WIRING HARNESS RSL	TATA spare parts
503054620179	WIRING HARNESS ASSY MAIN	TATA spare parts
503054620188	WIRING HARNESS ASSY MAIN	TATA spare parts
503054620192	WIRING HARNESS PARK BRAKE SWITCH	TATA spare parts
503054620193	"WIRING HARNESS,SCR UNIT"	TATA spare parts
503054620194	"WIRING HARNESS,TAIL"	TATA spare parts
503054660129	WIRING HARNESS TAIL	TATA spare parts
503054660136	W/H PIGTAIL FOR WIPER MOTOR	TATA spare parts
503054660139	W/H TAIL LPT2518TC 48WB BSIII COWL 6X4 E	TATA spare parts
503054660145	W/H TAIL LPT2518TC/48WB BSIII COWL	TATA spare parts
503054690108	W/H MAIN LPT2518TC BSIII 24V	TATA spare parts
503054690117	WIRING HARNESS TAIL LPT2518TC BSIII 55WB	TATA spare parts
503054700190	PLATE ASSY MOTOR MTG	TATA spare parts
503054700191	PLATE ASSY MOTOR MTG	TATA spare parts
503054707101	PLATE SPEED LIMITER DEVICE MOTOR MTG	TATA spare parts
503054707103	PLATE SPEED LIMITER DEVICE MOTOR MTG	TATA spare parts
503054709901	STICKER	TATA spare parts
503054900108	BRKT ASSY DOSING CONTROLLER UNIT MTG BS6	TATA spare parts
503058903501	SOCKET / RA 109 THU	TATA spare parts
503131200102	ASSY.CROSS MEMBER NO.7 - ADD C/M	TATA spare parts
503131200103	ASSY.CROSS MEMBER NO.9 - RSB REAR	TATA spare parts
503131200104	ASSY.BRACKET -RH RADIATOR MTG	TATA spare parts
503131200105	ASSY.BRACKET -LH RADIATOR MTG.	TATA spare parts
503131200106	SUB ASSY. 6TH CROSS MEMBER(SPRING C/M)	TATA spare parts
503131207104	6TH CROSS MEMBER (SPRING C/M REAR-FRONT)	TATA spare parts
503131208201	END CROSS MEMBER	TATA spare parts
503131307105	SUPPORT-TOP (REAR SPRING C/M)	TATA spare parts
503131307106	GUSSET BOTTOM	TATA spare parts
503133000101	ASSY FRONT AXLE COMP WITH BRAKES	TATA spare parts
503141100102	ASSY.PROP.SHAFT FRONT	TATA spare parts
503143700103	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
503154660101	W/H MAIN-LPT2116 697 E-II	TATA spare parts
503154660102	W/H TAIL-LPT2116 697 E-II	TATA spare parts
503154660103	W/H ENGINE-LPT2116/1616 697 E-II	TATA spare parts
50320148000LCK	ASSY CAB KIT FOR LPTA 2445	TATA spare parts
503216172001	CONTROLLER	TATA spare parts
503224103701	ENG.MTG.BKT.FRT.FRAME LH	TATA spare parts
503224103702	ENG.MTG.BKT.FRT.FRAME RH	TATA spare parts
503224103705	BRACKET ENGINE ARM FRONT-LH	TATA spare parts
503224103706	BRACKET ENGINE ARM FRONT-RH	TATA spare parts
503224103707	BRACKET ENGINE MTG FRONT FRAME LH	TATA spare parts
503224103708	BRACKET ENGINE MTG FRONT FRAME RH	TATA spare parts
503224200102	ASSY. BRACKET	TATA spare parts
503224200103	ASSY. BRACKET - RH (ENG.MTG. REAR BOTTOM	TATA spare parts
503224200109	ASSY MTG BKT LH (ENG.MTG. TOP - REAR)	TATA spare parts
503224200110	ASSY. BRACKET - R.H (ENG.MTG. TOP - REAR	TATA spare parts
503224200117	RUBBER MOUNT REAR	TATA spare parts

503224203701	BRACKET ENGINE MTG REAR-LH	TATA spare parts
503224203702	BRACKET ENGINE MTG REAR-RH	TATA spare parts
503224500101	BRACKET TRANSMISSION FRAME SIDE LH	TATA spare parts
503224500102	BRACKET TRANSMISSION FRAME SIDE RH	TATA spare parts
503224500103	TUBE ASSY	TATA spare parts
503226806901	PIPE	TATA spare parts
503226806902	PIPE	TATA spare parts
503226807101	MOUNTING BRACKET (SOLENOID VALVE)	TATA spare parts
503226807102	MOUNTING BRACKET (PRESSURE REGULATOR)	TATA spare parts
503226807103	BELLOW MOUNTING PLATE	TATA spare parts
503226807701	GAITER GEAR SHIFT LEVER	TATA spare parts
503228500101	ASSY AGB MTG BKT-LH	TATA spare parts
503228500102	AGB MTG BKT LOWER-LH	TATA spare parts
503228500102AE	AGB MTG BKT LOWER-LH 1628	TATA spare parts
503228500103	AGB MOUNTING BRACKET	TATA spare parts
503228500103AE	AGB MNTNG BRACKET 1628	TATA spare parts
503228500104	ASSY AGB MTG BKT-RH	TATA spare parts
503228500104AE	ASSY AGB MTG BKT-RH 1628	TATA spare parts
503228500105	AGB MTG BKT LH SIDE	TATA spare parts
503228500106	AGB MTG BKT LOWER RH	TATA spare parts
503228500107	AGB MTG BKT RH SIDE	TATA spare parts
503228500108	ASSY. BAR AGB MTG	TATA spare parts
503228500108AE	ASSY. BAR AGB MTG 1628	TATA spare parts
503228500110	ASSY BRACKET - LH (TC-2500 MTG. LOWER)	TATA spare parts
503228500111	ASSY BRACKET (AGB MTG)	TATA spare parts
503228500114	ASSY BRACKET - RH (FOR AGB MOUNTING)	TATA spare parts
503228506701	PIN (AGB MTG)	TATA spare parts
503228507114	SPACER AGB MTG. LOWER	TATA spare parts
503229000101	INTEGRATED PEDAL UNIT	TATA spare parts
503231000105	FRAME COMPLETE	TATA spare parts
503231000121	FRAME ASSY WITH FITMENT	TATA spare parts
503231107113	REINFORCEMENT- LH	TATA spare parts
503231107114	REINFORCEMENT- RH	TATA spare parts
503231107115	REAR REINFORCEMENT- LH	TATA spare parts
503231107116	REAR REINFORCEMENT- RH	TATA spare parts
503231200115	CROSS MEMBER ASSY	TATA spare parts
503231200117	ASSY. END CROSS MEMBER COMPLETE	TATA spare parts
503231207112	CROSS MEMBER BRACKET	TATA spare parts
503231208210	SPACER	TATA spare parts
503231208211	SPACER	TATA spare parts
503231307101	GUSSET UPPER 4TH CROSS MEMBER	TATA spare parts
503231307102	GUSSET LWR FOR 4TH C.M.	TATA spare parts
503231307111	GUSSET UPPER-LH (CROSS MEMBER)	TATA spare parts
503231307112	GUSSET LOWER-LH (CROSS MEMBER)	TATA spare parts
503231307113	GUSSET LOWER-RH (CROSS MEMBER)	TATA spare parts
503231307114	GUSSET UPPER-RH (CROSS MEMBER)	TATA spare parts
503231307118	GUSSET FOR CM ASSY	TATA spare parts

503231540101	BATTERY SUPPORT ASSY	TATA spare parts
503231540106	BATTERY BOX ASSY INFO FITMENT DRAWING	TATA spare parts
503231600109	ASSY TOOL BOX COMPLETE	TATA spare parts
503231700103	WATER TANK COMPLETE (100 LIT.)	TATA spare parts
503231700104	ASSY. SUPPORT BRACKET (WATER TANK MTG.)	TATA spare parts
503231700140	WATER TANK COMPLETE (100 LIT.)	TATA spare parts
503231700141	STRAP ASSY	TATA spare parts
503231706702	PIN (WATER TANK MTG)	TATA spare parts
503231707701	RUBBER PACKING (WATER TANK)	TATA spare parts
503231707702	RUBBER PACKING (WATER TANK MTG.)	TATA spare parts
503231707704	RUBBER PACKING	TATA spare parts
503232100102	ASSY. FRONT SPRING	TATA spare parts
503232100102AE	ASSY. FRONT SPRING 1828	TATA spare parts
503232100111	1ST LEAF ASSY WITH BUSH	TATA spare parts
503232100115	FRONT SPRING ASSY	TATA spare parts
503232103203	CENTER BOLT	TATA spare parts
503232103301	SPRING HANGER BRACKET -LH (FRONT)	TATA spare parts
503232103301AE	BRKT-FRT SPRING FRT 1628	TATA spare parts
503232103302	SPRING HANGER BRACKET -LH (SHACKLE SIDE)	TATA spare parts
503232103302AE	SPRNG HANGER BRKT FR-L -1628	TATA spare parts
503232103303	SPRING HANGER BRACKET -RH (SHACKEL SIDE)	TATA spare parts
503232103303AE	BRKT-FRT SPRING RR LH 1628	TATA spare parts
503232104203	U-BOLT	TATA spare parts
503232104205	SPRING CLIP	TATA spare parts
503232104206	U-BOLT	TATA spare parts
503232105103	SADDLE RH	TATA spare parts
503232105104	SADDLE LH	TATA spare parts
503232107101	SPACER(BETWEEN AXLE-FRONT SPRING)	TATA spare parts
503232107107	CASTER PLATE	TATA spare parts
503232107109	2ND LEAF	TATA spare parts
503232107110	3RD LEAF	TATA spare parts
503232107112	SPACER	TATA spare parts
503232107113	SPACER FRONT SPRING	TATA spare parts
503232108601	CENTER LINER	TATA spare parts
503232204201	U-BOLT (LENGTH -380 MM)	TATA spare parts
503232204202	U BOLT	TATA spare parts
503232204203	U-BOLT	TATA spare parts
503232300101	ASSY SA BRK LH(TOP)	TATA spare parts
503232300102	ASSY SA BRK RH(TOP)	TATA spare parts
503232300103	SA BOTTOM BRK- LH	TATA spare parts
503232300103AE	SA BTTM BRKT LH-(ON AXLE) -1628	TATA spare parts
503232300104	SA BOTTOM BRK-RH	TATA spare parts
503232300104AE	SA BTTM BRKT RH-(ON AXLE) -1628	TATA spare parts
503232303201	PIN(SA BOTTOM MOUNTING)	TATA spare parts
503232303201AE	PIN(SA BOTTOM MNTNG) 1628	TATA spare parts
503232400105	ASSY ADAPTER PLATE (REAR FWD)	TATA spare parts
503232400106	ASSEMBLY ADAPTER PLATE(REAR RWD)	TATA spare parts

503232403201	HEX FL BOLT M20X2.5X60	TATA spare parts
503232403202	HEX FL BOLT M18X2.5X65	TATA spare parts
503232403203	HEX FL BOLT M14X2X45	TATA spare parts
503232403301	BRACKET - RH (TORQUE ROD AND REAR RWD AX	TATA spare parts
503232403302	BRACKET -LH (TORQUE ROD-RWD)	TATA spare parts
503232403303	BRACKET -RWD AXLE (V-ROD)	TATA spare parts
503232403304	BRACKET -FWD AXLE (V-ROD)	TATA spare parts
503232803301	BRACKET STABILIZER- AXLE	TATA spare parts
503232807101	ROD STABILIZER	TATA spare parts
503240100101	TYRE AND WHEEL RIM ASSY	TATA spare parts
503240100106	TYRE ASSY WITH WHEEL RIM AND BEADLOCK SY	TATA spare parts
503240100111	PIPE ASSY	TATA spare parts
503240100129	BEADLOCK SYSTEM	TATA spare parts
503240300118	ASSY SPARE WHEEL LIFTING UNIT	TATA spare parts
503240300128	SUPPORT ASSY	TATA spare parts
503240300132	ASSY.SPARE WHEEL MTG.BKT.	TATA spare parts
503240300147	ASSY. HUB COVER	TATA spare parts
503240300170	SWC ACTUATION UNIT	TATA spare parts
503240300204	BRACKET ASSY	TATA spare parts
503240307501	NYLON BELT WITH RATCHET W-50 L-2500	TATA spare parts
503240990109	KIT FOR SPARE WHEEL MOUNTING STR	TATA spare parts
503241110101	UNIT PACK	TATA spare parts
503241115101	FLANG EYOKE	TATA spare parts
503241120101	ASSY.PROP.SHAFT (G.B. TO T.C.)	TATA spare parts
503241120102	ASSY. PROP. SHAFT (T.C. TO. REAR FWD AXL	TATA spare parts
503241120103	ASSY. PROP SHAFT (T.C. TO FRONT AXLE)	TATA spare parts
503241120103AE	ASSY. PROP SFT TC TO FA -1628	TATA spare parts
503241120104	ASSY PROP. SHAFT (G.B. TO T.C.)	TATA spare parts
503241120109	LONG FORK SUB ASSY 180 SLIP BS6	TATA spare parts
503241120114	PROPELLER SHAFT ASSY AGB TO REAR AXLE	TATA spare parts
503241120115	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
503241120127	PROPELLER SHAFT ASSY GB TO AGB	TATA spare parts
503241120130	PROPELLER SHAFT ASSY AGB TO REAR AXLE	TATA spare parts
503241120132	4TH PROPELLER SHAFT ASSY	TATA spare parts
503241990107	SHORT FORK TUBE & REAR HSG SUB ASSY	TATA spare parts
503241990108	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
503241990109	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
503242308601	CONNECTOR-SPRING BRAKE ACTUATOR	TATA spare parts
503243200105	SUB ASSY. AIR TANK RH (C.D. 320)	TATA spare parts
503243200106	SUB ASSY. AIR TANK LH (C.D. 320)	TATA spare parts
503243200112	SUB. ASSY. AIR TANK (CD 466)	TATA spare parts
503243200113	AIR TANK ASSY (40LX2+30)	TATA spare parts
503243200118	ASSY.BRACKER( FOR AIR TANK MTG.)	TATA spare parts
503243200119	SUB ASSY. AIR TANK RH	TATA spare parts
503243200123	ASSY.BRACKER( FOR AIR TANK MTG.)	TATA spare parts
503243200124	SUB ASSY. AIR TANK RH (C.D. 300)	TATA spare parts
503243208211	SUPPORT CHANNEL AIR TANK MTG.	TATA spare parts

503243208601	SPACER AIR TANK MTG BKT	TATA spare parts
503243400101	ASSY. BRACKET-LCRV LINK MTG.	TATA spare parts
503243400102	ASSY. BRACKET-LCRV LINK MTG.	TATA spare parts
503243403304	BRACKET-LCRV MTG.	TATA spare parts
503243700112	ASSY. BRACKET-APU MTG.	TATA spare parts
503243703301	BRACKET-TRAILER CONTROL VALVE MTG	TATA spare parts
503243703305	BRACKET-RELAY VALVE MTG	TATA spare parts
503243708201	ASSY BRACKET-APU MTG.	TATA spare parts
503243900162	ASSY. SECOND METAL PIPE COMP. TO APU	TATA spare parts
503243900163	ASSY. THIRD METAL PIPE COMPRESSOR TO APU	TATA spare parts
503243910106	PIPE ASSY THIRD COMPRESSOR TO APU	TATA spare parts
503243910107	PIPE ASSY SECOND COMPRESSOR TO APU	TATA spare parts
503243910108	PIPE ASSY COMP OUTLET FIRST METAL PIPE	TATA spare parts
503243910111	NYLON PIPE ASSY SET COMPLETE	TATA spare parts
503243920170	ASSY. METAL PIPE WITH CRIMPED HOSE -18OD	TATA spare parts
503243920171	ASSY. SECOND METAL PIPE COMP. TO APU -	TATA spare parts
503243920172	ASSY. THIRD METAL PIPE COMPRESSOR TO AP	TATA spare parts
503243930170	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
503243990124	PIPE ASSY SECOND COMP. TO APU	TATA spare parts
503243990125	METAL PIPE ASSY DCV TO APU	TATA spare parts
503243990128	PIPE ASSY	TATA spare parts
503245100107	HOSE AXLE TO CTIS VALVE	TATA spare parts
503245100116	HOSE CTIS VALVE TO TUBE VALVE FRONT	TATA spare parts
503245100123	HOSE ASSY CTIS VALVE TO TUBE VALVE	TATA spare parts
503245100128	ASSY PIPE PTO TO SOLENOID	TATA spare parts
503245100137	ASSY PIPE (PRV TO PCU)	TATA spare parts
503245110139	NYLON PIPE BUNCH	TATA spare parts
503245110140	NYLON PIPE BUNCH	TATA spare parts
503245300108	ASSY. KIT (TELEFLOW PARTS) 6X6	TATA spare parts
503245300115	SET CTIS TUBES	TATA spare parts
503245303302	BRACKET BREATHER MTG	TATA spare parts
503245307106	MOUNTING BRACKET (CTIS) 6X6	TATA spare parts
503245307112	PCU 6X6	TATA spare parts
503245307118	EXHAUST HOSE FROM PCU OF CTIS	TATA spare parts
503245307120	ASSY. HOSE CTIS VALVE TO TUBE VALVE (TEL	TATA spare parts
503245307130	WIRING HARNESS	TATA spare parts
503245309901	EXHAUST HOSE	TATA spare parts
503245990101	KIT-HOSES & CONNECTORS (SOLENOID & DIFF)	TATA spare parts
503245990102	KIT-HOSES & PIPES FOR CTIS	TATA spare parts
503245990103	KIT- HOSES & PIPES & BREATHERS	TATA spare parts
503246304101	PITMAN ARM	TATA spare parts
503246304105	PITMAN ARM	TATA spare parts
503246305103	PITMAN ARM	TATA spare parts
503246600108	STEERING GEAR BOX ASSY LH	TATA spare parts
503246600109	BRACKET FLOW CONTROL VALVE MTG	TATA spare parts
503246600110	VALVE BLOCK	TATA spare parts
503246600111	VANE PUMP ASSY	TATA spare parts



503246603301	OIL RESERVIOR MTG BKT	TATA spare parts
503246603304	BRACKET HYD TANK MTG -	TATA spare parts
503246703302	CABIN TILTING HYDRAULIC CYLINDER MOUNTIN	TATA spare parts
503246708002	HEX SCR M20X1.5X45 GRADE (IS13725)	TATA spare parts
503246800104	ASSY. 1/2IN R2 HOSE PRESSURE LINE	TATA spare parts
503246800105	RETURN LINE HOSE ASSY	TATA spare parts
503246800106	ASSY.¿ RETURN LINE	TATA spare parts
503246800107	SUCTION LINE¿ HOSE ASSY	TATA spare parts
503246803301	BRACKET STEERING PIPE CLAMP BS6	TATA spare parts
503246803303	BRACKET STEERING PIPE CLAMP	TATA spare parts
503246900101	DRAG LINK ASSY LH	TATA spare parts
503246990102	ASSY. KIT FOR STEERING PIPE	TATA spare parts
503247100118	MAIN BODY (SEAM WELDED) RH 260 LTRS	TATA spare parts
503247500101	ASSY SUPPORT 1(RECT. FUEL TANK 400 LTR.)	TATA spare parts
503247500104	MTG.(RECT. FUEL TANK 400 LTR.)	TATA spare parts
503247500105	ASSY.WEBASTO HEATER MTG BKT.1	TATA spare parts
503247500106	ASSY.WEBASTO HEATER MTG.BKT.2	TATA spare parts
503247500109	ASSY.SUPPORT II(RECT.FUEL TANK 400 LTR.)	TATA spare parts
503247600102	FUEL PIPE SUCTION W/SEP TO ENGINE	TATA spare parts
503247600104	ASSY.FUEL SUCTION LINE-F/TANK TO W/S	TATA spare parts
503247600105	ASSY.FUEL SUCTION LINE-W/S TO ENGINE	TATA spare parts
503247600106	ASSY.FUEL RETURN LINE-ENGINE TO F/TANK	TATA spare parts
503247600107	ASSY FUEL SUCTION LINE-F/TANK TO W/S	TATA spare parts
503247600109	ASSY FUEL RETURN LINE-ENGINE TO F/TANK	TATA spare parts
503247600127	ASSY FUEL SUCTION LINE-W/S TO ENGINE	TATA spare parts
503247600144	FUEL SUCTION PIPE FUEL TANK TO P/FILTER	TATA spare parts
503247600146	FUEL PIPE ASSY RETURN LINE	TATA spare parts
503247700101	ASSY BRACKET FUEL FILTER MTG	TATA spare parts
503249100127	ASSY.SUPPORT BKT. FOR SILENCER MTG.	TATA spare parts
503249100128	ASSY. EXHAUST MUFFLER	TATA spare parts
503249100130	ASSY. EXHAUST SECOND PIPE	TATA spare parts
503249109912	HEAT SHIELD SILENCER -	TATA spare parts
503249200102	ASSEMBLY EXHAUST PIPE FIRST	TATA spare parts
503249200105	BRACKET ASSY PIPE	TATA spare parts
503249200106	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
503249200107	BRACKET ASSY	TATA spare parts
503249200109	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
503249200110	TAIL PIPE ASSY -	TATA spare parts
503249200113	BRACKET ASSY	TATA spare parts
503249200115	BRACKET ASSY PIPE	TATA spare parts
503249203306	L-BRACKET EXHAUST PIPE MTG	TATA spare parts
503249204201	U-BOLT	TATA spare parts
503249207101	BRACKET SUPPORT(EXHAUST PIPE)	TATA spare parts
503252200101	ASSY.REAR FRONT FENDER MTG.	TATA spare parts
503252200105	ASSY BRACKET REAR FRONR FENDER MTG.	TATA spare parts
503252200106	ASSY BRACKET-LH(FENDER MTG REAR REAR)	TATA spare parts
503252200107	ASSY BRACKET-LH(FENDER MTG REAR FRT)	TATA spare parts

503252200108	ASSY BRACKET-RH(FENDER MTG REAR FRT)	TATA spare parts
503252200109	ASSY BRACKET-RH(FENDER MTG REAR REAR)	TATA spare parts
503254100103	ASSY STRUCTURE OF BATTERY CARRIER	TATA spare parts
503254100104	ASSY BATTERY CABLE +VE (FROM BATT CUT OF	TATA spare parts
503254100105	ASSY BATTERY CABLE -VE (FROM BATT CUT OF	TATA spare parts
503254100106	ASSY BATT CABLE +VE (FROM BATT TO CUT OF	TATA spare parts
503254100107	ASSY BATT CABLE -VE (FROM BATT TO CUT OF	TATA spare parts
503254100122	ASSY.COPPER BATT. CABLE (+ VE) RED	TATA spare parts
503254100123	ASSY BATTERY CABLE -VE	TATA spare parts
503254108205	STUD	TATA spare parts
503254109901	SOCKET FOR LPTA2038 6X6 MFU	TATA spare parts
503254109902	PLUG FOR LPTA2038 6X6 MFU	TATA spare parts
503254109904	SOCKET FOR LPTA20386X6MFU & LPTA3138 8X8	TATA spare parts
503254209901	AIR PRESSURE TRANSDUCER	TATA spare parts
503254209902	INSTRUMENT CLUSTER LPTA2038TC 6X6 VEHICL	TATA spare parts
503254500103	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
503254600102	WIRING HARNESS SIDE MARKER	TATA spare parts
503254600103	WIRING HARNESS SIDE MARKER	TATA spare parts
503254600106	REMOTE THROTTLE ASSY	TATA spare parts
503254606301	COVER FOR W/H	TATA spare parts
503254606302	FRONT COVER FOR W/H	TATA spare parts
503254606303	COVER FOR FUEL TANK WIRE	TATA spare parts
503254608203	MAXI FUSE MTG BKT	TATA spare parts
503254608204	ENG LAMP MTG BKT	TATA spare parts
503254608206	FUEL TANK W/H COVER MTG. BKT	TATA spare parts
503254610103	WIRING HARNESS MAIN	TATA spare parts
503254610104	WIRING HARNESS BUMPER	TATA spare parts
503254610108	WIRING HARNESS ROOF	TATA spare parts
503254610109	WIRING HARNESS SWITCH	TATA spare parts
503254620109	WIRING HARNESS ENGINE	TATA spare parts
503254630106	WIRING HARNESS ABS	TATA spare parts
503254630107	WIRING HARNESS TAIL	TATA spare parts
503254630108	WIRING HARNESS ATU	TATA spare parts
503254640109	JUMP START SOCKET BATTERY+ TO JUMP START	TATA spare parts
503254640110	JUMP START SOCKET BATTERY-TO JUMP START	TATA spare parts
503254640113	JUMPER CABLE ASSY	TATA spare parts
503254660101	WH MAIN LPTA2038TC 6X6	TATA spare parts
503254660102	WH TAIL LPTA2038TC 6X6	TATA spare parts
503254660103	W/H TAIL LPTA2038 6X6 CGT	TATA spare parts
503254660104	WH ENGINE LPTA2038 6X6	TATA spare parts
503254660105	WIRING HARNESS Y-PIGTAIL	TATA spare parts
503254660105AE	WH Y-PIGTAIL 1628	TATA spare parts
503254680101	WH Y-PIGTAIL M/S SAN ELECTROMECH	TATA spare parts
503254900101	BRACKET ASSY TCU UNIT MTG	TATA spare parts
503256000101	ASSY WINCH 12T H100S	TATA spare parts
503256000114	BRACKET ASSY CONTROL VALVE MTG	TATA spare parts
503256200101	3/4IN R2 BSP ST BOTH END HOSE	TATA spare parts

503256200104	ASSY. HYD. PISTON PUMP 6X6 BS3	TATA spare parts
503256200110	3/4IN BSP ST BOTH END HOSE	TATA spare parts
503256200116	3/4IN R2 BSP SAE BOTH END HOSE	TATA spare parts
503256200119	1/2IN BSP SAE 100R2 ST BOTH END HOSE	TATA spare parts
503256200122	DIRECTIONAL CONTROL VALVE	TATA spare parts
503256200126	ASSY. HOSE 1/2IN R2 BSP ST BOTH END.	TATA spare parts
503256200128	2IN BARE HOSE (BOTH END)	TATA spare parts
503256200196	CONTROL VALVE AIR	TATA spare parts
503256200208	PRESSURE HOSE ASSY PTO PUMP TO DCV	TATA spare parts
503256204203	CLAMP (PRESSURE & RETURN LINE)	TATA spare parts
503256206810	SEPSON CONECTOR FOR WINCH	TATA spare parts
503256206831	ELBOW	TATA spare parts
503256210106	BYPASS HOSE TO OIL COOLER	TATA spare parts
503256210130	RETURN HOSE CRANE TO T-CONNECTOR	TATA spare parts
503256210131	RETURN HOSE T-CONN TO HYD TANK	TATA spare parts
503256210133	HOSE ASSY WITH END FITTINGS	TATA spare parts
503256210134	PRESSURE HOSE DCV TO CRANE	TATA spare parts
503256210135	HOSE PIPE PUMP TO DCV	TATA spare parts
503256210136	HOSE ASSY WITH END FITTINGS	TATA spare parts
503256210138	HUDRAULIC PUMP ASSY WINCH	TATA spare parts
503256215816	SUCTION HOSE	TATA spare parts
503256306801	PUMP SUCTION FITTING	TATA spare parts
503256500105	COVER ASSY WINCH CONTROL BOX	TATA spare parts
503256500112	ASSY FRONT FAIRLEAD ROLLER & MTG BRACKET	TATA spare parts
503256500116	ASSY PULLEY FOR ROPE	TATA spare parts
503256500120	ASSY.HYD.PRESSURE LINE 1/2IN R2 BSP 90 D	TATA spare parts
503256500122	ASSY. RETURN LINE HOSE (WINCH CONTROL VA	TATA spare parts
503256500123	ASSY FAIRLEAD ROLLER MTG BRACKET (REAR)	TATA spare parts
503256500149	ASSY PULLEY ON CROSS MEMBER	TATA spare parts
503256500153	ASSY PULLEY DIA 200	TATA spare parts
503256500154	ASSY PULLEY MTG BKT FOR WINCH ROPE	TATA spare parts
503256500155	ASSY COMPLETE WINCH ROPE TENSIONER	TATA spare parts
503256500157	ASSY COMPLETE (ROPE ROLLER MTG BKT)	TATA spare parts
503256500159	ASSY COMPLETE PULLEY MTG FOR ROPE	TATA spare parts
503256500160	ASSY COMPLETE PULLY MTG. FOR ROPE	TATA spare parts
503256500164	ASSY ROLLER (FAIRLEAD ROLLER)	TATA spare parts
503256500166	ASSY BUSH	TATA spare parts
503256500176	ASSY BRACKET (SUCTION HOSE CLAMPING)	TATA spare parts
503256500179	BRACKET ASSY WINCH ROPE GUIDE MTG	TATA spare parts
503256500180	ASSY. BRACKET (FOR WINCH ROPE GUIDE)	TATA spare parts
503256500181	ASSY.PRESSURE LINE HOSE (PUMP TO WINCH C	TATA spare parts
503256506701	PULLEY PIN BOTTOM	TATA spare parts
503256507106	LOCK PLATE	TATA spare parts
503256507121	PULLEY PIN BOTTOM	TATA spare parts
503256507122	LOCK PLATE	TATA spare parts
503256507123	SPACER PLATE WINCH	TATA spare parts
503256507124	SPACER RH PLATE WINCH	TATA spare parts

503256507125	SPACER LH PLATE WINCH	TATA spare parts
503256507132	PULLEY PIN BOTTOM	TATA spare parts
503256507173	PIN FAIRLEAD ROLLER	TATA spare parts
503256507176	LOCKING PLATE FAIRLEAD ROLLER	TATA spare parts
503256507193	SIDE COVER (CONTROL VALVE BKT)	TATA spare parts
503256508211	COVER PLATE (ROLLER PULLEY MTG)	TATA spare parts
503256510101	ASSY BRACKET (WINCH ROPE GUIDE)	TATA spare parts
503256517148	BRACKET RETURN & PRESSURE LINE MTG	TATA spare parts
503256600111	ASSY BRACKET (FOR CONTROL VALVE)	TATA spare parts
503256600112	ASSY COVER WITH REMOTE CONTROL BOX	TATA spare parts
503256600114	ASSY COVER WITH SUPPORT PLATES	TATA spare parts
503256603308	MTG.BRACKET(DIR.CONTROLVALVE)	TATA spare parts
503256800135	KIT-WINCH PIPE & FITTINGS	TATA spare parts
503256800154	PRESSURE LINE DCV TO WINCH CONTROL UNIT	TATA spare parts
503256800158	PRESS LINE 2 HYD TANK TO MANUAL PUMP	TATA spare parts
503256800166	RETURN LINE ASSY T-PORT TO HOSE ASSY	TATA spare parts
503256800167	RETURN LINE ASSY T-PORT TO HOSE ASSY	TATA spare parts
503256800168	RETURN LINE ASSY CONTROL VALVE TO TEE	TATA spare parts
503256800169	RETURN LINE ASSY INTERMEDIATE	TATA spare parts
503256800170	RETURN LINE ASSY WINCH	TATA spare parts
503256800171	RETURN LINE ASSY	TATA spare parts
503256800173	RETURN LINE WINCH CONTROL UNIT TO WINCH	TATA spare parts
503256800174	PRESSURE LINE WINCH TO CONTROL UNIT	TATA spare parts
503256800175	PRESSURE LINE WINCH TO CONTROL UNIT	TATA spare parts
503256800176	RETURN LINE WINCH TO WINCH CONTROL UNIT	TATA spare parts
503256800177	RETURN LINE WINCH TO WINCH CONTROL UNIT	TATA spare parts
503256800178	PRESSURE LINE ASSY WINCH	TATA spare parts
503256800181	PRESSURE LINE DCV TO WINCH CONTROL UNIT	TATA spare parts
503256800182	PRESSURE LINE DCV TO WINCH CONTROL UNIT	TATA spare parts
503256904203	P CLAMP	TATA spare parts
503256904205	CLAMP FOR 70 DIA HOSE	TATA spare parts
503256990104	KIT-HYDRAULIC WINCH	TATA spare parts
503256990107	KIT-WINCH ASSY.	TATA spare parts
503256990111	KIT-CONNECTORS	TATA spare parts
503256990116	BUSH	TATA spare parts
503256990121	SILENCER	TATA spare parts
503256990122	SEAL RING ASSY	TATA spare parts
503256990123	O-RING	TATA spare parts
503256990124	O-RING	TATA spare parts
503256990125	GASKET	TATA spare parts
503256990129	SEAL RING ASSY	TATA spare parts
503256990130	BEARING HOUSING	TATA spare parts
503256990131	BEARING HOUSING	TATA spare parts
503256990132	SPRING	TATA spare parts
503256990133	SPRING	TATA spare parts
503256990136	WASHER	TATA spare parts
503256990138	RING	TATA spare parts

503256990141	SPRING	TATA spare parts
503256990142	BEARING	TATA spare parts
503256990147	V-BELT	TATA spare parts
503256990149	PIN	TATA spare parts
503256990150	GREASE NIPPLE	TATA spare parts
503256990151	COVER	TATA spare parts
503256990152	BEARING	TATA spare parts
503256990153	SPACER	TATA spare parts
503256990155	SPRING	TATA spare parts
503256990157	SPACER	TATA spare parts
503256990169	MOTOR	TATA spare parts
503256990174	GASKET	TATA spare parts
503256990178	PRESSURE ROLLER	TATA spare parts
503256990180	WEDGE WINCH WIRE ROPE	TATA spare parts
503256990181	GASKET	TATA spare parts
503256990187	SEAL RING ASSY	TATA spare parts
503256990189	GASKET	TATA spare parts
503256990193	SPRING CLIP 1	TATA spare parts
503256990194	MOTOR	TATA spare parts
503256990199	PRESSURE ROLLER	TATA spare parts
503256990202	HYDRAULIC BRAKE WITH CONTROL VALVE	TATA spare parts
503256990203	KIT-HYDRAULIC WINCH	TATA spare parts
503256993101	BEARING	TATA spare parts
503256993102	BEARING	TATA spare parts
503256993103	BEARING	TATA spare parts
503256993104	BEARING	TATA spare parts
503256993401	BUSHING	TATA spare parts
503256994301	SPRING CLIP	TATA spare parts
503256994302	SPRING CLIP	TATA spare parts
503256994704	GREASE NIPPLE COVER	TATA spare parts
503256995301	GASKET	TATA spare parts
503256995302	GASKET	TATA spare parts
503256995303	GASKET	TATA spare parts
503256995304	GASKET	TATA spare parts
503256996701	SPRING PIN	TATA spare parts
503256997102	WEDGE	TATA spare parts
503256997801	SEAL RING	TATA spare parts
503256997802	O-RING	TATA spare parts
503256997803	O-RING	TATA spare parts
503256997804	SEAL RING	TATA spare parts
503256997805	V-RING	TATA spare parts
503256997806	SEAL RING	TATA spare parts
503256998402	SPACER TUBE	TATA spare parts
503256998601	SUPPORT RING	TATA spare parts
503256998602	SPACER	TATA spare parts
503256998701	SPRING CLIP	TATA spare parts
503256998702	SPRING	TATA spare parts

503256998801	SPRING PIN	TATA spare parts
503256998802	GREASE NIPPLE	TATA spare parts
503256999201	WASHER	TATA spare parts
503256999901	SILENCER	TATA spare parts
503258900601	ZF SERVO TEST - 600 TESTER	TATA spare parts
503258901801	OIL FILTER WRENCH	TATA spare parts
503258902601	RETAINER SUN GEAR	TATA spare parts
503258902602	PULLER BEARING REMOVAL	TATA spare parts
503258902603	INSTALLER LAY SHAFT BEARING CONE	TATA spare parts
503258902604	SHIFTER SHAFT BUSH INSTALLER	TATA spare parts
503258902616	PULLER BEARING	TATA spare parts
503258902617	PULLER BEARING	TATA spare parts
503258902618	PULLER BEARING	TATA spare parts
503258902619	PULLER BEARING	TATA spare parts
503258902805	EXPANDERS	TATA spare parts
503258902806	EXTRACTING DEVICE	TATA spare parts
503258902807	WRENCH	TATA spare parts
503258902808	SETTING TOOL	TATA spare parts
503258902809	RING	TATA spare parts
503258903501	PULLER FOR HUB OUTER BEARING OUTER RACE	TATA spare parts
503258905601	SPANNER C-HOOK	TATA spare parts
503258905602	SPANNER C-HOOK	TATA spare parts
503258909901	DIAL WITH POINTER	TATA spare parts
503258909902	PRESSURE GAUGE	TATA spare parts
503259000104	ASSY SUPPORT(FOR JIB CRANE MTG.)	TATA spare parts
503259000107	ASSY.SUPPORT(FOR JIB CRANE MTG.)	TATA spare parts
503259000109	ASSY MATERIAL HANDLING CRANE	TATA spare parts
503259200110	SLEWING PISTON	TATA spare parts
503259200111	SLIDE PAD	TATA spare parts
503259200112	STABILISER LEG	TATA spare parts
503259200113	PRESSURE SENSOR	TATA spare parts
503259200114	SLIDE PAD	TATA spare parts
503259200117	ELECTRONIC BOX	TATA spare parts
503259200118	SLIDE PAD	TATA spare parts
503259200119	CYLINDER	TATA spare parts
503259200120	CYLINDER	TATA spare parts
503259200121	CYLINDER	TATA spare parts
503259200122	CYLINDER	TATA spare parts
503259200123	CYLINDER	TATA spare parts
503259200124	SLIDE PAD	TATA spare parts
503259200125	SLIDE PAD	TATA spare parts
503259200126	SLIDE PAD	TATA spare parts
503259200128	SLIDE PAD	TATA spare parts
503259200129	SLIDE PAD	TATA spare parts
503259200130	HP HOSE	TATA spare parts
503259200131	BUZZER	TATA spare parts
503259200132	OVER CENTER VALVE	TATA spare parts

503259200133	HP HOSE	TATA spare parts
503259200134	HP HOSE	TATA spare parts
503259200135	HP HOSE	TATA spare parts
503259200136	HP HOSE	TATA spare parts
503259200137	HP HOSE	TATA spare parts
503259200141	PACKING SET	TATA spare parts
503259200142	PACKING SET	TATA spare parts
503259200143	KIT-SEAL	TATA spare parts
503259200144	O-RING	TATA spare parts
503259200145	PACKING SET	TATA spare parts
503259200146	PACKING SET	TATA spare parts
503259200148	STOP	TATA spare parts
503259200149	LEVEL SCALE	TATA spare parts
503259200150	CLAMP	TATA spare parts
503259200151	RING	TATA spare parts
503259200152	BUSH	TATA spare parts
503259200153	STOP	TATA spare parts
503259200154	EXTENSION BOOM	TATA spare parts
503259200155	EXTENSION BOOM	TATA spare parts
503259200156	SPACER	TATA spare parts
503259200157	SECURING PLATE	TATA spare parts
503259200158	SPACING TUBE	TATA spare parts
503259200159	BUSH	TATA spare parts
503259200161	SEAL RING	TATA spare parts
503259200162	SEAL RING	TATA spare parts
503259200163	NIPPLE	TATA spare parts
503259200164	NIPPLE	TATA spare parts
503259200165	ANGLE COUPLING	TATA spare parts
503259200166	RETAINING RING	TATA spare parts
503259200167	L-COUPLING	TATA spare parts
503259200168	PILOT CHECK VALVE	TATA spare parts
503259200169	HP HOSE	TATA spare parts
503259200170	LOAD HOLDING VALVE	TATA spare parts
503259200171	HP HOSE	TATA spare parts
503259200172	HP PIPE	TATA spare parts
503259200173	GREASE NIPPLE	TATA spare parts
503259200174	BUSH	TATA spare parts
503259200175	NIPPLE	TATA spare parts
503259210141	PRESSURE GAUGE	TATA spare parts
503283450101	CONDENSER ASSY	TATA spare parts
503283550101	COMPRESSOR ASSY	TATA spare parts
503283601601	SUCTION PIPE ASSY	TATA spare parts
503283601602	DISCHARGE PIPE ASSY	TATA spare parts
503283601603	LIQUID PIPE ASSY	TATA spare parts
503283650101	HEATER HOSE ASSY OUTLET	TATA spare parts
503283650102	HEATER HOSE ASSY INLET	TATA spare parts
503300990101	SPARE KIT OF FULLY CABIN FOR LPT 1613	TATA spare parts

503300990102	SPARE KIT OF ASSY COWL FOR VC 50339342R	TATA spare parts
503300990103	SPARE KIT OF FULLY CABIN FOR LPT 1613	TATA spare parts
50331048000R40	PARTIALLY FITTED CAB W/O ELECTICALS LPT	TATA spare parts
50331052000RCK	ASSY CABIN KIT W/FITMENTS LPT 1613	TATA spare parts
503315400101	ALTERNATOR 12V 65AMPS 6-GRV	TATA spare parts
503316100101	CONTAINER ECU 697 TCIC CR BS-IV	TATA spare parts
503316100105	CONTAINER (ECU 697 CR BS-IV OBD II)	TATA spare parts
503316100106	CONTAINER (ECU 697 CR BSIV 12V OBD2)	TATA spare parts
503326800109	ASSY. SHIFT CABLE	TATA spare parts
503326800110	ASSY. SELECT CABLE	TATA spare parts
503326800112	VERTICAL GEAR SHIFT UNIT ASSY-M12	TATA spare parts
503326800116	SHIFT CABLE ASSY	TATA spare parts
503326800123	TURNING TUBE ASSY	TATA spare parts
503326810101	BRACKET ASSY GEAR SHIFT LEVER MTG	TATA spare parts
503326810103	SUPPORT TUBE ASSY	TATA spare parts
503326820102	ASSY. SHIFT CABLE(FOR POWER SHIFT)	TATA spare parts
503326820103	ASSY. SELECT CABLE (FOR POWER SHIFT)	TATA spare parts
503326826701	BALL JOINT M10	TATA spare parts
503326826702	BALL JOINT M12	TATA spare parts
503329100101	ASSY. CLUTCH HYD.PIPE	TATA spare parts
503329100105	ASSY. PEDAL LEVER (CLUTCH)	TATA spare parts
503329100107	ASSY.CLUTCH PEDAL MTG.BKT WITH STOPPER	TATA spare parts
503331000101	ASSY. FRAME COMPLETE	TATA spare parts
503331000105	FRAME ASSY WITH FITMENT	TATA spare parts
503331207103	RADIATOR SUPPORT BRACKET-RH	TATA spare parts
503331207104	RADIATOR SUPPORT BRACKET-LH	TATA spare parts
503331208202	BRACKET (FOR SOLENOID VALVE MTG)	TATA spare parts
503331700101	ASSY EXTENSION PIECE FOR FRAME	TATA spare parts
503331700102	ASSY EXTENSION PIECE FOR FRAME	TATA spare parts
503331700105	REINFORCEMENT ASSY RH	TATA spare parts
503331700106	REINFORCEMENT ASSY LH	TATA spare parts
503332403302	BRACKET SPRING HANGER	TATA spare parts
503333000101	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
503341110101	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
503341110102	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
503341110107	SHORT FORK TUBE& FRONT END PIECE ASSY	TATA spare parts
503341120101	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
503343900102	ASSY.NYLON PIPE SET COMPLETE-42WB 697 BS	TATA spare parts
503343900131	ASSY METAL PIPE FIRST FOR 1613 697	TATA spare parts
503343900132	ASSY METAL PIPE 2ND 1613 697	TATA spare parts
503343900133	ASSY METAL PIPE 3RD 1613 697	TATA spare parts
503343900160	METAL PIPE ASSY INTER. JOINT-1 TO 2	TATA spare parts
503343900192	ASSY COMP THIRD METAL PIPE	TATA spare parts
503343900193	ASSY COMP SECOND METAL PIPE	TATA spare parts
503343903301	BRACKET TWISTED	TATA spare parts
503343910105	ASSY NYLON PIPE SET CHASSIS	TATA spare parts
503343910118	ASSY NYLON PIPE SET COMPLETE	TATA spare parts



503343910155	ASSY NYLON BUNCH LPT 1613697 BSIII COWL	TATA spare parts
503343910181	PIPE ASSY BUNCH COMPLETE	TATA spare parts
503343920112	PIPE ASSY BUNCH COMPLETE	TATA spare parts
503343920117	PIPE ASSY BUNCH COMPLETE	TATA spare parts
503343920156	NYLON PIPE BUNCH ASSY	TATA spare parts
503343920161	PIPE ASSY	TATA spare parts
503343920162	PIPE ASSY BUNCH COMPLETE	TATA spare parts
503343920164	PIPE ASSY BUNCH COMPLETE	TATA spare parts
503346703301	BRACKET STG GEAR BOX MTG	TATA spare parts
503346800115	ASSY.PIPE STG-LPT1613;697BS-IV SE ENG	TATA spare parts
503346800116	ASSY.SUCTION LINES(RESERVOIR TO PUMP)	TATA spare parts
503346800117	ASSY.PRESSURE LINE(PUMP TO GB)	TATA spare parts
503346800118	ASSY.RETURN LINE GB TO INTER. JOINT SE E	TATA spare parts
503346800119	ASSY.RETURN LINE INTER JOINT TO RES TK.S	TATA spare parts
503346800123	ASSY PIPELINES & CLAMPS	TATA spare parts
503346800124	ASSY.SUCTION LINE	TATA spare parts
503346800125	ASSY PRESSURE LINE (FROM PUMP TO GB)	TATA spare parts
503346800126	ASSY RETURN LINE	TATA spare parts
503346800127	ASSY BKT FOR STG. PIPE SUPPORT	TATA spare parts
503346803301	L-BRACKET	TATA spare parts
503346803302	BRACKET	TATA spare parts
503346803305	ASSY BRACKET	TATA spare parts
503346804203	BRACKET (FOR STEERING PIPING)	TATA spare parts
503347600104	SUCTION LINE ASSY BS-III DICOR	TATA spare parts
503347600106	ASSY RETURN LINE ACCUMULATOR TO FUEL TANK	TATA spare parts
503347600110	ASSY RETURN LINE (ACCUMALARATOR TO FUEL	TATA spare parts
503347600112	ASSY SUCTION LINE (FUEL FILTER TO FUEL P	TATA spare parts
503347600113	ASSY SUCTION LINE (BABY FILTER TO FUEL F	TATA spare parts
503347600115	SUCTION PIPE ASSY (PROTECT TO MAIN FIL)	TATA spare parts
503347600116	SUCTION PIPE ASSY (TANK TO PROTECT FIL)	TATA spare parts
503347600117	SUCTION PIPE ASSY (MAIN FILTER TO ENG)	TATA spare parts
503347600118	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
503347600122	SUCTION PIPE ASSY (FINAL FILTER TO ENG)	TATA spare parts
503347600123	SUCTION PIPE ASSY (TANK TO PROTECT FIL)	TATA spare parts
503347600124	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
503347700101	BRACKET ASSY (FILTER MTG)	TATA spare parts
503349100101	ASSY. EXHAUST PIPE	TATA spare parts
503349100102	ASSY SILENCER BS IV	TATA spare parts
503349109901	HEAT SHIELD- FIRST PIPE	TATA spare parts
503349109902	HEAT SHIELD- SECOND PIPE	TATA spare parts
503349109903	HEAT SHIELD- DOC PM TRAP	TATA spare parts
503349200114	SECOND PIPE ASSY FOR INTEGRATED DOC POC	TATA spare parts
503349200115	THIRD PIPE ASSY FOR INTEGRATED DOC POC	TATA spare parts
503349200116	ASSY SUPPORT BRACKET	TATA spare parts
503349200117	EXHAUST PIPE ASSY	TATA spare parts
503349200131	EXH.PIPE LPT 1613/42 697 BS-4 COWL	TATA spare parts
503349200132	EXH.PIPE LPT 1613/42 697 BS-4 COWL	TATA spare parts

503349200133	EXH.PIPE LPT 1613/42 697 BS-4 COWL	TATA spare parts
503349200134	ASSY SUPPORT DOC-POC (REAR)	TATA spare parts
503349200135	ASSY SUPPORT DOC-POC (FRONT)	TATA spare parts
503349200137	EXH FIRST PIPE(SUB-ASSY 2)	TATA spare parts
503349200141	EXHAUST PIPE ASSY FIRST	TATA spare parts
503349200142	EXHAUST PIPE ASSY REAR	TATA spare parts
503349200152	PIPE ASSY INTERMEDIATE	TATA spare parts
503349200153	PIPE ASSY INTERMEDIATE	TATA spare parts
503349200155	ASSY FIRST TUBE (OBD2)	TATA spare parts
503349200160	ASSY EXHAUST PIPE SECOND	TATA spare parts
503349200161	EXHAUST PIPE ASSY REAR	TATA spare parts
503349200162	BRACKET ASSY (EXHAUST PIPE MOUNTING)	TATA spare parts
503349200166	EXHAUST PIPE ASSY SECOND	TATA spare parts
503349200167	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
503349200168	BRACKET ASSY TAIL PIPE MTG	TATA spare parts
503349200169	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
503349200171	EXHAUST PIPE ASSY FIRST	TATA spare parts
503349200173	BRACKET ASSY SILENCER MTG	TATA spare parts
503349200174	BRACKET ASSY SILENCER MTG	TATA spare parts
503349200175	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
503349200176	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
503349203306	CLAMP FOR TAIL PIPE	TATA spare parts
503349203307	CLAMP FOR INTEGRATED DOC POC	TATA spare parts
503349203310	BRACKET EXHAUST BRAKE SUPPORT	TATA spare parts
503349203311	BRACKET EXHAUST PIPE CLAMPING	TATA spare parts
503349203313	BRACKET EXHAUST PIPE SUPPORT	TATA spare parts
503349203316	BRACKET EXHAUST BRAKE SUPPORT	TATA spare parts
503349204201	CLAMP DOC POC	TATA spare parts
503349206916	BUNDY TUBE	TATA spare parts
503349206917	BUNDY TUBE	TATA spare parts
503349206953	PIPE FRONT DPS SENSOR	TATA spare parts
503349206954	PIPE REAR DPS SENSOR	TATA spare parts
503349206955	OUTLET TUBE FOR DPS	TATA spare parts
503349206956	INLET TUBE -DOC-POC TO DPS	TATA spare parts
503349206972	TUBE HOSE TO DPS	TATA spare parts
503349206973	TUBE HOSE TO DPS	TATA spare parts
503349207115	BRACKET-FIRST PIPE	TATA spare parts
503349208205	SILENCER CLAMP BS IV	TATA spare parts
503349208206	CLAMP FOR POC	TATA spare parts
503349208207	CIRCULAR CLAMP FOR DOC	TATA spare parts
503349208208	BRACKET;DPS MTG	TATA spare parts
503349208211	CHANNEL DOC-POC MTG	TATA spare parts
503349208212	BRACKET (ON CLUTCH HOUSING)	TATA spare parts
503349604201	CLAMP HEAT SHIELD FRONT	TATA spare parts
503349605306	KIT-EXHAUST HEAT SHIELD	TATA spare parts
503349605307	HEAT SHIELD EXHAUST PIPE	TATA spare parts
503349990102	HEAT SHIELD KIT- EXHAUST FIRST PIPE SIDE	TATA spare parts

503349990105	KIT-EXHAUST HEAT SHIELD	TATA spare parts
503349990106	KIT-EXHAUST HEAT SHIELD	TATA spare parts
503349990107	KIT-EXHAUST HEAT SHIELD	TATA spare parts
503349990114	KIT-EXHAUST PIPE HEAT SHIELD	TATA spare parts
503349990115	KIT-EXHAUST PIPE HEAT SHIELD	TATA spare parts
503349990116	KIT-HEAT SHIELD FOR SILENCER & EXH PIPE	TATA spare parts
503354100103	ASSY SUPPORT	TATA spare parts
503354200109	ASSY. INSTRUMENT CLUSTER BS3/4	TATA spare parts
503354200112	GEAR SHIFT INDICATOR	TATA spare parts
503354206301	COVER FOR ECU BSIII CRDI	TATA spare parts
503354209902	R.P.M.METER 12V (BACKLIT)	TATA spare parts
503354209903	GEAR SHIFT SOLENOID VALVE-12V	TATA spare parts
503354209904	ECU EMS I6 24V 697 DICOR ENG. BS3/4	TATA spare parts
503354249901	GEAR SHIFT SOLENOID VALVE-24V	TATA spare parts
503354249904	GEAR SHIFT SOLENOID VALVE-24V	TATA spare parts
503354401601	ASSY WARNING LAMP IND.(12V)	TATA spare parts
503354506301	FUSE BOX COVER WITH PRINTING BSIII	TATA spare parts
503354509901	SOLENOID SWITCH 12V 4ST	TATA spare parts
503354600124	BATTERY CABLE +VE BCS O/P TO SM	TATA spare parts
503354600131	WIRING HARNESS ABS	TATA spare parts
503354600133	WIRING HARNESS ABS FRAME	TATA spare parts
503354600136	WIRING HARNESS ABS FRAME	TATA spare parts
503354600150	WIRING HARNESS MAIN	TATA spare parts
503354600152	FUSE BOX COVER & STICKER ASSY	TATA spare parts
503354600153	WIRING HARNESS MAIN	TATA spare parts
503354600154	WIRING HARNESS ABS SPLIT	TATA spare parts
503354600161	BATTERY CABLE +VE ADD BATT TO BCS I/P	TATA spare parts
503354601605	AXLE SHAFT GEAR (9X16) 20MNC	TATA spare parts
503354601650	WIRING HARNESS TAIL	TATA spare parts
503354601657	WIRING HARNESS TAIL	TATA spare parts
503354601681	WIRING HARNESS TAIL	TATA spare parts
503354601682	WIRING HARNESS TAIL	TATA spare parts
503354608206	BRACKET FOR CHANNEL MTG	TATA spare parts
503354608207	BKT FOR HARNESS MOUNTING	TATA spare parts
503354608216	BRACKET(SENSOR W/H CLAMPING)	TATA spare parts
503354620104	W/H INST.CONSOLE LPT1613 697 BSIV	TATA spare parts
503354660101	W/H MAIN LPT1613 CAB 697 BS-IV 12V	TATA spare parts
503354660102	W/H SENSOR LPT1613	TATA spare parts
503354660103	W/H ENGINE LPT1613 697 BS-IV 12V	TATA spare parts
503354660104	W/H INST.CONSOLE LPT1613 697 BSIV	TATA spare parts
503354660105	W/H TAIL LPT1613/42 697 BS-IV 12V	TATA spare parts
503354660125	W/H ENGINE LPT1616 BSIV DICOR COWL	TATA spare parts
503354660127	W/H SENSOR LPT1616 BSIV DICOR COWL	TATA spare parts
503354660128	W/H MAIN LPT1616 BSIV 24V DICOR COWL ERG	TATA spare parts
503354660131	W/H TAIL LPT1616/42 24V BSIV DICOR	TATA spare parts
503354660134	W/H ENGINE LPT1616 BSIII DICOR COWL	TATA spare parts
503354660135	W/H TAIL LPT1613/42WB BSIII DICOR COWL	TATA spare parts

503354660137	W/H MAIN LPT1613 CAB 697 BS-IV 12V	TATA spare parts
503354660139	W/H SENSOR LPT1613;697;BSIV;12V	TATA spare parts
503354660140	W/H TAIL LPT1613/42 BSIV CWL OBDII	TATA spare parts
503354660143	WIRING HARNESS -TAIL	TATA spare parts
503354660145	WIRING HARNESS;ENGINE	TATA spare parts
503354660149	W/H MAIN LPT1616 BSIII 24V DICOR COWL	TATA spare parts
503354660150	W/H EMS LPT1613 BSIV DICOR COWL	TATA spare parts
503354660157	WIRING HARNESS TAIL	TATA spare parts
503354660158	WIRING HARNESS MAIN	TATA spare parts
503354660159	WIRING HARNESS MAIN BS4	TATA spare parts
503354660161	WIRING HARNESS;MAIN	TATA spare parts
503354709901	CONTROLLER GEAR SHIFT ADVISORY BS4	TATA spare parts
503354900101	BRACKET ASSY DC-DC CONVERTER MTG	TATA spare parts
50335742000R40	CAB ASSY W/O FITMENT	TATA spare parts
503383300101	CONTROL PANEL ASSY	TATA spare parts
503383400101	BLOWER ASSY	TATA spare parts
503383400102	AC UNIT ASSY	TATA spare parts
503383400103	VENTILATION UNIT ASSY	TATA spare parts
503383400109	RESISTOR ASSY	TATA spare parts
503383400113	BLOWER HSG ASSY	TATA spare parts
503383400115	DUCT ASSY FRONT	TATA spare parts
503383400116	WIRING HARNESS ASSY	TATA spare parts
503383400117	WIRING HARNESS	TATA spare parts
503383403301	BRACKET AC UNIT MTG CENTER	TATA spare parts
503383403302	BRACKET AC UNIT MTG RH	TATA spare parts
503383403303	BRACKET AC UNIT MTG	TATA spare parts
503383403304	BRACKET AC UNIT MTG LH	TATA spare parts
503383403306	BRACKET AC UNIT MTG MIDDLE	TATA spare parts
503383406310	COVER	TATA spare parts
503383600101	SUCTION PIPE HVAC END	TATA spare parts
503383600102	SUCTION PIPE COMPRESSOR END	TATA spare parts
503383600103	DISCHARGE PIPE COMPRESSOR END	TATA spare parts
503383600105	LIQUID PIPE HVAC END	TATA spare parts
503383600106	LIQUID PIPE CONDENSER END	TATA spare parts
503383750101	BRACKET ASSY AC PIPE MTG	TATA spare parts
503383750102	BRACKET ASSY AC PIPE MTG	TATA spare parts
503383750105	BRACKET ASSY AC PIPE MTG	TATA spare parts
503400990101	SPARE KIT OF FULLY BUILT COWL	TATA spare parts
503400990104	KIT FUEL ELECTRONIC FEED PUMP 350L+350L	TATA spare parts
503400990105	KIT FUEL ELECTRONIC FEED PUMP 300L FT	TATA spare parts
50340868000RCK	ASSY. COWL KIT W/FITMENTS LPT 1918 5L BS	TATA spare parts
503424200101	BRACKETASSYCHASSISRH	TATA spare parts
503424200102	BRACKETASSYCHASSISLH	TATA spare parts
503424200103	BRACKET ASSY CHASSIS RH	TATA spare parts
503424200104	BRACKET ASSY CHASSIS LH	TATA spare parts
503426800107	GEAR SHIFT UNIT ASSY	TATA spare parts
503426800108	CABLE SHIFT SYSTEM ASSY	TATA spare parts

503426800109	CABLE ASSY GEAR SELECTION	TATA spare parts
503426800110	GEAR SHIFT UNIT BS6	TATA spare parts
503426800111	GEAR SHIFT UNIT ASSY WITH CABLE BS6	TATA spare parts
503426800112	CABLE ASSY GEAR SELECTION BS6	TATA spare parts
503426800113	CABLE SHIFT SYSTEM ASSY BS6	TATA spare parts
503426820102	ANCHOR&BRACKET&ASSY&SHIFT&CABLE&CABLE	TATA spare parts
503426820106	ANCHOR BRACKET ASSY SHIFT CABLE BS6	TATA spare parts
503426827104	SUPPORT&BRACKET&(SHIFT&CABLE)	TATA spare parts
503426827111	BRACKET&(CLAMP)	TATA spare parts
503429100105	CLUTCH PEDAL ASSY WITH STOPPER	TATA spare parts
503429300104	BUNDY TUBE ASSY CMC TO FIREWALL	TATA spare parts
503429300107	BUNDY TUBE ASSY CMC TO LONG MEMBER	TATA spare parts
503429300108	BUNDY TUBE ASSY, LONG MEMBER	TATA spare parts
503429300109	CLUTCH MASTER CYL. W/RESERVOIR BS3/4	TATA spare parts
503429300111	MAJOR REPAIR KIT CLUTCH MASTER CYLINDER	TATA spare parts
503429300112	MINOR REPAIR KIT CLUTCH MASTER CYLINDER	TATA spare parts
503429300113	BUNDY TUBE ASSY CMC TO LONG MEMBER BS6	TATA spare parts
503429305801	LOW PRESSURE HOSE CLUTCH RESRVOIR TO CMC	TATA spare parts
503429500101	SUPPORT ASSY PEDAL MTG	TATA spare parts
503431000102	FRAME&ASSY&W/O FITMENT	TATA spare parts
503431000104	FRAME&ASSY&WITH&FITMENT	TATA spare parts
503431000106	FRAME ASSY WITH FITMENT	TATA spare parts
503431000108	FRAME ASSY WITH FITMENT	TATA spare parts
503431000110	FRAME ASSY WITH FITMENT	TATA spare parts
503431000114	FRAME ASSY WITH FITMENT	TATA spare parts
503431200110	CROSSMEMBERASSY	TATA spare parts
503431200113	CROSS MEMBER ASSY ENGINE MTG FRONT	TATA spare parts
503431200120	CROSSMEMBERASSYENGINEFRONT	TATA spare parts
503431200123	SUPPORT ASSY LH	TATA spare parts
503431200124	SUPPORT ASSY RH	TATA spare parts
503431700105	BRACKET ASSY RADIATOR MTG RH	TATA spare parts
503431700106	BRACKET ASSY RADIATOR MTG LH	TATA spare parts
503431700113	BRACKET ASSY RADIATOR MTG RH	TATA spare parts
503431700114	BRACKET ASSY RADIATOR MTG LH	TATA spare parts
503431703302	BRACKET DUMBBELL MTG LH	TATA spare parts
503431703303	BRACKET DUMBBELL MTG RH	TATA spare parts
503441100101	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
503441100103	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
503441100104	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
503441100105	PROPELLER SHAFT ASSY COUPLING FRONT	TATA spare parts
503441100106	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
503441100107	PROPELLER SHAFT ASSY COUPLING MIDDLE	TATA spare parts
503441303301	BRACKETCENTERBEARINGMTG	TATA spare parts
503441303302	BRACKET CENTER BRG MTG	TATA spare parts
503443700101	BRACKET ASSY MODULATOR VALVE MTG	TATA spare parts
503443700102	BRACKET ASSY MODULATOR VALVE MTG	TATA spare parts
503443700110	AIR COMPRESSOR ASSY	TATA spare parts

503443900123	PIPE ASSY METAL COM. TO JOINT-1	TATA spare parts
503443900127	PIPE ASSY BUNCH COMPLETE	TATA spare parts
503443900139	PIPE ASSY	TATA spare parts
503443900140	METAL PIPE ASSY	TATA spare parts
503443900142	NYLON PIPE BUNCH ASSY	TATA spare parts
503443900150	BUNCH ASSY PIPE	TATA spare parts
503443900156	METAL PIPE ASSY	TATA spare parts
503443900159	PIPE BUNCH ASSY	TATA spare parts
503443903301	BRACKET BS6	TATA spare parts
503443910102	METAL PIPE ASSY	TATA spare parts
503443910103	NYLON PIPE BUNCH ASSY	TATA spare parts
503446800110	SUCTION LINE ASSY	TATA spare parts
503446800111	PRESSURE LINE ASSY	TATA spare parts
503446800112	PRESSURE LINE ASSY	TATA spare parts
503446800113	RETURN LINE ASSY STG GEAR BOX END	TATA spare parts
503446800114	RETURN LINE ASSY RESERVOIR END	TATA spare parts
503446800116	PRESSURE LINE ASSY	TATA spare parts
503446800117	SUCTION LINE ASSY	TATA spare parts
503446800119	PRESSURE LINE ASSY	TATA spare parts
503446800120	RETURN LINE ASSY	TATA spare parts
503446803301	L-BRACKET BS6	TATA spare parts
503446900101	DRAG LINK ASSY FRONT	TATA spare parts
503446900103	DRAG LINK ASSY FRONT BS6	TATA spare parts
503446990130	REPAIR KIT BS6	TATA spare parts
503447500101	BRACKETASSY(FILTERMTG.)	TATA spare parts
503447600101	SUCTION PIPE (TANK TO PRE FILTER)	TATA spare parts
503447600102	SUCTION PIPE (HPV RETURN TO SUC. LINE)	TATA spare parts
503447600103	SUCTION PIPE (PRE FILTER TO MAIN FILTER)	TATA spare parts
503447600104	FUELPIPE(MAINFILTERTOHANDPRIMING)	TATA spare parts
503447600105	FUEL PIPE (FILTER TO ENG)	TATA spare parts
503447600106	RETURN LINE (ENG TO TANK )	TATA spare parts
503447600107	RETURN LINE (HP TO RETURN LINE )	TATA spare parts
503447600109	FUEL SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
503447600110	SUCTION PIPE ASSY FILTER TO FEED PUMP	TATA spare parts
503447600111	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
503447600112	FUEL RETURN PIPE ASSY HP PUMP TO T-CONN	TATA spare parts
503447600113	RETURN PIPE ASSY FEED PUMP TO FUEL TANK	TATA spare parts
503447600114	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
503447600116	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
503447600117	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
503447600118	SUCTION PIPE ASSY	TATA spare parts
503447600119	FUEL SUCTION PIPE ASSY FILTER TO FIP	TATA spare parts
503447600122	RETURN FUEL PIPE ASSY	TATA spare parts
503447600123	FUEL TANK INTER CONNECTION HOSE ASSY	TATA spare parts
503447603301	BRACKET	TATA spare parts
503447603302	BRACKET	TATA spare parts
503447990101	ASSY. FUEL SYSTEM	TATA spare parts

503449103301	BRACKET SILENCER MTG	TATA spare parts
503449103302	BRACKETPIPEMTG	TATA spare parts
503449200103	EXHAUSTPIPEASSYWITHFLEXBELLOW	TATA spare parts
503449200104	EXHAUSTPIPEASSYINTERMEDIATE	TATA spare parts
503449200108	BRACKETASSY	TATA spare parts
503449200110	EXHAUSTPIPEASSYINTERMEDIATE	TATA spare parts
503449200111	EXHAUST PIPE ASSY	TATA spare parts
503449200114	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
503449200119	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
503449203302	BRACKET SILENCER MTG	TATA spare parts
503449203303	L-BRACKET EXHAUST MTG	TATA spare parts
503449203305	BRACKET EXHAUST PIPE CLAMPING	TATA spare parts
503449203306	BRACKET EXHAUST PIPE CLAMPING	TATA spare parts
503449203307	BRACKET EXHAUST PIPE MTG	TATA spare parts
503449203309	L-BRACKET EXHAUST MTG	TATA spare parts
503449206905	BUNDY TUBE	TATA spare parts
503449206908	BUNDY TUBE	TATA spare parts
503449206910	TUBE	TATA spare parts
503449206911	TUBE	TATA spare parts
503449206916	TUBE DPS SENSOR OUTLET	TATA spare parts
503449206918	TUBE DPS SENSOR OUTLET	TATA spare parts
503454480101	BRACKET ASSY ENGINE LAMP MTG	TATA spare parts
503454600106	L-BRACKET ASSY	TATA spare parts
503454600119	BATTERY CABLE -VE	TATA spare parts
503454600135	WIRING HARNESS ABS FRAME	TATA spare parts
503454600136	WIRING HARNESS ABS FRAME	TATA spare parts
503454600141	WIRING HARNESS TAIL	TATA spare parts
503454600142	WIRING HARNESS ABS FRAME	TATA spare parts
503454600143	WIRING HARNESS MAIN	TATA spare parts
503454600146	WIRING HARNESS ENGINE BS4	TATA spare parts
503454600147	WIRING HARNESS TAIL	TATA spare parts
503454600152	WIRING HARNESS MAIN	TATA spare parts
503454600154	WIRING HARNESS MAIN	TATA spare parts
503454601611	BATTERY CABLE +VE ASSY - 50SQ MM	TATA spare parts
503454601622	WIRING HARNESS TAIL	TATA spare parts
503454601627	WIRING HARNESS TAIL	TATA spare parts
503454603307	BRACKET MAXI FUSE MTG	TATA spare parts
503454900101	BRACKET ASSY ECU MTG	TATA spare parts
503454900103	BRACKET ASSY DC-DC CONVERTER MTG	TATA spare parts
503454900104	BRACKET ASSY ECU MTG	TATA spare parts
503454903306	BRACKET DC TO DC CONVERTER MTG	TATA spare parts
503454903308	ECU MTG SUPPORT	TATA spare parts
503626800107	ASSY ANCHORING BRACKET (GEAR SHIFT & SEL	TATA spare parts
503626900109	HOSE ASSY FOR SUPPLYING OIL TO OIL COOLE	TATA spare parts
503626900110	HOSE ASSY FOR SUPPLYING OIL TO OIL COOLE	TATA spare parts
503626907106	BRACKET RH (OIL COOLER ASSY )	TATA spare parts
503626907107	BRACKET RH (OIL COOLER ASSY )	TATA spare parts

503628500101	AGB MOUNTING BRACKET - LH SIDE	TATA spare parts
503628500103	AGB MOUNTING BRACKET - RH SIDE	TATA spare parts
503628500105	ASSY AGB MTG BKT-LH	TATA spare parts
503628500106	AGB MOUNTING BRACKET-RH(BAR ASM MTG)	TATA spare parts
503631000102	ASSY. FRAME COMPLETE	TATA spare parts
503631000103	FRAME ASSY	TATA spare parts
503631107105	STFNR-FRONT LH	TATA spare parts
503631107106	STFNR-TRUN	TATA spare parts
503631107107	STIFNER REAR-LH	TATA spare parts
503631107108	STFNR-REAR RH	TATA spare parts
503631200106	ASSY ENG MTG CROSS MEMBER	TATA spare parts
503631200108	BRACKET (SUPPORT ENG MTG CM)	TATA spare parts
503631200109	ASSEMBLY CM 5TH	TATA spare parts
503631200110	ASSY. END CROSS MEMBER COMPLETE	TATA spare parts
503631200111	ASSEMBLY CROSS MBR 5TH	TATA spare parts
503631708601	SPACER FOR SUSPENSION HANGER BRACKET	TATA spare parts
503632300101	ASSY BRACKET (FRONT SA TOP)	TATA spare parts
503632300102	ASSY SHOCK ABSORBER BRKT-RH	TATA spare parts
503632404201	U CLAMP	TATA spare parts
503640100102	ASSY WHEEL RIM	TATA spare parts
503640106302	TUBELESS TYRE	TATA spare parts
503640109901	TUBLESS VALVES-12V1 (TURRET TYPE)	TATA spare parts
503640300101	ASSY SUPPORT COMPLETE (SPARE WHEEL MTG)	TATA spare parts
503640300118	ASSY BRACKET (FOR BOTH SPARE WHEEL STR.	TATA spare parts
503640300123	ASSY BASE SUPPORT (FOR SPARE WHEEL STRUC	TATA spare parts
503640300129	ASSY POWERPACK	TATA spare parts
503640300132	ASSY BRACKET (POWER CYL MTG)	TATA spare parts
503640300136	BRACKET FORç ELECTRICAL SW/D.C. VALVE	TATA spare parts
503640300139	POWER PACK (MOTOR & TANK ASM)	TATA spare parts
503640307111	CLAMP (POWER CYL MTG BKT)	TATA spare parts
503640307120	PLATE (FOR PIN LOCKING)	TATA spare parts
503640307501	BALATA PACKING	TATA spare parts
503640800101	ASSY HOSE POWER PACK-1	TATA spare parts
503640800103	ASSY HOSE FOR POWER PACK-2	TATA spare parts
503641120101	ASSY.PROP.SHAFT GB TO TC	TATA spare parts
503641120101AE	ASSY.PROP SFT GB TO TC -1628	TATA spare parts
503641120102	ASSY PROP SHAFT TC TO RA	TATA spare parts
503641120102AE	ASSY. PROP SFT TC TO RA -1628	TATA spare parts
503641120104	ASSY PROPELLER SHAFT FROM AGB TO RA	TATA spare parts
503643700103	ASSY. BRACKET-ASR/DCV MTG.	TATA spare parts
503643703301	BRACKET LH-DCV MTG. FRONT	TATA spare parts
503643703302	BRACKET-RH DCV MTG. FRONT	TATA spare parts
503643703304	BRACKET DCV MTG	TATA spare parts
503643900102	ASSY. METAL PIPE WITH CRIMPED HOSE	TATA spare parts
503643900102AE	ASSY METAL PIPE W/CRMPD HSE-1828	TATA spare parts
503643900103	ASSY SECOND METAL PIPE COMPRESSOR. TO AP	TATA spare parts
503643900104	ASSY THIRD METAL PIPE COMPRESSOR TO APU	TATA spare parts



503643900156	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
503643910121	PIPE ASSY BUNCH COMPLETE	TATA spare parts
503645300110	CTIS KIT FOR LPTA1628 4X4 LHD	TATA spare parts
503646300113	DRAG LINK ASSY (LHD)	TATA spare parts
503646603301	BRACKET FOR STG RESERVIOR MTG	TATA spare parts
503646700102	SPACER ASSY (STEERING GEARBOX MOUNTING)	TATA spare parts
503646703301	BRACKET (FOR PIPE CLAMPS)	TATA spare parts
503646800101	SUCTION LINE HOSE & PIPE ASSY	TATA spare parts
503646800102	RETURN LINE HOSE & PIPE ASSY-RESERVOIR E	TATA spare parts
503646800103	RETURN LINE HOSE & PIPE ASSY-G.B END	TATA spare parts
503646800104	PRESSURE LINE HOSE & PIPE ASSY	TATA spare parts
503646803301	BRACKET FOR STG LINES MTG BS6	TATA spare parts
503646990102	ASSY. KIT OF STEERING LINES	TATA spare parts
503647500102	ASSY.SUPPORT I (RECT. FUEL TANK 400 LTR.	TATA spare parts
503647500102AE	ASSY.SUPPORT (FUEL TK 400 L)-1628	TATA spare parts
503647500103	ASSY.SUPPORT I (RECT. FUEL TANK 400 LTR.	TATA spare parts
503647500103AE	ASY SUPORT(RECT.FUELTK 400 -1628	TATA spare parts
503647507103	SPACER PLATE (FOR FILTER MTG)	TATA spare parts
503647600101	ASSY SUCTION FUEL LINE FROM F/T TO W/S	TATA spare parts
503647600102	ASSY RETURN FUEL LINE	TATA spare parts
503647600103	ASSY SUCTION FUEL LINE FROM W/S TO FIP	TATA spare parts
503647600104	FUEL SUCTION LINE FT TO WEBASTO HEATER	TATA spare parts
503647600106	FUEL RETURN LINE WEBASTO HEATER TO FT	TATA spare parts
503649100105	ASSY BRACKET SUPPORT EXHAUST BRAKE	TATA spare parts
503649100108	ASSY.THIRD PIPE FROM FLEX TO MUFFLER	TATA spare parts
503649100109	ASSY.SUPPORT EXHAUST PIPE	TATA spare parts
503649100112	ASSEMBLY SECOND PIPE EXHAUST	TATA spare parts
503649103701	FIRST PIPE FROM ENGINE TO FLEX	TATA spare parts
503649108203	BRACKET SUPPORT EXHAUST PIPE( GEAR BOX)	TATA spare parts
503649108204	BRACKET FRONT SILENCER MOUNTING FRAME	TATA spare parts
503649990101	KIT FOR EXHAUST SHIELD	TATA spare parts
503652200101	ASSY. REAR FRONT FENDER MTG.	TATA spare parts
503652200101AE	ASSY. REAR FRT FENDER MTG. -1628	TATA spare parts
503654100104	ASSY BRACKET BATTERY COVER (FRONT)	TATA spare parts
503654100105	ASSY.BATT.CABLE +VE- BATT CUTOFF SW TO S	TATA spare parts
503654100119	ASSY BATTERY CARRIER STRUCTURE	TATA spare parts
503654100124	ASSY.BATT.CABLE +VE 120SQ.MM LG 700 (FRO	TATA spare parts
503654100124AE	ASSY.BATT.CABLE +VE -1628	TATA spare parts
503654100125	BATT CABLE +VE 120SQ.MM LG 3600(CUT OFF	TATA spare parts
503654100125AE	BATT CABLE +VE SW TO STA -1628	TATA spare parts
503654100126	200A POWER SOCKET +VE LG 220	TATA spare parts
503654100126AE	200A PWR SOCKET +VE LG 220-1628	TATA spare parts
503654100127	200A POWER SOCKET -VE LG 220	TATA spare parts
503654100127AE	200A POWER SOCKET-VE LG 220-1628	TATA spare parts
503654100137	ASSY BATTERY CARRIER WELDED	TATA spare parts
503654107701	STOPPER RUBBER FOR BATTERY (Z-DIRECTION)	TATA spare parts
503654110102	ASSY.BATT.CABLE -VE- BATT CUT OFF SW TO	TATA spare parts

503654110103	ASSY BATT CABLE -VE 120SQ.MM LG 300MM	TATA spare parts
503654110103AE	ASSY BATT CABLE -VE -1628	TATA spare parts
503654110104	BATT.CABLE -VE 120SQ.MM LG 3550 CUT OFF	TATA spare parts
503654110104AE	BATT CABLE -VE SW TO STA -1628	TATA spare parts
503654440103	ASSY.HEAD LAMP RH 24V AUTOLITE LPTA1628	TATA spare parts
503654440103AE	ASSY.HLAMP RH 24V -1628-1828	TATA spare parts
503654440104	ASSY.HEAD LAMP LH 24V AUTOLITE LPTA1628	TATA spare parts
503654440104AE	ASSY.HLAMP LH 24V -1628-1828	TATA spare parts
503654508202	PLATE FOR SWITCH AND PLUG SOCKET MTG	TATA spare parts
503654508205	BKT FOR INDICATOR SW MTG	TATA spare parts
503654508207	SWITCH MTG PLATE (FAT 8X8)	TATA spare parts
503654508208	SW MTG PLATE LPT 1828 6X6 LHD	TATA spare parts
503654508209	SW MTG PLATE (LH SIDE) 4 SW	TATA spare parts
503654600107	BATTERY CABLE -VE (CUTOFF SW TO SM)	TATA spare parts
503654600108	BATTERY CABLE +VE(CUTOFF SW TO SM)	TATA spare parts
503654600109	BATTERY CABLE +VE (BATT TO B.C.SW)	TATA spare parts
503654600110	BATTERY CABLE -VE (BATT TO B.C.SW)	TATA spare parts
503654600112	WIRING HARNESS TAIL	TATA spare parts
503654600114	W/H ENGINE	TATA spare parts
503654600117	WIRING HARNESS ABS	TATA spare parts
503654600119	WIRING HARNESS TAIL	TATA spare parts
503654660101	W/H MAIN (LPTA 1628 LHD ARMY)	TATA spare parts
503654660101AE	W/H MAIN (LPTA 1628 )	TATA spare parts
503654660102	W/H TAIL(LPTA 1628 LHD ARMY)	TATA spare parts
503654660102AE	W/H TAIL LPTA 1628 LHD ARMY 1628	TATA spare parts
503654660103	W/H BUMPER (LPTA 1628 LHD ARMY)	TATA spare parts
503654660103AE	W/H BUMPER (LPTA 1628)	TATA spare parts
503654660104	W/H ENGINE (LPTA 1628 LHD ARMY)	TATA spare parts
503654660105	W/H SWITCH LPTA 1628 LHD ARMY	TATA spare parts
503654660105AE	W/H SW LPTA 1628 LHD ARMY -1628	TATA spare parts
503654660106	W/H DRIVER CABIN ROOF LPTA 1628 LHD ARMY	TATA spare parts
503654660106AE	W/H DRIVER CABIN ROOF LPTA 1628	TATA spare parts
503654660109	W/H POWER PACK¿ LPTA1628 4X4 LHD	TATA spare parts
503656500116	HOSE L BEND & 3/4INCH BSP	TATA spare parts
503682200101	ASSY BKT FOR WASHER BOTTLE MTG	TATA spare parts
503683106301	FACE DUCT	TATA spare parts
503683106302	DEMIST DUCT	TATA spare parts
503683406901	ASSY SUCTION PIPE	TATA spare parts
503683406902	ASSY DISCHARGE PIPE	TATA spare parts
503683406903	ASSY LIQUID PIPE	TATA spare parts
503683607701	HEATER OUTLET HOSE(HVAC TO RAD.PIPE)	TATA spare parts
503683607704	HEATER INLET HOSE(ENGINE TO HVAC)	TATA spare parts
503728500107	AGB MTG BKT LOWER LH	TATA spare parts
503728500108	AGB MTG BKT LOWER RH	TATA spare parts
503728500109	AGB MOUNTING BRACKET-LH (BAR ASM MTG)	TATA spare parts
503728500110	AGB MOUNTING BRACKET-RH (BAR ASM MTG)	TATA spare parts
503728500111	ASSY BAR AGB MTG.	TATA spare parts

503728500115	ASSY BRACKET-RH (AGB MTG)	TATA spare parts
503728500116	ASSY BRACKET -LH (AGB MTG)	TATA spare parts
503728507127	SPACER PLATE (AGB MTG-LH)	TATA spare parts
503731000101	ASSY. FRAME COMPLETE	TATA spare parts
503731000102	FRAME ASSY	TATA spare parts
503740308202	SPACER PLATE (POWER PACK MTG)	TATA spare parts
503740308203	SPACER PLATE (POWER PACK MTG)	TATA spare parts
503740800101	ASSY HOSE POWER PACK-1	TATA spare parts
503740800102	ASSY HOSE FOE POWER PACK-2	TATA spare parts
503741120102	ASSY PROP.SHAFT (GB TO TC)	TATA spare parts
503741120103	ASSY.PROP.SHAFT TC TO FWD.AXLE	TATA spare parts
503741120103AE	ASSY PROP SFT TC TO FW AXLE-1828	TATA spare parts
503741120104	ASSY PROPELLER SHAFT FROM TC TO RA	TATA spare parts
503741120104AE	ASSY PROP SFT TO 2ND F AXLE-1828	TATA spare parts
503743200101	ASSY BRACKET (AIR TANK MTG)	TATA spare parts
503743708202	BRACKET RELAY VALVE MTG LH	TATA spare parts
503743708203	BRACKET RELAY VALVE MTG RH	TATA spare parts
503743900105	ASSY THIRD METAL PIPE COMPRESSOR TO APU	TATA spare parts
503743900107	PIPE ASSY METAL TEFLON HOSE TO 2ND JOINT	TATA spare parts
503743900171	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
503743900184	SET-NYLON PIPE BUNCH COMPLETE	TATA spare parts
503743910101	PIPE ASSY METAL 2ND PIPE TO DCV	TATA spare parts
503743910132	BUNCH PIPE ASSY	TATA spare parts
503745103301	BRACKET SOLENOID VALVE MTG	TATA spare parts
503746800101	SUCTION LINE ASSY RESERVOIR TO PUMP	TATA spare parts
503746800103	RETURN LINE ASSY RESERVOIR END	TATA spare parts
503746990101	KIT-PIPE & ADAPTER	TATA spare parts
503747100101	FUEL TANK ASSY WITH TANK UNIT	TATA spare parts
503747500101	ASSY BRACKET FUEL TANK MTG.	TATA spare parts
503747500102	ASSY. BRACKET FUEL TANK MTG.	TATA spare parts
503747500103	ASSY. BRACKET FUEL TANK MTG.	TATA spare parts
503747507101	SPACER (FUEL TANK MTG. BKT.)	TATA spare parts
503747507102	SPACER (FUEL TANK MTG. BKT.)	TATA spare parts
503747507103	SPACER (FUEL TANK MTG. BKT)	TATA spare parts
503747600101	ASSY.FUEL SUCTION LINE FROM F/T <sub>2</sub> TO W/S	TATA spare parts
503747600102	ASSY FUEL RETURN LINE	TATA spare parts
503747600103	ASSY FUEL SUCTION LINE FROM W/S TO FIP	TATA spare parts
503747600108	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
503747600109	FUEL SUCTION PIPE ASSY FILTER TO FIP	TATA spare parts
503747600111	FUEL RETURN PIPE ASSY FIP TO FUEL TANK	TATA spare parts
503749100102	STRAP ASSY SILENCER MTG	TATA spare parts
503749103302	BRACKET	TATA spare parts
503749103303	BRACKET	TATA spare parts
503749109901	HEAT SHIELD EXHAUST ELBOW	TATA spare parts
503749109902	HEAT SHIELD EXHAUST PIPE	TATA spare parts
503749109903	HEAT SHIELD EXHAUST BRAKE	TATA spare parts
503749109904	HEAT SHIELD STRAIGHT	TATA spare parts

503749109905	HEAT SHIELD BEND	TATA spare parts
503749109906	HEAT SHIELD EXHAUST	TATA spare parts
503749109907	HEAT SHIELD EXHAUST PIPE	TATA spare parts
503749109909	HEAT SHIELD EXHAUST SILENCER	TATA spare parts
503749109911	HEAT SHIELD EXHAUST PIPE	TATA spare parts
503749109941	HEAT SHIELD COVER	TATA spare parts
503749109942	HEAT SHIELD SPARK ARRESTER	TATA spare parts
503749109943	END CAP HEAT SHIELD	TATA spare parts
503749200108	EXHAUST PIPE ASSY	TATA spare parts
503749200109	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
503749200111	BRACKET ASSY	TATA spare parts
503749907121	BRACKET SPARK ARRESTER MTG	TATA spare parts
503749990101	KIT-EXHAUST HEAT SHIELD	TATA spare parts
503749990102	KIT-EXHAUST HEAT SHIELD	TATA spare parts
503754100103	ASSY BATT CABLE +VE 3150 MM LG (CUT OFF	TATA spare parts
503754110102	ASSY.BATT.CABLE -VE 3100 MM LG (CUT OFF	TATA spare parts
503754304901	AIR PRESSURE TRANSDUCER	TATA spare parts
503754600104	W/H ABS 4S/4M	TATA spare parts
503754600107	WIRING HARNESS MAIN	TATA spare parts
503754600109	W/H TAIL	TATA spare parts
503754600111	W/H ENGINE	TATA spare parts
503754600112	BATTERY CABLE -VE (CUTOFF SW TO SM)	TATA spare parts
503754600113	BATTERY CABLE +VE(CUTOFF SW TO SM)	TATA spare parts
503754600114	BATTERY CABLE +VE (BATT TO B.C.SW)	TATA spare parts
503754600115	BATTERY CABLE -VE (BATT TO B.C.SW)	TATA spare parts
503754600120	BATTERY CABLE JUMP START SOCKET ASSY	TATA spare parts
503754600122	W/H BUMPER	TATA spare parts
503754600125	WIRING HARNESS MAIN	TATA spare parts
503754600129	WIRING HARNESS ENGINE	TATA spare parts
503754600131	WIRING HARNESS BUMPER	TATA spare parts
503754600132	WIRING HARNESS ABS	TATA spare parts
503754660101	W/H ENGINE (LPTA 1828 6X6 LHD)	TATA spare parts
503754660101AE	W/H ENG (LPTA 1828;6X6 LHD) 1628	TATA spare parts
503754660102	WIRING HARNESS TAIL	TATA spare parts
503754660103	W/H POWER PACK	TATA spare parts
503900990002	ASSY GSA KIT FOR LPT3718 COWL	TATA spare parts
503900990003	ASSY GSA KIT FOR 3718.T SIGNA	TATA spare parts
503900990005	SPARE KIT ASSEMBLY OF VTS AND EMERGENCY	TATA spare parts
50390668000R40	ASSY. COWL W/O FITMENT LPT3718 BS4	TATA spare parts
50390668000RCK	ASSY COWL KIT W/FITMENTS LPT3718 BS4	TATA spare parts
503924200103	REAR ENGINE MOUNT (ENGINE SIDE)	TATA spare parts
503924200104	ASSY.BRACKET-LH (ENG.MTG REAR-BOTTOM)	TATA spare parts
503924200105	ASSY.BRACKET-RH (ENG.MTG REAR-BOTTOM)	TATA spare parts
503924200106	ASSY. BRACKET-LH (ENGINE MTG. REAR)	TATA spare parts
503924200107	ASSY. BRACKET-RH (ENGINE MTG. REAR)	TATA spare parts
503924200110	ASSY BRACKET ( ENG.MTG REAR TOP )	TATA spare parts
503924200111	ASSY.BKT FOR 5TH SUPPORT ON LM-RH	TATA spare parts

503924200112	ASSY.BKT.FOR 5TH SUPPORT ON LM-LH	TATA spare parts
503924200121	BRACKET ASSY ENGINE MTG TOP REAR	TATA spare parts
503926800101	TURNING TUBE (WITHOUT BALL JOINT)	TATA spare parts
503926800105	ASSY GEAR SHIFT LEVER	TATA spare parts
503926800106	GS LEVER WITH YOKE	TATA spare parts
503926810101	ASSY BRACKET	TATA spare parts
503926900101	ASSY HOSE - OIL HOSE OUT	TATA spare parts
503926900102	ASSY HOSE - OIL HOSE IN	TATA spare parts
503926907101	BRACKET LH - OIL COOLER	TATA spare parts
503926907102	BRACKET RH - OIL COOLER	TATA spare parts
503929100102	ASSY. HYD. PIPE (TO CLUTCH BOOSTER)	TATA spare parts
503929100103	ASSY. PIPE (M/CYL TO 2ND PIPE)	TATA spare parts
503929200101	ASSY. CLUTCH BOOSTER MTG. BKT.	TATA spare parts
503929300101	ASSY. CLUTCH BOOSTER BS3/4	TATA spare parts
503929300102	BUNDY TUBE ASSY CMC TO LONG MEMBER	TATA spare parts
503929300103	BUNDY TUBE ASSY LONG MEMBER	TATA spare parts
503929300105	CLUTCH HIGH PRESSURE HOSE	TATA spare parts
503929300107	CLUTCH CONTROL ASSY WITH SUPPORT	TATA spare parts
503929300108	MAJOR KIT-CLUTCH BOOSTER	TATA spare parts
503929300109	CLUTCH BOOSTER ASSY	TATA spare parts
503929500102	BRACKET ASSY CLUTCH PEDAL MTG	TATA spare parts
503931000102	ASSY. FRAME COMPLETE	TATA spare parts
503931000106	ASSY. FRAME WITH FITMENT BS3	TATA spare parts
503931000113	FRAME ASSY	TATA spare parts
503931000116	ASSY. FRAME WITH FITMENT BS3	TATA spare parts
503931000120	ASSY. FRAME LPT3718	TATA spare parts
503931000121	FRAME ASSY WITH FITMENT	TATA spare parts
503931000122	FRAME ASSY	TATA spare parts
503931000123	FRAME ASSY	TATA spare parts
503931000124	FRAME ASSY WITH FITMENT	TATA spare parts
503931000126	FRAME ASSY WITH FITMENT	TATA spare parts
503931000127	FRAME ASSY WITH FITMENT	TATA spare parts
503931000128	ASSY. FRAME WITH FITMENT BS4	TATA spare parts
503931000130	ASSY. FRAME WITH FITMENT BS4	TATA spare parts
503931000132	FRAME ASSY WITH FITMENT	TATA spare parts
503931000146	FRAME ASSY WITH FITMENT BS6	TATA spare parts
503931000149	FRAME ASSY WITH FITMENT	TATA spare parts
503931000155	FRAME ASSY WITH FITMENT	TATA spare parts
503931000159	FRAME ASSY WITH FITMENT	TATA spare parts
503931000160	FRAME ASSY WITH FITMENT	TATA spare parts
503931000171	FRAME ASSY WITH FITMENT	TATA spare parts
503931107125	REINFORCEMENT LH	TATA spare parts
503931107126	REINFORCEMENT RH	TATA spare parts
503931107140	REINFORCEMENT RH	TATA spare parts
503931107141	REINFORCEMENT LH	TATA spare parts
503931107142	REINFORCEMENT RH	TATA spare parts
503931107143	REINFORCEMENT LH	TATA spare parts

503931107144	REINFORCEMENT REAR-RH	TATA spare parts
503931107145	REINFORCEMENT REAR-LH	TATA spare parts
503931107146	REINFORCEMENT CROSS MEMBER	TATA spare parts
503931107147	REINFORCEMENT SPRING CROSS MEMBER RH	TATA spare parts
503931107148	REINFORCEMENT SPRING CROSS MEMBER LH	TATA spare parts
503931107156	REINFORCEMENT REAR-RH	TATA spare parts
503931107157	REINFORCEMENT REAR-LH	TATA spare parts
503931107162	REINFORCEMENT LONG MEMBER FRONT-RH	TATA spare parts
503931107163	REINFORCEMENT LONG MEMBER FRONT-LH	TATA spare parts
50393110716335	REINFORCEMENT LM FRONT-LH UNPAINTED	TATA spare parts
503931107164	REINFORCEMENT CROSS MEMBER	TATA spare parts
503931107167	REINFORCEMENT CROSS MEMBER RH	TATA spare parts
503931107168	REINFORCEMENT CROSS MEMBER LH	TATA spare parts
503931107169	REINFORCEMENT REAR SPRING HANGER BKT RH	TATA spare parts
503931107170	REINFORCEMENT REAR SPRING HANGER BKT LH	TATA spare parts
503931107174	SUPPORT PLATE	TATA spare parts
503931107175	REINFORCEMENT SPRING CROSS MEMBER RH	TATA spare parts
503931107176	REINFORCEMENT SPRING CROSS MEMBER LH	TATA spare parts
503931107186	REINFORCEMENT RH	TATA spare parts
503931107187	REINFORCEMENT LH	TATA spare parts
503931107197	SUPPORT PLATE BS6	TATA spare parts
503931117103	REINFORCEMENT RH	TATA spare parts
503931117104	REINFORCEMENT LH	TATA spare parts
503931200104	ASSY.CM C-TYPE WITH SQUARE PLATE	TATA spare parts
503931200118	ASSEMBLY SUPPORT - RH (III CM)	TATA spare parts
503931200119	ASSEMBLY SUPPORT - LH (III CM)	TATA spare parts
503931200120	ASSY. RADIATOR MTG. BRACKET-RH	TATA spare parts
503931200121	ASSY. RADIATOR MTG. BRACKET-LH	TATA spare parts
503931200126	ASSY. C/M (C-TYPE)	TATA spare parts
503931200127	ASSY. GUSSET FOR CM-RH WITH L-BRACKET	TATA spare parts
503931200128	ASSY. GUSSET FOR CM-LH WITH L-BRACKET	TATA spare parts
503931200133	ASSY. CROSS MEMBER (HAT TYPE)	TATA spare parts
503931200139	CROSS MEMBER ASSY 4TH	TATA spare parts
50393120013935	CROSS MEMBER ASSY 4TH UNPAINTED	TATA spare parts
503931200141	BRACKET ASSY RAIDATOR MTG LH	TATA spare parts
503931200144	CROSS MEMBER ASSY	TATA spare parts
503931200145	CROSS MEMBER ASSY WITH SQUARE PLAT	TATA spare parts
503931200146	CROSS MEMBER ASSY	TATA spare parts
503931200149	BRACKET ASSY RAIDATOR MTG RH	TATA spare parts
503931200151	BRACKET ASSY RADIATOR MTG RH	TATA spare parts
503931200152	BRACKET ASSY RADIATOR MTG LH	TATA spare parts
503931200153	CROSS MEMBER ASSY 5TH	TATA spare parts
503931200154	CROSS MEMBER ASSY BUMPER	TATA spare parts
50393120015435	CROSS MEMBER ASSY BUMPER BS6 PH2	TATA spare parts
503931200156	CROSS MEMBER ASSY	TATA spare parts
503931200158	CROSS MEMBER ASSY	TATA spare parts
503931200159	CROSS MEMBER ASSY	TATA spare parts

503931200161	CROSS MEMBER ASSY ENGINE MTG FRONT BS6	TATA spare parts
503931200163	CROSS MEMBER ASSY	TATA spare parts
503931200164	CROSS MEMBER ASSY BS6	TATA spare parts
503931200166	CROSS MEMBER ASSY BS6	TATA spare parts
503931200167	CROSS MEMBER ASSY BS6	TATA spare parts
503931200169	CROSS MEMBER ASSY BS6	TATA spare parts
503931200170	SUPPORT ASSY RH BS6	TATA spare parts
503931200171	SUPPORT ASSY LH BS6	TATA spare parts
503931200172	CROSS MEMBER ASSY ENGINE MTG FRONT BS6	TATA spare parts
503931200175	CROSS MEMBER ASSY BS6	TATA spare parts
503931200182	CROSS MEMBER ASSY BS6	TATA spare parts
503931207121	CM LIFT AXLE SUPPORT	TATA spare parts
503931207141	END CROSS MEMBER	TATA spare parts
503931207149	CROSS MEMBER	TATA spare parts
50393120714935	CROSS MEMBER UNPAINTED	TATA spare parts
503931207150	CROSS MEMBER BS6	TATA spare parts
503931207152	CROSS MEMBER BS6	TATA spare parts
503931207158	CROSS MEMBER BS6	TATA spare parts
503931207171	END CROSS MEMBER BS6	TATA spare parts
503931207172	SUPPORT OUTER-RH	TATA spare parts
503931207173	SUPPORT OUTER-LH	TATA spare parts
503931208601	SHIM (ENGINE REAR CM)	TATA spare parts
503931208603	SUPPORT PLATE (MIDDLE SPRING HANGER)	TATA spare parts
503931300101	ASSY. GUSSET REINFORCEMENT - LH	TATA spare parts
503931300102	ASSY. GUSSET REINFORCEMENT - RH	TATA spare parts
503931300103	EXT. BUMP STOPER	TATA spare parts
503931300120	GUSSET ASSY CROSS MEMBER BS6	TATA spare parts
50393130012035	GUSSET ASSY CROSS MEMBER BS6 PH2	TATA spare parts
503931307125	REINFORCEMENT REAR - RH	TATA spare parts
503931307126	REINFORCEMENT REAR - LH	TATA spare parts
503931307139	BOTTOM GUSSET - RH(LIFT AXLE SUPPORT CM)	TATA spare parts
503931307140	BOTTOM GUSSET - LH(LIFT AXLE SUPPORT CM)	TATA spare parts
503931307141	TOP GUSSET - RH (LIFT AXLE SUPPORT CM)	TATA spare parts
503931307142	TOP GUSSET - LH (LIFT AXLE SUPPORT CM)	TATA spare parts
503931307148	REINFORCEMENT REAR - RH	TATA spare parts
503931307149	REINFORCEMENT REAR - LH	TATA spare parts
503931307155	SUPPORT BOTTOM OUTER-RH	TATA spare parts
50393130715535	SUPPORT BOTTOM OUTER-RH_UNPAINTED	TATA spare parts
503931307156	SUPPORT BOTTOM OUTER-LH	TATA spare parts
50393130715635	SUPPORT BOTTOM OUTER-LH_UNPAINTED	TATA spare parts
503931307166	REINFORCEMENT BUMPER CROSS MEMBER LH	TATA spare parts
50393130716635	REINFORCEMENT,BUMPER MBR,LH	TATA spare parts
503931307167	REINFORCEMENT BUMPER CROSS MEMBER RH	TATA spare parts
50393130716735	REINFORCEMENT,BUMPER CROSS ,RH	TATA spare parts
503931307168	GUSSET BUMPER CROSS MEMBER LH	TATA spare parts
50393130716835	GUSSET BUMPER CROSS MEMBER LH UNPAINTED	TATA spare parts
503931307169	GUSSET BUMPER CROSS MEMBER RH	TATA spare parts

50393130716935	GUSSET BUMPER CROSS MEMBER RH UNPAINTED	TATA spare parts
503931307180	REINFORCEMENT RH	TATA spare parts
503931307181	REINFORCEMENT LH	TATA spare parts
503931307182	SPACER	TATA spare parts
503931307186	GUSSET BUMPER CROSS MEMBER RH BS6	TATA spare parts
503931307187	GUSSET BUMPER CROSS MEMBER LH BS6	TATA spare parts
503931307192	REINFORCEMENT BUMPER CROSS MEMBER RH BS6	TATA spare parts
503931307193	REINFORCEMENT BUMPER CROSS MEMBER LH BS6	TATA spare parts
503931317101	GUSSET TOP-LH BS6	TATA spare parts
503931317102	GUSSET TOP-RH BS6	TATA spare parts
503931317103	GUSSET BOTTOM RH BS6	TATA spare parts
503931317104	GUSSET BOTTOM LH BS6	TATA spare parts
503931317113	SUPPORT PLATE BS6	TATA spare parts
503931317174	GUSSET CROSS MEMBER LH BS6	TATA spare parts
503931317175	GUSSET CROSS MEMBER RH BS6	TATA spare parts
503931506701	COUPLING PIN	TATA spare parts
503931540104	BRACKET ASSY BATTERY TRAY MTG	TATA spare parts
503931540106	BATTERY SUPPORT ASSY	TATA spare parts
503931540107	BRACKET ASSY BATTERY TRAY MTG	TATA spare parts
503931540111	BRACKET ASSY BATTERY TRAY MTG	TATA spare parts
503931540121	BRACKET ASSY BATTERY TRAY MTG BS6	TATA spare parts
503931540122	BRACKET ASSY BATTERY TRAY MTG BS6	TATA spare parts
503931543301	C-CHANNEL BATTERY FIXING TOP	TATA spare parts
503931543302	C-CHANNEL BATTERY FIXING TOP	TATA spare parts
503931700103	ASSY. ENGINE BOTTOM SHIELD	TATA spare parts
503931700104	ASSY. TRANSMISSION SHIELD (REAR SIDE)	TATA spare parts
503931700107	ASSY COWL LH SHIELD	TATA spare parts
503931700108	ASSY TRANSMISSION SHIELD	TATA spare parts
503931700109	ASSY. TRANSMISSION SHIELD FRONT SIDE	TATA spare parts
503931700110	ASSY. COWL RH SHIELD	TATA spare parts
503931700114	ASSY. BRACKET & BOTTOM SHIELD MTG.	TATA spare parts
503931700117	BRACKET ASSY FUPD LH	TATA spare parts
503931700118	BRACKET ASSY FUPD RH	TATA spare parts
503931700123	BRACKET ASSY RUPD MTG LH	TATA spare parts
503931700124	BRACKET ASSY RUPD MTG RH	TATA spare parts
503931700128	BRACKET ASSY GEAR BOX MTG RH	TATA spare parts
503931700129	BRACKET ASSY GEAR BOX MTG LH	TATA spare parts
503931700131	BRACKET ASSY RADIATOR MTG RH	TATA spare parts
50393170013135	BRACKET ASSY RADIATOR MTG RH UNPAINTED	TATA spare parts
503931700132	BRACKET ASSY RADIATOR MTG LH	TATA spare parts
503931700133	BRACKET ASSY RADIATOR MTG RH	TATA spare parts
50393170013335	BRACKET ASSY RADIATOR MTG RH UNPAINTED	TATA spare parts
503931700134	BRACKET ASSY RADIATOR MTG LH	TATA spare parts
50393170013435	BRACKET ASSY RADIATOR MTG LH UNPAINTED	TATA spare parts
503931700150	SUPPORT ASSY RADIATOR MTG RH BS6	TATA spare parts
503931700151	SUPPORT ASSY RADIATOR MTG LH BS6	TATA spare parts
503931700153	BRACKET ASSY RAIDATOR MTG RH BS6	TATA spare parts



503931700154	BRACKET ASSY RAIDATOR MTG LH BS6	TATA spare parts
503931700171	BRACKET ASSY RAIDATOR MTG RH BS6	TATA spare parts
503931700172	BRACKET ASSY RAIDATOR MTG LH BS6	TATA spare parts
503931700173	SUPPORT ASSY RADIATOR MTG RH BS6	TATA spare parts
503931700174	SUPPORT ASSY RADIATOR MTG LH BS6	TATA spare parts
503931703301	SUPPORT BRACKET TRANSMISSION SHIELD LH	TATA spare parts
503931703302	SUPPORT BRACKET TRANSMISSION SHIELD TOP	TATA spare parts
503931703305	Z-SUPPORT BRACKET MIDDLE TRN SIDE	TATA spare parts
503931703307	SUPPORT BRACKET TRANSMISSION SHIELD RH	TATA spare parts
503931703309	L-PLATE TRANS. SHIELD MTG.	TATA spare parts
503931707124	RUBBER PACKING	TATA spare parts
503932100106	ASSY BUMP STOPPER ON FRAME FFWD-LH	TATA spare parts
503932100107	ASSY BUMP STOPPER ON FRAME FFWD-RH	TATA spare parts
503932100108	ASSY BUMP STOPPER ON FRAME FRWD BS6	TATA spare parts
503932100109	ASSY. LINK ROD BS3/4/6	TATA spare parts
503932100114	ASSY BELL CRANK LEAVER FFWD-LH	TATA spare parts
503932100115	ASSY BELL CRANK LEAVER FFWD-RH	TATA spare parts
503932100116	ASSY BELL CRANK LEAVER FRWD-LH	TATA spare parts
503932100117	ASSY BELL CRANK LEAVER FRWD-RH	TATA spare parts
503932100118	ASSY BRACKET AXLE STOPPER FRWD-LH	TATA spare parts
503932100119	ASSY BRACKET AXLE STOPPER FRWD-RH	TATA spare parts
503932100122	ASSY 3 LEAF PARABOLIC SPRING-FRWD	TATA spare parts
503932100132	BUMP STOPPER ASSY	TATA spare parts
503932100133	PARABOLIC LEAF SPRING ASSY	TATA spare parts
503932100134	PARABOLIC LEAF SPRING ASSY	TATA spare parts
503932100136	BUMP STOPPER ASSY FRONT	TATA spare parts
503932100137	PARABOLIC LEAF SPRING ASSY FRONT	TATA spare parts
503932100138	PARABOLIC LEAF SPRING ASSY REAR	TATA spare parts
503932100175	BRACKET ASSY SPRING HANGER MIDDLE-LH BS6	TATA spare parts
503932100176	BRACKET ASSY SPRING HANGER MIDDLE-LH BS6	TATA spare parts
503932100178	RUBBER BUSH ASSY BS6	TATA spare parts
503932100180	BRACKET ASSY SPRING HANGER REAR BS6	TATA spare parts
503932100188	PARABOLIC LEAF SPRING ASSY FRONT FWD BS6	TATA spare parts
503932100189	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
503932100190	1ST LEAF ASSY BS6	TATA spare parts
503932100191	PARABOLIC LEAF SPRING ASSY FRONT RWD BS6	TATA spare parts
503932100195	PARABOLIC LEAF SPRING ASSY FRONT FWD BS6	TATA spare parts
503932100196	PARABOLIC LEAF SPRING ASSY FRONT RWD BS6	TATA spare parts
503932100197	BUMP STOPPER ASSY BS6	TATA spare parts
503932101612	RUBBER BUSH ASSY BS6-PH2	TATA spare parts
503932103202	CENTRE BOLT	TATA spare parts
503932103203	CENTRE BOLT	TATA spare parts
503932103204	HEX BOLT BS6	TATA spare parts
503932103210	CENTRE BOLT M16X1.5X175	TATA spare parts
503932103211	CENTRE BOLT M16X1.5X185 BS6	TATA spare parts
503932103212	CENTRE BOLT M16X1.5X143	TATA spare parts
503932103213	CENTER BOLT BS6	TATA spare parts

503932103217	HEX BOLT BS6	TATA spare parts
503932103218	CENTER BOLT M16X1.5X127	TATA spare parts
503932103219	CENTER BOLT M16X1.5X160	TATA spare parts
503932103220	CENTER BOLT BS6	TATA spare parts
503932103223	HEX BOLT BS6	TATA spare parts
503932103229	CENTER BOLT BS6	TATA spare parts
503932103304	SPRING HANGER MOUNTING BRACKET-FRONT	TATA spare parts
503932103312	BRACKET SPRING HANGER MIDDLE-LH	TATA spare parts
503932103313	BRACKET SPRING HANGER MIDDLE-RH	TATA spare parts
503932103322	GUIDE PLATE	TATA spare parts
503932103712	GUIDE PLATE	TATA spare parts
503932104201	SPRING CLIP BS6-PH2	TATA spare parts
503932104205	U-BOLT BS6 PH2	TATA spare parts
503932104208	SPRING CLIP BS6	TATA spare parts
503932104209	SPRING CLIP BS6	TATA spare parts
503932104210	SPRING CLIP BS6	TATA spare parts
503932104211	SPRING CLIP BS6-PH2	TATA spare parts
503932106501	HEX NUT BS6	TATA spare parts
503932106507	HEX NUT BS6	TATA spare parts
503932106508	HEX NUT BS6	TATA spare parts
503932107107	SPACER (BUMP STOPPER)	TATA spare parts
503932107120	SPACER PLATE BS6	TATA spare parts
503932107126	CASTER PLATE BS6	TATA spare parts
503932107146	SPACER	TATA spare parts
503932107163	CASTER PLATE BS6-PH2	TATA spare parts
503932107170	CASTER PLATE	TATA spare parts
503932107171	SPACER	TATA spare parts
503932107177	SPACER BS6-PH2	TATA spare parts
503932107182	4TH LEAF BS6	TATA spare parts
503932107184	PACKING PLATE BS6-PH2	TATA spare parts
503932107187	3RD LEAF BS6	TATA spare parts
503932107188	2ND LEAF BS6	TATA spare parts
503932107189	3RD LEAF BS6	TATA spare parts
503932107190	2ND LEAF BS6	TATA spare parts
503932107403	RIVET BS6	TATA spare parts
503932107404	RIVET BS6	TATA spare parts
503932107405	RIVET BS6	TATA spare parts
503932107701	RUBBER STOPPER	TATA spare parts
503932108610	SPACER TUBE BS6	TATA spare parts
503932108611	CENTER LINER BS6-PH2	TATA spare parts
503932108612	CENTER LINER BS6	TATA spare parts
503932108613	CENTER PAD BS6	TATA spare parts
503932110101	PARABOLIC LEAF SPRING ASSY FRONT	TATA spare parts
503932110102	PARABOLIC LEAF SPRING ASSY REAR	TATA spare parts
503932110103	PARABOLIC LEAF SPRING ASSY FRONT FWD	TATA spare parts
503932110104	PARABOLIC LEAF SPRING ASSY FRONT RWD	TATA spare parts
503932110110	RUBBER BUSH ASSY BS6	TATA spare parts

503932110119	PARABOLIC LEAF SPRING ASSY FRONT RWD	TATA spare parts
503932110120	PARABOLIC LEAF SPRING ASSY FRONT FWD	TATA spare parts
503932110122	PARABOLIC LEAF SPRING ASSY FRONT FWD BS6	TATA spare parts
503932110123	PARABOLIC LEAF SPRING ASSY FRONT RWD BS6	TATA spare parts
503932110124	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
503932110125	1ST LEAF ASSY BS6-PH2	TATA spare parts
503932110132	BUMP STOPPER ASSY FRONT BS6	TATA spare parts
503932110133	BUMP STOPPER ASSY FRONT BS6	TATA spare parts
503932110134	BUMP STOPPER ASSY FRONT BS6	TATA spare parts
503932117103	SPACER BS6-PH2	TATA spare parts
503932117106	CASTER PLATE BS6-PH2	TATA spare parts
503932117107	2ND LEAF BS6-PH2	TATA spare parts
503932117109	4TH LEAF BS6-PH2	TATA spare parts
503932117110	CASTER PLATE BS6-PH2	TATA spare parts
503932117111	3RD LEAF BS6-PH2	TATA spare parts
503932117112	2ND LEAF BS6-PH2	TATA spare parts
503932117116	3RD LEAF BS6-PH2	TATA spare parts
503932117123	SPACER PLATE BS6-PH2	TATA spare parts
503932300101	ASSY SHOCK ABSORBER BKT TOP FFWD	TATA spare parts
503932300104	ASSY SHOCK ABSORBER BKT TOP	TATA spare parts
503932300105	BRACKET ASSY FRONT SHOCK ABSORBER MTG	TATA spare parts
503932300107	BRACKET ASSY FRONT SHOCK ABSORBER TOP	TATA spare parts
503932300108	BRACKET ASSY FRONT SHOCK ABSORBER TOP	TATA spare parts
503932300111	BRACKET ASSY FRONT SHOCK ABSORBER TOP BS	TATA spare parts
503932300112	BRACKET ASSY FRONT SHOCK ABSORBER TOP BS	TATA spare parts
503932400123	BELL CRANK LEVER ASSY BS6-PH2	TATA spare parts
503932400124	KIT-BELL CRANK LEVER & LINK ROD BS6 PH2	TATA spare parts
503932403201	CENTER BOLT	TATA spare parts
503932403701	BRACKET SPRING HANGER REAR-MIDDLE	TATA spare parts
503932404201	SPRING CLIP REAR SPRING BS6	TATA spare parts
503932406501	HEX NUT	TATA spare parts
503932990101	KIT-RETRO FITMENT FOR WASHER SPRING PIN	TATA spare parts
503933000101	ASSY.FRONT FWD AXLE COMPLETE WITH BRAKES	TATA spare parts
503933000102	ASSY.FRONT RDW AXLE COMPLETE WITH BRAKES	TATA spare parts
503933000103	ASSLY TAG AXLE COMPLETE WITH BRAKES	TATA spare parts
503933000106	FRONT AXLE ASSY WITH BRAKE FRT FWD	TATA spare parts
503933000107	FRONT AXLE ASSY WITH BRAKE FRT RWD	TATA spare parts
503933000111	FRONT AXLE ASSY WITH BRAKE FRT FWD	TATA spare parts
503933000112	FRONT AXLE ASSY WITH BRAKE FRT RWD	TATA spare parts
503933000113	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
503933000114	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
503933000116	LIFT AXLE ASSY WITH BRAKE	TATA spare parts
503933000117	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
503933000118	TAG AXLE ASSY WITH BRAKE BS6	TATA spare parts
503933000119	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
503933105101	ASSY. FRONT AXLE BEAM 7.5T 6.5DEG BS3	TATA spare parts
503933105103	FRONT AXLE BEAM	TATA spare parts

503933105104	FRONT AXLE BEAM	TATA spare parts
503933200101	ASSY STUB AXLE NORMAL-M20	TATA spare parts
503933200103	ASSY.KNUCKLE LH NON ABS(4NOS. M12X1.25)	TATA spare parts
503933200104	ASSY.KNUCKLE RH NON ABS(4NOS. M12X1.25)	TATA spare parts
503933209101	WASHER 31	TATA spare parts
503933800106	ASSY.TIE ROD COMP	TATA spare parts
503933800111	TIE ROD ASSY	TATA spare parts
503933800112	TIE ROD ASSY	TATA spare parts
503933800113	TIE ROD ASSY	TATA spare parts
503933805101	TIE ROD ARM LH	TATA spare parts
503933805102	TIE ROD ARM RH	TATA spare parts
503933805103	TIE ROD ARM-RH	TATA spare parts
503933805104	TIE ROD ARM-LH	TATA spare parts
503933805105	TIE ROD ARM RH	TATA spare parts
503933805106	TIE ROD ARM LH	TATA spare parts
503933805107	TIE ROD ARM RH	TATA spare parts
503933805108	TIE ROD ARM LH	TATA spare parts
503933900102	ASSY PRESSURE REGULATOR VALVE	TATA spare parts
503933900103	PULL ROD ASSY	TATA spare parts
503933900105	AIR SPRING MTG. LH	TATA spare parts
503933900106	AIR SPRING MTG. RH	TATA spare parts
503933900107	EXTERNAL BUMP STOPER MTG BKT-OUTER (32AX)	TATA spare parts
503933900108	AXLE SEAT LH	TATA spare parts
503933900109	AXLE SEAT RH	TATA spare parts
503933900112	BEAM ASSEMBLY LH	TATA spare parts
503933900114	BEAM ASSEMBLY RH	TATA spare parts
503933900115	REBOUND CLIP FINISHED	TATA spare parts
503933900123	KIT ASSY.LIFT AXLE PIPING & CLAMPS	TATA spare parts
503933900165	KIT-NYLON PIPE ASSY	TATA spare parts
503933900173	LINK ROD ASSY	TATA spare parts
503933900189	NYLON PIPE ASSY	TATA spare parts
503933900190	NYLON PIPE ASSY	TATA spare parts
503933900191	NYLON PIPE ASSY	TATA spare parts
503933900192	NYLON PIPE ASSY	TATA spare parts
503933900196	NYLON PIPE ASSY	TATA spare parts
503933900201	LIFT AXLE CONTROL VALVE (GEN-2)	TATA spare parts
503933900202	LOAD SENSING VALVE (WITH P CLAMP)	TATA spare parts
503933900221	HENDRICKSON KIT FOR TAG LIFT AXLE	TATA spare parts
503933900237	BUMP STOPPER ASSY	TATA spare parts
503933900245	ASSLY LSV LINK MTG BKT	TATA spare parts
503933900247	COIL ASSLY	TATA spare parts
503933900252	AIR SPRING MTG. LH	TATA spare parts
503933900253	AIR SPRING MTG. RH	TATA spare parts
503933900266	VALVE WITH SEALING BS6	TATA spare parts
503933900270	BEAM ASSY LH	TATA spare parts
503933900271	BEAM ASSY RH	TATA spare parts
503933900274	AIR SPRING MTG LH	TATA spare parts

503933900275	AIR SPRING MTG RH	TATA spare parts
503933900276	AXLE SEAT ASSY LH	TATA spare parts
503933900277	AXLE SEAT ASSY RH	TATA spare parts
503933900290	KIT-PUSHER AXLE ASSY PHASE-III WITHOUT A	TATA spare parts
503933900293	BRACKET ASSY	TATA spare parts
503933900306	KIT-LIFT AXLE	TATA spare parts
503933900309	KIT-LIFT AXLE	TATA spare parts
503933900318	BUMP STOPPER ASSY RH	TATA spare parts
503933900320	AIR SPRING MTG RH	TATA spare parts
503933900323	AIR SPRING MTG LH	TATA spare parts
503933900324	AXLE SEAT ASSY LH	TATA spare parts
503933900325	AIR SPRING MTG LH	TATA spare parts
503933900326	AXLE BEAM ASSY RH	TATA spare parts
503933900327	MAIN AIR SPRING	TATA spare parts
503933900328	AXLE SEAT ASSY RH	TATA spare parts
503933900332	AIR SPRING MTG RH	TATA spare parts
503933900341	BUMP STOPPER ASSY LH	TATA spare parts
503933900342	AXLE BEAM ASSY LH	TATA spare parts
503933900345	STABILIZER STEERING DAMPER	TATA spare parts
503933900346	STABILIZER STEERING DAMPER	TATA spare parts
503933900348	AXLE SEAT LH BS6	TATA spare parts
503933900349	KIT-LIFT AXLE BS6	TATA spare parts
503933900351	AXLE SEAT RH BS6	TATA spare parts
503933900353	"STABILIZER,STEERING DAMPER"	TATA spare parts
503933900354	"STABILIZER,STEERING DAMPER"	TATA spare parts
503933900355	AIR SPRING MTG LH	TATA spare parts
503933900365	AIR SPRING MTG RH	TATA spare parts
503933900371	PIPE BUNCH ASSY BS6	TATA spare parts
503933900384	PIPE BUNCH ASSY BS6	TATA spare parts
503933903301	GUSSET BOTTOM - LH	TATA spare parts
503933903302	GUSSET BOTTOM - RH	TATA spare parts
503933903303	GUSSET TOP - RH	TATA spare parts
503933903304	GUSSET TOP - LH	TATA spare parts
503933903307	HANGER LH	TATA spare parts
503933903308	HANGER RH	TATA spare parts
503933903309	U - SECTION	TATA spare parts
503933903310	Z - SECTION	TATA spare parts
503933903311	WEAR PAD	TATA spare parts
503933903315	M27 HARDENED WASHER	TATA spare parts
503933903317	HANGER LH	TATA spare parts
503933903318	HANGER RH	TATA spare parts
503933903330	HANGER RH	TATA spare parts
503933903331	HANGER LH	TATA spare parts
503933903332	HANGER RH	TATA spare parts
503933903334	Z-SECTION	TATA spare parts
503933903336	HANGER LH	TATA spare parts
503933903337	U-SECTION	TATA spare parts

503933903338	U SECTION BS6	TATA spare parts
503933903339	HANGER LH BS6	TATA spare parts
503933903340	HANGER RH BS6	TATA spare parts
503933903361	M27X3 GR 10 NUT	TATA spare parts
503933903367	M27X3X200 LONG 10.9 GRADE BOLT	TATA spare parts
503933903368	M27X3X210 LONG 10.9 GRADE BOLT	TATA spare parts
503933903369	FLANGE BOLT	TATA spare parts
503933904901	CONNECTOR ASSY BS6	TATA spare parts
503933904902	CONNECTOR ASSY BS6	TATA spare parts
503933905300	GASKET	TATA spare parts
503933905301	PLASTIC COVER BS6	TATA spare parts
503933906002	REBOUND STRAP	TATA spare parts
503933906915	NYLON PIPE FROM LSV TO LACV PORT 11	TATA spare parts
503933906917	NYLON PIPE RELAY VALVE TO MAIN BELLOW	TATA spare parts
503933906918	NYLON PIPE RELAY VALVE TO MAIN BELLOW	TATA spare parts
503933906946	NYLON PIPE RELAY VALVE TO LACV PORT 21	TATA spare parts
503933906970	NYLON PIPE FROM TEE1 TO TEE2	TATA spare parts
503933906971	NYLON PIPE RELAY VALVE TO LACV PORT 22	TATA spare parts
503933906973	NYLON PIPE RELAY VALVE TO LIFT BELLOW	TATA spare parts
503933906981	NYLON PIPE TEE3 TO LACV PORT 12	TATA spare parts
503933906982	NYLON PIPE TEE2 TO RELAY VALVE	TATA spare parts
503933906983	NYLON PIPE SUPPLY TO LACV & RELAY VALVE	TATA spare parts
503933906984	NYLON PIPE SUPPLY TO RV MAIN BELLOW	TATA spare parts
503933906985	NYLON PIPE RELAY VALVE TO LIFT BELLOW	TATA spare parts
503933906994	NYLON PIPE FROM TEE TO PLV	TATA spare parts
503933906996	NYLON PIPE FROM PRV TO LSV	TATA spare parts
503933907101	LSV MTG BKT.	TATA spare parts
503933907107	BRACKET (FOR LSV MTG)	TATA spare parts
503933908201	U-SECTION	TATA spare parts
503933908603	SPACER	TATA spare parts
503933908605	SPACER BS6	TATA spare parts
503933909002	PRESSURE LIMITING VALVE ASSY	TATA spare parts
503933909003	LOAD DETECTION VALVE ASSY	TATA spare parts
503933909004	LIFT AXLE CONTROL VALVE ASSY BS6	TATA spare parts
503933909005	PRESSURE LIMITING VALVE ASSY BS6	TATA spare parts
503933909006	PRESSURE LIMITING VALVE ASSY BS6	TATA spare parts
503933909007	LIFT AXLE CONTROL MODULE BS6	TATA spare parts
503933909902	MAIN AIR SPRING BS2/3	TATA spare parts
503933909902DF	AIR SPRING MAIN-6T TAG AXLE-3718	TATA spare parts
503933910122	BRACKET ASSY	TATA spare parts
503933910124	HEIGHT LEVELLING VALVE ASSY	TATA spare parts
503933910125	KIT-NYLON PIPES	TATA spare parts
503933910126	KIT-NYLON PIPES	TATA spare parts
503933990141	KIT-NYLON PIPE ASSY	TATA spare parts
503933990178	MINOR REPAIR KIT BS6	TATA spare parts
503933990179	MINOR REPAIR KIT BS6	TATA spare parts
503933990180	MINOR REPAIR KIT BS6	TATA spare parts

503933990181	MAJOR REPAIR KIT BS6	TATA spare parts
503933990192	PIPE BUNCH ASSY	TATA spare parts
503933990199	PIPE BUNCH ASSY	TATA spare parts
503933990214	KIT-NYLON PIPES	TATA spare parts
503933990219	PIPE BUNCH ASSY	TATA spare parts
503933990252	KIT-NYLON PIPES	TATA spare parts
503933990255	KIT-NYLON PIPES BS6	TATA spare parts
503933990258	KIT-NYLON PIPES BS6	TATA spare parts
50393468000R40	ASSLY CAB WITHOUT FITMENT	TATA spare parts
50393468000RCK	ASSY CABIN WITH FITMENT FOR TATA SIGNA 3	TATA spare parts
50393968000R40	ASSY. COWL COMP. LPT3718 W/O FITMENT BS4	TATA spare parts
503940100119	WHEEL RIM ASSY BS6	TATA spare parts
503940100140	ASSY WHEEL RIM 8.25X22.5	TATA spare parts
503940107101	HOSE	TATA spare parts
503940107102	HOSE	TATA spare parts
503940110106	WHEEL RIM ASSY BS6-PH2	TATA spare parts
503940110123	SENSOR ASSY TPMS BS6-PH2	TATA spare parts
503940110126	WHEEL RIM ASSY BS6 PH2	TATA spare parts
503940300103	BRACKET SPARE WHEEL CARRIER MTG	TATA spare parts
503941100103	ASSY.PROP SHAFT FRONT TC BS3	TATA spare parts
503941100104	ASSY.PROP SHAFT MIDDLE TC BS3	TATA spare parts
503941100105	ASSY.BRACKET PROP.SHAFT REAR	TATA spare parts
503941100107	CENTRE BEARING KIT	TATA spare parts
503941100114	ASSY.PROP SHAFT FRONT LCCR	TATA spare parts
503941105101	FLANGE YOKE	TATA spare parts
503941105102	COMPANION FLANGE	TATA spare parts
503941105103	HEXAGON HEAD BOLT	TATA spare parts
503941105104	COMPANION FLANGE	TATA spare parts
503941106101	OUTER SLINGER	TATA spare parts
503941106102	WASHER	TATA spare parts
503941106103	OUTER SLINGER BS6	TATA spare parts
503941106104	OUTER SLINGER	TATA spare parts
503941109901	UNIT PACK	TATA spare parts
503941109902	CENTER BEARING KIT	TATA spare parts
503941110105	ASSY PROP SHAFT FRONT	TATA spare parts
503941110108	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
503941110109	PROPELLER SHAFT ASSY FRONT	TATA spare parts
503941110110	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
503941110111	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
503941110112	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
503941110114	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
503941110115	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
503941110117	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
503941110118	SHORT FORK TUBE & FRT END PIECE	TATA spare parts
503941110120	PROPELLER SHAFT ASSY FRONT	TATA spare parts
503941110121	PROPELLER SHAFT ASSY MIDDLE	TATA spare parts
503941110122	SHORT FORK TUBE AND FRT END PIECE	TATA spare parts

503941110123	SHORT FORK TUBE AND FRT END PIECE	TATA spare parts
503941110130	PROPELLER SHAFT ASSY FRONT(SPICER MAKE)	TATA spare parts
503941110132	PROPELLER SHAFT ASSY MIDDLE(SPICER MAKE)	TATA spare parts
503941110139	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
503941115101	FLANGE YOKE	TATA spare parts
503941120103	ASSY.PROP SHAFT REAR TC BS3	TATA spare parts
503941120104	ASSY.PROP SHAFT INTERAXLE TC	TATA spare parts
503941120106	ASSY PROP SHAFT REAR	TATA spare parts
503941120109	ASSY.PROP SHAFT REAR LCCR	TATA spare parts
503941120113	PROPELELRSHAFTASSY DRIVE	TATA spare parts
503941120114	UNIT PACK	TATA spare parts
503941120115	ASSY. PROPELELR SHAFT DRIVE BS3/4	TATA spare parts
503941120116	LONG FORK SUB ASSY. (140 SLIP)	TATA spare parts
503941120117	SHORT FORK TUBE & REAR HOUSING SUB ASSY	TATA spare parts
503941120118	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
503941120120	PROPELLER SHAFT ASSY REAR	TATA spare parts
503941120121	SHORT FORK TUBE & REAR END PIECE	TATA spare parts
503941120122	PROPELLER SHAFT ASSY REAR	TATA spare parts
503941120123	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
503941120126	PROPELLER SHAFT ASSY DRIVE(SPICER MAKE)	TATA spare parts
503941120130	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
503941300104	ASSY CENTRE BEARING MTG BRACKET	TATA spare parts
503941303303	CENTRE BEARING MTG. BRACKET-FRONT	TATA spare parts
503941303304	CENTRE BEARING MTG. BRACKET-MIDDLE	TATA spare parts
503941303307	CENTRE BEARING MTG. BRACKET FRONT	TATA spare parts
503941303308	CENTRE BEARING MTG. BRACKET MIDDLE	TATA spare parts
503941303315	BRACKET ASSY CENTER BRG MTG	TATA spare parts
503941303318	BRACKET CENTER BEARING	TATA spare parts
503941303319	BRACKET CENTER BEARING	TATA spare parts
503941303320	BRACKET CENTER BRG MTG BS6	TATA spare parts
503941303321	BRACKET CENTER BRG MTG BS6	TATA spare parts
503941990105	SHORT FORKTUBE & REAR END PIECE	TATA spare parts
503941990110	CENTER BEARING	TATA spare parts
503941990117	CENTER BEARING	TATA spare parts
503941990122	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
503941990123	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
503942100105	ASSY. FR.BRK WITH D/C LH LPT3721	TATA spare parts
503942100106	ASSY. FR.BRK WITH D/C RH LPT3721	TATA spare parts
503942108201	ANCHOR BRACKET LPT 3721	TATA spare parts
503942109901	MAJOR KIT SPARE KIT BRACKET LH	TATA spare parts
503942109902	MAJOR KIT SPARE KIT BRACKET RH	TATA spare parts
503943200101	BRACKET ASSY PING TANK MTG	TATA spare parts
503943200102	ASSEMBLY AIR TANK VOSS-20 LITERS W/O NRV	TATA spare parts
503943200103	ASSY. AIR TANK-40 LTRS VOSS (CD-350)	TATA spare parts
503943200105	BRACKET ASSY AIR TANK MTG RH BS6	TATA spare parts
503943200106	BRACKET ASSY AIR TANK MTG LH BS6	TATA spare parts
503943200108	ASSEMBLY PING TANK MOUNTING BRACKET	TATA spare parts



503943200109	ASSY. FIRST METAL PIPE CLAMP BRACKET	TATA spare parts
503943200110	AIR TANK ASSY 20 LTR WITH 130 PITCH	TATA spare parts
503943200111	AIR TANK ASSY 15 LTR WITH 225 PITCH	TATA spare parts
503943200115	AIR TANK ASSY 30 LTR WITH 302 PITCH	TATA spare parts
503943200117	BRACKET PING TANK MTG	TATA spare parts
503943200118	AIR TANK ASSY WITH FITTINGS(VOSS+METRIC)	TATA spare parts
503943200121	AIR TANK ASSY BS6	TATA spare parts
503943200122	AIR TANK ASSY WITH MTG BKT	TATA spare parts
503943200125	AIR TANK ASSY WITH BKTS & STRAP 20 LTR	TATA spare parts
503943200127	AIR TANK ASSY WITH BKT BS6	TATA spare parts
503943200132	AIR TANK ASSY WITH BKTS & STRAP 30 LTR	TATA spare parts
503943200134	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
503943200136	AIR TANK ASSY WITH FITTINGS	TATA spare parts
503943200137	BRACKET ASSY AIR TANK MTG	TATA spare parts
503943207104	METAL PIPE	TATA spare parts
503943208204	BRACKET FOR SRT AXLE LPT 3721	TATA spare parts
503943700105	TYPE 16 CHAMBER	TATA spare parts
503943700111	LOAD SENSING VALVE-FIXED RATIO	TATA spare parts
503943700115	SPRING BRK. ACTUATOR LH 20/24 BS3/4	TATA spare parts
503943700125	RELAY VALE ASSY WITH BKT VOSS + VOSS	TATA spare parts
503943700129	RELAY VALVE BS6	TATA spare parts
503943700165	VALVE	TATA spare parts
503943700166	AIR PROCESSING UNIT	TATA spare parts
503943700167	CIRCUIT PROTECTION VALVE	TATA spare parts
503943700172	BRAKE CHAMBER	TATA spare parts
503943700179	BRAKE CHAMBER	TATA spare parts
503943700180	PRESSURE LIMITING VALVE	TATA spare parts
503943700182	AIR PROCESSING UNIT	TATA spare parts
503943700184	CIRCUIT PROTECTION VALVE	TATA spare parts
503943700185	AIR PROCESSING UNIT	TATA spare parts
503943700196	SPRING BRAKE ACTUATOR	TATA spare parts
503943703303	BRACKET RELAY VALVE MTG	TATA spare parts
503943710101	BRACKET ASSY	TATA spare parts
503943710157	PRESSURE REDUCTION VALVE	TATA spare parts
503943900108	ASSEMBLY NYLON PIPE SET CHASSIS LPT 3721	TATA spare parts
503943900119	KIT-NYLON PIPE WITH CLAMPS & BKTS	TATA spare parts
503943900127	NYLON PIPE BUNCH ASSY	TATA spare parts
503943900150	ASSY. METAL PIPE COMPRESSOR OUTLET TO JO	TATA spare parts
503943900151	ASSY PING TANK OUTLET TO INTERMIDATED JO	TATA spare parts
503943900152	ASSY. METAL PIPE JOINT-2 TO AIR DRYER IN	TATA spare parts
503943900164	NYLON PIPE ASSY RELAY-2 TO FRWD RH	TATA spare parts
503943900212	NYLON PIPE BUNCH ASSY	TATA spare parts
503943900215	PIPE BUNCH ASSY	TATA spare parts
503943903306	BRACKET HOSE MTG RH	TATA spare parts
503943903309	BRACKET BS6	TATA spare parts
503943903311	BRACKET (HOSE MTG)	TATA spare parts
503943903312	BRACKET BS6	TATA spare parts

503943903313	BRACKET HOSE MOUNTING	TATA spare parts
503943907501	GROMMET BS6	TATA spare parts
503943910136	INTERMIDATED JOINT 1 TO PING TANK INLET	TATA spare parts
503943910138	ASSY METAL PIPE FROM COMPRESSOR END TO P	TATA spare parts
503943910188	ASSY. METAL PIPE(COMP. -PING TANK)BS3/4	TATA spare parts
503943910189	METAL PIPE ASSY PING TANK TO INTM.JOINT	TATA spare parts
503943910194	NYLON PIPE BUNCH ASSY	TATA spare parts
503943920110	PIPE ASSY BUNCH	TATA spare parts
503943920111	NYLON PIPE ASSY BUNCH-COMPLETE	TATA spare parts
503943930162	PIPE ASSY BUNCH COMPLETE	TATA spare parts
503943930169	PIPE ASSY BUNCH COMPLETE	TATA spare parts
503943930180	METAL PIPE ASSY	TATA spare parts
503943930181	METAL PIPE ASSY	TATA spare parts
503943940155	PIPE ASSY 3RD (INT JOINT TO AIR DRYER)	TATA spare parts
503943950131	PIPE BUNCH ASSY	TATA spare parts
503943950149	NYLON PIPE BUNCH ASSY	TATA spare parts
503943950150	METAL PIPE ASSY	TATA spare parts
503943950195	METAL PIPE ASSY	TATA spare parts
503943960112	PIPE BUNCH ASSY	TATA spare parts
503943960158	NYLON PIPE BUNCH ASSY	TATA spare parts
503943960159	NYLON PIPE BUNCH ASSY	TATA spare parts
503943970120	METAL PIPE ASSY BS6	TATA spare parts
503943970121	METAL PIPE ASSY BS6	TATA spare parts
503943970122	METAL PIPE ASSY BS6	TATA spare parts
503943970144	PIPE BUNCH ASSY	TATA spare parts
503943970157	PIPE BUNCH ASSY	TATA spare parts
503943970181	PIPE BUNCH ASSY	TATA spare parts
503943970189	NYLON PIPE BUNCH ASSY	TATA spare parts
503943970204	PIPE BUNCH ASSY	TATA spare parts
503943970217	METAL PIPE ASSY JOINT-2 TO AIR DRYER 1	TATA spare parts
503943990101	REPAIR KIT-TML	TATA spare parts
503946100101	COLUMN ASSY UPPER	TATA spare parts
503946100102	ASSY. POWER STEERING GEAR BOX BS3/4	TATA spare parts
503946100105	STEERING COLUMN ASSY TILT & TELESCOPIC	TATA spare parts
503946100106	BRACKET ASSY STG COLUMN MTG	TATA spare parts
503946100108	INTERMEDIATE SHAFT ASSY	TATA spare parts
503946100109	INTERMEDIATE SHAFT ASSY BS6	TATA spare parts
503946100112	STEERING COLUMN ASSY TILT & TELESCOPIC	TATA spare parts
503946103301	BRACKET FOR STEERING GB MOUNTING	TATA spare parts
503946107101	SPACER PLATE (RELAY ARM MTG.)	TATA spare parts
503946108001	HEX SCREW M20X1.5X40L (FOR STEERING GB	TATA spare parts
503946108003	PAN HEAD SCREW BS6	TATA spare parts
503946300106	ASSY. 1ST DRAG LINK	TATA spare parts
503946300107	ASSY. 1ST RELAY ROD	TATA spare parts
503946300108	ASSY. 2ND RELAY ROD	TATA spare parts
503946300109	ASSY.2ND DRAG LINK	TATA spare parts
503946300114	ASSY. 2ND DRAG LINK	TATA spare parts

503946303704	RELAY ARM BS6	TATA spare parts
503946303705	RELAY ARM BS6	TATA spare parts
503946304101	PITMAN ARM ( GEARBOX)	TATA spare parts
503946304102	RELAY ARM	TATA spare parts
503946304103	IDLER ARM	TATA spare parts
503946304104	PITMAN ARM	TATA spare parts
503946304106	RELAY ARM	TATA spare parts
503946304107	PITMAN ARM STG GEAR BOX	TATA spare parts
503946305101	PITMAN ARM BS6	TATA spare parts
503946305102	RELAY ARM	TATA spare parts
503946305103	PITMAN ARM	TATA spare parts
503946600102	ASSY. STEERING GEAR BOX BS4	TATA spare parts
503946600103	POWER STEERING PUMP ASSY	TATA spare parts
503946600104	POWER CYLINDER ASSY WITH BALL JOINT	TATA spare parts
503946600105	POWER CYLINDER ASSY WITH OUT BALL JOINT	TATA spare parts
503946600108	BRACKET ASSY RESERVOIR MTG BS6	TATA spare parts
503946600110	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
503946600116	STEERING GEAR BOX ASSY BS6	TATA spare parts
503946600119	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
503946600121	STEERING GEAR BOX ASSY BS6	TATA spare parts
503946600123	WORM & RACK ASSY BS6-PH2	TATA spare parts
503946600124	SHAFT ASSY BS6-PH2	TATA spare parts
503946603305	BRACKET CLAMP MTG STG PIPE BS6	TATA spare parts
503946609901	HOUSING ASSEMBLY	TATA spare parts
503946703301	BRACKET FOR RELAY ARM MOUNTING	TATA spare parts
503946703302	BRACKET POWER CYLINDER MTG	TATA spare parts
503946703305	BRACKET STG GEAR BOX MTG BS4/6	TATA spare parts
503946703310	BRACKET STG GEAR BOX MTG BS6	TATA spare parts
503946703313	BRACKET POWER CYL MTG	TATA spare parts
503946703501	BOSS	TATA spare parts
503946703502	BOSS	TATA spare parts
503946800101	ASSY. PRESSURE LINE (PUMP TO GB)	TATA spare parts
503946800102	ASSY.RETURN LINE (GB TO TANK)	TATA spare parts
503946800103	ASSY.PRESSURE LINE (GB TO POWER CYL.)	TATA spare parts
503946800104	ASSY.RETURN LINE (POWER CYL.TO GB)	TATA spare parts
503946800105	ASSY. SUCTION LINE (TANK TO PUMP)	TATA spare parts
503946800110	ASSY. SEALING RING (THREAD SIZE M26X1.5)	TATA spare parts
503946800113	SUCTION LINE ASSY	TATA spare parts
503946800115	RETURN LINE ASSY RESERVOIR END	TATA spare parts
503946800117	HIGH PRESSURE LINE ASSY P/CYL TO GB	TATA spare parts
503946800118	PRESSURE LINE ASSY STG GB TO POWER CYL	TATA spare parts
503946800119	RETURN LINE ASSY	TATA spare parts
503946800120	PRESSURE LINE ASSY	TATA spare parts
503946800122	RETURN LINE ASSY	TATA spare parts
503946800125	PRESSURE LINE ASSY	TATA spare parts
503946800128	SUCTION LINE ASSY BS6	TATA spare parts
503946800129	RETURN LINE ASSY BS6	TATA spare parts

503946800130	SUCTION LINE ASSY BS6	TATA spare parts
503946800131	PRESSURE LINE ASSY BS6	TATA spare parts
503946800133	HIGH PRESSURE LINE ASSY STG GB TO P/CYL	TATA spare parts
503946800134	HIGH PRESSURE LINE ASSY P/CYL TO GB	TATA spare parts
503946800153	PRESSURE LINE ASSY BS6	TATA spare parts
503946900102	RELAY ROD ASSY	TATA spare parts
503946900103	RELAY ROD ASSY	TATA spare parts
503946900104	DRAG LINK ASSY REAR	TATA spare parts
503946900105	BALL JOINT ASSY POWER CYL	TATA spare parts
503946900106	DRAG LINK ASSY BS6-PH2	TATA spare parts
503946900107	RELAY ROD ASSY BS6	TATA spare parts
503946900108	DRAG LINK ASSY FRONT BS6	TATA spare parts
503946900109	DRAG LINK ASSY REAR BS6	TATA spare parts
503946900111	RELAY ROD ASSY BS6	TATA spare parts
503946900113	BALL JOINT ASSY LH BS6-PH2	TATA spare parts
503946900114	BALL JOINT ASSY RH BS6-PH2	TATA spare parts
503946900115	KIT-BALL JOINT DRAG LINK BS6-PH2	TATA spare parts
503946903301	TWIST PLATE	TATA spare parts
503946903302	MTG. PLATE	TATA spare parts
503946913301	CLAMP FOR HYD.PIPING	TATA spare parts
503946990106	ASSY KIT OF PIPELINES & ADAPTERS	TATA spare parts
503946990123	KIT-PIPE & ADAPTER	TATA spare parts
503946990127	MAJOR KIT-SEAL(COMPACT)	TATA spare parts
503946990128	SECTOR SHAFT ASSY	TATA spare parts
503946990129	HOUSING	TATA spare parts
503946990130	KIT-SEAL(OUTPUT SHAFT SIDE)	TATA spare parts
503946990131	MAJOR KIT-SEAL	TATA spare parts
503946990144	RELAY ARM ASSY BS6	TATA spare parts
503946990171	TIE ROD END ASSY LH BS6-PH2	TATA spare parts
503946990173	KIT-BALL JOINT DRAG LINK BS6	TATA spare parts
503946990175	TIE ROD END ASSY RH BS6	TATA spare parts
503946990176	DRAG LINK ASSY RH	TATA spare parts
503946990187	HOUSING ASSY BS6	TATA spare parts
503946990188	WORM & AMP RACK ASSY BS6	TATA spare parts
503946990189	S/SHAFT ASSY BS6	TATA spare parts
503946990190	SEAL ASSY BS6	TATA spare parts
503946990192	KIT-SEAL BS6-PH2	TATA spare parts
503947109201	WASHER BS6-PH2	TATA spare parts
503947109901	PLUG BS6	TATA spare parts
503947600101	FUEL SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
503947600109	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
503947600111	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
503947600113	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
503947600114	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
503947600115	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
503947600124	ASSY. SUCTION LINE	TATA spare parts
503947600127	ASSY RETURN LINE	TATA spare parts

503947600139	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
503947600140	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
503947600141	SUCTION PIPE ASSY TANK TO FILTER	TATA spare parts
503947600142	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
503947600143	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
503947600144	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
503947600145	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
503947600146	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
503947600147	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
503949100113	ASSY. FLEX CONNECTOR	TATA spare parts
503949200102	ASSY EXHAUST PIPE 2ND	TATA spare parts
503949200103	PIPE ASSY T-CONNECTOR TO AIR OIL FILTER	TATA spare parts
503949200105	ASSY. EXHAUST PIPE (THIRD)	TATA spare parts
503949200111	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
503949200112	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
503949200119	EXHAUST PIPE ASSY SECOND	TATA spare parts
503949200122	EXHAUST PIPE ASSY SECOND	TATA spare parts
503949200128	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
503949200130	EXHAUST PIPE ASSY SECOND	TATA spare parts
503949200131	CLAMP ASSY EGP MTG	TATA spare parts
503949203301	BRACKET EXHAUST PIPE FRAME SUPPORT	TATA spare parts
503949203302	BRACKET EXHAUST PIPE MOUNTING	TATA spare parts
503949203303	BRACKET EXHAUST PIPE & SILENCER MTG	TATA spare parts
503949203304	BRACKET EXHAUST PIPE MTG	TATA spare parts
503949203306	L-BRACKET	TATA spare parts
503949203308	BRACKET TAIL PIPE MTG	TATA spare parts
503949203313	BRACKET EGP MTG	TATA spare parts
503949203315	BRACKET EGP MTG	TATA spare parts
503949203317	BRACKET EXHAUST PIPE CLAMPING	TATA spare parts
503949203319	BRACKET TAIL PIPE MTG	TATA spare parts
503949204201	CLAMP EGP MTG	TATA spare parts
503949206903	TAIL PIPE	TATA spare parts
503949206916	TAIL PIPE	TATA spare parts
503949206922	TAIL PIPE	TATA spare parts
503949206927	EXHAUST TAIL PIPE	TATA spare parts
503949207501	RUBBER GROMMET	TATA spare parts
503949208209	CLAMP (SILENCER MTG.)	TATA spare parts
503949208210	PIPE SUPPORT BRACKET	TATA spare parts
503949208215	L CLAMP FOR EXHAUST PIPE MOUNTING	TATA spare parts
503949208216	L CLAMP FOR EXHAUST PIPE MOUNTING	TATA spare parts
503949208217	L CLAMP FOR EXHAUST PIPE MOUNTING	TATA spare parts
503949208218	L CLAMP FOR EXHAUST PIPE MOUNTING	TATA spare parts
503949208219	BRACKET EXHAUST PIPE MTG	TATA spare parts
503949208226	BRACKET-EXHAUST BRAKE MTG	TATA spare parts
503949208228	CLAMP (EXHAUST MTG)	TATA spare parts
503949990104	KIT HEAT SHIELD	TATA spare parts
503954100106	BATTERY+VE CABLE ASSY LPT3723	TATA spare parts

503954100107	BATTERY-VE CABLE ASSY LPT 3723	TATA spare parts
503954100111	BATTERY CARRIER ASSY	TATA spare parts
503954209905	INST.CLSTR(1:0.93)	TATA spare parts
503954303601	FILTER ASSY BS6-PH2	TATA spare parts
503954304903	FUEL LEVEL SENSOR BS6	TATA spare parts
503954306801	ENGINE SUCTION FITTING FUEL TANK BS6-PH2	TATA spare parts
503954306802	ENGINE RETURN FITTING FUEL TANK BS6-PH2	TATA spare parts
503954504901	SWITCH HILL ASSIST	TATA spare parts
503954600109	WIRING HARNESS WITH ABS CHASSIS	TATA spare parts
503954600110	WIRING HARNESS ABS FRAME	TATA spare parts
503954600111	WIRING HARNESS WITH ABS CHASSIS	TATA spare parts
503954600113	WIRING HARNESS MAIN BS3	TATA spare parts
503954600120	WIRING HARNESS TAIL	TATA spare parts
503954600144	CABLE ASSY BATTERY +VE	TATA spare parts
503954600146	BATTERY CABLE -VE	TATA spare parts
503954600154	WIRING HARNESS MAIN	TATA spare parts
503954600162	PIGTAIL ASSY EMS WIRING HARNESS BS6	TATA spare parts
503954600183	FUSE BOX COVER	TATA spare parts
503954600188	WIRING HARNESS ABS FRAME	TATA spare parts
503954600189	BATTERY CABLE +VE MAXI FUSE O/P TO SM	TATA spare parts
503954600190	BATTERY CABLE +VE	TATA spare parts
503954600194	BATTERY CABLE -VE	TATA spare parts
503954600196	WIRING HARNESS ENGINE BS4	TATA spare parts
503954600197	WIRING HARNESS TAIL	TATA spare parts
503954600198	WIRING HARNESS TAIL	TATA spare parts
503954600199	WIRING HARNESS ABS SPLIT	TATA spare parts
503954601621	W/H STOP LIGHT SWITCH BS6	TATA spare parts
503954601665	WIRING HARNESS MAIN BS4	TATA spare parts
503954601666	WIRING HARNESS ENGINE BS4	TATA spare parts
503954601667	WIRING HARNESS SCR UNIT	TATA spare parts
503954601668	WIRING HARNESS TAIL BS4	TATA spare parts
503954601669	WIRING HARNESS ENGINE BS4	TATA spare parts
503954601670	WIRING HARNESS SCR UNIT	TATA spare parts
503954601675	WIRING HARNESS SCR UNIT	TATA spare parts
503954601676	WIRING HARNESS ENGINE	TATA spare parts
503954601678	WIRING HARNESS TAIL	TATA spare parts
503954601679	PIGTAIL LIFT AXLE SWITCH	TATA spare parts
503954609003	WIRING HARNESS BS6	TATA spare parts
503954609903	WIRING HARNESS BS6	TATA spare parts
503954610101	WIRING HARNESS SCR UNIT	TATA spare parts
503954610102	PIGTAIL ASSY EMS WIRING HARNESS	TATA spare parts
503954610105	WIRING HARNESS MAIN BS6	TATA spare parts
503954610106	WIRING HARNESS ABS FRAME	TATA spare parts
503954610113	WIRING HARNESS ABS FRAME	TATA spare parts
503954610114	PIGTAIL ABS WIRING HARNESS	TATA spare parts
503954610115	WIRING HARNESS TAIL BS6	TATA spare parts
503954610117	WIRING HARNESS ABS FRAME BS6	TATA spare parts

503954610118	CABLE BATTERY +VE WITH MEGA FUSE	TATA spare parts
503954610120	PIGTAIL LIFT AXLE SWITCH	TATA spare parts
503954610121	WIRING HARNESS ABS FRAME	TATA spare parts
503954610127	BATTERY CABLE +VE	TATA spare parts
503954610132	BATTERY CABLE +VE BCS O/P TO SM	TATA spare parts
503954610134	PIGTAIL ASSY	TATA spare parts
503954610143	WIRING HARNESS FRONT	TATA spare parts
503954610145	WIRING HARNESS MAIN	TATA spare parts
503954610146	WIRING HARNESS MAIN	TATA spare parts
503954620105	W/HMAIN LPT 3721 LIFT AXLE ERGO	TATA spare parts
503954620132	WIRING HARNESS ABS FRAME	TATA spare parts
503954630101	WIRING HARNESS SCR UNIT BS6	TATA spare parts
503954630102	WIRING HARNESS TAIL BS6	TATA spare parts
503954660102	W/H TAIL LPT-3721 TC/62 BS-III 24V	TATA spare parts
503954660105	W/H MAIN LPT 3721/LIFT AXLE/ERGO	TATA spare parts
503954660111	WIRING HARNESS TAIL	TATA spare parts
503954660115	W/H MAIN LPT3723TC COWL 24V	TATA spare parts
503954660116	W/H TAIL	TATA spare parts
503954660121	W/H STOP LIGHT SWITCH LPT3723TC COWL	TATA spare parts
503954660126	WIRING HARNESS TAIL	TATA spare parts
503954700108	BRACKET ASSY VEHICLE TRACKING ASSY MTG	TATA spare parts
503954709901	VEHICLE ELECTRONIC CONTROLLER UNIT	TATA spare parts
503954900103	TILT SWITCH SYSTEM BS6	TATA spare parts
503954904901	TILT SWITCH BS6	TATA spare parts
503954909002	SOLENOID VALVE BS6	TATA spare parts
503958902601	SUPPORT STAND GEAR BOX	TATA spare parts
503958902602	GEAR BOX REPAIR CRADLE ASSY	TATA spare parts
50396168000R40	SIGNA 3718.TK CR 24 CUM BX 10R_CAB/COWL	TATA spare parts
50396868000R40	SIGNA 3718.TK CR 24 CUM BX 10R_CAB/COWL	TATA spare parts
50398368000RCK	CABIN KIT FOR 50398368000R	TATA spare parts
504000990101	KIT FULLY TRIMMED CABIN FOR PRIMA 4025.S	TATA spare parts
504000990103	KIT FULLY BUILD CABIN FOR PRIMA 4023.S	TATA spare parts
504000990104	EMERGENCY SWITCH & VTS FOR PRIMA 4025	TATA spare parts
504024103701	ENGINE MTG ARM FOR SAE 2 HSG - LH	TATA spare parts
504024103702	ENGINE MTG ARM FOR SAE 2 HSG - RH	TATA spare parts
504024200101	ASSY BRACKET-RH (ENG MTG-REAR BOTTOM)	TATA spare parts
504024200102	ASSY BRACKET-LH (ENG MTG-REAR BOTTOM)	TATA spare parts
504026808201	BKT-CABLE SUPPORT	TATA spare parts
504026810101	TURNING TUBE ASSY	TATA spare parts
504026810103	TURNING TUBE ASSY	TATA spare parts
504026810105	TURNING ROD ASSY	TATA spare parts
504026900102	ASSY OIL COOLER HOSE (INLET FROM OIL COO	TATA spare parts
504026900103	ASSY OIL COOLER HOSE (OUTLET FROM OIL CO	TATA spare parts
504026901601	ASSY OIL COOLER HOSE (INLET TO OIL COOLE	TATA spare parts
504026901602	ASSY OIL COOLER HOSE (OUTLET FROM OIL CO	TATA spare parts
504029000101	INTEGRATED PEDAL UNIT BS6	TATA spare parts
504029000102	INTEGRATED PEDAL UNIT BS6	TATA spare parts

504029000103	INTEGRATED PEDAL UNIT BS6	TATA spare parts
504031000101	ASSY. FRAME 4028.S(CAST 6 HOLE BKT)BS3/4	TATA spare parts
504031000104	FRAME ASSY PRIMA 4623.S (4X2)	TATA spare parts
504031000114	FRAME ASSY WITH FITMENT BS6	TATA spare parts
504031000115	FRAME ASSY WITH FITMENT BS6	TATA spare parts
504031107103	L-REINFORCEMENT-LH(BATTERY MTG REGION)	TATA spare parts
504031107110	L-REINFORCEMENT TOP-RH BS6	TATA spare parts
504031107111	L-REINFORCEMENT TOP-LH BS6	TATA spare parts
504031107112	L-REINFORCEMENT TOP-RH BS6	TATA spare parts
504031107113	L-REINFORCEMENT TOP-RH BS6	TATA spare parts
504031107118	L-REINFORCEMENT BOTTOM-RH BS6	TATA spare parts
504031107119	L-REINFORCEMENT BOTTOM-LH BS6	TATA spare parts
504031107124	L-REINFORCEMENT TOP-LH BS6	TATA spare parts
504031107125	L-REINFORCEMENT TOP-RH BS6	TATA spare parts
504031107130	L-REINFORCEMENT BOTTOM-RH BS6	TATA spare parts
504031107131	L-REINFORCEMENT BOTTOM-LH BS6	TATA spare parts
504031200101	ASSY FIRST CROSS MEMBER COMPLETE BS6	TATA spare parts
504031200110	CROSS MEMBER ASSY BS6	TATA spare parts
504031200111	CROSS MEMBER MTG ASSY	TATA spare parts
504031200113	END CROSS MEMBER ASSY	TATA spare parts
504031200114	CROSS MEMBER ASSY	TATA spare parts
504031200115	ALLIGATED CROSS MEMBER ASSY	TATA spare parts
504031207109	REINFORCEMENT BRACKET LH BS6	TATA spare parts
504031207110	REINFORCEMENT BRACKET RH BS6	TATA spare parts
504031300101	GUSSET ASSY WITH SPACER	TATA spare parts
504031300103	GUSSET ASSY WITH SPACER	TATA spare parts
504031307115	SUPPORT BRACKET ENGINE MTG FRONT-LH	TATA spare parts
504031307116	SUPPORT BRACKET ENGINE MTG FRONT-RH	TATA spare parts
504031307118	GUSSET BOTTOM-RH	TATA spare parts
504031307119	GUSSET BOTTOM-LH	TATA spare parts
504031307120	GUSSET TOP-RH	TATA spare parts
504031307121	GUSSET TOP-LH	TATA spare parts
504031700103	CROSS MEMBER FUPD	TATA spare parts
504031700104	FUPD BRACKET ASSY. COMPLETE RH	TATA spare parts
504031700105	FUPD BRACKET ASSY. COMPLETE LH	TATA spare parts
504031700106	ASSY - BATTERY & AIRTANK MTG	TATA spare parts
504031700111	FUPD BRACKET ASSY.COMPOSITE RH	TATA spare parts
504031700112	FUPD BRACKET ASSY.COMPOSITE LH	TATA spare parts
504031700114	BATTERY CARRIER & AIR TANK MTG ASSY	TATA spare parts
504031705101	TOW HOOK-M0 VEHICLES	TATA spare parts
504032100104	BRACKET ASSY FRONT SPRING MTG REAR-LH BS	TATA spare parts
504032100105	BRACKET ASSY FRONT SPRING MTG REAR-RH BS	TATA spare parts
504032100111	PARABOLIC LEAF SPRING ASSY BS6	TATA spare parts
504032100118	BRACKET ASSY FRONT SPRING MTG FRONT-LH B	TATA spare parts
504032100119	BRACKET ASSY FRONT SPRING MTG FRONT-RH B	TATA spare parts
504032100120	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
504032100126	MAIN LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts



504032103202	CENTER BOLT BS6-PH2	TATA spare parts
504032103301	BRACKET ASSY FRONT SPRING HANGER	TATA spare parts
504032103701	BRACKET FRONT SPRING MTG FRONT BS6	TATA spare parts
504032104201	U-BOLT BS6	TATA spare parts
504032104202	U-BOLT BS6	TATA spare parts
504032107108	2ND LEAF BS6-PH2	TATA spare parts
504032107110	3RD LEAF BS6-PH2	TATA spare parts
504032107112	2ND LEAF BS6-PH2	TATA spare parts
504032107115	3RD LEAF BS6-PH2	TATA spare parts
504032107701	RUBBER BUFFER	TATA spare parts
504032300101	BRACKET ASSY SHOCK ABSORBER MTG UPPER BS	TATA spare parts
504032303301	BRACKET SHOCK ABSORBER MTG LOWER-LH BS6	TATA spare parts
504032303303	BRACKET SHOCK ABSORBER MTG LOWER-RH BS6	TATA spare parts
504032400105	LEAF SPRING ASSY REAR	TATA spare parts
504032403201	CENTER BOLT	TATA spare parts
504032403301	SLIDE SUPPORT	TATA spare parts
504032403701	GUIDE PLATE	TATA spare parts
504032407104	CASTER PLATE	TATA spare parts
504033000101	ASSY.FA COMP.WITH BKS. LPS4021/LPT2521	TATA spare parts
504033000103	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
504033000106	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
504034100101	FIFTH WHEEL ASSY WITH STRUCTURE BS6	TATA spare parts
504034100108	FIFTH WHEEL COUPLING ASSY BS6-PH2	TATA spare parts
504034200101	STRUCTURE FIFTH WHEEL COUPLING ASSY MTG	TATA spare parts
504034200105	FIFTH WHEEL ASSY WITH STRUCTURE	TATA spare parts
504034200107	SUBSTRUCTURE ASSY FIFTH WHEEL COUPLING	TATA spare parts
504034200109	L-PLATE LH BS6	TATA spare parts
504034200110	L-PLATE RH BS6	TATA spare parts
504034200113	FIFTH WHEEL ASSY WITH STRUCTURE BS6	TATA spare parts
504034200117	STRUCTURE FIFTH WHEEL COUPLING ASSY MTG	TATA spare parts
504034200119	FIFTH WHEEL ASSY WITH STRUCTURE BS6	TATA spare parts
504034200201	PEDESTAL H 172 - DV1 BS6	TATA spare parts
504034207101	L-PLATE LH	TATA spare parts
504034207102	L-PLATE RH	TATA spare parts
504041100102	ASSY PROPELLER SHAFT	TATA spare parts
504041120101	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
504041120103	SHORT FORK TUBE & REAR HOUSING SUB ASSY	TATA spare parts
504041120106	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
504042100102	ASSY.FRONT BRAKE WITH D/C LH	TATA spare parts
504042100103	ASSY.FRONT BRAKE WITH D/C RH	TATA spare parts
504042100107	AUTO SLACK ADJUSTER-160CD ST.50 CRANK (	TATA spare parts
504042100108	SHIELD ASSY.TOP LH	TATA spare parts
504042100109	SHIELD ASSY.TOP RH	TATA spare parts
504042100115	BRAKE ASSY SHIELD BOTTOM LH	TATA spare parts
504042100116	BRAKE ASSY SHIELD BOTTOM RH	TATA spare parts
504042100124	LINED SHOE ASSY	TATA spare parts
504042100131	DRUM BRAKE ASSY FRONT -LH DIA410X180	TATA spare parts

504042100132	DRUM BRAKE ASSY FRONT -RH DIA410X180	TATA spare parts
504042100133	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
504042100134	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
504042100140	AUTO SLACK ADJUSTER ( WABCO )	TATA spare parts
504042100166	AUTO SLACK ADJUSTER ASSY BS6	TATA spare parts
504042103401	BUSH CAM-END BS4	TATA spare parts
504042103701	BRAKE DRUM FRONT	TATA spare parts
504042103702	DRUM BRAKE -TORQUE PLATE MACHINING LH	TATA spare parts
504042103703	DRUM BRAKE -TORQUE PLATE MACHINING RH	TATA spare parts
504042109901	BRAKE ASSY KIT-TORQUE PLATE-LH	TATA spare parts
504042109902	BRAKE ASSY KIT-TORQUE PLATE-RH	TATA spare parts
504042109903	KIT-BRACKET ASSY-LH	TATA spare parts
504042109904	KIT-BRACKET ASSY-RH	TATA spare parts
504042109905	KIT-BUSH	TATA spare parts
504042300110	DRUM BRAKE ASSY REAR LH WITH D/C	TATA spare parts
504042300111	DRUM BRAKE ASSY REAR RH WITH D/C	TATA spare parts
504042300112	SHIELD ASSY. TOP	TATA spare parts
504042300113	SHIELD ASSY. BOTTOM	TATA spare parts
504042300114	LINED SHOE ASSY	TATA spare parts
504042300127	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
504042300128	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
504042300153	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
504042300154	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
504042303702	TORQUE PLATE MACHINING	TATA spare parts
504042303703	BRACKET BRAKE CHAMBER MTG REAR-LH	TATA spare parts
504042303704	BRACKET BRAKE CHAMBER MTG REAR-RH	TATA spare parts
504042303705	BRACKET BRAKE CHAMBER MTG REAR-LH	TATA spare parts
504042303706	BRACKET BRAKE CHAMBER MTG REAR-RH	TATA spare parts
504042305102	CAM SHAFT LH BS6	TATA spare parts
504042305103	CAM SHAFT RH BS6	TATA spare parts
504042307701	GROMMET	TATA spare parts
504042307901	S CAM-SHAFT LH	TATA spare parts
504042307902	S CAM-SHAFT RH	TATA spare parts
504042308601	SPACER	TATA spare parts
504042308602	SPACER BS6	TATA spare parts
504042309901	KIT-BRK LINING STD BS3	TATA spare parts
504042309902	KIT LINING SET(FIRST OVER SIZE)	TATA spare parts
504042309903	KIT LINING SET(SECOND OVER SIZE)	TATA spare parts
504042309904	SPARE KIT FOR TORQUE PLATE	TATA spare parts
504042309905	SPARE KIT-BUSH	TATA spare parts
504042309906	KIT-SPRING	TATA spare parts
504042309909	KIT-ROLLER	TATA spare parts
504042309911	KIT DUST SHIELD	TATA spare parts
504042309916	DRUM BRAKE ASSY REAR LINED LHOE AF5429	TATA spare parts
504042309925	DRUM BRAKE KIT S CAM SHAFT LH	TATA spare parts
504042309926	DRUM BRAKE KIT S CAM SHAFT RH	TATA spare parts
504042990101	ASSY. BRAKE-KIT TORQUE PLATE LH BS3/4	TATA spare parts

504042990102	BRAKE ASSY -KIT TORQUE PLATE RH	TATA spare parts
504042990103	KIT BRACKET ASSY. LH	TATA spare parts
504042990104	KIT BRACKET ASSY. LH/RH	TATA spare parts
504042990105	KIT -DUST SHIELD BS6	TATA spare parts
504042990107	KIT -CAMSHAFT LH	TATA spare parts
504042990108	KIT -CAMSHAFT RH	TATA spare parts
504042990109	BRAKE ASSY -TUBE FLANGE BRACKET ASSY LH	TATA spare parts
504042990110	BRAKE ASSY -TUBE FLANGE BRACKET ASSY RH	TATA spare parts
504042990128	ASSY. LINED SHOE NA1707 BS3/4	TATA spare parts
504042990134	DRUM BRAKE -LINING KIT STANDARD SIZE	TATA spare parts
504042990135	DRUM BRAKE -LINING KIT 1ST OVER SIZE	TATA spare parts
504042990136	DRUM BRAKE -LINING KIT 2ND OVER SIZE	TATA spare parts
504042993401	BUSH -CAM END	TATA spare parts
504042995101	BRAKE ASSY -CAM SHAFT LH	TATA spare parts
504042995102	BRAKE ASSY -CAM SHAFT RH	TATA spare parts
504042998201	SHIELD ASSY - BOTTOM	TATA spare parts
504042998202	SHIELD ASSY - TOP	TATA spare parts
504043200106	ASSY AIR TANK (20LTR+15LTR)	TATA spare parts
504043200107	ASSY SUPPORT-AIR TANK MOUNTING	TATA spare parts
504043200109	ASSY STRAP PIN AND BOLT COMPLETE	TATA spare parts
504043200111	AIR TANK ASSY WITH BKT SPLIT TANK 30L (	TATA spare parts
504043700110	ASSY MTG BKT-MODULATOR VALVE	TATA spare parts
504043700111	HAND BRAKE VALVE WITH SWITCH WITH OUT TR	TATA spare parts
504043700112	AUTOMATIC LOAD SENSING VALVE	TATA spare parts
504043700114	ASSY BRACKET (FOR LSV LEVER MTG-ON AXLE)	TATA spare parts
504043700115	HAND BRAKE VALVE WITH SWITCH	TATA spare parts
504043700116	BRACKET ASSY MV MTG LH	TATA spare parts
504043700117	FOOT BRAKE VALVE	TATA spare parts
504043700121	BRACKET ASSY APU MTG	TATA spare parts
504043700199	BRACKET ASSY-MODULATOR VALVE MTG-FRONT	TATA spare parts
504043900102	ASSY METAL PIPE SECOND	TATA spare parts
504043900103	ASSY METAL PIPE THIRD	TATA spare parts
504043900104	ASSY NYLON PIPE BUNCH 9 BAR SYSTEM	TATA spare parts
504043900108	ASSY NYLON PIPE AIR TANK REAR TO DTV-11	TATA spare parts
504043900113	ASSY NYLON PIPE NRV TO HBV-1	TATA spare parts
504043900144	ASSY METAL PIPE THIRD	TATA spare parts
504043900152	ASSY NYLON PIPE BUNCH	TATA spare parts
504043900153	ADAPTER	TATA spare parts
504043900174	PIPE BUNCH ASSY	TATA spare parts
504043910111	PIPE BUNCH ASSY	TATA spare parts
504043910113	METAL PIPE ASSY	TATA spare parts
504043910114	METAL PIPE ASSY	TATA spare parts
504043910115	METAL PIPE ASSY	TATA spare parts
504043910125	PIPE BUNCH ASSY	TATA spare parts
504043910141	METAL PIPE ASSY	TATA spare parts
504043910142	METAL PIPE ASSY	TATA spare parts
504043910185	PIPE BUNCH ASSY BS6	TATA spare parts

504043930158	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
504043930181	PIPE BUNCH ASSY BS6	TATA spare parts
504043990101	KIT-HAND BRAKE VALVE	TATA spare parts
504046100101	STEERING COLUMN ASSY TILT & TELESCOPIC B	TATA spare parts
504046103801	INTERMEDIATE BRACKET BS6-PH2	TATA spare parts
504046103802	BRACKET STG COLUMN MTG BS6-PH2	TATA spare parts
504046300102	DRAG LINK ASSEMBLY	TATA spare parts
504046304101	PITMAN ARM	TATA spare parts
504046304102	PITMAN ARM FOR MO TIPPER	TATA spare parts
504046600102	HOUSING ASSY BS6	TATA spare parts
504046700101	SPACER - STG GEAR BOX MTG BRKT	TATA spare parts
504046800101	SUCTION LINE ASSY TYPE-I	TATA spare parts
504046800102	PRESSURE LINE ASSY GB END TYPE-I	TATA spare parts
504046800103	PRESSURE LINE ASSY.PUMP END TYPE-I	TATA spare parts
504046800104	RETURN LINE ASSY GB END TYPE-I	TATA spare parts
504046800106	RETURN LINE ASSY G.B.END TYPE I BS6	TATA spare parts
504046800107	PRESSURE LINE ASSY G.B.END TYPE I BS6	TATA spare parts
504046800108	AUXILIARY PIPE ASSY RESERVOIR BS6	TATA spare parts
504046800109	SUCTION LINE ASSY TYPE-I	TATA spare parts
504046800114	RETURN LINE ASSY BS6	TATA spare parts
504046990104	CABIN AND ELECT KIT PART LIST FOR M0	TATA spare parts
504047100107	ASSY. FUEL TANK WELDED (400 LTR RECT)	TATA spare parts
504047508201	SUPPORT BRACKET FUEL TANK BS6	TATA spare parts
504047600116	FUEL SUCTION PIPE ASSY	TATA spare parts
504047600117	FUEL PIPE ASSY	TATA spare parts
504047600119	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
504047600120	FUEL SUCTION PIPE ASSY TANK TO P/FILTER	TATA spare parts
504047600121	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
504047600123	FUEL SUCTION PIPE ASSY FTR TO ENGINE BS6	TATA spare parts
504047600125	FUEL SUCTION PIPE ASSY FUEL TANK TO FTR	TATA spare parts
504047600126	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
504047700101	BRACKET ASSY FUEL FILTER MTG	TATA spare parts
504047700102	ASSY. FILTER HEAD & FUEL WATER SEP. BS3	TATA spare parts
504047700104	HEAD & FUEL WATER SEPARATOR	TATA spare parts
504047700105	FUEL FILTER HEAD ASSY	TATA spare parts
504047703601	FUEL WATER SEP. SPINON W/SENSOR BS3	TATA spare parts
504047703602	FUEL FILTER	TATA spare parts
504047703603	FUEL WATER SEPARATOR SPINON BS3	TATA spare parts
504047709901	ADAPTOR FOR FUEL FILTER	TATA spare parts
504049200103	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
504049200107	BRACKET ASSY DECOMP PIPE MTG	TATA spare parts
504049200108	RETURN LINE,DM TO TANK BS6	TATA spare parts
504049200114	BRACKET ASSY-EGP MTG-REAR BS6	TATA spare parts
504049200115	PRESSURE LINE,SM TO DM BS6	TATA spare parts
504049203301	BRACKET FRONT( ON LONG MEMBER)	TATA spare parts
504049203303	BRACKET FOR PIPE SUPPORT( ON LONG MEMBER)	TATA spare parts
504049203305	BRACKET EXHAUST PIPE SUPPORT	TATA spare parts

504049203306	L-BRACKET EXHAUST MTG	TATA spare parts
504049203308	BRACKET DECOMP PIPE MTG BS6	TATA spare parts
504049203310	BRACKET EGP MTG	TATA spare parts
504049203325	BRACKET TAIL PIPE MTG BS6	TATA spare parts
504049205304	GASKET EXHAUST SYSTEM BS6	TATA spare parts
504052200101	BRACKET ASSY FENDER MTG FRONT-LH	TATA spare parts
504052200102	BRACKET ASSY WHEEL ARCH MTG FRONT-RH	TATA spare parts
504052200103	BRACKET ASSY REAR FENDER MTG REAR-LH	TATA spare parts
504052200104	BRACKET ASSY WHEEL ARCH MTG REAR-RH	TATA spare parts
504052203301	BRACKET TAIL LAMP MTG	TATA spare parts
504052206304	MUDFLAP REAR	TATA spare parts
504054200103	GEAR SHIFT INDICATOR	TATA spare parts
50405434000RCK	ASSY CABIN KIT W/FITMENT PRIMA LX 4625 B	TATA spare parts
504054400104	BRACKET ASSY LICENSE PLATE MTG	TATA spare parts
504054400106	FRONT FOG LAMP ASSY	TATA spare parts
504054400107	TAIL LAMP LED ASSY LH BS6	TATA spare parts
504054400108	TAIL LAMP LED ASSY RH BS6	TATA spare parts
504054400109	HEADLAMP ASSY LH BS6-PH2	TATA spare parts
504054400110	HEADLAMP ASSY RH BS6-PH2	TATA spare parts
504054400111	REFLEX REFLECTOR FRONT-LH BS6-PH2	TATA spare parts
504054400112	REFLEX REFLECTOR FRONT-RH BS6-PH2	TATA spare parts
504054400113	SIDE REPEATER LAMP ASSY LH BS6-PH2	TATA spare parts
504054400114	SIDE REPEATER LAMP ASSY RH BS6-PH2	TATA spare parts
504054400115	DOOR AJAR LAMP ASSY BS6-PH2	TATA spare parts
504054400116	ROOF LAMP ASSY BS6	TATA spare parts
504054403307	BRACKET SIDE MARKER LAMP MTG LH	TATA spare parts
504054403309	BRACKET SIDE MARKER LAMP MTG RH	TATA spare parts
504054500101	STEERING WHEEL SWITCH ASSY BS6	TATA spare parts
504054504904	SWITCH LIFT AXLE FRONT BS6	TATA spare parts
504054504906	SWITCH LIFT AXLE DISABLE BS6	TATA spare parts
504054504908	SWITCH ENGINE BRAKE BS6	TATA spare parts
504054504909	SWITCH HEAVY MODE BS6	TATA spare parts
504054504910	SWITCH LIGHT MODE BS6	TATA spare parts
504054504912	SWITCH ABS DIAGNOSTICS BS6	TATA spare parts
504054504915	HAZARD WARNING SWITCH BS6	TATA spare parts
504054504917	SWITCH ENGINE LAMP BS6	TATA spare parts
504054504920	STEERING WHEEL SWITCH LH BS6	TATA spare parts
504054504921	STEERING WHEEL SWITCH RH BS6	TATA spare parts
504054504926	SWITCH HILL ASSIST BS6	TATA spare parts
504054504929	SWITCH CABIN ROOF LAMP BS6-PH2	TATA spare parts
504054504932	SWITCH WORK AREA LAMP BS6	TATA spare parts
504054504933	SWITCH MEDIUM MODE BS6	TATA spare parts
504054504938	SWITCH HEADLAMP LEVELLING BS6	TATA spare parts
504054504939	COMBINATION SWITCH RH BS6	TATA spare parts
504054504940	SWITCH REGENERATION START MANUAL BS6	TATA spare parts
504054504941	SWITCH REGENERATION INHIBIT BS6	TATA spare parts
504054504962	SWITCH ASSY COMBINATION BS6-PH2	TATA spare parts

504054504963	CAN BASED SWITCH ASSY DASHBOARD BS6	TATA spare parts
504054504964	CAN BASED SWITCH ASSY DASHBOARD BS6-PH2	TATA spare parts
504054504965	CAN BASED SWITCH ASSY DASHBOARD BS6	TATA spare parts
504054504966	CAN BASED SWITCH ASSY DASHBOARD BS6-PH2	TATA spare parts
504054509901	STEERING WHEEL WIRING HARNESS BS6	TATA spare parts
504054509903	LIGHT & TURN MODULE COMBI SWITCH BS6	TATA spare parts
504054509904	WIPER STALK LEVER BS6	TATA spare parts
504054509905	BODY COMBINATION SWITCH BS6	TATA spare parts
504054600109	WIRING HARNESS GEAR BOX BS6	TATA spare parts
504054600111	WIRING HARNESS BATTERY CABLE -VE BS6	TATA spare parts
504054600124	WIRING HARNESS DASHBOARD BS6	TATA spare parts
504054600125	WIRING HARNESS TAIL BS6	TATA spare parts
504054600126	WIRING HARNESS FRAME BS6	TATA spare parts
504054600128	WIRING HARNESS DOSING UNIT BS6	TATA spare parts
504054600129	POWER CABLE ALTERNATOR TO STARTER MOTOR	TATA spare parts
504054600130	WIRING HARNESS GEAR BOX BS6-PH2	TATA spare parts
504054600135	BATTERY CABLE +VE MEGA FUSE O/P TO SM BS	TATA spare parts
504054600140	WIRING HARNESS ABS FRAME BS6	TATA spare parts
504054607501	GROMMET BS6-PH2	TATA spare parts
504054709905	VEHICLE ELECTRONIC CONTROLLER UNIT BS6	TATA spare parts
504054800104	INFOTAINMENT SYSTEM BS6	TATA spare parts
504054800107	BRACKET ASSY SPEAKER MTG LH	TATA spare parts
504054800108	BRACKET ASSY SPEAKER MTG RH	TATA spare parts
504054808201	BRACKET BS6	TATA spare parts
504058903501	PINION DEPTH MEASUREMENT GAUGE/RA/110	TATA spare parts
504124203701	BRACKET ENG MTG REAR-LH BS6	TATA spare parts
504124203702	BRACKET ENG MTG REAR-RH BS6	TATA spare parts
504126800103	ASSY GEARSHIFT UNIT CABLES	TATA spare parts
504126800104	GEAR SHIFT CABLE BS3/4	TATA spare parts
504126800105	GEAR SELECT CABLE BS3/4	TATA spare parts
504126800106	ASSY.PNEUMATIC PIPELINE	TATA spare parts
504126800129	PIPE ASSY WITH SOLENOID PNEUMATIC	TATA spare parts
504126800133	TURNING TUBE ASSY BS6	TATA spare parts
504129300101	CLUTCH BOOSTER ASSY BS6	TATA spare parts
504131000101	ASSY.FRAME-LPS 4923(6X4)	TATA spare parts
504131000102	FRAME ASSY	TATA spare parts
504131000108	FRAME ASSY WITH FITMENT	TATA spare parts
504131000118	FRAME ASSY WITH FITMENT BS6	TATA spare parts
504131000119	FRAME ASSY WITH FITMENT BS6	TATA spare parts
504131000123	FRAME ASSY WITH FITMENT BS6	TATA spare parts
504131107103	C-REINFORCEMENT-LH(BATTERY MTG REGION)	TATA spare parts
504131107111	L-REINFORCEMENT BS6	TATA spare parts
504131107112	L-REINFORCEMENT BS6	TATA spare parts
504131107123	L-REINFORCEMENT BS6	TATA spare parts
504131107124	L-REINFORCEMENT BS6	TATA spare parts
504131107131	C-REINFORCEMENT LH BS6	TATA spare parts
504131107132	C-REINFORCEMENT RH BS6	TATA spare parts

504131107154	ANGLE PLATE LH BS6-PH2	TATA spare parts
504131107155	ANGLE PLATE RH BS6-PH2	TATA spare parts
504131200102	CROSS MEMBER ASSY REAR SPRING FRONT BS6	TATA spare parts
50413120010260	CROSS MEMBER ASSY REAR SPRING FRONT BS6	TATA spare parts
504131200109	CROSS MEMBER ASSY WITH GUSSET BS6	TATA spare parts
504131700103	BATTERY TRAY ASSY BS6	TATA spare parts
504131707701	SHIELD UNDER TRANSMISSION	TATA spare parts
504132107101	CASTER PLATE BS6	TATA spare parts
504132300101	BRACKET ASSY FRONT SHOCK ABSORBER TOP-LH	TATA spare parts
504132300102	BRACKET ASSY FRONT SHOCK ABSORBER TOP-RH	TATA spare parts
504132303303	BRACKET SHOCK ABSORBER MTG LOWER-LH BS6	TATA spare parts
504132303304	BRACKET SHOCK ABSORBER MTG LOWER-RH BS6	TATA spare parts
504132400105	ASSY ADAPTOR PLATE (SRT AXLE)	TATA spare parts
504132400112	SPRING ASSY REAR BS6	TATA spare parts
504132403201	CENTER BOLT BS6	TATA spare parts
504132407101	CASTER PLATE BS6	TATA spare parts
504140300106	SPARE WHEEL CARRIER ASSY BS6	TATA spare parts
504140300114	HOLDING BRACKET ASSY BS6	TATA spare parts
504140300115	SPARE WHEEL CARRIER ASSY BS6 PH2	TATA spare parts
504141100101	ASSY PROPELLER SHAFT MAIN	TATA spare parts
504141107101	GUARD-P/SHAFT FRONT	TATA spare parts
504141120107	SEALED UNIVERSAL JOINT ASSY.	TATA spare parts
504142300101	ASSEMBLY REAR BRAKE LH/RH WITH D/C	TATA spare parts
504142300102	ASSEMBLY REAR BRAKE RH/LH WITH D/C	TATA spare parts
504142300103	ASSY ASA LH/RH 60 OFFSET 55 CRANK	TATA spare parts
504142300104	ASSY.ASA RH/LH 60 OFFSET 55 CRANK	TATA spare parts
504142300121	BRAKE ASSY REAR AXLE LH W/T D/C.	TATA spare parts
504142300122	BRAKE ASSY REAR AXLE RH W/T D/C.	TATA spare parts
504142307901	S CAM-SHAFT LH	TATA spare parts
504142307902	S CAM-SHAFT RH	TATA spare parts
504142309901	KIT-REAR S CAM SHAFT LH.	TATA spare parts
504142309902	KIT-REAR S CAM SHAFT RH	TATA spare parts
504143200103	ASSY. LCRV MTG. BKT ON AXLE	TATA spare parts
504143200104	ASSEMBLY LCRV MOUNTING BRACKET ON AXLE	TATA spare parts
504143200105	ASSY. BRKT ON AXLE REAR REAR.	TATA spare parts
504143200106	BRACKET ASSY LCRV LINK MTG ON AXLE	TATA spare parts
504143208209	LCRV LINK ROD MOUNTING BRACKET	TATA spare parts
504143400102	LCRV LINK ROD	TATA spare parts
504143700124	BRACKET ASSY FOR AIR PROCESSING UNIT BS6	TATA spare parts
504143700138	CHANNEL ASSY BS6	TATA spare parts
504143700140	GRADUATED HAND CONTROL VALVE	TATA spare parts
504143703301	LCRV MTG. BKT	TATA spare parts
504143703302	BRACKET	TATA spare parts
504143900105	PIPE BUNCH ASSY	TATA spare parts
504143900128	ASSY NYLON PIPE HBV-21 TO ADAP NG12	TATA spare parts
504143900129	ASSY NYLON PIPE ADAP NG12 NW9 TO TEE-5	TATA spare parts
504143900130	ASSY NYLON PIPE TEE-2 TO MOD VALVE(F-LH)	TATA spare parts

504143900131	ASSY NYLON PIPE TEE-2 TO MOD VALVE(F-RH)	TATA spare parts
504143900133	ASSY NYLON PIPE DBV-21 TO TEE-3	TATA spare parts
504143900134	ASSY NYLON PIPE DBV ADDI P-22 TO TCV-42	TATA spare parts
504143900137	ASSY NYLON PIPE BUNCH FOR 4923.S WITH AP	TATA spare parts
504143900140	ASSY METAL PIPE	TATA spare parts
504143900142	ASSY METAL PIPE TURBOCHECK VALVE TO APU	TATA spare parts
504143900171	PIPE BUNCH ASSY NYLON FOR APU	TATA spare parts
504143900194	METAL PIPE ASSY	TATA spare parts
504143900195	PIPE BUNCH ASSY	TATA spare parts
504143910187	PIPE BUNCH ASSY BS6	TATA spare parts
504146600101	POWER STEERING PUMP ASSY	TATA spare parts
504146800105	MALE ADAPTOR M16X1.5XM22X1.5	TATA spare parts
504146800106	PRESSURE LINE ASSY G.B.END TYPE	TATA spare parts
504146800107	RETURN LINE ASSY G.B.END TYPE	TATA spare parts
504146800109	CONNECTOR ASSY	TATA spare parts
504146803301	BRACKET STG PIPE MTG	TATA spare parts
504146808202	COUPLING BODY BS6	TATA spare parts
504146900101	DRAG LINK ASSY BS6	TATA spare parts
504146900103	DRAG LINK ASSY (TALBROS) BS6	TATA spare parts
504147100102	ASSY. FUEL TANK WELDED 400L.(GALV) BS3/4	TATA spare parts
504147100105	ASSY. FUEL TANK CAP-REUTTER	TATA spare parts
504147108205	SEAT ADAPTER FOR INT TANK UNIT FOR M0	TATA spare parts
504147500101	BRACKET ASSY FUEL TANK MTG REAR	TATA spare parts
504147500102	BRACKET ASSY FUEL TANK MTG FRONT	TATA spare parts
504147500106	SPACER BRKT ASSY FUEL TANK MTG BS6-PH2	TATA spare parts
504147600101	ASSY FUEL LINE FT TO WS	TATA spare parts
504147600102	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
504147600103	ASSY RETURN LINE ENGINE TO FT	TATA spare parts
504147600106	SUCTION TUBE FUEL TANK TO W/SEP	TATA spare parts
504147600107	FUEL SUCTION PIPE ASSY TANK TO P/FILTER	TATA spare parts
504147600108	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
504147600109	FUEL PIPE ASSY FUEL TANK INTERCONNECTION	TATA spare parts
504147600110	PIPE ASSY FUEL TANK-1 TO 2 BS6-PH2	TATA spare parts
504147600111	RETURN PIPE ASSY ENGINE TO CONN BS6	TATA spare parts
504147704901	INTEGRATED FUEL SENDER UNIT	TATA spare parts
504149100101	BRACKET ASSY UREA TANK MTG	TATA spare parts
504149108201	BRACKET	TATA spare parts
504149108205	TAIL PIPE SUPPORT BKT	TATA spare parts
504149108206	MUFFLER HOLDING BKT	TATA spare parts
504149200101	PIPE ASSEMBLY	TATA spare parts
504149200102	ASSY EXHAUST TAIL PIPE	TATA spare parts
504149200104	MUFFLER ASSY	TATA spare parts
504149200109	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
504149200119	SUCTION LINE,TANK TO SM BS6	TATA spare parts
504149203301	BRACKET	TATA spare parts
504149203303	BRACKET TAIL PIPE ASSY MTG BS6	TATA spare parts
504149203701	EXHAUST ELBOW	TATA spare parts



504149205301	GASKET BS6	TATA spare parts
504149206902	EXHAUST TAIL PIPE	TATA spare parts
504149206903	THIRD PIPE FROM SECOND PIPE TO MUFFLER	TATA spare parts
504149206904	EXHAUST TAIL PIPE	TATA spare parts
504149208201	BRACKET	TATA spare parts
504154200101	TELLTALE INDICATIONS	TATA spare parts
504154400101	BRACKET ASSY LH BS6	TATA spare parts
504154400102	BRACKET ASSY RH BS6	TATA spare parts
504154500101	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
504154504901	IGNITION SWITCH ASSY WITH ILLU RING BS6	TATA spare parts
504154600101	BATTERY CABLE +VE BCS TO MEGA FUSE BS6	TATA spare parts
504154600102	BATTERY CABLE +VE MEGA FUSE O/P TO SM BS	TATA spare parts
504154600104	BRACKET MEGA FUSE MTG	TATA spare parts
504154600107	WIRING HARNESS ABS FRAME BS6	TATA spare parts
504154708201	BRACKET ASSY FLASHER MTG	TATA spare parts
504200990102	KIT FULLY TRIMMED CABIN FOR PRIMA 2525.K	TATA spare parts
504200990103	KIT FULLY TRIMMED CABIN FOR PRIMA 2525.K	TATA spare parts
504200990104	KIT FULLY TRIMMED CABIN FOR PRIMA 2525.K	TATA spare parts
504224200104	RUBBER MOUNT REAR BS6	TATA spare parts
504224200113	ENGINE MTG ASSY REAR-RH	TATA spare parts
504224200114	ENGINE MTG REAR-LH	TATA spare parts
504224200115	ENGINE MTG ASSY REAR LH	TATA spare parts
504224200116	ENGINE MOUNT ASSY RH	TATA spare parts
504226800109	ASSY BRACKET (G.S.LEVER MTG.)	TATA spare parts
504226800111	ASSY RETAINER PLATE(ON CAB)	TATA spare parts
504226800113	ASSY. SELECTOR SHIFTER FORK	TATA spare parts
504226800114	KNOB 6-SPEED	TATA spare parts
504226800115	ASSY. SUPPORT PLATE	TATA spare parts
504226800121	GEAR SHIFT CABLE ASSY	TATA spare parts
504226800122	GEAR SELECT CABLE ASSY	TATA spare parts
504226800123	CABLE SHIFT SYSTEM ASSY	TATA spare parts
504226800132	SEALING PLATE BS6-PH2	TATA spare parts
504226800133	RETAINER PLATE ASSY BS6-PH2	TATA spare parts
504226800143	BALL JOINT ASSY BS6-PH2	TATA spare parts
504226800228	GSL ASSY WITH SHIFT LEVER YOKE	TATA spare parts
504226806301	BASE PLATE	TATA spare parts
504226806302	RETAINER PLATE (MIDDLE)	TATA spare parts
504226806304	SEALING PLATE	TATA spare parts
504226807101	BASE PLATE (SUPPORT TUBE)	TATA spare parts
504226807701	BASE BELLOW	TATA spare parts
504226807702	RUBBER BELLOW (UPPER)	TATA spare parts
504226807703	RUBBER BELLOW BS6-PH2	TATA spare parts
504226807704	BASE BELLOW BS6	TATA spare parts
504226810101	ASSY TURNING TUBE WITH OUT BALL JOINT	TATA spare parts
504226810102	ASSY SUPPORT TUBE	TATA spare parts
504226810109	TURNING TUBE ASSY BS6-PH2	TATA spare parts
504226810111	CLAMPING PLATE ASSY BS6-PH2	TATA spare parts

504226810112	CLAMPING PLATE ASSY BS6-PH2	TATA spare parts
504226810113	SUPPORT TUBE ASSY BS6	TATA spare parts
504226813401	BUSH BS6	TATA spare parts
504226813402	BUSH BS6	TATA spare parts
504226813404	WASHER BS6	TATA spare parts
504226813405	INSERT BS6	TATA spare parts
504226817105	SUPPORT PLATE BS6-PH2	TATA spare parts
504226817501	RUBBER BUSH BS6	TATA spare parts
504226817502	RUBBER BUSH BS6	TATA spare parts
504226817504	BUSH BS6	TATA spare parts
504229100102	ASSY BRACKET CLUTCH BOOSTER MTG	TATA spare parts
504229300101	ASSY. CLUTCH BOOSTER (TYPE-1)	TATA spare parts
504231000101	ASSY. FRAME PRIMA 2523 BS3	TATA spare parts
504231000102	FRAME ASSY	TATA spare parts
504231000103	FRAME ASSY	TATA spare parts
504231000104	FRAME ASSEMBLY	TATA spare parts
504231000119	FRAME ASSY WITH SUSPENSION BRACKET BS6	TATA spare parts
504231000120	FRAME ASSY WITH SUSPENSION BRACKET BS6	TATA spare parts
504231107103	LONG MEMBER LH	TATA spare parts
504231107104	LONG MEMBER RH	TATA spare parts
504231107105	REINFORCEMENT LH	TATA spare parts
504231107106	REINFORCEMENT RH	TATA spare parts
504231107107	REINFORCEMENT - RR AXLE CTR CM	TATA spare parts
504231107108	REINF-FRNT SUSP RR-INNER LH	TATA spare parts
504231107109	FRONT REINF (UPPER FLANGE)	TATA spare parts
504231107110	L REINF	TATA spare parts
504231107111	L REINF FRNT SUSP FRNT-INNER	TATA spare parts
504231107112	REINF-FRNT SUSP RR-INNER RH	TATA spare parts
504231107115	L-REINFORCEMENT	TATA spare parts
504231107145	SUPPORT BRACKET ENGINE MTG FRONT-LH BS6	TATA spare parts
504231107146	SUPPORT BRACKET ENGINE MTG FRONT-RH BS6	TATA spare parts
504231200105	ASSEMBLY END CROSS MEMBER	TATA spare parts
504231200107	CROSS MEMBER ASSY	TATA spare parts
504231200108	CROSS MEMBER ASSY	TATA spare parts
504231200109	CROSS MEMBER ASSY 4TH	TATA spare parts
504231200110	CROSS MEMBER ASSY 5TH	TATA spare parts
504231207101	CROSS MEMBER END	TATA spare parts
504231307101	GUSSET - UPPER CTR CROSS MBR	TATA spare parts
504231307102	GUSSET - LOWER CTR CROSS MEMBER	TATA spare parts
504231540102	BRACKET ASSY BATTERY TRAY MTG BS6	TATA spare parts
504231540103	BATTERY CARRIER & AIR TANK MTG ASSY BS6	TATA spare parts
504231700109	ASSY-BATTERY & AIRTANK MTG	TATA spare parts
504231700110	ASSEMBLY - SUMP GUARD	TATA spare parts
504231700111	ASSEMBLY-SUMP GUARD MTG BRKT	TATA spare parts
504231700114	ASSEMBLY SUMP GUARD FRONT	TATA spare parts
504231700116	ASSY HEAT SHIELD COMPLETE	TATA spare parts
504231700117	ASSEMBLY SUMP GUARD COMPLETE	TATA spare parts

504231700125	ASSY RUPD	TATA spare parts
504231700142	HEAT SHIELD ASSY	TATA spare parts
504231700145	BRACKET ASSY FUPD MTG RH	TATA spare parts
504231700146	RACKET ASSY FUPD MTG LH	TATA spare parts
504231700148	BRACKET ASSY GEAR BOX MTG RH BS6	TATA spare parts
504231700149	BRACKET ASSY GEAR BOX MTG LH BS6	TATA spare parts
504231700152	BRACKET ASSY FUPD MTG RH	TATA spare parts
504231700153	BRACKET ASSY FUPD MTG LH	TATA spare parts
504231703201	HEX BOLT	TATA spare parts
504231707101	SPACER-FRNT SUSP FRNT REINF	TATA spare parts
504231707111	BATTERY MTG BRKT	TATA spare parts
504231707117	TOP PLATE FOR SUMP GAURD SUPPORT BKT LH	TATA spare parts
504231707118	TOP PLATE FOR SUMP GAURD SUPPORT BKT RH	TATA spare parts
504231707121	BRKT FOR SUMP GUARD	TATA spare parts
504232100104	BUMP STOPPER ASSY FRONT	TATA spare parts
504232104201	U-BOLT M22X1.5X260	TATA spare parts
504232104202	U-BOLT M22X1.5X245	TATA spare parts
504232108601	SPACER	TATA spare parts
504232403201	HEX FLANGE BOLT M20X2.5X180 10.9	TATA spare parts
504232403301	SPACER PLATE REAR RFD	TATA spare parts
504232403302	SPACER PLATE REAR RMD	TATA spare parts
504232403303	SPACER PLATE REAR RWD	TATA spare parts
504232403724	TORQUE ROD MTG BKT-LH TML SUSPENSION	TATA spare parts
504232403725	TORQUE ROD MTG BKT-RH TML SUSPENSION	TATA spare parts
504232403726	TORQUE ROD MTG BKT-LH TML SUSPENSION	TATA spare parts
504232403727	TORQUE ROD MTG BKT-RH TML SUSPENSION	TATA spare parts
504232403730	RUBBER BOLSTER MTG BKT-LH TML SUSPENSION	TATA spare parts
504232403731	RUBBER BOLSTER MTG BKT-RH TML SUSPENSION	TATA spare parts
504232408601	SPACER PLATE-ARTICULATION STOPPER-LPK252	TATA spare parts
504233000103	ASSY FRONT AXLE COMP WITH BRKS W/O ABS.	TATA spare parts
504233000104	FA FWD 3123.T PRIMA 910SCD/105MMDRP/NON	TATA spare parts
504233000107	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
504233000108	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
504233000109	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
504233000111	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
504233800101	ASSY.TIE ROD COMPLETE	TATA spare parts
504240109901	TYRE RIB TYPE	TATA spare parts
504240300101	BRACKET ASSY WITH WELDED NUT	TATA spare parts
504240300102	BRACKET ASSY WITH WELDED NUT	TATA spare parts
504241100104	ASSY PROPELLER SHAFT MAIN LPK 2523 MO	TATA spare parts
504241107101	PROPELLER SHAFT GUARD	TATA spare parts
504241110102	ASSY. PROPELLER SHAFT FRONT	TATA spare parts
504241110103	ASSY. PREOPELLER SHAFT MIDDLE	TATA spare parts
504241110104	ASSY PROP SHAFT FRONT WITH CB	TATA spare parts
504241120101	ASSY. PROPELLER? SHAFT INTERAXLE	TATA spare parts
504241120104	ASSY PROPELLER SHAFT REAR	TATA spare parts
504241120105	ASSY. PROPLLER SHAFT REAR	TATA spare parts

504241120109	PROPELLER SHAFT ASSY REAR	TATA spare parts
504241120110	ASSY. PROPELLER SHAFT INTERAXLE BS3/4	TATA spare parts
504241120112	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
504241120113	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
504241120114	LONG FORK SUB ASSY	TATA spare parts
504241120115	SHORT FORK & REAR HSG SUB ASSY	TATA spare parts
504241120122	PROPELELR SHAFT ASSY DRIVE BS6	TATA spare parts
504241120132	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
504241300101	BRACKET ASSY CENTRE BEARING MTG	TATA spare parts
504241300102	BRACKET ASSY CENTRE BEARING MTG	TATA spare parts
504241300103	BRACKET ASSY CENTRE BEARING MTG	TATA spare parts
504242300101	DRUM BRAKE ASSY REAR LH WITH D/C	TATA spare parts
504242300102	DRUM BRAKE ASSY REAR RH WITH D/C	TATA spare parts
504242300119	BRACKET ASSY CHAMBER MTG LH	TATA spare parts
504242300120	BRACKET ASSY CHAMBER MTG RH	TATA spare parts
504242300123	ASSY. ASA 90MM OFFSET 30 CRANK-LH BS3/4	TATA spare parts
504242300124	ASSY. ASA 90MM OFFSET 30 CRANK-RH BS3/4	TATA spare parts
504242300125	REAR AXLE BRAKE ASSY W/T D/C-LH	TATA spare parts
504242300126	REAR AXLE BRAKE ASSY W/T D/C-RH	TATA spare parts
504242300190	AUTO SLACK ADJUSTER	TATA spare parts
504242303709	PLUMMER BLOCK REAR BRAKE ASSY	TATA spare parts
504242307901	S CAM SHAFT LH.	TATA spare parts
504242307902	S CAM SHAFT RH.	TATA spare parts
504242307903	S CAM-SHAFT LH	TATA spare parts
504242307904	S CAM-SHAFT RH	TATA spare parts
504242308204	ANCHOR BRACKET ASA LH	TATA spare parts
504242308205	ANCHOR BRACKET ASA RH	TATA spare parts
504242310102	AUTO SLACK ADJUSTER ASSY RH	TATA spare parts
504242310103	AUTO SLACK ADJUSTER ASSY LH	TATA spare parts
504243200101	BRACKET ASSY MTG FOR ADJUSTING VALVE MTG	TATA spare parts
504243700113	SBA TYPE 24/24 W/BOTH METRIC PORT BS3/4	TATA spare parts
504243700115	SBA TYPE 24/24 WITH STAND OUT 60 WORKING	TATA spare parts
504243700122	CHAMBERLH	TATA spare parts
504243700123	SPRING BRAKE ACTUATOR TYPE-16/16 (V+V)	TATA spare parts
504243700135	BRAKE CHAMBER LH	TATA spare parts
504243700136	SPRING BRAKE ACTUATOR TYPE 16/16	TATA spare parts
504243700144	ADJUSTING VALVE	TATA spare parts
504243703301	BRACKET	TATA spare parts
504243708202	ACRV MOUNTING BRACKET	TATA spare parts
504243803301	BRACKET	TATA spare parts
504243900112	PIPE ASSY BUNCH COMPLETE	TATA spare parts
504243900155	NYLON PIPE BUNCH ASSY	TATA spare parts
504243900192	ASSY OF TWO METAL PIPES FROM HOSE TO APD	TATA spare parts
504243900206	ASSY NYLON BUNCH FOR PRIMA 2523.K DROP A	TATA spare parts
504243900288	ASSY METAL PIPE JOINT TO APDA	TATA spare parts
504243900308	NYLON PIPE BUNCH ASSY.FOR APU	TATA spare parts
504243900364	PIPE ASSY METAL JOINT-3 TO TCV INLET	TATA spare parts

504243900365	PIPE ASSY METAL SECOND	TATA spare parts
504243900366	ASSY METAL PIPE TO APDA INLET	TATA spare parts
504243900382	METAL PIPE ASSY FIRST.	TATA spare parts
504243900385	PIPE ASSY METAL FIRST TO SECOND JOINT	TATA spare parts
504243900386	PIPE ASSY METAL CONTROL PORT TO JOINT	TATA spare parts
504243900390	PIPE ASSY METAL THIRD	TATA spare parts
504243903301	BRACKET(FOR TEE CONR.MTG.OF FRT.BRK.CCT)	TATA spare parts
504243907501	GROMMET (FOR BRAKE PIPES-LONG MEMBER) BS	TATA spare parts
504243908201	QRV MTG BRACKET (ON DEAD AXLE)	TATA spare parts
504243908202	L-BRACKET	TATA spare parts
504243908209	RELAY VALVE MOUNTING L BRACKET	TATA spare parts
504243910102	PIPE BUNCH ASSY FOR APU	TATA spare parts
504243910141	PIPE BUNCH ASSY FOR APDA	TATA spare parts
504243920110	PIPE ASSY THIRD METAL PIPE	TATA spare parts
504243920113	PIPE ASSY FOURTH METAL PIPE	TATA spare parts
504243920114	PIPE ASSY FIFTH METAL PIPE	TATA spare parts
504243920145	PIPE ASSY METAL FOURTH	TATA spare parts
504243990102	TYPE 16/16 SBA PORTS SPARE KIT NO.1	TATA spare parts
504243990103	TYPE 16/16 SBA PORTS SPARE KIT NO.2	TATA spare parts
504243990104	ADJUSTING VALVE REPAIR KIT	TATA spare parts
504243990105	SPRING BRAKE ACTUATOR T24/24 MAJOR SPARE	TATA spare parts
504245100115	ASSY.COMP NYLON BUNCH FOR SOLN-A C V/PTO	TATA spare parts
504246300101	ASSY. DRAG LINK BS3/4	TATA spare parts
504246800101	ASSY. SUCTION PIPE & HOSES	TATA spare parts
504246800102	ASSY.RETURN LINE FOR ZF AT GB END	TATA spare parts
504246800103	ASSY. PRESSURE LINE AT GEAR BOX END	TATA spare parts
504246800104	ASSY. PRESSURE LINE AT PUMP END	TATA spare parts
504246800105	ASSY RETURN LINE AT RESERVOIR END	TATA spare parts
504246800110	RETURN LINE ASSY	TATA spare parts
504246800118	PRESSURE LINE ASSY STG GEAR BOX END	TATA spare parts
504247100102	ASSY. FUEL TANK WELDED (260 LTR RECT) M0	TATA spare parts
504247100104	FUEL TANK RH 260 L (GALVANNEALED)	TATA spare parts
504247100111	ASSY. CAP FUEL TANK (CHAIN & KEY) BS3/4	TATA spare parts
504247108203	DRAIN PLUG BS6-PH2	TATA spare parts
504247600104	ASSY SUCTION LINE FUEL TANK TO	TATA spare parts
504247600105	ASSY FUEL RETURN LINE ENG. TO FUEL TANK	TATA spare parts
504247600106	ASSY FUEL SUCTION LINE W/S TO ENGINE	TATA spare parts
504247600107	ASSY FUEL SUCTION LINE W/S TO ENGINE	TATA spare parts
504247600108	ASSY FUEL RETURN LINE ENGINE TO F/T	TATA spare parts
504247600109	ASSY FUEL LINE FT TO WS 2523.T LCCR	TATA spare parts
504247600121	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
504247600122	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
504247600123	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
504247700102	BRACKET ASSY FUEL FILTER MTG BS6	TATA spare parts
504247704901	ASSY FUEL SENDER M0 CARGO	TATA spare parts
504249000101	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
504249100102	ASSY. EXHAUST FIRST PIPE BS3	TATA spare parts

504249100151	BRACKET ASSY UREA TANK & DOSING UNIT MTG	TATA spare parts
504249106501	HEX FL NUT M10	TATA spare parts
504249108001	HEX BOLT M12X130 IS1364P1-8.8-SS8451-8C	TATA spare parts
504249108002	HEX FL BOLT M10X130	TATA spare parts
504249109901	HEAT SHIELD OUTER	TATA spare parts
504249200102	BRACKET ASSY	TATA spare parts
504249200103	TAIL PIPE ASSY	TATA spare parts
504249200104	EXHAUST PIPE ASSY & FLANGE	TATA spare parts
504249200117	PIPE ASSY T-CONNECTOR TO AIR OIL FILTER	TATA spare parts
504249200119	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
504249200121	EXHAUST PIPE ASSY INT	TATA spare parts
504249200122	TAIL PIPE ASSY	TATA spare parts
504249200123	EXHAUST ELBOW	TATA spare parts
504249200124	STRUCTURE ASSY SILENCER MTG	TATA spare parts
504249200127	BRACKET ASSY EXHAUST BRAKE & VALVE MTG	TATA spare parts
504249200128	STRAP ASSY EGP MTG TOP	TATA spare parts
504249200130	BRACKET ASSY DECOMP PIPE MTG	TATA spare parts
504249200134	BRACKET ASSY STAY ROD MTG	TATA spare parts
504249203302	BRACKET MUFFLER MOUNTING	TATA spare parts
504249203305	BRACKET TAIL PIPE HOLDING SUPPORT	TATA spare parts
504249203310	CLAMP EXH PIPE	TATA spare parts
504249203315	BRACKET HEAT SHIELD MTG	TATA spare parts
504249203702	EXHAUST ELBOW	TATA spare parts
504249204201	CLAMP TAIL PIPE	TATA spare parts
504249205802	AIR PIPING(UREA TANK TO DOSER PUMP)	TATA spare parts
504249207105	SUPPORT PLATE	TATA spare parts
504249208203	HEAT SHILED SILENCER	TATA spare parts
504249208204	COVER HEAT SHIELD	TATA spare parts
504249604201	CLAMP HEAT SHIELD FRONT	TATA spare parts
504249604202	CLAMP HEAT SHIELD FRONT	TATA spare parts
504249990103	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990104	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990105	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990107	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990108	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990110	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990111	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990112	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990113	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990114	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990115	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990118	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990119	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990120	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504249990122	KIT-EXHAUST HEAT SHIELD	TATA spare parts
504254200102	INSTRUMENT CLUSTER ASSY	TATA spare parts
504254303301	BRACKET BEEPER MTG	TATA spare parts

504254709901	SWITCH CONTR. FUEL ECONOMY BS4	TATA spare parts
504300990102	KIT FULLY TRIMMED CABIN FOR PRIMA 3125.K	TATA spare parts
50430569000RCK	ASSY CAB KIT W/FITMENTS PRIMA 3123.T BS3	TATA spare parts
50430569000RCKCR	ASSY CAB COMP KIT PRIMA 3123.T BS3 CAR R	TATA spare parts
50430569000RCKTW	ASSY CAB COMP KIT PRIMA 3123.T BS3 TIT W	TATA spare parts
504326010102	GEAR SHIFT LINKAGE ASSY	TATA spare parts
504326800104	ASSY BASE PLATE	TATA spare parts
504326800105	GAITER ASSEMBLY	TATA spare parts
504326800106	PNEUMATIC PIPE ASSY	TATA spare parts
504326800109	TURNING TUBE ASSY	TATA spare parts
504326800119	PNEUMATIC PIPE ASSY	TATA spare parts
504326800121	PNEUMATIC PIPE ASSY BS6	TATA spare parts
504326800122	PNEUMATIC PIPE ASSY BS6	TATA spare parts
504326800136	PNEUMATIC PIPE ASSY BS6-PH2	TATA spare parts
504326901601	ASSY OIL COOLER HOSE (INLET FROM OIL COO	TATA spare parts
504326901602	ASSY OIL COOLER HOSE (OUTLET FROM OIL CO	TATA spare parts
504329100104	ASSY PNEU PIPE TO CLUTCH BOOSTER	TATA spare parts
504331000101	ASSEMBLY FRAME	TATA spare parts
504331000102	FRAME ASSY	TATA spare parts
504331000104	FRAME ASSY	TATA spare parts
504331000105	ASSY FRAME	TATA spare parts
504331000106	ASSY. FRAME 3123.T (FAB 4 HOLE BKT) BS3	TATA spare parts
504331100117	REINFORCEMENT ASSY LH	TATA spare parts
504331100118	REINFORCEMENT ASSY RH	TATA spare parts
504331100119	REINFORCEMENT ASSY LH	TATA spare parts
504331100120	REINFORCEMENT ASSY RH	TATA spare parts
504331107107	REINFORCEMENT LH	TATA spare parts
504331107108	REINFORCEMENT RH	TATA spare parts
504331107119	REINFORCEMENT FRONT LH BOTTOM	TATA spare parts
504331107120	REINFORCEMENT FRONT RH BOTTOM	TATA spare parts
504331107146	REINFORCEMENT FRONT LH	TATA spare parts
504331107147	REINFORCEMENT REAR LH	TATA spare parts
504331107148	REINFORCEMENT FRONT RH	TATA spare parts
504331107149	REINFORCEMENT REAR RH	TATA spare parts
504331200101	ASSY CROSS MEMBER LIFT AXLE	TATA spare parts
504331200106	ASSEMBLY CROSS MEMBER 4TH	TATA spare parts
504331200107	CROSS MEMBER ASSY LIFT AXLE	TATA spare parts
504331200110	CROSS MEMBER ASSY	TATA spare parts
504331200111	CROSS MEMBER ASSY	TATA spare parts
504331207102	CROSS MEMBER 4TH	TATA spare parts
504331207104	CROSS MEMBER	TATA spare parts
504331307108	ENG MTG BRKT C LH	TATA spare parts
504331307109	ENG MTG BRKT C RH	TATA spare parts
504331307110	LH GUSSET FOR END CROSS MEMBER	TATA spare parts
504331307111	RH GUSSET FOR END CROSS MEMBER	TATA spare parts
504331307112	GUSSET LWR	TATA spare parts
504331700118	BRACKET ASSY RUPD MTG LH	TATA spare parts

504331700119	BRACKET ASSY RUPD MTG RH	TATA spare parts
504331703301	BRACKET NOISE SHIELD MTG	TATA spare parts
504331707701	SHIELD UNDER CLUTCH-3123.K M0	TATA spare parts
504332100107	ASSLY.AXLE STOPPER	TATA spare parts
504332100109	PARABOLIC LEAF SPRING ASSY FRONT	TATA spare parts
504332100113	LEAF SPRING ASSY FRONT	TATA spare parts
504332100114	LEAF SPRING ASSY FRONT	TATA spare parts
504332100119	PARABOLIC LEAF SPRING ASSY FRONT FWD	TATA spare parts
504332103204	CENTER BOLT	TATA spare parts
504332103205	CENTRE BOLT M16X1.5X210	TATA spare parts
504332103301	SPRING HANGER BKT FRONT MIDDLE LH	TATA spare parts
504332103302	SPRING HANGER BKT FRONT MIDDLE RH	TATA spare parts
504332103304	SPRING HANGER BKT FRONT REARWARD	TATA spare parts
504332104201	U BOLT FRONT SPRING	TATA spare parts
504332104202	U-BOLT M22X1.5X315	TATA spare parts
504332104203	U-BOLT M22X1.5X300	TATA spare parts
504332104205	U-BOLT BS6	TATA spare parts
504332104206	U-BOLT BS6	TATA spare parts
504332104207	U-BOLT	TATA spare parts
504332107102	CASTER PLATE	TATA spare parts
504332107103	CASTER PLATE	TATA spare parts
504332107104	SPACER	TATA spare parts
504332107105	SPACER	TATA spare parts
504332303301	BRACKET SHOCK ABSORBER	TATA spare parts
504332303302	BRACKET SHOCK ABSORBER	TATA spare parts
504332303304	BRACKET SHOCK ABSORBER MTG LOWER-LH	TATA spare parts
504332303305	BRACKET SHOCK ABSORBER MTG LOWER-RH	TATA spare parts
504332307101	FRONT SHOCK ABSORBER BKT.	TATA spare parts
504332400102	ASSY. REAR SPRING	TATA spare parts
504332400109	ASSEMBLY TANDEM BOGIE WITH REVERSE U BOL	TATA spare parts
504332400110	BELL CRANK LEVER ASSY WITH CAST SHACKLE	TATA spare parts
504332400117	BELL CRANK LEVER ASSY	TATA spare parts
504332400118	KIT-BELL CRANK LEVER & LINK ROD	TATA spare parts
504332403301	BRACKET SPRING HANGER REAR-MIDDLE	TATA spare parts
504333000109	ASSY.FRONT AXLE COMP WITH BRAKES FFA W/O	TATA spare parts
504333000110	ASSY FRONT AXLE FRA NON ABS	TATA spare parts
504333000111	FRONT AXLE ASSY COMP. WITH BRAKES	TATA spare parts
504333000112	FRONT AXLE ASSY WITH BRAKE W/O ABS.	TATA spare parts
504333000114	LIFT AXLE ASSY WITH BRAKE	TATA spare parts
504333000116	FRONT AXLE ASSY WITH BRAKE FRT FWD	TATA spare parts
504333000118	FRONT AXLE ASSY WITH BRAKE FRT FWD	TATA spare parts
504333000119	FRONT AXLE ASSY WITH BRAKE FRT RWD	TATA spare parts
504333800101	TIE ROD ASSY	TATA spare parts
504333800102	TIE ROD ASSY	TATA spare parts
504333800103	BALL JOINT ASSY RH	TATA spare parts
504333800104	BALL JOINT ASSY LH	TATA spare parts
504333804701	DUST COVER BS6	TATA spare parts



504333805101	STEERING ARM BS6	TATA spare parts
504333805102	TIE ROD ARM RH	TATA spare parts
504333805103	TIE ROD ARM LH	TATA spare parts
504333900121	BRACKET ASSY LSV LINKAGE MTG ON AXLE	TATA spare parts
504333900122	AIR SPRING MOUNT ASSY-RH	TATA spare parts
504333900123	AIR SPRING MOUNT ASSY-LH	TATA spare parts
504333900140	ASSY. LIFT AXLE CONTROL VALVE BS3/4/6	TATA spare parts
504333900141	LOAD SENSING VALVE ASSY	TATA spare parts
504333900142	PRESSURE LIMITING VALVE ASSY	TATA spare parts
504333900143	ASSY. LIFT AXLE CONTROL VALVE BS3/4	TATA spare parts
504333900144	ASSY. LOAD DETECTION VALVE BS3/4	TATA spare parts
504333900146	NYLON PIPE ASSY LACV TO QRV	TATA spare parts
504333900147	NYLON PIPE ASSY LACV TO QRV	TATA spare parts
504333900158	KIT-NYLON PIPE ASSY	TATA spare parts
504333900171	LOAD SENSING VALVE BS6	TATA spare parts
504333900290	PUSHER AXLE ASSY	TATA spare parts
504333903306	U - SECTION	TATA spare parts
504333903307	REBOUND CLIP	TATA spare parts
504333903308	HANGER LH	TATA spare parts
504333903309	HANGER RH	TATA spare parts
504333907701	REBOUND STRAP	TATA spare parts
504333990101	CHOKE SCREW WITH O-RING	TATA spare parts
504333990102	COIL ASSY BS6	TATA spare parts
504333990103	VALVE WITH GASKET	TATA spare parts
504333990105	REPAIR KIT	TATA spare parts
504333990291	MAJOR KIT-LSV WITH P-CLAMP BS6	TATA spare parts
504333994201	MINOR KIT-P-CLAMP BS6	TATA spare parts
504340300101	ASSY SPARE WHEEL CARRIER	TATA spare parts
504341100101	ASSY PROP SHAFT FRONT FOR 3123.K	TATA spare parts
504341100102	PROPELLER SHAFT ASSY FRONT	TATA spare parts
504341100103	ASSY SECOND PROPELLER SHAFT FRONT 3123.K	TATA spare parts
504341107103	PROPELLER SHAFT GUARD FRT BOTTOM	TATA spare parts
504341107105	BRACKET P/SHAFT GUARD LPK3123.K	TATA spare parts
504341107106	GUARD P/SHAFT	TATA spare parts
504341110106	PROPELLER SHAFT ASSY FRONT	TATA spare parts
504341110108	PROPELLER SHAFT ASSY MIDDLE	TATA spare parts
504341110111	PROPELLER SHAFT ASSY MIDDLE	TATA spare parts
504341115103	COMPANION FLANGE	TATA spare parts
504341120103	PROPELLER SHAFT ASSY REAR	TATA spare parts
504341120104	PROPELLER SHAFT ASSY REAR	TATA spare parts
504341120106	PROPELLER SHAFT ASSY REAR	TATA spare parts
504341300105	BRACKET ASSY P/SHAFT MTG	TATA spare parts
504341300106	BRACKET ASSY P/SHAFT MTG	TATA spare parts
504341300107	BRACKET ASSY CENTER BRG MTG	TATA spare parts
504341303319	BRACKET CENTER BRG MTG	TATA spare parts
504341307108	CENTER BEARING BRACKET 3123.K DROOP AXLE	TATA spare parts
504341307111	CENTER BEARING MOUNTING BRACKET	TATA spare parts

504341990138	SHORT FORK TUBE&AMP FRONT END PIECE SU	TATA spare parts
504341990140	LONG FORK ASSY	TATA spare parts
504342100131	AUTO SLACK ADJUSTER ASSY LH	TATA spare parts
504342100132	AUTO SLACK ADJUSTER ASSY RH	TATA spare parts
504342303705	CHAMBER MOUNTING BRACKET LH./RH	TATA spare parts
504342303706	CHAMBER MOUNTING BRACKET RH/LH	TATA spare parts
504343200103	AIR TANK ASSY WITH BKT ASSY	TATA spare parts
504343200108	SUPPORT ASSY AIR TANK MTG	TATA spare parts
504343208201	BRACKET FOR HOLDING NYLON PIPE	TATA spare parts
504343700125	SPRING BRAKE ACTUATOR BS6	TATA spare parts
504343700138	SPRING BRAKE ACTUATOR BS6	TATA spare parts
504343708202	Z-BRACKET FOR METAL PIPE	TATA spare parts
504343708204	BRACKET FOR ADJUSTING VALVE MTG	TATA spare parts
504343900106	NYLON PIPE BUNCH ASSY COMPLETE	TATA spare parts
504343900152	ASY NYLON PIPE PORT 22 TO FR AIR-TANK	TATA spare parts
504343900153	ASY NYLON PIPE FROM PORT 24 TO PRV	TATA spare parts
504343900154	ASSY NYLON PIPE FROM APU PORT 23 TO PRV	TATA spare parts
504343900155	ASY NYLON PIPE FROM APU PORT 21 TO REAR	TATA spare parts
504343900157	ASSY NYLON PIPE FROM DVB PORT 11 TO TEE-	TATA spare parts
504343900158	ASSY NYLON PIPE FROM TEE-4 TO DTV PORT 1	TATA spare parts
504343900160	ASY NYLON PIPE FROM FRONT AIR TANK TO TE	TATA spare parts
504343900161	ASSY NYLON PIPE FROM DBV-22 TO TEE-3	TATA spare parts
504343900162	ASSY NYLON PIPE FROM TEE-4 TO RH FRONT F	TATA spare parts
504343900163	ASY NYLON PIPE FROM TEE3 TO TEE 2	TATA spare parts
504343900166	ASSY NYLON PIPE FROM TEE 7 TO RR RWD CKT	TATA spare parts
504343900167	ASSY NYLON PIPE FROM TEE-7 TO REAR FWD R	TATA spare parts
504343900168	ASY NYLON PIPE FROM TEE 2 TO LH FRONT C	TATA spare parts
504343900169	ASY NYLON PIPE FROM TEE-2 TO RH FRT CHA	TATA spare parts
504343900171	ASY NYLON PIPE FROM T-8 TO SBA REAR RWD	TATA spare parts
504343900172	ASY NYLON PIPE FROM T-9 TO SBA REAR FWD	TATA spare parts
504343900176	ASY NYLON PIPE FROM TEE-1 TO ACRV PORT-1	TATA spare parts
504343900181	ASSY METAL SECOND PIPE	TATA spare parts
504343900182	ASY NYLON PIPE FROM TEE-3 TO RELAY VALVE	TATA spare parts
504343900185	ASSY NYLON PIPE FROM PRV PARKING TO TEE-	TATA spare parts
504343900186	ASSY NYLON PIPE FROM TEE-5 TO RELAY VALV	TATA spare parts
504343900187	ASSY NYLON PIPE FROM TEE-5 TO RR RELAY F	TATA spare parts
504343900188	ASSY NYLON PIPE FROM TEE-6 TO TEE-7	TATA spare parts
504343900189	ASY NYLON PIPE FROM REAR AIR TANK TO TEE	TATA spare parts
504343900191	ASSY NYLON PIPE PRV TO AUXILIARY TANK(NR	TATA spare parts
504343900197	ASY SECOND METAL PIPE FROM APU END	TATA spare parts
504343900198	ASY NYLON PIPE FROM TEE -12 TO SOLENOID	TATA spare parts
504343900199	ASSY NYLON PIPE MAGNETIC VALVE TO EXHAUS	TATA spare parts
504343900201	ASSY OF NYLON BUNCH FOR 3123K	TATA spare parts
504343900202	ASY NYLON PIPE FROM ST ADAPTOR TO ACRV P	TATA spare parts
504343900203	ASY NYLON PIPE FROM DBV PORT-21 TO TEE-1	TATA spare parts
504343900204	ASY NYLON PIPE FROM TEE-14 TO ACRV PORT	TATA spare parts
504343900205	ASY NYLON PIPE FROM TEE 14 TO TEE-5	TATA spare parts

504343900210	ASY NYLON PIPE FROM RELAY RWD TO BRAKE C	TATA spare parts
504343900211	ASY NYLON PIPE FROM RELAY RWD TO BRAKE C	TATA spare parts
504343900212	ASY NYLON PIPE FROM RELAY FR TO SBA HOSE	TATA spare parts
504343900213	ASY NYLON PIPE FROM ACRV PORT-2 RH TO TE	TATA spare parts
504343900214	ASY NYLON PIPE FROM RELAY FRONT TO LH FR	TATA spare parts
504343900215	ASSY NYLON PIPE FROM TEE-9 TO RH FR RWD	TATA spare parts
504343900216	ASSY NYLON PIPE FROM TEE-9 TO FR RWD LH	TATA spare parts
504343900219	ASY NYLON PIPE AUXILIARY AIR TANK TO TEE	TATA spare parts
504343900220	ASY NYLON PIPE FROM TEE 10 TO TEEç 11	TATA spare parts
504343900228	ASSY NYLON PIPE FROM APDA PORT-4 TO CONT	TATA spare parts
504343900247	ASSY NYLON PIPE ST ADAPTOR TO HBV 1	TATA spare parts
504343900249	ASSY NYLON PIPE FROM HBV PORT-21 TO ST A	TATA spare parts
504343900250	ASY NYLON PIPE FROM TEE1 TO VOSS ADAPTOR	TATA spare parts
504343900270	NYLON PIPE BUNCH ASSY	TATA spare parts
504343900301	PIPE BUNCH ASSYç NYLON	TATA spare parts
504343900327	PIPE ASSY METAL FIRST TO SECOND JOINT	TATA spare parts
504343900342	ASSY METAL PIPE JOINT-4 TO TCV	TATA spare parts
504343900344	METAL PIPE ASSY FOURTH	TATA spare parts
504343900345	PIPE ASSY METAL FIRST	TATA spare parts
504343900353	METAL PIPE ASSY. SECOND	TATA spare parts
504343900354	METAL PIPE ASSY. THIRD	TATA spare parts
504343900373	METAL PIPE ASSY THIRD	TATA spare parts
504343900374	METAL PIPE ASSY FOURTH	TATA spare parts
504343900375	PIPE ASSY METAL SECOND	TATA spare parts
504343900388	PIPE ASSY METAL CTRL PORT TO JOINT	TATA spare parts
504343900389	METAL PIPE ASSY TCV TO APU INLET	TATA spare parts
504343900392	METAL PIPE ASSY TCV TO APU INLET	TATA spare parts
504343900393	METAL PIPE ASSY TCV INLET TO JOINT - 4	TATA spare parts
504343900398	NYLON PIPE BUNCH ASSY FOR APU	TATA spare parts
504343907501	GROMMET BS6-PH2	TATA spare parts
504343910170	PIPE ASSY NYLON RV-2 TO SBA RH PORT-11	TATA spare parts
504343910171	PIPE ASSY NYLON TEE 8 TO RH SBA PORT 12	TATA spare parts
504343910172	PIPE ASSY NYLON TEE 8 TO LH SBA PORT-12	TATA spare parts
504343910173	PIPE ASSY NYLON RV-2 TO SBA LH PORT-11	TATA spare parts
504343910177	PIPE ASSY NYLON ACRV TO TEE-8	TATA spare parts
504343910191	PIPE BUNCH ASSY FOR APU	TATA spare parts
504343920121	PIPE ASSY BUNCH COMPLETE	TATA spare parts
504343920152	PIPE ASSY BUNCH COMPLETE	TATA spare parts
504343920174	PIPE ASSY BUNCH COMPLETE	TATA spare parts
504343930166	PIPE ASSY METAL SECOND	TATA spare parts
504343940123	METAL PIPE ASSYç SECOND	TATA spare parts
504343940124	METAL PIPE ASSY THIRD	TATA spare parts
504343940150	PIPE ASSY METAL CTRL PORT TO JOINT	TATA spare parts
504343940153	PIPE ASSY METAL JOINT-3 TO TCV	TATA spare parts
504343940154	PIPE ASSY TCV TO METAL PIPE JOINT	TATA spare parts
504345100105	SET ASSY. NYLON BUNCH SOLENOI DIFF LOCK	TATA spare parts
504345100108	SET ASSY. COMP PIPE BUNCHç ACV BOX BODY	TATA spare parts

504346100101	STEERING GEAR BOX ASSY	TATA spare parts
504346300103	ASSY 1ST DRAG LINK	TATA spare parts
504346300104	ASSY 2ND DRAG LINK	TATA spare parts
504346300106	DRAG LINK ASSY -1	TATA spare parts
504346300107	RELAY ROD ASSY -1	TATA spare parts
504346300108	RELAY ROD ASSY -2	TATA spare parts
504346300109	DRAG LINK ASSY -2	TATA spare parts
504346304101	PITMAN ARM	TATA spare parts
504346305104	PITAMN ARM	TATA spare parts
504346305107	PITMAN ARM BS6	TATA spare parts
504346600101	STEERING PUMP TYPE-I	TATA spare parts
504346600102	STEERING GEAR BOX TYPE-I	TATA spare parts
504346600104	VANE PUMP ASSY BS6	TATA spare parts
504346609901	FLOW LIMITING PISTON BS6	TATA spare parts
504346609903	HOUSING ASSEMBLY BS6	TATA spare parts
504346700101	SPACER-STG RESERVOIR MTG BKT	TATA spare parts
504346700102	SPACER	TATA spare parts
504346703301	BKT - RELAY ARM MOUNTING	TATA spare parts
504346703303	BRACKET RELAY ARM MTG	TATA spare parts
504346703304	IDLER ARM MTG BRACKET	TATA spare parts
504346800101	PRESSURE LINE PUMP END	TATA spare parts
504346800102	SUCTION LINE	TATA spare parts
504346800103	RETURN LINE (RESERVOIR END)	TATA spare parts
504346800104	RETURN LINE-INTERMEDIATE	TATA spare parts
504346800105	PRESSURE LINE AASY GEAR BOX END	TATA spare parts
504346800106	PRESSURE LINE AASY POWER CYLINDER END	TATA spare parts
504346800107	PRESSURE LINE ASM-P/CYL	TATA spare parts
504346800113	ASSY RETURN LINE-GB END	TATA spare parts
504346800114	ELBOW ADAPTER ASSY	TATA spare parts
504346800115	PRESSURE LINE ASSY BS6	TATA spare parts
504346800116	HIGH PRESSURE LINE ASSY P/CYL	TATA spare parts
504346800117	HIGH PRESSURE LINE ASSY P/CYL	TATA spare parts
504346800118	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
504346800119	SUCTION LINE ASSY BS6	TATA spare parts
504346800120	DRAG LINK ASSY BALL JOINT	TATA spare parts
504346800121	ASSY. BALL JOINT RH BS3/4	TATA spare parts
504346800122	BALL JOINT ASSEMBLY-L.H	TATA spare parts
504346800124	BALL JOINT ASSY	TATA spare parts
504346800127	RETURN LINE ASSY STG GEAR BOX END BS6	TATA spare parts
504346800130	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
504346800131	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
504346800171	PRESSURE LINE ASM PUMP END TYPE-I	TATA spare parts
504346800172	RETURN LINE ASSY	TATA spare parts
504346800175	SUCTION LINE ASM TYPE I	TATA spare parts
504346800176	RETURN LINE ASM- RESERVOIR END	TATA spare parts
504346800179	SUCTION LINE ASSY	TATA spare parts
504346800180	ELBOW ADAPTER ASSY	TATA spare parts

504346800183	HIGH PRESSURE LINE ASSY GB END	TATA spare parts
504346800184	HIGH PRESSURE LINE ASSY INTERMEDIATE	TATA spare parts
504346800194	RETURN LINE ASSY RESERVOIR END	TATA spare parts
504346800195	HIGH PRESSURE LINE ASSY	TATA spare parts
504346803305	STG PIPE MTG BRKT	TATA spare parts
504346803310	BRACKET STRG PIPE MTG BS6	TATA spare parts
504346990107	HOUSING ASSY	TATA spare parts
504346990108	SECTOR SHAFT ASSY	TATA spare parts
504346990109	HOUSHING COVER ASSY	TATA spare parts
504346990110	PISTON ASSY	TATA spare parts
504346990111	COMPLETE SEALING KIT	TATA spare parts
504346990112	SMALL COMPONENT SET	TATA spare parts
504346990113	HOUSING ASSY	TATA spare parts
504346990114	DOWEL PIN	TATA spare parts
504346990115	PRESSURE PLATE	TATA spare parts
504346990116	PRESSURE PLATE ROTOR SET	TATA spare parts
504346990117	PRESSURE PLATE FRONT PLATE	TATA spare parts
504346990118	PUMP BODY ROTOR KIT	TATA spare parts
504346990119	POWER CYLINDER TUBE S/A	TATA spare parts
504346990120	PISTON ROD	TATA spare parts
504346990121	PISTON	TATA spare parts
504346990122	LOCK WASHER	TATA spare parts
504346990123	POWER CYLINDER HEAD END COWER	TATA spare parts
504346990124	POWER CYLINDER SET SCREW	TATA spare parts
504346990125	POWER CYLINDER SNAP RING	TATA spare parts
504346990126	POWER CYLINDER SNAP RING	TATA spare parts
504346990147	KIT-POWER STEERING PUMP BS6	TATA spare parts
504346994801	DOWEL PIN BS6	TATA spare parts
504347100103	FUEL TANK ASSY WITH BAFFLES (365LTR)	TATA spare parts
504347600101	ASSY. FUEL RETURN LINE	TATA spare parts
504347600102	ASSY FUEL SUCTION LINE	TATA spare parts
504347600105	FUEL SUCTION PIPE ASSY	TATA spare parts
504347600106	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
504347600107	FUEL SUCTION PIPE ASSY	TATA spare parts
504349100101	MUFFLER FOR 3123.K PRIMA	TATA spare parts
504349100102	CROSS MEMBER SUPPORT BRACKET	TATA spare parts
504349100111	BRACKET ASSY DOSING UNIT MTG	TATA spare parts
504349100113	BRACKET ASSY UREA TANK MTG	TATA spare parts
504349100114	BRACKET ASSY	TATA spare parts
504349100809	ASSY TAIL PIPE	TATA spare parts
504349108202	SUPPORT BKT FOR THIRD PIPE ASSY	TATA spare parts
504349108203	SUPPORT BKT FOR THIRD PIPE ASSY	TATA spare parts
504349108204	SUPPORT BKT FOR SECOND PIPE ASSY	TATA spare parts
504349108207	TAIL PIPE MTG.BRKT	TATA spare parts
504349108211	SUPPORT BKT FOR SECOND PIPE	TATA spare parts
504349108213	SUPPORT BKT FOR TAIL PIPE	TATA spare parts
504349108214	THIRD PIPE SUPPORT BKT	TATA spare parts

504349108215	TAIL PIPE SUPPORT BKT	TATA spare parts
504349200104	SECOND PIPE ASSY WITH FLEX	TATA spare parts
504349200107	EXHAUST PIPE ASSY & FLANGE	TATA spare parts
504349200128	PIPE ASSY T-CONNECTOR TO AIR OIL FILTER	TATA spare parts
504349200134	PRESSURE LINE,SM TO DM BS6	TATA spare parts
504349200135	RETURN LINE DM TO TANK BS6-PH2	TATA spare parts
504349206903	FOURTH PIPE FROM THIRD PIPE TO MUFFLER	TATA spare parts
504349206911	EXHAUST PIPE CENTER	TATA spare parts
504349207104	SPACER PLATE BS6	TATA spare parts
504349208201	CLAMP EXHAUST SILENCER MTG	TATA spare parts
504354109901	BATTERY BS6 PH2	TATA spare parts
504354504901	SWITCH LIGHT MODE	TATA spare parts
504354504902	SWITCH MEDIUM MODE	TATA spare parts
504354504903	SWITCH HEAVY MODE	TATA spare parts
504354600101	WIRING HARNESS WIPER	TATA spare parts
504354700101	BRACKET ASSY AUTO DRAIN CONN BKT MTG	TATA spare parts
504360CK0199	CAB COMPLETE PRIMA LX 3123.T	TATA spare parts
504432307101	SHOCK ABSORBER BRACKET TOP	TATA spare parts
504446900102	BALL JOINT ASSY	TATA spare parts
504524100104	RUBBER MOUNT FRONT	TATA spare parts
504524200104	RUBBER MOUNT REAR	TATA spare parts
504531200104	END CROSS MEMBER ASSY	TATA spare parts
504531200109	FRONT TOW HOOK ASSY	TATA spare parts
504531200114	CROSS MEMBER ASSY	TATA spare parts
504531200115	CROSS MEMBER ASSY	TATA spare parts
504531506701	COUPLING PIN	TATA spare parts
504532100105	ASSY BUMP STOPPER FRONT FWD	TATA spare parts
504532100106	ASSY BUMP STOPPER FRONT RWD	TATA spare parts
504532100109	PARABOLIC LEAF SPRING ASSY FRONT RWD	TATA spare parts
504532100110	PARABOLIC LEAF SPRING ASSY FRONT FWD	TATA spare parts
504532400118	LEAF SPRING ASSY REAR	TATA spare parts
504532400141	SPRING ASSY REAR BOGIE SUSPENSION	TATA spare parts
504532403705	TRUNNION PIVOT HOUSING	TATA spare parts
504532403724	TRUNNION BRACKET	TATA spare parts
504532408604	SPACER	TATA spare parts
504532506102	SPACER	TATA spare parts
504540100119	NYLON PIPE BUNCH	TATA spare parts
504542100109	AUTO SLACK ADJUSTER	TATA spare parts
504542100110	AUTO SLACK ADJUSTER	TATA spare parts
504542100116	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
504542100117	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
504542300147	AUTO SLACK ADJUSTER	TATA spare parts
504542300148	AUTO SLACK ADJUSTER	TATA spare parts
504542300149	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
504542300150	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
504542300151	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
504542300152	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts

504543700110	AIR DRYER ASSY	TATA spare parts
504543903301	BRACKET (HOSE MTG.)	TATA spare parts
504543903303	BRACKET	TATA spare parts
504543906804	T-SOCKET	TATA spare parts
504545100199	NYLON PIPE BUNCH	TATA spare parts
504545110103	NYLON PIPE BUNCH	TATA spare parts
504545304202	CLAMP (FOR NYLON PIPE)	TATA spare parts
504545307101	OPERATOR CONTOL UNIT	TATA spare parts
504545309906	BREATHER CONNECTOR	TATA spare parts
504545309907	CONNECTOR (AIR BREATHER)	TATA spare parts
504545309908	MALE CONNECTOR	TATA spare parts
504546305115	STEERING ARM RH	TATA spare parts
504546305118	STEERING ARM LH	TATA spare parts
504546600116	STEERING GEAR BOX ASSY	TATA spare parts
504546600122	POWER STEERING PUMP ASSY	TATA spare parts
504546600130	FILTER ASSY	TATA spare parts
504546600131	FLOW CONTROL VALVE ASSY	TATA spare parts
504546600132	FLOW CONTROL VALVE ASSY	TATA spare parts
504546605101	BRACKET POWER CYL MTG	TATA spare parts
504546605103	BRACKET POWER CYL MTG	TATA spare parts
504546609902	LEVEL GAUGE OIL RESERVOIR	TATA spare parts
504546609905	CAP BREATHER	TATA spare parts
504546703310	Z-BRKT-STRG PIPE MTG	TATA spare parts
504546816874	LOCK NUT M33X2 IS10410 SS8451-8C	TATA spare parts
504546990117	KIT-PIPE & ADAPTER	TATA spare parts
504547100108	FUEL FILTER(FUEL PRO FH 230 SERIES)	TATA spare parts
504547100113	FUEL TANK ASSY	TATA spare parts
504547606806	BALL VALVE	TATA spare parts
504554100104	ASSY.BATT.CABLE +VE- BATT TO BATT CUT OF	TATA spare parts
504554100106	BATTERY CABLE LINK FOR 12X12	TATA spare parts
504554100106AE	BATTERY CABLE LINK 12X12 1628	TATA spare parts
504554100108	ASSY SPACER BATTERY CLAMPING	TATA spare parts
504554100109	ASSY BATTERY COVER	TATA spare parts
504554110101	ASSY BATT CABLE -VE -FROM BATT TO B.C.SW	TATA spare parts
504554204901	INDICATOR REAR AXLE STEERING SYSTEM	TATA spare parts
504554204902	INDICATOR LAMP	TATA spare parts
504554209907	WASHER BOTTLE	TATA spare parts
504554400101	ASSY BRACKET FOR ENG LAMP MTG	TATA spare parts
504554607501	RUBBER GROMMET WITH SLIT(ELLIPTICAL 95X5	TATA spare parts
504554608202	L BRACKET FOR TAIL WH MTG	TATA spare parts
504554608207	PLATE FOR GROMMET	TATA spare parts
504554610102	WIRING HARNESS SWITCH	TATA spare parts
504554610103	WIRING HARNESS MAIN	TATA spare parts
504554610104	WIRING HARNESS BUMPER	TATA spare parts
504554610106	WIRING HARNESS ROOF	TATA spare parts
504554620111	WIRING HARNESS ENGINE	TATA spare parts
504554630102	WIRING HARNESS TAIL	TATA spare parts

504554630103	WIRING HARNESS ATU	TATA spare parts
504554630108	WIRING HARNESS ABS FRAME	TATA spare parts
504554640106	JUMPER CABLE ASSY	TATA spare parts
504554640108	BATTERY CABLE -VE CUT OFF SW TO SM	TATA spare parts
504554640109	BATTERY CABLE +VE CUT OFF SW TO SM	TATA spare parts
504554640110	CABLE ALTERNATOR TO STARTER MOTOR -VE	TATA spare parts
504554640111	CABLE ALTERNATOR TO STARTER MOTOR +VE	TATA spare parts
504583550101	COMPRESSOR ASSY	TATA spare parts
504746808202	L BRACKET	TATA spare parts
504831207128	FRONT EXTENSION	TATA spare parts
504841107101	GUARD PROPELLER SHAFT BS6	TATA spare parts
504843700101	ASSY.APDA MOUNTING BKT.FOR LPO1620	TATA spare parts
504843700102	24/24 VAVE SPRING BRAKE ACTUATOR	TATA spare parts
504843906801	DOUBLE SOCKET M14X1.5 TO M12X1.5	TATA spare parts
504847500115	ASSY. REAR ARRESTOR BS6	TATA spare parts
504847610103	SINGLE CLAMP ASSY WITH BRACKET BS6	TATA spare parts
504849208212	CLAMP-7THK.	TATA spare parts
504854100101	ASSY.BATTERY COVER - 180 AH	TATA spare parts
504854100109	NK (+95 SQ MM) BS6	TATA spare parts
504854108201	BATTERY CLAMP (180AH)	TATA spare parts
504854200101	INSTRUMENT CLUSTER MOUNTING PLATE	TATA spare parts
504854200102	INSTRUMENT CLUSTER COVER WITH FOAM	TATA spare parts
504854209902	RELAY 24V30A NO(MIDI RELAY)	TATA spare parts
504854209903	RELAY 24V30A NO(MICRO RELAY)	TATA spare parts
504854401601	MIL INDICATION ON DASHBOARD	TATA spare parts
504854401606	RANGE INHIBITED INDICATION	TATA spare parts
504854401607	TRANS SERVICE INDICATION	TATA spare parts
504929100102	HOSE FROM M/CYL TO CLUTCH SERVO(TYPE-1)	TATA spare parts
504942303305	BRACKET BS6	TATA spare parts
504942303306	BRACKET BS6	TATA spare parts
505029100101	HOSE FROM M/CYL TO CLUTCH SERVO(TYPE-1)	TATA spare parts
505029300101	ASSY. CLUTCH BOOSTER(TYPE 1) BS3/4	TATA spare parts
505031107103	REINFORCEMENT LH	TATA spare parts
505031107104	REINFORCEMENT RH	TATA spare parts
505031200101	ASSY CTR CROSS MEMBER	TATA spare parts
505031207101	CROSS MEMBER CTR	TATA spare parts
505245100125	ASSY 3/16 PNEUMATIC HOSE (STRAIGHT/STRAI	TATA spare parts
505245100127	ASSY 3/16 PNEUMATIC HOSE (STRAIGHT/STRAI	TATA spare parts
505245903401	ELBOW BODY CM 22X1.5	TATA spare parts
505324200103	RUBBER MOUNT REAR BS3/4	TATA spare parts
505341100102	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
505341100155	LONG FORK ASSLY	TATA spare parts
505341304331	COUPLING FLANGE SUB ASSLY	TATA spare parts
505341990101	SLIP YOKE ASSEMBLY	TATA spare parts
505341990102	WELCH PLUG	TATA spare parts
505341990103	SEAL	TATA spare parts
505341990104	CENTER BEARING RUBBER	TATA spare parts



505341990105	CENTER BEARING	TATA spare parts
505341990106	CENTER BEARING BRACKET	TATA spare parts
505341990107	WASHER-FLAT	TATA spare parts
505343900176	AIR DRYER CARTRIDGE BS4/6	TATA spare parts
505349203302	BRACKET FOR HOLDING TAIL PIPE	TATA spare parts
505383100201	ASSY FACE DUCT BS6	TATA spare parts
505383100202	ASSY DEFROST DUCT CENTRAL BS6	TATA spare parts
505383100203	ASSY DEFROST DUCT DRIVER SIDE BS6	TATA spare parts
505383100204	ASSY DEFROST DUCT CO-DRIVER SIDE BS6	TATA spare parts
505383100207	FOOT DUCT ASSY LH	TATA spare parts
505383100208	FOOT DUCT ASSY RH	TATA spare parts
505383106307	AIRVENT DEFROST GRILL LH	TATA spare parts
505383106308	AIRVENT DEFROST GRILL CENTER LH	TATA spare parts
505383106309	AIRVENT GRILL MIDDLE	TATA spare parts
505383106310	AIRVENT GRILL CENTER RH	TATA spare parts
505383106311	AIRVENT DEFROST GRILL SIDE RH	TATA spare parts
505383106320	AIR DUCT RH UPPER	TATA spare parts
505383106321	AIR DUCT RH LOWER	TATA spare parts
505383106322	AIR DUCT LH UPPER	TATA spare parts
505383106323	AIR DUCT LH LOWER	TATA spare parts
505383106324	CASE BLOWER UPPER	TATA spare parts
505383106325	CASE BLOWER LOWER	TATA spare parts
505383106326	DISTRIBUTION DUCT BLOWER BS6	TATA spare parts
505383110101	THERMAL EXPANSION VALVE	TATA spare parts
505383300102	CONTROL PANEL ASSY	TATA spare parts
505383300103	ASSY. CONTROL ONLY AC-ELECTRIC-24V BS4/6	TATA spare parts
505383300104	CONTROL PANEL ASSY BS6	TATA spare parts
505383400104	DRAIN HOSE ASSY	TATA spare parts
505383400107	ASSY. VENTILATION UNIT BS4/6	TATA spare parts
505383400108	VENTILATION ASSY	TATA spare parts
505383400110	WIRING HARNESS	TATA spare parts
505383400112	RESISTOR BLOWER	TATA spare parts
505383400114	VENTILATION UNIT ASSY BS6	TATA spare parts
505383400125	WIRING HARNESS BS6-PH2	TATA spare parts
505383400130	VENTILATION UNIT ASSY BS6 PH2	TATA spare parts
505383400131	AC UNIT ASSY BS6	TATA spare parts
505383400132	WIRING HARNESS SUB ASSY BS6	TATA spare parts
505383400138	EVAPORATOR ASSY BS6-PH2	TATA spare parts
505383400139	MOTOR ASSY WITH FAN BS6	TATA spare parts
505383400140	WIRING HARNESS BS6-PH2	TATA spare parts
505383400141	KINEMATICS ASSY MODE CONTROL BS6-PH2	TATA spare parts
505383400149	VENTILATION UNIT ASSY BS6 PH2	TATA spare parts
505383400151	BLOWER MOTOR ASSY BS6-PH2	TATA spare parts
505383400152	BLOWER ASSY BS6-PH2	TATA spare parts
505383400153	BLOWER MOTOR BS6-PH2	TATA spare parts
505383400159	MOTOR ASSY WITH FAN BS6	TATA spare parts
505383400164	THERMO EXPANSION VALVE BS6-PH2	TATA spare parts

505383400165	THERMISTER BS6-PH2	TATA spare parts
505383400166	ACTUATOR MOTOR BS6-PH2	TATA spare parts
505383400167	FILTER ASSY BS6-PH2	TATA spare parts
505383400168	DAMPER FACE BS6-PH2	TATA spare parts
505383400169	DAMPER ASSY BS6-PH2	TATA spare parts
505383400170	DAMPER FOOT BS6-PH2	TATA spare parts
505383400171	DAMPER FAD BS6-PH2	TATA spare parts
505383400175	KINEMATICS ASSY BS6-PH2	TATA spare parts
505383400207	AC UNIT ASSY	TATA spare parts
505383400212	EVAPOTATOR SUB ASSY	TATA spare parts
505383400214	ACTUATOR MOTOR ASSY	TATA spare parts
505383400217	THERMISTOR	TATA spare parts
505383400219	ASSY. MOTOR WITH FAN BS4/6	TATA spare parts
505383400220	WIRING HARNESS SUB ASSY	TATA spare parts
505383403314	BRACKET FAD MTG	TATA spare parts
505383403315	BRACKET BS6-PH2	TATA spare parts
505383403316	BRACKET BS6-PH2	TATA spare parts
505383403317	BRACKET BS6-PH2	TATA spare parts
505383403320	BRACKET RH BS6-PH2	TATA spare parts
505383403321	BRACKET LH BS6-PH2	TATA spare parts
505383403322	BRACKET RH BS6-PH2	TATA spare parts
505383403323	BRACKET LH BS6-PH2	TATA spare parts
505383403324	BRACKET UPPER DUCT MTG BS6-PH2	TATA spare parts
505383403325	BRACKET LH BS6-PH2	TATA spare parts
505383403326	BRACKET FRESH AIR DUCT MTG BS6-PH2	TATA spare parts
505383403328	BRACKET BS6-PH2	TATA spare parts
505383403401	BUSH BS6	TATA spare parts
505383403403	BUSH	TATA spare parts
505383404202	CLIP	TATA spare parts
505383404701	COVER HEATER CUTOUT	TATA spare parts
505383404902	RESISTOR ASSY BS6	TATA spare parts
505383404903	WIRING HARNESS BS6-PH2	TATA spare parts
505383404907	WIRE BS6-PH2	TATA spare parts
505383405314	MOUTH PACKING PAD	TATA spare parts
505383405315	BLOWER ASSY PACKING PAD	TATA spare parts
505383406001	LEVER SUB ASSY	TATA spare parts
505383406002	LEVER F/R MIDDLE LEVER	TATA spare parts
505383406003	MODE CAM PLATE	TATA spare parts
505383406301	FRESH AIR DUCT UPPER	TATA spare parts
505383406302	FRESH AIR DUCT LOWER	TATA spare parts
505383406303	CASE HEATER EVAP SIDE	TATA spare parts
505383406305	CAP	TATA spare parts
505383406307	CASING HEATER	TATA spare parts
505383406312	CASE BS6-PH2	TATA spare parts
505383406313	BAFFLE AIR DUCT BS6-PH2	TATA spare parts
505383406323	BLOWER CASING BS6-PH2	TATA spare parts
505383406324	BLOWER CASING BS6-PH2	TATA spare parts

505383406325	FRESH AIR DUCT BS6-PH2	TATA spare parts
505383406326	FRESH AIR DUCT BS6-PH2	TATA spare parts
505383406327	CASE BS6-PH2	TATA spare parts
505383406328	CASE BS6-PH2	TATA spare parts
505383406329	CASE BS6-PH2	TATA spare parts
505383406330	CASE BS6-PH2	TATA spare parts
505383406331	HEATER CASING LH BS6-PH2	TATA spare parts
505383406332	HEATER CASING RH BS6-PH2	TATA spare parts
505383406333	FOOT DUCT BS6-PH2	TATA spare parts
505383406334	COVER BS6-PH2	TATA spare parts
505383406335	COVER BS6-PH2	TATA spare parts
505383406336	COVER BS6-PH2	TATA spare parts
505383406337	CONNECTING DUCT BS6-PH2	TATA spare parts
505383406338	CONNECTING DUCT BS6-PH2	TATA spare parts
505383406339	COVER BS6-PH2	TATA spare parts
505383406340	FRESH AIR DUCT BS6-PH2	TATA spare parts
505383406343	FRESH AIR DUCT BS6-PH2	TATA spare parts
505383406344	CASE BS6-PH2	TATA spare parts
505383406345	CASE BS6-PH2	TATA spare parts
505383406347	CASE BS6-PH2	TATA spare parts
505383406901	SUCTION PIPE UNIT END	TATA spare parts
505383406904	LIQUID PIPE HVAC UNIT END	TATA spare parts
505383407801	FILTER BACK	TATA spare parts
505383407802	FILTER FRONT	TATA spare parts
505383409904	STICKER-AC REFRIGERANT CHARGE QTY	TATA spare parts
505383409905	STICKER BS6	TATA spare parts
505383507503	GROMMET FOR DRAIN PIPE	TATA spare parts
505383550101	ASSY. AIR COMPRESSOR BS4	TATA spare parts
505383550102	COMPRESSOR ASSY	TATA spare parts
505383550103	CLUTCH COMPRESSOR	TATA spare parts
505383600101	SUCTION PIPE ASSY	TATA spare parts
505383600102	DISCHARGE PIPE ASSY	TATA spare parts
505383600103	LIQUID PIPE ASSY	TATA spare parts
505383600104	SUCTION HOSE ASSY COMPRESSOR END	TATA spare parts
505383600105	AC PIPE ASSY	TATA spare parts
505383600107	LIQUID PIPE ASSY	TATA spare parts
505383600108	SUCTION HOSE ASSY COMPRESSOR END	TATA spare parts
505383600111	LIQUID PIPE ASSY	TATA spare parts
505383600114	DISCHARGE PIPE CONDENSER END 1	TATA spare parts
505383600123	PIPE ASSY BS6	TATA spare parts
505383600135	DISCHARGE PIPE CONDENSER END	TATA spare parts
505383600137	SUCTION PIPE HVAC END	TATA spare parts
505383600139	SUCTION PIPE HVAC END 1	TATA spare parts
505383600140	DISCHARGE PIPE ASSY BS6	TATA spare parts
505383600141	SUCTION PIPE ASSY BS6	TATA spare parts
505383600142	SUCTION HOSE ASSY COMPRESSOR END BS6	TATA spare parts
505383600143	SUCTION PIPE COMPRESSOR END BS6	TATA spare parts

505383600144	SUCTION PIPE ASSY BS6	TATA spare parts
505383600145	SUCTION PIPE HVAC END BS6	TATA spare parts
505383600146	SUCTION PIPE COMPRESSOR END BS6	TATA spare parts
505383600147	DISCHARGE & SUCTION LINE ASSY	TATA spare parts
505383600148	SUCTION PIPE HVAC END BS6	TATA spare parts
505383600149	DISCHARGE PIPE CONDENSER END BS6	TATA spare parts
505383600150	DISCHARGE PIPE CONDENSER END BS6	TATA spare parts
505383600151	DISCHARGE PIPE ASSY BS6	TATA spare parts
505383600153	DISCHARGE PIPE COMPRESSOR END BS6	TATA spare parts
505383600154	DISCHARGE PIPE COMPRESSOR END BS6	TATA spare parts
505383600156	SUCTION HOSE ASSY COMPRESSOR END BS6	TATA spare parts
505383600157	DISCHARGE & SUCTION LINE ASSY 1	TATA spare parts
505383600159	PLATE ASSY BS6	TATA spare parts
505383605801	DRAIN HOSE HVAC END	TATA spare parts
505383750103	BRACKET ASSY WITH WELD NUT BS6	TATA spare parts
505383750107	BRACKET ASSY AC PIPE MTG	TATA spare parts
505383750110	BRACKET ASSY WITH WELD NUT	TATA spare parts
505383750112	BRACKET ASSY WITH WELD NUT BS6	TATA spare parts
505383750121	BRACKET ASSY WITH WELD NUT BS6-PH2	TATA spare parts
505383784202	CLAMP AC PIPE	TATA spare parts
505383784203	CLAMP AC LINE	TATA spare parts
505383784204	P-CLAMP LIQUID TUBE	TATA spare parts
505383784205	P-CLAMP AC LINES	TATA spare parts
505383990111	KIT-COVER FITMENT BS6	TATA spare parts
505527999903	HARNESS ASSEMBLY CONTROL INTERNAL	TATA spare parts
505527999904	PLATE CHANNEL MEDIUM	TATA spare parts
505532300101	ASSY HYDRO PNEUMATIC STRUT FRONT	TATA spare parts
505532400116	CARDAN SHAFT ASSY REAR-LH	TATA spare parts
505532400126	CARDAN SHAFT ASSY REAR-RH	TATA spare parts
505532600101	ASSY HYDRO PNEUMATIC STRUT REAR	TATA spare parts
505540100103	WHEEL ASSY WITH RUNFLAT SYSTEM	TATA spare parts
505541000102	ASSY PROPELLER SHAFT FRONT	TATA spare parts
505541000103	ASSY PROPELLER SHAFT MIDDLE	TATA spare parts
505541000104	ASSY PROPELLER SHAFT REAR	TATA spare parts
505541000107	PROPELLER SHAFT ASSY LH-AMPHI DRIVE	TATA spare parts
505541000108	PROPELLER SHAFT ASSY RH-AMPHI DRIVE	TATA spare parts
505541005102	ASSY DRIVE SHAFT	TATA spare parts
505541104301	CIRCLIP	TATA spare parts
505543700114	AIR DRYER AIR PROCESSING UNIT	TATA spare parts
505543703803	VALVE AIR & MASTER CYL KNOTT	TATA spare parts
505543801601	BULKHEAD SOCKET	TATA spare parts
505543801602	BULKHEAD PLUG	TATA spare parts
505544000115	KIT ASSY FOR HYDRAULIC COMPONANT	TATA spare parts
505544000119	KIT-HYDRAULIC COMPONANT	TATA spare parts
505544106802	HOSE SUCTION LINE BULKHEAD TO PUMP	TATA spare parts
505544106804	HOSE PUMP TO RETURN LINE BULKHEAD	TATA spare parts
505544106809	ADAPTER BULKHEAD SOCKET M4X2	TATA spare parts

505544106810	ADAPTER BULKHEAD PLUG M42X2	TATA spare parts
505544106811	ADAPTER BULKHEAD SOCKET M30X2	TATA spare parts
505544106812	ADAPTER BULKHEAD PLUG M30X2	TATA spare parts
505545206801	BULK HEAD CONNECTOR FOR NYLON TO METALIC	TATA spare parts
505545206805	CONNECTOR MALE 3/8-18 NPTF	TATA spare parts
505545206808	MALE CONNECTOR CTI AIR INLET REAR	TATA spare parts
505545307101	OCP UNIT FOR WHAP (8X8)	TATA spare parts
505545307102	PCU UNIT CTIS FOR WHAP (8X8)	TATA spare parts
505545307103	WIRING HARNESS FOR CTIS WHAP (8X8)	TATA spare parts
505545307104	FITTINGS FOR CTIS HUB	TATA spare parts
505545307113	5/2 SINGLE SOL. VALVE 1/4IN (WITHOUT COI	TATA spare parts
505546600101	TANDEM PUMP 33 27CC	TATA spare parts
505546600102	STEERING OIL COOLER-WATER WHAP	TATA spare parts
505546806817	CONNECTOR C4 M22X1.5 PANEL MOUNTED	TATA spare parts
505546806818	CONNECTOR C4 M22X1.5 HOSE MOUNTED	TATA spare parts
505546806819	CONNECTOR C2 M26X1.5 PANEL MOUNTED	TATA spare parts
505546806820	CONNECTOR C2 M26X1.5 HOSE MOUNTED	TATA spare parts
505546806821	CONNECTOR C4 M26X1.5 PANEL MOUNTED	TATA spare parts
505546806822	CONNECTOR C4 M26X1.5 HOSE MOUNTED	TATA spare parts
505547606903	TUBE 15X12 ç 10 METER	TATA spare parts
505547606917	TUBE 12.5X10 ç 10 METER	TATA spare parts
505554109901	SOCKET SLAVE START	TATA spare parts
505554150101	FUSE POWER DESTRIUTION BOX	TATA spare parts
505554509903	BATTERY CUT OFF SWITCH	TATA spare parts
505554509904	TOGGLE SWITCH	TATA spare parts
505554509908	TOGGLE SWITCH(PULL TO UNLOCK)	TATA spare parts
505554509910	PUSH BUTTON WITH INDICATOR	TATA spare parts
505554509911	LENS FOR PUSH BUTTON	TATA spare parts
505554509913	TOGGLE SWITCH(PULL TO UNLOCK MOM)	TATA spare parts
505554509914	LED INDICATOR RED	TATA spare parts
505554509916	SWITCH TOGGLE CENTER OFF	TATA spare parts
505554509917	SWITCH PUSH BUTTON	TATA spare parts
505554509918	SWITCH SECUIRTY CAP	TATA spare parts
505554509919	SWITCH TOGGLE PULL CENTER OFF	TATA spare parts
505554509920	LAMP LED GREEN 6MM	TATA spare parts
505554509921	LAMP LED YELLOW 6MM	TATA spare parts
505554509922	LAMP LED RED 22MM	TATA spare parts
505554600117	W/H ABS FRAME	TATA spare parts
505554601606	WIRING HARNESS ENGINE	TATA spare parts
505554601615	W/H UNDER BODY CONNECTIONS	TATA spare parts
505554601616	WIRING HARNESS CAN	TATA spare parts
505554601617	W/H DRIVER COMPARTMENT	TATA spare parts
505554601618	W/H MAIN	TATA spare parts
505554601619	W/H SWITCH PLATE 1	TATA spare parts
505554601620	W/H SWITCH PLATE 2	TATA spare parts
505554601621	W/H SWITCH PLATE 3	TATA spare parts
505554601622	W/H SWITCH PLATE 4	TATA spare parts

505554601623	W/H NBC SWITCH	TATA spare parts
505554601624	W/H NBC	TATA spare parts
505554601627	W/H HYDROJET	TATA spare parts
505554601628	SOLENOID PIGTAIL	TATA spare parts
505554601629	WIRING HARNESS ROOF	TATA spare parts
505554601630	WIRING HARNESS FRONT LH	TATA spare parts
505554601631	WIRING HARNESS HYDRAULIC SYSTEM	TATA spare parts
505556000102	WINCH ASSY SIDE MOUNTED	TATA spare parts
505556500103	ROPE TRUMPET ASSY	TATA spare parts
505556500104	ROPE GUIDE PULLEY ASSY	TATA spare parts
505556500107	AIR VALVE ASSY	TATA spare parts
505556500110	WINCH REMOTE CONTROL BOX ASSY	TATA spare parts
505556500112	CONTROL VALVE CABLE ASSY	TATA spare parts
505556500113	CONNECTION BOX ASSY	TATA spare parts
505556500114	WIRE ROPE ASSY WINCH	TATA spare parts
505556506801	AIR VALVE CONNECTOR FOR WINCH	TATA spare parts
505583606917	SUCTION HOSE	TATA spare parts
505583606918	LIQUID PIPE	TATA spare parts
505583606920	LIQUID PIPE	TATA spare parts
505583606921	LIQUID PIPE	TATA spare parts
505583606922	LIQUID PIPE	TATA spare parts
505583606923	SUCTION HOSE	TATA spare parts
505583606924	DISCHARGE HOSE ASSY	TATA spare parts
505583606925	DISCHARGE HOSE ASSY COMPRESSOR	TATA spare parts
505583606926	DISCHARGE HOSE ASSY	TATA spare parts
505583606927	LIQUID PIPE ASSY	TATA spare parts
505583606929	DISCHARGE HOSE ASSY CONDENSOR	TATA spare parts
505583606930	LIQUID PIPE CONDENSER END	TATA spare parts
505583606932	SUCTION HOSE ASSY	TATA spare parts
505583606933	SUCTION HOSE ASSY COMPRESSOR END	TATA spare parts
505583606934	SUCTION PIPE MIDDLE	TATA spare parts
505583606935	LIQUID PIPE MIDDLE	TATA spare parts
505583606936	LIQUID HOSE ASSY	TATA spare parts
505583606937	SUCTION HOSE ASSY HVAC	TATA spare parts
505583606938	LIQUID PIPE MIDDLE	TATA spare parts
505583606939	LIQUID PIPE MIDDLE	TATA spare parts
505583606940	LIQUID PIPE CONDENSER END	TATA spare parts
505649100125	CLAMP ASSY EGP MTG	TATA spare parts
505649103358	BRACKET EGP MTG	TATA spare parts
505649103359	BRACKET EGP MTG	TATA spare parts
505649104204	CLAMP EGP MTG	TATA spare parts
505649200112	EXHAUST PIPE ASSY	TATA spare parts
505649200151	BRACKET ASSY	TATA spare parts
505649203312	SUPPORT BRACKET	TATA spare parts
505649203357	SUPPORT BRACKET	TATA spare parts
505649206902	EXHAUST TAIL PIPE	TATA spare parts
505743903301	BRACKET HOSE MTG LH	TATA spare parts

505749100104	FLEX CONNECTOR ASSY	TATA spare parts
505749109925	FLEX CONNECTOR HEAT SHIELD	TATA spare parts
505749200107	SUPPORT ASSY EXHAUST MTG	TATA spare parts
505749207101	SUPPORT PLATE	TATA spare parts
505754400103	TAIL LAMP MTG ASSY LH	TATA spare parts
505754400104	TAIL LAMP MTG ASSY RH	TATA spare parts
505754600119	W/H SWITCH	TATA spare parts
505754601607	BATTERY CABLE -VE(CUTOFF SW TO SM)	TATA spare parts
505754601608	BATTERY CABLE +VE (CUTOFF SW TO SM)	TATA spare parts
505754601609	BATTERY CABLE +VE (BATT TO B.C.SW)	TATA spare parts
505754601610	BATTERY CABLE -VE (BATT TO B.C.SW)	TATA spare parts
505833805101	STEERING ARM	TATA spare parts
506140100108	TUBELESS WHEEL RIM ASSY	TATA spare parts
506140109901	TUBELESS TYRE FOR RACE 3 STOCKING ONLY	TATA spare parts
506145300101	SOLENOID VALVE	TATA spare parts
506331200101	CROSS MEMBER ASSY BS6	TATA spare parts
506333105101	FRONT AXLE BEAM BS6	TATA spare parts
506341303301	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
506343700102	BRACKET ASSY APDA MTG BS6	TATA spare parts
506343700115	RELAY VALVE & MODULATOR VALVE ASSY W BKT	TATA spare parts
506343700116	BRACKET BS6-PH2	TATA spare parts
506343700120	FOOT BRAKE VALVE BS6	TATA spare parts
506343700121	SPRING BRAKE ACTUATOR BS6	TATA spare parts
506346100101	STEERING GEAR BOX ASSY BS6	TATA spare parts
506346600101	POWER STEERING PUMP ASSY BS6	TATA spare parts
506346600107	KIT-ROTOR WITH FR PLATE & AMP PR PLATE B	TATA spare parts
506346609901	HOUSING ASSY BS6-PH2	TATA spare parts
506346609903	KIT WITH FRONT PLATE & PRESSURE PLATE BS	TATA spare parts
506346703301	BRACKET POWER CYL MTG BS6	TATA spare parts
506346990115	PISTON ASSY BS6	TATA spare parts
506346990121	HOUSING ASSY BS6	TATA spare parts
506346990126	SECTOR SHAFT ASSY BS6	TATA spare parts
506354600101	FUSE BOX SUPPORT ASSY BS6	TATA spare parts
506354600102	FUSE BOX MTG ASSY BS6	TATA spare parts
506400990101	KIT FULLY TRIMMED CABIN LPK2518 BSIII	TATA spare parts
506400990102	KIT FULLY TRIMMED SIGNA CAB LPK2518 BS4	TATA spare parts
506400990103	KI-FULLY TRIMMED CABIN LPK 2518 AC BS4	TATA spare parts
506400990104	KIT FULL TRIMMED CAB 2518 BS4 SGNA NS AC	TATA spare parts
506400990107	ASSY. CAB KIT LPK 2518 NON SLP AC BS4	TATA spare parts
506400990108	KIT-FULL TRIMMED CAB LPK2518 CRE AC BS4	TATA spare parts
506400990109	ASSY. CAB KIT LPK CRE BS4 NON SLP BLW	TATA spare parts
50641238100R40	ASSLY CAB COMPLETE(NON SLEEPER)	TATA spare parts
506429100102	FOAM CLUTCH PEDAL BS6	TATA spare parts
506429100103	SEAL MASTER CYLINDER BACK PLATE	TATA spare parts
506429100104	FOAM CLUTCH PEDAL BS6	TATA spare parts
506429300101	BUNDY TUBE ASSY CMC TO LONG MEMBER	TATA spare parts
506429300102	ASSY. CLUTCH MASTER CYLINDER BS3/4/6	TATA spare parts

506429300103	MAJOR KIT-MASTER CYLINDER	TATA spare parts
506429300105	MINOR KIT-MASTER CYLINDER	TATA spare parts
506429300107	CLUTCH MASTER CYLINDER WITH RESERVOIR BS	TATA spare parts
506429300109	MAJOR KIT-MASTER CYLINDER WITH RESERVOIR	TATA spare parts
506429300110	MINOR KIT-MASTER CYLINDER WITH RESERVOIR	TATA spare parts
506429500102	BRACKET ASSY RESERVOIR HOLDING	TATA spare parts
506429500105	BRACKET ASSY CLUTCH MASTER CYLINDER MTG	TATA spare parts
506429500109	BRACKET ASSY CLUTCH MASTER CYLINDER MTG	TATA spare parts
506429500110	BRACKET ASSY RESERVOIR HOLDING BS6	TATA spare parts
506431000101	FRAME ASSY WITH FITMENT	TATA spare parts
506432400102	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
506432400103	LEAF SPRING ASSY REAR BS6	TATA spare parts
506432407102	2ND LEAF BS6	TATA spare parts
506432407103	3RD LEAF BS6	TATA spare parts
506432407104	4TH LEAF BS6	TATA spare parts
506432407105	5TH LEAF BS6	TATA spare parts
506432407106	6TH LEAF BS6	TATA spare parts
506432407107	7TH LEAF BS6	TATA spare parts
506432407109	9TH LEAF BS6	TATA spare parts
506432407110	10TH LEAF BS6	TATA spare parts
506432407111	11TH LEAF BS6	TATA spare parts
506432407112	12TH LEAF BS6	TATA spare parts
506432407113	8TH LEAF BS6	TATA spare parts
506441120101	PROPELLER DRIVE SHAFT ASSY	TATA spare parts
506441120102	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
506441120103	PROPELLER SHAFT ASSY INTERAXLE	TATA spare parts
506441120104	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
506443700116	SPRING BRAKE ACTUATOR BS6	TATA spare parts
506443700117	SPRING BRAKE ACTUATOR ASSY	TATA spare parts
506443700118	SPRING BRAKE ACTUATOR BS6	TATA spare parts
506443700119	SPRING BRAKE ACTUATOR	TATA spare parts
506443900102	BUNCH ASSY PIPE	TATA spare parts
506443900104	BUNCH ASSY PIPE	TATA spare parts
506443900134	NYLON PIPE BUNCH ASSY	TATA spare parts
506447500104	BRACKET ASSY FUEL TANK MTG	TATA spare parts
506447600101	FUEL SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
506447600102	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
506454400101	TAIL LAMP MTG ASSY LH	TATA spare parts
506454400102	TAIL LAMP MTG ASSY RH	TATA spare parts
506454403305	COVER TAIL LAMP	TATA spare parts
506454500103	LINK ASSY	TATA spare parts
506454504901	SWITCH ENGINE BRAKE	TATA spare parts
506454504902	BATTERY CUT OFF SWITCH	TATA spare parts
506454600104	WIRING HARNESS TAIL	TATA spare parts
506454600106	WIRING HARNESS TAIL	TATA spare parts
506454600109	PIGTAIL ASSY EMS WIRING HARNESS	TATA spare parts
506454600110	WIRING HARNESS FRONT BS4	TATA spare parts



506454600111	WIRING HARNESS ENGINE BS4	TATA spare parts
506454600112	WIRING HARNESS MAIN	TATA spare parts
506454600113	WIRING HARNESS ABS SPLIT	TATA spare parts
506454600115	WIRING HARNESS ABS FRAME	TATA spare parts
506454600116	WIRING HARNESS TAIL	TATA spare parts
506454600118	WIRING HARNESS TAIL	TATA spare parts
506454600122	WIRING HARNESS TAIL	TATA spare parts
506454600123	WIRING HARNESS ENGINE	TATA spare parts
506454600130	PIGTAIL ASSY EMS WIRING HARNESS	TATA spare parts
506454600132	WIRING HARNESS MAIN BS4	TATA spare parts
506454600135	WIRING HARNESS EMS PIGTAIL	TATA spare parts
506454600138	WIRING HARNESS TAIL	TATA spare parts
506454601601	WIRING HARNESS TAIL	TATA spare parts
50645538100R40	ASSEMBLY BODY FITTED	TATA spare parts
50646138100R40	ASSLY CAB COMPLETE(NON SLEEPER)	TATA spare parts
506624203701	BRACKET ENGINE MTG BOTTOM REAR-RH BS6	TATA spare parts
506624203702	BRACKET ENGINE MTG BOTTOM REAR-LH BS6	TATA spare parts
506631000102	FRAME ASSY WITH FITMENT	TATA spare parts
506631000108	FRAME ASSY WITH FITMENT	TATA spare parts
506631000116	FRAME ASSY WITH FITMENT	TATA spare parts
506631000148	FRAME ASSY WITH FITMENT	TATA spare parts
506631000154	FRAME ASSY WITH FITMENT	TATA spare parts
506631107119	REINFORCEMENT SPRING CROSS MEMBER RH	TATA spare parts
506631107120	REINFORCEMENT SPRING CROSS MEMBER LH	TATA spare parts
506631107123	REINFORCEMENT RH	TATA spare parts
506631107124	REINFORCEMENT LH	TATA spare parts
506631107150	REINFORCEMENT RH BS6	TATA spare parts
506631107151	REINFORCEMENT LH BS6	TATA spare parts
506631200102	CROSS MEMBER ASSY BUMPER	TATA spare parts
506631200105	SUPPORT BRACKET ASSY	TATA spare parts
506631200106	SUPPORT BRACKET ASSY RH	TATA spare parts
506631200107	CROSS MEMBER ASSY BS6	TATA spare parts
506631200113	CROSS MEMBER ASSY BS6	TATA spare parts
506631200114	CROSS MEMBER ASSY BS6	TATA spare parts
506631300102	GUSSET ASSY CROSS MEMBER	TATA spare parts
50663130010235	UNPAINTED GUSSET ASSY CROSS MEMBER BS6 P	TATA spare parts
506631300103	SUPPORT BRACKET ASSY BELLOW MTG LH	TATA spare parts
506631300104	CROSS MEMBER ASSY WITH GUSSET	TATA spare parts
506631300105	SUPPORT BRACKET ASSY BELLOW MTG RH	TATA spare parts
506631307109	REINFORCEMENT CROSS MEMBER	TATA spare parts
506631307113	GUSSET BUMPER CROSS MEMBER LH	TATA spare parts
506631307114	GUSSET BUMPER CROSS MEMBER RH	TATA spare parts
506632100105	PARABOLIC LEAF SPRING ASSY FRONT	TATA spare parts
506632100106	PARABOLIC LEAF SPRING ASSY REAR	TATA spare parts
506632100119	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
506632100121	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
506632100123	PARABOLIC LEAF SPRING ASSY FRONT BS6	TATA spare parts

506632100126	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
506632100137	PARABOLIC LEAF SPRING ASSY FRONT	TATA spare parts
506632100138	PARABOLIC LEAF SPRING ASSY REAR	TATA spare parts
506632100154	BUMP STOPPER ASSY FRONT BS6	TATA spare parts
506632100158	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
506632100159	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
506632100161	PARABOLIC LEAF SPRING ASSY FRONT FWD BS6	TATA spare parts
506632100162	PARABOLIC LEAF SPRING ASSY FRONT RWD BS6	TATA spare parts
506632100165	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
506632100166	PARABOLIC LEAF SPRING ASSY FRONT RWD BS6	TATA spare parts
506632100167	PARABOLIC LEAF SPRING ASSY FRONT FWD BS6	TATA spare parts
506632100168	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
506632103201	CENTER BOLT	TATA spare parts
506632103202	CENTER BOLT	TATA spare parts
506632103206	CENTERBOLT LEAFSPRINGCENTREBOLT BS6	TATA spare parts
506632103219	CENTER BOLT BS6-PH2	TATA spare parts
506632103220	CLAMP BOLT BS6-PH2	TATA spare parts
506632103222	CENTER BOLT BS6-PH2	TATA spare parts
506632103224	CENTER BOLT BS6-PH2	TATA spare parts
506632104201	U-CLAMP	TATA spare parts
506632104202	U-CLAMP	TATA spare parts
506632104204	U-BOLT	TATA spare parts
506632104210	U-BOLT BS6	TATA spare parts
506632104214	SPRING CLIP BS6-PH2	TATA spare parts
506632104215	CLAMP BS6-PH2	TATA spare parts
506632104216	CLAMP BS6-PH2	TATA spare parts
506632106501	CENTER BOLT NUT BS6-PH2	TATA spare parts
506632106503	HEX NUT BS6-PH2	TATA spare parts
506632107122	CASTER PLATE BS6	TATA spare parts
506632107124	2ND LEAF BS6	TATA spare parts
506632107125	3RD LEAF BS6	TATA spare parts
506632107126	4TH LEAF BS6	TATA spare parts
506632107130	2ND LEAF BS6	TATA spare parts
506632107131	3RD LEAF BS6	TATA spare parts
506632107133	4TH LEAF BS6	TATA spare parts
506632107134	SPACER BS6	TATA spare parts
506632107136	SPACER BS6-PH2	TATA spare parts
506632107157	4TH LEAF BS6-PH2	TATA spare parts
506632107158	4TH LEAF BS6-PH2	TATA spare parts
506632107161	SPACER BS6-PH2	TATA spare parts
506632107162	2ND LEAF BS6-PH2	TATA spare parts
506632107163	3RD LEAF BS6-PH2	TATA spare parts
506632107167	CASTER PLATE BS6-PH2	TATA spare parts
506632107168	2ND LEAF BS6-PH2	TATA spare parts
506632107171	3RD LEAF BS6-PH2	TATA spare parts
506632107172	SPACER BS6-PH2	TATA spare parts
506632107173	4TH LEAF BS6-PH2	TATA spare parts

506632107175	3RD LEAF BS6-PH2	TATA spare parts
506632107177	2ND LEAF BS6-PH2	TATA spare parts
506632107179	2ND LEAF BS6-PH2	TATA spare parts
506632107185	3RD LEAF BS6-PH2	TATA spare parts
506632107186	4TH LEAF BS6-PH2	TATA spare parts
506632108604	CENTER LINER BS6-PH2	TATA spare parts
506632108605	SPACER TUBE BS6-PH2	TATA spare parts
506632300103	BRACKET ASSY FRONT SHOCK ABSORBER TOP BS	TATA spare parts
506632400102	LEAF SPRING ASSY REAR	TATA spare parts
506632400122	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
506632400123	LEAF SPRING ASSY REAR BS6	TATA spare parts
506632400135	LEAF SPRING ASSY REAR BS6	TATA spare parts
506632400137	LEAF SPRING ASSY REAR BS6-PH2	TATA spare parts
506632400139	REAR SPRING ASSY BS6-PH2	TATA spare parts
506632403201	CENTER BOLT _LEAF SPRING	TATA spare parts
506632403202	CENTER BOLT BS6-PH2	TATA spare parts
506632403310	BRACKET SPRING HANGER MIDDLE-LH BS6	TATA spare parts
506632403311	BRACKET SPRING HANGER MIDDLE-RH BS6	TATA spare parts
506632403312	BRACKET SPRING HANGER REAR-LH BS6	TATA spare parts
506632403313	BRACKET SPRING HANGER REAR-RH BS6	TATA spare parts
506632403314	BRACKET FRONT SPRING HANGER REAR BS6	TATA spare parts
506632404201	SPRING CLIP _REAR SPRING	TATA spare parts
506632404202	SPRING CLIP _REAR SPRING	TATA spare parts
506632404203	SPRING CLIP _REAR SPRING	TATA spare parts
506632404206	SPRING CLIP BS6	TATA spare parts
506632404209	U-CLAMP BS6 PH2	TATA spare parts
506632406701	PIN BS6	TATA spare parts
506632407138	4TH LEAF BS6	TATA spare parts
506632407139	14TH LEAF BS6	TATA spare parts
506632407140	10TH LEAF BS6	TATA spare parts
506632407141	7TH LEAF BS6	TATA spare parts
506632407142	2ND LEAF BS6	TATA spare parts
506632407143	6TH LEAF BS6	TATA spare parts
506632407144	1ST LEAF BS6-PH2	TATA spare parts
506632407145	11TH LEAF BS6	TATA spare parts
506632407146	8TH LEAF BS6	TATA spare parts
506632407147	12TH LEAF BS6	TATA spare parts
506632407148	3RD LEAF BS6	TATA spare parts
506632407149	9TH LEAF BS6	TATA spare parts
506632407150	13TH LEAF BS6	TATA spare parts
506632407151	5TH LEAF BS6	TATA spare parts
506633000101	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
506633000102	FRONT AXLE ASSY WITH BRAKE FRT FWD	TATA spare parts
506633000103	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
506633000104	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
506633105101	FRONT AXLE BEAM BS6	TATA spare parts
506633900105	AXLE SEAT ASSY LH	TATA spare parts

506633900106	AIR SPRING MTG RH	TATA spare parts
506633900114	LIFT AXLE CONTROL VALVE ASSY	TATA spare parts
506633900115	AIR SPRING MTG LH	TATA spare parts
506633900117	AXLE SEAT ASSY RH	TATA spare parts
506633900118	Z-SECTION	TATA spare parts
506633900121	LIFT AXLE CONTROL VALVE ASSY	TATA spare parts
506633900169	KIT-LIFT AXLE BS6	TATA spare parts
506633900175	BEAM ASSY LH	TATA spare parts
506633900176	BEAM ASSY RH	TATA spare parts
506633900178	AIR SPRING MTG LH	TATA spare parts
506633900179	AIR SPRING MTG RH	TATA spare parts
506633900180	AXLE BEAM ASSY	TATA spare parts
506633900183	QUICK RELEASE VALVE ASSLY LH	TATA spare parts
506633900184	QUICK RELEASE VALVE ASSLY RH	TATA spare parts
506633900196	LIFT AXLE BEAM ASSY	TATA spare parts
506633900198	LIFT AXLE ASSY WITH BRAKE	TATA spare parts
506633900207	BRACKET	TATA spare parts
506633900208	BRACKET	TATA spare parts
506633900230	PIPE BUNCH ASSY	TATA spare parts
506633900244	KIT-NYLON PIPES BS6	TATA spare parts
506633900363	LINK ROD ASSY BS6	TATA spare parts
506633900366	LIFT AXLE CONTROL VALVE ASSY BS6	TATA spare parts
506633903204	1 1/8-7 NYLOC NUT	TATA spare parts
506633903206	1 1/8-7 X 10 HEX HEAD BOLT	TATA spare parts
506633903207	1 1/8-7 X 11 IN HEX HEAD BOLT	TATA spare parts
506633903208	M16X2X 40LG GRD 10 9 HEX HD BOLT	TATA spare parts
506633903214	M16X2X 45LG GRD 10.9 HEX HD BOLT	TATA spare parts
506633903215	1 1/8-7 X 11 IN HEX HEAD BOLT	TATA spare parts
506633903216	1 1/8-7 NYLOC NUT	TATA spare parts
506633903217	M30X2X260LG GRD 10.9 HEX HD BOLT	TATA spare parts
506633903218	M30 HARDENED WASHER	TATA spare parts
506633903219	M30X-2 CLASS 10 NYLOCK NUT	TATA spare parts
506633903301	HANGER LH	TATA spare parts
506633903302	HANGER RH	TATA spare parts
506633903303	Z-SECTION	TATA spare parts
506633903305	HANGER ADJUSTMENT PLATE	TATA spare parts
506633903310	BOLT M27X3X205 LENGTH	TATA spare parts
506633904801	SPRING DOWEL	TATA spare parts
506633905101	REBOUND CHAIN	TATA spare parts
506633905108	REBOUND CLIP ASSY	TATA spare parts
506633906701	PIN	TATA spare parts
506633907101	PLATE BS6	TATA spare parts
506633907501	MAIN AIR SPRING BS4	TATA spare parts
506633909204	1 1/8-7 HARDENED WASHER	TATA spare parts
506633909205	ECCENTRIC WASHER FLANGE ASSLY LH	TATA spare parts
506633909206	ECCENTRIC WASHER FLANGE ASSLY RH	TATA spare parts
506633909901	WEAR PAD	TATA spare parts

506633990106	KIT-LIFT AXLE PIPING	TATA spare parts
506633990128	KIT-NYLON PIPES BS6	TATA spare parts
506633990138	PIPE BUNCH ASSY BS6	TATA spare parts
506633990147	PIPE BUNCH ASSY BS6	TATA spare parts
506633990166	PIPE BUNCH ASSY BS6	TATA spare parts
506640100103	WHEEL RIM ASSY BS6	TATA spare parts
506640300104	DIFFERENTIAL PRESSURE SENSOR BS6	TATA spare parts
506641100101	PROPELLER SHAFT ASSY COUPLING-2ND PROP S	TATA spare parts
506641100102	PROPELLER SHAFT ASSY COUPLING-1ST PROP S	TATA spare parts
506641110109	1ST PROPELLER SHAFT ASSY	TATA spare parts
506641110110	2ND PROPELLER SHAFT ASSY	TATA spare parts
506641110111	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
506641110112	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
506641110117	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
506641110118	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
506641120107	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
506641120108	PROPELLER SHAFT ASSY DRIVE-3RD PROP SHAF	TATA spare parts
506641303303	BRACKET ASSY CENTER BRG MTG	TATA spare parts
506641990103	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
506641990104	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
506641990105	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
506643200102	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
506643200104	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
506643200105	AIR TANK ASSY	TATA spare parts
506643200106	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
506643200108	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
506643200109	BRACKET ASSY AIR TANK MTG BS6	TATA spare parts
506643200110	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
506643200111	AIR TANK ASSY	TATA spare parts
506643200113	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
506643200114	BRACKET ASSY. RH	TATA spare parts
506643200115	BRACKET ASSY. LH	TATA spare parts
506643200116	BRACKET ASSY BS6	TATA spare parts
506643200117	BRACKET ASSY BS6	TATA spare parts
506643200118	AIR TANK ASSY	TATA spare parts
506643200120	AIR TANK ASSY	TATA spare parts
506643200121	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
506643208201	BRACKET	TATA spare parts
506643700104	BRACKET	TATA spare parts
506643700105	PRESSURE LIMITING VALVE	TATA spare parts
506643703304	BRACKET	TATA spare parts
506643703305	BRACKET	TATA spare parts
506643703306	BRACKET	TATA spare parts
506643703309	BRACKET RELAY VALVE MTG	TATA spare parts
506643703311	BRACKET	TATA spare parts
506643900101	NYLON PIPE BUNCH ASSY	TATA spare parts
506643900175	METAL PIPE ASSY	TATA spare parts

506643900176	METAL PIPE ASSY	TATA spare parts
506643900201	METAL PIPE ASSY	TATA spare parts
506643900202	METAL PIPE ASSY	TATA spare parts
506643900203	METAL PIPE ASSY	TATA spare parts
506643900204	METAL PIPE ASSY	TATA spare parts
506643900209	METAL PIPE ASSY	TATA spare parts
506643910149	METAL PIPE ASSY	TATA spare parts
506643910150	METAL PIPE ASSY	TATA spare parts
506643910151	METAL PIPE ASSY	TATA spare parts
506643910152	METAL PIPE ASSY	TATA spare parts
506643910154	METAL PIPE ASSY	TATA spare parts
506643910177	NYLON PIPE BUNCH ASSY	TATA spare parts
506646100104	STEERING COLUMN ASSY W/O STEERING WHEEL	TATA spare parts
506646200101	STEERING SPINDLE ASSY	TATA spare parts
506646703302	BRACKET STG GEAR BOX MTG	TATA spare parts
506647600101	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
506647600102	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
506649200103	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
506649200104	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
506649200105	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
506649200106	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
506649203303	BRACKET EXHAUST PIPE SUPPORT	TATA spare parts
506649990103	KIT-EXHAUST HEAT SHIELD	TATA spare parts
506654504901	SWITCH LIFT AXLE FRONT	TATA spare parts
506654504902	SWITCH LIFT AXLE REAR	TATA spare parts
506654600102	WIRING HARNESS TAIL	TATA spare parts
506654600103	WIRING HARNESS FRONT	TATA spare parts
506654600105	WIRING HARNESS MAIN	TATA spare parts
506654600106	PIGTAIL ASSY	TATA spare parts
506654600118	WIRING HARNESS TAIL	TATA spare parts
506654600119	WIRING HARNESS MAIN	TATA spare parts
506654600123	WIRING HARNESS TAIL	TATA spare parts
506654600128	WIRING HARNESS FRONT	TATA spare parts
506658408201	MANUFACTURERS PLATE BS6	TATA spare parts
506724200101	BRACKET ASSY ENGINE MTG REAR-TOP	TATA spare parts
506724200102	BRACKET ASSY ENGINE MTG REAR-TOP	TATA spare parts
506731000102	FRAME ASSY WITH FITMENT	TATA spare parts
506731200102	CROSS MEMBER ASSY PROPELLER SHAFT MTG	TATA spare parts
506731200106	SUPPORT BRACKET ASSY FRONT-RH	TATA spare parts
506741110101	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
506741120101	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
506741303301	BRACKET CENTER BRG MTG	TATA spare parts
506743900102	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
506743900103	METAL PIPE ASSY JOINT 1 TO JOINT 2	TATA spare parts
506743900104	METAL PIPE ASSY JOINT 2 TO JOINT 3	TATA spare parts
506743900107	PIPE BUNCH ASSY	TATA spare parts
506743900121	METAL PIPE ASSY JOINT 3 TO DDU	TATA spare parts

506746800101	SUCTION LINE ASSY	TATA spare parts
506746800103	PRESSURE LINE ASSY	TATA spare parts
506746800104	RETURN LINE ASSY	TATA spare parts
506747600102	SUCTION PIPE ASSY PRE FILTER TO FILTER	TATA spare parts
506747600105	SUCTION PIPE ASSY FUEL TANK TO FILTER	TATA spare parts
506749200101	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
506831000101	FRAME ASSY WITH FITMENT BS6	TATA spare parts
506831000106	FRAME ASSY WITH FITMENT BS6	TATA spare parts
506831200102	CROSS MEMBER ASSY BS6	TATA spare parts
506831200103	CROSS MEMBER ASSY WITH GUSSET BS6	TATA spare parts
506833000101	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
506841100101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
506841120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
506841990101	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
506841990102	SHORT FORK TUBE & REAR END PIECE ASSY BS6	TATA spare parts
506843900101	PIPE BUNCH ASSY BS6	TATA spare parts
506843900125	METAL PIPE ASSY WITH CRIMPED TEFLON HOSE	TATA spare parts
506846305102	RELAY ARM	TATA spare parts
506846305103	PITMAN ARM	TATA spare parts
506846800101	SUCTION LINE ASSY	TATA spare parts
506846800106	SUCTION LINE ASSY BS6	TATA spare parts
506846800107	PRESSURE LINE ASSY BS6	TATA spare parts
506846800108	RETURN LINE ASSY STG GEAR BOX END BS6	TATA spare parts
506846900101	DRAG LINK ASSY FRONT BS6	TATA spare parts
506846900104	DRAG LINK ASSY FRONT BS6	TATA spare parts
506846990103	BALL JOINT ASSY RH	TATA spare parts
506849200108	PRESSURE LINE,SM TO DM BS6	TATA spare parts
506849200109	RETURN LINE,DM TO TANK BS6	TATA spare parts
506849200110	EXHAUST PIPE ASSY SECOND W/ FLEX BELLOW	TATA spare parts
506849200111	EXHAUST PIPE ASSY THIRD BS6	TATA spare parts
506849203302	BRACKET EXHAUST PIPE SUPPORT BS6	TATA spare parts
506854600101	WIRING HARNESS ABS FRAME BS6	TATA spare parts
506854600103	BATTERY CABLE +VE MAXI FUSE O/P TO SM BS	TATA spare parts
506854600105	WIRING HARNESS TAIL BS6	TATA spare parts
506854600107	WIRING HARNESS ABS FRAME BS6	TATA spare parts
50690256000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 2823.K B	TATA spare parts
506929300101	BUNDY TUBE ASSY CMC TO LONG MEMBER BS6	TATA spare parts
506929300102	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
506929300104	CLUTCH BOOSTER ASSY BS6	TATA spare parts
506929300106	MINOR KIT-CLUTCH BOOSTER BS6	TATA spare parts
506929300107	MINOR KIT-CLUTCH BOOSTER BS6	TATA spare parts
506929300110	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
506929303301	BRACKET CLUTCH PIPE MTG BS6	TATA spare parts
506930100101	BRACKET ASSY ACCELERATOR MTG BS6 PH2	TATA spare parts
506931000101	FRAME ASSY WITH FITMENT BS6	TATA spare parts
506931000105	FRAME ASSY WITH FITMENT BS6	TATA spare parts
506931000108	FRAME ASSY WITH FITMENT BS6	TATA spare parts

506931000110	FRAME ASSY WITH FITMENT BS6	TATA spare parts
506931000112	FRAME ASSY WITH FITMENT BS6	TATA spare parts
506931000117	FRAME ASSY WITH FITMENT BS6	TATA spare parts
506931000119	FRAME ASSY WITH FITMENT BS6	TATA spare parts
506931000121	FRAME ASSY WITH FITMENT BS6	TATA spare parts
506931000123	FRAME ASSY WITH FITMENT BS6	TATA spare parts
506931000127	FRAME ASSY WITH FITMENT BS6	TATA spare parts
506931107101	OUTER PIECE RH BS6	TATA spare parts
506931107102	OUTER PIECE RH BS6	TATA spare parts
506931107103	REINFORCEMENT RH BS6	TATA spare parts
506931107104	REINFORCEMENT LH BS6	TATA spare parts
506931200108	CROSSMEMBERASSYWITHGUSSET BS6	TATA spare parts
506931200109	SUPPORT ASSY RADIATOR MTG RH BS6	TATA spare parts
506931200110	SUPPORT ASSY RADIATOR MTG LH BS6	TATA spare parts
506931300106	SUPPORT ASSY ENGINE CROSS MEMBER RH BS6	TATA spare parts
506931300107	SUPPORT ASSY ENGINE CROSS MEMBER LH BS6	TATA spare parts
506931307101	REINFORCEMENT FRONT SPRING BKT FRONT-RH	TATA spare parts
506931307102	REINFORCEMENT FRONT SPRING BKT FRONT-LH	TATA spare parts
506931540105	BATTERY BOX ASSY	TATA spare parts
506931700103	BATTERY BOX ASSY BS6	TATA spare parts
506931900102	BRACKET ASSY RADIATOR GUARD RH BS6	TATA spare parts
506931900103	BRACKET ASSY RADIATOR GUARD LH BS6	TATA spare parts
506931900105	BRACKET ASSY RADIATOR GUARD RH BS6	TATA spare parts
506931900106	BRACKET ASSY RADIATOR GUARD LH BS6	TATA spare parts
506931900107	RADIATOR SHIELD ASSY BS6	TATA spare parts
506932403701	TRUNNION BRACKET BS6	TATA spare parts
506932403704	BRACKET PIVOT MTG BS6	TATA spare parts
506932403705	GUIDE PLATE REAR SPRING BS6	TATA spare parts
506932403706	BRACKET V-ROD MTG BS6	TATA spare parts
506932403707	BRACKET ARTICULATION STOPPER BS6	TATA spare parts
506932403728	BRACKET PIVOT MTG BS6	TATA spare parts
506932404201	U-BOLT REAR BS6	TATA spare parts
506932409201	THRUST WASHER BS6	TATA spare parts
506933000102	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
506933000103	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
506933000105	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
506933000107	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
506933805101	STEERING ARM BS6	TATA spare parts
506941100102	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
506941110101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
506941120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
506941120104	PROPELLER SHAFT ASSY-DRIVE BS6	TATA spare parts
506941120105	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
506941303302	BRACKET CENTER BRG MTG BS6	TATA spare parts
506941990102	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
506941990103	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
506941990105	SHORT FORK BS6	TATA spare parts



506941990106	SHORT FORK TUBE AND FRONT END PIECE BS6	TATA spare parts
506943200108	AIR TANK ASSY BS6	TATA spare parts
506943200113	AIR TANK ASSY BS6	TATA spare parts
506943200114	AIR TANK ASSY 40+40 LTR WITH VOSS FITTIN	TATA spare parts
506943200116	AIR TANK ASSY WITH BKT BS6	TATA spare parts
506943200120	STRAP ASSY (AIR TANK MTG) BS6	TATA spare parts
506943200121	AIR TANK ASSY BS6	TATA spare parts
506943200122	CHANNEL ASSY BS6	TATA spare parts
506943200124	AIR TANK ASSY WITH BKT BS6	TATA spare parts
506943200125	AIR TANK ASSY BS6	TATA spare parts
506943200127	STRAP ASSY AIR TANK MTG BS6-PH2	TATA spare parts
506943700105	SPRING BRAKE ACTUATOR BS6	TATA spare parts
506943700106	SPRING BRAKE ACTUATOR ASSY BS6	TATA spare parts
506943700108	BRACKET ASSY METAL PIPE CLAMP BS6-PH2	TATA spare parts
506943700110	SPRING BRAKE ACTUATOR BS6	TATA spare parts
506943900167	METAL PIPE ASSY BS6	TATA spare parts
506943900172	PIPE BUNCH ASSY BS6	TATA spare parts
506943900177	PIPE BUNCH ASSY BS6	TATA spare parts
506943900193	PIPE BUNCH ASSY BS6	TATA spare parts
506943903302	BRACKET BS6	TATA spare parts
506943903303	BRACKET BS6	TATA spare parts
506943903304	BRACKET BS6	TATA spare parts
506943903305	BRACKET BS6	TATA spare parts
506943907501	GROMMET BS6	TATA spare parts
506943910130	METAL PIPE ASSY BS6	TATA spare parts
506943910131	METAL PIPE ASSY BS6	TATA spare parts
506943910141	PIPE BUNCH ASSY BS6	TATA spare parts
506943910152	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
506943910160	PIPE BUNCH ASSY BS6	TATA spare parts
506943910170	PIPE BUNCH ASSY BS6	TATA spare parts
506945100108	NYLON PIPE BUNCH BS6	TATA spare parts
506946305102	PITMAN ARM BS6	TATA spare parts
506946305103	PITMAN ARM BS6	TATA spare parts
506946800103	PRESSURE LINE ASSY	TATA spare parts
506946800105	SUCTION LINE ASSY BS6	TATA spare parts
506946800106	RETURN LINE ASSY RESERVOIR END BS6	TATA spare parts
506946800107	RETURN LINE ASSY STG GEAR BOX END BS6	TATA spare parts
506946800108	PRESSURE LINE ASSY BS6	TATA spare parts
506946900101	DRAG LINK ASSY BS6	TATA spare parts
506946900103	DRAG LINK ASSY	TATA spare parts
506946900104	DRAG LINK ASSY BS6	TATA spare parts
506947100105	FUEL TANK ASSY W/O TANK UNIT BS6 PH2	TATA spare parts
506947100108	ASSY FUEL TANK W/O TANK UNIT300L RMC BS6	TATA spare parts
506947500101	BRACKET FUEL TANK MTG BS6	TATA spare parts
506947500102	BRACKET FUEL TANK MTG BS6	TATA spare parts
506947500113	BRACKET ASSY BS6	TATA spare parts
506947500117	BRACKET ASSY FUEL TANK MTG BS6	TATA spare parts

506947500118	BRACKET ASSY FUEL TANK MTG BS6-PH2	TATA spare parts
506947507102	REINFORCEMENT BS6	TATA spare parts
506947508202	GUARD BASE FUEL TANK BS6-PH2	TATA spare parts
506947600101	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
506947600102	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
506947600103	RETURN FUEL PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
506947600104	RETURN FUEL PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
506947600105	RETURN FUEL PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
506947600106	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
506947600107	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
506947600108	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
506947600109	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
506947600110	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
506947600111	RET FUEL PIPE ASSY ENG TO FUEL TANK BS6	TATA spare parts
506947600112	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
506947600114	RETURN FUEL PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
506947600115	SUCTION PIPE ASSY FUEL TANK TO FILTER BS	TATA spare parts
506947600117	RETURN FUEL PIPE ASSY BS6	TATA spare parts
506947703302	BRACKET BS6	TATA spare parts
506947703303	BRACKET BS6	TATA spare parts
506949100101	STAY ROD ASSY BS6	TATA spare parts
506949200101	PRESSURE LINE,SM TO DM BS6	TATA spare parts
506949200102	RETURN LINE;DM TO TANK BS6	TATA spare parts
506949200103	BRACKET ASSY BS6	TATA spare parts
506949200105	BASE PLATE EGP MTG BKT ASSY BS6	TATA spare parts
506949200111	BRACKET STAY ROD MTG - BS6	TATA spare parts
506949200113	BRACKET ASSY BS6	TATA spare parts
506949200115	BRACKET ASSY BS6	TATA spare parts
506949200116	STRUCTURE ASSY SILENCER MTG BS6	TATA spare parts
506949200117	STAY ROD ASSY BS6	TATA spare parts
506949200124	BRACKET ASSY TAIL PIPE MTG BS6	TATA spare parts
506949200125	BRACKET ASSY BS6	TATA spare parts
506949200126	RETURN LINE;DM TO TANK BS6	TATA spare parts
506949200127	PRESSURE LINE;SM TO DM BS6	TATA spare parts
506949200130	PRESSURE LINE;SM TO DM BS6	TATA spare parts
506949200135	EXHAUST PIPE ASSY-SECOND BS6	TATA spare parts
506949200144	ARRESTOR RING ASSY BS6	TATA spare parts
506949200146	ARRESTOR RING ASSY BS6	TATA spare parts
506949200148	BRACKET ASSY BS6	TATA spare parts
506949200150	BRACKET ASSY BS6	TATA spare parts
506949200151	BRACKET ASSY BS6	TATA spare parts
506949200152	EXHAUST PIPE ASSY BS6	TATA spare parts
506949200155	BRACKET ASSY BS6	TATA spare parts
506949200159	EXHAUST PIPE ASSY BS6	TATA spare parts
506949200161	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
506949200163	BRACKET ASSY-EXHAUST PIPE SUPPORT BS6	TATA spare parts
506949200168	SUPPORT BRACKET BS6	TATA spare parts

506949200170	TAIL PIPE BS6	TATA spare parts
506949200172	L-BRACKET BS6	TATA spare parts
506949200175	HEAT SHIELD ASSY BS6	TATA spare parts
506949200179	HEAT SHIELD ASSY BS6	TATA spare parts
506949203353	BRACKET BS6	TATA spare parts
506949203356	BRACKET SUPPORT BS6	TATA spare parts
506949207148	PLATE BS6	TATA spare parts
506949207149	PLATE BS6	TATA spare parts
506949208202	BRACKET BS6	TATA spare parts
506949208203	CLAMPING BRACKET PIPE BS6	TATA spare parts
506949208207	HEAT SHILED SILENCER BS6	TATA spare parts
506949208208	HEAT SHILED SILENCER BS6	TATA spare parts
506949208218	HEAT SHIELD SILENCER BS6	TATA spare parts
506949208227	HEAT SHILED SILENCER BS6	TATA spare parts
506949208228	HEAT SHILED SILENCER BS6	TATA spare parts
506949208231	HEAT SHILED SILENCER BS6	TATA spare parts
506949208232	HEAT SHIELD SILENCER BS6	TATA spare parts
506949990105	BELLOW HEAT SHIELD BS6	TATA spare parts
506949990107	HEAT SHIELD ASSY BS6	TATA spare parts
506949990108	HEAT SHIELD ASSY BS6	TATA spare parts
506949990109	KIT-EXHAUST SYSTEM BS6	TATA spare parts
506949990110	KIT-EXHAUST SYSTEM BS6	TATA spare parts
506949990112	KIT-EXHAUST SYSTEM BS6	TATA spare parts
506949990113	KIT-EXHAUST SYSTEM BS6	TATA spare parts
506949990114	KIT-EXHAUST SYSTEM BS6	TATA spare parts
506949990115	KIT-EXHAUST SYSTEM-5.6L SIGNA SLPR CAB	TATA spare parts
506949990116	KIT-EXHAUST SYSTEM-5.6L SIGNA SLPR CAB	TATA spare parts
506949990117	KIT-EXHAUST SYSTEM-5.6L SIGNA SLPR CAB	TATA spare parts
506949990118	KIT-EXHAUST SYSTEM BS6	TATA spare parts
506954400101	BRACKETASSYTAILLAMPCHANNELMTGLH BS6	TATA spare parts
506954400102	BRACKETASSYTAILLAMPCHANNELMTGRH BS6	TATA spare parts
506954400106	BRACKET ASSY TAIL LAMP MTG RH BS6	TATA spare parts
506954400107	BRACKET ASSY TAIL LAMP MTG LH BS6	TATA spare parts
506954400108	BRACKET ASSY;TAIL LAMP MTG;LH BS6	TATA spare parts
506954400109	BRACKET ASSY;TAIL LAMP MTG;RH BS6	TATA spare parts
506954400110	BRACKET ASSY TAIL LAMP MTG LH BS6	TATA spare parts
506954400111	BRACKET ASSY TAIL LAMP MTG RH BS6	TATA spare parts
506954400112	BRACKETASSYTAILLAMPMTGLH BS6	TATA spare parts
506954400113	BRACKETASSYTAILLAMPMTGRH BS6	TATA spare parts
506954400116	BRACKET ASSY TAIL LAMP MTG LH BS6	TATA spare parts
506954400117	BRACKET ASSY TAIL LAMP MTG RH BS6	TATA spare parts
506954400118	BRACKET ASSY TAIL LAMP MTG RH BS6	TATA spare parts
506954400119	BRACKET ASSY TAIL LAMP MTG LH BS6	TATA spare parts
506954400121	BRACKETASSY BS6	TATA spare parts
506954400127	BRACKET ASSY TAIL LAMP MTG LH BS6 PH2	TATA spare parts
506954400128	BRACKET ASSY TAIL LAMP MTG RH BS6 PH2	TATA spare parts
506954400130	DOOR LAMP ASSY BS6-PH2	TATA spare parts

506954504901	POWER SOCKET ASSY WITH CAP BS6	TATA spare parts
506954600101	WIRING HARNESS TAIL BS6	TATA spare parts
506954600103	WIRING HARNESS SCR UNIT BS6	TATA spare parts
506954600106	W/H BATTERY CABLE CUT OFF SW TO MFIP BS6	TATA spare parts
506954600107	WIRING HARNESS TAIL BS6	TATA spare parts
506954600108	WIRING HARNESS TAIL BS6	TATA spare parts
506954600109	WIRING HARNESS SCR UNIT BS6	TATA spare parts
506954600110	WIRING HARNESS ABS FRAME BS6	TATA spare parts
506954600114	WIRING HARNESS TAIL BS6	TATA spare parts
506954600115	WIRING HARNESS SCR UNIT BS6	TATA spare parts
506954600116	WIRING HARNESS ENGINE BS6	TATA spare parts
506954600118	WIRING HARNESS TAIL BS6	TATA spare parts
506954603302	BRACKET ASSY W/H CONNECTOR MTG BS6	TATA spare parts
506954603303	BRACKET ASSY WIRING HARNESS MTG BS6	TATA spare parts
506954603305	BRACKET ASSY WIRING HARNESS MTG BS6	TATA spare parts
506954603306	BRACKET ASSY W/H CONNECTOR MTG BS6-PH2	TATA spare parts
506954603307	BRACKET ASSY W/H CONNECTOR MTG BS6	TATA spare parts
506954603308	BRACKET BS6	TATA spare parts
506954607501	GROMMET BS6	TATA spare parts
506954607502	GROMMETBS6	TATA spare parts
506954607503	GROMMET BS6	TATA spare parts
506954607504	GROMMET BS6	TATA spare parts
506954610104	EARTH CABLE BS6	TATA spare parts
506954630101	WIRING HARNESS TAIL BS6	TATA spare parts
506954630102	WIRING HARNESS ABS FRAME BS6	TATA spare parts
506954630103	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
506954630104	WIRING HARNESS ABS FRAME BS6	TATA spare parts
50695838000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 2823 BS6	TATA spare parts
50696000147RCJ0	SIGNA 2823.K BSVI 39WHD_CAB/COWL	TATA spare parts
50696000152RCJ0	SIGNA 2823.K BSVI 39W_CAB/COWL	TATA spare parts
50697438000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 2823 BS6	TATA spare parts
50697838000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 2823 BS6	TATA spare parts
50699338000RCK	ASSY CABIN KIT W/FITMENT SIGNA 2823.K. F	TATA spare parts
50699538000RCK	CABIN KIT FOR SIGNA 2823.K BS6	TATA spare parts
50700556000RCK	ASSY CABIN KIT W/FITMENTS SIGNA3523.TK B	TATA spare parts
507031000101	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507031000104	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507031000107	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507031000111	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507031000113	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507031200104	CROSS MEMBER ASSY BS6	TATA spare parts
507031200105	CROSS MEMBER ASSY WITH SUPPORT BS6-PH2	TATA spare parts
507031200106	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
507031200107	CROSS MEMBER ASSY WITH GUSSET BS6	TATA spare parts
507031200125	ALLIGATED CROSS MEMBER ASSY BS6	TATA spare parts
507031203301	SUPPORT BRACKET RH BS6	TATA spare parts
507031203302	SUPPORT BRACKET LH BS6	TATA spare parts

507031207105	CROSS MEMBER BS6	TATA spare parts
507031207111	L-PLATE RH BS6	TATA spare parts
507031207112	L-PLATE LH BS6	TATA spare parts
507031700102	BRACKET ASSY GEAR BOX MTG RH BS6	TATA spare parts
507031700103	BRACKET ASSY GEAR BOX MTG LH BS6	TATA spare parts
507033000101	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
507033000102	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
507033000103	FRONT AXLE ASSY WITH BRAKE FRT FWD BS6	TATA spare parts
507033000104	FRONT AXLE ASSY WITH BRAKE FRT RWD BS6	TATA spare parts
507041110102	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
507041120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
507041120105	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
507041303301	BRACKET CENTER BRG MTG BS6	TATA spare parts
507041303303	BRACKET CENTER BRG MTG BS6	TATA spare parts
507041990102	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
507041990108	SHORT FORK TUBE & FRONT END PIECE S	TATA spare parts
507041990109	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
507042100106	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
507042100107	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
507042100109	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
507042100110	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
507042100111	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
507042100112	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
507042100113	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
507042100114	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
507042100146	DRUM BRAKE ASSY WITH DC FRONT-LH BS6 PH2	TATA spare parts
507042100147	DRUM BRAKE ASSY WITH DC FRONT-RH BS6 PH2	TATA spare parts
507042100193	DRUM BRAKE ASSY WITH DC FRONT-LH M/S AAL	TATA spare parts
507042100194	DRUM BRAKE ASSY WITH DC FRONT-RH M/S AAL	TATA spare parts
507042100195	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
507042100196	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
507042108201	ANCHOR BRACKET LH (AUTO. SLACK ADJ.)	TATA spare parts
507042108202	ANCHOR BRACKET (AUTO. SLACK ADJ.)	TATA spare parts
507042108601	SPACER BS6	TATA spare parts
507042300105	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300106	DRUM BRAKE ASSY WITH DC REAR-RH (TVS AF	TATA spare parts
507042300109	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300110	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300113	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300114	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300115	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300116	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300129	DRUM BRAKE ASSY WITH DC REAR-LH (BIL) BS	TATA spare parts
507042300130	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300143	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300144	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300150	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts

507042300151	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300155	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300156	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300160	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300161	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300164	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300165	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300221	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300222	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300225	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300226	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300227	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300228	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300241	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300242	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300243	DRUM BRAKE ASSY WITH DC REAR-LH (AAL) BS	TATA spare parts
507042300244	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300245	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300246	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300247	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300248	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300249	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300250	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300251	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300252	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300253	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300254	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300256	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300257	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300258	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300259	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300267	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300268	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300269	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300270	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300275	DRUM BRAKE ASSY WITH DC REAR-LH BS6 PH2	TATA spare parts
507042300276	DRUM BRAKE ASSY WITH DC REAR-RH BS6 PH2	TATA spare parts
507042300277	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300278	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300279	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300280	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300282	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300283	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
507042300293	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300294	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300296	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
507042300298	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts

507042990105	KIT DUST COVER ASSY BS6	TATA spare parts
507042990108	KIT BUSH BS6	TATA spare parts
507042990111	BRAKE SHOE ASSY WITH LINER BS6	TATA spare parts
507042990114	KIT BUSH BS6	TATA spare parts
507042990119	KIT BUSH BS6	TATA spare parts
507042990123	KIT FULCRUM PIN BS6	TATA spare parts
507042990124	KIT ROLLER BS6	TATA spare parts
507042990128	BRAKE SHOE ASSY WITH LINER REAR BS6	TATA spare parts
507042990138	KIT CAMSHAFT LH BS6	TATA spare parts
507042990139	KIT CAMSHAFT RH BS6	TATA spare parts
507042990144	KIT CAMSHAFT - LH	TATA spare parts
507042990145	KIT CAMSHAFT - RH	TATA spare parts
507042990150	KIT DUST COVER BS6	TATA spare parts
507042990151	BRAKE LINING-410X180 TVS AF 3939 STD BS6	TATA spare parts
507042990152	BRAKE LINING-410X180 TVS AF 3939 OS1 BS6	TATA spare parts
507042990153	BRAKE LINING-410X180 TVS AF 3939 OS2 BS6	TATA spare parts
507042990157	BRAKE LINING-410X180 HC AF 1040G STD BS6	TATA spare parts
507042990158	BRAKE LINING-410X180 HC AF 1040G OS1 BS6	TATA spare parts
507042990159	BRAKE LINING-410X180 HC AF 1040G OS2 BS6	TATA spare parts
507042990170	KIT-BRAKE SHOE & LINER BS6	TATA spare parts
507042990172	KIT LINING SET 410X200 STD BS6	TATA spare parts
507042990173	KIT LINING SET 410X200 OS1 BS6	TATA spare parts
507042990174	KIT LINING SET 410X200 OS2 BS6	TATA spare parts
507042990178	KIT LINING SET 410X220 STD BS6	TATA spare parts
507042990179	KIT LINING SET 410X220 OS1 BS6	TATA spare parts
507042990180	KIT LINING SET 410X220 OS2 BS6	TATA spare parts
507042990184	KIT-TORQUE PLATE ASSY LH	TATA spare parts
507042990185	KIT-TORQUE PLATE ASSY RH	TATA spare parts
507042990193	KIT TORQUE PLATE BS6	TATA spare parts
507042990194	KIT FULCRUM PIN BS6	TATA spare parts
507042990196	KIT ROLLER BS6	TATA spare parts
507042990199	KIT-BRAKE SPRING BS6	TATA spare parts
507042993417	KIT-CAMSHAFT LH BS6-PH2	TATA spare parts
507042993418	KIT-CAMSHAFT RH BS6-PH2	TATA spare parts
507043200102	AIR TANK ASSY WITH BKTS & STRAP BS6	TATA spare parts
507043200114	AIR TANK ASSY WITH BKTS & STRAP BS6-PH2	TATA spare parts
507043700109	ANTI COMPOUNDING RELAY VALVE BS6	TATA spare parts
507043700111	BRACKET-RELAY & MODULATOR VALVE MTG BS6	TATA spare parts
507043900104	METAL PIPE ASSY JOINT TO APU INTAKE	TATA spare parts
507043900107	PIPE BUNCH ASSY BS6	TATA spare parts
507043910107	PIPE BUNCH ASSY BS6	TATA spare parts
507043910147	PIPE BUNCH ASSY BS6	TATA spare parts
507046800101	PRESSURE LINE ASSY BS6	TATA spare parts
507049200105	DIFFUSER BS6	TATA spare parts
507049200108	PIPE ASSY BS6	TATA spare parts
507049200109	CLAMP ASSY PIPE MTG BS6	TATA spare parts
507049200111	EXHAUST PIPE ASSY BS6	TATA spare parts

507049200112	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
507049200114	SPACER UREA TANK MTG BKT BS6	TATA spare parts
507049203301	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
507049203302	BRACKET BS6	TATA spare parts
507049203304	L-BRACKET BS6	TATA spare parts
507049204201	U-BOLT BS6	TATA spare parts
507049204203	CLAMP EXHAUST MTG BS6	TATA spare parts
507049207103	BRACKET SUPPORT BS6	TATA spare parts
507054600101	WIRING HARNESS TAIL BS6	TATA spare parts
507054600107	WIRING HARNESS ENGINE BS6	TATA spare parts
507054600108	PIGTAIL ASSY EMS WIRING HARNESS BS6	TATA spare parts
507054600109	BATTERY CABLE +VE BCS TO MEGA FUSE BS6	TATA spare parts
507054600110	WIRING HARNESS TAIL BS6	TATA spare parts
507054600112	WIRING HARNESS SCR UNIT BS6	TATA spare parts
507054630101	WIRING HARNESS TAIL BS6	TATA spare parts
507054630102	WIRING HARNESS ABS FRAME BS6	TATA spare parts
507124200101	RUBBER MOUNT REAR BS6	TATA spare parts
507131000102	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507131000104	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507131107103	REINFORCEMENT RH BS6	TATA spare parts
507131107104	REINFORCEMENT LH BS6	TATA spare parts
507131107107	SUPPORT PLATE BS6	TATA spare parts
507131540101	BRACKET ASSY BATTERY MTG	TATA spare parts
507131540102	BRACKET ASSY BATTERY MTG	TATA spare parts
507131700102	BRACKET ASSY GEAR BOX MTG LH	TATA spare parts
507131700103	BRACKET ASSY GEAR BOX MTG RH	TATA spare parts
507131990101	KIT-REINFORCEMENT FRAME RETRO 4225.TK BS	TATA spare parts
507141100101	PROPELLER SHAFT ASSY FRONT	TATA spare parts
507141990101	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
507143200101	AIR TANK ASSY WITH BKT	TATA spare parts
507143200102	AIR TANK ASSY BS6	TATA spare parts
507143200105	AIR TANK ASSY BS6	TATA spare parts
507143900143	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507143900164	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
507143900165	METAL PIPE ASSY	TATA spare parts
507143900166	METAL PIPE ASSY	TATA spare parts
507143900167	METAL PIPE ASSY	TATA spare parts
507143900168	METAL PIPE ASSY	TATA spare parts
507143900181	METAL PIPE ASSY	TATA spare parts
507143910109	NYLON PIPE BUNCH ASSY	TATA spare parts
507143910137	NYLON PIPE BUNCH ASSY	TATA spare parts
507147600104	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
507147600105	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
507147600106	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
507149200101	STAY ROD ASSY BS6	TATA spare parts
507149200102	BRACKET STAY ROD MTG BS6	TATA spare parts
507149200105	EXHAUST PIPE ASSY BS6	TATA spare parts



507149200107	BRACKET ASSY BS6	TATA spare parts
507149200108	BRACKET ASSY BS6	TATA spare parts
507154600104	POWER CABLE STARTER TO ALTERNATOR BS6	TATA spare parts
507154600106	WIRING HARNESS ENGINE BS6	TATA spare parts
50720145000RCK	CABIN KIT PRIMA 2830.K BS6 REPTO BS6	TATA spare parts
50720239000RCK	ASSY CABIN KIT W/FITMENTS PRIMA LX 2825	TATA spare parts
507231000105	FRAME ASSY WITH SUSPENSION BRACKET BS6	TATA spare parts
507231540104	BATTERY BOX ASSY BS6	TATA spare parts
507232103301	BRACKET FRONT SPRING LH BS6	TATA spare parts
507232103302	BRACKET FRONT SPRING RH BS6	TATA spare parts
507233000101	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
507233000103	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
507233000106	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
507241120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
507241120102	PROPELLER SHAFT ASSY-DRIVE BS6	TATA spare parts
507241990101	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
507243200101	AIR TANK ASSY BS6	TATA spare parts
507243200102	AIR TANK ASSY WITH BKT BS6	TATA spare parts
507243700109	SPRING BRAKE ACTUATOR KB BS6	TATA spare parts
507243900101	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507243900145	PIPE ASSY BS6	TATA spare parts
507243900150	METAL PIPE ASSY BS6	TATA spare parts
507243900153	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507243900154	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507243900175	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
507243900179	METAL PIPE ASSY BS6	TATA spare parts
507243910114	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507243910168	METAL PIPE ASSY BS6	TATA spare parts
507245903301	BRACKET SOLENOID VALVE MTG BS6	TATA spare parts
507245903302	BRACKET SOLENOID VALVE MTG BS6	TATA spare parts
507246305102	PITMAN ARM BS6	TATA spare parts
507246600103	STEERING GEAR BOX ASSY BS6	TATA spare parts
507246800104	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
507246800105	RETURN LINE ASSY STG GEAR BOX END BS6	TATA spare parts
507246800106	RTN LINE ASSY STG GEAR BOX END BS6-PH2	TATA spare parts
507246800107	PR LINE ASSY STG GEAR BOX END BS6-PH2	TATA spare parts
507246800110	HP LINE ASSY STG GB END BS6-PH2	TATA spare parts
507246800111	RETURN LINE ASSY GB TO INT JOINT BS6-PH2	TATA spare parts
507247600101	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
507247600102	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
507247600103	SUCTION PIPE ASSY FUEL TANK TO FILTER BS	TATA spare parts
507247600105	ASSY. SUCTION PIPE FILTER TO ENG BS6	TATA spare parts
507247600106	ASSY. RETURN PIPE ENG TO FUEL TANK BS6	TATA spare parts
507247600107	RETURN FUEL PIPE ASSY ENG TO FUEL TANK -	TATA spare parts
507247600108	RETURN FUEL PIPE ASSY BS6	TATA spare parts
507247600109	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
507247600110	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts

507247600111	SUCTION PIPE ASSY FUEL TANK TO FILTER BS	TATA spare parts
507249200101	RETURN LINE;DM TO TANK BS6	TATA spare parts
507249200102	RETURN LINE DM TO TANK BS6	TATA spare parts
507249200103	PRESSURE LINE;SM TO DM BS6	TATA spare parts
507249200104	PRESSURE LINE,SM TO DM BS6	TATA spare parts
507254504901	CAN BASED SWITCH ASSY DASHBOARD BS6	TATA spare parts
507254504906	SWITCH RPM DECREMENT DASHBOARD BS6	TATA spare parts
507254504907	SWITCH RPM INCREMENT DASHBOARD BS6	TATA spare parts
507254600102	WIRING HARNESS DASHBOARD BS6	TATA spare parts
507254600103	BRACKET MEGA FUSE MTG BS6	TATA spare parts
507254600104	WIRING HARNESS TAIL BS6	TATA spare parts
507254600105	W/H BATTERY CABLE CUT OFF SW TO MFIP BS6	TATA spare parts
507254600106	WIRING HARNESS ABS FRAME BS6	TATA spare parts
507254600108	WIRING HARNESS TAIL LAMP	TATA spare parts
507254600110	WIRING HARNESS ENGINE BS6	TATA spare parts
507254600116	BATTERY CABLE -VE BS6	TATA spare parts
507254600117	WIRING HARNESS DASHBOARD BS6	TATA spare parts
507254607501	GROMMET	TATA spare parts
507254850101	DMS CAMERA BS6	TATA spare parts
507254850102	DMS CONTROLLER BS6	TATA spare parts
50731339000RCK	CABIN KIT FOR PRIMA 2830.K BS6	TATA spare parts
507329300101	CLUTCH BOOSTER ASSY BS6	TATA spare parts
507331000102	FRAME ASSY WITH SUSPENSION BRACKET BS6	TATA spare parts
507331000111	FRAME ASSY WITH SUSPENSION BRACKET BS6	TATA spare parts
507331000115	FRAME ASSY WITH SUSPENSION BRACKET BS6	TATA spare parts
507331000118	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507331107115	SUPPORT PLATE RH BS6	TATA spare parts
507331107116	SUPPORT PLATE LH BS6	TATA spare parts
507331307101	SUPPORT ENGINE CROSS MEMBER MTG-LH BS6	TATA spare parts
507331307102	SUPPORT ENGINE CROSS MEMBER MTG-RH BS6	TATA spare parts
507331700102	BRACKET ASSY GEAR BOX MTG RH BS6	TATA spare parts
507333000103	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
507341120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
507341120104	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
507341990102	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
507343700113	ANTI ROLL BACK ASSY BS6	TATA spare parts
507343900108	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507343910102	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507345100101	NYLON PIPE BUNCH BS6	TATA spare parts
507345100106	NYLON PIPE BUNCH BS6	TATA spare parts
507346305101	PITMAN ARM BS6	TATA spare parts
507346800101	PRESSURE LINE ASSY BS6	TATA spare parts
507347600101	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
507347600102	SUCTION PIPE ASSY FUEL TANK TO FILTER BS	TATA spare parts
507347600103	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
507349200101	PRESSURE LINE;SM TO DM BS6	TATA spare parts
507349200102	RETURN LINE;DM TO TANK BS6	TATA spare parts

507354630102	WIRING HARNESS ABS FRAME BS6	TATA spare parts
507354630106	WIRING HARNESS TAIL BS6	TATA spare parts
507358600101	BRACKET ASSY SADDLE MTG BS6-PH2	TATA spare parts
507358600102	BRACKET ASSY JACK MTG BS6-PH2	TATA spare parts
507358604003	CLAMP WARNING TRIANGLES BS6-PH2	TATA spare parts
507431000101	FRAME ASSY WITH SUSPENSION BRACKET BS6	TATA spare parts
507431200101	CROSS MEMBER ASSY BS6	TATA spare parts
507431207110	REINFORCEMENT ENG MTG BKT LH BS6	TATA spare parts
507431207111	REINFORCEMENT ENG MTG BKT RH BS6	TATA spare parts
507431540102	BATTERY CARRIER - AIR TANK MTG ASSY BS6	TATA spare parts
507431540103	BRACKET ASSY BATTERY MTG RH BS6	TATA spare parts
507431540104	BRACKET ASSY BATTERY MTG LH BS6	TATA spare parts
507432100102	BRACKET ASSY SPRING HANGER REAR BS6	TATA spare parts
507432100120	PARABOLIC LEAF SPRING ASSY BS6	TATA spare parts
507432100121	PARABOLIC LEAF SPRING ASSY BS6	TATA spare parts
507432100122	1ST LEAF ASSY	TATA spare parts
507432100123	1ST LEAF ASSY BS6	TATA spare parts
507432103711	BRACKET SPRING HANGER FRONT BS6	TATA spare parts
507432107102	CASTER PLATE	TATA spare parts
507432107137	2ND LEAF	TATA spare parts
507432107138	3RD LEAF	TATA spare parts
507432107139	4TH LEAF	TATA spare parts
507432107141	2ND LEAF BS6	TATA spare parts
507432107142	3RD LEAF BS6	TATA spare parts
507432107143	4TH LEAF BS6	TATA spare parts
507432107401	RIVET SPRING CLIP BS6	TATA spare parts
507432307101	BRACKET FRONT SHOCK ABSORBER BS6	TATA spare parts
507433000101	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
507433000102	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
507433000103	FRONT AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
507433000104	FRONT AXLE ASSY WITH BRAKE ABS RWD BS6	TATA spare parts
507441100101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
507441110101	PROPELLER SHAFT ASSY-COUPLING BS6	TATA spare parts
507441120101	PROPELLER SHAFT ASSY BS6	TATA spare parts
507441120102	PROPELLER SHAFT ASSY-DRIVE BS6	TATA spare parts
507441303302	CENTRE BEARING MOUTING BRACKET BS6	TATA spare parts
507441990101	SHORT FORK TUBE& REAR HSG SUB ASSY BS6	TATA spare parts
507441990102	SHORT FORK TUBE & FRONT END PIECE SUB A	TATA spare parts
507443200101	AIR TANK ASSY WITH BKTS & STRAP BS6	TATA spare parts
507443200102	AIR TANK ASSY WITH BKT BS6	TATA spare parts
507443200108	AIR TANK ASSY WITH BKT(PCD 254) BS6	TATA spare parts
507443700102	BRACKET ASSY BS6	TATA spare parts
507443700112	RELAY VALVE & MODULATOR VALVE ASSY BS6	TATA spare parts
507443900103	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507443900165	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507443900178	PIPE ASSY BS6	TATA spare parts
507443900185	NYLON PIPE BUNCH ASSY BS6	TATA spare parts

507446305101	PITMAN ARM BS6	TATA spare parts
507446305102	RELAY ARM BS6	TATA spare parts
507446305104	PITMAN ARM BS6	TATA spare parts
507446800101	RETURN LINE ASSY BS6	TATA spare parts
507446800102	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
507446800103	RETURN LINE ASSY BS6-PH2	TATA spare parts
507446800104	SUCTION LINE ASSY BS6-PH2	TATA spare parts
507446800105	PRESSURE LINE ASSY-STG GEAR BOX END BS6	TATA spare parts
507446800106	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
507447600101	FUEL SUCTION PIPE ASSY FUEL TANK TO FTR	TATA spare parts
507447600102	FUEL SUCTION PIPE ASSY FTR TO ENGINE BS6	TATA spare parts
507447600103	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
507449200102	BRACKET ASSY UREA TANK MTG BS6	TATA spare parts
507449200104	PRESSURE LINE;SM TO DM BS6	TATA spare parts
507449200105	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
507449200106	EXHAUST PIPE ASSY SECOND BS6	TATA spare parts
507449200109	TAIL PIPE BS6	TATA spare parts
507449200110	HEAT SHIELD ASSY BS6	TATA spare parts
507449203305	BRACKET BS6	TATA spare parts
507449208204	HEAT SHILED SILENCER BS6	TATA spare parts
507449208208	HEAT SHIELD SILENCER BS6	TATA spare parts
50750252000RCK	ASSY CABIN KIT W/FITMENTS PRIMA 3530 BS6	TATA spare parts
507531000101	FRAME ASSY WITH SUSPENSION BRACKET BS6	TATA spare parts
507531000104	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507531540105	BRACKET ASSY BATTERY MTG RH BS6-PH2	TATA spare parts
507531540106	BRACKET ASSY BATTERY MTG LH BS6-PH2	TATA spare parts
507532100109	BRACKET ASSY BUMP STOPPER BS6	TATA spare parts
507532307101	BRACKET FRONT SHOCK ABSORBER BS6	TATA spare parts
507532307102	BRACKET FRONT SHOCK ABSORBER BS6	TATA spare parts
507533000101	FRONT AXLE ASSY WITH BRAKE (FRONT FORWAR	TATA spare parts
507533000102	FRONT AXLE ASSY WITH BRAKE ABS (FRONT RE	TATA spare parts
507533000105	FRONT AXLE ASSY WITH BRAKE FRT FWD BS6	TATA spare parts
507533000107	FRONT AXLE ASSY WITH BRAKE ABS FRT FWD B	TATA spare parts
507533400101	FRONT HUB ASSY WITH POLE WHEEL BS6	TATA spare parts
507533805101	STEERING ARM BS6	TATA spare parts
507533805102	STEERING ARM BS6	TATA spare parts
507541100101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
507541120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
507541120103	PROPELLER SHAFT ASSY-DRIVE BS6	TATA spare parts
507541990102	SUB ASSY HEX BOLT WITH WASHER	TATA spare parts
507541990103	SHORT FORK TUBE AND FRONT END PIECE SUB	TATA spare parts
507543200102	AIR TANK ASSY BS6	TATA spare parts
507543900101	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507543900158	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507543900163	METAL PIPE ASSY BS6	TATA spare parts
507543900164	METAL PIPE ASSY BS6	TATA spare parts
507543900165	METAL PIPE ASSY BS6	TATA spare parts

507545100102	NYLON PIPE BUNCH PNEUMATIC SYSTEM BS6	TATA spare parts
507546800101	PRESSURE LINE ASSY STG GB END BS6-PH2	TATA spare parts
507546800102	PRESSURE LINE ASSY STG GB END BS6-PH2	TATA spare parts
507547600101	FUEL SUCTION PIPE ASSY FUEL TANK TO FTR	TATA spare parts
507547600102	FUEL SUCTION PIPE ASSY FTR TO ENGINE BS6	TATA spare parts
507547600103	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
507549200110	PRESSURE LINE,SM TO DM BS6	TATA spare parts
507549200111	RETURN LINE;DM TO TANK BS6	TATA spare parts
507549200114	BASE PLATE EGP MTG BKT ASSY BS6	TATA spare parts
507549200117	BRACKET ASSY STAY ROD MTG BS6	TATA spare parts
507549200119	STRUCTURE ASSY BS6	TATA spare parts
507549200124	BRACKET ASSY TAIL PIPE MTG BS6	TATA spare parts
507549200128	STAY ROD ASSY BS6	TATA spare parts
507549200132	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
507549203305	CLAMPING BRACKET PIPE BS6	TATA spare parts
507549203309	BRACKET EXHAUST PIPE SUPPORT BS6	TATA spare parts
507549203330	BRACKET SUPPORT BS6	TATA spare parts
507549208201	HEAT SHILED SILENCER BS6	TATA spare parts
507554504901	WORK AREA LAMP SWITCH BS6	TATA spare parts
507554504902	SWITCH CABIN ROOF LAMP BS6	TATA spare parts
507554504903	SWITCH MEDIUM MODE BS6	TATA spare parts
507554504905	SWITCH WORK AREA LAMP BS6	TATA spare parts
507554504906	SWITCH POWER TAKE OFF BS6	TATA spare parts
507554504907	SWITCH INTERAXLE DIFF LOCK BS6	TATA spare parts
507554504908	STEERING WHEEL ADJUSTMENT SWITCH BS6	TATA spare parts
507554504910	SWITCH INTER WHEEL DIFF LOCK BS6	TATA spare parts
507554600106	WIRING HARNESS TAIL BS6	TATA spare parts
507554600108	BATTERY CABLE -VE BS6	TATA spare parts
507554600109	BATTERY CABLE +VE MEGA FUSE O/P TO SM BS	TATA spare parts
507554609901	STICKER-FUSE BOX BS6	TATA spare parts
507554640101	BATTERY CABLE LINK BS6	TATA spare parts
507554720105	BRACKET ASSY BS6	TATA spare parts
507554728206	BRACKET SENSOR MTG BS6	TATA spare parts
507631000103	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507631000105	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507631200104	BRACKET SUPPORT ASSY RH	TATA spare parts
507631200105	BRACKET SUPPORT ASSY LH	TATA spare parts
507631200106	END CROSS MEMBER ASSY WITH GUSSET BS6	TATA spare parts
507631200107	SUPPORT ASSY WITH SPACER	TATA spare parts
507631200108	SUPPORT ASSY WITH SPACER	TATA spare parts
507631200109	CROSS MEMBER BS6	TATA spare parts
507631207116	END CROSS MEMBER BS6	TATA spare parts
507631307108	GUSSET BOTTOM RH BS6	TATA spare parts
507631307109	GUSSET BOTTOM-LH BS6	TATA spare parts
507631307110	GUSSET RH BS6	TATA spare parts
507631307111	GUSSET LH BS6	TATA spare parts
507631307112	GUSSET BOTTOM RH BS6	TATA spare parts

507631307113	GUSSET BOTTOM-LH BS6	TATA spare parts
507631307114	SUPPORT TOP RH BS6	TATA spare parts
507631307115	SUPPORT TOP LH BS6	TATA spare parts
507631307116	SUPPORT PLATE CROSS MEMBER MTG BS6	TATA spare parts
507643200101	AIR TANK ASSY BS6	TATA spare parts
507643200102	CHANNEL ASSY BS6	TATA spare parts
507643200103	AIR TANK ASSY BS6	TATA spare parts
507643900107	PIPE BUNCH ASSY BS6	TATA spare parts
507643900126	CLAMP ASSY BS6	TATA spare parts
507643900128	METAL PIPE ASSY BS6	TATA spare parts
507643900129	METAL PIPE ASSY BS6	TATA spare parts
507643900130	METAL PIPE ASSY APU TO JOINT BS6	TATA spare parts
507645100102	NYLON PIPE BUNCH BS6	TATA spare parts
507654600101	WIRING HARNESS TAIL BS6	TATA spare parts
507726800101	TURNING TUBE ASSY BS6	TATA spare parts
507726803701	BRACKET GEAR SHIFT LEVER MTG BS6	TATA spare parts
507726809901	GEAR SHIFT LEVER BS6	TATA spare parts
50790152000RCK	CABIN KIT W/FITMENTS SIGNA 3518.S AC BS6	TATA spare parts
50790156000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 3518.T B	TATA spare parts
50791156000RCK	ASSY COWL KIT W/FITMENTS LPT 3518 BS6	TATA spare parts
507931000107	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507931000111	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507931000115	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507931000119	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507931000120	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507931000126	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507931000131	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507931000133	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507931000135	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507931000138	FRAME ASSY WITH FITMENT BS6	TATA spare parts
507931107116	REINFORCEMENT RH BS6	TATA spare parts
507931107117	REINFORCEMENT LH BS6	TATA spare parts
507931107118	REINFORCEMENT RH BS6	TATA spare parts
507931107119	REINFORCEMENT LH BS6	TATA spare parts
507931200101	BRACKET ASSY RAIDATOR MTG RH BS6	TATA spare parts
507931200102	BRACKET ASSY RAIDATOR MTG LH BS6	TATA spare parts
507931200110	CROSS MEMBER ASSY CENTER BEARING MTG BS6	TATA spare parts
507931200115	SUPPORT ASSY ENGINE CROSS MEMBER RH BS6	TATA spare parts
507931200116	SUPPORT ASSY ENGINE CROSS MEMBER LH BS6	TATA spare parts
507931200117	CROSS MEMBER ASSY ENGINE BS6	TATA spare parts
507931300110	REINFORCEMENT ASSY BUMPER CROSS MEMBER	TATA spare parts
507931300112	REINFORCEMENT ASSY BUMPER CROSS MEMBER	TATA spare parts
507931307120	GUSSET CROSS MEMBER TOP-RH BS6	TATA spare parts
507931307121	GUSSET CROSS MEMBER TOP-LH BS6	TATA spare parts
507931307123	GUSSET CROSS MEMBER BOTTOM-RH BS6	TATA spare parts
507931307124	GUSSET CROSS MEMBER BOTTOM-LH BS6	TATA spare parts
507931307130	REINFORCEMENT BUMPER CROSS MEMBER RH B	TATA spare parts

507931307131	REINFORCEMENT BUMPER CROSS MEMBER LH BS6	TATA spare parts
507931307132	L-REINFORCEMENT TOP-RH BS6	TATA spare parts
507931307133	L-REINFORCEMENT TOP-LH BS6	TATA spare parts
507931700120	SUPPORT ASSY RADIATOR MTG RH BS6	TATA spare parts
507931700121	SUPPORT ASSY RADIATOR MTG LH BS6	TATA spare parts
507933000102	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
507933400102	TAPER ROLLER BEARING INNER 6.5T PII BS6	TATA spare parts
507933900125	NYLON PIPE ASSY LACV TO QRV BS6	TATA spare parts
507933900170	PIPE BUNCH ASSY BS6	TATA spare parts
507933900177	KIT-NYLON PIPES BS6	TATA spare parts
507933990110	KIT-LIFT AXLE PIPING BS6	TATA spare parts
507933990118	KIT-LIFT AXLE PIPING BS6	TATA spare parts
507933990122	KIT-LIFT AXLE PIPING BS6	TATA spare parts
507941100101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
507941100102	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
507941110102	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
507941110103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
507941110104	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
507941110105	SHORT FORK TUBE BS6	TATA spare parts
507941110106	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
507941120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
507941120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
507941303301	BRACKET CENTER BRG MTG BS6	TATA spare parts
507941990101	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
507941990102	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
507941990103	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
507941990104	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
507941990105	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
507943200111	AIR TANK ASSY WITH BKTS & STRAP BS6-PH2	TATA spare parts
507943700116	BRACKET ASSY	TATA spare parts
507943700117	BRACKET ASSY BS6	TATA spare parts
507943700118	AIR TANK ASSY BS6	TATA spare parts
507943700150	MODULATOR VALVE ESP BS6	TATA spare parts
507943700154	BRACKET ASSY BS6-PH2	TATA spare parts
507943703305	BRACKET	TATA spare parts
507943900102	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507943900114	PIPE ASSY	TATA spare parts
507943900115	PIPE ASSY	TATA spare parts
507943900133	METAL PIPE ASSY BS6	TATA spare parts
507943900134	METAL PIPE ASSY BS6	TATA spare parts
507943900135	METAL PIPE ASSY BS6	TATA spare parts
507943900137	METAL PIPE ASSY BS6	TATA spare parts
507943900138	METAL PIPE ASSY BS6	TATA spare parts
507943910101	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507943910130	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507943910150	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
507943920102	NYLON PIPE BUNCH ASSY BS6	TATA spare parts

507943920143	PIPE BUNCH ASSY BS6	TATA spare parts
507946305101	PITMAN ARM BS6	TATA spare parts
507946900101	DRAG LINK ASSY FRONT BS6	TATA spare parts
507946900102	DRAG LINK ASSY FRONT BS6	TATA spare parts
507947100102	FUEL TANK ASSY W/O TANK UNIT BS6	TATA spare parts
507947600101	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
507947600102	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
507947600103	SUCTION FUEL PIPE FUEL TANK TO W/SEP BS6	TATA spare parts
507947600105	FUEL PIPE ASSY FUEL TANK INTERCONNECTION	TATA spare parts
507947600106	PIPE ASSY TANK TO INT JOINT BS6	TATA spare parts
507947600108	FUEL PIPE ASSY FUEL TANK INTERCONNECTION	TATA spare parts
507947603301	CLAMP BRACKET BS6	TATA spare parts
507947603303	REINFORCEMENT BS6	TATA spare parts
507947608201	CLAMP BS6	TATA spare parts
507949200102	SUCTION LINE;TANK TO SM BS6	TATA spare parts
507949200105	BRACKET ASSY UREA TANK MTG BS6	TATA spare parts
507949200106	CLAMP ASSY EGP MTG BS6	TATA spare parts
507949200107	BRACKET ASSY EGP MTG BS6	TATA spare parts
507949200108	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
507949200109	DEF TANK ASSY BS6	TATA spare parts
507949200112	RETURN LINE;DM TO TANK BS6	TATA spare parts
507949200113	PRESSURE LINE,SM TO DM BS6	TATA spare parts
507949200115	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
507949200116	BRACKET ASSY UREA TANK MTG BS6	TATA spare parts
507949200118	STRAP ASSY UREA TANK MTG BS6	TATA spare parts
507949200122	BRACKET ASSY UREA TANK MTG LH BS6	TATA spare parts
507949200123	BRACKET ASSY UREA TANK MTG RH BS6	TATA spare parts
507949200124	STRAP ASSY UREA TANK MTG BS6	TATA spare parts
507949200125	STRAP ASSY UREA TANK MTG BS6	TATA spare parts
507949200126	BRACKET ASSY BS6	TATA spare parts
507949200133	PRESSURE LINE;SM TO DM BS6	TATA spare parts
507949200137	DEF TANK - FILTER NECK BS6	TATA spare parts
507949200138	DEF TANK - PLASTIC CAP WITH LOCK BS6	TATA spare parts
507949200140	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
507949200142	HEAT SHIELD ASSY BS6	TATA spare parts
507949200148	BRACKET ASSY DEF TANK MTG BS6	TATA spare parts
507949200152	STRAP ASSY DEF TANK MTG BS6	TATA spare parts
507949200158	SUPPORT BRACKET SUPPLY UNIT MTG LH BS6	TATA spare parts
507949200186	BRACKET ASSY UREA TANK MTG BS6-PH2	TATA spare parts
507949200197	BREATHER ASSY BS6-PH2	TATA spare parts
507949200198	BREATHER ASSEMBLY BS6-PH2	TATA spare parts
507949203303	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
507949203304	BRACKET TAIL PIPE BS6	TATA spare parts
507949203308	L-BRACKET EXHAUST MTG BS6	TATA spare parts
507949203312	BRACKET BS6	TATA spare parts
507949203317	BRACKET BS6	TATA spare parts
507949203318	BRACKET TAIL PIPE BS6	TATA spare parts



507949203320	BRACKET TAIL PIPE BS6	TATA spare parts
507949203342	BRACKET BS6	TATA spare parts
507949203357	BRACKET SUPPORT BS6-PH2	TATA spare parts
507949204201	CLAMP EGP MTG BS6	TATA spare parts
507949204202	CLAMP	TATA spare parts
507949204203	DRAIN PLUG BS6	TATA spare parts
507949204204	CLAMP BS6	TATA spare parts
507949204205	CLAMP BS6	TATA spare parts
507949204206	CLAMP BS6	TATA spare parts
507949204207	CLAMP BS6	TATA spare parts
507949204208	CLAMP BS6 PH2	TATA spare parts
507949207702	RUBBER PACKING BS6	TATA spare parts
507949207704	RUBBER PACKING BS6	TATA spare parts
507949207709	DEF TANK - GASKET (RETAINER) BS6	TATA spare parts
507949207802	O-RING BS6-PH2	TATA spare parts
507949208201	BASE PLATE UREA TANK BS6	TATA spare parts
507949208231	COVER BS6	TATA spare parts
507949990128	KIT-EXHAUST SHIELD BS6	TATA spare parts
507954400101	HEADLAMP LH BS6	TATA spare parts
507954400102	HEADLAMP RH BS6	TATA spare parts
507954400103	HEADLAMP LH BS6	TATA spare parts
507954400104	HEADLAMP RH BS6	TATA spare parts
507954600102	WIRING HARNESS SCR UNIT BS6	TATA spare parts
507954600103	WIRING HARNESS ENGINE BS6	TATA spare parts
507954600105	WIRING HARNESS STOP LIGHT SWITCH BS6	TATA spare parts
507954600106	WIRING HARNESS MAIN BS6	TATA spare parts
507954600113	WIRING HARNESS TAIL BS6	TATA spare parts
507954600114	WIRING HARNESS ABS FRAME BS6	TATA spare parts
507954600116	BATTERY CABLE -VE BS6	TATA spare parts
507954600117	BATTERY CABLE +VE	TATA spare parts
507954600123	WIRING HARNESS TAIL BS6	TATA spare parts
507954600126	WIRING HARNESS ABS FRAME BS6	TATA spare parts
507954600128	WIRING HARNESS TAIL BS6	TATA spare parts
507954600132	WIRING HARNESS SCR UNIT BS6	TATA spare parts
507954600137	WIRING HARNESS TAIL BS6	TATA spare parts
507954610102	WIRING HARNESS MAIN BS6	TATA spare parts
507954630101	WIRING HARNESS ABS FRAME BS6	TATA spare parts
507954630102	WIRING HARNESS SCR UNIT BS6	TATA spare parts
507954630103	WIRING HARNESS TAIL BS6	TATA spare parts
507954630104	WIRING HARNESS ABS FRAME BS6	TATA spare parts
507954630105	WIRING HARNESS SCR UNIT BS6	TATA spare parts
507954630106	WIRING HARNESS TAIL BS6	TATA spare parts
507954630108	WIRING HARNESS TAIL BS6	TATA spare parts
507954630109	WIRING HARNESS ABS FRAME BS6	TATA spare parts
507954690101	BRACKET ASSY BS6	TATA spare parts
507954700101	BRACKET ASSY BS6-PH2	TATA spare parts
50800633000RCK	ASSY CABIN KIT W/FITMENT SIGNA 4623.S BS	TATA spare parts

50801133000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 4625.S B	TATA spare parts
50801233000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 4625.S B	TATA spare parts
50801633000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 4625.S B	TATA spare parts
50801733000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 4625.S B	TATA spare parts
508031000103	ASSY. FRAME 4623.S (CAST 6 HOLE BRKT)BS4	TATA spare parts
50803100010304	ASSY FRAME 4623.S(FAB 4 HOLE BRKT)BS3/4	TATA spare parts
50803100010306	ASSY FRAME (CAST TYPE 6 HOLE BRKT)	TATA spare parts
508031000106	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508031000109	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508031000110	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508031000111	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508031000113	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508031000115	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508031000119	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508031107101	REINFORCEMENT MIDDLE-BOTTOM-RH BS6	TATA spare parts
508031107102	REINFORCEMENT MIDDLE-BOTTOM-LH BS6	TATA spare parts
508031107107	L-REINFORCEMENT TOP-RH BS6	TATA spare parts
508031107108	L-REINFORCEMENT TOP-LH BS6	TATA spare parts
508031107115	LONG MEMBER RH BS6	TATA spare parts
508031107116	LONG MEMBER LH BS6	TATA spare parts
508031107117	REINFORCEMENT MIDDLE-RH BS6	TATA spare parts
508031107118	REINFORCEMENT MIDDLE-LH BS6	TATA spare parts
508031107119	REINFORCEMENT MIDDLE-RH BS6	TATA spare parts
508031107120	REINFORCEMENT MIDDLE-LH BS6	TATA spare parts
508031107124	REINFORCEMENT MIDDLE-BOTTOM-RH BS6	TATA spare parts
508031107125	REINFORCEMENT MIDDLE-BOTTOM-LH BS6	TATA spare parts
508031107126	L-REINFORCEMENT BOTTOM-RH BS6	TATA spare parts
508031107127	L-REINFORCEMENT BOTTOM-LH BS6	TATA spare parts
508031107146	L-REINFORCEMENT BOTTOM-LH BS6	TATA spare parts
508031107147	L-REINFORCEMENT BOTTOM-RH BS6	TATA spare parts
508031200103	BRACKET ASSY LH	TATA spare parts
508031200104	BRACKET ASSY RH	TATA spare parts
508031200105	CROSS MEMBER ASSY BS6	TATA spare parts
508031200106	CROSS MEMBER ASSY TUBULAR BS6	TATA spare parts
508031200107	REINFORCEMENT ASSY LH BS6	TATA spare parts
508031200108	REINFORCEMENT ASSY RH BS6	TATA spare parts
508031207103	SPACER PLATE BS6	TATA spare parts
508031207108	SPACER PLATE BS6	TATA spare parts
508031207109	SPACER PLATE BS6	TATA spare parts
508031207110	SPACER PLATE BS6	TATA spare parts
508031307107	SPACER PLATE BS6	TATA spare parts
508031307110	SPACER PLATE BS6-PH2	TATA spare parts
508031407103	REINFORCEMENT BUMP STOPPER BS6	TATA spare parts
508032400102	REAR SPRING ASSY BS6	TATA spare parts
508032400103	REAR SPRING ASSY BS6	TATA spare parts
508032400105	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
508032400107	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts

508032403202	CLAMP BOLT BS6	TATA spare parts
508032403204	CENTER BOLT BS6	TATA spare parts
508032403205	CLAMP BOLT BS6	TATA spare parts
508032403206	CLAMP BOLT BS6	TATA spare parts
508032403207	CLAMP BOLT BS6-PH2	TATA spare parts
508032404201	CLAMP - J TYPE BS6	TATA spare parts
508032404202	CLAMP SMALL BS6	TATA spare parts
508032404204	CLAMP BS6	TATA spare parts
508032404205	CLAMP BIG BS6	TATA spare parts
508032404206	CLAMP SMALL BS6	TATA spare parts
508032404209	CLAMP BIG BS6	TATA spare parts
508032406502	HEX NUT BS6	TATA spare parts
508032406503	HEX NUT BS6	TATA spare parts
508032406902	FERRULE BS6	TATA spare parts
508032406903	SPACER TUBE BS6-PH2	TATA spare parts
508032407103	3RD LEAF BS6	TATA spare parts
508032407104	4TH LEAF BS6	TATA spare parts
508032407105	5TH LEAF BS6	TATA spare parts
508032407106	6TH LEAF BS6	TATA spare parts
508032407107	7TH LEAF BS6	TATA spare parts
508032407108	8TH LEAF BS6	TATA spare parts
508032407109	9TH LEAF BS6	TATA spare parts
508032407110	10TH LEAF BS6	TATA spare parts
508032407111	1ST LEAF AUX SPRING BS6	TATA spare parts
508032407112	2ND LEAF AUX SPRING BS6	TATA spare parts
508032407113	3RD LEAF AUX SPRING BS6	TATA spare parts
508032407114	PACKING PLATE BS6-PH2	TATA spare parts
508032407115	1ST LEAF BS6-PH2	TATA spare parts
508032407116	2ND LEAF BS6	TATA spare parts
508032407117	3RD LEAF BS6	TATA spare parts
508032407118	4TH LEAF BS6	TATA spare parts
508032407119	5TH LEAF BS6	TATA spare parts
508032407120	6TH LEAF BS6	TATA spare parts
508032407121	7TH LEAF BS6	TATA spare parts
508032407122	8TH LEAF BS6	TATA spare parts
508032407123	9TH LEAF BS6	TATA spare parts
508032407125	10TH LEAF BS6	TATA spare parts
508032407126	1ST LEAF AUX SPRING BS6	TATA spare parts
508032407127	2ND LEAF AUX SPRING BS6	TATA spare parts
508032407128	3RD LEAF AUX SPRING BS6	TATA spare parts
508032407129	PACKING PLATE BS6	TATA spare parts
508032407130	1ST LEAF BS6-PH2	TATA spare parts
508032407131	2ND LEAF BS6	TATA spare parts
508032407401	RIVET BS6	TATA spare parts
508032407402	RIVET BS6	TATA spare parts
508032408601	CENTER PAD BS6	TATA spare parts
508032408602	CENTER PAD BS6	TATA spare parts

508033000101	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
508034200103	L-PLATE LH BS6	TATA spare parts
508034200104	L-PLATE RH BS6	TATA spare parts
508041110101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508041120101	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
508041120102	ASSY PROPEELER SHAFT	TATA spare parts
508041120106	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508041120108	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
508041990102	SHORT FORK TUBE ASSY	TATA spare parts
508041990105	SHORT FORK TUBE ASSY BS6	TATA spare parts
508041990106	LONG FORK ASSY	TATA spare parts
508041990107	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
508042100111	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
508042100112	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
508042100119	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
508042100120	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
508042100127	DRUM BRAKE ASSY WITH DC FRONT-LH M/S BIL	TATA spare parts
508042100128	DRUM BRAKE ASSY WITH DC FRONT-RH M/S BIL	TATA spare parts
508042100129	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
508042100130	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
508042100135	KIT LINED SHOE ASSY BS6	TATA spare parts
508042100147	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
508042100148	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
508042100149	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
508042100150	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
508042103701	BRACKET ACTUATOR MOUNTING-LH	TATA spare parts
508042103702	BRACKET ACTUATOR MOUNTING-LH	TATA spare parts
508042109901	POLE WHEEL FRONT BS6	TATA spare parts
508042300107	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300108	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300123	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
508042300124	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
508042300127	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300128	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300129	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300130	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300131	DRUM BRAKE ASSY WITH DC REAR-LH (TVS AF	TATA spare parts
508042300132	DRUM BRAKE ASSY WITH DC REAR-RH (TVS AF	TATA spare parts
508042300133	DRUM BRAKE ASSY WITH DC REAR-LH (HC AF 1	TATA spare parts
508042300134	DRUM BRAKE ASSY WITH DC REAR-RH (HC AF 1	TATA spare parts
508042300135	KIT LINED SHOE ASSY (NON-CAPTIVE ROOLER)	TATA spare parts
508042300145	DRUM BRAKE ASSY WITH DC REAR-LH BS6 PH2	TATA spare parts
508042300146	DRUM BRAKE ASSY WITH DC REAR-RH BS6 PH2	TATA spare parts
508042300149	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300150	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300151	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300152	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts

508042300153	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300154	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300155	DRUM RAKE ASSY WITH DC REAR-LH (AAL) BS6	TATA spare parts
508042300156	DRUM BRAKE ASSY WITH DC REAR-RH (AAL) BS	TATA spare parts
508042300157	DRUM BRAKE ASSY WITH DC REAR-LH BS6 PH2	TATA spare parts
508042300158	DRUM BRAKE ASSY WITH DC REAR-RH BS6 PH2	TATA spare parts
508042300159	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300160	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300161	DRUM BRAKE ASSY WITH DC REAR-LH (HC AF 1	TATA spare parts
508042300162	DRUM BRAKE ASSY WITH DC REAR-RH (HC AF 1	TATA spare parts
508042300163	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300164	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300169	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300170	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
508042300171	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300172	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300175	DRUM BRAKE ASSY WITH DC REAR-LH (TVS AF	TATA spare parts
508042300176	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
508042300177	DRUM BRAKE ASSY WITH DC REAR-LH BS6 PH2	TATA spare parts
508042300178	DRUM BRAKE ASSY WITH DC REAR-RH BS6 PH2	TATA spare parts
508042300181	DRUM BRAKE ASSY WITH DC RR-LH (BIL) BS6	TATA spare parts
508042300182	DRUM BRAKE ASSY WITH DC RR-RH (BIL) BS6	TATA spare parts
508042300183	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300184	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300185	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300186	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300197	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300198	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300201	DRUM BRAKE ASSY WITH DC REAR-RH (TVS AF	TATA spare parts
508042300202	DRUM BRAKE ASSY WITH DC REAR-RH (HC AF 1	TATA spare parts
508042300213	DRUM BRAKE ASSY WITH DC REAR-RH (AAL) BS	TATA spare parts
508042300214	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300215	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300216	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300219	DRUM BRAKE ASSY WITH DC REAR-LH (TVS AF	TATA spare parts
508042300220	DRUM BRAKE ASSY WITH DC REAR-LH (HC AF 1	TATA spare parts
508042300225	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300226	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300239	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
508042300240	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
508042300252	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300253	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300254	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300255	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300266	DRUM BRAKE ASSY WITH DC REAR-LH (AAL ) B	TATA spare parts
508042300267	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300268	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts

508042300269	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300270	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300271	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300272	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
508042300273	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
508042300278	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300279	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300290	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300291	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300292	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300293	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042300295	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
508042300296	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508042300297	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508042303701	BRAKE DRUM BS6	TATA spare parts
508042310106	DRUM BRAKE ASSY WITH DC REAR-LH (BIL) BS	TATA spare parts
508042310107	DRUM BRAKE ASSY WITH DC REAR-RH (BIL) BS	TATA spare parts
508042310209	DRUM BRAKE ASSY WITH DC REAR-LH BS6 PH2	TATA spare parts
508042310210	DRUM BRAKE ASSY WITH DC REAR-RH BS6 PH2	TATA spare parts
508042990102	KIT-CAMSHAFT LH BS6	TATA spare parts
508042990104	KIT-CAMSHAFT RH BS6	TATA spare parts
508042990120	MINOR KIT-AUTO ADJUSTER ASSY BS6-PH2	TATA spare parts
508042990135	KIT- DUST COVER BS6	TATA spare parts
508042990139	KIT-BRAKE LINED SHOE (TVS AF 3939) BS6	TATA spare parts
508042990140	MAJOR KIT-AUTO ADJUSTER ASSY BS6-PH2	TATA spare parts
508042990146	KIT-BRAKE (HC AF 1040G) BS6	TATA spare parts
508042990147	BRAKE SHOE ASSY WITH LINER BS6	TATA spare parts
508042990150	KIT-AUTO SLACK ADJUSTER MINOR BS6-PH2	TATA spare parts
508042990151	KIT-AUTO SLACK ADJUSTER MAJOR BS6-PH2	TATA spare parts
508042990154	BRAKE LINING AF1040 BS6-PH2	TATA spare parts
508042990156	PLUMMER BLOCK ASSY BS6	TATA spare parts
508042990159	KIT-BRAKE SHOE & LINER BS6	TATA spare parts
508042990160	KIT-BRAKE SHOE & LINER BS6-PH2	TATA spare parts
508042990161	WASHER BS6	TATA spare parts
508042993402	KIT-CAMSHAFT LH BS6	TATA spare parts
508042993403	KIT-CAMSHAFT RH BS6	TATA spare parts
508042993404	SPIDER ASSY WTH BUSH & SEAL LH BS6	TATA spare parts
508042993405	SPIDER ASSY WTH BUSH & SEAL RH BS6	TATA spare parts
508042993406	KIT-CAMSHAFT LH BS6-PH2	TATA spare parts
508042993407	KIT-CAMSHAFT RH BS6-PH2	TATA spare parts
508042993408	KIT-CAMSHAFT LH BS6-PH2	TATA spare parts
508042993409	KIT-CAMSHAFT RH BS6-PH2	TATA spare parts
508043200101	AIR TANK ASSY BS6	TATA spare parts
508043200104	AIR TANK ASSY WITH BKT	TATA spare parts
508043700117	AIR TANK ASSY BS6	TATA spare parts
508043700138	HBV WITH TRAILER CHECK BS6	TATA spare parts
508043700139	BRACKET ASSY BS6	TATA spare parts

508043900103	BUNCH ASSY PIPE BS6	TATA spare parts
508043900130	METAL PIPE ASSY BS6	TATA spare parts
508043900131	METAL PIPE ASSY BS6	TATA spare parts
508043900134	PIPE BUNCH ASSY	TATA spare parts
508043900144	BUNCH ASSY PIPE BS6	TATA spare parts
508043900168	BUNCH PIPE ASSY BS6	TATA spare parts
508043900196	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
508043910110	BUNCH ASSY PIPE BS6	TATA spare parts
508043910111	METAL PIPE ASSY BS6	TATA spare parts
508043910113	BUNCH ASSY PIPE BS6	TATA spare parts
508043910158	BUNCH ASSY-PIPE BS6	TATA spare parts
508046600101	RELIEF VALVE ASSY	TATA spare parts
508046800111	PRESSURE LINE ASSY BS6	TATA spare parts
508047100102	FUEL TANK ASSY W/O TANK UNIT BS6	TATA spare parts
508047109901	CONNECTOR BS6	TATA spare parts
508047500101	BUSH FUEL TANK MTG BRACKET BS6	TATA spare parts
508047500102	BRACKET FUEL TANK MTG BS6	TATA spare parts
508047500103	BRACKET ASSY WITH SUPPORT BS6	TATA spare parts
508047600101	FUEL PIPE ASSY FUEL TANK INTERCONNECTION	TATA spare parts
508047600102	FUEL PIPE ASSY FUEL TANK INTERCONNECTION	TATA spare parts
508047600103	FUEL SUCTION PIPE ASSY-TANK TO W/SEP BS6	TATA spare parts
508047600104	FUEL SUCTION PIPE ASSY-FTR TO ENGINE BS6	TATA spare parts
508047600105	FUEL RETURN PIPE ASSY-ENG TO FUEL TANK B	TATA spare parts
508047600106	FUEL SUCTION PIPE ASSY FUEL TANK TO FTR	TATA spare parts
508047600107	FUEL SUCTION PIPE ASSY FTR TO ENGINE BS6	TATA spare parts
508047600108	FUEL RTN PIPE ASSY ENG TO FUEL TANK BS6-	TATA spare parts
508047703301	BRACKET BS6-PH2	TATA spare parts
508049200101	RETURN LINE;DM TO TANK BS6	TATA spare parts
508049200102	BRACKET ASSY EGP MTG REAR	TATA spare parts
508049200103	PRESSURE LINE;SM TO DM BS6	TATA spare parts
508049200105	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
508049200108	BRACKET ASSY EGP MTG BS6	TATA spare parts
508049200109	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
508049200111	BRACKET ASSY EGP MTG BS6	TATA spare parts
508049200113	BRACKET ASSY EGP MTG REAR BS6	TATA spare parts
508049203305	BRACKET TAIL PIPE MTG BS6	TATA spare parts
508049203307	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
508049203335	BRACKET SUPPORT BS6-PH2	TATA spare parts
508049204201	CLAMP BS6	TATA spare parts
508049207101	SPACER PLATE BS6	TATA spare parts
508049605312	HEAT SHIELD ASSY BS6	TATA spare parts
508049990106	KIT-EXHAUST HEAT SHIELD BS6	TATA spare parts
508049990113	HEAT SHIELD ASSY BS6	TATA spare parts
508054600105	WIRING HARNESS TAIL BS6	TATA spare parts
508054600107	WIRING HARNESS ABS FRAME BS6	TATA spare parts
508054600110	BATTERY CABLE -VE BS6	TATA spare parts
508054600118	WIRING HARNESS ROOF BS6	TATA spare parts

508054610101	BRACKET ASSY FUSE BOX MTG BS6-PH2	TATA spare parts
508054610102	BRACKET ASSY DIAGNOSTIC CONN MTG BS6-PH2	TATA spare parts
508054610112	WIRING HARNESS MAIN BS6	TATA spare parts
508054610118	WIRING HARNESS MAIN BS6	TATA spare parts
508054610119	WIRING HARNESS MAIN BS6	TATA spare parts
508054610123	PIGTAIL VEHICLE TRACKING SYSTEM BS6	TATA spare parts
508054613301	BRACKET INLINE CONN MTG BS6	TATA spare parts
508054630102	WIRING HARNESS-ABS FRAME BS6	TATA spare parts
508054630106	WIRING HARNESS DFT PIGTAIL BS6	TATA spare parts
508054707101	PLATE BS6	TATA spare parts
508054707103	PLATE BS6	TATA spare parts
508054708201	BRACKET TELEMATICS UNIT MTG BS6	TATA spare parts
508054709901	VEHICLEELECTRONICCONTROLLERUNIT BS6	TATA spare parts
508054719901	TELEMATICS UNIT BS6-PH2	TATA spare parts
508054850102	WIRING HARNESS-DMS BS6	TATA spare parts
508058900601	HOLDER BS6	TATA spare parts
508058900603	DRIFT BS6	TATA spare parts
508058900604	PULLER BS6	TATA spare parts
50807633000RCK	ASSY CABIN KIT W/FITMENT SIGNA 4625.S BS	TATA spare parts
508116172001	ECU ABS E8 UNIVERSAL 24V BS6	TATA spare parts
508129300101	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
508131000104	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508131000115	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508131000120	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508131000121	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508131000122	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508131000127	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508131000129	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508131000133	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508131107103	REINFORCEMENT MIDDLE-RH BS6	TATA spare parts
508131107104	REINFORCEMENT MIDDLE-LH BS6	TATA spare parts
508131107119	C-REINFORCEMENT RH BS6	TATA spare parts
508131107120	C-REINFORCEMENT LH BS6	TATA spare parts
508131107122	LONG MEMBER LH BS6	TATA spare parts
508131107130	ANGLE PLATE LH BS6	TATA spare parts
508131107131	ANGLE PLATE RH BS6	TATA spare parts
508131107138	REINFORCEMENT MIDDLE-RH BS6	TATA spare parts
508131107139	REINFORCEMENT MIDDLE-LH BS6	TATA spare parts
508131200106	ALLIGATED CROSS MEMBER ASSY	TATA spare parts
508131200107	CROSS MEMBER ASSY CENTER BS6	TATA spare parts
50813120010860	CROSS MEMBER ASSY REAR SPRING FRONT BS6	TATA spare parts
508131200110	END CROSS MEMBER ASSY WITH GUSSET BS6	TATA spare parts
508131200111	CROSS MEMBER ASSY REAR SPRING FRONT BS6	TATA spare parts
508131200112	CROSS MEMBER ASSY BS6	TATA spare parts
508131200127	REINFORCEMENT ASSY RH BS6	TATA spare parts
508131200128	REINFORCEMENT ASSY LH BS6	TATA spare parts
508131200130	L-BRACKET ASSY LHBS6	TATA spare parts



508131200131	L-BRACKET ASSY RH BS6	TATA spare parts
508131200132	L-BRACKET ASSY LH BS6	TATA spare parts
508131200133	L-BRACKET ASSY RH BS6	TATA spare parts
508131200141	END CROSS MEMBER ASSY BS6-PH2	TATA spare parts
508131200147	CROSS MEMBER ASSY TUBULAR BS6	TATA spare parts
508131200148	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
508131307131	ANGLE PLATE LH BS6	TATA spare parts
508131307132	ANGLE PLATE RH BS6	TATA spare parts
508131700104	SUPPORT ASSY RADIATOR MTG RH BS6	TATA spare parts
508131700105	SUPPORT ASSY RADIATOR MTG LH BS6	TATA spare parts
508131700106	BRACKET ASSY RADIATOR MTG BS6	TATA spare parts
508131700108	BRACKET ASSY FUPD MTG RH BS6	TATA spare parts
508131700109	BRACKET ASSY FUPD MTG LH BS6	TATA spare parts
508132100105	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
508132100106	FRONT SPRING ASSY BS6-PH2	TATA spare parts
508132104201	CLAMP BS6-PH2	TATA spare parts
508132107107	3RD LEAF BS6-PH2	TATA spare parts
508132107109	4TH LEAF BS6-PH2	TATA spare parts
508132107110	2ND LEAF BS6-PH2	TATA spare parts
508132107111	CENTER PAD BS6-PH2	TATA spare parts
508132300101	SHOCK ABSORBER ASSY FRONTBS6-PH2	TATA spare parts
508132300102	BRACKET ASSY FRONT SHOCK ABSORBER MTG BS	TATA spare parts
508132300103	BRACKET ASSY SHOCK ABSORBER MTG LOWER BS	TATA spare parts
508132400102	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
508132400103	LEAF SPRING ASSY REAR BS6	TATA spare parts
508132400114	LEAF SPRING ASSY REAR BS6-PH2	TATA spare parts
508132403204	CENTER BOLT BS6-PH2	TATA spare parts
508132407102	2ND LEAF BS6	TATA spare parts
508132407117	1ST LEAF AUX SPRING BS6-PH2	TATA spare parts
508132407118	2ND LEAF AUX SPRING BS6-PH2	TATA spare parts
508132407119	3RD LEAF AUX SPRING BS6-PH2	TATA spare parts
508132407120	4TH LEAF AUX SPRING BS6-PH2	TATA spare parts
508132407121	5TH LEAF AUX SPRING BS6-PH2	TATA spare parts
508132407123	6TH LEAF AUX SPRING BS6-PH2	TATA spare parts
508132407124	7TH LEAF AUX SPRING BS6-PH2	TATA spare parts
508132407125	8TH LEAF AUX SPRING BS6-PH2	TATA spare parts
508132407126	9TH LEAF AUX SPRING BS6-PH2	TATA spare parts
508132600102	SHOCK ABSORBER ASSY REARBS6-PH2	TATA spare parts
508132800102	LINK ASSY ANTI ROLL BAR BS6-PH2	TATA spare parts
508133000102	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
508133000103	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
508133000104	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
508133105101	FRONT AXLE BEAM BS6 PH2	TATA spare parts
508134100101	FIFTH WHEEL ASSY WITH STRUCTURE BS6	TATA spare parts
508134200101	SUBSTRUCTURE ASSY FIFTH WHEEL COUPLING B	TATA spare parts
508134200109	GUIDE BRACKET ASSY LH BS6	TATA spare parts
508134200110	GUIDE BRACKET ASSY RH BS6	TATA spare parts

508134200113	FIFTH WHEEL ASSY WITH STRUCTURE BS6	TATA spare parts
508134200114	SUBSTRUCTURE ASSY FIFTH WHEEL COUPLING B	TATA spare parts
508134200118	SUBSTRUCTURE ASSY FIFTH WHEEL COUPLING B	TATA spare parts
508134200119	FIFTH WHEEL ASSY WITH STRUCTURE BS6	TATA spare parts
508134200121	GUIDE BRACKET ASSY LH BS6	TATA spare parts
508134200122	GUIDE BRACKET ASSY RH BS6	TATA spare parts
508134200123	L-PLATE LH BS6	TATA spare parts
508134200124	L-PLATE RH BS6	TATA spare parts
508134200128	SUBSTRUCTURE ASSY FIFTH WHEEL COUPLING B	TATA spare parts
508134200129	FIFTH WHEEL ASSY WITH STRUCTURE BS6	TATA spare parts
508134200130	L-PLATE LH BS6	TATA spare parts
508134200131	L-PLATE RH BS6	TATA spare parts
508134200135	SUBSTRUCTURE ASSY FIFTH WHEEL COUPLING B	TATA spare parts
508134200136	FIFTH WHEEL ASSY WITH STRUCTURE BS6	TATA spare parts
508134200141	SUBSTRUCTURE ASSY FIFTH WHEEL COUPLING B	TATA spare parts
508134200142	FIFTH WHEEL ASSY WITH STRUCTURE BS6-PH2	TATA spare parts
508141120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508141120104	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508141120105	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508141120106	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508141120107	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508141120109	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
508141120110	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
508141120111	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508141990106	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
508141990108	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
508141990109	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
508141990111	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
508141990112	CROSS ASSY BS6	TATA spare parts
508141990113	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
508143200101	BRACKET ASSY AIR TANK MTG	TATA spare parts
508143200102	AIR TANK ASSY BS6	TATA spare parts
508143200103	AIR TANK ASSY BS6	TATA spare parts
508143200104	AIR TANK ASSY WITH BKT BS6	TATA spare parts
508143203301	BRACKET ASSY (AIR TANK MTG.) BS6	TATA spare parts
508143700117	PRESSURE REDUCTION VALVE BS6	TATA spare parts
508143700118	BRACKET BS6	TATA spare parts
508143700121	BRACKET	TATA spare parts
508143700127	ADAPTER BS6	TATA spare parts
508143700128	DOUBLE CHECK VALVE BS6	TATA spare parts
508143700136	DUAL TREADLE VALVE BS6	TATA spare parts
508143700140	DUAL TREADLE VALVE BS6	TATA spare parts
508143700141	ANTI ROLL BACK ASSY BS6	TATA spare parts
508143700143	ANTI ROLL BACK ASSY BS6	TATA spare parts
508143700145	BRACKET BS6	TATA spare parts
508143700147	AIR TANK ASSY BS6	TATA spare parts
508143700150	BRAKE CHAMBER TYPE 27 WITH PTC BS6	TATA spare parts

508143700158	BRAKE CHAMBER BS6	TATA spare parts
508143700160	ASSY BRACKET (FOR LSV LEVER MTG-ON AXLE)	TATA spare parts
508143700170	BRACKET ASSY BS6	TATA spare parts
508143700176	BRAKE CHAMBER BS6-PH2	TATA spare parts
508143700178	BRAKE CHAMBER BS6	TATA spare parts
508143700179	BRAKE CHAMBER BS6-PH2	TATA spare parts
508143700180	BRAKE CHAMBER BS6-PH2	TATA spare parts
508143700181	BRAKE CHAMBER BS6	TATA spare parts
508143700182	BRAKE CHAMBER BS6-PH2	TATA spare parts
508143700183	BRAKE CHAMBER BS6-PH2	TATA spare parts
508143700184	BRAKE CHAMBER BS6	TATA spare parts
508143700187	BRAKE CHAMBER BS6	TATA spare parts
508143700189	HBV WITH TRAILER CHECK BS6	TATA spare parts
508143900101	METAL PIPE ASSY BS6	TATA spare parts
508143900102	METAL PIPE ASSY BS6	TATA spare parts
508143900104	BUNCH ASSY PIPE BS6	TATA spare parts
508143900140	BRACKET ASSY BS6	TATA spare parts
508143900145	BUNCH ASSY PIPE BS6	TATA spare parts
508143900165	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
508143903313	CLAMP BS6 PH2	TATA spare parts
508143903322	BRACKET BS6-PH2	TATA spare parts
508143910101	METAL PIPE ASSY	TATA spare parts
508143910175	BUNCH ASSY-PIPE BS6	TATA spare parts
508143920117	BUNCH PIPE ASSY BS6	TATA spare parts
508143920159	METAL PIPE ASSY BS6-PH2	TATA spare parts
508143920161	METAL PIPE ASSY BS6-PH2	TATA spare parts
508143920166	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
508145990101	NYLON PIPE BUNCH BS6-PH2	TATA spare parts
508146100101	STEERING COLUMN ASSY TILT AND TELESCOPIC	TATA spare parts
508146100102	BRACKET ASSY STG COLUMN MTG BS6	TATA spare parts
508146100103	COLUMN ASSY UPPER BS6	TATA spare parts
508146100104	SPLINE TUBE ASSY BS6	TATA spare parts
508146100105	STEERING COLUMN ASSY TILT & TELESCOPIC B	TATA spare parts
508146106301	RUBBER BELLOW ASSY BS6	TATA spare parts
508146600101	POWER STEERING PUMP ASSY BS6	TATA spare parts
508146600103	SHAFT SUB ASSY BS6	TATA spare parts
508146600106	HOUSING SUB ASSEMBLY KIT BS6	TATA spare parts
508146600107	BRACKET ASSY RESERVOIR MTG BS6	TATA spare parts
508146800101	PRESSURE LINE ASSY BS6	TATA spare parts
508146800102	PRESSURE LINE ASSY BS6	TATA spare parts
508146800103	RETURN LINE ASSY BS6	TATA spare parts
508146800104	RETURN LINE ASSY STG GEAR BOX END BS6	TATA spare parts
508146800105	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
508146800106	SUCTION LINE ASSY BS6	TATA spare parts
508146800109	ELBOW ADAPTER ASSY BS6 PH2	TATA spare parts
508146800112	ELBOW ADAPTER ASSY BS6-PH2	TATA spare parts
508146990116	HOUSING ASSY BS6	TATA spare parts

508147500101	SPACER BRACKET ASSY FUEL TANK MTG BS6	TATA spare parts
508147500102	BRACKET ASSY FUEL TANK MTG BS6	TATA spare parts
508147600101	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
508147600102	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
508147600103	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
508147600107	FUEL SUCTION PIPE ASSY FTR TO ENGINE BS6	TATA spare parts
508147600108	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
508149200103	SUCTION LINE;TANK TO SM BS6	TATA spare parts
508149200104	PRESSURE LINE;SM TO DM BS6	TATA spare parts
508149200117	BRACKET ASSY EGP MTG REAR BS6	TATA spare parts
508149200124	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
508149200127	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
508149200129	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
508149200130	BRACKET ASSY EGP MTG BS6	TATA spare parts
508149200132	BRACKET ASSY EGP MTG REAR BS6	TATA spare parts
508149203303	BRACKET TAIL PIPE BS6	TATA spare parts
508149203308	BRACKET BS6	TATA spare parts
508149203317	BRACKET TAIL PIPE MTG BS6	TATA spare parts
508149203318	BRACKET TAIL PIPE BS6	TATA spare parts
508149990103	HEAT SHIELD ASSY BS6	TATA spare parts
508149990105	HEAT SHIELD ASSY BS6	TATA spare parts
508154400101	BRACKET ASSY LICENSE PLATE MTG BS6	TATA spare parts
508154400102	BRACKET ASSY WITH MTG PLATE TAIL LAMP RH	TATA spare parts
508154400103	BRACKET ASSY WITH MTG PLATE TAIL LAMP LH	TATA spare parts
508154403304	BRACKET TAIL LAMP BASE MTG BS6	TATA spare parts
508154403315	BRACKET TAIL LAMP BASE MTG BS6	TATA spare parts
508154504901	SWITCH BATTERY CUT OFF BS6	TATA spare parts
508154504902	SWITCH HEADLAMP LEVELLING BS6	TATA spare parts
508154504903	SWITCH REAR FOG LAMP BS6	TATA spare parts
508154504904	SWITCH EMERGENCY HELP BS6	TATA spare parts
508154504905	SWITCH FRONT FOG LAMP BS6	TATA spare parts
508154504906	SWITCH RPM INCREMENT DASHBOARD BS6	TATA spare parts
508154504907	FUEL SELECTOR SWITCH BS6	TATA spare parts
508154504909	SWITCH RPM DECREMENT DASHBOARD BS6	TATA spare parts
508154600101	WIRING HARNESS TAIL BS6	TATA spare parts
508154600102	WIRING HARNESS SCR UNIT BS6	TATA spare parts
508154600105	PIGTAIL COMBI SWITCH	TATA spare parts
508154600111	WIRING HARNESS EMS PIGTAIL BS6	TATA spare parts
508154600112	BATTERY -VE BS6	TATA spare parts
508154600115	BATTERY +VE BS6	TATA spare parts
508154600116	BATT CABLE +VE BCS OFF O/P TO M FUSE I/P	TATA spare parts
508154600117	BATTERY +VE BS6	TATA spare parts
508154600118	PIGTAIL TAIL LAMPBS6	TATA spare parts
508154600120	WIRING HARNESS ROOF BS6	TATA spare parts
508154600122	BRACKET MEGA FUSE MTG BS6	TATA spare parts
508154600123	EARTH CABLE BS6	TATA spare parts
508154600125	WIRING HARNESS ABS FRAME BS6	TATA spare parts

508154600127	WIRING HARNESS MAIN BS6	TATA spare parts
508154600150	PIGTAIL BS6	TATA spare parts
508154600151	BATTERY +VE BS6	TATA spare parts
508154609901	STICKER MAXI FUSE BOX BS6	TATA spare parts
508154610111	WIRING HARNESS MAIN BS6	TATA spare parts
508154610113	WIRING HARNESS MAIN BS6	TATA spare parts
508154610114	WIRING HARNESS MAIN BS6	TATA spare parts
508154610118	WIRING HARNESS DFT SWITCH PIGTAIL BS6	TATA spare parts
508154630101	WIRING HARNESS-ABS FRAME BS6	TATA spare parts
508154803302	BRACKET TPMS RECEIVER MTG BS6-PH2	TATA spare parts
508154804902	TYRE PRESSURE MONITORING SYSTEM BS6-PH2	TATA spare parts
50817238000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 5530.S B	TATA spare parts
50817838100RCK	ASSY CAB KIT W/FITMENT FOR SIGNA 5530.S	TATA spare parts
50818438000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 5530 BS6	TATA spare parts
50819438000RCK	ASSY CABIN KIT W/FITMENT 5530 SIGNA BS6	TATA spare parts
50842368000RCK	ASSY CAB KIT W/FITMENTS SIGNA 4225.T BS6	TATA spare parts
508424100101	ENGINE MOUNT ASSY FRONT BS6-PH2	TATA spare parts
508424990101	KIT- ENGINE MTG BS4	TATA spare parts
508431000102	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508431000111	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508431000116	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508431000136	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508431200114	CROSS MEMBER ASSY BUMPER BS6-PH2	TATA spare parts
508431200118	CROSS MEMBER ASSY BS6	TATA spare parts
508431300110	REINFORCEMENT ASSY LH BS6-PH2	TATA spare parts
508431300111	REINFORCEMENT ASSY RH BS6-PH2	TATA spare parts
50843168000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 4225 BS6	TATA spare parts
508432400111	REAR SPRING ASSY BS6-PH2	TATA spare parts
508432400112	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
508432403405	SPRING BUSH BS6-PH2	TATA spare parts
508432404201	SPRING CLIP REAR SPRING BS6-PH2	TATA spare parts
508432404212	SPRING CLIP REAR SPRING BS6-PH2	TATA spare parts
508432407115	1ST LEAF BS6-PH2	TATA spare parts
508432407116	2ND LEAF BS6-PH2	TATA spare parts
508432407118	3RD LEAF BS6-PH2	TATA spare parts
508432407119	4TH LEAF BS6-PH2	TATA spare parts
508432407120	5TH LEAF BS6-PH2	TATA spare parts
508432407121	6TH LEAF BS6-PH2	TATA spare parts
508432407122	7TH LEAF BS6-PH2	TATA spare parts
508432407123	8TH LEAF BS6-PH2	TATA spare parts
508432407124	9TH LEAF BS6-PH2	TATA spare parts
508432407125	10TH LEAF BS6-PH2	TATA spare parts
508432407126	PLATE REAR SPRING SPACER BS6-PH2	TATA spare parts
508432408650	SLEEVE BS6-PH2	TATA spare parts
508433000108	LIFT AXLE ASSY WITH BRAKE BS6	TATA spare parts
508433000109	FRONT AXLE ASSY WITH BRAKE FRT FWD BS6	TATA spare parts
508433105101	LIFT AXLE BEAM BS6	TATA spare parts

508433200101	STUB AXLE ASSY	TATA spare parts
508433200103	STUB AXLE END CAP ASSY BS6 PH2	TATA spare parts
508433200104	STUB AXLE ASSY BS6	TATA spare parts
508433200105	STUB AXLE ASSY RH BS6-PH2	TATA spare parts
508433200106	STUB AXLE ASSY LH BS6-PH2	TATA spare parts
508433205103	STUB AXLE RH BS6 PH2	TATA spare parts
508433205104	STUB AXLE LH BS6 PH2	TATA spare parts
508433207701	STUB AXLE END CAP BS6-PH2	TATA spare parts
508433208202	SLEEVE BS6-PH2	TATA spare parts
508433405502	FRONT HUB BS6	TATA spare parts
508433800104	TIE ROD ASSY BS6 PH2	TATA spare parts
508433800108	TIE ROD ASSY BS6-PH2	TATA spare parts
508433805107	STEERING ARM BS6 PH2	TATA spare parts
508433900183	KIT-LIFT AXLE BS6-PH2	TATA spare parts
508433900185	AIR SPRING MTG LH BS6-PH2	TATA spare parts
508433900186	AIR SPRING MTG RH BS6-PH2	TATA spare parts
508433900202	LINK ROD ASSY BS6-PH2	TATA spare parts
508433990104	REPAIR KIT BS6-PH2	TATA spare parts
50843768400RCK	ASSY CAB KIT W/FITMENT FOR SIGNA 4225	TATA spare parts
508441100102	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508441100103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508441100104	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508441110101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508441110102	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508441110103	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
508441110104	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
508441110111	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508441110112	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508441110120	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508441110122	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508441110127	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508441120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508441120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508441120104	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
508441120109	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508441120110	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508441120114	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508441120116	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
508441300101	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
508441300102	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
508441300110	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
508441300111	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
508441300113	BRACKET ASSY CENTER BRG MTG BS6 PH2	TATA spare parts
508441300114	BRACKET ASSY CENTER BRG MTG BS6 PH2	TATA spare parts
508441990101	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
508441990102	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
508441990108	LONG FORK ASSY BS6	TATA spare parts

508441990110	CENTER BEARING ASSY BS6-PH2	TATA spare parts
508441990126	LONG FORK ASSY BS6	TATA spare parts
508441990127	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
508441990129	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
508441990130	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
508441990141	LONG FORK ASSY BS6-PH2	TATA spare parts
508441990142	UNIVERSAL JOINT ASSY BS6-PH2	TATA spare parts
508443200101	BRACKET ASSY AIR TANK MTG BS6	TATA spare parts
508443200103	AIR TANK ASSY BS6-PH2	TATA spare parts
508443200111	STRAP ASSY WITH PIN & BOLT BS6-PH2	TATA spare parts
508443200112	STRAP ASSY AIR TANK MTG BS6-PH2	TATA spare parts
508443200116	AIR TANK ASSY BS6-PH2	TATA spare parts
508443200118	AIR TANK ASSY BS6-PH2	TATA spare parts
508443200121	AIR TANK ASSY BS6	TATA spare parts
508443200122	AIR TANK ASSY BS6	TATA spare parts
508443200126	AIR TANK ASSY BS6	TATA spare parts
508443200127	AIR TANK ASSY BS6	TATA spare parts
508443700103	AIR PROCESSING UNIT-KB	TATA spare parts
508443700119	BRAKE AGGR ASSY BS6	TATA spare parts
508443700120	LIFT AXLE PROTECTION BS6VALVE	TATA spare parts
508443700122	KIT- LIFT AXLE PROTECTION VALVE BS6	TATA spare parts
508443700131	RELAY VALVE & MODULATOR VALVE ASSY W BKT	TATA spare parts
508443700155	BRAKE CHAMBER BS6-PH2	TATA spare parts
508443700158	BRAKE CHAMBER BS6-PH2	TATA spare parts
508443900101	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
508443900115	METAL PIPE ASSY 1ST COMP.TO JOINT-1 BS6	TATA spare parts
508443900125	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
508443900155	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
508443900251	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
508443900252	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
508443903303	BRACKET BS6-PH2	TATA spare parts
508443906801	ADAPTER BS6	TATA spare parts
508443910116	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
508443910178	BRACKET ASSY BS6	TATA spare parts
508443910202	PIPE ASSY BS6	TATA spare parts
508443920131	METAL PIPE ASSY WITH CRIMPED TEFLON HOSE	TATA spare parts
508443920132	METAL PIPE ASSY BS6 PH2	TATA spare parts
508443920133	METAL PIPE ASSY BS6 PH2	TATA spare parts
508443920134	METAL PIPE ASSY BS6 PH2	TATA spare parts
508443920148	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
508446100102	STEERING COLUMN ASSY TILT & TELESCOPIC B	TATA spare parts
508446100103	STEERING COLUMN ASSY TILT & TELESCOPIC B	TATA spare parts
508446600103	POWER STEERING GEAR ASSY BS6-PH2	TATA spare parts
508446600107	STEERING PUMP BS6-PH2	TATA spare parts
508446800109	PRESSURE LINE ASSY STG GEAR BOX END BS6-	TATA spare parts
508446800110	RETURN LINE ASSY STG GEAR BOX END BS6-PH	TATA spare parts
508446800114	PRESSURE LINE ASSY STG GEAR BOX END BS6-	TATA spare parts

508446800115	RETURN LINE ASSY STG GEAR BOX END BS6-PH	TATA spare parts
508446990125	HOUSING ASSY BS6-PH2	TATA spare parts
508446990140	WORM & VALVE HSG WITH RACK ASSY BS6-PH2	TATA spare parts
508446990141	PISTON ASSY BS6-PH2	TATA spare parts
508446990144	INTERMEDIATE SHAFT ASSY BS6-PH2	TATA spare parts
508446990145	COLUMN ASSY UPPER BS6-PH2	TATA spare parts
508447107801	SEALING RING BS6	TATA spare parts
508447507102	BRACKET BS6	TATA spare parts
508447600101	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
508447600102	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
508447600103	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
508447600107	SUCTION PIPE ASSY - FILTER TO ENGINE BS6	TATA spare parts
508447600108	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
508447600109	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
508447600110	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
508447600119	SUCTION PIPE ASSY FILTER TO ENG BS6-PH2	TATA spare parts
508447600120	FUEL SUC PIPE ASSY TANK TO W/SEP BS6-PH2	TATA spare parts
508447600121	RTN PIPE ASSY ENG TO FUEL TANK BS6-PH2	TATA spare parts
508447600122	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
508447600123	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
508447600124	RETURN FUEL PIPE ASSY BS6-PH2	TATA spare parts
508447600128	FUEL SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
508447600129	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
508449200101	BRACKET ASSY BS6	TATA spare parts
508449200102	BRACKET ASSY BS6	TATA spare parts
508449200104	EXHAUST PIPE ASSY FIRST BS6	TATA spare parts
508449200109	BRACKET ASSY FRONT BS6	TATA spare parts
508449200110	BRACKET ASSY EXHAUST PIPE SUPPORT BS6	TATA spare parts
508449200114	BRACKET ASSY BS6	TATA spare parts
508449200116	BRACKET ASSY BS6	TATA spare parts
508449200117	RETURN LINE,DM TO TANK BS6	TATA spare parts
508449200121	BRACKET ASSY REAR BS6	TATA spare parts
508449200122	BRACKET ASSY EXHAUST PIPE SUPPORT BS6	TATA spare parts
508449200124	PRESSURE LINE,SM TO DM BS6	TATA spare parts
508449200128	BRACKET ASSY BS6	TATA spare parts
508449200132	PRESSURE LINE;SM TO DM BS6	TATA spare parts
508449200146	BRACKET ASSY BS6	TATA spare parts
508449200151	BRACKET ASSY BS6	TATA spare parts
508449200158	BRACKET ASSY BS6	TATA spare parts
508449203304	BRACKET BS6	TATA spare parts
508449203312	CLAMPING BRACKET PIPE BS6	TATA spare parts
508449203315	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
508449203320	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
508449203339	BRACKET PIPE MTG BS6	TATA spare parts
508449203342	L-BRACKET BS6	TATA spare parts
508449203344	L-BRACKET BS6	TATA spare parts
508449204203	CLAMP HEAT SHIELD FRONT BS6	TATA spare parts



508449204204	CLAMP BS6	TATA spare parts
508449206701	CLEVIS PIN BS6	TATA spare parts
508449207112	BRACKET BS6	TATA spare parts
508449208204	PROTECTIVE COVER SM BS6	TATA spare parts
508449210102	EXHAUST PIPE ASSY SECOND BS6	TATA spare parts
508449210104	BRACKET ASSY EXHAUST PIPE MTG BS6	TATA spare parts
508449210106	BRACKET ASSY EXHAUST PIPE SUPPORT BS6	TATA spare parts
508449210108	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
508449210109	COVER ASSY BS6	TATA spare parts
508449213308	BRACKET BS6	TATA spare parts
508449600101	HEAT SHIELD ASSY BS6	TATA spare parts
508449990104	HEAT SHIELD INSULATION BS6	TATA spare parts
508454109901	COVER ASSY BATTERY BS6-PH2	TATA spare parts
508454504901	CLUTCH SWITCH BS6	TATA spare parts
508454600102	WIRING HARNESS TAIL BS6	TATA spare parts
508454600106	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
508454600108	BATT CABLE +VE BCS O/P TO MAXI FUSE BOX	TATA spare parts
508454600109	WIRING HARNESS SCR UNIT BS6	TATA spare parts
508454600110	BATTERY CABLE +VE MAXI FUSE O/P TO SM BS	TATA spare parts
508454600111	WIRING HARNESS MAIN BS6	TATA spare parts
508454610104	WIRING HARNESS MAIN BS6	TATA spare parts
508454610117	WIRING HARNESS MAIN BS6	TATA spare parts
508454620101	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
508454630101	WIRING HARNESS TAIL BS6	TATA spare parts
508454630103	WIRING HARNESS TAIL BS6	TATA spare parts
508454630104	WIRING HARNESS SCR UNIT BS6	TATA spare parts
508454630107	WIRING HARNESS ABS FRAME BS6	TATA spare parts
508454630108	WIRING HARNESS SCR UNIT BS6	TATA spare parts
508454630119	WIRING HARNESS ABS FRAME BS6	TATA spare parts
508454630127	WIRING HARNESS TAIL	TATA spare parts
508454640107	BATT CABLE +VE BATT TO ELE BCS OFF I/P B	TATA spare parts
508454640109	BATT CABLE +VE BCS O/P TO MAXI FUSE BOX	TATA spare parts
508454700101	BRACKET ASSY VECU MTG BS6	TATA spare parts
508454709901	VEHICLE ELECTRONIC CONTROLLER UNIT BS6	TATA spare parts
508454728210	PLATE BS6	TATA spare parts
508454820101	WIPER MOTOR ASSY WITH BRACKET BS6-PH2	TATA spare parts
50848168000RCK	ASSY COWL KIT W/FITMENTS LPT 4225 BS6	TATA spare parts
50849168000RCK	ASSY COWL KIT FOR LPT 4225 BS6	TATA spare parts
50849168400RCK	ASSY COWL KIT FOR LPT 4225 BS6	TATA spare parts
5084D1B0475001	FRONT FLAPS AND BONNETS BS6-PH2	TATA spare parts
5084H9X0233005	FRONT AXLE ASSY WITH BRAKES-FWD BS6-PH2	TATA spare parts
5084H9X0233006	FRONT AXLE ASSY WITH BRAKES-RWD BS6-PH2	TATA spare parts
5084H9X0233007	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
5084H9X0233008	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
50850255000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 2818 BS6	TATA spare parts
50852568000RCK	ASSY COWL W/FITMENT LPT 2818 BS6	TATA spare parts
508529300101	BUNDY TUBE ASSY CMC TO LONG MEMBER BS6	TATA spare parts

508529300102	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
508531000102	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508531000104	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508531000106	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508531000107	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508531000110	FRAMEASSYWITHFITMENTBS6	TATA spare parts
508531000142	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508531200101	CROSS MEMBER ASSY BS6	TATA spare parts
508531200110	CROSS MEMBER ASSY BS6	TATA spare parts
508531200112	CROSS MEMBER ASSY CENTER BEARING MTG BS6	TATA spare parts
508531700104	BRACKET ASSY RAIDATOR MTG RH BS6	TATA spare parts
508531700105	BRACKET ASSY RAIDATOR MTG RH BS6	TATA spare parts
508532103302	BRACKET SPRING HANGER LH BS6	TATA spare parts
508532103303	BRACKET SPRING HANGER RH BS6	TATA spare parts
508532400102	CROSS BEAM REAR TWIST BEAM	TATA spare parts
508532400103	AIR SPRING ASSY	TATA spare parts
508532403701	BRACKET TORQUE ROD MTG	TATA spare parts
508532403708	BRACKET PANHARD ROD MTG	TATA spare parts
508532403709	LOWER SADDLE	TATA spare parts
508532403710	GUIDE PLATE	TATA spare parts
508532405101	SADDLE TOP	TATA spare parts
508532408602	WASHER BS6	TATA spare parts
508532600103	BRACKET ASSY REAR SHOCK ABSORBER LOWER	TATA spare parts
508533000104	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
508533000105	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
508533000110	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
508533805101	STEERING ARM BS6	TATA spare parts
508541100101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508541100102	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508541100103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508541100104	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
508541110104	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508541110105	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508541120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508541120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508541120107	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
50854255000RCK	ASSY CAB KIT FOR SIGNA 2818.T BS6	TATA spare parts
508543200104	AIR TANK ASSY WITH BKT BS6	TATA spare parts
508543703301	L-BRACKET BS6	TATA spare parts
508543900124	PIPE BUNCH ASSY BS6	TATA spare parts
508543900144	PIPE BUNCH ASSY BS6	TATA spare parts
508543900150	PIPE BUNCH ASSYBS6	TATA spare parts
508543900155	PIPE BUNCH ASSY BS6	TATA spare parts
508543900159	PIPE BUNCH ASSYBS6	TATA spare parts
508543900198	PIPE BUNCH ASSY BS6	TATA spare parts
508543907501	GROMMET BS6	TATA spare parts
508543910101	METAL PIPE ASSY BS6	TATA spare parts

508543910102	METAL PIPE ASSY BS6	TATA spare parts
508543910103	METAL PIPE ASSY BS6	TATA spare parts
508543920139	PIPE BUNCH ASSY BS6	TATA spare parts
508543920142	PIPE BUNCH ASSY BS6	TATA spare parts
508543920153	METAL PIPE ASSY TEFLON JOINT TO JOINT BS	TATA spare parts
508543920158	METAL PIPE ASSY JOINT TO APU BS6	TATA spare parts
508543920188	METAL PIPE ASSY BS6	TATA spare parts
508546305101	PITMAN ARM BS6	TATA spare parts
508546305102	PITMAN ARM BS6	TATA spare parts
508546305103	PITMAN ARM BS6	TATA spare parts
508546305104	PITMAN ARM BS6	TATA spare parts
508546600103	STEERING GEAR BOX ASSY BS6	TATA spare parts
508546600104	STEERING GEAR BOX ASSY BS6	TATA spare parts
508546800101	SUCTION LINE ASSY BS6	TATA spare parts
508546800104	SUCTION LINE ASSY BS6	TATA spare parts
508546800106	PRESSURE LINE ASSY BS6	TATA spare parts
508546800107	PRESSURE LINE ASSY BS6	TATA spare parts
508546800111	PRESSURE LINE ASSY BS6	TATA spare parts
508546800112	RETURN LINE ASSY BS6	TATA spare parts
508546800113	PRESSURE LINE ASSY BS6	TATA spare parts
508546800114	RETURN LINE ASSY BS6	TATA spare parts
508546800115	SUCTION LINE ASSY BS6	TATA spare parts
508546800116	RETURN LINE ASSY BS6	TATA spare parts
508546900101	DRAG LINK ASSY BS6	TATA spare parts
508546990111	HOUSING COVER ASSY BS6	TATA spare parts
508546990112	LIMITER ASSY BS6	TATA spare parts
508546990113	LIMITER ASSY BS6	TATA spare parts
508546990114	PISTON ASSY BS6	TATA spare parts
508546990115	SECTOR SHAFT ASSY BS6	TATA spare parts
508546990120	STEERING LIMITER SCREW ASSY BS6	TATA spare parts
508546990121	AUTO LIMITER VALVE BS6	TATA spare parts
508546990123	AUTO LIMITER VALVE BS6	TATA spare parts
508546990125	AUTO LIMITER VALVE BS6	TATA spare parts
508547500102	BASE FRAME CYLINDER MTG BS6	TATA spare parts
508547500104	BOX ASSY BS6	TATA spare parts
508547500108	STRAP ASSY BS6	TATA spare parts
508547500109	BRACKET ASSY BS6	TATA spare parts
508547500110	BRACKET ASSY HP REGULATOR MTG BS6	TATA spare parts
508547500112	RESTRAINT ASSY BS6	TATA spare parts
508547500119	COVER ASSY BS6	TATA spare parts
508547500125	RESTRAINT ASSY BS6	TATA spare parts
508547500131	RESTRAINT ASSY BS6	TATA spare parts
508547500133	RESTRAINT ASSY BS6	TATA spare parts
508547506701	CLEVIS PIN BS6	TATA spare parts
508547506705	CLEVIS PIN BS6	TATA spare parts
508547507120	L-BRACKET BS6	TATA spare parts
508547600101	RETURN PIPE ASSY;ENGINE TO FUEL TANK BS6	TATA spare parts

508547600102	SUCTION FUEL PIPE;FUEL TANK TO W/SEP BS6	TATA spare parts
508547600105	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
508547600107	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
508547600108	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
508547600109	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
508547600110	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
508547600111	HP TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
508547600112	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
508547600113	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
508547600114	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
508547600117	VENT TUBE ASSY BS6	TATA spare parts
508547600118	VENT TUBE ASSY BS6	TATA spare parts
508547600119	VENT TUBE ASSY BS6	TATA spare parts
508547600120	VENT TUBE ASSY BS6	TATA spare parts
508547600121	VENT TUBE ASSY BS6	TATA spare parts
508547600122	VENT TUBE ASSY BS6	TATA spare parts
508547600126	VENT TUBE ASSY BS6	TATA spare parts
508547600141	VENT TUBE ASSY BS6	TATA spare parts
508547600142	VENT TUBE ASSY BS6	TATA spare parts
508547600143	SUCTION PIPE ASSY FUEL TANK TO FILTER FU	TATA spare parts
508547600144	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
508547600145	FUEL RETURN PIPE ASSY (ENG TO FUEL TANK)	TATA spare parts
508549200101	BRACKET ASSY;TAIL PIPE MTG BS6	TATA spare parts
508549200102	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
508549204201	CLAMP BS6	TATA spare parts
508549600102	HEAT SHIELD ASSY BS6	TATA spare parts
508554304902	FUEL LEVEL SENSOR BS6	TATA spare parts
508554304903	LEVEL SENSOR FUEL BS6	TATA spare parts
508554304904	FUEL LEVEL SENSOR BS6	TATA spare parts
508554400101	BRACKET ASSY WITH MTG PLATE TAIL LAMP RH	TATA spare parts
508554400102	BRACKET ASSY WITH MTG PLATE TAIL LAMP LH	TATA spare parts
508554600103	WIRING HARNESS TAIL BS6	TATA spare parts
508554600107	WIRING HARNESS TAIL BS6	TATA spare parts
508554600114	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
508554600115	WIRING HARNESS MAIN BS6	TATA spare parts
508554600116	WIRING HARNESS ENGINE BS6	TATA spare parts
508554600117	WIRING HARNESS SCR UNIT BS6	TATA spare parts
508554600118	WIRING HARNESS ABS FRAME BS6	TATA spare parts
508554600119	WIRING HARNESS PIGTAIL LIFT AXLE BS6	TATA spare parts
508554600120	WIRING HARNESS TAIL BS6	TATA spare parts
508554600122	BATTERY CABLE +VE MAXI FUSE O/P TO SM BS	TATA spare parts
508554600123	BATT CABLE +VE BCS O/P TO MAXI FUSE BOX	TATA spare parts
508554600124	PIGTAIL COMBI SWITCH BS6	TATA spare parts
508554600132	WIRING HARNESS TAIL BS6	TATA spare parts
508554600140	PIGTAIL COMBI SWITCH BS6	TATA spare parts
508554603301	BRACKET CONNECTOR MTG BS6	TATA spare parts
508554610101	WIRING HARNESS MAIN BS6	TATA spare parts

508554610103	WIRING HARNESS MAIN BS6	TATA spare parts
508554610109	WIRING HARNESS MAIN BS6	TATA spare parts
508554620101	WIRING HARNESS;ENGINE BS6	TATA spare parts
508554620102	WIRING HARNESS ENGINE BS6	TATA spare parts
508554630101	WIRING HARNESS SCR UNIT BS6	TATA spare parts
508554630102	WIRING HARNESS TAIL BS6	TATA spare parts
508554630103	WIRING HARNESS ABS FRAME BS6	TATA spare parts
508554630105	WIRING HARNESS ABS FRAME BS6	TATA spare parts
508554630107	WIRINGHARNESSCRUNIT BS6	TATA spare parts
508554630108	WIRINGHARNESSTAIL BS6	TATA spare parts
508554630109	WIRINGHARNESABSFRAME BS6	TATA spare parts
508554630113	WIRING HARNESS ABS FRAME BS6	TATA spare parts
508554630115	WIRING HARNESS TAIL BS6	TATA spare parts
508554630121	WIRING HARNESS ABS FRAME BS6	TATA spare parts
508554630122	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
508554630123	WIRING HARNESS RPAS BS6	TATA spare parts
508554630124	WIRING HARNESS TAIL BS6	TATA spare parts
508554630125	WIRING HARNESS SCR UNIT BS6	TATA spare parts
508554640101	CABLE¿ASSY¿BATTERY¿+VE BS6	TATA spare parts
508554708202	BRACKET TELEMATICS MTG BS6	TATA spare parts
508554709901	STICKER FUEL ECONOMY SWITCH CONTROLLER B	TATA spare parts
508554710101	BRACKET ASSY VEHICLE TRACKING ASSY MTG B	TATA spare parts
50860132000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 1918.K B	TATA spare parts
508631000104	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508631000106	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508631200101	SUPPORT ASSY ENGINE CROSS MEMBER RH BS6	TATA spare parts
508631200102	SUPPORT ASSY ENGINE CROSS MEMBER LH BS6	TATA spare parts
508631200103	CROSS MEMBER ASSY ENGINE BS6	TATA spare parts
508641120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508641120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508643700101	ANTI COMPOUNDING RELAY VALVE BS6	TATA spare parts
508643700103	SPRING BRAKE ACTUATOR BS6	TATA spare parts
508643700104	SPRING BRAKE ACTUATOR ASSY BS6	TATA spare parts
508643900101	METAL PIPE ASSY BS6	TATA spare parts
508643900104	PIPE BUNCH ASSY BS6	TATA spare parts
508643900120	METAL PIPE ASSY BS6	TATA spare parts
508643900122	PIPE BUNCH ASSY BS6	TATA spare parts
508647600101	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
508647600102	SUCTION LINE ASSY BS6	TATA spare parts
508647600103	FUEL RETURN PIPE ASSY HP PUMP TO T-CONN	TATA spare parts
508647600104	FUEL RETURN PIPE ASSY BS6	TATA spare parts
508649200106	PIPE ASSY BS6	TATA spare parts
508649200107	STAY ROD ASSY BS6	TATA spare parts
508649200110	BRACKET ASSY BS6	TATA spare parts
508649200111	EXHAUST PIPE ASSY BS6	TATA spare parts
508649200112	BRACKET ASSY BS6	TATA spare parts
508649200113	BRACKET ASSY BS6	TATA spare parts

508649200114	BRACKET ASSY BS6	TATA spare parts
508649200115	SUCTION PIPE BS6	TATA spare parts
508649200116	SUCTION PIPE BS6	TATA spare parts
508649200117	PRESSURE LINE SM TO DM BS6	TATA spare parts
508649200120	BRACKET ASSY BS6	TATA spare parts
508649200124	HEAT SHIELD ASSY BS6	TATA spare parts
508649203303	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
508649203307	L-BRACKET EXHAUST MTG BS6	TATA spare parts
508649204201	CLAMP BS6	TATA spare parts
508649208201	COVERç BS6	TATA spare parts
508649208202	HEAT SHILED-SILENCER BS6	TATA spare parts
508649208206	HEAT SHIELD-SILENCER BS6	TATA spare parts
508649208210	HEAT SHIELD SILENCER BS6	TATA spare parts
508649208211	HEAT SHILED SILENCER BS6	TATA spare parts
508649990101	HEAT SHIELD EXHAUST BS6	TATA spare parts
508649990110	KIT-EXHAUST SYSTEM BS6	TATA spare parts
508649990111	HEAT SHIELD EXHAUST BS6	TATA spare parts
508649990114	KIT-EXHAUST SYSTEM BS6	TATA spare parts
508649990115	HEAT SHIELD EXHAUST BS6	TATA spare parts
508654600101	WIRING HARNESS TAIL BS6	TATA spare parts
508654600103	WIRING HARNESS ABS FRAME BS6	TATA spare parts
508654600104	EARTH CABLE BS6	TATA spare parts
508654600106	WIRING HARNESS TAIL BS6	TATA spare parts
508724200101	BRACKET ASSY CHASSIS RH BS6	TATA spare parts
508724200102	BRACKET ASSY CHASSIS LH BS6	TATA spare parts
508731000107	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508731000111	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508731107106	LONG MEMBER LH BS6	TATA spare parts
508731107107	REINFORCEMENT RH BS6	TATA spare parts
508731107108	REINFORCEMENT LH BS6	TATA spare parts
508731107119	GUSSET TOP-RH BS6	TATA spare parts
508731107120	GUSSET TOP-LH BS6	TATA spare parts
508731107121	GUSSET BOTTOM RH BS6	TATA spare parts
508731107122	GUSSET BOTTOM-LH BS6	TATA spare parts
508731200103	CROSS MEMBER ASSY BS6	TATA spare parts
508731200105	CROSS MEMBER ASSY ENGINE BS6	TATA spare parts
508732103703	BRACKET SPRING HANGER REAR-LH BS6	TATA spare parts
508732103704	BRACKET SPRING HANGER REAR-RH BS6	TATA spare parts
508733000102	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
508741120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
508741120106	PROPELLER SHAFT ASSY-DRIVE BS6	TATA spare parts
508741120108	PROPELLER SHAFT ASSY INTERAXLE BS6-PH2	TATA spare parts
508743700105	SPRING BRAKE ACTUATOR ASSY BS6	TATA spare parts
508743900103	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
508746305101	PITMAN ARM BS6	TATA spare parts
508746305102	PITMAN ARM BS6-PH2	TATA spare parts
508746600101	BRACKET ASSY RESERVOIR MTG	TATA spare parts

508746600102	BRACKET ASSY RESERVOIR MTG	TATA spare parts
508746600103	BRACKET ASSY RESERVOIR MTG	TATA spare parts
508746603301	BRACKET RESERVOIR SUPPORT BS6	TATA spare parts
508746603302	MTG.PLATE BS6	TATA spare parts
508746606901	PIPE BS6	TATA spare parts
508746607101	MTG.PLATE BS6	TATA spare parts
508746608201	CLAMP BS6	TATA spare parts
508746800101	SUCTION LINE ASSY BS6	TATA spare parts
508746800102	PRESSURE LINE ASSY BS6	TATA spare parts
508746800103	RETURN LINE ASSY RESERVOIR END	TATA spare parts
508746800104	RETURN LINE ASSY STG GEAR BOX END	TATA spare parts
508746800105	PRESSURE LINE ASSY BS6	TATA spare parts
508746800106	RETURN LINE ASSY GEAR BOX TO INT JOINT B	TATA spare parts
508747600101	SUCTION PIPE ASSY TANK TO PRE-FILTER BS6	TATA spare parts
508747600102	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
508747600103	FUEL RETURN PIPE ASSY BS6	TATA spare parts
508747600105	FUEL RETURN PIPE ASSY HP PUMP TO T-CONN	TATA spare parts
508747600106	SUCTION PIPE ASSY FILTER TO PUMP BS6	TATA spare parts
508747600107	SUCTION LINE ASSY BS6	TATA spare parts
508747600108	FUEL RETURN PIPE ASSY BS6	TATA spare parts
508749200101	STRUCTURE ASSY SILENCER MTG BS6	TATA spare parts
508749200102	EXHAUST PIPE ASSY BS6	TATA spare parts
508749200105	BRACKET ASSY STAY ROD MTG BS6	TATA spare parts
508749200107	BRACKET ASSY BS6	TATA spare parts
508749200109	EXHAUST PIPE ASSY WITH BELLOW BS6	TATA spare parts
508749200116	BRACKET ASSY SM MTG BS6	TATA spare parts
508749200126	BRACKET ASSY BS6	TATA spare parts
508749200129	RETURN LINE DM TO TANK BS6	TATA spare parts
508749200132	PRESSURE LINE SM TO DM BS6	TATA spare parts
508749203305	SUPPORT BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
508749203306	L-BRACKET EXHAUST MTG BS6	TATA spare parts
508754304901	FUEL LEVEL SENSOR BS6	TATA spare parts
508754600101	WIRING HARNESS SCR UNIT BS6	TATA spare parts
508754600102	WIRING HARNESS TAIL BS6	TATA spare parts
508754600103	WIRING HARNESS EGP PIGTAIL BS6	TATA spare parts
508754600105	BATTERY CABLE -VE BATTERY TO SM BS6	TATA spare parts
50875538000RCK	ASSY CAB KIT SIGNA 2821.K BS6	TATA spare parts
50880568000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 4925 BS6	TATA spare parts
50881568000RCK	ASSY CABIN KIT W/FITMENT SIGNA 4825.T BS	TATA spare parts
50881868100RCK	CABIN KIT W/FITMANTS SIGNA 4925.T AC BS6	TATA spare parts
508824200101	REAR MOUNT	TATA spare parts
508824200104	REAR MOUNT BS6 PH2	TATA spare parts
508829300101	CLUTCH BOOSTER ASSY BS6	TATA spare parts
508831000108	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508831000110	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508831000118	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508831000122	FRAME ASSY WITH FITMENT BS6	TATA spare parts

508831000131	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508831000140	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508831000142	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508831000144	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508831000162	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508831000172	FRAME ASSY WITH FITMENT BS6	TATA spare parts
508831107115	REINFORCEMENT RH BS6	TATA spare parts
508831107116	REINFORCEMENT LH BS6	TATA spare parts
508833000101	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
508833000103	FRONT AXLE ASSY WITH BRAKE FRT FWD BS6	TATA spare parts
508833000104	FRONT AXLE ASSY WITH BRAKE FRT RWD BS6	TATA spare parts
508833000109	TAG AXLE ASSY WITH BRAKE BS6	TATA spare parts
508833000116	FRONT AXLE ASSY WITH BRAKE FRT FWD BS6	TATA spare parts
508833000117	FRONT AXLE ASSY WITH BRAKE FRT RWD BS6	TATA spare parts
50883368000RCK	ASSY COWL KIT W/FITMENTS LPT 4925 BS6	TATA spare parts
508833805102	TIE ROD ARM LH BS6	TATA spare parts
508833805103	TIE ROD ARM RH BS6	TATA spare parts
508833805105	STEERING ARM BS6	TATA spare parts
508833900142	KIT-NYLON PIPES BS6	TATA spare parts
508833900145	KIT-LIFT AXLE BS6	TATA spare parts
508833900146	AXLE BEAM ASSY BS6	TATA spare parts
508833900151	KIT-NYLON PIPES BS6	TATA spare parts
508833900178	KIT-NYLON PIPES BS6	TATA spare parts
508833900195	PIPE BUNCH ASSY BS6	TATA spare parts
508833900216	PIPE BUNCH ASSY BS6	TATA spare parts
508833900262	BRACKET ASSY MAIN BELLOW MTG LH BS6	TATA spare parts
508833900263	BRACKET ASSY MAIN BELLOW MTG RH BS6	TATA spare parts
508833900283	PIPE BUNCH ASSY BS6	TATA spare parts
508833900347	LIFT AXLE BEAM ASSY BS6	TATA spare parts
508833900350	LIFT AXLE BEAM ASSY BS6	TATA spare parts
508833900354	AXLE BEAM BS6-PH2	TATA spare parts
508833900358	LIFT AXLE ASSY BS6-PH2	TATA spare parts
508833900370	KIT-LIFT AXLE BS6	TATA spare parts
508833900374	BRACKET RH BS6-PH2	TATA spare parts
508833900378	AIR SPRING MTG LH BS6-PH2	TATA spare parts
508833900379	AIR SPRING MTG RH BS6-PH2	TATA spare parts
508833900382	BRACKET LH BS6-PH2	TATA spare parts
508833903306	HANGER RH BS6-PH2	TATA spare parts
508833903307	HANGER LH BS6-PH2	TATA spare parts
508833909901	MAIN AIR SPRING BS6	TATA spare parts
508833909902	LIFT AIR SPRING ASSY BS6	TATA spare parts
50883668000RCK	ASSY COWL KIT W/FITMENTS LPT 4825 BS6	TATA spare parts
508841100106	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508841100107	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508841110109	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508841110110	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
508841110113	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts



50884110114	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
50884110126	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
50884110128	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
50884110129	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
50884110132	PROPELLER SHAFT ASSY-COUPLING BS6	TATA spare parts
50884110133	PROPELLER SHAFT ASSY-COUPLING BS6	TATA spare parts
50884110134	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
50884110139	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
50884120105	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
50884120109	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
50884120110	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
50884120119	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
50884120120	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
50884120122	PROPELLER SHAFT ASSY-DRIVE BS6	TATA spare parts
50884120123	PROPELLER SHAFT ASSY-DRIVE BS6	TATA spare parts
508841300103	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
508841300104	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
508841300105	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
508841300111	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
508841300112	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
508841300113	CENTER BEARING WITH HONEYCOMB BS6	TATA spare parts
508841303304	BRACKET CENTER BRG MTG BS6	TATA spare parts
508841303305	BRACKET CENTER BRG MTG BS6	TATA spare parts
508841303307	BRACKET CENTER BRG MTG BS6	TATA spare parts
508841303309	BRACKET CENTER BRG MTG BS6	TATA spare parts
508841303310	BRACKET CENTER BRG MTG BS6	TATA spare parts
508841303311	BRACKET CENTER BRG MTG BS6	TATA spare parts
508841990112	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
508841990114	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
508841990115	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
508841990121	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
508841990122	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
508841990135	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
508841990140	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
508841990149	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
508842100141	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
508842100142	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
508842100143	DRUM BRAKE ASSY WITH DC REAR-LH (HC AF 1	TATA spare parts
508842100144	DRUM BRAKE ASSY WITH DC REAR-RH (HC AF 1	TATA spare parts
508842100169	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
508842100170	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
508842100179	DRUM BRAKE ASSY WITH DC FRONT-LH BS6-PH2	TATA spare parts
508842100180	DRUM BRAKE ASSY WITH DC FRONT-RH BS6-PH2	TATA spare parts
508842300239	AUTO SLACK ADJUSTER ASSY BS6 PH2	TATA spare parts
508842300249	AUTO SLACK ADJUSTER ASSY RH BS6-PH2	TATA spare parts
508842300250	AUTO SLACK ADJUSTER ASSY LH BS6-PH2	TATA spare parts
508842300251	AUTO SLACK ADJUSTER ASSY RH BS6-PH2	TATA spare parts

508842300252	AUTO SLACK ADJUSTER ASSY LH BS6-PH2	TATA spare parts
508842300255	BRACKET ASSY BRAKE CHAMBER MTG LH BS6	TATA spare parts
508842300256	BRACKET ASSY BRAKE CHAMBER MTG RH BS6	TATA spare parts
508842300267	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
508842300268	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
508842300289	DRUM BRAKE ASSY WITH DC REAR-LH BS6 PH2	TATA spare parts
508842300290	DRUM BRAKE ASSY WITH DC REAR-RH BS6 PH2	TATA spare parts
508842300291	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508842300292	DRUM BRAKE ASSY REAR-LH BS6	TATA spare parts
508842300296	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508842300297	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508842300298	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508842300299	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508842310201	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
508842310202	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508842310207	DRUM BRAKE ASSY WITH DC REAR-LH BS6 PH2	TATA spare parts
508842310208	DRUM BRAKE ASSY WITH DC REAR-RH BS6 PH2	TATA spare parts
508842310209	DRUM BRAKE ASSY WITH DC REAR-LH BS6-PH2	TATA spare parts
508842310210	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
508842310211	DRUM BRAKE ASSY WITH DC REAR-LH BS6 PH2	TATA spare parts
508842310212	DRUM BRAKE ASSY WITH DC REAR-RH BS6 PH2	TATA spare parts
508842310215	DRUM BRAKE ASSY WITH DC REAR-LH BS6 PH2	TATA spare parts
508842310216	DRUM BRAKE ASSY WITH DC REAR-RH BS6 PH2	TATA spare parts
508842310217	DRUM BRAKE ASSY WITH DC REAR-RH BS6-PH2	TATA spare parts
508843200112	AIR TANK ASSY BS6	TATA spare parts
508843200114	AIR TANK ASSY WITH BKTS & STRAP BS6	TATA spare parts
508843200115	AIR TANK ASSY WITH BKTS & STRAP BS6	TATA spare parts
508843200116	AIR TANK ASSY BS6	TATA spare parts
508843200117	BRACKET ASSY BS6	TATA spare parts
508843200118	BRACKET ASSY AIR TANK MTG LH BS6	TATA spare parts
508843200119	AIR TANK ASSY BS6	TATA spare parts
508843200136	AIR TANK ASSY BS6	TATA spare parts
508843200138	AIR TANK ASSY WITH BKTS & STRAP BS6-PH2	TATA spare parts
508843200140	AIR TANK ASSY BS6-PH2	TATA spare parts
508843200142	AIR TANK ASSY BS6 PH2	TATA spare parts
508843200145	AIR TANK ASSY BS6-PH2	TATA spare parts
508843200155	AIR TANK ASSY BS6	TATA spare parts
508843700123	RELAY VALVE BS6	TATA spare parts
508843700125	ANTI COMPOUNDING RELAY VALVE BS6-PH2	TATA spare parts
508843700137	RELAY VALVE & MODULATOR VALVE ASSY W BKT	TATA spare parts
508843700146	RELAY VALVE BS6	TATA spare parts
508843700151	RELAY VALVE ASSY WITH BRACKET BS6-PH2	TATA spare parts
508843700155	RELAY VALVE ASSY WITH BRACKET BS6-PH2	TATA spare parts
508843900159	PIPE BUNCH ASSY BS6	TATA spare parts
508843900161	METAL PIPE ASSY BS6	TATA spare parts
508843900162	METAL PIPE ASSY BS6	TATA spare parts
508843900163	METAL PIPE ASSY BS6	TATA spare parts

508843900164	METAL PIPE ASSY BS6	TATA spare parts
508843900168	METAL PIPE ASSY WITH CRIMPED TEFLON HOSE	TATA spare parts
508843900170	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
508843900198	METAL PIPE ASSY BS6	TATA spare parts
508843900199	METAL PIPE ASSY BS6	TATA spare parts
508843910162	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
508843910174	BRACKET ASSY AIR TANK MTG BS6	TATA spare parts
508843910175	PIPE BUNCH ASSY BS6	TATA spare parts
508843920101	PIPE BUNCH ASSY BS6	TATA spare parts
508843920145	PIPE BUNCH ASSY BS6	TATA spare parts
508843920186	METAL PIPE ASSY WITH CRIMPED TEFLON HOSE	TATA spare parts
508843930102	PIPE BUNCH ASSY BS6	TATA spare parts
508843930163	PIPE BUNCH ASSY BS6	TATA spare parts
508843930197	PIPE BUNCH ASSY BS6	TATA spare parts
508846100102	STEERING COLUMN ASSY WITH MTG BRACKET BS	TATA spare parts
508846100103	SUPPORT BRACKET ASSY STG COLUMN MTG BS6	TATA spare parts
508846100105	STEERING COLUMN ASSY WITH TUBE BS6	TATA spare parts
508846100107	STEERING COLUMN ASSY BS6	TATA spare parts
508846200101	RUBBER BELLOW ASSY BS6	TATA spare parts
508846207701	RUBBER BELLOW BS6	TATA spare parts
508846208201	PLATE BELLOW BS6	TATA spare parts
508846303701	RELAY ARM BS6	TATA spare parts
508846303702	RELAY ARM BS6 PH2	TATA spare parts
508846305104	RELAY ARM BS6	TATA spare parts
508846305105	PITMAN ARM BS6	TATA spare parts
508846305106	PITMAN ARM BS6	TATA spare parts
508846305108	PITMAN ARM BS6 PH2	TATA spare parts
508846305109	PITMAN ARM BS6-PH2	TATA spare parts
508846305110	PITMAN ARM BS6 PH2	TATA spare parts
508846305113	PITMAN ARM BS6	TATA spare parts
508846600101	STEERING PUMP BS6	TATA spare parts
508846600106	POWER STEERING GEAR ASSY BS6-PH2	TATA spare parts
508846700101	BRACKET ASSY RESERVOIR MTG BS6	TATA spare parts
508846703302	Z-BRACKET BS6	TATA spare parts
508846703303	BRACKET BS6	TATA spare parts
508846703305	BRACKET BS6	TATA spare parts
508846800101	HIGH PRESSURE LINE ASSY GB TO P/CYL BS6	TATA spare parts
508846800103	RETURN LINE ASSY BS6	TATA spare parts
508846800104	SUCTION LINE ASSY BS6	TATA spare parts
508846800105	HIGH PRESSURE LINE ASSY P/CYL TO GB BS6	TATA spare parts
508846800112	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
508846800114	RETURN LINE ASSY GEAR BOX TO INT JOINT B	TATA spare parts
508846800115	PRESSURE LINE ASSY BS6	TATA spare parts
508846800116	SUCTION LINE ASSY BS6	TATA spare parts
508846800117	HIGH PRESSURE LINE ASSY GB TO P/CYL BS6	TATA spare parts
508846800118	HIGH PRESSURE LINE ASSY P/CYL TO GB BS6	TATA spare parts
508846800119	PRESSURE LINE ASSY BS6	TATA spare parts

508846800120	RETURN LINE ASSY BS6	TATA spare parts
508846800121	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
508846800122	SUCTION LINE ASSY BS6	TATA spare parts
508846800123	SUCTION LINE ASSY BS6	TATA spare parts
508846800124	RETURN LINE ASSY BS6	TATA spare parts
508846800125	RETURN LINE ASSY-INT JOINT TO RESERVOIR	TATA spare parts
508846800126	RETURN LINE ASSY STG GEAR BOX TO JOINT	TATA spare parts
508846800127	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
508846800128	RETURN LINE ASSYBS6	TATA spare parts
508846800129	HIGH PRESSURE LINE ASSY P/CYL TO GBBS6	TATA spare parts
508846800131	HIGH PRESSURE LINE ASSY GB TO P/CYLBS6	TATA spare parts
508846800132	PRESSURE LINE ASSYBS6	TATA spare parts
508846803301	BRACKET BS6	TATA spare parts
508846803302	BRACKET BS6	TATA spare parts
508846900101	DRAG LINK ASSY-FRONT BS6	TATA spare parts
508846900102	RELAY ROD ASSY BS6	TATA spare parts
508846900103	DRAG LINK ASSY FRONT BS6	TATA spare parts
508846900120	RELAY ROD ASSY BS6	TATA spare parts
508846900122	DRAG LINK ASSY REAR BS6	TATA spare parts
508846990110	KIT-HOUSING ASSY BS6	TATA spare parts
508846990111	CARTRIDGE ASSY BS6	TATA spare parts
508846990161	HOUSING ASSY BS6-PH2	TATA spare parts
508846990164	KIT-AUTO POPPET VALVE BS6-PH2	TATA spare parts
508846990165	HOUSING ASSY BS6-PH2	TATA spare parts
508847100103	FUEL TANK ASSY W/O TANK UNIT BS6	TATA spare parts
508847100106	AUXILARY FUEL TANK ASSY BS6	TATA spare parts
508847106901	TUBE BS6	TATA spare parts
508847600102	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
508847600105	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
508847600106	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
508847600107	FUEL PIPE ASSY FUEL TANK INTERCONNECTION	TATA spare parts
508847600108	FUEL PIPE ASSY FUEL TANK INTERCONNECTION	TATA spare parts
508847600109	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
508847600110	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
508847600111	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
508849200103	EXHAUST PIPE ASSY FIRST BS6	TATA spare parts
508849200105	CLAMP ASSY EGP MTG BS6	TATA spare parts
508849200107	BRACKET ASSY EXHAUST PIPE SUPPORT BS6	TATA spare parts
508849200108	BRACKET ASSY BS6	TATA spare parts
508849200110	SUPPORT ASSY BS6	TATA spare parts
508849200114	BRACKET ASSY UREA TANK MTG BS6	TATA spare parts
508849200123	PRESSURE LINE;SM TO DM BS6	TATA spare parts
508849200124	RETURN LINE;DM TO TANK BS6	TATA spare parts
508849200125	RETURN LINE;DM TO TANK BS6	TATA spare parts
508849200128	BRACKET ASSY EXHAUST PIPE SUPPORT BS6	TATA spare parts
508849200129	EXHAUST PIPE ASSY FIRST BS6	TATA spare parts
508849200130	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts

508849200131	EXHAUST PIPE ASSY THIRD BS6	TATA spare parts
508849200132	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
508849200133	EXHAUST PIPE ASSY - BS6	TATA spare parts
508849200139	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
508849200141	BRACKET ASSY BS6 PH2	TATA spare parts
508849200143	RETURN LINE DM TO TANK BS6	TATA spare parts
508849200145	PRESSURE LINE SM TO DM BS6	TATA spare parts
508849203310	BRACKET SUPPORT BS6	TATA spare parts
508849203311	BRACKET SUPPORT BS6	TATA spare parts
508849203329	BRACKET EXHAUST PIPE SUPPORT BS6	TATA spare parts
508849203330	BRACKET EXHAUST PIPE SUPPORT BS6	TATA spare parts
508849203334	L-BRACKET EXHAUST PIPE MTG	TATA spare parts
508849206904	EXHAUST TAIL PIPE	TATA spare parts
508849208202	COVER FRONT BS6	TATA spare parts
508849208203	PROTECTION SHIELD BS6	TATA spare parts
508849208204	COVER TOP BS6	TATA spare parts
508849990101	HEAT SHIELD ASSY BS6	TATA spare parts
50885368500RCK	ASSY COWL KIT W/FITMENTS LPT 4825 BS6	TATA spare parts
508854504901	SWITCH LIFT AXLE REAR BS6	TATA spare parts
508854504902	SWITCH DIFFERENTIAL LOCK BS6	TATA spare parts
508854504903	SWITCH REGENERATION INHIBIT BS6	TATA spare parts
508854504904	SWITCH REGENERATION START MANUAL BS6	TATA spare parts
508854600108	WIRING HARNESS TAIL BS6	TATA spare parts
508854600114	WIRING HARNESS-TAIL BS6	TATA spare parts
508854603301	BRACKET WIRING HARNESS MTG BS6 PH2	TATA spare parts
508854610102	WIRING HARNESS MAIN BS6	TATA spare parts
508854610105	WIRING HARNESS RPAS BS6	TATA spare parts
508854610106	WIRING HARNESS MAIN BS6	TATA spare parts
508854630101	WIRING HARNESS ABS FRAME BS6	TATA spare parts
508854630102	WIRING HARNESS TAIL BS6	TATA spare parts
508854630103	WIRING HARNESS TAIL BS6	TATA spare parts
508854630104	WIRING HARNESS TAIL BS6	TATA spare parts
508854630105	WIRING HARNESS SCR UNIT BS6	TATA spare parts
508854630106	WIRING HARNESS TAIL BS6	TATA spare parts
508854630107	WIRING HARNESS TAIL BS6	TATA spare parts
508854630114	WIRING HARNESS SCR UNIT BS6	TATA spare parts
508854630115	WIRING HARNESS-ABS FRAME BS6	TATA spare parts
508854640101	WIRING HARNESS-BATTERY -VE BS6	TATA spare parts
508854640102	WIRING HARNESS-BATTERY +VE BS6	TATA spare parts
50885468000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 4825 BS6	TATA spare parts
508854709901	STEERING ANGLE SENSOR BS6-PH2	TATA spare parts
508854719901	TELEMATICS UNIT BS6 PH2	TATA spare parts
508854820102	KIT-WINDSHIELD WASHER UNIT BS6	TATA spare parts
508854820103	TUBE ASSY BS6	TATA spare parts
508854823301	BRACKET WASHER BOTTLE MTG BS6	TATA spare parts
508854829904	PIGTAIL BS6	TATA spare parts
50886468000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 4825 BS6	TATA spare parts

50887168000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 4825.T B	TATA spare parts
50888168000RCK	ASSY COWL KIT W/FITMENTS LPT 4825 BS6	TATA spare parts
508929300101	BUNDY TUBE LONG MEMBER	TATA spare parts
508931000102	FRAME ASSY WITH FITMENT	TATA spare parts
508931000106	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
508931200101	CROSS MEMBER ASSY BS6	TATA spare parts
508931200103	END CROSS MEMBER ASSY BS6	TATA spare parts
508931200109	BRACKET ASSY	TATA spare parts
508931200114	BRACKET ASSY	TATA spare parts
508931207101	CROSS MEMBER BS6	TATA spare parts
508931208201	CHEQUERED PLATE	TATA spare parts
508931307107	SUPPORT TOP-RH BS6	TATA spare parts
508931307108	SUPPORT TOP RH BS6	TATA spare parts
508931407113	L-REINFORCEMENT BS6	TATA spare parts
508932100103	FRONT SPRING ASSY	TATA spare parts
508932100105	BRACKET SHOCK ABSORBER MTG ASSY - BS6	TATA spare parts
508932100106	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
508932100109	ASSEMBLY BUMP STOPPER (FRONT) BS6	TATA spare parts
508932103201	CENTER BOLT BS6	TATA spare parts
508932107102	CLAMP LEAF SPRING BS6	TATA spare parts
508932107103	PACKING PLATE BS6	TATA spare parts
508932107105	PACKING PLATE BS6	TATA spare parts
508932107106	2ND LEAF BS6	TATA spare parts
508932107107	3RD LEAF BS6	TATA spare parts
508933000101	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
508934200102	SUBSTRUCTURE ASSY FIFTH WHEEL COUPLING	TATA spare parts
508934200103	RAMP ASSY FIFTH WHEEL COUPLING RH	TATA spare parts
508934200104	RAMP ASSY FIFTH WHEEL COUPLING LH	TATA spare parts
508934200105	L PLATE ASSEMBLY LH	TATA spare parts
508934200106	L PLATE ASSEMBLY RH	TATA spare parts
508934207104	PLATE	TATA spare parts
508940307101	PLATE	TATA spare parts
508941120101	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
508941990101	SHORT FORK TUBE ASSY BS6	TATA spare parts
508943200107	AIR TANK ASSY BS6	TATA spare parts
508943200108	AIR TANK ASSY BS6	TATA spare parts
508943700104	BRACKET ASSY	TATA spare parts
508943700118	QUICK RELEASE VALVE BS6	TATA spare parts
508943703306	BRACKET BS6-PH2	TATA spare parts
508943708201	BRACKET	TATA spare parts
508943900102	BUNCH PIPE ASSY	TATA spare parts
508943900103	PIPE BUNCH ASSY CABIN	TATA spare parts
508943900152	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
508943900153	METAL PIPE ASSY	TATA spare parts
508943900154	METAL PIPE ASSY	TATA spare parts
508943900155	METAL PIPE ASSY	TATA spare parts
508943900156	METAL PIPE ASSY	TATA spare parts

508943900179	BUNCH PIPE ASSY BS6	TATA spare parts
508943900182	METAL PIPE ASSY BS6	TATA spare parts
508943900183	METAL PIPE ASSY BS6	TATA spare parts
508947600102	FUEL SUCTION PIPE ASSY	TATA spare parts
508947600103	SUCTION PIPE T-CONN-3 TO FUEL FILTER	TATA spare parts
508947600105	RETURN PIPE ASSY FEED PUMP TO FUEL TANK	TATA spare parts
508947600106	FUEL SUCTION PIPE ASSY FILTER TO FIP	TATA spare parts
508947600107	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
508947600108	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
508947600109	SUCTION PIPE T-CONN-3 TO FUEL FILTER BS6	TATA spare parts
508947600110	FUEL SUCTION PIPE ASSY FILTER TO HP PUMP	TATA spare parts
508947600111	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
508947600112	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
508947600113	SUCTION PIPE ASSY FILTER TO FEED PUMP	TATA spare parts
508947600117	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
508947600119	FUEL RETURN PIPE ASSY-ENG TO FUEL TANK B	TATA spare parts
508947700101	BRACKETASSYFILTERMTG BS6	TATA spare parts
508949200101	PIPE ASSY CATCON INTAKE	TATA spare parts
508949200102	EXHAUST PIPE ASSY ELBOW TO EXHAUST BRAKE	TATA spare parts
508949200103	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
508949200105	TAIL PIPE ASSY	TATA spare parts
508949200106	PIPE ASSY CATCON OUTLET	TATA spare parts
508949200107	EXHAUST PIPE INTERMEDIATE	TATA spare parts
508949200111	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
508949200114	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
508949200115	PRESSURE LINE SM TO DM BS6	TATA spare parts
508949200121	BRACKET ASSY BS6-PH2	TATA spare parts
508949203301	BRACKET EXHAUST BRAKE MTG	TATA spare parts
508949203302	BRACKET CATCON MTG	TATA spare parts
508949203303	BRACKET SUPPORT BS6	TATA spare parts
508949203304	BRACKET EXHAUST PIPE BS6	TATA spare parts
508949203305	BRACKET TAIL PIPE MTG BS6	TATA spare parts
508949203306	BRACKET NOISE SHIELD MTG	TATA spare parts
508949203307	BRACKET NOISE SHIELD MTG	TATA spare parts
508949203308	PLATE	TATA spare parts
508949203316	L-BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
508949207102	SPACER PLATE BS6	TATA spare parts
508949208201	BRACKET BOTTOM	TATA spare parts
508949990101	HEAT SHIELD	TATA spare parts
508954200103	INSTRUMENT CLUSTER ASSY	TATA spare parts
508954600101	WIRING HARNESS FRONT CHASSIS	TATA spare parts
508954600102	WIRING HARNESS REAR CHASSIS	TATA spare parts
508954600103	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
508954600112	WIRING HARNESS ABS FRAME	TATA spare parts
508954600119	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
508954600121	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
508954600122	BATTERY CABLE -VE BS6	TATA spare parts

508954600124	WIRING HARNESS ABS FRAME BS6	TATA spare parts
508954600126	STARTER CABLE BS6	TATA spare parts
508954603302	BRACKET JUMPER CABLE MTG BS6	TATA spare parts
508954606301	FUSE BOX COVER & STICKER ASSY	TATA spare parts
508954609901	STICKER FUSE & RELAY BOX	TATA spare parts
508954609902	STICKER MAXI FUSE BOX	TATA spare parts
508954630109	WIRING HARNESS EGP PIGTAIL BS6-PH2	TATA spare parts
508954640103	BATTERY CABLE -VE BS6-PH2	TATA spare parts
508954700102	BRACKET ASSY VEHICLE TRACKING ASSY MTG	TATA spare parts
508954850104	BRACKET ASSY CONTROLLER MTG BS6-PH2	TATA spare parts
508954850105	DMS CAMERA	TATA spare parts
50896000005R40	ULTRA EX 3021.S BS-VI _CAB/COWL BS6	TATA spare parts
509000990102	KIT FULLY TRIMMED COWL FOR LPT 4823 BS4	TATA spare parts
509031000102	FRAME ASSY WITH FITMENT	TATA spare parts
509031000103	FRAME ASSY WITH FITMENT	TATA spare parts
509031107113	REINFORCEMENT RH	TATA spare parts
509031107114	REINFORCEMENT LH	TATA spare parts
509033900129	BRACKET ASSY PIVOT MTG BS6	TATA spare parts
509033900207	BRACKET ASSY BS6	TATA spare parts
509033900213	CHAIN ASSY REBOUND BS6	TATA spare parts
509033900278	PIPE BUNCH ASSY BS6	TATA spare parts
509033903201	HEX SCREW	TATA spare parts
509033905103	BRACKET REBOUND CHAIN MTG BS6	TATA spare parts
509033905105	BRACKET REBOUND CHAIN MTG BS6	TATA spare parts
509033905106	BRACKET BS6	TATA spare parts
509033906501	CASTLE NUT 1 1/4INCH UNF THREADS 14 TPI	TATA spare parts
509033906701	PIN BS6	TATA spare parts
509033906702	PIN BS6	TATA spare parts
509033907103	BUSH PIVOT BOLT LOCKING	TATA spare parts
509033907104	HANGER OUTER BUSH	TATA spare parts
509033909001	RELAY VALVE ASSY	TATA spare parts
509033909901	REBOUND STRAP	TATA spare parts
509033990201	KIT-RETRO FITMENT BS6	TATA spare parts
509033990203	KIT-RETRO FITMENT FOR REBOUND CHAIN ASSY	TATA spare parts
509041100101	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
509041100102	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
509041120101	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
509041120107	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
509041300101	CB BRACKET ASSY. WITH WELDED RIBS	TATA spare parts
509041303302	BRACKET CENTER BRG MTG BS6	TATA spare parts
509041303303	BRACKET CENTER BRG MTG	TATA spare parts
509041990103	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
509041990104	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
509041990105	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
509041990111	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
509043200104	AIR TANK ASSY	TATA spare parts
509043200113	AIR TANK ASSY WITH BKTS & STRAP BS6	TATA spare parts



509043200117	AIR TANK ASSY WITH BKT	TATA spare parts
509043200119	AIR TANK ASSY WITH BKT BS6	TATA spare parts
509043200120	AIR TANK ASSY WITH BKT BS6	TATA spare parts
509043700103	AIR PROCESSING UNIT	TATA spare parts
509043700104	AIR PROCESSING UNIT	TATA spare parts
509043700112	AIR DRYER BS6	TATA spare parts
509043700124	BRACKET ASSY BS6	TATA spare parts
509043700146	BRACKET ASSY	TATA spare parts
509043700157	BRAKE CHAMBER BS6	TATA spare parts
509043700158	SPRING BRAKE ACTUATOR ASSY RH BS6	TATA spare parts
509043700159	SPRING BRAKE ACTUATOR ASSY LH BS6	TATA spare parts
509043700160	SPRING BRAKE ACTUATOR ASSY LH BS6	TATA spare parts
509043700161	SPRING BRAKE ACTUATOR ASSY RH BS6	TATA spare parts
509043700163	SPRING BRAKE ACTUATOR BS6	TATA spare parts
509043703302	BRACKET RELAY VALVE MTG BS6	TATA spare parts
509043900101	PIPE BUNCH ASSY	TATA spare parts
509043900136	NYLON PIPE BUNCH ASSY	TATA spare parts
509043910126	PIPE BUNCH ASSY	TATA spare parts
509047600101	FUEL SUCTION PIPE ASSY TANK TO W/SEP	TATA spare parts
509047600102	RETURN PIPE ASSY ENGINE TO FUEL TANK	TATA spare parts
509047600104	SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
509047600105	ASSY FUEL PIPE LINE (VALVE TO VALVE)	TATA spare parts
509047603301	CLAMP BRACKETBS6	TATA spare parts
509049200102	EXHAUST PIPE ASSY SECOND	TATA spare parts
509054200101	TELL-TALE INDICATOR	TATA spare parts
509054504901	SWITCH LIFT AXLE DISABLE	TATA spare parts
509054600103	WIRING HARNESS TAIL	TATA spare parts
509054600104	WIRING HARNESS TAIL	TATA spare parts
509054600105	WIRING HARNESS TAIL	TATA spare parts
509054709901	CONTROLLER GEAR SHIFT ADVISORY WITH LAC	TATA spare parts
50906000001R40	LPT 4823 CRE BSIV 10X2_CAB/COWL	TATA spare parts
50906000002R40	TATA SIGNA4823.T CRE BSIV 10X2_CAB/COWL	TATA spare parts
50907568000RCK	ASSY. CAB KIT SIGNA 4823.T BS4 SLP AC	TATA spare parts
509131000112	FRAME ASSY WITH SUSPENSION BRACKET BS6	TATA spare parts
509131000116	FRAME ASSY WITH SUSPENSION BRACKET BS6	TATA spare parts
509131117101	REINFORCEMENT CROSS MEMBER BS6	TATA spare parts
509131200101	CROSS MEMBER ASSY REAR SPRING BS6	TATA spare parts
509131200102	CROSS MEMBER ASSY BS6	TATA spare parts
509131200105	CROSS MEMBER ASSY BS6	TATA spare parts
509131307104	CROSS MEMBER BS6	TATA spare parts
509132100102	PARABOLIC LEAF SPRING ASSY BS6	TATA spare parts
509132100106	PARABOLIC LEAF SPRING ASSY BS6	TATA spare parts
509132103201	CENTER BOLT BS6	TATA spare parts
509132103701	GUIDE PLATE	TATA spare parts
509132104201	U-BOLT BS6	TATA spare parts
509132104202	U-BOLT BS6	TATA spare parts
509132107102	PACKING PLATE BS6	TATA spare parts

509132107103	PACKING PLATE BS6	TATA spare parts
509133000101	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
509133105101	FRONT AXLE BEAM	TATA spare parts
509141100101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
509141110104	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
509141110105	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
509141120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
509141120106	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
509141120107	LONG FORK ASSY PROPELLER SHAFT BS6	TATA spare parts
509141303301	BRACKET CENTER BRG MTG BS6	TATA spare parts
509141303302	BRACKET CENTER BRG MTG BS6	TATA spare parts
509141990107	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
509141990108	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
509141990116	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
509141990118	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
509143700109	BRACKET ASSY APU MTG BS6-PH2	TATA spare parts
509143900125	PIPE BUNCH ASSY CABIN BS6	TATA spare parts
509143900149	METAL PIPE ASSY BS6	TATA spare parts
509143900150	METAL PIPE ASSY BS6	TATA spare parts
509143900151	METAL PIPE ASSY BS6	TATA spare parts
509143900152	METAL PIPE ASSY BS6	TATA spare parts
509143900153	METAL PIPE ASSY BS6	TATA spare parts
509143900160	PIPE BUNCH ASSY BS6	TATA spare parts
509143900166	PIPE BUNCH ASSY BS6	TATA spare parts
509146305101	PITMAN ARM	TATA spare parts
509146600101	STEERING GEAR BOX ASSY	TATA spare parts
509146600102	SECTOR SHAFT ASSY	TATA spare parts
509146600103	WORM VALVE & RACK ASSY	TATA spare parts
509146600104	HOUSING ASSY	TATA spare parts
509146900101	DRAG LINK ASSY	TATA spare parts
509146900102	BALL JOINT ASSY	TATA spare parts
509146990104	SEAL KIT ASSY	TATA spare parts
509147100101	FUEL TANK ASSY BS6	TATA spare parts
509147600101	FUEL TANK INTER CONNECTION HOSE ASSY	TATA spare parts
509147600102	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
509147600109	FUEL SUCTION PIPE ASSY FILTER TO HP PUMP	TATA spare parts
509147600111	FUEL RETURN PIPE ASSY ENGINE TO T-CONN B	TATA spare parts
509147600115	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
509147600117	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
509147600120	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
509147600121	PIPE ASSY FUEL TANK-1 TO FUEL TANK-2 BS6	TATA spare parts
509147600122	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
509147600123	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
509147600124	FUEL RETURN PIPE ASSY ENGINE TO T-CONN B	TATA spare parts
509147600125	FUEL RETURN PIPE ASSY CONN TO TANK BS6	TATA spare parts
509147600126	FUEL RETURN PIPE ASSY ENGINE TO CONN BS6	TATA spare parts
509147608201	BRACKET FUEL PIPE MTG BS6	TATA spare parts

509149200103	PIPE RETURN LINE BS6	TATA spare parts
509149200110	PRESSURE LINE SM TO DM BS6	TATA spare parts
509149203301	BRACKET TAIL PIPE MTG BS6	TATA spare parts
509154600112	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
509154600114	WIRING HARNESS ABS FRAME BS6	TATA spare parts
509154600115	WIRING HARNESS ABS FRAME BS6	TATA spare parts
509154600121	WIRING HARNESS ABS BS6	TATA spare parts
509154600122	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
509154700101	BRACKET ASSY CONTROLLER MTG	TATA spare parts
50916000006R40	ULTRA EX 2821.T 68 WB BSVI_CAB/COWL BS6	TATA spare parts
509631307107	CROSS MEMBER BRACKET BS6	TATA spare parts
509700990101	SPARE KIT TATA SIGNA 2823.TK CRE HD BSIV	TATA spare parts
50985153000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 3518.TK	TATA spare parts
509931000102	FRAME ASSY WITH FITMENT	TATA spare parts
509931000104	FRAME ASSY WITH FITMENT	TATA spare parts
50997268000RCK	ASSY. CAB KIT W/FITMENTS SIGNA 4223.TK A	TATA spare parts
51010542000R40	TATA LPT 1913 CRI6 BSIV_CAB/COWL	TATA spare parts
510131000101	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
510131000102	FRAME ASSY WITH FITMENT	TATA spare parts
510131000104	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
510131000105	FRAME ASSY WITH SUSPENSION BRACKET	TATA spare parts
510131000109	FRAME ASSY WITH FITMENT	TATA spare parts
510131200101	CROSS MEMBER ASSY WITH GUSSET	TATA spare parts
510131200102	CROSS MEMBER ASSY WITH GUSSET BS6	TATA spare parts
510131700101	EXTENSION PIECE ASSY FRONT-RH	TATA spare parts
510131700102	EXTENSION PIECE ASSY FRONT-LH	TATA spare parts
510146100101	BRACKET STG GEAR BOX MTG	TATA spare parts
510146305101	PITMAN ARM	TATA spare parts
510146800101	PRESSURE LINE ASSY	TATA spare parts
510146900102	DRAG LINK ASSY	TATA spare parts
510231200102	CROSS MEMBER ASSY	TATA spare parts
510231200107	C-CHANNEL CROSS MEMBER ASSY	TATA spare parts
510231200108	CROSS MEMBER ASSY	TATA spare parts
510231207101	REINFORCEMENT MIDDLE-BOTTOM-RH	TATA spare parts
510231207102	REINFORCEMENT MIDDLE-BOTTOM-LH	TATA spare parts
510231207103	L-REINFORCEMENT TOP-RH	TATA spare parts
510231207104	L-REINFORCEMENT TOP-LH	TATA spare parts
510231207105	REINFROCEMENT RH	TATA spare parts
510231207106	REINFROCEMENT LH	TATA spare parts
510231207108	REINFORCEMENT TOP-RH	TATA spare parts
510231207109	REINFORCEMENT TOP-LH	TATA spare parts
510231208201	SPACER PLATE BS6	TATA spare parts
510231208202	SPACER PLATE BS6	TATA spare parts
510231700102	BRACKET ASSY RADIATOR MTG RH BS6	TATA spare parts
510231700103	BRACKET ASSY RADIATOR MTG LH BS6	TATA spare parts
510246800101	RETURN LINE ASSY	TATA spare parts
510246800104	PRESSURE LINE ASSY	TATA spare parts

510331000101	FRAME ASSY WITH FITMENT	TATA spare parts
510331000104	FRAME ASSY WITH FITMENT	TATA spare parts
510331000106	FRAME ASSY WITH FITMENT	TATA spare parts
510333000101	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
510333200101	STUB AXLE ASSY ABS RH	TATA spare parts
510333200102	STUB AXLE ASSY ABS LH	TATA spare parts
510500990101	KIT FULLY BUILD STCAB LPT 2818 BS4 BLW	TATA spare parts
510531000105	FRAME ASSY WITH FITMENT	TATA spare parts
510543700103	DRYING & DISTRIBUTION UNIT	TATA spare parts
510543900103	PIPE BUNCH ASSY	TATA spare parts
510543930114	PIPE ASSY COMP TO JOINT-1	TATA spare parts
510543930115	PIPE ASSY INT JOINT TO INT JOINT	TATA spare parts
510543950128	PIPE ASSY INT JOINT TO INT JOINT	TATA spare parts
510545208201	L-BRACKET BS6	TATA spare parts
510545208202	BRACKET SOLENOID VALVE MTG BS6	TATA spare parts
510545700101	ADAPTER BS6	TATA spare parts
510547600104	RETURN PIPE ASSY ENGINE	TATA spare parts
510547600105	SUCTION PIPE ASSY FUEL	TATA spare parts
510547600106	SUCTION PIPE ASSY FUEL	TATA spare parts
510549100101	SPARK ARRESTER ASSY	TATA spare parts
510549200103	PIPE ASSY	TATA spare parts
510549200106	EXHAUST PIPE ASSY	TATA spare parts
510554100102	BATTERY CABLE +VE	TATA spare parts
510554208201	PLATE SWITCH MTG BS6	TATA spare parts
510554500101	REAR SWITCH MTG BOX BS6	TATA spare parts
510554504901	PIANO KEY SWITCH;RPM INCREMENT BS6	TATA spare parts
510554504902	PIANO KEY SWITCH;RPM DECREMENT BS6	TATA spare parts
510554508203	COVER BS6	TATA spare parts
510554600104	WIRING HARNESS SCR UNIT	TATA spare parts
510554600105	WIRING HARNESS MAIN	TATA spare parts
510554600106	WIRING HARNESS TAIL	TATA spare parts
510554600108	WIRING HARNESS ENGINE	TATA spare parts
510554600301	WIRING HARNESS ABS FRAME	TATA spare parts
51056000001R40	PARTIAL FITTED CAB WITHOUT FITMENT	TATA spare parts
51056000007R40	PARTIAL FITTED CAB WITHOUT FITMENT	TATA spare parts
510741120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
510741990101	SHORT FORK TUBE AND REAR HSG SUB ASSY B	TATA spare parts
510954600101	WIRING HARNESS TAIL	TATA spare parts
510954600102	PIGTAIL FUEL LEVEL SENSOR	TATA spare parts
510954600103	WIRING HARNESS SCR UNIT	TATA spare parts
510954600104	WIRING HARNESS TAIL	TATA spare parts
511254600101	WIRING HARNESS TAIL	TATA spare parts
511254600102	WIRING HARNESS MAIN	TATA spare parts
511254600104	WIRING HARNESS ENGINE	TATA spare parts
511254600106	WIRING HARNESS ABS FRAME	TATA spare parts
511441120102	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
511541120101	PROPELLER SHAFT ASSY BS6	TATA spare parts

511729300101	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
511729300102	NYLON PIPE ASSY BS6-PH2	TATA spare parts
511729300103	NYLON PIPE ASSY BS6	TATA spare parts
51173133000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 4018 BS6	TATA spare parts
51173233000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 4018 BS6	TATA spare parts
511733000101	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
511733105102	FRONT AXLE BEAM FRONT AXLE BEAM BS6	TATA spare parts
511733805101	STEERING ARM BS6	TATA spare parts
511733990101	ASSY.FRONT AXLE COMP.SET NORMAL BS6	TATA spare parts
511746305101	PITMAN ARM BS6	TATA spare parts
511746800101	SUCTION LINE ASSY BS6-PH2	TATA spare parts
511747100102	AUXILARY FUEL TANK ASSY BS6	TATA spare parts
511747600101	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
511747600102	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
511747608202	COVER BS6	TATA spare parts
511749200104	BRACKET ASSY BS6-PH2	TATA spare parts
511749203308	BRACKET TAIL PIPE MTG BS6-PH2	TATA spare parts
511754503301	BRACKET BS6	TATA spare parts
511754610101	PIGTAIL VEHICLE TRACKING SYSTEM BS6	TATA spare parts
511754620101	WIRING HARNESS PIGTAIL	TATA spare parts
511754630102	WIRING HARNESS TAIL BS6	TATA spare parts
51177733200RCK	ASSY CABIN KIT W/FITMENTS SIGNA 4018.S B	TATA spare parts
51177833000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 4018 BS6	TATA spare parts
511829300101	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
511829300105	PIPE ASSY INT JOINT TO BOOSTER HYD BS6-P	TATA spare parts
511829300108	BUNDY TUBE ASSY LONG MEMBER	TATA spare parts
511830100101	BRACKET ASSY ACCELERATOR PEDAL MTG BS6-P	TATA spare parts
511831000126	FRAME ASSY WITH FITMENT BS6	TATA spare parts
511831700111	BEAM ASSY FUPD BS6-PH2	TATA spare parts
511832100105	LEAF SPRING ASSY FRONT BS6-PH2	TATA spare parts
511832100106	1ST LEAF ASSY BS6-PH2	TATA spare parts
511832100110	SHACKLE ASSY BS6-PH2	TATA spare parts
511832100111	LEAF SPRING ASSY FRONT	TATA spare parts
511832103301	BRACKET FRONT SPRING MTG FRONT BS6-PH2	TATA spare parts
511832103302	BRACKET SPRING HANGER FRONT-REAR	TATA spare parts
511832103701	BRACKET SPRING HANGER FRONT	TATA spare parts
511832107102	2ND LEAF BS6-PH2	TATA spare parts
511832107103	3RD LEAF BS6-PH2	TATA spare parts
511832107104	4TH LEAF BS6-PH2	TATA spare parts
511832107112	SHACKLE BS6-PH2	TATA spare parts
511832200101	BUMP STOPPER ASSY FRONT BS6-PH2	TATA spare parts
511832303701	BRACKET SHOCK ABS MTG. ON AXLE - LH (FRT	TATA spare parts
511832303702	BRACKET SHOCK ABSORBER MTG FRONT-LH FROM	TATA spare parts
511832504201	U-BOLT SPRING ASSY BS6-PH2	TATA spare parts
511841100101	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
511841100102	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
511841100103	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts

511841100104	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
511841100105	PROPELLER SHAFT ASSY BS6	TATA spare parts
511841100106	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
511841300101	BRACKET ASSY CENTER BRG MTG	TATA spare parts
511841300102	BRACKET ASSY CENTER BRG MTG	TATA spare parts
511843800101	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
511843800103	METAL PIPE ASSY ADAPTER TO DDU	TATA spare parts
511843800104	METAL PIPE	TATA spare parts
511843800107	METAL PIPE ASSY ADAPTER TO DDU BS6	TATA spare parts
511843900129	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
511843900135	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
511846100102	STEERING COLUMN ASSY BS6-PH2	TATA spare parts
511846305101	PITMAN ARM BS6	TATA spare parts
511846305102	PITMAN ARM BS6-PH2	TATA spare parts
511846305103	PITMAN ARM BS6-PH2	TATA spare parts
511846600101	STEERING GEAR BOX ASSYBS6	TATA spare parts
511846600102	SECTOR SHAFT ASSY BS6	TATA spare parts
511846600103	WORM & VALVE HSG WITH RACK ASSY BS6	TATA spare parts
511846600104	HOUSING ASSY BS6	TATA spare parts
511846600106	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
511846600108	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
511846600113	HOUSING ASSY BS6-PH2	TATA spare parts
511846600114	PISTON ASSY BS6-PH2	TATA spare parts
511846600118	SEAL SHAFT BS6-PH2	TATA spare parts
511846600120	KIT-SEAL BS6-PH2	TATA spare parts
511846600121	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
511846600122	STEERING GEAR BOX ASSY	TATA spare parts
511846700101	BRACKET ASSY RESERVOIR MTG&BS6	TATA spare parts
511846700102	BRACKET ASSY RESERVOIR MTG BS6-PH2	TATA spare parts
511846703301	BRACKET STG GEAR BOX MTG BS6	TATA spare parts
511846703302	BRACKET STG GEAR BOX MTG BS6-PH2	TATA spare parts
511846800101	PRESSURE LINE ASSY BS6	TATA spare parts
511846800102	RETURN LINE ASSY BS6	TATA spare parts
511846800103	PRESSURE LINE ASSY BS6	TATA spare parts
511846800104	SUCTION LINE ASSY BS6	TATA spare parts
511846800105	HIGH PRESSURE LINE ASSY BS6-PH2	TATA spare parts
511846800106	RETURN LINE ASSY BS6-PH2	TATA spare parts
511846800108	SUCTION LINE ASSY BS6-PH2	TATA spare parts
511846800109	RETURN LINE ASSY BS6-PH2	TATA spare parts
511846800111	HIGH PRESSURE LINE ASSY BS6-PH2	TATA spare parts
511846800112	SUCTION LINE ASSY	TATA spare parts
511846800113	RETURN LINE ASSY	TATA spare parts
511846800115	HIGH PRESSURE LINE ASSY	TATA spare parts
511846900101	DRAG LINK ASSY BS6	TATA spare parts
511846900105	DRAG LINK ASSY BS6-PH2	TATA spare parts
511846900108	DRAG LINK ASSY	TATA spare parts
511846900109	DRAG LINK ASSY BS6-PH2	TATA spare parts

511846990104	KIT-SEAL BS6	TATA spare parts
511847600101	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
511847600103	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
511847600104	FUEL RETURN PIPE ASSY BS6	TATA spare parts
511847600106	FUEL RETURN PIPE ASSY BS6	TATA spare parts
511849200101	EXHAUST PIPE ASSY & FLANGE BS6	TATA spare parts
511849200102	EXT PIPE ASSY WITH FLEX BELLOW-FRONT BS6	TATA spare parts
511849200103	BRACKET ASSY FRONT PIPE MTG BS6	TATA spare parts
511849200105	UREA PIPE ASSY BS6	TATA spare parts
511849200106	EXHAUST PIPE ASSY FIRST	TATA spare parts
511849200107	KIT-EXHAUST PIPE HEAT SHIELD ASSY BS6	TATA spare parts
511849200108	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
511849200109	BRACKET ASSY FRONT PIPE MTG	TATA spare parts
511849200112	BRACKET ASSY EGP MTG BS6	TATA spare parts
511849200113	HEAT SHIELD ASSY	TATA spare parts
511849203302	BRACKET FRONT PIPE MTG BS6	TATA spare parts
511849203303	BRACKET FRONT PIPE MTG BS6	TATA spare parts
511849203304	BRACKET BS6	TATA spare parts
511849203306	BRACKET	TATA spare parts
511854600140	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
511854600141	WIRING HARNESS REAR CHASSIS	TATA spare parts
511858902601	DRIFT BS6-PH2	TATA spare parts
511858902603	DRIFT FOR INPUT SHAFT FITMENT ON FRONT H	TATA spare parts
51186000106R40	PARTIALLY FITTED CAB W/O ELECTICALS BS6	TATA spare parts
51186000107R40	PARTIALLY FITTED CAB W/O ELECTICALS BS6	TATA spare parts
51186000115R40	PARTIALLY FITTED CAB W/O ELECTICALS 1109	TATA spare parts
51186000122R40	PARTIALLY FITTED CAB W/O ELECTICALS 1109	TATA spare parts
51186000124R40	PARTIALLY FITTED CAB W/O ELECTRICALS BS6	TATA spare parts
51186000131R40	PARTIALLY FITTED CAB W/O ELECT&AMP CONTR	TATA spare parts
511870110201	SUPD ASSY LH BS6-PH2	TATA spare parts
511870110202	SUPD ASSY RH BS6-PH2	TATA spare parts
511870110203	SUPD ASSY RH	TATA spare parts
511870110204	SUPD ASSY LH	TATA spare parts
51190142000RCK	ASSY COWL KIT W/FITMENTS LPT1918 BS6	TATA spare parts
51190168000RCK	ASSY COWL KIT W/FITMENTS LPT1918TC BS6	TATA spare parts
511931000103	FRAME ASSY WITH FITMENT BS6	TATA spare parts
511931000105	FRAME ASSY WITH FITMENT BS6	TATA spare parts
511931000107	FRAME ASSY WITH FITMENT BS6	TATA spare parts
511931000111	FRAME ASSY WITH FITMENT BS6	TATA spare parts
511931000114	FRAME ASSY WITH FITMENT BS6	TATA spare parts
511931000120	FRAME ASSY WITH FITMENT BS6	TATA spare parts
511931107106	LONG MEMBER LH BS6	TATA spare parts
511931200103	CROSS MEMBER ASSY WITH GUSSET BS6	TATA spare parts
511931200112	CROSS MEMBER ASSY BS6	TATA spare parts
511931200113	CROSS MEMBER ASSY BS6	TATA spare parts
511931200121	CROSS MEMBER ASSY CENTER BEARING MTG BS6	TATA spare parts
511931200122	CROSS MEMBER ASSY BS6-PH2	TATA spare parts

511931207115	REINFROCEMENT RH BS6	TATA spare parts
511931207116	REINFROCEMENT LH BS6	TATA spare parts
511931207123	REINFROCEMENT RH BS6	TATA spare parts
511931207124	REINFROCEMENT LH BS6	TATA spare parts
511931208204	SUPPORT PLATE CROSS MEMBER MTG BS6	TATA spare parts
511931248201	SUPPORT PLATE ENGINE MTG BS6	TATA spare parts
511931307101	REINFORCEMENT BUMPER CROSS MEMBER RH BS6	TATA spare parts
511931307102	REINFORCEMENT BUMPER CROSS MEMBER LH BS6	TATA spare parts
511931307103	GUSSET PLATE TOP-RH BS6	TATA spare parts
511931307104	GUSSET PLATE TOP-LH BS6	TATA spare parts
511931307131	REINFORCEMENT BUMPER CROSS MEMBER RH BS6	TATA spare parts
511931307132	REINFORCEMENT BUMPER CROSS MEMBER LH BS6	TATA spare parts
511931700106	BRACKET ASSY RAIDATOR MTG RH BS6	TATA spare parts
511931700107	BRACKET ASSY RAIDATOR MTG LH BS6	TATA spare parts
511932407101	SPACER PLATE REAR BS6	TATA spare parts
511932407102	SPACER BS6	TATA spare parts
511933000101	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
511933000102	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
511933000104	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
511941100101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
511941100104	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
511941100106	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
511941100107	PROPELLER SHAFT ASSY-COUPLING BS6	TATA spare parts
511941120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
511941120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
511941120105	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
511941120106	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
511941303303	BRACKET CENTER BRG MTG BS6	TATA spare parts
511941990101	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
511941990106	SHORT FORK TUBE AND FRONT END PIECE BS6	TATA spare parts
511941990107	SHORT FORK TUBE AND REAR END PIECE BS6	TATA spare parts
511941990112	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
511943900101	PIPE BUNCH ASSY BS6	TATA spare parts
511943900139	PIPE BUNCH ASSY BS6	TATA spare parts
511943900141	METAL PIPE ASSY BS6	TATA spare parts
511943900142	METAL PIPE ASSY BS6	TATA spare parts
511943900143	METAL PIPE ASSY BS6	TATA spare parts
511943900146	METAL PIPE ASSY BS6	TATA spare parts
511943900161	PIPE BUNCH ASSY BS6	TATA spare parts
511946305101	PITMAN ARM BS6	TATA spare parts
511946305106	PITMAN ARM BS6	TATA spare parts
511946800101	PRESSURE LINE ASSY BS6	TATA spare parts
511947100101	AUXILARY FUEL TANK ASSY BS6	TATA spare parts
511947600101	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
511947600102	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
511947600103	RETURN FUEL PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
511947600104	FUEL PIPE ASSY FUEL TANK INTERCONNECTION	TATA spare parts



511947600105	PIPE ASSY TANK TO INT JOINT BS6	TATA spare parts
511947600106	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
511947600107	RETURN FUEL PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
511947600108	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
511947600110	FUEL PIPE ASSY FUEL TANK INTERCONNECTION	TATA spare parts
511947606804	COUPLING BODY	TATA spare parts
511949200101	BRACKET ASSY EGP MTG BS6	TATA spare parts
511949200102	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
511949200103	EXHAUST PIPE ASSY WITH HEAT SHIELD BS6	TATA spare parts
511949200105	RETURN LINE;DM TO TANK BS6	TATA spare parts
511949200107	BRACKET ASSY EGP MTG BS6	TATA spare parts
511949200109	EXHAUST PIPE ASSY WITH HEAT SHIELD BS6	TATA spare parts
511949200111	BRACKET ASSY EGP MTG BS6	TATA spare parts
511949200112	BRACKET ASSY BS6	TATA spare parts
511949605311	HEAT SHIELD ASSY BS6	TATA spare parts
511949605312	HEAT SHIELD ASSY BS6	TATA spare parts
511949990112	KIT-EXHAUST HEAT SHIELD	TATA spare parts
511954600101	WIRING HARNESS TAIL BS6	TATA spare parts
511954600102	WIRING HARNESS ABS FRAME BS6	TATA spare parts
511954600103	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
511954600104	WIRING HARNESS SCR UNIT BS6	TATA spare parts
511954630101	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
511954630106	WIRING HARNESS TAIL BS6	TATA spare parts
51196000011R40	PARTIALLY FITTED CAB SIGNA 1918.T BS6	TATA spare parts
51200148000RCK	ASSY COWL KIT W/FITMENTS LPT 1918 BS6	TATA spare parts
51200149000RCK	ASSY CAB WITH FITMENT ULTRA 1918.T BS6	TATA spare parts
51200168000RCK	ASSY COWL KIT W/FITMENTS LPT1918 BS6	TATA spare parts
51202368000RCK	ASSY COWL KIT W/FITMENTS ULTRA 1918.T BS	TATA spare parts
512029300102	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
512029300103	NYLON PIPE ASSY BS6-PH2	TATA spare parts
512029307501	GROMMET	TATA spare parts
512031000101	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
512031000102	FRAME ASSY W/O TOP COAT BS6	TATA spare parts
512031000103	FRAME ASSY WITH FITMENT BS6	TATA spare parts
512031000105	FRAME ASSY WITH FITMENT BS6	TATA spare parts
512031000107	FRAME ASSY WITH FITMENT BS6	TATA spare parts
512031000109	FRAME ASSY WITH FITMENT BS6	TATA spare parts
512031000111	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
512031000113	FRAME ASSY WITH FITMENT BS6	TATA spare parts
512031000116	FRAME ASSY WITH FITMENT BS6	TATA spare parts
512031000120	FRAME ASSY WITH FITMENT BS6	TATA spare parts
512031000125	FRAME ASSY WITH FITMENT BS6	TATA spare parts
512031107139	LONG MEMBER LH BS6-PH2	TATA spare parts
512031107140	LONG MEMBER RH BS6-PH2	TATA spare parts
512031200101	CROSS MEMBER ASSY ENGINE MTG FRONT BS6	TATA spare parts
512031200102	SUPPORT ASSY ENGINE CROSS MEMBER RH BS6	TATA spare parts
512031200103	SUPPORT ASSY ENGINE CROSS MEMBER LH BS6	TATA spare parts

512031200105	CROSS MEMBER ASSY BS6	TATA spare parts
512031200106	CROSS MEMBER ASSY WITH GUSSET BS6-PH2	TATA spare parts
512031200108	CROSS MEMBER ASSY WITH GUSSET BS6	TATA spare parts
512031207123	REINFORCEMENT REAR-RH BS6	TATA spare parts
512031207124	REINFORCEMENT REAR-LH BS6	TATA spare parts
512031207125	REINFORCEMENT REAR-RH BS6	TATA spare parts
512031207126	REINFORCEMENT REAR-LH BS6	TATA spare parts
512031700102	BRACKET ASSY RAIDATOR MTG RH BS6	TATA spare parts
512031700103	BRACKET ASSY RAIDATOR MTG LH BS6	TATA spare parts
512031700104	SUPPORT ASSY RADIATOR MTG RH BS6	TATA spare parts
512031700105	SUPPORT ASSY RADIATOR MTG LH BS6	TATA spare parts
512032400102	REAR SPRING ASSY BS6	TATA spare parts
512033000102	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
512033105102	FRONT AXLE BEAM BS6-PH2	TATA spare parts
512040300101	SPACER PLATE ASSY SPARE WHEEL MTG BKT BS	TATA spare parts
512041100101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512041100105	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512041100109	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512041100111	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512041100113	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512041110101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512041110102	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512041120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
512041120104	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
512041120108	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
512041120109	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
512041120113	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
512041120114	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
512041120115	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
512041120116	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
512041300101	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
512041300103	BRACKET ASSY CENTER BRG MTG	TATA spare parts
512041300105	BRACKET ASSY CENTER BRG MTG	TATA spare parts
512041303301	BRACKET CENTER BRG MTG BS6	TATA spare parts
512041303302	BRACKET CENTER BRG MTG BS6	TATA spare parts
512041303304	BRACKET CENTER BRG MTG BS6	TATA spare parts
512041303310	SPACER BS6	TATA spare parts
512041990101	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
512041990102	SHORT FORK TUBE AND FRONT END PIECE BS6	TATA spare parts
512041990103	SHORT FORK TUBE FRONT END PIECE ASSY BS6	TATA spare parts
512041990104	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
512041990117	SHORT FORK TUBE AND REAR END PIECE BS6	TATA spare parts
512041990119	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
512041990127	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
512043200103	AIR TANK ASSY BS6-PH2	TATA spare parts
512043700106	BRAKE AGGR ASSY BS6	TATA spare parts
512043700143	HANDBRAKE VALVE BS6	TATA spare parts

512043700162	COVER BS6	TATA spare parts
512043700163	COVER BS6	TATA spare parts
512043700167	ANTI ROLL BACK ASSY BS6	TATA spare parts
512043703301	BRACKET BS6-PH2	TATA spare parts
512043703303	BRACKET BS6-PH2	TATA spare parts
512043900103	METAL PIPE ASSY SECOND BS6	TATA spare parts
512043900104	METAL PIPE ASSY ADAPTER TO APU BS6	TATA spare parts
512043900106	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
512043900107	PIPE ASSY BS6	TATA spare parts
512043900133	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
512043900134	PIPE BUNCH ASSY CABIN BS6	TATA spare parts
512043900137	PIPE BUNCH ASSY BS6	TATA spare parts
512043900145	METAL PIPE ASSY BS6	TATA spare parts
512043900146	METAL PIPE ASSY BS6	TATA spare parts
512043900147	METAL PIPE ASSY BS6	TATA spare parts
512043900150	PIPE BUNCH ASSY BS6	TATA spare parts
512043900173	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
512043900183	PIPE BUNCH ASSY BS6	TATA spare parts
512043900185	BUNCH ASSY PIPE BS6	TATA spare parts
512043910105	METAL PIPE ASSY BS6	TATA spare parts
512043910106	METAL PIPE ASSY BS6	TATA spare parts
512043910107	METAL PIPE ASSY BS6	TATA spare parts
512043910108	METAL PIPE ASSY BS6	TATA spare parts
512043910109	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
512043910114	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
512043910148	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
512043910188	PIPE BUNCH ASSY BS6	TATA spare parts
512043910199	METAL PIPE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts
512043920142	METAL PIPE ASSY BS6-PH2	TATA spare parts
512043920188	METAL PIPE ASSY ADAPTER TO ADAPTER BS6-P	TATA spare parts
512043920189	METAL PIPE ASSY ADAPTER TO ADAPTER BS6-P	TATA spare parts
512043920191	METAL PIPE ASSY ADAPTER TO APU BS6-PH2	TATA spare parts
512043920193	METAL PIPE ASSY ADAPTER TO ADAPTER BS6-P	TATA spare parts
512043920194	METAL PIPE ASSY ADAPTER TO APU BS6-PH2	TATA spare parts
512043920195	METAL PIPE ASSY HOSE TO INT JT BS6-PH2	TATA spare parts
512043930103	METAL PIPE ASSY BS6-PH2	TATA spare parts
512043930110	METAL PIPE ASSY BS6-PH2	TATA spare parts
512043930114	METAL PIPE ASSY BS6-PH2	TATA spare parts
512046305101	PITMAN ARM	TATA spare parts
512046600101	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
512046800101	SUCTION LINE ASSY BS6	TATA spare parts
512046800102	PRESSURE LINE ASSY BS6	TATA spare parts
512046800103	RETURN LINE ASSY BS6	TATA spare parts
512046990114	KIT-AUTO POPPET VALVE BS6-PH2	TATA spare parts
512047100101	ASSY. FUEL TANK W/ TANK UNIT BS6	TATA spare parts
512047100102	FUEL TANK ASSY BS6	TATA spare parts
512047100104	FUEL TANK ASSY BS6	TATA spare parts

512047500101	BRACKET ASSY FUEL TANK MTG BS6	TATA spare parts
512047500102	HEAT SHIELD ASSY FOR FUEL TANK BS6	TATA spare parts
512047500105	BRACKET ASSY BS6	TATA spare parts
512047500106	BRACKET ASSY FUEL TANK MTG BS6	TATA spare parts
512047500108	SPACER BRACKET FUEL TANK BS6-PH2	TATA spare parts
512047507102	SPACER BS6	TATA spare parts
512047508206	GUARD BASE FUEL TANK BS6	TATA spare parts
512047600101	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
512047600102	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
512047600103	FUEL RETURN PIPE ASSY HP PUMP TO T-CONN	TATA spare parts
512047600104	FUEL RETURN PIPE ASSY BS6	TATA spare parts
512047600106	SUCTION PIPE ASSY FUEL FTR TO PRIM PUMP	TATA spare parts
512047600108	SUCTION PIPE FILTER TO PUMP BS6	TATA spare parts
512047600109	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
512047600110	FUEL RETURN PIPE ASSY ENGINE TO T-CONN B	TATA spare parts
512047600118	FUEL PIPE ASSY FUEL TANK INTERCONNECTION	TATA spare parts
512047600119	PIPE ASSY TANK TO INT JOINT BS6	TATA spare parts
512047600120	FUEL PIPE ASSY FUEL TANK INTERCONNECTION	TATA spare parts
512047600121	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
512047600122	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
512047600123	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
512047600124	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
512047600125	PIPE ASSY FUEL TANK-1 TO FUEL TANK-2 BS6	TATA spare parts
512047600137	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
512049200106	BRACKET ASSY EGP MTG BS6	TATA spare parts
512049200110	BRACKET ASSY BS6	TATA spare parts
512049200111	BRACKET ASSY TAIL PIPE MTG BS6	TATA spare parts
512049200112	BRACKET ASSY WITH SPACER EXHAUST MTG BS6	TATA spare parts
512049200114	PRESSURE LINE SM TO DM BS6	TATA spare parts
512049200117	BRACKET ASSY EGP MTG BS6	TATA spare parts
512049200118	BRACKET ASSY EGP MTG BS6	TATA spare parts
512049200119	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
512049200124	BRACKET ASSY EGP MTG BS6	TATA spare parts
512049200126	PRESSURE LINE SM TO DM BS6	TATA spare parts
512049200128	SUCTION PIPE BS6	TATA spare parts
512049200129	BRACKET ASSY EXHAUST PIPE MTG BS6	TATA spare parts
512049200130	EXHAUST PIPE ASSY FIRST BS6	TATA spare parts
512049200131	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
512049200133	BRACKET ASSY BS6	TATA spare parts
512049203304	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
512049203318	BRACKET TAIL PIPE BS6	TATA spare parts
512049203320	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
512049990118	FLEXIBLE HEAT SHIELD BS6	TATA spare parts
512049990121	HEAT SHIELD ASSY BS6	TATA spare parts
512054304902	FUEL LEVEL SENSOR BS6	TATA spare parts
512054307801	O-RING BS6	TATA spare parts
512054400105	BRACKET ASSY TAIL LAMP MTG LH BS6	TATA spare parts

512054400106	BRACKET ASSY TAIL LAMP MTG RH BS6	TATA spare parts
512054501601	SWITCH HILL ASSIST BS6	TATA spare parts
512054600102	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
512054600106	BATTERY CABLE +VE BS6	TATA spare parts
512054600107	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
512054600108	WIRING HARNESS INSTRUMENT PANEL BS6	TATA spare parts
512054600110	WIRING HARNESS GEAR BOX BS6	TATA spare parts
512054600111	BATT CABLE +VE ELE BCS OFF I/P TO J/B BS	TATA spare parts
512054600112	WIRING HARNESS ABS FRAME BS6	TATA spare parts
512054600113	WIRING HARNESS ENGINE BS6	TATA spare parts
512054600122	WIRING HARNESS MAIN BS6	TATA spare parts
512054600126	WIRING HARNESS ABS FRAME BS6	TATA spare parts
512054600127	WIRING HARNESS SCR UNIT BS6	TATA spare parts
512054600128	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
512054600129	WIRING HARNESS ABS FRAME BS6	TATA spare parts
512054600132	WIRING HARNESS TAIL BS6	TATA spare parts
512054600133	WIRING HARNESS TAIL BS6	TATA spare parts
512054600134	WIRING HARNESS ABS FRAME BS6	TATA spare parts
512054600135	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
512054600136	WIRING HARNESS TAIL BS6	TATA spare parts
512054600137	WIRING HARNESS ABS FRAME BS6	TATA spare parts
512054600138	WIRING HARNESS ABS FRAME BS6	TATA spare parts
512054600139	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
512054600144	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
512054600145	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
512054609901	STICKER MAXI FUSE BS6	TATA spare parts
512054610123	WIRING HARNESS-MAIN BS6	TATA spare parts
512054610126	WIRING HARNESS IP BS6-PH2	TATA spare parts
512054640108	BATTERY CABLE -VE BS6	TATA spare parts
512054650104	WIRING HARNESS LOAD BODY	TATA spare parts
512054650106	WIRING HARNESS LOAD BODY BS6	TATA spare parts
512058900701	SPANNER HP LINE NUT BS6-PH2	TATA spare parts
512058902601	DEF SENSOR UNIT REMOVAL TOOL BS6-PH2	TATA spare parts
51206000107R40	ASSY PARTIAL FITTED CAB ULTRA 1918 BS6	TATA spare parts
512131000109	FRAME ASSY WITH FITMENT BS6	TATA spare parts
512131000113	FRAME ASSY WITH FITMENT BS6	TATA spare parts
512131200104	CROSS MEMBER ASSY CENTER BEARING MTG BS6	TATA spare parts
512131200105	CROSS MEMBER ASSY REAR SPRING FRONT BS6	TATA spare parts
512131200106	CROSS MEMBER ASSY REAR SPRING REAR BS6	TATA spare parts
512132403302	BRACKET HELPER SPRING BS6	TATA spare parts
512132403303	BRACKET SPRING HANGER REAR-REAR BS6	TATA spare parts
512132404201	U-BOLT BS6	TATA spare parts
512143200106	AIR TANK ASSY BS6	TATA spare parts
512143700112	QUICK RELEASE VALVE BS6	TATA spare parts
512143700125	RELAY VALVE BS6	TATA spare parts
512143700131	SPRING BRAKE ACTUATOR ASSY LH BS6	TATA spare parts
512143700132	SPRING BRAKE ACTUATOR ASSY RH BS6	TATA spare parts

512143700135	SPRING BRAKE ACTUATOR ASSY LH BS6	TATA spare parts
512143700136	SPRING BRAKE ACTUATOR ASSY RH BS6	TATA spare parts
512143900101	METAL PIPE ASSY (JOINT TO APU) BS6	TATA spare parts
512143900102	METAL PIPE ASSY (JOINT TO JOINT) BS6	TATA spare parts
512143900103	METAL PIPE ASSY (TEFLON JOINT TO JOINT)	TATA spare parts
512154600102	WIRING HARNESS ABS FRAME BS6	TATA spare parts
512343300103	VACUUM PUMP ASSY	TATA spare parts
512350102702	CONNECTOR NW12 45	TATA spare parts
512350102705	CONNECTOR	TATA spare parts
512355106303	MASCOT	TATA spare parts
512358902408	LIFTING DEVICE	TATA spare parts
512380104001	COVER - CHARGING GUN BAG ACE EV	TATA spare parts
512410030001	INSPECTION LID 1	TATA spare parts
512410040001	INSPECTION LID 2	TATA spare parts
512410050001	INSPECTION LID 3	TATA spare parts
512410060001	INSPECTION LID 4	TATA spare parts
512410070001	INSPECTION LID 5	TATA spare parts
512410080001	INSPECTION LID 6	TATA spare parts
512410090001	INSPECTION LID 7	TATA spare parts
512410100001	INSPECTION LID 8	TATA spare parts
512410110001	INSPECTION LID 9	TATA spare parts
512410130001	INSPECTION LID 11	TATA spare parts
512410140001	INSPECTION LID 12	TATA spare parts
512410190001	INSPECTION LID 17	TATA spare parts
512410200001	INSPECTION LID 18	TATA spare parts
512410210001	INSPECTION LID 19	TATA spare parts
512410220001	INSPECTION LID 20	TATA spare parts
512430030001	INPECTION LID HANDLE	TATA spare parts
512454600101	CABLE BATT TAP +VE TO MANUAL CUT OFF +VE	TATA spare parts
512454600103	PIGTAIL WIRING HARNESS BS6	TATA spare parts
51251168000RCK	ASSY CAB KIT W/FITMENTS SIGNA 4225.TK BS	TATA spare parts
512524203701	BRACKET ENGINE MTG REAR FRAME LH BS6	TATA spare parts
512524203702	BRACKET ENGINE MTG REAR FRAME RH BS6	TATA spare parts
512529300102	NYLON PIPE ASSY BS6	TATA spare parts
512529307101	SUPPORT PLATE BS6	TATA spare parts
512529503301	BRACKET BS6-PH2	TATA spare parts
512533909002	CONTROL VALVE LIFT AXLE BS6	TATA spare parts
512533909003	PRESSURE LIMITING VALVE ASSY BS6	TATA spare parts
512533990108	KIT-NYLON PIPES BS6	TATA spare parts
512541110101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512541110102	PROPELLER SHAFT ASSY MIDDLE	TATA spare parts
512541110105	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512541110108	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512541120101	PROPELLER SHAFT ASSY REAR	TATA spare parts
512541120104	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
512541303301	BRACKET CENTER BRG MTG BS6	TATA spare parts
512541303302	BRACKET CENTER BRG MTG BS6	TATA spare parts

512541303303	BRACKET CENTER BRG MTG BS6	TATA spare parts
512541990101	SHORT FORK TUBE &FRONT END PIECE ASSY BS	TATA spare parts
512541990103	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
512541990104	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
512541990105	SHORT FORK TUBE AND FRONT END PIECE SUB	TATA spare parts
512541990111	SHORT FORK TUBE AND REAR HOUSING SUB AS	TATA spare parts
512541990113	SHORT FORK TUBE &AMP FRONT END PIECE S	TATA spare parts
512543700111	AIR DRYER -Repair kit	TATA spare parts
512543900106	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
512543900142	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
512546703302	BRACKET POWER CYL MTG BS6-PH2	TATA spare parts
512547600109	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
512547600110	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
512547600111	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
512549200103	BRACKET ASSY STAY ROD MTG BS6	TATA spare parts
512549200104	BRACKET ASSY BS6	TATA spare parts
512549200105	BRACKET ASSY BS6	TATA spare parts
512549200107	EXHAUST PIPE ASSY BS6	TATA spare parts
512549200108	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
512549200115	ARRESTOR RING ASSY BS6	TATA spare parts
512549200117	EXHAUST PIPE ASSY BS6	TATA spare parts
512549200118	BRACKET ASSY BS6	TATA spare parts
512549200120	EXHAUST PIPE ASSY FIRST BS6	TATA spare parts
512549203304	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
512549204203	CLAMP BS6	TATA spare parts
512549204204	CLAMP BS6	TATA spare parts
512549990101	HEAT SHIELD INSULATION BS6	TATA spare parts
512549990104	KIT-EXHAUST ASSY RETRO 4225/4825.TK BS6	TATA spare parts
512554600102	CABLE ASSY BATTERY +VE BS6	TATA spare parts
512554600103	CABLE ASSY BATTERY -VE BS6	TATA spare parts
512554603302	BRACKET INLINE CONN MTG BS6	TATA spare parts
512554640103	BATTERY CABLE +VE BATTERY TO BCS OFF I/P	TATA spare parts
512554640105	BATTERY CABLE +VE BCS TO MEGA FUSE BS6-P	TATA spare parts
512554640106	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
51260151000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 3118.T B	TATA spare parts
51261151000RCK	CABIN KIT FOR 51261151000R TATA LPT 3118	TATA spare parts
512631000101	FRAME ASSY WITH FITMENT BS6	TATA spare parts
512641100101	PROPELLER SHAFT ASSY-COUPLING BS6	TATA spare parts
512641110101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512641110102	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512641110103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512641110105	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512641120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
512641120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
512641303301	BRACKET CENTER BRG MTG BS6	TATA spare parts
512641990105	SHORT FORK TUBE AND FRONT END PIECE SUB	TATA spare parts
512641990106	SHORT FORK TUBE AND FRONT END PIECE SUB	TATA spare parts

512641990107	SHORT FORK TUBE AND REAR HOUSING SUB AS	TATA spare parts
512643700113	SPRING BRAKE ACTUATOR LH BS6	TATA spare parts
512643700114	SPRING BRAKE ACTUATOR RH BS6	TATA spare parts
512643700115	SPRING BRAKE ACTUATOR BS6	TATA spare parts
512643703301	BRACKET RELAY VALVE MTG BS6	TATA spare parts
512643900141	PIPE BUNCH ASSY BS6	TATA spare parts
512643900148	PIPE BUNCH ASSY BS6	TATA spare parts
512643900172	PIPE BUNCH ASSY BS6	TATA spare parts
512643900183	PIPE BUNCH ASSY BS6	TATA spare parts
512646600101	STEERING GEAR BOX ASSY BS6	TATA spare parts
512646800101	RETURN LINE ASSY BS6	TATA spare parts
512646800102	SUCTION LINE ASSY BS6	TATA spare parts
512646800103	PRESSURE LINE ASSY BS6	TATA spare parts
512646800104	RETURN LINE ASSY BS6	TATA spare parts
512646990111	HOUSING ASSY BS6	TATA spare parts
512646990112	SECTOR SHAFT ASSY BS6	TATA spare parts
512646990115	AUTOPOPPET KIT ASSY BS6	TATA spare parts
512646990116	AUTOPOPPET KIT ASSY BS6	TATA spare parts
512649200102	SUCTION PIPE BS6	TATA spare parts
512654600106	WIRING HARNESS SCR UNIT BS6	TATA spare parts
512654600107	WIRING HARNESS TAIL BS6	TATA spare parts
512654600109	WIRING HARNESS TAIL BS6	TATA spare parts
512654601602	WIRING HARNESS BS6	TATA spare parts
512654630105	WIRING HARNESS ABS FRAME BS6	TATA spare parts
512654630108	WIRING HARNESS ABS FRAME	TATA spare parts
512654630110	WIRING HARNESS TAIL BS6	TATA spare parts
512742300101	BRKT ASSY ACTUATOR MTG RR-RH BS6-PH2	TATA spare parts
512742300105	DRUM BRAKE ASSY WITH DC REAR-RH BS6-PH2	TATA spare parts
512742300106	DRUM BRAKE ASSY WITH DC REAR-LH BS6-PH2	TATA spare parts
512746800105	RETURN LINE ASSY RESERVOIR END BS6-PH2	TATA spare parts
512746800106	SUCTION LINE ASSY BS6-PH2	TATA spare parts
512746800107	SUCTION LINE ASSY BS6-PH2	TATA spare parts
512747500101	SPACER BRACKET ASSY FUEL TANK MTG BS6	TATA spare parts
512749200105	BRACKET ASSY EGP MTG BS6	TATA spare parts
512749200112	EXHAUST TAIL PIPE ASSY BS6-PH2	TATA spare parts
512749203301	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
512749203310	BRACKET BS6-PH2	TATA spare parts
512749206906	EXHAUST TAIL PIPE DIFFUSER BS6	TATA spare parts
512754708202	BRACKET TELEMATICS UNIT MTG BS6	TATA spare parts
51280738000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 2825.K B	TATA spare parts
51281038000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 2825 BS6	TATA spare parts
51281538500RCK	CABIN KIT FOR SIGNA 2825.K EBSVI HD	TATA spare parts
512829500101	BRACKET ASSY BS6	TATA spare parts
512831000102	FRAME ASSY WITH FITMENT BS6	TATA spare parts
512833000101	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
512833805101	STEERING ARM BS6	TATA spare parts
512841120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts



512841120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
512841120105	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
512841120109	PROPELLER SHAFT ASSY-DRIVE BS6	TATA spare parts
512841990101	SHORT FORK TUBE; REAR END PIECE ASSY BS6	TATA spare parts
512841990103	SHORT FORK TUBE & REAR END PIECE	TATA spare parts
512841990105	SLIP YOKE ASSY BS6	TATA spare parts
512843000104	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
512843200112	CHANNEL ASSY BS6	TATA spare parts
512843700104	SPRING BRAKE ACTUATOR BS6	TATA spare parts
512843700105	SPRING BRAKE ACTUATOR BS6	TATA spare parts
512843700106	SPRING BRAKE ACTUATOR BS6	TATA spare parts
512843700115	MAJOR KIT BS6	TATA spare parts
512843700116	SPRING BRAKE ACTUATOR T24/24 MAJOR SPARE	TATA spare parts
512843709901	DIAPHRAGM BS6-PH2	TATA spare parts
512843709902	QUADRUPLE SYSTEM PROTECTION VALVE BS6	TATA spare parts
512843709904	ADAPTER BS6-PH2	TATA spare parts
512843900107	PIPE BUNCH ASSY BS6	TATA spare parts
512843900120	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
512843900122	PIPE BUNCH ASSY BS6	TATA spare parts
512843900126	METAL PIPE ASSY BS6	TATA spare parts
512843900142	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
512846305101	PITMAN ARM BS6	TATA spare parts
512847600101	SUCTION PIPE ASSY FILTER TO ENGINE (FUEL	TATA spare parts
512847600103	RETURN FUEL PIPE ASSY BS6	TATA spare parts
512847600104	FUEL SUCTION PIPE ASSY-TANK TO W/SEP BS6	TATA spare parts
512849200101	CLAMP ASSY EXHAUST MTG BS6	TATA spare parts
512849200102	EXHAUST PIPE ASSY SECOND BS6	TATA spare parts
512849200103	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
512849200110	EXHAUST PIPE ASSY BS6	TATA spare parts
512849200114	BRACKET ASSY EXHAUST PIPE SUPPORT BS6	TATA spare parts
512849200115	BRACKET ASSY BS6	TATA spare parts
512849200116	BRACKET ASSY BS6	TATA spare parts
512849200121	EXHAUST PIPE ASSY FIRST BS6	TATA spare parts
512849200122	EXHAUST PIPE ASSY WITH BELLOW BS6	TATA spare parts
512849200125	BRACKET ASSY BS6	TATA spare parts
512849200126	BRACKET ASSY BS6	TATA spare parts
512849200130	EXHAUST PIPE ASSY BS6	TATA spare parts
512849203301	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
512849203312	BRACKET BS6	TATA spare parts
512849203326	BRACKET BS6	TATA spare parts
512849203333	BRACKET BS6	TATA spare parts
512849204201	CLAMP PIPE RH BS6	TATA spare parts
512849204202	CLAMP PIPE LH BS6	TATA spare parts
512849990101	KIT-EXHAUST SYSTEM BS6	TATA spare parts
512849990102	KIT-EXHAUST SYSTEM BS6	TATA spare parts
512849990104	KIT-EXHAUST SYSTEM BS6	TATA spare parts
512849990106	KIT-EXHAUST SYSTEM-6.7L SIGMA SLPR CAB	TATA spare parts

512849990107	KIT-EXHAUST SYSTEM-6.7L SIGNA SLPR CAB	TATA spare parts
512854600101	WIRING HARNESS TAIL BS6	TATA spare parts
512854600105	WIRING HARNESS ROOF BS6	TATA spare parts
512854600107	WIRING HARNESS TAIL BS6	TATA spare parts
512854600108	WIRING HARNESS ABS FRAME BS6	TATA spare parts
512854603301	BRACKET INLINE CONN MTG BS6	TATA spare parts
512854620102	WIRING HARNESS ENGINE BS6	TATA spare parts
512854630102	WIRING HARNESS TAIL BS6	TATA spare parts
512854640101	WIRING HARNESS BATT M.FUSE TO STR BS6	TATA spare parts
512854640102	CABLE BATT TAP +VE TO MANUAL CUT OFF +VE	TATA spare parts
512854640104	PIGTAIL ASSY EMS WIRING HARNESS BS6	TATA spare parts
512854640105	BATTERY CABLE +VE MAXI FUSE O/P TO SM BS	TATA spare parts
512854640106	BATT CABLE +VE BCS O/P TO MAXI FUSE BOX	TATA spare parts
512854640107	CABLE ASSY BATTERY -VE BS6	TATA spare parts
51286000114RCJO	SIGNA2825.TK EBSVI HD_CAB/COWL	TATA spare parts
51290856000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 3525 BS6	TATA spare parts
51292756500RCK	ASSY CABIN KIT W/FITMENTS SIGNA 3525 BS6	TATA spare parts
512941110101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
512943700107	ANTI ROLL BACK ASSY BS6	TATA spare parts
512943900103	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
512949200102	BRACKET ASSY EXHAUST PIPE SUPPORT BS6	TATA spare parts
512949200103	PRESSURE LINE,SM TO DM BS6	TATA spare parts
512949200105	EXHAUST PIPE ASSY FIRST BS6	TATA spare parts
512954600101	WIRING HARNESS TAIL BS6	TATA spare parts
512954600102	WIRING HARNESS ABS FRAME BS6	TATA spare parts
512954600103	WIRING HARNESS SCR UNIT BS6	TATA spare parts
512954640101	WIRING HARNESS BATTERY MEGA FUSE TO STR	TATA spare parts
513127200062DB	DEF WINDOW	TATA spare parts
513128240005DB	COUPLING ROD	TATA spare parts
513128240028DB	WIPER ARM	TATA spare parts
51320968000RCK	ASSY CAB KIT W/FITMENTS SIGNA 4825.TK BS	TATA spare parts
513231000108	FRAME ASSY WITH FITMENT BS6	TATA spare parts
513231107109	REINFORCEMENT RH BS6	TATA spare parts
513231107110	REINFORCEMENT LH BS6	TATA spare parts
513231990101	KIT-REINFORCEMENT FRAME RETRO 4825.TK BS	TATA spare parts
513233000101	FRONT AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
513233000102	FRONT AXLE ASSY WITH BRAKE RWD BS6	TATA spare parts
513233900114	LIFT AXLE ASSY BS6	TATA spare parts
513233900116	ORIFICE VALVE BS6	TATA spare parts
513233900117	GATE VALVE ASSY BS6	TATA spare parts
513233900126	PIPE BUNCH ASSY BS6	TATA spare parts
513233900143	LINK ROD ASSY BS6-PH2	TATA spare parts
513233900170	LIFT AXLE BEAM ASSY BS6-PH2	TATA spare parts
513233900188	KIT-NYLON PIPES BS6-PH2	TATA spare parts
513233900189	NYLON PIPE ASSY AIR TANK TO TEE BS6-PH2	TATA spare parts
513233900190	NYLON PIPE ASSY TEE TO TEE - BS6-PH2	TATA spare parts
513233900191	NYLON PIPE ASSY TEE TO LACV BS6-PH2	TATA spare parts

513233900192	NYLON PIPE ASSY TEE TO PLV BS6-PH2	TATA spare parts
513233900193	NYLON PIPE ASSY PLV TO TEE BS6-PH2	TATA spare parts
513233900194	NYLON PIPE ASSY TEE TO PRV BS6-PH2	TATA spare parts
513233900195	NYLON PIPE ASSY TEE TO LDV BS6-PH2	TATA spare parts
513233900196	NYLON PIPE ASSY RELAY VALVE TO TEE BS6-P	TATA spare parts
513233900197	NYLON PIPE ASSY BS6-PH2	TATA spare parts
513233900198	NYLON PIPE ASSY - BS6-PH2	TATA spare parts
513233900199	NYLON PIPE ASSY QRV TO MAIN BELLOW LH BS	TATA spare parts
513233900224	PIPE BUNCH ASSY BS6	TATA spare parts
513233900233	NYLON PIPE ASSY RELAY VALVE TO TEE BS6-P	TATA spare parts
513233900234	NYLON PIPE ASSY TEE TO LIFT BELLOW LH BS	TATA spare parts
513233900235	NYLON PIPE ASSY TEE TO LIFT BELLOW RH BS	TATA spare parts
513233900236	NYLON PIPE ASSY TEE TO TEE BS6-PH2	TATA spare parts
513233900237	NYLON PIPE ASSY - BS6-PH2	TATA spare parts
513233900238	NYLON PIPE ASSY BS6-PH2	TATA spare parts
513233900239	NYLON PIPE ASSY RELAY VALVE TO TEE BS6-P	TATA spare parts
513233900240	NYLON PIPE ASSY BS6-PH2	TATA spare parts
513233900241	NYLON PIPE ASSY TEE TO LACV BS6-PH2	TATA spare parts
513233900242	NYLON PIPE ASSY RELAY VALVE TO LACV BS6-	TATA spare parts
513233900243	NYLON PIPE ASSY PRV TO RELAY VALVE - BS6	TATA spare parts
513233900244	NYLON PIPE ASSY TEE TO NYLON PIPE ASSY O	TATA spare parts
513233900245	LIFT AXLE LINK ARM ASSY LH BS6-PH2	TATA spare parts
513233900246	NYLON PIPE ASSY TEE TO LACV BS6-PH2	TATA spare parts
513233900247	NYLON PIPE ASSY LSV TO LACV BS6-PH2	TATA spare parts
513233900248	NYLON PIPE ASSY TEE TO LACV BS6-PH2	TATA spare parts
513233900249	NYLON PIPE ASSY TEE TO LACV BS6-PH2	TATA spare parts
513233900250	NYLON PIPE ASSY TEE TO LACV BS6-PH2	TATA spare parts
513233900254	LIFT AXLE LINK ARM ASSY RH BS6-PH2	TATA spare parts
513233900262	KIT-NYLON PIPES BS6-PH2	TATA spare parts
513233900263	NYLON PIPE ASSY BS6-PH2	TATA spare parts
513233900264	NYLON PIPE ASSY RELAY VALVE TO LACV BS6-	TATA spare parts
513233900265	NYLON PIPE ASSY RELAY VALVE TO LACV BS6-	TATA spare parts
513233900267	NYLON PIPE ASSY TEE TO LACV BS6-PH2	TATA spare parts
513233900269	NYLON PIPE ASSY QRV TO MAIN BELLOW RH BS	TATA spare parts
513233909901	MAIN AIR SPRING	TATA spare parts
513233990101	CHAIN ASSY REBOUND BS6	TATA spare parts
513233990102	LIFT AXLE PIPING ASSY WITH VALVES BS6	TATA spare parts
51324068100RCK	ASSY CABIN KIT FOR SIGNA 4825 BS6	TATA spare parts
513241100102	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
513241100103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
513241100107	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
513241100108	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
513241120101	DRIVE SHAFT ASSY BS6	TATA spare parts
513241120106	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
513241300101	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
513241303302	BRACKET CENTER BRG MTG BS6	TATA spare parts
513241990101	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts

513241990102	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
513241990104	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
513241990121	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
513241990122	SHORT FORK TUBE & REAR END PIECE ASS	TATA spare parts
513241990123	SHORT FORK TUBE & FRONT END PIECE AS	TATA spare parts
513243200102	BRACKET ASSY AIR TANK MTG BS6	TATA spare parts
513243200106	BRACKET ASSY BS6	TATA spare parts
513243200107	BRACKET ASSY AIR TANK MTG BS6	TATA spare parts
513243200109	AIR TANK ASSY WITH BKT BS6	TATA spare parts
513243200114	AIR TANK ASSY WITH BKTS & STRAP BS6	TATA spare parts
513243200118	AIR TANK ASSY BS6	TATA spare parts
513243700105	RELAY VALVE BS6	TATA spare parts
513243700116	SOLENOID VALVE BS6	TATA spare parts
513243700120	BRAKE CHAMBER BS6	TATA spare parts
513243703303	BRACKET RELAY VALVE MTG BS6	TATA spare parts
513243900102	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
513243900104	METAL PIPE ASSY BS6	TATA spare parts
513243900105	METAL PIPE ASSY BS6	TATA spare parts
513243900117	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
513243900187	METAL PIPE ASSY WITH CRIMPED TEFLON HOSE	TATA spare parts
513243900197	STRAP CABLE TIE BS6	TATA spare parts
513243910102	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
513243910114	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
513254600101	WIRING HARNESS TAIL BS6	TATA spare parts
513254600102	WIRING HARNESS SCR UNIT BS6	TATA spare parts
513254600103	WIRING HARNESS ABS FRAME BS6	TATA spare parts
513254600104	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
513254600105	W/H BATTERY CABLE CUT OFF SW TO MFIP BS6	TATA spare parts
513254600108	WIRING HARNESS TAIL BS6	TATA spare parts
513254610101	WIRING HARNESS MAIN BS6	TATA spare parts
513343700123	DESICCANT CARTRIDGE	TATA spare parts
513343900161	METAL PIPE ASSY	TATA spare parts
513543700126	RELAY VALVE WITH MTG BKT BS6	TATA spare parts
513546703301	BRACKET POWER CYL MTG BS6	TATA spare parts
513700990101	KIT-ACE GOLD DSL BS6 CDPF EXHAUST SYSTEM	TATA spare parts
513715400101	ALTERNATOR 12V 70A LIN BS6-PH2	TATA spare parts
513724100101	BRACKET ASSY C-MOUNT BS6	TATA spare parts
513724100102	BRACKET ASSY C-MOUNT BS6-PH2	TATA spare parts
513724200101	STOPPER ASSY B-MOUNT BS6	TATA spare parts
513724200102	BRACKET ASSY B-MOUNT BS6	TATA spare parts
513724200103	BRACKET ASSY ENGINE MTG REAR BS6	TATA spare parts
513724200107	BRACKET ASSY B-MOUNT BS6-PH2	TATA spare parts
513724200108	BRACKET ASSY B-MOUNT BS6-PH2	TATA spare parts
513724203701	BRACKET B-MOUNT BS6	TATA spare parts
513729100101	CLUTCH CABLE ASSY BS6-PH2	TATA spare parts
513729100103	CLUTCH PEDAL ASSY BS6-PH2	TATA spare parts
513729100105	STOPPER BOLT ASSY CLUTCH PEDAL BS6-PH2	TATA spare parts

513729100108	CLUTCH CABLE ASSY BS6-PH2	TATA spare parts
513729200101	BRAKE PEDAL ASSY BS6-PH2	TATA spare parts
513729500102	BRACKET ASSY CONTROL MTG BS6-PH2	TATA spare parts
513729500103	BRKT ASSY BRAKE & CL CONTROL MTG BS6-PH2	TATA spare parts
513731000103	FRAME ASSY BS6	TATA spare parts
513731000104	FRAME ASSY BS6-PH2	TATA spare parts
513731000106	FRAME ASSY BS6-PH2	TATA spare parts
513731200110	CROSS MEMBER ASSY GEAR BOX MTG BS6-PH2	TATA spare parts
513731200111	CROSS MEMBER ASSY FRONT	TATA spare parts
513732400106	GUIDE PLATE ASSY BS6	TATA spare parts
513733000101	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
513733000107	FRONT AXLE ASSY BS6	TATA spare parts
513733200107	STUB AXLE ASSY RH BS6	TATA spare parts
513733200108	STUB AXLE ASSY LH BS6	TATA spare parts
513733200109	STUB AXLE ASSY ABS LH BS6-PH2	TATA spare parts
513733200110	STUB AXLE ASSY ABS RH BS6-PH2	TATA spare parts
513733805101	STEERING ARM BS6	TATA spare parts
513733805102	STEERING ARM BS6	TATA spare parts
513741100101	PROPELLER SHAFT ASSY BS6	TATA spare parts
513741100102	PROPELLER SHAFT ASSY BS6-PH2	TATA spare parts
513741100103	PROPELLER SHAFT ASSY BS6-PH2	TATA spare parts
513742700104	HOOK ASSY BS6	TATA spare parts
513742700108	PARKING BRAKE CABLE ASSY FRONT BS6	TATA spare parts
513743500102	VACUUM PIPE ASSY BS6	TATA spare parts
513743500103	VACUUM HOSE BS6	TATA spare parts
513743500106	VACUUM PIPE ASSY BS6-PH2	TATA spare parts
513743500108	VACUUM PIPE ASSY BS6-PH2	TATA spare parts
513743500110	VACUUM PIPE ASSY BS6-PH2	TATA spare parts
513743500114	VACUUM PIPE ASSY BS6-PH2	TATA spare parts
513743500121	VACUUM PIPE ASSY BS6	TATA spare parts
513743500124	VACUUM PIPE ASSY BS6-PH2	TATA spare parts
513743500126	VACUUM PIPE ASSY BS6-PH2	TATA spare parts
513743800102	TUBE ASSY T-CONN TO ADAPTER BS6	TATA spare parts
513743800103	TUBE ASSY ADAPTER TO REAR BRAKE HOSE LH	TATA spare parts
513743800104	TUBE ASSY ADAPTER TO REAR BRAKE HOSE RH	TATA spare parts
513743800106	TUBE ASSY ADAPTER TO REAR BRAKE HOSE LH	TATA spare parts
513743800107	TUBE ASSY ADAPTER TO REAR BRAKE HOSE RH	TATA spare parts
513743800109	TUBE ASSY T-CONN TO ADAPTER BS6	TATA spare parts
513743800110	TUBE ASSY ADAPTER TO REAR BRAKE HOSE RH	TATA spare parts
513743800113	TUBE ASSY-ADAPTER TO LCRV INLET BS6	TATA spare parts
513743800114	TUBE ASSY-ADAPTER TO LCRV INLET BS6	TATA spare parts
513743800115	TUBE ASSY-LCRV TO REAR BRAKE HOSE-RH BS6	TATA spare parts
513743800116	PIPE ASSY LCRV OUTLET TO RE HOSE BS6-PH2	TATA spare parts
513743800121	TUBE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts
513743800122	TUBE ASSY ADAPTER TO FRONT HOSE RH BS6	TATA spare parts
513743800123	TUBE ASSY ADAPTER TO REAR BRAKE HOSE LH	TATA spare parts
513743800124	TUBE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts

513743800125	TUBE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts
513743800126	TUBE ASSY ADAPTER TO REAR BRAKE HOSE RH	TATA spare parts
513743800127	TUBE ASSY TMC SECONDARY TO ADAPTER BS6-P	TATA spare parts
513743800128	TUBE ASSY TMC PRIMERY TO ADAPTER BS6-PH2	TATA spare parts
513743800130	TUBE ASSY ADAPTER TO FRONT BRAKE HOSE LH	TATA spare parts
513743800131	TUBE ASSY PRIMARY PORT TO ADAPTER BS6	TATA spare parts
513743800132	TUBE ASSY BS6	TATA spare parts
513743800136	TUBE ASSY HOSE TO REAR BRAKE ASSY RH BS6	TATA spare parts
513743800137	TUBE ASSY HOSE TO REAR BRAKE ASSY LH BS6	TATA spare parts
513743800138	TUBE ASSY BS6-PH2	TATA spare parts
513743800139	TUBE ASSY BS6-PH2	TATA spare parts
513743800142	TUBE ASSY ADAPTER TO REAR TLSPV BS6-PH2	TATA spare parts
513743800143	TUBE ASSY ADAPTER TO LCRV INLET BS6-PH2	TATA spare parts
513743800144	TUBE ASSY LCRV TO RR BR HOSE RH BS6-PH2	TATA spare parts
513743800145	COVER ASSY TANDEM MASTER CYL BS6-PH2	TATA spare parts
513743800147	BRACKET ASSY BS6-PH2	TATA spare parts
513743800151	TUBE ASSY ADAPTER TO LCRV INLET BS6-PH2	TATA spare parts
513743800152	TUBE ASSY ADAPTER TO LCRV INLET BS6-PH2	TATA spare parts
513743800153	TUBE ASSY LCRV TO RR BRAKE HOSE BS6-PH2	TATA spare parts
513743800154	TUBE ASSY TMC PRIMARY TO T-CONN BS6-PH2	TATA spare parts
513743800155	TUBE ASSY TMC SECONDARY TO T-CONN BS6-PH	TATA spare parts
513743800156	BRACKET ASSY BS6-PH2	TATA spare parts
513743800157	BRACKET ASSY BS6-PH2	TATA spare parts
513743800158	TUBE ASSY ADAPTER TO FRT HOSE RH BS6-PH2	TATA spare parts
513743800159	TUBE ASSY ADAPTER TO ADAPTER BS6-PH2	TATA spare parts
513743800162	TUBE ASSY HOSE TO RR BR ASSY RH BS6-PH2	TATA spare parts
513743800163	TUBE ASSY HOSE TO RR BK ASSY LH BS6-PH2	TATA spare parts
513743800164	TUBE ASSY ADAPTER TO ADAPTER BS6-PH2	TATA spare parts
513743800165	TUBE ASSY ADAPTER TO ADAPTER BS6-PH2	TATA spare parts
513743800166	TUBE ASSY HOSE TO RR BR ASSY LH BS6-PH2	TATA spare parts
513743800167	TUBE ASSY HOSE TO RR BR ASSY RH BS6-PH2	TATA spare parts
513743800168	TUBE ASSY T-CONN TO ADAPTER BS6-PH2	TATA spare parts
513743800169	TUBE ASSY T-CONN TO ADAPTER BS6-PH2	TATA spare parts
513743805802	VACUUM HOSE ENGINE END BS6	TATA spare parts
513743805803	HOSE RESERVOIR TO TMC PRIMARY BS6-PH2	TATA spare parts
513743805804	HOSE RESERVOIR TO TMC SECONDARY BS6-PH2	TATA spare parts
513746100102	STEERING COLUMN ASSY BS6-PH2	TATA spare parts
513746100103	STEERING COLUMN ASSY UPPER BS6-PH2	TATA spare parts
513746100104	INTERMEDIATE SHAFT ASSY BS6-PH2	TATA spare parts
513746100105	STEERING COLUMN BS6-PH2	TATA spare parts
513746100106	INTERMEDIATE SHAFT ASSY BS6-PH2	TATA spare parts
513746100108	STEERING COLUMN ASSY UPPER BS6-PH2	TATA spare parts
513746305101	DROP ARM BS6-PH2	TATA spare parts
513746600104	STEERING GEAR ASSY BS6-PH2	TATA spare parts
513746990106	BOX ASSY BS6-PH2	TATA spare parts
513746990108	WORM & NUT ASSY BS6-PH2	TATA spare parts
513746993201	HEX BOLT BS6-PH2	TATA spare parts

513746996501	LOCK NUT BS6-PH2	TATA spare parts
513747100105	FUEL TANK ASSY BS6	TATA spare parts
513747100106	FUEL FILLER NECK ASSY BS6	TATA spare parts
513747100108	FUEL TANK ASSY BS6	TATA spare parts
513747100110	BRACKET ASSY CPV MTG BS6	TATA spare parts
513747105301	GASKET FSU BS6	TATA spare parts
513747107701	SEAL BS6	TATA spare parts
513747500104	STRAP ASSY & RUBBER FUEL TANK MTG BS6	TATA spare parts
513747500105	STRAP ASSY BS6	TATA spare parts
513747507702	RUBBER STRAP BS6	TATA spare parts
513747600105	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
513747600106	VAPOUR PIPE ASSY BS6	TATA spare parts
513747600107	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
513747600108	FUEL RETURN PIPE ASSY BS6	TATA spare parts
513747600110	VAPOUR PIPE ASSY BS6	TATA spare parts
513747600111	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
513747600112	FUEL RETURN PIPE ASSY BS6	TATA spare parts
513747600114	VAPOUR PIPE ASSY BS6	TATA spare parts
513747600116	VAPOUR PIPE ASSY BS6	TATA spare parts
513747600117	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
513747600119	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
513747600120	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
513747600121	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
513747600122	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
513747600126	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
513747600128	VAPOUR PIPE ASSY CANISTER TO ENGINE BS6-	TATA spare parts
513747600129	VAPOUR PIPE ASSY TANK TO TPV BS6-PH2	TATA spare parts
513747600132	VAPOUR PIPE ASSY BS6-PH2	TATA spare parts
513747600138	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
513747600139	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
513747600140	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
513747600141	VAPOUR PIPE ASSY BS6-PH2	TATA spare parts
513747600142	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
513747600144	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
513747600145	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
513747600146	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
513747600147	VAPOUR PIPE ASSY BS6-PH2	TATA spare parts
513747600148	VAPOUR PIPE ASSY BS6-PH2	TATA spare parts
513747600149	VAPOUR PIPE ASSY CANISTER TO ENG BS6-PH2	TATA spare parts
513747600183	BRACKET ASSY BS6-PH2	TATA spare parts
513747600186	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
513747603308	BRACKET CLAMP MTG BS6	TATA spare parts
513747603309	BRACKET PURGE VALVE MTG BS6-PH2	TATA spare parts
513747603311	BRACKET PURGE VALVE MTG BS6-PH2	TATA spare parts
513747605821	FUEL FILLING HOSE BS6	TATA spare parts
513747605824	EVAP HOSE T-CONN TO ENGINE MANIFOLD BS6	TATA spare parts
513747605825	BREATHER HOSE BS6	TATA spare parts

513747605838	FUEL FILLING HOSE BS6-PH2	TATA spare parts
513747605846	BREATHER HOSE BS6-PH2	TATA spare parts
513747605847	HOSE BS6-PH2	TATA spare parts
513747605862	FUEL FILLING HOSE BS6-PH2	TATA spare parts
513747605863	BREATHER HOSE BS6-PH2	TATA spare parts
513749100102	SILENCER ASSY BS6	TATA spare parts
513749200104	BRACKET ASSY BS6	TATA spare parts
513749200116	BRACKET ASSY BS6-PH2	TATA spare parts
513749200118	SILENCER ASSY EXHAUST BS6-PH2	TATA spare parts
513749200120	UREA TANK ASSY BS6-PH2	TATA spare parts
513749200121	PIPE ASSY UREA SUPPLY BS6-PH2	TATA spare parts
513749200124	BRACKET ASSY SILENCER MTG REAR BS6	TATA spare parts
513749200128	EXT PIPE ASSY WITH FLEX BELLOW BS6-PH2	TATA spare parts
513749200136	HEAT SHIELD ASSY CATCON BS6-PH2	TATA spare parts
513749200137	SILENCER ASSY WITH BKT & HEAT SHIELD BS6	TATA spare parts
513749200138	EXHAUST PIPE ASSY WITH HEAT SHIELD BS6-P	TATA spare parts
513749200140	BRACKET ASSY BS6-PH2	TATA spare parts
513749203323	BRACKET BS6-PH2	TATA spare parts
513749203324	BRACKET BS6-PH2	TATA spare parts
513749203330	BRACKET BS6-PH2	TATA spare parts
513749205803	HOSE BS6-PH2	TATA spare parts
513749205804	HOSE BS6-PH2	TATA spare parts
513749605801	HEAT SHIELD ASSY BS6-PH2	TATA spare parts
513754100102	BRACKET ASSY BS6-PH2	TATA spare parts
513754100103	BRACKET ASSY BATTERY TRAY MTG BS6-PH2	TATA spare parts
51375410M10133	BATTERY TRAY ASSY BS6-PH2	TATA spare parts
513754300104	BRACKET ASSY HORN MTG BS6	TATA spare parts
513754304901	SIREN ASSY BS6	TATA spare parts
513754420101	REVOLVING LAMP BS6	TATA spare parts
513754500102	IGNITION SWITCH BS6-PH2	TATA spare parts
513754504901	HEADLAMP LEVELLING SWITCH BS6-PH2	TATA spare parts
513754504902	HEADLAMP LEVELLING SWITCH BS6-PH2	TATA spare parts
513754504902C7	GRANIT_BLACK-HEADLAMP LEVELLING SWITCH B	TATA spare parts
513754600102	WIRING HARNESS MAINBS6	TATA spare parts
513754600103	WIRING HARNESS MAIN BS6	TATA spare parts
513754600106	WIRING HARNESS MAIN BS6	TATA spare parts
513754600107	WIRING HARNESS;ROOF;RH BS6	TATA spare parts
513754600108	WIRING HARNESS MAIN BS6	TATA spare parts
513754600109	WIRING HARNESS;EMERGENCY SWITCH BS6	TATA spare parts
513754600110	BATTERY CABLE +VE BS6	TATA spare parts
513754600111	WIRING HARNESS SIDE REPEATER BS6	TATA spare parts
513754600113	WIRING HARNESS ENGINE BS6	TATA spare parts
513754600114	WIRING HARNESS ENGINE BS6	TATA spare parts
513754600119	BATTERY CABLE +VE BS6	TATA spare parts
513754600120	BATTERY CABLE -VE BS6-PH2	TATA spare parts
513754600121	WIRING HARNESS MAIN BS6	TATA spare parts
513754600123	WIRING HARNESS SIDE REPEATER BS6	TATA spare parts



513754600124	BRACKET ASSY FUSE & RELAY BASE MTG BS6	TATA spare parts
513754600128	WIRING HARNESS PIGTAIL BS6	TATA spare parts
513754600133	PIGTAIL GPS CONNECTOR BS6	TATA spare parts
513754600135	WIRING HARNESS ABS BS6	TATA spare parts
513754600142	BRACKET ASSY FUSE BOX MTG BS6-PH2	TATA spare parts
513754600143	BRACKET FUSE & RELAY MTG BS6-PH2	TATA spare parts
513754600144	WIRING HARNESS ASSY ENGINE BS6-PH2	TATA spare parts
513754600145	BRACKET ASSY FUSE BOX MTG BS6-PH2	TATA spare parts
513754600146	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
513754600147	RELAY COVER ASSY BS6	TATA spare parts
513754600148	BATTERY CABLE +VE BS6-PH2	TATA spare parts
513754600149	BATTERY CABLE +VE BS6-PH2	TATA spare parts
513754600150	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
513754600151	WIRING HARNESS MAIN BS6	TATA spare parts
513754600154	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
513754600155	RELAY COVER ASSY BS6-PH2	TATA spare parts
513754600156	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
513754600158	RELAY COVER ASSY BS6-PH2	TATA spare parts
513754600162	WIRING HARNESS SIDE REPEATER BS6-PH2	TATA spare parts
513754600165	WIRING HARNESS EMERGENCY SWITCH BS6-PH2	TATA spare parts
513754600168	WIRING HARNESS-MAIN BS6	TATA spare parts
513754600169	BRACKET FUSE & RELAY MTG BS6-PH2	TATA spare parts
513754600170	WIRING HARNESS ROOF BS6-PH2	TATA spare parts
513754600171	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
513754600172	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
513754600174	BATTERY CABLE +VE BS6-PH2	TATA spare parts
513754600177	BRACKET ASSY ABS INTERCONNECTOR MTG BS6	TATA spare parts
513754600186	PIGTAIL GPS CONNECTOR BS6-PH2	TATA spare parts
513754600187	WIRING HARNESS ROOF RH BS6	TATA spare parts
513754600197	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
513754600199	WIRING HARNESS ROOF RH BS6-PH2	TATA spare parts
513754600210	PIGTAIL ASSY EMS WIRING HARNESS BS6-PH2	TATA spare parts
513754603302	BRACKET WIRING HARNESS BRANCH MTG BS6	TATA spare parts
513754603303	BRACKET WIRING HARNESS BRANCH MTG BS6	TATA spare parts
513754603306	BRACKET FUSE BOX & RELAY BASE MTG BS6	TATA spare parts
513754603307	BRKT WIRING HARNESS BRANCH MTG BS6-PH2	TATA spare parts
513754603308	MOUNTING BRACKET BS6	TATA spare parts
513754603309	BRACKET TCU WIRING HARNESS MTG BS6	TATA spare parts
513754603312	BRACKET WIRING HARNESS CLIP MTG BS6	TATA spare parts
513754603313	BRACKET RELAY BASE MTG BS6-PH2	TATA spare parts
513754603314	BRKT WIRING HARNESS BRANCH MTG BS6-PH2	TATA spare parts
513754603316	BRACKET-WIRING HARNESS BRANCH MTG BS6	TATA spare parts
513754603319	BRACKET DIAGNOSTIC CONNECTOR MTG BS6-PH2	TATA spare parts
513754603320	BRACKET FUSE & RELAY MTG BS6-PH2	TATA spare parts
513754603325	BRACKET RELAY & FUSE BOX MTG BS6-PH2	TATA spare parts
513754603392	BRACKET ASSY INLINE CONNECTOR MTG BS6	TATA spare parts
513754603395	BRACKET WIRING HARNESS CLIP MTG BS6-PH2	TATA spare parts

513754603398	BRACKET TCU WIRING HARNESS MTG BS6	TATA spare parts
513754606308	FUSE BOX COVER BS6-PH2	TATA spare parts
513754610106	BATTERY CABLE +VE BS6-PH2	TATA spare parts
513754610107	RELAY COVER ASSY BS6-PH2	TATA spare parts
513754610117	BRKT ASSY EMS WIRING HARNESS MTG BS6-PH2	TATA spare parts
513754610129	BRACKET ASSY RETAINER PLATE BS6-PH2	TATA spare parts
513754610132	WIRING HARNESS SIDE REPEATER BS6-PH2	TATA spare parts
513754610133	RELAY COVER ASSY BS6-PH2	TATA spare parts
513754610134	WIRING HARNESS-MAIN BS6-PH2	TATA spare parts
513754610138	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
513754613302	BRACKET ENGINE MTG BS6-PH2	TATA spare parts
513754613307	MOUNTING BRACKET BS6-PH2	TATA spare parts
513754613309	BRKT INTERCONNECTION CONNECTOR MTG BS6-PH2	TATA spare parts
513754613310	BRACKET WIRING HARNESS CLIP MTG BS6-PH2	TATA spare parts
513754613314	MOUNTING BRACKET BS6-PH2	TATA spare parts
513754613317	BRKT INTERCONNECTION CONNECTOR MTG BS6-PH2	TATA spare parts
513754613323	MOUNTING BRACKET BS6-PH2	TATA spare parts
513754613328	BRACKET BS6-PH2	TATA spare parts
513754613329	BRACKET FUSE BOX MTG BS6-PH2	TATA spare parts
513754700102	PUBLIC ADDRESS SYSTEM DASHBOARD BS6	TATA spare parts
513754700109	BRACKET ASSY ECU BKT MTG BS6-PH2	TATA spare parts
513754709901	WHEEL SPEED SENSOR FRONT	TATA spare parts
513754710101	BRACKET ASSY BS6-PH2	TATA spare parts
513755100101	MASCOT ASSY - GOLD + BS6	TATA spare parts
513755106301	MASCOT BS6	TATA spare parts
513755106303	MASCOT CNG+ BS6	TATA spare parts
513755156301	DECAL BS6	TATA spare parts
513758902401	ENG MTG BRKT LH (ENGINE REPAIR) BS6-PH2	TATA spare parts
513758902402	ENGINE MOUNTING BRACKET - RH (ENGINE REPAIR)	TATA spare parts
513758902403	LOCKING TOOL FLYWHEEL BS6-PH2	TATA spare parts
513758902404	LOCKING TOOL FLYWHEEL BS6-PH2	TATA spare parts
513758902405	SUPPORT RAIL BS6-PH2	TATA spare parts
513758902406	DRIFT CAM/CRANK OIL SEAL FRT PR BS6-PH2	TATA spare parts
513758902407	DRIFT CRANK OIL SEAL RR PRESSING BS6-PH2	TATA spare parts
513758902408	DRIFT FOR CAM AND CRANK OIL SEAL BS6-PH2	TATA spare parts
513758902410	SPANNER BS6-PH2	TATA spare parts
513758902604	GEARBOX MOUNTING PLATE BS6-PH2	TATA spare parts
513758903301	DRIFT BS6-PH2	TATA spare parts
513758903302	BEARING INSTALLATION (BRG OD 130) BS6-PH2	TATA spare parts
513758903307	DRIFT BS6-PH2	TATA spare parts
513758903308	BEARING REMOVAL (BEARING OD 130) BS6-PH2	TATA spare parts
513758903309	HUB LOCKNUT SOCKET (A/F 92) BS6-PH2	TATA spare parts
513758903310	HUB - LOCK NUT SOCKET BS6-PH2	TATA spare parts
513758903311	ADAPTER THREAD PROTECTION (M60X1.5) BS6-PH2	TATA spare parts
513758903312	THREAD PROTECTION TOOL BS6-PH2	TATA spare parts
513758903501	HANDLE BS6-PH2	TATA spare parts
513758903502	BEARING INSTALLATION TOOL -DRIFT BS6-PH2	TATA spare parts

513758903503	BEARING INSTALLATION TOOL -DRIFT BS6-PH2	TATA spare parts
513758903504	BEARING REMOVAL TOOL-DRIFT BS6-PH2	TATA spare parts
513758903505	BEARING REMOVAL TOOL-DRIFT BS6-PH2	TATA spare parts
513758903510	HUB - LOCK NUT SOCKET BS6-PH2	TATA spare parts
513758903511	THREAD PROTECTION TOOL BS6-PH2	TATA spare parts
513758903512	THREAD PROTECTION TOOL BS6-PH2	TATA spare parts
513758903514	DRIFT FITMENT OF BEARING BS6-PH2	TATA spare parts
513758903515	DRIFT REMOVAL OF BEARING BS6-PH2	TATA spare parts
513760000105BF	ASSY BODY SHELL ARCTIC_WHITE BS6	TATA spare parts
513760100104CN	IRISH_CREAM-BODY SHELL ASSY PAINTED BS6	TATA spare parts
513760100104JS	TITANIUM WH-BODY SHELL ASSY PAINTED BS6	TATA spare parts
513760100116BF	ARCTIC WHITE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
513760100129JS	TITANIUM WH-BODY SHELL ASSY PAINTED BS6	TATA spare parts
513760100132	TUBE ASSY WITH BRACKET BS6	TATA spare parts
513760100134	TUBE ASSY WIHT BRACKET BS6	TATA spare parts
513760100149CN	IRISH_CREAM-BODY SHELL ASSY PAINTED BS6	TATA spare parts
513760100149HU	ASSY BODY SHELL AZURE_BLUE BS6	TATA spare parts
513760100149JS	TITANIUM_WH-BODY SHELL ASSY PAINTED BS6	TATA spare parts
513760110113BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
513760110170	GUSSET ASSY CROSS MEMBER LH BS6-PH2	TATA spare parts
51376011M10172	TUBE ASSY REAR BS6-PH2	TATA spare parts
51376060M10104	DASHBOARD CROSS MEMBER ASSY BS6-PH2	TATA spare parts
513761200101	CROSS MEMBER ASSY REAR BS6	TATA spare parts
51376120M10103	CROSS MEMBER ASSY REAR BS6-PH2	TATA spare parts
51376120M10107	ASSY REAR SILL COMPLETE FACELIFIT HT BS6	TATA spare parts
51376120M10108	ASSY REAR SILL COMPLETE FACELIFIT BS6-PH	TATA spare parts
513761600108	WHEEL ARCH ASSY INNER-LH BS6	TATA spare parts
513761600111	COVER ASSY ENGINE BS6	TATA spare parts
513761600114	GUSSET ASSY CROSS MEMBER SUPPORT REAR-RH	TATA spare parts
513761600141	MIDDLE FLOOR ASSY BS6	TATA spare parts
513761600149	FRONT FLOOR ASSY BS6	TATA spare parts
513761600152	FLOOR ASSY BS6	TATA spare parts
513761600201	WHEEL ARCH ASSY INNER-LH BS6	TATA spare parts
51376160M10123	CAB MTG CLOSING ASSY LH BS6-PH2	TATA spare parts
51376160M10132	COVER ASSY ENGINE BS6-PH2	TATA spare parts
51376160M10140	VERTICAL WALL ASSY BS6-PH2	TATA spare parts
51376160M10141	MIDDLE FLOOR ASSY BS6-PH2	TATA spare parts
51376160M10143	ASSY SILL INNER FRONT LH BS6-PH2	TATA spare parts
51376160M10144	ASSY SILL INNER FRONT RH BS6-PH2	TATA spare parts
51376160M10147	FRONT FLOOR ASSY BS6-PH2	TATA spare parts
51376160M10158	COVER ASSY ENGINE BS6-PH2	TATA spare parts
51376160M10168	BUMPER MTG ASSY FRONT-CENTER BS6-PH2	TATA spare parts
51376160M10173	WHEEL ARCH ASSY RH BS6-PH2	TATA spare parts
51376160M10175	WHEEL ARCH ASSY LH BS6-PH2	TATA spare parts
51376160M10176	WHEEL ARCH ASSY RH BS6-PH2	TATA spare parts
51376160M10191	ASSY CAB MTG CLOSING RH - ACE BSIV BS6-P	TATA spare parts
51376160M10196	BRACKET ASSY CAB CLOSURE MTG LH BS6-PH2	TATA spare parts

513761800102	MIDDLE FLOOR ASSY BS6	TATA spare parts
513761800104	REAR FLOOR ASSY REAR BS6	TATA spare parts
51376180M10105	REAR FLOOR ASSY REAR BS6-PH2	TATA spare parts
513762000101	FRONT WALL ASSY BS6	TATA spare parts
51376200M10104	FRONT WALL ASSY BS6-PH2	TATA spare parts
51376250M10102	PANEL ASSY WINDSHIELD SUPPORT BS6-PH2	TATA spare parts
513763000101	SIDE WALL ASSY LHBS6	TATA spare parts
513763000102	SIDE WALL ASSY RHBS6	TATA spare parts
513763000107	SIDE WALL ASSY LH BS6	TATA spare parts
513763000108	SIDE WALL ASSY RH BS6	TATA spare parts
513763000109	ASSY SIDE WALL LH BS6	TATA spare parts
513763000110	ASSY SIDE WALL RH BS6	TATA spare parts
51376300M10103	SIDE WALL ASSY LH BS6-PH2	TATA spare parts
51376300M10104	SIDE WALL ASSY RH BS6-PH2	TATA spare parts
51376300M10111	SIDE WALL ASSY OUTER-RH BS6-PH2	TATA spare parts
51376300M10112	SIDE WALL ASSY RH BS6-PH2	TATA spare parts
51376300M10114	SIDE WALL ASSY OUTER-LH BS6-PH2	TATA spare parts
51376300M10115	SIDE WALL ASSY OUTER-LH BS6-PH2	TATA spare parts
513763200101	BRACKET ASSY SNORKEL MTG TOP BS6-PH2	TATA spare parts
513763200102	BRACKET ASSY SNORKEL MTG TOP BS6-PH2	TATA spare parts
513763203303	BRACKET FRONT PANEL MTG TOP-LH BS6-PH2	TATA spare parts
513763203304	BRACKET FRONT PANEL MTG TOP-RH BS6-PH2	TATA spare parts
513763203305	BRKT FRONT PANEL MTG BOTTOM-LH BS6-PH2	TATA spare parts
513763203306	BRKT FRONT PANEL MTG BOTTOM-RH BS6-PH2	TATA spare parts
513763700108	SIDE OUTER ASSY LH BS6	TATA spare parts
513763700109	FRONT SIDE ASSY OUTER-LH BS6	TATA spare parts
513763700113	SIDE WALL ASSY OUTER-LH BS6-PH2	TATA spare parts
51376370M10101	SIDE OUTER ASSY LH BS6-PH2	TATA spare parts
51376370M10106	SIDE OUTER ASSY RH BS6-PH2	TATA spare parts
51376370M10108	SIDE OUTER ASSY LH BS6-PH2	TATA spare parts
51376370M10110	ASSY SIDE OUTER RH BS6-PH2	TATA spare parts
513764000101	REAR WALL ASSY BS6	TATA spare parts
51376400M10104	REAR WALL ASSY BS6-PH2	TATA spare parts
513765708201	PANEL ROOF BS6	TATA spare parts
513768406301	COVER UREA TANK PIPE BS6	TATA spare parts
513768406308	CARPET ENGINE COVER BS6-PH2	TATA spare parts
513768406308C7	GRANIT_BLACK-CARPET ENGINE COVER BS6-PH2	TATA spare parts
513768406309	INSULATION ENGINE COVER BS6-PH2	TATA spare parts
513768406312	CARPET ENGINE COVER BS6-PH2	TATA spare parts
513768406312C7	GRANIT_BLACK-CARPET ENGINE COVER BS6-PH2	TATA spare parts
513768706304	CARPET VERTICAL WALL BS6-PH2	TATA spare parts
513768706304C7	GRANIT_BLACK-CARPET VERTICAL WALL BS6-PH	TATA spare parts
513768706306	CARPET FRONT WALL BS6-PH2	TATA spare parts
513768706306C7	GRANIT_BLACK-CARPET FRONT WALL BS6-PH2	TATA spare parts
513768706307	FLOOR CARPET WITH INSULATION BS6-PH2	TATA spare parts
513768706307C7	GRANIT_BLACK-FLOOR CARPET WITH INSULATIO	TATA spare parts
513768706308	INSULATION VERTICAL WALL UPPER BS6-PH2	TATA spare parts

513768706309	INSULATION VERTICAL WALL LOWER BS6-PH2	TATA spare parts
513768706310	CARPET VERTICAL WALL BS6-PH2	TATA spare parts
513768706310C7	GRANIT_BLACK-CARPET VERTICAL WALL BS6-PH	TATA spare parts
513768706311	FLOOR CARPET WITH INSULATION BS6-PH2	TATA spare parts
513768706313	INSULATION ENGINE COVER BS6-PH2	TATA spare parts
513769106301	TAIL LAMP TRIM LH BS6	TATA spare parts
513769106302	TAIL LAMP TRIM RH BS6	TATA spare parts
513769300101	COVER ASSY GEAR SHIFT LEVER BS6-PH2	TATA spare parts
513769300101C7	GRANIT_BLACK-COVER ASSY GR SHIFT LEVER B	TATA spare parts
513769300102	BOOT RING ASSY BS6-PH2	TATA spare parts
513769300102ZZ	CLRPART_ASSY-BOOT RING ASSY BS6-PH2	TATA spare parts
513769300103	COVER ASSY GEAR SHIFT LEVER BS6-PH2	TATA spare parts
513769300103C7	GRANIT_BLACK-COVER ASSY GEAR SHIFT LEVER	TATA spare parts
513769406301	LINER REAR WALL BS6	TATA spare parts
513769500101	HEADLINER ASSY REAR BS6	TATA spare parts
513769500101ZZ	HEADLINER ASSY REAR BS6-PH2	TATA spare parts
51377000M10006	ASSY SKIRT PANEL TAILGATE BS6-PH2	TATA spare parts
51377200M10101	DOOR SHELL ASSY FRONT DOOR LH BS6-PH2	TATA spare parts
51377200M10104	DOOR SHELL ASSY FRONT DOOR RH BS6-PH2	TATA spare parts
51377200M10105	DOOR SHELL ASSY FRONT DOOR LH BS6-PH2	TATA spare parts
51377200M10106	DOOR SHELL ASSY FRONT DOOR RH BS6-PH2	TATA spare parts
513772320102	FUEL LID LOCK ASSY BS6	TATA spare parts
513772980102	KIT-LOCK SET ASSY BS6	TATA spare parts
513772980104	KIT-LOCK SET ASSY BS6-PH2	TATA spare parts
51377300M10104	ASSY REAR DOOR COMP WITH HINGES BS6-PH2	TATA spare parts
51377300M10107	REAR DOOR BIW ASSY WITH HINGE LH BS6-PH2	TATA spare parts
51377300M10108	REAR DOOR BIW ASSY WITH HINGE RH BS6-PH2	TATA spare parts
513774000103	TAILGATE SHELL ASSY BS6	TATA spare parts
51377400M10101	ASSY TAILGATE SHELL COMP WITH HINGES BS6	TATA spare parts
51377400M10106	TAILGATE SHELL ASSY BS6-PH2	TATA spare parts
513774200103	STAY ROD ASSY BS6	TATA spare parts
513774306301	DOOR STRAP ASSY BS6	TATA spare parts
513779100120	TUBULAR STRUCTURE ASSY BS6	TATA spare parts
513779100123	TUBULAR STRUCTURE ASSY BS6	TATA spare parts
51377910M10110	ASSY STRIKER MTG BRACKET TAILGATE BS6-PH	TATA spare parts
51377910M10122	TUBULAR STRUCTURE ASSY BS6-PH2	TATA spare parts
51377910M10124	TUBULAR STRUCTURE ASSY BS6-PH2	TATA spare parts
513781100101	COVER ASSY HEADLAMP LH BS6-PH2	TATA spare parts
513781100101ZZ	CLRPART_ASSY-COVER ASSY HEADLAMP LH BS6-	TATA spare parts
513781100102	COVER ASSY HEADLAMP RH BS6-PH2	TATA spare parts
513781100102ZZ	CLRPART_ASSY-COVER ASSY HEADLAMP RH BS6-	TATA spare parts
513781106303	CAP HEADLAMP COVER LH BS6-PH2	TATA spare parts
513781106304	CAP HEADLAMP COVER RH BS6-PH2	TATA spare parts
513781207701	SEAL HEADLAMP COVER-LH BS6-PH2	TATA spare parts
513781207702	SEAL HEADLAMP COVER-RH BS6-PH2	TATA spare parts
513781207703	SEAL HEADLAMP COVER-LH BS6-PH2	TATA spare parts
513781207704	SEAL HEADLAMP COVER-RH BS6-PH2	TATA spare parts

513781207707	GROMMET HEADLAMP COVER BS6-PH2	TATA spare parts
513781306301	PIPE COVER BS6	TATA spare parts
513783400101	VENTILATION DUCT ASSY RH BS6-PH2	TATA spare parts
513783400103	FRONT GRILLE ASSY BS6-PH2	TATA spare parts
513783800101	PLATE ASSY BS6-PH2	TATA spare parts
513785100101	CARRIER FRAME BS6	TATA spare parts
513786100101	STRETCHER ASSY BS6	TATA spare parts
513786500104	BRACKET BS6	TATA spare parts
513786706301	COVER BS6	TATA spare parts
513786706302	COVER BS6	TATA spare parts
513786800103	CIRCLIP BS6	TATA spare parts
513786806301	SIDE PAD ASSY BS6	TATA spare parts
513786806302	SIDE PAD ASSY BS6	TATA spare parts
513786806303	SIDE PAD ASSY BS6	TATA spare parts
513786806304	COVER BS6	TATA spare parts
513788300101	FOOT STEP STRUCTURE ASSY REAR BS6	TATA spare parts
51378840M10102	FRONT PANEL ASSY BS6-PH2	TATA spare parts
513788460101	BRACKET ASSY BUMPER MTG LH BS6-PH2	TATA spare parts
513788460102	BRACKET ASSY BUMPER MTG RH BS6-PH2	TATA spare parts
513788460107	SUPPORT CHANNEL ASSY BS6-PH2	TATA spare parts
513788463305	BRACKET BUMPER SIDE MTG LH BS6-PH2	TATA spare parts
513788463306	BRACKET BUMPER SIDE MTG RH BS6-PH2	TATA spare parts
513788500101	FRONT BUMPER ASSY BS6-PH2	TATA spare parts
513788506302	REFLECTIVE TAPE FRONT BUMPER BS6-PH2	TATA spare parts
513788506304	REFLECTIVE TAPE FRONT BUMPER BS6-PH2	TATA spare parts
513788530102	TOP GRILL ASSY FRONT BUMPER BS6-PH2	TATA spare parts
513788707701	SEAL ENGINE HOOD BS6-PH2	TATA spare parts
513788806305	SPACER BS6	TATA spare parts
5137A9Z0170001CN	IRISH CREAM LOADBODY FITTED ASSY MFG BS6	TATA spare parts
5137A9Z0170001JS	TITANIUM WH - LOADBODY FITTED ASSY MFG B	TATA spare parts
5137A9Z0170002	LOADBODY FITTED ASSY MFG BS6-PH2	TATA spare parts
5137D9Y0160002CN	IRISH_CREAM-PAINTED BODY SHELL-MFG2 BS6-	TATA spare parts
5137D9Y0160002JS	TITANIUM_WH - PAINTED BODY SHELL-MFG BS6	TATA spare parts
5137D9Y0160003CN	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
5137D9Y0160011BF	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
5137D9Y0160012BF	PAINTED BODY SHELL-ARCTIC_WHITE BS6-PH2	TATA spare parts
5137D9Y0160012FD	PAINTED BODY SHELL-SK_GOLN_YELW BS6-PH2	TATA spare parts
5137H9X0233001	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
5137H9X0233002	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
5137H9X0233003	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
514030200001	FRONT FRP SHOW	TATA spare parts
514030210001	FRONT FRP CENTRE FLAP	TATA spare parts
514030220001	FRONT FRP SIDE LAMP BAZEL FLAP LH	TATA spare parts
514030230001	FRONT FRP SIDE LAMP BAZEL FLAP RH	TATA spare parts
514031010001	HEADLAMP HOUSING LH	TATA spare parts
514031020001	HEADLAMP HOUSING RH	TATA spare parts
514031030001	FRONT SIDE PLATE RH	TATA spare parts

514031040001	FRONT SIDE PLATE LH	TATA spare parts
514040240001	HINGE ASSY (HEAD LIGHT FRP)	TATA spare parts
51410236000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 1923 BS6	TATA spare parts
51410536000RCK	ASSY CABIN W/FITMENTS SIGNA 1923.K BS6	TATA spare parts
514141110101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
514141120102	PROPELLER¿SHAFT¿ASSY DRIVE¿ BS6	TATA spare parts
514141120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
514141990101	SHORTFORKTUBE&REARENDPIECEASSY BS6	TATA spare parts
514154600101	WIRING HARNESS TAIL BS6	TATA spare parts
514154600102	WIRING HARNESS ABS FRAME BS6	TATA spare parts
514154600103	WIRING HARNESS ENGINE BS6	TATA spare parts
514154620101	PIGTAIL SCR WIRING HARNESS BS6	TATA spare parts
514154620102	PIGTAIL FUEL HEATER WIRING HARNESS BS6	TATA spare parts
514154620103	PIGTAIL GRID HEATER CONTROLLER UNIT BS6	TATA spare parts
51416000013RCJO	SIGNA 1923.K BSVI_CAB/COWL	TATA spare parts
514430110001	REAR FRP SHOW	TATA spare parts
514430130001	REAR SIDE PLATE RH	TATA spare parts
514430140001	REAR SIDE PLATE LH	TATA spare parts
514430150001	REAR BUMPER	TATA spare parts
514430330001	TAIL LAMP HOUSING LH	TATA spare parts
514430340001	TAIL LAMP HOUSING RH	TATA spare parts
514430350001	REAR LID	TATA spare parts
514610030001	REAR FLAP ASSEMBLY	TATA spare parts
51470133000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 5525.S B	TATA spare parts
51470233000RCK	ASSY CABIN KIT W/FITMENTS SIGNA 5525 BS6	TATA spare parts
51471133000RCK	ASSY CABIN KIT W/FITMENT SIGNA 5530.S BS	TATA spare parts
51471133100RCK	ASSY CABIN KIT W/FITMENT SIGNA5530.S BS6	TATA spare parts
51471233000RCK	ASSY CABIN KIT W/FITMENT SIGNA 5530.S BS	TATA spare parts
51472333000RCK	CABIN W/FITMENT TATA SIGNA 5530.S BS6-PH	TATA spare parts
51472433000RCK	CABIN KIT W/FITMENT SIGNA 5530.S BS6-PH2	TATA spare parts
51473100M10002	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
514743900101	BUNCH ASSY PIPE BS6	TATA spare parts
514746305101	PITMAN ARM BS6-PH2	TATA spare parts
514746800101	SUCTION LINE ASSY BS6	TATA spare parts
514746800103	RTN LINE ASSY STG GR BOX END BS6-PH2	TATA spare parts
514746800104	RETURN LINE ASSY STG GEAR BOX END BS6 PH	TATA spare parts
514746800113	HIGH PRESSURE LINE ASSY STG GB END BS6-P	TATA spare parts
514746900101	DRAG LINK ASSY BS6-PH2	TATA spare parts
514746900102	DRAG LINK ASSY FRONT BS6	TATA spare parts
514749200106	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
514749200108	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6-P	TATA spare parts
514754610102	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
514754620101	WIRING HARNESS ENGINE BS6	TATA spare parts
514754630102	WIRING HARNESS TAIL BS6	TATA spare parts
514754630105	WIRING HARNESS TAIL BS6 PH2	TATA spare parts
514754630106	BRACKET JUMPER CABLE MTG BS6 PH2	TATA spare parts
514754633303	BRACKET JUMPER CABLE MTG BS6-PH2	TATA spare parts

514834200101	L-PLATE LH BS6-PH2	TATA spare parts
514834200102	L-PLATE RH BS6-PH2	TATA spare parts
514841120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
514841120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
514841990102	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
514841990103	FLANGE YOKE BS6	TATA spare parts
514841990104	UNIVERSAL JOINT BS6	TATA spare parts
514841990106	LONG FORK ASSY BS6	TATA spare parts
514846100101	STEERING COLUMN ASSY TILT & TELESCOPIC B	TATA spare parts
514846800101	PRESSURE LINE ASSY BS6	TATA spare parts
514849200101	BRACKET ASSY-EGP MTG BS6	TATA spare parts
514849200102	BRACKET ASSY-EGP MTG BS6	TATA spare parts
514849200103	BRACKET ASSY-EGP MTG-REAR BS6	TATA spare parts
514849200105	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
514849200106	BRACKET ASSY EGP MTG REAR BS6-PH2	TATA spare parts
514849207101	SPACER PLATE BS6-PH2	TATA spare parts
514931000106	FRAME ASSY WITH FITMENT BS6	TATA spare parts
514931000108	FRAME ASSY WITH FITMENT BS6	TATA spare parts
514931200103	CROSS MEMBER ASSY WITH GUSSET BS6	TATA spare parts
514931300101	REINFORCEMENT ASSY BS6	TATA spare parts
514931300103	REINFORCEMENT ASSY BS6	TATA spare parts
514931307105	REINFORCEMENT BUMPER CROSS MEMBER RH BS	TATA spare parts
514931307118	REINFORCEMENT BUMPER CROSS MEMBER LH BS	TATA spare parts
514941110101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
514941120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
514941120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
514941300101	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
514941300102	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
514943900104	PIPE BUNCH ASSY BS6	TATA spare parts
514943900121	PIPE BUNCH ASSY BS6	TATA spare parts
514954630102	WIRING HARNESS ABS FRAME BS6	TATA spare parts
515031000102	FRAME ASSY WITH FITMENT BS6	TATA spare parts
515031000106	FRAME ASSY WITH FITMENT BS6	TATA spare parts
515031200102	CROSS MEMBER ASSY BS6	TATA spare parts
515031200103	CROSS MEMBER ASSY BS6	TATA spare parts
515031200105	SUPPORT ASSY RH BS6	TATA spare parts
515031200106	SUPPORT ASSY LH BS6	TATA spare parts
515031200111	CROSS MEMBER ASSY BS6	TATA spare parts
515031300101	REINFORCEMENT ASSY BS6	TATA spare parts
515031300102	REINFORCEMENT ASSY BS6	TATA spare parts
515031307110	BRACKET REINFORCEMENT BS6	TATA spare parts
515031327101	SPACER PLATE REAR BS6-PH2	TATA spare parts
515031327102	SPACER PLATE REAR BS6-PH2	TATA spare parts
515031327103	SPACER PLATE REAR BS6-PH2	TATA spare parts
515041100101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
515041110103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
515041120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts



515041120103	PROPELLER SHAFT ASSY-DRIVE BS6	TATA spare parts
515041300101	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
515041300102	BRACKET ASSY-CENTER BRG MTG BS6	TATA spare parts
515041300107	BRACKET CENTER BRG MTG BS6	TATA spare parts
515043200102	AIR TANK ASSY BS6	TATA spare parts
515043900101	PIPE BUNCH ASSY BS6	TATA spare parts
515043900117	METAL PIPE ASSY BS6	TATA spare parts
515043900121	PIPE ASSY BS6	TATA spare parts
515043900125	PIPE BUNCH ASSY BS6	TATA spare parts
515046305102	PITMAN ARM BS6	TATA spare parts
515046305103	PITMAN ARM BS6	TATA spare parts
515046800101	PRESSURE LINE ASSY BS6	TATA spare parts
515046800102	SUCTION LINE ASSY BS6	TATA spare parts
515046800103	PRESSURE LINE ASSY BS6	TATA spare parts
515046800104	SUCTION LINE ASSY BS6	TATA spare parts
515046800106	RETURN LINE ASSY BS6	TATA spare parts
515046900101	DRAG LINK ASSY BS6	TATA spare parts
515046900102	DRAG LINK ASSY BS6	TATA spare parts
515047508207	STONE GUARD BS6	TATA spare parts
515047600123	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
515047600124	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
515047600125	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
515047600126	VENT TUBE ASSY BS6	TATA spare parts
515047600127	VENT TUBE ASSY BS6	TATA spare parts
515047600128	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
515047600129	VENT TUBE ASSY - BS6	TATA spare parts
515047600131	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
515047600136	VENT PIPE ASSY BS6	TATA spare parts
515047600137	VENT PIPE ASSY BS6	TATA spare parts
515047600138	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
515047600139	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
515047600140	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
515049200101	BRACKET ASSY EXHAUST MTG BS6	TATA spare parts
515049200102	BRACKET ASSY BS6	TATA spare parts
515049200103	BRACKET ASSY EXHAUST MTG BS6	TATA spare parts
515049200105	PIPE ASSY INTERMEDIATE BS6	TATA spare parts
515049200107	PIPE ASSY INTERMEDIATE BS6	TATA spare parts
515049200110	BRACKET ASSY BS6	TATA spare parts
515049200111	CLAMP ASSY CATCON BS6	TATA spare parts
515049200112	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
515049200113	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
515049200114	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
515049203303	L-BRACKET BS6	TATA spare parts
515049203307	L-BRACKET EXHAUST MTG BS6	TATA spare parts
515049203309	BRACKET BS6	TATA spare parts
515049203315	BRACKET EXHAUST PIPE BS6	TATA spare parts
515049203317	BRACKET BS6	TATA spare parts

515049203319	L-BRACKET ASSY EXHAUST MTG BS6	TATA spare parts
515049203321	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
515049600103	HEAT SHIELD ASSY BS6	TATA spare parts
515049600104	HEAT SHIELD ASSY BS6	TATA spare parts
515049600105	HEAT SHIELD ASSY BS6	TATA spare parts
515049600108	HEAT SHILED ASSY BS6	TATA spare parts
515049600111	HEAT SHIELD ASSY PIPE BS6	TATA spare parts
515049600112	HEAT SHIELD ASSY PIPE BS6	TATA spare parts
515049990101	HEAT SHIELD ASSY BS6	TATA spare parts
515049990102	HEAT SHIELD ASSY CATCON BS6	TATA spare parts
515049990105	COVER HEAT SHIELD BS6	TATA spare parts
515049990106	HEAT SHIELD ASSY BS6	TATA spare parts
515054500101	BRKT ASSY BATTERY CUT OFF SWITCH MTG BS6	TATA spare parts
515054610107	WIRING HARNESS MAIN	TATA spare parts
515054610130	WIRING HARNESS MAIN BS6	TATA spare parts
515054620101	WIRING HARNESS ENGINE BS6	TATA spare parts
515054620104	WIRING HARNESS ENGINE BS6	TATA spare parts
515054630101	WIRING HARNESS TAIL BS6	TATA spare parts
515054630102	WIRING HARNESS TAIL BS6	TATA spare parts
515054630103	WIRING HARNESS ABS FRAME BS6	TATA spare parts
515054630104	CYLINDER EARTHING ASSY BS6	TATA spare parts
515054640101	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
515054640103	BATTERY CABLE +VE ELE BCS O/P TO BCS I/P	TATA spare parts
515054900102	BRACKET ASSY ECU MTG BS6	TATA spare parts
515054903301	COVER ASSY ECU BS6	TATA spare parts
51521233000RCK	CABIN W/FITMENTS TATA SIGNA 4021.S 5L BS	TATA spare parts
51521333000RCK	CABIN W/FITMENTS TATA SIGNA 4021.S 5L BS	TATA spare parts
515229300101	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
515229300110	BUNDY TUBE ASSY LONG MEMBER BS6-PH2	TATA spare parts
515230100101	BRACKET ASSY ACCELERATOR MTG BS6-PH2	TATA spare parts
51523100M10102	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
515241120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
515241990102	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
515243703301	L-BRACKET BS6-PH2	TATA spare parts
515243900101	METAL PIPE ASSY BS6-PH2	TATA spare parts
515243900104	BUNCH ASSY PIPE BS6-PH2	TATA spare parts
515246800104	PRESSURE LINE ASSY STG GEAR BOX END BS6-	TATA spare parts
515246800105	PRESSURE LINE ASSY STG GEAR BOX END BS6-	TATA spare parts
515246800106	RETURN LINE ASSY STG GEAR BOX END BS6-PH	TATA spare parts
515246800107	RETURN LINE ASSY STG GEAR BOX END BS6-PH	TATA spare parts
515247600101	FUEL SUCTION PIPE ASSY TANK TO W/SEP - B	TATA spare parts
515247600102	SUCTION PIPE ASSY FUEL FTR TO PRIM PUMP	TATA spare parts
515247600103	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
515247600104	FUEL RETURN PIPE ASSY - BS6	TATA spare parts
515247600105	FUEL RETURN PIPE ASSY ENGINE TO T-CONN -	TATA spare parts
515247600109	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
515247600110	FUEL RETURN PIPE ASSY ENGINE TO T-CONN B	TATA spare parts

515247600111	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
515247600112	SUCTION PIPE ASSY PUMP TO FILTER BS6-PH2	TATA spare parts
515247700101	BRACKET ASSY BS6-PH2	TATA spare parts
515249200101	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
515249200103	BRACKET ASSY EGP MTG BS6	TATA spare parts
515249200105	SUCTION PIPE BS6	TATA spare parts
515249200107	PIPE ASSY UREA RETURN BS6	TATA spare parts
515249200109	BRACKET ASSY EGP MTG BS6	TATA spare parts
515249200110	PRESSURE LINE SM TO DM BS6	TATA spare parts
515249200111	PIPE ASSY UREA RETURN BS6-PH2	TATA spare parts
515249200118	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
515249200119	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
515249200140	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6-P	TATA spare parts
515249200141	EXHAUST TAIL PIPE ASSY BS6-PH2	TATA spare parts
515249200147	SUCTION PIPE BS6-PH2	TATA spare parts
515249203301	BRACKET TAIL PIPE BS6	TATA spare parts
515249203302	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
515249203309	L-BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
515249203316	L-BRACKET BS6-PH2	TATA spare parts
515249204201	CLAMP BS6	TATA spare parts
515254610107	WIRING HARNESS MAIN ASSY BS6-PH2	TATA spare parts
515254630104	WIRING HARNESS SCR UNIT BS6	TATA spare parts
515254630105	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
515254630106	WIRING HARNESS SCR UNIT BS6-PH2	TATA spare parts
515254630107	ADD ON WIRING HARNESS BS6	TATA spare parts
515254630108	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
515254630109	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
515254630111	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
515254633301	BRACKET INLINE CONN MTG BS6-PH2	TATA spare parts
515331000104	FRAME ASSY WITH FITMENT BS6	TATA spare parts
515331400101	CROSS MEMBER ASSY BS6	TATA spare parts
515333800101	TIE ROD ASSY BS6-PH2	TATA spare parts
515333805101	STEERING ARM BS6-PH2	TATA spare parts
515369306301	UTILITY BOX BS6-PH2	TATA spare parts
5153D2A0468001	CCB ASSY BS6-PH2	TATA spare parts
5153D2A0468004	CCB ASSY BS6-PH2	TATA spare parts
5153D9Z0160001	FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
515441120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
515446800101	SUCTION LINE ASSY BS6-PH2	TATA spare parts
515446800102	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
515447600101	SUCTION PIPE ASSY FUEL TANK TO FILTER BS	TATA spare parts
515447600102	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
515447600103	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
515447600105	RETURN PIPE ASSY ENGINE TO CONN BS6	TATA spare parts
515454620102	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
515454630103	WIRING HARNESS EGP BS6-PH2	TATA spare parts
515454630105	WIRING HARNESS TAIL BS6	TATA spare parts

51553100M10104	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51553100M10105	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51553100M10108	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
515531107109	L-REINFORCEMENT TOP-RH BS6-PH2	TATA spare parts
515531107110	L-REINFORCEMENT TOP-LH BS6-PH2	TATA spare parts
515531107111	L-REINFORCEMENT BOTTOM-RH BS6-PH2	TATA spare parts
515531107112	L-REINFORCEMENT BOTTOM-LH BS6-PH2	TATA spare parts
515541110103	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
515541120102	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
515541120104	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
515541300101	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
515541990101	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
515543200101	AIR TANK ASSY WITH BKTS & STRAP BS6-PH2	TATA spare parts
515543200102	CHANNEL ASSY AIR TANK MTG BS6-PH2	TATA spare parts
515543208202	L-BRACKET BS6-PH2	TATA spare parts
515543700102	AIR TANK ASSY BS6-PH2	TATA spare parts
515543900118	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
515543900140	METAL PIPE ASSY BS6 PH2	TATA spare parts
515543900141	METAL PIPE ASSY HOSE TO INT JOINT BS6-PH	TATA spare parts
515543900144	METAL PIPE ASSY BS6 PH2	TATA spare parts
515543900145	METAL PIPE ASSY BS6 PH2	TATA spare parts
515543900152	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
515543900183	METAL PIPE ASSY BS6-PH2	TATA spare parts
515546800101	SUCTION LINE ASSY BS6-PH2	TATA spare parts
515546800105	PRESSURE LINE ASSY STG GR BOX END BS6-PH	TATA spare parts
515546800106	PR LINE ASSY STG GEAR BOX END BS6-PH2	TATA spare parts
515547600104	FUEL SUCT.PIPE ASSY TANK - W/SEP BS6-PH2	TATA spare parts
515547600105	SUCTION PIPE ASSY FILTER TO ENG BS6-PH2	TATA spare parts
515547600106	RETURN FUEL PIPE ASSY BS6-PH2	TATA spare parts
515549200106	BRACKET ASSY TAIL PIPE MTG BS6 PH2	TATA spare parts
515549200107	STRUCTURE ASSY BS6-PH2	TATA spare parts
515549200113	BRACKET ASSY BS6 PH2	TATA spare parts
515549200115	EXT PIPE ASSY WITH FLEX BELLOW BS6-PH2	TATA spare parts
515549200124	PRESSURE LINE SM TO DM BS6-PH2	TATA spare parts
515549200126	RETURN LINE DM TO TANK BS6-PH2	TATA spare parts
515554504901	ATC SWITCH DASHBOARD BS6-PH2	TATA spare parts
515554620101	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
515554620103	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
515554630101	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
515554630102	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
515554630103	WIRING HARNESS SCR UNIT BS6-PH2	TATA spare parts
515554630104	WIRING HARNESS ABS FRAME 4S3M BS6-PH2	TATA spare parts
515554630105	WIRING HARNESS ABS FRAME 4S3M BS6-PH2	TATA spare parts
515554640102	CABLE BATT TAP +VE TO MANUAL CUT OFF +VE	TATA spare parts
515554640103	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
51556160M10110	FLOOR PANEL ASSY CENTER NSLPR BS6-PH2	TATA spare parts
51556160M10114	MUDGUARD ASSY REAR-LH BS6-PH2	TATA spare parts

51556160M10115	MUDGUARD ASSY REAR-RH BS6-PH2	TATA spare parts
51556160M10116	FLOOR PANEL ASSY LH NSLPR BS6-PH2	TATA spare parts
51556160M10117	FLOOR PANEL ASSY RH NSLPR BS6-PH2	TATA spare parts
51556160M10130	REINF ASSY FLOOR WHEEL ARCH LH BS6-PH2	TATA spare parts
51556160M10131	REINF ASSY FLOOR WHEEL ARCH RH BS6-PH2	TATA spare parts
51556470M10103	CORNER PANEL ASSY RH NSLPR BS6-PH2	TATA spare parts
51556470M10116	PANEL REAR WALL BS6-PH2	TATA spare parts
51556470M10118	CORNER PANEL ASSY LH NSLPR BS6-PH2	TATA spare parts
5155D9Y0160001	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
51563100M10001	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
515631107109	REINFORCEMENT BUMPER CROSS MEMBER RH BS6-PH2	TATA spare parts
515631107110	REINFORCEMENT BUMPER CROSS MEMBER LH BS6-PH2	TATA spare parts
515631700101	BRACKET ASSY RAIDATOR MTG RH BS6-PH2	TATA spare parts
515631700102	BRACKET ASSY RAIDATOR MTG LH BS6-PH2	TATA spare parts
515632100101	LEAF SPRING ASSY FRONT BS6-PH2	TATA spare parts
515632107101	8TH LEAF BS6-PH2	TATA spare parts
515632107103	9TH LEAF BS6-PH2	TATA spare parts
515641120106	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
515643700103	KIT-BRAKE CHAMBER (MINOR KIT) BS6-PH2	TATA spare parts
515643700104	KIT-BRAKE CHAMBER (MAJOR KIT) BS6-PH2	TATA spare parts
515643900126	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
515643900139	METAL PIPE ASSY WITH CRIMPED TEFLON HOSE	TATA spare parts
515646305101	PITMAN ARM BS6-PH2	TATA spare parts
515647600105	SUCTION PIPE ASSY FUEL TANK TO FILTER BS6	TATA spare parts
515647600108	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
515647600109	SUCTION PIPE ASSY FILTER TO ENGINE BS6-P	TATA spare parts
515647600110	FUEL RETURN PIPE ASSY HP PUMP TO T-CONN	TATA spare parts
515647700101	BRACKET ASSY BS6 PH2	TATA spare parts
515649200104	TAIL PIPE ASSY BS6-PH2	TATA spare parts
515649200106	HEAT SHIELD ASSY SILENCER BS6-PH2	TATA spare parts
515649200107	HEAT SHIELD ASSY SILENCER BS6-PH2	TATA spare parts
515649200108	HEAT SHIELD ASSY FRONT BS6-PH2	TATA spare parts
515649200110	BRACKET ASSY TAIL PIPE MTG BS6-PH2	TATA spare parts
515649200118	BRACKET ASSY BS6-PH2	TATA spare parts
515649200132	STRUCTURE ASSY BS6-PH2	TATA spare parts
515649200136	BRACKET ASSY BS6-PH2	TATA spare parts
515649200138	CLAMP ASSY PIPE MTG BS6-PH2	TATA spare parts
515649200144	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6-P	TATA spare parts
515649200145	PRESSURE LINE SM TO DM BS6-PH2	TATA spare parts
515649200146	SUCTION PIPE BS6-PH2	TATA spare parts
515649200148	PRESSURE LINE SM TO DM BS6-PH2	TATA spare parts
515649200150	STAY ROD ASSY BS6-PH2	TATA spare parts
515649200154	RETURN LINE DM TO TANK BS6-PH2	TATA spare parts
515649203304	BRACKET HEAT SHIELD SUPPORT BS6-PH2	TATA spare parts
515649203312	L-BRACKET EXHAUST MTG BS6-PH2	TATA spare parts
515649203314	BRACKET BS6-PH2	TATA spare parts
515654610102	WIRING HARNESS DOOR	TATA spare parts

515654610103	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
515654630105	WIRING HARNESS SCR UNIT BS6-PH2	TATA spare parts
515654630108	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
515654630109	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
51570538000RCK	CABIN KIT W/FITMENT SIGNA 2825.K 39W BS6	TATA spare parts
515724200101	BRACKET ASSY CHASSIS LH BS6-PH2	TATA spare parts
515724200102	BRACKET ASSY CHASSIS RH BS6-PH2	TATA spare parts
51573100M10001	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51573100M10103	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
515732103201	CENTER BOLT BS6-PH2	TATA spare parts
515732107101	CASTER PLATE BS6-PH2	TATA spare parts
515741120110	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
515741120113	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
515741120114	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
515743200101	AIR TANK ASSY WITH BKTS & STRAP BS6-PH2	TATA spare parts
515743900177	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
515746700101	BRACKET ASSY RESERVOIR MTG BS6-PH2	TATA spare parts
515747600101	RETURN FUEL PIPE ASSY BS6 PH2	TATA spare parts
515747600103	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
515747600105	SUCTION PIPE ASSY FILTER TO ENGINE BS6-P	TATA spare parts
515747600106	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
515747600107	RETURN FUEL PIPE ASSY BS6-PH2	TATA spare parts
515754630113	WIRING HARNESS TAIL BS6	TATA spare parts
51580138000RCK	CABIN W/FITMENTS SIGNA 2830.K BS6-PH2	TATA spare parts
51580538000RCK	CABIN KIT W/FITMENT SIGNA 2830.TK BS6-PH	TATA spare parts
51580738000RCK	CABIN KIT W/FITMENT SIGNA 2830.K BS6-PH2	TATA spare parts
51580838000RCK	CABIN KIT W/FITMENT SIGNA 2830.TK BS6-PH	TATA spare parts
515824200103	BRACKET ASSY FRAME SIDE RH BS6-PH2	TATA spare parts
515824200104	BRACKET ASSY FRAME SIDE LH BS6-PH2	TATA spare parts
515824200105	BRACKET ASSY FRAME SIDE RH BS6 PH2	TATA spare parts
515824200106	BRACKET ASSY FRAME SIDE LH BS6 PH2	TATA spare parts
515829300104	NYLON PIPE ASSY BS6-PH2	TATA spare parts
51583100M10102	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51583100M10117	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
515831200101	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
515831203301	SUPPORT BRACKET RH BS6-PH2	TATA spare parts
515831203302	SUPPORT BRACKET LH BS6-PH2	TATA spare parts
515831203303	PLATE CROSS MEMBER BS6-PH2	TATA spare parts
515841120106	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
515841120107	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
515841120108	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
515841120109	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
515841990106	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
515842300108	DRUM BRAKE ASSY WITH DC REAR-RH BS6-PH2	TATA spare parts
515842300109	DRUM BRAKE ASSY WITH DC REAR-RH MAKE BIL	TATA spare parts
515842300110	DRUM BRAKE ASSY WITH DC REAR-LH MAKE MER	TATA spare parts
515842300111	DRUM BRAKE ASSY WITH DC REAR-RH MAKE MER	TATA spare parts

515842308201	ANCHOR BRACKET LH BS6-PH2	TATA spare parts
515842308202	ANCHOR BRACKET RH BS6-PH2	TATA spare parts
515842990107	KIT-CAMSHAFT RH BS6-PH2	TATA spare parts
515842990108	KIT-BRAKE LIED SHOE ASSY LH/RH (BIL) BS6	TATA spare parts
515842990110	KIT-SPRING BS6-PH2	TATA spare parts
515842990111	KIT-SPRING BS6-PH2	TATA spare parts
515842990112	KIT-SPRING BS6-PH2	TATA spare parts
515843200101	AIR TANK ASSY BS6 PH2	TATA spare parts
515843200104	AIR TANK ASSY BS6 PH2	TATA spare parts
515843200107	CHANNEL ASSY AIR TANK MTG BS6 PH2	TATA spare parts
515843200108	AIR TANK ASSY WITH END FITTINGS BS6-PH2	TATA spare parts
515843900109	PIPE BUNCH ASSY BS6 PH2	TATA spare parts
515843900152	METAL PIPE ASSY BS6-PH2	TATA spare parts
515843900160	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
515843900178	METAL PIPE ASSY BS6	TATA spare parts
515843900186	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
515843900226	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
515843903301	BRACKET BS6-PH2	TATA spare parts
515843910117	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
515843910148	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
515843910176	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
515843910195	PIPE BUNCH ASSY BS6	TATA spare parts
515846700101	BRACKET ASSY RESERVOIR MTG BS6 PH2	TATA spare parts
515846700102	BRACKET ASSY RESERVOIR MTG BS6-PH2	TATA spare parts
515846800101	SUCTION LINE ASSY BS6-PH2	TATA spare parts
515846800102	RETURN LINE ASSY RESERVOIR END BS6 PH2	TATA spare parts
515846800104	RTN LINE ASSY GR BOX TO INT JT BS6-PH2	TATA spare parts
515847600101	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
515847600102	SUCTION PIPE ASSY FILTER TO ENGINE BS6-P	TATA spare parts
515847600103	RETURN FUEL PIPE ASSY BS6-PH2	TATA spare parts
515847600104	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
515847600105	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
515847600107	SUCTION PIPE ASSY FILTER TO ENG BS6-PH2	TATA spare parts
515847600108	RETURN FUEL PIPE ASSY BS6	TATA spare parts
515847600111	RETURN PIPE ASSY BS6-PH2	TATA spare parts
515847600112	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
515849200105	BASE PLATE EGP MTG BKT ASSY BS6-PH2	TATA spare parts
515849200108	BRACKET ASSY BS6 PH2	TATA spare parts
515849200109	BRACKET ASSY BS6-PH2	TATA spare parts
515849200111	CLAMP ASSY PIPE MTG BS6 PH2	TATA spare parts
515849200113	HEAT SHIELD ASSY FRONT BS6 PH2	TATA spare parts
515849200114	HEAT SHIELD ASSY SILENCER BS6 PH2	TATA spare parts
515849200115	HEAT SHIELD ASSY SILENCER BS6 PH2	TATA spare parts
515849200121	STRUCTURE ASSY BS6-PH2	TATA spare parts
515849200124	BRACKET ASSY BS6 PH2	TATA spare parts
515849200133	BRACKET ASSY STAY ROD MTG BS6 PH2	TATA spare parts
515849200136	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6 P	TATA spare parts

515849200138	BRACKET ASSY BS6 PH2	TATA spare parts
515849200143	SUCTION LINE TANK TO SM BS6-PH2	TATA spare parts
515849200145	PRESSURE LINE SM TO DM BS6-PH2	TATA spare parts
515849200147	RETURN LINE DM TO TANK BS6-PH2	TATA spare parts
515849200149	RETURN LINE DM TO TANK BS6-PH2	TATA spare parts
515849200159	BRACKET ASSY BS6-PH2	TATA spare parts
515849203311	BRACKET HEAT SHIELD SUPPORT BS6-PH2	TATA spare parts
515849203314	BRACKET EXHAUST PIPE CLAMPING BS6 PH2	TATA spare parts
515849204201	CLAMP BS6 PH2	TATA spare parts
515849207114	LOCK PLATE BS6-PH2	TATA spare parts
515854600109	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
515854600110	BATTERY CABLE -VE BS6 PH2	TATA spare parts
515854603301	BRACKET INLINE CONN MTG BS6-PH2	TATA spare parts
515854610103	PIGTAIL VEHICLE TRACKING SYSTEM BS6 PH2	TATA spare parts
515854610105	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
515854610107	WIRING HARNESS DMS BS6	TATA spare parts
515854610108	BRACKET ASSY WIRING HARNESS MTG BS6-PH2	TATA spare parts
515854610109	BRACKET ASSY WIRING HARNESS MTG BS6-PH2	TATA spare parts
515854620101	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
515854620104	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
515854630101	WIRING HARNESS TAIL BS6 PH2	TATA spare parts
515854630103	WIRING HARNESS SCR UNIT BS6 PH2	TATA spare parts
515854630110	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
515854630114	WIRING HARNESS TAIL BS6	TATA spare parts
515854630117	WIRING HARNESS SCR UNIT BS6	TATA spare parts
515854630118	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
515854630120	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
515854630127	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
515854630128	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
515854630129	PIGTAIL ASSY EMS WIRING HARNESS BS6-PH2	TATA spare parts
515854630132	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
515854630134	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
515854630136	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
515854630140	WIRING HARNESS TAIL BS6	TATA spare parts
515854640113	BATTERY CABLE +VE MAXI FUSE O/P TO SM BS	TATA spare parts
515854640118	BATTERY CABLE +VE MAXI FUSE O/P TO SM BS	TATA spare parts
515870807001	PLATE BOTTOM CLAMP BS6-PH2	TATA spare parts
515887800107	RESILIENCE MTG ASSY BS6-PH2	TATA spare parts
515887800108	RESILIENCE MTG ASSY BS6-PH2	TATA spare parts
515887800111	RESILIENCE MTG ASSY BS6-PH2	TATA spare parts
515887807001	PLATE BOTTOM CLAMP BS6-PH2	TATA spare parts
5158D1A0161001	UNDER BODY SUB STRUCTURE BS6-PH2	TATA spare parts
515924200101	BRACKET ASSY CHASSIS LH BS6-PH2	TATA spare parts
515924200102	BRACKET ASSY CHASSIS RH BS6-PH2	TATA spare parts
515929300101	NYLON PIPE ASSY T-CONN TO AIR TANK BS6	TATA spare parts
515932100107	BUMP STOPPER ASSY BS6-PH2	TATA spare parts
51600356000RCK	ASSY CABIN WITH FITMENT FOR SIGNA 3530.T	TATA spare parts



51600656000RCK	CABIN W/FITMENTS SIGNA 3530.K BS6-PH2	TATA spare parts
51600756000RCK	CABIN KIT W/FITMENT SIGNA 3530.TK BS6-PH	TATA spare parts
51603100M10001	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51603100M10003	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
516041110106	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516041120110	PROPELLER SHAFT DRIVE ASSY BS6-PH2	TATA spare parts
516041120111	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516041303302	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
516041303303	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
516041990110	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
516041990112	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
516043200106	AIR TANK ASSY WITH BKT BS6-PH2	TATA spare parts
516043900141	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516043910131	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516046700101	BRACKET ASSY RESERVOIR MTG BS6-PH2	TATA spare parts
516046700102	BRACKET ASSY RESERVOIR MTG BS6-PH2	TATA spare parts
516046800101	SUCTION LINE ASSY BS6 PH2	TATA spare parts
516047600101	FUEL SUCTION PIPE ASSY FUEL TANK TO ENG	TATA spare parts
516047600102	SUCTION PIPE ASSY FILTER TO ENGINE BS6-P	TATA spare parts
516047600104	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
516047600107	RETURN PIPE ASSY ENGINE TO CONN BS6-PH2	TATA spare parts
516049200102	PRESSURE LINE SM TO DM BS6-PH2	TATA spare parts
516049200104	RETURN LINE DM TO TANK	TATA spare parts
516054603301	BRACKET INLINE CONN MTG BS6-PH2	TATA spare parts
516054603302	BRACKET WIRING HARNESS MTG BS6-PH2	TATA spare parts
516054630103	WIRING HARNESS SCR UNIT BS6-PH2	TATA spare parts
516054630104	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
516054630107	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
516054630111	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
516054630118	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
516054640104	BATTERY CABLE +VE MAXI FUSE O/P TO SM BS	TATA spare parts
516054640105	BATTERY CABLE +VE MAXI FUSE O/P TO SM BS	TATA spare parts
516087100122	SUBFRAME ASSY WITH MOUNTINGS BS6 PH2	TATA spare parts
516087800101	RESILIENCE MTG ASSY BS6-PH2	TATA spare parts
516154610101	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
51618271238	SHEET 1.25X1219X2438 D513 SS4010	TATA spare parts
51618273851	SHEET 1.6X1475X1550 D513 SS4010	TATA spare parts
51620368000RCK	CABIN KIT W/FITMENT SIGNA 4830.TK AC BS6	TATA spare parts
51620568000RCK	CABIN KIT W/FITMENT SIGNA 4830.TK BS6-PH	TATA spare parts
51620668000RCK	CABIN KIT W/FITMENT SIGNA 4830.TK BS6-PH	TATA spare parts
51620768000RCK	CABIN KIT W/FITMENT SIGNA 4830.TK BS6-PH	TATA spare parts
51623100M10001	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51623100M10003	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
516231200105	CROSS MEMBER ASSY TUBULAR BS6-PH2	TATA spare parts
516231203301	SUPPORT BRACKET RH BS6-PH2	TATA spare parts
516231203302	SUPPORT BRACKET LH BS6-PH2	TATA spare parts
516231207106	SUPPORT PLATE BS6-PH2	TATA spare parts

516232100103	BUMP STOPPER ASSY FRONT BS6-PH2	TATA spare parts
516232300102	BRACKET ASSY FRONT SHOCK ABSORBER BS6-PH	TATA spare parts
516232303301	BRACKET SHOCK ABSORBER MTG LOWER-LH BS6-	TATA spare parts
516232303302	BRACKET SHOCK ABSORBER MTG LOWER-RH BS6-	TATA spare parts
516232404202	SPRING CLIP REAR SPRING BS6-PH2	TATA spare parts
516233805104	TIE ROD ARM LH BS6 PH2	TATA spare parts
516233805106	TIE ROD ARM RH BS6 PH2	TATA spare parts
516233900201	PIPE BUNCH ASSY BS6 PH2	TATA spare parts
516233903302	BRACKET BS6-PH2	TATA spare parts
516233910111	LINK ROD ASSY BS6-PH2	TATA spare parts
516241110106	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516241110119	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516241110124	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516241110127	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516241110128	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516241120114	PROPELLER SHAFT ASSY INTERAXLE BS6-PH2	TATA spare parts
516241120115	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516241120116	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516241120117	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516241300102	BRACKET ASSY CENTER BRG MTG BS6 PH2	TATA spare parts
516241300103	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
516241303305	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
516241303307	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
516241990106	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
516241990130	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
516241990139	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
516241990140	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
516241990146	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
516241990147	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
516241990152	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
516241990154	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
516241990155	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
516243200102	AIR TANK ASSY BS6-PH2	TATA spare parts
516243200103	BRACKET ASSY BS6-PH2	TATA spare parts
516243200104	BRACKET ASSY AIR TANK MTG BS6-PH2	TATA spare parts
516243200105	AIR TANK ASSY WITH MTG BKT BS6-PH2	TATA spare parts
516243703303	BRACKET RELAY VALVE MTG BS6-PH2	TATA spare parts
516243900174	METAL PIPE ASSY BS6-PH2	TATA spare parts
516243900197	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516243910101	METAL PIPE ASSY BS6-PH2	TATA spare parts
516243910102	METAL PIPE ASSY BS6 PH2	TATA spare parts
516243910103	METAL PIPE ASSY BS6 PH2	TATA spare parts
516243920130	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516243920144	NYLON PIPE BUNCH ASSY BS6 PH2	TATA spare parts
516246303702	RELAY ARM BS6-PH2	TATA spare parts
516246305103	PITMAN ARM BS6-PH2	TATA spare parts
516246305104	PITMAN ARM BS6-PH2	TATA spare parts

516246600103	POWER CYL ASSY WITH BALL JOINT BS6-PH2	TATA spare parts
516246700101	BRACKET ASSY RESERVOIR MTG BS6 PH2	TATA spare parts
516246703501	BOSS BS6-PH2	TATA spare parts
516246703701	BRACKET POWER CYL MTG BS6-PH2	TATA spare parts
516246703702	BRACKET RELAY ARM MTG BS6-PH2	TATA spare parts
516246800101	RETURN LINE ASSY RESERVOIR END BS6-PH2	TATA spare parts
516246800102	HIGH PRESSURE LINE ASSY P/CYL TO GB BS6-	TATA spare parts
516246800108	SUCTION LINE ASSY BS6-PH2	TATA spare parts
516246800111	HIGH PRESSURE LINE ASSY GB TO P/CYL BS6-	TATA spare parts
516246800112	SUCTION LINE ASSY BS6-PH2	TATA spare parts
516246800113	HIGH PRESSURE LINE ASSY P/CYL TO GB BS6-	TATA spare parts
516246900108	DRAG LINK ASSY FRONT BS6-PH2	TATA spare parts
516246900109	DRAG LINK ASSY FRONT BS6-PH2	TATA spare parts
516246900110	RELAY ROD ASSY BS6-PH2	TATA spare parts
516246900111	RELAY ROD ASSY BS6-PH2	TATA spare parts
516246900112	DRAG LINK ASSY REAR BS6-PH2	TATA spare parts
516246900113	DRAG LINK ASSY REAR BS6-PH2	TATA spare parts
516249200108	SPACER UREA TANK MTG BKT BS6-PH2	TATA spare parts
516249200111	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
516249200112	EXHAUST PIPE ASSY SECOND BS6 PH2	TATA spare parts
516249200114	BRACKET ASSY BS6 PH2	TATA spare parts
516249200115	BRACKET ASSY BS6 PH2	TATA spare parts
516249200117	STAY ROD ASSY BS6 PH2	TATA spare parts
516249200119	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6 P	TATA spare parts
516249200122	SUCTION LINE TANK TO SM BS6-PH2	TATA spare parts
516249203308	BRACKET EXHAUST PIPE SUPPORT BS6 PH2	TATA spare parts
516249204201	CLAMP	TATA spare parts
516254630103	WIRING HARNESS SCR UNIT BS6-PH2	TATA spare parts
516254630106	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
516254630108	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
516254630113	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
516254630114	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
516254640104	BATT CABLE +VE BCS O/P TO MAXI FUSE BOX	TATA spare parts
516254640105	CABLE BATT TAP +VE TO MANUAL CUT OFF +VE	TATA spare parts
516254640109	BATTERY CABLE +VE BATTERY TO BCS OFF I/P	TATA spare parts
516287100135	SUBFRAME ASSY WITH MOUNTINGS BS6-PH2	TATA spare parts
5162H9X0233004	FRONT FORWARD AXLE WITH BREAK BS6-PH2	TATA spare parts
5162H9X0233005	FRONT REARWARD AXLE WITH BRAKE BS6-PH2	TATA spare parts
5162H9X0233007	LIFT AXLE WITH BRAKE BS6-PH2	TATA spare parts
5162H9X0233008	LIFT AXLE WITH BRAKE BS6-PH2	TATA spare parts
516324200101	BRACKET ASSY FRAME SIDE LH BS6-PH2	TATA spare parts
516324200102	BRACKET ASSY FRAME SIDE RH BS6-PH2	TATA spare parts
516324200105	BRACKET ASSY FRAME SIDE LH BS6	TATA spare parts
516324200106	BRACKET ASSY FRAME SIDE RH BS6	TATA spare parts
516331540103	BRACKET ASSY BATTERY TRAY MTG BS6-PH2	TATA spare parts
516331540104	BRACKET ASSY BATTERY TRAY MTG BS6-PH2	TATA spare parts
516331540105	BATTERY BOX ASSY BS6-PH2	TATA spare parts

516341120102	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
516343700107	ANTI ROLL BACK ASSY BS6 PH2	TATA spare parts
516343703301	BRACKET BS6	TATA spare parts
516343703302	BRACKET BS6-PH2	TATA spare parts
516343900102	PIPE ASSY BS6	TATA spare parts
516343900120	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
516343900155	METAL PIPE ASSY BS6	TATA spare parts
516343900199	METAL PIPE ASSY BS6-PH2	TATA spare parts
516343910101	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
516346600101	STEERING GEAR BOX ASSY BS6	TATA spare parts
516346600102	HOUSING COVER ASSY BS6-PH2	TATA spare parts
516346600106	STEERING PUMP BS6-PH2	TATA spare parts
516346609901	HOUSING ASSY BS6-PH2	TATA spare parts
516346800102	RETURN LINE ASSY BS6	TATA spare parts
516347600101	SUCTION PIPE ASSY FUEL TANK TO FILTER BS	TATA spare parts
516347600102	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
516347600103	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
516347600104	RETURN FUEL PIPE ASSY BS6	TATA spare parts
516347600107	SUCTION PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
516347600108	SUCTION PIPE ASSY FUEL TANK TO FILTER BS	TATA spare parts
516347600109	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
516347600110	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
516349200103	PRESSURE LINE SM TO DM BS6-PH2	TATA spare parts
516349200104	RETURN LINE DM TO TANK	TATA spare parts
516349200106	RETURN LINE DM TO TANK BS6-PH2	TATA spare parts
516354600101	WIRING HARNESS DOSING UNIT BS6	TATA spare parts
516354600102	WIRING HARNESS TAIL BS6	TATA spare parts
516354600103	WIRING HARNESS TAIL BS6	TATA spare parts
516354600106	WIRING HARNESS DOSING UNIT BS6	TATA spare parts
516354600107	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
516354600109	BATTERY CABLE -VE BS6	TATA spare parts
516354600110	BATTERY CABLE +VE MEGA FUSE O/P TO SM BS	TATA spare parts
516354600111	BATTERY CABLE +VE MEGA FUSE O/P TO SM BS	TATA spare parts
516354600112	WIRING HARNESS FRAME BS6	TATA spare parts
516354609901	STICKER MAXI FUSE BOX BS6-PH2	TATA spare parts
516387800107	RESILIENCE MTG ASSY BS6-PH2	TATA spare parts
5163H9X0233001	FRONT FORWARD AXLE WITH BRAKE BS6-PH2	TATA spare parts
5163H9X0233002	FRONT REARWARD AXLE WITH BRAKE BS6-PH2	TATA spare parts
516424200103	BRACKET ASSY FRAME SIDE LH BS6-PH2	TATA spare parts
516424200104	BRACKET ASSY FRAME SIDE RH BS6-PH2	TATA spare parts
516424200105	BRACKET ASSY BS6-PH2	TATA spare parts
516424200108	BRACKET ASSY BS6-PH2	TATA spare parts
51643100M10003	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
516431200106	CROSS MEMBER ASSY 4TH BS6-PH2	TATA spare parts
516431700102	SUMP GUARD ASSY FRONT BS6-PH2	TATA spare parts
516441110107	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516441120107	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts

516441120111	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516441303301	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
516443700107	ANTI ROLL BACK ASSY BS6-PH2	TATA spare parts
516443700108	BRACKET ASSY BS6 PH2	TATA spare parts
516443900101	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516443900142	METAL PIPE ASSY BS6-PH2	TATA spare parts
516443900143	METAL PIPE ASSY WITH CRIMPED TEFLON HOSE	TATA spare parts
516443900159	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516443903302	BRACKET BS6-PH2	TATA spare parts
516443904201	CLAMP BS6-PH2	TATA spare parts
516443910143	METAL PIPE ASSY BS6	TATA spare parts
516443910165	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
516446300101	DRAG LINK ASSY FRONT BS6-PH2	TATA spare parts
516446300102	RELAY ROD ASSY BS6-PH2	TATA spare parts
516446600101	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
516446800101	HIGH PRESSURE LINE ASSY CYL TO STG GB BS	TATA spare parts
516446800114	RETURN LINE ASSY STG GB END BS6-PH2	TATA spare parts
516446800115	PRESSURE LINE ASSY STG GB END BS6-PH2	TATA spare parts
516446900101	RELAY ROD ASSY IDLER ARM TO RELAY ARM BS	TATA spare parts
516446900102	RELAY ROD ASSY PITMAN ARM TO IDLER ARM B	TATA spare parts
516446900103	RELAY ROD ASSY IDLER ARM TO RELAY ARM BS	TATA spare parts
516446900105	DRAG LINK ASSY BS6-PH2	TATA spare parts
516447600101	FUEL SUC PIPE ASSY FUEL TANK TO FTR BS6-	TATA spare parts
516447600102	FUEL SUC PIPE ASSY FTR TO ENG BS6-PH2	TATA spare parts
516447600103	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
516447600104	FUEL SUC PIPE ASSY FUEL TANK TO FTR BS6-	TATA spare parts
516447600105	FUEL SUC PIPE ASSY FTR TO ENG BS6-PH2	TATA spare parts
516447600106	FUEL RTN PIPE ASSY ENG TO FUEL TANK BS6-	TATA spare parts
516447600107	RETURN FUEL PIPE ASSY BS6-PH2	TATA spare parts
516447600108	RETURN FUEL PIPE ASSY BS6-PH2	TATA spare parts
516449200120	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6-P	TATA spare parts
516449200121	BRACKET ASSY EXT PIPE SUPPORT BS6-PH2	TATA spare parts
516449200122	STAY ROD ASSY BS6-PH2	TATA spare parts
516449200124	TAIL PIPE ASSY BS6 PH2	TATA spare parts
516449200128	RETURN LINE DM TO TANK BS6-PH2	TATA spare parts
516449200130	PRESSURE LINE SM TO DM BS6-PH2	TATA spare parts
516449200132	PRESSURE LINE SM TO DM	TATA spare parts
516449200158	STRUCTURE ASSY BS6-PH2	TATA spare parts
516449203304	Z-BRACKET BS6	TATA spare parts
516449207501	GROMMET BS6 PH2	TATA spare parts
516454600101	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
516454600102	WIRING HARNESS DASHBOARD BS6-PH2	TATA spare parts
516454600103	WIRING HARNESS FRAME BS6-PH2	TATA spare parts
516454600105	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
516454600106	WIRING HARNESS DOSING UNIT BS6-PH2	TATA spare parts
516454600107	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
516454600110	BATTERY CABLE +VE MEGA FUSE O/P TO SM BS	TATA spare parts

516454600111	WIRING HARNESS DOSING UNIT BS6-PH2	TATA spare parts
516454600112	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
516454600115	BATTERY CABLE -VE BS6-PH2	TATA spare parts
516454600122	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
516454600138	BATT CABLE +VE MEGA FUSE O/P TO SM BS6-P	TATA spare parts
516454600160	BRACKET MEGA FUSE MTG BS6-PH2	TATA spare parts
516454607501	GROMMET BS6-PH2	TATA spare parts
516454607502	GROMMET BS6-PH2	TATA spare parts
516454609901	STICKER CABIN FUSE & RELAY BOX BS6-PH2	TATA spare parts
516454710101	BRACKET ASSY BS6-PH2	TATA spare parts
51646010M10126	ASSY SIDE SKIN NON SLPR FLAT LH BS6-PH2	TATA spare parts
51646010M10127	ASSY SIDE SKIN NON SLPR FLAT RH BS6-PH2	TATA spare parts
51646120M10121	ASSY SIDE SILL INNER COMP LH NON SLPR BS	TATA spare parts
51646120M10122	ASSY SIDE SILL INNER COMP RH NON SLPR BS	TATA spare parts
51646160M10106	ASSY PANEL FLOOR SIDE RH RHD BS6-PH2	TATA spare parts
51646160M10232	UNDERBODY ASSY BS6-PH2	TATA spare parts
51646160M10236	CENTER FLOOR ASSY REAR BS6-PH2	TATA spare parts
51646160M10237	PANEL ASSY SIDE FLOOR LH BS6-PH2	TATA spare parts
51646260M10101	FIREWALL ASSY INNER BS6-PH2	TATA spare parts
51646270M10104	PANEL ASSY FIREWALL OUTER BS6-PH2	TATA spare parts
51646360M10125	ASSY SIDE WALL INNER NSLPR COMPLETE LH B	TATA spare parts
51646360M10126	INNER PANEL ASSY SIDE WALL RH BS6-PH2	TATA spare parts
51646370M10109	ASSY SIDE WALL OUTER LH NSLPR BS6-PH2	TATA spare parts
51646370M10110	ASSY SIDE WALL OUTER RH NSLPR BS6-PH2	TATA spare parts
51646470M10109	ASSY PANEL REARWALL WITH WINDOW NON-SLP	TATA spare parts
51646570M10125	ROOF CENTER ASSY BS6-PH2	TATA spare parts
516487800106	RESILIENCE MTG ASSY BS6-PH2	TATA spare parts
516487800107	RESILIENCE MTG ASSY BS6-PH2	TATA spare parts
5164D9Y0160001	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
5164H9X0233001	FRONT FORWARD AXLE WITH BREAK BS6-PH2	TATA spare parts
5164H9X0233002	FRONT REARWARD AXLE WITH BRAKE BS6-PH2	TATA spare parts
516524203701	ENGINE MTG ARM RH BS6-PH2	TATA spare parts
516524203702	ENGINE MTG ARM LH BS6-PH2	TATA spare parts
516530100101	BRACKET ASSY ACCELERATOR MTG BS6-PH2	TATA spare parts
51653100M10118	FRAME ASSY WITH FITEMENT BS6-PH2	TATA spare parts
51653100M10121	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
516531200101	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
516531200102	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
516531200104	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
516531200105	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
516531200106	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
516531200111	SUPPORT ASSY ENGINE CROSS MEMBER RH BS6-	TATA spare parts
516531200112	SUPPORT ASSY ENGINE CROSS MEMBER LH BS6-	TATA spare parts
516531207106	LFLASEREINFORCEMENT BS6-PH2	TATA spare parts
516531540104	BRACKET ASSY BATTERY MTG BS6-PH2	TATA spare parts
516532100102	BRACKET ASSY SPRING HANGER REAR BS6-PH2	TATA spare parts
516532103702	BRCKT SPRG HANGER FRONT BS6-PH2	TATA spare parts

516532300102	BRACKET ASSY FRONT SHOCK ABSORBER MTG BS	TATA spare parts
516532400104	BRACKET ASSY BUMP STOPPER MTG BS6-PH2	TATA spare parts
516532400105	BRACKET ASSY SPRING HANGER REAR BS6-PH2	TATA spare parts
516532400107	BUMP STOPPER ASSY BS6-PH2	TATA spare parts
516532403701	BRACKET SPRING HANGER REAR-FRONT BS6-PH2	TATA spare parts
516532404201	U-CLAMP BS6-PH2	TATA spare parts
516532407104	SHACKLE REAR SPRING BS6-PH2	TATA spare parts
516532803701	BRACKET ANTI ROLL BAR BS6-PH2	TATA spare parts
516533805101	STEERING ARM BS6-PH2	TATA spare parts
516540100113	WHEEL BALANCING ASSY BS6-PH2	TATA spare parts
516540107101	HOSE BS6-PH2	TATA spare parts
516540207101	HOSE BS6-PH2	TATA spare parts
516540207102	HOSE BS6-PH2	TATA spare parts
516541110103	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516541110105	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516541110109	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516541110110	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516541110112	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516541110120	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516541110121	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516541110122	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516541110126	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516541110127	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516541110132	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516541110134	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516541110136	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516541110141	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
516541120102	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516541120106	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516541120112	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516541120114	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516541120116	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516541120118	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516541120120	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516541300101	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
516541300102	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
516541300103	SPT ASSY CENTER BRG CROSS MEMBER BS6-PH2	TATA spare parts
516541300104	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
516541300108	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
516541300109	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
516541990102	COUPLING FLANGE ASSY BS6-PH2	TATA spare parts
516543400101	BRACKET ASSY RETARDER MTG BS6-PH2	TATA spare parts
516543400102	BRACKET ASSY RETARDER MTG BS6-PH2	TATA spare parts
516543400106	BRACKET ASSY RETARDER MTG BS6-PH2	TATA spare parts
516543400107	BRACKET ASSY RETARDER MTG BS6-PH2	TATA spare parts
516543403201	FLANGE BOLT BS6-PH2	TATA spare parts
516543700101	DUAL BRAKE VALVE BS6-PH2	TATA spare parts

516543700102	BRAKE AGGR ASSY BS6-PH2	TATA spare parts
516543700103	BRAKE AGGR ASSY BS6-PH2	TATA spare parts
516543700111	MODULATOR VALVE BS6-PH2	TATA spare parts
516543700116	BRACKET ASSY APU MTG BS6-PH2	TATA spare parts
516543900120	NYLON PIPE BUNCH ASSY CHASSIS BS6-PH2	TATA spare parts
516543900158	NYLON PIPE BUNCH ASSY CHASSIS BS6-PH2	TATA spare parts
516543900171	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516543900179	PIPE ASSY BS6-PH2	TATA spare parts
516543900184	PIPE ASSY BS6-PH2	TATA spare parts
516543900185	PIPE ASSY BS6-PH2	TATA spare parts
516543900186	PIPE ASSY BS6-PH2	TATA spare parts
516543900187	PIPE ASSY BS6-PH2	TATA spare parts
516543900190	METAL PIPE ASSY BS6-PH2	TATA spare parts
516543900201	NYLON PIPE BUNCH ASSY CHASSIS BS6-PH2	TATA spare parts
516543900237	METAL PIPE ASSY BS6-PH2	TATA spare parts
516543900238	METAL PIPE ASSY BS6-PH2	TATA spare parts
516543900239	PIPE ASSY BS6-PH2	TATA spare parts
516543900240	PIPE ASSY BS6-PH2	TATA spare parts
516543903306	BRACKET BS6-PH2	TATA spare parts
516543903315	BRACKET BS6-PH2	TATA spare parts
516543910116	NYLON PIPE BUNCH ASSY CHASSIS	TATA spare parts
516543910160	PIPE ASSY BS6-PH2	TATA spare parts
516543910161	PIPE ASSY BS6-PH2	TATA spare parts
516543910164	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516543910170	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516543910189	NYLON PIPE BUNCH ASSY CABIN BS6-PH2	TATA spare parts
516543920101	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516543920111	NYLON PIPE BUNCH ASSY CABIN BS6-PH2	TATA spare parts
516543920174	NYLON PIPE BUNCH ASSY CHASSIS BS6-PH2	TATA spare parts
516543930148	NYLON PIPE BUNCH ASSY CHASSIS BS6-PH2	TATA spare parts
516546100102	STRG COLUMN ASSY TILT & TELESCOPIC BS6-P	TATA spare parts
516546100103	BRACKET ASSY STG COLUMN MTG BS6-PH2	TATA spare parts
516546100104	STRG COLUMN ASSY TILT & TELESCOPIC BS6-P	TATA spare parts
516546305101	PITMAN ARM BS6-PH2	TATA spare parts
516546600102	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
516546600103	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
516546700103	COVER PLATE ASSY BS6-PH2	TATA spare parts
516546700105	COVER PLATE ASSY BS6-PH2	TATA spare parts
516546703302	SPACER BS6-PH2	TATA spare parts
516546800106	SUCTION LINE ASSY BS6-PH2	TATA spare parts
516546800107	RETURN LINE ASSY BS6-PH2	TATA spare parts
516546800108	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
516546800109	RETURN LINE ASSY BS6-PH2	TATA spare parts
516546800111	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
516546800114	SUCTION LINE ASSY BS6-PH2	TATA spare parts
516546800118	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
516546800119	RETURN LINE ASSY BS6-PH2	TATA spare parts



516546800120	RETURN LINE ASSY BS6-PH2	TATA spare parts
516546800121	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
516546800122	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
516546800123	RETURN LINE ASSY BS6-PH2	TATA spare parts
516546800124	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
516546800125	RETURN LINE ASSY BS6-PH2	TATA spare parts
516546800127	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
516546800128	RETURN LINE ASSY BS6-PH2	TATA spare parts
516546800129	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
516546800130	RETURN LINE ASSY BS6-PH2	TATA spare parts
516546800132	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
516546800133	SUCTION LINE ASSY BS6-PH2	TATA spare parts
516546800134	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
516546900101	DRAG LINK ASSY BS6-PH2	TATA spare parts
516546990124	HOUSING ASSY BS6-PH2	TATA spare parts
516546990131	SEAL ASSY BS6-PH2	TATA spare parts
516546990132	HOUSING ASSY BS6-PH2	TATA spare parts
516546990134	SHAFT ASSY BS6-PH2	TATA spare parts
516546990142	RACK ASSY BS6-PH2	TATA spare parts
516547600123	FUEL PIPE ASSY TANK TO FILTER BS6-PH2	TATA spare parts
516547600124	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
516547600125	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
516547600131	FUEL PIPE ASSY TANK TO FILTER BS6-PH2	TATA spare parts
516547600132	RETURN LINE ASSY BS6-PH2	TATA spare parts
516547600133	SUCTION PIPE ASSY BS6-PH2	TATA spare parts
516547600134	FUEL PIPE ASSY TANK TO FILTER BS6-PH2	TATA spare parts
516547600135	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
516547600136	RETURN LINE ASSY BS6-PH2	TATA spare parts
516547603302	BRACKET BS6-PH2	TATA spare parts
516549200101	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6-P	TATA spare parts
516549200102	EXHAUST PIPE ASSY INTERMEDIATE BS6-PH2	TATA spare parts
516549200103	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6-P	TATA spare parts
516549200104	EXHAUST PIPE ASSY INTERMEDIATE BS6-PH2	TATA spare parts
516549200105	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6-P	TATA spare parts
516549200106	CLAMP ASSY EGP MTG BS6-PH2	TATA spare parts
516549200108	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
516549200109	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
516549200111	CLAMP ASSY EGP MTG BS6-PH2	TATA spare parts
516549200112	BRACKET ASSY BS6-PH2	TATA spare parts
516549200113	BRACKET ASSY TAIL PIPE MTG BS6-PH2	TATA spare parts
516549200117	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
516549203301	BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
516549203302	BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
516554109901	COVER BATTERY BS6-PH2	TATA spare parts
516554504902	SWITCH ARB	TATA spare parts
516554600104	WIRING HARNESS PANEL BS6-PH2	TATA spare parts
516554600105	WIRING HARNESS AFTER TREATMENT BS6-PH2	TATA spare parts

516554600109	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
516554600110	W/H REVERSE PARK ASSIST BS6-PH2	TATA spare parts
516554600112	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
516554600113	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
516554600114	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
516554600115	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
516554600116	WIRING HARNESS MAXIFUSE TO ALT BS6-PH2	TATA spare parts
516554600117	CABLE ASSY STARTER MOTOR -VE BS6-PH2	TATA spare parts
516554600118	CABLE ASSY STARTER MOTOR TRUEVE BS6-PH2	TATA spare parts
516554600119	WIRING HARNESS MAIN	TATA spare parts
516554600120	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
516554600123	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
516554600124	WIRING HARNESS PANEL BS6-PH2	TATA spare parts
516554600125	WIRING HARNESS PANEL BS6-PH2	TATA spare parts
516554600126	WIRING HARNESS AFTER TREATMENT BS6-PH2	TATA spare parts
516554600128	W/H RETARDER ECU TO DASHBOARD BS6-PH2	TATA spare parts
516554600132	W/H ALTERNATOR TO STARTER BS6-PH2	TATA spare parts
516554600136	CABLE ASSY BATTERY +VE BS6	TATA spare parts
516554600143	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
516554600153	ASSY. BATT. CABLE -VE	TATA spare parts
516554610102	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
516554700102	BRACKET ASSY YAW RATE SENSOR MTG BS6-PH2	TATA spare parts
516554856301	COVER	TATA spare parts
5165D1A1860001	FES STRUCTURE BS6-PH2	TATA spare parts
5165D1A1860005	FES STRUCTURE BS6-PH2	TATA spare parts
5165D1A1860009	FES STRUCTURE BS6-PH2	TATA spare parts
5165D9Z0160024	FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
51660568000RCK	CABIN W/FITMENTS SIGNA 4830.T BS6-PH2	TATA spare parts
51660868000RCK	CABIN KIT W/FITMENT SIGNA 4830.T TC BS6-	TATA spare parts
516624100102	ENGINE MOUNT ASSY FRONT BS6-PH2	TATA spare parts
516629300102	NYLON PIPE ASSY T-CONN TO AIR TANK BS6	TATA spare parts
516629300103	NYLON PIPE ASSY BS6-PH2	TATA spare parts
516629300106	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
516629503301	BRACKET CLUTCH PIPE MTG BS6-PH2	TATA spare parts
516629503302	BRACKET CLUTCH HOSE MTG BS6-PH2	TATA spare parts
516630100101	BRACKET ASSY ACCELERATOR MTG BS6-PH2	TATA spare parts
51663100M10001	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51663100M10002	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51663100M10003	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51663100M10004	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
516631540101	BRACKET ASSY BATTERY MTG BS6-PH2	TATA spare parts
516631700101	BATTERY BOX ASSY BS6-PH2	TATA spare parts
516633900113	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516633900134	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516633900140	LINK ROD ASSY BS6-PH2	TATA spare parts
516633907701	BUMP STOPPER PLATE BS6-PH2	TATA spare parts
516641110113	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts

516641110114	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516641110115	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516641120105	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516641300107	BRACKET ASSY CENTER BRG MTG BS6 PH2	TATA spare parts
516641300110	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
516641300111	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
516641300113	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
516641990104	LONG FORK ASSY BS6-PH2	TATA spare parts
516641990111	CENTER BEARING ASSY BS6-PH2	TATA spare parts
516641990115	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
516641990116	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
516641990117	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
516641990118	LONG FORK ASSY PROPELLER SHAFT BS6-PH2	TATA spare parts
516641990119	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
516642300108	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
516642300109	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
516642990103	KIT-CAMSHAFT LH BS6-PH2	TATA spare parts
516642990104	KIT-CAMSHAFT RH BS6-PH2	TATA spare parts
516643900105	METAL PIPE ASSY BS6-PH2	TATA spare parts
516643900106	METAL PIPE ASSY BS6-PH2	TATA spare parts
516643910140	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516649200110	RETURN LINE DM TO TANK BS6-PH2	TATA spare parts
516649200112	RETURN LINE DM TO TANK BS6-PH2	TATA spare parts
516649200114	PRESSURE LINE SM TO DM BS6-PH2	TATA spare parts
516649200115	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
516649200116	EXHAUST PIPE ASSY SECOND BS6-PH2	TATA spare parts
516649200117	EXHAUST TAIL PIPE ASSY BS6 PH2	TATA spare parts
516649200118	BRACKET ASSY PIPE MTG BS6	TATA spare parts
516649200119	BRACKET ASSY EXHAUST PIPE MTG BS6 PH2	TATA spare parts
516649200120	BRACKET ASSY EGP MTG BS6	TATA spare parts
516649200121	CLAMP ASSY EGP MTG - BS6	TATA spare parts
516649200123	BRACKET ASSY BS6	TATA spare parts
516649200135	BRACKET ASSY EGP MTG BS6 PH2	TATA spare parts
516649200137	CLAMP ASSY EGP MTG BS6-PH2	TATA spare parts
516649200149	BRACKET ASSY. UREA TANK BS6	TATA spare parts
516649203304	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
516649203306	BRACKET TAIL PIPE MTG BS6	TATA spare parts
516649203323	L-BRACKET EXHAUST MTG BS6	TATA spare parts
516649203324	L-BRACKET EXHAUST PIPE MTG BS6 PH2	TATA spare parts
516649203342	BRACKET TAIL PIPE	TATA spare parts
516649203343	L BRACKET EXHAUST PIPE BS6	TATA spare parts
51665168000RCK	CABIN KIT W/FITMENT LPT 4830 TC BS6-PH2	TATA spare parts
516654610102	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
516654630103	WIRING HARNESS SCR UNIT BS6	TATA spare parts
516654630111	WIRING HARNESS MAXI FUSE BS6 PH2	TATA spare parts
516654640101	BRACKET ENGINE MTG BS6 PH2	TATA spare parts
5166F9Y0131006	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts

5166H9X0233015	LIFT AXLE WITH BRAKE (THSL MAKE) BS6-PH2	TATA spare parts
51670411030	BOX STRAPPING STRIP 0.38X12.7-IS5872	TATA spare parts
516741110101	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
516741110103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
516741120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
516741300101	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
516743900101	PIPE BUNCH ASSY BS6	TATA spare parts
516746600109	STEERING GEAR BOX ASSY BS6	TATA spare parts
516754610104	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
516754610106	BRACKET ASSY FUSE BOX MTG BS6-PH2	TATA spare parts
516754630108	WIRING HARNESS SCR UNIT BS6 PH2	TATA spare parts
51683100M10106	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51683100M10109	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51683100M10116	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51683100M10117	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51683100M10118	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
516831107105	REINFORCEMENT RH BS6-PH2	TATA spare parts
516831107106	REINFORCEMENT LH BS6-PH2	TATA spare parts
516831200101	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
516831200102	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
516831540101	BATTERY BOX ASSY BS6-PH2	TATA spare parts
516833900108	KIT-NYLON PIPES BS6-PH2	TATA spare parts
516833900114	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516833900118	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516833900134	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516833900147	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516833900158	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
516841110103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
516841110108	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516841110109	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516841110110	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516841110111	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
516841110113	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
516841120104	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
516841120107	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516841120108	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516841120109	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
516841300103	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
516841300104	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
516841300105	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
516841990109	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
516841990110	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
516841990111	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
516841990112	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
516841990116	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
516843900127	MT PIPE ASSY WITH CRIMPED HOSE BS6-PH2	TATA spare parts
516843900150	BRACKET ASSY BS6-PH2	TATA spare parts

516843900181	BUNCH PIPE ASSY BS6	TATA spare parts
516843900201	BUNCH PIPE ASSY BS6-PH2	TATA spare parts
516843900227	BUNCH PIPE ASSY BS6-PH2	TATA spare parts
516843900249	BUNCH PIPE ASSY BS6-PH2	TATA spare parts
516846800104	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
516846800106	RETURN LINE ASSY GEAR BOX TO INT JOINT B	TATA spare parts
516846800107	RETURN LINE ASSY GEAR BOX TO INT JOINT B	TATA spare parts
516846800109	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
516847600105	SUCTION PIPE ASSY FILTER TO ENG BS6-PH2	TATA spare parts
516847600106	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
516847600107	RETURN PIPE ASSY ENGINE TO CONN BS6-PH2	TATA spare parts
516849200106	RETURN LINE DM TO TANK	TATA spare parts
516849200109	EXT PIPE ASSY WITH FLEX BELLOW BS6-PH2	TATA spare parts
516849200110	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
516849203314	L-BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
516849207501	GROMMET BS6 PH2	TATA spare parts
516854620103	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
516854630139	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
516854630141	WIRING HARNESS TAIL BS6	TATA spare parts
516854630142	WIRING HARNESS ABS FRAME BS6	TATA spare parts
516854630144	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
516854630145	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
516854630146	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
516854630147	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
516854630149	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
516854630151	WIRING HARNESS ABS BS6-PH2	TATA spare parts
516854630152	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
516854640105	CABLE ASSY BATTERY +VE BS6 PH2	TATA spare parts
516854640114	BATTERY CABLE -VE BS6-PH2	TATA spare parts
5168H9X0233001	FRONT LIFT AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
5168H9X0233003	FRONT LIFT AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
516931200104	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
516932400101	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
516932400102	LEAF SPRING ASSY REAR BS6-PH2	TATA spare parts
516932403201	CENTER BOLT BS6-PH2	TATA spare parts
516932404202	SPRING CLIP BS6-PH2	TATA spare parts
516932404203	SPRING CLIP REAR SPRING BS6-PH2	TATA spare parts
516932407102	2ND LEAF BS6-PH2	TATA spare parts
516932407103	3RD LEAF BS6-PH2	TATA spare parts
516932407104	4TH LEAF BS6-PH2	TATA spare parts
516932407105	5TH LEAF BS6-PH2	TATA spare parts
516932407107	7TH LEAF BS6-PH2	TATA spare parts
516932407108	8TH LEAF BS6-PH2	TATA spare parts
516932407109	9TH LEAF BS6-PH2	TATA spare parts
516932407110	10TH LEAF BS6-PH2	TATA spare parts
516932407111	6TH LEAF BS6-PH2	TATA spare parts
516941110103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts

516941120104	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
516941120106	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
516941300101	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
516946800101	SUCTION LINE ASSY BS6-PH2	TATA spare parts
516946800102	PR LINE ASSY STG GEAR BOX END BS6-PH2	TATA spare parts
516946800103	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
516946800105	PRESSURE LINE ASSY STG GR BOX END BS6-PH	TATA spare parts
516946800106	RETURN LINE ASSY GEAR BOX TO INT JOINT B	TATA spare parts
516946800107	RETURN LINE ASSY GEAR BOX TO INT JOINT B	TATA spare parts
516946800108	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
516946800109	PRESSURE LINE ASSY STG GEAR BOX END BS6	TATA spare parts
516947500103	BRACKET ASSY FUEL TANK MTG BS6 PH2	TATA spare parts
516947600106	SUCTION PIPE ASSY FUEL TANK TO FILTER BS	TATA spare parts
516947600107	SUCTION PIPE ASSY FILTER TO ENG BS6-PH2	TATA spare parts
516947600108	RETURN PIPE ASSY BS6-PH2	TATA spare parts
516947600109	FUEL RTN PIPE ASSY ENG TO T-CONN BS6-PH2	TATA spare parts
516954506302	SWITCH DUMMY KNOB BS6 PH2	TATA spare parts
516954610105	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
516954620106	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
516954630117	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
516954630118	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
516954630124	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
516954630125	WIRING HARNESS TAIL BS6	TATA spare parts
516954630126	WIRING HARNESS ABS FRAME BS6	TATA spare parts
516954630127	WIRING HARNESS ABS FRAME BS6	TATA spare parts
516954630128	WIRING HARNESS TAIL BS6	TATA spare parts
516954630129	WIRING HARNESS TAIL BS6	TATA spare parts
516954630130	WIRING HARNESS ABS FRAME BS6	TATA spare parts
516954640106	BATTERY CABLE -VE BS6-PH2	TATA spare parts
5169H9X0233006	FRONT AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
517020960001	LOCK	TATA spare parts
517020970001	LOCK	TATA spare parts
517020980001	SKIRT PANEL COMPLETE-RH-1	TATA spare parts
517020990001	SKIRT PANEL COMPLETE-RH-2	TATA spare parts
517021000001	SKIRT PANEL COMPLETE-RH-3	TATA spare parts
517021010001	SKIRT PANEL COMPLETE-RH-4	TATA spare parts
517021020001	SKIRT PANEL COMPLETE-RH-5	TATA spare parts
517021030001	SKIRT PANEL COMPLETE-RH-6	TATA spare parts
517021040001	SKIRT PANEL COMPLETE-RH-7	TATA spare parts
517021050001	SKIRT PANEL COMPLETE-LH-1	TATA spare parts
517021060001	SKIRT PANEL COMPLETE-LH-2	TATA spare parts
517021070001	SKIRT PANEL COMPLETE-LH-3	TATA spare parts
517021080001	SKIRT PANEL COMPLETE-LH-4	TATA spare parts
517021090001	SKIRT PANEL COMPLETE-LH-5	TATA spare parts
517021100001	SKIRT PANEL COMPLETE-LH-6	TATA spare parts
517021130001	BATTERY BOX FLAP ASSY	TATA spare parts
517021140001	AIR TANK FLAP ASSY	TATA spare parts

517021150001	DIESEL TANK FLAP ASSEMBLY	TATA spare parts
517021160001	AUX DRIVE FLAP ASSY	TATA spare parts
517021170001	RH SIDE FLAP TOP (REAR ENGINE) ASSY	TATA spare parts
517021180001	RH SIDE FLAP BOTTOM (REAR ENGINE) ASSY	TATA spare parts
517021190001	LH SIDE FLAP TOP (REAR ENGINE) ASSY	TATA spare parts
517021200001	LH SIDE FLAP BOTTOM (REAR ENGINE) ASSY	TATA spare parts
517021210001	OUTER PANEL LH( COOLANT TANK REAR)	TATA spare parts
517021250001	PANEL	TATA spare parts
517021260001	BATTERY CUTOFF SWITCH FLAP ASSY	TATA spare parts
517030700001	WHEEL ARCH	TATA spare parts
517040410001	HANDLE FOR FLAP	TATA spare parts
517041300101	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
517041990103	LONG FORK ASSY BS6-PH2	TATA spare parts
517049200101	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6-P	TATA spare parts
517049200102	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
517049200103	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
517049200104	EXHAUST TAIL PIPE ASSY BS6-PH2	TATA spare parts
517049200106	PROTECTIVE SHIELD BS6-PH2	TATA spare parts
517049200107	BRACKET ASSY EXHAUST BS6-PH2	TATA spare parts
517049200109	PROTECTIVE COVER SM BS6-PH2	TATA spare parts
517049200110	SUCTION PIPE BS6-PH2	TATA spare parts
517049200111	SUCTION PIPE BS6-PH2	TATA spare parts
517049200114	PRESSURE LINE SM TO DM BS6-PH2	TATA spare parts
517049200118	PIPE ASSY UREA RETURN BS6-PH2	TATA spare parts
517049203304	BRACKET DOSER UNIT MTG BS6-PH2	TATA spare parts
517049203306	L-BRACKET BS6-PH2	TATA spare parts
517049203307	L-BRACKET EXHAUST MTG BS6-PH2	TATA spare parts
517054610106	WIRING HARNESS MAIN BS6	TATA spare parts
517054620102	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
517054630121	WIRING HARNESS SCR UNIT BS6-PH2	TATA spare parts
517054640101	BATT.CABLE +VE MAXI FUSE O/P -SM BS6-PH2	TATA spare parts
51712580368	TUBE-5 MTRS	TATA spare parts
517131408233	END CROSS MEMBER BS6-PH2	TATA spare parts
517132103201	CENTER BOLT BS6-PH2	TATA spare parts
517132108601	SPACER BS6-PH2	TATA spare parts
517132403701	BRACKET REAR SPRING HANGER FRONT	TATA spare parts
517143700101	AIR COMPRESSOR EV	TATA spare parts
517146708001	HEX SCREW	TATA spare parts
517180409901	TRACTION MOTOR	TATA spare parts
517180719901	VEHICLE MANAGEMENT UNIT EV	TATA spare parts
517180719902	VEHICLE MANAGEMENT UNIT EV	TATA spare parts
517241300103	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
517242993301	KIT-BRACKET ASSY LH BS6	TATA spare parts
517242993302	KIT-BRACKET ASSY RH BS6	TATA spare parts
517242993303	KIT-BRACKET ASSY LH BS6-PH2	TATA spare parts
517242993304	KIT-BRACKET ASSY RH BS6-PH2	TATA spare parts
517242993307	KIT-BRACKET ASSY LH BS6-PH2	TATA spare parts

517242993308	KIT-BRACKET ASSY RH BS6-PH2	TATA spare parts
517242993701	KIT-BRACKET ASSY LH BS6-PH2	TATA spare parts
517242993702	KIT-BRACKET ASSY RH BS6-PH2	TATA spare parts
517247100102	FUEL TANK ASSY W/O TANK UNIT	TATA spare parts
517247100105	FUEL TANK ASSY W/O TANK UNIT	TATA spare parts
517247600102	FUEL SUCTION PIPE ASSY TANK TO W/SEP BS6	TATA spare parts
517247600104	FUEL RTN PIPE ASSY ENG TO T-CONN BS6-PH2	TATA spare parts
517247600105	FUEL RTN PIPE ASSY ENG TO CONN BS6-PH2	TATA spare parts
517247608201	BRACKET FUEL PIPE MTG BS6-PH2	TATA spare parts
517254304901	FUEL LEVEL SENSOR BS6-PH2	TATA spare parts
517254610103	WIRING HARNESS FRONT CHASSIS BS6-PH2	TATA spare parts
517254630106	WIRING HARNESS REAR CHASSIS	TATA spare parts
51740138000RCK	CABIN KIT FOR TATA SIGNA 5530.S BS6-PH2	TATA spare parts
51740338000RCK	CABIN W/FITMENTS TATA SIGNA 5530.S BS6-P	TATA spare parts
51741238000RCK	CABIN KIT W/FITMENT SIGNA 5530.S BS6-PH2	TATA spare parts
51741438000RCK	CABIN KIT W/FITMENT SIGNA 5530.S BS6-PH2	TATA spare parts
517416172001	ECU BS6-PH2	TATA spare parts
517420110001	FUEL FLAP ASSEMBLY	TATA spare parts
517420120001	FUEL FLAP ASSEMBLY	TATA spare parts
517429300101	NYLON PIPE ASSY BS6 PH2	TATA spare parts
51743100M10107	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51743100M10108	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51743100M10109	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51743100M10110	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
517431200105	CROSS MEMBER ASSY TUBULAR BS6-PH2	TATA spare parts
517431200107	L-PLATE RH ASSY BS6-PH2	TATA spare parts
517431200108	L-PLATE LH ASSY BS6-PH2	TATA spare parts
517431207101	SPACER PLATE BS6-PH2	TATA spare parts
517431700107	BATTERY CARRIER & AIR TANK MTG ASSY BS6-	TATA spare parts
517443700150	PRESSURE TEST-CONNECTOR BS6	TATA spare parts
517443900104	PIPE BUNCH ASSY BS6	TATA spare parts
517443900136	PIPE ASSY BS6-PH2	TATA spare parts
517443900140	METAL PIPE ASSY BS6-PH2	TATA spare parts
517443900141	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
517443900142	PIPE ASSY BS6-PH2	TATA spare parts
517443900143	PIPE ASSY BS6-PH2	TATA spare parts
517443900144	PIPE ASSY BS6-PH2	TATA spare parts
517443900145	PIPE ASSY BS6-PH2	TATA spare parts
517443900146	PIPE ASSY BS6-PH2	TATA spare parts
517443900147	PIPE ASSY BS6-PH2	TATA spare parts
517443900150	PIPE ASSY BS6-PH2	TATA spare parts
517443900151	PIPE ASSY BS6-PH2	TATA spare parts
517443900152	PIPE ASSY BS6-PH2	TATA spare parts
517443900163	PIPE ASSY BS6-PH2	TATA spare parts
517443900164	PIPE ASSY BS6-PH2	TATA spare parts
517443900166	PIPE ASSY BS6-PH2	TATA spare parts
517443900172	BUNCH ASSY PIPE BS6 PH2	TATA spare parts



517443900173	PIPE ASSY BS6-PH2	TATA spare parts
517443900174	PIPE ASSY BS6-PH2	TATA spare parts
517443900175	PIPE ASSY BS6-PH2	TATA spare parts
517443900176	PIPE ASSY BS6-PH2	TATA spare parts
517443900177	PIPE ASSY BS6-PH2	TATA spare parts
517443900178	PIPE ASSY BS6-PH2	TATA spare parts
517443900179	PIPE ASSY BS6-PH2	TATA spare parts
517443900180	PIPE ASSY BS6-PH2	TATA spare parts
517443900181	PIPE ASSY BS6-PH2	TATA spare parts
517443900182	PIPE ASSY BS6-PH2	TATA spare parts
517443900183	PIPE ASSY BS6-PH2	TATA spare parts
517443900184	PIPE ASSY BS6-PH2	TATA spare parts
517443900185	PIPE ASSY BS6-PH2	TATA spare parts
517443900186	PIPE ASSY BS6-PH2	TATA spare parts
517443900191	METAL PIPE ASSY BS6-PH2	TATA spare parts
517443900196	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
517443903302	L-BRACKET BS6-PH2	TATA spare parts
517443910149	METAL PIPE ASSY WITH CRIMPED HOSE BS6-PH	TATA spare parts
517447600101	FUEL SUCTION PIPE ASSY FTR TO ENGINE BS6	TATA spare parts
517447600102	FUEL SUC PIPE ASSY TANK TO W/SEP BS6-PH2	TATA spare parts
517447600103	RETURN PIPE ASSY ENGINE TO CONN BS6 PH2	TATA spare parts
517449200101	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
517449200102	BRACKET ASSY BS6	TATA spare parts
517449200103	CLAMP ASSY EGP MTG BS6 PH2	TATA spare parts
517449200104	CLAMP ASSY EGP MTG BS6 PH2	TATA spare parts
517449200108	BRACKET ASSY EGP MTG REAR BS6 PH2	TATA spare parts
517449200110	HEAT SHIELD ASSY BS6-PH2	TATA spare parts
517449200111	EXHAUST TAIL PIPE ASSY BS6-PH2	TATA spare parts
517449200114	BRACKET ASSY EGP MTG BS6	TATA spare parts
517449200115	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6 P	TATA spare parts
517449200116	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
517449200118	RETURN LINE DM TO TANK BS6-PH2	TATA spare parts
517449200122	BRACKET ASSY EXHAUST PIPE BS6	TATA spare parts
517449203303	L-BRACKET EXHAUST MTG BS6	TATA spare parts
517449203307	BRACKET TAIL PIPE BS6-PH2	TATA spare parts
517449203310	BRACKET TAIL PIPE MTG BS6-PH2	TATA spare parts
517449203318	L-BRACKET EXHAUST PIPE MTG BS6 PH2	TATA spare parts
517449203319	BRACKET BS6-PH2	TATA spare parts
517449203320	L-BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
517449204204	CLAMP BS6-PH2	TATA spare parts
517449204205	CLAMP BS6-PH2	TATA spare parts
517454610103	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
517454630101	WIRING HARNESS TAIL BS6 PH2	TATA spare parts
517454630102	WIRING HARNESS SCR UNIT BS6 PH2	TATA spare parts
517454630103	WIRING HARNESS EMS PIGTAIL BS6	TATA spare parts
517454630105	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
517454640101	BRACKET BS6-PH2	TATA spare parts

517454640102	ASSY. BATTERY CABLE +VE BS6 PH2	TATA spare parts
517454640104	BATT. CABLE +VE MEGA FUSE O/P TO ST. M	TATA spare parts
517454640106	BATTERY CABLE +VE BCS TO MEGA FUSE BS6-P	TATA spare parts
51746160M10103	FLOOR PANEL ASSY CENTER BS6-PH2	TATA spare parts
51746160M10124	FLOOR PANEL ASSY LH BS6-PH2	TATA spare parts
51746160M10125	FLOOR PANEL ASSY RH BS6-PH2	TATA spare parts
51746160M10130	REINFORCEMENT ASSY FLOOR WHEELARCH LH BS	TATA spare parts
51746160M10131	REINFORCEMENT ASSY FLOOR WHEELARCH RH BS	TATA spare parts
51746160M10148	MUDGUARD ASSY REAR-LH BS6-PH2	TATA spare parts
51746160M10149	MUDGUARD ASSY REAR-RH BS6-PH2	TATA spare parts
5174D1A0161001	UNDER BODY SUB STRUCTURE BS6-PH2	TATA spare parts
5174H9X0233008	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
5174H9X0233009	FRONT AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
5174H9X0233010	FRONT AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
5174H9X0233015	FRONT AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
51751133000RCK	CABIN W/FITMENT SIGNA 4625.S BS6-PH2	TATA spare parts
51751233000RCK	CABIN KIT SIGNA 4625.S CX TC BS6-PH2	TATA spare parts
51753100M10105	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51753100M10125	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
517531200101	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
517531200103	SUPPORT BRACKET ASSY LH BS6-PH2	TATA spare parts
517531200106	CROSS MEMBER ASSY BS6	TATA spare parts
517531307103	SPACER PLATE BS6 PH2	TATA spare parts
517532100101	PARABOLIC LEAF SPRING ASSY FRONT BS6-PH2	TATA spare parts
517532100102	PARABOLIC LEAF SPRING ASSY FRONT BS6-PH2	TATA spare parts
517532103201	CENTER BOLT BS6-PH2	TATA spare parts
517532107101	CASTER PLATE BS6-PH2	TATA spare parts
517532107102	CASTER PLATE BS6-PH2	TATA spare parts
517534200105	FIFTH WHEEL ASSY WITH STRUCTURE BS6-PH2	TATA spare parts
517543900123	PIPE ASSY BS6-PH2	TATA spare parts
517543900128	PIPE ASSY BS6-PH2	TATA spare parts
517543900131	PIPE ASSY BS6-PH2	TATA spare parts
517543900132	PIPE ASSY BS6-PH2	TATA spare parts
517543900133	PIPE ASSY BS6-PH2	TATA spare parts
517543900135	PIPE ASSY BS6-PH2	TATA spare parts
517543900136	PIPE ASSY BS6-PH2	TATA spare parts
517543900139	PIPE ASSY BS6-PH2	TATA spare parts
517543900158	PIPE BUNCH ASSY BS6	TATA spare parts
517543900162	PIPE ASSY BS6-PH2	TATA spare parts
517543900163	PIPE ASSY BS6-PH2	TATA spare parts
517543900164	PIPE ASSY BS6-PH2	TATA spare parts
517543900171	METAL PIPE ASSY WITH CRIMPED HOSE BS6 PH	TATA spare parts
517543900172	METAL PIPE ASSY WITH CRIMPED HOSE BS6 PH	TATA spare parts
517543900174	BUNCH ASSY PIPE BS6 PH2	TATA spare parts
517543910132	BUNCH ASSY PIPE BS6	TATA spare parts
517554600102	WIRING HARNESS MAIN BS6	TATA spare parts
517554630102	WIRING HARNESS TAIL BS6 PH2	TATA spare parts

51760333000RCK	CABIN KIT W/FITMENT SIGNA 4625.S BS6-PH2	TATA spare parts
517643900101	CONNECTOR PRESSURE TEST BS6	TATA spare parts
517647600101	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
517647600102	FUEL SUCTION PIPE ASSY FTR TO ENGINE BS6	TATA spare parts
51770168000RCK	COWL KIT W/FITMENT LPT 1923 BS6-PH2	TATA spare parts
51773100M10105	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51773100M10115	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51773100M10116	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
517731200102	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
517731200103	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
517731207101	L-REINFORCEMENT TOP-RH BS6-PH2	TATA spare parts
517731207102	L-REINFORCEMENT TOP-LH BS6-PH2	TATA spare parts
517731307101	REINFORCEMENT BUMPER CROSS MEMBER RH BS6-PH2	TATA spare parts
517731307102	REINFORCEMENT BUMPER CROSS MEMBER LH BS6-PH2	TATA spare parts
517731307111	SUPPORT PLATE	TATA spare parts
517732100102	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
517732107102	2ND LEAF BS6-PH2	TATA spare parts
517733805102	STEERING ARM BS6-PH2	TATA spare parts
517741100101	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
517741110103	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
517741110104	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
517741120103	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
517741120104	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
517741120109	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
517741300101	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
517741990104	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
517741990105	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
517742300111	DRUM BRAKE ASSY WITH DC REAR-LH BS6 PH2	TATA spare parts
517742300112	DRUM BRAKE ASSY WITH DC REAR-RH BS6 PH2	TATA spare parts
517742300114	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
517742300117	DRUM BRAKE ASSY WITH DC REAR-RH BS6-PH2	TATA spare parts
517742300121	DRUM BRAKE ASSY WITH DC REAR-LH BS6-PH2	TATA spare parts
517742300124	DRUM BRAKE ASSY WITH DC REAR-RH BS6-PH2	TATA spare parts
517742300128	DRUM BRAKE ASSY WITH DC REAR-LH BS6 PH2	TATA spare parts
517742300129	DRUM BRAKE ASSY WITH DC REAR-LH BS6-PH2	TATA spare parts
517742300131	DRUM BRAKE ASSY WITH DC REAR-RH BS6 PH2	TATA spare parts
517742300132	DRUM BRAKE ASSY WITH DC REAR-RH BS6-PH2	TATA spare parts
517742300135	DRUM BRAKE ASSY WITH DC REAR-LH BS6-PH2	TATA spare parts
517742300136	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
517742300138	DRUM BRAKE ASSY WITH DC REAR-RH BS6-PH2	TATA spare parts
517742300139	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
517742300146	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
517742300147	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
517742300148	DRUM BRAKE ASSY WITH DC REAR-LH BS6 PH2	TATA spare parts
517742300149	DRUM BRAKE ASSY WITH DC REAR-RH BS6 PH2	TATA spare parts
517742300150	DRUM BRAKE ASSY WITH DC REAR-LH (MASU NA	TATA spare parts
517742300151	DRUM BRAKE ASSY WITH DC REAR-RH (MASU NA	TATA spare parts

517742990103	KIT-CAMSHAFT LH BS6-PH2	TATA spare parts
517742990104	KIT-CAMSHAFT RH BS6-PH2	TATA spare parts
517742990105	KIT-BUSH LH BS6-PH2	TATA spare parts
517742990106	KIT-BUSH RH BS6-PH2	TATA spare parts
517742990107	KIT-BUSH BS6-PH2	TATA spare parts
517743200101	AIR TANK ASSY WITH BKTS & STRAP BS6-PH2	TATA spare parts
517743900101	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
517743900107	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
517746700101	BRACKET ASSY RESERVOIR MTG BS6-PH2	TATA spare parts
517746800103	SUCTION LINE ASSY BS6-PH2	TATA spare parts
517746800104	RETURN LINE ASSY RESERVOIR END BS6-PH2	TATA spare parts
517746800105	RETURN LINE ASSY GB TO INT JOINT BS6-PH2	TATA spare parts
517746800106	RETURN LINE ASSY BS6-PH2	TATA spare parts
517746900101	DRAG LINK ASSY BS6-PH2	TATA spare parts
517747600101	SUCTION PIPE ASSY FUEL TANK TO FILTER BS	TATA spare parts
517747600102	SUCTION PIPE ASSY FILTER TO ENG BS6-PH2	TATA spare parts
517747600103	RTN PIPE ASSY ENG TO FUEL TANK BS6-PH2	TATA spare parts
517747608201	BRACKET FUEL LINE SUPPORT BS6-PH2	TATA spare parts
517754501601	CARRIER PLATE SWITCH BS6-PH2	TATA spare parts
517754630101	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
517754630102	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
517754630103	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
517754630104	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
517754630105	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
517754630106	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
51776100M10120	SUBSTRUCTURE ASSY SLPR BS6-PH2	TATA spare parts
51776160M10101	FLOOR PANEL ASSY LH SLPR BS6-PH2	TATA spare parts
51776160M10111	FLOOR PANEL ASSY RH SLPR BS6-PH2	TATA spare parts
51776210M10145	DOOR POST ASSY LH BS6-PH2	TATA spare parts
51776210M10146	DOOR POST ASSY RH BS6-PH2	TATA spare parts
51776210M10154	FRAME ASSY FRONT-LH BS6-PH2	TATA spare parts
51776210M10155	FRAME ASSY FRONT-RH BS6-PH2	TATA spare parts
51776220M10124	REINFORCEMENT ASSY WAIST RAIL BS6-PH2	TATA spare parts
51776250M10148	OUTER PANEL ASSY WINDSHIELD BOTTOM BS6-P	TATA spare parts
51776250M10165	PANEL ASSY FACE SIDE BOTTOM-LH BS6-PH2	TATA spare parts
51776250M10166	PANEL ASSY FACE SIDE BOTTOM-RH BS6-PH2	TATA spare parts
51776260M10102	TOE PANEL ASSY LH BS6-PH2	TATA spare parts
51776260M10133	COVER PANEL ASSY BS6-PH2	TATA spare parts
51776260M10182	TOE PANEL ASSY RH BS6-PH2	TATA spare parts
51776260M10196	PANEL ASSY WINDSHIELD INNER-BOTTOM BS6-P	TATA spare parts
51776660M10120	ASSY STEP WELL COMPLETE LH BS6-PH2	TATA spare parts
51776660M10121	ASSY STEP WELL COMPLETE-RH BS6-PH2	TATA spare parts
5177D9Y0160001	PAINTED BODY SHELL-COWL BS6-PH2	TATA spare parts
5177H9X0233007	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
5177H9X0233010	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
51780148000RCK	COWL W/FITMENT LPT 1921 5L BS6-PH2	TATA spare parts
51783100M10102	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts

51783100M10143	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51783100M10146	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51783100M10147	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51783100M10148	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51783100M10150	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
517831200101	CROSS MEMBER ASSY BUMPER BS6-PH2	TATA spare parts
517831307103	SUPPORT PLATE BS6-PH2	TATA spare parts
517831307105	SPACER PLATE BS6-PH2	TATA spare parts
517831307106	SPACER PLATE BS6-PH2	TATA spare parts
517841110104	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
517841110105	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
517841110106	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
517841110108	SHORT FORK TUBE BS6-PH2	TATA spare parts
517841110110	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
517841110113	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
517841120103	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
517841120105	SHORT FORK TUBE BS6-PH2	TATA spare parts
517841120106	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
517841120108	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
517841120113	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
517841300101	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
517841300103	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
517841300104	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
517843900102	METAL PIPE ASSY BS6-PH2	TATA spare parts
517843900121	PIPE BUNCH ASSY	TATA spare parts
517849200102	SPACER UREA TANK MTG BKT BS6-PH2	TATA spare parts
517849200117	PRESSURE LINE SM TO DM BS6-PH2	TATA spare parts
517849200119	SUCTION PIPE BS6-PH2	TATA spare parts
517849203305	BRACKET CLAMP MTG BS6-PH2	TATA spare parts
517854630103	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
517854630104	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
517854630106	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
517854630107	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
517854630112	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
517854630115	WIRING HARNESS ABS FRAME	TATA spare parts
517854630116	WIRING HARNESS TAIL	TATA spare parts
517854640101	BATTERY CABLE -VE BS6-PH2	TATA spare parts
5178D9Z0160001	FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
5178H9X0233005	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
517931200102	CROSS MEMBER ASSY BS6	TATA spare parts
517941110103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
517941110104	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
517941120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
517941300101	BRACKET ASSY CENTER BRG MTG BS6	TATA spare parts
517943900180	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
517954630105	WH ABS BS6	TATA spare parts
51813100M10109	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts

51813100M10110	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51813100M10118	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51813100M10119	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51813100M10121	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51813100M10122	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51813100M10125	FRAME ASSY WITH FITMENTBS6-PH2	TATA spare parts
518131200104	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
518131200106	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
518131700104	BRACKET ASSY RAIDATOR MTG LH BS6-PH2	TATA spare parts
518131700105	BRACKET ASSY RAIDATOR MTG RH BS6-PH2	TATA spare parts
518131700116	BRACKET ASSY RAIDATOR MTG RH BS6-PH2	TATA spare parts
518131700117	BRACKET ASSY RAIDATOR MTG LH BS6-PH2	TATA spare parts
518131700121	BRACKET ASSY RAIDATOR MTG LH BS6-PH2	TATA spare parts
518131700122	BRACKET ASSY RAIDATOR MTG RH BS6-PH2	TATA spare parts
518141110102	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
518141110116	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
518141110117	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
518141120107	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
518141120115	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
518141120117	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
518141300101	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
518141300102	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
518141300107	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
518141990106	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
518141990107	UNIVERSAL JOINT ASSY BS6-PH2	TATA spare parts
518141990108	FLANGE YOKE BS6-PH2	TATA spare parts
518141990127	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
518141990128	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
518141990132	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
518141990133	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
518141990134	SHORT FORK TUBE & REAR HOUSING ASSY BS6	TATA spare parts
518143700105	BRACKET BS6-PH2	TATA spare parts
518143900148	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
518143900168	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
518143900192	PIPE BUNCH ASSY BS6-PH2	TATA spare parts
518146305104	PITMAN ARM BS6	TATA spare parts
518146305105	PITMAN ARM BS6-PH2	TATA spare parts
518146800102	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
518146800103	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
518146800105	PRESSURE LINE ASSY STG GB END BS6-PH2	TATA spare parts
518146800106	RETURN LINE ASSY GB TO INT JOINT BS6-PH2	TATA spare parts
518146800107	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
518146800109	PRESSURE LINE ASSY STG GB END BS6-PH2	TATA spare parts
518146800110	RETURN LINE ASSY GB TO INT JOINT BS6-PH2	TATA spare parts
518146803301	BRACKET PIPE CLAMP BS6-PH2	TATA spare parts
518146803302	BRACKET PIPE CLAMP BS6-PH2	TATA spare parts
518146900102	DRAG LINK ASSY BS6-PH2	TATA spare parts

518147600101	FUEL PIPE ASSY BS6-PH2	TATA spare parts
518147600102	FUEL INTER CONNECTION PIPE BS6-PH2	TATA spare parts
518149200103	CLAMP ASSY EGP MTG BS6-PH2	TATA spare parts
518149200112	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
518149200113	BRACKET ASSY UREA TANK MTG BS6-PH2	TATA spare parts
518149200115	SUPPORT BRKT SUPPLY UNIT MTG LH BS6-PH2	TATA spare parts
518149200118	BRACKET ASSY EGP MTG REAR BS6-PH2	TATA spare parts
518149200121	EXH PIPE ASSY WITH FLEX BELLOW BS6-PH2	TATA spare parts
518149200123	BRACKET ASSY EXHAUST PIPE MTG BS6	TATA spare parts
518149200125	BRACKET ASSY BS6-PH2	TATA spare parts
518149200136	HEAT SHIELD ASSY	TATA spare parts
518149203314	L-BRACKET EXHAUST MTG BS6-PH2	TATA spare parts
518149203317	L-BRACKET EXHAUST MTG BS6	TATA spare parts
518149203323	BRACKET TAIL PIPE BS6	TATA spare parts
518149204201	CLAMP EGP MTG BS6-PH2	TATA spare parts
518149207501	GROMMET BS6-PH2	TATA spare parts
51815356000RCK	CABIN W/FITMENTS SIGNA 2823.T BS6-PH2	TATA spare parts
518154620104	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
518154620105	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
518154630146	WIRING HARNESS SCR UNIT BS6-PH2	TATA spare parts
518154630148	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
518154630150	BRACKET MAXI FUSE BOX MTG BS6-PH2	TATA spare parts
518154630157	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
518154630158	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
518154630159	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
518154630160	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
518154630161	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
518154630162	W/H TAIL & MAXI FUSE INFO-FIT DRG BS6-PH	TATA spare parts
518154640101	BATTERY CABLE +VE BCS O/P TO SM BS6-PH2	TATA spare parts
518154640104	BATT.CABLE +VE BCS TO MEGA FUSE BS6-PH2	TATA spare parts
518154640105	BATT.CABLE +VE BATT.-BCS OFF I/P BS6-PH2	TATA spare parts
518154640106	BATTERY CABLE -VE BS6-PH2	TATA spare parts
5181D9Y0160001	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
5181H9X0233001	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
5181H9X0233002	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
5181H9X0233003	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
5181H9X0233004	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
518349200115	BRACKET ASSY EXHAUST MTG BS6	TATA spare parts
518349990103	HEAT SHIELD CATCON BS6	TATA spare parts
51843100M10106	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51843100M10107	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51843100M10108	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51843100M10109	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
51843100M10110	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
518431107103	BASE PLATE RH BS6-PH2	TATA spare parts
518431107104	BASE PLATE LH BS6-PH2	TATA spare parts
518431107105	REINFORCEMENT RH BS6-PH2	TATA spare parts

518431107106	REINFORCEMENT LH BS6-PH2	TATA spare parts
518431107117	SUPPORT PLATE BS6-PH2	TATA spare parts
518431200101	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
518441110101	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
518441110102	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
518441110105	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
518441110106	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
518441110107	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
518441110109	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
518441120101	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
518441120105	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
518441300103	BRACKET ASSY CENTER BRG MTG	TATA spare parts
518441990101	SHORT FORK TUBE & REAR END PIECE ASSY BS	TATA spare parts
518441990104	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
518441990105	SHORT FORK TUBE & FRONT END PIECE ASSY B	TATA spare parts
518443900174	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
518443910101	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
518443910104	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
518443910132	NYLON PIPE BUNCH ASSY	TATA spare parts
518446600114	STEERING GEAR BOX ASSY BS6	TATA spare parts
518446700101	BRACKET ASSY RESERVOIR MTG BS6 PH2	TATA spare parts
518446703301	BRACKET STG GEAR BOX MTG BS6-PH2	TATA spare parts
518446800101	SUCTION LINE ASSY BS6 PH2	TATA spare parts
518446800102	PRESSURE LINE ASSY BS6 PH2	TATA spare parts
518446800103	PRESSURE LINE ASSY STG GB END BS6-PH2	TATA spare parts
518446800105	RETURN LINE ASSY GB TO INT JOINT BS6-PH2	TATA spare parts
518446800109	SUCTION LINE ASSY BS6 PH2	TATA spare parts
518446800110	PRESSURE LINE ASSY STG GB END BS6-PH2	TATA spare parts
518446800111	RETURN LINE ASSY GB TO INT JOINT BS6-PH2	TATA spare parts
518446800114	PRESSURE LINE ASSY STG GEAR BOX END BS6-	TATA spare parts
518446800115	RETURN LINE ASSY GEAR BOX TO INT JOINT B	TATA spare parts
518446800116	RETURN LINE INTERMEDIATE BS6-PH2	TATA spare parts
518446800117	RETURN LINE ASSY INT JOINT TO RESERVOIR	TATA spare parts
51845168000RCK	CABIN KIT W/FITMENT LPT 4225 TC BS6-PH2	TATA spare parts
518454630108	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
518454630118	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
518454630121	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
518454630124	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
518454630125	WIRING HARNESS TAIL BS6	TATA spare parts
518454630127	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
518454630128	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
518454630143	ADD ON WIRING HARNESS BS6-PH2	TATA spare parts
51846012M10189	INNER PANEL ASSY REAR-LH BS6-PH2	TATA spare parts
51846012M10190	INNER PANEL ASSY REAR-RH BS6-PH2	TATA spare parts
51846012M10191	FRONT PANEL ASSY BERTH BOX BS6-PH2	TATA spare parts
51846012M10192	FRONT PANEL ASSY RH BS6-PH2	TATA spare parts
51846012M10193	FRONT PANEL ASSY LH BS6-PH2	TATA spare parts



51846012M10198	ANGLE ASSY SUPPORT BERTH BOX BS6-PH2	TATA spare parts
51846120M10114	ASSY SUPPORT CROSS MEMBER BS6-PH2	TATA spare parts
51846210M10119	DOOR POST ASSY RH BS6-PH2	TATA spare parts
51846210M10120	DOOR POST ASSY LH BS6-PH2	TATA spare parts
51846210M10124	FRAME ASSY FRONT-LH BS6-PH2	TATA spare parts
51846210M10127	FRAME ASSY FRONT-RH BS6-PH2	TATA spare parts
51846220M10101	SUPPORT ASSY WAIST RAIL BS6-PH2	TATA spare parts
51846220M10144	WAIST RAIL ASSY BS6-PH2	TATA spare parts
51846220M10148	REINFORCEMENT ASSY WAIST RAIL BS6-PH2	TATA spare parts
51846220M10182	ASSY CCB MTG BKT RH BS6-PH2	TATA spare parts
51846221M18211	REINFORCEMENT WINDSHIELD BOTTOM INNER-R	TATA spare parts
51846250M10128	OUTER PANEL ASSY WINDSHIELD BOTTOM BS6-P	TATA spare parts
51846250M10130	ASSY PANEL FACE SIDE BOTTOM LH BS6-PH2	TATA spare parts
51846250M10131	ASSY PANEL FACE SIDE BOTTOM RH BS6-PH2	TATA spare parts
51846260M10108	A-PILLAR ASSY INNER-LH BS6-PH2	TATA spare parts
51846260M10111	A-PILLAR ASSY INNER-RH BS6-PH2	TATA spare parts
51846260M10132	PANEL ASSY WINDSHIELD INNER-TOP BS6-PH2	TATA spare parts
51846260M10144	TOE PANEL ASSY RH BS6-PH2	TATA spare parts
51846260M10145	TOE PANEL ASSY LH BS6-PH2	TATA spare parts
51846260M10148	BONNET ASSY BS6-PH2	TATA spare parts
51846260M10149	COVER PANEL ASSY BS6-PH2	TATA spare parts
51846260M10157	WINDSCREEN PANEL ASSY BOTTOM BS6-PH2	TATA spare parts
51846470M10150	CORNER PANEL ASSY WITH POST OUTER-LH BS6	TATA spare parts
51846470M10151	CORNER PANEL ASSY WITH POST OUTER-RH BS6	TATA spare parts
51846470M10153	REAR WALL ASSY BS6-PH2	TATA spare parts
51846520M10113	TOP RAIL SIDE ASSY INNER-LH BS6-PH2	TATA spare parts
51846520M10114	TOP RAIL SIDE ASSY INNER-RH BS6-PH2	TATA spare parts
51846520M10118	TOP RAIL ASSY REAR BS6-PH2	TATA spare parts
51846520M10134	ROOF ASSY WITH TOP RAIL BS6-PH2	TATA spare parts
51846660M10107	STEP WELL ASSY LH BS6-PH2	TATA spare parts
51846660M10108	STEP WELL ASSY RH BS6-PH2	TATA spare parts
51847220M10136	INNER PANEL ASSY DOOR LH BS6-PH2	TATA spare parts
51847220M10137	INNER PANEL ASSY DOOR RH BS6-PH2	TATA spare parts
51847220M10140	DOOR SHELL ASSY LH BS6-PH2	TATA spare parts
51847220M10141	DOOR SHELL ASSY RH BS6-PH2	TATA spare parts
51847220M10144	OUTER PANEL DOOR LH BS6-PH2	TATA spare parts
51847220M10145	OUTER PANEL DOOR RH BS6-PH2	TATA spare parts
51847510M10118	CENTER FLAP ASSY INNER BS6-PH2	TATA spare parts
5184D9Y0160001	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
518754610101	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
518754620101	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
519743700104	RELAY VALVE & MODULATOR VALVE ASSY W BKT	TATA spare parts
519746305102	PITMAN ARM	TATA spare parts
520521000002	RUBBER BEADING (L= 5 MTRS)	TATA spare parts
520521000008	RUBBER BEADING	TATA spare parts
520540150002	ACP PANEL 3MM THK IVORY WHITE	TATA spare parts
520540180001	ACP 2438X1219X4MM IVORY WHITE	TATA spare parts

520540190001	HINGE (C6-220)	TATA spare parts
52103100M10001	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
522510070001	LHS FRONT INSWING DOOR WITH MECHANISM	TATA spare parts
522510080001	LHS MID INSWING DOOR WITH MECHANISM	TATA spare parts
522580000001	ROUNDED BLACK ROLLER GUIDE	TATA spare parts
522580010001	ENTRANCE ROLLER GUIDE HEX	TATA spare parts
522580020001	ROLLER GUIDE PLATE ANGLED	TATA spare parts
522580030001	JAMB RUBBER 3061 +	TATA spare parts
522580040001	BOTTOM BEARING ASSEMBLY ANGLE	TATA spare parts
522580050001	BEARING ROLLER	TATA spare parts
522580060001	NYLON BEARING	TATA spare parts
522580070001	BALL JOINT BEARING M10 X	TATA spare parts
522580080001	ROLLER GUIDE ASSEMBLY	TATA spare parts
522580090001	NYLON ROLLER	TATA spare parts
522580100001	3/4INCH STEEL SPHERICAL BALL	TATA spare parts
522580110001	DOOR ARM STOPPER	TATA spare parts
522580120001	SENSITIVE EDGE DOOR NOSING	TATA spare parts
522580130001	SEALING RUBBER L=2.6M	TATA spare parts
522580140001	BALL JOINT BEARING M12 X	TATA spare parts
522580150001	EDGE FINISHER / L=2100	TATA spare parts
522580160001	M12 STAINLESS WASHER	TATA spare parts
522580170001	C SK WASHER	TATA spare parts
522580180001	C SK SCREW M8X25MM	TATA spare parts
522580190001	MICRO SWITCH	TATA spare parts
522580200001	EMERGENCY BUSH BUTTON	TATA spare parts
522580210001	EMERGENCY BUSH BUTTON RED KNOB	TATA spare parts
522580220001	BUTTON COMPRESSION SPRING	TATA spare parts
522580230001	O RING FOR DOOR CONTROL	TATA spare parts
522580240001	E-CLIP FOR BUTTON	TATA spare parts
522580250001	CYLINDER 63X85 WITH	TATA spare parts
522580260001	CYLINDER 63 X 125 STROKE +	TATA spare parts
522580270001	CYLINDER 80X125 WITH	TATA spare parts
522580280001	60MM CRANK	TATA spare parts
522580290001	LEADING STUB SHAFT ASSEMBLY	TATA spare parts
522580300001	TRAILING DOOR STUB SHAFT	TATA spare parts
522580310001	PLUG DOOR SUB SHAFT GLIDE A WAY	TATA spare parts
522580320001	FILTER & REGULATOR	TATA spare parts
522580330001	3/2 SOLENOID VALVE ASSEMBLY	TATA spare parts
522580340001	DRIVER S OPEN LOCKOUT SOLENOID VALVE ASS	TATA spare parts
522580350001	NOT LOGIC CONTROL (PRESSURE VALVE)331 00	TATA spare parts
522580360001	1/8 BSP 3/2 AIR PILOT VALVE.	TATA spare parts
522580370001	SHITTLE VALVE 1/8INCH ASSEMBLY	TATA spare parts
522580380001	SOLENOID VALVE VUVS-L20- B52-D-G18-F7	TATA spare parts
522580390001	AIR PILOT DUMP VALVE JDH-	TATA spare parts
522580400001	MSSD-EB ANGLE SOCKET	TATA spare parts
522580410001	B-1/8 PLUG	TATA spare parts
522580420001	SILENCER AMTE-M-H-G18	TATA spare parts

522580430001	PUSH-IN/THREADED L-FITTING	TATA spare parts
522580440001	PUSH IN L-FITTING 1/8-4MM	TATA spare parts
522580450001	QSLV2-1/8-6 ELBOW DOUBLE UNIV	TATA spare parts
522580460001	QSTF-1/8-6-B	TATA spare parts
522580470001	U-1/8 SILENCER	TATA spare parts
522580480001	6 TO 4MM REDUCER	TATA spare parts
522580490001	ENTRANCE LEAD FIXED GLASS	TATA spare parts
522580500001	ENTRANCE TRAIL FIXED GLASS	TATA spare parts
522580510001	EXIT PLUG DOOR FIXED GLASS	TATA spare parts
523310370001	DRIVER DOOR ASSY	TATA spare parts
523320640001	INNER COVER	TATA spare parts
524010270001	WINDOW ASSEMBLY (HOPPER)	TATA spare parts
524010280001	WINDOW ASSEMBLY (HOPPER) LH	TATA spare parts
524010290001	WINDOW ASSEMBLY (HOPPER) RH	TATA spare parts
524021110001	SIDE GLASS RH 1	TATA spare parts
524021120001	SIDE GLASS RH 2	TATA spare parts
524021130001	SIDE GLASS RH 3	TATA spare parts
524021170001	SIDE GLASS LH	TATA spare parts
524021180001	PASS DOOR TOP GLASS (LH SIDE GLASS)	TATA spare parts
524021190001	SIDE WINDOW LH (DOOR BACK)	TATA spare parts
524021210001	SIDE GLASS LAST LH/ RH	TATA spare parts
524021220001	TOP GLASS (LH SIDE GLASS)	TATA spare parts
524021230001	TOP GLASS (LH SIDE GLASS)	TATA spare parts
524021240001	TOP GLASS (LH/RH LAST GLASS)	TATA spare parts
524021310001	TOP GLASS (RH GLASS 1)	TATA spare parts
524021320001	TOP GLASS (RH SIDE GLASS)	TATA spare parts
524021330001	TOP GLASS (RH GLASS 2)	TATA spare parts
524021340001	PASS TOP GLASS	TATA spare parts
524021360001	DRIVER TOP GLASS	TATA spare parts
524021370001	DRIVER DOOR WINDOW	TATA spare parts
524030350001	DRIVER PARTITION GLASS 1	TATA spare parts
524030360001	DRIVER PARTITION GLASS 2	TATA spare parts
524030370001	DISPLAY GLASS	TATA spare parts
524030380001	PARTITION GLASS	TATA spare parts
524030390001	PARTITION GLASS	TATA spare parts
524610010001	FRONT WINDSHIELD GLASS	TATA spare parts
524720020001	REAR WINDSHIELD GLASS	TATA spare parts
5256388	HOSE ELBOW	TATA spare parts
5257635	SET UPPER ENGINE GASKET	TATA spare parts
5257636	SET LOWER ENGINE GASKET	TATA spare parts
5257637	SET OIL SEALS	TATA spare parts
5257638	SET FULL ENGINE GASKET	TATA spare parts
5257639	KIT ENGINE PISTON (STD.)	TATA spare parts
5257640	SET PISTON RING (STD.)	TATA spare parts
5257641	SET BEARING CONNECTING ROD (STD.)	TATA spare parts
5257642	SET INSERT VALVE (INTAKE)	TATA spare parts
5257643	SET INSERT VALVE (EXHAUST)	TATA spare parts

5257815	BLOCK CYLINDER	TATA spare parts
5258739	SET PISTON BARE EURO II RS-I	TATA spare parts
5259152	TUBE, CPR WATER OUTLET	TATA spare parts
5259157	BELT V RIBBED	TATA spare parts
5259159	TUBE, CPR WATER INLET	TATA spare parts
5260263	WATER PUMP	TATA spare parts
5260332	TUBE FUEL SUPPLY FLEXIBLE PIPE	TATA spare parts
5262036	CAMSHAFT	TATA spare parts
5263218	ALTERNATOR (12V 40AMPS. 2GRV.PULLEY)	TATA spare parts
5263947	SPIN ON LUBE FILTER FOR ESI	TATA spare parts
5266521	CATALYTIC CONVERTER	TATA spare parts
5267723	FLEXIBLE PIPE	TATA spare parts
5271331	PLUG SPARK	TATA spare parts
5271485	CAMSHAFT	TATA spare parts
5271639	THERMOSTAT	TATA spare parts
5272200	HOSE PLAIN -- 1100 MM	TATA spare parts
5272422	SET PISTON RINGS STD	TATA spare parts
5272656	SET MAIN BRG RS I	TATA spare parts
5282670	VALVE EXHAUST	TATA spare parts
5282704	ASSLY CYLINDER HEAD	TATA spare parts
5285515	SUPPORT CAMSHAFT THRUST	TATA spare parts
5286931	Screw H.F.M8x1.25x25	TATA spare parts
5288690	MANIFOLD EXHAUST	TATA spare parts
5289874	OIL SEAL	TATA spare parts
5293027	SCREW CPT ISOLATOR CAP	TATA spare parts
5297584	RING COMPRESSION PISTON	TATA spare parts
53010020359	HOSE RAD 22X31X160	TATA spare parts
53010020472	HOSE RAD 28X37X60	TATA spare parts
53010020600	HOSE 38 X 50 X 60	TATA spare parts
53010020626	HOSE RAD 38 X 55 X 70	TATA spare parts
53010020642	HOSE RAD 38 X 50 X 80	TATA spare parts
53010020685	HOSE RAD 38 X 50 X 200	TATA spare parts
53010060687	HOSE 38 X 46 X 70	TATA spare parts
53010352505	HOSE 25 SAE100R4 TS24552	TATA spare parts
53200091210	NYLON TUBE- 8 X 6 X 1000	TATA spare parts
53200094481	VINYL ROLL 3X12X2 IS15061 BLUE	TATA spare parts
53200094499	VINYL FLOORING YELLOW	TATA spare parts
53200170756	ABS LIGHT GREY 2400X1220X2MM IS 7078	TATA spare parts
53271271000	OIL DEFLECTOR RING	TATA spare parts
534830110001	RUBBER MUD FLAP	TATA spare parts
53610001978	PLYWOOD 19X8X4 IS5509	TATA spare parts
540115100102	ASSY STARTER MOTOR COMSTAR WITH H.S.MTG	TATA spare parts
540115100106	HEAT SHIELD M/S.TALBROS	TATA spare parts
540115400101	ALTERNATOR 12V 90A DICOR BSIV	TATA spare parts
540115459902	PULLEY ALTERNATOR W/VP	TATA spare parts
540115459903	PULLEY(63DIA)	TATA spare parts
540115459904	D.E.BKT M/C ALT W/VP	TATA spare parts

540115459905	D.E.BKT1 M/C ALT	TATA spare parts
540115459907	Rotor assly final	TATA spare parts
540115459908	ROTOR ASSY FINAL	TATA spare parts
540115459909	ROTOR_ASSY_FINAL	TATA spare parts
540115459910	ROTOR ASSY	TATA spare parts
540115459912	STATOR_WINDING_FINAL_ASSY	TATA spare parts
540115459913	STATOR WINDING FINAL ASSY	TATA spare parts
540115459914	STATOR_WINDING_FINAL_ASSY_ALT_120A_W/O	TATA spare parts
540115459915	STATOR WINDING	TATA spare parts
540115459917	RECTIFIER ASSY ALT W/VP	TATA spare parts
540115459918	RECTIFIER_ASSY	TATA spare parts
540115459919	RECTIFIER ASSY	TATA spare parts
540115459921	SRE BKT M/C ALT W/P	TATA spare parts
540115459922	SRE BKT1 M/C ALT	TATA spare parts
540115459924	Regulator & brush box assly	TATA spare parts
540115459925	REGULATOR & BRUSH BOX ASSLY	TATA spare parts
540115459926	Regulator & brush box assly	TATA spare parts
540115459927	REG& BRUSH BOX ASSY	TATA spare parts
540115459929	Housing complete	TATA spare parts
540115459930	HOUSING COMP. ALT 117A	TATA spare parts
540115459931	ROTOR ALTERNATOR W/VP	TATA spare parts
540115459932	CENTRE_PLATE._ALTERNATOR_W/VP	TATA spare parts
540115459933	VANES ALTERNATOR W/VP	TATA spare parts
540115459934	CHECK VALVE ALTERNATOR W/VPS	TATA spare parts
540115459935	BEARING ASSY KIT ALT W/VP	TATA spare parts
540115459936	BEARING ASSY KIT	TATA spare parts
540115459938	FASTENERS ASSY KIT ALT W/VP	TATA spare parts
540115459939	FASTENERS_ASSY_KIT_ALT_120A_W/O_LTVS	TATA spare parts
540115459940	FASTENERS ASSY KIT	TATA spare parts
540115459942	VACUUM PUMP ASSY ALT W/ VP	TATA spare parts
540115459972	BRUSH BOX ASSY	TATA spare parts
540115459974	RECTIFIER ASSY ALT W/VP	TATA spare parts
540142990105	KIT-SLIDING PIN BIL NO.29932382	TATA spare parts
540147617737	CLAMP,FUEL PIPE MTG	TATA spare parts
540154500106	COMBI SWITCH	TATA spare parts
540154679976	W/H,SENSOR ASSY DCM2.5 1.4L CRAIL	TATA spare parts
540154800101	ASSY MUSIC SYSTEM	TATA spare parts
540155106316	VITRO MASCOT "BS-4"	TATA spare parts
540168906302	COVER FRONT CONSOLE-(AS MOULDED) EBONY	TATA spare parts
540210270001	STANCHION PIPE	TATA spare parts
540220070001	BRACKET ASSY PIPE TO SIDE WALL	TATA spare parts
540220080001	SPLIT 4 WAY BRACKET ASSY 40X32	TATA spare parts
540230200001	ANGULAR BRACKET ASSY 40 DIA	TATA spare parts
540230280001	GLASS MTG BRACKETS 40 DIA PIPE	TATA spare parts
540230290001	TOP ANGULAR CONNECTING PLATE	TATA spare parts
540230300001	TOP BRACKET ASSY 40 DIA PIPE	TATA spare parts
540230310001	SPLIT T BRACKET 3WAY ASSY 40X32	TATA spare parts

540230340001	BASE BRACKET 40 DIA	TATA spare parts
540230380001	SEAT MOUNTED STANCHION BRACKET 40 DIA	TATA spare parts
540230390001	GLASS MOUNTING BRACKETS 32 DIA PIPE	TATA spare parts
540230400001	BASE BRACKET 32 DIA	TATA spare parts
540230420001	ANGULAR BRACKET ASSY	TATA spare parts
540240090001	PARTITION GLASS	TATA spare parts
540268906317	BEZEL DIGITAL CLOCK SHADOW BEGIE	TATA spare parts
540269106302	A PILLAR TRIM UPPER RH EXTD.SHADOW BEIGE	TATA spare parts
540269106312	CARPET W/ARCH INR REAR LH (W/O P/SHELF)	TATA spare parts
540324100103	ASSY ENGINE MTG BRACKET RH (FOR EURO 5)	TATA spare parts
540324100104	ASSY ENG MTG LH (EURO 5)	TATA spare parts
540324108203	BOXING PLATE,ENG MTG BKT,RH (EURO V)	TATA spare parts
540324108207	BOTTOM BOX ENG MTG BKT(EURO 5) RH	TATA spare parts
540332300124	SHOCK ABSORBER ASSY W SPRING,FRONT SUSP	TATA spare parts
540344807703	SEPARATOR CLAMP EURO-V M/S A RAYMOND	TATA spare parts
540346600120	RACK & PINION,POWER STG	TATA spare parts
540354509901	HOUSING_COMBI_SWITCH_LHD_M/S_DAESUNG	TATA spare parts
540368900104	ASSY GEAR SHIFT KNOB AT	TATA spare parts
540715400106	STATOR	TATA spare parts
540715400107	ROTOR	TATA spare parts
540715400109	DRIVE END SHIELD	TATA spare parts
540715409917	INSULATION¿CAP¿BOSCH	TATA spare parts
540715409918	RECTIFIER	TATA spare parts
540731706301	STONEGUARD MIDDLE PIECE	TATA spare parts
540732100101	ASSY STRUT MTG BRACKET - LH	TATA spare parts
540732100110	ASSY FRONT BUMP STOPPER MTG BRACKET- LH	TATA spare parts
540740103801	ALLOY WHEEL RIM 6.5J X 16	TATA spare parts
540741100102	UJ KIT (DANA-1310X)	TATA spare parts
540741100102DF	UJ CROSS 27X81.8 - 207DI/XENON	TATA spare parts
540741100103	CENTER BEARING ASSY	TATA spare parts
540742807701	FOUR PIPE CLAMP FOR DIA 4.75 TO 8	TATA spare parts
540742807707	TWO PIPE CLAMP	TATA spare parts
540742807708	CLAMP ROD	TATA spare parts
540743100105	KIT FILLER CAP	TATA spare parts
540754109901	EARTH STRAP.	TATA spare parts
540754200101	POWER SOCKET ASSY.12V WITH BLUE ILLUMINA	TATA spare parts
540754200126	ASSY POWER SOCKET CAP BLACK W/O STRIP	TATA spare parts
540754209914	ASM - CONTROLLER	TATA spare parts
540754400114	THREE S/W LED ROOF LAMP WITH PIGTAIL	TATA spare parts
540754620157	WIRING HARNESS,FRONT	TATA spare parts
540755106308	MASCOT GS-800	TATA spare parts
540758604003	JACK SEAT RUBBER	TATA spare parts
540772308001	TORX SCREW M8X22 BS6	TATA spare parts
540783404212	SERVO ASSY	TATA spare parts
540786806305	WASHER JERICAN NYLON	TATA spare parts
540786807701	RUBBER WASHER(5 THK)	TATA spare parts
540882400112	REAR WIPER ARM AND BLADE ASSEMBLY	TATA spare parts

540883603310	BRACKET FOR DISCHARGE PIPE	TATA spare parts
540899008801	STUD M5 BONNET FINISHER	TATA spare parts
540899506301	CLIP	TATA spare parts
540942807701	CLAMP (4 IN 1) ARAYMOND BS6	TATA spare parts
541243996701	PIN	TATA spare parts
541243999201	SPRING WASHER BS6	TATA spare parts
541258900629	SUPPORT STAND ENGINE	TATA spare parts
541258900633	STAND ENGINE BS6	TATA spare parts
541258900702	ADAPTER,CHECKING ENGINE COMPRESSION	TATA spare parts
541258901301	HOLDER AIR COMPRESSOR PULLEY	TATA spare parts
541258902604	DRIFT	TATA spare parts
541258902606	SUPPORT PLATE	TATA spare parts
541554509901	REVERSE LIGHT SWITCH	TATA spare parts
541583606311	SEPRATOR CLAMP SDE SUCTION HOSE BS6	TATA spare parts
541720110001	FIRE DETECTION/SUPPRESION SYSTEM	TATA spare parts
541999003206	FLANGE BOLT BF6X16XP-1	TATA spare parts
542015400104	STATOR ASSYEMBLY BOSCH	TATA spare parts
542015400105	DEEP GROOVE BALL BEARING	TATA spare parts
542015400106	BEARING¿BOSCH	TATA spare parts
542015409901	FLANGED NUT PRE COATED	TATA spare parts
542015409902	PULLEY	TATA spare parts
542015409904	REGULATOR	TATA spare parts
542015409905	PROTECTIVE CAP	TATA spare parts
542015409906	FLANGE NUT	TATA spare parts
542015409908	OVEL HEAD SCREW	TATA spare parts
542015409909	COUNTER SUNK SCREW BS6	TATA spare parts
542015409911	HEXAGONAL SCREW	TATA spare parts
542015409912	WASHER AND SCREW ASSY	TATA spare parts
542147509903	CLAMP HP LINE DIA 6.35MM BS6	TATA spare parts
542258900102	KIT-INJECTOR PULLER	TATA spare parts
542415100104	STARTER MOTOR ASSY	TATA spare parts
542415109905	HOUSING ASSY	TATA spare parts
542415109906	DRIVE ASSY	TATA spare parts
542415109907	ARMATURE ASSY	TATA spare parts
542415109908	FRAME ASSY	TATA spare parts
542415109909	BRUSH HOLDER	TATA spare parts
542415109910	END PLATE ASSY	TATA spare parts
542415109912	SOLENOID ASSY	TATA spare parts
542415109916	SOLENOID ASSY BS6-PH2	TATA spare parts
542415400107	BRACKET ASSY,ALTERNATOR GUARD MTG	TATA spare parts
542415409920	PULLEY ALTERNATOR BS6-PH2	TATA spare parts
542446990116	SCREW	TATA spare parts
542447100170	CARBON CANISTER ASSY	TATA spare parts
542447100173	CANISTER	TATA spare parts
542447107706	VENT CAP	TATA spare parts
542447108255	FUEL MODULE MTG RING	TATA spare parts
542447510214	FILTER ASSY BS6-PH2	TATA spare parts

542447510225	KIT-LP FILTER BS6-PH2	TATA spare parts
542447605839	VAPOUR HOSE BS6-PH2	TATA spare parts
542455106301	FRONT BUMPER T EMBLEM	TATA spare parts
542458900603	INNER STRETCH BELT INSTALLATION TOOL BS6	TATA spare parts
542458900604	LOCKING PIN	TATA spare parts
542458900606	VALVE SPRING,COMPRESSOR	TATA spare parts
542458900609	WEDGE	TATA spare parts
542458900614	GUIDE PIN	TATA spare parts
542458900615	OUTER STRETCH BELT INSTALLATION TOOL BS6	TATA spare parts
542458900616	INNER STRETCH BELT REMOVAL TOOL BS6-PH2	TATA spare parts
542458901802	SPANNER,OIL FILTER	TATA spare parts
542458902403	BRACKET,ENGINE MTG,LH	TATA spare parts
542468904301	CLIP,WIRE ROUTING	TATA spare parts
542483753301	SUPPORT BRACKET BS6	TATA spare parts
542488708234	CLIP,STAY ROD CLAMP	TATA spare parts
542499508202	METAL CLIP U SHAPE (M6)	TATA spare parts
542529100108	ADAPTER ASSY ACE EV	TATA spare parts
542547510107	PRESSURE REGULATOR ASSY BS6-PH2	TATA spare parts
542547510232	HOSE ASSY BS6-PH2	TATA spare parts
542558504002	BAG CHARGING CABLE	TATA spare parts
542558900605	FIXTURE ASSY	TATA spare parts
542742807501	RUBBER BUSH FOR ABS9 MOUNTING	TATA spare parts
542754209948	CLOCK SPRING WITHOUT AIRBAG CONNECTOR	TATA spare parts
542754400128	ASSY HIGH MOUNTED STOP LAMP BULB	TATA spare parts
542754409912	LED REGISTRATION PLATE LAMP	TATA spare parts
542754500110	COMBI SWITCH RHD W/O RR WIPER-DEASUNG	TATA spare parts
542758900602	SPL TOOL - STRETCH BELT REMOVAL	TATA spare parts
542799506301	BUMPER MOUNTING CLIP	TATA spare parts
543040010001	SUNVISOR FRONT	TATA spare parts
543120050001	SALOON MIRROR	TATA spare parts
543315999903	REGULATOR	TATA spare parts
543329104204	SEPARATOR CLAMP	TATA spare parts
543347608201	PURGE VALVE MTG BKT BS6	TATA spare parts
543349205303	GASKET	TATA spare parts
543354606306	SEPERATOR CLAMP FOR BATT +VE 14-18 MM	TATA spare parts
543392700114	SCREW HEX FLANGE HEAD CAP	TATA spare parts
543415109901	STARTER MOTOR HEAT SHIELD	TATA spare parts
543446600115	VALVE ASSY,STEERING PUMP	TATA spare parts
543454200129	HORN ASSY LOW TONE	TATA spare parts
543815459925	SCREW	TATA spare parts
543815459926	STUD	TATA spare parts
543815459930	NUT PULLEY BS6-PH2	TATA spare parts
543815459937	SEAL	TATA spare parts
543815459938	REGULATOR	TATA spare parts
543816211218	CONTAINER,BODY CONTROL MODULE	TATA spare parts
543829100117	ASSISTANCE GUIDE SEAT TOP BS6	TATA spare parts
543829100118	ASSISTANCE SPRING SEAT BOTTOM BS6	TATA spare parts



543846203203	SCREW,INTERMEDIATE SHAFT	TATA spare parts
543854509908	PEPS ODH & TAILGATE SWITCH	TATA spare parts
543855106303	MASCOT FRONT BUMPER T-EMBLEM BASE PLATE	TATA spare parts
543858900601	SPECIAL TOOL,STRETCH BELT REMOVAL	TATA spare parts
543858900701	INJECTOR HOLDER	TATA spare parts
543858900705	DRIVE SHAFT BEARING INNER RACE REMOVAL P	TATA spare parts
543858902401	BRACKET,ENGINE MTG,LH	TATA spare parts
543858902402	STAND	TATA spare parts
543858902403	ADAPTER	TATA spare parts
543858902602	SUPPORT PLATE	TATA spare parts
543858902603	PULLER ASSY	TATA spare parts
544216102002	ELECTRONIC MANAGMENT SYSTEM	TATA spare parts
544216102003	HARDWARE CONTROL MODULE NGNA CUBE LITE	TATA spare parts
544247610128	PURGE VALVE ASSY BS6-PH2	TATA spare parts
544258408205	TRANSFER LABEL-PETROL BS6	TATA spare parts
544291900101	BEZEL ACTIVE,HEADREST	TATA spare parts
544291900102	BEZEL PASSIVE,HEADREST	TATA spare parts
545021700001	RVM SWITCH & ITS HARNESS	TATA spare parts
545040240001	CO-DRIVER SIDE REAR VIEW MIRROR BS4	TATA spare parts
545040250001	RVM MOUNTING BRACKET	TATA spare parts
545040260001	RVM BRACKET 5MM.PAINTED.2.5M(4362015) RH	TATA spare parts
545040270001	DRIVER SIDE REAR VIEW MIRROR BS4	TATA spare parts
545720280001	LOCK	TATA spare parts
5461741	TERMINAL STRIP	TATA spare parts
548020300001	HANDLE	TATA spare parts
54806860657	TATA GENUINE D.E.F 200 L	TATA spare parts
54895860916	P80 EMULSION INTERNATIONAL BS6-PH2	TATA spare parts
549030530001	SINGLE SEATER WITH 2 POINT SEAT BELT RH	TATA spare parts
549030540001	SINGLE SEATER WITH 2 POINT SEAT BELT LH	TATA spare parts
549030550001	ASSY 2 SEATER ON FRONT¿ WHEEL ARCH RH	TATA spare parts
549030560001	ASSY 2 SEATER ON FRONT¿ WHEEL ARCH LH	TATA spare parts
549030570001	ASSEMBLY TWIN SEATER RH	TATA spare parts
549030580001	ASSEMBLY TWIN SEATER LH	TATA spare parts
549030590001	ASSY TWIN¿ SEATER REAR¿ WHEEL ARCH RH	TATA spare parts
549030600001	ASSEMBLY TWIN SEATER REAR	TATA spare parts
549030610001	SINGLE SEATER REAR	TATA spare parts
549030620001	ASSEMBLY TWIN SEATER REAR	TATA spare parts
550124200101	STOPPER ASSY REAR	TATA spare parts
550131000104	ASSY FRAME	TATA spare parts
550131000109	ASSY FRAME SC 4X4 31WB W/O LB	TATA spare parts
550131000116	FRAME ASSY	TATA spare parts
550131700101	ASSY CROSS MEMBER TAIL LAMP MOUNTING	TATA spare parts
550132300102	SHOCK ABSORBER ASSY FRONT	TATA spare parts
550132400102	BUMP STOPPER ASSY	TATA spare parts
550132400104	REAR SPRING ASSY	TATA spare parts
550132403201	CENTER BOLT	TATA spare parts
550132407702	TIP INSERT 2ND LEAF	TATA spare parts

550132407703	TIP INSERT 3RD LEAF	TATA spare parts
550132600101	SHOCK ABSORBER REAR	TATA spare parts
550140100105	WHEEL RIM ASSY	TATA spare parts
550140100113	WHEEL RIM ASSY BS6	TATA spare parts
550141100101	ASSY.PROP.SHAFT COMPLETE-REAR	TATA spare parts
550141100105	ASSY.PROPELLER SHAFT SINGLE PIECE	TATA spare parts
550141100107	ASSY. PROP. SHAFT-REAR (SINGLE PIECE) 28	TATA spare parts
550141100108	ASSY PROP SHAFT-REAR SINGLE PC 28	TATA spare parts
550141100111	PROPELLER SHAFT ASSY FRONT	TATA spare parts
550141100112	PROPELLER SHAFT ASSY REAR	TATA spare parts
550141100113	SLIP YOKE ASSY	TATA spare parts
550141100114	SLIP YOKE ASSY	TATA spare parts
550141100115	PROPELLER SHAFT ASSY REAR	TATA spare parts
550141100116	PROPELLER SHAFT ASSY REAR BS6-PH2	TATA spare parts
550143100101	MODULATOR VALVE ABS	TATA spare parts
550143100102	BOOSTER ASSY WITH TMC & RESERVOIR	TATA spare parts
550143800103	ASSY.TUBE	TATA spare parts
550143800116	TUBE ASSY ADAPTER TO REAR HOSE BS6-PH2	TATA spare parts
550143990102	KIT-MASTER CYL ASSY WITH RESERVOIR	TATA spare parts
550143990103	KIT-MASTER CYL ASSY W/O RESERVOIR	TATA spare parts
550143999001	MODULATOR VALVE ABS	TATA spare parts
550149100107	ASSY PRE-SILENCER WITH HEAT SHIELD	TATA spare parts
550149200103	PIPE ASSY FRONT	TATA spare parts
550149200107	PIPE ASSY	TATA spare parts
550149200108	PIPE ASSY TAIL	TATA spare parts
550154600104	W/H TAIL & 4X4 TRANSFER CASE	TATA spare parts
550154600117	WIRING HARNESS TAIL	TATA spare parts
550154600119	WH TAIL & TRANSFER CASE WITH ABS 4X4	TATA spare parts
550154600125	WIRING HARNESS TAIL	TATA spare parts
550154600126	WIRING HARNESS TAIL BS6	TATA spare parts
550154600127	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
550154601613	WIRING HARNESS CABIN	TATA spare parts
550154601615	WIRING HARNESS CABIN	TATA spare parts
550154620108	WIRING HARNESS FRONT	TATA spare parts
550154620109	WIRING HARNESS CABIN	TATA spare parts
550158903301	UNITIZED BEARING FITMENT DRIFT	TATA spare parts
550158903302	UNITIZED BEARING REMOVAL DRIFT	TATA spare parts
550158903304	SUPPORT PLATE BS6	TATA spare parts
550160000125BF	ASSY BODY SHELL COMPLETE PAINTED RHD_ ARC	TATA spare parts
550160000132BF	ASSY BODY SHELL COMP PAINTED 2.2 LTR SAU	TATA spare parts
550160000132D3	ASSY BODY SHELL COMP PAINTED 2.2 LTR SAU	TATA spare parts
550160000132000000	ASSY BODY SHELL COMP PAINTED 2.2 LTR SAU	TATA spare parts
550160000132FG	ASSY BODY SHELL COMP PAINTED 2.2 LTR SAU	TATA spare parts
550160000175BF	ARCTIC_ WHITE-BODY SHELL ASSY	TATA spare parts
55016531000R40BF	ASSY. CAB SHELL W/FIT AR/WHITE XENON E2	TATA spare parts
550168500101	KIT FIT OF MOULDED CARPET LHD EBONY BLAC	TATA spare parts
550168500102	KIT FIT OF MOULDED CARPET RHD EBONY BLAC	TATA spare parts

550168500103	CARPET ASSY FRONT FLOOR BS6	TATA spare parts
550168506303	CARPET FLOOR MOULDED RHD 3150WB & HYDR	TATA spare parts
550168506305	FLOOR CARPET	TATA spare parts
550168506307	INSULATION TUNNEL	TATA spare parts
550168506308	CARPET FRONT TUNNEL BS6	TATA spare parts
550169200101	ASSY B PILLAR UPPER LH LINEN EXT CAB	TATA spare parts
550169200102	ASSY B PILLAR UPPER RH LINEN EXT CAB	TATA spare parts
550169200113	ASSY TRIM REAR ROOF HEADER EXT CAB	TATA spare parts
550169206306	REAR WALL TRIM	TATA spare parts
550170500103	COVER ASSY CANOPY	TATA spare parts
550170990101	ASSY CARPET LOADBODY	TATA spare parts
550172990101	KIT-LOCK SET ASSY	TATA spare parts
550179100105IQ	TUBULAR STRUCTURE ASSY	TATA spare parts
550191000118	DRIVER SEAT ASSY WITH HEADREST BS6	TATA spare parts
550192000101	SEAT ASSY	TATA spare parts
550199506301	XMAS TREE CLIP LINEN	TATA spare parts
550199506302	CLIP LINER MTG REAR	TATA spare parts
550210200001	DASHBOARD HARNESS	TATA spare parts
550210250001	BELL HARNESS	TATA spare parts
550210290001	RAMP SWITCH HARNESS	TATA spare parts
550210370001	MOBILE CHARGER HARNESS	TATA spare parts
550215100101	STARTER MOTOR WITH THERMAL CUT OFF	TATA spare parts
550215109904	HEXAGON NUT-M5 BS6	TATA spare parts
550215109905	DRIVE END SHIELD	TATA spare parts
550215601602	WIRING HARNESS ENGINE	TATA spare parts
550215601603	WIRING HARNESS EMS	TATA spare parts
550215601604	WIRING HARNESS EMS	TATA spare parts
550215603301	BRACKET EMS WIRING HARNESS MTG	TATA spare parts
550215603302	BRACKET ENGINE WIRING HARNESS MTG	TATA spare parts
55022731000R20	ASSY. STAGE XENON 2.2L	TATA spare parts
550229100101	ASSY.CTRL MTG.WITH CLUTCH & BRAKE PEDAL	TATA spare parts
550229100104	ASSY.CTRL MTG.WITH CLUTCH & BRAKE PEDAL	TATA spare parts
550229100115	ASSY.CLUTCH PIPE (6 O.D.)	TATA spare parts
550229100115AE	ASSY.CLUTCH PIPE -XEN DC/SC	TATA spare parts
550229100116	ASSY.CLUTCH PIPE (6 O.D.)	TATA spare parts
550229100118	ASSY. CONTROL MTG. BKT. WELDED (BRAKE)	TATA spare parts
550229100119	ASSY. CONTROL MTG. BKT. COMPLETE (CLUTCH	TATA spare parts
550229100120	ASSY. CONTROL MTG. BKT. COMPLETE RH(BRK)	TATA spare parts
550229100121	ASSY. CONTROL MTG. BKT. COMPLETE LH(BRK)	TATA spare parts
550229100123	ASSY. BRAKE PEDAL LEVER (4:1)	TATA spare parts
550229100125	ASSY.CLUTCH PIPE-LHD (6 O.D.)	TATA spare parts
550229100126	ASSY.CLUTCH PIPE-RHD (6 O.D.)	TATA spare parts
550229100127	ASSY. BRAKE PEDAL LEVER	TATA spare parts
550229100128	ASSY. CLUTCH PEDAL LEVER	TATA spare parts
550229100130	ASSY. CONTROL MTG. BKT. COMPLETE (CLUTCH	TATA spare parts
550229100131	ASSEMBLY CLUTCH PIPE-RHD	TATA spare parts
550229100132	ASSY BRACKET (CLUTCH SLAVE CYL. HOSE)	TATA spare parts

550229100142	ASSY. CONTROL MTG. BKT. COMPLETE- RH	TATA spare parts
550229100143	ASSY CLUTCH PIPE-LHD(XENON PETROL)	TATA spare parts
550229100144	ASSY.CLUTCH PIPE - RHD	TATA spare parts
550229100145	ASSY.CLUTCH PIPE (4.75 O.D.)	TATA spare parts
550229100149	ASSY. BRAKE PEDAL LEVER (4:1)	TATA spare parts
550229100152	ASSY. BRAKE PEDAL LEVER	TATA spare parts
550229100153	ASSY.CLUTCH PIPE CMC TO CSC OD 6 X 0.7 T	TATA spare parts
550229100154	ASSY.CONTROL MTG.BKT. COM.(CLUTCH)-LHD	TATA spare parts
550229100157	ASSY.CONTROL MTG. BKT COMPL (CLUTCH)-RHD	TATA spare parts
550229100163	ASSY.CLUTCH PIPE-LHD (6 O.D.X 0.7 THK)	TATA spare parts
550229100167	ASSY.CONTROL MTG. BKT. COMPLETE RHD(BRK)	TATA spare parts
550229100169	LEVER ASSY CLUTCH PEDAL	TATA spare parts
550229100170	BRACKET ASSY CLUTCH CONTROL MTG	TATA spare parts
550229100172	HIGH PRESSURE PIPE ASSY	TATA spare parts
550229100174	HIGH PRESSURE PIPE ASSY	TATA spare parts
550229100176	CLUTCH MASTER CYLINDER WITH HOSE	TATA spare parts
550229100177	PLATE ASSY	TATA spare parts
550229104201	CLAMP	TATA spare parts
550229106306	CLUTCH FOOTREST - RHD	TATA spare parts
550229106307	MOUNTING CLIP FOR CLUTCH FOOTREST	TATA spare parts
550229106308	CLUTCH FOOT REST	TATA spare parts
550229108221	BRACKET (BRAKE RETURN SPRING)	TATA spare parts
550229108701	COMPRESSION SPRING(FOR CLUTCH ASSISTANCE)	TATA spare parts
550229108702	COMPRESSION SPRING(FOR CLUTCH ASSISTANCE)	TATA spare parts
550229200101	LEVER ASSY BRAKE PEDAL	TATA spare parts
550229200102	BRAKE PEDAL ASSY WITH MTG BRACKET	TATA spare parts
550229200105	BRAKE PEDAL ASSY WITH BUSH	TATA spare parts
550229200106	BRAKE PEDAL ASSY WITH CONTROL MTG BKT	TATA spare parts
550230100101	ASSY.BRACKET(FOR LHD ACCL. PEDAL MTG.)	TATA spare parts
550230100102	ASSY.BRACKET(FOR RHD ACCL. PEDAL MTG.)	TATA spare parts
550230100104	ASSY ACCELERATO ROD (XENON PETROL LHD)	TATA spare parts
550230100105	ASSY. ACC. CABLE (XENON PETROL LHD)	TATA spare parts
550230100106	ASSY. BRACKET ACCELERATOR PEDAL MTG.-RHD	TATA spare parts
550230100107	BRACKET ASSY.(FOR ACC. PEDAL & BCM MTG.)	TATA spare parts
550230108203	SPACER(FOR ACCELERATOR PEDAL)	TATA spare parts
550231000108	ASSY FRAME XENON AIRBAG 2.2L DC 4X4 31WB	TATA spare parts
550231000109	ASSY FRAME XENON 3.0L DC 4X4 31WB	TATA spare parts
550231000113	FRAME ASSY	TATA spare parts
550231000114	FRAME ASSY REDUCED SCRUB ESP	TATA spare parts
550231000117	FRAME ASSY	TATA spare parts
550231000119	FRAME ASSY	TATA spare parts
550231200102	ASSY BRACKET (REAR ENGINE MOUNT 4X4)	TATA spare parts
550231200104	ASSY BRACKET (ENG MTG REAR)	TATA spare parts
550231200106	ASSY. CROSS MEMBER (ENG MTG REAR)	TATA spare parts
550231200107	ASSY. BRACKET (RUPD MOUNTING)	TATA spare parts
550231200108	ASSY.BRACKET ENGINE MTG REAR	TATA spare parts
550231200112	ASSY. CROSS MEMBER (FUEL TANK MTG)	TATA spare parts

550231200113	ASSY. CROSSMEMBER FRONT	TATA spare parts
550231200125	ASSY.NOISE SHEILD MTG.BRACKET	TATA spare parts
550231200126	ASSY.NOISE SHEILD MTG.BRACKET	TATA spare parts
550231200130	ASSY.BRACKET (FRONT GUARD MTG.)	TATA spare parts
550231200149	BRACKET ASSY CROSS MEMBER MTG RH	TATA spare parts
550231200150	BRACKET ASSY CROSS MEMBER MTG LH	TATA spare parts
550231208211	CROSS MEMBER ENG. MTG. REAR	TATA spare parts
550231208219	CRUSH PIECE (INNER)	TATA spare parts
550231208220	FLANGE - FRONT	TATA spare parts
550231208234	CROSSMEMBER (FRONT)	TATA spare parts
550231208235	CROSS MEMBER (REAR)	TATA spare parts
550231208236	CLOSING PLATE	TATA spare parts
550231400101	ASSY. TOWING HOOK (FRONT LH)	TATA spare parts
550231400102	CROSS MEMBER ASSY SPARE WHEEL MTG	TATA spare parts
550231410101	CROSS MEMBER ASSY CENTER BEARING MTG	TATA spare parts
550231470101	CROSS MEMBER ASSY FUEL TANK MTG REAR	TATA spare parts
550231500106	CROSS MEMBER ASSY FOOT STEP MTG REAR	TATA spare parts
550231505101	TOW HOOK	TATA spare parts
550231700103	ASSY NOISE SHIELD	TATA spare parts
550231700104	RADIATOR TOP COVER ASSY.	TATA spare parts
550231706301	FRONT GUARD	TATA spare parts
550231706302	FRONT GUARD-PIGMENTED SILVER	TATA spare parts
550231706308	FRONT GUARD (PIGMENTED BLACK)	TATA spare parts
550231708205	BRACKET FILLER NECK MTG	TATA spare parts
550231860101	CROSS MEMBER ASSY FRONT CRASH	TATA spare parts
550231908202	STONE GUARD	TATA spare parts
550231990101	KIT-BRACKET REINFORCEMENT FRAME	TATA spare parts
550232100103	CROSS MEMBER	TATA spare parts
550232100104	BUMP STOPPER ASSY FRONT	TATA spare parts
550232100109	ECCENTRIC PIN ASSY LOWER WISHBONE MTG	TATA spare parts
550232100111	ECCENTRIC PIN ASSY LOWER WISHBONE MTG	TATA spare parts
550232108701	COIL SPRING FRONT	TATA spare parts
550232109204	TONGUE WASHER	TATA spare parts
550232300102	SHOCK ABSORBER ASSY FRONT	TATA spare parts
550232300103	DAMPER ASSY FRONT	TATA spare parts
550232400115	REAR SPRING ASSY PARABOLIC DC	TATA spare parts
550232400117	BRACKET ASSY SPRINGN HANGER REAR	TATA spare parts
550232403201	HEX FLANGE BOLT M16X1.5X	TATA spare parts
550232403202	HEX FLANGE BOLT M16X1.5X175	TATA spare parts
550232403203	HEX FLANGE BOLT M16X1.5X115	TATA spare parts
550232403204	HEX FLANGE BOLT M16X1.5X135_SHOCK ABOSRE	TATA spare parts
550232403205	HEX FLANGE BOLT M16X1.5X100_SHOCK ABOSRE	TATA spare parts
550232404205	CLAMP REAR LEAF SPRING	TATA spare parts
550232404206	CLAMP REAR LEAF SPRING	TATA spare parts
550232405101	ASSLY. GUIDE PLATE - RH	TATA spare parts
550232405102	ASSLY. GUIDE PLATE - LH	TATA spare parts
550232407107	1ST LEAF	TATA spare parts

550232407108	LEAF - 2	TATA spare parts
550232407109	3RD LEAF	TATA spare parts
550232600101	SHOCK ABSORBER ASSY REAR	TATA spare parts
550232608202	SPACER	TATA spare parts
550232800102	ANTI ROLL BAR ASSY	TATA spare parts
550240100108	ASSY.AL ALLOYWHEELRIM(5.5JX16)	TATA spare parts
550240100124	ALLOY WHEEL RIM -5.5JX16(M/S. SYNERGIES	TATA spare parts
550240100202	ASSY.WHEEL RIM COVER 16(4X4)	TATA spare parts
550240109904	TUBELESS TYRE	TATA spare parts
550240109905	TUBELESS TYRE 235/70 R16	TATA spare parts
550240300101	ASSY.SPARE WHEEL CARRIER	TATA spare parts
550240306901	HEX BOLT M12	TATA spare parts
550241100101	ASSY.PROP.SHAFT -RR SPRINT 3LDICOR	TATA spare parts
550241100106	ASSY. PROP. SHAFT-REAR SC/SPC/CC 31WB 4X	TATA spare parts
550241100106AE	ASSY PROP SFT RR -XENON DC/SC	TATA spare parts
550241100107	ASSY. PROP. SHAFT-REAR (SINGLE PIECE) 28	TATA spare parts
550241100109	PROPELLER SHAFT ASSY	TATA spare parts
550241100111	PROPELLER SHAFT ASSY	TATA spare parts
550241100112	PROPELLER SHAFT ASSY	TATA spare parts
550241100114	PROPELLER SHAFT ASSY REAR	TATA spare parts
550241100115	PROPELLER SHAFT ASSY REAR	TATA spare parts
550241100116	PROPELLER SHAFT ASSY MONOTRON BS6-PH2	TATA spare parts
550241110106	ASSY.PROP.SHAFT REAR	TATA spare parts
550241120106	ASSY.PROP.SHAFT REAR	TATA spare parts
550241120107	ASSY.PROP.SHAFT REAR	TATA spare parts
550242700108	PARKING BRAKE CABLE ASSY	TATA spare parts
550242801605	CLAMP (PLASTIC CLAMP)	TATA spare parts
550243100103	ASSY.TANDEM BTMC COMMON BOTTLE	TATA spare parts
550243100104	BOOSTER ASSY WITH TMC & RESERVOIR	TATA spare parts
550243100105	HYDRAULIC MODULATOR ESP	TATA spare parts
550243100106	BOOSTER ASSY WITH TMC & RESERVOIR	TATA spare parts
550243500101	ASSY.TANDEM BOOSTER WITH TMC,BOTTLE	TATA spare parts
550243500103	ASSY VACUUM HOSE	TATA spare parts
550243500105	ASSY VACUUM HOSE	TATA spare parts
550243500106	ASSY BOOSTER TMC	TATA spare parts
550243500108	ASSY.VACUUM HOSE	TATA spare parts
550243500109	ASSY VACUUM HOSE	TATA spare parts
550243500111	VACUUM HOSE ASSY	TATA spare parts
550243500113	BOOSTER ASSY 8+9IN WITH COMMON RESERVOIR	TATA spare parts
550243500114	VACUUM HOSE ASSY	TATA spare parts
550243500131	KIT-FLUID RESERVOIR BS6	TATA spare parts
550243500137	KIT-FLUID RESERVOIR BS6-PH2	TATA spare parts
550243505805	VACUUM HOSE	TATA spare parts
550243505806	RUBBER HOSE VACUUM PIPE	TATA spare parts
550243505809	VACUUM HOSE	TATA spare parts
550243505819	VACUUM HOSE	TATA spare parts
550243509901	MC ASSY WITH RESERVOIR (SERVICE)	TATA spare parts

550243509902	FLUID RESERVOIR ASSY	TATA spare parts
550243800101	ASSY.BRAKE TUBE	TATA spare parts
550243800102	ASSY.BRAKE TUBE	TATA spare parts
550243800103	ASSY.BRAKE TUBE	TATA spare parts
550243800109	ASSY.BRAKE TUBE	TATA spare parts
550243800111	ASSY.BRAKE TUBE	TATA spare parts
550243800124	ASSY BRAKE TUBE	TATA spare parts
550243800125	ASSY BRAKE TUBE	TATA spare parts
550243800126	ASSY BRAKE TUBE	TATA spare parts
550243800127	ASSY BRAKE TUBE	TATA spare parts
550243800128	ASSY BRAKE TUBE	TATA spare parts
550243800135	ASSY.BRAKE TUBE MODUL.PORT C TO FR RH	TATA spare parts
550243800136	ASSY BRAKE PIPE MODULATOR PORT B TO REAR	TATA spare parts
550243800137	ASSY BRAKE TUBE	TATA spare parts
550243800139	ASS.BRAKE PIPE MTG.BKT.ON FIREWALL	TATA spare parts
550243800140	ASSY BRAKE HOSE(REAR)	TATA spare parts
550243800143	ASSY.BRAKE PIPE	TATA spare parts
550243800144	ASSY.BRAKE PIPE	TATA spare parts
550243800145	ASSY.BRAKE PIPE	TATA spare parts
550243800146	ASSY.BRAKE PIPE	TATA spare parts
550243800150	ASSY BRAKE PIPE TMC PRIMARY-TEE FR LH	TATA spare parts
550243800151	ASSY BRAKE PIPE TMC SECONDARY TO REAR	TATA spare parts
550243800152	ASSY. BRAKE PIPE TMC PRIMARY-TEE FR RH	TATA spare parts
550243800169	BRAKE PIPE ASSY MOD PORT TO REAR RH	TATA spare parts
550243800175	TUBE ASSY TMC PRIMARY TO MODULATOR (8 DI	TATA spare parts
550243800176	TUBE ASSY TMC SECONDARY TO MODULATOR (8	TATA spare parts
550243800177	TUBE ASSY MODULATOR PORT C TO FR RH	TATA spare parts
550243800178	TUBE ASSY MODULATOR PORT B TO REAR RH	TATA spare parts
550243800179	TUBE ASSY MODULATOR PORT A TO RR LH	TATA spare parts
550243800181	BRAKE PIPE ASSY MOD PORT TO REAR LH	TATA spare parts
550243800182	BRAKE PIPE ASSY FRONT RH	TATA spare parts
550243800183	BRAKE PIPE ASSY FRONT LH	TATA spare parts
550243800184	BRAKE PIPE ASSY MOD PORT LGMBR REAR RH	TATA spare parts
550243800185	BRAKE PIPE ASSY MOD PORT LGMBR REAR LH	TATA spare parts
550243800186	BRAKE PIPE ASSY REAR LH	TATA spare parts
550243800187	BRAKE PIPE ASSY REAR RH	TATA spare parts
550243800188	BRACKET ASSY CONNECTOR MTG	TATA spare parts
550243800194	BRACKET ASSY SENSOR CABLE MTG RH	TATA spare parts
550243800195	BRACKET ASSY SENSOR CABLE MTG LH	TATA spare parts
550243800200	BRAKE HOSE ASSY REAR	TATA spare parts
550243804201	P CLAMP FOR VACUUM HOSE	TATA spare parts
550243804202	CLAMP BRAKE PIPES & FUEL PIPES	TATA spare parts
550243804203	CLAMP BRAKE PIPE	TATA spare parts
550243804205	CLAMP ASSY BRAKE PIPE	TATA spare parts
550243806701	PIN ABS COVER UNIT MOUNTING	TATA spare parts
550243807101	PLATE BRAKE PIPE SUPPORT	TATA spare parts
550243807701	CLAMP BRAKE PIPE & HARNESS	TATA spare parts

550243807702	XENON ABS COVER	TATA spare parts
550243809904	3-WAYCONNECTOR BS6	TATA spare parts
550243990101	KIT-M/C ASSY WITH RESERVOIR SERVICE	TATA spare parts
550243990102	T M C ASSY	TATA spare parts
550243990103	M/C ASSEMBLY WITHOUT RESERVOIR-SERVICE	TATA spare parts
550243990104	T M C ASSY W/O RESERVOIR	TATA spare parts
550243990105	BOOSTER ASSEMBLY-SERVICE	TATA spare parts
550243990106	BOOSTER ASSY	TATA spare parts
550243990108	BOOSTER ASSY	TATA spare parts
550243990109	MASTER CYLINDER ASSY	TATA spare parts
550243990112	KIT-REPAIR MC ASSY WITH RESERVOIR	TATA spare parts
550243990114	KIT-REPAIR O-RING(SERVICE)	TATA spare parts
550243990115	KIT-REPAIR BOOSTER ASSY(SERVICE)	TATA spare parts
550243990116	KIT-FLUIDRESERVOIR BS6	TATA spare parts
550243990117	KITFILLERCAP BS6	TATA spare parts
550243990118	KIT-REPAIRFILTER BS6	TATA spare parts
550243990119	KIT-REPAIRFILLERCAPASSEMBLY BS6	TATA spare parts
550243990121	MASTERCYLINDERASSY BS6	TATA spare parts
550243999001	MODULATOR VALVE ESP	TATA spare parts
550243999902	KIT-REPAIR FLUID RESERVOIR ASSY BS6	TATA spare parts
550246100101	ASSY TILT STG. COLUMN	TATA spare parts
550246100107	STEERING COLUMN ASSY	TATA spare parts
550246100108	STEERING COLUMN ASSY	TATA spare parts
550246107101	BENT PLATE	TATA spare parts
550246107701	RUBBER BELLOW	TATA spare parts
550246107703	RUBBER BELLOW	TATA spare parts
550246200101	ASSY.STAY BRACKET (LHD) STG TO FIREWALL	TATA spare parts
550246200102	ASSY.STAY BRACKET (RHD) STG TO FIREWALL	TATA spare parts
550246200103	ASSY.TILT STEERING UNIT COMPLETE	TATA spare parts
550246200104	ASSY.BRACKET (STG.COLOUMN MTG.)	TATA spare parts
550246200107	ASSY.HANDLE	TATA spare parts
550246200115	ASSY STG COLUMN MTG BKT(COLLAPS) RHD	TATA spare parts
550246200116	ASSY STG COLUMN MTG BKT(COLLAPS) LHD	TATA spare parts
550246200118	ASSY POWER STEERING GEARBOX	TATA spare parts
550246200119	ASSY POWER STEERING GEARBOX (M/S ZF)	TATA spare parts
550246200120	ASSY LOWER INTERMEDIATE SHAFT	TATA spare parts
550246200121	ASSY. POWER STG GEAR BOX 90BAR RHD BS3/4	TATA spare parts
550246200123	ASSY LEVER (WITH CAM) FOR TILT STG COLUM	TATA spare parts
550246200124	ASSY UPPER COLUMN WITH SOLID SHAFT	TATA spare parts
550246200125	ASSY LOWER SHAFT (TELESCOPIC)	TATA spare parts
550246200126	SLEEVE STG BS6	TATA spare parts
550246200130	STEERING COLUMN ASSY LOWER	TATA spare parts
550246200201	ASSY.COLLAPSIBLE STG.COL.UNIT COMPLETE	TATA spare parts
550246200202	ASSY.COLLAPSIBLE STG.COL.UNIT COMPLETE	TATA spare parts
550246200203	ASSY. COLLAPSIBLE STG. COLUMN COMPLETE (	TATA spare parts
550246203201	HEX BOLT	TATA spare parts
550246203313	SUPPORT BRACKET-TOP(COLLAPS STG COLUMN)	TATA spare parts



550246203402	NORGLIDE BUSH (PAWL LINK CAM PIVOT)	TATA spare parts
550246204301	SPRING RING	TATA spare parts
550246206301	WASHER	TATA spare parts
550246206501	NUT	TATA spare parts
550246207701	PACKING (COLLAPS STG MTG ON C.C.B)	TATA spare parts
550246207702	RUBBER BELLOW STG SPINDLE	TATA spare parts
550246207901	STEERING SPINDE BOTTOM BS6	TATA spare parts
550246210101	SUB-ASSY.PAWL (WITH BOSS).	TATA spare parts
550246300102	ASSY IDLER ARM MTG BRACKET-RHD	TATA spare parts
550246300103	ASSY. IDLER ARM BRACKET-RHD	TATA spare parts
550246300104	ASSY. IDLER ARM BRACKET-LHD	TATA spare parts
550246300114	ASSY. IDLER ARM WITH FORGED MTG. BKT	TATA spare parts
550246300115	ASSY. IDLER ARM WITH FORGED MTG BKT(LHD)	TATA spare parts
550246300116	ASSY. IDLER ARM WITH BUSH (RHD)	TATA spare parts
550246303301	IDLER ARM MTG. BKT (FORGED)- RHD	TATA spare parts
550246306004	PITMAN ARM (RHD)	TATA spare parts
550246306005	PITMAN ARM (LHD)	TATA spare parts
550246600112	ASSY.P/STG PUMP(90BAR) - -DICOR	TATA spare parts
550246600130	POWER STEERING PUMP KIT - XENON	TATA spare parts
550246600138	HOUSING ASSEMBLY KIT STG. PUMP - XENON	TATA spare parts
550246600140	SHAFT SUB ASSY. STG. PUMP - XENON	TATA spare parts
550246600141	CARTRIDGE ASSY. KIT STG. PUMP XENON BS4	TATA spare parts
550246600142	SEAL KIT - STG. PUMP XENON	TATA spare parts
550246600148	CENTER LINK ASSY-RHD	TATA spare parts
550246600149	CENTRE LINK ASSY-LHD	TATA spare parts
550246600167	POWER STEERING PUMP ASSY	TATA spare parts
550246600178	SUPPORT BRACKET ASSY RESERVOIR	TATA spare parts
550246600179	POWER STEERING RESERVOIR ASSY BS4	TATA spare parts
550246600183	RACK & PINION ASSY POWER STG	TATA spare parts
550246600184	INNER BALL JOINT & BELLOW ASSY	TATA spare parts
550246600186	FEED PIPE ASSY LONG	TATA spare parts
550246600187	FEED PIPE ASSY SHORT	TATA spare parts
550246600201	ASSY.CENTER LINK _	TATA spare parts
550246600202	ASSY. TIE ROD	TATA spare parts
550246600203	ASSY.CENTRE LINK	TATA spare parts
550246600204	ASSY. TIE ROD	TATA spare parts
550246600207	ASSY. TIE ROD(M/S SONA SOMIC	TATA spare parts
550246600208	ASSY P/STG RESERVOIR WITH BKT	TATA spare parts
550246600210	ASSY. CENTER LINK - RHD BS3/4	TATA spare parts
550246600211	ASSY. TIE ROD BS3/4	TATA spare parts
550246600212	ASSY. CENTER LINK - LHD	TATA spare parts
550246600221	COVER ASSEMBLY FOR RESERVOIR - POWER STE	TATA spare parts
550246600222	FILTER ASSEMBLY FOR RESERVOIR - POWER ST	TATA spare parts
550246600223	SHELL ASSEMBLY	TATA spare parts
550246600224	BRACKET ASSEMBLY	TATA spare parts
550246600225	COVER ASSEMBLY FOR POWER STEERING RESERV	TATA spare parts
550246600226	BRACKET ASSEMBLY FOR POWER STEERING RESE	TATA spare parts

550246603201	BOLT	TATA spare parts
550246603801	SUCTION PORT CONNECTOR STG. PUMP- XENON	TATA spare parts
550246603802	SUCTION PORT CONNECTOR STG. PUMP XENON	TATA spare parts
550246604301	MOUNTING CLAMP	TATA spare parts
550246605103	WHEEL STOPPER - LH	TATA spare parts
550246605104	WHEEL STOPPER - RH	TATA spare parts
550246606101	RETAINING RING - STG PUMP XENON	TATA spare parts
550246606301	SLEEVE(FOR I-SHAFT)	TATA spare parts
550246607701	MOUNTING RUBBER	TATA spare parts
550246607801	O RING (SUC. PORT CONNECTOR) STG PUMP -	TATA spare parts
550246607802	O-RING (WORM COVER)	TATA spare parts
550246607803	O-RING (CYLINDER COVER)	TATA spare parts
550246607804	O-RING (RACK PAD ADJUSTER)	TATA spare parts
550246607805	O-RING (SIDE COVER)	TATA spare parts
550246608201	SUPPORT BRACKET	TATA spare parts
550246608501	HOSE ADAPTOR (FOR STEERING RETURN LINE)	TATA spare parts
550246609201	SPRING WASHER	TATA spare parts
550246800101	ASSY RETURN LINE (G/BOX.TO RESERVOIR)	TATA spare parts
550246800102	ASSY RETURN LINE (G/BOX.TO RESERVOIR)	TATA spare parts
550246800103	ASSY. HIGH PRESSURE LINE 2.2L RHD	TATA spare parts
550246800104	ASSY RETURN LINE 2.2L RHD- RANE	TATA spare parts
550246800105	HIGH PRESSURE LINE ASSY	TATA spare parts
550246800108	RETURN LINE ASSY RACK & PINION TO RES	TATA spare parts
550246800109	ASSY.BRACKET FOR STG. LINES SUPPORT	TATA spare parts
550246800110	SUCTION LINE ASSY.	TATA spare parts
550246800111	ASSY SUCTION LINE (2.2L LHD)	TATA spare parts
550246800112	ASSY HIGH PR LINE (2.2L LHD)	TATA spare parts
550246800113	ASSY RETURN LINE - (2.2 L LHD)	TATA spare parts
550246800114	ASSY SUCTION LINE 3.0L LHD	TATA spare parts
550246800115	ASSY HIGH PR LINE - 3.0L LHD	TATA spare parts
550246800116	ASSY. RETURN LINE - 3.0L LHD	TATA spare parts
550246800128	ASSY. SUCTION LINE (LHD)	TATA spare parts
550246800129	ASSY.HIGH PRESSURE LINE	TATA spare parts
550246800131	ASSY. PRESSURE LINE (EURO V-RHD)	TATA spare parts
550246800132	ASSY RETURN LINE (EURO V-RHD)	TATA spare parts
550246800161	SUCTION LINE ASSY RESERVOIR TO PUMP	TATA spare parts
550246800162	HIGH PRESSURE LINE ASSY	TATA spare parts
550246800163	RETURN LINE ASSY RACK & PINION TO RES	TATA spare parts
550246803301	PLATE FOR HOSE CLAMP	TATA spare parts
550246803302	STG. LINES SUPPORTING BRACKET	TATA spare parts
550246804201	HOSE CLAMP (RESERVOIR SIDE)	TATA spare parts
550246804204	SPACER CLAMP 12X19X25	TATA spare parts
550246804205	SPACER CLAMP 18.2X23.6X32	TATA spare parts
550246804208	CLAMP TUBE SUPPORT	TATA spare parts
550246804209	CLAMP	TATA spare parts
550246804210	CLAMP	TATA spare parts
550246805801	RUBBER HOSE (RETURN LINE)	TATA spare parts

550246990103	SHAFT ASSY BS6	TATA spare parts
550246990104	KIT-CARTRIDGE ASSY BS6	TATA spare parts
550247100102	ASSY. FUEL TANK (COMPLETE)	TATA spare parts
550247100103	ASSY.FILLER NECK TOP WITH BRACKET	TATA spare parts
550247100109	ASSY.FILLER NECK TOP WITH BRACKET	TATA spare parts
550247100113	ASSY FUEL FILTER MTG BKT	TATA spare parts
550247100115	ASSY FUEL TANK COMPLETE 65L	TATA spare parts
550247100126	ASSY FUEL TANK COMPLETE 70L	TATA spare parts
550247100151	ASSY.FILLER NECK	TATA spare parts
550247100154	ASSLY.RUBBER BUSH	TATA spare parts
550247100155	FLANGE UNIT(65L)SUCTION AND RETURN LINE	TATA spare parts
550247100157	ASSY. FUEL STRAINER	TATA spare parts
550247100160	ASSY FLANGE UNIT (70L)	TATA spare parts
550247100164	ASSY. FILLER NECK TOP WITH BRAKET	TATA spare parts
550247100167	SUCTION UNIT ASSY	TATA spare parts
550247100168	FUEL TANK ASSY WITH TANK UNIT	TATA spare parts
550247100172	FILLER NECK ASSY WITH BRACKET	TATA spare parts
550247106914	SPACER TUBE(FOR FUEL TANK MTG.)	TATA spare parts
550247107701	RUBBER HOSE (FUEL FILLING)	TATA spare parts
550247107701AE	RBBR HOSE (FUEL FLLNG)-XEN DC/SC	TATA spare parts
550247107702	FUEL FILLING HOSE	TATA spare parts
550247109912	RUBBER SEALING	TATA spare parts
550247500101	BRACKET ASSY FUEL TANK MTG	TATA spare parts
550247500102	BRACKET ASSY FUEL TANK MTG	TATA spare parts
550247500103	BRACKET ASSY FUEL TANK MTG	TATA spare parts
550247600101	ASSY. BREATHER HOSE	TATA spare parts
550247600118	ASSY. FUEL LINES - CHASSIS SIDE	TATA spare parts
550247600120	ASSY. DELIVERY LINE - FUEL TANK TO SEDIME	TATA spare parts
550247600129	ASSY DELIVERY LINE (FUEL TANK TO SEDIMTR)	TATA spare parts
550247600130	ASSY DELIVERY LINE (SEDIMNTR TO FIREWAL)	TATA spare parts
550247600131	ASSY DELIVERY LINE (FIRWL TO PRMG PUMP)	TATA spare parts
550247600132	ASSY DELIVERY LINE (FUEL FILTER TO FIP)	TATA spare parts
550247600133	ASSY RETURN LINE (FIP TO FIREWALL)	TATA spare parts
550247600134	ASSY RETURN LINE (FIREWALL TO FUEL TANK)	TATA spare parts
550247600135	ASSY RETURN LINE (FIP TO T-CONNECTOR)	TATA spare parts
550247600138	FUEL SUCTION PIPE ASSY TANK TO FIREWALL	TATA spare parts
550247600139	DELIVERY PIPE ASSY FIREWALL TO PR FILTER	TATA spare parts
550247600140	DELIVERY PIPE ASSY PRE FILTER TO FILTER	TATA spare parts
550247600141	DELIVERY PIPE ASSY FILTER TO FIP	TATA spare parts
550247600142	RETURN PIPE ASSY FILTER TO FIREWALL	TATA spare parts
550247600143	RETURN PIPE ASSY FIP TO T-CONN	TATA spare parts
550247600144	RETURN PIPE ASSY FIREWALL TO TANK	TATA spare parts
550247600147	DELIVERY PIPE ASSY FUEL TANK TO SED	TATA spare parts
550247600148	DELIVERY PIPE ASSY SED TO FIREWALL	TATA spare parts
550247600149	RETURN PIPE ASSY FIREWALL TO FUEL TANK	TATA spare parts
550247600150	BRACKET ASSY FUEL PIPE CLAMP MTG	TATA spare parts
550247604201	PIPE CLAMP FOR DIA 4.8 4.8&16	TATA spare parts

550247604202	PIPE CLAMP FOR DIA 11 & 12	TATA spare parts
550247604203	PIPE CLAMP FOR DIA 8.0 & 11.0	TATA spare parts
550247604204	CLIP ROD COMMON FOR ALL CLIPS	TATA spare parts
550247604205	CLAMP (FUEL LINE)	TATA spare parts
550247604206	SPECIAL CLAMP (PIPE OD 11X11 & 4.75 OD)	TATA spare parts
550247604207	CLAMP FUEL PIPE	TATA spare parts
550247605801	RUBBER HOSE	TATA spare parts
550247605802	BREATHER HOSE	TATA spare parts
550247605807	BREATHER HOSE	TATA spare parts
550247605808	FUEL FILLER HOSE	TATA spare parts
550249100104	ASSY SILENCER COMPLETE (FOR 3150WB)	TATA spare parts
550249100110	ASSY SILENCER COMP.31WB(M/S S.M.AUTO)	TATA spare parts
550249100111	ASSY SILENCER COMP.28WB	TATA spare parts
550249200101	ASSY EXHAUST PIPE FRONT	TATA spare parts
550249200102	ASSY EXHAUST PIPE INTERMEDIATE	TATA spare parts
550249200105	ASSY. EXHAUST PIPE FRONT.	TATA spare parts
550249200114	PIPE ASSY INTERMEDIATE	TATA spare parts
550249200116	PIPE ASSY TAIL	TATA spare parts
550249200119	ASSY EXHAUST INTERMEDIATE PIPE	TATA spare parts
550249200128	PIPE ASSY FRONT	TATA spare parts
550249200130	PIPE ASSY	TATA spare parts
550249200132	PIPE ASSY TAIL	TATA spare parts
550249200137	PIPE ASSY FRONT	TATA spare parts
550254100102	ASSY BATT HOLDING CLAMP	TATA spare parts
550254100105	ASSY BATT CABLE +VE XENON 3.0L AIRBAG-IS	TATA spare parts
550254100108	ASSY HEAT SHIELD FOR XENON EURO-V	TATA spare parts
550254100110	2P BAT MTG MEGA FUSE BOX BASE125A 500A	TATA spare parts
550254100113	ASSEMBLY BATTERY CABLE POSITIVE	TATA spare parts
550254109901	2P BAT MTG MAXI FUSE BOX COVER	TATA spare parts
550254109902	BAT MTG MAXI FUSE BOX BASE	TATA spare parts
550254200105	ASSY RELAY AND W/W CTRL SUPPORT	TATA spare parts
550254200106	ASSY BCM MTG BKT	TATA spare parts
550254200107	ASSY TIK TOK RELAY & BUZZER SUPPORT	TATA spare parts
550254200109	ELECT INST CLUSTER XENON E-V & E-II SA	TATA spare parts
550254200111	ELECT INST CLUSTER XENON 3.0L AIRBAG SPE	TATA spare parts
550254200146	INSTRUMENT CLUSTER ASSY	TATA spare parts
550254200147	INSTRUMENT CLUSTER ASSY	TATA spare parts
550254201601	TANK UNIT 70L EURO-V WITH AIR BAG	TATA spare parts
550254208216	REVERSE SWITCH CONNECTOR PARKING BRACKET	TATA spare parts
550254209902	ECU (TRANSFER CASE)4X4 TELCOLINE	TATA spare parts
550254209902AE	ECU (TRANSFER CASE)4X4-XEN DC/SC	TATA spare parts
550254209904	BODY CNTRL MODUL XENON E4 W/AIRBAG	TATA spare parts
550254209905	DISPLAY PANEL EURO-V WITH AIR BAG	TATA spare parts
550254209908	AIR BAG ECU XENON-V WITH AIR BAG	TATA spare parts
550254209909	INST CLUSTER XENON E-V	TATA spare parts
550254209910	RSU XENON E-V WITH AIR BAG	TATA spare parts
550254209914	ELECT.INST.1:0.90 XENON E-V & E-II FOR 4	TATA spare parts

550254209915	DISPLAY PANEL WITH ESP & TPMS	TATA spare parts
550254209918	BODY CONTROL MODULE H4	TATA spare parts
550254409901	FRONT ROOF LAMP EURO-V WITH AIRBAG	TATA spare parts
550254409902	REAR ROOF LAMP XENON E-V WITH AIR BAG	TATA spare parts
550254500101	ASSY. FUSE & RELAY BOX MTG BKT	TATA spare parts
550254500103	ASSY COMBI SW LHD MID-END	TATA spare parts
550254500105	ASSY COMBI SW W INT & W/O CRUS CTRL W HO	TATA spare parts
550254500106	FACIA SW PACK (HLLS 4X4 DUMMY & DUMMY)	TATA spare parts
550254500109	ASSY COMBI SW LHD MID-END	TATA spare parts
550254500110	ASSY COMBI SW RHD MID-END	TATA spare parts
550254500117	SWITCH FASCIA-HLLS HDC ESP OFF TOD	TATA spare parts
550254500118	SWITCH ASSY FASCIA ESP	TATA spare parts
550254500119	SWITCH FASCIA-HLLS HDC ESP OFF	TATA spare parts
550254500122	ASSY 30 POLE FUSE BOX HOLD CLAMP BOTTOM	TATA spare parts
550254500123	ASSY 30 POLE FUSE BOX HOLD CLAMP TOP LHD	TATA spare parts
550254500124	ASSY 30 POLE FUSE BOX HOLD CLAMP BOTTOM	TATA spare parts
550254500125	ASSY 30 POLE FUSE BOX HOLD CLAMP TOP RHD	TATA spare parts
550254500134	COMBI SWITCH ASSY	TATA spare parts
550254504901	HILL DECENT CONTROL SWITCH	TATA spare parts
550254504902	TORQUE ON DEMAND SWITCH	TATA spare parts
550254506306	CARRIER PLATE	TATA spare parts
550254506317	BEZEL WITH PAD	TATA spare parts
550254506318	SWITCH FASCIA BEZEL (HLL D D 4X4)	TATA spare parts
550254506331	CARRIER PLATE SWITCH	TATA spare parts
550254508205	FUSE BOX 30 POLE MTG SUPPORT LOWER LHD	TATA spare parts
550254508206	FUSE BOX 30 POLE MTG SUPPORT UPPER LHD	TATA spare parts
550254509903	HEAD LAMP ROTARY SW WITH REAR FOG XENON	TATA spare parts
550254509904	WIPER SWITCH XENON EURO V RHD	TATA spare parts
550254509906	LOW END LIGHT SWITCH XENON EURO V RHD	TATA spare parts
550254509907	XENON EURO V WIPER SWITCH LHD	TATA spare parts
550254509909	XENON EURO V LIGHT SWITCH LOW END LHD	TATA spare parts
550254509910	FUSE BOX STICKER (30 FUSES)	TATA spare parts
550254509913	WINDOW WINDING SW RR DOOR RH	TATA spare parts
550254509914	WINDOW WINDING SW RR DOOR LH	TATA spare parts
550254509916	FUSE BOX STICKER-3.0L AIRBAG(30 FUSES)	TATA spare parts
550254509918	REVERSE LIGHT SWITCH	TATA spare parts
550254509920	SWITCH ESP OFF	TATA spare parts
550254510101	POUCH ASSY SPARE FUSE	TATA spare parts
550254600101	W/H.TAIL & 4X4 TRANSFER CASE	TATA spare parts
550254600106	WH FRONT LHD RHD	TATA spare parts
550254600109	WH CABIN RHD 4X2 4X4 [MS MSSL]	TATA spare parts
550254600110	WH DRIVER DOOR RHD	TATA spare parts
550254600111	WH DRIVER DOOR RHD	TATA spare parts
550254600112	WH DRIVER DOOR RHD	TATA spare parts
550254600115	WIRING HARNESS CO-DRIVER DOOR	TATA spare parts
550254600115AE	WIRNG HRNSS CODRVER DR-XEN DC/SC	TATA spare parts
550254600118	WIRING HARNESS REAR DOOR	TATA spare parts

550254600121	WH CABIN LHD 4X2 4X4	TATA spare parts
550254600121AE	WIRING HRNSS CABIN -XENON DC/SC	TATA spare parts
550254600124	WIRING HARNESS DRIVER DOOR LHD	TATA spare parts
550254600124AE	WIRING HRNSS DRIVR DR-XEN DC/SC	TATA spare parts
550254600126	WH DRIVER DOOR RHD	TATA spare parts
550254600131	PIGTAIL BREAK FUILD BOTTLE	TATA spare parts
550254600134	WH CABIN WITH ABS LHD 4X2 4X4	TATA spare parts
550254600135	W/H FRONT LHD/RHD 2.2L DICOR	TATA spare parts
550254600136	W/H FRONT LHD/RHD 2.2L DICOR	TATA spare parts
550254600137	W/H FRONT LHD/RHD 2.2L DICOR	TATA spare parts
550254600151	ASSY 24 POLE INTERFACING CONN SUPPORT	TATA spare parts
550254600156	ASSY SUPPORT BKT FOR E-V LH INTER CONNEC	TATA spare parts
550254600159	ASSY SUPPORT BKT 3.0L LHD AB INTERCONN.	TATA spare parts
550254600167	BRACKET ASSY RELAY BKT MTG	TATA spare parts
550254600175	BRACKET ASSY INLINE CONNECTOR MTG	TATA spare parts
550254600176	BRACKET ASSY RELAY BASE & RELAY MTG	TATA spare parts
550254600180	BRACKET ASSY FUSE & RELAY BASE MTG	TATA spare parts
550254600182	WIRING HARNESS CABIN	TATA spare parts
550254600183	WIRING HARNESS FRONT	TATA spare parts
550254600184	WIRING HARNESS TAIL	TATA spare parts
550254600198	WIRING HARNESS TAIL	TATA spare parts
550254600204	WIRING HARNESS-TAIL BS6	TATA spare parts
550254601601	W/H TAIL & TRANSFER CASE 3.0L	TATA spare parts
550254601602	WIRING HARNESS FRONT 2.2L	TATA spare parts
550254601603	WIRING HARNESS CABIN 2.2L RHD	TATA spare parts
550254601604	WIRING HARNESS CABIN 2.2L LHD	TATA spare parts
550254601605	W/H. TAIL & 4X4 TRANSFER CASE	TATA spare parts
550254601609	WH DRIVER DOOR RHD	TATA spare parts
550254601616	W/H FRONT LHD/RHD 2.2L DICOR	TATA spare parts
550254601618	WH TAIL & TRANSFER CASE WITH ABS 4X4	TATA spare parts
550254601628	WH CABIN RHD WITH ABS 4X2 4X4	TATA spare parts
550254601635	W/H TAIL XENON 2.2L (4X2/4X4) EURO-V	TATA spare parts
550254601636	W/H HEAD LAMP RH EURO-V [AIRBAG]	TATA spare parts
550254601637	W/H CABIN XENON 2.2L EURO-V LHD [AIRBAG]	TATA spare parts
550254601638	W/H EMS XENON 2.2L EURO-V	TATA spare parts
550254601665	WIRING HARNESS CABIN	TATA spare parts
550254601694	CLAMP CABLE SUPPORT	TATA spare parts
550254601696	WIRING HARNESS TAIL	TATA spare parts
550254601697	WIRING HARNESS CABIN	TATA spare parts
550254601698	WIRING HARNESS FRONT	TATA spare parts
550254601699	WIRING HARNESS CABIN	TATA spare parts
550254603302	BRACKET INLINE CONNECTOR MTG	TATA spare parts
550254603309	BRACKET INLINE CONNECTOR MTG	TATA spare parts
550254604303	SUPPORT BKT FOR ALTERNATOR CABLE	TATA spare parts
550254604304	SUPPORT CLAMP FOR BATTERY CABLE	TATA spare parts
550254604305	SUPPORT BRACKET FOR BATTERY CABLE	TATA spare parts
550254608203	DOOR CONN SUPPORT CO-DRIVER LHD	TATA spare parts

550254608204	DOOR CONN SUPPORT CO DRIVER RHD	TATA spare parts
550254608205	WH EMS SUPPORT NEAR DPS	TATA spare parts
550254608206	SUPPORT BKT FOR E-V LH INTERCONNECTION	TATA spare parts
550254610102	WH CABIN RHD WITH ABS 4X2 4X4	TATA spare parts
550254610107	WH TAIL EURO-V	TATA spare parts
550254610108	W/H HEAD LAMP RH EURO-V	TATA spare parts
550254610109	W/H CABIN	TATA spare parts
550254610115	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
550254610142	WIRING HARNESS TAIL	TATA spare parts
550254620101	WH CABIN 2.2L RHD 4X2 4X4 M1	TATA spare parts
550254620102	WH CABIN RHD WITH ABS 4X2 4X4	TATA spare parts
550254620106	W/H CABIN RHD WITH ABS 4X2 4X4 M1	TATA spare parts
550254620107	WH TAIL EURO-V	TATA spare parts
550254620108	W/H HEAD LAMP RH EURO-V	TATA spare parts
550254620109	W/H CABIN	TATA spare parts
550254620110	W/H EMS	TATA spare parts
550254620111	W/H FRONT ESP	TATA spare parts
550254620112	W/H CABIN	TATA spare parts
550254620114	W/H TAIL 4X2	TATA spare parts
550254620116	W/H EMS 2.2L E-II	TATA spare parts
550254620117	WH CABIN XENON 3L 4X4 RHD W\AIRBAG	TATA spare parts
550254620118	WH FRONT XENON 3L W\AIRBAG	TATA spare parts
550254620119	WH TAIL XENON 3L 4X4 W\AIRBAG	TATA spare parts
550254620121	W/H TAIL 3.0L AIRBAG 4X2	TATA spare parts
550254620126	W/H TAIL	TATA spare parts
550254620128	W/ H CABIN	TATA spare parts
550254620129	WIRING HARNESS TAIL	TATA spare parts
550254620130	W/H TAIL	TATA spare parts
550254620131	W/H CABIN	TATA spare parts
550254620132	W/H FRONT	TATA spare parts
550254620133	W/H ROOF	TATA spare parts
550254620134	PIGTAIL MAP READING LAMP	TATA spare parts
550254620136	WIRING HARNESS FRONT	TATA spare parts
550254620138	WIRING HARNESS TAIL	TATA spare parts
550254620146	WIRING HARNESS TAIL	TATA spare parts
550254620150	"WIRING HARNESS,TAIL"	TATA spare parts
550254620151	WIRING HARNESS TAIL	TATA spare parts
550254620152	WIRING HARNESS CABIN	TATA spare parts
550254630102	WH CABIN RHD WITH ABS 4X2 4X4	TATA spare parts
550254630107	WH TAIL EURO-V	TATA spare parts
550254630108	W/H HEAD LAMP RH EURO-V	TATA spare parts
550254630109	W/H CABIN	TATA spare parts
550254640110	W/H EMS XENON 2.2L EURO-V	TATA spare parts
550254640116	W/H EMS XENON 2.2L EURO-II	TATA spare parts
550254709901	BODY CONTROL MODULE XENON AT	TATA spare parts
550254709902	TPMS SENSOR	TATA spare parts
550254800102	RECEIVER TYRE PRESSURE MONITORING SYSTEM	TATA spare parts

550254800103	AIR BAG CONTROL UNIT	TATA spare parts
550254806301	BRACKET TPMS RECEIVER/ECU MTG	TATA spare parts
550254904901	PCB FLOOR CONSOLE	TATA spare parts
5502600003L40IQ	ASSEMBLY BODY FITTED_DEN_FORST_GN	TATA spare parts
550260000132BF	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
550260000132D3	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
550260000132DU	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
550260000132000000	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
550260000132FG	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
550260000133	ASSY BODY SHELL COMPLETE RHD 2.2 LTR FOR	TATA spare parts
550260000140BF	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
550260000140D3	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
550260000140DU	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
550260000140FG	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
550260000145ZY	ASSY BODY COMPLETE LHD	TATA spare parts
550260000155ZY	ASSY BODY CAB COMPLETE	TATA spare parts
550260000156BF	ASSY BODY SHELL PAINTED A.WHITE LHD 2.2	TATA spare parts
550260000156D3	ASSY BODY SHELL COMP PAINTED LHD 2.2 L E	TATA spare parts
550260000156DU	ASSY BODY SHELL COMP PAINTED LHD 2.2 L E	TATA spare parts
550260000156000000	ASSY BODY SHELL COMP PAINTED LHD 2.2 L E	TATA spare parts
550260000156FG	ASSY BODY SHELL COMP PAINTED LHD 2.2 L E	TATA spare parts
550260000161BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED	TATA spare parts
550260000165IQ	DEN_FORST_GN-ASSYB/SCOMP.PAINTEDLHD2	TATA spare parts
550260000172ZY	CLRPRT_ASY_1-BODY ASSY	TATA spare parts
550260000173BF	ASSY BODY SHELL COMPLETE PAINTED RHD 2.2	TATA spare parts
550260000173D3	ARCTIC_SILVR- ASSY BODY SHELL PAINTED	TATA spare parts
550260000173DU	QUARTZ_BLACK- ASSY BODY SHELL PAINTED	TATA spare parts
550260000173000000	ARIZONA_BLUE- ASSY BODY SHELL PAINTED	TATA spare parts
550260000173FG	MINERAL_RED -ASSY -BODY SHELL PAINTED	TATA spare parts
550260000177BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED	TATA spare parts
550261000102	ASSY SUBSTRUCTURE WITH FLOORS COMPLT RHD	TATA spare parts
550261000106	FLOOR ASSY WITH SUBSTRUCTURE	TATA spare parts
550262600104	DASH PANEL ASSY WITH SUPPORT PANEL	TATA spare parts
550267800101	ASSY.SLIDING WINDOW	TATA spare parts
550268500102	KIT FIT OF MOULDED CARPET RHD EBONY BLAC	TATA spare parts
550268500103	CARPET ASSY FLOOR	TATA spare parts
550268506301	MOULDED CARPET LHD EBONY BLACK AIRBAG	TATA spare parts
550268506303	SEAT MOUNTING COVER FOR CARPET(EBONY BLA	TATA spare parts
550268506305	INSULATION FIREWALL ENGINE SIDE RHD(EURO	TATA spare parts
550268506307	MOULDED CARPET FLOOR	TATA spare parts
550268506308	MOULDED CARPET FLOOR	TATA spare parts
550268506310	INSULATION FIREWALL CAB SIDE	TATA spare parts
550268506312	CARPET WITH INSULATION FRONT FLOOR	TATA spare parts
550268900102	ASSEMBLY NACELLE TOP LHD D380 COLLAPS ST	TATA spare parts
550268900106	ASSY CENTER CONSOLE FOR AIRBAGS	TATA spare parts
550268900107	ASSY DASHBOARD LHD FOR AIRBAGS	TATA spare parts
550268900113	ASSY DASHBOARD RHD FOR AIRBAGS	TATA spare parts



550268900114	ASSY STEERING COLUMN COVER LHD FOR AIRBA	TATA spare parts
550268900117	ASSY DASHBOARD SIDE COVER LH RHD AIRBAGS	TATA spare parts
550268900118	ASSY DASHBOARD SIDE COVER RH RHD AIRBAGS	TATA spare parts
550268900119	ASSY PAB LHD FOR XENON AIRBAG	TATA spare parts
550268900121	ASSY PAB RHD TAKATA FOR XENON AIRBAG	TATA spare parts
550268900132	ASSY LID GLOVE BOX RHD FOR AIRBAGS	TATA spare parts
550268900133	ASSY STEERING COLUMN COVER RHD FOR AIRBA	TATA spare parts
550268900135	ASSEMBLY NACELLE TOP D380 RHD COLLAPS ST	TATA spare parts
550268900138	DASHBOARD ASSY LHD NON-AIRBAGS	TATA spare parts
550268900139	ASSY DASHBOARD RHD NON-AIRBAGS	TATA spare parts
550268900144	KIT DIS ADAPTER AIRBAG	TATA spare parts
550268900155	ASSY DIAGNOSTIC CONNECTOR FIXING MTG BRA	TATA spare parts
550268900156	ASSY DASHBOARD SIDE COVER LH LHD AIRBAGS	TATA spare parts
550268900157	ASSY DASHBOARD SIDE COVER RH LHD AIRBAGS	TATA spare parts
550268900159	ASSY STG WHEEL D380 COLAPS W/O ABAG LEAT	TATA spare parts
550268900161	ASSY STG WHEEL LEATHER WRAP PAINT & W/O	TATA spare parts
550268900162	ASSY HORN PAD WITH DAB PAINTED	TATA spare parts
550268900164	ASSY HORN PAD W/O DAB UNPAINTED TAKATA	TATA spare parts
550268900175	ASH TRAY EBONY BLACK WITH SATIN SILVER L	TATA spare parts
550268900179	BEZEL ASSY FLOOR CONSOLE GEAR SHIFTER	TATA spare parts
550268903304	PAB COVER SUPPORT BKT LH	TATA spare parts
550268906301	NACELLE BOTTOM D380 LHD COLLAPS AIRBAGS	TATA spare parts
550268906314	DIS FINISHER FOR AIRBAGS	TATA spare parts
550268906319	NACELLE BOTTOM RHD D380 COLLAPS STG EBON	TATA spare parts
550268906320	GLOVE BOX CAP PAB FIXING FOR AIRBAGS EBO	TATA spare parts
550268906323	GLOVE BOX ADD-ON RHD FOR AIRBAGS	TATA spare parts
550268906324	FLOOR CONSOLE BUCKET TYPE HIGH END EBONY	TATA spare parts
550268906326	TOP UTILITY BIN RHD EBONY BLACK FOR NON-	TATA spare parts
550268906328	DASHBOARD RETENTION CLIP FEMALE	TATA spare parts
550268906336	BINNACLE INSTRUMENT CLUSTER FRONT RHD EB	TATA spare parts
550268906337	BINNACLE INSTRUMENT CLUSTER FRONT LHD EB	TATA spare parts
550268906338	BINNACLE INSTRUMENT CLUSTER REAR RHD EBO	TATA spare parts
550268906501	J-METAL CLIP FOR TOP UTILITY BIN	TATA spare parts
550268910102	HORN PAD ASSY WITH AIRBAG	TATA spare parts
550268910107	DASHBOARD ASSY WITH DUCT	TATA spare parts
550269200101	ASSY TRIM A PILLAR LOWER LH EBONY BLACK	TATA spare parts
550269200102	ASSY TRIM A PILLAR LOWER RH EBONY BLACK	TATA spare parts
550269200103	ASSY TRIM A PILLAR UPPER LH LINEN (LIGHT	TATA spare parts
550269200104	ASSY TRIM A PILLAR UPPER RH LINEN (LIGHT	TATA spare parts
550269200105	ASSY TRIM B PILLAR UPPER LH LINEN (LIGHT	TATA spare parts
550269200106	ASSY TRIM B PILLAR UPPER RH LINEN (LIGHT	TATA spare parts
550269200107	ASSY TRIM C PILLAR UPPER LH LINEN (LIGHT	TATA spare parts
550269200108	ASSY TRIM C PILLAR UPPER RH LINEN (LIGHT	TATA spare parts
550269200109	ASSY TRIM C PILLAR LOWER LH EBONY BLACK	TATA spare parts
550269200110	ASSY TRIM C PILLAR LOWER RH EBONY BLACK	TATA spare parts
550269200111	ASSY TRIM REAR WALL CROSS MEMBER EBONY B	TATA spare parts
550269206312	SCUFF PLATE FRONT LH EBONY BLACK AIRBAG	TATA spare parts

550269206313	SCUFF PLATE FRONT RH EBONY BLACK AIRBAG	TATA spare parts
550269206314	SCUFF PLATE REAR LH EBONY BLACK AIRBAG	TATA spare parts
550269206315	SCUFF PLATE REAR RH EBONY BLACK AIRBAG	TATA spare parts
550269206316	CAP(BONNET OPENING LEVER) EBONY BLACK AI	TATA spare parts
550269206317	CAP SCUFF PLATE EBONY BLACK AIRBAG	TATA spare parts
550269500101	ASSY SUNVISOR LH RHD LINEN (LIGHT GRAY)	TATA spare parts
550269500102	ASSY SUNVISOR RH RHD LINEN (LIGHT GRAY)	TATA spare parts
550269500104	ASSY GRAB HANDLE COLLAPSIBLE LINEN (LIGH	TATA spare parts
550269500106	ASSY SUNVISOR LH LHD LINEN (LIGHT GRAY)	TATA spare parts
550269500107	ASSY SUNVISOR RH LHD LINEN (LIGHT GRAY)	TATA spare parts
550269500109	ASSY ROOF LINING 4 DOOR LINEN (LIGHT GRA	TATA spare parts
550269506302	PLASTIC BUTTON GRAB HANDLE LINEN (LIGHT	TATA spare parts
550269506303	ROOF LINING BUTTON LINEN (LIGHT GRAY) FO	TATA spare parts
550270000112IQ	DEN_FORST_GN-LOAD BODY ASSY	TATA spare parts
550270500108	ASSY TAIL GATE MIDDLE.	TATA spare parts
550270500109	ASSY GUARD SIDE LH	TATA spare parts
550270500111	ASSY GUARD SIDE RH	TATA spare parts
550270500112	ASSY.HOLDER FIRE EXTINGUISHER	TATA spare parts
550270500128IQ	ASSY LOAD BODY PAINTED DEN_FORST_GN	TATA spare parts
550270500129	ASSEMBLY CANOPY COVER-FABRIC	TATA spare parts
550270500130	KIT CANOPY TUBULAR STRUC & CAGES PAINTED	TATA spare parts
550270508262	PLATE CANOPY ATTACHEMENT	TATA spare parts
550270508265	PLATE CANOPY ATTACHEMENT COMMON	TATA spare parts
550270990101	ASSY.CARPET LOADBODY	TATA spare parts
550272300103	ASSY LOCK KIT LHD COLLAPSIBLE STG FOR AI	TATA spare parts
550272300104	ASSY LOCK KIT RHD COLLAPSIBLE STG FOR AI	TATA spare parts
550272300105	ASSY LOCK KIT RHD COLLAPSIBLE STG FOR AI	TATA spare parts
550272300106	ASSY LOCK KIT LHD AB EII COLLAP STG	TATA spare parts
550272306301	BEZEL FOR DOOR INNER HANDLE FRONT LH EBO	TATA spare parts
550272306302	BEZEL FOR DOOR INNER HANDLE FRONT RH EBO	TATA spare parts
550272700101	ASSY FR DR ARMREST w/o w/w s/w CUTOUT R	TATA spare parts
550272700102	ASSY FR DR ARMREST WITH W/W S/W CUTOUT R	TATA spare parts
550272700103	ASSY FRONT DOOR TRIM RHD LH EBONY BLACK	TATA spare parts
550272700104	ASSY FRONT DOOR TRIM RHD RH EBONY BLACK	TATA spare parts
550272700107	ASSY FRT DR TRM LHD LH EBONY BLACK AIRBG	TATA spare parts
550272700108	ASSY FRT DR TRM LHD RH EBONY BLACK AIRBG	TATA spare parts
550272700109	ASSY FR DR ARMREST WITH W/W S/W CUTOUT L	TATA spare parts
550272700110	ASSY FR DR ARMREST W/O W/W S/W CUTOUT LH	TATA spare parts
550272706302	FRONT DOOR ARMREST FOR SINGLE W/W S/W RH	TATA spare parts
550272706303	FRONT DOOR ARMREST RHD LH W/O W/W S/W C	TATA spare parts
550272706311	MATT ARM REST FRONT DOOR LH EBONY BLACK	TATA spare parts
550272706312	MATT ARM REST FRONT DOOR RH EBONY BLACK	TATA spare parts
550272706314	DUMMY BEZEL MIRROR SWITCH EBONY BLACK AI	TATA spare parts
550272706315	CLOSING CAP F/D UPPER LH EBONY BLACK AIR	TATA spare parts
550272706316	CLOSING CAP F/D UPPER RH EBONY BLACK AIR	TATA spare parts
550272706317	CLOSING CAP F/D LOWER LH EBONY BLACK AIR	TATA spare parts
550272706318	CLOSING CAP F/D LOWER RH EBONY BLACK AIR	TATA spare parts

550272706323	POP-UP KNOB FRONT DOOR EBONY BLACK	TATA spare parts
550273306301	BEZEL FOR REAR DOOR INNER HANDLE LH EBON	TATA spare parts
550273306302	BEZEL FOR REAR DOOR INNER HANDLE RH EBON	TATA spare parts
550273700101	ASSY REAR DOOR TRIM RHD LH EBONY BLACK A	TATA spare parts
550273700102	ASSY REAR DOOR TRIM RHD RH EBONY BLACK A	TATA spare parts
550273706309	CLOSING CAP REAR DOOR UPPER LH EBONY BLA	TATA spare parts
550273706310	CLOSING CAP REAR DOOR UPPER RH EBONY BLA	TATA spare parts
550273706311	CLOSING CAP REAR DOOR LOWER LH EBONY BLA	TATA spare parts
550273706312	CLOSING CAP REAR DOOR LOWER RH EBONY BLA	TATA spare parts
550273706313	BEZEL LH REAR DOOR TRIM EBONY BLACK	TATA spare parts
550273706314	BEZEL RH REAR DOOR TRIM EBONY BLACK	TATA spare parts
550281100106	ASSY ORVM INNER COVER ELECTRICAL LH EBON	TATA spare parts
550281100107	ASSY ORVM INNER COVER ELECTRICAL RH EBON	TATA spare parts
550281106305	COVER FOR FENDER INNER	TATA spare parts
550282400104	ASSY WASHER BOTTLE WITH PUMP	TATA spare parts
550282400105	ASSY PIPES NOZZLE AND T JOINT	TATA spare parts
550282400106	WIND SHIELD WASHER KIT 1.5L	TATA spare parts
550282400107	ASSY WASHAER WATER FILLING CAP SUPPORT	TATA spare parts
550282400110	KIT ROTARY LINK SEAL SPRING WASHER AND N	TATA spare parts
550282400111	ASSY WASHER BOTTLE FILLER NECK SUPPORT	TATA spare parts
550282406308	CLAMP	TATA spare parts
550282406309	WATER VENT TUBE	TATA spare parts
550282406901	PIPE T JOINT TO NOZZLE	TATA spare parts
550282406902	PIPE MUMP TO T JOINT	TATA spare parts
550282407502	SEAL	TATA spare parts
550282408203	WASHER BOTTLE MTG BRACKET	TATA spare parts
550282408205	FILLER HOSE CLAMP BRACKET	TATA spare parts
550282409905	ROTARY LINK ASSY	TATA spare parts
550282903301	BRACKET WINDSHIELD WASHER TANK MTG	TATA spare parts
550293000104	ASSY SINGLE SEATER JUMP SEAT XENON	TATA spare parts
550293000105	REAR SEAT ASSY	TATA spare parts
550340100201	ASSY.AL ALLOYWHEELRIM(5.5JX16)-M/S.LENSO	TATA spare parts
550340109901	TYRE 215/75R16C 113/111S 8PR UE168N-MAXX	TATA spare parts
550361000101	KIT ASSY FLOOR - THAILAND CKD	TATA spare parts
550515100104	STARTER MOTOR WITH THERMAL CUT OFF	TATA spare parts
550515103101	NEEDLE BEARING	TATA spare parts
550515103201	HEX SCREW (STAY BOLT)	TATA spare parts
550515103401	BEARING BUSH KIT	TATA spare parts
550515103801	FIXING BRKT ASSY	TATA spare parts
550515103802	C.E.BRKT ASSY	TATA spare parts
550515104101	SOLENOID ASSY	TATA spare parts
550515106301	ENGAGING LEVER	TATA spare parts
550515106302	COVER PLATE-INSITU MOULDING	TATA spare parts
550515107801	OIL SEAL	TATA spare parts
550515108001	SCREW BS6	TATA spare parts
550515109201	WASHER	TATA spare parts
550515109902	STARTER MOTOR BS1/2/3/4/6	TATA spare parts

550515109907	DRIVE AND FLANGE	TATA spare parts
550515109908	COUNTER SUNK SCREW(M5)	TATA spare parts
550515109909	RETAINER	TATA spare parts
550515109910	STOP RING	TATA spare parts
550515109911	OVER RUNNING CLUTCH	TATA spare parts
550515109912	FORK LEVER	TATA spare parts
550515109913	BEARING PEDESTAL	TATA spare parts
550515109914	SEAL	TATA spare parts
550515109915	SEAL RING	TATA spare parts
550515109917	¿EPICYDODOL GEAR TRAIN	TATA spare parts
550515109918	ARMATURE	TATA spare parts
550515109919	STARTER FRAME	TATA spare parts
550515109921	COMMUTATOR END SHIELD	TATA spare parts
550515109922	SHIM	TATA spare parts
550515109923	REATINING WASHER	TATA spare parts
550515109924	CLOSER CAP(STEEL)	TATA spare parts
550515109925	OVAL¿HEAD¿SCREW	TATA spare parts
550515109927	FLANGE NUT	TATA spare parts
550515109928	SPRING LOCK WASHER	TATA spare parts
550515109929	HEX NUT M8	TATA spare parts
550515109930	SPRING LOCK WASHER (M5)	TATA spare parts
550515109931	HEX NUT (M5)	TATA spare parts
550515109932	SPRING LOCK WASHER (M6)	TATA spare parts
550515109933	HEX NUT (M5)	TATA spare parts
550515109934	SEALING CAP	TATA spare parts
550515109935	COVER DISC	TATA spare parts
550515109936	SOLENOID SWITCH	TATA spare parts
550515109937	BRUSH HOLDER	TATA spare parts
550515109938	CAPSULE(STEEL)	TATA spare parts
550515109939	FLANGE NUT	TATA spare parts
550515109940	EARTH TERMINAL	TATA spare parts
550515109942	FIXING BRACKET ASSY	TATA spare parts
550515109943	ENGAGED LEVER ASSY AND SUPPORT MOULD	TATA spare parts
550515109944	DRIVE ASSY	TATA spare parts
550515109945	BRACKET ASSY STARTER MOTOR MTG	TATA spare parts
550515109946	OUTPUT SHAFT ASSY	TATA spare parts
550515109948	ARMATURE ASSY	TATA spare parts
550515109951	CE BRACKET	TATA spare parts
550515109952	RELAY ASSY	TATA spare parts
550515109971	SOLENOIDSWITCHASSY	TATA spare parts
550515109983	DRIVEASSY	TATA spare parts
550515109984	ANNULUS HOUSING ASSY	TATA spare parts
550515109985	OUTPUT SHAFTASSY	TATA spare parts
550515109987	ANNULUS	TATA spare parts
550515109988	PLANETARYGEARASSY	TATA spare parts
550515109989	NEEDLE BEARING	TATA spare parts
550515109990	ARMATURE ASSY	TATA spare parts

550515109991	BRUSH GEAR ASSY	TATA spare parts
550515109992	THERMALCUTOUTASSY	TATA spare parts
550515109993	FASTENERSASSEMBLYKIT	TATA spare parts
550515109994	DRIVEASSEMBLYKIT	TATA spare parts
550515109995	PACKINGASSEMBLYKIT	TATA spare parts
550515149905	STARTER MOTOR 24V 3.5KW	TATA spare parts
550515149906	STARTER MOTOR 24V 2.7KW 3L ENG. BS3/4	TATA spare parts
550515409905	ALTERNATOR 12V 90A FOR 3L ENG	TATA spare parts
550515409923	PULLEY	TATA spare parts
550515409924	DRIVE END SHIELD ASSY	TATA spare parts
550515409925	ROTOR ASSY	TATA spare parts
550515409926	STATOR	TATA spare parts
550515409927	RECTIFIER	TATA spare parts
550515409928	REGULATOR	TATA spare parts
550515409929	FLANGE NUT	TATA spare parts
550515409932	ROTOR ASSY BS6	TATA spare parts
550515449913	ALTERNATOR 24V 80A FOR 3L ENG	TATA spare parts
550515449918	DRIVE END SHIELD	TATA spare parts
550515449919	BEARING(ALTERNATOR¿12V¿90A)	TATA spare parts
550515449921	ROTOR	TATA spare parts
550515449922	RECTIFIER ASSEMBLY	TATA spare parts
550515449925	REGULATOR(ALTERNATOR 12V 90A)	TATA spare parts
550515449930	PULLEY	TATA spare parts
550515449931	PULLEY	TATA spare parts
550515449932	DRIVE END SHIELD ASSY ALTERNATOR	TATA spare parts
550515449933	RECTIFIER	TATA spare parts
550516204901	ECU - 12V BS6	TATA spare parts
550529000109	BRAKE PEDAL ASSY WITH MTG BRACKET BS6	TATA spare parts
550529100117	PUSH ROD ASSY WITH FORK¿BS6	TATA spare parts
550529100163	CLUTCH PEDAL ASSY WITH BUSH BS6	TATA spare parts
550529100192	NYLON PIPE ASSY BS6	TATA spare parts
550529200115	BRAKE PEDAL ASSY WITH BUSH BS6	TATA spare parts
550529200116	BRAKEPEDALASSYWITHBUSH BS6	TATA spare parts
550529300103	BUNDY TUBE ASSY CMC TO FIREWALL BS6	TATA spare parts
550529300104	BUNDY TUBE ASSY MIDDLE BS6	TATA spare parts
550529300107	BRACKET ASSY BOOSTER MTG	TATA spare parts
550529300108	PUSH ROD ASSY WITH FORK	TATA spare parts
550529300109	BUNDY TUBE ASSY CMC TO FIREWALL	TATA spare parts
550529300112	BUNDY TUBE ASSY LONG MEMBER	TATA spare parts
550529300113	BUNDY TUBE ASSY MIDDLE	TATA spare parts
550529300114	VACUUM BOOSTER WITH CMC ASSY BS6	TATA spare parts
550529300116	CLUTCH MASTER CYLINDER ASSY BS6	TATA spare parts
550529500106	BRACKET ASSY BRAKE CONTROL MTG BS6	TATA spare parts
550529500112	BRACKET ASSY CLUTCH CONTROL MTG BS6	TATA spare parts
550529500113	CLUTCH PEDAL ASSY WITH MTG BKT BS6	TATA spare parts
550529500116	BRACKET ASSY CLUTCH PEDAL MTG	TATA spare parts
550529500119	BRACKETASSYBRAKEPEDALMTG BS6	TATA spare parts

550529500120	BRACKET ASSY BRAKE LEVER MTG	TATA spare parts
550530100101	BRACKET ASSY ACCELEARTOR PEDAL MTG	TATA spare parts
550530100104	BRACKET ASSY ACCELERATOR PEDAL MTG	TATA spare parts
550530100105	BRACKET ASSY ACCELERATOR PEDAL	TATA spare parts
550531208209	CROSS MEMBER	TATA spare parts
550531400121	ALLIGATEDCROSSMEMBERASSY BS6	TATA spare parts
550531408228	REINFORCEMENT	TATA spare parts
550531408244	CLEAT	TATA spare parts
550531408267	REINFORCEMENT STEERING GEAR BOX MTG RH	TATA spare parts
550531408268	REINFORCEMENT STEERING GEAR BOX MTG LH	TATA spare parts
550531408284	BRACKET REINFORCEMENT RH	TATA spare parts
550531408285	BRACKET REINFORCEMENT LH	TATA spare parts
550532103201	CENTRE BOLT M12X1.75 GR-10.9	TATA spare parts
550532103202	CLAMP BOLT M8X1.25	TATA spare parts
550532103502	BOSS	TATA spare parts
550532103701	GUIDE PLATE (ASSY.FRONT SPRING MTG.)	TATA spare parts
550532107401	RIVET DIA 10 BS6	TATA spare parts
550532108301	CENTRE PAD (ASSY.LEAF SPRING)	TATA spare parts
550532200105	BUMP STOPPER ASSY FRONT	TATA spare parts
550532300110	SHOCK ABSORBER BKT ASSY FRT.	TATA spare parts
550532300112	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
550532305102	BRACKET-BOTTOM(FRONT SHOCK ABSORBER)	TATA spare parts
550532403711	BRACKET REAR SPRING HANGER FRONT	TATA spare parts
550532407163	SHACKLE PLATE	TATA spare parts
550532506501	HEX. NUT WITH COLLAR M16X1.5	TATA spare parts
550532900102	ASSY ANTIROLL BAR WITH BUSHES	TATA spare parts
550533105113	FRONT AXLE BEAM-NORMAL	TATA spare parts
550533109901	COTTER PIN	TATA spare parts
550533203405	5.5T/6.5T KING PIN BUSH ( BETA)	TATA spare parts
550533206502	HEX LOCK NUT	TATA spare parts
550533206715	5.5/6.5T KINGPIN (BETA)	TATA spare parts
550533208601	TONGUE SPACER WITH HOLES	TATA spare parts
550533209218	KING PIN SPACER 1 THK	TATA spare parts
550533209219	KING PIN SPACER 1.2THK.	TATA spare parts
550533209220	KING PIN SPACER 1.3 THK	TATA spare parts
550533209221	KING PIN SPACER 1.4 THK	TATA spare parts
550533209222	KING PIN SPACER 1.5 THK	TATA spare parts
550533209223	KING PIN SPACER 1.6 THK	TATA spare parts
550533209224	KING PIN SPACER 1.7 THK	TATA spare parts
550533209225	KING PIN SPACER 1.8 THK	TATA spare parts
550533209226	KING PIN SPACER 1.9 THK	TATA spare parts
550533209227	KING PIN SPACER 2THK	TATA spare parts
550533209228	KING PIN SPACER 2.1 THK	TATA spare parts
550533209230	KING PIN SPACER	TATA spare parts
550533209231	KING PIN SPACER	TATA spare parts
550533209232	KING PIN SPACER	TATA spare parts
550533209233	KING PIN SPACER	TATA spare parts

550533209234	KING PIN SPACER	TATA spare parts
550533209235	KING PIN SPACER	TATA spare parts
550533209236	KING PIN SPACER	TATA spare parts
550533209238	KING PIN SPACER	TATA spare parts
550533209239	KING PIN SPACER	TATA spare parts
550533800109	TIE ROD ASSY	TATA spare parts
550533800123	BALL JOINT ASSEMBLY-RH	TATA spare parts
550533805123	STEERING ARM	TATA spare parts
550533805124	TIE ROD ARM RH	TATA spare parts
550533805125	TIE ROD ARM LH	TATA spare parts
550533990102	REPAIR KIT DRAG LINK	TATA spare parts
550540300105	SPARE WHEEL CARRIER ASSY	TATA spare parts
550541300108	CENTER BEARING ASSY	TATA spare parts
550541308203	SLINGER BS6	TATA spare parts
550542990103	ASSLY. BRIDGE PIPE	TATA spare parts
550542990109	BRAKE SHOE	TATA spare parts
550542997704	PROTECTOR- FOR BUNDY TUBE	TATA spare parts
550543500102	VACUUM TANK ASSY WITH MTG BKT BS6	TATA spare parts
550543500108	VACUUM BOOSTER ASSY BS6	TATA spare parts
550543708201	SOLENOID VALVE MOUNTING BRACKET	TATA spare parts
550543800105	ASSY LCRV HOSE M/S BIL BS6	TATA spare parts
550543800169	BUNDY TUBE BOOSTER TO CABIN BKT BS6	TATA spare parts
550543800170	BUNDY TUBE TMC TO CABIN BKT BS6	TATA spare parts
550543800173	BUNDY TUBE CABIN TILT HOSE TO T-CONN BS6	TATA spare parts
550543800178	PIPE ASSY LCRV OUTLET TO RE HOSE BS6	TATA spare parts
550543803301	BRACKET FOR L.C.R.V. MTG	TATA spare parts
550543808204	BRACKET BRAKE HOSE MTG REAR BS6	TATA spare parts
550543808210	BRACKET HOSE MTG&BS6	TATA spare parts
550543808211	BRACKET HOSE MTG TILT CABIN BS6	TATA spare parts
550543810164	BUNDY TUBE CAB TILT HOSE TO ADAPTER BS6	TATA spare parts
550543810165	BUNDY TUBE ADAPTER TO FRONT HOSE LH BS6	TATA spare parts
550543810167	BUNDY TUBE T-CONN TO FRONT HOSE RH BS6	TATA spare parts
550543900180	NYLON PIPE ASSY BOOSTER NRV TO FRT ADAPT	TATA spare parts
550546100104	ASSLY.STEERING COLUMN FOR NRW CAB(RANE)	TATA spare parts
550546203711	POWER STEERING GEARBOX	TATA spare parts
550546600109	RESERVOIR MOUNT ASSY	TATA spare parts
550546600111	HOUSING COVER ASSEMBLY	TATA spare parts
550546600112	HOUSING ASSEMBLY	TATA spare parts
550546600113	BRACKET ASSY RESERVOIR MTG BS6	TATA spare parts
550546600114	BRACKET ASSY RESERVOIR MTG BS6	TATA spare parts
550546800144	HIGH PRESSURE LINE ASSY	TATA spare parts
550546800145	RETURN LINE ASSY	TATA spare parts
550547000105	FUEL TANK ASSY WITH BRACKET BS6	TATA spare parts
550547000106	FUEL TANK ASSY WITH BRACKET	TATA spare parts
550547100105	FUEL TANK ASSY	TATA spare parts
550547607701	GROMMET (FOR FUEL LINES)	TATA spare parts
550547608212	BKT. FOR FUEL LINE CLAMPING	TATA spare parts

550549100156	SILENCER ASSY EXHAUST	TATA spare parts
550549104224	CATCON MTG STRAP	TATA spare parts
550549104225	MTG STRAP FOR FRONT PIPE	TATA spare parts
550549200137	ASSEMBLY SUPPORT BRACKET SILENCER ASSEMB	TATA spare parts
550549200139	ASSEMBLY SILENCER NG3L WITH BOSS	TATA spare parts
550549200150	ASSY SILENCER WITH BOSS FOR 3L	TATA spare parts
550549203330	L BRACKET FOR SILENCER ASSLY	TATA spare parts
550549203352	BRACKET SILENCER MTG	TATA spare parts
550549203362	BRACKET FOR SILENCER MTG	TATA spare parts
550554100101	BATTERY CABLE +VE	TATA spare parts
550554100102	BATTERY CABLE -VE	TATA spare parts
550554100115	STARTER CABLE	TATA spare parts
550554209901	ECU EMS 3L BS3/4	TATA spare parts
550554249901	EMS ECU 3L 24V BS3/4	TATA spare parts
550554600118	W/H FIREWALL WITH FOG LAMP	TATA spare parts
550554600128	W/H FLOOR	TATA spare parts
550554600176	ASSY BRACKET (FORCED VENT-1 MTG ON CCB)	TATA spare parts
550554600179	ASSY BRACKET (FORCED VENT-2 MTG ON CCB)	TATA spare parts
550554608203	BKT FOR WH MTG	TATA spare parts
550554620120	W/H ROOF	TATA spare parts
550558600103	ASSY JACK MOUNTING BRACKET	TATA spare parts
550558600104	ASSY. BRACKET-FIRE EXT. MOUNTING BS6	TATA spare parts
550615400101	ALTERNATOR 12V 117A WITH VACCUM PUMP	TATA spare parts
550615400102	ALTERNATOR 12V 120A 6 GROOVE PULLEY BS6	TATA spare parts
550615409901	SUCTION CONNECTOR ASSY	TATA spare parts
550615409902	FASTENERS ASSEMBLY KIT	TATA spare parts
550615409903	VACUUM PUMP ASSLY KIT	TATA spare parts
550615409904	BEARING ASSEMBLY KIT	TATA spare parts
550615409905	DELIVERY CONNECTOR ASSY	TATA spare parts
550615409907	PLUG MOULDING ASSY	TATA spare parts
550615409908	RECTIFIER ASSEMBLY	TATA spare parts
550616100101	CONTAINER PART NO. FOR 7.5T 497 BSIII EN	TATA spare parts
550624000101	BRACKET ASSY ENGINE MTG FRONT-LH	TATA spare parts
550624000102	BRKT ASSY ENGINE MTG BOTTOM REAR BS6-PH2	TATA spare parts
550624000103	BRKT ASSY ENGINE MTG BOTTOM REAR BS6-PH2	TATA spare parts
550624100103	ASSY.FRONT ENGINE MOUNT BRACKET(3L-GB550	TATA spare parts
550624100112	BRACKETASSYENGINEMTGTOPLH BS6	TATA spare parts
550624100113	BRACKETASSYENGINEMTGTOPRH BS6	TATA spare parts
550624100119	BRACKET ASSY ENGINE MTG FRONT-LH BS6-PH2	TATA spare parts
550624100120	BRACKET ASSY ENGINE MTG TOP RH BS6-PH2	TATA spare parts
550624105101	ENG MTG ARM FRONT-LH	TATA spare parts
550624105102	ENG MTG ARM FRONT-RH	TATA spare parts
550624200103	GUSSET ASSY	TATA spare parts
550624200104	ASSEMBLY OF THIRD CROSS MEMBER	TATA spare parts
550624200105	BRACKETASSYENGINEMTGREAR BS6	TATA spare parts
550624200108	BRKT ASSY ENGINE MTG REAR TOP-LH BS6-PH2	TATA spare parts
550624200109	BRKT ASSY ENG MTG REAR TOP-RH BS6-PH2	TATA spare parts



550624200111	ENGINE MOUNT ASSY REAR BS6-PH2	TATA spare parts
550624203702	BRACKET ENGINE ARM FRONT-RH BS6	TATA spare parts
550624203703	ENGINE MOUNT ARM LH BS6	TATA spare parts
550624208203	3RD CROSS MEMBER FOR 4SP AND 3L ENGINE	TATA spare parts
550629300101	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
550629300104	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
550629300105	BUNDY TUBE ASSY MIDDLE BS6	TATA spare parts
550629500102	BRACKET ASSY BOOSTER MTG BS6	TATA spare parts
55063033000R40	PARTIALLY FITTED CAB W/O ELECT&CONTROLS	TATA spare parts
550631000111	FRAME 7.5T-3920WB-497E WITH OUT TOP COAT	TATA spare parts
550631000112	ASSY FRAME	TATA spare parts
550631000119	FRAME 7.5T-4530WB-497ENG WITH TOP COAT	TATA spare parts
550631000120	FRAME 7.5T-3920WB-497ENG WITH TOP COAT	TATA spare parts
550631000121	ASSY. FRAME	TATA spare parts
550631000155	ASSY.COMPLETE FRAME LPO 497E 4200WB	TATA spare parts
550631000156	FRAME ASSY WITH TOP COAT	TATA spare parts
550631000157	FRAME ASSY WITH TOP COAT	TATA spare parts
550631000162	FRAME ASSY WITH TOP COAT	TATA spare parts
550631000163	FRAME ASSY WITH TOP COAT	TATA spare parts
550631000164	FRAME ASSY WITH TOP COAT	TATA spare parts
550631000181	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
550631000183	FRAMEASSYWITHTOPCOAT BS6	TATA spare parts
550631000185	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
550631000187	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
550631000190	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
550631000191	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
550631107103	LONG MEMBER RH BS6	TATA spare parts
550631107104	LONG MEMBER LH BS6	TATA spare parts
550631107105	LONG MEMBER RH BS6	TATA spare parts
550631107106	LONG MEMBER LH BS6	TATA spare parts
550631107107	LONG MEMBER RH BS6	TATA spare parts
550631107108	LONG MEMBER LH BS6	TATA spare parts
550631200151	ASSY.GUSSET FOR ENGINE CM FRONT	TATA spare parts
550631200152	BRACKET ASSY RH	TATA spare parts
550631200153	BRACKET ASSY LH	TATA spare parts
550631207151	COBRA BRACKET RH 4200WB POSITON 1	TATA spare parts
550631207153	COBRA BRACKET 4200WB POSITION 2	TATA spare parts
550631207164	PLATE	TATA spare parts
550631207165	L-BRACKET RH	TATA spare parts
550631207166	L-BRACKET LH	TATA spare parts
550631207167	COBRA BRACKET LH	TATA spare parts
550631207168	COBRA BRACKET RH	TATA spare parts
550631207169	COBRA BRACKETS	TATA spare parts
550631208202	CROSS MEMBER BS6	TATA spare parts
550631208251	REINFORCEMENT	TATA spare parts
550631208253	REINFORCEMENT RH	TATA spare parts
550631208254	REINFORCEMENT LH	TATA spare parts

550631208290	REINFORCEMENT BS6-PH2	TATA spare parts
550631400103	ASSY CROSS MEMBER	TATA spare parts
550631400115	CROSS MEMBER ASSY 4TH	TATA spare parts
550631400118	BRACKET ASSY RADIATOR MTG RH BS6	TATA spare parts
550631400119	BRACKET ASSY RADIATOR MTG LH BS6	TATA spare parts
550631400120	CROSS MEMBER ASSY BS6	TATA spare parts
550631407153	JOINT GUSSET 9 LH	TATA spare parts
550631407154	JOINT GUSSET 9 RH	TATA spare parts
550631407155	JOINT GUSSET 10 LH	TATA spare parts
550631407156	JOINT GUSSET 10 RH	TATA spare parts
550631407157	JOINT GUSSET LH 11	TATA spare parts
550631407158	JOINT GUSSET RH 11	TATA spare parts
550631407159	COBRA BRACKETç 11	TATA spare parts
550631407160	L-BRACKET RH	TATA spare parts
550631407161	L-BRACKET LH	TATA spare parts
550631407162	GUSSET(ENGINE CM)	TATA spare parts
550631407165	COBRA BRACKET	TATA spare parts
550631408208	REINFORCEMENT SPRING HANGER BKT FRONT-RH	TATA spare parts
550631408209	REINFORCEMENT SPRING HANGER BKT FRONT-LH	TATA spare parts
550631408210	REINFORCEMENT RH. FRT.SHOCK ABS.BKT.	TATA spare parts
550631408214	REINFORCEMENT RH STEERING GB SUPPORT	TATA spare parts
550631408215	REINFORCEMENT LH STEERING GB SUPPORT	TATA spare parts
550631408216	ECU MTG.BKT	TATA spare parts
550631408251	GUSSET ENGINE CM REAR	TATA spare parts
550631408262	REINFORCEMENT TOP-RH	TATA spare parts
550631408267	REINFORCEMENTTOP-RH BS6	TATA spare parts
550631408274	BRACKET REINFORCEMENT RH BS6-PH2	TATA spare parts
550631408275	BRACKET REINFORCEMENT LH BS6-PH2	TATA spare parts
550631490101	NOISESHIELDASSY BS6	TATA spare parts
550631700105	FUPD ASSY CROSS BEAM BS6	TATA spare parts
550631700106	BRACKET ASSY FUPD MTG BS6	TATA spare parts
550631709201	WASHER BS6	TATA spare parts
550632100104	ASSY.SPRING HANGER BKT.	TATA spare parts
550632100105	ASSY.SPRING HANGER BKT.	TATA spare parts
550632100125	ASSY.FRONT SPRING (RUBBER BUSH)	TATA spare parts
550632100126	ASSY.FIRST LEAF WITH BUSHES	TATA spare parts
550632100131	ASSY.FIRST LEAF WITH BUSHES	TATA spare parts
550632100133	ASSEMBLY LEAF SPRING-FRONT	TATA spare parts
550632100137	LEAF SPRING ASSY	TATA spare parts
550632100138	1ST LEAF ASSY WITH BUSH	TATA spare parts
550632100143	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
550632100144	LEAF SPRING ASSY FRONT	TATA spare parts
550632100145	CLAMP ASSY	TATA spare parts
550632100149	BRACKET ASSY FRONT SPRING HANGER REAR BS	TATA spare parts
550632100150	LEAF SPRING ASSY	TATA spare parts
550632100152	1STLEAFASSYWITHBUSH BS6	TATA spare parts
550632100153	CLAMPASSY BS6	TATA spare parts

550632100154	LEAF SPRING ASSY FRONT BS6	TATA spare parts
550632100155	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
550632103314	BRACKET FRONT SPRING MTG FRONT BS6	TATA spare parts
550632103315	BRACKET FRONT SPRING HANGER REAR BS6	TATA spare parts
550632103401	COLLAR	TATA spare parts
550632103402	BUSH	TATA spare parts
550632103702	BRACKET FRONT SPRING HANGER	TATA spare parts
550632103703	BRACKET FRONT SPRING HANGER REAR	TATA spare parts
550632107114	PACKING PLATE	TATA spare parts
550632107118	3RD LEAF	TATA spare parts
550632107119	2ND LEAF	TATA spare parts
550632107134	SECOND LEAF	TATA spare parts
550632107135	THIRD LEAF	TATA spare parts
550632107140	SECOND LEAF	TATA spare parts
550632107140DF	SECOND LEAF FRONT PARA - ULTRA812	TATA spare parts
550632107141	THIRD LEAF	TATA spare parts
550632107141DF	THIRD LEAF FRONT PARA - ULTRA812	TATA spare parts
550632107142	SPACER 70X10X130	TATA spare parts
550632107151	SHACKLE	TATA spare parts
550632107152	2ND LEAF BS6	TATA spare parts
550632107153	3RD LEAF BS6	TATA spare parts
550632107154	1ST LEAF BS6	TATA spare parts
550632107157	2NDLEAF BS6	TATA spare parts
550632107159	3RDLEAF BS6	TATA spare parts
550632107160	2ND LEAF BS6	TATA spare parts
550632107162	4TH LEAF BS6	TATA spare parts
550632107164	3RD LEAF BS6	TATA spare parts
550632107165	SUPPORT PLATE BS6	TATA spare parts
550632107702	TIP INSERT BS6-PH2	TATA spare parts
550632107703	TIP INSERT BS6-PH2	TATA spare parts
550632108602	SPACER	TATA spare parts
550632108603	SLEEVE	TATA spare parts
550632200106	ASSEMBLY BUMP STOPPER (FRONT)	TATA spare parts
550632207102	CASTER PLATE	TATA spare parts
550632207104	CASTER PLATE BS6	TATA spare parts
550632400127	ASSY.REAR PARABOLIC SPRING (RUBBER BUSH)	TATA spare parts
550632400128	ASSY.FIRST LEAF WITH BUSHES	TATA spare parts
550632400130	ASSY.FIRST LEAF WITH BUSHES	TATA spare parts
550632400132	ASSY.LEAF SPRING-REAR	TATA spare parts
550632400145	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
550632400150	REAR SPRING ASSY	TATA spare parts
550632400153	LEAF SPRING ASSY REAR	TATA spare parts
550632400154	1ST LEAF ASSY WITH BUSH	TATA spare parts
550632400156	1ST LEAF ASSY WITH BUSH	TATA spare parts
550632400157	LEAF SPRING ASSY REAR	TATA spare parts
550632403207	CENTRE BOLT	TATA spare parts
550632403208	CENTRE BOLT	TATA spare parts

550632403210	CENTRE BOLT	TATA spare parts
550632403211	CENTRE BOLT	TATA spare parts
550632403212	CENTRE BOLT	TATA spare parts
550632403215	CENTRE BOLT	TATA spare parts
550632403217	CENTRE BOLT	TATA spare parts
550632403218	CENTRE BOLT	TATA spare parts
550632403219	CENTRE BOLT BS6	TATA spare parts
550632403220	CENTER BOLT M12X123	TATA spare parts
550632403222	CENTER BOLT M12 X 200	TATA spare parts
550632403223	CENTRE BOLT M12X1.75X94	TATA spare parts
550632403226	CLAMP BOLT	TATA spare parts
550632403228	CENTER BOLT	TATA spare parts
550632403702	BRACKET HELPER SPRING	TATA spare parts
550632403703	BRACKET SPRING HANGER REAR-LH	TATA spare parts
550632403704	BRACKET SPRING HANGER REAR-RH	TATA spare parts
550632403705	CASTER PLATE	TATA spare parts
550632404202	CLAMP 25X6	TATA spare parts
550632404207	CLAMP	TATA spare parts
550632404219	SPRING CLIP	TATA spare parts
550632404221	CLAMP	TATA spare parts
550632404223	CLAMP	TATA spare parts
550632407117	1ST LEAF BS6	TATA spare parts
550632407118	3RD LEAF BS6	TATA spare parts
550632407119	2ND LEAF BS6	TATA spare parts
550632407161	SECOND LEAF	TATA spare parts
550632407162	THIRD LEAF	TATA spare parts
550632407165	SECOND LEAF	TATA spare parts
550632407166	THIRD LEAF	TATA spare parts
550632407167	FORTH LEAF	TATA spare parts
550632407168	FIFTH LEAF	TATA spare parts
550632407169	SIXTH LEAF	TATA spare parts
550632407169DF	SIXTH LEAF REAR - ULTRA812	TATA spare parts
550632407170	SEVENTH LEAF	TATA spare parts
550632407171	EIGHTH LEAF	TATA spare parts
550632407172	FIRST LEAF (AUXILLARY)	TATA spare parts
550632407173	SECOND LEAF (AUXILLARY)	TATA spare parts
550632407174	THIRD LEAF (AUXILLARY)	TATA spare parts
550632408603	SPACER	TATA spare parts
550632408604	SPACER PLATE	TATA spare parts
550632417107	2ND LEAF	TATA spare parts
550632417108	3RD LEAF	TATA spare parts
550632417109	4TH LEAF	TATA spare parts
550632417110	5TH LEAF	TATA spare parts
550632417111	6TH LEAF	TATA spare parts
550632417112	7TH LEAF	TATA spare parts
550632417113	1ST LEAF AUX SPRING	TATA spare parts
550632417114	2ND LEAF AUX SPRING	TATA spare parts

550632417115	3RD LEAF AUX SPRING	TATA spare parts
550632417116	4TH LEAF AUX SPRING	TATA spare parts
550632417117	5TH LEAF AUX SPRING	TATA spare parts
550632417118	6TH LEAF AUX SPRING	TATA spare parts
550632417119	7TH LEAF AUX SPRING	TATA spare parts
550632417121	2ND LEAF	TATA spare parts
550632417131	3RD LEAF	TATA spare parts
550632417134	4TH LEAF	TATA spare parts
550632417135	5TH LEAF	TATA spare parts
550632417136	6TH LEAF	TATA spare parts
550632417137	7TH LEAF	TATA spare parts
550632417139	1ST LEAF AUX SPRING	TATA spare parts
550632417140	2ND LEAF AUX SPRING	TATA spare parts
550632417141	3RD LEAF AUX SPRING	TATA spare parts
550632504205	U-CLAMP	TATA spare parts
550632800101	ANTI ROLL BAR ASSY WITH LINK BS6	TATA spare parts
550633000106	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
550633000128	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
550633000136	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
550633000138	ASSY FRONT AXLE COMPLETE	TATA spare parts
550633000142	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
550633000143	FRONT AXLE ASSY 7.5T BUS (NON ABS)	TATA spare parts
550633000164	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
550633000165	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
550633000167	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
550633000171	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
550633105101	FRONT AXLE BEAM BS6	TATA spare parts
550633105102	FRONT AXLE BEAM	TATA spare parts
550633105104	FRONT AXLE BEAM-NORMAL	TATA spare parts
550633105106	FRONT AXLE BUS BEAM 7.5T	TATA spare parts
550633105107	FRONT AXLE BEAM-NORMAL	TATA spare parts
550633200105	STUB AXLE ASSY LH	TATA spare parts
550633200106	STUB AXLE ASSY RH	TATA spare parts
550633200136	STUB AXLE ASSY RH	TATA spare parts
550633200137	STUB AXLE ASSY LH	TATA spare parts
550633200138	STUB AXLE ASSY LH BS6	TATA spare parts
550633200139	STUB AXLE ASSY RH BS6	TATA spare parts
550633200140	STUB AXLE ASSY LH BS6-PH2	TATA spare parts
550633200141	STUB AXLE ASSY RH BS6-PH2	TATA spare parts
550633200149	STUB AXLE ASSY. LH(NORMAL)	TATA spare parts
550633200153	STUB AXLE ASSY.RH(NORMAL)	TATA spare parts
550633200165	STUB AXLE ASSY.(RH) (INTEGRATED)	TATA spare parts
550633200170	STUB AXLE ASSY (LH) (INTEGRATED)	TATA spare parts
550633200197	STUB AXLE ASSY RH	TATA spare parts
550633200198	STUB AXLE ASSY LH	TATA spare parts
550633203101	THRUST BEARING	TATA spare parts
550633203210	HEX BOLT (TIE ROD ARM)	TATA spare parts

550633205109	STUB AXLE RH(BUS) 7.5T	TATA spare parts
550633205110	STUB AXLE LH(BUS) 7.5T	TATA spare parts
550633205123	STUBAXLERH BS6	TATA spare parts
550633205124	STUBAXLELH BS6	TATA spare parts
550633206705	KING PIN-NORMAL Y1-7.5T(TRUCK)	TATA spare parts
550633207802	KING PIN SEAL	TATA spare parts
550633209210	KING PIN SPACER	TATA spare parts
550633209211	KING PIN SPACER	TATA spare parts
550633209212	KING PIN SPACER	TATA spare parts
550633209213	KING PIN SPACER	TATA spare parts
550633209214	KING PIN SPACER	TATA spare parts
550633209215	KING PIN SPACER	TATA spare parts
550633209216	KING PIN SPACER	TATA spare parts
550633209217	KING PIN SPACER	TATA spare parts
550633209218	KING PIN SPACER	TATA spare parts
550633209219	KING PIN SPACER	TATA spare parts
550633209220	KING PIN SPACER	TATA spare parts
550633209222	KING PIN SPACER 2.25 THK.	TATA spare parts
550633209223	KING PIN SPACER 2.35 THK.	TATA spare parts
550633209224	KING PIN SPACER 2.45 THK.	TATA spare parts
550633209225	KING PIN SPACER 2.55THK.	TATA spare parts
550633209226	KING PIN SPACER 2.65 THK.	TATA spare parts
550633209227	KING PIN SPACER 2.75 THK.	TATA spare parts
550633400107	FRONT HUB ASSY. FOR NON ABS	TATA spare parts
550633400111	HUB ASSY (BUS) ( WITH 245 PCD DRUM)	TATA spare parts
550633400114	FRONT HUB ASSY (BUS) ( NON ABS VEHICLE)	TATA spare parts
550633403707	FRONT HUB	TATA spare parts
550633403714	FRONT HUB (BUS) (WITH 245 PCD BRAKE DRUM	TATA spare parts
550640100106	ASSY WHEEL RIM 6 X 17.5	TATA spare parts
550640100108	WHEEL RIM ASSY WITH VALVE(205 PCD + TUBE	TATA spare parts
550640100120	WHEEL RIM ASSY WITH VALVE BS6	TATA spare parts
550640100130	WHEEL RIM ASSY WITH VALVE BS6	TATA spare parts
550640109905	TUBELESS TYRE 225/75R 17.5	TATA spare parts
550641100101	PROPELELR SHAFT ASSY MONOTRON BS6	TATA spare parts
550641100102	PROPELELR SHAFT ASSY MONOTRON 35WB	TATA spare parts
550641100103	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
550641100105	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
550641100106	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
550641110104	ASSY. PROP. SHAFT WITH CENETRE BEARING	TATA spare parts
550641110108	ASSY. PROP. SHAFT WITH CENETRE BEARING C	TATA spare parts
550641110129	FRONT ASSY.COUPLING SHAFT WITH CENTRE BE	TATA spare parts
550641110133	MONOTRON SHAFT ASSY. 4200WB	TATA spare parts
550641110151	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
550641110152	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
550641110172	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
550641115101	FLANGE YOKE	TATA spare parts
550641115105	COMPANION_FLANGE	TATA spare parts

55064115110	FLANGE YOKE	TATA spare parts
550641116501	COMPANION_FLANGE_NUT	TATA spare parts
550641120105	SLIP YOKE ASSY	TATA spare parts
550641120106	SLIP YOKE ASSY	TATA spare parts
550641120111	COMPANION FLANGE	TATA spare parts
550641120133	ASSY. DRIVE SHAFT COMPLETE 4200WB	TATA spare parts
550641120143	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
550641120154	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
550641120177	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
550641120178	CROSS ASSY	TATA spare parts
550641120179	SLIP YOKE ASSEMBLY	TATA spare parts
550641125103	SLIP YOKE ASSY	TATA spare parts
550641125106	FULL RND FLANGE YOKE ASSEMBLY	TATA spare parts
550641127701	YOKE SEAL	TATA spare parts
550641128201	DUST CAP	TATA spare parts
550641128203	PROPELLER SHAFT WELCH PLUG BS6	TATA spare parts
550641300101	ASSY.CENTER BEARING	TATA spare parts
550641300103	CENTER BEARING AND RETAINER ASSY.	TATA spare parts
550641300105	KIT-UNIVERSAL JOINT BS3/4/6	TATA spare parts
550641300106	CENTER BEAR. ASSY 192MM PITCH COUP	TATA spare parts
550641300107	CENTER BEARING 192MM PITCH MONOTRON BS4	TATA spare parts
550641300107DF	CENTER BEARING ASSY ULTRA 812/912/LPO10.	TATA spare parts
550641300115	CENTER BEARING ASSY	TATA spare parts
550641300116	CENTER BEARING ASSY BS6	TATA spare parts
550641303304	BRACKET CENTER BRG MTG	TATA spare parts
550641307104	CENTER MOUNTING BRACKET	TATA spare parts
550641307106	BRACKET CENTER BRG MTG BS6	TATA spare parts
550641307112	BRACKET CENTER BRG MTG	TATA spare parts
550641307113	BRACKET-CENTER BRG MTG BS6	TATA spare parts
550641307501	RUBBER HOUSING	TATA spare parts
550641308202	SLINGER	TATA spare parts
550641308205	SLINGER	TATA spare parts
550641308206	MONOTRON SLINGER	TATA spare parts
550641308207	CENTER BEARING BRACKET 192MM PITCH	TATA spare parts
550641308210	CENTER BEARING ASSY AND RETAINER	TATA spare parts
550641308211	CENTER BEARING RUBBER	TATA spare parts
550641308214	BRACKET BRG MTG BS6	TATA spare parts
550642100101	ASSLY. CALIPER RB60X60-RH	TATA spare parts
550642100102	ASSLY. CALIPER RB60X60-LH	TATA spare parts
550642100109	ASSLY F/A BRK LH WITH DUST COVER	TATA spare parts
550642100110	ASSLY F/A BRAKE RH WITH DUST COVER	TATA spare parts
550642100111	ASSLY.BRK.PAD AF4820E-OUTBOARD_RB60X60	TATA spare parts
550642100144	SHIELD ASSLY TOP	TATA spare parts
550642100145	SHIELD ASSLY BOTTOM	TATA spare parts
550642100152	DRUM BRAKE ASSY WITH DC LH	TATA spare parts
550642100153	DRUM BRAKE ASSY WITH DC RH	TATA spare parts
550642100155	CALIPER ASSEMBLY - LH ( WITH FERODO PADS	TATA spare parts

550642100156	CALIPER ASSEMBLY - RH ( WITH FERODO PADS	TATA spare parts
550642100188	AUTO SLACK ADJUSTER	TATA spare parts
550642100201	CALIPER ASSY FRONT-LH	TATA spare parts
550642100202	CALIPER ASSY FRONT-RH	TATA spare parts
550642100208	DRUM BRAKE ASSY WITH DC LH	TATA spare parts
550642100209	DRUM BRAKE ASSY WITH DC RH	TATA spare parts
550642100211	KIT CALIPER ASSY - MINOR	TATA spare parts
550642103702	VENTILATED BRAKE DISC RB60X60 FRONT	TATA spare parts
550642103703	BRAKE DRUM Y1 7.5T BUS(325 X 120) BS3/4	TATA spare parts
550642103705	BRAKE DRUM	TATA spare parts
550642103706	BRAKE DRUM	TATA spare parts
550642108203	SPLASH SHIELD FOR FRONT INTEGRATED STUB-	TATA spare parts
550642108204	SPLASH SHIELD FOR FRONT INTEGRATED STUB-	TATA spare parts
550642110104	AUTO SLACK ADJUSTER BS6	TATA spare parts
550642110126	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
550642110127	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
550642300105	ASSLY.H2LS BRAKE DIA.320X110-LH DIA.31.7	TATA spare parts
550642300106	ASSLY.H2LS BRAKE DIA.320X110-RH DIA.31.7	TATA spare parts
550642300107	ASSLY.WHEEL CYL.DIA.31.75-LH W/ BLEEDER	TATA spare parts
550642300108	ASSLY.WHEEL CYL.DIA.31.75-RH W/ BLEEDER	TATA spare parts
550642300109	ASSLY.WHEEL CYL.DIA.31.75-LH W/O BLEEDER	TATA spare parts
550642300110	ASSLY.WHEEL CYL.DIA.31.75-RH W/O BLEEDER	TATA spare parts
550642300122	ASY R/A BRK-LH WITH DUST COVER	TATA spare parts
550642300123	ASY R/A BRK-RH WITH DUST COVER	TATA spare parts
550642300137	SHIELD ASSLY TOP	TATA spare parts
550642300138	SHIELD ASSLY BOTTOM	TATA spare parts
550642300168	DRUM BRAKE ASSY R/A W/T D/C -LH	TATA spare parts
550642300169	DRUM BRAKE ASSY R/A W/T D/C -RH	TATA spare parts
550642300170	WHEEL CYLINDER ASSY WITH BLEEDER LH	TATA spare parts
550642300171	WHEEL CYLINDER ASSY W/O BLEEDER LH	TATA spare parts
550642300172	WHEEL CYLINDER ASSY WITH BLEEDER RH	TATA spare parts
550642300173	WHEEL CYLINDER ASSY W/O BLEEDER RH	TATA spare parts
550642300174	DRUM BRAKE ASSY LH DIA.320X110-31.75W/C	TATA spare parts
550642300175	DRUM BRAKE ASSY RH DIA.320X110-31.75W/C	TATA spare parts
550642300179	DRUM BRAKE ASSY R/A W/T D/C -RH	TATA spare parts
550642300180	DRUM BRAKE ASSY R/A W/T D/C -LH	TATA spare parts
550642300193	AUTO SLACK ADJUSTER ASSY RH	TATA spare parts
550642300194	AUTO SLACK ADJUSTER ASSY LH	TATA spare parts
550642300199	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
550642303707	BRAKE DRUM BS6	TATA spare parts
550642305101	S-CAM SHAFT- LH (325X120)	TATA spare parts
550642305102	S-CAM SHAFT- RH (325X120)	TATA spare parts
550642310101	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
550642310117	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
550642310118	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
550642310137	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
550642310138	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts



550642990101	KIT CALIPER (MAJOR)	TATA spare parts
550642990102	KIT CALIPER (MINOR)	TATA spare parts
550642990103	CARRIER SUB ASSY-LH	TATA spare parts
550642990104	CARRIER SUB ASSY-RH	TATA spare parts
550642990105	KIT SLIDING PIN	TATA spare parts
550642990106	KIT PAD ASSEMBLY (FER 3422 GRADE)	TATA spare parts
550642990110	KIT WHEEL CYL.- MAJOR	TATA spare parts
550642990111	KIT WHEEL CYL.- MINOR	TATA spare parts
550642990117	KIT-PAD ASSY RB 60X60 BS3	TATA spare parts
550642990118	WHEEL CYLINDER ASSY MINOR KIT DIA.31.75	TATA spare parts
550642990120	KIT-BRAKE SHOE & LINER	TATA spare parts
550642990121	KIT-BRAKE LINER SET STD (325 X 100) BS4	TATA spare parts
550642990123	KIT-BRAKE LINER O/S 1 (325 X 100) BS4	TATA spare parts
550642990125	KIT-BRAKE LINER O/S 2 (325 X 100) BS4	TATA spare parts
550642990149	KIT-TORQUE PLATE ASSY LH	TATA spare parts
550642990150	KIT-TORQUE PLATE ASSY RH	TATA spare parts
550642990151	KIT-CAMSHAFT	TATA spare parts
550642990157	KIT-CAMSHAFT	TATA spare parts
550642990159	KIT-BRAKE SHOE WITH LINER	TATA spare parts
550642990160	BRAKE SHOE ASSY	TATA spare parts
550642990161	KIT-BRAKE AGGR	TATA spare parts
550642990164	KIT-BRAKE SHOE	TATA spare parts
550642990165	KIT-BRAKE	TATA spare parts
550642990166	KIT-TORQUE PLATE ASSY LH	TATA spare parts
550642990168	KIT-CAMSHAFT¿(LH)	TATA spare parts
550642990170	KIT SHIM BS6	TATA spare parts
550642990171	KIT-TORQUE PLATE ASSY LH BS6	TATA spare parts
550642990172	KIT-TORQUE PLATE ASSY RH	TATA spare parts
550642990173	KIT-TORQUE PLATE ASSY RH BS6	TATA spare parts
550642990174	KIT-BRACKET ASSY LH BS6	TATA spare parts
550642990175	KIT-BRAKE SHOE	TATA spare parts
550642990176	KIT-BRAKE AGGR	TATA spare parts
550642990180	KIT TORQUE PLATE ASSY LH ( BIL)	TATA spare parts
550642990181	KIT TORQUE PLATE ASSY RH ( BIL)	TATA spare parts
550642990182	KIT-BRAKE AGGR	TATA spare parts
550642990185	KIT-BRAKE SHOE	TATA spare parts
550642990186	LINED SHOE ASSY	TATA spare parts
550642990187	KIT-BRACKET ASSY RH BS6	TATA spare parts
550642990190	KIT-CAMSHAFT¿(RH)	TATA spare parts
550642990191	CAMSHAFT REAR-LH	TATA spare parts
550642990197	KIT-BRAKE SHOE WITH LINER	TATA spare parts
550642990198	CAMSHAFT REAR-RH	TATA spare parts
550642997703	PROTECTIVE PLUG	TATA spare parts
550643200102	AIR TANK 15 LIT (118 STRAP CD) W/SUPPORT	TATA spare parts
550643200103	AIR TANK ASSY WITH STRAP	TATA spare parts
550643200104	AIR TANK ASSY	TATA spare parts
550643200108	SUPPORTASSYAIRTANK BS6	TATA spare parts

550643200109	AIR TANK ASSY WITH BKT BS6	TATA spare parts
550643300101	BRACKET ASSY LCRV LINK MTG BS6	TATA spare parts
550643400101	BRACKET ASSY BS6	TATA spare parts
550643700101	ASSY DUAL BRAKE VALVE	TATA spare parts
550643700102	BRAKE CHAMBER TYPE 12	TATA spare parts
550643700105	SYSTEM PROTCTION VALVE	TATA spare parts
550643700106	BRAKE CHAMBER LH BS6	TATA spare parts
550643700107	BRAKE CHAMBER RH BS6	TATA spare parts
550643700108	SPRING¿BRAKE¿ACTUATOR¿16/16	TATA spare parts
550643700112	DUAL BRAKE VALVE	TATA spare parts
550643700113	DRYING & DISTRIBUTION UNIT	TATA spare parts
550643700115	BRAKE CHAMBER BS6	TATA spare parts
550643700133	DRYING & DISTRIBUTION UNIT	TATA spare parts
550643703304	BRACKET-DDU MTG BS6	TATA spare parts
550643703305	BRACKET ALSV MTG	TATA spare parts
550643800105	ASSY METAL PIPE ADAPTOR TO DDU	TATA spare parts
550643800106	ASSY METAL PIPE HOSE TO ADAPTOR	TATA spare parts
550643800109	ASSY METAL PIPE ADAPTOR TO DDU	TATA spare parts
550643800110	ASSY METAL PIPE ADAPTOR TO DDU	TATA spare parts
550643800120	PIPE ASSY COMPRESSOR TO DDU	TATA spare parts
550643800121	PIPE ASSY COMPRESSOR TO DDU	TATA spare parts
550643800192	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
550643800194	PIPE ASSY AIR DRYER TO INT JOINT	TATA spare parts
550643800195	PIPE ASSY HOSE ASSY TO INT JOINT	TATA spare parts
550643800196	PIPE ASSY AIR DRYER TO INT JOINT	TATA spare parts
550643800197	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
550643800198	METAL PIPE BS6	TATA spare parts
550643800199	METAL PIPE BS6	TATA spare parts
550643810101	METAL PIPE ASSY BS6	TATA spare parts
550643810104	METAL PIPE ASSY ADAPTER TO DDU BS6	TATA spare parts
550643900159	PIPE ASSY DBV 22 TO ADAPTOR	TATA spare parts
550643900193	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
550643900195	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
550643903301	BRACKET NYLON PIPE HOLDING	TATA spare parts
550643910138	RUBBER HOSE ASSY BS6	TATA spare parts
550643916938	RUBBER HOSE DIA 25 (DBV EXHAUST)	TATA spare parts
550643920123	PIPE ASSY NYLON BUNCH CHASSIS	TATA spare parts
550643920129	NYLON PIPE BUNCH ASSY-42WB ABS	TATA spare parts
550643920131	NYLON PIPE BUNCH ASSY ABS	TATA spare parts
550643920145	PIPE BUNCH ASSY	TATA spare parts
550643920187	NYLON PIPE BUNCH ASSY CABIN	TATA spare parts
550643920199	PIPE BUNCH ASSY CHASSIS	TATA spare parts
550643930127	PIPE ASSY NYLON BUNCH - CAB	TATA spare parts
550643930141	PIPE ASSY NYLON BUNCH - CHASSIS	TATA spare parts
550643930161	PIPE ASSY NYLON BUNCH - CAB	TATA spare parts
550643930167	PIPE BUNCH ASSY CHASSIS 35WB	TATA spare parts
550643930172	PIPE BUNCH ASSY CHASSIS	TATA spare parts

550643930185	PIPE BUNCH ASSY CHASSIS	TATA spare parts
550643930196	METAL PIPE ASSY HOSE TO INT JOINT	TATA spare parts
550643930197	METAL PIPE ASSY INT JOINT TO DDU	TATA spare parts
550643935892	HOSE	TATA spare parts
550643935893	HOSE	TATA spare parts
550643940115	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
550643940122	BRACKET BS6	TATA spare parts
550643940126	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
550643940130	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
550643940136	PIPE BUNCH ASSY CABIN BS6	TATA spare parts
550643940143	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
550643940145	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
550643940147	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
550643950115	PIPE BUNCH ASSY CABIN BS6	TATA spare parts
550646100101	SPLINETUBEASSY BS6	TATA spare parts
550646100102	UPPERCOLUMNASSY BS6	TATA spare parts
550646100103	STRG COLUMN ASSY WITH IFLASESHAFT BS6-PH	TATA spare parts
550646800101	ASSY. SUCTION LINE (RESERVOIR TO PUMP)	TATA spare parts
550646800102	ASSY. HIGH PRESSURE LINE - RHD (STRG. PU	TATA spare parts
550646800103	ASSY. RETURN LINE - RHD (STRG. GEAR BOX	TATA spare parts
550646800107	HIGH PRESSURE LINE ASSY PUMP TO STG GB	TATA spare parts
550646800108	RETURN LINE & HOSE ASSY	TATA spare parts
550646800119	SUCTION LINE ASSY	TATA spare parts
550646805807	HOSE SUCTION LINE	TATA spare parts
550646807719	PLASTIC CLAMP (DIA.8 TO 12)	TATA spare parts
550646900101	DRAG LINK ASSY	TATA spare parts
550647104201	CLAMP FOR ELE FEED PUMP (7.5T) BS6	TATA spare parts
550647600101	FUEL SUCTION PIPE ASSY FUEL TNK TO E.F.P	TATA spare parts
550647600102	FUEL RETURN PIPE ASSY.O.FLW TO F.T.SEG-2	TATA spare parts
550647600103	FUEL SUCTION PIPE ASSY.PREFIL.TO M_FILT.	TATA spare parts
550647600106	FUEL RETURN PIPE ASSY O.FLW TO F.T.SEG-1	TATA spare parts
550647600107	FUEL SUCTION PIPE ASSY.FUEL TNK TO E.F.P	TATA spare parts
550647600108	FUEL RETURN PIPE ASSY O.FLW TO F.T.SEG-2	TATA spare parts
550647600109	FUEL SUCTION PIPE ASSY.E.F.P TO FUEL FLT	TATA spare parts
550647600119	ASSY. RETURN LINE OVERFLOW TO FUEL TANK	TATA spare parts
550647600120	ASSY.SUCTION LINE BABY FILTER TO ENGINE	TATA spare parts
550647600121	ASSY.SUCTION LINE FUEL TANK TO BABY FILT	TATA spare parts
550647600122	ASSY BRACKET FOR CLAMPING BS6	TATA spare parts
550647600123	FUEL SUCTION LINE ASSY FUEL TANK TO E.F.P	TATA spare parts
550647600124	FUEL RETURN LINE ASSY SEGMENT 2	TATA spare parts
550647600125	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
550647600126	FUEL RETURN PIPE ASSY BS6	TATA spare parts
550647600144	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
550647600145	PRIMING PUMP ASSY BS6	TATA spare parts
550647600150	SUCTION PIPE ASSY HEATER TO FEED PUMP	TATA spare parts
550647600151	FUEL SUCTION LINE ASSY FILTER TO FIP	TATA spare parts
550647600152	FUEL SUCTION PIPE ASSY. FILTER TO FIP	TATA spare parts

550647600155	FUEL SUCTION LINE ASSY E.F.P TO PRE-FILT	TATA spare parts
550647600156	FUEL SUCTION LINE ASSY MAIN-FILT TO FIP	TATA spare parts
550647600157	FUEL RETURN LINE ASSY FIP TO F.TK SEG-1	TATA spare parts
550647600159	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
550647600167	SUCTION FUEL PIPE ASSY TANK TO PREFILTER	TATA spare parts
550647600168	SUCTION FUEL PIPE ASSY FINAL FTR TO FIP	TATA spare parts
550647600169	RETURN FUEL PIPE ASSY ENGINE TO TANK	TATA spare parts
550647600170	PRIMING PUMP ASSY	TATA spare parts
550647600171	BRACKET ASSY FILTER MTG	TATA spare parts
550647600172	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
550647600177	FUEL RETURN PIPE ASSY BS6	TATA spare parts
550647600192	FUEL RETURN PIPE ASSY BS6	TATA spare parts
550647603302	BRACKET FOR PRE_FILTER MTG.	TATA spare parts
550647603303	BRACKET FUEL_FILTER_HAND_PRIMING MTG.	TATA spare parts
550647608201	BRACKET FOR FUEL LINE CLAMPING	TATA spare parts
550647608204	BKT. FOR FUEL LINE CLAMPING (7.5T TRUCK)	TATA spare parts
550647608208	ELEC_FEED_PUMP_MTG_PLATE	TATA spare parts
550649000108	PIPE ASSY HOSE PIPE TO SILENCER PORT	TATA spare parts
550649000109	RUBBER HOSE FROM DPS TO EXH PORT	TATA spare parts
550649000110	PIPE ASSY EXHAUST PIPE TO HOSE	TATA spare parts
550649000111	HOSE PIPE ASSY PIPE TO DPS UP STREAM	TATA spare parts
550649000115	HOSE PIPE ASSY DPS TO PIPE DOWN STREAM	TATA spare parts
550649000116	HOSE PIPE ASSY UP STREAM	TATA spare parts
550649100110	SILENCER ASSY WITH TAIL PIPE	TATA spare parts
550649100111	BRACKET ASSY SILENCER MTG	TATA spare parts
550649100112	BRACKET ASSY CATCON MTG	TATA spare parts
550649104202	CLAMP	TATA spare parts
550649200101	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
550649200102	FRONT PIPE ASSY	TATA spare parts
550649200106	BRACKET ASSY DOC POC MTG	TATA spare parts
550649200107	ASSY.FOR SUPPORT BRACKET	TATA spare parts
550649200112	ASSY MTG BRACKET	TATA spare parts
550649200114	BRACKET ASSY	TATA spare parts
550649200115	SILENCER ASSEMBLY	TATA spare parts
550649200116	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
550649200118	PIPE ASSY DPS SENSOR REAR	TATA spare parts
550649200119	PIPE ASSY DPS SENSOR INTAKE	TATA spare parts
550649200121	EXHAUST PIPE ASSY FIRST BS6	TATA spare parts
550649200124	BRACKET ASSY EGP MTG BS6	TATA spare parts
550649200125	EXHAUST PIPE ASSY SECOND BS6	TATA spare parts
550649200126	BRACKET ASSY BS6	TATA spare parts
550649200129	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
550649200132	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
550649200134	BRACKETASSYEXHAUSTPIPE BS6	TATA spare parts
550649200135	BRACKETASSYFRONTPIPEMTG BS6	TATA spare parts
550649203301	Z-BRACKET BS6	TATA spare parts
550649203311	MTG BRACKET FOR DPS SENSOR	TATA spare parts

550649203312	DPS SENSOR MTG. BKT.	TATA spare parts
550649203313	MTG BKT FOR DPS SENSOR	TATA spare parts
550649203317	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
550649203318	BRACKET FRONT PIPE MTG BS6	TATA spare parts
550649204203	BRACKET CATCON MTG	TATA spare parts
550649204206	HANGER BRACKET	TATA spare parts
550649205301	GASKET(NEW)	TATA spare parts
550649208204	CLAMP EXHAUST PIPE INT	TATA spare parts
550649990103	NOISE SHIELD ASSY REAR-BOTTOM	TATA spare parts
550649990104	NOISE SHIELD ASSY FRONT-BOTTOM	TATA spare parts
550654100114	BRACKET ASSLY(12V 130AH/100AH BATTERY CA	TATA spare parts
550654100128	BUS BATTERY CARRIER ASSY 24V 130AH	TATA spare parts
550654100145	BATTERY COVER LH FOR 24V 130AH	TATA spare parts
550654100146	BATTERY COVER RH FOR 24V 130AH.	TATA spare parts
550654100156	ASSY BKT FOR CUT OFF SW MTG	TATA spare parts
550654108801	BEND STUD BATTERY CLAMPLING	TATA spare parts
550654200101	ASSY BRACKET (BATTERY CUTOFF SWITCH MTG)	TATA spare parts
550654200102	ASSY BRACKET MAXI FUSE MTG	TATA spare parts
550654200104	INSTRUMENT CLUSTER ASSY	TATA spare parts
550654200110	INSTRUMENT CLUSTER INTERFACE HARDWARE	TATA spare parts
550654208208	BRACKET (FACIA SWITCH MTG.) BS6	TATA spare parts
550654208210	CARRIER PLATE FASCIA SWITCH BS6	TATA spare parts
550654208214	BRACKET (DIAGNOSTICS CONNECTOR MTG.)	TATA spare parts
550654403301	BRACKET ASSY TAIL LAMP MTG LH	TATA spare parts
550654403302	BRACKET ASSY TAIL LAMP MTG RH	TATA spare parts
550654403303	BRACKET ASSY TAIL LAMP MTG BS6-PH2	TATA spare parts
550654500104	ASSY INTERFACE UNIT FOR VEH GB550	TATA spare parts
550654500109	ASSY FUSE BOX (1+4) W/O COVER. BS6	TATA spare parts
550654503301	PLATE FASCIA SWITCH MTG BS6-PH2	TATA spare parts
550654504902	HAZARD SWITCH BS6 PH2	TATA spare parts
550654504903	SWITCH ALL DOOR OPEN/CLOSE EV	TATA spare parts
550654504905	SWITCH HILL HOLDER BS6 PH2	TATA spare parts
550654504906	SWITCH FRONT/REAR DOOR OPEN EV	TATA spare parts
550654504907	SWITCH NIGHT LAMP EV	TATA spare parts
550654504908	SWITCH INTERNAL STAGE LAMP 1 & 2 EV	TATA spare parts
550654504909	SWITCH DESTINATION BOARD EV	TATA spare parts
550654504911	SWITCH PASSENGER FAN EV	TATA spare parts
550654504915	SWITCH BODY BUILDER EMERGENCY EV	TATA spare parts
550654504916	SWITCH STOP REQUEST BUZZER RESET EV	TATA spare parts
550654504918	SWITCH DRIVER FAN EV	TATA spare parts
550654504919	SWITCH DRIVER LAMP EV	TATA spare parts
550654504925	SWITCH HEAVY MODE BS6 PH2	TATA spare parts
550654504931	SWITCH REGENERATION INHIBIT BS6 PH2	TATA spare parts
550654504932	SWITCH REGENERATION START MANUAL BS6 PH2	TATA spare parts
550654504933	ALARM RESET SWITCH BS6-PH2	TATA spare parts
550654504935	SWITCH EMERGENCY HELP BS6 PH2	TATA spare parts
550654504936	SWITCH LIFT AXLE FRONT BS6 PH2	TATA spare parts

550654504938	SWITCH LIFT AXLE DISABLE BS6 PH2	TATA spare parts
550654504939	SWITCH ENGINE BRAKE BS6 PH2	TATA spare parts
550654504947	SWITCH LIGHT MODE BS6 PH2	TATA spare parts
550654504948	SWITCH ENGINE LAMP BS6 PH2	TATA spare parts
550654504949	SWITCH FRONT FOG LAMP BS6-PH2	TATA spare parts
550654504950	SWITCH MEDIUM MODE BS6 PH2	TATA spare parts
550654504952	SWITCH EXHAUST BRAKE BS6-PH2	TATA spare parts
550654504954	STRG LOCK & IGNITION SWITCH ASSY BS6-PH2	TATA spare parts
550654504956	SWITCH RETARDER BS6-PH2	TATA spare parts
550654504957	SWITCH START STOP INHIBIT BS6-PH2	TATA spare parts
550654504959	ATC SWITCH DASHBOARD BS6 PH2	TATA spare parts
550654504960	SWITCH BATTERY CUT OFF BS6-PH2	TATA spare parts
550654504961	SWITCH ASSY COMBINATION BS6-PH2	TATA spare parts
550654509906	CONTACTLESS NEUTRAL POSITION SENSOR BS4	TATA spare parts
550654600103	WIRING HARNESS EMS	TATA spare parts
550654600107	WIRING HARNESS GEAR BOX	TATA spare parts
550654600108	BRACKET ASSY(FRONT & REAR ABS INLINE MTG	TATA spare parts
550654600110	WIRING HARNESS ABS	TATA spare parts
550654600114	BRACKET ASSY(2 POLE INLINE CONNECTOR MTG	TATA spare parts
550654600115	BRACKET ASSY(E-BOX INLINE CONNECTOR)	TATA spare parts
550654600117	ASSY BRKT(IP INLINE & E-BOX CONN. MTG)	TATA spare parts
550654600122	WIRING HARNESS ENGINE	TATA spare parts
550654600125	BRACKET ASSY (3LTR ENG WH MTG)	TATA spare parts
550654600129	BRACKET ASSY(INLINE FOR 2 POLE CONNECTOR	TATA spare parts
550654600158	ASSY BKT(FR CHASSIS-BATTERY CABLE WH MTG	TATA spare parts
550654600161	ASSY BRACKET (LPO 3LENG BUS FRONT & ENGI	TATA spare parts
550654600165	ASSY BRACKET (3L LPO BUS CONNECTOR) BS6	TATA spare parts
550654600168	ASSY BKT FOR ENG WH MTG ON FRAME	TATA spare parts
550654600176	BRACKET ASSY INLINE CONNECTOR MTG	TATA spare parts
550654600199	BRACKET ASSY FRONT TO REAR INLINE	TATA spare parts
550654600203	WIRING HARNESS LOAD BODY BS6	TATA spare parts
550654600204	WIRING HARNESS LOAD BODY BS6	TATA spare parts
550654600205	WIRINGHARNESSEVERSEPARKASSIST BS6	TATA spare parts
550654600206	WIRING HARNESS LOAD BODY BS6	TATA spare parts
550654601628	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
550654601631	"WIRING HARNESS,FRONT CHASSIS"	TATA spare parts
550654601633	WIRING HARNESS REAR CHASSIS	TATA spare parts
550654601639	BATTERY CABLE +VE	TATA spare parts
550654601640	BATTERY CABLE +VE;BCS TO MEGA FUSE	TATA spare parts
550654601641	BATTERY CABLE +VE MAXI FUSE O/P TO SM	TATA spare parts
550654601642	BATTERY CABLE -VE	TATA spare parts
550654601657	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
550654601661	WIRING HARNESS FRONT CHASSIS	TATA spare parts
550654601666	WIRING HARNESS REAR CHASSIS	TATA spare parts
550654601667	WIRING HARNESS REAR CHASSIS	TATA spare parts
550654601687	WIRING HARNESS SWITCH	TATA spare parts
550654601688	WIRING HARNESS REAR CHASSIS	TATA spare parts

550654601689	WIRING HARNESS FLOOR	TATA spare parts
550654603301	BRACKET ASSY GEAR BOX MTG	TATA spare parts
550654603302	W/H SUPPORT BKT FOR CLUTCH ACTUATOR	TATA spare parts
550654603303	BRACKET W/H SUPPORT ON GB550	TATA spare parts
550654603304	BRACKET WIRING HARNESS MTG	TATA spare parts
550654603305	BRACKET ENG INLINE CONN MTG	TATA spare parts
550654608201	BRACKET(EXHAUST SIDE WH MTG)	TATA spare parts
550654608203	BRACKET(FRONT TO REAR INLINE CONNECTOR)	TATA spare parts
550654608207	BRACKET(ENGINE MOUNTING)	TATA spare parts
550654608217	BRACKET(CAB SW PIGTAIL CONNECTOR MTG)	TATA spare parts
550654608227	BRACKET(CHASSIS HARNESS MTG ON EXHAUST)	TATA spare parts
550654608228	BRACKET (FR CHASSIS HORN MTG)	TATA spare parts
550654608233	BRACKET(FRONT CHASSIS WH ON ROUND CROSS	TATA spare parts
550654608235	BRACKET(ENGINE & FRONT CHASSIS WH CONNEC	TATA spare parts
550654608236	BRACKET(FIREWALL INLINE CONNECTOR MTG)	TATA spare parts
550654608247	BRACKET	TATA spare parts
550654608250	BKT(5L ENGINE INJECTOR HARNESS MTG)	TATA spare parts
550654608260	BRACKET ON CROSS MEMBER FOR WH MTG	TATA spare parts
550654608275	CHASSIS HARNESS MTG BKT _6.5T_5.5T_ TRUCK	TATA spare parts
550654608278	BRACKET(AUTODRAIN CONNECTOR MTG)	TATA spare parts
550654608281	BRACKET GEAR BOX INLINE CONN MTG	TATA spare parts
550654608286	L BKT FOR BATTERY CABLE MTG BS6	TATA spare parts
550654609954	STICKER FUSE & RELAY	TATA spare parts
550654610121	BRACKET ASSY INLINE CONN & BOX MTG	TATA spare parts
550654610131	WIRING HARNESS ABS FRAME 4S3M	TATA spare parts
550654610141	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
550654610144	BATTERY CABLE +VE BS6	TATA spare parts
550654610168	WIRING HARNESS FLOOR BS6	TATA spare parts
550654610170	WIRING HARNESS ABS FRAME	TATA spare parts
550654610171	WIRING HARNESS ABS FRAME	TATA spare parts
550654610174	WIRING HARNESS FLOOR	TATA spare parts
550654610175	BATTERY CABLE +VE BCS TO MEGA FUSE BS6	TATA spare parts
550654610176	STARTER CABLE	TATA spare parts
550654610181	WIRING HARNESS ABS FRAME	TATA spare parts
550654610182	WIRING HARNESS FRONT CHASSIS	TATA spare parts
550654610184	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
550654619914	STICKER FUSE & RELAY BOX BS6-PH2	TATA spare parts
550654620107	WIRING HARNESS REAR CHASSIS	TATA spare parts
550654620108	BRACKET ASSY FUSE BOX MTG	TATA spare parts
550654620113	WIRING HARNESS REAR CHASSIS	TATA spare parts
550654620114	WIRING HARNESS REAR CHASSIS	TATA spare parts
550654620118	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
550654620119	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
550654620125	WIRING HARNESS ROOF BS6	TATA spare parts
550654620126	WIRING HARNESS INSTRUMENT PANEL BS6	TATA spare parts
550654620129	WIRING HARNESS ENGINE BS6	TATA spare parts
550654620131	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts

550654620135	WIRING HARNESS FIREWALL	TATA spare parts
550654620136	W/H ROOF	TATA spare parts
550654620138	WIRING HARNESS ENGINE	TATA spare parts
550654620150	STARTER CABLE BS6	TATA spare parts
550654620152	WIRING HARNESS EGP PIGTAIL BS6	TATA spare parts
550654620154	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
550654620155	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
550654629901	WIRING HARNESS REAR LPO 7.5T 4200 WB	TATA spare parts
550654629909	LOAD BODY HARNESS(9.6T 7.5T 497 3L ENG	TATA spare parts
550654629910	LOAD BODY HARNESS(9.6T 7.5T 497 3L ENG 3	TATA spare parts
550654629911	NDLB WH 9.6T 3310WB	TATA spare parts
550654629945	IP HARNESS WIDER CAB RHD-W/O EBOX	TATA spare parts
550654629946	WIRING HARNESS 9.6T 497 ENG FRONT CHASSI	TATA spare parts
550654629947	WIRING HARNESS 9.6T 497 ENGINE-W/O EBOX	TATA spare parts
550654629983	WIRING HARNESS FRONT CHASSIS	TATA spare parts
550654629985	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
550654629995	WIRING HARNESS FRONT CHS WITH NABS&FV(49	TATA spare parts
550654629997	WIRING HARNESS WIDER CAB RHDW/O EBO	TATA spare parts
550654630109	WIRING HARNESS REAR CHASSIS¿BS6	TATA spare parts
550654630140	WIRING HARNESS REVERSE PARK ASSIST BS6-P	TATA spare parts
550654630155	WIRING HARNESS-REVERSE PARK ASSIST BS6	TATA spare parts
550654630157	WIRING HARNESS EGP PIGTAIL BS6-PH2	TATA spare parts
550654630162	WIRING HARNESS FRONT CHASSIS BS6-PH2	TATA spare parts
550654630165	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
550654640207	BATTERY CABLE +VE BS6-PH2	TATA spare parts
550654709903	FREQUENCY DIVIDER	TATA spare parts
550654709905	VEHICLE ELECTRONIC CONTROLLER UNIT BS6	TATA spare parts
550654709907	VEHICLE ELECTRONIC CONTROLLER UNIT BS6	TATA spare parts
550654800102	BRACKETASSYABSECUMTG BS6	TATA spare parts
550654800105	ANTENNA CABLE BS6	TATA spare parts
550654800106	CABLE BS6	TATA spare parts
550654900103	BRACKET ASSY DOSING CONTROLLER UNIT MTG	TATA spare parts
550654904901	DC TO DC CONVERTER BS1/2/3/4/6	TATA spare parts
550654904907	DC TO DC CONVERTER BS6	TATA spare parts
550658902405	DRIFT	TATA spare parts
550658902601	PULLER	TATA spare parts
550658902602	PULLER	TATA spare parts
550658902603	PULLER	TATA spare parts
550658902605	PULLER GEAR BOX REAR HALF HSG	TATA spare parts
550658902606	DRIFT	TATA spare parts
550658902608	DRIFT	TATA spare parts
550658902612	DRIFT	TATA spare parts
550658902613	DRIFT	TATA spare parts
550658902614	DRIFT	TATA spare parts
550658902615	DRIFT	TATA spare parts
550658902616	DRIFT	TATA spare parts
550658902617	SPANNER	TATA spare parts



550658902618	SPANNER BS6	TATA spare parts
550658902620	TOOL BS6	TATA spare parts
550658902621	REMOVAL TOOL BS6	TATA spare parts
550658902623	REMOVAL TOOL BS6	TATA spare parts
550658903501	DRIFT	TATA spare parts
55066000006R40	ASSEMBLY BODY FITTED	TATA spare parts
55066000007L40	ASSEMBLY BODY FITTED	TATA spare parts
55066000007R40	PARTIAL FITTED CAB ULTRA 814	TATA spare parts
55066000018R40	ASSEMBLY BODY FITTED	TATA spare parts
55066000037R40	ASSY BODY COMPLETE W/O FITMENT BS6	TATA spare parts
55066000139R40	ASSLY CAB COMPLETE W/O FITMENT BS6	TATA spare parts
550660CK0198	TATA ULTRA 512-33 E-III (MALAYSIA)	TATA spare parts
550660CK0199	TATA ULTRA 1014-45WB BS4 (AIR BRAKE)	TATA spare parts
550715100104	CE BRACKET ASSY	TATA spare parts
550715149901	STARTER MOTOR 24V 4.5KW 5L ENG M/S.BOSCH	TATA spare parts
550715149902	STARTER MOTOR 24V 4.5KW WITH TCO BS3/4/6	TATA spare parts
550715149904	SOLENOID SWITCH ASSEMBLY	TATA spare parts
550715149905	FIXING BRACKET ASSEMBLY	TATA spare parts
550715149906	ENGAGING LEVER ASSEMBLY	TATA spare parts
550715149907	DRIVE ASSEMBLY	TATA spare parts
550715149908	INTER BRACKET ASSEMBLY	TATA spare parts
550715149909	ANNULUS	TATA spare parts
550715149910	RUBBER CUSHION	TATA spare parts
550715149911	OUTPUT SHAFT ASSEMBLY	TATA spare parts
550715149912	COVER PLATE ALTERNATOR	TATA spare parts
550715149913	ARMATURE ASSEMBLY	TATA spare parts
550715149914	BALL BEARING	TATA spare parts
550715149916	BRUSH GEAR ASSY	TATA spare parts
550715149917	CE BRACKET	TATA spare parts
550715149918	RELAY ASSEMBLY	TATA spare parts
550715149919	CABLE ASSEMBLY FINAL	TATA spare parts
550715149923	SPRING WASHER RELAY	TATA spare parts
550715149932	FLANGE NUT(M10)	TATA spare parts
550715149935	BRUSH ASSEMBLY KIT	TATA spare parts
550715149938	RELAY ASSEMBLY KIT	TATA spare parts
550715149945	FASTNERS KIT	TATA spare parts
550715149946	BRUSH ASSEMBLY KIT	TATA spare parts
550715400103	3L NGE/ALTERNATOR 24V 150A 8PK	TATA spare parts
550715400104	DRIVE END SHIELD BS6	TATA spare parts
550715400105	ROTOR BS6	TATA spare parts
550715400106	STATOR BS6	TATA spare parts
550715400107	RECTIFIER BS6	TATA spare parts
550715400108	BALL BEARING BS6	TATA spare parts
550715400109	SLIP RING END SHIELD BS6	TATA spare parts
550715404903	REGULATOR BS6	TATA spare parts
550715405301	PROTECTIVE CAP BS6	TATA spare parts
550715406501	HEXAGON NUT BS6	TATA spare parts

550715406502	HEX NUT BS6	TATA spare parts
550715407002	PULLEY BS6	TATA spare parts
550715407801	FITTING RING BS6	TATA spare parts
550715408001	HEX FLANGE SCREW BS6	TATA spare parts
550715409201	SPRING WAHSER BS6	TATA spare parts
550715409905	ALTERNATOR 12V 90A FOR 5L ENG	TATA spare parts
550715409909	ALTERNATOR 12V 90A FOR 497 ENG	TATA spare parts
550715409912	SCREW AND WASHHER ASSEMBLY BS6	TATA spare parts
550715409915	ALTERNATOR_12V_150A_497ENG_180DEG	TATA spare parts
550715409919	D E BRACKET ASSY	TATA spare parts
550715409920	FLANGE NUT	TATA spare parts
550715409922	DE FAN	TATA spare parts
550715409923	ROTOR AASY	TATA spare parts
550715409924	STATOR ASSY	TATA spare parts
550715409925	S R E BRACKET ASSY	TATA spare parts
550715409927	RECTIFIER ARRNG	TATA spare parts
550715409931	REGULATOR ASSY	TATA spare parts
550715409932	BRUSH ASSY	TATA spare parts
550715409936	REAR COVER	TATA spare parts
550715409937	NUT	TATA spare parts
550715409939	TERMINAL BUSH	TATA spare parts
550715409940	PULLEY	TATA spare parts
550715409958	OVAL¿HEAD¿SCREW	TATA spare parts
550715409983	D.E FAN BS6	TATA spare parts
550715449909	ALTERNATOR 24V 50A FOR 497 ENG	TATA spare parts
550715449916	ALTERNATOR C5 24V 80A WITH M5 BOLT REGUL	TATA spare parts
550715449917	ALTERNATOR 24V 80A 6PULLEY BS3/4/6	TATA spare parts
550715449919	ALTERNATOR C3 24V 50A FOR 497 ENG	TATA spare parts
550715449920	ALTERNATOR 6 PULLEY 24V 50A FOR 5L ENG	TATA spare parts
550715449925	PROTECTIVE CAP BS6	TATA spare parts
550715449926	OVALHEADSCREW BS6	TATA spare parts
550715449927	REGULATOR BS6	TATA spare parts
550715449928	RECTIFIER BS6	TATA spare parts
550715449929	STATOR ASSY BS6	TATA spare parts
550715449931	SPACER BS6	TATA spare parts
550715449932	PULLEY BS6	TATA spare parts
550715449933	DRIVE AND SHIELD ASSY BS6	TATA spare parts
550716100101	CONTAINER PART NO. FOR 9.6T 497 BSIII EN	TATA spare parts
550716100103	CONTAINER PART NO.9.6T 497E BS3 4.125RAR	TATA spare parts
550716204901	ECU	TATA spare parts
550716204902	ELECTRONIC MANAGMENT SYSTEM BS6	TATA spare parts
550724000101	BRACKET ASSY ENGINE MTG FRONT-LH BS6	TATA spare parts
550724000102	BRACKET ASSY ENGINE MTG FRONT-RH BS6	TATA spare parts
550724000103	BRACKET ASSY ENGINE MTG REAR-TOP BS6	TATA spare parts
550724000104	SUPPORT PLATE ASSY BOTTOM BS6	TATA spare parts
550724100117	497 FRONT LH ENGINE RUBBER MOUNT	TATA spare parts
550724100118	ASSY.ENGINE MOUNT BRACKET FRONT RH	TATA spare parts

550724100119	ASSY.ENGINE MOUNT BRACKET FRONT LH	TATA spare parts
550724100120	497 FRONT RH ENGINE RUBBER MOUNT	TATA spare parts
550724100129	RUBBER MTG FRONT-LH BS3/4/6	TATA spare parts
550724100130	RUBBER MTG FRONT-RH BS3/4/6	TATA spare parts
550724100138	ENGINE MOUNT ASSY FRONT-LH BS6	TATA spare parts
550724100139	ENGINE MOUNT ASSY FRONT-RH BS6	TATA spare parts
550724100156	FRONT ENGINE MOUNTING ASSY RH	TATA spare parts
550724100157	FRONT ENGINE MOUNTING ASSY LH	TATA spare parts
550724100160	LH-ASSY ENGINE MOUNTING BRACKET FRONT LP	TATA spare parts
550724100161	RH-ASSY ENGINE MOUNTING BRACKET FRONT LP	TATA spare parts
550724100162	TUBE ASSEMBLY FOR FRONT ENGINE MOUNT (LP	TATA spare parts
550724200108	ENGINE MOUNTING REAR BS3/4/6	TATA spare parts
550724200110	REAR ASSEMBLY BRACKET LH - 497 ENGINE SI	TATA spare parts
550724200111	REAR ENGINE MOUNT ASSEMBLY RH	TATA spare parts
550724200112	REAR ENGINE MOUNT ASSEMBLY LH	TATA spare parts
550724200115	REAR ASSEMBLY BRACKET RH - 497 ENGINE SI	TATA spare parts
550724200120	BRACKET ASSY ENGINE MTG REAR BS6	TATA spare parts
550724200127	BRACKET ASSY BS6-PH2	TATA spare parts
550724200130	BRACKET ASSY ENGINE MTG REAR BS6-PH2	TATA spare parts
550724200153	ASSY.ENGINE MOUNTING BKT RH .REAR UPPER	TATA spare parts
550724200154	ASSY.REAR ENGINE MOUTNG BKT LH UPPER 497	TATA spare parts
550724200156	ASSY.REAR ENGINE MOUNTING BKT	TATA spare parts
550729000121	ASSEMBLY CLUTCH COMPLETE	TATA spare parts
550729000124	ASSEMBLY COMPLETE CONTROL (DAOH BRAKE)	TATA spare parts
550729000126	CLUTCH PEDAL ASSY WITH MTG BKT	TATA spare parts
550729000127	ASSEMBLY COMPLETE BRAKE CONTROL (LHD)	TATA spare parts
550729000133	ASSEMBLY COMPLETE CLUTCH CONTROL	TATA spare parts
550729000261	ASSEMBLY CLUTCH ACTUATION COMPLETE	TATA spare parts
550729000262	ASSEMBLY BRAKE COMPLETE	TATA spare parts
550729000271	BRAKE PEDAL ASSY WITH MTG BRACKET	TATA spare parts
550729100103	OIL RESERVIOR TANK FOR CLUTCH (RHD)	TATA spare parts
550729100104	OIL RESERVIOR TANK CLUTCH	TATA spare parts
550729100124	BRACKET ASSEMBLY FOR 3 LIT	TATA spare parts
550729100150	CLUTCH PIPING	TATA spare parts
550729100157	PIPE FOR 3LITBOOSTER ON 3LIT ENGINE	TATA spare parts
550729100162	CLUTCH PIPE	TATA spare parts
550729100167	HOSE PIPE FOR LPT9.6/7.5T	TATA spare parts
550729100168	HOSE PIPE FOR LP/LPO 9.6/7.5T BS4	TATA spare parts
550729100204	CLUTCH PEDAL ASSY WITH BUSH BS6-PH2	TATA spare parts
550729100211	COMPLETE ASSEMBLY CLUTCH PEDAL	TATA spare parts
550729100241	CLUTCH PIPE	TATA spare parts
550729100247	HOSE PIPE LP BUS	TATA spare parts
550729100249	BUNDY TUBE ASSY CLUTCH PIPE	TATA spare parts
550729100250	CLUTCH HOSE PIPE LP BUS LHD	TATA spare parts
550729100282	ASSEMBLY CLUTCH PEDAL COMPLETE BS6	TATA spare parts
550729103402	NORGLIDE BUSH	TATA spare parts
550729108604	SPACER	TATA spare parts

550729109905	CLUTCH PEDAL STOPPER	TATA spare parts
550729200117	BRAKE PEDAL ASSY WITH MTG BRKT BS6-PH2	TATA spare parts
550729200118	BRAKE PEDAL ASSY WITH BUSH BS6-PH2	TATA spare parts
550729200123	ASSEMBLY BRAKE PEDAL LEVER COMPLETE	TATA spare parts
550729200126	ASSEMBLY COMPLETE BRAKE CONTROL	TATA spare parts
550729200242	BRAKE PEDAL ASSY WITH BUSH BS6-PH2	TATA spare parts
550729200243	BRAKE PEDAL ASSY WITH MTG BRACKET BS6	TATA spare parts
550729200261	BRAKEPEDALASSY BS6	TATA spare parts
550729203401	NORGLIDE BUSH	TATA spare parts
550729208604	SPACER	TATA spare parts
550729208651	SPACER	TATA spare parts
550729300102	CLUTCH PIPE	TATA spare parts
550729300106	PUSHROD ASSEMBLY FOR TRUCK	TATA spare parts
550729300107	BUNDY TUBE ASSY CMC TO FIREWALL	TATA spare parts
550729300109	BUNDY TUBE ASSY MIDDLE	TATA spare parts
550729300119	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
550729300123	BUNDY TUBE ASSY BS6	TATA spare parts
550729300124	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
550729300126	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
550729300129	BUNDY TUBE ASSY CMC TO FIREWALL BS6	TATA spare parts
550729300130	PIPE ASSY CMC TO BOOSTER BS6-PH2	TATA spare parts
550729500104	ASSEMBLY CONTROL MOUNTING BRACKET	TATA spare parts
550729500108	ASSEMBLY MOUNTING BRACKET (DAOH BRAKE)	TATA spare parts
550729500251	ASSEMBLY MOUNTING BRACKET (CLUTCH) BS6	TATA spare parts
550729500252	ASSY CONTROL MTG BKT (DAOH) BS6	TATA spare parts
550729500257	MOUNTING BRACKET ASSEMBLY FOR BOOSTER	TATA spare parts
550730100102	ACCELERATOR MODULE BS3/4	TATA spare parts
550730100104	ASSY.BUS ACCELERATOR PEDAL MTG.BKT	TATA spare parts
550730100115	ASM.ACCELERATOR PEDAL MTG.BKT.(SECONDARY)	TATA spare parts
550730100116	BRACKET ASSY ACCELERATOR PEDAL MTG	TATA spare parts
550730100117	ACCELERATOR PEDAL ASSY	TATA spare parts
550730100118	SUPPORT BRACKET ACCELERATOR PEDAL	TATA spare parts
550731000105	FRAME ASSY WITH TOP COAT	TATA spare parts
550731000121	ASSY.FRAME 9.6T-4530WB	TATA spare parts
550731000122	ASSY FRAME 9.6T-3920WB	TATA spare parts
550731000127	ASSY. FRAME WITH FITMENT BS3/4	TATA spare parts
550731000128	FRAME 9.6T-3920WB-497ENG WITH TOP COAT(S	TATA spare parts
550731000129	FRAME 9.6T-3310WB-497ENG WITH TOP COAT	TATA spare parts
550731000133	FRAME 9.6T-3L-4530WB WITH OUT TOP COAT	TATA spare parts
550731000134	FRAME 9.6T-3L-3920WB WITH OUT TOP COAT	TATA spare parts
550731000135	FRAME ASSY W/O TOP COAT	TATA spare parts
550731000136	FRAME ASSY WITH TOP COAT	TATA spare parts
550731000137	FRAME ASSY WITH TOP COAT	TATA spare parts
550731000138	FRAME ASSY WITH TOP COAT	TATA spare parts
550731000161	ASSY.FRAME LPO 5200WB 40 SEATER WITH 49	TATA spare parts
550731000162	ASSY.FRAME LPO 4920WB 36SEATER WITH 497	TATA spare parts
550731000163	ASSY.FRAME LPO 497E 5200WB WITH TOP COAT	TATA spare parts

550731000164	FRAME ASSY WITH TOP COAT	TATA spare parts
550731000165	FRAME ASSY WITH TOP COAT	TATA spare parts
550731000166	FRAME ASSY WITH TOP COAT	TATA spare parts
550731000193	FRAME ASSY WITH TOP COAT	TATA spare parts
550731000194	FRAME ASSY WITH TOP COAT	TATA spare parts
550731000195	FRAME ASSY WITH TOP COAT	TATA spare parts
550731010102	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
550731010107	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
550731010113	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
550731010119	FRAME ASSY WITH FITMENT BS6	TATA spare parts
550731010133	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55073101M10113	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
550731117104	LONG MEMBER RH BS6	TATA spare parts
550731117105	LONG MEMBER LH BS6	TATA spare parts
550731200103	CROSS MEMBER ASSY REAR	TATA spare parts
550731200104	CROSS MEMBER ASSY REAR EV	TATA spare parts
550731200152	ASSY BRACKET FES MOUNTING	TATA spare parts
550731200154	BRACKET ASSY FES MTG RH- BS6-PH2	TATA spare parts
550731200155	ASSY.BRACKET FES MOUNTING LH BS6-PH2	TATA spare parts
550731200157	ASSY.CROSS MEMBER	TATA spare parts
550731200170	L-BRACKETFESMTGRH BS6	TATA spare parts
550731200171	L-BRACKETFESMTGLH BS6	TATA spare parts
550731200174	BRACKET ASSY BS6	TATA spare parts
550731200175	L-BRACKET FES MTG RH BS6	TATA spare parts
550731200176	L-BRACKET FES MTG LH BS6	TATA spare parts
550731207111	CROSS MEMBER BS6-PH2	TATA spare parts
550731207164	L-BRACKET RH BS6	TATA spare parts
550731207165	L-BRACKET LH BS6	TATA spare parts
550731207173	L-BRACKETRH BS6	TATA spare parts
550731207174	L-BRACKETLH BS6	TATA spare parts
550731207178	L-BRACKET BS6	TATA spare parts
550731207179	L-BRACKET BS6	TATA spare parts
550731207180	L-BRACKET BS6	TATA spare parts
550731207181	L-BRACKET BS6	TATA spare parts
550731207184	L-BRACKET BS6	TATA spare parts
550731207187	L-BRACKET BS6	TATA spare parts
550731207188	L-BRACKET RH BS6	TATA spare parts
550731207189	L-BRACKET BS6	TATA spare parts
550731207194	L-BRACKET BS6	TATA spare parts
550731207195	L-BRACKET BS6	TATA spare parts
550731207196	L-BRACKET BS6	TATA spare parts
550731207198	L-BRACKET BS6	TATA spare parts
550731208203	CROSS MEMBER	TATA spare parts
550731208204	FRONT CROSS MEMBER	TATA spare parts
550731208260	REINFORCEMENT RH	TATA spare parts
550731208261	REINFORCEMENT LH	TATA spare parts
550731208264	ENGINE CM(FRONT) WITH TOP COAT	TATA spare parts

550731208267	BRACKET (ASSY.CROSSMEMBER)	TATA spare parts
550731208283	CROSS MEMBER BS6	TATA spare parts
550731208284	REINFORCEMENTRH BS6	TATA spare parts
550731208285	REINFORCEMENTLH BS6	TATA spare parts
550731208288	CROSS MEMBER BS6-PH2	TATA spare parts
550731208338	REINFORCEMENT RH BS6	TATA spare parts
550731208339	REINFORCEMENT LH BS6	TATA spare parts
550731218209	REINFORCEMENT RH BS6	TATA spare parts
550731218210	REINFORCEMENT LH BS6	TATA spare parts
550731240103	TUBE ASSY CROSS MEMBER	TATA spare parts
550731247101	PACKING PLATE	TATA spare parts
550731247102	PACKING PLATE	TATA spare parts
550731400102	ASSY BRACKET RH RUPD	TATA spare parts
550731400103	ASSY BRACKET LH RUPD	TATA spare parts
550731400104	ASSY.OF RUPD	TATA spare parts
550731400109	ASSY.CROSS MEMBER	TATA spare parts
550731400110	ASSY.CROSS MEMBER	TATA spare parts
550731400111	CROSSMEMBER ASSY	TATA spare parts
550731400112	ASSY.OF GUSSET	TATA spare parts
550731400120	CROSSMEMBERASSYBS6	TATA spare parts
550731400122	CROSS MEMBER ASSY BS6	TATA spare parts
550731400155	CROSS MEMBER ASSY BS6	TATA spare parts
550731400157	CROSS MEMBER ASSYBS6	TATA spare parts
550731400158	CROSS MEMBER ASSYBS6	TATA spare parts
550731400159	CROSS MEMBER ASSYBS6	TATA spare parts
550731400160	CROSS MEMBER ASSY BS6	TATA spare parts
550731400170	CROSS MEMBER ASSY	TATA spare parts
550731400172	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
550731407151	COBRA BRACKET	TATA spare parts
550731407154	GUSSET BS6	TATA spare parts
550731407169	L-BRACKET RH BS6	TATA spare parts
550731407170	L-BRACKET RH BS6	TATA spare parts
550731407171	L-BRACKET BS6	TATA spare parts
550731407172	L-BRACKET BS6	TATA spare parts
550731407179	L-BRACKET RH BS6-PH2	TATA spare parts
550731407180	L-BRACKET LH BS6-PH2	TATA spare parts
550731408209	REINFORCEMENT	TATA spare parts
550731408210	CLEAT	TATA spare parts
550731408227	GUSSET BS6	TATA spare parts
550731408228	GUSSET (SHB REAR)	TATA spare parts
550731408229	REINFORCEMENT RH (FRT SPG HANGER BRKT)	TATA spare parts
550731408230	REINFORCEMENT LH (FRT SPG HANGER BRKT)	TATA spare parts
550731408243	REINFORCEMENT RH	TATA spare parts
550731408244	REINFORCEMENT LH	TATA spare parts
550731408245	REINFORCEMENT RH	TATA spare parts
550731408246	REINFORCEMENT LH	TATA spare parts
550731408265	REINFORCEMENT	TATA spare parts

550731408266	REINFORCEMENT RH	TATA spare parts
550731408267	REINFORCEMENT LH	TATA spare parts
550731408286	REINFORCEMENT AUX.BRACKET	TATA spare parts
550731408287	REINFORCEMENT AUX.BRACKET REAR	TATA spare parts
550731408294	ENDCROSSMEMBER BS6	TATA spare parts
550731408297	CROSSMEMBER BS6	TATA spare parts
550731408300	REINFORCEMENTSFRINGHANGERBKTFRONT-RH B	TATA spare parts
550731408301	REINFORCEMENTSFRINGHANGERBKTFRONT-LH B	TATA spare parts
550731503701	TOWING HOOK	TATA spare parts
550731505101	TOW HOOK BS6	TATA spare parts
550731505102	TOW HOOK HOLDING BLOCK FRONT BS6	TATA spare parts
550731505103	TOW HOOK BS6	TATA spare parts
550731700114	FUPD MTG.RH	TATA spare parts
550731700115	FUPD MTG.LH	TATA spare parts
550731700116	FUPD CROSS MEMBER ASSY.	TATA spare parts
550731700120	RUPD ASSY	TATA spare parts
550731700122	FUPD CROSS BEAM ASSY	TATA spare parts
550731700123	FUPD MTG RH	TATA spare parts
550731700124	FUPD MTG LH	TATA spare parts
550731700129	BRACKET ASSY RUPD RH	TATA spare parts
550731700130	BRACKET ASSY RUPD LH	TATA spare parts
550732100117	ASSY.FIRST LEAF WITH BUSH	TATA spare parts
550732100130	ASSY.FRONT SPRING (RUBBER BUSH)	TATA spare parts
550732100132	ASSY.SPRING HANGER BRACKET FRONT RWD (RU	TATA spare parts
550732100136	ASSY.FIRST LEAF WITH VIBRACOUSTIC BUSHES	TATA spare parts
550732100139	ASSY.LEAF SPRING -FRONT	TATA spare parts
550732100143	FRONT PARABOLIC SPRING;ASSY(RUBBER BUSH)	TATA spare parts
550732100147	FIRST LEAF WITH¿ RUBBER BUSH	TATA spare parts
550732100148	FRONT SPRING ASSY (PARABOLIC)	TATA spare parts
550732100149	FIRST LEAF ASSY WITH BUSH	TATA spare parts
550732100149DF	MAIN LEAF FRONT W/BUSH PARA-9.6T/10.2T U	TATA spare parts
550732100152	FRONT SPRING ASSY BS6	TATA spare parts
550732100160	LEAF SPRING ASSY FRONT	TATA spare parts
550732100165	TIP¿INSERT	TATA spare parts
550732100170	BRACKET ASSY SPRING HANGER FRONT BS6-PH2	TATA spare parts
550732100174	BRACKET ASSY FRONT SPRING HANGER REAR	TATA spare parts
550732100181	CLAMP ASSY	TATA spare parts
550732100182	1ST LEAF ASSY WITH BUSH	TATA spare parts
550732100185	1ST LEAF ASSY WITH BUSH	TATA spare parts
550732100187	LEAF SPRING ASSY FRONT	TATA spare parts
550732100197	LEAF SPRING ASSY FRONT-LH BS6-PH2	TATA spare parts
550732101608	SPACER LPO 52 9.6T	TATA spare parts
550732101613	TIP INSERT	TATA spare parts
550732103201	CENTRE BOLT	TATA spare parts
550732103206	HEX BOLT	TATA spare parts
550732103301	BRACKET SPRING HANGER FRONT-FRONT	TATA spare parts
550732103302	BRACKET SPRING HANGER FRONT-REAR	TATA spare parts

550732103307	BRACKET SPRING HANGER FRONT-FRONT	TATA spare parts
550732103502	BOSS	TATA spare parts
550732103706	SPRING HANGER BKT.-FRONT FRD(RUBBER BUSH	TATA spare parts
550732103707	SPRING HANGER BKT.-FRONT (RUBBER BUSH)	TATA spare parts
550732104212	SPRING CLIP	TATA spare parts
550732104216	SPRING CLIP	TATA spare parts
550732104217	SPRING CLIP	TATA spare parts
550732104218	SPRING CLIP	TATA spare parts
550732104219	SPRING CLIP	TATA spare parts
550732104220	SPRING CLIP	TATA spare parts
550732104221	SPRING CLIP BS6	TATA spare parts
550732104222	SPRING CLIP	TATA spare parts
550732104223	SPRING CLIP	TATA spare parts
550732104224	CLAMP 25X6	TATA spare parts
550732104225	CLAMP	TATA spare parts
550732104229	SPRING CLIP	TATA spare parts
550732106702	AXLE LOCATING PIN (FRONT SUSPENSION)	TATA spare parts
550732106708	SPRING PIN	TATA spare parts
550732106902	FERRULE	TATA spare parts
550732107129	SUPPORT PLATE BS6	TATA spare parts
550732107155	4TH LEAF	TATA spare parts
550732107156	2ND LEAF	TATA spare parts
550732107157	3RD LEAF	TATA spare parts
550732107159	CASTER PLATE	TATA spare parts
550732107165	SECOND LEAF	TATA spare parts
550732107166	THIRD LEAF	TATA spare parts
550732107173	PACKING PLATE	TATA spare parts
550732107179	SECOND LEAF	TATA spare parts
550732107180	THIRD LEAF	TATA spare parts
550732107190	SECOND LEAF	TATA spare parts
550732107191	THIRD LEAF	TATA spare parts
550732107192	FOURTH LEAF	TATA spare parts
550732107194	SECOND LEAF	TATA spare parts
550732107194DF	SECOND LEAF FRONT PARA-9.6T/10.2T ULTRAB	TATA spare parts
550732107195	THIRD LEAF	TATA spare parts
550732107195DF	THIRD LEAF FRONT PARA-9.6T/10.2T ULTRABU	TATA spare parts
550732107196	FOURTH LEAF	TATA spare parts
550732107196DF	FOURTH LEAF FRONT PARA-9.6T/10.2T ULTRAB	TATA spare parts
550732107197	TOP PLATE	TATA spare parts
550732107401	RIVET DIA 10 BS6	TATA spare parts
550732107406	RIVET	TATA spare parts
550732107407	RIVET BS6	TATA spare parts
550732108301	CENTRE PAD (ASSY.LEAF SPRING)	TATA spare parts
550732110104	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
550732110106	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
550732110107	LEAF SPRING ASSY FRONT-RH BS6-PH2	TATA spare parts
550732117101	SPACER 70X10X130	TATA spare parts



550732117102	SPACER 70X7X130	TATA spare parts
550732117122	2ND LEAF	TATA spare parts
550732117123	3RD LEAF	TATA spare parts
550732117133	CASTER PLATE FRONT SPRING BS6-PH2	TATA spare parts
550732117134	4TH LEAF BS6-PH2	TATA spare parts
550732117136	3RD LEAF BS6-PH2	TATA spare parts
550732117137	2ND LEAF BS6-PH2	TATA spare parts
550732117138	4TH LEAF BS6-PH2	TATA spare parts
550732117139	2ND LEAF BS6-PH2	TATA spare parts
550732117140	3RD LEAF BS6-PH2	TATA spare parts
550732200103	ASSY. BUMP STOPPER	TATA spare parts
550732200105	ASSY. BUMP STOPPER	TATA spare parts
550732200107	BUMP STOPPER ASSY FRONT BS6-PH2	TATA spare parts
550732207102	CASTER PLATE	TATA spare parts
550732207103	CASTER PLATE	TATA spare parts
550732207107	SHACKLE BS6-PH2	TATA spare parts
550732300104	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
550732300105	ASSY.SHOCK ABSORBER MTG.BRACKET	TATA spare parts
550732300106	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
550732300112	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
550732300114	ASSY.SHOCK ABSORBER MTG.BRACKET	TATA spare parts
550732303305	BRACKET SHOCK ABSORBER MTG LOWER-LH	TATA spare parts
550732303306	BRACKET SHOCK ABSORBER MTG LOWER-RH	TATA spare parts
550732303702	BRACKET SHOCK ABS MTG.-LH (FRT FWD)	TATA spare parts
550732303703	BRACKET SHOCK ABS MTG.-RH (FRT FWD)	TATA spare parts
550732305101	BRACKET-LH (SHOCK ABS.CUM JACK MOUNTING)	TATA spare parts
550732305102	BRACKET-RH (SHOCK ABS.CUM JACK MOUNTING)	TATA spare parts
550732308210	SHOCK ABSORBER BRACKET BOTTOM-LH	TATA spare parts
550732308211	SHOCK ABSORBER BRACKET BOTTOM-RH	TATA spare parts
550732308212	LOCK SHEET	TATA spare parts
550732400120	ASSY.FIRST SPRING WITH BUSH	TATA spare parts
550732400124	ASSY.SHACKLE (FOR RUBBER BUSH)	TATA spare parts
550732400125	ASSY.REAR SHACKLE WITH RUBBER BUSH	TATA spare parts
550732400134	ASSY.REAR SPRING (RUBBER BUSH)	TATA spare parts
550732400136	REAR AXLE STOPPER ASSY	TATA spare parts
550732400137	ASSY.REAR AXLE STOPPER	TATA spare parts
550732400138	ASSY.REAR AXLE STOPPER	TATA spare parts
550732400139	REAR AXLE STOPPER ASSY.	TATA spare parts
550732400143	ASSY. FIRST LEAF WITH BUSHES	TATA spare parts
550732400144	ASSY.LEAF SPRING-REAR	TATA spare parts
550732400147	REAR SPRING ASSY WITH AUX.SPRING	TATA spare parts
550732400148	FIRST LEAF ASSY WITH BUSH	TATA spare parts
550732400148DF	MAIN LEAF REAR W/BUSH-ULTRA912/1012/1014	TATA spare parts
550732400153	REAR SPRING ASSY (PARABOLIC)	TATA spare parts
550732400154	FIRST LEAF ASSY WITH BUSH	TATA spare parts
550732400154DF	MAIN LEAF REAR W/BUSH PARA-9.6T/10.2T UL	TATA spare parts
550732400166	SHACKLE ASSY WITH RUBBER BUSH BS6	TATA spare parts

550732400187	LEAF SPRING ASSY REAR	TATA spare parts
550732400188	1ST LEAF ASSY WITH BUSH	TATA spare parts
550732400189	CLAMP ASSY	TATA spare parts
550732400190	LEAF SPRING ASSY REAR	TATA spare parts
550732400191	CLAMP ASSY	TATA spare parts
550732400192	1ST LEAF ASSY WITH BUSH	TATA spare parts
550732403204	CENTER BOLT BS6-PH2	TATA spare parts
550732403304	BRACKET SPRING HANGER REAR-REAR BS6-PH2	TATA spare parts
550732403402	NUT	TATA spare parts
550732403503	SPACER	TATA spare parts
550732403709	SLIDE SUPPORT (REAR SPRING)	TATA spare parts
550732403710	SPRING HANGER BRACKET (FOR RUBBER BUSH)	TATA spare parts
550732403712	SHACKLE BS6	TATA spare parts
550732403713	SPRING HANGER BRACKET REAR	TATA spare parts
550732404233	SPRING CLIP	TATA spare parts
550732404235	SPRING¿CLIP¿ BS6	TATA spare parts
550732406708	SPRING PIN (FOR RUBBER BUSH) BS3/4/6	TATA spare parts
550732406709	SPRING PIN (FOR RUBBER BUSH) BS3/4/6	TATA spare parts
550732406902	SPACER BS6-PH2	TATA spare parts
550732407122DF	SECOND LEAF REAR PARA-9.6T/10.2T ULTRABU	TATA spare parts
550732407123DF	THIRD LEAF REAR PARA-9.6T/10.2T ULTRABUS	TATA spare parts
550732407124DF	FOURTH LEAF REAR PARA-9.6T/10.2T ULTRABU	TATA spare parts
550732407153	SECOND LEAF	TATA spare parts
550732407154	THIRD LEAF	TATA spare parts
550732407184	SECOND LEAF	TATA spare parts
550732407185	THIRD LEAF	TATA spare parts
550732407186	FOURTH LEAF	TATA spare parts
550732407187	FIFTH LEAF	TATA spare parts
550732407188	SIXTH LEAF	TATA spare parts
550732407189	SEVENTH LEAF	TATA spare parts
550732407190	EIGHTH LEAF	TATA spare parts
550732407191	NINETH LEAF	TATA spare parts
550732407192	TENTH LEAF	TATA spare parts
550732407193	ELEVENTH LEAF	TATA spare parts
550732407195	SECOND LEAF (MAIN SPRING)	TATA spare parts
550732407195DF	SECOND LEAF REAR-ULTRA912/1012/1014/T.11	TATA spare parts
550732407196	THIRD LEAF (MAIN SPRING)	TATA spare parts
550732407197	FOURTH LEAF (MAIN SPRING)	TATA spare parts
550732407198	FIFTH LEAF (MAIN SPRING)	TATA spare parts
550732407199	SIXTH LEAF (MAIN SPRING)	TATA spare parts
550732407404	RIVETBS6	TATA spare parts
550732408401	SPACER FERRULE ID10XOD12X75)	TATA spare parts
550732408602	SPACER (LEAF SPRING MTG.)	TATA spare parts
550732408607	SPACER (LEAF SPRING MTG.)	TATA spare parts
550732408609	SPACER (ASSY.LEAF SPRING)	TATA spare parts
550732409201	SPACER BS6-PH2	TATA spare parts
550732410102	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts

550732410103	LEAF SPRING ASSY REAR BS6-PH2	TATA spare parts
550732410104	SPRING CLIP ASSY BS6-PH2	TATA spare parts
550732410106	BRACKET ASSY SPRING HANGER REAR BS6-PH2	TATA spare parts
550732410113	PAD REAR SPRING BS6-PH2	TATA spare parts
550732417101	SEVENTH LEAF (MAIN SPRING)	TATA spare parts
550732417102	EIGHTH LEAF (MAIN SPRING)	TATA spare parts
550732417103	NINETH LEAF (AUXILLARY SPRING)	TATA spare parts
550732417104	EIGHTH LEAF (AUXILLARY SPRING)	TATA spare parts
550732417105	SEVENTH LEAF (AUXILLARY SPRING)	TATA spare parts
550732417106	SIXTH LEAF (AUXILLARY SPRING)	TATA spare parts
550732417107	FIFTH LEAF (AUXILLARY SPRING)	TATA spare parts
550732417107DF	FIFTH LEAF AUX SPRING-ULTRA912/1012/1014	TATA spare parts
550732417108	FOURTH LEAF (AUXILLARY SPRING)	TATA spare parts
550732417108DF	FOURTH LEAF AUX SPRING-ULTRA912/1012/101	TATA spare parts
550732417109	THIRD LEAF (AUXILLARY SPRING)	TATA spare parts
550732417109DF	THIRD LEAF AUX SPRING-ULTRA912/1012/1014	TATA spare parts
550732417110	SECOND LEAF (AUXILLARY SPRING)	TATA spare parts
550732417110DF	SECOND LEAF AUX SPRING-ULTRA912/1012/101	TATA spare parts
550732417111	FIRST LEAF (AUXILLARY SPRING)	TATA spare parts
550732417122	SECOND LEAF	TATA spare parts
550732417123	THIRD LEAF	TATA spare parts
550732417124	FOURTH LEAF	TATA spare parts
550732417155	4TH LEAF	TATA spare parts
550732417156	3RD LEAF	TATA spare parts
550732417158	2ND LEAF	TATA spare parts
550732417161	3RD LEAF	TATA spare parts
550732427102	2ND LEAF	TATA spare parts
550732427108	2ND LEAF BS6-PH2	TATA spare parts
550732427109	3RD LEAF BS6-PH2	TATA spare parts
550732427110	4TH LEAF BS6-PH2	TATA spare parts
550732500102	SHACKLE ASSY BS6-PH2	TATA spare parts
550732503701	GUIDE PLATE BS6-PH2	TATA spare parts
550732504216	U CLAMP	TATA spare parts
550732504217	U-CLAMP	TATA spare parts
550732504220	U-CLAMP	TATA spare parts
550732507101	SHACKLE BS6-PH2	TATA spare parts
550732600112	ASSY.REAR SHOCK ABSORBER	TATA spare parts
550732600116	ASSY.REAR SHOCK ABSORBER	TATA spare parts
550732600119	ASSY.REAR SHOCK ABSORBER	TATA spare parts
550732600122	ASSY.SHOCK ABSORBER MTG.BKT.BOTTOM-LH BS	TATA spare parts
550732600123	ASSY.SHOCK ABSORBER MTG.BKT.BOTTOM-RH BS	TATA spare parts
550732800109	ASSY.ANTIROLL BAR WITH EYE	TATA spare parts
550732800112	RUBBER BUSH ASSY ANTI ROLL BAR	TATA spare parts
550732800116	ASSY.CONNECTING LINK	TATA spare parts
550732800117	ASSY.ANTIROLL BAR FRONT (WITH BUSHES)	TATA spare parts
550732800118	ASSY.FRONT ANTIROLL BAR COMPLETE	TATA spare parts
550732800122	ASSY.ANTIROLL BAR WITH BUSHES	TATA spare parts

550732800123	ASSY.ANTIROLL BAR COMPLETE	TATA spare parts
550732800125	CONNECTING LINK ASSY	TATA spare parts
550732800126	ASSY.ARB.MTG.BKT.(FRONT TOP)-RH	TATA spare parts
550732800127	ASSY.ARB.MTG.BKT.(FRONT TOP)-LH	TATA spare parts
550732800128	ASSY.CONNECTING LINK MTG.BRACKET	TATA spare parts
550732800132	ANTI ROLL BAR ASSY WITH LINK	TATA spare parts
550732800133	CONNECTING LINK ASSY FRONT	TATA spare parts
550732800135	ANTI ROLL BAR ASSY WITH LINK BS6	TATA spare parts
550732800140	ANTI ROLL BAR ASSY WITH LINK	TATA spare parts
550732800147	ANTI ROLL BAR ASSY WITH LINK BS6-PH2	TATA spare parts
550732800148	CONNECTING LINK ASSY FRONT BS6-PH2	TATA spare parts
550732800150	ANTI ROLL BAR ASSY WITH LINK BS6-PH2	TATA spare parts
550732803305	BRACKET ANTI ROLL BAR MTG LOWER-RH	TATA spare parts
550732803306	BRACKET ANTI ROLL BAR MTG LOWER-LH	TATA spare parts
550732806002	CONNECTING LINK BS6	TATA spare parts
550732807501	RUBBER BUSH(ASSY.ANTIROLL BAR MTG.) BS4	TATA spare parts
550732807504	RUBBER BUSH (ANTI ROLL BAR MTG.) BS4	TATA spare parts
550732807904	ANTIROLLBAR	TATA spare parts
550732807910	ANTI ROLL BAR BS6	TATA spare parts
550732808210	BRACKET(ASSY.CONNECTING LINK)	TATA spare parts
550732808215	BRACKET(ASSY.CONNECTING LINK)	TATA spare parts
550732808216	BRACKET (CONNECTING LINK ASSY.)	TATA spare parts
550732900107	ASSY. CONNECTING LINK MTG. BRACKET	TATA spare parts
550732900109	ANTI ROLL BAR ASSY COMP BUS REAR	TATA spare parts
550732900110	ANTI ROLL BAR ASSY WITH LINK	TATA spare parts
550732900116	ANTI ROLL BAR ASSY WITH LINK RR BS6-PH2	TATA spare parts
550732900117	CONNECTING LINK ASSY REAR BS6-PH2	TATA spare parts
550732903301	BRACKET ANTI ROLL BAR MTG LOWER-RH	TATA spare parts
550732903302	BRACKET ANTI ROLL BAR MTG LOWER-LH	TATA spare parts
550732903702	BRACKET(ASSY.ANTIROLL BAR MTG.)	TATA spare parts
550732903704	BRACKET-LH (ASSY.ANTIROLL BAR MTG.)	TATA spare parts
550732903705	BRACKET-RH (ASSY.ANTIROLL BAR MTG.)	TATA spare parts
550732907502	RUBBER BUSH (ASSY.ANTIROLL BAR MTG.)	TATA spare parts
550733000120	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
550733000126	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
550733000130	FRONT AXLE ASSY RHD (NON ABS) 9.6T Y1 BU	TATA spare parts
550733000134	ASSY FRONT AXLE COMPLETE	TATA spare parts
550733000159	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
550733000160	RETRO FITMENT KIT FOR Y1 9.6T FA (BUS)	TATA spare parts
550733000179	FRONT AXLE ASSEMBLY	TATA spare parts
550733000190	FRONT AXLE ASSY WITH BRAKE;ABS	TATA spare parts
550733000191	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
550733000195	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
550733000197	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
550733000203	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
550733000206	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
550733000207	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts

550733105102	FRONT AXLE BEAM	TATA spare parts
550733105103	FRONT AXLE BEAM-NORMAL	TATA spare parts
550733105105	FRONT AXLE BEAM_RUSSIA	TATA spare parts
550733105108	FRONT AXLE BEAM (NORMAL)	TATA spare parts
550733106701	COTTER PIN	TATA spare parts
550733106702	COTTER PIN	TATA spare parts
550733106705	COTTER PIN (FOR RETRO KIT PURPOSE)	TATA spare parts
550733200133	ASSY. OF STUB AXLE WITH BUSH (NORMAL)	TATA spare parts
550733200137	ASSY. STUB AXLE WITH BUSH-LH (NORMAL)	TATA spare parts
550733200141	STUB AXLE ASSY WIYH BUSH(RH)	TATA spare parts
550733200142	STUB AXLE ASSY-R.H(NORMAL)	TATA spare parts
550733200146	STUB AXLE ASSY WITH BUSH(LH)	TATA spare parts
550733200193	STUB AXLE ASSY ABS RH	TATA spare parts
550733200195	STUB AXLE ASSY LH	TATA spare parts
550733200197	STUB AXLE ASSY RH&BS6	TATA spare parts
550733200198	STUB AXLE ASSY LH&BS6	TATA spare parts
550733200201	STUB AXLE ASSY ABS RH BS6-PH2	TATA spare parts
550733200202	STUB AXLE ASSY RH BS6-PH2	TATA spare parts
550733200203	STUB AXLE ASSY ABS LH BS6-PH2	TATA spare parts
550733200204	STUB AXLE ASSY LH BS6-PH2	TATA spare parts
550733203201	MOUNTING BRACKET BOLT (LH STUB)	TATA spare parts
550733203204	HEX BOLT-M14X1.5X115 (USE IN TIE ROD ARM	TATA spare parts
550733203205	HEX BOLT -M14X1.5X47	TATA spare parts
550733203209	HEX.BOLT ( TIE ROD ARM)	TATA spare parts
550733203213	HEX. BOLT.	TATA spare parts
550733203215	HEX BOLT M14X94 IS 1364-12.9-SS 8451	TATA spare parts
550733203216	HEX BOLT M14X43 IS 1364-12.9-SS 8451	TATA spare parts
550733203217	HEX BOLT M14X109 IS:1364-12.9-SS:8451	TATA spare parts
550733203219	COLLARED PIN	TATA spare parts
550733205127	STUB AXLE BUS(RH)	TATA spare parts
550733205128	STUB AXLE BUS(LH)	TATA spare parts
550733206701	KING PIN BS3/4	TATA spare parts
550733206702	KING PIN (NORMAL)	TATA spare parts
550733206703	KING PIN (NORMAL-1)	TATA spare parts
550733206704	KING PIN (REPAIR-I)	TATA spare parts
550733206705	KING PIN (REPAIR-II)	TATA spare parts
550733206712	KING PIN(FOR RETRO KIT PURPOSE)	TATA spare parts
550733207701	O RING	TATA spare parts
550733207702	O RING	TATA spare parts
550733400105	FRONT HUB ASSY ( 9.6T BUS WITH 245 P.C.D	TATA spare parts
550733400107	FRONT HUB ASSY NON ABS	TATA spare parts
550733400109	FRONT HUB ASSY ( FOR NON ABS BUS) 9.6T	TATA spare parts
550733400116	FRONTHUBASSYWITHPINS	TATA spare parts
550733400122	TAPER ROLLER BEARING BS6-PH2	TATA spare parts
550733403105	Y1-9.6T/7.5T(BUS & TRUCK)THRUST BEARING	TATA spare parts
550733403108	THRUST BEARING NORMAL BS3/4/6	TATA spare parts
550733403707	COVER FRONT HUB BS6-PH2	TATA spare parts

550733403711	FRONT HUB ( 9.6T BUS WITH 245 P.C.D HOLE	TATA spare parts
550733403712	FRONT HUB BS6	TATA spare parts
550733405301	GASKET	TATA spare parts
550733405303	GASKET FRONT AXLE COVER BS6-PH2	TATA spare parts
550733405502	FRONT HUB ABS BS6-PH2	TATA spare parts
550733406701	HUB PIN FRONT	TATA spare parts
550733407801	OIL SEAL BS3/4	TATA spare parts
550733408201	KING PIN TOP COVER	TATA spare parts
550733408203	BAFFLE	TATA spare parts
550733408207	FRONT HUB COVER	TATA spare parts
550733409203	LOCK WASHER BS6-PH2	TATA spare parts
550733800110	TIE ROD ASSEMBLY	TATA spare parts
550733800111	TIE ROD ASSY. - 9.6T(BUS)	TATA spare parts
550733800115	TIE ROD ASSY	TATA spare parts
550733800116	TIE ROD ASSY	TATA spare parts
550733800120	TIE ROD ASSY	TATA spare parts
550733800122	TIE ROD ASSY BS6-PH2	TATA spare parts
550733804201	CLAMP	TATA spare parts
550733805108	STEERING ARM	TATA spare parts
550733805112	TIE ROD ARM ( RH) (BUS WITH 245 PCD DRUM	TATA spare parts
550733805113	TIE ROD ARM ( LH) (BUS WITH 245 PCD DRUM	TATA spare parts
550733805116	STEERING ARM	TATA spare parts
550733805124	TIE ROD ARM(RH)	TATA spare parts
550733805125	TIE ROD ARM (LH)	TATA spare parts
550733805126	TIE ROD ARM (RH) BS4	TATA spare parts
550733805127	TIE ROD ARM (LH) BS4	TATA spare parts
550733805131	TIE ROD ARM - RH	TATA spare parts
550733805132	TIE ROD ARM - LH	TATA spare parts
550733805135	STEERING ARM BS6	TATA spare parts
550733808503	Y1-9.6T/7.5T-SOCKET	TATA spare parts
550733809904	DUST COVER	TATA spare parts
550733809906	REPAIR KIT TIE ROD	TATA spare parts
550733990101	ASSY. BALL JOINT LH BS3/4	TATA spare parts
550733990102	ASSY. BALL JOINT RH BS3/4	TATA spare parts
550733990103	BALL JOINT ASSY LH BS4	TATA spare parts
550733990104	BALL JOINT ASSY RH BS4	TATA spare parts
550740100117	WHEEL RIM ASSY WITH VALVE BS6	TATA spare parts
550740100123	WHEEL RIM ASSY WITH VALVE BS6-PH2	TATA spare parts
550740100128	WHEEL RIM ASSY WITH VALVE BS6	TATA spare parts
550740100134	WHEEL RIM ASSY WITH VALVE EV	TATA spare parts
550740106701	HUB PIN	TATA spare parts
550740106702	HUB PIN REAR BS4	TATA spare parts
550740108201	WHEEL SPACER	TATA spare parts
550740109904	VALVE	TATA spare parts
550740109910	TUBELESS TYRE 235/75R 17.5	TATA spare parts
550740109912	TUBELESS TYRE	TATA spare parts
550740109921	TUBELESS RADIAL TYRE RIB 235/75 R 17.5	TATA spare parts

550740109942	TRANSFER LABEL TYRE PRESSURE	TATA spare parts
550740109951	VALVE EXTENSION	TATA spare parts
550740109953	CLIP BALANCE WEIGHT BS6	TATA spare parts
550740109970	TUBELESS TYRE	TATA spare parts
550740200109	ASSY. WHEEL RIM BS3/4/6	TATA spare parts
550740300105	ASSEMBLY SPARE WHEEL CARRIER	TATA spare parts
550740300111	SPARE WHEEL CARRIER ASSY.	TATA spare parts
550740307104	MOUNTING BRACKET FOR SPARE WHEEL CARRIE	TATA spare parts
550740307105	ATTACHMENT PLATE FOR SPARE WHEEL CARRIER	TATA spare parts
550740308214	HOLDINGBRACKET BS6	TATA spare parts
550741100101	GUARD ASSY PROPELLER SHAFT BS6	TATA spare parts
550741110121	ASSY.PROP SHAFT WITH CENETRE BEARING COM	TATA spare parts
550741110125	ASSY.PROP SHAFT WITH CENTER BEARING COMP	TATA spare parts
550741110162	MIDDLE ASSY.COUPLING SHAFT WITH CENTRE B	TATA spare parts
550741110163	MONOTRON SHAFT ASSY. 5200WB	TATA spare parts
550741110167	MONOTRON SHAFT ASSY.4920WB	TATA spare parts
550741110194	PROPELLER SHAFT MONOTRON ASSY	TATA spare parts
550741110197	COUPLING SHAFT ASSY WITH CENTER BEARING	TATA spare parts
550741110198	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
550741110199	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
550741110204	PROPELLER SHAFT MONOTRON ASSY	TATA spare parts
550741110208	PROPELLER SHAFT MONOTRON ASSY	TATA spare parts
550741110212	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
550741110213	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
550741110214	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
550741110217	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
550741110218	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
550741110219	PROPELLER SHAFT ASSY REAR BS6	TATA spare parts
550741110220	PROPELLER SHAFT ASSY WITH CB FRONT BS6	TATA spare parts
550741110221	PROPELLER SHAFT ASSY BS6	TATA spare parts
550741110223	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
550741110224	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
550741120129	ASSY.PROP.SHAFT REAR COMPLETE	TATA spare parts
550741120130	PROPELLER SHAFT ASSY DRIVE¿BS6	TATA spare parts
550741120180	PROPELLER SHAFT ASSY REAR	TATA spare parts
550741120186	DRIVE SHAFT ASSY COMPLETE	TATA spare parts
550741120188	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
550741120191	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
550741120210	PROPELLER SHAFT ASSY REAR	TATA spare parts
550741300117	BRACKET ASSY CENTER BRG MTG	TATA spare parts
550741307109	CENTER BEARING MTG BKT	TATA spare parts
550741307111	CENTER BEARING MTG BKT	TATA spare parts
550741307112	CENTER BEARING MTG BKT	TATA spare parts
550741307114	BRACKET CENTER BRG MTG	TATA spare parts
550741307115	CENTER BEARING MTG BKT SPL100	TATA spare parts
550741307116	BRACKET CENTER BRG MTG	TATA spare parts
550741307120	BRACKET CENTER BRG MTG BS6	TATA spare parts

550741307121	BRACKET CENTER BRG MTG BS6	TATA spare parts
550741307122	BRACKET CENTER BRG MTG (45WB) BS6	TATA spare parts
550741307123	BRACKET CENTER BRG MTG BS6	TATA spare parts
550741307128	BRACKET CENTER BRG MTG BS6	TATA spare parts
550741307129	BRACKET CENTER BRG MTG BS6	TATA spare parts
550741307130	BRACKET CENTER BRG MTG BS6	TATA spare parts
550741307140	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
550741307141	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
550741308211	CENTER BEARING MTG. BKT.-BUS	TATA spare parts
550741308216	SUPPORTING BRACKET OF CENTER BEARING MTG	TATA spare parts
550741308226	THE PROPELLER GUARD PART FOR 9.6T & 7.5T	TATA spare parts
550741308230	L-STRIP PROPELLER GUARD	TATA spare parts
550741308232	GUARD PROPELLER SHAFT BS6	TATA spare parts
550742100101	ASSLY CALIPER 68X68 LH	TATA spare parts
550742100102	ASSLY CALIPER 68X68 RH	TATA spare parts
550742100114	ASSLY F/A BRK -RH WITH DUST COVER	TATA spare parts
550742100115	ASSLY F/A BRK -LH WITH DUST COVER	TATA spare parts
550742100145	DRUM BRAKE KIT TORQUE PLATE LH	TATA spare parts
550742100146	DRUM BRAKE KIT TORQUE PLATE RH	TATA spare parts
550742100147	DRUM BRAKE KIT BRACKET ASSLY LH	TATA spare parts
550742100148	DRUM BRAKE KIT BRACKET ASSLY RH	TATA spare parts
550742100149	KIT BUSH	TATA spare parts
550742100150	SHIELD ASSLY TOP	TATA spare parts
550742100151	SHIELD ASSLY BOTTOM	TATA spare parts
550742100162	CALIPER ASSEMBLY - LH ( WITH FERODO PADS	TATA spare parts
550742100163	CALIPER ASSEMBLY - RH ( WITH FERODO PADS	TATA spare parts
550742100166	ASSY. AUTO SLK. ADJ. ST. FOR LWS BS3/4/6	TATA spare parts
550742100204	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
550742100205	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
550742100206	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
550742100207	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
550742100218	BRAKE ASSY FRONT-LH	TATA spare parts
550742100219	BRAKE ASSY FRONT-RH	TATA spare parts
550742100250	DRUM BRAKE ASSY WITH DC FRONT-LH BS6-PH2	TATA spare parts
550742100251	DRUM BRAKE ASSY WITH DC FRONT-RH BS6-PH2	TATA spare parts
550742100258	DRUM BRAKE ASSY WITH DC FRONT-LH BS6-PH2	TATA spare parts
550742100259	DRUM BRAKE ASSY WITH DC FRONT-RH BS6-PH2	TATA spare parts
550742103301	BRACKET CALIPER MTG.-RH (FORGED)_RB68X68	TATA spare parts
550742103302	BRACKET CALIPER MTG.-LH (FORGED)_RB68X68	TATA spare parts
550742103701	VENTILATED BRAKE DISC RB68X68 FA BS3	TATA spare parts
550742103703	BRAKE DRUM FRONT BS6	TATA spare parts
550742103705	BRAKE DRUM Y1 9.6T BUS(325 X 140) BS3/4	TATA spare parts
550742108203	SPLASH SHIELD RB68X68 FA	TATA spare parts
550742108219	ANCHOR BRACKET RH BS6	TATA spare parts
550742108221	ANCHOR BRACKET LH BS6	TATA spare parts
550742110119	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
550742110120	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts



550742110123	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
550742110124	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
550742110135	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
550742110136	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
550742110202	AUTO SLACK ADJUSTER ASSY REAR-LH	TATA spare parts
550742110203	AUTO SLACK ADJUSTER ASSY REAR-RH	TATA spare parts
550742110237	DRUM BRAKE ASSY WITH DC FRONT-LH BS6-PH2	TATA spare parts
550742110238	DRUM BRAKE ASSY WITH DC FRONT-RH BS6-PH2	TATA spare parts
550742110248	DRUM BRAKE ASSY WITH DC FRONT-LH BS6-PH2	TATA spare parts
550742110249	DRUM BRAKE ASSY WITH DC FRONT-RH BS6-PH2	TATA spare parts
550742300100	AUTO SLACK ADJUSTER ASSY REAR-LH BS6	TATA spare parts
550742300101	AUTO SLACK ADJUSTER ASSY REAR-RH BS6	TATA spare parts
550742300105	ASSLY. BRAKE DIA.320X110-RH(H2LS 34.95W/	TATA spare parts
550742300106	ASSLY. BRAKE DIA.320X110-LH(H2LS 34.95W/	TATA spare parts
550742300115	ASSLY.WHEEL CYL.DIA.34.95-LH W/ BLEEDER	TATA spare parts
550742300116	ASSLY.WHEEL CYL.DIA.34.95-RH W/ BLEEDER	TATA spare parts
550742300117	ASSLY.WHEEL CYL.DIA.34.95-LH W/O BLEEDER	TATA spare parts
550742300118	ASSLY.WHEEL CYL.DIA.34.95-RH W/O BLEEDER	TATA spare parts
550742300119	LINNED SHOE ASSY. 320X110	TATA spare parts
550742300135	ASY R/A BRK LH WITH DUST COVER	TATA spare parts
550742300136	ASY R/A BRK RH WITH DUST COVER	TATA spare parts
550742300153	KIT TORQUE PLATE	TATA spare parts
550742300154	KIT BUSH	TATA spare parts
550742300172	SHIELD ASSY. - TOP	TATA spare parts
550742300173	SHIELD ASSY. - BOTTOM	TATA spare parts
550742300198	BRAKE ASSY REAR AXLE LH	TATA spare parts
550742300199	BRAKE ASSY REAR AXLE RH	TATA spare parts
550742300210	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
550742300215	DRUM BRAKE ASSY R/A W/T D/C-LH	TATA spare parts
550742300216	DRUM BRAKE ASSY R/A W/T D/C-RH	TATA spare parts
550742300217	"WHEEL CYLINDER ASSY WITH BLEEDER,LH"	TATA spare parts
550742300218	"WHEEL CYLINDER ASSY W/O BLEEDER,LH"	TATA spare parts
550742300219	"WHEEL CYLINDER ASSY WITH BLEEDER,RH"	TATA spare parts
550742300220	"WHEEL CYLINDER ASSY W/O BLEEDER,RH"	TATA spare parts
550742300224	DRUM BRAKE ASSY LH DIA.320X110-34.95W/C	TATA spare parts
550742300225	DRUM BRAKE ASSY RH DIA.320X110-34.95W/C	TATA spare parts
550742300227	KIT-BRAKE LINED SHOE ASSY	TATA spare parts
550742300228	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
550742300229	KIT-BRAKE LINER SET-STD	TATA spare parts
550742300231	KIT-BRAKE LINER SET-1 O/S	TATA spare parts
550742300246	DRUM BRAKE ASSY WITH DC REAR-LH BS6-PH2	TATA spare parts
550742300247	DRUM BRAKE ASSY WITH DC REAR-RH BS6-PH2	TATA spare parts
550742300254	DRUM BRAKE ASSY WITH DC REAR-LH BS6-PH2	TATA spare parts
550742300255	DRUM BRAKE ASSY WITH DC REAR-RH BS6-PH2	TATA spare parts
550742300298	DRUM BRAKE ASSY WITH DC REAR-LH BS6-PH2	TATA spare parts
550742300299	DRUM BRAKE ASSY WITH DC REAR-RH BS6-PH2	TATA spare parts
550742303707	CASTILATED BRAKE DRUM DIA.320 X 110	TATA spare parts

550742303714	SENSOR.MTG.BKT FOR 9.6T-BUS REAR S-CAM32	TATA spare parts
550742303715	CHAMBER MTG.BKT. REAR - LH FOR 9.6T BUS	TATA spare parts
550742303716	CHAMBER MTG.BKT. REAR - RH FOR 9.6T BUS	TATA spare parts
550742303720	BRAKE DRUM DIA.325 X 140 BS3/4	TATA spare parts
550742303722	BRAKE DRUM BS6	TATA spare parts
550742303727	BRACKET ASSY SENSOR MTG BS6	TATA spare parts
550742303730	BRAKE DRUM	TATA spare parts
550742303731	BRAKE DRUM (140MM) BS6	TATA spare parts
550742303732	BRAKE DRUM BS6-PH2	TATA spare parts
550742305103	S-CAM SHAFT- LH (325X140)	TATA spare parts
550742305104	S-CAM SHAFT- RH(325X140)	TATA spare parts
550742307501	RUBBER GROMMET_ RA DR-BRK.(ABS) BS6	TATA spare parts
550742308219	BRACKET-LH_ABS CONNECTOR MTG._ RA BS6	TATA spare parts
550742308220	BRACKET-RH_HOSE & ABS CONNECTOR MTG BS6	TATA spare parts
550742310103	DRUM¿BRAKE¿ASSY¿WITH¿DC REAR-LH	TATA spare parts
550742310104	DRUM¿BRAKE¿ASSY¿WITH¿DC REAR-RH	TATA spare parts
550742310108	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
550742310109	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
550742310134	DRUM BRAKE ASSEMBLY WITH DC RRRH BS6	TATA spare parts
550742310139	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
550742310140	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
550742310146	DRUM BRAKE ASSEMBLY WITH DC RRLH BS6	TATA spare parts
550742310206	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
550742310207	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
550742310214	DRUM BRAKE ASSY WITH DC REAR-LH BS6-PH2	TATA spare parts
550742310215	DRUM BRAKE ASSY WITH DC REAR-RH BS6-PH2	TATA spare parts
550742400101	ASSY. BRACKET (LCRV MOUNTING)	TATA spare parts
550742400103	ASSY LCRV LINKAGE (M12XM12)	TATA spare parts
550742400105	BRACKET ASSY LCRV PULL ROD	TATA spare parts
550742700101	ASSLY. BRAKE 220X45 DUO SERVO W/ SBL LIN	TATA spare parts
550742700108	ASSY BRACKET (PARKING CABLE BKT)-ON GEAR	TATA spare parts
550742700111	ASSY PARKING BRAKE CABLE (DIA 220)	TATA spare parts
550742700116	ASSY PARKING BRAKES LEVER	TATA spare parts
550742700128	ASSY.SHOE LINER AF	TATA spare parts
550742700131	ASSY MOUNTING BRACKET (PARKING CABLE)	TATA spare parts
550742700138	ASSY PARKING BRAKE CABLE (LONG CABLE)	TATA spare parts
550742700139	ASSY PARKING BRAKE CABLE (BRAKE END)	TATA spare parts
550742703702	PARKING BRAKE DRUM 220X45(FOR GB550)	TATA spare parts
550742708204	PARKING CABLE OUTER HOLDING BRACKET	TATA spare parts
550742708210	BRACKET (PARKING CABLE HOLDING)	TATA spare parts
550742990101	KIT CALIPER (MAJOR)	TATA spare parts
550742990102	KIT CALIPER (MINOR)	TATA spare parts
550742990103	CARRIER SUB ASSY-LH	TATA spare parts
550742990104	CARRIER SUB ASSY-RH	TATA spare parts
550742990105	KIT BRIDGE BOLT	TATA spare parts
550742990106	KIT SLIDING PIN	TATA spare parts
550742990107	KIT BLEED SCREW	TATA spare parts

550742990108	KIT PAD ASSEMBLY (FER 3422 GRADE)	TATA spare parts
550742990109	KIT GUIDE PIN	TATA spare parts
550742990110	INDICATOR CABLE ASSEMBLY (PAD)	TATA spare parts
550742990111	KIT-BRACKET ASSY LH BS6	TATA spare parts
550742990113	ASSLY.BACK PLATE-LH	TATA spare parts
550742990114	ASSLY.BACK PLATE-RH	TATA spare parts
550742990115	ASSLY.BRIDGE PIPE	TATA spare parts
550742990119	KIT WHEEL CYL.- MAJOR	TATA spare parts
550742990120	KIT WHEEL CYLINDER MINOR	TATA spare parts
550742990121	KIT CAM SCREW	TATA spare parts
550742990122	KIT BLEED SCREW	TATA spare parts
550742990123	KIT LINED SHOE ASSLY.	TATA spare parts
550742990124	KIT-LINING SET BS3	TATA spare parts
550742990125	KIT SHOE HOLD DOWN	TATA spare parts
550742990126	BACK PLATE ASSEMBLY	TATA spare parts
550742990127	KIT LINED SHOE	TATA spare parts
550742990130	KIT SHOE HOLD DOWN	TATA spare parts
550742990131	KIT ADJUSTER ASSY	TATA spare parts
550742990133	KIT HAND BRAKE LEVER	TATA spare parts
550742990141	KIT FRONT PAD BS3	TATA spare parts
550742990143	DRUM BRAKE KIT SPRING	TATA spare parts
550742990145	KIT-DUST SHIELD ASSY.	TATA spare parts
550742990146	DRUM BRAKE KIT DUST SHIELD	TATA spare parts
550742990150	KIT-BRAKE SHOE WITH LINER	TATA spare parts
550742990166	DRUM BRAKE KIT-DUST SHIELD	TATA spare parts
550742990167	KIT-BRACKET ASSY RH BS6	TATA spare parts
550742990168	ADJUSTER ASSY	TATA spare parts
550742990170	KIT-BRAKE DUST SHIELD ASSY BS6	TATA spare parts
550742990173	KIT SPRING DRUM BRAKE	TATA spare parts
550742990174	SPRING CAM END	TATA spare parts
550742990176	DRUM BRAKE ASSY -KIT TORQUE PLATE LH	TATA spare parts
550742990177	DRUM BRAKE ASSY -KIT TORQUE PLATE RH	TATA spare parts
550742990178	KIT-BRAKE	TATA spare parts
550742990181	TORQUE PLATE FRONT-LH BS6-PH2	TATA spare parts
550742990182	TORQUE PLATE FRONT-RH BS6-PH2	TATA spare parts
550742990183	TORQUE PLATE FRONT-LH BS6-PH2	TATA spare parts
550742990184	TORQUE PLATE FRONT-RH BS6-PH2	TATA spare parts
550742990189	DUST COVER TOP BS6-PH2	TATA spare parts
550742990190	DUST COVER BOTTOM BS6-PH2	TATA spare parts
550742990194	BRAKE SHOE ASSY BS6-PH2	TATA spare parts
550742990201	RETRO KIT FOR VEHICLE	TATA spare parts
550742990202	KIT LINED SHOE ASSY BS6-PH2	TATA spare parts
550742990206	BRAKE LINING-325X155 AFF0028 STD BS6-PH2	TATA spare parts
550742990208	BRAKE LINING-325X155 AFF0028 OS1 BS6-PH2	TATA spare parts
550742990210	BRAKE LINING-325X155 AFF0028 OS2 BS6-PH2	TATA spare parts
550742990212	KIT SPRING BS6-PH2	TATA spare parts
550742990279	BRAKE LINING STD-325X140 CS AFF0028 BS6-	TATA spare parts

550742990283	BRAKE LINING OS1-325X140 CS AFF0028 BS6-	TATA spare parts
550742990285	KIT-BRAKE SHOE ASSY FRONT BS6-PH2	TATA spare parts
550742990287	BRAKE LINING OS2-325X140 CS AFF0028 BS6-	TATA spare parts
550742990289	KIT-BRAKE SHOE ASSY BS6-PH2	TATA spare parts
550742994302	CLIP - FOR BUNDY TUBE	TATA spare parts
550742994304	CLIP ANTI-ROTATION BS6	TATA spare parts
550742994306	CIRCLIP	TATA spare parts
550742996501	ADJUSTER BS6	TATA spare parts
550742996703	PIN SHOE HOLD DOWN BS6	TATA spare parts
550742997501	GROMMET - ADJUSTER WINDOW	TATA spare parts
550742997502	GROMMET - LINING INSPECTION WINDOW	TATA spare parts
550742997503	GROMMET	TATA spare parts
550742997704	PROTECTIVE PLUG	TATA spare parts
550742997705	CAP-BLEED SCREW	TATA spare parts
550742997707	PROTECTOR- FOR BUNDY TUBE	TATA spare parts
550742998002	SET SCREW- FOR WHEEL CYL.	TATA spare parts
550742998003	ADJUSTER SCREW	TATA spare parts
550742998201	STRUT	TATA spare parts
550742998701	SPRING SHOE HOLD DOWN BS6	TATA spare parts
550742998702	SPRING - SHOE RETURN	TATA spare parts
550742998705	SPRING SHOE RETURN	TATA spare parts
550742998706	SPRING ABUTMENT END (DIA 220X45 PARKING)	TATA spare parts
550742998708	SPRING - ABUTMENT END	TATA spare parts
550742999201	SPRING WASHER- FOR WHEEL CYL.	TATA spare parts
550742999203	SHOE ASSY	TATA spare parts
550742999204	WASHER	TATA spare parts
550742999901	GREASE SACHET	TATA spare parts
550743100110	ASSY. MASTER CYLINDER WITH RESERVOIR	TATA spare parts
550743200108	SUB ASSY. AIR TANK (20 LIT) 118 STRAP CE	TATA spare parts
550743200109	AIR TANK ASSY LH BS6	TATA spare parts
550743200112	AIR TANK ASSY WITH SEALING PLUG	TATA spare parts
550743200116	AIR TANK ASSY WITH SEALING PLUG	TATA spare parts
550743200118	AIR TANK ASSY RH BS6	TATA spare parts
550743200122	AIR TANK ASSY WITH MTG BKT BS6	TATA spare parts
550743200123	AIR TANK ASSY BS6	TATA spare parts
550743200125	BRACKET ASSY LH BS6-PH2	TATA spare parts
550743200126	BRACKET ASSY BS6-PH2	TATA spare parts
550743200127	AIR TANK ASSY WITH BKTS & STRAP BS6	TATA spare parts
550743200128	AIR TANK ASSY WITH BKTS & STRAP BS6	TATA spare parts
550743200135	AIR TANK ASSY WITH MTG BKT BS6	TATA spare parts
550743400101	ASSY. EXHAUST BRAKE UNIT DIA 80	TATA spare parts
550743700105	ASSY AIR CYLINDER WITH MTG BRACKET	TATA spare parts
550743700108	AIR DRYER	TATA spare parts
550743700109	SYSTEM PROTCTION VALVE	TATA spare parts
550743700111	PRESSURE LIMITING VALVE	TATA spare parts
550743700113	AIR CYL ASSY	TATA spare parts
550743700114	AIR COMPRESSOR ASSY 160 CC GEAR DRIVEN	TATA spare parts

550743700119	ASSY BRACKET RELAY VALVE MTG.	TATA spare parts
550743700122	SOLENOID VALVE 12V	TATA spare parts
550743700126	RETRO FITMENT KIT FOR BRAKE Y1 LPO 497	TATA spare parts
550743700128	BRACKET ASSY HBV MTG BS6	TATA spare parts
550743700129	SPRING BRAKE ACTUATOR TYPE12/12 VOSS+MET	TATA spare parts
550743700130	BRAKE CHAMBER TYPE 12 LH	TATA spare parts
550743700131	REMOTE SILENCER (DBV EXHAUST)	TATA spare parts
550743700133	ASSY TWO POLE LP SWITCH (3.2 BAR)	TATA spare parts
550743700137	HAND BRAKE VALVEç 550643701602	TATA spare parts
550743700142	KIT 160CC GEAR DRIVEN COMP MINOR REPAIR	TATA spare parts
550743700143	KIT 160CC GEAR DR. COMP MAJOR OVERHAUL	TATA spare parts
550743700144	KIT 160CC GEAR DRIVEN COMP RING REPAIR	TATA spare parts
550743700145	KIT 160CC GEAR DRIVEN COMP PISTON REPAIR	TATA spare parts
550743700146	BRACKET ASSY HAND BRAKE VALVE MTG	TATA spare parts
550743700149	SOLENOID VALVE ASSY	TATA spare parts
550743700151	AIR CYLINDER ASSY	TATA spare parts
550743700158	ANTI COMPOUNDING RELAY VALVE	TATA spare parts
550743700219	BRAKE CHAMBER ASSY BS6-PH2	TATA spare parts
550743700220	BRAKE CHAMBER LH BS6-PH2	TATA spare parts
550743700226	ADAPTER MODULATOR VALVE	TATA spare parts
550743700255	BRAKE CHAMBER	TATA spare parts
550743700256	BRAKE CHAMBER	TATA spare parts
550743700267	RELAY VALVE - MODULATOR VALVE ASSY W BKT	TATA spare parts
550743700268	RELAY VALVE & MODULATOR VALVE ASSY W BKT	TATA spare parts
550743703303	BRACKET SOLENOID VALVE MTG	TATA spare parts
550743703304	BRACKET QRV MTG REAR	TATA spare parts
550743703307	BRACKET QRV MTG REAR BS6	TATA spare parts
550743703501	BOSS LP SWITCH MTG	TATA spare parts
550743703502	BOSS	TATA spare parts
550743708204	BRACKET QUICK RELEASE VALVE MTG	TATA spare parts
550743708205	BRACKET (QUICK RELEASE VALVE)	TATA spare parts
550743708207	BRACKET RELAY & MODULATOR VALVE MTG BS6	TATA spare parts
550743708208	BRACKET RELAY VALVE MTG	TATA spare parts
550743708210	BRACKET SOLENOIDVALVEMTG	TATA spare parts
550743708212	BRACKET MODULATOR VALVE MTG FRONT	TATA spare parts
550743708226	BRACKET MODULATOR VALVE MTG BS6-PH2	TATA spare parts
550743708227	BRACKET BS6-PH2	TATA spare parts
550743800103	ASSY FRT HOSE MTG BKT WT WIRE SUPPORT	TATA spare parts
550743800105	ASSY TUBE ADAPTOR TO ADAPTOR	TATA spare parts
550743800112	ASSY. FRONT HOSE	TATA spare parts
550743800139	ASSY LCRV HOSE	TATA spare parts
550743800164	ASSY. TUBE T CONNECTOR TO FRT LH HOSE	TATA spare parts
550743800166	ASSY. TUBE LCRV TO REAR HOSE	TATA spare parts
550743800167	ASSY. TUBE TEE TO REAR BRAKE DRUM RH	TATA spare parts
550743800168	ASSY. TUBE TEE TO REAR BRAKE DRUM LH	TATA spare parts
550743800204	MTG BRACKET ASSY (FOR HOSE ON CAB)	TATA spare parts
550743800206	PIPE ASSY WITH CRIMPED HOSE	TATA spare parts

550743803301	BRACKETCLAMPMTG	TATA spare parts
550743806804	ADAPTOR (FOR 6 O.D. PIPE)	TATA spare parts
550743806808	3 WAY UNION (FOR 6 O.D. TUBE)	TATA spare parts
550743806812	ADAPTOR (DAOH PIPE FITMENT)	TATA spare parts
550743807709	PLASTIC CLAMP (BRAKE PIPE)	TATA spare parts
550743807710	PLASTIC CLAMP (BRAKE PIPE)	TATA spare parts
550743807711	PLASTIC CLAMP (BRAKE PIPE)	TATA spare parts
550743807712	PLASTIC CLAMP (BRAKE PIPE)	TATA spare parts
550743807713	PLASTIC CLAMP (BRAKE PIPE)	TATA spare parts
550743807716	CLAMP (PLASTIC)	TATA spare parts
550743808202	BRACKET (FOR HOSE MOUNTING) ON CAB FLOOR	TATA spare parts
550743808203	BRACKET (PIPE ON FRAME NEAR REAR AXLE)	TATA spare parts
550743808211	FRONT CALIPER HOSE MOUNTING BRACKET BS6	TATA spare parts
550743808212	BRACKET (COMP. PIPE MTG.)	TATA spare parts
550743808216	PARKING BRAKE CABLE MTG BKT	TATA spare parts
550743808501	GASKET (FOR HOSE MTG BKT)	TATA spare parts
550743810108	ASSY. TUBE FRONT SMC TO ADAPTOR	TATA spare parts
550743810109	ASSY. TUBE REAR SMC TO ADAPTOR	TATA spare parts
550743810110	ASSY. TUBE ADAPTOR TO LCRV INLET	TATA spare parts
550743810111	ASSY. TUBE ADAPTOR TO ADAPTOR	TATA spare parts
550743810113	ASSY. TUBE T CONNECTOR TO FRT RH HOSE	TATA spare parts
550743810114	ASSY. METAL PIPE WITH CRIMPED HOSE	TATA spare parts
550743810115	ASSY. METAL PIPE (FIRST)	TATA spare parts
550743810116	ASSY. METAL PIPE (SECOND)	TATA spare parts
550743810135	METAL PIPE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts
550743810136	BRACKET ASSY T-CONN MTG BS6	TATA spare parts
550743810182	METAL PIPE ASSY HOSE TO ADAPTER BS6	TATA spare parts
550743810183	ASSY. METAL PIPE (SECOND) FOR 3310 WB	TATA spare parts
550743810189	ASSY.BRACKET (HOSE MTG.ON REAR AXLE)	TATA spare parts
550743810190	METAL PIPE ASSY BS6	TATA spare parts
550743810194	METAL PIPE ASSY COMPRESSOR TO AIR DRYER	TATA spare parts
550743810197	METAL PIPE ASSY COMPRESSOR TO AIR DRYER	TATA spare parts
550743820144	METAL PIPE ASSY BS6	TATA spare parts
550743820145	METAL PIPE ASSY BS6	TATA spare parts
550743900149	ASSY. NYLON PIPE COMPLETE	TATA spare parts
550743900189	ASSY BRACKET (FORNT HOSE MTG.)	TATA spare parts
550743900190	ASSY. BRACKET (REAR HOSE MTG.)	TATA spare parts
550743900211	PIPE ASSY NYLON BUNCH - CHASSIS	TATA spare parts
550743900219	NYLON PIPE BUNCH ASSY CHASSIS	TATA spare parts
550743900220	BRAKE HOSE FRONT ASSY	TATA spare parts
550743900232	PIPE ASSY NYLON BUNCH - CAB	TATA spare parts
550743900237	PIPE ASSY NYLON BUNCH - CHASSIS	TATA spare parts
550743900258	PIPE ASSY NYLON BUNCH - CAB	TATA spare parts
550743901601	FRONT BRAKE HOSE3/8 IN	TATA spare parts
550743903301	BRACKET	TATA spare parts
550743903302	BRACKET	TATA spare parts
550743903304	BRACKET (REAR HOSE MTG.) BS6	TATA spare parts

550743903307	BRACKET SOLENOID VALVE	TATA spare parts
550743903311	BRACKET (METAL PIPE MTG)	TATA spare parts
550743903313	MOUNTING BRACKET (PURGE TANK)	TATA spare parts
550743903315	MOUNTING BRACKET (SOLENOID VALVE)	TATA spare parts
550743903316	BRACKET (EXHAUST SOLENOID MTG)	TATA spare parts
550743903318	BRACKET (METAL PIPE MTG) BS6	TATA spare parts
550743905801	HOSE	TATA spare parts
550743907501	RUBBER GROMMET (FOR NYLON BUNCH)	TATA spare parts
550743907502	RUBBER GROMMET (NYLON PIPE)	TATA spare parts
550743907503	RUBBER GROMMET	TATA spare parts
550743907505	RUBBER GROMMET BS6	TATA spare parts
550743907506	RUBBER GROMMET BS6	TATA spare parts
550743910171	NYLON PIPE BUNCH ASSY CHASSIS	TATA spare parts
550743910187	ASSY METAL PIPE WITH CRIMPED HOSE (52WB)	TATA spare parts
550743910188	ASSY METAL PIPE DIA 15 AC TO DDU 1ST (52	TATA spare parts
550743910246	NYLON PIPE BUNCH ASSY	TATA spare parts
550743910250	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
550743910281	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
550743920131	ASSY NYLON PIPE SET COMPLETE SET NON ABS	TATA spare parts
550743920135	ASSY NYLON PIPE SET COMPLETE	TATA spare parts
550743920180	BRAKE HOSE 3/8INC	TATA spare parts
550743920202	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
550743920203	METAL PIPE ASSY HOSE TO JOINT BS6	TATA spare parts
550743920204	METAL PIPE ASSY JOINT 1 TO JOINT 2 BS6	TATA spare parts
550743920205	METAL PIPE ASSY JOINT TO DDU BS6	TATA spare parts
550743920207	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
550743920243	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
550743930137	NYLON PIPE BUNCH ASSY -52WB ABS	TATA spare parts
550743930146	NYLON PIPE BUNCH ASSY -49WB ABS	TATA spare parts
550743930254	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
550743940114	PIPE ASSY (NYLON BUNCH - CAB)	TATA spare parts
550743940115	PIPE ASSY (NYLON BUNCH - CHASSIS)	TATA spare parts
550743940116	PIPE ASSY (NYLON BUNCH - CHASSIS)	TATA spare parts
550743940117	PIPE ASSY (NYLON BUNCH - CHASSIS)	TATA spare parts
550743940118	PIPE BUNCH ASSY	TATA spare parts
550743940150	PIPE ASSY (NYLON BUNCH - CAB)	TATA spare parts
550743940168	NYLON PIPE BUNCH ASSY ABS	TATA spare parts
550743940178	PIPE BUNCH ASSY	TATA spare parts
550743950152	NYLON PIPE BUNCH ASSY	TATA spare parts
550743960129	BRAKE HOSE ASSY	TATA spare parts
550743960132	NYLON PIPE BUNCH ASSY CHASSIS	TATA spare parts
550743970109	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
550743970110	BRACKET ASSY REAR HOSE MTG BS6	TATA spare parts
550743970123	NYLON PIPE BUNCH ASSY CABIN BS6	TATA spare parts
550743970130	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
550743970149	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
550743970161	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts

550743970166	PIPE BUNCH ASSY CABIN BS6	TATA spare parts
550743970172	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
550743980115	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
550743980118	NYLON PIPE BUNCH ASSY CABIN BS6	TATA spare parts
550743990102	KIT-FLUID RESERVOIR	TATA spare parts
550746000108	ASSLY.POWER STRG.GEAR BOX MTG.BKT.&PITMA	TATA spare parts
550746000156	ASSEMBLY FOR POWER STRG GEAR BOX & PITMA	TATA spare parts
550746100101	ASSY. STEERING COLUMN BS3/4	TATA spare parts
550746100123	STEERING¿COLUMN¿UPPER	TATA spare parts
550746100124	SPLINE¿TUBE¿ASSY	TATA spare parts
550746100126	STEERING COLUMN ASSY BS6	TATA spare parts
550746100127	COLUMNASSY UPPER BS6	TATA spare parts
550746100128	STEERING COLUMN ASSY UPPER BS6	TATA spare parts
550746100131	STEERING COLUMN ASSY BS6-PH2	TATA spare parts
550746103206	PINION BOLT	TATA spare parts
550746103207	HEX BOLT	TATA spare parts
550746200108	KIT-SEAL BS6	TATA spare parts
550746200121	KIT-SEAL RACK BS6	TATA spare parts
550746200127	SEAL KIT (HOUSING ASSY) BS6	TATA spare parts
550746200132	ASSY.RUBBER BELLOW	TATA spare parts
550746200133	ASSLY.RUBBER BELLOW	TATA spare parts
550746200134	RUBBER BELLOW ASSY FOR NARROW	TATA spare parts
550746203201	HEX.BOLT-(M14X1.5X35-(DIN961/IS 1364-199	TATA spare parts
550746203713	POWER STRG.GEAR BOX CASTING-RHD	TATA spare parts
550746203714	POWER STRG.GEAR BOX -LHD	TATA spare parts
550746203715	POWER STRG.GEAR BOX MTG.BKT CASTING-RHD	TATA spare parts
550746203717	P.S.G. MTG. BKT.	TATA spare parts
550746204701	SIDE COVER BS6	TATA spare parts
550746206502	HEX NUT M30	TATA spare parts
550746207170	CLAMPNG PLATE	TATA spare parts
550746207180	BASE PLATE FOR RESERVOIR MTG.BKT	TATA spare parts
550746207704	O-RING BS6	TATA spare parts
550746207802	DUST SEAL	TATA spare parts
550746208801	STUD	TATA spare parts
550746209203	TAB WASHER	TATA spare parts
550746209204	SPRING WASHER -M14	TATA spare parts
550746303001	BALL RETURN GUIDE LH BS6	TATA spare parts
550746305101	PITMAN ARM	TATA spare parts
550746305103	PITMAN ARM	TATA spare parts
550746305107	PITMAN ARM BS6	TATA spare parts
550746305109	PITMAN ARM	TATA spare parts
550746306012	PITMAN ARM 215MM RHD	TATA spare parts
550746306015	PITMAN ARM 215MM	TATA spare parts
550746306016	LPT PITMAN ARM 215MM(ZF)-LHD	TATA spare parts
550746400102	ASSY STRG WHEEL-WITH HORN PIN(TRW-SUN ST	TATA spare parts
550746400103	ASSY STRG WHEEL-WITH CLOCK SPRING	TATA spare parts
550746400105	STEERING WHEEL ASSY WITH HORN PAD	TATA spare parts



550746600103	ASSLY.POWER STEERING PUMP BS3/4	TATA spare parts
550746600114	ASSLY. DRAGLINK FOR 9.5T/7.5T - RHD	TATA spare parts
550746600119	ASSLY.POWER STRG.RESERVOIR MTG.BKT.	TATA spare parts
550746600120	BRACKET ASSY RESERVOIR MTG	TATA spare parts
550746600131	ASSLY.DRAGLINK RANE FOR WIDER TRUCK-RHD	TATA spare parts
550746600132	DRAG LINK ASSY	TATA spare parts
550746600138	ASSLY.RESERVOIR MTG.BKT-LPO 497 ENG	TATA spare parts
550746600146	STEERING GEAR BOX ASSY	TATA spare parts
550746600147	SECTOR SHAFT ASSY BS6	TATA spare parts
550746600148	MAJOR KIT-SEAL	TATA spare parts
550746600149	HOUSING ASSY VALVE BS6	TATA spare parts
550746600150	WORM & RACK ASSY	TATA spare parts
550746600157	ASSLY. DRAGLINK FOR LPO-BUS RHD	TATA spare parts
550746600161	KIT-SEAL INPUT SHAFT	TATA spare parts
550746600162	DRAG LINK ASSY	TATA spare parts
550746600165	POWER STEERING PUMP POWER STEERING PUMP	TATA spare parts
550746600169	MAJOR KIT-SEAL	TATA spare parts
550746600170	FLP WITH PRV 100 BAR	TATA spare parts
550746600174	PISTON ASSY	TATA spare parts
550746600175	HOUSING ASSY	TATA spare parts
550746600176	HOUSING COVER ASSY	TATA spare parts
550746600188	BRACKET ASSY RESERVOIR MTG	TATA spare parts
550746600191	POWER STEERING GEAR BOX ASSY	TATA spare parts
550746600201	POWER STEERING PUMP ASSY	TATA spare parts
550746603306	BRACKET HYD RESERVOIR SUPPORT	TATA spare parts
550746603710	HOUSING	TATA spare parts
550746603711	HOUSING BS6	TATA spare parts
550746606501	SLOTTED NUT	TATA spare parts
550746607801	SEAL SHAFT	TATA spare parts
550746609202	WASHER DROPARM BS6	TATA spare parts
550746609905	RELIEF VALVE ASSY BS6	TATA spare parts
550746700101	BRACKET ASSY RESERVOIR MTG	TATA spare parts
550746700102	BRACKET ASSY POWER STEERING PUMP MTG BS6	TATA spare parts
550746700104	BELLOW PLATE ASSY BS6-PH2	TATA spare parts
550746703201	HEX FLANGE BOLT	TATA spare parts
550746703305	BRACKET ASSY STG GEAR BOX MTG	TATA spare parts
550746703702	BRACKET STG GEAR BOX MTG	TATA spare parts
550746703703	STG GEAR BOX MTG BRACKET	TATA spare parts
550746800148	ASSY. HIGH PRESSURE LINE - RHD (STRG. PU	TATA spare parts
550746800149	ASSY. RETURN LINE - RHD (STRG. GEAR BOX	TATA spare parts
550746800150	ASSY. SUCTION LINE (RESERVIOR TO PUMP)FO	TATA spare parts
550746800156	HIGH PRESSURE LINE ASSY	TATA spare parts
550746800185	RETURN LINE ASSY	TATA spare parts
550746800186	HIGH PRESSURE LINE ASSY	TATA spare parts
550746800190	SUCTION LINE ASSY	TATA spare parts
550746800191	RETURN LINE ASSY	TATA spare parts
550746800192	HIGH PRESSURE LINE	TATA spare parts

550746800194	PRESSURE LINE ASSY	TATA spare parts
550746800195	PRESSURE LINE ASSY	TATA spare parts
550746800196	RETURN LINE ASSY	TATA spare parts
550746800197	RETURN LINE ASSY	TATA spare parts
550746800198	SUCTION LINE ASSY	TATA spare parts
550746800199	RETURN LINE ASSY	TATA spare parts
550746800208	SUCTION LINE ASSY BS6	TATA spare parts
550746800209	PRESSURE LINE ASSY BS6	TATA spare parts
550746800210	RETURN LINE ASSY BS6	TATA spare parts
550746805806	HOSE SUCTION LINE	TATA spare parts
550746807789	PLASTIC CLAMP (DIA.10 & 12)	TATA spare parts
550746807795	PLASTIC CLAMP (DIA.10 & 12)	TATA spare parts
550746810101	HIGH PRESSURE LINE ASSY	TATA spare parts
550746810104	HIGH PRESSURE LINE ASSY BS6	TATA spare parts
550746810105	RETURN LINE ASSY RESERVOIR TO JOINT BS6	TATA spare parts
550746810109	PRESSURE LINE ASSY	TATA spare parts
550746810110	RETURN LINE ASSY	TATA spare parts
550746810113	SUCTION LINE ASSY(STRG GB SIDE)	TATA spare parts
550746810116	SUCTION LINE ASSY	TATA spare parts
550746810117	RETURN LINE ASSY	TATA spare parts
550746810118	HIGH PRESSURE LINE ASSY	TATA spare parts
550746810120	PRESSURE LINE ASSY BS6	TATA spare parts
550746810122	RETURN LINE ASSY GEAR BOX TO INT JOINT B	TATA spare parts
550746810123	RETURN LINE ASSY INT JOINT TO RESERVOIR	TATA spare parts
550746810124	SUCTION LINE ASSY BS6	TATA spare parts
550746810125	RETURN LINE ASSY GEAR BOX TO INT JOINT B	TATA spare parts
550746810126	RETURN LINE ASSY	TATA spare parts
550746810127	PRESSURE LINE ASSY	TATA spare parts
550746810128	SUCTION LINE ASSY(TANK SIDE)	TATA spare parts
550746810135	RETURN LINE ASSY BS6	TATA spare parts
550746810136	PRESSURE LINE ASSY BS6	TATA spare parts
550746810138	SUCTION LINE ASSY BS6	TATA spare parts
550746900101	ASSY. DRAG LINK BS3/4	TATA spare parts
550746900105	DRAG LINK ASSY	TATA spare parts
550746900111	DRAG LINK ASSY BS6	TATA spare parts
550746990103	HORN PAD ASSEMBLY	TATA spare parts
550746990104	ASSY. BALL JOINT RH BS3/4	TATA spare parts
550746990105	HOUSING ASSY	TATA spare parts
550746990106	SECTOR SHAFT ASSY	TATA spare parts
550746990107	HOUSING COVER ASSY	TATA spare parts
550746990108	PISTON ASSY	TATA spare parts
550746990109	COMPLETE SEALING KIT	TATA spare parts
550746990110	SMALL COMPONENT SET	TATA spare parts
550746990121	SEALING RING	TATA spare parts
550746990123	STEERING GEAR BOX ASSY WITH BKT & P/ARM	TATA spare parts
550746990151	KIT-RETRO FITMENT	TATA spare parts
550746990176	KIT-RETRO FITMENT	TATA spare parts

550746994701	HOUSING COVER ASSY	TATA spare parts
550746996601	PISTON ASSY	TATA spare parts
550746997701	COMPLETE SEALING KIT	TATA spare parts
550746997901	SECTOR SHAFT ASSY	TATA spare parts
550746999901	HOUSING ASSY	TATA spare parts
550746999903	SMALL COMPONENT SET	TATA spare parts
550747000102	ASSY. FUEL TANK WITH STRAPS SUPPORT	TATA spare parts
550747000103	ASSY. FUEL TANK WITH STRAPS SUPPORTS &	TATA spare parts
550747000104	ASSY. FUEL TANK COMPLETE WITH STRAPS SUP	TATA spare parts
550747000108	ASSY. FUEL TANK COMPLETE WITH SPACER 160	TATA spare parts
550747000109	ASSY. FUEL TANK COMPLETE WITH SPACER 120	TATA spare parts
550747000124	FUEL TANK ASSY (NEW MTG CHANGE) BS6	TATA spare parts
550747000125	FUEL TANK ASSY BS6	TATA spare parts
550747000127	FUEL TANK ASSY BS6	TATA spare parts
550747000128	FUEL TANK ASSY BS6	TATA spare parts
550747100103	FUEL TANK ASSY BS6	TATA spare parts
550747100104	FUEL TANK ASSY BS6	TATA spare parts
550747100105	ASSY FUEL TANK BS6	TATA spare parts
550747100107	ASSY. FUEL TANK COMPLETE (90LTRS.)	TATA spare parts
550747100108	ASSY. FUEL TANK WELDED (90 LTRS)	TATA spare parts
550747100127	FUEL TANK ASSY BS6-PH2	TATA spare parts
550747100146	BRACKET ASSY BS6	TATA spare parts
550747100170	FUEL TANK ASSY BS6-PH2	TATA spare parts
550747104201	NEW ELECTRIC FEED PUMP CLIP BS6	TATA spare parts
550747107703	HOSE FOR TPV	TATA spare parts
550747500101	ASSY.SPACERBKT.FUELTANKMTG BS6	TATA spare parts
550747500106	ASSY.STRAP FOR FUEL TANK	TATA spare parts
550747500108	ASSY.SPACER BKT.WITH SPACER PLATE (BUS)	TATA spare parts
550747500112	ASSY. BRACKET (FUEL TANK MOUNTING)	TATA spare parts
550747500113	ASSY. STRAP FUEL TANK MTG.	TATA spare parts
550747500120	BRACKET ASSY BS6-PH2	TATA spare parts
550747500121	STRAP & RUBBER PACKING ASSY BS6-PH2	TATA spare parts
550747500129	BRACKET ASSY BS6-PH2	TATA spare parts
550747500140	BRACKET ASSY BS6-PH2	TATA spare parts
550747500143	BRACKET ASSY BS6-PH2	TATA spare parts
550747506501	SLEEVE NUT BS6	TATA spare parts
550747506701	PIN FOR STRAP MTG.	TATA spare parts
550747506708	CLEVIS PIN BS6	TATA spare parts
550747507701	RUBBER PACKING	TATA spare parts
550747507711	RUBBER BEADING BS6-PH2	TATA spare parts
550747508209	SPACER BKT. FOR FUEL TANK (BUS)	TATA spare parts
550747508232	PLATE BS6-PH2	TATA spare parts
550747508235	PLATE BS6-PH2	TATA spare parts
550747518216	BRACKET BS6	TATA spare parts
550747518217	BRACKET BS6	TATA spare parts
550747600114	ASSM. RETURN LINE (OVERFLOW TO FUEL TANK	TATA spare parts
550747600119	ASSY. RETURN LINE (OVERFLOW TO FUEL TANK	TATA spare parts

550747600131	SUCTION LINE (FUEL TANK TO BABY FILTER)	TATA spare parts
550747600132	ASSY.SUCTION LINE (BABY FILTER TO FEED P	TATA spare parts
550747600133	ASSY.SUCTION LINE (FUEL TANK TO BABY FIL	TATA spare parts
550747600161	FUEL SUCTION LINE ASSY E.F.P TO PRE-FILT	TATA spare parts
550747600162	FUEL RETURN LINE ASSY SEGMENT_1	TATA spare parts
550747600170	ASSY.SUCTION LINE (FUEL TANK TO BABY FIL	TATA spare parts
550747600171	ASSY.SUCTION LINE BABY FILTER TO FIP	TATA spare parts
550747600172	ASSY.RETURN LINE OVERFLOW TO FUEL TANK	TATA spare parts
550747600181	FUEL RETURN LINE ASSY SEGMENT-2	TATA spare parts
550747600195	FUEL SUCTION LINE ASSY FUEL TANK TO E.F.P	TATA spare parts
550747600196	FUEL SUCTION LINE ASSY E.F.P TO PRE-FILT	TATA spare parts
550747600197	FUEL RETURN LINE ASSY SEGMENT_2	TATA spare parts
550747600202	FUEL RETURN PIPE ASSY BS6	TATA spare parts
550747600232	FUEL SUCTION PIPE ASSY PRE_FL.TO MAIN.FL	TATA spare parts
550747600233	FUEL SUCTION PIPE ASSY FT.TO E.F.P.	TATA spare parts
550747600236	RETURN FUEL PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
550747600237	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
550747600238	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
550747600240	FUEL PIPE ASSY BS6	TATA spare parts
550747600241	FUEL PIPE ASSY BS6	TATA spare parts
550747600242	FUEL PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
550747600265	PRIMING PUMP ASSY BS6	TATA spare parts
550747600269	FUEL PIPE ASSY FILTER TO ENGINE FILTER T	TATA spare parts
550747600272	FUEL PIPE ASSY BS6	TATA spare parts
550747600278	RETURN FUEL PIPE ASSY BS6	TATA spare parts
550747600282	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
550747600283	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
550747600284	RETURN FUEL PIPE ASSY FILTER AND ENGINE	TATA spare parts
550747600285	FUEL RETURN PIPE ASSY BS6	TATA spare parts
550747605895	PIPE ROV VALVE BS6-PH2	TATA spare parts
550747608206	BRACKET FOR FUEL LINE CLAMPING	TATA spare parts
550747608211	BRACKET FOR ELECTRIC FEED PUMP (LPO/AMT)	TATA spare parts
550747608213	BRACKET FOR ELE. FEED PUMP MTG	TATA spare parts
550747610101	FUEL SUCTION PIPE ASSY	TATA spare parts
550747610102	FUEL SUCTION PIPE ASSY	TATA spare parts
550747610103	FUEL SUCTION PIPE ASSY	TATA spare parts
550747610104	FUEL RETURN PIPE ASSY	TATA spare parts
550747610157	QUICK CONNECTOR (ELBOW 11.8X10) BS6	TATA spare parts
550747610159	FUEL SUCTION PIPE ASSY	TATA spare parts
550747610160	FUEL SUCTION PIPE ASSY	TATA spare parts
550747610182	FUEL SUCTION PIPE ASSY	TATA spare parts
550747610183	FUEL RETURN PIPE ASSY	TATA spare parts
550747610197	FUEL RETURN PIPE ASSY	TATA spare parts
550747610198	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
550747610199	RETURN FUEL PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
550747620101	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
550747620102	FUEL PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts

550747620103	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
550747620109	RETURN FUEL PIPE ASSY BS6	TATA spare parts
550747620110	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
550747620111	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
550747620113	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
550747620114	RETURN FUEL PIPE ASSY BS6	TATA spare parts
550747620119	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620120	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620121	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620122	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620123	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620124	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620125	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620126	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620127	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620128	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620129	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620130	VENT TUBE ASSY BS6	TATA spare parts
550747620131	VENT TUBE ASSY BS6	TATA spare parts
550747620132	VENT TUBE ASSY BS6	TATA spare parts
550747620133	VENT TUBE ASSY BS6	TATA spare parts
550747620134	VENT TUBE ASSY BS6	TATA spare parts
550747620135	VENT TUBE ASSY BS6	TATA spare parts
550747620136	HP TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620137	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620138	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620139	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747620140	CLAMP ASSY	TATA spare parts
550747620141	HP GAS TUBE WITH PVC SLEEVE BS6	TATA spare parts
550747620144	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
550747704901	SUCTION UNIT ASSY WITH TFR	TATA spare parts
550749100101	SILENCER ASSY RH	TATA spare parts
550749100103	SILENCER FOR 497 ENG.WITH ST.TAIL PIPE	TATA spare parts
550749100111	ASSEMBLY SILENCER FOR 497	TATA spare parts
550749100116	PIPE ASSY DPS SENSOR REAR	TATA spare parts
550749100126	SILENCER ASSEMBLY(497)	TATA spare parts
550749100132	ASSEMBLY SILENCER FOR 497 BSIV	TATA spare parts
550749100136	ASSEMBLY FLEX BELLOW	TATA spare parts
550749100139	ASSLY BRACKET	TATA spare parts
550749100141	MTG BRACKET ASSLY FOR FRONT PIPE	TATA spare parts
550749100145	ASSY.INTERMEDIATE PIPE	TATA spare parts
550749100146	ASSY SILENCER STRAP FOR CNG 5.7SGI	TATA spare parts
550749100157	ASSEMBLY L-BRACKET	TATA spare parts
550749100164	PIPE ASSY CATCON INTAKE	TATA spare parts
550749100165	PIPE ASSY DOWNSTREAM	TATA spare parts
550749103304	BRACKET EGP MTG BS6	TATA spare parts
550749103320	SUPPORT BRACKET FOR SILENCER ASSEMBLY	TATA spare parts

550749103324	HANGER BRACKET	TATA spare parts
550749103326	MTG BRACKET FRONT PIPE	TATA spare parts
550749103327	HANGER BRACKET	TATA spare parts
550749103335	FRONT C/S MEMBER MOUNTING BRACKET	TATA spare parts
550749103336	MTG BRACKET FOR NOISE SHIELD	TATA spare parts
550749103339	MTG BRACKET FOR NOISE SHIELD	TATA spare parts
550749103396	BRACKET FRONT PIPE MTG	TATA spare parts
550749104214	MTG STRAP FOR FRONT PIPE	TATA spare parts
550749105803	HOSE	TATA spare parts
550749105804	HOSE	TATA spare parts
550749106918	METAL PIPE UPSTREAM-1	TATA spare parts
550749106919	METAL PIPE DOWNSTREAM-1	TATA spare parts
550749200101	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
550749200104	HEAT SHIELD PIPE ASSY FRONT	TATA spare parts
550749200105	ASSEMBLY FRONT PIPE	TATA spare parts
550749200109	TAIL PIPE BS6	TATA spare parts
550749200111	ASSY. NOISE SHIELD COMPLETE	TATA spare parts
550749200113	FRONT PIPE ASSY. FOR LPO BUS	TATA spare parts
550749200115	ASSEMBLY FRONT PIPE	TATA spare parts
550749200119	ASSEMBLY SUPPORT BRACKET	TATA spare parts
550749200123	ASSY STRAP	TATA spare parts
550749200124	ASSLY MOUNTING BRACKET FRONT PIPE	TATA spare parts
550749200151	ASSEMBLY HOSE PIPE UPSTREAM	TATA spare parts
550749200152	ASSEMBLY HOSE PIPE DOWNSTREAM	TATA spare parts
550749200154	ASSEMBLY HOSE PIPE DOWNSTREAM	TATA spare parts
550749200156	ASSEMBLY HOSE PIPE UPSTREAM	TATA spare parts
550749200158	ASSEMBLY FRONT PIPE FOR 16T	TATA spare parts
550749200161	HOSE PIPE ASSY UP STREAM BS6	TATA spare parts
550749200165	PIPE ASSY DPS SENSOR INTAKE	TATA spare parts
550749200166	PIPE ASSY DPS SENSOR REAR	TATA spare parts
550749200178	PIPE ASSY UPSTREAM	TATA spare parts
550749200185	EXHAUST PIPE INTERMEDIATE	TATA spare parts
550749200186	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
550749200187	EXHAUST PIPE ASSY DOC TO SILENCER	TATA spare parts
550749200188	PIPE ASSY DOWNSTREAM	TATA spare parts
550749200195	FRONT PIPE ASSY BS6	TATA spare parts
550749200198	FRONT PIPE ASSY BS6	TATA spare parts
550749203302	BRACKET	TATA spare parts
550749203314	BRACKET EXHAUST PIPE	TATA spare parts
550749203326	MTG BRACKET FOR EXHAUST SYSTEM	TATA spare parts
550749203329	BRACKET FRONT PIPE MTG	TATA spare parts
550749206958	TAIL PIPE BS6	TATA spare parts
550749206960	TAIL PIPE BS6	TATA spare parts
550749207110	BRACKET BS6	TATA spare parts
550749210104	BRACKET ASSY BS6	TATA spare parts
550749210106	BRACKET ASSY BS6	TATA spare parts
550749210109	UREA PIPE ASSY 550749200197 BS6	TATA spare parts

550749210110	PIPE ASSY UREA SUPPLY (OLD PART - 550749	TATA spare parts
550749210112	BRACKET ASSY BS6	TATA spare parts
550749210124	BRACKET ASSY BS6	TATA spare parts
550749210130	BRACKET ASSY TAIL PIPE MTG BS6-PH2	TATA spare parts
550749210131	BRACKET ASSY BS6-PH2	TATA spare parts
550749210132	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
550749210134	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
550749210135	EXHAUST PIPE ASSY WITH BELLOW BS6-PH2	TATA spare parts
550749210148	BRACKET ASSY UREA TANK MTG BS6-PH2	TATA spare parts
550749210197	BRACKET ASSY EXHAUST PIPE SUPPORT BS6-PH	TATA spare parts
550749213302	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
550749213305	CLAMP BS6	TATA spare parts
550749213308	BRACKET BS6	TATA spare parts
550749213311	BRACKET BS6	TATA spare parts
550749213314	L-BRACKET TAIL PIPE MTG SUPPORT BS6-PH2	TATA spare parts
550749213319	L-BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
550749600120	HEAT SHIELD ASSY BS6-PH2	TATA spare parts
550749600121	HEAT SHIELD ASSY SILENCER BS6-PH2	TATA spare parts
550749609901	HEAT SHIELD PIPE	TATA spare parts
550749609902	HEAT SHIELD PIPE	TATA spare parts
550749609903	HEAT SHIELD PIPE	TATA spare parts
550749609904	HEAT SHIELD 4	TATA spare parts
550749609905	HEAT SHIELD 5	TATA spare parts
550749609906	HEAT SHIELD DOC POC	TATA spare parts
550749609911	HEAT SHIELD DOC POC	TATA spare parts
550749609912	HEAT SHIELD PIPE	TATA spare parts
550749609913	HEAT SHIELD PIPE	TATA spare parts
550749609914	HEAT SHIELD PIPE	TATA spare parts
550749609915	HEAT SHIELD PIPE	TATA spare parts
550749609916	HEAT SHIELD PIPE	TATA spare parts
550749609917	HEAT SHIELD PIPE	TATA spare parts
550749609918	HEAT SHIELD DOC POC	TATA spare parts
550749990105	KIT-EXHAUST PIPE HEAT SHIELD	TATA spare parts
550754000111	RETROFITMENT KIT FOR 4ST RELAY	TATA spare parts
550754108294	BRACKET(BATTERY CABLE MTG)	TATA spare parts
550754109903	EARTH STRAP FOR Y1	TATA spare parts
550754109969	BATTERY CLAMP FOR CF	TATA spare parts
550754199904	BATTERY CABLE JUMPER 497 ENG 9.6T & 7.5T	TATA spare parts
550754199927	BATTERY CABLE NEGATIVE L-270MM 70SQ.MM.	TATA spare parts
550754199935	CHASSIS EARTHING	TATA spare parts
550754199938	EARTH CABLE FOR WIDER CAB TO CHASSIS	TATA spare parts
550754199944	CABLE 9.6T 497 ENG STARTER AND MAXIFUSE	TATA spare parts
550754200130	BRACKET ASSY (HORN 12V/24V MOUNTING)	TATA spare parts
550754200131	BRACKET ASSY (BUZZER MTG FOR 497 ENG 4SP	TATA spare parts
550754200132	BRACKET ASSY(BUZZER MTG FOR 3L ENG 5L EN	TATA spare parts
550754200133	BRACKET ASSY (INLINE CONNECTOR MOUNTING)	TATA spare parts
550754200138	ASSY. INSTRUMENT CLUSTER BS3/4	TATA spare parts

550754200165	BRACKET ASSYY(BATTERY CUT OFF SW MTG)	TATA spare parts
550754200170	ASSY BRACKET FOR ECU MOUNTING_3L	TATA spare parts
550754200178	BRACKET ASSY ECU MTG	TATA spare parts
550754200179	ASSY. BRACKET FOR ENG & IP INT RH	TATA spare parts
550754208256	BRACKET(3L ENGINE HARNESS FLYWHEEL MTG)	TATA spare parts
550754209905	TANK UNIT 160 LIT	TATA spare parts
550754209913	INSTRUMENT_CLUSTER_BASE_LEVEL-12V_AIR	TATA spare parts
550754209924	FLASHER CAT-6 12V	TATA spare parts
550754209929	REVERSE BUZZER UNIT 12V	TATA spare parts
550754209931	WIPER CONTROLLER 12V	TATA spare parts
550754209932	AIR PRESSURE SENSOR BS1/2/3/4	TATA spare parts
550754209949	WATER IN FUEL SENSOR	TATA spare parts
550754209975	DUMMY CAP WEAR INDICATOR	TATA spare parts
550754244601	IGNITION RELAY(24V 50A NO WITH RESISTOR)	TATA spare parts
550754244603	MICRO RELAY NO 30A 24V RES. UNSEALED	TATA spare parts
550754244604	WIPER ON RELAY(24V 10A NO/NC WITH RESIST	TATA spare parts
550754244605	RELAY WITH RESISTOR NO/NC 40A 24V(MINI)	TATA spare parts
550754244606	RELAY WITH DIODE NO/NC 30A 24V(MINI)	TATA spare parts
550754244607	MICRO RELAY 30A 24V WITH DIODE	TATA spare parts
550754244608	MICRO RELAY WITH DIODE BS6	TATA spare parts
550754249901	ECU EMS DCM3.3 PLUS 5L NEW GEN 24V BS3/4	TATA spare parts
550754249904	INSTRUMENT_CLUSTER_BASE_LEVEL-24V_AIR	TATA spare parts
550754249910	INSTRUMENT_CLUSTER_BASE_LEVEL-24V_AIR_	TATA spare parts
550754249915	FLASHER CAT-6 24V	TATA spare parts
550754249917	WIPER CONTROLLER 24V	TATA spare parts
550754400125	HEAD LAMP WITH HLLA WITH DRL LHD LH - 24	TATA spare parts
550754400126	HEAD LAMP WITH HLLA WITH DRL LHD RH - 24	TATA spare parts
550754400138	ASSY HEAD LAMP MTG BRKT OUTBOARD BODY SI	TATA spare parts
550754400139	ASSY HEAD LAMP MTG BRKT OUTBOARD BODY SI	TATA spare parts
550754400146	ASSY ENGINE LAMP MTG BRKT	TATA spare parts
550754400147	ASSY BRACKET FOR BUS (TAIL LAMP MTG.)	TATA spare parts
550754400166	ASSY. HEAD LAMP LH W/HLLA W/O DRL BS3/4/	TATA spare parts
550754400167	ASSY. HEAD LAMP RH W/HLLA W/O DRL BS3/4/	TATA spare parts
550754400194	ASSY ROOF LAMP MOUNTING BRACKET	TATA spare parts
550754400202	BRACKET ASSY HEADLAMP MTG LH	TATA spare parts
550754400203	BRACKET ASSY HEADLAMP MTG RH	TATA spare parts
550754401621	COVER ASSY DOOR CUTOFF LH	TATA spare parts
550754401622	COVER ASSY DOOR CUTOFF RH	TATA spare parts
550754401627	LAMP ASSY EOL MARKER FRONT 12V	TATA spare parts
550754401628	LAMP ASSY EOL MARKER FRONT 24V	TATA spare parts
550754406301	COVER ASSY DOOR CUTOFF LH	TATA spare parts
550754406302	COVER ASSY DOOR CUTOFF RH	TATA spare parts
550754409911	LAMP ROOF LAMP	TATA spare parts
550754409914	SIDE MARKER LAMP-12V	TATA spare parts
550754409922	ASSY TAIL LAMP WITH EOM AND WITH RPL LH	TATA spare parts
550754409923	ASSY TAIL LAMP WITH EOM AND WITH RPL RH-	TATA spare parts
550754409924	ASSY TAIL LAMP WITH EOM AND WITH RPL LH-	TATA spare parts



550754409927	ASSY TAIL LAMP W/O EOM AND WITH RPL RH-1	TATA spare parts
550754409928	ASSY TAIL LAMP W/O EOM AND W/O RPL LH-12	TATA spare parts
550754409952	HEAD LAMP WITH HLLA AND W/O DRL(RHD)LH-1	TATA spare parts
550754409953	HEAD LAMP WITH HLLA AND W/O DRL(RHD)RH-1	TATA spare parts
550754409982	HEAD LAMP DUMMY PANEL LH	TATA spare parts
550754409983	HEAD LAMP DUMMY PANEL RH	TATA spare parts
550754409984	END OUT LINE MARKER LAMP FRONT-12V	TATA spare parts
550754409985	END OUTLINE MARKER LAMP REAR(LH)-12V	TATA spare parts
550754409986	SIDE REPEATER LAMP-12V	TATA spare parts
550754409987	DOOR AJAR LAMP-12V	TATA spare parts
550754409988	FRONT REFLEX REFLECTOR LH	TATA spare parts
550754409989	FRONT REFLEX REFLECTOR RH	TATA spare parts
550754409993	LAMP LENS TAIL-LH	TATA spare parts
550754409994	LAMP LENS TAIL-RH	TATA spare parts
550754409996	BULB ASSY HEAD LAMP WITHOUT DRL 12V BS6	TATA spare parts
550754409997	BULB ASSY HEAD LAMP WITHOUT DRL 24V BS6	TATA spare parts
550754410110	HEADLAMP ASSY WITH LEVEL MOTOR LH	TATA spare parts
550754410111	HEADLAMP ASSY WITH LEVEL MOTOR RH	TATA spare parts
550754410112	ASSY. HEADLAMP W/LEVEL MOTOR LH BS3/4	TATA spare parts
550754410113	ASSY. HEADLAMP W/LEVEL MOTOR RH BS3/4	TATA spare parts
550754410114	HEADLAMP ASSY WITH LEVEL MOTOR LH BS6	TATA spare parts
550754410115	HEADLAMP ASSY WITH LEVEL MOTOR RH BS6	TATA spare parts
550754420107	END OUTLINE MARKER LAMP FRONT	TATA spare parts
550754420108	END OUTLINE MARKER LAMP FRONT	TATA spare parts
550754429901	RETRO REFLECTOR ASSY FRONT-LH	TATA spare parts
550754429902	RETRO REFLECTOR ASSY FRONT-RH	TATA spare parts
550754440119	ASSY HEAD LAMP W/ HLLA W/O DRL(RHD)LH-24	TATA spare parts
550754440120	ASSY HEAD LAMP W/ HLLA W/O DRL(RHD)RH-24	TATA spare parts
550754440127	ASSY HEAD LAMP W/ HLLA W/O DRL(LHD)LH-24	TATA spare parts
550754440128	ASSY HEAD LAMP W/ HLLA W/O DRL(LHD)RH-24	TATA spare parts
550754449910	GLOVE BOX LAMP-24V	TATA spare parts
550754449915	T/L ASSY WITH EOM & WITH RPL 24V-LH	TATA spare parts
550754449916	TAIL LAMP ASSY WITH EOM & WITH RPL 24V-R	TATA spare parts
550754449917	TAIL LAMP ASSY WITH EOM & W/O RPL 24V-LH	TATA spare parts
550754449918	T/L ASSY WITH EOM & W/O RPL 24V-RH	TATA spare parts
550754449920	TAIL LAMP ASSY W/O EOM & WITH RPL 24V-RH	TATA spare parts
550754449921	T/L ASSY W/O EOM & W/O RPL 24V-LH	TATA spare parts
550754449922	T/L ASSY W/O EOM & W/O RPL 24V-RH	TATA spare parts
550754449945	HEAD LAMP LOW BEAM LH-24V(RHD)BUS BS4	TATA spare parts
550754449946	HEAD LAMP LOW BEAM RH-24V(RHD)BUS BS4	TATA spare parts
550754449951	LAMP ASSY GLOVE BOX	TATA spare parts
550754449960	HEAD LAMP WITH HLLA AND W/O DRL(LHD)LH-2	TATA spare parts
550754449961	HEAD LAMP WITH HLLA AND W/O DRL(LHD)RH-2	TATA spare parts
550754449980	LAMP ASSY GLOVE BOX WITH SWITCH	TATA spare parts
550754449981	ASSY FRONT BLINKER LAMP(AMBER LENS)LH-24	TATA spare parts
550754449982	ASSY FRONT BLINKER LAMP(AMBER LENS)RH-24	TATA spare parts
550754449983	ASSY FRONT BLINKER LAMP(AMBER LENS)LH-24	TATA spare parts

550754449984	ASSY FRONT BLINKER LAMP(AMBER LENS)RH-24	TATA spare parts
550754449985	LAMP ASSY END OUT LINE MARKER FRONT-24V	TATA spare parts
550754449986	LAMP ASSY END OUT LINE MARKER REAR-24V	TATA spare parts
550754449987	LAMP ASSY SIDE REPEATER-24V	TATA spare parts
550754449988	LAMP ASSY DOOR AJAR-24V	TATA spare parts
550754449989	FRONT FOG LAMP-24V	TATA spare parts
550754449990	LAMP ROOF LAMP WITH DIODE 24V	TATA spare parts
550754500115	ASSY IGN SWITCH ILLUMINATION RING WITHOU	TATA spare parts
550754500121	COMBI SWITCH ASSEMBLY BASE LEVEL	TATA spare parts
550754500126	COMBI SWITCH FOR Y1	TATA spare parts
550754500144	DEFROSTER COVER ASSY	TATA spare parts
550754500147	STEERING LOCK CUM IGN RING W/ ILLU. BS4	TATA spare parts
550754500156	ASSY COMBI SWITCH -HIGH END.	TATA spare parts
550754500157	ASSY COMBI SW-MID LEVEL.	TATA spare parts
550754500158	BRACKET ASSY(MAXI FUSE MOUNTING)	TATA spare parts
550754500195	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
550754501618	SWITCH REGENERATION START MANUAL 553254	TATA spare parts
550754501620	SWITCH REGENERATION INHIBIT 553254504906	TATA spare parts
550754501621	SWITCH LIGHT MODE - 553254504903 BS6	TATA spare parts
550754501622	SWITCH HEAVY MODE 553254504907 BS6	TATA spare parts
550754501629	ROTARY SWITCH HEAD LAMP BS6	TATA spare parts
550754504902	SWITCH HILL ASSIST	TATA spare parts
550754504904	COMBI SWITCH BS6	TATA spare parts
550754504910	SWITCH EXHAUST BRAKE FOR 3L ENGINE	TATA spare parts
550754504912	SWITCH ARB	TATA spare parts
550754506302	DUMMY USB COVER	TATA spare parts
550754506303	DUMMY MUTLI SENSOR COVER	TATA spare parts
550754506304	FUSEBOXFRAMEM/S.MTA BS6	TATA spare parts
550754506316	FUSE BOX STICKER 12V TRUCK 3.0L	TATA spare parts
550754506321	SWITCH COVER	TATA spare parts
550754506323	FUSE BOX AND ECU PLATE COVER	TATA spare parts
550754506330	MAXIFUSE BOX MTG COVER FOR TRUCK & BUS	TATA spare parts
550754508209	BRACKET(CAB MTG FOR 3L ENG ECU WH)	TATA spare parts
550754509901	EMERGENCY BATTERY CUTOFF SWITCH 12V BS4	TATA spare parts
550754509902	HAZARD WARNING SWITCH FOR 12V	TATA spare parts
550754509903	DIMMER CONTROL SWITCH FOR 12V	TATA spare parts
550754509928	HEAD LAMP LEVELLING SWITCH FOR 12V	TATA spare parts
550754509941	Y1FUSEBOX BS6	TATA spare parts
550754509960	HEAD LAMP ROTARY SWITCH	TATA spare parts
550754509961	HEAD LAMP ROTARY SW WITHOUT FOG 12V	TATA spare parts
550754509962	Y1 COMBI SW RH LEVER LIGHT STALK BS6	TATA spare parts
550754509964	Y1 COMBI SW HORN PAD M/S.DAESUNG	TATA spare parts
550754509965	Y1 COMBI SW COMBI HOUSING M/S.DAESUNG	TATA spare parts
550754509970	FACIA SWITCH ASSY IND.ENGINE LAMP 12V	TATA spare parts
550754509971	FACIA SWITCH ASSY IND.EXHAUST BRAKE 12V	TATA spare parts
550754509972	FACIA SWITCH ASSY IND.ABS 12V	TATA spare parts
550754509982	MISCELANEOUS SWITCH FACIA ASSY LH 12V	TATA spare parts

550754509990	COMBI SW LH LEVER W/INT.WIPER CONT-DAESU	TATA spare parts
550754509994	CAB LOCK SWITCH	TATA spare parts
550754509995	HEAD LAMP ROTARY SW WITH REAR FOG 12V	TATA spare parts
550754510101	BRACKET ASSY FUSEBOX MTG	TATA spare parts
550754510103	BRACKET ASSY(MAXI-FUSE BOX MTG FOR LPT)	TATA spare parts
550754510115	COMBINATION SWITCH RH	TATA spare parts
550754519920	STICKER MAXI FUSE BOX	TATA spare parts
550754540101	ASSY STEERING LOCK CUM IGN RING	TATA spare parts
550754541602	SWITCH REGENERATION START MANUAL BS6	TATA spare parts
550754541603	SWITCH REGENERATION INHIBIT BS6	TATA spare parts
550754541604	SWITCH HEAVY MODE BS6	TATA spare parts
550754541606	SWITCH LIGHT MODE BS6	TATA spare parts
550754541611	ROTARY SWITCH HEAD LAMP BS6	TATA spare parts
550754544902	SWITCH EXHAUST BRAKE FOR 3L ENGINE	TATA spare parts
550754549901	EMERGENCY BATTERY CUTOFF SWITCH FOR 24V	TATA spare parts
550754549902	HAZARD WARNING SWITCH FOR 24V	TATA spare parts
550754549903	DIMMER CONTROL SWITCH FOR 24V	TATA spare parts
550754549904	REVERSE LIGHT SWITCH	TATA spare parts
550754549928	HEAD LAMP LEVELLING SWITCH FOR 24V	TATA spare parts
550754549960	HEAD LAMP ROTARY SW	TATA spare parts
550754549961	HEAD LAMP ROTARY SW WITHOUT FOG 24V	TATA spare parts
550754549970	FACIA SWITCH ASSY IND.ENGINE LAMP 24V	TATA spare parts
550754549971	FACIA SWITCH ASSY IND.EXHAUST BRAKE 24V	TATA spare parts
550754549972	FACIA SWITCH ASSY IND.ABS24V	TATA spare parts
550754549982	MISCELANEOUS SWITCH FACIA ASSY LH 24V	TATA spare parts
550754549983	MISCELANEOUS SWITCH FACIA ASSY RH 24V	TATA spare parts
550754549984	MISCELANEOUS SWITCH FACIA ASSY MID 24V	TATA spare parts
550754549991	REVERSE LIGHT SWITCH FOR 12V/24V.	TATA spare parts
550754600101	WIRING HARNESS SWITCH	TATA spare parts
550754600107	CABLE ASSY BATTERY +VE TO ELEC CUT OFF	TATA spare parts
550754600108	BATTERY CABLE -VE BS6	TATA spare parts
550754600109	CABLE FUSE BOX TO STARTER +VE	TATA spare parts
550754600112	CABLE EBDS O/P TO MEGA FUSE BOX I/P	TATA spare parts
550754600128	WIRING HARNESS ABS	TATA spare parts
550754600129	WIRING HARNESS FRONT CHASSIS	TATA spare parts
550754600139	WIRING HARNESS REAR CHASSIS	TATA spare parts
550754600140	WIRING HARNESS REAR CHASSIS	TATA spare parts
550754600147	WIRING HARNESS REAR CHASSIS	TATA spare parts
550754600159	BRACKET ASSY(FRONT CHASSIS HARNESS MTG)	TATA spare parts
550754600162	BRACKET ASSY (MASTER AIR CYLIDER)	TATA spare parts
550754600168	BRACKET(LPO 497ENG CHASSIS HARNESS MTG)	TATA spare parts
550754600170	ASSY BRACKET(LPO FRONT HARNESS MTG.)	TATA spare parts
550754600173	ASSY BRACKET(FRONT INLINE MTG BKT FOR BU	TATA spare parts
550754600175	BRACKET ASSY(CHASSIS HANRESS MTG )	TATA spare parts
550754600184	BRACKET ASSY (CAB TILT SW)	TATA spare parts
550754600194	BATTERY CABLE -VE	TATA spare parts
550754600198	BATTERY CABLE -VE BS6	TATA spare parts

550754601656	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
550754601670	WIRING HARNESS ENGINE	TATA spare parts
550754601672	BATTERY CABLE -VE TO STARTER -VE	TATA spare parts
550754603307	BRACKET BS6	TATA spare parts
550754606315	FUSE RELAY BOX	TATA spare parts
550754606334	FUSE RELAY BOX	TATA spare parts
550754606358	FUSE BOX COVER BS6	TATA spare parts
550754607502	GROMMET BS6	TATA spare parts
550754607702	GROMMET BODY SIDE OUTER BS6	TATA spare parts
550754608206	BRACKET(ALTERNATOR HARNESS MTG.)	TATA spare parts
550754608210	BRACKET( BOOST PRESSURE SENSOR HARNESS M	TATA spare parts
550754608211	BRACKET(STARTER HARNESS MTG.)	TATA spare parts
550754608214	BRACKET(ENGINE SPEED SENSOR)	TATA spare parts
550754608218	BRACKET(ENG COOLANT TEMP SENSOR)	TATA spare parts
550754608222	BRACKET(3L ENG COOLER MTG)	TATA spare parts
550754608223	BRACKET (3L ENG STARTER MOTOR)	TATA spare parts
550754608225	BRACKET(3L ENG AC COMPRESSOR VCV)	TATA spare parts
550754608226	BRACKET(3L ENG BLOCK HEATER)	TATA spare parts
550754608228	BRACKET (3L ENG FLYWHEEL HOUSING)	TATA spare parts
550754608231	BRACKET(5L ENG KNOCK SENSOR)	TATA spare parts
550754608232	BRACKET(5L ENG WATER IN FUEL SENSOR)	TATA spare parts
550754608234	BRACKET(5L ENG FLYWHEEL HOUSING)	TATA spare parts
550754608239	BRACKET(CROSS MEMBER SIDE)	TATA spare parts
550754608242	BRACKET(CROSS MEMBER MOUNTED)	TATA spare parts
550754608246	BRACKET(MASTER AIR CYLIDER)	TATA spare parts
550754608248	BRACKET(LPO 497ENG HARNESS MTG)	TATA spare parts
550754608249	BRACKET(LPO 497ENG FRONT HARNESS MTG) BS	TATA spare parts
550754608259	BRACKET(497 GB550 HARNESS MTG)	TATA spare parts
550754608260	BRACKET(GEAR BOX FLYWHEEL HARNESS MTG)	TATA spare parts
550754608261	BRACKET(AC COMPRESSOR MTG)	TATA spare parts
550754608262	BRACKET(497ENG GB550 REVERSE LIGHT SWITC	TATA spare parts
550754608263	BRACKET(3L ENG& ALTERNATOR)	TATA spare parts
550754608265	BRACKET(GB 400 & GB500 HARNESS MTG)	TATA spare parts
550754608272	BRACKET ( L TYPE HARNESS MTG.)	TATA spare parts
550754608273	BRACKET(3L ENG AIR FILTER MAF SENSOR)	TATA spare parts
550754608285	BRACKET(HEAD LAMP MTG ON FES)	TATA spare parts
550754608291	BRACKET(497 ENG VEHICLE SPEED SENSOR MTG	TATA spare parts
550754608294	BRACKET(ROTATRY FIP MTG)	TATA spare parts
550754608299	BRACKET(LPO BUS STARTER MOTOR CABLE)	TATA spare parts
550754608303	IP HARNESS UPPER MTG BKT ON CCB LEG LH B	TATA spare parts
550754609903	2100_WIDER_CAB_ROOF_RH_WH	TATA spare parts
550754609905	2100_WIDER_CAB_LH_DOOR_WH	TATA spare parts
550754609906	2100_WIDER_CAB_RH_DOOR_WH	TATA spare parts
550754609946	W/H FIREWALL BS6	TATA spare parts
550754609971	INJECTOR HARNESS-5L ENGINE	TATA spare parts
550754609993	COMBI SWITCH PIGTAIL FOR	TATA spare parts
550754610130	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts

550754610131	WIRING HARNESS FRONT CHASSIS	TATA spare parts
550754610132	WIRING HARNESS ENGINE	TATA spare parts
550754610154	WIRING HARNESS ENGINE	TATA spare parts
550754610157	WIRING HARNESS FRONT CHASSIS	TATA spare parts
550754610183	WIRING HARNESS REAR CHASSIS	TATA spare parts
550754610184	WIRING HARNESS REAR CHASSIS	TATA spare parts
550754610185	WIRING HARNESS REAR CHASSIS	TATA spare parts
550754610188	W/H FRONT CHASSIS	TATA spare parts
550754610191	EARTH CABLE	TATA spare parts
550754610197	WIRING HARNESS IP	TATA spare parts
550754610198	WIRING HARNESS IP	TATA spare parts
550754610199	WIRING HARNESS ABS FRAME	TATA spare parts
550754610211	WIRING HARNESS DMS BS6-PH2	TATA spare parts
550754610212	WIRING HARNESS INSTRUMENT PANEL BS6-PH2	TATA spare parts
550754610215	WIRING HARNESS SWITCH BS6-PH2	TATA spare parts
550754611607	WIRING HARNESS REAR CHASSIS	TATA spare parts
550754611609	BATTERY CABLE -VE BS6	TATA spare parts
550754611624	WIRING HARNESS FRONT CHASSIS	TATA spare parts
550754611627	WIRING HARNESS REAR CHASSIS	TATA spare parts
550754619908	LPO 497 24V BS-III STARTER TO ALTERNATOR	TATA spare parts
550754619915	STARTER VE CABLE FOR BUS	TATA spare parts
550754619940	STICKER MAXI FUSE BS6	TATA spare parts
550754619942	STICKER MAXI FUSE BS6	TATA spare parts
550754619944	LOW AIR PR SW LINK FOR_7.5T_9.6T_ TRUCK	TATA spare parts
550754619945	STICKER MAXI FUSE	TATA spare parts
550754619946	STICKER MAXI FUSE	TATA spare parts
550754619957	PIGTAIL FOR 4ST RELAY BUS	TATA spare parts
550754620120	PIGTAIL CHASSIS WIRING HARNESS	TATA spare parts
550754620132	WIRING HARNESS ABS FRAME	TATA spare parts
550754620136	WIRING HARNESS IP BS4	TATA spare parts
550754620145	WIRING HARNESS EMS	TATA spare parts
550754620148	CABLE ASSY BATTERY +VE TO ELEC CUT OFF	TATA spare parts
550754620153	WIRING HARNESS ABS FRAME 4S4M	TATA spare parts
550754620164	WIRING HARNESS FRONT CHASSIS	TATA spare parts
550754620181	WIRING HARNESS REAR CHASSIS	TATA spare parts
550754620182	WIRING HARNESS REAR CHASSIS	TATA spare parts
550754620183	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
550754620185	WIRING HARNESS REAR CHASSIS	TATA spare parts
550754620192	WIRING HARNESS FRONT CHASSIS	TATA spare parts
550754620193	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
550754620194	WIRING HARNESS BATTERY-VE TO STARTER-VE	TATA spare parts
550754620205	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
550754629901	W/H LPO 9.6T 497 ENG IP	TATA spare parts
550754629902	LPO 9.6T 497ENG 5200WB ENGINE HARNESS	TATA spare parts
550754629903	LPO BUS SWITCHES HARNESS PIGTAIL	TATA spare parts
550754629904	LPO 9.6T 497 ENG W/H HEAD LAMP RH	TATA spare parts
550754629905	LPO 9.6T 497 ENG W/H HEAD LAMP LH	TATA spare parts

550754629906	LPO 9.6T 497ENG WIRING HARNESS REAR	TATA spare parts
550754629909	BUS LPO 497ENG FRONT HARNESS	TATA spare parts
550754629911	WIRING HARNESS FES TO CHASSIS EARTH	TATA spare parts
550754629917	COMBI SWITCH PIGTAIL	TATA spare parts
550754629925	WH GEAR BOX (GB 550)	TATA spare parts
550754629926	2100_WIDER_CAB_FLOOR_RH_WIRING HARNESS	TATA spare parts
550754629927	2100_WIDER_CAB_ROOF_RH_WIRING HARNESS	TATA spare parts
550754629928	2100_WIDER_CAB_LH_DOOR_WIRING HARNESS	TATA spare parts
550754629929	2100_WIDER_CAB_RH_DOOR_WIRING HARNESS	TATA spare parts
550754629930	2100_WIDER_CAB_FIRWALL_HANRESS_RHD	TATA spare parts
550754629932	3920WB_REAR_CHASSIS_WIRING HARNESS NON	TATA spare parts
550754629933	9.6T_497_ENG_4530WB_REAR_CHASSIS_WIRING	TATA spare parts
550754629934	WIRING HARNESS REAR CH LPT 9.6T 497 NON-	TATA spare parts
550754629944	FRONT CHASSIS WH LPO 497 BS-III 24V BUS	TATA spare parts
550754629945	W/H LPO 497 12V BS-III W/O ABS W/O AC AC	TATA spare parts
550754629947	W/H LPO 497 12V BS-III W/O ABS WITH AC F	TATA spare parts
550754629948	W/H LPO 497 12V BS-III W/O AC FRONT CHAS	TATA spare parts
550754629949	W/H LPO 497 12V BS-III WITH AC FRONT CHA	TATA spare parts
550754629956	FES WH LPO 497 BS-III 24V BUS WITH OUT A	TATA spare parts
550754629957	FRONT CHASSIS WH LPO 497 BS-III 24V BUS	TATA spare parts
550754629992	STICKER MAXI FUSE BS6-PH2	TATA spare parts
550754630120	WIRING HARNESS REAR CHASSIS	TATA spare parts
550754630121	WIRING HARNESS ENGINE	TATA spare parts
550754630122	ALTERNATOR CABLE	TATA spare parts
550754630160	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
550754630163	WIRING HARNESS FRONT CHASSIS	TATA spare parts
550754630176	PIGTAIL - ULTRA	TATA spare parts
550754630178	PIGTAIL ALTERNATOR +VE BS6	TATA spare parts
550754630179	WIRING HARNESS SWITCH BS6	TATA spare parts
550754630180	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
550754630183	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
550754630184	WIRING HARNESS ENGINE BS6	TATA spare parts
550754630195	WIRING HARNESS REAR CHASSIS	TATA spare parts
550754630213	WIRING HARNESS EGP BS6-PH2	TATA spare parts
550754630218	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
550754639930	STICKER-MAXI FUSE BS6	TATA spare parts
550754640103	WIRING HARNESS SWITCH BS6	TATA spare parts
550754640104	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
550754640105	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
550754640107	WIRING HARNESS EGP PIGTAIL BS6	TATA spare parts
550754640109	WIRING HARNESS ENGINE BS6	TATA spare parts
550754640115	BATTERY CABLE -VE BS6	TATA spare parts
550754640140	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
550754640145	WIRING HARNESS FRONT CHASSIS	TATA spare parts
550754640152	WIRING HARNESS PIGTAIL	TATA spare parts
550754640155	WIRING HARNESS-FRONT CHASSIS BS6	TATA spare parts
550754640161	WIRING HARNESS IP OLD PART 550754630181	TATA spare parts

550754640164	WIRING HARNESS ABS FRAME 4S4M BS6	TATA spare parts
550754640166	WIRING HARNESS ABS FRAME 4S4M BS6	TATA spare parts
550754640167	WIRING HARNESS IP (DELETED PART NO 55075	TATA spare parts
550754640177	BATT CABLE +VE BATT TO ELE BCS OFF I/P B	TATA spare parts
550754640183	WIRING HARNESS-HEADLAMP-LH BS6	TATA spare parts
550754640184	WIRING HARNESS-HEADLAMP-RH BS6	TATA spare parts
550754640186	PIGTAIL UREA LEVEL SENSOR BS6	TATA spare parts
550754640187	WIRING HARNESS-REAR CHASSIS BS6	TATA spare parts
550754640189	WIRING HARNESS-REAR CHASSIS BS6	TATA spare parts
550754646301	STICKER MAXI FUSE BOX BS6-PH2	TATA spare parts
550754650146	WIRING HARNESS ABS BS6	TATA spare parts
550754650147	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
550754650148	WIRING HARNESS TAIL BS6	TATA spare parts
550754650149	WIRING HARNESS MAIN BS6	TATA spare parts
550754650150	BATTERY CABLE +VE BS6	TATA spare parts
550754650158	WIRING HARNESS INSTRUMENT PANEL BS6	TATA spare parts
550754650175	WIRING HARNESS SWITCH BS6-PH2	TATA spare parts
550754650188	WIRING HARNESS ESC BS6-PH2	TATA spare parts
550754650196	WIRING HARNESS ESC BS6-PH2	TATA spare parts
550754650198	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
550754660104	WIRING HARNESS H/L & BLINKER BS6-PH2	TATA spare parts
550754660106	WIRING HARNESS ESC BS6-PH2	TATA spare parts
550754660112	WIRING HARNESS ABS FRAME 4S3M BS6-PH2	TATA spare parts
550754660116	WIRING HARNESS INSTRUMENT PANEL BS6-PH2	TATA spare parts
550754699901	LPO 497 ENGINE TO CHASSIS EARTH	TATA spare parts
550754699902	LPO 497 BATTERY CABLE -VE	TATA spare parts
550754699903	LPO 497 4SP 3L ENG FES TO CHASSIS EARTH	TATA spare parts
550754699904	LPO 497 BATTERY CABLE +VE	TATA spare parts
550754699905	LPO 9.6T 497 ENG 24V STARTER POSITIVE CA	TATA spare parts
550754699908	LPO 497 24V BS-III STARTER TO ALTERNATOR	TATA spare parts
550754699909	STARTER +VE CABLE FOR BUS	TATA spare parts
550754699911	BATTERY -VE CABLE FOR BUS LPO 497 12V BS	TATA spare parts
550754699915	BATTERY CABLE POSITIVE FOR BUS LPO 497 1	TATA spare parts
550754699917	STARTER TO BATTERY CABLE NEGATIVE LPO	TATA spare parts
550754699919	STARTER TO BATTERY NEGATIVE CABLE 497 12	TATA spare parts
550754699924	BATTERY CUT-OFF R/Y O/P TO MEGA FUSE I/P	TATA spare parts
550754699931	BATT CABLE +VE 3L 12V 6.5T& 7.5T LPT	TATA spare parts
550754699934	BATT +VE TO AK FB I/P(LPT 497 12V)	TATA spare parts
550754699936	AK FB TO STARTER CABLE +VE(LPT 497 12V)	TATA spare parts
550754699937	BATTERY -VE TO STARTER-VE(497 12V TRUCK)	TATA spare parts
550754699938	BATT CABLE -VE 497/3L 12V BUS	TATA spare parts
550754699941	LPO 497/3L 12V BUS BATTERY CUT-OFF TO ME	TATA spare parts
550754699942	AK FUSE O/P TO STARTER 3L 12V 7.5T TRUCK	TATA spare parts
550754699944	LPO 497/3L 12V BUS BATTERY TO BATT CUT	TATA spare parts
550754700109	BRACKET ASSY YAW RATE SENSOR MTG BS6-PH2	TATA spare parts
550754709913	VEHICLE ELECTRONIC CONTROLLER UNIT BS6	TATA spare parts
550754709916	VEHICLE SPEED SENSOR BS6	TATA spare parts

550754800103	ECU ABS 8 4S/4M 4S/3M 12V BS3/4/6	TATA spare parts
550754904902	AIR PRESSURE TRANSDUCER	TATA spare parts
550754904903	AIR PRESSURE TRANSDUCER BS6	TATA spare parts
550758408204	LABEL TYRE PRESSURE INSTRUCTION BS6	TATA spare parts
550758408206	LABEL TYRE PRESSURE INSTRUCTION BS6-PH2	TATA spare parts
550758600103	ASSY BASE-JACK MOUNTING	TATA spare parts
550758600105	BRACKET ASSY JACK MTG BS6	TATA spare parts
550758604022	JACK CLAMP	TATA spare parts
550758604023	JACK CLAMP-1 BS6	TATA spare parts
550758604024	JACK CLAMP-2 BS6	TATA spare parts
550758900101	ASSY SCREW JACK WITH 1 PIECE HANDLE	TATA spare parts
550758900106	STRAP AND HINGE ASSY	TATA spare parts
550758900112	SPL TOOL FOR TAPPET GAP SETTING	TATA spare parts
550758900601	CRANK SHAFT LOCKING PIN / 3L / Y1	TATA spare parts
550758900602	FLYWHEEL LOCKING TOOL / 3L / Y1	TATA spare parts
550758900603	DRIFT / CRANK SHAFT PILOT BRG / 3L / Y1	TATA spare parts
550758900604	CAM SHAFT LOCK TOOL/ VALVE TIMING/ 3L/Y1	TATA spare parts
550758900605	CLUTCH ALLIGNMENT MANDREL / 3L / Y1	TATA spare parts
550758900606	PULLER FOR PILOT BEARING	TATA spare parts
550758900607	ENG MTG BKT LH & RH/USE W-27022404/02/3L	TATA spare parts
550758900608	SUPPORT RAIL/ USE W-282958900605/ 3L/ Y1	TATA spare parts
550758900609	PULLER / REMOVE INJECTOR / 3L	TATA spare parts
550758900610	TOOL / LOCK TIMING CHAIN TENSIONER / 3L	TATA spare parts
550758900611	FEELER GAUGE 0.3 THK FOR EXHAUST VALVE G	TATA spare parts
550758900612	FEELER GAUGE 0.25 THK FOR INLET VALVE GA	TATA spare parts
550758900613	MAIN BODY WITH HANDLE(SPL TOOL FOR TAPPE	TATA spare parts
550758900614	DOLLY FOR FITMENT OF REAR OIL SEAL	TATA spare parts
550758900615	TOOL-INJECTOR SLEEVE REMOVAL AND FITMENT	TATA spare parts
550758900616	TOOL - STRETCH BELT FITMENT	TATA spare parts
550758900617	DRIFT - FITMENT OF FRONT SEAL	TATA spare parts
550758900618	TOOL - STRETCH BELT REMOVAL	TATA spare parts
550758900619	BOLT HEX FL FOR FIP SPROCKET	TATA spare parts
550758900620	HOLDER FAN PULLEY TOOL	TATA spare parts
550758900621	HOLDER	TATA spare parts
550758900622	PULLER	TATA spare parts
550758900623	TOOL FOR REMOVAL OF OIL SUMP	TATA spare parts
550758900624	TOOL FOR REMOVAL OF OIL SUMP	TATA spare parts
550758900625	FUEL INJECTION PUMP REMOVAL TOOL	TATA spare parts
550758900626	SOCKET FOR REMOVAL AND FITMENT OF AIR CO	TATA spare parts
550758900627	TOOL FOR REMOVAL OF OIL SUMP	TATA spare parts
550758900629X	SUPPORT STAND ENGINE	TATA spare parts
550758900631	DRIFT CRANKSHAFT OIL SEAL FRONT	TATA spare parts
550758900632	DRIFT CRANKSHAFT OIL SEAL REAR	TATA spare parts
550758900634	LOCKING TOOL FLYWHEEL	TATA spare parts
550758900635	TOOL REMOVAL OF STRETCH BELT	TATA spare parts
550758900636	SPANNER	TATA spare parts
550758900637	HOLDER FAN PULLEY	TATA spare parts



550758900638	TOOL STRETCH BELT MTG	TATA spare parts
550758900640	SPANNER	TATA spare parts
550758900641	CRANKSHAFT ROTATION TOOL	TATA spare parts
550758900642	SPANNER	TATA spare parts
550758900643	SPANNER	TATA spare parts
550758900644	LOCKING TOOL FLYWHEEL	TATA spare parts
550758900645	PULLER FLYWHEEL	TATA spare parts
550758900646	PULLER ASSY	TATA spare parts
550758900701	PULLER	TATA spare parts
550758900702	PULLER INJECTOR REMOVAL	TATA spare parts
550758900703	ADAPTER CHECKING ENGINE COMPRESSION	TATA spare parts
550758901401	SPANNER	TATA spare parts
550758903501	SOC 95 HEX-3/4IN SQX60L/H-LOCK NUT/RA106	TATA spare parts
550758903502	MOUNTING PLATE/CARRIER HOUSING/RA /1055	TATA spare parts
550758903503	T-PINION DEPTH MEASUREMENT GAUGE/RA/106	TATA spare parts
550758903504	MOUNTING PLATE/CARRIER HSG ASSY/ RA/1068	TATA spare parts
550758903505	HOLDER FOR COUPLING FLANGE / RA 1068	TATA spare parts
550758903507	DRIFT/ INSTALL PINION NOSE BRG/ RA /1068	TATA spare parts
550758903508	HOOK FOR LIFTING CARRIER HSG ASSY/RA1068	TATA spare parts
550758903509	SPANNER	TATA spare parts
550758904007	JACK HANDLE	TATA spare parts
550758904008	ASSY. HYD. JACK-6T	TATA spare parts
550758904201	P-TOOL / DIRT EXCULDER / 71ST2021	TATA spare parts
550758904202	TOOL / SHOW HOLD DOWN PIN / 71ST2023	TATA spare parts
550758904203	ADJUSTING TOOL / 71ST2024	TATA spare parts
550758904204	EXCLUDER GUIDE / 71ST2025	TATA spare parts
550758904205	SPRING EXPANDER TOOL / 71ST2026	TATA spare parts
550758904206	FIXTURE / RB CALIPER TABLE / 71ST2027	TATA spare parts
550758904207	TOOL / RB CALIPER PISTON RETRACTION / 71	TATA spare parts
550758904208	PISTON HOLD / 71ST2029	TATA spare parts
550758904209	WOODEN BLOCK / 71ST2030	TATA spare parts
550758990101	KIT-AIS 140 12V 8-9.4M	TATA spare parts
550758990102	KIT-AIS 140 24V 8-9.4M	TATA spare parts
550758990103	KIT-AIS 140 12V 10.1-11.5M	TATA spare parts
550758990104	KIT-AIS 140 24V 10.1-11.5M	TATA spare parts
550758990105	KIT-AIS 140 24V 10.1-11.5M MUX	TATA spare parts
55075945000R40	PARTIALLY FITTED CAB W/O ELECT&CONTROLS	TATA spare parts
55076000003R40	ASSEMBLY BODY FITTED	TATA spare parts
55076000004L40	PARTIALLY FITTED CAB W/O ELECT& AMP CONT	TATA spare parts
55076000010R40	ASSEMBLY BODY FITTED	TATA spare parts
550760000110	ASSY.STRUCTURE WELDED COMP.FACELESS BS-I	TATA spare parts
550760000125	ASSY.STR.WELDED COMP ULTRA LPO 3L	TATA spare parts
550760000129	TRIMMED FES-9.6T 497BS-3 N-ABS N-AC 12V	TATA spare parts
550760000130	DRIVER STATION ASSY	TATA spare parts
55076000013R40	PARTIALLY FITTED CAB ULTRA T.11	TATA spare parts
550760000148	FES ASSY WITH FITMENT	TATA spare parts
550760010102	DRIVER STATION ASSY WITH CED COATING BS6	TATA spare parts

550760010105	DRIVER STATION ASSY WITH CED COATING BS6	TATA spare parts
550760010106	DRIVER STATION ASSY BS6	TATA spare parts
550760010110	DRIVER STATION ASSY WITH CED COATING	TATA spare parts
550760110209	DRIVER SEAT MTG BKT ASM FOR BUS	TATA spare parts
550760110245	HEADLAMP ASSY RH BS6-PH2	TATA spare parts
550760110248	CROSS MEMBER ASSY FRAME FRONT BS6	TATA spare parts
550760110249	CROSS MEMBER ASSY FRONT BS6	TATA spare parts
550760110257	CANOPY MTG STRUCTURE ASSY BS6	TATA spare parts
550760110258	HEADLAMP ASSY LH BS6	TATA spare parts
550760110261	FLOOR PANEL DRIVER STATION BS6	TATA spare parts
550760128298	HEADLAMP PLATE SUPPORT BS6-PH2	TATA spare parts
550760136954	TUBE REAR BS6	TATA spare parts
550760136955	TUBE REAR SUPPORT BS6	TATA spare parts
550760138228	FRONT PANEL	TATA spare parts
550760138235	PANEL TOP	TATA spare parts
550760CK0198	FULLY FITTED CAB WITH ELECTRICALS & CO	TATA spare parts
550760CK0199	TATA ULTRA 912-45WB BSIII HDLB	TATA spare parts
550768700103	KIT-INSULATION BS6-PH2	TATA spare parts
550768706303	INSULATION BS6	TATA spare parts
550768706304	INSULATION BS6	TATA spare parts
550768706305	INSULATION BS6	TATA spare parts
550768706306	INSULATION BS6	TATA spare parts
550768706307	INSULATION BS6	TATA spare parts
550768706308	INSULATION BS6	TATA spare parts
550768706309	INSULATION BS6	TATA spare parts
550768706310	INSULATION BS6	TATA spare parts
550768706313	INSULATION BS6	TATA spare parts
550768706314	INSULATION BS6	TATA spare parts
550768706355	INSULATION	TATA spare parts
550768706356	INSULATION	TATA spare parts
550782400101	WIPER SYSTEM RHD-24V Y1BUS	TATA spare parts
550782400106	WIPER LINKAGE ASSEMBLY	TATA spare parts
550782400108	WIPER MOTOR - 24V	TATA spare parts
550782400109	WIPER ARM ASSY - DRIVER	TATA spare parts
550782400110	WIPER ARM ASSY - CO-DRIVER	TATA spare parts
550782400111	WASHER BOTTLE ASSEMBLY-24V	TATA spare parts
550782400112	ASSY. WIPER BLADE 28IN BS2/3/4	TATA spare parts
550782400113	WASHER BOTTLE ASSEMBLY-12V	TATA spare parts
550782400114	WIPER MOTOR 12V	TATA spare parts
550782400115	KIT-WASHER SYSTEM	TATA spare parts
550782400116	KIT-WASHER SYSTEM	TATA spare parts
550782400118	WIPER ARM ASSY WITH BLADE CO-DRIVER SIDE	TATA spare parts
550782400119	WIPER ARM ASSY WITH BLADE DRIVER SIDE BS	TATA spare parts
550782400123	WIPER BLADE ASSY BS6	TATA spare parts
550782400124	WIPER ARM ASSY CO-DRIVER SIDE BS6	TATA spare parts
550782400125	WIPER ARM ASSY DRIVER SIDE BS6	TATA spare parts
550782400126	WIPER ARM ASSY WITH BLADE DRIVER SIDE BS	TATA spare parts

550782400127	WIPER ARM ASSY WITH BLADE CO-DRIVER SIDE	TATA spare parts
550782400128	WIPER ARM ASSY WITH BLADE DRIVER SIDE BS	TATA spare parts
550782400129	WIPER ARM ASSY DRIVER SIDE BS6	TATA spare parts
550782400130	WIPER LINK ASSY WITH MOTOR BS6	TATA spare parts
550782400135	WIPER BLADE ASSY BS6	TATA spare parts
550782400139	WIPER LINKAGE ASSY BS6	TATA spare parts
550782400141	BRACKET ASSY SUPPORT ARM MTG DRIVER SIDE	TATA spare parts
550782400142	WIPER BLADE ASSY BS6	TATA spare parts
550782400143	WIPER LINK ASSY WITH MOTOR BS6	TATA spare parts
550782400145	WIPER ARM ASSY WITH BLADE DRIVER SIDE BS	TATA spare parts
550782400146	WIPER ARM ASSY WITH BLADE CO-DRIVER SIDE	TATA spare parts
550782400147	WIPER ARM ASSY CO-DRIVER SIDEBS6	TATA spare parts
550782400148	WIPER ARM ASSY DRIVER SIDE BS6	TATA spare parts
550782400150	WIPER LINK ASSY WITH MOTORBS6	TATA spare parts
550782400152	WIPER LINKAGE ASSY BS6	TATA spare parts
550782400165	WIPER ARM ASSY WITH BLADE DRIVER SIDE	TATA spare parts
550782400166	WIPER ARM ASSY DRIVER SIDE	TATA spare parts
550782400167	WIPER BLADE ASSY	TATA spare parts
550782400168	BRACKET ASSY SUPPORT ARM MTG DRIVER SIDE	TATA spare parts
550782400175	WIPER LINK ASSY WITH MOTOR BS6-PH2	TATA spare parts
550782400303	WIPER MOTOR & LINKAGE SYSTEM 24 VOLT	TATA spare parts
550782400304	WIPER LINKAGE SYSTEM 12 VOLT (WIPER MOTO	TATA spare parts
550782400305	WIPER ARM AND BLADE DRIVER SIDE	TATA spare parts
550782400306	WIPER ARM AND BLADE CO-DRIVER SIDE	TATA spare parts
550782400311	WIPER ARM ASSY	TATA spare parts
550782400312	WIPER ARM CO DRIVER SIDE	TATA spare parts
550782400313	WIPER BLADE DR AND CO-DR	TATA spare parts
550782400321	WIPER LINKAGE	TATA spare parts
550782406301	WASHER&TANK&RHD BS6	TATA spare parts
550782406302	CAP OF WASHER BOTTLE - M/S. FICOSA BS6	TATA spare parts
550782407501	GROMMET(WASHER&BOTTLE&LEVEL&SENSOR) BS	TATA spare parts
550782407502	GROMMET(WASHER BOTTLE WATER PUMP)	TATA spare parts
550782409907	WASHER&BOTTLE&LEVEL&SENSOR BS6	TATA spare parts
550782409910	WASHER BOTTLE PUMP-12V	TATA spare parts
550782409911	HOSE&PIPE&L=900&ID4&OD7 BS6	TATA spare parts
550782409913	HOSE&PIPE&L=750&ID4&OD7 BS6	TATA spare parts
550782409916	WIPER MOTOR 24V LTVS	TATA spare parts
550782409917	WIPER MOTOR 12 VOLT	TATA spare parts
550782409919	PUMP ASSY BS6	TATA spare parts
550782409920	SEAL CAP BS6	TATA spare parts
550782409921	RUBBER SEAL IN CAP BS6	TATA spare parts
550782409922	HOSE TUBE BS6	TATA spare parts
550782409923	HOSE TUBE BS6	TATA spare parts
550782409924	RESERVIOR BS6	TATA spare parts
550782409925	BREATHER TUBE BS6	TATA spare parts
550782409926	CONNECTOR ASSY BS6	TATA spare parts
550782449901	WASHER BOTTLE PUMP-24V BS6	TATA spare parts

550782900101	KIT-WASHER SYSTEM BS6	TATA spare parts
550782900102	KIT-WASHER SYSTEM BS6	TATA spare parts
550782907704	CAP&SEAL BS6	TATA spare parts
550783505801	RUBBER HOSE(17 ID X L 900)	TATA spare parts
550783505802	RUBBER HOSE(17 ID X L 2000)	TATA spare parts
550783550101	KIT-AC PARTS ON ENGINE BS6	TATA spare parts
550788700106	ENGINE HOOD ASSY BS6-PH2	TATA spare parts
550788707703	SEAL BS6-PH2	TATA spare parts
550788707704	RBR BELLOW GR SHIFT LEVER UPPER BS6-PH2	TATA spare parts
550791000103	DRIVER SEAT ASSY	TATA spare parts
550791000104	DRIVER SEAT ASSY	TATA spare parts
5507D1A1860001	FES STRUCTURE BS6-PH2	TATA spare parts
550824100108	ENGINE MTG FRONT-RH	TATA spare parts
550824100109	ENGINE MTG FRONT-LH	TATA spare parts
550824100166	ENGINE MOUNT ASSY FRONT-LH	TATA spare parts
550824100167	ENGINE MOUNT ASSY FRONT-RH	TATA spare parts
550824200101	REAR ENGINE MOUNT G400 3L BS4	TATA spare parts
550824208207	CROSS MEMBER MOUNT	TATA spare parts
550829300107	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
550829300121	NYLON PIPE ASSY BS6	TATA spare parts
550831000184	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
550831200103	CROSS MEMBER ASSY	TATA spare parts
550831400109	CROSS MEMBER ASSY	TATA spare parts
550831400118	SUPPORT BRACKET ASSY	TATA spare parts
550831407120	COBRA BKT	TATA spare parts
550831407121	COBRA BKT	TATA spare parts
550831408228	REINFORCEMENT FRONT SPRING HANGER RH	TATA spare parts
550831408229	REINFORCEMENT FRONT SPRING HANGER LH	TATA spare parts
550831408234	PLATE REINFORCEMENT RH	TATA spare parts
550831408235	PLATE REINFORCEMENT LH	TATA spare parts
550831408249	REINFORCEMENT SPRING HANGER BKT REAR-RH	TATA spare parts
550831408250	REINFORCEMENT SPRING HANGER BKT REAR-LH	TATA spare parts
550831408251	REINFORCEMENT RH	TATA spare parts
550831408270	REINFORCEMENT LH	TATA spare parts
550832107121	SHACKLE PLATE (FRONT)	TATA spare parts
550832200103	ASSY.RUBBER BUSH (DIA 22)	TATA spare parts
550832200105	ASSY. RUBBER BUSH 22 DIA. BS3/4	TATA spare parts
550832300103	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
550832400122	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
550832400130	LEAF SPRING ASSY REAR BS6	TATA spare parts
550832400134	LEAF SPRING ASSY REAR	TATA spare parts
550832407102	3RD LEAF BS6	TATA spare parts
550832407103	7TH LEAF BS6	TATA spare parts
550832407104	5TH LEAF BS6	TATA spare parts
550832407107	4TH LEAF BS6	TATA spare parts
550832407108	8TH LEAF BS6	TATA spare parts
550832407109	2ND LEAF BS6	TATA spare parts

550832407110	6TH LEAF BS6	TATA spare parts
550832600104	ASSY.REAR SHOCK ABSORBER	TATA spare parts
550833000107	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
550833000111	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
550833200107	STUB AXLE ASSY RH BS6	TATA spare parts
550833200108	STUB AXLE ASSY LH BS6	TATA spare parts
550833200111	STUB AXLE ASSY LH BS6	TATA spare parts
550833200112	STUB AXLE ASSY RH BS6	TATA spare parts
550833200115	STUB AXLE ASSY RH BS6-PH2	TATA spare parts
550833200116	STUB AXLE ASSY LH BS6-PH2	TATA spare parts
550833805104	STEERING ARM BS6	TATA spare parts
550833805105	STEERING ARM BS6	TATA spare parts
550840100106	ASSY WHEEL RIM 6.75X17.5 PCD205 OFSET115	TATA spare parts
550840206701	HUB PIN	TATA spare parts
550840300106	SPARE WHEEL CARRIER ASSY	TATA spare parts
550840300107	BKT. STRUCTURE ASSY. BS6	TATA spare parts
550840300108	HOLDING BRACKET ASSY BS6	TATA spare parts
550840300113	SPAREWHEELCARRIERASSYBS6	TATA spare parts
550840307101	SPARE WHEEL CARRIER ATTACHMENT PLATE	TATA spare parts
550841120175	PROPELDR SHAFT ASSY DRIVE BS6	TATA spare parts
550841127702	PROPELLER SHAFT SEAL	TATA spare parts
550841128205	PROPELLER SHAFT SEAL GUARD	TATA spare parts
550841307111	CENTER BEARING MOUNTING BRACKET	TATA spare parts
550841308201	PROPELLER SHAFT GUARD	TATA spare parts
550841308210	PROPELLER SHAFT GUARD-BOTTOM 6.5T	TATA spare parts
550841990102	STUB YOKE	TATA spare parts
550841990103	SLIP YOKE ASSY	TATA spare parts
550842100112	DRUM BRAKE ASSY RHBS6	TATA spare parts
550842100113	DRUM BRAKE ASSY LHBS6	TATA spare parts
550842300111	DRUM BRAKE ASSY REAR-RH BS6	TATA spare parts
550842300112	DRUM BRAKE ASSY REAR-LH BS6	TATA spare parts
550842303701	BRACKET ACTUATOR MTG LH	TATA spare parts
550842303702	BRACKET ACTUATOR MTG RH	TATA spare parts
550842700101	BRACKET ASSY PARKING CABLE MTG BS6	TATA spare parts
550842700103	BRACKET ASSY BS6-PH2	TATA spare parts
550842700113	PARKING BRAKE CABLE ASSY BS6	TATA spare parts
550842700114	PARKING BRAKE LEVER ASSY BS6	TATA spare parts
550842700116	BRACKET ASSY PARKING BRAKE LEVER MTG BS6	TATA spare parts
550842800101	ASSY. BRACKET FOR LCRV MTG. BS6	TATA spare parts
550843200101	ASSY. BRAKE FLUID RESERVOIR VADC-RHD BS6	TATA spare parts
550843400102	ASSY EXHAUST BRAKE UNIT W/O VACCUM CYL	TATA spare parts
550843500101	CAMSHAFT DRIVEN VACUUM PUMP BS4	TATA spare parts
550843700101	ASSY. BELT DRIVEN COMPR.(160CC) BS3/4/6	TATA spare parts
550843700103	MAJOR OVERHAUL	TATA spare parts
550843700104	HEAD MAJORç KIT	TATA spare parts
550843700105	PISTON REPAIR	TATA spare parts
550843700106	PR REPAIRç KIT	TATA spare parts

550843800202	TUBE ASSY ADAPTER TO LCRV BS6	TATA spare parts
550843800203	BUNDY TUBE FRONT T-CONN TO ADAPTER BS6	TATA spare parts
550843800206	TUBE ASSY REAR T-CONN TO BRAKE ASSY LH B	TATA spare parts
550843800207	TUBE ASSY REAR T-CONN TO REAR BRAKE RH B	TATA spare parts
550843803301	BRACKET LCRV LINK MTG BS6	TATA spare parts
550843803304	BRACKET LCRV LINK MTG BS6	TATA spare parts
550843806805	ELBOW CONNECTOR BS6	TATA spare parts
550843808213	ADAPTER PLATE BS6	TATA spare parts
550843810150	HOSE ASSY RESERVOIR BS6	TATA spare parts
550843820121	TUBE ASSY-ADAPTER TO REAR ADAPTER BS6	TATA spare parts
550843820124	TUBE ASSY-ADAPTER TO LCRV BS6	TATA spare parts
550843900208	NYLON PIPE ASSY VACUUM LINE BS6	TATA spare parts
550843900254	NYLON PIPE ASSY VACUUM LINE BS6	TATA spare parts
550843907502	RUBBER GROMMET (FOR BOOSTER PIPE) BS6	TATA spare parts
550846100104	INTERMEDIATE SHAFT ASSY BS6	TATA spare parts
550846305102	PITMAN ARM	TATA spare parts
550846305106	PITMAN ARM BS6	TATA spare parts
550846708001	HEX SCREW	TATA spare parts
550846800111	ASSY. HIGH PR. LINE (PUMP TO GEAR) BS3	TATA spare parts
550846800112	ASSY. RETURN LINE - RHD (STRG. GEAR BOX	TATA spare parts
550846800113	ASSY. SUCTION LINE (RESERVIOR TO PUMP)	TATA spare parts
550846800120	RETURN LINE ASSY	TATA spare parts
550846800129	SUCTION LINE ASSY	TATA spare parts
550846800151	SUCTION LINE ASSY	TATA spare parts
550846900107	DRAG LINK ASSY BS6	TATA spare parts
550847103304	BRACKET FOR BABY FILTER	TATA spare parts
550847500112	SPACER BRKT ASSY FUEL TANK MTG BS6-PH2	TATA spare parts
550847507101	SPACER PLATE FOR FUEL TANK MTG (LPO BUS)	TATA spare parts
550847610127	SUCTION FUEL PIPE ASSY BS6-PH2	TATA spare parts
550847610128	FUEL PIPE ASSY FILTER TO FIP BS6-PH2	TATA spare parts
550847610136	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
550847610138	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
550849103305	BRACKET DOC POC MTG	TATA spare parts
550849105801	HOSE	TATA spare parts
550849200101	BRACKET ASSY BS6	TATA spare parts
550849203309	BRACKET FRONT PIPE MTG BS6-PH2	TATA spare parts
550849203310	BRACKET BS6-PH2	TATA spare parts
550849600104	HEAT SHIELD TAIL PIPE BS6	TATA spare parts
550854200103	BRACKET ASSY INSTRUMENT CLUSTER MTG BS6	TATA spare parts
550854200106	INSTR. CLUSTER INTERFACE HARDWARE BS3/4	TATA spare parts
550854206301	COVER INSTRUMENT CLUSTER	TATA spare parts
550854600120	BRACKET ASSY(LPO BUS 497ENG INLINE CONNE	TATA spare parts
550854600123	ASSY OF BRACKET & STRIP PLATE FOR CAB	TATA spare parts
550854600125	BRACKET ASSY CONNECTOR MTG	TATA spare parts
550854600144	W/H FRONT CHASSIS	TATA spare parts
550854600145	WIRING HARNESS FRONT CHASSIS	TATA spare parts
550854601605	W/H LOAD BODY 3920WB	TATA spare parts

550854601641	W/H LOAD BODY 33WB/35 WB	TATA spare parts
550854603302	BRACKET FIREWALL & IP INLINE CONN MTG	TATA spare parts
550854610123	CYLINDER EARTHING ASSY BS6	TATA spare parts
550854629981	W/H 497 12V TRUCK REAR CHASSIS 3310WB	TATA spare parts
550854629982	W/H 497 12V TRUCK REAR CHASSIS 3920WB	TATA spare parts
550854629983	W/H 497 12V TRUCK REAR CHASSIS 4530WB	TATA spare parts
550854629984	WIRING HARNESS FRONT CHASSIS	TATA spare parts
550854629985	W/H FRONT CHASSIS	TATA spare parts
550854629989	WIRING HARNESS REAR CHASSIS 3310WB	TATA spare parts
550854629990	WIRING HARNESS REAR CHASSIS 3920WB	TATA spare parts
550854629991	WIRING HARNESS REAR CHASSIS 4530 WB	TATA spare parts
550854709901	YAW RATE SENSOR	TATA spare parts
550854709902	STEERING-WHEEL-ANGLE SENSOR	TATA spare parts
550858408204	SPEED LIMIT - LABEL	TATA spare parts
550858903501	DRIFT BS6-PH2	TATA spare parts
550858903502	DRIFT BS6-PH2	TATA spare parts
550858903505	ADAPTOR THREAD PROTECTION TOOL BS6-PH2	TATA spare parts
550882400103	WASHER BOTTLE ASSY FOR WIDER RHD 12V	TATA spare parts
550882406301	RUBBER GROMMET FOR WASHER PIPING	TATA spare parts
550882408203	BRACKET(WIPER MOTOR CABLE MTG)	TATA spare parts
550882409901	WIPER MOTOR 12V RHD	TATA spare parts
550882409911	WIPER MOTOR ASSY NARROW 12V RHD	TATA spare parts
550882409919	PUMP ASSY	TATA spare parts
550882440104	WASHER BOTTLE ASSY FOR WIDER LHD	TATA spare parts
550882449902	WIPER MOTOR 24V RHD	TATA spare parts
550882449903	WIPER MOTOR 24V LHD	TATA spare parts
550882900107	KIT-WASHER SYSTEM	TATA spare parts
551015103201	HEX SCREW	TATA spare parts
551015108204	COVER DISC	TATA spare parts
551015109907	DRIVE END FLANGE	TATA spare parts
551015109910	STOP RING	TATA spare parts
551015109911	OVER RUNNING CLUTCH DRIVE	TATA spare parts
551015109912	FORK LEVER	TATA spare parts
551015109913	BEARING PEDESTAL	TATA spare parts
551015109914	SEAL	TATA spare parts
551015109917	EPICYCLOIDAL GEAR TRAIN	TATA spare parts
551015109918	ARMATURE	TATA spare parts
551015109919	STARTER FRAME	TATA spare parts
551015109921	COMMUNTER END SHIELD	TATA spare parts
551015109922	SHIM	TATA spare parts
551015109924	CLOSER CAP	TATA spare parts
551015109927	HEX FLANGE NUT	TATA spare parts
551015109929	HEX NUT M8	TATA spare parts
551015109930	SPRING LOCK WASHER	TATA spare parts
551015109931	HEX NUT	TATA spare parts
551015109932	SPRING LOCK WASHER	TATA spare parts
551015109933	HEX NUT M5	TATA spare parts

551015109934	SEALING CAP	TATA spare parts
551015109936	SOLENOID SWITCH	TATA spare parts
551015109937	BRUSH HOLDER	TATA spare parts
551015109938	CAPSULE	TATA spare parts
551015109939	FLANGE NUT	TATA spare parts
55110860616	ENGINE OIL SAE 15W40 GEO	TATA spare parts
551115400101	ALTERNATOR 12V, 117A,VAC PUMP	TATA spare parts
551115400102	ALTERNATOR 12V 75A VAC 57 DIA 6PK-L	TATA spare parts
551115400106	STARTER MOTOR GEAR RED. R78-M10	TATA spare parts
551115409902	PULLEY	TATA spare parts
551115409907	INSERT	TATA spare parts
551115409908	INSERT	TATA spare parts
551115409910	ROTOR ASSLY	TATA spare parts
551115409911	S.R.E BEARING	TATA spare parts
551115409912	STATOR WINDING ASSY.FINAL	TATA spare parts
551115409914	SLIDING BUSH	TATA spare parts
551115409915	RECTIFIER ARRANGEMENT	TATA spare parts
551115409916	REGULATOR CUM BRUSH BOX ARRANGEMENT FI	TATA spare parts
551115409917	BAFFLE PLATE	TATA spare parts
551115409918	PLAIN WASHER	TATA spare parts
551115409919	SPRING WASHER	TATA spare parts
551115409921	OIL SEAL	TATA spare parts
551115409922	LOCKING DISC	TATA spare parts
551115409925	SPRING WASHER	TATA spare parts
551115409926	NUT	TATA spare parts
551115409927	PLAIN WASHER	TATA spare parts
551115409928	SPRING WASHER	TATA spare parts
551115409929	NUT	TATA spare parts
551115409930	PLUG MOULDING ASSY.	TATA spare parts
551115409931	HOUSING M/C	TATA spare parts
551115409932	O RING	TATA spare parts
551115409933	SEALING WASHER	TATA spare parts
551115409934	CHECK VALVE ASSY	TATA spare parts
551115409935	SUCTION CONNECTOR ASSY	TATA spare parts
551115409936	SEALING WASHER	TATA spare parts
551115409937	SUCTION CONNECTOR SCREW	TATA spare parts
551115409938	SEALING WASHER	TATA spare parts
551115409939	CONNECTOR ASSY.(DELIVERY)	TATA spare parts
551115409940	SCREW	TATA spare parts
551115409941	OIL INLET PLUG	TATA spare parts
551115409942	D.E BRACKET ASSY.	TATA spare parts
551115409943	S.R.E BRACKET COMPLETE ASSY.	TATA spare parts
551115409944	VACUUM PUMP ASSY	TATA spare parts
551115409945	PULLEY	TATA spare parts
551115409978	REGULATOR CUM BRUSH BOX ASSY	TATA spare parts
551115409980	SRE BRACKET ASSEMBLY	TATA spare parts
55112003CN	HEAD LAMP ASSY CONTESSA/RHD-LH	TATA spare parts



55112004CN	HEAD LAMP ASSY CONTESSA/RHD-RH	TATA spare parts
55112024CN	TWIN HEAD LAMP CONTESSA/LHD-LH	TATA spare parts
55112025CN	TWIN HEAD LAMP CONTESSA/LHD-RH	TATA spare parts
551120430001	HEAD LAMP ASSY RH 24V	TATA spare parts
551120440001	HEAD LAMP ASSY LH 24V	TATA spare parts
551129100129	CLUTCH HOSE BS4	TATA spare parts
551131000101	ASSY. FRAME (VICTA DI BS-IV)	TATA spare parts
551132100115	ASSY. CAMBER BOLT.	TATA spare parts
551132108703	SPRING-FRONT SUSPENSION	TATA spare parts
551132108708	SPRING-FRONT SUSPENSION	TATA spare parts
551132108709	SPRING-FRONT SUSPENSION	TATA spare parts
551132108710	SPRING-FRONT SUSPENSION	TATA spare parts
551132108711	SPRING-FRONT SUSPENSION	TATA spare parts
551132108712	SPRING-FRON SUSPENSION	TATA spare parts
551132109202	TONGUE WASHER	TATA spare parts
551132400104	ASSY. REAR LEAF SPRING	TATA spare parts
551140100104	ASSY WHEEL COVER	TATA spare parts
551141100101	KIT-UNIVERSAL JOINT BS4	TATA spare parts
551141103201	CAP SCREW	TATA spare parts
551141109901	BEARING STRAP	TATA spare parts
551142300101	KIT BLEED SCREW	TATA spare parts
551142300102	KIT W C (MINOR) (SUMO GOLD)	TATA spare parts
551142300103	KIT-LINED SHOE BS1/2/3/4	TATA spare parts
551142300104	KIT SCRW & WASHER	TATA spare parts
551142300105	KIT LEVER ASSY-LH	TATA spare parts
551142300106	KIT LEVER ASSY-RH	TATA spare parts
551142300107	KIT LEVER PAWL LH	TATA spare parts
551142300108	KIT LEVER PAWL RH	TATA spare parts
551142300109	W C ASSY (SUMO GOLD)	TATA spare parts
551142300114	KIT-LINED SHOE WITH B/B LEVER (M/S BIL-2	TATA spare parts
551142300115	KIT SCREW & WASHER	TATA spare parts
551142300116	KIT LEVER ASSY-LH	TATA spare parts
551142300117	KIT LEVER ASSY-RH	TATA spare parts
551142300118	KIT LEVER PAWL LH	TATA spare parts
551142300119	BRAKE SHOE ASSY WITH LEVER LH -	TATA spare parts
551142300120	ASSY REAR BRAKE RH(VA/VE AL W\CYL)	TATA spare parts
551142300121	WHEEL CYLINDER ASSY	TATA spare parts
551142300122	KIT LEVER PAWL RH	TATA spare parts
551142300127	ASSY.REAR BRAKE LH	TATA spare parts
551142300128	ASSY.REAR BRAKE RH(AL W\CYL)	TATA spare parts
551142300129	WHEEL CYLINDER	TATA spare parts
551142700108	ASSY. PARKING BRAKE CABLE REAR (LH)	TATA spare parts
551142700109	ASSY. PARKING BRAKE CABLE REAR (RH)	TATA spare parts
551142700112	ASSY. PARKING BRAKE LEVER WITH COVER	TATA spare parts
551142700113	ASSY. PARKING BRAKE CABLE (FRNT)	TATA spare parts
551142800103	ASSY. TUBE (ADAPTER TO LCRV)	TATA spare parts
551142800104	ASSY. TUBE (TMC TO ADAPTER)	TATA spare parts

551146207901	STEERING SPINDLE BOTTOM BS6	TATA spare parts
551146805802	SUCTION HOSE (RESERVOIR TO PUMP)	TATA spare parts
551147100106	ASSY SEDIMENTOR BKT COMPLETE	TATA spare parts
551147508206	CLAMPING PLATE (FUEL LINES)	TATA spare parts
551147508209	BRACKET (FUEL LINE MTG.)	TATA spare parts
551147600128	ASSY PRIMING PUMP	TATA spare parts
551147604201	SEPERATOR CLAMP FOR FUEL LINES	TATA spare parts
551147604202	SEPERATOR CLAMP BS6	TATA spare parts
551147605801	BREATHER HOSE	TATA spare parts
551149100102	ASSY.SILENCER WITH HOOK	TATA spare parts
551149200103	ASSY.FRONT PIPE EXHAUST	TATA spare parts
551149200104	ASSY.INTERMEDIATE PIPE EXHAUST	TATA spare parts
551149200106	ASSY.MIDDLE PIPE EXHAUST	TATA spare parts
551149200108	ASSY TAIL PIPE (EXHAUST)	TATA spare parts
551149200109	ASSY INTERMEDIATE PIPE (EXHAUST)	TATA spare parts
551149200110	ASSY FRONT PIPE (EXHAUST)	TATA spare parts
551154100103	KIT ASSY BATTERY CABLE +VE & -VE. SUMO B	TATA spare parts
551154109906	EARTH STRAP	TATA spare parts
551154200101	ELEC.INST.CLUSTER FOR VICTA DI-GX	TATA spare parts
551154200102	ELEC.INST.CLUSTER FOR VICTA DI-EX	TATA spare parts
551154200106	ASSY INSTRUMENT CLUSTER FOR SUMO BS IV.	TATA spare parts
551154200165	ASSY DCM 2.5 ECU MTG BKT	TATA spare parts
551154400101	ASSY HEAD LAMP LH	TATA spare parts
551154400102	ASSY HEAD LAMP RH	TATA spare parts
551154400103	ASSY.ROOF LAMP W/E MARK BULB,W/O CONN-JA	TATA spare parts
551154400104	ROOF LAMP (LINEN)	TATA spare parts
551154500101	REV.LIGHT SW.W/300MM PIGTAIL	TATA spare parts
551154600108	W/H TAIL GATE FOR VICTA DI EX/LX/CX	TATA spare parts
551154600112	WIRING HARNESS TAIL VICTA DI	TATA spare parts
551154600114	KIT WIRING HARNESS VICTA DI EX PHASSE-II	TATA spare parts
551154600119	W/H EMS	TATA spare parts
551154600120	W/H FRONT SUMO BS IV	TATA spare parts
551154600121	W/H CABIN SUMO BS IV.	TATA spare parts
551154600122	W/H TAIL	TATA spare parts
551154600126	W/H ENGINE	TATA spare parts
551154608202	ANTI ROTATION BRACKET	TATA spare parts
551154608204	BRACKET CAM SENSOR HARNESS SUPPORT	TATA spare parts
551183400103	COMPRESSOR WITH DIA.95MM 6PK PULLEY	TATA spare parts
551183404208	EDGE CLAMP-DISCHARGE HOSE SUMO GOLD BSIV	TATA spare parts
551220140001	TAIL LAMP ASSY 24V	TATA spare parts
551220150001	TAIL LAMP ASSY 24V RH	TATA spare parts
551232103401	BIMETALLIC SPRING BUSH - 20 DIA	TATA spare parts
551232103402	BIMETALLIC SPRING BUSH - 22 DIA BS1-6	TATA spare parts
551232103402DF	BUSH REAR SPRING 22DIA-LPT407/709-LP712/	TATA spare parts
551232400104	ASSY. REAR PARABOLIC SPRING AMBULANCE	TATA spare parts
551232400106	ASSY REAR PARABOLIC SPRING AMBULANCE	TATA spare parts
551232400111	ASSY FIRST LEAF WITH BUSH	TATA spare parts

551232407111	SECOND LEAF	TATA spare parts
551232407112	THIRD LEAF	TATA spare parts
551232408301	CENTRE PAD	TATA spare parts
551240109902	TUBELESS TYRE LT315/75R16 8 PR ALL	TATA spare parts
551254200101	INSTRUMENT CLUSTER	TATA spare parts
551254209903	INSTRUMENT CLUSTER	TATA spare parts
551254608201	EMS W/H CONNECTOR SUPPORT BKT	TATA spare parts
551254608257	BRACKET L WH CLAMPING BS6	TATA spare parts
551331000105	ASSY. FRAME COMPLETE	TATA spare parts
551331000107	ASSY.FRAME COMPLETE	TATA spare parts
551331000109	ASSY.FRAME W/O CLEATS	TATA spare parts
551331000111	ASSY FRAME	TATA spare parts
551331000114	FRAME ASSY WITH FITMENT BS6	TATA spare parts
55133100M10114	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
551331200101	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
551331200102	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
551331200103	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
551331400101	COBRA BRACKET ASSY BS6-PH2	TATA spare parts
551331400102	COBRA BRACKET ASSY BS6-PH2	TATA spare parts
551332100103	1ST LEAF SPRING ASSY WITH BUSH BS6-PH2	TATA spare parts
551332100104	LEAF SPRING ASSY FRONT BS6-PH2	TATA spare parts
551332107101	3RD LEAF BS6-PH2	TATA spare parts
551332107103	2ND LEAF BS6-PH2	TATA spare parts
551332400102	1ST LEAF SPRING ASSY WITH BUSH BS6-PH2	TATA spare parts
551332400105	LEAF SPRING ASSY REAR BS6-PH2	TATA spare parts
551332400106	CLAMP ASSY BS6-PH2	TATA spare parts
551332407101	2ND LEAF BS6-PH2	TATA spare parts
551332407104	3RD LEAF BS6-PH2	TATA spare parts
551333000101	ASSY.FRONT AXLE WITH BRAKES	TATA spare parts
551341110101	PROPELLER SHAFT ASSY COUPLING(52WB) BS6	TATA spare parts
551341110102	PROPELLER SHAFT ASSY MONOTRON (52WB) BS6	TATA spare parts
551341110105	PROPELLER SHAFT ASSY BS6-PH2	TATA spare parts
551341110107	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
551341300103	SPT ASSY CENTER BRG CROSS MEMBER BS6-PH2	TATA spare parts
551341307101	BRACKET CENTER BRG MTG (52WB) BS6	TATA spare parts
551341307102	BRACKET CENTER BRG MTG (52WB) BS6	TATA spare parts
551341307114	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
551341307115	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
551343200101	SUB ASSY AIR TANK FOR VOSS LPT 809 (110)	TATA spare parts
551343200102	ASSY.AIR TANK WITH FITTINGS	TATA spare parts
551343700101	RELAY VALVE & MODULATOR VALVE ASSY BS6-P	TATA spare parts
551343700107	BRAKE VALVE ASSY BS6-PH2	TATA spare parts
551343700115	BRAKE CHAMBER BS6	TATA spare parts
551343708201	BRACKET BS6-PH2	TATA spare parts
551343708203	BRACKET BS6-PH2	TATA spare parts
551343900103	ASSY NYLON PIPE SET CHASS COMP LPT 809	TATA spare parts
551343900106	ASSY NYLON PIPE SET CHASSIS COMP	TATA spare parts

551343900117	ASSY NYLON PIPE SET CHASSIS COMPL 34WB	TATA spare parts
551343900121	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
551343900151	MET PIPE ASSY WITH CRIMPED HOSE BS6-PH2	TATA spare parts
551343900152	METAL PIPE ASSY HOSE TO JOINT BS6-PH2	TATA spare parts
551343900153	METAL PIPE ASSY JOINT 1 TO JOINT 2 BS6-P	TATA spare parts
551343900154	METAL PIPE ASSY JOINT TO DDU BS6-PH2	TATA spare parts
551347600101	ASSY.SUCTION LINE	TATA spare parts
551347600102	ASSY.SUCTION LINE	TATA spare parts
551347600103	ASSY.RETURN LINE	TATA spare parts
551354600101	WIRING HARNESS TAIL BS6	TATA spare parts
551354600104	WIRING HARNESS TAIL BS6	TATA spare parts
551354600105	WIRING HARNESS ABS BS6	TATA spare parts
551354600106	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
551354600107	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
551354640101	WIRING HARNESS ESC BS6-PH2	TATA spare parts
551354640102	WIRING HARNESS ABS BS6-PH2	TATA spare parts
551354640103	WIRING HARNESS SWITCH BS6-PH2	TATA spare parts
5513H9X0233001	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
5513H9X0233002	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
55140860084	LUBRI PASTE MOLYKOTE P40 DOW CORNING BS6	TATA spare parts
55140860459	GREASE 3% MOS2 SS6820 320 TS25205P1	TATA spare parts
551490000400	M16 X 2 X 130MM ALLEN BOLT ASSY	TATA spare parts
551490001200	M14 X 1.5 X 35MM HEX BOLT ASSY	TATA spare parts
551490001400	M14 X 1.5 X 45MM HEX BOLT ASSY	TATA spare parts
551490001500	M14 X 1.5 X 50MM HEX BOLT ASSY	TATA spare parts
551500000101	RETRO KIT LP 913/49WB CNG BS-IV	TATA spare parts
551515400101	ALTERNATOR	TATA spare parts
551515440101	ALTERNATOR 150A LCV BS4	TATA spare parts
551516172001	ECU BS6-PH2	TATA spare parts
551524200103	BRACKET ASSY ENGINE MTG REAR-LH	TATA spare parts
551524200104	BRACKET ASSY ENGINE MTG REAR-RH	TATA spare parts
551524203701	ENGINE MTG ARM	TATA spare parts
551529100103	CLUTCH PIPE ASSY FRONT	TATA spare parts
551529100104	CLUTCH PIPE ASSY (PURGE TANK TO CB)	TATA spare parts
551529100105	CLUTCH PIPE ASSY (PURGE T. TO3WAY VALVE)	TATA spare parts
551529100106	CLUTCH PIPE ASSY	TATA spare parts
551529300107	NYL PIPE ASSY T-CONN TO CLUTCH BOOSTER B	TATA spare parts
551529300108	BUNDY TUBE ASSY CLUTCH PIPE	TATA spare parts
551529300109	BUNDY TUBE ASSY CLUTCH PIPE	TATA spare parts
551529300111	BUNDY TUBE ASSY CLUTCH PIPE	TATA spare parts
551530100102	BRACKET ASSY ACCELERATOR PEDAL MTG	TATA spare parts
551531000103	ASSY FRAME COMPLETE (49 WB) LP 913	TATA spare parts
551531000105	ASSY. FRAME COMP LP 913 CNG AC	TATA spare parts
551531000107	FRAME ASSY COMP	TATA spare parts
551531000111	FRAME ASSY WITH FITMENT	TATA spare parts
551531000117	FRAME ASSY WITH FITMENT BS6	TATA spare parts
551531000119	FRAME ASSY WITH FITMENT	TATA spare parts

551531000121	FRAME ASSY WITH FITMENT BS6	TATA spare parts
551531200101	ASSY. CROSS MEMBER	TATA spare parts
551531200102	ASSY. JOINT GUSSET - LH	TATA spare parts
551531200104	ASSY JOINT GUSSET PLATE RH	TATA spare parts
551531200106	CROSS MEMBER ASSY	TATA spare parts
551531200113	BRACKETASSY ACCOMPRESSORMTG TOPBS6	TATA spare parts
551531200115	ASSY AC COMP.MTG BKT	TATA spare parts
551531200119	SPRING GUIDE BAR	TATA spare parts
551531200120	ASSY. RUBBER BUSH BS6-PH2	TATA spare parts
551531200121	ASSY.RUBBERBUSHCOMPLETEBS6	TATA spare parts
551531208201	REINFORCEMENT R.H.	TATA spare parts
551531208202	REINFORCEMENT L.H.	TATA spare parts
551531208203	REINFORCEMENT (RH) BOTTOM	TATA spare parts
551531208204	REINFORCEMENT (LH) BOTTOM	TATA spare parts
551531208226	SPRING SUPPORT TOP	TATA spare parts
551531208227	SPRING SUPPORT BOTTTOM	TATA spare parts
551531208251	REINFORCEMENT-LONG MEMBER(CYLINDER MTG	TATA spare parts
551531208252	REINFORCEMENT-LONG MEMBER(CYLINDER MTG	TATA spare parts
551531208254	TOPCLAMPBS6	TATA spare parts
551531208256	PLATEBS6	TATA spare parts
551531208257	RUBBERBUFFERBS6	TATA spare parts
551531208258	BANDED COGGED V BELT (TWIN GROOVE)	TATA spare parts
551531407101	L-BRACKET RH BS6	TATA spare parts
551531407102	L-BRACKET LH BS6	TATA spare parts
551531407103	L-BRACKET BS6	TATA spare parts
551531408205	REINFORCEMENT RH BS6	TATA spare parts
551531408206	REINFORCEMENT LH BS6	TATA spare parts
551531505105	TOW HOOK HOLDING BLOCK FRONT	TATA spare parts
551531540106	BATTERY SUPPORT ASSY BS6	TATA spare parts
551531703201	COLLAR SCREW (AC-COMPRESSOR MOUNTING)	TATA spare parts
551531703202	COLLARSCR.M10X858.8TS17215SS8451-8CBS6	TATA spare parts
551531708701	HELICAL COMPRESSION SPRING	TATA spare parts
551532100120	LEAF SPRING ASSY FRONT	TATA spare parts
551532100121	1ST LEAF ASSY WITH BUSH	TATA spare parts
551532107127	4TH LEAF	TATA spare parts
551532107128	2ND LEAF	TATA spare parts
551532107129	3RD LEAF	TATA spare parts
551532203701	GUIDE PLATE	TATA spare parts
551532800106	LINK ASSY ANTI ROLL BAR RH	TATA spare parts
551532800107	LINK ASSY ANTI ROLL BAR LH	TATA spare parts
551532900105	CONNECTING LINK ASSY REAR ANTI ROLL BAR	TATA spare parts
551533000102	ASSY.FRONT AXLE WITH BRK.(NON ASBESTOS)	TATA spare parts
551533000103	ASSY FRONT AXLE WITH BRAKES(NON ASBS)	TATA spare parts
551533000106	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
551533105104	FRONT AXLE BEAM	TATA spare parts
551533800102	TIE ROD ASSY	TATA spare parts
551540100104	WHEEL RIM ASSY WITH VALVE BS6	TATA spare parts

551541105101	FLANGE_YOKE	TATA spare parts
551541108201	PROP SHAFT GUARD	TATA spare parts
551541109901	UNIT PACK-CROSS KIT PROP SHAFT	TATA spare parts
551541110102	ASSY. PROPELLER SHAFT WITH CENTRE BEARIN	TATA spare parts
551541110108	ASSY PROPELLER SHAFT (FRONT)	TATA spare parts
551541110111	ASSY. UNITIZED PROP. SHAFT	TATA spare parts
551541110114	PROPELELR SHAFT ASSY COUPLING	TATA spare parts
551541110115	PROPELELRSHAFTASSY MONOTRON BS6	TATA spare parts
551541110118	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
551541110119	PROPELLER SHAFT ASSY	TATA spare parts
551541120101	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
551541307101	BRACKET CENTER BRG MTG	TATA spare parts
551541307102	BRACKET CENTER BRG MTG	TATA spare parts
551541307106	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
551541308201	L-BRACKET PROPELLERGUARD	TATA spare parts
551543700101	RELAY VALVE & MODULATOR VALVE ASSY W BKT	TATA spare parts
551543700116	BRAKE CHAMBER BS6	TATA spare parts
551543900118	ASSY NYLON PIPE SET CHASSIS COMPL LP913	TATA spare parts
551543900131	ASSY METAL PIPE DIA 12 DBV12 TO QRV	TATA spare parts
551543900132	ASSY METAL PIPE DIA 12 QRV TO FBC-LH	TATA spare parts
551543900133	ASSY METAL PIPE DIA 12 QRV TO FBC-RH	TATA spare parts
551543900134	ASSY METAL PIPE DIA 12 DBV11 TO RST	TATA spare parts
551543900135	ASSY METAL PIPE DIA 12 DBV12 TO FST	TATA spare parts
551543900136	ASSY METAL PIPE DIA 12 HBV TO RBA	TATA spare parts
551543900137	ASSY METAL PIPE DIA 6 HBV TO DDU	TATA spare parts
551543900138	ASSY METAL PIPE DIA 6 DBV TO RELAY VALVE	TATA spare parts
551543900141	ASSY METAL PIPE DIA 15 WITH CRIMPED HOSE	TATA spare parts
551543900142	ASSY METAL PIPE DIA 12 HBV TO RBA	TATA spare parts
551543900143	ASSY METAL PIPE DIA 6 HBV TO DDU	TATA spare parts
551543900144	ASSY METAL PIPE DIA 6 DDU TO PURG TANK	TATA spare parts
551543900145	ASSY METAL PIPE DIA 6 DDU TO CB	TATA spare parts
551543900150	ASSLY METAL PIPE DIA12 DBV TO RST	TATA spare parts
551543900151	ASSY METAL PIPE DIA12 HBV TO RBA1	TATA spare parts
551543900152	ASSLY METAL PIPE DIA12 HBV TO RBA2	TATA spare parts
551543900153	ASSLY METAL PIPE DIA12 FST TO DBV1	TATA spare parts
551543900154	ASSLY METAL PIPE DIA12 FST TO DBV	TATA spare parts
551543900155	ASSLY METAL PIPE DIA6 DBV TO RELAY VALVE	TATA spare parts
551543900156	ASSLY METAL PIPE DIA6 DBV TO RELAY VALVE	TATA spare parts
551543900157	ASSLY METAL PIPE DIA6 HBV TO DDU	TATA spare parts
551543900166	PIPE BUNCH ASSY	TATA spare parts
551543920102	PIPE ASSY BUNCH COMPLETE	TATA spare parts
551543920109	METALPIPEASSYHOSETOJOINTBS6	TATA spare parts
551543920110	METALPIPEASSYJOINTTODDUBS6	TATA spare parts
551543920112	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
551543920113	NYLON PIPE ASSY T-CONN TO RV BS6	TATA spare parts
551543920114	NYLON PIPE ASSY DDU TO RST BS6	TATA spare parts
551543920115	NYLON PIPE ASSY DDU TO FST BS6	TATA spare parts

551543920116	NYLON PIPE ASSY DBV TO T-CONN BS6	TATA spare parts
551543920117	PIPE ASSY RST TO T-CONN BS6	TATA spare parts
551543920118	NYLON PIPE ASSY T-CONN TO AIR TANK BS6	TATA spare parts
551543920119	NYLON PIPE ASSY HBV TO BULKHEAD BS6	TATA spare parts
551543920120	NYLON PIPE ASSY DDU TO HBV BS6	TATA spare parts
551543920121	NYLON PIPE ASSY DBV TO RELAY VALVE BS6	TATA spare parts
551543920122	NYLON PIPE ASSY DDU TO T-CONN BS6	TATA spare parts
551543920131	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
551543920132	METAL PIPE ASSY HOSE TO JOINT	TATA spare parts
551543920133	METAL PIPE ASSY HOSE TO JOINT	TATA spare parts
551543920134	METAL PIPE ASSY JOINT TO DDU	TATA spare parts
551543920185	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
551546100101	STEERING COLUMN ASSY BS6	TATA spare parts
551546100102	INTERMEDIATESHAFTASSY BS6	TATA spare parts
551546700103	BELLOW PLATE ASSY BS6-PH2	TATA spare parts
551546800104	ASSY SUCTION LINE-CRIMPED (TANK TO PUMP)	TATA spare parts
551546800105	ASSY PRESSURE LINE-CRIMPED (PUMP TO GB)	TATA spare parts
551546800120	SUCTIONLINEASSYBS6	TATA spare parts
551546800121	PRESSURELINEASSYBS6	TATA spare parts
551546800122	RETURN LINE ASSY BS6	TATA spare parts
551546800123	SUCTION LINE ASSY	TATA spare parts
551546800125	PRESSURE LINE ASSY	TATA spare parts
551546800126	RETURN LINE ASSY	TATA spare parts
551546900102	DRAG LINK ASSY	TATA spare parts
551547500105	ASSY.BRACKET -RH (END STOPPER)	TATA spare parts
551547500106	ASSY.BRACKET LH(END STOPPER)(406DIA CYL)	TATA spare parts
551547500109	ASSY.BRACKET WITH RUBBER(CYLINDER MTG)	TATA spare parts
551547500114	ASSY.STRAP WITH RUBBER(CYL.MTG)	TATA spare parts
551547508208	COMPLIANCE PLATE	TATA spare parts
551547600101	ASSY. FUEL LINE (F TANK-STRAINER)	TATA spare parts
551547600102	ASSY.NYLON FUEL LINE	TATA spare parts
551547600103	ASSY RETURN LINE.	TATA spare parts
551547600104	ASSY.RETURN LINE (ENGINE TO TANK)	TATA spare parts
551547600105	ASSY SUCTION LINE (STRAINER TO F.PUMP)	TATA spare parts
551547600119	SUCTION FUEL PIPE ASSY PRTFIL TO MAINFIL	TATA spare parts
551547600144	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600148	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600149	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600150	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600151	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600152	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600153	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600154	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600155	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600156	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600158	VENTTUBEASSYBS6	TATA spare parts
551547600159	VENTTUBEASSYBS6	TATA spare parts

551547600160	VENTTUBEASSYBS6	TATA spare parts
551547600161	VENTTUBEASSYBS6	TATA spare parts
551547600162	VENTPIPEASSYBS6	TATA spare parts
551547600163	VENTTUBEASSYBS6	TATA spare parts
551547600164	VENTTUBEASSYBS6	TATA spare parts
551547600165	VENTTUBEASSYBS6	TATA spare parts
551547600166	VENTTUBEASSYBS6	TATA spare parts
551547600194	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600195	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600196	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600197	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547600198	HP GAS TUBE WITH PVC SLEEVE BS6	TATA spare parts
551547600208	FUEL SUCTION PIPE ASSY FILTER TO ENGINE	TATA spare parts
551547600209	FUEL SUCTION PIPE ASSY P/FILTER TO W/SEP	TATA spare parts
551547600210	FUEL PIPE ASSY RETURN LINE	TATA spare parts
551547600211	FUEL SUCTION PIPE ASSY TANK TO P/FILTER	TATA spare parts
551547603302	BRACKET	TATA spare parts
551547603309	BRACKET	TATA spare parts
551547603310	BRACKET	TATA spare parts
551547606934	COOLING PIPE	TATA spare parts
551547606935	COOLING PIPE	TATA spare parts
551547607701	BLOCK SINGLE CLAMP BS6	TATA spare parts
551547608202	BRACKET	TATA spare parts
551547610102	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547610109	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
551547610110	VENTTUBEASSYBS6	TATA spare parts
551547610111	VENTPIPEASSYBS6	TATA spare parts
551547610112	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547610114	BOX ASSY BS6	TATA spare parts
551547610115	CLAMP ASSY BS6-PH2	TATA spare parts
551547610182	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547610183	VENT TUBE ASSY BS6-PH2	TATA spare parts
551547610184	CLAMP ASSY BS6-PH2	TATA spare parts
551547610185	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547610186	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547610187	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547610188	VENT TUBE ASSY BS6-PH2	TATA spare parts
551547610198	VENT TUBE ASSY BS6-PH2	TATA spare parts
551547620105	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547620106	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547620107	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547620108	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547620110	VENT TUBE ASSY BS6-PH2	TATA spare parts
551547620111	VENT TUBE ASSY BS6-PH2	TATA spare parts
551547620113	VENT TUBE ASSY BS6-PH2	TATA spare parts
551547620114	VENT PIPE ASSY BS6-PH2	TATA spare parts
551547620115	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts



551547620116	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547620117	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547620118	HP TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547620121	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547620122	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547620123	HP GAS TUBE WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547620124	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
551547800103	ASSY HP CNG PIPE(SOLENOID-SENSOR)	TATA spare parts
551547800104	ASSY HP CNG PIPE (SENSOR TO SOLENOID)	TATA spare parts
551547800105	ASSY HP CNG PIPE (SOLENOID TO HP REGULAT	TATA spare parts
551547800108	ASSY HP PIPE1(3WAY VALVE-FRONT RH CYL)	TATA spare parts
551547800109	ASSY HP CNG PIPE-2 (3 WAY VALVE TO FRONT	TATA spare parts
551547800110	ASSY HP CNG PIPE-3 (3 WAY VALVE TO FRONT	TATA spare parts
551547800111	ASSY HP CNG PIPE-4 (3 WAY VALVE TO FRONT	TATA spare parts
551547800112	ASSY HP CNG PIPE-1(FRNT RH CYL-FRNT LH)	TATA spare parts
551547800113	ASSY HP CNG PIPE-2 (FRONT RH CYL TO FRON	TATA spare parts
551547800114	ASSY HP CNG PIPE-1 (FRONT RH CYL TO REAR	TATA spare parts
551547800115	ASSY HP CNG PIPE-2 (FRONT RH CYL TO REAR	TATA spare parts
551547800116	ASSY HP CNG PIPE-3(FRNT RH CYL-REAR RH)	TATA spare parts
551547800117	ASSY HP CNG PIPE-1(REAR RH CYL-REAR LH)	TATA spare parts
551547800118	ASSY HP CNG PIPE-2 (REAR RH CYL TO REAR	TATA spare parts
551547800119	ASSY.VENTING PIPE-1(HP REG.-FRNT RH CYL)	TATA spare parts
551547800120	ASSY.VENTING PIPE-2(HP REG.-FRNT RH CYL)	TATA spare parts
551547800121	ASSY VENTING PIPE-3-HP REGLTR-FRNT RHCYL	TATA spare parts
551547800122	ASSY VENTING PIPE-4-HP RGLATR-FRNT RHCYL	TATA spare parts
551547800123	ASSY VENTING PIPE-1(FRNT RH CYL-REAR RH)	TATA spare parts
551547800124	ASSY VENTING PIPE-2(FRNT RH CYL-REAR RH)	TATA spare parts
551547800125	ASSY VENTING PIPE-3(FRNT RH CYL-REAR RH)	TATA spare parts
551547800126	ASSY.VENTNG PIPE-1(REAR RH CYL-VEH.REAR)	TATA spare parts
551547800127	ASSY VENTING PIPE-1 (FRONT LH CYL TO REA	TATA spare parts
551547800128	ASSY VENTING PIPE-2 (FRONT LH CYL TO REA	TATA spare parts
551547800129	ASSY VENTING PIPE-3 (FRONT LH CYL TO REA	TATA spare parts
551547800130	ASSY.VENTING PIPE1(REAR LH CYL-VEH.REAR)	TATA spare parts
551547980101	KIT-FUEL PIPE ASSY	TATA spare parts
551549100101	EXHAUST SILENCER ASSY WITH PIPE BS6	TATA spare parts
551549100104	TUBE ASSY BS6-PH2	TATA spare parts
551549100108	ASSY.SILENCER(NG5B)(CIRCULAR)	TATA spare parts
551549100109	ASSY.HEAT SHIELD FOR SILENCER	TATA spare parts
551549100110	ASSY. CLAMP (CATCON-MTG.)	TATA spare parts
551549100111	ASSY.HEAT SHIELD (CATCON)	TATA spare parts
551549100126	BRACKET ASSY SIENCER MTG BS6	TATA spare parts
551549100129	BRACKET ASSY BS6-PH2	TATA spare parts
551549105801	RUBBER HOSE PRESSURE SENSOR BS6	TATA spare parts
551549105803	RUBBER HOSE PRESSURE SENSOR BS6	TATA spare parts
551549200103	ASSY. BRACKET (EXHAUST MTG.ON C/M )	TATA spare parts
551549200104	ASSY. BRACKET (FOR EXHAUST TAIL PIPE MTG	TATA spare parts
551549200106	ASSY. BRACKET (FOR EXHAUST PIPE I MTG.)	TATA spare parts

551549200107	ASSY. BRACKET PIPE MTG	TATA spare parts
551549200108	ASSY. BRACKET (CATCON MTG.)	TATA spare parts
551549200109	ASSY. BRACKET (MUFFLER MTG.)	TATA spare parts
551549200110	ASSY. PIPE EXHAUST (REAR-I)	TATA spare parts
551549200111	ASSY BRACKET TAIL PIPE MTG.	TATA spare parts
551549200113	ASSY. BRACKET (FOR EXHAUST-MTG)	TATA spare parts
551549200114	ASSY. BRACKET (TAIL PIPE.)	TATA spare parts
551549200115	ASSY. BRACKET (END TAIL PIPE MTG.-I)	TATA spare parts
551549200116	ASSY. BRACKET (END TAIL PIPE MTG II)	TATA spare parts
551549200117	ASSY.INTERMEDIATE PIPE WITH BOSS	TATA spare parts
551549200123	FLEX BELLOW ASSY BS6	TATA spare parts
551549200124	BRACKET ASSY BS6	TATA spare parts
551549200129	BRACKET ASSY TAIL PIPE MTG	TATA spare parts
551549200131	TUBE ASSY	TATA spare parts
551549200132	TUBE ASSY	TATA spare parts
551549200133	EXHAUST PIPE ASSY	TATA spare parts
551549200134	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
551549200136	BRACKET ASSY	TATA spare parts
551549200140	CLAMP ASSY-CATCON MTG BS6	TATA spare parts
551549200158	EXT PIPE ASSY WITH FLEX BELLOW BS6-PH2	TATA spare parts
551549203302	L BRACKET FOR SILENCER ASSLY BS6	TATA spare parts
551549203304	BRACKET EXHAUST PIPE MTG	TATA spare parts
551549203322	BRACKET BS6-PH2	TATA spare parts
551549203704	EXHAUST ELBOW	TATA spare parts
551549204202	CLAMP DOC POC	TATA spare parts
551549206908	EXHAUST TAIL PIPE-II	TATA spare parts
551549206936	EXHAUST TAIL PIPE	TATA spare parts
551549208210	BRACKET (TAIL PIPE-MTG)	TATA spare parts
551549208216	SUPPORT BRACKET (FRN EXH PIPE MTG)دندند	TATA spare parts
551549208218	PIPE CLAMP	TATA spare parts
551549208219	PIPE CLAMP	TATA spare parts
551549208240	ELBOW-HEAT SHIELD-1 (FRONT EXHAUST PIPE)	TATA spare parts
551549208241	BEND-HEAT SHIELD-2 (FRONT EXHAUST PIPE)	TATA spare parts
551549208242	BELLOW-HEAT SHIELD-3(FRONT EXHAUST PIPE)	TATA spare parts
551549208243	STRAIGHT HEATSHIELD4(FRONT EXHAUST PIPE)	TATA spare parts
551549208244	BEND-HEAT SHIELD-5(FRONT EXHAUST PIPE)	TATA spare parts
551549208245	STRAIGHT-HEATSHIELD6(FRONT EXHAUST PIPE)	TATA spare parts
551549600101	HEAT SHIELD CATCON BS6	TATA spare parts
551549600102	HEAT SHIELD ASSY CATCON BS6	TATA spare parts
551549600108	HEAT SHIELD ASSY SILENCER BS6	TATA spare parts
551554	CLAMP HOSE	TATA spare parts
551554100102	ASSY BATTERY CABLE -VE 2050 MM 50SQMM LP	TATA spare parts
551554100103	BATT CABLE +VE 50SQMM 1300MM	TATA spare parts
551554100114	BATTERY SUPPORT ASSY	TATA spare parts
551554100115	BATTERY LINK BS6	TATA spare parts
551554108203	BATTERY TOP CLAMP	TATA spare parts
551554200102	INSTRUMENT CLUSTER ASSY	TATA spare parts

551554200107	INSTRUMENT CLUSTER LP913 CNG BSIV ESPEED	TATA spare parts
551554209901	SPEEDOMETER RATIO 0.76	TATA spare parts
551554300101	INST.CLUSTER 0.76 LP913 CNG BSIV	TATA spare parts
551554300104	BRACKET ASSY-HORN MTG BS6	TATA spare parts
551554300106	BRACKET ASSY HORN MTG BS6-PH2	TATA spare parts
551554303303	BRACKET HORN MTG BS6-PH2	TATA spare parts
551554500103	BRKT ASSY BATTERY CUT OFF S/W MTG BS6-PH	TATA spare parts
551554504901	ALARM RESET SWITCH BS6	TATA spare parts
551554600107	BATTERY -VE	TATA spare parts
551554600138	WIRING HARNESS SENSOR	TATA spare parts
551554600140	BATTERY CABLE +VE	TATA spare parts
551554600142	WIRING HARNESS INJECTOR	TATA spare parts
551554600144	BATTERY CABLE +VE MEGA FUSE	TATA spare parts
551554600145	WIRING HARNESS ABS FRAME	TATA spare parts
551554600148	WIRING HARNESS MAXI FUSE	TATA spare parts
551554600151	WIRING HARNESS,MAIN	TATA spare parts
551554600154	WIRING HARNESS TAIL	TATA spare parts
551554600178	WIRING HARNESS SWITCH BS6	TATA spare parts
551554600179	WIRING HARNESS TAIL BS6	TATA spare parts
551554600180	WIRINGHARNESSMAXIFUSE BS6	TATA spare parts
551554600181	WIRINGHARNESSHEADLAMP-BLINKER BS6	TATA spare parts
551554600185	WIRING HARNESS SENSOR BS6	TATA spare parts
551554600187	BATTERY CABLE +VE BS6	TATA spare parts
551554600189	BATTERY CABLE +VE BS6	TATA spare parts
551554600190	BATTERY CABLE +VE BS6	TATA spare parts
551554600192	WIRING HARNESS MAIN	TATA spare parts
551554600195	WIRING HARNESS MAXI FUSE	TATA spare parts
551554600197	WIRINGHARNESSMAIN BS6	TATA spare parts
551554601602	WIRING HARNESS ENGINE	TATA spare parts
551554601603	WIRING HARNESS HEAD LIGHT & BLINKER	TATA spare parts
551554601604	WIRING HARNESS TAIL	TATA spare parts
551554601605	WIRING HARNESS SWITCH	TATA spare parts
551554601606	WIRING HARNESS MAIN	TATA spare parts
551554601607	WIRING HARNESS MAXI FUSE	TATA spare parts
551554601624	WIRING HARNESS TAIL LPK913 34WB	TATA spare parts
551554601626	WIRING HARNESS MAIN LPK913 EII 12V	TATA spare parts
551554601627	WIRING HARNESS ENGINE LPK913 EII	TATA spare parts
551554601638	WIRING HARNESS ABS FRAME 4S4M	TATA spare parts
551554606306	STICKER MAXI FUSE BOX BS6	TATA spare parts
551554608210	DIAGNOSTIC CONN.MTG.BRKT LP913 CNG BSIV	TATA spare parts
551554610110	WIRING HARNESS TAIL BS6	TATA spare parts
551554610114	BATTERY CABLE +VE BS6	TATA spare parts
551554610115	BATTERY CABLE +VE BS6	TATA spare parts
551554610117	WIRING HARNESS PIGTAIL BS6	TATA spare parts
551554610120	WIRING HARNESS ASSY	TATA spare parts
551554610126	BATT CABLE +VE BCS OFF O/P TO M FUSE I/P	TATA spare parts
551554610128	WIRING HARNESS SWITCH	TATA spare parts

551554610130	STARTER CABLE	TATA spare parts
551554610171	WH DASHBOARD BS6-PH2	TATA spare parts
551554610172	WH ENGINE-POWER CONNECTION	TATA spare parts
551554630101	W/H EMS LP913 CNG BS-IV	TATA spare parts
551554630102	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
551554630115	WIRING HARNESS PIGTAIL	TATA spare parts
551554630120	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
551554630122	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
551554630124	BATTERY CABLE -VE BS6-PH2	TATA spare parts
551554630125	WIRING HARNESS SENSOR BS6-PH2	TATA spare parts
551554630127	WIRING HARNESS SWITCH BS6-PH2	TATA spare parts
551554630149	WH AC INTERFACE BS6	TATA spare parts
551554640105	WIRING HARNESS SENSOR BS6	TATA spare parts
551554709903	INTELLIGENT BATTERY SENSOR BS6-PH2	TATA spare parts
551583400101	ASSY AC COMPRESSOR	TATA spare parts
551583550107	AC COMPRESSOR ASSY BS6-PH2	TATA spare parts
551583550112	COMPRESSOR ASSY BS6	TATA spare parts
551583553302	BRACKETASSY ACCOMPRESSORMTG BS6	TATA spare parts
551583553306	BRACKET ASSY-AC COMPRESSOR MTG BS6	TATA spare parts
551583555301	PACKING BS6	TATA spare parts
551583555302	PACKING BS6	TATA spare parts
551583556303	BELT ACCOMPRESSOR BS6	TATA spare parts
551583556307	BELT-AC COMPRESSOR BS6	TATA spare parts
551583557501	ASSY. RUBBER BUSH COMPLETE BS6	TATA spare parts
551583557502	BUSH BS6	TATA spare parts
551583557701	PACKING SHEET_SIDE BS6	TATA spare parts
551583557703	PACKING SHEET_TOP BS6	TATA spare parts
551583557704	RUBBER BUFFER BS6	TATA spare parts
551583558701	HELICAL COMPRESSION SPRING BS6	TATA spare parts
551583558801	STUD BS6	TATA spare parts
551591100101	RISER ASSY BS6	TATA spare parts
551591100102	RISER ASSY BS6	TATA spare parts
551591108203	SPACER BS6	TATA spare parts
551700990101	ASSY KIT IRIS ZIP VEHICLE	TATA spare parts
551700990102	ASSY KIT IRIS BS4 AIS 140 REGULATION	TATA spare parts
551700990105	ASSY KIT IRIS BS4 AIS 140 NEW	TATA spare parts
551715100101	STARTER MOTOR 1.4 KWIRIS/ZIP BS2/3/4	TATA spare parts
551715100102	STARTER MOTOR 1.4KW	TATA spare parts
551715100104	ARMATURE	TATA spare parts
551715101605	HEAT SHIELD STARTER MOTOR	TATA spare parts
551715103401	BEARING BUSH KIT	TATA spare parts
551715103701	CLOSURE CAP	TATA spare parts
551715103801	FIXING BRKT. ASSY.	TATA spare parts
551715103802	DRIVE END SHIELD	TATA spare parts
551715104931	SOLENOID SWITCH	TATA spare parts
551715105401	ANNULUS	TATA spare parts
551715105402	EPICYCLOIDAL GEAR TRAIN	TATA spare parts

551715105430	OVER RUNNING CLUTCH	TATA spare parts
551715106301	ENGAGING LEVER	TATA spare parts
551715106302	ANNULUS HOUSING	TATA spare parts
551715106303	FORK LEVER	TATA spare parts
551715106304	BEARING PEDESTAL	TATA spare parts
551715106533	FLANGE NUT BS6	TATA spare parts
551715107701	SEALING KIT	TATA spare parts
551715107702	SEAL	TATA spare parts
551715108201	STATOR FRAME	TATA spare parts
551715108202	BRUSH ASSY CONNECTOR	TATA spare parts
551715108203	STARTER ASSY	TATA spare parts
551715108204	COVER DISC	TATA spare parts
551715108205	CLOSURE CAP	TATA spare parts
551715109901	STARTER MOTOR	TATA spare parts
551715109903	PLUNGER ASSY	TATA spare parts
551715109904	PLUNGER RETURN SPRING	TATA spare parts
551715109905	SOLENOID ASSY	TATA spare parts
551715109906	FIXING BRACKET ASSY	TATA spare parts
551715109907	DRIVE ASSY	TATA spare parts
551715109909	PLANETARY GEAR ASSY	TATA spare parts
551715109910	OUTPUT SHAFT ASSY	TATA spare parts
551715109911	BRUSH GEAR ASSY	TATA spare parts
551715109912	C.E. BRACKET ASSY	TATA spare parts
551715109913	FASTENERS ASSY KIT	TATA spare parts
551715109914	SEALING KIT	TATA spare parts
551715109915	BEARING BUSH KIT	TATA spare parts
551715109916	PINION KIT	TATA spare parts
551715109918	BEARING KIT	TATA spare parts
551715109919	PLUNGER ASSY	TATA spare parts
551715109920	SOLENOID ASSY	TATA spare parts
551715109921	HEAT SHIELD FOR STARTER MOTOR	TATA spare parts
551715109923	RETAINING¿RING BS6	TATA spare parts
551715109924	STOP¿RING BS6	TATA spare parts
551715109952	FASTENERS ASSEMBLY KIT	TATA spare parts
551715109955	HEAT SHIELD FOR STARTER MOTOR 1.4KW	TATA spare parts
551715109964	HEAT SHIELD FOR STARTER MOTOR 1.4KW	TATA spare parts
551715206301	ECU COVER	TATA spare parts
551715209901	ECU-EMS (CNG)	TATA spare parts
551715400102	ALTERNATOR 50AMP BS2/3/4	TATA spare parts
551715400105	ALTERNATOR 50A WITH VACCUM PUMP	TATA spare parts
551715400106	ROTOR ASSY. FINAL	TATA spare parts
551715406329	RECTIFIER¿ARRANGEMENT	TATA spare parts
551715407002	PULLEY BS6	TATA spare parts
551715409903	MACHINED PULLEY	TATA spare parts
551715409904	DE BRACKET ASSY	TATA spare parts
551715409905	STATOR WINDING ASSY	TATA spare parts
551715409906	SRE BRACKET ASSY	TATA spare parts

551715409907	RECTIFIER ASSY	TATA spare parts
551715409908	REGULATOR CUM BRUSH BOX ASSY	TATA spare parts
551715409909	REAR COVER MOULDING	TATA spare parts
551715409910	CAPACITOR ASSY	TATA spare parts
551715409911	BEARING ASSY KIT	TATA spare parts
551715409912	FASTENER ASSY KIT	TATA spare parts
551715409915	ROTOR ASSY	TATA spare parts
551715409916	S.R.E BEARING	TATA spare parts
551715409917	STATOR ASSY	TATA spare parts
551715409918	S.R.E BRACKET ASSY	TATA spare parts
551715409919	RECTIFIER ASSY	TATA spare parts
551715409921	REAR COVER	TATA spare parts
551715999901	PRESSURE SWITCH	TATA spare parts
551715999902	ELECTRICAL SHUTOFF SOLENOID BS2/3/4	TATA spare parts
551724000101	ASSY. C-MOUNT (ENGINE) BS2/3/4	TATA spare parts
551724000102	ASSY. D-MOUNT (ENGINE) BS2/3/4	TATA spare parts
551729100109	ASSY. BRACKET CLUTCH CABLE GUIDE - ENGIN	TATA spare parts
551729100110	ASSY. CLUTCH PEDAL LEVER	TATA spare parts
551729100111	ASSY. CLUTCH PEDAL LEVER COMPLETE	TATA spare parts
551729100121	ASSY. CLUTCH CABLE IRIS ZIP 3233MM BS3	TATA spare parts
551729100126	ASSY.BRACKET CLUTCH CABLE CLAMP	TATA spare parts
551729100127	ASSY. BRACKET CLUTCH CABLE CLAMP ALTERNA	TATA spare parts
551729100132	ASSY. SHUT OFF CABLE 1853MM -ZIP BS2/3/4	TATA spare parts
551729100137	CLUTCH CABLE ZIP LHD	TATA spare parts
551729100138	ASSY. BRACKET CLUTCH CABLE MTG.	TATA spare parts
551729100142	ASSY. BRACKET CABLE CLAMPING	TATA spare parts
551729100143	CLUTCH CABLE ASSY	TATA spare parts
551729100150	ASSY BRACKET CLUTCH CABLE CLAMP	TATA spare parts
551729100153	ASSY BRACKET TWIN CLAMP	TATA spare parts
551729100154	CLUTCH CABLE	TATA spare parts
551729100156	ASSY CLUTCH CABLE MTG BRKT	TATA spare parts
551729100162	ASSY.CLUTCH PEDAL LEVER	TATA spare parts
551729100166	CLUTCH CABLE ASSY	TATA spare parts
551729100167	CLUTCH CABLE ASSY	TATA spare parts
551729100174	BRACKET ASSY CLUTCH CABLE GUIDE	TATA spare parts
551729100176	ASSY CLUTCH CABLE	TATA spare parts
551729100177	CLUTCH CABLE ASSY	TATA spare parts
551729104201	SEPARATOR CLAMP 6 AND 6ABOVE	TATA spare parts
551729106702	PIVOT PIN CLUTCH PEDAL MTG.	TATA spare parts
551729108219	BRACKET CLUTCH CABLE CLAMP	TATA spare parts
551729108221	BRACKET CLUTCH CABLE CLAMP ALTERNATOR SI	TATA spare parts
551729108222	BRACKET (CLUTCH CABLE CLAMP)	TATA spare parts
551729108228	BRACKET FUEL SHUT OFF CABLE KNOB MTG.	TATA spare parts
551729108256	WIRING HARNESS AND CLUTCH CABLE MTG BKT	TATA spare parts
551729108294	CLAMP CLUTCH CABLE	TATA spare parts
551729108404	PIVOT BOLT CLUTCH PEDAL	TATA spare parts
551729200115	ASSY BRAKE PEDAL LEVER COMPLETE	TATA spare parts

551729200130	ASSY. BRAKE PEDAL LEVER COMPLETE	TATA spare parts
551729200137	ASSY. BRAKE PEDAL LEVER	TATA spare parts
551729206701	PIVOT PIN BRAKE PEDAL MTG.	TATA spare parts
551729208222	TMC SUPPORT BRACKET	TATA spare parts
551729208226	TMC MOUNTING BRACKET	TATA spare parts
551729500106	ASSY TUBE CONTROLS MOUNTING	TATA spare parts
551729500107	ASSY. CONTROL PEDALS MOUNTING SYSTEM	TATA spare parts
551729500109	ASSY. CONTROL PEDALS MOUNTING SYSTEM	TATA spare parts
551729500112	CONTROL PEDALS MOUNTING SYSTEM ASSY	TATA spare parts
551729500113	ASSY. BRACKET CONTROL TUBE (FLOOR SIDE CE	TATA spare parts
551729500118	ASSY. CONTROL PEDALS MOUNTING SYSTEM	TATA spare parts
551729500125	ASSY CONTROL PEDALS MTG SYSTEM	TATA spare parts
551729508206	BRACKET CONTROL TUBE (FLOOR SIDE CENTRAL	TATA spare parts
551729508213	CLAMP-13DIA	TATA spare parts
551730100101	ASSY ACCELERATOR CABLE 2995MM	TATA spare parts
551730100104	ASSY. STOPPER BRACKET ACCELERATOR PEDAL	TATA spare parts
551730100107	ASSY. ACCELERATOR PEDAL LEVER COMPLETE	TATA spare parts
551730100110	ASSY. ACCELERATOR CABLE	TATA spare parts
551730100116	ASSY. REINFORCEMENT APM MOUNTING	TATA spare parts
551730100119	ASSY. ACCELERATOR CABLE	TATA spare parts
551730100127	ASSY ACCELERATOR PEDAL MODULE	TATA spare parts
551730100130	ASSY. ACCELERATOR CABLE 2915MM	TATA spare parts
551730100134	ACCELERATOR CABLE	TATA spare parts
551730100137	ASSY EXCESS CABLE 2200MM	TATA spare parts
551730100138	ASSY.ACCL CABLE	TATA spare parts
551730100140	ACCELERATOR CABLE ASSY	TATA spare parts
551730100141	ACCELERATOR CABLE ASSY	TATA spare parts
551730400102	ASSY EXCESS FUEL CABLE	TATA spare parts
551730400107	ASSY EXCESS FUEL CABLE	TATA spare parts
551730400111	ASSY. EXCESS FUEL CABLE	TATA spare parts
551730408701	SPRING (EXCESS FUEL LEVER)	TATA spare parts
551731700118	ASSY. NOISE SHIELD COMPLETE	TATA spare parts
551731708289	BRACKET - LH LONG MEMBER NOISE SHIELD MT	TATA spare parts
551732100102	ASSY. FRONT STRUT COMP. RH BS2/3/4	TATA spare parts
551732100103	ASSY. FRONT STRUT COMPLETE LH BS2/3/4	TATA spare parts
551732100110	ASSY. LOWER BALL JOINT RH BS2/3/4	TATA spare parts
551732100111	ASSY. LOWER BALL JOINT LH BS2/3/4	TATA spare parts
551732100125	ASSY WISHBONE WITH BUSHES RH	TATA spare parts
551732100126	ASSY WISHBONE WITH BUSHES LH	TATA spare parts
551732100138	ASSY LOWER BALL JOINT RH	TATA spare parts
551732100139	ASSY LOWER BALL JOINT LH	TATA spare parts
551732100140	ASSY LOWER BALL JOINT RH	TATA spare parts
551732100141	ASSY LOWER BALL JOINT LH	TATA spare parts
551732100152	ASSY FRONT STRUT COMPLETE RH - PC	TATA spare parts
551732100153	ASSY. FRONT STRUT COMP. LH - PC BS3/4	TATA spare parts
551732100154	DAMPER ELEMENT ASSEMBLY-RH	TATA spare parts
551732100155	DAMPER ELEMENT ASSEMBLY-LH	TATA spare parts

551732100158	ASSY WISHBONE WITH BUSHES RH - PC	TATA spare parts
551732100159	ASSY WISHBONE WITH BUSHES LH - PC	TATA spare parts
551732100162	ASSY FRONT STRUT COMPLETE RH PC	TATA spare parts
551732100163	ASSY FRONT STRUT COMPLETE LH PC	TATA spare parts
551732100166	ASSY FRONT STRUT COMPLETE RH PC	TATA spare parts
551732100167	ASSY FRONT STRUT COMPLETE LH PC	TATA spare parts
551732100174	TOP MOUNT	TATA spare parts
551732100175	UPPER SPRING SEAT SUB ASSY	TATA spare parts
551732100176	ASSY SUPPORT CUP	TATA spare parts
551732100177	ASSY FRONT STRUT COMPLETE RH GC	TATA spare parts
551732100178	ASSY FRONT STRUT COMPLETE LH GC	TATA spare parts
551732100181	ASSY FRONT STRUT COMPLETE RH	TATA spare parts
551732100182	ASSY FRONT STRUT COMPLETE LH	TATA spare parts
551732100197	ASSY. WISHBONE WITH BUSHES RH BS2/3/4	TATA spare parts
551732100198	ASSY. WISHBONE W/BUSHES LH BS2/3/4	TATA spare parts
551732100199	PIVOT BUSH ASSY LOWER WISHBONE REAR	TATA spare parts
551732103101	STRUT BEARING	TATA spare parts
551732103201	HEX FLANGE BOLT FOR LBJ MTG	TATA spare parts
551732103204	STRUT MOUNTING PIN ECCENTRIC	TATA spare parts
551732107708	BUMP STOPPER	TATA spare parts
551732107709	RUBBER SEAT WITH DUST COVER	TATA spare parts
551732107710	RUBBER MOUNT	TATA spare parts
551732107711	CAP	TATA spare parts
551732107712	BUMP STOPER	TATA spare parts
551732108257	SPRING SEAT TOP	TATA spare parts
551732108258	BEARING TOP SEAT	TATA spare parts
551732108259	INNER SUPPORT	TATA spare parts
551732108702	SPRING	TATA spare parts
551732108703	FRONT COIL SPRING	TATA spare parts
551732108705	SPRING FRONT STRUT	TATA spare parts
551732400106	ASSY SEMI TRAILING ARM COMP WITH BUSH RH	TATA spare parts
551732400107	ASSY SEMI TRAILING ARM COMP WITH BUSH LH	TATA spare parts
551732400125	ASSY SEMI TRAILING ARM COMP WITH BRAKES	TATA spare parts
551732400126	ASSY SEMI TRAILING ARM COMP WITH BRAKES	TATA spare parts
551732400127	ASSY SEMI TRAILING ARM COMP WITH BUSH RH	TATA spare parts
551732400128	ASSY SEMI TRAILING ARM COMP WITH BUSH LH	TATA spare parts
551732400141	SEMI TRAILING ARM ASSY COMP WITH BUSH FO	TATA spare parts
551732400145	ASSY. SEMI TRAILING ARM W/BUSH RH BS4	TATA spare parts
551732400146	ASSY. SEMI TRAIL ARM W/BUSH LH BS2/3/4	TATA spare parts
551732401606	BUMP STOPPER REAR	TATA spare parts
551732406301	SPACER REAR SPRING TOP	TATA spare parts
551732407501	BUMP STOPPER REAR M/S AMP (M-2895-000)	TATA spare parts
551732407701	SPRING RUBBER SEAT TOP	TATA spare parts
551732407702	SPRING RUBBER SEAT TOP REAR	TATA spare parts
551732408701	REAR COIL SPRING BS3/4	TATA spare parts
551732408702	REAR COIL SPRING PC	TATA spare parts
551732408703	REARCOILSPRINGACEZIP	TATA spare parts



551732408704	REAR COIL SPRING ZIP CNG	TATA spare parts
551732600101	ASSY. REAR DAMPER BS2/3/4	TATA spare parts
551732600102	ASSY REAR DAMPER PC	TATA spare parts
551732600103	ASSY. DAMPER REAR BS3/4	TATA spare parts
551732609201	WASHER DAMPER MTG REAR	TATA spare parts
551732800101	ASSEMBLY FRONT ANTI-ROLL BAR COMPLETE	TATA spare parts
551732806001	LINK ANTIROLL BAR FRONT	TATA spare parts
551732807501	RUBBER BUSH	TATA spare parts
551732807502	RUBBER BUSH (FRONT ANTI ROLL BAR)	TATA spare parts
551732807701	BEARING BLOCK FRONT ARB MOUNTING	TATA spare parts
551732807901	FRONT ANTI ROLL BAR	TATA spare parts
551732808201	CUP (FRONT ANTI ROLL BAR)	TATA spare parts
551732808203	BRCKET (BEARING BLOCK MOUNTING)	TATA spare parts
551732990101	KIT-FRONT STRUT BS2/3/4	TATA spare parts
551732990102	PENGUIN PC - FRONT STRUT SPARE KIT 2	TATA spare parts
551732990103	KIT - 1	TATA spare parts
551732990104	KIT - 2	TATA spare parts
551732990108	FRONT STRUT SPARE KIT 2	TATA spare parts
551732998701	REAR COIL SPRING (SPARE)	TATA spare parts
551733100102	ASSY STUB AXLE WITH BRAKE-RH	TATA spare parts
551733100112	ASSY STUB AXLE WITH BRAKE-LH	TATA spare parts
551733108603	SPACER TUBE	TATA spare parts
551733205103	STUB AXLE LH	TATA spare parts
551733205104	STUB AXLE RH	TATA spare parts
551733400105	OIL SEAL FRONT INNER BS2/3/4	TATA spare parts
551733400106	OIL SEAL-FRONT INNER	TATA spare parts
551733400108	OIL SEAL-FRONT INNER	TATA spare parts
551733403106	TAPPER ROLLER BEARING-INNER BS2/3/4	TATA spare parts
551733403108	TAPPER ROLLER BEARING-INNER	TATA spare parts
551733403109	TAPPER ROLLER BEARING-INNER	TATA spare parts
551733403110	TAPPER ROLLER BEARING-INNER	TATA spare parts
551733403117	TAPER ROLLER BEARING M/S ABC BEARINGS	TATA spare parts
551733408201	BAFFLE	TATA spare parts
551733408203	HUB COVER	TATA spare parts
551733408204	HUB COVER	TATA spare parts
551733408602	SEAL RACE (STUB AXLE)	TATA spare parts
551735600108	OIL SEAL-INNER	TATA spare parts
551735600111	ASSY.HUB UNIT REAR	TATA spare parts
551735600112	ASSY. HUB COMPLETE RH	TATA spare parts
551735600113	ASSY. HUB COMPLETE LH	TATA spare parts
551735600114	ASSY. HUB COMPLETE RH	TATA spare parts
551735600115	ASSY. HUB COMPLETE LH	TATA spare parts
551735603107	DOUBLE ROW TAPPER ROLLER BRG. BS2/3/4	TATA spare parts
551735603109	DOUBLE ROW TAPPER ROLLER BEARING	TATA spare parts
551735605103	HUB REAR	TATA spare parts
551735707903	BRAKE DRUM MOUNTING FLANGE REAR	TATA spare parts
551740100120	ASSY. WHEEL RIM 3.5 MT X 10	TATA spare parts

551740100130	ASSY. WHEEL RIM 3.5 MT X 10	TATA spare parts
551740100132	ASSY WHEEL RIM 3.5 MT X 10	TATA spare parts
551740106702	WHEEL MOUNTING PIN (FRONT)	TATA spare parts
551740106703	WHEEL MOUNTING PIN (REAR)	TATA spare parts
551740107702	RUBBER PAD (SPARE WHEEL MOUNTING	TATA spare parts
551740107703	RUBBER PAD (SPARE WHEEL SUPPORT)	TATA spare parts
551740300107	ASSY. TUBE COMPLETE (SPARE WHEEL MTG.)	TATA spare parts
551740300111	ASSY.TUBE COMPLETE (SPARE WHEEL MOUNTING)	TATA spare parts
551740300114	ASSY.MTG BRACKET WITH WASHER	TATA spare parts
551740300115	ASSY. TUBE (SPARE WHEEL MTG.)	TATA spare parts
551740300123	ASSY BRACKET WITH WELDED BOLTS.	TATA spare parts
551740300132	ASSY TUBE COMPLETE (SPARE WHEEL MTG.)	TATA spare parts
551740306703	PIN (SPARE WHEEL MOUNTING)	TATA spare parts
551740306705	PIN SPARE WHEEL MTG.	TATA spare parts
551740306905	CLAMP (SPARE WHEEL MTG.)	TATA spare parts
551740306911	CLAMP (SPARE WHEEL MOUNTING)	TATA spare parts
551740306916	CLAMPING BOLT(SPARE WHEEL MTG)	TATA spare parts
551740308210	LOCK PLATE (SPARE WHEEL MTG.)	TATA spare parts
551742100106	ASSY. FRONT BRAKE RH	TATA spare parts
551742100107	ASSY. FRONT BRAKE LH	TATA spare parts
551742100108	ASSY. FRONT BRAKE LH	TATA spare parts
551742100109	ASSY. FRONT BRAKE RH	TATA spare parts
551742100110	FRONT DRUM BRAKE ASSLY RH	TATA spare parts
551742100111	FRONT DRUM BRAKE ASSLY LH	TATA spare parts
551742100112	ASSY. FRONT BRAKE LH-WITH LINERS	TATA spare parts
551742100113	ASSY. FRONT BRAKE RH-WITH LINERS	TATA spare parts
551742101601	FRONT BRAKE ASSY. LH	TATA spare parts
551742101602	FRONT BRAKE ASSY. RH	TATA spare parts
551742103701	BRAKE DRUM CUM HUB (FRONT) BS2/3/4	TATA spare parts
551742300102	REAR BRAKE ASSY LH	TATA spare parts
551742300103	REAR BRAKE ASSY. RH	TATA spare parts
551742300106	ASSY. REAR BRAKE LH	TATA spare parts
551742300107	ASSY. REAR BRAKE RH	TATA spare parts
551742300108	ASSY. REAR BRAKE LH	TATA spare parts
551742300109	ASSY. REAR BRAKE RH	TATA spare parts
551742300111	ASSY REAR BRAKE LH	TATA spare parts
551742300112	ASSY REAR BRAKE RH	TATA spare parts
551742303702	REAR DRUM (180 DIA) BS2/3/4	TATA spare parts
551742303801	WHEEL CYLINDER ASSY	TATA spare parts
551742700113	ASSY. PARKING BRAKE CABLE FRONT	TATA spare parts
551742700116	ASSY. PARKING BRAKE CABLE FRONT	TATA spare parts
551742700119	ASSY. PARKING BRAKE LEVER	TATA spare parts
551742700150	ASSY. PARKING BRAKE CABLE REAR	TATA spare parts
551742700151	ASSY. BRACKET ABUTMENT (REAR)	TATA spare parts
551742700153	ASSY. PARKING BRAKE LEVER	TATA spare parts
551742700154	ASSY FRONT PARKING BRAKE CABLE 737MM	TATA spare parts
551742700155	ASSY. RR PARKING BRK CABLE 1335 BS2/3/4	TATA spare parts

551742700158	PARKING LEVER ASSY COMPLETE	TATA spare parts
551742700160	ASSY. PARKING BRAKE CABLE FRONT	TATA spare parts
551742700161	ASSY. PARKING BRAKE CABLE REAR 1515MM	TATA spare parts
551742700179	BRACKET ASSY ABUTMENT	TATA spare parts
551742700192	CABLE ASSY PARKING BRAKE FRONT	TATA spare parts
551742700197	PARKING BRAKE CABLE ASSY REAR LH	TATA spare parts
551742700199	PARKING BRAKE CABLE ASSY REAR LH	TATA spare parts
551742700201	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
551742700202	PARKING BRAKE CABLE ASSY REAR-LH	TATA spare parts
551742700203	PARKING BRAKE CABLE ASSY REAR-RH	TATA spare parts
551742701601	ASSY. PARKING BRAKE CABLE (REAR)	TATA spare parts
551742704204	CLIP PARKING BRAKE CABLE	TATA spare parts
551742706701	PIN (PULLEY MOUNTING)	TATA spare parts
551742710101	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
551742710102	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
551742710104	PARKING BRAKE CABLE ASSY REAR RH	TATA spare parts
551742710106	PARKING BRAKE CABLE ASSY REAR RH	TATA spare parts
551742800104	ASSY. BRAKE HOSE FRONT BS2/3/4	TATA spare parts
551742800105	ASSY. BRAKE HOSE REAR	TATA spare parts
551742800106	BRAKE HOSE ASSY. FRONT	TATA spare parts
551742800107	BRAKE HOSE ASSY. REAR	TATA spare parts
551742800108	ASSY. BRAKE HOSE REAR	TATA spare parts
551742800109	ASSY. BRAKE HOSE FRONT	TATA spare parts
551742990101	REPAIR KIT ADJ FRONT LH	TATA spare parts
551742990102	REPAIR KIT ADJ FRONT RH	TATA spare parts
551742990103	KIT-SHOE COMP. FRONT BRAKE (M/S	TATA spare parts
551742990104	FRONT WHEEL CYLINDER ASSY. MAJOR KIT	TATA spare parts
551742990105	FRONT WHEEL CYLINDER ASSY. MINOR KIT	TATA spare parts
551742990107	REPAIR KIT ADJUSTER LH RR	TATA spare parts
551742990108	REPAIR KIT ADJUSTER RH RR	TATA spare parts
551742990109	KIT-BRAKE SHOE REAR BS2/3/4	TATA spare parts
551742990110	STRUT ASSEMBLY LH (FRONT)	TATA spare parts
551742990111	STRUT ASSEMBLY RH(FRONT)	TATA spare parts
551742990113	BACKPLATE ASSY - LH	TATA spare parts
551742990114	BACK PLATE ASSY FRH	TATA spare parts
551742990115	BACK PLATE ASSY. -LH	TATA spare parts
551742990116	BACK PLATE ASSY. -RH	TATA spare parts
551742990117	KIT-BRAKE SHOE WITH LINER BS2/3/4	TATA spare parts
551742990120	KIT WHEEL CYLINDER-MINOR	TATA spare parts
551742990121	KIT LEVER PAWL- LH	TATA spare parts
551742990122	KIT LEVER PAWL- RH	TATA spare parts
551742990123	REAR SHOE HOLD DOWN KIT	TATA spare parts
551742990124	REAR KIT WHEEL CYLINDER MINOR	TATA spare parts
551742990125	REAR KIT WHEEL CYLINDER MAJOR	TATA spare parts
551742990129	KIT-LINED SHOE FRONT	TATA spare parts
551742990135	KIT-FRT BRAKE SHOE BS2/3/4	TATA spare parts
551742990180	ASSY. WHEEL CYLINDER? (DIA 25.4) BS2/3/4	TATA spare parts

551742990182	BACK PLATE COMP LH	TATA spare parts
551742990183	BACK PLATE COMP RH	TATA spare parts
551742993701	WHEEL CYLINDER ASSY- (DIA 15.88 MM)	TATA spare parts
551742993702	ASSY. WHEEL CYLINDER (REAR) BS2/3/4	TATA spare parts
551742996301	BACKPLATE ASSY - RH	TATA spare parts
551742998002	BLEED SCREW - REAR BRAKE	TATA spare parts
551742998203	BACK PLATE ASSY. -LH	TATA spare parts
551742998204	BACK PLATE ASSY. -RH	TATA spare parts
551742998207	BACK PLATE COMPLETE LH REAR	TATA spare parts
551742998208	BACK PLATE COMPLETE RH REAR	TATA spare parts
551742998701	RETURN SPRING ¿ANCHOR ¿POINT	TATA spare parts
551742998703	SPRING W/CYL END	TATA spare parts
551743100109	ASSY. DPV	TATA spare parts
551743100110	TANDEM MASTER CYL. DIA.19.05 BS2/3/4	TATA spare parts
551743100111	TANDEM MASTER CYL. DIA.19.05	TATA spare parts
551743100112	ASSY. BRAKE FLUID RESERVOIR	TATA spare parts
551743100113	TANDEM MASTER CYL.DIA 19.05	TATA spare parts
551743100115	ASSY. DPV 25 BAR	TATA spare parts
551743100118	ASSY TWIN LSPV	TATA spare parts
551743100120	ASSY. TWIN LSPV - MAGIC IRIS CNG	TATA spare parts
551743800142	ASSY. TUBE FROM TMC SECONDERY TO ADAPTE	TATA spare parts
551743800145	ASSY. TUBE FROM FRONT BRAKE HOSE TO FRON	TATA spare parts
551743800146	ASSY TUBE FROM FRONT BRAKE HOSE TO FRONT	TATA spare parts
551743800147	ASSY TUBE FROM REAR BRAKE HOSE TO REAR B	TATA spare parts
551743800148	ASSY TUBE FROM REAR BRAKE HOSE TO REAR B	TATA spare parts
551743800152	ASSY TUBE FROM TMC PRIMERY TO ADAPTER	TATA spare parts
551743800182	ASSY. TUBE FROM ADAPTER C2 TO DPV INLET	TATA spare parts
551743800183	ASSY TUBE FROM ADAPTOR C1 TO DPV INLET A	TATA spare parts
551743800184	ASSY. TUBE FROM DPV OUTLET B1 TO FRONT B	TATA spare parts
551743800185	ASSY.TUBE FROM DPV OUTLET B2 TO FRONT BR	TATA spare parts
551743800186	ASSY. TUBE FROM DPV OUTLET B4 TO REAR BR	TATA spare parts
551743800187	ASSY. TUBE FROM DPV OUTLET B3 TO REAR BR	TATA spare parts
551743800188	ASSY. TUBE FROM TMC SECONDERY TO ADAPTER	TATA spare parts
551743800189	ASSY TUBE FROM TMC PRIMERY TO ADAPTER C2	TATA spare parts
551743800192	ASSY. TUBE FROM TMC SECONDARY TO ADAPTER	TATA spare parts
551743800193	ASSY. BRAKE TUBE FROM TMC PRIMARY TO ADA	TATA spare parts
551743800209	ASSY BRACKET BUNDY MOUNTING	TATA spare parts
551743800212	ASSY T CONNECTOR SUPPORT BRACKET	TATA spare parts
551743800213	ASSY TUBE FROM ADAPTER C2 TO T CONNECTOR	TATA spare parts
551743800214	ASSY TUBE FROM ADAPTER C1 TO T CONNECTOR	TATA spare parts
551743800215	ASSY TUBE FROM T CONNECTOR 2 TO FRONT BR	TATA spare parts
551743800216	ASSY TUBE FROM T CONNECTOR 1 TO FRONT BR	TATA spare parts
551743800217	ASSY TUBE FROM T CONNECTOR 1 TO REAR BRA	TATA spare parts
551743800218	ASSY TUBE FROM T CONNECTOR 2 TO REAR BRA	TATA spare parts
551743800221	TUBE ASSY T CONNECTOR TO TLSPV INLET 2	TATA spare parts
551743800223	ASSY. TUBE FROM T CONNECTOR TO TLSPV INL	TATA spare parts
551743800225	TUBE ASSY TLSPV TO REAR HOSE RH	TATA spare parts

551743800226	ASSY. TUBE FROM TLSPV TO REAR HOSE LH	TATA spare parts
551743800228	ASSY. CONTROL LINK WITH SUPPORT BKT AND	TATA spare parts
551743800229	ASSY. BUNDY SUPPORT BKT.	TATA spare parts
551743800231	ASSY BKT TLSPV MTG	TATA spare parts
551743800233	TUBE ASSY TLSPV TO REAR HOSE LH	TATA spare parts
551743803317	BRACKET BRAKE PIPE MTG	TATA spare parts
551743803318	BRACKET BRAKE HOSE MTG REAR	TATA spare parts
551743806801	ADAPTER	TATA spare parts
551743807701	HOSE BRAKE RESERVOIR TO TMC SECONDARY IN	TATA spare parts
551743807703	HOSE BRAKE RESERVOIR TO TMC PRIMARY INLE	TATA spare parts
551743807711	HOSE FROM RESERVOIR TO TMC PRIMARY-PC LH	TATA spare parts
551743807726	HOSE FROM RESERVOIR TO TMC SECONDARY-PC	TATA spare parts
551743810126	TUBE ASSY T-CONN TO TLSPV	TATA spare parts
551743810127	TUBE ASSY T-CONN TO TLSPV	TATA spare parts
551743810129	TUBE ASSY TWIN LSPV TO REAR HOSE LH	TATA spare parts
551743810130	TUBE ASSY TWIN LSPV TO REAR HOSE RH	TATA spare parts
551743810133	BRAKE HOSE ASSY REAR	TATA spare parts
551743810150	TUBE ASSY T-CONN TO REAR BRAKE HOSE LH	TATA spare parts
551743810151	TUBE ASSY T-CONN TO REAR BRAKE HOSE RH	TATA spare parts
551743990102	T M C KIT MAJOR	TATA spare parts
551743990103	T M C KIT MINOR	TATA spare parts
551743990105	MAJOR KIT TMC ASSY	TATA spare parts
551743990106	MINOR KIT TMC ASSY	TATA spare parts
551743997706	STOPPER - ASSY TLSPV	TATA spare parts
551743997707	COLLAR - ASSY. TLSPV	TATA spare parts
551743997708	CONTROL SPRING - ASSY TLSPV	TATA spare parts
551743997709	BOLT M6X10	TATA spare parts
551743997710	CONTROL SPRING - ASSY TLSPV	TATA spare parts
551746100105	ASSY.STEERING COLUMN	TATA spare parts
551746100107	ASSY. STEERING COLUMN BS3/4	TATA spare parts
551746100110	UPPER COLUMN ASSEMBLY	TATA spare parts
551746100111	I-SHAFT ASSEMBLY UPPER	TATA spare parts
551746100112	I-SHAFT ASSEMBLY MIDDLE	TATA spare parts
551746100113	I-SHAFT ASSEMBLY LOWER	TATA spare parts
551746100114	ASSY.STEERING COLUMN-LHD	TATA spare parts
551746100115	UPPER COLUMN ASSY. - RHD	TATA spare parts
551746100116	LOWER I SHAFT ASSY.	TATA spare parts
551746103201	HEX BOLT	TATA spare parts
551746200101	RUBBER BELLOW-LHD	TATA spare parts
551746200104	ASSY. STEERING RUBBER BELLOW-RHD	TATA spare parts
551746207701	RUBBER GASKET	TATA spare parts
551746207705	RUBBER BELLOW	TATA spare parts
551746207707	RUBBER GASKET	TATA spare parts
551746208219	COVER SHEET	TATA spare parts
551746208220	COVER SHEET	TATA spare parts
551746400104	ASSY STEERING WHEEL	TATA spare parts
551746400105	ASSY STEERING WHEEL-2 SPOKE	TATA spare parts

551746400106	DAMPER ASSEMBLY	TATA spare parts
551746400107	STEERING WHEEL	TATA spare parts
551746400108	BOTTOM COVER WITH CONTACT RING	TATA spare parts
551746406301	HORN PAD	TATA spare parts
551746600104	ASSY. RACK & PINION STRG GEAR-RHD BS3/4	TATA spare parts
551746600105	ASSY RACK AND PINION STEERING GEAR	TATA spare parts
551746600106	ASSY.RACK AND PINION STEERING GEAR	TATA spare parts
551746600109	ASSY R&P STEERING GEAR-LHD	TATA spare parts
551746990101	HOUSING KIT	TATA spare parts
551746990102	PINION BRG SUB ASSY	TATA spare parts
551746990103	ASSY. INNER BALL JOINT BS3	TATA spare parts
551746990105	GEAR BOX ASSEMBLY	TATA spare parts
551746990106	ASSY. TIE ROD BS3/4	TATA spare parts
551746990107	END COMP STEERING TIE ROD	TATA spare parts
551746990108	BELLOW KIT	TATA spare parts
551746990109	YOKE KIT	TATA spare parts
551746990110	PINION COVER KIT	TATA spare parts
551746990111	UPPER COLUMN ASSY	TATA spare parts
551746990112	I-SHAFT ASSY. UPPER	TATA spare parts
551746990113	I-SHAFT ASSY MIDDLE	TATA spare parts
551746990114	I-SHAFT ASSY LOWER	TATA spare parts
551746990115	RUBBER JOINT ASSY	TATA spare parts
551746990137	ASSY. INTERMEDIATE SHAFT LOWER BS3/4	TATA spare parts
551746990138	ASSY. INTERMEDIATE SHAFT MIDDLE BS3/4	TATA spare parts
551746990139	UPPER COLUMN ASSY	TATA spare parts
551746990143	COVER ASSY	TATA spare parts
551746993501	YOKE COVER	TATA spare parts
551746993502	PINION COVER	TATA spare parts
551746993702	RACK	TATA spare parts
551746994301	BELLOW STRAP - PINION	TATA spare parts
551746994302	BELLOW STRAP - SUPPORT	TATA spare parts
551746994303	BELLOW CLIP	TATA spare parts
551746994304	WIRE STEERING	TATA spare parts
551746994305	CLIP RACK BOOT	TATA spare parts
551746996101	TAB WASHER	TATA spare parts
551746996501	NUT TIE ROD END LOCK	TATA spare parts
551746996502	NYLOC NUT	TATA spare parts
551746996503	HEX DOMED NUT	TATA spare parts
551746997701	RUBBER MOUNT	TATA spare parts
551746997703	RACK BUSH	TATA spare parts
551746997704	BELLOW - PINION	TATA spare parts
551746997705	BELLOW - SUPPORT	TATA spare parts
551746997706	DUST EXCLUDER	TATA spare parts
551746997707	BOOT STEERING PINION SIDE	TATA spare parts
551746997708	BOOT STEERING RACK SIDE	TATA spare parts
551746997709	DUST COVER	TATA spare parts
551746997801	OIL SEAL	TATA spare parts

551746998201	BRACKET-SUPPORT END	TATA spare parts
551746998202	BRACKET MOUNT	TATA spare parts
551746998203	BRACKET MOUNT	TATA spare parts
551746998601	SPACER	TATA spare parts
551746998701	SPRING	TATA spare parts
551746999901	YOKE	TATA spare parts
551747100127	ASSY. FILLER NECK (FUEL FILLING)	TATA spare parts
551747100132	ASSY. FILLER NECK (FUEL FILLING)	TATA spare parts
551747100142	ASSY. FUEL TANK COMPLETE	TATA spare parts
551747100143	ASSY. FUEL TANK COMPLETE	TATA spare parts
551747100150	ASSY. FUEL TANK CAP W/TWO KEYS BS2/3/4	TATA spare parts
551747100158	FUEL TANK ASSY WITHOUT TANK UNIT	TATA spare parts
551747100159	FUEL TANK ASSY WITH TANK UNIT	TATA spare parts
551747100162	ASSY BRACKET FRONT (FUEL TANK MTG.)	TATA spare parts
551747100163	ASSY BRACKET REAR (FUEL TANK MTG.)	TATA spare parts
551747100164	ASSY BRACKET (FUEL TANK MTG.)	TATA spare parts
551747100165	BARE FUEL TANK ¿(WITHOUT FUEL PUMP & TAN	TATA spare parts
551747100166	FUEL TANK ASSY WITH PUMP AND TANK UNIT	TATA spare parts
551747100171	ASSEMBLY PLASTIC FUEL TANK	TATA spare parts
551747100175	ASSY BRACKET FRONT (FUEL TANK MTG.)	TATA spare parts
551747100176	ASSY BRACKET REAR (FUEL TANK MTG.)	TATA spare parts
551747100177	ASSY BRACKET (FUEL TANK MTG.)	TATA spare parts
551747100178	FUEL PUMP MODULE (WITH TANKUNIT) BS4	TATA spare parts
551747100180	ASSY BRACKET(GEAR SHIFT CABLE CLAMP MTG)	TATA spare parts
551747100181	ASSY BRACKET GSL CLAMPING	TATA spare parts
551747100185	ASSY. FUEL TANK COMPLETE	TATA spare parts
551747100192	CAP ASSY FUEL TANK	TATA spare parts
551747106923	BREATHER HOSE	TATA spare parts
551747107703	HOSE FUEL FILLING	TATA spare parts
551747107704	HOSE FUEL FILLING	TATA spare parts
551747107707	HOSE (FUEL FILLING)	TATA spare parts
551747107708	BREATHER HOSE	TATA spare parts
551747107711	RUBBER GROMMET	TATA spare parts
551747107712	RUBBER GROMMET(VENT TUBE)	TATA spare parts
551747107714	HOSE (FUEL FILLING)	TATA spare parts
551747107715	BREATHER HOSE	TATA spare parts
551747107718	BREATHER HOSE	TATA spare parts
551747107720	FUEL FILLER HOSE	TATA spare parts
551747108278	BRACKET FUEL LINE CLAMPING	TATA spare parts
551747109910	CNG CYLINDER - 53 LTR	TATA spare parts
551747109911	CNG CYLINDER - 53 LTR.	TATA spare parts
551747200116	ASSY. BRACKET WITH SCREW (LH CYLINDER ST	TATA spare parts
551747200133	ASSY CRADLE(CYLINDER MTG.ON FRAME)	TATA spare parts
551747200140	ASSY.CRADLE(CYLINDER MTG.)	TATA spare parts
551747500106	ASSY.LOCKING STRAP	TATA spare parts
551747500107	STRAP ASSY WITH RUBBER	TATA spare parts
551747500108	ASSY.CYL.MTG.STRAP	TATA spare parts

551747500115	BRACKET ASSY FUEL TANK MTG	TATA spare parts
551747507704	RUBBER PACKING(LH CYLINDER STOPPER)	TATA spare parts
551747507705	RUBBER PACKING(CYLINDER)	TATA spare parts
551747508204	COMPLIANCE PLATE	TATA spare parts
551747600130	ASSY. SUCTION LINE (TANK TO FILTER)BS2/3	TATA spare parts
551747600131	ASSY SUCTION LINE (FILTER TO PUMP)	TATA spare parts
551747600132	FUEL RETURN PIPE (ENGINE TO TANK) BS3	TATA spare parts
551747600133	ASSY. FUEL LINES COMPLETE	TATA spare parts
551747600134	ASSY.FEED LINE(TANK TO FILTER)	TATA spare parts
551747600136	ASSY. FUEL RETURN LINE BS4	TATA spare parts
551747600142	ASSY. SUCTION LINE (FILT TO PMP) BS2/3/4	TATA spare parts
551747600150	FUEL SUCTION PIPE ASSY	TATA spare parts
551747600151	FUEL SUCTION PIPE ASSY	TATA spare parts
551747600152	FUEL SUCTION PIPE ASSY	TATA spare parts
551747600155	FUEL SUCTION PIPE ASSY	TATA spare parts
551747600156	FUEL SUCTION PIPE ASSY	TATA spare parts
551747600158	FUEL SUCTION PIPE ASSY	TATA spare parts
551747600159	FUEL RETURN PIPE ASSY	TATA spare parts
551747600180	FUEL SUCTION PIPE ASSY	TATA spare parts
551747600181	FUEL SUCTION PIPE ASSY	TATA spare parts
551747603304	BRACKET FUEL PIPE CLAMP MTG	TATA spare parts
551747604201	CLAMP	TATA spare parts
551747604202	DOUBLE CLAMP(VENT&L.P.HOSE MTG.)	TATA spare parts
551747604203	P CLAMP(HOSE CLAMPING)	TATA spare parts
551747604204	COATED CLAMP (FOR VENT TUBE)	TATA spare parts
551747604205	CLIP,FUEL LINE	TATA spare parts
551747607701	SEALING RING (FILLING RECEPTACLE-CORR.HO	TATA spare parts
551747607702	SEALING RING-(PRESSURE GAUGE-CORRU.HOSE	TATA spare parts
551747607703	RUBBER GROMMET-CORRU.HOSE MTG AT FUEL N	TATA spare parts
551747608218	BRACKET(VENT&L.P.LINE MTG.ON L.M.)	TATA spare parts
551747610120	VENTING PIPE ASSY (CAB MOUNTED)	TATA spare parts
551747610126	HP GAS TUBE ASSY FILLING RECEP TO CYL	TATA spare parts
551747610127	ASSY. VENTING TUBE (ITVR-CYLINDER)	TATA spare parts
551747610128	ASSY. VENTING TUBE (CYL.ITVR-REGULATOR)	TATA spare parts
551747610130	ASSY.BRACKET(L.P.FILTER MTG.)	TATA spare parts
551747610131	ASSY.L.P.HOSE	TATA spare parts
551747610132	ASSY.H.P.GAS TUBE (FILL.REC TO TEE)	TATA spare parts
551747610133	ASSY.H.P.GAS TUBE(TEE TO PRESSURE GAUGE)	TATA spare parts
551747610134	ASSY.H.P.GAS TUBE(TEE TO CYL.)	TATA spare parts
551747610135	ASSY. VENTING TUBE(CYLINDER TO TEE)	TATA spare parts
551747610136	ASSY.VENTING TUBE(CYL.REG TO TEE)	TATA spare parts
551747610137	ASSY. VENTING TUBE(TEE TO C.UNION)	TATA spare parts
551747610138	ASSY. VENTING TUBE(ATMOSPHERE)	TATA spare parts
551747610139	ASSY.BRACKET(H.P.TUBE CLAMPING)	TATA spare parts
551747610142	ASSY.BRACKET(VENTING TUBE MTG.)	TATA spare parts
551747610144	ASSY.L.P.HOSE(ITVR TO L.P.FILTER)	TATA spare parts
551747610145	ASSY.BRACKET(L.P.FILTER MTG.)	TATA spare parts



551747610146	ASSY.BRACKET (L.P.HOSE MTG.)	TATA spare parts
551747610148	ASSY.H.P.GAS TUBE(UNION TO CYLINDER)	TATA spare parts
551747610149	ASSY.H.P.GAS TUBE(UNION TO UNION-BELOW F	TATA spare parts
551747610150	ASSY.BRACKET(H.P.TUBE CLAMPING-BELOW FLO	TATA spare parts
551747610151	ASSY.BRACKET (H.P.TUBE CLAMPING)	TATA spare parts
551747700102	FILLING RECEPTACLE ASSY	TATA spare parts
551747700103	ASSY.L.P.COAL.FILTER	TATA spare parts
551747700104	ASSY.FILLING RECEPTACLE	TATA spare parts
551747700105	ASSY.ITVR VENTED	TATA spare parts
551747700106	MANUAL CLOSE SUB-ASSEMBLY.	TATA spare parts
551747700107	SOLENOID COIL ASSY.	TATA spare parts
551747700108	PRESSUE RELIEF VALVE ASSY	TATA spare parts
551747700109	FILTER CARTRIDGE SET	TATA spare parts
551747706801	INLET FITTING	TATA spare parts
551747707201	PURGE PLUG	TATA spare parts
551747707202	NYLON PLUG	TATA spare parts
551747707203	ANTI DIRT PLUG	TATA spare parts
551747707204	DRAIN PLUG	TATA spare parts
551747707701	RUBBER DISC	TATA spare parts
551747707801	O-RING	TATA spare parts
551747707802	O-RING	TATA spare parts
551747707803	O-RING	TATA spare parts
551747707804	O-RING-ADAPTOR L.P.COAL FILTER	TATA spare parts
551747707805	O-RING HOUSING BS6	TATA spare parts
551747707806	O-RING - PRESSURE SENSOR	TATA spare parts
551747707808	O-RING - DRAIN PLUG	TATA spare parts
551747707901	FILTER SPINDLE	TATA spare parts
551747709201	SEALING WASHER	TATA spare parts
551747709202	ADJUST WASHER	TATA spare parts
551747709901	PRESSURE GAUGE	TATA spare parts
551747709902	PULL RING	TATA spare parts
551747709903	MAGNET-SWITCH	TATA spare parts
551747709904	OUTLET ADAPTOR	TATA spare parts
551747709905	HIGH PRESSURE SENSOR	TATA spare parts
551747709906	PRV ADAPTOR	TATA spare parts
551747709907	PRESSURE SENSOR	TATA spare parts
551747709908	ADAPTOR L.P.COAL FILTER	TATA spare parts
551747709909	PICO STRAP	TATA spare parts
551747709910	RUBBER RING	TATA spare parts
551747709911	RUBBER RING	TATA spare parts
551747709912	LIP O RING	TATA spare parts
551749100134	ASSY.MUFFLER COMPLETE	TATA spare parts
551749100138	ASSY. CATCON SUPPORT BRACKET	TATA spare parts
551749100139	ASSY. EXHAUST MTG.BKT. TRANSAXLE END	TATA spare parts
551749100142	ASSY FRONT PIPE	TATA spare parts
551749100175	ASSY.MUFFLER COMPLETE WITH HEATSHIELDS.	TATA spare parts
551749100176	HEAT SHIELD ASSY	TATA spare parts

551749100177	HEAT SHIELD ASSY	TATA spare parts
551749100178	ASSY.MUFFLER COMPLETE	TATA spare parts
551749103701	BRACKET EXHAUST MOUNTING	TATA spare parts
551749103706	BRACKET RH EXHAUST MOUNTING	TATA spare parts
551749103707	BRACKET	TATA spare parts
551749103708	BRACKET-RH EXHAUST MOUNTING	TATA spare parts
551749103709	BRACKET	TATA spare parts
551749200101	GASKET (EXHAUST MANIFOLD)	TATA spare parts
551749200102	GASKET EXHAUST PIPE	TATA spare parts
551749200103	GASKET EXHAUST MANIFOLD	TATA spare parts
551749200111	SILENCER ASSY WITH BKT	TATA spare parts
551749200124	SILENCER ASSY WITH BKT	TATA spare parts
551749200125	PIPE ASSY	TATA spare parts
551749203304	BRACKET	TATA spare parts
551754100105	BATTERY CABLE POSITIVE PC	TATA spare parts
551754100107	BATTERY CABLE NEGATIVE PC	TATA spare parts
551754100109	ASSY BATTERY STUD	TATA spare parts
551754100110	ASSY BATTERY STUD LOCKSIDE	TATA spare parts
551754100112	ASSY BATTERY CABLE POSITIVE MAGIC IRIS &	TATA spare parts
551754100114	ASSY BATTERY CLAMP FOR 14 SEATER PC	TATA spare parts
551754100116	BATTERY CABLE NEGATIVE MAGIC IRIS & ACE	TATA spare parts
551754100118	ASSY LITTLE FUSE BOX MTG BKT	TATA spare parts
551754100121	ASSY BATTERY CLAMP	TATA spare parts
551754100123	BATT CABLE POSITIVE ACE ZIP CNG	TATA spare parts
551754100124	ASSY BATTERY CABLE POSITIVE &POWER CABLE	TATA spare parts
551754100126	ASSY BATTERY CABLE POSITIVE	TATA spare parts
551754100127	ASSY BATT.CABLE POSITIVE ZIP QUADRICYCLE	TATA spare parts
551754101604	EARTH_CABLE	TATA spare parts
551754101610	ASSY BATTERY CABLE POSITIVE ACE ZIP CNG	TATA spare parts
551754106301	BATTERY TRAY PC	TATA spare parts
551754108201	BATTERY CLAMP	TATA spare parts
551754108203	BATTERY CLAMP FOR PC	TATA spare parts
551754108204	BOLTED BRACKET FOR BATTERY CLAMPING PC	TATA spare parts
551754108206	BATTERY CABLE BRACKET	TATA spare parts
551754108214	CLAMP BATTERY 50 AH	TATA spare parts
551754108801	BATTERY CLAMPING STUD	TATA spare parts
551754108804	BATTERY CLAMPING STUD FOR BOLTED TRAY	TATA spare parts
551754109904	EARTH CABLE	TATA spare parts
551754109909	EARTH CABLE	TATA spare parts
551754109913	MAIN CABLE BATTERY TO STARTER MOTOR 35SQ	TATA spare parts
551754109914	POWER CABLE MAGIC IRIS / ACE ZIP BSIII	TATA spare parts
551754200101	ASSY_INSTRUMENT_CLUSTER_	TATA spare parts
551754200102	ASSY POWER SOCKET W/O ILLUMINATION	TATA spare parts
551754200104	ASSY_FLOAT TANK UNIT	TATA spare parts
551754200105	ASSY FLOAT TANK UNIT	TATA spare parts
551754200107	ASSY IGN COIL MTG BKT IRIS CNG BS IV	TATA spare parts
551754200109	ASSY INSTRUMENT CLUSTER ACE ZIP AND IRIS	TATA spare parts

551754200110	INSTRUMENT CLUSTER	TATA spare parts
551754200115	HT CABLE MAGIC IRIS CNG	TATA spare parts
551754200134	OVER SPEED INDICATOR ASSY	TATA spare parts
551754201609	TEMPERATURE SENSOR FOR RADIATOR FAN	TATA spare parts
551754201610	ASSY. FLOAT TANK UNIT BS2/3	TATA spare parts
551754201611	VEHICLE SPEED SENSOR BS2/3/4/6	TATA spare parts
551754208201	RELAY MOUNTING BRACKET	TATA spare parts
551754208205	LAMBDA SENSOR CONN PARKING BKT	TATA spare parts
551754208211	WH BKT ON SUSPENSION CROSS MEMBER ACE ZI	TATA spare parts
551754208217	LAMBDA SENSOR CONN PARKING BKT	TATA spare parts
551754209901	VEHICLE SPEED SENSOR	TATA spare parts
551754209903	RAD. COOLING FAN CONTROLLER BS2/3/4	TATA spare parts
551754209909	TEMPERATURE SENSOR FOR FAN CONTROLLER	TATA spare parts
551754209910	HORN 12V DC	TATA spare parts
551754209919	TEMP. SENSOR FOR INST. CLUSTER BS2/3/4	TATA spare parts
551754209920	TEMPERATURE SENSOR FOR FAN CONTROL M10	TATA spare parts
551754209923	HORN 12V DC DIA 70	TATA spare parts
551754209932	ENGINE STOP SOLENOID	TATA spare parts
551754209933	ENGINE STOP SOLENOID	TATA spare parts
551754307701	GASKET TANK UNIT	TATA spare parts
551754400103	ASSY. COMPOSITE HEAD LAMP LH BS3/4	TATA spare parts
551754400104	ASSY COMPOSITE HEAD LAMP RH	TATA spare parts
551754400105	ASSY TAIL LAMP LH	TATA spare parts
551754400106	ASSY TAIL LAMP RH	TATA spare parts
551754400107	ASSY HIGH MOUNTED STOP LAMP	TATA spare parts
551754400108	ASSY COMPOSITE HEAD LAMP WITHOUT LEVELIN	TATA spare parts
551754400109	ASSY COMPOSITE HEAD LAMP WITHOUT LEVELIN	TATA spare parts
551754400111	ASSY HEAD LAMP MTG BRACKET LH	TATA spare parts
551754400112	ASSY HEAD LAMP MTG BRACKET RH	TATA spare parts
551754400113	ASSY REGISTRATION PLATE LAMP	TATA spare parts
551754400114	REAR ROOF LAMP	TATA spare parts
551754400117	COMPOSITE HEAD LAMP WITH LEVELING MOTOR	TATA spare parts
551754400118	COMPOSITE HEAD LAMP WITH LEVELING MOTOR	TATA spare parts
551754407501	RUBBER WASHER FOR HEAD LAMP MOUNTING	TATA spare parts
551754409907	FRONT_REFLEX_REFLECTOR	TATA spare parts
551754409919	REAR REFLEX REFLECTOR PC	TATA spare parts
551754500102	ASSY. IGNITION SWITCH BS3/4	TATA spare parts
551754500103	ASSY. COMBI SW. W/SINGLE STALK BS2/3/4	TATA spare parts
551754500109	ASSY COMBINATION SWITCH SINGLE STALK	TATA spare parts
551754500110	HEAD LAMP LEVELING SWITCH	TATA spare parts
551754500112	STEERING LOCK WITH IGNITION SWITCH ASSY	TATA spare parts
551754501601	HEAD_LAMP_LEVELLING_SW	TATA spare parts
551754504901	HEAD LAMP LEVELLING SWITCH	TATA spare parts
551754504902	HAZARD WARNING SWITCH	TATA spare parts
551754508202	PUSH BUTTON & DIGNOSTIC BRACKET	TATA spare parts
551754508204	ASSY 14POLE FUSE BOX MTG BKT	TATA spare parts
551754509901	HEADLAMP LEVELLING SWITCH	TATA spare parts

551754509904	LIGHTING SW. WIPER	TATA spare parts
551754509905	HORN PIN - COMBI SW SPARE	TATA spare parts
551754509914	FLASHER	TATA spare parts
551754509916	HAZARD WARNING SWITCH	TATA spare parts
551754509920	ELECTRICAL MODULE IGNITION SWITCH	TATA spare parts
551754509922	IGNITION SWITCH KEY MODULE	TATA spare parts
551754509923	START STOP ENABLE DISABLE PIANO SW	TATA spare parts
551754509930	HAZARD WARNING SWITCH	TATA spare parts
551754600106	ENGINE WIRING HARNESS PC	TATA spare parts
551754600107	ROOF WIRING HARNESS PC	TATA spare parts
551754600110	ASSY CABIN WIRING HARNESS	TATA spare parts
551754600111	ASSY CHASSIS WIRING HARNESS	TATA spare parts
551754600114	ASSY MAIN WIRING HARNESS MAGIC IRIS	TATA spare parts
551754600116	ASSY ROOF WIRING HARNESS :MAGIC IRIS & A	TATA spare parts
551754600117	ASSY MAIN WIRING HARNESS ACE ZIP	TATA spare parts
551754600118	ASSY ENGINE WIRING HARNESS : MAGIC IRIS	TATA spare parts
551754600123	ANTENNA CABLE	TATA spare parts
551754600128	ASSY MAIN WIRING HARNESS MAGIC IRIS	TATA spare parts
551754600129	ASSY MAIN WH ACE ZIP BSIII	TATA spare parts
551754600130	ASSY ENGINE WH IRIS/ZIP BSIII	TATA spare parts
551754600131	ASSY ROOF WH IRIS/ZIP BSIII	TATA spare parts
551754600143	ASSY MAIN WIRING HARNESS	TATA spare parts
551754600144	MAIN WH ACE ZIP BSIII	TATA spare parts
551754600145	MAIN WH ACE ZIP BSIII	TATA spare parts
551754600147	W/H MAIN	TATA spare parts
551754600148	W/H MAIN	TATA spare parts
551754600150	WH MAIN MAGIC IRIS CNG	TATA spare parts
551754600152	WH EMS IRIS MAGIC CNG BSIV	TATA spare parts
551754600153	WH CYLINDER EARTHING MAGIC IRIS CNG	TATA spare parts
551754600166	ASSY MAIN WIRING HARNESS	TATA spare parts
551754600168	ASSY ENGINE WIRING HARNESS	TATA spare parts
551754600176	ENGINE WH	TATA spare parts
551754600177	ENGINE WH IRIS/ZIP BSIII	TATA spare parts
551754600192	WIRING HARNESS EMS	TATA spare parts
551754600199	WIRING HARNESS MAIN	TATA spare parts
551754601628	WH MAIN MAGIC IRIS CNG BSIV WITH START S	TATA spare parts
551754601633	CYLINDER EARTHING IRIS CNG	TATA spare parts
551754601634	ASSY MAIN WIRING HARNESS MAGIC IRIS	TATA spare parts
551754601650	BATTERY CABLE -VE	TATA spare parts
551754601678	BATTERY CABLE +VE	TATA spare parts
551754601679	WIRING HARNESS MAIN	TATA spare parts
551754601685	WIRING HARNESS EMS	TATA spare parts
551754603302	BRACKET BATTERY + VE CABLE MTG	TATA spare parts
551754603335	BRACKET - WIRING HARNESS MTG	TATA spare parts
551754607508	PLUG BUTTON FOR 30 X 40 SLOT	TATA spare parts
551754607509	PLUG BUTTON FOR 25 X 40 SLOT	TATA spare parts
551754607510	PLUG BUTTON FOR 30 X 60 SLOT	TATA spare parts

551754608202	EWH MOUNTING BRACKET 1	TATA spare parts
551754608203	EWH MOUNTING BRACKET 2	TATA spare parts
551754608204	EWH MOUNTING BRACKET 3 (ADAPTOR PLATE)	TATA spare parts
551754608205	EWH MOUNTING BRACKET 4	TATA spare parts
551754608206	EWH MOUNTING BRACKET 5 (ADAPTOR PLATE)	TATA spare parts
551754608207	FUSE BOX MOUNTING BRACKET	TATA spare parts
551754608210	BATTERY CABLE & BCP INTERFACE CONNECTOR	TATA spare parts
551754608211	MAIN WIRING HARNESS MOUNTING BRACKET ON	TATA spare parts
551754608219	CLAMP FOR WIRING HARNESS	TATA spare parts
551754608220	WH BRACKET HAT SECTION SINGLE MOUNT	TATA spare parts
551754608228	BRACKET ON TRANSMISSION FOR BCP & EWH	TATA spare parts
551754608230	BRACKET NEAR CRANK SENSOR	TATA spare parts
551754608235	BKT ON EXHAUST MTG BKT LH	TATA spare parts
551754608236	WH BRACKET NEAR FUSE BOX ACE ZIP CNG	TATA spare parts
551754608237	BRACKET 2WAY ON LONG MEMBER IRIS	TATA spare parts
551754608238	3WAY BRACKET ON LONG MEMBER	TATA spare parts
551754608239	BRACKET FOR WH ENGINE AND BCP BSIV DICOR	TATA spare parts
551754608241	BKT ON ADAPTER PLATE	TATA spare parts
551754608245	BRACKET FOR DOWNSTREAM LAMBDA ON TRANS	TATA spare parts
551754610105	BATTERY CABLE +VE	TATA spare parts
551754610127	WIRING HARNESS MAIN	TATA spare parts
551754610136	WIRING HARNESS MAIN	TATA spare parts
551754610139	WIRING HARNESS - MAIN	TATA spare parts
551754610141	WIRING HARNESS - EMS	TATA spare parts
551754610144	WIRING HARNESS MAIN BS4	TATA spare parts
551754610145	WIRING HARNESS MAIN	TATA spare parts
551754610157	WIRING HARNESS EMERGENCY SWITCH	TATA spare parts
551754610160	WIRING HARNESS MAIN	TATA spare parts
551754610163	WIRING HARNESS MAIN	TATA spare parts
551754610178	WIRING HARNESS EMS	TATA spare parts
551754610179	WIRING HARNESS MAIN	TATA spare parts
551754611606	WIRING HARNESS MAIN	TATA spare parts
551754611614	WIRING HARNESS MAIN BS4	TATA spare parts
551754611615	WIRING HARNESS EMS BS4	TATA spare parts
551754800101	ASSY. MUSIC SYSTEM BS3/4	TATA spare parts
551754808201	BRACKET MUSIC SYSTEM MTG LH	TATA spare parts
551754808202	BRACKET MUSIC SYSTEM MTG RH	TATA spare parts
551755106301	ACE ZIP STICKER	TATA spare parts
551755106302	ACE ZIP STICKER	TATA spare parts
551755106304	MASCOT ACE	TATA spare parts
551755106305	MASCOT ZIP	TATA spare parts
551755106306	MASCOT	TATA spare parts
551758304002	SCISSORS JACK ASSY	TATA spare parts
551758900601	ENGINE MTG BKT / LH / PENGUINE	TATA spare parts
551758900602	ENGINE MTG BKT / RH / PENGUINE	TATA spare parts
551758900603	PULLER FOR FLYWHEEL	TATA spare parts
551758900604	PULLER FOR BUSH ON GEAR END COVER	TATA spare parts

551758900605	PULLER FOR ROCKER ARM SHAFT ON CYL HEAD	TATA spare parts
551758900606	CRANK SHAFT BEARING BUSH PULLER FOR CRAN	TATA spare parts
551758900607	VALVE LIFTING TOOL CYL.HD ASSLY 75 & 600	TATA spare parts
551758900608	FLY WHEEL LOCKING TOOL FOR 600CC ENGINE	TATA spare parts
551758900609	BUMPING CLEARNACE MEASURING TOOL / PENG	TATA spare parts
551758900610	PULLER FOR SMALL END SIDE BUSH REMOVING	TATA spare parts
551758900611	TOOL FOR REMOVING VALVE GUIDE FOR CYL HE	TATA spare parts
551758900612	STEAMSEAL PRESSING TOOL FOR CYLINDER HEA	TATA spare parts
551758900613	OIL SEAL PRESSING MANDREL FOR CRANK SHAF	TATA spare parts
551758900614	ADAPTOR FOR COMPRESSION CHECKING	TATA spare parts
551758900615	ENGINE AND TRANSAXLE HOLDER / PENGUINE	TATA spare parts
551758900616	FLY WHEEL LOCKING TOOL	TATA spare parts
551758900617	BUMPING CLEARANCE CHECKING GAUGE	TATA spare parts
551758902402	TROLLEY/REMOVE ENGINE & TRANSAXLE/PENGU	TATA spare parts
551758902601	DRIFT / DRIVE SHAFT OIL SEAL / PENGUINE	TATA spare parts
551758902602	DRIFT / NEEDLE BRG / GB / PENGUINE	TATA spare parts
551758902603	DOLLEY/O-RACE BRG/LAY SHAFT F-HALF/PENGU	TATA spare parts
551758902604	DRIFT / INPUT SHAFT OIL SEAL / PENGUINE	TATA spare parts
551758902605	PULLER / REMOVE TRANSAXLE HALF BRG / PEN	TATA spare parts
551758902606	PULLER FOR NEEDLE BEARING	TATA spare parts
551758903201	PULLER / REMOVE BRAKE DRUM / PENGUINE	TATA spare parts
551758903301	DRIFT / F-HUB OIL SEAL / PENGUINE	TATA spare parts
551758903302	DRIFT/F-HUB O-RACE T-ROLLER BRG/PENGUINE	TATA spare parts
551758903501	DOLLEY / BRAKE DRUM MTG FLANGE / PENGUIN	TATA spare parts
551758903502	MANDREL / INSTALL HUB BRAKE DRUM MTG FLA	TATA spare parts
551758903503	DOLLEY / REMOVE HUB UNITISED BRG / PENGU	TATA spare parts
551758903504	MANDREL (UNITISED BEARING)	TATA spare parts
551758904201	DIAL GAUGE HOLD STAND/HUB PLAY/PENGUIN	TATA spare parts
551758904202	PISTON CUP EXPANDER 15.87D / IRIS	TATA spare parts
551758904203	PISTON CUP ASSY. TOOL	TATA spare parts
551758904701	SOCKET 2ITVR CNG VALVE	TATA spare parts
551758904702	SOCKET SUPPORT ASSY	TATA spare parts
551758905401	13BI -250L BEND SPANNER / STARTER MOTOR	TATA spare parts
551760000102	ASSY BODY SHELL COMPL PAINTED -GC	TATA spare parts
551760000102BF	ASSY BODY SHELL COMPL PAINTED WHITE	TATA spare parts
551760000102BN	ASSY BODY SHELL COMPL PIANTED	TATA spare parts
551760000102HO	BODY SHELL COMPLETE PAINTED -GC	TATA spare parts
551760000102IH	ASSY BODY SHELL COMPL PAINTED -GC	TATA spare parts
551760000102IP	BODY SHELL COMPL PIANTED -GC S. ORANGE	TATA spare parts
551760000103	ASSY BODY SHELL COMPL -GC	TATA spare parts
551760000138	ASSY BODY SHELL - LESS DOORS_PC	TATA spare parts
551760000181	ASSY BODY SHELL COMPLETE PAINTED_PC	TATA spare parts
551760000181BF	ARCTIC_WHITE-ASSY BODY SHELL COMPLETE	TATA spare parts
551760000181BN	ASSY BODY SHELL COMPLETE PAINTED_PC	TATA spare parts
551760000181BU	JET_BLACK-ASSY BODY SHELL COMPLETE PAINT	TATA spare parts
551760000181FD	ASSY BODY SHELL COMPLETE PAINTED_PC	TATA spare parts
551760000181HO	ASSY BODY SHELL COMPLETE PAINTED_PC	TATA spare parts

551760000181HS	ASSY BODY SHELL COMPLETE PAINTED_PC	TATA spare parts
551760000181ZZ	ASSY BODY SHELL COMPLETE PA	TATA spare parts
551760000185	ASSY BODY SHELL COMPLETE PAINTED_MAGIC	TATA spare parts
551760000216BF	ARCTIC WHITE-ASSY BODY SHELL COMPL PAINT	TATA spare parts
551760000219	ASSY BODY SHELL-NO DOOR	TATA spare parts
551760000229	ASSY BODY SHELL COMPLETE PAINTED	TATA spare parts
551760000233	ASSY BODY SHELL COMPL PAINTED GC BS IV	TATA spare parts
551760000233BF	ARCTIC_WHITE-ASSY BODY SHELL COMPL PAINT	TATA spare parts
551760000233IH	ICY_BLUE-ASSY BODY SHELL COMPL PAINT	TATA spare parts
551760000250	ASSY BODY SHELL NO DOOR	TATA spare parts
551760000252BF	ASSY BODY SHELL COMPLETE PAINTED 3 DOOR	TATA spare parts
551760000252FD	ASSY BODY SHELL COMPLETE SK_GOLN_YELW	TATA spare parts
551760000291	ASSY BODY SHELL COMP PAINTED ZIP REFRESH	TATA spare parts
551760000291BF	ARTIC WHITE-ASSY BODY SHELL COMP PAINTED	TATA spare parts
551760000291BN	RUBY RED-ASSY BODY SHELL COMP PAINTED ZI	TATA spare parts
551760000291HO	NEON RUSH-ASSY BODY SHELL COMP PAINTED Z	TATA spare parts
551760000291IH	ICY BLUE-ASSY BODY SHELL COMP PAINTED ZI	TATA spare parts
551760000291IP	SUNRISE ORANGE-ASSY BODY SHELL COMP PAIN	TATA spare parts
551760000305	BODY SHELL ASSY PAINTED	TATA spare parts
551760000305BF	ARCTIC WHITE - BODY SHELL ASSY PAINTED	TATA spare parts
551760000305BN	RUBY RED - BODY SHELL ASSY PAINTED	TATA spare parts
551760000305IH	ICY BLUE-BODY SHELL ASSY PAINTED	TATA spare parts
551760000305IP	SUNRISE ORANGE - BODY SHELL ASSY PAINTED	TATA spare parts
551760000337	BODY SHELL ASSY	TATA spare parts
551760000338	BODY SHELL ASSY	TATA spare parts
551760000338BF	ARTIC WHITE-ASSY BODY SHELL COMP PAINTED	TATA spare parts
551760000338BN	RUBY RED-ASSY BODY SHELL COMP PAINTED ZI	TATA spare parts
551760000338HO	NEON RUSH-ASSY BODY SHELL COMP PAINTED Z	TATA spare parts
551760000338IH	ICY BLUE-ASSY BODY SHELL COMP PAINTED ZI	TATA spare parts
551760000338IP	SUNRISE ORANGE-ASSY BODY SHELL COMP PAIN	TATA spare parts
551760000344	BODY SHELL ASSY	TATA spare parts
551760000344BF	BODY SHELL COMPLETE ARTICWHITE	TATA spare parts
551760000344BU	BODY SHELL COMPLETE JETBLACK	TATA spare parts
551760000344FD	BODY SHELL COMPLETE SKGOLDENYELLO	TATA spare parts
551760000344HO	BODY SHELL COMPLETE NEONRUSH	TATA spare parts
551760000344HS	BODYSHELL COMPLETE PAINTED LASER RED	TATA spare parts
551760000344IP	SUNRISE_ORAG-BODY SHELL ASSY	TATA spare parts
551760000350BF	BODY SHELL PAINTED ARCTIC WHITE	TATA spare parts
551760000359	BODY SHELL ASSY PAINTED	TATA spare parts
551760000359BF	ASSY. BODYSHELL PAINTED ARCTIC WHITE BS4	TATA spare parts
551760000359BN	BODY SHELL ASSY RUBY_RED	TATA spare parts
551760000359HO	NEON RUSH -BODY SHELL ASSY PAINTED	TATA spare parts
551760000359HS	LASER_RED-BODY SHELL ASSY PAINTED	TATA spare parts
551760000359IH	BODY SHELL ASSY PAINTED ICY_BLUE	TATA spare parts
551760000359IP	SUNRISE_ORAG-BODY SHELL ASSY PAINTED	TATA spare parts
55176000Z102BF	ASSY BODY SHELL COMP. PAINTED -GC - ARCT	TATA spare parts
55176000Z102BN	ASSY BODY SHELL COMP. PAINTED -GC - RUBY	TATA spare parts

55176000Z102FD	ASSY BODY SHELL COMP. PAINTED -GC - SK G	TATA spare parts
551760010304	BODY SHELL ASSY	TATA spare parts
551760100104	ASSY PANEL REAR CROSS WALL OUTER	TATA spare parts
551760100125	ASSY BATTERY SUPPORT	TATA spare parts
551760100139	ASSY PANEL REAR CROSS	TATA spare parts
551760100140	ASSY PANEL REAR CROSS WALL OUTER	TATA spare parts
551760106910	REINF PARKING LEVER LOWER	TATA spare parts
551760600101	ASSY DASHBOARD CROSS MEMBER	TATA spare parts
55176060010135	ASSY DASH BOARD CROSS MEMBER	TATA spare parts
551760600140	ASSY DASHBOARD CROSS MEMBER-LHD	TATA spare parts
551760600178	ASSY DASHBOARD CROSS MEMBER	TATA spare parts
551760603316	BRACKET DASHBOARD MTG CENTER LH	TATA spare parts
551761100117	ASSY BRKT OIL FILTER MTG	TATA spare parts
551761100152	ASSY BRACKET RADIATOR	TATA spare parts
551761100195	ASSY AMOUNT TUBE STRUCTURE	TATA spare parts
551761100303	ASSY BRACKET STEERING GEAR	TATA spare parts
551761108240	PANEL BATTERY SERVICE HOLE COVER	TATA spare parts
551761110123	BRACKET ASSY HORN MTG	TATA spare parts
551761200118	ASSY BRACKET BUMPER MTG SIDE	TATA spare parts
551761200124	TUBE ASSY	TATA spare parts
551761200210	ASSY COVER AIRFILTER ACCESS	TATA spare parts
551761200290	ASSY SUPPORT STAY - FRONT SUSPENSION	TATA spare parts
551761200297	ASSY CROSS MEMBER FRONT - FRNT SUSPN	TATA spare parts
551761200298	ASSY CROSS MEMBER REAR - FRNT SUSPN	TATA spare parts
551761200318	ASSY BRACKET - FUEL TANK MIDDLE MTG	TATA spare parts
551761206901	BEAM FRONT SUSPENSION FRONT	TATA spare parts
551761206909	SUPP BEAM FRT SUSP REAR SQUARE TUBE	TATA spare parts
551761208202	CROSS MEMBER FRONT	TATA spare parts
551761600103	ASSY WHEEL ARCH FRONT LH	TATA spare parts
551761600104	ASSY WHEEL ARCH FRONT RH	TATA spare parts
551761600117	BRACKET ASSY	TATA spare parts
551761600132	ASSY FRT FLOOR	TATA spare parts
551761600133	FRONT FLOOR ASSY	TATA spare parts
55176160013335	FRONT FLOOR ASSY	TATA spare parts
55176160013535	PANEL ASSY FRONT FLOOR UPPER	TATA spare parts
551761600206	ASSY PANEL FRONT FLOOR UPPER ZIP CNG	TATA spare parts
551761800102	ASSY PANEL CENTER	TATA spare parts
551761800115	ASSY PANEL REAR FLOOR	TATA spare parts
551761800134	ASSY SEAT PAN	TATA spare parts
551761800136	ASSY COVER START MOTOR SERVICE	TATA spare parts
551761800181	ASSY PANEL CENTER FLOOR REAR BS4	TATA spare parts
551761808201	PANEL CENTER FLOOR FRONT	TATA spare parts
551762000101	ASSY. FRONT WALL BS3/4	TATA spare parts
551762000102	ASSY FRONT WALL COMPLETE GC	TATA spare parts
55176200010235	ASSY. FRONT WALL-ACE ZIP BS3/4	TATA spare parts
551762000104	ASSY FRONT WALL COMPLETE GC LHD	TATA spare parts
551762708201	PANEL FRONT WALL	TATA spare parts



551763000101	ASSY SIDE WALL COMPLETE LH_GC	TATA spare parts
55176300010135	ASSY. SIDE WALL LH BS3/4	TATA spare parts
551763000102	ASSY SIDE WALL COMPLETE RH_GC	TATA spare parts
55176300010235	ASSY. SIDE WALL RH BS3/4	TATA spare parts
551763000103	ASSY. SIDE WALL COMP. LH (PC) BS3/4	TATA spare parts
55176300010335	CED-ASSY SIDE WALL COMPLETE LH_PC	TATA spare parts
551763000104	ASSY. SIDE WALL COMP. RH (PC) BS3/4	TATA spare parts
55176300010435	CED-ASSY SIDE WALL COMPLETE RH (PC)	TATA spare parts
551763000109	ASSY SIDE WALL COMPLETE RH (PC)	TATA spare parts
551763200160	ASSLY REINF SEAT BELT RETRACTOR RH	TATA spare parts
551763200168	ASSY BRKT RR BUMPER MTG	TATA spare parts
551763200203	ASSY FUEL RECIPTICAL CUP	TATA spare parts
551763203304	BRACKET CANOPY BACK OUTER LH	TATA spare parts
551763203305	BRACKET CANOPY BACK OUTER LH	TATA spare parts
551763600115	ASSY A PILLAR INNER LOWER COMPLETE LH	TATA spare parts
551763600116	ASSY A PILLAR INNER LOWER COMPLETE RH	TATA spare parts
551763600117	ASSY CARRIER SIDE WALL INNER COMPLETE LH	TATA spare parts
551763600118	ASSY CARRIER SIDE WALL INNER COMPLETE RH	TATA spare parts
551763700113	ASSY CANTRAIL REAR OUTER LH	TATA spare parts
551763700114	ASSY CANTRAIL REAR OUTER RH	TATA spare parts
551763700119	ASSY SIDE WALL OUTER COMPLETE LH (PC)	TATA spare parts
551763700120	ASSY SIDE WALL OUTER COMPLETE RH (PC)	TATA spare parts
551763700125	ASSY CARRIER SIDE WALL OUTER COMPLETE	TATA spare parts
55176370012535	CED-ASSY CARRIER SIDE WALL OUTER COMPLE	TATA spare parts
551763700126	ASSY CARRIER SIDE WALL OUTER COMPLETE	TATA spare parts
55176370012635	CED-ASSY CARRIER SIDE WALL OUTER COMPLE	TATA spare parts
551763700127	ASSY PANEL CARRIER SIDE WALL OUTER LOWER	TATA spare parts
551763700131	ASSY PANEL CARRIER SIDE SILL OUTER LH	TATA spare parts
551763700137	ASSY CARRIER SIDE WALL OUTER COMPLETE LH	TATA spare parts
551763700138	ASSY CARRIER SIDE WALL OUTER COMPLETE RH	TATA spare parts
55176370820135	PANEL SIDE SILL OUTER-LH	TATA spare parts
55176370820235	PANEL SIDE SILL OUTER-RH	TATA spare parts
551763708248	REINF SIDE GATE MTG LH	TATA spare parts
551763990101	ASSY C MOUNT REWORK PLATE	TATA spare parts
551763993301	REINF SIDE WALL OUTER LH - FOR REPAIR	TATA spare parts
551763993302	REINF SIDE WALL OUTER RH- FOR REPAIR	TATA spare parts
551763993305	STA MOUNTING BUSH	TATA spare parts
551764000101	ASSY PANEL REAR WALL COMPLETE	TATA spare parts
55176400010135	PANEL ASSY REAR WALL	TATA spare parts
551764603301	BRACKET MIDDLE- REAR PANEL	TATA spare parts
551765103301	BRACKET	TATA spare parts
551765200101	ASSY ROOF HEADER FRONT	TATA spare parts
551765200103	ASSY PANEL CARRIER ROOF	TATA spare parts
551765200108	ASSY REAR CORNER ROOF PC	TATA spare parts
551765203301	BRACKET CANOPY ROOF REAR	TATA spare parts
551765203304	BRACKET	TATA spare parts
551765208202	PANEL ROOF HEADER REAR	TATA spare parts

551765208206	PANEL CARRIER ROOF	TATA spare parts
551765208209	PANEL CARRIER ROOF REAR UPPER BOW	TATA spare parts
551765708201	PANEL ROOF	TATA spare parts
55176570820135	PANEL ROOF	TATA spare parts
551765708202	PANEL ROOF PC	TATA spare parts
551766100106	ASSY TUBULAR FRAME COMPLETE-IRIS CNG	TATA spare parts
551766100107	ASSY TOP COVER CYLINDER-IRIS CNG	TATA spare parts
551766108204	PANEL REAR¿ CYL COVER¿ IRIS CNG	TATA spare parts
551766208209	NUT PLATE CYL COVER-IRIS CNG	TATA spare parts
551767102301	WINDSHIELD GLASS BS2/3/4	TATA spare parts
551767106301	GLASS STOPPER	TATA spare parts
551767106305	MOULD WINDSHIELD GLASS BS2/3/4	TATA spare parts
551767800101	ASSY SLIDING GLASS REAR WINDOW	TATA spare parts
551767802301	REAR GLASS -FIXED	TATA spare parts
551767806301	MOULD REAR SLIDING WINDOW	TATA spare parts
551768200104	ASSY INSULATION ZIP CNG	TATA spare parts
551768203301	RETAINER FOR INSULATION	TATA spare parts
551768206301	INSULATION ENGINE COVER RH	TATA spare parts
551768206302	INSULATION ENGINE FRONT	TATA spare parts
551768206303	INSULATION ENGINE SIDE RH	TATA spare parts
551768206304	INSULATION ENGINE SIDE LH	TATA spare parts
551768206305	INSULATION AIR FILTER COVER	TATA spare parts
551768206306	INSULATION ENGINE COVER LH	TATA spare parts
551768206307	INSULATION REAR FLOOR PANEL	TATA spare parts
551768206308	INSULATION COVER START MOTOR SERVICE	TATA spare parts
551768206309	INSULATION EXHAUST COVER	TATA spare parts
551768206315	INSULATION FOR PANEL REAR WALL	TATA spare parts
551768206319	INSULATION REAR FLOOR PANEL	TATA spare parts
551768206321	INSULATION LOAD BODY COVER	TATA spare parts
551768206322	INSULATION EXHAUST	TATA spare parts
551768406301	FLOOR MAT FRONT	TATA spare parts
551768406302	FLOOR MAT REAR	TATA spare parts
551768406304	FLOOR MAT FRONT-LHD	TATA spare parts
551768406312	CARPET PANEL REAR CROSS MEMBER LWR	TATA spare parts
551768406313	CARPET PANEL CENTER FLOOR REAR	TATA spare parts
551768900103	ASSY COVER SHIFT LEVER	TATA spare parts
551768900104	ASSY LID GLOVE BOX	TATA spare parts
551768900105	ASSY DASHBOARD HIGH END PC	TATA spare parts
551768900108	ASSY DASHBOARD LOW END	TATA spare parts
551768900109	ASSY DASHBOARD LOW END PC	TATA spare parts
551768900110	ASSY NACELLE COMPLETE	TATA spare parts
551768900111	ASSY INSTRUMENT CLUSTER HOOD UPPER	TATA spare parts
551768900112	ASSY INSTRUMENT HOOD COVER LOWER	TATA spare parts
551768900112A3	ASSY INSTRUMENT HOOD COVER LOWER	TATA spare parts
551768900113	ASSY DASHBOARD COMPLETE LHD	TATA spare parts
551768900122	ASSY DASHBOARD	TATA spare parts
551768906304	CAP WASHER RESERVIOR	TATA spare parts

551768906305	CAP BREAK FLUID RESERVIOR	TATA spare parts
551768906306	CAP DASHBOARD MTG LH	TATA spare parts
551768906307	CAP DASHBOARD MTG RH	TATA spare parts
551768906310	HOUSING GLOVE BOX	TATA spare parts
551768906311	STOPPER GLOVE BOX	TATA spare parts
551768906312	LID GLOVE BOX	TATA spare parts
551768906313	BELLOW HOLDER	TATA spare parts
551768906314	PAD AUDIO SUPPORT	TATA spare parts
551768906316	INSTRUMENT CLUSTER HOOD UPPER	TATA spare parts
551768906317	LOCK GLOVE BOX	TATA spare parts
551768906319	COVER DASHBOARD BOTTOM	TATA spare parts
551768906322	DUMMY COVER PAINO SWITCH	TATA spare parts
551768906323	DUMMY COVER HEADLAMP LEVELING SWITCH	TATA spare parts
551769100101	ASSY SIDE PAD FRONT RH	TATA spare parts
551769100102	ASSY SIDE PAD REAR LH	TATA spare parts
551769100103	ASSY SIDE PAD REAR RH	TATA spare parts
551769100108	ASSY TOP COVER REAR	TATA spare parts
551769106301	PAD REAR PANEL	TATA spare parts
551769106307	A PILLAR TRIM LH	TATA spare parts
551769106307AQ	A PILLAR TRIM LH	TATA spare parts
551769106308	A PILLAR TRIM RH	TATA spare parts
551769106308AQ	A PILLAR TRIM RH	TATA spare parts
551769106309	ELR UNIT COVER LH	TATA spare parts
551769106310	ELR UNIT COVER RH	TATA spare parts
551769106314	A PILLAR TRIM LH (LHD)	TATA spare parts
551769106315	A PILLAR TRIM RH(LHD)	TATA spare parts
551769106316	TAIL LAMP COVER	TATA spare parts
551769106320	TAIL LAMP COVER RH	TATA spare parts
551769306301	COVER FRONT FLOOR UPPER	TATA spare parts
551769306303	PANEL ENGINE COVER	TATA spare parts
551769306304	COVER FRONT FLOOR UPPER RH SIDE	TATA spare parts
551769506301	HEADLINER FRONT GC	TATA spare parts
551769506302	GRAB HANDLE FRONT	TATA spare parts
551769506303	HEADLINER REAR	TATA spare parts
551769506304	HEADLINER FRONT PC	TATA spare parts
551769506307	HEADLINER FRONT ZIP LHD	TATA spare parts
551769706301	B PILLAR SEAL	TATA spare parts
551769706302	REAR SIDE WALL SEAL	TATA spare parts
551769706303	B PILLAR SEAL	TATA spare parts
551769706304	REAR SIDE WALL SEAL RH	TATA spare parts
551770100133	ASSY LOAD BODY FLOOR	TATA spare parts
55177010013335	FLOOR ASSY LOAD BODY	TATA spare parts
551770100158	ASSY TAILGATE SKIRT	TATA spare parts
551770100168	ASSY LOADBODY FLOOR COVER PANEL	TATA spare parts
551770100202	ASSY LOADBODY FLOOR ACE ZIP CNG	TATA spare parts
551770100215	FLOOR ASSY LOAD BODY	TATA spare parts
551770108220	LOADBODY FLOOR COVER PANEL	TATA spare parts

551770108251	PANEL LOAD BODY FLOOR LH	TATA spare parts
55177010825135	PANEL LOAD BODY FLOOR LH	TATA spare parts
551770108260	PANEL LOAD BODY FLOOR MIDDLE	TATA spare parts
55177010826035	PANEL LOAD BODY FLOOR MIDDLE	TATA spare parts
551770108261	PANEL LOAD BODY FLOOR RH	TATA spare parts
55177010826135	PANEL LOAD BODY FLOOR RH	TATA spare parts
551770208201	FRONT WALL	TATA spare parts
551770300109	ASSY-SIDEWALL PANEL LH	TATA spare parts
55177030010935	SIDE WALL PANEL ASSY LH	TATA spare parts
551770300110	ASSY-SIDE WALL PANEL RH	TATA spare parts
55177030011035	SIDE WALL PANEL ASSY RH	TATA spare parts
551770300161	SIDE PANEL ASSY LH	TATA spare parts
551770300162	SIDE PANEL ASSY RH	TATA spare parts
551770300165	LOAD BODY ASSY	TATA spare parts
551770300166BF	ARCTIC WHITE-LOAD BODY ASSY	TATA spare parts
551770300166BN	LOAD BODY ASSY RUBY_RED	TATA spare parts
551770300166HO	NEON RUSH -LOAD BODY ASSY	TATA spare parts
551770300166HS	LASER_RED-LOAD BODY ASSY	TATA spare parts
551770300166IH	ICY BLUE-LOAD BODY ASSY	TATA spare parts
551770300166IP	SUNRISE_ORAG-LOAD BODY ASSY	TATA spare parts
551770300177	BRACKET ASSY - LH	TATA spare parts
551770300178	BRACKET ASSY - RH	TATA spare parts
551770400101	ASSY-TAILGATE PANEL	TATA spare parts
55177040010135	PANEL ASSY TAILGATE	TATA spare parts
551770400107	PANEL ASSY TAILGATE	TATA spare parts
551770900106	ASSY PROTECTOR BAR LWR	TATA spare parts
551772200101	ASSY. FRONT DOOR SHELL LH BS3/4	TATA spare parts
55177220010135	CED-ASSY FRT DOOR SHELL LH	TATA spare parts
551772200102	ASSY. FRT DOOR SHELL RH BS2/3/4	TATA spare parts
55177220010235	CED-ASSY FRT DOOR SHELL RH	TATA spare parts
551772200105	ASSY PANEL OTR FR_DR LH	TATA spare parts
55177220010535	OUTER PANEL ASSY FRONT DOOR LH	TATA spare parts
551772200106	ASSY PANEL FRONT DOOR OTR RH	TATA spare parts
55177220010635	OUTER PANEL ASSY FRONT DOOR RH	TATA spare parts
551772200117	ASSY FRT DOOR SHELL LH LHD	TATA spare parts
551772300103	ASSY DOOR LATCH WITH LINKS LH	TATA spare parts
551772300104	ASSY DOOR LATCH WITH LINKS RH	TATA spare parts
551772300105	ASSY DOOR OUTER HANDLE	TATA spare parts
551772300106	ASSY OUTER DOOR HANDLE RH	TATA spare parts
551772300107	ASSY LOCK KIT	TATA spare parts
551772300108	ASSY DOOR LOCK	TATA spare parts
551772300110	ASSY DOOR OUTER HANDLE LH	TATA spare parts
551772300111	ASSY DOOR OUTER HANDLE RH	TATA spare parts
551772300114	KIT ASSY LOCK SET- ACE ZIP	TATA spare parts
551772300116	KIT ASSY LOCK SET IRIS CNG	TATA spare parts
551772300117	KIT ASSY LOCK SET ACE ZIP LHD	TATA spare parts
551772300120	ASSY INNER HANDLE RH	TATA spare parts

551772306301	WAIST SEAL INNER LH	TATA spare parts
551772306302	WAIST SEAL INNER RH	TATA spare parts
551772306303	WAIST SEAL OUTER LH	TATA spare parts
551772306304	WAIST SEAL OUTER RH	TATA spare parts
551772306305	DOOR PRIMARY SEAL LH	TATA spare parts
551772306306	DOOR PRIMARY SEAL RH	TATA spare parts
551772306307	DOOR SECONDARY SEAL MOULD LH	TATA spare parts
551772306308	DOOR SECONDARY SEAL MOULD RH	TATA spare parts
551772306309	DOOR PRIMARY SEAL LH	TATA spare parts
551772306310	PRIMARY SEAL RH	TATA spare parts
551772306311	SECONDARY SEAL LH	TATA spare parts
551772306312	SECONDARY SEAL RH	TATA spare parts
551772306318	WAIST SEAL INNER LH	TATA spare parts
551772306320	WAIST SEAL OUTER LH	TATA spare parts
551772306321	PRIMARY SEAL LH	TATA spare parts
551772306322	PRIMARY SEAL RH	TATA spare parts
551772306323	SECONDARY SEAL LH	TATA spare parts
551772306324	SECONDARY SEAL RH	TATA spare parts
551772306327	WAIST SEAL INNER RH	TATA spare parts
551772306328	WAIST SEAL OUTER RH	TATA spare parts
551772310101	HINGE ASSY WITH PIN LH	TATA spare parts
551772310102	HINGE ASSY WITH PIN RH	TATA spare parts
551772500101	ASSY MANUAL WINDOW REGULATOR LH	TATA spare parts
551772500102	ASSY MANUAL WINDOW REGULATOR RH	TATA spare parts
551772500103	ASSY MANUAL WINDOW REGULATOR LH	TATA spare parts
551772500104	ASSY MANUAL WINDOW REGULATOR RH	TATA spare parts
551772502301	REGULATING GLASS FRONT DOOR LH	TATA spare parts
551772502302	REGULATING GLASS FRONT DOOR RH	TATA spare parts
551772506301	DOOR GLASS RUN MOULD LH	TATA spare parts
551772506302	DOOR GLASS RUN MOULD RH	TATA spare parts
551772506303	GLASS RUN MOULD LH	TATA spare parts
551772506304	GLASS RUN MOULD RH	TATA spare parts
551772506305	GLASS RUN MOULD LH	TATA spare parts
551772506306	GLASS RUN MOULD RH	TATA spare parts
551772700101	ASSY FRONT DOOR PAD LH	TATA spare parts
551772700102	ASSY FRONT DOOR PAD RH	TATA spare parts
551772706301	PLASTIC MEMBRANE LH	TATA spare parts
551772706302	PLASTIC MEMBRANE RH	TATA spare parts
551773200101	ASSY RR DOOR SHELL LH	TATA spare parts
55177320010135	CED-ASSY RR DOOR SHELL LH	TATA spare parts
551773200116	ASSY RR DOOR SHELL RH	TATA spare parts
551773300103	ASSY RR DOOR LATCH WITH LINKS	TATA spare parts
551773300108	ASSY RR DOOR LATCH WITH LINKS RH	TATA spare parts
551773306301	REAR DOOR TOP COVER	TATA spare parts
551773306303	RR_DR_PRIMARY_SEAL_LH	TATA spare parts
551773306305	REAR DOOR PRIMARY SEAL	TATA spare parts
551773306306	DOVETAIL BODY SIDE	TATA spare parts

551773306307	REAR DOOR TOP COVER RH	TATA spare parts
551773306308	RR DR PRIMARY SEAL RH	TATA spare parts
551773700101	ASSY REAR DOOR PAD LH	TATA spare parts
551773700102	ASSY REAR DOOR PAD RH	TATA spare parts
551774506301	TAILGATE SEAL	TATA spare parts
551779200101	ASSY. CANOPY COMPLETE BS3/4	TATA spare parts
551779200103	CANOPY ASSY LH	TATA spare parts
551779200104	CANOPY ASSY RH	TATA spare parts
551779200105	CANOPY ASSY T/G	TATA spare parts
551779200109	ASSY CANOPY COMPLETE_DOORLESS	TATA spare parts
551781006301	MAGIC IRIS CNG DECALS LH	TATA spare parts
551781006302	MAGIC IRIS CNG DECALS RH	TATA spare parts
551781100109	ASSY ORVM BLANK COVER LH	TATA spare parts
551781100110	ASSY. ORVM DOOR MTG LH BS2/3/4	TATA spare parts
551781100111	ASSY. ORVM DOOR MTG RH BS2/3/4	TATA spare parts
551781100112	ASSY IRVM	TATA spare parts
551781100113	ASSY ORVM LH PILLAR MTD	TATA spare parts
551781100114	ASSY ORVM RH PILLAR MTD	TATA spare parts
551781100116	ASSY FRONT EMBLEM	TATA spare parts
551781100124	ORVM ASSY LH	TATA spare parts
551781100135	ASSY FUEL FILLAR COVER IRIS CNG	TATA spare parts
551781100138	MUDFLAP ASSY FRONT-LH	TATA spare parts
551781100139	MUDFLAP ASSY FRONT-RH	TATA spare parts
551781100140	KEY ASSY WITH TAG BS6	TATA spare parts
551781100142	ORVM ASSY RH	TATA spare parts
551781106314	SEAL SEAT PAN	TATA spare parts
551781106315	SEAL_AIR FILTER COVER	TATA spare parts
551781106317	SEAL STARTER MOTOR COVER	TATA spare parts
551781106318	A PILLAR CORNER INNER COVER LH	TATA spare parts
551781106319	A PILLAR CORNER INNER COVER RH	TATA spare parts
551781106320	SEAT REAR SEAL SIDE SUPPORT	TATA spare parts
551781106325	SEAL AIR FILTER COVER	TATA spare parts
551781106326	SEAL STARTER MOTOR COVER	TATA spare parts
551781106331	REAR REFLECTIVE TAPE_RED	TATA spare parts
551781106332	FRONT REFLECTIVE TAPE_WHITE	TATA spare parts
551781106333	REAR SEAT SIDE SUPPORT PAD RH	TATA spare parts
551781106335	CAP FOR AIR INTAKE PROVISION HOLES	TATA spare parts
551781106338	SEAL BATTERY TRAY	TATA spare parts
551781207701	RUBBER SEAL-MAGIC CNG	TATA spare parts
551781806301	MASCOT-IRIS	TATA spare parts
551781806302	MASCOT ZIP	TATA spare parts
551781906306	TOOL KIT HOLDIG STRAP	TATA spare parts
551781906309	PLUG BUTTON FOR 8 X 12 SLOT	TATA spare parts
551781906311	GROMMET FOR HOLE DIA 17	TATA spare parts
551781906312	GROMMET FOR HOLE DIA 18	TATA spare parts
551781906313	GROMMET FOR HOLE DIA 11	TATA spare parts
551782400102	ASSY ARM	TATA spare parts

551782400103	ASSY BLADE	TATA spare parts
551782400105	ASSY WIPER LINKAGES	TATA spare parts
551782400107	ASSY WIPER MOTOR SYSTEM COMPLETE	TATA spare parts
551782400108	ASSY_WIPER_ARM_BLADE_WITH_NOZZLE	TATA spare parts
551782400111	ASSY WIPER_ARM_BLADE_WITH NOZZLE	TATA spare parts
551782400112	KIT ASSY WASHER BOTTLE	TATA spare parts
551782400113	ASSY WIPER MOTOR SYSTEM	TATA spare parts
551782400115	ASSY ARM	TATA spare parts
551782400116	ASSY BLADE	TATA spare parts
551782400117	ASSY WIPER ARM BLADE WITHOUT NOZZLE	TATA spare parts
551782400118	ASSY WIPER MOTOR SYSTEM RHD COMPLETE	TATA spare parts
551782400122	ASSY WIPER MOTOR SYSTEM ZIP LHD	TATA spare parts
551782403302	BRACKET_WIPER	TATA spare parts
551782409901	ASSY_WIPER_MOTOR	TATA spare parts
551782409902	NOZZLE	TATA spare parts
551782409903	NOZZLE KIT	TATA spare parts
551782409904	TUBE L CONNECTOR TO NOZZLE	TATA spare parts
551782409905	MOUNTING BRACKET	TATA spare parts
551782409906	CHANNEL LONK MOULDING	TATA spare parts
551782409907	SPINDLE UNIT ASSLY	TATA spare parts
551782409908	ROTARY LINK ASSEMBLY	TATA spare parts
551782409909	PIVOT COVER	TATA spare parts
551782409910	HEX NUT M18X1.0	TATA spare parts
551782409911	CUP WASHER	TATA spare parts
551782409913	ARM NUT M8X1.5	TATA spare parts
551782409914	GEAR BOX BRUSHPLATE AND ARMATURE ASSY	TATA spare parts
551782409916	COVER PLATE AND BRUSHBOX ASSY	TATA spare parts
551782409917	GEAR AND SLIP RING ASSY	TATA spare parts
551782409918	FASTNERS AND SEAL KIT	TATA spare parts
551782409919	MOTOR ASSY WIPER	TATA spare parts
551782409920	LINK ASSY WIPER	TATA spare parts
551782409921	BOLT W/WASHER	TATA spare parts
551782409922	BOLT M6X20	TATA spare parts
551782409923	WASHER	TATA spare parts
551782409924	CAP	TATA spare parts
551782409925	HEX NUT M8X1	TATA spare parts
551782409926	WASHER W/PACKING	TATA spare parts
551782409927	HEX FLANGE NUT M8X1.25	TATA spare parts
551782409928	WIPER MOTOR ASSY	TATA spare parts
551782900101	KIT ASSY WASHER SYSTEM LHD WITH EMI/EMC	TATA spare parts
551782900104	KIT ASSY WASHER SYSTEM IRIS RHD WITHOUT	TATA spare parts
551782906301	WASHER BOTTLE	TATA spare parts
551782906302	FILLER NECK	TATA spare parts
551782906303	L CONNECTOR FOR WASHER TUBE	TATA spare parts
551782906901	PIPE FROM FILLER NECK TO WASHER BOTTLE	TATA spare parts
551782906902	WASH TUBE IRIS LHD	TATA spare parts
551782907701	FILLER NECK CAP	TATA spare parts

551782907702	GASKET FOR L CONNECTOR	TATA spare parts
551783100101	ASSY VENTILATION DUCT COMPLETE LH	TATA spare parts
551783100102	ASSY VENTILATION DUCT COMPLETE RH	TATA spare parts
551783100107	ASSY GRILL COMPLETE	TATA spare parts
551783100113	RH AIR VENT	TATA spare parts
551783106303	VENTILATION_DUCT_INSIDE_LH	TATA spare parts
551783106304	VENTILATION_DUCT INSIDE RH	TATA spare parts
551783106305	GASKET VENTILATION DUCT	TATA spare parts
551783106311	CENTRAL DUCT-ACE IRIS	TATA spare parts
551783106313	GRILL VENTILATION FIXED LOOVERS	TATA spare parts
551783106314	LH AIR VENT	TATA spare parts
551783500118	ASSY PCT HEATER	TATA spare parts
551783500127	ASSY BKT BLOWER MTG	TATA spare parts
551783503303	BKT HEATER CASING MTG	TATA spare parts
551783506301	CASING HEATER-1	TATA spare parts
551783506302	CASING HEATER-2	TATA spare parts
551783506303	ADAPTOR PTC HEATER	TATA spare parts
551783506305	DUCT AIR INTAKE	TATA spare parts
551783506306	DUCT OUTLET RH SIDE	TATA spare parts
551783506307	VENTILATION DUCT RH	TATA spare parts
551783507701	FOAM HEATER CASING-1	TATA spare parts
551783507702	FOAM HEATER CASING-2	TATA spare parts
551783606301	CROSS LINK FOAM VENTILATION DUCT	TATA spare parts
551788100103	ASSY BEZEL LH	TATA spare parts
551788100103BF	ASSY BEZEL LH	TATA spare parts
551788100103BN	ASSY BEZEL LH	TATA spare parts
551788100103BU	JET BLACK-ASSY BEZEL LH	TATA spare parts
551788100103FD	SK GOLDEN YELLOW-ASSY BEZEL LH	TATA spare parts
551788100103HO	NEON RUSH-ASSY BEZEL LH	TATA spare parts
551788100103HS	LASER RED - ASSY BEZEL LH	TATA spare parts
551788100103IH	ICY BLUE-ASSY BEZEL LH	TATA spare parts
551788100103IP	SUNRISE ORANGE - ASSY BEZEL LH	TATA spare parts
551788100104	ASSY BEZEL RH	TATA spare parts
551788100104BF	ASSY BEZEL RH	TATA spare parts
551788100104BN	ASSY BEZEL RH	TATA spare parts
551788100104BU	JET BLACK-ASSY BEZEL RH	TATA spare parts
551788100104FD	SK GOLDEN YELLOW-ASSY BEZEL RH	TATA spare parts
551788100104HO	NEON RUSH-ASSY BEZEL RH	TATA spare parts
551788100104HS	LASER RED - ASSY BEZEL RH	TATA spare parts
551788100104IH	ICY BLUE-ASSY BEZEL RH	TATA spare parts
551788100104IP	SUNRISE ORANGE - ASSY BEZEL RH	TATA spare parts
551788100105	ASSY FENDER LH	TATA spare parts
55178810010535	FENDER ASSY LH	TATA spare parts
551788100106	ASSY FENDER RH	TATA spare parts
55178810010635	FENDER ASSY RH	TATA spare parts
551788106303	FRT EXTENSION FENDER_LH	TATA spare parts
551788106304	FRT FENDER EXTENSION_RH	TATA spare parts



551788200101	ASSY GUARD RR WHEEL COMPLETE GC	TATA spare parts
551788500101	ASSY IMPACT BEAM FRONT BUMPER	TATA spare parts
551788500108	ASSY. FASCIA FRT BUMPER W/O FOG BS2/3/4	TATA spare parts
551788500114	ASSY. FRONT IMPACT BEAM BS2/3/4	TATA spare parts
551788506302	SIDE SUPPORT FRONT BUMPER LH	TATA spare parts
551788506303	SIDE SUPPORT FRONT BUMPER RH	TATA spare parts
551788506304	COVER TOWING HOOK	TATA spare parts
551788506306	BEZEL FRONT REFLEX REFLECTOR;LH	TATA spare parts
551788506307	BEZEL FRONT REFLEX REFLECTOR;RH	TATA spare parts
551788600108	ASSY FACIA REAR BUMPER COMPLETE WITHOUT	TATA spare parts
551788606302	COVER TOWING HOOK	TATA spare parts
551788606311	COVER TOWING HOOK GC	TATA spare parts
551791000102	ASSY DRIVER SEAT WITH HEAD REST PC	TATA spare parts
551791000107	ASSY DRIVER SEAT PC	TATA spare parts
551791000108	ASSY FRONT BENCH SEAT	TATA spare parts
551791000109	ASSY WELDED DRIVER SEAT FRAME COMPLETE	TATA spare parts
551791000110	ASSY DRIVER FSB FOAM PAD PC	TATA spare parts
551791000111	ASSY DRIVER FSC FOAM PAD PC	TATA spare parts
551791000112	ASSY WELDED SLIDER SET WITH MTG BKT	TATA spare parts
551791000117	ASSY BACK COMPLETE	TATA spare parts
551791000118	ASSY DRIVER SEAT CUSHION WITHOUT TRACK	TATA spare parts
551791000120	ASSY CO-DRIVER SEAT CUSHION COMPLETE	TATA spare parts
551791003301	PLASTIC CAP UPPER MTG BRACKET	TATA spare parts
551791009901	TOREX HEAD M8 X15L BOLT	TATA spare parts
551791009905	WASHER 8.5	TATA spare parts
551791500101	ASSY FRONT SEAT BELT WITH ELR	TATA spare parts
551791500102	ASSY FRONT SEAT BELT KIT FOR FIX CO-DRIV	TATA spare parts
551791500104	ASSY ELR UNIT RH	TATA spare parts
551791500105	ASSY TWIN BUCKLE FOR FIX CO DRIVER SEAT	TATA spare parts
551791500107	ASSY FRONT SEAT BELT KIT FOR FIX CO-DRIV	TATA spare parts
551791500108	ASSY ELR UNIT RH	TATA spare parts
551791500109	ASSY TWIN BUCKLE FOR FIX CO DRIVER SEAT	TATA spare parts
551791500113	KIT ASSY DRIVER SEAT BELT (3+D)	TATA spare parts
551791500115	ASSY SINGLE BUCKLE FOR DRIVER SEAT(D+3)	TATA spare parts
551792000101	ASSY REAR SEAT	TATA spare parts
551792000103	ASSY REAR BENCH SEAT	TATA spare parts
551792000107	ASSY WELDED RSB COMPLETE	TATA spare parts
551792000108	ASSY RSB FOAM PAD PC 1230	TATA spare parts
551792000109	ASSY RSB FOAM PAD	TATA spare parts
551792000110	ASSY REAR SEAT BENCH	TATA spare parts
551792000120	ARM REST ASSY COMPLETE	TATA spare parts
551792003301	TOP SUPPORT BKT	TATA spare parts
551792003302	LOWER HINGE MTG BKT	TATA spare parts
551792009901	TOREX HEAD M8 X 15L BOLT	TATA spare parts
551792009902	M8 STEP BOLT	TATA spare parts
551792009903	DELTRIN BUSH -FRONT HINGE	TATA spare parts
551792009904	M8 NYLOC NUT	TATA spare parts

551792009905	WASHER 8.5	TATA spare parts
551792500101	ASSY REAR SEAT LAP BELT KIT(3P)	TATA spare parts
551792500103	ASSY REAR SEAT LAP BELT KIT(3P)	TATA spare parts
551792500104	ASSY REAR SEAT LAP BELT KIT	TATA spare parts
551792500105	ASSY REAR LAP BELT	TATA spare parts
551792500106	ASSY REAR TWIN BUCKLE	TATA spare parts
551792500107	ASSY LAP PLUS BUCKLE	TATA spare parts
551792500108	ASSY REAR SEAT LAP BELT KIT(3P)	TATA spare parts
551794000102	ASSY CO DRIVER SEAT WITH HEAD REAST	TATA spare parts
551794000105	ASSY CO-DRIVER SEAT PC	TATA spare parts
551794000106	ASSY WELDED CO-DRIVER SEAT FRAME STRUCTU	TATA spare parts
551794000107	ASSY DRIVER FSC FOAM PAD PC	TATA spare parts
551794000108	ASSY DRIVER FSB FOAM PAD PC	TATA spare parts
551794500102	ASSY ELR UNIT LH	TATA spare parts
551794500103	ASSY ELR UNIT LH	TATA spare parts
551799000101	ASSY SPARE WHEEL KNOB	TATA spare parts
551799005601	KNOB M6	TATA spare parts
551799506301	SEAT SEAL MTG CLIP	TATA spare parts
551799506308	PLASTIC CAP FOR SLOT 10 X 14	TATA spare parts
551799506309	PLASTIC CAP FOR SLOT 16 X 12	TATA spare parts
551799506310	PLASTIC CAP FOR SLOT 16 X 20	TATA spare parts
551799506313	CLIP M6 WELD NUT	TATA spare parts
551799506314	CLIP M8 WELD NUT	TATA spare parts
551799506315	CAP DIA 16 HOLE	TATA spare parts
551799506316	CAP DIA 10 HOLE	TATA spare parts
551799506317	CAP DIA 12 HOLE	TATA spare parts
551799506318	CAP DIA 8 HOLE	TATA spare parts
551924203701	BKT ENGINE MOUNTING REAR RH (F/W HSG)	TATA spare parts
551924203702	BKT ENGINE MOUNTING REAR LH (F/W HSG)	TATA spare parts
551928500104	ASSY AGB MOUNTING BRACKET LOWER LH	TATA spare parts
551928500105	ASSY AGB MOUNTING BRACKET LOWER RH	TATA spare parts
551928500110	ASSY MTG BRACKET (LH) (AGB 3RD MOUNTING)	TATA spare parts
551928500111	ASSY MOUNTING BRACKET (RH) (AGB 4TH MOUN	TATA spare parts
551928500113	ASSY ADJSUTABLE STAY ROD-AGB MTG LOWER	TATA spare parts
551928500121	AGB MOUNTING BKT ASSY RH TOP	TATA spare parts
551928500122	AGB MOUNTING BKT ASSY LH TOP	TATA spare parts
551928507105	BASE PLATE AGB MTG.	TATA spare parts
551928900115	ASSY OIL COOLER HOSE (OC TO TC)	TATA spare parts
551928900116	ASSY. OIL COOLER HOSE (TC TO OC)	TATA spare parts
551928903401	ELBOW CONNECTOR CM22X1.5 (MPV)	TATA spare parts
551928903402	ELBOW BODY CM 22X1.5 (MPV)	TATA spare parts
551928908103	OIL COOLER MOUNTING BRACKET	TATA spare parts
551928908104	OIL COOLER MOUNTING BRACKET	TATA spare parts
551928908105	OIL COOLER MOUNTING BRACKET AT TC END	TATA spare parts
551929000101	INTEGRAL PEDAL UNIT (IPU) FOR MPV	TATA spare parts
551929000103	INTEGRATED PEDAL UNIT	TATA spare parts
551929100104	ASSY. CLUTCH BOOSTER HOSE	TATA spare parts

551929100105	HYD PIPE ASSY (CLUTCH BOOSTER)	TATA spare parts
551931000101	ASSEMBLY FRAME.	TATA spare parts
551931000103	ASSEMBLY FRAME (MPV LHD)	TATA spare parts
551931200102	ASSY CROSS MEMBER WITH ROLLER MOUNTING	TATA spare parts
551931200105	ASSY SUPPORT(ENGINE CM FRONT)	TATA spare parts
551931300101	ASSY FRAME MOUNTING BRACKET - 1	TATA spare parts
551931300102	ASSY FRAME MOUNTING BRACKET-2	TATA spare parts
551931500101	LIFTING HOOK ASSY	TATA spare parts
551931705301	BALATA PACKING	TATA spare parts
551932100103	ASSY FIRST LEAF WITH BUSH	TATA spare parts
551932100103DF	MAIN LEAF FRONT/REAR W/BUSH - MPV	TATA spare parts
551932100104	ASSY LEAF SPRING	TATA spare parts
551932100105	ASSY SPRING SHACKLE	TATA spare parts
551932103201	CENTRE BOLT	TATA spare parts
551932103301	SPRING HANGER BRKT FRONT-RH	TATA spare parts
551932103302	SPRING HANGER BRKT (FRONT)	TATA spare parts
551932103701	SPRING SHACKLE (FRONT & REAR SPRING)	TATA spare parts
551932107104	SECOND LEAF	TATA spare parts
551932107105	THIRD LEAF	TATA spare parts
551932107106	FOURTH LEAF	TATA spare parts
551932107107	FIFTH LEAF	TATA spare parts
551932107108	SIXTH LEAF	TATA spare parts
551932107109	SEVENTH LEAF	TATA spare parts
551932107110	EIGHTH LEAF	TATA spare parts
551932203701	GUIDE PLATE	TATA spare parts
551932208601	SPACER (GUIDE PLATE)	TATA spare parts
551932300101	ASSY SHOCK ABSORBER BRKT LOWER-LH	TATA spare parts
551932300102	ASSY SHOCK ABSORBER BRKT LOWER-RH	TATA spare parts
551932400101	ASSY SPRING HANGER BRKT (REAR)	TATA spare parts
551932403305	SPRING HANGER BRACKET (REAR)	TATA spare parts
551932403308	SPRING HANKER BKT-LH	TATA spare parts
551932403309	SPRING HANKER BKT-RH	TATA spare parts
551932600103	ASSY SHOCK ABSORBER BRACKET REAR LOWER-L	TATA spare parts
551932600104	ASSY SHOCK ABSORBER BRACKET REAR LOWER-R	TATA spare parts
551932608601	SPACER	TATA spare parts
551932800101	ASSY LINK- ANTIROLL BAR	TATA spare parts
551932800103	ASSY ANTIROLL BAR(CRIMPED)	TATA spare parts
551932800113	ASSY ARB MTG LINK	TATA spare parts
551932803401	BUSH HALF (TOP)	TATA spare parts
551932803402	BUSH HALF (BOTTOM)	TATA spare parts
551940100101	ASSY. WHEEL RIM	TATA spare parts
551940100104	WHEEL ASSY. WITH RUNFLAT SYSTEM	TATA spare parts
551940106302	RADIAL TYRE SIZE/TYPE 14.00R20 ML	TATA spare parts
551940107701	WHEEL RUBBER SEAL	TATA spare parts
551940109901	VALVE-V3-14-2	TATA spare parts
551940300107	PULLEY ASSEMBLY	TATA spare parts
551940300108	ASSY SPARE WHEEL MOUNTING	TATA spare parts

551940300109	ASSY LIFTING ARM COMPLETE	TATA spare parts
551940300111	ROPE GUIDE ASSY	TATA spare parts
551940300113	SPARE WHEEL WINCH SPANNER	TATA spare parts
551940300114	ASSY MOUNTING BRACKET PULLEY	TATA spare parts
551940300134	BRACKET ASSY (PULLEY MTG)	TATA spare parts
551940300135	BRACKET ASSY (ROPE GUIDE)	TATA spare parts
551940308201	COVER PLATE	TATA spare parts
551940309902	DYNEEMA SPARE WHEEL LIFTING ROPE	TATA spare parts
551940309904	DYNEEMA SAFETY ROPE	TATA spare parts
551941000107	ASSY PROP SHAFT- TC TO FA	TATA spare parts
551941000108	ASSY PROP SHAFT- TC TO RA	TATA spare parts
551941000109	ASSY-PROPELLER SHAFT- GB TO TC	TATA spare parts
551941000113	ASSY-PROPELLER SHAFT- GB TO TC	TATA spare parts
551941000114	ASSY PROP SHAFT- TC TO FA	TATA spare parts
551941000115	ASSY PROP SHAFT- TC TO RA	TATA spare parts
551941115101	FLANGE YOKE	TATA spare parts
551941115102	UNIT PACK	TATA spare parts
551941115103	FLANGE YOKE	TATA spare parts
551941115104	UNIT PACK	TATA spare parts
551942103401	SENSOR BUSH ( FOR ABS AT FRONT)	TATA spare parts
551942103401AE	SENSOR BUSH ( ABS AT FRT) -1628	TATA spare parts
551942103701	BRAKE DRUM-FRONT	TATA spare parts
551942309901	POLE WHEEL-REAR (120 TEETH FOR RA109RR)	TATA spare parts
551943206801	ADAPTER PRESSURE TRANSDUCER	TATA spare parts
551943700112	BRACKET ASSY HAND BRAKE VALVE MTG RH	TATA spare parts
551943703303	BRACKET-LH (FRONT PALM COUPLING MTG.)	TATA spare parts
551943703304	BRACKET-RH(FRONT PALM COUPLING MTG.)	TATA spare parts
551943707501	GROMMET	TATA spare parts
551943900123	ASSY. METAL PIPE AIR DRIER TO COUPLING B	TATA spare parts
551943900124	ASSY. METAL PIPE COUPLING TO HOSE	TATA spare parts
551943900129	ASSY. METAL PIPE WITH CRIMPED HOSE	TATA spare parts
551943900152	ASSY. METAL PIPE TEE 2 TO BRAKE ACT. LH	TATA spare parts
551943900153	ASSY. METAL PIPE TEE 2 TO BRAKE ACT. RH	TATA spare parts
551943900154	ASSY. METAL PIPE PALM COUPLING TO ADAPTO	TATA spare parts
551943900155	ASSY. METAL PIPE PALM COUPLING TO ADAPTO	TATA spare parts
551943900165	ASSY. NYLON PIPE SET COMPL-	TATA spare parts
551943900172	ASSY. NYLON PIPE SET COMPLET FOR MPV (LH	TATA spare parts
551943900176	PIPE ASSY	TATA spare parts
551943903304	BRACKET-METAL PIPE CLAMPING-1ST METAL PI	TATA spare parts
551943903305	BRACKET-METAL PIPE CLAMPING-1ST METAL PI	TATA spare parts
551943903306	BRACKET-METAL PIPE CLAMPING-1ST METAL PI	TATA spare parts
551943904201	CLAMP (DIA. 18 PIPE) BS6	TATA spare parts
551945300101	SOLENOID VALVE BS1/2/3/4	TATA spare parts
551945900105	ASSY. SUPPORT PLATE FOR SOLENOID VALVES	TATA spare parts
551945906801	ADAPTOR - EXHAUST BRAKE TO SOLENOID VALV	TATA spare parts
551945907103	SUPPORT PLATE FOR SOLENOID VALVES	TATA spare parts
551946000104	ASSY. DRAGLINK	TATA spare parts

551946100101	ASSY STEERING GEAR BOX MTG. BRACKET	TATA spare parts
551946100104	STEERING GEAR BOX MTG. BRACKET	TATA spare parts
551946108001	HEX SCREW	TATA spare parts
551946200102	ASSY. STEERING SPINDLE	TATA spare parts
551946203101	SPERICAL SUPPORT STG. SPINDLE	TATA spare parts
551946207901	STEERING SPINDLE (MIDDLE)	TATA spare parts
551946208201	BRACKET (STG. SPINDLE SPH. SUPPORT)	TATA spare parts
551946300101	ASSY. TIE ROD	TATA spare parts
551946300104	TABLE DRW FOR ASSY.TIE ROD MTG ARM- LH	TATA spare parts
551946300105	ASSY.TIE ROD MOUNTING ARM- RH	TATA spare parts
551946300108	TIE ROD ASSY	TATA spare parts
551946306001	PITMAN ARM	TATA spare parts
551946306002	STEERING ARM (TOP)	TATA spare parts
551946600101	ASSY. POWER STEERING GEAR BOX	TATA spare parts
551946600102	ASSY.STEERING RESERVOIRç MTG. BRACKET	TATA spare parts
551946600107	PISTON ASSY	TATA spare parts
551946600109	VALVE INSERT ASSY BS6-PH2	TATA spare parts
551946700101	ASSY. BRACKET	TATA spare parts
551946703301	BRACKET	TATA spare parts
551946800101	ASSY. SUCTION LINE	TATA spare parts
551946800102	ASSY. HIGH PRESSURE LINE	TATA spare parts
551946800103	ASSY. HIGH PRESSURE LINE	TATA spare parts
551946800104	ASSY. RETURN LINE	TATA spare parts
551946800105	ASSY RETURN LINE	TATA spare parts
551946800112	ASSY.HIGH PRESSURE LINE	TATA spare parts
551946800114	ASSY.RETURN LINE-1	TATA spare parts
551946800119	HOSE ASSY HIGH PRESSRE	TATA spare parts
551946800120	RETURN LINE ASSY (STG. G.BOX TO TANK)	TATA spare parts
551946900101	DRAG LINK END ASSY RH	TATA spare parts
551947100101	ASSY FUEL TANK COMPLETE 300 LTR	TATA spare parts
551947108224	THREADED ADAPTER (HOSE ASSY AT OTHER END)	TATA spare parts
551947500101	ASSY OF STRAP	TATA spare parts
551947507701	RUBBER PACKING	TATA spare parts
551947507702	RUBBER PACKING	TATA spare parts
551947600112	ASSY-SUCTION LINE W/S TO ENGINE	TATA spare parts
551947600113	ASSY-RETURN FUEL ENGINE TO F/TANK	TATA spare parts
551947600116	ASSY-SUCTION LINE-1 FT TO W/S	TATA spare parts
551947600117	ASSY-SUCTION LINE 2 FT TO W/S	TATA spare parts
551947600122	ASSY FUEL PIPE MTG BRACKET	TATA spare parts
551947600123	ASSY L-CHANNEL (FUEL LINE SUPPORT)	TATA spare parts
551947603313	BRKT-FUEL LINE	TATA spare parts
551947605801	HOSE FOR FUEL NECK	TATA spare parts
551947606703	PIN	TATA spare parts
551947606802	VOSS ADAPTOR M12X1.5	TATA spare parts
551947606915	BREATHER CONNECTING PIPE	TATA spare parts
551949100102	ASSY HEAT SHIELD (FOR EXHAUST MANIFOLD)	TATA spare parts
551949200102	EXHAUST PIPE ASSY. FROM ELBOW TO EXHAUST	TATA spare parts

551949200104	EXHAUST PIPE ASSY. FROM EXHAUST BRAKE TO	TATA spare parts
551949200105	EXHAUST PIPE ASSY. FROM RIGID MTG. TO OV	TATA spare parts
551949200106	EXH. PIPE MTG. BKT. ASSY (TOP)	TATA spare parts
551949200107	ASSY. TAIL PIPE	TATA spare parts
551949200108	EXHAUST PIPE ASSY. FROM OVERLAP JOINT TO	TATA spare parts
551949200118	EXHAUST PIPE ASSY	TATA spare parts
551949200125	FRONT PIPE ASSY	TATA spare parts
551949200126	BRACKET ASSY EGP MTG	TATA spare parts
551949200128	STRAP ASSY UREA TANK MTG	TATA spare parts
551949200132	ASSY EXHAUST PIPE FRONT	TATA spare parts
551949200133	ASSY EXHAUST PIPE (FOOT STEP TO MUFFLER)	TATA spare parts
551949200134	ASSY TAIL PIPE	TATA spare parts
551949200135	ASSY MUFFLER MTG BRACKET FRONT	TATA spare parts
551949200136	ASSY MUFFLER MTG BRACKET REAR	TATA spare parts
551949200141	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
551949200143	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
551949203303	BRACKET	TATA spare parts
551949206908	EXHAUST PIPE - VI	TATA spare parts
551949206923	EXHAUST TAIL PIPE	TATA spare parts
551949207101	ENGINE ELBOW MTG. BKT.	TATA spare parts
551949600101	BRACKET ASSY HEAT SHIELD MTG	TATA spare parts
551949600102	HEAT SHIELD ASSY	TATA spare parts
551949608201	HEAT SHIELD EXHAUST	TATA spare parts
551949990101	EXHAUST PIPE INSULATION KIT	TATA spare parts
551949990103	ASSY EXHAUST PIPE INSULATION MPV LHD	TATA spare parts
551954100103	ASSY BATTERY TRAY	TATA spare parts
551954100142	ASSY.BATTERY CABLE +VE(CUT OFF SW TO SM)	TATA spare parts
551954100149	ASSY.BATT.CABLE JUMP START PLUG	TATA spare parts
551954106301	PLASTIC BATTERY TRAY	TATA spare parts
551954106303	DRAIN PIPE BATTERY TRAY	TATA spare parts
551954108208	C-CANNEL(EXTERNAL BATTERY TRAY SUPPORT.)	TATA spare parts
551954109904	BATTERY 12V 160AH (BR140)	TATA spare parts
551954150101	ASSY.BATTERY CABLE POSITIVE(BATT TO CUT	TATA spare parts
551954150102	ASSY.BATTERY CABLE NEGATIVE MPV	TATA spare parts
551954150103	ASSY.BATTERY CABLE POSITIVE(CUT OFF SW T	TATA spare parts
551954150104	ASSY.BATTERY CABLE LINK	TATA spare parts
551954209904	AIR PRESSURE TRANSDUCER	TATA spare parts
551954249901	FLOAT UNIT	TATA spare parts
551954249906	24V 50A MAXI NOR RELAY	TATA spare parts
551954400106	ASSY H/L E CERT 24V BULB LH RHD	TATA spare parts
551954400107	ASSY HEAD LAMP RH	TATA spare parts
551954408202	ROOF_MOUNTING_SEARCHLAMP	TATA spare parts
551954440105	ASSY.REGISTRATION PLATE LAMP 24V	TATA spare parts
551954500104	ASSY SW PLATE	TATA spare parts
551954503302	BRACKET	TATA spare parts
551954506301	FUSE_BOX_COVER	TATA spare parts
551954506303	HIGH LOW PIANO SWITCH FOR TRANSFER CASE	TATA spare parts

551954506304	NEUTRAL PIANO SWITCH FOR TRANSFER CASE C	TATA spare parts
551954600112	WIRING HARNESS DASHBOARD	TATA spare parts
551954600113	WIRING HARNESS ROOF FRONT	TATA spare parts
551954600115	ABS FRAME WIRING HARNESS MPV	TATA spare parts
551954600118	ASSY MTG. BKT. FOR HORN	TATA spare parts
551954600120	ASSY C CHANNEL REAR	TATA spare parts
551954600121	ASSY C CHANNEL REAR (SMALL)	TATA spare parts
551954600123	ASSY C CHANNEL FRONT	TATA spare parts
551954600125	ASSY BKT FOR RELAY MTG	TATA spare parts
551954600126	ASSY BRACKET FOR ABS WH MTG	TATA spare parts
551954600140	WIRING HARNESS ABS	TATA spare parts
551954600145	WIRING HARNESS BUMPER	TATA spare parts
551954600148	WIRING HARNESS TAIL LAMP LH	TATA spare parts
551954600149	WIRING HARNESS ROOF REAR	TATA spare parts
551954600150	WIRING HARNESS TAIL	TATA spare parts
551954600151	WIRING HARNESS MAIN	TATA spare parts
551954600152	WIRING HARNESS DOSING UNIT	TATA spare parts
551954600154	WIRING HARNESS ENGINE	TATA spare parts
551954600155	WIRING HARNESS ROOF MIDDLE	TATA spare parts
551954600157	WIRING HARNESS TAIL LAMP RH	TATA spare parts
551954608202	SUPPORT BKT. FOR AUTO TRAN.WH	TATA spare parts
551954608203	BRACKET ROOF WH SUPPORT BS6	TATA spare parts
551954608219	FLOOR MOUNTED BKT(FOR ROOF WIRING HARNE	TATA spare parts
551954608224	TWISTED BRACKET FOR WIRING HARNESS MTG	TATA spare parts
551954608239	L BRACKET MPV LHD BS6-PH2	TATA spare parts
551954620120	WIRING HARNESS DASH	TATA spare parts
551954620122	WIRING HARNESS ENGINE	TATA spare parts
551954620124	WIRING HARNESS ROOF FRONT	TATA spare parts
551954660101	WIRING HARNESS MAIN MPV	TATA spare parts
551954660102	WIRING HARNESS TAIL MPV	TATA spare parts
551954660103	WH ENGINE MPV	TATA spare parts
551954660105	WIRING HARNESS ROOF MPV	TATA spare parts
551954660106	WIRING HARNESS SWITCH MPV	TATA spare parts
551954660107	WIRING HARNESS ROOF MIDDLE MPV	TATA spare parts
551954660108	WIRING HARNESS ROOF REAR MPV	TATA spare parts
551954660109	WIRING HARNESS TAIL RH MPV	TATA spare parts
551954660110	WIRING HARNESS TAIL LH MPV	TATA spare parts
551954660111	WIRING HARNESS BUMPER RH MPV	TATA spare parts
551954660112	WIRING HARNESS BUMPER LH MPV	TATA spare parts
551954660113	MAP READING LAMP PIGTAIL	TATA spare parts
551954660113AE	MAP READING LAMP PIGTAIL 1628	TATA spare parts
551954660114	PLUG SOCKET PIGTAIL	TATA spare parts
551954660114AE	PLUG SOCKET PIGTAIL 1628	TATA spare parts
551954660121	WIRING HARNESS MAIN	TATA spare parts
551954660123	WIRING HARNESS TAIL	TATA spare parts
551954680111	WIRING HARNESS BUMPER LH	TATA spare parts
551954680112	MAP READING LAMP PIGTAIL M/S SAN ELECTRO	TATA spare parts

551954829902	PIPE	TATA spare parts
551954829903	WASHER PUMP	TATA spare parts
551954829906	CAP SEAL	TATA spare parts
551954829907	ELBOW CONNECTOR	TATA spare parts
551954829909	RUBBER GROMMET	TATA spare parts
551954829911	T-CONNECTOR	TATA spare parts
551955100101	ASSY T EMBLEM	TATA spare parts
551958300101	HYDRAULIC JACK ASSY	TATA spare parts
551958902625	GEAR BOX GB600 TROLLEY	TATA spare parts
551960000102	ASSY HULL PAINTED RHD	TATA spare parts
551961200103	ASSY CROSS MEMBER REAR FLOOR	TATA spare parts
551961608213	COVER PLATE FLOOR FRT	TATA spare parts
551961800119	ASSY REAR FLOOR CTR EXTREME	TATA spare parts
551962600105	ASSY ECU MTG PLATE	TATA spare parts
551967100108	ASSY WINDSHIELD MTG FRAME	TATA spare parts
551967102301	WINDSHIELD GLASS BS3/4	TATA spare parts
551967102302	SIDE DOOR WINDOW GLASS LH	TATA spare parts
551967102304	REAR DOOR WINDOW GLASS	TATA spare parts
551967102305	SIDE DOOR WINDOW GLASS RH	TATA spare parts
551967102306	SIDEWALL WIND. GLASS-GUN PORT HOLE BS3/4	TATA spare parts
551967102314	SIDE DOOR WINDOW GLASS LH LHD	TATA spare parts
551967102315	SIDE DOOR WINDOW GLASS RH LHD	TATA spare parts
551967107701	WINDSHIELD GLASS SEAL	TATA spare parts
551967107702	SIDE DOOR WINDOW GLASS SEAL	TATA spare parts
551967107704	REAR DOOR WINDOW GLASS SEAL	TATA spare parts
551967107705	SIDEWALL WINDOW GLASS SEAL	TATA spare parts
551967108201	SIDE DOOR WINDOW FRAME LH	TATA spare parts
551967108202	SIDE DOOR WINDOW FRAME RH	TATA spare parts
551967108205	SIDE WALL WINDOW FRAME	TATA spare parts
551967108206	REAR DOOR WINDOW FRAME	TATA spare parts
551968400101	ASSY CARPET FLOOR	TATA spare parts
551968400102	ASSY HEAT INSULATION TUNNEL BOTTOM	TATA spare parts
551968400103	ASSY UNDERBODY INSULATION FLOOR	TATA spare parts
551968400104	ASSY CARPET FLOOR LHD	TATA spare parts
551968400105	ASSY HEAT INSULATION TUNNEL BOTTOM LHD	TATA spare parts
551968400106	ASSY UNDERBODY INSULATION FLOOR LHD	TATA spare parts
551968700101	ASSY HEAT INSULATION FIREWALL INNER	TATA spare parts
551968700102	ASSY HEAT INSULATION FIREWALL OUTER	TATA spare parts
551968700103	ASSY HEAT INSULATION FIREWALL INNER LHD	TATA spare parts
551968700104	ASSY HEAT INSULATION FIREWALL OUTER LHD	TATA spare parts
551968900108	ASSY DASHBOARD CROSS CAR BEAM	TATA spare parts
551968900117	ASSY DASHBOARD LHD	TATA spare parts
551968906301	DASHBOARD MPV RHD	TATA spare parts
551969000102	ASSY KIT INTERIOR TRIM MPV	TATA spare parts
551969206301	GARNISH SIDE WALL WINDOW	TATA spare parts
551969506301	GARNISH ROOF HATCH	TATA spare parts
551969506302	GARNISH TURRET	TATA spare parts



551972200110	ASSY MINE LOCK HANDLE OUTER SA	TATA spare parts
551972200111	ASSY SIDE DOOR MINE LOCK BKT LH	TATA spare parts
551972200112	ASSY SIDE DOOR MINE LOCK BKT RH	TATA spare parts
551972300112	ASSY SIDE DOOR MINE LOCK SYSTEM RH SA	TATA spare parts
551972305605	MINE LOCK HANDLE INNER LH SA	TATA spare parts
551972305606	MINE LOCK HANDLE INNER RH SA	TATA spare parts
551972306001	SIDE DOOR LINK I SA	TATA spare parts
551972306002	SIDE DOOR LINK II SA	TATA spare parts
551972306003	SIDE DOOR LINK III SA	TATA spare parts
551972306004	SIDE DOOR LINK IV SA	TATA spare parts
551972306704	SIDE DOOR MINE LOCK PIN UPPER	TATA spare parts
551972306705	SIDE DOOR MINE LOCK PIN LOWER	TATA spare parts
551972306706	LINK HINGE PIN I	TATA spare parts
551972306707	LINK HINGE PIN II	TATA spare parts
551972306708	LINK HINGE PIN III	TATA spare parts
551972307701	SEAL PRIMARY LH	TATA spare parts
551972307702	SEAL PRIMARY RH	TATA spare parts
551972308222	MINE LOCK STOPPER SA	TATA spare parts
551972308225	BASE PLATE MINE LOCK STOPPER SA	TATA spare parts
551972320101	LOCK SET ASSY	TATA spare parts
551974300106	ASSY GRAB HANDLE REAR DOOR INNER	TATA spare parts
551974306003	REAR DOOR LINK I SA	TATA spare parts
551974306004	REAR DOOR LINK II SA	TATA spare parts
551974306005	REAR DOOR LINK III SA	TATA spare parts
551974306704	REAR DOOR MINE LOCK PIN LOWER	TATA spare parts
551974307701	SEAL PRIMARY REAR DOOR	TATA spare parts
551974308206	BUSH KEY COVER DOOR OUTER	TATA spare parts
551975100113	ASSY GAS SPRING MTG STRUCTURE BONNET	TATA spare parts
551975100118	BELL CRANK ASSY	TATA spare parts
551975100120	ASSY STAY ROD WITH WASHER FOR BONNET	TATA spare parts
551975107701	FRT GRILL SEAL	TATA spare parts
551975107702	BONNET LID SEAL LH	TATA spare parts
551975107703	BONNET LID SEAL RH	TATA spare parts
551975108232	LOCK HANDLE	TATA spare parts
551975108236	SPRING	TATA spare parts
551975108238	HATCH LOCK STRIKER	TATA spare parts
551975108248	BONNET LID GRILL	TATA spare parts
551975200103	ASSY GAS STRUT BONNET	TATA spare parts
551975200105	ASSY SECONDARY BONNET LOCK	TATA spare parts
551978200105	ASSY GAS STRUT ROOF HATCH	TATA spare parts
551978207701	ROOF HATCH SEAL	TATA spare parts
551981000102	ASSY HVAC COVER LH	TATA spare parts
551981000103	ASSY HVAC COVER RH	TATA spare parts
551981100102	ASSY REAR VIEW MIRROR LH	TATA spare parts
551981100103	ASSY REAR VIEW MIRROR RH	TATA spare parts
551981100104	ASSY ORVM SET MANUAL VERSION	TATA spare parts
551981106301	SEAL SECONDARY REAR DOOR	TATA spare parts

551981106302	SEAL SECONDARY	TATA spare parts
551981106304	GROMMET FIREWALL	TATA spare parts
551981106305	STICKER FOR SEAT BELT& HELMET IN ENGLISH	TATA spare parts
551981106306	STICKER FOR SEAT BELT & HELMET IN HINDI	TATA spare parts
551981106307	STICKER FOR MINE LOCK	TATA spare parts
551981106308	STICKER FOR GUN POART	TATA spare parts
551981106309	STICKER FOR LOCK	TATA spare parts
551981106310	STICKER FOR STAY ROD	TATA spare parts
551981106311	STICKER OF EMERGENCY EXIT	TATA spare parts
551981990101	ASSY KIT REFLECTIVE TAPE MPV	TATA spare parts
551981990103	KIT SURROGATE FLOOR	TATA spare parts
551982400104	TWO SPEED WIPER MOTOR 24V MPV	TATA spare parts
551982400105	ASSY MTG BKT WIPER MOTOR	TATA spare parts
551982400109	KIT WIPE AND WASH SYSTEM_MPV	TATA spare parts
551982400110	ASSY WASHER TANK	TATA spare parts
551982400114	KIT WIPE & WASH SYSTEM_MPV_LHD_ALMIGHTY	TATA spare parts
551982400122	WIPER MOTOR ASSY	TATA spare parts
551982408211	WIPER MOTOR MTG BKT LHD	TATA spare parts
551982408213	WIPER ARM LHD	TATA spare parts
551982409901	WIPER ARM	TATA spare parts
551982409902	WIPER BLADE	TATA spare parts
551983100101	ASSY_SIDE_DUCT_LH	TATA spare parts
551983100102	ASSY_SIDE_DUCT_RH	TATA spare parts
551983100110	ASSY_FRESH_AIR_DUCT_LH	TATA spare parts
551983100111	ASSY_FRESH_AIR_DUCT_RH	TATA spare parts
551983106330	FRESH AIR DUCT OUTSIDE	TATA spare parts
551983106340	DUCT_CONNECTING_DEFROST	TATA spare parts
551983300101	ASSY PUSH PULL CABLE BACK	TATA spare parts
551983300102	ASSY PUSH PULL CABLE FOR PLANUM CONTROL	TATA spare parts
551983400101	ASSY_AC_UNIT_LH_COMPLETE	TATA spare parts
551983400102	ASSY_AC_UNIT_RH_COMPLETE	TATA spare parts
551983400103	KIT_AC_MPV_24V	TATA spare parts
551983400104	ASSY_CONDENSER_COMPLETE	TATA spare parts
551983400106	ASSY_LIQUID_PIPE	TATA spare parts
551983400107	ASSY_DISCHARGE_PIPE	TATA spare parts
551983400108	ASSY_SUCTION_PIPE	TATA spare parts
551983400123	ASSY COVER FOR AC PIPE V BOTTOM	TATA spare parts
551983400144	MTG_BKT_DUCT	TATA spare parts
551983400146	ASSY_SUCTION_PIPE_LHD	TATA spare parts
551983400148	ASSY_LIQUID_PIPE_LHD	TATA spare parts
551983400203	ASSY_BLOWER_LH	TATA spare parts
551983400204	ASSY_BLOWER RH	TATA spare parts
551983400205	ASSY_CONNECTING_DUCT_LH	TATA spare parts
551983400206	ASSY_CONNECTING_DUCT_RH	TATA spare parts
551983400212	ASSY CONTROL PANEL AC	TATA spare parts
551983400213	ASSY TEMP.CONTROL PANEL	TATA spare parts
551983403370	MTG_BKT_AC_PIPE	TATA spare parts

551983403395	COVER_AC_PIPE_RH	TATA spare parts
551983404914	THERMO AMPLIFIER	TATA spare parts
551983406930	DISCHARGE PIPE COND END TOP	TATA spare parts
551983407502	GROMMET_HEATER_HOSE_FIREWALL	TATA spare parts
551983407503	GROMMET_AC_PIPE_FLOOR	TATA spare parts
551983500201	ASSY_HEATER_HOSE_OUT	TATA spare parts
551983500202	ASSY_HEATER_HOSE_IN	TATA spare parts
551983500210	ASSY HEATER HOSE LHD(CABIN TO ENGINE)	TATA spare parts
551983500211	ASSY HEATER HOSE (HEATER TO LCL)	TATA spare parts
551983503320	MTG_BKT_HEATER_HOSE_CHASSIS	TATA spare parts
551983503321	MTG_BKT_HEATER_HOSE_FIREWALL_OUTSIDE	TATA spare parts
551983503322	MTG_BKT_HEATER_HOSE_FIREWALL	TATA spare parts
551983503324	MTG_BKT_HEATER_HOSE_INSIDE	TATA spare parts
551983503325	MTG_BKT_HEATER_HOSE_INSIDE	TATA spare parts
551984100111	ASSY BKT JERRY CAN MTG	TATA spare parts
551988100109	ASSY BKT FENDER MTG LH	TATA spare parts
551988100110	ASSY BKT FENDER MTG RH	TATA spare parts
551988100111	ASSY BKT FENDER MTG REAR RH	TATA spare parts
551988100116	ASSY GRILL HEADLAMP	TATA spare parts
551988100121	ASSY WHEELARCH FRT LH	TATA spare parts
551988100122	ASSY WHEELARCH FRT RH	TATA spare parts
551988100125	ASSY BATTERY TRAY	TATA spare parts
551988100126	ASSY SUPPORT WHEELARCH MTG LH	TATA spare parts
551988100127	ASSY SUPPORT WHEELARCH MTG RH	TATA spare parts
551988100128	ASSY SUPPORT WHEELARCH MTG FRT RH	TATA spare parts
551988100129	ASSY EXTN FENDER FRT LH	TATA spare parts
551988100130	ASSY EXTN FENDER FRT RH	TATA spare parts
551988100135	ASSY SUPPORT BATTERY TRAY	TATA spare parts
551988100137	ASSY EXTN FENDER FRT RH LHD	TATA spare parts
551988100139	ASSY FRT EXTN FENDER FRT RH LHD	TATA spare parts
551988100142	ASSY SIDE PANEL FENDER FRT LH	TATA spare parts
551988107701	FRONT FENDER BEADING LH	TATA spare parts
551988107702	FRONT FENDER BEADING RH	TATA spare parts
551988108206	SIDE PANEL FENDER FRT RH	TATA spare parts
551988200105	ASSY EXTN WHEELARCH REAR LH	TATA spare parts
551988200106	ASSY EXTN WHEELARCH REAR RH	TATA spare parts
551988200109	ASSY EXTN FENDER REAR LH	TATA spare parts
551988200110	ASSY EXTN FENDER REAR RH	TATA spare parts
551988200111	ASSY GRILL TAIL LAMP	TATA spare parts
551988200112	ASSY PANEL FENDER REAR COMP LH	TATA spare parts
551988200113	ASSY PANEL FENDER REAR COMP RH	TATA spare parts
551988200116	ASSY SIDE PANEL FENDER REAR LH	TATA spare parts
551988200117	ASSY SIDE PANEL FENDER REAR RH	TATA spare parts
551988207701	REAR FENDER BEADING LH	TATA spare parts
551988207702	REAR FENDER BEADING RH	TATA spare parts
551988208210	SIDE PANEL FENDER REAR RH	TATA spare parts
551988300101	ASSY REAR STEP LOWER	TATA spare parts

551988300102	ASSY REAR STEP UPPER	TATA spare parts
551988306701	CLEVIS PIN	TATA spare parts
551988307701	NYLON BUSH (REAR STEP)	TATA spare parts
551988400101	ASSY SUPPORT FRONT STEP MTG	TATA spare parts
551988400109	ASSY HINGE FRT FOOTSTEP	TATA spare parts
551988400115	ASSY FRT FOOTSTEP COMP LH	TATA spare parts
551988400127	SUPPORT ASSY FRONT STEP MTG	TATA spare parts
551988400129	SUPPORT ASSY FRONT STEP MTG	TATA spare parts
551988407701	FOOTSTEP FRONT PANEL BEADING LH	TATA spare parts
551988407702	FOOTSTEP FRONT PANEL BEADING RH	TATA spare parts
551988407703	FOOTSTEP CLOSURE BEADING LH	TATA spare parts
551988407704	FOOTSTEP CLOSURE BEADING RH	TATA spare parts
551988407705	FOOTSTEP FRONT PANEL BEADING LH	TATA spare parts
551988408213	SHIM	TATA spare parts
551988500101	ASSY BUMPER FRONT	TATA spare parts
551988500103	ASSY MARKER POST LH	TATA spare parts
551988500104	ASSY MARKER POST RH	TATA spare parts
551990900103	ASSY GLASS GUNPORT	TATA spare parts
551990903408	SPACER RING2 GLASS GUNPORT	TATA spare parts
551990906301	RUBBER GASKET GUNPORT	TATA spare parts
551991000101	ASSY SEAT MPV DRIVER	TATA spare parts
551991700101	ASSY SEAT MTG BRACKET DRIVER	TATA spare parts
551991700104	ASSY AUXILLARY PIPE FOR PNEUMATIC SEAT	TATA spare parts
551992000102	ASSY CREW SEAT REAR	TATA spare parts
551992100101	ASSY BKT CREW SEAT MTG FRAME	TATA spare parts
551992103301	SEAT MTG BKT LH	TATA spare parts
551992103302	SEAT MTG BKT RH	TATA spare parts
551998800117	ASSY BKT TRANSFERCASE OIL COOLER	TATA spare parts
551998800118	ASSY BKT TRANSFERCASE OIL COOLER	TATA spare parts
552030100101	ACCELERATOR CABLE ASSY	TATA spare parts
552047600101	ASSY SUCTION LINE (STRAINER TO MECH FEED	TATA spare parts
552054600113	WIRING HARNESS SIDE BLINKER	TATA spare parts
552054600114	WIRING HARNESS SIDE BLINKER	TATA spare parts
552054600115	WIRING HARNESS SIDE BLINKER	TATA spare parts
552054600117	WIRING HARNESS TAIL	TATA spare parts
552054600119	WIRING HARNESS ENGINE	TATA spare parts
552054600120	WIRING HARNESS ABS	TATA spare parts
552054601607	W/H PARKING	TATA spare parts
552054601609	WIRING HARNESS MAIN	TATA spare parts
55206000002R40	PARTIAL FITTED CAB FOR LPT813EX2	TATA spare parts
552315108002	HEX SCREW BS6	TATA spare parts
552315109908	ARMATURE ASSY BS6	TATA spare parts
552315109911	COMMUTATOR END SHIELD ASSY BS6	TATA spare parts
552315208201	WH-ENG-CLAMPING BKT ON AIR FILTER MOUNTI	TATA spare parts
552315208202	ENGINE WH MTG BKT ACE FACE LIFT	TATA spare parts
552315400102	ALTERNATOR BS6	TATA spare parts
552315400103	ALTERNATOR 50A WITH VP & BIG BANJO	TATA spare parts

552315400104	ALTERNATOR 50A WITH VP & SMALL BANJO	TATA spare parts
552315400105	ALTERNATOR 12V 70A 4 GROOVE PULLEY BS6	TATA spare parts
552315400106	DRIVEENDSHIELDASSEMBLY BS6	TATA spare parts
552315400107	ROTORASSEMBLY BS6	TATA spare parts
552315400108	STATORASSEMBLY BS6	TATA spare parts
552315400109	DEBRACKETASSY BS6	TATA spare parts
552315400110	RECTIFIERASSY BS6	TATA spare parts
552315400111	REGULATOR&BRUSHBOXASSY BS6	TATA spare parts
552315400112	SREBRACKETASSY BS6	TATA spare parts
552315400113	KIT-PLUGMOULDING BS6	TATA spare parts
552315400114	TERMINALMOULDING BS6	TATA spare parts
552315400117	SUCTIONCONNECTORASSY BS6	TATA spare parts
552315400121	VACUUMPUMPASSY BS6	TATA spare parts
552315400122	REGULATOR & BRUSH BOX ASSY BS6-PH2	TATA spare parts
552315409902	BEARING ASSY KIT	TATA spare parts
552315409903	FASTNERS ASSY KIT	TATA spare parts
552315409917	PULLEY BS6	TATA spare parts
552315409919	STARTER&WINDING&ASSY BS6	TATA spare parts
552315409921	CENTER&PLATE	TATA spare parts
552315409922	BEARING&ASSY&KIT BS6	TATA spare parts
552315409923	FASTENERS&KIT BS6	TATA spare parts
552315409924	VACUUM&PUMP&ASSY BS6	TATA spare parts
552315409925	PROJECTIVECAP BS6	TATA spare parts
552315409926	REGULATOR BS6	TATA spare parts
552315409927	RECTIFIER BS6	TATA spare parts
552315409928	DEEPGROOVEBALLBEARING BS6	TATA spare parts
552315409929	FUSE BS6	TATA spare parts
552329100106	ASSY. CLUTCH CABLE NA DICOR 1810MM BS3/4	TATA spare parts
552329100107	ASSY CLUTCH PEDAL LEVER	TATA spare parts
552329100111	ASSY.CLUTCH CABLE	TATA spare parts
552329100115	CLUTCH PEDAL ASSY WITH BUSH	TATA spare parts
552329100120	CLUTCH CABLE ASSY	TATA spare parts
552329100121	BRACKET ASSY CLUTCH CABLE GUIDE BS6	TATA spare parts
552329100122	CLUTCH CABLE ASSY BS6	TATA spare parts
552329108209	BRACKET CLUTCH CABLE MOUNT	TATA spare parts
552329200103	ASSY.BRAKE PEDAL LEVER	TATA spare parts
552329200116	ASSY. BRAKE PEDAL COMPLETE	TATA spare parts
552329200118	BRACKET ASSY BRAKE CONTROL MTG	TATA spare parts
552329200126	BRAKE PEDAL ASSY WITH BUSH	TATA spare parts
552329205301	FOAM SEALING	TATA spare parts
552329206704	PIN (BRAKE SPRING MTG.)	TATA spare parts
552329208701	RETURN SPRING (BRAKE)	TATA spare parts
552329208702	RETURN SPRING (CLUTCH) BS6	TATA spare parts
552329208703	RETURN SPRING BRAKE BS6-PH2	TATA spare parts
552329209201	PLASTIC WASHER (DIA-8.4)	TATA spare parts
552329209202	PLASTIC WASHER (DIA-10.5)	TATA spare parts
552329500101	BRACKET ASSY CONTROL MTG(WELDED) BS6	TATA spare parts

552329500102	ASSY.CONTROL MTG. BKT(CLUTCH AND BRAKE)	TATA spare parts
552330100106	ASSY. MECHANICAL ACCELERATOR PEDAL	TATA spare parts
552330100113	ASSY. ACCELERATOR CABLE 2557MM BS3/4	TATA spare parts
552330100116	ACCELERATOR PEDAL MODULE BS3/4	TATA spare parts
552330100118	ASSY. ACCELERATOR CABLE	TATA spare parts
552330100122	ASSY.MECH.ACCELERATOR PEDAL COMPLETE	TATA spare parts
552330100125	ACCELERATOR CABLE 2526MM BS3/4	TATA spare parts
552330100134	ASSY. ACCELERATOR PEDAL COMPLETE	TATA spare parts
552330100138	ACCELERATOR CABLE ASSY	TATA spare parts
552330100141	ACCELERATOR PEDAL MODULE BS3/4/6	TATA spare parts
552330100142	ACCELERATOR PEDAL MODULE BS6	TATA spare parts
552330106301	PACKING FOAM	TATA spare parts
552330108703	PEDAL SPRING	TATA spare parts
552331000104	ASSY. FRAME (750 PAYLOAD)	TATA spare parts
552331000109	ASSY FRAME (ACE FACELIFT)	TATA spare parts
552331000114	FRAME ASSY	TATA spare parts
552331138284	REINFORCEMENT (BRACKET CAB SUPPORT) BS6	TATA spare parts
552331148212	CUP BS6	TATA spare parts
552331230125	ASSY. FRONT CROSS MEMBER	TATA spare parts
552331230161	ASSY.BRACKET FUEL FILTER MTG.	TATA spare parts
552331230168	ASSY FRONT CROSS MEMBER	TATA spare parts
552331540102	BATTERY TRAY ASSY	TATA spare parts
552331700101	BRACKET ASSY LOAD BODY MTG BS6-PH2	TATA spare parts
552332100108	FIRST LEAF ASSY WITH BUSH	TATA spare parts
552332100109	ASSY. FRONT SPRING SEMIELLIPTICAL	TATA spare parts
552332104201	U BOLT (FRONT SPRING)	TATA spare parts
552332104202	U-BOLT FRONT SPRING	TATA spare parts
552332104211	CLIP BS6-PH2	TATA spare parts
552332107101	GUIDE PLATE FRONT	TATA spare parts
552332107103	SECOND LEAF	TATA spare parts
552332107104	THIRD LEAF	TATA spare parts
552332107105	FOURTH LEAF	TATA spare parts
552332107106	FIFTH LEAF	TATA spare parts
552332107701	RUBBER PAD FRONT SPRING CLIP BS6-PH2	TATA spare parts
552332300102	ASSY.FRONT SHOCK ABSORBER	TATA spare parts
552332400106	ASSY. REAR GUIDE PLATE LH	TATA spare parts
552332400107	ASSY. GUIDE PLATE LH (REAR SPRING)	TATA spare parts
552332400113	ASSY.REAR SPRING HANGER BKT.(RR RR)	TATA spare parts
552332400116	1ST LEAF ASSY WITH BUSH	TATA spare parts
552332400117	ASSY.GUIDE PLATE LH (REAR SPRING)	TATA spare parts
552332400118	ASSY.GUIDE PLATE RH (REAR SPRING)	TATA spare parts
552332400122	REAR LEAF SPRING ASSY. SEMIELLIPTICAL	TATA spare parts
552332400123	FIRST LEAF ASSY WITH BUSH	TATA spare parts
552332400125	ASSY SHACKLE (REAR SPRING)	TATA spare parts
552332400130	LEAF SPRING ASSY. REAR SEMIELLIPTICAL	TATA spare parts
552332400131	1ST LEAF ASSY WITH BUSH	TATA spare parts
552332400137	BRACKET ASSY REAR SPRING HANGER REAR BS6	TATA spare parts

552332400138	1ST LEAF ASSY WITH BUSH	TATA spare parts
552332400139	LEAF SPRING ASSY REAR	TATA spare parts
552332403201	CENTER_BOLT M10X57X23	TATA spare parts
552332403203	CENTER BOLT	TATA spare parts
552332407108	SECOND LEAF	TATA spare parts
552332407109	THIRD LEAF	TATA spare parts
552332407110	FOURTH LEAF	TATA spare parts
552332407111	FIFTH LEAF	TATA spare parts
552332407112	SIXTH LEAF	TATA spare parts
552332407113	SEVENTH LEAF	TATA spare parts
552332407121	2ND LEAF	TATA spare parts
552332407122	3RD LEAF	TATA spare parts
552332407127	2ND LEAF	TATA spare parts
552332407129	3RD LEAF	TATA spare parts
552332407130	4TH LEAF	TATA spare parts
552332407131	5TH LEAF	TATA spare parts
552332407132	6TH LEAF	TATA spare parts
552332407133	2ND LEAF	TATA spare parts
552332407134	3RD LEAF	TATA spare parts
552332407136	4TH LEAF	TATA spare parts
552332407137	5TH LEAF	TATA spare parts
552332500104	BRACKET ASSY SPRING HANGER FRONT (RR FR)	TATA spare parts
552332504201	U CLAMP REAR	TATA spare parts
552332600102	ASSY.REAR SHOCK ABSORBER	TATA spare parts
552332606704	PIN(REAR S/A MTG.TOP)	TATA spare parts
552332800102	LINK ASSY ANTI ROLL BAR	TATA spare parts
552332800106	LINK ASSY FRONT ANTI ROLL BAR	TATA spare parts
552332800121	ASSY FRONT ANTIROLL BAR COMPLETE	TATA spare parts
552332800130	ANTI ROLL BAR ASSY FRONT	TATA spare parts
552332806901	SLEEVE BS6	TATA spare parts
552333000104	FRONT AXLE ASSY	TATA spare parts
552333000107	ASSY. FRONT AXLE TUBE	TATA spare parts
552333000109	ASSY. FRONT AXLE	TATA spare parts
552333000113	FRONT AXLE TUBE ASSY	TATA spare parts
552333000115	FRONT AXLE ASSY	TATA spare parts
552333200105	STUB AXLE ASSY RH	TATA spare parts
552333200106	STUB AXLE ASSY LH	TATA spare parts
552333200107	KING PIN SUPPORT ASSY TOP BS6-PH2	TATA spare parts
552333200109	ASSY. STUB AXLE WITH BUSH RH	TATA spare parts
552333200110	ASSY. STUB AXLE WITH BUSH LH	TATA spare parts
552333200115	STUB AXLE ASSY RH BS6-PH2	TATA spare parts
552333200116	STUB AXLE ASSY LH BS6-PH2	TATA spare parts
552333201602	O-RING BS6-PH2	TATA spare parts
552333203402	BUSH KING PIN BS6-PH2	TATA spare parts
552333207802	SEAL BS6-PH2	TATA spare parts
552333208601	SHIM 0.90 THK BS6-PH2	TATA spare parts
552333208602	SHIM 0.95 THK BS6-PH2	TATA spare parts

552333208603	SHIM 1.00 THK BS6-PH2	TATA spare parts
552333208606	SHIM 1.05 THK BS6-PH2	TATA spare parts
552333208607	SHIM 1.10 THK BS6-PH2	TATA spare parts
552333208608	SHIM 1.15 THK BS6-PH2	TATA spare parts
552333208609	SHIM 1.20 THK BS6-PH2	TATA spare parts
552333208610	SHIM 1.25 THK BS6-PH2	TATA spare parts
552333208611	SHIM 1.30 THK BS6-PH2	TATA spare parts
552333208612	SHIM 1.35 THK BS6-PH2	TATA spare parts
552333208613	SHIM 1.40 THK BS6-PH2	TATA spare parts
552333208614	SHIM 1.45 THK BS6-PH2	TATA spare parts
552333208615	SHIM 1.50 THK BS6-PH2	TATA spare parts
552333208616	SHIM 1.55 THK BS6-PH2	TATA spare parts
552333208617	SHIM 1.60 THK BS6-PH2	TATA spare parts
552333208618	SHIM 1.65 THK BS6-PH2	TATA spare parts
552333208619	SHIM 1.70 THK BS6-PH2	TATA spare parts
552333209901	CAP KING PIN BS6-PH2	TATA spare parts
552333403101	THRUST BEARING BS6-PH2	TATA spare parts
552333800102	TIE ROD ASSEMBLY BS4	TATA spare parts
552333800104	TIE ROD ASSY	TATA spare parts
552333800106	ASSY. TIE ROD BS3/4	TATA spare parts
552333805101	STEERING ARM (14 IN WHEEL)	TATA spare parts
552333805103	STEERING ARM	TATA spare parts
552333990101	BALL JOINT END ASSY-RH	TATA spare parts
552333990102	BALL JOINT END ASSY-LH	TATA spare parts
552333990107	BALL JOINT ASSY RH	TATA spare parts
552333990108	BALL JOINT ASSY LH	TATA spare parts
552333996501	LOCK NUT-LH	TATA spare parts
552333996502	LOCK NUT RH BS6	TATA spare parts
552333996503	LOCK NUT LH BS6	TATA spare parts
552340101602	WHEEL RIM COVER ASSY	TATA spare parts
552340300107	ASSY.SPARE WHEEL CARRIER	TATA spare parts
552340300108	ASSY.SPARE WHEEL CARRIER	TATA spare parts
552340306903	HOOK CLAMP SPARE WHEEL MTG	TATA spare parts
552341100103	PROPELLER SHAFT ASSY	TATA spare parts
552341100105	TORSIONAL VIBRATION DAMPER	TATA spare parts
552341100109	PROPELLER SHAFT ASSY (RSB)	TATA spare parts
552341100110	PROPELLER SHAFT ASSY	TATA spare parts
552341100115	PROPELLER SHAFT ASSY	TATA spare parts
552341100116	PROPELLER SHAFT ASSY	TATA spare parts
552341100117	SLIP YOKE ASSY	TATA spare parts
552342100101	CALIPER ASSY FRONT-RH	TATA spare parts
552342100102	CALIPER ASSY FRONT-LH	TATA spare parts
552342300104	DRUM BRAKE ASSY RH	TATA spare parts
552342300105	DRUM BRAKE ASSY LH	TATA spare parts
552342700108	FRONT PARKING BRAKE CABLE ASSY-ACE EX	TATA spare parts
552342700112	PARKING BRAKE CABLE ASSY.REAR	TATA spare parts
552342700113	PARKING BRAKE CABLE ASSY. FRONT	TATA spare parts



552342700114	CABLE ASSY PARKING BRAKE FRONT	TATA spare parts
552342990103	KIT PAD ASSY	TATA spare parts
552342990105	KIT-BRAKE SHOE WITH LINER	TATA spare parts
552343100106	ASSY. BOOSTER 7INCH W/TMC DIA.22.22 BS3/	TATA spare parts
552343100107	ASSY BRACKET LCRV MOUNTING	TATA spare parts
552343100108	ASSY. BRAKE FLUID RESERVOIR	TATA spare parts
552343100110	LOAD SENSING VALVE WITH LEVER	TATA spare parts
552343108203	LCRV MTG BRACKET	TATA spare parts
552343500101	ASSY 6IN BOOSTER WITH TMC	TATA spare parts
552343500102	VACUUM PIPE ASSY	TATA spare parts
552343500103	ASSY.VACUUM PIPE	TATA spare parts
552343500105	ASSY.VACUUM PIPE(BOOSTER END)	TATA spare parts
552343500106	ASSY.VACUUM PIPE	TATA spare parts
552343500109	VACUUM PIPE-ENGINE END	TATA spare parts
552343500114	ASSY. VACUUM PUMP BS3/4	TATA spare parts
552343500117	VACUUM PIPE ASSY	TATA spare parts
552343500119	VACUUM PUMP ASSY	TATA spare parts
552343500122	BOOSTER ASSY	TATA spare parts
552343500123	VACUUM PIPE ASSY	TATA spare parts
552343504205	CLAMP VACUUM PIPE	TATA spare parts
552343505804	HOSE¿ BOOSTER NRV TO VACUUM PIPE	TATA spare parts
552343506923	TUBE	TATA spare parts
552343507701	VACUUM HOSE-ENGINE SIDE	TATA spare parts
552343507702	VACCUM HOSE-BOOSTER END	TATA spare parts
552343507703	VACUUM HOSE-BOOSTER END	TATA spare parts
552343507704	VACUUM HOSE(ENGINE END)	TATA spare parts
552343507705	VACUUM HOSE BOOSTER END	TATA spare parts
552343507706	VACUUM HOSE BOOSTER END BS6	TATA spare parts
552343507801	O-RING	TATA spare parts
552343507802	O-RING	TATA spare parts
552343800102	ASSY. PIPE	TATA spare parts
552343800103	ASSY. PIPE	TATA spare parts
552343800104	ASSY. PIPE	TATA spare parts
552343800105	ASSY. PIPE	TATA spare parts
552343800106	ASSY. PIPE	TATA spare parts
552343800107	ASSY. PIPE	TATA spare parts
552343800108	ASSY. VACUUM PIPE BOOSTER END	TATA spare parts
552343800114	ASSY. PIPE	TATA spare parts
552343800115	ASSY. PIPE	TATA spare parts
552343800116	ASSY. PIPE	TATA spare parts
552343800117	ASSY. PIPE	TATA spare parts
552343800125	TUBE ASSY SECONDARY PORT TO T CONNECTOR	TATA spare parts
552343800126	TUBE ASSY TMC PRIMARY TO LONG MEM PIPE	TATA spare parts
552343800127	ASSY TUBE	TATA spare parts
552343800134	TUBE ASSY LCRV TO REAR BRAKE HOSE	TATA spare parts
552343800135	ASSY PIPE BS6	TATA spare parts
552343800144	TUBE ASSYTMC SECONDARY TOTCONNECTOR	TATA spare parts

552343800145	TUBE ASSYTMC PRIMARY TOTCONNECTOR	TATA spare parts
552343800147	ASSY. PIPE	TATA spare parts
552343800148	ASSY. PIPE	TATA spare parts
552343800149	ASSY. PIPE	TATA spare parts
552343800150	ASSY. PIPE	TATA spare parts
552343800157	BRACEKT ASSY (TMC COVER MOUNTING)	TATA spare parts
552343800158	ASSY. TMC COVER	TATA spare parts
552343800159	TANDEM MASTER CYL COVER ASSY	TATA spare parts
552343800162	ASSY. PIPE	TATA spare parts
552343800163	TUBE ASSY PRIMARY PORT TO ADAPTER	TATA spare parts
552343800164	TUBE ASSY T-CONN TO FRONT BRAKE HOSE RH	TATA spare parts
552343800165	BUNDY TUBE ASSY T-CONN TO REAR HOSE LH	TATA spare parts
552343800166	TUBE ASSY ADAPTER TO REAR BRAKE HOSE RH	TATA spare parts
552343800167	TUBE ASSY ADAPTER TO FRONT BRAKE HOSE LH	TATA spare parts
552343800168	TUBE ASSY SECONDARY PORT TO T-CONN	TATA spare parts
552343800169	TUBE ASSY PRIMARY PORT TO ADAPTER	TATA spare parts
552343800175	TUBE ASSYLCRV OUTLET TO REAR BRAKE HOSE	TATA spare parts
552343800176	TUBE ASSYTCONNECTOR TO LCRV INLET	TATA spare parts
552343800177	TUBE ASSYTCONNECTOR TO LCRV INLET	TATA spare parts
552343800178	TUBE ASSYLCRV OUTLET TO REAR BRAKE HOSE	TATA spare parts
552343800185	TUBE ASSY TMC TO RH T-CONNECTOR	TATA spare parts
552343800186	TUBE ASSY - PRIMARY PORT TO ADAPTER	TATA spare parts
552343800187	TUBE ASSY TMC TO LH CALIPER TUBE ASSY	TATA spare parts
552343800188	BRACKET ASSY - TMC COVER MOUNTING	TATA spare parts
552343800189	COVER ASSY - TANDEM MASTER CYL	TATA spare parts
552343803301	BRACKET BRAKE HOSE MTG REAR	TATA spare parts
552343803302	BRACKET BRAKE HOSE MTG REAR	TATA spare parts
552343803303	BRACKET BRAKE HOSE MTG REAR BS6	TATA spare parts
552343805801	HOSE BOOSTER END	TATA spare parts
552343805802	HOSE BRAKE FLUID	TATA spare parts
552343805803	HOSE BRAKE FLUID	TATA spare parts
552343805806	HOSE RESERVOIR SECONDRY	TATA spare parts
552343805807	HOSE RESERVOIR PRIMARY	TATA spare parts
552343805808	HOSE - RESERVOIR PRIMARY	TATA spare parts
552343805809	HOSE - RESERVOIR SECONDARY	TATA spare parts
552343805812	HOSE - PRIMARY	TATA spare parts
552343805813	HOSE - SECONDARY	TATA spare parts
552343805814	HOSE RESERVOIR TO TMC PRIMARY	TATA spare parts
552343810104	TUBE ASSY;TMC SECONDARY TO T-CONN	TATA spare parts
552343810105	TUBE ASSY;T-CONN TO FRONT BRAKE HOSE;LH	TATA spare parts
552343810106	TUBE ASSY;TMC PRIMARY TO T-CONN	TATA spare parts
552343810107	TUBE ASSY;T-CONN TO FRONT BRAKE HOSE;RH	TATA spare parts
552343810108	TUBE ASSY T-CONN TO REAR BRAKE HOSE LH	TATA spare parts
552343810109	TUBE ASSY T-CONN TO REAR BRAKE HOSE RH	TATA spare parts
552343810116	TUBE ASSY T-CONN TO PCRV RH	TATA spare parts
552343810117	TUBE ASSY T-CONN TO PCRV LH	TATA spare parts
552343810122	TUBE ASSY T-CONN TO REAR BRAKE HOSE RH	TATA spare parts

552343810123	TUBE ASSY T-CONN TO REAR BRAKE HOSE LH	TATA spare parts
552343810125	BRACKET ASSY LCRV MTG	TATA spare parts
552343810126	TUBE ASSY ADAPTER TO LCRV INLET	TATA spare parts
552343810127	TUBE ASSY T-CONN TO LCRV	TATA spare parts
552343810128	TUBE ASSY LCRV TO REAR BRAKE HOSE RH	TATA spare parts
552343810129	TUBE ASSY LCRV OUTLET TO REAR HOSE	TATA spare parts
552343990101	MC ASSY	TATA spare parts
552343990102	BOOSTER ASSY	TATA spare parts
552343990103	KIT INLET ADAPTOR	TATA spare parts
552343990104	MC KIT MAJOR	TATA spare parts
552343990105	KIT BOOSTER	TATA spare parts
552343990107	MC KIT MINOR	TATA spare parts
552343990110	MINOR KIT	TATA spare parts
552343990111	MAJOR KIT	TATA spare parts
552346100103	ASSY.STEERING COLUMN	TATA spare parts
552346100104	STEERING COLUMN ASSY WITH I-SHAFT	TATA spare parts
552346100107	ASSY.STEERING COLUMN (LHD)	TATA spare parts
552346100109	ASSY. STEERING COLUMN BS2/3/4	TATA spare parts
552346200102	ASSY. STEERING GEAR BOX BS2/3/4	TATA spare parts
552346200111	STEERING GEAR BOX ASSY	TATA spare parts
552346200114	ASSY.STEERING COLUMN BELLOW	TATA spare parts
552346200121	STEERING GEAR BOX ASSY	TATA spare parts
552346206301	FOAM PACKING	TATA spare parts
552346206302	BUSH (FOR RUBBER BELLOW)	TATA spare parts
552346207701	RUBBER BELLOW	TATA spare parts
552346208201	COVER SHEET	TATA spare parts
552346208301	SHIM STG GEAR BOX BS6-PH2	TATA spare parts
552346208601	SHIM 0.2 THK. (STEERING GEAR BOX)	TATA spare parts
552346208602	SHIM 0.5 THK. (STEERING GEAR BOX)	TATA spare parts
552346208603	SHIM 0.8 THK. (STEERING GEAR BOX)	TATA spare parts
552346400102	ASSY.STEERING WHEEL 2 SPOKE	TATA spare parts
552346600105	ASSY. DRAG LINK BS3/4	TATA spare parts
552346600108	DRAG LINK ASSY	TATA spare parts
552346600116	BEARINGASSY BS6	TATA spare parts
552346603201	BOLT BS6	TATA spare parts
552346603202	BOLT BS6	TATA spare parts
552346606502	LOCKNUT BS6	TATA spare parts
552346607801	OILSEAL BS6	TATA spare parts
552346609201	SPRINGWASHER BS6	TATA spare parts
552346609203	SPRINGWASHER BS6	TATA spare parts
552346609204	BOXASSY BS6	TATA spare parts
552346990102	I-SHAFT ASSY	TATA spare parts
552346990103	UPPER COLUMN ASSY	TATA spare parts
552346990104	ASSY. LOWER I SHAFT BS2/3/4	TATA spare parts
552346990108	BOX SUB ASSY	TATA spare parts
552346990109	WORM AND NUT SUB ASSY	TATA spare parts
552346990114	UPPER COLUMN ASSY	TATA spare parts

552346990121	BOX SUB ASSY	TATA spare parts
552346990122	WORM AND NUT SUB ASSY	TATA spare parts
552346990123	BALL JOINT ASSY RH	TATA spare parts
552346990124	LOCK NUT	TATA spare parts
552346990125	INTERMEDIATE SHAFT ASSY	TATA spare parts
552346993001	BEARING SUB ASSY (BOTTOM)	TATA spare parts
552346993002	BEARING SUB ASSY (TOP)	TATA spare parts
552346993104	BALLBEARING - 6303 - BS6	TATA spare parts
552346993105	BALLBEARING - 6204 - BS6	TATA spare parts
552346993201	BOLT	TATA spare parts
552346993202	M8 BOLT	TATA spare parts
552346994702	COVER PLATE	TATA spare parts
552346994703	END PLATE	TATA spare parts
552346995101	DROP ARM	TATA spare parts
552346995103	DROP ARM	TATA spare parts
552346996301	HORN PAD	TATA spare parts
552346996501	LOCK NUT-RH	TATA spare parts
552346996502	LOCK NUT	TATA spare parts
552346997801	DUST SEAL	TATA spare parts
552346997901	ROCKER SHAFT MACHINED	TATA spare parts
552346997902	ROCKER SHAFT MACHINED	TATA spare parts
552346998001	ADJUSTER SCREW	TATA spare parts
552346998301	SHIM 0.010 IN	TATA spare parts
552346998302	SHIM 0.005 IN	TATA spare parts
552346998303	SHIM 0.003 IN	TATA spare parts
552346998701	SPRING	TATA spare parts
552346999202	SPRING WASHER	TATA spare parts
552346999203	SPRING WASHER	TATA spare parts
552346999901	LOCATOR	TATA spare parts
552346999902	SPRING SEAT	TATA spare parts
552347100104	FUEL TANK ASSY BS6	TATA spare parts
552347100106	FUEL TANK ASSY BS6	TATA spare parts
552347600106	FUEL RETURN PIPE ASSY	TATA spare parts
552347600109	FUEL SUCTION PIPE ASSY	TATA spare parts
552347600110	FUEL SUCTION PIPE ASSY	TATA spare parts
552347600111	FUEL RETURN PIPE ASSY	TATA spare parts
552347600112	FUEL RETURN PIPE ASSY	TATA spare parts
552347600114	FUEL RETURN PIPE ASSY	TATA spare parts
552347600115	FUEL RETURN PIPE ASSY	TATA spare parts
552347600116	FUEL RETURN PIPE ASSY	TATA spare parts
552349100109	ASSY. BRACKET (ON FRAME-TAIL PIPE MTG)	TATA spare parts
552349100115	ASSY SILENCER	TATA spare parts
552349100120	PIPE ASSEMBLY INTERMEDIATE	TATA spare parts
552349100122	PIPE ASSY FRONT WITH FLEXIBLE BELLOW	TATA spare parts
552349100135	PIPE ASSY WITH THERMAL INSULATION INTERM	TATA spare parts
552349200114	ASSLY RUBBER HANGER	TATA spare parts
552354100102	BATTERY CABLE +VE	TATA spare parts

552354100105	BATTERY CABLE +VE	TATA spare parts
552354100108	BATTERY CABLE +VE	TATA spare parts
552354100112	ASSLY BKT FOR MIDI FUSE MODULE MTG	TATA spare parts
552354100113	ASLY BKT FOR MIDI FUSE MODULE MTG ACE EX	TATA spare parts
552354100127	BATTERY CABLE TERMINAL 2 TO MIDI FUSE	TATA spare parts
552354100129	MAIN CABLE BATT. TO STARTER ACE FL BSIII	TATA spare parts
552354108202	STUD MTG SUPPORT BS6-PH2	TATA spare parts
552354108204	BATTERY BOTTOM CLAMP ON TRAY	TATA spare parts
552354108801	BATTERY CLAMPING STUD 59 MM	TATA spare parts
552354200101	ACE BS IV ASSY EGR CONTROLLER MTG BKT	TATA spare parts
552354200108	ELECTRONIC INSTR CLUSTER(0.62 RATIO)	TATA spare parts
552354200109	INSTRUMENT CLUSTER .(0.65 RATIO) BS3/4	TATA spare parts
552354200115	ELECT. INSTR. CLUSTER(0.5625 RATIO) BS4	TATA spare parts
552354200116	ELECTRONIC INSTR CLUSTER(0.62 RATIO)	TATA spare parts
552354200119	ASSY. INSTRUMENT CLUSTER BS3/4	TATA spare parts
552354200138	DIGITAL CLOCK	TATA spare parts
552354200139	INSTRUMENT CLUSTER ASSY	TATA spare parts
552354200142	INSTRUMENT CLUSTER ASSY	TATA spare parts
552354200144	INSTRUMENT CLUSTER	TATA spare parts
552354200146	INSTRUMENT CLUSTER ASSY	TATA spare parts
552354200154	FACIA SWITCH PACK	TATA spare parts
552354200156	FACIA SWITCH PACK	TATA spare parts
552354201611	INSTRUMENT CLUSTER ASSY	TATA spare parts
552354204902	ABS & EBD INDICATOR	TATA spare parts
552354206301	PLUG WITH RETAINER RING FOR CIGARETTE LI	TATA spare parts
552354208204	ACE BS IV DIAGNOSTIC CONNECTOR MTG BKT	TATA spare parts
552354208213	ACE FACELIFT DIAGNOSTIC CONN. MTG BKT	TATA spare parts
552354208215	RADIATOR FAN CONN PARKING BKT BS6	TATA spare parts
552354209904	ECU (A-ECU) OBDII ACE HT BS4	TATA spare parts
552354400112	ASSYFRONTFOGLAMPLHACEFACELIFT	TATA spare parts
552354400113	ASSYFRONTFOGLAMPRHACEFACELIFT	TATA spare parts
552354400114	ASSY. HEAD LAMP LH ACE FL BS2/3/4	TATA spare parts
552354400115	ASSY. HEAD LAMP RH ACE FL BS2/3/4	TATA spare parts
552354400116	LAMP ASSY HEADLAMP - LH (LHD)	TATA spare parts
552354400117	LAMP ASSY HEADLAMP - RH (LHD)	TATA spare parts
552354400118	ASSY. TAIL LAMP LH MAGIC	TATA spare parts
552354400119	ASSY. TAIL LAMP RH MAGIC	TATA spare parts
552354400120	LAMP ASSY HEADLAMP-LH(RHD)	TATA spare parts
552354400121	LAMP ASSY HEADLAMP-RH(RHD)	TATA spare parts
552354400122	LAMP ASSY CABIN ACE EV	TATA spare parts
552354400137	LAMP ASSY CABIN	TATA spare parts
552354400139	LAMP ASSY CABIN FRONT ACE EV	TATA spare parts
552354401604	CABIN LAMP FRONT	TATA spare parts
552354409903	REFLEX REFLECTOR LH	TATA spare parts
552354409904	REFLEX REFLECTOR RH	TATA spare parts
552354480102	LAMP ASSY CABIN	TATA spare parts
552354500108	ASSY. 3 PACK SWITCH	TATA spare parts

552354500110	ASSY. 3 PACK SWITCH ACE EV	TATA spare parts
552354500124	FACIA SWITCH (3PACK)- RHD	TATA spare parts
552354500132	FACIA SWITCH ASSY	TATA spare parts
552354504901	HEAD LAMP LEVELING SWITCH	TATA spare parts
552354504902	DEMISTING SWITCH	TATA spare parts
552354504904	HEADLAMP LEVELLING SWITCH	TATA spare parts
552354504905	STEERING LOCK WITH IGNITION SWITCH BS6	TATA spare parts
552354600105	W/H MAIN ACE FACE LIFT BS3	TATA spare parts
552354600108	WH MAIN ACE MAGIC FACE LIFT BS III	TATA spare parts
552354600115	WIRING HARNESS MAIN	TATA spare parts
552354600116	WIRING HARNESS MAIN	TATA spare parts
552354600121	WH ENGINE ACE BS III FACELIFT	TATA spare parts
552354600122	WIRING HARNESS ENGINE	TATA spare parts
552354600125	ENGINE WIRING HARNESS	TATA spare parts
552354600126	WH MAIN ACE FACELIFT BS IV	TATA spare parts
552354600131	WH ENGINE ACE FACELIFT BS IV	TATA spare parts
552354600134	W/H MAIN	TATA spare parts
552354600141	MAGIC FACELIFT DICOR TCIC BS IV WH MAIN	TATA spare parts
552354600143	ACE/MAGIC FL ASSLY BKT FOR CONTROLLERS	TATA spare parts
552354600151	W/H MAIN (HOURS METER)	TATA spare parts
552354600155	WIRING HARNESS MAIN	TATA spare parts
552354600157	WH MAIN ACE BS IV EOBD II S1	TATA spare parts
552354600158	W/H MAIN EOBD II ACE 275 IDI BSIV	TATA spare parts
552354600159	ASSY MAIN WH ACE CNG BSIV FACELIFT	TATA spare parts
552354600160	ACE/MAGIC FL: ASSLY BKT FOR FUSEBOX MTG	TATA spare parts
552354600164	ASSY RELAY AND FLASHER BRACKET ACE CNG F	TATA spare parts
552354600166	WIRING HARNESS MAIN EOBD II	TATA spare parts
552354600167	WIRING HARNESS - MAIN	TATA spare parts
552354600183	WIRING HARNESS MAIN	TATA spare parts
552354600194	WIRING HARNESS MAIN	TATA spare parts
552354600222	WIRING HARNESS ROOF	TATA spare parts
552354601626	WIRING HARNESS MAIN	TATA spare parts
552354601634	WIRING HARNESS MAIN	TATA spare parts
552354601661	WIRING HARNESS ENGINE	TATA spare parts
552354601686	WIRING HARNESS MAIN	TATA spare parts
552354603303	BRACKET WH MOUNTING	TATA spare parts
552354606307	FUSE BOX COVER	TATA spare parts
552354608202	WH ENGINE AND BATT CABLE POSITIVE MTG BK	TATA spare parts
552354608204	INTERCONNECTIONCONNMTGBKTACEFACELIFT	TATA spare parts
552354609901	HT CABLE	TATA spare parts
552354609917	MICRO RELAY WITH RESISTOR BS6	TATA spare parts
552354609919	MICRO RELAY WITH DIODE	TATA spare parts
552354609929	RELAY WITH DIODE BS6	TATA spare parts
552354609936	MINI RELAY BS6	TATA spare parts
552354610104	WH MAIN ACE CNG BSIV EOBDII	TATA spare parts
552354610105	WH MAIN MAGIC CNG BSIV EOBDII	TATA spare parts
552354610106	WH ENGINE ACE CNG BSIV EOBDII	TATA spare parts

552354610110	WIRING HARNESS BATTERY CABLE +VE	TATA spare parts
552354610116	WIRING HARNESS MAIN	TATA spare parts
552354610129	BATTERY CABLE +VE	TATA spare parts
552354610131	WIRING HARNESS ENGINE	TATA spare parts
552354610135	BATTERY CABLE +VE	TATA spare parts
552354610137	WIRING HARNESS MAIN	TATA spare parts
552354610151	WIRING HARNESS MAIN	TATA spare parts
552354610153	WIRING HARNESS MAIN	TATA spare parts
552354610157	WIRING HARNESS MAIN	TATA spare parts
552354610160	WIRING HARNESS MAIN	TATA spare parts
552354610165	WIRING HARNESS MAIN	TATA spare parts
552354610175	WIRING HARNESS ENGINE	TATA spare parts
552354610177	WIRING HARNESS MAIN BS4	TATA spare parts
552354610180	WIRING HARNESS BATTERY CABLE +VE	TATA spare parts
552354610181	WIRING HARNESS;BATTERY CABLE +VE	TATA spare parts
552354610182	WIRING HARNESS BATTERY CABLE +VE	TATA spare parts
552354610192	WIRING HARNESS;ENGINE	TATA spare parts
552354610196	WIRING HARNESS MAIN	TATA spare parts
552354610197	WIRING HARNESS BATTERY CABLE +VE	TATA spare parts
552354610198	WIRING HARNESS BATTERY -VE CABLE	TATA spare parts
552354620157	WIRING HARNESS MAIN	TATA spare parts
552354620159	BRACKET BATTERY CABLE CLAMP MTG	TATA spare parts
552354620162	BATTERY CABLE +VE	TATA spare parts
552354620169	WIRING HARNESS ENGINE	TATA spare parts
552354709902	ECU INTEGRATED BS4	TATA spare parts
552354709904	AUXILLARY ECU	TATA spare parts
552354709906	FASTAG	TATA spare parts
552354709908	WHEEL SPEED SENSOR REAR	TATA spare parts
552354709909	WHEEL SPEED SENSOR FRONT	TATA spare parts
552354820101	WIPER MOTOR ASSY WITH BRACKET BS6	TATA spare parts
552354820102	WIPER MOTOR ASSY BS6	TATA spare parts
552355106301	FRONT STICKER LH	TATA spare parts
552355106302	FRONT STICKER YELLOW	TATA spare parts
552355106303	SIDE STICKER LH	TATA spare parts
552355106304	SIDE STICKER RH	TATA spare parts
552355106307	MASCOT DICOR	TATA spare parts
552355106308	FRONT STICKER ORANGE	TATA spare parts
552355106309	SIDE STICKER LH ORANGE	TATA spare parts
552355106310	SIDE STICKER RH ORANGE	TATA spare parts
552355106311	MASCOT TURBO	TATA spare parts
552355106312	SET DECALS	TATA spare parts
552355106313	SIDE DECALE LH MAGIC DICOR FACELIFT	TATA spare parts
552355106314	SIDE DECALE RH MAGIC DICOR FACELIFT	TATA spare parts
552355106315	MASCOT EX2	TATA spare parts
552355106316	ONE MILLION VEHICLE DECAL	TATA spare parts
552355106317	TATA ACE EX2 DECAL LH	TATA spare parts
552355106318	TATA ACE EX2 DECAL RH	TATA spare parts

552355106319	ACE CNG DECAL FRONT PANEL	TATA spare parts
552355106320	ACE CNG DECAL LH	TATA spare parts
552355106321	ACE CNG DECAL RH	TATA spare parts
552355106322	MASCOT HT2	TATA spare parts
552355106323	ACE HT2 DECAL LH	TATA spare parts
552355106324	ACE HT2 DECAL RH	TATA spare parts
552355106331	MASCOT MEGA	TATA spare parts
552355106332	MASCOT MANTRA	TATA spare parts
552355106334	DECAL FRONT DOOR LH ACE MEGA	TATA spare parts
552355106335	DECAL FRONT DOOR RH ACE MEGA	TATA spare parts
552355106341	MASCOT ACE	TATA spare parts
552355106343	MASCOT	TATA spare parts
552355106344	STICKER	TATA spare parts
552358900701	ADAPTER CHECKING ENGINE COMPRESSION	TATA spare parts
552360100133	ASSY.BODY SHELL COMPLETE PAINTED ACE 275	TATA spare parts
552360100133FD	ASSY BODY SHELL COMPLETE PAINTED - SKOOL	TATA spare parts
552360100133H3	ASSY BODY SHELL COMPLETE PAINTED - OPALI	TATA spare parts
552360100135	ASSY UNDERBODY PASSENGER CARRIER	TATA spare parts
552360100160BF	ASSY BODY SHELL COMPLETE PAINTED MAGIC 27	TATA spare parts
552360100160BN	ASSY BODY SHELL COMPLETE PAINTED - RUB	TATA spare parts
552360100160BU	ASSY BODY SHELL COMPLETE PAINTED - JET	TATA spare parts
552360100160FD	ASSY BODY SHELL COMPLETE PAINTED - SK	TATA spare parts
552360100189BF	BODYSHELL COMPL W/SD ARTIC_WHITE	TATA spare parts
552360100189BU	ASSY BODY SHELL COMPLETE PAINTED (WITH SD	TATA spare parts
552360100189C9	ASSY BODY SHELL COMPLETE PAINTED (WITH SD	TATA spare parts
552360100189FW	BODYSHELL COMPL W/SD IVORY_WHITE	TATA spare parts
552360100189H3	BODYSHELL COMPL W/SD OPALINE	TATA spare parts
552360100204	ASSY BODY SHELL COMPLETE-FACELIFT	TATA spare parts
552360100205BF	ASSY BODY SHELL COMPLETE PAINTED- ARTIC	TATA spare parts
552360100205CN	ASSY. CABIN BARE ACE IRISH CREAM BS3/4	TATA spare parts
552360100205HO	ASSY BODY SHELL COMPLETE PAINTED-FACELIF	TATA spare parts
552360100205HS	ASSY BODY SHELL COMPLETE PAINTED -LASER	TATA spare parts
552360100205HU	ASSY. CABIN BARE ACE AZURE BLUE BS3/4	TATA spare parts
552360100205JS	ASSY BODY SHELL TITANIUM_WH- PAINTED	TATA spare parts
552360100285BF	ARCTIC_WHITE-ASSY BODY SHELL COMPLETE	TATA spare parts
552360100285BU	BODY SHELL COMPLETE PAINTED JET BLACK	TATA spare parts
552360100285FD	SK_GOLN_YELW-ASSY BODY SHELL COMPLETE PA	TATA spare parts
552360100285HS	LASER_RED-ASSY BODY SHELL COMPLETE PAINT	TATA spare parts
552360100301BF	ASSY BODY SHELL PAINTED. ARC WHITE BS3/4	TATA spare parts
552360100341	ASSY BODY SHELL DICR FL BS4 WT 2050 GVW	TATA spare parts
552360100342BF	ASSY.BODYSHELL PAINTED A.WHITE DICOR BS3	TATA spare parts
552360100342G3	ASSY.B.SHELL PAINTED POR.WHITE DICOR BS4	TATA spare parts
552360100342HU	ASSY. CABIN BARE ACE MEGA AZURE BLUE BS4	TATA spare parts
552360100342JS	TITANIUM_WH-ASSY BODY SHELL COMPLETE PAIN	TATA spare parts
552360100354BF	ARCTIC_WHITE-ASSY BODY SHELL COMPLETE PAI	TATA spare parts
552360100354BN	RUBY_RED-ASSY BODY SHELL COMPLETE PAINTED	TATA spare parts
552360100354BU	JET_BLACK-ASSY BODY SHELL COMPLETE PAINTE	TATA spare parts



552360100354FD	SK GOLN YELW-ASSY BODYSHELL COMPLETE PAI	TATA spare parts
552360100354HS	ASSY BODYSHELL COMPLETE LASER RED	TATA spare parts
55236010Z141	ASSY PARTIAL BODY SHELL WITH REAR SILL I	TATA spare parts
55236010Z142	ASSY PARTIAL BODY SHELL WITH TUBULAR STR	TATA spare parts
55236010Z144	ASSY BODY SHELL COMP MAGIC LHD	TATA spare parts
55236010Z145BF	ARCTIC_WHITE-ASSY BODYSHELL COMPLETE PAI	TATA spare parts
55236010Z145BN	ASSY BODYSHELL COMPLETE PAINTED MAGIC LH	TATA spare parts
55236010Z145CN	ASSY BODYSHELL COMPLETE PAINTED MAGIC LH	TATA spare parts
55236010Z145FD	ASSY BODYSHELL COMPLETE PAINTED MAGIC LH	TATA spare parts
552360110120BF	ASSY. CABIN BARE W/FRAME ACE WHITE BS4	TATA spare parts
552360110120HF	ASSY BODY SHELL COMP ACE FACELIFT CNG BS	TATA spare parts
552360110120HU	ASSY BODY SHELL COMP ACE FACELIFT CNG BS	TATA spare parts
552360110120JS	ASSY BODY SHELL TITANIUM WH	TATA spare parts
552360110129CN	IVORY WHITE-ASSY BODY SHELL COMPLETE(PAI	TATA spare parts
552360110129FW	ASSY BODY SHELL COMPLETE PAINTED- IVORY	TATA spare parts
552360110129HU	AZURE_BLUE-ASSY BODY SHELL COMPLETE(PAIN	TATA spare parts
552360110141BF	ARCTIC WHITE-ASSY BODY SHELL COMPLETE PA	TATA spare parts
552360110141FD	BODY SHELL SK GOLDEN YELLOW- COMPLETE PA	TATA spare parts
552360110141G3	ASSY BODYSHL COMP PAINTED PC FL DICOR	TATA spare parts
552360110141HF	METEOR_SILVR-ASSY BODYSHL COMP PAINTED	TATA spare parts
552360110141HS	BODY SHELL LASER RED - COMPLETE PAINTED	TATA spare parts
552360110141IC	BODY SHELL BLAZING RED - COMPLETE PAINTE	TATA spare parts
552360110153BF	BODY SHELL ASSY COMPLETE PAINTED ARCTIC	TATA spare parts
552360110160	BODY SHELL ASSY	TATA spare parts
552360110161	ASSY BODYSHELL COMP PC DICOR TCIC FL BS4	TATA spare parts
552360110196BF	ASSY BODY SHELL COMPLETE PAINTED-ACE EX	TATA spare parts
552360110196BU	ASSY BODY SHELL COMPLETE PAINTED-ACE EX	TATA spare parts
552360110196CN	ASSY BODY SHELL COMPLETE PAINTED-ACE EX	TATA spare parts
552360110196HU	ASSY BODY SHELL COMPLETE PAINTED-ACE EX	TATA spare parts
552360110217BF	ARCTIC_WHITE-ASSY BODYSHL COMP(PAINTED)	TATA spare parts
552360110217FW	ASSY BODYSHELL COMPL ACE TCIC FL BS4	TATA spare parts
55236011Z104BF	ARCTIC_WHITE-ASSY BODYSHELLPAINTED	TATA spare parts
552360200101BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED	TATA spare parts
552360200101CN	ASSY. BODYSHELL PAINTED IRISH CREAM BS4	TATA spare parts
552360200101JS	TITANIUM_WH-BODY SHELL ASSY PAINTED	TATA spare parts
552360200102	BODY SHELL ASSY WITH DOOR	TATA spare parts
552360600101	ASSY DASHBOARD CROSS MEMBER MAGIC LHD	TATA spare parts
552360600102	ASSY. DASHBOARD C/MEMBER ACE FL BS2/3/4	TATA spare parts
552360600117	ASSYBRACKETSUPPORTD/BC/MLHFACELIFT	TATA spare parts
552360600119	ASSY CCB ACE FACELIFT LHD	TATA spare parts
552360600131	ASSY DASHBOARD CROSS MEMBER	TATA spare parts
552361200101	ASSY REAR CROSS MEMBER	TATA spare parts
552361200106	ASSY BUMPER SIDE LOWER MTG LH	TATA spare parts
552361200107	ASSY BUMPER SIDE LOWER MTG RH	TATA spare parts
552361200108	ASSY REAR SILL COMPLETE FACELIFIT	TATA spare parts
552361203301	BUMPER SIDE UPP MTG BRKT	TATA spare parts
552361600101	ASSY CAB CLOSURE BKT LH	TATA spare parts

552361600104	ASSY WHEEL ARCH INNER RH	TATA spare parts
552361600128	ASSY ENGINE COVER ACE DICOR	TATA spare parts
552361600131	ASSY PANEL FRONT FLOOR FACELIFT	TATA spare parts
552361600134	COVER ASSY ENGINE BS6	TATA spare parts
552361600181	ASSYBUMPERMTGFRONTCENTERFACELIFT	TATA spare parts
552361600184	ASSY WHEEL ARCH INNER LH FACELIFT	TATA spare parts
552361600185	ASSY VERTICAL FLOOR COMPLETE FACELIFT	TATA spare parts
552361600186	ASSY WHEEL ARCH INNER LH FACELIFT-PC	TATA spare parts
552361600187	ASSY PANEL FRONT FLOOR FACELIFT(PC)	TATA spare parts
552361600188	ASSY BKT GSL COVER MTG	TATA spare parts
552361600232	ASSY FRONT FLOOR	TATA spare parts
552361600249	ASSY WHEEL ARCH INNER LH	TATA spare parts
552361600253	ASSY WHEELARCH INNER LH	TATA spare parts
552361600269	WHEEL ARCH ASSY INNER-LH	TATA spare parts
552362000103	ASSY FRONT WALL FACELIFT	TATA spare parts
552362000111	ASSY FRONTWALL ACE 2.1T DICOR 800CC TCIC	TATA spare parts
55236200011135	ASSY FRONTWALL CED COATED	TATA spare parts
552362000113	ASSY FRONT WALL	TATA spare parts
552362000114	ASSY FRONT WALL	TATA spare parts
55236200011735	ASSY FRONTWALL CED COATED	TATA spare parts
552362200105	ASSY BUMPER MTG BKT LH FACELIFT	TATA spare parts
552362208204	HEADLAMP MTG BKT LH FACELIFT	TATA spare parts
552362500101	ASSY PANEL WINDSHIELD SUPPORT FACELIFT	TATA spare parts
552362508201	PANEL WINDSHIELD SUPPORT FACELIFT	TATA spare parts
552362600113	ASSY REINF FOR STEERING MTG BKT FACELIFT	TATA spare parts
552362603307	SUPPORT BRACKET DASHBOARD LH	TATA spare parts
552362603308	SUPPORT BRACKET DASHBOARD RH	TATA spare parts
552362608216	PANEL CONTROL MTG FACELIFT	TATA spare parts
552363000101	ASSY. SIDE WALL LH FACELIFT BS3/4	TATA spare parts
552363000102	ASSY. SIDE WALL RH FACELIFT BS3/4	TATA spare parts
552363000103	ASSY SIDE WALL COMPLETE-LH (PC) FACELIFT	TATA spare parts
552363000104	ASSY SIDE WALL COMPLETE-RH (PC) FACELIFT	TATA spare parts
552363000105	ASSY. SIDE WALL LH BS3/4	TATA spare parts
552363000106	ASSY. SIDE WALL RH BS3/4	TATA spare parts
552363000107	ASSY SIDE WALL COMPLETE LH CNG FACELIFT	TATA spare parts
552363000108	ASSY SIDEWALL COMPLETE LH FL DICOR	TATA spare parts
55236300010835	CED-ASSY SIDEWALL COMPLETE LH FL DICOR	TATA spare parts
552363100109	ASSY BKT DASH BOARD C/M MTG RH FACELIFT	TATA spare parts
552363100110	ASSY A PILLAR REINF RH FACELIFT	TATA spare parts
552363100111	ASSY BKT DASH BOARD C/M MTG LH FACELIFT	TATA spare parts
552363100112	ASSY A PILLAR REINF LH FACELIFT	TATA spare parts
552363200103	ASSY BUMPER LOWER SIDEWALL MTG BKT LH	TATA spare parts
552363200104	ASSY HEADLAMP LOCATOR BKT FACELIFT	TATA spare parts
552363200105	ASSY BUMPER LOWER SIDEWALL MTG BKT RH	TATA spare parts
552363203301	BUMPER UPP MTG BRKT LH	TATA spare parts
552363203302	BUMPER UPP MTG BRKT RH	TATA spare parts
552363208203	FRONT PANEL LOWER MTG BKT FACELIFT	TATA spare parts

552363600110	ASSY SIDE WALL INNER LH FACELIFT BS6	TATA spare parts
552363600128	ASSY SIDE WALL INNER LH MAGIC DICOR BS6	TATA spare parts
552363700103	ASSY SILL OUTER RH MAGIC LHD AFRICA BS6	TATA spare parts
552363708216	PANEL SIDE WALL OUTER LH MAGIC DICOR BS6	TATA spare parts
55236370C201	PANEL FRONT SIDE OUTER RH MAGIC LHD AFRI	TATA spare parts
55236370Z101	ASSY FRONT SIDE OUTER RH MAGIC LHD	TATA spare parts
55236370Z102	ASSY SIDE WALL REAR COMPLETE RH	TATA spare parts
55236370Z103	ASSY SILL OUTER RH MAGIC LHD AFRICA(COAT	TATA spare parts
55236370Z104	ASSY SIDE REAR OUTER RH MAGIC LHD AFRICA	TATA spare parts
552364000109	REAR WALL ASSY	TATA spare parts
552367100101	WINDSHIELD GLASS BS2/3/4	TATA spare parts
552367106302	BOTTOM SUPPORT WINDSHIELD	TATA spare parts
552367106303	WINDSHIELD MOULD BS2/3/4	TATA spare parts
552367800103	ASSY REAR SLIDING WINDOW	TATA spare parts
552368206302	TORQUE TAPE REAR DOOR HINGE BS6	TATA spare parts
552368406301	ENGINE COVER INSULATION Q-SHIELD	TATA spare parts
552368406304	WHEEL ARCH INSULATION LH	TATA spare parts
552368406305	WHEEL ARCH INSULATION RH	TATA spare parts
552368406306	INSULATION PAD LH	TATA spare parts
552368406307	INSULATION PAD RH	TATA spare parts
552368406308	OIL FILLING COVER INSULATION Q-SHIELD	TATA spare parts
552368406309	ENGINE COVER CARPET	TATA spare parts
552368406310	OIL FILLING COVER CARPET ACE DICOR	TATA spare parts
552368406312	INSULATION PAD LH FACELIFT	TATA spare parts
552368406316	ENGINE COVER CARPET WITH INSULATION-ACE	TATA spare parts
552368406322	INSULATION ENGINE COVER DICOR	TATA spare parts
552368406323	OIL FILLING COVER INSULATION DICOR	TATA spare parts
552368406327	INSULATION REAR CROSS MEMBER DICOR	TATA spare parts
552368406328	CARPET REAR CROSS MEMBER DICOR	TATA spare parts
552368406331	CARPET ENGINE COVER	TATA spare parts
552368406332	"INSULATION, CAB 2MTG RH"	TATA spare parts
552368406333	CARPET CROSS MEMBER REAR	TATA spare parts
552368406334	CARPET MIDDLE	TATA spare parts
552368406335	INSULATION PAD LH	TATA spare parts
552368406336	INSULATION PAD RH	TATA spare parts
552368406355	COVER	TATA spare parts
552368406358	INSULATION PAD LH BS6	TATA spare parts
552368406361	CARPET-CROSS MEMBER-REAR BS6	TATA spare parts
552368706317	VERTICAL WALL INSULATION	TATA spare parts
552368706320	FRONT WALL CARPET FACELIFT	TATA spare parts
552368706321	PVC MATT WITH KINIFOAM FRONT FLOOR ACE F	TATA spare parts
552368706322	VERTICAL WALL INSULATION UPPER	TATA spare parts
552368706323	VERTICAL WALL INSULATION LOWER	TATA spare parts
552368706324	VERTICAL WALL CARPET DRIVER SIDE ACE DIC	TATA spare parts
552368706324C7	GRANIT_BLACK-VERTICAL WALL CARP DR ACE D	TATA spare parts
552368706325	VERTICAL WALL CARPET CO DRIVER SIDE ACE	TATA spare parts
552368706325C7	GRANIT_BLACK-VERTICAL WALL CARPET CO DR	TATA spare parts

552368706326	COVER VIN PLATE	TATA spare parts
552368706327	VERTICAL WALL CARPET ACE FACELIFT	TATA spare parts
552368706329	FLOOR CARPET WITH INSULATION	TATA spare parts
552368706332	VERTICAL WALL CARPET ACE CNG FACELIFT	TATA spare parts
552368706334	FRONT WALL CARPET MAGIC VAN	TATA spare parts
552368706337	FRONT WALL CARPET 2.1 TON DICOR	TATA spare parts
552368706348	FLOOR CARPET WITH INSULATION	TATA spare parts
552368706348C7	GRANIT_BLACK-FLOOR CARPET WITH INSULATION	TATA spare parts
552368900101	ASSY. DASHBOARD BS3/4	TATA spare parts
552368900102	ASSY SPEAKER GRILL LH	TATA spare parts
552368900108	ASSY BEZEL COMPLETE	TATA spare parts
552368900109	ASSY SPEAKER GRILL RH	TATA spare parts
552368900110	ASSY DASHBOARD MAGIC LHD	TATA spare parts
552368900111	ASSY DASHBOARD LHD	TATA spare parts
552368900114	ASSY ENGINE SHIELD CONSOLE	TATA spare parts
552368900115	ASSY DASHBOARD WITH DEMIST	TATA spare parts
552368900117	ASSY DASHBOARD MAGIC FACELIFT	TATA spare parts
552368900121	ASSY DASHBOARD ACE FL DICOR EURO I	TATA spare parts
552368900122	ASSY SPEAKER GRILL LH	TATA spare parts
552368900123	ASSY SPEAKER GRILL RH	TATA spare parts
552368900127	AIR VENT ASSY	TATA spare parts
552368906303	GLOVE BOX LID	TATA spare parts
552368906304	COVER DASHBOARD BS6	TATA spare parts
552368906307	NACELLE UPPER	TATA spare parts
552368906308	NECELLE LOWER	TATA spare parts
552368906311	AIR VENT DUCT LH	TATA spare parts
552368906312	AIR VENT DUCT RH	TATA spare parts
552368906313	SPEAKER GRILL LH	TATA spare parts
552368906314	SPEAKER GRILL RH	TATA spare parts
552368906322	COVER BFR RESERVOIR	TATA spare parts
552368906323	COVER NO LOSS TANK	TATA spare parts
552368906324	VENT DUCT INNER COVER RH	TATA spare parts
552368906325	VENT DUCT INNER COVER LH	TATA spare parts
552368906326	GLOVE BOX LID REINFORCEMENT	TATA spare parts
552368906327	IP MTG CAP TOP LH	TATA spare parts
552368906328	IP MTG CAP TOP RH	TATA spare parts
552368906329	HINGE PIN	TATA spare parts
552368906330	GLOVE BOX LID REINFORCEMENT SPRING	TATA spare parts
552368906331	DUCT GASKET LH	TATA spare parts
552368906332	DUCT GASKET RH	TATA spare parts
552368906333	PAD AUDIO SUPPORT	TATA spare parts
552368906334	BEZEL DIGITAL CLOCK	TATA spare parts
552368906336	BUMP STOP	TATA spare parts
552368906339	COVER NO LOSS TANK	TATA spare parts
552368906340	MUSIC SYSTEM COVER	TATA spare parts
552368906343	DUMMY COVER TWO PACK SWITCH	TATA spare parts
552368906344	GLOVE BOX LID LHD	TATA spare parts

552368906346	NACELLE UPPER LHD	TATA spare parts
552368906347	NACELLE LOWER LHD	TATA spare parts
552368906353	REINF DASHBOARD FRT LH	TATA spare parts
552368906354	REINF DASHBOARD FRT RH	TATA spare parts
552368906355	GLOVE BOX LOCK BS6	TATA spare parts
552368906357	CAP FOR ENGINE COVER PLASTIC CONSOLE BS6	TATA spare parts
552368906358	SUPPORT DASHBOARD SPRING	TATA spare parts
552368906359	CROSS LINK FOAM DASHBOARD SUPPORT	TATA spare parts
552368906363	DEMIST GRILL RH	TATA spare parts
552368906364	DEMIST GRILL CENTER	TATA spare parts
552368906374	GLOVE BOX LOCK BARREL ASSY BS6	TATA spare parts
552368906376	GLOVE BOX LID	TATA spare parts
552368906377	GLOVE BOX LID REINF	TATA spare parts
552368906380	COVER BRAKE FLUID RESERVOIR	TATA spare parts
552368906381	COVER NO LOSS TANK	TATA spare parts
552368906382	IP MTG CAP TOP LH	TATA spare parts
552368906383	IP MTG CAP TOP RH	TATA spare parts
552368906392	COVER AIR VENT DASHBOARD BS6	TATA spare parts
552368996302	"INSULATION, LOAD BODY COVER"	TATA spare parts
552369106303	PAD SIDE WALL REAR INNER RH MAGIC LHD AF	TATA spare parts
552369106304	A PILLAR TRIM UPPER RH MAGIC LHD	TATA spare parts
552369106350	TRIM PAD FRONT LH FOR MAGIC FACELIFT	TATA spare parts
552369106351	PAD SIDE WALL INNER RH FOR MAGIC FACELIF	TATA spare parts
552369106352	PAD SIDE WALL RR INR LH MAGIC FACELIFT	TATA spare parts
552369106355	COVER HIGH MOUNTED STOP LAMP CUTOUT BS6	TATA spare parts
552369106356	PAD SIDE WALL REAR INNER RH	TATA spare parts
552369206301	PLASTIC MEMBRANE	TATA spare parts
552369406301	REAR WALL LINER	TATA spare parts
552369500101	ASSY HEADLINER REAR MAGIC FACELIFT	TATA spare parts
552369506301	HEAD LINER FRONT	TATA spare parts
552369506301AQ	LINEN-HEAD LINER FRONT ACE EV	TATA spare parts
552369506306	ANTI FLUTTER STRIP ROOF FRONT BS6	TATA spare parts
552369506307	ANTI FLUTTER STRIP ROOF REAR BS6	TATA spare parts
552370000114	ASSYLOADBODYCOMPLETESIDEXFIXFACELIFT	TATA spare parts
552370000115BF	ARCTIC_WHITE-ASSY 2.2M LOAD BODY PAINTED	TATA spare parts
552370000115CN	LOAD BODY PAINTED FACELIFT IRISH CREAM	TATA spare parts
552370000115FW	IVORY_WHITE-ASSY 2.2M LOAD BODY PAINTED	TATA spare parts
552370000115GC	LOAD BODY CASTLE GREY-ASSY 2.2M PAINTED	TATA spare parts
552370000115HO	NEON_RUSH-ASSY 2.2M LOAD BODY PAINTED FA	TATA spare parts
552370000115HU	LOAD BODY PAINTED FACELIFT AZURE BLUE	TATA spare parts
552370000115JS	TITANIUM_WH-ASSY 2.2M LOAD BODY PAINTED	TATA spare parts
552370000119BF	LOADBODY COMP FLOOR-ACE LHD ARTIC WHITE	TATA spare parts
552370000122	ASSY LOADBODY SHELL	TATA spare parts
552370000124BF	LOAD BODY COMP (PAINTED) ARTIC WHITE	TATA spare parts
552370000124G3	ASSY LOADBODY COMP DICOR (PAINTED)	TATA spare parts
552370000124HU	LOAD BODY AZURE_BLUE COMP DICOR	TATA spare parts
552370000129BF	ASSY LOADBODY SHELL ACE FACELIFT-CNG(PAI	TATA spare parts

552370000129HF	ASSY LOADBODY SHELL ACE FACELIFT-CNG(PAI	TATA spare parts
552370000129HU	ASSY LOADBODY SHELL ACE FACELIFT-CNG(PAI	TATA spare parts
552370000132BF	ARCTIC_WHITE-ASSY LOADBODY SIDE DROP PAI	TATA spare parts
552370000132BU	JET_BLACK-ASSY LOADBODY SIDE DROP PAINTE	TATA spare parts
552370000132CN	IRISH_CREAM-ASSY LOADBODY SIDE DROP PAIN	TATA spare parts
552370000132FW	ASSY LOAD BODY SIDE DROP PAINTED - IVORY	TATA spare parts
552370000132FZ	ASSY LOAD BODY SIDE DROP PAINTED - CHAMP	TATA spare parts
552370000132HU	LOADBODY SIDE DROP AZURE BLUE	TATA spare parts
552370000132IC	ASSY LOADBODY SIDE DROP PAINTED FACELIFT	TATA spare parts
552370100107	ASSY TAILGATE SKIRT (0.75T)-LOAD BODY FA	TATA spare parts
552370100126	ASSY LOADBODY FLOOR SIDE DROP FACELIFT	TATA spare parts
552370100127	ASSY TAILGATE SKIRT	TATA spare parts
552370100128	ASSY TAILGATE LOAD BODY OPTIMIZE BS6	TATA spare parts
552370100146	REAR SKIRT ASSY ACE EV	TATA spare parts
552370200101	BRACKET ASSY FRONT WALL LOAD BODY MTG	TATA spare parts
552370308203	SIDE WALL LH	TATA spare parts
552370308204	SIDE WALL RH	TATA spare parts
552370400101	ASSY TAILGATE LATCH (HIGH DECK LOADBODY)	TATA spare parts
552370500101	FRAME ASSY-REAR BS6	TATA spare parts
552370906302	RUBBER GROMMET	TATA spare parts
552372000104	ASSY. FRT DOOR SHELL LH FACELIFT BS2/3/4	TATA spare parts
552372000106	ASSY. FRT DOOR SHELL RH FACELIFT BS2/3/4	TATA spare parts
552372000107	ASSY FRONT DOOR SHELL COMPLETE(CED COATE	TATA spare parts
552372000109	ASSY FRONT DOOR SHELL COMPLETE-LH ACE EX	TATA spare parts
552372000112	ASSY FRONT DOOR SHELL COMPLETE RH ACE EX	TATA spare parts
55237200Z104	ASSY FRONT DOOR SHELL COMP LH ACE FACELI	TATA spare parts
55237200Z107	ASSY FRONT DOOR SHELL COMP RH -FACELIFT	TATA spare parts
55237200Z109	ASSY FRONT DOOR SHELL COMPLETE LH	TATA spare parts
55237200Z112	ASSY FRONT DOOR SHELL COMPLETE RH	TATA spare parts
552372200112	ASSY FRONT DOOR INNER LH FACLIFT	TATA spare parts
552372200123	ASSY FRONT DOOR INNER RH FACELIFT	TATA spare parts
552372200125	ASSY DOOR PULL MTG BKT FACELIFT	TATA spare parts
552372200126	ASSY DOOR PAD MTG BKT FACELIFT	TATA spare parts
552372208203	REINF FRONT DOOR PULL LH FACELIFT	TATA spare parts
552372300117	KIT-ASSY. LOCK SET W/FUEL CAP BS2/3/4	TATA spare parts
552372300120	KIT ASSY LOCK SET WITH FUEL CAP PC	TATA spare parts
552372300121	BLANK KEY ACE EV RHD	TATA spare parts
552372300124	ASSY LINK INNER HANDLE LH	TATA spare parts
552372300125	ASSY LINK INNER HANDLE RH	TATA spare parts
552372300126	KIT-LOCK SET ASSY BS6-PH2	TATA spare parts
552372300128	LOCK BARREL ASSY FRONT DOOR RH BS6	TATA spare parts
552372300130	KIT-LOCK SET ASSY BS6-PH2	TATA spare parts
552372300132	KIT-LOCK SET ASSY BS6-PH2	TATA spare parts
552372536301	DUST SEAL LH BS6	TATA spare parts
552372536302	DUST SEAL MOULD FRONT DOOR BS6	TATA spare parts
552372536303	PRIMARY DOOR SEAL FRONT DOOR LH BS6	TATA spare parts
552372536304	PRIMARY DOOR SEAL FRONT DOOR RH BS6	TATA spare parts

552372700101	ASSY. DOOR PAD LH BS2/3/4	TATA spare parts
552372700102	ASSY. DOOR PAD RH BS2/3/4	TATA spare parts
552372706301	DOOR TRIM LH	TATA spare parts
552372706302	DOOR PAD LH	TATA spare parts
552372706303	DOOR PULL CUP LH	TATA spare parts
552372706304	CAP DOOR TRIM LH	TATA spare parts
552372706305	DOOR TRIM RH	TATA spare parts
552372706306	DOOR PAD RH	TATA spare parts
552372706307	DOOR PULL CUP RH	TATA spare parts
552372706308	CAP DOOR TRIM RH	TATA spare parts
552372706309	PLASTIC MENRANE FRONT DOOR LH FACELIFT	TATA spare parts
552372706310	PLASTIC MEMBRANE FRONT DOOR RH FACELIFT	TATA spare parts
552372980102	KIT-LOCK SET	TATA spare parts
552372980103	KIT-LOCK SET ASSY BS6	TATA spare parts
552372990101	KIT-LOCK WITH FUEL CAP	TATA spare parts
552373002102	ASSY REAR DOOR COMP WITH HINGES RH-MAGIC	TATA spare parts
552373306002	LINK INNER HANDLE TO LATCH RH MAGIC LHD	TATA spare parts
552373306003	LINK POP UP KNOB TO LATCH RH MAGIC LHD A	TATA spare parts
552373306301	REAR DOOR TOP COVER RH MAGIC LHD AFRICA	TATA spare parts
552373700101	ASSY PAD REAR DOOR MAGIC LHD AFRICA	TATA spare parts
552373700102	ASSY PAD REAR DOOR MAGIC FACELIFT	TATA spare parts
552374700101	ASSY PAD TAILGATE MAGIC FACELIFT	TATA spare parts
552374700102	PAD ASSY TAILGATE	TATA spare parts
552374706303	MEMBRANE TAILGATE	TATA spare parts
552379100102	ASSY TUBULAR STRUCTURE COMPLETE MAGIC LH	TATA spare parts
552379200102	ASSY CANOPY	TATA spare parts
552381000101	REAR ENGINE COVER ASSY TOP	TATA spare parts
552381100103	ASSY HEADLAMP COVER LH FACELIFT	TATA spare parts
552381100104	ASSY HEADLAMP COVER RH FACELIFT	TATA spare parts
552381100107	SUNVISOR LH MAGIC LHD	TATA spare parts
552381100108	ASSY. ORVM LH FACELIFT BS2/3/4	TATA spare parts
552381100109	ASSY. ORVM RH FACELIFT BS2/3/4	TATA spare parts
552381100113	ASSY SUNVISOR WITH TWO POINT MTG LH-BARL	TATA spare parts
552381100114	ASSY SUNVISOR WITH TWO POINT MTG LH-LIGH	TATA spare parts
552381100115	ASSY SUNVISOR WITH TWO POINT MTG RH-BARL	TATA spare parts
552381100116	ASSY SUN VISOR WITH TWO POINT MTG RH LIG	TATA spare parts
552381100123	ORVM ASSY LH	TATA spare parts
552381100123C7	GRANIT_BLACK-ORVM ASSY LH BS6-PH2	TATA spare parts
552381100124	ORVM ASSY RH	TATA spare parts
552381100124C7	GRANIT_BLACK-ORVM ASSY RH BS6-PH2	TATA spare parts
552381106306	FRONT WHEEL GUARD LH	TATA spare parts
552381106307	FRONT WHEEL GUARD RH	TATA spare parts
552381106310	DEMIST COVER MAGIC VAN	TATA spare parts
552381106311	SUNVISOR HINGE CLIP MTG LH-BARLEY BIEGE	TATA spare parts
552381106312	SUNVISOR HINGE CLIP MTG RH-BARLEY BIEGE	TATA spare parts
552381106313	SUNVISOR HINGE CLIP MTG LH-LIGHT GREY	TATA spare parts
552381106314	SUNVISOR HINGE CLIP MTG RH-LIGHT GREY	TATA spare parts

552381106314AQ	LINEN-SUNVISOR HINGE CLIP MTG RH-LIGHT G	TATA spare parts
552381106319	FOAM HEADLAMP GAP LH	TATA spare parts
552381106320	FOAM HEADLAMP GAP RH	TATA spare parts
552381106321	ORVM COVER LH	TATA spare parts
552381106322	ORVM COVER RH	TATA spare parts
552381106323	BLACK TAPE PANEL FRONT FLOOR	TATA spare parts
552381207707	GROMMET FOR HEADLAMP COVER_2 BS6-PH2	TATA spare parts
552381300103	ASSY GSL BELLOW WITH HOLDER	TATA spare parts
552381300104	ASSY GSL BELLOW WITH 5 SPPED GSL KNOB	TATA spare parts
552381300105	COVER ASSY GSL FOR FACELIFT LHD	TATA spare parts
552381306301	REAR ENGINE COVER BOTTOM-MAGIC BS IV	TATA spare parts
552381306302	REAR ENGINE COVER TOP-MAGIC BSIV	TATA spare parts
552381306303	REAR CLOSING COVER	TATA spare parts
552381306304	ENGINE COVER RRWALL TO LOADBODY ACE DICO	TATA spare parts
552381306320	AIR DEFLECTOR	TATA spare parts
552381990101	KIT-INSULATION ECU COVER	TATA spare parts
552382400106	ASSY. WIPER BLADE DRIVER BS2/3/4/6	TATA spare parts
552382400107	ASSY WIPER ARM DRIVER BS4	TATA spare parts
552382400108	ASSY. WIPER BLADE CO DRIVER BS2/3/4	TATA spare parts
552382400109	ASSY WIPER ARM CO DRIVER BS4	TATA spare parts
552382400111	ASSY. WIPER ARM AND BLADE DRIVER BS2/3/4	TATA spare parts
552382400112	ASSY ARM AND BLADE CO DRIVER	TATA spare parts
552382400113	ASSY. WIPER MOTOR KIT & LINKAGES BS2/3/4	TATA spare parts
552382400121	ASSY. WIPER MOTOR W/BACKET BS2/3/4	TATA spare parts
552382400122	ASSY. WIPER LINKAGE SYSTEM BS2/3/4	TATA spare parts
552382400129	KIT WASHER BOTTLE	TATA spare parts
552382400130	ASSY WIPER MOTOR BS6	TATA spare parts
552382400131	ASSY WIPER MOTOR BKT BS6	TATA spare parts
552382400132	ASSY WIPER MOTOR WITH BKT	TATA spare parts
552382400133	ASSY WIPER LINKAGES	TATA spare parts
552382400134	ASSY WIPER MOTOR WITH BKT AND LINKAGES	TATA spare parts
552382400138	ASSY WIPER ARM AND BLADE DRIVER LHD	TATA spare parts
552382400141	ASSY WIPER ARM & BLADE CO-DRIVER LHD	TATA spare parts
552382400142	ASSYWIPERMOTORWITHBKTACEFLLD	TATA spare parts
552382400144	KIT WIPER MTR WITH BKT-LINKGS ACE FL LHD	TATA spare parts
552382400145	ASSY WIPER MOTOR BS6	TATA spare parts
552382400146	MOUNTING BRACKET BS6-PH2	TATA spare parts
552382400148	WIPER LINK ASSY WITH MOTOR BS6	TATA spare parts
552382406304	WIPER GROMMET ON SUPPORT PANEL	TATA spare parts
552382406305	GROMMET DRIVER SIDE	TATA spare parts
552382406306	GROMMET CO DRIVER SIDE	TATA spare parts
552382407501	RUBBER GROMMET-WIPER KIT	TATA spare parts
552382409902	GEARBOX BRUSHPLATE AND ASSY	TATA spare parts
552382409903	ARMATURE ASSY	TATA spare parts
552382409905	GEAR AND SLIP RING ASSY	TATA spare parts
552382409906	ROTARY LINK ASSY	TATA spare parts
552382409907	COVER PLATE AND BRUSH PLATE ASSY	TATA spare parts



552382409908	FASTNERS AND SEALING KIT	TATA spare parts
552382409909	ARMATURE ASSY BS6-PH2	TATA spare parts
552382409910	BRUSH HOLDER ASSY BS6-PH2	TATA spare parts
552382409911	GEAR WHEEL ASSY BS6-PH2	TATA spare parts
552382409912	CRANK WHEEL BALL ASSY - FL BS6-PH2	TATA spare parts
552382409931	BRACKET BS6-PH2	TATA spare parts
552382900105	KIT-WASHER SYSTEM	TATA spare parts
552382909901	WASHER BOTTLE BS6	TATA spare parts
552383406301	BLOWER ASSEMBLY	TATA spare parts
552383407501	GROMMET DRAIN PIPE	TATA spare parts
552384000102	ASSY KIT HIGH DECK LOAD BODY	TATA spare parts
552384000103	ASSY HIGHDECK LOADBODY(PAINTED)	TATA spare parts
552384000103CN	LOAD BODY HIGH DECK (PAINTED)	TATA spare parts
552384000104	ASSY TAILGATE HANDLE KIT LH	TATA spare parts
552384000105	ASSY TAILGATE HANDLE KIT RH	TATA spare parts
552384000106	ASSY KIT CANOPY MTG BKT	TATA spare parts
552384300101	ASSY HIGH DECK LOADBODY	TATA spare parts
552384300117	ASSY GRILL FRONT WALL UPPER	TATA spare parts
552384308224	SIDE WALL LH BS6	TATA spare parts
552384308226	FRONT WALL BS6	TATA spare parts
552384308228	FRONT BOTTOM COVER	TATA spare parts
552384308254	LOCK PLATE HIGHDECK LOADBODY LH	TATA spare parts
552384308255	LOCK PLATE HIGHDECK LOADBODY RH	TATA spare parts
552384500109	ASSY UPPER FRAME HIGHDECK LOADBODY	TATA spare parts
552388400102	FRONT PANEL ASSY	TATA spare parts
552388400103	ASSY SIDE UPPER BRACKET LH	TATA spare parts
552388400104	ASSY SIDE UPPER BRACKET RH	TATA spare parts
552388400105	ASSY SIDE LOWER BRACKET LH	TATA spare parts
552388400106	ASSY SIDE LOWER BRACKET RH	TATA spare parts
552388408202	PANEL FRONT OUTER FACELIFT	TATA spare parts
552388408220	PANEL FRONT INNER FACELIF	TATA spare parts
552388408221	LOWER MIDDLE BRACKET LH	TATA spare parts
552388408222	MIDDLE UPPER BRACKET	TATA spare parts
552388408227	LOWER MIDDLE BRACKET RH BS6	TATA spare parts
552388500101	ASSY. FRONT BUMPER BS2/3/4	TATA spare parts
552388500101C7	GRANIT_BLACK-FRONT BUMPER ASSY BS6-PH2	TATA spare parts
552388500101FD	SK_GOLN_YELW-ASSY FRONT BUMPER	TATA spare parts
552388500101FW	ASSY FRONT BUMPER	TATA spare parts
552388500101FZ	ASSY FRONT BUMPER - CHAMPGN GOLD	TATA spare parts
552388500101G3	FRONT BUMPER PORCLN_WHITE	TATA spare parts
552388500101GM	ASSY FRONT BUMPER	TATA spare parts
552388500101HF	ASSY FRONT BUMPER	TATA spare parts
552388500101HU	FRONT BUMPER AZURE_BLUE	TATA spare parts
552388500101IC	ASSY FRONT BUMPER	TATA spare parts
552388500101J7	CHILL_METLIC-ASSY FRONT BUMPER	TATA spare parts
552388500102G3	PORCLN_WHITE-FRONT BUMPER ASSY	TATA spare parts
552388500102HM	ASSY. FRONT BUMPER URBAN BRONZE BS3/4	TATA spare parts

552388506304	FRONT BUMPER¿ GRILL OUTSIDE FITMENT	TATA spare parts
552388506310	T EMBLEM	TATA spare parts
552388506311	REFLECTIVE TAPE FOR ACE FACELIFT	TATA spare parts
552388506312	BUMPER BLACK TAPE	TATA spare parts
552388509901	CLIP	TATA spare parts
552388509902	CLIP FRONT BUMPER GRILLE	TATA spare parts
552388600101	ASSY REAR BUMPER	TATA spare parts
552388606302	REAR BUMPER TOW HOOK COVER	TATA spare parts
552388606305	MIDDLE MTG BRKT RR BUMPER LH BS6-PH2	TATA spare parts
552388606306	MIDDLE MTG BRKT RR BUMPER RH BS6-PH2	TATA spare parts
552388800101	ASSY. LEAF SCREEN TRIM BS2/3/4	TATA spare parts
552388800104	ASSY. GRILL BS2/3/4	TATA spare parts
552388800104ZZ	CLRPART_ASSY-GRILL ASSY BS6-PH2	TATA spare parts
552388800114	ASSY LEAF SCREEN TRIM	TATA spare parts
552388806301	LEAF SCREEN TRIM BS6	TATA spare parts
552388806301C7	GRANIT_BLACK-LEAF SCREEN TRIM BS6-PH2	TATA spare parts
552388806303	FRONT PANEL OUTER BS2/3/4	TATA spare parts
552388806303BF	FRONT PANEL OUTER ARCTIC WHITE BS2/3/4	TATA spare parts
552388806303BU	PANEL¿ FRONT OUTER	TATA spare parts
552388806303CN	FRONT PANEL OUTER BS2/3/4	TATA spare parts
552388806303FD	PANEL¿ FRONT OUTER	TATA spare parts
552388806303FW	PANEL FRONT OUTER	TATA spare parts
552388806303G3	PANEL¿FRONT OUTER	TATA spare parts
552388806303GM	PANEL FRONT OUTER	TATA spare parts
552388806303HF	PANEL¿ FRONT OUTER	TATA spare parts
552388806303HS	PANEL FRONT OUTER	TATA spare parts
552388806303HU	PANEL FRONT OUTER AZURE BLUE BS2/3/4	TATA spare parts
552388806303IC	PANEL FRONT OUTER	TATA spare parts
552388806303J7	PANEL¿ FRONT OUTER	TATA spare parts
552388806303JS	TITANIUM_WH-PANEL FRONT OUTER BS6-PH2	TATA spare parts
552388806307	PLENUM SEAL	TATA spare parts
552388806311	FOAM FRESH AIR DUCT-LH	TATA spare parts
552388806312	FOAM FRESH AIR DUCT-RH	TATA spare parts
552391000101	ASSY DRIVER SEAT RH CELEBRATION VEHICLE	TATA spare parts
552391000105	ASSY DRIVER SEAT COMP ACE LHD	TATA spare parts
552391000107	ASSY DRIVER SEAT COMP MAGIC LHD WO HDRES	TATA spare parts
552391000108	ASSY DR-SEAT WITH HEAD REST ACE EV UK	TATA spare parts
552391000111	ASSY¿ DRIVER SEAT W/O HEAD REST ACE FACE	TATA spare parts
552391000113	ASSY DRIVER SEAT W/O HEADREST ACE FACELF	TATA spare parts
552391000115	ASSY DR-SEAT	TATA spare parts
552391000116	ASSY DRIVER SEAT MAGIC FACELIFT	TATA spare parts
552391000117	ASSY DRIVER SEAT MAGIC VAN DICOR	TATA spare parts
552391000124	DRIVER SEAT ASSY	TATA spare parts
552391000126	ASSY DR SEAT COMP FACELFT MAGIC DICOR	TATA spare parts
552391000127	DRIVER SEAT ASSY WITH HR ACE FL EURO I	TATA spare parts
552391700101	CORNER¿SEAL¿RH BS6	TATA spare parts
552391700103	DICOR BEADING BS6	TATA spare parts

552391700104	PVC BEADING BS6	TATA spare parts
552391700105	DRIVER SEAT PLASTIC COVER KIT RH FL BS6-	TATA spare parts
552391900102	DRIVER SEAT ASSY MAGIC SLIDER KIT BS6-PH	TATA spare parts
552391900103	PAN KIT RH DICOR BS6	TATA spare parts
552391900104	PAN KIT LH DICOR BS6	TATA spare parts
552391900105	PAN RH KIT BS6	TATA spare parts
552391900106	PAN LH KIT BS6	TATA spare parts
552391900107	HR BEZEL KIT FACELIFT BS6-PH2	TATA spare parts
552391900108	HR KIT FACELIFT BS6	TATA spare parts
552391980104	INSULATION SEAT PAN RH	TATA spare parts
552392000103	ASSY REAR FACING SEAT MAGIC FACELIFT	TATA spare parts
552392000104	SEAT TWO SEATER REAR FACING SEAT FACELIF	TATA spare parts
552392000107	ASSY FRONT FACING SEAT MAGIC FACELIFT	TATA spare parts
552392000109	ASSY 3RD ROW FF FACELIFT WITH SBA CNG	TATA spare parts
552392000110	ASSY FRONT FACING SEAT MAGIC VAN	TATA spare parts
552392000111	ASSY 2ND ROW SEAT COMP MAGIC VAN	TATA spare parts
552392500107	ASSY 2 POINT LAPBELT	TATA spare parts
552394000101	ASSY CO-DRIVER SEAT CELEBRATION VEHICLE	TATA spare parts
552394000105	ASSY CO-DR SEAT WITH HEADREST ACE EV UK	TATA spare parts
552394000106	ASSY CO-DRIVER SEAT MAGIC LHD WO HDREST	TATA spare parts
552394000109	ASSY CO-DRIVER SEAT W/O HEAD REST ACE FA	TATA spare parts
552394000111	ASSY CO DRIVER SEAT W/O HEADREST	TATA spare parts
552394000113	ASSY CO-DRIVER¿ SEAT	TATA spare parts
552394000114	ASSY CO-DRIVER SEAT MAGIC VAN DICOR	TATA spare parts
552394000115	ASSY CO-DRIVER SEAT- MAGIC FACELIFT	TATA spare parts
552394000125	ASSY CO-DR SEAT COMP MAGIC DICOR FACELFT	TATA spare parts
552394000126	CO-DRIVER SEAT ASSY ACE FL DICOR EURO I	TATA spare parts
552394200102	CO-DRIVER SEAT ASSY CUSHION LH MAGIC FL	TATA spare parts
552394700101	CORNER¿SEAL¿LH BS6	TATA spare parts
552394980103	INSULATION CO-DRIVER SEAT	TATA spare parts
552399106701	GLOVEBOX SPRING SUPPORT PIN	TATA spare parts
552399506303	TRIM CLIP - PIN	TATA spare parts
552399506304	TRIM CLIP-GROMMET	TATA spare parts
552399506305	TRIM CLIP	TATA spare parts
552399508001	CR FL PAN HEAD SPECIAL SCREW M6X14 SS 84	TATA spare parts
552429108602	TABLE SPACER BS6	TATA spare parts
552429300102	ASSY PUSH ROD	TATA spare parts
552432807101	SPACER PLATE	TATA spare parts
552433108201	HOUSING END PLATE	TATA spare parts
552433408201	WHEEL END PLATE	TATA spare parts
552441105101	FLANGE YOKE	TATA spare parts
552446300101	ASSY. TIE ROD	TATA spare parts
552446304104	TIE ROD ARM (RH)	TATA spare parts
552446304105	TIE ROD ARM (LH)	TATA spare parts
552446304106	STEERING ARM	TATA spare parts
552447508205	BRACKET BS6	TATA spare parts
552454100115	ASSY BATTERY CABLE +VE FROM BATTERY TO P	TATA spare parts

552454110102	ASSY BATTERY CABLE -VE FROM BATTERY -VE	TATA spare parts
552454608206	L BRACKET FOR VSS BS6	TATA spare parts
552454608218	L BRACKET (WH TAIL MTG I) BS6	TATA spare parts
552454608219	L BRACKET (WH TAIL MTG II)	TATA spare parts
552454608230	L BRACKET(WH ABS) BS6	TATA spare parts
552454608231	L BRACKET (WH BUMPER WELDED) BS6	TATA spare parts
552454608235	L BRACKET(WH TAIL)	TATA spare parts
552458604001	BRACKET (HYD. JACK MTG.)	TATA spare parts
552458903201	PULLER FOR REMOVAL OF SPRING PIN	TATA spare parts
552458903501	SOCKET FOR HUB LOCK NUT FOR REAR AXLE	TATA spare parts
552482400101	WIPER MOTOR 24V	TATA spare parts
552627403203	BOLT -M10X1.5X35 LG	TATA spare parts
552627403204	BOLT M10X1.5X25 LG BS6	TATA spare parts
552627403205	BOLT - M12 - 1.75 - 25 LG	TATA spare parts
552627407801	RING ASSLY	TATA spare parts
552627409201	WASHER	TATA spare parts
552641115101	FLANGE YOKE DIA 120 BS6	TATA spare parts
552715100101	STARTER MOTOR ASSY	TATA spare parts
552715400101	ALTERNATOR 12V 75A WITH VACUUM PUMP	TATA spare parts
552715400102	ALTERNATOR 12V 150A 6 GROOVE PULLEY BS6	TATA spare parts
552715409903	PULLEY BS6	TATA spare parts
552716100102	CONTAINER 497BS-IV (LP410EX/34WB)OBD-2	TATA spare parts
552716100103	CONTAINER 497BS-IV (LPT410EX2/34WB OBD-2	TATA spare parts
552716100104	ECU WITH CLBRN LP407 W/O RSL-3.8 SGI BSI	TATA spare parts
552716100105	CONTAINER 3.8SGI(LPT407CNG BS-IV OBD-2)	TATA spare parts
552716172001	ECU BS6-PH2	TATA spare parts
552724000104	BRACKET ASSY ENGINE MTG BOTTOM LH BS6	TATA spare parts
552724000105	BRACKET ASSY ENGINE MTG BOTTOM RH BS6	TATA spare parts
552724100101	BRACKET ASSY ENGINE MTG FRONT-RH BS6	TATA spare parts
552724100102	BRACKET ASSY ENGINE MTG FRONT-LH BS6	TATA spare parts
552724100103	BRACKET ASSY ENGINE MTG FRONT-LH BS6-PH2	TATA spare parts
552724100104	BRACKET ASSY ENGINE MTG FRONT BS6-PH2	TATA spare parts
552724100105	BRACKET ASSY ENGINE MTG FRONTFLASELH BS6	TATA spare parts
552724100106	BRACKET ASSY ENGINE MTG FRONT-RH BS6-PH2	TATA spare parts
552724100109	BRACKET ASSY ENGINE MTG FRONT-LH BS6-PH2	TATA spare parts
552724100110	BRACKET ASSY ENGINE MTG FRONT-RH BS6-PH2	TATA spare parts
552724200101	BRACKET ASSY ENGINE MTG LH BS6	TATA spare parts
552724200102	BRACKET ASSY ENGINE MTG REAR-RH BS6	TATA spare parts
552724200103	HEAT SHIELD ASSY LH	TATA spare parts
552724200105	BRACKET ASSY ENGINE MTG REAR TOPFLASELH	TATA spare parts
552724200106	BRACKET ASSY ENGINE MTG REAR TOPFLASERH	TATA spare parts
552724200107	BRACKET ASSY ENGINE MTG BOTTOM LH BS6-PH	TATA spare parts
552724200108	BRACKET ASSY ENGINE MTG BOTTOM RH BS6-PH	TATA spare parts
552724200109	BRACKET ASSY ENGINE MTG REAR-LH BS6-PH2	TATA spare parts
552724200110	BRACKET ASSY BS6-PH2	TATA spare parts
552729100117	CLUTCH PEDAL ASSY WITH MTG BKT BS6-PH2	TATA spare parts
552729100120	CLUTCH PEDAL ASSY WITH BUSH BS6-PH2	TATA spare parts

552729100121	CLUTCH PEDAL ASSY WITH MTG BKT BS6-PH2	TATA spare parts
552729200107	BRAKE PEDAL ASSY WITH BUSH BS6	TATA spare parts
552729200109	BRAKE PEDAL ASSY WITH MTG BRACKET BS6	TATA spare parts
552729300102	BUNDY TUBE ASSY	TATA spare parts
552729300109	BRACKET ASSY CLUTCH BOOSTER MTG	TATA spare parts
552729300112	PUSH ROD	TATA spare parts
552729300113	BUNDY TUBE ASSY	TATA spare parts
552729300114	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
552729300115	BUNDY TUBE ASSY CMC TO FIREWALL BS6	TATA spare parts
552729300118	BUNDY TUBE ASSY CMC TO FIREWALL BS6	TATA spare parts
552729300119	BUNDYTUBEASSYLONGMEMBERBS6	TATA spare parts
552729300120	NYLON PIPE ASSY T-CONN TO CLUTCH BOOSTER	TATA spare parts
552729300124	BUNDY TUBE ASSY-CMC TO FIREWALL BS6	TATA spare parts
552729300136	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
552729300137	BUNDY TUBE ASSY CMC TO FIREWALL BS6	TATA spare parts
552729300151	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
552729300155	NYLON PIPE ASSY BS6	TATA spare parts
552729300156	NYLON PIPE ASSY BS6	TATA spare parts
552729300162	PIPE ASSY CMC TO BOOSTER BS6-PH2	TATA spare parts
552729300165	HOSE ASSY CMC TO RESERVOIR BS6-PH2	TATA spare parts
552729301602	PIPE ASSY CMC TO BOOSTER BS6-PH2	TATA spare parts
552729307502	GROMMET BS6-PH2	TATA spare parts
552729500103	BRACKET ASSY RESERVOIR HOLDING BS6	TATA spare parts
552729500105	BRACKET ASSY BRAKE PEDAL MTG BS6	TATA spare parts
552729990113	KIT-CLUTCH CONTROL BS6	TATA spare parts
552730100101	ASSY. ACCELERATOR PEDAL	TATA spare parts
552730100102	COVER (FOR ACCL. PEDAL)	TATA spare parts
552730100103	ACCELERATOR PEDAL ASSY WITH MTG BRACKET	TATA spare parts
552730100106	BRKT ASSY ACC PEDAL MTG BS6-PH2	TATA spare parts
552731000106	ASSY.FRAME WITH FITMENT LPT407 EX2 BS3/4	TATA spare parts
552731000113	FRAME ASSY WITH FITMENT BS6	TATA spare parts
552731000115	FRAME ASSY WITH FITMENT	TATA spare parts
552731000117	FRAMEASSYWITHFITMENTBS6	TATA spare parts
552731000119	FRAME ASSY WITH FITMENT BS6	TATA spare parts
552731000130	FRAME ASSY WITH FITMENT BS6	TATA spare parts
552731000132	FRAME ASSY WITH FITMENT BS6	TATA spare parts
552731000136	FRAME ASSY WITH FITMENT BS6	TATA spare parts
552731000138	FRAME ASSY WITH FITMENT BS6	TATA spare parts
552731000143	FRAME ASSY WITH FITMENT	TATA spare parts
552731000150	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
552731000151	FRAME ASSY WITH FITMENT BS6	TATA spare parts
55273100M10112	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55273100M10113	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55273100M10114	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55273100M10117	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55273100M10183	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55273100M10184	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts

55273100M10186	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
552731200110	BRACKET ASSY FES MTG RH BS6	TATA spare parts
552731200111	BRACKET ASSY FES MTG LH BS6	TATA spare parts
552731200113	COBRA BRACKET ASSY BS6	TATA spare parts
552731200114	COBRA BRACKET ASSY BS6	TATA spare parts
552731200118	COBRA BRACKET ASSY BS6	TATA spare parts
552731200119	COBRA BRACKET ASSY BS6	TATA spare parts
552731200120	CROSS MEMBER ASSY BS6	TATA spare parts
552731200121	COBRA BRACKET ASSY BS6	TATA spare parts
552731200124	CROSS MEMBER ASSY BS6	TATA spare parts
552731200131	COBRA BRACKET ASSY BS6-PH2	TATA spare parts
552731200132	COBRA BRACKET ASSY BS6-PH2	TATA spare parts
552731207114	L-BRACKET BS6	TATA spare parts
552731207117	L-BRACKET BS6	TATA spare parts
552731207118	L-BRACKETBS6	TATA spare parts
552731207119	L-BRACKET RH BS6-PH2	TATA spare parts
552731207120	L-BRACKET LH BS6-PH2	TATA spare parts
552731207123	LFLASEBRACKET BS6-PH2	TATA spare parts
552731207124	LFLASEBRACKET BS6-PH2	TATA spare parts
552731208202	REINFORCEMENT RH BS6	TATA spare parts
552731208203	REINFORCEMENT LH BS6	TATA spare parts
552731208220	END CROSS MEMBER BS6	TATA spare parts
552731240105	TUBE ASSY CROSS MEMBER BS6	TATA spare parts
552731240106	TUBE ASSY CROSS MEMBER BS6-PH2	TATA spare parts
552731300103	REINFORCEMENT ASSY SPRING BKT FRONT-RH B	TATA spare parts
552731300104	REINFORCEMENT ASSY SPRING BKT FRONT-LH B	TATA spare parts
552731303301	BRACKET ENGINE MTG CROSS MEMBER	TATA spare parts
552731308205	REINFORCEMENT LH	TATA spare parts
552731308206	REINFORCEMENT RH	TATA spare parts
552731308210	REINFORCEMENT RH BS6	TATA spare parts
552731308211	REINFORCEMENT RH (STEERING MOUNTIN BKT.)	TATA spare parts
552731308219	REINFORCEMENT RH BS6-PH2	TATA spare parts
552731308220	REINFORCEMENT LH BS6-PH2	TATA spare parts
552731400101	CROSS MEMBER ASSY BS6	TATA spare parts
552731400102	CROSS MEMBER ASSY BS6	TATA spare parts
552731400103	CROSS MEMBER ASSY BS6	TATA spare parts
552731400108	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
552731407101	L-BRACKET RH BS6	TATA spare parts
552731407102	L-BRACKET LH BS6	TATA spare parts
552731407105	L-BRACKETRH BS6	TATA spare parts
552731407106	L-BRACKETLH BS6	TATA spare parts
552731407114	L-BRACKET BS6	TATA spare parts
552731407116	L-BRACKET RH BS6	TATA spare parts
552731407117	L-BRACKET BS6	TATA spare parts
552731407125	L-BRACKET RHBS6	TATA spare parts
552731407126	L-BRACKET RHBS6	TATA spare parts
552731407135	LFLASEBRACKET BS6-PH2	TATA spare parts

552731407136	LFLASEBRACKET RH BS6-PH2	TATA spare parts
552731407137	LFLASEBRACKET LH BS6-PH2	TATA spare parts
552731408203	CROSS MEMBER BS6	TATA spare parts
552731408210	BRACKET REINFORCEMENT RH BS6-PH2	TATA spare parts
552731408211	BRACKET REINFORCEMENT RH BS6-PH2	TATA spare parts
552731505101	TOW HOOK HOLDING BLOCK FRONT BS6	TATA spare parts
552732100109	FRONT SPRING ASSY	TATA spare parts
552732100110	FRONT SPRING ASSY	TATA spare parts
552732100118	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
552732100119	LEAF SPRING ASSY FRONT BS6-PH2	TATA spare parts
552732107110	2ND LEAF BS6-PH2	TATA spare parts
552732107112	3RD LEAF BS6-PH2	TATA spare parts
552732400119	LEAF SPRING ASSY REAR BS6-PH2	TATA spare parts
552732400120	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
552732407111	3RD LEAF BS6-PH2	TATA spare parts
552732407112	2ND LEAF BS6-PH2	TATA spare parts
552733000107	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
552733000110	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
552733000112	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
552733000114	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
552733105101	FRONT AXLE BEAM BS6-PH2	TATA spare parts
552733405501	FRONT HUB BS6	TATA spare parts
552740100102	WHEEL RIM ASSY	TATA spare parts
552740109902	TYRE	TATA spare parts
552740109903	TUBE 6.50X16 CEAT	TATA spare parts
552740307101	PLATE SPARE WHEEL MTG BS6-PH2	TATA spare parts
552740307103	PLATE SPARE WHEEL MTG BS6	TATA spare parts
552741000101	ASSY.UNITIZED PROP.SHAFT	TATA spare parts
552741100102	PROPELLER SHAFT ASSY BS6	TATA spare parts
552741100103	PROPELLER SHAFT ASSY BS6	TATA spare parts
552741109901	SLIP YOKE ASSY BS6	TATA spare parts
552741109902	FLANGE YOKE BS6	TATA spare parts
552741109903	UNIT PACK BS6	TATA spare parts
552741109904	UNIT PACK BS6	TATA spare parts
552741109905	BEARING RETAINER BS6	TATA spare parts
552741110102	PROPELLERSHAFTASSYMONOTRONBS6	TATA spare parts
552741110105	PROPELLER SHAFT ASSY BS6-PH2	TATA spare parts
552741110106	PROPELLER SHAFT ASSY MONOTRON BS6-PH2	TATA spare parts
552741120101	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
552741120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
552741300101	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
552741307105	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
552741307106	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
552741308201	GUARD PROPELLER SHAFT BS6-PH2	TATA spare parts
552742100167	BRAKE AGGR ASSY FRONT-RH	TATA spare parts
552742100195	DRUM BRAKE ASSY FRONT-LH BS6	TATA spare parts
552742100196	DRUM BRAKE ASSY FRONT-RH BS6	TATA spare parts

552742103704	BRAKE DRUM BS6	TATA spare parts
552742103709	BRAKE DRUM	TATA spare parts
552742300130	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
552742300134	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
552742300194	DRUM BRAKE ASSY REAR-LH BS6	TATA spare parts
552742300195	DRUM BRAKE ASSY REAR-RH BS6	TATA spare parts
552742303704	BRACKET ACTUATOR MTG LH	TATA spare parts
552742303705	BRACKET ACTUATOR MTG RH	TATA spare parts
552742307501	GROMMET BS6	TATA spare parts
552742700119	BRACKET ASSY PARKING BRAKE CABLE MTG BS6	TATA spare parts
552742700120	INNER CABLE FRONT BS6	TATA spare parts
552742700121	PARKING BRAKE CABLE ASSY REAR BS6	TATA spare parts
552742700122	BRACKET ASSY PARKING BRAKE CABLE REAR BS	TATA spare parts
552742700123	PARKING BRAKE CABLE ASSY-REAR BS6	TATA spare parts
552742700130	PARKING BRAKE LEVER ASSY BS6	TATA spare parts
552742700134	LEVER ASSY BS6	TATA spare parts
552742700149	BRACKET ASSY PARKING BRAKE CABLE FRONT	TATA spare parts
552742703303	BRACKET PARKING BRAKE LEVER MTG	TATA spare parts
552742708704	TORSION SPRING BS6	TATA spare parts
552742980101	WHEEL CYLINDER ASSLY-LH(WITH BLEED SCREW	TATA spare parts
552742980102	WHEEL CYLINDER ASSLY-RH(WITH BLEED SCREW	TATA spare parts
552742980103	WHEEL CYLINDER ASSLY-LH(W/O BLEED SCREW)	TATA spare parts
552742980104	WHEEL CYLINDER ASSLY-RH(W/O BLEED SCREW)	TATA spare parts
552742980105	BACK PLATE ASSY LH BS6	TATA spare parts
552742980106	BACK PLATE ASSY RH BS6	TATA spare parts
552742980107	BACK PLATE ASSY LH BS6	TATA spare parts
552742980108	BACK PLATE ASSY RH BS6	TATA spare parts
552743100111	BRACKET ASSY LCRV MTG BS6	TATA spare parts
552743200103	AIR TANK ASSY WITH BKT	TATA spare parts
552743500108	PIPE BUNCH ASSY CHASSIS	TATA spare parts
552743500110	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
552743500126	KIT-BOOSTER ASSY (REPAIR)	TATA spare parts
552743500128	PIPE ASSY VACUUM BUNCH FOR CAB	TATA spare parts
552743500129	PIPE ASSY VACUUM BUNCH FOR CHASSIS	TATA spare parts
552743500134	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
552743500135	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
552743500163	PIPE BUNCH ASSY CHASSIS	TATA spare parts
552743500164	VACUUM BOOSTER ASSY BS6	TATA spare parts
552743507501	GROMMET VACUUM PIPE HOLDING	TATA spare parts
552743507502	GROMMET VACUUM PIPE	TATA spare parts
552743700101	DRYING & DISTRIBUTION UNIT	TATA spare parts
552743700103	BRAKE CHAMBER BS6	TATA spare parts
552743700111	KIT-DDU	TATA spare parts
552743700113	KIT-DUAL BRAKE VALVE	TATA spare parts
552743800107	TUBE ASSY ADAPTER TO LCRV INLET	TATA spare parts
552743800111	ASSY TUBE (SECONDRY TO FRONT TEE)	TATA spare parts
552743800118	ASSY TUBE (FROM TEE TO REAR LH BKT)	TATA spare parts



552743800119	ASSY TUBE (FROM TEE TO REAR RH BKT)	TATA spare parts
552743800127	TUBE ASSY HOSE TO FRONT BRAKE ASSY RH BS	TATA spare parts
552743800167	TUBE ASSY BRAKE HOSE TO ADAPTOR	TATA spare parts
552743800178	HOSE ASSY RESERVOIR TO TMC PRI.	TATA spare parts
552743800179	HOSE ASSY RESERVOIR TO TMC SEC.	TATA spare parts
552743800202	TUBE ASSY HOSE TO FRONT BRAKE ASSY LH BS	TATA spare parts
552743800206	TUBE ASSY LCRV TO REAR BRAKE HOSE LH BS6	TATA spare parts
552743800207	TUBE ASSY HOSE TO FRONT BRAKE ASSY LH BS	TATA spare parts
552743800213	TUBE ASSY ADAPTER TO LCRV INLET BS6	TATA spare parts
552743800216	TUBE ASSY HOSE TO FRONT BRAKE ASSY RH BS	TATA spare parts
552743800221	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
552743800222	METAL PIPE ASSY BS6	TATA spare parts
552743800223	METAL PIPE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts
552743800224	METAL PIPE ASSY ADAPTER TO DDU BS6	TATA spare parts
552743800227	METAL PIPE ASSY CRIMPED HOSE TO ADAPTER	TATA spare parts
552743800228	METAL PIPE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts
552743803303	BRACKET BRAKE TUBE MTG	TATA spare parts
552743803304	BRACKET BRAKE PIPE MTG	TATA spare parts
552743803305	BRACKET TEE CONN. MTG.	TATA spare parts
552743803314	BRACKET PIPE MOUNTING	TATA spare parts
552743803315	BRACKET BRAKE LINE MTG	TATA spare parts
552743803323	BRACKET ON ANCHOR PLATE ASSY. (FOR FRONT	TATA spare parts
552743806808	4-WAY CONNECTOR BS6	TATA spare parts
552743808205	BRACKET FOR BRAKE LINE MTG ON FES FLOOR	TATA spare parts
552743810102	TUBE ASSY HOSE TO ADAPTER BS6	TATA spare parts
552743810103	TUBE ASSY-ADAPTER TO LCRV INLET BS6	TATA spare parts
552743810109	TUBE ASSY-ADAPTER TO LCRV INLET BS6	TATA spare parts
552743810163	TUBE ASSY 4-WAY CONN TO ADAPTER RH BS6	TATA spare parts
552743810164	TUBE ASSY 4-WAY CONN TO BRAKE HOSE FR-RH	TATA spare parts
552743810165	TUBE ASSY 4-WAY CONN TO BRAKE HOSE FR-LH	TATA spare parts
552743810166	TUBE ASSY 4-WAY CONN TO ADAPTER LH BS6	TATA spare parts
552743810167	TUBE ASSY 4-WAY CONN TO BRAKE HOSE FR-LH	TATA spare parts
552743810168	TUBE ASSY 4-WAY CONN TO BRAKE HOSE FR-RH	TATA spare parts
552743810169	TUBE ASSY ADAPTER TO LCRV INLET BS6	TATA spare parts
552743810170	TUBE ASSY T-CONN TO REAR-LH BS6	TATA spare parts
552743900101	ASSY NYLON PIPE BUNCH	TATA spare parts
552743900112	PIPE ASSY MAG VALVE TO EXHUST BKR. CYL.	TATA spare parts
552743900115	PIPE ASSY BUNCH FOR CHASSIS	TATA spare parts
552743900117	PIPE ASSY BUNCH FOR CAB	TATA spare parts
552743900123	PIPE ASSY MAG VALVE TO EXH. BRK.	TATA spare parts
552743900135	BUNCH PIPE ASSY	TATA spare parts
552743900144	METAL PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
552743900145	METAL PIPE ASSY CRIMPED HOSE TO ADAPTER	TATA spare parts
552743900202	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
552743900209	METAL PIPE ASSY ADAPTER TO DDU	TATA spare parts
552743900211	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
552743900212	NYLON PIPE ASSY RV TO MV BS6	TATA spare parts

552743900213	NYLON PIPE ASSY MV TO T-CONN BS6	TATA spare parts
552743900214	NYLON PIPE ASSY DBV TO RELAY VALVE BS6	TATA spare parts
552743900215	NYLON PIPE ASSY T-CONN TO RELAY VALVE BS	TATA spare parts
552743900216	NYLON PIPE ASSY RV TO BC RH BS6	TATA spare parts
552743900217	NYLON PIPE ASSY RV TO BC LH BS6	TATA spare parts
552743900222	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
552743900225	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
552743900257	PIPE BUNCH ASSY CHASSIS BS6-PH2	TATA spare parts
552743910120	PIPE BUNCH ASSY	TATA spare parts
552743910135	METAL PIPE ASSY HOSE TO ADAPTOR	TATA spare parts
552743910136	METAL PIPE ASSY ADAPTER TO DDU	TATA spare parts
552743910175	PIPE BUNCH ASSY	TATA spare parts
552743910298	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
552743920111	METAL PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
552743920113	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
552743920120	NYLON PIPE ASSY T-CONN TO DBV BS6	TATA spare parts
552743920127	NYLON PIPE ASSY RV TO BRAKE LH BS6	TATA spare parts
552743920128	NYLON PIPE ASSY RV TO BRAKE RH BS6	TATA spare parts
552743920129	NYLON PIPE ASSY T-CONN TO SBA RH BS6	TATA spare parts
552743920130	NYLON PIPE ASSY T-CONN TO SBA LH BS6	TATA spare parts
552743920141	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
552743930112	NYLON PIPE BUNCH ASSY BS6-PH2	TATA spare parts
552746100102	STEERING COLUMN ASSY BS6	TATA spare parts
552746100104	STEERING COLUMN ASSY BS6-PH2	TATA spare parts
552746305101	PITMAN ARM BS6	TATA spare parts
552746305102	PITMAN ARM BS6-PH2	TATA spare parts
552746600101	BRACKET ASSY RESERVOIR MTG BS6	TATA spare parts
552746600102	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
552746603301	BRACKET RESERVOIR SUPPORT BS6	TATA spare parts
552746700101	BRACKET ASSY RESERVOIR MTG BS6-PH2	TATA spare parts
552746703302	BRACKET STG GEAR BOX MTG BS6	TATA spare parts
552746703305	BRACKET STG GEAR BOX MTG BS6-PH2	TATA spare parts
552746800107	SUCTION LINE ASSY BS6	TATA spare parts
552746800108	HIGH PRESSURE LINE ASSYBS6	TATA spare parts
552746800109	RETURN LINE ASSY BS6	TATA spare parts
552746800111	SUCTION LINE ASSY BS6	TATA spare parts
552746800112	PRESSURE LINE ASSY BS6	TATA spare parts
552746800113	PRESSURE LINE ASSY BS6	TATA spare parts
552746800114	SUCTION LINE ASSY BS6	TATA spare parts
552746800116	RETURN LINE ASSY BS6	TATA spare parts
552746800117	PRESSURE LINE ASSY BS6	TATA spare parts
552746800118	SUCTION LINE ASSY BS6	TATA spare parts
552746800119	RETURN LINE ASSY BS6	TATA spare parts
552746800120	PRESSURE LINE ASSY BS6	TATA spare parts
552746800121	SUCTION LINE ASSY BS6	TATA spare parts
552746800128	SUCTION LINE ASSY BS6-PH2	TATA spare parts
552746800129	HIGH PRESSURE LINE ASSY	TATA spare parts

552746800130	SUCTION LINE ASSY BS6-PH2	TATA spare parts
552746800132	RETURN LINE ASSY BS6-PH2	TATA spare parts
552746803301	BRACKET STG PIPE MTG BS6	TATA spare parts
552746900102	DRAG LINK ASSY (OFFER PART 552746901602	TATA spare parts
552746900105	DRAG LINK ASSY BS6-PH2	TATA spare parts
552746900106	DRAG LINK ASSY BS6-PH2	TATA spare parts
552747100103	BRACKET ASSY FUEL FILTER MTG BS6-PH2	TATA spare parts
552747500102	BRACKET ASSY WITH RIBç BS6	TATA spare parts
552747500103	ENDRESTRAINTASSYRHBS6	TATA spare parts
552747500104	END RESTRAINT ASSY LH BS6	TATA spare parts
552747500110	ARRESTOR ASSY REAR CYLINDER RH BS6	TATA spare parts
552747500111	ARRESTOR ASSY REAR CYLINDER LH BS6	TATA spare parts
552747500116	RESTRAINT ASSY BS6-PH2	TATA spare parts
552747500125	ARRESTOR ASSY BS6-PH2	TATA spare parts
552747508215	STONE GUARD BS6-PH2	TATA spare parts
552747600101	SUCTION FUEL PIPE ASSY TANK TO FILTER	TATA spare parts
552747600105	SUCTION FUEL PIPE ASSY	TATA spare parts
552747600122	SUCTION PIPE ASSY FUEL TANK TO W/SEP	TATA spare parts
552747600123	SUCTION PIPE ASSY W/SEP TO ENGINE	TATA spare parts
552747600124	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
552747600126	FUEL SUCTION PIPE ASSY	TATA spare parts
552747600127	SUCTION FUEL PIPE ASSY	TATA spare parts
552747600128	FUEL RETURN PIPE ASSY OVER FLOW TO TANK	TATA spare parts
552747600130	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
552747600138	SUCTION PIPE ASSY TANK TO PRE-FILTER	TATA spare parts
552747600139	SUCTION PIPE ASSY FILTER TO FIP	TATA spare parts
552747600140	FUEL RETURN PIPE ASSY OVER FLOW TO TANK	TATA spare parts
552747600142	SUCTION PIPE ASSY FILTER TO FIP BS6	TATA spare parts
552747600143	SUCTION PIPE ASSY TANK TO PREFILTER BS6	TATA spare parts
552747600144	FUEL RETURN PIPE ASSY (36WB -52WB) BS6	TATA spare parts
552747600148	HP PIPE ASSYBS6	TATA spare parts
552747600149	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
552747600152	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
552747600153	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
552747600154	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
552747600155	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
552747600157	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
552747600158	HP TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
552747600159	VENT TUBE ASSY BS6	TATA spare parts
552747600160	VENT TUBE ASSY BS6	TATA spare parts
552747600161	VENT TUBE ASSY BS6	TATA spare parts
552747600162	VENT TUBE ASSY BS6	TATA spare parts
552747600163	VENT TUBE ASSY BS6	TATA spare parts
552747600164	VENT TUBE ASSY BS6	TATA spare parts
552747600165	VENT TUBE ASSY BS6	TATA spare parts
552747600166	VENT TUBE ASSY BS6	TATA spare parts
552747600167	VENT TUBE ASSY BS6	TATA spare parts

552747600168	VENT TUBE ASSYBS6	TATA spare parts
552747600169	HP TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
552747600170	HP TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
552747600171	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
552747600172	HP GAS TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
552747600173	HP TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
552747600178	SUCTION PIPE ASSY FILTER TO FIP BS6	TATA spare parts
552747600186	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
552747600187	FUEL RETURN PIPE ASSY BS6	TATA spare parts
552747600188	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
552747600197	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
552747600198	FUEL RETURN PIPE ASSY BS6	TATA spare parts
552747600199	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
552747600207	SUCTION PIPE ASSY TANK TO PREFLASEFILTER	TATA spare parts
552747600208	SUCTION PIPE ASSY FILTER TO FIP BS6-PH2	TATA spare parts
552747600209	FUEL RETURN PIPE ASSY OVER FLOW TO TANK	TATA spare parts
552747603303	BRACKET BS6	TATA spare parts
552747603304	BRACKET	TATA spare parts
552747607101	BACK PLATE BS6	TATA spare parts
552747607103	CLAMP PLATE BS6	TATA spare parts
552747608201	ANGLE BRACKET BS6	TATA spare parts
552747608204	COVER BOTTOM BS6	TATA spare parts
552747608205	COVER TOP BS6	TATA spare parts
552747610102	SINGLE CLAMP ASSY WITH BRACKET BS6	TATA spare parts
552747610129	VENT TUBE ASSY BS6-PH2	TATA spare parts
552747610135	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610136	VENT TUBE ASSY BS6-PH2	TATA spare parts
552747610140	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610141	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610146	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610147	HP TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610148	VENT TUBE ASSY BS6-PH2	TATA spare parts
552747610149	VENT TUBE ASSY BS6-PH2	TATA spare parts
552747610150	HP TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610151	HP TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610157	VENT TUBE ASSY BS6-PH2	TATA spare parts
552747610160	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610161	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610162	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610163	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610164	VENT TUBE ASSY BS6-PH2	TATA spare parts
552747610165	VENT TUBE ASSY BS6-PH2	TATA spare parts
552747610166	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610167	HP TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610168	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610169	HP GAS TUBE ASSY WITH PVC SLEEVE BS6-PH2	TATA spare parts
552747610170	VENT TUBE ASSY BS6-PH2	TATA spare parts

552747610188	HP PIPE ASSY BS6-PH2	TATA spare parts
552747610192	HP PIPE ASSY BS6-PH2	TATA spare parts
552747610193	VENT PIPE ASSY BS6-PH2	TATA spare parts
552747610194	VENT PIPE ASSY BS6-PH2	TATA spare parts
552747610195	HP PIPE ASSY BS6-PH2	TATA spare parts
552747610196	VENT PIPE ASSY BS6-PH2	TATA spare parts
552747620107	HP PIPE ASSY BS6-PH2	TATA spare parts
552747620119	HP PIPE ASSY BS6-PH2	TATA spare parts
552747620120	HP PIPE ASSY (INTEGRATED FILLING UNIT FI	TATA spare parts
552747620121	VENT PIPE ASSY BS6-PH2	TATA spare parts
552747620123	HP PIPE ASSY (INTEGRATED FILLING UNIT FI	TATA spare parts
552747620124	VENT PIPE ASSY BS6-PH2	TATA spare parts
552747620128	HP PIPE ASSY BS6-PH2	TATA spare parts
552747620129	HP PIPE ASSY BS6-PH2	TATA spare parts
552747620135	HP PIPE ASSY BS6-PH2	TATA spare parts
552747620136	VENT PIPE ASSY BS6-PH2	TATA spare parts
552747620141	HP PIPE ASSY BS6-PH2	TATA spare parts
552747620142	VENT PIPE ASSY BS6-PH2	TATA spare parts
552749100105	BRACKET ASSY DOC POC MTG	TATA spare parts
552749100106	BRACKET ASSY DOC POC MTG	TATA spare parts
552749100107	ASSY SILENCER WITH BOSS	TATA spare parts
552749100108	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
552749100119	SILENCER ASSY	TATA spare parts
552749100123	TUBE ASSY BS6-PH2	TATA spare parts
552749100124	BRACKET ASSY SILENCER MTG BS6-PH2	TATA spare parts
552749100129	CLAMP ASSY CATCON MTG BS6-PH2	TATA spare parts
552749100131	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
552749100134	PIPE ASSY CATCON INTAKE	TATA spare parts
552749100135	PIPE ASSY DOWNSTREAM (DPS)	TATA spare parts
552749100139	PIPE ASSY DPS SENSOR BS6-PH2	TATA spare parts
552749100140	PIPE ASSY DPS SENSOR BS6-PH2	TATA spare parts
552749100142	PIPE ASSY DPS SENSOR REAR BS6-PH2	TATA spare parts
552749100143	PIPE ASSY DPS SENSOR INTAKE BS6-PH2	TATA spare parts
552749103302	BRACKET DOC POC SUPPORTç BS6	TATA spare parts
552749103303	BRACKET DOC POC MTG	TATA spare parts
552749103304	BRACKET DOC POC MTG	TATA spare parts
552749103305	BRACKET	TATA spare parts
552749103307	BRACKET CATCON MTG BS6-PH2	TATA spare parts
552749105801	HOSE (DPS SENSOR)	TATA spare parts
552749105802	HOSE (DPS SENSOR)	TATA spare parts
552749200101	ASSY FRT.EXH.PIPE WITH FLEX.BELOW	TATA spare parts
552749200103	ASSY.EXHAUST INTERMEDIATE PIPE WITH BOSS	TATA spare parts
552749200104	PIPE ASSY WITH BELLOW FRONT	TATA spare parts
552749200105	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
552749200106	EXH PIPE ASSY WITH FLEX BELLOW BS6	TATA spare parts
552749200107	ASSY.FRT.EXH.PIPE (WITH FLEXIBLE BELLOW)	TATA spare parts
552749200109	ASSY.EXHAUST INTERMEDIATE PIPE	TATA spare parts

552749200110	ASSY.FRONT EXH. PIPE (WITH FLEX BELLOW)	TATA spare parts
552749200113	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
552749200115	BRACKET ASSY TAIL PIPE MTG BS6	TATA spare parts
552749200117	UREA PIPE ASSY (36-52WB) (552749200118)	TATA spare parts
552749200121	BRACKET ASSY	TATA spare parts
552749200122	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
552749200123	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
552749200125	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
552749200132	BRACKET ASSY BS6	TATA spare parts
552749200133	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
552749200135	BRACKET ASSY BS6-PH2	TATA spare parts
552749200154	TUBE ASSY BS6-PH2	TATA spare parts
552749200155	EXH PIPE ASSY WITH FLEX BELLOW FRT BS6-P	TATA spare parts
552749200156	BRACKET ASSY BS6-PH2	TATA spare parts
552749200162	PIPE ASSY UREA SUPPLY BS6-PH2	TATA spare parts
552749200165	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
552749200166	BRACKET ASSY DPS SENSOR BS6-PH2	TATA spare parts
552749200167	CLAMP ASSY CATCON MTG BS6-PH2	TATA spare parts
552749200169	BRACKET ASSY BS6-PH2	TATA spare parts
552749200170	EXHAUST PIPE ASSY BS6-PH2	TATA spare parts
552749200171	BRACKET ASSY CATCON MTG BS6-PH2	TATA spare parts
552749200172	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
552749200176	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
552749200177	BRACKET ASSY SILENCER MTG BS6-PH2	TATA spare parts
552749200179	CLAMP ASSY CATCON MTG BS6-PH2	TATA spare parts
552749200181	BRACKET ASSY CATCON MTG BS6-PH2	TATA spare parts
552749200191	BRACKET ASSY DPS SENSOR BS6-PH2	TATA spare parts
552749200198	EXHAUST PIPE ASSY WITH FLEX BELLOW BS6-P	TATA spare parts
552749200199	HEAT SHIELD ASSY BS6-PH2	TATA spare parts
552749203331	CLAMP BS6-PH2	TATA spare parts
552749203332	CLAMP BS6-PH2	TATA spare parts
552749203335	BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
552749206922	TAIL PIPE BS6	TATA spare parts
552749206923	DIFFUSER BS6	TATA spare parts
552749207101	BRACKET BS6	TATA spare parts
552749207102	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
552749207104	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
552749207112	BRACKET BS6	TATA spare parts
552749207119	L-BRACKET EXHAUST PIPE MTG BS6-PH2	TATA spare parts
552749207120	BRACKET BS6-PH2	TATA spare parts
552749208203	CLAMP	TATA spare parts
552749208211	CLAMP EXHAUST PIPE MTG FRONT BS6-PH2	TATA spare parts
552749208214	CLAMP BS6-PH2	TATA spare parts
552749600120	HEAT SHIELD ASSY BS6-PH2	TATA spare parts
552749600122	HEAT SHIELD ASSY BS6-PH2	TATA spare parts
552749600124	HEAT SHIELD PLATE BS6-PH2	TATA spare parts
552749600126	HEAT SHIELD ASSY BS6-PH2	TATA spare parts

552749600128	HEAT SHIELD ASSY SILENCER BS6-PH2	TATA spare parts
552754200101	INSTRUMENT CLUSTER 1:0.76	TATA spare parts
552754200103	INST CLUSTER 1:0.80 LP/T407 MFIP	TATA spare parts
552754200104	NST CLUSTER 1:0.80 LP407 MFIP	TATA spare parts
552754200114	INSTRUMENT CLUSTER ASSY	TATA spare parts
552754200115	INSTRUMENT CLUSTER ASSY	TATA spare parts
552754200132	INSTRUMENT CLUSTER ASSY	TATA spare parts
552754209902	DIAL WITH FUEL AND TATA LOGO ASSY	TATA spare parts
552754304902	HORN LOW TONE BS6-PH2	TATA spare parts
552754504903	SWITCH POWER TAKE OFF BS6	TATA spare parts
552754504904	SWITCH TIPPING CONTROL BS6	TATA spare parts
552754504905	ALARM RESET SWITCH BS6	TATA spare parts
552754504906	EMERGENCY HELP SWITCH ASSY BS6-PH2	TATA spare parts
552754504907	SWITCH BATTERY CUT OFF BS6-PH2	TATA spare parts
552754504908	HAZARD WARNING SWITCH BS6-PH2	TATA spare parts
552754504909	SWITCH HEAVY MODE BS6-PH2	TATA spare parts
552754504910	SWITCH LIGHT MODE BS6-PH2	TATA spare parts
552754504911	SWITCH EXHAUST BRAKE BS6-PH2	TATA spare parts
552754504912	SWITCH REGENERATION INHIBIT BS6-PH2	TATA spare parts
552754504913	SWITCH REGENERATION START MANUAL BS6-PH2	TATA spare parts
552754504915	ALARM RESET SWITCH BS6-PH2	TATA spare parts
552754504916	ATC SWITCH DASHBOARD BS6-PH2	TATA spare parts
552754504918	SWITCH HILL HOLDER BS6-PH2	TATA spare parts
552754504919	STRG LOCK & IGNITION SWITCH ASSY BS6-PH2	TATA spare parts
552754509903	FUSE BASE WITH COVER	TATA spare parts
552754600105	WIRING HARNESS MAIN	TATA spare parts
552754600143	W/H GRID HEATER LPT 613	TATA spare parts
552754600146	W/H MAIN PIGTAIL	TATA spare parts
552754600148	W/H SENSOR	TATA spare parts
552754600149	W/H SENSOR LP/LPT 410 BSIII	TATA spare parts
552754600150	BRACKET ASSY(MAXI-FUSE BOX MTG FOR LPT)	TATA spare parts
552754600153	WIRING HARNESS ENGINE	TATA spare parts
552754600157	WIRING HARNESS TAIL	TATA spare parts
552754600164	CYLINDER EARTHING ASSY BS6	TATA spare parts
552754600186	WIRING HARNESS MAIN	TATA spare parts
552754600189	WIRING HARNESS TAIL	TATA spare parts
552754600192	WIRING HARNESS ENGINE	TATA spare parts
552754600194	WIRING HARNESS ENGINE	TATA spare parts
552754600195	WIRING HARNESS SENSOR	TATA spare parts
552754601641	BATTERY CABLE +VE	TATA spare parts
552754601664	WIRING HARNESS MAXI FUSE	TATA spare parts
552754601667	WIRING HARNESS LOAD BODY	TATA spare parts
552754601673	WIRING HARNESS TAIL	TATA spare parts
552754601679	WIRING HARNESS LOAD BODY	TATA spare parts
552754601684	WIRING HARNESS MAXI FUSE	TATA spare parts
552754601685	WIRING HARNESS MAXI FUSE	TATA spare parts
552754601686	WIRING HARNESS TAIL	TATA spare parts

552754601688	WIRING HARNESS MAIN	TATA spare parts
552754601689	WIRING HARNESS INJECTOR	TATA spare parts
552754601690	WIRING HARNESS SENSOR	TATA spare parts
552754601693	WIRING HARNESS MAIN	TATA spare parts
552754601694	WIRING HARNESS TAIL	TATA spare parts
552754601696	WIRING HARNESS MOTOR CONTROLLER	TATA spare parts
552754601697	WIRING HARNESS TAIL	TATA spare parts
552754601698	PIGTAIL VEHICLE SPEED SENSOR	TATA spare parts
552754603301	BRACKET F/B MTG LH	TATA spare parts
552754603306	BRACKET CONNECTOR CLIP MTG BS6	TATA spare parts
552754603309	BRACKET W/H INJECTOR SENSOR BRANCH MTG	TATA spare parts
552754603310	BRACKET WIRING HARNESS MTG	TATA spare parts
552754603316	BRACKET INTERFACE CONNECTOR MTG BS6	TATA spare parts
552754603318	BRACKET BS6	TATA spare parts
552754603319	BRACKETWIRINGHARNESSMTG BS6	TATA spare parts
552754603320	BRACKET CONNECTOR CLIP MTG BS6-PH2	TATA spare parts
552754606301	STICKERMAXIFUSEBOX BS6	TATA spare parts
552754606304	STICKER MAXI FUSE BOX BS6	TATA spare parts
552754606307	STICKER MAXI FUSE BOX BS6-PH2	TATA spare parts
552754606308	STICKER MAXI FUSE BOX BS6-PH2	TATA spare parts
552754610101	WIRING HARNESS MAIN	TATA spare parts
552754610104	WIRING HARNESS MAXI FUSE	TATA spare parts
552754610105	WIRING HARNESS MAXI FUSE	TATA spare parts
552754610113	WIRING HARNESS MAIN	TATA spare parts
552754610115	WIRING HARNESS MAIN	TATA spare parts
552754610116	WIRING HARNESS TAIL	TATA spare parts
552754610119	WIRING HARNESS PIGTAIL	TATA spare parts
552754610120	WIRING HARNESS ABS FRAME	TATA spare parts
552754610121	WIRING HARNESS MAIN	TATA spare parts
552754610124	WIRING HARNESS TAIL	TATA spare parts
552754610127	WIRING HARNESS EMS	TATA spare parts
552754610133	WIRING HARNESS MOTOR CONTROLLER	TATA spare parts
552754610140	BATTERY CABLE +VE	TATA spare parts
552754610194	WIRING HARNESS TAIL	TATA spare parts
552754611602	WIRING HARNESS ENGINE	TATA spare parts
552754611604	WIRING HARNESS MAIN	TATA spare parts
552754611607	WIRING HARNESS MAIN	TATA spare parts
552754611608	WIRING HARNESS EMS	TATA spare parts
552754611611	WIRING HARNESS MAIN	TATA spare parts
552754611612	WIRING HARNESS TAIL	TATA spare parts
552754611620	WIRING HARNESS MAIN	TATA spare parts
552754611623	WIRING HARNESS EMS	TATA spare parts
552754620101	WIRING HARNESS MAIN	TATA spare parts
552754620103	WIRING HARNESS TAIL	TATA spare parts
552754620105	WIRING HARNESS ENGINE	TATA spare parts
552754620106	WIRING HARNESS SENSOR	TATA spare parts
552754620107	W/H SENSOR LP407 TMML MFIP	TATA spare parts



552754620109	W/H MAIN LP407 MFIP	TATA spare parts
552754620110	W/H TAIL LP407/34WB MFIP	TATA spare parts
552754620111	W/H ENGINE LP407 MFIP TMML	TATA spare parts
552754620115	W/H TAIL LPT 407 BSIV 34WB EOBD	TATA spare parts
552754620117	FUSE BOX MTG ASSY BS6	TATA spare parts
552754620124	WIRING HARNESS TAIL	TATA spare parts
552754620129	WIRING HARNESS ENGINE	TATA spare parts
552754620132	FUSE BOX COVER	TATA spare parts
552754620134	WIRING HARNESS MAIN	TATA spare parts
552754620135	WIRING HARNESS MAIN	TATA spare parts
552754620136	WIRING HARNESS MAIN	TATA spare parts
552754620166	WIRING HARNESS MAXIFUSE BS6	TATA spare parts
552754620167	BATTERY CABLE +VE BS6	TATA spare parts
552754620183	WIRING HARNESS SWITCH BS6	TATA spare parts
552754620185	WIRING HARNESS SCR UNIT BS6	TATA spare parts
552754620186	BATTERY CABLE +VE BS6	TATA spare parts
552754620190	WIRING HARNESS HEADLAMP & BLINKER BS6	TATA spare parts
552754620199	WIRING HARNESS TAIL BS6	TATA spare parts
552754630106	WIRING HARNESS EMS BS6	TATA spare parts
552754630109	BATTERY CABLE +VE BCS TO MEGA FUSE BS6	TATA spare parts
552754630112	FUSE BOX COVER WITH SCREEN PAINTING BS6	TATA spare parts
552754630119	WIRING HARNESS TAIL BS6	TATA spare parts
552754630125	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
552754630126	WIRING HARNESS ABS BS6	TATA spare parts
552754630128	WIRING HARNESS TAIL BS6	TATA spare parts
552754630129	BATTERY CABLE -VE BS6	TATA spare parts
552754630130	BATTERY CABLE +VE BS6	TATA spare parts
552754630132	BRACKET ASSY MIDI FUSE BOX MTG BS6	TATA spare parts
552754630146	WIRING HARNESS MAIN	TATA spare parts
552754630149	WIRING HARNESS MAXI FUSE	TATA spare parts
552754630150	WIRING HARNESS MAIN BS6	TATA spare parts
552754630153	WIRING HARNESS ENGINE BS6	TATA spare parts
552754630154	WIRING HARNESS TAIL BS6	TATA spare parts
552754630155	WIRING HARNESS EMS BS6	TATA spare parts
552754630159	ANTENNA CABLE BS6	TATA spare parts
552754630160	WIRING HARNESS TAIL BS6	TATA spare parts
552754630161	WIRINGHARNESSREVERSEPARKASSIST BS6	TATA spare parts
552754630162	WIRING HARNESS MAIN BS6	TATA spare parts
552754630163	WIRING HARNESS MAIN BS6	TATA spare parts
552754630164	WIRING HARNESS ABS BS6	TATA spare parts
552754630167	WIRING HARNESS TAIL BS6	TATA spare parts
552754630169	BATTERY CABLE +VE BS6	TATA spare parts
552754630179	WIRING HARNESS MAIN BS6	TATA spare parts
552754630180	WIRING HARNESS EMS BS6	TATA spare parts
552754630182	WIRING HARNESS TAIL BS6	TATA spare parts
552754630193	WIRING HARNESS SENSOR BS6	TATA spare parts
552754630196	WIRING HARNESS MAIN BS6	TATA spare parts

552754630197	WIRING HARNESS-TAIL BS6	TATA spare parts
552754630198	WIRING HARNESS TAIL	TATA spare parts
552754630199	WIRING HARNESS ABS BS6	TATA spare parts
552754630203	MAIN WIRING HARNESS BS6 PH2	TATA spare parts
552754640101	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
552754640102	WIRING HARNESS ABS BS6	TATA spare parts
552754640104	WIRING HARNESS TAIL BS6	TATA spare parts
552754640123	WIRING HARNESS MAIN BS6	TATA spare parts
552754640124	WIRING HARNESS REVERSE PARK ASSIST BS6	TATA spare parts
552754640133	WIRING HARNESS TAIL	TATA spare parts
552754640136	WIRING HARNESS SWITCH BS6-PH2	TATA spare parts
552754640137	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
552754640139	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
552754640144	WIRING HARNESS H/L & BLINKER BS6-PH2	TATA spare parts
552754640145	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
552754640146	WIRING HARNESS SENSOR BS6-PH2	TATA spare parts
552754640147	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
552754640154	BATTERY CABLE TRUEVE BS6-PH2	TATA spare parts
552754640155	BATTERY CABLE -VE BS6-PH2	TATA spare parts
552754640158	WIRING HARNESS EMS BS6-PH2	TATA spare parts
552754640178	WIRING HARNESS SENSOR BS6-PH2	TATA spare parts
552754650138	WIRING HARNESS ESC BS6-PH2	TATA spare parts
552754650141	WIRING HARNESS ESC BS6-PH2	TATA spare parts
552754650143	WIRING HARNESS SENSOR BS6	TATA spare parts
552754650144	BATTERY CABLE -VE BS6-PH2	TATA spare parts
552754650159	WIRING HARNESS ABS BS6-PH2	TATA spare parts
552754650164	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts
552754650165	WIRING HARNESS ABS BS6-PH2	TATA spare parts
552754650166	WIRING HARNESS MAIN BS6 PH2	TATA spare parts
552754660115	W/H TAIL LP407 34WB CNG BSIV FES OBD2	TATA spare parts
552754700104	BRACKET ASSY SPEED LIMITER MOTOR MTG	TATA spare parts
552754709901	FASTAG	TATA spare parts
552754709903	STEERING ANGLE SENSOR	TATA spare parts
552754709904	YAW RATE SENSOR BS6-PH2	TATA spare parts
552754709908	STEERING ANGLE SENSOR BS6-PH2	TATA spare parts
552754709911	INTELLIGENT BATTERY SENSOR BS6-PH2	TATA spare parts
552754800101	MUSIC SYSTEM	TATA spare parts
552754800104	BRACKET ASSY ABS ECU MTG BS6-PH2	TATA spare parts
552754804901	SOLENOID VALVE BS6	TATA spare parts
552754906801	ADAPTER BS6	TATA spare parts
552754990106	KIT-ELECTRICAL AGGREGATE ASSY	TATA spare parts
55276000001R40	ASSEMBLY BODY FITTED	TATA spare parts
55276000002R4070	PARTIAL FITTED COWL FOR LP407 BSII	TATA spare parts
55276000003R40	ASSEMBLY BODY FITTED	TATA spare parts
55276000004R40	PARTIALLY FITTED CAB W/O ELECTRICALS BS4	TATA spare parts
55276000004R40AWBL	CAB PARTIALLY FITTED LPT407 AW BLW	TATA spare parts
55276000007R40	ASSEMBLY BODY FITTED	TATA spare parts

55276000011R40	ASSEMBLY BODY FITTED	TATA spare parts
55276000012R40	PARTIALLY FITTED CAB W/O ELECTICALS	TATA spare parts
55276000013R40	ASSEMBLY BODY FITTED	TATA spare parts
55276000019R40	ASSEMBLY BODY FITTED	TATA spare parts
55276000055R40	ASSEMBLY BODY FITTED BS6	TATA spare parts
55276000063R40	PARTIALLY FITTED CAB W/O ELECTRICALS BS6	TATA spare parts
55276000171R40	PARTIAL FITTED CAB LPT 710 BS6	TATA spare parts
55276000171R40AWBL	PARTIAL CAB LPT 710 ARTIC WHITE BS6	TATA spare parts
55276000171R40BRBL	PARTIAL CAB LPT 710 BRICK RED BS6	TATA spare parts
55276000171R40NBBL	PARTIAL CAB LPT 710 NEPT-BLUE BS6	TATA spare parts
55276000171R40TWBL	PARTIAL CAB LPT 710 TITANIUM WHITE BS6	TATA spare parts
55276000204R40	610 LPT DCR34HSD 100B6M5_CAB/COWL BS6	TATA spare parts
55276000245R40	709G LPT DCR38CBC 85B6M5 XDL_CAB/COWL BS6	TATA spare parts
552770160101	SUPD ASSY BS6-PH2	TATA spare parts
552783550102	ASSY A/C COMPRESSOR TCCI MAKE (IMPORT) B	TATA spare parts
552783550105	CLUTCH ASSY BS6	TATA spare parts
552791000101	DRIVER SEAT ASSY BS6	TATA spare parts
552791000103	RISER ASSY BS6-PH2	TATA spare parts
552791000104	DRIVER SEAT ASSY BS6	TATA spare parts
552791100102	BRACKET ASSY-DRIVER SEAT MTG BS6	TATA spare parts
552791100107	RISER ASSY BS6	TATA spare parts
552791108206	SPACER BS6	TATA spare parts
5527A9Z0170001	LOAD BODY ASSY BS6-PH2	TATA spare parts
5527D1A1860001	FES STRUCTURE BS6-PH2	TATA spare parts
5527D9Z0160004	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
5527D9Z0160006	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
5527D9Z0160013	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
5527D9Z0160014	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
5527D9Z0160028	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
5527D9Z0160030	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
5527D9Z0160041	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
552815219901	ECU WITH GORE PLUG	TATA spare parts
552831000101	ASSY FRAME XENON 2.2L DICOR SC 4X2 31WB	TATA spare parts
552831000102	ASSY FRAME SC 4X2 31WB PETROL	TATA spare parts
552831000111	FRAME ASSY	TATA spare parts
552831000112	FRAME ASSY	TATA spare parts
552841100101	PROPELLER SHAFT ASSY	TATA spare parts
552841100102	PROPELLER SHAFT ASSY	TATA spare parts
552841100103	PROPELLER SHAFT ASSY	TATA spare parts
552847100101	ASSY.FILLER NECK TOP WITH BRACKET	TATA spare parts
552847100102	FUEL FILLER NECK ASSY	TATA spare parts
552847600103	ASSY. FUEL LINE (CANISTER TO ATMOSPHERE)	TATA spare parts
552847605804	FUEL FILLING HOSE	TATA spare parts
552847605805	FUEL FILLING HOSE	TATA spare parts
552847605806	BREATHER HOSE	TATA spare parts
552847990101	KIT-LOCK	TATA spare parts
552854620107	WIRING HARNESS TAIL	TATA spare parts

552872300101	ASSY LOCK KIT LHD COLLAP STG FLB NG003 M	TATA spare parts
552872300102	KEY SET ASSY KIT RHD NON AB	TATA spare parts
552915400101	ALTERNATOR 12V 120A 8 GR PULLEY BS3/4/6	TATA spare parts
552915400103	ROTOR	TATA spare parts
552915400104	DRIVE¿END¿SHIELD¿ASSY ALTERNATOR	TATA spare parts
552915407001	PULLEY	TATA spare parts
552915409901	PROTECTIVE¿CAP	TATA spare parts
552915409902	REGULATOR	TATA spare parts
552915409903	STATOR	TATA spare parts
552915409904	RECTIFIER BS6	TATA spare parts
552915409905	PROTECTIVE CAP BS6	TATA spare parts
552915409906	FUSE BS6	TATA spare parts
552924000102	BRACKET ASSY ENGINE MTG REAR BS6	TATA spare parts
552924100101	ASSY FOR RH BRACKET ENGINE MOUNT	TATA spare parts
552924100102	ASSEMBY FOR LH BRACKET ENGINE MOUNT	TATA spare parts
552924100105	ENGINE ASSY MTG BKT RH	TATA spare parts
552924100106	ENGINE MTG ASSY LH	TATA spare parts
552924100111	BRACKET ASSY ENGINE MTG FRONT-LH BS6	TATA spare parts
552924100112	BRACKET ASSY ENGINE MTG FRONT-RH BS6	TATA spare parts
552924107116	REINFORCEMENT BS6	TATA spare parts
552924200103	BRACKET ASSY CHASSIS RH	TATA spare parts
552924200104	BRACKET ASSY CHASSIS LH	TATA spare parts
552924200105	BRACKET ASSY ENGINE MTG TOP RH	TATA spare parts
552924200106	BRACKET ASSY ENGINE MTG TOP LH	TATA spare parts
552924200110	BRACKET ASSY ENGINE MTG REAR BS6-PH2	TATA spare parts
55292639000RCK	CABIN KIT FOR ULTRA CX T.16 3.3L CAB BS6	TATA spare parts
55292645000RCK	CABIN KIT FOR ULTRA CX T.16 3.3L HSD BS6	TATA spare parts
552929100106	LEVERASSYCLUTCHPEDAL BS6	TATA spare parts
552929100107	CLUTCH PEDAL ASSY WITH MTG BKT BS6	TATA spare parts
552929300102	BUNDY TUBE ASSY MIDDLE	TATA spare parts
552929300105	BUNDY TUBE ASSY MIDDLE BS6	TATA spare parts
552929300118	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
552929300122	BUNDY TUBE ASSY CMC TO FIREWALL BS6	TATA spare parts
552929500101	BRACKET ASSY CLUTCH PEDAL MTG BS6	TATA spare parts
552930100102	BRKT ASSY ACCELERATOR PEDAL MTG BS6-PH2	TATA spare parts
552930100103	ACCELERATOR PEDAL ASSY BS6-PH2	TATA spare parts
552931000110	FRAME ASSY WITH TOP COAT	TATA spare parts
552931000111	FRAME ASSY WITH TOP COAT	TATA spare parts
552931000112	FRAME ASSY WITH TOP COAT	TATA spare parts
552931000129	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
552931000132	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
552931000135	FRAME ASSY WITH TOP COAT	TATA spare parts
552931000139	FRAME ASSY WITH TOP COAT	TATA spare parts
552931000154	FRAME ASSY WITH FITMENT BS6	TATA spare parts
552931000160	FRAME ASSY WITH FITMENT	TATA spare parts
552931000166	FRAME ASSY WITH FITMENT BS6	TATA spare parts
552931000168	FRAME ASSY WITH TOP COAT BS6	TATA spare parts

552931000173	FRAME ASSY WITH FITMENT BS6	TATA spare parts
552931000175	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
552931000177	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
552931000179	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
55293100M10132	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55293100M10216	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55293100M10222	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55293100M10225	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55293100M10230	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55293100M10232	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
552931010101	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
552931107127	LONG MEMBER RH BS6	TATA spare parts
552931107128	LONG MEMBER LH BS6	TATA spare parts
552931107129	LONG MEMBER RH BS6	TATA spare parts
552931107130	LONG MEMBER LH BS6	TATA spare parts
552931107143	LONG MEMBER RH BS6	TATA spare parts
552931107144	LONG MEMBER LH BS6	TATA spare parts
552931107145	LONG MEMBER RH BS6	TATA spare parts
552931107146	LONG MEMBER LH BS6	TATA spare parts
552931107149	LONG MEMBER RH BS6	TATA spare parts
552931107150	LONG MEMBER LH BS6	TATA spare parts
552931200105	END CROSS MEMBER ASSY	TATA spare parts
552931200111	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
552931200112	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
552931207141	CROSS MEMBER BS6-PH2	TATA spare parts
552931208202	CROSS MEMBER	TATA spare parts
552931208213	END CROSS MEMBER ASSY	TATA spare parts
552931300101	REINFORCEMENT ASSY BS6	TATA spare parts
552931400101	CROSS MEMBER ASSY	TATA spare parts
552931400111	CROSS MEMBER ASSY	TATA spare parts
552931400112	CROSS MEMBER ASSY BS6	TATA spare parts
552931400113	CROSS MEMBER ASSY BS6	TATA spare parts
552931407119	BRACKET BUMP STOPPER MTG REAR	TATA spare parts
552931540101	BRACKET ASSY BATTERY MTG BS6	TATA spare parts
552931540102	BRACKET ASSY BATTERY MTG RH BS6	TATA spare parts
552931540103	BRACKET ASSY BATTERY MTG RH BS6	TATA spare parts
552931543305	BRACKET BOTTOM PLATE BS6	TATA spare parts
552931543306	BRACKET SUPPORT BS6	TATA spare parts
552931543307	BRACKET BOTTOM PLATE BS6	TATA spare parts
552931700105	RUPD ASSY	TATA spare parts
552932100104	SPRING HANGER BKT FRONT ASSY.	TATA spare parts
552932100105	FRONT SPRING ASSY	TATA spare parts
552932100106	1ST LEAF ASSY WITH BUSH	TATA spare parts
552932100111	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
552932100112	LEAF SPRING ASSY FRONT BS6	TATA spare parts
552932100114	LEAF SPRING ASSY FRONT BS6	TATA spare parts
552932100115	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts

552932100116	CLAMP BS6	TATA spare parts
552932100120	FRONT SPRING ASSY BS6	TATA spare parts
552932100124	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
552932100127	LEAF SPRING ASSY FRONT BS6	TATA spare parts
552932100139	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
552932100140	LEAF SPRING ASSY FRONT BS6-PH2	TATA spare parts
552932100152	FRONT SPRING ASSY BS6-PH2	TATA spare parts
552932100153	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
552932103201	CENTRE BOLT M12 X 1.75	TATA spare parts
552932103203	CENTER BOLT BS6	TATA spare parts
552932103205	CENTER BOLT BS6	TATA spare parts
55293210320N	CENTER BOLT BS6-PH2	TATA spare parts
552932103701	SPRING HANGER BKT FRONT RH	TATA spare parts
552932103702	BRACKET SPRING HANGER LH	TATA spare parts
552932103703	BRACKET SPRING HANGER FRONT	TATA spare parts
552932103704	BRACKET SPRING HANGER FRONT-FRONT	TATA spare parts
552932103705	SPRING HANGER BKT FRONT -RWD	TATA spare parts
552932104203	SPRING CLIP	TATA spare parts
552932104204	U-CLAMP	TATA spare parts
552932104210	SPRING CLIP BS6-PH2	TATA spare parts
552932104212	SPRING CLIP BS6	TATA spare parts
552932104213	CLAMP BS6-PH2	TATA spare parts
55293210421N	SPRING CLIP BS6-PH2	TATA spare parts
552932106701	SPRING PIN	TATA spare parts
552932106901	FERRULE BS6	TATA spare parts
552932107106	2ND LEAF	TATA spare parts
552932107107	3RD LEAF	TATA spare parts
552932107108	4TH LEAF	TATA spare parts
552932107117	1ST LEAF BS6	TATA spare parts
552932107118	2ND LEAF BS6	TATA spare parts
552932107119	3RD LEAF BS6	TATA spare parts
552932107120	4TH LEAF BS6	TATA spare parts
552932107121	5TH LEAF BS6	TATA spare parts
552932107122	6TH LEAF BS6	TATA spare parts
552932107123	7TH LEAF BS6	TATA spare parts
552932107124	8TH LEAF BS6	TATA spare parts
552932107125	9TH LEAF BS6	TATA spare parts
552932107126	4TH LEAF BS6	TATA spare parts
552932107128	3RD LEAF BS6	TATA spare parts
552932107129	2ND LEAF BS6	TATA spare parts
552932107135	2ND LEAF BS6	TATA spare parts
552932107136	3RD LEAF BS6	TATA spare parts
552932107137	1ST LEAF BS6	TATA spare parts
552932107139	4TH LEAF BS6	TATA spare parts
552932107140	SPACER BS6	TATA spare parts
552932107153	4TH LEAF BS6-PH2	TATA spare parts
552932107154	3RD LEAF BS6-PH2	TATA spare parts

552932107157	2ND LEAF BS6-PH2	TATA spare parts
552932107187	2ND LEAF BS6-PH2	TATA spare parts
552932107188	3RD LEAF BS6-PH2	TATA spare parts
552932107189	4TH LEAF BS6-PH2	TATA spare parts
552932107401	RIVET BS6	TATA spare parts
552932107402	RIVET BS6	TATA spare parts
552932108303	CENTER PAD BS6-PH2	TATA spare parts
552932108603	SPACER BS6-PH2	TATA spare parts
552932200101	BUMP STOPPER ASSY FRONT	TATA spare parts
552932200104	BUMP STOPPER ASSY FRONT BS6-PH2	TATA spare parts
552932204203	U-CLAMP	TATA spare parts
552932204208	U-CLAMP FRONT SPRING BS6-PH2	TATA spare parts
552932207101	SHACKLE PLATE	TATA spare parts
552932207111	CASTER PLATE	TATA spare parts
552932207113	CASTER PLATE BS6	TATA spare parts
552932207114	CASTER PLATE BS6	TATA spare parts
552932207115	CASTER PLATE BS6	TATA spare parts
552932207116	SPACER BS6	TATA spare parts
552932207117	SPACER BS6	TATA spare parts
552932207122	CASTER PLATE BS6	TATA spare parts
552932300101	BRACKET ASSY SHOCK ABSORBER MTG FRONT	TATA spare parts
552932300102	SHOCK ABSORBER ASSY FRONT	TATA spare parts
552932300106	BRACKET ASSY SHOCK ABSORBER MTG FRONT BS	TATA spare parts
552932307101	BRACKET SHOCK ABSORBER MTG FRONT-LOWER	TATA spare parts
552932308201	BRACKET SHOCK ABSORBER MTG FRONT-LOWER	TATA spare parts
552932308207	LOCKING PLATE BS6-PH2	TATA spare parts
552932400101	ASSY.FIRST LEAF WITH BUSHES	TATA spare parts
552932400103	LEAF SPRING ASSY WITH AUX SPRING REAR	TATA spare parts
552932400111	LEAF SPRING ASSY REAR BS6	TATA spare parts
552932400112	CLAMP ASSY BS6	TATA spare parts
552932400113	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
552932400118	CLAMP ASSY BS6	TATA spare parts
552932400120	SHACKLE ASSY BS6	TATA spare parts
552932400125	BRACKET ASSY SPRING HANGER REAR BS6-PH2	TATA spare parts
552932400128	LEAF SPRING ASSY WITH AUX SPRING REAR BS	TATA spare parts
552932400129	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
552932400130	SHACKLE ASSY BS6-PH2	TATA spare parts
552932403201	CENTER BOLT	TATA spare parts
552932403203	CENTER BOLT BS6	TATA spare parts
552932403204	CLAMP BOLT BS6	TATA spare parts
552932403303	BRACKET SPRING SUPPORT	TATA spare parts
552932403304	BRACKET SPRING HANGER REAR-FRONT BS6	TATA spare parts
552932403305	BRACKET SPRING HANGER REAR-REAR BS6	TATA spare parts
552932403502	BOSS BS6	TATA spare parts
552932403701	BRACKET SPRING HANGER REAR-FRONT	TATA spare parts
552932403702	SPRING HANGER BRACKET REAR	TATA spare parts
552932403706	BRACKET SPRING HANGER REAR BS6-PH2	TATA spare parts

552932403707	SLIDE SUPPORT BS6-PH2	TATA spare parts
552932404205	CLAMP SPRING	TATA spare parts
552932407102	2ND LEAF	TATA spare parts
552932407103	3RD LEAF	TATA spare parts
552932407104	4TH LEAF	TATA spare parts
552932407105	5TH LEAF	TATA spare parts
552932407106	6TH LEAF	TATA spare parts
552932407107	7TH LEAF	TATA spare parts
552932407108	8TH LEAF	TATA spare parts
552932407109	9TH LEAF	TATA spare parts
552932407113	1ST LEAF AUX SPRING	TATA spare parts
552932407114	2ND LEAF AUX SPRING	TATA spare parts
552932407115	3RD LEAF AUX SPRING	TATA spare parts
552932407122	SPACER PLATE	TATA spare parts
552932407130	3RD LEAF BS6	TATA spare parts
552932407131	5TH LEAF BS6	TATA spare parts
552932407132	4TH LEAF BS6	TATA spare parts
552932407133	2ND LEAF BS6	TATA spare parts
552932407134	SHACKLE BS6	TATA spare parts
552932407152	SHACKLE BS6-PH2	TATA spare parts
552932407154	2ND LEAF BS6-PH2	TATA spare parts
552932407155	3RD LEAF BS6-PH2	TATA spare parts
552932407156	4TH LEAF BS6-PH2	TATA spare parts
552932407157	5TH LEAF BS6-PH2	TATA spare parts
552932407158	6TH LEAF BS6-PH2	TATA spare parts
552932407160	7TH LEAF BS6-PH2	TATA spare parts
552932407161	8TH LEAF BS6-PH2	TATA spare parts
552932407162	9TH LEAF BS6-PH2	TATA spare parts
552932407163	1ST LEAF AUX SPRING BS6-PH2	TATA spare parts
552932407164	2ND LEAF AUX SPRING BS6-PH2	TATA spare parts
552932407165	3RD LEAF AUX SPRING BS6-PH2	TATA spare parts
552932407166	4TH LEAF AUX SPRING BS6-PH2	TATA spare parts
552932407167	5TH LEAF AUX SPRING BS6-PH2	TATA spare parts
552932407168	6TH LEAF AUX SPRING BS6-PH2	TATA spare parts
552932407169	7TH LEAF AUX SPRING BS6-PH2	TATA spare parts
552932407170	CASTER PLATE	TATA spare parts
552932408303	CENTER PAD BS6	TATA spare parts
552932408603	SPACER TUBE BS6	TATA spare parts
552932408604	SPACER TUBE BS6	TATA spare parts
552932408605	SPACER BS6-PH2	TATA spare parts
552932500104	REAR AXLE STOPPER ASSY	TATA spare parts
552932503703	GUIDE PLATE BS6	TATA spare parts
552932504201	U-BOLT	TATA spare parts
552932504202	U-BOLT	TATA spare parts
552932504204	U-CLAMP BS6	TATA spare parts
552932800103	CONNCTING LINK ASSY	TATA spare parts
552932800104	ANTI ROLL BAR ASSY WITH LINK	TATA spare parts



552932800110	CONNECTING LINK ASSY BS6	TATA spare parts
552932800111	ANTI ROLL BAR ASSY FRONT BS6	TATA spare parts
552932800114	LINK ASSY ANTI ROLL BAR FRONT BS6	TATA spare parts
552932800115	ANTI ROLL BAR ASSY FRONT BS6	TATA spare parts
552932800117	ANTI ROLL BAR ASSY WITH LINK BS6-PH2	TATA spare parts
552932800118	CONNECTING LINK ASSY FRONT BS6-PH2	TATA spare parts
552932800119	BRACKET ASSY ANTI ROLL BAR MTG FRONT BS6	TATA spare parts
552932803303	BRACKET ANTI ROLL BAR MTG LOWER-RH	TATA spare parts
552932803304	BRACKET ANTI ROLL BAR MTG LOWER-LH	TATA spare parts
552932803305	BRACKET ANTI ROLL BAR MTG LOWER-RH BS6	TATA spare parts
552932803306	BRACKET ANTI ROLL BAR MTG LOWER-LH BS6	TATA spare parts
552932803312	BRACKET ANTI ROLL BAR LINK LH BS6	TATA spare parts
552932803313	BRACKET ANTI ROLL BAR LINK RH BS6	TATA spare parts
552932806002	CONNECTING LINK BS6	TATA spare parts
552932806003	CONNECTING LINK BS6-PH2	TATA spare parts
552932807903	ANTI ROLL BAR BS6	TATA spare parts
552932900102	ANTI ROLL BAR ASSY BS6	TATA spare parts
552932900103	CONNECTING LINK ASSY REAR BS6	TATA spare parts
552932903303	BRACKET ANTI ROLL BAR MTG LOWER BS6	TATA spare parts
552932906001	CONNECTING LINK BS6	TATA spare parts
552933000106	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
552933000107	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
552933000108	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
552933000113	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
552933105105	FRONT AXLE BEAM	TATA spare parts
552933105109	FRONT AXLE BEAM BS6-PH2	TATA spare parts
552933200105	STUB AXLE SEALING CAP WITH GREASE NIPPLE	TATA spare parts
552933209201	PACKING HUB CAP BS6	TATA spare parts
552933209206	THRUST WASHER BS6-PH2	TATA spare parts
552933209209	THRUST WASHER - 1.1 MM THK BS6-PH2	TATA spare parts
552933209210	THRUST WASHER - 1.2 MM THK BS6-PH2	TATA spare parts
552933209211	THRUST WASHER - 1.3 MM THK BS6-PH2	TATA spare parts
552933209212	THRUST WASHER - 1.4 MM THK BS6-PH2	TATA spare parts
552933209213	THRUST WASHER - 1.5 MM THK BS6-PH2	TATA spare parts
552933209214	THRUST WASHER - 1.6 MM THK BS6-PH2	TATA spare parts
552933209215	THRUST WASHER - 1.7 MM THK BS6-PH2	TATA spare parts
552933400105	FRONT HUB ASSY - BS6-PH2	TATA spare parts
552933400106	FRONT HUB ASSY ABS BS6-PH2	TATA spare parts
552933405501	WHEEL HUB (FRONT-CAST)	TATA spare parts
552933800101	TIE ROD ASSY BS6	TATA spare parts
552933800102	TIE ROD ASSY	TATA spare parts
552933800103	BALL JOINT ASSY RH	TATA spare parts
552933800104	BALL JOINT ASSY LH	TATA spare parts
552933800106	TIE ROD ASSY BS6-PH2	TATA spare parts
552933800109	TIE ROD ASSY BS6-PH2	TATA spare parts
552933805102	TIE ROD ARM RH	TATA spare parts
552933805103	TIE ROD ARM LH	TATA spare parts

552933805104	STEERING ARM	TATA spare parts
552933805105	STEERING ARM BS6	TATA spare parts
552933805107	TIE ROD ARM RH BS6-PH2	TATA spare parts
552933805108	TIE ROD ARM LH BS6-PH2	TATA spare parts
552940109901	TYRE FRONT	TATA spare parts
552941100102	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
552941100103	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
552941108201	SUPPORT PROPELLER SHAFT GUARD BS6-PH2	TATA spare parts
552941110104	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
552941110121	COUPLING SHAFT ASSY WITH CENTER BEARING	TATA spare parts
552941110128	COUPLING SHAFT ASSY	TATA spare parts
552941110130	PROPELLERSHAFTASSY COUPLING BS6	TATA spare parts
552941110133	PROPELLER SHAFT ASSY FRONT BS6	TATA spare parts
552941110135	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
552941110137	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
552941110138	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
552941110142	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
552941110148	PROPELLER SHAFT ASSY COUPLING BS6-PH2	TATA spare parts
552941120105	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
552941120116	PROPELLER SHAFT ASSY REAR BS6	TATA spare parts
552941120122	PROPELLER SHAFT ASSY REAR	TATA spare parts
552941120126	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
552941120137	PROPELLER SHAFT ASSY DRIVEçBS6	TATA spare parts
552941120138	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
552941120140	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
552941120143	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
552941120145	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
552941120148	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
552941120149	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
552941120152	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
552941129901	SHORT FORK TUBE ASSY BS6	TATA spare parts
552941300101	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
552941307101	BRACKET PROPELLER SHAFT GUARD MTG	TATA spare parts
552941307102	BRACKET CENTER BRG MTG	TATA spare parts
552941307103	BRACKET CENTER BRG MTG BS6	TATA spare parts
552941307104	BRACKET-CENTER BRG MTG BS6	TATA spare parts
552941307105	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
552941307107	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
552941308202	BRACKET CENTER BRG MTG	TATA spare parts
552941308204	GUARD PROPELLER SHAFT BS6	TATA spare parts
552942100104	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
552942100105	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
552942100158	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
552942100159	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
552942100160	DRUM BRAKE ASSY WITH DC FRONT-LH BS6-PH2	TATA spare parts
552942100161	DRUM BRAKE ASSY WITH DC FRONT-RH BS6-PH2	TATA spare parts
552942103702	BRAKE DRUM FRONT	TATA spare parts

552942109905	KIT-RIVET	TATA spare parts
552942300105	DRUM BRAKE ASSY WITH DC REAR-LH	TATA spare parts
552942300106	DRUM BRAKE ASSY WITH DC REAR-RH	TATA spare parts
552942300111	BRACKET ASSY ACTUATOR MTG REAR-LHBS6	TATA spare parts
552942300112	BRACKET ASSY ACTUATOR MTG REAR-RHBS6	TATA spare parts
552942300135	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts
552942300137	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
552942300155	BRAKE DRUM ASSY REAR-LH BS6-PH2	TATA spare parts
552942300156	BRAKE DRUM ASSY REAR-RH BS6-PH2	TATA spare parts
552942300157	BRAKE DRUM ASSY-REAR-LH BS6	TATA spare parts
552942300158	BRAKE DRUM ASSY-REAR-RH BS6	TATA spare parts
552942303301	BRACKET ASSY SENSOR MTG REAR	TATA spare parts
552942303702	BRAKE DRUM	TATA spare parts
552942990107	BRAKE ASSY MINOR O/H KIT	TATA spare parts
552942990108	BRAKE ASSY MINOR SERVICE KIT	TATA spare parts
552942990109	BRAKE ASSY BRAKE SHOE & LINING KIT	TATA spare parts
552942990110	BRAKE LINING KIT(STD)360X170 NA1707 BS6	TATA spare parts
552942990117	BRAKE ASSY BRAKE SPRING KIT	TATA spare parts
552942990119	BRAKE ASSY CAM SHAFT REPAIR KIT-REAR	TATA spare parts
552942990120	BRAKE ASSY CAM SHAFT REPAIR KIT-FRONT	TATA spare parts
552942995102	CAM SHAFT-LH	TATA spare parts
552942995103	CAM SHAFT-RH	TATA spare parts
552942995104	CAM SHAFT LH	TATA spare parts
552942995105	CAM SHAFT RH	TATA spare parts
552942998701	SPRING BRAKE-SHOE RETAINING.	TATA spare parts
552942998702	BRAKE ASSY RETURN SPRING-BRAKE SHOE	TATA spare parts
552943200101	AIR TANK ASSY LH BS6	TATA spare parts
552943200102	AIR TANK ASSY RH BS6	TATA spare parts
552943200107	AIR TANK ASSY WITH MTG BKT BS6	TATA spare parts
552943200108	AIR TANK ASSY WITH MTG BKT BS6	TATA spare parts
552943200112	AIR TANK ASSY WITH BKT BS6	TATA spare parts
552943200115	BRACKET ASSY AIR TANK MTG BS6-PH2	TATA spare parts
552943200116	AIR TANK ASSY WITH BKTS & STRAP BS6-PH2	TATA spare parts
552943200118	AIR TANK ASSY WITH BKT BS6	TATA spare parts
552943200120	AIR TANK ASSY WITH BKT BS6	TATA spare parts
552943200152	AIR TANK ASSY WITH BKTS & STRAP BS6	TATA spare parts
552943700101	BRACKET ASSY APDA MTG BS6	TATA spare parts
552943700121	PRESSURE TEST-CONNECTOR BS6	TATA spare parts
552943700143	BRAKE CHAMBER BS6	TATA spare parts
552943700151	ANTI ROLL BACK ASSY BS6-PH2	TATA spare parts
552943700165	BRAKE CHAMBER BS6	TATA spare parts
552943700166	BRAKE CHAMBER BS6-PH2	TATA spare parts
552943700168	BRAKE CHAMBER BS6-PH2	TATA spare parts
552943700183	SPRING BRAKE ACTUATOR BS6	TATA spare parts
552943700184	SPRING BRAKE ACTUATOR BS6	TATA spare parts
552943800107	TUBE ASSY WITH CRIMPED RUBBER HOSE	TATA spare parts
552943800110	TUBE ASSY HOSE TO ADAPTER	TATA spare parts

552943800115	METAL PIPE WITH CRIMPED HOSE BS6	TATA spare parts
552943800118	METAL PIPE ASSY ADAPTER TO ADAPTER BS6-P	TATA spare parts
552943800119	METAL PIPE ASSY ADAPTER TO ADAPTER BS6-P	TATA spare parts
552943800120	METAL PIPE ASSY ADAPTER TO APU BS6-PH2	TATA spare parts
552943800121	METAL PIPE ASSY HOSE TO ADAPTER BS6-PH2	TATA spare parts
552943800122	METAL PIPE ASSY JOINT TO DDU BS6-PH2	TATA spare parts
552943810101	METAL PIPE ASSY BS6	TATA spare parts
552943810104	METAL PIPE ASSY BS6	TATA spare parts
552943810106	METAL PIPE ASSY ADAPTER TO APU	TATA spare parts
552943810107	METAL PIPE ASSY ADAPTER TO ADAPTER	TATA spare parts
552943810108	METAL PIPE ASSY HOSE TO ADAPTER	TATA spare parts
552943810109	METAL PIPE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts
552943810110	METAL PIPE ASSY ADAPTER TO APU BS6	TATA spare parts
552943900202	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
552943900216	METAL PIPE ASSY JOINT TO DDU BS6	TATA spare parts
552943900271	NYLON PIPE BUNCH ASSY BS6	TATA spare parts
552943903301	BRACKET BS6-PH2	TATA spare parts
552943910163	PIPE BUNCH ASSY CABIN	TATA spare parts
552943910166	PIPE BUNCH ASSY CHASSIS	TATA spare parts
552943910185	PIPE BUNCH ASSY CHASSIS	TATA spare parts
552943910196	PIPE BUNCH ASSY CHASSIS	TATA spare parts
552943920132	TUBE ASSY HOSE TO ADAPTER	TATA spare parts
552943920136	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
552943920138	PIPE BUNCH ASSY CABIN BS6	TATA spare parts
552943920140	PIPE BUNCH ASSY CHASSIS	TATA spare parts
552943920150	NYLON PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
552943920175	NYLON PIPE ASSY CHASSIS BS6	TATA spare parts
552943920180	NYLON PIPE BUNCH ASSY CABIN BS6	TATA spare parts
552943920184	PIPE BUNCH ASSY CABIN	TATA spare parts
552943920199	NYLON PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
552943930103	PIPE BUNCH ASSY CABIN BS6	TATA spare parts
552943930127	NYLON PIPE BUNCH ASSY CHASSIS	TATA spare parts
552943930128	PIPE BUNCH ASSY CABIN	TATA spare parts
552943930141	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
552943930165	AIR TANK ASSY RH&BS6	TATA spare parts
552943930174	NYLON PIPE BUNCH ASSY CABIN BS6	TATA spare parts
552943930177	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
552943930193	NYLON PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
552943930199	NYLON PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
552943940158	NYLON PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
552943940168	NYLON PIPE ASSY CHASSIS BS6	TATA spare parts
552943950202	HOSE ASSY FRONT BRAKE CHAMBER	TATA spare parts
552946100104	STEERING COLUMN ASSY WITH BELLOW BS6-PH2	TATA spare parts
552946100105	STEERING COLUMN ASSY BS6-PH2	TATA spare parts
552946100106	STEERING COLUMN ASSY BS6-PH2	TATA spare parts
552946305101	PITMAN ARM BS6	TATA spare parts
552946305102	PITMAN ARM BS6	TATA spare parts

552946305103	PITMAN ARM BS6-PH2	TATA spare parts
552946306002	PITMAN ARM	TATA spare parts
552946600109	STEERING GEAR BOX ASSY	TATA spare parts
552946600111	BRACKET ASSY RESERVOIR MTG BS6	TATA spare parts
552946600112	STEERING GEAR BOX ASSY BS6	TATA spare parts
552946600113	HOUSING ASSY BS6	TATA spare parts
552946600114	WORM & RACK ASSY BS6	TATA spare parts
552946600115	SHAFT ASSY BS6	TATA spare parts
552946600117	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
552946600120	HOUSING COVER ASSY BS6-PH2	TATA spare parts
552946600122	HOUSING ASSY BS6-PH2	TATA spare parts
552946600124	PISTON ASSY BS6-PH2	TATA spare parts
552946600125	SECTOR SHAFT ASSY BS6-PH2	TATA spare parts
552946600131	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
552946600134	POWER STEERING PUMP ASSY BS6-PH2	TATA spare parts
552946700102	BRACKET ASSY POWER STRG PUMP MTG BS6-PH2	TATA spare parts
552946700103	BRACKET ASSY RESERVOIR MTG BS6-PH2	TATA spare parts
552946700108	BRACKET ASSY RESERVOIR MTG	TATA spare parts
552946703302	BRACKET STG GEAR BOX MTG BS6	TATA spare parts
552946703701	BRACKET STG GEAR BOX MTG	TATA spare parts
552946800106	SUCTION LINE ASSY	TATA spare parts
552946800107	HIGH PRESSURE LINE ASSY	TATA spare parts
552946800108	RETURN LINE ASSY	TATA spare parts
552946800109	SUCTION LINE ASSY BS6	TATA spare parts
552946800115	PRESSURE LINE ASSY BS6	TATA spare parts
552946800117	RETURN LINE ASSY GEAR BOX TO INT JOINT B	TATA spare parts
552946800119	SUCTION LINE ASSY¿BS6	TATA spare parts
552946800122	RETURN LINE ASSY RESERVOIR TO JOINT¿BS6	TATA spare parts
552946800123	RETURN LINE ASSY RESERVOIR TO JOINT¿BS6	TATA spare parts
552946800126	SUCTION LINE ASSY BS6-PH2	TATA spare parts
552946800127	PRESSURE LINE ASSY BS6-PH2	TATA spare parts
552946800128	RETURN LINE ASSY BS6-PH2	TATA spare parts
552946800129	RETURN LINE ASSY BS6-PH2	TATA spare parts
552946803301	L-BRACKET BS6	TATA spare parts
552946900104	DRAG LINK ASSY	TATA spare parts
552946900107	DRAG LINK ASSY BS6	TATA spare parts
552946900108	DRAG LINK ASSY BS6	TATA spare parts
552946900109	DRAG LINK ASSY BS6	TATA spare parts
552946900111	DRAG LINK END ASSY BS6-PH2	TATA spare parts
552946900113	DRAG LINK ASSY BS6-PH2	TATA spare parts
552946900115	DRAG LINK BS6-PH2	TATA spare parts
552946990102	VALVE INSERT ASSY	TATA spare parts
552946990103	HOUSING COVER ASSY	TATA spare parts
552946990105	SECTOR SHAFT ASSY	TATA spare parts
552946990132	KIT-SEAL INPUT SHAFT BS6	TATA spare parts
552946990147	KIT-SEAL BS6-PH2	TATA spare parts
552946990150	SET-STEERING COMPONENT BS6-PH2	TATA spare parts

552947100102	BRACKET ASSY BS6	TATA spare parts
552947508201	BRACKET BS6-PH2	TATA spare parts
552947600101	FUEL SUCTION PIPE ASSY TANK TO P/FILTER	TATA spare parts
552947600103	FUEL SUCTION PIPE ASSY W/SEP TO FIP	TATA spare parts
552947600104	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
552947600108	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
552947600113	SUCTION LINE PIPE ASSY	TATA spare parts
552947600114	FUEL SUCTION PIPE ASSY	TATA spare parts
552947600115	SUCTION PIPE ASSY PRE FILTER TO FILTER	TATA spare parts
552947600116	SUCTION PIPE ASSY FILTER TO FIP	TATA spare parts
552947600117	FUEL RETURN PIPE ASSY ENG TO FUEL TANK	TATA spare parts
552947600118	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
552947600119	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
552947600120	RETURN FUEL PIPE ASSY BS6	TATA spare parts
552947600129	VENT TUBE ASSY BS6	TATA spare parts
552947600143	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
552947600144	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
552947600145	RETURN FUEL PIPE ASSY BS6	TATA spare parts
552947600149	FUEL PIPE ASSY FILTER TO ENGINE BS6	TATA spare parts
552947600159	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
552947600160	SUCTION FUEL PIPE ASSY BS6-PH2	TATA spare parts
552947600164	RETURN FUEL PIPE ASSY BS6-PH2	TATA spare parts
552947600165	SUCTION FUEL PIPE ASSY BS6-PH2	TATA spare parts
552947600166	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
552947608202	BRACKET FOR PREFILTER	TATA spare parts
552947610158	SUCTION FUEL PIPE ASSY BS6-PH2	TATA spare parts
552947610159	RETURN FUEL PIPE ASSY BS6-PH2	TATA spare parts
552947703301	BRACKET	TATA spare parts
552947703302	BRACKET MAIN FILTER MTG	TATA spare parts
552947703303	BRACKET FUEL FILTER MTG BS6	TATA spare parts
552949100101	PIPE ASSY DPS SENSOR INTAKE	TATA spare parts
552949100102	PIPE ASSY DPS SENSOR REAR	TATA spare parts
552949100103	PIPE ASSY DPS SENSOR INTAKE	TATA spare parts
552949100104	PIPE ASSY DPS SENSOR REAR	TATA spare parts
552949100114	SILENCER ASSY	TATA spare parts
552949103302	HANGER BRACKET BS6	TATA spare parts
552949200105	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
552949200108	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
552949200119	UREA TANK ASSY BS6	TATA spare parts
552949200120	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
552949200122	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
552949200125	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
552949200128	PIPE ASSY FRONT BS6	TATA spare parts
552949200132	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
552949200139	BRACKET ASSY TAIL PIPE MTG BS6	TATA spare parts
552949200140	BRACKET ASSY EGP MTG BS6	TATA spare parts
552949200143	CLAMP ASSY CATCON MTG BS6	TATA spare parts

552949200151	EXHAUST PIPE ASSY INT BS6	TATA spare parts
552949200152	FLEX BELLOW ASSY BS6	TATA spare parts
552949200156	TAIL PIPE ASSY BS6	TATA spare parts
552949200157	EXHAUST TAIL PIPE ASSY BS6	TATA spare parts
552949203301	BRACKET FRONT PIPE MTG	TATA spare parts
552949203306	L-BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
552949203308	BRACKET BS6	TATA spare parts
552949203315	BRACKET BS6	TATA spare parts
552949203403	THREADED INSERT M5*1.5 BS6	TATA spare parts
552949203404	DRAIN INSERT M14*1.5 BS6	TATA spare parts
552949204202	STRAP DOC POC MTG	TATA spare parts
552949207801	O-RING BS6	TATA spare parts
552949207802	O-RING BS6	TATA spare parts
552949208203	CLAMP BS6	TATA spare parts
552949208205	CLAMP BS6	TATA spare parts
552949600107	HEAT SHIELD ASSY BS6	TATA spare parts
552949600110	HEAT SHIELD ASSY BS6	TATA spare parts
552949600114	HEAT SHIELD ASSY	TATA spare parts
552949600116	HEAT SHIELD ASSY	TATA spare parts
552954103301	BRACKET STOPPER MTG BS6-PH2	TATA spare parts
552954103302	CLAMP BATTERY MTG BS6-PH2	TATA spare parts
552954400102	ROOF LAMP ASSY BS6	TATA spare parts
552954400106	BRACKET ASSY LH BS6	TATA spare parts
552954400107	BRACKET ASSY RH BS6	TATA spare parts
552954500105	CLUSTER ASSY CENTER BS6	TATA spare parts
552954500111	STEERING LOCK & IGNITION SWITCH ASSY BS6	TATA spare parts
552954500113	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
552954501605	SWITCH EXHAUST BRAKE BS6	TATA spare parts
552954501617	SWITCH ABS DIAGNOSTICS BS6	TATA spare parts
552954501620	SWITCH EMERGENCY HELP BS6	TATA spare parts
552954501624	SWITCH HEADLAMP LEVELLING BS6	TATA spare parts
552954504902	SWITCH HILL ASSIST BS6	TATA spare parts
552954504903	SWITCH-REGENERATION INHIBIT BS6	TATA spare parts
552954504904	SWITCH-REGENERATION START MANUAL BS6	TATA spare parts
552954506302	DUMMY SWITCH DASHBOARD LH BS6	TATA spare parts
552954506303	DUMMY SWITCH DASHBOARD CENTER BS6	TATA spare parts
552954506305	DUMMY SWITCH DASHBOARD RH BS6	TATA spare parts
552954509920	REMOTE CUT OFF SWITCH BATTERY BS6	TATA spare parts
552954600111	WIRING HARNESS ABS FRAME	TATA spare parts
552954600118	WIRING HARNESS REAR CHASSIS	TATA spare parts
552954600127	WIRING HARNESS FRONT CHASSIS	TATA spare parts
552954600128	WIRING HARNESS ENGINE	TATA spare parts
552954600137	WIRING HARNESS FRONT CHASSIS	TATA spare parts
552954600139	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
552954600141	WIRING HARNESS ENGINE	TATA spare parts
552954600149	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
552954600150	WIRING HARNESS ABS FRAME	TATA spare parts

552954600151	WIRING HARNESS ABS FRAME	TATA spare parts
552954600152	WIRING HARNESS ABS FRAME	TATA spare parts
552954600173	WIRING HARNESS LOAD BODY BS6	TATA spare parts
552954600181	CCBASSY BS6	TATA spare parts
552954600183	ARMATURE ASSY BS6	TATA spare parts
552954600194	BATTERY CABLE +VE BCS TO MEGA FUSE	TATA spare parts
552954600195	BATTERY CABLE +VE	TATA spare parts
552954600196	WIRING HARNESS REAR CHASSIS	TATA spare parts
552954600199	STARTER CABLE	TATA spare parts
552954601617	WIRING HARNESS REAR CHASSIS	TATA spare parts
552954601621	WIRING HARNESS ENGINE	TATA spare parts
552954603302	L-BRACKET CONNECTOR MTG BS6	TATA spare parts
552954606301	FUSE BOX COVER	TATA spare parts
552954606302	FUSE BOX COVER	TATA spare parts
552954609905	STICKER MAXI FUSE BOX BS6	TATA spare parts
552954610102	WIRING HARNESS ENGINE BS6	TATA spare parts
552954610104	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
552954610106	WIRING HARNESS PIGTAIL BS6	TATA spare parts
552954610107	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
552954610108	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
552954610109	WIRING HARNESS INSTRUMENT PANEL BS6	TATA spare parts
552954610110	PIGTAIL ALTERNATOR +VE BS6	TATA spare parts
552954610111	BATTERY CABLE +VE BCS TO MEGA FUSE BS6	TATA spare parts
552954610112	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
552954610113	BATTERY CABLE +VE BS6	TATA spare parts
552954610114	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
552954610115	BATTERY CABLE -VE	TATA spare parts
552954610116	WIRING HARNESS REAR CHASSIS	TATA spare parts
552954610123	WIRING HARNESS FLOOR BS6	TATA spare parts
552954610125	WIRING HARNESS ROOF BS6	TATA spare parts
552954610127	WIRING HARNESS EGP PIGTAIL BS6	TATA spare parts
552954610130	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
552954610138	ENG MTG BRACKET BS6	TATA spare parts
552954610140	WIRING HARNESS LOAD BODY BS6	TATA spare parts
552954610143	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
552954610144	WIRING HARNESS ABS FRAME BS6	TATA spare parts
552954610145	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
552954610146	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
552954610148	PIGTAIL ALTERNATOR +VE BS6	TATA spare parts
552954610154	WIRING HARNESS LOAD BODY BS6	TATA spare parts
552954610157	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
552954610158	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
552954610175	WIRING HARNESS REVERSE PARK ASSIST BS6	TATA spare parts
552954610179	WIRING HARNESS EGP PIGTAIL BS6	TATA spare parts
552954610180	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
552954610181	WIRING HARNESS ABS FRAME 4S4M BS6	TATA spare parts
552954610195	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts



552954610196	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
552954610197	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
552954620108	WIRING HARNESS REAR CHASSIS	TATA spare parts
552954620112	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
552954630116	WIRING HARNESS EGP BS6-PH2	TATA spare parts
552954630120	WIRING HARNESS FRONT CHASSIS BS6-PH2	TATA spare parts
552954630121	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
552954630126	WIRING HARNESS ABS	TATA spare parts
552954630139	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
552954630140	WIRING HARNESS REVERSE PARK ASSIST BS6-P	TATA spare parts
552954630141	WIRING HARNESS EGP BS6-PH2	TATA spare parts
552954630144	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
552954630145	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
552954630147	WIRING HARNESS ABS FRAME	TATA spare parts
552954640101	BATTERY CABLE -VE BS6-PH2	TATA spare parts
552954700102	BRACKET ASSY VECU MTG BS6	TATA spare parts
552954700104	BRACKET ASSY GDCU UNIT MOUNTING BS6-PH2	TATA spare parts
552958604002	JACK CLAMP BS6	TATA spare parts
552958903301	BEARING INSTALLATION TOOL -DRIFT BS6-PH2	TATA spare parts
552958903302	BEARING REMOVAL TOOL-DRIFT BS6-PH2	TATA spare parts
552958903303	THREAD PROTECTION TOOL BS6-PH2	TATA spare parts
55296000002R40	ASSEMBLY BODY FITTED	TATA spare parts
55296000117R40	PARTIAL FITTED CAB W/O FITMENT ULTRA T.1	TATA spare parts
55296000147R40	ASSY PARTIAL FITTED CAB ULTRA BS6	TATA spare parts
552970000101	LOAD BODY ASSY BS6-PH2	TATA spare parts
552970000110	LOAD BODY ASSY BS6-PH2	TATA spare parts
552970000155	LOAD BODY ASSY BS6-PH2	TATA spare parts
552970100114	SUPD ASSY LH BS6-PH2	TATA spare parts
552970100119	SUPD ASSY LH BS6-PH2	TATA spare parts
552970100120	SUPD ASSY RH BS6-PH2	TATA spare parts
552970100126	SUPD ASSY LH BS6-PH2	TATA spare parts
552970100127	SUPD ASSY LH BS6-PH2	TATA spare parts
552970100133	SUPD ASSY BS6-PH2	TATA spare parts
552970100134	SUPD ASSY BS6-PH2	TATA spare parts
552970100136	SUPD ASSY BS6-PH2	TATA spare parts
552970100137	SUPD ASSY LH BS6-PH2	TATA spare parts
552970100138	SUPD ASSY RH BS6-PH2	TATA spare parts
552970100139	SUPD ASSY	TATA spare parts
552970100140	SUPD ASSY LH BS6-PH2	TATA spare parts
552970100141	SUPD ASSY RH BS6-PH2	TATA spare parts
552970100144	SUPD ASSY LH	TATA spare parts
552970100145	SUPD ASSY RH	TATA spare parts
552970100150	SUPD ASSY	TATA spare parts
552970100155	SUPD ASSY BS6-PH2	TATA spare parts
552970100179	SUPD ASSY LH BS6-PH2	TATA spare parts
552970100180	SUPD ASSY RH BS6-PH2	TATA spare parts
552970100182	SUPD ASSY BS6-PH2	TATA spare parts

552970100183	SUPD ASSY LH BS6-PH2	TATA spare parts
552970100184	SUPD ASSY RH BS6-PH2	TATA spare parts
552970106011	MUDGUARD CENTER BS6	TATA spare parts
552970106012	MUDFLAP BS6-PH2	TATA spare parts
552970106302	MUDFLAP BS6-PH2	TATA spare parts
5529A9Z0170001	LOADBODY FITTED ASSY MFG BS6-PH2	TATA spare parts
5529A9Z0170002	LOADBODY FITTED ASSY MFG BS6-PH2	TATA spare parts
5529A9Z0170006	LOADBODY FITTED ASSY MFG BS6-PH2	TATA spare parts
5529A9Z0170007	LOADBODY FITTED ASSY MFG BS6-PH2	TATA spare parts
5529A9Z0170008	LOAD BODY FITTED ASSY MFG BS6-PH2	TATA spare parts
5529H9X0233002	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
5529H9X0233003	FRONT AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
5529H9X0233012	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
5529H9X0233014	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
5529H9X0233015	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
553000990107	KIT FUEL ELECTRONIC FEED PUMP 160L FT	TATA spare parts
553000990108	KIT FUEL ELECTRONIC FEED PUMP 160L FT	TATA spare parts
55301145000R40	PARTIALLY FITTED CAB W/O ELECT&CONTROLS.	TATA spare parts
553016102001	ECU HARDWARE BS6-PH2	TATA spare parts
553016204901	ECU HARDWARE BS6	TATA spare parts
553016204902	HARDWARE CONTROL MODULEBS6	TATA spare parts
553016262001	INST CLUSTER INTERFACE HARDWARE BS6-PH2	TATA spare parts
553016262003	INSTRUMENT CL INTERFACE HARDWARE BS6-PH2	TATA spare parts
553024200101	BRACKET ASSY ENGINE MTG BOTTOM LH	TATA spare parts
553024200102	BRACKET ASSY ENGINE MTG BOTTOM RH	TATA spare parts
553026800101	ASSY SHIFTER UNIT	TATA spare parts
553026800102	SELECTION CABLE ASSY	TATA spare parts
553026800103	ASSY. GEAR SHIFT CABLE BS3/4/6	TATA spare parts
553026820101	BRACKET ASSY CABLE ANCHORING	TATA spare parts
553026820103	ASSY SHIFT ANCHORING BRACKET	TATA spare parts
553026820106	ANCHOR BRACKET ASSY SHIFT CABLE BS6-PH2	TATA spare parts
553029100101	BUNDY TUBE ASSY LONG MEMBER MIDDLE	TATA spare parts
553029100103	BUNDY TUBE ASSY MIDDLE	TATA spare parts
553029100201	CLUTCH PEDAL ASSY WITH PEDAL BOX BS6-PH2	TATA spare parts
553029300101	BUNDY TUBE ASSY CMC TO LONG MEMBER	TATA spare parts
553029300102	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
553029300104	ASSY. CLUTCH BOOSTER BS4/6	TATA spare parts
553029300106	KIT-SPARE PART ASSY BS6	TATA spare parts
553029300125	NYLON PIPE ASSY BS6-PH2	TATA spare parts
553029303304	BRACKET FOR CLUTCH HOSE SUPORT	TATA spare parts
553029500101	BRACKET ASSY CLUTCH CONTROL MTG BS6-PH2	TATA spare parts
553029500102	CLUTCH PEDAL ASSY WITH PEDAL BOX	TATA spare parts
553031000104	FRAME ASSY WITH TOP COAT	TATA spare parts
553031000105	FRAME ASSY WITH TOP COAT	TATA spare parts
553031000106	ASSY. FRAME ULTRA 1518 TOP COAT BS3/4	TATA spare parts
553031000108	FRAME ASSY WITH TOP COAT	TATA spare parts
553031000111	FRAME ASSY WITH TOP COAT	TATA spare parts

553031000114	FRAME ASSY WITH TOP COAT	TATA spare parts
553031000115	ASSY FRAME 15.7T-4530WB-5L E WITH TOP CO	TATA spare parts
553031000122	FRAME ASSY WITH TOP COAT	TATA spare parts
553031000127	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
553031000129	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
553031000137	FRAME ASSY	TATA spare parts
553031000143	FRAME ASSY W/O TOP COAT BS6	TATA spare parts
553031000144	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
553031000145	FRAME ASSY BS6	TATA spare parts
553031000146	FRAME ASSY BS6	TATA spare parts
553031000147	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
553031000150	FRAME ASSY WITH TOP COAT	TATA spare parts
553031000152	FRAME ASSY WITH TOP COAT	TATA spare parts
553031000165	FRAME ASSY WITH TOP COAT	TATA spare parts
553031000201	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
553031000203	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
553031103501	SLEEVE BS6	TATA spare parts
553031107123	LONG MEMBER RH BS6	TATA spare parts
553031107124	LONG MEMBER LH BS6	TATA spare parts
553031107125	LONG MEMBER RH BS6	TATA spare parts
553031107126	LONG MEMBER LH BS6	TATA spare parts
553031107127	LONG MEMBER RH BS6	TATA spare parts
553031107128	LONG MEMBER LH BS6	TATA spare parts
553031107137	LONG MEMBER RH BS6	TATA spare parts
553031107138	LONG MEMBER LH BS6	TATA spare parts
553031107143	LONG MEMBER RH BS6	TATA spare parts
553031107144	LONG MEMBER LH BS6	TATA spare parts
553031200101	CROSS MEMBER ASSY	TATA spare parts
553031200102	END CROSS MEMBER ASSY	TATA spare parts
553031200103	CROSS MEMBER ASSY ENGINE MTG FRONT	TATA spare parts
553031200113	CROSS MEMBER ASSY CAB MTG	TATA spare parts
553031200115	BRACKET ASSY CAB MTG RH	TATA spare parts
553031200116	BRACKET ASSY CAB MTG LH	TATA spare parts
553031200122	CROSS MEMBER ASSY BS6	TATA spare parts
553031207105	CROSS MEMBER ENGINE MTG FRONT BS6-PH2	TATA spare parts
553031208201	END CROSS MEMBER	TATA spare parts
553031208207	END CROSS MEMBER	TATA spare parts
553031240101	BRACKET ASSY ENGINE MTG FRONT-LH ENGINE	TATA spare parts
553031240102	BRACKET ASSY ENGINE MTG FRONT-RH BS6	TATA spare parts
553031300101	REINFORCEMENT ASSY	TATA spare parts
553031400102	CROSS MEMBER ASSY	TATA spare parts
553031400103	CROSS MEMBER ASSY	TATA spare parts
553031400106	CROSS MEMBER ASSY	TATA spare parts
553031400107	CROSS MEMBER ASSY	TATA spare parts
553031400109	BRACKET ASSY ECU MTG BS6	TATA spare parts
553031400111	CROSS MEMBER ASSY BS6	TATA spare parts
553031400113	CROSS MEMBER ASSY - BS6	TATA spare parts

553031400116	CROSS MEMBER ASSY	TATA spare parts
553031407133	REINFORCEMENT CROSS MEMBER RH BS6	TATA spare parts
553031407134	REINFORCEMENT CROSS MEMBER LH BS6	TATA spare parts
553031408205	REINFORCEMENT STEERING GEAR BOX MTG RH B	TATA spare parts
553031408206	REINFORCEMENT STEERING GEAR BOX MTG LH B	TATA spare parts
553031408217	BRACKET ECU MTG-5L	TATA spare parts
553031503701	TOW HOOK FRONT	TATA spare parts
553031540102	BRACKET ASSY BATTERY MTG LH	TATA spare parts
553031540103	BRACKET ASSY BATTERY MTG RH	TATA spare parts
553031540104	BRACKET ASSY BOTTOM SIDE SUPPORT	TATA spare parts
553031540105	BRACKET ASSY BATTERY CLAMP SUPPORT	TATA spare parts
553031540106	BRACKET ASSY BATTERY CLAMP	TATA spare parts
553031540112	BATTERY CARRIER & AIR TANK MTG ASSY	TATA spare parts
553031548801	STUD	TATA spare parts
553031700102	ASSY.CHANNEL RUPD	TATA spare parts
553031700104	ASSY.BRACKET COMPLETE (RUPD)	TATA spare parts
553031700105	ASSY BRACKET LH RUPD	TATA spare parts
553031700114	BEAM ASSY FUPD	TATA spare parts
553031700127	BATTERY CARRIER AND AIR TANK MTG ASSY	TATA spare parts
553031700133	BRACKET ASSY FUPD MTG LH	TATA spare parts
553031700134	BRACKET ASSY FUPD MTG RH	TATA spare parts
553031700138	BRACKET ASSY RUPD MTG LH BS6	TATA spare parts
553031700139	BRACKET ASSY RUPD MTG RH BS6	TATA spare parts
553031700146	BRACKET ASSY FUPD MTG LH BS6	TATA spare parts
553031700147	BRACKET ASSY FUPD MTG RH - BS6	TATA spare parts
553031700158	BRACKET ASSY RUPD MTG RH	TATA spare parts
553031700159	BRACKET ASSY RUPD MTG LH	TATA spare parts
553032100104	FRONT SPRING ASSY	TATA spare parts
553032100105	1ST LEAF ASSY WITH BUSH	TATA spare parts
553032100106	RUBBER BUSH ASSY	TATA spare parts
553032100114	LEAF SPRING ASSY FRONT BS6	TATA spare parts
553032100115	1ST LEAF ASSY BS6	TATA spare parts
553032100117	FRONT SPRING ASSY BS6	TATA spare parts
553032103201	CENTER BOLT	TATA spare parts
553032103202	CLAMP BOLT	TATA spare parts
553032103206	CLAMP BOLT BS6	TATA spare parts
553032104203	CLAMP LEAF SPRING	TATA spare parts
553032104205	SPRING CLIP BS6	TATA spare parts
553032106501	CENTRE BOLT NUT	TATA spare parts
553032106502	HEX NUT	TATA spare parts
553032106503	CENTER BOLT NUT BS6	TATA spare parts
553032107106	2ND LEAF	TATA spare parts
553032107107	3RD LEAF	TATA spare parts
553032107108	4TH LEAF	TATA spare parts
553032107109	CASTER PLATE	TATA spare parts
553032107124	3RD LEAF BS6	TATA spare parts
553032107126	PACKING PLATE BS6	TATA spare parts

553032107127	2ND LEAF BS6	TATA spare parts
553032108301	SHIM	TATA spare parts
553032108302	CENTER PAD	TATA spare parts
553032108304	CENTER PAD BS6	TATA spare parts
553032200101	BUMP STOPPER ASSY	TATA spare parts
553032204201	U-BOLT	TATA spare parts
553032204202	U-BOLT	TATA spare parts
553032204204	U-BOLT	TATA spare parts
553032400103	REAR SPRING ASSY	TATA spare parts
553032400104	1ST LEAF ASSY WITH BUSH	TATA spare parts
553032400105	REAR AXLE STOPPER ASSY	TATA spare parts
553032400107	LEAF SPRING ASSY WITH AUX SPRING REAR BS	TATA spare parts
553032400111	LEAF SPRING ASSY WITH AUX SPRING REAR	TATA spare parts
553032400118	1ST LEAF ASSY WITH BUSH	TATA spare parts
553032400119	REAR SPRING ASSY	TATA spare parts
553032403202	CLAMP BOLT	TATA spare parts
553032403203	CENTRE BOLT	TATA spare parts
553032403204	CLAMP BOLT	TATA spare parts
553032404201	CLAMP	TATA spare parts
553032404202	CLAMP	TATA spare parts
553032404204	CLAMP	TATA spare parts
553032404209	SPRING CLIP REAR	TATA spare parts
553032404214	SPRING CLIP	TATA spare parts
553032404215	CLIP	TATA spare parts
553032405101	LOWER SADDLE REAR BS6	TATA spare parts
553032406501	CENTRE BOLT NUT	TATA spare parts
553032406503	NUT BS6	TATA spare parts
553032406701	SPRING PIN SPRING MTG	TATA spare parts
553032406901	PIPE	TATA spare parts
553032406903	SPACER	TATA spare parts
553032407129	2ND LEAF	TATA spare parts
553032407130	3RD LEAF	TATA spare parts
553032407131	4TH LEAF	TATA spare parts
553032407132	5TH LEAF	TATA spare parts
553032407133	6TH LEAF	TATA spare parts
553032407134	7TH LEAF	TATA spare parts
553032407135	8TH LEAF	TATA spare parts
553032407136	9TH LEAF	TATA spare parts
553032407137	1ST LEAF AUX SPRING	TATA spare parts
553032407138	2ND LEAF AUX SPRING	TATA spare parts
553032407139	3RD LEAF AUX SPRING	TATA spare parts
553032407188	3RD LEAF AUX SPRING	TATA spare parts
553032407189	2ND LEAF AUX SPRING	TATA spare parts
553032407190	6TH LEAF AUX SPRING	TATA spare parts
553032407191	6TH LEAF MAIN SPRING	TATA spare parts
553032407192	4TH LEAF AUX SPRING	TATA spare parts
553032407193	7TH LEAF AUX SPRING	TATA spare parts

553032407194	3RD LEAF MAIN SPRING	TATA spare parts
553032407195	4TH LEAF MAIN SPRING	TATA spare parts
553032407196	1ST LEAF MAIN SPRING BS6	TATA spare parts
553032407197	2ND LEAF MAIN SPRING	TATA spare parts
553032407198	7TH LEAF MAIN SPRING	TATA spare parts
553032407199	5TH LEAF MAIN SPRING	TATA spare parts
553032408301	CENTER PAD	TATA spare parts
553032417101	1ST LEAF AUX SPRING	TATA spare parts
553032417102	9TH LEAF MAIN SPRING	TATA spare parts
553032417103	5TH LEAF AUX SPRING	TATA spare parts
553032417104	8TH LEAF MAIN SPRING	TATA spare parts
553032503701	BRACKET GUIDE PLATE	TATA spare parts
553032800101	ANTI ROLL BAR ASSY FRONT	TATA spare parts
553032800102	CONNECTING LINK ASSY	TATA spare parts
553032800106	ANTI ROLL BAR ASSY FRONT BS6	TATA spare parts
553032803301	BRACKET ANTI ROLL BAR ASSY MTG	TATA spare parts
553032803304	BRACKET ASSY ANTI ROLL BAR MTG UPPER BS6	TATA spare parts
553032806002	CONNECTING LINK	TATA spare parts
553033000104	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
553033000107	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
553033000111	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
553033000114	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
553033105105	FRONT AXLE BEAM-NORMAL	TATA spare parts
553033105110	FRONT AXLE BEAM BS6-PH2	TATA spare parts
553033200105	STUB AXLE ASSY ABS RH	TATA spare parts
553033200106	STUB AXLE ASSY ABS LH	TATA spare parts
553033800101	TIE ROD ASSY BS6	TATA spare parts
553033800102	TIE ROD ASSY	TATA spare parts
553033800103	TIE ROD ASSY	TATA spare parts
553033800107	TIE ROD ASSY BS6-PH2	TATA spare parts
553033805101	TIE ROD ARM RH	TATA spare parts
553033805102	TIE ROD ARM LH	TATA spare parts
553033805104	STEERING ARM	TATA spare parts
553033805105	STEERING ARM BS6-PH2	TATA spare parts
553033805106	STEERING ARM BS6-PH2	TATA spare parts
553040100104	ASSY. WHEEL RIM BS3/4/6	TATA spare parts
553040100108	WHEEL RIM ASSY BS6	TATA spare parts
553040100115	ASSY. WHEEL RIM BS4	TATA spare parts
553040109913	TUBELESS TYRE 275/80R22.5 TL	TATA spare parts
553040209903	TUBELESS TYRE 275/80R22.5 TL	TATA spare parts
553040300101	SPARE WHEEL CARRIER ASSY	TATA spare parts
553041110114	PROPELLER SHAFT ASSY FRONT	TATA spare parts
553041110115	PROPELLER SHAFT ASSY FRONT	TATA spare parts
553041110116	CROSS ASSY	TATA spare parts
553041110119	PROPELLER SHAFT ASSY FRONT	TATA spare parts
553041115101	COMPANION FLANGE	TATA spare parts
553041115102	FLANGE YOKE	TATA spare parts

553041120114	PROPELLER SHAFT ASSY REAR	TATA spare parts
553041120115	PROPELELR SHAFT ASSY DRIVE	TATA spare parts
553041120116	PROPELLER SHAFT ASSY REAR	TATA spare parts
553041120117	PROPELLER SHAFT ASSY REAR	TATA spare parts
553041120118	CROSS ASSY	TATA spare parts
553041120119	SLIP YOKE ASSY	TATA spare parts
553041120122	PROPELLER SHAFT ASSY REAR	TATA spare parts
553041120123	PROPELLER SHAFT ASSY DRIVE	TATA spare parts
553041120124	PROPELLER SHAFT ASSY REAR BS6	TATA spare parts
553041120125	PROPELLER SHAFT ASSY REAR BS6	TATA spare parts
553041120127	REAR DRIVE SHAFT	TATA spare parts
553041120128	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
553041120129	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
553041120130	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
553041120132	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
553041300102	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
553041300105	BRACKET ASSY CENTER BRG MTG	TATA spare parts
553041307101	BRACKET CENTER BRG MTG	TATA spare parts
553042100104	AUTO SLACK ADJUSTER LH	TATA spare parts
553042100105	AUTO SLACK ADJUSTER RH	TATA spare parts
553042100106	DRUM BRAKE ASSY WITH D/C FRONT LH	TATA spare parts
553042100107	DRUM BRAKE ASSY WITH D/C FRONT RH	TATA spare parts
553042100110	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
553042100111	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
553042100112	DRUM BRAKE ASSY WITH DC FRONT-LH	TATA spare parts
553042100113	DRUM BRAKE ASSY WITH DC FRONT-RH	TATA spare parts
553042100114	MINOR O/H KIT FRONT	TATA spare parts
553042100115	LINED SHOE KIT FRONT	TATA spare parts
553042100125	LINED SHOE ASSY	TATA spare parts
553042100149	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
553042100150	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
553042100151	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
553042100152	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
553042100153	DRUM BRAKE ASSY WITH DC FRONT-LH BS6	TATA spare parts
553042100154	DRUM BRAKE ASSY WITH DC FRONT-RH BS6	TATA spare parts
553042106317	KIT-BRAKE LINER O/S 1 ( 325 X 155) BS6	TATA spare parts
553042106318	KIT-BRAKE LINER O/S 2 ( 325 X 155) BS6	TATA spare parts
553042106322	KIT-BRAKE LINER SET (325 X 140) STD BS6	TATA spare parts
553042106323	KIT-BRAKE LINER O/S 1 (325 X 140) BS6	TATA spare parts
553042106324	KIT-BRAKE LINER O/S 2 (325 X 140) BS6	TATA spare parts
553042300117	DRUM BRAKE ASSY 6262 WITH D/C LH	TATA spare parts
553042300118	DRUM BRAKE ASSY 6262 WITH D/C RH	TATA spare parts
553042300119	DRUM BRAKE ASSY 6262 WITH D/C LH	TATA spare parts
553042300120	DRUM BRAKE ASSY 6262 WITH D/C RH	TATA spare parts
553042300126	BRAKE SHOE & LINER KIT-FRONT	TATA spare parts
553042300127	BRK LINING KIT(STD)410X180AF 6262N BS3-6	TATA spare parts
553042300137	DRUM BRAKE ASSY WITH DC REAR-LH BS6	TATA spare parts

553042300138	DRUM BRAKE ASSY WITH DC REAR-RH BS6	TATA spare parts
553042300152	DRUM BRAKE ASSY WITH DC REAR FWD-LH (AAL	TATA spare parts
553042300153	DRUM BRAKE ASSY WITH DC REAR FWD-RH (AAL	TATA spare parts
553042300154	DRUM BRAKE ASSY WITH DC REAR FWD-LH (AAL	TATA spare parts
553042300155	DRUM BRAKE ASSY WITH DC REAR FWD-RH (AAL	TATA spare parts
553042306313	KIT-BRAKE LINER SET STD (325 X 155) BS6	TATA spare parts
553042306315	KIT-BRAKE LINER O/S 1 (325 X 155) BS6	TATA spare parts
553042306316	KIT-BRAKE LINER O/S 2 (325 X 155) BS6	TATA spare parts
553042306317	KIT-BRAKE LINER SET STD (325 X 120) BS6	TATA spare parts
553042306318	KIT-BRAKE LINER O/S 1 (325 X 120) BS6	TATA spare parts
553042306319	KIT-BRAKE LINER O/S 2 (325 X 120) BS6	TATA spare parts
553042990111	KIT-BRAKE SHOE ASSY FRONT BS6	TATA spare parts
553042990117	KIT-BRACKET ASSY LH	TATA spare parts
553042990118	KIT-BRACKET ASSY RH	TATA spare parts
553042990119	KIT-BRAKE	TATA spare parts
553042990123	KIT-BRAKE	TATA spare parts
553042990126	KIT-BUSH	TATA spare parts
553042990128	KIT CAMSHAFT LH ( BIL)	TATA spare parts
553042990129	KIT CAMSHAFT RH ( BIL)	TATA spare parts
553042990130	KIT TORQUE PLATE LH	TATA spare parts
553042990131	KIT TORQUE PLATE RH	TATA spare parts
553042990138	KIT BRACKET ASSY LH ( BIL)	TATA spare parts
553042990139	KIT BRACKET ASSY RH ( BIL)	TATA spare parts
553042990142	KIT-CAMSHAFT LH	TATA spare parts
553042990143	KIT-CAMSHAFT RH	TATA spare parts
553042990145	TORQUE PLATE	TATA spare parts
553042990146	TORQUE¿PLATE	TATA spare parts
553042990148	KIT-BRAKE SHOE ASSY FRONT BS6	TATA spare parts
553042990151	KIT-BRAKE SHOE ASSY FRONT BS6	TATA spare parts
553042990158	BRAKE LINING KIT(STD)325X155 NA1707 BS6	TATA spare parts
553042990159	BRAKE LINING KIT(OS1)325X155 NA1707 BS6	TATA spare parts
553042990160	BRAKE LINING KIT(OS2)325X155 NA1707 BS6	TATA spare parts
553042990167	BRAKE LINING KIT(STD)325X140 AF TL70 BS6	TATA spare parts
553042990168	BRAKE LINING KIT(OS1)325X140 AF TL70 BS6	TATA spare parts
553042990169	BRAKE LINING KIT(OS2)325X140 AF TL70 BS6	TATA spare parts
553042990170	BRAKE KIT(STD)325X155 AF TL70 BS6	TATA spare parts
553042990171	BRAKE LINING KIT(OS1)325X155 AF TL70 BS6	TATA spare parts
553042990172	BRAKE LINING KIT(OS2)325X155 AF TL70 BS6	TATA spare parts
553042990182	KIT- BRAKE TORQUE PLATE ASSY BS6	TATA spare parts
553042990183	KIT-CAMSHAFT LH BS6-PH2	TATA spare parts
553042990184	KIT-CAMSHAFT RH BS6-PH2	TATA spare parts
553042990187	DUST SHIELD TOP BS6	TATA spare parts
553042990188	DUST SHIELD BOTTOM BS6	TATA spare parts
553042990189	KIT-DUST SHIELD ASSY BS6	TATA spare parts
553042990206	KIT-BRAKE LINER SET STD (325 X 155) BS6	TATA spare parts
553042990207	KIT-BRAKE LINER O/S 1 (325 X 155) BS6	TATA spare parts
553042990208	KIT-BRAKE LINER O/S 2 (325 X 155) BS6	TATA spare parts



553042990209	BRAKE LINING KIT(STD)325X120 AF TL70 BS6	TATA spare parts
553042990210	BRAKE LINING KIT(OS1)325X120 AF TL70 BS6	TATA spare parts
553042990211	BRAKE LINING KIT(OS2)325X120 AFTL70 BS6	TATA spare parts
553042990212	KIT-BUSH BS6	TATA spare parts
553042990237	KIT-SPRING LH BS6	TATA spare parts
553042990239	KIT-BRAKE SHOE & LINER 410X180 TVSAF3838	TATA spare parts
553042990243	KIT-CAMSHAFT BS6	TATA spare parts
553042990247	KIT- ROLLER BS6	TATA spare parts
553042990248	KIT- CAMSHAFT WASER W/ SPACER BS6	TATA spare parts
553042990255	MINOR SERVICE KIT BS6	TATA spare parts
553043200101	AIR TANK ASSEMBLY LH-30L	TATA spare parts
553043200102	AIR TANK ASSEMBLY RH-30L	TATA spare parts
553043200103	BRACKET ASSY - RH (30LIT AIR TANK MTG) B	TATA spare parts
553043200104	BRACKET ASSY - LH (30LIT AIR TANK MTG) B	TATA spare parts
553043400102	EXHAUST BRAKE ASSY W/O AIR CYLINDER	TATA spare parts
553043700101	AIR PROCESSING AND DISTRIBUTION UNIT	TATA spare parts
553043700199	ANTI ROLL BACK ASSY BS6-PH2	TATA spare parts
553043703302	MODULATOR VALVE MTG BRKT - FRONT	TATA spare parts
553043800105	TUBE ASSY WITH CRIMPED HOSE	TATA spare parts
553043800106	PIPE ASSY HOSE TO ADAPTOR	TATA spare parts
553043800108	PIPE ASSY ADAPTOR TO APDA	TATA spare parts
553043800111	METAL PIPE ASSY ADAPTER TO APU	TATA spare parts
553043800113	METAL PIPE ASSY HOSE TO ADAPTER	TATA spare parts
553043800114	METAL PIPE ASSY ADAPTER TO APU	TATA spare parts
553043803301	BRACKET FOR PIPE ON CAB FLOOR	TATA spare parts
553043900103	PIPE ASSY (NYLON BUNCH - CAB)	TATA spare parts
553043900163	HOSE ASSY BRAKE FRONT	TATA spare parts
553043900172	PIPE BUNCH ASSY CHASSIS	TATA spare parts
553043900175	PIPE BUNCH ASSY CHASSIS	TATA spare parts
553043900176	PIPE ASSY (NYLON BUNCH - CHASSIS) 53 AB	TATA spare parts
553043900181	NYLON PIPE BUNCH ASSY CHASSIS	TATA spare parts
553043900184	METAL PIPE ASSY ADAPTER TO APU	TATA spare parts
553043900189	METAL PIPE ASSY HOSE TO ADAPTER	TATA spare parts
553043903303	BRACKET T-CONN MTG	TATA spare parts
553043907501	RUBBER GROMMET (ON L/M)	TATA spare parts
553043910103	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
553043910126	PIPE BUNCH ASSY CABIN	TATA spare parts
553043910155	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
553043910160	PIPE BUNCH ASSY CABIN BS6	TATA spare parts
553043910177	PIPE BUNCH ASSY CABIN BS6	TATA spare parts
553043910184	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
553043920112	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
553043920114	PIPE BUNCH ASSY CABIN	TATA spare parts
553043920115	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
553043920142	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
553043920148	PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
553043920175	PIPE BUNCH ASSY CABIN	TATA spare parts

553043920189	PIPE BUNCH ASSY CHASSIS	TATA spare parts
553043920191	METAL PIPE ASSY ADAPTER TO APU	TATA spare parts
553043920198	PIPE BUNCH ASSY CHASSIS	TATA spare parts
553043930102	PIPE BUNCH ASSY CHASSIS	TATA spare parts
553043930123	NYLON PIPE ASSY CHASSIS	TATA spare parts
553043930138	PIPE BUNCH ASSY CHASSIS	TATA spare parts
553043940162	PIPE BUNCH ASSY CABIN BS6-PH2	TATA spare parts
553046100104	STEERING COLUMN ASSY	TATA spare parts
553046100105	RUBBER BELLOW ASSY	TATA spare parts
553046100106	COLUMN ASSY UPPER	TATA spare parts
553046100107	SPLINE SHAFT ASSY	TATA spare parts
553046108001	HEX FLANGE SCREW	TATA spare parts
553046108002	HEX FLANGE BOLT BS6	TATA spare parts
553046301601	PITMAN ARM	TATA spare parts
553046305101	PITMAN ARM	TATA spare parts
553046305103	PITMAN ARM BS6-PH2	TATA spare parts
553046600104	PISTON ASSY	TATA spare parts
553046600105	HOUSING ASSY	TATA spare parts
553046600106	STEERING GEAR BOX ASSY	TATA spare parts
553046600109	DRAG LINK ASSY	TATA spare parts
553046600112	ASSY. STEERING GEAR BOX BS3/4	TATA spare parts
553046600113	HOUSING ASSY VALVE	TATA spare parts
553046600114	SECTOR SHAFT ASSY	TATA spare parts
553046600115	SECTOR SHAFT ASSY	TATA spare parts
553046600116	MAJOR KIT-SEAL	TATA spare parts
553046600117	MAJOR KIT-SEAL	TATA spare parts
553046600118	MAJOR KIT-SEAL	TATA spare parts
553046600119	MAJOR KIT-SEAL	TATA spare parts
553046600120	WORM & RACK ASSY	TATA spare parts
553046600124	WORM & RACK ASSY	TATA spare parts
553046600125	KIT-SEAL	TATA spare parts
553046600126	HOUSING ASSY	TATA spare parts
553046600127	STEERING GEAR BOX ASSY	TATA spare parts
553046603701	HOUSING	TATA spare parts
553046607801	CAP SEAL	TATA spare parts
553046607802	O-RING	TATA spare parts
553046608001	SCREW	TATA spare parts
553046609201	WASHER	TATA spare parts
553046609901	CAP	TATA spare parts
553046703301	BRACKET OIL RESERVOIR MTG	TATA spare parts
553046703701	BRACKET STG GEAR BOX MTG	TATA spare parts
553046703703	BRACKET STG GEAR BOX MTG	TATA spare parts
553046800108	SUCTION LINE ASSY	TATA spare parts
553046800111	RETURN LINE ASSY	TATA spare parts
553046800112	HIGH PRESSURE LINE ASSY	TATA spare parts
553046800115	HIGH PRESSURE LINE ASSY	TATA spare parts
553046800116	RETURN LINE ASSY	TATA spare parts

553046800117	SUCTION LINE ASSY	TATA spare parts
553046900105	DRAG LINK ASSY BS6-PH2	TATA spare parts
553047100101	FUEL TANK ASSY	TATA spare parts
553047100106	FUEL TANK ASSY	TATA spare parts
553047500102	FUEL TANK MTG ASSY WITH RUBBER PACKG.	TATA spare parts
553047600103	SUCTION FUEL PIPE ASSY	TATA spare parts
553047600104	RETURN FUEL PIPE ASSY	TATA spare parts
553047600108	SUCTION FUEL PIPE ASSY	TATA spare parts
553047600109	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553047600110	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553047600111	RETURN FUEL PIPE ASSY BS6	TATA spare parts
553047600118	SUCTION FUEL PIPE ASSY TANK TO ENGINE	TATA spare parts
553047600119	SUCTION FUEL PIPE ASSY PREFIL TO MAINFIL	TATA spare parts
553047600120	SUCTION FUEL PIPE ASSY MAINFILTER TO FIP	TATA spare parts
553047600121	RETURN FUEL PIPE ASSY ENGINE TO TANK	TATA spare parts
553047600123	BRACKET ASSY	TATA spare parts
553047600132	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553047600133	RETURN FUEL PIPE ASSY BS6	TATA spare parts
553047600134	SUCTION FUEL PIPE ASSY	TATA spare parts
553047600135	SUCTION FUEL PIPE ASSY	TATA spare parts
553047600136	RETURN FUEL PIPE ASSY	TATA spare parts
553047600137	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553047600138	RETURN FUEL PIPE ASSY BS6	TATA spare parts
553047600139	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553047600142	SUCTION PIPE ASSY TANK SIDE BS6	TATA spare parts
553047600145	FUEL RETURN PIPE ASSY ENG TO FUEL TANK B	TATA spare parts
553047600146	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553047600147	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553047600148	RETURN FUEL PIPE ASSY BS6	TATA spare parts
553047600150	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553047600151	RETURN FUEL PIPE ASSY BS6	TATA spare parts
553047600152	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553047600153	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553047600154	RETURN FUEL PIPE ASSY BS6	TATA spare parts
553047600183	RETURN FUEL PIPE ASSY BS6-PH2	TATA spare parts
553047600184	RETURN FUEL PIPE ASSY BS6-PH2	TATA spare parts
553047600189	SUCTION FUEL PIPE ASSY BS6-PH2	TATA spare parts
553047600190	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
553047600191	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
553047603301	BRACKET FOR FUELLINE CLAMPING	TATA spare parts
553047603303	BRACKET FOR FUELLINE CLAMPING	TATA spare parts
553047603308	BRACKET	TATA spare parts
553047704901	TANK UNIT WITH THICK FILM RESISTANCE	TATA spare parts
553049100101	SILENCER ASSY WITH TAIL PIPE	TATA spare parts
553049100104	CLAMP ASSY EGP MTG BS6	TATA spare parts
553049100107	RUBBER BUFFER ASSY BS6	TATA spare parts
553049103304	BRACKET SILENCER MTG BS6	TATA spare parts

553049104201	CLAMP EGP MTG BS6	TATA spare parts
553049200101	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
553049200104	NOISE SHIELD ASSY FRONT-RH	TATA spare parts
553049200105	NOISE SHIELD ASSY REAR-RH	TATA spare parts
553049200107	BRACKET ASSY NOISE SHIELD MTG	TATA spare parts
553049200108	BRACKET ASSY NOISE SHIELD MTG	TATA spare parts
553049200109	NOISE SHIELD ASSY FRONT-BOTTOM	TATA spare parts
553049200110	NOISE SHIELD BRACKET 5	TATA spare parts
553049200111	NOISE SHIELD BRACKET 6	TATA spare parts
553049200114	BRACKET ASSY	TATA spare parts
553049200115	SILENCER MTG BKT FRT	TATA spare parts
553049200117	EXHAUST PIPE WITH FLEX JOINT FRONT BS6	TATA spare parts
553049200118	BRACKET ASSY EGP MTG BS6	TATA spare parts
553049200119	BRACKET ASSY BS6	TATA spare parts
553049200127	BRACKET ASSY UREA TANK MTG BS6	TATA spare parts
553049200128	BRACKET ASSY DEF TANK MTG LH BS6	TATA spare parts
553049200129	BRACKET ASSY DEF TANK MTG RH BS6	TATA spare parts
553049200130	UREA TANK ASSY BS6	TATA spare parts
553049200131	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
553049200133	UREA PIPE ASSY BS6	TATA spare parts
553049200134	UREA PIPE ASSY BS6	TATA spare parts
553049200135	PIPE ASSY UREA RETURN BS6	TATA spare parts
553049200138	BRACKET ASSY FRONT PIPE MTG - BS6	TATA spare parts
553049200141	UREA PIPE ASSY SUCTION LINE BS6	TATA spare parts
553049200142	UREA PIPE ASSY SUCTION LINE BS6	TATA spare parts
553049200148	BRACKET ASSY UREA TANK MTG RH BS6-PH2	TATA spare parts
553049200149	BRACKET ASSY UREA TANK MTG LH BS6-PH2	TATA spare parts
553049200150	BRACKET ASSY UREA TANK MTG BS6-PH2	TATA spare parts
553049200152	STRAP ASSY UREA TANK MTG BS6-PH2	TATA spare parts
553049200161	STRAP ASSY UREA TANK MTG BS6-PH2	TATA spare parts
553049200168	BRACKET ASSY UREA TANK MTG BS6-PH2	TATA spare parts
553049200182	UREA PIPE ASSY BS6-PH2	TATA spare parts
553049200183	EXHAUST PIPE ASSY WITH FLEX JOINT FRONT	TATA spare parts
553049203305	BRACKET BS6	TATA spare parts
553049203306	BRACKET UREA LINE SUPPORT BS6	TATA spare parts
553049203312	L-BRACKET EXHAUST PIPE MTG - BS6	TATA spare parts
553049203318	SUPPORT EXHAUST PIPE MTG - BS6	TATA spare parts
553049203322	CLAMP EXHAUST PIPE ASSY (FOR FRONT CLAMP	TATA spare parts
553049205301	GASKET BS6	TATA spare parts
553049206908	TUBE BS6	TATA spare parts
553049600110	HEAT SHIELD ASSY (SANKAR SEALING) BS6	TATA spare parts
553049999902	STICKER-CAUTION BS6-PH2	TATA spare parts
553054100105	COVER BATTERY BS6	TATA spare parts
553054106302	COVER BATTERY	TATA spare parts
553054200107	INSTRUMENT CLUSTER ASSY BS6	TATA spare parts
553054200108	INSTRUMENT CLUSTER ASSY BS6	TATA spare parts
553054200109	INSTRUMENT CL INTERFACE HARDWARE BS6-PH2	TATA spare parts

553054400105	ROOF LAMP ASSY	TATA spare parts
553054500109	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
553054500111	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
553054541605	SWITCH ENGINE LAMP BS6	TATA spare parts
553054541608	SWITCH EXHAUST BRAKE 24V BS6	TATA spare parts
553054541611	SWITCH ABS DIAGNOSTICS BS6	TATA spare parts
553054541628	SWITCH HEADLAMP LEVELLING BS6	TATA spare parts
553054544903	SWITCH HEAVY MODE BS6	TATA spare parts
553054544904	SWITCH REGENERATION INHIBIT 24V BS6	TATA spare parts
553054544905	SWITCH LIGHT MODE BS6	TATA spare parts
553054544906	SWITCH REGENERATION START MANUAL 24V BS	TATA spare parts
553054544907	SWITCH ABS DIAGNOSTICS BS6	TATA spare parts
553054544908	SWITCH ENGINE LAMP;BS6	TATA spare parts
553054544909	SWITCH EXHAUST BRAKE BS6	TATA spare parts
553054544910	ROTARY SWITCH HEADLAMP BS6	TATA spare parts
553054544912	SWITCH HEADLAMP LEVELLING BS6	TATA spare parts
553054544913	SWITCH HILL ASSIST BS6	TATA spare parts
553054549916	REMOTE CUT OFF SWITCH BATTERY BS6	TATA spare parts
553054600103	BRACKET ASSY EMS ECU MTG	TATA spare parts
553054600107	ROOF WIRING HARNESS	TATA spare parts
553054600108	FLOOR WIRING HARNESS	TATA spare parts
553054600112	ENGINE WIRING HARNESS	TATA spare parts
553054600129	WIRING HARNESS REAR CHASSIS	TATA spare parts
553054600138	WIRING HARNESS ENGINE BS3/4	TATA spare parts
553054600142	WIRING HARNESS INSTRUMENT PANEL BS3/4	TATA spare parts
553054600143	WIRING HARNESS ABS FRAME	TATA spare parts
553054600145	WIRING HARNESS REAR CHASSIS	TATA spare parts
553054600146	WIRING HARNESS REAR CHASSIS	TATA spare parts
553054600150	WIRING HARNESS ABS FRAME	TATA spare parts
553054600151	WIRING HARNESS ABS FRAME	TATA spare parts
553054600155	WIRINGHARNESSFRONTCHASSIS	TATA spare parts
553054600160	WIRING HARNESS LOAD BODY	TATA spare parts
553054600162	WIRING HARNESS FLOOR	TATA spare parts
553054600172	BOX ASSY INLINE CONNECTOR	TATA spare parts
553054600186	WIRING HARNESS FRONT CHASSIS	TATA spare parts
553054600187	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
553054600188	BATTERY CABLE -VE	TATA spare parts
553054600189	WIRING HARNESS ENGINE	TATA spare parts
553054600191	STARTER CABLE	TATA spare parts
553054600193	BRACKET ASSY FUSE BOX MTG	TATA spare parts
553054600196	WIRING HARNESS ABS FRAME	TATA spare parts
553054601611	WIRING HARNESS GEAR BOX GB750	TATA spare parts
553054601623	W/H FRONT CHASSIS	TATA spare parts
553054601624	WIRING HARNESS REAR CHASSIS	TATA spare parts
553054601625	W/H FIREWALL	TATA spare parts
553054601626	WIRING HARNESS ENGINE	TATA spare parts
553054601628	W/H REAR CHASSIS 49WB	TATA spare parts

553054601629	W/H REAR CHASSIS 45WB	TATA spare parts
553054601632	BATTERY CABLE POSITIVE	TATA spare parts
553054601633	STARTER CABLE	TATA spare parts
553054601634	BATTERY CABLE NEGATIVE	TATA spare parts
553054601650	BATTERY CABLE LINK	TATA spare parts
553054603302	BRACKET BS6	TATA spare parts
553054607701	GROMMET	TATA spare parts
553054608201	BATTERY CABLE MOUNTING BRACKET	TATA spare parts
553054609905	STICKER CABIN	TATA spare parts
553054609918	STICKER MAXI FUSE BOX BS6	TATA spare parts
553054610106	REAR CHASSIS WIRING HARNESS - 68WB	TATA spare parts
553054610114	WIRING HARNESS REAR CHASSIS	TATA spare parts
553054610116	WIRING HARNESS ABS FRAME	TATA spare parts
553054610125	WIRING HARNESS REAR CHASSIS	TATA spare parts
553054610129	WIRING HARNESS ABS FRAME	TATA spare parts
553054610130	TERMINAL BATTERY -VE BS6-PH2	TATA spare parts
553054610132	CCB ASSY BS6	TATA spare parts
553054610138	BATTERY CABLE +VE BCS TO MEGA FUSE BS6	TATA spare parts
553054610139	BATTERY CABLE +VE BS6	TATA spare parts
553054610170	WIRING HARNESS ABS FRAME 4S3M BS6	TATA spare parts
553054610172	BATTERY CABLE +VE	TATA spare parts
553054610179	WIRING HARNESS FRONT CHASSIS	TATA spare parts
553054610181	BATTERY CABLE -VE BS6	TATA spare parts
553054610182	WIRING HARNESS ENGINE BS6	TATA spare parts
553054610187	WIRING HARNESS ENGINE BS6	TATA spare parts
553054610188	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
553054610189	WIRING HARNESS FLOOR BS6	TATA spare parts
553054610190	WIRING HARNESS ROOF BS6	TATA spare parts
553054610195	WIRING HARNESS INSTRUMENT PANEL BS6	TATA spare parts
553054610198	BATTERY CABLE +VE	TATA spare parts
553054610203	WIRING HARNESS ROOF BS6-PH2	TATA spare parts
553054610212	WIRING HARNESS FIREWALL BS6-PH2	TATA spare parts
553054620111	WIRING HARNESS LOAD BODY	TATA spare parts
553054620112	WIRING HARNESS LOAD BODY BS6-PH2	TATA spare parts
553054620129	BATTERY CABLE +VE BCS TO MEGA FUSE	TATA spare parts
553054620131	WIRING HARNESS EGP PIGTAIL BS6	TATA spare parts
553054620133	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
553054620141	WIRING HARNESS REAR CHASSIS	TATA spare parts
553054620146	WIRING HARNESS GEAR BOX	TATA spare parts
553054620147	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
553054620148	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
553054620149	STARTER CABLE BS6	TATA spare parts
553054620150	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
553054620152	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
553054620153	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
553054620154	WIRING HARNESS LOAD BODY BS6	TATA spare parts
553054620155	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts

553054620156	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
553054620157	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
553054620162	WIRING HARNESS REVERSE PARK ASSIST BS6	TATA spare parts
553054620166	WIRING HARNESS REVERSE PARK ASSIST BS6	TATA spare parts
553054620183	BATTERY CABLE +VE EBCS TO MEGA FUSE	TATA spare parts
553054620192	WIRING HARNESS ABS FRAME	TATA spare parts
553054620199	PIGTAIL UREA LEVEL SENSOR BS6	TATA spare parts
553054620201	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
553054630110	WIRING HARNESS EGP PIGTAIL BS6	TATA spare parts
553054630115	WIRING HARNESS EMS & ENGINE BS6	TATA spare parts
553054630134	WIRING HARNESS FRONT CHASSIS BS6-PH2	TATA spare parts
553054630137	WIRING HARNESS ABS FRAME BS6-PH2	TATA spare parts
553054700101	INTERFACE UNIT GEARBOX	TATA spare parts
553054700105	BRACKET ASSY CONTROLLER MTG	TATA spare parts
553054700107	BRACKET ASSY VEHICLE TRACKING ASSY MTG B	TATA spare parts
553054800103	BRACKET ASSY SPEAKER MTG LH BS6	TATA spare parts
553054800104	BRACKET ASSY SPEAKER MTG RH BS6	TATA spare parts
553054800118	BRACKET ASSY ABS ECU MTG BS6-PH2	TATA spare parts
553054904901	USB CHARGER BS6	TATA spare parts
553054904902	USB CHARGER BS6	TATA spare parts
553058408201	LABEL TYRE PRESSURE INSTRUCTION	TATA spare parts
553058600101	BRACKET ASSY FIRE EXTINGUISHER MTG BS6	TATA spare parts
553058900101	VALVE SPRING COMPRESSOR	TATA spare parts
553058900601	CAMSHAFT LOCKING PLATE	TATA spare parts
553058900602	DRIFT FOR VALVE GUIDE	TATA spare parts
553058900603	DRIFT FOR STEM SEAL - DRIFT FOR STEM SEA	TATA spare parts
553058900604	SPANNER FOR TAPPET SETTING NUT	TATA spare parts
553058900605	DRIFT FOR CRANKSHAFT REAR OIL SEAL	TATA spare parts
553058900606	DRIFT FOR CRANKSHAFT FRONT OIL SEAL	TATA spare parts
553058900607	RAIL (TO BE USED WITH 282958900605 VALVE	TATA spare parts
553058900608	PULLER FOR CRANKSHAFT OIL SEAL (FRONT AN	TATA spare parts
553058900609	PUSHER FOR CRANKSHAFT OIL SEAL (FRONT AN	TATA spare parts
553058900610	SOCKET FOR INJECTOR SLEEVE	TATA spare parts
553058900617	CRANKSHAFT ROTATION TOOL	TATA spare parts
553058900701	HP LINE NUT SPANNER	TATA spare parts
553058900702	PULLER FOR FIP	TATA spare parts
553058900703	QUILL NUT SPANNER	TATA spare parts
553058900704	ADAPTER FOR COMPRESSION PRESSURE MEASUR	TATA spare parts
553058900705	PULLER FOR FIP GEAR AND COMPRESSOR GEAR	TATA spare parts
553058900706	INJECTOR PULLER	TATA spare parts
553058900707	STUD FIP INSTALLATION	TATA spare parts
553058900708	PULLER FUEL INJECTION PUMP	TATA spare parts
553058901401	SPANNER FOR TURBO CHARGER	TATA spare parts
553058902403	BRACKET ENGINE	TATA spare parts
553058903510	FIXTURE BEARING PRESSING	TATA spare parts
553058903522	HUB LOCK NUT REMOVAL BS6	TATA spare parts
553058904905	TOOL-UREA TANK NECK FILTER BS6	TATA spare parts

553058904906	TOOL-UREA TANK NECK FILTER BS6	TATA spare parts
553058904911	TOOL FUEL TANK CAP BS6	TATA spare parts
553058904912	SPECIAL SOCKET BS6	TATA spare parts
55306000001R40	ASSEMBLY BODY FITTED	TATA spare parts
55306000005R40	ASSEMBLY BODY FITTED	TATA spare parts
55306000008R40	ASSY. CABIN KIT W/O W/H & STRG U1518 BS4	TATA spare parts
55306000013R40	ASSEMBLY BODY FITTED	TATA spare parts
55306000014R40	ASSEMBLY BODY FITTED	TATA spare parts
55306000015R40	ASSEMBLY BODY FITTED	TATA spare parts
55306000015R40AWBL	CAB PARTIALLY FITTED ULTRA 1918 AW BL	TATA spare parts
55306000021R40	PARTIAL FITTED CAB W/O FITMENT ULTRA T.1	TATA spare parts
55306000122R40	PARTIAL FITTED CAB W/O FITMENT ULTRA T.1	TATA spare parts
55306000124R40	ASSY PARTIAL FITTED CAB ULTRA T.16 BS6	TATA spare parts
55306000132R40	PARTIAL FITTED CAB T.18 ULTRA BS6	TATA spare parts
55306100M10132	UNDERBODY ASSY BS6-PH2	TATA spare parts
55306100M10143	UNDERBODY ASSY WITH STUDS BS6-PH2	TATA spare parts
55306300M10111	SIDE WALL ASSY LH BS6-PH2	TATA spare parts
55306300M10112	SIDE WALL ASSY RH BS6-PH2	TATA spare parts
55306360M10149	INNER PANEL ASSY RH BS6-PH2	TATA spare parts
55306420M10130	REINFORCEMENT ASSY C/M BACK PANEL BS6-PH	TATA spare parts
55306470M10112	REAR WALL ASSY BS6-PH2	TATA spare parts
55306570M10116	ROOF ASSY BS6-PH2	TATA spare parts
553070100103	SUPD ASSY LH BS6-PH2	TATA spare parts
553070100104	SUPD ASSY RH BS6-PH2	TATA spare parts
55308840M10138	FRONT PANEL ASSY WITH HINGE BS6-PH2	TATA spare parts
5530D9Y0160001	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
55310025053	BURNING RED	TATA spare parts
55310026014	ANTHRACITE GRAY	TATA spare parts
55313331104	PAINT ACRALKD NEPT BLUE G SPR QD SS7330	TATA spare parts
55313335363	PAINT ACRALKD RUBY RED G SPR QD SS7330	TATA spare parts
55313336025	PAINT ACR ALKD STEELGREY G SPR QD SS7330	TATA spare parts
55313338001	PAINT ACRALKD SUPER TE WHITE SS7330	TATA spare parts
55319018033	ARCTICE WHITE	TATA spare parts
55319018297	TOP COOT BLOCK	TATA spare parts
553215400103	ALTERNATOR 12V 120A 6 GROOVE PULLEY BS6	TATA spare parts
553215400104	D.E BRACKET ASSY. BS6	TATA spare parts
553215400105	S.R.E BRACKET CUM RECTIFIER ASSY. CUM ST	TATA spare parts
553215400111	ROTOR ASSY. FINAL BS6	TATA spare parts
553215400112	FASTENERS & SUNDRIES PARTS KIT BS6	TATA spare parts
553215409903	REAR COVER MOULDING BS6	TATA spare parts
553220230001	LAMP ASSY NO. PLATE 24V	TATA spare parts
553220240001	STOP SWITCH PIPE MOUNTED 40 DIA 24V	TATA spare parts
553220250001	STOP DISABLE SWITCH 24V	TATA spare parts
553220260001	NUMBER PLATE LAMP COVER FRP	TATA spare parts
553224000109	BRACKET ASSY ENGINE MTG BOTTOM REAR BS6	TATA spare parts
553224000113	BRACKET ASSY ENGINE MTG BOTTOM REAR-LH B	TATA spare parts
553224000114	BRACKET ASSY ENGINE MTG BOTTOM REAR BS6	TATA spare parts



553224100107	BRACKET ASSY ENGINE MTG FRONT BS6	TATA spare parts
553224100108	BRACKET ASSY ENGINE MTG FRONT BS6	TATA spare parts
553224100109	BRACKET ASSY ENGINE MTG FRONT-RH BS6	TATA spare parts
553224100110	BRACKET ASSY ENGINE MTG FRONT-LH BS6	TATA spare parts
553224108205	COVER PLATE BS6	TATA spare parts
553224108208	COVER PLATE BS6-PH2	TATA spare parts
553224200104	BRACKET REAR ENGINE MOUNT RH BS6	TATA spare parts
553224200105	BRACKET REAR MOUNT LH BS6	TATA spare parts
553224200114	ENGINE MOUNT REAR BS6-PH2	TATA spare parts
553224207140	SPACER PLATE ENGINE MTG REAR BS6	TATA spare parts
553229100103	CLUTCH PEDAL ASSY WITH BUSH	TATA spare parts
553229100113	CLUTCH PEDAL ASSY WITH MTG BKT BS6-PH2	TATA spare parts
553229200102	BRAKE PEDAL ASSY WITH BUSH	TATA spare parts
553229200104	BRAKE PEDAL ASSY WITH MTG BRACKET BS6-PH	TATA spare parts
553229200109	BRAKE PEDAL ASSY WITH BUSH BS6	TATA spare parts
553229200110	BRACKET ASSY BRAKE CONTROL MTG BS6	TATA spare parts
553229200117	BRAKE PEDAL ASSY WITH BUSH BS6	TATA spare parts
553229200118	BRACKET ASSY BRAKE CONTROL MTG BS6-PH2	TATA spare parts
553229300101	BUNDY TUBE ASSY	TATA spare parts
553229300102	BUNDY TUBE ASSY	TATA spare parts
553229300104	BRACKET ASSY CLUTCH PEDAL MTG BS6	TATA spare parts
553229300106	CLUTCH PEDAL ASSY WITH BUSH BS6	TATA spare parts
553229300109	BUNDY TUBE ASSY CMC TO LONG MEMBER BS6	TATA spare parts
553229300111	PIPE ASSY T-CONN TO PURGE TANK BS6	TATA spare parts
553229300112	CLUTCH PIPE ASSY VACUUM BOOSTER BS6	TATA spare parts
553229300115	BUNDY TUBE ASSY CMC TO LONG MEMBER BS6	TATA spare parts
553229300116	PIPE ASSY T-CONN TO PURGE TANK BS6	TATA spare parts
553229300117	PIPE ASSY T-CONN TO HOSE BS6	TATA spare parts
553229300121	PIPE ASSY CMC TO BOOSTER BS6-PH2	TATA spare parts
553229300122	PIPE ASSY CMC TO BOOSTER BS6-PH2	TATA spare parts
553229300134	BRACKET ASSY CLUTCH SLAVE CYLINDER MTG B	TATA spare parts
553229300136	BRACKET ASSY STOPPER MTG BS6	TATA spare parts
553229300141	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
553229300143	VACUUM BOOSTER WITH CMC ASSY BS6	TATA spare parts
553229300148	CLUTCH MASTER CYLINDER ASSY BS6	TATA spare parts
553229300154	CLUTCH PIPE ASSY VACUUM BOOSTER BS6	TATA spare parts
553229300155	BUNDY TUBE ASSY CMC TO LONG MEMBER BS6	TATA spare parts
553229300159	CLUTCH PIPE ASSY VACUUM BOOSTER BS6	TATA spare parts
553229300166	NYLON PIPE ASSY BS6	TATA spare parts
553229300167	NYLON PIPE ASSY BS6	TATA spare parts
553229300168	NYLON PIPE ASSY BS6	TATA spare parts
553229300169	NYLON PIPE ASSY BS6	TATA spare parts
553229300170	CLUTCH PIPE ASSY VACUUM BOOSTER BS6	TATA spare parts
553229300172	BRACKET ASSY CLUTCH PEDAL MTG BS6-PH2	TATA spare parts
553229300174	BUNDY TUBE ASSYCMC TO LONG MEMBER BS6	TATA spare parts
553229300175	CLUTCH PIPE ASSYVACUUM BOOSTER BS6	TATA spare parts
553229300209	NYLON PIPE ASSY BS6-PH2	TATA spare parts

553229306002	LEVER BS6	TATA spare parts
553229500105	BRACKET ASSY CLUTCH & BRAKE PEDAL MTG BS	TATA spare parts
553229500129	BRACKET ASSY CLUTCH PEDAL MTG BS6	TATA spare parts
553229503306	BRACKET BRAKE & CLUTCH CONTROL MTG BS6	TATA spare parts
553229990119	MAJOR KIT-MASTER CYLINDER BS6	TATA spare parts
553229990120	MAJOR KIT-MASTER CYLINDER BS6	TATA spare parts
553229990121	MINOR KIT-MASTER CYLINDER BS6	TATA spare parts
553229990122	KIT-FLUID RESERVOIR BS6	TATA spare parts
553230100101	ACCELERATOR CABLE ASSY	TATA spare parts
553230100103	ACCELERATOR PEDAL ASSY WITH COVER	TATA spare parts
553230100106	BRACKET ASSY ACCELERATOR PEDAL MTG BS6	TATA spare parts
553230100108	BRKT ASSY ACCELERATOR PEDAL MTG BS6-PH2	TATA spare parts
553230100109	BRKT ASSY ACC PEDAL MTG BS6-PH2	TATA spare parts
553230103304	BRACKET ACCELERATOR PEDAL MTG BS6	TATA spare parts
553231000101	ASSY. FRAME WITH FITMENT BS4	TATA spare parts
553231000104	FRAME ASSY WITH FITMENT	TATA spare parts
553231000108	FRAME ASSY WITH FITMENT	TATA spare parts
553231000113	FRAME ASSY WITH FITMENT	TATA spare parts
553231000119	FRAME ASSY WITH FITMENT BS6	TATA spare parts
553231000121	FRAME ASSY WITH FITMENT	TATA spare parts
553231000123	FRAME ASSY WITH FITMENT	TATA spare parts
553231000127	FRAME ASSY WITH FITMENT	TATA spare parts
553231000129	FRAME ASSY WITH FITMENT BS6	TATA spare parts
553231000131	FRAME ASSY WITH FITMENT BS6	TATA spare parts
553231000132	FRAME ASSY WITH FITMENT BS6	TATA spare parts
553231000139	FRAME ASSY WITH FITMENT BS6	TATA spare parts
553231000141	FRAMEASSYWITHFITMENT BS6	TATA spare parts
553231000143	FRAME ASSY WITH FITMENT BS6	TATA spare parts
553231000146	FRAMEASSYWITHFITMENT BS6	TATA spare parts
553231000148	FRAME ASSY WITH FITMENT	TATA spare parts
553231000150	FRAME ASSY WITH FITMENT BS6	TATA spare parts
553231000151	FRAME ASSY WITH FITMENT BS6	TATA spare parts
553231200101	CROSS MEMBER ASSY	TATA spare parts
553231200102	CROSS MEMBER ASSY	TATA spare parts
553231200105	CROSS MEMBER ASSY BS6	TATA spare parts
553231200106	CROSS MEMBER ASSY BS6	TATA spare parts
553231200107	CROSS MEMBER ASSY BS6	TATA spare parts
553231200116	BRACKETASSY CROSSMEMBERMTG RH BS6	TATA spare parts
553231200117	BRACKETASSY CROSSMEMBERMTG LH BS6	TATA spare parts
553231200119	CROSSMEMBERASSY BS6	TATA spare parts
553231200120	CROSSMEMBERASSY BS6	TATA spare parts
553231200121	CROSSMEMBERASSY BS6	TATA spare parts
553231200122	CROSSMEMBERASSY BS6	TATA spare parts
553231200126	CROSS MEMBER ASSY BS6	TATA spare parts
553231200127	CROSS MEMBER ASSY BS6	TATA spare parts
553231200130	CROSS MEMBER ASSY WITH SUPPORT BS6-PH2	TATA spare parts
553231200137	CROSS MEMBER ASSY BS6-PH2	TATA spare parts

553231200138	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
553231200139	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
553231200143	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
553231200144	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
553231200145	CROSS MEMBER MTG ASSY BS6-PH2	TATA spare parts
553231203301	SUPPORT BRACKET CROSS MEMBER RH BS6	TATA spare parts
553231203302	SUPPORT BRACKET CROSS MEMBER LH BS6	TATA spare parts
553231207101	GUSSET BS6	TATA spare parts
553231207111	END CROSS MEMBER BS6	TATA spare parts
553231208204	REINFORCEMENT RH BS6	TATA spare parts
553231208205	REINFORCEMENT LH BS6	TATA spare parts
553231208212	REINFORCEMENT RH BS6	TATA spare parts
553231208213	REINFORCEMENT LH BS6	TATA spare parts
553231208216	SUPPORT BRACKET CROSS MEMBER RH BS6	TATA spare parts
553231208217	BRACKET CAB SUPPORT BS6	TATA spare parts
553231208226	L-REINFORCEMENT TOP-RH BS6	TATA spare parts
553231208227	L-REINFORCEMENT TOP-LH BS6	TATA spare parts
553231208228	REINFORCEMENT BOTTOM RH BS6	TATA spare parts
553231208229	REINFORCEMENT BOTTOM LH BS6	TATA spare parts
553231208230	REINFORCEMENT RH BS6	TATA spare parts
553231300101	REINFORCEMENT ASSY REAR-RH	TATA spare parts
553231300102	REINFORCEMENT ASSY REAR-LH	TATA spare parts
553231400103	CROSS MEMBER ASSY REAR SPIRNG FRONT	TATA spare parts
553231400106	CROSSMEMBERMTGASSY(CENTREBEARINGMTG.)	TATA spare parts
553231400109	CROSS MEMBER SHOCK ABSORBER REAR BS6	TATA spare parts
553231400115	CROSS MEMBER ASSY CENTER BEARING MTG BS6	TATA spare parts
553231400117	CROSS MEMBER ASSY BS6	TATA spare parts
553231400120	CENTER BEARING CROSS MEMBER ASSY BS6	TATA spare parts
553231400121	CROSS MEMBER ASSY BS6	TATA spare parts
553231400122	CROSS MEMBER ASSY BS6	TATA spare parts
553231400123	CROSS MEMBER ASSY BS6	TATA spare parts
553231408210	END CROSS MEMBER BS6	TATA spare parts
553231408231	REINFORCEMENTRHBS6	TATA spare parts
553231408232	REINFORCEMENT LH BS6	TATA spare parts
553231408242	REINFORCEMENT TOP-RH BS6	TATA spare parts
553231408243	REINFORCEMENT TOP-LH BS6	TATA spare parts
553231408244	REINFORCEMENT BOTTOM RH BS6	TATA spare parts
553231408245	REINFORCEMENT BOTTOM LH BS6	TATA spare parts
553231410103	CROSS MEMBER ASSY REAR SPIRNG FRONT BS6	TATA spare parts
553231540103	BRACKET ASSY BATTERY MTG BS6	TATA spare parts
553231540104	BRACKET ASSY BATTERY MTG BS6	TATA spare parts
553231540106	BRACKET ASSY BATTERY MTG BS6	TATA spare parts
553232100101	1ST LEAF ASSY WITH BUSH FRONT	TATA spare parts
553232100103	FRONT SPRING ASSY	TATA spare parts
553232100120	LEAF SPRING ASSY FRONT BS6	TATA spare parts
553232100122	CLAMPASSY BS6	TATA spare parts
553232100125	1STLEAFASSYWITHBUSH BS6	TATA spare parts

553232100128	BRACKET BUMPSTOPPERASSY(FRONTSPRG.BUMP	TATA spare parts
553232100134	FRONT SPRING ASSY BS6	TATA spare parts
553232100135	BRACKET ASSY WITH BUSH SPRING HANGER BS6	TATA spare parts
553232103306	BRACKET-FRONTSPRINGHANGER-LH BS6	TATA spare parts
553232103307	BRACKET-FRONTSPRINGHANGER-RH BS6	TATA spare parts
553232104202	SPRING CLIP BS6-PH2	TATA spare parts
553232106901	FERRULE BS6	TATA spare parts
553232107103	2ND LEAF	TATA spare parts
553232107104	3RD LEAF	TATA spare parts
553232107131	1STLEAF BS6	TATA spare parts
553232107132	2NDLEAF BS6	TATA spare parts
553232107133	3RDLEAF BS6	TATA spare parts
553232300103	BRACKET ASSY SHOCK ABSORBER MTG FRONT-LH	TATA spare parts
553232300104	BRACKET ASSY SHOCK ABSORBER MTG FRONT-RH	TATA spare parts
553232300109	BRACKET ASSY SHOCK ABSORBER MTG FRONT-LH	TATA spare parts
553232300111	BRACKET ASSY SHOCK ABSORBER MTG FRONT-RH	TATA spare parts
553232300113	BRACKET ASSY SHOCK ABSORBER MTG FRONT-RH	TATA spare parts
553232305101	BRACKET SHOCK ABSORBER FRONT	TATA spare parts
553232400101	REAR SPRING SEMI ELLIPTICAL ASSY	TATA spare parts
553232400102	FIRST LEAF ASSY WITH BUSH	TATA spare parts
553232400105	BUMP STOPPER ASSY	TATA spare parts
553232400106	1ST LEAF ASSY WITH BUSH	TATA spare parts
553232400107	REAR SPRING ASSY	TATA spare parts
553232400126	CLAMPASSY BS6	TATA spare parts
553232400128	LEAF SPRING ASSY REAR BS6	TATA spare parts
553232400140	BRACKETASSY REARSPRING FRONT-LH BS6	TATA spare parts
553232400141	BRACKETASSYBRACKET-(FRONT)-R.H. BS6	TATA spare parts
553232400142	BRACKETASSY SPRINGHANGER REAR-LH BS6	TATA spare parts
553232400143	BRACKET ASSY SPRING HANGER REAR-RH BS6	TATA spare parts
553232400144	1STLEAFASSYWITHBUSH BS6	TATA spare parts
553232400145	BRKT ASSY SPRING HANGER REAR-LH BS6-PH2	TATA spare parts
553232400146	BRKT ASSY SPRING HANGER REAR-RH BS6-PH2	TATA spare parts
553232400148	REAR SPRING ASSY BS6	TATA spare parts
553232400152	REAR SPRING ASSY BS6	TATA spare parts
553232400164	REAR SPRING ASSY BS6	TATA spare parts
553232407101	FIRST LEAF BS6	TATA spare parts
553232407102	SECOND LEAF	TATA spare parts
553232407103	THIRD LEAF	TATA spare parts
553232407104	FOURTH LEAF	TATA spare parts
553232407105	FIFTH LEAF	TATA spare parts
553232407106	SIXTH LEAF	TATA spare parts
553232407107	SEVENTH LEAF	TATA spare parts
553232407108	EIGHTH LEAF	TATA spare parts
553232407109	NINETH LEAF	TATA spare parts
553232407110	TENTH LEAF	TATA spare parts
553232407112	2ND LEAF	TATA spare parts
553232407113	PLATE BUMP STOPPER ASSY BS6	TATA spare parts

553232407114	3RD LEAF	TATA spare parts
553232407131	LOCK PLATE BS6	TATA spare parts
553232407138	1STLEAF BS6	TATA spare parts
553232407139	2NDLEAF BS6	TATA spare parts
553232407140	3RDLEAF BS6	TATA spare parts
553232407146	4THLEAF BS6	TATA spare parts
553232407147	SPACER(ASSY.PARABOLICSPRING) BS6	TATA spare parts
553232407148	SHACKLE BS6	TATA spare parts
553232500102	SHACKLE ASSY BS6	TATA spare parts
553232503701	CASTER PLATE BS6	TATA spare parts
553232800101	BEARING BLOCK BS6	TATA spare parts
553232800106	CONNCTINGLINKASSY FRONTANTIROLLBAR BS6	TATA spare parts
553232800107	ANTI ROLL BAR ASSY WITH LINK BS6	TATA spare parts
553232900101	ANTIROLLBARASSYWITHLINK REAR BS6	TATA spare parts
553232900105	LINK ASSY ANTI ROLL BAR BS6	TATA spare parts
553232906003	CONNECTINGLINK BS6	TATA spare parts
553232907101	SPACER PLATE BS6	TATA spare parts
553232907901	ANTIROLLBAR BS6	TATA spare parts
553233000105	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
553233000111	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
553233000113	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
553233000115	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
553233000116	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
553233000117	FRONT AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
553233000123	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
553233200101	STUB AXLE ASSY ABS RH	TATA spare parts
553233200102	STUB AXLE ASSY ABS LH	TATA spare parts
553233200115	STUB AXLE ASSY BS6-PH2	TATA spare parts
553233400101	FRONT HUB ASSY ABS BS6	TATA spare parts
553233400110	FRONT HUB ASSY BS6	TATA spare parts
553233800101	TIE ROD ASSY BS6	TATA spare parts
553233800102	TIE ROD ASSY	TATA spare parts
553233800104	TIE ROD ASSY BS6	TATA spare parts
553233805101	TIE ROD ARM RH	TATA spare parts
553233805102	TIE ROD ARM LH	TATA spare parts
553233805103	STEERING ARM	TATA spare parts
553233805104	STEERING ARM BS6	TATA spare parts
553233805105	TIE ROD ARM LHç BS6	TATA spare parts
553233805106	TIE ROD ARM RHç BS6	TATA spare parts
553233805107	STEERING ARM	TATA spare parts
553233805109	STEERINGARM BS6	TATA spare parts
553240100108	WHEEL RIM ASSY WITH VALVE BS6	TATA spare parts
553240100110	WHEEL RIM ASSY WITH VALVE BS6	TATA spare parts
553240300105	BRACKET ASSY SPARE WHEEL MTG BS6-PH2	TATA spare parts
553241000102	PROPELLER SHAFT ASSY	TATA spare parts
553241100101	PROPELLER SHAFT ASSY BS6	TATA spare parts
553241100102	PROPELLER SHAFT ASSY BS6	TATA spare parts

553241100103	PROPELLER SHAFT ASSY BS6	TATA spare parts
553241100105	PROPELLER SHAFT ASSY BS6	TATA spare parts
553241100113	PROPELLER SHAFT ASSY BS6	TATA spare parts
553241108201	GUARD PROPELLER SHAFT BS6	TATA spare parts
553241110104	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
553241110105	PROPELELR SHAFT ASSY MONOTRON BS6	TATA spare parts
553241120101	PROPELLER SHAFT ASSY REAR	TATA spare parts
553241120110	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
553241120113	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
553241120114	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
553241120115	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
553241125101	SLEEVE YOKE	TATA spare parts
553241127801	DUST SEAL	TATA spare parts
553241127802	DUST CAP	TATA spare parts
553241307102	BRACKET CENTER BRG MTG BS6	TATA spare parts
553241307104	BRACKET CENTER BRG MTG BS6-PH2	TATA spare parts
553241308201	SUPPORT PROPELLER SHAFT GUARD BS6	TATA spare parts
553241990101	BEARING PLUG SHAFT	TATA spare parts
553241990102	CENTER BEARING ASSY BRK	TATA spare parts
553241990103	CENTER BEARING KIT	TATA spare parts
553241990103DF	CENTER BEARING ASSY SFC407 BS3/4	TATA spare parts
553241990105	SLEEVE YOKE ASSY BS6-PH2	TATA spare parts
553241990107	SLEEVE YOKE ASSY BS6	TATA spare parts
553242100103	BRAKE ASSY FRONT-LH	TATA spare parts
553242100104	BRAKE ASSY FRONT-RH	TATA spare parts
553242100139	DRUM BRAKE ASSY FRONT-LH	TATA spare parts
553242100140	DRUM BRAKE ASSY FRONT-RH	TATA spare parts
553242100172	DRUM BRAKE ASSY FRONT-RH BS6	TATA spare parts
553242100176	DRUM BRAKE ASSY FRONT-LH BS6	TATA spare parts
553242100191	DRUM BRAKE ASSY WITH DC FRONT-LH - BS6	TATA spare parts
553242100192	DRUM BRAKE ASSY WITH DC FRONT-LH - BS6	TATA spare parts
553242100195	DRUMBRAKEASSYFRONT-RH BS6	TATA spare parts
553242100196	DRUMBRAKEASSYFRONT-LH BS6	TATA spare parts
553242103201	BOLT FRONT BRAKE MTG BS6	TATA spare parts
553242103202	BOLT FRONT BRAKE MTG BS6	TATA spare parts
553242103703	BRAKE DRUM FRONT	TATA spare parts
553242103707	FRONT BRAKE DRUM (120MM) BS6	TATA spare parts
553242300130	DRUM BRAKE ASSY REAR-LH BS6	TATA spare parts
553242300146	KIT-BRAKE WHEEL CYLINDER MINOR	TATA spare parts
553242300148	BRAKE ASSY REAR-LH	TATA spare parts
553242300149	BRAKE ASSY REAR-RH	TATA spare parts
553242300150	DRUM BRAKE ASSY REAR-RH BS6	TATA spare parts
553242300154	DRUM BRAKE ASSY REAR-LH BS6	TATA spare parts
553242300155	DRUM BRAKE ASSY REAR-RH BS6	TATA spare parts
553242300159	DRUM BRAKE ASSY REAR-LH	TATA spare parts
553242300160	DRUM BRAKE ASSY REAR-RH	TATA spare parts
553242300176	BRACKET ASSY ACTUATOR MTG REAR-LH BS6	TATA spare parts

553242300177	BRACKET ASSY ACTUATOR MTG REAR-RH BS6	TATA spare parts
553242303301	BRACKET ASSY SENSOR MTG REAR BS6	TATA spare parts
553242303701	BRAKE DRUM	TATA spare parts
553242303703	BRACKET BRAKE CHAMBER MTG REAR-LH EV	TATA spare parts
553242303704	BRACKET BRAKE CHAMBER MTG REAR-RH EV	TATA spare parts
553242303711	BRACKET ABS SENSOR MTG REAR BS6	TATA spare parts
553242303712	BRACKET ABS SENSOR MTG REAR BS6	TATA spare parts
553242303713	BRAKE DISC BS6-PH2	TATA spare parts
553242305401	POLE WHEEL REAR (MACHINED) BS6	TATA spare parts
553242307501	GROMMET BS6-PH2	TATA spare parts
553242309906	POLE WHEEL REAR BS6-PH2	TATA spare parts
553242309907	POLE WHEEL REAR BS6-PH2	TATA spare parts
553242310111	DRUM BRAKE ASSY WITH DC REAR-LH - TL70 (	TATA spare parts
553242310112	DRUM BRAKE ASSY WITH DC REAR-RH - TL70 (	TATA spare parts
553242310133	ABS SENSOR WITH CABLE & CONNECTOR BS6	TATA spare parts
553242700103	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
553242700105	REINFORCEMENT ASSY	TATA spare parts
553242700111	PARKING BRAKE CABLE ASSY BS6	TATA spare parts
553242700113	PARKING BRAKE ASSY	TATA spare parts
553242700114	BRACKET ASSY PARKING BRAKE CABLE MTG	TATA spare parts
553242700115	PARKING BRAKE CABLE ASSY	TATA spare parts
553242700117	PARKING BRAKE CABLE ASSY	TATA spare parts
553242700119	PARKING BRAKE LEVER ASSY	TATA spare parts
553242700127	BRACKET ASSY PARKING BRAKE CABLE MTG BS6	TATA spare parts
553242700133	PARKING BRAKE CABLE ASSY BS6	TATA spare parts
553242700148	PARKING BRAKE CABLE ASSY BS6-PH2	TATA spare parts
553242703308	BRACKET HANDBRAKE MTG	TATA spare parts
553242703329	BRACKET PARKING BRAKE CABLE MTG BS6	TATA spare parts
553242706701	HOOK & BS6	TATA spare parts
553242980109	KIT WHEEL CYLINDER-MINOR BS6	TATA spare parts
553242980110	KIT WHEEL CYLINDER-MINOR W/O EXCLUDER B	TATA spare parts
553242980112	KIT WHEEL CYLINDER-MAJOR BS6	TATA spare parts
553242980121	KIT LINED SHOE ASSY BS6	TATA spare parts
553242980122	BRK LINING KIT(STD)320X110 AFS5 8087 BS6	TATA spare parts
553242980127	KIT LINED SHOE ASSY BS6	TATA spare parts
553242980133	LINED SHOE ASSY BS6	TATA spare parts
553242980137	BRAKE LINING KIT(STD)320X110 AF 55 BS6	TATA spare parts
553242980138	BRAKE LINING KIT(OS1)320X110 AF 55 BS6	TATA spare parts
553242980145	WHEEL CYLINDER ASSY WITH BLEEDER LH BS6	TATA spare parts
553242980146	WHEEL CYLINDER ASSY WITH BLEEDER RH BS6	TATA spare parts
553242980147	WHEEL CYLINDER ASSY W/O BLEEDER LH BS6	TATA spare parts
553242980148	WHEEL CYLINDER ASSY W/O BLEEDER RH BS6	TATA spare parts
553242980149	BACK PLATE ASSY LH BS6	TATA spare parts
553242980150	BACK PLATE ASSY RH BS6	TATA spare parts
553242980157	BACK PLATE ASSY LH BS6	TATA spare parts
553242980158	BACK PLATE ASSY.REAR RH BS6	TATA spare parts
553242990101	WHEEL CYLINDER ASSY LH	TATA spare parts

553242990102	WHEEL CYLINDER ASSY RH	TATA spare parts
553242990104	WHEEL CYLINDER ASSY LH	TATA spare parts
553242990105	WHEEL CYLINDER ASSY RH	TATA spare parts
553242990107	KIT-TORQUE PLATE ASSY LH	TATA spare parts
553242990108	KIT-TORQUE PLATE ASSY RH	TATA spare parts
553242990115	KIT-CAMSHAFT LH	TATA spare parts
553242990116	KIT-CAMSHAFT RH	TATA spare parts
553242990119	SLEEVE	TATA spare parts
553242990126	KIT-BRAKE KIT-BLEED SCREW BS6	TATA spare parts
553242990130	KIT-BRAKE SHOE-HOLD DOWN	TATA spare parts
553242990131	MINOR KIT-WHEEL CYLINDER ASSY	TATA spare parts
553242990134	BACK PLATE ASSY LH	TATA spare parts
553242990135	BACK PLATE ASSY RH	TATA spare parts
553242990153	BACK PLATE ASSY	TATA spare parts
553242990154	PARKING BRAKE CABLE ASSY	TATA spare parts
553242990155	MINOR KIT-WHEEL CYLINDER ASSY	TATA spare parts
553242990156	MAJOR KIT-WHEEL CYLINDER	TATA spare parts
553242990159	BACK PLATE ASSY LH	TATA spare parts
553242990160	BACK PLATE ASSY RH	TATA spare parts
553242990161	SHOE ASSY	TATA spare parts
553242990162	KIT-BRAKE SHOE	TATA spare parts
553242990163	BRAKE LINING KIT(STD)320X90 AF 55 BS6	TATA spare parts
553242990164	BRAKE LINING KIT(OS1)320X90 AF 55 BS6	TATA spare parts
553242990165	DUST SHIELD TOP	TATA spare parts
553242990166	DUST SHIELD BOTTOM	TATA spare parts
553242990181	KIT-BRACKET ASSY LH	TATA spare parts
553242990182	KIT-BRACKET ASSY RH	TATA spare parts
553242990195	KIT-TORQUE PLATE ASSY LH	TATA spare parts
553242990196	KIT-TORQUE PLATE ASSY RH	TATA spare parts
553242993201	BOLT	TATA spare parts
553242994301	CLIP ANTI-ROTATION	TATA spare parts
553242996309	SPRING CAM END (SS) BS6-PH2	TATA spare parts
553242996701	PIN SHOE HOLD DOWN	TATA spare parts
553242998001	SET-SCREW WHEEL CYLINDER	TATA spare parts
553242998003	SCREW	TATA spare parts
553242998702	RETURN SPRING BRAKE SHOE	TATA spare parts
553242999201	SPRING WASHER	TATA spare parts
553242999902	CLIP SHOE HOLD DOWN	TATA spare parts
553243100104	MODULATOR VALVE WITH MTG BKT BS6	TATA spare parts
553243103302	BRACKET LCRV LINK MTG BS6	TATA spare parts
553243200106	AIR TANK ASSY (553243700107) BS6	TATA spare parts
553243203301	BRACKET AIR TANK MTG BS6	TATA spare parts
553243400102	EXHAUST BRAKE ASSY BS6-PH2	TATA spare parts
553243500102	VACUUM PIPE BUNCH ASSY	TATA spare parts
553243500108	PIPE ASSY QFC TO VACUUM TANK	TATA spare parts
553243500109	VACUUM BUNCH ASSY	TATA spare parts
553243500110	VACUUM BUNCH ASSY	TATA spare parts



553243500111	BOOSTER ASSY WITH TMC & RESERVOIR	TATA spare parts
553243500113	VACUUM PIPE ASSY ON CHASSIS	TATA spare parts
553243500114	VACUUM PIPE BUNCH ASSY	TATA spare parts
553243500115	PIPE BUNCH ASSY CABIN BS6	TATA spare parts
553243500118	PIPE BUNCH ASSY CABIN	TATA spare parts
553243500120	VACUUM PIPE BUNCH ASSY BS6	TATA spare parts
553243500121	VACUUM PIPE BUNCH ASSY BS6	TATA spare parts
553243500122	BOOSTER ASSY WITH TMC & RESERVOIR BS6	TATA spare parts
553243500124	VACUUM PIPE BUNCH ASSY BS6	TATA spare parts
553243500125	VACUUM PIPE BUNCH ASSY BS6	TATA spare parts
553243500128	NYLON PIPE ASSY CABIN BS6	TATA spare parts
553243500129	PIPE ASSY MAGNETIC VALVE TO PTO BS6	TATA spare parts
553243500130	VACUUM PIPE BUNCH ASSY BS6	TATA spare parts
553243500136	BOOSTER ASSY WITH TMC & RESERVOIR BS6	TATA spare parts
553243500152	VACUUM PIPE BUNCH ASSY BS6	TATA spare parts
553243500165	VACUUM TANK ASSY WITH MTG BKT BS6-PH2	TATA spare parts
553243503306	BRACKET HAND LEVER MTG BS6-PH2	TATA spare parts
553243700103	BRACKET ASSY MODULATOR VALVE MTG BS6	TATA spare parts
553243700113	BRACKET ASSY MODULATOR VALVE MTG BS6-PH2	TATA spare parts
553243700118	AUTOMATIC LOAD SENSING VALVE BS6	TATA spare parts
553243703302	BRACKET LCRV MTG	TATA spare parts
553243703303	BRACKET	TATA spare parts
553243800105	TUBE ASSY FROM TMC SEC TO ADAPTOR	TATA spare parts
553243800106	TUBE ASSY FROM TMC PRIMARY TO FRONT RH	TATA spare parts
553243800107	TUBE ASSY FROM TMC PRIMARY TO FRONT LH	TATA spare parts
553243800108	BRACKET ASSY BRAKE TUBE MTG.	TATA spare parts
553243800116	TUBE ASSY ADAPTER TO LCRV	TATA spare parts
553243800120	TUBE ASSY LCRV OUTLET TO RE HOSE	TATA spare parts
553243800122	TUBE ASSY 3-WAY UNION TO REAR-RH	TATA spare parts
553243800123	TUBE ASSY. 3-WAY UNION TO REAR-LH	TATA spare parts
553243800124	TUBE ASSY ADAPTER TO GP VALVE	TATA spare parts
553243800128	TUBE ASSY LCRV INTAKE	TATA spare parts
553243800132	TUBE ASSY FRONT HOSE TO BRAKE ASSY LH	TATA spare parts
553243800133	TUBE ASSY FRONT HOSE TO BRAKE ASSY RH	TATA spare parts
553243800136	TUBE ASSY 3-WAY UNION TO REAR-LH	TATA spare parts
553243800137	TUBE ASSY 3-WAY UNION TO REAR-RH	TATA spare parts
553243800154	TUBE ASSY ADAPTER TO LCRV INTAKE	TATA spare parts
553243800155	TUBE ASSY LCRV TO REAR HOSE	TATA spare parts
553243800169	TUBE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts
553243800170	TUBE ASSY ADAPTER TO LCRV INLET BS6	TATA spare parts
553243800171	TUBE ASSY TMC SECONDARY TO ADAPTER BS6	TATA spare parts
553243800172	TUBE ASSY TMC PRIMARY TO FRONT-RH BS6	TATA spare parts
553243800173	TUBE ASSY TMC PRIMARY TO FRONT-LH BS6	TATA spare parts
553243800174	TUBE ASSY ADAPTER TO LCRV INLET BS6	TATA spare parts
553243800177	TUBE ASSY TMC PRIMARY TO FRONT-LH BS6	TATA spare parts
553243800179	TUBE ASSY TMC PRIMARY TO FRONT-RH BS6	TATA spare parts
553243800180	TUBE ASSY LCRV TO REAR HOSE BS6	TATA spare parts

553243800181	TUBE ASSY T-CONN TO REAR-LH BS6	TATA spare parts
553243800182	TUBE ASSY T-CONN TO REAR-RH BS6	TATA spare parts
553243800184	TUBE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts
553243800211	TUBE ASSY ADAPTER TO REAR BRAKE HOSE LH	TATA spare parts
553243800212	TUBE ADAPTER TO REAR BRAKE HOSE RH BS6	TATA spare parts
553243807701	CLAMP FOR BRAKE LINES DIA 12 AND 4.75	TATA spare parts
553243808203	BRACKET GP VALVE MTG	TATA spare parts
553243808204	BRACKET BRAKE TUBE	TATA spare parts
553243808208	BRACKET BRAKE TUBE	TATA spare parts
553243808214	BRACKET BS6-PH2	TATA spare parts
553243808215	BRKT HOSE & ABS CONN MTG RR AXLE RH BS6-	TATA spare parts
553243810111	TUBE ASSY LCRV TO REAR HOSE BS6	TATA spare parts
553243810112	TUBE ASSY ADAPTER TO LCRV INLET BS6	TATA spare parts
553243810113	TUBE ASSY ADAPTER TO LCRV INLET BS6	TATA spare parts
553243810128	TUBE ASSY TMC PRIMARY TO ADAPTER BS6	TATA spare parts
553243810129	TUBE ASSY TMC SECONDARY TO ADAPTER BS6	TATA spare parts
553243810130	TUBE ASSY MV FR TO FRT BRAKE HOSE LH BS6	TATA spare parts
553243810131	TUBE ASSY MV TO ADAPTER BS6	TATA spare parts
553243810132	TUBE ASSY MV TO ADAPTER BS6	TATA spare parts
553243810133	TUBE ASSY MV TO ADAPTER BS6	TATA spare parts
553243810134	TUBE ADAPTER TO FRONT BRAKE HOSE RH BS6	TATA spare parts
553243810135	TUBE ASSY ADAPTER TO MV BS6	TATA spare parts
553243810136	TUBE ASSY ADAPTER TO MV BS6	TATA spare parts
553243810137	TUBE ASSY ADAPTER TO REAR BRAKE HOSE LH	TATA spare parts
553243810138	TUBE ASSY ADAPTER TO REAR BRAKE HOSE RH	TATA spare parts
553243810168	TUBE ASSY MV FR TO FRT BRAKE HOSE RH BS6	TATA spare parts
553243810169	TUBE ASSY MV TO REAR HOSE LH BS6-PH2	TATA spare parts
553243810170	TUBE ASSY MV TO REAR HOSE RH BS6-PH2	TATA spare parts
553243810175	TUBE ASSY ADAPTER TO FRONT BRAKE HOSE LH	TATA spare parts
553243810176	TUBE ASSY MV TO REAR HOSE RH BS6-PH2	TATA spare parts
553243810179	TUBE ASSY ADAPTER TO MV BS6-PH2	TATA spare parts
553243810181	TUBE ASSY TMC SECONDARY TO ADAPTER BS6-P	TATA spare parts
553243810182	TUBE ASSY TMC PRIMARY TO ADAPTER BS6-PH2	TATA spare parts
553243810183	TUBE ASSY ADAPTER TO MV BS6-PH2	TATA spare parts
553243810184	TUBE ASSY MV TO REAR HOSE LH BS6-PH2	TATA spare parts
553243816953	HOSE BR FLUID RESERVOIR TO TMC BS6-PH2	TATA spare parts
553243816962	HOSE BR FLUID RESERVOIR TO TMC BS6-PH2	TATA spare parts
553243900113	PIPE BUNCH ASSY	TATA spare parts
553243900141	METAL PIPE ASSY	TATA spare parts
553243900151	METAL PIPE ASSY ADAPTER TO DDU	TATA spare parts
553243900180	METAL PIPE ASSY BS6	TATA spare parts
553243900181	METAL PIPE ASSY JOINT 2 TO JOINT 3 (29	TATA spare parts
553243900182	METAL PIPE ASSY BS6	TATA spare parts
553243907501	RUBBER GROMMET BS6	TATA spare parts
553243910103	PIPE BUNCH ASSY (29WB) BS6	TATA spare parts
553243910104	METAL PIPE ASSY WITH CRIMPED HOSE (29 33	TATA spare parts
553243910105	METAL PIPE ASSY HOSE TO JOINT (33WB) BS6	TATA spare parts

553243910106	METAL PIPE JOINT TO DDU BS6	TATA spare parts
553243910135	PIPE BUNCH ASSY (33WB) BS6	TATA spare parts
553243910156	PIPE ASSY JOINT TO JOINT (29WB) BS6	TATA spare parts
553243910157	PIPE ASSY JOINT TO JOINT (29WB) BS6	TATA spare parts
553243910158	METAL PIPE JOINT TO DDU BS6	TATA spare parts
553243910159	METAL PIPE JOINT TO JOINT BS6	TATA spare parts
553243910160	METAL PIPE INT JOINT TO INT JOINT BS6	TATA spare parts
553243910163	PIPE BUNCH ASSY BS6	TATA spare parts
553243990102	TMC ASSY WITH RESERVIOR BS6	TATA spare parts
553243990103	TMC ASSY W/O RESERVIOR WITH SEAL FLUID T	TATA spare parts
553243990104	BOOSTER ASSY	TATA spare parts
553243990106	KIT NON RETURN VALVE BS6	TATA spare parts
553243990107	KIT FLUID RESERVIOR BS6	TATA spare parts
553243990108	KIT-MASTER CYL	TATA spare parts
553243990117	KIT-ADAPTER BS6	TATA spare parts
553243990118	KIT-BOOSTER BS6	TATA spare parts
553243990119	TMC ASSY W/O RESERVIOR WITH SEAL FLUID T	TATA spare parts
553243990120	BOOSTER ASSY BS6	TATA spare parts
553243990121	TANDEM MASTER CYLINDER ASSY BS6	TATA spare parts
553243990122	TANDEM MASTER CYLINDER ASSY BS6	TATA spare parts
553243990140	TANDEM MASTER CYLINDER ASSY BS6	TATA spare parts
553246100103	STEERING COLUMN ASSY - 29WB BS6	TATA spare parts
553246100104	STEERING COLUMN ASSY BS6	TATA spare parts
553246100105	STEERING COLUMN ASSY BS6	TATA spare parts
553246100111	STEERING COLUMN ASSY BS6	TATA spare parts
553246100113	STEERING COLUMN ASSY BS6-PH2	TATA spare parts
553246107701	RUBBER BELLOW BS6	TATA spare parts
553246107702	RUBBER BELLOW STG COLUMN BS6	TATA spare parts
553246108202	COVER STG COLUMN BELLOW BS6	TATA spare parts
553246305101	PITMAN ARM	TATA spare parts
553246305102	PITMAN ARM	TATA spare parts
553246305105	PITMAN ARM BS6	TATA spare parts
553246600101	POWER STEERING PUMP ASSY BS6	TATA spare parts
553246600102	STEERING GEAR BOX ASSY	TATA spare parts
553246600107	STEERING GEAR BOX ASSY WITH PITMAN ARM B	TATA spare parts
553246600109	HOUSING ASSY BS6	TATA spare parts
553246600111	VANE PUMP BS6	TATA spare parts
553246600112	HOUSING ASSY BS6	TATA spare parts
553246600114	BRACKET ASSY RESERVOIR MTG BS6	TATA spare parts
553246600116	WORM & RACK ASSY BS6	TATA spare parts
553246600118	SECTOR SHAFT ASSY BS6	TATA spare parts
553246600119	HOUSING ASSY BS6	TATA spare parts
553246600120	WORM & VALVE HSG WITH RACK ASSY BS6	TATA spare parts
553246600121	POWER STEERING GEAR ASSY BS6	TATA spare parts
553246600122	POWER STEERING GEAR BOX ASSYBS6	TATA spare parts
553246600124	UNIVERSAL JOINT ASSY BS6	TATA spare parts
553246600125	POWER STEERING PUMP ASSYBS6	TATA spare parts

553246600126	CARTRIDGE ASSY BS6	TATA spare parts
553246600127	STRG GR BOX ASSY WITH PITMAN ARM BS6-PH2	TATA spare parts
553246600128	POWER STEERING GEAR BOX ASSY BS6	TATA spare parts
553246600129	STEERING GEAR BOX ASSY BS6-PH2	TATA spare parts
553246600131	PISTON ASSY BS6-PH2	TATA spare parts
553246600132	SET-STEERING COMPONENT BS6-PH2	TATA spare parts
553246600134	HOUSING ASSY BS6-PH2	TATA spare parts
553246600138	SECTOR SHAFT ASSY BS6-PH2	TATA spare parts
553246600140	POWER STEERING GEAR BOX ASSY - BS6	TATA spare parts
553246607901	SHAFT ASSY BS6	TATA spare parts
553246608801	STUD BS6-PH2	TATA spare parts
553246703301	BRACKET STG GEAR BOX MTG	TATA spare parts
553246703701	BRACKET STG GEAR BOX MTG	TATA spare parts
553246800101	SUCTION LINE ASSY RESERVOIR TO PUMP	TATA spare parts
553246800102	RETURN LINE ASSY	TATA spare parts
553246800103	PRESSURE LINE ASSY	TATA spare parts
553246800104	SUCTION LINE ASSY	TATA spare parts
553246800105	PRESSURE LINE ASSY	TATA spare parts
553246800106	RETURN LINE ASSY	TATA spare parts
553246800109	HIGH PRESSURE LINE ASSY BS6	TATA spare parts
553246800112	RETURN LINE ASSY BS6	TATA spare parts
553246800115	SUCTION LINE ASSY BS6	TATA spare parts
553246800119	SUCTION LINE ASSY BS6	TATA spare parts
553246800121	HIGH PRESSURE LINE ASSY BS6	TATA spare parts
553246800122	SUCTION LINE ASSY BS6	TATA spare parts
553246800123	RETURN LINE ASSY BS6	TATA spare parts
553246800124	SUCTION LINE ASSY BS6-PH2	TATA spare parts
553246900101	DRAG LINK ASSY	TATA spare parts
553246900102	DRAG LINK ASSY BS6	TATA spare parts
553246900110	TIE ROD END ASSY LH BS6-PH2	TATA spare parts
553246900111	TIE ROD END ASSY RH BS6-PH2	TATA spare parts
553246900112	KIT-BALL JOINT BS6-PH2	TATA spare parts
553246900113	DRAG LINK ASSY BS6	TATA spare parts
553246990107	KIT-SEAL BS6	TATA spare parts
553246990108	SMALL COMPONENT SET BS6	TATA spare parts
553246990109	KIT-DRAG LINK ASSY BS6-PH2	TATA spare parts
553246990119	KIT-SEAL BS6	TATA spare parts
553246990121	KIT-HOUSING ASSY BS6	TATA spare parts
553246990122	INPUT SHAFT ASSY BS6	TATA spare parts
553247100101	FUEL TANK ASSY WITH STRAP BS6	TATA spare parts
553247100103	FUEL TANK ASSY WITH BRACKET	TATA spare parts
553247100108	FUEL TANK ASSY BS6-PH2	TATA spare parts
553247100124	FUEL TANK ASSY BS6-PH2	TATA spare parts
553247109902	CYLINDER BS6	TATA spare parts
553247500105	BRACKET ASSY BS6-PH2	TATA spare parts
553247500107	STRAP ASSY & RBR FUEL TANK MTG BS6-PH2	TATA spare parts
553247500109	BRACKET ASSY BS6-PH2	TATA spare parts

553247503301	BRACKET BS6	TATA spare parts
553247600106	SUCTION PIPE ASSY FILTER TO FIP	TATA spare parts
553247600107	RETURN FUEL PIPE ASSY ENG TO FUEL TANK	TATA spare parts
553247600108	HP PIPE ASSY SOLENOID TO HP REGULATOR BS	TATA spare parts
553247600109	SUCTION PIPE ASSY TANK TO PRE-FILTER	TATA spare parts
553247600110	SUCTION PIPE ASSY FILTER TO FIP	TATA spare parts
553247600111	FUEL RETURN PIPE ASSY OVER FLOW TO TANK	TATA spare parts
553247600112	FUEL RETURN PIPE ASSY OVER FLOW TO TANK	TATA spare parts
553247600113	SUCTION PIPE ASSY TANK TO PRE-FILTER	TATA spare parts
553247600114	SUCTION PIPE ASSY FILTER TO FIP	TATA spare parts
553247600115	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553247600118	PRIMING PUMP ASSY BS6	TATA spare parts
553247600119	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553247600120	FUEL RETURN PIPE ASSY BS6	TATA spare parts
553247600122	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553247600123	FUEL RETURN PIPE ASSY BS6	TATA spare parts
553247600125	HP TUBE ASSY WITH PVC SLEEVE BS6	TATA spare parts
553247600127	VENT PIPE ASSY BS6	TATA spare parts
553247600130	VENT TUBE ASSY BS6	TATA spare parts
553247600131	FUEL PIPE ASSY SUPPLY LINE TO ENGINE BS6	TATA spare parts
553247600132	FUEL PIPE ASSY RETURN LINE (29WB) BS6	TATA spare parts
553247600133	FUEL PIPE BS6	TATA spare parts
553247600140	HP PIPE ASSY BS6	TATA spare parts
553247600141	VENT PIPE ASSY BS6	TATA spare parts
553247600142	HP PIPE ASSY BS6	TATA spare parts
553247600143	VENT PIPE ASSY BS6	TATA spare parts
553247600144	VENT PIPE ASSY BS6	TATA spare parts
553247600145	HP PIPE ASSY SOLENOID TO HP REGULATOR BS	TATA spare parts
553247600146	VENT PIPE ASSY BS6	TATA spare parts
553247600147	VENT PIPE ASSY BS6	TATA spare parts
553247600148	VENT TUBE ASSY BS6	TATA spare parts
553247600150	FUEL PIPE ASSY SUPPLY LINE TO ENGINE BS6	TATA spare parts
553247600152	FUEL PIPE ASSY FILTER TO FIP BS6	TATA spare parts
553247600155	FUEL RETURN PIPE ASSY BS6	TATA spare parts
553247600156	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553247600165	RETURN FUEL PIPE ASSY BS6	TATA spare parts
553247600169	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553247600221	SUCTION FUEL PIPE ASSY	TATA spare parts
553247600222	FUEL RETURN PIPE ASSY	TATA spare parts
553247603303	BRACKET FILTER MTG BS6-PH2	TATA spare parts
553247603304	BRACKET BS6	TATA spare parts
553247610104	FUEL RETURN PIPE ASSY ENGINE TO TANK SEG	TATA spare parts
553247610105	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
553247610106	FUEL PIPE ASSY FILTER TO FIP BS6	TATA spare parts
553247700101	INTEGRATED FILLING UNIT ASSY BS6	TATA spare parts
553249100101	BRACKET ASSY DOC POC MTG	TATA spare parts
553249100102	BRACKET ASSY	TATA spare parts

553249100103	PIPE ASSY DPS SENSOR INTAKE	TATA spare parts
553249100104	PIPE ASSY DPS SENSOR REAR	TATA spare parts
553249100108	PIPE ASSY DPS SENSOR	TATA spare parts
553249100110	PIPE ASSY DPS SENSOR	TATA spare parts
553249100114	SILENCER ASSY EXHAUSTç BS6	TATA spare parts
553249103302	BRACKET CATCON MTG	TATA spare parts
553249200102	BRACKET ASSY DPS SENSOR	TATA spare parts
553249200103	ASSY. BRACKET (SILENCER MOUNTING)	TATA spare parts
553249200104	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
553249200108	EXHAUST PIPE ASSY WITH FLEX BELLOW	TATA spare parts
553249200111	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
553249200112	PIPE ASSY EXHAUST PIPE TO HOSE DPS	TATA spare parts
553249200117	EXH PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
553249200119	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
553249200120	BRACKET ASSY EGP MTG BS6	TATA spare parts
553249200123	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
553249200124	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts
553249200131	BRACKET ASSY EXHAUST PIPE BS6	TATA spare parts
553249200141	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
553249200143	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
553249200145	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
553249200149	UREA PIPE ASSY (29WB) (553249200127) BS6	TATA spare parts
553249200154	BRACKET ASSY BS6	TATA spare parts
553249200168	TAIL PIPE ASSY BS6	TATA spare parts
553249200170	BRACKET ASSY TAIL PIPE MTG BS6	TATA spare parts
553249200174	BRACKET ASSY EXHAUST PIPE BS6	TATA spare parts
553249200186	EXH PIPE ASSY W/FLEX BELLOW FRT BS6-PH2	TATA spare parts
553249200189	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
553249203302	BRACKET EXHAUST PIPE CLAMPING	TATA spare parts
553249203306	BRACKET BS6	TATA spare parts
553249206921	DIFFUSER BS6	TATA spare parts
553249206922	TAIL PIPE (29WB) BS6	TATA spare parts
553249206923	DIFFUSER BS6	TATA spare parts
553249206931	DIFFUSER BS6	TATA spare parts
553249208202	U-BOLT BS6	TATA spare parts
553249208203	CLAMP BS6	TATA spare parts
553249208204	BRACKET EXHAUST PIPE MTG BS6	TATA spare parts
553249208205	BRACKET EXHAUST PIPE BS6	TATA spare parts
553249208801	STUD BS6	TATA spare parts
553249208802	STUD BS6-PH2	TATA spare parts
553249609901	HEAT SHIELD PIPE	TATA spare parts
553249609902	HEAT SHIELD PIPE	TATA spare parts
553249609903	HEAT SHIELD PIPE	TATA spare parts
553249609904	HEAT SHIELD PIPE	TATA spare parts
553249609905	HEAT SHIELD PIPE	TATA spare parts
553249609906	HEAT SHIELD PIPE	TATA spare parts
553249609907	HEAT SHIELD PIPE	TATA spare parts

553249609909	HEAT SHIELD DOC POC	TATA spare parts
553254200106	INSTRUMENT CLUSTER ASSY	TATA spare parts
553254200109	INSTRUMENT CLUSTER ASSY	TATA spare parts
553254200112	INSTRUMENT CLUSTER ASSY	TATA spare parts
553254200113	INSTRUMENT CLUSTER ASSY	TATA spare parts
553254200115	INSTRUMENT CLUSTER 0.76 RATIO	TATA spare parts
553254300101	BUZZER UNIT BS6	TATA spare parts
553254303301	BRACKETBUZZER MTG	TATA spare parts
553254304901	ELECTRIC BUZZER BS6	TATA spare parts
553254304902	FUEL LEVEL SENSOR BS6-PH2	TATA spare parts
553254304903	FUEL LEVEL SENSOR BS6-PH2	TATA spare parts
553254400125	TAIL LAMP LED ASSY LH BS6-PH2	TATA spare parts
553254400126	TAIL LAMP LED ASSY RH BS6-PH2	TATA spare parts
553254433301	BRACKET TAIL LAMP MTG BS6	TATA spare parts
553254500102	SWITCH BATTERY CUT OFF-MTG BRACKET ASSY	TATA spare parts
553254500104	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
553254501601	ENGINE LAMP SWITCH BS6	TATA spare parts
553254501602	BATTERY CUT OFF SWITCH BS6	TATA spare parts
553254501603	CARRIER PLATE BS6	TATA spare parts
553254504901	SWITCH REGENERATION START MANUAL BS6	TATA spare parts
553254504902	SWITCH FRONT FOG LAMP BS6	TATA spare parts
553254504903	SWITCH-LIGHT MODE BS6	TATA spare parts
553254504905	HAZARD WARNING SWITCH BS6	TATA spare parts
553254504906	SWITCH REGENERATION INHIBIT BS6	TATA spare parts
553254504907	SWITCH-HEAVY MODE BS6	TATA spare parts
553254504908	SWITCH REAR FOG LAMP BS6	TATA spare parts
553254504909	SWITCH EXHAUST BRAKE BS6	TATA spare parts
553254504910	SWITCH BATTERY CUT OFF BS6	TATA spare parts
553254504911	ROTARY SWITCH HEADLAMP 550754501629 BS6	TATA spare parts
553254504912	CARRIER PLATE ASSY FACIA SWITCH MTG BS6	TATA spare parts
553254504913	SWITCHABS OFF BS6	TATA spare parts
553254504914	SWITCH ASSY COMBINATION BS6-PH2	TATA spare parts
553254600104	WIRING HARNESS TAIL	TATA spare parts
553254600110	PIGATIL MUSIC SYSTEM	TATA spare parts
553254600111	FUSE BOX COVER	TATA spare parts
553254600112	BATTERY CABLE +VE MEGA FUSE	TATA spare parts
553254600113	WIRING HARNESS MAIN	TATA spare parts
553254600115	WIRING HARNESS MAIN	TATA spare parts
553254600118	WIRING HARNESS MAIN	TATA spare parts
553254600119	WIRING HARNESS MAIN	TATA spare parts
553254600122	WIRING HARNESS MAIN	TATA spare parts
553254600124	WIRING HARNESS MAIN	TATA spare parts
553254600125	WIRING HARNESS TAIL	TATA spare parts
553254600127	WIRING HARNESS TAIL	TATA spare parts
553254600128	WIRING HARNESS TAIL	TATA spare parts
553254600131	WIRING HARNESS TAIL	TATA spare parts
553254600134	WIRING HARNESS TAIL	TATA spare parts

553254600136	WIRING HARNESS TAIL	TATA spare parts
553254600137	WIRING HARNESS ENGINE	TATA spare parts
553254600147	WIRING HARNESS ENGINE	TATA spare parts
553254600149	BATTERY CABLE -VE	TATA spare parts
553254600160	PIGTAIL VEHICLE SPEED SENSOR	TATA spare parts
553254600175	PIGTAIL BRAKE FLUID BOTTLE W/H	TATA spare parts
553254600201	WIRING HARNESS-TAIL BS6	TATA spare parts
553254601606	WIRING HARNESS INJECTOR	TATA spare parts
553254601608	WIRING HARNESS ENGINE	TATA spare parts
553254601609	WIRING HARNESS SENSOR	TATA spare parts
553254601613	WIRING HARNESS MAIN	TATA spare parts
553254601624	PIGTAIL WIRING HARNESS	TATA spare parts
553254601625	WIRING HARNESS TAIL	TATA spare parts
553254601627	WIRING HARNESS MAIN	TATA spare parts
553254601628	WIRING HARNESS TAIL	TATA spare parts
553254601629	WIRING HARNESS ENGINE	TATA spare parts
553254601635	WIRING HARNESS MAIN	TATA spare parts
553254601636	WIRING HARNESS TAIL	TATA spare parts
553254601639	WIRING HARNESS TAIL	TATA spare parts
553254601640	CABLE MEGAFUSE O/P TO STARTER +VE	TATA spare parts
553254601641	WIRING HARNESS TAIL	TATA spare parts
553254601642	WIRING HARNESS MAIN	TATA spare parts
553254601643	WIRING HARNESS MAXI FUSE	TATA spare parts
553254601645	WIRING HARNESS TAIL LAMP	TATA spare parts
553254601646	WIRING HARNESS TAIL	TATA spare parts
553254601647	WIRING HARNESS MAIN	TATA spare parts
553254603303	BRACKET INTERFACE CONNECTOR MTG BS6	TATA spare parts
553254603304	BRACKET INTERFACE CONNECTOR MTG BS6	TATA spare parts
553254603306	BRACKET INTERFACE CONNECTOR MTG BS6	TATA spare parts
553254603307	PLATE WIRING HARNESS MTG BS6	TATA spare parts
553254603308	BRACKET INTERFACE CONNECTOR MTG BS6	TATA spare parts
553254606301	STICKER MAXI FUSE BOX BS6	TATA spare parts
553254610102	ASSY.BATT.CABLE +VE (W/COT) 1.26M 35SQ I	TATA spare parts
553254610128	WIRING HARNESS MAIN	TATA spare parts
553254610137	WIRING HARNESS MAIN	TATA spare parts
553254610142	WIRING HARNESS ENGINE	TATA spare parts
553254610143	ASSY.BATT.CABLE +VE	TATA spare parts
553254610144	WIRING HARNESS MAIN	TATA spare parts
553254610145	ASSY.BATTERY CABLE -VE(2100MM)SFC407CNG.	TATA spare parts
553254610146	ASSY.BATTERY CABLE +VE - SFC 407 CNG	TATA spare parts
553254610147	FUSE BOX MTG ASSY BS6	TATA spare parts
553254610149	ANTENNA CABLE	TATA spare parts
553254610151	WIRING HARNESS PARKING BRAKE	TATA spare parts
553254610157	WIRING HARNESS ENGINE BS6	TATA spare parts
553254610158	WIRING HARNESS EMS BS6	TATA spare parts
553254610170	WIRING HARNESS ENGINE BS6	TATA spare parts
553254610171	WIRING HARNESS TAIL BS6	TATA spare parts



553254610174	WIRING HARNESS MAIN BS6	TATA spare parts
553254610177	WIRING HARNESS SENSOR BS6	TATA spare parts
553254610179	WIRING HARNESS SIDE MARKER LAMP BS6	TATA spare parts
553254610180	BATTERY CABLE +VE MEGA FUSE	TATA spare parts
553254610183	BATTERY CABLE -VE	TATA spare parts
553254610184	BATTERY CABLE +VE	TATA spare parts
553254620109	BATTERY CABLE +VE BS6	TATA spare parts
553254620110	BATTERY CABLE -VE BS6	TATA spare parts
553254620111	WIRING HARNESS SIDE MARKER LAMP	TATA spare parts
553254620113	WIRING HARNESS TAIL BS6	TATA spare parts
553254620115	WIRING HARNESS MAXI FUSE BS6	TATA spare parts
553254620121	WIRING HARNESS TAIL BS6	TATA spare parts
553254620122	WIRING HARNESS MAIN BS6	TATA spare parts
553254620123	WIRING HARNESS MAIN BS6	TATA spare parts
553254620124	FUSE BOX MTG ASSY BS6	TATA spare parts
553254620125	WIRING HARNESS TAIL BS6	TATA spare parts
553254620127	BATTERY CABLE +VE BS6	TATA spare parts
553254620131	BATTERY CABLE +VE (COMMONIZED WITH 55275	TATA spare parts
553254620132	BATTERY CABLE +VE BS6	TATA spare parts
553254620133	WIRING HARNESS MAIN ASSY	TATA spare parts
553254620134	BATTERY CABLE -VE BS6	TATA spare parts
553254620145	WIRING HARNESS REVERSE PARK ASSIST BS6	TATA spare parts
553254620146	WIRING HARNESS TAIL BS6	TATA spare parts
553254620151	WIRING HARNESS EMS BS6	TATA spare parts
553254620155	PIGTAILCOMBI SWITCH BS6	TATA spare parts
553254620158	WIRING HARNESS MAIN BS6	TATA spare parts
553254620180	WIRING HARNESS MAXI FUSE	TATA spare parts
553254620187	WIRINGHARNESSABS BS6	TATA spare parts
553254620188	WIRING HARNESS ABS FRAME LP 410 29 (5532	TATA spare parts
553254620190	WIRINGHARNESS MAIN BS6	TATA spare parts
553254620192	EARTH STRAP BS6	TATA spare parts
553254620193	BRACKET ASSY MAXI FUSE BOX MTG BS6	TATA spare parts
553254626301	STICKER MAXI FUSE BOX BS6	TATA spare parts
553254630102	WIRING HARNESS MAIN BS6	TATA spare parts
553254630111	BRACKET ASSY FUSE BOX MTG BS6-PH2	TATA spare parts
553254630112	WIRING HARNESS TAIL BS6	TATA spare parts
553254630114	WIRINGHARNESSTAIL BS6	TATA spare parts
553254630118	WIRING HARNESS MAIN BS6	TATA spare parts
553254630119	WIRING HARNESS LOAD BODY LAMP BS6	TATA spare parts
553254630122	WIRING HARNESS ABS BS6	TATA spare parts
553254630123	WIRING HARNESS TAIL BS6	TATA spare parts
553254630126	WIRING HARNESS EMS BS6-PH2	TATA spare parts
553254630132	WIRING HARNESS ESC BS6-PH2	TATA spare parts
553254630143	WIRING HARNESS MAIN BS6	TATA spare parts
553254630145	W/H REVERSE PARK ASSIST BS6-PH2	TATA spare parts
553254630148	WIRING HARNESS ROOF LAMP BS6	TATA spare parts
553254630158	WIRING HARNESS MAXI FUSE BS6-PH2	TATA spare parts

553254630160	WIRING HARNESS SWITCH BS6-PH2	TATA spare parts
553254630161	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
553254630162	WIRING HARNESS SCR UNIT BS6-PH2	TATA spare parts
553254630165	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
553254630168	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
553254630171	WIRING HARNESS ESC BS6-PH2	TATA spare parts
553254630174	WIRING HARNESS SENSOR BS6	TATA spare parts
553254630177	BATTERY CABLE -VE BS6-PH2	TATA spare parts
553254650103	ADD ON WIRING HARNESS BS6	TATA spare parts
553254700102	BRACKET ASSY VECU MTG BS6	TATA spare parts
553254700104	BRACKET ASSY VEHICLE TRACKING ASSY MTG B	TATA spare parts
553254700108	BRACKET ASSY YAW RATE SENSOR MTG BS6-PH2	TATA spare parts
553254700109	BRACKET ASSY YAW RATE SENSOR MTG BS6-PH2	TATA spare parts
553254708206	BRACKET BS6-PH2	TATA spare parts
553254800111	. SPEAKER BS6	TATA spare parts
553254820101	BRACKET ASSY BS6	TATA spare parts
553254900102	BRACKET ASSY ECU MTG	TATA spare parts
553258903501	SPANNER BS6	TATA spare parts
553258904201	TOOL KIT -BRAKE DIAGNOSTIC	TATA spare parts
553258904202	TOOL KIT -VACUUM DIAGNOSTIC	TATA spare parts
553258904203	CLAMP -HOSE	TATA spare parts
553258904204	HOSE -EZ BLEED	TATA spare parts
553258904205	TESTER -BRAKE FLUID	TATA spare parts
553258904206	TOOL -CALIPER PISTON EXTRACTION	TATA spare parts
553258904207	TOOL KIT -AUTO ADJUSTER	TATA spare parts
55326000003R40	ASSEMBLY BODY FITTED	TATA spare parts
55326000005R40	ASSEMBLY BODY FITTED	TATA spare parts
55326000006R40	ASSEMBLY BODY FITTED BS4	TATA spare parts
55326000007R40	PARTIALLY FITTED CAB W/O WIRING HARNESS	TATA spare parts
55326000008R40	ASSEMBLY BODY FITTED	TATA spare parts
55326000009R40	PARTIALLY FITTED CAB W/O ELECTRICALS	TATA spare parts
55326000011R40	ASSEMBLYBODYFITTED	TATA spare parts
55326000012R40	ASSEMBLY BODY FITTED	TATA spare parts
55326000014R40	ASSEMBLY BODY FITTED	TATA spare parts
55326000015R40	ASSEMBLY BODY FITTED	TATA spare parts
55326000017R40	PARTIAL FITTED CABIN SFC 407 BS4	TATA spare parts
55326000019R40	PARTIALLY FITTED CAB W/O ELECTICALS	TATA spare parts
55326000022R40	ASSEMBLY BODY FITTED	TATA spare parts
55326000023R40	ASSEMBLY BODY FITTED	TATA spare parts
55326000024R40	PARTIALLY FITTED CAB W/O ELECTICALS &AMP	TATA spare parts
55326000025R40	ASSEMBLY BODY FITTED	TATA spare parts
55326000028R40	PARTIALLY FITTED CAB W/O ELECTICALS & CO	TATA spare parts
55326000031R40	PARTIALLY FITTED CAB W/O ELECTRICALS	TATA spare parts
55326000033R40	ASSEMBLY BODY FITTED	TATA spare parts
55326000047R40	ASSEMBLY BODY FITTED	TATA spare parts
55326000050R40	ASSEMBLY BODY FITTED	TATA spare parts
55326000098R40	PARTIALLY FITTED CAB W/O ELECTICALS & CO	TATA spare parts

55326000158R40	407 GOLD SFC DCR29CBC 100B6M5_CAB/COWL B	TATA spare parts
55326000159R40	PARTIALLY FITTED CAB W/O ELECTICALS &AMP	TATA spare parts
55326000160R40	PARTIALLY FITTED CAB W/O ELECTICALS BS6	TATA spare parts
55326000161R40	PARTIALLY FITTED CAB W/O ELECTICALS BS6	TATA spare parts
55326000162R40	610 SFC DCR33HSD 100B6M5_CAB BS6	TATA spare parts
55326000182R40	610 SFC PARTIAL FITTED CAB BS6	TATA spare parts
55326000183R40	PARTIALLY FITTED CAB W/O ELECTICALS 510	TATA spare parts
55326000191R40	PARTIAL FITTED CAB 407 GOLD SFC BS6	TATA spare parts
55326000246R40	PARTIALLY FITTED CAB W/O ELECTICALS BS6	TATA spare parts
553270108201	STAY ROD BS6-PH2	TATA spare parts
553282900101	KIT-WASHER SYSTEM BS6	TATA spare parts
553310000001	FRONT LED SIGN OLA098	TATA spare parts
553316100001	CONTAINER NO.3.8TCIC CNG ENG. BS-IV	TATA spare parts
553316172001	ECU ELECTRONIC BRAKING SYSTEM	TATA spare parts
553324100101	ENGINE MTG ASSY	TATA spare parts
553324100110	BRACKETASSY TOP-RH	TATA spare parts
553324100111	BRACKETASSY	TATA spare parts
553324100112	A-MOUNTTRACTIONUNITASSY	TATA spare parts
553324100113	BRACKETASSY FRAMESIDE RH	TATA spare parts
553324100114	BRACKETASSY FRAMESIDE LH	TATA spare parts
553324100124	BRACKET ASSY FRAME SIDE LH	TATA spare parts
553324100125	BRACKET ASSY FRAME SIDE RH	TATA spare parts
553324107122	STOPPER BASE PLATE	TATA spare parts
553324200101	ENGINE MTG ASSY LH	TATA spare parts
553324200102	ENGINE MTG ASSY RH	TATA spare parts
553324200103	ENGINE MTG ASSY RH	TATA spare parts
553324200104	ENGINE MTG ASSY LH	TATA spare parts
553324200107	GUSSET ASSY RH	TATA spare parts
553324200108	GUSSET ASSY LH	TATA spare parts
553326800112	GEAR SHIFT LEVER ASSY	TATA spare parts
553329100101	CLUTCH PIPE RHD	TATA spare parts
553329100102	CLUTCH PIPE ASSY	TATA spare parts
553331000104	FRAME ASSY	TATA spare parts
553331000105	FRAME ASSY 4920WB LPO9.6T WITH TOP COAT	TATA spare parts
553331000108	FRAME ASSY 3L 9.6T 4920 WITH TOPCOAT	TATA spare parts
553331000109	FRAME ASSY COMPLETE	TATA spare parts
553331000123	FRAMEASSYWITHTOPCOAT	TATA spare parts
553331000128	FRAMEASSYWITHTOPCOAT	TATA spare parts
553331000132	FRAMEASSYWITHTOPCOAT EV	TATA spare parts
553331107103	HUMP RH	TATA spare parts
553331107104	HUMP LH	TATA spare parts
553331200101	TUBE CROSSMEMBER ASSEMBLY	TATA spare parts
553331200102	HAT CROSSMEMBER ASSEMBLY 2	TATA spare parts
553331200103	C CROSSMEMBER ASSEMBLY	TATA spare parts
553331200107	TUBE ASSY CROSS MEMBER	TATA spare parts
553331200108	CRANK CROSS MEMBER ASSEMBLY	TATA spare parts
553331200109	ASSEMBLY OUTTRIGGER SUPPORT 1	TATA spare parts

553331200110	ASSEMBLY OUTTRIGGER SUPPORT 2 LH	TATA spare parts
553331200111	ASSEMBLY OUTTRIGGER SUPPORT 2 RH	TATA spare parts
553331200112	HAT CROSSMEMBER ASSEMBLY 1	TATA spare parts
553331200113	ASSEMBLY BUPM STOPER	TATA spare parts
553331200114	ASSEMBLY BUMP STOPER 2	TATA spare parts
553331200117	ASSEMBLY BRACKET FES MOUNTING RH	TATA spare parts
553331200118	ASSEMBLY BRACKET FES MOUNTING LH	TATA spare parts
553331200119	BRACKET ASSY FES MOUNTING	TATA spare parts
553331200146	BRACKETASSY LH	TATA spare parts
553331200147	BRACKET ASSY¿ RH	TATA spare parts
553331200148	BRACKETASSY ENGINEMTG FRONT-RH	TATA spare parts
553331200149	BRACKET ASSY ENGINE MTG LH	TATA spare parts
553331207116	PLATE 1 RH	TATA spare parts
553331207117	PLATE 2	TATA spare parts
553331207119	PLATE 1 LH	TATA spare parts
553331207122	SPARE WHEEL BRACKET	TATA spare parts
553331207127	L-BRACKET 1	TATA spare parts
553331207128	L-BRACKET 2	TATA spare parts
553331207129	REINFORCEMENT RH	TATA spare parts
553331207130	REINFORCEMENT LH	TATA spare parts
553331207152	COBRABRACKET	TATA spare parts
553331207153	COBRABRACKET	TATA spare parts
553331208201	REINFORCEMENT 1 RH	TATA spare parts
553331208202	REINFORCEMENT 1 LH	TATA spare parts
553331208204	REINFORCEMENT 2	TATA spare parts
553331208224	REINFORCEMENT 3 RH	TATA spare parts
553331208225	REINFORCEMENT 3 LH	TATA spare parts
553331208226	REINFORCEMENT 4 RH	TATA spare parts
553331208227	REINFORCEMENT 4 LH	TATA spare parts
553331208231	REINFORCEMENT 8 RH	TATA spare parts
553331208232	REINFORCEMENT 8 LH	TATA spare parts
553331208233	CROSS MEMBER C TYPE	TATA spare parts
553331320121	BRACKET BELLOWMTG LH	TATA spare parts
553331320122	BRACKET BELLOWMTG RH	TATA spare parts
553331320123	BRACKET AIRBELLOWMTG REAR	TATA spare parts
553331320124	BRACKET AIRBELLOWMTG REAR	TATA spare parts
553331320132	BRACKETAIRBELLOWMTGREAR EV	TATA spare parts
553331320133	BRACKETAIRBELLOWMTGREAR EV	TATA spare parts
553331327158	BACKPLATE	TATA spare parts
553331400102	ASSY. SHOCK ABSORBER CROSS MEMBER	TATA spare parts
553331400104	CROSS MEMBER ASSY	TATA spare parts
553331400105	CROSS MEMBER ASSY EV	TATA spare parts
553331407102	COBRA BRACKET 2 RH	TATA spare parts
553331407103	COBRA BRACKET 2 LH	TATA spare parts
553331407104	COBRA BRACKET 4	TATA spare parts
553331407105	COBRA BRACKET 5	TATA spare parts
553331407106	PLATE 1	TATA spare parts

553331407107	PLATE 2	TATA spare parts
553331407108	PLATE 3	TATA spare parts
553331407109	PLATE 4	TATA spare parts
553331407111	PLATE 5	TATA spare parts
553331407113	PLATE 7	TATA spare parts
553331407115	PLATE 9	TATA spare parts
553331407116	L-BRACKET	TATA spare parts
553331407144	COBRA BRACKET	TATA spare parts
553331407145	COBRA BRACKET	TATA spare parts
553331407146	COBRA BRACKET RH	TATA spare parts
553331407147	COBRA BRACKET LH	TATA spare parts
553331407148	COBRA BRACKET LH	TATA spare parts
553331407149	COBRA BRACKET RH	TATA spare parts
553331407150	COBRA BRACKET RH	TATA spare parts
553331407151	COBRA BRACKET LH	TATA spare parts
553331407152	COBRA BRACKET LH EV	TATA spare parts
553331407153	COBRA BRACKET RH EV	TATA spare parts
553331407160	COBRABRACKETRH EV	TATA spare parts
553331407161	COBRA BRACKET RH EV	TATA spare parts
553331407163	COBRABRACKETRH EV	TATA spare parts
553331407164	COBRABRACKETLH EV	TATA spare parts
553331500101	TOWING HOOK	TATA spare parts
553331540101	BRACKET ASSY EV	TATA spare parts
553331540102	BATTERY CARRIER & PLATFORM ASSYEV	TATA spare parts
553331700105	ASSEMBLY BOX OUTRIGGER 1	TATA spare parts
553331700106	ASSEMBLY BOX OUTRIGGER 2	TATA spare parts
553331700107	ASSEMBLY BOX OUTRIGGER 3	TATA spare parts
553331700108	OUTRIGGER ASSY 4 RH	TATA spare parts
553331700109	OUTRIGGER ASSY 4 LH	TATA spare parts
553331700144	CROSSMEMBERASSYWITHSUPPORT EV	TATA spare parts
553331700146	BRACKET ASSY FRONT CRASH	TATA spare parts
553332100103	FRONT SPRING ASSY	TATA spare parts
553332100104	FIRST LEAF ASSY WITH BUSH	TATA spare parts
553332100127	FRONT AIR SPRING BELLOW WITH TOP PLATE	TATA spare parts
553332100129	FRONT SPRING ASSY	TATA spare parts
553332100134	1ST LEAF ASSY WITH CLIP	TATA spare parts
553332100145	AIR SPRING ASSY FRONT	TATA spare parts
553332100158	PARABOLIC LEAF SPRING ASSY FRONT	TATA spare parts
553332100181	CLIP	TATA spare parts
553332103201	CENTRE BOLT	TATA spare parts
553332103202	HEX BOLT M8X1.25	TATA spare parts
553332103206	HEX BOLTS	TATA spare parts
553332103207	CENTER BOLT	TATA spare parts
553332103214	HEX BOLT	TATA spare parts
553332103307	BRACKET FRONT AIR BELLOW MTG RH	TATA spare parts
553332103308	BRACKET FRONT AIR BELLOW MTG LH	TATA spare parts
553332103309	BRACKET ANTI ROLL BAR MTG LOWER-RH	TATA spare parts

553332103310	BRACKET ANTI ROLL BAR MTG LOWER-LH	TATA spare parts
553332103311	BRACKET ANTI ROLL BAR MTG	TATA spare parts
553332104201	CLAMP 25X6	TATA spare parts
553332106501	CENTRE BOLT NUT M12X1.75	TATA spare parts
553332106502	HEX BOLT NUT M8X1.25	TATA spare parts
553332106601	PISTON EV	TATA spare parts
553332106902	SPACER TUBE FERRULE	TATA spare parts
553332107106	SECOND LEAF	TATA spare parts
553332107107	THIRD LEAF	TATA spare parts
553332107108	FORTH LEAF	TATA spare parts
553332107140	PACKING PLATE -70X23X130	TATA spare parts
553332107143	CASTER PLATE	TATA spare parts
553332107147	LEAF&SPRING&WRAPPER	TATA spare parts
553332107167	BRACKET LEVELLINGVALVEMTG	TATA spare parts
553332107168	BRACKET CONNECTINGLINKASSY	TATA spare parts
553332107172	PACKING PLATE	TATA spare parts
553332107179	TOP PLATE EV	TATA spare parts
553332107183	BRACKET LEVELLING VALVE MTG	TATA spare parts
553332107401	RIVET	TATA spare parts
553332107406	RIVET	TATA spare parts
553332107407	RIVET	TATA spare parts
553332107701	BELLOW	TATA spare parts
553332108301	CENTRE PAD 60X130X3	TATA spare parts
553332108401	SHIM TUBE DIA9XDIA12	TATA spare parts
553332200101	CLAMP PLATE ASSY.-(FOR U BOLT MTG.)	TATA spare parts
553332200102	BRACKET ASSY BUMP STOPPER	TATA spare parts
553332204201	U-BOLT	TATA spare parts
553332204202	U-BOLT	TATA spare parts
553332204203	U-BOLT	TATA spare parts
553332206501	HEX NUT WITH COLLAR M18 X 1.5	TATA spare parts
553332207101	CASTER PLATE	TATA spare parts
553332300101	BRACKET ASSY SHOCK ABSORBER MTG	TATA spare parts
553332300104	SHOCK ABSORBER ASSY FRONT	TATA spare parts
553332300106	BRACKET ASSY SHOCK ABSORBER MTG RH	TATA spare parts
553332300107	BRACKET ASSY SHOCK ABSORBER MTG LH	TATA spare parts
553332300111	BONDED BUSH ASSY (TOP SIDE)	TATA spare parts
553332300112	BONDED BUSH ASSY (BOTTOM SIDE)	TATA spare parts
553332400104	SHACKLE ASSY REAR	TATA spare parts
553332400105	REAR SPRING ASSY	TATA spare parts
553332400106	FIRST LEAF ASSY WITH BUSH	TATA spare parts
553332400115	LEAF SPRING ASSY WITH BUSH	TATA spare parts
553332400134	KIT-REARSUSPENSIONASSY	TATA spare parts
553332400141	PANHARD&ROD&ASSY&TVTR&ASSEMBLY.900MM	TATA spare parts
553332400143	AIR SPRING ASSY,REAR	TATA spare parts
553332400148	CHANNEL CROSS&MEMBER&CROSS&CHANNEL&AS	TATA spare parts
553332400156	BRACKETASSY LEVELLINGVALVEMTG	TATA spare parts
553332400163	AIR TANK ASSY WITH BRACKET	TATA spare parts

553332400164	CASTER PLATE ASSY WITH PIN	TATA spare parts
553332400166	LEAFSPRINGASSY REAR	TATA spare parts
553332400183	BRACKET ASSY LEVELLING VALVE MTG	TATA spare parts
553332403001	WASHER REBOUND&STOPPER	TATA spare parts
553332403201	CENTRE BOLT N12X1.75	TATA spare parts
553332403202	CENTRE BOLT M12X1.75	TATA spare parts
553332403203	HEX BOLT EV	TATA spare parts
553332403204	HEX&FLANGE&BOLT&M16&X&2	TATA spare parts
553332403209	HEX&FLANGE&BOLT	TATA spare parts
553332403211	HEX FLANGE BOLT	TATA spare parts
553332403212	HEX&BOLT SPRING&CLIP REAR	TATA spare parts
553332403214	CAP SCREW M10X1.5-45 LONG FLAT HEAD SOCK	TATA spare parts
553332403701	SPRING HANGER BRACKET REAR -(RWD)	TATA spare parts
553332403702	BRACKET SPRING HANGER. REAR-FWD	TATA spare parts
553332403715	BRACKET PANHARD&MTG UPPER&-	TATA spare parts
553332403719	BRACKETREARSPRINGHANGER EV	TATA spare parts
553332404201	CLAMP 25X6	TATA spare parts
553332404203	SPRING CLIP	TATA spare parts
553332404204	U-BOLT	TATA spare parts
553332406504	HEX&FLANGE&NUT	TATA spare parts
553332406505	HEX&FLANGE&NUT	TATA spare parts
553332406511	FLANGE NUT M10X1.5 PREVAILING TORQUE FLG	TATA spare parts
553332407105	SHACKLE PLATE	TATA spare parts
553332407108	SECOND LEAF	TATA spare parts
553332407109	THIRD LEAF	TATA spare parts
553332407110	FORTH LEAF	TATA spare parts
553332407111	SPACER (LEAF SPRING ASSY.)	TATA spare parts
553332407166	2ND LEAF	TATA spare parts
553332407167	LINER REAR&LEAF&SPRING	TATA spare parts
553332407170	CENTER&LINER	TATA spare parts
553332407178	BRACKET	TATA spare parts
553332407401	RIVET DIA10 BS6	TATA spare parts
553332407501	GROMMET	TATA spare parts
553332407702	TIP INSERT	TATA spare parts
553332407704	TIP INSERT BS6	TATA spare parts
553332407705	TIP INSERT BS6	TATA spare parts
553332407706	TIP INSERT BS6	TATA spare parts
553332408301	CENTRE PAD 60X150X3	TATA spare parts
553332408305	SHIM	TATA spare parts
553332408601	SPACER TUBE REAR SPRING	TATA spare parts
553332500103	REAR AXLE STOPPER ASSY	TATA spare parts
553332503701	GUIDE PLATE ( REAR )	TATA spare parts
553332504201	U-BOLT	TATA spare parts
553332504202	U-BOLT	TATA spare parts
553332506501	HEX NUT WITH COLLAR M20 X 1.5	TATA spare parts
553332600113	BONDED BUSH ASSY ( TOP SIDE)	TATA spare parts
553332800101	ANTI ROLL BAR ASSY COMP FRONT	TATA spare parts

553332800102	CONNECTING LINK ASSY (FRONT)	TATA spare parts
553332800103	RUBBER BUSH ASSY	TATA spare parts
553332800125	CONNECTING LINK ASSY FRONT	TATA spare parts
553332800128	ANTI ROLL BAR ASSY FRONT	TATA spare parts
553332803704	BRACKET ANTI ROLL BAR MTG BS6	TATA spare parts
553332806001	CONNECTING LINK	TATA spare parts
553332806004	CONNECTING LINK	TATA spare parts
553332807701	RUBBERBUSH ANTIROLLBAR	TATA spare parts
553332808402	TUBE	TATA spare parts
553332900101	ANTI ROLL BAR ASSY COMP REAR	TATA spare parts
553332900102	CONNECTING LINK ASSY (REAR)	TATA spare parts
553332900103	BRACKET ASSY ANTI ROLL BAR MTG REAR-RH B	TATA spare parts
553332900104	BRACKET ASSY ANTI ROLL BAR MTG REAR-LH B	TATA spare parts
553332900106	ANTI ROLL BAR ASSY WITH EYE PIECE BS6	TATA spare parts
553332903701	BRACKET (ANTI ROLL BAR ASSY.MTG.)	TATA spare parts
553332906001	CONNECTING LINK (ARB SUPPORT)	TATA spare parts
553332996001	CONNECTING ROD	TATA spare parts
553333000103	ASSY FRONT AXLE Y1-9.6T (BUS)	TATA spare parts
553333000104	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
553333000107	FRONTAXLEASSYWITHBRAKEABS	TATA spare parts
553333105102	FRONT AXLE BEAM (NORMAL)	TATA spare parts
553333200101	STUB AXLE ASSY	TATA spare parts
553333200102	STUB AXLE ASSY	TATA spare parts
553333400101	FRONT HUB ASSY WITH BEARING ABS	TATA spare parts
553333400102	FRONT HUB ASSY WITH PINS EV	TATA spare parts
553333403101	TAPER ROLLER BEARING	TATA spare parts
553333405501	FRONT HUB	TATA spare parts
553333408201	COVER FRONT HUB	TATA spare parts
553333408601	SEAL RACE	TATA spare parts
553333800101	TIE ROD ASSY	TATA spare parts
553333800102	TIE ROD END ASSLY	TATA spare parts
553333805102	STEERINGARM	TATA spare parts
553340109901	TUBELESS TYRE	TATA spare parts
553341110110	COUPLING SHAFT ASSY	TATA spare parts
553341110114	FRONT PROPELLER SHAFT	TATA spare parts
553341110121	PROPELLER&SHAFT&ASSY&WITH&CB FRONT	TATA spare parts
553341110124	PROPELLER SHAFT ASSY COUPLING	TATA spare parts
553341120108	PROPELLER SHAFT ASSY REAR	TATA spare parts
553341120113	ASSY DRIVE PROPELLER SHAFT	TATA spare parts
553341120117	PROPELLER&SHAFT&ASSY DRIVE	TATA spare parts
553341120120	REAR AXLE ASSY WITH HUB	TATA spare parts
553341300101	BRACKETASSY CENTERBRGMTG	TATA spare parts
553341300102	BRACKET ASSY CENTER BRG MTG	TATA spare parts
553341307103	SUPPORTPLATE CENTERBRGBKT	TATA spare parts
553341308204	BRACKET CENTER BRG MTG	TATA spare parts
553341308206	BRACKET ASSY CENTRE BEARING MTG	TATA spare parts
553341308207	PROPELLER SHAFT GUARD 9.6T & 7.5T	TATA spare parts



553341990101	CROSS ASSEMBLY	TATA spare parts
553341990102	CENTER BEARING ASSEMBLY	TATA spare parts
553341990103	COMPANION FLANGE	TATA spare parts
553341990105	SLIP YOKE ASSEMBLY	TATA spare parts
553341990111	SHORT FORK TUBE & FRONT END PIECE ASSY	TATA spare parts
553341990112	SHORT FORK TUBE & REAR END PIECE ASSY	TATA spare parts
553342100101	BRAKECHAMBER	TATA spare parts
553342100102	CALIPER ASSY DISC BRAKE LH	TATA spare parts
553342100103	CALIPER ASSY DISC BRAKE RH	TATA spare parts
553342100103C	CALIPER ASSY DISC BRAKE RHCORE	TATA spare parts
553342103201	HEX BOLT M14X1.5X45	TATA spare parts
553342103202	HEX BOLT M14X1.5X150	TATA spare parts
553342103203	BOLT	TATA spare parts
553342103204	HEX BOLT M14X1.5X97	TATA spare parts
553342103205	BOLT	TATA spare parts
553342103206	BOLT	TATA spare parts
553342103701	ROTOR DISC BRAKE	TATA spare parts
553342103702	ADAPTER PLATE LH	TATA spare parts
553342103703	ADAPTER PLATE RH	TATA spare parts
553342108201	DUSTCOVERBRAKEDISCLH	TATA spare parts
553342108202	DUSTCOVERBRAKEDISCRH	TATA spare parts
553342903301	BRACKET (FRONT HOSE MTG) RH	TATA spare parts
553342903302	BRACKET (FRONT HOSE MTG) LH	TATA spare parts
553342990102	KIT BUSH-ADB PAN17	TATA spare parts
553342990103	KIT BRAKE PAD-ADB PAN17	TATA spare parts
553342990104	KIT RUBBER BOOT-ADB PAN17	TATA spare parts
553342990105	KIT SLIDER ASSY- ADB PAN17	TATA spare parts
553343200101	AIR TANK ASSY COMP LH 15 LIT	TATA spare parts
553343200116	BASE PLATE	TATA spare parts
553343200121	BRACKETASSY AUX.DRIVERH	TATA spare parts
553343200122	BRACKET ASSY BELT TENSION EV	TATA spare parts
553343200123	BRACKETASSY AUX.DRIVELH	TATA spare parts
553343200126	AIRTANKASSY	TATA spare parts
553343200128	AIRTANKASSY(15LTR)	TATA spare parts
553343200129	AIR TANK ASSY	TATA spare parts
553343200130	BASE SUPPORT	TATA spare parts
553343200131	BASE PLATE FOR AUX DRIVE EV	TATA spare parts
553343200132	AIR TANK ASSY W/O BKT	TATA spare parts
553343200135	BRACKET ASSY AUX DRIVE UNIT EV	TATA spare parts
553343203316	BRACKET (AIR TANK MTG.) EV	TATA spare parts
553343203317	BRACKET (AIR TANK MTG.) EV	TATA spare parts
553343207103	BRACKET CLUTCH STATOR EV	TATA spare parts
553343207701	COVER FOR FILTER EV	TATA spare parts
553343700101	BRACKET APDA MTG	TATA spare parts
553343700102	AIR PROCESSING & DISTRIBUTION UNIT 8.6B	TATA spare parts
553343700104	SOLENOID VALVE 24V	TATA spare parts
553343700106	AIR COMPRESSOR ASSY	TATA spare parts

553343700107	AIR PROCESSING UNIT	TATA spare parts
553343700107C	AIR PROCESSING UNITCORE	TATA spare parts
553343700120	SPRING BRAKE ACTUATOR	TATA spare parts
553343700120C	SPRING BRAKE ACTUATORCORE	TATA spare parts
553343700123	BRACKETASSY APUMTG	TATA spare parts
553343700127	DISC BRAKE CHAMBER LH	TATA spare parts
553343700128	DISC BRAKE CHAMBER RH	TATA spare parts
553343700142	AUXDRIVEUNITASSY EV	TATA spare parts
553343700143	AIR COMPRESSOR ASSY EV	TATA spare parts
553343700144	AIR COMPRESSOR 3VX425 SUPER HC- V BELT E	TATA spare parts
553343700145	COVER ASSY AUX. DRIVE UNIT EV	TATA spare parts
553343700147	TEMPERATURE SENSOR EV	TATA spare parts
553343700148	L BRACKET EV	TATA spare parts
553343700149	NIPPLE EV	TATA spare parts
553343700150	NIPPLE EV	TATA spare parts
553343700151	BYPASS OUTLET PIPE EV	TATA spare parts
553343700152	SUPPORT AFTER COOLER EV	TATA spare parts
553343700153	COVER AFTER COOLER EV	TATA spare parts
553343700154	CHECK VALVE EV	TATA spare parts
553343700155	VALVE SAFETY EV	TATA spare parts
553343700156	PIPE ASSY EV	TATA spare parts
553343700157	AFTER COOLER AUX DRIVE UNIT EV	TATA spare parts
553343700158	HOSE ASSY EV	TATA spare parts
553343700164	DUST COVER AUX DRIVE	TATA spare parts
553343700169	DUST COVER UNIT RH SET	TATA spare parts
553343700170	DUST COVER UNIT LH SET	TATA spare parts
553343700196	BRACKET ASSY	TATA spare parts
553343700197	SUPPORT ASSY E-COMPRESSOR RH	TATA spare parts
553343700198	SUPPORT ASSY E-COMPRESSOR LH	TATA spare parts
553343700202	BRACKET ASSY AIR DRYER MTG	TATA spare parts
553343700203	BRACKET ASSY SPV MTG	TATA spare parts
553343700204	BRACKET ASSY PURGE TANK MTG	TATA spare parts
553343700219	SPRING BRAKE ACTUATOR TYPE 16/24 STROKE	TATA spare parts
553343700221	AIR DRYER ASSEMBLY	TATA spare parts
553343703301	BRACKET SOLENOID VALVE MTG	TATA spare parts
553343703302	BRACKET SOLENOID VALVE MTG	TATA spare parts
553343703305	BRACKET	TATA spare parts
553343703314	BRACKET SOLENOID VALVE MTG	TATA spare parts
553343703339	BRACKET	TATA spare parts
553343703371	BRACKET PRESSURE REDUCTION VALVE MTG	TATA spare parts
553343706801	PRESSURE SWITCH BLOCK	TATA spare parts
553343707501	RUBBER	TATA spare parts
553343708202	BRACKET RELAY VALVE	TATA spare parts
553343708207	BRACKET PRESSURE SWITCH BLOCK MTG	TATA spare parts
553343708208	BRACKET PRESSUREREDUCTIONVALVEMTGEV	TATA spare parts
553343710107	BRAKE MODULATOR UNIT REAR AXLE UNIT	TATA spare parts
553343710108	BRAKE MODULATOR UNIT FRONT AXLE UNIT	TATA spare parts

553343710112	BRACKET ASSY	TATA spare parts
553343710113	BASE PLATE WELDMENT ASSY	TATA spare parts
553343800101	PIPE ASSY AIR COMPRESSOR TO APDA	TATA spare parts
553343800102	PIPE ASSY AIR COMPRESSOR TO APDA	TATA spare parts
553343800103	METAL PIPE ASSY RST TO TEE	TATA spare parts
553343800104	METAL PIPE ASSY RST TO RELAY	TATA spare parts
553343800105	METAL PIPE ASSY DBV TO RELAY	TATA spare parts
553343800106	METAL PIPE ASSY RST TEE TO DDU	TATA spare parts
553343800107	METAL PIPE ASSY FST TO DDU	TATA spare parts
553343800108	METAL PIPE ASSY HBV TO RELAY	TATA spare parts
553343800109	METAL PIPE ASSY DBV TO RELAY	TATA spare parts
553343800110	METAL PIPE ASSY DDU 23 TEE TO RELAY	TATA spare parts
553343800111	METAL PIPE ASSY DDU 23 TEE TO HBV	TATA spare parts
553343800112	METAL PIPE ASSY AUX AIR TANK TO T-CON	TATA spare parts
553343800113	METAL PIPE ASSY FST TO DBV	TATA spare parts
553343800114	METAL PIPE ASSY COMP TO DDU	TATA spare parts
553343800115	METAL PIPE ASSY DBV TO RELAY	TATA spare parts
553343800116	METAL PIPE ASSY RST TEE TO DBV	TATA spare parts
553343800117	METAL PIPE ASSY QRV TO FRONT LH	TATA spare parts
553343800118	METAL PIPE ASSY QRV TO FRONT RH	TATA spare parts
553343800119	METAL PIPE ASSY RELAY VALVE TO RH	TATA spare parts
553343800120	METAL PIPE ASSY RELAY VALVE TO LH	TATA spare parts
553343800121	METAL PIPE ASSY DBV TO FST	TATA spare parts
553343800122	METAL PIPE ASSY DBV TO QRV	TATA spare parts
553343800123	METAL PIPE ASSY RELAY TO PARKING HOSE	TATA spare parts
553343800124	METAL PIPE REAR RELAY TO PARKING HOSE LH	TATA spare parts
553343800125	METAL PIPE ASSY RST TO DBV	TATA spare parts
553343800126	METAL PIPE ASSY HBV TO RELAY VALVE	TATA spare parts
553343800127	METAL PIPE ASSY HBV TO DDU TEE	TATA spare parts
553343800128	METAL PIPE RELAY VALVE TO HBV	TATA spare parts
553343800130	METAL PIPE ASSY DDU TO AUX TANK	TATA spare parts
553343800131	METAL PIPE ASSY TEE TO CLUTCH BOOSTER	TATA spare parts
553343800132	METAL PIPE COMP TO DDU	TATA spare parts
553343800133	PIPE ASSY WITH CRIMPED HOSE	TATA spare parts
553343800134	PIPE ASSY DDU 23 TO TEE	TATA spare parts
553343808203	BRACKET BRAKE PIPE MTG	TATA spare parts
553343808204	BRACKET BRAKE PIPE MTG	TATA spare parts
553343900126	NYLON PIPE BUNCH	TATA spare parts
553343900141	PIPE BUNCH ASSY	TATA spare parts
553343900168	PIPE BUNCH ASSY	TATA spare parts
553343900197	PIPE BUNCH ASSY	TATA spare parts
553343900275	NYLON PIPE ASSY 12 OD	TATA spare parts
553343900276	NYLON PIPE ASSY 8 OD	TATA spare parts
553343900277	2ND METAL PIPE ASSY (STAINLESS STEEL)	TATA spare parts
553343900278	3RD METAL PIPE ASSY (STAINLESS STEEL)	TATA spare parts
553343900280	PIPE ASSY 2ND METAL PIPE(18 OD)	TATA spare parts
553343900281	PIPE ASSY 3RD METAL PIPE(18 OD)	TATA spare parts

553343900282	PIPE ASSY EV	TATA spare parts
553343900284	PIPE ASSY 4TH METAL PIPE(18 OD)	TATA spare parts
553343900302	PIPEASSY1STMETALPIPE(18OD)	TATA spare parts
553343900303	PIPEASSY2NDMETALPIPE(18OD)	TATA spare parts
553343900304	PIPEASSY4THMETALPIPE(18OD)	TATA spare parts
553343900305	PIPEASSY5THMETALPIPE(18OD)	TATA spare parts
553343900306	PIPEASSY3RDMETALPIPE(18OD)	TATA spare parts
553343900307	PIPEASSY1STMETALPIPE(18OD) EV	TATA spare parts
553343900308	PIPEASSY2NDMETALPIPE(18OD) EV	TATA spare parts
553343900358	PIPE ASSY	TATA spare parts
553343900359	PIPE ASSY	TATA spare parts
553343900362	PIPE ASSY	TATA spare parts
553343900363	PIPE ASSY	TATA spare parts
553343900366	PIPE ASSY	TATA spare parts
553343900367	PIPE ASSY	TATA spare parts
553343900395	METAL PIPE ASSY	TATA spare parts
553343900396	METAL PIPE ASSY	TATA spare parts
553343901601	HOSE ASSY BRAKE REAR	TATA spare parts
553343903302	BRACKET-HOSE MTG BS6	TATA spare parts
553343906805	ADAPTER	TATA spare parts
553343906806	ADAPTER EV	TATA spare parts
553343907502	RUBBER GROMMET	TATA spare parts
553343910131	NYLON PIPE BUNCH ASSY	TATA spare parts
553343910206	NYLON PIPE BUNCH ASSY	TATA spare parts
553343910236	PIPE BUNCH ASSY	TATA spare parts
553343915804	AIRINTAKEHOSE AIRFILTERSIDE	TATA spare parts
553343920165	PIPE ASSY 5TH METAL PIPE(18 OD)	TATA spare parts
553343990108	AIR DRYER ASSY	TATA spare parts
553343990109	AIR CHOKE INDICATOR EV	TATA spare parts
553343990110	SPV BRACKET ASSY	TATA spare parts
553343990111	KIT-AIR DRYER WITH PURGE TANK & BKTS	TATA spare parts
553343990112	BRACKET ASSY	TATA spare parts
553343990118	RETRO KIT-CLUTCH BRACKET	TATA spare parts
553343993101	BEARING	TATA spare parts
553343998203	PIN	TATA spare parts
553346200101	ASSY GEARBOX MTG. BKT.	TATA spare parts
553346200102	ASSY POWER STRNG GEAR BOX & PITMAN ARM	TATA spare parts
553346200104	UNIVERSAL¿JOINT¿ASSY	TATA spare parts
553346207701	RUBBER BELLOW	TATA spare parts
553346208201	PLATE BELLOW	TATA spare parts
553346306001	PITMAN ARM	TATA spare parts
553346306004	PITMAN ARM	TATA spare parts
553346600107	POWER STEERING PUMP ASSY	TATA spare parts
553346600108	SHAFT ASSY	TATA spare parts
553346600109	HOUSING ASSY EV	TATA spare parts
553346600110	CARTRIDGE ASSY EV	TATA spare parts
553346600114	POWER STEERING PUMP ASSY	TATA spare parts

553346604601	JAW COUPLING - L100	TATA spare parts
553346608001	GRUB SCREW (M6X12)	TATA spare parts
553346608601	SPACER	TATA spare parts
553346700102	BRACKET ASSY POWER STEERING PUMP MTG	TATA spare parts
553346700105	COVER ASSY	TATA spare parts
553346700106	COVER LH	TATA spare parts
553346700107	SIDE COVER	TATA spare parts
553346700110	COVER ASSY	TATA spare parts
553346703301	BRACKET STG GEAR BOX MTG	TATA spare parts
553346703312	BRACKET PIPE SUPPORT	TATA spare parts
553346704705	COVER PLATE	TATA spare parts
553346707501	RUBBER BIDDING	TATA spare parts
553346707503	RUBBER BIDDING	TATA spare parts
553346707504	RUBBER BIDDING	TATA spare parts
553346708002	HEX SCREW	TATA spare parts
553346800106	SUCTION LINE ASSY	TATA spare parts
553346800107	HIGH PRESSURE LINE ASSY	TATA spare parts
553346800108	RETURN LINE ASSY	TATA spare parts
553346800116	RETURN LINE ASSY	TATA spare parts
553346800118	SUCTION LINE ASSY	TATA spare parts
553346800119	HIGH PRESSURE LINE ASSY	TATA spare parts
553346800129	HIGH PRESSURE LINE ASSY	TATA spare parts
553346800130	SUCTION LINE ASSY	TATA spare parts
553346800149	HIGHPRESSURELINEASSY	TATA spare parts
553346800150	SUCTION LINE ASSY	TATA spare parts
553346800151	RETURNLINEASSY	TATA spare parts
553346800152	SUCTION LINE ASSY EV	TATA spare parts
553346800153	SUCTIONLINEASSY EV	TATA spare parts
553346800158	HIGHPRESSURELINEASSY	TATA spare parts
553346803301	BRACKET PIPE SUPPORT	TATA spare parts
553346808201	BRKT-STRG PIPE MTG	TATA spare parts
553346808202	BRKT-STRG PIPE MTG	TATA spare parts
553346810103	SUCTION LINE ASSY	TATA spare parts
553346810104	SUCTION LINE ASSY	TATA spare parts
553346810105	PRESSURE LINE ASSY	TATA spare parts
553346810106	PRESSURE LINE ASSY	TATA spare parts
553346810107	PRESSURE LINE ASSY	TATA spare parts
553346810109	SUCTION LINE ASSY	TATA spare parts
553346810110	RETURN LINE ASSY	TATA spare parts
553346900101	DRAG LINK ASSY	TATA spare parts
553346900111	DRAG LINK ASSY BS6	TATA spare parts
553346900112	DRAG LINK ASSY	TATA spare parts
553346980101	KIT-POWER STEERING PUMP EV	TATA spare parts
553347100102	FUEL TANK ASSY COMPLETE 90LTR (SLF)	TATA spare parts
553347500101	ASSY. STRAP FOR TANK (SLF)	TATA spare parts
553347500102	ASSY BRKT HPR MTG	TATA spare parts
553347500103	BRACKET ASSY FOR FUEL TANK MTG	TATA spare parts

553347500104	BRACKET ASSY	TATA spare parts
553347500106	STRAP ASSY	TATA spare parts
553347506701	CLEVIS PIN 10F8X58X53.5TS17606SS:8451-11	TATA spare parts
553347507701	RUBBER PAD FOR STRAP (SLF)	TATA spare parts
553347507702	RUBBER PAD FOR TANK BKT (SLF)	TATA spare parts
553347507703	RUBBER	TATA spare parts
553347507704	RUBBER	TATA spare parts
553347530103	ASSY CONTROL PANEL	TATA spare parts
553347600118	BRACKET ASSY CLAMP MTG	TATA spare parts
553347600120	TUBE ASSY OD 22 X 2 THICK	TATA spare parts
553347600121	ASSY TUBE OD 22 X 2 THK	TATA spare parts
553347600135	CNG VENT PIPE 3	TATA spare parts
553347600142	CNG VENT PIPE 4	TATA spare parts
553347600143	CNG VENT PIPE HPR TO CNG VENT PIPE 1	TATA spare parts
553347600144	CNG VENT PIPE 1	TATA spare parts
553347600145	CNG VENT PIPE 2	TATA spare parts
553347600147	CNG VENT PIPE 5	TATA spare parts
553347600180	VENT PIPE ROOF END	TATA spare parts
553347600181	SUCTION PIPE ASSY TANK TO PRE FILT SEG-1	TATA spare parts
553347600182	SUCTION PIPE ASSY TANK TO PRE FILT SEG-2	TATA spare parts
553347600183	SUCTION PIPE ASSY PRE FILT TO FINAL FILT	TATA spare parts
553347600184	SUCTION PIPE ASSY FINAL FILT TO FIP	TATA spare parts
553347600185	RETURN PIPE ASSY ENGINE TO TANK SEG-2	TATA spare parts
553347600186	RETURN PIPE ASSY ENGINE TO TANK SEG-1	TATA spare parts
553347608210	BRACKET FOR FUEL LINE CLAMPING	TATA spare parts
553347704901	SUCTION UNIT	TATA spare parts
553347980101	KIT-FUEL PIPE ASSY	TATA spare parts
553349100101	ASSY. SILENCER FOR 497 BSIV 650 FESLF	TATA spare parts
553349100102	ASSEMBLY BRACKET	TATA spare parts
553349100103	SILENCER ASSEMBLY	TATA spare parts
553349100104	ASSEMBLY BRACKET FOR CATCON MTG.	TATA spare parts
553349100105	ASSY. L-BRACKET	TATA spare parts
553349100106	ASSY. SUPPORT BKT FOR SILENCER MTG.	TATA spare parts
553349100107	BRACKET ASSY L-TYPE	TATA spare parts
553349100108	ASSY MTG BRACKET	TATA spare parts
553349100109	ASSY SILENCER (CIRCULAR) WITH CLAMPS	TATA spare parts
553349100110	ASSY HANGER BRACKET	TATA spare parts
553349103311	BRACKET FOR DPS SENSOR MTG.	TATA spare parts
553349107702	PIPE HOSE INTERMEDIATE	TATA spare parts
553349200101	ASSEMBLY FRONT PIPE	TATA spare parts
553349200102	ASSY. INTERMEDIATE PIPE	TATA spare parts
553349200103	PIPE ASSY INTERMEDIATE	TATA spare parts
553349200109	ASSY HEAT SHIELD FOR CATCON	TATA spare parts
553349200112	PIPE ASSY METAL DOWNSTREAM-2	TATA spare parts
553349200113	PIPE ASSY METAL UPSTREAM-2	TATA spare parts
553349200114	EXHAUST PIPE ASSY FLEX BELLOW FRONT	TATA spare parts
553349200115	EXHAUST PIPE ASSY INTERMEDIATE	TATA spare parts

553349209902	HEAT SHIELD BEND 2	TATA spare parts
553349209903	HEAT SHIELD BEND 3	TATA spare parts
553349209904	HEAT SHIELD BEND 4	TATA spare parts
553349209905	HEAT SHIELD BEND 1	TATA spare parts
553349209908	HEAT SHIELD BEND 1	TATA spare parts
553349209909	HEAT SHIELD BEND 2	TATA spare parts
553349209910	HEAT SHIELD BEND 3	TATA spare parts
553354100108	ASSY 650FH LP BATTERY CARRIER 24V	TATA spare parts
553354100110	COVERBATTERY	TATA spare parts
553354190116	WIRING HARNESS BATTERY MEGAFUSE O/P TO S	TATA spare parts
553354190117	W/H BATTERY MEGAFUSE O/P TO STARTER	TATA spare parts
553354190118	WIRING HARNESS BATTERY -VE TO STARTER -V	TATA spare parts
553354190119	WIRING HARNESS BATTERY CABLE +VE TO M BD	TATA spare parts
553354190120	W/H BATTERY CABLE +VE TO M BDS I/P	TATA spare parts
553354190121	WIRING HARNESS BATTERY CABLE M BDS O/P T	TATA spare parts
553354190122	W/H BATTERY CABLE M BDS O/P TO E BDS I/P	TATA spare parts
553354190123	W/H BATTERY -VE TO STARTER -VE	TATA spare parts
553354190124	WIRING HARNESS BATTERY CABLE +VE TO MEGA	TATA spare parts
553354190125	W/H BATTERY CABLE +VE TO MEGAFUSE I/P	TATA spare parts
553354190126	W/H BATTERY MEGA FUSE O/P TO STARTER +VE	TATA spare parts
553354190128	W/H BATTERY CABLE -VE TO STARTER -VE	TATA spare parts
553354190130	W/H BATTERY CABLE MBDS O/P TO EBDS I/P	TATA spare parts
553354190132	W/H BATTERY CABLE +VE TO MEGA FUSE I/P	TATA spare parts
553354190134	W/H BATTERY CABLE +VE TO MBDS I/P	TATA spare parts
553354190136	WIRING HARNESS BATTERY MEGAFUSE O/P TO A	TATA spare parts
553354200105	ASSY BRACKET FOR MAXI FUSE MTG	TATA spare parts
553354200108	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
553354200111	INSTRUMENT CLUSTER ASSY	TATA spare parts
553354300104	BRACKET ASSY BEEPER MTG EV	TATA spare parts
553354300105	BRACKET ASSY HORN MTG	TATA spare parts
553354400107	BRACKET ASSY ENGINE LAMP MTG	TATA spare parts
553354401601	WATER IN FUEL INDICATOR	TATA spare parts
553354500107	MEGA FUSE BOX ASSY 4P W/O COVER	TATA spare parts
553354500108	BRACKET ASSY MAXI FUSE & CUT OFF S/W MTG	TATA spare parts
553354500110	BRACKET ASSY FUSE BOX MTG	TATA spare parts
553354500113	BRACKET ASSY MAXI FUSE W/H MTG	TATA spare parts
553354500116	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
553354500117	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
553354500118	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
553354500120	BRACKET ASSY BATTERY CUT OFF SWITCH MTG	TATA spare parts
553354504903	ELECTRICAL BATTERY CUT OFF SWITCH	TATA spare parts
553354504904	SWITCH DISABLE PERSON	TATA spare parts
553354504905	SWITCH HEAD LAMP ROTARY	TATA spare parts
553354506302	FUSE BOX COVER	TATA spare parts
553354506308	FUSE BOX FRAME	TATA spare parts
553354506311	FUSE BOX COVER	TATA spare parts
553354506312	FUSEEXTRACTOR BS6	TATA spare parts

553354506314	FUSE BOX COVER	TATA spare parts
553354506315	CARRIER PLATE FASCIA SWITCH EV	TATA spare parts
553354600117	ASSY BRACKET FOR WH MTG ON FRAME	TATA spare parts
553354600118	ASSY BRACKET FOR CBCU MTG	TATA spare parts
553354600120	ASSY BKT BATTERY CABLE	TATA spare parts
553354600122	ASSY BRACKET IP TO CHASSIS INLINE	TATA spare parts
553354600132	ASSY BKT ENGINE INLINE MTG FOR 497 LF	TATA spare parts
553354600133	ASSY BRACKET CNG GAS SENSOR	TATA spare parts
553354600154	WIRING HARNESS ENGINE	TATA spare parts
553354600155	KIT WIRING HARNESS (MIDI)	TATA spare parts
553354600156	KIT WIRING HARNESS (MINI)	TATA spare parts
553354600173	BRACKET&I/C&CONNECTOR&MTG	TATA spare parts
553354600180	WIRING HARNESS CHASSIS	TATA spare parts
553354600181	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
553354600182	WIRING HARNESS SWITCH	TATA spare parts
553354600185	WIRING HARNESS ABS FRAME	TATA spare parts
553354600188	WIRING HARNESS FRONT CAN	TATA spare parts
553354600189	WIRING HARNESS MAXI FUSE	TATA spare parts
553354600192	WIRING HARNESS REAR CAN BS4	TATA spare parts
553354600201	PIG TAIL FOR EXISTING VEHICLES	TATA spare parts
553354601649	W/H MAXI FUSE	TATA spare parts
553354603307	BRACKET WIRING HARNESS MTG BS6	TATA spare parts
553354603308	BRACKET	TATA spare parts
553354603310	BRACKET EV	TATA spare parts
553354603313	BRACKET BATTERY CABLE CLAMP MTG	TATA spare parts
553354608204	BRACKET FOR CLIP MOUNTING ON FES BS6	TATA spare parts
553354608207	BRACKET FOR SENSOR WH MTG FOR LF BUS	TATA spare parts
553354608217	ENG INLINE MTG BKT FOR 497 LF BUS BS6-PH	TATA spare parts
553354608218	BRACKET EMS HARNESS SUPPORT 3.8 SGI TCIC	TATA spare parts
553354608219	BRACKET LAMBDA SENSOR MTG 3.8 SGI TCIC	TATA spare parts
553354609912	HARNESS BDC	TATA spare parts
553354609946	STICKER FUSE - RELAY BOX EV	TATA spare parts
553354609950	RESISTOR ASSY	TATA spare parts
553354610115	WIRING HARNESS CHASSIS	TATA spare parts
553354610116	PIGTAIL ALTERNATOR +VE	TATA spare parts
553354610117	WIRING HARNESS ABS FRAME 4S3M	TATA spare parts
553354610118	WIRING HARNESS ENGINE	TATA spare parts
553354610119	PIGTAILALTERNATOR +VE	TATA spare parts
553354610120	WIRING HARNESS INSTRUMENT PANEL	TATA spare parts
553354610123	WIRING HARNESS FRONT CAN	TATA spare parts
553354610124	WIRING HARNESS SWITCH	TATA spare parts
553354610177	CABLE&MECH&CUT&OFF&O/P&TO&ELEC&CUT&OFF	TATA spare parts
553354613301	BRACKET INTERFACE CONNECTOR MTG	TATA spare parts
553354620103	WIRINGHARNESSM-CAN	TATA spare parts
553354620104	WIRING HARNESS ENGINE	TATA spare parts
553354620105	WIRING HARNESS FES	TATA spare parts
553354620107	WIRING HARNESS CHASSIS	TATA spare parts



553354620108	WIRING HARNESS MAXI FUSE	TATA spare parts
553354620111	W/H FRONT CHASSIS	TATA spare parts
553354620114	W/H SWITCH	TATA spare parts
553354620121	W/H CAN 497 TCIC LP 650FH CNG	TATA spare parts
553354620122	WIRING HARNESS MAXI FUSEBOX CABLE 497 TC	TATA spare parts
553354620123	WIRINGHARNESSE-CANREAR	TATA spare parts
553354620136	W/H SWITCH	TATA spare parts
553354620137	FRONT CAN WH	TATA spare parts
553354620139	PIGTAIL FOR LOV VALVE ON ROOF	TATA spare parts
553354620140	W/H EMS	TATA spare parts
553354620142	W/H INSTRUMENT PANEL	TATA spare parts
553354620143	W/H CHASSIS	TATA spare parts
553354620145	W/H HEAD LAMP LH WITH CBCU	TATA spare parts
553354620146	W/H IP MULTIPLEXING	TATA spare parts
553354620147	W/H EMS	TATA spare parts
553354620149	WIRING HARNESS CHASSIS	TATA spare parts
553354620155	W/H INSTRUMENT PANEL	TATA spare parts
553354620156	WIRING HARNESS MAXI FUSE	TATA spare parts
553354620157	WIRING HARNESS IP	TATA spare parts
553354620158	WIRING HARNESS CHASSIS	TATA spare parts
553354620162	WIRING HARNESS ENGINE	TATA spare parts
553354620163	WIRING HARNESS INSTR. PANEL BS4	TATA spare parts
553354620165	WIRING HARNESS CHASSIS	TATA spare parts
553354620166	WIRING HARNESS CHASSIS	TATA spare parts
553354620171	WIRINGHARNESSE-CANREAR	TATA spare parts
553354620173	BATTERY CABLE SHORT LINK	TATA spare parts
553354620174	WIRINGHARNESSE-CANFRONT	TATA spare parts
553354620177	WIRINGHARNESSE-CANFRONT	TATA spare parts
553354620179	WIRINGHARNESSE-FES	TATA spare parts
553354620186	WIRING HARNESS ABS	TATA spare parts
553354620188	FUSE¿BASE¿SUPPORT	TATA spare parts
553354620189	PIGTAIL - ULTRA MULTIPLEXING	TATA spare parts
553354620190	WIRINGHARNESSTAIL	TATA spare parts
553354620194	WIRINGHARNESSECONTROL	TATA spare parts
553354620195	WIRINGHARNESSE-ROOF	TATA spare parts
553354630103	CABLE¿ELEC¿CUT¿OFF¿SW¿O/P¿TO¿DC-DC¿-VE	TATA spare parts
553354630104	CABLE¿BATTERY¿+VE¿TO¿BATTERY¿CUT¿OFF¿SW	TATA spare parts
553354630105	CABLE¿BATTERY¿-VE¿TO¿CHASSIS	TATA spare parts
553354630106	CABLE¿ELEC¿CUT¿OFF¿SW¿O/P¿TO¿DC-DC¿+VE	TATA spare parts
553354630107	WIRINGHARNESSEMAXIFUSE	TATA spare parts
553354630111	WIRING HARNESS HEADLAMP	TATA spare parts
553354630122	CABLE BATTERY +VE TO BATTERY CUT OFF SW	TATA spare parts
553354630124	CABLE MECH CUT OFF O/P TO ELEC CUT OFF I	TATA spare parts
553354630126	CABLE BATTERY LINK EV	TATA spare parts
553354630127	WIRING HARNESS CONTROL EV	TATA spare parts
553354630128	WIRING HARNESS FES EV	TATA spare parts
553354630129	WIRING HARNESS ROOF EV	TATA spare parts

553354630130	WIRING HARNESS P-CAN FRONT EV	TATA spare parts
553354630131	WIRING HARNESS E-CAN REAR EV	TATA spare parts
553354630133	WIRING HARNESS ABS EV	TATA spare parts
553354630134	WIRING HARNESS MAXI FUSE EV	TATA spare parts
553354630136	WIRING HARNESS REVERSE PARK ASSIST EV	TATA spare parts
553354630138	WIRING HARNESS TAIL EV	TATA spare parts
553354630168	WIRING HARNESS FES	TATA spare parts
553354630169	WIRING HARNESS SWITCH	TATA spare parts
553354630170	CABLE BATTERY +VE TO BATTERY CUT OFF SW	TATA spare parts
553354630171	CABLE BATTERY -VE TO CHASSIS	TATA spare parts
553354630172	CABLE BATTERY LINK	TATA spare parts
553354630173	WIRING HARNESS EV CAN FRONT	TATA spare parts
553354630174	WIRING HARNESS CONTROL	TATA spare parts
553354630176	WIRING HARNESS TAIL	TATA spare parts
553354630177	WIRING HARNESS MAXI FUSE	TATA spare parts
553354630178	WIRING HARNESS CHASSIS CAN REAR	TATA spare parts
553354630179	WIRING HARNESS ROOF	TATA spare parts
553354630182	WIRING HARNESS	TATA spare parts
553354630183	BRACKET OBD MTG	TATA spare parts
553354630184	PIGTAIL HORN	TATA spare parts
553354630187	CABLE ELEC CUT OFF SW O/P TO DC-DC +VE	TATA spare parts
553354630188	BRACKET ASSY MEGA FUSE	TATA spare parts
553354630189	BRACKET FUSE AND RELAY BOX MTG	TATA spare parts
553354630190	WIRING HARNESS HEADLAMP	TATA spare parts
553354650101	BATTERY CABLE -VE	TATA spare parts
553354650102	WIRING HARNESS REVERSE PARK ASSIST	TATA spare parts
553354650105	CABLE MECH CUT OFF TO ELEC CUT OFF SW I/	TATA spare parts
553354700101	ECU	TATA spare parts
553354700101C	ECU VEHICLE TRACKING ASSYCORE	TATA spare parts
553354700102	BRACKET ASSY YAW RATE SENSOR MTG	TATA spare parts
553354700104	BRACKET ASSY VECU MTG	TATA spare parts
553354709903	ECU VEHICLE CONTROLLER	TATA spare parts
553354709903C	ECU VEHICLE CONTROLLERCORE	TATA spare parts
553354903302	BRACKET BS6-PH2	TATA spare parts
553358900701	ADAPTER	TATA spare parts
553360000101	ASSY.STR.WELD.COMP DIESEL ULTRA MIDI 6/9	TATA spare parts
553360000116	FES ASSY WITH FITMENT	TATA spare parts
553360100102	FES ASSY	TATA spare parts
553360100113	DRIVER STATION ASSY WITH FITMENT	TATA spare parts
553368706301	INSULATION	TATA spare parts
553368706302	INSULATION	TATA spare parts
553368706303	INSULATION	TATA spare parts
553368706304	INSULATION	TATA spare parts
553368706305	INSULATION	TATA spare parts
553368706306	INSULATION	TATA spare parts
553368706307	INSULATION	TATA spare parts
553368706308	INSULATION	TATA spare parts

553368706309	INSULATION	TATA spare parts
553368706310	INSULATION	TATA spare parts
553368706311	INSULATION	TATA spare parts
553368706312	INSULATION	TATA spare parts
553368706313	INSULATION	TATA spare parts
553368706314	INSULATION	TATA spare parts
553368706315	INSULATION	TATA spare parts
553368706316	INSULATION	TATA spare parts
553368706317	INSULATION	TATA spare parts
553368706318	INSULATION	TATA spare parts
553368706319	INSULATION	TATA spare parts
553368706320	INSULATION	TATA spare parts
553368706321	INSULATION	TATA spare parts
553368706322	INSULATION	TATA spare parts
553368706325	INSULATION	TATA spare parts
553368706326	INSULATION	TATA spare parts
553380100199	CABLE HV BAT LOOP CABLE	TATA spare parts
553380103305	SUPPORT BRACKET BACK	TATA spare parts
553380103311	L-BRACKET CABLE SUPPORT	TATA spare parts
553380103313	L-BRACKETCABLESUPPORT	TATA spare parts
553380103322	L-BRACKET CABLE SUPPORT EV	TATA spare parts
553380103348	L-BRACKET CABLE SUPPORT	TATA spare parts
553380110109	CABLE HV INV TO HV JUNCTION BOX	TATA spare parts
553380110110	CABLE GND BCS TO ROOF STR GND	TATA spare parts
553380110112	CABLE HV SIGNAL INVERTER TO MOTOR	TATA spare parts
553380110113	CABLE HV AUX INV TO HV JB ETS	TATA spare parts
553380110119	CABLE GND HV AUX DRIVE TO CHASSIS GND	TATA spare parts
553380110120	CABLE HV JB BAT TO HVAC UNIT	TATA spare parts
553380110121	CABLE HV GND DC JB BAT TO ROOF STR GND	TATA spare parts
553380110122	CABLE HV BAT LOOP CABLE	TATA spare parts
553380110123	CABLE GND HV BATT-1 TO ROOF STR GND	TATA spare parts
553380110124	CABLE GND HV BATT-2 TO ROOF STR GND	TATA spare parts
553380110125	CABLE HV BAT-1 TO BAT-2	TATA spare parts
553380110127	CABLE HV BATTERY TO HV JUNCTION BOX	TATA spare parts
553380110129	CABLE GND HVAC TO ROOF STR GND	TATA spare parts
553380110131	CABLE HV JB BAT TO BCS	TATA spare parts
553380110134	CABLE HV DC JB ETS TO HV DC JB BAT	TATA spare parts
553380110137	CABLE HV INV TO HV JUNCTION BOX	TATA spare parts
553380110140	CABLE HV MOTOR INVERTER-4 TO MOTOR-C1	TATA spare parts
553380110141	CABLE HV MOTOR INVERTER-3 TO MOTOR-A2	TATA spare parts
553380110142	CABLE HV MOTOR INVERTER-2 TO MOTOR-B2	TATA spare parts
553380110143	CABLE HV MOTOR INVERTER-1 TO MOTOR-C2	TATA spare parts
553380110144	CABLE HV SIGNAL INVERTER TO MOTOR	TATA spare parts
553380110145	CABLE HV AUX INV TO HV JB ETS	TATA spare parts
553380110146	CABLE HV AUX INV TO AUX DRIVE MOTOR	TATA spare parts
553380110147	CABLE HV JB ETS TO GBT CHARGER	TATA spare parts
553380110151	CABLE HV GND DC JB ETS TO CHASSIS GND	TATA spare parts

553380110154	CABLE HV GND INVERTER TO CHASSIS GND	TATA spare parts
553380110155	CABLE HV GND MOTOR TO CHASSIS GND	TATA spare parts
553380110156	CABLE HV GND AUX INV TO CHASSIS GND	TATA spare parts
553380110162	CABLE HV MOTOR INVERTER-6 TO MOTOR-A1	TATA spare parts
553380110163	CABLE HV MOTOR INVERTER-5 TO MOTOR-B1	TATA spare parts
553380110174	BRACKETASSYHVCABLESUPPORT	TATA spare parts
553380110175	CABLE HV GND INVERTER TO CHASSIS GND	TATA spare parts
553380110176	BRACKETASSYHVCABLESUPPORT	TATA spare parts
553380110177	BRACKET ASSY HV CABLE SUPPORT	TATA spare parts
553380110178	BRACKETASSYHVCABLESUPPORT	TATA spare parts
553380110179	WIRING HARNESS_DB9 SPLITTER	TATA spare parts
553380110180	WIRING HARNESS DIGNOSTICS PIGTAIL	TATA spare parts
553380110190	CABLE HV BATTERY TO HV JUNCTION BOX	TATA spare parts
553380110191	CABLE HV BATTERY TO HV JUNCTION BOX	TATA spare parts
553380110194	CABLE HV JB ETS TO GBT CHARGER EV	TATA spare parts
553380110196	CABLE HV JB BAT TO HVAC UNIT EV	TATA spare parts
553380110197	CABLE HV AUX INV TO AUX DRIVE MOTOR	TATA spare parts
553380120174	CABLE HV INV TO HV JUNCTION BOX	TATA spare parts
553380120175	CABLE HV MOTOR INVERTER-2 TO MOTOR-B2	TATA spare parts
553380120176	CABLE HV MOTOR INVERTER-3 TO MOTOR-A2	TATA spare parts
553380120177	CABLE HV MOTOR INVERTER-1 TO MOTOR-C2	TATA spare parts
553380120178	CABLE HV SIGNAL INVERTER TO MOTOR	TATA spare parts
553380120179	CABLE HV DC JB ETS TO HV DC JB BAT	TATA spare parts
553380120181	CABLE HV BATTERY JB ROOF TO HV BATT-2	TATA spare parts
553380120182	CABLE GND HV CHASSIS TO BUS BODY SHELL	TATA spare parts
553380120183	CABLE HV GND DC JB ETS TO CHASSIS GND	TATA spare parts
553380120184	CABLE HV GND INVERTER TO CHASSIS GND	TATA spare parts
553380120186	CABLE HV GND MOTOR TO CHASSIS GND	TATA spare parts
553380120188	CABLE HV GND AIR COMP TO CHASSIS GND	TATA spare parts
553380120189	CABLE HVGND STEERING PUMP TO CHASSIS GND	TATA spare parts
553380120190	CABLE HV GND DC JB BAT TO ROOF STR GND	TATA spare parts
553380120191	CABLE GND HV BATT-1 TO ROOF STR GND	TATA spare parts
553380120192	CABLE GND HV BATT-2 TO ROOF STR GND	TATA spare parts
553380120197	CABLE HV BATTERY JB ROOF TO HV BATT-1	TATA spare parts
553380130101	BRACKET ASSY HV CABLE SUPPORT	TATA spare parts
553380130103	BRACKET ASSY HV CABLE SUPPORT	TATA spare parts
553380130106	BRACKET HV CABLE SUPPORT	TATA spare parts
553380130107	CLAMP ASSY 2 WAY 50 SQ MM HV CABLE EV	TATA spare parts
553380130108	CLAMP ASSY 4 WAY 50 SQ MM HV CABLE EV	TATA spare parts
553380130109	CLAMP ASSY 4 WAY 70 SQ MM HV CABLE EV	TATA spare parts
553380130110	CLAMP ASSY 2 WAY 70 SQ MM HV CABLE EV	TATA spare parts
553380130111	CLAMP ASSY EV	TATA spare parts
553380130116	CABLE ASSY	TATA spare parts
553380130117	CABLE ASSY	TATA spare parts
553380130118	CABLE ASSY	TATA spare parts
553380130119	CABLE ASSY	TATA spare parts
553380130120	CABLE ASSY	TATA spare parts

553380130124	CLAMP ASSY EV	TATA spare parts
553380130125	CLAMP ASSY 2 WAY 50-70 SQ MM HV CABLE EV	TATA spare parts
553380130127	CABLE HV JB CHARGER TO CCS-2 CHARGER 1	TATA spare parts
553380130128	BRACKET ASSY CHARGER SOCKET	TATA spare parts
553380200106	JUNCTIONBOXBATTERY	TATA spare parts
553380200108	JUNCTIONBOXTRACTION	TATA spare parts
553380200113	BRACKET&ASSY	TATA spare parts
553380200114	BRACKET&ASSY	TATA spare parts
553380200115	BRACKET&ASSY&JUNCTION&BOX&MTG	TATA spare parts
553380200116	BRACKET&ASSY&JUNCTION&BOX&MTG	TATA spare parts
553380200118	JUNCTION BOX BATTERY	TATA spare parts
553380200119	BRACKET ASSY JUNCTION BOX MTG EV	TATA spare parts
553380200120	BRACKET ASSY JUNCTION BOX MTG EV	TATA spare parts
553380200121	JUNCTIONBOXBATTERY EV	TATA spare parts
553380200135	JUNCTION BOX BATTERY	TATA spare parts
553380200136	BRACKET ASSY	TATA spare parts
553380209903	CONTACTOR	TATA spare parts
553380209905	TEMPERATURE SENSOR PT-1000	TATA spare parts
553380209906	RUBBER BASE PLATE RH	TATA spare parts
553380209907	RUBBER GASKET SILICON	TATA spare parts
553380209908	SWITCH SUPPORTER LOWER JB	TATA spare parts
553380209911	COBRA BRACKETLV CONNECTOR RECEPTACLE(ATC	TATA spare parts
553380209916	FUSE 250A 1000VDC	TATA spare parts
553380209917	FUSE 50A 1000VDC	TATA spare parts
553380209918	MICROSWITCH-1	TATA spare parts
553380209919	2 POLE CONNECTOR 50SQMM HVC2P80MV118 (C	TATA spare parts
553380209920	2 POLE CONNECTOR 50SQMM HVC2P80MV218 (C	TATA spare parts
553380209921	2 POLE LV CONNECTOR 90 SERIES MALE TTP-0	TATA spare parts
553380209922	LV HARNESS	TATA spare parts
553380209923	FUSE 80A 1000VDC	TATA spare parts
553380209924	FUSE 35A 1000VDC	TATA spare parts
553380209925	LV HARNESS	TATA spare parts
553380209926	2 POLE CONNECTOR 6SQMM HVC2P36MV106-00	TATA spare parts
553380209927	2 POLE CONNECTOR 4SQMM HVC2P36MV204-00	TATA spare parts
553380209928	2 POLE CONNECTOR 50SQMM HVC2P80MV318 (C	TATA spare parts
553380209929	MICRO SWITCH	TATA spare parts
553380209930	CONNECTOR HEADER	TATA spare parts
553380209931	2 POLE CONNECTOR 50SQMM HVC2P80MV118 (C	TATA spare parts
553380209953	FUSE 25A 1000VDC	TATA spare parts
553380400109	NUT	TATA spare parts
553380400111	SEAL	TATA spare parts
553380400112	TERMINAL BLOCK	TATA spare parts
553380400113	FLANGE HEAD BOLT	TATA spare parts
553380400114	BRACKET	TATA spare parts
553380400116	HEX SCREW	TATA spare parts
553380400117	VENT HOSE MOTOR COOLING	TATA spare parts
553380400118	SOCKET HEAD SCREW	TATA spare parts

553380400120	BRACKET ASSY	TATA spare parts
553380400122	BRACKET ASSY	TATA spare parts
553380400125	BRACKET ASSY	TATA spare parts
553380400126	BRACKET ASSY	TATA spare parts
553380400128	BRACKET ASSY	TATA spare parts
553380400129	BRACKET ASSY	TATA spare parts
553380400133	BRACKET ASSY	TATA spare parts
553380400134	FLANGE ASSY TRACTION MOTOR	TATA spare parts
553380405101	FLANGETRACTIONMOTOR	TATA spare parts
553380406801	REDUCER HOSE	TATA spare parts
553380408203	PLATE	TATA spare parts
553380408206	BRACKET	TATA spare parts
553380408212	BRACKET	TATA spare parts
553380408216	BRACKET	TATA spare parts
553380408217	PLATE	TATA spare parts
553380408218	PLATE	TATA spare parts
553380408220	PLATE	TATA spare parts
553380409905	AUXILIARY MOTOR	TATA spare parts
553380409905C	AUXILIARY MOTORCORE	TATA spare parts
553380409906	TRACTION MOTOR	TATA spare parts
553380409908	CABLE GLAND	TATA spare parts
553380409909	AUXILIARY MOTOR	TATA spare parts
553380440101	BRACKET ASSY	TATA spare parts
553380449901	CONTROLLER	TATA spare parts
553380500113	BRACKET ASSY INVERTER MTG	TATA spare parts
553380500114	BRACKET ASSY INVERTER MTG	TATA spare parts
553380500123	BRACKET ASSY,INVERTER MTG	TATA spare parts
553380500126	BRACKET ASSY INVERTER MTG	TATA spare parts
553380500127	BRACKET ASSY INVERTER MTG	TATA spare parts
553380500128	BRACKET ASSY INVERTER MTG	TATA spare parts
553380501601	BUSH	TATA spare parts
553380503322	C-CHANNEL	TATA spare parts
553380503338	SUPPORT EV	TATA spare parts
553380508211	COVER AUXILLARY SIDE	TATA spare parts
553380508212	COVER AUXILLARY BOTTOM	TATA spare parts
553380508214	COVER AUXILLARY SIDE	TATA spare parts
553380508602	SPACER INVERTER MTG	TATA spare parts
553380509901	TRACTION INVERTER (EV)	TATA spare parts
553380509901C	TRACTION INVERTERCORE	TATA spare parts
553380509903	AUX INVERTER & DC CONVERTER UNIT(EV)	TATA spare parts
553380509903C	AUX INVERTER & DC DC CONVERTER UNITCORE	TATA spare parts
553380509906	AUX INVERTER & DC DC CONVERTER UNIT	TATA spare parts
553380509907	TRACTION INVERTER	TATA spare parts
553380556901	TUBE INVERTER MTG	TATA spare parts
553380557701	RUBBER PAD	TATA spare parts
553380600106	BRACKET ASSY BATTERY BOX MTG	TATA spare parts
553380600155	CURRENT SENSOR	TATA spare parts

553380600156	MAIN FUSE	TATA spare parts
553380600157	PRECHARGE FUSE	TATA spare parts
553380600158	PRECHARGE CONTACTOR	TATA spare parts
553380600159	MAIN CONTACTOR	TATA spare parts
553380600160	PRECHARGE RESISTOR	TATA spare parts
553380600161	GASKET HOUSING	TATA spare parts
553380600162	HARNESS BATTERY DISTRIBUTION UNIT	TATA spare parts
553380600163	MASTER ECU BATTERY MANAGEMENT SYSTEM	TATA spare parts
553380600164	SLAVE ECU BATTERY MANAGEMENT SYSTEM	TATA spare parts
553380600165	HV CONNECTOR BATTERY	TATA spare parts
553380600166	LV CONNECTOR BATTERY	TATA spare parts
553380600167	SWITCH MANUAL DISCONNECT	TATA spare parts
553380600168	SWITCH MANUAL DISCONNECT	TATA spare parts
553380600169	GASKET HOUSING	TATA spare parts
553380600170	HARNESS BATTERY DISTRIBUTION UNIT	TATA spare parts
553380600171	HV CONNECTOR BATTERY	TATA spare parts
553380600172	LV CONNECTOR BATTERY	TATA spare parts
553380600173	GASKET HOUSING	TATA spare parts
553380600174	HARNESS BATTERY DISTRIBUTION UNIT	TATA spare parts
553380600175	MASTER ECU BATTERY MANAGEMENT SYSTEM	TATA spare parts
553380600176	LV CONNECTOR BATTERY	TATA spare parts
553380600181	HIGH VOLTAGE BATTERY ASSY SERIES PACK	TATA spare parts
553380609903	ASSY. HIGH VOLT. BATTERY SERIES PACK EV	TATA spare parts
553380609907	HIGH VOLTAGE BATTERY ASSY SERIES PACK	TATA spare parts
553380609914	HVBATTERYASSY EV	TATA spare parts
553380900120	CONNECTOR	TATA spare parts
553380900125	CONNECTOR	TATA spare parts
553380900126	PLATEASSY	TATA spare parts
553380900127	TUBEASSY(BCSCOLD&HOT)	TATA spare parts
553380900133	TUBE¿ASSY¿(BCS¿COLD¿&¿HOT)	TATA spare parts
553380900134	BRACKETASSY.PUMPMTG	TATA spare parts
553380900135	BRACKET¿ASSY RADIATOR¿MTG¿(RH)	TATA spare parts
553380900137	COOLINGPIPEASSY(PUMPOUTLET)	TATA spare parts
553380900138	COOLINGPIPEASSY(TRACTIONMOTORINLET)	TATA spare parts
553380900141	BRACKET¿ASSY RADIATOR¿MTG¿(LH)	TATA spare parts
553380903305	BRACKET	TATA spare parts
553380905830	HOSE	TATA spare parts
553380905831	HOSE	TATA spare parts
553380905832	HOSE BATTERYINTAKE	TATA spare parts
553380905833	COOLANTOUTLETHOSE BATTERY	TATA spare parts
553380905846	HOSE	TATA spare parts
553380905847	HOSE TRACTIONMOTOROUTLET	TATA spare parts
553380905848	HOSEASSY INVERTERINTAKE(PUMPOUTLETLINETO	TATA spare parts
553380905849	HOSEASSY INVERTEROUTLET	TATA spare parts
553380905850	HOSEASSY INVERTERINTAKE(PUMPOUTLETLINETO	TATA spare parts
553380905851	HOSEASSY INVERTEROUTLET(TRACTIONINVERTER	TATA spare parts
553380905852	HOSE TRACTIONMOTORINTAKE	TATA spare parts

553380905853	HOSE TRACTIONMOTOROUTLET	TATA spare parts
553380905854	HOSE MOTORTORADIATOR	TATA spare parts
553380905855	HOSE(FILLLINE)	TATA spare parts
553380905856	VENT HOSE MOTOR COOLING	TATA spare parts
553380905857	HOSE(DATTORADIATOR)	TATA spare parts
553380905858	HOSE OUTLETMANIFOLDTOPUMP	TATA spare parts
553380906301	FAN¿SHROUD	TATA spare parts
553380906902	CONNECTOR¿EV	TATA spare parts
553380906908	CONNECTOR¿EV	TATA spare parts
553380906923	PIPE(TRACTIONMOTORTORADIATOR)	TATA spare parts
553380909201	WASHER	TATA spare parts
553383300104	CONTROL PANEL ASSY	TATA spare parts
553383400101	BATTERY COOLING UNIT	TATA spare parts
553383400103	BATTERY COOLING UNIT	TATA spare parts
553383404901	DISTRIBUTION BOX	TATA spare parts
553383404904	SENSOR	TATA spare parts
553383404905	SENSOR	TATA spare parts
553383404906	DISTRIBUTION BOX	TATA spare parts
553383404907	DISTRIBUTION BOX	TATA spare parts
553383404908	WIRING HARNESS	TATA spare parts
553383404909	SENSOR	TATA spare parts
553383404910	WIRING HARNESS	TATA spare parts
553383404911	RELAY	TATA spare parts
553383404912	SENSOR	TATA spare parts
553383404913	1 A BLADE FUSE	TATA spare parts
553383404914	TERMINALS EV	TATA spare parts
553383404915	TERMINALS EV	TATA spare parts
553383404916	WIRING HARNESS EV	TATA spare parts
553383404917	20 A BLADE FUSE	TATA spare parts
553383405001	HEAT EXCHANGER ASSY	TATA spare parts
553383405003	HEATEXCHANGER	TATA spare parts
553383405803	HOSE	TATA spare parts
553383405804	HOSE	TATA spare parts
553383405806	HOSE EV	TATA spare parts
553383405807	HOSE EV	TATA spare parts
553383405820	HOSE	TATA spare parts
553383406303	HOSE	TATA spare parts
553383406304	FAN COVER	TATA spare parts
553383406305	COVER	TATA spare parts
553383406901	AC PIPE ASSY	TATA spare parts
553383406902	AC PIPE ASSY	TATA spare parts
553383406903	SUCTION HOSE ASSY	TATA spare parts
553383406904	DISCHARGE HOSE ASSY	TATA spare parts
553383406906	AC PIPING	TATA spare parts
553383406908	LIQUID HOSE ASSY	TATA spare parts
553383406909	AC PIPE	TATA spare parts
553383406910	DISCHARGE HOSE ASSY	TATA spare parts



553383406911	AC PIPING	TATA spare parts
553383406912	AC PIPE	TATA spare parts
553383406913	AC PIPE ASSY	TATA spare parts
553383406914	DISCHARGE HOSE ASSY	TATA spare parts
553383406915	AC PIPE	TATA spare parts
553383406916	AC PIPE ASSY	TATA spare parts
553383406917	AC PIPE	TATA spare parts
553383407501	RUBBER BUSH ASSY	TATA spare parts
553383407502	RUBBER GROMMET	TATA spare parts
553383407503	GROMMET	TATA spare parts
553383407504	GROMMET	TATA spare parts
553383407701	PRESSURE BALANCER	TATA spare parts
553383408202	BASE	TATA spare parts
553383408203	COVER	TATA spare parts
553383408204	BRACKET ASSY AC COMPRESSOR MTG	TATA spare parts
553383408205	TANK I/O HEATER SYSTEM	TATA spare parts
553383408206	DAMPER ASSY	TATA spare parts
553383409001	EXPANSIONVALVE	TATA spare parts
553383409002	EXPANSION VALVE	TATA spare parts
553383409901	PUMPASSY	TATA spare parts
553383409903	PUMP ASSY	TATA spare parts
553383409904	PUMP ASSY EV	TATA spare parts
553383455001	CONDENSER	TATA spare parts
553383455002	CONDENSER	TATA spare parts
553383455004	CONDENSER	TATA spare parts
553383455005	CONDENSER	TATA spare parts
553383455006	CONDENSER ASSY	TATA spare parts
553383456301	CONDENSER FAN	TATA spare parts
553383456302	BLOWER ASSY	TATA spare parts
553383456302C	BLOWER ASSYCORE	TATA spare parts
553383550101	ASSY. AC COMPRESSOR BS3/4	TATA spare parts
553383550102	COMPRESSOR ASSY	TATA spare parts
553383550103	COMPRESSOR ASSY	TATA spare parts
553383550106	AC COMPRESSOR ASSY BS6	TATA spare parts
553383605801	HOSE EV	TATA spare parts
553383605802	HOSE EV	TATA spare parts
553383605803	HOSE EV	TATA spare parts
553383605804	HOSE EV	TATA spare parts
553383605806	HOSE EV	TATA spare parts
553383605807	HOSE EV	TATA spare parts
553383605808	HOSE EV	TATA spare parts
553383605809	HOSE EV	TATA spare parts
553383605810	HOSE EV	TATA spare parts
553383605811	HOSE EV	TATA spare parts
553383605812	HOSE EV	TATA spare parts
553383605813	HOSE EV	TATA spare parts
553383605814	HOSE EV	TATA spare parts

553383656901	TUBE	TATA spare parts
553383750107	BRACKET ASSY	TATA spare parts
553383753313	BRACKET	TATA spare parts
553383753315	BRACKET	TATA spare parts
553386990101	KIT-FIRE DETECTION AND SUPPRESSION SYS	TATA spare parts
553391000102	COMPLETE SEAT ASSEMBLY WITH TRACK AND ST	TATA spare parts
553410120001	REAR DESTINATION BOARD (070-DBR)	TATA spare parts
553410130001	SIDE DESTINATION BOARD (070-DBS)	TATA spare parts
553410140001	INNER DESTINATION BOARD (073-DBI)	TATA spare parts
55347000077	PAINT METALLIC CLEARCOAT TSA TS25110	TATA spare parts
553546600106	HOUSING COVER ASSY BS6-PH2	TATA spare parts
553546600109	KIT-SEAL BS6-PH2	TATA spare parts
553630010001	ROOF VENTILATOR FOR HYBRID	TATA spare parts
553700990101	SERVICE KIT FOR MAGIC EXPRESS AIS 140	TATA spare parts
553700990104	SERVICE KIT FOR MAGIC HT AIS 140	TATA spare parts
553700990105	SERVICE KIT - MAGIC EXPRESS AIS 140 NEW	TATA spare parts
553700990106	MAGIC MANTRA CNG & HT AIS140	TATA spare parts
553700990107	KIT- ACE GOLD BS6	TATA spare parts
553715100101	STARTER MOTOR ASSY BS6	TATA spare parts
553715100104	STARTER MOTOR ASSY BS6	TATA spare parts
553715100105	SOLENOID ASSY BS6	TATA spare parts
553715100106	FIXING BRACKET ASSY BS6	TATA spare parts
553715100107	DRIVE ASSY BS6	TATA spare parts
553715100108	PLANETARY GEAR ASSY BS6	TATA spare parts
553715100109	OUTPUT SHAFT ASSY BS6	TATA spare parts
553715100110	ARMATURE ASSY BS6	TATA spare parts
553715100111	BRUSH GEAR ASSY BS6	TATA spare parts
553715100112	CE BRACKET ASSY BS6	TATA spare parts
553715100114	STARTER MOTOR ASSY BS6-PH2	TATA spare parts
553715100115	SOLENOID ASSY BS6-PH2	TATA spare parts
553715100116	FIXING BRACKET ASSY BS6-PH2	TATA spare parts
553715100117	PLANETARY GEAR ASSY BS6-PH2	TATA spare parts
553715100118	OUTPUT SHAFT ASSY BS6-PH2	TATA spare parts
553715100119	ARMATURE ASSY BS6-PH2	TATA spare parts
553715100120	BRUSH GEAR ASSY BS6-PH2	TATA spare parts
553715100121	CE BRACKET ASSY BS6-PH2	TATA spare parts
553715100123	KIT-FASTENERS BS6-PH2	TATA spare parts
553715100124	KIT-SEALING BS6-PH2	TATA spare parts
553715100125	BEARING ASSY BS6-PH2	TATA spare parts
553715100126	DRIVE ASSY BS6-PH2	TATA spare parts
553715100127	BEARING ASSY BS6-PH2	TATA spare parts
553715109901	HOUSING ANNULUS BS6	TATA spare parts
553715109902	ENGAGING LEVER BS6	TATA spare parts
553715109903	ANNULUS BS6	TATA spare parts
553715109904	KIT-FASTENERS BS6	TATA spare parts
553715109905	KIT-SEALING BS6	TATA spare parts
553715109906	KIT-BEARING BS6	TATA spare parts

553715109907	KIT-BEARING BUSH BS6	TATA spare parts
553715109908	POLE&HOUSING BS6	TATA spare parts
553715109909	LEVER&HOLDER BS6	TATA spare parts
553715109910	PLANETARY&GEAR&TRAIN BS6	TATA spare parts
553715109911	PINION STARTER&MOTOR BS6	TATA spare parts
553715109912	CAPSULE BS6	TATA spare parts
553715109913	DRIVE&END&SHIELD BS6	TATA spare parts
553715109914	COVER&DISC BS6	TATA spare parts
553715109915	FORK&LEVER BS6	TATA spare parts
553715109916	SOLENOID SWITCH BS6	TATA spare parts
553715109917	COUNTER&SUNK&SCREW BS6	TATA spare parts
553715109919	BRUSH&HOLDER BS6	TATA spare parts
553715109920	HEX&NUT BS6	TATA spare parts
553715109921	DUST&PROTECTION&COVER BS6	TATA spare parts
553715109922	WATER&DRAIN&SLEEVE BS6	TATA spare parts
553715109923	HEX&NUT BS6	TATA spare parts
553715109924	ENGAGING LEVER BS6-PH2	TATA spare parts
553715109925	ANNULUS BS6-PH2	TATA spare parts
553720220001	WASHER KIT-24V/10 LTR	TATA spare parts
553720260001	WIPER SYSTEM 24V	TATA spare parts
553724100103	A-MOUNTASSY BS6	TATA spare parts
553724100105	C-MOUNTASSY BS6	TATA spare parts
553724100106	BRACKETASSYC-MOUNT BS6	TATA spare parts
553724100107	BRACKET ASSY C-MOUNT BS6	TATA spare parts
553724100108	BRACKET ASSY C-MOUNT BS6	TATA spare parts
553724103310	PLATE BS6	TATA spare parts
553724103801	BRACKETC-MOUNT BS6	TATA spare parts
553724107101	SPACERPLATEENGINEMTG BS6	TATA spare parts
553724200101	B-MOUNTASSY BS6	TATA spare parts
553724200108	BRACKETASSYB-MOUNT BS6	TATA spare parts
553724200109	BRACKETASSYB-MOUNT BS6	TATA spare parts
553729100101	CLUTCH CABLE ASSY BS6	TATA spare parts
553729100104	CLUTCH CABLE ASSY BS6	TATA spare parts
553729100109	CLUTCHPEDALASSYWITHBUSH BS6	TATA spare parts
553729200101	BRAKE PEDAL ASSY WITH BUSH	TATA spare parts
553729200105	BRACKET ASSY BRAKE & CLUTCH PEDAL MTG BS	TATA spare parts
553729200108	BRAKEPEDALASSYWITHBUSH BS6	TATA spare parts
553729500103	BRACKET ASSY CONTROL MTG BS6	TATA spare parts
553729500104	BRACKET ASSY BRAKE & CLUTCH CONTROL MTG	TATA spare parts
553729500108	BRACKET ASSY BRAKE & CLUTCH PEDAL MTG BS	TATA spare parts
553730130001	WIPER SYSTEM LINKAGE	TATA spare parts
553730140001	TWIN RADIAL WIPER ARM ASSY LH	TATA spare parts
553730150001	TWIN RADIAL WIPER ARM ASSY RH	TATA spare parts
553730160001	WIPER BLADE ASSY	TATA spare parts
553731000104	FRAME ASSY	TATA spare parts
553731000111	FRAME ASSY BS6	TATA spare parts
553731000114	FRAME ASSY BS6	TATA spare parts

553731000115	FRAME ASSY BS6	TATA spare parts
553731200113	CROSS MEMBER ASSY FRONT SPRING BS6	TATA spare parts
553731200119	CROSS MEMBER ASSY BS6	TATA spare parts
553731200131	CROSS MEMBER ASSY LOAD BODY MTG BS6	TATA spare parts
553731200132	CROSS MEMBER ASSY GEAR BOX MTG BS6	TATA spare parts
553731200133	CROSS MEMBER ASSY-ENGINE MTG BS6	TATA spare parts
553731200137	CROSS MEMBER FRONT FRAME BS6	TATA spare parts
553731200141	CROSS MEMBER ASSY-ENGINE MTG BS6	TATA spare parts
553731200142	BRACKET ASSY BS6	TATA spare parts
553731200143	BRACKET ASSY BS6	TATA spare parts
553731200145	CROSS MEMBER ASSY-REAR SPRING-FRONT BS6	TATA spare parts
553731200149	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
553731200152	CROSS MEMBER ASSY BS6	TATA spare parts
553731203312	BRACKET-SIDE SUPPORT MTG BS6	TATA spare parts
553731203313	BRACKET-SIDE SUPPORT-LH BS6	TATA spare parts
553731203314	BRACKET-SIDE SUPPORT-RH BS6	TATA spare parts
553731208223	BRACKET BS6-PH2	TATA spare parts
553731208224	BRACKET BS6-PH2	TATA spare parts
553731220102	BRACKET ASSY AIR FILTER MTG BS6-PH2	TATA spare parts
553731230107	CAB SUPPORT ASSY-RH BS6	TATA spare parts
553731540110	BATTERY TRAY ASSY BS6	TATA spare parts
553732100110	BRACKET ASSY BUMP STOPPER RH BS6	TATA spare parts
553732100111	BRACKET ASSY BUMP STOPPER LH BS6	TATA spare parts
553732103701	GUIDE PLATE FRONT BS6	TATA spare parts
553732104202	U-BOLT FRONT SPRING BS6	TATA spare parts
553732300101	BRACKET ASSY SHOCK ABSORBER MTG FRONT	TATA spare parts
553732400115	GUIDE PLATE ASSY REAR-LH BS6	TATA spare parts
553732400116	GUIDE PLATE ASSY REAR-RH BS6	TATA spare parts
553732400117	LEAF SPRING ASSY REAR BS6	TATA spare parts
553732400118	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
553732405102	GUIDE PLATE LH BS6	TATA spare parts
553732405103	GUIDE PLATE RH BS6	TATA spare parts
553733000101	FRONT AXLE ASSY	TATA spare parts
553733000103	FRONT AXLE TUBE ASSY	TATA spare parts
553733000104	FRONT AXLE ASSY BS6	TATA spare parts
553733000106	FRONT AXLE ASSY	TATA spare parts
553733000109	FRONT AXLE ASSY	TATA spare parts
553733000111	FRONT AXLE ASSY	TATA spare parts
553733000113	FRONT AXLE ASSY BS6	TATA spare parts
553733200102	STUB AXLE ASSY WITH BUSH LH	TATA spare parts
553733200103	STUB AXLE ASSY WITH BUSH RH	TATA spare parts
553733200106	STUBAXLEASSY LH BS6	TATA spare parts
553733200107	STUBAXLEASSY RH BS6	TATA spare parts
553733205107	STUB AXLE ABS LH BS6	TATA spare parts
553733205108	STUB AXLE ABS RH BS6	TATA spare parts
553733400106	HUBASSYWITHBRAKEDISC BS6	TATA spare parts
553733400108	FRONT HUB ASSY WITH BEARING BS6	TATA spare parts

553733403701	FRONT HUB	TATA spare parts
553733805101	STEERING ARM	TATA spare parts
553733805106	STEERING ARM BS6	TATA spare parts
553741100103	PROPELLER SHAFT ASSY BS6	TATA spare parts
553741100104	PROPELLER SHAFT ASSY BS6	TATA spare parts
553742100106	KIT-PAD ASSY	TATA spare parts
553742100107	HOUSING LH BS6	TATA spare parts
553742100109	HOUSING RH BS6	TATA spare parts
553742100113	KIT - PAD ASSY	TATA spare parts
553742100118	CALIPER ASSY FRONT-LH BS6	TATA spare parts
553742100119	CALIPER ASSY FRONT-RH BS6	TATA spare parts
553742100121	PAD ASSY BS6	TATA spare parts
553742100128	KIT-PAD ASSY BS6	TATA spare parts
553742105401	TONER RING FRONT	TATA spare parts
553742105402	TONER RING FRONT BS6	TATA spare parts
553742107701	PLUG BS6	TATA spare parts
553742300111	KIT-BLEED SCREW BS6	TATA spare parts
553742300115	KIT LINED SHOE	TATA spare parts
553742300116	KIT-LEVER PAWL LH	TATA spare parts
553742300117	KIT-LEVER PAWL RH	TATA spare parts
553742300118	SPRING ADJUSTER	TATA spare parts
553742300119	SPRING SHOE RETURN TOP	TATA spare parts
553742300121	BACK PLATE ASSY LH	TATA spare parts
553742300122	BACK PLATE ASSY RH	TATA spare parts
553742300123	WHEEL CYLINDER ASSY	TATA spare parts
553742300124	ADJUSTER ASSY LH	TATA spare parts
553742300125	ADJUSTER ASSY RH	TATA spare parts
553742300128	KIT-BRAKE SHOE	TATA spare parts
553742300132	KIT LEVER PAWL LH	TATA spare parts
553742300135	KIT LEVER PAWL RH	TATA spare parts
553742300137	KIT SCREW	TATA spare parts
553742300138	KIT SLIDING PIN	TATA spare parts
553742300139	KIT-SHOE HOLD DOWN	TATA spare parts
553742300142	KIT-BRAKE SPRING	TATA spare parts
553742305401	TONE WHEEL	TATA spare parts
553742700103	FRONT PARKING BRAKE CABLE ASSY-ACE EX	TATA spare parts
553742700105	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
553742700109	PARKING BRAKE CABLE ASSY FRONT (55374270	TATA spare parts
553742700114	PARKING BRAKE CABLE ASSY REAR-LH	TATA spare parts
553742700115	PARKING BRAKE CABLE ASSY REAR-RH	TATA spare parts
553742700116	PARKING BRAKE CABLE- FRONT BS6	TATA spare parts
553742700123	PARKING BRAKE CABLE BS6	TATA spare parts
553743100104	BRACKET ASSY ABS MODULATOR MTG	TATA spare parts
553743106301	COVER ABS MODULATOR	TATA spare parts
553743106302	COVER ABS MODULATOR	TATA spare parts
553743500104	VACUUM PIPE ASSY BS6	TATA spare parts
553743500111	VACUUM PIPE ASSY BS6	TATA spare parts

553743500113	VACUUM BOOSTER ASSY	TATA spare parts
553743500114	VACUUM PIPE ASSY BS6	TATA spare parts
553743500115	VACUUM BOOSTER ASSY BS6	TATA spare parts
553743500117	VACUUM PIPE ASSY BS6	TATA spare parts
553743500125	VACUUM PIPE ASSY BS6	TATA spare parts
553743505801	HOSE BOOSTER NRV TO VACUUM PIPE BS6	TATA spare parts
553743505803	VACUUM HOSE ENGINE END BS6	TATA spare parts
553743505805	VACUUM HOSE BOOSTER END BS6	TATA spare parts
553743800102	TUBE ASSY ADAPTOR TO LCRV	TATA spare parts
553743800103	TUBE ASSY TCONNECTOR TO LCRV	TATA spare parts
553743800105	TUBE ASSY ADAPTER TO LCRV REAR BS6	TATA spare parts
553743800106	TUBE ASSY T-CONN TO LCRV BS6	TATA spare parts
553743800108	TUBE ASSY LCRV TO REAR BRAKE HOSE RH BS6	TATA spare parts
553743800109	TUBE ASSY TMC PRIMARY TO T-CONN LH BS6	TATA spare parts
553743800110	TUBE ASSY TMC SECONDARY TO T-CONN BS6	TATA spare parts
553743800113	TUBE ASSY T-CONN TO ADAPTER BS6	TATA spare parts
553743800114	TUBE ASSY T-CONN TO ADAPTER BS6	TATA spare parts
553743800115	TUBE ASSY HOSE TO REAR BRAKE ASSY LH	TATA spare parts
553743800116	TUBE ASSY ADAPTER TO ADAPTER	TATA spare parts
553743800117	TUBE ASSY T-CONN TO ADAPTER BS6	TATA spare parts
553743800118	TUBE ASSY HOSE TO REAR BRAKE ASSY RH	TATA spare parts
553743800120	BRACKET ASSY-BRAKE PIPE CLAMPING BS6	TATA spare parts
553743800121	TUBE ASSY T-CONN TO FRONT BRAKE HOSE LH	TATA spare parts
553743800122	TUBE ASSY TMC PRIMARY TO T-CONN BS6	TATA spare parts
553743800124	TUBE ASSY TMC SECONDARY TO T-CONN BS6	TATA spare parts
553743800125	TUBE ASSY T-CONN TO FRONT BRAKE HOSE RH	TATA spare parts
553743800130	TUBE ASSY T-CONN TO FRONT BRAKE HOSE RH BS6	TATA spare parts
553743800131	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800132	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800133	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800134	TUBE ASSY ADAPTER TO FRONT BRAKE HOSE LH	TATA spare parts
553743800135	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800136	TUBE ASSY ADAPTER TO ADAPTER	TATA spare parts
553743800137	TUBE ASSY ADAPTER TO FRONT HOSE RH	TATA spare parts
553743800138	TUBE ASSY TMC SECONDARY TO ADAPTER	TATA spare parts
553743800139	TUBE ASSY TMC PRIMERY TO ADAPTER	TATA spare parts
553743800141	TUBE ASSY ADAPTER TO ADAPTER	TATA spare parts
553743800142	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800143	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800144	TUBE ASSY ADAPTER TO REAR BRAKE HOSE RH	TATA spare parts
553743800145	TUBE ASSY ADAPTER TO REAR BRAKE HOSE LH	TATA spare parts
553743800148	TUBE ASSY TMC SECONDARY TO ADAPTER	TATA spare parts
553743800149	TUBE ASSY ADAPTER TO LCRV REAR BS6	TATA spare parts
553743800150	TUBE ASSY ADAPTER TO LCRV REAR BS6	TATA spare parts
553743800151	TUBE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts
553743800152	TUBE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts
553743800153	TUBE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts

553743800154	TUBE ASSY ADAPTER TO ADAPTER BS6	TATA spare parts
553743800155	TUBE ASSY ADAPTER TO REAR BRAKE HOSE RH	TATA spare parts
553743800160	TUBE ASSY MV TO ADAPTER BS6	TATA spare parts
553743800161	TUBE ASSY ADAPTER TO LCRV BS6	TATA spare parts
553743800162	TUBE ASSY ADAPTER TO LCRV BS6	TATA spare parts
553743800163	BRACKET ASSY TMC COVER MTG BS6	TATA spare parts
553743800164	COVER ASSY TANDEM MASTER CYL BS6	TATA spare parts
553743800165	COVER ASSY TANDEM MASTER CYL BS6	TATA spare parts
553743800166	TUBEASSY T-CONNTOADAPTER BS6	TATA spare parts
553743800167	TUBEASSY T-CONNTOADAPTER BS6	TATA spare parts
553743800169	TUBEASSY ADAPTERTOLCRV REAR BS6	TATA spare parts
553743800170	TUBEASSY T-CONNTOADAPTER BS6	TATA spare parts
553743800171	TUBEASSY T-CONNTOADAPTER BS6	TATA spare parts
553743800201	TUBE ASSY TMC PRIMERY TO ADAPTER	TATA spare parts
553743800207	TUBE ASSY ADAPTER TO REAR BRAKE HOSE LH	TATA spare parts
553743800208	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800209	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800210	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800211	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800212	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800213	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800214	TUBE ASSY ADAPTER TO ADAPTER	TATA spare parts
553743800215	TUBE ASSY ADAPTER TO ADAPTER	TATA spare parts
553743800216	TUBE ASSY ADAPTER TO ADAPTER	TATA spare parts
553743800217	TUBE ASSY ADAPTER TO FRONT HOSE RH	TATA spare parts
553743800218	TUBE ASSY TMC SECONDARY TO ADAPTER BS6	TATA spare parts
553743800219	TUBE ASSY TMC SECONDARY TO ADAPTER BS6	TATA spare parts
553743800222	TUBE ASSY ADAPTER TO ADAPTER	TATA spare parts
553743800223	TUBE ASSY ADAPTER TO ADAPTER	TATA spare parts
553743800224	TUBE ASSY ADAPTER TO FRONT HOSE RH	TATA spare parts
553743800225	TUBE ASSY ADAPTER TO ADAPTER	TATA spare parts
553743800226	TUBE ASSY ADAPTER TO MV	TATA spare parts
553743800227	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800228	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800229	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800230	TUBE ASSY MV TO ADAPTER	TATA spare parts
553743800231	TUBE ASSY ADAPTER TO MV	TATA spare parts
553743800232	TUBE ASSY ADAPTER TO REAR BRAKE HOSE LH	TATA spare parts
553743800233	TUBE ASSY ADAPTER TO REAR BRAKE HOSE RH	TATA spare parts
553743800235	TUBE ASSY ADAPTER TO FRONT BRAKE HOSE LH	TATA spare parts
553743803308	BRACKET SENSOR CABLE MTG BS6	TATA spare parts
553743803309	BRACKET SENSOR CABLE BS6	TATA spare parts
553743803310	BRACKET SENSOR CABLE MTG BS6	TATA spare parts
553743803311	BRACKET SENSOR CABLE MTG	TATA spare parts
553743803312	BRACKET SENSOR CABLE MTG	TATA spare parts
553743803317	BRACKET SENSOR CABLE MTG BS6	TATA spare parts
553743803328	BRACKET BS6	TATA spare parts

553743803329	BRACKET BS6	TATA spare parts
553743805801	HOSE RESERVOIR TO TMC PRIMARY BS6	TATA spare parts
553743805802	HOSE RESERVOIR TO TMC SECONDARY BS6	TATA spare parts
553743805803	HOSE RESERVOIR TO TMC PRIMARY BS6	TATA spare parts
553743805804	HOSE RESERVOIR TO TMC SECONDARY BS6	TATA spare parts
553743807501	GROMMET BS6	TATA spare parts
553743807701	CLAMP BRAKE PIPE BS6	TATA spare parts
553743990101	KIT-MASTER CYL	TATA spare parts
553743990102	MAJOR KIT-MASTER CYLINDER	TATA spare parts
553743990108	KIT-MASTER CYL BS6	TATA spare parts
553744000101	SUPER ACE PTO WITH 5CC PUMP ASSLY	TATA spare parts
553746100102	STEERING&COLUMN&ASSY BS6	TATA spare parts
553746100104	STEERING COLUMN ASSY WITH I-SHAFT BS6	TATA spare parts
553746305102	DROP ARM BS6	TATA spare parts
553746600103	DRAG LINK ASSY BS6	TATA spare parts
553746600104	STEERING GEAR BOX ASSY WITH PITMAN ARM B	TATA spare parts
553746990104	INTERMEDIATE&SHAFT&ASSY BS6	TATA spare parts
553746993201	HEX&BOLT BS6	TATA spare parts
553747000101	BRACKET ASSY WITH MESH PRESSURE GUAGE	TATA spare parts
553747100103	BRACKET BS6	TATA spare parts
553747100110	BRACKET ASSY CPV MTG BS6	TATA spare parts
553747100112	FUEL MODULE ASSY	TATA spare parts
553747100114	FUEL TANK CAP WITH LOCK	TATA spare parts
553747100116	FUEL FILLER NECK ASSY BS6	TATA spare parts
553747100118	BRACKET ASSY FUEL FILTER MTG BS6	TATA spare parts
553747100120	FUEL TANK ASSY BS6	TATA spare parts
553747100121	FUEL MODULE ASSY BS6	TATA spare parts
553747100122	FUEL MODULE ASSY BS6	TATA spare parts
553747100123	FUEL TANK ASSY BS6	TATA spare parts
553747100125	FUEL TANK ASSY BS6	TATA spare parts
553747100126	FUEL FILLER NECK ASSY BS6	TATA spare parts
553747103308	BRACKET PURGE VALVE MTG BS6	TATA spare parts
553747105301	GASKET FSU BS6	TATA spare parts
553747106101	LOCKING RING BS6	TATA spare parts
553747106302	SHELL FUEL TANK BS6	TATA spare parts
553747500101	BRACKET ASSY ( FOR FILLING NOZZLE MTG.)	TATA spare parts
553747500108	STOPPER BRACKET ASSY WITH SCREW BS6	TATA spare parts
553747500114	COVER FILLING NOZZLE BS6	TATA spare parts
553747500115	FILLING RECEPTACLE ASSY BS6	TATA spare parts
553747503314	BRACKET FUEL FILLER MTG BS6	TATA spare parts
553747600107	PIPE ASSY LOW PRESSURE	TATA spare parts
553747600113	VENT PIPE ASSY. WITH ADAPTER	TATA spare parts
553747600114	FUEL SUCTION PIPE ASSY	TATA spare parts
553747600115	FUEL SUCTION PIPE ASSY	TATA spare parts
553747600116	FUEL RETURN PIPE ASSY	TATA spare parts
553747600118	HP PIPE ASSY.(REAR CYL. TO FRONT CYL.)	TATA spare parts
553747600119	HP PIPE ASSY.(NOZZLE TO REAR CYL.)	TATA spare parts



553747600131	FUEL RETURN PIPE ASSY BS6	TATA spare parts
553747600133	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
553747600142	VENT PIPE ASSY	TATA spare parts
553747600143	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
553747600145	FUEL SUCTION PIPE ASSY	TATA spare parts
553747600146	FUEL RETURN PIPE ASSY	TATA spare parts
553747600147	FUEL RETURN PIPE ASSY	TATA spare parts
553747600148	FUEL RETURN PIPE ASSY	TATA spare parts
553747600149	FUEL RETURN PIPE ASSY	TATA spare parts
553747600153	VAPOUR PIPE ASSY BS6	TATA spare parts
553747600154	FUEL RETURN PIPE ASSY BS6	TATA spare parts
553747600155	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
553747600156	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
553747600157	VAPOUR PIPE ASSY TANK TO TPV BS6	TATA spare parts
553747600160	SUCTION PIPE ASSY TANK TO FILTER BS6	TATA spare parts
553747600161	SUCTION PIPE ASSY BS6	TATA spare parts
553747600163	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
553747600164	VAPOUR PIPE ASSY BS6	TATA spare parts
553747600182	FUELSUCTIONPIPEASSYFILTERTOFCU BS6	TATA spare parts
553747600183	FUELSUCTIONPIPEASSYFUELTANKTOFUELFILTER	TATA spare parts
553747600184	FUELRETURNPIPEASSY- BS6	TATA spare parts
553747600186	FUELSUCTIONPIPEASSY- BS6	TATA spare parts
553747600187	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
553747600188	RETURN PIPE ASSY ENGINE TO FUEL TANK BS6	TATA spare parts
553747603303	BRACKET-FUEL PIPE CLAMP MTG BS6	TATA spare parts
553747605802	FUEL RETURN PIPE	TATA spare parts
553747605832	HOSE BS6	TATA spare parts
553747605836	RUBBER HOSE ENGINE SIDE BS6	TATA spare parts
553747605844	FUEL FILLING HOSE BS6	TATA spare parts
553747605845	BREATHER HOSE BS6	TATA spare parts
553747605860	RUBBER HOSE CANISTER VENTING BS6	TATA spare parts
553747605862	HOSE BS6	TATA spare parts
553747700101	LP FILTER ASSY	TATA spare parts
553747990101	FUEL MODULE W/O FLS BS6	TATA spare parts
553749200118	PIPE ASSY UREA SUPPLY (553749200119) BS6	TATA spare parts
553749200142	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
553749200143	ROV TUBE (L-213MM) BS6	TATA spare parts
553749200147	HOOK ASSY EXHAUST BS6	TATA spare parts
553749200149	UREA TANK ASSY BS6	TATA spare parts
553749200155	FILLER NECK ASSY BS6	TATA spare parts
553749200156	FILLER NECK CAP BS6	TATA spare parts
553749200160	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
553749200165	HOOK ASSY EXHAUST BS6	TATA spare parts
553749200170	PIPE ASSY FLEX BELLOW FRONT BS6	TATA spare parts
553749200171	BRACKET ASSY BS6	TATA spare parts
553749200172	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
553749200174	SILENCER ASSY EXHAUST BS6	TATA spare parts

553749200176	STONE GUARD ASSY BS6	TATA spare parts
553749200178	BRACKET ASSY BS6	TATA spare parts
553749200179	BRACKET ASSY BS6	TATA spare parts
553749200185	SILENCER ASSY EXHAUST BS6	TATA spare parts
553749203306	BRACKET BS6	TATA spare parts
553749203320	BRACKET BS6	TATA spare parts
553749203321	BRACKET BS6	TATA spare parts
553749203322	BRACKET BS6	TATA spare parts
553749203328	BRACKET BS6	TATA spare parts
553749204226	HOOK BS6	TATA spare parts
553749204227	HOOK BS6	TATA spare parts
553749205801	HOSE- UREA TANK TO CONNECTOR BS6	TATA spare parts
553749205802	HOSE- CONNECTOR TO NECK BS6	TATA spare parts
553749205803	HOSE- UREA FILLING NECK TO TANK BS6	TATA spare parts
553749206801	CONNECTOR BS6	TATA spare parts
553749207702	RUBBER WASHER BS6	TATA spare parts
553749207709	SEAL BS6	TATA spare parts
553749207721	STONE GUARD BS6	TATA spare parts
553749208203	BRACKET BS6	TATA spare parts
553749208602	SPACER UREA TANK MTG BKT BS6-PH2	TATA spare parts
553754108801	STUD BATTERY MTG	TATA spare parts
553754304901	FUEL LEVEL SENSOR BS6	TATA spare parts
553754400102	HEADLAMP ASSY LH BS6-PH2	TATA spare parts
553754400108	HEADLAMP ASSY RH BS6-PH2	TATA spare parts
553754400111	LAMP ASSY CABIN BS6-PH2	TATA spare parts
553754400112	INDICATOR LAMP FRONT-LH BS6-PH2	TATA spare parts
553754400113	INDICATOR LAMP FRONT-RH BS6-PH2	TATA spare parts
553754400118	TAIL LAMP ASSY LH BS6-PH2	TATA spare parts
553754400119	TAIL LAMP ASSY RH BS6-PH2	TATA spare parts
553754500106	EMERGENCY HELP SWITCH	TATA spare parts
553754501610	SWITCH EMERGENCY HELP	TATA spare parts
553754504902	FASCIA SWITCH ASSY BS6	TATA spare parts
553754504902C7	GRANIT_BLACK-SWITCH REGENERATION START M	TATA spare parts
553754504903	HEADLAMP LEVELLING SWITCH BS6	TATA spare parts
553754504907C7	GRANIT BLACK-ECO SWITCH	TATA spare parts
553754504908C7	GRANIT_BLACK-POWER SWITCH BS6	TATA spare parts
553754504909	SWITCH REGENERATION START MANUAL BS6-PH2	TATA spare parts
553754504911	ECO SWITCH BS6	TATA spare parts
553754504913	POWER SWITCH BS6-PH2	TATA spare parts
553754509904	EMERGENCY HELP SWITCH BS6	TATA spare parts
553754600102	WIRING HARNESS MAIN BS6	TATA spare parts
553754600118	WIRING HARNESS ASSY ENGINE BS6	TATA spare parts
553754600122	WIRING HARNESS ENGINE	TATA spare parts
553754600123	BATTERY CABLE +VE	TATA spare parts
553754600126	BATTERY CABLE +VE BS6	TATA spare parts
553754600127	WIRING HARNESS SIDE REPEATER	TATA spare parts
553754600128	WIRING HARNESS MAIN BS6	TATA spare parts

553754600144	"WIRING HARNESS,MAIN"	TATA spare parts
553754600145	WIRING HARNESS SIDE REPEATER	TATA spare parts
553754600146	WIRING HARNESS MAIN	TATA spare parts
553754600147	WIRING HARNESS ROOF	TATA spare parts
553754600148	WIRING HARNESS SIDE REPEATER	TATA spare parts
553754600149	WIRING HARNESS MAIN	TATA spare parts
553754600151	WIRING HARNESS PIGTAIL	TATA spare parts
553754600152	WIRING HARNESS ABS	TATA spare parts
553754600154	WIRING HARNESS MAIN BS6	TATA spare parts
553754600156	WIRING HARNESS BATTERY CABLE +VE	TATA spare parts
553754600158	WIRING HARNESS ENGINE BS6	TATA spare parts
553754600160	BATTERY CABLE +VE BS6	TATA spare parts
553754600161	STICKER & COVER ASSY FUSE BOX BS6	TATA spare parts
553754600162	STICKER & COVER ASSY FUSE BOX BS6	TATA spare parts
553754600163	WIRING HARNESS ASSY ENGINE BS6	TATA spare parts
553754600165	BATTERY CABLE +VE BS6	TATA spare parts
553754600166	WIRING HARNESS MAIN BS6	TATA spare parts
553754600167	BRACKET ASSY FUSE BOX MTG BS6	TATA spare parts
553754600172	WIRING HARNESS ABS BS6	TATA spare parts
553754600177	WIRING HARNESS BATTERY +VE	TATA spare parts
553754600179	BRACKET ASSY FUSE BOX MTG BS6	TATA spare parts
553754600180	HT CABLE BS6	TATA spare parts
553754600184	WIRING HARNESS MAIN	TATA spare parts
553754600185	WIRINGHARNESSMAIN BS6	TATA spare parts
553754600191	WIRING HARNESS ENGINE	TATA spare parts
553754600193	PIGTAIL REAR PARKING SENSOR BS6	TATA spare parts
553754600194	PIGTAIL REAR PARKING SENSOR BS6	TATA spare parts
553754600196	MTA FUSE BOX BASE BS6-PH2	TATA spare parts
553754600197	WIRING HARNESS ABS	TATA spare parts
553754600199	PIGTAIL REAR PARKING SENSOR BS6	TATA spare parts
553754603301	BRACKET ASSY ENGINE WIRING HARNESS MTG	TATA spare parts
553754603302	BRACKET	TATA spare parts
553754603306	BRACKET FUSE BOX MTG BS6	TATA spare parts
553754603312	BRACKET BATTERY CABLE MTG	TATA spare parts
553754603314	BRACKET WIRING HARNESS CLIP MTG BS6	TATA spare parts
553754603317	BRACKET WIRING HARNESS CLIP MTG BS6	TATA spare parts
553754603318	BRACKET WIRING HARNESS CLIP MTG BS6	TATA spare parts
553754603319	BRACKET WIRING HARNESS CLIP MTG BS6	TATA spare parts
553754603324	BRACKET RELAY BASE MTG BS6	TATA spare parts
553754603326	BRACKET-W/H & BATTERY CABLE MTG BS6	TATA spare parts
553754603327	BRACKET ALTERNATOR MTG BS6	TATA spare parts
553754603329	BRACKET EMS CABLE MTG BS6	TATA spare parts
553754603330	BRACKET WIRING HARNESS - EMS CABLE MTG B	TATA spare parts
553754603331	BRACKET EMS CABLE MTG BS6	TATA spare parts
553754603332	BRACKET EMS WIRING HARNESS MTG BS6-PH2	TATA spare parts
553754603335	BRACKET-ENGINE MTG BS6	TATA spare parts
553754603336	BRACKET BS6	TATA spare parts

553754603339	BRACKET BS6	TATA spare parts
553754603340	BRACKET BS6	TATA spare parts
553754606311	FUSE BOX COVER BS6	TATA spare parts
553754606312	FUSE BOX COVER BS6	TATA spare parts
553754606334	HOLDER BS6-PH2	TATA spare parts
553754606335	FUSE BOX COVER BS6-PH2	TATA spare parts
553754610101	WIRING HARNESS BATTERY CABLE +VE	TATA spare parts
553754610107	PIGTAIL GPS CONNECTOR BS6	TATA spare parts
553754610124	WIRING HARNESS MAIN BS6	TATA spare parts
553754610129	WIRING HARNESS PIGTAIL BS6-PH2	TATA spare parts
553754610132	WIRING HARNESS MAIN BS6	TATA spare parts
553754610133	WIRING HARNESS MAIN BS6	TATA spare parts
553754610135	WIRING HARNESS ENGINE BS6	TATA spare parts
553754610136	WIRING HARNESS ASSY ENGINEBS6	TATA spare parts
553754610138	PIGTAIL ASSY BS6	TATA spare parts
553754610143	WIRING HARNESS MAIN BS6	TATA spare parts
553754610147	WIRING HARNESS-MAIN BS6	TATA spare parts
553754610148	STICKER & COVER ASSY FUSE BOX BS6-PH2	TATA spare parts
553754610153	EARTH STRAP BS6-PH2	TATA spare parts
553754709906	VEHICLE SPEED SENSOR BS6	TATA spare parts
553754900113	BRACKET ASSY ECU WIRING HARNESS MTG BS6	TATA spare parts
553754903301	BRACKET LAMBADA SENSOR MTG BS6	TATA spare parts
553754904901	USB SOCKET BS6	TATA spare parts
553755106301	MASCOT XPRESS	TATA spare parts
553755106302	DECAL XPRESS LH-TATA ACE	TATA spare parts
553755106303	DECAL XPRESS RH-TATA ACE	TATA spare parts
553755106304	DECAL SIDE OUTER LH	TATA spare parts
553755106305	DECAL SIDE OUTER RH	TATA spare parts
553755106306	EXPRESS MASCOT	TATA spare parts
553755106307	DECAL SIDE OUTER LH	TATA spare parts
553755106308	DECAL SIDE OUTER RH	TATA spare parts
553755106309	MASCOT BS6	TATA spare parts
553758408201	TRANSFER LABEL PETROL BS6	TATA spare parts
553758900601	TORQUE WRENCH TORCOFIX SE 9X12 10-50NM	TATA spare parts
553758900602	RECT. REVERSIBLE RATCHET HD 1/2INCH SE 9	TATA spare parts
553758900605	RECT. REVERSIBLE RATCHET HD 3/8INCH SE 9	TATA spare parts
553758900606	RECT. REVERSIBLE RATCHET HD 1/4INCH SE 9	TATA spare parts
553758900607	TORN TORQUE WRENCH 2.5 - 25 NM WITH PLU	TATA spare parts
553758900608	TORQUE WRENCH QL5ONS 10-50NM ADJUST.TYP	TATA spare parts
553758900609	SPANNER SPARK PLUG BS6	TATA spare parts
553758900611	ADAPTER CHECKING ENGINE COMPRESSION BS6	TATA spare parts
553758903302	DRIFT BS6	TATA spare parts
553760000110	BODY SHELL ASSY BS6	TATA spare parts
553760000111CN	IRISH_CREAM-BODY SHELL ASSY PAINTED BS6	TATA spare parts
553760000111JS	TITANIUM_WH-BODY SHELL ASSY PAINTED BS6	TATA spare parts
553760100118BF	ARCTIC WHITE - ASSY BODY SHELL PAINTED	TATA spare parts
553760100123	TUBE ASSY REAR BS6	TATA spare parts

553760100141	BODY SHELL ASSY	TATA spare parts
553760100142BF	ARCTIC WHITE - ASSY BODY SHELL PAINTED	TATA spare parts
553760100142FD	SKOOL GOLDEN YELLOW - ASSY BODY SHELL PA	TATA spare parts
553760100142G3	ASSY. CABIN BARE (MAGIC) PORC WHITE BS4	TATA spare parts
553760100142HF	METEOR_SILVR-BODY SHELL ASSY PAINTED	TATA spare parts
553760100142HS	LASER RED - ASSY BODY SHELL PAINTED	TATA spare parts
553760100142J7	CHILL METLIC - ASSY BODY SHELL PAINTED	TATA spare parts
553760100153CN	IRISH_CREAM-BODY SHELL ASSY PAINTED BS6	TATA spare parts
553760100153JS	TITANIUM_WH-BODY SHELL ASSY PAINTED BS6	TATA spare parts
553760100186BF	ARCTIC WHITE BODY SHELL ASSY PAINTED BS6	TATA spare parts
553760100186FD	SK_GOLN_YELW-BODY SHELL ASSY PAINTED BS6	TATA spare parts
553760110141BF	ARCTIC_WHITE-BODY SHELL ASSY	TATA spare parts
553760110141HF	METEOR_SILVR-BODY SHELL ASSY	TATA spare parts
553760110141HU	AZURE_BLUE-BODY SHELL ASSY	TATA spare parts
553760110141JS	TITANIUM_WH-BODY SHELL ASSY	TATA spare parts
553760110141K4	FESTIV_CORAL-BODY SHELL ASSY	TATA spare parts
553760110142BF	ARCTIC_WHITE-ASSY BODY SHELL COMP FL CNG	TATA spare parts
553760110142HF	METEOR_SILVR-ASSY BODY SHELL COMP FL CNG	TATA spare parts
553760110142HU	AZURE_BLUE-ASSY BODY SHELL COMP FL CNG BS	TATA spare parts
553760110142JS	TITANIUM_WH-ASSY BODY SHELL COMP FL CNG B	TATA spare parts
553760110142K4	FESTIV_CORAL-ASSY BODY SHELL COMP FL CNG	TATA spare parts
55376011Z104BF	BODY SHELL COMP ARTIC WHITE ACE HT	TATA spare parts
55376011Z104FD	BODY SHELL COMP SK GOLDEN YELLOW ACE HT	TATA spare parts
55376011Z104GM	BODY SHELL COMP ACE HT SARDINIA RED	TATA spare parts
55376011Z104HU	BODY SHELL COMP AZURE BLUE ACE HT	TATA spare parts
55376011Z104IC	ASSY BODY SHELL COMP ACE HT BLAZING RED	TATA spare parts
55376011Z118FW	ASSY BODY SHELL COMP PAINTED IVORY WHITE	TATA spare parts
55376011Z118FZ	ASSY BODY SHELL COMP PAINTED CHAMPGN GO	TATA spare parts
553760600103	CROSS MEMBER ASSY BS6	TATA spare parts
553761200101	PANEL ASSY REAR CROSS MEMBER REAR BS6	TATA spare parts
553761600102	WHEEL ARCH ASSY INNER-LH	TATA spare parts
553761600110	WHEEL ARCH ASSY INNER-REAR-RH BS6	TATA spare parts
553761600122	CAB MTG CLOSING ASSY LH BS6	TATA spare parts
553761600130	MIDDLE FLOOR ASSY BS6	TATA spare parts
553761600140	ECU MTG ASSY BS6	TATA spare parts
553761600161	PANEL ASSY MIDDLE FLOOR	TATA spare parts
553761600162	WHEEL ARCH ASSY INNER-REAR-LH BS6	TATA spare parts
553761600166	WHEEL ARCH ASSY INNER-REAR-RH BS6	TATA spare parts
553761600174	ENGINE COVER ASSY BS6	TATA spare parts
553761600179	FLOOR ASSY BS6	TATA spare parts
553761600184	FRONT FLOOR ASSY BS6	TATA spare parts
553761600189	PANEL ASSY FRONT FLOOR BS6	TATA spare parts
553761600195	VERTICAL FLOOR ASSY BS6	TATA spare parts
553761600196	BRACKET ASSY CAB CLOSURE MTG LH BS6	TATA spare parts
553761600198	FRONT FLOOR ASSY BS6	TATA spare parts
553761610113	MIDDLE FLOOR ASSY BS6	TATA spare parts
553761800105	REAR FLOOR ASSY REAR	TATA spare parts

553762000102	FRONT WALL ASSY BS6	TATA spare parts
553763000101	SIDE WALL ASSY LH	TATA spare parts
553763000102	SIDE WALL ASSY RH	TATA spare parts
553763000106	SIDE WALL ASSY RH BS6	TATA spare parts
553763600133	SIDE WALL ASSY INNER-RH BS6	TATA spare parts
553763700101	ASSY SIDE OUTER LH	TATA spare parts
553763700106	SIDE OUTER ASSY RH	TATA spare parts
553763700112	SIDE OUTER ASSY LH BS6	TATA spare parts
553763708203	REINF PANEL SUPPORT OUTER-UPPER-LH BS6	TATA spare parts
553763708204	REINF PANEL SUPPORT OUTER-UPPER-RH BS6	TATA spare parts
553764000103	ASSY REAR WALL BS6	TATA spare parts
553764000107	REAR WALL ASSY BS6	TATA spare parts
553764000108	REAR WALL ASSY BS6	TATA spare parts
553765708201	PANEL REAR ROOF	TATA spare parts
553767302301	FIXED GLASS REAR CABIN	TATA spare parts
553767306301	SEAL GLASS REAR	TATA spare parts
553767400101	SLIDING WINDOW ASSY REAR	TATA spare parts
553767406302	SEAL REAR DOOR SLIDING WINDOW	TATA spare parts
553767406303	FOAM REAR WINDOW GLASS	TATA spare parts
553767500101	SLIDING WINDOW ASSY REAR QUARTER LH	TATA spare parts
553767500102	SLIDING WINDOW ASSY REAR QUARTER RH	TATA spare parts
553767506303	SEAL REAR QUARTER SLIDING WINDOW LH	TATA spare parts
553767506304	SEAL REAR QUARTER SLIDING WINDOW RH	TATA spare parts
553767802301	FIXED GLASS TAILGATE	TATA spare parts
553767806301	SEAL TAILGATE GLASS	TATA spare parts
553768206308	MEL SHEET-REAR FLOOR BS6-PH2	TATA spare parts
553768206309	MEL SHEET-REAR FLOOR BS6-PH2	TATA spare parts
553768206310	MEL SHEET-REAR FLOOR BS6-PH2	TATA spare parts
553768206311	MEL SHEET-REAR DOOR-LH BS6-PH2	TATA spare parts
553768206312	MEL SHEET-REAR BS6-PH2	TATA spare parts
553768406308	CARPET MIDDLE	TATA spare parts
553768406309	FOAM CROSS LINK	TATA spare parts
553768406310	CARPET ENGINE COVER TOP	TATA spare parts
553768406316	CARPET MIDDLE	TATA spare parts
553768406319	CARPET ENGINE COVER TOP	TATA spare parts
553768406321	COVER UREA TANK PIPE BS6	TATA spare parts
553768406322	INSULATION PAD LH BS6	TATA spare parts
553768406323	CARPET ENGINE COVER BS6	TATA spare parts
553768406323C7	GRANIT_BLACK-CARPET ENGINE COVER BS6	TATA spare parts
553768506303	CARPETENGINECOVER BS6	TATA spare parts
553768506303C7	GRANIT_BLACK-CARPET ENGINE COVER BS6	TATA spare parts
553768506304	CARPETVERTICALWALL BS6	TATA spare parts
553768506304C7	GRANIT_BLACK-CARPET VERTICAL WALL BS6	TATA spare parts
553768506305	FLOORCARPET BS6	TATA spare parts
553768506305C7	GRANIT_BLACK-FLOOR CARPET BS6	TATA spare parts
553768706303	CARPET FRONT WALL BS6	TATA spare parts
553768706303C7	GRANIT_BLACK-CARPET FRONT WALL BS6	TATA spare parts

553768706305	INSULATION LOAD BODY COVER BS6	TATA spare parts
553768706307	INSULATION ENGINE COVER BS6	TATA spare parts
553768706308	INSULATION ENGINE COVER BS6	TATA spare parts
553768706309	INSULATIONENGINECOVER BS6	TATA spare parts
553768706310	INSULATIONVERTICALWALL BS6	TATA spare parts
553768706312	VERTICAL WALL CARPET DRIVER BS6	TATA spare parts
553768706313	VERTICAL WALL CARPET CO-DRIVER BS6	TATA spare parts
553768900102	CONSOLE ASSY ENGINE SHIELD	TATA spare parts
553768900105	DASHBOARD ASSY BS6	TATA spare parts
553768900105ZZ	CLRPART_ASSY-DASHBOARD ASSY BS6	TATA spare parts
553768900106	BEZEL ASSY BS6	TATA spare parts
553768900108	LOCK ASSY GLOVE BOX BS6	TATA spare parts
553768900110	DASHBOARD ASSYBS6	TATA spare parts
553768900110ZZ	CLRPART_ASSY-DASHBOARD ASSY BS6	TATA spare parts
553768903302	BRACKET LATCH MTG GLOVE BOX BS6	TATA spare parts
553768906307	COVER BOTTOM CENTER DASHBOARD	TATA spare parts
553768906308	BEZEL INSTRUMENT CLUSTER BS6	TATA spare parts
553768906309	DASHBOARD SKIN BS6	TATA spare parts
553768906310	GLOVE BOX LID BS6	TATA spare parts
553768906311	GLOVE BOX HOUSING BS6	TATA spare parts
553768906312	CAP AUX TANK BS6	TATA spare parts
553768906313	CAP BRAKE FLUID RESERVOIR BS6	TATA spare parts
553768906314	CAP DASHBOARD MTG BS6	TATA spare parts
553768906318	STOPPER GLOVE BOX LID BS6	TATA spare parts
553768906320	DASHBOARD SKINBS6	TATA spare parts
553768996301	INSULATION LOAD BODY COVER	TATA spare parts
553769100104	GRILL ASSY AIR INTAKE BS6	TATA spare parts
553769106301	RUBRAIL FRONT-LH	TATA spare parts
553769106302	RUBRAIL MIDDLE-LH	TATA spare parts
553769106303	RUBRAIL REAR-LH	TATA spare parts
553769106304	RUB RAIL TAILGATE	TATA spare parts
553769106306	RUB RAIL REAR QUARTER LH	TATA spare parts
553769106307	RUB RAIL REAR QUARTER RH	TATA spare parts
553769106308	RUBRAIL FRONT-RH	TATA spare parts
553769106309	RUBRAIL MIDDLE-RH	TATA spare parts
553769106310	RUBRAIL REAR-RH	TATA spare parts
553769106311	SCUFF PLATE REAR DOOR INNER-LH	TATA spare parts
553769106312	SCUFF PLATE REAR DOOR INNER-RH	TATA spare parts
553769106313	SCUFF PLATE TAILGATE INNER	TATA spare parts
553769106314	TRIM ROOF RH BS6	TATA spare parts
553769106315	TRIM ROOF LH BS6	TATA spare parts
553769106316	TRIM ROOF REAR BS6	TATA spare parts
553769136302	B-PILLAR TRIM RH BS6	TATA spare parts
553769136303	B-PILLAR TRIM LH BS6	TATA spare parts
553769146301	C-PILLAR TRIM LH BS6	TATA spare parts
553769146302	C-PILLAR TRIM RH BS6	TATA spare parts
553769156301	D-PILLAR TRIM LH BS6	TATA spare parts

553769156302	D-PILLAR TRIM RH BS6	TATA spare parts
553769506301	HEADLINER REAR MAGIC VAN	TATA spare parts
553769506302	ANTI FLUTTER STRIP ROOF FRONT BS6	TATA spare parts
553769506303	ANTI FLUTTER STRIP ROOF FRONT BS6	TATA spare parts
553769506309	HEADLINER REAR BS6	TATA spare parts
553769506310	HEADLINER FRONT BS6	TATA spare parts
553769800101	FLOOR ASSY BS6	TATA spare parts
553770000107CN	IRISH_CREAM-LOAD BODY ASSY BS6	TATA spare parts
553770000107JS	TITANIUM_WH-LOAD BODY ASSY BS6	TATA spare parts
553770000110CN	IRISH_CREAM-FLAT BED LOAD BODY ASSY BS6	TATA spare parts
553770000110JS	LOAD BODY ASSY TITANIUM_WH-FLAT BED BS6	TATA spare parts
553770000117CN	IRISH_CREAM-LOAD BODY ASSY BS6	TATA spare parts
553770000117HU	ASSY LOAD BODY AZURE_BLUE- BS6	TATA spare parts
553770000117JS	TITANIUM_WH-LOAD BODY ASSY BS6	TATA spare parts
553770000119	SHELL ASSY LOAD BODY BS6	TATA spare parts
553770000126	LOAD BODY ASSY BS6	TATA spare parts
553770000129CN	IRISH_CREAM-LOAD BODY ASSY BS6	TATA spare parts
553770000129JS	TITANIUM_WH-LOAD BODY ASSY BS6	TATA spare parts
553770000130	FLAT BED LOAD BODY ASSY BS6	TATA spare parts
553770100101	ASSY TAILGATE SKIRT LOAD BODY CNG FL	TATA spare parts
553770100143	REAR SKIRT ASSY BS6	TATA spare parts
553770100161	LIDASSYFUELFILLER BS6	TATA spare parts
553770100183	BRACKET ASSY FRAME MOUNTING ACE EV	TATA spare parts
553770100185	BRACKET ASSY FRAME MOUNTING ACE EV	TATA spare parts
553770100186	BRACKET ASSY FRAME MOUNTING ACE EV	TATA spare parts
553770106301	FOAM PACKING BS6	TATA spare parts
553770106302	REFLECTIVE TAPE BS6	TATA spare parts
553770106309	REFLECTIVE TAPE BS6-PH2	TATA spare parts
553770106310	REFLECTIVE TAPE BS6-PH2	TATA spare parts
553770107701	RUBBER SEAL ACE EV	TATA spare parts
553770108202	SUPPORT ANGLE FRONT PANEL BS6	TATA spare parts
553770108218	STAY MUDGUARD BS6	TATA spare parts
553770108219	STAY MUDGUARD BS6-PH2	TATA spare parts
553770906301	BALATA ACE EV	TATA spare parts
553771406301	PARTITION PANEL REAR-OUTER BS6	TATA spare parts
553771406302	PARTITION PANEL ASSY REAR WALL BS6	TATA spare parts
553771406303	PANEL PARTITION WALL LOWER BS6	TATA spare parts
553772000101	DOOR SHELL ASSY FRONT DOOR LH	TATA spare parts
553772200102	DOOR SHELL ASSY FRONT DOOR LH BS6	TATA spare parts
553772208201	OUTER PANEL FRONT DOOR LH BS6	TATA spare parts
553772300101	INNER HANDLE ASSY FRONT DOOR LH BS6	TATA spare parts
553772300102	INNER HANDLE ASSY FRONT DOOR RH BS6	TATA spare parts
553772320101	FUEL LID LOCK ASSY BS6-PH2	TATA spare parts
553772980101	KIT-LOCK SET WITH FUEL CAP	TATA spare parts
553772980102	KIT-LOCK SET WITH FUEL CAP BS6	TATA spare parts
553772980105	KIT-LOCK SET ASSY	TATA spare parts
553772980106	KIT-LOCK SET ASSY BS6	TATA spare parts



553773000105	DOOR SHELL ASSY REAR-LH	TATA spare parts
553773000106	DOOR SHELL ASSY REAR-RH	TATA spare parts
553773000107	REAR DOOR BIW ASSY WITH HINGE LH BS6	TATA spare parts
553773000108	REAR DOOR BIW ASSY WITH HINGE RH BS6	TATA spare parts
553773200111	DOOR PANEL ASSY OUTER-LH BS6	TATA spare parts
553773200112	DOOR PANEL ASSY OUTER-RH BS6	TATA spare parts
553773200113	DOOR PANEL ASSY INNER-LH BS6	TATA spare parts
553773200114	DOOR PANEL ASSY INNER-RH BS6	TATA spare parts
553773300104	HINGE ASSY REAR DOOR LH	TATA spare parts
553773306001	LINK POP UP KNOB LATCH LH BS6	TATA spare parts
553773306002	LINK POP UP KNOB LATCH RH BS6	TATA spare parts
553773306004	LINK LOCK BARREL LH BS6	TATA spare parts
553773306005	LINK LOCK BARREL RH BS6	TATA spare parts
553773320101	LATCH ASSY REAR DOOR LH	TATA spare parts
553773320102	LATCH ASSY REAR DOOR RH	TATA spare parts
553773501601	SIDE DOOR ASSY REAR LH SEAL LH	TATA spare parts
553773501602	SIDE DOOR ASSY REAR RH SEAL RH	TATA spare parts
553774000105	TAILGATE SHELL ASSY BS6	TATA spare parts
553774000106	TAILGATE SHELL ASS	TATA spare parts
553774200109	TAILGATE ASSY INNER BS6	TATA spare parts
553774200112	TAILGATE ASSY OUTER BS6	TATA spare parts
553774208204	OUTER PANEL TAILGATE APERTURE	TATA spare parts
553774208231	OUTER PANEL TAILGATE BS6-PH2	TATA spare parts
553774305202	PRIMARY DOOR SEAL	TATA spare parts
553774306003	LINK POP UP KNOB TO TAILGATE LATCH	TATA spare parts
553774326001	LINK LOCK BARREL	TATA spare parts
553774326002	LINK OUTER HANDLE TO LATCH	TATA spare parts
553774501601	PRAMARY SEAL TAILGATE	TATA spare parts
553774547701	SECONDRARY SEAL FOR REAR DOOR	TATA spare parts
553779100107	TUBULAR STRUCTURE ASSY	TATA spare parts
553779100121	TUBULAR STRUCTURE ASSY BS6	TATA spare parts
553779108202	PANEL REAR ROOF EXTENSION	TATA spare parts
553781300101	COVER ASSY ECU	TATA spare parts
553781300101C7	GRANIT_BLACK-COVER ASSY ECU BS6	TATA spare parts
553781306313	COVER REAR BS6	TATA spare parts
553781706303	PLASTIC MEMBRANE BS6-PH2	TATA spare parts
553781706305	PLASTIC MEMBRANE BS6-PH2	TATA spare parts
553783100102	AIR INTAKE DUCT ASSY	TATA spare parts
553783406301	BLOWER ASSY	TATA spare parts
553783500101	BRACKET ASSY BLOWER MTG	TATA spare parts
553783500102	BRACKET ASSY BLOWER MTG	TATA spare parts
553783500106	AIR DISTRIBUTOR ASSY	TATA spare parts
553783500108	HEATER CASING ASSY	TATA spare parts
553783505801	DRAIN HOSE	TATA spare parts
553783650101	HEATER PIPE ASSY	TATA spare parts
553783650102	HEATER PIPE ASSY INTAKE	TATA spare parts
553783650103	HEATER PIPE ASSY OUTLET	TATA spare parts

553783655805	HEATER HOSE ENGINE END	TATA spare parts
553783784202	SEPARATOR CLAMP	TATA spare parts
553784000102CN	ASSY HIGHDECK LOADBODY(PAINTED)	TATA spare parts
553784000110CN	IRISH_CREAM-HIGHDECK LOAD BODY ASSY BS6	TATA spare parts
553784300102	ASSY HIGH DECK LOADBODY FACELIFT	TATA spare parts
553786600102	MEDICAL EQUIPMENT BS6	TATA spare parts
553786800101	FIRE EXTINGUISHER ASSY BS6	TATA spare parts
553786980101	KIT-AMBULANCE BS6	TATA spare parts
553788206303	WHEEL ARCH FENDER REAR-LH	TATA spare parts
553788206304	WHEEL ARCH FENDER REAR-RH	TATA spare parts
553788300101	FOOT STEP ASSY REAR	TATA spare parts
553788300102	FOOT STEP ASSY REAR	TATA spare parts
553788300103	FOOT STEP ASSY	TATA spare parts
553788300104	FOOT STEP ASSY LH BS6	TATA spare parts
553788300108	FOOT STEP STRUCTURE ASSY REAR BS6	TATA spare parts
553788300109	FOOT STEP STRUCTURE ASSY REAR BS6	TATA spare parts
553788400101	ENGINECOVERASSYREAR BS6	TATA spare parts
553788408204	BRACKET BONNET MTG BS6-PH2	TATA spare parts
553788506304	REFLECTIVE TAPE FRONT BS6	TATA spare parts
553788600102	REAR BUMPER ASSY BS6	TATA spare parts
553788600103	REAR BUMPER ASSY BS6	TATA spare parts
553788606306	REFLECTIVE TAPE TAILGATE	TATA spare parts
553788800103	GARNISH FRONT ASSY	TATA spare parts
553788800104BF	ASSY.FRONT PANEL ARC WHITE-OUTER ACE BS4	TATA spare parts
553788800104FZ	FRONT PANEL ASSY OUTER ACE FL EURO I	TATA spare parts
553788800104G3	PORCLN_WHITE-FRONT PANEL ASSY OUTER ACE	TATA spare parts
553788800104HM	ASSY. FRT PANEL URBAN BRONZE OUTER BS3/4	TATA spare parts
553788800104J7	CHILL_METLIC-FRONT PANEL ASSY,OUTER ACE	TATA spare parts
553791000103	DRIVER SEAT ASSY W/O HEADREST	TATA spare parts
553791000104	DRIVER SEAT ASSY BS6	TATA spare parts
553791990101	ASSY BACK RH COMPLETE (ACE GOLD BS-VI) K	TATA spare parts
553791990102	ASSY CUSHION RH COMPLETE (ACE GOLD BS-VI	TATA spare parts
553792000110	SEAT ASSY 4TH ROW REAR	TATA spare parts
553792000111	SEAT ASSY 2ND ROW REAR	TATA spare parts
553792000112	SEAT ASSY 3RD ROW REAR	TATA spare parts
553792000113	4TH ROW SEAT ASSY BS6	TATA spare parts
553792000114	2ND ROW SEAT ASSY BS6	TATA spare parts
553792000115	3RD ROW SEAT ASSY BS6	TATA spare parts
553792000117	FLIP - FOLD REAR SEAT ASSY BS6	TATA spare parts
553792000118	REAR TWIN SEAT BS6	TATA spare parts
553792000119	DOCTOR SEAT ASSY BS6	TATA spare parts
553792400101	KIT ARMREST (ASSY COMPLETE ARM REST+ M6	TATA spare parts
553792450101	KIT ASSY 3RD ROW CUSHION COMPLETE LOW EN	TATA spare parts
553792450104	KIT ASSY 2ND ROW CUSHION COMPLETE LOW EN	TATA spare parts
553792450106	KIT ASSY 4TH ROW CUSHION COMPLETE LOW EN	TATA spare parts
553792450108	KIT ASSY 2ND ROW BACK COMPLETE LOW END (	TATA spare parts
553792450113	KIT ASSY 3RD ROW BACK COMPLETE LOW END (	TATA spare parts

553792450114	KIT ASSY 4TH ROW BACK COMPLETE LOW END (	TATA spare parts
553794000101	ARM REST ASSY BS6-PH2	TATA spare parts
553794000105	CO-DRIVERSEATASSYW/OHEADREST BS6	TATA spare parts
553794000106	CO-DRIVER SEAT ASSY BS6	TATA spare parts
553794000107	ARMREST ASSY BS6-PH2	TATA spare parts
553794001601	ARMREST ASSY BS6-PH2	TATA spare parts
553794990101	KIT-CO-DRIVER SEAT CUSHION BS6	TATA spare parts
553794990102	KIT-BACKREST ASSY CO-DRIVER SEAT BS6	TATA spare parts
553829108703	TORSION SPRING CLUTCH PEDAL	TATA spare parts
553831000106	FRAME ASSY	TATA spare parts
553841100101	PROPELLER SHAFT ASSY	TATA spare parts
553843500106	VACUUM BOOSTER ASSY	TATA spare parts
553843500109	VACUUM BOOSTER ASSY	TATA spare parts
553843500110	SERVO UNIT ASSY	TATA spare parts
553843500111	PLUNGER ASSY SECONDARY BS6	TATA spare parts
553843500112	KIT-MASTER CYL	TATA spare parts
553843500116	MASTER CYLINDER ASSY	TATA spare parts
553843500117	KIT-MASTER CYLINDER	TATA spare parts
553843500118	MASTER CYLINDER ASSY	TATA spare parts
553846607701	SEAL	TATA spare parts
553846996502	LOCK NUT BS6	TATA spare parts
553849100113	FRONT PIPE ASSY WITH FLEXIBLE BELLOW	TATA spare parts
553849100115	PIPE ASSY;FRONT WITH FLEXIBLE BELLOW	TATA spare parts
553854600111	WIRING HARNESS CABIN	TATA spare parts
553854600117	BATTERY CABLE +VE	TATA spare parts
553854600119	WIRING HARNESS CHASSIS	TATA spare parts
553854600120	WIRING HARNESS CABIN	TATA spare parts
553854600121	WIRING HARNESS ENGINE	TATA spare parts
553854600124	WIRING HARNESS;EMS	TATA spare parts
553854600193	WIRING HARNESS CABIN	TATA spare parts
553854600195	WIRING HARNESS CHASSIS	TATA spare parts
553854600199	WIRING HARNESS CABIN	TATA spare parts
553854601616	WIRING HARNESS;CHASSIS	TATA spare parts
553854601617	WIRING HARNESS EMS	TATA spare parts
553854601623	WIRING HARNESS CABIN	TATA spare parts
553854601624	WIRING HARNESS EMS	TATA spare parts
553854601625	WIRING HARNESS CHASSIS	TATA spare parts
553854601629	WIRING HARNESS CABIN	TATA spare parts
553854601630	WIRING HARNESS CHASSIS	TATA spare parts
553854601646	WIRING HARNESS;CABIN	TATA spare parts
553854601647	WIRING HARNESS CABIN	TATA spare parts
553854610103	WIRING HARNESS CHASSIS	TATA spare parts
553854700105	ECU,VEHICLE TRACKING ASSY	TATA spare parts
553854709902	WHEEL SPEED SENSOR	TATA spare parts
553854900102	BRACKET ASSY ECU EMS MTG	TATA spare parts
553860000116BF	ASSY BODY SHELL ARCTIC_WHITE- SUPERACE	TATA spare parts
553868900101	FLOOR CONSOLE ASSY	TATA spare parts

553883600109	DISCHARGE PIPE COMPRESSOR END	TATA spare parts
553883600110	DISCHARGE HOSE ASSY	TATA spare parts
553883600111	SUCTION PIPE COMPRESSOR END	TATA spare parts
553883600112	SUCTION HOSE ASSY	TATA spare parts
553931000102	FRAME ASSY WITH FITMENT	TATA spare parts
553933000101	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
553941100101	PROPELLER SHAFT ASSY BS6	TATA spare parts
553954600101	WIRING HARNESS TAIL	TATA spare parts
554013	CLIP	TATA spare parts
5540130	CLAMP TUBE	TATA spare parts
554115400102	ALTERNATOR 12V 120A LIN BS6-PH2	TATA spare parts
55412031000R20	STAGE ROLL OUT CHASSIS DC 4X2 AT	TATA spare parts
554131000101	FRAME ASSY	TATA spare parts
554131000103	FRAME ASSY	TATA spare parts
554142700106	PARKING BRAKE CABLE ASSY REAR BS6	TATA spare parts
554142700108	PARKING BRAKE CABLE ASSY REAR BS6-PH2	TATA spare parts
554143800102	TUBE ASSY T-CONN TO FRONT BRAKE HOSE LH	TATA spare parts
554143800103	TUBE ASSY T-CONN TO FRONT BRAKE HOSE RH	TATA spare parts
554143800104	TUBE ASSY TMC PRIMARY TO ADAPTER BS6	TATA spare parts
554143800105	TUBE ASSY ADAPTER TO REAR HOSE BS6	TATA spare parts
554143800106	TUBE ASSY T-CONN TO FRONT BRAKE HOSE LH	TATA spare parts
554143800107	TUBE ASSY T-CONN TO FRONT BRAKE HOSE RH	TATA spare parts
554143800108	TUBE ASSY ADAPTER TO REAR HOSE BS6-PH2	TATA spare parts
554143800109	TUBE ASSY ADAPTER TO REAR HOSE BS6-PH2	TATA spare parts
554147600101	FUEL SUCTION PIPE ASSY	TATA spare parts
554147600102	FUEL RETURN PIPE ASSY	TATA spare parts
554147600107	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554147600108	FUEL RETURN PIPE ASSY BS6	TATA spare parts
554147605801	FUEL FILLER HOSE	TATA spare parts
554147605804	FUEL FILLER HOSE BS6	TATA spare parts
554154500101	WINDOW WINDING SWITCH REAR DOOR RH	TATA spare parts
554154700103	BRACKET ASSY BCM MTG	TATA spare parts
554154710101	BRACKET ASSY TELEMATICS UNIT MTG BS6-PH2	TATA spare parts
55416360M10113	BODY SIDE ASSY INNER PANEL LH BS6-PH2	TATA spare parts
55416360M10114	BODY SIDE ASSY INNER PANEL RH BS6-PH2	TATA spare parts
55416370M10106	BODY SIDE ASSY OUTER-RH BS6-PH2	TATA spare parts
55416370M10107	OUTER PANEL ASSY BODY SIDE LH BS6-PH2	TATA spare parts
55416470M10103	REAR WALL ASSY BS6-PH2	TATA spare parts
554170000102BF	LOAD BODY ASSY BS6	TATA spare parts
55417320M10142	DOOR SHELL ASSY REAR DOOR LH BS6-PH2	TATA spare parts
55417320M10144	REAR DOOR ASSY WITH HINGE LH BS6-PH2	TATA spare parts
55417320M10145	REAR DOOR ASSY WITH HINGE RH BS6-PH2	TATA spare parts
5541D9Y0160002BF	PAINTED BODY SHELL-MFGBS6-PH2	TATA spare parts
5541D9Y0160003BF	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
554454203201	BOLT -WHEEL RH BS6-PH2	TATA spare parts
554515100101	STARTER MOTOR ASSY	TATA spare parts
554515100102	FIXING BRKT. ASSY.	TATA spare parts

554515100103	C.E. BRKT ASSY	TATA spare parts
554515100105	ARMATURE ASSY BS6	TATA spare parts
554515100106	BRUSH GEAR ASSY BS6	TATA spare parts
554515100110	ANNULUS ASSY BS6	TATA spare parts
554515105401	ANNULUS BS6	TATA spare parts
554515107101	COVER PLATE BS6	TATA spare parts
554515400101	ALTERNATOR	TATA spare parts
554515400102	ALTERNATOR WITH INTERNAL FAN	TATA spare parts
554515400103	D.E BRACKET ASSY	TATA spare parts
554515400104	ROTOR ASSY BS6-PH2	TATA spare parts
554515400105	STATOR ASSY.	TATA spare parts
554515400106	BRACKET ALTERNATOR BS6-PH2	TATA spare parts
554515400107	RECTIFIER ARRANGEMENT BS6-PH2	TATA spare parts
554515400109	BEARING ASSY KIT	TATA spare parts
554515400110	KIT-FASTENER	TATA spare parts
554515400115	BEARING ASSY KIT BS6-PH2	TATA spare parts
554515400117	REGULATOR ASSY BS6-PH2	TATA spare parts
554515400118	ALTERNATOR 12V 90A LIN BS6-PH2	TATA spare parts
554515400119	ALTERNATOR 12V 90A LIN BS6-PH2	TATA spare parts
554515400121	ALTERNATOR 12V 90A WITH 5 GROOVE PULLEY	TATA spare parts
554515400143	BRACKET ASSY BS6-PH2	TATA spare parts
554515400144	STATOR ASSY BS6-PH2	TATA spare parts
554515400145	ROTOR BS6-PH2	TATA spare parts
554515400146	RECTIFIER ASSY BS6-PH2	TATA spare parts
554515401607	HEAT SHIELD ALTERNATOR	TATA spare parts
554515401608	HEAT SHIELD ALTERNATOR	TATA spare parts
554515404901	REGULATOR ASSY	TATA spare parts
554515404902	RECTIFIER ARRNG.	TATA spare parts
554515404903	S.R.E BRACKET ASSY	TATA spare parts
554515404904	REGULATOR ASSY FINAL	TATA spare parts
554515407001	PULLEY	TATA spare parts
554515407002	PULLEY	TATA spare parts
554515407901	STATOR ASSY	TATA spare parts
554515407902	ROTOR ASSY.	TATA spare parts
554515408201	D.E FAN	TATA spare parts
554515409901	REAR COVER	TATA spare parts
554515409902	KIT-FASTENER	TATA spare parts
554515409923	SLIDING BUSH BS6-PH2	TATA spare parts
554515409924	COVER REAR BS6-PH2	TATA spare parts
554515409925	SCREW BS6-PH2	TATA spare parts
554515409926	NUT BS6-PH2	TATA spare parts
554515409927	WASHER BS6-PH2	TATA spare parts
554516204901	ECU BS6	TATA spare parts
554516204903	ECU BS6	TATA spare parts
554516261601	INSTRUMENT CLUSTER ASSY BS6-PH2	TATA spare parts
554516262001	INSTRUMENT CLUSTER INTERFACE HARDWARE BS6-PH2	TATA spare parts
554524000101	REAR MOUNT ASSY BS6	TATA spare parts

554524000104	C-MOUNT ASSY ENGINE	TATA spare parts
554524000106	RUBBER STOPPER ASSY	TATA spare parts
554524000109	BRACKET ASSY B-MOUNT	TATA spare parts
554524100107	ENGINE MOUNT ASSY FRONT BS6	TATA spare parts
554524100108	RUBBER BUSH ASSY	TATA spare parts
554524100112	BRACKET ASSY C-MOUNT BS6	TATA spare parts
554524100113	A-MOUNT ASSY BS6	TATA spare parts
554524100117	A-MOUNT ASSY BS6-PH2	TATA spare parts
554524103801	BRACKET C-MOUNT	TATA spare parts
554524103804	BRACKET B-MOUNT	TATA spare parts
554524103805	BRACKET C-MOUNT BS6	TATA spare parts
554524103806	BRACKET C-MOUNT BS6-PH2	TATA spare parts
554524200101	B-MOUNT ASSY	TATA spare parts
554524200102	B-MOUNT ASSY BS6	TATA spare parts
554524200104	ENGINE MOUNT ASSY REAR BS6	TATA spare parts
554524200106	STOPPER ASSY B-MOUNT BS6	TATA spare parts
554524203801	BRACKET B-MOUNT BS6-PH2	TATA spare parts
554524203802	BRACKET B-MOUNT BS6	TATA spare parts
554524206501	BOSS BS6	TATA spare parts
554524207702	RUBBER PAD	TATA spare parts
554529100102	CLUTCH PEDAL ASSY WITH BUSH	TATA spare parts
554529100103	CLUTCH CABLE ASSY	TATA spare parts
554529100105	BRACKET ASSY CLUTCH CABLE GUIDE	TATA spare parts
554529100108	CLUTCH CABLE ASSY	TATA spare parts
554529100109	CLUTCH CABLE ASSY	TATA spare parts
554529100113	HOOK ASSY CLUTCH CABLE MTG	TATA spare parts
554529100117	BRACKET ASSY CLUTCH CABLE GUIDE BS6	TATA spare parts
554529100121	CLUTCH PEDAL ASSY WITH BUSH	TATA spare parts
554529100124	CLUTCH CABLE ASSY BS6	TATA spare parts
554529100126	CLUTCH PEDAL ASSY WITH BUSH BS6	TATA spare parts
554529100130	CLUTCH PEDAL ASSY WITH BUSH BS6-PH2	TATA spare parts
554529100134	CLUTCH RELEASE LEVER ARRANGEMENT ASSY BS	TATA spare parts
554529100135	BRACKET ASSY CLUTCH CABLE GUIDE BS6	TATA spare parts
554529100137	CLUTCH PEDAL ASSY WITH BUSH	TATA spare parts
554529100138	CLUTCH CABLE ASSY BS6-PH2	TATA spare parts
554529101604	CLUTCH CABLE ASSY	TATA spare parts
554529107701	PACKING FOAM	TATA spare parts
554529108701	SPRING	TATA spare parts
554529108702	TORSION SPRING CLUTCH PEDAL	TATA spare parts
554529109201	PLASTIC WASHER BS6	TATA spare parts
554529200113	BRACKET ASSY CONTROL MTG	TATA spare parts
554529200114	BRACKET ASSY CLUTCH & BRAKE PEDAL MTG	TATA spare parts
554529200117	BRAKE PEDAL ASSY WITH BUSH	TATA spare parts
554529200136	BRACKET ASSY CONTROL MTG	TATA spare parts
554529200141	BRACKET ASSY CLUTCH - BRAKE PEDAL MTG	TATA spare parts
554529200142	BRAKE PEDAL ASSY WITH BUSH	TATA spare parts
554529200150	BRAKE PEDAL ASSY WITH BUSH	TATA spare parts

554529200154	BRAKE PEDAL ASSY WITH BUSH BS6	TATA spare parts
554529200169	BRAKE PEDAL ASSY WITH BUSH BS6-PH2	TATA spare parts
554529200172	BRACKET ASSY CONTROL MTG BS6-PH2	TATA spare parts
554529200173	BRKT ASSY CLUTCH & BR PEDAL MTG BS6-PH2	TATA spare parts
554529200186	BRAKE PEDAL ASSY WITH BUSH BS6-PH2	TATA spare parts
554529203314	BRACKET CLUTCH CABLE MTG	TATA spare parts
554529208601	SPACER	TATA spare parts
554529208602	SPACER BS6-PH2	TATA spare parts
554529500108	BRACKET ASSY BRAKE & CLUTCH CONTROL MTG	TATA spare parts
554529500119	BRACKET ASSY CONTROL MTG BS6-PH2	TATA spare parts
554529500120	BRACKET ASSY CLUTCH & BRAKE PEDAL MTG BS	TATA spare parts
554529503309	BRACKET CLUTCH CABLE MTG BS6-PH2	TATA spare parts
554529504201	CLAMP CLUTCH CABLE BS6-PH2	TATA spare parts
554530100102	ACCELERATOR PEDAL MODULE	TATA spare parts
554530100110	ACCELERATOR PEDAL MODULE	TATA spare parts
554530100112	ACCELERATOR PEDAL MODULE BS6	TATA spare parts
554531000110	FRAME ASSY BS6	TATA spare parts
554531000124	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
554531000127	FRAME ASSY W/O TOP COAT BS6-PH2	TATA spare parts
554531000129	FRAME ASSY WITH TOP COAT BS6-PH2	TATA spare parts
554531000134	FRAME ASSY WITH TOP COAT BS6-PH2	TATA spare parts
554531000201	FRAME ASSY	TATA spare parts
554531000205	FRAME ASSY WITH TOP COAT	TATA spare parts
554531000206	FRAME ASSY	TATA spare parts
554531000208	FRAME ASSY	TATA spare parts
554531000209	FRAME ASSY WITH TOP COAT	TATA spare parts
554531000210	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
554531000212	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
554531100105	BRACKET ASSY BUMP STOPPER REAR	TATA spare parts
554531107101	PLATE SHOCK ABSORBER MTG REAR	TATA spare parts
554531108230	REINFORCEMENT INNER-RH	TATA spare parts
554531108231	REINFORCEMENT OUTER-RH	TATA spare parts
554531108232	REINFORCEMENT OUTER-LH	TATA spare parts
554531108233	REINFORCEMENT INNER-LH	TATA spare parts
554531130105	BATTERY TRAY ASSY BS6-PH2	TATA spare parts
554531200103	CROSS MEMBER ASSY SUSPNESION MTG REAR	TATA spare parts
554531200106	CROSS MEMBER ASSY-FRONT CYLINDER-REAR BS	TATA spare parts
554531200114	CROSS MEMBER ASSY-REAR CYLINDER-FRONT BS	TATA spare parts
554531200117	CROSS MEMBER ASSY ENGINE MTG	TATA spare parts
554531200118	CROSS MEMBER ASSY REAR CYLINDER REAR BS6	TATA spare parts
554531200121	CROSS MEMBER ASSY FRONT	TATA spare parts
554531200124	CROSS MEMBER ASSY FUEL TANK MTG	TATA spare parts
554531200135	CROSS MEMBER ASSY FRONT	TATA spare parts
554531200137	CROSS MEMBER ASSY BS6	TATA spare parts
554531200148	CROSS MEMBER ASSY	TATA spare parts
554531200150	CROSS MEMBER ASSY REAR SPIRNG FRONT BS6	TATA spare parts
554531200153	CROSS MEMBER ASSY GEAR BOX MTG BS6	TATA spare parts

554531200155	CROSS MEMBER ASSY 2ND BS6	TATA spare parts
554531200178	CROSS MEMBER ASSY FRONT BS6	TATA spare parts
554531200179	CROSS MEMBER ASSY BS6	TATA spare parts
554531200180	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
554531200181	CROSS MEMBER ASSY-FUEL TANK MTG BS6	TATA spare parts
554531220101	BRACKET ASSY AIR FILTER MTG	TATA spare parts
554531220116	BRACKET ASSY RADIATOR MTG LH BS6	TATA spare parts
554531220119	BRACKET ASSY RADIATOR MTG RH BS6	TATA spare parts
554531260102	HOOK ASSY BS6	TATA spare parts
554531320115	BRACKET ASSY BUMP STOPPER	TATA spare parts
554531320116	BRACKET ASSY BUMP STOPPER REAR	TATA spare parts
554531326902	SLEEVE REAR SPRING MTG BS6	TATA spare parts
554531460111	BRACKET ASSY-PITMAN ARM STOPPER BS6	TATA spare parts
554531470118	BRACKET ASSY CNG CYLINDER MTG REAR BS6	TATA spare parts
554531470119	BRACKET ASSY CNG CYLINDER MTG REAR BS6	TATA spare parts
554531470120	CROSS MEMBER ASSY FRONT CYLINDER REAR BS	TATA spare parts
554531473311	BRACKET SUPPORT-CROSS MEMBER MTG BS6	TATA spare parts
554531540101	BATTERY TRAY ASSY	TATA spare parts
554531540108	BATTERY TRAY ASSY	TATA spare parts
554531543323	BRACKET BATTERY CLAMP MTG BS6-PH2	TATA spare parts
554531700108	BRACKET ASSY TAIL LAMP MTG RH BS6	TATA spare parts
554531890108	BRACKET ASSY LOAD BODY MTG BS6	TATA spare parts
554531890119	BRACKET ASSY BODY MTG REAR BS6	TATA spare parts
554531890129	BRACKET ASSY-LOAD BODY MTG BS6	TATA spare parts
554531893334	SUPPORT BRACKET CAB STRUCTURE LH BS6	TATA spare parts
554531893401	WASHER FRONT & REAR BIW MTG BS6	TATA spare parts
554531990101	KIT-BRACKET REINFORCEMENT FRAME	TATA spare parts
554532100114	BRACKET ASSY SPRING HANGER FRONT LH (FR	TATA spare parts
554532100115	BRACKET ASSY SPRING HANGER FRONT RH (FR	TATA spare parts
554532100122	BUMP STOPPER ASSY FRONT BS6	TATA spare parts
554532100124	LEAF SPRING ASSY FRONT	TATA spare parts
554532100125	1ST LEAF ASSY WITH BUSH	TATA spare parts
554532100126	CLAMP ASSY	TATA spare parts
554532100132	BUMP STOPPER ASSY FRONT	TATA spare parts
554532100133	BUMP STOPPER ASSY FRONT BS6	TATA spare parts
554532100141	LEAF SPRING ASSY FRONT BS6-PH2	TATA spare parts
554532100143	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
554532100146	1ST LEAF ASSY WITH BUSH FRONT BS6-PH2	TATA spare parts
554532100149	LEAF SPRING ASSY FRONT BS6-PH2	TATA spare parts
554532100151	LEAF SPRING ASSY FRONT	TATA spare parts
554532100152	1ST LEAF ASSY WITH BUSH	TATA spare parts
554532100161	LEAF SPRING ASSY FRONT	TATA spare parts
554532100162	1ST LEAF ASSY WITH BUSH	TATA spare parts
554532100165	GUIDE PLATE ASSY	TATA spare parts
554532103201	CENTER BOLT	TATA spare parts
554532104201	U-CLAMP FRONT SPRING	TATA spare parts
554532104208	U-CLAMP FRONT BS6	TATA spare parts



554532107102	6TH LEAF	TATA spare parts
554532107103	PLATE	TATA spare parts
554532107109	2ND LEAF	TATA spare parts
554532107111	2ND LEAF	TATA spare parts
554532107112	3RD LEAF	TATA spare parts
554532107113	4TH LEAF	TATA spare parts
554532107114	5TH LEAF	TATA spare parts
554532107128	2ND LEAF BS6-PH2	TATA spare parts
554532107130	3RD LEAF BS6-PH2	TATA spare parts
554532107132	4TH LEAF BS6-PH2	TATA spare parts
554532107133	2ND LEAF BS6-PH2	TATA spare parts
554532107161	2ND LEAF	TATA spare parts
554532107162	3RD LEAF	TATA spare parts
554532107163	4TH LEAF	TATA spare parts
554532107164	5TH LEAF	TATA spare parts
554532107706	TIP INSERT	TATA spare parts
554532108206	BRACKET BUMP STOPPER RH BS6	TATA spare parts
554532108207	BRACKET BUMP STOPPER LH BS6	TATA spare parts
554532108217	PLATE FRONT SPRING MTG REAR-LH	TATA spare parts
554532108218	PLATE FRONT SPRING MTG REAR-LH	TATA spare parts
554532108219	PLATE FRONT SPRING MTG REAR-LH	TATA spare parts
554532108220	PLATE FRONT SPRING MTG REAR-RH	TATA spare parts
554532108603	CENTER PAD	TATA spare parts
554532204201	U-CLAMP FRONT BS6	TATA spare parts
554532204202	U-CLAMP FRONT	TATA spare parts
554532400106	SHACKLE ASSY	TATA spare parts
554532400109	GUIDE PLATE ASSY REAR-LH BS6	TATA spare parts
554532400111	GUIDE PLATE ASSY REAR-RH BS6	TATA spare parts
554532400113	LEAF SPRING ASSY REAR	TATA spare parts
554532400122	LEAF SPRING ASSY	TATA spare parts
554532400123	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
554532400125	CLAMP ASSY	TATA spare parts
554532400126	CLAMP ASSY	TATA spare parts
554532400130	SHACKLE ASSY	TATA spare parts
554532400131	1ST LEAF ASSY WITH BUSH	TATA spare parts
554532400132	LEAF SPRING ASSY REAR	TATA spare parts
554532400136	GUIDE PLATE ASSY REAR-RH	TATA spare parts
554532400142	BUSH ASSY	TATA spare parts
554532400144	BUSH ASSY	TATA spare parts
554532400151	LEAF SPRING ASSY REAR	TATA spare parts
554532400152	1ST LEAF ASSY WITH BUSH	TATA spare parts
554532400153	GUIDE PLATE ASSY;REAR-LH	TATA spare parts
554532400154	GUIDE PLATE ASSY;REAR-RH	TATA spare parts
554532400156	GUIDE PLATE ASSY	TATA spare parts
554532400161	LEAF SPRING ASSY REAR	TATA spare parts
554532400162	1ST LEAF ASSY WITH BUSH	TATA spare parts
554532400163	LEAF SPRING ASSY REAR BS6	TATA spare parts

554532400164	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
554532400166	LEAF SPRING ASSY REAR BS6-PH2	TATA spare parts
554532400168	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
554532400171	MAIN LEAF ASSY WITH BUSH	TATA spare parts
554532400176	GUIDE PLATE ASSY BS6-PH2	TATA spare parts
554532401610	BUSH LEAF SPRING BS6	TATA spare parts
554532403304	GUIDE PLATE	TATA spare parts
554532403307	GUIDE PLATE FRONT	TATA spare parts
554532404204	U-CLAMP REAR	TATA spare parts
554532404206	U-BOLT;REAR	TATA spare parts
554532404209	U-CLAMP REAR	TATA spare parts
554532404213	U-CLAMP REAR BS6-PH2	TATA spare parts
554532406901	SLEEVE DAMPER MTG BS6	TATA spare parts
554532407105	CASTER PLATE BS6-PH2	TATA spare parts
554532407106	7TH LEAF	TATA spare parts
554532407111	2ND LEAF	TATA spare parts
554532407112	3RD LEAF	TATA spare parts
554532407117	1ST LEAF BS6	TATA spare parts
554532407118	2ND LEAF BS6	TATA spare parts
554532407119	3RD LEAF BS6	TATA spare parts
554532407120	4TH LEAF BS6	TATA spare parts
554532407121	5TH LEAF BS6	TATA spare parts
554532407125	5TH LEAF	TATA spare parts
554532407126	2ND LEAF	TATA spare parts
554532407128	4TH LEAF	TATA spare parts
554532407129	3RD LEAF	TATA spare parts
554532407143	1ST LEAF BS6	TATA spare parts
554532407144	2ND LEAF BS6	TATA spare parts
554532407145	3RD LEAF BS6	TATA spare parts
554532407146	4TH LEAF BS6	TATA spare parts
554532407148	2ND LEAF BS6-PH2	TATA spare parts
554532407149	3RD LEAF BS6-PH2	TATA spare parts
554532407150	4TH LEAF BS6-PH2	TATA spare parts
554532407151	5TH LEAF BS6-PH2	TATA spare parts
554532407153	6TH LEAF BS6-PH2	TATA spare parts
554532407161	2ND LEAF	TATA spare parts
554532407162	3RD LEAF	TATA spare parts
554532407163	4TH LEAF	TATA spare parts
554532407164	5TH LEAF	TATA spare parts
554532407165	6TH LEAF	TATA spare parts
554532407167	2ND LEAF	TATA spare parts
554532407702	TIP INSERT	TATA spare parts
554532408602	CENTER PAD	TATA spare parts
554532500101	BUMP STOPPER ASSY REAR	TATA spare parts
554532500102	GUIDE PLATE ASSY	TATA spare parts
554532600101	SHOCK ABSORBER ASSY REAR	TATA spare parts
554532600102	SHOCK ABSORBER ASSY REAR	TATA spare parts

554532800101	ANTI ROLL BAR ASSY FRONT	TATA spare parts
554532800103	ANTI ROLL BAR ASSY WITH LINK	TATA spare parts
554532800107	LINK ASSY ANTI ROLL BAR	TATA spare parts
554532800109	ANTI ROLL BAR ASSY WITH CRIMPED WASHER B	TATA spare parts
554532800118	LINK ASSY ANTI ROLL BAR BS6-PH2	TATA spare parts
554532800119	ANTI ROLL BAR ASSY FRONT BS6-PH2	TATA spare parts
554532806902	SLEEVE ANTI ROLL BAR	TATA spare parts
554532807701	RUBBER BUSH ANTI ROLL BAR	TATA spare parts
554532807703	BUSH ANTI ROLL BAR BS6-PH2	TATA spare parts
554532807704	BUSH ANTI ROLL BAR MTG UPPER BS6-PH2	TATA spare parts
554532807904	ANTI ROLL BAR FRONT BS6-PH2	TATA spare parts
554533000102	FRONT AXLE TUBE ASSY BS6	TATA spare parts
554533000103	FRONT AXLE TUBE ASSY	TATA spare parts
554533000104	FRONT AXLE ASSY	TATA spare parts
554533000112	FRONT AXLE ASSY	TATA spare parts
554533000113	FRONT AXLE TUBE ASSY BS6	TATA spare parts
554533000115	FRONT AXLE TUBE ASSY	TATA spare parts
554533000116	FRONT AXLE	TATA spare parts
554533000117	FRONT AXLE ASSY BS6	TATA spare parts
554533000123	FRONT AXLE ASSY BS6	TATA spare parts
554533000129	FRONT AXLE ASSY BS6	TATA spare parts
554533000133	FRONT AXLE ASSY BS6	TATA spare parts
554533103701	FRONT HUB	TATA spare parts
554533200109	STUB AXLE ASSY LH BS6	TATA spare parts
554533200110	STUB AXLE ASSY RH	TATA spare parts
554533200113	STUB AXLE ASSY BS6	TATA spare parts
554533200114	STUB AXLE ASSY RH BS6	TATA spare parts
554533200121	STUB AXLE ASSY RH BS6-PH2	TATA spare parts
554533200122	STUB AXLE ASSY LH BS6-PH2	TATA spare parts
554533200125	STUB AXLE ASSY RH BS6	TATA spare parts
554533205105	STUB AXLE RH	TATA spare parts
554533205106	STUB AXLE LH	TATA spare parts
554533208602	SHIM BS6-PH2	TATA spare parts
554533400112	FRONTHUBASSYWITHBEARING- BS6	TATA spare parts
554533400113	BEARINGASSY FRONT- BS6	TATA spare parts
554533400121	BEARING ASSY FRONT BS6-PH2	TATA spare parts
554533403702	FRONT HUB BS6-PH2	TATA spare parts
554533405501	FRONT HUB ABS- BS6	TATA spare parts
554533406501	LOCK NUT	TATA spare parts
554533406505	LOCKNUT BS6	TATA spare parts
554533406506	LOCK NUT BS6-PH2	TATA spare parts
554533408201	CAP FRONT HUB	TATA spare parts
554533408205	SEALING RING BS6	TATA spare parts
554533408206	SEALING RING BS6-PH2	TATA spare parts
554533800105	TIE ROD ASSY	TATA spare parts
554533800106	BALL JOINT ASSY RH	TATA spare parts
554533800107	BALL JOINT ASSY LH	TATA spare parts

554533805102	STEERING ARM	TATA spare parts
554533805107	STEERING ARM	TATA spare parts
554533805110	STEERING ARM BS6	TATA spare parts
554533805111	STEERING ARM BS6	TATA spare parts
554533806501	LOCK NUT RH BS6	TATA spare parts
554540100101	WHEEL RIM COVER ASSY	TATA spare parts
554540100102	WHEEL RIM COVER ASSY	TATA spare parts
554540100105	WHEEL RIM ASSY	TATA spare parts
554540100106	WHEEL RIM ASSYBS6	TATA spare parts
554540100110	WHEEL RIM ASSY BS6	TATA spare parts
554540100111	WHEEL RIM ASSY	TATA spare parts
554540109901	TUBELESS TYRE,FRONT 165 R14	TATA spare parts
554540109902	"TUBELESS TYRE,FRONT"	TATA spare parts
554540109903	"TUBELESS TYRE,FRONT"	TATA spare parts
554540109913	TUBELESS TYRE	TATA spare parts
554540203201	BOLT WHEEL	TATA spare parts
554540203202	BOLT WHEEL MOUNTING	TATA spare parts
554540300101	TUBE ASSY SPARE WHEEL CARRIER BS6	TATA spare parts
554540300104	TUBE ASSY SPARE WHEEL CARRIER	TATA spare parts
554540300113	TUBE ASSY SPARE WHEEL CARRIER BS6-PH2	TATA spare parts
554540306701	PIN SPARE WHEEL MTG	TATA spare parts
554540306907	CLAMP SPARE WHEEL MTG BS6	TATA spare parts
554540309901	NYLON INSERT BS6	TATA spare parts
554541100101	PROPELLER SHAFT ASSY	TATA spare parts
554541100103	PROPELLER SHAFT ASSY	TATA spare parts
554541100105	PROPELLER SHAFT ASSY	TATA spare parts
554541100107	SLIPYOKEASSY	TATA spare parts
554541100108	CROSSASSY	TATA spare parts
554541100109	PROPELLER SHAFT ASSY	TATA spare parts
554541100110	PROPELLER SHAFT ASSY	TATA spare parts
554541100111	PROPELLER SHAFT ASSY	TATA spare parts
554541100119	PROPELLER SHAFT ASSY	TATA spare parts
554541100120	PROPELLER SHAFT ASSY BS6	TATA spare parts
554541100121	PROPELLER SHAFT ASSY BS6	TATA spare parts
554541100124	CROSSASSY BS6	TATA spare parts
554541100124DF	UJ CROSS 22DIAX55 - ACE/MAGIC BS3/4	TATA spare parts
554541100125	PROPELLER SHAFT ASSY BS6	TATA spare parts
554541100128	PROPELLER SHAFT ASSY BS6-PH2	TATA spare parts
554541100129	PROPELLER SHAFT ASSY BS6-PH2	TATA spare parts
554541100133	LONG FORK ASSY BS6-PH2	TATA spare parts
554541103701	FLANGEYOKE	TATA spare parts
554541108201	BRACKET C-MOUNT	TATA spare parts
554541990101	KIT-SLIP YOKE ASSY	TATA spare parts
554542100103	CALIPER ASSY FRONT-RH	TATA spare parts
554542100104	CALIPER ASSY FRONT-LH	TATA spare parts
554542100105	KIT-CARRIER ASSY	TATA spare parts
554542100108	KIT-PAD	TATA spare parts

554542100109	CALIPER ASSY LH	TATA spare parts
554542100110	CALIPER ASSY RH	TATA spare parts
554542100113	CALIPER ASSY FRONT-LH	TATA spare parts
554542100114	CALIPER ASSY FRONT-RH	TATA spare parts
554542100119	CALIPER ASSY FRONT-LH BS6	TATA spare parts
554542100120	CALIPER ASSY FRONT-RH BS6	TATA spare parts
554542300109	DRUMBRAKEASSY REAR-LH	TATA spare parts
554542300110	DRUMBRAKEASSY REAR-RH	TATA spare parts
554542300112	MINOR- KIT WHEEL CYLINDER ASSY (CONSISTS	TATA spare parts
554542300113	ADJUSTER ASSY LH	TATA spare parts
554542300114	ADJUSTER ASSY RH	TATA spare parts
554542300115	WHEEL CYLINDER ASSY	TATA spare parts
554542300118	DRUM BRAKE ASSY REAR-LH	TATA spare parts
554542300119	DRUM BRAKE ASSY REAR-RH	TATA spare parts
554542300122	DRUM BRAKE ASSY REAR-LH	TATA spare parts
554542300123	DRUM BRAKE ASSY REAR-RH	TATA spare parts
554542300124	KIT-LINED SHOE(CONSISTS OF)	TATA spare parts
554542300129	DRUM BRAKE ASSY REAR-LH	TATA spare parts
554542300130	DRUM BRAKE ASSY REAR-RH	TATA spare parts
554542300131	WHEEL CYLINDER ASSY	TATA spare parts
554542300135	DRUM BRAKE ASSY REAR-LH BS6	TATA spare parts
554542300136	DRUM BRAKE ASSY REAR-RH BS6	TATA spare parts
554542303701	BRAKE DRUM	TATA spare parts
554542303702	BRAKE DRUM BS6-PH2	TATA spare parts
554542700105	PARKING BRAKE LEVER ASSY WITH GRIP	TATA spare parts
554542700107	PARKING BRAKE CABLE ASSY REAR RH	TATA spare parts
554542700108	PARKING BRAKE CABLE ASSY REAR LH	TATA spare parts
554542700109	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
554542700110	PARKING BRAKE CABLE ASSY REAR-LH	TATA spare parts
554542700111	PARKING BRAKE CABLE ASSY REAR-RH	TATA spare parts
554542700118	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
554542700119	PARKING BRAKE CABLE ASSY REAR	TATA spare parts
554542700120	PARKING BRAKE CABLE ASSY FRONT BS6-PH2	TATA spare parts
554542700121	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
554542700122	PARKING BRAKE CABLE ASSY FRONT BS6	TATA spare parts
554542700124	PARKING BRAKE CABLE ASSY REAR BS6	TATA spare parts
554542700133	BRACKET ASSY PARKING BRAKE LEVER	TATA spare parts
554542700140	PARKING BRAKE CABLE ASSY REAR-LH BS6	TATA spare parts
554542700141	PARKING BRAKE CABLE ASSY REAR-RH BS6	TATA spare parts
554542700143	PARKING BRAKE CABLE ASSY FRONT BS6	TATA spare parts
554542700144	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
554542700145	PARKINGBRAKELEVERASSY	TATA spare parts
554542700147	PARKING BRAKE CABLE ASSY FRONT BS6	TATA spare parts
554542700148	BRACKET ASSY BS6	TATA spare parts
554542700150	PARKING BRAKE CABLE ASSY REAR-LH	TATA spare parts
554542700151	PARKING BRAKE CABLE ASSY REAR-RH	TATA spare parts
554542700152	PARKING BRAKE CABLE ASSY REAR-LH BS6-PH2	TATA spare parts

554542700153	PARKING BRAKE CABLE ASSY REAR-RH BS6-PH2	TATA spare parts
554542700160	PARKING BRAKE CABLE ASSY REAR-LH BS6-PH2	TATA spare parts
554542700161	PARKING BRAKE CABLE ASSY REAR-RH BS6-PH2	TATA spare parts
554542700163	PARKING BRAKE CABLE ASSY REAR-LH BS6	TATA spare parts
554542700164	PARKING BRAKE CABLE ASSY REAR-RH BS6	TATA spare parts
554542701605	PARKING BRAKE CABLE ASSY FRONT	TATA spare parts
554543100102	REMOTE RESERVOIR ASSY	TATA spare parts
554543103303	BRACKET LCRV MTG	TATA spare parts
554543500102	VACUUM PIPE ASSY	TATA spare parts
554543500103	VACUUM PIPE ASSY BS6	TATA spare parts
554543500106	VACUUM PIPE ASSY	TATA spare parts
554543500110	VACUUM HOSE ASSY ENGINE END	TATA spare parts
554543500111	VACUUM HOSE ASSY	TATA spare parts
554543500112	VACUUM HOSE ASSY	TATA spare parts
554543500114	VACUUM PIPE BOOSTER END BS6	TATA spare parts
554543500116	VACUUM BOOSTER ASSY	TATA spare parts
554543500117	VACUUM PIPE ENGINE END BS6	TATA spare parts
554543500125	MAJOR KIT - MASTER CYLINDER	TATA spare parts
554543500126	KIT - ADAPTER	TATA spare parts
554543500127	VACUUM BOOSTER ASSY	TATA spare parts
554543500128	KIT - SERVO UNIT	TATA spare parts
554543500129	MASTER CYLINDER ASSY	TATA spare parts
554543500132	KIT - SERVO UNIT	TATA spare parts
554543500133	SERVO UNIT ASSY	TATA spare parts
554543500139	VACUUM PIPE ASSY	TATA spare parts
554543500141	VACUUM HOSE ASSY ENGINE END BS6	TATA spare parts
554543500146	VACUUM BOOSTER ASSY BS6-PH2	TATA spare parts
554543500148	VACUUM PIPE ASSY BS6	TATA spare parts
554543500149	VACUUM HOSE ASSY ENGINE END BS6-PH2	TATA spare parts
554543500151	MATSER CYLINDER ASSY	TATA spare parts
554543500152	MC KIT (MINOR)	TATA spare parts
554543500153	MC KIT (MAJOR)	TATA spare parts
554543500154	KIT INLET ADAPTOR	TATA spare parts
554543500168	BOOSTER ASSY BS6-PH2	TATA spare parts
554543500170	BOOSTER ASSY BS6-PH2	TATA spare parts
554543500172	MASTER CYLINDER ASSY BS6-PH2	TATA spare parts
554543500173	MASTER CYLINDER ASSY BS6-PH2	TATA spare parts
554543500174	VACUUM PIPE ASSY BS6-PH2	TATA spare parts
554543500175	VACUUM TANK ASSY BS6-PH2	TATA spare parts
554543500180	VACUUM BOOSTER ASSY BS6-PH2	TATA spare parts
554543504201	CLAMP VACUUM PIPE BS6	TATA spare parts
554543504202	CLAMP VACUUM PIPE BS6	TATA spare parts
554543505823	VACUUM HOSE ENGINE SIDE	TATA spare parts
554543505826	VACUUM HOSE BOOSTER END BS6-PH2	TATA spare parts
554543505827	VACUUM HOSE BOOSTER END BS6	TATA spare parts
554543505840	VACUUM HOSE BS6-PH2	TATA spare parts
554543506801	BULKHEAD	TATA spare parts

554543506908	TUBE BS6	TATA spare parts
554543800103	TUBE ASSY T-CONN TO LCRV	TATA spare parts
554543800104	TUBE ASSY ADAPTER TO LCRV	TATA spare parts
554543800105	TUBE ASSY LCRV TO REAR BRAKE HOSE RH	TATA spare parts
554543800107	TUBE ASSY T-CONN TO REAR BRAKE HOSE LH	TATA spare parts
554543800111	BRACKET ASSY TMC COVER MTG BS6	TATA spare parts
554543800115	TUBE ASSY T-CONN TO REAR BRAKE HOSE RH	TATA spare parts
554543800120	TUBE ASSY LCRV TO REAR BRAKE HOSE RH	TATA spare parts
554543800121	TUBE ASSY T-CONN TO LCRV	TATA spare parts
554543800122	TUBE ASSY T-CONN TO LCRV	TATA spare parts
554543800129	TUBE ASSY TMC SECONDARY TO T-CONN	TATA spare parts
554543800130	TUBE ASSY TMC PRIMARY TO T-CONN	TATA spare parts
554543800131	TUBE ASSY T-CONN TO BRAKE HOSE FRT-RH	TATA spare parts
554543800132	TUBE ASSY T-CONN TO BRAKE HOSE FRT-LH	TATA spare parts
554543800133	TUBE ASSY T-CONN TO LCRV	TATA spare parts
554543800134	TUBE ASSY T-CONN TO LCRV	TATA spare parts
554543800135	TUBE ASSY LCRV TO REAR BRAKE HOSE RH	TATA spare parts
554543800136	TUBE ASSY LCRV TO REAR BRAKE HOSE LH	TATA spare parts
554543800137	TUBE ASSY REAR HOSE TO BRAKE ASSY RH	TATA spare parts
554543800138	TUBE ASSY REAR HOSE TO BRAKE ASSY LH	TATA spare parts
554543800141	TUBE ASSY TMC PRIMARY TO T-CONN	TATA spare parts
554543800142	TUBE ASSY TMC SECONDARY TO T-CONN	TATA spare parts
554543800149	TUBE ASSY REAR HOSE TO BRAKE ASSY RH	TATA spare parts
554543800150	TUBE ASSY REAR HOSE TO BRAKE ASSY LH	TATA spare parts
554543800157	TUBE ASSY;T-CONN TO REAR BRAKE HOSE;RH	TATA spare parts
554543800159	TUBE ASSY;T-CONN TO REAR BRAKE HOSE;LH	TATA spare parts
554543800160	TUBE ASSY ADAPTER TO REAR BRAKE HOSE LH	TATA spare parts
554543800163	TUBE ASSY ADAPTER TO REAR BRAKE HOSE RH	TATA spare parts
554543800173	BRAKE HOSE ASSY REAR	TATA spare parts
554543800174	BRAKE HOSE ASSY FRONT	TATA spare parts
554543800178	TUBE ASSY T-CONN TO LCRV BS6-PH2	TATA spare parts
554543800179	TUBE ASSY T-CONN TO LCRV BS6-PH2	TATA spare parts
554543800180	TUBE ASSY T-CONN TO REAR HOSE RH	TATA spare parts
554543800182	TUBE ASSY T-CONN TO REAE BRAKE LH	TATA spare parts
554543800187	TUBE ASSY LCRV TO REAR BRAKE HOSE RH	TATA spare parts
554543800188	TUBE ASSY T-CONN TO LCRV	TATA spare parts
554543800189	TUBE ASSY ADAPTER TO LCRV INLET	TATA spare parts
554543800191	TUBE ASSY T-CONN TO ADAPTER BS6	TATA spare parts
554543800193	TUBE ASSY HOSE TO REAR BRAKE ASSY LH BS6	TATA spare parts
554543800194	TUBE ASSY HOSE TO REAR BRAKE ASSY RH BS6	TATA spare parts
554543800195	TUBE ASSY TMC PRIMERY TO ADAPTER	TATA spare parts
554543800196	TUBE ASSY ADAPTER TO T-CONN LH	TATA spare parts
554543800197	TUBE ASSY TMC SECONDARY TO ADAPTER	TATA spare parts
554543800198	TUBE ASSY ADAPTER TO T-CONN RH	TATA spare parts
554543801601	CLAMP BRAKE PIPES & FUEL PIPES	TATA spare parts
554543803306	BRACKET LCRV MTG AXLE	TATA spare parts
554543803307	BRACKET LSPV MTG REAR AXLE	TATA spare parts

554543803310	BRACKET LCRV MTG AXLE BS6	TATA spare parts
554543803317	BRACKET LCRV MTG AXLE BS6	TATA spare parts
554543804202	CLAMP BRAKE PIPES & FUEL PIPES	TATA spare parts
554543804203	CLAMP	TATA spare parts
554543804204	CLAMP BRAKE PIPES & FUEL PIPES BS6-PH2	TATA spare parts
554543805801	HOSE RESERVOIR TO TMC PRIMARY	TATA spare parts
554543805802	HOSE RESERVOIR TO TMC SECONDARY	TATA spare parts
554543805805	HOSE RESERVOIR TO TMC PRIMARY	TATA spare parts
554543805806	HOSE RESERVOIR TO TMC SECONDARY	TATA spare parts
554543805814	HOSE RESERVOIR TO TMC SECONDARY BS6	TATA spare parts
554543805815	HOSE RESERVOIR TO TMC PRIMARY BS6	TATA spare parts
554543805824	HOSE BS6-PH2	TATA spare parts
554543806802	3-WAY CONNECTOR	TATA spare parts
554543807501	GROMMET	TATA spare parts
554543808203	BRACKET LCRV MTG AXLE	TATA spare parts
554543809201	SEALING WASHER BS6	TATA spare parts
554543810109	TUBE ASSY REAR HOSE TO BRAKE ASSY RH BS6	TATA spare parts
554543810110	TUBE ASSY REAR HOSE TO BRAKE ASSY LH BS6	TATA spare parts
554543810112	TUBE ASSY T-CONN TO LCRV BS6	TATA spare parts
554543810113	TUBE ASSY T-CONN TO LCRV BS6	TATA spare parts
554543810114	TUBE ASSY T-CONN TO LCRV BS6	TATA spare parts
554543810115	TUBE ASSY T-CONN TO LCRV BS6	TATA spare parts
554543810156	TUBE ASSY TMC SECONDARY TO ADAPTER BS6-P	TATA spare parts
554543810157	TUBE ASSY TMC PRIMERY TO ADAPTER BS6-PH2	TATA spare parts
554543810163	TUBE ASSY T-CONN TO LCRV BS6	TATA spare parts
554543810164	TUBE ASSY T-CONN TO LCRV BS6	TATA spare parts
554543810169	TUBE ASSY REAR HOSE TO BRAKE ASSY LH BS6	TATA spare parts
554543810170	TUBE ASSY REAR HOSE TO BRAKE ASSY RH BS6	TATA spare parts
554543810174	TUBE ASSY TMC PRIMARY TO ADAPTER BS6-PH2	TATA spare parts
554543810175	TUBE ASSY TMC SECONDARY TO ADAPTER BS6-P	TATA spare parts
554543990101	KIT-BOOSTER ASSY BS6	TATA spare parts
554543990102	KIT-ADAPTER BS6	TATA spare parts
554543990103	MASTER CYLINDER ASSY BS6	TATA spare parts
554546100103	STEERING COLUMN ASSY WITH I-SHAFT	TATA spare parts
554546100104	STEERING COLUMN ASSY TOP	TATA spare parts
554546100105	INTERMEDIATE SHAFT ASSY STG COLUMN	TATA spare parts
554546100115	STEERING COLUMN ASSY WITH I-SHAFT	TATA spare parts
554546100116	STEERING COLUMN ASSY UPPER	TATA spare parts
554546100117	INTERMEDIATE SHAFT ASSY STG COLUMN	TATA spare parts
554546100118	BELLOW ASSY STG COLUMN	TATA spare parts
554546100120	STEERING COLUMN ASSY EPAS BS6	TATA spare parts
554546100121	EPAS STG COLUMN ASSY WITH I-SHAFT BS6	TATA spare parts
554546100122	EPAS ECU HARDWARE & SOFTWARE - BS6	TATA spare parts
554546100123	STEERING COLUMN ASSY WITH I-SHAFT BS6	TATA spare parts
554546100125	STEERING COLUMN ASSY UPPER BS6	TATA spare parts
554546100129	STEERING COLUMN ASSY WITH I-SHAFT BS6	TATA spare parts
554546100130	INTERMEDIATE SHAFT ASSY BS6	TATA spare parts



554546100131	STEERING COLUMN ASSY EPAS BS6	TATA spare parts
554546100132	EPAS ECU HARDWARE & SOFTWARE	TATA spare parts
554546100133	STEERING COLUMN ASSY UPPER BS6-PH2	TATA spare parts
554546100134	INTERMEDIATE SHAFT ASSY STG COLUMN	TATA spare parts
554546100135	BRACKET ASSY EPAS ECU MTG BS6	TATA spare parts
554546100139	STEERING COLUMN ASSY EPAS BS6	TATA spare parts
554546103304	BRACKET ECU MTG BS6	TATA spare parts
554546106301	DUST COVER	TATA spare parts
554546106306	COVER STG COLUMN BELLOW	TATA spare parts
554546107701	RUBBER BELLOW	TATA spare parts
554546107703	RUBBER BELLOW STG COLUMN	TATA spare parts
554546107707	RUBBER BELLOW STG COLUMN	TATA spare parts
554546107709	RUBBER BELLOW STG COLUMN	TATA spare parts
554546203202	SCREW	TATA spare parts
554546203203	HEX NUT-FLANGE	TATA spare parts
554546208202	COVER SHEET	TATA spare parts
554546400105	STEERING WHEEL	TATA spare parts
554546400106	HORN PAD ASSY WITH T-EMBLEM	TATA spare parts
554546400107	HORN SWITCH ASSY	TATA spare parts
554546401604	STEERING WHEEL ASSY WITH T-EMBLEM	TATA spare parts
554546600106	POWER STEERING GEAR ASSY	TATA spare parts
554546600107	RESERVOIR ASSY WITH BRACKET	TATA spare parts
554546600108	POWER STEERING PUMP ASSY	TATA spare parts
554546600112	CAP ASSY	TATA spare parts
554546600114	BRACKET ASSY	TATA spare parts
554546600115	INPUT SHAFT ASSY	TATA spare parts
554546600122	BRACKET ASSY RESERVOIR MTG	TATA spare parts
554546600123	ASSY. POWER STEERING GEAR BOX BS3/4	TATA spare parts
554546600124	POWER STEERING PUMP ASSY	TATA spare parts
554546600125	WORM & VALVE HSG WITH RACK ASSY	TATA spare parts
554546600126	HOUSING ASSY	TATA spare parts
554546600127	SECTOR SHAFT ASSY	TATA spare parts
554546600128	FLOW CUM RELIEF VALVE ASSY BS6	TATA spare parts
554546600129	WORM & VALVE HSG ASSY	TATA spare parts
554546600136	POWER STEERING GEAR ASSY	TATA spare parts
554546600137	POWER STEERING PUMP ASSY	TATA spare parts
554546600138	CARTRIDGE ASSY BS6	TATA spare parts
554546600139	WORM & VALVE HSG WITH RACK ASSY	TATA spare parts
554546600140	WORM & VALVE HSG ASSY	TATA spare parts
554546600141	HOUSING ASSY	TATA spare parts
554546600142	SECTOR SHAFT ASSY	TATA spare parts
554546600143	BEVEL GEAR ASSY	TATA spare parts
554546600148	POWER STEERING GEAR ASSY	TATA spare parts
554546600151	WORM & VALVE HSG WITH RACK ASSY	TATA spare parts
554546600152	WORM & VALVE HSG ASSY	TATA spare parts
554546600153	HOUSING ASSY	TATA spare parts
554546600154	SECTOR SHAFT ASSY	TATA spare parts

554546600155	POWER STEERING PUMP ASSY	TATA spare parts
554546600156	STEERING GEAR BOX ASSY WITH PITMAN ARM B	TATA spare parts
554546600157	POWER STEERING PUMP ASSY	TATA spare parts
554546600158	POWER STEERING GEAR ASSY	TATA spare parts
554546600166	BEVELGEARASSY BS6	TATA spare parts
554546600177	WORM&NUTASSY BS6	TATA spare parts
554546600188	BOX ASSY BS6	TATA spare parts
554546600189	ROCKERSHAFT BS6	TATA spare parts
554546600192	COVERPLATEASSY BS6	TATA spare parts
554546603001	BALL	TATA spare parts
554546603101	NEEDLE BEARING	TATA spare parts
554546603201	BOLT	TATA spare parts
554546603203	BOLT	TATA spare parts
554546603206	BOLT	TATA spare parts
554546604201	CLAMP	TATA spare parts
554546604701	SIDE COVER	TATA spare parts
554546604702	SIDE COVER	TATA spare parts
554546605102	DROP ARM	TATA spare parts
554546605105	DROP ARM	TATA spare parts
554546605108	PITMAN ARM	TATA spare parts
554546605109	DROPARM BS6	TATA spare parts
554546606505	LOCKNUT BS6	TATA spare parts
554546606801	CONNECTOR PRESSURE PORT BS6	TATA spare parts
554546606802	SUCTION PORT CONNECTOR STG PUMP BS6	TATA spare parts
554546607001	POWER STEERING PULLEY	TATA spare parts
554546607101	PLATE GEARBOXEND BS6	TATA spare parts
554546607201	PLUG BS6	TATA spare parts
554546607801	O-RING	TATA spare parts
554546607803	O-RING BS6	TATA spare parts
554546607804	O-RING	TATA spare parts
554546607805	SEAL	TATA spare parts
554546607807	O-RING BS6	TATA spare parts
554546607809	COVERPLATEASSY BS6	TATA spare parts
554546608001	ALLEN SCREW	TATA spare parts
554546608002	PAN HEAD SCREW	TATA spare parts
554546608003	SCREW	TATA spare parts
554546608005	ALLENSCREW BS6	TATA spare parts
554546608006	ALLENSCREW BS6	TATA spare parts
554546608201	BALL RETURN GUIDE LH	TATA spare parts
554546608301	SHIM BS6	TATA spare parts
554546608302	SHIM BS6	TATA spare parts
554546608303	SHIM BS6	TATA spare parts
554546608401	SLEEVE BS6	TATA spare parts
554546609201	WASHER	TATA spare parts
554546609903	BEARING ADJUSTER	TATA spare parts
554546609904	BALL GUIDE	TATA spare parts
554546700101	TUBE ASSY	TATA spare parts

554546703202	STOPPER BOLT	TATA spare parts
554546800105	RETURN LINE ASSY GEAR BOX TO RESERVOIR	TATA spare parts
554546800106	BRACKET ASSY	TATA spare parts
554546800109	HIGH PRESSURE LINE ASSY PUMP TO STG GB	TATA spare parts
554546800110	RETURN LINE ASSY GEAR BOX TO RESERVOIR	TATA spare parts
554546800112	HIGH PRESSURE LINE ASSY PUMP TO STG GB	TATA spare parts
554546800114	SUCTION LINE ASSY	TATA spare parts
554546800115	HIGH PRESSURE LINE ASSY	TATA spare parts
554546800116	RETURN LINE ASSY	TATA spare parts
554546800117	HIGH PRESSURE LINE ASSY PUMP TO STG GB	TATA spare parts
554546800118	RETURN LINE ASSY GEAR BOX TO RESERVOIR	TATA spare parts
554546800121	BRACKET ASSY BS6	TATA spare parts
554546805809	SUCTION HOSE	TATA spare parts
554546805810	SUCTION&HOSE	TATA spare parts
554546900102	DRAG LINK ASSY	TATA spare parts
554546900103	BALLJOINTASSY RH	TATA spare parts
554546900104	DRAG LINK ASSY	TATA spare parts
554546900107	DRAG LINK ASSY BS6-PH2	TATA spare parts
554546990104	KIT-SEAL ROLLER SHAFT	TATA spare parts
554546990107	KIT-SEAL	TATA spare parts
554546990120	KIT-BEARING RACE	TATA spare parts
554546990121	KIT- SEAL	TATA spare parts
554546990123	STEERING COLUMN ASSY.UPPER BS6	TATA spare parts
554546990124	INTERMEDIATE SHAFT ASSY BS6	TATA spare parts
554546990130	MAJOR KIT-SEAL	TATA spare parts
554546990133	KIT-HOUSING ASSY BS6	TATA spare parts
554546990134	MAJOR KIT -SEAL	TATA spare parts
554546990135	KIT- SEAL.ROLLER SHAFT	TATA spare parts
554546990138	KIT MOTOR ASSY BS6	TATA spare parts
554546990140	KIT-MAJOR SEAL	TATA spare parts
554546990144	KIT-FASTNER	TATA spare parts
554546990145	DRIVE MOTOR ASSY	TATA spare parts
554546990146	C-EPAS COLUMN ASSY	TATA spare parts
554546990147	STEERING COLUMN ASSY C-EPAS TOP	TATA spare parts
554546990150	SERVICE ECU	TATA spare parts
554546990151	C-EPAS UNIT ASSY	TATA spare parts
554546990152	WIRING HARNESS TORQUE SENSOR	TATA spare parts
554546990153	DUST COVER	TATA spare parts
554546996501	NUT BS6	TATA spare parts
554546998005	SCREW BS6	TATA spare parts
554546998006	SCREW	TATA spare parts
554546999202	SPRING WASHER BS6	TATA spare parts
554547100106	FUEL PUMP MODULE	TATA spare parts
554547100107	FUEL FILLER NECK ASSY	TATA spare parts
554547100108	DRAIN PLUG ASSY	TATA spare parts
554547100109	FUEL TANK ASSY	TATA spare parts
554547100121	FUEL MODULE ASSY BS6	TATA spare parts

554547100122	FUEL TANK ASSY	TATA spare parts
554547100124	FUEL FILLER NECK ASSY BS6-PH2	TATA spare parts
554547100127	FUEL TANK ASSY W/INTANK PUMP BS6-PH2	TATA spare parts
554547100130	FUEL TANK ASSY BS6-PH2	TATA spare parts
554547100131	FUEL FILLER NECK ASSY BS6-PH2	TATA spare parts
554547100137	INTANK PUMP ASSY BS6-PH2	TATA spare parts
554547100143	FUEL TANK ASSY BS6-PH2	TATA spare parts
554547100146	INTANK PUMP ASSY BS6-PH2	TATA spare parts
554547100149	FUEL FILLER NECK ASSY BS6-PH2	TATA spare parts
554547100150	FUEL TANK ASSY W/INTANK PUMP BS6-PH2	TATA spare parts
554547100154	BRACKET ASSY BS6-PH2	TATA spare parts
554547103302	BRACKET CLAMP MTG BS6-PH2	TATA spare parts
554547103306	BRACKET BS6-PH2	TATA spare parts
554547105301	GASKET FSU BS6-PH2	TATA spare parts
554547106301	FUEL CAP	TATA spare parts
554547106302	FUEL TANK	TATA spare parts
554547107801	O-RING	TATA spare parts
554547109914	CYLINDER BS6-PH2	TATA spare parts
554547109916	CYLINDER BS6-PH2	TATA spare parts
554547109918	CYLINDER BS6	TATA spare parts
554547500105	2-WAY ISOLATION VALVE BS6-PH2	TATA spare parts
554547500120	BRACKET ASSY FILLING NOZZLE MTG BS6	TATA spare parts
554547500121	STRAP MTG ASSY BS6-PH2	TATA spare parts
554547500122	BRACKET ASSY BS6-PH2	TATA spare parts
554547500123	STRAP ASSY BS6-PH2	TATA spare parts
554547500135	CYLINDER ARRESTING ARRANGEMENT ASSY BS6-	TATA spare parts
554547500137	BRACKET ASSY BS6-PH2	TATA spare parts
554547500138	CYLINDER ARRESTING ARRANGEMENT ASSY BS6-	TATA spare parts
554547500144	BRACKET ASSY BS6-PH2	TATA spare parts
554547500156	STRAP MTG ASSY BS6-PH2	TATA spare parts
554547500158	STRAP MTG ASSY BS6-PH2	TATA spare parts
554547500167	CYLINDER STOPPER ASSY FRONT RH BS6	TATA spare parts
554547500173	STOPPER BRACKET ASSY ASSY WITH SCREW BS6	TATA spare parts
554547500176	STOPPER BRACKET ASSY BS6-PH2	TATA spare parts
554547500180	STOPPER BRACKET ASSY BS6-PH2	TATA spare parts
554547500186	BRACKET ASSY FUEL TANK MTG BS6-PH2	TATA spare parts
554547503318	BRACKET BS6-PH2	TATA spare parts
554547506702	CLEVIS PIN BS6-PH2	TATA spare parts
554547507703	RUBBER PACKING BS6-PH2	TATA spare parts
554547507711	RUBBER PACKING BS6-PH2	TATA spare parts
554547508278	BRACKET STOPPER CYL LH CNG CYL MTG BS6	TATA spare parts
554547508281	COMPLIANCE PLATE BS6	TATA spare parts
554547515802	RUBBER HOSE BS6-PH2	TATA spare parts
554547518202	BRACKET BS6-PH2	TATA spare parts
554547600102	FUEL SUCTION PIPE ASSY	TATA spare parts
554547600103	FUEL RETURN PIPE ASSY	TATA spare parts
554547600105	BRACKET ASSY FUEL LINE	TATA spare parts

554547600106	FUEL SUCTION PIPE ASSY	TATA spare parts
554547600107	FUEL RETURN PIPE ASSY	TATA spare parts
554547600108	FUEL SUCTION PIPE ASSY	TATA spare parts
554547600110	FUEL RETURN PIPE ASSY	TATA spare parts
554547600111	FUEL SUCTION PIPE ASSY	TATA spare parts
554547600113	FUEL RETURN PIPE ASSY	TATA spare parts
554547600115	FUEL SUCTION PIPE ASSY	TATA spare parts
554547600116	FUEL SUCTION PIPE ASSY	TATA spare parts
554547600117	FUEL RETURN PIPE ASSY	TATA spare parts
554547600128	HP PIPE ASSY BS6	TATA spare parts
554547600129	VENT PIPE ASSYBS6	TATA spare parts
554547600130	VENT PIPE ASSY	TATA spare parts
554547600131	VENT PIPE ASSY	TATA spare parts
554547600132	HP PIPE ASSY FRONT CYL TO REAR CYL	TATA spare parts
554547600134	BRACKET ASSY FILLING NOZZLE MTG	TATA spare parts
554547600158	VENT PIPE ASSY	TATA spare parts
554547600160	VENT PIPE ASSY	TATA spare parts
554547600163	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554547600164	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554547600165	FUEL RETURN PIPE ASSY BS6	TATA spare parts
554547600168	FUEL RETURN PIPE ASSY	TATA spare parts
554547600169	FUEL SUCTION PIPE ASSY	TATA spare parts
554547600178	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554547600179	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554547600181	FUEL RETURN PIPE ASSY BS6	TATA spare parts
554547600183	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554547600184	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554547601601	CLAMP ASSY	TATA spare parts
554547603306	BRACKET BS6-PH2	TATA spare parts
554547603307	BRACKET BS6-PH2	TATA spare parts
554547605899	BREATHER HOSE BS6	TATA spare parts
554547607701	BREATHER HOSE	TATA spare parts
554547607702	BREATHER HOSE	TATA spare parts
554547607703	FUEL HOSE	TATA spare parts
554547607705	BREATHER HOSE	TATA spare parts
554547610109	VENT PIPE ASSY BS6	TATA spare parts
554547610111	LP HOSE ASSY FILTER TO ENGINE BS6	TATA spare parts
554547610112	BRACKET ASSY CLAMP MTG BS6	TATA spare parts
554547610113	VENT TUBE ASSY WITH ADAPTER BS6	TATA spare parts
554547610114	HP TUBE ASSY BS6	TATA spare parts
554547610121	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
554547610122	VAPOUR PIPE ASSY CANISTER TO CPV BS6-PH2	TATA spare parts
554547610123	VENT PIPE ASSY BS6	TATA spare parts
554547610129	VENT PIPE ASSY BS6	TATA spare parts
554547610130	VENT PIPE ASSY REAR CYLINDER BS6	TATA spare parts
554547610133	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554547610134	FUEL RETURN PIPE ASSY BS6	TATA spare parts

554547610135	VENT TUBE ASSY WITH ADAPTER BS6	TATA spare parts
554547610136	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554547610137	HP TUBE ASSY BS6-PH2	TATA spare parts
554547610140	HP TUBE ASSY BS6-PH2	TATA spare parts
554547610151	VENT TUBE ASSY WITH ADAPTER BS6-PH2	TATA spare parts
554547610153	HP TUBE ASSY BS6-PH2	TATA spare parts
554547610155	HP PIPE ASSY BS6-PH2	TATA spare parts
554547610158	COVER FILLING NOZZLE BS6-PH2	TATA spare parts
554547610161	CYLINDER ARRESTING ARRANGEMENT ASSY BS6-	TATA spare parts
554547610179	HP TUBE ASSY BS6-PH2	TATA spare parts
554547615804	BREATHER HOSE BS6-PH2	TATA spare parts
554547615807	FUEL FILLING HOSE BS6-PH2	TATA spare parts
554547615809	VAPOUR HOSE BS6-PH2	TATA spare parts
554547615842	BREATHER HOSE BS6-PH2	TATA spare parts
554547615843	FUEL FILLING HOSE BS6-PH2	TATA spare parts
554547615848	HOSE BS6-PH2	TATA spare parts
554547620102	VENT PIPE ASSY BS6	TATA spare parts
554547620103	HP PIPE ASSY FRONT CYL TO REAR CYL BS6	TATA spare parts
554547620107	HP PIPE ASSY BS6	TATA spare parts
554547620108	VENT PIPE ASSY BS6	TATA spare parts
554547620109	HP PIPE ASSY BS6	TATA spare parts
554547620110	VENT PIPE ASSY ITVR TO FRONT TEE BS6	TATA spare parts
554547620111	BRACKET ASSY BS6-PH2	TATA spare parts
554547620119	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
554547620120	VAPOUR PIPE ASSY BS6-PH2	TATA spare parts
554547620121	VAPOUR PIPE ASSY CANISTER TO CPV BS6-PH2	TATA spare parts
554547620144	HP PIPE ASSY-FRONT CYL TO REAR CYL BS6	TATA spare parts
554547620148	BRACKET ASSY BS6-PH2	TATA spare parts
554547620149	GUARD ASSY CYLINDER VALVE BS6-PH2	TATA spare parts
554547620150	HP PIPE ASSY BS6-PH2	TATA spare parts
554547620151	HOLDER TUBE BS6-PH2	TATA spare parts
554547620152	HOLDER TUBE BS6-PH2	TATA spare parts
554547620154	BRACKET ASSY BS6-PH2	TATA spare parts
554547620172	VENT TUBE ASSY WITH ADAPTER BS6-PH2	TATA spare parts
554547700102	VALVE ASSY BS6	TATA spare parts
554547700103	BRACKET ASSY FUEL FILTER MTG BS6-PH2	TATA spare parts
554547703601	FILTER BS6	TATA spare parts
554549006901	SPACER TUBE BS6	TATA spare parts
554549100103	HEAT SHIELD ASSY	TATA spare parts
554549100119	SILENCER ASSY EXHAUST BS6	TATA spare parts
554549200109	SILENCER ASSY EXHAUST	TATA spare parts
554549200113	BRACKET ASSY BS6	TATA spare parts
554549200121	EXHAUST SYSTEM ASSY	TATA spare parts
554549200124	BRACKET ASSY BS6	TATA spare parts
554549200125	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
554549200129	BRACKET ASSY EGP MTG BS6	TATA spare parts
554549200133	SILENCER ASSY EXHAUST BS6	TATA spare parts

554549200134	UREA TANK ASSY BS6	TATA spare parts
554549200135	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
554549200136	BRACKET ASSY BS6	TATA spare parts
554549200138	BRACKET ASSY EGP MTG BS6	TATA spare parts
554549200142	FILLER NECK FILTER BS6	TATA spare parts
554549200143	VENT PIPE BS6	TATA spare parts
554549200144	GASKET BS6	TATA spare parts
554549200145	DRAIN PLUG BS6	TATA spare parts
554549200146	GASKET VENT VALVE BS6	TATA spare parts
554549200148	VENT VALVE BS6	TATA spare parts
554549200156	EXHAUST PIPE ASSY WITH FLEX JOINT FRONT	TATA spare parts
554549200161	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
554549200164	PIPE ASSY FLEX BELLOW FRONT BS6	TATA spare parts
554549200165	SILENCER ASSY EXHAUST BS6-PH2	TATA spare parts
554549203315	BRACKET BS6	TATA spare parts
554549203316	BRACKET BS6	TATA spare parts
554549203320	BRACKET BS6	TATA spare parts
554549205301	GASKET BS6	TATA spare parts
554549206933	SLEEVE BOTTOM BS6	TATA spare parts
554549210103	PIPE ASSY UREA SUPPLY BS6-PH2	TATA spare parts
554549210106	PIPE ASSY FLEX BELLOW FRONT BS6-PH2	TATA spare parts
554549210108	BRACKET ASSY EGP MTG BS6-PH2	TATA spare parts
554554100104	COVER ASSY BATTERY	TATA spare parts
554554100106	STUD ASSY BATTERY MTG BS6	TATA spare parts
554554100107	BRACKET ASSY BATTERY BASE MTG BS6-PH2	TATA spare parts
554554108208	COVER BS6	TATA spare parts
554554108211	SPACER BS6	TATA spare parts
554554200106	INSTRUMENT CLUSTER INTERFACE HARDWARE	TATA spare parts
554554200107	INSTRUMENT CLUSTER ASSY BS6	TATA spare parts
554554200108	INSTRUMENT CLUSTER ASSY BS6	TATA spare parts
554554200109	INSTRUMENT CLUSTER INTERFACE HARDWARE BS6	TATA spare parts
554554300101	BRACKET ASSY HORN MTG	TATA spare parts
554554300102	BRACKET ASSY BS6	TATA spare parts
554554349901	METAL INSERT	TATA spare parts
554554400102	SIDE REPEATER LAMP LH	TATA spare parts
554554400103	SIDE REPEATER LAMP RH	TATA spare parts
554554400104	TAIL LAMP ASSY LH	TATA spare parts
554554400105	TAIL LAMP ASSY RH	TATA spare parts
554554400106	HEADLAMP ASSY WITH LEVEL MOTOR RH	TATA spare parts
554554400107	HEADLAMP ASSY WITH LEVEL MOTOR LH	TATA spare parts
554554400111	REFLEX REFLECTOR ASSY LH	TATA spare parts
554554400114	HEADLAMP ASSY WITH LEVEL MOTORS RH	TATA spare parts
554554400115	HEADLAMP ASSY WITH LEVEL MOTORS LH	TATA spare parts
554554400119	REFLEX REFLECTOR ASSY RH	TATA spare parts
554554400122	TAIL LAMP ASSY RH BS6	TATA spare parts
554554400123	TAIL LAMP ASSY LH BS6	TATA spare parts
554554400124	HEADLAMP ASSY WITH LEVEL MOTOR RH BS6	TATA spare parts

554554400125	HEADLAMP ASSY WITH LEVEL MOTOR LH BS6	TATA spare parts
554554400126	SIDE REPEATER ASSY RH	TATA spare parts
554554400127	LAMP ASSY REGISTRATION PLATE	TATA spare parts
554554400128	LAMP ASSY CABIN	TATA spare parts
554554400129	SIDE REPEATER ASSY LH	TATA spare parts
554554400131	HEADLAMP ASSY WITH LEVEL MOTOR LH BS6-PH	TATA spare parts
554554400132	HEADLAMP ASSY WITH LEVEL MOTOR RH BS6-PH	TATA spare parts
554554400133	HEADLAMP ASSY WITH LEVEL MOTOR LH	TATA spare parts
554554400134	HEADLAMP ASSY WITH LEVEL MOTOR RH	TATA spare parts
554554409901	REFLEX REFLECTOR ASSY LH	TATA spare parts
554554409902	REFLEX REFLECTOR ASSY RH	TATA spare parts
554554420101	ASSY. HEADLAMP W/LEVEL MOTOR RH BS4/6	TATA spare parts
554554420102	ASSY. HEADLAMP W/LEVEL MOTOR LH BS4/6	TATA spare parts
554554500102	FASCIA SWITCH ASSY	TATA spare parts
554554500103	FASCIA SWITCH ASSY	TATA spare parts
554554500107	POWER WINDOW SWITCH	TATA spare parts
554554500108	FASCIA SWITCH ASSY	TATA spare parts
554554500110	FASCIA SWITCH ASSY BS6	TATA spare parts
554554500112	FASCIA SWITCH ASSY BS6	TATA spare parts
554554500113	FASCIA SWITCH ASSY- 554554501618 BS6	TATA spare parts
554554500115	FASCIA SWITCH ASSY BS6-PH2	TATA spare parts
554554504901	HEADLAMP LEVELLING SWITCH	TATA spare parts
554554504902	REVERSE LIGHT SWITCH ASSY WITH PIGTAIL	TATA spare parts
554554504905	ECO SWITCH BS6	TATA spare parts
554554504906	FASCIA SWITCH	TATA spare parts
554554504909	SWITCH REGENERATION START MANUAL BS6	TATA spare parts
554554504910	ECO SWITCH BS6	TATA spare parts
554554504911	SWITCH REGENERATION START MANUAL BS6	TATA spare parts
554554504912	HEADLAMP LEVELLING SWITCH BS6	TATA spare parts
554554504914	CNG SELECTOR SWITCH ASSY BS6-PH2	TATA spare parts
554554509901	SWITCH DUMMY KNOB	TATA spare parts
554554509910	BEZEL FASCIA SWITCH	TATA spare parts
554554509911	BEZEL FASCIA SWITCH	TATA spare parts
554554509912	CARRIER PLATE FASCIA SWITCH BS6	TATA spare parts
554554509913	KNOB BS6	TATA spare parts
554554509914	BEZEL FASCIA SWITCH BS6	TATA spare parts
554554600102	WIRING HARNESS MAIN	TATA spare parts
554554600103	WIRING HARNESS ENGINE	TATA spare parts
554554600124	BATTERY CABLE +VE BS6	TATA spare parts
554554600129	BRACKET ASSY JUNCTION BOX MTG	TATA spare parts
554554600132	WIRING HARNESS MAIN BS2/4	TATA spare parts
554554600149	WIRING HARNESS CHASSIS BS6	TATA spare parts
554554600171	BRACKET ASSY MIDI FUSE BOX MTG	TATA spare parts
554554600172	WIRING HARNESS CHASSIS BS6	TATA spare parts
554554600181	WIRING HARNESS CABIN BS6	TATA spare parts
554554600184	WIRING HARNESS EMS BS6	TATA spare parts
554554600190	WIRING HARNESS CABIN	TATA spare parts



554554600197	WIRING HARNESS CABIN BS6	TATA spare parts
554554601601	WIRING HARNESS BATTERY POSITIVE CABLE	TATA spare parts
554554601610	BATTERY CABLE +VE	TATA spare parts
554554601611	WIRING HARNESS MAIN	TATA spare parts
554554601613	WIRING HARNESS ASSY ENGINE	TATA spare parts
554554601619	WIRING HARNESS BATTERY CABLE +VE	TATA spare parts
554554601620	BATTERY CABLE +VE	TATA spare parts
554554601624	WIRING HARNESS MAIN	TATA spare parts
554554601625	WIRING HARNESS ENGINE BS3/4	TATA spare parts
554554601626	WIRING HARNESS MAIN	TATA spare parts
554554601627	WIRING HARNESS CHASSIS	TATA spare parts
554554601629	STARTER CABLE BATTERY +VE	TATA spare parts
554554601630	BATTERY CABLE -VE	TATA spare parts
554554601644	WIRING HARNESS DOOR	TATA spare parts
554554601645	WIRING HARNESS ANTENNA	TATA spare parts
554554601670	WIRING HARNESS CABIN	TATA spare parts
554554601672	WIRING HARNESS CABIN	TATA spare parts
554554603301	BRACKET STARTER MTR PROTECTION UNIT MTG	TATA spare parts
554554603302	BRACKET WIRING HARNESS MTG BS6	TATA spare parts
554554603306	BRACKET INTERCONNECTION CONNECTOR MTG	TATA spare parts
554554603307	BRACKET EMS WIRING HARNESS MTG	TATA spare parts
554554603308	BRACKET BATTERY +VE CABLE MTG	TATA spare parts
554554603313	BRACKET BATTERY CABLE MTG	TATA spare parts
554554603314	BRACKET BATTERY +VE CABLE MTG	TATA spare parts
554554603318	BRACKET EMS WIRING HARNESS MTG	TATA spare parts
554554603323	BRACKET WIRING HARNESS CLIP MTG	TATA spare parts
554554603324	BRACKET INTERCONNECTION CONNECTOR MTG	TATA spare parts
554554603325	BRACKET WIRING HARNESS CLIP MTG	TATA spare parts
554554603326	BRACKET WIRING HARNESS CLIP MTG	TATA spare parts
554554603330	BRACKET W/H - BATTERY CABLE MTG	TATA spare parts
554554603331	BRACKET BATTERY CABLE MTG	TATA spare parts
554554603332	BRACKET W/H - BATTERY CABLE MTG	TATA spare parts
554554603334	BRACKET INTERCONNECTION CONNECTOR MTG BS6	TATA spare parts
554554603339	BRACKET BS6	TATA spare parts
554554603340	BRACKET ENGINE WIRING HARNESS MTG	TATA spare parts
554554603341	BRACKET EMS CABLE MTG BS6	TATA spare parts
554554603342	BRACKET FUSE BOX MTG BS6	TATA spare parts
554554603347	BRACKET CLIP MTG BS6	TATA spare parts
554554603348	BRACKET EARTH STRAP MTG BS6	TATA spare parts
554554603349	BRACKET BS6	TATA spare parts
554554603352	BRACKET WIRING HARNESS MTG BS6	TATA spare parts
554554603354	BRACKET EMS CABLE MTG BS6	TATA spare parts
554554603355	BRACKET ENGINE WIRING HARNESS MTG BS6-PH	TATA spare parts
554554603358	BRACKET WIRING HARNESS MTG BS6	TATA spare parts
554554603363	BRACKET BS6-PH2	TATA spare parts
554554603366	BRACKET WIRING HARNESS CLIP MTG BS6-PH2	TATA spare parts
554554603369	BRACKET WIRING HARNESS CLIP MTG BS6-PH2	TATA spare parts

554554603371	MOUNTING BRACKET BS6	TATA spare parts
554554603376	BRACKET WIRING HARNESS CLIP MTG BS6-PH2	TATA spare parts
554554603377	BRACKET-RELAY BASE MTG BS6	TATA spare parts
554554603379	BRACKET BS6	TATA spare parts
554554603384	BRACKET INTERCONNECTION CONNECTOR MTG BS6	TATA spare parts
554554603391	MOUNTING BRACKET BS6-PH2	TATA spare parts
554554610101	WIRING HARNESS DOOR LH	TATA spare parts
554554610111	WIRING HARNESS MAIN BS6	TATA spare parts
554554610113	WIRING HARNESS ENGINE BS6	TATA spare parts
554554610125	WIRING HARNESS ENGINE	TATA spare parts
554554610126	BATTERY CABLE +VE	TATA spare parts
554554610127	WIRING HARNESS MAIN	TATA spare parts
554554610128	BRACKET FUSE BOX MTG	TATA spare parts
554554610129	BATTERY CABLE +VE BS6	TATA spare parts
554554610130	WIRING HARNESS ENGINE BS6	TATA spare parts
554554610131	WIRING HARNESS MAIN BS6	TATA spare parts
554554610132	BRACKET ASSY RETAINER PLATE	TATA spare parts
554554610135	BRACKET ASSY FUSE BOX MTG BS6	TATA spare parts
554554610138	WIRING HARNESS MAIN	TATA spare parts
554554610140	BRACKET ASSY CONTROLLER & RELAY MTG	TATA spare parts
554554610141	WIRING HARNESS CHASSIS	TATA spare parts
554554610142	WIRING HARNESS CABIN	TATA spare parts
554554610143	BRACKET ASSY MIDI FUSE BOX MTG	TATA spare parts
554554610144	WIRING HARNESS BATTERY CABLE +VE	TATA spare parts
554554610146	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
554554610148	WIRING HARNESS ASSY ENGINE	TATA spare parts
554554610149	RELAY COVER ASSY	TATA spare parts
554554610154	WIRING HARNESS CHASSIS	TATA spare parts
554554610156	WIRING HARNESS CABIN	TATA spare parts
554554610158	WIRING HARNESS MAIN	TATA spare parts
554554610161	STICKER & COVER ASSY FUSE BOX BS6-PH2	TATA spare parts
554554610162	RELAY COVER ASSY BS6	TATA spare parts
554554610166	WIRING HARNESS BATTERY CABLE +VE BS6	TATA spare parts
554554610168	WIRING HARNESS ENGINE BS6	TATA spare parts
554554610170	PIGTAIL REAR PARKING SENSOR BS6	TATA spare parts
554554610176	RELAY COVER ASSY BS6	TATA spare parts
554554610188	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
554554610199	WIRING HARNESS CHASSIS BS6	TATA spare parts
554554620102	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
554554620103	WIRING HARNESS CHASSIS BS6	TATA spare parts
554554620105	WIRING HARNESS-CHASSIS BS6	TATA spare parts
554554620108	WIRING HARNESS MAIN BS6	TATA spare parts
554554620109	WIRING HARNESS-CHASSIS BS6	TATA spare parts
554554620111	P-CLAMP BS6	TATA spare parts
554554620112	P-CLAMP BS6	TATA spare parts
554554620113	WIRING HARNESS BATTERY CABLE +VE BS6	TATA spare parts
554554620114	RELAY COVER ASSY BS6-PH2	TATA spare parts

554554620116	WIRING HARNESS CHASSIS BS6	TATA spare parts
554554620118	WIRING HARNESS CABIN BS6	TATA spare parts
554554620119	FUSE BOX ASSY BS6-PH2	TATA spare parts
554554620120	COVER ASSY FUSE BOX WITH STICKER BS6	TATA spare parts
554554620128	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
554554620134	BATTERY CABLE -VE BS6-PH2	TATA spare parts
554554620136	EARTH STRAP BS6-PH2	TATA spare parts
554554620149	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
554554620150	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
554554620152	P-CLAMP BS6-PH2	TATA spare parts
554554620153	WIRING HARNESS BATTERY CABLE +VE BS6-PH2	TATA spare parts
554554620154	WIRING HARNESS BATTERY CABLE +VE BS6-PH2	TATA spare parts
554554620155	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
554554620167	BATTERY CABLE +VE BS6-PH2	TATA spare parts
554554620170	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
554554620183	RELAY COVER ASSY BS6-PH2	TATA spare parts
554554620192	BATTERY CABLE +VE BS6-PH2	TATA spare parts
554554630103	WIRING HARNESS MAIN BS6	TATA spare parts
554554630105	WIRING HARNESS-ENGINE BS6	TATA spare parts
554554630107	WIRING HARNESS-CHASSIS BS6	TATA spare parts
554554630115	WIRING HARNESS MAIN BS6	TATA spare parts
554554630117	WIRING HARNESS-MAIN BS6	TATA spare parts
554554630120	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
554554630121	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
554554630122	WIRING HARNESS-CHASSIS BS6-PH2	TATA spare parts
554554630129	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
554554630132	BRACKET RELAY BASE MTG BS6-PH2	TATA spare parts
554554630133	RELAY COVER ASSY BS6-PH2	TATA spare parts
554554630135	RELAY COVER ASSY BS6-PH2	TATA spare parts
554554700101	BRACKET ASSY GPIU MTG	TATA spare parts
554554700102	BRACKET ASSY TELEMATICS MTG	TATA spare parts
554554700104	BRACKET ASSY GLOW CONTROL UNIT MTG BS6	TATA spare parts
554554700106	BRACKET ASSY GDCU UNIT MOUNTING BS6-PH2	TATA spare parts
554554709902	FLASHER	TATA spare parts
554554709903	ALUMINIUM FOIL	TATA spare parts
554554709904	GLOW CONTROL UNIT BS6	TATA spare parts
554554709905	CONTROLLER GEAR SHIFT ADVISORY	TATA spare parts
554554801603	MUSIC SYSTEM	TATA spare parts
554554801604	SPEAKER	TATA spare parts
554554803302	BRACKET ECU COVER MTG BS6-PH2	TATA spare parts
554554807501	COVER ECU PROTECTION BS6-PH2	TATA spare parts
554554829901	HOSE ASSY	TATA spare parts
554554829902	WASHER BOTTLE	TATA spare parts
554554829905	FILLER NECK BS6	TATA spare parts
554554829906	BREATHER TUBE	TATA spare parts
554554829907	T-CONNECTOR	TATA spare parts
554554829908	WASHER PUMP	TATA spare parts

554554900101	BRACKET ASSY ECU BKT MTG BS6	TATA spare parts
554554900103	BRACKET ASSY EMS ECU MTG	TATA spare parts
554554900104	BRACKET ASSY ECU BKT MTG BS6-PH2	TATA spare parts
554554900106	BRACKET ASSY ECU BKT MTG	TATA spare parts
554554900107	BRACKET ASSY ECU WIRING HARNESS MTG BS6	TATA spare parts
554554900109	BRACKET ASSY ECU MTG BS6	TATA spare parts
554554900111	BRACKET ASSY ECU BKT MTG BS6	TATA spare parts
554554903309	BRACKET LAMBDA SENSOR MTG BS6-PH2	TATA spare parts
554554906301	COVER ECU	TATA spare parts
554554906302	COVER EMS ECU BS6	TATA spare parts
554555106301	MASCOT	TATA spare parts
554555106302	DECAL FRONT DOOR LH	TATA spare parts
554555106303	DECAL FRONT DOOR RH	TATA spare parts
554555106304	MASCOT	TATA spare parts
554555106305	MASCOT	TATA spare parts
554555106306	MASCOT	TATA spare parts
554555106307	MASCOT	TATA spare parts
554555106308	MASCOT BS6	TATA spare parts
554555106309	MASCOT BS6	TATA spare parts
554558300102	TOOL KIT BS6	TATA spare parts
554558304003	SCISSORS JACK ASSY BS6	TATA spare parts
554558304008	JACK HANDLE BS6	TATA spare parts
554558304009	CLAMP JACK HANDLE BS6	TATA spare parts
554558408201	TRANSFER LABEL GEAR SHIFT SPEED	TATA spare parts
554558604001	BRACKET TOOL KIT MTG BS6	TATA spare parts
554558604002	BRACKET TOOL KIT MTG BS6	TATA spare parts
554558900602	SPANNER BS6	TATA spare parts
554558900701	SPANNER BS6	TATA spare parts
554558900702	LOCKING PIN FLYWHEEL BS6	TATA spare parts
554558901801	SPANNER OIL FILTER BS6	TATA spare parts
554558902401	SUPPORT STAND ENGINE BS6	TATA spare parts
554558902402	LOCKING TOOL CAMSHAFT	TATA spare parts
554558903505	UNIVERSAL HANDLE BS6	TATA spare parts
554558903506	DUMMY BEARING DIFFERENTIAL CASE BS6	TATA spare parts
554558903507	DOLLY- PRESSING PINION INNER CUP BS6	TATA spare parts
554558903508	DOLLY- PRESSING PINION OUTER CUP BS6	TATA spare parts
554558903509	DOLLY- PRESSING PINION INN CONE BS6	TATA spare parts
554558903510	DOLLY- PRESSING DIFFERENTIAL CASE BEARIN	TATA spare parts
554558903511	PULLER REMOVAL DIFFERENTIAL CASE BEARING	TATA spare parts
554558903512	PULLER REMOVAL PINION INNER AND OUTER BE	TATA spare parts
554558903513	ADAPTER - REMOVAL PINION INNER / OUTER C	TATA spare parts
554558903514	DOLLY - PRESSING PINION & OIL SEAL BS6	TATA spare parts
554558903515	PULLER - PINION OIL SEAL AND IN BOARD OI	TATA spare parts
554558903516	HOLDER - COMPANION FLANGE BS6	TATA spare parts
554558903517	PULLER AXLE SHAFT BEARING BS6	TATA spare parts
554558903518	PINION ASSEMBLY FIXTURE BS6	TATA spare parts
554558903519	DOLLY PRESSING INBOARD OIL SEAL BS6	TATA spare parts

554558903520	AXLE SHAFT PULLER BS6	TATA spare parts
554558903521	SPANNER FOR HOLDING TOP PLATE BS6	TATA spare parts
554558903522	SPANNER FOR DRIVER SCREW ROD BS6	TATA spare parts
554558903523	DIFF PIN REMOVAL TOOL BS6	TATA spare parts
554558903524	DIFFERENTIAL ASSY STAND BS6	TATA spare parts
554558904601	SPECIAL TOOL STRETCH BELT FITMENT	TATA spare parts
554558904701	TOOL FUEL TANK	TATA spare parts
554558904702	CNG VALVE REMOVAL & REFITMENT TOOL BS6-P	TATA spare parts
554560000104BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED	TATA spare parts
554560000104JS	TITANIUM_WH-BODY SHELL ASSY PAINTED	TATA spare parts
554560000104KO	JOSH_BLUE-BODY SHELL ASSY PAINTED	TATA spare parts
554560000104L6	THUNDER_GOLD-BODY SHELL ASSY PAINTED	TATA spare parts
554560000106JS	TITANIUM_WH-BODY SHELL ASSY PAINTED	TATA spare parts
554560000112JS	ASSY BODY SHELL WH TITANIUM INTRA V10 BS	TATA spare parts
554560000112L6	THUNDER_GOLD-BODY SHELL ASSY PAINTED BS6	TATA spare parts
554560000117JS	TITANIUM_WH-BODY SHELL ASSY PAINTED	TATA spare parts
554560000117L6	THUNDER_GOLD-BODY SHELL ASSY PAINTED	TATA spare parts
554560000119FD	SK GOLN YELW-BODY SHELL ASSY PAINTED BS6	TATA spare parts
554560000119JS	TITANIUM_WH-BODY SHELL ASSY PAINTED	TATA spare parts
554560000119L6	THUNDER_GOLD-BODY SHELL ASSY PAINTED BS6	TATA spare parts
554560100121	BODY SHELL ASSY	TATA spare parts
554560100122BF	ASSY. BODY SHELL PAINTED ACE ARC_WHITE	TATA spare parts
554560100122G3	ASSY. CABIN BARE ACE PORCLN WHITE BS3/4	TATA spare parts
554560100122HM	ASSY. BODYSHELL PAINTED URB BRONZE BS3	TATA spare parts
554560100122HU	AZURE_BLUE-BODY SHELL ASSY PAINTED	TATA spare parts
554560100122JS	TITANIUM_WH-BODY SHELL ASSY PAINTED	TATA spare parts
554560100147	BODY SHELL ASSY	TATA spare parts
554560100153BF	ASSY. BODYSHELL PAINTED ARCTIC WHITE BS4	TATA spare parts
554560100153CN	IRISH_CREAM-BODY SHELL ASSY PAINTED	TATA spare parts
554560100153J7	ASSY. BODYSHELL PAINTED CHILL METLIC BS4	TATA spare parts
554560100153JS	TITANIUM_WH-BODY SHELL ASSY PAINTED	TATA spare parts
554560100180BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED	TATA spare parts
554560110102CN	ASSY BODY SHELL PAINTED-IRISH CREAM BS6	TATA spare parts
554560110114BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
554560600101	CROSS MEMBER ASSY	TATA spare parts
554560600103	DASHBOARD CROSS CAR BEAM ASSY LH	TATA spare parts
554560600113	CROSS MEMBER ASSY BS6	TATA spare parts
554560600137	CROSS MEMBER ASSY DASHBOARD MTG BS6	TATA spare parts
554560600141	CROSS MEMBER ASSY DASHBOARD MTG	TATA spare parts
554560603316	BRACKET RH BS6	TATA spare parts
554560606902	CROSS SUPPORT	TATA spare parts
554560606907	CROSS SUPPORT	TATA spare parts
55456060M10101	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
554561200111	CROSS MEMBER ASSY REAR BS6	TATA spare parts
554561200115	PANEL ASSY CROSS MEMBER REAR BS6	TATA spare parts
554561600102	FRONT FLOOR ASSY	TATA spare parts
554561600133	BRACKET ASSY APM MTG	TATA spare parts

554561600135	CAB MTG CLOSING ASSY RH BS6	TATA spare parts
554561600136	FLOOR ASSY BS6	TATA spare parts
554561600138	WHEEL ARCH ASSY INNER-LH BS6	TATA spare parts
554561600139	FRONT FLOOR ASSY BS6	TATA spare parts
554561600157	BRACKET ASSY ENGINE COVER MTG BS6	TATA spare parts
554561600158	REAR FLOOR ASSY RH BS6	TATA spare parts
554561600186	CROSS MEMBER ASSY REAR BS6	TATA spare parts
554561600207	WHEEL ARCH ASSY INNER-RH	TATA spare parts
554561600220	WHEEL ARCH ASSY INNER-RH BS6	TATA spare parts
554561600225	FRONT FLOOR ASSY	TATA spare parts
554561600235	FRONT FLOOR ASSY BS6	TATA spare parts
554561600242	ENGINE COVER ASSY BS6	TATA spare parts
554561600257	CAB MTG CLOSING ASSY LH BS6	TATA spare parts
554561600259	CROSS MEMBER ASSY REAR	TATA spare parts
554561600283	CROSS MEMBER ASSY FLOOR	TATA spare parts
554561600284	CROSS MEMBER ASSY FLOOR	TATA spare parts
554561603353	COVER LH	TATA spare parts
554561603354	COVER RH	TATA spare parts
554561608233	SILL INNER-FRONT-L	TATA spare parts
554561608234	SILL INNER-FRONT-RH	TATA spare parts
55456160M10157	BRACKET ASSY ENGINE COVER MTG BS6-PH2	TATA spare parts
55456160M10158	REAR FLOOR ASSY RH BS6-PH2	TATA spare parts
55456160M10186	CROSS MEMBER ASSY REAR BS6-PH2	TATA spare parts
55456160M10225	FRONT FLOOR ASSY BS6-PH2	TATA spare parts
55456160M10235	FRONT FLOOR ASSY BS6-PH2	TATA spare parts
55456160M10283	CROSS MEMBER ASSY FLOOR BS6-PH2	TATA spare parts
554561610180	WHEEL ARCH ASSY INNER-LH BS6	TATA spare parts
554561610181	WHEEL ARCH ASSY INNER-RH BS6	TATA spare parts
554562000110	FRONT WALL ASSY BS6	TATA spare parts
554562000114	FRONT WALL ASSY BS6	TATA spare parts
554562000115	FRONT WALL ASSY	TATA spare parts
554562000117	FRONT WALL ASSY	TATA spare parts
554562000120	FRONT WALL ASSY BS6	TATA spare parts
55456200M10114	FRONT WALL ASSY BS6-PH2	TATA spare parts
55456200M10117	FRONT WALL ASSY BS6-PH2	TATA spare parts
554562508201	PANEL WINDSHIELD SUPPORT BS6	TATA spare parts
554562600123	BRACKET ASSY	TATA spare parts
554563000101	SIDE WALL ASSY LH	TATA spare parts
554563000102	SIDE WALL ASSY RH	TATA spare parts
554563000105	SIDE WALL ASSY LH	TATA spare parts
554563000106	SIDE WALL ASSY RH	TATA spare parts
554563000110	ASSY SIDE WALL-RH BS6	TATA spare parts
554563200109	BRACKET ASSY SIDE BONNET MTG FRONT-LH	TATA spare parts
554563200110	BRACKET ASSY SIDE BONNET MTG FRONT-RH	TATA spare parts
554563200118	BRACKET ASSY SNORKEL MTG BOTTOM BS6	TATA spare parts
554563600103	SIDE WALL ASSY INNER-LH BS6	TATA spare parts
554563600104	SIDE WALL ASSY INNER-RH BS6	TATA spare parts

554563600111	B-PILLAR ASSY INNER-LH BS6	TATA spare parts
554563600112	B-PILLAR ASSY INNER-RH BS6	TATA spare parts
554563600135	A-PILLAR ASSY INNER-LH BS6	TATA spare parts
554563600136	A-PILLAR ASSY INNER-RH BS6	TATA spare parts
554563600204	SIDE WALL ASSY INNER-RH ACE EV	TATA spare parts
554563608201	CANTRAIL INNER-LH BS6	TATA spare parts
554563608202	CANTRAIL INNER-RH BS6	TATA spare parts
55456360M10109	WHEEL ARCH ASSY OUTER-LH BS6-PH2	TATA spare parts
55456360M10110	WHEEL ARCH ASSY OUTER-RH BS6-PH2	TATA spare parts
55456360M10111	B-PILLAR ASSY INNER-LH BS6-PH2	TATA spare parts
55456360M10112	B-PILLAR ASSY INNER-RH BS6-PH2	TATA spare parts
55456360M10135	A-PILLAR ASSY INNER-LH BS6-PH2	TATA spare parts
55456360M10136	A-PILLAR ASSY INNER-RH BS6-PH2	TATA spare parts
554563700105	BRACKET ASSY MUD FLAP MTG LH	TATA spare parts
554563700113	SIDE WALL ASSY OUTER-LH	TATA spare parts
554563700114	SIDE WALL ASSY OUTER-FRONT-RH	TATA spare parts
55456370M10113	SIDE WALL ASSY OUTER-LH BS6-PH2	TATA spare parts
55456370M10114	SIDE WALL ASSY OUTER-FRONT-RH BS6-PH2	TATA spare parts
55456370M10115	SIDE WALL ASSY OUTER-FRONT-RH BS6-PH2	TATA spare parts
554564000103	REAR WALL ASSY BS6	TATA spare parts
554564000104	REAR WALL ASSY	TATA spare parts
554564000112	REAR WALL ASSY BS6	TATA spare parts
55456400M10103	REAR WALL ASSY BS6-PH2	TATA spare parts
554565700101	HEADER ASSY FRONT ROOF	TATA spare parts
554565700102	REINFORCEMENT ASSY ROOF BOW BS6	TATA spare parts
554565708201	ROOF	TATA spare parts
554565708209	ROOF BOW BS6	TATA spare parts
55456570M10102	REINFORCEMENT ASSY ROOF BOW BS6-PH2	TATA spare parts
554567100102	ASSY. WINDSHIELD GLASS FRONT BS4/6	TATA spare parts
554567106302	SUPPORT WINDSCREEN BOTTOM BS6	TATA spare parts
554567107701	WINDSCREEN MOULD	TATA spare parts
554567800102	REAR WINDOW ASSY	TATA spare parts
554567802301	GLASS REAR SCREEN	TATA spare parts
554567807701	SEAL REAR SLIDING WINDOW	TATA spare parts
554567807702	SEAL REAR SLIDING WINDOW	TATA spare parts
554568206301	TORQUE TAPE FRONT DOOR HINGE LH	TATA spare parts
554568206302	TORQUE TAPE FRONT DOOR HINGE RH	TATA spare parts
554568206303	ANTI VIBRATION SHEET ROOF BS6-PH2	TATA spare parts
554568406302	INSULATION PAD	TATA spare parts
554568406303	INSULATION REAR CROSS MEMBER	TATA spare parts
554568406304	CARPET;REAR WALL CROSS MEMBER	TATA spare parts
554568406307	INSULATION ENGINE COVER	TATA spare parts
554568406308	INSULATION OIL FILLING COVER	TATA spare parts
554568406309	INSULATION PAD RH	TATA spare parts
554568406311	CARPET ENGINE COVER	TATA spare parts
554568406312	STRUCTURAL FOAM PAD BS6-PH2	TATA spare parts
554568406314	CARPET ENGINE COVER BS6	TATA spare parts

554568406315	INSULATION ENGINE COVER BS6	TATA spare parts
554568406317	INSULATION OIL FILLING COVER BS6	TATA spare parts
554568506301	FLOOR CARPET	TATA spare parts
554568506302	CARPET RADIATOR ACCESS COVER	TATA spare parts
554568506305	TRIM FLOOR CARPET LH	TATA spare parts
554568506307	FLOOR CARPET	TATA spare parts
554568506309	TRIM FLOOR CARPET RH	TATA spare parts
554568506317	FLOOR CARPET	TATA spare parts
554568506318	FLOOR CARPET	TATA spare parts
554568506319	CARPET ENGINE COVER	TATA spare parts
554568506321	CARPET RADIATOR ACCESS COVER	TATA spare parts
554568506322	FLOOR CARPET	TATA spare parts
554568506323	FLOOR CARPET	TATA spare parts
554568506324	CARPET FLOOR LH	TATA spare parts
554568506325	CARPET FLOOR RH	TATA spare parts
554568506326	CARPET FLOOR LH	TATA spare parts
554568506328	CARPET RADIATOR ACCESS COVER	TATA spare parts
554568506330	CARPET FLOOR LH	TATA spare parts
554568506331	CARPET FLOOR RH	TATA spare parts
554568506336	FLOOR CARPET BS6-PH2	TATA spare parts
554568506337	FLOOR CARPET BS6	TATA spare parts
554568506338	FLOOR CARPET BS6	TATA spare parts
554568506339	FLOOR CARPET BS6-PH2	TATA spare parts
554568700101	SUPPORT BKT ASSY LOAD BODY INSULATION	TATA spare parts
554568706301	FLOOR CARPET WITH INSULATION	TATA spare parts
554568706304	CARPET ENGINE ACCESS COVER	TATA spare parts
554568706304C7	GRANIT_BLACK-CARPET ENGINE ACCESS COVER	TATA spare parts
554568706305	INSULATION ENGINE ACCESS COVER	TATA spare parts
554568706306	INSULATION REAR CROSS MEMBER	TATA spare parts
554568706307	INSULATION LOAD BODY COVER	TATA spare parts
554568706309	CARPET & INSULATION;FRONT	TATA spare parts
554568706310	INSULATION (VERTICAL)	TATA spare parts
554568706311	INSULATION RADIATOR ACCESS COVER	TATA spare parts
554568706318	INSULATION ENGINE COVER	TATA spare parts
554568706320	INSULATION FRONT FLOOR ASSY	TATA spare parts
554568706321	INSULATION ENGINE COVER	TATA spare parts
554568706322	INSULATION VERTICAL WALL UPPER	TATA spare parts
554568706323	INSULATION ENGINE COVER	TATA spare parts
554568706324	INSULATION OIL FILLING COVER	TATA spare parts
554568706325	INSULATION VERTICAL WALL LOWER BS6	TATA spare parts
554568706326	FLOOR CARPET WITH INSULATION	TATA spare parts
554568706330	INSULATION RADIATOR ACCESS COVER	TATA spare parts
554568706331	INSULATION RADIATOR ACCESS COVER	TATA spare parts
554568706332	INSULATION RADIATOR ACCESS COVER	TATA spare parts
554568706334	INSULATION VERTICAL WALL LOWER	TATA spare parts
554568706336	CARPET FRONT WALL BS6	TATA spare parts
554568706336C7	GRANIT_BLACK-CARPET FRONT WALL ACE EV	TATA spare parts



554568706337	INSULATION REAR CROSS MEMBER	TATA spare parts
554568706338	INSULATION&PARKING&BRAKE&MTG&BRACKET	TATA spare parts
554568706339	FLOOR CARPET WITH INSULATION BS6	TATA spare parts
554568706340	INSULATION&LOAD&BODY&COVER	TATA spare parts
554568706345	INSULATION LOAD BODY COVER BS6-PH2	TATA spare parts
554568900102	DASHBOARD ASSY	TATA spare parts
554568900102ZV	CLRPRT_ASY_1-DASHBOARD ASSY BS6	TATA spare parts
554568900102ZY	CLRPRT_ASY_1-DASHBOARD ASSY	TATA spare parts
554568900102ZZ	CLRPART_ASSY-DASHBOARD ASSY BS6	TATA spare parts
554568900106	BEZEL ASSY	TATA spare parts
554568900106CV	FIN_M_SILVER-BEZEL ASSY BS6	TATA spare parts
554568900106KO	JOSH_BLUE-BEZEL ASSY	TATA spare parts
554568900109	GLOVE BOX LID SSY INNER	TATA spare parts
554568900109C7	GRANIT_BLACK-GLOVE BOX LID ASSY INNER BS	TATA spare parts
554568900113	BRACKET ASSY DASHBOARD AUDIO MTG CENTER	TATA spare parts
554568900115	COVER ASSY AC CONTROL	TATA spare parts
554568900115ZZ	CLRPART_ASSY-COVER ASSY AC CONTROL BS6	TATA spare parts
554568900116	BEZEL ASSY CLUSTER	TATA spare parts
554568900116ZZ	ASSY-BEZEL ASSY CLUSTER	TATA spare parts
554568900119	DASHBOARD ASSY W/O HVAC	TATA spare parts
554568900119ZY	CLRPRT_ASY_1-DASHBOARD ASSY W/O HVAC BS6	TATA spare parts
554568900120	MOBILE HOLDER ASSY	TATA spare parts
554568900120C7	GRANIT_BLACK-MOBILE HOLDER ASSY	TATA spare parts
554568900123	GLOVE BOX LID ASSY INNER	TATA spare parts
554568900124	BEZEL ASSY CLUSTER	TATA spare parts
554568900126	COVER ASSY DASHBOARD CENTER-LOWER	TATA spare parts
554568900126ZZ	CLRPART_ASSY-COVER ASSY DASHBOARD CENTER	TATA spare parts
554568900127	GLOVE BOX LOCK BARREL ASSY BS6-PH2	TATA spare parts
554568900130	COVER ASSY AC CONTROL	TATA spare parts
554568900132	DASHBOARD ASSY WITH HVAC	TATA spare parts
554568900135	CONSOLE ASSY ENGINE SHIELD	TATA spare parts
554568900138	COVER ASSY CENTER VENT	TATA spare parts
554568900138C7	GRANIT_BLACK-COVER ASSY CENTER VENT BS6	TATA spare parts
554568900140	DASHBOARD ASSY BS6	TATA spare parts
554568900140ZZ	JUNCTION BOX ASSEMBLY KIT ACE EV	TATA spare parts
554568900147	BRACKET ASSY CLUSTER MTG BS6	TATA spare parts
554568903302	BRACKET DASHBOARD MTG BS6	TATA spare parts
554568903303	CLIP&DASHBOARD&RETENTION	TATA spare parts
554568906307	GLOVE BOX HOUSING	TATA spare parts
554568906307C7	GRANIT_BLACK-GLOVE BOX HOUSING BS6	TATA spare parts
554568906308	END CAP LH	TATA spare parts
554568906309	END CAP RH	TATA spare parts
554568906309C7	GRANIT_BLACK-END CAP RH BS6	TATA spare parts
554568906310	BEZEL SIDE AIR VENT LH	TATA spare parts
554568906310JS	TITANIUM_WH-BEZEL SIDE AIR VENT LH BS6	TATA spare parts
554568906310KO	JOSH_BLUE-BEZEL SIDE AIR VENT LH	TATA spare parts
554568906311	BEZEL SIDE AIR VENT RH	TATA spare parts

554568906311JS	TITANIUM_WH-BEZEL SIDE AIR VENT RH BS6	TATA spare parts
554568906311KO	JOSH_BLUE-BEZEL SIDE AIR VENT RH	TATA spare parts
554568906322	NACELLE LOWER	TATA spare parts
554568906322C7	GRANIT_BLACK-NACELLE LOWER BS6	TATA spare parts
554568906323	NACELLE UPPER	TATA spare parts
554568906323C7	GRANIT_BLACK-NACELLE UPPER BS6	TATA spare parts
554568906326	BOOT RING GEAR SHIFT LEVER BS6	TATA spare parts
554568906328	HINGE PIN	TATA spare parts
554568906329	SUPPORT BRACKET DASHBOARD MTG BS6	TATA spare parts
554568906331	DASHBOARD SKIN	TATA spare parts
554568906332	GLOVE BOX HOUSING	TATA spare parts
554568906350	COVER AC VENT LH	TATA spare parts
554568906350C7	GRANIT_BLACK-COVER AC VENT LH BS6	TATA spare parts
554568906351	COVER AC VENT RH	TATA spare parts
554568906351C7	GRANIT_BLACK-COVER AC VENT RH BS6	TATA spare parts
554568906355	NACELLE LOWER BS6	TATA spare parts
554568906357	NACELLE UPPER BS6	TATA spare parts
554568906358	DASHBOARD SKIN BS6	TATA spare parts
554568906359	BEZEL INSTRUMENT CLUSTER BS6	TATA spare parts
554568906369	COVER STEERING COLUMN BS6	TATA spare parts
554568907501	GROMMET DASHBOARD MTG	TATA spare parts
554568907502	GROMMET DASHBOARD LOCATOR CENTER	TATA spare parts
554568996301	INSULATION LOAD BODY COVER	TATA spare parts
554568996302	AIR DEFLECTOR BS6	TATA spare parts
554569100102	SCUFF PLATE ASSY	TATA spare parts
554569100103	SCUFF PLATE ASSY	TATA spare parts
554569100104	SCUFF PLATE ASSY;LH	TATA spare parts
554569100105	SCUFF PLATE ASSY;RH	TATA spare parts
554569100106	SCUFF PLATE ASSY LH	TATA spare parts
554569100107	SCUFF PLATE ASSY RH	TATA spare parts
554569100108	SCUFF PLATE ASSY WHEEL ARCH LH	TATA spare parts
554569100109	SCUFF PLATE ASSY WHEEL ARCH RH	TATA spare parts
554569106312	COVER HEADLAMP LH	TATA spare parts
554569106313	COVER HEADLAMP RH	TATA spare parts
554569106323	COVER SCREW JACK	TATA spare parts
554569107501	RUBBER CAP	TATA spare parts
554569107701	SEAL HEADLAMP COVER LH	TATA spare parts
554569107702	SEAL HEADLAMP COVER RH	TATA spare parts
554569120101	A-PILLAR TRIM ASSY UPPER-LH	TATA spare parts
554569120101ZY	CLRPRT_ASY_1-A-PILLAR TRIM ASSY UPPER-LH	TATA spare parts
554569120101ZZ	CLRPART_ASSY-A-PILLAR TRIM ASSY UPPER-LH	TATA spare parts
554569120102	A-PILLAR TRIM ASSY UPPER-RH	TATA spare parts
554569120102ZY	CLRPRT_ASY_1-A-PILLAR TRIM ASSY UPPER-RH	TATA spare parts
554569120102ZZ	CLRPART_ASSY-A-PILLAR TRIM ASSY UPPER-RH	TATA spare parts
554569120103	A-PILLAR TRIM ASSY LOWER-LH	TATA spare parts
554569120104	A-PILLAR TRIM ASSY LOWER-RH	TATA spare parts
554569130103	B-PILLAR TRIM ASSY LOWER-LH	TATA spare parts

554569130104	B-PILLAR TRIM ASSY LOWER-RH	TATA spare parts
554569306301	COVER DOCUMENT HOLDER	TATA spare parts
554569306301C7	GRANIT_BLACK-COVER DOCUMENT HOLDER BS6	TATA spare parts
554569306304	ACCESS COVER RADIATOR	TATA spare parts
554569306305	ACCESS COVER ENGINE	TATA spare parts
554569306306	TRIM COVER LH	TATA spare parts
554569306307	TRIM COVER RH	TATA spare parts
554569306312	ACCESS COVER RADIATOR	TATA spare parts
554569306313	ACCESS COVER RADIATOR	TATA spare parts
554569406301	LINER REAR WALL	TATA spare parts
554569406301C7	LINER REAR WALL BS6	TATA spare parts
554569406302	LINER REAR WALL	TATA spare parts
554569406303	LINER REAR WALL	TATA spare parts
554569406304	LINER REAR WALL	TATA spare parts
554569406305	LINER REAR WALL BS6	TATA spare parts
554569406305C7	GRANIT_BLACK-LINER REAR WALL BS6	TATA spare parts
554569406308	LINER REAR WALL BS6	TATA spare parts
554569406308C7	GRANIT_BLACK-LINER REAR WALL ACE EV	TATA spare parts
554569406310	LINER REAR WALL BS6-PH2	TATA spare parts
554569406312	LINER REAR WALL BS6	TATA spare parts
554569406312C7	GRANIT_BLACK-LINER REAR WALL BS6	TATA spare parts
554569406316C7	GRANIT_BLACK-LINER REAR WALL BS6-PH2	TATA spare parts
554569506301	ROOF LINING	TATA spare parts
554569506301AQ	LINEN-ROOF LINING	TATA spare parts
554569506304	ROOF LINING	TATA spare parts
554569506305	HEADLINER FRONT BS6	TATA spare parts
554569506305AQ	LINEN-HEADLINER FRONT BS6	TATA spare parts
554569507702	FOAM FRONT CREW LH	TATA spare parts
554569507703	FOAM FRONT CREW RH	TATA spare parts
554569707701	SEAL RADIATOR ACCESS COVER	TATA spare parts
554569707702	SEAL ENGINE ACCESS COVER	TATA spare parts
554569707704	SEAL RADIATOR ACCESS COVER	TATA spare parts
554569707706	SEAL RADIATOR ACCESS COVER	TATA spare parts
554570000103	SHELL ASSY LOAD BODY	TATA spare parts
554570000104BF	ARCTIC_WHITE-LOADBODY ASSY	TATA spare parts
554570000104CN	IRISH_CREAM-LOADBODY ASSY	TATA spare parts
554570000104J7	CHILL_METLIC-LOADBODY ASSY	TATA spare parts
554570000107	SHELL ASSY LOAD BODY	TATA spare parts
554570000108G3	LOAD BODY ASSY PAINTED PORCLN WHITE	TATA spare parts
554570000108HM	LOAD BODY ASSY PAINTED URBAN BRONZE	TATA spare parts
554570000113BF	ARCTIC_WHITE-LOAD BODY ASSY	TATA spare parts
554570000115	SHELL ASSY LOAD BODY	TATA spare parts
554570000116BF	ARCTIC_WHITE-LOAD BODY ASSY	TATA spare parts
554570000116JS	TITANIUM_WH-LOAD BODY ASSY	TATA spare parts
554570000116KO	JOSH_BLUE-LOAD BODY ASSY	TATA spare parts
554570000116L6	THUNDER_GOLD-LOAD BODY ASSY	TATA spare parts
554570000127BF	ARCTIC_WHITE-LOAD BODY ASSY	TATA spare parts

554570000132	KIT-LOAD BODY	TATA spare parts
554570000133	KIT-LOAD BODY	TATA spare parts
554570000149JS	TITANIUM_WH-LOAD BODY ASSY	TATA spare parts
554570000154	LOAD GUARD ASSY	TATA spare parts
554570000155BF	ASSY LOAD BODY ARCTIC_WHITE- BS6	TATA spare parts
554570000187	LOAD BODY ASSY BS6	TATA spare parts
554570000187CN	ASSY LOAD BODY-IRISH CREAM ACE HT+ BS6	TATA spare parts
554570000195JS	TITANIUM_WH-LOAD BODY ASSY	TATA spare parts
554570000195L6	THUNDER_GOLD-LOAD BODY ASSY BS6	TATA spare parts
554570000198	KIT-LOAD BODY LH BS6	TATA spare parts
554570000199	KIT-LOAD BODY RH BS6	TATA spare parts
554570000205BF	ARCTIC_WHITE-LOAD BODY BS6	TATA spare parts
554570010101	SHELL ASSY LOAD BODY BS6	TATA spare parts
554570010102JS	TITANIUM_WH-LOAD BODY ASSY BS6	TATA spare parts
554570100129	BRACKET ASSY MUDGUARD MTG	TATA spare parts
554570100184	FRONT WALL ASSY	TATA spare parts
554570103333	COVER PLATE BS6-PH2	TATA spare parts
554570106901	STAY ROD	TATA spare parts
554570106902	STAY ROD	TATA spare parts
554570106904	STAY ROD	TATA spare parts
554570106906	STAY ROD	TATA spare parts
554570108260	SUPPORT MUDGUARD	TATA spare parts
554570108277	SUPPORT MUDGUARD BS6	TATA spare parts
554570200103	FRONT PANEL ASSY BS6	TATA spare parts
554570300101	SIDE PANEL ASSY LH	TATA spare parts
554570300102	SIDE PANEL ASSY RH	TATA spare parts
554570300105	SIDE PANEL ASSY LH BS6	TATA spare parts
554570300106	SIDE PANEL ASSY RH BS6	TATA spare parts
554570300122	SIDE WALL ASSY LH	TATA spare parts
554570300123	SIDE WALL ASSY RH	TATA spare parts
554570400101	TAILGATE ASSY	TATA spare parts
554570400105	LATCH ASSY TAILGATE LH BS6	TATA spare parts
554570400106	TAILGATE ASSY	TATA spare parts
554570400107	TAILGATE ASSY BS6	TATA spare parts
554570900101	HINGE ASSY	TATA spare parts
554570900102	TAILGATE LOCK ASSY RH BS6	TATA spare parts
554570900103	TOGGLE CLAMP ASSY	TATA spare parts
554570906302	BALATA PACKING	TATA spare parts
554570906303	BALATA PACKING	TATA spare parts
554570906306	SEAL LOAD BODY COVER FRONT	TATA spare parts
554570908202	HANDLE LATCH LH	TATA spare parts
554570908204	HANDLE LATCH RH	TATA spare parts
554570908207	LOCK L-PLATE LH	TATA spare parts
554570908208	LOCK L-PLATE RH	TATA spare parts
554572000101	FRONT DOOR SHELL ASSY WITH HINGE LH	TATA spare parts
554572000102	FRONT DOOR SHELL ASSY WITH HINGE RH	TATA spare parts
554572000105	FRONT DOOR SHELL ASSY WITH HINGE LH	TATA spare parts

55457200M10101	FRT DR SHELL ASSY WITH HINGE LH BS6-PH2	TATA spare parts
55457200M10102	FRT DR SHELL ASSY WITH HINGE RH BS6-PH2	TATA spare parts
554572200127	GLASS GUIDE CHANNEL ASSY FRONT DOOR LH B	TATA spare parts
554572200128	GLASS GUIDE CHANNEL ASSY FRONT DOOR RH B	TATA spare parts
554572200131	INNER PANEL ASSY FRT DOOR-LH STAGE I BS6	TATA spare parts
554572200132	INNER PANEL ASSY FRT DOOR-RH STAGE I BS6	TATA spare parts
554572208201	OUTER PANEL FRONT DOOR LH BS6	TATA spare parts
554572208202	OUTER PANEL FRONT DOOR RH BS6	TATA spare parts
554572208211	INTRUSION PANEL FRONT DOOR LH BS6	TATA spare parts
554572208212	INTRUSION PANEL FRONT DOOR RH BS6	TATA spare parts
554572300115	GLASS GUIDE CHANNEL ASSY REAR-LH BS6	TATA spare parts
554572300116	GLASS GUIDE CHANNEL ASSY REAR-RH BS6	TATA spare parts
554572300119	HINGE ASSY FRONT DOOR BOTTOM-LH	TATA spare parts
554572300120	HINGE ASSY FRONT DOOR BOTTOM-RH	TATA spare parts
554572306301	DUST SEAL	TATA spare parts
554572306302	DOOR STOPPER	TATA spare parts
554572306306	DOOR STOPPER RH BS6	TATA spare parts
554572311601	OUTER HANDLE ASSY FRONT DOOR LH	TATA spare parts
554572311602	OUTER HANDLE ASSY FRONT DOOR RH	TATA spare parts
554572320106	LOCK ASSY FRONT DOOR RH BS6-PH2	TATA spare parts
554572320114	DOOR LATCH ASSY FRONT DOOR LH	TATA spare parts
554572320115	DOOR LATCH ASSY FRONT DOOR LH	TATA spare parts
554572320116	DOOR LATCH ASSY FRONT DOOR RH	TATA spare parts
554572331601	INNER HANDLE ASSY FRONT DOOR LH	TATA spare parts
554572331602	INNER HANDLE ASSY FRONT DOOR RH	TATA spare parts
554572336001	LINK POP UP KNOB TO LATCH FRONT DOOR LH	TATA spare parts
554572336002	LINK POP UP KNOB TO LATCH FRONT DOOR RH	TATA spare parts
554572336003	LINK INNER HANDLE TO LATCH FRONT DOOR LH	TATA spare parts
554572336004	LINK INNER HANDLE TO LATCH FRONT DOOR RH	TATA spare parts
554572340102	CHECK STRAP ASSY FRONT DOOR	TATA spare parts
554572510101	WINDOW REGULATOR ASSY FRONT DOOR LH	TATA spare parts
554572510102	WINDOW REGULATOR ASSY FRONT DOOR RH	TATA spare parts
554572510103	WINDOW REGULATOR ASSY FRONT DOOR LH	TATA spare parts
554572510104	WINDOW REGULATOR ASSY FRONT DOOR RH	TATA spare parts
554572511601	WINDOW REGULATOR ASSY FRONT DOOR LH	TATA spare parts
554572511602	WINDOW REGULATOR ASSY FRONT DOOR RH	TATA spare parts
554572522301	WINDOW GLASS FRONT DOOR LH	TATA spare parts
554572522302	WINDOW GLASS FRONT DOOR RH	TATA spare parts
554572536301	PRIMARY SEAL FRONT DOOR LH	TATA spare parts
554572536302	PRIMARY SEAL FRONT DOOR RH	TATA spare parts
554572546301	SECONDARY SEAL FRONT DOOR LH	TATA spare parts
554572546302	SECONDARY SEAL FRONT DOOR RH	TATA spare parts
554572556301	GLASS RUN MOULD FRONT DOOR LH	TATA spare parts
554572556302	GLASS RUN MOULD FRONT DOOR RH	TATA spare parts
554572576301	WAIST SEAL FRONT DOOR OUTER-LH	TATA spare parts
554572576302	WAIST SEAL FRONT DOOR OUTER-RH	TATA spare parts
554572576303	WAIST SEAL FRONT DOOR INNER-LH	TATA spare parts

554572576304	WAIST SEAL FRONT DOOR INNER-RH	TATA spare parts
554572700101	DOOR TRIM ASSY FRT DR MANUAL WINDING LH	TATA spare parts
554572700101ZY	CLRPRT_ASY_1-DOOR TRIM ASSY FRT DR MANUA	TATA spare parts
554572700101ZZ	CLRPART_ASSY-DOOR TRIM ASSY FRT DR MANUA	TATA spare parts
554572700102	DOOR TRIM ASSY FRT DR MANUAL WINDING RH	TATA spare parts
554572700102ZY	CLRPRT_ASY_1-DOOR TRIM ASSY FRT DR MANUA	TATA spare parts
554572700102ZZ	CLRPART_ASSY-DOOR TRIM ASSY FRT DR MANUA	TATA spare parts
554572700103	INNER COVER ASSY ORVM LH	TATA spare parts
554572700103ZY	CLRPRT_ASY_1-INNER COVER ASSY ORVM LH	TATA spare parts
554572700103ZZ	CLRPART_ASSY-INNER COVER ASSY ORVM LH	TATA spare parts
554572700104	INNER COVER ASSY ORVM RH	TATA spare parts
554572700104ZY	CLRPRT_ASY_1-INNER COVER ASSY ORVM RH	TATA spare parts
554572700104ZZ	CLRPART_ASSY-INNER COVER ASSY ORVM RH	TATA spare parts
554572700105ZY	CLRPRT_ASY_1-DOOR TRIM ASSY WITH AUTO WI	TATA spare parts
554572700106ZY	CLRPRT_ASY_1-DOOR TRIM ASSY WITH AUTO W/	TATA spare parts
554572716301	MEMBARANE FRONT DOOR LH	TATA spare parts
554572716302	MEMBARANE FRONT DOOR RH	TATA spare parts
554572716303	MEMBARANE FRONT DOOR LH BS6	TATA spare parts
554572716304	MEMBARANE FRONT DOOR RH BS6	TATA spare parts
554572901601	ORVM ASSY FRONT DOOR LH	TATA spare parts
554572901602	ORVM ASSY FRONT DOOR RH	TATA spare parts
554572980101	KIT-LOCK SET ASSY	TATA spare parts
554572980105	KIT-LOCK SET ASSY	TATA spare parts
554572980107	KIT-LOCK SET ASSY BS6-PH2	TATA spare parts
554572980108	KIT-LOCK SET ASSY BS6	TATA spare parts
554581100107	SUNVISOR ASSY WITH 2-POINT MTG LH	TATA spare parts
554581100107AQ	LINEN-SUNVISOR ASSY WITH 2-POINT MTG LH	TATA spare parts
554581100108	SUNVISOR ASSY WITH 2-POINT MTG RH	TATA spare parts
554581100108AQ	LINEN-SUNVISOR ASSY WITH 2-POINT MTG RH	TATA spare parts
554581406301	UTILITY POCKET BS6	TATA spare parts
554581406301C7	GRANIT_BLACK-UTILITY POCKET ACE EV	TATA spare parts
554582400101	WIPER LINK ASSY WITH MOTOR	TATA spare parts
554582400114	WIPER ARM WITH BLADE DRIVER SIDE	TATA spare parts
554582400116	WIPER ARM BLADE W/O NOZZLE ASSY	TATA spare parts
554582400117	LINKAGE ASSY	TATA spare parts
554582400118	WIPER ARM BLADE W/O NOZZLE ASSY	TATA spare parts
554582400119	WIPER LINK ASSY WITH MOTOR BS6	TATA spare parts
554582400120	WIPER ARM WITH BLADE DRIVER SIDE	TATA spare parts
554582400121	WIPER ARM WITH BLADE CO-DRIVER SIDE	TATA spare parts
554582400122	WIPER ARM WITH BLADE CO-DRIVER SIDE	TATA spare parts
554582400123	WIPER MOTOR ASSY	TATA spare parts
554582406301	CORRUGATED TUBE BS6	TATA spare parts
554582407501	SEAL WIPER MOUNTING LH BS6	TATA spare parts
554582407502	SEAL WIPER MOUNTING RH BS6	TATA spare parts
554582900101	KIT-WASHER SYSTEM	TATA spare parts
554582900104	KIT-WASHER SYSTEM BS6	TATA spare parts
554582909905	PIPE PUMP TO T-JOINT	TATA spare parts

554582909909	GROMMET WASHER PIPE BS6	TATA spare parts
554582909910	HOSE TUBE BS6	TATA spare parts
554582909916	NOZZLE ASSY	TATA spare parts
554583100101	ADAPTER ASSY	TATA spare parts
554583100103	FACE DUCT ASSY RH	TATA spare parts
554583100104	FACE DUCT ASSY LH	TATA spare parts
554583100105	FACE DUCT ASSY RH	TATA spare parts
554583100106	SIDE DEMIST DUCT LH	TATA spare parts
554583100107	SIDE DEMIST DUCT RH	TATA spare parts
554583100108	FACE DUCT ASSY LH	TATA spare parts
554583105301	FOAM ADAPTER	TATA spare parts
554583106301	DEFROST DUCT	TATA spare parts
554583106301C7	GRANIT_BLACK-DEFROST DUCT BS6	TATA spare parts
554583106308	ADAPTER	TATA spare parts
554583106309	ADAPTER	TATA spare parts
554583106311	DEFROST DUCT	TATA spare parts
554583106312	DISTRIBUTION BOX	TATA spare parts
554583106313	FOOT DUCT RH	TATA spare parts
554583106314	AIR DUCT UPPER	TATA spare parts
554583106315	AIR DUCT LOWER	TATA spare parts
554583106316	FOOT DUCT LH	TATA spare parts
554583300105	CONTROL PANEL	TATA spare parts
554583300108	CONTROL PANEL BS6	TATA spare parts
554583301601	CONTROL PANEL	TATA spare parts
554583400102	HVAC ASSY	TATA spare parts
554583400108	AC UNIT ASSY BS6	TATA spare parts
554583400109	HEATER ASSY	TATA spare parts
554583400110	EVAPORATOR ASSY	TATA spare parts
554583400112	BLOWER MOTOR ASSY	TATA spare parts
554583400113	EVAPORATOR ASSY BS6	TATA spare parts
554583404902	WIRING HARNESS ASSY	TATA spare parts
554583404903	WIRING HARNESS ASSY BS6	TATA spare parts
554583405301	EXPANSION VALVE	TATA spare parts
554583405302	FOAM SEAL BS6-PH2	TATA spare parts
554583406302	GRILLE AIR INTAKE	TATA spare parts
554583406303	COVER THERMOSTATIC EXPANSION VALVE LOWE	TATA spare parts
554583406304	COVER LH	TATA spare parts
554583406305	COVER RH	TATA spare parts
554583406306	COVER THERMOSTATIC EXPANSION VALVE UPPER	TATA spare parts
554583406310	COVER AC UNIT BS6	TATA spare parts
554583407701	DRAIN HOSE WITH GROMMET	TATA spare parts
554583407704	GROMMET DRAIN HOSE BS6-PH2	TATA spare parts
554583409903	STUD	TATA spare parts
554583409905	GROMMET	TATA spare parts
554583450101	CONDENSER	TATA spare parts
554583500102	HEATER CORE ASSY	TATA spare parts
554583550101	COMPRESSOR ASSY	TATA spare parts

554583554901	BRACKET LEAD WIRE BS6	TATA spare parts
554583559901	CLUTCH ASSY MAGNET BS6	TATA spare parts
554583600101	SUCTION PIPE	TATA spare parts
554583600102	SUCTION PIPE	TATA spare parts
554583600103	LIQUID PIPE	TATA spare parts
554583600104	SUCTION HOSE ASSY	TATA spare parts
554583600105	DISCHARGE HOSE ASSY	TATA spare parts
554583600106	LIQUID PIPE	TATA spare parts
554583600113	DISCHARGE HOSE ASSY BS6	TATA spare parts
554583600114	SUCTION HOSE ASSY BS6	TATA spare parts
554583650101	HEATER HOSE ASSY OUTLET	TATA spare parts
554583654201	CLAMP HEATER HOSE BS6-PH2	TATA spare parts
554583655801	HEATER HOSE INLET	TATA spare parts
554583655803	HEATER HOSE INLET	TATA spare parts
554583655804	HEATER HOSE INLET	TATA spare parts
554583655819	HEATER HOSE INLET BS6-PH2	TATA spare parts
554583656901	HEATER PIPE	TATA spare parts
554583656902	HEATER PIPE	TATA spare parts
554583656921	HEATER PIPE INLET	TATA spare parts
554583656922	PIPE SUB-ASSY_OUTLET	TATA spare parts
554583707501	GROMMET TXV CUTOUT	TATA spare parts
554583707502	GROMMET	TATA spare parts
554583750101	BRACKET ASSY AC UNIT MTG	TATA spare parts
554583750102	COVER ASSY	TATA spare parts
554583753302	P-CLAMP HEATER LINES	TATA spare parts
554583753309	BRACKET HVAC UNIT MTG RH	TATA spare parts
554583753310	BRACKET HVAC UNIT MTG LH	TATA spare parts
554583800101	AIR INTAKE ASSY	TATA spare parts
554583800102	AIR DUCT ASSY	TATA spare parts
554583809901	AIR FILTER	TATA spare parts
554584000114	HI-DECK LOAD BODY ASSY	TATA spare parts
554584100107	COVER ASSY FRONT-TOP	TATA spare parts
554584100108	COVER ASSY BATTERY BOX SIDE-LH	TATA spare parts
554584100109	COVER ASSY BATTERY BOX SIDE-RH	TATA spare parts
554584300101	COVER ASSY FRONT-BOTTOM BS6	TATA spare parts
554584500101	FRAME ASSY HIGHDECK LOAD BODY UPPER	TATA spare parts
554588100101	SPLASH GUARD ASSY WHEEL ARCH FRONT-LH	TATA spare parts
554588100102	SPLASH GUARD ASSY WHEEL ARCH FRONT-RH	TATA spare parts
554588106301	HINGE PIN BS6	TATA spare parts
554588106302	FLAP SPLASH GUARD FRONT-LH BS6	TATA spare parts
554588106303	FLAP SPLASH GUARD FRONT-RH BS6	TATA spare parts
554588106304	COVER LH BS6	TATA spare parts
554588146303	BRACKET SPLASH GUARD MTG LH BS6-PH2	TATA spare parts
554588146304	BRACKET SPLASH GUARD MTG RH BS6-PH2	TATA spare parts
554588200101	COVER ASSY FRONT WHEEL ARCH LH	TATA spare parts
554588200102	COVER ASSY FRONT WHEEL ARCH RH	TATA spare parts
554588200105	REINF ASSY FRONT WHEEL ARCH COVER LH	TATA spare parts



554588200106	REINF ASSY FRONT WHEEL ARCH COVER RH	TATA spare parts
554588206301	MUDFLAP FRONT-LH	TATA spare parts
554588206302	MUDFLAP FRONT-RH	TATA spare parts
554588206304	COVER FRONT WHEEL ARCH LH	TATA spare parts
554588206305	COVER FRONT WHEEL ARCH RH	TATA spare parts
554588206306	SIDE REPEATOR COVER LH	TATA spare parts
554588206306BF	ARCTIC_WHITE-SIDE REPEATOR COVER LH	TATA spare parts
554588206306FD	SK_GOLN_YELW-SIDE REPEATOR COVER LH BS6	TATA spare parts
554588206306JS	TITANIUM_WH-SIDE REPEATOR COVER LH	TATA spare parts
554588206306JV	STONEHENGE-SIDE REPEATOR COVER LH BS6	TATA spare parts
554588206306KO	JOSH_BLUE-SIDE REPEATOR COVER LH	TATA spare parts
554588206306L6	THUNDER_GOLD-SIDE REPEATOR COVER LH	TATA spare parts
554588206307	SIDE REPEATOR COVER RH	TATA spare parts
554588206307BF	ARCTIC_WHITE-SIDE REPEATOR COVER RH	TATA spare parts
554588206307FD	SK_GOLN_YELW-SIDE REPEATOR COVER RH BS6	TATA spare parts
554588206307JS	TITANIUM_WH-SIDE REPEATOR COVER RH	TATA spare parts
554588206307JV	STONEHENGE-SIDE REPEATOR COVER RH BS6	TATA spare parts
554588206307KO	JOSH_BLUE-SIDE REPEATOR COVER RH	TATA spare parts
554588206307L6	THUNDER_GOLD-SIDE REPEATOR COVER RH	TATA spare parts
554588206308	MUDFLAP FRONT-LH	TATA spare parts
554588206309	MUDFLAP FRONT-RH	TATA spare parts
554588300102	FOOT STEP ASSY LH	TATA spare parts
554588300103	FOOT STEP ASSY RH	TATA spare parts
554588300104	FOOT STEP ASSY LH BS6	TATA spare parts
554588300105	FOOT STEP ASSY RH BS6	TATA spare parts
554588400105	FRONT PANEL ASSY	TATA spare parts
554588400106	COVER ASSY REAR ENGINE	TATA spare parts
554588400111	FRONT PANEL ASSY	TATA spare parts
554588408201	FRONT PANEL OUTER BS6	TATA spare parts
554588408206	ENGINE COVER REAR BS6-PH2	TATA spare parts
55458840M10105	FRONT PANEL ASSY BS6-PH2	TATA spare parts
55458840M10111	FRONT PANEL ASSY BS6-PH2	TATA spare parts
554588500101	BUMPER ASSY FRONT	TATA spare parts
554588500101ZM	CLRPRT_ASY13-BUMPER ASSY FRONT BS6	TATA spare parts
554588500101ZP	CLRPRT_ASY10-BUMPER ASSY FRONT BS6	TATA spare parts
554588500101ZS	CLRPRT_ASY_7-BUMPER ASSY FRONT	TATA spare parts
554588500101ZT	CLRPRT_ASY_6-BUMPER ASSY FRONT	TATA spare parts
554588500101ZU	CLRPRT_ASY_5-BUMPER ASSY FRONT	TATA spare parts
554588500101ZW	CLRPRT_ASY_3-BUMPER ASSY FRONT	TATA spare parts
554588500101ZX	CLRPRT_ASY_2-BUMPER ASSY FRONT	TATA spare parts
554588500101ZY	TITANIUM WHITE BUMPER ASSY FRONT	TATA spare parts
554588500101ZZ	CLRPART_ASSY-BUMPER ASSY FRONT	TATA spare parts
554588500106	BUMPER ASSY FRONT	TATA spare parts
554588500106ZY	CLRPRT_ASY_1-BUMPER ASSY FRONT	TATA spare parts
554588500106ZZ	CLRPRT_ASY_1-BUMPER ASSY FRONT	TATA spare parts
554588506303B8	BRIGHT_CHROM-CHROME STRIP FRONT BUMPER	TATA spare parts
554588506303CE	PIANO_BK_PLN-CHROME STRIP FRONT BUMPER	TATA spare parts

554588506304	REFLECTIVE TAPE	TATA spare parts
554588506306B8	BRIGHT_CHROM-CHROME STRIP FRONT BUMPER	TATA spare parts
554588506306CE	PIANO_BK_PLN-CHROME STRIP FRONT BUMPER F	TATA spare parts
554588506308	GRILL LOWER	TATA spare parts
554588506308C7	GRANIT_BLACK-GRILL LOWER	TATA spare parts
554588506308L8	HYPER_SILVER-GRILL LOWER	TATA spare parts
554588506309	STRIP LH	TATA spare parts
554588506310	STRIP RH	TATA spare parts
554588800101	TRUST BAR ASSY	TATA spare parts
554588800102	LEAF SCREEN TRIM ASSY	TATA spare parts
554588800106	LEAF SCREEN ASSY TRIM	TATA spare parts
554588800109	TRUST BAR ASSY	TATA spare parts
554588800109ZU	CLRPRT_ASY_5-TRUST BAR ASSY BS6-PH2	TATA spare parts
554588800109ZY	CLRPRT_ASY_1-TRUST BAR ASSY	TATA spare parts
554588800109ZZ	CLRPART_ASSY-TRUST BAR ASSY	TATA spare parts
554588806302	FRONT GRILL	TATA spare parts
554588806308	GROMMET DRIVER SIDE	TATA spare parts
554588806309	GROMMET CO-DRIVER SIDE	TATA spare parts
554588806316AU	SATIN_CHROME - TRUST BAR	TATA spare parts
554588806316B8	BRIGHT_CHROME -TRUST BAR	TATA spare parts
554588806317C7	GRANIT_BLACK - FRONT GRILL	TATA spare parts
554588806317L8	HYPER_SILVER - FRONT GRILL	TATA spare parts
554588806319	SEAL LEAF SCREEN BS6	TATA spare parts
554589100101	SPACER PLATE ASSY	TATA spare parts
554589100102	BUSH ASSY FRONT CAB MTG	TATA spare parts
554589100103	BUSH CAB MTG REAR	TATA spare parts
554589108401	SLEEVE BODY MTG	TATA spare parts
554589108402	SLEEVE	TATA spare parts
554589108601	SPACER BODY MTG	TATA spare parts
554589109901	WASHER	TATA spare parts
554591000101	DRIVER SEAT ASSY W/O HEADREST	TATA spare parts
554591000102	DRIVER SEAT ASSY	TATA spare parts
554591000102C7	GRANIT_BLACK-DRIVER SEAT ASSY	TATA spare parts
554591000103	DRIVER SEAT ASSY	TATA spare parts
554591000106	DRIVER SEAT ASSY	TATA spare parts
554591000106C7	GRANIT_BLACK-DRIVER SEAT ASSY	TATA spare parts
554591000109	DRIVER SEAT ASSY	TATA spare parts
554591000111	DRIVER SEAT ASSY WITH HEADREST BS6	TATA spare parts
554591000112	DRIVER SEAT ASSY W/O HEADREST RH	TATA spare parts
554591000115C7	GRANIT_BLACK-DRIVER SEAT ASSY WITH HEADR	TATA spare parts
554591000118C7	GRANIT_BLACK DRIVER SEAT ASSY WITH HEAD	TATA spare parts
554591200101	BACKREST ASSY DRIVER SEAT BS6	TATA spare parts
554591200105	CUSHION ASSY DRIVER SEAT BS6	TATA spare parts
554591200107	CUSHION ASSY BS6	TATA spare parts
554591300101	BACKREST ASSY BS6	TATA spare parts
554591700101	PLASTIC COVER ASSY RECLINER BS6	TATA spare parts
554591756301	CAP RECLINER HANDLE BS6	TATA spare parts

554591756302	RECLINER COVER OUTBOARD RH BS6	TATA spare parts
554591756304	BUSH BS6	TATA spare parts
554591756305	RECLINER KNOB RH BS6	TATA spare parts
554591900101	BRACKET ASSY DRIVER SEAT MTG REAR-RH BS6	TATA spare parts
554591900102	BRACKET ASSY DRIVER SEAT MTG FRONT-RH BS	TATA spare parts
554591900103	PASSIVE SLIDE RAIL ASSY BS6	TATA spare parts
554591900104	TRACK ASSY RH BS6	TATA spare parts
554591900105	BRACKET ASSY DRIVER SEAT MTG FRONT-RH BS	TATA spare parts
554591900106	TRACK ASSY RH BS6	TATA spare parts
554591900107	PAN KIT ASSY BS6	TATA spare parts
554591900108	SLIDER ASSY BS6	TATA spare parts
554591906301	RUBBER PAD BS6	TATA spare parts
554591906302	RUBBER PAD BS6	TATA spare parts
554591910101	TIE	TATA spare parts
554591919903	KNOB BS6	TATA spare parts
554591919905	SCREW BS6	TATA spare parts
554591919906	STEP BOLT BS6	TATA spare parts
554591919907	NUT BS6	TATA spare parts
554591930102	HEADREST ASSY BS6	TATA spare parts
554594000101	CO-DRIVER SEAT ASSY W/O HEADREST	TATA spare parts
554594000102	CO-DRIVER SEAT ASSY	TATA spare parts
554594000102C7	GRANIT_BLACK-CO-DRIVER SEAT ASSY	TATA spare parts
554594000103	CO-DRIVER SEAT ASSY	TATA spare parts
554594000106	CO-DRIVER SEAT ASSY	TATA spare parts
554594000106C7	GRANIT_BLACK-CO-DRIVER SEAT ASSY	TATA spare parts
554594000112	ARMREST ASSY	TATA spare parts
554594000112C7	GRANIT_BLACK-ARMREST ASSY	TATA spare parts
554594000115	CO-DRIVER SEAT ASSY W/O HEADREST	TATA spare parts
554594000118C7	GRANIT_BLACK-CO-DRIVER SEAT ASSY WITH HE	TATA spare parts
554594000121C7	GRANIT_BLACK CO-DRIVER SEAT ASSY WITH H	TATA spare parts
554594000122C7	GRANIT_BLACKARMREST ASSY	TATA spare parts
554594000124	CO-DRIVER SEAT ASSY BS6	TATA spare parts
554594200101	CO-DRIVER SEAT CUSHION BS6	TATA spare parts
554594200104	CO-DRIVER SEAT BACKREST ASSY BS6	TATA spare parts
554594300103	BACKREST ASSY BS6-PH2	TATA spare parts
554594700101	PLASTIC COVER RECLINER BS6-PH2	TATA spare parts
554597500101	SEAT BELT ELR FRONT LH	TATA spare parts
554597500101C7	GRANIT_BLACK_SEAT BELT ELR FRONT-LH	TATA spare parts
554597500102	TWIN BUCKLE ASSY DRIVER & MIDDLE SEAT	TATA spare parts
554597500102C7	GRANIT_BLACK_TWIN BUCKLE ASSY DRIVER AND	TATA spare parts
554597500103	LAP & WEBBING BELT ASSY. CO-DR & MID SEA	TATA spare parts
554597500103C7	GRANIT_BLACK_LAP & WEBBING BUCKLE ASSY C	TATA spare parts
554597500104	SEAT BELT ELR FRONT RH	TATA spare parts
554597500104C7	GRANIT_BLACK_SEAT BELT ELR FRONT-RH	TATA spare parts
554597500105C7	GRANIT_BLACK SEAT BELT ASSY WITH ELR FRO	TATA spare parts
554597500106C7	GRANIT_BLACK SEAT BELT ASSY WITH ELR FRO	TATA spare parts
554597500107	WEBBING BUCKLE ASSY CO-DRIVER	TATA spare parts

554597500107C7	GRANIT_BLACK-WEBBING BUCKLE ASSY CO-DRIV	TATA spare parts
554597500108C7	GRANIT_BLACK- WEBBING BUCKLE ASSY DRIVER	TATA spare parts
554597500111C7	GRANIT_BLACK-SEAT BELT ASSY WITH ELR FRO	TATA spare parts
554597500112C7	GRANIT_BLACK-SEAT BELT ASSY WITH ELR FRO	TATA spare parts
554597500113	LAP - WEBBING BUCKLE ASSY CO-DR-MID SEAT	TATA spare parts
554597500119	SEAT BELT ASSY WITH ELR FRONT-LH BS6	TATA spare parts
554597500119C7	GRANIT_BLACK-SEAT BELT ASSY WITH ELR FRO	TATA spare parts
554597500120	SEAT BELT ASSY WITH ELR FRONT-RH BS6	TATA spare parts
554597500120C7	GRANIT_BLACK-SEAT BELT ASSY WITH ELR FRO	TATA spare parts
554597500123	WEBBING BUCKLE ASSY CO-DRIVER BS6	TATA spare parts
554597500123C7	GRANIT_BLACK-WEBBING BUCKLE ASSY CO-DRIV	TATA spare parts
554597500124	WEBBING BUCKLE ASSY DRIVER BS6	TATA spare parts
554597500124C7	GRANIT_BLACK-WEBBING BUCKLE ASSY DRIVER	TATA spare parts
554597980102	KIT SEAT BELT FRONT	TATA spare parts
554597980102C7	GRANIT_BLACK-KIT-SEAT BELT FRONT	TATA spare parts
554597980103C7	GRANIT_BLACK KIT-SEAT BELT WITH ELR FRON	TATA spare parts
554597980105	KIT-SEAT BELT WITH ELR - LAP BELT FRONT	TATA spare parts
554599008001	CR FLANGE PAN HEAD SPECIAL SCREW BS6	TATA spare parts
5545A9Z0170001JS	TITANIUM_WHITE_LOADBODY ASSY BS6-PH2	TATA spare parts
5545A9Z0170003	LOADBODY FITTED ASSY MFG BS6-PH2	TATA spare parts
5545A9Z0170003JS	TITANIUM_WHITE_LOADBODY ASSY BS6-PH2	TATA spare parts
5545A9Z0170004BF	ARCTIC_WHITE_LOAD BODY ASSY BS6-PH2	TATA spare parts
5545D1D0470004	TAILGATE ASSY BS6-PH2	TATA spare parts
5545D9Y0160001JS	TITANIUM_WH-PAINTED BODY SHELL-MFG BS6-P	TATA spare parts
5545D9Y0160001L6	THUNDER_GOLD-PAINTED BODY SHELL-MFG BS6	TATA spare parts
5545D9Y0160003JS	TITANIUM_WHITE-BODY SHELL ASSY PAINTED B	TATA spare parts
5545H9X0233002	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
554600990101	KIT-9 INCH BOOSTER IN INTRA V30 LOW END	TATA spare parts
554600990102	KIT-9 INCH BOOSTER IN INTRA V30 HIGH END	TATA spare parts
554615100103	STARTER MOTOR ASSY BS6	TATA spare parts
554615100104	FIXING BRACKET ASSY BS6	TATA spare parts
554615100105	DRIVE ASSY BS6	TATA spare parts
554615100106	KIT-FASTENERS BS6	TATA spare parts
554615100107	KIT-PINION BS6	TATA spare parts
554624103801	BRACKET C-MOUNT BS6	TATA spare parts
554624200101	C-MOUNT ASSY BS6	TATA spare parts
554629100105	CLUTCH PEDAL ASSY WITH BUSH BS6	TATA spare parts
554629100106	CLUTCH¿CABLE¿ASSY	TATA spare parts
554629100107	BUNDY TUBE ASSY CMC TO FIREWALL BS6	TATA spare parts
554629100108	BUNDY TUBE ASSY MIDDLE BS6	TATA spare parts
554629100109	CONCENTRIC SLAVE CYLINDER ASSY BS6	TATA spare parts
554629100110	CLUTCH MASTER CYLINDER WITH HOSE BS6	TATA spare parts
554629100111	BUNDY TUBE ASSY CLUTCH PIPE BS6	TATA spare parts
554629100112	HOSE PIPE ASSY BS6	TATA spare parts
554629100115	HIGH PRESSURE CLUTCH PIPE ASSY BS6	TATA spare parts
554629100117	BUNDY TUBE ASSY MIDDLE BS6	TATA spare parts
554629100118	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts

554629100119	BUNDY TUBE ASSY CMC TO FIREWALL BS6	TATA spare parts
554629100122	CLUTCH PEDAL ASSY WITH BUSH BS6-PH2	TATA spare parts
554629100125	BUNDY TUBE ASSY LONG MEMBER BS6-PH2	TATA spare parts
554629100130	CLUTCH MASTER CYLINDER WITH HOSE BS6	TATA spare parts
554629103301	SUPPORT BRACKET CCB BS6	TATA spare parts
554629107501	GROMMET CLUTCH PIPE BS6	TATA spare parts
554629108702	RETURN SPRING CLUTCH PEDAL BS6	TATA spare parts
554629200103	BRAKE PEDAL ASSY WITH BUSH BS6	TATA spare parts
554629203304	BRACKET CLUTCH PIPE MTG BS6	TATA spare parts
554629208602	SPACER BS6	TATA spare parts
554629500105	BRACKET ASSY CLUTCH & BRAKE PEDAL MTG BS	TATA spare parts
554629500106	BRACKET ASSY CONTROL MTG BS6	TATA spare parts
554629500112	BRACKET ASSY MTG BS6	TATA spare parts
554629500140	BRKT ASSY CLUTCH & BR PEDAL MTG BS6-PH2	TATA spare parts
554629507701	PACKING FOAMBS6	TATA spare parts
554631000101	FRAME ASSY BS6	TATA spare parts
554631000102	FRAME ASSY	TATA spare parts
554631000103	FRAME ASSY WITH TOP COAT	TATA spare parts
554631000104	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
554631000107	FRAME ASSY	TATA spare parts
554631000108	FRAME ASSY WITH TOP COAT	TATA spare parts
554631000110	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
554631000122	FRAME ASSY WITH TOP COAT BS6-PH2	TATA spare parts
554631200103	CROSS MEMBER ASSY ENGINE MTG	TATA spare parts
554631200116	CROSS MEMBER ASSY FRONT BS6	TATA spare parts
554631203331	BRACKET SIDE SUPPORT MTG BS6	TATA spare parts
554631240103	BRACKET ASSY ENGINE MTG LH BS6	TATA spare parts
554631240104	BRACKET ASSY ENGINE MTG FRONT-RH BS6	TATA spare parts
554631423301	BRACKET PARKING BRAKE CABLE FRONT BS6	TATA spare parts
554631423302	BRACKET CABLE MTG BS6	TATA spare parts
554631423303	BRACKET CABLE MTG BS6	TATA spare parts
554631893343	BRACKET CAB SUPPORT RH BS6	TATA spare parts
554631893344	BRACKET CAB SUPPORT LH BS6	TATA spare parts
554631893345	BRACKET CAB MTG RH BS6	TATA spare parts
554631893346	BRACKET CAB MTG LH BS6	TATA spare parts
554632100102	1ST LEAF ASSY WITH BUSHBS6	TATA spare parts
554632100103	LEAF SPRING ASSY FRONT BS6	TATA spare parts
554632100104	GUIDE PLATE ASSY BS6	TATA spare parts
554632100110	LEAF SPRING ASSY FRONT	TATA spare parts
554632100111	1ST LEAF ASSY	TATA spare parts
554632100113	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
554632100114	LEAF SPRING ASSY FRONT BS6	TATA spare parts
554632100117	BUSH ASSY BS6	TATA spare parts
554632100118	BUSH ASSY BS6	TATA spare parts
554632103201	CENTER BOLT BS6	TATA spare parts
554632104201	U-CLAMP FRONT BS6	TATA spare parts
554632104202	U-CLAMP FRONT SPRING	TATA spare parts

554632107101	5TH LEAFBS6	TATA spare parts
554632107102	4TH LEAFBS6	TATA spare parts
554632107104	2ND LEAFBS6	TATA spare parts
554632107106	3RD LEAFBS6	TATA spare parts
554632107111	2ND LEAF	TATA spare parts
554632107112	3RD LEAF	TATA spare parts
554632107113	4TH LEAF	TATA spare parts
554632107115	5TH LEAF	TATA spare parts
554632107116	6TH LEAF	TATA spare parts
554632107118	2ND LEAF BS6	TATA spare parts
554632107119	3RD LEAF BS6	TATA spare parts
554632107120	4TH LEAF BS6	TATA spare parts
554632107121	5TH LEAF BS6	TATA spare parts
554632109201	WASHER DAMPER BS6	TATA spare parts
554632109202	WASHER DAMPER BS6	TATA spare parts
554632300101	SHOCK ABSORBER ASSY FRONT BS6	TATA spare parts
554632400101	1ST LEAF ASSY WITH BUSHBS6	TATA spare parts
554632400102	CLAMP ASSYBS6	TATA spare parts
554632400104	LEAF SPRING ASSY REAR BS6	TATA spare parts
554632400109	GUIDE PLATE ASSY BS6	TATA spare parts
554632400115	1ST LEAF ASSY WITH BUSH	TATA spare parts
554632400116	LEAF SPRING ASSY REAR	TATA spare parts
554632400120	LEAF SPRING ASSY REAR BS6	TATA spare parts
554632400121	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
554632400122	CLAMP ASSY BS6	TATA spare parts
554632403201	CENTER BOLT BS6	TATA spare parts
554632404201	CLAMPBS6	TATA spare parts
554632404202	U-CLAMP REAR BS6	TATA spare parts
554632404203	U-CLAMP REAR BS6	TATA spare parts
554632407101	3RD LEAFBS6	TATA spare parts
554632407102	2ND LEAF BS6	TATA spare parts
554632407103	5TH LEAFBS6	TATA spare parts
554632407107	4TH LEAFBS6	TATA spare parts
554632407115	6TH LEAF	TATA spare parts
554632407116	3RD LEAF	TATA spare parts
554632407117	5TH LEAF	TATA spare parts
554632407119	7TH LEAF	TATA spare parts
554632407120	2ND LEAF	TATA spare parts
554632407122	4TH LEAF	TATA spare parts
554632407131	2ND LEAF BS6	TATA spare parts
554632407132	3RD LEAF BS6	TATA spare parts
554632407133	4TH LEAF BS6	TATA spare parts
554632407134	5TH LEAF BS6	TATA spare parts
554632407135	6TH LEAF BS6	TATA spare parts
554632407136	7TH LEAF BS6	TATA spare parts
554632407137	8TH LEAF BS6	TATA spare parts
554632600101	SHOCK ABSORBER ASSY REAR BS6	TATA spare parts

554632800101	LINK ASSY ANTI ROLL BAR	TATA spare parts
554632800102	ANTI ROLL BAR ASSY FRONT	TATA spare parts
554632800103	ANTI ROLL BAR ASSY WITH CRIMPED WASHER	TATA spare parts
554632800104	ANTI ROLL BAR ASSY WITH CRIMPED WASHER B	TATA spare parts
554632800105	ANTI ROLL BAR ASSY FRONT BS6	TATA spare parts
554632800106	LINK ASSY ANTI ROLL BAR BS6	TATA spare parts
554632807902	ANTI ROLL BAR FRONT BS6	TATA spare parts
554632990101	KIT-SUSPENSION ASSY	TATA spare parts
554633000101	FRONT AXLE ASSY BS6	TATA spare parts
554633000103	FRONT AXLE ASSY WITH BRAKE BS6	TATA spare parts
554633100101	FRONT AXLE TUBE ASSY BS6	TATA spare parts
554633200102	STUB AXLE ASSY LH BS6	TATA spare parts
554633200103	STUB AXLE ASSY RH BS6	TATA spare parts
554633403702	FRONT HUB BS6	TATA spare parts
554633805102	STEERING ARM BS6	TATA spare parts
554640100103	WHEEL RIM ASSY BS6	TATA spare parts
554640103201	BOLT WHEEL MOUNTING FRONT BS6	TATA spare parts
554640109905	LABEL TYRE PRESSURE INSTRUCTION BS6	TATA spare parts
554640203201	BOLT WHEEL BS6	TATA spare parts
554640203202	BOLT WHEEL MOUNTING REAR BS6	TATA spare parts
554640300101	TUBE ASSY SPARE WHEEL CARRIER BS6	TATA spare parts
554640306501	HEX NUT SPARE WHEEL MTG BS6	TATA spare parts
554641100101	PROPELLER SHAFT ASSY BS6	TATA spare parts
554641100102	PROPELLER SHAFT ASSY BS6	TATA spare parts
554642100102	CALIPER ASSY LH BS6	TATA spare parts
554642100103	CALIPER ASSY RH BS6	TATA spare parts
554642100104	KIT-SLIDING PIN BS6	TATA spare parts
554642100105	KIT-PAD ASSY BS6	TATA spare parts
554642100106	MAJOR KIT-CALIPER BS6	TATA spare parts
554642100107	KIT-CARRIER ASSY BS6	TATA spare parts
554642100109	MINOR KIT-CALIPER BS6	TATA spare parts
554642100111	KIT-BLEEDER BS6	TATA spare parts
554642100114	CALIPER ASSY LH BS6	TATA spare parts
554642100115	CALIPER ASSY RH BS6	TATA spare parts
554642100125	KIT-PAD ASSY BS6	TATA spare parts
554642103701	BRAKE DISC FRONT BS6	TATA spare parts
554642300102	BRAKE ASSY SHOE TYPE (LH)	TATA spare parts
554642300103	BRAKE ASSY SHOE TYPE (RH)	TATA spare parts
554642300105	DRUM BRAKE ASSY REAR-LH BS6	TATA spare parts
554642300106	DRUM BRAKE ASSY REAR-RH BS6	TATA spare parts
554642300111	WHEEL CYLINDER ASSY	TATA spare parts
554642300112	MINOR KIT-WHEEL CYLINDER ASSY	TATA spare parts
554642300113	BACK PLATE ASSY RH BS6	TATA spare parts
554642300117	KIT-LEVER PAWL LH BS6	TATA spare parts
554642300118	KIT-LEVER PAWL RH BS6	TATA spare parts
554642300119	KIT-SPRING PAD BS6	TATA spare parts
554642300121	BACK PLATE ASSY LH BS6	TATA spare parts

554642300123	KIT-LINED SHOE ASSY BS6	TATA spare parts
554642303701	BRAKE DRUM (FINISHED) BS6	TATA spare parts
554642303702	BRAKE DRUM BS6	TATA spare parts
554642700103	PARKING&BRAKE&CABLE&ASSY&FRONT	TATA spare parts
554642700104	PARKING BRAKE CABLE ASSY REAR-LH BS6	TATA spare parts
554642700105	PARKING BRAKE CABLE ASSY REAR-RH BS6	TATA spare parts
554642700106	PARKING BRAKE CABLE	TATA spare parts
554642700107	PARKING BRAKE CABLE	TATA spare parts
554642700109	PARKING BRAKE CABLE ASSY FRONT BS6	TATA spare parts
554642700110	PARKING BRAKE LEVER ASSY WITH GRIP	TATA spare parts
554643100101	BRAKE FLUID RESERVOIR ASSY BS6	TATA spare parts
554643500101	VACUUM&PIPE&ASSY	TATA spare parts
554643500105	VACUUM HOSE ASSY BS6	TATA spare parts
554643500106	VACUUM PIPE ASSY BS6	TATA spare parts
554643500107	VACUUM BOOSTER ASSY BS6	TATA spare parts
554643500108	VACUUM HOSE ASSY PUMP END BS6	TATA spare parts
554643500111	VACUUM PIPE ASSY BS6	TATA spare parts
554643500118	MASTER CYLINDER ASSY BS6	TATA spare parts
554643500119	BOOSTER ASSY BS6	TATA spare parts
554643500120	KIT-NON RETURN VALVE BS6	TATA spare parts
554643500121	NON RETURN VALVE BS6	TATA spare parts
554643500123	VACUUM PIPE ASSY BS6-PH2	TATA spare parts
554643500125	VACUUM BOOSTER ASSY BS6-PH2	TATA spare parts
554643500126	BOOSTER ASSY BS6-PH2	TATA spare parts
554643500127	MASTER CYLINDER ASSY BS6-PH2	TATA spare parts
554643505802	HOSE BOOSTER ENDBS6	TATA spare parts
554643506801	BULKHEAD BS6	TATA spare parts
554643507501	GROMMET BS6	TATA spare parts
554643800101	TUBE ASSY TMC SECONDARY TO T-CONN BS6	TATA spare parts
554643800102	TUBE ASSY TMC PRIMARY TO T-CONN BS6	TATA spare parts
554643800103	TUBE ASSY T-CONN TO BRAKE HOSE FRT-RH BS	TATA spare parts
554643800104	TUBE ASSY T-CONN TO BRAKE HOSE FRT-LH BS	TATA spare parts
554643800105	TUBE ASSY T-CONN TO LCRV BS6	TATA spare parts
554643800106	TUBE ASSY T-CONN TO LCRV BS6	TATA spare parts
554643800107	TUBE ASSY REAR HOSE TO BRAKE ASSY RH BS6	TATA spare parts
554643800108	TUBE ASSY REAR HOSE TO BRAKE ASSY LH BS6	TATA spare parts
554643800113	TUBE ASSY TMC PRIMARY TO T-CONN BS6	TATA spare parts
554643800114	TUBE ASSY TMC SECONDARY TO T-CONN BS6	TATA spare parts
554643800122	TUBE ASSY T-CONN TO LCRV BS6-PH2	TATA spare parts
554643800124	TUBE ASSY T-CONN TO LCRV BS6-PH2	TATA spare parts
554643800127	TUBE ASSY TMC PRIMARY TO T-CONN BS6-PH2	TATA spare parts
554643800128	TUBE ASSY TMC SECONDARY TO T-CONN BS6-PH	TATA spare parts
554643803303	BRACKET LCRV MTG AXLE BS6	TATA spare parts
554643804201	CLAMP BS6	TATA spare parts
554643805801	HOSE RESERVOIR TO TMC PRIMARY BS6	TATA spare parts
554643805802	HOSE RESERVOIR TO TMC SECONDARY BS6	TATA spare parts
554646200101	BRACKET ASSY POWER STG LINE BS6	TATA spare parts



554646600101	POWER STEERING PUMP ASSY BS6	TATA spare parts
554646600102	RELIEF VALVE ASSY BS6	TATA spare parts
554646800101	HIGH PRESSURE LINE ASSY PUMP TO STG GB B	TATA spare parts
554646800102	SUCTION LINE ASSY RESERVOIR TO PUMP BS6	TATA spare parts
554646800103	RETURN LINE ASSY GEAR BOX TO RESERVOIR B	TATA spare parts
554646800104	RETURN LINE ASSY GEAR BOX TO RESERVOIR B	TATA spare parts
554646805801	SUCTION HOSE BS6	TATA spare parts
554646900101	DRAG LINK BS6	TATA spare parts
554646900102	DRAG LINK ASSY BS6	TATA spare parts
554647100101	BRACKET¿ASSY¿FILTER¿¿SEDIMENTER¿MTG	TATA spare parts
554647100103	FUEL¿TANK¿ASSY	TATA spare parts
554647103302	BRACKET	TATA spare parts
554647103304	BRACKET FUEL FILTER MTG BS6	TATA spare parts
554647106301	FUEL TANKBS6	TATA spare parts
554647503301	BRACKET FUEL FILTER MTG BS6-PH2	TATA spare parts
554647600102	FUEL RETURN PIPE ASSY	TATA spare parts
554647600103	FUEL SUCTION PIPE ASSY	TATA spare parts
554647600104	FUEL¿SUCTION¿PIPE¿ASSY	TATA spare parts
554647600105	FUEL¿SUCTION¿PIPE¿ASSY	TATA spare parts
554647600107	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554647600108	FUEL RETURN PIPE ASSY BS6	TATA spare parts
554647600110	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554647600113	FUEL RETURN PIPE ASSY BS6	TATA spare parts
554647600121	FUEL RETURN PIPE ASSY BS6	TATA spare parts
554647600122	FUEL RETURN PIPE ASSY BS6	TATA spare parts
554647600123	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554649200101	PIPE ASSY FRONT	TATA spare parts
554649200102	SILENCER ASSY WITH HOOK	TATA spare parts
554649200103	EXHAUST PIPE WITH SILENCER ASSY FRONT BS	TATA spare parts
554649200114	EXHAUST FLEXIBLE BELLOW ASSY BS6-PH2	TATA spare parts
554649200116	BRACKET ASSY WITH HOOK BS6-PH2	TATA spare parts
554654304901	TANK UNIT WITH THICK FILM RESISTANCE	TATA spare parts
554654307701	GASKET	TATA spare parts
554654600101	WIRING HARNESS BATTERY CABLE +VE	TATA spare parts
554654600102	WIRING HARNESS CABIN	TATA spare parts
554654600103	WIRING¿HARNESS¿CHASSIS	TATA spare parts
554654600104	WIRING¿HARNESS¿EMS	TATA spare parts
554654600105	BATTERY¿CABLE¿-VE	TATA spare parts
554654600106	EARTH¿STRAP	TATA spare parts
554654600107	WIRING HARNESS CHASSIS BS6	TATA spare parts
554654600108	WIRING HARNESS EMS BS6	TATA spare parts
554654600109	WIRING HARNESS CABIN BS6	TATA spare parts
554654600111	WIRING HARNESS BATTERY CABLE +VE BS6	TATA spare parts
554654600115	WIRING HARNESS CABIN BS6	TATA spare parts
554654600120	RELAY¿COVER¿ASSY	TATA spare parts
554654600124	RELAY COVER ASSY BS6	TATA spare parts
554654600125	RELAY COVER ASSY BS6	TATA spare parts

554654600126	WIRING HARNESS CHASSIS BS6	TATA spare parts
554654600127	WIRING HARNESS EMS BS6-PH2	TATA spare parts
554654600129	RELAY COVER ASSY	TATA spare parts
554654600130	WIRING HARNESS CABIN	TATA spare parts
554654600131	WIRING HARNESS CHASSIS	TATA spare parts
554654600139	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
554654600144	WIRING HARNESS CHASSIS BS6	TATA spare parts
554654600145	WIRING HARNESS CHASSISBS6	TATA spare parts
554654600149	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
554654600151	RELAY COVER ASSY BS6-PH2	TATA spare parts
554654600156	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
554654600163	WIRING HARNESS EMS BS6-PH2	TATA spare parts
554654600164	WIRING HARNESS BATTERY CABLE +VE BS6-PH2	TATA spare parts
554654600171	WIRING HARNESS-CHASSIS BS6	TATA spare parts
554654600172	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
554654600174	RELAY COVER ASSY BS6-PH2	TATA spare parts
554654600180	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
554654600181	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
554654600182	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
554654600185	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
554654600186	RELAY COVER ASSY BS6-PH2	TATA spare parts
554654600192	RELAY COVER ASSY BS6-PH2	TATA spare parts
554654600198	WIRING HARNESS EMS BS6-PH2	TATA spare parts
554654603301	BRACKET BATTERY +VE	TATA spare parts
554654603303	BRACKET RELAY - FUSE BOX MTG	TATA spare parts
554654603306	BRACKET WIRING HARNESS MTG BS6	TATA spare parts
554654603307	BRACKET WIRING HARNESS MTG BS6	TATA spare parts
554654603308	BRACKET WIRING HARNESS MTG BS6	TATA spare parts
554654603309	BRACKET RELAY BASE MTG BS6	TATA spare parts
554654603311	BRACKET ENGINE WIRING HARNESS MTG BS6	TATA spare parts
554654603312	BRACKET STARTER ALTERNATOR W/H MTG BS6	TATA spare parts
554654603314	BRACKET RELAY BASE MTG BS6	TATA spare parts
554654603315	BRACKET RELAY BASE MTG BS6-PH2	TATA spare parts
554654606304	FUSE BOX COVER BS6	TATA spare parts
554654606311	FUSE BOX COVER BS6	TATA spare parts
554654719902	ECU VEHICLE TRACKING ASSY BS6-PH2	TATA spare parts
554654900101	BRACKET ASSY ECU MTG BS6	TATA spare parts
554658304001	WHEEL SPANNER BS6	TATA spare parts
554658901804	ADAPTER CHECKING ENGINE COMPRESSION BS6	TATA spare parts
554660000105JS	TITANIUM_WH-BODY SHELL ASSY PAINTED BS6	TATA spare parts
554660000105KO	JOSH_BLUE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
554660000108JS	TITANIUM_WH-BODY SHELL ASSY PAINTED	TATA spare parts
554660000108KO	JOSH_BLUE-BODY SHELL ASSY PAINTED	TATA spare parts
554660000110BF	ASSY BODY SHELL ARCTIC_WHITE BS6	TATA spare parts
554660000110CN	IRISH_CREAM-BODY SHELL ASSY PAINTED BS6-	TATA spare parts
554660000110FD	SK_GOLN_YELW-BODY SHELL ASSY PAINTED BS6	TATA spare parts
554660000110JS	TITANIUM_WH-BODY SHELL ASSY PAINTED BS6	TATA spare parts

554660000110KO	JOSH_BLUE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
554660000112JS	TITANIUM_WH-BODY SHELL ASSY PAINTED	TATA spare parts
554660000112KO	JOSH_BLUE-BODY SHELL ASSY PAINTED	TATA spare parts
554661600102	REINFORCEMENT ASSY WITH NUT LH BS6	TATA spare parts
554661600116	BRACKET ASSY ENGINE COVER MTG BS6	TATA spare parts
554661600119	ENGINE COVER ASSY	TATA spare parts
554661600146	SIDE SILL ASSY INNER-FRONT-LH BS6	TATA spare parts
554661600147	SIDE SILL ASSY INNER-FRONT-RH BS6	TATA spare parts
554661600148	COVER ASSY	TATA spare parts
554661600160	FRONT FLOOR ASSY WITH SUBSTRUCTURE BS6	TATA spare parts
554661600173	FRONT FLOOR ASSY WITH SUBSTRUCTURE	TATA spare parts
554661600189	FRONT FLOOR ASSY WITH SUBSTRUCTURE	TATA spare parts
55466160M10102	REINFORCEMENT ASSY WITH NUT LH BS6-PH2	TATA spare parts
55466160M10116	BRACKET ASSY ENGINE COVER MTG BS6-PH2	TATA spare parts
55466160M10119	ENGINE COVER ASSY BS6-PH2	TATA spare parts
55466160M10139	SUBSTRUCTURE ASSY REAR BS6-PH2	TATA spare parts
55466160M10148	SIDE SILL ASSY INNER-FRONT-RH BS6-PH2	TATA spare parts
55466160M10149	SIDE SILL ASSY INNER-FRONT-LH BS6-PH2	TATA spare parts
55466160M10173	FRT FLOOR ASSY WITH SUBSTRUCTURE BS6-PH2	TATA spare parts
55466160M10189	FRONT FLOOR ASSY WITH SUBSTRUCTURE BS6-P	TATA spare parts
554662000105	FRONT WALL ASSY BS6	TATA spare parts
554662000108	FRONT WALL ASSY BS6	TATA spare parts
55466200M10105	FRONT WALL ASSY BS6-PH2	TATA spare parts
55466200M10108	FRONT WALL ASSY BS6-PH2	TATA spare parts
554663600109	WHEEL ARCH ASSY OUTER-LH BS6	TATA spare parts
554663600110	WHEEL ARCH ASSY OUTER-RH BS6	TATA spare parts
554663600113	SIDE WALL ASSY INNER-LH BS6	TATA spare parts
554663600114	SIDE WALL ASSY INNER-RH BS6	TATA spare parts
554664000105	REAR WALL ASSY BS6	TATA spare parts
55466400M10105	REAR WALL ASSY BS6-PH2	TATA spare parts
554668506301	CARPET ENGINE COVER BS6	TATA spare parts
554669707701	SEAL¿ENGINE¿ACCESS¿COVER	TATA spare parts
554669707702	SEAL¿ENGINE¿ACCESS¿COVER	TATA spare parts
554669707703	SEAL¿ENGINE¿ACCESS¿COVER	TATA spare parts
554670000104JS	TITANIUM_WH-LOAD BODY ASSY	TATA spare parts
554670000104KO	JOSH_BLUE-LOAD BODY ASSY	TATA spare parts
554670000112	SHELL ASSY LOAD BODY BS6	TATA spare parts
554670000113JS	TITANIUM_WH-LOAD BODY ASSY BS6	TATA spare parts
554670000113KO	JOSH_BLUE-LOAD BODY ASSY BS6	TATA spare parts
554670000191JS	TITANIUM_WH-FLAT BED LOAD BODY ASSY BS6	TATA spare parts
55467000M10001	LOADBODY SHELL WELDED BS6	TATA spare parts
554670010104	LOAD BODY ASSY PAINTED BS6-PH2	TATA spare parts
554670100168	SKIRT PANEL ASSY BS6	TATA spare parts
554670106301	REFLECTIVE TAPE BS6	TATA spare parts
554670106303	REFLECTIVE TAPE BS6	TATA spare parts
554670118207	BRACKET HINGE ACE EV	TATA spare parts
554670200114	COVER ASSY FRONT	TATA spare parts

554670208246	HINGE SUPPORT ACE EV	TATA spare parts
554670300115	SIDE PANEL ASSY LH BS6	TATA spare parts
554670300116	SIDE PANEL ASSY RH BS6	TATA spare parts
554670300126	SIDE PANEL ASSY LH BS6	TATA spare parts
554670300128	SIDE PANEL ASSY RH BS6	TATA spare parts
554670400108	TAILGATE ASSY	TATA spare parts
554670500101	TUBE ASSY BS6	TATA spare parts
554670906302	SEAL LOAD BODY COVER FRONT	TATA spare parts
554670906313	MUDFLAP BS6	TATA spare parts
554683450101	CONDENSER	TATA spare parts
554683600101	LIQUID PIPE CONDENSER END BS6	TATA spare parts
554683600102	DISCHARGE PIPE CONDENSER END BS6	TATA spare parts
554683600103	DISCHARGE PIPE ASSY REAR BS6	TATA spare parts
554683600104	SUCTION PIPE ASSY REAR CAB	TATA spare parts
554683600105	SUCTION PIPE COMPRESSOR END	TATA spare parts
554683600106	DISCHARGE PIPE COMPRESSOR END	TATA spare parts
554683600107	SUCTION PIPE COMPRESSOR END BS6	TATA spare parts
554683600108	LIQUID PIPE CONDENSER END	TATA spare parts
554683600109	SUCTION PIPE COMPRESSOR END	TATA spare parts
554683600110	DISCHARGE PIPE ASSY REAR	TATA spare parts
554683600111	DISCHARGE PIPE CONDENSER END	TATA spare parts
554683600115	SUCTION PIPE MIDDLE BS6-PH2	TATA spare parts
554683600116	LIQUID PIPE ASSY BS6-PH2	TATA spare parts
554683650103	CLAMP ASSY	TATA spare parts
554683654202	CLAMP HEATER HOSE BS6-PH2	TATA spare parts
554683655806	HEATER HOSE HVAC END INTAKE	TATA spare parts
554683655807	HEATER HOSE HVAC END OUTLET	TATA spare parts
554683655808	HEATER HOSE ENGINE INTAKE MIDDLE	TATA spare parts
554683655809	HEATER HOSE HVAC TO RAD PIPE OUTLET	TATA spare parts
554683655810	HEATER HOSE ENGINE INTAKE END	TATA spare parts
554683656904	HEATER PIPE OUTLET	TATA spare parts
554683656905	HEATER PIPE ASSY INTAKE	TATA spare parts
554683656906	HEATER PIPE ASSY	TATA spare parts
554683750101	BRACKET ASSY AC PIPE MTG BS6	TATA spare parts
554683750102	BRACKET ASSY AC PIPE MTG	TATA spare parts
554683753304	BRACKET HEATER PIPE MTG	TATA spare parts
554683753309	BRACKET BS6-PH2	TATA spare parts
554683753310	BRACKET AC PIPE MTG BS6-PH2	TATA spare parts
554683753312	BRACKET HEATER HOSE MTG BS6-PH2	TATA spare parts
554683784201	P-CLAMP AC LINES	TATA spare parts
554684000107BF	ASSY LOAD BODY ARCTIC_WHITE-HI-DECK BS6	TATA spare parts
554684500102	FRAME ASSY HIGHDECK LOAD BODY UPPER BS6	TATA spare parts
554684906301	SEAL (LOAD BODY FRONT COVER) BS6	TATA spare parts
554688100101	SPLASH GUARD ASSY WHEEL ARCH FRONT-LH BS	TATA spare parts
554688100102	SPLASH GUARD ASSY WHEEL ARCH FRONT-RH BS	TATA spare parts
554688146303	BRACKET SPLASH GUARD MTG LH BS6	TATA spare parts
554688146304	BRACKET SPLASH GUARD MTG RH BS6	TATA spare parts

554688400101	COVER¿ASSY¿REAR¿ENGINE	TATA spare parts
554688408201	ENGINE COVER REAR BS6	TATA spare parts
5546A9Z0170001	LOADBODY FITTED ASSY MFG BS6-PH2	TATA spare parts
5546D1D0470001	TAILGATE ASSY BS6-PH2	TATA spare parts
5546D1D0770001	HIGH DECK TUBULAR STRUCTURE BS6-PH2	TATA spare parts
5546D9Y0160001JS	TITANIUM_ WHITE-PAINTED BODY SHELL ASSY B	TATA spare parts
5546D9Y0160001KO	JOSH_ BLUE-PAINTED BODY SHELL ASSY BS6-PH	TATA spare parts
5546D9Y0160002BF	ARCTIC_ WHITE_ BODY SHELL ASSY PAINTED BS6	TATA spare parts
5546D9Y0160002HM	URBAN_ BRONZE_ BODY SHELL ASSY PAINTED BS6	TATA spare parts
5546D9Y0160002JS	TITANIUM_ WHITE-BODY SHELL ASSY PAINTED B	TATA spare parts
5546D9Y0160002KO	JOSH_ BLUE_ BODY SHELL ASSY PAINTED BS6-PH	TATA spare parts
5546H9X0233002	FRONT AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
55470145000RCK	ASSY CABIN KIT W/FITMENT ULTRA T.11 BS6	TATA spare parts
55470753000RCK	CABIN KIT FOR ULTRA T.12 3.3L CAB BS6	TATA spare parts
55471545000RCK	ASSY CABIN KIT W/FITMENT ULTRA T.11 BS6	TATA spare parts
554724000101	BRACKET ASSY ENGINE MTG REAR BS6	TATA spare parts
554729100101	BUNDY TUBE ASSY BS6	TATA spare parts
554729300101	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
554729500101	BRACKET ASSY BOOSTER MTG BS6	TATA spare parts
554731000103	FRAME ASSY W/O TOP COAT BS6	TATA spare parts
554731000105	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
554731000106	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
554731000108	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
554731000110	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
554731107103	LONG MEMBER RH BS6	TATA spare parts
554731107104	LONG MEMBER LH BS6	TATA spare parts
554731107105	LONG MEMBER RH BS6	TATA spare parts
554731107106	LONG MEMBER LH BS6	TATA spare parts
554731107107	LONG MEMBER RH BS6	TATA spare parts
554731107108	LONG MEMBER LH BS6	TATA spare parts
554731107109	LONG MEMBER RH BS6	TATA spare parts
554731107110	LONG MEMBER LH BS6	TATA spare parts
554731408215	REINFORCEMENT RH BS6-PH2	TATA spare parts
554731408216	REINFORCEMENT LH BS6-PH2	TATA spare parts
554731408217	REINFORCEMENT BS6-PH2	TATA spare parts
554731408218	REINFORCEMENT RH BS6-PH2	TATA spare parts
554731408219	REINFORCEMENT BS6-PH2	TATA spare parts
554731408220	REINFORCEMENT BS6-PH2	TATA spare parts
554732100109	FRONT SPRING ASSY BS6-PH2	TATA spare parts
554732100110	1ST LEAF WITH BUSH BS6-PH2	TATA spare parts
554732100114	SHACKLE ASSY BS6-PH2	TATA spare parts
554732104201	U-CLAMP BS6-PH2	TATA spare parts
554732107112	2ND LEAF BS6-PH2	TATA spare parts
554732107115	3RD LEAF BS6-PH2	TATA spare parts
554732107126	SHACKLE BS6-PH2	TATA spare parts
554732400108	LEAF SPRING ASSY REAR BS6-PH2	TATA spare parts
554732400109	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts

554732400111	LEAF SPRG ASSY WITH AUX SPRG RR BS6-PH2	TATA spare parts
554732400112	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
554732403202	CENTER BOLT BS6-PH2	TATA spare parts
554732404201	SPRING CLIP BS6-PH2	TATA spare parts
554732404202	SPRING CLIP REAR BS6-PH2	TATA spare parts
554732407120	6TH LEAF BS6-PH2	TATA spare parts
554732407121	3RD LEAF BS6-PH2	TATA spare parts
554732407122	7TH LEAF BS6-PH2	TATA spare parts
554732407124	2ND LEAF BS6-PH2	TATA spare parts
554732407125	8TH LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407126	4TH LEAF BS6-PH2	TATA spare parts
554732407127	7TH LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407139	9TH LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407140	3RD LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407141	6TH LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407142	2ND LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407144	8TH LEAF BS6-PH2	TATA spare parts
554732407145	4TH LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407146	5TH LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407147	5TH LEAF BS6-PH2	TATA spare parts
554732407148	1ST LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407149	1ST LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407150	2ND LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407151	3RD LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407153	5TH LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407155	4TH LEAF AUX SPRING BS6-PH2	TATA spare parts
554732407156	2ND LEAF BS6-PH2	TATA spare parts
554732407157	3RD LEAF BS6-PH2	TATA spare parts
554732407160	4TH LEAF BS6-PH2	TATA spare parts
554732407161	5TH LEAF BS6-PH2	TATA spare parts
554732407162	6TH LEAF BS6-PH2	TATA spare parts
554732407164	7TH LEAF BS6-PH2	TATA spare parts
554732407165	8TH LEAF BS6-PH2	TATA spare parts
554732407167	SPACER PLATE REAR SUSPENSION BS6-PH2	TATA spare parts
554732504201	U-BOLT BS6-PH2	TATA spare parts
554733205101	STUB AXLE BS6-PH2	TATA spare parts
554733805101	STEERING ARM BS6-PH2	TATA spare parts
554733805102	TIE ROD ARM RH BS6-PH2	TATA spare parts
554733805103	TIEROD ARM LH BS6-PH2	TATA spare parts
554741100101	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
554741100102	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
554741110101	PROPELLER SHAFT ASSY FRONT BS6	TATA spare parts
554741110102	PROPELLER SHAFT ASSY MONOTRON BS6	TATA spare parts
554741110103	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
554741110104	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
554741110105	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
554741110106	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts

554741110108	PROPELLER SHAFT ASSY COUPLING BS6	TATA spare parts
554741120101	PROPELLER SHAFT ASSY REAR BS6	TATA spare parts
554741120102	PROPELLER SHAFT ASSY REAR BS6	TATA spare parts
554741120103	PROPELLER SHAFT ASSY DRIVE BS6	TATA spare parts
554741120108	PROPELLER SHAFT ASSY DRIVE BS6-PH2	TATA spare parts
554741300107	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
554743200104	AIR TANK ASSY WITH BKTS & STRAP	TATA spare parts
554743700115	RELAY VALVE BS6-PH2	TATA spare parts
554743700123	BRAKE CHAMBER BS6	TATA spare parts
554743700149	BRAKE CHAMBER	TATA spare parts
554743707101	BRACKET BS6-PH2	TATA spare parts
554743900101	TUBE ASSY WITH CRIMPED RUBBER HOSE BS6	TATA spare parts
554743900102	NYLON PIPE BUNCH ASSY CABIN BS6	TATA spare parts
554743900125	NYLON PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
554743900138	METAL PIPE ASSY ADAPTER TO DDU BS6	TATA spare parts
554743900140	NYLON PIPE BUNCH ASSY CHASSIS BS6	TATA spare parts
554743900141	NYLON PIPE BUNCH ASSY CABIN BS6	TATA spare parts
554743900196	METAL PIPE ASSY BS6-PH2	TATA spare parts
554743900197	METAL PIPE ASSY BS6-PH2	TATA spare parts
554743900239	METAL PIPE ASSY BS6-PH2	TATA spare parts
554743900240	METAL PIPE ASSY BS6-PH2	TATA spare parts
554743900242	METAL PIPE ASSY BS6-PH2	TATA spare parts
554743903301	L-BRACKET BS6-PH2	TATA spare parts
554743910201	METAL PIPE ASSY BS6-PH2	TATA spare parts
554743910202	METAL PIPE ASSY BS6-PH2	TATA spare parts
554743910203	METAL PIPE ASSY BS6-PH2	TATA spare parts
554743910204	METAL PIPE ASSY BS6-PH2	TATA spare parts
554746305102	PITMAN ARM	TATA spare parts
554746600102	STEERING GEAR BOX ASSY	TATA spare parts
554746600103	KIT-HOUSING ASSY	TATA spare parts
554746600104	WORM & VALVE HSG WITH RACK ASSY	TATA spare parts
554746600105	SECTOR SHAFT ASSY	TATA spare parts
554746600106	KIT-SEAL INPUT SHAFT	TATA spare parts
554746600114	POWER STEERING PUMP ASSY BS6-PH2	TATA spare parts
554746600115	POWER STEERING PUMP ASSY BS6-PH2	TATA spare parts
554746600116	POWER STEERING PUMP ASSY BS6-PH2	TATA spare parts
554746600117	POWER STEERING PUMP ASSY BS6-PH2	TATA spare parts
554746600120	FLOW LIMITING PISTON BS6-PH2	TATA spare parts
554746700103	BRACKET ASSY RESERVOIR MTG BS6-PH2	TATA spare parts
554746800101	SUCTION LINE ASSY WITH HOSE BS6	TATA spare parts
554746800102	RETURN LINE ASSY RESERVOIR TO JOINT BS6	TATA spare parts
554746800103	HIGH PRESSURE LINE ASSY BS6	TATA spare parts
554746800105	SUCTION LINE ASSY BS6	TATA spare parts
554746800107	HIGH PRESSURE LINE ASSY BS6	TATA spare parts
554746800109	RETURN LINE ASSY PUMP TO INT JOINT BS6	TATA spare parts
554746800112	RETURN LINE ASSY BS6	TATA spare parts
554746800121	SUCTION LINE ASSY BS6-PH2	TATA spare parts

554746800122	HIGH PRESSURE LINE ASSY BS6-PH2	TATA spare parts
554746800123	RETURN LINE ASSY BS6-PH2	TATA spare parts
554746807701	SEALING WASHER BS6	TATA spare parts
554747508204	COMPLIANCE PLATE BS6	TATA spare parts
554747600101	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
554747600102	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
554747600103	RETURN FUEL PIPE ASSY BS6	TATA spare parts
554747600104	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
554747600105	RETURN FUEL PIPE ASSY BS6	TATA spare parts
554747600107	RETURN FUEL PIPE ASSY BS6	TATA spare parts
554747600108	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554747600109	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
554747600112	RETURN FUEL PIPE ASSY BS6	TATA spare parts
554747600113	FUEL RETURN PIPE ASSY BS6	TATA spare parts
554747600114	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
554747600115	RETURN FUEL PIPE ASSY BS6	TATA spare parts
554747600122	VENT PIPE ASSY BS6	TATA spare parts
554747600123	HP PIPE ASSY BS6	TATA spare parts
554747600124	VENT PIPE ASSY BS6	TATA spare parts
554747600125	HP PIPE ASSY BS6	TATA spare parts
554747600126	VENT PIPE ASSY BS6	TATA spare parts
554747600127	HP PIPE ASSY BS6	TATA spare parts
554747600128	VENT PIPE ASSY BS6	TATA spare parts
554747600129	VENT PIPE ASSY BS6	TATA spare parts
554747600130	HP PIPE ASSY BS6	TATA spare parts
554747600131	HP PIPE ASSY BS6	TATA spare parts
554747600132	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554747600133	SUCTION FUEL PIPE ASSY BS6	TATA spare parts
554747600134	FUEL RETURN PIPE ASSY BS6	TATA spare parts
554747600149	VENT PIPE ASSY BS6	TATA spare parts
554747600152	VENT PIPE ASSY BS6	TATA spare parts
554747600153	VENT PIPE ASSY BS6	TATA spare parts
554747600155	VENT PIPE ASSY BS6	TATA spare parts
554747600157	VENT PIPE ASSY BS6	TATA spare parts
554747600160	VENT PIPE ASSY BS6	TATA spare parts
554747600164	VENT PIPE ASSY BS6	TATA spare parts
554747600166	VENT PIPE ASSY BS6	TATA spare parts
554747600167	VENT PIPE ASSY BS6	TATA spare parts
554747600173	VENT PIPE ASSY BS6	TATA spare parts
554747800101	BRACKET ASSY HP REGULATOR MTG BS6	TATA spare parts
554749100102	EXHAUST PIPE ASSY WITH BOSS	TATA spare parts
554749100104	PIPE ASSY DPS SENSOR INTAKE BS6	TATA spare parts
554749100107	PIPE ASSY DPS SENSOR REAR BS6	TATA spare parts
554749100109	CLAMP ASSY CATCON MTG BS6	TATA spare parts
554749100112	CLAMP ASSY CATCON MTG BS6-PH2	TATA spare parts
554749100113	CLAMP ASSY SILENCER MTG BS6-PH2	TATA spare parts
554749103301	BRACKET SILENCER MTG BS6-PH2	TATA spare parts



554749103302	BRACKET DPS SENSOR MTG BS6-PH2	TATA spare parts
554749104201	CLAMP CATCON MTG BS6	TATA spare parts
554749200102	EXH PIPE ASSY WITH FLEX BELLOW FRONT BS6	TATA spare parts
554749200107	UREA TANK ASSY BS6	TATA spare parts
554749200113	UREA PIPE ASSY BS6	TATA spare parts
554749200114	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
554749200115	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
554749200117	EXH PIPE ASSY WITH FLEX BELLOW FRONT BS6	TATA spare parts
554749200118	PIPE ASSY UREA SUPPLY BS6	TATA spare parts
554749200119	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
554749200120	BRACKET ASSY-TAIL PIPE MTG BS6	TATA spare parts
554749200123	SILENCER ASSY EXHAUST BS6	TATA spare parts
554749200133	PIPE ASSY UREA SUPPLY BS6-PH2	TATA spare parts
554749200138	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
554749200141	UREA TANK ASSY BS6-PH2	TATA spare parts
554749203301	BRACKET EGP MTG BS6	TATA spare parts
554749203304	BRACKET FRONT PIPE MTG BS6	TATA spare parts
554749203305	L-BRACKET-TAIL PIPE MTG SUPPORT BS6	TATA spare parts
554749203310	BRACKET FRONT PIPE MTG BS6-PH2	TATA spare parts
554749203312	BRACKET FRONT PIPE MTG BS6-PH2	TATA spare parts
554749203314	BRACKET PIPE SUPPORT BS6-PH2	TATA spare parts
554749203316	BRACKET FRONT PIPE MTG BS6-PH2	TATA spare parts
554749203317	BRACKET FRONT PIPE MTG	TATA spare parts
554749206910	EXHAUST TAIL PIPE BS6	TATA spare parts
554749600102	HEAT SHIELD ASSY POC DOC	TATA spare parts
554749990106	KIT-EXH PIPE HEAT SHIELD ASSY BS6-PH2	TATA spare parts
554754100101	BATTERY SUPPORT ASSY BS6-PH2	TATA spare parts
554754103301	BATTERY SUPPORT TOP BS6-PH2	TATA spare parts
554754600103	WIRING HARNESS INSTRUMENT PANEL BS6	TATA spare parts
554754600104	CCB ASSY BS6	TATA spare parts
554754600105	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
554754600106	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
554754600107	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
554754600108	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
554754600109	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
554754600110	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
554754600111	PIGTAIL ALTERNATOR +VE BS6	TATA spare parts
554754600115	WIRING HARNESS-ENGINE BS6	TATA spare parts
554754600118	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
554754600119	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts
554754600120	COVER ASSY FUSE BOX BS6-PH2	TATA spare parts
554754600132	WIRING HARNESS FRONT CHASSISBS6	TATA spare parts
554754600134	WIRING HARNESS LOAD BODY BS6	TATA spare parts
554754600163	WIRING HARNESS FLOOR BS6	TATA spare parts
554754600164	WIRING HARNESS REVERSE PARK ASSIST BS6	TATA spare parts
554754609907	STICKER MAXI FUSE BOX BS6	TATA spare parts
554754610102	WIRING HARNESS REAR CHASSIS BS6	TATA spare parts

554754610103	PIGTAIL ALTERNATOR +VE BS6	TATA spare parts
554754610104	WIRING HARNESS LOAD BODY BS6	TATA spare parts
554754610105	WIRING HARNESS FRONT CHASSIS BS6	TATA spare parts
554754610107	BATT. CABLE +VE BCS TO MEGA FUSE BS6-PH2	TATA spare parts
554754610112	WIRING HARNESS REVERSE PARK ASSIST BS6-P	TATA spare parts
554754620110	WIRING HARNESS INJECTOR BS6-PH2	TATA spare parts
554754630105	WIRING HARNESS FRONT CHASSIS BS6-PH2	TATA spare parts
554754630113	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
554754630119	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
554754630137	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
554754630145	WIRING HARNESS REAR CHASSIS BS6-PH2	TATA spare parts
554754630147	WIRING HARNESS FRONT CHASSIS BS6-PH2	TATA spare parts
554754640109	BATTERY CABLE -VE BS6-PH2	TATA spare parts
554754640110	PIGTAIL ALTERNATOR +VE BS6-PH2	TATA spare parts
554754707101	PLATE BS6	TATA spare parts
554754707102	PLATE BS6	TATA spare parts
554754708201	BRACKET BS6	TATA spare parts
554754728203	PLATE BS6-PH2	TATA spare parts
55476000114R40	ASSY PARTIAL FITTED CAB ULTRA T.BS6	TATA spare parts
55476010M10156	TOP RAIL ASSY FRONT BS6-PH2	TATA spare parts
55476260M10101	FIREWALL ASSY BS6-PH2	TATA spare parts
55476260M10115	FIREWALL ASSY WITH STUD BS6-PH2	TATA spare parts
55476320M10101	REINFORCEMENT ASSY STRIKER BS6-PH2	TATA spare parts
55476320M10108	REINFORCEMENT ASSY SIDE WALL LH BS6-PH2	TATA spare parts
55476320M10109	REINFORCEMENT ASSY SIDE WALL RH BS6-PH2	TATA spare parts
554770100101	MUDGUARD MTG ASSY BS6-PH2	TATA spare parts
554770106301	MUDFLAP SPRAY SUPPRESSION BS6-PH2	TATA spare parts
554770106302	MUDGUARD CENTER BS6-PH2	TATA spare parts
554770106303	MUDGUARD REAR-LH BS6-PH2	TATA spare parts
554770106304	MUDGUARD REAR-RH BS6-PH2	TATA spare parts
554770160101	BRACKET ASSY SUPD MTG FRONT BS6-PH2	TATA spare parts
55477220M10101	FRONT DOOR INNER ASSY LH	TATA spare parts
55477220M10134	FRONT DOOR SHELL ASSY LH BS6-PH2	TATA spare parts
55477220M10135	FRONT DOOR SHELL ASSY RH BS6-PH2	TATA spare parts
5547H9X0233003	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
554915100102	STARTER MOTOR ASSY BS6	TATA spare parts
554915100103	SOLENOID ASSY BS6	TATA spare parts
554915100104	FIXING BRACKET ASSY BS6	TATA spare parts
554915100105	DRIVE ASSY BS6	TATA spare parts
554915100106	PLANETARY GEAR ASSY BS6	TATA spare parts
554915100107	OUTPUT SHAFT ASSY BS6	TATA spare parts
554915100108	CE BRACKET ASSY BS6	TATA spare parts
554915100109	KIT-FASTENERS BS6	TATA spare parts
554915100110	KIT-SEALING BS6	TATA spare parts
554915100111	KIT-BEARING BS6	TATA spare parts
554915100112	NEEDLE BEARING BS6	TATA spare parts
554915100113	KIT-BEARING BUSH BS6	TATA spare parts

554915100114	KIT-PINION BS6	TATA spare parts
554915100116	CE BRACKET ASSY BS6	TATA spare parts
554915100117	SOLENOID ASSY BS6	TATA spare parts
554924203801	BRACKET C-MOUNT BS6	TATA spare parts
554929100112	BUNDY TUBE ASSY LONG MEMBER BS6	TATA spare parts
554929100114	SUPPORT BRACKET ASSY CONTROL MTG BS6	TATA spare parts
554929100115	CLUTCH PEDAL ASSY BS6	TATA spare parts
554929100116	CLUTCH PEDAL ASSY WITH BUSH BS6	TATA spare parts
554929100117	CLUTCH MASTER CYLINDER WITH HOSE BS6	TATA spare parts
554929108704	ASSISTANCE SPRING CLUTCH PEDAL BS6	TATA spare parts
554929200106	BRAKE PEDAL ASSY BS6	TATA spare parts
554929200107	BRAKE PEDAL ASSY WITH BUSH BS6	TATA spare parts
554929500123	BRACKET ASSY CONTROL MTG BS6	TATA spare parts
554929500125	BRACKET ASSY BOOSTER MTG BS6	TATA spare parts
554929500126	BRACKET ASSY CLUTCH PEDAL MTG BS6	TATA spare parts
554929500134	BRKT ASSY CLUTCH & BR PEDAL MTG BS6-PH2	TATA spare parts
554929508001	PIVOT PIN CLUTCH PEDAL MTG BS6	TATA spare parts
554931000110	FRAME ASSY WITH TOP COAT BS6	TATA spare parts
554931000112	FRAME ASSY BS6-PH2	TATA spare parts
554931000113	FRAME ASSY WITH TOP COAT BS6-PH2	TATA spare parts
554931100104	REINFORCEMENT ASSY LONG MEMBER BELLY LH	TATA spare parts
554931100105	REINFORCEMENT ASSY LONG MEMBER BELLY RH	TATA spare parts
554931203309	REINFORCEMENT SUPPORT BRACKET LH BS6	TATA spare parts
554931203310	REINFORCEMENT SUPPORT BRACKET RH BS6	TATA spare parts
554931320101	BRACKET ASSY SHOCK ABSORBER MTG LH BS6	TATA spare parts
554931320102	BRACKET ASSY SHOCK ABSORBER MTG RH BS6	TATA spare parts
554931320107	BRACKET ASSY BUMP STOPPER FRONT-LH BS6	TATA spare parts
554931320108	BRACKET ASSY BUMP STOPPER FRONT-RH BS6	TATA spare parts
554931320110	SUPPORT BRACKET ASSY BS6	TATA spare parts
554931320111	BRACKET ASSY SUPPORT LH BS6	TATA spare parts
554931320112	BRACKET ASSY SUPPORT RH BS6	TATA spare parts
554931323306	SUPPORT BRACKET SPRING HANGER BKT LH BS6	TATA spare parts
554931323307	SUPPORT BRACKET SPRING HANGER BKT RH BS6	TATA spare parts
554931540103	BATTERY TRAY ASSY BS6	TATA spare parts
554932100104	GUIDE PLATE ASSY BS6	TATA spare parts
554932100130	CLAMP ASSY BS6	TATA spare parts
554932100131	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
554932100132	LEAF SPRING ASSY FRONT BS6	TATA spare parts
554932107108	CENTER PAD BS6	TATA spare parts
554932107110	SPACER BS6	TATA spare parts
554932107111	2ND LEAF BS6	TATA spare parts
554932107703	TIP INSERT BS6	TATA spare parts
554932300102	SHOCK ABSORBER ASSY FRONT BS6	TATA spare parts
554932400103	BUMP STOPPER ASSY REAR BS6	TATA spare parts
554932400122	LEAF SPRING ASSY REAR BS6	TATA spare parts
554932400123	1ST LEAF ASSY WITH BUSH BS6	TATA spare parts
554932400124	CLAMP ASSY BS6	TATA spare parts

554932400126	CLAMP ASSY BS6	TATA spare parts
554932403201	CENTER BOLT	TATA spare parts
554932403202	CENTER BOLT BS6	TATA spare parts
554932404201	U-CLAMP REAR BS6	TATA spare parts
554932407132	2ND LEAF BS6	TATA spare parts
554932407133	3RD LEAF BS6	TATA spare parts
554932407134	4TH LEAF BS6	TATA spare parts
554932407135	5TH LEAF BS6	TATA spare parts
554932407136	6TH LEAF BS6	TATA spare parts
554932407137	7TH LEAF BS6	TATA spare parts
554932407138	8TH LEAF BS6	TATA spare parts
554932407139	9TH LEAF BS6	TATA spare parts
554932407140	10TH LEAF BS6	TATA spare parts
554932407141	PLATE SHACKLE BS6	TATA spare parts
554932800104	BEARING BLOCK ANTI ROLL BAR BS6	TATA spare parts
554932800105	ANTI ROLL BAR ASSY FRONT BS6	TATA spare parts
554932800106	LINK ASSY ANTI ROLL BAR BS6	TATA spare parts
554932807701	BUSH ANTI ROLL BAR BS6	TATA spare parts
554932807703	BUSH ANTI ROLL BAR MTG UPPER BS6	TATA spare parts
554932808205	CLAMP ANTI ROLL BAR BS6	TATA spare parts
554933000106	FRONT AXLE ASSY BS6	TATA spare parts
554933100101	FRONT AXLE TUBE ASSY BS6	TATA spare parts
554933109901	COTTER BOLT BS6	TATA spare parts
554933200105	CAP ASSY KING PIN BS6	TATA spare parts
554933200106	CAP ASSY KING PIN BS6	TATA spare parts
554933200107	STUB AXLE ASSY RH BS6	TATA spare parts
554933200109	STUB AXLE ASSY LH BS6	TATA spare parts
554933203401	BUSH KING PIN BS6	TATA spare parts
554933206701	KING PIN BS6	TATA spare parts
554933208601	SHIM - 1.0 THK BS6	TATA spare parts
554933208602	SHIM - 1.05 THK BS6	TATA spare parts
554933208603	SHIM - 1.1 THK BS6	TATA spare parts
554933208604	SHIM - 1.15 THK BS6	TATA spare parts
554933208606	SHIM - 1.2 THK BS6	TATA spare parts
554933208607	SHIM - 1.25 THK BS6	TATA spare parts
554933208608	SHIM - 1.3 THK BS6	TATA spare parts
554933208609	SHIM - 1.35 THK BS6	TATA spare parts
554933208610	SHIM - 1.4 THK BS6	TATA spare parts
554933208611	SHIM - 1.45 THK BS6	TATA spare parts
554933208612	SHIM - 1.5 THK BS6	TATA spare parts
554933208613	SHIM - 1.55 THK BS6	TATA spare parts
554933208614	SHIM - 1.6 THK BS6	TATA spare parts
554933208615	SHIM - 1.65 THK BS6	TATA spare parts
554933208618	SHIM - 1.7 THK BS6	TATA spare parts
554933209901	CAP KING PIN BS6	TATA spare parts
554933403101	THRUST BEARING BS6	TATA spare parts
554933403701	FRONT HUB BS6	TATA spare parts

554933408202	CAP FRONT HUB BS6	TATA spare parts
554933800101	TIE ROD ASSY BS6	TATA spare parts
554933805103	STEERING ARM BS6	TATA spare parts
554933806501	LOCK NUT RH BS6	TATA spare parts
554936	SM BACK RINGS	TATA spare parts
554940100105	WHEEL RIM ASSY BS6	TATA spare parts
554940100111	WHEEL RIM ASSY BS6	TATA spare parts
554940109902	TUBELESS TYRE	TATA spare parts
554940300106	TUBE ASSY SPARE WHEEL CARRIER BS6	TATA spare parts
554941100108	TORSIONAL VIBRATION DAMPER ASSY BS6	TATA spare parts
554941100110	PROPELLER SHAFT ASSY BS6	TATA spare parts
554941100111	LONG FORK ASSY BS6	TATA spare parts
554942100102	CALIPER ASSY FRONT-LH BS6	TATA spare parts
554942100103	CALIPER ASSY FRONT-RH BS6	TATA spare parts
554942100106	CALIPER ASSY FRONT-LH BS6	TATA spare parts
554942100107	CALIPER ASSY FRONT-RH BS6	TATA spare parts
554942100112	KIT PAD ASSY BS6	TATA spare parts
554942103701	BRAKE DISC VENTILATED FRONT BS6	TATA spare parts
554942300102	DRUM BRAKE ASSY REAR-LH(AF 4179M) BS6	TATA spare parts
554942300103	DRUM BRAKE ASSY REAR-RH (AF 4179M) BS6	TATA spare parts
554942300111	KIT SPRING BS6	TATA spare parts
554942300115	KIT LEVER PAWL LH BS6	TATA spare parts
554942300119	KIT LEVER PAWL RH BS6	TATA spare parts
554942300120	KIT BLEED SCREW BS6	TATA spare parts
554942300121	KIT LINED SHOE (AF 4179M) BS6	TATA spare parts
554942300124	WHEEL CYLINDER ASSEMBLY BS6	TATA spare parts
554942303701	BRAKE DRUM BS6	TATA spare parts
554942308703	SPRING SHOE RETURN-WHEEL CYL END BS6	TATA spare parts
554942700108	PARKING BRAKE CABLE ASSY REAR-RH BS6	TATA spare parts
554942700109	PARKING BRAKE CABLE ASSY REAR-LH BS6	TATA spare parts
554942700110	PARKING BRAKE CABLE ASSY FRONT BS6	TATA spare parts
554943500108	VACUUM PIPE ASSY BS6	TATA spare parts
554943500110	VACUUM BOOSTER ASSY BS6	TATA spare parts
554943500112	BOOSTER ASSY BS6	TATA spare parts
554943500113	TMC ASSY WITH RESERVIOR BS6-PH2	TATA spare parts
554943500114	TMC ASSY BS6	TATA spare parts
554943500115	RESERVOIR ASSY BRAKE FLUID BS6	TATA spare parts
554943505803	HOSE BOOSTER END BS6	TATA spare parts
554943505806	VACUUM HOSE BOOSTER END BS6	TATA spare parts
554943507501	RUBBER GROMMET BS6	TATA spare parts
554943800101	TUBE ASSY T-CONN TO BRAKE HOSE FRT-RH BS	TATA spare parts
554943800109	TUBE ASSY TMC PRIMARY TO T-CONN BS6	TATA spare parts
554943800111	TUBE ASSY T-CONN TO BRAKE HOSE FRT-LH BS	TATA spare parts
554943800113	TUBE ASSY TMC SECONDARY TO T-CONN BS6	TATA spare parts
554943800118	TUBE ASSY REAR HOSE TO BRAKE ASSY LH BS6	TATA spare parts
554943800119	TUBE ASSY REAR HOSE TO BRAKE ASSY RH BS6	TATA spare parts
554943800120	TUBE ASSY TMC PRIMARY TO T-CONN BS6	TATA spare parts

554943800121	TUBE ASSY TMC SECONDARY TO T-CONN BS6	TATA spare parts
554943800127	TUBE ASSY T-CONN TO LCRV BS6	TATA spare parts
554943800128	TUBE ASSY T-CONN TO LCRV BS6	TATA spare parts
554943800129	TUBE ASSY T-CONN TO LCRV BS6-PH2	TATA spare parts
554943800130	TUBE ASSY T-CONN TO LCRV BS6-PH2	TATA spare parts
554943803303	BRACKET LCRV MTG AXLE BS6	TATA spare parts
554943804201	CLAMP BS6	TATA spare parts
554943805804	HOSE RESERVOIR TO TMC PRIMARY BS6	TATA spare parts
554943805805	HOSE RESERVOIR TO TMC SECONDARY BS6	TATA spare parts
554946100106	STEERING COLUMN ASSY WITH I-SHAFT BS6	TATA spare parts
554946100107	INTERMEDIATE SHAFT ASSY STG COLUMN BS6	TATA spare parts
554946100109	STEERING COLUMN ASSY UPPER BS6	TATA spare parts
554946107703	RUBBER BELLOW STG COLUMN BS6	TATA spare parts
554946200101	COVER PLATE ASSY BS6	TATA spare parts
554946600117	STEERING GEAR BOX ASSY WITH PITMAN ARM B	TATA spare parts
554946600119	WORM & VALVE HSG WITH RACK ASSY BS6	TATA spare parts
554946600120	WORM & VALVE HSG ASSY BS6	TATA spare parts
554946600121	HOUSING ASSY BS6	TATA spare parts
554946600123	SECTOR SHAFT ASSY BS6	TATA spare parts
554946603201	BOLT BS6	TATA spare parts
554946605103	DROP ARM BS6	TATA spare parts
554946609202	WASHER BS6	TATA spare parts
554946800101	HIGH PRESSURE LINE ASSY PUMP TO STG GB B	TATA spare parts
554946800102	RETURN LINE ASSY GEAR BOX TO RESERVOIR B	TATA spare parts
554946805801	SUCTION HOSE BS6	TATA spare parts
554946900102	DRAG LINK ASSY BS6	TATA spare parts
554946900103	DRAG LINK ASSY BS6	TATA spare parts
554946990101	BALL JOINT ASSY RH BS6	TATA spare parts
554947600102	FUEL SUCTION PIPE ASSY BS6-PH2	TATA spare parts
554947600103	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554947600104	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554947600106	FUEL RETURN PIPE ASSY BS6	TATA spare parts
554947600107	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
554947600108	FUEL RETURN PIPE ASSY BS6	TATA spare parts
554947600109	FUEL RETURN PIPE ASSY BS6-PH2	TATA spare parts
554947600110	BRACKET ASSY FILTER MTG BS6-PH2	TATA spare parts
554947600117	FUEL SUCTION PIPE ASSY BS6	TATA spare parts
554947600118	FUEL RETURN PIPE ASSY BS6	TATA spare parts
554947600119	FUEL RETURN PIPE ASSY BS6	TATA spare parts
554949200109	BRACKET ASSY UREA TANK MTG BS6-PH2	TATA spare parts
554949200114	BRACKET ASSY UREA TANK MTG BS6-PH2	TATA spare parts
554949200116	BRACKET ASSY UREA TANK MTG BS6-PH2	TATA spare parts
554949200117	UREA PIPE ASSY BS6-PH2	TATA spare parts
554949200119	BRACKET ASSY WITH HOOK BS6	TATA spare parts
554949203325	BRACKET BS6-PH2	TATA spare parts
554949205801	HOSE BS6-PH2	TATA spare parts
554949205802	HOSE BS6-PH2	TATA spare parts

554954600103	STICKER & COVER ASSY FUSE BOX BS6	TATA spare parts
554954600109	STICKER - COVER ASSY FUSE BOX BS6	TATA spare parts
554954600110	WIRING HARNESS BATTERY CABLE +VE BS6	TATA spare parts
554954600112	WIRING HARNESS EMS BS6	TATA spare parts
554954600114	WIRING HARNESS BATTERY CABLE +VE BS6-PH2	TATA spare parts
554954600121	STICKER & COVER ASSY FUSE BOX BS6-PH2	TATA spare parts
554954600125	WIRING HARNESS EMS BS6-PH2	TATA spare parts
554954600126	WIRING HARNESS CHASSIS BS6	TATA spare parts
554954600127	WIRING HARNESS CABIN BS6	TATA spare parts
554954600128	STICKER & COVER ASSY FUSE BOX BS6-PH2	TATA spare parts
554954600129	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
554954600130	WIRING HARNESS CHASSIS BS6	TATA spare parts
554954600133	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
554954600134	WIRING HARNESS CABIN BS6	TATA spare parts
554954600140	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
554954600142	WIRING HARNESS CHASSIS BS6-PH2	TATA spare parts
554954600160	WIRING HARNESS EMS BS6-PH2	TATA spare parts
554954600171	WIRING HARNESS BATTERY CABLE +VE BS6-PH2	TATA spare parts
554954603308	BRACKET WIRING HARNESS MTG BS6	TATA spare parts
554954603309	BRACKET WIRING HARNESS BRANCH MTG BS6	TATA spare parts
554954606303	FUSE BOX COVER BS6	TATA spare parts
554955106301	MASCOT BS6	TATA spare parts
554955151601	DECAL FRONT DOOR LH BS6-PH2	TATA spare parts
554955151602	DECAL FRONT DOOR RH BS6-PH2	TATA spare parts
554955151603	DECAL SIDE OUTER LH BS6-PH2	TATA spare parts
554955151604	DECAL SIDE OUTER RH BS6-PH2	TATA spare parts
554958304003	SCISSOR JACK ASSY BS6	TATA spare parts
554958902601	LOCKING TOOL FLYWHEEL BS6	TATA spare parts
554958902603	LOCKING PIN FLYWHEEL BS6	TATA spare parts
554958903501	UNIVERSAL MANDREL (FOR ALL DOLLY) BS6	TATA spare parts
554958903502	DUMMY DIFFERENTIAL CASE BEARING BS6	TATA spare parts
554958903503	DOLLY PRESSING PINION INNER CUP BS6	TATA spare parts
554958903504	DOLLY PRESSING PINION OUTER CUP BS6	TATA spare parts
554958903505	DOLLY PRESSING PINION INNER CONE BS6	TATA spare parts
554958903506	DOLLY PRESSING DIFF CASE BEARING BS6	TATA spare parts
554958903507	PULLER REMOVAL DIFF CASE BEARING BS6	TATA spare parts
554958903508	PULLER REMOVAL PINION INNER BEARING BS6	TATA spare parts
554958903509	ADAPT REMOVAL PINION INNER & OUT.CUP BS6	TATA spare parts
554958903510	DOLLY PRESSING PINION OIL SEAL BS6	TATA spare parts
554958903511	PULLER PINION O.SEAL & AX. SHAFT CUP BS6	TATA spare parts
554958903512	TUBE OIL SEAL PRESSING DOLLY BS6	TATA spare parts
554958903513	AXLE SHAFT HUB OIL SEAL PRESS.DOLLY BS6	TATA spare parts
554958903514	CARRIER AND PINION ASSEMBLY FIXTURE BS6	TATA spare parts
554958903515	AXLE SHAFT PULLER BS6	TATA spare parts
554958903516	DIFF CASE GEAR LOCK PIN REMOVAL TOOL BS6	TATA spare parts
554958903517	SPANNER HOLD.TOP PLATE/DR.SCR.ROD_27 BS6	TATA spare parts
554960000109JS	TITANIUM_WH-BODY SHELL ASSY PAINTED BS6	TATA spare parts

554960000109JV	STONEHENGE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
554960600101	CROSS MEMBER ASSY BS6	TATA spare parts
554962000107	FRONT WALL ASSY BS6	TATA spare parts
554963700107	SIDE WALL ASSY OUTER-FRONT-RH BS6	TATA spare parts
554964000101	REAR WALL ASSY BS6	TATA spare parts
554968706301	INSULATION LOAD BODY COVER BS6	TATA spare parts
554968706302	HEAT SHIELD	TATA spare parts
554969106302	COVER HEADLAMP RH BS6	TATA spare parts
554970000117JS	TITANIUM_WH-LOAD BODY ASSY BS6	TATA spare parts
554970000117JV	STONEHENGE-LOAD BODY ASSY BS6	TATA spare parts
554970100110	BRACKET ASSY TAIL LAMP MTG RH BS6	TATA spare parts
554970100113	BRACKET ASSY TAIL LAMP MTG LH BS6	TATA spare parts
554970300103	SIDE PANEL ASSY LH BS6	TATA spare parts
554970300104	SIDE PANEL ASSY RH BS6	TATA spare parts
554970400102	TAILGATE ASSY BS6	TATA spare parts
554970906301	BALATA PACKING BS6	TATA spare parts
554970906303	MUDGUARD REAR BS6	TATA spare parts
554970906305	BALATA PACKING BS6	TATA spare parts
554983600103	DISCHARGE PIPE CONDENSER END BS6-PH2	TATA spare parts
554983600104	DISCHARGE PIPE ASSY REAR BS6-PH2	TATA spare parts
554983600105	SUCTION PIPE COMPRESSOR END BS6-PH2	TATA spare parts
554983600108	SUCTION PIPE COMPRESSOR END BS6-PH2	TATA spare parts
554983600110	DISCHARGE PIPE COMPRESSOR END BS6-PH2	TATA spare parts
554983750101	BRACKET ASSY BS6-PH2	TATA spare parts
554983750102	CLAMP ASSY PIPING BS6-PH2	TATA spare parts
554988100101	SPLASH GUARD ASSY WHEEL ARCH FRONT-LH BS	TATA spare parts
554988100102	SPLASH GUARD ASSY WHEEL ARCH FRONT-RH BS	TATA spare parts
554988146303	BRACKET SPLASH GUARD MTG LH BS6	TATA spare parts
554988146304	BRACKET SPLASH GUARD MTG RH BS6	TATA spare parts
554988200101	REINF ASSY FRONT WHEEL ARCH COVER LH BS6	TATA spare parts
554988200102	REINF ASSY FRONT WHEEL ARCH COVER RH BS6	TATA spare parts
554988200103	COVER ASSY FRONT WHEEL ARCH LH BS6	TATA spare parts
554988200104	COVER ASSY FRONT WHEEL ARCH RH BS6	TATA spare parts
554988206301	COVER FRONT WHEEL ARCH LH BS6	TATA spare parts
554988206302	COVER FRONT WHEEL ARCH RH BS6	TATA spare parts
554988460101	BUMPER ASSY LOWER MTG RH BS6-PH2	TATA spare parts
554988460105	BUMPER ASSY LOWER MTG LH BS6-PH2	TATA spare parts
554988500101	BUMPER LOWER ASSY BS6	TATA spare parts
5549A9Z0170001JS	TITANIUM WHITE - LOADBODY FITTED ASSY MF	TATA spare parts
5549D1D0470001	TAILGATE ASSY BS6-PH2	TATA spare parts
5549D9Y0160002JV	STONEHENGE BODY SHELL ASSY PAINTED BS6-P	TATA spare parts
5549H9X0233001	FRONT AXLE ASSY WITH BRAKES-MFG BS6-PH2	TATA spare parts
555015400101	ALTERNATOR 12V 150A LIN BS6-PH2	TATA spare parts
555016102001	ECU HARDWARE BS6-PH2	TATA spare parts
555046100104	STEERING COLUMN ASSY BS6	TATA spare parts
555046800101	L-BRACKETASSYBS6	TATA spare parts
555047500104	HEAT SHIELD ASSY LH	TATA spare parts



555047507703	GROMMET FUEL FILLER NECK BS6-PH2	TATA spare parts
555054200102	TELL-TALE INDICATOR BS6	TATA spare parts
555054300101	HORN MTG BRACKET BS6	TATA spare parts
555054300102	BRACKET ASSY HORN MTG	TATA spare parts
555054400102	HEADLAMP ASSY WITH LAMP BS6	TATA spare parts
555054400103	ROOF LAMP BS6	TATA spare parts
555054400104	TAIL LAMP ASSY LH BS6	TATA spare parts
555054400105	TAIL LAMP ASSY RH BS6	TATA spare parts
555054400106	SIDE INDICATOR LAMP ASSY LH BS6	TATA spare parts
555054400107	SIDE INDICATOR LAMP ASSY RH BS6	TATA spare parts
555054400108	SIDE REPEATER LAMP ASSY.LH BS6	TATA spare parts
555054400109	SIDE REPEATER LAMP ASSY.RH BS6	TATA spare parts
555054400112	TURN INDICATOR LAMP WITH DRL LH BS6	TATA spare parts
555054400113	TURN INDICATOR LAMP WITH DRL RH BS6	TATA spare parts
555054403301	BRACKET FRONT REFLEX REFLECTOR MTG LH BS	TATA spare parts
555054403302	BRACKET FRONT REFLEX REFLECTOR MTG RH BS	TATA spare parts
555054500103	SWITCH ASSY 3 PACK BS6	TATA spare parts
555054500104	SWITCH ASSY 2 PACK BS6	TATA spare parts
555054500106	SWITCH ASSY 3 PACK BS6	TATA spare parts
555054500108	SWITCH ASSY 4 PACK BS6	TATA spare parts
555054500109	BATTERY CUTOFF SWITCH BS6	TATA spare parts
555054500110	SWITCH ASSY 2 PACK BS6	TATA spare parts
555054500111	SWITCH ASSY 4 PACK BS6	TATA spare parts
555054500112	SWITCH ASSY 2 PACK BS6	TATA spare parts
555054500113	SWITCH ASSY 2 PACKBS6	TATA spare parts
555054500116	SWITCH ASSY 3 PACK BS6	TATA spare parts
555054504902	ECO SWITCH BS6	TATA spare parts
555054504903	SWITCH FRONT FOG LAMP BS6	TATA spare parts
555054504909	SWITCH REAR A/C BS6	TATA spare parts
555054504910	SWITCH REGENERATION START MANUAL BS6	TATA spare parts
555054504913	BATTERY CUT OFF SWITCH BS6	TATA spare parts
555054504914	SWITCH DISABLE PERSON BS6	TATA spare parts
555054504916	HAZARD WARNING SWITCH BS6	TATA spare parts
555054504918	SWITCH REAR FOG LAMP BS6	TATA spare parts
555054504919	SWITCH ROOF LAMP BS6	TATA spare parts
555054504921	ELECTRICAL BATTERY CUT OFF SWITCH BS6	TATA spare parts
555054509901	SWITCH CARRIER PLATE BS6	TATA spare parts
555054509902	SWITCH CARRIER PLATE BS6	TATA spare parts
555054509903	SWITCH CARRIER PLATE BS6	TATA spare parts
555054509904	SWITCH CARRIER PLATE BS6	TATA spare parts
555054600112	WIRING HARNESS CABIN BS6	TATA spare parts
555054600113	WIRING HARNESS FRONT BS6	TATA spare parts
555054600114	WIRING HARNESS TAIL BS6	TATA spare parts
555054600115	WIRING HARNESS CABIN SPACE FLOOR BS6	TATA spare parts
555054600116	WIRING HARNESS TAILGATE RH BS6	TATA spare parts
555054600117	WIRING HARNESS REAR DOOR RH BS6	TATA spare parts
555054600118	WIRING HARNESS REAR BUMPER BS6	TATA spare parts

555054600120	WIRING HARNESS TAILGATE LH BS6	TATA spare parts
555054600121	WIRING HARNESS ROOF A/C BS6	TATA spare parts
555054600122	PIGTAIL ROOF AC BS6	TATA spare parts
555054600123	WIRING HARNESS REAR DOOR LH BS6	TATA spare parts
555054600124	WIRING HARNESS EMS BS6	TATA spare parts
555054600125	WIRING HARNESS EMS PIGTAIL BS6	TATA spare parts
555054600126	WIRING HARNESS ROOF LH BS6	TATA spare parts
555054600127	WIRING HARNESS ABS ECU BS6	TATA spare parts
555054600128	WIRING HARNESS CABIN BS6	TATA spare parts
555054600129	WIRING HARNESS FRONT BS6	TATA spare parts
555054600130	WIRING HARNESS FRONT BS6	TATA spare parts
555054600131	WIRING HARNESS ROOF LH BS6	TATA spare parts
555054600132	WIRING HARNESS TAIL BS6	TATA spare parts
555054600133	WIRING HARNESS FRONT BS6	TATA spare parts
555054600134	WIRING HARNESS CABIN BS6	TATA spare parts
555054600135	WIRING HARNESS FRONT BS6	TATA spare parts
555054600136	WIRING HARNESS CABIN BS6	TATA spare parts
555054600137	WIRING HARNESS FRONT BS6	TATA spare parts
555054600138	WIRING HARNESS ROOF LH BS6	TATA spare parts
555054600142	WIRING HARNESS CABIN BS6	TATA spare parts
555054600143	WIRING HARNESS FRONT BS6	TATA spare parts
555054600144	WIRING HARNESS TAIL BS6	TATA spare parts
555054600145	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
555054600147	WIRING HARNESS CABIN BS6	TATA spare parts
555054600148	WIRING HARNESS ROOF LH BS6	TATA spare parts
555054600149	WIRING HARNESS CABIN BS6	TATA spare parts
555054600151	WIRING HARNESS REAR BUMPER BS6	TATA spare parts
555054600152	WIRING HARNESS ROOF A/C BS6	TATA spare parts
555054600154	WIRING HARNESS ROOF LH BS6	TATA spare parts
555054600156	BATTERY +VE CABLE ASSY WITH ENG W/H BS6-	TATA spare parts
555054600158	BRACKET ASSY CABIN FRONT CONN MTG BS6	TATA spare parts
555054600159	WIRING HARNESS ROOF A/C BS6	TATA spare parts
555054600161	PIGTAIL VEHICLE TRACKING SYSTEM BS6	TATA spare parts
555054600166	WIRING HARNESS CABIN BS6	TATA spare parts
555054600170	BRACKET ASSY CABIN FRONT CONN MTG BS6-PH	TATA spare parts
555054600171	WIRING HARNESS ROOF LH BS6	TATA spare parts
555054600180	WIRING HARNESS REAR DOOR LH BS6	TATA spare parts
555054600181	WIRING HARNESS REAR DOOR RH BS6	TATA spare parts
555054600189	WIRING HARNESS CABIN BS6	TATA spare parts
555054600191	PLATE U-BOLT MTG BS6-PH2	TATA spare parts
555054600194	WIRING HARNESS CABIN BS6	TATA spare parts
555054600199	WIRING HARNESS FRONT BS6-PH2	TATA spare parts
555054603301	BRACKET IN LINE CONNECTOR MTG BS6	TATA spare parts
555054603307	BRACKET CABIN WIRING HARNESS MTG BS6-PH2	TATA spare parts
555054606302	COVER WITH PRINT DETAILS BS6	TATA spare parts
555054609901	STICKER & COVER ASSY BS6	TATA spare parts
555054609902	STICKER & COVER ASSY BS6	TATA spare parts

555054610103	WIRING HARNESS HOOTER BS6	TATA spare parts
555054610104	WIRING HARNESS EMS BS6-PH2	TATA spare parts
555054610109	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
555054610114	WIRING HARNESS FRONT BS6-PH2	TATA spare parts
555054610124	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
555054610125	WIRING HARNESS ROOF LH BS6-PH2	TATA spare parts
555054610126	WIRING HARNESS FRONT BS6-PH2	TATA spare parts
555054610130	WIRING HARNESS ABS ECU BS6-PH2	TATA spare parts
555054610149	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
555054610150	WIRING HARNESS ROOF A/C BS6-PH2	TATA spare parts
555054610151	WIRING HARNESS ROOF LH BS6-PH2	TATA spare parts
555054610157	WIRING HARNESS ROOF LH BS6-PH2	TATA spare parts
555054610158	WIRING HARNESS ROOF LH BS6-PH2	TATA spare parts
555054610159	WIRING HARNESS ROOF LH BS6-PH2	TATA spare parts
555054610160	WIRING HARNESS ROOF LH BS6-PH2	TATA spare parts
555054610161	PIGTAIL UREA LEVEL SENSOR BS6-PH2	TATA spare parts
555054610163	BRACKET ASSY FUSE BOX MTG BS6-PH2	TATA spare parts
555054610164	BRACKET ASSY RELAY BOX MTG BS6-PH2	TATA spare parts
555054610167	WIRING HARNESS USB CABLE	TATA spare parts
555054610168	WIRING HARNESS ROOF A/C BS6-PH2	TATA spare parts
555054610170	BRACKET ASSY WIRING HARNESS MTG BS6-PH2	TATA spare parts
555054610174	WIRING HARNESS FRONT BS6-PH2	TATA spare parts
555054610175	WIRING HARNESS FRONT	TATA spare parts
555054610176	WIRING HARNESS FRONT BS6-PH2	TATA spare parts
555054640102	BATTERY CABLE -VE BS6-PH2	TATA spare parts
555054640104	BATT CABLE +VE BATT TO ELE BCS BS6-PH2	TATA spare parts
555054640115	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
555054640116	WIRING HARNESS CABIN	TATA spare parts
555054640117	WIRING HARNESS CABIN BS6-PH2	TATA spare parts
555054640118	WIRING HARNESS CABIN	TATA spare parts
555054700102	BRACKET ASSY GDCU UNIT MOUNTING BS6-PH2	TATA spare parts
555054800101	KIT-FIRE DETECTION SUPPRESSION SYSTEM BS	TATA spare parts
555058300105	FIRE DETECTION & SUPPRESSION SYS BS6-PH2	TATA spare parts
555058300108	FIRE DETECTION & SUPPRESSION SYSTEM BS6-	TATA spare parts
555058604001	CROSSLINK FOAM BS6	TATA spare parts
55506010M10119	ASSY CROSS MBR LOWER COMPLETE BS6-PH2	TATA spare parts
55506010M10180	TIE MEMBER ASSY UPPER BS6-PH2	TATA spare parts
55506100M10148	SUBSTRUCTURE ASSY WITH FLOOR REAR BS6-PH	TATA spare parts
55506100M10156	SUBSTRUCTURE ASSY WITH FLOOR REAR BS6-PH	TATA spare parts
55506100M10160	SUBSTRUCTURE ASSY FRONT BS6-PH2	TATA spare parts
55506100M10190	SUBSTRUCTURE ASSY WITH FLOOR REAR BS6-PH	TATA spare parts
55506120M10115	ASSY SILL INNER SIDE LH BS6-PH2	TATA spare parts
55506120M10116	ASSY SILL INNER SIDE RH BS6-PH2	TATA spare parts
55506120M10144	ASSY SILL INNER SIDE LH BS6-PH2	TATA spare parts
55506120M10145	ASSY SILL INNER SIDE RH BS6-PH2	TATA spare parts
55506131M10199	ASSY EMS BRACKET BS6-PH2	TATA spare parts
55506132M10112	CLOSING PLATE ASSY LONG MEMBER BS6-PH2	TATA spare parts

55506160M10102	FRONT FLOOR BS6-PH2	TATA spare parts
55506200M10102	FIREWALL ASSY BS6-PH2	TATA spare parts
55506200M10110	WINDSHIELD PILLAR ASSY BS6-PH2	TATA spare parts
55506220M10145	BRACKET ASSY AIR DUCT CUT OUT MTG BS6-PH	TATA spare parts
55506260M10101	SIDE BONNET ASSY LH BS6-PH2	TATA spare parts
55506260M10102	WHEEL ARCH ASSY FRONT-LH BS6-PH2	TATA spare parts
55506260M10107	ASSY FRONT WHEEL ARCH COMP RH BS6-PH2	TATA spare parts
55506260M10124	SHOTGUN ASSY LH BS6-PH2	TATA spare parts
55506260M10125	ASSY SHOT GUN COMPLETE RH BS6-PH2	TATA spare parts
55506260M10162	SIDE BONNET ASSY RH BS6-PH2	TATA spare parts
55506260M10171	HEADLAMP HOUSING ASSY LH BS6-PH2	TATA spare parts
55506260M10172	HEADLAMP HOUSING ASSY RH BS6-PH2	TATA spare parts
55506300M10247	SIDE WALL ASSY LH BS6-PH2	TATA spare parts
55506300M10248	SIDE WALL ASSY RH BS6-PH2	TATA spare parts
55506300M10261	SIDE WALL ASSY LH BS6-PH2	TATA spare parts
55506300M10266	SIDE WALL ASSY RH BS6-PH2	TATA spare parts
55506300M10277	SIDE WALL ASSY LH BS6-PH2	TATA spare parts
55506300M10278	SIDE WALL ASSY RH BS6-PH2	TATA spare parts
55506300M10288	SIDE WALL ASSY LH BS6-PH2	TATA spare parts
55506300M10289	SIDE WALL ASSY RH BS6-PH2	TATA spare parts
55506500M10117	ROOF ASSY(STRETCH AMBU-AC+REVLVNG LAMP	TATA spare parts
55506500M10120	PANEL ASSY ROOF MIDDLE BS6-PH2	TATA spare parts
55506500M10124	ROOF ASSY BS6-PH2	TATA spare parts
55506510M10105	STIFFENER ASSY ROOF BS6-PH2	TATA spare parts
55506510M10107	ASSY CROSSMEMBER UPPER REAR BS6-PH2	TATA spare parts
55506510M10110	ASSY STIFFNER ROOF CENTRE BS6-PH2	TATA spare parts
55506510M10111	STIFFENER ASSY ROOF REAR BS6-PH2	TATA spare parts
55506510M10131	STIFFENER ASSY ROOF FRONT PILLAR BS6-PH2	TATA spare parts
55506510M10132	STIFFENER ASSY ROOF FRONT PILLAR BS6-PH2	TATA spare parts
55506510M10146	TUBE ASSY LIGHT BKT REAR BS6-PH2	TATA spare parts
55506510M10154	BRACKET BS6-PH2	TATA spare parts
55506510M10155	BRACKET BS6-PH2	TATA spare parts
55506510M10156	STIFFENER ASSY ROOF REAR BS6-PH2	TATA spare parts
55506510M10157	STIFFENER ASSY ROOF BS6-PH2	TATA spare parts
55506510M10158	STIFFENER ASSY ROOF REAR BS6-PH2	TATA spare parts
55506510M10159	BRACKET BS6-PH2	TATA spare parts
55506570M10101	ASSY ROOF PANEL BS6-PH2	TATA spare parts
55506570M10103	ROOF BOW AC UNIT ASSY BS6-PH2	TATA spare parts
55506570M10111	ROOF ASSY BS6-PH2	TATA spare parts
55507220M10150	FRONT DOOR SHELL ASSY LH BS6-PH2	TATA spare parts
55507220M10151	FRONT DOOR SHELL ASSY RH BS6-PH2	TATA spare parts
55507420M10107	DOOR SHELL ASSY REAR-LH BS6-PH2	TATA spare parts
55507420M10108	DOOR SHELL ASSY REAR-RH BS6-PH2	TATA spare parts
55507420M10110	DOOR SHELL ASSY REAR-RH BS6-PH2	TATA spare parts
55507420M10122	DOOR SHELL ASSY REAR-LH BS6-PH2	TATA spare parts
55507420M10130	DOOR SHELL ASSY REAR-LH BS6-PH2	TATA spare parts
55507420M10131	DOOR SHELL ASSY REAR-RH BS6-PH2	TATA spare parts

55507420M10132	DOOR SHELL ASSY REAR-LH BS6-PH2	TATA spare parts
55507420M10133	DOOR SHELL ASSY REAR-RH BS6-PH2	TATA spare parts
55508810M10103	SIDE BONNET ASSY LH BS6-PH2	TATA spare parts
55508810M10104	SIDE BONNET ASSY RH BS6-PH2	TATA spare parts
55508810M10111	FENDER ASSY OUTER-LH BS6-PH2	TATA spare parts
55508810M10112	FENDER ASSY OUTER-RH BS6-PH2	TATA spare parts
55508870M10160	CENTER BONNET ASSYWITH HINGES BS6-PH2	TATA spare parts
5550D1B0273001	REAR DOOR ASSY LH-RH BS6-PH2	TATA spare parts
5550D9Y0160002G3	PORCLN_WHITE-PAINTED BODY SHELL-MFG BS6-	TATA spare parts
5550D9Y0160003G3	PORCLN_WHITE-PAINTED BODY SHELL-MFG BS6-	TATA spare parts
5550D9Y0160005FD	SK_GOLN_YELW-PAINTED BODY SHELL-MFG BS6-	TATA spare parts
5550D9Y0160012FD	SK_GOLN_YELW-PAINTED BODY SHELL-MFG BS6-	TATA spare parts
555243803301	BRACKET-VACUUM PUMP MTG ACE EV	TATA spare parts
555254504901	EMERGENCY STOP SWITCH ACE EV	TATA spare parts
555254504902	SWITCH GEAR RANGE SELECTOR ACE EV	TATA spare parts
555262208201	BRACKET SUPPORT MTG ACE EV	TATA spare parts
555268306302	COVER EMERGENCY SWITCH & DNR SWITCH ACE	TATA spare parts
555268306303	BEZEL EMERGENCY SWITCH COVER ACE EV	TATA spare parts
555268306303CE	PIANO_BK_PLN-BEZEL EMERGENCY SWITCH COVE	TATA spare parts
555280589901	CHARGER & DC-DC CONVERTOR ACE EV	TATA spare parts
555283400101	BATTERY COOLING UNIT ACE EV	TATA spare parts
555283400102	COOLANT TANK ASSY ACE EV	TATA spare parts
555283605804	TUBE ASSY ACE EV	TATA spare parts
555283605805	HOSE BCS OUTLET TO BATTERY INLET ACE EV	TATA spare parts
555283605806	HOSE BATTERY OUTLET TO BCS INLET ACE EV	TATA spare parts
555316262001	INTERIM LCD INSTRUMENT CLUSTER ACE EV	TATA spare parts
555324000105	A-MOUNT ASSY ACE EV	TATA spare parts
555324000106	C-MOUNT ASSY ACE EV	TATA spare parts
555324100102	ASSY BRKT ENGINE MTG FRT. ACE EV	TATA spare parts
555324100103	BRACKET ASSY C-MOUNT ACE EV	TATA spare parts
555324100105	BRACKET ASSY ACE EV	TATA spare parts
555324100110	BRACKET ASSY C-MOUNT ACE EV	TATA spare parts
555324203701	BRACKET B-MOUNT ACE EV	TATA spare parts
555329200101	LEVER ASSY BRAKE PEDAL ACE EV	TATA spare parts
555329200106	BRACKET ASSY SENSOR MTG ACE EV	TATA spare parts
555329200108	BRACKET ASSY WITH BUSH ACE EV	TATA spare parts
555329207701	RUBBER COVER BRAKE PEDAL ACE EV	TATA spare parts
555329500103	ASSY BRAKE & CLUTCH CONTR. MTG BKT ACE E	TATA spare parts
555329500104	BRACKET ASSY CONTROL MTG ACE EV	TATA spare parts
555331200110	CROSS MEMBER ASSY ACE EV	TATA spare parts
555341100101	PROPELLER SHAFT ASSY ACE EV	TATA spare parts
555342700109	PARKING BRAKE CABLE ASSY FRONT ACE EV	TATA spare parts
555342700110	PARKING BRAKE CABLE ASSY REAR-RH ACE EV	TATA spare parts
555342700111	PARKING BRAKE CABLE ASSY REAR-LH ACE EV	TATA spare parts
555343100101	VACUUM HOSE ASSY ACE EV	TATA spare parts
555343100103	KIT-NON RETURN VALVE ACE EV	TATA spare parts
555343500102	VACUUM BRAKE HOSE ACE EV	TATA spare parts

555343500103	HOSE ASSY ACE EV	TATA spare parts
555343500104	HOSE ASSY ACE EV	TATA spare parts
555343500106	HOSE ACE EV	TATA spare parts
555343500107	BOOSTER ASSY W/O NRV ACE EV	TATA spare parts
555343500108	VACUUM SENSOR ACE EV	TATA spare parts
555343505815	HOSE ACE EV	TATA spare parts
555343505816	HOSE ACE EV	TATA spare parts
555343800105	TUBE ASSY T-CONN TO ADAPTER ACE EV	TATA spare parts
555343800106	TUBE ASSY T-CONN TO ADAPTER ACE EV	TATA spare parts
555343800107	TUBE ASSY ADAPTER TO LCRV REAR ACE EV	TATA spare parts
555343800108	TUBE ASSY ADAPTER TO LCRV REAR ACE EV	TATA spare parts
555343800109	TUBE ASSY TMC SECONDARY TO T-CONN ACE EV	TATA spare parts
555343800110	TUBE ASSY TMC PRIMARY TO T-CONN ACE EV	TATA spare parts
555343800111	TUBE ASSY LCRV TO REAR BRAKE HOSE RH ACE	TATA spare parts
555343800112	TUBE ASSY T-CONN TO FRT BRKE HOSE LH ACE	TATA spare parts
555343990101	KIT-BOOSTER ASSY ACE EV	TATA spare parts
555354509902	DRIVE CONTROL SWITCH	TATA spare parts
555354600111	CABLE ASSY MEGA FUSE TO DC CONVERT.+VE A	TATA spare parts
555354600112	CABLE ASSY DC CONVER.TO BATTERY -VE ACE	TATA spare parts
555354600114	WIRING HARNESS MAIN ACE EV	TATA spare parts
555354600115	PIGTAIL CONTAINER LAMP ACE EV	TATA spare parts
555354600118	STICKER & COVER ASSY FUSE BOX ACE EV	TATA spare parts
555354600119	BATTERY -VE ACE EV	TATA spare parts
555354610103	WIRING HARNESS MAIN	TATA spare parts
555354640112	WIRING HARNESS PIGTAIL	TATA spare parts
555354719904	ECU VEHICLE TRACKING ASSY ACE EV	TATA spare parts
555354904901	POTENTIOMETER ASSY ACE EV	TATA spare parts
555358900611	INSULATED PHILLIPS SCREWDRIVER SIZE PH1*	TATA spare parts
555358900612	INSULATED PHILLIPS SCREWDRIVER PH2*100MM	TATA spare parts
555358900613	INSULATED PHILLIPS SCREWDRIVER PH3*150MM	TATA spare parts
555358900614	INSULATED SCREWDRIVER SIZE 0.8*4.0*100MM	TATA spare parts
555358900615	INSULATED SCREWDRIVER 1.0*5.5*125MM ACE	TATA spare parts
555358900616	INSULATED SCREWDRIVER 1.2*6.5*150MM ACE	TATA spare parts
555358900617	INSULATED RING WRENCH 7MM ACE EV	TATA spare parts
555358900618	INSULATED RING WRENCH 8MM ACE EV	TATA spare parts
555358900619	INSULATED RING WRENCH 9MM ACE EV	TATA spare parts
555358900620	INSULATED RING WRENCH 10MM ACE EV	TATA spare parts
555358900621	INSULATED RING WRENCH 11MM ACE EV	TATA spare parts
555358900622	INSULATED RING WRENCH 12MM ACE EV	TATA spare parts
555358900623	INSULATED RING WRENCH 13MM ACE EV	TATA spare parts
555358900624	INSULATED RING WRENCH 14MM ACE EV	TATA spare parts
555358900625	INSULATED RING WRENCH 15MM ACE EV	TATA spare parts
555358900626	INSULATED RING WRENCH 16MM ACE EV	TATA spare parts
555358900627	INSULATED RING WRENCH 17MM ACE EV	TATA spare parts
555358900628	INSULATED RING WRENCH 18MM ACE EV	TATA spare parts
555358900629	INSULATED RING WRENCH 19MM ACE EV	TATA spare parts
555358900630	INSULATED OPEN WRENCH 8MM ACE EV	TATA spare parts

555358900631	INSULATED OPEN WRENCH 10MM ACE EV	TATA spare parts
555358900632	INSULATED OPEN WRENCH 12MM ACE EV	TATA spare parts
555358900633	INSULATED OPEN WRENCH 13MM ACE EV	TATA spare parts
555358900634	INSULATED OPEN WRENCH 14MM ACE EV	TATA spare parts
555358900635	INSULATED DEEP SOCKET 1/4INCH 6MM ACE EV	TATA spare parts
555358900654	INSULATED DEEP SOCKET 1/4INCH 7MM ACE EV	TATA spare parts
555358900655	INSULATED DEEP SOCKET 1/4INCH 8MM ACE EV	TATA spare parts
555358900656	INSULATED DEEP SOCKET 1/4INCH 10MM ACE E	TATA spare parts
555358900657	INSULATED DEEP SOCKET 1/4INCH 11MM ACE E	TATA spare parts
555358900658	INSULATED DEEP SOCKET 1/4INCH 12MM ACE E	TATA spare parts
555358900659	INSULATED ALLEN SOCKET 1/4INCH 4MM ACE E	TATA spare parts
555358900660	INSULATED ALLEN SOCKET 1/4INCH 5MM ACE E	TATA spare parts
555358900661	INSULATED ALLEN SOCKET 1/4INCH 6MM ACE E	TATA spare parts
555358900662	INSULATED ALLEN SOCKET 1/4INCH 8MM ACE E	TATA spare parts
555358900663	INSULATED Z TYPE ADAPTER 3/8INCH ACE EV	TATA spare parts
555358900664	INSULATED ADAPTER-3/8INCH (FEMALE) TO 1/	TATA spare parts
555358900665	INSULATED SOCKET 3/8INCH 10MM ACE EV	TATA spare parts
555358900666	INSULATED SOCKET 3/8INCH 12MM ACE EV	TATA spare parts
555358900667	INSULATED SOCKET 3/8INCH 13MM ACE EV	TATA spare parts
555358900668	INSULATED SOCKET 3/8INCH 15MM ACE EV	TATA spare parts
555358900669	INSULATED SOCKET 3/8INCH 14MM ACE EV	TATA spare parts
555358900670	INSULATED SOCKET 3/8INCH 17MM ACE EV	TATA spare parts
555358900671	INSULATED SOCKET 3/8INCH 19MM ACE EV	TATA spare parts
555358900672	INSULATED SOCKET 3/8INCH 22MM ACE EV	TATA spare parts
555358900673	INSULATED EXTENSION 1/4INCH*150MM ACE EV	TATA spare parts
555358900674	INSULATED EXTENSION 3/8INCH*125MM ACE EV	TATA spare parts
555358900675	INSULATED EXTENSION 3/8INCH*250MM ACE EV	TATA spare parts
555358900676	INSULATED T-HANDLE 3/8*200MM ACE EV	TATA spare parts
555358900677	INSULATED RATCHET WRENCH 1/4INCH*145MM	TATA spare parts
555358900678	INSULATED RATCHET WRENCH 3/8INCH*200MM	TATA spare parts
555358900679	INSULATED SNIPE NOSE SIDE CUTTING PLIER	TATA spare parts
555358900680	INSULATED COMBINATION PLIER 200MM ACE EV	TATA spare parts
555358900681	INSULATED DISMANTLING KNIFE ACE EV	TATA spare parts
555358900682	INSULATED TORQUE WRENCH ACE EV	TATA spare parts
555358902401	FIXTURE BATTERY PACK	TATA spare parts
555358908001	COOLANT DISPENSER ACE EV	TATA spare parts
555360010115	BODY SHELL ASSY ACE EV	TATA spare parts
555360010118NS	SPRUCE_BLUE-BODY SHELL ASSY PAINTED ACE	TATA spare parts
555361600106	ENGINE COVER ASSY ACE EV	TATA spare parts
555361600109	BRACKET ASSY BUMPER MTG BOTTOMMIDDLE AC	TATA spare parts
555361600110	FLOOR ASSY ACE EV	TATA spare parts
555361600113	PANEL ASSY FRONT FLOOR ACE EV	TATA spare parts
555361600114	WHEEL ARCH ASSY INNER-LH ACE EV	TATA spare parts
555361600115	WHEEL ARCH ASSY INNER-RH ACE EV	TATA spare parts
555362000102	FRONT WALL ASSY ACE EV	TATA spare parts
555363000101	SIDE WALL ASSY RH ACE EV	TATA spare parts
555364000101	REAR WALL ASSY ACE EV	TATA spare parts

555368300104	COVER ASSY	TATA spare parts
555368300105	BEZEL ASSY DNR SWITCH	TATA spare parts
555368706301	FLOOR CARPET WITH INSULATION ACE EV	TATA spare parts
555368706301C7	GRANIT_BLACK-FLOOR CARPET WITH INSULATIO	TATA spare parts
555368706302	CARPET ENGINE COVER ACE EV	TATA spare parts
555368706303	CARPET VERTICAL WALL EV	TATA spare parts
555368706303C7	GRANIT_Black-CARPET VERTICAL WALL ACE EV	TATA spare parts
555370000101	LOAD BODY ASSY RIVETED ACE EV	TATA spare parts
555370100702	RIVET ACE EV	TATA spare parts
555370208225	BRACKET HOOK ACE EV	TATA spare parts
555370400103	LOCK ASSY DOOR ACE EV	TATA spare parts
555370400105	TAILGATE ASSY LH ACE EV	TATA spare parts
555370400106	TAILGATE ASSY RH ACE EV	TATA spare parts
555372980103	KIT-LOCK SET ASSY ACE EV	TATA spare parts
555380100111	BRACKET ASSY - CHARGING PORT ACE EV	TATA spare parts
555380100117	CABLE ASSY ACE EV	TATA spare parts
555380100118	CABLE ASSY ACE EV	TATA spare parts
555380100119	CABLE ASSY ACE EV	TATA spare parts
555380100123	CABLE ASSY (EARTHING CABLE) ACE EV	TATA spare parts
555380100124	CABLE ASSY (EARTHING CABLE) ACE EV	TATA spare parts
555380100125	CABLE ASSY (EARTHING CABLE) ACE EV	TATA spare parts
555380100126	CABLE ASSY (EARTHING CABLE) ACE EV	TATA spare parts
555380100127	BRACKET ACE EV	TATA spare parts
555380100128	BRACKET ACE EV	TATA spare parts
555380100129	CABLE ASSY (EARTHING CABLE) ACE EV	TATA spare parts
555380100135	CHARGING GUN ACE EV	TATA spare parts
555380400101	TRACTION MOTOR ASSY ACE EV	TATA spare parts
555380409901	SPIDER-TPU	TATA spare parts
555380409902	INDUCTION MOTOR ACE EV	TATA spare parts
555380409904	STONE GUARD FAN 80X80X38	TATA spare parts
555380409921	DECAL - GEAR BOX	TATA spare parts
555380409922	NAME PLATE-DRIVETRAIN	TATA spare parts
555380409923	TERMINAL BOOT HV	TATA spare parts
555380500101	BRACKET ASSY -LH ACE EV	TATA spare parts
555380500102	BRACKET ASSY ACE EV	TATA spare parts
555380509901	E-BOX MTG ASSY ACE EV	TATA spare parts
555380509902	E-BOX BOTTOM HOUSING WHK	TATA spare parts
555380509903	E-BOX MTG BKT WITH INSERT OFFSET RH WITH	TATA spare parts
555380509904	E-BOX MTG BKT WITH INSERT OFFSET LH WITH	TATA spare parts
555380509907	MCU COOLING DUCT WELDMENT	TATA spare parts
555380509911	MCU COOLING FAN ASSY PWM	TATA spare parts
555380509914	BUS BAR MCU TO E-BOX EARTHING	TATA spare parts
555380509922	DIODE AND RESISTOR PCB ENCLOSURE ASSEMBL	TATA spare parts
555380509924	VCU ASSEMBLY ACE EV	TATA spare parts
555380509926	30A & 50A FUSE BOX ASSEMBLY	TATA spare parts
555380509929	HV CONNECTOR SOCKET 70 SQ.MM	TATA spare parts
555380509931	POSITIVE BUSBAR E-BOX	TATA spare parts



555380509932	NEGATIVE BUSBAR E-BOX	TATA spare parts
555380509939	HOSE PARKING BKT TML	TATA spare parts
555380509940	BOX MID BRACKET	TATA spare parts
555380509941	HOSE PARKING END BKT TML	TATA spare parts
555380509942	HOSE PARKING BOTTOM BKT TML	TATA spare parts
555380509943	WIRING HARNESS E BOX ACE EV	TATA spare parts
555380509944	DC-DC CABLE ASSEMBLY	TATA spare parts
555380509945	BCS HV CABLE	TATA spare parts
555380509946	MCU CONT OUTPUT TO MCU POS CABLE	TATA spare parts
555380509947	DC-DC FUSE INPUT TO BUSBAR POS CABLE	TATA spare parts
555380509949	E BOX MAIN TOP COVER	TATA spare parts
555380509951	E BOX MCU ACCESS TOP COVER	TATA spare parts
555380509952	OBC DC-DC CD CHARGER - ACE EV	TATA spare parts
555380509955	VCU MTG BKT WITH INSERT ACE	TATA spare parts
555380509956	PRU MTG BKT WITH INSERT ACE	TATA spare parts
555380509957	PRU BOARD ENCAPSULATION	TATA spare parts
555380509960	HEV FUSE 30 A	TATA spare parts
555380509961	HEV FUSE 50 A	TATA spare parts
555380509964	MAIN CONTACTOR EV	TATA spare parts
555380509969	MCU HEATSINK - ACE EV	TATA spare parts
555380509972	ANABOND HEAT SINK 652C ACE EV	TATA spare parts
555380509973	COOLING DUCT SPACER ACE EV	TATA spare parts
555380509974	STICKER MCU ACE EV	TATA spare parts
555380509975	STICKER PRU ACE EV	TATA spare parts
555380509977	STICKER AL - ENCLOSURE VCU ASSEMBLY ACE	TATA spare parts
555380509982	RTV SILICONE SEALANT 666T PLUS ANABOND A	TATA spare parts
555380509987	METAL GLAND DIA 25MM METRIC THD ACE EV	TATA spare parts
555380509988	STICKER E-BOX DETAILS ACE EV	TATA spare parts
555380509989	DECAL DON'T HIGH PRESSURE WASH ACE EV	TATA spare parts
555380509990	STICKER DC-DC CHARGER DETAILS	TATA spare parts
555380600101	BRACKET ASSY BATTERY BOX MTG ACE EV	TATA spare parts
555380600105	BRACKET ASSY BATTERY BOX MTG ACE EV	TATA spare parts
555380609902	ASSY WELDED ENCLOSURE BOTTOM BATTERY PA	TATA spare parts
555380609904	CELL STACK 2 ASSY ACE EV	TATA spare parts
555380609905	VOLTAGE SENSOR HARNESS ACE -(MODULE-B &	TATA spare parts
555380609906	CELL STACK 1 ASSY ACE EV	TATA spare parts
555380609907	VOLTAGE SENSOR HARNESS ACE -(MODULE-A)	TATA spare parts
555380609908	SUB ASEMBLY BDU	TATA spare parts
555380609909	SOLID BUSBAR BATT MAIN +VE	TATA spare parts
555380609910	SOLID BUSBAR BDC & FCC -VE TO CONN -VE	TATA spare parts
555380609912	SOLID BUSBAR BATT MAIN -VE	TATA spare parts
555380609914	BDU HARNESS ACE (JP1)	TATA spare parts
555380609915	BDU HARNESS ACE (JP2)	TATA spare parts
555380609918	BDC CONT INPUT TO PRECHARGE RESISTOR INP	TATA spare parts
555380609919	SEALING GASKET OF COOLANT INLET AND OUTL	TATA spare parts
555380609922	SUB ASSY COOLING PORT MTG BKT WITH INSER	TATA spare parts
555380609927	SOCKET ACE EV	TATA spare parts

555380609928	BATTERY DISCONNECT CONTACTOR EV	TATA spare parts
555380609929	FUSE BATTERY ACE EV	TATA spare parts
555380609939	BRACKET L STACK HOLDER	TATA spare parts
555380609944	BMS SUPPORT CUSHION FOAM	TATA spare parts
555380609947	MODULE PROTECTIVE PAD	TATA spare parts
555380609948	CONNECTOR INLET & OUTLET	TATA spare parts
555380609949	SUB ASSY INLET PIPE	TATA spare parts
555380609950	SUB ASSY OUTLET ASSMBLY	TATA spare parts
555380609956	PRESSURE RELIEF VALVE	TATA spare parts
555380609960	WIRING HARNESS ACE EV	TATA spare parts
555380609961	VOLTAGE AND TEMPERATURE SENSOR PIGTAIL A	TATA spare parts
555380609964	CELL STACK ASSY-02 (10 CELL MODULE) ACE	TATA spare parts
555380609965	CELL STACK ASSY-01 (9 CELL MODULE) ACE E	TATA spare parts
555380609966	SUB ASSY BUSBAR FCC CONT +VE TO FCC CONN	TATA spare parts
555380609967	SUB ASSY BUSBAR BDC CONT +VE TO HV CONN	TATA spare parts
555380609968	GASKET FCC (FAST CHARGING PLUG-IN SEAL)	TATA spare parts
555380609969	GASKET BDC (DISCHARGE PLUG-IN SEAL) ACE	TATA spare parts
555380609970	BRACKET FCC MTG WITH RIVET INSERT ACE EV	TATA spare parts
555380609971	BRACKET BDC MTG WITH RIVET INSERT ACE EV	TATA spare parts
555380609972	HV CONNECTOR SOCKET 50 SQ.MM(96V) ACE EV	TATA spare parts
555380609973	HV CONNECTOR SOCKET 70 SQ.MM(96V) ACE EV	TATA spare parts
555380609974	SUB ASSY BUSBAR STACK ACE EV	TATA spare parts
555380609975	SUBASSY BUSBAR MSD -VE TO BATTERY STACK	TATA spare parts
555380609976	SUB-ASSY BUSBAR BATTERY PACK -VE TO BDU	TATA spare parts
555380609977	SUBASSY BUSBAR STACK 2 +VE TO STACK 3 -V	TATA spare parts
555380609978	SUB-ASSY BUSBAR BATTERY PACK +VE TO BDU	TATA spare parts
555380609979	SUB ASSY BUSBAR COMM CONT -VE TO HV CONN	TATA spare parts
555380609980	SUB-ASSY BUSBAR COMM CONT -VE TO FCC CO	TATA spare parts
555380609981	ASSY GASKET BATTERY PACK - BOTTOM AND TO	TATA spare parts
555380609982	BKT MOUNT WITH INSERT BMS ACE EV	TATA spare parts
555380609983	BMS ASSY ACE EV	TATA spare parts
555380609984	ENCLOSURE TOP BATTERY PACK ACE EV	TATA spare parts
555380609985	COVER TOP STACK 1	TATA spare parts
555380609986	COVER TOP STACK 1	TATA spare parts
555380609987	SUB ASSY BDU BOTTOM ENCLOSURE WITH INSER	TATA spare parts
555380609988	B-BOX RELAY ACE EV	TATA spare parts
555380609989	RELAY PRECHARGE ACE EV	TATA spare parts
555380609990	SUB ASSY PRECHARGE RESISTOR ACE EV	TATA spare parts
555380609993	SUB ASSY MTG BKT WITH INSERT CURRENT SEN	TATA spare parts
555380609994	CURRENT SENSOR LCV ACE EV	TATA spare parts
555380609995	SUB ASSY COVER TOP BDU WITH INSERT ACE E	TATA spare parts
555380619903	STICKER EARTHING POINT ACE EV	TATA spare parts
555380619904	STICKER HV CONNECTOR ACE EV	TATA spare parts
555380619905	STICKER COOLING DETAILS ACE EV	TATA spare parts
555380619906	STICKER POWERED BY ELECTRA ACE EV	TATA spare parts
555380619907	STICKER HIGH VOLTAGE ACE EV	TATA spare parts
555380619908	STICKER MSD ACE EV	TATA spare parts

555380619909	STICKER COOLING CONNECTOR OUTLET ACE EV	TATA spare parts
555380619910	STICKER COOLING CONNECTOR INLET ACE EV	TATA spare parts
555380619911	NAME PLATE-BATTERY PACK ACE EV	TATA spare parts
555380619912	GASKET-CONNECTOR INLET & OUTLET ACE EV	TATA spare parts
555380619916	COVER TOP STACK1	TATA spare parts
555380619917	SNAP CLIP BATTERY PACK	TATA spare parts
555380619918	SUB ASSY BUSBAR STACK	TATA spare parts
555380619919	SUB-ASSY BUSBAR COMM CONT -VE TO FCC	TATA spare parts
555380619920	SUBASSY BUSBAR MSD -VE TO BATTERY STACK	TATA spare parts
555380619921	SUBASSY BUSBAR STACK 2 +VE TO STACK 3 -V	TATA spare parts
555380619922	SUB-ASSY BUSBAR BATTERY PACK +VE TO BDU	TATA spare parts
555380619923	SUB-ASSY BUSBAR BATTERY PACK -VE TO BDU	TATA spare parts
555380619940	STICKER UL SYMBOLS	TATA spare parts
555380619941	STICKER - DISPOSAL	TATA spare parts
555380619942	STICKER DOs & DON&T	TATA spare parts
555380619943	END CAP INLET & OUTLET CONNECTOR	TATA spare parts
555380619944	COVER TOP STACK 2 & 3	TATA spare parts
555380980101	POWER TRAIN ASSY	TATA spare parts
555380990101	VCU ASSY E-BOX ACE EV	TATA spare parts
555380990102	MOTOR CONTROL UNIT ACE EV	TATA spare parts
555380990103	BATTERY MANAGEMENT SYSTEM EV	TATA spare parts
555383400101	COOLANT PUMP ASSY ACE EV	TATA spare parts
555383400102	HOSE ACE EV	TATA spare parts
555383400103	HOSE ACE EV	TATA spare parts
555383400104	HOSE ACE EV	TATA spare parts
555383403301	BRACKET ACE EV	TATA spare parts
555383403302	BRACKET ACE EV	TATA spare parts
555383403303	BRACKET ACE EV	TATA spare parts
555383403304	PLATE ASSY ACE EV	TATA spare parts
555383403306	BRACKET ACE EV	TATA spare parts
555383403307	PLATE ASSY ACE EV	TATA spare parts
555383403308	PLATE ACE EV	TATA spare parts
555383403309	BRACKET ACE EV	TATA spare parts
555383403310	PLATE ASSY ACE EV	TATA spare parts
555383404903	CONTROLLER BATTERY COOLING SYSTEM ACE EV	TATA spare parts
555383404904	CONTROLLER BATTERY COOLING SYSTEM ACE EV	TATA spare parts
555383404905	SENSOR ACE EV	TATA spare parts
555383404906	SENSOR ACE EV	TATA spare parts
555383404908	SENSOR ACE EV	TATA spare parts
555383404909	WIRING HARNESS ACE EV	TATA spare parts
555383404910	CONTROLLER BATTERY COOLING SYSTEM ACE EV	TATA spare parts
555383404911	FUSE ACE EV	TATA spare parts
555383405801	HOSE ACE EV	TATA spare parts
555383405802	HOSE ACE EV	TATA spare parts
555383406901	PIPE ACE EV	TATA spare parts
555383406902	TUBE ACE EV	TATA spare parts
555383406903	PIPE ACE EV	TATA spare parts

555383406904	PIPE ACE EV	TATA spare parts
555383406906	HOSE ACE EV	TATA spare parts
555383407502	DAMPER ASSY ACE EV	TATA spare parts
555383407503	GROMMET ACE EV	TATA spare parts
555383407504	BUSH ACE EV	TATA spare parts
555383407801	O-RING ACE EV	TATA spare parts
555383407802	O-RING ACE EV	TATA spare parts
555383407803	O-RING ACE EV	TATA spare parts
555383407804	O-RING ACE EV	TATA spare parts
555383407805	SENSOR ACE EV	TATA spare parts
555383407808	O-RING ACE EV	TATA spare parts
555383407809	O-RING ACE EV	TATA spare parts
555383407810	O-RING ACE EV	TATA spare parts
555383409901	COOLANT TANK ASSY ACE EV	TATA spare parts
555383409902	CAP ACE EV	TATA spare parts
555383409903	HOUSING ASSY ACE EV	TATA spare parts
555383409904	LINK ACE EV	TATA spare parts
555383409905	CAP ACE EV	TATA spare parts
555383409906	CONDENSER ACE EV	TATA spare parts
555383409907	FUSE ACE EV	TATA spare parts
555383409908	FUSE ACE EV	TATA spare parts
555383409909	FUSE ACE EV	TATA spare parts
555383409910	EXPANSION VALVE ACE EV	TATA spare parts
555383450101	CONDENSER ASSY ACE EV	TATA spare parts
555383450102	CONDENSER FAN ACE EV	TATA spare parts
555383456301	FAN SHROUD ASSY ACE EV	TATA spare parts
555383459902	DAMPER ASSY ACE EV	TATA spare parts
555383550101	COMPRESSOR ASSY ACE EV	TATA spare parts
555383554901	BOLT ACE EV	TATA spare parts
555383600101	SUCTION PIPE ACE EV	TATA spare parts
555383600102	DISCHARGE PIPE ACE EV	TATA spare parts
555383600103	LIQUID HOSE ACE EV	TATA spare parts
555383604901	WIRING HARNESS ACE EV	TATA spare parts
555383605801	HOSE BATTERY OUTLET TO BCS INLET ACE EV	TATA spare parts
555383605802	HOSE BCS OUTLET TO BATTERY INLET ACE EV	TATA spare parts
555383605803	HOSE BCS OUTLET TO BATTERY INLET ACE EV	TATA spare parts
555383605806	HOSE ACE EV	TATA spare parts
555383606901	TUBE ASSY ACE EV	TATA spare parts
555383656901	T-CONNECTOR ACE EV	TATA spare parts
555383656904	TUBE ACE EV	TATA spare parts
555383750103	BRACKET ASSY ACE EV	TATA spare parts
555383750104	CLAMP ASSY ACE EV	TATA spare parts
555383753301	BRACKET ACE EV	TATA spare parts
555383784201	CLAMP ACE EV	TATA spare parts
555383784202	CLAMP ACE EV	TATA spare parts
555388450101	HOUSING ASSY CHARGING UNITACE EV	TATA spare parts
555388450102	COVER ASSY LID ACE EV	TATA spare parts

555388456301	HOUSING CHARGING UNIT ACE EV	TATA spare parts
555388456302	HINGE PIN ACE EV	TATA spare parts
555388456306	BACK PLATE ACE EV	TATA spare parts
555398300108	AEROKIT ASSY	TATA spare parts
555398300108JS	TITANIUM_WH-AEROKIT ASSY	TATA spare parts
555398306301	AEROKIT-CAB STRUCTURE ACE EV	TATA spare parts
555429300107	BUNDY TUBE ASSY LONG MEMBER	TATA spare parts
555429300108	BUNDY TUBE ASSY MIDDLE	TATA spare parts
555429500103	BRACKET ASSY CLUTCH PEDAL MTG	TATA spare parts
555429500105	BRAKE PEDAL ASSY WITH MTG BRACKET	TATA spare parts
55543100M10110	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55543100M10182	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
555431400104	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
555431400105	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
555431400110	CROSS MEMBER ASSY	TATA spare parts
555431408226	REINFORCEMENT TOP-RH BS6-PH2	TATA spare parts
555431408229	REINFORCEMENT STG GEAR BOX SUPPORT RH BS	TATA spare parts
555431408230	REINFORCEMENT STG GEAR BOX SUPPORT RH BS	TATA spare parts
555432100110	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
555432100111	FRONT SPRING ASSY BS6-PH2	TATA spare parts
555432100112	SHACKLE ASSY FRONT BS6-PH2	TATA spare parts
555432104201	U-CLAMP BS6-PH2	TATA spare parts
555432107104	2ND LEAF BS6-PH2	TATA spare parts
555432107105	3RD LEAF BS6-PH2	TATA spare parts
555432107108	SHACKLE FRONT SPRING BS6-PH2	TATA spare parts
555432400107	BRACKET ASSY WITH BUSH REAR SPRING LH BS	TATA spare parts
555432400108	BRACKET ASSY WITH BUSH REAR SPRING RH BS	TATA spare parts
555432400116	REAR SPRING ASSY BS6-PH2	TATA spare parts
555432400117	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
555432400120	SHACKLE ASSY REAR BS6-PH2	TATA spare parts
555432403702	BRACKET REAR SPRING HANGER FRONT BS6-PH2	TATA spare parts
555432407145	3RD LEAF MAIN SPRING BS6-PH2	TATA spare parts
555432407146	2ND LEAF MAIN SPRING BS6-PH2	TATA spare parts
555432407147	1ST LEAF AUX SPRING BS6-PH2	TATA spare parts
555432407149	4TH LEAF MAIN SPRING BS6-PH2	TATA spare parts
555432407150	5TH LEAF MAIN SPRING BS6-PH2	TATA spare parts
555432407154	6TH LEAF MAIN SPRING BS6-PH2	TATA spare parts
555432407155	3RD LEAF AUX SPRING BS6-PH2	TATA spare parts
555432407156	7TH LEAF MAIN SPRING BS6-PH2	TATA spare parts
555432407157	2ND LEAF AUX SPRING BS6-PH2	TATA spare parts
555432407176	SHACKLE REAR SPRING BS6-PH2	TATA spare parts
555441100102	PROPELLER SHAFT ASSY MONOTRON BS6-PH2	TATA spare parts
555441300101	BRACKET ASSY CENTER BRG MTG BS6-PH2	TATA spare parts
555443800101	METAL PIPE BS6-PH2	TATA spare parts
555443800102	METAL PIPE BS6-PH2	TATA spare parts
555443810103	METAL PIPE ASSY WITH CRIMPED HOSE BS6-PH	TATA spare parts
555443900106	PIPE BUNCH ASSY CHASSIS BS6-PH2	TATA spare parts

555446100101	STEERING COLUMN ASSY WITH BELLOW	TATA spare parts
555446600101	STEERING GEAR BOX ASSY WITH PITMAN ARM	TATA spare parts
555446800101	HIGH PRESSURE LINE ASSY	TATA spare parts
555446800102	RETURN LINE ASSY	TATA spare parts
555449100104	PIPE ASSY UREA SUPPLY BS6-PH2	TATA spare parts
555449200102	EXHAUST PIPE ASSY FIRST BS6-PH2	TATA spare parts
555449200103	EXT PIPE ASSY WITH FLEX BELLOW BS6-PH2	TATA spare parts
555449200105	BRACKET ASSY FRONT PIPE MTG BS6-PH2	TATA spare parts
555449200106	HEAT SHIELD ASSY	TATA spare parts
555449203302	BRACKET FRONT PIPE MTG BS6-PH2	TATA spare parts
555449203303	BRACKET FRONT PIPE MTG	TATA spare parts
555454610117	WIRING HARNESS FIREWALL	TATA spare parts
555454620103	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
555454620105	WIRING HARNESS ENGINE	TATA spare parts
555454630112	WIRING HARNESS REAR CHASSIS	TATA spare parts
555454630115	WIRING HARNESS REAR CHASSIS	TATA spare parts
555454709901	GATEWAY DOMAIN CONTROLLER UNIT	TATA spare parts
555458903301	DRIFT (BEARING FITMENT TOOL) BS6-PH2	TATA spare parts
555458903302	DRIFT (BEARING REMOVAL TOOL) BS6-PH2	TATA spare parts
555470110201	SUPD ASSY	TATA spare parts
555470110203	SUPD ASSY LH	TATA spare parts
555470160101	SUPD ASSY BS6-PH2	TATA spare parts
555470160102	SUPD ASSY BS6-PH2	TATA spare parts
555470160104	SUPD ASSY	TATA spare parts
555470160105	SUPD ASSY LH BS6-PH2	TATA spare parts
5554A9Z0170003	LOADBODY FITTED ASSY MFG BS6-PH2	TATA spare parts
555515400101	ALTERNATOR 12V 120A LIN WITH FUSE BS6-PH	TATA spare parts
555529300101	PIPE ASSY CMC TO BOOSTER BS6-PH2	TATA spare parts
555529300103	NYLON PIPE ASSY BS6-PH2	TATA spare parts
55553100M10102	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55553100M10103	FRAME ASSY WITH FITMENT	TATA spare parts
55553100M10105	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55553100M10119	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55553100M10129	FRAME ASSY WITH FITMENT	TATA spare parts
55553100M10139	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
55553100M10144	FRAME ASSY BS6-PH2	TATA spare parts
55553100M10150	FRAME ASSY WITH FITMENT BS6-PH2	TATA spare parts
555531200106	CROSS MEMBER ASSY	TATA spare parts
555531200112	CROSS MEMBER ASSY	TATA spare parts
555531200113	CROSS MEMBER ASSY	TATA spare parts
555531400104	CENTER BEARING CROSS MEMBER ASSY	TATA spare parts
555531400105	CROSS MEMBER ASSY CTR BRG MTG BS6-PH2	TATA spare parts
555531400108	CROSS MEMBER ASSY	TATA spare parts
555531400111	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
555531400112	CENTER BEARING CROSS MEMBER ASSY	TATA spare parts
555532100106	1ST LEAF ASSY WITH BUSH FRONT BS6-PH2	TATA spare parts
555532100107	FRONT SPRING ASSY BS6-PH2	TATA spare parts

555532103301	BRKT FRT SPRING HANGER FRONT-LH BS6-PH2	TATA spare parts
555532103302	BRKT FRT SPRING HANGER FRONT-RH BS6-PH2	TATA spare parts
555532107105	SPACER PLATE BS6-PH2	TATA spare parts
555532107107	CASTER PLATE BS6-PH2	TATA spare parts
555532107108	3RD LEAF BS6-PH2	TATA spare parts
555532107109	2ND LEAF BS6-PH2	TATA spare parts
555532305101	BRACKET FRONT SHOCK ABSORBER LOWER BS6-P	TATA spare parts
555532400106	1ST LEAF ASSY WITH BUSH BS6-PH2	TATA spare parts
555532400109	REAR SPRING ASSY BS6-PH2	TATA spare parts
555532400112	LEAF SPRING ASSY REAR BS6-PH2	TATA spare parts
555532400113	BRACKET ASSY WITH BUSH REAR SPRING RH	TATA spare parts
555532400114	BRACKET ASSY WITH BUSH REAR SPRING LH	TATA spare parts
555532400115	BUMP STOPPER ASSY BS6-PH2	TATA spare parts
555532403703	CASTER PLATE BS6-PH2	TATA spare parts
555532407110	8TH LEAF REAR BS6-PH2	TATA spare parts
555532407113	5TH LEAF BS6-PH2	TATA spare parts
555532407117	6TH LEAF BS6-PH2	TATA spare parts
555532407119	3RD LEAF BS6-PH2	TATA spare parts
555532407123	4TH LEAF BS6-PH2	TATA spare parts
555532407125	7TH LEAF BS6-PH2	TATA spare parts
555532407126	2ND LEAF BS6-PH2	TATA spare parts
555532407140	SPACER BS6-PH2	TATA spare parts
555532507101	SHACKLE BS6-PH2	TATA spare parts
555541100103	PROPELLER SHAFT ASSY MONOTRON	TATA spare parts
555541100105	PROPELLER SHAFT ASSY MONOTRON BS6-PH2	TATA spare parts
555541100106	PROPELLER SHAFT ASSY MONOTRON BS6-PH2	TATA spare parts
555542100106	DRUM BRAKE ASSY FRONT-LH BS6-PH2	TATA spare parts
555542100107	DRUM BRAKE ASSY FRONT-RH BS6-PH2	TATA spare parts
555543500110	VACUUM PIPE BUNCH ASSY BS6-PH2	TATA spare parts
555543800113	TUBE ASSY ADAPTER TO LCRV INLET	TATA spare parts
555543800114	TUBE ASSY LCRV TO REAR HOSE BS6-PH2	TATA spare parts
555543800115	TUBE ASSY ADAPTER TO ADAPTER BS6-PH2	TATA spare parts
555543800116	TUBE ASSY LCRV OUTLET TO REAR HOSE BS6-P	TATA spare parts
555543800117	TUBE ASSY TMC PRIMARY TO FRONT-LH BS6-PH	TATA spare parts
555543800118	TUBE ASSY TMC PRIMARY TO FRONT-RH BS6-PH	TATA spare parts
555543800119	TUBE ASSY ADAPTER TO ADAPTER BS6-PH2	TATA spare parts
555543800120	TUBE ASSY ADAPTER TO LCRV INLET BS6-PH2	TATA spare parts
555543800124	TUBE ASSY TMC SECONDARY TO ADAPTER BS6-P	TATA spare parts
555543800125	TUBE ASSY TMC PRIMARY TO FRT-RH BS6-PH2	TATA spare parts
555543800126	TUBE ASSY TMC PRIMARY TO FRT-LH BS6-PH2	TATA spare parts
555546100101	STEERING COLUMN ASSY BS6-PH2	TATA spare parts
555547100101	BRACKET ASSY FUEL FILTER MTG BS6-PH2	TATA spare parts
555547500101	ARRESTOR ASSY BS6-PH2	TATA spare parts
555547500103	RESTRAINT ASSY BS6-PH2	TATA spare parts
555547500107	ARRESTOR ASSY BS6-PH2	TATA spare parts
555547500109	ARRESTOR ASSY BS6-PH2	TATA spare parts
555547500117	BRACKET ASSY BS6-PH2	TATA spare parts

555547508204	COMPLIANCE PLATE BS6-PH2	TATA spare parts
555547600111	SUCTION FUEL PIPE ASSY BS6-PH2	TATA spare parts
555547600115	FUEL PIPE ASSY FILTER TO FIP BS6-PH2	TATA spare parts
555547600119	VENT PIPE ASSY BS6-PH2	TATA spare parts
555547600120	VENT PIPE ASSY BS6-PH2	TATA spare parts
555547600129	HP PIPE ASSY BS6-PH2	TATA spare parts
555547600130	VENT PIPE ASSY BS6-PH2	TATA spare parts
555547600131	HP PIPE ASSY BS6-PH2	TATA spare parts
555547600135	HP PIPE ASSY BS6-PH2	TATA spare parts
555547600137	VENT PIPE ASSY BS6-PH2	TATA spare parts
555547600142	HP PIPE ASSY BS6-PH2	TATA spare parts
555547600147	BRACKET ASSY BS6-PH2	TATA spare parts
555549100106	PIPE ASSY DPS SENSOR BS6-PH2	TATA spare parts
555549100108	PIPE ASSY DPS SENSOR BS6-PH2	TATA spare parts
555549100111	CLAMP ASSY CATCON MTG BS6-PH2	TATA spare parts
555549100113	BRACKET ASSY SILENCER MTG REAR BS6-PH2	TATA spare parts
555549200102	EXT PIPE ASSY WITH FLEX BELLOW BS6-PH2	TATA spare parts
555549200104	EXHAUST PIPE ASSY WITH FLEX BELLOW FRONT	TATA spare parts
555549200105	EXHAUST PIPE ASSY FIRST	TATA spare parts
555549200106	BRACKET ASSY FRONT PIPE MTG	TATA spare parts
555549200107	BRACKET ASSY FRONT PIPE MTG BS6-PH2	TATA spare parts
555549200108	BRACKET ASSY FRONT PIPE MTG	TATA spare parts
555549203301	BRACKET FRONT PIPE MTG BS6-PH2	TATA spare parts
555549203302	BRACKET FRONT PIPE MTG BS6-PH2	TATA spare parts
555549203304	SUPPORT BRACKET EXHAUST BRAKE BS6-PH2	TATA spare parts
555549600101	HEAT SHIELD ASSY BS6-PH2	TATA spare parts
55554100101	BRACKET ASSY BATTERY BASE MTG BS6-PH2	TATA spare parts
55554103301	BRACKET BATTERY CLAMPING BS6-PH2	TATA spare parts
55554500101	BRKT ASSY BATT.CUT OFF SWTCH MTG BS6-PH2	TATA spare parts
55554504902	IGNITION SWITCH BS6-PH2	TATA spare parts
55554600102	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
55554600103	WIRING HARNESS EMS BS6	TATA spare parts
55554600112	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
55554600114	WIRING HARNESS SENSOR	TATA spare parts
55554600124	BATTERY CABLE -VE BS6-PH2	TATA spare parts
55554600131	PIGTAIL COMBI SWITCH BS6-PH2	TATA spare parts
55554600140	BATTERY CABLE +VE BCS TO MEGA FUSE BS6	TATA spare parts
55554600142	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
55554600143	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
55554600144	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
55554600145	WIRING HARNESS ENGINE	TATA spare parts
55554600149	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
55554600152	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
55554600153	WIRING HARNESS TAIL BS6-PH2	TATA spare parts
55554603301	BRACKET WIRING HARNESS CLAMP MTG BS6	TATA spare parts
55554603304	BRACKET CONNECTOR MTG BS6-PH2	TATA spare parts
55554708201	BRACKET GDCU UNIT MOUNTING BS6-PH2	TATA spare parts



55555156301	DECAL FRONT DOOR LH BS6	TATA spare parts
55556013M10119	ASSY.ROOF BOW BS6-PH2	TATA spare parts
55556014M10106	PANEL ASSY FRONT BS6-PH2	TATA spare parts
55556015M10181	FENDER ASSY FRONT-LH BS6-PH2	TATA spare parts
55556015M10182	FENDER ASSY FRONT-RH BS6-PH2	TATA spare parts
55556060M10118	ASSY.PANEL INNER BONNET REAR RH RHD BS6-	TATA spare parts
55556060M10119	ASSY.MUDGUARD COMP.L.H.R.H.D. BS6-PH2	TATA spare parts
55556060M10125	MUDGUARD ASSY WITH REINF & BRACKET RH BS	TATA spare parts
55556100M10148	SUBSTRUCTURE ASSY WITH FLOOR BS6-PH2	TATA spare parts
55556160M10102	STEP WELL ASSY LH BS6-PH2	TATA spare parts
55556160M10103	STEP WELL ASSY RH BS6-PH2	TATA spare parts
55556200M10153	FRONT WALL ASSY BS6-PH2	TATA spare parts
55556210M10118	DOOR POST ASSY FRONT-LH BS6-PH2	TATA spare parts
55556210M10119	DOOR POST ASSY FRONT-RH BS6-PH2	TATA spare parts
55556250M10103	OUTER PANEL ASSY WINDSHIELD BOTTOM BS6-P	TATA spare parts
55556260M10113	POST SIDE ASSY FRONT-RH BS6-PH2	TATA spare parts
55556260M10153	INNER PANEL ASSY WINDSHIELD	TATA spare parts
55556261M10116	FIREWALL PANEL ASSY BS6-PH2	TATA spare parts
55556261M10117	FIREWALL ASSY BS6-PH2	TATA spare parts
55556261M10124	PANEL ASSY POST SIDE LH BS6-PH2	TATA spare parts
55556400M10111	REAR WALL ASSY BS6-PH2	TATA spare parts
555570100105	SUPD ASSY	TATA spare parts
555570100106	SUPD ASSY BS6-PH2	TATA spare parts
555570110201	SUPD ASSY LH	TATA spare parts
555570110203	SUPD ASSY RH	TATA spare parts
555570160102	SUPD ASSY	TATA spare parts
55557220M10109	DOOR SHELL ASSY LH BS6-PH2	TATA spare parts
55557220M10110	DOOR SHELL ASSY RH BS6-PH2	TATA spare parts
55558810M10105	ASSY.BONNET SIDE LH BS6-PH2	TATA spare parts
55558810M10106	ASSY.BONNET SIDE RH BS6-PH2	TATA spare parts
55558870M10193	BONNET CENTER ASSY FRONT BS6-PH2	TATA spare parts
5555A9Z0170003	LOADBODY FITTED ASSY BS6-PH2	TATA spare parts
5555A9Z0170004	LOAD BODY ASSY BS6-PH2	TATA spare parts
5555A9Z0170006	LOADBODY FITTED ASSY MFG BS6-PH2	TATA spare parts
5555D9Y0160001	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
5555D9Y0160002	PAINTED BODY SHELL BS6-PH2	TATA spare parts
5555D9Z0160070	PARTIALLY FITTED CAB BS6-PH2	TATA spare parts
5555D9Z0160071	PARTIALLY FITTED CAB BS6-PH2	TATA spare parts
5555D9Z0160078	PARTIALLY FITTED CAB W/O ELECTICALS &AMP	TATA spare parts
5555D9Z0160079	FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
5555D9Z0160082	PARTIALLY FITTED CAB BS6-PH2	TATA spare parts
5555D9Z0160093	PARTIALLY FITTED CAB BS6-PH2	TATA spare parts
5555D9Z0160095	PARTIALLY FITTED CAB BS6-PH2	TATA spare parts
5555D9Z0160098	PARTIALLY FITTED CABIN ASSY-MFG BS6-PH2	TATA spare parts
5555H9X0233009	FRONT AXLE ASSY WITH BRAKES BS6	TATA spare parts
5555H9X0233010	FRONT AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
555620020001	REAR REFLECTOR	TATA spare parts

555631200101	CROSS MEMBER ASSY FRT CYL REAR BS6-PH2	TATA spare parts
555631200102	CROSS MEMBER ASSY BS6-PH2	TATA spare parts
555631470101	SPT BRKT ASSY CROSS MEMBER BS6-PH2	TATA spare parts
555631890101	BRACKET ASSY LOAD BODY MTG BS6-PH2	TATA spare parts
555643500102	VACUUM PIPE ENGINE END BS6	TATA spare parts
555643500103	VACUUM PIPE ASSY BS6	TATA spare parts
555643500112	VACUUM PIPE ASSY BS6-PH2	TATA spare parts
555643500115	VACUUM PIPE ASSY BS6-PH2	TATA spare parts
555643800102	TUBE ASSY T-CONN TO ADAPTER BS6	TATA spare parts
555643800103	TUBE ASSY T-CONN TO ADAPTER BS6	TATA spare parts
555643800104	TUBE ASSY ADAPTER TO R BRAKE HOSE RH BS6	TATA spare parts
555643800105	TUBE ASSY ADAPTER TO R BRAKE HOSE LH BS6	TATA spare parts
555643800106	BRACKET ASSY BS6-PH2	TATA spare parts
555643800108	BRACKET ASSY BS6-PH2	TATA spare parts
555643800119	TUBE ASSY T-CONN TO ADAPTER BS6-PH2	TATA spare parts
555643800120	TUBE ASSY T-CONN TO ADAPTER BS6-PH2	TATA spare parts
555649200105	SILENCER ASSY WITH PIPE & HEAT SHIELD BS	TATA spare parts
555654600104	WIRING HARNESS MAIN BS6	TATA spare parts
555654600106	WIRING HARNESS EMS BS6	TATA spare parts
555654600111	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
555654600112	RELAY COVER ASSY BS6-PH2	TATA spare parts
555654600118	WIRING HARNESS ENGINE BS6-PH2	TATA spare parts
555654600119	WIRING HARNESS MAIN BS6-PH2	TATA spare parts
555660110108BF	ARCTIC_WHITE-BODY SHELL ASSY PAINTED BS6	TATA spare parts
555661600102	WHEEL ARCH ASSY INNER-LH BS6	TATA spare parts
55566160M10135	CAB MTG CLOSING ASSY RH BS6-PH2	TATA spare parts
55566160M10175	WHEEL ARCH ASSY LH BS6-PH2	TATA spare parts
55566160M10257	CAB MTG CLOSING ASSY LH BS6-PH2	TATA spare parts
5556A9Z0170001BF	LOADBODY FITTED ASSY MFG ARTIC WHITE BS6	TATA spare parts
5556D9Y0160001BF	PAINTED BODY SHELL-MFG BS6-PH2	TATA spare parts
5556D9Y0160002BF	PAINTED BODY SHELL-MFG _ARTIC WHITE BS6-	TATA spare parts
5556F1A0131002	FRAME ASSY BS6-PH2	TATA spare parts
555720010001	REFLEX REFLECTOR AMBER	TATA spare parts
5557D1A1860001	FES STRUCTURE BS6-PH2	TATA spare parts
556010450001	ITS KIT FOR HYBRID LOW FLOOR	TATA spare parts
556020870001	REAR TOP MARKER 24V RED	TATA spare parts
556020920001	DOOR LAMP BLACK	TATA spare parts
556020930001	DRIVER CABIN LAMP WHITE	TATA spare parts
556020990001	STOP REQUEST LAMP	TATA spare parts
556021000001	STOP/ RAMP REQUEST LAMP	TATA spare parts
556021010001	ROOF LED LAMP STRIP 24V	TATA spare parts
556021020001	DRIVER CABIN LAMP 1 MTS 24V	TATA spare parts
556021040002	WI-FI UNIT SET	TATA spare parts
556021060001	LCD TV 24V	TATA spare parts
556030190001	MOBILE CHARGER	TATA spare parts
556080559901	DC-DC CONVERTER EV	TATA spare parts
55732110126	MIG WIRE 1.2	TATA spare parts

55843	GASKET TURBOCHARGER	TATA spare parts
5586485	SM PINION SPRINGS	TATA spare parts
55CSSE01	CONDUCTOR SEAT	TATA spare parts
55FBBP01	FRONT BUMPER	TATA spare parts
55FPDFPD01	FRONT PASSENGER J/K DOOR	TATA spare parts
55S2LASE01	TWO SEATER SEAT L.H. WITH	TATA spare parts
55S2LSE01	TWO SEATER SEAT L.H.	TATA spare parts
55S2RASE01	TWO SEATER SEAT R.H. WITH	TATA spare parts
55S2RSE01	TWO SEATER SEAT R.H.	TATA spare parts
55S6SE01	SIX SEATER SEAT	TATA spare parts
55SFSF01	SPARE WHEEL FLAP	TATA spare parts
56506000560	ADHESIVE SYN RUBBER BASE TS25408-50ML BS	TATA spare parts
56506000667	SEALING COMPOUND ELRING DIRKO	TATA spare parts
56506001281	GLASS SEALANT	TATA spare parts
56506001329	ADHESIVE TEROSTAT 3213-138HENKEL 420GMS	TATA spare parts
56506002350	ADHESIVE BEARING RETAINER HS TS25408	TATA spare parts
56506002562	ADHESIVE THREAD LOCKER HS	TATA spare parts
56506002881	LIQUID SEALANT (MB CAP REAR SEAL)	TATA spare parts
56506003160	HIGH TACK ADHESIVE TS25408 BS6 PH2	TATA spare parts
56506003411	ADHESIVE DIRECT GLAZING	TATA spare parts
56506003429	TEROSTAT-8511 100ML BOTTL	TATA spare parts
56506003437	TEROSTAT-8521 100ML BOTTL	TATA spare parts
56506003445	TEROSTAT-8550 1LTR TIN	TATA spare parts
56506003453	TEROSTAT 930G 420GM TUBE	TATA spare parts
56506003461	RTV SILICON LIQUID GASKET TS25408	TATA spare parts
56506004905	ADHESIVE SEALANT600ML WHITE	TATA spare parts
56506004913	ADHESIVE SEALANT600ML BLACK	TATA spare parts
56506005081	RTV SILICON SEALANT 666-ANABOND-100G PAC	TATA spare parts
56506005715	BICOMPONENT ACRYLIC ADHESIVE	TATA spare parts
56506005731	ACELERADOR	TATA spare parts
56506005821	ANABOND WHITE 2X25X2500 ROLL	TATA spare parts
570101000108	ENGINE MPV	TATA spare parts
570101000109	ASSEMBLY ENGINE COMPLETE	TATA spare parts
570101000114	ASSY ENGINE COMPLETE	TATA spare parts
570101000115	ASSY. ENGINE COMP. ISBE6.7 -275 HP BS3	TATA spare parts
570101000116	ENGINE LPT 2521 ISBE 210 HP BS4	TATA spare parts
570101000123	ENGINE LPTA 1623 RTA ISBE 245	TATA spare parts
570101000127	ENGINE OPTION LIST (ISBE 275 HP -LPTA162	TATA spare parts
570101000127AE	ASSY ENG COMPL. (275 HP) -1628	TATA spare parts
570101000131	ASSY. ENGINE COMP. ISBE6.7-230HP BS3	TATA spare parts
570101000132	ASSY ENGINE COMPLETE (2523.K AC)	TATA spare parts
570101000134	ENGINE ISBE 230HP NONAC	TATA spare parts
570101000151	ENGINE ASSY	TATA spare parts
570101000152	COMPLETE ENGINE	TATA spare parts
570101000153	ENGINE ASSY COMPLETE	TATA spare parts
570101000154	ASSY ENGINE COMPLETE	TATA spare parts
570101000155	ENGINE ASSY PRIMA LX 4028.S AC	TATA spare parts

570101000156	ASSY. ENGINE COMP. ISBE6.7 BS4	TATA spare parts
570101000164	ENGINE OPTION LIST	TATA spare parts
570101000166	ENGINE ASSY-OPTION LIST	TATA spare parts
570101000167	ENGINE	TATA spare parts
570101000176	ENGINE OPTION LIST	TATA spare parts
570101000180	ENGINE OPTION LIST	TATA spare parts
570101000187	ENGINE OPTION LIST	TATA spare parts
570101000193	ENGINE OPTION LIST	TATA spare parts
570101000204	ENGINE OPTION LIST	TATA spare parts
570101000206	ENGINE OPTION LIST	TATA spare parts
570101000210	ENGINE ASSY-OPTION LIST	TATA spare parts
570101000211	ENGINE-OPTION LIST	TATA spare parts
570101000213	ENGINE OPTION LIST	TATA spare parts
570101000236	ENGINE-OPTION LIST	TATA spare parts
570101000277	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000285	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000289	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000291	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000302	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000304	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000308	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000310	ENGINE-OPTION LIST ISBE6.7 BS6 WB	TATA spare parts
570101000312	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000314	ENGINE-OPTION LIST BS6	TATA spare parts
570101000318	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000320	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000322	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000324	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000330	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000341	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000357	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101000371	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101010106	ENGINE-OPTION LIST ISBE 6.7 BS4	TATA spare parts
570101010111	ENGINE OPTION LIST	TATA spare parts
570101010114	ENGINE ASSY-OPTION LIST	TATA spare parts
570101010117	ENGINE-OPTION LIST BS6	TATA spare parts
570101010118	ENGINE - OPTION LIST BS6	TATA spare parts
570101010174	ENGINE - OPTION LIST BS6	TATA spare parts
570101010178	ENGINE-OPTION LIST BS6	TATA spare parts
570101010180	ENGINE-OPTION LIST BS6	TATA spare parts
570101010184	ENGINE-OPTION LIST BS6	TATA spare parts
570101010192	ENGINE - OPTION LIST BS6	TATA spare parts
570101010196	ENGINE - OPTION LIST BS6	TATA spare parts
570101010198	ENFINE OPTION LIST BS6	TATA spare parts
570101010201	ENGINE-OPTION LIST BS6	TATA spare parts
570101010231	ENGINE-OPTION LIST BS6	TATA spare parts
570101010233	ENGINE-OPTION LIST BS6	TATA spare parts

570101010243	ENGINE - OPTION LIST BS6	TATA spare parts
570101010254	ENGINE OPTION LIST BS6	TATA spare parts
570101010256	ENGINE OPTION LIST BS6	TATA spare parts
570101010262	ENGINE - OPTION LIST BS6	TATA spare parts
570101010274	ENGINE - OPTION LIST BS6	TATA spare parts
570101010278	ENGINE - OPTION LIST BS6	TATA spare parts
570101010280	ASSY. ENGINE ISBE6.7 BS6 WB	TATA spare parts
570101010284	ASSY. ENGINE ISBE6.7 WB BS6	TATA spare parts
570101010286	ENGINE - OPTION LIST BS6	TATA spare parts
570101010289	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
570101010311	ASSY. ENGINE ISBE6.7 BS6 WB BS6	TATA spare parts
570101010313	ENGINE-OPTION LIST	TATA spare parts
570101010315	ENGINE-OPTION LIST BS6	TATA spare parts
570101010332	COVER ASSY-PTO-END BS6	TATA spare parts
570101010344	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
570101010345	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
570101010355	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
570101010362	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
570101010378	ENGINE - OPTION LIST BS6	TATA spare parts
570101020117	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
570101020122	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
570101020124	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
570101020125	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
570101020140	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
570101020142	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
570101020144	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
570101153801	AIR INTAKE ELBOW ON ENGINE	TATA spare parts
570101173302	BRACKET (DIP STICK MTG.)	TATA spare parts
570101173303	BRACKET (DIP STICK MTG)	TATA spare parts
570101173304	BRACKET (DIP STICK MTG.)	TATA spare parts
570101173305	DIPSTICK MOUNTING BRACKET	TATA spare parts
570101173310	BRACKET	TATA spare parts
570101173312	BRACKET DIPSTICK MTG BS6	TATA spare parts
570101990101	PAN OIL	TATA spare parts
570101990101AE	PAN OIL 1628	TATA spare parts
570101990104	LONG BLOCK 245 HP BS III (LPO 1624)	TATA spare parts
570101990105	LONG BLOCK (ISBE 235HP & 270 HP BS III)	TATA spare parts
570101990105AE	LONG BLOCK (ISBE 235HP & 270 HP BS III)	TATA spare parts
570101990106	LONG BLOCK (ISBE 230 HP BS III ENG	TATA spare parts
570101990107	LONG BLOCK ISBE 6.7 FRONT SUMP BS4 BS3/4	TATA spare parts
570101990108	LONG BLOCK (ISBE 245 HP BS III MPV)	TATA spare parts
570101990109	LONG BLOCK ISBe6.7 BS4 REAR SUMP LPO1624	TATA spare parts
570101990110	LONG BLOCK FOR ISBE	TATA spare parts
570101990111	SET,UPPER ENGINE GASKET ISBe6.7 BS3/BS4	TATA spare parts
570101990111AE	SET UPPER ENG GSKT-1628-1828	TATA spare parts
570101990112	KIT-GASKET LOWER ISBE6.7 BS3/4	TATA spare parts
570101990112AE	SET LOWER ENG GSKT-1628-1828	TATA spare parts

570101990116	BREATHER CRANKCASE	TATA spare parts
570101990131	LONG BLOCK ISBE6.7 FRONT OIL SUMP BS3	TATA spare parts
570101990132	LONG BLOCK ISBE6.7 REAR OIL SUMP EURO3	TATA spare parts
570101990150	CYLINDER HEAD BS3/4	TATA spare parts
570101990155	LONG BLOCK	TATA spare parts
570101990221	UPPER GASKET KIT ISBE6.7 BS6	TATA spare parts
570101990222	LOWER GASKET KIT ISBE6.7 BS6	TATA spare parts
570101990223	ASSY. LONG BLOCK ISBE6.7 BS6 FR SUMP W/B	TATA spare parts
570101990226	HEAD CYLINDER BS6	TATA spare parts
570101990227	ASSY. LONG BLOCK ISBE 6.7 BS4 DEEP SUMP	TATA spare parts
570101990280	LONG BLOCK ISBE6.7 W/BRK BS6-PH2	TATA spare parts
570101990281	LONG BLOCK ISBE6.7 W/BRK BS6-PH2	TATA spare parts
570101993001	BALL BEARING ASSY	TATA spare parts
570101993302	BRACKET BREATHER BS6	TATA spare parts
570101993303	BRACE BRACKET BS6	TATA spare parts
570101993305	BRACE TUBE BS6	TATA spare parts
570101993306	BRACE HOSE BS6	TATA spare parts
570101993307	BRACE BRACKET BS6-PH2	TATA spare parts
570101993401	BUSHING	TATA spare parts
570101993402	BUSHING	TATA spare parts
570101993703	HEAD CYLINDER	TATA spare parts
570101993703AE	HEAD CYLINDER 1628	TATA spare parts
570101993704	HEAD CYLINDER	TATA spare parts
570101993709	CYLINDER LINER	TATA spare parts
570101993711	CYLINDER HEAD	TATA spare parts
570101993712	CYLINDER HEAD	TATA spare parts
570101993713	CYLINDER HEAD	TATA spare parts
570101994201	CLAMP SPRING HOSE	TATA spare parts
570101994201AE	CLAMP SPRING HOSE 1628	TATA spare parts
570101994202	CLAMP INJECTOR BS4	TATA spare parts
570101994203	CLAMP SPRING HOSE BS6	TATA spare parts
570101994204	CLAMP SPRING HOSE BS6	TATA spare parts
570101994205	CLAMP SPRING HOSE BS6	TATA spare parts
570101994206	CLAMP WIRE TIE	TATA spare parts
570101994302	CLIP BS6	TATA spare parts
570101994303	CLIP BS6	TATA spare parts
570101994701	COVER ACCESS HOLE BS6	TATA spare parts
570101995301	GASKET OIL PAN	TATA spare parts
570101995301AE	GASKET OIL PAN	TATA spare parts
570101995302	GASKET CYLINDER HEAD ISBE6.7 BS3/4/6	TATA spare parts
570101995302AE	GASKET CYLINDER HEAD	TATA spare parts
570101995303	GASKET OIL SUC CONNECTION	TATA spare parts
570101995307	GASKET OIL PAN BS6	TATA spare parts
570101995308	GASKET OIL PAN BS6	TATA spare parts
570101995309	GASKET FLANGE BS6	TATA spare parts
570101996901	TUBE BREATHER	TATA spare parts
570101996903	TUBE LUB OIL SUCTION	TATA spare parts

570101996907	TUBE LUB OIL SUCTION BS6	TATA spare parts
570101996908	TUBE LUB OIL SUCTION BS6	TATA spare parts
570101996909	TUBE BREATHER BS6	TATA spare parts
570101996910	TUBE LUB OIL DRAIN BS6	TATA spare parts
570101996911	TUBE AIR TRANSFER BS6	TATA spare parts
570101996912	TUBE AIR TRANSFER BS6	TATA spare parts
570101996913	BRACE TUBE BS6	TATA spare parts
570101997101	PLATE CLAMPING	TATA spare parts
570101997102	PLATE CLAMPING BS6	TATA spare parts
570101997103	PLATE CLAMPING BS6	TATA spare parts
570101997203	PLUG THREADED	TATA spare parts
570101997203AE	PLUG THREADED 1628	TATA spare parts
570101997204	PLUG THREADED BS6	TATA spare parts
570101997706	SEAL OIL BS6	TATA spare parts
570101997801	SEAL O RING	TATA spare parts
570101997801AE	SEAL O RING 1628	TATA spare parts
570101997803	SEAL O RING BS4	TATA spare parts
570101997804	SEAL O RING BS4	TATA spare parts
570101997805	SEAL O RING	TATA spare parts
570101997805AE	SEAL O RING 1628	TATA spare parts
570101998001	MAIN BEARING BOLT	TATA spare parts
570101998002	SCREW ROUND HEAD CAP	TATA spare parts
570101998003	SCREW ROUND HEAD CAP	TATA spare parts
570101998004	SCREW ROUND HEAD CAP BS4	TATA spare parts
570101998005	SCREW BANJO CONNECTOR	TATA spare parts
570101998006	SCREW SOCKET HEAD CAP	TATA spare parts
570101998007	SCREW HEX FLANGE HEAD CAP	TATA spare parts
570101998012	SCREW HEX FLANGE HEAD	TATA spare parts
570101998013	"SCREW,HEX FLANGE HEAD CAP"	TATA spare parts
570101998014	"SCREW,SOCKET HEAD CAP"	TATA spare parts
570101998016	SCREW ROUND HEAD CAP BS6	TATA spare parts
570101998017	SCREW HEX FLANGE HEAD CAP BS6	TATA spare parts
570101998018	SCREW SDR ISOLATOR CAP BS6	TATA spare parts
570101998019	SCREW HEXAGON HEAD CAP BS6	TATA spare parts
570101998020	SCREW HEX FLANGE HEAD CAP BS6	TATA spare parts
570101998801	STUD DOUBLE END PLAIN BS6	TATA spare parts
570101998802	STUD DOUBLE END PLAIN BS6	TATA spare parts
570101998803	STUD DOUBLE END PLAIN BS6-PH2	TATA spare parts
570101999001	VALVE CHECK BS6	TATA spare parts
570101999201	WASHER SEALING	TATA spare parts
570101999701	ENGINE BARRING TOOL	TATA spare parts
570101999801	DIPSTICK	TATA spare parts
570101999803	INJECTOR BS6	TATA spare parts
570101999804	CONNECTOR INJ FUEL SUPPLY BS6	TATA spare parts
570101999814	CONNECTOR FUEL LINE	TATA spare parts
570101999815	PAN OIL BS6	TATA spare parts
570101999817	BREATHER CRANKCASE BS6	TATA spare parts

570101999820	SOLENOID ENGINE BRAKE BS6	TATA spare parts
570101999821	ADAPTER O RING BS6	TATA spare parts
570101999822	DIPSTICK BS6	TATA spare parts
570101999823	DIPSTICK BS6	TATA spare parts
570101999825	COALESCER BREATHER CARTRIDGE BS6	TATA spare parts
570101999827	SPACER MOUNTING	TATA spare parts
570101999828	SOLENOID BS6	TATA spare parts
570101999901	PLUG SCREW	TATA spare parts
570101999902	CAP MAIN BEARING	TATA spare parts
570101999904	PLUG EXPANSION	TATA spare parts
570101999905	CAP MAIN BEARING	TATA spare parts
570101999905AE	CAP MAIN BEARING 1628	TATA spare parts
570101999907	STIFFENER CYLINDER BLOC	TATA spare parts
570101999920	ADAPTER OIL PAN	TATA spare parts
570101999921	STIFFENER CYLINDER BLOCK	TATA spare parts
570101999922	PLUG EXPANSION	TATA spare parts
570101999923	PLUG EXPANSION	TATA spare parts
570101999924	DIPSTICK	TATA spare parts
570101999925	BREATHER CRANKCASE	TATA spare parts
570101999925AE	BREATHER CRANKCASE 1628	TATA spare parts
570101999926	SLEEVE SALVAGE BS3	TATA spare parts
570101999927	COUPLING PLAIN HOSE	TATA spare parts
570101999928	DIPSTICK	TATA spare parts
570101999929	CAP MAIN BEARING	TATA spare parts
570101999930	CAP MAIN BEARING	TATA spare parts
570101999932	CYLINDER BLOCK BS6	TATA spare parts
570101999933	BRACE TUBE BS6	TATA spare parts
570101999935	BARE CYLINDER HEAD BS6	TATA spare parts
570101999936	BARRING TOOL	TATA spare parts
570103117101	ADOPTER PLATE	TATA spare parts
570103118601	FLY HSG SPACER(FOR G1150 GB)	TATA spare parts
570103990101	SET-PISTON RING (STD) ISBE6.7 BS2/3/4	TATA spare parts
570103990101AE	SET PISTON RING (STD.) 1628	TATA spare parts
570103990102	RING SET(1 OVERSIZE)	TATA spare parts
570103990103	BARE SET PISTON(STANDARD)	TATA spare parts
570103990105	SET-BEARING CONNECTING ROD (STD) BS2-6	TATA spare parts
570103990105AE	SET BRG CNNCTING ROD (STD.)-1628	TATA spare parts
570103990106	CON ROD BEARING SET(2 S)	TATA spare parts
570103990107	CON ROD BEARING SET(3 S)	TATA spare parts
570103990108	CON ROD BEARING SET(4 S)	TATA spare parts
570103990109	SET-MAIN BEARING BS3/4	TATA spare parts
570103990110	SET-PISTON (STD) ISBE6.7 BS3/4	TATA spare parts
570103990110AE	KIT ENGINE PISTON (STD.) 1628	TATA spare parts
570103990111	CRANKSHAFT ENGINE BS3/4	TATA spare parts
570103990111AE	CRANKSHAFT ENGINE	TATA spare parts
570103990112	CRANKSHAFT ENGINE	TATA spare parts
570103990118	DAMPER VIBRATION	TATA spare parts



570103990118AE	DAMPER VIBRATION 1628 1828	TATA spare parts
570103990120	FLYWHEEL	TATA spare parts
570103990123	HOUSING FLYWHEEL	TATA spare parts
570103990124	HOUSING FLYWHEEL	TATA spare parts
570103990126	HOUSING FLYWHEEL	TATA spare parts
570103990127	ROD ENGINE CONNECTING	TATA spare parts
570103990131	VIBRATION DAMPER VISCOUS BS3/4	TATA spare parts
570103990135	FLYWHEEL BS4	TATA spare parts
570103990136	FLYWHEEL (149T) ISBE6.7 BS3/4	TATA spare parts
570103990136AE	FLYWHEEL 1628 1828	TATA spare parts
570103990142	CRANKSHAFT,ENGINE ISBe6.7 BS3/BS4	TATA spare parts
570103990145	CON ROD BEARING SET(I S)	TATA spare parts
570103990146	CRANKSHAFT THRUST BEARING SET(1 S)	TATA spare parts
570103990147	CRANKSHAFT THRUST BEARING SET(2 S)	TATA spare parts
570103990148	CRANKSHAFT THRUST BEARING SET(3 S)	TATA spare parts
570103990149	CRANKSHAFT THRUST BEARING SET(4 S)	TATA spare parts
570103990151	SET-PISTON	TATA spare parts
570103990154	ROD ENGINE CONNECTING BS6-PH2	TATA spare parts
570103990175	PISTON RING SET STD ISBE6.7 BS6	TATA spare parts
570103990176	BARE PISTON SET STD ISBE6.7 BS6	TATA spare parts
570103990177	KIT MAIN BEARING BS6	TATA spare parts
570103990183	KIT MAIN BEARING BS6	TATA spare parts
570103990184	KIT MAIN BEARING BS6	TATA spare parts
570103990185	FLYWHEEL BS6-PH2	TATA spare parts
570103993101	BEARING CONNECTING ROD	TATA spare parts
570103993102	BEARING THRUST	TATA spare parts
570103993131	BEARING MAIN BS6-PH2	TATA spare parts
570103993132	BEARING MAIN BS6-PH2	TATA spare parts
570103993133	BEARING CYD ROLLER BS6	TATA spare parts
570103993134	BEARING CYD ROLLER BS6	TATA spare parts
570103993135	BEARING CYD ROLLER BS6	TATA spare parts
570103993401	BUSHING BS6	TATA spare parts
570103993701	HOUSING FLYWHEEL	TATA spare parts
570103993702	"HOUSING,FLYWHEEL"	TATA spare parts
570103993703	HOUSING GEAR	TATA spare parts
570103993706	HOUSING FLYWHEEL BS6	TATA spare parts
570103993707	HOUSING FLYWHEEL BS6	TATA spare parts
570103993708	HOUSING FLYWHEEL BS6	TATA spare parts
570103993709	HOUSING ACTUATOR BS6	TATA spare parts
570103993710	HOUSING FLYWHEEL BS6	TATA spare parts
570103994701	PLATE COVER	TATA spare parts
570103994701AE	PLATE COVER 1628	TATA spare parts
570103994702	PLATE COVER BS6	TATA spare parts
570103994801	DOWEL PIN	TATA spare parts
570103994801AE	DOWEL PIN	TATA spare parts
570103994802	DOWEL PIN	TATA spare parts
570103995301	GASKET COVER PLATE	TATA spare parts

570103995301AE	GASKET COVER PL LPTA1628/LPTA1828	TATA spare parts
570103995302	GASKET CARRIER BS6	TATA spare parts
570103995401	GEAR CRANKSHAFT	TATA spare parts
570103995402	GEAR CRANKSHAFT	TATA spare parts
570103995403	GEAR IDLER BS6	TATA spare parts
570103995404	GEAR CRANKSHAFT BS6	TATA spare parts
570103996601	PISTON ENGINE	TATA spare parts
570103996603	PISTON ENGINE	TATA spare parts
570103996604	PISTON ENGINE	TATA spare parts
570103996605	SET PISTON (10S) 6.7 BS4	TATA spare parts
570103996606	PISTON ENGINE ISBE6.7 BS6	TATA spare parts
570103996611	PISTON ENGINE BS6	TATA spare parts
570103996701	PISTON PIN	TATA spare parts
570103996901	TUBE LUB OIL SUPPLY BS6	TATA spare parts
570103997001	PULLEY CRANKSHAFT	TATA spare parts
570103997001AE	PULLEY CRANKSHAFT 1628 1828	TATA spare parts
570103997002	PULLEY CRANKSHAFT	TATA spare parts
570103997003	PULLEY CRANKSHAFT	TATA spare parts
570103997201	PLUG THREADED BS6	TATA spare parts
570103997202	PLUG O RING BS6	TATA spare parts
570103997203	PLUG THREADED BS6	TATA spare parts
570103997701	OIL SEAL	TATA spare parts
570103997702	SEAL O RING BS6	TATA spare parts
570103997703	SEAL O RING BS6	TATA spare parts
570103997704	SEAL O RING BS6	TATA spare parts
570103997705	SEAL O RING BS6	TATA spare parts
570103997801	SEAL OIL	TATA spare parts
570103997902	SHAFT STUB BS6	TATA spare parts
570103997903	SHAFT STUB BS6	TATA spare parts
570103997904	SHAFT BS6	TATA spare parts
570103998001	SCREW HEX FLANGE HEAD CAP	TATA spare parts
570103998002	SCREW HEX FLANGE HEAD CAP	TATA spare parts
570103998003	SCREW HEX FLANGE HEAD CAP	TATA spare parts
570103998004	SCREW HEX FLANGE HEAD CAP	TATA spare parts
570103998005	SCREW HEX FLANGE HEAD CAP	TATA spare parts
570103998007	SCREW HEX FLANGE HEAD CAP BS6	TATA spare parts
570103998008	SCREW HEX FLANGE HEAD CAP BS6	TATA spare parts
570103998009	SCREW HEX FLANGE HEAD CAP BS6	TATA spare parts
570103998010	SCREW HEX FLANGE HEAD CAP BS6	TATA spare parts
570103998011	SCREW CAPTIVE WASHER CAP BS6	TATA spare parts
570103998012	SCREW HEX FLANGE HEAD CAP BS6	TATA spare parts
570103998013	SCREW HEX FLANGE HEAD CAP BS6-PH2	TATA spare parts
570103999201	WASHER PLAIN BS6	TATA spare parts
570103999802	RING COMPRESSION PISTON ISBE6.7 BS6	TATA spare parts
570103999803	RING OIL PISTON BS6	TATA spare parts
570103999804	RING COMPRESSION PISTON ISBE6.7 BS6	TATA spare parts
570103999815	PLUG O RING BS6	TATA spare parts

570103999816	RING COMPRESSION PISTON ISBE6.7 BS6	TATA spare parts
570103999817	RING COMPRESSION PISTON ISBE6.7 BS6	TATA spare parts
570103999818	RING OIL PISTON ISBE6.7 BS6	TATA spare parts
570103999819	FLANGE POWER TAKEOFF BS6	TATA spare parts
570103999820	UNION MALE BS6	TATA spare parts
570103999821	RING RETAINING BS6	TATA spare parts
570103999822	SHIELD DEBRIS BS6	TATA spare parts
570103999901	PLUG EXPANSION BS6	TATA spare parts
570103999902	RING COMPRESSION PISTON	TATA spare parts
570103999903	RING COMPRESSION PISTON	TATA spare parts
570103999904	RING OIL PISTON	TATA spare parts
570103999905	RING RETAINING BS4	TATA spare parts
570103999907	NOZZLE PISTON COOLING	TATA spare parts
570103999907AE	NOZZLE PISTON COOLING 1628	TATA spare parts
570103999911	FLANGE CRANKSHAFT	TATA spare parts
570103999915	DAMPER VISCOUS VIBRATION BS6	TATA spare parts
570105990103	CAMSHAFT	TATA spare parts
570105990104	CAMSHAFT	TATA spare parts
570105990104AE	CAMSHAFT 1628	TATA spare parts
570105990107	HOUSING GEAR	TATA spare parts
570105990107AE	HOUSING GEAR 1628	TATA spare parts
570105990110	HOUSING ROCKER LEVER	TATA spare parts
570105993301	BRACKET TIMING BS6	TATA spare parts
570105993302	BRACKET IDLER PULLEY BS6-PH2	TATA spare parts
570105993701	COVER VALVE	TATA spare parts
570105993702	COVER VALVE	TATA spare parts
570105993702AE	COVER VALVE 1628	TATA spare parts
570105994701	COVER VALVE	TATA spare parts
570105994702	COVER FRONT	TATA spare parts
570105994702AE	COVER FRONT 1628 1828	TATA spare parts
570105994703	COVER PUSH ROD	TATA spare parts
570105994705	COVER VALVE	TATA spare parts
570105994707	COVER VALVE	TATA spare parts
570105994708	COVER FRONT	TATA spare parts
570105994709	COVER FRONT BS6	TATA spare parts
570105994710	HOUSING GEAR BS6	TATA spare parts
570105994714	COVER VALVE BS6	TATA spare parts
570105994801	DOWEL RING	TATA spare parts
570105994802	DOWEL RING	TATA spare parts
570105995301	GASKET VALVE COVER BS4	TATA spare parts
570105995301AE	GASKET VAL COVER LPTA1628/LPTA1828	TATA spare parts
570105995303	GASKET RKR LEVER HOUSING	TATA spare parts
570105995303AE	GASKET RKR LEVER HOUSING 1628	TATA spare parts
570105995305	GASKET INTEGRATED WIRING BS6	TATA spare parts
570105995306	GASKET INTEGRATED WIRING BS6	TATA spare parts
570105995401	GEAR CAMSHAFT	TATA spare parts
570105995401AE	GEAR CAMSHAFT 1628	TATA spare parts

570105996003	LEVER ROCKER	TATA spare parts
570105996501	NUT HEXAGON FLANGE	TATA spare parts
570105997701	SEAL OIL	TATA spare parts
570105997701AE	SEAL OIL 1628 1828	TATA spare parts
570105997901	SHAFT ROCKER LEVER	TATA spare parts
570105997903	CAMSHAFT BS6	TATA spare parts
570105998002	SCREW SOCKET HEAD CAP	TATA spare parts
570105998003	SCREW HEX FLANGE HEAD CAP	TATA spare parts
570105998004	SCREW HEXAGON HEAD CAP BS6	TATA spare parts
570105998701	SPRING VALVE BS6	TATA spare parts
570105998702	SPRING VALVE BS6	TATA spare parts
570105998801	STUD	TATA spare parts
570105998802	SCREW STUDED FLANGE CAP BS6	TATA spare parts
570105999001	VALVE EXHAUST	TATA spare parts
570105999808	SUPPORT ROCKER LEVER BS6	TATA spare parts
570105999809	SUPPORT ROCKER LEVER BS6	TATA spare parts
570105999811	LEVER ROCKER BS6	TATA spare parts
570105999812	ISOLATOR VIBRATION BS6	TATA spare parts
570105999813	TENSIONER BELT	TATA spare parts
570105999814	CROSSHEAD VALVE BS6	TATA spare parts
570105999815	SUPPORT ROCKER LEVER BS6	TATA spare parts
570105999816	LEVER ROCKER BS6	TATA spare parts
570105999817	ROCKER ARM BS6	TATA spare parts
570105999901	RETAINER VALVE SPRING	TATA spare parts
570105999903	CAP FILLER	TATA spare parts
570105999905	ISOLATOR NOISE	TATA spare parts
570105999906	TAPPET VALVE	TATA spare parts
570105999910	RING SPEED INDICATOR	TATA spare parts
570105999910AE	RING SPEED INDICATOR 1628	TATA spare parts
570105999911	SUPPORT CAMSHAFT THRUST	TATA spare parts
570105999918	ISOLATOR NOISE BS4	TATA spare parts
570105999919	INSERT VALVE	TATA spare parts
570105999920	INSERT VALVE	TATA spare parts
570105999921	SUPPORT CAMSHAFT THRUST	TATA spare parts
570105999924	COVER VALVE BS6	TATA spare parts
570107990101	MANIFOLD FUEL BS3/4	TATA spare parts
570107990101AE	MANIFOLD FUEL 1628	TATA spare parts
570107990102	HIGH PRESSURE PUMP BS3/4	TATA spare parts
570107990102AE	PUMP FUEL 1628 1828 715	TATA spare parts
570107990103	MANIFOLD FUEL	TATA spare parts
570107990104	PUMP FUEL INJECTION	TATA spare parts
570107990107	HEAD FUEL FILTER	TATA spare parts
570107990107AE	HEAD FUEL FILTER 1628	TATA spare parts
570107990118	PUMP FUEL INJECTION BS6	TATA spare parts
570107990126	PUMP FUEL INJECTION BS6-PH2	TATA spare parts
570107993301	BRACE TUBE BS6	TATA spare parts
570107993302	BRACE TUBE BS6	TATA spare parts

570107993303	BRACE TUBE BS6	TATA spare parts
570107994201	CLAMP INJECTOR	TATA spare parts
570107994202	CLIP	TATA spare parts
570107994203	CLIP	TATA spare parts
570107994203AE	CLIP 1628	TATA spare parts
570107995401	GEAR FUEL PUMP BS6	TATA spare parts
570107996804	CONNECTOR QCK DISCONNECT	TATA spare parts
570107996901	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
570107996901AE	TUBE INJECTOR FUEL SUPPLY 1628	TATA spare parts
570107996902	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
570107996903	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
570107996903AE	TUBE INJECTOR FUEL SUPPLY 1628	TATA spare parts
570107996904	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
570107996905	TUBE FUEL DRAIN BS3/4	TATA spare parts
570107996905AE	TUBE FUEL DRAIN 1628	TATA spare parts
570107996912	TUBE FUEL SUPPLY	TATA spare parts
570107996912AE	TUBE FUEL SUPPLY 1628	TATA spare parts
570107996913	TUBE FUEL SUPPLY	TATA spare parts
570107996914	TUBE FUEL SUPPLY	TATA spare parts
570107996915	TUBE FUEL DRAIN	TATA spare parts
570107996916	TUBE FUEL SUPPLY	TATA spare parts
570107996917	TUBE FUEL SUPPLY	TATA spare parts
570107996918	TUBE FUEL SUPPLY	TATA spare parts
570107996919	TUBE FUEL SUPPLY	TATA spare parts
570107996920	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
570107996921	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
570107996922	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
570107996923	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
570107996924	TUBE FUEL SUPPLY	TATA spare parts
570107996927	TUBE FUEL SUPPLY	TATA spare parts
570107996928	TUBE FUEL SUPPLY	TATA spare parts
570107996929	TUBE FUEL SUPPLY	TATA spare parts
570107996930	TUBE FUEL SUPPLY	TATA spare parts
570107996931	TUBE FUEL SUPPLY	TATA spare parts
570107996933	TUBE INJECTOR FUEL SUPPLY BS6	TATA spare parts
570107996935	TUBE INJECTOR FUEL SUPPLY BS6	TATA spare parts
570107996936	TUBE INJECTOR FUEL SUPPLY BS6	TATA spare parts
570107996937	TUBE INJECTOR FUEL SUPPLY BS6	TATA spare parts
570107996939	TUBE INJECTOR FUEL SUPPLY BS6	TATA spare parts
570107996940	TUBE INJECTOR FUEL SUPPLY BS6	TATA spare parts
570107996941	TUBE FUEL DRAIN BS6	TATA spare parts
570107996942	TUBE FUEL SUPPLY BS6	TATA spare parts
570107996943	TUBE FUEL SUPPLY BS6	TATA spare parts
570107996944	BRACE TUBE BS6	TATA spare parts
570107996945	TUBE FUEL DRAIN BS6	TATA spare parts
570107996946	TUBE FUEL SUPPLY BS6-PH2	TATA spare parts
570107996947	TUBE FUEL SUPPLY BS6-PH2	TATA spare parts

570107996948	TUBE FUEL DRAIN BS6-PH2	TATA spare parts
570107996949	TUBE INJECTOR FUEL SUPPLY BS6-PH2	TATA spare parts
570107996950	TUBE FUEL DRAIN BS6-PH2	TATA spare parts
570107996951	TUBE FUEL DRAIN BS6-PH2	TATA spare parts
570107998801	SCREW STUDED FLANGE CAP BS4	TATA spare parts
570107998802	STUD	TATA spare parts
570107998803	STUD DOUBLE END PLAIN BS6	TATA spare parts
570107999201	WASHER SEALING	TATA spare parts
570107999801	FUEL FILTER HEAD	TATA spare parts
570107999802	CONNECTOR QCK DISCONNECT	TATA spare parts
570107999803	CONNECTOR QCK DISCONNECT BS6	TATA spare parts
570107999804	MANIFOLD FUEL BS6	TATA spare parts
570107999808	VALVE CHECK BS6	TATA spare parts
570107999809	CONNECTOR QUICK CONNECT BS6	TATA spare parts
570107999810	ACCUMULATOR BS6-PH2	TATA spare parts
570107999901	FUEL FILTER ELEMENT SPINON BS3/4	TATA spare parts
570107999901AE	ASSY FUEL FLTR -1628-1828	TATA spare parts
570107999903	GASKET COVER PLATE	TATA spare parts
570107999904	ASSY FUEL FILTER	TATA spare parts
570107999907	INJECTOR CRIN1.6 BS3/4	TATA spare parts
570107999907AE	INJECTOR 1628 1828	TATA spare parts
570107999908	CONNECTOR INJ FUEL SUPPLY	TATA spare parts
570107999908AE	CONNECTOR INJ FUEL SUPPLY 1628	TATA spare parts
570107999909	INJECTOR CRIN3	TATA spare parts
570107999910	HIGH PRESSURE CONNECTOR BS4	TATA spare parts
570107999911	CONNECTOR QCK DISCONNECT	TATA spare parts
570107999913	CONNECTOR QCK DISCONNECT	TATA spare parts
570107999915	RETAINER INJ FUL SUP	TATA spare parts
570107999928	ADAPTER FUEL CONNECTOR ASSY	TATA spare parts
570107999931	BRACE TUBE	TATA spare parts
570107999931AE	BRACE TUBE 1628	TATA spare parts
570107999932	CONNECTOR QCK DISCONNECT	TATA spare parts
570107999932AE	CONNECTOR QCK DISCONNECT 1628	TATA spare parts
570107999935	ADAPTER FUEL CONNECTOR	TATA spare parts
570107999936	CONNECTOR QCK DISCONNECT	TATA spare parts
570107999938	ADAPTER FUEL CONNECTOR	TATA spare parts
570107999939	HEAD FUEL FILTER	TATA spare parts
570107999941	PRESSURE REGULATOR (M PROP)	TATA spare parts
570107999956	INJECTOR ISBE6.7 BS4	TATA spare parts
570107999957	PUMP FUEL INJECTION	TATA spare parts
570109130108	CLEAN AIR DUCT ASSY.	TATA spare parts
570109130120	AIR FILTER FOR MPV	TATA spare parts
570109130135	AIR INTAKE SYSTEM	TATA spare parts
570109130137	ASSY CLAMP (FOR CLEAN DUCT MTG)	TATA spare parts
570109130138	ASSY PIPE (CLEAN SIDE)	TATA spare parts
570109130139	ASSY BRACKET	TATA spare parts
570109130143	SET AIR INTAKE SYSTEM	TATA spare parts

570109130144	ASSY. BRACKET ( AIR FILTER MTG.)	TATA spare parts
570109130147	ASSY. BRACKET(SNORKEL MTG. TOP)	TATA spare parts
570109130148	ASSY. RUBBER BUFFER	TATA spare parts
570109130155	ASSY AIR FILTER (LPTA 1628)	TATA spare parts
570109130159	ASSY PIPE ( SNORKEL TO AF)	TATA spare parts
570109130160	ASSY. PIPE (AF TO TC)	TATA spare parts
570109130163	ASSY PRECLEANER-MPV	TATA spare parts
570109130167	ASSY. BRACKET ( PIPE SUPPORT)	TATA spare parts
570109130168	ASSY. AIR FILTER (LPO1925 LF HYBRID BUS)	TATA spare parts
570109130169	ASSY. BRACKET ( AIR FILTER SUPPORT)	TATA spare parts
570109130171	ASSY PIPE (CLEAN SIDE)	TATA spare parts
570109130172	ASSY PIPE (CLEAN SIDE)	TATA spare parts
570109130173	ASSY. BRACKET SNORKEL MTG.	TATA spare parts
570109130175	ASSY. BKT ( AIR FILTER MTG)-MPV	TATA spare parts
570109130178	ASSY STRAP FOR AIR FILTER-MPV	TATA spare parts
570109130180	ASLY STRAP FOR PRECLEANER-MPV WITH SHACK	TATA spare parts
570109130182	ASLY STRAP FOR AIR FILTER-MPV¿ WITH SHAC	TATA spare parts
570109130185	ASSY.SUPPORT BKT BACK SIDE(AIR FILTER TO	TATA spare parts
570109130186	ASLY BRACKET( AIR FILTER TO TC PIPE SUPP	TATA spare parts
570109130188	ASLY.AIR FILTER-FLEETGUARD FOR MPV	TATA spare parts
570109130190	ASSY SUPPORT BRACKET (AIR FILTER TO TC P	TATA spare parts
570109130194	SNORKEL MTG BKT TOP (RH) LPTA1628 LHD	TATA spare parts
570109130195	AIR FILTER MOUNTING BRACKET	TATA spare parts
570109130199	ASSY BRACKET ( AIR FILTER MTG.)	TATA spare parts
570109130201	ASSY BRACKET ( AIR FILTER MTG.)2523.K	TATA spare parts
570109130207	ASLY AIR FILTER 4023.S	TATA spare parts
570109130208	CLEAN SIDE DUCT ASSEMBLY	TATA spare parts
570109130209	AIR FILTER MTG BKT MO	TATA spare parts
570109130212	DAMPER ASSY	TATA spare parts
570109130215	GRID ASSY AIR FILTER (M & H) BS6	TATA spare parts
570109130217	ASSY AIR FILTER LOWER HALF	TATA spare parts
570109130218	BRACKET ASSEMBLY	TATA spare parts
570109130220	ASSY DUCT AIR INTAKE	TATA spare parts
570109130221	ASSY BRACKET PIPE SUPPORT	TATA spare parts
570109130222	ASSY BRACKET	TATA spare parts
570109130223	ASSY BRACKET PIPE SUPPORT	TATA spare parts
570109130224	ASSY PIPE	TATA spare parts
570109130225	ASSY PIPE	TATA spare parts
570109130226	ISOLATOR VIBRATION	TATA spare parts
570109130227	ASSY. AIR CLEANER BS3/4	TATA spare parts
570109130229	ASSY PIPE	TATA spare parts
570109130231	BRACKET ASY	TATA spare parts
570109130232	SET AIR INTAKE SYSTEM -3128.K/2528.K	TATA spare parts
570109130245	SET-AIR INTAKE SYSTEM	TATA spare parts
570109130258	AIR FILTER ASSY	TATA spare parts
570109130259	BRACKET ASSY	TATA spare parts
570109130260	AIR INTAKE SYSTEM ASSY	TATA spare parts

570109130261	AIR INTAKE PIPE	TATA spare parts
570109130264	AIR INTAKE SYSTEM ASSY	TATA spare parts
570109130269	ISOLATOR VIBRATION ASSY	TATA spare parts
570109130284	DUCT AIR FILTER TO TC BS6	TATA spare parts
570109130285	KIT-AIR INTAKE SYSTEMBS6	TATA spare parts
570109130287	KIT-AIR INTAKE SYSTEM BS6	TATA spare parts
570109130289	PIPE AIR FILTER TO TC BS6	TATA spare parts
570109130292	PIPE ASSY WITH BRACKET FILTER TO ELBOW B	TATA spare parts
570109130295	KIT-AIR INTAKE ASSY BS6	TATA spare parts
570109130296	KIT-AIR INTAKE ASSY BS6	TATA spare parts
570109130303	BRACKET CLEAN SIDE PIPE SUPPORT BS6	TATA spare parts
570109130304	CLAMP ASSY WITH RUBBER BS6	TATA spare parts
570109130307	KIT-AIR INTAKE ASSY BS6	TATA spare parts
570109130314	AIR FILTER ASSY BS6	TATA spare parts
570109130315	BRACKET ASSY SNORKEL MTG BS6	TATA spare parts
570109130316	BRACKET ASSY SNORKEL MTG BS6	TATA spare parts
570109130317	KIT-AIR INTAKE SYSTEM BS6	TATA spare parts
570109130318	AIR FILTER ASSY WITH BRACKET BS6	TATA spare parts
570109130319	AIR CLEANER ASSY BS6	TATA spare parts
570109130320	DUCT ASSY AIR INTAKE SYSTEM BS6	TATA spare parts
570109130324	AIR INTAKE PIPE ASSY A/F TO T/C BS6	TATA spare parts
570109130325	HEX HEAD BOLT BS6	TATA spare parts
570109130326	BRACKET ASSY AIR FILTER MTG BS6	TATA spare parts
570109130327	BRACKET ASSY AIR FILTER MTG BS6	TATA spare parts
570109130328	BRACKET DUCT MTG BS6	TATA spare parts
570109130329	BRACKET CLEAN SIDE PIPE SUPPORT BS6	TATA spare parts
570109130332	BRACKET CLEAN SIDE PIPE SUPPORT BS6	TATA spare parts
570109130333	DAMPER ASSY BS6	TATA spare parts
570109130334	BRACKET ASSY BS6	TATA spare parts
570109130337	KIT-AIR INTAKE ASSY BS6	TATA spare parts
570109130339	BRACKET CLEAN SIDE PIPE SUPPORT BS6	TATA spare parts
570109130344	PIPE ASSY BS6	TATA spare parts
570109130345	HOUSING ASSY BS6	TATA spare parts
570109130347	DUCT ASSY BS6	TATA spare parts
570109130355	DAMPER ASSY BS6	TATA spare parts
570109130356	BRACKET ASSY BS6	TATA spare parts
570109130358	KIT-AIR INTAKE SYSTEM BS6	TATA spare parts
570109130360	AIR DUCT ASSY CLEAN BS6-PH2	TATA spare parts
570109130361	KIT-AIR INTAKE SYSTEM BS6	TATA spare parts
570109130362	AIR DUCT ASSY DIRTY BS6	TATA spare parts
570109130369	AIR FILTER ASSY W/O BRACKET BS6	TATA spare parts
570109130370	PIPE ASSY AIR FILTER OUTLET BS6	TATA spare parts
570109130371	PIPE ASSY INTERMEDIATE BS6	TATA spare parts
570109130372	PIPE ASSY TC INTAKE BS6	TATA spare parts
570109130374	DAMPER ASSY BS6	TATA spare parts
570109130375	AIR FILTER HOUSING ASSY TOP BS6	TATA spare parts
570109130376	AIR FILTER HOUSING ASSY BOTTOM BS6	TATA spare parts



570109130377	PIPE ASSY TC INTAKE BS6	TATA spare parts
570109130385	AIR DUCT ASSY DIRTY BS6	TATA spare parts
570109130386	AIR DUCT ASSY CLEAN BS6	TATA spare parts
570109130387	AIR DUCT ASSY CLEAN BS6 PH2	TATA spare parts
570109130388	BRACKET WITH FASTENERS BS6-PH2	TATA spare parts
570109130389	BRACKET WITH FASTENERS BS6	TATA spare parts
570109130392	BRACKET ASSY BS6	TATA spare parts
570109130393	AIR DUCT ASSY DIRTY BS6	TATA spare parts
570109130394	AIR CLEANER ASSY WITH MTG BRACKET BS6	TATA spare parts
570109130395	AIR DUCT ASSY CLEAN BS6	TATA spare parts
570109130397	BRACKET ASSY BS6-PH2	TATA spare parts
570109130398	BRACKET ASSY BS6	TATA spare parts
570109133306	BRACKET( SNORKEL MTG.)	TATA spare parts
570109133314	PLATE (AIR FILTER MTG)-M0	TATA spare parts
570109133316	BRACKET(AF TO TC PIPE SUPPORT)	TATA spare parts
570109133320	BRACKET PIPE SUPPORT TC SIDE MPV LHD	TATA spare parts
570109133322	BRACKET ASSY	TATA spare parts
570109133323	SUPPORT BRACKET	TATA spare parts
570109133324	BRACKET BS6	TATA spare parts
570109133328	BRACKET AIR FILTER MTG BS6	TATA spare parts
570109133329	BRACKET BS6	TATA spare parts
570109133330	BRACKET CLEAN SIDE PIPE SUPPORT BS6	TATA spare parts
570109133331	BRACKET CLEAN SIDE PIPE SUPPORT BS6	TATA spare parts
570109133332	BRACKET CLEAN SIDE PIPE SUPPORT BS6	TATA spare parts
570109133334	BRACKET ASSY BS6	TATA spare parts
570109134203	HOSE CLAMP (120 ID)	TATA spare parts
570109134204	HOSE CLAMP (190 ID)	TATA spare parts
570109134206	HOSE CLAMP (MANN & HUMMEL)	TATA spare parts
570109134207	HOSE CLAMP T BOLT	TATA spare parts
570109134208	HOSE CLAMP SLTB 232	TATA spare parts
570109134209	CLAMP	TATA spare parts
570109134210	CLAMP AIR FILTER BS6	TATA spare parts
570109134211	CLAMP AIR INTAKE PIPE BS6	TATA spare parts
570109134212	CLAMP HOSE BS6	TATA spare parts
570109134214	CLAMP HOSE BS6	TATA spare parts
570109134215	CLAMP HOSE BS6	TATA spare parts
570109134216	CLAMP HOSE BS6	TATA spare parts
570109135812	HOSE (AIR FILTER TO TC)-MPV	TATA spare parts
570109135814	REDUCER HOSE (AIS)(153 ID X 102 ID)	TATA spare parts
570109135816	HOSE ELBOW ( 140X102 DIA)	TATA spare parts
570109135817	HOSE (PRECLEANER TO AIR FILTER) ID 153MM	TATA spare parts
570109135818	HOSE AIR FILTER TO SNORKEL BS6	TATA spare parts
570109135836	HOSE (ENG TO RAD-ID44)	TATA spare parts
570109135841	HOSE (AIR FILTER OUTLET )4023.S	TATA spare parts
570109135842	HOSE	TATA spare parts
570109135843	HOSE HUMP	TATA spare parts
570109135844	HOSE REDUCER DEGREE	TATA spare parts

570109135845	HOSE HUMP	TATA spare parts
570109135846	REDUCER HOSE	TATA spare parts
570109135848	HOSE(PRECLN TO FLT MPV_LHD_EXISTING	TATA spare parts
570109135850	HOSE (PRECLN TO FORNT BONNET FACE)	TATA spare parts
570109135860	HOSE ELBOW BS6	TATA spare parts
570109135870	HOSE HUMP BS6	TATA spare parts
570109135871	HOSE REDUCER BS6	TATA spare parts
570109135875	HOSE REDUCER AIR FILTER BS6	TATA spare parts
570109135877	HOSE HUMP BS6	TATA spare parts
570109135878	HOSE REDUCER BS6	TATA spare parts
570109135881	HOSE ASSY BS6-PH2	TATA spare parts
570109135882	HOSE REDUCER BS6-PH2	TATA spare parts
570109135883	SLEEVE BS6-PH2	TATA spare parts
570109136302	PIPE AIR FILTER TO TC BS6	TATA spare parts
570109136308	RAIN HOOD SNORKEL BS6-PH2	TATA spare parts
570109136903	PIPE - CLEAN AIR DUCT	TATA spare parts
570109136909	PIPE (AIR FILTER TO TC)-MPV	TATA spare parts
570109136919	PIPE (AIR FILTER TO TC) (LPTA 1628 LHD)	TATA spare parts
570109136923	DUCT (AIR FILTER TO TC)-4023.S	TATA spare parts
570109136925	PIPE (ON AIR FILTER OUTLET)	TATA spare parts
570109136930	PIPE AIR INTAKE -TC SIDE MPV LHD	TATA spare parts
570109136931	PIPE ASSY AIR INTAKE FILTER SIDE MPV LHD	TATA spare parts
570109136934	AIR INTAKE PIPE	TATA spare parts
570109136943	PIPE ASSY AIR FILTER TO TC BS6	TATA spare parts
570109136944	PIPE ASSY BS6	TATA spare parts
570109136945	PIPE ASSY BS6	TATA spare parts
570109136950	PIPE ASSY BS6-PH2	TATA spare parts
570109136951	PIPE ASSY BS6-PH2	TATA spare parts
570109136952	PIPE BS6-PH2	TATA spare parts
570109137707	RUBBER BUSH BS6	TATA spare parts
570109137708	BUSH BS6	TATA spare parts
570109137709	GASKET AIR FILTER BODY BS6	TATA spare parts
570109137712	SEAL RING BS6	TATA spare parts
570109137714	VALVE AND DEFLECTOR BS6	TATA spare parts
570109138201	GUIDE RING ( FOR PRECLEANER)-MPV	TATA spare parts
570109139901	HEXAGON ROD	TATA spare parts
570109139902	HEXAGON ROD-SMALL	TATA spare parts
570109139906	RESTRICTION INDICATOR ASSY BS6	TATA spare parts
570109139907	AIR FILTER ELEMENT (SECONDARY) BS6	TATA spare parts
570109139908	AIR FILTER ELEMENT (PRIMARY) BS6	TATA spare parts
570109139909	RESTRICTION INDICATOR BS6-PH2	TATA spare parts
570109139910	AIR FILTER PRIMARY ELEMENT BS6	TATA spare parts
570109139911	AIR FILTER SECONDARY ELEMENTBS6	TATA spare parts
570109140111	COVER ASSY BOTTOM BS6	TATA spare parts
570109140113	PIPE ASSY BS6-PH2	TATA spare parts
570109140114	BRACKET ASSY BS6-PH2	TATA spare parts
570109140115	AIR CLEANER ASSY BS6-PH2	TATA spare parts

570109140116	BRACKET ASSY BS6-PH2	TATA spare parts
570109140117	BRACKET ASSY BS6-PH2	TATA spare parts
570109140118	BRACKET ASSY BS6-PH2	TATA spare parts
570109140119	DUCT ASSY AIR INTAKE SYSTEM BS6-PH2	TATA spare parts
570109140120	PIPE ASSY BS6-PH2	TATA spare parts
570109140121	PIPE ASSY BS6-PH2	TATA spare parts
570109140124	BRACKET ASSY BS6-PH2	TATA spare parts
570109140125	AIR CLEANER ASSY BS6-PH2	TATA spare parts
570109140126	DUCT ASSY AIR INTAKE SYSTEM BS6-PH2	TATA spare parts
570109140141	BRACKET ASSY BS6-PH2	TATA spare parts
570109140153	BRACKET ASSY BS6-PH2	TATA spare parts
570109140154	AIR CLEANER ASSY BS6-PH2	TATA spare parts
570109140164	BRACKET ASSY BS6-PH2	TATA spare parts
570109990101	RETROFITMENT KIT (AIR INTAKE SYSTEM)	TATA spare parts
570109994201	CLAMP V BAND	TATA spare parts
570109994204	CLAMP V BAND BS6	TATA spare parts
570109996901	PIPE AIR TRANSFER	TATA spare parts
570109996902	PIPE AIR TRANSFER	TATA spare parts
570109996902AE	PIPE AIR TRANSFER 1628	TATA spare parts
570109996905	PIPE AIR TRANSFER BS6	TATA spare parts
570109997701	SEAL O RING	TATA spare parts
570109999801	CONNECTOR QCK DISCONNECT BS6	TATA spare parts
570109999803	CONNECTOR QCK DISCONNECT BS6	TATA spare parts
570109999804	CONNECTION AIR TRANSFER BS6	TATA spare parts
570109999805	CONNECTOR QCK DISCONNECT BS6	TATA spare parts
570109999810	HEAD FUEL FILTER BS6	TATA spare parts
570109999811	CONNECTION AIR TRANSFER BS6	TATA spare parts
570113103102	BRACKET ASSY AIR COMPRESSOR PIPE SUPPORT	TATA spare parts
570113103103	BRACKET AIR COMPRESSOR PIPE MTG BS6	TATA spare parts
570113130101	ASSY TUBE WITH FERRULE & CAP NUT	TATA spare parts
570113130102	ASSY TUBE WITH FERRULE & CAP NUT	TATA spare parts
570113130103	ASSY PIPE	TATA spare parts
570113130110	ASSY TUBE WITH FERRULE & CAP NUT (AF SID	TATA spare parts
570113130111	ASSY TUBE WITH FERRULE & CAP NUT (ENG SI	TATA spare parts
570113130113	ASSY. PIPE (COMP & AIRFILTER)	TATA spare parts
570113130114	ASSY - AIR COMPRESSOR PIPING	TATA spare parts
570113130117	ASSY - AIR COMPRESSOR PIPING	TATA spare parts
570113130117AE	ASSY AIR CMPRSR PIPING-1628-1828	TATA spare parts
570113130118	ASSY - AIR COMPRESSOR PIPING	TATA spare parts
570113130123	PIPE ASSY WITH FERRULE & CAP NUT	TATA spare parts
570113130125	PIPE ASSY WITH CRIMPED HOSE AIR COMP BS6	TATA spare parts
570113130128	PIPE ASSY WITH CRIMPED HOSE AIR COMP BS6	TATA spare parts
570113130129	PIPE ASSY WITH CRIMPED HOSE AIR COMP BS6	TATA spare parts
570113130131	PIPE ASSY WITH CRIMPED HOSE AIR COMP BS6	TATA spare parts
570113130137	PIPE ASSY WITH CRIMPED HOSE AIR COMP BS6	TATA spare parts
570113130142	PIPE ASSY WITH CRIMPED HOSE AIR COMP BS6	TATA spare parts
570113130144	PIPE ASSY WITH CRIMPED HOSE AIR COMP BS6	TATA spare parts

570113135801	HOSE (AIR COMPRESSOR 21 ID 370L) - LPS 4	TATA spare parts
570113135803	HOSE ( AIR COMPRESSOR)	TATA spare parts
570113135803AE	HOSE ( AIR COMPRESSOR) 1628	TATA spare parts
570113135804	HOSE	TATA spare parts
570113135808	HOSE AIR INTAKE TO AIR COMP PIPE MPV LHD	TATA spare parts
570113135811	HOSE AIR COMPRESSOR BS6	TATA spare parts
570113135816	HOSE BS6	TATA spare parts
570113135817	HOSE BS6	TATA spare parts
570113136801	COUPLING BODY (3/4IN NPTF X M30X2)	TATA spare parts
570113136801AE	"COUPLING BODY(3/4"" NPTF)-1628"	TATA spare parts
570113136802	COUPLING BODY (3/4INC NPTF)-MPV	TATA spare parts
570113136803	COUPLING BODY BS6	TATA spare parts
570113990101	COMPRESSOR AIR	TATA spare parts
570113990106	AIR COMPRESSOR	TATA spare parts
570113990115	AIR COMPRESSOR BS6	TATA spare parts
570113990116	AIR COMPRESSOR ASSY BS6	TATA spare parts
570113993301	BRACE BRACKET BS6	TATA spare parts
570113993302	BRACE TUBE BS6-PH2	TATA spare parts
570113993401	BUSHING REDUCING PIPE BS6-PH2	TATA spare parts
570113994201	CLIP	TATA spare parts
570113994201AE	CLIP 1628	TATA spare parts
570113994202	CLIP	TATA spare parts
570113995401	GEAR ACCESSORY DRIVE	TATA spare parts
570113996501	NUT REGULAR HEXAGON	TATA spare parts
570113996502	NUT	TATA spare parts
570113996901	TUBE CPR WATER OUTLET	TATA spare parts
570113996902	TUBE CPR WATER OUTLE	TATA spare parts
570113996903	TUBE CPR WATER INLET	TATA spare parts
570113996904	TUBE CPR WATER INLET	TATA spare parts
570113996905	TUBE CPR WATER OUTLET	TATA spare parts
570113996906	TUBE CPR WATER OUTLET	TATA spare parts
570113996906AE	TUBE CPR WATER OUTLET 1628	TATA spare parts
570113996907	TUBE CPR WATER OUTLET	TATA spare parts
570113996911	TUBE CPR WATER INLET BS6	TATA spare parts
570113996912	TUBE CPR WATER OUTLET BS6	TATA spare parts
570113996913	TUBE CPR WATER OUTLET BS6	TATA spare parts
570113996914	TUBE CPR WATER OUTLET BS6	TATA spare parts
570113996915	TUBE CPR WATER OUTLET BS6	TATA spare parts
570113996916	TUBE CPR WATER OUTLET BS6	TATA spare parts
570113996917	TUBE CPR WATER OUTLET BS6-PH2	TATA spare parts
570113996918	TUBE CPR WATER OUTLET BS6-PH2	TATA spare parts
570113996919	TUBE CPR WATER INLET BS6-PH2	TATA spare parts
570113997201	PLUG FLANGED O RING BS6	TATA spare parts
570113997701	SEAL O RING	TATA spare parts
570113997702	SEAL GROMMET	TATA spare parts
570113997703	SEAL O RING	TATA spare parts
570113997704	SEAL O RING	TATA spare parts

570113997705	SEAL RECTANGULAR RING	TATA spare parts
570113998601	SPACER MOUNTING	TATA spare parts
570113999801	ELBOW TUBE CONNECTOR BS6	TATA spare parts
570113999901	BRACE AIR COMPRESSOR	TATA spare parts
570113999901AE	BRACE AIR COMPRESSOR 1628 1828	TATA spare parts
570113999907	CONNECTOR QCK DISCONNECT	TATA spare parts
570113999908	CONNECTOR MALE	TATA spare parts
570113999910	CONNECTOR QCK DISCONNECT BS4	TATA spare parts
570114110103	ASSY UREA DOSING PUMP	TATA spare parts
570114110104	ASSY UREA SPRAY NOZZLE	TATA spare parts
570114110105	TEMPERATURE SENSOR	TATA spare parts
570114110106	TEMPERATURE SENSOR	TATA spare parts
570114110107	NOX SENSOR (24V) BS4	TATA spare parts
570114110108	SET AFTER TREATMENT SYSTEM (LPO 1621TC)	TATA spare parts
570114110109	EXHAUST GAS PROCESSOR (LPO 1621TC) END I	TATA spare parts
570114110111	EXHAUST GAS PROCESSOR BS4	TATA spare parts
570114110113	EXHAUST GAS PROCESSOR	TATA spare parts
570114110116	EXHAUST GAS PROCESSOR	TATA spare parts
570114110143	DP SENSOR SENSING (OUTLET) BS6 (6.7/F)	TATA spare parts
570114110144	DP SENSOR SENSING (INLET) BS6 (6.7/F)	TATA spare parts
570114110146	MODULE DPF CATALYST BS6 (6.7/V) BS6	TATA spare parts
570114110148	MODULE SCR OUTLET BS6 (6.7/H) BS6	TATA spare parts
570114110149	CLAMP BAND BS6	TATA spare parts
570114110160	HEX FLANGE BOLT BS6	TATA spare parts
570114110165	MODULE DOC INLET BS6 (6.7/V) BS6	TATA spare parts
570114110166	MODULE DPF CATALYST BS6 (6.7/H) BS6	TATA spare parts
570114110167	MODULE SCR OUTLET BS6 (6.7/V) BS6	TATA spare parts
570114110169	WIRING HARNESS BS6 (5.6/6.7/F)	TATA spare parts
570114110170	MIXER DEF BS6 (5.6/6.7/F) BS6	TATA spare parts
570114110171	MODULE SCR OUTLET BS6 (6.7/F) BS6	TATA spare parts
570114110172	MODULE DPF CATALYST BS6 (6.7/F) BS6	TATA spare parts
570114110173	MODULE DOC INLET BS6 (6.7/F) BS6	TATA spare parts
570114110174	PLATE ASSY BS6 (5.6/6.7/F)	TATA spare parts
570114110177	NOX SENSOR BS6 (5.6/6.7/H/F)	TATA spare parts
570114110179	MODULE DOC INLET BS6 (6.7/V) BS6	TATA spare parts
570114110183	GASKET CIRCULAR (5.6/6.7/F) BS6	TATA spare parts
570114110185	NOX SENSOR BS6	TATA spare parts
570114110189	CONDUIT ELECTRICAL BS6	TATA spare parts
570114110192	CONDUIT ELECTRICAL BS6	TATA spare parts
570114110194	NOX SENSOR ASSY	TATA spare parts
570114110195	NOZZLE ASSY UREA SPRAY	TATA spare parts
570114110206	PRESSURE DIFFERENCE SENSOR ASSY BS6	TATA spare parts
570114110207	PRESSURE DIFFERENCE SENSOR ASSY BS6	TATA spare parts
570114110214	BRACKET SENSOR SUPPORT BS6	TATA spare parts
570114110215	BRACKET SENSOR SUPPORT BS6	TATA spare parts
570114110216	BRACKET SENSOR SUPPORT BS6	TATA spare parts
570114110224	MODULE DOC INLET BS6-PH2	TATA spare parts

570114110225	MODULE SCR OUTLET BS6-PH2	TATA spare parts
570114110226	DP SENSOR INLET LINE ASSY BS6-PH2	TATA spare parts
570114110227	MODULE PRESSURE SENSING BS6-PH2	TATA spare parts
570114110228	MODULE PRESSURE SENSING BS6-PH2	TATA spare parts
570114110229	SENSOR TEMPERATURE BS6-PH2	TATA spare parts
570114110230	WIRING HARNESS BS6-PH2	TATA spare parts
570114110232	CONDUIT ELECTRICAL BS6-PH2	TATA spare parts
570114110233	CONDUIT ELECTRICAL BS6-PH2	TATA spare parts
570114110235	MODULE DPF CATALYST BS6-PH2	TATA spare parts
570114110236	MODULE SCR OUTLET BS6-PH2	TATA spare parts
570114110239	PRESSURE DIFFERENCE SENSOR ASSY - HORIZO	TATA spare parts
570114110240	PRESSURE DIFFERENCE SENSOR ASSY - HORIZO	TATA spare parts
570114110241	HARNESS WIRING BS6-PH2	TATA spare parts
570114110242	BRACKET WIRE SUPPORT BS6-PH2	TATA spare parts
570114110244	MODULE DPF CATALYST BS6-PH2	TATA spare parts
570114110247	BRACKET SENSOR MTG BS6	TATA spare parts
570114110248	BRACKET SENSOR SUPPORT BS6-PH2	TATA spare parts
570114110250	MODULE PRESSURE SENSING BS6-PH2	TATA spare parts
570114110251	MODULE PRESSURE SENSING BS6-PH2	TATA spare parts
570114110252	HARNESS WIRING BS6-PH2	TATA spare parts
570114110253	CONDUIT ELECTRICAL BS6-PH2	TATA spare parts
570114110254	CONDUIT ELECTRICAL BS6-PH2	TATA spare parts
570114110255	NOX SENSOR ASSY BS6	TATA spare parts
570114110273	MODULE DOC INLET BS6-PH2	TATA spare parts
570114110274	MODULE SCR OUTLET BS6-PH2	TATA spare parts
570114110275	MIXER DIESEL EXHAUST FLUID BS6-PH2	TATA spare parts
570114110276	MIXER DIESEL EXHAUST FLUID	TATA spare parts
570114110277	TEMPERATURE SENSOR ASSY BS6-PH2	TATA spare parts
570114110278	SUBMODULE DECOMPOSITION REACTOR BS6-PH2	TATA spare parts
570114110279	BRACKET SENSOR SUPPORT BS6-PH2	TATA spare parts
570114110280	MODULE DOC INLET BS6-PH2	TATA spare parts
570114116501	NOZZLE RETAINER NUT	TATA spare parts
570114119901	TEMPERATURE SENSOR BS4	TATA spare parts
570114600103	ASSY PIPE (IC TO ENGINE) 4023.S	TATA spare parts
570114600105	PIPE INTERCOOLER TO ENGINE	TATA spare parts
570114600106	PIPE INTERCOOLER TO TURBOCHARGER	TATA spare parts
570114600107	PIPE ASSY	TATA spare parts
570114603303	BRACKET (TC TO IC PIPE SUPPORT)	TATA spare parts
570114603308	BRACKET (TC TO IC PIPE SUPPORT)	TATA spare parts
570114603309	BRACKET (TC TO IC PIPE SUPPORT)	TATA spare parts
570114603310	BRACKET ( PIPE TC TO IC)	TATA spare parts
570114603311	BRACKET IC TO ENGINE PIPE SUPPORT	TATA spare parts
570114603314	BRACKET (TC TO IC PIPE SUPPORT)	TATA spare parts
570114603317	SUPPORT BRACKET	TATA spare parts
570114603320	SUPPORT BRACKET TC PIPE TO INTERCOOLER B	TATA spare parts
570114603327	SUPPORT BRACKET TC PIPE TO INTERCOOLER B	TATA spare parts
570114605801	HOSE HUMP	TATA spare parts

570114605803	HOSE HUMP BS6	TATA spare parts
570114606901	PIPE (IC TO ENGINE)	TATA spare parts
570114606902	PIPE (TC TO IC)	TATA spare parts
570114606907	PIPE ( TC TO IC )	TATA spare parts
570114606911	PIPE (TC TO IC)	TATA spare parts
570114606912	PIPE (MPV)	TATA spare parts
570114606914	PIPE (IC TO ENG)	TATA spare parts
570114606915	PIPE (TC TO IC)	TATA spare parts
570114606916	PIPE (IC TO ENG)	TATA spare parts
570114606918	PIPE (IC TO ENGINE)	TATA spare parts
570114606919	PIPE ( TC TO INTERCOOLER)	TATA spare parts
570114606922	PIPE ( TC TO IC)-MPV	TATA spare parts
570114606924	PIPE (TC TO IC) 4023.S	TATA spare parts
570114606929	PIPE ASSY IC TO ELBOW AIR INTAKE	TATA spare parts
570114606934	PIPE	TATA spare parts
570114606936	PIPE ENGINE TO INTERCOOLER	TATA spare parts
570114606940	PIPE TC TO IC BS6	TATA spare parts
570114606944	PIPE TC TO INTERCOOLER	TATA spare parts
570114606946	PIPE IC OUT TO AIR INTAKE ELBOW BS6	TATA spare parts
570114606947	PIPE TC TO IC BS6	TATA spare parts
570114609908	INTERCOOLER (LPTA1628 LHD)	TATA spare parts
570114609908AE	INTERCOOLER 1828	TATA spare parts
570114609909	ASSY INTERCOOLER	TATA spare parts
570114609911	INTERCOOLER (4023.S)	TATA spare parts
570114609912	INTERCOOLER	TATA spare parts
570114990102	BRACKET EXH CONNECTION	TATA spare parts
570114990109	TURBOCHARGER	TATA spare parts
570114990113	TURBO CHARGER	TATA spare parts
570114990115	TURBOCHARGER	TATA spare parts
570114990118	TURBOCHARGER	TATA spare parts
570114990119	TURBOCHARGER	TATA spare parts
570114990126	TURBOCHARGER	TATA spare parts
570114990127	TURBOCHARGER	TATA spare parts
570114990137	TURBOCHARGER BS6	TATA spare parts
570114990138	AFTER TREATMENT SYSTEM ASSY BS6 (6.7/F)	TATA spare parts
570114990139	AFTER TREATMENT SYSTEM ASSY BS6 (6.7/F)	TATA spare parts
570114990140	AFTER TREATMENT SYSTEM ASSY BS6 (6.7/V)	TATA spare parts
570114990141	AFTER TREATMENT SYSTEM ASSY BS6 (6.7/V)	TATA spare parts
570114990145	AFTER TREATMENT SYSTEM ASSY BS6	TATA spare parts
570114990146	AFTER TREATMENT SYSTEM BS6-PH2 (6.7/H/T)	TATA spare parts
570114990147	AFTER TREATMENT SYSTEM BS6-PH2 (6.7/H/S)	TATA spare parts
570114990148	AFTER TREATMENT SYSTEM BS6-PH2 (6.7/V/K)	TATA spare parts
570114990149	DEF QUALITY CHECK-HANNA TOOL	TATA spare parts
570114993302	BRACKET EXH CONNECTION BS6	TATA spare parts
570114993303	BRACKET EXH CONNECTION BS6	TATA spare parts
570114993304	BRACKET EXH CONNECTION BS6	TATA spare parts
570114993307	BRACE BRACKET BS6	TATA spare parts

570114993308	BRACKET EXHAUST OUTLET BS6	TATA spare parts
570114993309	BRACKET EXH CONNECTION BS6-PH2	TATA spare parts
570114993801	MANIFOLD AIR INTAKE	TATA spare parts
570114993801AE	MANIFOLD AIR INTAKE 1628	TATA spare parts
570114993802	HOUSING STARTING AID	TATA spare parts
570114993802AE	HOUSING STARTING AID 1628	TATA spare parts
570114994202	CLAMP V BAND BS6	TATA spare parts
570114994203	V-CLAMP ASSY BS6	TATA spare parts
570114994204	CLAMP V BAND BS6-PH2	TATA spare parts
570114994701	COVER INTAKE MANIFOLD	TATA spare parts
570114995301	GASKET EXHAUST MANIFOLD	TATA spare parts
570114995302	GASKET OIL DRAIN	TATA spare parts
570114995302AE	ET OIL DRAINLPTA 1628/LPTA 1828/	TATA spare parts
570114995304	GASKET EXHAUST MANIFOLD BS6-PH2	TATA spare parts
570114995801	HOSE PLAIN BS4	TATA spare parts
570114995803	HOSE FLEXIBLE	TATA spare parts
570114995803AE	HOSE FLEXIBLE 1628	TATA spare parts
570114995804	HOSE FLEXIBLE	TATA spare parts
570114996901	TUBE TUR OIL SUPPLY	TATA spare parts
570114996902	TUBE PRESSURE SENSING BS6	TATA spare parts
570114996904	TUBE TUR COOLANT DRAIN BS6	TATA spare parts
570114996905	TUBE TUR COOLANT SUPPLY BS6	TATA spare parts
570114996906	TUBE TUR OIL SUPPLY BS6	TATA spare parts
570114996908	TUBE PRESSURE SENSING BS6	TATA spare parts
570114996909	TUBE TUR OIL SUPPLY BS6-PH2	TATA spare parts
570114996910	TUBE TUR COOLANT SUPPLY BS6-PH2	TATA spare parts
570114996911	TUBE TUR COOLANT DRAIN BS6-PH2	TATA spare parts
570114996912	TUBE TURBOCHARGER COOLANT SUPPLY BS6-PH2	TATA spare parts
570114996913	TUBE TURBOCHARGER COOLANT DRAIN BS6-PH2	TATA spare parts
570114996917	TUBE TUR COOLANT SUPPLY BS6-PH2	TATA spare parts
570114996918	TUBE TUR COOLANT DRAIN BS6-PH2	TATA spare parts
570114997701	SEAL O RING	TATA spare parts
570114998001	SCREW STUDDED HEXAGON CAP	TATA spare parts
570114998002	SCREW ROUND HEAD CAP	TATA spare parts
570114998010	SCREW BS6	TATA spare parts
570114998011	SCREW BS6	TATA spare parts
570114998012	SCREW STUDDED FLANGE CAP BS6	TATA spare parts
570114998013	SCREW HEX FLANGE HEAD CAP BS6-PH2	TATA spare parts
570114998601	SPACER MOUNTING	TATA spare parts
570114999801	CONNECTION TUR OIL DRAIN	TATA spare parts
570114999802	MANIFOLD AIR INTAKE BS6	TATA spare parts
570114999805	MANIFOLD EXHAUST BS6	TATA spare parts
570114999806	UNION MALE BS6	TATA spare parts
570114999807	CONNECTION ADAPTER BS6	TATA spare parts
570114999809	CONNECTION EXHAUST OUTLET BS6	TATA spare parts
570114999810	CONNECTION EXHAUST OUTLET BS6	TATA spare parts
570114999811	MANIFOLD AIR INTAKE BS6	TATA spare parts



570114999812	CONNECTION EXHAUST OUTLET BS6	TATA spare parts
570114999832	VALVE EXHAUST THROTTLE BS6	TATA spare parts
570114999833	CONNECTION TUR OIL DRAIN BS6	TATA spare parts
570114999834	CONNECTION TUR OIL DRAIN BS6	TATA spare parts
570114999835	SHIELD HEAT BS6	TATA spare parts
570114999836	SHIELD HEAT BS6	TATA spare parts
570114999837	SHIELD HEAT BS6	TATA spare parts
570114999841	CONNECTION EXHAUST OUTLET BS6	TATA spare parts
570114999842	CONNECTION EXHAUST OUTLET BS6	TATA spare parts
570114999843	CONNECTION EXHAUST OUTLET BS6	TATA spare parts
570114999844	CONNECTION EXHAUST OUTLET BS6	TATA spare parts
570114999845	CONNECTION EXHAUST OUTLET BS6	TATA spare parts
570114999847	TURBOCHARGER BS6-PH2	TATA spare parts
570114999848	EXHAUST THROTTLE VALVE BS6-PH2	TATA spare parts
570114999849	CONNECTION EXHAUST OUTLET BS6-PH2	TATA spare parts
570114999850	UNION MALE BS6-PH2	TATA spare parts
570114999901	CONNECTION EXHAUST OUTLET	TATA spare parts
570114999901AE	CONNECTION EXHAUST OUTLET 1628	TATA spare parts
570114999902	CONNECTION TUR OIL DRAIN	TATA spare parts
570114999905	CONNECTION TUR OIL DRAIN	TATA spare parts
570114999909	CONNECTION TUR OIL DRAIN	TATA spare parts
570114999910	LOCKPLATE	TATA spare parts
570115403301	BRACKET BS6	TATA spare parts
570115990102	MOTOR STARTING	TATA spare parts
570115990103	ALTERNATOR	TATA spare parts
570115990105	MOTOR STARTING	TATA spare parts
570115990106	ALTERNATOR BS3/4	TATA spare parts
570115990106AE	ALTERNATOR	TATA spare parts
570115990107	MODULE ELECTRONIC CONTROL	TATA spare parts
570115990108	MODULE ELECTRONIC CONTROL BS3	TATA spare parts
570115990108AE	MODULE ELECTR CONTROL -1628-1828	TATA spare parts
570115990111	WIRING HARNESS? BS3/4	TATA spare parts
570115990111AE	HARNESS WIRING 1628	TATA spare parts
570115990112	HARNESS WIRING	TATA spare parts
570115990112AE	HARNESS WIRING LPTA1628/LPTA1828	TATA spare parts
570115990117	MOTOR STARTING	TATA spare parts
570115990117AE	MOTOR STARTING 1628 1828	TATA spare parts
570115990118	ALTERNATOR	TATA spare parts
570115990120	HARNESS ETR CNT MDL WIRING	TATA spare parts
570115990123	MULTIMETER DIGITAL BS4/SBS6	TATA spare parts
570115990124	MODULE ELECTRONIC CONTROL BS3/4	TATA spare parts
570115990128	STARTER MOTOR BS3/4/6	TATA spare parts
570115990130	WIRING HARNESS BS3	TATA spare parts
570115990134	HARNESS ETR CNT MDL WRG	TATA spare parts
570115990137	HARNESS WIRING	TATA spare parts
570115990145	MODULE ELECTRONIC CONTROL BS6	TATA spare parts
570115990150	HEAD CYLINDER	TATA spare parts

570115990153	ALTERNATOR BS6	TATA spare parts
570115990155	ALTERNATOR BS6	TATA spare parts
570115990164	ALTERNATOR BS6-PH2	TATA spare parts
570115993101	BALL BEARING BS6	TATA spare parts
570115993301	BRACKET ETR CNT MODULE	TATA spare parts
570115993302	BRACKET ETR CNT MODULE	TATA spare parts
570115993306	BRACE BRACKET BS6	TATA spare parts
570115993307	BRACE BRACKET BS6-PH2	TATA spare parts
570115994201	CLIP WIRE RETAINING BS4	TATA spare parts
570115994201AE	CLIP WIRE RETAINING 1628	TATA spare parts
570115994202	CLIP WIRE RETAINING BS4	TATA spare parts
570115994203	CLIP	TATA spare parts
570115996501	NUT HEXAGON FLANGE	TATA spare parts
570115996502	FLANGE NUT BS6	TATA spare parts
570115996503	HEX NUT BS6	TATA spare parts
570115996504	FLANGE NUT BS6	TATA spare parts
570115997001	PULLEY BS6	TATA spare parts
570115998001	SCREW HEX FLANGE HEAD CAP	TATA spare parts
570115998002	SCREW HEX FLANGE HEAD CAP BS4	TATA spare parts
570115998003	SCREW SOCKET HEAD CAP	TATA spare parts
570115998004	SCREW STUDDED FLANGE CAP	TATA spare parts
570115998005	SCREW STUDDED FLANGE CAP BS6	TATA spare parts
570115998006	COUNTER SUNK SCREW BS6	TATA spare parts
570115998007	HEX SCREW BS6	TATA spare parts
570115998008	OVAL-HEAD SCREW BS6	TATA spare parts
570115998009	CONTACT SCREW BS6	TATA spare parts
570115998010	SCREW STUDDED FLANGE CAP BS6-PH2	TATA spare parts
570115998601	SPACER BS6	TATA spare parts
570115999803	WIRE GROUND BS6	TATA spare parts
570115999804	SUPPORT ELECTRONIC CONTROL BS6	TATA spare parts
570115999805	HARNESS ETR CNT MDL WRG BS6	TATA spare parts
570115999806	HARNESS ETR CNT MDL WRG BS6	TATA spare parts
570115999808	SENSOR POSITION	TATA spare parts
570115999809	DRIVE END SHIELD BS6	TATA spare parts
570115999810	HOLDING PLATE BS6	TATA spare parts
570115999811	ROTOR BS6	TATA spare parts
570115999812	STATOR BS6	TATA spare parts
570115999813	RECTIFIER BS6	TATA spare parts
570115999814	REGULATOR BS6	TATA spare parts
570115999815	PROTECTIVE CAP BS6	TATA spare parts
570115999816	SENSOR PRESSURE	TATA spare parts
570115999817	SWITCH PRESSURE BS6	TATA spare parts
570115999818	SWITCH PRESSURE BS6	TATA spare parts
570115999819	HARNESS ETR CNT MDL WRG BS6-PH2	TATA spare parts
570115999820	HARNESS ETR CNT MDL WRG BS6-PH2	TATA spare parts
570115999901	BRACE TUBE	TATA spare parts
570115999902	BRACE ALTERNATOR BS4	TATA spare parts

570115999902AE	BRACE ALTERNATOR 1628 1828	TATA spare parts
570115999903	BRACE ALTERNATOR	TATA spare parts
570115999904	SENSOR PRESSU	TATA spare parts
570115999905	SENSOR POSITION	TATA spare parts
570115999908	RETAINER COVER	TATA spare parts
570115999909	AID STARTING	TATA spare parts
570115999909AE	AID STARTING 1628	TATA spare parts
570115999910	DATA PLATE	TATA spare parts
570115999938	ADAPTER POSITION SENSOR	TATA spare parts
570115999940	"BRACE,WIRING"	TATA spare parts
570115999942	HARNESS INJECTOR WIRING BS6	TATA spare parts
570118990103	HEAD LUB OIL FILTER	TATA spare parts
570118990103AE	HEAD LUB OIL FILTER	TATA spare parts
570118990104	HEAD LUB OIL FILTER	TATA spare parts
570118990106	COOLER OIL	TATA spare parts
570118990106AE	COOLER OIL 1628	TATA spare parts
570118990110	DIPSTICK BS3/4	TATA spare parts
570118990112	PUMP LUBRICATING OIL	TATA spare parts
570118990112AE	PUMP LUBRICATING OIL 1628 1828	TATA spare parts
570118993301	BRACE TUBE	TATA spare parts
570118993302	PLATE CLAMPING	TATA spare parts
570118995304	GASKET FILTER BS6	TATA spare parts
570118995801	HOSE	TATA spare parts
570118996902	TUBE LUB OIL SUCTION	TATA spare parts
570118996902AE	TUBE LUB OIL SUCTION 1628	TATA spare parts
570118996903	TUBE LUB OIL SUCTION	TATA spare parts
570118997101	GASKET FILTER HEAD	TATA spare parts
570118997102	GASKET OIL COOLER CORE	TATA spare parts
570118997102AE	GASKET OIL COOLER CORE 1828	TATA spare parts
570118997201	PLUG THREADED	TATA spare parts
570118997801	SEAL O RING	TATA spare parts
570118998001	"SCREW,HEX FLANGE HEAD CAP"	TATA spare parts
570118999801	CARTRIDGE LUB OIL FILTER	TATA spare parts
570118999901	OIL FILTER CARTRIDGE BS3/4	TATA spare parts
570118999901AE	ASSY OIL FLTR -1628-1828	TATA spare parts
570118999902	CARTRIDGE LUB OIL FILTER	TATA spare parts
570118999904	PLUNGER PRS REGULATOR	TATA spare parts
570120990101	ASSY FAN (499 4678) - 26 INCH RING FAN	TATA spare parts
570120990101AE	FAN ENGINE 1628 1828	TATA spare parts
570120990112	THERMOSTAT	TATA spare parts
570120990118	COVER VALVE	TATA spare parts
570120990127	THERMOSTAT BS4	TATA spare parts
570120990127AE	THERMOSTAT	TATA spare parts
570120990133	FAN ENGINE ISBe5.9/6.7 BS3/4	TATA spare parts
570120990134	FAN ENGINE 26INCH ISBe6.7 BS4	TATA spare parts
570120990135	FAN ENGINE	TATA spare parts
570120990137	FAN ENGINE BS4/6	TATA spare parts

570120990142	CONNECTION WATER INLET BS6	TATA spare parts
570120990143	PUMP WATER	TATA spare parts
570120990151	FAN ENGINE BS6	TATA spare parts
570120993301	BRACKET IDLER PULLEY	TATA spare parts
570120993701	CONNECTION WATER INLET	TATA spare parts
570120996301	V-BELT RIBBED ISBe6.7 BS3/4/6	TATA spare parts
570120996301AE	BELT V RIBBED	TATA spare parts
570120996301DF	BELT V RIBBED-8PK-PRIMA2528/3128/4028	TATA spare parts
570120996302	BELT V RIBBED	TATA spare parts
570120996304	BELT V RIBBED	TATA spare parts
570120996305	RIBBED V BELT BS2/3/4	TATA spare parts
570120996305DF	BELT V RIBBED-LPT2521-PRIMA4023/4028/492	TATA spare parts
570120996306	BELT V RIBBED BS4	TATA spare parts
570120996307	BELT V RIBBED	TATA spare parts
570120996309	BELT V RIBBED BS6	TATA spare parts
570120996310	BELT V RIBBED	TATA spare parts
570120997001	PULLEY IDLER BS3/4/6	TATA spare parts
570120997002	PULLEY FAN BS6-PH2	TATA spare parts
570120997201	PLUG THREADED	TATA spare parts
570120997701	SEAL RECTANGULAR RING	TATA spare parts
570120997702	SEAL THERMOSTAT	TATA spare parts
570120997703	SEAL THERMOSTAT BS6-PH2	TATA spare parts
570120997801	SHIELD DUST BS4	TATA spare parts
570120997901	SHAFT IDLER BS4	TATA spare parts
570120998001	SCREW HEX FLANGE HEAD CAP	TATA spare parts
570120998002	SCREW HEX FLANGE HEAD CAP	TATA spare parts
570120998003	SCREW HEX FLANGE HEAD CAP BS4	TATA spare parts
570120998801	STUD DOUBLE END PLAIN (MOUNTING FAN) BS4	TATA spare parts
570120998802	STUD DOUBLE END PLAIN BS4	TATA spare parts
570120999801	COUPLING PLAIN HOSE BS6	TATA spare parts
570120999901	CONNECTION WATER INLET	TATA spare parts
570120999906	COUPLING PLAIN HOSE	TATA spare parts
570120999907	TENSIONER,BELT 6BT ISBe5.9/6.7 BS3/BS4	TATA spare parts
570120999907AE	TENSIONER BELT 1628 1828 715	TATA spare parts
570120999908	TENSIONER BELT	TATA spare parts
570120999910	CLUTCH VISCOUS FAN BS4	TATA spare parts
570120999916	CONNECTION WATER INTAKE	TATA spare parts
570120999918	THERMOSTAT	TATA spare parts
570120999919	FAN ENGINE BS6-PH2	TATA spare parts
570122993301	BRACKET LIFTING	TATA spare parts
570122993301AE	BRACKET LIFTING 1628	TATA spare parts
570122993302	BRACKET LIFTING	TATA spare parts
570122994701	PLATE COVER	TATA spare parts
570123113201	HEX FLANGE BOLT BS6	TATA spare parts
570123123302	BRACKET	TATA spare parts
570123126303	BELT AC COMP	TATA spare parts
570150000101	ASSY PIPE (RAD TO ENG)	TATA spare parts

570150000105	ASSY BRACKET (FOR VENT TUBE MOUNTING)	TATA spare parts
570150000105AE	ASSY. BRKT (VENT TUBE MTG) -1628	TATA spare parts
570150000106	FILL PIPE ASSY	TATA spare parts
570150000111	ASSY BRACKET	TATA spare parts
570150000113	ASSY. FILL PIPE	TATA spare parts
570150000119	ASSY. BRACKET (RAD MTG-ON CHASSIS-RH)	TATA spare parts
570150000121	STUD ASSY (RAD MTG)	TATA spare parts
570150000122	AUX WATER TANK MTG BKT- ASSY-MPV	TATA spare parts
570150000126	ASSY BRACKET (RAD BOTTOM MTG) - LH-MPV	TATA spare parts
570150000127	ASSY BRACKET (RAD BOTTOM MTG) - RH-MPV	TATA spare parts
570150000128	ASSY INTEGRAL HOSE	TATA spare parts
570150000136	ASSY BRACKET-LH(ON RADIATOR SIDE MTG)-MP	TATA spare parts
570150000137	BRACKET-RH(ON RADIATOR SIDE MTG)-MPV	TATA spare parts
570150000138	STUD ASSY (RAD MTG)	TATA spare parts
570150000140	ASSY BKT.-RH ( ON RADIATOR)	TATA spare parts
570150000141	ASSY BKT.-RH( ON LM)	TATA spare parts
570150000142	ASSY BKT.-LH ( ON RADIATOR)	TATA spare parts
570150000143	ASSY BKT.-LH( ON LM)	TATA spare parts
570150000144	STUD ASSY (RAD MTG)	TATA spare parts
570150000145	ASSY. BRACKET( VENT HOSE SUPPORT)	TATA spare parts
570150000148	ASSY BKT. (AUX TANK) COMPLETE	TATA spare parts
570150000149	ASSY PIPE (RAD TO ENG) LPTA 1628	TATA spare parts
570150000153	ASSY BRACKET LH (RAD MTG BKT LPTA 1628)	TATA spare parts
570150000154	ASSY BRACKET RH (RAD MTG BKT LPTA 1628)	TATA spare parts
570150000155	ASSY BRACKET RH (RAD MTG BKT ON LM LPTA	TATA spare parts
570150000156	ASSY BRACKET LH (RAD MTG BKT ON LM LPTA	TATA spare parts
570150000157	ASSY HOSE WITH CORRUGATED TUBE	TATA spare parts
570150000161	ASSY.BKT ENG TO RAD PIPE SUPPORT-MPV	TATA spare parts
570150000166	ASSY RAD MTG BKT RH (TOP SIDE)4023.S	TATA spare parts
570150000167	ASSY RAD MTG BKT LH (TOP SIDE)4023.S	TATA spare parts
570150000168	ASSY PIPE (RAD TO ENG)	TATA spare parts
570150000174	BRACKET (VENT TUBE MTG)	TATA spare parts
570150000175	AIR PROTECTOR (RADIATOR UPPER)	TATA spare parts
570150000176	AIR PROTECTOR (RADIATOR RH SIDE)	TATA spare parts
570150000177	AIR PROTECTOR (RADIATOR LH SIDE)	TATA spare parts
570150000180	BRACKET LOWER-RH	TATA spare parts
570150000181	BRACKET LOWER-LH	TATA spare parts
570150000195	RAD MTG BRACKET (4023.S)	TATA spare parts
570150000197	VENT HOSE ASSY AUX TANK TO RADIATOR	TATA spare parts
570150000198	VENT HOSE ASSY AUX. TANK TO ENG	TATA spare parts
570150000203	BRACKET ASSY RADIATOR MTG RH	TATA spare parts
570150000204	BRACKET ASSY RADIATOR MTG LH	TATA spare parts
570150003301	BRACKET RH (RADIATOR LOWER MOUNTING FRA	TATA spare parts
570150003303	BRACKET RADIATOR MOUNTING LH	TATA spare parts
570150003304	BRACKET RADIATOR MOUNTING RH	TATA spare parts
570150003305	BRACKET RADIATOR MOUNTING (LH)	TATA spare parts
570150003306	BRACKET RADIATOR MOUNTING (RH)	TATA spare parts

570150003307	BRACKET-LH (RAD LOWER MTG)	TATA spare parts
570150003308	BRACKET (RAD LOWER MTG)	TATA spare parts
570150003321	BRACKET LH (ON LM SIDE MTG)	TATA spare parts
570150003322	BRACKET RH (ON LM SIDE MTG)	TATA spare parts
570150003323	BRACKET RADIATOR MOUNTING LH	TATA spare parts
570150003324	BRACKET RADIATOR MOUNTING RH	TATA spare parts
570150003325	BRACKET LH (RAD LOWER MTG - FRAME)	TATA spare parts
570150003327	BRACKET IC TO TC PIPE SUPPORT-MPV	TATA spare parts
570150003328	BRACKET RAD SUPPORT-RH	TATA spare parts
570150003329	BRACKET-RH(RAD LOWER MTG.)	TATA spare parts
570150003331	BRACKET (SUPPORT VENT TUBES)	TATA spare parts
570150003332	BRACKET AUX WATER TANK TO RAD PIPE SUPPO	TATA spare parts
570150003334	RAD MTG BKT(ON FRAME)BOTTOM-LH-4028.S	TATA spare parts
570150003335	RAD MTG BKT(ON FRAME)BOTTOM-RH-4928.S	TATA spare parts
570150003336	RAD MTG BKT(ON RAD)BOTTOM-LH-4028.S	TATA spare parts
570150003337	RAD MTG BKT(ON RAD)BOTTOM-RH-4028.S	TATA spare parts
570150003338	BRACKET - TOP RH (RAD PROTECTOR MTG)	TATA spare parts
570150003339	BRACKET- TOP LH (RAD PROTECTOR MTG)	TATA spare parts
570150003342	RAD MTG BKT(ON FRAME)BOTTOM-LH-4028.S	TATA spare parts
570150003343	RAD MTG BKT(ON FRAME)BOTTOM-RH-4928.S	TATA spare parts
570150003344	BRACKET (VENT TUBES SUPPORT)	TATA spare parts
570150003366	BRACKET RADIATOR MTG TOP-LH BS6	TATA spare parts
570150003367	BRACKET RADIATOR MTG TOP-RH BS6	TATA spare parts
570150003368	BRACKET RADIATOR MTG BOTTOM	TATA spare parts
570150003369	BRACKET BS6	TATA spare parts
570150003370	BRACKET BS6	TATA spare parts
570150003372	BRACKET RADIATOR MTG TOP-LH BS6	TATA spare parts
570150003373	BRACKET RADIATOR MTG TOP-RH BS6	TATA spare parts
570150003378	BRACKET RADIATOR LOWER MTG BS6	TATA spare parts
570150004201	CLAMP (FOR HVAC TUBE SUPPORT)	TATA spare parts
570150004202	CLAMP (VENT TUBE SUPPORT)	TATA spare parts
570150006301	CUSHION RUBBER (RAD MTG)	TATA spare parts
570150007702	FLAP (RADIATOR SIDE RH)	TATA spare parts
570150007703	FLAP (RADIATOR SIDE LH)	TATA spare parts
570150007705	AIR GUIDE FLAPPER BEAD	TATA spare parts
570150008802	ASLY TIE ROD	TATA spare parts
570150100106	RADIATOR ASSEMBLY-MPV	TATA spare parts
570150100112	ASSY. RADIATOR BS3/4	TATA spare parts
570150100129	SET - COOLING SYSTEM	TATA spare parts
570150100132	SET-COOLING SYSTEM-2528.K	TATA spare parts
570150100134	COOLING SYSTEM ASSY(LPT2521BS4)	TATA spare parts
570150100135	ENGINE COOLING SYSTEM (LPO 1925 LF HYBRI	TATA spare parts
570150100137	ASSY. RADIATOR & INTERCOOLER BS3/4	TATA spare parts
570150100143	ASSY RADIATOR	TATA spare parts
570150100144	ASSY RADIATOR AND INTERCOOLER	TATA spare parts
570150100147	SET-COOLING SYSTEM	TATA spare parts
570150100162	ENGINE COOLING SYSTEM BS6	TATA spare parts

570150100237	COOLING SYSTEM BS6	TATA spare parts
570150100242	AUX COOLANT TANK ASSY	TATA spare parts
570150100253	SET-COOLING SYSTEM	TATA spare parts
570150105802	HOSE (RADIATOR TO ENGINE)	TATA spare parts
570150105802AE	HOSE (RDTR TO ENGINE) -1628-1828	TATA spare parts
570150105803	HOSE (WATER PUMP INLET)	TATA spare parts
570150105803AE	HOSE (WATR PMP INLET) -1628-1828	TATA spare parts
570150105805	REDUCER HOSE(ENGINE TO RADIATOR)	TATA spare parts
570150105805AE	REDUCER HOSE(EG TO RAD)1628-1828	TATA spare parts
570150105807	HOSE (WATER FILL PIPE)	TATA spare parts
570150105808	REDUCER HOSE (ENG TO RAD)	TATA spare parts
570150105809	VENT HOSE (ENGINE TO AUX.TANK)	TATA spare parts
570150105810	VENT HOSE (RADIATOR TO AUX. TANK)	TATA spare parts
570150105811	HOSE (RADIATOR TO ENGINE)	TATA spare parts
570150105812	HOSE (WATER PUMP INLET)	TATA spare parts
570150105814	REDUCER HOSE(ENGINE TO RADIATOR)	TATA spare parts
570150105815	HOSE (WATER FILL PIPE)	TATA spare parts
570150105816	HOSE (WATER FILL PIPE)	TATA spare parts
570150105818	VENT HOSE (ENGINE TO AUX.TANK)	TATA spare parts
570150105819	VENT HOSE (RADIATOR TO AUX. TANK)	TATA spare parts
570150105820	HOSE (WATER FILL PIPE)	TATA spare parts
570150105821	HOSE (RAD TO ENG)	TATA spare parts
570150105828	HOSE (AUX WATER TANK)	TATA spare parts
570150105831	HOSE (RADIATOR TO ENGINE)(LPTA1627 RTN)	TATA spare parts
570150105834	VENT HOSE( 9 ID)	TATA spare parts
570150105835	HOSE ( RAD TO ENG)	TATA spare parts
570150105836	HOSE WATER FILL PIPE	TATA spare parts
570150105836AE	HOSE WATER FILL PIPE 1628 1828	TATA spare parts
570150105837	HOSE(ENGINE TO RADIATOR-ID 44)-MPV	TATA spare parts
570150105838	HOSE (ENG TO RAD-ID44) MPV	TATA spare parts
570150105839	HOSE (ID52 80X95)	TATA spare parts
570150105840	HOSE (RADIATOR TO ENGINE) 4023.S	TATA spare parts
570150105847	REDUCER HOSE (DIA 9 TO 6)	TATA spare parts
570150105855	VENT HOSE ENGINE TO AUX WATER TANK	TATA spare parts
570150105860	HOSE INTAKE BS6	TATA spare parts
570150105868	HOSE BS6	TATA spare parts
570150106906	PIPE (ENGINE TO RADIATOR)	TATA spare parts
570150106910	VENT TUBE ENG TO AUX WATER TANK	TATA spare parts
570150106915	PIPE (TC TO IC) MPV	TATA spare parts
570150106916	PIPE (ENG TO RAD) MPV	TATA spare parts
570150106919	PIPE AUX WATER TANK TO RAD-MPV	TATA spare parts
570150106920	VENT PIPE (AUX WATER TANK TO RAD)-MPV	TATA spare parts
570150106921	PIPE (AUX WATER TANK TO ENG)-MPV	TATA spare parts
570150106923	PIPE (RAD TO ENG BOTTOM SIDE )	TATA spare parts
570150106925	FILL PIPE (RAD SIDE)	TATA spare parts
570150106926	VENT TUBE (ENG TO AUX)	TATA spare parts
570150106927	VENT TUBE (RAD TO AUX)	TATA spare parts

570150106928	PIPE 45 OD (ENG TO RAD)	TATA spare parts
570150106929	PIPE (RAD TO WP)	TATA spare parts
570150106930	PIPE (RAD TO ENGINE)LPTA 1628	TATA spare parts
570150106936	FILL PIPE ( AUX SIDE)	TATA spare parts
570150106940	PIPE (RAD TO ENG) 4023.S	TATA spare parts
570150106942	VENT PIPE (AUX WATER TANK TO RAD)-4023.S	TATA spare parts
570150106953	PIPE (RAD TO ENGINE) MPV_LHD	TATA spare parts
570150106954	TUBE VENT ENG TO AUX WATER TANK MPV LHD	TATA spare parts
570150106959	VENT TUBE	TATA spare parts
570150106993	VENT TUBE BS6	TATA spare parts
570150106994	VENT TUBE BS6	TATA spare parts
570150106995	AIR VENT PIPE EXPANSION TANK	TATA spare parts
570150106996	AIR VENT TUBE	TATA spare parts
570150506306	FAN SHROUD	TATA spare parts
570150506308	FAN SHROUD (LPO1925 LF) (22IN JET RING)	TATA spare parts
570150506309	FAN SHROUD-MPV (26INC JET RING)	TATA spare parts
570150506310	FAN SHROUD	TATA spare parts
570150506311	FAN SHROUD ( 26INCH JET RING)	TATA spare parts
570150506315	FAN SHROUD MPV LHD	TATA spare parts
570203153401	CONNECTING ROD BUSH	TATA spare parts
570214105301	INTEGRAL GASKET(INTAKE MANIFOLD)	TATA spare parts
570301179942	CLAMPING SADDLE,INJECTOR	TATA spare parts
570314110107	ASSY, CLAMP FOR VAC. PUMP TO V.A. HOSE	TATA spare parts
570314114203	CLAMP FOR VAC. PUMP	TATA spare parts
570314114204	CLAMP FOR EVRV TO VA FOR FIAT 1.3SDE90PS	TATA spare parts
570314114206	CLAMP FOR HOSE EVRV2TC ON BLOW-BY HOSE (	TATA spare parts
570350104201	AUX VENT HOSE SEPERATOR CLAMP BS6	TATA spare parts
570501104108	CAP NO 2 (FOR BALANCER SHAFT 3 BEARING)	TATA spare parts
570501104802	HOLLOW DOWEL (MANUAL GB ON CRANKCASE)	TATA spare parts
570501104803	HOLLOW DOWEL (FOR MB CAP MTG)	TATA spare parts
570501107803	OILSEAL CRANKSHAFT FRONT M/S SFN	TATA spare parts
570501107804	OILSEAL CRANKSHAFT REAR M/S SFN	TATA spare parts
570501130115	ASSY. OIL SUMP COMPLETE BS6	TATA spare parts
570501136903	OIL DRAIN TUBE	TATA spare parts
570501143801	REAR COVER CRANKCASE	TATA spare parts
570501147701	ASSY TIMING COVER (REAR)	TATA spare parts
570501147702	ASSY TIMING COVER(FRONT)	TATA spare parts
570501147703	TIMING COVER(BOTTOM)	TATA spare parts
570501150104	ASSY. CAP (OIL FILLER)	TATA spare parts
570501150131	CYLINDER HEAD ASSY W/O VALVES BS6	TATA spare parts
570501150132	CYLINDER HEAD ASSY WITH VALVES BS6	TATA spare parts
570501150134	CYLINDER HEAD ASSY W/O VALVES BS6	TATA spare parts
570501150135	CYLINDER HEAD ASSY WITH VALVES BS6	TATA spare parts
570501153201	HEX. BOLT (CYLINDER HEAD)	TATA spare parts
570501153203	SPECIAL PAN HEAD SCREW ( M5X10 )	TATA spare parts
570501153405	VALVE SEAT INSERT INTAKE NORMAL(M/S PAC)	TATA spare parts
570501153411	VALVE SEAT INSERT EXT	TATA spare parts



570501153429	VALVE SEAT INSERT, INTAKE GASOLINE & CNG	TATA spare parts
570501153432	VALVE SEAT INSERT, EXHAUST GASOLINE & CN	TATA spare parts
570501154801	HOLLOW DOWEL (ON CYL CRANKCASE )	TATA spare parts
570501154802	SOLID DOWEL(REED PLATE)	TATA spare parts
570501154803	INSERT (OFFER) (CYLINDER HEAD COVER) BS6	TATA spare parts
570501155305	GASKET (OIL FILLER CAP)	TATA spare parts
570501156903	NIPPLE(HEATER PICK UP FOR CYLINDER HEAD)	TATA spare parts
570501157703	GASKET (CYLINDER HEAD COVER) (M/S BANCO)	TATA spare parts
570501159201	WASHER(FOR CYL. HEAD BOLT)	TATA spare parts
570501159901	CAP(OIL FILLER)	TATA spare parts
570501170114	ADAPTER DIPSTICK TUBE ASSY (ACE) BS6	TATA spare parts
570501170115	DIPSTICK ASSY BS6	TATA spare parts
570501174201	CLAMP OIL SEPARATOR (M/S OETIKER) BS6	TATA spare parts
570501174203	SEPARATOR CLAMP(OIL SEPARATOR HOSE TO FU	TATA spare parts
570501176303	ASSEMBLY OIL SEPARATOR BS6	TATA spare parts
570501178202	CLAMP (REED PLATE)	TATA spare parts
570501178204	REED PLATE	TATA spare parts
570501990108	ENGINE OVERHAUL SEAL KIT	TATA spare parts
570503105403	SPUR GEAR (CRANKSHAFT)	TATA spare parts
570503105404	SPUR GEAR (BALANCER SHAFT)	TATA spare parts
570503108201	SENSOR WHEEL (36-2 TEETH)	TATA spare parts
570503109101	BALANCER THRUST PLATE BS6	TATA spare parts
570503110108	ASSY FLYWHEEL (ACE STARTR ON GB) BS6	TATA spare parts
570503123114	THRUST WASHER (MENON) (M/S MENON)	TATA spare parts
570503123119	BALANCER SHAFT BEARING (M/S MENON)	TATA spare parts
570503123402	BUSH BALANCER SHAFT (M/S MENON)	TATA spare parts
570503133201	HEX FL. BOLT (FRONT PULLEY)	TATA spare parts
570503133202	HEX FL. BOLT (FRONT PULLEY)	TATA spare parts
570503153203	BOLT CONNECTING ROD (M/S. SFL)BS6	TATA spare parts
570505107907	CAMSHAFT BS6	TATA spare parts
570505109201	WASHER (CAMSHAFT)	TATA spare parts
570505110107	ASSY. TG WITH PIN (M/S.GKN)	TATA spare parts
570505110108	ASSY. TENSIONER (KNURLING)	TATA spare parts
570505110110	ASSY CRANKSHAFT TIMING GEAR WITH PIN(M/S	TATA spare parts
570505115403	TIMING GEAR-(CAMSHAFT)(M/S GKN)	TATA spare parts
570505116302	TIMING BELT (M/S GATES)	TATA spare parts
570505125102	VALVE SPRING RETAINER (M/S BHAVANI)	TATA spare parts
570505128202	SPRING SEAT (VALVE SPRING)	TATA spare parts
570505129007	INLET VALVE (M/S DURO VALVE)	TATA spare parts
570505129008	EXHAUST VALVE (M/S DURO VALVE)	TATA spare parts
570505129012	INLET VALVE CNG & E20 (M/S RANE VALVE)	TATA spare parts
570505129013	EXHAUST VALVE E20 (M/S RANE VALVE)	TATA spare parts
570505129025	EXHAUST VALVE	TATA spare parts
570505139901	TAPPET	TATA spare parts
570505150102	ASSY. VALVE GUIDE SEAL (M/S SFN)	TATA spare parts
570505153409	VALVE GUIDE (SINTERED) NORMAL	TATA spare parts
570505990103	KIT -VALVE SEAL & VALVE GUIDE	TATA spare parts

570507106301	ASSY. FUEL RAIL (M/S MGI)	TATA spare parts
570507108201	CLIP (FUEL INJECTOR)	TATA spare parts
570509125301	THROTTLE BODY GASKET	TATA spare parts
570509130104	ASSY. AIR FILTER COMPLETE (M/S MAHLE)	TATA spare parts
570509130106	ASSY. AIR FILTER ELEMENT (M/S MAHLE)	TATA spare parts
570509130127	ASSY. ISOLATOR (FOR SNORKEL MOUNTING) BS	TATA spare parts
570509137501	RUBBER GROMMET(FOR AIR FILTER MOUNTING)	TATA spare parts
570514100103	ASSY. ISOLATOR (FOR THROTTLE SUPPORT)	TATA spare parts
570514100107	ASSY. AIR INTAKE MANIFOLD	TATA spare parts
570514100114	ASSY. AIRINTAKE MANIFOLD CNG M/S VISTEON	TATA spare parts
570514103304	SUPPORT (INTAKE MANIFOLD)	TATA spare parts
570514103307	SUPPORT BRACKET BS6	TATA spare parts
570514103805	ADAPTER BS6	TATA spare parts
570514107701	GASKET AIR INTAKE (CYLINDER HEAD PORT)	TATA spare parts
570514107702	GASKET AIR INTAKE (THROTTLE BODY)	TATA spare parts
570514115304	EXHAUST MANIFOLD GASKET (M/S BANCO)	TATA spare parts
570515200125	ELECTRONIC THROTTLE BODY	TATA spare parts
570515200148	ELECTRONIC THROTTLE CONTROL BS6	TATA spare parts
570515209904	CANISTER PURGE VALVE	TATA spare parts
570515209906	COOLANT TEMPERATURE SENSOR	TATA spare parts
570515209906_NIU1	COOLANT TEMPERATURE SENSOR	TATA spare parts
570515209908	RESSURE/TEMPERATURE SENSOR (MAP SENSOR)	TATA spare parts
570515209909	OXYGEN SENSOR (LAMBADA SENSOR)	TATA spare parts
570515209915	KNOCK SENSOR	TATA spare parts
570515209924	FUEL INJECTOR(CNG)	TATA spare parts
570515209933	IGNITION COIL ASSY	TATA spare parts
570518130102	ASSY. OIL FILTER - M/S PUROLATOR	TATA spare parts
570518150105	ASSY OIL STRAINER (FOR ACE) BS6	TATA spare parts
570518158801	STUD M6 X 16.0 (TVS)	TATA spare parts
570518179901	ADAPTOR (OIL FILTER)	TATA spare parts
570520120103	ASSY. THERMOSTAT (M/S WESTERN THOMSON)	TATA spare parts
570520123808	THERMOSTAT COVER BS6	TATA spare parts
570520125801	RUBBER HOSE(CYL.HD NIPPLE TO WATER PUMP)	TATA spare parts
570520127704	RUBBER GASKET, THERMOSTAT COVER (AMT)	TATA spare parts
570522123708	A-MOUNTING ARM BS6	TATA spare parts
570524200105	ASSY.ENGINE MOUNTING PAD'C'(M/S SVIL)	TATA spare parts
570550990104	PRESSURE CAP ASSY. ( TTR NO.: S0218003M0	TATA spare parts
570550990105	DRAIN COCK ASSY(TTR NO:S0202027M001 )	TATA spare parts
570601000105	ENGINE TRUCK 7.5T 12V NON AC	TATA spare parts
570601000106	ENGINE 3L LPO 7.5T RHD	TATA spare parts
570601000111	ENGINE 3L EURO-IV 12V LPO BUS WITH AC	TATA spare parts
570601000115	ENGINE 3L NGE 7.5T 24V SA TRUCK W/H HVAC	TATA spare parts
570601000121	ENGINE 3L 9.6T 24V NON-AC LPO	TATA spare parts
570601000124	ENGINE 3L 24V MULTIPLEXING AC LPO BUS	TATA spare parts
570601000126	ENGINE ASSY	TATA spare parts
570601000136	ENGINE 3L 24V AMT LPO BUS NON-AC (6PK)	TATA spare parts
570601000138	ENGINE ASSY	TATA spare parts

570601000140	ENGINE ASSY	TATA spare parts
570601000143	3LNGE 125PS BS-IV 12V N-AC LPO BUS	TATA spare parts
570601000144	ASSY. ENGINE TRUCK 7.5T 12V NON AC	TATA spare parts
570601000153	3L LPO-LHD BS-IV 24V-150A AC W/O GRID	TATA spare parts
570601000158	ENGINE ASSY	TATA spare parts
570601000159	3L 24V HVAC W/O GRID 150AMP LPO E-III	TATA spare parts
570601000160	ASSLY ENGINE COMP 3L NGE 24V AC 150AMP L	TATA spare parts
570601000161	ASSY ENGINE COMPLETE 3L NGE 24V N-AC 80	TATA spare parts
570601000166	ENGINE ASSY WITH HVAC & POWER STRG BS6	TATA spare parts
570601000167	3L 24V HVAC W/O GRID 150AMP LPO E-IV	TATA spare parts
570601000169	ENGINE COMPLETE 3L LPT ME 24V W/H HVAC A	TATA spare parts
570601000170	ENGINE ASSY BS6	TATA spare parts
570601000184	ENGINE ASSY 3.3L BS6	TATA spare parts
57060100018470	ENGINE ASSY 3.3L BS6	TATA spare parts
570601000185	ENGINE ASSY 3.3L ULTRA T.12 BS6	TATA spare parts
570601000186	ENGINE ASSY BS6	TATA spare parts
570601000187	ENGINE ASSY BS6	TATA spare parts
570601000188	ENGINE ASSY BS6	TATA spare parts
570601000189	ENGINE ASSY BS6	TATA spare parts
570601000190	ENGINE ASSY BS6	TATA spare parts
570601000191	BARE ENGINE ASSY BS6	TATA spare parts
570601000193	ENGINE ASSY	TATA spare parts
570601000195	ENGINE ASSY. 3.3L NG BS6	TATA spare parts
570601000198	ENGINE ASSY BS6	TATA spare parts
570601000210	ENGINE ASSYBS6	TATA spare parts
570601000214	ASSY ENGINE 3L W/HVAC & POWER STEERING B	TATA spare parts
570601000215	ENGINE ASSY BS6	TATA spare parts
570601000220	ENGINE ASSY BS6	TATA spare parts
570601000221	ENGINE ASSY BS6	TATA spare parts
570601000224	ENGINE ASSY BS6	TATA spare parts
570601000226	ENGINE ASSY BS6-PH2	TATA spare parts
570601000229	ENGINE ASSY WITH HVAC & POWER STEERING	TATA spare parts
570601000230	ENGINE ASSY BS6-PH2	TATA spare parts
570601000232	ENGINE ASSY BS6-PH2	TATA spare parts
57060100023270	IPBT ENGINE ASSY WITH CLUTCH BS6-PH2	TATA spare parts
570601000240	ENGINE ASSY BS6-PH2	TATA spare parts
570601000260	ENGINE ASSY	TATA spare parts
570601100101	ASSY. CYL. CRANKCASE & BEDPLATE BS3/4	TATA spare parts
570601100106	ASSY.CYL.CRANKCASE AND BEDPLATE COMPLETE	TATA spare parts
570601100115	BED PLATE ASSY WITH DOWELS BS6	TATA spare parts
570601100132	CYLINDER BLOCK ASSY	TATA spare parts
570601103201	HEX BOLT (MAIN BEARING-BED PLATE)	TATA spare parts
570601103701	CYLINDER BLOCK 3L BS4	TATA spare parts
570601103702	BED PLATE (CAST IRON)	TATA spare parts
570601103706	BED PLATE CUT-OUT (3.3L) BS6	TATA spare parts
570601103808	SPACER BS6-PH2	TATA spare parts
570601103809	SPACER ASSY BS6	TATA spare parts

570601104201	CLAMP (CRANK SENSOR CABLE)	TATA spare parts
570601107701	O-RING	TATA spare parts
570601108203	CORE PLUG BS6-PH2	TATA spare parts
570601130103	ASSY. OIL SUMP	TATA spare parts
570601130107	ASSY OIL SUMP BUS (WITH DRAIN PLUG) BS4	TATA spare parts
570601130115	OIL SUMP ASSY WITH DRAIN PLUG BS6	TATA spare parts
570601150102	ASSY. CYLINDER HEAD M/C (W/O VALVES)	TATA spare parts
570601150104	ASSY. BAFFLE PLATE	TATA spare parts
570601150109	DECOUPLING ELEMENT	TATA spare parts
570601150117	CYLINDER HEAD WITHOUT GLOW PLUG	TATA spare parts
570601150118	ASSY. CYLINDER HEAD W/VALVES BS3/4	TATA spare parts
570601150123	CYL HEAD ASSY W/O VALVES	TATA spare parts
570601150124	CYL HEAD ASSY WITH VALVES	TATA spare parts
570601150128	COVER ENGINE WITH RUBBER GASKET BS6	TATA spare parts
570601150130	ISOLATOR ASSY BS6	TATA spare parts
570601150131	ISOLATOR ASSY BS6	TATA spare parts
570601150132	ISOLATOR ASSY BS6	TATA spare parts
570601150134	COVER ENGINE BS6	TATA spare parts
570601150140	COVER ENGINE BS6-PH2	TATA spare parts
570601153201	BOLT (CYLINDER HEAD)	TATA spare parts
570601153204	BOLT CYL HEAD BS6	TATA spare parts
570601153401	VALVE SEAT INSERT-INTAKE	TATA spare parts
570601153403	VALVE SEAT INSERT-EXHAUST	TATA spare parts
570601153412	VALVE SEAT EXHAUST BS6	TATA spare parts
570601153413	INSERT-VALVE-EXHAUST BS6	TATA spare parts
570601153701	CYLINDER HEAD	TATA spare parts
570601153702	CYLINDER HEAD 3L BS4	TATA spare parts
570601153801	CYLINDER HEAD COVER	TATA spare parts
570601153805	COVER CYLINDER HEAD	TATA spare parts
570601153806	CYLINDER HEAD COVER BS6	TATA spare parts
570601155305	CYLINDER HEAD GASKET ( 1.3 MM THK ) BS4	TATA spare parts
570601155306	CYLINDER HEAD GASKET ( 1.4 MM THK )	TATA spare parts
570601155307	GSK SEAL CAM SHAFT COVER	TATA spare parts
570601155309	GASKET INJECTOR SEAL BS4	TATA spare parts
570601155316	GASKET CYLINDER HEAD (1.3 MM) BS6	TATA spare parts
570601155317	GASKET CYLINDER HEAD (1.4 MM) BS6	TATA spare parts
570601157701	O RING INJECTOR SLEEVE BS4	TATA spare parts
570601157703	O RING (CYL. HEAD TO CAM CARRIER)	TATA spare parts
570601157707	RUBBER WASHER (FOR CYL. HEAD COVER)	TATA spare parts
570601158401	INJECTOR SLEEVE	TATA spare parts
570601158402	SLEEVE INJECTOR BS6	TATA spare parts
570601158801	STUD FOR INTAKE MANIFOLD	TATA spare parts
570601158802	STUD FOR EXHAUST MANIFOLD	TATA spare parts
570601159202	WASHER (FOR CYL. HEAD COVER)	TATA spare parts
570601159901	ADAPTOR (CYL. HEAD COVER)	TATA spare parts
570601159902	OIL FILLER CAP BS4	TATA spare parts
570601160102	ASSY. FUEL INJECTOR BS3/4	TATA spare parts

570601160104	INJECTOR ASSY	TATA spare parts
570601160106	INJECTOR ASSY¿BS6	TATA spare parts
570601163201	HEX. FLANGE BOLT (INJECTOR CLAW)	TATA spare parts
570601164201	INJECTOR CLAW	TATA spare parts
570601164203	CLAW INJECTOR BS6	TATA spare parts
570601166701	REACTION PIN(2.5MM THK. INJ. WASHER)	TATA spare parts
570601167701	O RING ( FOR INJECTOR SLEEVE )	TATA spare parts
570601169201	SPHERICAL WASHER (INJECTOR CLAMP)	TATA spare parts
570601169207	WASHER INJECTOR¿BS6	TATA spare parts
570601170108	ASSY. OIL SEPARATOR PIPE	TATA spare parts
570601170109	ASSY. DRAIN SEAL (FOR OIL SEPARATOR)	TATA spare parts
570601170127	DIPSTICK SUPPORT BRACKET	TATA spare parts
570601170128	TRUCK DIPSTICK ASSLY	TATA spare parts
570601170131	DIPSTICK TUBE¿ ASSY BS4	TATA spare parts
570601170134	DIPSTICK BS4	TATA spare parts
570601170149	PIPE OIL SEPARATOR ASSY BS6	TATA spare parts
570601170150	SUPPORT BRACKET OMS	TATA spare parts
570601170154	DIPSTICK ASSY BS6	TATA spare parts
570601170156	BRACKET ASSY DIPSTICK MTG BS6	TATA spare parts
570601170159	OIL MIST SEPARATOR BS6	TATA spare parts
570601170160	HOSE OMS TO BEDPLATE BS6	TATA spare parts
570601170161	PIPE ASSY WITH CLAMP¿BS6	TATA spare parts
570601170162	OIL MIST SEPARATOR ASSY¿BS6	TATA spare parts
570601170163	ASSY PIPE WITH HOSE (OMS OIL RETURN) BS6	TATA spare parts
570601170164	HOSE OMS TO BEDPLATE - OLD PART NUMBER -	TATA spare parts
570601170165	HOSE OMS TO BEDPLATE BS6	TATA spare parts
570601170167	DIPSTICK ASSY BS6	TATA spare parts
570601170173	DIP STICK BS6	TATA spare parts
570601170178	DIPSTICK INNER BS6-PH2	TATA spare parts
570601170181	TUBE ASSY WITH CLAMP OMS TO ATM BS6-PH2	TATA spare parts
570601170182	OIL MIST SEPARATOR BS6-PH2	TATA spare parts
570601173301	OMS MTNG BKT	TATA spare parts
570601173303	OIL MIST SEPERATOR MOUNTING BRACKET	TATA spare parts
570601173315	OMS BRACKET FOR TRUCK	TATA spare parts
570601173328	BRACKET BS6	TATA spare parts
570601173329	BRACKET (OMS) BS6	TATA spare parts
570601173331	BRACKET OIL SEPARATOR MTG¿ BS6	TATA spare parts
570601173332	BRACKET BS6	TATA spare parts
570601173334	BRACKET BS6	TATA spare parts
570601173338	BRACKET OIL SEPARATOR MTG BS6-PH2	TATA spare parts
570601175809	HOSE (OMS TO CY. HEAD COVER)	TATA spare parts
570601175813	HOSE(OILRETURNFROMOMS)TRUCK	TATA spare parts
570601175814	HOSE (OMS TO OIL SUMP) BS4	TATA spare parts
570601175815	HOSE (CYLINDER HEAD COVER TO OMS)	TATA spare parts
570601175816	BREATHER HOSE(OMS TO ATMOSPHERE)	TATA spare parts
570601175817	BREATHER HOSE (OMS TO ATMOSPHERE)TRUCK	TATA spare parts
570601175824	HOSE (CY. HEAD COVER TO OMS-LP RHD)	TATA spare parts

570601175825	HOSE (FROM OMS TO BED PLATE-LP RHD)	TATA spare parts
570601175830	HOSE BLOWBY CHC TO OIL SEPARATOR	TATA spare parts
570601175831	HOSE	TATA spare parts
570601175832	BREATHER HOSE	TATA spare parts
570601175837	HOSE OIL SEPARATOR TO OIL SUMP BS6	TATA spare parts
570601175838	HOSE BS6	TATA spare parts
570601175844	BREATHER HOSE BS6	TATA spare parts
570601175845	HOSE BLOWBY CHC TO OIL SEPARATOR BS6	TATA spare parts
570601175846	HOSE BLOWBY BS6	TATA spare parts
570601175847	HOSE BS6	TATA spare parts
570601175848	HOSE BS6	TATA spare parts
570601175849	HOSE BS6	TATA spare parts
570601175850	HOSE¿BS6	TATA spare parts
570601175852	HOSE¿BS6	TATA spare parts
570601175853	HOSE¿BS6	TATA spare parts
570601175854	HOSE OLD PART NUMBER - 570601175833 BS6	TATA spare parts
570601175855	BREATHER HOSE OLD PART NUMBER - 57060117	TATA spare parts
570601175856	HOSE BLOWBY CHC TO OIL SEPARATOR BS6	TATA spare parts
570601175857	BREATHER HOSE TUBE TO ATMOSPHERE BS6	TATA spare parts
570601175861	HOSE (OIL RETURN FROM OMS TO OIL SUMP) B	TATA spare parts
570601177702	O-RING - OIL FILLER CAP	TATA spare parts
570601177703	O RING (ASSY. DRAIN SEAL)	TATA spare parts
570601177705	O RING (OIL SEPARATOR PIPE)	TATA spare parts
570601178209	BRACKET BS6	TATA spare parts
570601179902	DIPSTICK TUBE ADAPTER	TATA spare parts
570601990101	LONG BLOCK 3L NGE BS4 BS4	TATA spare parts
570601990103	HALF BLOCK 3L NGE BS-IV	TATA spare parts
570601990107	KIT-GASKET ENGINE OVERHAUL	TATA spare parts
570601990108	KIT-SEAL ENGINE OVERHAUL	TATA spare parts
570601990109	KIT-DECARBONISING GASKET	TATA spare parts
570601990110	SET-INTAKE & EXHAUST VALVE (3LNGE BS6)	TATA spare parts
570601990113	ASSY LONG BLOCK AC BUS DOUBLE PULLEY 8PK	TATA spare parts
570601990115	HALF BLOCK 3LNGE (BUS) BS4	TATA spare parts
570601990126	VALVE GUIDE INTAKE & EXHAUST BS6	TATA spare parts
570601990128	ASSY. LONG BLOCK 3L BS3/4	TATA spare parts
570601990129	HALF BLOCK TATA ULTRA 814/39 BS-III	TATA spare parts
570601990144	HALF¿BLOCK	TATA spare parts
570601990145	ASSY LONG BLOCK NON AC SINGLE PULLEY 6PK	TATA spare parts
570601990146	LONG BLOCK ASSY BS6	TATA spare parts
570601990148	HALF BLOCK BS6	TATA spare parts
570601990149	KIT-GASKET ENGINE OVERHAUL	TATA spare parts
570601990150	KIT-ENGINE OVERHAUL SEAL BS6	TATA spare parts
570601990151	KIT-DECARBONISING GASKET BS6	TATA spare parts
570601990169	LONG BLOCK ASSY BS6	TATA spare parts
570601990172	HALF BLOCK ASSY BS6	TATA spare parts
570601990174	LONG BLOCK ASSY	TATA spare parts
570601990175	HALF BLOCK	TATA spare parts

570601990176	LONG BLOCK ASSY (BUS) 3LNGE BS-IV	TATA spare parts
570601990178	CYLINDER HEAD ASSY W/VALVES W/O INJECTOR	TATA spare parts
570601990184	ENGINE LONG BLOCK 3L_12V ULTRA TRUCK	TATA spare parts
570601990185	ENGINE LONG BLOCK 3L_12V ULTRA BUS	TATA spare parts
570601990186	ENGINE LONG BLOCK 3L_24V ULTRA BUS	TATA spare parts
570601990187	ASSY. LONG BLOCK 3L BS4 24V	TATA spare parts
570601990188	LONG BLOCK ASSY BS6-PH2	TATA spare parts
570601990190	HALF BLOCK ASSY BS6-PH2	TATA spare parts
570603107101	STONE WHEEL	TATA spare parts
570603107801	REAR SEAL	TATA spare parts
570603107802	CRANKSHAFT REAR SEAL	TATA spare parts
570603107901	CRANKSHAFT	TATA spare parts
570603107905	CRANKSHAFT 3.3L NEW GEN ENGINE(NORMAL) B	TATA spare parts
570603107909	CRANKSHAFT BS6	TATA spare parts
570603110102	ASSY. FLYWHEEL WITH RING GEAR BS4	TATA spare parts
570603110104	FLYWHEEL ASSY WITH DRIVING RING BS6	TATA spare parts
570603113201	FLYWHEEL MOUNTING BOLT	TATA spare parts
570603113706	FLYWHEEL HOUSING FOR GB550 GEAR BOX	TATA spare parts
570603113710	FLYWHEEL HOUSING BS6	TATA spare parts
570603118201	FLYWHEEL HOUSING INSPECTION WINDOW COVER	TATA spare parts
570603118205	BACK COVER PLATE FOR FLYWHEEL HOUSING	TATA spare parts
570603118801	M12 STUD FOR FLYWHEEL HOUSING(TC SIDE)	TATA spare parts
570603118802	M12 STUD FOR FLYWHEEL HOUSING(EGR SIDE)	TATA spare parts
570603120101	SET MAIN BEARING HALF U/L STD	TATA spare parts
570603120103	SET MAIN BEARING HALF U/L NORMAL	TATA spare parts
570603120105	SET-MAIN BEARING UPPER/LOWER REPAIR -I	TATA spare parts
570603120106	SET-MAIN BEARING UPPER/LOWER REPAIR -II	TATA spare parts
570603120107	SET-MAIN BEARING UPPER/LOWER REPAIR -III	TATA spare parts
570603120108	SET-MAIN BEARING UPPER/LOWER REPAIR -IV	TATA spare parts
570603120109	SET-MAIN BEARING UPPER/LOWER REP-I	TATA spare parts
570603120111	SET-MAIN BEARING UPPER/LOWER REP-III	TATA spare parts
570603123401	MAIN BEARING SHELL	TATA spare parts
570603123402	MAIN BEARING SHELL	TATA spare parts
570603123403	THRUST WASHER - STD	TATA spare parts
570603123406	MAIN BEARING UPPER SHELL - NORMAL BS6	TATA spare parts
570603123408	MAIN BEARING LOWER SHELL - NORMAL BS6	TATA spare parts
570603123419	THRUST WASHER - REPAIR I	TATA spare parts
570603123420	THRUST WASHER - REPAIR II	TATA spare parts
570603130101	ASSY.VIBRATION DAMPER	TATA spare parts
570603130105	DAMPER PULLEY 8 PK	TATA spare parts
570603130106	VIBRATION DAMPER ASSY	TATA spare parts
570603133201	HEX BOLT (ON CRANKSHAFT)	TATA spare parts
570603133202	HEX BOLT M14X1.5 -CRANKSHAFT WITH AC D	TATA spare parts
570603140101	ASSY.PISTON (FEDERAL MOGUL)	TATA spare parts
570603140104	PISTON ASSY BS6	TATA spare parts
570603140106	ASSY. OIL CONTROL RING	TATA spare parts
570603149801	TOP RING	TATA spare parts

570603149802	MIDDLE RING	TATA spare parts
570603150101	CONNECTING ROD ASSY WITH SMALL END BUSH	TATA spare parts
570603150104	SET-CONROD BEARING HALF(UPPER/LOWER)-STD	TATA spare parts
570603150105	SET-CONROD BEARING HALF(UPPER/LOWER)-NO	TATA spare parts
570603150106	SET-CONROD BEARING HALF(UPPER/LOWER)-NO	TATA spare parts
570603150107	SET-CONROD BEARING HALF(UPPER/LOWER)-NO	TATA spare parts
570603150108	CONNECTING ROD ASSY WITH BUSH & BOLT BS6	TATA spare parts
570603150116	SET-CONNECTING ROD BRG SHELL UPPER/LOWER	TATA spare parts
570603150117	SET-CONNECTING ROD BRG SHELL UPPER/LOWER	TATA spare parts
570603150118	SET-CONNECTING ROD BRG SHELL UPPER/LOWER	TATA spare parts
570603150119	SET-CONNECTING ROD BRG SHELL UPPER/LOWER	TATA spare parts
570603150120	SET-CONN ROD BRG HALF UPPER/LOWER	TATA spare parts
570603150131	SET-BEARING HALF CONNECTING ROD BS6	TATA spare parts
570603153201	BOLT CONNECTING ROD	TATA spare parts
570603153202	BOLT CONNECTING ROD BS6-PH2	TATA spare parts
570603153401	BUSH CON ROD SMALL END	TATA spare parts
570603153402	CP BEARING SHELL SET	TATA spare parts
570603153403	CP BEARING SHELL SET	TATA spare parts
570603153406	CON ROD BEARING UPPER SHELL- NORMAL BS6	TATA spare parts
570603153408	CONROD BEARING LOWER SHELL- NORMAL BS6	TATA spare parts
570603153419	BUSH CONNECTING ROD - NORMAL 1	TATA spare parts
570603153429	BEARING CONNECTING ROD UPPER BS6	TATA spare parts
570603990102	SET-PISTON RING (3L NGE BS-IV)	TATA spare parts
570603990103	SET-PISTON GRADE A STD BS3/4	TATA spare parts
570603990107	SET-THRUST WASHER 3LNGE BS6	TATA spare parts
570603990108	SET-CONNECTING ROD/BUSH 3LNGE BS-IV	TATA spare parts
570603990111	SET-PISTON RING (3L NGE BS-IV) -REPAIR I	TATA spare parts
570603990112	SET-PISTON RING (3L NGE BS-IV) -REPAIR I	TATA spare parts
570603990113	SET-PISTON RING (3L NGE BS-IV) -REPAIR I	TATA spare parts
570603990114	SET-PISTON ASSY GRADE A REPAIR-I	TATA spare parts
570603990115	SET-PISTON ASSY GRADE A REPAIR-II	TATA spare parts
570603990116	SET-PISTON ASSY GRADE A REPAIR-III	TATA spare parts
570603990117	SET-PISTON ASSY GRADE A REPAIR-I	TATA spare parts
570603990118	SET-PISTON ASSY GRADE A REPAIR-II	TATA spare parts
570603990119	SET-PISTON ASSY GRADE A - REPAIR-III	TATA spare parts
570603990122	SET-PISTON ASSY WITH PIN & CIRCLIP	TATA spare parts
570603990139	SET-PISTON RING BS6	TATA spare parts
570603990141	SET-BEARING HALF CONNECTING ROD BS6	TATA spare parts
570603990155	SET-PISTON ASSY GRADE A BS6	TATA spare parts
570603990156	SET-PISTON ASSY GRADE B BS6	TATA spare parts
570603990157	SET-PISTON ASSY GRADE C BS6	TATA spare parts
570605100101	ASSY. CYL. HEAD WITH CAMCARRIER & CAMCAP	TATA spare parts
570605100109	CYL. HEAD ASSY W/CAM CARRIER W/O VALVES	TATA spare parts
570605100110	CYL HEAD ASSY W/O VALVES (SUITABLE FOR G	TATA spare parts
570605100111	CAM CARRIER	TATA spare parts
570605103201	CAM CARRIER BOLT	TATA spare parts
570605103801	CAM SHAFT CARRIER	TATA spare parts



570605103802	CAM CAP FRONT	TATA spare parts
570605103803	CAM CAP (MID & REAR)	TATA spare parts
570605103805	CAMSHAFT CARRIER	TATA spare parts
570605107701	ORING (FOR CAMSHAFT CARRIER)	TATA spare parts
570605107901	TRAILING CAMSHAFT	TATA spare parts
570605107902	LEADING CAMSHAFT	TATA spare parts
570605107903	TRAILING CAMSHAFT BS6	TATA spare parts
570605110101	TENSIONER HYDRAULIC BS4	TATA spare parts
570605110102	TIMING CHAIN KIT	TATA spare parts
570605110106	TIMING CHAIN LAYOUT	TATA spare parts
570605110107	TENSIONER HYDRAULIC BS6	TATA spare parts
570605110108	TENSIONER HYDRAULIC BS6	TATA spare parts
570605113201	BOLT FOR PRIMARY AND SECONDARY TENSIONER	TATA spare parts
570605113202	BOLT FOR CHAIN GUIDE PRIMARY	TATA spare parts
570605113203	BOLT FOR SECONDARY CHAIN GUIDE	TATA spare parts
570605113204	BOLT FOR MECHANICAL TENSIONER & PRIMARY	TATA spare parts
570605117801	O-RING CRANKSHAFT SPROCKET	TATA spare parts
570605118602	SPACER (HYD TENSIONER TO CYL HEAD)	TATA spare parts
570605118901	SPROCKET CRANKSHAFT BS4	TATA spare parts
570605118902	SPROCKET FIP	TATA spare parts
570605118903	SPROCKET CAMSHAFT	TATA spare parts
570605118906	SPROCKET OIL PUMP BS6	TATA spare parts
570605118907	SPROCKET CRANKSHAFT BS6	TATA spare parts
570605118908	SPROCKET FIP BS6	TATA spare parts
570605118909	SPROCKET CAMSHAFT BS6	TATA spare parts
570605119901	CHAIN CRANKSHAFT TO HP PUMP	TATA spare parts
570605119902	CHAIN HP PUMP TO CAMSHAFT	TATA spare parts
570605119903	CHAIN GUIDE	TATA spare parts
570605119905	PRIMARY ARM ASSY.(TENSIONER LOWER)	TATA spare parts
570605119906	SECONDARY ARM ASSY.(TENSIONER UPPER)	TATA spare parts
570605119907	BUSH CHAIN BS6	TATA spare parts
570605119908	BUSH CHAIN BS6	TATA spare parts
570605119909	PRIMARY ARM ASSY BS6	TATA spare parts
570605119910	SECONDARY ARM ASSY BS6	TATA spare parts
570605119911	CHAIN GUIDE BS6	TATA spare parts
570605119912	CHAIN GUIDE BS6	TATA spare parts
570605128701	VALVE SPRING	TATA spare parts
570605128702	RETAINER VALVE SPRING	TATA spare parts
570605129201	WASHER VALVE SPRING	TATA spare parts
570605129901	INLET VALVE	TATA spare parts
570605129902	EXHAUST VALVE	TATA spare parts
570605129903	VALVE LOCK HALF	TATA spare parts
570605129904	INTAKE VALVE BS6-PH2	TATA spare parts
570605129905	EXHAUST VALVE BS6	TATA spare parts
570605140101	ASSY. ROCKER SHAFT WITH CORE PLUG	TATA spare parts
570605140103	ROCKER ARM ASSY- JTKET(FORGING)	TATA spare parts
570605140104	ROCKER ARM ASSY BS6	TATA spare parts

570605143801	FRONT COVER	TATA spare parts
570605143805	COVER PLATE (FRONT COVER)	TATA spare parts
570605143808	COVER FRONT BS6	TATA spare parts
570605145401	CAM SENSOR WHEEL BS4	TATA spare parts
570605146701	LOCKING PIN (ROCKER SHAFT)	TATA spare parts
570605147701	O RING (FRONT COVER TO BLOCK)	TATA spare parts
570605147702	O RING (COVER PLATE)	TATA spare parts
570605147703	O RING (COVER PLATE)	TATA spare parts
570605147802	FRONT SEAL	TATA spare parts
570605147803	FRONT SEAL BS3/4	TATA spare parts
570605148601	ROCKER WASHER (MINIMUM THICKNESS)	TATA spare parts
570605990101	KIT SPARE GR 05 LONG BLK 3LNGE BS-IV	TATA spare parts
570607100101	ASSY. HP PUMP BS3/4	TATA spare parts
570607100104	HP PUMP ASSY BS6	TATA spare parts
570607140101	FUEL PRESSURE LINE (PUMP TO RAIL) BS4	TATA spare parts
570607140102	COMMON RAIL ASSY.(1800 BAR)	TATA spare parts
570607140109	SET-ASSY. HP LINES BS3/4	TATA spare parts
570607140111	HP PIPE ASSY FIP TO RAIL BS6	TATA spare parts
570607140112	HP PIPE ASSY RAIL TO INJECTOR BS6	TATA spare parts
570607140113	HP PIPE ASSY RAIL TO INJECTOR BS6	TATA spare parts
570607140114	HP PIPE ASSY RAIL TO INJECTOR BS6	TATA spare parts
570607140115	HP PIPE ASSY RAIL TO INJECTOR BS6	TATA spare parts
570607140120	ASY. LEAK OFF LINE	TATA spare parts
570607140123	LEAK OFF PIPE ASSY	TATA spare parts
570607140126	COMMON RAIL ASSY WITH PRESSURE SENSOR BS	TATA spare parts
570607140127	ASSY.LEAK OFF LINE	TATA spare parts
570607140129	LEAK OFF PIPE ASSY	TATA spare parts
570607140133	HP PIPE ASSY FIP TO RAIL BS6	TATA spare parts
570607140134	HP PIPE ASSY RAIL TO INJECTOR BS6	TATA spare parts
570607140135	HP PIPE ASSY RAIL TO INJECTOR BS6	TATA spare parts
570607140136	HP PIPE ASSY RAIL TO INJECTOR BS6	TATA spare parts
570607140137	HP PIPE ASSY RAIL TO INJECTOR BS6	TATA spare parts
570607140138	SET-HP PIPE ASSY BS6	TATA spare parts
570607144201	CLAMP	TATA spare parts
570607144203	CLAMP LEAK OFF LINE	TATA spare parts
570607147701	LEAK OFF VALVE BS4	TATA spare parts
570607147702	LEAK OFF VALVE	TATA spare parts
570607148601	SPACER RAIL MTG BS6	TATA spare parts
570609110101	PRIMING PUMP ASSY	TATA spare parts
570609110102	FUEL FILTER ASSY	TATA spare parts
570609110104	HEAD & FUEL-WATER SEPARATOR ASSY.	TATA spare parts
570609110106	FUEL FILTER ELEMENT (SPINON) BS3/4	TATA spare parts
570609110107	HEAD & FUEL FILTER ASY	TATA spare parts
570609110108	FUEL WATER SEPARATOR SPIN ON BS3/4	TATA spare parts
570609110113	DOSER UNIT ASSY BS6	TATA spare parts
570609110114	DOSER UNIT ASSY BS6	TATA spare parts
570609110121	FUEL FILTER ASSY WITH BRACKET BS6	TATA spare parts

570609110122	FUEL FILTER ASSY (PROTEKT FILTER 12 VOLT	TATA spare parts
570609110123	FUEL FILTER ASSY (FINE FILTER 12 VOLT) B	TATA spare parts
570609110125	FUEL FILTER ELEMENT ASSY BS6	TATA spare parts
570609110126	FUEL FILTER ELEMENT ASSY BS6	TATA spare parts
570609110127	OVER FLOW VALVE ASSY BS6	TATA spare parts
570609110128	FUEL FILTER ASSY WITH BRACKET BS6	TATA spare parts
570609110129	FUEL FILTER ASSY WITH BRACKET BS6	TATA spare parts
570609110130	FUEL FILTER ASSY WITH BRACKET BS6	TATA spare parts
570609110135	WATER SENSOR ASSY FUEL FILTER BS6	TATA spare parts
570609116801	BANJO BS6	TATA spare parts
570609116802	BANJO BS6	TATA spare parts
570609119901	ASSY. FUEL WATER SEPARATOR BS3/4	TATA spare parts
570609120103	LEAK OFF PIPE ASSY INJECTOR BS6	TATA spare parts
570609120104	OVERFLOW PIPE ASSY FIP TO ACCUMULATOR BS	TATA spare parts
570609120105	OVERFLOW PIPE ASSY COMMON RAIL BS6	TATA spare parts
570609120107	BRACKET FUEL ACCUMULATOR SUPPORT BS6	TATA spare parts
570609120108	LEAK OFF PIPE ASSY INJECTOR BS6	TATA spare parts
570609128201	SUPPORT BRACKET BS6	TATA spare parts
570609130111	AIR FILTER MTNG PRESSED BKT	TATA spare parts
570609130122	ASSY AIS FOR 7.5T TRUCK	TATA spare parts
570609130127	FL. AIR INTAKE SYSTEM (LPO RHD BUS)	TATA spare parts
570609130134	AIS CLEANSIDE HOSE ASSY (LPO BUS)	TATA spare parts
570609130140	HOSE REDUCER	TATA spare parts
570609130141	AIR SNORKEL ASSY (DIRTY SIDE-7.5T TRUCK)	TATA spare parts
570609130142	AIR PIPE & BRACKET ASSY (7.5T TRUCK)	TATA spare parts
570609130143	DUCT ASSY (DIRTY SIDE-7.5T TRUCK)	TATA spare parts
570609130144	AIR PIPE ASSY (7.5T TRUCK)	TATA spare parts
570609130146	AIR FILTER ASSY WITH SNORKEL	TATA spare parts
570609130152	AIR CLEANER ASSY	TATA spare parts
570609130154	AIR CLEANER ASSY (LPO BUS)	TATA spare parts
570609130161	SNORKEL MTNG BRACKET (LPO BUS)	TATA spare parts
570609130162	RESTRICTION INDICATOR PIPE ASSY	TATA spare parts
570609130179	PIPE ASSY WITH TUBE	TATA spare parts
570609130181	PIPE ASSY WITH BRACKET	TATA spare parts
570609130188	DUCT INTAKE SYSTEM	TATA spare parts
570609130194	PRE CLEANER	TATA spare parts
570609130195	BRACKET ASSY	TATA spare parts
570609130232	KIT-AIR INTAKE SYSTEM BS6	TATA spare parts
570609130234	KIT-AIR FILTER ASSY	TATA spare parts
570609130236	PIPE ASSY	TATA spare parts
570609130239	KIT-AIR INTAKE ASSY BS6	TATA spare parts
570609130241	KIT-AIR INTAKE SYSTEM BS6	TATA spare parts
570609130246	KIT-AIR INTAKE ASSY BS6	TATA spare parts
570609130250	BRACKETASSY BS6	TATA spare parts
570609130253	KIT-AIRINTAKEASSY BS6	TATA spare parts
570609130255	PIPEASSYAIRFILTERTOTC BS6	TATA spare parts
570609130259	PIPE ASSY AIR FILTER TO TC BS6	TATA spare parts

570609130260	PIPE ASSY AIR FILTER TO TC BS6	TATA spare parts
570609130266	REDUCERHOSE BS6	TATA spare parts
570609130267	AIRINTAKEPIPE BS6	TATA spare parts
570609130270	SERVICEINDICATORASSY BS6	TATA spare parts
570609130273	BRACKET AIRINTAKEMTG(LPT1412/1512SLPCAB)	TATA spare parts
570609130274	KIT-AIR INTAKE SYSTEM BS6	TATA spare parts
570609130277	RESTRICTION INDICATOR PIPE ASSY BS6	TATA spare parts
570609130279	PIPE AND BRACKET ASSY BS6	TATA spare parts
570609130284	ISOLATOR VIBRATION BS6	TATA spare parts
570609130290	PIPE ASSY AIR INTAKE SYSTEM BS6	TATA spare parts
570609130291	RAIN HOOD SNORKEL BS6	TATA spare parts
570609130292	KIT-AIR INTAKE SYSTEM BS6-PH2	TATA spare parts
570609130298	KIT-AIR INTAKE ASSY BS6-PH2	TATA spare parts
570609130310	PIPE ASSY WITH BRACKET BS6-PH2	TATA spare parts
570609133330	AIR FILTER CLEAN SIDE BKT	TATA spare parts
570609133354	BRACKET AIR DUCT MTG BS6	TATA spare parts
570609133360	BRACKET BS6	TATA spare parts
570609133361	BRACKET BS6	TATA spare parts
570609133374	BRACKET ASSY BS6-PH2	TATA spare parts
570609133378	BRACKET AIR INTAKE MTG BS6-PH2	TATA spare parts
570609134201	HOSE CLAMP T BOLT	TATA spare parts
570609135804	BUS AIS CLEAN SIDE HOSE	TATA spare parts
570609135805	AIR DUCT (CLEAN SIDE-7.5T TRUCK)	TATA spare parts
570609135806	HOSE REDUCER (DIRTY SIDE)-LP G2 BUS	TATA spare parts
570609135810	HOSE (AIS LP G2 BUS)	TATA spare parts
570609135811	HOSE REDUCER	TATA spare parts
570609135819	HOSE REDUCER ELBOW	TATA spare parts
570609135828	HOSEAIRFILTERPIPETOTC BS6	TATA spare parts
570609135829	HOSEAIRCLEANER BS6	TATA spare parts
570609135830	HOSEAIRFILTERPIPE BS6	TATA spare parts
570609135834	HOSEASSYAIRFILTEROUTLET BS6	TATA spare parts
570609135836	REDUCER HOSE BS6	TATA spare parts
570609135837	HOSEASSYAIRFILTEROUTLET BS6	TATA spare parts
570609135839	HOSE REDUCER BS6	TATA spare parts
570609135840	HOSE REDUCER ELBOW BS6	TATA spare parts
570609135842	RUBBER SLEEVE SNORKEL MTG BS6	TATA spare parts
570609135846	HOSE ASSY PIPE TO TC END BS6-PH2	TATA spare parts
570609136302	AIR INTAKE PIPE ASSY A/F TO T/C BS6	TATA spare parts
570609136303	AIRINTAKEPIPEASSYA/FTOT/C BS6	TATA spare parts
570609136305	AIRINTAKEPIPEASSYA/FTOT/C BS6	TATA spare parts
570609136307	DUCT AIR INLET BS6	TATA spare parts
570609136911	PIPEASSYAIRFILTERTOTC BS6	TATA spare parts
570609136912	PIPE ASSY SNORKEL TO AIR FILTER BS6	TATA spare parts
570609139901	AIR MASS FLOW SENSOR BS4	TATA spare parts
570609140107	KIT & LAYOUT-AIR INTAKE SYSTEM BS6	TATA spare parts
570609140108	BRACKET WITH SPACER BS6	TATA spare parts
570612000101	AFTER TREATMENT SYSTEM ASSY BS6-PH2	TATA spare parts

570612000104	AFTER TREATMENT SYSTEM ASSY BS6-PH2	TATA spare parts
570612000106	AFTER TREATMENT SYSTEM ASSY BS6	TATA spare parts
570612000107	AFTER TREATMENT SYSTEM ASSY BS6	TATA spare parts
570612000108	AFTER TREATMENT SYSTEM ASSY BS6	TATA spare parts
570612100101	DIESEL OXIDATION CATALYST ASSY	TATA spare parts
570612100102	CANNING ASSY DIESEL OXIDATION CATALYST B	TATA spare parts
570612140101	BRACKET BS6-PH2	TATA spare parts
570612143301	SUPPORT BRACKET BS6-PH2	TATA spare parts
570612143302	SUPPORT BRACKET BS6-PH2	TATA spare parts
570612143303	SUPPORT BRACKET BS6-PH2	TATA spare parts
570613113301	AIR COMPRESSOR SUPPORT BRACKET	TATA spare parts
570613113306	SUPPORT BRACKET(AIR SUPPLY LINE LP G2)	TATA spare parts
570613113308	SUPPORT BARCKET AIR COMPRESSOR REAR	TATA spare parts
570613113701	AIR COMPRESSOR MOUNTING BRACKET	TATA spare parts
570613130110	ASSY. AIR SUPPLY LINE (160CC AIR COMP)	TATA spare parts
570613130113	PIPE ASSY WITH FERRULE & CAP NUT	TATA spare parts
570613130123	AIR SUPPLY PIPE ASSY	TATA spare parts
570613130128	AIR SUPPLY PIPE ASSY AIR COMPRESSOR BS6	TATA spare parts
570613130133	AIR SUPPLY PIPE ASSY	TATA spare parts
570613130134	AIR SUPPLY PIPE ASSY BS6	TATA spare parts
570613130137	AIR SUPPLY PIPE ASSY BS6	TATA spare parts
570613130149	ASSY AIR COMPRESSOR INLET LINE BS6	TATA spare parts
570613130150	AIR SUPPLY PIPE ASSY BS6	TATA spare parts
570613130151	AIR SUPPLY PIPE ASSY AIR COMPRESSOR BS6	TATA spare parts
570613130155	AIR SUPPLY PIPE ASSY BS6	TATA spare parts
570613130160	AIR SUPPLY PIPE ASSY BS6-PH2	TATA spare parts
570613130161	AIR SUPPLY PIPE ASSY	TATA spare parts
570613130162	AIR SUPPLY PIPE ASSY BS6-PH2	TATA spare parts
570613133301	SUPPORT BKT (AIR COMP PIPE SUPPORT) BS6	TATA spare parts
570614100102	PIPE ASSY TC OUT TO INTERCOOLER	TATA spare parts
570614103801	INTAKE MANIFOLD	TATA spare parts
570614103803	AIR INTAKE PIPE [ON INTAKE MANIFOLD]	TATA spare parts
570614103810	HOUSING BS6	TATA spare parts
570614103811	INTAKE MANIFOLD BS6	TATA spare parts
570614103812	AIR INTAKE PIPE INTAKE MANIFOLD BS6	TATA spare parts
570614103816	AIR INTAKE PIPE INTAKE MANIFOLD	TATA spare parts
570614103817	AIR INTAKE PIPE INTAKE MANIFOLD BS6	TATA spare parts
570614103822	AIR INTAKE PIPE INTAKE MANIFOLD BS6-PH2	TATA spare parts
570614103825	INTAKE MANIFOLD BS6-PH2	TATA spare parts
570614103827	AIR INTAKE PIPE INTAKE MANIFOLD	TATA spare parts
570614105303	GASKET INTAKE MANIFOLD BS4	TATA spare parts
570614105304	GASKET INTAKE ELBOW	TATA spare parts
570614105306	GASKET	TATA spare parts
570614105810	TC OUTLET HOSE	TATA spare parts
570614110104	ASSY. EGR VALVE (PIERBURG) BS3/4	TATA spare parts
570614110112	TUBE EGR (EX.MANIFOLD TO EGR VALVE BS4	TATA spare parts
570614110115	ASSY EGR COOLER & VALVE	TATA spare parts

570614110134	HOSE TC TO EVRV (BUS TC END)	TATA spare parts
570614110135	HOSE EVRV TO TC (BUS)	TATA spare parts
570614110136	HOSE ASSY EVRV TO TURBOCHARGER	TATA spare parts
570614110140	BRACKET (VACUUM RESERVIOR)	TATA spare parts
570614110152	ASSY.EGR COOLER & VALVE (24V-BWES)	TATA spare parts
570614110153	VACUUM MODULATOR WITH FILTER 24V	TATA spare parts
570614110156	ASSY. EGR MIXER BS4	TATA spare parts
570614110173	CATCON ASSY	TATA spare parts
570614110183	EGR COOLER & VALVE ASSY BS6	TATA spare parts
570614110184	EGR COOLER & VALVE ASSY BS6	TATA spare parts
570614110185	AFTER TREATMENT SYSTEM ASSY BS6	TATA spare parts
570614110186	DOC ASSY BS6	TATA spare parts
570614110187	DPF ASSY BS6	TATA spare parts
570614110191	DEF INJECTOR (LPO -NAC) BS6	TATA spare parts
570614110192	PUMP ASSY UREA DOSE BS6	TATA spare parts
570614110193	THROTTLE VALVE ASSY BS6	TATA spare parts
570614110202	AFTER TREATMENT SYSTEM ASSY BS6	TATA spare parts
570614110204	EGR VALVE ASSY BS6	TATA spare parts
570614110205	EGR VALVE ASSY BS6	TATA spare parts
570614110209	AFTER TREATMENT SYSTEM ASSY	TATA spare parts
570614110211	EGR MIXTURE BS6	TATA spare parts
570614110212	CANNINGASSYDOC BS6	TATA spare parts
570614110213	DPF ASSY - LPT/LP/ULTRA 3.3L BS6	TATA spare parts
570614110214	SCR W/MIXER ASSY - LPT/LP/ULTRA 3.3L BS6	TATA spare parts
570614110215	PIPEASSY BS6	TATA spare parts
570614110216	PIPEASSY BS6	TATA spare parts
570614110217	CANNING ASSY WITH MIXER SCR BS6	TATA spare parts
570614110218	CANNING ASSY WITH MIXER SCR BS6	TATA spare parts
570614110223	BRACKET BS6	TATA spare parts
570614110224	BRACKET BS6	TATA spare parts
570614110226	BRACKET BS6	TATA spare parts
570614110227	BRACKET BS6	TATA spare parts
570614110228	DP TUBEHIGH PRESSURE BS6	TATA spare parts
570614110229	DP TUBELOW PRESSURE BS6	TATA spare parts
570614110230	BRACKET ASSY WITH SENSOR TABLE DP MTG BS	TATA spare parts
570614110236	EGR PIPE EGR PIPE TO EGR VALVE BS6-PH2	TATA spare parts
570614110237	TUBE ASSY EGR BS6-PH2	TATA spare parts
570614110239	EGR MIXTURE ASSY BS6-PH2	TATA spare parts
570614110243	EGR VALVE BS6-PH2	TATA spare parts
570614110252	RUBBER GROMMET BS6	TATA spare parts
570614113301	TC AIR INTAKE ELBOW SUPPORT BRACKET BACK	TATA spare parts
570614113302	TC AIR INTAKE ELBOW SUPPORT BRACKET	TATA spare parts
570614113312	SUPPORT BRACKET (570614113719) BS6	TATA spare parts
570614113314	BRACKET AIR INTAKE ELBOW BS6	TATA spare parts
570614113318	BRACKET ASSY BS6-PH2	TATA spare parts
570614113701	EXHAUST MANIFOLD	TATA spare parts
570614113706	INTERMEDIATE PIPE	TATA spare parts

570614113708	INTERMEDIATE PIPE SUPPORT BKT.	TATA spare parts
570614113709	INT PIPE ASSY TC TO EXH PIPE	TATA spare parts
570614113711	BRACKET INTERMEDIATE PIPE	TATA spare parts
570614113716	EXHAUST ELBOW BS6	TATA spare parts
570614113717	ADAPTER BS6	TATA spare parts
570614113718	BRACKET EXHAUST ELBOW SUPPORT BS6	TATA spare parts
570614113721	EGR PIPE ASSY EXH MANI.-EGR PIPE BS6-PH2	TATA spare parts
570614113801	TC AIR INTAKE ELBOW (TRUCK)	TATA spare parts
570614113805	AIR INLET ELBOW LPO BUS	TATA spare parts
570614113806	TC AIR INLET ELBOW LP RHD	TATA spare parts
570614113813	AIR INTAKE ELBOW BS6	TATA spare parts
570614113814	AIR INTAKE ELBOW BS6	TATA spare parts
570614113815	AIR INTAKE ELBOW BS6	TATA spare parts
570614113819	AIR INTAKE ELBOW BS6	TATA spare parts
570614114204	CLAMP (LPO -NAC) BS6	TATA spare parts
570614114301	CLIP BS6	TATA spare parts
570614115309	EXHAUST MANIFOLD GASKET ( LCV ) BS4	TATA spare parts
570614115311	GASKET EGR PIPE TO EGR VALVE BS4	TATA spare parts
570614115314	GASKET BS6	TATA spare parts
570614115807	HOSE T CONNECTOR TO EVRV	TATA spare parts
570614115808	HOSE NRV TO VACUUM PUMP	TATA spare parts
570614115817	RUBBER HOSE BS6	TATA spare parts
570614115818	RUBBER HOSE BS6	TATA spare parts
570614118205	HEAT SHIELD (INTERMEDIATE PIPE)	TATA spare parts
570614118206	HEAT SHIELD (TURBOCHARGER)	TATA spare parts
570614118207	HEAT SHIELD (EXHAUST MANIFOLD)	TATA spare parts
570614118210	HEAT SHIELD ASSY EXHAUST MANIFOLD BS6	TATA spare parts
570614118211	HEAT SHIELD ASSY TURBOCHARGER BS6	TATA spare parts
570614118212	HEAT SHIELD ASSY EXHAUST ELBOW BS6	TATA spare parts
570614118214	HEAT SHIELD ASSY TURBOCHARGER	TATA spare parts
570614118217	HEAT SHIELD ASSY BS6	TATA spare parts
570614118218	HEAT SHIELD ASSY BS6	TATA spare parts
570614118801	STUD(FOR TC TOP MOUNTING)	TATA spare parts
570614118802	STUD (FOR TC BOTTOM MOUNTING)	TATA spare parts
570614119901	QUICK CONNECTOR STRAIGHT	TATA spare parts
570614119902	VACUUM LINES HOSE CLAMP	TATA spare parts
570614119903	V-CLAMP ASSY BS6	TATA spare parts
570614119904	BRACKET ASSY WITH SENSOR TABLE DPMTG BS6	TATA spare parts
570614119912	CONNECTOR BS6	TATA spare parts
570614510112	ASSY. TURBOCHARGER BS4	TATA spare parts
570614510113	ASSY. TURBOCHARGER BS4	TATA spare parts
570614510120	ASSY. TURBOCHARGER DE-SPEED BUS	TATA spare parts
570614510121	ASSY. TURBOCHARGER BS3/4	TATA spare parts
570614510123	ASSY. TC OIL RETURN LINE BS4	TATA spare parts
570614510127	TURBOCHARGER BS6	TATA spare parts
570614510129	OIL RETURN PIPE ASSY TURBOCHARGER BS6	TATA spare parts
570614510130	TURBOCHARGER BS6	TATA spare parts

570614510131	TURBOCHARGER ASSY BS6	TATA spare parts
570614510133	TURBOCHARGER ASSY BS6-PH2	TATA spare parts
570614510135	TURBOCHARGER ASSY BS6-PH2	TATA spare parts
570614515309	GASKET (TC AIR INTAKE)	TATA spare parts
570614515310	GASKET (TC TO INT ELBOW)	TATA spare parts
570614515311	GASKET (EXHAUST MANIFOLD TO TC)	TATA spare parts
570614515312	GASKET EXHAUST MANIFOLD TO EGR PIPE BS4	TATA spare parts
570614515313	GASKET BV43 TC OUT	TATA spare parts
570614515314	GASKET EXHAUST MANIFOLD TO TC BS4	TATA spare parts
570614515315	GASKET AIR INTAKE ELBOW TO TURBOCHARGER	TATA spare parts
570614515317	GASKET TURBOCHARGER AIR INTAKE BS6	TATA spare parts
570614515319	GASKET TURBOCHARGER BS6	TATA spare parts
570614515320	GASKET EXHAUST MANIFOLD TO TC BS6	TATA spare parts
570614515805	RUBBER HOSE(TC OIL DRAIN HOSE)	TATA spare parts
570614600114	ASSY. PIPE TC TO IC (TRUCK)	TATA spare parts
570614600122	ASSY. FAB. TC TO IC PIPE BUS	TATA spare parts
570614600130	SUPPORT BRACKET ASSY TCIC PIPE	TATA spare parts
570614600140	BRACKET ASSY-TC TO IC PIPE MTG BS6	TATA spare parts
570614603309	TC-IC PIPE SUPPORT FROM AIR COMP BKT	TATA spare parts
570614603310	TC-IC SUPPORT BKT (BANGLE BKT)	TATA spare parts
570614603311	BRACKET (TC TO IC PIPE SUPPORT)	TATA spare parts
570614603327	BRACKET BS6	TATA spare parts
570614603330	SUPPORT BRACKET BS6	TATA spare parts
570614603333	CLAMP-P-TYPE BS6	TATA spare parts
570614603335	BRACKET BS6	TATA spare parts
570614603804	PIPE TC TO IC BS6	TATA spare parts
570614603807	ADAPTER-TURBOCHARGER COMPRESSOR-OUTLET	TATA spare parts
570614603809	PIPE TC ADAPTER TO INTERCOOLER BS6	TATA spare parts
570614603810	ELBOW BS6	TATA spare parts
570614605814	HUMP HOSE IC TO AIR INTAKE ELBOW BS6	TATA spare parts
570614605815	HOSE ASSY TURBOCHARGER TO INTERCOOLER BS6	TATA spare parts
570614605818	HOSE BS6	TATA spare parts
570614605820	HUMP HOSE	TATA spare parts
570614606920	PIPE TC OUTLET TO INTERCOOLER BS6	TATA spare parts
570614606923	PIPE TC TO INTERCOOLER BS6	TATA spare parts
570614606924	PIPE-TC TO INTERCOOLER BS6	TATA spare parts
570614990106	KIT-UREA PUMP FASTENERS SUPPLY MODULE BS6	TATA spare parts
570614990107	KIT-UREA PUMP ASSY SUPPLY MODULE BS6	TATA spare parts
570615140102	ASSY AUTO TENSIONER	TATA spare parts
570615140103	ASSY BRACKET (ALTERNATOR MOUNTING)	TATA spare parts
570615140106	ALTERNATOR & AUTO TENSIONER BKT ASSLY	TATA spare parts
570615140109	AUTO TENSIONER FOR 8PK BELT GATES	TATA spare parts
570615140115	3LNGE/BRACKET ASSY ALTERNATOR MTG	TATA spare parts
570615147903	BRACKET ALTERNATOR BKT TOP SUPPORT	TATA spare parts
570615147905	BRACKET ALTERNATOR BKT TOP SUPPORT	TATA spare parts
570615220101	OIL PRESSURE SWITCH BS6-PH2	TATA spare parts
570615240101	SENSOR PARTICULATE MATTER BS6-PH2	TATA spare parts



570615240102	NOX SENSOR BS6-PH2	TATA spare parts
570615240103	SENSOR UREA QUALITY BS6-PH2	TATA spare parts
570615400101	NOX SENSOR (LPO -NAC) BS6	TATA spare parts
570615400102	PFM SENSOR	TATA spare parts
570615400103	TEMPERATURE SENSOR BS6	TATA spare parts
570615400104	DEF QUALITY SENSOR 250KBPS BS6	TATA spare parts
570616109901	CRANK SPEED SENSOR BS4	TATA spare parts
570616109902	CAM SHAFT POSITION SENSOR BS4	TATA spare parts
570616109903	T-MAP SENSOR BS4	TATA spare parts
570618100101	OIL PUMP ASSY	TATA spare parts
570618100103	TENSIONER ASSY. MECHANICAL BS4	TATA spare parts
570618100104	OIL PUMP ASSY BS6	TATA spare parts
570618107701	O RING (OIL PUMP-BED PLATE)	TATA spare parts
570618109901	CHAIN CRANK SHAFT TO OIL PUMP	TATA spare parts
570618130102	OIL FILTER ELEMENT (SPINON) BS3/4	TATA spare parts
570618130105	OIL FILTER ASSY BS6	TATA spare parts
570618130107	OIL FILTER ASSY BS6-PH2	TATA spare parts
570618130109	OIL FILTER HEAD ASSY BS6-PH2	TATA spare parts
570618133801	OIL FILTER HEAD (SPIN ON TYPE)	TATA spare parts
570618150103	ASSEMBLY STRAINER (OIL PUMP)	TATA spare parts
570618150106	ASSY. STRAINER COMPLETE ( BUS )	TATA spare parts
570618150116	STRAINER ASSY	TATA spare parts
570618150118	STRAINER ASSY BS6-PH2	TATA spare parts
570618155301	GASKET (STRAINER BOSS-OIL PUMP)	TATA spare parts
570618157702	O RING (OIL FILTER HEAD-BLOCK)	TATA spare parts
570618170101	PISTON COOLING NOZZLE	TATA spare parts
570618170102	OIL COOLER ASSY BS6	TATA spare parts
570618170105	OIL COOLER ASSY-OFFER DRG	TATA spare parts
570618170107	FLEXIBLE OIL SUPPLY LINE	TATA spare parts
570618170108	FLEXIBLE OIL SUPPLY LINE RESERVOIR TO TC	TATA spare parts
570618170109	FLEXIBLE OIL SUPPLY LINE 130	TATA spare parts
570618170117	OIL COOLER (WITH 570618170116)	TATA spare parts
570618170122	OIL SUPPLY LINE ASSY AIR COMPRESSOR	TATA spare parts
570618170124	NOZZLE ASSY PISTON COOLING	TATA spare parts
570618170125	TC OIL SUPPLY LINE ASSY BS6	TATA spare parts
570618170126	NOZZLE ASSY PISTON COOLING	TATA spare parts
570618170127	PIPE ASSY AIR COMP OIL SUPPLY BS6	TATA spare parts
570618173703	OIL RESERVIOR(SUIT.FOR AIR COMPRESSOR)	TATA spare parts
570618173705	OIL RESERVOIR (FOR AIR COMP. JNNURM)	TATA spare parts
570618174202	CLAMP FOR AIR COMP OIL RETURN HOSE	TATA spare parts
570618175302	GASKET (PISTON COOLING NOZZLE)	TATA spare parts
570618179901	ADAPTOR (FOR OIL COOLER & OIL FILTER)	TATA spare parts
570618179903	PIPE UNION BOLT	TATA spare parts
570618179904	BANJO BOLT	TATA spare parts
570618179905	BANJO 22	TATA spare parts
570620100101	ASSY. WATER PUMP BS3/4	TATA spare parts
570620100103	WATER PUMP ASSY -8PK MAIN BELT DRIVE	TATA spare parts

570620100104	WATER PUMP ASSY 3.3L NGE BS-IV BS6	TATA spare parts
570620100109	WATER PUMP ASSY BS6-PH2	TATA spare parts
570620107701	O-RING WATER PUMPBS6	TATA spare parts
570620120101	THERMOSTAT ELEMENT BS4	TATA spare parts
570620120103	ASSY THERMOSTAT HOUSING	TATA spare parts
570620120105	COVER ASSY THERMOSTAT	TATA spare parts
570620120107	ASSY. INLET PIPE	TATA spare parts
570620120123	CONNECTION ASSLY FOR 3L NGE WITH AC	TATA spare parts
570620120125	COOLANT PIPE ASSY	TATA spare parts
570620120129	COOLANT PIPE ASSY HVAC	TATA spare parts
570620120134	T-CONNECTOR ASSY 3L NGE 8PK BELT IN HVAC	TATA spare parts
570620120135	ASSEMBLY T-CONNECTOR	TATA spare parts
570620120136	T-CONNECTOR ASSY	TATA spare parts
570620120138	THERMOSTAT ELEMENT	TATA spare parts
570620120190	COOLANT PIPE ASSY	TATA spare parts
570620120201	COOLANT PIPE ASSY	TATA spare parts
570620120202	SPIDER HOSE ASSY	TATA spare parts
570620120203	COOLANT HOSE ASSY AIR COMPRESSOR RETURN	TATA spare parts
570620120216	THERMOSTAT ELEMENT BS6	TATA spare parts
570620120217	THERMOSTAT ELEMENT BS6	TATA spare parts
570620120223	COOLANT PIPE ASSY	TATA spare parts
570620123310	CRIMP HOSE SUP. BKT (EGR TO WIE)	TATA spare parts
570620123317	BRACKET EGR LINE	TATA spare parts
570620123805	THERMOSTAT BODY ASSY W/O TUBE	TATA spare parts
570620123806	THERMOSTAT COVER	TATA spare parts
570620123807	THERMOSTAT HOUSING BS6	TATA spare parts
570620125303	WATER INLET GASKET	TATA spare parts
570620125304	GASKET THERMOSTAT HOUSING BS4	TATA spare parts
570620125803	HOSE (CYLINDER BLOCK TO OIL COOLER)	TATA spare parts
570620125810	"HOSE, EGR TO WATER INTAKE ELBOW"	TATA spare parts
570620125813	"HOSE, EGR COOLER TO COOLANT PIPE"	TATA spare parts
570620125817	HOSE (OIL COOLER TO EGR COOLER)	TATA spare parts
570620125823	HOSE BS6	TATA spare parts
570620126905	WATER INLET ELBOW	TATA spare parts
570620126915	ELBOW WATER INTAKE	TATA spare parts
570620127701	O-RING THERMOSTAT BS4	TATA spare parts
570620127702	O RING (WATER OUTLET PIPE)	TATA spare parts
570620130101	COOLANT PIPE ASSY BS6	TATA spare parts
570620130103	COOLANT PIPE ASSY	TATA spare parts
570620130105	COOLANT PIPE ASSY BS6-PH2	TATA spare parts
570620140115	FAN BRG HSG DOUBLE ROW BALL BRG BS4	TATA spare parts
570620140123	FAN 500 DIA LONG SHAFT BS4	TATA spare parts
570620140132	FAN ASSY CW 500 DIA FOR TRUCK	TATA spare parts
570620140133	ASSY. BEARING HOUSING BS3/4	TATA spare parts
570620140135	ASSY. BEARING HOUSING BS3/4	TATA spare parts
570620140136	FAN DRIVE ASSY VISCOUS CLUTCH BS6	TATA spare parts
570620140141	BEARING HOUSING ASSY BS6	TATA spare parts

570620140142	FAN/FAN DRIVE ASSY BS6	TATA spare parts
570620140143	FAN DRIVE ASSY 24 V BS6	TATA spare parts
570620140147	BEARING HOUSING ASSY BS6	TATA spare parts
570620140148	BEARING HOUSING ASSY BS6	TATA spare parts
570620140154	FAN BS6	TATA spare parts
570620140155	FANDRIVE BS6	TATA spare parts
570620140160	BEARING HOUSING ASSY BS6	TATA spare parts
570620140161	KIT-FITMENTOFVISCOUSFAN BS6	TATA spare parts
570620143102	ANGULAR CONTACT BALL BRG BS6	TATA spare parts
570620143703	BEARING HOUSING BS6	TATA spare parts
570620143706	BEARING HOUSING BS6	TATA spare parts
570620143707	HUB BS6	TATA spare parts
570620143820	PWS STRG PUMP BKT (FOR DOUBLE BELT)	TATA spare parts
570620147020	PULLEYBEARINGHOUSING BS6	TATA spare parts
570620147023	PULLEY BEARING HOUSING BS6	TATA spare parts
570620147916	SHAFTBEARINGHOUSING BS6	TATA spare parts
570620147917	LONG SHAFT FAN BS6	TATA spare parts
570620147918	SHAFT BEARING HOUSING BS6	TATA spare parts
570622123301	L BRACKET (AIR INTAKE PIPE SUPPORT) BS6	TATA spare parts
570622125103	FRONT ENGINE SUPPORT-LEFT (PAINTED)	TATA spare parts
570622125104	FRONT ENGINE SUPPORT - RIGHT (PAINTED)	TATA spare parts
570622127104	LIFTING HOOK REAR	TATA spare parts
570622127105	LIFTING HOOK FRONT	TATA spare parts
570622990101	KIT SPARE GR 22 HALF BLK 3LNGE BS-IV	TATA spare parts
570623123306	BRACKET POWER STEERING SUPPORT REAR	TATA spare parts
570623123307	BRACKET POWER STEERING SUPPORT REAR	TATA spare parts
570623123310	SUPPORT BKT FOR MSC 90 AC BKT	TATA spare parts
570623123315	BRACKET POWER STEERING SUPPORT REAR	TATA spare parts
570623123316	BRACKET ASSY POWER STEERING PUMP	TATA spare parts
570623123317	BRACKET ASSY POWER STEERING PUMP BS6	TATA spare parts
570623123701	INTEGRATED BRACKET FOR AC COMPRESSOR	TATA spare parts
570623123702	BOTTOM BRACKET FOR AC COMPRESSOR	TATA spare parts
570623123705	PULLEY TRUCK-AC COMP DRIVER ON CRANK	TATA spare parts
570623123709	PULLEY	TATA spare parts
570623123716	BRACKET ASSY POWER STEERING PUMP BS6-PH2	TATA spare parts
570623123804	STIFFNER BRACKET FOR AC COMPRESSOR	TATA spare parts
570623123808	BKT.TRUCK AC COMP(DRIVE FROM DAMPER)	TATA spare parts
570623123809	BRACKET AC COMP MTG	TATA spare parts
570623126321	STRETCH BELT-TRUCK AC 941 DRIVE BS4	TATA spare parts
570623126322	BELT 6PK 1760 MM BS3/4	TATA spare parts
570623126323	POLY V BELT 6-PK 972MM TRUCK AC	TATA spare parts
570623126323DF	BELT POLY V 6PK 972MM L-ULTRA814/1014 AC	TATA spare parts
570623126327	BUS MSC240-AC BELT -FIXED TENSIONER 6PK-	TATA spare parts
570623126329	BELT 1760MM 8PK	TATA spare parts
570623126329DF	BELT 8PK STEERING 1760MM L-9.6T/10.2T UL	TATA spare parts
570623126345	BELT AC	TATA spare parts
570623126345DF	BELT 6PK 1117MM L AC-8.5T/9.6T/10.2T ULT	TATA spare parts

570623126346	POLY V-BELT BS6	TATA spare parts
570623126352	POLY V-BELT BS6	TATA spare parts
570623126355	BELT	TATA spare parts
570623126701	CYL. PIN 14M6X15	TATA spare parts
570623127002	PULLEY 185 DIA	TATA spare parts
570623127003	PULLEY DIA.185 8 PK FOR AIR COMPRESSOR	TATA spare parts
570623127010	PULLEY(FOR SEPERATE PST PUMP DRIVE)	TATA spare parts
570623127013	PWS PUMP PULLEY WITH SEPRATE DRIVE & 8PK	TATA spare parts
570623127016	PULLEY AIR COMP	TATA spare parts
570623127023	PULLEY BS6	TATA spare parts
570623145801	OIL RETURN HOSE	TATA spare parts
570623403701	BRACKET ASSY POWER STEERING PUMP BS6	TATA spare parts
570623403702	BRACKET POWER STEERING PUMP MTG BS6	TATA spare parts
570623403703	BRACKETBS6	TATA spare parts
570650100115	ASSY. COOLING SYS.3L NGE BUS	TATA spare parts
570650100129	ASSY. RADIATOR BUS BS3/4/6	TATA spare parts
570650100133	ASSY.IC BUS WITH SHORT OUT DUCT	TATA spare parts
570650100135	INTER COOLER TRUCK FOR NON-GRID HEATER	TATA spare parts
570650100139	RADIATOR TRUCK W/O HVAC	TATA spare parts
570650100142	ASSY.RAD.BOTTOM MTG.BRACKET LPO BUS	TATA spare parts
570650100143	ASSY.PIPE(W/H SLEEVE IC OUT TO AIR AIE)	TATA spare parts
570650100144	COOLING SYS.TRUCK SUIT.TO 500 FAN	TATA spare parts
570650100155	PRESSURE CAP ASSY (0.9 BAR) BS4	TATA spare parts
570650100174	ENGINE COOLING SYSTEM	TATA spare parts
570650100183	COOLING SYSTEM ASSY BS6	TATA spare parts
570650100203	INTERCOOLER ASSY BS6	TATA spare parts
570650100205	FAN SHROUD ASSY BS6	TATA spare parts
570650100213	BRACKET ASSY RADIATOR MTG BOTTOM BS6	TATA spare parts
570650100222	BRACKET RADIATOR BOTTOM MTG BS6	TATA spare parts
570650100223	COOLING SYSTEM¿BS6	TATA spare parts
570650100225	RADIATOR ASSY WITH IC & FAN SHROUD ASSY	TATA spare parts
570650100226	BRACKET ASSY AIR INTAKE PIPE SUPPORT BS6	TATA spare parts
570650100227	BRACKET ASSY AIR INTAKE PIPE SUPPORT BS6	TATA spare parts
570650100233	RAD ASSY WITH DRAIN COCK &AMP FILLER CA	TATA spare parts
570650100241	TUBE ASSY BS6	TATA spare parts
570650100242	TUBE ASSY BS6	TATA spare parts
570650100243	TUBE ASSY UREA INJECTOR INLET BS6	TATA spare parts
570650100251	RADIATOR ASSY BS6	TATA spare parts
570650100252	COOLING SYSTEM ASSY BS6	TATA spare parts
570650100254	INTERCOOLER ASSY BS6	TATA spare parts
570650100284	RADIATOR & INTERCOOLER WITH SHROUD & BKT	TATA spare parts
570650100285	RADIATOR ASSY BS6	TATA spare parts
570650100286	INTERCOOLER ASSY BS6	TATA spare parts
570650100287	FAN SHROUD ASSY BS6	TATA spare parts
570650100296	RADIATOR ASSY WITH IC & FAN SHROUD ASSY	TATA spare parts
570650100297	RADIATOR ASSY BS6	TATA spare parts
570650100298	BRACKET ASSY RADIATOR MTG BOTTOM BS6	TATA spare parts

570650100299	RADIATOR ASSY BS6	TATA spare parts
570650103315	BKT.TO SUPPORT PIPE(IC-INTAKE ELBOW)NON-	TATA spare parts
570650103327	BRACKET ASSY RAD TO BASE FRAME MTG RH	TATA spare parts
570650103342	BRACKET BS6	TATA spare parts
570650103348	BRACKET RADIATOR ASSY MTG RH BS6	TATA spare parts
570650103349	BRACKET RADIATOR ASSY MTG LH BS6	TATA spare parts
570650103351	BRACKET PIPE SUPPORT BS6	TATA spare parts
570650103354	SUPPORT BRACKET BS6	TATA spare parts
570650103355	BRACKET RADIATOR ASSY MTG LH BS6	TATA spare parts
570650103356	BRACKET RADIATOR ASSY MTG RH BS6	TATA spare parts
570650103357	BRACKET RADIATOR ASSY MTG LH BS6	TATA spare parts
570650103358	BRACKET RADIATOR ASSY MTG RH BS6	TATA spare parts
570650103360	SUPPORT BRACKET BS6	TATA spare parts
570650103362	SUPPORT BRACKET BS6	TATA spare parts
570650103363	SUPPORT BRACKET BS6	TATA spare parts
570650103364	SUPPORT BRACKET BS6	TATA spare parts
570650103366	SUPPORT BRACKET BS6	TATA spare parts
570650103367	BRACKET BS6	TATA spare parts
570650103368	SUPPORT BRACKET BS6	TATA spare parts
570650103369	BRACKET RADIATOR BOTTOM MTG	TATA spare parts
570650103373	SUPPORT BRACKET BS6-PH2	TATA spare parts
570650103374	SUPPORT BRACKET BS6-PH2	TATA spare parts
570650103375	BRACKET RADIATOR BOTTOM MTG BS6-PH2	TATA spare parts
570650103376	BRACKET RADIATOR BOTTOM MTG BS6-PH2	TATA spare parts
570650103377	BRACKET RADIATOR BOTTOM MTG BS6-PH2	TATA spare parts
570650103378	L-BRACKET BS6-PH2	TATA spare parts
570650103807	PIPE IC TO AIR INTAKE ELBOW BS6	TATA spare parts
570650104201	P-CLAMP BS6	TATA spare parts
570650105806	THERMO VENT HOSE FOR TRUCK	TATA spare parts
570650105810	HOSE ASSY RADIATOR BS6	TATA spare parts
570650105812	HOSE (T-CONNECTOR TO WATER INLET ELBOW)	TATA spare parts
570650105813	HOSE FOR TRUCK(RADIATOR TO T-CONNECTOR)	TATA spare parts
570650105814	RADIATOR TO T CONNECTOR ( BUS )	TATA spare parts
570650105816	VENT HOSE BUS	TATA spare parts
570650105820	HOSE THERMOSTAT TO RADIATOR	TATA spare parts
570650105832	HOSE(COOLANT REMOTE FILLING LPO BUS)	TATA spare parts
570650105837	HOSE T-CON-WATER ELBOW IN 24V 150A	TATA spare parts
570650105838	HOSE TO CLOSE FILLER NECK PORT	TATA spare parts
570650105842	HOSE (RADIATOR TO T-CONNECTOR TRUCK) BS6	TATA spare parts
570650105849	HOSE(NLT TO FILLER NECK)	TATA spare parts
570650105852	HOSE FILLER NECK TO NO LOSS TANK PIPE	TATA spare parts
570650105863	HOSE BS6	TATA spare parts
570650105865	HOSE ASSY RADIATOR BS6	TATA spare parts
570650105873	HOSE BS6	TATA spare parts
570650105874	HOSE BS6	TATA spare parts
570650105877	RUBBER HOSE RADIATOR BOTTOM BS6	TATA spare parts
570650105880	HOSE BS6	TATA spare parts

570650105881	HOSE BS6	TATA spare parts
570650105882	HOSE BS6	TATA spare parts
570650105883	HOSE BS6	TATA spare parts
570650105884	HOSE BS6	TATA spare parts
570650105885	HOSE BS6	TATA spare parts
570650105886	HOSE BS6	TATA spare parts
570650105887	HOSE BS6	TATA spare parts
570650105896	HOSE RADIATOR TO NO LOSS TANK BS6	TATA spare parts
570650105897	HOSE FILLER NECK TO RADIATOR BS6	TATA spare parts
570650106303	RECOVERY COOLANT TANK (500 FAN TRCUK)	TATA spare parts
570650106919	TUBE BS6	TATA spare parts
570650106920	TUBE BS6	TATA spare parts
570650106921	TUBE BS6	TATA spare parts
570650106922	TUBE BS6	TATA spare parts
570650106928	TUBE BS6	TATA spare parts
570650106929	TUBE BS6	TATA spare parts
570650106930	TUBE BS6	TATA spare parts
570650106931	TUBE BS6	TATA spare parts
570650106934	TUBE BS6	TATA spare parts
570650106935	TUBE BS6	TATA spare parts
570650106936	TUBE BS6	TATA spare parts
570650106937	TUBE BS6	TATA spare parts
570650106941	TUBE BS6	TATA spare parts
570650106942	TUBE LP NAC BS6	TATA spare parts
570650106943	TUBE LP NAC BS6	TATA spare parts
570650106944	TUBE LP NAC BS6	TATA spare parts
570650106947	TUBE BS6	TATA spare parts
570650106948	TUBE BS6	TATA spare parts
570650106949	TUBE BS6	TATA spare parts
570650106950	TUBE BS6	TATA spare parts
570650106951	TUBE BS6	TATA spare parts
570650106952	TUBE BS6	TATA spare parts
570650106953	TUBE BS6	TATA spare parts
570650106954	TUBE BS6	TATA spare parts
570650106955	TUBE BS6	TATA spare parts
570650106956	TUBE BS6	TATA spare parts
570650106957	TUBE BS6	TATA spare parts
570650106958	TUBE BS6	TATA spare parts
570650106959	TUBE BS6	TATA spare parts
570650106960	TUBE BS6	TATA spare parts
570650106961	TUBE BS6	TATA spare parts
570650106962	TUBE BS6	TATA spare parts
570650106963	TUBE BS6	TATA spare parts
570650106964	TUBE BS6	TATA spare parts
570650106973	TUBE BS6-PH2	TATA spare parts
570650106974	TUBE BS6-PH2	TATA spare parts
570650106975	TUBE BS6-PH2	TATA spare parts

570650106976	TUBE BS6-PH2	TATA spare parts
570650106980	TUBE BS6-PH2	TATA spare parts
570650106981	TUBE ASSY BS6-PH2	TATA spare parts
570650106982	TUBE BS6-PH2	TATA spare parts
570650106983	TUBE BS6-PH2	TATA spare parts
570650106990	TUBE	TATA spare parts
570650106991	TUBE BS6-PH2	TATA spare parts
570650106992	TUBE BS6-PH2	TATA spare parts
570650106993	TUBE ASSY BS6-PH2	TATA spare parts
570650110101	COOLING SYSTEM ASSY	TATA spare parts
570650110102	AUX TANK MOUTING BRACKET	TATA spare parts
570650110106	VENT HOSE ASSY AUX TANK TO RADIATOR	TATA spare parts
570650110107	VENT HOSE ASSY AUX TANK TO ENGINE	TATA spare parts
570650110110	AUX WATER TANK ASSY	TATA spare parts
570650110111	BRACKET ASSY	TATA spare parts
570650110115	AUX TANK SUPPORT BRACKET (L-SHAPE)	TATA spare parts
570650110131	RADIATOR ASSY BS6	TATA spare parts
570650110133	COOLING SYSTEM ASSY BS6-PH2	TATA spare parts
570650110134	RADIATOR ASSY BS6-PH2	TATA spare parts
570650110135	HOSE ASSY AUX WATER TANK TO WATER INTAKE	TATA spare parts
570650110136	CRIMP PIPE ASSY AUX WATER TANK TO ENGINE	TATA spare parts
570650110137	VENT HOSE ASSY AUX TANK TO RADIATOR	TATA spare parts
570650110138	VENT PIPE ASSY	TATA spare parts
570650115801	HOSE BS6	TATA spare parts
570650115802	HOSE BS6	TATA spare parts
570650115803	HOSE BS6	TATA spare parts
570650115804	HOSE¿BS6	TATA spare parts
570650115805	HOSE FILLER PIPE TO RADIATOR (OLD PART -	TATA spare parts
570650115806	HOSE FILLER NECK TO NO LOSS TANK PIPE (O	TATA spare parts
570650115807	HOSE BS6	TATA spare parts
570650115808	HOSE BS6	TATA spare parts
570650115809	HOSE BS6	TATA spare parts
570650115810	HOSE BS6	TATA spare parts
570650115811	HOSE BS6	TATA spare parts
570650115814	HOSE LP NAC BS6	TATA spare parts
570650115815	HOSE LP NAC BS6	TATA spare parts
570650115816	HOSE LP NAC BS6	TATA spare parts
570650115817	HOSE LP NAC BS6	TATA spare parts
570650115818	HOSE LP NAC BS6	TATA spare parts
570650115819	HOSE¿ BS6	TATA spare parts
570650115820	HOSE¿BS6	TATA spare parts
570650115823	HOSE BS6	TATA spare parts
570650115824	HOSE BS6	TATA spare parts
570650115825	HOSE¿BS6	TATA spare parts
570650115826	HOSE¿BS6	TATA spare parts
570650115827	HOSE¿BS6	TATA spare parts
570650115828	HOSE¿BS6	TATA spare parts

570650115829	HOSE¿BS6	TATA spare parts
570650115830	HOSE¿BS6	TATA spare parts
570650115831	HOSE¿BS6	TATA spare parts
570650115833	HOSE¿BS6	TATA spare parts
570650115836	RUBBER HOSE RADIATOR BOTTOM BS6	TATA spare parts
570650115837	HOSEBS6	TATA spare parts
570650115838	HOSE BS6	TATA spare parts
570650115841	HOSE RADIATOR TO T-CONNECTOR	TATA spare parts
570650115846	HOSE BS6-PH2	TATA spare parts
570650115847	HOSE BS6-PH2	TATA spare parts
570650506304	FAN SHROUD(BUS)SUITABLE TO 500 DIA.FAN	TATA spare parts
570650506305	FAN SHROUD SUITABLE FOR 500 CW FAN	TATA spare parts
570650506309	SHROUD ASSY	TATA spare parts
570650506311	FAN SHROUD BS6	TATA spare parts
570650506312	FAN SHROUD BS6	TATA spare parts
570703990107	SET-THRUST WASHER UPPER/LOWERBS6	TATA spare parts
570714115303	GASKET EGR INTAKE PIPE TO EGR VALVE	TATA spare parts
570714118802	STUD CM8X22 IS:1862 (SS)	TATA spare parts
570716102001	ECU HARDWARE	TATA spare parts
570718175302	GASKET(TC OIL RETURN TO BLOCK) - TALBROS	TATA spare parts
570800000108	ASSY. 275 CNG ENG BSIV (OBD-II)	TATA spare parts
570800000109	ENGINE COMPLETE CNG BSIV (OBD-II)	TATA spare parts
570800000110	ASSY. 275 CNG ENG BSIV (ITVR)	TATA spare parts
570801000101	ASSY. ENGINE COMPLETE WITH CLUTCH	TATA spare parts
570801000102	ENGINE COMPLETE WITH CLUTCH	TATA spare parts
570801000104	ASSY. ENGINE COMPLETE WITH CLUTCH BS IV	TATA spare parts
570801000105	ASSY. ENGINE COMPLETE WITH CLUTCH BS IV	TATA spare parts
570801150101	ASSY. BAFFLE CYL. HEAD COVER	TATA spare parts
570801150105	ASSY. CYLINDER HEAD W/VALVES BS2/3/4	TATA spare parts
570801150106	ASSY. CYLINDER HEAD W/O VALVES BS2/3/4	TATA spare parts
570801151601	GASKET CYL. HEAD BS2/3/4	TATA spare parts
570801151601DFR1	GASKET CYL HEAD RS1-1.2MM ACE/MAGIC-CNG	TATA spare parts
570801151601DFR2	GASKET CYL HEAD RS2-1.3MM ACE/MAGIC-CNG	TATA spare parts
570801151601DFR3	GASKET CYL HEAD RS3-1.4MM ACE/MAGIC-CNG	TATA spare parts
570801151602	CYLINDER HEAD COVER GASKET	TATA spare parts
570801151604	GASKET-BAFFLE (CYLINDER HEAD COVER)	TATA spare parts
570801153805	CYLINDER HEAD COVER	TATA spare parts
570801155301	GASKET BAFFLE(CYLINDER HEAD COVER)	TATA spare parts
570801155302	GASKET (CYLINDER HEAD)	TATA spare parts
570801155303	GASKET-CYL.HEAD COVER	TATA spare parts
570801175801	HOSE-BLOWBY (HEAD COVER TO INTAKE HOSE)	TATA spare parts
570801175802	HOSE BLOW-BY (HEAD COVER TO MANIFOLD)	TATA spare parts
570801175803	BLOW-BY HOSE(HEAD COVER TO INTAKE HOSE)	TATA spare parts
570801175804	HOSE BLOW BY (HEAD COVER TO INTAKE HOSE)	TATA spare parts
570801990101	ENG.OVERHAUL GASKET+SEAL KIT	TATA spare parts
570801990102	ENG.OVERHAUL GASKET SUB-KIT	TATA spare parts
570801990103	ENG.OVERHAUL SEAL SUB-KIT	TATA spare parts



570801990105	ASSY. LONG BLOCK 275 CNG	TATA spare parts
570801990106	SET INLET & EXHAUST VALVE	TATA spare parts
570801990107	ASSY.BARE ENGINE 275 CNG(MAGIC)	TATA spare parts
570801990113	ENG.OVERHAUL GASKET SUB-KIT	TATA spare parts
570801990114	ASSY HALF BLOCK ACE CNG BSIII	TATA spare parts
570801990117	ASSY. LONG BLOCK 275IDI BS2/4	TATA spare parts
570803110101	ASSY FLYWHEEL COMPLETE.	TATA spare parts
570803990109	SET-PISTON W/O RING GRADE-A BS2/3/4	TATA spare parts
570803990110	SET PISTON W/O RING GRADE-B	TATA spare parts
570803990111	SET PISTON W/O RING GRADE-C	TATA spare parts
570803990115	SET PISTON RINGS BS2/3/4	TATA spare parts
570803990117	SET CON.ROD BUSH	TATA spare parts
570803990118	SET CON.ROD BUSH	TATA spare parts
570805107902	CAMSHAFT (ROLLER ROCKER) BS2/3/4	TATA spare parts
570805140101	ASSY. ROCKER SHAFT WITH SEALING CAP	TATA spare parts
570807100101	ASSY.FUEL RAIL	TATA spare parts
570807100103	FUEL RAIL ASSY	TATA spare parts
570807103301	INJECTOR RETAINER	TATA spare parts
570807990101	SET - O RING (INJECTOR)	TATA spare parts
570809130102	ASSY.HOSE (A/F ELBOW TO TH.BODY)	TATA spare parts
570809130104	ASSY.HOSE WITH TUBE	TATA spare parts
570809130105	ASSY.AIR CLEANER FOR CNG	TATA spare parts
570809130107	ASSY. SERVICE INDICATOR BS4	TATA spare parts
570809130108	ASSY FILTER ELEMENT	TATA spare parts
570809130109	ASSY. AIR CLEANER HOSE & CLAMP	TATA spare parts
570809130110	ASSY. PIPE	TATA spare parts
570809130111	AIR INTAKE HOSE	TATA spare parts
570809133801	AIR INTAKE ELBOW	TATA spare parts
570809134201	HOSE CLAMP-CONSTANT TORQUE	TATA spare parts
570809134202	HOSE CLAMP-CONSTANT TORQUE	TATA spare parts
570809135801	HOSE (AIR FILTER TO ASSY. PIPE)	TATA spare parts
570809137101	AIR FILTER MTG. BKT. LH	TATA spare parts
570809137102	AIR FIL MTG BKT-LH	TATA spare parts
570809137103	AIR FIL MTG BKT-RH	TATA spare parts
570814100101	ASSY. INTAKE MANIFOLD COMPLETE	TATA spare parts
570814100102	ASSY INTAKE MANIFOLD COMPLETE	TATA spare parts
570814103801	INTAKE MANIFOLD	TATA spare parts
570814110101	ASSY HEAT SHIELD (FOR EXHAUST MANIFOLD)	TATA spare parts
570814110102	ASSY.GASKET EXHAUST MANIFOLD	TATA spare parts
570814110103	ASSY. HEAT SHIELD (FOR EXHAUST MANIFOLD)	TATA spare parts
570814113701	EXHAUST MANIFOLD	TATA spare parts
570814990101	DECARBONISING GASKET KIT	TATA spare parts
570815200101	ASSY. BRACKET CAM SENSOR	TATA spare parts
570815203802	BRACKET(FOR CRANK ANGLE SENSOR)	TATA spare parts
570815203803	ASSY. BRACKET CAM SENSOR	TATA spare parts
570815207701	RUBBER GROMET	TATA spare parts
570815210101	ASSY. THROTTLE BODY	TATA spare parts

570815210102	ECU (275 CNG ENGINE )	TATA spare parts
570815210104	ECU ACE CNG BS IV	TATA spare parts
570815210106	ECU ACE CNG BSIV (OBD-II) WITH SOFTWARE	TATA spare parts
570815210107	ECU	TATA spare parts
570815217701	O' RING INJECTOR(RAIL SIDE)	TATA spare parts
570815217702	O' RING INJECTOR(MANIFOLD SIDE)	TATA spare parts
570815219901	CRANK ANGLE SENSOR	TATA spare parts
570815219902	CAM SENSOR	TATA spare parts
570815219903	COOLANT TEMP SENSOR	TATA spare parts
570815219904	FUEL INJECTOR	TATA spare parts
570815219907	TPS	TATA spare parts
570815219908	IACV	TATA spare parts
570815219911	INJECTOR-CNG	TATA spare parts
570820120101	ASSY. TUBE (FOR WATER BYPASS)	TATA spare parts
570820120102	WATER PIPE ASSY OUTLET	TATA spare parts
570820123801	THERMOSTAT HOUSING	TATA spare parts
570820123802	COVER (THERMOSTAT)	TATA spare parts
570822107101	LIFTING HOOK (REAR)	TATA spare parts
570822107102	LIFTING HOOK (FRONT)	TATA spare parts
570849100101	CATALYTIC CONVERTER BS III	TATA spare parts
570849100102	ASSY. CATALYTIC CONVERTER	TATA spare parts
570849100105	ASSY CLOSE COUPLED CATCON	TATA spare parts
570849100106	ASSY CATCON-UNDER BODY	TATA spare parts
570849100109	ASSY. HEADSHELD-2	TATA spare parts
570849101601	ASSY.CATALYTIC CONVERTER COMPLETE.	TATA spare parts
570849101603	ASSY CATALYTIC CONVERTER COMPLETE	TATA spare parts
570849101605	ASSY CATALYTIC CONVERTER COMPLETE (UNDER	TATA spare parts
570849103301	CATCON SUPPORT BRACKET	TATA spare parts
570850100101	ASSY.TRANSITION PIECE(UPPER COOLING LINE	TATA spare parts
570901000120	ENGINE ASSY COMPLETE 5L 180PS 24V BS3	TATA spare parts
570901000135	ENGINE 5L LPO1625 HYB 180PS 24V BS4	TATA spare parts
570901000139	ASSY. ENGINE COMP. 5L ULTRA 1518 BS4	TATA spare parts
570901000143	ENGINE ASSY	TATA spare parts
570901000147	ENGINE ASSY BS6	TATA spare parts
570901000150	ENGINE ASSY	TATA spare parts
570901000153	ENGINE ASSY	TATA spare parts
57090100015570	ENGINE ASSY 5L BS6	TATA spare parts
570901000158	ENGINE ASSY BS6	TATA spare parts
570901000159	5L 180PS 24V EURO4 HVAC APPLICATION.	TATA spare parts
570901000163	ENGINE ASSY BS6	TATA spare parts
570901000168	ENGINE ASSY BS6	TATA spare parts
570901000169	ENGINE ASSY	TATA spare parts
570901000170	ENGINE ASSY BS6	TATA spare parts
570901000172	ENGINE ASSY	TATA spare parts
570901000173	ENGINE ASSY COMPLETE 5L 180 PS BS6 AC	TATA spare parts
570901000175	ENGINE ASSY BS6	TATA spare parts
570901000176	ENGINE ASSY BS6	TATA spare parts

570901000177	ENGINE ASSY BS6	TATA spare parts
570901000178	ENGINE ASSY BS6	TATA spare parts
570901000179	ENGINE ASSY BS6	TATA spare parts
570901000180	ENGINE ASSY BS6	TATA spare parts
570901000182	ENGINE ASSY BS6	TATA spare parts
570901000184	ENGINEASSY BS6	TATA spare parts
570901000187	ENGINE ASSY BS6	TATA spare parts
570901000188	ENGINE ASSY BS6	TATA spare parts
570901000190	ENGINE ASSY BS6	TATA spare parts
570901000192	ENGINE ASSY BS6	TATA spare parts
570901000196	ENGINE ASSY COMPLETE : 5L 180 PS BS6 NON	TATA spare parts
570901000197	ENGINE ASSY COMPLETE 5L 200PS	TATA spare parts
570901000198	ENGINE ASSY	TATA spare parts
570901000199	ASSY. ENGINE 5L BS6	TATA spare parts
570901000205	ENGINE ASSY BS6-PH2	TATA spare parts
570901000208	ENGINE ASSY BS6	TATA spare parts
570901000215	ENGINE ASSY BS6-PH2	TATA spare parts
570901000216	ENGINE ASSY BS6-PH2	TATA spare parts
570901000227	ENGINE ASSY BS6	TATA spare parts
570901000228	ENGINE ASSY BS6	TATA spare parts
570901000234	ENGINE ASSY BS6-PH2	TATA spare parts
570901000241	ENGINE ASSY BS6-PH2	TATA spare parts
570901000244	ENGINE ASSY BS6-PH2	TATA spare parts
570901000245	ENGINE ASSY BS6	TATA spare parts
570901000247	ENGINE ASSY BS6-PH2	TATA spare parts
570901100102	ASSY CRANKCASE WITH CYL LINER & BEDPLATE	TATA spare parts
570901100111	CYL CRANKCASE ASSY BS6	TATA spare parts
570901100112	CYL BLOCK ASSY BS6	TATA spare parts
570901103201	MAIN BEARING BOLT	TATA spare parts
570901103401	BUSH (OIL PUMP)	TATA spare parts
570901103702	CYLINDER LINER BS6	TATA spare parts
570901103703	BEDPLATE	TATA spare parts
570901103706	CYLINDER LINER	TATA spare parts
570901103708	CYLINDER LINER	TATA spare parts
570901104802	FLYWHEEL HOUSING MTG/BED PLATE INNER DOV	TATA spare parts
570901108203	CORE PLUG	TATA spare parts
570901108204	CORE PLUG	TATA spare parts
570901108205	CORE PLUG	TATA spare parts
570901108206	CORE PLUG	TATA spare parts
570901108207	CORE PLUG	TATA spare parts
570901108208	CORE PLUG	TATA spare parts
570901108209	CORE PLUG BS6-PH2	TATA spare parts
570901108210	CORE PLUG BS6-PH2	TATA spare parts
570901108211	CORE PLUG BS6-PH2	TATA spare parts
570901108212	CORE PLUG BS6-PH2	TATA spare parts
570901108213	CORE PLUG BS6-PH2	TATA spare parts
570901108214	CORE PLUG BS6-PH2	TATA spare parts

570901130105	ASSEMBLY OIL SUMP WITH DRAIN PLUG	TATA spare parts
570901130120	OIL SUMP WITH DRAIN PLUG	TATA spare parts
570901130121	OIL SUMP ASSY WITH DRAIN PLUG	TATA spare parts
570901130125	OIL SUMP WITH DRAIN PLUG BS6	TATA spare parts
570901130126	OIL SUMP WITH DRAIN PLUG BS6	TATA spare parts
570901130128	OIL SUMP WITH DRAIN PLUG	TATA spare parts
570901130133	OIL SUMP WITH DRAIN PLUG BS6-PH2	TATA spare parts
570901130136	OIL SUMP ASSY	TATA spare parts
570901135302	OIL SUMP GASKET	TATA spare parts
570901135305	GASKET OIL SUMP	TATA spare parts
570901139901	CLAMP (OIL SUMP MOUNTING)	TATA spare parts
570901139902	CLAMP (OIL SUMP MOUNTING)	TATA spare parts
570901150106	ASSY. CYLINDER HEAD (WITHOUT VALVES)	TATA spare parts
570901150108	ASSY. CYLINDER HEAD WITH VALVES BS4	TATA spare parts
570901150110	DECOUPLING ELEMENT (SHORT)	TATA spare parts
570901150111	DECOUPLING ELEMENT LONG	TATA spare parts
570901150113	ASSY PRE-SEPERATION CHAMBER COVER WITH G	TATA spare parts
570901150132	CYLINDER HEAD ASSY W/O VALVES	TATA spare parts
570901150134	CYL HEAD ASSY W/O VALVES BS6	TATA spare parts
570901150135	CYL HEAD ASSY WITH VALVES BS6	TATA spare parts
570901150136	CYL HEAD ASSY WITH VALVES	TATA spare parts
570901150142	CYL HEAD ASSY WITH VALVES BS6	TATA spare parts
570901150144	CYLINDER HEAD COVER WITH GASKET BS6-PH2	TATA spare parts
570901150159	CYLINDER HEAD COVER BS6	TATA spare parts
570901150161	BAFFLE PLATE ASSY CYL HEAD COVER BS6	TATA spare parts
570901153201	BOLT (CYLINDER HEAD)	TATA spare parts
570901153401	VALVE SEAT INTAKE	TATA spare parts
570901153402	VALVE SEAT EXHAUST	TATA spare parts
570901153801	CYLINDER HEAD COVER	TATA spare parts
570901153803	REAR COVER (CYLINDER HEAD)	TATA spare parts
570901154801	HOLLOW DOWEL (CYLINDER HEAD)	TATA spare parts
570901155306	CYLINDER HEAD COVER GASKET	TATA spare parts
570901155308	GASKET(CYL HEAD TO REAR COVER)	TATA spare parts
570901155309	CYLINDER HEAD GASKET BS3/4/6	TATA spare parts
570901155312	GASKET CYL HEAD COVER BS6-PH2	TATA spare parts
570901156901	TUBE BREATHER	TATA spare parts
570901157701	SEALING RING (INJECTOR SLEEVE)	TATA spare parts
570901158402	INJECTOR SLEEVE	TATA spare parts
570901160101	ASSY. FUEL INJECTOR BS3/4	TATA spare parts
570901160102	ASSY. FUEL INJECTOR BS3/4	TATA spare parts
570901160109	INJECTOR ASSY BS6	TATA spare parts
570901165102	INJECTOR CLAW	TATA spare parts
570901165103	HP CONNECTOR QUILL ASSEMBLY	TATA spare parts
570901166501	HP CONNECTOR NUT ASSEMBLY	TATA spare parts
570901170102	TUBE ASSY WITH CLAMP OMS TO OIL SUMP	TATA spare parts
570901170105	CLAMP (DIPSTICK MOUNTING)	TATA spare parts
570901170108	ASSY BRACKET	TATA spare parts

570901170111	ASSY OIL MIST SEPERATOR	TATA spare parts
570901170119	DIPSTICK ASSY Y1	TATA spare parts
570901170120	DIPSTICK ASSY LPO 1617	TATA spare parts
570901170122	TUBE ASSY DIPSTICK	TATA spare parts
570901170123	PIPE ASSY OMS TO ATM	TATA spare parts
570901170132	PIPE ASSY OMS TO ATM	TATA spare parts
570901170133	TUBE ASSY WITH CLAMP BS6	TATA spare parts
570901170134	TUBE ASSY WITH CLAMP	TATA spare parts
570901170139	BRACKET ASSY WITH WELD NUT	TATA spare parts
570901170140	DIPSTICK ASSY	TATA spare parts
570901170145	TUBE ASSY WITH CLAMP BS6	TATA spare parts
570901170150	BRACKET ASSY WITH WELD NUT BS6	TATA spare parts
570901170151	DIPSTICK ASSY BS6	TATA spare parts
570901170153	OIL MIST SEPARATOR ASSY BS6	TATA spare parts
570901170155	BRACKET ASSY WITH WELD NUT BS6	TATA spare parts
570901170156	BRACKET ASSY WITH WELD NUT BS6	TATA spare parts
570901170161	DIPSTICK TUBE ASSY	TATA spare parts
570901170165	TUBE ASSY WITH CLAMP BS6	TATA spare parts
570901170166	TUBE ASSY WITH CLAMP BS6	TATA spare parts
570901170170	DIPSTICK ASSY BS6	TATA spare parts
570901170174	DIPSTICK ASSY	TATA spare parts
570901170177	COIL ASSY DIPSTICK	TATA spare parts
570901170183	SUPPORT BRACKET ASSY BS6	TATA spare parts
570901170184	SUPPORT BRACKET ASSY BS6	TATA spare parts
570901170185	PIPE ASSY OMS TO ATM BS6-PH2	TATA spare parts
570901170193	DIPSTICK ASSY	TATA spare parts
570901170194	TUBE ASSY WITH CLAMP BS6-PH2	TATA spare parts
570901170197	BRACKET ASSY OMS MTG BS6-PH2	TATA spare parts
570901170198	PIPE ASSY OMS TO ATM BS6-PH2	TATA spare parts
570901170199	DIPSTICK ASSY BS6-PH2	TATA spare parts
570901170204	DIPSTICK ASSY BS6-PH2	TATA spare parts
570901175801	RUBBER HOSE(CYL.HEAD COVER TO OMS) UPPER	TATA spare parts
570901175803	RUBBER HOSE (OMS TO OIL SUMP)	TATA spare parts
570901175807	RUBBER HOSE(CYL.HEAD COVER TO OMS) LOWER	TATA spare parts
570901175812	RUBBER HOSE OMS TO ATMOSPHERE	TATA spare parts
570901175816	RUBBER HOSE OMS TO ATMOSPHERE	TATA spare parts
570901175817	RUBBER HOSE BS6	TATA spare parts
570901175819	RUBBER HOSE BS6	TATA spare parts
570901175821	RUBBER HOSE BS6-PH2	TATA spare parts
570901175824	RUBBER HOSE BS6-PH2	TATA spare parts
570901175826	HOSE OMS BREATHER TO ATMOSPHERE BS6-PH2	TATA spare parts
570901176903	TUBE (CYL. HEAD COVER TO OMS)	TATA spare parts
570901176909	TUBE BS6-PH2	TATA spare parts
570901178204	BRACKET (DIPSTICK TUBE SUPPORT)	TATA spare parts
570901178205	BRACKET DIPSTICK MTG	TATA spare parts
570901178206	BRACKET DIPSTICK MTG	TATA spare parts
570901179901	SLEEVE NUT DIPSTICK	TATA spare parts

570901990106	LONG BLOCK ULTRA 1518 LPT BS3/4	TATA spare parts
570901990108	KIT-INTAKE & EXHAUST VALVES (5L ENGINE)	TATA spare parts
570901990110	HALF BLOCK ULTRA 1518 LPT BS3/4	TATA spare parts
570901990112	KIT- GASKET ENGINE OVERHAUL(5L ENGINE)	TATA spare parts
570901990115	ASSY. LONG BLOCK LPO 1625 BS4	TATA spare parts
570901990117	HALF BLOCK	TATA spare parts
570901990125	LONG BLOCK 5L BS4	TATA spare parts
570901990126	KIT-HALF BLOCK	TATA spare parts
570901990129	KIT LONG BLOCK BS6	TATA spare parts
570901990133	KIT-GASKET ENGINE OVERHAUL BS6	TATA spare parts
570901990136	KIT-LONG BLOCK BS6	TATA spare parts
570901990138	KIT-HALF BLOCK BS6	TATA spare parts
570901990143	LONG BLOCK 2821.T/3521.T 5L BS4	TATA spare parts
570901990145	HALF BLOCK	TATA spare parts
570901990148	KIT-LONG BLOCK BS6	TATA spare parts
570901990150	KIT-HALF BLOCK BS6	TATA spare parts
570901990152	KIT-LONG BLOCK BS6	TATA spare parts
570901990154	KIT-HALF BLOCK BS6	TATA spare parts
570901990157	KIT-DECARBONISING GASKET BS6	TATA spare parts
570901990158	KIT-DECARBONISING GASKET BS6	TATA spare parts
570901990159	KIT-ENGINE OVERHAUL GASKET BS6	TATA spare parts
570901990161	LONG BLOCK ASSY BS6	TATA spare parts
570901990162	HALF BLOCK ASSY BS6	TATA spare parts
570901990163	KIT-LONG BLOCK BS6	TATA spare parts
570901990164	KIT-HALF BLOCK BS6	TATA spare parts
570901990168	KIT-LONG BLOCK BS6	TATA spare parts
570901990169	KIT-HALF BLOCK BS6	TATA spare parts
570901990172	LONG BLOCK BS6	TATA spare parts
570901990174	HALF BLOCK BS6	TATA spare parts
570901990175	KIT-LONG BLOCK BS6	TATA spare parts
570901990177	KIT-HALF BLOCK BS6	TATA spare parts
570901990179	KIT-ENGINE OVERHAUL GASKET BS6	TATA spare parts
570901990181	KIT-LONG BLOCK BS6	TATA spare parts
570901990183	KIT-HALF BLOCK BS6	TATA spare parts
570901990186	KIT-LONG BLOCK BS6	TATA spare parts
570901990187	KIT-LONG BLOCK BS6	TATA spare parts
570901990188	KIT-HALF BLOCK BS6	TATA spare parts
570901990189	KIT-LONG BLOCK BS6	TATA spare parts
570901990191	KIT-HALF BLOCK BS6	TATA spare parts
570901990193	KIT-LONG BLOCK BS6	TATA spare parts
570901990195	KIT LONG BLOCK BS6	TATA spare parts
570901990197	KIT HALF BLOCK BS6	TATA spare parts
570901990204	KIT- LONG BLOCK	TATA spare parts
570901990205	KIT- HALF BLOCK BS6	TATA spare parts
570901990217	KIT-LONG BLOCK BS6	TATA spare parts
570901990218	KIT-HALF BLOCK BS6	TATA spare parts
570901990222	KIT-RETRO FITMENT	TATA spare parts

570901990240	KIT-LONG BLOCK BS6-PH2	TATA spare parts
570901990243	KIT-HALF BLOCK BS6-PH2	TATA spare parts
570901990244	KIT-LONG BLOCK BS6-PH2	TATA spare parts
570901990247	KIT-LONG BLOCK BS6-PH2	TATA spare parts
570901990249	KIT-HALF BLOCK BS6-PH2	TATA spare parts
570901990252	KIT-LONG BLOCK BS6-PH2	TATA spare parts
570901990254	KIT-HALF BLOCK BS6-PH2	TATA spare parts
570901990257	KIT-LONG BLOCK BS6-PH2	TATA spare parts
570901990267	KIT-LONG BLOCK BS6-PH2	TATA spare parts
570903100101	CRANKSHAFT ASSY WITHOUT PIN-NORMAL	TATA spare parts
570903103101	DEEP GROOVE BALL BEARING	TATA spare parts
570903105401	GEAR CRANKSHAFT	TATA spare parts
570903105404	GEAR CRANKSHAFT	TATA spare parts
570903107802	CRANKSHAFT FRONT OIL SEAL	TATA spare parts
570903107803	CRANKSHAFT REAR OIL SEAL	TATA spare parts
570903110103	FLYWHEEL ASSY WITH RING GEAR(380 CLUTCH)	TATA spare parts
570903110104	ASSY. FLYWHEEL W/RING GEAR 352DIA. BS3-6	TATA spare parts
570903110113	FLYWHEEL ASSY WITH RING GEAR	TATA spare parts
570903110120	FLYWHEEL ASSY WITH RING GEAR	TATA spare parts
570903111601	O-RING 35.5X2	TATA spare parts
570903113201	HEX FLANGE BOLT (FLYWHEEL TO CRANKSHAFT)	TATA spare parts
570903113707	FLYWHEEL HOUSING	TATA spare parts
570903113708	FLYWHEEL HOUSING BS6	TATA spare parts
570903113801	FLYWHEEL HOUSING	TATA spare parts
570903113803	FLYWHEEL HOUSING BS6	TATA spare parts
570903113804	FLYWHEEL HOUSING BS6	TATA spare parts
570903114801	DOWEL PIN	TATA spare parts
570903115401	RING GEAR FLYWHEEL	TATA spare parts
570903116701	PIN ( TIMING ARRANGEMENT )	TATA spare parts
570903118201	COVER FLYWHEEL HOUSING (TDC)	TATA spare parts
570903118202	COVER FLYWHEEL HOUSING	TATA spare parts
570903120101	SET MAIN BEARING UPPER/LOWER (NORMAL)	TATA spare parts
570903120103	SET-MAIN BRG HALF UPPER/LOWER(REPAIR-I)F	TATA spare parts
570903120104	SET-MAIN BRG HALF UPPER/LOWER(REPAIR-II)	TATA spare parts
570903120112	SET-MAIN BRG SHELL HALF UPPER/LOWER BS6	TATA spare parts
570903123105	MAIN BRG HALF UPPER(NORMAL)FM	TATA spare parts
570903123109	MAIN BRG HALF LOWER(NORMAL)FM	TATA spare parts
570903123123	MAIN BRG HALF LOWER??BS6	TATA spare parts
570903123402	THRUST WASHER SET REGULAR	TATA spare parts
570903123403	THRUST WASHER (REPAIR I)	TATA spare parts
570903123404	THRUST WASHER (REPAIR II)	TATA spare parts
570903137002	CRANK SHAFT PULLEY WITH 6 GROOVES	TATA spare parts
570903137015	PULLEY AC DRIVE BS6-PH2	TATA spare parts
570903137016	PULLEY CRANKSHAFT BS6-PH2	TATA spare parts
570903150106	SET BEARING HALF (UPPER/LOWER) (NORMAL)	TATA spare parts
570903150108	SET-BEARING HALF UPPER/LOWER (REPAIR-I)F	TATA spare parts
570903150109	SET-BEARING HALF UPPER/LOWER (REPAIR-II)	TATA spare parts

570903150113	ASSY CON ROD WITH BUSH & BOLT-NORMAL	TATA spare parts
570903150121	SET-CON. ROD BUSH (NORMAL)	TATA spare parts
570903153103	CON ROD UPPER BEARING SHELL (NORMAL)	TATA spare parts
570903153107	CON ROD LOWER BEARING SHELL (NORMAL)	TATA spare parts
570903153201	CONNECTING ROD BOLT	TATA spare parts
570903153401	BUSH CON ROD (NORMAL)	TATA spare parts
570903153402	BUSH CONNECTING ROD(NORMAL I) BS6	TATA spare parts
570903160102	SET-PISTON WITH COOLING GALLERY	TATA spare parts
570903160107	SET PISTON W/O COOLING GALLERY+RINGS	TATA spare parts
570903160110	SET-PISTON W/O COOLING GALLERY & RING BS	TATA spare parts
570903160114	SET-PISTON WITH COOLING GALLERY	TATA spare parts
570903990101	KIT- BARE PISTON (5L ENGINE)	TATA spare parts
570903990102	KIT-PISTON RINGS (5L ENGINE)	TATA spare parts
570903990109	SET PISTON WITH PIN & CIRCLIP (5L)	TATA spare parts
570903990117	SET-PISTON ASSY WITH PIN & CIRCLIP BS6	TATA spare parts
570903990122	PISTON ASSY WITH PIN & CIRCLIP BS6	TATA spare parts
570903990124	KIT-PISTON RING	TATA spare parts
570903990126	SET-PISTON ASSY BS6	TATA spare parts
570905100101	IDLER GEAR ASSY 1	TATA spare parts
570905100102	IDLER GEAR ASSY 2	TATA spare parts
570905100103	IDLER GEAR ASSY 3	TATA spare parts
570905100105	DISTANCE PLATE & BUSH ASSY -2	TATA spare parts
570905100110	SET CAMSHAFT BEARING UPPER/LOWER (NORMAL)	TATA spare parts
570905100112	SET CAMSHAFT BEARING UPPER/LOWER((REPAIR	TATA spare parts
570905100113	SET CAMSHAFT BEARING UPPER/LOWER(REPAIR-	TATA spare parts
570905100119	IDLER GEAR ASSY	TATA spare parts
570905100120	IDLER GEAR ASSY	TATA spare parts
570905103103	BEARING CAMSHAFT UPPER (NORMAL)FM	TATA spare parts
570905103107	BEARING CAMSHAFT LOWER (NORMAL)FM	TATA spare parts
570905103111	BEARING CAMSHAFT UPPER (NORMAL)BM BS6	TATA spare parts
570905103115	BEARING CAMSHAFT LOWER (NORMAL)BM BS6	TATA spare parts
570905103201	HEXAGONAL FLANGE BOLT CAM SHAFT GEAR	TATA spare parts
570905103401	BUSH DISTANCE PLATE - 2	TATA spare parts
570905103402	BUSH (IDLER GEAR ASSY-I)	TATA spare parts
570905103403	BUSH (IDLER GEAR ASSY-II)	TATA spare parts
570905103404	BUSH (IDLER GEAR ASSY-III)	TATA spare parts
570905103701	CAM SHAFT BEARING CAP 1	TATA spare parts
570905103702	CAM SHAFT BEARING CAP 2 3 & 4	TATA spare parts
570905103703	CAM SHAFT BEARING CAP 5	TATA spare parts
570905105405	GEAR CAMSHAFT	TATA spare parts
570905105501	HUB 1 (IDLER GEAR ASSY 1)	TATA spare parts
570905105502	HUB 2 (IDLER GEAR ASSY 2)	TATA spare parts
570905105503	HUB 3 (IDLER GEAR ASSY 3)	TATA spare parts
570905107101	DISTANCE PLATE-1	TATA spare parts
570905107102	DISTANCE PLATE-2	TATA spare parts
570905107104	TRIGGER WHEEL	TATA spare parts
570905107901	CAMSHAFT NORMAL (CASE CARBURISED)	TATA spare parts



570905120102	EXHAUST VALVE BRIDGE ASSY BS6	TATA spare parts
570905125101	VALVE-SPRING RETAINER TOP	TATA spare parts
570905125102	VALVE BRIDGE	TATA spare parts
570905128201	VALVE-SPRING RETAINER BOTTOM	TATA spare parts
570905128202	RETAINER VALVE SPRING BOTTOM	TATA spare parts
570905128701	VALVE SPRING INTAKE	TATA spare parts
570905128702	VALVE SPRING EXHAUST	TATA spare parts
570905129001	VALVE INTAKE	TATA spare parts
570905129002	VALVE EXHAUST	TATA spare parts
570905129003	INTAKE VALVE BS6	TATA spare parts
570905129004	EXHAUST VALVE BS6	TATA spare parts
570905140103	ASSY ROCKER SHAFT WITH PIN & SEALING CAP	TATA spare parts
570905140104	ASSY ROCKER ARM INTAKE	TATA spare parts
570905140105	ASSY ROCKER ARM EXHAUST	TATA spare parts
570905140106	ROCKER ARM ASSY INTAKE BS6	TATA spare parts
570905140107	ROCKER ARM ASSY EXHAUST BS6	TATA spare parts
570905140114	ROCKER ARM ASSY WITH BUSH EXHAUST BS6	TATA spare parts
570905140116	PEDESTAL ASSY WITH PIN & NUT BS6	TATA spare parts
570905145103	CAP (ROCKER SHAFT)	TATA spare parts
570905147901	ROCKER SHAFT BS6	TATA spare parts
570905148201	SEALING PUSHI-IN CAP	TATA spare parts
570905148601	DISTANCE SLEEVE 1	TATA spare parts
570905148602	DISTANCE SLEEVE 2	TATA spare parts
570905153401	VALVE GUIDE	TATA spare parts
570905153402	VALVE GUIDE	TATA spare parts
570905155102	VALVE COLLET	TATA spare parts
570905157801	VALVE STEM SEAL	TATA spare parts
570905157803	OIL SEAL VALVE STEM	TATA spare parts
570907100101	FUEL INJECTION PUMP BS3/4	TATA spare parts
570907100107	FUEL INJECTION PUMP ASSY BS6	TATA spare parts
570907105401	GEAR FUEL INJECTION PUMP	TATA spare parts
570907123702	FIP SUPPORT PLATE	TATA spare parts
570907123703	SUPPORT PLATE FIP BS6	TATA spare parts
570907140102	ASSY FUEL PRESSURE LINE-1 (RAIL TO INJ.)	TATA spare parts
570907140103	ASSY FUEL PRESSURE LINE-2 (RAIL TO INJ.)	TATA spare parts
570907140104	ASSY FUEL PRESSURE LINE-3 (RAIL TO INJ.)	TATA spare parts
570907140105	ASSY FUEL PRESSURE LINE-4 (RAIL TO INJ.)	TATA spare parts
570907140106	ASSY FUEL PRESSURE LINE (PUMP TO RAIL)	TATA spare parts
570907140108	ASSY FUEL RAIL	TATA spare parts
570907140118	ASSY. FUEL RAIL 2000BAR 5L BS4	TATA spare parts
570907140124	FUEL PR PIPE ASSY PUMP TO RAIL	TATA spare parts
570907140138	FUEL PRESSURE LINE-1 (RAIL TO INJ.) BS6	TATA spare parts
570907140139	FUEL PRESSURE LINE-2 (RAIL TO INJ.) BS6	TATA spare parts
570907140140	FUEL PRESSURE LINE-3 (RAIL TO INJ.) BS6	TATA spare parts
570907140141	FUEL PRESSURE LINE-4 (RAIL TO INJ.) BS6	TATA spare parts
570907140142	FUEL PRESSURE LINE (PUMP TO RAIL) BS6	TATA spare parts
570907148201	ASSY CLAMP	TATA spare parts

570909100101	PRIMING PUMP ASSY	TATA spare parts
570909113801	BRACKET FUEL FILTER MTG BS6	TATA spare parts
570909120106	ASSY. FUEL FILTER MAIN BS3/4	TATA spare parts
570909120120	ASSY. FUEL FILTER (PRE ) DELPHI BS3/4	TATA spare parts
570909120121	VENTURY ASSY	TATA spare parts
570909120122	BRACKET ASSY VENTURI SUPPORT	TATA spare parts
570909120123	FUEL PIPE ASSY (INJECTOR RETURN)	TATA spare parts
570909120125	FUEL PIPE ASSY (FIP TO VENTURI)	TATA spare parts
570909120126	FUEL PIPE ASSY (COMMON RAIL RETURN)	TATA spare parts
570909120134	BRACKET ASSY VENTURI SUPPORT	TATA spare parts
570909120136	FUEL PRE FILTER ASSY WITH DRAIN PLUG W/O	TATA spare parts
570909120140	FUEL PIPE ASSY BS6	TATA spare parts
570909120141	FUEL PIPE ASSY BS6	TATA spare parts
570909120142	FUEL PIPE ASSY BS6	TATA spare parts
570909120143	FUEL PIPE ASSY BS6	TATA spare parts
570909120145	BRACKET ASSY BS6	TATA spare parts
570909120146	FUEL PIPE ASSY BS6	TATA spare parts
570909120147	BRACKET ASSY VENTURI SUPPORTçBS6	TATA spare parts
570909120155	FUEL FILTERBS6	TATA spare parts
570909120156	BRACKET ASSY FUEL FILTER MTG BS6-PH2	TATA spare parts
570909120157	FUEL PIPE ASSY BS6	TATA spare parts
570909120158	FUEL PIPE ASSY BS6	TATA spare parts
570909120159	BRACKET ASSY FUEL FILTER MTG BS6	TATA spare parts
570909120162	FUEL PIPE ASSY BS6	TATA spare parts
570909120164	FUEL PIPE ASSY BS6	TATA spare parts
570909120165	FUEL PIPE ASSY BS6	TATA spare parts
570909120166	SUPPORT BRACKET ASSY BS6-PH2	TATA spare parts
570909120168	FUEL FILTER ASSY BS6	TATA spare parts
570909120171	BRACKET ASSY FUEL FILTER MTG BS6-PH2	TATA spare parts
570909120177	SUPPORT BRACKET ASSY BS6-PH2	TATA spare parts
570909120178	FUEL FILTER ASSY	TATA spare parts
570909120180	WATER SENSOR ASSEMBLY BS6-PH2	TATA spare parts
570909120182	FUEL FILTER ASSY	TATA spare parts
570909120185	FUEL PIPE ASSY BS6-PH2	TATA spare parts
570909120186	BRACKET ASSY VENTURI SUPPORT BS6-PH2	TATA spare parts
570909120187	FUEL PIPE ASSY BS6-PH2	TATA spare parts
570909120188	FUEL PIPE ASSY BS6-PH2	TATA spare parts
570909120190	FUEL PIPE ASSY BS6-PH2	TATA spare parts
570909120192	FUEL PIPE ASSY BS6-PH2	TATA spare parts
570909120196	BRACKET ASSY BS6-PH2	TATA spare parts
570909120197	SUPPORT BRACKET BS6-PH2	TATA spare parts
570909120198	BRACKET ASSY BS6-PH2	TATA spare parts
570909120199	FUEL PIPE ASSY BS6-PH2	TATA spare parts
570909120201	SUPPORT BRACKET ASSY BS6-PH2	TATA spare parts
570909120202	BRACKET ASSY BS6-PH2	TATA spare parts
570909120203	FUEL PIPE ASSY BS6-PH2	TATA spare parts
570909120204	SUPPORT BRACKET ASSY BS6-PH2	TATA spare parts

570909120205	SUPPORT BRACKET ASSY BS6-PH2	TATA spare parts
570909126901	CONNECTOR (FUEL RETURN)	TATA spare parts
570909128211	SUPPORT BRACKET BS6	TATA spare parts
570909128212	SUPPORT BRACKET BS6	TATA spare parts
570909128220	SUPPORT BRACKET FUEL RETURN LINE BS6-PH2	TATA spare parts
570909128224	BRACKET BS6-PH2	TATA spare parts
570909129901	BRACKET ASSY FUEL FILTER	TATA spare parts
570909129904	ASSY. FUEL FILTER ELEMENT W/RING BS3/4	TATA spare parts
570909129906	QUICK CONNECTER 9.89 90 DEG BS6	TATA spare parts
570909129911	DRAIN WATER SCREW	TATA spare parts
570909129913	ASSY. FUEL FILTER ELEMENT W/RING BS3/4	TATA spare parts
570909129921	FUEL FILTER ELEMENT ASSY BS6	TATA spare parts
570909129923	FUEL FILTER ELEMENT WITH O-RING BS6-PH2	TATA spare parts
570909129924	FUEL FILTER CARTRIDGE	TATA spare parts
570909130102	ASSY. AIR FILTER BS3/4	TATA spare parts
570909130106	ASSY. AIR FILTER ELEMENT (PRIMARY) BS3/4	TATA spare parts
570909130107	AIR FILTER ELEMENT(SAFETY) BS3/4	TATA spare parts
570909130112	AIR CLEANER ASSY BS6	TATA spare parts
570909130115	A/F ELEMENT(PRIMARY) BS6	TATA spare parts
570909130117	A/F ELEMENT(SAFETY) BS6	TATA spare parts
570909130118	BRACKET ASSY (M/S FLTG AIS- 5L Y1 LPT) B	TATA spare parts
570909130119	BRACKET ASSY (M/S FLTG AIS- 5L Y1 LPT) B	TATA spare parts
570909130125	RAIN HOOD ASSY (PLASTIC) BS6	TATA spare parts
570909130134	AIR INTAKE SYSTEM ASSY	TATA spare parts
570909130144	SUPPORT BRACKET AIR FILTER TO TC PIPE	TATA spare parts
570909130146	PIPE ASSY TURBOCHARGER SIDE	TATA spare parts
570909130151	PIPE ASSY WITH FLANGE AIR FILTER OUTLET	TATA spare parts
570909130174	A/F ELEMENT (PRIMARY) M/S FLEETGUARD BS6	TATA spare parts
570909130175	A/F ELEMENT (SAFETY) M/S FLEETGUARD BS6-	TATA spare parts
570909130179	PIPE ASSY WITH CLAMP	TATA spare parts
570909130180	PIPE ASSY WITH CLAMP	TATA spare parts
570909130181	AIR FILTER ASSY	TATA spare parts
570909130182	BRACKET ASSY AIR FILTER MTG	TATA spare parts
570909130185	BRACKET ASSY	TATA spare parts
570909130186	AIR INTAKE PIPE ASSY AIR FILTER TO TC	TATA spare parts
570909130187	SUPPORT ASSY AIR INTAKE PIPE	TATA spare parts
570909130197	AIR FILTER ASSY	TATA spare parts
570909130198	BRACKET ASSY AIR FILTER MTG	TATA spare parts
570909130213	KIT-AIR INTAKE ASSY	TATA spare parts
570909130214	AIR FILTER ASSY	TATA spare parts
570909130217	KIT-AIR INTAKE ASSY BS6	TATA spare parts
570909130220	AIR INTAKE PIPE ASSY A/F TO T/C	TATA spare parts
570909130222	PIPE ASSY WITH STOPPER	TATA spare parts
570909130223	AIR FILTER ASSY BS6	TATA spare parts
570909130224	AIR FILTER ASSY W/O BRACKET BS6	TATA spare parts
570909130230	AIR FILTER ASSY BS6	TATA spare parts
570909130231	AIR FILTER ASSY WITH BRACKET BS6	TATA spare parts

570909130232	AIR FILTER ASSY W/O BRACKET BS6	TATA spare parts
570909130249	KIT-AIR INTAKE SYSTEM BS6	TATA spare parts
570909130250	AIR FILTER ASSY BS6	TATA spare parts
570909130252	AIR FILTER ASSY WITH BRACKET BS6	TATA spare parts
570909130255	SUPPORT BRACKET BS6	TATA spare parts
570909130257	AIR INTAKE PIPE ASSY A/F TO T/C BS6	TATA spare parts
570909130259	AIR FILTER ASSY W/O BRACKET BS6	TATA spare parts
570909130262	SUPPORT BRACKET AIR INTAKE PIPE MTG BS6	TATA spare parts
570909130265	BRACKET ASSY AIR FILTER MTG BS6	TATA spare parts
570909130268	AIR INTAKE PIPE ASSY A/F TO T/C BS6	TATA spare parts
570909130272	AIR FILTER SUB ASSY WITHOUT MOUNTING BRA	TATA spare parts
570909130273	AIR FILTER ASSY BS6	TATA spare parts
570909130276	KIT-AIR INTAKE ASSY BS6	TATA spare parts
570909130279	AIR FILTER ASSY COMPLETE BS6	TATA spare parts
570909130280	AIR FILTER ASSY WITH BRACKET BS6	TATA spare parts
570909130281	AIR FILTER ASSY	TATA spare parts
570909130284	AIR FILTER ASSY W/O BRACKET BS6	TATA spare parts
570909130287	SUPPORT ASSY AIR INTAKE PIPE BS6	TATA spare parts
570909130288	AIR FILTER ASSY WITH BRACKET BS6	TATA spare parts
570909130307	AIR FILTER ASSY W/O FILTER ELEMENT BS6	TATA spare parts
570909130309	BRACKETASSYAIRFILTERMTG BS6	TATA spare parts
570909130312	AIR DUCT ASSY CLEAN BS6	TATA spare parts
570909130313	AIR DUCT ASSY BS6	TATA spare parts
570909130315	BRACKET WITH FASTENERS BS6	TATA spare parts
570909130321	HOSE ASSY BS6	TATA spare parts
570909130327	BRACKET ASSY BS6-PH2	TATA spare parts
570909130330	BRACKET ASSY AIR INTAKE DUCT BS6-PH2	TATA spare parts
570909130331	BRACKET ASSY AIR FILTER MTG BS6-PH2	TATA spare parts
570909130350	PIPE ASSY WITH BRACKET BS6-PH2	TATA spare parts
570909130351	BRACKET ASSY AIR INTAKE DUCT BS6-PH2	TATA spare parts
570909130352	PIPE ASSY WITH BRACKET BS6-PH2	TATA spare parts
570909130361	AIR FILTER ASSY BS6-PH2	TATA spare parts
570909130364	AIR DUCT ASSY BS6-PH2	TATA spare parts
570909130365	HOSE ASSY BS6-PH2	TATA spare parts
570909134201	CLAMP EVACUATOR VALVE BS6	TATA spare parts
570909134206	CLAMP	TATA spare parts
570909134212	CLAMP BS6	TATA spare parts
570909135801	RUBBER HOSE AIR INTAKE PIPE	TATA spare parts
570909135816	REDUCER HOSE AIR FILTER PIPE	TATA spare parts
570909135817	RUBBER HOSE (TC TO ASSY PIPE)	TATA spare parts
570909135818	RUBBER HOSE (TURBOCHARGER INLET)	TATA spare parts
570909135822	RUBBER HOSE	TATA spare parts
570909135823	RUBBER HOSE	TATA spare parts
570909135824	REDUCER HOSE	TATA spare parts
570909135825	RUBBER HOSE	TATA spare parts
570909135826	RUBBER HOSE	TATA spare parts
570909135827	RUBBER HOSE	TATA spare parts

570909135841	HOSE BS6	TATA spare parts
570909135844	HOSE	TATA spare parts
570909135848	RUBBER HOSE AIR FILTER TO PIPE BS6	TATA spare parts
570909135850	RUBBER HOSE PIPE TO TC BS6	TATA spare parts
570909135864	HOSE BS6-PH2	TATA spare parts
570909136301	DUST UNLOADER VALVE BS6	TATA spare parts
570909136303	AIR INTAKE NON RETURN VALVE BS6	TATA spare parts
570909136305	CLEAN AIR DUCT-2 BS6	TATA spare parts
570909136912	PIPE ELBOW (FOR DUST UNLOADING)	TATA spare parts
570909137802	DEFLECTOR AIR FILTER BS6	TATA spare parts
570909138204	BRACKET(AMF SENSOR HOUSING)	TATA spare parts
570909138208	BRACKET (TO SUPPORT AIR INTAKE PIPE)	TATA spare parts
570909138217	SUPPORT BRACKET	TATA spare parts
570909138223	SUPPORT BRACKET AIR INTAKE PIPE MTG	TATA spare parts
570909138226	BRACKET AMF SENSOR HOUSING	TATA spare parts
570909138227	BRACKET AIR INTAKE PIPE MTG	TATA spare parts
570909138228	SUPPORT BRACKET AIR INTAKE PIPE MTG	TATA spare parts
570909138230	BRACKET BS6	TATA spare parts
570909138232	BRACKET BS6	TATA spare parts
570909139905	HEX NUT (M10X1.5) BS6	TATA spare parts
570909139908	SERVICE INDICATOR	TATA spare parts
570909139909	BRACKET	TATA spare parts
570909139910	ADAPTER	TATA spare parts
570909139911	CONNECTOR	TATA spare parts
570909139912	HOSE	TATA spare parts
570909139914	CONNECTOR	TATA spare parts
570909139915	WASHER BS6	TATA spare parts
570909139918	SERVICE INDICATOR BS6	TATA spare parts
570909139923	AIR FILTER ELEMENT (PRIMARY) BS6	TATA spare parts
570909139924	AIR FILTER ELEMENT (SECONDARY) BS6	TATA spare parts
570909140104	SUCTION PIPE ASSY COMPLETE	TATA spare parts
570909140108	MANIFOLD ASSY BS6	TATA spare parts
570909140109	HOUSING ASSY AMF SENSOR	TATA spare parts
570909140119	AIR INTAKE PIPE ASSY A/F TO T/C	TATA spare parts
570909140120	RUBBER BUFFER ASSY-OFFER DRG	TATA spare parts
570909140125	HOUSING ASSY BS6	TATA spare parts
570909140126	CLAMP ASSY BS6	TATA spare parts
570909140127	AIR DUCT ASSY CLEAN BS6	TATA spare parts
570909140130	AIR DUCT ASSY DIRTY BS6	TATA spare parts
570909140132	AIR DUCT ASSY CLEAN BS6	TATA spare parts
570909140137	CLAMP BS6	TATA spare parts
570909140140	AIR DUCT ASSY CLEAN BS6	TATA spare parts
570909140141	CLEAN AIR DUCT-3 BS6	TATA spare parts
570909140162	AIR CLEANER ASSY BS6-PH2	TATA spare parts
570909140174	ASSY. AIR FILTER MTG BRACKET 5L Y1 LPT	TATA spare parts
570909140179	AIR DUCT ASSY COMPLETE DIRTY SIDE	TATA spare parts
570909140182	CLAMP ASSY BS6	TATA spare parts

570909140184	CLAMP ASSY BS6	TATA spare parts
570909140185	CLAMP ASSY BS6	TATA spare parts
570909140186	RUBBER BELLOW ASSY BS6	TATA spare parts
570909140188	ISOLATOR ASSY BS6	TATA spare parts
570909140189	SUCTION PIPE ASSY BS6	TATA spare parts
570909140191	SUCTION PIPE ASSY AIR FILTER	TATA spare parts
570909140192	AIR DUCT ASSY DIRTY	TATA spare parts
570909140193	SUCTION PIPE ASSY BS6	TATA spare parts
570909140194	AIR DUCT ASSY CLEAN	TATA spare parts
570909140206	AIR DUCT ASSY CLEAN	TATA spare parts
570909140207	AIR DUCT ASSY DIRTY	TATA spare parts
570909140208	AIR DUCT ASSY CLEAN BS6	TATA spare parts
570909140209	AIR INTAKE PIPE ASSY A/F TO T/C BS6	TATA spare parts
570909140210	AIR DUCT ASSY BS6	TATA spare parts
570909140212	RUBBER BELLOW ASSY	TATA spare parts
570909140216	SUCTION PIPE ASSY BS6	TATA spare parts
570909140217	SET-AIR INTAKE PIPE HOSE & CLAMPS BS6	TATA spare parts
570909140218	AIR FILTER ASSY BS6	TATA spare parts
570909140219	SET-AIR INTAKE PIPE WITH HOSE & CLAMPS B	TATA spare parts
570909140220	HOSE ASSY BS6	TATA spare parts
570909140222	AIR FILTER ASSY BS6-PH2	TATA spare parts
570909140251	SNORKEL ASSY AIR INTAKE	TATA spare parts
570909140255	ISOLATOR ASSY BS6	TATA spare parts
570909140257	AIR FILTER ASSY BS6	TATA spare parts
570909140264	SUCTION PIPE ASSY BS6	TATA spare parts
570909140265	HOSE ASSY	TATA spare parts
570909140266	AIR DUCT BS6	TATA spare parts
570909140267	T-BOLT HOSE CLAMP BS6	TATA spare parts
570909140270	T-BOLT HOSE CLAMP BS6	TATA spare parts
570909140272	SUPPORT BRACKET BS6	TATA spare parts
570909140275	BRACKET ASSY AIR FILTER MTG	TATA spare parts
570909140276	AIR DUCT ASSY DIRTY BS6	TATA spare parts
570909140277	BRACKET ASSY AIR FILTER MTG BS6	TATA spare parts
570909140278	AIR DUCT ASSY CLEAN BS6	TATA spare parts
570909140284	AIR DUCT ASSY DIRTY	TATA spare parts
570909140285	HOSE ASSY	TATA spare parts
570909140286	HOSE ASSY	TATA spare parts
570909140287	AIR DUCT ASSY CLEAN	TATA spare parts
570909140288	HOSE ASSY	TATA spare parts
570909140289	BRACKET ASSY BS6	TATA spare parts
570909140290	BRACKET ASSY BS6	TATA spare parts
570909140292	BRACKET ASSY BS6	TATA spare parts
570909140294	AIR DUCT ASSY CLEAN BS6	TATA spare parts
570909140295	HOSE ASSY BS6	TATA spare parts
570909140296	AIR DUCT ASSY BS6	TATA spare parts
570909140304	AIR DUCT ASSY CLEAN BS6	TATA spare parts
570909140307	PIPE ASSY BS6	TATA spare parts

570909140308	PIPE ASSY BS6	TATA spare parts
570909140309	BRACKET ASSY BS6	TATA spare parts
570909140312	AIR DUCT ASSY CLEAN BS6	TATA spare parts
570909140313	AIR FILTER ASSY BS6	TATA spare parts
570909140314	AIR DUCT ASSY BS6	TATA spare parts
570909140317	AIR DUCT ASSY CLEAN BS6	TATA spare parts
570909140318	BRACKET ASSY BS6	TATA spare parts
570909140319	PIPE ASSY BS6	TATA spare parts
570909140322	CLAMP BS6	TATA spare parts
570909140323	CLAMP ASSY BS6	TATA spare parts
570909140324	PIPE ASSY BS6	TATA spare parts
570909140325	PIPE ASSY BS6	TATA spare parts
570909140326	PIPE ASSY BS6	TATA spare parts
570909140327	PIPE ASSY BS6	TATA spare parts
570909140331	BRACKETASSY BS6	TATA spare parts
570909140332	BRACKETASSY BS6	TATA spare parts
570909140333	BRACKETASSY BS6	TATA spare parts
570909140334	BRACKETASSY BS6	TATA spare parts
570909140337	HOSE ASSY BS6	TATA spare parts
570909140340	HOSE ASSY	TATA spare parts
570909140345	AIR DUCT ASSY CLEAN BS6	TATA spare parts
570909140346	PIPEASSY BS6	TATA spare parts
570909140348	CLAMP ASSY BS6	TATA spare parts
570909140354	AIR CLEANER ASSY WITH MTG BRACKET BS6-PH	TATA spare parts
570909140355	AIR DUCT ASSY CLEAN BS6-PH2	TATA spare parts
570909140361	PIPE ASSY BS6-PH2	TATA spare parts
570909145809	HOSE AIR FILTER OUTLET BS6	TATA spare parts
570909145810	HOSE TURBOCHARGER INTAKE BS6	TATA spare parts
570909145813	AIR DUCT BS6	TATA spare parts
570909145815	ELBOW HOSE BS6-PH2	TATA spare parts
570909145817	HOSE TURBOCHARGER INTAKE BS6	TATA spare parts
570909145820	AIR DUCT BS6	TATA spare parts
570909145821	AIR DUCT BS6	TATA spare parts
570909145822	AIR DUCT BS6	TATA spare parts
570909145824	AIR DUCT ASSY BS6	TATA spare parts
570909145825	HOSE REDUCER BS6	TATA spare parts
570909145826	HOSE BS6	TATA spare parts
570909145827	DUCT BS6	TATA spare parts
570909145828	DUCT BS6	TATA spare parts
570909145863	HOSE AIR FILTER PIPE TO TC BS6-PH2	TATA spare parts
570909145864	BELLOW AIR FILTER BS6-PH2	TATA spare parts
570909147801	SEAL RING BS6	TATA spare parts
570909149901	NIPPLE BS6	TATA spare parts
570909149902	AIR DUCT DIRTY BS6	TATA spare parts
570909149904	AIR DUCT CLEAN BS6	TATA spare parts
570909149905	NIPPLE BS6	TATA spare parts
570913107801	SEALING RING AIR COMPRESSOR BS6	TATA spare parts

570913130103	BRACKET ASSY AIR COMPRESSOR PIPE MTG	TATA spare parts
570913130106	ASSY SUPPORT BRACKET (AIR COMPRESSOR)	TATA spare parts
570913130112	PIPE ASSY WITH FERRULE & COUPLING NUT	TATA spare parts
570913130114	PIPE ASSY WITH CAP NUT & FERRULE	TATA spare parts
570913130119	SUPPORT BRACKET ASSY BS6	TATA spare parts
570913130121	PIPE ASSY WITH COUPLING NUT & FERRULE	TATA spare parts
570913130126	SUPPORT BRACKET ASSY	TATA spare parts
570913130127	PIPE ASSY WITH COUPLING NUT & FERRULE BS	TATA spare parts
570913130131	PIPE ASSY BS6	TATA spare parts
570913130134	PIPE ASSY WITH COUPLING NUT & FERRULE BS	TATA spare parts
570913130135	PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
570913130138	PIPE ASSY WITH COUPLING NUT & FERRULE	TATA spare parts
570913130139	PIPE ASSY WITH COUPLING NUT & FERRULE BS	TATA spare parts
570913130144	AIR SUPPLY PIPE ASSY AIR COMPRESSOR	TATA spare parts
570913130145	AIR SUPPLY PIPE ASSY AIR COMPRESSOR BS6	TATA spare parts
570913130146	PIPE ASSY WITH CAP NUT & FERRULE BS6	TATA spare parts
570913130148	PIPE ASSY AIR COMPRESSOR BS6	TATA spare parts
570913130149	PIPE ASSY WITH COUPLING NUT & FERRULE BS	TATA spare parts
570913130150	PIPE ASSY WITH COUPLING NUT & FERRULE BS	TATA spare parts
570913130151	AIR SUPPLY PIPE ASSY AIR COMPRESSOR BS6	TATA spare parts
570913130154	PIPE ASSY WITH FERRULE & AMP NUT BS6	TATA spare parts
570913130156	PIPE ASSY WITH COUPLING NUT & FERRULE BS	TATA spare parts
570913130157	PIPE ASSY WITH CAP NUT & FERRULE BS6-PH2	TATA spare parts
570913130158	AIR SUPPLY PIPE ASSY AIR COMPRESSOR BS6-	TATA spare parts
570913130159	PIPE ASSY WITH COUPLING NUT & FERRULE BS	TATA spare parts
570913133304	CLAMP (COMP. INLET LINE)	TATA spare parts
570913133306	CLAMP	TATA spare parts
570913133307	CLAMP BS6	TATA spare parts
570913135829	HOSE AIR INTAKE TO AIR COMPRESSOR	TATA spare parts
570913135839	HOSE AIR INTAKE TO AIR COMPRESSOR BS6-PH	TATA spare parts
570913136915	PIPE AIR COMPRESSOR INTAKE BS6	TATA spare parts
570913138203	SUPPORT BRACKET (FOR AIR COMPRESSOR) BS6	TATA spare parts
570914100105	ASSY FLANGE HEATER UNIT	TATA spare parts
570914100109	BRACKET	TATA spare parts
570914100112	ADAPTER INTAKE MANIFOLD	TATA spare parts
570914103802	INTAKE MANIFOLD WITH TEMPERATURE SENSOR	TATA spare parts
570914103803	ADAPTER (INTAKE MANIFOLD)	TATA spare parts
570914103810	ADAPTER INTAKE MANIFOLD	TATA spare parts
570914103814	ADAPTER INTAKE MANIFOLD BS6	TATA spare parts
570914103815	ADAPTER INTAKE MANIFOLD	TATA spare parts
570914103816	ADAPTER INTAKE MANIFOLD BS6	TATA spare parts
570914103817	INTAKE MANIFOLD BS6	TATA spare parts
570914105302	GASKET (INTAKE MANIFOLD TO HEATER FLANGE)	TATA spare parts
570914105303	GASKET (INTAKE MANIFOLD TO HEATER FLANGE)	TATA spare parts
570914105304	GASKET INTAKE MANIFOLD	TATA spare parts
570914110101	EGR VALVE ASSY	TATA spare parts
570914110104	HEAT SHIELD	TATA spare parts



570914110106	ASSEMBLY EGR COOLER	TATA spare parts
570914110108	ASSY.TUBE (EGR COOLER OUTLET TO WP)	TATA spare parts
570914110109	TUBE ASSY WITH CRIMPED RUBBER HOSE (EGR	TATA spare parts
570914110113	PIPE ASSY EGR COOLER TO AIR INTAKE ASSY	TATA spare parts
570914110114	ASSY EGR PIPE (EXH. MANI. TO EGR VALVE)	TATA spare parts
570914110121	ASSEMBLY EGR COOLER WITH EGR VALVE	TATA spare parts
570914110127	PUMP ASSY UREA DOSE BS6	TATA spare parts
570914110131	DEF INJECTOR BS6	TATA spare parts
570914110136	DOC ASSY	TATA spare parts
570914110137	PARTIAL FLOW FILTER ASSY CERAMIC	TATA spare parts
570914110138	CATCON ASSY DOC & PFF	TATA spare parts
570914110142	AFTER TREATMENT SYSTEM BS6	TATA spare parts
570914110147	EGR COOLER ASSY WITH EGR VALVE BS6	TATA spare parts
570914110149	EGR VALVE ASSY BS6	TATA spare parts
570914110150	THROTTLE VALVE ASSY BS6	TATA spare parts
570914110160	DP TUBEHIGH PRESSURE BS6	TATA spare parts
570914110161	DP TUBELOW PRESSURE BS6	TATA spare parts
570914110162	PIPE ASSY EGR COOLER TO INTAKE MANIFOLD	TATA spare parts
570914110163	DOC ASSY BS6	TATA spare parts
570914110164	DPF ASSY BS6	TATA spare parts
570914110169	AFTER TREATMENT SYSTEM BS6	TATA spare parts
570914110170	DP TUBELOW PRESSURE BS6	TATA spare parts
570914110176	CANNING ASSYDPF BS6	TATA spare parts
570914110179	SET-AFTER TREATMENT SYSTEM BS6	TATA spare parts
570914110182	PIPE ASSY BS6	TATA spare parts
570914110183	EGR COOLER ASSY WITH EGR VALVE BS6	TATA spare parts
570914110185	PIPE ASSY EGR COOLER TO INTAKE MANIFOLD	TATA spare parts
570914110190	CANNING ASSY DIESEL OXIDATION CATALYST B	TATA spare parts
570914110191	CANNING ASSY WITH MIXER SCR BS6	TATA spare parts
570914110192	SCR W/MIXER ASSY - MCV BUS 5L	TATA spare parts
570914110193	SCR W/MIXER ASSY - MHCV TRUCK 5L	TATA spare parts
570914110194	PIPE ASSY BS6	TATA spare parts
570914110195	DPF ASSY - MCV BUS 5L	TATA spare parts
570914110196	DOC ASSY - MCV BUS 5L	TATA spare parts
570914110197	AFTER TREATMENT SYSTEM ASSY BS6	TATA spare parts
570914110198	DIESEL OXIDATION CATALYST ASSY BS6	TATA spare parts
570914110201	CANNING ASSY WITH MIXER SCR	TATA spare parts
570914110202	PIPE ASSY BS6	TATA spare parts
570914110203	PIPE ASSY BS6	TATA spare parts
570914110204	AFTER TREATMENT SYSTEM ASSY BS6	TATA spare parts
570914110208	COVER BS6	TATA spare parts
570914110209	COVER BS6	TATA spare parts
570914110210	COVER BS6	TATA spare parts
570914110211	COVER BS6	TATA spare parts
570914110212	COVER BS6	TATA spare parts
570914110213	COVER BS6	TATA spare parts
570914110214	COVER BS6	TATA spare parts

570914110215	COVER BS6	TATA spare parts
570914110216	CLAMP ASSY V-BAND BS6	TATA spare parts
570914110217	COVER BS6	TATA spare parts
570914110218	COVER BS6	TATA spare parts
570914110219	COVER BS6	TATA spare parts
570914110220	COVER BS6	TATA spare parts
570914110221	COVER BS6	TATA spare parts
570914110222	COVER BS6	TATA spare parts
570914110223	COVER BS6	TATA spare parts
570914110245	BRACKET ASSY (UREA QUALITY SENSOR MOUNTI	TATA spare parts
570914110247	AFTER TREATMENT SYSTEM ASSY BS6	TATA spare parts
570914110251	DOC ASSY -SIGNA 4221.T 5L	TATA spare parts
570914110252	DPF ASSY - SIGNA 4221.T 5L	TATA spare parts
570914110253	SCR W/MIXER ASSY - SIGNA 4221.T 5L	TATA spare parts
570914110256	TRAY ASSY BS6	TATA spare parts
570914110267	AFTER TREATMENT SYSTEM ASSY BS6	TATA spare parts
570914110269	COOLANT PIPE ASSY BS6-PH2	TATA spare parts
570914110270	AFTER TREATMENT SYSTEM ASSY	TATA spare parts
570914110273	AFTER TREATMENT SYSTEM ASSY	TATA spare parts
570914110280	SET-AFTER TREATMENT SYSTEM BS6-PH2	TATA spare parts
570914110287	HEAT SHIELD ASSY BS6-PH2	TATA spare parts
570914110295	HEAT SHIELD ASSY BS6-PH2	TATA spare parts
570914110296	PIPE ASSY EXH MANIFOLD TO EGR VALVE BS6-	TATA spare parts
570914110298	COOLANT PIPE ASSY BS6-PH2	TATA spare parts
570914110301	HEAT SHIELD ASSY BS6	TATA spare parts
570914113701	EXHAUST MANIFOLD	TATA spare parts
570914113703	CASTING PIPE (EXH.MANIFOLD TO EGR VALVE)	TATA spare parts
570914113704	ADAPTER EXHAUST	TATA spare parts
570914113705	EXHAUST ELBOW (BORG WARNER TURBO)	TATA spare parts
570914113712	EXHAUST ELBOW¿BS6	TATA spare parts
570914113713	ADAPTER EXHAUST¿BS6	TATA spare parts
570914113714	EXHAUST ELBOW BS6	TATA spare parts
570914113715	SUPPORT BRACKET BS6	TATA spare parts
570914113716	EXHAUST ELBOW BS6	TATA spare parts
570914113717	SUPPORT BRACKET BS6	TATA spare parts
570914113718	SUPPORT BRACKET EXHAUST ELBOW BS6	TATA spare parts
570914113719	SUPPORT BRACKET BS6	TATA spare parts
570914113721	EXHAUST ELBOW BS6-PH2	TATA spare parts
570914113725	ADAPTER EXHAUST BS6-PH2	TATA spare parts
570914114205	CLAMP BS6	TATA spare parts
570914115306	GASKET EXHAUST MANIFOLD	TATA spare parts
570914115307	GASKET EXH MANIFOLD TO TURBOCHARGER	TATA spare parts
570914115308	GASKET TC TO INTERMEDIATE PIPE	TATA spare parts
570914115309	GASKET EGR PIPE TO EGR VALVE	TATA spare parts
570914115312	GASKET BS6	TATA spare parts
570914115801	RUBBER HOSE(WATER DIST.RAIL TO EGRVALVE)	TATA spare parts
570914115803	RUBBER HOSE (ASSY TUBE TO T.S)	TATA spare parts

570914115804	RUBBER HOSE (EGR COOLER TO ASSY TUBE)	TATA spare parts
570914115812	RUBBER HOSE BS6	TATA spare parts
570914115815	RUBBER HOSE BS6	TATA spare parts
570914115816	RUBBER HOSE BS6	TATA spare parts
570914115817	RUBBER HOSE BS6	TATA spare parts
570914115818	RUBBER HOSE BS6	TATA spare parts
570914115823	RUBBER HOSE BS6	TATA spare parts
570914115824	RUBBER HOSE BS6	TATA spare parts
570914116502	FLANGED CLINCH NUT M10 X 1.5	TATA spare parts
570914116905	CONNECTOR BS6-PH2	TATA spare parts
570914118201	SUPPORT BRACKET ( EXHAUST ELBOW )	TATA spare parts
570914118207	PROTECTIVE COVER (UREA QUALITY LEVEL SEN	TATA spare parts
570914118601	SPACER	TATA spare parts
570914118801	STUD BS6	TATA spare parts
570914118802	STUD BS6	TATA spare parts
570914119903	FROST COMPENSATION MEMBRANE FILTER	TATA spare parts
570914119904	CLAMP ASSY V-BAND BS6	TATA spare parts
570914119908	HEAT SHIELD ASSY BS6	TATA spare parts
570914119909	BRACKET ASSY WITH SENSOR TABLE DP MTG BS	TATA spare parts
570914119910	BRACKET ASSY SENSOR MTG BS6	TATA spare parts
570914119912	STAND-UP PLATE BS6	TATA spare parts
570914119913	BRACKET ASSY WITH SENSOR TABLE DP MTG BS	TATA spare parts
570914119915	BRACKET ASSY SENSOR MTG BS6	TATA spare parts
570914119923	FILTER COVER ASSY WITH PRESSURE ELEMENT	TATA spare parts
570914119924	CONNECTOR ASSY WITH O-RING INLET BS6	TATA spare parts
570914119925	CONNECTOR ASSY WITH O-RING OUTLET BS6	TATA spare parts
570914119926	CONNECTOR ASSY WITH O-RING BACKFLOW BS6	TATA spare parts
570914119929	WASHER BS6	TATA spare parts
570914119930	WASHER BS6	TATA spare parts
570914119931	SCREW BS6	TATA spare parts
570914119934	SCREW BS6	TATA spare parts
570914119937	BRACKET ASSY WITH SENSOR TABLE DP MTG BS	TATA spare parts
570914510101	ASSY. TURBOCHARGER BS3/4	TATA spare parts
570914510105	TURBOCHARGER ASSY	TATA spare parts
570914510106	TURBOCHARGER ASSY	TATA spare parts
570914510107	TURBOCHARGER ASSY BS6	TATA spare parts
570914510108	TURBOCHARGER ASSY BS6	TATA spare parts
570914510111	CLAMP ASSY V-BAND BS6	TATA spare parts
570914510113	TURBOCHARGER ASSY	TATA spare parts
570914510114	TURBOCHARGER ASSY BS6-PH2	TATA spare parts
570914510116	TURBOCHARGER ASSY BS6-PH2	TATA spare parts
570914519901	V BAND CLAMP	TATA spare parts
570914600103	INTERCOOLER ASSY	TATA spare parts
570914600110	INTERCOOLER ASSY M/S TATATOYO	TATA spare parts
570914600114	PIPE ASSY TURBOCHARGER TO INTERCOOLER	TATA spare parts
570914600115	PIPE ASSY TURBOCHARGER TO INTERCOOLER	TATA spare parts
570914600119	PIPE ASSY TURBOCHARGER TO INTERCOOLER	TATA spare parts

570914600126	PIPE ASSY TC TO INTERCOOLER	TATA spare parts
570914600127	INTERCOOLER ASSY BS6	TATA spare parts
570914600128	CLAMP INTERCOOLER PIPE BS6	TATA spare parts
570914600130	INTERCOOLER ASSY BS6	TATA spare parts
570914600132	PIPE ASSY TURBOCHARGER TO INTERCOOLER BS	TATA spare parts
570914600136	RUBBER BUFFER BS6-PH2	TATA spare parts
570914600139	PIPE ASSY TURBOCHARGER TO INTERCOOLER BS	TATA spare parts
570914600142	INTERCOOLER ASSY BS6	TATA spare parts
570914600144	PIPE ASSY TURBOCHARGER TO INTERCOOLER BS	TATA spare parts
570914600146	CLAMP ASSY	TATA spare parts
570914600147	CLAMP ASSY	TATA spare parts
570914603303	SUPPORT BS6	TATA spare parts
570914603306	SUPPORT BRACKET BS6-PH2	TATA spare parts
570914603802	ADAPTER TC COMPRESSOR OUTLET	TATA spare parts
570914603803	PIPE INTERMEDIATE	TATA spare parts
570914604204	HOSE CLAMP TB-60	TATA spare parts
570914604205	HOSE CLAMP TB-72	TATA spare parts
570914604208	P-TYPE CLAMP PIPE TC TO IC	TATA spare parts
570914604210	P-TYPE CLAMP PIPE TC TO IC BS6-PH2	TATA spare parts
570914604211	P-TYPE CLAMP PIPE TC TO IC BS6-PH2	TATA spare parts
570914605809	HOSE INTERCOOLER TO INTAKE MANIFOLD	TATA spare parts
570914605810	HOSE INTERCOOLER TO INTAKE MANIFOLD	TATA spare parts
570914605814	HOSE INTERCOOLER TO INTAKE MANIFOLD	TATA spare parts
570914605820	HOSE INTERCOOLER TO INTAKE MANIFOLD	TATA spare parts
570914605821	HOSE INTERCOOLER TO INTAKE MANIFOLD BS6	TATA spare parts
570914605822	HOSE IC TO INTAKE MANIFOLD BS6	TATA spare parts
570914605823	HOSE TC PIPE END TO INTERCOOLER	TATA spare parts
570914605824	HOSE IC PIPE TO INTAKE ELBOW BS6	TATA spare parts
570914605829	HUMP HOSE BS6	TATA spare parts
570914605830	HOSE TC PIPE END TO INTERCOOLER BS6	TATA spare parts
570914605831	HOSE INTERCOOLER TO INTAKE MANIFOLD BS6	TATA spare parts
570914605834	HOSE BS6-PH2	TATA spare parts
570914606801	PIPE TC TO INTERCOOLER	TATA spare parts
570914606803	PIPE INTERCOOLER INTAKE BS6	TATA spare parts
570914606804	PIPE INTERCOOLER TO INTAKE MANIFOLD BS6	TATA spare parts
570914606917	PIPE BS6-PH2	TATA spare parts
570914608204	SUPPORT BRACKET INTERCOOLER PIPE	TATA spare parts
570914608205	SUPPORT BRACKET (TC TO IC PIPE)	TATA spare parts
570914608211	SUPPORT BRACKET BS6	TATA spare parts
570914608212	SUPPORT BRACKET PIPE TC TO IC BS6-PH2	TATA spare parts
570914608213	SUPPORT BRACKET PIPE TC TO IC BS6-PH2	TATA spare parts
570914609901	ELBOW CAST TC COMPRESSOR OUTLET	TATA spare parts
570915143201	HEX FLANGE BOLT M10X174.5	TATA spare parts
570915143701	BRACKET ALTERNATOR MTG	TATA spare parts
570915143804	BRACKET ALTERNATOR MTG BS6-PH2	TATA spare parts
570915144801	O-RING 31.5X2.65-C-VITON-TS16222	TATA spare parts
570915146301	POLY V BELT BS6-PH2	TATA spare parts

570915148201	DISTANCE PLATE (ALTERNATOR MOUNTING)	TATA spare parts
570915189902	DISTANCE PIECE (INJECTOR WIRING HARNESS)	TATA spare parts
570915220102	OIL PRESSURE & TEMP SENSOR BS6-PH2	TATA spare parts
570915240101	SENSOR PARTICULATE MATTER	TATA spare parts
570915240105	SENSOR PARTICULATE MATTER BS6-PH2	TATA spare parts
570915240108	NOX SENSOR BS6-PH2	TATA spare parts
570915240109	UREA QUALITY SENSOR BS6-PH2	TATA spare parts
570915240110	UREA QUALITY SENSOR BS6-PH2	TATA spare parts
570915250101	UREA SUPPLY MODULE WITH HEATER BS6	TATA spare parts
570915250102	UREA SUPPLY MODULE BS6-PH2	TATA spare parts
570915400101	CAM SENSOR	TATA spare parts
570915400104	AIR TEMPRETURE SENSOR	TATA spare parts
570915400105	AIR MASS FLOW SENSOR	TATA spare parts
570915400107	PFM SENSOR BS6	TATA spare parts
570915400108	EXHAUST TEMPERATURE SENSOR BS6	TATA spare parts
570915400109	NOX SENSOR BS6	TATA spare parts
570915400110	DIFFERENTIAL PRESSURE SENSOR INTRA AND 141	TATA spare parts
570915400112	AIR TEMPERATURE SENSOR BS6	TATA spare parts
570915400114	TEMPERATURE SENSOR BS6	TATA spare parts
570915400115	TEMPERATURE SENSOR CATCON BS6	TATA spare parts
570915400116	UREA LEVEL SENSOR BS6	TATA spare parts
570915400117	UREA LEVEL SENSOR BS6	TATA spare parts
570915400118	UREA QUALITY SENSOR UREA QUALITY SENSOR	TATA spare parts
570915400119	UREA QUALITY SENSOR BS6	TATA spare parts
570915407701	O-RING BS6	TATA spare parts
570915408201	BRACKET BS6	TATA spare parts
570915409901	UREA LEVEL SENSOR FILTER BS6	TATA spare parts
570918100101	ASSY OIL PUMP COMPLETE	TATA spare parts
570918105401	GEAR OIL PUMP BS6	TATA spare parts
570918108701	SPRING OIL PRESSURE RELIEF VALVE	TATA spare parts
570918109001	OIL PRESSURE RELIEF VALVE	TATA spare parts
570918130101	OIL FILTER ELEMENT (SPINON) BS3/4	TATA spare parts
570918130102	OIL FILTER ELEMENT (SPINON) BS4	TATA spare parts
570918150103	ASSY STRAINER (FOR OIL PUMP)	TATA spare parts
570918150110	STRAINER ASSY OIL PUMP	TATA spare parts
570918150112	SUPPORT BRACKET ASSY STRAINER	TATA spare parts
570918150118	STRAINER ASSY OIL PUMP BS6	TATA spare parts
570918150125	STRAINER ASSY OIL PUMP BS6	TATA spare parts
570918153302	FLANGE(OIL PUMP STAINER)	TATA spare parts
570918153303	FLANGE OIL PUMP STRAINER	TATA spare parts
570918158219	BRACKET STRAINER MTG	TATA spare parts
570918170102	OIL COOLER ASSY	TATA spare parts
570918170103	ASSEMBLY CENTRIFUGE FILTER	TATA spare parts
570918170104	ASSY TC OIL SUPPLY LINE	TATA spare parts
570918170106	NOZZLE ASSY PISTON COOLING	TATA spare parts
570918170111	ASSY OIL RETURN LINE (TC)	TATA spare parts
570918170118	OIL COOLER ASSY	TATA spare parts

570918170119	OIL COOLER ASSY WITH COVER	TATA spare parts
570918170120	OIL COOLER ASSY WITH COVER	TATA spare parts
570918170121	KIT-CENTRIFUGE FILTER	TATA spare parts
570918170122	KIT-CENTRIFUGE SEALS	TATA spare parts
570918170123	KIT-CENTRIFUGE ROTOR	TATA spare parts
570918170124	KIT-CENTRIFUGE FILTER COVER	TATA spare parts
570918170125	PISTON COOLING NOZZLE ASSY	TATA spare parts
570918170126	OIL COOLER ASSY WITH COVER	TATA spare parts
570918170127	TC OIL SUPPLY LINE ASSY BS6	TATA spare parts
570918170129	OIL COOLER ASSY WITH COVER BS6	TATA spare parts
570918170133	OIL COOLER ASSY	TATA spare parts
570918170138	OIL RETURN LINE ASSY BS6	TATA spare parts
570918170140	OIL COOLER ASSY BS6	TATA spare parts
570918170145	OIL COOLER ASSY WITH COVER BS6	TATA spare parts
570918170146	OIL COOLER ASSY WITH COVER BS6	TATA spare parts
570918170152	OIL COOLER ASSY WITH COVER BS6	TATA spare parts
570918170163	OIL COOLER ASSY WITH COVER BS6-PH2	TATA spare parts
570918170174	OIL COOLER ASSY WITH COVER BS6-PH2	TATA spare parts
570918170178	TC OIL SUPPLY LINE ASSY BS6-PH2	TATA spare parts
570918170184	THERMOSTAT OIL COOLER BS6-PH2	TATA spare parts
570918173207	SOCKET HEAD CAP SCREW BS6	TATA spare parts
570918173208	SOCKET HEAD CAP SCREW BS6	TATA spare parts
570918173209	SOCKET HEAD CAP SCREW BS6-PH2	TATA spare parts
570918175302	GASKET	TATA spare parts
570918175305	GASKET TC RETURN ADAPTER	TATA spare parts
570918175307	GASKET (OIL COOLER COVER-BLOCK) BS3/4/6	TATA spare parts
570918175309	GASKET OIL COOLER BS6	TATA spare parts
570918175317	GASKET THERMOSTAT COVER BS6-PH2	TATA spare parts
570918176701	FIXATION BOLT	TATA spare parts
570918176702	FIXATION BOLT BS6	TATA spare parts
570918176801	PIPE UNION BOLT BS6	TATA spare parts
570918178703	SPRING PRESSURE RELIEF VALVE BS6	TATA spare parts
570918178704	SPRING BYPASS VALVE BS6	TATA spare parts
570918179003	PRESSURE RELIEF VALVE BS6	TATA spare parts
570918179004	BYPASS VALVE OIL COOLER BS6	TATA spare parts
570918179201	SEALING WASHER BS6	TATA spare parts
570918179202	SEALING WASHER BS6	TATA spare parts
570918179203	SEALING WASHER BS6	TATA spare parts
570918179204	SEALING WASHER BS6	TATA spare parts
570918179205	SEALING WASHER BS6	TATA spare parts
570918179225	WASHER BS6	TATA spare parts
570918179905	ADAPTER OIL FILTER	TATA spare parts
570918179906	SEALING PLUG BS6	TATA spare parts
570918179907	SEALING PLUG BS6	TATA spare parts
570918179908	SEALING PLUG BS6	TATA spare parts
570918179914	SEALING PLUG BS6	TATA spare parts
570918179915	SEALING PLUG BS6	TATA spare parts

570918179936	ADAPTER OIL FILTER BS6	TATA spare parts
570920100102	ASSY. WATER PUMP 6PK PULLEY N/HVAC BS3-6	TATA spare parts
570920100104	WATER PUMP PULLEY	TATA spare parts
570920100107	INTEGRAL SHAFT BEARING WATER PUMP BS6	TATA spare parts
570920100108	SEAL ASSY WATER PUMP BS6	TATA spare parts
570920100110	WATER PUMP ASSY WITH PULLEY	TATA spare parts
570920100112	WATER PUMP ASSY WITH PULLEY BS6	TATA spare parts
570920100114	WATER PUMP ASSY WITH PULLEY BS6	TATA spare parts
570920105303	GASKET (WATER PUMP TO BLOCK-1)	TATA spare parts
570920105304	GASKET WATER PUMP TO BLOCK-2	TATA spare parts
570920105305	GASKET WATER PUMP	TATA spare parts
570920105306	GASKET WATER PUMP BS6	TATA spare parts
570920106902	TUBE(WATER PUMP TO EXPANSION TANK)	TATA spare parts
570920120102	WATER DISTRIBUTION RAIL ASSY	TATA spare parts
570920120105	COOLANT HOSE ASSY WATER PUMP TO AIR COMP	TATA spare parts
570920120108	COVER ASSY WITH TUBE THERMOSTAT	TATA spare parts
570920120123	COOLANT ADAPTER ASSY (AIR COMPRESSOR )	TATA spare parts
570920120124	COOLANT PIPE ASSY AIR COMPRESSOR OUTLET	TATA spare parts
570920120128	COOLANT HOSE ASSY WATER PUMP TO AIR COMP	TATA spare parts
570920120129	ASSEMBLY ADAPTOR WITH TUBE	TATA spare parts
570920120130	THERMOSTAT ASSY (SOT 87 DEG)	TATA spare parts
570920120135	COOLANT HOSE ASSY WATER PUMP TO AIR COMP	TATA spare parts
570920120136	COOLANT PIPE ASSY AIR COMPRESSOR OUTLET	TATA spare parts
570920120141	COOLANT PIPE ASSY BS6	TATA spare parts
570920120142	COOLANT HOSE ASSY BS6	TATA spare parts
570920120145	THERMOSTAT ASSY	TATA spare parts
570920120146	COOLANT HOSE ASSY WATER PUMP TO AIR COMP	TATA spare parts
570920120147	COOLANT PIPE ASSY	TATA spare parts
570920120149	WATER DISTRIBUTION RAIL ASSY BS6	TATA spare parts
570920120157	COOLANT HOSE ASSY WATER PUMP TO AIR COMP	TATA spare parts
570920120158	COOLANT HOSE ASSY	TATA spare parts
570920120159	WATER DISTRIBUTION RAIL ASSY BS6	TATA spare parts
570920120168	THERMOSTAT ASSY BS6-PH2	TATA spare parts
570920120171	COOLANT HOSE ASSY BS6-PH2	TATA spare parts
570920120173	COVER ASSY THERMOSTAT BS6-PH2	TATA spare parts
570920120175	ADAPTER ASSY WITH TUBE BS6-PH2	TATA spare parts
570920120176	BRACKET ASSY BS6-PH2	TATA spare parts
570920123303	BRACKET BS6-PH2	TATA spare parts
570920123304	BRACKET BS6-PH2	TATA spare parts
570920123802	THERMOSTAT COVER	TATA spare parts
570920125302	GASKET WATER DISTRI RAIL TO CYL HEAD	TATA spare parts
570920126907	CONNECTOR THERMOSTAT VENT BS6	TATA spare parts
570920126914	ADAPTER(AIR COMPRESSOR COOLANT LINE)	TATA spare parts
570920126920	CONNECTOR	TATA spare parts
570920140101	BRACKET ASSY FAN MTG	TATA spare parts
570920140102	ASSY VISCOUS FAN	TATA spare parts
570920140104	ASSY FAN MOUNTING BRACKET	TATA spare parts

570920140112	ASSY. FAN WITH E-VISCOUS CLUTCH BS4/6	TATA spare parts
570920140118	BRACKET ASSY FAN MTG	TATA spare parts
570920140119	BRACKET ASSY FAN MTG	TATA spare parts
570920140121	BRACKET ASSY FAN MTG BS6	TATA spare parts
570920140127	BRACKET ASSY FAN MTG BS6-PH2	TATA spare parts
570920140128	FAN ASSY WITH VISCOUS CLUTCH BS6-PH2	TATA spare parts
570920141601	DOUBLE ROW ANGULAR CONTACT BEARING-SKF	TATA spare parts
570920143701	BRACKET (FAN MOUNTING) BS6	TATA spare parts
570920143702	BRACKET FAN MTG NON AC BS6	TATA spare parts
570920143804	SPACER FAN	TATA spare parts
570920145501	FLANGE (FAN PULLEY MOUNTING) BS6	TATA spare parts
570920147001	FAN PULLEY BS6	TATA spare parts
570920149201	SPACER FAN PULLEY MTG BS6	TATA spare parts
570920156305	BELT DRIVE PLANE ALTERNATOR 6PK 1575 MM	TATA spare parts
570920156305DF	BELT 6PK 1575MM L ALTERNATOR-5L BS4/6	TATA spare parts
570920156307	BELT FOR DRIVE PLANE-2 WITH AC 1238(6PK)	TATA spare parts
570920156308	BELT FOR DRIVE PLANE-2 6PK - 1025MM(NON-	TATA spare parts
570920156308DF	BELT TENSIONER 6PK 1025MM L-5L BS4/6	TATA spare parts
570920156316	BELT DRIVE PLAIN	TATA spare parts
570922123201	HEX BOLT	TATA spare parts
570922128201	ENGINE LIFTING HOOK CYL HEAD FRONT	TATA spare parts
570922128202	ENGINE LIFTING HOOK CYL HEAD FRONT BS6	TATA spare parts
570922128203	ENGINE LIFTING HOOK CYL HEAD FRONT BS6	TATA spare parts
570922135101	ENGINE MOUNTING ARM FRONT(RH)	TATA spare parts
570922135102	ENGINE MOUNTING ARM FRONT(LH)	TATA spare parts
570922135113	ENGINE MTG ARM REAR-LH	TATA spare parts
570922135114	ENGINE MTG ARM REAR-RH	TATA spare parts
570922135115	ENGINE MTG ARM FRONT-LH	TATA spare parts
570922135116	ENGINE MTG ARM FRONT-RH	TATA spare parts
570922138201	LOCK PLATE	TATA spare parts
570922138202	LOCK PLATE	TATA spare parts
570923110101	TENSIONER ASSEMBLY (DRIVE PLANE 1)	TATA spare parts
570923110102	TENSIONER ASSY WITH AC(DRIVE PLANE-2)	TATA spare parts
570923110103	IDLER (DRIVE PLANE 1)	TATA spare parts
570923110105	TENSIONER ASSEMBLY NON-AC (DRIVE PLANE -	TATA spare parts
570923113709	SUPPORT BRACKET AC COMP MTG	TATA spare parts
570923113713	BRACKET ALTERNATOR MTG BS6-PH2	TATA spare parts
570923113801	TENSIONER BRACKET (NON-AC VERSION)	TATA spare parts
570923116303	POLY V BELT BS6-PH2	TATA spare parts
570923118201	BRACKET ALTERNATOR MTG BS6-PH2	TATA spare parts
570923125401	GEAR AIR COMP	TATA spare parts
570923125402	GEAR AIR COMP	TATA spare parts
570950100102	ASSY RADIATOR INTERCOOLER	TATA spare parts
570950100107	ASSY RADIATOR	TATA spare parts
570950100108	CLAMP ASSY (COOLANT PIPE)	TATA spare parts
570950100125	ASSY. RADIATOR CAP	TATA spare parts
570950100131	ASSEMBLY SUPPORT BRACKET (FOR VENT TUBE)	TATA spare parts



570950100132	ASSEMBLY SUPPORT BRACKET(FOR VENT TUBES)	TATA spare parts
570950100134	ASSEMBLY FILL PIPE WITH CLAMP	TATA spare parts
570950100150	BRACKET ASSY (AUX TANK MTG)	TATA spare parts
570950100153	VENT TUBE ASSY (ENGINE TO AUX TANK)	TATA spare parts
570950100154	PIPE ASSY FILLER LINE WITH CLAMP	TATA spare parts
570950100163	RADIATOR ASSY WITH FRAME	TATA spare parts
570950100164	RADIATOR ASSY WITH INTERCOOLER&AUX TANK	TATA spare parts
570950100167	PIPE ASSY ENGINE TO AUX WATER TANK	TATA spare parts
570950100208	BRACKET ASSY	TATA spare parts
570950100209	COOLING PIPE ASSY THERMOSTAT TO RADIATOR	TATA spare parts
570950100210	ASSY BRACKET (COOLANT PIPE)- CAST PIPE	TATA spare parts
570950100211	ASSY PIPE (RAD TO WP) - CAST PIPE	TATA spare parts
570950100212	ASSY PIPE (RAD TO WP)-2- CAST PIPE	TATA spare parts
570950100216	ASSY RADIATOR INTERCOOLER	TATA spare parts
570950100217	PIPE ASSY THERMOSTAT COVER TO RADIATOR	TATA spare parts
570950100218	PIPE ASSY RADIATOR TO WATER PUMP	TATA spare parts
570950100220	BRACKET ASSY VENT TUBE SUPPORT	TATA spare parts
570950100221	VENT TUBE ASSY AUX WATER TANK TO ENGINE	TATA spare parts
570950100222	AUX WATER TANK ASSY WITH LEVEL SENSOR	TATA spare parts
570950100223	RADIATOR COOLANT TANK	TATA spare parts
570950100225	BRACKET ASSY COOLING PIPE MTG	TATA spare parts
570950100228	AUX WATER TANK ASSY WITH LEVEL SENSOR	TATA spare parts
570950100229	RADIATOR ASSY	TATA spare parts
570950100230	RADIATOR & INTERCOOLER ASSY	TATA spare parts
570950100231	RADIATOR ASSY	TATA spare parts
570950100232	VENT TUBE ASSY	TATA spare parts
570950100240	PIPE ASSY AUX TANK TO RADIATOR	TATA spare parts
570950100244	PIPE ASSY RADIATOR TO WATER PUMP	TATA spare parts
570950100245	COOLING PIPE ASSY THERMOSTAT TO RADIATOR	TATA spare parts
570950100247	SUPPORT BRACKET ASSY	TATA spare parts
570950100248	RADIATOR ASSY WITH FRAME	TATA spare parts
570950100249	KIT-ENGINE COOLING SYSTEM	TATA spare parts
570950100250	PIPE ASSY RADIATOR TO WATER PUMP BS6	TATA spare parts
570950100252	PIPE ASSY ENGINE TO AUX WATER TANK	TATA spare parts
570950100253	BRACKET ASSY DIPSTICK MTG	TATA spare parts
570950100254	KIT-ENGINE COOLING SYSTEM BS6	TATA spare parts
570950100255	WATER FILLER PIPE ASSY WITH CLAMP	TATA spare parts
570950100257	AUX WATER TANK ASSY WITH PRESSURE CAP	TATA spare parts
570950100258	RADIATOR & INTERCOOLER ASSY BS6	TATA spare parts
570950100260	RADIATOR ASSY WITH FRAME BS6	TATA spare parts
570950100262	SET-AUX WATER TANK BS6	TATA spare parts
570950100267	BRACKET ASSY BS6	TATA spare parts
570950100268	COOLANT LINE ASSY BS6	TATA spare parts
570950100269	COOLANT LINE ASSY BS6	TATA spare parts
570950100270	COOLANT LINE ASSY BS6	TATA spare parts
570950100273	PIPE ASSY AUX TANK TO RADIATOR	TATA spare parts
570950100274	PIPE ASSY WITH CLAMP BS6	TATA spare parts

570950100279	PIPE ASSY AUX TANK TO RADIATOR BS6	TATA spare parts
570950100283	RADIATOR ASSY BS6	TATA spare parts
570950100288	BRACKET ASSY BS6	TATA spare parts
570950100295	RADIATOR ASSY WITH FRAME BS6	TATA spare parts
570950100297	SUPPORT BRACKET ASSY BS6	TATA spare parts
570950100299	PIPE ASSY BS6	TATA spare parts
570950100306	KIT-ENGINE COOLING SYSTEM BS6	TATA spare parts
570950100307	COOLANT LINE ASSY BS6	TATA spare parts
570950100308	COOLANT LINE ASSY BS6	TATA spare parts
570950100309	COOLANT LINE ASSY BS6	TATA spare parts
570950100311	BRACKET ASSY BS6	TATA spare parts
570950100317	KIT-ENGINE COOLING SYSTEM BS6	TATA spare parts
570950100319	BRACKET ASSY BS6	TATA spare parts
570950100321	SUPPORT BRACKET ASSY BS6	TATA spare parts
570950100324	PIPE ASSY BS6	TATA spare parts
570950100325	PIPE ASSY BS6	TATA spare parts
570950100326	BRACKET ASSY BS6	TATA spare parts
570950100327	BRACKET ASSY AUX WATER TANK MTG BS6	TATA spare parts
570950100328	RADIATOR ASSY WITH FRAME BS6	TATA spare parts
570950100330	COOLANT PIPE ASSY BS6	TATA spare parts
570950100331	PIPE ASSY ENGINE TO AUX WATER TANK BS6	TATA spare parts
570950100332	SUPPORT BRACKET ASSY BS6	TATA spare parts
570950100333	SUPPORT BRACKET ASSY BS6	TATA spare parts
570950100334	SUPPORT BRACKET ASSY BS6	TATA spare parts
570950100335	PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
570950100336	RADIATOR BS6	TATA spare parts
570950100337	INTERCOOLER ASSY BS6	TATA spare parts
570950100338	RADIATOR ASSY WITH INTERCOOLER & SHROUD	TATA spare parts
570950100342	COOLANT LINE ASSY BS6	TATA spare parts
570950100343	COOLANT LINE ASSY BS6	TATA spare parts
570950100345	PIPE ASSY RADIATOR TO WATER PUMP BS6	TATA spare parts
570950100346	AUX WATER TANK ASSY BS6	TATA spare parts
570950100349	SUPPORT BRACKET ASSY BS6	TATA spare parts
570950100350	SUPPORT BRACKET ASSY BS6	TATA spare parts
570950100351	SUPPORT BRACKET ASSY BS6	TATA spare parts
570950100352	KIT-ENGINE COOLING SYSTEM BS6	TATA spare parts
570950100354	RADIATOR ASSY WITH FRAME BS6	TATA spare parts
570950100357	RADIATOR & INTERCOOLER ASSY BS6	TATA spare parts
570950100361	RADIATOR ASSY BS6	TATA spare parts
570950100369	PIPE ASSY RADIATOR TO WATER PUMP BS6-PH2	TATA spare parts
570950100370	PIPE ASSY RAD. FP TO WATER PUMP BS6-PH2	TATA spare parts
570950100375	COOLANT LINE ASSY BS6-PH2	TATA spare parts
570950100376	COOLANT LINE ASSY BS6-PH2	TATA spare parts
570950100378	COOLANT LINE ASSY BS6-PH2	TATA spare parts
570950100379	COOLANT LINE ASSY BS6-PH2	TATA spare parts
570950100381	COOLANT LINE ASSY BS6-PH2	TATA spare parts
570950100382	COOLANT LINE ASSY BS6-PH2	TATA spare parts

570950100384	WATER FILLER PIPE ASSY W/CLAMP BS6-PH2	TATA spare parts
570950100387	RADIATOR ASSY WITH FRAME BS6-PH2	TATA spare parts
570950100395	RADIATOR ASSY WITH FRAME BS6	TATA spare parts
570950103308	SUPPORT BRACKET BS6	TATA spare parts
570950103801	ADAPTOR(RADIATOR TO WATERPUMP)	TATA spare parts
570950103802	ADAPTER RADIATOR TO WATER PUMP	TATA spare parts
570950103811	ADAPTER BS6-PH2	TATA spare parts
570950104225	SUPPORT BRACKET	TATA spare parts
570950104226	CLAMP	TATA spare parts
570950104228	SUPPORT BRACKET BS6	TATA spare parts
570950104229	SUPPORT BRACKET BS6	TATA spare parts
570950104234	CLAMP BS6	TATA spare parts
570950105820	HOSE (THERMOSTAT TO RADIATOR PIPE)	TATA spare parts
570950105821	HOSE RADIATOR TO WATER PUMP	TATA spare parts
570950105827	HOSE (FILLER PIPE TO RADIATOR)	TATA spare parts
570950105841	HOSE (THERMOSTAT COVER TO RADIATOR)	TATA spare parts
570950105846	RUBBER HOSE(WATER DIST.RAIL TO VENTLINE)	TATA spare parts
570950105847	RUBBER HOSE (EGR COOLER TO VENT LINE)	TATA spare parts
570950105848	RUBBER HOSE (THERMOSTAT TO VENT LINE)	TATA spare parts
570950105866	HOSE (FOR FILL PIPE)	TATA spare parts
570950105867	RUBBER HOSE (FOR VENTING)	TATA spare parts
570950105868	RUBBER HOSE (FOR VENTING)	TATA spare parts
570950105869	HOSE REDUCER (AUX TANK TO FILL PIPE)	TATA spare parts
570950105877	HOSE RADIATOR INTAKE	TATA spare parts
570950105891	VENT HOSE (RADIATOR TO AUX. TANK)	TATA spare parts
570950105892	VENT HOSE (ENGINE TO AUX TANK)	TATA spare parts
570950105894	RUBBER HOSE (RADIATOR VENT TO AUX TANK)	TATA spare parts
570950105901	HOSE RADIATOR INTAKE BS6	TATA spare parts
570950106304	PIPE THERMO COVER TO RADIATOR - PLASTIC	TATA spare parts
570950106926	VENT TUBE (RADIATOR TO AUX TANK)	TATA spare parts
570950106952	FILLER PIPE AUX WATER TANK TO WATER PUMP	TATA spare parts
570950106953	VENT TUBE RADIATOR TO AUX TANK	TATA spare parts
570950106954	PIPE RADIATOR TO WATER PUMP	TATA spare parts
570950106970	TUBE BS6	TATA spare parts
570950106974	HC DOSER COOLANT CONNECTOR BS6	TATA spare parts
570950106992	TUBE (ENGINE TO UREA INJECTOR) BS6	TATA spare parts
570950107501	RUBBER GROMMET (VENT TUBE SUPPORT)	TATA spare parts
570950108208	SUPPORT BRACKET (FOR COOLANT PIPE)	TATA spare parts
570950108212	CLAMP (VENT TUBE SUPPORT)	TATA spare parts
570950108213	CLAMP (VENT TUBE SUPPORT)	TATA spare parts
570950108220	SUPPORT BRACKET VENT HOSE	TATA spare parts
570950108228	SUPPORT BRACKET (COOLANT PIPE)- CAST PIP	TATA spare parts
570950108230	SUPPORT BRACKET COOLANT PIPE	TATA spare parts
570950108231	BRACKET AUX WATER TANK MTG	TATA spare parts
570950108232	SUPPORT BRACKET COOLANT PIPE BS6	TATA spare parts
570950108235	CLAMP BS6	TATA spare parts
570950108236	CLAMP BS6	TATA spare parts

570950108237	SUPPORT BRACKET BS6	TATA spare parts
570950108246	BRACKET BS6	TATA spare parts
570950108254	SUPPORT BRACKET BS6-PH2	TATA spare parts
570950108260	SUPPORT BRACKET BS6-PH2	TATA spare parts
570950108261	SUPPORT BRACKET COOLANT PIPE BS6-PH2	TATA spare parts
570950108262	SUPPORT BRACKET BS6-PH2	TATA spare parts
570950108272	BRACKET BS6-PH2	TATA spare parts
570950109903	FLAP	TATA spare parts
570950109907	CONNECTOR BS6	TATA spare parts
570950109914	O-RING BS6	TATA spare parts
570950109918	FLAP BS6	TATA spare parts
570950110101	FILLER PIPE ASSY WITH CLAMP BS6	TATA spare parts
570950110102	WATER FILLER PIPE ASSY WITH CLAMP BS6	TATA spare parts
570950110105	COOLANT LINE ASSY BS6	TATA spare parts
570950110106	COOLANT LINE ASSY BS6	TATA spare parts
570950110115	COOLANT LINE ASSY BS6	TATA spare parts
570950110116	COOLANT LINE ASSY BS6	TATA spare parts
570950110119	COOLANT PIPE ASSY BS6	TATA spare parts
570950110120	COOLANT PIPE ASSY BS6	TATA spare parts
570950110124	COOLANT PIPE ASSY BS6	TATA spare parts
570950110136	COOLANT PIPE ASSY BS6	TATA spare parts
570950110141	COOLANT LINE ASSY BS6	TATA spare parts
570950110142	COOLANT LINE ASSY BS6	TATA spare parts
570950110144	COOLANT LINE ASSY BS6	TATA spare parts
570950110145	COOLANT LINE ASSY BS6	TATA spare parts
570950110151	COOLANT LINE ASSY BS6	TATA spare parts
570950110152	COOLANTLINEASSY BS6	TATA spare parts
570950110154	RUBBERHOSE BS6	TATA spare parts
570950110156	COOLANT PIPE ASSY BS6	TATA spare parts
570950110157	COOLANT PIPE ASSY BS6	TATA spare parts
570950110158	COOLANT PIPE ASSY BS6	TATA spare parts
570950110159	COOLANT PIPE ASSY BS6	TATA spare parts
570950110160	COOLANT PIPE ASSY BS6	TATA spare parts
570950110161	COOLANT LINE ASSY BS6	TATA spare parts
570950110162	COOLANT LINE ASSY BS6	TATA spare parts
570950110166	COOLANT LINE ASSY (ENGINE TO UREA INJECT	TATA spare parts
570950110167	COOLANT PIPE ASSY (ENGINE TO UREA INJECT	TATA spare parts
570950110168	COOLANT LINE ASSY (UREA INJECTOR TO ENGI	TATA spare parts
570950110171	COOLANT PIPE ASSY (ENGINE TO DOSING INJE	TATA spare parts
570950110172	COOLANT LINE ASSY (DOSING INJECTOR TO EN	TATA spare parts
570950110173	COOLANT LINE ASSY (DOSING INJECTOR TO EN	TATA spare parts
570950110175	SUPPORT BRACKET ASSY BS6-PH2	TATA spare parts
570950110177	COOLANT LINE ASSY BS6-PH2	TATA spare parts
570950110182	BRACKET ASSY BS6-PH2	TATA spare parts
570950110183	COOLANT LINE ASSY BS6-PH2	TATA spare parts
570950110185	KIT-ENGINE COOLING SYSTEM BS6-PH2	TATA spare parts
570950110187	PIPE ASSY BS6-PH2	TATA spare parts

570950110190	COOLANT LINE ASSY BS6-PH2	TATA spare parts
570950110192	PIPE ASSY BS6-PH2	TATA spare parts
570950110196	COOLANT LINE ASSY BS6-PH2	TATA spare parts
570950110197	COOLANT LINE ASSY BS6-PH2	TATA spare parts
570950110199	COOLANT LINE ASSY BS6-PH2	TATA spare parts
570950110205	BRACKET ASSY BS6-PH2	TATA spare parts
570950110206	BRACKET ASSY BS6-PH2	TATA spare parts
570950110211	PIPE ASSY BS6-PH2	TATA spare parts
570950110212	COOLANT PIPE ASSY BS6-PH2	TATA spare parts
570950110213	COOLANT LINE ASSY BS6-PH2	TATA spare parts
570950110215	BRACKET ASSY BS6-PH2	TATA spare parts
570950110217	RADIATOR ASSY WITH INTERCOOLER & SHROUD	TATA spare parts
570950110225	COOLANT PIPE ASSY BS6-PH2	TATA spare parts
570950110226	SUPPORT BRACKET ASSY BS6-PH2	TATA spare parts
570950110227	PIPE ASSY ENGINE TO AUX WATER TANK BS6-P	TATA spare parts
570950110231	BRACKET ASSY BS6-PH2	TATA spare parts
570950110235	PIPE ASSY ENGINE TO AUX WATER TANK BS6-P	TATA spare parts
570950110236	TUBE BS6-PH2	TATA spare parts
570950110237	SUPPORT BRACKET ASSY BS6-PH2	TATA spare parts
570950110238	SUPPORT BRACKET ASSY BS6-PH2	TATA spare parts
570950110240	SUPPORT BRACKET ASSY BS6-PH2	TATA spare parts
570950110248	SUPPORT BRACKET ASSY BS6-PH2	TATA spare parts
570950115807	HOSE OVERFLOW (FROM AUX TANK)	TATA spare parts
570950115810	HOSE AUX WATER TANK TO RADIATOR	TATA spare parts
570950115813	HOSE FILLER PIPE TO RADIATOR	TATA spare parts
570950115814	HOSE THERMOSTAT COVER TO RADIATOR	TATA spare parts
570950115819	HOSE (RAD TO WP)-1 -CAST PIPE	TATA spare parts
570950115820	HOSE (RAD TO WP)-2 -CAST PIPE	TATA spare parts
570950115821	HOSE (RAD TO WP)-3 - CAST PIPE	TATA spare parts
570950115822	HOSE (RAD TO WP)-4- CAST PIPE	TATA spare parts
570950115823	HOSE THERMOSTAT COVER TO RADIATOR	TATA spare parts
570950115824	HOSE RADIATOR TO WATER PUMP	TATA spare parts
570950115825	HOSE RADIATOR TO WATER PUMP	TATA spare parts
570950115826	HOSE AUX WATER TANK TO FILLER PIPE	TATA spare parts
570950115827	HOSE AUX WATER TANK	TATA spare parts
570950115828	HOSE AUX TANK TO RADIATOR VENT	TATA spare parts
570950115831	VENT HOSE ENGINE TO AUX TANK	TATA spare parts
570950115832	VENT HOSE RADIATOR TO AUX TANK	TATA spare parts
570950115834	HOSE AUX WATER TANK TO FILLER PIPE	TATA spare parts
570950115838	HOSE	TATA spare parts
570950115839	HOSE RADIATOR TO WATER PUMP	TATA spare parts
570950115840	HOSE AUX WATER TANK TO RADIATOR	TATA spare parts
570950115841	VENT HOSE ENGINE TO AUX TANK BS6	TATA spare parts
570950115842	VENT HOSE (RADIATOR TO AUX. TANK)	TATA spare parts
570950115843	HOSE REDUCER AUX TANK TO FILLER PIPE BS6	TATA spare parts
570950115847	HOSE RADIATOR TO WATER PUMP	TATA spare parts
570950115848	HOSE AUX WATER TANK TO FILLER PIPE	TATA spare parts

570950115854	HOSE RADIATOR TO WATER PUMP BS6	TATA spare parts
570950115858	RUBBER HOSE BS6	TATA spare parts
570950115861	HOSE (COOLANT PIPE TO HC DOSER INLET) BS	TATA spare parts
570950115864	RUBBER HOSE BS6	TATA spare parts
570950115865	RUBBER HOSE BS6	TATA spare parts
570950115866	HOSE	TATA spare parts
570950115867	HOSE FILLER PIPE TO RADIATOR BS6	TATA spare parts
570950115870	HOSE BS6	TATA spare parts
570950115871	HOSEBS6	TATA spare parts
570950115874	HOSE ENGINE TO UREA INJECTOR BS6	TATA spare parts
570950115875	HOSE ENGINE TO UREA INJECTOR BS6	TATA spare parts
570950115876	HOSE UREA INJECTOR TO ENGINE BS6	TATA spare parts
570950115880	HOSE RADIATOR TO WATER PUMP BS6	TATA spare parts
570950115881	HOSEINTERCOOLEROUTLET BS6	TATA spare parts
570950115886	VENT HOSE ENGINE TO AUX TANK BS6	TATA spare parts
570950115890	VENT HOSE BS6	TATA spare parts
570950115891	HOSE BS6	TATA spare parts
570950115894	VENT HOSE RADIATOR TO AUX WATER TANK BS6	TATA spare parts
570950115896	VENT HOSE BS6	TATA spare parts
570950115902	HOSEBS6	TATA spare parts
570950125801	HOSE RADIATOR TO WATER PUMP BS6	TATA spare parts
570950125802	HOSE THERMOSTAT TO RADIATOR BS6	TATA spare parts
570950125803	VENT HOSE BS6	TATA spare parts
570950125804	HOSE AUX WATER TANK TO RADIATOR BS6	TATA spare parts
570950125805	HOSE BS6	TATA spare parts
570950125809	RUBBER HOSE BS6	TATA spare parts
570950125810	HOSE RADIATOR TO WATER PUMP BS6	TATA spare parts
570950125812	HOSE BS6	TATA spare parts
570950125818	HOSE ENGINE TO UREA INJECTOR BS6	TATA spare parts
570950125819	HOSE FILLER PIPE TO WATER PUMP BS6	TATA spare parts
570950125822	HOSE BS6-PH2	TATA spare parts
570950125823	HOSE BS6-PH2	TATA spare parts
570950125830	HOSE ENGINE TO UREA INJECTOR BS6	TATA spare parts
570950125834	HOSE RADIATOR TO WATER PUMP BS6	TATA spare parts
570950125835	HOSE AUX WATER TANK TO FILLER PIPE BS6	TATA spare parts
570950125840	HOSE RADIATOR TO WATER PUMP BS6-PH2	TATA spare parts
570950125841	HOSE RADIATOR TO WATER PUMP BS6-PH2	TATA spare parts
570950125847	HOSE BS6-PH2	TATA spare parts
570950125853	HOSE BS6-PH2	TATA spare parts
570950125854	AUX HOSE BS6-PH2	TATA spare parts
570950125855	HOSE ENGINE TO UREA INJECTOR BS6-PH2	TATA spare parts
570950125857	HOSE RADIATOR TO WATER PUMP BS6-PH2	TATA spare parts
570950125858	HOSE THERMOSTAT TO RADIATOR BS6-PH2	TATA spare parts
570950125860	HOSE BS6-PH2	TATA spare parts
570950125861	HOSE BS6-PH2	TATA spare parts
570950125872	VENT HOSE BS6-PH2	TATA spare parts
570950125875	RUBBER HOSE BS6-PH2	TATA spare parts

570950125876	RUBBER HOSE BS6-PH2	TATA spare parts
570950400120	BRACKET ASSY RADIATOR MTG BS6	TATA spare parts
570950400121	BRACKET ASSY RADIATOR MTG BOTTOM-RH	TATA spare parts
570950400122	BRACKET ASSY RADIATOR MTG BOTTOM-LH	TATA spare parts
570950400126	TIE ROD ASSY WITH BUSH BS6	TATA spare parts
570950406301	RUBBER BUFFER	TATA spare parts
570950406901	TUBE RAD-MTG.	TATA spare parts
570950408203	SUPPORT BRACKET (FOR RAD MTG)	TATA spare parts
570950408210	BRACKET (RADIATOR MOUNTING BOTTOM)	TATA spare parts
570950408219	SUPPORT BRACKET RADIATOR MTG	TATA spare parts
570950408224	LOCK PLATE BS6	TATA spare parts
570950408228	BRACKETRADIATORMTGLH	TATA spare parts
570950408229	BRACKETRADIATORMTGRH	TATA spare parts
570950408230	SUPPORT BRACKET	TATA spare parts
570950408233	BRACKET BS6	TATA spare parts
570950408237	BRACKET RADIATOR BOTTOM MTG BS6	TATA spare parts
570950408239	SUPPORT BRACKET BS6	TATA spare parts
570950408243	BRACKET RADIATOR BOTTOM MTG BS6-PH2	TATA spare parts
570950408244	BRACKET RADIATOR BOTTOM MTG BS6-PH2	TATA spare parts
570950409201	WASHER	TATA spare parts
570950506303	FAN SHROUD	TATA spare parts
570950506309	FAN SHROUD	TATA spare parts
570950506311	FAN SHROUD	TATA spare parts
570950506315	FAN SHROUD	TATA spare parts
570950506316	FAN SHROUD BS6	TATA spare parts
570950506319	FAN SHROUD BS6	TATA spare parts
570950506321	SHROUD ASSY	TATA spare parts
570950506322	FAN SHROUD BS6	TATA spare parts
570950506323	FAN SHROUD BS6	TATA spare parts
570950506330	FAN SHROUD BS6	TATA spare parts
570950506331	FAN SHROUD BS6	TATA spare parts
570950506332	FAN SHROUD BS6	TATA spare parts
570950506333	FAN SHROUD BS6	TATA spare parts
570950506334	FAN SHROUD BS6	TATA spare parts
570950506335	FAN SHROUD BS6	TATA spare parts
571000000103	ENG.TCIC COMP. WITHOUT CLUTCH (ACE)	TATA spare parts
571000000105	ENG.NA COMP. WITHOUT CLUTCH (ACE)	TATA spare parts
571000000106	ENGINE COMP. WITHOUT CLUTCH	TATA spare parts
571000000109	ASSY ENGINE COMPLETE	TATA spare parts
571000000115	ENGINE COMPLETE WITHOUT CLUTCH	TATA spare parts
571000000116	ASSY. ENG. COMPLETE WITHOUT CLUTCH	TATA spare parts
571000000117	ENGINE COMPLETE WITHOUT CLUTCH	TATA spare parts
571000000118	ASSEMBLY ENGINE COMPONENT W/O CLUTCH	TATA spare parts
571000000121	ASSY ENGINE WITHOUT CLUTCH	TATA spare parts
571000000126	ENGINE COMPLETE WITHOUT CLUTCH	TATA spare parts
571000000129	ASSY ENGINE WITHOUT CLUTCH	TATA spare parts
571000000135	ASSEMBLY ENGINE COMPONENT W/O CLUTCH	TATA spare parts

571000000138	ENGINE ASSY W/O CLUTCHBS6	TATA spare parts
571000000142	ASSY ENGINE 800CC ACE HT+ BS6	TATA spare parts
571000000143	ENGINE ASSY W/O CLUTCH BS6	TATA spare parts
571000000144	ASSEMBLY ENGINE COMPONENT W/O CLUTCHBS	TATA spare parts
571000000147	ENGINE ASSY W/O CLUTCH BS6	TATA spare parts
571000000149	ENGINE ASSY W/O CLUTCHBS6	TATA spare parts
571000000157	ENGINE ASSY W/O CLUTCH BS6-PH2	TATA spare parts
571000000158	ENGINE ASSY W/O CLUTCH BS6-PH2	TATA spare parts
5710009321	SCISSOR LINK LH	TATA spare parts
5710009322	SCISSOR LINK RH	TATA spare parts
571001100101	ASSY. CYL. CRANKCASE W/BEDPLATE BS3/4	TATA spare parts
571001100113	CYL CRANKCASE ASSY WITH BED PLATE COMPL	TATA spare parts
571001100115	ADAPTER PLATE	TATA spare parts
571001100117	CYL CRANKCASE ASSY WITH BED PLATE	TATA spare parts
571001100121	CYL CRANKCASE ASSY WITH BED PLATE BS6	TATA spare parts
571001100123	CYL CRANKCASE ASSY WITH BED PLATE BS6	TATA spare parts
571001103201	HEX FL. BOLT (BEDPLATE MOUNTING AT MAIN	TATA spare parts
571001103202	MAIN BEARING BOLT	TATA spare parts
571001103701	CYLINDER LINER	TATA spare parts
571001103801	CYLINDER CRANKCASE	TATA spare parts
571001104801	HOLLOW DOWEL 12H6X10.6X12L	TATA spare parts
571001104802	DOWEL PIN 4H6X10L	TATA spare parts
571001104803	HOLLOW DOWEL 13H6X11.6X18L	TATA spare parts
571001106904	BLOWBY TUBE	TATA spare parts
571001106905	OIL RETURN TUBE- FRONT	TATA spare parts
571001106906	OIL RETURN TUBE - REAR	TATA spare parts
571001106907	TUBE OIL RETURN REAR	TATA spare parts
571001106908	TUBE OIL RETURN FRONT	TATA spare parts
571001107202	PLUG SEALING	TATA spare parts
571001130111	ASSY. OIL SUMP LIQUID GASKET BS2/4	TATA spare parts
571001130125	OIL SUMP ASSY WITH DRAIN PLUG	TATA spare parts
571001130127	OIL SUMP ASSY	TATA spare parts
571001133803	ADAPTER PLATE OIL SUMP	TATA spare parts
571001136902	TUBE OIL SEPARATOR RETURN BS6	TATA spare parts
571001138210	PLATE	TATA spare parts
571001140102	ASSY. TIMING COVER (REAR)	TATA spare parts
571001140103	ASSY TIMING COVER (FRONT TOP)	TATA spare parts
571001140104	ASSY TIMING COVER (FRONT BOTTOM)	TATA spare parts
571001140105	ASSY CAP AND O-RING (FRONT TIMING COVER)	TATA spare parts
571001140115	TIMING COVER ASSY REAR	TATA spare parts
571001140116	TIMING COVER ASSY TOP-UPPER	TATA spare parts
571001140117	TIMING COVER ASSY FRONT-BOTTOM	TATA spare parts
571001140118	TIMING COVER ASSY TOP-UPPER	TATA spare parts
571001140119	SUPPORT TIMING COVER LH	TATA spare parts
571001140120	TIMING COVER ASSY REAR BS6	TATA spare parts
571001140121	TIMING COVER ASSY TOP-UPPER BS6	TATA spare parts
571001140122	TIMING COVER ASSY TOP-UPPER	TATA spare parts



571001140123	TIMING COVER ASSY REAR	TATA spare parts
571001140127	TIMING COVER ASSY REAR BS6-PH2	TATA spare parts
571001143801	COVER BALANCER SHAFT	TATA spare parts
571001145302	GASKET COVER BALANCER SHAFT	TATA spare parts
571001150101	ASSY. CYLINDER HEAD WITH VALVES BS4	TATA spare parts
571001150102	ASSY. CYLINDER HEAD W/O VALVES BS3/4	TATA spare parts
571001150103	COVER ASSY CYL HEAD COMPLETE	TATA spare parts
571001150104	ASSY. BAFFLE PLATE CYL. HEAD COVER	TATA spare parts
571001150108	CYLINDER HEAD COVER COMPLETE ASSY	TATA spare parts
571001150109	CYL HEAD WITH VALVES ASSY	TATA spare parts
571001150119	CYL HEAD COVER ASSY	TATA spare parts
571001150128	ASSY. CYLINDER HEAD W/VALVES BS3/4	TATA spare parts
571001150130	COVER ASSY WITH BAFFLE PLATE CYL HEAD BS	TATA spare parts
571001150134	BAFFLE PLATE ASSY	TATA spare parts
571001150135	BAFFLE PLATE ASSY	TATA spare parts
571001150136	COVER ASSY WITH BAFFLE PLATE CYL HEAD BS	TATA spare parts
571001150137	ADAPTER ASSY WITH PIPE	TATA spare parts
571001150138	CYL HEAD ASSY W/O VALVES	TATA spare parts
571001150139	CYL HEAD ASSY WITH VALVES	TATA spare parts
571001150143	COVER ASSY WITH PLUG CYL HEAD	TATA spare parts
571001150146	CYL HEAD ASSY W/O VALVES BS6	TATA spare parts
571001150147	CYL HEAD ASSY WITH VALVES BS6	TATA spare parts
571001150156	COVER ASSY WITH PLUG CYL HEAD BS6-PH2	TATA spare parts
571001150159	CYL HEAD ASSY W/O VALVES BS6-PH2	TATA spare parts
571001151601	GASKET BAFFLE PLATE	TATA spare parts
571001153201	HEX BOLT (CYLINDER HEAD)	TATA spare parts
571001153403	VALVE SEAT INSERT(INTAKE)	TATA spare parts
571001153404	VALVE SEAT INSERT(EXHAUST)	TATA spare parts
571001153405	INSERT VALVE SEAT EXHAUST BS6	TATA spare parts
571001153702	EGR TUBE CYL HEAD COVER	TATA spare parts
571001153802	CYLINDER HEAD COVER WITH INTEGRATED INTA	TATA spare parts
571001153804	CYL HEAD COVER WITH INT INTAKE MANIFOLD	TATA spare parts
571001153808	CYL HEAD COVER WITH INTAKE MANIFOLD	TATA spare parts
571001155303	CYL. HEAD GASKET 1.3 MM	TATA spare parts
571001155304	CYL. HEAD GASKET 1.2 MM	TATA spare parts
571001155305	CYL. HEAD GASKET 1.1 MM	TATA spare parts
571001155308	GASKET CYL. HEAD COVER BS3/4/6	TATA spare parts
571001155309	GASKET - BAFFLE PLATE	TATA spare parts
571001155313	GASKET CYL.HEAD - 1.3THK BS3/4/6	TATA spare parts
571001155314	GASKET-CYLINDER HEAD - 1.2THK BS3/4/6	TATA spare parts
571001155315	GASKET CYL. HEAD - 1.1THK BS3/4/6	TATA spare parts
571001156501	DOMED CAP NUT CYL HEAD COVER MTG BS6	TATA spare parts
571001156901	NIPPLE THERMOSTAT BYPASS	TATA spare parts
571001156902	NIPPLE (BLOW BY OUTLET CYLINDER HEAD COV	TATA spare parts
571001156905	EGR TUBE (CYLINDER HEAD COVER)	TATA spare parts
571001156906	SPACER TUBE CYL HEAD COVER-34	TATA spare parts
571001156907	SPACER TUBE CYL HEAD COVER-74	TATA spare parts

571001156908	SPACER TUBE CYL HEAD COVER-115	TATA spare parts
571001156909	NIPPLE (BLOW BY INLET CYLINDER HEAD COVE	TATA spare parts
571001157709	DAMPER CYL. HEAD COVER	TATA spare parts
571001157711	DAMPER CYL. HEAD COVER	TATA spare parts
571001157712	DAMPER CYL. HEAD COVER	TATA spare parts
571001157713	DAMPER CYL. HEAD COVER	TATA spare parts
571001158201	REED VALVE	TATA spare parts
571001158202	REED VALVE STOPPER	TATA spare parts
571001158203	CORE PLUG DIA.25	TATA spare parts
571001158206	REED VALVE STOPPER	TATA spare parts
571001158601	DISTANCE PIECE	TATA spare parts
571001158801	STUD FOR CYLINDER HEAD COVER- 134.2	TATA spare parts
571001158802	STUD FOR CYLINDER HEAD COVER- 93	TATA spare parts
571001158803	STUD FOR CYLINDER HEAD COVER- 56.2	TATA spare parts
571001158805	STUD	TATA spare parts
571001158806	STUD	TATA spare parts
571001158807	STUD	TATA spare parts
571001159201	WASHER (FOR CYLINDER HEAD BOLT)	TATA spare parts
571001159902	REDUCER (CYLINDER HEAD)	TATA spare parts
571001159903	ADAPTER - WATER TEMP.SENSOR (ACE)	TATA spare parts
571001160101	ASSY.INJECTOR	TATA spare parts
571001160102	ASSY INJECTOR	TATA spare parts
571001160103	ASSY. FUEL INJECTOR BS3/4	TATA spare parts
571001160104	INJECTOR BS2/3	TATA spare parts
571001160106	INJECTOR ASSY BS6	TATA spare parts
571001163202	HEX FLANGE BOLT INJECTOR MTG	TATA spare parts
571001165101	INJECTOR CLAW BS4	TATA spare parts
571001166701	PIN (INJECTOR CLAW SUPPORT) BS4	TATA spare parts
571001167701	O RING (FOR INJECTOR) BS4	TATA spare parts
571001167702	O-RING INJECTOR BS6	TATA spare parts
571001170104	ASSY DIPSTICK BS4	TATA spare parts
571001170109	ASSY DIPSTICK TUBE	TATA spare parts
571001170111	ASSY. BLOW BY PIPE (ACE)	TATA spare parts
571001170120	ASSY PIPE WITH CLAMP OIL SEP HOSE TO OI	TATA spare parts
571001170121	BRACKET ASSY OIL SEPARATOR MTG	TATA spare parts
571001170122	ASSY BRACKET FOR OIL SEPARATOR MTG (ACE)	TATA spare parts
571001170123	ASSY PIPE WITH CLAMP	TATA spare parts
571001170135	ASSLY BOLW BY PIPE (ACE NA)	TATA spare parts
571001170145	OIL SAPERATOR ASSY	TATA spare parts
571001170179	TUBE ASSY DIPSTICK	TATA spare parts
571001170186	PIPE ASSY OMS TO INTAKE PIPE	TATA spare parts
571001170189	PIPE ASSY WITH CLAMP	TATA spare parts
571001170190	BRACKET ASSY BLOWBY PIPE	TATA spare parts
571001170191	TUBE ASSY DIPSTICK	TATA spare parts
571001170192	DIPSTICK ASSY	TATA spare parts
571001170193	PIPE ASSY BLOWBY	TATA spare parts
571001170199	HOSE ASSY WITH SLEEVE BLOWBY	TATA spare parts

571001170201	PIPE ASSY BLOWBY BS6	TATA spare parts
571001170203	OIL MIST SEPARATOR MTG ASSY	TATA spare parts
571001170204	TUBE ASSY DIPSTICK BS6	TATA spare parts
571001170206	PIPE ASSY OMS OIL RETURN BS6	TATA spare parts
571001170207	BRACKET ASSY OMS MTG BS6	TATA spare parts
571001170210	DIPSTICK ASSY BS6	TATA spare parts
571001170214	BRACKET ASSY BLOWBY PIPE BS6	TATA spare parts
571001170216	HOSE ASSY BS6	TATA spare parts
571001173701	BRACKET OIL MIST SEPARATOR MTG	TATA spare parts
571001175302	GASKET BLOW BY ACCUMULATOR	TATA spare parts
571001175305	GASKET LADDER FRAME	TATA spare parts
571001175804	HOSE - BLOW BY ADAPTOR	TATA spare parts
571001175817	HOSE - ASSY. BLOW BY PIPE TO CYL. HEAD C	TATA spare parts
571001175826	HOSE (OIL SEP TO BELLOW HOSE)	TATA spare parts
571001175827	HOSE (HEAD COVER TO OIL SEP)	TATA spare parts
571001175828	HOSE(OIL SEP TO ASSY PIPE)	TATA spare parts
571001175830	HOSE(HEAD COVER TO OIL SEPARATOR)	TATA spare parts
571001175831	HOSE (OIL SEP TO ASSY INTER.PIPE)	TATA spare parts
571001175832	HOSE (OIL SEP TO ASSY PIPE WITH CLAMP)	TATA spare parts
571001175833	HOSE (ASSY PIPE WITH CLAMP TO OIL SUMP)	TATA spare parts
571001175834	HOSE(OIL SEPARATOR TO INTAKE HOSE)	TATA spare parts
571001175835	HOSE - ASSY. BLOW BY PIPE TO CYL. HEAD C	TATA spare parts
571001175836	HOSE - ASSY. BLOWBY PIPE TO CRANKCASE TU	TATA spare parts
571001175844	BRACKET HOLDING SLEEVE	TATA spare parts
571001175863	HOSE OIL SEPARATOR TO CYL HEAD COVER	TATA spare parts
571001175866	HOSE OIL SEPARATOR TO PIPE	TATA spare parts
571001175872	HOSE OIL SEPARATOR TO AIR INTAKE PIPE	TATA spare parts
571001175873	HOSE OIL SEPARATOR TO AIR INTAKE HOSE	TATA spare parts
571001175874	HOSE BLOWBY	TATA spare parts
571001175875	HOSE BLOWBY PIPE TO CYL HEAD COVER	TATA spare parts
571001175879	HOSE OMS TO AIR FILTER HOSE BS6	TATA spare parts
571001175880	HOSE CYL HEAD COVER TO OMS BS6	TATA spare parts
571001175881	HOSE OMS TO OIL SUMP PIPE BS6	TATA spare parts
571001175882	HOSE BLOWBY PIPE TO CYL HEAD COVER BS6	TATA spare parts
571001175883	HOSE OIL SEPARATOR RETURN TO SUMP BS6	TATA spare parts
571001175884	HOSE OIL SEPARATOR TO AIR INTAKE HOSE BS	TATA spare parts
571001175885	HOSE OIL SEPARATOR TO PIPE	TATA spare parts
571001175886	HOSE CYL HEAD COVER TO OMS	TATA spare parts
571001175887	HOSE OIL SEPARATOR TO AIR INTAKE PIPE	TATA spare parts
571001178208	BRACKET (BLOWBY HOSE SUPPORT)	TATA spare parts
571001178218	BRACKET OIL SEPARATOR MTG	TATA spare parts
571001990103	KIT-GASKET ENGINE OVERHAUL SUB KIT	TATA spare parts
571001990104	KIT-ENGINE OVERHAUL SEAL BS3/4/6	TATA spare parts
571001990107	KIT-GASKET DECARBONISING	TATA spare parts
571001990108	HALF BLOCK (ACE NA)	TATA spare parts
571001990109	BARE ENGINE (ACE NA)	TATA spare parts
571001990111	ENGINE OVERHAUL SEAL KIT	TATA spare parts

571001990116	HALF BLOCK ASSY	TATA spare parts
571001990117	BARE ENGINE ASSY	TATA spare parts
571001990118	CYL HEAD ASSY WITHOUT INJECTOR	TATA spare parts
571001990120	ASSY. LONG BLOCK 800CC TCIC BS3	TATA spare parts
571001990122	ASSY. HALF BLOCK 800CC BS3/4	TATA spare parts
571001990123	ASSY. LONG BLOCK 800CC BS4	TATA spare parts
571001990127	BARE ENGINE ASSY	TATA spare parts
571001990144	ENGINE OVERHAUL GASKET KIT	TATA spare parts
571001990146	KIT-DECARBONISING GASKET	TATA spare parts
571001990152	CYL HEAD ASSY W/O INJECTOR	TATA spare parts
571001990153	ASSY. LONG BLOCK 800CC BS4	TATA spare parts
571001990158	HALF BLOCK ASSY	TATA spare parts
571001990162	ENG OVERHAUL GASKET KIT W/O HEAD GASKET	TATA spare parts
571001990166	HALF BLOCK BS6	TATA spare parts
571001990167	CYL HEAD ASSY W/O INJECTOR BS6	TATA spare parts
571001990169	LONG BLOCK BS6	TATA spare parts
571001990174	KIT-DECARBONISING GASKET WITH 1.1 THK CY	TATA spare parts
571001990175	KIT-ENGINE OVERHAUL GASKET WITH 1.1 THK	TATA spare parts
571001990178	BARE ENGINE ASSY BS6	TATA spare parts
571001990180	HALF BLOCK BS6	TATA spare parts
571001990182	KIT-ENGINE OVERHAUL SEAL BS6	TATA spare parts
571001990197	CYL HEAD ASSY W/O INJECTOR BS6-PH2	TATA spare parts
571001990200	BARE ENGINE ASSY BS6-PH2	TATA spare parts
571001990202	HALF BLOCK ASSY BS6-PH2	TATA spare parts
571001990203	KIT-DECARBONISING GASKET BS6-PH2	TATA spare parts
571001990204	KIT-ENGINE OVERHAUL GASKET BS6-PH2	TATA spare parts
5710028000	HYD TANK	TATA spare parts
571003100101	ASSY. CRANKSHAFT W/PIN BS3/4	TATA spare parts
571003100102	ASSY. BALANCER SHAFT W/PIN BS3/4	TATA spare parts
571003100106	ASSBLY.BALANCER SHAFT WITH PIN	TATA spare parts
571003100116	ASSY. BALANCER SHAFT WITH PIN (ACE NA)	TATA spare parts
571003100118	BALANCER SHAFT ASSY WITH PIN BS6	TATA spare parts
571003100119	ASSY. CRANK SHAFT W/PIN BS4/6	TATA spare parts
571003105403	GEAR (CRANKSHAFT & BALANCER SHAFT)	TATA spare parts
571003107909	BALANCER SHAFT LIFT 6.5 BS3/4	TATA spare parts
571003110102	ASSY FLYWHEEL (ACE)	TATA spare parts
571003110103	ASSY ADAPTER PLATE -ACE	TATA spare parts
571003110106	FLYWHEEL ASSY WITH RING GEAR	TATA spare parts
571003110109	FLYWHEEL ASSY WITH RING GEAR BS6	TATA spare parts
571003113201	HEX. BOLT (FOR FLYWHEEL)	TATA spare parts
571003123104	THRUST WASHER (BIMETAL)	TATA spare parts
571003123105	MAIN BEARING SHELL UPPER	TATA spare parts
571003123106	MAIN BEARING SHELL LOWER	TATA spare parts
571003123110	BEARING BALANCER SHAFT BS6	TATA spare parts
571003137001	PULLEY CRANKSHAFT	TATA spare parts
571003137007	PULLEY CRANKSHAFT	TATA spare parts
571003137008	PULLEY CRANKSHAFT	TATA spare parts

571003137009	PULLEY CRANK SHAFTBS6	TATA spare parts
571003140102	ASSY PISTON (GRADE A) (FM)	TATA spare parts
571003140103	ASSY PISTON (GRADE B)	TATA spare parts
571003140105	PISTON ASSY (GRADE A)	TATA spare parts
571003140111	PISTON ASSY GRADE A	TATA spare parts
571003146602	ASSY PISTON (GRADE B) (FM)	TATA spare parts
571003146701	GUDGEON PIN	TATA spare parts
571003148701	OIL RING	TATA spare parts
571003149901	TOP RING	TATA spare parts
571003149902	2ND RING	TATA spare parts
571003150102	ASSY CON ROD WITH BUSH(FRACTURE SPLIT)	TATA spare parts
571003153103	CONROD BEARING LOWER (BIMETAL)	TATA spare parts
571003153104	CONROD BEARING UPPER (BIMETAL)	TATA spare parts
571003153202	BOLT,CONNECTING ROD	TATA spare parts
571003153203	BOLT,CONNECTING ROD	TATA spare parts
571003990102	SET-PISTON A W/O RINGS BS3/4	TATA spare parts
571003990103	SET PISTON RINGS BS3/4/6	TATA spare parts
571003990106	SET PISTON B W/O RINGS	TATA spare parts
571003990107	SET PISTON C W/O RINGS	TATA spare parts
571003990108	SET-MAIN BRG. HALF (CRANK SHAFT) BS3/4/6	TATA spare parts
571003990112	SET PISTON A W/O RINGS (ACE NA)	TATA spare parts
571003990113	SET PISTON C W/O RINGS (ACE NA)	TATA spare parts
571003990114	SET PISTON B W/O RINGS (ACE NA)	TATA spare parts
571003990115	SET PISTON RINGS (ACE NA) BS3/4	TATA spare parts
571003990117	SET-BEARING HALF CONNECTING ROD STD	TATA spare parts
571003990118	SET-CONNECTING ROD BUSH	TATA spare parts
571003990120	SET-PISTON GRADE A BS3/4	TATA spare parts
571003990129	SET-BEARING HALF CON R/S 1	TATA spare parts
571003990130	SET-BEARING HALF CON R/S 2	TATA spare parts
571003990133	SET MAIN BEARING - CRANK SHAFT - REPAIR	TATA spare parts
571003990134	SET MAIN BEARING - CRANK SHAFT - REPAIR	TATA spare parts
571003990143	RS1 PISTON RING SET ACE DICOR TCIC BS4	TATA spare parts
571003990144	RS2 PISTON RING SET ACE DICOR TCIC BS4	TATA spare parts
571003990153	RS1 PISTON SET ACE DICOR TCIC BS4 A GRAD	TATA spare parts
571003990156	RS2 PISTON SET ACE DICOR TCIC BS4 A GRAD	TATA spare parts
571003990187	SET-PISTON RING REPAIR-1 BS6	TATA spare parts
571003990188	SET-PISTON RING REPAIR-II BS6	TATA spare parts
571003990189	SET-PISTON W/O RINGS GRADE A BS6	TATA spare parts
571003990190	SET-PISTON W/O RINGS GRADE B BS6	TATA spare parts
571003990191	SET-PISTON W/O RINGS GRADE C BS6	TATA spare parts
571005104101	CAM SHAFT BEARING CAP (FRONT & REAR)	TATA spare parts
571005104102	CAM SHAFT BEARING CAP (THRUST)	TATA spare parts
571005107801	CAMSHAFT FRONT OIL SEAL	TATA spare parts
571005107901	CAMSHAFT BS3/4/6	TATA spare parts
571005110101	ASSY TENSIONER (TIMING BELT)	TATA spare parts
571005110102	ASSY IDLER (TIMING BELT) BS4	TATA spare parts
571005110104	ASSY. TIMING GEAR CRANKSHAFT WITH STOPPE	TATA spare parts

571005110107	ASSY. TIMING BELT TENSIONER BS3/4/6	TATA spare parts
571005110108	ASSY. IDLER? BS3/4/6	TATA spare parts
571005110109	AUTO TENSIONER ASSY BS6	TATA spare parts
571005110111	TENSIONER ASSY BS6-PH2	TATA spare parts
571005110112	IDLER ASSY BS6-PH2	TATA spare parts
571005115404	TIMING GEAR CAMSHAFT	TATA spare parts
571005116301	TIMING BELT	TATA spare parts
571005116302	TIMING BELT BS3/4/6	TATA spare parts
571005116304	TIMING BELT BS6-PH2	TATA spare parts
571005125103	VALVE SPRING RETAINER	TATA spare parts
571005125106	INTAKE VALVE	TATA spare parts
571005125107	EXHAUST VALVE BS3/4/6	TATA spare parts
571005125109	INTAKE VALVE BS6-PH2	TATA spare parts
571005128201	SPRING SEAT (VALVE SPRING)	TATA spare parts
571005128701	VALVE SPRING	TATA spare parts
571005153702	VALVE GUIDE (INTAKE & EXHAUST)	TATA spare parts
571005990101	SET-VALVE,INTAKE & EXHAUST BS3/4	TATA spare parts
571007100101	ASSY HIGH PRESSURE PUMP	TATA spare parts
571007100102	ASSY. ROLLER TAPPET BS3/4	TATA spare parts
571007100105	HIGH PRESSURE PUMP BS3/4	TATA spare parts
571007100108	ASSY. ROLLER TAPPET BS3/4	TATA spare parts
571007100109	ASSY. FUEL CONTROL UNIT BS3/4	TATA spare parts
571007100111	HIGH PRESSURE PUMP ASSY	TATA spare parts
571007100112	ASSY. HP PUMP BS3/4	TATA spare parts
571007100115	HP PUMP ASSY BS6	TATA spare parts
571007100116	ROLLER TAPPET ASSY BS6	TATA spare parts
571007103701	ADAPTER HIGH PRESSURE PUMP	TATA spare parts
571007103705	ADAPTER FIP	TATA spare parts
571007103707	ADAPTER FIP BS6	TATA spare parts
571007105302	GASKET HP PUMP ADAPTER	TATA spare parts
571007105303	GASKET HP PUMP ADAPTER	TATA spare parts
571007105304	GASKET HP PUMP ADAPTER BS6	TATA spare parts
571007108301	SHIM 0.4 THK	TATA spare parts
571007108302	SHIM 0.5 THK	TATA spare parts
571007108303	SHIM 0.6 THK.	TATA spare parts
571007108304	SHIM 0.7 THK.	TATA spare parts
571007108305	SHIM 0.8 THK.	TATA spare parts
571007108306	SHIM 0.9 THK.	TATA spare parts
571007108307	SHIM 0.1 THK.	TATA spare parts
571007108308	SHIM 0.2 THK.	TATA spare parts
571007108309	SHIM 0.3 THK.	TATA spare parts
571007124201	CLAMP-HIGH PRESSURE PUMP	TATA spare parts
571007124202	CLAMP HP PUMP	TATA spare parts
571007124205	CLAMP HP PUMP	TATA spare parts
571007124206	CLAMP¿HP¿PUMP	TATA spare parts
571007127701	O-RING BS6	TATA spare parts
571007128601	SPACER (HP PUMP MOUNTING)	TATA spare parts

571007140106	ASSY FUEL PR.LINE (PUMP TO RAIL) BENT	TATA spare parts
571007140107	ASSY FUEL PR.LINE (RAIL TO INJECTOR) BEN	TATA spare parts
571007140109	ASSY. INJECTOR BACK LEAK HOSES BS3/4	TATA spare parts
571007140110	ASSY. RADIAL FUEL RAIL BS3/4	TATA spare parts
571007140112	ASSY. CLAMPING PLATE (HP LINE)	TATA spare parts
571007140113	ASSY. CLAMP (HP LINE)	TATA spare parts
571007140126	ASSLY CLAMP	TATA spare parts
571007140127	ASSY. BACK LEAK SYSTEM BS3/4	TATA spare parts
571007140130	ASSY. FUEL RAIL 0.8L TDI CRAIL BS3/4	TATA spare parts
571007140134	ASSY. HP LINE-PUMP TO RAIL W/CLAMP BS3/4	TATA spare parts
571007140135	ASSY HP LINE-(RAIL TO INJECTOR)	TATA spare parts
571007140142	ASSY BACK LEAK SYSTEM WITH NRV	TATA spare parts
571007140144	ASSY.HP LINE WITH CLAMP	TATA spare parts
571007140166	ASSY. HP PIPE W/CLAMPS BS2/4	TATA spare parts
571007140169	ASSY. BACK LEAK SYSTEM BS3/4	TATA spare parts
571007140175	HP PIPE ASSY WITH CLAMPS	TATA spare parts
571007140176	BACK LEAK SYSTEM ASSY	TATA spare parts
571007140177	BACK LEAK SYSTEM ASSY	TATA spare parts
571007140180	SET-BACK LEAK HOSE ASSY	TATA spare parts
571007140182	FUEL RAIL ASSY BS6	TATA spare parts
571007140183	SET-BACK LEAK HOSE ASSY BS6	TATA spare parts
571007140185	HP PIPE ASSY WITH CLAMPS	TATA spare parts
571007140187	BACK LEAK SYSTEM ASSY BS6	TATA spare parts
571007140188	HP PIPE ASSY RAIL TO INJECTOR BS6	TATA spare parts
571007140189	HP PIPE ASSY FIP TO RAIL BS6	TATA spare parts
571007140190	HP PIPE ASSY FIP TO RAIL BS6	TATA spare parts
571007140191	BACK LEAK SYSTEM ASSY BS6	TATA spare parts
571007140192	SET-BACK LEAK HOSE ASSY BS6	TATA spare parts
571007144202	BACK LEAK TUBE CLIP	TATA spare parts
571007145802	HOSE-FROM COMMON RAIL TO T-CONNECTOR	TATA spare parts
571007145805	HOSE (COMMON RAIL T-CONNECTOR TO HP PUM)	TATA spare parts
571007145810	HOSE - HP PUMP TO PIPE	TATA spare parts
571007145811	HOSE - PIPE TO T-CONNECTOR	TATA spare parts
571007145816	HOSE-COMMON RAIL TO T-CONNECTOR BS4	TATA spare parts
571007145817	HOSE - HP PUMP TO CONNECTOR BS4	TATA spare parts
571007146903	TUBE - HP PUMP HOSE TO T-CONNECTOR	TATA spare parts
571007178201	CLAMP	TATA spare parts
571007178202	CLAMP&BS6	TATA spare parts
571009110101	ASSY. FUEL FILTER BS3/4	TATA spare parts
571009110105	FUEL FILTER ELEMENT BS3/4	TATA spare parts
571009110108	ASSY. FUEL FILTER BS3/4	TATA spare parts
571009110109	ASSY. MAIN FUEL FILTER BS2/4	TATA spare parts
571009110112	FUEL FILTER ASSY BS6	TATA spare parts
571009110113	FUEL FILTER ASSY	TATA spare parts
571009110114	KIT-FILTER ELEMENTBS6	TATA spare parts
571009113801	FILTER HEAD	TATA spare parts
571009117201	DRAIN PLUG BS4	TATA spare parts

571009117701	O RING	TATA spare parts
571009118001	AIR VENT SCREW BS4	TATA spare parts
571009119901	TEMPERATURE SENSOR BS4	TATA spare parts
571009119902	WATER SENSOR	TATA spare parts
571009119903	FUEL FILTER INSERT A CLASS BS3/4	TATA spare parts
571009119908	TEMPERATURE SENSORBS6	TATA spare parts
571009119909	WATER LEVEL SENSORBS6	TATA spare parts
571009119910	PRESSURE SWITCH BS6	TATA spare parts
571009130103	ASSY. BKT FOR SNORKEL MOUNTING (BOTTOM)	TATA spare parts
571009130104	ASSY. HOSE (HFM PIPE TO INTER. PIPE)	TATA spare parts
571009130108	ASSY.INTERMEDIATE PIPE (ACE)	TATA spare parts
571009130109	ASSY.TUBE- HFM SENSOR (ACE)	TATA spare parts
571009130116	ASSY RUBBER HOSE (HFM SENSOR TUBE TO INT	TATA spare parts
571009130117	ASSY.PIPE	TATA spare parts
571009130118	ASSY. AIR FILTER WITH STIFFENER & SLEEVE	TATA spare parts
571009130119	ASSY.STRAP - AIR FILTER	TATA spare parts
571009130121	ASSY SNORKEL WITH MESH (EMDET)	TATA spare parts
571009130128	ASSY. STRAP AIR FILTER	TATA spare parts
571009130134	AIR FILTER ASSY BS6	TATA spare parts
571009130161	ASSY. HOSE WITH NIPPLE	TATA spare parts
571009130162	ASSY. STIFFNER BKT.	TATA spare parts
571009130163	SET AIR INTAKE SYSTEM	TATA spare parts
571009130164	ASSY. PIPE WITH FLANGE	TATA spare parts
571009130165	ASSY. TUBE HFM SENSOR	TATA spare parts
571009130166	ASSY. INTERMEDIATE PIPE	TATA spare parts
571009130167	ASSY. SLEEVE WITH CLAMP	TATA spare parts
571009130171	ASSY. HOSE CLAMP (DIA. 40-55)	TATA spare parts
571009130172	ASSY. HOSE CLAMP (DIA. 55-75)	TATA spare parts
571009130173	ASSY. HOSE CLAMP (DIA. 70-90)	TATA spare parts
571009130176	HOSE ASSY	TATA spare parts
571009130189	AIR FILTER STRAP ASSY	TATA spare parts
571009130194	ASSY. HOSE -PIPE TO CYL. HEAD COV. BS3/4	TATA spare parts
571009130195	STRAP ASSY AIR FILTER	TATA spare parts
571009130197	STRAP ASSY RESONATOR	TATA spare parts
571009130199	HOSE ASSY PIPE TO TC END	TATA spare parts
571009130201	SNORKEL MESH ASSY	TATA spare parts
571009130202	HOSE ASSY HFM PIPE TO INTERMEDIATE PIPE	TATA spare parts
571009130203	HOSE ASSY WITH NIPPLE	TATA spare parts
571009130204	SNORKEL ASSY	TATA spare parts
571009130205	HOSE ASSY AIR INTAKE SYSTEM	TATA spare parts
571009130206	PIPE ASSY HFM SENSOR TO TC	TATA spare parts
571009130207	PIPE ASSY INTERMEDIATE	TATA spare parts
571009130208	SET AIR INTAKE SYSTEM	TATA spare parts
571009130209	PIPE ASSY WITH CLAMP INTERMEDIATE	TATA spare parts
571009130210	BRACKET ASSY	TATA spare parts
571009130211	COVER ASSY	TATA spare parts
571009130212	PIPE ASSY WITH CLAMP	TATA spare parts



571009130213	PIPE ASSY WITH CLAMP	TATA spare parts
571009130214	PIPE ASSY WITH CLAMP	TATA spare parts
571009130215	BRACKET ASSY	TATA spare parts
571009130217	PIPE ASSY OMS TO INTERMEDIATE BS6	TATA spare parts
571009130218	HOSE ASSY HFM PIPE TO INTERMEDIATE PIPE	TATA spare parts
571009130219	PIPE ASSY AIR INTAKE BS6	TATA spare parts
571009130220	HOSE ASSY HFM PIPE TO INTERMEDIATE PIPE	TATA spare parts
571009130223	HOSE ASSY WITH TUBE BS6	TATA spare parts
571009130224	ISOLATOR&ASSY&SNORKEL&MTG	TATA spare parts
571009130227	ASSY. HOSE W/NIPPLE	TATA spare parts
571009130229	SNORKEL ASSY BS6	TATA spare parts
571009130230	ASSY. HOSE WITH NIPPLE BS4	TATA spare parts
571009130231	KIT-AIR INTAKE BS6	TATA spare parts
571009130236	SNORKEL ASSY BS6	TATA spare parts
571009131604	SNORKEL ASSY WITH MESH BS6	TATA spare parts
571009133802	PIPE ASSY INTERMEDIATE BS6	TATA spare parts
571009133803	PIPE WITH BOSS AIR INTAKE BS6	TATA spare parts
571009135301	GASKET	TATA spare parts
571009135801	HOSE (SNORKEL TO AIR FILTER) BS3/4	TATA spare parts
571009135802	HOSE- AIR FILTER TO HFM SENSOR (ACE)	TATA spare parts
571009135808	HOSE - INTERMEDIATE PIPE TO TURBOCHARGER	TATA spare parts
571009135809	HOSE - ASSY TUBE TO HFM SENSO	TATA spare parts
571009135819	HOSE (AIR FILTER TO ASSY TUBE)	TATA spare parts
571009135828	HOSE (HFM TO ASSY TUBE)	TATA spare parts
571009135829	HOSE (AIR FILTER INTAKE)	TATA spare parts
571009135830	HOSE (AIR FILTER SLEEVE TO HFM)	TATA spare parts
571009135831	HOSE TUBE ASSY TO HFM	TATA spare parts
571009135837	HOSE AIR FILTER TO TUBE ASSY	TATA spare parts
571009135839	HOSE SERVICE INDICATOR	TATA spare parts
571009135845	HOSE AIR FILTER TO SNORKEL	TATA spare parts
571009135846	HOSE INTERMEDIATE PIPE TO TC	TATA spare parts
571009135850	HOSE INTERMEDIATE PIPE TO TC BS6	TATA spare parts
571009135853	HOSE TUBE ASSY TO HFM BS6	TATA spare parts
571009135854	HOSE AIR FILTER TO SNORKEL BS6	TATA spare parts
571009135855	HOSE AIR FILTER TO HFM SENSOR BS6	TATA spare parts
571009135856	HOSE AIR FILTER TO SNORKEL	TATA spare parts
571009135857	HOSE HFM PIPE TO INTERMEDIATE PIPE	TATA spare parts
571009135862	HOSE AIR FILTER TO SNORKEL BS6-PH2	TATA spare parts
571009136303	AIR FILTER ELBOW	TATA spare parts
571009136305	RESONATOR BOX	TATA spare parts
571009137101	BRACKET (AIR FILTER MTG)ACE	TATA spare parts
571009137106	BRACKET ASSY FOR SERVICE INDICATOR MTG	TATA spare parts
571009137501	GROMMET	TATA spare parts
571009137502	GROMET	TATA spare parts
571009138205	MUDFLAP AIR INTAKE PIPE BS6	TATA spare parts
571009138206	BRACKET BS6	TATA spare parts
571014100103	THROTTLE VALVE ASSY,INTAKE	TATA spare parts

571014110103	ASSY HEAT SHIELD (TURBOCHARGER)	TATA spare parts
571014110109	ASSY.VACUUM REGULATING VALVE	TATA spare parts
571014110113	ASSY BRACKET EVRV ACE	TATA spare parts
571014110117	ASSY CATALYTIC CONVERTER	TATA spare parts
571014110123	VALVE ASSLY VACCUME REGULATING	TATA spare parts
571014110124	ASSY EGR VALVE (BS3)	TATA spare parts
571014110125	CATALYTIC CONVERTER WITH PIPE ACE	TATA spare parts
571014110126	ASSY. FRONT PIPE CATCON BS4/6	TATA spare parts
571014110127	ASSY. CATCON W/HEAT SHIELD & BKT BS3/4	TATA spare parts
571014110128	ASSY. EGR PIPE -INLET	TATA spare parts
571014110129	ASSY. EGR PIPE - OUTLET BS3/4	TATA spare parts
571014110130	ASSY EGR PIPE - INLET	TATA spare parts
571014110131	ASSY EGR PIPE - OUTLET	TATA spare parts
571014110132	ASSY EGR PIPE INLET	TATA spare parts
571014110134	ASSY EGR PIPE OUTLET	TATA spare parts
571014110137	ASSY BRACKET(VACUUM ROUTINE ACE)	TATA spare parts
571014110142	ASSY HEAT SHIELD	TATA spare parts
571014110162	BRACKET ASSY VACUUM ROUTING	TATA spare parts
571014110172	CATALYTIC CONVERTOR ASSY	TATA spare parts
571014110181	PIPE ASSY EGR INTAKE	TATA spare parts
571014110182	PIPE ASSY EGR OUTLET	TATA spare parts
571014110187	HEAT SHIELD ASSY TURBOCHARGER	TATA spare parts
571014110188	PIPE ASSY EXH MANIFOLD TO EGR VALVE	TATA spare parts
571014110189	PIPE ASSY EGR COOLER TO AIR INTAKE ELBOW	TATA spare parts
571014110194	CATALYTIC CONVERTER ASSY	TATA spare parts
571014110199	BRACKET ASSY CLOSE COUPLED CATCON MTG	TATA spare parts
571014110208	CATALYTIC CONVERTER ASSY	TATA spare parts
571014110210	ASSY. CATCON BS4	TATA spare parts
571014110211	SUPPORT BRACKET ASSY CATCON	TATA spare parts
571014110214	VALVE ASSY VACUUM REGULATING	TATA spare parts
571014110228	NYLON TUBE ASSY VACUUM RESERVOIR BS6	TATA spare parts
571014110229	NYLON TUBE ASSY EVRV TO EGR COOLER BS6	TATA spare parts
571014110230	NYLON TUBE ASSY VACUUM RESERVOIR BS6	TATA spare parts
571014110231	BRACKET ASSY EVRV MTG BS6	TATA spare parts
571014110233	EGR PIPE ASSY INTAKE	TATA spare parts
571014110236	PRESSURE TUBE ASSY WITH BRACKETS BS6	TATA spare parts
571014110238	CATALYTIC CONVERTER ASSY	TATA spare parts
571014110240	PIPE ASSY EXH MANIFOLD TO EGR VALVE BS6	TATA spare parts
571014110242	PIPE ASSY EGR COOLER TO AIR INTAKE ELBOW	TATA spare parts
571014110243	PIPE ASSY EGR COOLER TO AIR INTAKE ELBOW	TATA spare parts
571014110245	PRESSURE TUBE ASSY WITH BRACKETS BS6	TATA spare parts
571014110248	HOSE ASSY BS6	TATA spare parts
571014110249	CLAMP ASSY BS6	TATA spare parts
571014110250	DEF INJECTOR BS6	TATA spare parts
571014110253	PRESSURE TUBE ASSY WITH BRACKETS BS6	TATA spare parts
571014110265	PIPE ASSY EGR INTAKE	TATA spare parts
571014110268	CATALYTIC CONVERTER ASSY	TATA spare parts

571014110275	PIPE ASSY EXH MANIFOLD TO EGR VALVE	TATA spare parts
571014110276	PIPE ASSY EGR COOLER TO AIR INT ELBOW BS	TATA spare parts
571014110282	NYLON TUBE ASSY VACUUM RESERVOIR BS6	TATA spare parts
571014110283	HOSE ASSY EVRV TO AIR FILTER BS6	TATA spare parts
571014110286	BRACKET ASSY SENSOR MTG BS6-PH2	TATA spare parts
571014110303	PRESSURE TUBE ASSY WITH BRACKETS BS6-PH2	TATA spare parts
571014111650	HEAT SHIELD TURBOCHARGER OUTER	TATA spare parts
571014113701	EXHAUST MANIFOLD	TATA spare parts
571014113705	EXHAUST ELBOW	TATA spare parts
571014113707	BRACKET CLOSE COUPLED CATCON SUPPORT	TATA spare parts
571014113708	EXHAUST ELBOW	TATA spare parts
571014113710	BRACKET EGR MODULE MTG BS6	TATA spare parts
571014113711	BRACKET EGR MODULE MTG BS6	TATA spare parts
571014113713	EXHAUST ELBOW TURBOCHARGER BS6	TATA spare parts
571014113714	STIFFENER EXHAUST MANIFOLD BS6	TATA spare parts
571014113715	EXHAUST ELBOW TURBOCHARGER BS6	TATA spare parts
571014113716	EXHAUST ELBOW	TATA spare parts
571014113723	BRACKET EGR MODULE MTG BS6	TATA spare parts
571014115301	GASKET (FOR ASSY EGR PIPES)	TATA spare parts
571014115303	GASKET EXHAUST ELBOW BS6	TATA spare parts
571014115304	GASKET,AIR INTAKE,THROTTLE BODY	TATA spare parts
571014115305	GASKET-EXHAUST MANIFOLD TO CATCON	TATA spare parts
571014115307	GASKET(FRONT PIPE TO CATCON)	TATA spare parts
571014115317	GASKET EGR INTAKE PIPE TO EGR VALVE	TATA spare parts
571014115318	GASKET EGR VALVE BS6	TATA spare parts
571014115324	GASKET EXHAUST ELBOW TO CATCON	TATA spare parts
571014115327	GASKET EGR COOLER TO EGR PIPE	TATA spare parts
571014115328	GASKET EXHAUST ELBOW TO CATCON	TATA spare parts
571014115331	GASKET EGR COOLER TO EGR PIPE BS6-PH2	TATA spare parts
571014115802	HOSE(EVRV CIRCUIT)	TATA spare parts
571014115803	HOSE(EVRV CIRCUIT)	TATA spare parts
571014115804	HOSE (EVRV CIRCUIT)	TATA spare parts
571014115805	HOSE (EVRV CIRCUIT)	TATA spare parts
571014115807	HOSE VACCUME ROUTING	TATA spare parts
571014115815	HOSE - EVRV	TATA spare parts
571014115819	HOSE EVRV TO INTAKE	TATA spare parts
571014115822	HOSE EVRV TO EGR VALVE	TATA spare parts
571014115823	HOSE EVRV TO INTAKE	TATA spare parts
571014115824	HOSE EVRV CIRCUIT	TATA spare parts
571014115826	HOSE BS6	TATA spare parts
571014115827	HOSE EVRV TO VACUUM PUMP BS6	TATA spare parts
571014115828	HOSE EVRV TO T-CONNECTOR BS6	TATA spare parts
571014115829	HOSE EVRV BS6	TATA spare parts
571014115830	HOSE EVRV TO T-CONNECTOR BS6	TATA spare parts
571014115831	HOSE EVRV TO VACUUM PUMP BS6	TATA spare parts
571014115832	HOSE EVRV TO VACUUM ACCUMULATOR BS6	TATA spare parts
571014115833	HOSE EVRV TO TURBOCHARGER BS6	TATA spare parts

571014115834	HOSE EVRV TO AIR INTAKE BS6	TATA spare parts
571014115835	HOSE EVRV TO AIR INTAKE BS6	TATA spare parts
571014115836	HOSE EVRV TO CONNECTOR BS6	TATA spare parts
571014115837	HOSE EVRV CIRCUIT BS6	TATA spare parts
571014115838	HOSE EVRV TO T-CONNECTOR BS6	TATA spare parts
571014115840	HOSE EVRV TO AIR FILTER BS6	TATA spare parts
571014115841	HOSE EVRV TO T-CONNECTOR BS6	TATA spare parts
571014115844	HOSE EVRV TO TURBOCHARGER BS6	TATA spare parts
571014115849	HOSE DPF INTAKE PRESSURE BS6	TATA spare parts
571014115850	HOSE INTAKE PRESSURE TUBE TO SENSOR BS6	TATA spare parts
571014115851	HOSE DPF OUTLET PRESSURE BS6	TATA spare parts
571014115852	HOSE DPF OUTLET PRESSURE SENSOR SIDE BS6	TATA spare parts
571014115853	HOSE EVRV CIRCUIT BS6	TATA spare parts
571014115854	HOSE EVRV CIRCUIT BS6	TATA spare parts
571014115855	HOSE EVRV TO T-CONNECTOR BS6	TATA spare parts
571014115856	HOSE EVRV TO T-CONNECTOR BS6	TATA spare parts
571014115857	HOSE EVRV TO NYLON TUBE BS6	TATA spare parts
571014115858	HOSE EVRV TO EGR BS6	TATA spare parts
571014115859	HOSE DPF INTAKE PRESSURE BS6	TATA spare parts
571014115860	HOSE INTAKE PRESSURE TUBE TO SENSOR BS6	TATA spare parts
571014115861	HOSE DPF OUTLET PRESSURE BS6	TATA spare parts
571014115862	HOSE DPF OUTLET PRESSURE SENSOR SIDE BS6	TATA spare parts
571014115863	HOSE DPF INTAKE PRESSURE BS6	TATA spare parts
571014115864	HOSE DPF OUTLET PRESSURE BS6	TATA spare parts
571014115865	HOSE INTAKE PRESSURE TUBE TO SENSOR BS6	TATA spare parts
571014115866	HOSE DPF OUTLET PRESSURE SENSOR SIDE BS6	TATA spare parts
571014117702	EV RV HOSE CLIP	TATA spare parts
571014117705	SUPPORT CLIP (VACUUM HOSE)	TATA spare parts
571014118201	BRACKET TURBOCHARGER SUPPORT	TATA spare parts
571014118206	BKT. ASSY. CATCON	TATA spare parts
571014118212	HEAT SHIELD TURBOCHARGER INNER	TATA spare parts
571014118213	HEAT SHIELD TURBOCHARGER OUTER	TATA spare parts
571014118219	HEAT SHIELD TURBOCHARGER OUTER	TATA spare parts
571014118225	HEAT SHIELD TURBOCHARGER OUTER	TATA spare parts
571014118227	BRACKET BS6	TATA spare parts
571014118228	HEAT SHIELD TURBOCHARGER OUTER BS6	TATA spare parts
571014118229	HEAT SHIELD TURBOCHARGER INNER BS6	TATA spare parts
571014118233	STIFFENER BRACKET EGR COOLER BKT ASSY BS	TATA spare parts
571014118234	BRACKET EGR MODULE MTG BS6	TATA spare parts
571014118236	BRACKET SENSOR MTG BS6	TATA spare parts
571014118237	BRACKET SENSOR MTG BS6-PH2	TATA spare parts
571014119913	DOC BRICK WITH LOADING BS6	TATA spare parts
571014119914	DPF BRICK WITH LOADING BS6	TATA spare parts
571014119915	SCR BRICK WITH LOADING BS6	TATA spare parts
571014510101	ASSY. TURBOCHARGER BS3/4	TATA spare parts
571014510102	TURBOCHARGER ASSY BS6	TATA spare parts
571014515301	GASKET (TC TO CYLINDER HEAD)	TATA spare parts

571014515303	GASKET TC TO EXHAUST ELBOW	TATA spare parts
571014515304	GASKET TURBOCHARGER TO EXHAUST ELBOW BS	TATA spare parts
571014600102	ASSY.PIPE (IC TO CYL HEAD COVER)	TATA spare parts
571014600104	ASSY.BRACKET WITH BASE PLATE-RH (INTERCO	TATA spare parts
571014600105	ASSY.BRACKET WITH BASE PLATE- LH (INTERC	TATA spare parts
571014600108	ASSY BRACKET(INTER COOLER DUCT MOUNTING)	TATA spare parts
571014600113	ASSY PIPE WITH CLAMP (TC TO IC)	TATA spare parts
571014600127	ASSY. HOSE TURBOCHARGER OUTLET BS3/4	TATA spare parts
571014600134	PIPE ASSY INTERCOOLER TO CYL HEAD COVER	TATA spare parts
571014600135	PIPE ASSY INTERCOOLER TO CYL HEAD COVER	TATA spare parts
571014600137	PIPE ASSY INTERCOOLER TO CYL HEAD COVER	TATA spare parts
571014600176	HOSE ASSY TURBOCHARGER OUTLET	TATA spare parts
571014600177	INTERCOOLER ASSY	TATA spare parts
571014600178	HOSE ASSY WITH PROTECTIVE SLEEVE	TATA spare parts
571014600181	HOSE ASSY TURBOCHARGER OUTLET BS6	TATA spare parts
571014600182	HOSE ASSY WITH PROTECTIVE SLEEVE BS6	TATA spare parts
571014600183	HOSE ASSY TURBOCHARGER OUTLET BS6	TATA spare parts
571014600184	PIPE ASSY WITH CLAMP TC TO INTERCOOLER B	TATA spare parts
571014600185	PIPE ASSY INTERCOOLER TO INTAKE THROTTLE	TATA spare parts
571014600186	HOSE ASSY WITH PROTECTIVE SLEEVE BS6	TATA spare parts
571014603801	PIPE INTERCOOLER TO INTAKE THROTTLE BS6	TATA spare parts
571014603803	PIPE TC TO INTERCOOLER BS6	TATA spare parts
571014604201	CLAMP WITH SPRING HOSE BS6-PH2	TATA spare parts
571014605801	RUBBER HOSE (IC OUTLET TO PIPE)	TATA spare parts
571014605803	RUBBER HOSE (PIPE TO HEAD COVER) BS3/4	TATA spare parts
571014605809	HOSE - PIPE TO IC	TATA spare parts
571014605810	HOSE - TC TO PIPE	TATA spare parts
571014605814	HOSE-ASSY.PIPE TO CYL.HEAD COVER	TATA spare parts
571014605815	HOSE-TC TO ASSY.PIPE	TATA spare parts
571014605817	HOSE IC INLET PIPE TO IC	TATA spare parts
571014605818	HOSE IC OUTLET TO PIPE	TATA spare parts
571014605820	RUBBER HOSE PIPE TO HEAD COVER	TATA spare parts
571014605824	HOSE IC OUTLET TO IC PIPE	TATA spare parts
571014605826	RUBBER HOSE PIPE TO HEAD COVER BS6	TATA spare parts
571014605827	RUBBER HOSE PIPE TO HEAD COVER BS6	TATA spare parts
571014605829	HOSE IC OUTLET TO IC PIPE BS6	TATA spare parts
571014605833	HOSE PIPE TO THROTTLE BS6	TATA spare parts
571014606301	INTERCOOLER DUCT	TATA spare parts
571014608205	BRACKET PIPE MTG BS6	TATA spare parts
571014608206	BRACKET IC PIPE SUPPORT BS6	TATA spare parts
571014608207	BRACKET PIPE MTG BS6	TATA spare parts
571014608208	BRACKET MTG TC IC PIPE BS6	TATA spare parts
571014609912	SLEEVE BS6	TATA spare parts
571014700102	ASSY. EGR COOLER W/VALVE BS3/4	TATA spare parts
571014700114	EGR VALVE ASSY WITH COOLER	TATA spare parts
571014700124	EGR VALVE ASSY WITH COOLER BS6	TATA spare parts
571014700125	EGR VALVE ASSY BS6	TATA spare parts

571014990105	KIT-GASKET DECARBONISING	TATA spare parts
571014990114	SET-EGR VALVE BS6	TATA spare parts
571014990115	SET-EGR COOLER ASSY BS6	TATA spare parts
571015143702	STIFFENER BRACKET	TATA spare parts
571015143703	STIFFENER BRACKET BS6	TATA spare parts
571015143801	BRACKET (FOR ALTERNATOR MTG)	TATA spare parts
571015143807	BRACKET ALTERNATOR MTG	TATA spare parts
571015143808	BRACKET ALTERNATOR MTG BS6	TATA spare parts
571015148201	STIFFENER BRACKET	TATA spare parts
571015209901	T-MAP SENSOR (BOOST PRESSURE SENSOR) BS4	TATA spare parts
571015209902	CRANK SENSOR (SPEED SENSOR) BS3/4/6	TATA spare parts
571015209903	CAM SENSOR (PHASE SENSOR) BS2/3/4	TATA spare parts
571015209904	AIR MASS FLOW SENSOR BS3/4/6	TATA spare parts
571015209906	ENGINE CONTROL UNIT BS3/4	TATA spare parts
571015209907	STICKER LABEL FOR ECU BS6	TATA spare parts
571015209910	CAM SENSOR BS6	TATA spare parts
571015209911	T-MAP SENSOR BS6	TATA spare parts
571015209912	LAMBDA SENSOR	TATA spare parts
571015209913	NOX SENSOR BS6	TATA spare parts
571015209914	TEMPERATURE SENSOR BS6	TATA spare parts
571015240101	SENSOR PARTICULATE MATTER BS6-PH2	TATA spare parts
571015240102	NOX SENSOR BS6-PH2	TATA spare parts
571015409901	GLOW PLUG BS4	TATA spare parts
571015409902	GLOW PLUG BS3/4	TATA spare parts
571015409903	GLOW PLUG BS6	TATA spare parts
571015990105	ECU WITH SOFTWARE(ACE TDI 2.1T BS III)	TATA spare parts
571015990107	ECU WITH SOFTWARE -(MAGIC FL TCIC BS-IV)	TATA spare parts
571015990109	ECU WITH SOFTWARE-ACE TCIC 0.85T BS-IV	TATA spare parts
571015990116	ECU WITH SOFTWARE(ACE NA 0.75T BS III)	TATA spare parts
571016101203	CONTAINER ASSY	TATA spare parts
571016101207	CONTAINER ASSY	TATA spare parts
571016101221	ASSY. CONTAINER BS3	TATA spare parts
571016101223	ASSY. CONTAINER BS2/4	TATA spare parts
571016101224	CONTAINER ASSY (ECU WITH SOFTWARE)	TATA spare parts
571018100101	ASSY. OIL PUMP BS3/4	TATA spare parts
571018100103	OIL PUMP ASSY	TATA spare parts
571018105301	GASKET OIL PUMP	TATA spare parts
571018130104	ASSY. OIL FILTER ELEMENT (SPINON) BS3/4	TATA spare parts
571018133801	ADAPTER (CRANKCASE TO OIL COOLER)	TATA spare parts
571018133804	ADAPTER OIL FILTER	TATA spare parts
571018150102	ASSY STRAINER (FOR OIL PUMP )- ACE	TATA spare parts
571018150103	STRAINER ASSY OIL PUMP	TATA spare parts
571018150104	STRAINER ASSY OIL PUMP BS6	TATA spare parts
571018155302	GASKET OIL PUMP STRAINER	TATA spare parts
571018155304	GASKET OIL PUMP STRAINER	TATA spare parts
571018170105	ASSY OIL COOLER - MODINE	TATA spare parts
571018170109	ASSY. TC OIL LINES BS3/4	TATA spare parts

571018170111	ASSLY PISTON COOLING NOZZLE-FABRICATED	TATA spare parts
571018170115	NOZZLE ASSY PISTON COOLING	TATA spare parts
571018170117	OIL COOLER ASSY	TATA spare parts
571018170118	OIL PIPE ASSY TC FEEDER & RETURN	TATA spare parts
571018170119	NOZZLE ASSY PISTON COOLING	TATA spare parts
571018170120	OIL PIPE ASSY TC FEEDER & RETURN	TATA spare parts
571018170123	OIL FEEDER PIPE ASSY CYL HEAD TO TC BS6	TATA spare parts
571018170124	PIPE ASSY TURBOCHARGER OIL RETURN BS6	TATA spare parts
571018170125	ASSY. OIL COOLER W/ GASKET BS3/4	TATA spare parts
571018175302	GAKSET TC OIL RETURN LINE BS6	TATA spare parts
571018175306	GASKET OIL COOLER ADAPTER	TATA spare parts
571018175307	GASKET TC OIL RETURN OUTLET	TATA spare parts
571018175308	GASKET ASSY. TC OIL LINES	TATA spare parts
571018175310	GASKET(PISTON COOLING NOZZLE)	TATA spare parts
571018178201	MOUNTING FLANGE (TC OIL LINE -NA)	TATA spare parts
571018179903	ADAPTOR (FOR OIL COLLER AND OIL FILTER)	TATA spare parts
571018179904	ADAPTOR (OIL FILTER)	TATA spare parts
571018179905	ADAPTER ASSY OIL COOLER	TATA spare parts
571020100103	ASSY. WATER PUMP(PLASTIC IMPELLER) BS3/4	TATA spare parts
571020100106	ASSY. WATER PUMP (ACE NA) BS3/4	TATA spare parts
571020100107	WATER PUMP ASSY BS6	TATA spare parts
571020105302	GASKET WATER PUMP BS4	TATA spare parts
571020120101	ASSY THERMOSTAT	TATA spare parts
571020120103	ASSY THERMOSTAT COVER	TATA spare parts
571020120106	THERMOSTAT ASSY	TATA spare parts
571020120107	COVER ASSY THERMOSTAT	TATA spare parts
571020120112	COVER ASSY THERMOSTAT	TATA spare parts
571020120114	THERMOSTAT ASSY	TATA spare parts
571020120117	THERMOSTAT ASSY BS6-PH2	TATA spare parts
571020125301	GASKET THERMOSTAT	TATA spare parts
571020125801	SLEEVE	TATA spare parts
571020128201	BRACKET HOSE CLAMPING	TATA spare parts
571022100101	ASSY. LIFTING HOOK (FRONT)	TATA spare parts
571022100107	LIFTING HOOK ASSY REAR	TATA spare parts
571022100109	LIFTING HOOK ASSY FRONT	TATA spare parts
571022100110	LIFTING HOOK ASSY REAR	TATA spare parts
571022100111	LIFTING HOOK ASSY REAR BS6	TATA spare parts
571022100112	LIFTING HOOK ASSY REAR BS6	TATA spare parts
571022100113	LIFTING HOOK ASSY BS6	TATA spare parts
571022107102	LIFTING HOOK-REAR	TATA spare parts
571022107103	LIFTING HOOK (REAR)	TATA spare parts
571022108201	LIFTING HOOK BS6	TATA spare parts
571022123708	ENGINE MOUNTING ARM (FRONT MOUNTING-AC	TATA spare parts
571022123714	BRACKET EXHAUST ELBOW	TATA spare parts
571022123715	ENGINE MTG ARM FRONT	TATA spare parts
571022123718	BRACKET ENGINE MTG ARM BS6	TATA spare parts
571022123719	ENGINE MTG ARM FRONT BS6	TATA spare parts

571022123720	BRACKET ENGINE MTG ARMBS6	TATA spare parts
571022123721	ENGINE MTG ARM FRONT BS6	TATA spare parts
571022123804	ENGINE MOUNTING BRACKET( HPDC )	TATA spare parts
571022128201	STIFFENER BS6	TATA spare parts
571022128202	STIFFENERBS6	TATA spare parts
571023113703	BRACKET POWER STEERING PUMP MTG BS6	TATA spare parts
571023113802	BRACKET POWER STEERING PUMP MTG	TATA spare parts
571023113803	BRACKET POWER STEERING PUMP MTG	TATA spare parts
571023113804	BRACKET POWER STEERING PUMP MTG	TATA spare parts
571023116301	POLY V BELT	TATA spare parts
571023116306	POLY V BELT BS4	TATA spare parts
571023116306DF	BELT POLY V-MEGA/MAGIC 800CC BS3/4	TATA spare parts
571023116317	POLY V-BELT	TATA spare parts
571023116318	POLY V-BELT POWER STEERING PUMP	TATA spare parts
571023116319	POLY V-BELT	TATA spare parts
571023120102	BELT IDLER PULLEY	TATA spare parts
571023120104	TENSIONER PULLEY 3 POINT MTG WITH S BS4	TATA spare parts
571023120109	TENSIONER ASSY PULLEY	TATA spare parts
571023123703	BRACKET AC COMP MTG	TATA spare parts
571023123704	STIFFENER BRACKET	TATA spare parts
571023123705	BRACKET AC COMP MTG BS6	TATA spare parts
571023126301	POLY V-BELT AC COMP BS6	TATA spare parts
571024200103	ASSLY ENGINE MOUNT (REAR)	TATA spare parts
5710400051	REAR HING PIN / SHAFT LOCKING PLATE	TATA spare parts
5710400052	REAR HING / SHAFT LOCKING PLATE STOPPER	TATA spare parts
5710400053	REAR HING PIN / SHAFT	TATA spare parts
571049100102	ASSY. UNDERBODY CATCON BS3/4	TATA spare parts
571049100103	CATCON ASSY UNDERBODY	TATA spare parts
571049100105	CATCON ASSY WITH FLEXIBLE BELLOW BS6	TATA spare parts
571049100106	SCR & MIXER ASSY BS6	TATA spare parts
571049100109	CATCON ASSY WITH FLEXIBLE BELLOW BS6	TATA spare parts
571049100110	SCR & MIXER ASSY BS6	TATA spare parts
571049100113	CATCON ASSY WITH FLEXIBLE BELLOW BS6	TATA spare parts
571049100121	CATCON ASSY WITH FLANGE BS6-PH2	TATA spare parts
571049100122	SCR & MIXER ASSY BS6-PH2	TATA spare parts
571049100127	CATCON ASSY WITH FLEXIBLE BELLOW BS6	TATA spare parts
571049100128	CATCON ASSY WITH FLEXIBLE BELLOW BS6	TATA spare parts
571049100137	CATCON ASSY WITH FLEXIBLE BELLOW BS6	TATA spare parts
571049100141	CATCON ASSY WITH FLANGE BS6-PH2	TATA spare parts
571049105302	GASKET EXHAUST FLANGE BS6	TATA spare parts
571050100106	ASSY. RADIATOR COMPLETE - ACE	TATA spare parts
571050100107	ASSY. PIPE WITH CLAMP (RADIATOR OUTLET)	TATA spare parts
571050100109	ASSY RADIATOR	TATA spare parts
571050100110	ASSY. PRESSURE CAP BS3/4/6	TATA spare parts
571050100111	ASSY FAN MOTOR & SHROUD	TATA spare parts
571050100112	FAN MOTOR ASSY.	TATA spare parts
571050100130	ASSY. PIPE - RADIATOR TO WATER PUMP (ACE	TATA spare parts



571050100131	ASSY. PIPE - THERMOSTAT TO RADIATOR (AC	TATA spare parts
571050100132	ASSY PIPE WITH CLAMP RADIATOR INLET - AC	TATA spare parts
571050100133	ASSY. BRACKET FOR ASSY. COOLING PIPE - A	TATA spare parts
571050100137	ASSY PIPE (THERMOSTAT BYPASS)	TATA spare parts
571050100138	ASSY COOLING PIPES WITH BRACKET-ACE	TATA spare parts
571050100145	RADIATOR SEALING LH	TATA spare parts
571050100146	RADIATOR SEALING TOP	TATA spare parts
571050100147	RADIATOR SEALING RH	TATA spare parts
571050100148	ASSY RADIATOR SEAL BOTTOM-ACE	TATA spare parts
571050100149	ASSBLY RADIATOR SEAL BACK WITH INSERT-AC	TATA spare parts
571050100167	ASSY PIPE (RADIATOR TO WATER PUMP)	TATA spare parts
571050100172	ASSLY.PIPE THERMOSTAT TO RADIATOR	TATA spare parts
571050100188	ASSY RADIATOR SEAL (RH)	TATA spare parts
571050100189	ASSY RADIATOR SEAL (LH)	TATA spare parts
571050100190	ASSY RADIATOR SEAL TOP	TATA spare parts
571050100191	ASSY. RADIATOR BS3/4	TATA spare parts
571050100212	BRACKET ASSY	TATA spare parts
571050100219	NO LOSS TANK ASSY WITH CAP	TATA spare parts
571050100241	PIPE ASSY UPPER COOLING LINE	TATA spare parts
571050100242	PIPE ASSY LOWER COOLING LINE	TATA spare parts
571050100243	SEAL ASSY RADIATOR BOTTOM	TATA spare parts
571050100244	SEAL ASSY RADIATOR TOP	TATA spare parts
571050100247	SEAL ASSY RADIATOR BACK	TATA spare parts
571050100248	ASSY. RADIATOR BS3/4	TATA spare parts
571050100249	RADIATOR SUB ASSY BS6	TATA spare parts
571050100251	BLEEDING SCREW ASSY	TATA spare parts
571050100252	ASSY. FAN SHROUD & MOTOR BS3/4	TATA spare parts
571050100254	MOTOR ASSY FAN	TATA spare parts
571050100262	PIPE ASSY WATER PUMP INLET	TATA spare parts
571050100264	PIPE ASSY THERMOSTAT TO RADIATOR	TATA spare parts
571050100266	PIPE ASSY	TATA spare parts
571050100272	PIPE ASSY LCL	TATA spare parts
571050100273	PIPE ASSY WITH BRACKET	TATA spare parts
571050100274	RADIATOR ASSY	TATA spare parts
571050100275	NOLOSSTANK	TATA spare parts
571050100278	PIPE ASSY WATER PUMP	TATA spare parts
571050100281	RADIATOR SEALING TOP	TATA spare parts
571050100284	PIPE ASSY WATER PUMP INTAKE	TATA spare parts
571050100286	BRACKET ASSY WITH SLEEVE	TATA spare parts
571050100289	PIPE ASSY LCL	TATA spare parts
571050100291	PIPE ASSY WATER PUMP	TATA spare parts
571050100292	PIPE ASSY LCL	TATA spare parts
571050100293	RADIATORASSY	TATA spare parts
571050100294	SHROUDASSYWITHFAN&MOTOR	TATA spare parts
571050100298	PIPE ASSY WATER PUMP INTAKE	TATA spare parts
571050100299	BRACKET ASSY HOSE SUPPORT	TATA spare parts
571050100302	SPACER TUBE RADIATOR MTG	TATA spare parts

571050100303	FILLERNECK	TATA spare parts
571050100304	BRACKETASSY RADIATOR TANK MTGBKT	TATA spare parts
571050100305	CAP RECOVERY BOTTLE	TATA spare parts
571050100307	PIPE ASSY WATER PUMP BS6	TATA spare parts
571050100309	PIPE ASSY WATER PUMP BS6	TATA spare parts
571050100310	BRACKET ASSY HOSE SUPPORT BS6	TATA spare parts
571050100315	PIPE ASSY LCL BS6	TATA spare parts
571050100322	RADIATOR ASSY	TATA spare parts
571050100323	FILLER NECK	TATA spare parts
571050100324	RECOVERY BOTTLE ASSY	TATA spare parts
571050100325	BRACKET ASSY	TATA spare parts
571050100326	PIPE ASSY WATER PUMP BS6	TATA spare parts
571050100327	HOSE ASSY EGR COOLER TO PIPE BS6	TATA spare parts
571050100328	BRACKET ASSY BS6	TATA spare parts
571050100350	PIPE ASSY LCL BS6	TATA spare parts
571050100351	PIPE ASSY WATER PUMP BS6	TATA spare parts
571050100353	HOSE OIL COOLER TO WATER PUMP BS6	TATA spare parts
571050100363	RADIATOR ASSY WITH FAN & SHROUD BS6-PH2	TATA spare parts
571050100364	NO LOSS TANK ASSY WITH CAP BS6-PH2	TATA spare parts
571050100365	PIPE ASSY WATER PUMP BS6-PH2	TATA spare parts
571050100368	SHROUD ASSY WITH FAN - MOTOR BS6-PH2	TATA spare parts
571050105802	HOSE- UPPER COOLING LINE (ASSY PIPE WITH	TATA spare parts
571050105805	HOSE-THERMOSTAT TO RADIATOR PIPE (SMALL	TATA spare parts
571050105810	HOSE - THERMOSTAT BYPASS TO EGR COOLER	TATA spare parts
571050105811	HOSE - COOLING SYSTEM	TATA spare parts
571050105822	HOSE- ASSY. RADIATOR PIPE TO WATER PUMP	TATA spare parts
571050105825	HOSE- OIL COOLER TO WATER PUMP_ ACE	TATA spare parts
571050105826	HOSE- OIL COOLER TO ASSY RADIATOR PIPE	TATA spare parts
571050105827	HOSE - EGR COOLER TO ASSY. RADIATOR PIPE	TATA spare parts
571050105828	HOSE - LOWER COOLING LINE	TATA spare parts
571050105829	HOSE - UPPER COOLING LINE	TATA spare parts
571050105830	HOSE-ASSY WATER PUMP PIPE TO THERMOSTAT	TATA spare parts
571050105831	HOSE-COOLING PIPES TO RADIATOR PIPES.	TATA spare parts
571050105837	BRACKET HOLDING SLEEVE	TATA spare parts
571050105848	HOSE COOLING SYSTEM	TATA spare parts
571050105849	HOSE COOLING SYSTEM	TATA spare parts
571050105856	HOSE THERMOSTAT TO ASSY PIPE	TATA spare parts
571050105859	HOSE LOSS TANK TO RADIATOR	TATA spare parts
571050105860	HOSE EGR COOLER TO RADIATOR PIPE	TATA spare parts
571050105861	HOSE LCL RADIATOR OUTLET	TATA spare parts
571050105863	HOSE PIPE ASSY TO EGR COOLER	TATA spare parts
571050105867	HOSE OIL COOLER TO RADIATOR	TATA spare parts
571050105868	HOSE THERMOSTAT COVER TO RADIATOR	TATA spare parts
571050105869	HOSE OIL COOLER TO WATER PUMP	TATA spare parts
571050105894	HOSE LCL	TATA spare parts
571050105896	HOSE LCL RADIATOR OUTLET	TATA spare parts
571050105897	HOSE THERMOSTAT OUTLET	TATA spare parts

571050105898	HOSE THERMOSTAT OUTLET	TATA spare parts
571050105899	SLEEVE BRACKET HOLDING	TATA spare parts
571050106304	SHROUD	TATA spare parts
571050106310	SHROUD	TATA spare parts
571050106311	COVER PLATE BS6	TATA spare parts
571050106312	CAP	TATA spare parts
571050107502	RUBBER GROMMET	TATA spare parts
571050107504	RUBBER GROMMET RADIATOR MTG	TATA spare parts
571050108208	CLAMP FOR ASSY. COOLING PIPE - ACE	TATA spare parts
571050108216	SUPPORT ROD RADIATOR MTG TOP-LH	TATA spare parts
571050108217	SUPPORT ROD RADIATOR MTG TOP-RH	TATA spare parts
571050115801	VENT HOSE	TATA spare parts
571050115802	HOSE REDUCER	TATA spare parts
571050115806	FILLERHOSE RADIATOR	TATA spare parts
571050115807	FILLERHOSE RADIATOR	TATA spare parts
571050115808	HOSE RECOVERYTANK	TATA spare parts
571050115809	HOSE EGR COOLER OUTLET BS6	TATA spare parts
571050115811	HOSE PIPE ASSY TO EGR COOLER BS6	TATA spare parts
571050115812	HOSE OIL COOLER TO RADIATOR BS6	TATA spare parts
571050115813	HOSE EGR COOLER TO RADIATOR PIPE BS6	TATA spare parts
571050115814	HOSE LCL BS6	TATA spare parts
571050115815	HOSE THERMOSTAT COVER TO RADIATOR BS6	TATA spare parts
571050115816	HOSE OIL COOLER TO WATER PUMP BS6	TATA spare parts
571050115817	HOSE EGR COOLER TO RADIATOR PIPE BS6	TATA spare parts
571050115819	HOSE OIL COOLER TO RADIATOR BS6	TATA spare parts
571050115820	HOSE WATER PUMP TO OIL COOLER	TATA spare parts
571050115821	HOSE OIL COOLER TO RADIATOR	TATA spare parts
571050115826	FILLER HOSE RADIATOR	TATA spare parts
571050115827	FILL HOSE INLET	TATA spare parts
571050115831	HOSE REDUCER BS6	TATA spare parts
571050115832	HOSE LCL RADIATOR OUTLET BS6	TATA spare parts
571050117704	BRACKETASSY	TATA spare parts
571050403301	BRACKET RADIATOR MTG	TATA spare parts
571050403302	BRACKET RADIATOR MTG	TATA spare parts
571401000106	ENGINE ASSY 697NA.ENG.24V-EX110	TATA spare parts
571401000107	ASSY ENG COMP.697TC82.TCIC-BSIII	TATA spare parts
571401000119	ASSY ENG COMP 697TC51 81.5 KW @1500 GOEM	TATA spare parts
571401000120	ASSY ENG COMP 697TC52 93.5 KW @1500 GOEM	TATA spare parts
571401000126	125 KVA GOEM ENG ASSEMBLY	TATA spare parts
571401000128	ENG ASSY 697TC10 93.5KW@1500 CPCB2 GOEM	TATA spare parts
571401000129	ENG ASSY 697TC10 81.5KW@1500 CPCB2 GOEM	TATA spare parts
571401000133	ENGINE ASSLY 697 101 PS	TATA spare parts
571401100123	CYL BLOCK ASSY WITH FLYWHEEL HSG	TATA spare parts
571401135301	GASKET-OIL SUMP FLANGE	TATA spare parts
571401145301	GASKET-TGH	TATA spare parts
571401145302	GASKET-TGH COVER	TATA spare parts
571401150106	CYLINDER HEAD ASSY WITH VALVES	TATA spare parts

571401160101	INJECTORASSY	TATA spare parts
571401160103	INJECTOR	TATA spare parts
571401177801	O RING	TATA spare parts
571401990109	HALF BLOCK - (TELCON EX-200)	TATA spare parts
571401990110	LONG BLOCK -(TELCON EX-200)	TATA spare parts
571401990113	HALF BLOCK ASSY 697TCIC BSIII 130PS	TATA spare parts
571401990114	LONG BLOCK ASSY 697TCIC BSIII 130PS	TATA spare parts
571401990118	ASSY. LONG BLOCK¿ 82.5KVA CPCB-I	TATA spare parts
571401990123	HALF BLOCK ASSY	TATA spare parts
571401990124	LONG BLOCK ASSY	TATA spare parts
571401990127	ASSY HALF BLOCK	TATA spare parts
571401990128	ASSY. LONG BLOCK	TATA spare parts
571401990131	HALF BLOCK ASSY	TATA spare parts
571401990133	LONG BLOCK ASSY	TATA spare parts
571401990135	KIT-ENGINE OVERHAUL GASKET	TATA spare parts
571401990139	HALF BLOCK ASSY	TATA spare parts
571401990140	LONG BLOCK ASSY	TATA spare parts
571401990145	HALF BLOCK ASSY	TATA spare parts
571401990147	LONG BLOCK ASSY	TATA spare parts
571401990150	HALF BLOCK ASSY	TATA spare parts
571401990152	LONG BLOCK ASSY	TATA spare parts
571403110105	FLYWHEEL ASSY WITH RING GEAR	TATA spare parts
571403110109	ASSY FLYWHEEL WITH RING GEAR (10/-1DEG)	TATA spare parts
571403110110	ASSY FLYWHEEL¿ WITH RING GEAR	TATA spare parts
571403990106	SET-PISTON RING	TATA spare parts
571407100107	ASSY FIP	TATA spare parts
571407100112	FIP-697 BSIII	TATA spare parts
571407100118	B12 E-GOVERNOR ACTUATOR (697)	TATA spare parts
571407100119	GOVERNOR MOUNTING BKT.(697)	TATA spare parts
571407100120	ECU MOUNTING BKT.	TATA spare parts
571407100121	GOVERNOR LINK ASSEMBLY	TATA spare parts
571407100122	ASSY SOLENOID	TATA spare parts
571407100127	FIP ASSY WITH SUPPORT 82.5KVA CPCBII	TATA spare parts
571407100129	FIP ASSY WITH SUPPORT 100KVA CPCBII	TATA spare parts
571407100131	FUEL INJECTION PUMP	TATA spare parts
571407100143	SOLENOID VALVE ASSY ENGINE STOP	TATA spare parts
571407120101	FUEL INJECTION PUMP ASSY	TATA spare parts
571407140122	KIT-HP LINE	TATA spare parts
571407149901	FUEL OVER FLOW PIPE PUMP TO INJECTOR	TATA spare parts
571409120111	LEAK OFF PIPE ASSY INJECTOR	TATA spare parts
571409140102	AIR INTAKE SYSTEM	TATA spare parts
571409140103	ASSY BRACKET AIR CLEANER MTG.	TATA spare parts
571409140104	PIPE ASSY. POWDER COATED	TATA spare parts
571409140105	PIPE ASSY. POWDER COATED	TATA spare parts
571409145802	HOSE REDUCER ELBOW	TATA spare parts
571409145803	RUBBER SLEEVE	TATA spare parts
571413105301	GASKET-AIR COMPRESSOR	TATA spare parts

571413117101	FLANGE(FOR CLOSING AIR COMP HOLE) BS6-PH	TATA spare parts
571414110102	ASSY COOLANT OUTLET LINE EGR VALVE 697	TATA spare parts
571414110103	ASSY EGR LINE (EGR VALVE TO SPACER)	TATA spare parts
571414110104	ASSY COOLANT INLET LINE(OIL COOLER TO EG	TATA spare parts
571414110105	ASSY EGR PIPE-FROM EXH MANIFOLD TO EGR C	TATA spare parts
571414110106	SPACER (AIR INTAKE ELBOW)	TATA spare parts
571414110107	ASSY EGR VALVE	TATA spare parts
571414110108	EGR COOLER MOUNTING BRACKET	TATA spare parts
571414110111	EGR COOLANT OUTLET LINE	TATA spare parts
571414110112	EGR COOLENT INLET LINE	TATA spare parts
571414110124	SPACER ASSY AIR INTAKE ELBOW	TATA spare parts
571414110131	EGR PIPE EGR COOLER TO EXHAUST PIPE	TATA spare parts
571414110134	EGR PIPE ASSY WITH CLAMP	TATA spare parts
571414110136	EGR VALVE	TATA spare parts
571414110140	EGR VALVE ASSY	TATA spare parts
571414110201	ASSY EGR COOLER	TATA spare parts
571414110203	ASSY. EGR COOLER	TATA spare parts
571414113702	EXHAUST MANIFOLD	TATA spare parts
571414115301	GASKET-EXHAUST MANIFOLD	TATA spare parts
571414115342	GASKET	TATA spare parts
571414117101	EGR COOLER MOUNTING PLATE	TATA spare parts
571414119904	ECU	TATA spare parts
571414510101	ASSY TURBO CHARGER	TATA spare parts
571414510103	TURBOCHARGER ASSY	TATA spare parts
571414510104	ADAPTER ASSY TURBOCHARGER	TATA spare parts
571414519901	HEAT SHIELD	TATA spare parts
571414600106	INTERCOOLER ASSY	TATA spare parts
571414603801	IC PIPE (TC TO IC)	TATA spare parts
571414603802	IC PIPE (IC TO AIRINTAKE)	TATA spare parts
571414604201	U-CLAMP(TC TO IC PIPE SUPPORT)	TATA spare parts
571414604202	U-CLAMP(AIR INTAKE TO IC PIPE SUPPORT)	TATA spare parts
571414606901	PIPE INTERCOOLER TO AIR INTAKE	TATA spare parts
571414606902	PIPE	TATA spare parts
571418130103	LUBE LIL FILTER ASSY	TATA spare parts
571418170103	ASSY OIL SUPPLY LINE(OIL COOLER TO TC)	TATA spare parts
571418170104	ASSY. OIL COOLER WITH COVER AND ADAPTOR	TATA spare parts
571418170110	OIL SUPPLY PIPE ASSY	TATA spare parts
571418170111	OIL RETURN LINE ASSY	TATA spare parts
571418175801	HOSE(TC OIL OUTLET TO CYL BLOCK)	TATA spare parts
571420105301	GASKET-WATER PUMP	TATA spare parts
571420107001	WATER PUMP PULLEY	TATA spare parts
571420120102	ASSY. THERMOSTAT	TATA spare parts
571420120104	ASSY UPPER WATER COOLING LINE	TATA spare parts
571420120108	THERMOSTAT	TATA spare parts
571420126902	PIPE BYPASS	TATA spare parts
571420126903	PIPE	TATA spare parts
571420140103	FAN	TATA spare parts

571420140106	FAN DIA 660\7 BLADES	TATA spare parts
571420305801	HOSE (THERMOSTAT TO WATER PUMP)	TATA spare parts
571422120101	ASSY SUPPORT ENGINE FRONT-RH	TATA spare parts
571422120102	ASSY SUPPORT ENGINE FRONT (LH)	TATA spare parts
571422120103	CROSS ARM	TATA spare parts
571449100101	ASSY CATCON	TATA spare parts
571450100101	RADIATOR ASSY	TATA spare parts
571450100102	ASSY. ENGINE COOLING SYSTEM	TATA spare parts
571450100104	RADIATOR & INTERCOOLER ASSY	TATA spare parts
571450100110	RECOVERY BOTTLE ASSY	TATA spare parts
571450100111	PRESSURE CAP	TATA spare parts
571450100112	RADIATOR ASSY	TATA spare parts
571450105801	HOSE (RADIATOR TO WATER PUMP)	TATA spare parts
571450105802	HOSE (RADIATOR TO THERMOSTAT)	TATA spare parts
571450105803	HOSE	TATA spare parts
571450105804	HOSE	TATA spare parts
571450506301	FAN GUARD	TATA spare parts
571450990105AJ0	KIT-ENGINE COOLING SYSTEM	TATA spare parts
571454200105	WIRING HARNESS	TATA spare parts
571454209901	EGR CONTROLLER	TATA spare parts
571454209904	ECU (697 ENGINE)	TATA spare parts
571454209908	ECU 100 KVA CPCB II	TATA spare parts
571454209909	ECU 100 KVA CPCB II (EGR+GOV)	TATA spare parts
571500000178	ENGINE ASSY W/O CLUTCH BS6-PH2	TATA spare parts
571501100128	CYL BLOCK ASSY & BED PLATE	TATA spare parts
571501103204	BOLT,MAIN BEARING CAP TORX M10X1.5 E14	TATA spare parts
571501103205	SEALING PLUG	TATA spare parts
571501103819	BED PLATE BS6	TATA spare parts
571501107801	OIL SEAL (CRANK SHAFT FRONT)	TATA spare parts
571501108202	DEFLECTOR PLATE CYL. BLOCK	TATA spare parts
571501130118	OIL SUMP ASSY BS6	TATA spare parts
571501150141	CYL HEAD ASSY W/O VALVES BS6-PH2	TATA spare parts
571501150145	COVER ASSY CYLINDER HEAD BS6	TATA spare parts
571501153204	BOLT,CYL HEAD TORX M10X1.5 E12	TATA spare parts
571501153412	ORIFICE,OIL GALLERY	TATA spare parts
571501153419	VALVE SEAT,INTAKE	TATA spare parts
571501153421	VALVE SEAT,EXHAUST	TATA spare parts
571501153813	CYLINDER HEAD	TATA spare parts
571501155307	GASKET,CYL BLOCK TO CYL HEAD	TATA spare parts
571501157701	CAP	TATA spare parts
571501157702	CAP OIL FILLER RING	TATA spare parts
571501157703	RUBBER OCV SEAL BS6-PH2	TATA spare parts
571501157704	SEAL CYLINDER HEAD COVER BS6-PH2	TATA spare parts
571501170105	DIPSTICK TUBE ASSY BS6	TATA spare parts
571501170107	DIPSTICK ASSY BS6	TATA spare parts
571501175804	HOSE,BLOWBY HEAD COVER TO MANIFOLD	TATA spare parts
571501990154	KIT-ENGINE OVERHAUL SEAL BS6-PH2	TATA spare parts

571501990196	KIT-INLET & EXHAUST VALVES BS6-PH2	TATA spare parts
571501990264	HALF BLOCK ASSY ENGINE BS6-PH2	TATA spare parts
571501990267	BARE ENGINE ASSY BS6-PH2	TATA spare parts
571501990270	ASSY CYL HEAD WITHOUT INJECTOR BS6-PH2	TATA spare parts
571503100123	CRANKSHAFT ASSY WITH BRG & SENSOR WHEEL	TATA spare parts
571503107909	CRANKSHAFT-TABLE DRG BS6	TATA spare parts
571503108204	TARGET WHEEL,CRANK SENSOR	TATA spare parts
571503110104	FLYWHEEL ASSY	TATA spare parts
571503120104	SET MAIN BRG UPPER/LOWER "J" (NA) BS6-PH	TATA spare parts
571503123413	MAIN BEARING UPPER 'J' (FM)	TATA spare parts
571503123416	MAIN BEARING LOWER 'J' (FM)	TATA spare parts
571503130106	PULLEY ASSY VIBRATION DAMPER BS6	TATA spare parts
571503133201	HEX FLANGE BOLT (FOR DAMPER PULLEY)	TATA spare parts
571503139201	WASHER (DAMPER PULLEY)	TATA spare parts
571503140133	PISTON ASSY GRADE A BS6	TATA spare parts
571503140134	PISTON ASSY GRADE B BS6	TATA spare parts
571503150121	CONNECTING ROD ASSY WITH BUSH	TATA spare parts
571503150127	CONN ROD ASSY WITH PISTON ASSY	TATA spare parts
571503153201	BOLT (CON ROD FRACTURE SPLIT)	TATA spare parts
571503153407	CONROD BEARING 'C' (FM)	TATA spare parts
571503153408	CONROD BEARING 'D' (FM)	TATA spare parts
571503990107	SET-PISTON RING GRADE A,B	TATA spare parts
571503990119	SET-THRUST WASHER	TATA spare parts
571503990142	SET-PISTON W/O RINGS GRADE A BS6-PH2	TATA spare parts
571503990143	SET-PISTON W/O RINGS GRADE B BS6-PH2	TATA spare parts
571503990146	SET-CONNECTING ROD BEARING HALF	TATA spare parts
571505100134	CAMSHAFT ASSY INTAKE	TATA spare parts
571505103203	HEX BOLT (INTAKE CAMSHAFT VVT)	TATA spare parts
571505103205	HEX BOLT (EXHAUST CAMSHAFT VVT)	TATA spare parts
571505103206	HEX FL BOLT (ITG BRG CAP)	TATA spare parts
571505104115	CAP,BEARING,CAMSHAFT NA	TATA spare parts
571505104117	CAP,INTEGRAL CAM BEARING,LOWER	TATA spare parts
571505104118	CAP,INTEGRAL CAM BEARING,UPPER	TATA spare parts
571505107915	CAMSHAFT,EXHAUST	TATA spare parts
571505107924	CAMSHAFT INTAKE BS6	TATA spare parts
571505108205	TARGET WHEEL,CAMPHASE SENSOR	TATA spare parts
571505110107	SOLENOID VALVE (DENSO)	TATA spare parts
571505110114	VCT. EXHAUST (TC)	TATA spare parts
571505110125	VARIABLE CAM TIMING BS6	TATA spare parts
571505118905	SPROCKET, CRANKSHAFT NA	TATA spare parts
571505119910	BUSH CHAIN	TATA spare parts
571505119911	TENSIONER, HYDRAULIC	TATA spare parts
571505119912	TENSIONER RAIL	TATA spare parts
571505119913	BLADE, FIXED (CRANK CAM)	TATA spare parts
571505119915	CAM CARRIER ASSY	TATA spare parts
571505124301	LOCK HALF BS6	TATA spare parts
571505125107	INTAKE VALVE: TC	TATA spare parts

571505125112	EXHAUST VALVE BS6	TATA spare parts
571505128703	VALVE SPRING (SSS) :NA	TATA spare parts
571505140101	HLA RFF ASSY(INA)	TATA spare parts
571505153705	VALVE GUIDE	TATA spare parts
571507104203	CLIP,FUEL INJECTOR	TATA spare parts
571507140106	FUEL RAIL ASSY	TATA spare parts
571507140114	FUEL RAIL ASSY BS6	TATA spare parts
571509130150	PIPE ASSY WITH BRACKET BS6	TATA spare parts
571509130168	BRACKET WITH WELD NUT BS6	TATA spare parts
571509135817	HOSE BS6	TATA spare parts
571509135820	HOSE BS6	TATA spare parts
571509135824	HOSE AIR FILTER TO SNORKEL BS6	TATA spare parts
571514100112	INTAKE MANIFOLD BS6	TATA spare parts
571514110138	GASKET,EXHAUST	TATA spare parts
571514110249	CATCON ASSY BS6	TATA spare parts
571515146307	BELT ALTERNATOR BS6	TATA spare parts
571515189902	SPARK PLUG	TATA spare parts
571515209905	LAMBDA SENSOR	TATA spare parts
571515209910	ROTATIONAL SPEED SENSOR BS6	TATA spare parts
571515209911	ROTATIONAL SPEED SENSOR	TATA spare parts
571515209913	PRESSURE/TEMPERATURE SENSOR BS6	TATA spare parts
571515210115	IGNITION COIL ASSY BS6	TATA spare parts
571515219907	INJECTOR	TATA spare parts
571515219922	THROTTLE BODY BS6	TATA spare parts
571518100108	OIL PUMP ASSY	TATA spare parts
571518103812	OIL FILTER HOLDER (NA)	TATA spare parts
571518105304	GASKET,OIL FILTER ADAPTER	TATA spare parts
571518108803	STUD	TATA spare parts
571518130101	OIL FILTER ASSY	TATA spare parts
571518150112	STRAINER ASSY BS6	TATA spare parts
571520100116	WATER PUMP ASSY BS6	TATA spare parts
571520120135	WATER BYPASS TUBE ASSY	TATA spare parts
571520120157	COVER ASSY THERMOSTAT HOUSING BS6	TATA spare parts
571520127702	SEAL (WATER BY-PASS TUBE)	TATA spare parts
571520305801	HOSE,THERMOSTAT TO BYPASS PIPE	TATA spare parts
571522107104	LIFTING HOOK : (FRONT )	TATA spare parts
571522107105	ENGINE LIFTING HOOK CYL HEAD FRONT BS6	TATA spare parts
571522123702	A-MOUNTING ARM BS6	TATA spare parts
571522148202	ENGINE NUMBER PLATE BS6	TATA spare parts
571523123804	BRACKET COMPRESSOR MTG BS6	TATA spare parts
571523126302	BELT AC COMP BS6	TATA spare parts
571550100145	PIPE ASSY LCL WATER PUMP BS6	TATA spare parts
571550100146	PIPE ASSY THERMOSTAT COVER TO RADIATOR B	TATA spare parts
571550100164	BRACKET ASSY BS6	TATA spare parts
571550100170	HOSE ASSY RADIATOR TO ENGINE BS6	TATA spare parts
571550104204	BRACKET UCL MTG BS6	TATA spare parts
571550104210	CLAMP BS6	TATA spare parts



571550105866	HOSE BS6	TATA spare parts
571550105867	HOSE BS6	TATA spare parts
571550105868	RUBBER HOSE BS6	TATA spare parts
571550105869	RUBBER HOSE BS6	TATA spare parts
571550105875	HOSE BS6	TATA spare parts
571550105893	RUBBER HOSE THERMOSTAT TO CONNECTOR BS6	TATA spare parts
571550105894	COOLANT HOSE PR REGULATOR INTAKE BS6	TATA spare parts
571550105895	RUBBER HOSE WATER PUMP INTAKE BS6	TATA spare parts
571550105896	COOLANT HOSE PR REGULATOR OUTLET BS6	TATA spare parts
571550106305	CONNECTOR PRESSURE LINE BS6	TATA spare parts
571614115317	GASKET (EXHAUST MANIFOLD) M/S. TALBROS	TATA spare parts
571701000105	ENGINE COMPLETE WITH CLUTCH ACE ZIP	TATA spare parts
571701010101	ASSY. LONG BLOCK G600W BS2/3/4	TATA spare parts
571701010104	ASSY. ENGINE COMPLETE (G600W) BS4	TATA spare parts
571701019901	TOTAL OVERHAUL KIT	TATA spare parts
571701019902	PARTIAL OVERHAUL KIT	TATA spare parts
571701019906	SET OF GASKETS	TATA spare parts
571701019907	KIT-PARTIAL OVERHAUL	TATA spare parts
571701019908	KIT-TOTAL OVERHAUL	TATA spare parts
571701109901	CRANKCASE ASSY WITH STANDARD BUSH DOWEL	TATA spare parts
571701109902	PIN (DIA. 4X8 FOR THRUST WASHER)	TATA spare parts
571701109903	STUD PTO END COVER (M8X1.25X62TL)	TATA spare parts
571701109904	STUD	TATA spare parts
571701109905	STUD CYLINDER HEAD MTG. (M12X1.5X246TL)	TATA spare parts
571701109906	STUD ENGINE FEET (M10X1.5X60TL)	TATA spare parts
571701109907	STUD M8X1.25X34L	TATA spare parts
571701109908	DOWEL PIN (DIA.6X18 FOR PTO END COVER)	TATA spare parts
571701109909	ASSY. CYLINDER BARREL BS2/3/4	TATA spare parts
571701109909DF	CYLINDER BARREL ASSY-ZIP/IRIS BS3/4	TATA spare parts
571701109910	DOWEL PIN (HOLLOW) (15H7X12.6X12L)	TATA spare parts
571701109911	JOINT CYL HEAD (AL- GASKET 0.5MM BS4	TATA spare parts
571701109912	OIL SEAL STD (CRANKSHAFT SUPPORT FWE SID	TATA spare parts
571701109912DF	OIL SEAL CRANKSHAFT REAR-ZIP/IRIS BS3/4	TATA spare parts
571701109913	PTO END COVER ASSY.	TATA spare parts
571701109914	PTO COVER GRUB SCREW	TATA spare parts
571701109915	GRUB SCREW (1/8IN BSPT X 5/16IN L FOR PT	TATA spare parts
571701109916	OIL SEAL STD FOR PTO COVER	TATA spare parts
571701109916DF	OIL SEAL CRANKSHAFT FRONT-ZIP/IRIS BS3/4	TATA spare parts
571701109917	SPRING WASHER ADAPTOR MOUNTING (14.2X8	TATA spare parts
571701109918	GASKET FOR PTO COVER.	TATA spare parts
571701109919	STARTER PLATE	TATA spare parts
571701109920	STUD STARTER MOUNTING	TATA spare parts
571701109921	STUD TENSIONER LEVER (M8X1.25X28TL)	TATA spare parts
571701109923	KIT-PISTON ASSY. & CYL. BARREL BS2/3/4	TATA spare parts
571701109924	OIL SEAL U/S 0.5MM (CRANKSHAFT SUPPORT)	TATA spare parts
571701109925	OIL SEAL U/S 1.0MM (CRANKSHAFT SUPPORT)	TATA spare parts
571701109926	OIL SEAL U/S 0.5 MM FOR PTO COVER	TATA spare parts

571701109927	OIL SEAL U/S 1.0 MM	TATA spare parts
571701109928	ENGINE OVERHAUL GASKET KIT	TATA spare parts
571701109929	SET OF OIL SEALS (STD) BS2/3/4	TATA spare parts
571701109930	COLLAR NUT FOR PTO COVER- M8X1.25	TATA spare parts
571701109931	DOWEL SLEEVE-ç PTO END COVER	TATA spare parts
571701109932	CRANKCASE ASSEMBLY. WITH STANDARD BUSH D	TATA spare parts
571701109934	STUD - PTO END COVER (M8X1.25)	TATA spare parts
571701109935	STUD FWE (M8X1.25X37TL FWE)	TATA spare parts
571701109936	STUD ENGINE FEET (M10X1.5X60TL)	TATA spare parts
571701109937	STUD (M8X1.25X34TL) FOR FUEL FEED PUMP	TATA spare parts
571701109939	COVER PTO (COLLAR NUT M8)	TATA spare parts
571701109940	STUD STARTER MTG	TATA spare parts
571701109941	STUD TENSIONER LEVER (M8X1.25X28TL)	TATA spare parts
571701109942	WASHER PLAIN (16X8.1X2 MM THK)	TATA spare parts
571701109943	NUT REGULAR HEXAGON M8X1.25	TATA spare parts
571701109944	PLATE RETAINER	TATA spare parts
571701109945	PLATE RETAINER	TATA spare parts
571701109951	CRANKCASE ASSY WITH BUSH AND PLUG	TATA spare parts
571701109953	STUD	TATA spare parts
571701109954	OIL RETURN TUBE ASSY	TATA spare parts
571701109955	BRACKET WIRING HARNESS SUPPORT	TATA spare parts
571701109956	BRACKET WIRING HARNESS SUPPORT	TATA spare parts
571701109957	HEX FLANGE SCREW	TATA spare parts
571701109959	HEX FLANGE BOLT	TATA spare parts
571701109960	KIT-BARREL & ASSY. PISTON BS4	TATA spare parts
571701109961	COVER ASSY PTO END	TATA spare parts
571701139901	OIL PAN ASSY WITH DRAIN PLUG	TATA spare parts
571701139902	JOINT OIL PAN (1.5MM THICK) GASKET FOR O	TATA spare parts
571701139903	JOINT DRAIN PLUG (WASHER- 19X12.1X1MM TH	TATA spare parts
571701139904	HEX FLANGE SCREW M8X1.25X20	TATA spare parts
571701139905	MAGNETIC DRAIN PLUG	TATA spare parts
571701139906	OIL PAN ASSEMBLY WITH DRAIN PLUG	TATA spare parts
571701139910	ASSY. OIL PAN W/DRAIN PLUG BS4	TATA spare parts
571701159901	ASSY. CYLINDER HEAD BS2/3/4	TATA spare parts
571701159902	SET OF VALVE SEAT STD	TATA spare parts
571701159903	VALVE SEAT INLET	TATA spare parts
571701159904	VALVE SEAT IEXHAUST	TATA spare parts
571701159905	STUD INJECTOR MOUNTING (M8X1.25X50TL)	TATA spare parts
571701159906	SPRING WASHER (11.1X6.1X1.3MM THK)	TATA spare parts
571701159907	GASKET CYLINDER HEAD 1.25MM BS3/4	TATA spare parts
571701159907DF	GASKET CYLINDER HEAD 1.25MM-ZIP/IRIS BS3	TATA spare parts
571701159908	GASKET CYLINDER HEAD -1.4MM BS2/3/4	TATA spare parts
571701159908DF	GASKET CYLINDER HEAD 1.40MM-ZIP/IRIS BS3	TATA spare parts
571701159909	STUD INTAKE MANIFOLD (M6X1X37TL)	TATA spare parts
571701159910	STUD (M6X1X26TL) FOR THERMOSTAT	TATA spare parts
571701159911	NUT CYL. HEAD M12	TATA spare parts
571701159912	WASHER (24X13X3MM THK. FOR CYLINDER HEAD	TATA spare parts

571701159913	SEALING WASHER OF TEMPERATURE SENSOR (10	TATA spare parts
571701159914	JOINT FOR TEMPERATURE SENSOR (15X10.2X2	TATA spare parts
571701159915	SPRING WASHER M6- FOR THERMOSTAT	TATA spare parts
571701159917	SEALING WASHER (10X6.2X1.9 CU WASHER FOR	TATA spare parts
571701159918	CLAMP C	TATA spare parts
571701159919	ROCKER BOX COVER	TATA spare parts
571701159920	JOINT 0.25 MM (GASKET FOR ROCKER COVER)	TATA spare parts
571701159924	BOLT M8 FOR ROCKER COVER (M8X1.25X45L)	TATA spare parts
571701159925	SPRING WASHER (15X8.4X0.5MM THK.) BS4	TATA spare parts
571701159926	BOLT M8 FOR ROCKER COVER (M8X1.25X40L)	TATA spare parts
571701159927	CLAMP - A	TATA spare parts
571701159928	CLAMP - B	TATA spare parts
571701159929	GASKET CYL. HEAD -1.0MM BS2/3/4	TATA spare parts
571701159929DF	GASKET CYLINDER HEAD 1.00MM-ZIP/IRIS BS3	TATA spare parts
571701159930	OIL FILLING PLUG	TATA spare parts
571701159931	O RING FOR OIL FILLING CAP	TATA spare parts
571701159932	CLAMP - D	TATA spare parts
571701159933	ROCKER BOX COVER ASSEMBLY	TATA spare parts
571701159934	STUD INJECTOR MTG. (M8X1.25X50TL)	TATA spare parts
571701159935	STUD INTAKE MANIFOLD (M6X1X37TL)	TATA spare parts
571701159936	CYLINDER HEAD NUT M12	TATA spare parts
571701159938	COVER ROCKER MACHINED	TATA spare parts
571701159939	PIPE STUB DIA 11	TATA spare parts
571701159940	BOLT M8X1.25X45	TATA spare parts
571701159941	BOLT M8X1.25X40	TATA spare parts
571701159942	ASSY OIL FILLING PLUG WITH O-RING	TATA spare parts
571701159943	ASSY. CYL. HEAD W/VALVE GUIDE & SEAT BS4	TATA spare parts
571701159945	GASKET CYLINDER HEAD 1.6MM	TATA spare parts
571701159946	GASKET CYLINDER HEAD 1.2MM	TATA spare parts
571701159947	GASKET CYLINDER HEAD 1.4MM	TATA spare parts
571701159948	GASKET CYLINDER HEAD 1.0MM	TATA spare parts
571701159949	NIPPLE THERMOSTAT BYPASS BS4	TATA spare parts
571701159950	STUD	TATA spare parts
571701159951	BRACKET	TATA spare parts
571701159952	BRACKET	TATA spare parts
571701159955	CYLINDER HEAD COVER	TATA spare parts
571701159957	SCREW	TATA spare parts
571701159958	GASKET CYLINDER HEAD BS4	TATA spare parts
571701159959	HEX BOLT CYL HEAD	TATA spare parts
571701159960	BRACKET WIRING HARNESS SUPPORT	TATA spare parts
571701169901	INJECTOR	TATA spare parts
571701169903	O RING	TATA spare parts
571701169904	CLAMP INJECTOR	TATA spare parts
571701169905	NUT INJECTOR CLAMP	TATA spare parts
571701169906	CLAMP INJECTOR	TATA spare parts
571701169907	NUT INJECTOR CLAMP	TATA spare parts
571701169908	PIN INJECTOR CLAW	TATA spare parts

571701169909	STUD	TATA spare parts
571701169910	CLAMP INJECTOR	TATA spare parts
571701169911	ASSY. FUEL INJECTOR BS4	TATA spare parts
571701170101	OMS MOUNTING BRACKET	TATA spare parts
571701170102	ASSY. OMS MOUNTING BRACKET-MAGIC IRIS	TATA spare parts
571701170103	BRACKET OIL SEPARATOR MTG	TATA spare parts
571701179901	DIPSTICK ASSY	TATA spare parts
571701179902	BREATHER PLUG ASSEMBLY	TATA spare parts
571701179903	O RING BREATHER CAP	TATA spare parts
571701179904	PLATE BREATHER PLUG	TATA spare parts
571701179905	GASKET- BREATHER PLUG ASSEMBLY	TATA spare parts
571701179906	BREATHER VALVE (DIAPHRAGM)	TATA spare parts
571701179907	WORM DRIVE NOSE CLIP	TATA spare parts
571701179908	NIPPLE	TATA spare parts
571701179909	BREATHER EXTENSION	TATA spare parts
571701179910	CLAMP	TATA spare parts
571701179911	BREATHER SERVICE KIT	TATA spare parts
571701179912	CLAMP- BREATHER PIPE	TATA spare parts
571701179913	BREATHER EXTENSION	TATA spare parts
571701179914	CLAMP	TATA spare parts
571701179915	GASKET- BREATHER PLUG ASSEMBLY	TATA spare parts
571701179917	CLAMP CTC	TATA spare parts
571701179918	CLAMP-DRAIN PIPE (OIL SEPRATOR)	TATA spare parts
571701179919	CTC CLAMP (DIA.24 - DIA.30)	TATA spare parts
571701179922	TUBE ASSY OMS TO OIL SUMP	TATA spare parts
571701179923	DIPSTICK	TATA spare parts
571701179924	HOSE OIL SEPARATOR TO MANIFOLD BS4	TATA spare parts
571701179925	HOSE CYL HEAD COVER TO OMS BS4	TATA spare parts
571701179926	HOSE OIL RETURN BS4	TATA spare parts
571701179927	CTC CLAMP 13.1	TATA spare parts
571701179928	CLAMP-INLET PIPE (FOR OD 22) BS4	TATA spare parts
571703109901	ASSY. CRANK SHAFT W/PLUG & KEYS BS2/3/4	TATA spare parts
571703109902	KEY FWE SIDE (FLYWHEEL END SIDE)	TATA spare parts
571703109903	KEY PTO SIDE	TATA spare parts
571703109904	PLUG DIA 5	TATA spare parts
571703109905	PLUG DIA 5.5	TATA spare parts
571703109906	PLUG DIA 6	TATA spare parts
571703109907	BOLT FWE SIDE	TATA spare parts
571703109908	PLAIN WASHER FOR FLYWHEEL BOLT	TATA spare parts
571703109908DF	THRUST WASHER STD-ZIP/IRIS BS3/4	TATA spare parts
571703109908DFR1	THRUST WASHER OS10-ZIP/IRIS BS3/4	TATA spare parts
571703109908DFR2	THRUST WASHER OS20-ZIP/IRIS BS3/4	TATA spare parts
571703109908DFR3	THRUST WASHER OS30-ZIP/IRIS BS3/4	TATA spare parts
571703109909	BOLT PTO SIDE	TATA spare parts
571703113701	CLUTCH FLYWHEEL	TATA spare parts
571703113801	ADAPTOR PLATE	TATA spare parts
571703119901	FLYWHEEL RING GEAR ASSEMBLY	TATA spare parts

571703119902	RING GEAR BS2/3/4	TATA spare parts
571703129901	M B BUSH (MAIN BEARING BUSH-STD)	TATA spare parts
571703129902	MAIN BEARING BUSH U/S 0.5 MM (CRANKCASE)	TATA spare parts
571703129903	MAIN BEARING BUSH U/S 1.0 MM (CRANKCASE)	TATA spare parts
571703129904	THRUST WASHER (74X53.5X2.5 THK.-FWE SIDE)	TATA spare parts
571703129905	CRANKSHAFT SUPPORT ASSY. WITH STD. BUSH	TATA spare parts
571703129906	BUSH (MAIN BEARING BUSH- STD)	TATA spare parts
571703129909	RETAINER PLATE	TATA spare parts
571703129910	RETAINER PLATE	TATA spare parts
571703129911	NUT (M8X1.25 FOR CRANKSHAFT SUPPORT)	TATA spare parts
571703129912	WASHER (16X8.1X2MM THK.)	TATA spare parts
571703129913	RELIEF VALVE ASSEMBLY	TATA spare parts
571703129914	PRESSURE RELIEF VALVE	TATA spare parts
571703129915	SPRING	TATA spare parts
571703129916	FLANGE	TATA spare parts
571703129917	BOLT PULLEY (M6X1X12L)	TATA spare parts
571703129918	JOINT 0.15MM (SHIM 0.15MM THK. FOR END C)	TATA spare parts
571703129919	JOINT 0.3MM (SHIM 0.3MM THK. FOR END COV)	TATA spare parts
571703129920	BEARING STD	TATA spare parts
571703129920DF	MAIN BEARING STD-ZIP/IRIS BS3/4	TATA spare parts
571703129920DFR3	MAIN BEARING SET-OS30 1.5MM-ZIP/IRIS BS3	TATA spare parts
571703129921	BEARING U/S 0.5 MM	TATA spare parts
571703129921DF	MAIN BEARING SET-OS10 0.5MM-ZIP/IRIS BS3	TATA spare parts
571703129922	BEARING U/S 1.0 MM	TATA spare parts
571703129922DF	MAIN BEARING SET-OS20 1MM-ZIP/IRIS BS3/4	TATA spare parts
571703129923	SET OF MAIN BEARING BUSH (STD)	TATA spare parts
571703129924	SET OF MAIN BEARING BUSH (0.5U/S)	TATA spare parts
571703129925	SET OF MAIN BEARING BUSH (1.0U/S)	TATA spare parts
571703129926	MAIN BEARING BUSH U/S 0.5 MM (FWE)	TATA spare parts
571703129927	MAIN BEARING BUSH U/S 1.0 MM (FWE)	TATA spare parts
571703129930	FLANGE	TATA spare parts
571703129931	BOLT (M6X1X12L)FOR PRESSURE RELIEF VALVE	TATA spare parts
571703129933	THRUST WASHER HALF ROUND BS4	TATA spare parts
571703129934	SUPPORT ASSY CRANKSHAFT	TATA spare parts
571703129935	SUPPORT CRANKSHAFT	TATA spare parts
571703139901	CRANK SHAFT PULLEY	TATA spare parts
571703139902	BOLT PULLEY (M6X1X20L ALLEN SCREW)	TATA spare parts
571703149901	SET-PISTON W/RINGS GRADE A BS2/3/4	TATA spare parts
571703149901DF	PISTON KIT W/RINGS W/PIN CIRCLIP-ZIP/IRI	TATA spare parts
571703149902	SET-PISTON RING BS2/3/4	TATA spare parts
571703149902DF	PISTON RING SET - ZIP/IRIS BS3/4	TATA spare parts
571703149903	PISTON PIN	TATA spare parts
571703149904	CIRCLIP PISTON	TATA spare parts
571703149906	SET-PISTON WITH PIN CIRCLIP & RING BS4	TATA spare parts
571703159901	ASSY. CONNECTING ROD BS2/3/4	TATA spare parts
571703159902	BUSH SMALL END	TATA spare parts
571703159902DF	CON ROD BUSH SET STD-ZIP/IRIS BS3/4	TATA spare parts

571703159902DFR1	CON ROD BUSH SET RS1 OS10-ZIP/IRIS BS3/4	TATA spare parts
571703159902DFR2	CON ROD BUSH SET RS2 OS20-ZIP/IRIS BS3/4	TATA spare parts
571703159902DFR3	CON ROD BUSH SET RS3 OS30-ZIP/IRIS BS3/4	TATA spare parts
571703159903	NUT (M8X1) FOR CONNECTING ROD BOLTS BS4	TATA spare parts
571703159904	BOLT BS4	TATA spare parts
571703159905	LOCK PLATE CON ROD	TATA spare parts
571703159906	BEARING LARGE END- STD BS2/3/4	TATA spare parts
571703159906DF	CON ROD BEARING SET STD-ZIP/IRIS BS3/4	TATA spare parts
571703159907	BEARING LARGE END U/S 0.25 MM	TATA spare parts
571703159907DF	CON ROD BEARING SET OS10-0.25MM-ZIP/IRIS	TATA spare parts
571703159908	BEARING LARGE END U/S 0.50 MM	TATA spare parts
571703159908DF	CON ROD BEARING SET OS20-0.50MM-ZIP/IRIS	TATA spare parts
571703159910	CONNECTING ROD LOCK PLATE	TATA spare parts
571705109901	CAMSHAFT INLET & EXHAUST BS2/3/4	TATA spare parts
571705109902	FIP CAMSHAFT ASSEMBLY BS4	TATA spare parts
571705109906	VALVE CAM SHAFT ASSEMBLY	TATA spare parts
571705109907	VALVE CAMSHAFT WITH GEAR	TATA spare parts
571705119902	TRIGGER WHEEL WITH BUSH	TATA spare parts
571705129901	VALVE INTAKE	TATA spare parts
571705129902	VALVE EXHAUST	TATA spare parts
571705129903	VALVE SET BS2/3/4	TATA spare parts
571705129904	BOTTOM SHEET FOR VALVE SPRING	TATA spare parts
571705129905	VALVE SPRING	TATA spare parts
571705129906	RETAINER ( VALVE SPRING)	TATA spare parts
571705129907	COLLETS HALF FOR VALVE	TATA spare parts
571705129908	SCREW VALVE ADJUSTING	TATA spare parts
571705129909	NUT	TATA spare parts
571705129910	VALVE SET WITH STEM SEAL	TATA spare parts
571705129913	SET-VALVES WITH STEM SEAL MULTI GROOVE	TATA spare parts
571705139901	SET-TAPPET BS2/3/4	TATA spare parts
571705139902	TAPPET ASSLY	TATA spare parts
571705149901	O RING FOR SHAFT	TATA spare parts
571705149902	ROCKER FULCRUM	TATA spare parts
571705149903	ROCKER INLET VALVE	TATA spare parts
571705149904	ROCKER LEVER EXHAUST VALVE	TATA spare parts
571705149905	ROCKER LEVER SET	TATA spare parts
571705149906	LOCK SCREW FOR FULCRUM ADJUSTING	TATA spare parts
571705149907	NUT (M6X1 FOR FULCRUM ADJUSTING SCREW)	TATA spare parts
571705149908	NUT	TATA spare parts
571705149909	SCREW LOCK FOR FULCRUM ADJUSTING	TATA spare parts
571705149910	NUT (M6X1 FOR FULCRUM ADJUSTING SCREW)	TATA spare parts
571705149911	ROCKER ARM SHAFT	TATA spare parts
571705149912	O-RING OIL PICK UP PIPE	TATA spare parts
571705149913	SCREW	TATA spare parts
571705159901	VALVE GUIDE SET STANDARD	TATA spare parts
571705159902	GUIDE INLET VALVE STD	TATA spare parts
571705159903	GUIDE EXHAUST VALVE STD	TATA spare parts

571705159904	STEM SEAL VALVE BS2/3/4	TATA spare parts
571705159904DF	OIL SEAL VALVE STEM - ZIP/IRIS BS3/4	TATA spare parts
571705159907	GASKET CYL. HEAD -1.25MM	TATA spare parts
571705169901	PUSH ROD INLET & EXHAUST	TATA spare parts
571705169902	PUSH ROD SET	TATA spare parts
571705169903	GASKET GUIDE PRT	TATA spare parts
571705169904	GUIDE PUSH ROD TUBE	TATA spare parts
571705169905	JOINT PUSH ROD SLEEVE	TATA spare parts
571705169906	TUBE PUSH ROD PROTECTION	TATA spare parts
571705169907	TUBE PUSH ROD PROTECTION	TATA spare parts
571707109901	EXTRA FUEL DEVICE ASSEMBLY	TATA spare parts
571707109902	JOINT FOR STOP PIN 0.5MM	TATA spare parts
571707109903	JOINT FOR STOP PIN 1.0MM	TATA spare parts
571707109904	MACHINED WASHER	TATA spare parts
571707109905	BOLT M6X1X16	TATA spare parts
571707109906	BRACKET ASSEMBLY & LEVER	TATA spare parts
571707109907	COLLAR BOLT M6X1X16L	TATA spare parts
571707109908	PIN ASSEMBLY FOR GOVERNOR GEAR CONSISTIN	TATA spare parts
571707109909	PIN FOR GOVERNOR GEAR	TATA spare parts
571707109911	NUT (M10X1.5)	TATA spare parts
571707109912	MACHINED WASHER (18X10X2MM THK.)	TATA spare parts
571707109913	GEAR GOVERNOR	TATA spare parts
571707109914	THRUST WASHER	TATA spare parts
571707109915	TAB WASHER	TATA spare parts
571707109916	BALL	TATA spare parts
571707109917	GOVERNOR BELL	TATA spare parts
571707109918	DISC-GOVERNOR BELL	TATA spare parts
571707109919	CIRCLIP	TATA spare parts
571707109920	COVER GOVERNOR GROUP	TATA spare parts
571707109921	FDC LEAVER & GOV. SUPPORT ASSEMBLY	TATA spare parts
571707109922	SCREW-COUNTERSUNK (M6X1X35L)	TATA spare parts
571707109923	BOLT MIN SPEED SETTING (M6X1X35L)	TATA spare parts
571707109924	SPRING LOCK WASHER (12X6.2X0.6MM THK.)	TATA spare parts
571707109925	ASSY. REMOTE SPEED HOUSING BS2/3/4	TATA spare parts
571707109926	OIL SEAL	TATA spare parts
571707109927	PIN LEVER ASSEMBLY	TATA spare parts
571707109928	WASHER	TATA spare parts
571707109929	THROTTLE LEVER ASSEMBLY	TATA spare parts
571707109930	TIE ROD	TATA spare parts
571707109931	BOLT	TATA spare parts
571707109932	COVER- SPEED CONTROL BOX	TATA spare parts
571707109933	CAP SCREW (M6X1X16L)	TATA spare parts
571707109934	BOLT MAX SPEED SETTING (M6X1X35L)	TATA spare parts
571707109935	JOINT FOR HOUSING	TATA spare parts
571707109936	LOCK WIRE WITH LEAD SEAL	TATA spare parts
571707109937	FUEL INJECTION PUMP ASSY.	TATA spare parts
571707109938	HEX SOCKET HEAD SCREW	TATA spare parts

571707109939	SPACER FOR FUEL PUMP- 2.45MM	TATA spare parts
571707109940	JOINT- FUEL PUMP 0.10MM (SHIM)	TATA spare parts
571707109941	JOINT- FUEL PUMP 0.15MM (SHIM)	TATA spare parts
571707109942	JOINT- FUEL PUMP 0.20MM (SHIM)	TATA spare parts
571707109943	JOINT- FUEL PUMP 0.25MM (SHIM)	TATA spare parts
571707109944	JOINT- FUEL PUMP 0.30MM (SHIM)	TATA spare parts
571707109945	JOINT - FUEL PUMP 0.35MM (SHIM)	TATA spare parts
571707109946	JOINT - FUEL PUMP 0.40MM (SHIM)	TATA spare parts
571707109947	JOINT - FUEL PUMP 0.50MM (SHIM)	TATA spare parts
571707109948	COUNTERSUNK HEAD SCREW WITH HEXAGON SO	TATA spare parts
571707109949	CAP SCREW	TATA spare parts
571707109950	TDC MATCHING PLATE	TATA spare parts
571707109951	ASSY. EXTRA FUEL DEVICE BS2/3/4	TATA spare parts
571707109952	CAP SCREW M8X1.25X30	TATA spare parts
571707109953	EXCESS FUEL AND STOP BRACKET	TATA spare parts
571707109954	BOLT MAX SPEED SETTING (M6X1X50L)	TATA spare parts
571707109955	LEVER INTERNAL	TATA spare parts
571707109956	PIN THROTTLE LEVER PIVOT (TAPER PIN)	TATA spare parts
571707109958	BRACKET STOP AND EXCESS FUEL	TATA spare parts
571707109959	NUT (M10X1.5)	TATA spare parts
571707109960	BOLT M6X1X16	TATA spare parts
571707109961	SCREW -COUNTERSUNK (M6X1X35L)	TATA spare parts
571707109962	HEX SCREW M6X35 (M6X1X35L)	TATA spare parts
571707109963	BOLT	TATA spare parts
571707109964	COVER - SPEED CONTROL BOX	TATA spare parts
571707109965	BOLT MAX SPEED SETTING (M6X1X50L)	TATA spare parts
571707109966	SPACER FOR FUEL PUMP 2 MM THK	TATA spare parts
571707109967	PLATE TDC MATCHING	TATA spare parts
571707109968	SPACER FOR FUEL PUMP 2.45 MM	TATA spare parts
571707109969	SHIM JOINT FUEL PUMP 0.30 MM	TATA spare parts
571707109970	SHIM JOINT FUEL PUMP 0.50 MM	TATA spare parts
571707109974	STUD	TATA spare parts
571707109975	SHIM BS4	TATA spare parts
571707109976	ROLLER TAPPET	TATA spare parts
571707109977	HIGH PRESSURE PUMP BS4	TATA spare parts
571707109978	FLANGE FIP MTG	TATA spare parts
571707109979	SLEEVE	TATA spare parts
571707139901	CAMSHAFT FIP	TATA spare parts
571707149901	FUEL PIPE- PUMP TO INJECTOR	TATA spare parts
571707149902	BANJO BOLT M6X1X13L	TATA spare parts
571707149903	SPACER FOR LEAK OFF PIPE	TATA spare parts
571707149904	BANJO BOLT M6X1X13.5L	TATA spare parts
571707149905	HP PIPE ASSEMBLY	TATA spare parts
571707149906	FUEL OVERFLOW PIPE (PUMP TO INJECTOR)	TATA spare parts
571707149907	FUEL OVERFLOW PIPE (FEED PUMP TO INJECTO	TATA spare parts
571707149908	BANJO BOLT M6X1X13L	TATA spare parts
571707149909	BANJO BOLT M6X1X13.5L	TATA spare parts



571707149910	CLAMP -FUEL OVER FLOW PIPE	TATA spare parts
571707149911	Y CONNECTOR BS4	TATA spare parts
571707149912	M6X14 HEX HEAD FLANGE BOLT	TATA spare parts
571707149913	ASSY. FUEL DISTRIBUTION BLOCK BS4	TATA spare parts
571707149914	BRACKET	TATA spare parts
571707149915	LEAK OFF PIPE BS4	TATA spare parts
571707149916	CLAMP (CTC) OD11 BS4	TATA spare parts
571707149917	PIPE HP LINE BS4	TATA spare parts
571707149918	HIGH PRESSURE PIPE PUMP TO FDB BS4	TATA spare parts
571707149919	FUEL RETURN LINE (INJECTOR) BS4	TATA spare parts
571709109901	PIN FEED PUMP	TATA spare parts
571709109902	JOINT 0.25 MM THK. (GASKET)	TATA spare parts
571709109903	FUEL FEED PUMP BS2/3/4	TATA spare parts
571709109904	NUT	TATA spare parts
571709109905	JOINT- 0.4MM THK. (GASKET)	TATA spare parts
571709109906	JOINT- 0.5MM THK. (GASKET)	TATA spare parts
571709109907	JOINT- 0.8MM THK. (GASKET)	TATA spare parts
571709110101	ASSY FUEL FILTER	TATA spare parts
571709110102	FILTER ASSEMBLY	TATA spare parts
571709110106	FUEL CONTROL UNIT MOUNTING BRACKET	TATA spare parts
571709110109	BRACKET FUEL FILTER MTG A CLASS IRIS	TATA spare parts
571709129901	FUEL PIPE FEED PUMP TO FUEL INJECTION	TATA spare parts
571709129902	M10 BANJO BOLTX22L	TATA spare parts
571709129903	BANJO BOLT M12X1.5X24L	TATA spare parts
571709129904	BANJO BOLT M8X1.25X16L	TATA spare parts
571709129905	BANJO BOLT M12X1.5X24L	TATA spare parts
571709129906	BANJO BOLT M12X1.5X24L	TATA spare parts
571709129907	PIPE-FEED PUMP TO FUEL PUMP	TATA spare parts
571709129908	BANJO BOLT	TATA spare parts
571709129909	BANJO BOLT M10X22L	TATA spare parts
571709129910	BANJO BOLT M12X1.5X24L	TATA spare parts
571709129911	BANJO BOLT M8X1.25X16L	TATA spare parts
571709129912	BANJO BOLT M12X1.5	TATA spare parts
571709129913	PIPE -FEED PUMP TO FIP (SANTOP MAT)BS2-4	TATA spare parts
571709129914	FIP INLET PIPE-PA12 (FCU TO HP PUMP) BS4	TATA spare parts
571709130102	ASSY. AIR CLEANER ELEMENT BS2/3/4	TATA spare parts
571709130110	AIR CLEANER ASSY.	TATA spare parts
571709130116	ASSY. SNORKEL	TATA spare parts
571709130117	ASSY. AIR INTAKE SYSTEM KIT	TATA spare parts
571709130121	AIR CLEANER ASSY.(WITHOUT AIR FILTER)	TATA spare parts
571709130122	BRACKET MOUNTING ASSY.	TATA spare parts
571709130123	ASSY. AIR-INTAKE SYSTEM	TATA spare parts
571709130125	BRACKET ASSY	TATA spare parts
571709130127	AIR CLEANER ASSY	TATA spare parts
571709130129	ASSY CLEAN SIDE HOSE (BSIV)	TATA spare parts
571709130130	CLAMP ASSY.	TATA spare parts
571709130131	HOSE CLAMP-CONSTANT TORQUE	TATA spare parts

571709130132	ASSY. AIR FILTER INTEGRAL BS2/3/4	TATA spare parts
571709130136	AIR FILTER ASSY COMPLETE INTEGRAL KIT	TATA spare parts
571709130137	AIR CLEANER ASSY INTEGRAL KIT (BS-IV)	TATA spare parts
571709134201	HOSE CLAMP-CONSTANT TORQUE	TATA spare parts
571709134205	HOSE CLAMP; T BOLT	TATA spare parts
571709135804	HOSE (AIR CLEANER-INT MANIFOLD) BS2/3/4	TATA spare parts
571709135808	EJECTOR VALVE	TATA spare parts
571709135809	HOSE-PLASTIC PIPE TO LONG MEMBER ELBOW	TATA spare parts
571709135810	SLEEVE RUBBER	TATA spare parts
571709137706	PIPE-PLASTIC	TATA spare parts
571709138202	BRACKET (CLEAN SIDE HOSE SUPPORT)	TATA spare parts
571709139901	AIR INTAKE SYSTEM RETRO KIT	TATA spare parts
571709139902	ASSY.TOP SIDE TEMPLETE RETRO FITMENT	TATA spare parts
571709139903	BOTTOM SIDE TEMPLETE RETRO FITMENT	TATA spare parts
571714109901	AIR INTAKE MANIFOLDS	TATA spare parts
571714109902	GASKET INLET MANIFOLDS	TATA spare parts
571714109904	GASKET INTAKE MANIFOLD BS4	TATA spare parts
571714109905	GASKET EGR TUBE TO INTAKE MANIFOLD BS4	TATA spare parts
571714109906	BRACKET WIRING HARNESS MTG	TATA spare parts
571714109907	AIR INTAKE MANIFOLD	TATA spare parts
571714119901	EXHAUST MANIFOLDS	TATA spare parts
571714119902	GASKET EXHAUST MANIFOLDS	TATA spare parts
571714119903	NUT (M8X1.25)	TATA spare parts
571714119904	GASKET CYLINDER HEAD PORT	TATA spare parts
571714119905	EXHAUST MANIFOLD	TATA spare parts
571714119906	EGR VALVE BS4	TATA spare parts
571714119907	GASKET EGR VALVE INTAKE BS4	TATA spare parts
571714119908	GASKET EGR VALVE ELBOW BS4	TATA spare parts
571714119909	ADAPTER EGR VALVE MTG BS4	TATA spare parts
571714119910	HEX HEAD FLANGE BOLT M8 X 20	TATA spare parts
571714119911	HEX FLANGE HEAD CAP SCREW	TATA spare parts
571714119912	GASKET (INTAKE FLANGE-EGR VALVE) BS4	TATA spare parts
571714119913	BRACKET VACUUM MODULATOR	TATA spare parts
571714119915	PIPE VACUUM MODULATOR TO EGR VALVE BS4	TATA spare parts
571714119916	PIPE VACUUM PUMP TO VACUUM MODULATOR	TATA spare parts
571714119917	VACUUM MODULATOR ASSY BS4	TATA spare parts
571714700102	GUARD ASSY EGR COOLER	TATA spare parts
571714703301	BRACKET EGR COOLER MTG	TATA spare parts
571714709901	ASSY. EGR PIPE W/EGR COOLER FLANGE BS4	TATA spare parts
571714709902	GASKET EGR COOLER TO EGR PIPE BS4	TATA spare parts
571714709903	M8X16-HEX HEAD FLANGE BOLT	TATA spare parts
571714709904	EGR COOLER BS4	TATA spare parts
571714709905	HOSE EGR COOLER INTAKE BS4	TATA spare parts
571714709906	HOSE EGR COOLER OUTLET BS4	TATA spare parts
571714709907	CLAMP(CTC)(OD-19MM)	TATA spare parts
571715146301	COGGED BELT	TATA spare parts
571715146302	COGGED BELT BS2/3/4	TATA spare parts

571715149901	TENSIONER LEVER	TATA spare parts
571715149902	BOLT M8X35	TATA spare parts
571715149903	BRACKET ALTERNATOR MOUNTING (D-22886)	TATA spare parts
571715149904	LEVER TENSIONER	TATA spare parts
571715149905	BOLT M8X35	TATA spare parts
571715149906	BRACKET ALTERNATOR	TATA spare parts
571715149907	HEX HEAD FLANGE BOLT M8X1.25X110	TATA spare parts
571715149908	TENSIONER PLATE	TATA spare parts
571715189901	GLOW PLUG BS4 ZIP IRIS	TATA spare parts
571715189901DF	GLOW PLUG - -ZIP/IRIS BS3/4	TATA spare parts
571715200101	CONTAINER (ECU WITH SOFTWARE) BS4	TATA spare parts
571718109901	LUB OIL PUMP ASSEMBLY	TATA spare parts
571718109902	GEAR OIL PUMP	TATA spare parts
571718109903	NUT M8X 1.25 FOR LUB. OIL PUMP	TATA spare parts
571718109904	CAP SCREW (M6X1X30L ALLEN SCREW) FOR LUB	TATA spare parts
571718109905	CAP SCREW (11X6.4X0.5MM THK.) FOR LUB OI	TATA spare parts
571718109906	SPRING WASHER M6 FOR WATER PUMP (11X6.4X	TATA spare parts
571718109907	OIL PUMP LUB (NUT M8X1.25)	TATA spare parts
571718109908	CAP SCR (M6X1X30L) FOR LUB OIL PUMP	TATA spare parts
571718109909	OIL PUMP ASSY	TATA spare parts
571718109910	PRESSURE RELEIF VALVE BS4	TATA spare parts
571718109911	SPRING RETAINER ASSY BS4	TATA spare parts
571718109912	CIRCLIP RELIEF VALVE BS4	TATA spare parts
571718139901	ADAPTOR LUB OIL FILTER	TATA spare parts
571718139902	JOINT ADAPTER (GASKET 0.5MM THK.)	TATA spare parts
571718139903	STUD FOR SPIN ON	TATA spare parts
571718139904	OIL FILTER ELEMENT (SPINON) BS2/3/4	TATA spare parts
571718139904DF	OIL FILTER ELEMENT - ZIP/IRIS	TATA spare parts
571718139905	HEX SCREW (M8X1.25X20L)	TATA spare parts
571718139906	BOLT FOR PRESSURE GUAGE (M8X1.25X12L)	TATA spare parts
571718139907	JOINT FOR M8 (WASHER 12X8.1X1MM THK.- PH	TATA spare parts
571718139908	PIPE - FWE POSITIVE LUBRICATION	TATA spare parts
571718139909	BANJO BOLT M8X1.25X20L	TATA spare parts
571718139910	TUBE ROCKER LUBRICATION	TATA spare parts
571718139911	BANJO BOLT M6X1 FOR ROCKER LUBRICATION	TATA spare parts
571718139912	JOINT (WASHER 10X6.1X1MM PHOS.BRONZ BS4	TATA spare parts
571718139913	OIL RETURN PIPE CYLINDER HEAD TO CRANKC	TATA spare parts
571718139914	BANJO BOLT OIL RETURN (M12X1.5X24L)	TATA spare parts
571718139915	JOINT (WASHER 17X12.1X1.5MM PHOS.BR BS4	TATA spare parts
571718139916	PIPE OIL RETURN	TATA spare parts
571718139917	TUBE ROCKER LUBRICATION	TATA spare parts
571718139918	PIPE - FEW POSITIVE LUBRICATION W/C ENGI	TATA spare parts
571718139919	ADAPTER JOINT (GASKET 0.5 MM THK)	TATA spare parts
571718139920	HEX SCREW (M8X1.25X20L)	TATA spare parts
571718139921	BOLT FOR PRESSURE GAUGE (M8X1.25X12L)	TATA spare parts
571718139922	BANJO BOLT M8X1.25X20L	TATA spare parts
571718139923	BANJO BOLT M6X1 FOR ROCKER LUBRICATION	TATA spare parts

571718139924	BANJO BOLT OIL RETURN (M12X1.5X24L)	TATA spare parts
571718159901	OIL SUCTION TUBE	TATA spare parts
571718159902	BANJO BOLT (M10X1.5 FOR OIL INTAKE)	TATA spare parts
571718159903	JOINT (WASHER- 16X10.1X1MM THK. FOR OIL	TATA spare parts
571718159904	LOCK PLATE	TATA spare parts
571718159905	OIL STRAINER WITH INTAKE TUBE ASSEMBLY	TATA spare parts
571718159909	STRAINER ASSY BS4	TATA spare parts
571718169901	PIPE BS4	TATA spare parts
571718169902	BANJO BOLT BS4	TATA spare parts
571718169903	PIPE OIL RETURN BS4	TATA spare parts
571718169904	COPPER WASHER M16	TATA spare parts
571718169905	BANJO BOLT M16X1.5 BS4	TATA spare parts
571718169906	PIPE ASSY BS4	TATA spare parts
571718169907	PIPE ASSY OIL SUPPLY	TATA spare parts
571718169908	BANJO BOLT	TATA spare parts
571718169909	PIPE BS4	TATA spare parts
571718169910	BANJO BOLT M10X1.5(ON VACUUM PUMP) BS4	TATA spare parts
571718169911	PIPE ASSY OIL RETURN BS4	TATA spare parts
571720109901	CASING WATER PUMP	TATA spare parts
571720109902	GASKET FOR CASING WATER PUMP (0.5MM THK)	TATA spare parts
571720109903	WATER PUMP ASSEMBLY (WITH LIQUID SEALANT	TATA spare parts
571720109904	BOLT M6X1 FOR WATER PUMP (M6X1X20L)	TATA spare parts
571720109905	PULLEY WATER PUMP	TATA spare parts
571720109906	SCREW FOR PUMP FIXING (M8X1X30L ALLEN SC	TATA spare parts
571720109907	WATER PUMP ASSY. (WITH BLEEDING SCREW)	TATA spare parts
571720109908	BOLT M6X1 FOR WATER PUMP (M6X1X20L)	TATA spare parts
571720109911	WATER PUMP FRONT HSG BS2/3/4	TATA spare parts
571720109912	ASSY. WATER PUMP BS2/3/4	TATA spare parts
571720109913	ASSY. WATER PUMP BS4	TATA spare parts
571720109914	BRACKET WIRING HARNESS-WATER PUMP	TATA spare parts
571720125802	HOSE- WATER BYPASS TUBE (W/INTEGRAL THER	TATA spare parts
571720129902	THERMOSTAT COVER	TATA spare parts
571720129903	ASSY. THERMOSTAT BS2/3/4	TATA spare parts
571720129904	THERMOSTAT COVER	TATA spare parts
571720129905	BOLT COLLAR (M6)	TATA spare parts
571720129906	THERMOSTAT HOUSING BS4	TATA spare parts
571720129907	THERMOSTAT GASKET (O RING) BS4	TATA spare parts
571720129908	M6X20 HEX HEAD FLANGE BOLT	TATA spare parts
571720129909	THERMOSTAT ASSY BS4	TATA spare parts
571722109901	ENGINE LIFTING HOOK	TATA spare parts
571722109902	ENGINE LIFTING HOOK	TATA spare parts
571722123701	ENGINE MOUNTING ARM (MOUNT 'A')	TATA spare parts
571722123702	ENGINE MOUNTING BRACKET	TATA spare parts
571722123704	BRACKET-'D'MOUNT & SILENCER	TATA spare parts
571722123705	ENGINE MOUNTING BRACKET (A MOUNT)	TATA spare parts
571724100101	ASSY.ENGINE MOUNT-A (FRONT)	TATA spare parts
571724200101	ASSY. B-MOUNT RR MIDDLE (ENGINE) BS2/3/4	TATA spare parts

571724200102	ASSY.ENGINE MOUNT-C(REAR LEFT)	TATA spare parts
571724200103	ASSY.ENGINE MOUNT-D(REAR RIGHT)	TATA spare parts
571724200104	ASSY. C-MOUNT ENGINE (FRONT)	TATA spare parts
571724200105	ASSY. D-MOUNT ENGINE (REAR)	TATA spare parts
571724203201	HEX FL BOLT M10X1X95 12.9 PROPERTY CLASS	TATA spare parts
571749100104	ASSY. CATALYTIC CONVERTER COMPLETE(METAL	TATA spare parts
571749100105	ASSY. CATALYTIC CONVERTER COMPLETE (CERA	TATA spare parts
571749100112	CATCON ASSY	TATA spare parts
571749100115	ASSY. CATCON BS4	TATA spare parts
571749101602	ASSY. CATALYTIC CONVERTER COMPLETE	TATA spare parts
571750100104	ASSY. FAN MOTOR & SHROUD BS2/3/4	TATA spare parts
571750100106	ASSY. RADIATOR G600W BS3/4	TATA spare parts
571750100109	ASSY. RADIATOR BS2/3/4	TATA spare parts
571750100112	CLAMP-LCL MOUNTING	TATA spare parts
571750100113	ASSY. NO LOSS TANK W/CAP BS2/3/4	TATA spare parts
571750100114	ASSY.RADIATOR WITH DEFLECTOR	TATA spare parts
571750100115	ASSY.INTERMEDIATE PIPE (LOWER COOLING LI	TATA spare parts
571750100116	ASSY.INTERMEDIATE PIPE & BRACKET(BSIV)	TATA spare parts
571750100119	ASSY. CLAMP LCL MOUNTING (BSIV)	TATA spare parts
571750100128	RADIATOR ASSY WITH FAN MOTOR & SHROUD	TATA spare parts
571750100129	RADIATOR WITHOUT FAN MOTOR & SHROUD	TATA spare parts
571750100129DF	RADIATOR ASSY - -ZIP/IRIS BS3/4	TATA spare parts
571750105801	HOSE - UPPER COOLING LINE - GC WATER OUT	TATA spare parts
571750105806	HOSE-WATER PUMP TO INTERMEDIATE PIPE)	TATA spare parts
571750105808	LOWER COOLING LINE BS2/3/4	TATA spare parts
571750105809	RADIATOR DEFLECTOR	TATA spare parts
571750105810	LOWER COOLING LINE (BSIV)	TATA spare parts
571750105812	HOSE COOLANT ENGINE TO RADIATOR	TATA spare parts
571750106901	HOSE - NO LOSS TANK ( RADIATOR TO NO LOS	TATA spare parts
571750106902	HOSE - NO LOSS TANK ( RADIATOR TO NO LOS	TATA spare parts
571750106903	HOSE - NO LOSS TANK ( SPILL OVER HOSE )(	TATA spare parts
571750107703	RADIATOR GUARD	TATA spare parts
571750108201	CLAMP (NO LOSS TANK SPILL OVER HOSE)	TATA spare parts
571750109901	AIR BLEEDING SCREW	TATA spare parts
571750109902	AIR BLEEDING SCREW	TATA spare parts
571750109903	SCREW AIR BLEEDING	TATA spare parts
571785899017	EXPANSION PLUG	TATA spare parts
571801103701	MAIN BEARING CAP (NON THRUST) BS6	TATA spare parts
571801103702	MAIN BEARING CAP (THRUST) BS6	TATA spare parts
571803123128	MAIN&BEARING&LOWER&(GRADE&L) BS6	TATA spare parts
571803123129	MAIN&BEARING&LOWER&(GRADE&N) BS6	TATA spare parts
571803123130	MAIN&BEARING&LOWER&(GRADE&M) BS6	TATA spare parts
571803123134	MAIN&BEARING&UPPER&(SLOT))-L& BS6	TATA spare parts
571803123135	MAIN&BEARING&UPPER&(SLOT))-N& BS6	TATA spare parts
571803123136	MAIN&BEARING&UPPER&(SLOT))-M& BS6	TATA spare parts
571803150104	ASSY. CONNECTING ROD WITH CAP & BOLT BS6	TATA spare parts
571803153410	BEARING&HALF&CON&ROD&(GRADE&L) BS6	TATA spare parts

571803153411	BEARING½HALF½CON½ROD½(GRADE½N) BS6	TATA spare parts
571803153412	BEARING½HALF½CON½ROD½(GRADE½M) BS6	TATA spare parts
571805104102	CAM SHAFT BEARING CAP NO. 2 BS6	TATA spare parts
571805104103	CAM SHAFT BEARING CAP NO. 3 BS6	TATA spare parts
571814100102	ASSY.ISOLATOR (FOR THROTTLE SUPPORT)	TATA spare parts
571815209901	FUEL INJECTOR (EV14) BS6	TATA spare parts
571815209908	SPARK PLUG BS6	TATA spare parts
571909130121	AIR CLEANER ASSY	TATA spare parts
571909130121AE	AIR CLEANER ASSY 1628	TATA spare parts
571909130122	HOSE HUMP	TATA spare parts
571909130122AE	HOSE HUMP 1628	TATA spare parts
571909130123	DUCT ASSY AIR INTAKE	TATA spare parts
571909130124	STRAIGHT HOSE	TATA spare parts
571909130124AE	STRAIGHT HOSE 1628	TATA spare parts
571909130126	BRACKET ASSY-BOTTOM AIR INTAKE DUCT MT	TATA spare parts
571909130127	BRACKET ASSY-TOP AIR INTAKE DUCT MTG (	TATA spare parts
571909130130	ELEMENT - PRIMARY BS3/4	TATA spare parts
571909130130AE	ELEMENT - PRIMARY 1628 1828	TATA spare parts
571909130131	ELEMENT - SAFETY (FLEETGUARD) BS3/4	TATA spare parts
571909130131AE	ELEMENT - SAFETY 1628 1828	TATA spare parts
571909130142	AIR FILTER MOUNTING BRACKET	TATA spare parts
571918139916	OIL RETURN PIPE CYLINDER½ HEAD TO CRANKC	TATA spare parts
571918139917	TUBE ROCKER LUBRICATION	TATA spare parts
571918139918	PIPE - FWE POSITIVE OIL LUBRICATION	TATA spare parts
572100000102	ASSY.ENGINE COMPLETE(BS-IV)CNG	TATA spare parts
572101010101	BARE ENGINE	TATA spare parts
572101019901	SET OF JOINTS ( IT INCLUDES FOLLOWING )	TATA spare parts
572101019902	PARTIAL OVERHAUL KIT	TATA spare parts
572101019903	TOTAL OVERHAUL KIT	TATA spare parts
572101109901	PTO COVER ASSEMBLY	TATA spare parts
572101109902	CRANKCASE ASSY. WITH STANDARD BUSH & DOW	TATA spare parts
572101109903	CLAMP-PTO TOP	TATA spare parts
572101109904	CLAMP-PTO BOTTOM	TATA spare parts
572101109905	STARTER MOUNTING PLATE	TATA spare parts
572101109906	PISTON ASSEMBLY & BARREL KIT	TATA spare parts
572101109907	HEX HEAD FLANGE BOLT M8X1.25X12	TATA spare parts
572101109908	SET OF OIL SEALS (0.5U/S)	TATA spare parts
572101109909	SET OF OIL SEALS (1.0U/S)	TATA spare parts
572101109910	PTO COVER WITH GRUB SCREW	TATA spare parts
572101159901	CYLINDER HEAD ASSLY	TATA spare parts
572101159904	ROCKER COVER ASSEMBLY	TATA spare parts
572101159905	SET OF VALVE SEAT (STD)	TATA spare parts
572101159906	CORE PLUG (18 DIA.)	TATA spare parts
572101159907	O-RING FOR OIL FILLING CAP	TATA spare parts
572101159908	OIL FILLING CAP	TATA spare parts
572101159909	COLLAR NUTM6X1	TATA spare parts
572101175801	HOSE - BLOW BY (MAGIC IRIS)	TATA spare parts

572101175802	HOSE-BLOWBY (ACE ZIP)	TATA spare parts
572101179901	HOSE-OMS IN	TATA spare parts
572101179902	HOSE-OMS OIL RETURN	TATA spare parts
572101179903	PLATE ASSEMBLY-OMS	TATA spare parts
572101179904	CTC CALMP	TATA spare parts
572103119901	FLYWHEEL ASSY.WITH RING GEAR AND TONE WH	TATA spare parts
572103119902	FLYWHEEL ASSY.WITH RING GEAR	TATA spare parts
572103119903	TONE WHEEL	TATA spare parts
572103119904	HEX HEAD FLANGE BOLT (M6X1X30TL) FOR TON	TATA spare parts
572103129901	BEARING LARGE END- STD	TATA spare parts
572103129902	BEARING LARGE END U/S 0.25 MM	TATA spare parts
572103129903	BEARING LARGE END U/S 0.5 MM	TATA spare parts
572103149902	PISTON ASSEMBLY WITH RING SET PISTON PIN	TATA spare parts
572105109901	CAMSHAFT INLET & EXHAUST	TATA spare parts
572105129903	VALVE SET WITH STEM SEAL BS4	TATA spare parts
572105129904	COLLETS HALF FOR VALVE (MULTI-GROOVE)	TATA spare parts
572105129905	SCREW VALVE ADJUSTING M7X0.75	TATA spare parts
572105129906	VALVE SPRING BS4	TATA spare parts
572105129907	RETAINER TOP - VALVE SPRING	TATA spare parts
572105129908	BOTTOM SHEET FOR VALVE SPRING BS4	TATA spare parts
572105139901	SET-TAPPET ASSY BS4	TATA spare parts
572105149901	ROCKER LEVER SET	TATA spare parts
572105149902	NUT M7X0.75	TATA spare parts
572105159901	VALVE GUIDE SET (STD)	TATA spare parts
572105159902	SEAL VALVE STEM DOUBLE LIP BS4	TATA spare parts
572105169901	JOINT- PUSH ROD SLEEVE (BLACK COLOUR)	TATA spare parts
572105169902	SET-PUSH ROD BS4	TATA spare parts
572109130104	ASSY.HOSE (AIR CLEANER TO THROTTLE BODY)	TATA spare parts
572109130107	ASSY.AIR INTAKE SYSTEM	TATA spare parts
572109130108	AIR CLEANER ASSY	TATA spare parts
572109130111	HOSE REDUCER WITH HUMP	TATA spare parts
572109130112	SNORKEL ASSY WITH FLAP	TATA spare parts
572109130116	AIR FILTER ASSY WITH SNORKEL -INT ZIP	TATA spare parts
572109130117	AIR CLEANER ASSY KIT(INTEGRAL)-ZIP	TATA spare parts
572109134201	HOSE CLAMP-CONSTANT TORQUE	TATA spare parts
572109137701	PIPE-PLASTIC	TATA spare parts
572109138201	SUPPORT PLATE(CLEAN SIDE HOSE TO AIR FIL	TATA spare parts
572114109901	INTAKE MANIFOLD	TATA spare parts
572114109902	GASKET INTAKE	TATA spare parts
572114109903	STUD M10X1.5X23	TATA spare parts
572114109904	COLLAR NUT M10X1.5	TATA spare parts
572114110101	BRACKET ASSY CLOSE COUPLED CATCON MTG	TATA spare parts
572114119901	MANIFOLD-EXHAUST	TATA spare parts
572114119902	GASKET EXHAUST	TATA spare parts
572114119903	HEAT SHIELD	TATA spare parts
572114119904	SPRING-HEAT SHIELD	TATA spare parts
572115149901	ALTERNATOR MOUNTING BRACKET	TATA spare parts

572115149902	SPRING WASHER	TATA spare parts
572115200102	ECU WITH SOFTWARE - IRIS CNG	TATA spare parts
572115200103	CONTAINER ASSY (ECU WITH SOFTWARE)	TATA spare parts
572115209902	GASKET- ELECTRONIC THROTTLE BODY	TATA spare parts
572115209903	STUD M6X1X46	TATA spare parts
572115209904	CLAMP-ROCKER COVER	TATA spare parts
572115209905	O-RING-CRANK SENSOR	TATA spare parts
572115209906	COLLAR BOLT M6X1X12 FOR CLAMPS	TATA spare parts
572115219901	INJECTOR HOLDER	TATA spare parts
572115219902	INJECTOR CLAMP	TATA spare parts
572115219903	CONNECTOR-CNG	TATA spare parts
572115219904	CLAMP	TATA spare parts
572115219905	O-RING (INJECTOR-MANIFOLD SIDE)	TATA spare parts
572115219906	O-RING (INJECTOR-FUEL RAIL SIDE)	TATA spare parts
572115219907	HEX HEAD FLANGE BOLT M6X20	TATA spare parts
572115219908	HEX. HEAD SCREAW M5X0.8	TATA spare parts
572120109901	ASSY. WATER PUMP W/BLEEDING SCREW BS4	TATA spare parts
572120109902	FUR CLIP	TATA spare parts
572149100101	ASSY.CATCON CLOSE COUPLE METALLIC	TATA spare parts
572149100102	ASSY.CATCON UNDER BODY METALLIC ECOCAT	TATA spare parts
572149100103	CATCON ASSY	TATA spare parts
572150100101	ASSY.RADIATOR COMPLETE	TATA spare parts
572150100102	ASSY.PIPE LOWER COOLING LINE	TATA spare parts
572150100103	ASSY.PIPE UPPER COOLING LINE	TATA spare parts
572150100106	RADIATOR ASSY.	TATA spare parts
572150100108	ASSY.RADIATOR COMPLETE WITH DEFLECTOR	TATA spare parts
572150100111	ASSY.FAN;MOTOR AND SHROUD	TATA spare parts
572150100113	UPPER COOLING LINE PIPE ASSY.	TATA spare parts
572150100114	LOWER COOLING LINE PIPE ASSY.	TATA spare parts
572150100116	ASSY. RADIATOR COMPLETE	TATA spare parts
572150100119	INTEGRAL MOULDED HOSE	TATA spare parts
572150105801	HOSE UPPER COOLING LINE(UCL PIPE TO THER	TATA spare parts
572150105802	HOSE LOWER COOLING LINE(LCL PIPE TO INTE	TATA spare parts
572150105804	UPPER COOLING HOSE (RAD TO UPPER COOLING	TATA spare parts
572150108201	GAURD-ASSY. LCL PIPE	TATA spare parts
572301000107	ENGINE ISXE 600 HP EU-III	TATA spare parts
572301106801	COUPLING NUT	TATA spare parts
572301995801	HOSE PLAIN	TATA spare parts
572301995802	HOSE FLEXIBLE	TATA spare parts
572301997701	SEAL RECTANGULAR RING	TATA spare parts
572301997702	SEAL RECTANGULAR RING	TATA spare parts
572305995301	GASKET VALVE COVER	TATA spare parts
572309110101	FUEL FILTER ASSY WITH HEATER	TATA spare parts
572309130140	AIR FILTER ASSY 16 IN	TATA spare parts
572309130152	SCAVENGE BLOWER ASSY	TATA spare parts
572309130157	SET-AIR INTAKE SYSTEM	TATA spare parts
572309139906	SERVICE INDICATOR	TATA spare parts



57230999901	HEAD FUEL FILTER	TATA spare parts
57230999902	FILTER FUEL	TATA spare parts
572313990101	COMPRESSOR AIR	TATA spare parts
572314993701	MANIFOLD EXHAUST (CENTER PIECE)	TATA spare parts
572314993702	EXHAUST MANIFOLD (SIDE PIECE)	TATA spare parts
572314995301	GASKET EXHAUST MANIFOLD	TATA spare parts
572314995302	GASKET EXHAUST MANIFOLD TO TURBO	TATA spare parts
572314995303	TURBOCHARGER GASKET	TATA spare parts
572314995306	GASKET OIL DRAIN	TATA spare parts
572315140102	TENSIONER ASSY. (ALTERNATOR DRIVE)	TATA spare parts
572315146301	BELT 10PK (ALTERNATOR DRIVE)	TATA spare parts
572315990101	MOTOR STARTING	TATA spare parts
572315990102	CONNECTOR KIT 4 PIN	TATA spare parts
572315990103	AMP CONNECTOR KIT	TATA spare parts
572315999901	SOLENOID COIL FOR VPL VALVES	TATA spare parts
572318999902	CARTRIDGE LUB OIL FILTER	TATA spare parts
572320126801	COUPLING PLAIN HOSE	TATA spare parts
572320140109	HYDROSTATIC MOTOR ASSY	TATA spare parts
572320140110	HYD PUMP ASSY FAN DRIVE	TATA spare parts
572320140114	BLOCK	TATA spare parts
572320159904	HYD RESERVOIR ASSY FAN DRIVE	TATA spare parts
572320990101	PUMP WATER	TATA spare parts
572320990102	SEAL KIT FOR CYLINDER	TATA spare parts
572320990103	INLET SEAL KIT	TATA spare parts
572320990104	WORK SEGMENT SEAL KIT	TATA spare parts
572320990105	SEAL KIT FOR TF MOTOR	TATA spare parts
572320990106	SEAL KIT FOR TANDEM GEAR PUMP	TATA spare parts
572320996301	WATER PUMP BELT	TATA spare parts
572320996302	BELT V RIBBED	TATA spare parts
572320997701	SEAL THERMOSTAT	TATA spare parts
572320999903	THERMOSTAT	TATA spare parts
572320999904	TENSIONER BELT	TATA spare parts
572320999905	TENSIONER BELT	TATA spare parts
572320999907	FILTER ELEMENT	TATA spare parts
572320999908	WEATHER PACK CONNECTOR	TATA spare parts
572350100121	ENGINE COOLING SYSTEM (PACKAGE)	TATA spare parts
572350999901	PRESSURE REDUCING VALVE FOR VAL VALVE	TATA spare parts
572400000177	ASSY.ENG.W/O CLUTCH INTRA 1300 1.5L BS6	TATA spare parts
572400000181	ASSY.ENG.W/O CLUTCH INTRA 1300 1.5L BS6	TATA spare parts
572400000184	ASSY.ENG.W/O CLUTCH INTRA 1300 1.5L BS6	TATA spare parts
572400000187	ASSY.ENG.W/O CLUTCH INTRA 1500 1.5L BS6	TATA spare parts
572400000208	ENGINE ASSY W/O CLUTCH 1.5L BS6-PH2 BS6-	TATA spare parts
572400000209	ASSY.ENG.W/O CLUTCH INTRA 1300 1.5L BS6-	TATA spare parts
572400000211	ASSY.ENG.W/O CLUTCH INTRA 1500 1.5L BS6-	TATA spare parts
572401100112	BRACKET ASSY COMMON RAIL MTGBS6	TATA spare parts
572401100115	CYLINDER CRANKCASE ASSY BS6	TATA spare parts
572401130107	OIL SUMP ASSY WITH DRAIN PLUG BS6	TATA spare parts

572401133804	LADDER FRAME BS6-PH2	TATA spare parts
572401140105	TIMING COVER ASSY,BACK	TATA spare parts
572401140108	TIMING COVER ASSY FRONT BS6	TATA spare parts
572401140115	TIMING COVER ASSY BACK BS6-PH2	TATA spare parts
572401146701	PIN	TATA spare parts
572401150111	CYLINDER HEAD ASSY W/O VALVES	TATA spare parts
572401150114	COVER ASSY,CYLINDER HEAD	TATA spare parts
572401155304	GASKET,CYL HEAD (1.3 THK)	TATA spare parts
572401155305	GASKET,CYL HEAD (1.4 THK)	TATA spare parts
572401155306	GASKET,CYL HEAD (1.5 THK)	TATA spare parts
572401155307	GASKET CYL HEAD COVER BS6	TATA spare parts
572401157701	CAP,OIL FILLER	TATA spare parts
572401157702	O-RING,CYL HEAD COVER	TATA spare parts
572401160104	INJECTOR ASSY	TATA spare parts
572401165102	CLAW,INJECTOR	TATA spare parts
572401170126	DIPSTICK TUBE ASSY BS6	TATA spare parts
572401170128	HOSE ASSY OIL SEPARATOR TO AIR FILTER BS	TATA spare parts
572401170130	DIPSTICK ASSY BS6	TATA spare parts
572401170132	HOSE ASSY OIL SEPARATOR TO AIR FILTER BS	TATA spare parts
572401170133	HOSE ASSY OIL SEPARATOR TO AIR FILTER BS	TATA spare parts
572401173311	BRACKET DIPSTICK TUBE CLAMPING BS6	TATA spare parts
572401175812	RUBBER HOSE ADAPTER TO OIL SUMP BS6	TATA spare parts
572401990105	KIT-ENGINE OVERHAUL SEAL	TATA spare parts
572401990110	CYL HEAD ASSY W/O INJECTOR	TATA spare parts
572401990112	SET-INLET & EXHAUST VALVES	TATA spare parts
572401990113	SET-INTAKE & EXHAUST VALVE GUIDE BS6	TATA spare parts
572401990114	SET-VALVE SEAT INSERT BS6	TATA spare parts
572401990124	BARE ENGINE BS6	TATA spare parts
572401990125	HALF BLOCK BS6	TATA spare parts
572401990126	GASKET KIT ENG O/H W/CYL HD GASKET 1.4th	TATA spare parts
572401990131	SPD ENGINE BS6	TATA spare parts
572401990148	BARE ENGINE BS6-PH2	TATA spare parts
572401990149	KIT-ENGINE OVERHAUL GASKET BS6-PH2	TATA spare parts
572401990150	HALF BLOCK ASSY BS6-PH2	TATA spare parts
572401990151	CYL HEAD ASSY W/O INJECTOR BS6-PH2	TATA spare parts
572401990152	KIT-ENGINE OVERHAUL GASKET BS6-PH2	TATA spare parts
572403100108	CRANKSHAFT ASSY WITH PIN BS6	TATA spare parts
572403110106	FLYWHEEL ASSY WITH RING GEAR & PIN BS6	TATA spare parts
572403110107	FLYWHEEL ASSY WITH RING GEAR & PIN BS6	TATA spare parts
572403110110	FLYWHEEL ASSY WITH RING GEAR & PIN BS6-P	TATA spare parts
572403115401	RING GEAR BS6	TATA spare parts
572403130101	VIBRATION DAMPER ASSY	TATA spare parts
572403150104	CONNECTING ROD ASSY WITH BUSH	TATA spare parts
572403153105	BEARING HALF,CONN ROD,UPPER	TATA spare parts
572403153106	BEARING HALF,CONN ROD,UPPER	TATA spare parts
572403990107	SET-MAIN BRGS HALF UPPER/LOWER BS6	TATA spare parts
572403990109	SET-BUSH CONNECTING ROD BS6	TATA spare parts

572403990111	SET-PISTON RING BS6	TATA spare parts
572403990112	SET-PISTON W/O RINGS GRADE A BS6	TATA spare parts
572403990113	SET-PISTON W/O RINGS GRADE B BS6	TATA spare parts
572403990114	SET-PISTON W/O RINGS GRADE C BS6	TATA spare parts
572403990115	SET-BEARING HALF CONNECTING ROD BS6	TATA spare parts
572405113201	HEX FLANGE BOLT (TIMING BELT IDLER)	TATA spare parts
572405115401	GEAR,CRANKSHAFT	TATA spare parts
572405116301	TIMING BELT	TATA spare parts
572405118601	SPACER,TIMING BELT IDLER	TATA spare parts
572405157802	SEAL,VALVE GUIDE	TATA spare parts
572407100105	HP PUMP ASSY	TATA spare parts
572407140114	FUEL RAIL ASSY	TATA spare parts
572407140117	SET-BACK LEAK HOSE ASSY BS6	TATA spare parts
572407140119	HP PIPE ASSY FIP TO RAIL BS6	TATA spare parts
572407140122	FUEL PR PIPE ASSY,RAIL TO INJ	TATA spare parts
572407140123	FUEL PR PIPE ASSY,RAIL TO INJ	TATA spare parts
572407140124	FUEL PR PIPE ASSY,RAIL TO INJ	TATA spare parts
572407140125	FUEL PR PIPE ASSY,RAIL TO INJ	TATA spare parts
572407145803	HOSE BACK LEAK BS6-PH2	TATA spare parts
572407148201	BRACKET BS6	TATA spare parts
572409110107	FUEL FILTER ASSY WITH BRACKET	TATA spare parts
572409110108	KIT-FILTER ELEMENT	TATA spare parts
572409110109	KIT-CLOGGING SENSOR ASSY WITH CLIP	TATA spare parts
572409110119	FUEL FILTER ASSY WITH BRACKET BS6	TATA spare parts
572409130171	RIBBED HOSE ASSY HFM TO TC BS6	TATA spare parts
572409130179	PIPE ASSY AIR INTAKE BS6	TATA spare parts
572409130185	RIBBED HOSE ASSY HFM TO TC BS6	TATA spare parts
572409130196	PIPE ASSY AIR INTAKE BS6	TATA spare parts
572409130202	BRACKET ASSY BS6-PH2	TATA spare parts
572409130205	RIBBED HOSE ASSY HFM TO TC BS6-PH2	TATA spare parts
572409130206	HOSE ASSY AIR FILTER TO HFM SENSOR BS6-P	TATA spare parts
572409135819	RUBBER HOSE BS6	TATA spare parts
572409135821	RUBBER HOSE AIR INTAKE BS6	TATA spare parts
572409135822	HOSE AIR FILTER INTAKE BS6	TATA spare parts
572409135825	HOSE AIR FILTER INTAKE BS6-PH2	TATA spare parts
572414100113	BRACKET ASSY ELBOW AIR INTAKE BS6	TATA spare parts
572414100117	INTAKE MANIFOLD ASSY BS6-PH2	TATA spare parts
572414103816	ELBOW AIR INTAKE BS6	TATA spare parts
572414103821	ELBOW AIR INTAKE BS6-PH2	TATA spare parts
572414110117	HEAT SHIELD ASSY,EXHAUST MANIFOLD,TOP	TATA spare parts
572414110136	EGR COOLER ASSY BS6	TATA spare parts
572414110137	BRACKET ASSY EVRV MTG BS6	TATA spare parts
572414110138	BRACKET ASSY EVRV MTG BS6	TATA spare parts
572414110145	HOSE ASSY EVRV TO EGR BS6	TATA spare parts
572414110146	HOSE ASSY EVRV TO TURBOCHARGER BS6	TATA spare parts
572414110147	HOSE EVRV TO AIR INTAKE BS6	TATA spare parts
572414110148	HOSE ASSY VACUUM PUMP TO VACUUM ACC BS6	TATA spare parts

572414110149	EXHAUST PRESSURE PIPE ASSY PD SENSOR BS6	TATA spare parts
572414110150	BRACKET ASSY PRESSURE SENSOR MTG BS6	TATA spare parts
572414110156	CATCON ASSY WITH HEAT SHIELD & BKT BS6	TATA spare parts
572414110171	EGR PIPE ASSY WITH CLAMP BS6	TATA spare parts
572414110179	HEAT SHIELD - DP SENSOR BS6	TATA spare parts
572414110184	CATCON ASSY WITH HEAT SHIELD - BKT BS6	TATA spare parts
572414110196	BRACKET ASSY TURBOCHARGER MTG BS6	TATA spare parts
572414110198	CATCON ASSY WITH HEAT SHIELD & BKT BS6	TATA spare parts
572414110201	CATCON ASSY WITH HEAT SHIELD & BKT BS6-P	TATA spare parts
572414110202	CATCON ASSY WITH HEAT SHIELD & BKT BS6	TATA spare parts
572414110205	HEAT SHIELD ASSY TURBOCHARGER BS6	TATA spare parts
572414110207	CATCON ASSY WITH HEAT SHIELD & BKT BS6-P	TATA spare parts
572414110208	EGR PIPE ASSY WITH CLAMP BS6-PH2	TATA spare parts
572414110213	CATCON ASSY WITH HEAT SHIELD & BKT BS6	TATA spare parts
572414110215	HOSE EVRV TO AIR INTAKE BS6-PH2	TATA spare parts
572414110237	CATCON ASSY WITH HEAT SHIELD & BKT BS6-P	TATA spare parts
572414113312	BRACKET VACUUM RESERVOIR MTG BS6	TATA spare parts
572414113313	BRACKET BS6	TATA spare parts
572414113319	BRACKET BS6	TATA spare parts
572414113323	BRACKET TURBOCHARGER MTG BS6	TATA spare parts
572414113324	BRACKET CATCON MTG REAR BS6	TATA spare parts
572414113702	EXHAUST MANIFOLD BS6	TATA spare parts
572414113704	BRACKET CATCON ASSEMBLY FRONT BS6	TATA spare parts
572414113705	BRACKET CATCON ASSEMBLY REAR BS6	TATA spare parts
572414113706	BRACKET CATCON ASSY FRONT BS6	TATA spare parts
572414113707	BRACKET CATCON ASSY REAR BS6	TATA spare parts
572414113710	EXHAUST MANIFOLD BS6-PH2	TATA spare parts
572414115302	GASKET,EXHAUST MANIFOLD	TATA spare parts
572414115844	HOSE EVRV TO T-CONNECTOR BS6	TATA spare parts
572414115845	HOSE EVRV TO T-CONNECTOR BS6	TATA spare parts
572414115853	HOSE T-CONNECTOR TO ACCUMULATOR BS6	TATA spare parts
572414115854	HOSE NRV TO T-CONNECTOR BS6	TATA spare parts
572414115855	HOSE VACUUM PUMP TO NRV BS6	TATA spare parts
572414115876	HOSE VACUUM LINE TO SOLENOID VALVE BS6	TATA spare parts
572414115880	HOSE T-CONNECTOR TO EVRV BS6	TATA spare parts
572414118207	BRACKET TURBOCHARGER MTG BS6	TATA spare parts
572414118802	STUD,EXHAUST MANIFOLD	TATA spare parts
572414119902	CATALYST CDPF BS6	TATA spare parts
572414119903	CATALYST LNT BS6	TATA spare parts
572414135801	HOSE DPF OUTLET TO TUBE ASSY BS6	TATA spare parts
572414135802	HOSE OUTLET PRESSURE TUBE TO SENSOR BS6	TATA spare parts
572414135803	HOSE DPF INTAKE TO TUBE ASSY BS6	TATA spare parts
572414135804	HOSE INTAKE PRESSURE TUBE TO SENSOR BS6	TATA spare parts
572414135805	HOSE DPF OUTLET TO DPS BS6	TATA spare parts
572414135806	HOSE DPF INTAKE TO DPS BS6	TATA spare parts
572414135807	HOSE DPF OUTLET TO DPS BS6-PH2	TATA spare parts
572414135808	HOSE DPF INTAKE TO DPS BS6-PH2	TATA spare parts

572414510109	TURBOCHARGER ASSY BS6	TATA spare parts
572414510111	TURBOCHARGER ASSY BS6	TATA spare parts
572414515301	GASKET,TC INTAKE TO EXHAUST MANIFOLD	TATA spare parts
572414515303	GASKET (TC OUTLET FLANGE) BS6	TATA spare parts
572414600127	PIPE ASSY WITH BRACKET TC TO INTERCOOLER	TATA spare parts
572414600133	PIPE ASSY INTERCOOLER TO INTAKE THROTTLE	TATA spare parts
572414600134	PIPE ASSY TC TO INTERCOOLER BS6	TATA spare parts
572414600146	PIPE ASSY TC TO INTERCOOLER BS6	TATA spare parts
572414600147	PIPE ASSY WITH BRACKET TC TO INTERCOOLER	TATA spare parts
572414600149	PIPE ASSY WITH BRACKET TC TO INTERCOOLER	TATA spare parts
572414600153	PIPE ASSY INTERCOOLER TO INTAKE THROTTLE	TATA spare parts
572414600154	PIPE ASSY TC TO INTERCOOLER BS6-PH2	TATA spare parts
572414605826	HOSE TC OUTLET TO IC PIPE BS6	TATA spare parts
572414605830	RUBBER HOSE TURBOCHARGER TO INTERCOOLER	TATA spare parts
572414605832	HOSE INTERCOOLER PIPE TO THROTTLE BS6	TATA spare parts
572414605872	HOSE TC OUTLET TO IC PIPE BS6	TATA spare parts
572414605874	RUBBER HOSE TURBOCHARGER TO INTERCOOLER	TATA spare parts
572414605878	RBR HOSE TURBO TO INTERCOOLER BS6-PH2	TATA spare parts
572414700105	EGR COOLER ASSY BS6-PH2	TATA spare parts
572414700106	EGR VALVE ASSY BS6-PH2	TATA spare parts
572414700107	VACUUM ACTUATOR ASSY BS6-PH2	TATA spare parts
572414703301	BRACKET EGR MODULE MTG BS6	TATA spare parts
572414705302	GASKET EGR PIPE BS6-PH2	TATA spare parts
572414708001	SCREW BS6-PH2	TATA spare parts
572414990104	KIT-GASKET DECARBONISING BS6	TATA spare parts
572415143310	SUPPORT BRACKET OIL FILLING HOSE BS6	TATA spare parts
572415143701	BRACKET¿ALTERNATOR¿MTG	TATA spare parts
572415143703	BRACKET ALTERNATOR MTG BS6-PH2	TATA spare parts
572415209902	SPEED SENSOR	TATA spare parts
572415209903	AIR MASS FLOW SENSOR	TATA spare parts
572415240101	SENSOR PARTICULATE MATTER BS6-PH2	TATA spare parts
572415240102	UREA LEVEL SENSOR BS6-PH2	TATA spare parts
572415250101	UREA SUPPLY MODULE BS6-PH2	TATA spare parts
572416102001	ECU HARDWARE	TATA spare parts
572418105302	GASKET OIL PUMP BS6-PH2	TATA spare parts
572418170112	OIL FEEDER PIPE ASSY CYL HEAD TO TC BS6	TATA spare parts
572418170113	OIL RETURN LINE ASSY BS6	TATA spare parts
572418170115	OIL RETURN LINE ASSY BS6	TATA spare parts
572418170116	OIL FEEDER PIPE ASSY CYL HEAD TO TC BS6	TATA spare parts
572418175301	GASKET,PISTON COOLING NOZZLE	TATA spare parts
572420100101	WATER PUMP ASSY	TATA spare parts
572420105301	GASKET WATER PUMP BS6-PH2	TATA spare parts
572420120114	WATER BOX ASSY	TATA spare parts
572420120123	WATER BOX ASSY BS6	TATA spare parts
572420120124	ELBOW ASSY WATER INTAKEBS6	TATA spare parts
572420120125	WATER BOX ASSY BS6-PH2	TATA spare parts
572420120127	COVER ASSY THERMOSTAT HOUSING BS6	TATA spare parts

572420123804	COVER, THERMOSTAT	TATA spare parts
572422100101	ENGINE LIFTING HOOK BS6	TATA spare parts
572422103301	BRACKET EVRV ROUTING ON LIFTING HOOK BS6	TATA spare parts
572422107103	ENGINE LIFTING HOOK	TATA spare parts
572422107137	ENGINE LIFTING HOOK	TATA spare parts
572422108201	SUPPORT BS6	TATA spare parts
572422123706	ENGINE MTG ARM RH BS6	TATA spare parts
572422123707	ENGINE MTG ARM LH BS6	TATA spare parts
572422123708	ENGINE MTG ARM RH BS6	TATA spare parts
572422123709	STIFFENER BRACKET ADAPTOR TO ENGINE MTG	TATA spare parts
572422123710	STIFFENER LH BS6	TATA spare parts
572422123711	STIFFENER RH BS6	TATA spare parts
572423120109	BRACKET ASSY AC COMP MTG BS6	TATA spare parts
572449100103	SCR & MIXER ASSY BS6-PH2	TATA spare parts
572449100104	SCR ASSY BS6-PH2	TATA spare parts
572449200101	TUBE ASSY UREA INJECTOR COOLING BS6-PH2	TATA spare parts
572449205803	HOSE TUBE TO COOLANT RTN PIPE BS6-PH2	TATA spare parts
572449205804	HOSE TUBE ASSY TO UREA INJECTOR BS6-PH2	TATA spare parts
572449205805	HOSE UREA INJECTOR TO TUBE ASSY BS6-PH2	TATA spare parts
572449205806	HOSE UCL TO TUBE ASSY BS6-PH2	TATA spare parts
572450100147	PIPE ASSY WITH CLAMP RADIATOR OUTLET BS6	TATA spare parts
572450100152	PIPE ASSY EGR COOLER OUTLET BS6	TATA spare parts
572450100153	PIPE ASSY EGR COOLER OUTLET BS6	TATA spare parts
572450100162	RADIATOR ASSY WITH FAN & SHROUD BS6	TATA spare parts
572450100166	PIPE ASSY EGR COOLER OUTLET BS6	TATA spare parts
572450100168	PIPE ASSY EGR COOLER INTAKE BS6	TATA spare parts
572450100169	BRACKET EGR COOLER PIPE MTG BS6	TATA spare parts
572450100171	PIPE ASSY UCL TO RADIATOR BS6	TATA spare parts
572450100187	HOSE ASSY BS6	TATA spare parts
572450100188	HOSE ASSY BS6	TATA spare parts
572450100193	BRACKET EGR COOLER PIPE MTG BS6	TATA spare parts
572450100197	PIPE ASSY EGR COOLER OUTLET BS6-PH2	TATA spare parts
572450100198	PIPE ASSY EGR COOLER INTAKE BS6-PH2	TATA spare parts
572450100202	RADIATOR ASSY WITH FAN & SHROUD BS6-PH2	TATA spare parts
572450100210	PIPE ASSY WITH CLAMP RAD OUTLET BS6-PH2	TATA spare parts
572450100218	BRACKET EGR COOLER PIPE MTG BS6-PH2	TATA spare parts
572450104206	SEPARATOR CLAMP BS6-PH2	TATA spare parts
572450105301	SEALING FOAM BS6	TATA spare parts
572450105847	RUBBER HOSE RADIATOR INTAKE BS6	TATA spare parts
572450105848	RUBBER HOSE RADIATOR OUTLET BS6	TATA spare parts
572450105852	HOSE EGR COOLER INTAKE BS6	TATA spare parts
572450105853	HOSE EGR COOLER OUTLET BS6	TATA spare parts
572450105856	HOSE RADIATOR TO WATER INTAKE ELBOW BS6	TATA spare parts
572450105858	HOSE VENT LINE TO RADIATOR BS6	TATA spare parts
572450105860	RUBBER HOSE AUX WATER TANK BS6	TATA spare parts
572450105869	HOSE AUX WATER TANK TO WATER BOX BS6	TATA spare parts
572450105870	HOSE AUX WATER TANK TO BYPASS TUBE BS6	TATA spare parts

572450105871	HOSE VENT LINE TO RADIATOR BS6	TATA spare parts
572450105872	HOSE EGR COOLER OUTLET BS6	TATA spare parts
572450105873	HOSE EGR COOLER INTAKE BS6	TATA spare parts
572450105884	HOSE VENT LINE TO RADIATOR BS6-PH2	TATA spare parts
572450108206	SUPPORT ROD RADIATOR MTG TOP-RH BS6	TATA spare parts
572450108207	SUPPORT ROD RADIATOR MTG TOP-LH BS6	TATA spare parts
572450108208	BRACKET PWM PIGTAIL SUPPORT BS6-PH2	TATA spare parts
572450108209	BRACKET RADIATOR BOTTOM SUPPORT BS6-PH2	TATA spare parts
572450108211	P-CLAMP ASSY BS6-PH2	TATA spare parts
572450109901	RADIATOR ASSY BS6	TATA spare parts
572450109902	FAN MOTOR SHROUD ASSY BS6	TATA spare parts
572450109912	FAN MOTOR SHROUD ASSY BS6-PH2	TATA spare parts
572450115801	HOSE OIL COOLER INTAKE BS6	TATA spare parts
572450115802	HOSE OIL COOLER OUTLET BS6	TATA spare parts
572450115807	HOSE WATER BOX HSG TO RADIATOR PIPE BS6	TATA spare parts
572450115808	HOSE WATER BOX HSG TO RADIATOR PIPE BS6-	TATA spare parts
5730870105	BOLT M12X35 -10.9	TATA spare parts
5731030025	SPRING WASHER M12 SQUARE SECTION	TATA spare parts
573301990105	DECARB GASKET KIT	TATA spare parts
57350100010598	ASSY. ENGINE BS6	TATA spare parts
57350100011398	ENGINE ASSY WITH CLUTCH BS6	TATA spare parts
57350100011598	ACE CX ENGINE ASSY WITH CLUTCH BS6	TATA spare parts
573501000121	ENGINE ASSY WITH CLUTCH BS6	TATA spare parts
573501000129	ENGINE ASSY WITH CLUTCH BS6-PH2	TATA spare parts
573501000134	ENGINE ASSY W/O CLUTCH BS6-PH2	TATA spare parts
573501000137	ENGINE ASSY WITH CLUTCH BS6-PH2	TATA spare parts
573501100102	CYL CRANKCASE ASSY WITH MAIN BRG CAP BS6	TATA spare parts
573501100103	CYL CRANKCASE ASSY WITH DOWELS BS6-PH2	TATA spare parts
573501101601	CYLINDER LINER BS6	TATA spare parts
573501104101	BALANCER CAP BS6	TATA spare parts
573501104102	BALANCER CAP BS6	TATA spare parts
573501130103	ADAPTER OIL FILLING CAP BS6	TATA spare parts
573501150102	CYLINDER&HEAD&COVER&ASSY&COMPLETE BS6	TATA spare parts
573501153405	INSERT VALVE SEAT INTAKE BS6-PH2	TATA spare parts
573501153407	INSERT VALVE SEAT EXHAUST BS6-PH2	TATA spare parts
573501155301	GASKET CYLINDER HEAD BS6	TATA spare parts
573501156901	NIPPLE BS6	TATA spare parts
573501173801	BRACKET OIL&MIST&SEPARATOR&MTG& BS6	TATA spare parts
573501175101	BRACKET OIL MIST SEPARATOR MTG BS6-PH2	TATA spare parts
573501175807	HOSE OIL SEPARATOR TO INTAKE HOSE BS6	TATA spare parts
573501175808	HOSE BS6	TATA spare parts
573501175809	HOSE OIL SEPARATOR RETURN PIPE TO SUMP B	TATA spare parts
573501175810	RUBBER HOSE FILLING ADAPTER TO OIL SUMP	TATA spare parts
573501175811	HOSE OIL SEPARATOR TO ADAPTER BS6	TATA spare parts
573501175813	HOSE OIL SEPARATOR TO INTAKE HOSE BS6	TATA spare parts
573501990103	HALF BLOCK ENGINE BS6	TATA spare parts
573501990105	LONG BLOCK BS6	TATA spare parts

573501990106	KIT-CYL HEAD ASSY BS6	TATA spare parts
573501990108	KIT-DECARBONISING GASKET BS6	TATA spare parts
573501990109	KIT-GASKET BS6	TATA spare parts
573501990112	HALF BLOCK ENGINE BS6	TATA spare parts
573501990114	BARE ENGINE ASSY BS6	TATA spare parts
573501990115	KIT CYLINDER HEAD ASSY BS6-PH2	TATA spare parts
573501990120	BARE ENGINE ASSY BS6-PH2	TATA spare parts
573501990121	KIT-CYL HEAD ASSY BS6-PH2	TATA spare parts
573503107901	CRANKSHAFT BS6	TATA spare parts
573503107902	BALANCER SHAFT BS6	TATA spare parts
573503137001	PULLEY CRANKSHAFT BS6	TATA spare parts
573503990102	SET-PISTON W/O RINGS GRADE ABS6	TATA spare parts
573503990103	SET-PISTON W/O RINGS GRADE BBS6	TATA spare parts
573503990104	SET-PISTON W/O RINGS GRADE CBS6	TATA spare parts
573503990105	SET-PISTON RING BS6	TATA spare parts
573503990110	SET-PISTON W/O RINGS GRADE A BS6	TATA spare parts
573503990111	SET-PISTON W/O RINGS GRADE B BS6	TATA spare parts
573503990112	SET-PISTON W/O RINGS GRADE C BS6	TATA spare parts
573505104101	CAP CAMSHAFT BEARING BS6	TATA spare parts
573507100102	FUEL RAIL ASSYBS6	TATA spare parts
573509130113	SNORKEL ASSY BS6	TATA spare parts
573509130114	PIPE ASSY WITH BRACKET BS6	TATA spare parts
573509130116	STRAP ASSY AIR FILTER BS6	TATA spare parts
573509130118	HOSE ASSY BS6	TATA spare parts
573509130121	PIPE ASSY WITH BRACKET BS6	TATA spare parts
573509130123	HOSE ASSY BS6	TATA spare parts
573509130126	ISOLATOR ASSY BS6-PH2	TATA spare parts
573509130128	HOSE ASSY AIR INTAKE SYSTEM BS6-PH2	TATA spare parts
573509130130	KIT-AIR INTAKE BS6-PH2	TATA spare parts
573509130131	SNORKEL ASSY BS6-PH2	TATA spare parts
573509131601	SNORKEL ASSY BS6	TATA spare parts
573509135807	HOSE AIR FILTER TO SNORKEL BS6	TATA spare parts
573509135808	HOSE BS6	TATA spare parts
573514100105	ADAPTER BS6	TATA spare parts
573514103301	BRACKET BS6	TATA spare parts
573514103801	ADAPTER BS6-PH2	TATA spare parts
573514107701	GASKET ASSY INTAKE THROTTLE BS6	TATA spare parts
573514110105	CCC ASSY WITH HEAT SHIELD & MTG BKT	TATA spare parts
573514110107	CATCON ASSY WITH HEAT SHIELD	TATA spare parts
573514110114	CATALYTIC CONVERTER ASSY BS6	TATA spare parts
573514110117	CATALYTIC CONVERTER BS6-PH2	TATA spare parts
573514110124	CCC ASSY WITH HEAT SHIELD BS6	TATA spare parts
573514110126	CATCON ASSY WITH HEAT SHIELD BS6	TATA spare parts
573514110128	BRACKET ASSY WITH WELD NUT BS6-PH2	TATA spare parts
573514118203	HEAT SHIELD BS6-PH2	TATA spare parts
573515143701	BRACKET BS6	TATA spare parts
573515146302	ALTERNATOR BELT BS6	TATA spare parts



573515146304	ALTERNATOR BELT BS6	TATA spare parts
573515208201	ADAPTER BS6	TATA spare parts
573515209902	IGNITION COIL ASSY BS6	TATA spare parts
573518100106	INTEGRATED OIL & WATER PUMP BS6	TATA spare parts
573520120101	THERMOSTAT ASSY BS6-PH2	TATA spare parts
573522127101	ENGINE LIFTING HOOK BS6	TATA spare parts
573522127102	ENGINE LIFTING HOOK BS6	TATA spare parts
573550100103	PIPE ASSY WITH CLAMP RADIATOR INTAKE BS6	TATA spare parts
573550100104	PIPE ASSY RADIATOR WATER OUT BS6	TATA spare parts
573550100105	HOSE ASSY WITH SLEEVE BS6	TATA spare parts
573550104201	BRACKET LCL MTG BS6	TATA spare parts
573550104202	BRACKET UCL MTG BS6	TATA spare parts
573550105805	HOSE RADIATOR OUTLET PIPE TO LCL BS6	TATA spare parts
573550105806	HOSE RADIATOR INTAKE BS6	TATA spare parts
573550105807	HOSE PUMP INTAKE BS6	TATA spare parts
573550105808	HOSE THERMOSTAT COVER TO RADIATOR BS6	TATA spare parts
573550106902	HOSE NO LOSS TANK BS6	TATA spare parts
573558900601	SUPPORT STAND ENGINE BS6	TATA spare parts
573600000101	700CC ENGINE ASSY W/O CLUTCH BS6	TATA spare parts
573600000103	ENGINE ASSY W/O CLUTCH	TATA spare parts
573600000105	ENGINE ASSY BS6	TATA spare parts
573600000110	ENGINE ASSY W/O CLUTCH BS6-PH2	TATA spare parts
573601100102	CYL CRANKCASE ASSY BS6	TATA spare parts
573601100104	BRACKET ASSY WITH CLUTCH HSG CYL	TATA spare parts
573601100107	CYL CRANKCASE ASSY BS6-PH2	TATA spare parts
573601130101	OIL SUMP ASSY W/ODRAIN PLUG BS6	TATA spare parts
573601130102	OIL SUMP ASSY WITH DRAIN PLUG BS6	TATA spare parts
573601130106	OIL SUMP ASSY WITH DRAIN PLUG	TATA spare parts
573601130111	OIL SUMP ASSY WITH DRAIN PLUG BS6-PH2	TATA spare parts
573601140101	COVER ASSY TIMING GEAR HSG (FRONT)	TATA spare parts
573601140102	TIMING COVER ASSY REAR	TATA spare parts
573601150101	CYL HEAD ASSY W/O VALVES	TATA spare parts
573601150105	CYL HEAD ASSY WITH VALVES-NOZZLES BS6	TATA spare parts
573601150114	COVER ASSY CYLINDER HEAD (WITH NIPPLE)	TATA spare parts
573601150118	COVER ASSY CYLINDER HEAD BS6	TATA spare parts
573601150124	COVER ASSY CYLINDER HEAD BS6-PH2	TATA spare parts
573601153401	INSERT VALVE SEAT INTAKE BS6	TATA spare parts
573601153402	INSERT VALVE SEAT EXHAUST	TATA spare parts
573601153503	INSERT	TATA spare parts
573601155305	GASKET BAFFLE CYL HEAD COVER	TATA spare parts
573601155306	GASKET CYLINDER HEAD 0.20 THK	TATA spare parts
573601155307	GASKET CYLINDER HEAD 0.30 THK BS6	TATA spare parts
573601155308	GASKET CYLINDER HEAD 0.40 THK	TATA spare parts
573601155309	GASKET CYL HEAD COVER	TATA spare parts
573601155310	GASKET CYLINDER HEAD COVER BS6	TATA spare parts
573601157701	CAP OIL FILLER BS6	TATA spare parts
573601157702	O-RING OIL FILLER CAP BS6	TATA spare parts

573601158201	DEFLECTOR BLOWBY	TATA spare parts
573601158203	BAFFLE (CYL HEAD COVER)	TATA spare parts
573601158205	CORE PLUG BS6-PH2	TATA spare parts
573601160101	INJECTOR ASSY BS6	TATA spare parts
573601160102	INJECTOR BS6	TATA spare parts
573601170107	RETURN PIPE ASSY OIL SEPARATOR	TATA spare parts
573601170111	DIPSTICK ASSY BS6	TATA spare parts
573601170112	DIPSTICK TUBE BS6	TATA spare parts
573601170114	ASSY. DIPSTICK BS6	TATA spare parts
573601170116	DIPSTICK ASSY BS6-PH2	TATA spare parts
573601170118	LOWER HALF ASSY REED VALVE HSG BS6-PH2	TATA spare parts
573601170120	BRACKET ASSY BS6-PH2	TATA spare parts
573601173801	UPPER HALF REED VALVE HOUSING BS6-PH2	TATA spare parts
573601175302	BRACKET BONNET MTG BS6-PH2	TATA spare parts
573601175801	HOSE BLOWBY BS6	TATA spare parts
573601175811	HOSE BLOWBY BS6-PH2	TATA spare parts
573601175812	HOSE BLOWBY BS6-PH2	TATA spare parts
573601990105	CYL HEAD ASSY W/O INJECTOR	TATA spare parts
573601990109	KIT-DECARBONISING GASKET	TATA spare parts
573601990110	KIT-ENGINE OVERHAUL SEAL	TATA spare parts
573601990111	KIT-ENGINE OVERHAUL GASKET	TATA spare parts
573601990114	BARE ENGINE ASSY BS6	TATA spare parts
573601990115	HALF BLOCK ASSY BS6	TATA spare parts
573601990117	KIT-DECARBONISING GASKET	TATA spare parts
573601990118	KIT-ENGINE O/H GASKET-CYL HD 0.2 THK BS6	TATA spare parts
573601990121	CYL HEAD ASSY W/O INJECTOR BS6	TATA spare parts
573601990123	BARE ENGINE ASSY BS6-PH2	TATA spare parts
573601990124	HALF BLOCK ASSY BS6-PH2	TATA spare parts
573601990125	GASKET KIT-DECARBONISING-W/HD GSKT 1.1 T	TATA spare parts
573601990126	GASKET KIT-ENGINE O/H-W/HD GSKT 1.1 THK	TATA spare parts
573601990129	CYL HEAD ASSY W/O INJECTOR BS6-PH2	TATA spare parts
573603100101	CRANKSHAFT ASSY WITH PIN	TATA spare parts
573603110101	FLYWHEEL ASSY WITH RING GEAR & DOWEL BS6	TATA spare parts
573603110103	FLYWHEEL ASSY	TATA spare parts
573603110105	FLYWHEEL ASSY WITH RING GEAR & DOWEL	TATA spare parts
573603120101	SET-MAIN BRG HALF UPPER/LOWER-NORMAL BS6	TATA spare parts
573603130101	COUNTER WEIGHT	TATA spare parts
573603130103	COUNTER WEIGHT BS6	TATA spare parts
573603140112	PISTON ASSY GRADE A BS6	TATA spare parts
573603140116	SET-PISTON W/O RINGS GRADE A BS6	TATA spare parts
573603140118	SET-PISTON W/O RINGS GRADE B BS6	TATA spare parts
573603140120	SET-PISTON W/O RINGS GRADE C BS6	TATA spare parts
573603140121	SET-PISTON RING BS6	TATA spare parts
573603140126	SET-PISTON W/O RINGS GRADE A BS6-PH2	TATA spare parts
573603140128	SET-PISTON W/O RINGS GRADE B BS6-PH2	TATA spare parts
573603150101	SET-CONNECTING ROD BEARING HALF NORMAL	TATA spare parts
573603150102	SET-BUSH CONNECTING ROD BS6	TATA spare parts

573605104101	CAP CAMSHAFT BEARING	TATA spare parts
573605104102	CAP CAMSHAFT BEARING	TATA spare parts
573605107901	CAMSHAFT	TATA spare parts
573605110101	CAMSENSORPLATEASSYWITHTHGEAR BS6	TATA spare parts
573605110102	GEAR ASSY CRANKSHAFT	TATA spare parts
573605117101	SENSOR PLATE	TATA spare parts
573605125101	INTAKE VALVE BS6	TATA spare parts
573605125102	EXHAUST VALVE BS6	TATA spare parts
573607113302	BRACKET OVER FLOW LINE	TATA spare parts
573607120102	CAM BOX HOUSING ASSY BS6	TATA spare parts
573607123303	BRACKET BS6	TATA spare parts
573607123304	BRACKET ASSY BS6-PH2	TATA spare parts
573607123802	CAM BOX HOUSING BS6	TATA spare parts
573607123803	COVER PLATE CAMBOX HOUSING	TATA spare parts
573607123804	CAM BOX HOUSING	TATA spare parts
573607123805	BRACKET BS6-PH2	TATA spare parts
573607124101	BRACKET	TATA spare parts
573607127701	O-RING	TATA spare parts
573607137901	CAMSHAFT	TATA spare parts
573607140103	OIL INLET PIPE ASSY	TATA spare parts
573607140104	BACK LEAK PIPE ASSY BS6	TATA spare parts
573607140105	TUBE ASSY BS6	TATA spare parts
573607140106	TUBE ASSY	TATA spare parts
573607140112	BACK LEAK SYSTEM ASSY	TATA spare parts
573607140113	HP PIPE ASSY	TATA spare parts
573607140114	HP PIPE ASSY	TATA spare parts
573607140115	HP LINE TUBE ASSY PUMP TO RAIL	TATA spare parts
573607140116	HP PIPE ASSY BS6	TATA spare parts
573607140117	HP PIPE ASSY BS6	TATA spare parts
573607140118	HP LINE TUBE ASSY PUMP TO RAIL (57360714	TATA spare parts
573607140119	BACK LEAK SYSTEM ASSY BS6	TATA spare parts
573607140120	BACKLEAKSYSTEMASSY BS6	TATA spare parts
573607140121	INJECTOR BACK LEAK PIPE ASSY BS6	TATA spare parts
573607140122	HP LINE TUBE ASSY PUMP TO RAIL BS6-PH2	TATA spare parts
573607140123	HP PIPE ASSY BS6-PH2	TATA spare parts
573607140124	HP PIPE ASSY BS6-PH2	TATA spare parts
573607140125	OIL RTN PIPE ASSY CAMBOX TO CRANKCASE BS	TATA spare parts
573607145802	HOSE	TATA spare parts
573607148201	SUPPORT BRACKET FIP MTG	TATA spare parts
573609130101	PIPE ASSY AIR INTAKE SYSTEM (AIR FILTER	TATA spare parts
573609130102	HOSE ASSY INTAKE BS6	TATA spare parts
573609130108	AIR INTAKE PIPE BS6	TATA spare parts
573609130109	PIPE ASSY AIR FILTER TO HOSE (AIR FILTER	TATA spare parts
573609130112	RUBBERHOSEASSYSNORKELTOAIRFILTER BS6	TATA spare parts
573609130113	RESONATORBOXASSY BS6	TATA spare parts
573609130115	HOSE ASSY PIPE TO TC END BS6-PH2	TATA spare parts
573609133801	PIPE WITH BOSS AIR INTAKE BS6-PH2	TATA spare parts

573609135802	HOSE RESONATOR BOX TO INTAKE PIPE	TATA spare parts
573609135813	HOSE PIPE TO HFM SENSOR	TATA spare parts
573609135814	HOSE AIR INTAKE BS6	TATA spare parts
573609135815	HOSE AIR FILTER TO AIR INTAKE PIPE BS6	TATA spare parts
573609135816	HOSE BS6	TATA spare parts
573609135818	HOSE BS6	TATA spare parts
573609135819	HOSE BS6	TATA spare parts
573609137101	BRACKET RESONATOR BOX MTG	TATA spare parts
573609137103	BRACKET RESONATOR BOX MTG BS6	TATA spare parts
573614103803	INTAKE MANIFOLD BS6	TATA spare parts
573614103805	AIR INTAKE MANIFOLD BS6-PH2	TATA spare parts
573614110101	EGR MODULE ASSY BS6	TATA spare parts
573614110106	BRACKET ASSY SOLENOID VALVE MTG BS6	TATA spare parts
573614110109	BRACKET ASSY EGR COOLER MTG BS6	TATA spare parts
573614110111	BRACKET NOX SENSOR MTG BS6	TATA spare parts
573614110112	PRESSURE TUBE ASSY WITH BRACKETS BS6	TATA spare parts
573614110114	DOC & HEAT SHIELD ASSY BS6	TATA spare parts
573614110124	BRACKET ASSY VACUUM MODULATOR MTG	TATA spare parts
573614110126	PIPE WITH FLANGE ASSY BS6	TATA spare parts
573614110127	PIPE ASSY	TATA spare parts
573614110128	HOSE ASSY EVRV TO ALTERNATOR	TATA spare parts
573614110129	HOSE ASSY VACUUM LINE TO SOLENOID VALVE	TATA spare parts
573614110132	GASKET EXHAUST BS6	TATA spare parts
573614110133	HOSE ASSY BS6	TATA spare parts
573614110134	EGR TUBE ASSY BS6	TATA spare parts
573614110136	EGR TUBE ASSY BS6	TATA spare parts
573614110137	HEAT SHIELD ASSY EXHAUST MANIFOLD (57361	TATA spare parts
573614110143	PRESSURE TUBE ASSY BS6	TATA spare parts
573614110150	SCR & MIXER ASSY BS6	TATA spare parts
573614110153	BRACKET ASSY SENSOR MTG BS6	TATA spare parts
573614110154	PIPE ASSY BS6	TATA spare parts
573614110157	CC DOC & CDPF ASSY WITH HEAT SHIELD BS6	TATA spare parts
573614110162	BRACKET ASSY BS6-PH2	TATA spare parts
573614110163	BRACKET ASSY DOC & CDPF BS6	TATA spare parts
573614110164	BRACKET BS6	TATA spare parts
573614110169	BRACKET ASSY SENSOR MTG BS6-PH2	TATA spare parts
573614110170	BRACKET ASSY SENSOR MTG BS6-PH2	TATA spare parts
573614110181	EGR PIPE ASSY EXH MANIFOLD TO EGR VALVE	TATA spare parts
573614110183	TUBE ASSY EGR COOLER TO INT MANIFOLD BS6	TATA spare parts
573614110186	BRACKET ASSY WITH WELD NUT BS6-PH2	TATA spare parts
573614110189	DOC & CDPF ASSY BS6-PH2	TATA spare parts
573614110190	SCR & MIXER ASSY BS6-PH2	TATA spare parts
573614110193	CC DOC & CDPF ASSY WITH HEAT SHIELD BS6	TATA spare parts
573614110194	BRACKET ASSY DOC & CDPF BS6	TATA spare parts
573614110195	SUPPORT BRKT ASSY TURBOCHARGER BS6-PH2	TATA spare parts
573614110196	BRACKET ASSY DPS MTG	TATA spare parts
573614110197	BRACKET ASSY SENSOR MTG	TATA spare parts

573614110201	BRACKET ASSY DOC & CDPF MTG BS6-PH2	TATA spare parts
573614110202	CC DOC & CDPF ASSY WITH HEAT SHIELD BS6	TATA spare parts
573614110205	HEAT SHIELD ASSY TURBOCHARGER BS6-PH2	TATA spare parts
573614110208	HEAT SHIELD ASSY TURBOCHARGER BS6-PH2	TATA spare parts
573614110210	BRACKET ASSY EGR VALVE MTG BS6-PH2	TATA spare parts
573614110214	DOC & CDPF ASSY BS6-PH2	TATA spare parts
573614113302	BRACKET EGR MODULE MTG BS6	TATA spare parts
573614113307	BRACKET SENSOR MTG BS6	TATA spare parts
573614113309	BRACKET SENSOR MTG BS6	TATA spare parts
573614113312	BRACKET CLAMP SUPPORT BS6	TATA spare parts
573614113313	BRACKET CLAMP SUPPORT BS6	TATA spare parts
573614113316	BRACKET CLAMP SUPPORT BS6	TATA spare parts
573614113319	BRACKET CLAMP SUPPORT BS6-PH2	TATA spare parts
573614113323	BRACKET BS6	TATA spare parts
573614113705	EXHAUST MANIFOLD BS6	TATA spare parts
573614113710	EXHAUST MANIFOLD	TATA spare parts
573614113711	BRACKET CATCON MTG BS6	TATA spare parts
573614113712	BRACKET EGR COOLER MTG BS6	TATA spare parts
573614113713	EXHAUST ELBOW BS6	TATA spare parts
573614113719	BRACKET CATCON MTG BS6	TATA spare parts
573614115304	GASKET EGR VALVE BS6	TATA spare parts
573614115305	GASKET EXHAUST MANIFOLD	TATA spare parts
573614115306	GASKET TC OUTLET TO CLOSE COUPLED CATCON	TATA spare parts
573614115307	GASKET TC OUTLET TO COUPLED CATCON BS6-P	TATA spare parts
573614115805	HOSE VACUUM MODULATOR TO EGR VALVE	TATA spare parts
573614115817	HOSE DPF OUTLET PRESSURE SENSOR SIDE BS6	TATA spare parts
573614115818	HOSE INTAKE PRESSURE TUBE TO SENSOR BS6	TATA spare parts
573614115819	HOSE DPF OUTLET PRESSURE BS6	TATA spare parts
573614115824	HOSE DPF INTAKE PRESSURE BS6	TATA spare parts
573614115826	HOSE BS6	TATA spare parts
573614115827	HOSE INTAKE PRESSURE TUBE TO SENSOR BS6	TATA spare parts
573614115828	HOSE DPF OUTLET PRESSURE SENSOR SIDE BS6	TATA spare parts
573614118202	BRACKET BS6-PH2	TATA spare parts
573614510101	TURBOCHARGER ASSY BS6-PH2	TATA spare parts
573614600101	PIPE ASSY TURBOCHARGER HOSE TO IC HOSE B	TATA spare parts
573614600103	DUCT INTERCOOLER BS6-PH2	TATA spare parts
573614600104	HOSE ASSY WITH PROTECTIVE SLEEVE BS6-PH2	TATA spare parts
573614600105	PIPE ASSY WITH CLAMP BS6-PH2	TATA spare parts
573614600107	CLAMP PIPE BS6-PH2	TATA spare parts
573614603801	INTAKE ADAPTER BS6-PH2	TATA spare parts
573614604205	BRACKET BS6-PH2	TATA spare parts
573614605806	HOSE ASSY BS6-PH2	TATA spare parts
573614605808	RUBBER HOSE PIPE TO INTAKE MANIFOLD BS6-	TATA spare parts
573614605809	HOSE PIPE TO INTERCOOLER BS6-PH2	TATA spare parts
573614605810	HOSE BS6-PH2	TATA spare parts
573614606301	PIPE BS6-PH2	TATA spare parts
573614609901	SLEEVE BS6-PH2	TATA spare parts

573614700101	EGR VALVE ASSY BS6	TATA spare parts
573614700105	EGR VALVE ASSY BS6-PH2	TATA spare parts
573614705302	GASKET BS6	TATA spare parts
573614708001	SCREW M6X25 BS6	TATA spare parts
573615143705	BRACKETALTERNATOR(TOP) BS6	TATA spare parts
573615146301	POLY V-BELT BS6	TATA spare parts
573615203801	BRACKET (FOR CRANK ANGLE SENSOR)	TATA spare parts
573615209901	HFM SENSOR ASSY	TATA spare parts
573615209902	DIFFERENTIAL PRESSURE SENSOR BS6	TATA spare parts
573615409901	GLOW PLUG BS6	TATA spare parts
573618130101	GASKET OIL COOLER ADAPTER BS6-PH2	TATA spare parts
573618133801	ADAPTER BS6	TATA spare parts
573618133802	ADAPTER CRANKCASE TO OIL COOLER BS6-PH2	TATA spare parts
573618133803	ADAPTER CRANKCASE TO OIL COOLER BS6-PH2	TATA spare parts
573618150101	STRAINER&ASSY&OIL&PUMP	TATA spare parts
573618150104	STRAINER ASSY OIL PUMP BS6-PH2	TATA spare parts
573618155301	GASKET OIL PUMP STRAINER	TATA spare parts
573618170101	NOZZLE ASSY PISTON COOLING BS6	TATA spare parts
573618170102	PIPE ASSY TURBOCHARGER OIL RTN BS6-PH2	TATA spare parts
573618170103	OIL FEEDER PIPE ASSY CYL HEAD TO TC BS6-	TATA spare parts
573620120106	ADAPTER ASSY WITH TUBE BS6	TATA spare parts
573620120107	ELBOW ASSY WATER HEATER	TATA spare parts
573620120115	COVER ASSY& THERMOSTAT BS6	TATA spare parts
573620120116	COVER ASSY THERMOSTAT HOUSING BS6	TATA spare parts
573620120118	ELBOW ASSY WATER INTAKE & BYPASS BS6-PH2	TATA spare parts
573620120119	WATER BYPASS TUBE ASSY BS6-PH2	TATA spare parts
573620120120	ADAPTER ASSY WITH TUBE BS6-PH2	TATA spare parts
573620120137	HOSE OIL COOLER OUTLET BS6-PH2	TATA spare parts
573620123801	THERMOSTAT COVER	TATA spare parts
573620125302	GASKET COOLANT ADAPTER BS6	TATA spare parts
573620125803	HOSE CYL HEAD TO EGR COOLER BS6	TATA spare parts
573620125804	RUBBER HOSE EGR COOLER TO ADAPTER BS6	TATA spare parts
573620125806	HOSE	TATA spare parts
573620125811	HOSE BS6	TATA spare parts
573620125813	HOSE OIL COOLER WATER INTAKE BS6-PH2	TATA spare parts
573620125815	HOSE EGR TO WATER INTAKE ELBOW BS6-PH2	TATA spare parts
573622107101	LIFTING HOOK	TATA spare parts
573622107103	LIFTING HOOK BS6-PH2	TATA spare parts
573622107104	LIFTING HOOK REAR BS6-PH2	TATA spare parts
573622123706	ENGINEA-MTGARM BS6	TATA spare parts
573649100101	SDPF ASSY WITH MIXER BS6	TATA spare parts
573650100104	TRANSITIONPIECEASSYUCL BS6	TATA spare parts
573650100105	TRANSITION PIECE ASSY UCL BS6-PH2	TATA spare parts
573650100107	BENT PIPE ASSY WITH CLAMP BS6-PH2	TATA spare parts
573650100108	PIPE ASSY WITH CLAMP RADIATOR OUTLET BS6	TATA spare parts
573650100109	BRACKET ASSY BS6-PH2	TATA spare parts
573650100110	BRACKET ASSY BS6-PH2	TATA spare parts

573650100113	RADIATOR ASSY WITH FAN MOTOR & SHROUD BS	TATA spare parts
573650100116	FAN MOTOR ASSY WITH SHROUD BS6-PH2	TATA spare parts
573650104201	CLAMP HOSE	TATA spare parts
573650104202	BRACKETHOSECLAMPING BS6	TATA spare parts
573650104203	CLAMP BS6	TATA spare parts
573650104205	CLAMP BS6-PH2	TATA spare parts
573650105801	HOSE	TATA spare parts
573650105811	HOSE RADIATOR TO ENGINE BS6-PH2	TATA spare parts
573650105812	LOWER COOLING LINE BS6-PH2	TATA spare parts
5736810057	GEAR PUMP BLUE	TATA spare parts
5736810058	GEAR PUMP BLACK	TATA spare parts
5736880016	PTO GB600 V2 TYPE	TATA spare parts
573701000101	ENGINE OPTION LIST	TATA spare parts
573701000107	ASSY. ENGINE ISBE5.6 BS6 WOB	TATA spare parts
573701000109	ASSY. ENGINE ISBE5.6 BS6	TATA spare parts
573701000121	ENGINE-OPTION LIST ISBE5.6 BS6 WOB	TATA spare parts
573701000123	ENGINE ASSY-OPTION LIST BS6	TATA spare parts
573701000131	ENGINE-OPTION LIST ISBE5.6 BS6 WOB	TATA spare parts
573701000137	ENGINE ASSY-OPTION LIST BS6	TATA spare parts
573701000143	ASSY. ENGINE ISBE5.6 BS6 WOB	TATA spare parts
573701000155	ENGINE-OPTION LIST BS6	TATA spare parts
573701000157	ENGINE-OPTION LIST ISBE5.6 BS6 WOB	TATA spare parts
573701000161	ENGINE - OPTION LIST BS6	TATA spare parts
573701000165	ASSY. ENGINE ISBE5.6 BS6 WB	TATA spare parts
573701000170	ASSY. ENGINE ISBE5.6 BS6 WB	TATA spare parts
573701000177	ASSY. ENGINE ISBE5.6 BS6 WB	TATA spare parts
573701000183	ENGINE-OPTION LIST ISBE5.6 BS6 WB	TATA spare parts
573701000189	ENGINE ASSY-OPTION LIST BS6	TATA spare parts
573701000194	ENGINE - OPTION LIST BS6	TATA spare parts
573701000196	ENGINE-OPTION LIST BS6	TATA spare parts
573701000204	ENGINE-OPTION LIST ISBE5.6 BS6 WOB	TATA spare parts
573701000206	ASSY. ENGINE ISBE5.6 BS6 WB	TATA spare parts
573701000208	ASSY. ENGINE ISBE5.6 BS6 WOB	TATA spare parts
573701000210	ASSY. ENGINE ISBE5.6 BS6 WOB	TATA spare parts
573701000212	ASSY. ENGINE ISBE5.6 BS6 WB	TATA spare parts
573701000226	ASSY. ENGINE ISBE5.6 BS6 WB	TATA spare parts
573701000230	ASSY. ENGINE ISBE5.6 BS6 WOB	TATA spare parts
573701000240	ENGINE-OPTION LIST BS6	TATA spare parts
573701000242	ENGINE - OPTION LIST BS6	TATA spare parts
573701000244	ENGINE - OPTION LIST BS6	TATA spare parts
573701000246	ENGINE - OPTION LIST ISBE5.6 BS6 WOB	TATA spare parts
573701000248	ENGINE-OPTION LIST BS6	TATA spare parts
573701000262	ENGINE - OPTION LIST BS6	TATA spare parts
573701000266	ENGINE-OPTION LIST BS6	TATA spare parts
573701000270	ENGINE-OPTION LIST BS6	TATA spare parts
573701000274	ENGINE-OPTION LIST BS6	TATA spare parts
573701000286	ENGINE OPTION LIST BS6	TATA spare parts

573701000288	ENGINE OPTION LIST BS6	TATA spare parts
573701000296	ENGINE ASSY BS6-PH2	TATA spare parts
573701000302	ENGINE OPTION LIST BS6-PH2	TATA spare parts
573701000304	ENGINE OPTION LIST BS6-PH2	TATA spare parts
573701000310	ENGINE - OPTION LIST BS6	TATA spare parts
573701000314	ENGINE - OPTION LIST BS6	TATA spare parts
573701000316	ENGINE - OPTION LIST BS6	TATA spare parts
573701000318	ENGINE - OPTION LIST ISBE5.6 BS6 WOB BS6	TATA spare parts
573701000330	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
573701000333	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
573701000340	ENGINE OPTION LIST BS6	TATA spare parts
573701000342	ENGINE OPTION LIST BS6-PH2	TATA spare parts
573701000344	ENGINE-OPTION LIST ISBE5.6 BS6 WOB	TATA spare parts
573701000374	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
573701010159	ENGINE-OPTION LIST BS6-PH2	TATA spare parts
573701173303	BRACKET DIPSTICK MTG BS6	TATA spare parts
573701173304	BRACKET DIPSTICK TUBE MTG BS6-PH2	TATA spare parts
573701990102	BLOCK CYLINDER BS6	TATA spare parts
573701990107	BARE CYLINDER HEAD BS6	TATA spare parts
573701990108	HEAD CYLINDER BS6	TATA spare parts
573701990142	HEAD CYLINDER BS6	TATA spare parts
573701990145	UPPER GASKET KIT ISBE5.6 BS6 WB	TATA spare parts
573701990146	UPPER GASKET KIT ISBE5.6 BS6 WOB	TATA spare parts
573701990147	LOWER GASKET KIT ISBE5.6 BS6	TATA spare parts
573701990148	LONG BLOCK FRONT SUMP W/OB(W/O SSB) BS6	TATA spare parts
573701990149	ASSY. LONG BLOCK ISBE5.6 BS6 FR SUMP W/B	TATA spare parts
573701990151	ASSY. LONG BLOCK ISBE5.6BS6 FR SUMP W/OB	TATA spare parts
573701990171	LONG BLOCK ISBE5.6 W/BRK W/SSB BS6-PH2	TATA spare parts
573701990172	LONG BLOCK ISBE5.6 W/O BRK W/SSB BS6-PH2	TATA spare parts
573701990173	LONG BLOCK ISBE5.6 W/BRK W/O SSB BS6-PH2	TATA spare parts
573701990174	LONG BLOCK ISBE5.6 W/O BRK W/O SSB BS6-P	TATA spare parts
573701993101	BEARING MAIN BS6-PH2	TATA spare parts
573701993102	BEARING MAIN BS6-PH2	TATA spare parts
573701993303	BRACKET BREATHER BS6	TATA spare parts
573701993304	BRACE WIRING BS6	TATA spare parts
573701993306	BRACKET BREATHER BS6	TATA spare parts
573701993401	BUSHING BS6-PH2	TATA spare parts
573701994201	CLAMP HOSE BS6-PH2	TATA spare parts
573701994301	CLIP BS6	TATA spare parts
573701994302	CLIP BS6	TATA spare parts
573701994303	CLIP WIRE RETAINING BS6	TATA spare parts
573701995301	GASKET OIL PAN	TATA spare parts
573701995302	GASKET CYLINDER HEAD BS6	TATA spare parts
573701995303	GASKET FLANGE BS6	TATA spare parts
573701995802	HOSE MOLDED BS6	TATA spare parts
573701995803	BRACE HOSE BS6	TATA spare parts
573701995806	PLAIN HOSE BS6	TATA spare parts



573701996904	TUBE LUB OIL SUCTION BS6	TATA spare parts
573701996906	PIPE AIR TRANSFER BS6	TATA spare parts
573701996908	TUBE BREATHER BS6	TATA spare parts
573701996909	TUBE LUB OIL DRAIN BS6	TATA spare parts
573701997101	PLATE CLAMPING	TATA spare parts
573701997102	PLATE CLAMPING	TATA spare parts
573701997103	CLAMPING PLATE BS6-PH2	TATA spare parts
573701997104	CLAMPING PLATE BS6-PH2	TATA spare parts
573701997105	CLAMPING PLATE BS6-PH2	TATA spare parts
573701997106	CLAMPING PLATE BS6-PH2	TATA spare parts
573701998002	SCREW HEX FLANGE HEAD CAP	TATA spare parts
573701998003	SCREW STUDED FLANGE CAP BS6	TATA spare parts
573701998004	SCREW BANJO CONNECTOR	TATA spare parts
573701998005	SCREW STUDED FLANGE CAP BS6	TATA spare parts
573701999001	VALVE PRESSURE CONTROL BS6-PH2	TATA spare parts
573701999801	STIFFENER CYLINDER BLOCK BS6	TATA spare parts
573701999803	PAN OIL	TATA spare parts
573701999805	INJECTOR BS6	TATA spare parts
573701999808	BRACE TUBE BS6	TATA spare parts
573701999811	PAN OIL BS6	TATA spare parts
573701999812	DIPSTICK BS6	TATA spare parts
573701999814	SUPPORT BRACKET BS6	TATA spare parts
573701999815	DIPSTICK BS6	TATA spare parts
573701999818	SENSOR PRESSURE BS6	TATA spare parts
573701999819	DIPSTICK BS6	TATA spare parts
573701999838	PRESSURE-VACUUM MODULE	TATA spare parts
573701999839	GRADUATED BEAKER	TATA spare parts
573701999843	CHIP REMOVING UNIT	TATA spare parts
573701999844	DIPSTICK INSTALL-REMOVE	TATA spare parts
573701999845	BEAD PROBE	TATA spare parts
573701999846	DIAL BORE GAUGE	TATA spare parts
573701999849	PIPE PLUG SEALANT	TATA spare parts
573701999850	CUP PLUG SEALANT	TATA spare parts
573701999851	CUP PLUG DRIVING TOOL	TATA spare parts
573701999852	CUP PLUG DRIVING TOOL	TATA spare parts
573701999853	CUP PLUG DRIVING TOOL	TATA spare parts
573701999854	DIAL INDICATOR ASSY	TATA spare parts
573701999862	BREATHER CRANKCASE BS6	TATA spare parts
573701999863	STIFFENER BS6-PH2	TATA spare parts
573701999901	INJECTOR ASSY BS6-PH2	TATA spare parts
573703990107	ADAPTER CRANKSHAFT BS6	TATA spare parts
573703990109	FLYWHEEL BS6	TATA spare parts
573703990113	SET PISTONRING STD ISBE5.6 BS6	TATA spare parts
573703990114	BARE PISTON SET STD ISBE5.6 BS6	TATA spare parts
573703990115	KIT MAIN BEARING BS6	TATA spare parts
573703990116	KIT CON ROD BEARING STD W/O SSB BS6	TATA spare parts
573703990117	KIT MAIN BEARING STD W/O SSB BS6	TATA spare parts

573703993101	BEARING CONNECTING ROD BS6-PH2	TATA spare parts
573703993801	HOUSING FLYWHEEL BS6	TATA spare parts
573703994701	COVER REAR BS6	TATA spare parts
573703994702	COVER GEAR BS6	TATA spare parts
573703996601	PISTON ENGINE ISBE5.6 BS6	TATA spare parts
573703996602	PISTON ENGINE BS6-PH2	TATA spare parts
573703997101	PLATE CLAMPING BS6	TATA spare parts
573703999801	CRANKSHAFT ENGINE BS6	TATA spare parts
573703999802	DAMPER VISCOUS VIBRATION BS6	TATA spare parts
573703999806	SPACER CRANKSHAFT BS6	TATA spare parts
573703999808	RING COMPRESSION PISTON ISBE5.6 BS6	TATA spare parts
573703999809	RING COMPRESSION PISTON ISBE5.6 BS6	TATA spare parts
573703999901	HOUSING FLYWHEEL BS6-PH2	TATA spare parts
573703999902	FLYWHEEL BS6-PH2	TATA spare parts
573703999903	ROD ENGINE CONNECTING BS6-PH2	TATA spare parts
573705993301	BRACKET TIMING BS6	TATA spare parts
573705993801	HOUSING GEAR BS6	TATA spare parts
573705994701	COVER VALVE BS6	TATA spare parts
573705994702	COVER VALVE BS6	TATA spare parts
573705994703	COVER VALVE BS6	TATA spare parts
573705995301	GASKET GEAR HOUSING BS6	TATA spare parts
573705995302	GASKET REAR COVER BS6	TATA spare parts
573705995303	GASKET INTEGRATED WIRING BS6-PH2	TATA spare parts
573705997901	CAMSHAFT BS6	TATA spare parts
573705997902	CAMSHAFT BS6	TATA spare parts
573705999801	CAMSHAFT BS6	TATA spare parts
573705999812	ROCKER ARM SUPPORT BS6	TATA spare parts
573705999813	CAMSHAFT BS6	TATA spare parts
573707993301	BRACKET FUEL PLUMBING BS6	TATA spare parts
573707993302	BRACE TUBE BS6	TATA spare parts
573707994301	CLIP BS6	TATA spare parts
573707995801	HOSE FUEL DRAIN	TATA spare parts
573707995802	HOSE FUEL DRAIN	TATA spare parts
573707995805	HOSE FUEL RETURN LINE	TATA spare parts
573707995806	HOSE FUEL RETURN LINE	TATA spare parts
573707995807	HOSE FUEL RETURN LINE	TATA spare parts
573707996901	TUBE FUEL SUPPLY BS6	TATA spare parts
573707996902	TUBE FUEL DRAIN BS6	TATA spare parts
573707996903	TUBE FUEL DRAIN BS6	TATA spare parts
573707996904	TUBE INJECTOR FUEL SUPPLY BS6	TATA spare parts
573707996905	TUBE FUEL DRAIN BS6	TATA spare parts
573707996907	TUBE LUB OIL SUPPLY BS6-PH2	TATA spare parts
573707999001	VALVE PRESSURE CONTROL BS6	TATA spare parts
573707999802	PUMP FUEL BS6	TATA spare parts
573707999803	ACCUMULATOR BS6	TATA spare parts
573707999804	ISOLATOR VIBRATION BS6	TATA spare parts
573707999809	PLUG FUEL TUBE	TATA spare parts

573707999814	Rail Plug ISBe 6.7L & ISBe5.9Ajnky BS4	TATA spare parts
573707999816	COUPLING QUICK CONNECT	TATA spare parts
573707999817	FUEL PUMP GEAR RETENTION TOOL	TATA spare parts
573707999818	KIT-FUEL RETURN FLOW TESTER	TATA spare parts
573707999819	KIT-FUEL PRESSURE GAUGE ADOPTER	TATA spare parts
573707999820	FUEL SYSTEM LEAK TESTER	TATA spare parts
573707999822	KIT-FUEL RETURN FLOW HOSE	TATA spare parts
573707999823	FUEL LINK QUICK DISCONNECT TOOL	TATA spare parts
573707999824	KIT-FUEL PRESSURE GAUGE ADOPTER	TATA spare parts
573707999825	KIT-FUEL SYSTEM CLEAN CARE	TATA spare parts
573707999827	ELBOW PLAIN ADAPTER BS6-PH2	TATA spare parts
573709130101	BRACKET&ASSY& BS6	TATA spare parts
573709130102	KIT-AIR INTAKE ASSY BS6	TATA spare parts
573709130104	KIT-AIR INTAKE ASSY BS6	TATA spare parts
573709130105	AIR CLEANER ASSY BS6	TATA spare parts
573709130106	BRACKET ASSY AIR FILTER MTG BS6	TATA spare parts
573709130107	KIT-AIR FILTER ASSY BS6	TATA spare parts
573709130108	SUPPORT BRACKET BS6	TATA spare parts
573709130109	AIR CLEANER ASSY BS6	TATA spare parts
573709130110	BRACKET ASSY BS6	TATA spare parts
573709130111	BRACKET ASSY BS6	TATA spare parts
573709130112	RESTRICTION INDICATOR PIPE ASSY BS6	TATA spare parts
573709130113	BRACKET ASSY BS6	TATA spare parts
573709130114	KIT-AIR INTAKE ASSY BS6	TATA spare parts
573709130115	KIT-AIR INTAKE ASSY BS6	TATA spare parts
573709130119	PIPE ASSY BS6	TATA spare parts
573709130120	KIT-AIR INTAKE SYSTEM&& BS6	TATA spare parts
573709130122	PIPEASSYINTERMEDIATEHOSETOTCHOSE BS6	TATA spare parts
573709130130	AIRFILTERASSY BS6	TATA spare parts
573709130133	KIT-AIR INTAKE SYSTEM BS6	TATA spare parts
573709130134	PIPE ASSY WITH CLAMP BS6	TATA spare parts
573709130135	ISOLATOR SNORKEL MTG BS6	TATA spare parts
573709130136	BRACKET WITH WELD NUT BS6	TATA spare parts
573709130137	BRACKET WITH WELD NUT BS6	TATA spare parts
573709130139	BRACKET AIR FILTER TO TC PIPE BS6	TATA spare parts
573709130140	BRACKET AIR FILTER OUTLET PIPE MTG BS6	TATA spare parts
573709130141	BRACKET ASSY AIR FILTER MTG BS6	TATA spare parts
573709130142	PIPE ASSY INTERMEDIATE HOSE TO TC HOSE B	TATA spare parts
573709130143	CLAMP ASSY BS6-PH2	TATA spare parts
573709130145	KIT-AIR INTAKE ASSY BS6	TATA spare parts
573709130146	PIPE BS6	TATA spare parts
573709130148	AIRPREFILTERASSY BS6	TATA spare parts
573709130149	BRACKETASSY BS6	TATA spare parts
573709130152	BRACKET ASSY BS6-PH2	TATA spare parts
573709130155	HOSE&CLAMP&T&BOLT.(8140151)& BS6	TATA spare parts
573709130159	BRACKET BS6	TATA spare parts
573709130160	AIRFILTERASSY BS6	TATA spare parts

573709130162	PIPEASSY BS6	TATA spare parts
573709130165	PIPEASSY WITH BRACKET BS6	TATA spare parts
573709130166	BRACKET ASSY BS6-PH2	TATA spare parts
573709130168	KIT-AIR INTAKE SYSTEM BS6	TATA spare parts
573709130178	AIR CLEANER ASSY BS6-PH2	TATA spare parts
573709130179	AIR INTAKE PIPE BS6-PH2	TATA spare parts
573709130187	AIR DUCT ASSY CLEAN BS6	TATA spare parts
573709130188	BRACKET ASSY BS6-PH2	TATA spare parts
573709130190	BRACKET ASSY BS6-PH2	TATA spare parts
573709130199	KIT-AIR INTAKE ASSY BS6-PH2	TATA spare parts
573709130210	BRACKET ASSY BS6-PH2	TATA spare parts
573709133301	BRACKET WITH STRAP BS6	TATA spare parts
573709133302	BRACKET WITH STRAP BS6	TATA spare parts
573709133303	BRACKET WITH STRAP BS6	TATA spare parts
573709133304	BRACKET WITH STRAP BS6	TATA spare parts
573709133308	BRACKET AIR FILTER PIPE TO TC BS6	TATA spare parts
573709134201	CLAMP BS6	TATA spare parts
573709134202	CLAMP HOSE BS6	TATA spare parts
573709135801	PIPE AIR FILTER TO PRE FILTER BS6	TATA spare parts
573709135803	HOSE BS6	TATA spare parts
573709135805	HOSE BS6	TATA spare parts
573709135809	HOSEREDUCER ELBOW BS6	TATA spare parts
573709135810	HOSEREDUCER ELBOW BS6	TATA spare parts
573709135813	HOSEREDUCER BS6	TATA spare parts
573709135814	HOSEREDUCER BS6	TATA spare parts
573709135815	HOSE REDUCER BS6-PH2	TATA spare parts
573709135816	HOSE BS6-PH2	TATA spare parts
573709136901	PIPE BS6	TATA spare parts
573709136903	PIPE AIR INTAKE BS6	TATA spare parts
573709136906	PIPE AIR FILTER TO TC BS6	TATA spare parts
573709136907	PIPE SNORKEL BS6	TATA spare parts
573709136908	PIPE PRE CLEANER TO AIR FILTER BS6	TATA spare parts
573709136909	PIPE AIR FILTER TO TC BS6	TATA spare parts
573709138205	HEAT SHIELD BS6	TATA spare parts
573709138401	SLEEVE BS6	TATA spare parts
573709138701	SPRING STRAP BS6	TATA spare parts
573709139901	SENSOR PRS TEMPERATURE BS6	TATA spare parts
573709139902	RESTRICTION INDICATOR BS6	TATA spare parts
573709139905	RESTRICTION INDICATOR ASSY BS6	TATA spare parts
573709139913	AIR FILTER ELEMENT SAFETY BS6	TATA spare parts
573709139914	AIR FILTER ELEMENT PRIMARY BS6	TATA spare parts
573709139915	CAP SCREW BS6	TATA spare parts
573709139916	CLAMP EVACUATOR VALVE BS6	TATA spare parts
573709139917	SENSOR BS6	TATA spare parts
573709140101	KIT-AIR INTAKE ASSY BS6	TATA spare parts
573709140102	KIT-AIR INTAKE ASSY BS6	TATA spare parts
573709140103	KIT-AIR INTAKE ASSY BS6	TATA spare parts

573709140106	BRACKETASSYAIRFILTERMTG BS6	TATA spare parts
573709140107	BRACKETASSYPRECLEANERMTG BS6	TATA spare parts
573709140110	BRACKET ASSY BS6-PH2	TATA spare parts
573709140112	BRACKET ASSY BS6-PH2	TATA spare parts
573709140113	BRACKET ASSY BS6-PH2	TATA spare parts
573709140114	BRACKET ASSY AIR FILTER MTG BS6-PH2	TATA spare parts
573709140117	GASKET AIR FILTER BODY BS6-PH2	TATA spare parts
573709140118	CLAMP ASSY BS6-PH2	TATA spare parts
573709994301	CLIP BS6	TATA spare parts
573709995301	GASKET CONNECTION BS6	TATA spare parts
573709996901	TUBE FUEL SUPPLY BS6	TATA spare parts
573709996902	TUBE FUEL SUPPLY BS6	TATA spare parts
573709996903	PIPE AIR TRANSFER BS6	TATA spare parts
573709998001	SCREW HEX FLANGE HEAD CAP BS6	TATA spare parts
573709998002	SCREW HEX FLANGE HEAD CAP BS6	TATA spare parts
573709999801	PIPE AIR TRANSFER BS6	TATA spare parts
573709999802	VALVE AIR FUEL THROTTLE BS6	TATA spare parts
573709999804	CONNECTION AIR INTAKE BS6	TATA spare parts
573709999805	CONNECTOR QCK DISCONNECT BS6	TATA spare parts
573709999806	CONNECTION AIR TRANSFER BS6	TATA spare parts
573709999808	TUBE CUTTER	TATA spare parts
573713103101	BRACKET BS6	TATA spare parts
573713103102	BRACKET BS6	TATA spare parts
573713103104	SUPPORT BRACKET BS6	TATA spare parts
573713103106	BRACKET BS6	TATA spare parts
573713103301	BRACKET AIR COMPRESSOR INTAKE PIPE MTG B	TATA spare parts
573713106914	PIPE AIR CLEANER TO AIR COMPRESSOR BS6	TATA spare parts
573713106922	BRACKET BS6	TATA spare parts
573713113301	BRACKET BS6-PH2	TATA spare parts
573713130101	PIPE ASSY WITH CRIMPED HOSE AIR COMP BS6	TATA spare parts
573713130102	PIPE ASSY WITH CRIMPED HOSE AIR COMP BS6	TATA spare parts
573713130103	PIPE ASSY WITH CRIMPED HOSE AIR COMP BS6	TATA spare parts
573713130107	PIPE ASSY WITH CRIMPED HOSE AIR COMP BS6	TATA spare parts
573713130109	PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
573713130111	PIPE ASSY WITH CRIMPED HOSE BS6	TATA spare parts
573713130119	COOLING PIPE ASSY COMPRESSOR INTAKE BS6	TATA spare parts
573713130123	PIPEASSY BS6	TATA spare parts
573713130124	PIPEASSY BS6	TATA spare parts
573713130125	PIPE ASSY AIR FILTER TO AIR COMPRESSOR B	TATA spare parts
573713130131	PIPE ASSY WITH CRIMPED HOSE BS6-PH2	TATA spare parts
573713130140	PIPE ASSY WITH CRIMPED HOSE AIR COMP BS6	TATA spare parts
573713130141	BENT TUBE AIR COMPRESSOR INTAKE BS6-PH2	TATA spare parts
573713130143	PIPE ASSY WITH CRIMPED HOSE BS6-PH2	TATA spare parts
573713135807	HOSE AIR COMPRESSOR TO PIPE BS6	TATA spare parts
573713135810	HOSE BS6-PH2	TATA spare parts
573713135813	HOSE AIR COMPRESSOR TO PIPE BS6	TATA spare parts
573713138201	BRACKET BS6	TATA spare parts

573713990109	BRACE TUBE BS6	TATA spare parts
573713990115	COMPRESSOR AIR BS6	TATA spare parts
573713990117	KIT VALVE PLATE BS6	TATA spare parts
573713990118	HEAD REPAIR KIT BS6	TATA spare parts
573713990119	CRANK CASE REPAIR KIT BS6	TATA spare parts
573713993307	BRACE TUBE BS6	TATA spare parts
573713993309	BRACE TUBE BS6	TATA spare parts
573713993310	BRACE AIR COMPRESSOR BS6	TATA spare parts
573713993311	BRACE AIR COMPRESSOR BS6	TATA spare parts
573713993312	BRACE TUBE BS6	TATA spare parts
573713994301	CLIP BS6	TATA spare parts
573713995802	HOSE FLEXIBLE BS6	TATA spare parts
573713995803	HOSE FLEXIBLE BS6	TATA spare parts
573713996901	TUBE CPR WATER OUTLET BS6	TATA spare parts
573713996902	TUBE CPR WATER OUTLET BS6	TATA spare parts
573713996903	TUBE CPR WATER OUTLET BS6	TATA spare parts
573713996904	TUBE CPR WATER INLET BS6	TATA spare parts
573713996905	TUBE CPR WATER OUTLET BS6	TATA spare parts
573713996906	TUBE CPR WATER OUTLET BS6	TATA spare parts
573713996909	TUBE CPR WATER INLET BS6	TATA spare parts
573713996910	TUBE CPR WATER OUTLET BS6	TATA spare parts
573713996911	TUBE CPR WATER OUTLET BS6	TATA spare parts
573713996912	TUBE CPR WATER INLET BS6	TATA spare parts
573713996913	TUBE CPR WATER OUTLET BS6	TATA spare parts
573713996914	TUBE CPR WATER OUTLET BS6	TATA spare parts
573713996915	TUBE CPR WATER OUTLET BS6	TATA spare parts
573713996916	TUBE CPR WATER INLET BS6	TATA spare parts
573713996918	TUBE LUB OIL SUPPLY BS6-PH2	TATA spare parts
573713998002	SCREW SOCKET HEAD CAP BS6	TATA spare parts
573713999801	SUPPORT AIR COMPRESSOR BS6	TATA spare parts
573713999803	KIT-AIR COMPRESSOR CLEANING	TATA spare parts
573713999901	COMPRESSOR AIR BS6	TATA spare parts
573713999902	REPAIR KIT-PISTON RING BS6	TATA spare parts
573714110108	MODULE DOC INLET BS6 (5.6/F) BS6	TATA spare parts
573714110109	MODULE DPF CATALYST BS6 (5.6/F) BS6	TATA spare parts
573714110111	MODULE DOC INLET BS6 (6.7/H) BS6	TATA spare parts
573714110114	MODULE SCR OUTLET BS6 (5.6/H) BS6	TATA spare parts
573714110115	GASKET CIRCULAR BS6	TATA spare parts
573714110116	CLAMP ASSY,V-BAND BS6	TATA spare parts
573714110118	PLUG BS6	TATA spare parts
573714110119	GASKET IRREGULAR BS6	TATA spare parts
573714110124	DIFFERENTIAL PRESSURE SENSOR BS6	TATA spare parts
573714110125	TEMPERATURE SENSOR BS6 (5.6/6.7/H)	TATA spare parts
573714110126	NOX SENSOR ASSY BS6	TATA spare parts
573714110127	NOX SENSOR BS6 (5.6/6.7/H/V)	TATA spare parts
573714110130	INSULATION BS6 (5.6/6.7/H/F)	TATA spare parts
573714110131	CLAMP BAND BS6 (5.6/6.7/F)	TATA spare parts

573714110132	CABLE STRAP BS6	TATA spare parts
573714110133	BOLT,HEAT SHIELD BS6 (5.6/6.7/V)	TATA spare parts
573714110134	BOLT,HEAT SHIELD BS6 (5.6/6.7/V/F)	TATA spare parts
573714110135	CABLE STRAP BS6	TATA spare parts
573714110136	WIRING HARNESS BS6 (5.6/6.7/H)	TATA spare parts
573714110137	BOLT,HEAT SHIELD BS6 (5.6/6.7/H)	TATA spare parts
573714110138	BOLT,HEAT SHIELD BS6 (5.6/6.7/H)	TATA spare parts
573714110139	CABLE STRAP BS6 (6.7/H)	TATA spare parts
573714110142	MODULE SCR OUTLET BS6 (5.6/F) BS6	TATA spare parts
573714110144	SUPPORT BRACKET BS6 (5.6/6.7/F)	TATA spare parts
573714110145	DP SENSOR SENSING (INLET) BS6(5.6/6.7/F)	TATA spare parts
573714110146	DP SENSOR SENSING (OUTLET)BS6(5.6/6.7/F)	TATA spare parts
573714110147	SUPPORT BRACKET BS6 (5.6/6.7/F)	TATA spare parts
573714110148	NOX SENSOR BS6 (5.6/6.7/F)	TATA spare parts
573714110149	NOX SENSOR BS6 (5.6/6.7/F)	TATA spare parts
573714110150	TEMPERATURE SENSOR BS6 (6.7/F)	TATA spare parts
573714110151	TEMPERATURE SENSOR BS6 (6.7/F)	TATA spare parts
573714110152	HEX FLANGE BOLT BS6 (5.6/6.7/F)	TATA spare parts
573714110154	SUPPORT BRACKET BS6	TATA spare parts
573714110160	PUMP ASSY; DEF DOSE BS6	TATA spare parts
573714110161	AFTER TREATMENT SYSTEM ASSY	TATA spare parts
573714110167	DP SENSOR SENSING (OUTLET) BS6 (5.6/6.7/	TATA spare parts
573714110168	DP SENSOR SENSING (INLET) BS6 (5.6/6.7/V	TATA spare parts
573714110174	MODULE SCR OUTLET BS6 (5.6/6.7/V) BS6	TATA spare parts
573714110175	MODULE DPF CATALYST BS6 (5.6/6.7/V) BS6	TATA spare parts
573714110177	BRACKET BS6 (5.6/6.7/V)	TATA spare parts
573714110178	SUPPORT BRACKET BS6 (5.6/6.7/V)	TATA spare parts
573714110184	MODULE DPF CATALYST BS6 (5.6/H) BS6	TATA spare parts
573714110185	MIXER DIESEL EXHAUST FLUID	TATA spare parts
573714110187	BRACKET BS6 (5.6/6.7/H)	TATA spare parts
573714110188	BRACKET BS6 (5.6/6.7/H) BS6	TATA spare parts
573714110189	DP SENSOR SENSING (OUTLET) BS6 (5.6/6.7/	TATA spare parts
573714110190	DP SENSOR SENSING (INLET) BS6 (5.6/6.7/H	TATA spare parts
573714110192	MODULE DOC INLET BS6 (5.6/6.7/V) BS6	TATA spare parts
573714110193	MIXER DEF BS6 (5.6/6.7/V) BS6	TATA spare parts
573714110194	PLATE, SENSOR BS6 (5.6/6.7/V)	TATA spare parts
573714110195	HEX FLANGE BOLT BS6	TATA spare parts
573714110196	TEMPERATURE SENSOR BS6 (5.6/6.7 V)	TATA spare parts
573714110197	DOSER PUMP UNIT ASSY BS6	TATA spare parts
573714110198	WIRING HARNESS BS6 (5.6/6.7/V)	TATA spare parts
573714110199	DOSING UNIT INJECTOR BS6	TATA spare parts
573714110202	PUMP ASSY UREA DOSE BS6	TATA spare parts
573714110205	MODULE DOC INLET BS6 (5.6/H) BS6	TATA spare parts
573714110206	HEADER DIESEL EXHAUST FLUID TANK BS6	TATA spare parts
573714110207	DEF TANK - HEADER BS6	TATA spare parts
573714110208	TEMPERATURE SENSOR BS6 (6.7/H/F) BS6	TATA spare parts
573714110209	TEMPERATURE SENSOR BS6 (5.6/6.7/F)	TATA spare parts

573714110210	CONDUIT BS6	TATA spare parts
573714110211	CONDUIT BS6	TATA spare parts
573714110212	BRACKET WIRE SUPPORT (Z) BS6	TATA spare parts
573714110213	MIXER DEF BS6 (5.6/6.7/H) BS6	TATA spare parts
573714110214	TEMPERATURE SENSOR BS6 (5.6/6.7/H)	TATA spare parts
573714110215	WIRING HARNESS BS6 (5.6/6.7/H)	TATA spare parts
573714110218	SCR CATALYST ASSY BS6	TATA spare parts
573714110232	MODULE DOC INLET BS6-PH2	TATA spare parts
573714110233	GASKET CIRCULAR BS6-PH2	TATA spare parts
573714110234	MODULE DPF CATALYST BS6-PH2	TATA spare parts
573714110235	CLAMP V BAND BS6-PH2	TATA spare parts
573714110236	DECOMPOSITION PIPE WITH MIXER ASSY	TATA spare parts
573714110237	MODULE SCR OUTLET BS6-PH2	TATA spare parts
573714110238	BRACKET SENSOR SUPPORT BS6-PH2	TATA spare parts
573714110242	MODULE PRESSURE SENSING BS6-PH2	TATA spare parts
573714110243	MODULE PRESSURE SENSING BS6-PH2	TATA spare parts
573714110244	CLAMP BAND BS6-PH2	TATA spare parts
573714110246	HARNESS WIRING BS6-PH2	TATA spare parts
573714110265	MODULE DPF CATALYST BS6-PH2	TATA spare parts
573714110266	DECOMPOSITION PIPE WITH MIXER ASSY BS6-P	TATA spare parts
573714110267	SCR CATALYST ASSY BS6-PH2	TATA spare parts
573714110268	BRACKET SENSOR SUPPORT BS6-PH2	TATA spare parts
573714110269	MODULE PRESSURE SENSING BS6-PH2	TATA spare parts
573714110270	MODULE PRESSURE SENSING BS6-PH2	TATA spare parts
573714110271	HARNESS WIRING BS6-PH2	TATA spare parts
573714110272	CONDUIT ELECTRICAL BS6-PH2	TATA spare parts
573714110273	CONDUIT ELECTRICAL BS6-PH2	TATA spare parts
573714110274	DOC ASSY BS6-PH2	TATA spare parts
573714110276	BRACKET SENSOR SUPPORT BS6-PH2	TATA spare parts
573714110277	BRACKET SENSOR SUPPORT BS6-PH2	TATA spare parts
573714110278	SENSOR TEMPERATURE BS6-PH2	TATA spare parts
573714119919	SOLENOID VALVE ASSY BS6	TATA spare parts
573714119920	FILTER DIESEL EXHAUST FLUID BS6	TATA spare parts
573714119921	DEF TANK - IN TANK FILTER BS6	TATA spare parts
573714600101	INTERCOOLERASSY BS6	TATA spare parts
573714603301	BRACKET BS6	TATA spare parts
573714603807	PIPE ENGINE TO INTERCOOLER BS6	TATA spare parts
573714603808	PIPE INTERCOOLER TO AIR INTAKE PIPE BS6	TATA spare parts
573714605804	HOSEHUMP BS6	TATA spare parts
573714605806	HOSE INTERCOOLER INTAKE BS6-PH2	TATA spare parts
573714605807	HOSE INTERCOOLER OUTLET BS6-PH2	TATA spare parts
573714606803	PIPE INTERCOOLER INLET (MAHLE) BS6	TATA spare parts
573714606804	PIPE INTERCOOLER OUTLET (MAHLE) BS6	TATA spare parts
573714606805	PIPE ASSY IC TO AIR INTAKE ELBOW BS6	TATA spare parts
573714606806	PIPE ASSY TC OUT TO INTERCOOLER BS6	TATA spare parts
573714606906	PIPE TC TO IC BS6	TATA spare parts
573714606908	PIPE TURBOCHARGER TO INTERCOOLER BS6	TATA spare parts



573714606909	PIPE INTERCOOLER TO INTAKE MANIFOLD BS6	TATA spare parts
573714606910	PIPE INTERCOOLER TO TURBOCHARGER BS6	TATA spare parts
573714606916	ELBOW AIR INTAKE IC TO INTAKE MANIFOLD B	TATA spare parts
573714606919	PIPE TC TO INTERCOOLER BS6	TATA spare parts
573714606920	PIPE IC OUT TO AIR INTAKE ELBOW BS6	TATA spare parts
573714609903	INTERCOOLER ASSY BS6	TATA spare parts
573714609904	INTERCOOLER ASSY BS6	TATA spare parts
573714609905	INTERCOOLER ASSY BS6	TATA spare parts
573714609906	INTERCOOLER ASSY BS6	TATA spare parts
573714609907	INTERCOOLER ASSY BS6	TATA spare parts
573714609908	INTERCOOLER ASSY BS6	TATA spare parts
573714990101	MANIFOLD EXHAUST BS6	TATA spare parts
573714990111	ELBOW MALE UNION BS6	TATA spare parts
573714990117	TURBOCHARGER BS6	TATA spare parts
573714990123	AFTER TREATMENT SYSTEM ASSY BS6 (5.6/F)	TATA spare parts
573714990124	AFTER TREATMENT SYSTEM ASSY BS6 (5.6/H)	TATA spare parts
573714990125	AFTER TREATMENT SYSTEM ASSY BS6 (5.6/V)	TATA spare parts
573714990126	AFTER TREATMENT SYSTEM ASSY BS6 (5.6/V)	TATA spare parts
573714990130	TURBOCHARGER BS6-PH2	TATA spare parts
573714990134	FILTER DIESEL EXHAUST FLUID KIT BS6	TATA spare parts
573714990135	HOUSING LIQUID FILTER KIT BS6	TATA spare parts
573714990136	GASKET FILTER KIT BS6	TATA spare parts
573714990137	AFTER TREATMENT SYSTEM ASSY BS6 (5.6/H)	TATA spare parts
573714990138	AFTER TREATMENT SYSTEM BS6-PH2 (5.6/H/T)	TATA spare parts
573714990139	AFTER TREATMENT SYSTEM BS6-PH2 (5.6/H/B)	TATA spare parts
573714990140	AFTER TREATMENT SYSTEM BS6-PH2 (5.6/V/K)	TATA spare parts
573714993301	BRACKET EXH CONNECTION BS6	TATA spare parts
573714993302	BRACKET EXH CONNECTION BS6	TATA spare parts
573714993303	BRACKET EXH CONNECTION BS6	TATA spare parts
573714993304	SUPPORT BRACKET BS6	TATA spare parts
573714993305	BRACKET EXH CONNECTION BS6-PH2	TATA spare parts
573714993307	BRACKET SENSOR SUPPORT BS6-PH2	TATA spare parts
573714993701	MANIFOLD EXHAUST BS6	TATA spare parts
573714994201	CLAMP HOSE BS6-PH2	TATA spare parts
573714995301	GASKET OIL DRAIN BS6	TATA spare parts
573714995302	GASKET BS6	TATA spare parts
573714995303	GASKET BS6	TATA spare parts
573714995305	DOSING UNIT GRAPHITE GASKET BS6	TATA spare parts
573714995801	HOSE PLAIN BS6	TATA spare parts
573714996501	NUT BS6	TATA spare parts
573714996502	NUT BS6-PH2	TATA spare parts
573714996503	NUT BS6-PH2	TATA spare parts
573714996901	TUBE PRESSURE SENSING BS6	TATA spare parts
573714996903	TUBE TUR COOLANT DRAIN BS6	TATA spare parts
573714996904	TUBE TUR COOLANT SUPPLY BS6	TATA spare parts
573714996907	TUBE TUR COOLANT SUPPLY BS6	TATA spare parts
573714996911	TUBE PRESSURE SENSING BS6	TATA spare parts

573714996912	TUBE TUR OIL SUPPLY BS6	TATA spare parts
573714996914	TUBE TUR COOLANT DRAIN BS6	TATA spare parts
573714996915	TUBE TUR OIL SUPPLY BS6	TATA spare parts
573714996916	TUBE TUR COOLANT DRAIN BS6	TATA spare parts
573714996917	TUBE PRESSURE SENSING BS6	TATA spare parts
573714996918	TUBE TUR OIL SUPPLY BS6	TATA spare parts
573714996919	TUBE TUR COOLANT DRAIN BS6	TATA spare parts
573714996920	TUBE TUR OIL SUPPLY BS6-PH2	TATA spare parts
573714996921	PR LINE (SUP TO DOSING MODULE 3700 MM) B	TATA spare parts
573714996922	PR LINE (SUP TO DOSING MODULE 4150 MM) B	TATA spare parts
573714996923	PR LINE (SUP TO DOSING MODULE 1350 MM) B	TATA spare parts
573714996924	RTN LINE (DOSING MODULE TO DEF TANK 1250	TATA spare parts
573714996925	PRESSURE TUBE ASSY BS6	TATA spare parts
573714997201	PLATE BS6	TATA spare parts
573714999801	ELBOW TUBE CONNECTOR BS6	TATA spare parts
573714999805	CONNECTION EXHAUST OUTLET BS6	TATA spare parts
573714999806	CONNECTION EXHAUST OUTLET BS6	TATA spare parts
573714999812	VALVE EXHAUST THROTTLE BS6	TATA spare parts
573714999813	LOCKPLATE BS6	TATA spare parts
573714999815	CONNECTION TUR OIL DRAIN BS6	TATA spare parts
573714999816	SHIELD HEAT BS6	TATA spare parts
573714999817	SHIELD HEAT BS6	TATA spare parts
573714999818	CONNECTION EXHAUST OUTLET BS6	TATA spare parts
573714999819	BLANKET EXH CONNECTION BS6	TATA spare parts
573714999820	SHIELD HEAT BS6	TATA spare parts
573714999821	CONNECTION TUR OIL DRAIN BS6	TATA spare parts
573714999824	VALVE EXHAUST THROTTLE BS6	TATA spare parts
573714999825	CONNECTION ADAPTER BS6	TATA spare parts
573714999830	KIT-TC WASTEGATE PRESSURE SETTING	TATA spare parts
573714999831	KIT-TC ACTUATOR INSPECTION GAUGE	TATA spare parts
573714999850	CONNECTOR BS6	TATA spare parts
573714999851	CONNECTOR BS6	TATA spare parts
573714999852	HOUSING LIQUID FILTER BS6	TATA spare parts
573714999854	INSULATION BS6	TATA spare parts
573714999855	LID HOUSING LIQUID BS6	TATA spare parts
573714999856	KIT - DEF PRESSURE CONNECTOR BS6	TATA spare parts
573714999857	KIT - DEF SUCTION PORT BS6	TATA spare parts
573714999858	KIT - SUPPLY UNIT MAIN FILTER BS6	TATA spare parts
573714999859	KIT - DOSING UNIT INLET SCREEN BS6	TATA spare parts
573714999860	KIT - DAMPER BS6	TATA spare parts
573714999861	HOUSING SUPPLY UNIT MAIN FILTER BS6	TATA spare parts
573714999864	VENTILATION CAP - SU MAIN FILTER HOUSING	TATA spare parts
573714999865	CONNECTION EXHAUST OUTLET BS6	TATA spare parts
573714999874	MODULE SCR OUTLET BS6-PH2	TATA spare parts
573714999901	TURBOCHARGER BS6	TATA spare parts
573714999902	CONNECTION TUR OIL DRAIN BS6	TATA spare parts
573714999903	CONNECTION TUR OIL DRAIN BS6	TATA spare parts

573714999904	TURBOCHARGER BS6	TATA spare parts
573714999905	COVER INTAKE MANIFOLD BS6	TATA spare parts
573715409901	SENSOR TEMPERATURE BS6	TATA spare parts
573715990110	ALTERNATOR BS6	TATA spare parts
573715990113	MOTOR STARTING BS6	TATA spare parts
573715990114	ALTERNATOR BS6	TATA spare parts
573715990116	MODULE ELECTRONIC CONTROL BS6	TATA spare parts
573715990117	HARNESS ETR CNT MDL WRG BS6	TATA spare parts
573715990118	WIRING HARNESS ETR CNT MDL BS6	TATA spare parts
573715990119	KIT-FASTENERS BS6	TATA spare parts
573715990121	ALTERNATOR BS6	TATA spare parts
573715990129	FASTENERS KIT BS6-PH2	TATA spare parts
573715990130	RELAY ASSEMBLY KIT BS6-PH2	TATA spare parts
573715990131	SELAING KIT BS6-PH2	TATA spare parts
573715993301	BRACE WIRING BS6	TATA spare parts
573715993302	BRACKET ETR CNT MODULE BS6	TATA spare parts
573715993303	BRACE WIRING BS6	TATA spare parts
573715993304	BRACE ALTERNATOR	TATA spare parts
573715993305	BRACE ALTERNATOR	TATA spare parts
573715993306	BRACKET MOUNTING BS6	TATA spare parts
573715993307	BRACE WIRING BS6	TATA spare parts
573715993308	BRACE WIRING BS6	TATA spare parts
573715993309	BRACE WIRING BS6	TATA spare parts
573715993313	BRACKET BS6	TATA spare parts
573715993314	BRACKET BS6 (6.7/F) BS6	TATA spare parts
573715993315	PLATE CLAMPING BS6	TATA spare parts
573715993316	PLATE CLAMPING BS6	TATA spare parts
573715993317	SUPPORT ALTERNATOR BS6	TATA spare parts
573715994701	COVER COMPONENT BS6	TATA spare parts
573715994702	COVER REAR BS6	TATA spare parts
573715997701	SEAL BS6	TATA spare parts
573715998002	SCREW STUDDED FLANGE CAP BS6	TATA spare parts
573715998003	SCREW STUDDED FLANGE CAP BS6	TATA spare parts
573715998004	COUNTERSUNK SCREW BS6	TATA spare parts
573715998005	HEXAGON SCREW BS6	TATA spare parts
573715999802	SENSOR PRESSURE BS6	TATA spare parts
573715999804	SENSOR POSITION BS6	TATA spare parts
573715999805	WIRE GROUND BS6	TATA spare parts
573715999806	ADAPTER	TATA spare parts
573715999807	SENSOR TEMPERATURE BS6	TATA spare parts
573715999808	MODULE BATTERY BS6	TATA spare parts
573715999811	SENSOR POSITION BS6	TATA spare parts
573715999815	HARNESS ETR CNT MDL WRG BS6	TATA spare parts
573715999816	HARNESS ETR CNT MDL WRG BS6	TATA spare parts
573715999817	HARNESS ETR CNT MDL WRG BS6	TATA spare parts
573715999818	HARNESS ETR CNT MDL WRG BS6	TATA spare parts
573715999819	TERMINAL REMOVING TOOL	TATA spare parts

573715999820	TERMINAL REMOVING TOOL	TATA spare parts
573715999822	DIGITAL THERMOMETER	TATA spare parts
573715999825	CLAMP CURRENT PROBE	TATA spare parts
573715999829	TEST LEAD MALE	TATA spare parts
573715999830	TEST LEAD FEMALE	TATA spare parts
573715999831	TEST LEAD MALE	TATA spare parts
573715999832	TEST LEAD FEMALE	TATA spare parts
573715999833	TEST LEAD MALE	TATA spare parts
573715999834	TEST LEAD FEMALE	TATA spare parts
573715999835	CABLE BENCHTOP CALIBRATION	TATA spare parts
573715999839	KIT-WIRING REPAIR	TATA spare parts
573715999840	HEAT GUN	TATA spare parts
573715999841	SOCKET DEEP WELL	TATA spare parts
573715999845	TORCH	TATA spare parts
573715999849	WIRING HARNESS BS6 (6.7/F)	TATA spare parts
573715999850	TEMPERATURE SENSOR BS6 (5.6/6.7/F)	TATA spare parts
573715999851	HARNESS ETR CNT MDL WRG BS6	TATA spare parts
573715999853	DRIVE END SHIELD BS6	TATA spare parts
573715999854	STOP RING BS6	TATA spare parts
573715999855	REATINER BS6	TATA spare parts
573715999856	OVERRUNNING-CLUTCH DRIVE BS6	TATA spare parts
573715999857	FORK LEVER BS6	TATA spare parts
573715999858	BEARING PEDESTAL BS6	TATA spare parts
573715999859	STARTING RELAY BS6	TATA spare parts
573715999860	PLANETARY GEAR TRAIN BS6	TATA spare parts
573715999861	ARMATURE BS6	TATA spare parts
573715999862	POLE HOUSING BS6	TATA spare parts
573715999863	SOLENOID SWITCH BS6	TATA spare parts
573715999864	SEALING CAP BS6	TATA spare parts
573715999865	ROTOR BS6	TATA spare parts
573715999866	STATOR ASSY. BS6	TATA spare parts
573715999867	RECTIFIER ARRANGEMENT BS6	TATA spare parts
573715999868	REGULATOR ASSY BS6	TATA spare parts
573715999869	PROTECTION CIRCUIT BS6	TATA spare parts
573715999870	SHIELD COMMUTATOR END BS6	TATA spare parts
573715999872	RECTIFIER BS6-PH2	TATA spare parts
573715999873	PROTECTION CAP BS6-PH2	TATA spare parts
573715999874	HARNESS ETR CNT MDL WRG BS6-PH2	TATA spare parts
573715999875	HARNESS ETR CNT MDL WRG BS6-PH2	TATA spare parts
573715999877	POSITION SENSOR BS6	TATA spare parts
573715999879	FIXING BRACKET ASSEMBLY BS6-PH2	TATA spare parts
573715999882	OUTPUT SHAFT ASSEMBL BS6-PH2	TATA spare parts
573715999883	PLANETARY GEAR ASSEMBLY BS6-PH2	TATA spare parts
573715999886	CE BRACKET ASSEMBLY BS6-PH2	TATA spare parts
573715999887	CABLE ASSEMBLY FINAL BS6-PH2	TATA spare parts
573715999901	INTER BRACKET ASSEMBLY BS6-PH2	TATA spare parts
573715999903	PINION KIT BS6-PH2	TATA spare parts

573718995301	GASKET FILTER HEAD BS6	TATA spare parts
573718995302	GASKET FILTER HEAD BS6	TATA spare parts
573718998001	SCREW STUDED FLANGE CAP BS6	TATA spare parts
573718999807	CARTRIDGE LUB OIL FILTER BS6	TATA spare parts
573718999808	CORE COOLER BS6	TATA spare parts
573718999810	HEAD LUB OIL FILTER BS6	TATA spare parts
573718999811	BANJO CONNECTOR	TATA spare parts
573718999813	LUBRIPLATE	TATA spare parts
573718999815	CARTRIDGE LUBRICATION OIL FILTER BS6	TATA spare parts
573718999901	HEAD LUB OIL FILTER BS6	TATA spare parts
573718999902	PUMP LUBRICATING OIL BS6	TATA spare parts
573720153301	BRACKET WIRING HARNESS MTG BS6	TATA spare parts
573720990106	FAN ENGINE BS6	TATA spare parts
573720990112	FAN ASSY WITH E-VISCOUS CLUTCH BS6	TATA spare parts
573720990113	ASSY FAN ENGINE BS6	TATA spare parts
573720990114	ASSY FAN ENGINE BS6	TATA spare parts
573720990115	ASSY FAN ENGINE BS6	TATA spare parts
573720993302	BRACE TUBE FAN W/H BS6	TATA spare parts
573720993303	BRACE WIRING BS6	TATA spare parts
573720993304	BRACKET IDLER PULLEY BS6-PH2	TATA spare parts
573720994301	CLIP BS6	TATA spare parts
573720996302	BELT V RIBBED BS6	TATA spare parts
573720996303	BELT V RIBBED BS6	TATA spare parts
573720996304	BELT V RIBBED	TATA spare parts
573720996305	BELT V RIBBED BS6-PH2	TATA spare parts
573720996306	BELT V RIBBED BS6-PH2	TATA spare parts
573720996307	BELT V RIBBED BS6-PH2	TATA spare parts
573720999801	COUPLING PLAIN HOSE BS6	TATA spare parts
573720999802	SPACER FAN PILOT BS6	TATA spare parts
573720999803	CONNECTION WATER INLET BS6	TATA spare parts
573720999806	SUPPORT FAN BS6	TATA spare parts
573720999808	CLUTCH FAN BS6	TATA spare parts
573720999809	FAN ENGINE BS6	TATA spare parts
573720999810	CONNECTION WATER INLET BS6	TATA spare parts
573720999811	HARNESS WIRING BS6	TATA spare parts
573720999812	CLUTCH FAN BS6	TATA spare parts
573720999814	CONNECTION WATER INLET BS6	TATA spare parts
573720999817	CONNECTION WATER INLET BS6	TATA spare parts
573720999818	CLUTCH FAN BS6-PH2	TATA spare parts
573720999819	FAN ENGINE BS6	TATA spare parts
573720999820	KIT WIRING HARNESS BS6-PH2	TATA spare parts
573720999821	FAN ENGINE BS6	TATA spare parts
573720999822	CLUTCH FAN BS6	TATA spare parts
573720999823	HARNESS WIRING BS6	TATA spare parts
573720999901	PUMP WATER BS6	TATA spare parts
573723113201	HEX FLANGE BOLT BS6	TATA spare parts
573723999801	SUPPORT BRACKET BS6	TATA spare parts

57375009901	ELBOW HOSE ASSY WATER INTAKE BS6-PH2	TATA spare parts
573750010104	FILLER PIPE ASSY BS6	TATA spare parts
573750010105	FILLER PIPE ASSY BS6	TATA spare parts
573750010106	BRACKET ASSY FILLER PIPE SUPPORT BS6	TATA spare parts
573750010109	BRACKET FILLER PIPE SUPPORT BS6	TATA spare parts
573750010110	SUPPORT BRACKET BS6	TATA spare parts
573750010115	BRACKET ASSY BS6-PH2	TATA spare parts
573750010117	AUX HOSE ASSY BS6-PH2	TATA spare parts
573750010118	SUPPORT BRACKET BS6-PH2	TATA spare parts
573750010119	BRACKET ASSY BS6-PH2	TATA spare parts
573750010120	BRACKET ASSY BS6-PH2	TATA spare parts
573750010121	BRACKET ASSY BS6-PH2	TATA spare parts
573750010122	BRACKET ASSY BS6-PH2	TATA spare parts
573750010123	BRACKET ASSY BS6-PH2	TATA spare parts
573750010124	BRACKET ASSY BS6-PH2	TATA spare parts
573750100106	RADIATOR ASSY BS6	TATA spare parts
573750100109	PIPE ASSY ENGINE INTAKE BS6	TATA spare parts
573750100110	ENGINE COOLING SYSTEM ASSY BS6	TATA spare parts
573750100112	RADIATOR ASSY WITH FRAME BS6	TATA spare parts
573750100115	COOLING SYSTEM BS6	TATA spare parts
573750100116	RADIATOR ASSY BS6	TATA spare parts
573750100122	COOLING SYSTEM BS6	TATA spare parts
573750100127	COOLING SYSTEM BS6	TATA spare parts
573750100132	COOLING SYSTEM BS6	TATA spare parts
573750100136	ENGINE COOLING SYSTEM ASSY BS6	TATA spare parts
573750100137	RADIATOR ASSY BS6	TATA spare parts
573750100139	PIPE RADIATOR HOSE TO WATER PUMP HOSE BS	TATA spare parts
573750100140	RADIATOR ASSY BS6	TATA spare parts
5737501001400A	RADIATOR ASSY BS6	TATA spare parts
573750100142	COOLING SYSTEM ASSY BS6	TATA spare parts
573750100143	ENGINE COOLING SYSTEM ASSY BS6	TATA spare parts
573750100151	PIPE RADIATOR TO RETARDER BS6	TATA spare parts
573750100152	PIPE RADIATOR TO RETARDER BS6	TATA spare parts
573750100153	PIPE RETARDER TO ENGINE BS6	TATA spare parts
573750100154	PIPE RETARDER TO ENGINE BS6	TATA spare parts
573750100161	PIPE RETARDER TO ENGINE BS6	TATA spare parts
573750100162	SUPPORT BRACKET BS6	TATA spare parts
573750100177	COOLING SYSTEM ASSY BS6	TATA spare parts
573750100190	PIPE ASSY ENGINE INTAKE BS6	TATA spare parts
573750100192	COOLING SYSTEM BS6-PH2	TATA spare parts
573750100194	COOLING SYSTEM BS6	TATA spare parts
573750100209	ENGINE COOLING SYSTEM ASSY BS6-PH2	TATA spare parts
573750100212	PIPE RADIATOR TO RETARDER BS6-PH2	TATA spare parts
573750100213	PIPE RETARDER TO ENGINE BS6-PH2	TATA spare parts
573750100214	PIPE RETARDER TO ENGINE BS6-PH2	TATA spare parts
573750100216	RADIATOR ASSY WITH BRACKET BS6-PH2	TATA spare parts
573750100217	PIPE-RADIATOR TO RETARDER BS6	TATA spare parts

573750100218	PIPE RADIATOR TO RETARDER BS6-PH2	TATA spare parts
573750100222	PIPE- ENG TO RAD BS6	TATA spare parts
573750105805	COOLENT HOSE FOR CNG REGULATOR - 1000 MM	TATA spare parts
573750105807	HOSE BS6-PH2	TATA spare parts
573750105808	HOSE ASSY BS6-PH2	TATA spare parts
573750105809	HOSE BS6-PH2	TATA spare parts
573750105810	HOSE INTERCOOLER INTAKE BS6-PH2	TATA spare parts
573750105811	HOSE PLUG BS6-PH2	TATA spare parts
573750106902	PIPE (ENGINE TO RADIATOR) BS6	TATA spare parts
573750106907	PIPE BS6	TATA spare parts
573750106922	HOSE HUMP ENGINE TO INTERCOOLER BS6	TATA spare parts
573750106929	BRACKET BS6	TATA spare parts
573750106930	BENT HOSE PIPE BS6	TATA spare parts
573750106931	HOSE BS6	TATA spare parts
573750106934	BRACKET BS6	TATA spare parts
573750106935	BRACKET BS6	TATA spare parts
573750106950	PIPE RADIATOR BOTTOM BS6-PH2	TATA spare parts
573750106951	HOSE RADIATOR TO ENGINE INTAKE BS6	TATA spare parts
573750106952	HOSE BS6-PH2	TATA spare parts
573750106953	HOSE HUMP ENGINE TO INTERCOOLER BS6	TATA spare parts
573750106960	SUPPORT BRACKET BS6-PH2	TATA spare parts
573750106961	BRACKET BS6-PH2	TATA spare parts
573750110103	BRACKET ASSY RADIATOR FRAME SIDE MTG BS6	TATA spare parts
573750110104	BRACKET ASSY RADIATOR FRAME SIDE MTG BS6	TATA spare parts
573750110106	TIE ROD ASSY WITH BUSH BS6	TATA spare parts
573750110107	BRACKET ASSY RADIATOR FRAME SIDE MTG BS6	TATA spare parts
573750115802	HOSE BS6	TATA spare parts
573750115805	HOSE ASSY RADIATOR TO ENGINE BS6	TATA spare parts
573750115806	HOSE BS6	TATA spare parts
573750115808	HOSE RADIATOR INTAKE BS6	TATA spare parts
573750115810	RUBBER HOSE LCL RAD OUTLET TO METAL TUBE	TATA spare parts
573750115812	RUBBER HOSE LCL WATER PUMP SIDE BS6	TATA spare parts
573750115814	HOSE RADIATOR BOTTOM TO ENGINE BS6	TATA spare parts
573750115815	HOSE RADIATOR BOTTOM TANK TO ENGINE BS6	TATA spare parts
573750115816	RUBBER HOSE LCL WATER PUMP SIDE BS6	TATA spare parts
573750116902	VENT TUBE ASSY AUX WATER TANK TO ENGINE	TATA spare parts
573750116904	VENT TUBE ASSY AUX WATER TANK TO ENGINE	TATA spare parts
573750116905	WATER FILLER PIPE AWT TO RADIATOR BS6	TATA spare parts
573750116906	VENT TUBE ASSY AUX WATER TANK TO ENGINE	TATA spare parts
573750116908	PIPE ENGINE TO RADIATOR BS6	TATA spare parts
573750116909	WATER FILLER PIPE AWT TO RADIATOR BS6	TATA spare parts
573750116911	PIPE ASSY LCL WATER PUMP BS6-PH2	TATA spare parts
573750116912	VENT TUBE ASSY AUX WATER TANK TO ENGINE	TATA spare parts
573750400106	SUPPORT BRACKET BS6-PH2	TATA spare parts
573750400107	BRACKET SUPPORT PIPE BS6-PH2	TATA spare parts
573750400108	BRACKET ASSY BS6-PH2	TATA spare parts
573750403301	PLATE BS6	TATA spare parts

573750403308	BRKT PIPE LT RAD OUT STRUCTURE BS6-PH2	TATA spare parts
573750406903	TIERODBS6	TATA spare parts
573750407501	RUBBERBUFFERBS6	TATA spare parts
573750506302	FAN SHROUD (MAHLE) BS6	TATA spare parts
573750506303	FAN SHROUD BS6	TATA spare parts
573750506304	FANSHROUDBS6	TATA spare parts
573750506305	FAN SHROUD BS6	TATA spare parts
573750506306	FAN SHROUD BS6	TATA spare parts
573750506309	FAN SHROUD BS6	TATA spare parts
573750506310	FAN SHROUD BS6	TATA spare parts
573750506313	FAN SHROUD BS6	TATA spare parts
5737810021	FILTER ELEMENT	TATA spare parts
5737810023	FILTER	TATA spare parts
5737810024	CARBON	TATA spare parts
5737810025	CARBON	TATA spare parts
5737810026	CARBON SPRING	TATA spare parts
5737810027	CARBON SPRING	TATA spare parts
5737810028	EXHAUST PIPE	TATA spare parts
5737810033	COMP DELIVERY PIPE 10 CUM	TATA spare parts
5737810035	BEARING	TATA spare parts
5737810036	BEARING	TATA spare parts
5737810037	BEARING	TATA spare parts
5737810038	BEARING	TATA spare parts
5737810039	BEARING	TATA spare parts
5737810059	EXHAUST PIPE	TATA spare parts
5737810061	ASSY EXHAUST PIPE	TATA spare parts
5737810063	INTAKE COVER	TATA spare parts
5737810064	EXHAUST COVER S	TATA spare parts
5737810065	EXHAUST COVER H	TATA spare parts
580126103806	REAR COVER (3.3 THK.)	TATA spare parts
580126103806_niu3	REAR COVER (3.3 THK.)	TATA spare parts
580126106302	OIL COLLECTOR (FRONT HALF)	TATA spare parts
580126106302_niu1	OIL COLLECTOR (FRONT HALF)	TATA spare parts
580126106305	OIL CHANNEL (REAR HALF)	TATA spare parts
580126106305_niu1	OIL CHANNEL (REAR HALF)	TATA spare parts
580126106306	OIL COLLECTOR FRONT HALF	TATA spare parts
580126106306_niu1	OIL COLLECTOR FRONT HALF	TATA spare parts
580126106307	OIL COLLECTOR (REAR COVER)	TATA spare parts
580126106308	BREATHER CAP	TATA spare parts
580126106308_niu1	BREATHER CAP	TATA spare parts
580126108204	BRACKET (CABLE ANCHORING)	TATA spare parts
580126108204_NIU1	BRACKET (CABLE ANCHORING)	TATA spare parts
580126108206	CAP SHIFTER SHAFT	TATA spare parts
580126108206_niu1	CAP SHIFTER SHAFT	TATA spare parts
580126200107	SUB ASSY 2ND GEAR (LASER WELD VERSION) S	TATA spare parts
580126205410	SHIFTER SLEEVE (1ST/2ND SPEED)	TATA spare parts
580126205415	4TH GEAR LAYSHAFT ( RATIO : 26/31)	TATA spare parts



580126205419	REVERSE GEAR AND SHFTER SLEEVE 1ST / 2ND	TATA spare parts
580126208601	SPACER LAYSHAFT	TATA spare parts
580126250111	SUB ASSY 4TH GEAR I/P SHAFT 0.838(26/31)	TATA spare parts
580126253102	DEEP GROOVE BALL BRG WITH SNAP RING GROO	TATA spare parts
580126253103	BALL BEARING (I/S FRT. END)	TATA spare parts
580126253104	DEEP GROOVE BALL BEARING M/S TATA STEEL	TATA spare parts
580126253105	DEEP GROOVE BALL BEARING WITH SNAP RING	TATA spare parts
580126253105_niu3	DEEP GROOVE BALL BEARING WITH SNAP RING	TATA spare parts
580126253801	SYNCHRO CONE	TATA spare parts
580126254603	SHIFTER SLEEVE (3RD/4TH SPEED)	TATA spare parts
580126254604	ENGAGING GEAR (SINT SOFT VERSION)	TATA spare parts
580126254606	ENGAGING GEAR(M/S SUNDRAM FASTENERS LTD	TATA spare parts
580126254609	SHIFTER SLEEVE 3RD/4TH SPEED	TATA spare parts
580126254610	ENGAGING GEAR,1ST/2ND SPEED	TATA spare parts
580126257801	OIL SEAL INPUT SHAFT	TATA spare parts
580126257801_niu1	OIL SEAL INPUT SHAFT	TATA spare parts
580126257802	OIL SEAL INPUT SHAFT (M/S SIGMA FREUDENB	TATA spare parts
580126258602	SPACER INPUT SHAFT	TATA spare parts
580126258602_NIU1	SPACER INPUT SHAFT	TATA spare parts
580126258603	CIRCLIP (THK 1.95)	TATA spare parts
580126258603_niu1	CIRCLIP (THK 1.95)	TATA spare parts
580126258604	CIRCLIP (THK 2 )	TATA spare parts
580126258605	CIRCLIP (THK 2.05)	TATA spare parts
580126258606	CIRCLIP ( THK 2.10 )	TATA spare parts
580126258607	CIRCLIP (THK 2.15)	TATA spare parts
580126258608	CIRCLIP (THK 2.2)	TATA spare parts
580126258609	CIRCLIP (THK 2.25)	TATA spare parts
580126258610	CIRCLIP (THK 2.3)	TATA spare parts
580126258611	SNAP RING	TATA spare parts
580126258611_niu1	SNAP RING	TATA spare parts
580126258612	SNAP RING (2 THK)	TATA spare parts
580126258612_NIU1	SNAP RING (2 THK)	TATA spare parts
580126258613	SNAP RING (2.05 THK)	TATA spare parts
580126258614	SNAP RING (2.10 THK)	TATA spare parts
580126258615	SNAP RING (2.15 THK)	TATA spare parts
580126258616	SNAP RING (2.2 THK.)	TATA spare parts
580126258617	SNAP RING (2.25 THK)	TATA spare parts
580126258618	SNAP RING (2.3 THK)	TATA spare parts
580126258619	SNAP RING (2.35 THK)	TATA spare parts
580126258620	SNAP RING (2.4 THK)	TATA spare parts
580126258621	SNAP RING (2.45 THK)	TATA spare parts
580126258622	SNAP RING (2.5 THK)	TATA spare parts
580126258623	SNAP RING (1.9 THK)	TATA spare parts
580126258624	SNAP RING (2.6 THK)	TATA spare parts
580126258625	SNAP RING (2.7 THK)	TATA spare parts
580126259901	CARRIER	TATA spare parts
580126259901_NIU1	CARRIER	TATA spare parts

580126259902	CARRIER (M/S SUNDRUM FASTNERS LTD)	TATA spare parts
580126259902_niu1	CARRIER	TATA spare parts
580126303101	BALL BEARING	TATA spare parts
580126303102	DEEP GROOVE BALL BEARING (M/S TATA STEEL	TATA spare parts
580126303701	DIFFERENTIAL HOUSING	TATA spare parts
580126305406	BEVEL PINION (M/S SONA OKEGAWA PRECISION	TATA spare parts
580126305407	SIDE BEVEL GEAR (M/S SONA OKEGAWA PRECIS	TATA spare parts
580126307801	OIL SEAL (DIFFERENTIAL HOUSING)(M/S SIGM	TATA spare parts
580126307801_niu1	OIL SEAL (DIFFERENTIAL HOUSING)	TATA spare parts
580126307901	SPIDER ( ASSEMBLY DIFFERENTIAL )	TATA spare parts
580126308201	SPEED DETECT GEAR (ELECTRONIC)	TATA spare parts
580126308201_niu1	SPEED DETECT GEAR (ELECTRONIC)	TATA spare parts
580126308301	SHIM (ASSEMBLY DIFF.) 0.05 THK	TATA spare parts
580126308302	SHIM (DIFF ASSEMBLY) 0.075 THK	TATA spare parts
580126308303	SHIM (ASSEMBLY DIFF.) 0.125 THK	TATA spare parts
580126308304	SHIM (ASSEMBLY DIFF.) 0.25 THK	TATA spare parts
580126308305	SHIM (ASSEMBLY DIFF.) 0.3 THK	TATA spare parts
580126308306	SHIM (ASSEMBLY DIFF.) 0.38 THK	TATA spare parts
580126308308	SHIM (ASSEMBLY DIFF.) 0.45 THK	TATA spare parts
580126308309	SHIM (ASSYEMBLY DIFF.) 0.5 THK	TATA spare parts
580126350102	SUB ASSY REV IDLER GEAR(BIMETALIC BUSH)	TATA spare parts
580126353402	BIMETALIC BUSH (SUBASSY REV. IDLER GEAR	TATA spare parts
580126353403	BIMETALIC BUSH	TATA spare parts
580126356301	SPACER (REVERSE IDLER GEAR SHAFT)	TATA spare parts
580126357902	SHAFT (REVERSE IDLER)	TATA spare parts
580126510109	ASSY. REVERSE LEVER	TATA spare parts
580126510109_niu1	ASSY. REVERSE LEVER	TATA spare parts
580126513707	SHIFTER FINGER (REVERSE IDLER GEAR)	TATA spare parts
580126513708	SHIFTER DOG (REVERSE IDLER GEAR)	TATA spare parts
580126513709	SHIFTER DOG(REVERSE IDLER GEAR)	TATA spare parts
580126513710	SHIFTER FINGER (REVERSE IDLER GEAR)	TATA spare parts
580126513728	SHIFTER FINGER (REVERSE IDLER GEAR)	TATA spare parts
580126513729	SHIFTER DOG (REVERSE IDLER GEAR)	TATA spare parts
580126513803	SHIFTER FORK (1/2) INTEGRAL	TATA spare parts
580126513803_niu3	SHIFTER FORK (1/2) INTEGRAL	TATA spare parts
580126513806	SHIFTER FORKE (3/4) INTEGRAL	TATA spare parts
580126513809	BRACKET (REVERSE IDLER SHAFT LEVER)	TATA spare parts
580126516702	PIVOT PIN REVERSE IDLER LEVER	TATA spare parts
580126517904	SHIFTER SHAFT 1ST/2ND SPEED	TATA spare parts
580126517905	SHIFTER SHAFT (3RD/4TH SPEED)	TATA spare parts
580126517906	SHIFTER SHAFT (REVERSE SPEED)	TATA spare parts
580126517906_niu1	SHIFTER SHAFT (REVERSE SPEED)	TATA spare parts
580126519901	BARREL (REVERSE DETENT)	TATA spare parts
580126519901_niu1	BARREL (REVERSE DETENT)	TATA spare parts
580126700107	ASSEMBLY TOP COVER (COMPLETE)	TATA spare parts
580126700109	ASSY SELECTOR SHIFTER SHAFT	TATA spare parts
580126700110	SUBASSY BELL CRANK LEVER (SELECTION)	TATA spare parts

580126703406	BUSH (SELECTOR SHIFTER SHAFT) M/S MENON	TATA spare parts
580126703406_niu18	BUSH (SELECTOR SHIFTER SHAFT)	TATA spare parts
580126703702	SELECTION AND SHIFTING FINGER	TATA spare parts
580126703702_niu1	SELECTION AND SHIFTING FINGER	TATA spare parts
580126703703	SELECTION AND SHIFTING FINGER	TATA spare parts
580126703704	SELECTION AND SHIFTING FINGER	TATA spare parts
580126703802	TOP COVER HOUSING	TATA spare parts
580126706301	OIL FILLER PLUG CUM BREATHER	TATA spare parts
580126706302	DUST CAP	TATA spare parts
580126706303	COLLER WASHER ASSY TOP COVER (SELECTOR L	TATA spare parts
580126706703	PIN ( ASSY TOP COVER TO SEL. LEVER)	TATA spare parts
580126706703_NIU1	PIN ( ASSY TOP COVER TO SEL. LEVER)	TATA spare parts
580126706705	PIN (INTERLOCK)	TATA spare parts
580126707701	BELLOW SELECTOR SHIFTER	TATA spare parts
580126708203	SPACER - SELECTOR / SHIFTER SHAFT	TATA spare parts
580126708203_NIU1	SPACER - SELECTOR / SHIFTER SHAFT	TATA spare parts
580126708204	2UP (SELECTOR SHIFTER SHAFT)	TATA spare parts
580126708204_niu1	CUP (SELECTOR SHIFTER SHAFT)	TATA spare parts
580126708206	INTERLOCK PIECE	TATA spare parts
580126708206_niu1	INTERLOCK PIECE	TATA spare parts
580126708208	PLATE TOP COVER	TATA spare parts
580126708209	SPACER SELECTOR SHIFTER SHAFT	TATA spare parts
580126708701	SPRING (REV. DETENT)	TATA spare parts
580126708701_niu3	SPRING (REV. DETENT)	TATA spare parts
580126708702	SPRING OUTER ( CENTRAL DETENT )	TATA spare parts
580126708702_niu3	SPRING OUTER ( CENTRAL DETENT )	TATA spare parts
580126708704	SPRING (1ST & 2ND SELECTION)	TATA spare parts
580126708704_niu3	SPRING (1ST & 2ND SELECTION)	TATA spare parts
580126708705	SPRING ( REV. SELECTION )	TATA spare parts
580126708705_NIU1	SPRING ( REV. SELECTION )	TATA spare parts
580126709903	BARREL (CENTRAL DETENT)	TATA spare parts
580126800113	ASSY GSL KNOB	TATA spare parts
580126806313	CLIP	TATA spare parts
580126806314	SHIFT LOCKING BUSH	TATA spare parts
580126806315	SELECT LOCKING BUSH	TATA spare parts
580126808203	MOUNTING CLIP (M/S TATA FICOSA)	TATA spare parts
580126808701	RETENTION SPRING	TATA spare parts
580233000107	ASSY.FA-207 6.49(28/15) 2059 TRK 888 FR	TATA spare parts
580233000110	ASSY.FA207-LHD CTIS 6.49(28/15) 2060TRK	TATA spare parts
580233000110AE	ASSY.FA207-LHD CTIS 6.49(28/15) 2060TRK	TATA spare parts
580233000111	ASSY.FA207-CTIS FRONT FORWARD	TATA spare parts
580233000112	ASSY.FA207-CTIS THRO' DRIVE	TATA spare parts
580233000113	ASSY.FA207-CTIS 6.49(28/15) W/ NON ABS	TATA spare parts
580233000115	ASSY.FA207-LHD CTIS 6.49(28/15) 2060TRK	TATA spare parts
580233000115AE	ASSY.FA207- 6.49(28/15) -1628	TATA spare parts
580233000117	ASSY.FA207-CTIS FR/FWD 7.24(25/12) T180	TATA spare parts
580233000118	ASSY FA207-CTIS THRO DRIVE 7.24 ABS T180	TATA spare parts

580233000121	ASSY.FA207-RHD CTIS 6.49(28/15) ABS T180	TATA spare parts
580233000130	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
580233000133	FRONT AXLE ASSY WITH BRAKE FRT FWD	TATA spare parts
580233000134	FRONT AXLE ASSY WITH BRAKE FRT RWD	TATA spare parts
580233000137	FRONT AXLE ASSY WITH BRAKE ABS BS6-PH2	TATA spare parts
580233150103	ASSY FA207 COMP W/STUDS & DOWELS	TATA spare parts
580233150104	ASSY.FA207 C/BEAM W/STUDS AND DOWELS	TATA spare parts
580233150105	ASSY JOINT FLANGE WITH DOWEL AND STUD	TATA spare parts
580233153701	FA207 M/CED CAST AXLE BEAM 828 SCD-N	TATA spare parts
580233153703	AXLE BEAM HOUSING (FOR THRO DRIVE AXLE)	TATA spare parts
580233153709	FRONT AXLE BEAM	TATA spare parts
580233157701	OIL SEAL(72X100X8)	TATA spare parts
580233157703	OIL SEAL (72X100X11)- M/S SIGMA NOK	TATA spare parts
580233158601	PRESSURE RING	TATA spare parts
580233158801	STUD (JOINT FLANGE TO BEAM)-95LONG	TATA spare parts
580233250103	ASSY STEERING KNUCKLE	TATA spare parts
580233250106	STEERING KNUCKLE ASSY M/CED	TATA spare parts
580233250107	BREATHER PIPE ASSY	TATA spare parts
580233250107AE	BREATHER PIPE ASSY 1628	TATA spare parts
580233250108	PIPE ASM (STEERING KNUCKLE- CTIS)	TATA spare parts
580233250108AE	PIPE ASM (STEERING KNUCKLE)-1628	TATA spare parts
580233250115	STEERING KNUCKLE ASSY	TATA spare parts
580233257701	OIL SEAL (55X70X8)	TATA spare parts
580233257701AE	OIL SEAL (55X70X8) 1628	TATA spare parts
580233257901	SUPPORT SLEEVE	TATA spare parts
580233257902	SUPPORT SLEEVE FOR CTIS	TATA spare parts
580233258201	CLAMP BASE PLATE	TATA spare parts
580233258202	CLAMP	TATA spare parts
580233259901	PLUG	TATA spare parts
580233300101	TIE ROD ARM ASSY WITH COVER PLATE LH	TATA spare parts
580233300102	TIE ROD ARM ASSY WITH COVER PLATE RH	TATA spare parts
580233450104	ASSY BELL HOUSING COMPLETE	TATA spare parts
580233450105	ASSY.PLANET CARRIER & BELL HOUSING	TATA spare parts
580233450109	ASSY HUB WITH BRG OIL SEAL	TATA spare parts
580233450111	PIPE ASSM (HUB-CTIS)	TATA spare parts
580233450111AE	PIPE ASSM (HUB-CTIS) 1628	TATA spare parts
580233450119	PIPE ASSY	TATA spare parts
580233451601	TAPER ROLLER BRG (HUB OUTER) 170X110X38	TATA spare parts
580233453102	NEEDLE ROLLER	TATA spare parts
580233454301	CIRCLIP FOR CTIS	TATA spare parts
580233455401	SUN GEAR	TATA spare parts
580233455401AE	SUN GEAR 1628	TATA spare parts
580233455402	PLANET PINION	TATA spare parts
580233455402AE	PLANET PINION 1628	TATA spare parts
580233455403	RING GEAR	TATA spare parts
580233455501	WHEEL HUB (FRONT) SPIGOTTED	TATA spare parts
580233455502	ADAPTOR (RING GEAR)	TATA spare parts

58023345503	WHEEL HUB (SPEGOTED) FOR CTIS	TATA spare parts
58023345504	ADAPTOR RING GEAR FOR CTIS	TATA spare parts
580233456501	HUB LOCK NUT	TATA spare parts
580233456701	PIN (PLANET PINION)	TATA spare parts
580233456701AE	PIN (PLANET PINION) 1628	TATA spare parts
580233456803	COUPLING BODY	TATA spare parts
580233457702	HUB SEAL CASSETTE TYPE (152X120X25)	TATA spare parts
580233457702AE	HUB SEAL CASSETTE TYPE-1628-1828	TATA spare parts
580233458601	SPACER	TATA spare parts
580233458602	SUN GEAR WASHER (INNER)	TATA spare parts
580233458603	SPACER RING(BET OIL SEAL AND HUB BRG)	TATA spare parts
580233458605	SPACER (2.0 THK)¿ OD 109.8 X¿ ID 90	TATA spare parts
580233458606	SPACER (2.1 THK)	TATA spare parts
580233458607	SPACER (2.2 THK)	TATA spare parts
580233458608	SPACER (2.3 THK)	TATA spare parts
580233458609	SPACER (2.4 THK)	TATA spare parts
580233458610	SPACER (2.5 THK)	TATA spare parts
580233458611	SPACER (2.6 THK)	TATA spare parts
580233458612	SPACER (2.7 THK)	TATA spare parts
580233458613	SPACER (2.8 THK)	TATA spare parts
580233458614	SPACER (2.9 THK)	TATA spare parts
580233458615	SPACER (3.0 THK)	TATA spare parts
580233458616	SPACER (3.1 THK)	TATA spare parts
580233458617	SPACER (3.2 THK)	TATA spare parts
580233458618	SPACER (3.3 THK)	TATA spare parts
580233458619	SPACER (3.4 THK)	TATA spare parts
580233458620	SPACER (3.5 THK)¿ OD 109.8 X¿ ID 90	TATA spare parts
580233458621	SUN GEAR WASHER (OUTER)	TATA spare parts
580233458622	TONGUE WASHER (FOR LOCK NUT)	TATA spare parts
580233458623	WEAR RING (CTIS)	TATA spare parts
580233458623AE	WEAR RING (CTIS) 1628	TATA spare parts
580233458624	SPACER FOR STEERING LOCK	TATA spare parts
580233750106	ASSY DRIVE SHAFT COMP.(W/O DIFF LOCK)	TATA spare parts
580233750108	ASSY. DRIVE SHAFT COMP W/DIFF.LOCK	TATA spare parts
580233750108AE	ASY DRVE SFT COMP W/DIF LCK-1628	TATA spare parts
580233757901	DRIVE SHAFT (HUB END)	TATA spare parts
580233757901AE	DRIVE SHAFT (HUB END) 1628	TATA spare parts
580233757904	DRIVE SHAFT (DIFF END) (F/CAST BEAM)	TATA spare parts
580233757905	DRIVE SHAFT (DIFF END) DIFF LO F/CAST.B	TATA spare parts
580326000109	GEAR BOX ASSY	TATA spare parts
580326000121	GEAR BOX ASSY BS6	TATA spare parts
580326000122	GEAR BOX ASSY BS6	TATA spare parts
580326000129	GEAR BOX ASSY BS6	TATA spare parts
580326000130	GEAR BOX ASSY BS6	TATA spare parts
580326000134	GEAR BOX ASSY BS6	TATA spare parts
580326000135	GEAR BOX ASSY BS6	TATA spare parts
580326000136	GEAR BOX ASSY BS6	TATA spare parts

580326000139	GEAR BOX ASSY BS6	TATA spare parts
580326000140	GEAR BOX ASSY BS6	TATA spare parts
580326000141	GEAR BOX ASSY BS6	TATA spare parts
580326000142	GEAR BOX ASSY BS6	TATA spare parts
580326000143	GEAR BOX ASSY BS6	TATA spare parts
580326000144	GEAR BOX ASSY BS6	TATA spare parts
580326000148	GEAR BOX ASSY BS6-PH2	TATA spare parts
580326000151	GEAR BOX ASSY BS6-PH2	TATA spare parts
580326000152	GEAR BOX ASSY BS6-PH2	TATA spare parts
580326030122	GEARSHIFTLINKAGEASSYWITHCABLE BS6	TATA spare parts
580326100108	GEAR BOX HOUSING ASSY REAR- HALF BS6-PH2	TATA spare parts
580326100109	BRACKET ASSY	TATA spare parts
580326100120	FRONT HALF BS6-PH2	TATA spare parts
580326103802	HOUSING FRONT HALF	TATA spare parts
580326103808	HOUSING REAR HALF	TATA spare parts
580326103811	GEAR BOX HOUSING FRONT-HALF BS6	TATA spare parts
580326105301	GASKET (R.I WINDOW)	TATA spare parts
580326105302	GASKET (HOUSING JOINT FACE)	TATA spare parts
580326105304	GASKET REAR (C/S COVER) BS6	TATA spare parts
580326105305	GASKET	TATA spare parts
580326108201	COVER (R.I. WINDOW)	TATA spare parts
580326108202	COVER REAR (COUNTER SHAFT)	TATA spare parts
580326108301	SHIM (0.8 THICK)	TATA spare parts
580326200105	ASSLY.SYNCHROCONE(1ST/2ND) BS6	TATA spare parts
580326200109	ENGAGING GEAR ASSY WITH SHIFTER SLEEVE B	TATA spare parts
580326201601	SYNCHRO CONE (96 DIA.) CARBON LNG) BS3/4	TATA spare parts
580326201602	INTERMEDIATE CONE (1ST/2ND SPEED)	TATA spare parts
580326201603	INNER CONE (WITH CARBON LINING)	TATA spare parts
580326201604	SYNCHRO CONE(82 DIA)(WITH CARBON LINING)	TATA spare parts
580326203401	SENSING WHEEL (CONTACTLESS SPEEDO)	TATA spare parts
580326204301	SNAP RING (ENG.GEAR REV.)	TATA spare parts
580326204302	EXTERNAL CIRCLIP(ENG. GEAR 1/2)	TATA spare parts
580326204303	EXTERNAL CIRCLIP(ENG. GEAR 1/2)	TATA spare parts
580326204304	EXTERNAL CIRCLIP(ENG. GEAR 1/2)	TATA spare parts
580326204305	EXTERNAL CIRCLIP(ENG. GEAR 1/2)	TATA spare parts
580326204306	EXTERNAL CIRCLIP(ENG. GEAR 1/2)	TATA spare parts
580326204307	EXTERNAL CIRCLIP(ENG. GEAR 1/2)	TATA spare parts
580326204308	INTERNAL CIRCLIP- 3.04 THK.	TATA spare parts
580326204309	INTERNAL CIRCLIP- 3.09 THK.	TATA spare parts
580326204310	INTERNAL CIRCLIP- 3.14 THK.	TATA spare parts
580326204311	INTERNAL CIRCLIP- 3.19 THK.	TATA spare parts
580326204312	INTERNAL CIRCLIP- 3.24 THK.	TATA spare parts
580326204313	INTERNAL CIRCLIP- 3.29 THK.	TATA spare parts
580326204315	INTERNAL CIRCLIP -2.94 THK BS6-PH2	TATA spare parts
580326204316	INTERNAL CIRCLIP-2.99 THK BS6-PH2	TATA spare parts
580326204601	SYNCHRO RING (5TH/6TH SPEED)	TATA spare parts
580326204602	ENGAGING GEAR (1ST/2ND SPEED)	TATA spare parts

580326204603	SYNCHRO RING (REV. SPEED)	TATA spare parts
580326204604	ENGAGING GEAR (REV. SPEED)	TATA spare parts
580326204605	SHIFTER SLEEVE (5TH/6TH SPEED & REV.)	TATA spare parts
580326204606	ENGAGING GEAR (5TH/6TH SPEED)	TATA spare parts
580326204607	SYNCHRO RING (1ST/2ND)	TATA spare parts
580326204618	ENGAGING GEAR 3RD/4TH SPEED BS6-PH2	TATA spare parts
580326205101	COUPLING FLANGE (120 DIA. SERRATED)	TATA spare parts
580326205104	COUPLING FLANGE BS6-PH2	TATA spare parts
580326205401	HELICAL GEAR 2ND SPEED (MAIN SHAFT)	TATA spare parts
580326205402	HELICAL GEAR 1ST SPEED (MAIN SHAFT)	TATA spare parts
580326205403	REVERSE GEAR (MAIN SHAFT)	TATA spare parts
580326206501	HEX LOCK NUT BS6-PH2	TATA spare parts
580326206701	BOLT COUPLING FLANGE	TATA spare parts
580326207901	MAIN SHAFT	TATA spare parts
580326207904	MAIN SHAFT BS6-PH2	TATA spare parts
580326208201	DUST COVER (PRESS FIT)	TATA spare parts
580326208601	BUSH (REVERSE GEAR)	TATA spare parts
580326208602	SPACER (MAIN SHAFT) 9.20 THK	TATA spare parts
580326208603	SPACER (MAIN SHAFT) 9.25 THK	TATA spare parts
580326208604	SPACER (MAIN SHAFT) 9.30 THK	TATA spare parts
580326208605	SPACER (MAIN SHAFT) 9.35 THK	TATA spare parts
580326208606	SPACER (MAIN SHAFT) 9.40 THK	TATA spare parts
580326208607	SPACER (MAIN SHAFT) 9.45 THK	TATA spare parts
580326208608	SPACER (MAIN SHAFT) 9.50 THK	TATA spare parts
580326208609	SPACER (MAIN SHAFT) 9.55 THK	TATA spare parts
580326208610	SPACER (MAIN SHAFT) 9.60 THK	TATA spare parts
580326208611	SPACER (MAIN SHAFT) 9.65 THK	TATA spare parts
580326208612	SPACER (MAIN SHAFT) 9.70 THK	TATA spare parts
580326208613	SPACER (MAIN SHAFT) 9.75 THK	TATA spare parts
580326208614	SPACER (MAIN SHAFT) 9.80 THK	TATA spare parts
580326208615	SPACER (MAIN SHAFT) 9.85 THK	TATA spare parts
580326208616	SPACER (MAIN SHAFT) 9.90 THK	TATA spare parts
580326208617	SPACER (MAIN SHAFT) 9.95 THK	TATA spare parts
580326208618	SPACER (MAIN SHAFT) 10.00 THK	TATA spare parts
580326208619	SPACER (MAIN SHAFT) 10.05 THK	TATA spare parts
580326208620	SPACER (MAIN SHAFT) 10.10 THK	TATA spare parts
580326208621	SPACER (MAIN SHAFT) 10.15 THK	TATA spare parts
580326250110	DRIVE SHAFT ASSY BS6-PH2	TATA spare parts
580326253101	ROLLER CAGE (26X41X26)-KCI	TATA spare parts
580326253701	COVER TUBE	TATA spare parts
580326255301	GASKET (COVER TUBE)	TATA spare parts
580326257901	DRIVE SHAFT (RATIO-6.008)	TATA spare parts
580326257906	DRIVE SHAFT BS6	TATA spare parts
580326257908	DRIVE SHAFT BS6-PH2	TATA spare parts
58032625790820	DRIVE SHAFT BS6-PH2	TATA spare parts
580326300102	ENGAGING GEAR SHIFT SLV ASSY 3/4TH SPEED	TATA spare parts
580326300109	COUNTER SHAFT ASSY BS6-PH2	TATA spare parts

580326300111	COUNTERSHAFT ASSY BS6	TATA spare parts
580326303101	CYL. ROLLER BEARING-NU2207E-FAG	TATA spare parts
580326303102	CYL. ROLLER BEARING-NUP2207E-FAG	TATA spare parts
580326303103	NEEDLE CAGE (45X50X38)-NRB	TATA spare parts
580326303104	CYL ROLLER BEARING(NU 2207EC) OFFER DRG.	TATA spare parts
580326303402	COLLAR BUSH	TATA spare parts
580326304301	INTERNAL CIRCLIP- 2.04 THK.	TATA spare parts
580326304302	INTERNAL CIRCLIP- 2.09 THK.	TATA spare parts
580326304303	INTERNAL CIRCLIP- 2.14 THK.	TATA spare parts
580326304304	INTERNAL CIRCLIP- 2.19 THK.	TATA spare parts
580326304305	INTERNAL CIRCLIP- 2.24 THK.	TATA spare parts
580326304306	INTERNAL CIRCLIP- 2.29 THK.	TATA spare parts
580326304307	INTERNAL CIRCLIP- 2.34 THK.	TATA spare parts
580326304308	SNAP RING COUNTER SHAFT	TATA spare parts
580326304309	INTERNAL CIRCLIP BS6-PH2	TATA spare parts
580326304601	SYNCHRO RING (3RD/4TH)	TATA spare parts
580326305401	CONSTANT MESH GEAR (RATIO-6.008)	TATA spare parts
580326305402	HELICAL GEAR 3RD SPEED (COUNTER SHAFT)	TATA spare parts
580326305403	HELICAL GEAR 4TH SPEED (COUNTER SHAFT)	TATA spare parts
580326305404	HELICAL GEAR 6TH SPEED (COUNTER SHAFT)	TATA spare parts
580326305411	CONSTANT MESH GEAR BS6	TATA spare parts
580326305412	HELICAL GEAR 4TH SPEED BS6-PH2	TATA spare parts
580326305413	HELICAL GEAR 3RD SPEED BS6-PH2	TATA spare parts
580326305418	CONSTANT MESH GEAR BS6-PH2	TATA spare parts
58032630541820	CMG READY FOR TEETH GRINDING BS6-PH2	TATA spare parts
580326307901	COUNTER SHAFT	TATA spare parts
580326355401	REVERSE IDLER GEAR	TATA spare parts
580326357901	REVERSE IDLER SHAFT	TATA spare parts
580326358601	SPACER (REVERSE IDLER GEAR)	TATA spare parts
580326400101	PTO ASSY	TATA spare parts
580326513801	SHIFTER FORK (1ST/2ND)	TATA spare parts
580326513802	SWING FORK (3RD/4TH SPEED)	TATA spare parts
580326513803	SWING FORK (REVERSE)	TATA spare parts
580326513804	SWING FORK (5TH/6TH)	TATA spare parts
580326515101	SHIFTER DOG (1ST/2ND AND REV.)	TATA spare parts
580326515102	SHIFTER DOG (3RD/4TH AND 5TH/6TH)	TATA spare parts
580326517901	SHIFTER SHAFT (1ST/2ND)	TATA spare parts
580326517902	SHIFTER SHAFT (REVERSE)	TATA spare parts
580326517903	SHIFTER SHAFT (3RD/4TH SPEED)	TATA spare parts
580326517905	SHIFTER SHAFT 5TH SPEED	TATA spare parts
580326700102	SELECTOR SHAFT & SELECTION LEVER ASSY	TATA spare parts
580326707902	SELECTOR & SHIFTER SHAFT BS6	TATA spare parts
580326710104	COVER ASSY TOP BS6	TATA spare parts
580326710105	COVER ASSY TOP BS6	TATA spare parts
580326800102	GEAR SHIFTER ASSY (MAXICAB BUS) BS6	TATA spare parts
580326800107	GEAR SHIFT LEVER ASSY WITH SHIFT YOKE BS	TATA spare parts
580326800108	TURNING TUBE ASSY BS6	TATA spare parts



580326800111	GEAR SHIFT LINKAGE ASSY BS6	TATA spare parts
580326810101	BRACKET ASSY SUPPORT TUBE MTG BS6	TATA spare parts
580326810102	SUPPORT TUBE ASSY BS6	TATA spare parts
580326820122	ASSY.G.S. CABLES 5T/7.2T RHD 4SP ENG	TATA spare parts
580326820136	BRACKET ASSY SELECTION ANCHORING	TATA spare parts
580326820137	BRACKET ASSY SHIFTER ANCHORING	TATA spare parts
580326820139	GEAR SHIFTER ASSY WITH CABLE BS6	TATA spare parts
580326820140	BRACKET ASSY CABLE ANCHORING SHIFT BS6	TATA spare parts
580326820145	CABLE SHIFTER ASSY BS6	TATA spare parts
580326820148	BRACKET ASSY CABLE ANCHORING SHIFT BS6	TATA spare parts
580326820152	GEAR SHIFTER ASSY WITH CABLE BS6	TATA spare parts
580326820153	GEARSHIFTERASSY BS6	TATA spare parts
580326820161	GEAR SHIFTER ASSY WITH CABLE BS6	TATA spare parts
580326820163	GSL ASSY BS6	TATA spare parts
580326820164	SHIFT CABLE ASSY BS6	TATA spare parts
580326820165	SELECTION CABLE ASSY BS6	TATA spare parts
580326820166	SHIFT CABLE ASSY BS6	TATA spare parts
580326820167	SELECTION CABLE ASSY BS6	TATA spare parts
580326820168	SHIFT CABLE ASSY BS6	TATA spare parts
580326820169	SELECTION CABLE ASSY BS6	TATA spare parts
580326820170	MOUNTING PLATE ASSY RH BS6	TATA spare parts
580326820171	LEVER ASSY BS6	TATA spare parts
580326820172	GEAR SHIFTER ASSY WITH CABLE BS6-PH2	TATA spare parts
580326820174	SHIFT CABLE ASSY BS6-PH2	TATA spare parts
580326820175	SELECTION CABLE ASSY BS6-PH2	TATA spare parts
580326820178	GEAR SHIFTER ASSY WITH CABLE	TATA spare parts
580326821614	GEAR SHIFT LEVER KNOB	TATA spare parts
580326823201	BOLT BS6	TATA spare parts
580326824301	RETAINER CLIP BS6	TATA spare parts
580326824801	DOWEL PIN BS6	TATA spare parts
580326826021	SHIFT LEVERBS6	TATA spare parts
580326826099	SHIFT LEVER	TATA spare parts
580326826501	LOCK NUT BS6	TATA spare parts
580326827701	BELLOW (GSL - NARROW CAB)	TATA spare parts
580326827703	DAMPER BUSH BS6	TATA spare parts
580326828213	BRACKET - L TYPE (CABLE SHIFT)	TATA spare parts
580326828214	BRACKET- L TYPE (CABLE SHIFT) BS6-PH2	TATA spare parts
580326828216	BRACKET - L TYPE (CABLE SHIFT)	TATA spare parts
580326828217	BRACKET - L TYPE (CABLE SHIFT)	TATA spare parts
580326828219	Z-BRACKET	TATA spare parts
580326828801	BALL & STUD BS6	TATA spare parts
580326990102	GSL ASSY BS6	TATA spare parts
580326990103	LEVER ASSY BS6	TATA spare parts
580326990104	BRACKET ASSY BS6	TATA spare parts
580326996007	SHIFT CABLE BS6	TATA spare parts
580326996008	SELECTION CABLE BS6	TATA spare parts
580326998701	SPRING BS6	TATA spare parts

580326999901	GROMMET BS6	TATA spare parts
580326999902	BALL JOINT BS6	TATA spare parts
580326999903	BALL JOINT BS6	TATA spare parts
580326999904	BALL JOINT BS6	TATA spare parts
580326999905	RUBBER BELLOW BS6	TATA spare parts
580326999906	COVER BS6	TATA spare parts
580326999907	COVER BS6	TATA spare parts
580326999908	BALL JOINT BS6	TATA spare parts
580525000107	KIT-CLUTCH ASSY. 430 DIA. BS3	TATA spare parts
580525000108	SET-CLUTCH ASSY. 430 DIA. SETCO BS3/4/6	TATA spare parts
580525000121	SET-CLUTCH ASSY DIA 430	TATA spare parts
580525000123	SET-CLUTCH ASSY DIA 430	TATA spare parts
580525000124	SET-CLUTCH ASSY PULL TYPE DIA 430 BS6	TATA spare parts
580525000125	SET-CLUTCH ASSY PULL TYPE DIA 430 BS6	TATA spare parts
580525000128	SET-CLUTCH ASSY PULL TYPE DIA 430 BS6	TATA spare parts
580525000130	SET-CLUTCH ASSY PULL TYPE DIA 430 BS6	TATA spare parts
580525000135	SET-CLUTCH ASSY PULL TYPE DIA 430 BS6-PH	TATA spare parts
580525100102	CLUTCH HSG ASSY WITH RELEASE FORK BS6-PH	TATA spare parts
580525103701	CLUTCH HOUSING	TATA spare parts
580525103706	ADAPTER PLATE FLY WHEEL HSG & CLUTCH HSG	TATA spare parts
580525103709	CLUTCH HOUSING BS6-PH2	TATA spare parts
580525108001	HEX.FL.BOLT 7/16-14 UNC-3A THD.	TATA spare parts
580525200107	CLUTCH DISC 430 DIA. BS3	TATA spare parts
580525200108	CLUTCH DISC 430 DIA. BS3/4/6	TATA spare parts
580525200110	DISC FACING KIT-GRADE-510	TATA spare parts
580525200111	DISC FACING KIT-GRADE-510MCC	TATA spare parts
580525200112	CLUTCH DISC ASSY 430 DIA	TATA spare parts
580525200117	CLUTCH DISC ASSY DIA 430	TATA spare parts
580525200122	CLUTCH DISC ASSY DIA 430 BS6	TATA spare parts
580525200126	CLUTCH DISC ASSY DIA 430 BS6-PH2	TATA spare parts
580525200430DF	CLUTCH FACING 430 DIA ORG-3.5MM	TATA spare parts
580525200430DFWR	CLUTCH FACING 430 DIA ORG-3.5MM W/RIVETS	TATA spare parts
580525400107	CLUTCH COVER 430 DIA. BS3	TATA spare parts
580525400108	CLUTCH COVER 430 DIA. BS3/4/6	TATA spare parts
580525400110	KIT-COLLECTOR RING BS3	TATA spare parts
580525400116	CLUTCH COVER ASSY DIA 430	TATA spare parts
580525400118	CLUTCH COVER ASSY DIA 430 BS6	TATA spare parts
580525400119	CLUTCH COVER ASSY PULL TYPE DIA 430 BS6	TATA spare parts
580525400120	CLUTCH COVER ASSY BS6	TATA spare parts
580525400122	CLUTCH COVER ASSY PULL TYPE DIA 430 BS6	TATA spare parts
580525600101	RELEASE BEARING ASSEMBLY KIT	TATA spare parts
580525600102	KIT-CLUTCH RELEASE BRG (CB-L4064) BS3/4	TATA spare parts
580525600102AE	RELEASE BRG ASSY KIT-1628-1828	TATA spare parts
580525600103	CLUTCH RELEASE FORK ASSY BS6-PH2	TATA spare parts
580525600104	ASSY. CROSS SHAFT WITH LEVER (WORLD TRUC	TATA spare parts
580525600106	RELEASE BRG ASSY.KIT(CB-L4720)	TATA spare parts
580525600111	CLUTCH RELEASE BEARING ASSY BS6	TATA spare parts

580525600113	CLUTCH RELEASE BEARING ASSY	TATA spare parts
580525603403	BUSH (CLUTCH RELEASE FORK)	TATA spare parts
580525603404	BUSH (CLUTCH RELEASE LEVER)	TATA spare parts
580525603703	CLUTCH RELEASE FORK BS6	TATA spare parts
580525605101	CLUTCH RELEASE FORK	TATA spare parts
580525607901	CROSS SHAFT(SPLINED) G1400 G BOX	TATA spare parts
580525607902	CROSS SHAFT	TATA spare parts
580525990101	KIT-CLUTCH RELEASE BEARING BS6	TATA spare parts
580525990102	KIT-CLUTCH RELEASE BEARING 430 DIA BS6	TATA spare parts
580525990103	KIT-COLLECTOR RING BS6	TATA spare parts
580525990104	KIT-CLUTCH RELEASE BEARING 430 DIA BS6	TATA spare parts
580626803403	Collar Bush - HA Gear shoft Linkgae (GSL	TATA spare parts
580626806301	SERVICE KIT SELECT BALL COUPLING	TATA spare parts
580626806302	SERVICE KIT SHIFT BALL COUPLING	TATA spare parts
580725103402	BUSH LOWER (ON HOUSING)	TATA spare parts
580725103403	UPPER BUSH (ON HOUSING)	TATA spare parts
580725600102	ASSY. CLUTCH RELEASE YOKE	TATA spare parts
580725600103	ASSY. CLUTCH RELEASE BEARING - TEXSPIN	TATA spare parts
580725600105	CLUTCH RELEASE BEARING ASSY	TATA spare parts
580725601601	ASSY. CLUTCH RELEASE BEARING BS2/3/4	TATA spare parts
580725606001	CLUTCH RELEASE LEVER	TATA spare parts
580725608702	RETURN SPRING (INTERNAL)	TATA spare parts
580725608704	RETURN SPRING EXTERNAL	TATA spare parts
580927000101	AUTOMATIC TRANSMISSION ASSY - 6L50 RWD	TATA spare parts
580927000102	AUTO TRAN ASSY - 6L50 AWD 4BZA	TATA spare parts
580927000103	CONVERTER ASM -TORQ	TATA spare parts
580927000105	PLUG ASM-A/TRNS FLUID PAN DRN	TATA spare parts
580927000107	PAN ASM-A/TRNS FLUID	TATA spare parts
580927000108	PLUG-TRANS FLUID FIL TUBE SHPG	TATA spare parts
580927000111	GASKET-A/TRNS FLUID PAN	TATA spare parts
580927003201	BOLT/SCREW-C/VLV BODY	TATA spare parts
580927007801	SEAL-TURB SHF (O RING)	TATA spare parts
580927007802	SEAL-A/TRNS CASE (O RING)	TATA spare parts
580927008001	BOLT/SCREW-A/TRNS FLUID PAN	TATA spare parts
580927008201	COVER - T/CV HSG ACC HOLE	TATA spare parts
580927103801	ADAPTOR HOUSING - AT ASSY - 4X4	TATA spare parts
580927400101	FLEXPLATE ASSY	TATA spare parts
580927400102	ASSEMBLY RING GEAR ASSEMBLY FLEXPLATE	TATA spare parts
580927408001	HEX FL SCREW FLEXPLATE TO TORQUE CONVERT	TATA spare parts
580927600105	VENT AND DRAIN LINE ASSY	TATA spare parts
580927600107	BRACKET ASSY	TATA spare parts
580927607101	ADAPTER PLATE THIRD POINT MOUNT 4X2	TATA spare parts
580927608202	BKT - VENT LINE ASSY CLAMP MTG	TATA spare parts
580927608204	CLAMP - PARKING DRAIN LINE ASSY	TATA spare parts
580927608225	BRACKET,BREATHER ASSY MTG	TATA spare parts
580927700101	GEAR SHIFT LEVER ASSY - TRANS END	TATA spare parts
580927700102	GEAR SHIFTER UNIT WITH CABLE ASSY	TATA spare parts

580927808202	CABLE ANCHORING BRACKET	TATA spare parts
580927900106	TWOC COOLING LINE ASSY,IN	TATA spare parts
580927900116	CLAMP PLATE CLOSUER ASSY-SMALL-TWOC END	TATA spare parts
580927900165	CLAMP ASSY CLAMP HOLDING FRAME	TATA spare parts
580927900170	SUPPORT BRACKET ASSY BOTTOM	TATA spare parts
580927900185	BRACKET ASSY FAN MTG BOTTOM-LH	TATA spare parts
580927900186	BRACKET ASSY FAN MTG BOTTOM-RH	TATA spare parts
580927900187	SUPPORT BRACKET ASSY BOTTOM	TATA spare parts
580927900188	SUPPORT BRACKET ASSY COOLER MTG TOP	TATA spare parts
580927900189	BRACKET ASSY TUBE SUPPORT TOP	TATA spare parts
580927900190	BRACKET ASSY TUBE SUPPORT TOD END	TATA spare parts
580927900191	BRACKET TUBE SUPPORT TRANS END	TATA spare parts
580927900192	COOLING LINE ASSY TRANS INLET	TATA spare parts
580927900193	TWOC COOLING LINE ASSY OUT	TATA spare parts
580927900194	TAOC COOLING LINE ASSY OUTLET	TATA spare parts
580927900196	TUBE TAOC COOLING LINE ASSY INLET	TATA spare parts
580927900197	COOLING LINE ASSY TRANS INLET	TATA spare parts
580927900198	TWOC COOLING LINE ASSY OUT	TATA spare parts
580927900199	TUBE TAOC COOLING LINE ASSY INLET	TATA spare parts
580927903801	BRACKET,TRANS WATER OIL COOLER MTG	TATA spare parts
580927904209	CLAMP PLATE - SMALL - TAOC END	TATA spare parts
580927904211	STEPLESS EAR CLAMP - 017.5-706R	TATA spare parts
580927905301	GASKET - TRANS OIL COOLING SYSTEM	TATA spare parts
580927906983	TUBE TAOC END	TATA spare parts
580927907104	PLATE - CLAMP BLOCKER - TRANS END	TATA spare parts
580927907105	PLATE,CLAMP BLOCK - TAOC END	TATA spare parts
580927908284	PLATE OIL COOLER MTG	TATA spare parts
580927908285	PLATE	TATA spare parts
580927908287	CLAMP OIL COOLER TUBES	TATA spare parts
580927908288	SUPPORT BRACKET ASSY COOLER MTG TOP	TATA spare parts
580927908289	PLATE TAOC END	TATA spare parts
580927909901	TRANS WATER OIL COOLER	TATA spare parts
580927909902	TRANSMISSION AIR OIL COOLER ASSY	TATA spare parts
580928000101	ASSY TRANSFER CASE - TOD FOR GM 6L50 AT	TATA spare parts
58100100299	POLYURETHANE FILM 19MM WIDTH	TATA spare parts
581035000101	ASSY REAR AXLE RA-109 COMPLETE(43/7)	TATA spare parts
581035000102	ASSY RA-109 FWD AXLE COMPLETE W/BRKS 43/	TATA spare parts
581035000104	ASSY RA-109 RWD AXLE COMP W/BRK	TATA spare parts
581035000107	RA-109 SRT FWD AXLE COMP W/BRKS 41/6	TATA spare parts
581035000111	ASSY REAR AXLE RA-109SRT COMPLETE(41/6)	TATA spare parts
581035000112	ASSY FWD AXLE RA-109SRT COMPLETE W/BRKS(	TATA spare parts
581035000114	ASSY RWD AXLE RA-109SRT COMPLETE W/BRKS	TATA spare parts
581035000124	RA-109 SRT RWD AXLE COMP W/BRKS 41/6	TATA spare parts
581035000135	RA-109 SRT FWD AXLE COMP W/BRKS 41/7	TATA spare parts
581035000137	ASSY REAR RWD AXLE COMPLETE RA-109 SRT W	TATA spare parts
581035000140	RA-109SRT FWD AXLE COMP W/BRKS 41/6 1055	TATA spare parts
581035000141	RA-109SRT RWD AXLE COMP W/BRK 41/6 1055	TATA spare parts

581035000148	RA-109SRT COMP 41/6 1044 T180/T150/T150	TATA spare parts
581035000149	RA-109SRT FWD AXLE COMP W/BRKS 41/6 T180	TATA spare parts
581035000155	RA-109 SRT FWD AXLE COMP W/BRKS 41/6 105	TATA spare parts
581035000157	RA-109 SRT RWD AXLE COMP W/BRKS 41/6 105	TATA spare parts
581035000171	RA-109SRT FWD AXLE COMP W/BRKS LCRV 43/7	TATA spare parts
581035000173	RA-109SRT RWD AXLE COMP W/BRK LCRV T150	TATA spare parts
581035000179	A-109 SRT FWD AXLE COMP 43/7 T180/150 T	TATA spare parts
581035000181	RA-109 SRT RWD AXLE COMP.43/7 T150 TML	TATA spare parts
581035000191	RA-109 SRT RWD AXLE COMP W/BRKS 41/6	TATA spare parts
581035000193	RA-109 SRT FWD AXLE COMP W/BRKS 41/6	TATA spare parts
581035000194	RA-109 SRT FWD AXLE COMP 39/7 T-150/150	TATA spare parts
581035000198	RA-109SRT FWD AXLE COMP 41/6 T180/150 TM	TATA spare parts
581035000201	RA-109SRT RWD AXLE 41/6 T150 TML SUS	TATA spare parts
581035000202	RA-109SRT RWD AXLE WITH HUB 41/6 T-150	TATA spare parts
581035000211	RA-109SRT RWD AXLE COMP.39/7 T-150 W/BRK	TATA spare parts
581035000223	RA-109 SRT FWD AXLE COMP W/BRKS 45/7	TATA spare parts
581035000225	RA-109 SRT RWD AXLE COMP W/BRKS 45/7	TATA spare parts
581035000228	A-109SRT FWD AXLE W/BRKS TMLSUSP 39/7 T	TATA spare parts
581035000230	RA-109SRT RWD AXLE W/BRKS TMLSUSP 39/7 T	TATA spare parts
581035000251	ASSY RA109SRT FWD AXLE 41/6 T150/150 BRK	TATA spare parts
581035000271	AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000282	REAR AXLE ASSY WITH HUB ABS	TATA spare parts
581035000287	REAR AXLE ASSY WITH BRAKE RWD ABS	TATA spare parts
581035000288	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000290	REAR AXLE ASSY WITH BRAKE RWD ABS	TATA spare parts
581035000294	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
581035000296	REAR AXLE RWD AXLE ASSY ABS	TATA spare parts
581035000298	RA109SRT RWD AXLE W/ABS BRKS 1044 43/7 T	TATA spare parts
581035000304	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000322	AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000324	AXLE ASSY WITH BRAKE RWD	TATA spare parts
581035000326	AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000328	AXLE ASSY WITH BRAKE RWD	TATA spare parts
581035000330	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
581035000332	AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000334	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000335	REAR AXLE ASSY WITH BRAKE RWD ABS	TATA spare parts
581035000346	AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000349	AXLE ASSY WITH BRAKE RWD	TATA spare parts
581035000350	AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000354	AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000378	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000380	AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000382	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
581035000383	REAR AXLE ASSY WITH HUB ABS BS6	TATA spare parts
581035000384	AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000386	AXLE ASSY WITH BRAKE RWD	TATA spare parts

581035000388	AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000390	REAR AXLE ASSY WITH BRAKE RWD ABS	TATA spare parts
581035000392	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035000394	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
581035000398	REAR AXLE ASSY WITH BRAKE RWD	TATA spare parts
581035010105	AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035010107	REAR AXLE ASSY WITH BRAKE RWD	TATA spare parts
581035010111	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035010113	REAR AXLE ASSY WITH BRAKE RWD ABS	TATA spare parts
581035010118	REAR AXLE ASSY WITH BRAKE RWD ABS	TATA spare parts
581035010119	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010121	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035010129	AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035010134	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010136	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035010155	REAR AXLE ASSY WITH BRAKE RWD ABS	TATA spare parts
581035010157	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035010159	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035010174	AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010186	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035010188	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035010196	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
581035010204	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010206	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035010226	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
581035010228	AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035010236	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010238	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035010239	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035010240	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
581035010241	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035010243	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
581035010245	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035010246	REAR AXLE ASSY WITH BRAKE RWD ABS	TATA spare parts
581035010247	AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010248	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035010269	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035010270	REAR AXLE ASSY WITH BRAKE RWD ABS	TATA spare parts
581035010276	REAR AXLE ASSY WITH BRAKE FWD ABS BS6	TATA spare parts
581035010277	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035010302	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010304	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
581035010328	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010331	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
581035010335	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
581035010336	REAR AXLE BEAM ASSY REAR-RWD BS6	TATA spare parts
581035010338	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts

581035010340	AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010345	AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010347	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
581035010352	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035010353	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035010362	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010364	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035010366	AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010368	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
581035010371	REAR AXLE ASSY WITH BRAKE RWD BS6	TATA spare parts
581035010373	AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010378	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010379	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035010382	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010387	AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010389	AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035010391	AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020105	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020107	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020109	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020111	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035020115	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020116	"AXLE ASSY WITH BRAKE,FWD BS6"	TATA spare parts
581035020117	REAR AXLE ASSY WITH BRAKE;RWD;ABS BS6	TATA spare parts
581035020119	AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020121	AXLE BEAM ASSY REAR-RWD BS6	TATA spare parts
581035020125	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020127	REAR AXLE ASSY WITH BRAKE RWD BS6	TATA spare parts
581035020139	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020140	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
581035020143	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020145	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020147	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035020149	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020151	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035020152	REAR AXLE ASSY WITH BRAKE ABS RWD BS6	TATA spare parts
581035020158	AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020160	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
581035020167	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020169	REAR AXLE ASSY WITH BRAKE;ABS BS6	TATA spare parts
581035020170	AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020171	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
581035020174	REAR AXLE ASSY WITH BRAKE RWD BS6	TATA spare parts
581035020175	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020196	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035020198	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020205	AXLE ASSY WITH HUB FWD BS6	TATA spare parts

581035020206	REAR AXLE ASSY WITH BRAKE RWD ABS BS6	TATA spare parts
581035020208	AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020210	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
581035020218	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035020220	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
581035020222	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
581035020272	REAR AXLE ASSY WITH BRAKE FWD BS6	TATA spare parts
581035100101	ASSY. FWD BEAM W/RING/STUD DOWEL BS1- 4	TATA spare parts
581035100103	ASSY. RWD AXLE BEAM W/RING STUD DL BS1-6	TATA spare parts
581035100105	ASSY. FWD AXLE BEAM W/PR RNG/STD BS2/3/4	TATA spare parts
581035100108	ASSY. RWD AXLE BEAM W/RINGS/STUD BS2/3/4	TATA spare parts
581035100111	ASSY RWD AXLE BEAM W/PR.RINGS/STUDS	TATA spare parts
581035100112	ASSY RWD AXLE BEAM M/CED (1905 TRK)	TATA spare parts
581035100113	ASSY FWD BEAM W/PR RING STUD DOWEL	TATA spare parts
58103510011360	RA BEAM SRT WITH OIL CATCHER	TATA spare parts
581035100114	ASSY FWD BEAM W/PR RING STUD DOWEL	TATA spare parts
581035100119	ASSY FWD AXLE BEAM WITH PR.RINGS/STUDS	TATA spare parts
581035100120	ASSY FWD AXLE BEAM M/CED 1026 SCD	TATA spare parts
581035100121	ASSY RWD AXLE BEAM W/PR.RINGS/STUDS 1026	TATA spare parts
581035100122	ASSY RWD BEAM M/CED 1026 SCD	TATA spare parts
581035100123	ASSY.FWD BEAM-1055 W/PR RING STUD DOWEL	TATA spare parts
581035100125	ASSY.RWD BEAM-1055 W/PR RING STUD DOWEL	TATA spare parts
581035100126	ASSY.RA BEAM-1055 REAR RWD (M/CED)TML BS	TATA spare parts
581035100127	ASSY FWD AXLE BEAM WITH PR.RINGS/STUDS	TATA spare parts
581035100128	ASSY FWD AXLE BEAM M/CD.	TATA spare parts
581035100129	ASSY RWD AXLE BEAM W/PR.RINGS/STUDS	TATA spare parts
581035100130	ASSY RWD BEAM M/CED 1905TRK	TATA spare parts
581035100135	ASSY. FWD AXLE BEAM W/PR RING/STUD BS3/4	TATA spare parts
581035100136	ASSY FWD AXLE BEAM M/CED FOR TML SUP	TATA spare parts
581035100137	ASSY. RWD AXLE BEAM W/PR.RING/STUD BS3/4	TATA spare parts
581035100138	ASSY RWD AXLE BEAM M/CED FOR TML SUP	TATA spare parts
581035100140	REAR AXLE BEAM ASSY REAR-RWD BS6	TATA spare parts
581035100141	REAR AXLE BEAM ASSY REAR-FWD BS6	TATA spare parts
581035100142	ASSY. RWD AXLE BEAM W/RING STUD DL BS6	TATA spare parts
581035100143	ASSY. FWD AXLE BEAM W/RING STUD DL BS6	TATA spare parts
581035100144	ASSY. FWD AXLE BEAM W/PR RING/STUD BS3/4	TATA spare parts
58103510014460	RT REAR BEAM WITH OIL CATCHER	TATA spare parts
581035100145	ASSY. RWD AXLE BEAM W/PR RING/STUD BS3/4	TATA spare parts
581035100146	FWD BEAM ASSY M/CED TML SUSP	TATA spare parts
581035100147	RWD BEAM ASSY M/CED TML SUSP	TATA spare parts
581035100148	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
581035100150	RWD AXLE BEAM W/PR.R/STUDS TML SUSP 26T	TATA spare parts
581035100164	ASSY. AXLE BEAM WITH RING & STUD BS3/4	TATA spare parts
581035100166	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
581035100167	AXLE BEAM ASSY RWD	TATA spare parts
581035100175	AXLE BEAM ASSY WITH RING & STUD RR RWD	TATA spare parts
581035100176	ASSY. AXLE BEAM W/RING & STUD RR FWD BS4	TATA spare parts



581035100190	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
581035100191	AXLE ASSY WITH HUB FWD	TATA spare parts
581035100192	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
581035100193	REAR AXLE BEAM ASSY REAR-RWD	TATA spare parts
581035100206	REAR AXLE BEAM W/RING & STUD BS4	TATA spare parts
581035100208	ASSY. REAR AXLE BEAM W/RING & STUD BS6	TATA spare parts
581035100210	AXLE BEAM ASSY WITH RING & STUD FWD BS6	TATA spare parts
581035100212	AXLE BEAM ASSY WITH RING & STUD RR RWD B	TATA spare parts
581035100213	REAR AXLE ASSY WITH PRESSURE RING &AMP	TATA spare parts
581035100215	AXLE BEAM ASSY WITH RING &AMP STUD BS6	TATA spare parts
581035100230	REAR AXLE BEAM ASSY BS6	TATA spare parts
581035100231	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
581035100232	REAR AXLE BEAM ASSY BS6	TATA spare parts
581035100235	AXLE BEAM ASSY WITH STUD AND DOWEL BS6	TATA spare parts
581035100237	AXLE BEAM ASSY WITH STUD AND DOWEL BS6	TATA spare parts
581035100239	AXLE BEAM ASSY WITH RING &AMP STUD BS6	TATA spare parts
581035100240	AXLE BEAM ASSY WITH RING &AMP STUD BS6	TATA spare parts
581035100243	AXLE BEAM ASSY WITH RING & STUD FWD BS6	TATA spare parts
581035100245	AXLE BEAM ASSY WITH STUD & DOWEL BS6	TATA spare parts
581035100259	AXLE BEAM ASSY WITH STUD AND DOWEL BS6	TATA spare parts
581035100261	AXLE BEAM ASSY WITH STUD AND DOWEL BS6	TATA spare parts
581035100264	REAR AXLE BEAM ASSY REAR-FWD BS6	TATA spare parts
581035100265	REAR AXLE BEAM ASSY REAR-RWD BS6	TATA spare parts
581035100266	AXLE BEAM ASSY WITH RING &AMP STUD RR R	TATA spare parts
581035100267	AXLE BEAM ASSY WITH RING &AMP STUD FWD	TATA spare parts
581035100277	AXLE BEAM ASSY WITH RING &AMP STUD BS6	TATA spare parts
581035100278	AXLE BEAM ASSY WITH RING &AMP STUD FWD	TATA spare parts
581035100284	REAR AXLE BEAM ASSY WITH RING &AMP STUD	TATA spare parts
581035100286	REAR AXLE BEAM ASSY WITH STUD &AMP DOWEL	TATA spare parts
581035100288	REAR AXLE BEAM ASSY WITH STUD & DOWEL FW	TATA spare parts
581035100290	REAR AXLE BEAM ASSY WITH STUD & DOWEL RW	TATA spare parts
581035100297	REAR AXLE BEAM ASSY WITH STUD &AMP DOWEL	TATA spare parts
581035100301	REAR AXLE BEAM ASSY WITH STUD &AMP DOWEL	TATA spare parts
581035100311	REAR AXLE BEAM ASSY WITH STUD AND PIN BS	TATA spare parts
581035100315	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
581035100317	REAR AXLE BEAM ASSY WITH STUD & DOWEL BS	TATA spare parts
581035100326	AXLE BEAM ASSY WITH RING & STUD FWD BS6-	TATA spare parts
581035100334	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
581035100335	AXLE BEAM ASSY BS6	TATA spare parts
581035100340	AXLE BEAM ASSY WITH STUD & DOWEL BS6	TATA spare parts
581035100351	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
581035100352	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
581035100387	AXLE BEAM ASSY WITH RING & STUD BS6-PH2	TATA spare parts
581035101601	OIL SEAL (68X88X13) BS1/2/3/4/6	TATA spare parts
581035107102	SPRING SADDLE TOP BS6	TATA spare parts
581035107702	OIL SEAL (68X88X13)	TATA spare parts
581035107901	OUTPUT SHAFT (FRONT TANDEM) BS1/2/3/4	TATA spare parts

581035107902	OUTPUT SHAFT FRONT TANDEM	TATA spare parts
581035108204	OIL CATCHER	TATA spare parts
581035108601	PRESSURE RING BS6	TATA spare parts
581035110102	ASSY. CARRIER HSG. W/PLUMMER BLOCK BS1-4	TATA spare parts
581035110103	ASSY DRIVE HEAD COMP 43/7	TATA spare parts
581035110105	ASSY DRIVE HEAD COMP 41/6	TATA spare parts
581035110107	ASSY DRIVE HEAD COMPLETE(41/6)	TATA spare parts
581035110108	ASSY DRIVE HEAD COMP 43/7 180 DIA CPLNG	TATA spare parts
581035110110	ASSY CARR HSG COMP W/PINION & CW 39/7	TATA spare parts
581035110111	ASSY DRIVE HEAD COMP 41/7 180 DIA	TATA spare parts
581035110118	ASSY DRIVE HEAD 43/7 (BUSH ARGMNT) T150	TATA spare parts
581035110119	ASSY DRIVE HEAD 39/7 (BUSH ARGMNT) T150	TATA spare parts
581035110122	ASY DRIVE HEAD COMP 41/6 T150 BUSH.	TATA spare parts
581035110125	DRIVE HEAD ASSY WITH BUSH 41/6 T-180	TATA spare parts
581035110126	DRIVE HEAD ASSY 43/7 T-180 BUSH ARGMNT	TATA spare parts
581035110127	ASSY DRIVE HEAD 41/7 T-180 BUSH ARGMNT	TATA spare parts
581035110129	DRIVE HEAD ASSY 43/7 T-180 BUSH ARGMNT B	TATA spare parts
581035110131	DRIVE HEAD ASSY	TATA spare parts
581035110134	DRIVE HEAD ASSY	TATA spare parts
581035110151	CARRIER ASSY BS6-PH2	TATA spare parts
581035113701	CARRIER HOUSING	TATA spare parts
581035113702	DROP GEAR HOUSING BS1/2/3/4/6	TATA spare parts
581035115301	GASKET (CARRIER TO BEAM)	TATA spare parts
581035300101	ASSY.INTERAXLE DIFF. HSG. W/GEARS BS1/3	TATA spare parts
581035300101DF	DIFFERENTIAL HOUSING ASSY W/GEARS	TATA spare parts
581035300102	ASSY. INTERAXLE DIFF. HSG. BS1/2/3/4	TATA spare parts
581035300103	ASSY COUPLING FLANGE (INPUT SHAFT /150 D	TATA spare parts
581035300107	ASSY. CROWN & PINION 43/7 BS1/2/3/4	TATA spare parts
581035300115	ASSY. CROWN & PINION (41/6) BS1/3/4	TATA spare parts
581035300117	ASSY I/P COUPLING FLANGE180 SERRATED	TATA spare parts
581035300119	ASSY. CROWN & PINION (39/7) BS3/4	TATA spare parts
581035300122	ASSY. CROWN & PINION 41/7 BS2/3/4	TATA spare parts
581035300127	DIFFERENTIAL HOUSING ASSY BS6	TATA spare parts
581035300130	ASSY. CROWN & PINION (45/7) BS4	TATA spare parts
581035300151	CROWN WHEEL & PINION ASSY 41/8 BS6	TATA spare parts
581035300185	CROWN WHEEL & PINION ASSY BS6-PH2	TATA spare parts
58103530040160	THRUST WASHER (3.3 THK)	TATA spare parts
58103530040167	THRUST WASHER (4.0 THK)	TATA spare parts
58103530040168	THRUST WASHER (4.1 THK)	TATA spare parts
58103530040468	THRUST WASHER (4.1 THK)	TATA spare parts
581035303401	BUSH (I/P SHAFT)	TATA spare parts
581035303402	BUSH (O/P SHAFT)	TATA spare parts
581035303403	BUSH (I/P SHAFT)	TATA spare parts
581035303404	BUSH (O/P SHAFT)	TATA spare parts
581035303407	BUSH INPUT SHAFT	TATA spare parts
581035303408	BUSH OUTPUT SHAFT	TATA spare parts
581035305101	SPIDER (INTERAXLE DIFF.) BS1/2/3/4	TATA spare parts

581035305104	COVER (DROP GEAR HOUSING)	TATA spare parts
581035305105	OUTPUT COVER	TATA spare parts
581035305106	INTERAXLE DIFFERENTIAL SPIDER	TATA spare parts
581035305401	SHAFT GEAR (INPUT AXIS INTERAXLE DIFF)	TATA spare parts
581035305402	SHAFT GEAR (OUTPUT SHAFT-INTERAXLE DIFF)	TATA spare parts
581035305403	HELICAL GEAR (INPUT AXIS)	TATA spare parts
581035305404	HELICAL GEAR (PINION AXIS)	TATA spare parts
581035305405	PINION (43/7) RH -SPIRAC FRT TANDEM	TATA spare parts
581035305419	SHAFT GEAR-9/16 (I/P SHAFT-IAD)	TATA spare parts
581035305419DF	SHAFT GEAR-9/16-IAD INPUT SHAFT	TATA spare parts
581035305420	SHAFT GEAR 9/16 CONIFLEX (O/P SHAFT-IAD)	TATA spare parts
581035305420DF	SHAFT GEAR 9/16-CONIFLEX IAD OUTPUT SHAF	TATA spare parts
581035305421	SHAFT GEAR 9/16 (I/P SHAFT IAD) BS1-6	TATA spare parts
581035305421DF	SHAFT GEAR-9/16-IAD INPUT SHAFT	TATA spare parts
581035305422	SHAFT GEAR 9/16 (O/P SHAFT IAD) M/S SONA	TATA spare parts
581035305422DF	SHAFT GEAR 9/16-CONIFLEX IAD OUTPUT SHAF	TATA spare parts
581035305425	HELICAL GEAR 31/31 (INPUT AXIS) BS1-6	TATA spare parts
581035305426	HELICAL GEAR 31/31 (PINION AXIS) BS1-6	TATA spare parts
581035306101	LOCKING PLATE (INTERAXLE DIFF.)	TATA spare parts
581035306102	LOCKING PLATE	TATA spare parts
581035306501	THREADED RING (PINION)	TATA spare parts
581035307701	OIL SEAL BS6	TATA spare parts
581035307702	OIL SEAL BS6	TATA spare parts
581035307901	INPUT SHAFT (FRONT TANDEM)	TATA spare parts
581035307902	INPUT SHAFT (FRONT TANDEM) BS1/2/3/4	TATA spare parts
581035307904	INPUT SHAFT BS6	TATA spare parts
581035308201	OIL CATCHER (INTERAXLE DIFF. ASSY)	TATA spare parts
581035308301	SHIM (INPUT BEARING PRELOAD) 0.10 THK	TATA spare parts
581035308302	SHIM (INPUT BEARING PRELOAD) 0.15 THK	TATA spare parts
581035308303	SHIM (INPUT BEARING PRELOAD) 0.20 THK	TATA spare parts
581035308304	SHIM (INPUT BEARING PRELOAD) 0.25 THK	TATA spare parts
581035308305	SHIM (INPUT BEARING PRELOAD) 0.30 THK	TATA spare parts
581035308306	SHIM (INPUT BEARING PRELOAD) 0.40 THK	TATA spare parts
581035308307	SHIM (INPUT BEARING PRELOAD) 0.50 THK	TATA spare parts
581035308308	SHIM (INPUT BEARING PRELOAD) 1.0 THK	TATA spare parts
581035308309	SHIM (INPUT BEARING PRELOAD) 1.5 THK	TATA spare parts
581035308310	SHIM (OUTPUT BEARING PRELOAD) 0.10 THK	TATA spare parts
581035308311	SHIM (OUTPUT BEARING PRELOAD) 0.15 THK	TATA spare parts
581035308312	SHIM (OUTPUT BEARING PRELOAD) 0.20 THK	TATA spare parts
581035308313	SHIM (OUTPUT BEARING PRELOAD) 0.25 THK	TATA spare parts
581035308314	SHIM (OUTPUT BEARING PRELOAD) 0.30 THK	TATA spare parts
581035308315	SHIM (OUTPUT BEARING PRELOAD) 0.40 THK	TATA spare parts
581035308316	SHIM (OUTPUT BEARING PRELOAD) 0.50 THK	TATA spare parts
581035308317	SHIM (OUTPUT BEARING PRELOAD) 1.0 THK	TATA spare parts
581035308318	SHIM (OUTPUT BEARING PRELOAD) 1.5 THK	TATA spare parts
581035309201	THRUST WASHER (2.5 THK)	TATA spare parts
581035309202	THRUST WASHER (2.6 THK)	TATA spare parts

581035309203	THRUST WASHER (2.7 THK)	TATA spare parts
581035309204	THRUST WASHER (2.8 THK)	TATA spare parts
581035309205	THRUST WASHER (2.9 THK)	TATA spare parts
581035309206	THRUST WASHER (3.0 THK)	TATA spare parts
581035309207	THRUST WASHER (3.1 THK)	TATA spare parts
581035309208	THRUST WASHER (3.2 THK)	TATA spare parts
581035309209	THRUST WASHER (INTERAXLE SHAFT GEAR)	TATA spare parts
581035309210	THRUST WASHER 2.6THK	TATA spare parts
581035309211	THRUST WASHER 2.7 THK	TATA spare parts
581035309212	THRUST WASHER 2.8 THK	TATA spare parts
581035309213	THRUST WASHER 2.9 THK	TATA spare parts
581035309214	THRUST WASHER 3 THK	TATA spare parts
581035309215	THRUST WASHER 3.1 THK	TATA spare parts
581035309216	THRUST WASHER 3.2 THK	TATA spare parts
581035309217	THRUST WASHER (3.3 THK)	TATA spare parts
581035309218	THRUST WASHER (3.4 THK)	TATA spare parts
581035309219	THRUST WASHER (3.5 THK)	TATA spare parts
581035309220	THRUST WASHER (3.6 THK)	TATA spare parts
581035309221	THRUST WASHER (3.7 THK)	TATA spare parts
581035309222	THRUST WASHER (3.8 THK)	TATA spare parts
581035309223	THRUST WASHER (3.9 THK)	TATA spare parts
581035309224	THRUST WASHER (4.0 THK)	TATA spare parts
581035309225	THRUST WASHER 4.1 THK BS6	TATA spare parts
581035309226	THRUST WASHER (4.2 THK)	TATA spare parts
581035309227	THRUST WASHER (4.3 THK)	TATA spare parts
581035600104	REAR HUB ASSY WITH BRG & POLE WHEEL ABS	TATA spare parts
581035608601	SPACER (OUTPUT SHAFT BRG PRELOAD)	TATA spare parts
581035707901	REAR AXLE SHAFT (L= 947) 1814 TRK BS1- 4	TATA spare parts
581035707901DF	REAR AXLE SHAFT 947MM L-1814TRK RA109RX	TATA spare parts
581035707902	REAR AXLE SHAFT-(L=1087) 1814 TRK BS1- 4	TATA spare parts
581035707902DF	REAR AXLE SHAFT 1087MM L-1814TRK RA109RX	TATA spare parts
581035707903	REAR AXLE SHAFT (992 LENGTH) BS2/3/4	TATA spare parts
581035707903DF	REAR AXLE SHAFT 992MM L-RA109SRT	TATA spare parts
581035707904	REAR AXLE SHAFT (1132 LENGTH) BS2/3/4	TATA spare parts
581035707904DF	REAR AXLE SHAFT 1132MM L-RA109SRT	TATA spare parts
581035707905	AXLE SHAFT (1020) INSERT UNIT BS6	TATA spare parts
581035707906	AXLE SHAFT (880) INSERT UNIT BS6	TATA spare parts
581035707907	REAR AXLE SHAFT (922 LENGTH) BS6	TATA spare parts
581035707908	REAR AXLE SHAFT (1062 LENGTH) BS6	TATA spare parts
581035707915	REAR AXLE SHAFT	TATA spare parts
581035707916	REAR AXLE SHAFT	TATA spare parts
581035904601	ENGAGING SLEEVE (INTERAXLE DIFF LOCK)	TATA spare parts
581035905101	FORK (INTERAXLE DIFF LOCK)	TATA spare parts
581035906701	INTERAXLE DIFFLOCK PIN	TATA spare parts
5810H9W0135040	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
5810H9W0135041	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
5810H9W0135044	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts

5810H9W0135047	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
5810H9W0135048	REAR FORWARD AXLE WITH BRAKES ABS BS6-P	TATA spare parts
5810H9W0135049	REAR REARWARD AXLE WITH BRAKES BS6-PH2	TATA spare parts
5810H9W0135050	LIVE REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
5810H9W0135051	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
5810H9W0135052	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
5810H9W0135053	LIVE REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
5810H9W0135054	LIVE REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
5810H9W0135055	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
5810H9W0135068	LIVE REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
5810H9W0135069	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
581126000102	GEAR BOX G76-5/4 1 MK-II WITH TRANSFERCA	TATA spare parts
581126000107	ASSY. G-76-5/4.1 MK-II COMPLETE FOR CROS	TATA spare parts
581126000120	ASSY.G-76-5/4.1 MK-II FOR XENON 4X2	TATA spare parts
581126000121	ASSY.G76-5/4.1 WITH ADPT.HSG FOR XENON 4	TATA spare parts
581126000122	ASSY.G76-5/4.1 MK-II WITH TRANSFERCASE F	TATA spare parts
581126000182	ASSY.G-76-5/4.1 MK-II FOR XENON 4X2 (260	TATA spare parts
581126000183	GEAR BOX G76-5/4.1 WITH ADPT.HSG XENON 4	TATA spare parts
581126000184	ASSY.G76-5/4.1 MK-II WITH TRANSFERCASE F	TATA spare parts
581126000195	ASSY.G-76-5/4.1 MK-II FOR XENON 4X2	TATA spare parts
581126000196	ASSY. GEAR BOX G76-5/4 XENON 4X4 BS3/4	TATA spare parts
581126010105	GEARBOX ASSY G76-5/4.1 WITH ADPT.HSG	TATA spare parts
581126010113	GEAR BOX ASSY	TATA spare parts
581126010114	GEAR BOX ASSY	TATA spare parts
581126010120	GEAR BOX ASSY	TATA spare parts
581126100102	SUBASSY HOUSING FRONT AND REAR	TATA spare parts
581126100116	ASSY HOUSING (FRONT+REAR)2.2 4X4 260 DIA	TATA spare parts
581126100117	ASSY HOUSING (FRONT+REAR) 4X2;260 DIA	TATA spare parts
581126103801	FRONT HOUSING	TATA spare parts
581126103802	REAR HOUSING	TATA spare parts
581126104801	DOWEL SLEEVE	TATA spare parts
581126105301	GASKET (BETWEEN FRONT HSG AND REAR HSG)	TATA spare parts
581126108801	STUD	TATA spare parts
581126108807	STUD	TATA spare parts
581126109902	SHIFTER SHAFT DETENT	TATA spare parts
581126200101	ASSY REVERSE SPEED GEAR	TATA spare parts
581126200102	ASSLY 1ST SPEED GEAR (B/W)	TATA spare parts
581126200103	SUB ASSY HELICAL GEAR (BW) (2ND SPEED 2.	TATA spare parts
581126200104	SUB ASSY HELICAL GEAR 3RD SPEED (BW)	TATA spare parts
581126200105	ASSY OVER DRIVE (BW)	TATA spare parts
581126200106	ASSY SYNCHRO CONE 1ST/2ND SPEED (BW)	TATA spare parts
581126200107	ASSY ADAPTOR HSG 2WD	TATA spare parts
581126200115	ASSY OVER DRIVE GEAR (BW) (0.73 RATIO)	TATA spare parts
581126200129	ASSLY 1ST SPEED GEAR (B/W)	TATA spare parts
581126200134	ASSLY 1ST SPEED GEAR (B/W)	TATA spare parts
581126200187	GEAR ASSY 3RD SPEED BS6	TATA spare parts
581126200189	REVERSE GEAR MAIN SHAFT BS6	TATA spare parts

581126203806	SYNCHRO CONE (3RD/4TH SPEED GEAR)	TATA spare parts
581126203807	SYNCHRO CONE (5TH/REV SPEED GEAR)	TATA spare parts
581126203808	REAR COVER 2WD	TATA spare parts
581126203809	ADAPTOR HOUSING 4WD	TATA spare parts
581126204301	SNAP RING BS6	TATA spare parts
581126204601	SYNCHRO RING (REVERSE GEAR)	TATA spare parts
581126204602	SYNCHRO RING(1ST/2ND GEAR) (BW)	TATA spare parts
581126204603	SYNCHRO RING (3RD GEAR) (BW)	TATA spare parts
581126204604	SYNCHRO RING (OD GEAR) (BW)	TATA spare parts
581126204605	ENGAGING GEAR (1ST/2ND)	TATA spare parts
581126204606	ENGAGING GEAR (BW) (3RD/4TH SPEED)	TATA spare parts
581126204607	ENGAGING GEAR (BW) (REV/OD)	TATA spare parts
581126204608	SHIFTER SLEEVE (BW) (1ST/2ND GEAR)	TATA spare parts
581126204609	SHIFTER SLEEVE (BW) 3RD/4TH	TATA spare parts
581126204610	SHIFTER SLEEVE (BW) REV/O.D	TATA spare parts
581126204614	ENGAGING GEAR (1ST/2ND)	TATA spare parts
581126204615	ENGAGING GEAR (BW) (3RD/4TH SPEED)	TATA spare parts
581126204616	ENGAGING GEAR (BW) (REV/OD)	TATA spare parts
581126204617	SHIFTER SLEEVE 1ST & 2ND SPEED	TATA spare parts
581126204618	SHIFTER SLEEVE;3RD/4TH SPEED	TATA spare parts
581126204619	SHIFTER SLEEVE REV & OD SPEED	TATA spare parts
581126204637	SYNCHRO RINGBS6	TATA spare parts
581126205301	GASKET 4X2 (BETWEEN REAR HSG AND ADAPTOR)	TATA spare parts
581126205302	GASKET 4X4 (BETWEEN REAR HSG AND ADAPTOR)	TATA spare parts
581126205303	GASKET - BETWEEN ADAPTOR HOUSING 4X4 AND	TATA spare parts
581126205401	REVERSE SPEED GEAR(MAIN SHAFT)4.22 RATIO	TATA spare parts
581126205423	GEAR 3RD SPEED BS6	TATA spare parts
581126209901	ASSY STRUT	TATA spare parts
581126250101	ASSY DRIVE SHAFT (DMF)	TATA spare parts
581126250107	DRIVE SHAFT ASSY BS6	TATA spare parts
581126254601	SYNCHRO RING (DRIVE GEAR) (BW)	TATA spare parts
581126257906	DRIVE SHAFT	TATA spare parts
581126307901	COUNTER SHAFT (FOR REV 4.22 RATIO)	TATA spare parts
581126308201	CAP (ADAPTOR 4X4)	TATA spare parts
581126350105	SUB ASSY R.I. SHAFT	TATA spare parts
581126355401	REVERSE IDLER GEAR (REV 4.22 RATIO)	TATA spare parts
581126357902	REVERSE IDLER GEAR SHAFT	TATA spare parts
581126357904	REVERSE IDLER GEAR SHAFT	TATA spare parts
581126358601	SPACER	TATA spare parts
581126358603	SPACER (R.I. GEAR)	TATA spare parts
581126513801	SHIFTER FORK 1ST/2ND SPEED	TATA spare parts
581126513802	SHIFTER FORK 5TH/REV	TATA spare parts
581126515101	SELECTOR HEAD 1ST/2ND	TATA spare parts
581126515102	SELECTOR HEAD 3RD/4TH	TATA spare parts
581126515103	SELECTOR HEAD 5TH/REV	TATA spare parts
581126517901	SHIFTER SHAFT 1ST/2ND	TATA spare parts
581126517902	SHIFTER SHAFT 3RD/4TH	TATA spare parts

581126517903	SHIFTER SHAFT 5TH/REV	TATA spare parts
581126700102	ASSY REVERSE BLOCKER	TATA spare parts
581126700105	ASSY TOP COVER	TATA spare parts
581126703402	CORE PLUG (ASSY.TOP COVER)	TATA spare parts
581126703803	TOP COVER	TATA spare parts
581126705101	SELECTOR FINGER	TATA spare parts
581126705102	SWING BLOCKER	TATA spare parts
581126705301	GASKET (TOP COVER AND REAR COVER / ADAPT	TATA spare parts
581126706501	PIN CROSSGATE LIMITER	TATA spare parts
581126707903	SELECTOR SHAFT (SHIFTER ASSEMBLY)	TATA spare parts
581126708301	WASHER SHIM	TATA spare parts
581126708701	REVERSE BLOCKER SPRING (SHIFTER ASSEMBLY	TATA spare parts
581126709903	CAPTIVE DETENT (SELECTION)	TATA spare parts
581126709904	CAPTIVE DETENT (SHIFTER)	TATA spare parts
581126710108	ASSY EXTN BOX SUPPORT (4X2)	TATA spare parts
581126710144	BRACKET ASSY (EXT ARM SUPPORT)	TATA spare parts
581126710146	ASSY EXTN. BOX SUPPORT	TATA spare parts
581126713810	EXTENSION ARM	TATA spare parts
581126713814	EXTENSION ARM XENON HYDRO FORM	TATA spare parts
581126718215	BRACKET (4X4)	TATA spare parts
581126718234	BRACKET EXTENSION BOX SUPPORT 4X4	TATA spare parts
581126719908	SHIFT LINK ROD	TATA spare parts
581126719916	SHIFT LINK ROD	TATA spare parts
581126800143	ASSY GEAR SHIFT LEVER(W.RUBBER DAMPNER)	TATA spare parts
581126800192	GEAR SHIFT LEVER ASSY	TATA spare parts
581126803401	LINKAGE BUSH KIT	TATA spare parts
581126803402	NORGLIDE BUSH	TATA spare parts
581126803701	SHIFTING YOKE	TATA spare parts
581126803702	SHIFTING YOKE	TATA spare parts
581126806701	PIN	TATA spare parts
581126806702	PIN	TATA spare parts
581126806703	PIN	TATA spare parts
581126806704	PIN (G.S.L SIDE)	TATA spare parts
581126807708	RUBBER BELLOW (ON TUNNEL)	TATA spare parts
581126807709	FOAM ON TUNNEL	TATA spare parts
581126807713	RUBBER BELLOW EXTENSION ARM TO TUNNEL	TATA spare parts
581126807714	FOAM ON TUNNEL	TATA spare parts
581126808207	CLAMPING PLATE(FOR SEALING ON TUNNEL)	TATA spare parts
581225200101	CLUTCH DISC 352 DIA.(ORGANIC) BS3/4	TATA spare parts
581225200102	DISC FACING KIT-352 DIA ORGANIC	TATA spare parts
581225200352DF	CLUTCH FACING 352 DIA ORG	TATA spare parts
581225200352DFWR	CLUTCH FACING 352 DIA ORG-W/RIVETS	TATA spare parts
581225400101	CLUTCH COVER 352 DIA. BS3/4	TATA spare parts
581225400102	PRESSURE PLATE W/NEEDLE ROLLER BRNG BS4	TATA spare parts
581225400103	KIT-RELEASE LEVER 352DIA. ORGANIC BS1- 4	TATA spare parts
581225400104	RELEASE LEVER WITH EYE BOLT-352 DIA ORG.	TATA spare parts
581225400105	KIT-PR SPRING-352 DIA. ORGANIC BS1/3/4	TATA spare parts

581225406701	COTTOR PIN -352 DIA ORGANIC	TATA spare parts
581225408001	HEX. BOLT	TATA spare parts
581225408201	COVER - 352 DIA. ORGANIC	TATA spare parts
581225408601	COLLECTOR RING - 352 DIA ORG. BS1/3/4	TATA spare parts
581225600101	ASSY. CLUTCH RELEASE BEARING BS1/2/3/4	TATA spare parts
581225600101AE	CLUTCH RELEASE BRG -1415	TATA spare parts
581225600105	ASSY. CLUTCH RELEASE BEARING	TATA spare parts
581225600107	CLUTCH RELEASE BEARING	TATA spare parts
581225601602	ASSY. CLUTCH RELEASE BEARING BS1/2/3/4	TATA spare parts
581225605101	CLUTCH RELEASE YOKE	TATA spare parts
581225607902	CROSS SHAFT	TATA spare parts
581225607903	CROSS SHAFT - G400 G/BOX	TATA spare parts
581326000104	ASSY TA59 OF PENGUIN (1ST GEAR RATIO 26.	TATA spare parts
581326000107	ASSY TA59 OF PENGUIN WITH 1ST GEAR RATIO	TATA spare parts
581326100108	ASSLY B MOUNT BRACKET	TATA spare parts
581326100109	ASSEMBLY C MOUNT BRACKET	TATA spare parts
581326100110	ASSY. C MOUNT BRACKET BS2/3/4	TATA spare parts
581326103801	FRONT HALF HOUSING BS2/3/4	TATA spare parts
581326103802	REAR HALF HOUSING ASSY. TRANSAXLE	TATA spare parts
581326107201	FILLER PLUG	TATA spare parts
581326200102	SUB ASSY 1ST GEAR (LASER WELD VERSION)	TATA spare parts
581326200113	CYL.ROLLER BEARING-INNER & OUTER RACE	TATA spare parts
581326205408	3RD GEAR LAYSHAFT (RATIO 25/26)	TATA spare parts
581326205409	4TH GEAR LAYSHAFT (RATIO 24/32)	TATA spare parts
581326205416	3RD GEAR LAYSHAFT (RATIO:26/25)	TATA spare parts
581326205419	3RD GEAR LASHAFT (RATIO:26/25)	TATA spare parts
581326205420	4TH GEAR LAYSHAFT (RATIO:26/31)	TATA spare parts
581326205421	4TH GEAR LAYSHAFT (RATIO 24/32)	TATA spare parts
581326205422	3RD GEAR LAYSHAFT (RATIO 25/26)	TATA spare parts
581326207902	LAYSHAFT (4 SPD) F.D.RATIO:90/13 BS2/3/4	TATA spare parts
581326207903	LAYSHAFT (4 SPEED) F.D.RATIO 90/14	TATA spare parts
581326250102	SUB ASSY THIRD GEAR (LASER WELD) SOFT ST	TATA spare parts
581326250103	SUB ASSY 4TH GEAR INPUT SHAFT (GEAR RATIO)	TATA spare parts
581326250110	SUB ASSY. 3RD GEAR (LASER WELD) BS2/3/4	TATA spare parts
581326257902	INPUT SHAFT (4-SPEED) (RATIO:1ST=42/11;	TATA spare parts
581326300103	ASSY DRIVE SHAFT COMPLETE LH	TATA spare parts
581326300104	ASSY DRIVE SHAFT COMPLETE RH	TATA spare parts
581326300110	ASSY. DRIVE SHAFT LH BS2/3/4	TATA spare parts
581326300111	ASSY. DRIVE SHAFT RH BS2/3/4	TATA spare parts
581326300112	KIT-BOOT BS2/3/4	TATA spare parts
581326300113	JOINT KIT WHEEL SIDE (LH)	TATA spare parts
581326300114	JOINT KIT WHEEL SIDE (RH)	TATA spare parts
581326300115	JOINT KIT DIFFERENTIAL SIDE (LH)	TATA spare parts
581326300116	JOINT KIT DIFFERENTIAL SIDE (RH)	TATA spare parts
581326300117	ASSY. DRIVESHAFT LH (NEXTEER) BS2/3/4	TATA spare parts
581326300118	ASSY. DRIVESHAFT RH (NEXTEER) BS2/3/4	TATA spare parts
581326300123	AXLE SERVICE KIT (RH)	TATA spare parts



581326300124	AXLE SERVICE KIT (LH)	TATA spare parts
581326300125	SERVICE KIT OB	TATA spare parts
581326300126	SERVICE KIT BOOT	TATA spare parts
581326300127	SERVICE KIT IB	TATA spare parts
581326305402	FINAL DRIVE GEAR (RATIO:90/13) (ASSY DIF	TATA spare parts
581326305403	FINAL DRIVE GEAR (RATIO 90/14) (ASSY DIF	TATA spare parts
581326308701	SPRING	TATA spare parts
581326800102	ASSY. GEAR SHIFTER MECHANISM	TATA spare parts
581326800103	ASSY. GEAR SHIFTING HOUSING BS2/3/4	TATA spare parts
581326800106	ASSEMBLY BELLOW WITH KNOB AND BELLOW HC	TATA spare parts
581326800107	ASSY.GEAR SHIFT & SELECT CABLE BS2/3/4	TATA spare parts
581326806301	RUBBER FLOATING BUSH	TATA spare parts
581326806302	COLLER BUSH	TATA spare parts
581326807701	BELLOW	TATA spare parts
581735000101	ASSY REAR AXLE COMP W/ DAOH DRUM BRK 34	TATA spare parts
581735000109	ASSY RA-1068 COMP W/ S-CAM BRKS 33/8 970	TATA spare parts
581735000115	RA-1068 34/7 COMP W/S-CAM BRKS W/O ABS T	TATA spare parts
581735000117	ASSY RA-1068 33/8 COMP W/S-CAM BRK & W/O	TATA spare parts
581735000125	ASSY RA-1068 COMP W/ S-CAM BRKS 31/7 970	TATA spare parts
581735000131	RA-1068 HD 34/7 W/DAOH DRUM BRK NON ABS	TATA spare parts
581735000132	REAR AXLE ASSY BS6	TATA spare parts
581735000134	RA LPT 909 H EX2 JSR ( 33/8 )	TATA spare parts
581735000135	ASSY RA-1068 COMP W/ S-CAM BRKS 34/7 970	TATA spare parts
581735000138	ASSY RA-1068 S-CAM BRK 34/7 WABCO-ABS T-	TATA spare parts
581735000147	REAR AXLE ASSY WITH BRAKE	TATA spare parts
581735000151	REAR AXLE 1068 COMP 34/7 S-CAM BRAKES 97	TATA spare parts
581735000157	ASSY RA-1068 33/8 S-CAM BRK 970 SCD W\O	TATA spare parts
581735000160	ASSY REAR AXLE RA-1068 COMPLETE	TATA spare parts
581735000162	ASSY REAR AXLE RA-1068 S-CAM 33/8 N/ABS	TATA spare parts
581735000164	ASSY REAR AXLE RA1068-HD W/S-CAM BRK 33/	TATA spare parts
581735000172	REAR AXLE ASSY W/S-CAM BRKS 33/8	TATA spare parts
581735000177	REAR AXLE ASSY WITH BRAKE	TATA spare parts
581735000187	REAR AXLE ASSY RA-1068 S-CAM BRK 34/7 KB	TATA spare parts
581735000188	REAR AXLE ASSY RA-1068 S-CAM BRK 33/8 KB	TATA spare parts
581735000198	AXLE ASSY WITH BRAKE	TATA spare parts
581735000202	AXLE ASSY WITH BRAKE	TATA spare parts
581735000204	REAR AXLE ASSY WITH BRAKE	TATA spare parts
581735000219	REAR AXLE ASSY	TATA spare parts
581735000220	AXLE ASSY WITH BRAKE	TATA spare parts
581735000221	REAR AXLE ASSY	TATA spare parts
581735000224	AXLE ASSY WITH BRAKE	TATA spare parts
581735000228	REAR AXLE ASSY WITH BRAKE	TATA spare parts
581735000238	REAR AXLE ASSY WITH BRAKE	TATA spare parts
581735000263	REAR AXLE ASSY BS6	TATA spare parts
581735000265	REAR AXLE ASSY	TATA spare parts
581735000266	AXLE ASSY WITH BRAKE	TATA spare parts
581735000274	AXLE ASSY WITH BRAKE BS6	TATA spare parts

581735000275	AXLE ASSY WITH HUB	TATA spare parts
581735000283	AXLE ASSY WITH BRAKE BS6	TATA spare parts
581735000284	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
581735000293	REAR AXLE ASSY BS6	TATA spare parts
581735000295	REAR AXLE ASSY BS6	TATA spare parts
581735000296	REAR AXLE ASSY WITH HUB BS6	TATA spare parts
581735000302	REAR AXLE ASSY BS6	TATA spare parts
581735000303	REAR AXLE ASSY BS6	TATA spare parts
581735000317	AXLE ASSY WITH BRAKE BS6	TATA spare parts
581735000326	REAR AXLE ASSY WITH HUB BS6-PH2	TATA spare parts
581735000329	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
581735000331	AXLE ASSY WITH BRAKE	TATA spare parts
581735000345	AXLE ASSY WITH BRAKE	TATA spare parts
581735000346	AXLE BEAM ASSY WITH RING AND STUD PRESSU	TATA spare parts
581735100101	ASSY REAR AXLE BEAM W/PRESSURE RING DOWE	TATA spare parts
581735100107	ASSY REAR AXLE BEAM W/PRESSURE RING DOWE	TATA spare parts
581735100108	ASSY REAR AXLE BEAM MACHINED (RA 1068)-B	TATA spare parts
581735100109	ASSY REAR AXLE BEAM W/PRESSURE RING DOWE	TATA spare parts
581735100110	AXLE BEAM ASSY	TATA spare parts
581735100115	ASSY REAR AXLE BEAM W/PRESSURERING LPT-9	TATA spare parts
581735100121	ASSY REAR AXLE BEAM (MACHINED)	TATA spare parts
581735100122	ASSY REAR AXLE BEAM W/PRESSURERING STUDS	TATA spare parts
581735100128	ASSY REAR AXLE BEAM W/PRESSURE RING	TATA spare parts
581735100135	ASSY RA BEAM W \PRESS RING DOWEL & STUDS	TATA spare parts
581735100136	ASSY REAR AXLE BEAM (MACHINED) BS6	TATA spare parts
581735100137	ASSY RA BEAM W /PRESS RING DOWEL & STUDS	TATA spare parts
581735100139	ASSY RA BEAM W PRESS RING DOWEL & STUDS	TATA spare parts
581735100140	ASSY REAR AXEL BEAM (MACHINED)	TATA spare parts
581735100141	AXLE BEAM ASSY BS6	TATA spare parts
581735100142	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
581735100144	ASSY BEAM W PRESS RING DOWEL & STUDS	TATA spare parts
581735100147	REAR AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
581735100166	REAR AXLE ASSY	TATA spare parts
581735100167	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
581735100174	REAR AXLE BEAM ASSY BS6	TATA spare parts
581735100175	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
581735100183	AXLE BEAM ASSY WITH RING & STUD BS6-PH2	TATA spare parts
581735100189	REAR AXLE BEAM ASSY BS6-PH2	TATA spare parts
581735100190	AXLE BEAM ASSY WITH RING & STUD BS6-PH2	TATA spare parts
581735100196	REAR AXLE BEAM ASSY BS6-PH2	TATA spare parts
581735108001	SERRATED BOLT(M12X1.75X35)	TATA spare parts
581735108002	SERRATED BOLT(M12X1.75X55)	TATA spare parts
581735108601	PRESSURE RING	TATA spare parts
581735110101	ASSY CARRIER HOUSING COMP(34/7)	TATA spare parts
581735110102	ASSY. CARRIER HOUSING (RA 1068) BS3/4/6	TATA spare parts
581735110103	ASSY CARRIER HOUSING COMP(33/8)	TATA spare parts
581735110104	ASSY CARRIER HOUSING COMP 33/8 T120-SPIR	TATA spare parts

581735110107	CARRIER HOUSING ASSY BS6	TATA spare parts
581735110108	ASSY CARRIER HOUSING COMP(34/7)	TATA spare parts
581735110112	CARRIER HOUSING ASSY	TATA spare parts
581735110130	CARRIER HOUSING ASSY WITH PLUMMER BLOCK	TATA spare parts
581735110131	CARRIER HOUSING ASSY BS6-PH2	TATA spare parts
581735110132	CARRIER HOUSING ASSY WITH PLUMMER BLOCK	TATA spare parts
581735110135	CARRIER HOUSING ASSY (FOR RATION 34/7)	TATA spare parts
581735110139	CARRIER HOUSING ASSY BS6-PH2	TATA spare parts
581735300101	ASSY DIFFERENTIAL(34/7)	TATA spare parts
581735300103	ASSY. DIFFERENTIAL HSG.(RA 1068) BS3/4/6	TATA spare parts
581735300104	ASSY. CROWN & PINION(34/7 OERLIKON)BS3/4	TATA spare parts
581735300105	ASSY DIFFERENTIAL GEARS	TATA spare parts
581735300106	ASSY DIFFERENTIAL GEARS(M/S SONA)	TATA spare parts
581735300107	OIL SEAL HOUSING ASSY (TAIL PINION)	TATA spare parts
581735300108	ASSY DIFFERENTIAL(33/8)	TATA spare parts
581735300109	ASSY. CROWN & PINION (33/8) SPIRAC BS3/4	TATA spare parts
581735300113	ASSY CROWN WHEEL & PINION 31/7 SPIRAC	TATA spare parts
581735300115	COUPLING FLANGE ASSY	TATA spare parts
581735300120	DIFFERENTIAL ASSY BS6	TATA spare parts
581735300130	CROWN WHEEL & PINION ASSY	TATA spare parts
581735300133	CROWN WHEEL & PINION ASSY BS6	TATA spare parts
581735300137	CROWN WHEEL & PINION ASSY	TATA spare parts
581735300146	DIFFERENTIAL ASSY WITH CROWN WHEEL W/84	TATA spare parts
581735300148	DIFFERENTIAL HOUSING ASSY EV	TATA spare parts
581735300151	DIFFERENTIAL HOUSING ASSY BS6-PH2	TATA spare parts
581735303101	CYL. ROLLER BEARING	TATA spare parts
581735303103	TAPER ROLLER BEARING	TATA spare parts
581735303104	TAPER ROLLER BEARING 70 X 115 X 29 EV	TATA spare parts
581735303701	PINION HOUSING(CAST)	TATA spare parts
581735303702	OIL SEAL HOUSING(TAIL PINION)	TATA spare parts
581735305102	DIFFERENTIAL CASE	TATA spare parts
581735305402	DRIVE PINION EV	TATA spare parts
581735305403	REAR AXLE SHAFT GEAR( FORGED)	TATA spare parts
581735305405	PINION 33/8 SPIRAC	TATA spare parts
581735305407	DRIVE PINION (OERLIKON -SPIRAC)-31/7	TATA spare parts
581735305422	GEAR REAR AXLE SHAFT BS6-PH2	TATA spare parts
581735305423	DIFFERENTIAL BEVEL GEAR BS6-PH2	TATA spare parts
581735306101	LOCKING PLATE (DIFFERENTIAL CASE)	TATA spare parts
581735306103	LOCKING PLATE FOR DIFFERENTIAL BOLT LOCK	TATA spare parts
581735306104	LOCKING PLATE	TATA spare parts
581735306501	DIFFERENTIAL THREADED RING	TATA spare parts
581735308001	ADJUSTING PIN	TATA spare parts
581735308002	HEX BOLT DIFF ASSY EV	TATA spare parts
581735308003	HEX BOLT DIFF ASSY EV	TATA spare parts
581735308302	DEPTH SETTING SHIM 0.1 THK (BETWEEN CARR	TATA spare parts
581735308303	DEPTH SETTING SHIM 0.15 THK (BETWEEN CAR	TATA spare parts
581735308304	DEPTH SETTING SHIM 0.20 THK (BETWEEN CAR	TATA spare parts

581735308305	DEPTH SETTING SHIM 0.25 THK (BETWEEN CAR	TATA spare parts
581735308306	DEPTH SETTING SHIM 0.30 THK (BETWEEN CAR	TATA spare parts
581735308308	DEPTH SETTING SHIM 0.50 THK (BETWEEN CAR	TATA spare parts
581735308309	DEPTH SETTING SHIM 1.00 THK (BETWEEN CAR	TATA spare parts
581735308310	DEPTH SETTING SHIM 1.50 THK (BETWEEN CAR	TATA spare parts
581735308312	PINION BEARING PRELOADING SHIM(0.10 THK)	TATA spare parts
581735308313	PINION BEARING PRELOADING SHIM(0.15 THK)	TATA spare parts
581735308314	PINION BEARING PRELOADING SHIM(0.20 THK)	TATA spare parts
581735308315	PINION BEARING PRELOADING SHIM(0.25 THK)	TATA spare parts
581735308316	PINION BEARING PRELOADING SHIM(0.30 THK)	TATA spare parts
581735308317	PINION BEARING PRELOADING SHIM(0.40 THK)	TATA spare parts
581735308319	PINION BEARING PRELOADING SHIM(0.50 THK)	TATA spare parts
581735308320	PINION BEARING PRELOADING SHIM(1.00 THK)	TATA spare parts
581735308321	PINION BEARING PRELOADING SHIM(1.50 THK)	TATA spare parts
581735309201	THRUST WASHER SHAFT GEAR 1.95 THK	TATA spare parts
581735309202	THRUST WASHER SHAFT GEAR 2.00 THK	TATA spare parts
581735309203	THRUST WASHER SHAFT GEAR 2.05 THK	TATA spare parts
581735309204	THRUST WASHER SHAFT GEAR 2.10 THK	TATA spare parts
581735309205	THRUST WASHER SHAFT GEAR 2.15 THK	TATA spare parts
581735309206	THRUST WASHER SHAFT GEAR 2.20 THK	TATA spare parts
581735309207	THRUST WASHER SHAFT GEAR 2.30 THK	TATA spare parts
581735600102	ASSY REAR HUB W/PINS	TATA spare parts
581735600110	ASSY REAR HUB COMP (W/O ABS)	TATA spare parts
581735600112	ASSY REAR HUB COMP(WGT RED W\O ABS)	TATA spare parts
581735600113	ASSY REAR HUB W/PINS	TATA spare parts
581735600114	ASSY REAR HUB COMP (BUS WGT RED W\ABS)	TATA spare parts
581735600115	ASSY REAR HUB W/PINS ABS(9.6T BUS WGT.RE	TATA spare parts
581735600120	HUB ASSY BS6-PH2	TATA spare parts
581735601601	REAR HUB INNER OIL SEAL	TATA spare parts
581735601602	TAPER ROLLER BEARING(HUB INNER 75X125X37	TATA spare parts
581735603106	BEARING BS6-PH2	TATA spare parts
581735603701	REAR HUB(RA 1068)	TATA spare parts
581735603705	REAR HUB SPIGOTTED	TATA spare parts
581735603707	REAR HUB BS6	TATA spare parts
581735603710	REAR HUB BS6-PH2	TATA spare parts
581735605301	GASKET(BETN REAR HUB & AXLE SHAFT)	TATA spare parts
581735605302	GASKET(BETN REAR HUB & AXLE SHAFT)	TATA spare parts
581735606503	LOCK NUT BS6-PH2	TATA spare parts
581735607701	HUB INNER SEAL(100 X 125 X12) BS3/4	TATA spare parts
581735607701DF	HUB OIL SEAL INNER-100X125X12-RA1068-TRU	TATA spare parts
581735607702	HUB OUTER SEAL (110 X 128 X 9) BS1/2/3/4	TATA spare parts
581735607702DF	HUB OIL SEAL OUTER-110X128X9-RA1068-TRUC	TATA spare parts
581735608001	SERRATED HEX BOLT(AXLE SHAFT TO HUB)	TATA spare parts
581735608201	OIL CATCHER(RA 1068)	TATA spare parts
581735608203	OIL CATCHER BS6-PH2	TATA spare parts
581735608601	SPACER(BETWEEN REAR HUB BEARING)	TATA spare parts
581735608602	SPACER RING FOR HUB INNER OIL SEAL	TATA spare parts

581735608609	TONGUE SPACER BS6-PH2	TATA spare parts
581735608610	SPACER BS6-PH2	TATA spare parts
581735707901	REAR AXLE SHAFT BS3/4	TATA spare parts
581735707903	REAR AXLE SHAFT(RA 1068)-1730 TRK	TATA spare parts
581735707905	REAR AXLE SHAFT(TRUCK WEIGHT REDUCTION)	TATA spare parts
581735707906	REAR AXLE SHAFT(BUS WEIGHT REDUCTION)	TATA spare parts
581735707909	REAR AXLE SHAFT (W/1684 TRACK) BS4	TATA spare parts
581735707911	REAR AXLE SHAFT BS6-PH2	TATA spare parts
581735707912	REAR AXLE SHAFT BS6-PH2	TATA spare parts
581735707913	REAR AXLE SHAFT BS6-PH2	TATA spare parts
5817H9W0135001	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
5817H9W0135003	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
5817H9W0135005	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
5817H9W0135011	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
581927000101	ASSY AUTO TRANS.- PROVISION FOR TOP MOUN	TATA spare parts
581927000115	ASSY KIT FOR WHAP TRANS	TATA spare parts
581927000134	KIT-AUTOMATIC TRANSMISSION	TATA spare parts
581927000135	KIT-AUTOMATIC TRANSMISSION	TATA spare parts
581927000136	GEARBOX ASSEMBLY FOR 4500 SP	TATA spare parts
581927009901	BOLT- M8X1.5X20LG	TATA spare parts
581927009903	FLANGE OUTPUT ISO 180C/S	TATA spare parts
581927400101	ASSY. PTO 859X B5 XV	TATA spare parts
581927400115	PTO ASSY	TATA spare parts
581927400116	PTO ASSY	TATA spare parts
581927400117	PTO ASSY	TATA spare parts
581927400118	CONNECTOR	TATA spare parts
581927700110	TRANSMISSION CONTROL MODULE	TATA spare parts
581927700115	PUSH BUTTON SELECTOR	TATA spare parts
581927808201	DOUBLE¿CLAMP¿(CABLE¿CLAMPING)	TATA spare parts
581927900106	ASSY. COMPLETE OIL COOLER MOUNTING BRACK	TATA spare parts
581927900109	ASSY. TRANS OIL COOLER EURO3	TATA spare parts
581927900186	HOSE OIL COOLER INLET	TATA spare parts
581927900187	HOSE OIL COOLER OUTLET	TATA spare parts
581927900188	OIL COOLER ASSY	TATA spare parts
581927900189	BRACKET OIL COOLER ASSY	TATA spare parts
581927900190	BRACKET ASSY OIL COOLER MTG	TATA spare parts
581927900191	BRACKET ASSY OIL COOLER MTG	TATA spare parts
581927900192	ELBOW CONNECTOR COOLER	TATA spare parts
581927900193	DIPSTICK	TATA spare parts
581927903402	ELBOW CONNECTOR TRANS SIDE(29555329)	TATA spare parts
581927907106	CLAMP-1 (OIL HOSE CLAMPING LPTA2038 CFT)	TATA spare parts
581927907107	CLAMP-2 (OIL HOSE CLAMPING LPTA2038 CFT)	TATA spare parts
581927907112	CLAMP-5 (OIL HOSE CLAMPING LPTA2038 CFT)	TATA spare parts
581927907114	RADIATOR GUARD MOUNTING BRACKET (LPTA 20	TATA spare parts
581927907115	RADIATOR GUARD MOUNTING BRACKET (LPTA 20	TATA spare parts
581927990102	GEAR FLYWHEEL RING (TEETH=138)	TATA spare parts
581927990127	BACKPLATE ASSEMBLY CLUTCH	TATA spare parts

581927990129	HOUSING C3 CLUTCH	TATA spare parts
581927990130	HOUSING C4 CLUTCH	TATA spare parts
581927990134	GASKET & SEAL KIT FOR OUTPUTS XY ONLY	TATA spare parts
581927990135	BEARING KIT XY (890 ONLY)	TATA spare parts
581927990136	CLUTCH REPAIR KIT (890 & 890C SERIES)	TATA spare parts
581927993101	SPACER BEARING	TATA spare parts
581927993103	BEARING ASSEMBLY ROLLER	TATA spare parts
581927993104	BEARING ASSEMBLY THRUST	TATA spare parts
581927993105	BEARING ASSEMBLY ROLLER	TATA spare parts
581927993116	BEARING ASSEMBLY BALL	TATA spare parts
581927993118	BEARING ASSEMBLY ROLLER	TATA spare parts
581927993201	BOLT FLANGE HD M10 X 1.5 X 100 MM .	TATA spare parts
581927993301	BRACKET SPEED SENSOR	TATA spare parts
581927993405	CARRIER AND BUSHING ASSEMBLY	TATA spare parts
581927993410	RETAINER AND BUSHING ASSEMBLY BEARING	TATA spare parts
581927993411	BUSHING 89 MM ID	TATA spare parts
581927993701	HOUSING ASSEMBLY MAIN	TATA spare parts
581927993703	HOUSING PUMP	TATA spare parts
581927993705	HOUSING CONVERTER. WHEN CHANGING TO LA	TATA spare parts
581927994601	COVER SHIPPING OUTPUT	TATA spare parts
581927994611	HUB ASSEMBLY ROTATING CLUTCH	TATA spare parts
581927994616	HUB PTO DRIVE	TATA spare parts
581927994704	COVER PTO	TATA spare parts
581927994901	SENSOR ASSEMBLY SPEED	TATA spare parts
581927994906	CONNECTOR TWO-WAY	TATA spare parts
581927994907	TERMINAL SOCKET 150 SERIES	TATA spare parts
581927994908	LOCK SECONDARY	TATA spare parts
581927994910	LOCK SECONDARY TPA	TATA spare parts
581927994911	CONNECTOR PLUG THREE-WAY	TATA spare parts
581927994913	TERMINAL SOCKET 280 SERIES	TATA spare parts
581927994915	TERMINAL SOCKET 150.2 SERIES	TATA spare parts
581927994917	SENSOR ASSEMBLY-SPEED	TATA spare parts
581927995302	GASKET CASE	TATA spare parts
581927995304	GASKET PTO COVER .	TATA spare parts
581927995328	GASKET REAR COVER	TATA spare parts
581927995401	GEAR P1 PLANETARY RING	TATA spare parts
581927995402	GEAR P2 SUN	TATA spare parts
581927995405	GEAR SET P1 PINION SET CONTAINS SIX 295	TATA spare parts
581927995406	RING GEAR P2 PLANETARY	TATA spare parts
581927995410	GEAR SET P2 PINION. SET CONTAINS FOUR 2	TATA spare parts
581927995411	GEAR P3 PLANETARY RING.	TATA spare parts
581927995417	GEAR SET P3 PINION SET CONTAINS FOUR 29	TATA spare parts
581927995418	GEAR ASSEMBLY PTO	TATA spare parts
581927995419	GEAR PTO	TATA spare parts
581927996101	RING RETAINING EXTERNAL 546 MM ID	TATA spare parts
581927996103	CAMSHAFT BRACKET	TATA spare parts
581927996601	PISTON ASSEMBLY C3 CLUTCH	TATA spare parts

581927996604	PISTON C1	TATA spare parts
581927996605	PISTON BLANCE ROTATING CLUTCH	TATA spare parts
581927996803	DIPSTICK-OIL LEVEL INDICATOR	TATA spare parts
581927996805	SWITCH ASSY - PRESSURE	TATA spare parts
581927996813	TEE CONNECTOR	TATA spare parts
581927996816	HOSE - PRESSURE	TATA spare parts
581927996817	HOSE - WET SPLINE	TATA spare parts
581927996818	TEE CONNECTOR	TATA spare parts
581927996822	COVER AND PLUG ASSEMBLY REAR	TATA spare parts
581927997101	PLATE P1 THRUST	TATA spare parts
581927997102	PLATE C3 CLUTCH FRICTION	TATA spare parts
581927997103	PLATE C3 CLUTCH REACTION	TATA spare parts
581927997104	PLATE ASSEMBLY C3 PISTON RETURN	TATA spare parts
581927997105	PLATE C5 CLUTCH REACTION	TATA spare parts
581927997106	PLATE C5 CLUTCH FRICTION	TATA spare parts
581927997115	PLATE C1 CLUTCH APPLY	TATA spare parts
581927997116	PLATE C1 FRICTION	TATA spare parts
581927997118	BACKPLATE C1 CLUTCH	TATA spare parts
581927997120	PLATE C2 FRICTION	TATA spare parts
581927997203	PLUG COOLER PORT 1 5/1612	TATA spare parts
581927997809	SEALRING KIT EXTERNAL BUTTJOINT 594 MM	TATA spare parts
581927997817	SEAL ASSEMBLY OIL 110.42 MM OD. USED S	TATA spare parts
581927997818	SEALRING KIT EXTERNAL BUTTJOINT 108.0 M	TATA spare parts
581927997819	SEALRING 245.6 MM ID. COLOR CODED WHITE	TATA spare parts
581927997827	SEAL ASSEMBLY OUTPUT SEE SIL 6WT07	TATA spare parts
581927997842	SEAL ASSEMBLY OIL 110.27 MM OD. USED P	TATA spare parts
581927997902	SHAFT MAIN	TATA spare parts
581927997903	SPINDLE P1 PLANETARY PINION SEE SIL 10W	TATA spare parts
581927997904	SPINDLE P2 PLANETARY PINION. SEE SIL 10	TATA spare parts
581927997905	SHAFT ASSEMBLY TURBINE	TATA spare parts
581927997909	SPINDLE P3 PLANET	TATA spare parts
581927998401	TURBINE SHAFT. SEE SIL 22WT94	TATA spare parts
581927998601	RING P1 INDEXING SEE SIL 10WT00	TATA spare parts
581927998702	SPRING TRIM CONICAL. COLOR CODED YELLO	TATA spare parts
581927999201	WASHER P1 PINION THRUST	TATA spare parts
581927999202	WASHER P2 PINION THRUST	TATA spare parts
581927999206	WASHER THRUST	TATA spare parts
581927999207	WASHER THRUST	TATA spare parts
581927999208	WASHER BELLEVILLE	TATA spare parts
581927999222	RING RETAINING INTERNAL 256 MM OD	TATA spare parts
581927999225	CARRIER P3 PLANETARY	TATA spare parts
581927999226	BRACKET HARNESS	TATA spare parts
581927999227	VALVE ASSEMBLY CONTROL	TATA spare parts
581927999228	FILTER ASSEMBLY KIT SUCTION	TATA spare parts
581927999232	PLATE HARNESS CHANNEL	TATA spare parts
581927999233	BRACKET SOLENOID RIGHT SIDE	TATA spare parts
581927999234	BODY ASSEMBLY SOLENOID VALVE AND PIN	TATA spare parts

581927999236	VALVE TCC. SEE 06-WT-22.	TATA spare parts
581927999237	VALVE PCS 1. SEE 06-WT-22.	TATA spare parts
581927999238	PLATE SOLENOID SEPARATOR	TATA spare parts
581927999240	VALVE CONVERTER FLOW	TATA spare parts
581927999241	SPRING CONVERTER FLOW. NO COLOR CODE.	TATA spare parts
581927999242	CLIP CONVERTER FLOW	TATA spare parts
581927999243	VALVE LUBE REGULATOR	TATA spare parts
581927999244	SPRING LUBE REGULATOR. COLOR CODED ORAN	TATA spare parts
581927999245	VALVE MAIN REGULATOR. SEE 23-WT-19.	TATA spare parts
581927999246	SPRING MAIN REGULATOR. NO COLOR CODE.	TATA spare parts
581927999247	STOP MAIN REGULATOR	TATA spare parts
581927999248	BODY MAIN CONTROL VALVE. SEE 03-WT-21.	TATA spare parts
581927999249	VALVE C2 LATCH	TATA spare parts
581927999250	STOP C2 LATCH	TATA spare parts
581927999251	SPRING EXHAUST BACKFILL. COLOR CODED GR	TATA spare parts
581927999252	VALVE C1 LATCH	TATA spare parts
581927999253	VALVE CONVERTER RELIEF	TATA spare parts
581927999254	SPRING CONVERTER RELIEF. COLOR CODED WH	TATA spare parts
581927999255	VALVE CONVERTER REGULATOR	TATA spare parts
581927999256	SPRING FILTER LIFE VALVE. COLOR CODED R	TATA spare parts
581927999257	FILTER OIL. OIL FILTER SERVICE KIT 2955	TATA spare parts
581927999259	PLATE SEPARATOR	TATA spare parts
581927999260	GASKET CHANNEL PLATE	TATA spare parts
581927999911	KIT MOUNTING & INSTALLATION XY	TATA spare parts
581927999931	VALVE	TATA spare parts
581927999950	NUT OUTPUT	TATA spare parts
581927999957	PUMP ASSEMBLY CONVERTER	TATA spare parts
582126104801	DOWEL PIN (FRONT & REAR HALF)	TATA spare parts
582126201602	FOUR POINT BALL BRG (60 X130X31) BS3/4	TATA spare parts
582126203102	FOUR POINT BALL BEARING BS6	TATA spare parts
582126203103	CYLINDRICAL ROLLER BEARING	TATA spare parts
582126203111	NEEDLE CAGE BS6-PH2	TATA spare parts
582126203115	FOUR POINT BALL BEARING BS6	TATA spare parts
582126203117	CYLINDRICAL ROLLER BS6	TATA spare parts
582126204327	INTERNAL CIRCLIP (3.90 THK.)(MAIN SHAFT	TATA spare parts
582126204328	INTERNAL CIRCLIP (3.95 THK.)(MAIN SHAFT	TATA spare parts
582126204329	INTERNAL CIRCLIP (4.00 THK.)(MAIN SHAFT R	TATA spare parts
582126204330	INTERNAL CIRCLIP (4.05 THK.)(MAIN SHAFT	TATA spare parts
582126204331	INTERNAL CIRCLIP (4.10 THK.)(MAIN SHAFT	TATA spare parts
582126204332	INTERNAL CIRCLIP (4.15 THK.)( MAIN SHAFT	TATA spare parts
582126204333	INTERNAL CIRCLIP 4.20 THK. (MAIN SHAFT R	TATA spare parts
582126204334	INTERNAL CIRCLIP (4.25 THK.)(MAIN SHAFT	TATA spare parts
582126204335	INTERNAL CIRCLIP (4.30 THK.)(MAIN SHAFT	TATA spare parts
582126204336	INTERNAL CIRCLIP (4.35 THK.)(MAIN SHAFT	TATA spare parts
582126204337	INTERNAL CIRCLIP 4.40 THK. (MAIN SHAFT R	TATA spare parts
582126204338	INTERNAL CIRCLIP 4.45 THK. (MAIN SHAFT R	TATA spare parts
582126204339	INTERNAL CIRCLIP 4.50 THK. (MAIN SHAFT R	TATA spare parts



582126204340	INTERNAL CIRCLIP 4.55 THK. (MAIN SHAFT R	TATA spare parts
582126204341	INTERNAL CIRCLIP 4.60 THK. (MAIN SHAFT R	TATA spare parts
582126204342	INTERNAL CIRCLIP 4.65 THK. (MAIN SHAFT R	TATA spare parts
582126204604	SHIFTER SLEEVE 5TH/6TH SPEED BS3/4/6	TATA spare parts
582126204607	ENGAGING GEAR (REVERSE)	TATA spare parts
582126204609	SYNCHRO CONE 5TH/6TH SPEED BS3/4/6	TATA spare parts
582126204610	SYNCHRO CONE 5TH/6TH SPEED	TATA spare parts
582126207803	OIL SEAL REAR COVER	TATA spare parts
582126208701	COMPRESSION SPRING SYNCHRONISER	TATA spare parts
582126209901	CARRIER BS2/4	TATA spare parts
582126304315	INTERNAL CIRCLIP (3.90 THK.)(COUNTER SHA	TATA spare parts
582126304316	INTERNAL CIRCLIP (3.95 THK.)(COUNTER SHA	TATA spare parts
582126304317	INTERNAL CIRCLIP (4.00 THK.)(COUNTER SHA	TATA spare parts
582126304318	INTERNAL CIRCLIP (4.05 THK.)(COUNTER SHA	TATA spare parts
582126304319	INTERNAL CIRCLIP (4.10 THK.)(COUNTER SHA	TATA spare parts
582126304320	INTERNAL CIRCLIP (4.15 THK.)(COUNTER SHA	TATA spare parts
582126304321	INTERNAL CIRCLIP (4.20 THK.)(COUNTER SHA	TATA spare parts
582126304322	INTERNAL CIRCLIP (4.25 THK.)(COUNTER SHA	TATA spare parts
582126304323	INTERNAL CIRCLIP (4.30 THK.)(COUNTER SHA	TATA spare parts
582126304324	INTERNAL CIRCLIP (4.35 THK.)(COUNTER HAL	TATA spare parts
582126304325	INTERNAL CIRCLIP (4.40 THK.)(COUNTER SHA	TATA spare parts
582126304326	INTERNAL CIRCLIP (4.45 THK.)(COUNTER SHA	TATA spare parts
582126304327	INTERNAL CIRCLIP (4.50 THK.)(COUNTER SHA	TATA spare parts
582126304328	INTERNAL CIRCLIP (4.55 THK.)(COUNTER SHA	TATA spare parts
582126353102	NEEDLE CAGE	TATA spare parts
582126355301	GASKET ( R I WINDOW )	TATA spare parts
582126358201	COVER (R I WINDOW)	TATA spare parts
582126358601	SPACER (R I SHAFT)	TATA spare parts
582126400101	ASSY. PTO BS4/6	TATA spare parts
582126516702	SPIRAL DOWEL (DIA 6)	TATA spare parts
582126516703	SPIRAL DOWEL (DIA 8)	TATA spare parts
582233158601	PRESSURE RING	TATA spare parts
582233256101	LOCKING PLATE	TATA spare parts
582233257901	SUPPORT SLEEVE FRONT AXLE	TATA spare parts
582233451601	OIL SEAL (HUB INNER-DOUBLE LIP)	TATA spare parts
582233453104	TAPER ROLLER BEARING (70X110X25)	TATA spare parts
582233453107	TAPER ROLLER BEARING (66.675X110X22)	TATA spare parts
582233455301	GASKET (BETWEEN FRONT HUB)	TATA spare parts
582233455501	WHEEL HUB (FRONT) SPIGOTTED	TATA spare parts
582233755101	FOLLOWER	TATA spare parts
582233758601	SPACER (FOR FOLLOWER)	TATA spare parts
582233858001	HEX COLLER SCREW (HSG. TO SUPP. SLEEVE)	TATA spare parts
582326108804	STUD (M10)	TATA spare parts
582326108806	STUD (M10)	TATA spare parts
582525104801	SLEEVE	TATA spare parts
582525400114	CLUTCH COVER ASSY DIA.200	TATA spare parts
582525600109	CLUTCH RELEASE BEARING ASSY	TATA spare parts

582628000104	TRANSFER CASE (W/O DIFFERENTIAL)	TATA spare parts
582628000107	ASSY. TRANSFER CASE TC2500	TATA spare parts
582628000109	ASSEMBLY TC2500 W/O PUMP & PTO	TATA spare parts
582628000112	ASSY AGB TC2500 L 1.52 W/O DIFF 180CF EX	TATA spare parts
582628000114	AUX GEAR BOX LPTA 2038	TATA spare parts
582628000114AE	AUX GEAR BOX LPTA 2038	TATA spare parts
582628000132	TRANSFER CASE ASSY	TATA spare parts
582628100101	ASSEMBLY REAR HOUSING (WITH COVERS)	TATA spare parts
582628100103	ASSEMBLY FRONT HOUSING	TATA spare parts
582628100104	ASSY. REAR HOUSING (WITHOUT OUTPUT BEARI	TATA spare parts
582628103701	HOUSING REAR HALF	TATA spare parts
58262810370151	HOUSING REAR HALF- NM	TATA spare parts
582628103702	HOUSING FRONT HALF	TATA spare parts
58262810370251	HOUSING FRONT HALF- NM	TATA spare parts
582628109901	PLUG (OIL PATH)	TATA spare parts
582628150101	ASSEMBLY FILTER BREATHER AND ADAPTOR	TATA spare parts
582628200101	ASSEMBLY INPUT SHAFT	TATA spare parts
582628200102	ASSEMBLY OIL PUMP HOUSING	TATA spare parts
582628200105	ASSEMBLY COVER INPUT SHAFT (FRONT HALF)	TATA spare parts
582628201604	ASSEMBLY OIL PUMP	TATA spare parts
582628203101	TAPER ROLLER BEARING (INPUT SHAFT)	TATA spare parts
582628203701	BEARING COVER (INPUT SHAFT-REAR HALF)	TATA spare parts
582628203702	OIL PUMP HOUSING	TATA spare parts
582628203703	COVER (OIL PUMP HOUSING)	TATA spare parts
582628203705	COVER INPUT SHAFT (FRONT HALF)	TATA spare parts
582628203706	OIL PUMP COVER	TATA spare parts
582628203707	OIL PUMP GEAR HOUSING	TATA spare parts
582628204302	EXTERNAL CIRCLIP SHIFTER SHAFT	TATA spare parts
582628204601	SHIFTER SLEEVE (INPUT SHAFT)	TATA spare parts
582628205101	COUPLING FLANGE (INPUT SHAFT/REAR AXLE S	TATA spare parts
582628205401	HIGH RANGE GEAR (INPUT SHAFT)	TATA spare parts
582628205402	LOW RANGE GEAR (INPUT SHAFT)	TATA spare parts
582628205403	INTERNAL GEAR (OIL PUMP)	TATA spare parts
582628205404	EXTERNAL GEAR (OIL PUMP)	TATA spare parts
582628206501	HEX FLANGE NUT (COUPLING FLANGE)	TATA spare parts
582628206502	BEARING LOCK NUT (INPUT SHAFT)	TATA spare parts
582628206503	BUSH INPUT SHAFT( W/O P.T.O)	TATA spare parts
582628206504	BUSH (INPUT SHAFT)	TATA spare parts
582628207101	COVER OIL PUMP LID TOP	TATA spare parts
582628207801	OIL SEAL OUTER (INPUT/REAR OUTPUT SHAFT)	TATA spare parts
582628207802	OIL SEAL INNER (INPUT/REAR OUTPUT SHAFT)	TATA spare parts
582628207901	INPUT SHAFT	TATA spare parts
582628208301	SELECTION SHIM (0.25 THK.) (INPUT SHAFT)	TATA spare parts
582628208302	SELECTION SHIM (INPUT SHAFT)	TATA spare parts
582628208303	SELECTION SHIM (0.35 THK.) (INPUT SHAFT)	TATA spare parts
582628208304	SELECTION SHIM (0.40 THK.) (INPUT SHAFT)	TATA spare parts
582628208305	SELECTION SHIM (0.45 THK.) (INPUT SHAFT)	TATA spare parts

582628208306	SELECTION SHIM INPUT SHAFT (0.50 THK)	TATA spare parts
582628208307	SELECTION SHIM INPUT SHAFT (0.55 THK)	TATA spare parts
582628208308	SELECTION SHIM INPUT SHAFT (0.60 THK)	TATA spare parts
582628300101	ASSEMBLY FINAL DRIVE GEAR	TATA spare parts
582628300102	ASSEMBLY PLANET CARRIER	TATA spare parts
582628300107	ASSEMBLY COVER OUTPUT SHAFT	TATA spare parts
582628300108	ASSEMBLY PLANET CARRIER HOUSING WITH FIN	TATA spare parts
582628300109	ASSEMBLY OIL CATCHER (FINAL DRIVE GEAR)	TATA spare parts
582628300110	ASSY FD GEAR & PLANET CARRIER (FOR DOWEL	TATA spare parts
582628300111	ASSEMBLY COVER O/P SHAFT(FOR BUSH M/C)	TATA spare parts
582628300112	ASSEMBLY FD GEAR SHAFT (W/O DIFFERENTIAL	TATA spare parts
582628300402	SELECTION SHIM (FRONT OUTPUT)	TATA spare parts
58262830160999	ASSLY KIT DIFF-LOCK AIR CYLINDER	TATA spare parts
582628303101	SPH. ROLLER BEARING-DOUBLE ROW (REAR HOU	TATA spare parts
582628303102	TAPER ROLLER BEARING (FINAL DRIVE GEAR)	TATA spare parts
582628303103	CYLINDRICAL ROLLER BEARING (OUTPUT SHAFT	TATA spare parts
582628303104	TAPER ROLLER BEARING (PLANET CARRIER)	TATA spare parts
582628303105	NEEDLE ROLLER BEARING (PLANET GEAR)	TATA spare parts
582628303108	DEEP GROOVE BALL BRG COVER FRONT HSG O/P	TATA spare parts
582628303701	REAR COVER (OUTPUT SHAFT)	TATA spare parts
582628304301	INTERNAL SNAP RING (ANNULUS GEAR ASSEMBL	TATA spare parts
582628304302	INTERNAL CIRCLIP (3.95 THK.) (COVER FRON	TATA spare parts
582628304303	INTERNAL CIRCLIP (4.00 THK.) (COVER FRON	TATA spare parts
582628304304	INTERNAL CIRCLIP (4.05 THK.) (COVER FRON	TATA spare parts
582628304305	INTERNAL CIRCLIP (4.10 THK.) (COVER FRON	TATA spare parts
582628304306	INTERNAL CIRCLIP (4.15 THK.) (COVER FRON	TATA spare parts
582628304307	SNAP RING (PLANET CARRIER)	TATA spare parts
582628304310	INTERNAL CIRCLIP COVER FRT HSG 3.85 THK.	TATA spare parts
582628304311	INTERNAL CIRCLIP COVER FRT HSG 3.9 THK.	TATA spare parts
582628304601	CURVIC COUPLING (OUTPUT SHAFT-FRONT AXLE	TATA spare parts
582628304801	DOWEL PIN (PLANET CARRIER HOUSING)	TATA spare parts
582628305102	COUPLING FLANGE (OUTPUT SHAFT-FRONT AXLE	TATA spare parts
582628305402	PLANET GEAR	TATA spare parts
582628305403	ANNULUS GEAR (DIFFERENTIAL)	TATA spare parts
582628307801	OIL SEAL OUTER (FRONT OUTPUT SHAFT)	TATA spare parts
582628307802	OIL SEAL INNER (FRONT OUTPUT SHAFT)	TATA spare parts
582628307901	OUTPUT SHAFT (FRONT AXLE)	TATA spare parts
582628307902	OUTPUT SHAFT (REAR AXLE)	TATA spare parts
582628307903	PLANET SHAFT	TATA spare parts
582628307904	OUTPUT SHAFT FRONT (W/O DIFFERENTIAL)	TATA spare parts
582628307905	FD GEAR SHAFT (W/O DIFFERENTIAL)	TATA spare parts
582628308201	BAFFLE (FINAL DRIVE GEAR)	TATA spare parts
582628308301	SELECTION SHIM (0.60 THK.) (FRONT OUTPUT	TATA spare parts
582628308302	SELECTION SHIM (0.65 THK.) (FRONT OUTPUT	TATA spare parts
582628308303	SELECTION SHIM (0.70 THK.) (FRONT OUTPUT	TATA spare parts
582628308304	SELECTION SHIM (0.75 THK.) (FRONT OUTPUT	TATA spare parts
582628308305	SELECTION SHIM (0.80 THK.) (FRONT OUTPUT	TATA spare parts

582628308306	SELECTION SHIM (0.85 THK.) (FRONT OUTPUT	TATA spare parts
582628308307	SELECTION SHIM (FRONT OUTPUT)	TATA spare parts
582628308308	SELECTION SHIM (0.95 THK.) (FRONT OUTPUT	TATA spare parts
582628308309	SELECTION SHIM (FRONT OUTPUT)	TATA spare parts
582628308310	SELECTION SHIM (1.05 THK.) (FRONT OUTPUT	TATA spare parts
582628308311	SELECTION SHIM (1.10 THK.) (FRONT OUTPUT	TATA spare parts
582628308312	SELECTION SHIM (1.15 THK.) (FRONT OUTPUT	TATA spare parts
582628308701	COMPRESSION SPRING (PLANET CARRIER HOUSI	TATA spare parts
582628309201	THRUST WASHER (PLANET GEAR)	TATA spare parts
582628350101	ASSEMBLY INTERMEDIATE SHAFT	TATA spare parts
582628350102	ASSEMBLY OIL CATCHER (INTERMEDIATE SHAFT	TATA spare parts
582628353101	CYLINDRICAL ROLLER BEARING (INTERMEDIATE	TATA spare parts
582628353401	SPEEDO WHEEL (INTERMEDIATE SHAFT)	TATA spare parts
582628353701	SPEEDO HOUSING	TATA spare parts
582628353703	BEARING COVER (INTERMEDIATE SHAFT)	TATA spare parts
582628353704	PUMP HOUSING (INTERMEDIATE SHAFT)	TATA spare parts
582628354601	COUPLER HYDRAULIC PUMP	TATA spare parts
582628356501	HEX NUT (INTERMEDIATE HEX NUT INTERMEDIA	TATA spare parts
582628357101	COVER SPEEDO HOUSING	TATA spare parts
582628357102	COVER HYDRAULIC PUMP HOUSING	TATA spare parts
582628357901	INTERMEDIATE SHAFT	TATA spare parts
582628358301	SELECTION SHIM (1.5 THK.) (INTERMEDIATE	TATA spare parts
582628358302	SELECTION SHIM (INTERMEDIATE SHAFT)	TATA spare parts
582628358303	SELECTION SHIM (1.7 THK.) (INTERMEDIATE	TATA spare parts
582628358304	SELECTION SHIM (1.8 THK.) (INTERMEDIATE	TATA spare parts
582628358305	SELECTION SHIM (1.9 THK.) (INTERMEDIATE	TATA spare parts
582628358306	SELECTION SHIM (INTERMEDIATE SHAFT)	TATA spare parts
582628400101	ASSEMBLY SHIFTER FORK (HIGH-LOW GEAR)	TATA spare parts
582628400103	ASSEMBLY AIR CYLINDER (INPUT SHIFTING)	TATA spare parts
582628400108	ASSEMBLY AIR CYLINDER COVER	TATA spare parts
582628400109	ASSEMBLY DETENT HOUSING (INPUT SHIFTER S	TATA spare parts
582628401601	INDICATOR SWITCH	TATA spare parts
582628403201	STROKE ADJUSTING BOLT (AIR CYLINDER)	TATA spare parts
582628403401	BUSH REST BLOCK (COVER FRONT HOUSING)	TATA spare parts
582628403402	BUSH - PNEUMATIC CYLINDER (COVER FRONT H	TATA spare parts
582628403701	DETENT HOUSING (INPUT SHIFTER SHAFT)	TATA spare parts
582628403702	CYLINDER COVER (INPUT SHIFTING)	TATA spare parts
582628403703	COVER OUTPUT SHIFTER SHAFT	TATA spare parts
582628403801	AIR CYLINDER	TATA spare parts
582628404301	EXTERNAL CIRCLIP (SHIFTER SHAFT)	TATA spare parts
582628405101	SHIFTER FORK (RANGE)	TATA spare parts
582628405102	SHIFTER FORK (OUTPUT SHIFTING)	TATA spare parts
582628406501	HEX CAP NUT (OUTPUT SHIFTER SHAFT)	TATA spare parts
582628406602	PISTON 2 (NEUTRAL SHIFTING)	TATA spare parts
582628406603	PISTON 3 (LOW RANGE SHIFTING)	TATA spare parts
582628406604	PISTON-SPRING RESTING (OUTPUT SHIFTING)	TATA spare parts
582628406701	PLUNGER (DETENT HOUSING)	TATA spare parts

582628406702	PLUNGER (COVER AIR CYLINDER)	TATA spare parts
582628407101	CYLINDER COVER (OUTPUT SHIFTING SYSTEM)	TATA spare parts
582628407701	O-RING (SHIFTER SHAFT)	TATA spare parts
582628407702	O-RING - PISTON (NEUTRAL SHIFTING)	TATA spare parts
582628407901	SHIFTER SHAFT (INPUT SHIFTING)	TATA spare parts
582628407902	SHIFTER SHAFT (OUTPUT SHIFTING)	TATA spare parts
582628408001	SCREW (SHIFTER FORK)	TATA spare parts
582628408002	DETENT SCREW (DETENT HOUSING)	TATA spare parts
582628408701	HELICAL COMPRESSION SPRING (OUTPUT SHIFT)	TATA spare parts
582628408702	COMPRESSION SPRING (DETENT HOUSING)	TATA spare parts
582628409901	SHIFTER FORK PAD	TATA spare parts
582628900101	ASSEMBLY OIL SUCTION PIPE	TATA spare parts
582628900102	ASSEMBLY P.T.O. (IPH2233200)	TATA spare parts
582628900108	HOSE PIPE TC TO OC	TATA spare parts
582628900109	HOSE PIPE OC TO TC	TATA spare parts
582628906801	NON RETURN VALVE PRESSURE LINE	TATA spare parts
582628906802	NON RETURN VALVE RETURN LINE	TATA spare parts
582726106702	DOWEL PIN BS6-PH2	TATA spare parts
582726107201	FILLER PLUG BS6-PH2	TATA spare parts
582726208603	SPACER BS6-PH2	TATA spare parts
582726209201	WASHER BS6-PH2	TATA spare parts
582726209202	BRASS WASHER BS6-PH2	TATA spare parts
582726407101	PTO COVER BS6-PH2	TATA spare parts
582726903401	VALVE BODY BS6-PH2	TATA spare parts
582726906301	STRAINER ASSY BS6-PH2	TATA spare parts
582726908701	SPRING BS6	TATA spare parts
582835000109	AXLE ASSY WITH BRAKE FWD	TATA spare parts
582835000111	AXLE ASSY WITH BRAKE RWD	TATA spare parts
582835000114	AXLE ASSY WITH BRAKE FWD	TATA spare parts
582835000115	AXLE ASSY WITH BRAKE RWD	TATA spare parts
582835100111	AXLE BEAM ASSY WITH RING & STUD FWD	TATA spare parts
582835100113	AXLE BEAM ASSY WITH RING & STUD RWD	TATA spare parts
582835107901	OUTPUT SHAFT (FRONT TANDEM)	TATA spare parts
582835110104	ASSY.CARRIER HSG.WITH PLUMMER BLOCK	TATA spare parts
582835110106	DRIVE HEAD ASSY WITH CARRIER ASSY	TATA spare parts
582835300102	DIFF.HOUSING ASSY.CAST (9X14 GEARS)	TATA spare parts
582835300103	ASSY CW & PINION 39/7	TATA spare parts
582835300110	CROWN WHEEL & PINION ASSY	TATA spare parts
582835303702	DROP GEAR HOUSING (FRONT TANDEM)	TATA spare parts
582835305403	HELICAL GEAR PINION AXIS (34/34)	TATA spare parts
582835305404	HELICAL GEAR INPUT AXIS (34/34)	TATA spare parts
582835306101	LOCKING PLATE	TATA spare parts
582835307901	INPUT SHAFT (FRONT TANDEM)	TATA spare parts
582835707901	REAR AXLE SHAFT-989 LONG	TATA spare parts
582835707902	REAR AXLE SHAFT-1129 LONG	TATA spare parts
582835905101	FORK DIFFERENTIAL LOCK	TATA spare parts
582835906501	SPACER	TATA spare parts

582835906701	PISTON ROD (INTERAXLE DIFFLOCK)	TATA spare parts
582935000113	AXLE ASSY WITH BRAKE BS6	TATA spare parts
582935000120	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
582935000124	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
582935100123	AXLE BEAM ASSY BS6	TATA spare parts
582935100124	REAR AXLE BEAM ASSY WITH PRESSURE RING &	TATA spare parts
582935100132	REAR AXLE BEAM ASSY BS6	TATA spare parts
582935100134	AXLE BEAM ASSY WITH RING	TATA spare parts
582935100138	REAR AXLE BEAM ASSY BS6	TATA spare parts
582935100158	AXLE BEAM ASSY BS6-PH2	TATA spare parts
582935100166	AXLE BEAM ASSY BS6-PH2	TATA spare parts
582935108601	PRESSURE RING BS6	TATA spare parts
582935110101	CARRIER HOUSING ASSY WITH PLUMMER BLOCK	TATA spare parts
582935110106	CARRIER & PINION HOUSING ASSY BS6	TATA spare parts
582935110107	CARRIER HOUSING ASSY BS6	TATA spare parts
582935110108	CARRIER & PINION HOUSING ASSY BS6	TATA spare parts
582935110111	CARRIER & PINION HOUSING ASSY BS6-PH2	TATA spare parts
582935300103	DIFFERENTIAL HOUSING ASSY BS6	TATA spare parts
582935300106	ASSY ADJUSTING PIN BS6	TATA spare parts
582935300110	CROWN WHEEL & PINION ASSY BS6-PH2	TATA spare parts
582935300119	CROWN WHEEL & PINION ASSY BS6	TATA spare parts
582935300133	CROWN WHEEL AND PINION ASSY BS6	TATA spare parts
582935300141	CROWN WHEEL & PINION ASSY BS6-PH2	TATA spare parts
582935303101	TAPER ROLLER BEARING BS6-PH2	TATA spare parts
582935303102	TAPER ROLLER BRG(68.262X152.4X47.625) BS	TATA spare parts
582935303110	TAPER ROLLER BEARING BS6	TATA spare parts
582935303111	TAPER ROLLER BEARING BS6	TATA spare parts
582935303112	TAPER ROLLER BEARING BS6 PH2	TATA spare parts
582935303113	CYLINDRICAL ROLLER BEARING BS6	TATA spare parts
582935303201	HEX FLANGE BOLT M18X1.5X50 BS6	TATA spare parts
582935303701	PINION HOUSING BS6	TATA spare parts
582935305103	DIFFERENTIAL SPIDER BS6	TATA spare parts
582935305407	GEAR REAR AXLE SHAFT BS6	TATA spare parts
582935305408	PINION DIFFERENTIAL BS6	TATA spare parts
582935306501	THREADED RING (DIFFERENTIAL) BS6	TATA spare parts
582935307702	OIL SEAL BS6	TATA spare parts
582935308202	LOCKING PLATE BS6	TATA spare parts
582935308301	SHIM 1.10 THK.PINION DEPTH SETTING BS6	TATA spare parts
582935308302	SHIM 0.10 THK.PINION DEPTH SETTING BS6	TATA spare parts
582935308303	SHIM 0.15 THK.PINION DEPTH SETTING BS6	TATA spare parts
582935308304	SHIM 0.20 THK.PINION DEPTH SETTING BS6	TATA spare parts
582935308305	SHIM 0.25 THK.PINION DEPTH SETTING BS6	TATA spare parts
582935308306	SHIM 0.50 THK.PINION DEPTH SETTING BS6	TATA spare parts
582935308307	SHIM 0.80 THK.PINION DEPTH SETTING BS6	TATA spare parts
582935308308	SHIM 1.40 THK.PINION DEPTH SETTING BS6	TATA spare parts
582935308309	SHIM 1.70 THK.PINION DEPTH SETTING BS6	TATA spare parts
582935308310	SHIM 0.25 THK (PINION BRG PRELOADING) BS	TATA spare parts

582935308311	SHIM 0.20 THK (PINION BRG PRELOADING) BS	TATA spare parts
582935308312	SHIM 0.15 THK (PINION BRG PRELOADING) BS	TATA spare parts
582935308313	SHIM 0.10 THK (PINION BRG PRELOADING) BS	TATA spare parts
582935308314	SHIM 1.70 THK (PINION BRG PRELOADING) BS	TATA spare parts
582935308315	SHIM 1.40 THK (PINION BRG PRELOADING) BS	TATA spare parts
582935308601	PINION SPACER BS6	TATA spare parts
582935309202	SPHERICAL WASHER BS6	TATA spare parts
582935309203	THRUST WASHER BS6	TATA spare parts
582935309204	THRUST WASHER BS6	TATA spare parts
582935309205	THRUST WASHER BS6	TATA spare parts
582935309206	THRUST WASHER BS6	TATA spare parts
582935309207	THRUST WASHER BS6	TATA spare parts
582935309208	THRUST WASHER BS6	TATA spare parts
582935309901	LOCKING WIRE (OUTER RACE) BS6	TATA spare parts
582935603104	TAPER ROLLER BEARING BS6	TATA spare parts
582935605501	REAR HUB BS6	TATA spare parts
582935606501	HUB LOCK NUT BS6	TATA spare parts
582935608201	OIL CATCHER BS6	TATA spare parts
582935608301	SHIM 1.40 THK(BET HUB INNER OUTER BRG) B	TATA spare parts
582935608302	SHIM 0.10 THK(BET HUB INNER OUTER BRG) B	TATA spare parts
582935608303	SHIM 0.15 THK(BET HUB INNER OUTER BRG) B	TATA spare parts
582935608304	SHIM 0.20 THK(BET HUB INNER OUTER BRG) B	TATA spare parts
582935608305	SHIM 0.25 THK(BET HUB INNER OUTER BRG) B	TATA spare parts
582935608306	SHIM 1.70 THK(BET HUB INNER OUTER BRG) B	TATA spare parts
582935608307	SHIM 2.00 THK(BET HUB INNER OUTER BRG) B	TATA spare parts
582935608308	SHIM 2.30 THK(BET HUB INNER OUTER BRG) B	TATA spare parts
582935608601	SPACER TUBE BET HUB INNER & OUTER BRG BS	TATA spare parts
582935608602	TONGUE SPACER WITHOUT HOLES BS6	TATA spare parts
582935608603	TONGUE SPACER WITH HOLES BS6	TATA spare parts
582935707903	REAR AXLE SHAFT BS6	TATA spare parts
582935707904	REAR AXLE SHAFT BS6	TATA spare parts
582935707909	REAR AXLE SHAFT BS6 PH2	TATA spare parts
582935707910	REAR AXLE SHAFT BS6	TATA spare parts
582935900101	ASSY PISTON ROD BS6	TATA spare parts
582935903701	SHIFT CYLINDER HOUSING BS6	TATA spare parts
582935905101	SHIFTER FORK BS6	TATA spare parts
582935905402	SHIFTER SLEEVE BS6	TATA spare parts
582935908701	COMPRESSION SPRING BS6	TATA spare parts
5829H9W0135009	LIVE RR AXLE ASSY WITH BRAKES-MFG BS6-PH	TATA spare parts
5829H9W0135010	LIVE REAR AXLE ASSY WITH BRAKES BS6-PH2	TATA spare parts
5829H9W0135012	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
583026000108	GEAR BOX ASSY WITH PUMP & PTO	TATA spare parts
583026000111	GEAR BOX ASSY	TATA spare parts
583026000112	GEAR BOX ASSY	TATA spare parts
583026000114	ASSY. GEAR BOX BS4	TATA spare parts
583026000116	GEAR BOX ASSY	TATA spare parts
583026000119	GEAR BOX ASSY WITH PTO	TATA spare parts

583026000121	GEAR BOX ASSY	TATA spare parts
583026000128	GEAR BOX ASSY WITH PTO	TATA spare parts
583026000131	GEAR BOX BS6	TATA spare parts
583026000132	GEAR BOX ASSY BS6	TATA spare parts
583026000133	GEAR BOX ASSY WITH PTO BS6	TATA spare parts
583026000134	GEAR BOX ASSY BS6	TATA spare parts
583026000137	GEARBOXASSY BS6	TATA spare parts
583026103701	HOUSING REAR HALF WITH PTO WITH OIL PUMP	TATA spare parts
583026103707	HOUSING HALF FRONT	TATA spare parts
583026105301	GASKET (REAR & FRONT HALF)	TATA spare parts
583026106301	OIL SPRAY TUBE	TATA spare parts
583026200107	ASSY. SYNCHRO CONE (1/2/3 SPEED) BS3/4	TATA spare parts
583026200110	SYNCHRO CONE ASSY 1ST/2ND/3RD SPEED	TATA spare parts
583026203401	SENSING WHEEL CONTACTLESS SPEEDO	TATA spare parts
583026203402	BUSH REVERSE GEAR	TATA spare parts
583026203801	COVER REAR	TATA spare parts
583026204301	SNAP RING 4TH SPEED	TATA spare parts
583026204302	SNAP RING 4TH SPEED	TATA spare parts
583026204303	SNAP RING 4TH SPEED	TATA spare parts
583026204304	SNAP RING 4TH SPEED	TATA spare parts
583026204305	CIRCLIP EXTERNAL 5TH/6TH SPEED	TATA spare parts
583026204306	CIRCLIP EXTERNAL 5TH/6TH SPEED	TATA spare parts
583026204307	CIRCLIP EXTERNAL 5TH/6TH SPEED	TATA spare parts
583026204308	SNAP RING 2.0 THK.(COUNTER SHAFT PTO)	TATA spare parts
583026204309	SNAP RING 2.1 THK.(COUNTER SHAFT PTO)	TATA spare parts
583026204310	CIRCLIP EXTERNAL 3.7 MM THK(ENGAGING GEA	TATA spare parts
583026204311	CIRCLIP EXTERNAL 3.8 MM THK(ENGAGING GEA	TATA spare parts
583026204312	CIRCLIP EXTERNAL 3.9 MM THK(ENGAGING GEA	TATA spare parts
583026204313	CIRCLIP EXTERNAL 4.0 MM THK(ENGAGING GEA	TATA spare parts
583026204314	CIRCLIP EXTERNAL 4.1 MM THK(ENGAGING GEA	TATA spare parts
583026204601	SYNCHRO RING 1ST/2ND/3RD SPEED BS3/4	TATA spare parts
583026204602	ENGAGING GEAR (1/2/3/4 SPEED)	TATA spare parts
583026204603	ENGAGING GEAR (5TH/6TH SPEED)	TATA spare parts
583026204605	SYNCHRO RING BS3/4/6	TATA spare parts
583026204612	MAIN SHAFT ENGAGING GEAR REVERSE	TATA spare parts
583026204614	SYNCHRO RING BS6	TATA spare parts
583026205101	COUPLING FLANGE (150 DIA SERRATED)	TATA spare parts
583026205301	GASKET (REAR COVER MAIN SHAFT)	TATA spare parts
583026205401	1ST SPEED GEAR MAIN SHAFT BS3/4/6	TATA spare parts
583026205402	2ND SPEED GEAR (MAIN SHAFT)	TATA spare parts
583026205403	3RD SPEED GEAR (MAIN SHAFT)	TATA spare parts
583026205404	4TH SPEED GEAR (MAIN SHAFT)	TATA spare parts
583026205405	5TH SPEED GEAR (MAIN SHAFT)	TATA spare parts
583026205406	REVERSE GEAR (MAIN SHAFT) BS2/4	TATA spare parts
583026205409	GEAR 4TH SPEED MAIN SHAFT	TATA spare parts
583026205410	GEAR 5TH SPEED MAIN SHAFT	TATA spare parts
583026205413	REVERSE GEAR	TATA spare parts



583026206501	LOCK NUT COUPLING FLANGE	TATA spare parts
583026207901	MAIN SHAFT G950 BS3/4	TATA spare parts
583026207902	MAIN SHAFT	TATA spare parts
583026208601	SPACER 4TH GEAR MAIN SHAFT	TATA spare parts
583026208602	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208603	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208604	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208605	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208606	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208607	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208608	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208609	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208610	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208611	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208612	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208613	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208614	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208615	SPACER REVERSE GEAR MAIN SHAFT	TATA spare parts
583026208616	SPACER REVERSE GEAR MAIN SHAFT 6.7 MM TH	TATA spare parts
583026208617	SPACER REVERSE GEAR MAIN SHAFT 6.8 MM TH	TATA spare parts
583026208618	SPACER REVERSE GEAR MAIN SHAFT 6.9 MM TH	TATA spare parts
583026208619	SPACER REVERSE GEAR MAIN SHAFT 7.0 MM TH	TATA spare parts
583026208620	SPACER REVERSE GEAR MAIN SHAFT 7.1 MM TH	TATA spare parts
583026208621	SPACER REVERSE GEAR MAIN SHAFT 7.2 MM TH	TATA spare parts
583026208622	SPACER REVERSE GEAR MAIN SHAFT 7.3 MM TH	TATA spare parts
583026208623	SPACER REVERSE GEAR MAIN SHAFT 7.4 MM TH	TATA spare parts
583026253101	CYLINDRICAL ROLLER BEARING (55X120X29)	TATA spare parts
583026253102	BALL BEARING FOUR POINT BS2/4	TATA spare parts
583026253103	PILOT BEARING (34X54X42)	TATA spare parts
583026253104	PILOT BEARING BS6	TATA spare parts
583026253106	FOUR POINT BALL BEARING BS6	TATA spare parts
583026253107	CYL ROLLER BEARING	TATA spare parts
583026253108	FOUR POINT BALL BEARING BS6	TATA spare parts
583026253701	COVER FRONT BS3/4	TATA spare parts
583026254601	SYNCHRO RING DRIVE SHAFT	TATA spare parts
583026255301	GASKET (FRONT COVER)	TATA spare parts
583026256501	HEX NUT (DRIVE SHAFT)	TATA spare parts
583026257901	ASSY. DRIVE SHAFT BS3/4/6	TATA spare parts
583026258601	SPACER (DRIVE SHAFT)	TATA spare parts
583026303103	TAPER ROLLER BRG (45X95X36)	TATA spare parts
583026303104	TAPER ROLLER BRG (55X120X31.5)	TATA spare parts
583026303110	TAPER ROLLER BEARING COUNTER SHAFT BS6 P	TATA spare parts
583026303111	TAPER ROLLER BEARING COUNTER SHAFT BS6 P	TATA spare parts
583026303801	COVER PLATE REAR COVER	TATA spare parts
583026305401	3RD SPEED GEAR (COUNTER SHAFT)	TATA spare parts
583026305402	4TH SPEED GEAR (COUNTER SHAFT)	TATA spare parts
583026305403	5TH SPEED GEAR(COUNTER SHAFT)	TATA spare parts

583026305404	CONSTANT MESH GEAR (46T)	TATA spare parts
583026305408	GEAR 4TH SPEED COUNTER SHAFT	TATA spare parts
583026305409	GEAR 5TH SPEED COUNTER SHAFT	TATA spare parts
583026307901	ASSY. COUNTER SHAFT BS3/4/6	TATA spare parts
583026308301	SHIM 0.05 THK.	TATA spare parts
583026308302	SHIM 0.125 THK.	TATA spare parts
583026308303	SHIM 0.25 THK.	TATA spare parts
583026308304	SHIM 0.50 THK.	TATA spare parts
583026355401	REVERSE IDLER GEAR	TATA spare parts
583026357701	O-RING 28 X 3.55	TATA spare parts
583026357901	REVERSE IDLER SHAFT	TATA spare parts
583026400102	PTO WITH PUMP DUAL AXIS	TATA spare parts
583026400103	ORING G950	TATA spare parts
583026400104	PTO WITH PUMP DUAL AXIS BS4/6	TATA spare parts
583026400105	PTO ASSY	TATA spare parts
583026403701	ADAPTER HOUSING (PTO)	TATA spare parts
583026404601	CLUTCH PTO INTERPUMP	TATA spare parts
583026510107	SHIFTER SHAFT & FORK ASSY 1ST/2ND SPEED	TATA spare parts
583026510108	SHIFTER SHAFT & FORK ASSY 3RD/4TH SPEED	TATA spare parts
583026510109	SHIFTER FORK ASSY	TATA spare parts
583026513701	SHIFTER FORK;1ST/2ND/3RD/4TH SPEED	TATA spare parts
583026513702	SHIFTER FORK;5TH/6TH SPEED	TATA spare parts
583026513703	SHIFTER FORK REVERSE SPEED	TATA spare parts
583026513704	SWING FORK OVERDRIVE BS6-PH2	TATA spare parts
583026515101	SHIFTER DOG (1ST/2ND/3RD/4TH)	TATA spare parts
583026515102	SHIFTING DOG REVERSE/5TH/6TH SPEED	TATA spare parts
583026515103	SWING DOG BS6-PH2	TATA spare parts
583026515104	SHIFTER DOG 1ST/2ND/3RD/4TH SPEED BS6 PH	TATA spare parts
583026515105	SHIFTING DOG REVERSE/5TH/6TH SPEED BS6 P	TATA spare parts
583026517901	SHIFTER SHAFT (1ST/2ND SPEED)	TATA spare parts
583026517902	SHIFTER SHAFT (3ED/4TH SPEED)	TATA spare parts
583026517903	SHIFTER SHAFT (5TH/6TH SPEED)	TATA spare parts
583026517904	SHIFTER SHAFT (REVERSE)	TATA spare parts
583026517905	SHIFTER SHAFT BS6-PH2	TATA spare parts
583026700101	SELECTOR SHAFT & SELECTION LEVER ASSY	TATA spare parts
583026710101	COVER ASSY TOP	TATA spare parts
583026710102	SELECTOR SHIFTER SHAFT ASSY	TATA spare parts
583026710103	COVER ASSY TOP	TATA spare parts
583026710106	COVER ASSY TOP	TATA spare parts
583026710116	COVER ASSY TOP BS6-PH2	TATA spare parts
583026713701	SHIFTING FINGER BS4/6	TATA spare parts
583026718701	SPRING CENTRAL DETENT OUTER	TATA spare parts
583026718702	SPRING CENTRAL DETENT INNER	TATA spare parts
583026820101	ANCHOR BRACKET ASSY SELECTION CABLE	TATA spare parts
583026900102	OIL PUMP SUB ASSY	TATA spare parts
583026900103	HOSE ASSY	TATA spare parts
583026903801	OIL PUMP HOUSING(FOR OIL SPRAY AND REAR	TATA spare parts

583026905301	GASKET (HSG. TO OIL PUMP)	TATA spare parts
583235307702	OIL SEAL	TATA spare parts
583635000105	REAR AXLE ASSY WITH BRAKE	TATA spare parts
583635000107	REAR AXLE ASSY WITH BRAKE ABS	TATA spare parts
583635000113	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
583635000117	REAR AXLE ASSY BS6	TATA spare parts
583635000125	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
583635000127	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
583635000128	REAR AXLE ASSY WITH HUB ABS BS6	TATA spare parts
583635000133	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
583635000134	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
583635000141	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
583635000160	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
583635000165	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
583635000166	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
583635000173	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
583635000179	REAR AXLE ASSY WITH BRAKE ABS BS6	TATA spare parts
583635000185	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
583635000187	REAR AXLE ASSY WITH BRAKE BS6	TATA spare parts
583635100103	REAR AXLE BEAM ASSY BS6	TATA spare parts
583635100105	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
583635100106	AXLE BEAM ASSY WITH RING & STUD	TATA spare parts
583635100109	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
583635100113	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
583635100114	AXLE BEAM ASSY BS6	TATA spare parts
583635100115	AXLE BEAM ASSY WITH RING & STUD BS6	TATA spare parts
583635100116	REAR AXLE BEAM ASSY BS6	TATA spare parts
583635100117	AXLE BEAM ASSY WITH RING - STUD BS6	TATA spare parts
583635100118	AXLE BEAM ASSY BS6	TATA spare parts
583635100123	AXLE BEAM ASSY WITH RING AND STUD BS6	TATA spare parts
583635100124	REAR AXLE BEAM ASSY BS6-PH2	TATA spare parts
583635110101	CARRIER ASSY BS6	TATA spare parts
583635110102	CARRIER AND PINION HOUSING ASSY BS6	TATA spare parts
583635110104	CARRIER & PINION HOUSING ASSY	TATA spare parts
583635110106	CARRIER & PINION HOUSING ASSY BS6	TATA spare parts
583635110111	CARRIER & PINION HOUSING ASSY BS6	TATA spare parts
583635300101	DIFFERENTIAL HOUSING ASSY	TATA spare parts
583635300104	CROWN WHEEL & PINION ASSY BS6	TATA spare parts
583635300106	DIFFERENTIAL GEAR ASSY	TATA spare parts
583635300108	DIFFERENTIAL HOUSING ASSY BS6	TATA spare parts
583635300110	CROWN WHEEL - PINION ASSY BS6	TATA spare parts
583635300112	DIFFERENTIAL ASSY	TATA spare parts
583635300114	CROWN WHEEL & PINION ASSY	TATA spare parts
583635300122	DIFFERENTIAL ASSY BS6-PH2	TATA spare parts
583635300124	CROWN WHEEL - PINION ASSY BS6-PH2	TATA spare parts
583635303701	PINION HOUSING BS6	TATA spare parts
583635305103	DIFFERENTIAL SPIDER BS6	TATA spare parts

583635305403	DIFFERENTIAL BEVEL GEAR BS6	TATA spare parts
583635305404	DIFFERENTIAL BEVEL PINION BS6	TATA spare parts
583635308001	ADJUSTING PIN BS6	TATA spare parts
583635308301	SHIM PINION DEPTH SETTING	TATA spare parts
583635308302	SHIM PINION DEPTH SETTING	TATA spare parts
583635308303	SHIM PINION DEPTH SETTING	TATA spare parts
583635308304	SHIM PINION DEPTH SETTING	TATA spare parts
583635308305	SHIM PINION DEPTH SETTING	TATA spare parts
583635308306	SHIM PINION DEPTH SETTING	TATA spare parts
583635308307	SHIM PINION DEPTH SETTING BS6	TATA spare parts
583635308308	SHIM PINION DEPTH SETTING	TATA spare parts
583635308309	SHIM PINION DEPTH SETTING	TATA spare parts
583635309201	SPHERICAL WASHER BS6	TATA spare parts
583635309202	THRUST WASHER BS6	TATA spare parts
583635309203	THRUST WASHER BS6	TATA spare parts
583635309204	THRUST WASHER BS6	TATA spare parts
583635309205	THRUST WASHER BS6	TATA spare parts
583635309206	THRUST WASHER BS6	TATA spare parts
583635309207	THRUST WASHER BS6	TATA spare parts
583635600102	HUB ASSY BS6	TATA spare parts
583635606501	LOCK NUT	TATA spare parts
583635608601	TONGUE SPACER	TATA spare parts
583635608602	LOCKING PLATE	TATA spare parts
583635707901	REAR AXLE SHAFT	TATA spare parts
583635707902	REAR AXLE SHAFT BS6	TATA spare parts
5836H9W0135011	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
5836H9W0135016	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
5836H9W0135017	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
5836H9W0135019	LIVE REAR AXLE ASSY WITH BRAKES-MFG BS6-	TATA spare parts
5838300283	SCREW PLUG	TATA spare parts
5838300286	PLUG	TATA spare parts
5838300301	GROOVED STUD	TATA spare parts
5838300726	SEALING RING	TATA spare parts
5838300737	TYPE PLATE	TATA spare parts
5840300043	SHIM	TATA spare parts
5840300044	SHIM	TATA spare parts
5840300045	SHIM	TATA spare parts
5840301116	SCREW	TATA spare parts
5840302193	NEEDLE SLEEVE	TATA spare parts
5840302379	END COVER	TATA spare parts
5840302517	END COVER	TATA spare parts
5840302520	FLANGE	TATA spare parts
5840302754	CY.ROLL.BEARING	TATA spare parts
5840303040	SCREW PLUG	TATA spare parts
5840303316	REDUCTION PIECE	TATA spare parts
5840303318	SEALING RING	TATA spare parts
5840303319	GEAR SHIFT FORK	TATA spare parts

5840303444	GEAR SHIFT FORK	TATA spare parts
5840303666	PLUG	TATA spare parts
5840333067	SEALING RING	TATA spare parts
5840333084	BEARING	TATA spare parts
5840333085	BALL BEARING	TATA spare parts
5840333089	TA.ROLL.BEARING	TATA spare parts
5840333095	CY.ROLL.BEARING	TATA spare parts
5840333096	CY.ROLL.BEARING	TATA spare parts
5840333100	CY.ROLL.BEARING	TATA spare parts
5840333104	TA.ROLL.BEARING	TATA spare parts
5840333121	SLOTTED NUT	TATA spare parts
5840333128	PLUG	TATA spare parts
5840333130	PLUG	TATA spare parts
5840333132	PLUG	TATA spare parts
5840333135	SEALING RING	TATA spare parts
5840333137	SEALING RING	TATA spare parts
5840333140	SCREW	TATA spare parts
5840333146	SCREW	TATA spare parts
5840333148	SCREW	TATA spare parts
5840333149	SCREW	TATA spare parts
5840333188	COUNTERS.SCREW	TATA spare parts
5840333197	HEXAGON NUT	TATA spare parts
5840333198	HEXAGON NUT	TATA spare parts
5840333205	CYLINDRICAL PIN	TATA spare parts
5840333207	PIN	TATA spare parts
5840333227	SHAFT SEAL	TATA spare parts
5840333233	SHAFT SEAL	TATA spare parts
5840333240	SHAFT SEAL	TATA spare parts
5840333244	SHAFT SEAL	TATA spare parts
5840333245	SHAFT SEAL	TATA spare parts
5840333268	SHAFT SEAL	TATA spare parts
5840333288	SEALING PLUG	TATA spare parts
5841200018	POT	TATA spare parts
584126010113	GEAR BOX ASSY BS6-PH2	TATA spare parts
58412610370151	HOUSING FRONT BS6	TATA spare parts
58412610370251	HOUSING INTERMEDIATE BS6	TATA spare parts
58412610370351	GEAR BOX HOUSING REAR BS6	TATA spare parts
584126106701	DOWEL PIN BS6-PH2	TATA spare parts
584126107701	RUBBER BUSH BS6-PH2	TATA spare parts
584126201603	OUTER ROTOR BS6	TATA spare parts
584126201604	INNER ROTOR BS6	TATA spare parts
584126203001	PLANET ROLLER BS6-PH2	TATA spare parts
584126203101	TAPER ROLLER BEARING MAIN SHAFT BS6-PH2	TATA spare parts
584126203102	TAPER ROLLER BEARING BS6-PH2	TATA spare parts
584126203701	CYLINDER BS6-PH2	TATA spare parts
584126204301	CIRCLIP BS6-PH2	TATA spare parts
584126204302	CIRCLIP BS6-PH2	TATA spare parts

584126204303	CIRCLIP BS6-PH2	TATA spare parts
584126204304	CIRCLIP BS6	TATA spare parts
584126204305	CIRCLIP BS6	TATA spare parts
584126204306	CIRCLIP EXTERNAL BS6	TATA spare parts
584126204307	CIRCLIP EXTERNAL BS6	TATA spare parts
584126204308	CIRCLIP EXTERNAL BS6	TATA spare parts
584126204309	CIRCLIP EXTERNAL BS6	TATA spare parts
584126204310	CIRCLIP EXTERNAL BS6	TATA spare parts
584126204311	CIRCLIP EXTERNAL BS6-PH2	TATA spare parts
584126204312	CIRCLIP EXTERNAL BS6	TATA spare parts
584126204313	CIRCLIP EXTERNAL BS6	TATA spare parts
584126204314	CIRCLIP EXTERNAL BS6	TATA spare parts
584126204601	MAIN SHAFT ENGAGING GEAR BS6-PH2	TATA spare parts
58412620460364	ENGAGING GEAR 3RD/4TH SPEED BS6	TATA spare parts
584126204608	SYNCHRO CONE BS6	TATA spare parts
584126204609	SYNCHRO RING BS6	TATA spare parts
584126205101	COUPLING FLANGE BS6-PH2	TATA spare parts
584126205102	CARRIER BS6-PH2	TATA spare parts
58412620540180	GEAR 1ST/5TH SPEED MAIN SHAFT BS6	TATA spare parts
58412620540280	GEAR 2ND/6TH SPEED MAIN SHAFT BS6	TATA spare parts
58412620540380	GEAR 3RD/7TH SPEED MAIN SHAFT BS6	TATA spare parts
58412620540464	CRAWLER GEAR MAIN SHAFT BS6	TATA spare parts
58412620540564	REVERSE GEAR MAIN SHAFT BS6	TATA spare parts
584126205406	SUN GEAR BS6-PH2	TATA spare parts
584126205407	ANNULUS GEAR BS6-PH2	TATA spare parts
584126205408	PLANET GEAR BS6-PH2	TATA spare parts
584126206901	OIL TUBE BS6-PH2	TATA spare parts
584126207101	REACTION PLATE BS6-PH2	TATA spare parts
58412620790180	MAIN SHAFT BS6	TATA spare parts
584126207902	PLANET CARRIER ASSY BS6-PH2	TATA spare parts
584126207903	PLANET PIN GEAR BOX BS6-PH2	TATA spare parts
584126208301	SHIM INPUT SHAFT BS6-PH2	TATA spare parts
584126208302	SHIM INPUT SHAFT BS6-PH2	TATA spare parts
584126208601	SPACER MAIN SHAFT BS6-PH2	TATA spare parts
584126208602	SPACER BS6-PH2	TATA spare parts
584126208603	SPACER BS6-PH2	TATA spare parts
584126208604	SPACER BS6-PH2	TATA spare parts
584126209901	LOCK NUT BS6-PH2	TATA spare parts
584126253101	TAPER ROLLER BEARING DRIVE SHAFT BS6-PH2	TATA spare parts
584126256902	OIL TUBE BS6	TATA spare parts
584126257901	DRIVE SHAFT BS6-PH2	TATA spare parts
58412625790164	DRIVE SHAFT BS6	TATA spare parts
584126304301	CIRCLIP COUNTER SHAFT BS6	TATA spare parts
58412630540180	GEAR 1ST/5TH SPEED COUNTER SHAFT BS6	TATA spare parts
58412630540280	GEAR 2ND/6TH SPEED COUNTER SHAFT BS6	TATA spare parts
58412630540380	GEAR 3RD/7TH SPEED COUNTER SHAFT BS6	TATA spare parts
58412630540480	CONSTANT MESH GEAR COUNTER SHAFT BS6	TATA spare parts

58412630790180	COUNTER SHAFT BS6	TATA spare parts
584126308301	SHIM INPUT SHAFT BS6-PH2	TATA spare parts
584126308302	SHIM INPUT SHAFT BS6-PH2	TATA spare parts
584126308303	SHIM INPUT SHAFT BS6-PH2	TATA spare parts
584126308304	SHIM INPUT SHAFT BS6-PH2	TATA spare parts
584126308601	SPACER BS6-PH2	TATA spare parts
58412635540180	REVERSE IDLER GEAR BS6	TATA spare parts
584126356101	THRUST WASHER BS6	TATA spare parts
584126357101	LOCK PLATE BS6-PH2	TATA spare parts
584126357901	REVERSE IDLER SHAFT BS6-PH2	TATA spare parts
584126403101	BALL BEARING BS6-PH2	TATA spare parts
584126403702	ADAPTER HOUSING BS6-PH2	TATA spare parts
584126407901	QUILL SHAFT PTO BS6-PH2	TATA spare parts
584126510105	SHIFTER SHAFT & FORK ASSY 1ST/2ND SPEED	TATA spare parts
584126510106	SHAFT & FORK ASSY 3RD/4TH SPEED BS6-PH2	TATA spare parts
584126515101	DOG 1ST/2ND SPEED BS6-PH2	TATA spare parts
584126515102	SHIFTER DOG BS6-PH2	TATA spare parts
584126515105	SHIFTER FORK REVERSE/CRAWLER BS6-PH2	TATA spare parts
584126515110	SWING FORK BS6-PH2	TATA spare parts
584126516701	SPIRAL PIN BS6-PH2	TATA spare parts
584126516702	THREADED PIN BS6-PH2	TATA spare parts
584126517903	SHIFTER SHAFT REV/CRAWLER SPEED BS6-PH2	TATA spare parts
584126517904	SHIFTER SHAFT BS6-PH2	TATA spare parts
584126517905	INTERLOCK SHAFT BS6-PH2	TATA spare parts
584126703101	DRAWN CUP NEEDLE ROLLER BEARING BS6-PH2	TATA spare parts
584126710113	HOUSING ASSY TOP COVER BS6-PH2	TATA spare parts
584126710133	HOUSING ASSY TOP COVER BS6	TATA spare parts
584126710142	BRACKET ASSY LINK ROD MTG BS6-PH2	TATA spare parts
584126710146	PIPE ASSY BS6-PH2	TATA spare parts
584126710147	PIPE ASSY BS6-PH2	TATA spare parts
584126710148	PNEUMATIC VALVE BS6	TATA spare parts
584126710151	PIPE ASSY BS6-PH2	TATA spare parts
584126710152	PIPE ASSY BS6-PH2	TATA spare parts
584126715103	SHIFTER FINGER BS6-PH2	TATA spare parts
584126716704	DETENT BS6-PH2	TATA spare parts
584126717904	SHAFT SELECTOR & SHIFTING BS6-PH2	TATA spare parts
584126800105	TURNING TUBE ASSY BS6-PH2	TATA spare parts
584126800111	PNEUMATIC PIPE ASSY BS6-PH2	TATA spare parts
584126800112	PNEUMATIC PIPE ASSY BS6 PH2	TATA spare parts
584126800123	PNEUMATIC PIPE ASSY BS6	TATA spare parts
584126806804	STRAIGHT QUICK FIX CONNECTOR BS6	TATA spare parts
584126900102	TUBE ASSY OIL SPRAY BS6-PH2	TATA spare parts
584126900103	OIL CUP ASSY BS6-PH2	TATA spare parts
584126900105	PIPE ASSY BS6	TATA spare parts
584126900106	PIPE ASSY BS6	TATA spare parts
584126903801	COVER ASSY FRONT HOUSING BS6-PH2	TATA spare parts
584126903802	COVER TUBE BS6-PH2	TATA spare parts

584126903803	COVER PLATE BS6-PH2	TATA spare parts
584126906302	BUSH BS6-PH2	TATA spare parts
584126906303	O-RING BS6-PH2	TATA spare parts
5841300006	SPRING	TATA spare parts
5841300008	SLIDING PAD	TATA spare parts
5841300030	LOCKINGBALL BOLT	TATA spare parts
5841300085	SHIM	TATA spare parts
5841300086	SHIM	TATA spare parts
5841300087	SHIM	TATA spare parts
5841300103	DISTR.HOUSING	TATA spare parts
5841300104	DISTR.HOUSING	TATA spare parts
5841300105	BEARING COVER	TATA spare parts
5841300106	BEARING COVER	TATA spare parts
5841300111	LOCKING DEVICE	TATA spare parts
5841300118	THRUST WASHER	TATA spare parts
5841300119	SLOTTED NUT	TATA spare parts
5841300126	G.SHIFT SLEEVE	TATA spare parts
5841300129	IMPULSSTERN	TATA spare parts
5841300130	FLANGE	TATA spare parts
5841300131	OUTPUT SHAFT	TATA spare parts
5841300132	OUTPUT SHAFT	TATA spare parts
5841300133	INTERNAL RING	TATA spare parts
5841300135	INPUT GEAR	TATA spare parts
5841300136	INPUT GEAR	TATA spare parts
5841300137	COMPR.SPRING	TATA spare parts
5841300140	PIN	TATA spare parts
5841300141	BUSH	TATA spare parts
5841300142	GEAR SHIFT FORK	TATA spare parts
5841300143	PISTON ROD	TATA spare parts
5841300144	PISTON	TATA spare parts
5841300145	COVER	TATA spare parts
5841300146	GEAR SHIFT ROD	TATA spare parts
5841300155	G.SHIFT SLEEVE	TATA spare parts
5841300163	PRESSURE SWITCH	TATA spare parts
5841300164	PRESSURE SWITCH	TATA spare parts
5841300166	ABDECKBLECH	TATA spare parts
5841300172	CENTERING RING	TATA spare parts
5841300174	ABDECKBLECH	TATA spare parts
5841300176	BEARING COVER	TATA spare parts
5841300178	INTERM.PLATE	TATA spare parts
5841300185	G.SHIFT SLEEVE	TATA spare parts
5841300195	SLOTTED NUT	TATA spare parts
5841300197	INPUT GEAR	TATA spare parts
5841300198	INPUT GEAR	TATA spare parts
5841300208	GEAR SHIFT ROD	TATA spare parts
5841300209	SHIFT CYLINDER	TATA spare parts
5841300228	SHAFT SEAL	TATA spare parts



5841300229	BEARING BUSH	TATA spare parts
5841300315	SHIM	TATA spare parts
5841300324	FITTING PIN	TATA spare parts
5841300353	BREATHER	TATA spare parts
5841300373	BUSH	TATA spare parts
5841300374	WASHER	TATA spare parts
5841300375	PISTON	TATA spare parts
5841300432	PIN	TATA spare parts
5841300441	SET SCREW	TATA spare parts
5841300464	SHIM	TATA spare parts
5841300530	COLLAR NUT	TATA spare parts
5841300531	COVER	TATA spare parts
5841300532	SET SCREW	TATA spare parts
5841300533	COVER	TATA spare parts
5841300534	OUTPUT SHAFT	TATA spare parts
5841300536	PLANET GEAR	TATA spare parts
5841300537	RING GEAR	TATA spare parts
5841300538	GEAR SHIFT FORK	TATA spare parts
5841300540	END COVER	TATA spare parts
5841300541	COVER	TATA spare parts
5841300542	SPEEDOMETER OUTPUT WHEEL	TATA spare parts
5841300544	COMPR.SPRING	TATA spare parts
5841300545	THRUST WASHER	TATA spare parts
5841300548	NEEDLE CAGE	TATA spare parts
5841300549	FLANGE	TATA spare parts
5841300552	BEARING HOUSING	TATA spare parts
5841300553	SPEEDO HOUSING	TATA spare parts
5841300556	SPEEDOMETER INPUT WHEEL	TATA spare parts
5841300558	OIL DAM	TATA spare parts
5841300562	SET SCREW	TATA spare parts
5841300563	CAP NUT	TATA spare parts
5841300564	COVER	TATA spare parts
5841300566	TA.ROLL.BEARING	TATA spare parts
5841300567	OIL DAM	TATA spare parts
5841300573	PLANET SHAFT	TATA spare parts
5841300574	TA.ROLL.BEARING	TATA spare parts
5841300575	SHIM	TATA spare parts
5841300576	SHIM	TATA spare parts
5841300577	SHIM	TATA spare parts
5841300586	FLANGE	TATA spare parts
5841300595	G.SHIFT SLEEVE	TATA spare parts
5841300596	PISTON	TATA spare parts
5841300597	PISTON	TATA spare parts
5841300598	PISTON	TATA spare parts
5841300599	SHIM	TATA spare parts
5841300607	SHIM	TATA spare parts
5841300624	HEXAGON SCREW	TATA spare parts

5841300625	FLANGE	TATA spare parts
5841300629	COLLAR NUT	TATA spare parts
5841300630	COLLAR NUT	TATA spare parts
5841300642	RETAINING RING	TATA spare parts
5841300652	SEALING COLLAR	TATA spare parts
5841300653	COMPR.SPRING	TATA spare parts
5841300689	GEARBOX HOUSING	TATA spare parts
5841300724	DOUBLE GEAR	TATA spare parts
5841300726	INPUT SHAFT	TATA spare parts
5841300809	DOUBLE GEAR	TATA spare parts
5841300810	CY.ROLL.BEARING	TATA spare parts
5841300812	BEARING COVER	TATA spare parts
5841300818	GEARBOX HOUSING	TATA spare parts
5841302094	INPUT SHAFT	TATA spare parts
5841303204	OUTPUT GEAR	TATA spare parts
5841303205	CY.ROLL.BEARING	TATA spare parts
5841303207	OUTPUT SHAFT	TATA spare parts
584326000102	GEAR BOX ASSY BS6	TATA spare parts
584326103804	LOCK PLATE BS6	TATA spare parts
584326103806	FRONT HALF BS6	TATA spare parts
584326103807	REAR HALF BS6	TATA spare parts
584326106303	OIL CHANNEL BS6	TATA spare parts
584326106304	OIL CATCHER BS6	TATA spare parts
584326200101	GEAR ASSY 3RD SPEED INPUT SHAFT BS6	TATA spare parts
584326200102	GEAR ASSY 5TH SPEED INPUT SHAFT BS6	TATA spare parts
584326200106	COVER ASSY WITH BUSH REAR BS6	TATA spare parts
584326204344	SNAP RING BS6	TATA spare parts
584326205401	SENSING WHEEL BS6	TATA spare parts
584326205402	CONSTANT MESH GEAR BS6	TATA spare parts
584326207901	INPUT SHAFT BS6	TATA spare parts
584326208601	DUST COVER BS6	TATA spare parts
584326208602	SPACER BS6	TATA spare parts
584326208605	STOPPER BS6	TATA spare parts
584326253107	DEEP GROOVE BALL BEARING BS6	TATA spare parts
584326253109	DEEP GROOVE BALL BEARING BS6	TATA spare parts
584326253201	LOCKING SCREW BS6	TATA spare parts
584326253202	LOCKING SCREW BS6	TATA spare parts
584326253801	COVER FRONT BS6	TATA spare parts
584326257901	OUTPUT SHAFT BS6	TATA spare parts
584326300102	TWIN CONE ASSY 1ST/2ND SPEED BS6	TATA spare parts
584326301601	INTERMEDIATE CONE 1ST/2ND SPEED BS6	TATA spare parts
584326301602	SYNCHRO CONE BS6	TATA spare parts
584326301603	INNER CONE 1ST/2ND SPEED BS6	TATA spare parts
584326303105	CYL ROLLER BEARING BS6	TATA spare parts
584326304601	ENGAGING GEAR 1ST/2ND SPEED BS6	TATA spare parts
584326305402	CONSTANT MESH GEAR COUNTER SHAFT BS6	TATA spare parts
584326305403	GEAR 2ND SPEED BS6	TATA spare parts

584326305404	SHIFTER SLEEVE REVERSE BS6	TATA spare parts
584326305405	GEAR 1ST SPEED BS6	TATA spare parts
584326307901	COUNTER SHAFT BS6	TATA spare parts
584326308601	SPACER 1ST GEAR LAYSHAFT BS6	TATA spare parts
584326355401	REVERSE IDLER GEAR BS6	TATA spare parts
584326357901	REVERSE IDLER SHAFT BS6	TATA spare parts
584326510102	SHIFTER DOG ASSY BS6	TATA spare parts
584326513701	SHIFTER FORK 1ST/2ND SPEED BS6	TATA spare parts
584326513703	SHIFTER DOG 5TH/REVERSE SPEED BS6	TATA spare parts
584326513704	FORK 5TH - REVERSE BS6	TATA spare parts
584326513705	FORK 3RD/4TH SPEED BS6	TATA spare parts
584326513706	SHIFTER DOG 3RD/4TH SPEED BS6	TATA spare parts
584326513707	SHIFTER DOG 1ST/2ND SPEED BS6	TATA spare parts
584326513802	BRACKET REVERSE LEVER BS6	TATA spare parts
584326516702	PIVOT PIN LEVER BS6	TATA spare parts
584326518201	LEVER REVERSE GEAR BS6	TATA spare parts
584326518601	WASHER BS6-PH2	TATA spare parts
584326700101	SHIFTER LEVER ASSY BS6	TATA spare parts
584326700102	SELECTOR SHAFT ASSY BS6	TATA spare parts
584326700103	LEVER ASSY SELECTION BS6	TATA spare parts
584326700104	COVER ASSY TOP BS6	TATA spare parts
584326700108	GUIDE PLATE ASSY BS6-PH2	TATA spare parts
584326700111	INTERLOCK - BARREL ASSY BS6-PH2	TATA spare parts
584326700116	SHIFTER DOG ASSY BS6	TATA spare parts
584326703802	COVER TOP BS6	TATA spare parts
584326705102	SHIFTER LEVER BS6	TATA spare parts
584326706701	CROSS PIN SHIFTER/SELECT FINGER BS6	TATA spare parts
584326706702	BOLT BS6	TATA spare parts
584326707901	SHIFTER SHAFT 1ST/2ND SPEED BS6	TATA spare parts
584326707902	SHIFTER SHAFT 3RD/4TH SPEED BS6	TATA spare parts
584326707903	SHIFTER SHAFT 5TH/REVERSE BS6	TATA spare parts
584326708002	PIN BS6	TATA spare parts
584326708202	INTERLOCK PIECE BS6	TATA spare parts
584326708203	GUIDE PLATE BS6	TATA spare parts
584326708204	REVERSE INTERLOCK PLATE BS6	TATA spare parts
584326708701	TORSION SPRING BS6	TATA spare parts
584326709901	BARREL CENTRAL DETENT BS6	TATA spare parts
584326800103	BRACKET ASSY CABLE ANCHORING BS6	TATA spare parts
584326830101	HOOK ASSY WITH BRACKET FRONT HALF BS6	TATA spare parts
584558903501	SOCKET HUB LOCK NUT BS6-PH2	TATA spare parts
5846300018	OIL PIPE	TATA spare parts
5848300005	OIL TUBE	TATA spare parts
585552206303	MUDGUARD RH	TATA spare parts
585554820101	WINDSHIELD WASHER UNIT	TATA spare parts
585555100101	MASCOT ASSY	TATA spare parts
585555100104	MASCOT ASSY	TATA spare parts
585555100106	MASCOT ASSY	TATA spare parts

585560100113	ASSY CAB COMP WITH FITMENTS LHD	TATA spare parts
585560100113SJ	ASSY CAB COMP WITH FITMENTS LHD SPARE	TATA spare parts
585560100114	ASSY BODY SHELL PAINTED LHD	TATA spare parts
585560100124	ASSY CAB COMP WITH FITMENTS RHD WITH FIX	TATA spare parts
585560100125	ASSY BODY SHELL PAINTED WITH FIX W/S RH	TATA spare parts
585560100150	CAB COMP WITH FITMENTS RHD & MHC	TATA spare parts
585560100187	ASSY BODY SHELL PAINTED MAV 8X8	TATA spare parts
585560100188	ASSY CAB COMP WITH FITMENTS RHD MAV 8X8	TATA spare parts
585560110111	BODY SHELL ASSY WITH FITMENT PAINTED	TATA spare parts
585560110113	BODY SHELL ASSY PAINTED	TATA spare parts
585561200104	ASSY FRONT CROSS MEMBER FLOOR STRUCTURE	TATA spare parts
585561600118	ASSY BRACKET(ABS-ECU MTG.)	TATA spare parts
585562600118	ASSY FIREWALL INNER WITH FIX W/S	TATA spare parts
585562700118	ASSY SIDE FACE PANEL LH	TATA spare parts
585562700119	ASSY SIDE FACE PANEL RH	TATA spare parts
585565200111	ASSY INNER HANDLE MTG BKT (ROOF HATCH)	TATA spare parts
585565200113	ASSY HINGE PLATE	TATA spare parts
585565206001	LINK LATCH TO HANDLE(ROOF HATCH)	TATA spare parts
585565208221	LATCH MTG BKT (ROOF HATCH)	TATA spare parts
585565700104	ASSY LID ( ROOF OBSERVATION HATCH)	TATA spare parts
585565700105	ASSY NUT PLATE ROOF HATCH	TATA spare parts
585566600101	ASSY FOOT STEP LH	TATA spare parts
585566600102	ASSY FOOT STEP RH	TATA spare parts
585567102302	WS GLASS LH RHD	TATA spare parts
585567102302AE	WS GLASS LH RHD 1628 1828	TATA spare parts
585567102303	WS GLASS CORNER OUTER	TATA spare parts
585567102303AE	WS GLASS CORNER OUTER 1628 1828	TATA spare parts
585567107701	WS RUBBER BEADING LH	TATA spare parts
585567107701AE	WS RUBBER BEADING LH 1628	TATA spare parts
585567107703	WS CORNER OUTER RUBBER BEADING LH	TATA spare parts
585567107703AE	WS CRNR OUT RBBR BEADING LH-1628	TATA spare parts
585567107704	WS CORNER OUTER RUBBER BEADING RH	TATA spare parts
585567107704AE	WS CRNR OUT RBBR BEADING RH-1628	TATA spare parts
585567302301	SIDE GLASS	TATA spare parts
585567307701	SIDE RUBBER BEADING	TATA spare parts
585567607701	SEAL	TATA spare parts
585568400101	ASSY HEAT SHIELD	TATA spare parts
585568400102	ASSY ENGINE INSULATION	TATA spare parts
585568400103	ASSY CARPET LH RHD	TATA spare parts
585568400105	KIT FOR FIREWALL INSULATION	TATA spare parts
585568400106	ASSY HEAT SHIELD LHD	TATA spare parts
585568400106AE	ASSY HEAT SHIELD LHD 1628 1828	TATA spare parts
585568400107	ASSY ENGINE INSULATION LHD	TATA spare parts
585568400107AE	ASSY ENGINE INSULATION LHD 1628	TATA spare parts
585568400108	ASSY CARPET LH LHD	TATA spare parts
585568400109	KIT FOR FIREWALL INSULATION LHD	TATA spare parts
585568400109AE	KIT FIREWAL INSULATION -1628	TATA spare parts

585568400110	ASSY CARPET RH RHD	TATA spare parts
585568400111	ASSY CARPET RH LHD	TATA spare parts
585568400111AE	ASSY CARPET RH LHD 1628	TATA spare parts
585568400117	ASSY CARPET REAR LH	TATA spare parts
585568400118	ASSY CARPET REAR RH	TATA spare parts
585568400123	ASSY HEAT SHIELD 10X10	TATA spare parts
585568400124	ASSY ENGINE INSULATION 10X10	TATA spare parts
585568400126	CARPET ASSY REAR-RH	TATA spare parts
585568400127	CARPET ASSY-RH	TATA spare parts
585568400128	CARPET ASSY TUNNEL	TATA spare parts
585568400129	CARPET ASSY RH	TATA spare parts
585568400130	HEAT SHIELD ASSY	TATA spare parts
585568408201	SCUFF PLATE LH	TATA spare parts
585568408201AE	SCUFF PLATE LH 1628	TATA spare parts
585568408202	SCUFF PLATE RH	TATA spare parts
585568408202AE	SCUFF PLATE RH 1628	TATA spare parts
585568806301	A PILLAR TRIM LH	TATA spare parts
585568806302	A PILLAR TRIM RH	TATA spare parts
585568806304	A PILLAR TRIM LH LHD	TATA spare parts
585568806305	A PILLAR TRIM RH LHD	TATA spare parts
585568900101	ASSY CAB MTG BRACKET CO-DRIVER	TATA spare parts
585568900102	ASSY DASH MTG BRACKET CO-DRIVER LOWER	TATA spare parts
585568900104	ASSY CCB MTG BRACKET DRIVER	TATA spare parts
585568900106	ASSY CROSS CAR BEAM COMP	TATA spare parts
585568900107	ASSY DASHBOARD COMP	TATA spare parts
585568900110	ASSY CROSS CAR BEAM COMP LHD	TATA spare parts
585568900112	ASSY CCB MTG BRACKET CO-DRIVER LHD	TATA spare parts
585568900116	ASSY REINF. GLOVE BOX	TATA spare parts
585568900117	ASSY HINGE FOR FUSE BOX LID	TATA spare parts
585568900118	ASSY NUT PLATE (DASH BOARD MTG)	TATA spare parts
585568900119	ASSY CONTROL UNIT MTG BKT (DASH BOARD MT	TATA spare parts
585568900120	ASSY NUT PLATE FUSE BOX LID HINGE 1	TATA spare parts
585568900121	ASSY NUT PLATE FUSE BOX LID HINGE 2	TATA spare parts
585568900122	ASSY GLOVE BOX LHD	TATA spare parts
585568900126	ASSY DASHBOARD COMP RHD MAV 8X8	TATA spare parts
585568900128	ASSY FUSE BOX LID WITH KNOB	TATA spare parts
585568906301	DASHBOARD RHD	TATA spare parts
585568906302	DASHBOARD LHD	TATA spare parts
585568906303	FUSE BOX LID	TATA spare parts
585568906304	STEERING COLUMN COVER RHD	TATA spare parts
585568906305	STEERING COLUMN COVER LHD	TATA spare parts
585569000101	KIT FOR PU FOAM	TATA spare parts
585569000102	KIT FOR PU FOAM LHD	TATA spare parts
585569000102AE	KIT FOR PU FOAM LHD 1628	TATA spare parts
585569206301	SIDE WALL TRIM LH	TATA spare parts
585569206301AE	SIDE WALL TRIM LH 1628	TATA spare parts
585569206302	SIDE WALL TRIM RH	TATA spare parts

585569206302AE	SIDE WALL TRIM RH 1628	TATA spare parts
585569206311	SIDE WALL TRIM RH	TATA spare parts
585569406301	REAR WALL TRIM	TATA spare parts
585569406301AE	REAR WALL TRIM 1628	TATA spare parts
585569506301	ROOF TRIM LH	TATA spare parts
585569506302	ROOF TRIM RH	TATA spare parts
585569506303	TRIM ROOF HATCH	TATA spare parts
585569506303AE	TRIM ROOF HATCH 1628	TATA spare parts
585569506304	FOAM ROOF HATCH	TATA spare parts
585569506311	ROOF TRIM LH LHD	TATA spare parts
585569506312	ROOF TRIM RH LHD	TATA spare parts
585572200107	ASSY REINF PROXIMITY MIRROR	TATA spare parts
585572200115	ASSY DOOR SHELL LH LHD	TATA spare parts
585572200116	ASSY DOOR SHELL RH LHD	TATA spare parts
585572200123	ASSY NEW DOOR SHELL LH	TATA spare parts
585572200124	ASSY NEW DOOR SHELL RH	TATA spare parts
585572300109	KIT FOR LOCKS & KEY(COMMON KEY)	TATA spare parts
585572300114	ASSY HINGE COMPLETE(CASTING)	TATA spare parts
585572300115	KIT-LOCK SET WITH FUEL CAP	TATA spare parts
585572300120	DOOR CHECK STRAP(USING SEAT BELT)CREW C	TATA spare parts
585572300120AE	ASSY DOOR CHECK STRAP -1628	TATA spare parts
585572300121	ASSY DOOR LINK (LATCH TO OUTER HANDLE)	TATA spare parts
585572300134	ASSY LINK OUTER TO LATCH (NEW DOOR)	TATA spare parts
585572306001	DOOR LINK LATCH TO POP-UP	TATA spare parts
585572306002	LINK LATCH TO POP UP	TATA spare parts
585572306005	DOOR LINK LATCH TO INNER TRIGGER LH	TATA spare parts
585572306006	DOOR LINK LATCH TO INNER TRIGGER RH	TATA spare parts
585572306007	DOOR LINK LATCH TO KEY LH	TATA spare parts
585572306008	DOOR LINK LATCH TO KEY RH	TATA spare parts
585572306301	PRIMARY SEAL DOOR	TATA spare parts
585572306301AE	PRIMARY SEAL DOOR 1628	TATA spare parts
585572306303	SECONDARY SEAL DOOR LH	TATA spare parts
585572306303AE	SECONDARY SEAL DOOR LH 1628	TATA spare parts
585572306304	SECONDARY SEAL DOOR RH	TATA spare parts
585572306304AE	SECONDARY SEAL DOOR RH 1628	TATA spare parts
585572306313	WATER BARRIER COVER FRONT DOOR MIDDLE LH	TATA spare parts
585572306314	WATER BARRIER COVER FRONT DOOR BOTTOM L	TATA spare parts
585572306315	WATER BARRIER COVER FRONT DOOR TOP LH	TATA spare parts
585572306317	COVER WATER BARRIER FRONT DOOR MIDDLE-RH	TATA spare parts
585572306318	COVER WATER BARRIER FRONT DOOR BOTTOM-R	TATA spare parts
585572306319	COVER WATER BARRIER FRONT DOOR TOP-RH	TATA spare parts
585572306703	DOOR LINK STUD	TATA spare parts
585572308211	LEVER (REVERSE LOCK)	TATA spare parts
585572308214	DOOR CHECK STRAP BKT (DOOR)	TATA spare parts
585572308215	DOOR CHECK STRAP BKT (A PILLAR)	TATA spare parts
585572500101	ASSY DOOR GLASS GUIDE CHANNEL FRONT LH	TATA spare parts
585572500102	ASSY DOOR GLASS GUIDE CHANNEL FRONT RH	TATA spare parts

585572500103	ASSY DOOR GLASS GUIDE CHANNEL REAR LH	TATA spare parts
585572500104	ASSY DOOR GLASS GUIDE CHANNEL REAR RH	TATA spare parts
585572500110	ASSY WINDING REGULATOR LH	TATA spare parts
585572500110AE	ASSY WINDING REGULATOR LH 1628	TATA spare parts
585572500111	ASSY WINDING REGULATOR RH	TATA spare parts
585572500111AE	ASSY WINDING REGULATOR RH 1628	TATA spare parts
585572500115	ASSY GLASS GUIDE CHANNEL COMMON	TATA spare parts
585572502301	DOOR GLASS	TATA spare parts
585572502301AE	DOOR GLASS 1628 1828	TATA spare parts
585572502304	DOOR GLASS	TATA spare parts
585572506301	SEAL GLASS RUN CHANNEL	TATA spare parts
585572506302	SEAL GLASS RUN CHANNEL RH	TATA spare parts
585572506303	SEAL GLASS RUN CHANNEL BOTTOM FRONT	TATA spare parts
585572506304	SEAL GLASS RUN CHANNEL BOTTOM REAR	TATA spare parts
585572506305	WEATHER STRIP OUTER	TATA spare parts
585572506305AE	WEATHER STRIP OUTER 1628	TATA spare parts
585572506307	WEATHER STRIP INNER LH	TATA spare parts
585572506307AE	WEATHER STRIP INNER LH 1628	TATA spare parts
585572506308	WEATHER STRIP INNER RH	TATA spare parts
585572506308AE	WEATHER STRIP INNER RH 1628	TATA spare parts
585572506315	WEATHER STRIP OUTER WITH LIP LH	TATA spare parts
585572506316	WEATHER STRIP OUTER WITH LIP RH	TATA spare parts
585572506317	SEAL GLASS RUN CHANNEL BOTTOM NEW	TATA spare parts
585572506318	WEATHER STRIP INNER LH (NEW)	TATA spare parts
585572506319	WEATHER STRIP INNER RH (NEW)	TATA spare parts
585572700101	ASSY DOOR PADDING LH	TATA spare parts
585572700101AE	ASSY DOOR PADDING LH 1628	TATA spare parts
585572700102	ASSY DOOR PADDING RH	TATA spare parts
585572700102AE	ASSY DOOR PADDING RH 1628	TATA spare parts
585572700103	ASSY DOOR PADDING LH CREW CAB	TATA spare parts
585572700104	ASSY DOOR PADDING RH CREW CAB	TATA spare parts
585572700105	ASSY DOOR PADDING LH	TATA spare parts
585572700106	ASSY DOOR PADDING RH	TATA spare parts
585572717701	MEMBRANE FRONT DOOR LH	TATA spare parts
585572717702	MEMBRANE FRONT DOOR RH	TATA spare parts
585572717703	MEMBRANE FRONT DOOR LH	TATA spare parts
585572717704	MEMBRANE FRONT DOOR RH	TATA spare parts
585572717705	MEMBRANE FRONT DOOR LH	TATA spare parts
585572717706	MEMBRANE FRONT DOOR RH	TATA spare parts
585572717707	MEMBRANE FRONT DOOR LH	TATA spare parts
585572717708	MEMBRANE FRONT DOOR RH	TATA spare parts
585575100101	ASSY CENTER FLAP WELDED	TATA spare parts
585575100106	ASSY AERO CORNER LH	TATA spare parts
585575100106AE	ASSY AERO CORNER LH 1628	TATA spare parts
585575100107	ASSY AERO CORNER RH	TATA spare parts
585575100107AE	ASSY AERO CORNER RH 1628	TATA spare parts
585581100102	ASSY TANDEM RVM COMPLETE WITH FRAME LH	TATA spare parts

585581100105	BRACKET ASSY MIRROR MTG FRONT	TATA spare parts
585581100106	HOUSING ASSY	TATA spare parts
585581100116	ASSY MIRROR LH LHD	TATA spare parts
585581100116AE	ASSY MIRROR LH LHD 1628 1828	TATA spare parts
585581100117	ASSY TANDEM COMP WITH FRAME RH LHD	TATA spare parts
585581100117AE	ASSY TANDEM COMP W/FRAME RH-1628	TATA spare parts
585581100120	ASSY ELECTRICAL HEATED RVM LH	TATA spare parts
585581100121	ASSY ELECTRICAL HEATED RVM RH	TATA spare parts
585581100126	ASSY ELECTRICAL HEATED RVM LH	TATA spare parts
585581100127	ASSY ELECTRICAL HEATED RVM RH	TATA spare parts
585581100128	MIRROR ASSY FRONT	TATA spare parts
585581100129	REAR VIEW MIRROR ASSY LH	TATA spare parts
585581100130	REAR VIEW MIRROR ASSY RH	TATA spare parts
585581500101	ASSY GRAB HANDLE W END INSERT B PILLAR	TATA spare parts
585581500102	ASSY GRAB HANDLE W END INSERT A PLR LH	TATA spare parts
585581500103	ASSY GRAB HANDLE W END INSERT A PLR RH	TATA spare parts
585581506910	DASHBOARD GRAB HANDLE	TATA spare parts
585581708201	FORDABILITY PLATE 1200MM	TATA spare parts
585581708202	FORDABILITY PLATE 1400MM	TATA spare parts
585581800101	MASCOT TATA 3138 C - 8X8 VEHICLE	TATA spare parts
585581800102	MASCOT TATA 2038 C FOR 6X6 VEHICLE	TATA spare parts
585581800103	ASSY MASCOT 3138 C	TATA spare parts
585581800105	MASCOT 8X8	TATA spare parts
585581800112	ASSY TATA 1628C 4X4 MASCOT	TATA spare parts
585581800113	ASSY TATA 1828C 6X6 MASCOT	TATA spare parts
585581900120	ASSY BRACKET (FIRST AID BOX MTG)	TATA spare parts
585581906801	NOISE SHIELD LH	TATA spare parts
585581906802	NOISE SHIELD RH	TATA spare parts
585582400103	ASSY WIPER KIT COMPLETE	TATA spare parts
585582400105	ASSY WIPER KIT COMP LHD	TATA spare parts
585582400105AE	ASSY WIPER KIT COMP-1628-1828	TATA spare parts
585582400106	ASSY WIPER LINKAGE SYSTEM RHD	TATA spare parts
585582400108	OFFER-ASSY WIPER ARM AND BLADE LHD	TATA spare parts
585582400110	OFFER- ASSY WIPER LINKAGE SYSTEM LHD	TATA spare parts
585582409901	WIPER ARM RHD	TATA spare parts
585582409902	WIPER BLADE	TATA spare parts
585582409903	OFFER-WIPER ARM LHD	TATA spare parts
585583103315	L BKT CONDENSER FRAME BS6	TATA spare parts
585583106301	FACE DUCT UPPER	TATA spare parts
585583106302	DEMIST DUCT	TATA spare parts
585583107701	PACKING FOR FACE DUCT	TATA spare parts
585583400104	ASSY HVAC UNIT MTG LOWER BKT	TATA spare parts
585583400104AE	ASSY HVAC WITH MTG BRKTS -1828	TATA spare parts
585583400105	ASSY_HVAC_UNIT_MTG_BKT_RH	TATA spare parts
585583400113	KIT-NBC UNIT	TATA spare parts
585583400116	KIT-NBC UNIT	TATA spare parts
585583400139	ASSY CONTROL PANEL MTG BKT	TATA spare parts



585583400148	AIRTOP HEATER 4KW	TATA spare parts
585583400201	ASSY CONDENSER COMPLETE 24V	TATA spare parts
585583400201AE	ASSY CONDENSER COMPLETE 1828	TATA spare parts
585583400203	ASSY CONDENSER FAN SFA 14IN PUSHER 24V	TATA spare parts
585583403304	HVAC UNIT MTG SIDE LH	TATA spare parts
585583403305	HVAC UNIT MTG SIDE RH	TATA spare parts
585583403329	MTG BKT FACE DUCT CR LH	TATA spare parts
585583403333	MTG BKT DUCT DEMIST LH	TATA spare parts
585583403353	MTG BKT FACE DUCT TUNNEL	TATA spare parts
585583403354	MTG BKT FACE DUCT TUNNEL	TATA spare parts
585583403355	MTG BKT DEMIST DUCT TUNNEL	TATA spare parts
585583403363	AC HOSE MTG CLAMP	TATA spare parts
585583403365	HEATER HOSE MTG CLAMP	TATA spare parts
585583403370	HEATER HOSE CLAMP PLATE	TATA spare parts
585583403371	AC HOSE CLAMP PLATE	TATA spare parts
585583403372	AC HOSE CLAMP	TATA spare parts
585583403383	DEMIST DUCT MTG BKT RH CCB	TATA spare parts
585583404902	SUB HARNESS-HVAC MODULE MANUAL	TATA spare parts
585583404903	WIRING HARNESS DBW 2016 HEATER	TATA spare parts
585583406904	ASSY DISCHARGE PIPE	TATA spare parts
585583406905	ASSY LIQUID PIPE	TATA spare parts
585583406916	ASSY SUCTION PIPE	TATA spare parts
585583406917	ASSY DISCHARGE PIPE	TATA spare parts
585583406918	ASSY LIQUID PIPE	TATA spare parts
585583406940	ASSY DISCHARGE PIPE	TATA spare parts
585583406941	ASSY LIQUID PIPE	TATA spare parts
585583407701	PACKING FOR HVAC UNIT	TATA spare parts
585583409901	CHARGE QUANTITY STICKER	TATA spare parts
585583451601	CONDENSER ASSY	TATA spare parts
585583600117	SUCTION HOSE ASSY	TATA spare parts
585583600118	DISCHARGE HOSE ASSY	TATA spare parts
585583600120	LIQUID PIPE ASSY	TATA spare parts
585583600121	SUCTION PIPE ASSY	TATA spare parts
585583600122	DISCHARGE PIPE ASSY	TATA spare parts
585583600126	SUCTION PIPE ASSY	TATA spare parts
585583600127	LIQUID PIPE ASSY	TATA spare parts
585583601601	DISCHARGE PIPE ASSY	TATA spare parts
585583601602	LIQUID PIPE ASSY	TATA spare parts
585583601603	LIQUID PIPE ASSY	TATA spare parts
585583601605	DISCHARGE PIPE ASSY	TATA spare parts
585583607701	ASSY HEATER INLET HOSE	TATA spare parts
585583607705	HEATER OUTLET HOSE(HVAC TO RAD. PIPE)	TATA spare parts
585583607708	ASSY HEATER OUTLET HOSE(HVAC TO RADIATOR)	TATA spare parts
585583607718	HEATER INLET HOSE(BLOCK HEATER TO HVAC)	TATA spare parts
585583607719	ENGINE OUTLET HOSE(ENGINE TO BLK HEATER)	TATA spare parts
585583650101	HEATER HOSE ASSY INLET	TATA spare parts
585583650102	HEATER HOSE ASSY OUTLET	TATA spare parts

585583650111	HEATER HOSE ASSY INLET	TATA spare parts
585583650113	KIT-HEATER PIPE	TATA spare parts
585583650118	HEATER HOSE ASSY OUTLET	TATA spare parts
585583655862	DRAIN HOSE	TATA spare parts
585588100101	ASSY FRONT MUDGUARD LH	TATA spare parts
585588100101AE	ASSY FRONT MUDGUARD LH 1628	TATA spare parts
585588100102	ASSY FRONT MUDGUARD RH	TATA spare parts
585588100102AE	ASSY FRONT MUDGUARD RH 1628	TATA spare parts
585588100103	ASSY STAY ROD (FRONT MUDGUARD MTG)	TATA spare parts
585588106301	FENDER LH	TATA spare parts
585588106302	FENDER RH	TATA spare parts
585588106303	FENDER LH	TATA spare parts
585588106304	FENDER RH	TATA spare parts
585588200101	ASSY MUDFLAP MTG LH	TATA spare parts
585588200102	ASSY MUDFLAP MTG RH	TATA spare parts
585588200115	BRACKET ASSY MUDGUARD MTG LH	TATA spare parts
585588200116	BRACKET ASSY MUDGUARD MTG RH	TATA spare parts
585588206301	MUDFLAP LH	TATA spare parts
585588206302	MUDFLAP RH	TATA spare parts
585588206307	MUDGUARD RH	TATA spare parts
585588206308	MUDGUARD LH	TATA spare parts
585588206309	MUDGUARD RH	TATA spare parts
585588208204	BRACKET (MUDFLAP MTG. OUTER)	TATA spare parts
585588300103	ASSY COMP FRONT FOOT STEP	TATA spare parts
585588306701	PIN FR FOOT STEP	TATA spare parts
585588308204	BKT FRONT FOOT STEP NEW	TATA spare parts
585588500110	ASSY GRILLE HEAD LAMP	TATA spare parts
585588500119	ASSY WIRE ROPE SLING	TATA spare parts
585588500123	ASSY BUMPER TIE BAR LH	TATA spare parts
585588500124	ASSY BUMPER TIE BAR RH	TATA spare parts
585588500127	ASSY FLAG MTG	TATA spare parts
585588500129	ASSY RADIATOR GUARD	TATA spare parts
585588500133	ASSY BUMPER KIT	TATA spare parts
585588500133AE	ASSY BUMPER COMPLETE 1628	TATA spare parts
585588500134	ASSY BUMPER COMPLETE WITH FITMENTS	TATA spare parts
585588500144	ASSY FOOT STEP COMPLETE	TATA spare parts
585588500156	BRACKET ASSY RADIATOR GUARD MTG LH LHD	TATA spare parts
585588500157	BRACKET ASSY RADIATOR GUARD MTG RH LHD	TATA spare parts
585588508233	BRACKET (RADIATOR GUARD MTG)	TATA spare parts
585588508244	BRACKET RH(RADIATOR GUARD MTG)	TATA spare parts
585589100104	ASSY BRKT LATERAL SHOCK ABSORBER MTG LH	TATA spare parts
585589100107	ASSY STRIKER	TATA spare parts
585589100107AE	ASSY STRIKER 1828	TATA spare parts
585589100111	ASSY HYD PUMP	TATA spare parts
585589100111AE	ASSY HYD PUMP SINGLE CYL -1628	TATA spare parts
585589100112	ASSY REAR STRUT	TATA spare parts
585589100112AE	ASSY REAR STRUT -1628-1828	TATA spare parts

585589100113	ASSY REAR SHOCK ABSORBER MTG BRACKET LH	TATA spare parts
585589100113AE	ASSY R SHCK ABSRBR MT BKT L-1828	TATA spare parts
585589100114	ASSY REAR SHOCK ABSORBER MTG BRACKET RH	TATA spare parts
585589100114AE	ASSY R SHCK ABSRBR MT BKT R-1828	TATA spare parts
585589100115	ASSY HOSE - PUMP TO T1	TATA spare parts
585589100116	ASSY HOSE T1 TO CYLINDER	TATA spare parts
585589100117	ASSY HOSE-CYLINDER TO PUMP	TATA spare parts
585589100118	ASSY HOSE - T1 TO T2	TATA spare parts
585589100119	ASSY T JOINT	TATA spare parts
585589100119AE	ASSY T JOINT 1628	TATA spare parts
585589100121	ASSY PUMP OPERATING LEVER	TATA spare parts
585589100128	STRAIGHT CONNECTOR	TATA spare parts
585589100128AE	STRAIGHT CONNECTOR 1628	TATA spare parts
585589100129	ASSY REAR STRUT MFU	TATA spare parts
585589100131	ASSY HYD CYL BOTTOM MTG BRACKET LHD	TATA spare parts
585589100141	ASSY_LATERAL_SHOCKABSORBER_MTG_BKT_LHD	TATA spare parts
585589100141AE	ASSY LATRAL SHCK ABSRBR BKT-1828	TATA spare parts
585589100142	BRACKET ASSY CAB MTG	TATA spare parts
585589100143	FRONT CAB SUSPENSION BUSH (NEW) BS3/6	TATA spare parts
585589100143AE	FRONT CAB SUSPENSION BUSH 1628	TATA spare parts
585589100144	ASSY HYD CYL BTM MTG BRKT LH MFU	TATA spare parts
585589100145	ASSY CAB TILT CYLINDER MASTER LH MFU	TATA spare parts
585589100146	ASSY CABIN TILT CYLINDER SLAVE RH MFU	TATA spare parts
585589100147	ASSY HYD CAB TILT PUMP 8C.C MFU	TATA spare parts
585589100148	ASSY BLOCK EXTERNAL CHECK VALVE MFU	TATA spare parts
585589100152	ASSY CAB MTG BRKT FRNT BTM LH (NEW BUSH)	TATA spare parts
585589100152AE	ASSY CAB MTG BRKT FRT BTM L-1828	TATA spare parts
585589100153	ASST CAB MTG BRKT FRNT BTM RH (NEW BUSH)	TATA spare parts
585589100153AE	ASST CAB MTG BRKT FRT BTM R-1828	TATA spare parts
585589100154	ASSY CAB MTG BRKT FRT TOP (NEW BUSH)	TATA spare parts
585589100154AE	ASSY CAB MTG BRKT FRT TOP 1828	TATA spare parts
585589100155	ASSY MTG BRKT FRONT UPPER INNER(NEW)	TATA spare parts
585589100168	ASSY HYD CYL BOTTOM MTG BRACKET NEW	TATA spare parts
585589100170	ASSY CABIN TILT CYLINDER COMMON	TATA spare parts
585589100170AE	ASSY CABIN TILT CYL COMMON -1628	TATA spare parts
585589100195	KIT-HOSE CAB TILT	TATA spare parts
585589100198	KIT-HOSE SINGLE CYLINDER CAB TILT	TATA spare parts
585589103701	PIVOT MTG BRKT UPPER (NEW BUSH)	TATA spare parts
585589105301	BALLATA PACKING	TATA spare parts
585589105301AE	BALLATA PACKING 1628 1828	TATA spare parts
585589105827	HOSE CYLINDER TO T-CONN CYL TO T1	TATA spare parts
585589105828	HOSE HAND PUMP TO CYLINDER PUMP TO CYL	TATA spare parts
585589105829	HOSE LATCH TO T-CONN T2 TO LH LATCH	TATA spare parts
585589105830	HOSE ASSY T-CONNECTOR TO PUMP T1 2 PUMP	TATA spare parts
585589105831	HOSE CONNECTOR T1 TO T2	TATA spare parts
585589105832	HOSE LATCH TO T-CONN T2 TO RH LATCH	TATA spare parts
585589105833	HOSE ASSY T-CONNECTOR TO CYL	TATA spare parts

585589105834	HOSE ASSY HYD CYLINDER TO PUMP	TATA spare parts
585589105835	HOSE ASSY	TATA spare parts
585589105836	HOSE ASSY T-CONNECTOR TO PUMP	TATA spare parts
585589105837	HOSE ASSY T-CONNECTOR TO LH LATCH	TATA spare parts
585589105838	HOSE ASSY T-CONNECTOR TO RH LATCH	TATA spare parts
585589106705	PIN HYD CYL TOP MTG RH (MFU)	TATA spare parts
585589106707	FRONT CAB SUSPENSION PIN	TATA spare parts
585589106707AE	FRT CAB SUSPENSION PIN-1628-1828	TATA spare parts
585589106709	PIN HYD CYL TOP MTG LH MFU	TATA spare parts
585589106901	PLUG NUT	TATA spare parts
585589108218	BRKT HOSE MTG	TATA spare parts
585589108264	MOUNTING BRACKET	TATA spare parts
585589108603	SPECIAL SPACER HYD CYL BTM MTG LH MFU	TATA spare parts
585589108604	SPACER CAB TILT LH TOP MFU	TATA spare parts
585589109205	WASHER HYD CYL TOP MTG RH MFU	TATA spare parts
585589109207	SPACER	TATA spare parts
585589110101	SHOCK ABSORBER ASSY REAR-LH	TATA spare parts
585589110102	SHOCK ABSORBER ASSY REAR-RH	TATA spare parts
585589200101	HYDRAULIC CYLINDER MTG ASSY BKT BOTTOM	TATA spare parts
585589203401	BUSH CAB TILT CYLI MTG TOP	TATA spare parts
585589900101	ASSY CAB TILTING MECH LOCK	TATA spare parts
585589900102	ASSY TILTING MECH LOCK	TATA spare parts
585589900104	ASSY CAB TILTING MECH LOCK CYLWITH PIN	TATA spare parts
585591000101	ASSY TOP BEARTH COMPLETE	TATA spare parts
585591000101AE	ASSY TOP BEARTH COMPLETE 1628	TATA spare parts
585591000102	ASSY TOP BIRTH	TATA spare parts
585591000103	ASSY DRIVER SEAT	TATA spare parts
585591000106	ASSY PNUMATIC DRIVER SEAT LHD	TATA spare parts
585591700101	ASSY SEAT MTG BRACKET CO-DRIVER	TATA spare parts
585591700105	ASSY SEAT MTG. BRACKET DRIVER	TATA spare parts
585591700113	ASSY STAY ROD(BOTTOM BIRTH)	TATA spare parts
585591700115	ASSY BOTTOM BEARTH	TATA spare parts
585591700115AE	ASSY BOTTOM BEARTH 1628	TATA spare parts
585591700116	ASSY CHAIN (TOP BEARTH)	TATA spare parts
585591700116AE	ASSY CHAIN (TOP BEARTH) 1628	TATA spare parts
585591700119	ASSY SEAT MTG BRACKET CO-DRIVER LHD	TATA spare parts
585591700120	ASSY SEAT CO DRIVER WORLD TRUCK	TATA spare parts
585591700127	CO-DRIVER SEAT LHD	TATA spare parts
585591700128	ASSY BOTTOM BERTH NBC	TATA spare parts
585592100101	ASSY BERTH SUPPORT STRUCTURE	TATA spare parts
585592100102	ASSY BERTH PANEL LH	TATA spare parts
585592100103	ASSY BERTH PANEL RH	TATA spare parts
585592100111	ASSY BERTH SUPPORT STRUCTURE LH	TATA spare parts
585592100112	ASSY BERTH SUPPORT STRUCTURE RH	TATA spare parts
585592108203	L ANGLE RIFLE MTG LH	TATA spare parts
585592108204	L ANGLE RIFLE MTG RH	TATA spare parts
585598800101	CAB LIFTING BRACKET	TATA spare parts

585726000101	GEAR BOX ASSY BS6-PH2	TATA spare parts
585726000102	GEAR BOX ASSY BS6-PH2	TATA spare parts
585726000106	GEAR BOX ASSY BS6-PH2	TATA spare parts
585726100101	FRONT HALF ASSY BS6-PH2	TATA spare parts
585726103801	FRONT HALF BS6-PH2	TATA spare parts
585726103802	HOUSING REAR-HALF BS6-PH2	TATA spare parts
585726105301	GASKET BS6-PH2	TATA spare parts
585726200115	DUAL CONE SYNCRO ASSY	TATA spare parts
585726200116	SYNCHRO CONE ASSY 1ST/2ND SPEED BS6-PH2	TATA spare parts
585726203101	DEEP GROOVE BALL BEARING BS6-PH2	TATA spare parts
585726203102	DEEP GROOVE BALL BEARING BS6-PH2	TATA spare parts
585726204601	ENGAGING GEAR 1ST/2ND SPEED BS6-PH2	TATA spare parts
585726204602	SHIFTER SLEEVE 1/2/3/4TH SPEED BS6-PH2	TATA spare parts
585726204603	SYNCHRO RING 1S/2ND GEAR BS6-PH2	TATA spare parts
585726205401	HELICAL GR 1ST SPD MAIN SHAFT BS6-PH2	TATA spare parts
585726205402	HELICAL GR 2ND SPD MAIN SHAFT BS6-PH2	TATA spare parts
585726205403	HELICAL GR REV. SPD MAIN SHAFT BS6-PH2	TATA spare parts
585726205404	HELICAL GR 2ND SPEED MAIN SHAFT BS6-PH2	TATA spare parts
585726207901	MAIN SHAFT BS6-PH2	TATA spare parts
585726207902	MAIN SHAFT BS6-PH2	TATA spare parts
585726208601	SPACER MAIN SHAFT BS6-PH2	TATA spare parts
585726208602	SPACER MAIN SHAFT BS6-PH2	TATA spare parts
585726208603	SPACER MAIN SHAFT BS6-PH2	TATA spare parts
585726208604	SPACER MAIN SHAFT BS6-PH2	TATA spare parts
585726208605	SPACER MAIN SHAFT BS6-PH2	TATA spare parts
585726208606	SPACER MAIN SHAFT BS6-PH2	TATA spare parts
585726208607	SPACER MAIN SHAFT BS6-PH2	TATA spare parts
585726254301	CIRCLIP EXTERNAL BS6-PH2	TATA spare parts
585726254302	CIRCLIP EXTERNAL BS6-PH2	TATA spare parts
585726254303	CIRCLIP EXTERNAL BS6-PH2	TATA spare parts
585726254304	CIRCLIP EXTERNAL BS6-PH2	TATA spare parts
585726254305	CIRCLIP EXTERNAL BS6-PH2	TATA spare parts
585726254306	CIRCLIP EXTERNAL BS6-PH2	TATA spare parts
585726254307	CIRCLIP EXTERNAL BS6-PH2	TATA spare parts
585726254308	INTERNAL CIRCLIP DRIVE SHAFT BS6-PH2	TATA spare parts
585726254309	INTERNAL CIRCLIP DRIVE SHAFT BS6-PH2	TATA spare parts
585726254310	INTERNAL CIRCLIP DRIVE SHAFT BS6-PH2	TATA spare parts
585726254311	INTERNAL CIRCLIP DRIVE SHAFT BS6-PH2	TATA spare parts
585726254312	INTERNAL CIRCLIP DRIVE SHAFT BS6-PH2	TATA spare parts
585726254313	INTERNAL CIRCLIP DRIVE SHAFT BS6-PH2	TATA spare parts
585726254314	INTERNAL CIRCLIP DRIVE SHAFT BS6-PH2	TATA spare parts
585726257901	DRIVE SHAFT BS6-PH2	TATA spare parts
58572625790220	DRIVE SHAFT BS6-PH2	TATA spare parts
585726258601	SPACER DRIVE SHAFT BS6-PH2	TATA spare parts
585726303102	CYL ROLLER BEARING BS6-PH2	TATA spare parts
585726304601	SYNCHRO RING 3RD/4TH SPEED BS6-PH2	TATA spare parts
585726304602	ENGAGING GEAR 3RD/4TH SPEED BS6-PH2	TATA spare parts

585726304604	SYNCHRO CONE 3RD/4TH SPEED BS6-PH2	TATA spare parts
585726304605	SYNCHRO CONE 3RD/4TH SPEED	TATA spare parts
585726305401	CONSTANT MESH GEAR COUNTER SHAFT BS6-PH2	TATA spare parts
585726305402	HELICAL GR 3RD SPD COUNTER SHAFT BS6-PH2	TATA spare parts
585726305403	HELICAL GR 4TH SPD COUNTER SHAFT BS6-PH2	TATA spare parts
585726305404	CONSTANT MESH GEAR COUNTER SHAFT BS6-PH2	TATA spare parts
585726305405	HELICAL GR 3RD SPD COUNTER SHAFT BS6-PH2	TATA spare parts
585726305406	HELICAL GR 4TH SPD COUNTER SHAFT BS6-PH2	TATA spare parts
585726306501	HEX NUT BS6-PH2	TATA spare parts
585726307901	COUNTER SHAFT BS6-PH2	TATA spare parts
585726307902	COUNTER SHAFT BS6-PH2	TATA spare parts
585726308601	SPACER COUNTER SHAFT BS6-PH2	TATA spare parts
585726308602	SPACER COUNTER SHAFT BS6-PH2	TATA spare parts
585726308603	SPACER COUNTER SHAFT BS6-PH2	TATA spare parts
585726308604	SPACER COUNTER SHAFT BS6-PH2	TATA spare parts
585726308605	SPACER COUNTER SHAFT BS6-PH2	TATA spare parts
585726308606	SPACER COUNTER SHAFT BS6-PH2	TATA spare parts
585726308607	SPACER COUNTER SHAFT BS6-PH2	TATA spare parts
585726308608	SPACER COUNTER SHAFT BS6-PH2	TATA spare parts
585726308609	SPACER COUNTER SHAFT BS6-PH2	TATA spare parts
585726308610	SPACER COUNTER SHAFT BS6-PH2	TATA spare parts
585726308611	SPACER COUNTER SHAFT BS6-PH2	TATA spare parts
585726355401	REVERSE IDLER GEAR BS6-PH2	TATA spare parts
585726357902	REVERSE IDLER SHAFT BS6-PH2	TATA spare parts
585726358601	THRUST WASHER BS6-PH2	TATA spare parts
585726400102	PTO ASSY BS6-PH2	TATA spare parts
585726400104	PTO ASSY	TATA spare parts
585726510101	SWING FORK ASSY BS6-PH2	TATA spare parts
585726513801	SWING FORK BS6-PH2	TATA spare parts
585726513802	SWING FORK 3RD/4TH SPEED BS6-PH2	TATA spare parts
585726515101	SWING DOG BS6-PH2	TATA spare parts
585726820102	GSL ASSY BS6-PH2	TATA spare parts
585726820104	ANCHOR BRACKET ASSY SHIFT CABLE BS6-PH2	TATA spare parts
585726820106	SHIFTER CABLE ASSY BS6-PH2	TATA spare parts
585726820108	SHIFTER CABLE ASSY BS6-PH2	TATA spare parts
585726820109	ANCHOR BRACKET ASSY SHIFT CABLE	TATA spare parts
585726830102	HOOK ASSY WITH BRACKET BS6-PH2	TATA spare parts
585726830103	HOOK ASSY WITH BRACKET BS6-PH2	TATA spare parts
585726830104	HOOK ASSY WITH BRACKET	TATA spare parts
585852200101	BRACKET ASSY FENDER MTG FRONT-LH	TATA spare parts
585852200102	BRACKET ASSY FENDER MTG FRONT-RH	TATA spare parts
585852200103	BRACKET ASSY FENDER MTG REAR-LH	TATA spare parts
585852200104	BRACKET ASSY FENDER MTG REAR-RH	TATA spare parts
585855100110	MASCOT ASSY	TATA spare parts
585855100118	MASCOT ASSY	TATA spare parts
585855100119	MASCOT ASSY BS6	TATA spare parts
585855100120	MASCOT ASSY	TATA spare parts

585855100123	MASCOT ASSY BS6	TATA spare parts
585855100129	MASCOT ASSY BS6	TATA spare parts
585855100133	MASCOT ASSY BS6	TATA spare parts
585855100149	MASCOT ASSY BS6-PH2	TATA spare parts
585855106301	MASCOT 512	TATA spare parts
585855106302	MASCOT	TATA spare parts
585855106303	MASCOT	TATA spare parts
585855106304	MASCOT BS6	TATA spare parts
585855106305	MASCOT	TATA spare parts
585855106306	MASCOT BS6-PH2	TATA spare parts
585855106307	MASCOT	TATA spare parts
585855106308	MASCOTç 712	TATA spare parts
585855106310	MASCOT BS6	TATA spare parts
585855106314	MASCOT	TATA spare parts
585855106315	MASCOT	TATA spare parts
585855106317	MASCOT BS6	TATA spare parts
585855106318	MASCOT BS6	TATA spare parts
585855106324	MASCOT	TATA spare parts
585855106325	MASCOT BS6	TATA spare parts
585855106326	MASCOT BS6	TATA spare parts
585855156301	DECAL FRONT BS6	TATA spare parts
585860000103	ASSY BODY SHELL COMPLETE	TATA spare parts
585860000132	ASSY. CABIN BARE ULTRA TRK CLB BS3/4	TATA spare parts
585860000134	ASSY BODY SHELL COMP PAINTED RHD NARROW	TATA spare parts
585860000136	ASSY CAB COMPLETE RHD	TATA spare parts
585860000145	CAB COMP Y1 RHD(10.4)3L BASE AB	TATA spare parts
585860000157	ASSY CAB COMP WIDE RHD 8T 497 AC	TATA spare parts
585860000158	ASSY. CABIN W/O FITMENT BS3	TATA spare parts
585860000162	CAB ASSY	TATA spare parts
585860000171	BODY SHELL ASSY	TATA spare parts
585860000171AWBL	BARE CAB ULTRA T.12 ARTIC WHITE BLW	TATA spare parts
585860000171BRBL	BARE CAB ULTRA T.12 BRICK RED BLW	TATA spare parts
585860000171TWBL	BARE CAB ULTRA T.12 TITANIUM WHITE BLW	TATA spare parts
585860000176	BODY SHELL ASSY PAINTED	TATA spare parts
585860000176BRBL	BARE CAB ULTRA T.16 BRICK RED BLW	TATA spare parts
585860000177	BODY SHELL ASSY WITH CED COAT	TATA spare parts
585860000192	BODY SHELL ASSY PAINTED	TATA spare parts
585860000194	BODY SHELL ASSY PAINTED	TATA spare parts
585860000195	ASSY CAB - WITH DOORS - LHD	TATA spare parts
585860000197	BODY SHELL ASSY PAINTED	TATA spare parts
585860010121	BODY SHELL ASSY BS6	TATA spare parts
585860010156	"BODY SHELL ASSY,PAINTED"	TATA spare parts
585860100102	ROOF STRUCTURE ASSY	TATA spare parts
585860100112	BRACKET ASSY CAB LIFTING LH	TATA spare parts
585860100113	BRACKET ASSY CAB LIFTING RH	TATA spare parts
585860100114	ASSY ROOF BOW FRONTBS6	TATA spare parts
585860100119	ASSY ROOF STRUCTURE COMPLETE	TATA spare parts

58586010011935	ASSY ROOF STRUCTURE COMPLETE?? CED COATE	TATA spare parts
585860100121	ASSY ROOF BOW FRONT NRW	TATA spare parts
585860100130	ASSY CAB DROPPING HOOK REAR LH	TATA spare parts
585860100136	ASSY CAB DROPPING HOOK REAR RH	TATA spare parts
585860100144	ASSY TOP RAIL FRONT NRW COMPLETE	TATA spare parts
585860100155	ASSY SUNVISOR BKT WITH HEADBOX NRW	TATA spare parts
585860100156	TOP RAIL ASSY FRONT	TATA spare parts
585860108204	TOP RAIL REAR	TATA spare parts
585860108209	COVER PLATE STG CUTOUT	TATA spare parts
585860108220	TOP RAIL REAR NRW BS6	TATA spare parts
585860108222	COVER PLATE STRG CUTOUT NRW	TATA spare parts
585860108230	COVER PLATE	TATA spare parts
585860108241	COVER_PLATE_WIPER_MTG_CUTOUT NRW	TATA spare parts
585860108253	BKT HEADBOX MTG (CENTER) NRW	TATA spare parts
585860108257	CLOSING PLATE BS6	TATA spare parts
585861000104	ASSY UNDER BODY COMPLETE	TATA spare parts
58586100010435	CED-ASSY_UNDERBODY_COMPLETE	TATA spare parts
585861000114	ASSY UNDERBODY COMPLETE NRW BS6	TATA spare parts
585861000126	UNDERBODY ASSY	TATA spare parts
585861000132	UNDERBODY ASSY	TATA spare parts
585861000140	UNDERBODY ASSY	TATA spare parts
585862200119	ASSY DASHBOARD & STEERING MTG BKT NRW	TATA spare parts
585862200120	ASSY DASHBOARD MTG BKT NRW	TATA spare parts
585862600101	ASSY FIREWALL COMPLETE RHD	TATA spare parts
585862600106	ASSY FIREWALL COMPLETE NRW BS6	TATA spare parts
585862600115	ASSY FIREWALL COMPLETE RHD W/O WELD STUD	TATA spare parts
58586260011535	CED-ASSY FIREWALL WITH WELD STUD	TATA spare parts
585862600116	ASSY FR PANEL MTG BRKT UPP FR FIREWALL H	TATA spare parts
585862600118	ASSY REINF FIREWALL CONTROL MTG BKT I LH	TATA spare parts
585862600119	ASSY REINF FIREWALL CONTROL MTG BKT I RH	TATA spare parts
585862600126	ASSY FR PANEL MTG BRKT UPP FR FIREWALL H	TATA spare parts
585862600132	ASSY REINF FIREWALL CTRL MTG BKT I RHD N	TATA spare parts
585862600139	ASSY CAB LIFTING NRW	TATA spare parts
585862610136	ASSY FIREWALL ASSY WITH STUD	TATA spare parts
585862700105	ASSY PANEL TATA WIDE COMP	TATA spare parts
585862700106	ASSY LEAFSCREEN WITH MOULD	TATA spare parts
585862706306	PANEL TATA WIDE	TATA spare parts
585863000101	ASSY SIDE WALL COMPLETE LH	TATA spare parts
58586300010135	CED-ASSY SIDE WALL COMPLETE LH	TATA spare parts
585863000102	ASSY SIDE WALL COMPLETE RH	TATA spare parts
58586300010235	CED-ASSY SIDE WALL COMPLETE RH	TATA spare parts
585863000107	ASSY SIDE WALL COMPLETE NRW LH	TATA spare parts
58586300010735	CED-ASSY SIDE WALL COMPLETE NRW LH BS6	TATA spare parts
585863000108	ASSY SIDE WALL COMPLETE NRW RH	TATA spare parts
58586300010835	CED-ASSY SIDE WALL COMPLETE NRW RH BS6	TATA spare parts
585863000111	SIDE WALL ASSY LH	TATA spare parts
585863000112	SIDE WALL ASSY RH	TATA spare parts



585863200101	ASSY REINF STRIKER BS6	TATA spare parts
585863200102	ASSY REINF FENDER MTG BODYSIDE LH BS6	TATA spare parts
585863200108	ASSY SIDEWALL REINF LH BS6	TATA spare parts
585863200109	ASSY SIDEWALL REINF RH BS6	TATA spare parts
585863200111	ASSY REINF FENDER MTG BODYSIDE RH BS6	TATA spare parts
585863200137	ASSY REINF PANEL OUTER FENDER BS6	TATA spare parts
585863200151	ASSY BKT FRT PNL MTG TOP(BODY SIDE)LH	TATA spare parts
585863200152	ASSY BKT FRT PNL MTG TOP(BODY SIDE) RH	TATA spare parts
585863208270	REINF.BODY SIDE OUTER BS6	TATA spare parts
585863208295	REINFORCEMENT A-PILLAR TOP-LH BS6	TATA spare parts
585863208297	REINFORCEMENT A-POST LH BS6	TATA spare parts
585863208298	REINFORCEMENT A-PILLAR BOTTOM-LH BS6	TATA spare parts
585863218202	REINFORCEMENT A-PILLAR TOP-RH BS6	TATA spare parts
585863218204	REINFORCEMENT A-POST RH BS6	TATA spare parts
585863218205	REINFORCEMENT A-PILLAR BOTTOM-RH BS6	TATA spare parts
585863600101	ASSY BODY SIDE INNER LH	TATA spare parts
585863600102	ASSY BODY SIDE INNER RH	TATA spare parts
585863600148	INNER PANEL ASSY LH BS6	TATA spare parts
585863600149	INNER PANEL ASSY RH BS6	TATA spare parts
585863700135	CORNER PIECE LH BS6	TATA spare parts
585863700136	CORNER PIECE RH BS6	TATA spare parts
585863708211	REAR BRKT MIDDLE FENDER WIDE BS6	TATA spare parts
585864200101	ASSY REINF TOP SNORKEL MTG LH BS6	TATA spare parts
585864200103	ASSY REINF BOTTOM SNORKEL MTG BS6	TATA spare parts
585864200108	ASSY_REINF_TOP_SNORKEL_MTG_RH BS6	TATA spare parts
585864200109	ASSY REINF TOP SNORKEL MTG NRW BS6	TATA spare parts
585864200110	ASSY REINF BOTTOM SNORKEL MTG NRW BS6	TATA spare parts
585864200114	ASSY STORAGE BIN MTG BKT NRW BS6	TATA spare parts
585864200122	REINFORCEMENT ASSY SNORKEL MTG TOP-LH BS	TATA spare parts
585864200123	REINFORCEMENT ASSY SNORKEL MTG TOP-RH BS	TATA spare parts
585864200126	BRACKET ASSY SNORKEL MTG	TATA spare parts
585864200127	REINFORCEMENT ASSY BERTH HINGE MTG BS6	TATA spare parts
585864200128	REINFORCEMENT ASSY SNORKEL MTG TOP-LH BS	TATA spare parts
585864200129	REINFORCEMENT ASSY SNORKEL MTG TOP-RH BS	TATA spare parts
585864200130	REINFORCEMENT ASSY C/M BACK PANEL BS6	TATA spare parts
585864208223	REINF SUPPORT REAR WALL TOP NRW BS6	TATA spare parts
585864208234	REINFORCEMENT REAR WALL CENTER BS6	TATA spare parts
585864208236	BRACKET REAR WALL TRIM MTG BS6	TATA spare parts
585864208237	BRACKET REAR WALL TRIM MTG CENTER BS6	TATA spare parts
585864208240	BRACKET REAR WALL TRIM MTG	TATA spare parts
585864208241	BRACKET REAR WALL TRIM MTG BS6	TATA spare parts
585864208251	BRACKET REAR WALL TRIM MTG BS6	TATA spare parts
585864600102	ASSY¿ REAR WALL INNER	TATA spare parts
58586460010235	ASSY¿ REAR WALL INNER¿¿ CED COATED	TATA spare parts
585864608205	REAR WALL TRIM MTG BRACKET NRW BS6	TATA spare parts
585864700102	ASSY REAR WALL COMPLETE	TATA spare parts
585864700103	REAR WALL ASSY	TATA spare parts

585864700106	REAR WALL ASSY	TATA spare parts
585864700121	REAR WALL ASSY	TATA spare parts
585864708201	PANEL REAR WALL OUTER	TATA spare parts
58586470820135	CED-PANEL REARWALL	TATA spare parts
585864708203	REAR WALL NRW BS6	TATA spare parts
585864708206	PANEL REAR WALL	TATA spare parts
585864708213	PANEL REAR WALL	TATA spare parts
585865700101	ROOF PANEL ASM OTR	TATA spare parts
585865700116	ROOF ASSY	TATA spare parts
585865700125	ROOF ASSY	TATA spare parts
585865708201	PANEL ROOF	TATA spare parts
58586570820135	CED-PANEL ROOF	TATA spare parts
585865708203	PANELROOFNRW BS6	TATA spare parts
585865708221	PANEL ROOF BS6	TATA spare parts
585867102301	WINDSHIELD GLASS (4.76 MM THICK)	TATA spare parts
585867102302	WINDSHIELD GLASS WIDE BS3	TATA spare parts
585867102303	WINDSHIELD GLASS NARROW	TATA spare parts
585867106313	WINDSHIELD GLASS SUPPORT	TATA spare parts
585867106316	WINDSHIELD GLASS MOULD 04NOV11	TATA spare parts
585867106318	WINDSHIELD GLASS MOULD NARROW	TATA spare parts
585867106319	WINDSHIELD GLASS SUPPORT CENTER	TATA spare parts
585867106320	REAR SIDE WINDOW DAM LH	TATA spare parts
585867106322	REAR SIDE WINDOW DAM RH	TATA spare parts
585867402305	GLASS SIDE WINDOW LH	TATA spare parts
585867402306	GLASS SIDE WINDOW RH	TATA spare parts
585867800104	ASSY REAR SLIDING WINDOW	TATA spare parts
585867800111	SLIDING WINDOW ASSY REAR	TATA spare parts
585867802303	FIX GLASS REAR WINDOW	TATA spare parts
585867806303	REAR WINDOW MOULD	TATA spare parts
585867806304	REAR WINDOW MOULD NARROW	TATA spare parts
585868206301	INSULATION DASH INNER WIDE LHD	TATA spare parts
585868206303	DEADENER CENTER FLOOR CENTER WIDE	TATA spare parts
585868206304	DEADENER CENTER FLOOR REAR WIDE	TATA spare parts
585868206305	DEADENER CENTER FLOOR SIDE	TATA spare parts
585868206307	DEADENER FRONT FLOOR CENTER WIDE	TATA spare parts
585868206308	DEADENER FRONT FLOOR WHEEL HOUSEçBS6	TATA spare parts
585868206311	INSULATION DASH WIDE RHD	TATA spare parts
585868206320	DEADENER CTR FLOOR NRW BS6	TATA spare parts
585868206321	DEADENER FRONT FLOOR REAR NRW BS6	TATA spare parts
585868206322	DEADENER FRONT FLOOR NRW BS6	TATA spare parts
585868406304	CARPET FLOOR NRW RHD	TATA spare parts
585868406305	CARPET FLOOR SLEEPER RHD	TATA spare parts
585868406308	CARPET FLOOR WIDE	TATA spare parts
585868406309	CARPET FLOOR	TATA spare parts
585868406317	CARPET REAR	TATA spare parts
585868406320	CARPET FLOOR BS6	TATA spare parts
585868406322	CARPET REAR FLOOR	TATA spare parts

585868406323	CARPET REAR FLOOR	TATA spare parts
585868406327	CARPET FRONT FLOOR BS6	TATA spare parts
585868406330	CARPET TUNNEL BS6	TATA spare parts
585868406331	CARPET FLOOR LH BS6	TATA spare parts
585868406332	CARPET FLOOR RH BS6	TATA spare parts
585868406333	CARPET FLOOR LH BS6	TATA spare parts
585868406334	CARPET FLOOR RH BS6	TATA spare parts
585868406335	CARPET TUNNEL BS6	TATA spare parts
585868406336	CARPET FLOOR	TATA spare parts
585868900146	COCKPIT ASSY	TATA spare parts
585868900150	ASSY CROSS MEMBER DASH COMPLETE WIDE RHD	TATA spare parts
585868900152	ASSY CROSS MEMBER DASH COMPLETE WIDE LHD	TATA spare parts
585868900153	ASSY CROSS MEMBER DASH COMPLETE NRW RHD	TATA spare parts
585868900160	ASSY DASHBOARD WIDE RHD	TATA spare parts
585868900166	ASSY AIR VENT CENTER LH	TATA spare parts
585868900167	ASSY AIR VENT CENTER RH	TATA spare parts
585868900168	ASSY AIR VENT SIDE LH	TATA spare parts
585868900169	ASSY AIR VENT SIDE RH	TATA spare parts
585868900170	ASSY ARMATURE DASHBOARD WIDER RHD	TATA spare parts
585868900171	ASSY DEFROST COVER WIDE	TATA spare parts
585868900172	ASSY PASSENGER TRAY LOWER	TATA spare parts
585868900173	ASSY GLOVE BOX COMPLETE WIDE RHD	TATA spare parts
585868900174	ASSY PASSENGER TRAY UPPER WIDE	TATA spare parts
585868900176	ASSY TOP COVER DASHBOARD WIDE RHD	TATA spare parts
585868900177	ASSY CENTER CLUSTER DASHBOARD WIDE RHD	TATA spare parts
585868900179	ASSY SHOPPING HOOK	TATA spare parts
585868900180	ASSY CARD HOLDER DASHBOARD	TATA spare parts
585868900181	ASSY MT COVER DASHBOARD	TATA spare parts
585868900186	ASSY DASHBOARD MTG BKT SIDE LH	TATA spare parts
585868900187	ASSY DASHBOARD MTG BKT SIDE RH	TATA spare parts
585868900188	ASSY COVER DRIVE LOWER WIDE RHD	TATA spare parts
585868900189	ASSY SIDE DEFROST NOZZLE LH WIDE RHD	TATA spare parts
585868900191	ASSY STRIKER PASSENGER UPPER TRAY	TATA spare parts
585868900192	ASSY STRIKER GLOVE BOX	TATA spare parts
585868900193	ASSY SIDE DEFROST NOZZLE RH WIDE RHD	TATA spare parts
585868900207	COCKPIT ASSY	TATA spare parts
585868900222	ASSY SIDE COVER DASHBOARD LH	TATA spare parts
585868900223	ASSY SIDE COVER DASHBOARD RH	TATA spare parts
585868900226	ASSY TWEETER COVER TOP COVER WIDE LH	TATA spare parts
585868900227	ASSY TWEETER COVER TOP COVER WIDE RH	TATA spare parts
585868900235	ASSY FLOOR CONSOLE MANUAL UPPER WIDE RHD	TATA spare parts
585868900236	ASSY FLOOR CONSOLE MANUAL LOWER WIDE RHD	TATA spare parts
585868900237	ASSY COCKPIT WIDE RHD 497 FV 12V	TATA spare parts
585868900248	ASSYSHROUDINSTRU.CLUSTER12VRHD BS6	TATA spare parts
585868900249	ASSY LOCK GLOVE BOX	TATA spare parts
585868900250	ASSY LOCK PASSENGER TRAY UPPER	TATA spare parts
585868900252	ASSY PASSENGER TRAY LOWER LHD	TATA spare parts

585868900253	ASSY PASSENGER TRAY UPPER WIDE LHD	TATA spare parts
585868900254	ASSY ARMATURE DASHBOARD WIDER LHD	TATA spare parts
585868900255	ASSY GLOVE BOX COMPLETE WIDE LHD	TATA spare parts
585868900256	ASSY COVER DRIVE LOWER WIDE LHD	TATA spare parts
585868900257	ASSY TOP COVER DASHBOARD WIDE LHD	TATA spare parts
585868900271	ASSY DEFROST COVER WIDE BASE VERSION	TATA spare parts
585868900283	ASSY COCKPIT WIDE RHD 3L FV 12V	TATA spare parts
585868900290	ASSY DEFROST COVER NARROW BASE VERSION	TATA spare parts
585868900292	ASSY TOP COVER DASHBOARD NARROW RHD BS6	TATA spare parts
585868900294	ASSY COVER DRIVE LOWER NARROW RHD BS6	TATA spare parts
585868900295	ASSY GLOVE BOX COMPLETE NARROW RHD BS6	TATA spare parts
585868900324	STEERING WHEEL ASSY BS6-PH2	TATA spare parts
585868900326	STEERING ASSY BS6-PH2	TATA spare parts
585868900330	ARMATURE ASSY BS6-PH2	TATA spare parts
585868900334	STEERING WHEEL ASSY BS6-PH2	TATA spare parts
585868906327	MT COVER GEAR SHIFTER NARROW BS6	TATA spare parts
585868906339	TWEETER COVER TOP COVER WIDE LH	TATA spare parts
585868906340	TWEETER COVER TOP COVER WIDE RH	TATA spare parts
585868906341	NACELLE TOP	TATA spare parts
585868906342	NACELLE BOTTOM	TATA spare parts
585868906343	TOP COVER DASHBOARD WIDE RHD	TATA spare parts
585868906345	SHROUD INSTRUMENT CLUSTER LOWER RHD	TATA spare parts
585868906350	COVER GEAR SHIFTER RHD	TATA spare parts
585868906352	MOUNTINGBUSHFUUSEBOX BS6	TATA spare parts
585868906356	COVER OBD CONNECTOR RHD	TATA spare parts
585868906360	COVER GLOVE BOX WIDE BS6	TATA spare parts
585868906362	PASSENGER TRAY LOWER WIDE RHD BS6	TATA spare parts
585868906366	COVER TRIM GEAR SHIFTER LEVER WIDE RHD	TATA spare parts
585868906367	FUSE BOX COVER WIDE RHD	TATA spare parts
585868906375	BOOT COVER HOLDER	TATA spare parts
585868906376	SHROUD INSTRUMENT CLUSTER UPPER RHD	TATA spare parts
585868906380	STOPPER-GLOVE BOX BS6	TATA spare parts
585868906398	UTILITY BIN CENTER CLUSTER	TATA spare parts
585868906401	DUMMY AIR VENT CENTER LH	TATA spare parts
585868906402	DUMMY AIR VENT CENTER RH	TATA spare parts
585868906403	FLOOR CONSOLE MANUAL UPPER WIDE RHD	TATA spare parts
585868906405	FLOOR CONSOLE MANUAL GAP HIDER WIDE RHD	TATA spare parts
585868906406	DUMMY AIR VENT SIDE LH	TATA spare parts
585868906407	DUMMY AIR VENT SIDE RH	TATA spare parts
585868906409	NACELLE GAP HIDER RHD	TATA spare parts
585868906410	DUMMY COVER HVAC CONTROL UNIT	TATA spare parts
585868906411	ADJUSTABLE CUP HOLDER FOR FLOOR CONSOLE	TATA spare parts
585868906419	FUSE BOX COVER WIDE LHD	TATA spare parts
585868906422	COVER TRIM GEAR SHIFTER LEVER WIDE LHD	TATA spare parts
585868906426	TOP COVER DASHBOARD WIDE LHD	TATA spare parts
585868906427	SHROUD INSTRUMENT CLUSTER LOWER LHD	TATA spare parts
585868906428	SHROUD INSTRUMENT CLUSTER UPPER LHD	TATA spare parts

585868906431	FLOOR CONSOLE MANUAL LOWER WIDE LHD	TATA spare parts
585868906457	FUSE BOX COVER NARROW RHD	TATA spare parts
585868906460	RING BELLOW COVER GEAR SHIFTER NARROW BS	TATA spare parts
585868906483	FLOOR CONSOLE	TATA spare parts
585868906499	COVERGEARSHIFTLER BS6	TATA spare parts
585868907702	DAMPER-GLOVE BOX	TATA spare parts
585868908208	CENTERLEGMOUNTINGBRACKETRH BS6	TATA spare parts
585868908209	CENTERLEGMOUNTINGBRACKETLH BS6	TATA spare parts
585868910150	ASSY COCKPIT NARROW RHD BASE VERSION 4SP	TATA spare parts
585868910164	ASSY CENTER CLUSTER RHD 24V	TATA spare parts
585868910184	COCKPIT ASSY	TATA spare parts
585868910188	ASSY CROSS MEMBER DASH COMP ULTRA PLUS	TATA spare parts
585868910189	ASSY DASH MTG BKT & DR LWR ULTRA PLUS	TATA spare parts
585868910191	ASSY FLR CONSOLE AIR HAND BRAKE WIDE RHD	TATA spare parts
585868910192	ASSY FLOOR CONSOLE COMP WIDE LHD (ABS)	TATA spare parts
585868910215	FLOOR CONSOLE ASSY BS6	TATA spare parts
585868910224	BRACKET ASSY FLOOR CONSOLE MTG FRONT BS6	TATA spare parts
585868910230	COVER ASSY GEAR SHIFTER	TATA spare parts
585868910234	COCKPIT ASSY	TATA spare parts
585868910240	BOOTRINGASSY BS6	TATA spare parts
585868910241	COVERASSYGEARSHIFTER BS6	TATA spare parts
585868916316	NACELLE BOTTOM BS6-PH2	TATA spare parts
585868916317	NACELLE TOP BS6-PH2	TATA spare parts
585868916318	GARNISH BS6-PH2	TATA spare parts
585868916319	SWITCH BEZEL BS6-PH2	TATA spare parts
585868916321	HORN PAD ASSY BS6-PH2	TATA spare parts
585868916324	NACELLE TOP BS6-PH2	TATA spare parts
585868916325	NACELLE BOTTOM BS6-PH2	TATA spare parts
585868916403	HOLDERBOOTCOVER BS6	TATA spare parts
585868920106	BRACKET ASSY CONSOLE MTG BS6	TATA spare parts
585868920111	CROSSMEMBERASSYDASHBOARD BS6	TATA spare parts
585868920115	COCKPIT ASSY BS6	TATA spare parts
585868920116	COCKPIT ASSY	TATA spare parts
585868920119	COCKPIT ASSY BS6	TATA spare parts
585868920121	CLUSTER ASSY CENTER BS6	TATA spare parts
585868920128	FLOOR CONSOLE ASSY WITH COVER FRONT BS6	TATA spare parts
585868920130	COCKPIT ASSY BS6	TATA spare parts
585868920132	COCKPIT ASSY BS6	TATA spare parts
585868920136	CROSS MEMBER ASSY DASHBOARD BS6	TATA spare parts
585868920140	COCKPIT ASSY BS6	TATA spare parts
585868920147	ARMATURE ASSY BS6	TATA spare parts
585868920148	ARMATURE ASSY BS6	TATA spare parts
585868920149	COVER ASSY GEAR SHIFTER BS6	TATA spare parts
585868920150	COCKPIT ASSY BS6	TATA spare parts
585868920155	ARMATURE ASSY BS6	TATA spare parts
585868920159	COCKPIT ASSY	TATA spare parts
585868920173	CAP ASSY BS6	TATA spare parts

585868920190	COCKPIT ASSY BS6	TATA spare parts
585868920196	COCKPIT ASSY BS6	TATA spare parts
585868930109	COCKPIT ASSY BS6	TATA spare parts
585868930126	COCKPIT ASSY BS6	TATA spare parts
585868930129	SHROUD ASSY INSTRUMENT CLUSTER BS6	TATA spare parts
585868930130	SHROUD ASSY INSTRUMENT CLUSTER BS6	TATA spare parts
585868930131	CLUSTER ASSY CENTER BS6	TATA spare parts
585868930146	COCKPIT ASSY BS6	TATA spare parts
585868930154	COCKPIT ASSY BS6	TATA spare parts
585868930192	COCKPIT ASSY BS6	TATA spare parts
585868936305	CAP GLOVE BOX BS6	TATA spare parts
585868986301	CARPET PANEL BERTH BS6-PH2	TATA spare parts
585869100101	ASSY A PILLAR UPPER TRIM LH	TATA spare parts
585869100102	ASSY A PILLAR UPPER TRIM RH	TATA spare parts
585869100105	ASSY B PILLAR LOWER TRIM WIDE DAY LH	TATA spare parts
585869100106	ASSY B PILLAR LOWER TRIM WIDE DAY RH	TATA spare parts
585869100112	ASSY BRACKET ASSIST GRIP HANDLE LH	TATA spare parts
585869100113	ASSY SCUFF PLATE LH	TATA spare parts
585869100114	ASSY SCUFF PLATE RH	TATA spare parts
585869100115	ASSY BRACKET A PILLAR GRAB HANDLE LH	TATA spare parts
585869100116	ASSY BRACKET A PILLAR GRAB HANDLE RH	TATA spare parts
585869100117	ASSY BRACKET ASSIST GRIP HANDLE RH	TATA spare parts
585869100118	ASSY B PILLAR UPPER TRIM WIDE DAY LH FOR	TATA spare parts
585869100119	ASSY B PILLAR UPPER TRIM WIDE DAY RH FOR	TATA spare parts
585869100122	B-PILLAR TRIM ASSY LOWER-LH	TATA spare parts
585869100123	B-PILLAR TRIM ASSY LOWER-RH	TATA spare parts
585869100124	B-PILLAR TRIM ASSY UPPER-LH	TATA spare parts
585869100125	B-PILLAR TRIM ASSY UPPER-RH	TATA spare parts
585869100127	SIDE WALL TRIM ASSY LH	TATA spare parts
585869100128	SIDE WALL TRIM ASSY RH	TATA spare parts
585869100134	A-PILLAR TRIM ASSY UPPER-LH BS6-PH2	TATA spare parts
585869100135	A-PILLAR TRIM ASSY UPPER-RH BS6-PH2	TATA spare parts
585869106306	GRAB HANDLE A-PILLAR END CAP UPPER BS6	TATA spare parts
585869106307	GRAB HANDLE A-PILLAR END CAP LOWER BS6	TATA spare parts
585869106318	A PILLAR GRAB HANDLE	TATA spare parts
585869106319	B PILLAR GRAB HANDLE	TATA spare parts
585869106320	A PILLAR LOWER TRIM LH	TATA spare parts
585869106321	A PILLAR LOWER TRIM RH	TATA spare parts
585869106333	CAP GRAB HANDLE PILLAR 1	TATA spare parts
585869106336	CAP GRAB HANDLE PILLAR 2	TATA spare parts
585869106339	A PILLAR GRAB HANDLE	TATA spare parts
585869106340	B PILLAR GRAB HANDLE	TATA spare parts
585869106342	CAP GRAB HANDLE PILLAR 1	TATA spare parts
585869106343	CAP GRAB HANDLE PILLAR 2	TATA spare parts
585869106344	SCUFF PLATE MOUNTING CAP	TATA spare parts
585869106354	GRAB HANDLE A-PILLAR-LH	TATA spare parts
585869106355	GRAB HANDLE A-PILLAR-RH	TATA spare parts

585869108205	BKT ASSIST GRIP HANDLE RH	TATA spare parts
585869108209	SCUFF PLATE MOUNTING BKT LH	TATA spare parts
585869108210	SCUFF PLATE MOUNTING BKT RH	TATA spare parts
585869306301	STORAGE BOX REAR WALL NRW	TATA spare parts
585869400102	ASSY REAR WALL TRIM WITH FOAM	TATA spare parts
585869400103	REAR WALL TRIM ASSY	TATA spare parts
585869406301	REAR WALL TRIM WIDE DAY	TATA spare parts
585869406303	COAT HOOK REAR WALL	TATA spare parts
585869406308	REAR WALL TRIM WIDE	TATA spare parts
585869406312	REAR WALL TRIM BS6	TATA spare parts
585869500102	ASSY HEADBOX WIDE	TATA spare parts
585869500103	ASSY HEADLINING ROOF WIDE RHD	TATA spare parts
585869500105	ASSY SUNGLASS CASE	TATA spare parts
585869500107	ASSY CONSOLE HEADBOX	TATA spare parts
585869500118	ASSY CAP HEADBOX CENTER MOUNTING BS6	TATA spare parts
585869500122	ASSY HEADBOX NARROW	TATA spare parts
585869500123	HEADLINER ASSY	TATA spare parts
585869500126	ASSY CONSOLE HEADBOX W/O GOGGLE CASE	TATA spare parts
585869500131	ASSY HEADBOX WIDE W/O GOGGLE CASE	TATA spare parts
585869500135	HEAD LINING ASSY ROOF	TATA spare parts
585869500139	HEADBOX ASSY BS6-PH2	TATA spare parts
585869506309	CAP CENTER CONSOLE BS6	TATA spare parts
585869506310	HEADBOX WIDE MOCKUP CHANGE	TATA spare parts
585869506311	CONSOLE HEADBOX MOCKUP CHANGE	TATA spare parts
585869506312	HEADBOX CENTER MOCKUP CHANGE	TATA spare parts
585869506315	COVER HEADBOX SIDE WIDE LH	TATA spare parts
585869506316	COVER HEADBOX SIDE WIDE RH	TATA spare parts
585869506317	PIN SUNGLASS CASE MOCKUP CHANGE	TATA spare parts
585869506321	CAP HEADBOX CENTER MOUNTING	TATA spare parts
585869506322	CAP HEADBOX MOUNTING	TATA spare parts
585869506323	DAMPER SUNGLASS CASE	TATA spare parts
585869506324	HINGE BRACKET CONSOLE HEAD BOX	TATA spare parts
585869506325	DUMMY COVER HEADBOX CENTER	TATA spare parts
585869506328	COVERHEADBOXSIDENARROWLH BS6	TATA spare parts
585869506329	COVERHEADBOXSIDENARROWRH BS6	TATA spare parts
585869506334	HEADBOX(CONSOLEINTEGRATED) BS6	TATA spare parts
585869506341	COVER SUNGLASS CASE BS6	TATA spare parts
585869507702	DAMPER SUNGLASS HOUSING	TATA spare parts
585872000103	ASSY DOOR COMPLETE LH MW M-LATCH	TATA spare parts
585872000104	ASSY DOOR COMPLETE RH	TATA spare parts
585872100101	ASSY GLASS RUN CHANNEL REAR LH	TATA spare parts
585872100102	ASSY GLASS RUN CHANNEL REAR RH	TATA spare parts
585872200101	ASSY DOOR INNER COMPLETE LH BS6	TATA spare parts
585872200102	ASSY DOOR INNER COMPLETE RH BS6	TATA spare parts
585872200105	ASSY DOOR SHELL LH Y1	TATA spare parts
58587220010535	ASSY. DOOR SHELL COMP. LH-CED BS3/4/6	TATA spare parts
585872200106	ASSY DOOR SHELL RH Y1	TATA spare parts

58587220010635	ASSY. DOOR SHELL COMP. RH-CED BS3/4/6	TATA spare parts
585872200134	FRONT DOOR SHELL ASSY LH BS6	TATA spare parts
585872200135	FRONT DOOR SHELL ASSY RH BS6	TATA spare parts
585872208205	REINF_WAIST_LEVEL_DOOR_OUTER_LH BS6	TATA spare parts
585872208206	REINF_WAIST_LEVEL_DOOR_OUTER_RH BS6	TATA spare parts
585872300101	ASSY DOOR HINGE LH	TATA spare parts
585872300102	ASSY DOOR HINGE RH	TATA spare parts
585872300103	KIT-LOCK	TATA spare parts
585872300109	ASSY DOOR LATCH MANUAL LH	TATA spare parts
585872300110	ASSY DOOR LATCH MANUAL RH	TATA spare parts
585872300111	ASSY DOOR LATCH PWR LH 12V RHD	TATA spare parts
585872300112	ASSY DOOR LATCH PWR RH 12V RHD	TATA spare parts
585872300115	KIT-LOCK BS6-PH2	TATA spare parts
585872300118	ASSY LOCK BARREL LH	TATA spare parts
585872300129	ASSY LOCK BARREL RH	TATA spare parts
585872300132	ASSY CHECK STRAP	TATA spare parts
585872300133	ASSY DOOR INNER HANDLE LH	TATA spare parts
585872300134	ASSY DOOR INNER HANDLE RH	TATA spare parts
585872300135	ASSY DOOR OUTER HANDLE LH	TATA spare parts
585872300136	ASSY DOOR OUTER HANDLE RH	TATA spare parts
585872300143	ASSY LOCK KIT WITHOUT TRANSPONDER 12V	TATA spare parts
585872300144	ASSY LOCK KIT WITH TRANSPONDER 12V	TATA spare parts
585872300145	ASSY LOCK KIT WITHOUT TRANSPONDER 24V	TATA spare parts
585872300162	DOOR HINGE	TATA spare parts
585872300166	HINGE ASSY LH	TATA spare parts
585872300167	HINGE ASSY RH	TATA spare parts
585872300182	ASSY LOCK KIT WITH TRANSPONDER 12V BS6	TATA spare parts
585872300183	KIT-LOCK BS6	TATA spare parts
585872306311	INNERDOORHANDLECABLELH BS6	TATA spare parts
585872306312	INNERDOORHANDLECABLERH BS6	TATA spare parts
585872306313	DOORPOPUPCABLELH BS6	TATA spare parts
585872306314	DOORPOPUPCABLERH BS6	TATA spare parts
585872306315	KEYRODLH BS6	TATA spare parts
585872306316	KEYRODRH BS6	TATA spare parts
585872308001	BOLT M8X32 FOR DOOR HINGE MTG	TATA spare parts
585872308211	CABLE HOLDER	TATA spare parts
585872500107	ASSY WINDOW WINDING REGULATOR MANUAL L	TATA spare parts
585872500108	ASSY WINDOW WINDING REGULATOR MANUAL R	TATA spare parts
585872500109	WINDOW WINDING REGULATOR SYSTEM POWER	TATA spare parts
585872500110	ASSY WINDOW WINDING REGULATOR PWR LH 24	TATA spare parts
585872500111	WINDOW WINDING REGULATOR SYSTEM POWER	TATA spare parts
585872500112	ASSY WINDOW WINDING REGULATOR PWR RH 24	TATA spare parts
585872502301	GLASS SIDE DOOR LH	TATA spare parts
585872502302	GLASS SIDE DOOR RH	TATA spare parts
585872506314	DOOR PRIMARY SEAL LH	TATA spare parts
585872506315	DOOR PRIMARY SEAL RH	TATA spare parts
585872506316	DOOR SECONDARY SEAL LH	TATA spare parts



585872506317	DOOR SECONDARY SEAL RH	TATA spare parts
585872506318	GLASS RUN CHANNEL LH	TATA spare parts
585872506319	GLASS RUN CHANNEL RH	TATA spare parts
585872506320	INNER BELT MOULD LH	TATA spare parts
585872506321	INNER BELT MOULD RH	TATA spare parts
585872506322	DOOR GAP HIDING SEAL LH METZELER	TATA spare parts
585872506323	DOOR GAP HIDING SEAL RH	TATA spare parts
585872506324	OUTER BELT MOULD LH	TATA spare parts
585872506325	OUTER BELT MOULD RH	TATA spare parts
585872506328	GROMMET DOOR GLASS	TATA spare parts
585872506333	DOOR SECONDARY SEAL LH	TATA spare parts
585872506334	DOOR SECONDARY SEAL RH	TATA spare parts
585872700101	ASSY DOOR TRIM POWER WINDOW LH RHD	TATA spare parts
585872700102	ASSY DOOR TRIM POWER WINDOW RH RHD	TATA spare parts
585872700108	ASSY DOOR TRIM MANUAL WINDOW LH	TATA spare parts
585872700108BL	ASSY DOOR TRIM MANUAL WINDOW LH BLACK B	TATA spare parts
585872700108GR	DOOR TRIM MANUAL WINDOW LH GRAPHITE BS6	TATA spare parts
585872700109	ASSY DOOR TRIM MANUAL WINDOW RH	TATA spare parts
585872700109BL	ASSY DOOR TRIM MANUAL WINDOW RH BLACK B	TATA spare parts
585872700109GR	DOOR TRIM MANUAL WINDOW RH GRAPHITE BS6	TATA spare parts
585872700110	ASSY COVER OSRVM DOOR INNER LH	TATA spare parts
585872700111	ASSY COVER OSRVM DOOR INNER RH	TATA spare parts
585872700114	ASSY SWITCH BEZEL POWER WINDOW DOOR TRIM	TATA spare parts
585872700115	ASSY SWITCH BEZEL POWER WINDOW DOOR TRIM	TATA spare parts
585872700118	ASSY BRACKET CARRIER PLATE DOOR	TATA spare parts
585872706315	COVER GRIP HANDLE DOOR LH	TATA spare parts
585872706316	COVER GRIP HANDLE DOOR RH	TATA spare parts
585872706319	CARRIER PLATE MANUAL WINDOW DOOR TRIM L	TATA spare parts
585872706321	CARRIER PLATE MANUAL WINDOW DOOR TRIM R	TATA spare parts
585872706328	PLASTIC MEMBRANE DOOR LH	TATA spare parts
585872706329	PLASTIC MEMBRANE DOOR RH	TATA spare parts
585872708201	BRACKET CARRIER PLATE DOOR	TATA spare parts
585875100101	TATA PANEL ASSY NARROW	TATA spare parts
585875100103	AERO CORNER ASSY LH	TATA spare parts
585875100104	AERO CORNER ASSY RH	TATA spare parts
585875200101	KIT-T EMBLEM & BACKGROUND PLATE	TATA spare parts
585875200113	T-EMBLEM ASSY	TATA spare parts
585875206301	T EMBLEM	TATA spare parts
585875206302	TATA EMBLEM	TATA spare parts
585875206303	T EMBLEM BACKGROUND PLATE	TATA spare parts
585875206306	MASCOT ULTRA	TATA spare parts
585875206307	MASCOT 1012	TATA spare parts
585875206308	MASCOT 812	TATA spare parts
585875206309	MASCOT 912	TATA spare parts
585875206312	MASCOT 1212 BS6	TATA spare parts
585875206314	MASCOT 1518	TATA spare parts
585875206502	SPRING NUT	TATA spare parts

585881000101	KIT REFLECTIVE TAPE	TATA spare parts
585881000111	REFLECTIVE TAPE ASSY ULTRA+	TATA spare parts
585881000112	KIT-RETRO REFLECTIVE TAPE	TATA spare parts
585881000113	REFLECTIVE TAPE ASSY BS6	TATA spare parts
585881006319	REFLECTIVE TAPE < 7.5T	TATA spare parts
585881100103	SUNVISOR ASSY WITH 2-POINT MTG LH	TATA spare parts
585881100104	SUNVISOR ASSY WITH 2-POINT MTG RH	TATA spare parts
585881100114	ORVM ASSY LH	TATA spare parts
585881100115	ORVM ASSY RH	TATA spare parts
585881100136	ASSY. PROXY MIRROR BS3/4/6	TATA spare parts
585881100137	ASSY FRONT MIRROR	TATA spare parts
585881100141	ASSY SUNVISOR MOUNTING BRACKET BOLTED	TATA spare parts
585881100157	SUNVISOR ASSY_LH	TATA spare parts
585881100158	SUNVISOR ASSY_RH	TATA spare parts
585881100170	ASSY KIT ORVM RHD LH	TATA spare parts
585881100171	ASSY KIT ORVM RHD RH	TATA spare parts
585881100172	ASSY FRAME ORVM RHD LH	TATA spare parts
585881100173	ASSY FRAME ORVM RHD RH	TATA spare parts
585881100174	ASSY MAIN MIRROR LH	TATA spare parts
585881100175	ASSY MAIN MIRROR RH	TATA spare parts
585881100176	ASSY WIDE ANGLE MIRROR	TATA spare parts
585881100186	ASSY KIT ORVM RH MANUAL(ECE7.5T)	TATA spare parts
585881100213	KIT-ORVMLH	TATA spare parts
585881100214	KIT-ORVMRH	TATA spare parts
585881100239	ASSY KIT ORVM LH ULRTA+AIS/ECE	TATA spare parts
585881100240	ASSY KIT ORVM RH ULRTA+AIS/ECE	TATA spare parts
585881100244	KIT ORVM RH ULRTA+(ECE)	TATA spare parts
585881100284	KIT-ORVM RH NARROW AIS	TATA spare parts
585881100295	KIT-ORVM LH NARROW AIS	TATA spare parts
585881106302	STICKER (CAB TILTING INSTR)	TATA spare parts
585881106306	STRUCTURAL PAD BS6	TATA spare parts
585881106309	STRUCTURAL PAD BS6	TATA spare parts
585881106313	KIT FOR BLACKENING TAPE PANEL FRONT DOOR	TATA spare parts
585881106314	KIT FOR BLACKENING TAPE PANEL FRONT DOOR	TATA spare parts
585881110101	SUNVISOR ASSY LH	TATA spare parts
585881110102	SUNVISOR ASSY RH	TATA spare parts
585881110109	FRONT VIEW MIRROR ASSY BS6-PH2	TATA spare parts
585881116301	HOLE PLUG DIA 50 (PROTECTION FILM)	TATA spare parts
585881116303	HOLE PLUG ELLIPTICAL (PROTECTION FILM) B	TATA spare parts
585881906301	GROMMET BS6	TATA spare parts
585881906302	GROMMET BS6-PH2	TATA spare parts
585882400108	CHANNEL LINK MOULDING BS6	TATA spare parts
585882400111	ASSY WIPER SYSTEM RHD 12V	TATA spare parts
585882400114	ASSY WIPER ARM & BLADE DRIVER WIDE RHD	TATA spare parts
585882400115	ASSY WIPER ARM & BLADE CO DRIVER WIDE RH	TATA spare parts
585882400118	SPINDLE OSCILLATING LINK & PIN ASSY	TATA spare parts
585882400119	ASSY WIPER SYSTEM RHD (24V)	TATA spare parts

585882400120	ASSY WIPER SYSTEM LHD 24V (LUCASTVS)	TATA spare parts
585882400121	WIPER ARM ASSY WITH BLADE DRIVER SIDE	TATA spare parts
585882400122	WIPER ARM ASSY WITH BLADE CO-DRIVER SIDE	TATA spare parts
585882400123	ASSY WIPING LINKAGES & SPINDLE RHD NRW	TATA spare parts
585882400125	ASSY. WIPING LINKAGES & SPINDL RHD BS3/4	TATA spare parts
585882400127	HINGE ASSY BS6	TATA spare parts
585882400134	ASSY WIPER ARM & BLADE DRIVER NRW RHD(BC	TATA spare parts
585882400135	ASSY WIPER ARM BLADE CO DRIVER NRW RHD(B	TATA spare parts
585882400136	ASSY WIPER SYSTEM 12V NRW RHD	TATA spare parts
585882400140	ASSY WIPER BLADE DRIVER SIDE WIDE RHD	TATA spare parts
585882400141	ASSY WIPER ARM DRIVER SIDE WIDE RHD	TATA spare parts
585882400142	ASSY WIPER ARM CO DRIVER SIDE WIDE RHD	TATA spare parts
585882400143	WIPERARM ASSY DRIVERSIDE BS6	TATA spare parts
585882400144	WIPERARM ASSY CO-DRIVERSIDE BS6	TATA spare parts
585882406301	WIPER COVER FOR SCISSOR MECHANISM	TATA spare parts
585882406304	WIPER COVER FOR SCISSOR MECHANISM LHD	TATA spare parts
585883100105	ASSY CHEST DUCT_2100 RHD	TATA spare parts
585883100106	ASSY DEFROST_DEMIST DUCT_2100 RHD	TATA spare parts
585883100109	ASSY CHEST DUCT_1800 RHD	TATA spare parts
585883100119	ASSY CHEST DUCT CENTER_2100 RHD	TATA spare parts
585883100120	ASSY CHEST DUCT SIDE_2100 RHD	TATA spare parts
585883100201	ASSY FOOT DUCT-2100 RHD	TATA spare parts
585883100202	ASSY FOOT DUCT-2100 LHD	TATA spare parts
585883103303	BRKT CHEST DUCT CENTER	TATA spare parts
585883300102	ASSY CONTROL-FORCED VENTILATION-12V	TATA spare parts
585883300103	CONTROL ASSY FORCED VENTILATION	TATA spare parts
585883300115	ASSY CONTROL HVAC-ELECTRIC-24V	TATA spare parts
585883300130	ASSY CONTROL ONLY AC-ELECTRIC-12V	TATA spare parts
585883300135	AC CONTROL PANEL ASSY	TATA spare parts
585883300211	ASSY SPLIT HARNESS(CONTROL-HVAC)WIDERRHD	TATA spare parts
585883300216	ASSY SPLIT WIRE HARNESS(CONTROL-FV UNIT)	TATA spare parts
585883400105	ASSY AC COMPRESSOR (RIGHT PORT)	TATA spare parts
585883400110	LIQUID PIPE 1(TXV END)	TATA spare parts
585883400121	SUCTION PIPE 1(TXV END)	TATA spare parts
585883400127	ASSY AC PIPE-LIQUID-FRONT COND	TATA spare parts
585883400129	KIT-AC PIPES-497VP37 ENG	TATA spare parts
585883400140	ASSY AC COMPR (RH PORT)24V-6PK	TATA spare parts
585883400146	ASSY FORCED VENTILATION UNIT RHD WIDER-1	TATA spare parts
585883400147	FORCED VENTILATION UNIT ASSY	TATA spare parts
585883400155	ASSY FV UNIT RHD NRW-12V	TATA spare parts
585883400202	ASSY HVAC UNIT_2100_RHD-24V	TATA spare parts
585883400204	ASSY HVAC UNIT-2100 LHD-24V	TATA spare parts
585883400206	ASSY AC UNIT-WIDER RHD-497 ENG-12V	TATA spare parts
585883400215	AC UNIT ASSY	TATA spare parts
585883400216	AC UNIT ASSY BS6	TATA spare parts
585883400221	ASSY FRONT CONDENSER UNIT-12V	TATA spare parts
585883400222	ASSY FRONT CONDENSER UNIT-24V	TATA spare parts

585883400252	ASSY FRAME BKT-LH	TATA spare parts
585883400253	ASSY FRAME BKT-RH	TATA spare parts
585883403318	CHANNEL BKT	TATA spare parts
585883406001	DRAIN HOSE-CHASSIS END	TATA spare parts
585883407501	GROMMET-TXV CUTOUT	TATA spare parts
585883407502	GROMMET-HEATER CUTOUT	TATA spare parts
585883407503	GROMMET-AC PIPE CUTOUT(NRW)	TATA spare parts
585883407701	FOAM SEAL	TATA spare parts
585883409901	AC REFRIGERANT CHARGE QTY STICKER	TATA spare parts
585883409902	AIR INTAKE ASSY(FRESH/RECIRCULATION)	TATA spare parts
585883409903	AIR INTAKE FILTER (FRESH/RECIRCULATION)	TATA spare parts
585883409905	DISTRIBUTION HOUSING COMPLETE	TATA spare parts
585883409906	HEATER CORE ASSLY	TATA spare parts
585883409907	HEATER COVER	TATA spare parts
585883409908	EVAPORATOR ASSY COMPLETE	TATA spare parts
585883409909	EVAPORATOR ASSY	TATA spare parts
585883409910	THERMAL EXPANSION VALVE	TATA spare parts
585883409911	FACE- DEFROST DUCT	TATA spare parts
585883409912	DRAIN HOSE-HVAC SIDE	TATA spare parts
585883409913	SEALING SET COMPLETE	TATA spare parts
585883409914	MOUNTING BRACKET SET COMPLETE	TATA spare parts
585883409915	HEATER PIPE LOCATING BRACKET	TATA spare parts
585883409916	BLOWER AND AI ASSY COMPLETE_FV_RHD_12V	TATA spare parts
585883409917	DISTRIBUTION HOUSING COMPLETE_NRW_FV	TATA spare parts
585883409918	SEALING SET COMPLETE_NRW	TATA spare parts
585883409919	MOUNTING BRACKET SET COMPLETE_NRW	TATA spare parts
585883409920	FORCED VENTILATION- WIRE HARNESS_NRW	TATA spare parts
585883409921	AIR INTAKE CONNECTING DUCT	TATA spare parts
585883409922	ACTUATOR MOTOR(FEEDBACK TYPE)	TATA spare parts
585883409923	BLOWER(MOTOR HOLDER)ASSY COMPLETE	TATA spare parts
585883409924	RESISTOR (PLATE TYPE)	TATA spare parts
585883409925	AC- WIRE HARNESS	TATA spare parts
585883409926	PRESSURE SWITCH	TATA spare parts
585883409927	BLOWER AND AIR INTAKE ASSY	TATA spare parts
585883409930	RESISTOR (PLATE TYPE)_24V	TATA spare parts
585883409932	DISTRIBUTION HOUSING COMPLETE	TATA spare parts
585883409933	SEALING SET COMPLETE	TATA spare parts
585883409934	HVAC-WIRE HARNESS	TATA spare parts
585883409935	BLOWER ASSY WITH MOTOR FV_RHD_12V	TATA spare parts
585883409937	CONTROL PANEL BODY	TATA spare parts
585883409938	SET-O-RING FOR TXV	TATA spare parts
585883409939	AIR INTAKE ASSY AND SCROLL ASSY	TATA spare parts
585883409940	BLOWER ASSY	TATA spare parts
585883409941	BLOWER ASSY	TATA spare parts
585883409943	MOTOR HOLDER ASSY	TATA spare parts
585883409944	BLOWER SCROLL ASSY	TATA spare parts
585883409945	SET-MOTOR ASSY WITH HOLDER & SCROLL ASSY	TATA spare parts

585883409946	AIR INTAKE ASSY	TATA spare parts
585883409947	SET-MOTOR ASSY WITH HOLDER & SCROLL ASSY	TATA spare parts
585883409948	AIR INTAKE ASSY (FRESH/RECIRCULATION)24V	TATA spare parts
585883409949	BLOWER AND AIR INTAKE ASSY 24V	TATA spare parts
585883409950	BLOWER (MOTOR HOLDER) ASSY COMPLETE 24V	TATA spare parts
585883409951	ACTUATOR MOTOR (FEEDBACK TYPE) 24V	TATA spare parts
585883409952	RESISTOR ASSY (PLATE TYPE)24V	TATA spare parts
585883409953	DISTRIBUTION HSG COMPLETE 24V	TATA spare parts
585883409954	POLLEN FILTER LH	TATA spare parts
585883409955	KIT-CLUTCH AC COMPRESSOR BS6	TATA spare parts
585883409956	KIT-CLUTCH AC COMPRESSOR BS6	TATA spare parts
585883409957	ACTUATOR MOTOR ASSY BS6	TATA spare parts
585883409958	DISTRIBUTION HSG COMPLETE 24V BS6	TATA spare parts
585883409959	ACTUATOR&MOTOR&ASSY	TATA spare parts
585883409972	AIR&INTAKE&ASSY	TATA spare parts
585883409973	AIR INTAKE FILTER	TATA spare parts
585883409974	BLOWER&&AIR&INTAKE&ASSY	TATA spare parts
585883409975	BLOWER&MOTOR&ASSY	TATA spare parts
585883409976	DUCT AIR&INLET	TATA spare parts
585883409977	DISTRIBUTION&HSG&ASSY	TATA spare parts
585883409981	EVAPORATOR&ASSY	TATA spare parts
585883409982	EVAPORATOR&ASSY	TATA spare parts
585883409983	WIREHARNES BS6	TATA spare parts
585883409984	SET-O-RING TXV	TATA spare parts
585883409986	FACE&DEFROST&DUCT&&PLATE&ASSY	TATA spare parts
585883409987	DRAIN&HOSE HVAC	TATA spare parts
585883409988	SEALING HEATER&PIPE	TATA spare parts
585883409989	SEALING	TATA spare parts
585883409990	SEALING TXV&FIREWALL	TATA spare parts
585883409991	SEALING FACE&DUCT	TATA spare parts
585883409992	SEALING DEFROST&DUCT	TATA spare parts
585883409995	BRACKET FIREWALL&MTG	TATA spare parts
585883409996	BRACKET&ASSY HVAC&MTG BOTTOM	TATA spare parts
585883409997	BRACKET&ASSY HVAC&MTG TOP	TATA spare parts
585883419901	WIRING&HARNES&ASSY HVAC	TATA spare parts
585883419903	HEATER&CORE&ASSY	TATA spare parts
585883419907	BRACKET HEATER&PIPE&MTG	TATA spare parts
585883419920	DUCTHOUSINGCOMPLETE BS6	TATA spare parts
585883419921	DISTRIBUTION HSG ASSY BS6	TATA spare parts
585883419922	BLOWER ASSY	TATA spare parts
585883419923	BLOWER MOTOR ASSY	TATA spare parts
585883419924	SET-MOUNTING BRACKET BS6	TATA spare parts
585883419925	SEALINGSETCOMPLETE BS6	TATA spare parts
585883419927	MOTOR HOLDER ASSY BS6	TATA spare parts
585883419928	BLOWER ASSY	TATA spare parts
585883419946	AIRINTAKEASSY(FRESH/RECIRCULATION) BS6	TATA spare parts
585883419947	DISTRIBUTIONHOUSINGCOMPLETE BS6	TATA spare parts

585883419948	BLOWERCOMPLETEASSY BS6	TATA spare parts
585883419949	MOUNTINGBRACKETSETCOMPLETE BS6	TATA spare parts
585883419950	AIRINTAKEASSY BS6	TATA spare parts
585883450108	BRACKET ASSY CONDENSER FRAME MTG LH	TATA spare parts
585883450109	BRACKET ASSY CONDENSER FRAME MTG RH	TATA spare parts
585883450110	BRACKET ASSY CONDENSER MTG BOTTOM-RH BS6	TATA spare parts
585883450115	BRACKET ASSY CONDENSER MTG	TATA spare parts
585883450116	BRACKET ASSY CONDENSER FRAME MTG TOP-RH	TATA spare parts
585883450117	BRACKET ASSY CONDENSER FRAME MTG TOP-LH	TATA spare parts
585883450118	BRACKET ASSY CONDENSER MTG BOTTOM-LH BS6	TATA spare parts
585883450119	BRACKET ASSY CONDENSER MTG BOTTOM-RH	TATA spare parts
585883450120	BRACKET ASSY CONDENSER MTG BOTTOM-LH	TATA spare parts
585883450121	BRACKET ASSY CONDENSER MTG TOP	TATA spare parts
585883453314	CHANNEL BRACKET	TATA spare parts
585883459901	CONDENSER	TATA spare parts
585883459902	FAN SHROUD ASSY	TATA spare parts
585883459903	BUFFER & SLEEVE	TATA spare parts
585883459904	FAN SHROUD ASSY	TATA spare parts
585883500130	ASSY. AIR COMPRESSOR 24V-6PK(S1) BS3/4	TATA spare parts
585883500136	CLUTCH PULLEY ASSY	TATA spare parts
585883500145	ASSY AC COMP-MSC240-12V-6PK(S2P)	TATA spare parts
585883550103	KIT-AC PIPES-3L ENG-8T-LHD RUSSIA	TATA spare parts
585883550104	AC COMPRESSOR ASSY	TATA spare parts
585883550105	AC COMPRESSOR ASSY	TATA spare parts
585883550106	AC COMPRESSOR ASSY BS6	TATA spare parts
585883550108	COMPRESSOR ASSY BS6	TATA spare parts
585883550109	COMPRESSOR ASSY BS6	TATA spare parts
585883550205	ASSLY SUCTION HOSE PIPE 2-3L LHD	TATA spare parts
585883550206	ASSLY SUCTION HOSE 3 (COMP END)-3L LHD	TATA spare parts
585883550207	ASSLY DISCHARGE PIPE 1(COND END)-3L LHD	TATA spare parts
585883550208	ASSLY DISCHARGE HOSE 2 (COMP END)-3L LHD	TATA spare parts
585883554902	CLUTCH COIL AC COMPRESSOR	TATA spare parts
585883557003	PULLEY	TATA spare parts
585883557101	ARMATURE	TATA spare parts
585883600101	ASSLY MTG.BRKT-AC PIPING(MIDDLE)	TATA spare parts
585883600102	ASSLY MTG.BRKT-AC PIPING(UNDERBODY)	TATA spare parts
585883600105	BRACKET ASSY AC PIPE MTG	TATA spare parts
585883600106	BRACKET ASSY HEATER PIPE MTG	TATA spare parts
585883600124	DISCHARGE PIPE CONDENSER END	TATA spare parts
585883600125	LIQUID PIPE CONDENSER END	TATA spare parts
585883600126	SUCTION PIPE COMPRESSOR END	TATA spare parts
585883600127	DISCHARGE PIPE COMPRESSOR END	TATA spare parts
585883600128	LIQUID PIPE HVAC END	TATA spare parts
585883600129	SUCTION PIPE HVAC END	TATA spare parts
585883600130	SUCTION PIPE MIDDLE BS6	TATA spare parts
585883600131	DISCHARGE PIPE CONDENSER END BS6	TATA spare parts
585883600133	SUCTION PIPE COMPRESSOR END BS6	TATA spare parts

585883600134	DISCHARGE PIPE COMPRESSOR END BS6	TATA spare parts
585883606901	SUCTION HOSE ASSY COMPRESSOR END BS6	TATA spare parts
585883606902	DISCHARGE HOSE ASSY COMPRESSOR OUTLET¿BS	TATA spare parts
585883606908	SUCTION PIPE ASSY	TATA spare parts
585883606909	LIQUID PIPE ASSY	TATA spare parts
585883606910	LIQUID PIPE ASSY FRONT CONDENSER	TATA spare parts
585883606911	SUCTION PIPE MIDDLE	TATA spare parts
585883606912	SUCTION PIPE COMPRESSOR END	TATA spare parts
585883606913	DISCHARGE HOSE ASSY COMPRESSOR	TATA spare parts
585883606914	DISCHARGE PIPE CONDENSER END	TATA spare parts
585883650105	KIT-HEATER HOSES-3L ENG	TATA spare parts
585883650116	HEATER HOSE ASSY ENGINE TO HVAC	TATA spare parts
585883650117	HEATER HOSE ASSY HVAC TO ENGINE	TATA spare parts
585883650118	BRACKET ASSY HEATER HOSE MTG	TATA spare parts
585883650204	BRACKET ASSY AC PIPE MTG	TATA spare parts
585883650205	ASSLY BRKT UNDERBODY LH_1	TATA spare parts
585883650206	ASSLY BRKT UNDERBODY LH_2	TATA spare parts
585883650207	ASSLY BRKT FOR HEATER HOSE	TATA spare parts
585883653301	BRACKET AC PIPE MTG	TATA spare parts
585883680110	ASSY GRILLE-ROOF HATCH	TATA spare parts
585883688002	CONTROL KNOB-ROOF HATCH	TATA spare parts
585883688003	SLIDER KNOB-ROOF HATCH	TATA spare parts
585883708201	COVER PLATE BS6	TATA spare parts
585883750101	BRACKET ASSY AC PIPE MTG	TATA spare parts
585883750103	BRACKET ASSY AC PIPE MTG	TATA spare parts
585883750108	BRACKET ASSY AC PIPE MTG	TATA spare parts
585883753303	BRACKET AC PIPE MTG LH BS6	TATA spare parts
585883800104	AIR EXTRACTOR ASSY REAR	TATA spare parts
585883800201	ASSY AIR INTAKE GRILLE	TATA spare parts
585883803301	BRACKET AIR INTAKE GRILLE MTG	TATA spare parts
585883803302	BRACKET AIR INTAKE GRILLE MTG	TATA spare parts
585883803303	BRACKET AIR INTAKE GRILLE MTG	TATA spare parts
585883803304	BRACKET AIR INTAKE GRILLE MTG	TATA spare parts
585883807501	BODY AIR INTAKE GRILLE	TATA spare parts
585883807502	RUBBER PACKING FOR GRILLE	TATA spare parts
585883807520	WIRE MESH-AIR INTAKE GRILLE	TATA spare parts
585883807523	FRESH-AIR GRILLE_SHEET METAL_NARROW-RHD	TATA spare parts
585888100103	ASSY STRUCTURE FENDER FRONT LH	TATA spare parts
585888100104	ASSY STRUCTURE FENDER FRONT RH	TATA spare parts
585888100113	ASSY FRONT FENDER LH	TATA spare parts
585888100114	ASSY FRONT FENDER RH	TATA spare parts
585888100117	ASSY SUPPORT BRKT NOISE COVER LH TOP	TATA spare parts
585888100121	ASSY BRKT FRAME NOISE COVER	TATA spare parts
585888100127	ASSY SUPPORT BRKT NOISE COVER RH TOP	TATA spare parts
585888100137	AIR EXTRACTOR VALVE ASSY	TATA spare parts
585888100138	AIR EXTRACTOR VALVE ASSY BS6	TATA spare parts
585888100163	ASSY NOISE COVER LH	TATA spare parts

585888100164	ASSY NOISE COVER RH	TATA spare parts
585888100167	ASSEMBLY FENDER PHASE II-LH	TATA spare parts
585888100168	ASSEMBLY FENDER PHASE II-RH	TATA spare parts
585888100181	ASSY FRONT FENDER (PHASE II) ULTRA+ LH	TATA spare parts
585888100182	ASSY FRONT FENDER (PHASE II) ULTRA+ RH	TATA spare parts
585888100185	ASSY BRACKET FRONT FENDER LH ULTRA+	TATA spare parts
585888100186	ASSY BRACKET FRONT FENDER RH ULTRA+	TATA spare parts
585888100189	FOOTSTEP SUPPORT ASSY LH	TATA spare parts
585888100190	FOOTSTEP SUPPORT ASSY RH	TATA spare parts
585888100193	ASSEMBLY FOOR STEP STRUCTURE-LH	TATA spare parts
585888100194	ASSEMBLY FOOR STEP STRUCTURE-RH	TATA spare parts
585888100203	FOOT STEP SUPPORT ASSY LH	TATA spare parts
585888100204	FOOT STEP SUPPORT ASSY RH	TATA spare parts
585888103312	FRONT FENDER MTG BRT LH	TATA spare parts
585888103313	FRONT FENDER MTG BRT RH	TATA spare parts
585888103320	SUPPORT BRKT NOISE COVER BOTTOM	TATA spare parts
585888106326	NOISE COVER CARRIER LH ULTRA+	TATA spare parts
585888106327	NOISE COVER CARRIER RH ULTRA+	TATA spare parts
585888106332	NOISE COVER CARRIER LH NRW	TATA spare parts
585888106333	NOISE COVER CARRIER RH NRW	TATA spare parts
585888106350	NOISE COVER LH BS6	TATA spare parts
585888106351	NOISE COVER RH BS6	TATA spare parts
585888200101	PIPE ASSY FENDER REAR-LH BS6	TATA spare parts
585888200102	PIPE ASSY FENDER REAR-RH BS6	TATA spare parts
585888200109	ASSY REAR FENDER REINF BRACKET LH	TATA spare parts
585888200110	ASSY REAR FENDER REINF BRACKET RH	TATA spare parts
585888200111	ASSY MIDDLE FENDER WIDE LH	TATA spare parts
585888200112	ASSY MIDDLE FENDER WIDE RH	TATA spare parts
585888200114	PIPE ASSY FENDER REAR W/ BBRACKET RH BS6	TATA spare parts
585888200120	ASSY BRT REAR FENDER MTG UPPER LH	TATA spare parts
585888200121	ASSY BRT REAR FENDER MTG UPPER RH	TATA spare parts
585888200122	ASSY PIPE REAR FENDER MTG LOWER LH	TATA spare parts
585888200123	ASSY PIPE REAR FENDER MTG LOWER RH	TATA spare parts
585888200124	ASSY REAR FENDER REINF BRACKET OUTER LH	TATA spare parts
585888200126	ASSY REAR FENDER REINF BRACKET OUTER RH	TATA spare parts
585888200128	ASSY MUDGARD LINER LH	TATA spare parts
585888200129	ASSY MUDGARD LINER RH	TATA spare parts
585888200133	ASSY BRKT REAR ENGINE COVER LH	TATA spare parts
585888200134	ASSY BRKT REAR ENGINE COVER RH	TATA spare parts
585888200154	ASSY REAR ENGINE COVER WITH INSULATION	TATA spare parts
585888200156	ASSY BRKT MTG ADD ON RR FENDER UPR LH	TATA spare parts
585888200157	ASSY BRKT MTG ADD ON RR FENDER UPR RH	TATA spare parts
585888200158	ASSY BRKT MTG ADD ON RR FENDER LWR LH	TATA spare parts
585888200159	ASSY BRKT MTG ADD ON RR FENDER LWR RH	TATA spare parts
585888200175	MUDGUARD LINER ASSY LH	TATA spare parts
585888200176	MUDGUARD LINER ASSY RH	TATA spare parts
585888200181	ASSY REAR FENDER MTG UPPER LH WIDE (LHD)	TATA spare parts



585888200182	ASSY REAR FENDER MTG UPPER RH WIDE (LHD)	TATA spare parts
585888200202	ASSY MIDDLE FENDER LH (ULTRA+)	TATA spare parts
585888200203	ASSY MIDDLE FENDER RH (ULTRA+)	TATA spare parts
585888200221	MIDDLE FENDER ASSY LH	TATA spare parts
585888200222	MIDDLE FENDER ASSY RH	TATA spare parts
585888200228	ENGINE COVER ASSY WITH INSULATION REAR B	TATA spare parts
585888203390	BRACKET MIDDLE FENDER SUPPORT LH	TATA spare parts
585888203391	BRACKET MIDDLE FENDER SUPPORT RH	TATA spare parts
585888206301	REAR FENDER LH&BS6	TATA spare parts
585888206302	REAR FENDER RH&BS6	TATA spare parts
585888206303	SPRAY SUPPRESSION REAR FENDER LH&BS6	TATA spare parts
585888206304	SPRAY SUPPRESSION REAR FENDER RH&BS6	TATA spare parts
585888206307	FENDER REAR LH	TATA spare parts
585888206308	FENDER REAR RH	TATA spare parts
585888206330	REAR FENDER LINER LH	TATA spare parts
585888206331	REAR FENDER LINER RH	TATA spare parts
585888206352	MUD FLAP SPRAY SUPPRESSION RR FNDR LH(ABO)	TATA spare parts
585888206353	MUD FLAP SPRAY SUPPRESSION RR FNDR RH(ABO)	TATA spare parts
585888206354	MUD FLAP SPRAY SUPPRESSION RR FNDR LH	TATA spare parts
585888206355	MUD FLAP SPRAY SUPPRESSION RR FNDR RH	TATA spare parts
585888206362	REAR FENDER LINER LH NARROW	TATA spare parts
585888206363	REAR FENDER LINER RH NARROW	TATA spare parts
585888206376	FENDER REAR LH (LHD) WIDE	TATA spare parts
585888206377	FENDER REAR RH (LHD) WIDE	TATA spare parts
585888206394	MUD FLAP SPRAY SUPPRESSION RR FNDR LH(U+)	TATA spare parts
585888206395	MUD FLAP SPRAY SUPPRESSION RR FNDR RH(U+)	TATA spare parts
585888206396	FENDER REAR LH ULTRA+	TATA spare parts
585888210102	ASSY PIPE RR FDR MTG UPR LWR LH(ULTRA+)	TATA spare parts
585888210103	ASSY PIPE RR FDR MTG UPR LWR RH(ULTRA+)	TATA spare parts
585888210113	BRACKET ASSY REAR FENDER SUPPORT ULTRA+	TATA spare parts
585888210114	PIPE ASSY REAR FENDER MTG LH	TATA spare parts
585888210116	PIPE ASSY REAR FENDER MTG RH	TATA spare parts
585888210117	FENDER STRUCTURE ASSY BOTTOM-LH	TATA spare parts
585888210118	FENDER STRUCTURE ASSY BOTTOM-RH	TATA spare parts
585888210119	REAR FENDER ASSY MTG TOP-LH	TATA spare parts
585888210120	REAR FENDER ASSY MTG TOP-RH	TATA spare parts
585888210122	PIPEASSYFENDERREAR-LH	TATA spare parts
585888210124	PIPE ASSY FENDER REAR-RH	TATA spare parts
585888210128	PIPEASSYFENDERREAR-RH	TATA spare parts
585888216301	REAR ENGINE COVER NRW	TATA spare parts
585888216304	MUDFLAP FRONT LINER LH (NRW)	TATA spare parts
585888216305	MUDFLAP FRONT LINER RH (NRW)	TATA spare parts
585888216306	ENGINE COVER REAR (ULTRA+)	TATA spare parts
585888216307	REAR FENDER RH ULTRA+	TATA spare parts
585888216308	MUDFLAP FRONT LINER LH	TATA spare parts
585888216309	MUDFLAP FRONT LINER RH	TATA spare parts
585888216310	"REAR FENDER,LH"	TATA spare parts

585888216311	"REAR FENDER,RH"	TATA spare parts
585888216314	ENGINE COVER	TATA spare parts
585888216326	MIDDLE FENDER LHBS6	TATA spare parts
585888216327	MIDDLE FENDER RHBS6	TATA spare parts
585888300103	ASSY FOOT BOARD BUMPER LH	TATA spare parts
585888300104	ASSY FOOT BOARD BUMPER RH	TATA spare parts
585888300105	ASSY FOOT BOARD FENDER LH	TATA spare parts
585888300106	ASSY FOOT BOARD FENDER RH	TATA spare parts
585888300107	ASSY FOOT BOARD FENDER LH	TATA spare parts
585888300108	ASSY FOOT BOARD FENDER RH	TATA spare parts
585888300109	ASSY FOOT BOARD FENDER (PHASE II) LH	TATA spare parts
585888300110	ASSY FOOT BOARD FENDER (PHASE II) RH	TATA spare parts
585888306305	CAP SCREW FOOTBOARD BUMPER LH	TATA spare parts
585888306306	CAP SCREW FOOTBOARD BUMPER RH	TATA spare parts
585888400104	HINGE ASSY BONNET	TATA spare parts
585888400129	ASSY BRKT SUPPORT HINGE FIREWALL	TATA spare parts
585888400134	ASSY BRKT SUPPORT SIDE MTG LH	TATA spare parts
585888400135	ASSY BRKT SUPPORT SIDE MTG RH	TATA spare parts
585888400136	ASSY. PANEL FRONT INNER WIDE BS3/4/6	TATA spare parts
585888400138	ASSY PANEL FRONT WIDE COMPL WITH HINGE	TATA spare parts
58588840013835	ASSY. PANEL FRT WIDE COMP. CED BS3/4	TATA spare parts
585888400143	ASSY LATCH FRONT PANEL SELF CENTERING	TATA spare parts
585888400144	ASSY STRIKER LATCH FRONT PANEL SELF CENT	TATA spare parts
585888400145	ASSY HINGE FRONT PANEL	TATA spare parts
585888400146	ASSY STOPPER FRONT PANEL	TATA spare parts
585888400161	ASSY. PANEL FRONT INNER NRW	TATA spare parts
585888400162	ASSY PANEL FRONT NRW	TATA spare parts
585888400195	PANEL ASSY FRONT WIDE	TATA spare parts
58588840030135	CED-ASSY PANEL FRONT WITH HARDWARE(BIW)	TATA spare parts
585888406304	HEAD LAMP SEAL LH	TATA spare parts
585888406305	HEAD LAMP SEAL RH	TATA spare parts
585888406306	DUMMY HEAD LAMP SEAL LH	TATA spare parts
585888406307	DUMMY HEAD LAMP SEAL RH	TATA spare parts
585888406704	LOCATOR PIN BS6-PH2	TATA spare parts
585888408203	PANEL FRONT OUTER WIDE	TATA spare parts
585888408205	PANEL FRONT INNER WIDE	TATA spare parts
585888408208	PANEL FRONT OUTER NARROW	TATA spare parts
585888408211	FRONT PANEL MTG BRKT SIDE LH	TATA spare parts
585888408212	FRONT PANEL MTG BRKT SIDE RH	TATA spare parts
585888408257	SPACER SIDE MTG FRONT PANEL	TATA spare parts
585888418201	C - FRAME FOR TATA PANEL MTG NARROW BS6	TATA spare parts
585888418214	BRACKET FRONT PANEL MTG LH BS6	TATA spare parts
585888418215	BRACKET FRONT PANEL MTG RH BS6	TATA spare parts
585888418225	PANEL FRONT OUTER	TATA spare parts
585888500123	ASSY FOOT STEP MTG BRCKET (FUPD) LH	TATA spare parts
585888500124	ASSY FOOT STEP MTG BRCKET (FUPD) RH	TATA spare parts
585888500125	ASSY BUMPER MTG BRKT ON FUPD LH	TATA spare parts

585888500126	ASSY BUMPER MTG BRKT ON FUPD RH	TATA spare parts
585888500127	ASSY FOOT STEP MTG BRKT (WITHOUT FUPD) L	TATA spare parts
585888500128	ASSY FOOT STEP MTG BRKT (WITHOUT FUPD) R	TATA spare parts
585888500129	ASSY BUMPER CROSS MEMBER MTG BRKT LH	TATA spare parts
585888500130	ASSY BUMPER CROSS MEMBER MTG BRKT RH	TATA spare parts
585888500131	ASSY BUMPER CHASSIS MTG BRKT	TATA spare parts
585888500132	ASSY COVER FOG LAMP LH	TATA spare parts
585888500133	ASSY COVER FOG LAMP RH	TATA spare parts
585888500141	ASSY ACCESS COVER AND GAP COVER	TATA spare parts
585888500144	ASSY. BUMPER WIDE WITH FL MTG BKT BS3/4	TATA spare parts
585888500145	ASSY COVER WITHOUT FOGLAMP LH	TATA spare parts
585888500146	ASSY COVER WITHOUT FOGLAMP RH	TATA spare parts
585888500147	ASSY FOG LAMP MTG BKT LH BS6	TATA spare parts
585888500148	ASSY FOG LAMP MTG BKT RH BS6	TATA spare parts
585888500168	BUMPER ASSY WITH HARDWARE NARROW	TATA spare parts
585888500173	CORNER BUMPER ASSY LH NRW	TATA spare parts
585888500174	CORNER BUMPER ASSY RH NRW	TATA spare parts
585888500181	BRACKET ASSY SUPPORT FOOTSTEP LH NRW	TATA spare parts
585888500182	BRACKET ASSY SUPPORT FOOTSTEP RH NRW	TATA spare parts
585888500183	BUMPER ASSY MIDDLE NRW	TATA spare parts
585888500187	BUMPER ASSY MIDDLE ULTRA+	TATA spare parts
585888500189	BRACKET ASSY CHASSIS TO BUMPER MTG	TATA spare parts
585888500191	BRACKET ASSY CENTRE BUMPER MTG TOP	TATA spare parts
585888500192	BRACKET ASSY FOOTSTEP SUPPORT ULTRA15.3T	TATA spare parts
585888500193	HEADLAMP ACCESS COVER ASSY BUMPER LH NRW	TATA spare parts
585888500194	HEADLAMP ACCESS COVER ASSY BUMPER RH NRW	TATA spare parts
585888500195	BRACKET ASSY CORNER BUMPER MTG LH ULTRA	TATA spare parts
585888500196	BRACKET ASSY CORNER BUMPER MTG RH ULTRA	TATA spare parts
585888500199	BRACKET ASSY FOOTSTEP SUPPORT ULTRA 13.5	TATA spare parts
585888500201	BRACKET ASSY CHASSIS MTG NRW	TATA spare parts
585888500208	BRACKET ASSY BUMPER FRONT MTG RH BS6	TATA spare parts
585888500209	BRACKET ASSY FRONT BUMPER RH BS6	TATA spare parts
585888503349	BUMPER GAP COVER SIDE MTG BRT LH	TATA spare parts
585888503350	BUMPER GAP COVER SIDE MTG BRT RH	TATA spare parts
585888503351	BUMPER GAP COVER MTG BRT CENTER	TATA spare parts
585888506306	BUMPERSKINWIDE BS6	TATA spare parts
585888506317	GAP HIDER BUMPER SIDE LH	TATA spare parts
585888506318	GAP HIDER BUMPER SIDE RH	TATA spare parts
585888506331	GAP HIDER STEEL BUMPER NRW	TATA spare parts
585888508001	SCREW FL BTN HD M8X20	TATA spare parts
585888510142	BUMPER ASSY MIDDLE	TATA spare parts
585888510143	SPACER ASSY BS6	TATA spare parts
585888705301	FOAM BS6	TATA spare parts
585888706305	ENGINE INSULATION WIDE	TATA spare parts
585888706306	ENGINE INSULATION NARROW	TATA spare parts
585888706310	ENGINE INSULATION SL	TATA spare parts
585888800101	TRUST BAR ASSY	TATA spare parts

585889100101	ASSY. CROSS TUBE COMP. BS3/4/6	TATA spare parts
585889100102	ASSY CAB MTG REAR	TATA spare parts
585889100105	ASSY_CROSS_TUBE_MTG_BRACKET BS6	TATA spare parts
585889100107	ASSY CONNECTING LINK RH	TATA spare parts
585889100111	ASSY HANDLE MTG BKT	TATA spare parts
585889100112	ASSY CONNECTING LINK NRW	TATA spare parts
585889100120	ASSY_REAR_LOCKING_KIT_UPPER	TATA spare parts
585889100121	ASSYHOUSING(REARLOCK) BS6	TATA spare parts
585889100122	ASSY. INTERMEDIATE LINK	TATA spare parts
585889100126	ASSY BRACKET UPPER	TATA spare parts
585889100130	ASSY FRT MTG SHEET METAL LH 850X200	TATA spare parts
585889100133	ASSY FRT MTG SHEET METAL RH	TATA spare parts
585889100137	ASSY CAB MTG REAR LH NRW	TATA spare parts
585889100139	ASSY CAB MTG REAR RH NRW	TATA spare parts
585889100177	ASSY HOOK REAR MTG	TATA spare parts
585889100178	ASSY TILT CYL MTG BRKT BOTTOM	TATA spare parts
585889100183	BRACKET ASSY HANDLE MTG	TATA spare parts
585889100187	ASSY CYLINDER MTG TOP	TATA spare parts
585889100197	HYD CYLINDER CAB TILTING	TATA spare parts
585889100198	HYD PUMP FOR CAB TILTING	TATA spare parts
585889100199	ASSY BKT PUMP MTG	TATA spare parts
585889100202	ASSY HANDLE MTG BKT LHD	TATA spare parts
585889100211	SECONDARYHOOKASSYCOMPLETENRW BS6	TATA spare parts
585889100213	ASSY HOSE PUSH LINE CONNECTOR	TATA spare parts
585889100214	ASSY HOSE PULL LINE CONNECTOR	TATA spare parts
585889100215	BRACKET ASSY PUMP MTG RH	TATA spare parts
585889100217	ASSY HYD CYLINDER CAB TILTING LHD	TATA spare parts
585889100218	PUMP ASSY HYD CAB TILT	TATA spare parts
585889100221	ASSY HANDLE MTG BKT LHD	TATA spare parts
585889100223	ASSY TILT CYL MTG BRKT BOTTOM RH	TATA spare parts
585889100226	ASSY_REAR_LOCKING_KIT_UPPER_LHD	TATA spare parts
585889100228	ASSY CYLINDER MTG TOP LHD	TATA spare parts
585889100229	ASSY CAM (CAB LOCKING MECHANISM)	TATA spare parts
585889100259	ASSY REAR PLATE AND CUP NRW	TATA spare parts
585889100261	ASSY PLATE BUSH MTG REAR	TATA spare parts
585889100263	ASSY BRACKET DIRTY SIDE DUCT 3L ENG	TATA spare parts
585889100268	ASSY CAB MTG BKT REAR ULTRA PLUS	TATA spare parts
585889100275	ASSY CYLINDER MTG TOP ULTRA PLUS RHD	TATA spare parts
585889100283	BRACKET ASSY DIRTY SIDE 497 CR ENG BS6	TATA spare parts
585889100284	BUSH ASSY FRONT CAB MTG	TATA spare parts
585889100288	CROSS TUBE ASSY COMPLETE NRW	TATA spare parts
585889100292	HANDLE MTG ASSY NRW	TATA spare parts
585889100310	FRONTMTGASSY LH BS6	TATA spare parts
585889100311	FRONTMTGASSY RH BS6	TATA spare parts
585889100312	FRONT MTG ASSY LH	TATA spare parts
585889100313	FRONT MTG ASSY RH	TATA spare parts
585889100320	BRACKET ASSY CAB MTG REAR-LH	TATA spare parts

585889100321	BRACKET ASSY CAB MTG REAR-RH	TATA spare parts
585889100325	BRACKET ASSY CAB TILT CYLINDER MTGçBS6	TATA spare parts
585889103365	REINF FENDER MTG UPPER	TATA spare parts
585889103381	REINF FENDER MTG UPPER RH	TATA spare parts
585889103401	SERRATEDBUSH BS6	TATA spare parts
585889103403	BUSHREARHOOKPIVOT BS6	TATA spare parts
585889103409	BUSH SECONDARY LOCK	TATA spare parts
585889103411	SPACER BUSH BS6-PH2	TATA spare parts
585889103412	NYLON BUSH HOOK PIVOT	TATA spare parts
585889103414	SLEEVE HOOK SPRING	TATA spare parts
585889103417	BUSH CYLINDER TOP END	TATA spare parts
585889103711	ADJUSTER	TATA spare parts
585889106004	CONNECTING LINK	TATA spare parts
585889106724	PIVOT PIN REAR LOCK HOOK	TATA spare parts
585889106727	PIVOT PIN	TATA spare parts
585889106731	TOP END PIN	TATA spare parts
585889106742	PIN DAMPER & SHOCK ABSORBER MTG	TATA spare parts
585889106812	M14_HOSE CONNECTOR_PRICOL BS6	TATA spare parts
585889106925	BUSH CROSS TUBE	TATA spare parts
585889106941	SLEEVE BUSH REAR	TATA spare parts
585889106950	CROSTUBE BS6	TATA spare parts
585889106951	SLEEVE BS6	TATA spare parts
585889106955	WASHER PLATE	TATA spare parts
585889107101	HOOKREARLOCK BS6	TATA spare parts
585889107904	TORSION BAR NARROW RHD	TATA spare parts
585889108002	SPECIAL ADJUSTER BOLT	TATA spare parts
585889108205	CONNECTOR	TATA spare parts
585889108613	SPACER REAR CAB MTG ULTRA PLUS	TATA spare parts
585889108703	SPRING HANDLE LEVER	TATA spare parts
585889108706	HOOK SPRING REAR LOCKING	TATA spare parts
585889109203	SPACER BS6	TATA spare parts
585889110116	BRACKETASSY BS6	TATA spare parts
585889110120	LEVER ASSY BS6	TATA spare parts
585889110121	RUB BUSH FRONT MTG BS6	TATA spare parts
585889110136	BRACKET ASSY UPPER BS6-PH2	TATA spare parts
585889110162	BUSH FRONT BS6-PH2	TATA spare parts
585889110163	BUSH REAR BS6-PH2	TATA spare parts
585889113304	BRACKET HOSE MTG CLAMP	TATA spare parts
585889113312	BRACKET FRONTCABMTG LH BS6	TATA spare parts
585889113313	BRACKET FRONTCABMTG RH BS6	TATA spare parts
585889117177	STOPPERTORSIONBAR BS6	TATA spare parts
585889118201	SHIM BS6	TATA spare parts
585889127114	ADJUSTER BS6-PH2	TATA spare parts
585889200107	HOSE ASSY PUSH LINE	TATA spare parts
585889200108	HOSE ASSY PULL LINE	TATA spare parts
585889200115	SUPPORT ASSY CYLINDER MTG BKT BOTTOM BS6	TATA spare parts
585889209902	STICKER CAB TILTING INSTRUCTIONS	TATA spare parts

585889300104	ASSYBKTCABSTAYNARROW BS6	TATA spare parts
585889300105	ASSY CAB STAY NARROW	TATA spare parts
585889300106	ASSY STAY MTG BKT BODY SIDE BS6	TATA spare parts
585889300109	CAMASSYCABLOCKINGMECHANISM BS6	TATA spare parts
585889300112	BRACKET ASSY UPPER	TATA spare parts
585889300114	CAB STAY ASSY BS6-PH2	TATA spare parts
585891000102	DRIVER SEAT COMP. HIGH VER. RHD BS3/4/6	TATA spare parts
585891000106	DRIVER SEAT COMPLETE LOW VERSION RHD	TATA spare parts
585891000107	ASSY DRIVER SEAT WIDE LHD EXPORT	TATA spare parts
585891000113	ASSY KIT BACK DRIVER SEAT COMPLETE	TATA spare parts
585891000114	FEET COVER DRIVER SEAT	TATA spare parts
585891000115	RECLINER LEVER PLASTIC	TATA spare parts
585891000122	ASSY KIT CUSHION DRIVER SEAT COMPLETE	TATA spare parts
585891000125	ASSY RECLINER COVER OB	TATA spare parts
585891000126	TRACK COVER FOR SUSPENSION SEAT RH	TATA spare parts
585891000127	RELEASE LEVER HANDLE	TATA spare parts
585891000128	ASSY KIT HANDWHEEL	TATA spare parts
585891000129	ASSY KIT CABLE	TATA spare parts
585891000130	ASSY DRIVER SEAT WIDE LHD EXPORT COLD	TATA spare parts
585891000132	ASSY DRIVER SEAT BASE NARROW RHD	TATA spare parts
585891000137	ASSY SUSPENSION KIT	TATA spare parts
585891000138	ASSY SUSPENSION KIT	TATA spare parts
585891000154	DRIVER SEAT ASSY	TATA spare parts
585891000155	DRIVER SEAT ASSY BS6-PH2	TATA spare parts
585891000158	ASSY DAMPER SERVICE KIT BS6	TATA spare parts
585891000162	KIT ASSEMBLY SEAT BACK AND CUSHION BS6-P	TATA spare parts
585891000165	TRACK KIT ASSY SLEEPER CAB BS6-PH2	TATA spare parts
585891000192	KIT ASSY. HA MOUNTING BRACKET BS6-PH2	TATA spare parts
585891000196	TACK ASSY BACK AND CUSHION BS6-PH2	TATA spare parts
585891010110	TACK KIT ASSY BS6-PH2	TATA spare parts
585891010112	TRACK KIT ASSY BS6-PH2	TATA spare parts
585891500101	ELR BELT ASSY	TATA spare parts
585891500103	TWIN BUCKLE (CO DRIVER & MIDDLE)	TATA spare parts
585891500105	LAP BELT ASSY	TATA spare parts
585891500107	KIT SEAT BELT FIX TYPE WIDE RHD LOW VERS	TATA spare parts
585891500114	KIT SEAT BELT FIX TYPE NARROW RHD	TATA spare parts
585891980101	RISERASSY BS6	TATA spare parts
585891980102	SLIDERASSY BS6	TATA spare parts
585891980103	RECLINERKNOB BS6	TATA spare parts
585891980104	TRIMASSY FRONTSEATBACK BS6	TATA spare parts
585891980105	RECLINERSIDECOVER BS6	TATA spare parts
585891980107	TRIMASSY FRONTSEATCUSHION BS6	TATA spare parts
585891980108	RISERASSY BS6	TATA spare parts
585894000102	CO-DR SEAT WIDE RHD HIGH	TATA spare parts
585894000105	CO-DRIVER SEAT COMPLETE LOW VERSION RHD	TATA spare parts
585894000109	ASSY KIT BACK CO-DRIVER SEAT COMPLETE	TATA spare parts
585894000110	ASSY KIT CUSHION CO-DRIVER SEAT COMPLETE	TATA spare parts

585894000111	ASS KIT ARMREST COMPLETE	TATA spare parts
585894000112	ASSY CO DRIVER RECLINER COVER OB	TATA spare parts
585894000113	ASSY CO DRIVER RECLINER COVER IB	TATA spare parts
585894000114	SIDE VALANCE COVER LH	TATA spare parts
585894000115	IB FLOOR MTG COVER LH	TATA spare parts
585894000116	CO-DRIVER SEAT ASSY BS6	TATA spare parts
585894000118	CO-DRIVER SEAT ASSY	TATA spare parts
585894000122	ASSY CO-DR SEAT WIDE LHD HIGH COLD APPL	TATA spare parts
585894000132	CO-DRIVERSEATASSY	TATA spare parts
585894000145	CO-DRIVER SEAT ASSY	TATA spare parts
585894000147	CO-DRIVER 2-SEATER ASSY BS6-PH2	TATA spare parts
585897500101	SEAT BELT ASSY WITH ELR FRONT-LH	TATA spare parts
585897500104	LAP BELT ASSY MIDDLE	TATA spare parts
585897500105	SEAT BELT ASSY WITH ELR FRONT-LH	TATA spare parts
585897500106	SEAT BELT ASSY WITH ELR FRONT-RH	TATA spare parts
585897500107	STEM BUCKLE ASSY DRIVER BS6-PH2	TATA spare parts
585897500110	SEAT BELT ASSY WITH ELR FRONT-RH	TATA spare parts
585897500112	SEAT BELT ASSY WITH ELR FRONT-RH BS6-PH2	TATA spare parts
585897500115	TWIN BUCKLE ASSY CO-DRIVER & MIDDLE SEAT	TATA spare parts
585897500116	LAP BELT ASSY MIDDLE BS6-PH2	TATA spare parts
585897500117	SEAT BELT ASSY WITH ELR FRONT-LH BS6-PH2	TATA spare parts
585897500118	TWIN BUKLE ASSY CO-DR & MID SEAT BS6-PH2	TATA spare parts
585898410108	PANEL ASSY BERTH STRUCTURE LOWER-RH	TATA spare parts
585898410109	PANEL ASSY BERTH STRUCTURE LOWER-LH	TATA spare parts
585898410110	PANEL ASSY BERTH LOWER-FRONT	TATA spare parts
585898410115	PARTITION PANEL ASSY BERTH LOWER	TATA spare parts
585898410116	BERTH ASSY LOWER	TATA spare parts
585899008001	TAPPING SCREW 4.8X16	TATA spare parts
585899506302	TREE CLIP BS6	TATA spare parts
585899707503	GROMMET 16MM DIA	TATA spare parts
585899707528	GROMMET WIPER 34MM DIA	TATA spare parts
585899707529	GROMMET FOR M8 PLUG	TATA spare parts
5862403	CON ROD BEARING SET STD 692DI	TATA spare parts
5862703	CON ROD BEARING SET RS 2	TATA spare parts
5862803	CON ROD BEARING SET RS 3	TATA spare parts
586330015	MAGNETIC PLUG ASSEMBLY	TATA spare parts
58633015	MAGNETIC PLUG ASSEMBLY	TATA spare parts
5863315	MAGNETIC PLUG	TATA spare parts
586340002	PACKING RING	TATA spare parts
5870000090	SPECIAL DEVICE	TATA spare parts
5870000097	MOUNTING FIXTURE	TATA spare parts
5870053020	DRIVER	TATA spare parts
5870058084	DRIVER	TATA spare parts
5870058088	DRIVER	TATA spare parts
5870100044	PRESSURE PIECE	TATA spare parts
5870100056	PRESSURE PIECE	TATA spare parts
5870100060	PRESSURE PIECE	TATA spare parts

5870203032	TORQUE SPANNER	TATA spare parts
5870260002	GRIP	TATA spare parts
5870345091	ASSEMBLY DRIFT (COMPL.)	TATA spare parts
5870345094	ASSEMBLY JIG	TATA spare parts
5870506134	PRESSING SLEEVE	TATA spare parts
5870506169	DEVICE (IN PLACE OF SLEEVE 5870506130& P	TATA spare parts
5870610010	WHEEL STUD PULLER - BASIC TOOL	TATA spare parts
5870912018	CENTERRING PIN	TATA spare parts
5870970007	TWO-ARMED PULLER	TATA spare parts
590909145823	CLEAN AIR DUCT-1 BS6	TATA spare parts
59124271163	SHEET 1.6X705X1685 E34(BSK34)HR SS4012A	TATA spare parts
59125270527	SHEET 0.8X1500X2410 EDD513 SS4011	TATA spare parts
59125279877	SHEET 0.8X900X1820 EDD513 SS4011	TATA spare parts
59125982853	SHT. 0.8X1710X2135 EDD 40G40G GA SS4016	TATA spare parts
60000150002	GLASS (175X1575X5 THK)	TATA spare parts
60005080001	FRONT PASS. DOOR GLASS	TATA spare parts
60005080002	FRONT PASS. DOOR GLASS	TATA spare parts
60005080009	GLASS TINTED (268X810X5 THK)50	TATA spare parts
60005080010	GLASS TINTED (288X810X5 THK)50	TATA spare parts
60005080058	GLASS TINTED (268X810X5 THK) - BRONZE	TATA spare parts
60005080059	GLASS TINTED (288X810X5 THK) - BRONZE	TATA spare parts
60005080062	GLASS (381X845X5 THK)	TATA spare parts
60005080063	GLASS TINTED (265X856X5 THK) - BRONZE	TATA spare parts
6001202014	PIPE	TATA spare parts
6001202015	PIPE	TATA spare parts
6005200241	SCHALTKNOPF	TATA spare parts
6007202079	TUBE	TATA spare parts
6019-ZGB/T276-94	ANNULAR BALL BEARING	TATA spare parts
6029005023	CABLE NAT	TATA spare parts
6029005032	CABLE NAT	TATA spare parts
6029201727	PLUG	TATA spare parts
6029201743	PLUG	TATA spare parts
6038202045	CUT-OFF VALVE	TATA spare parts
6038211086	SHIFT CYLINDER	TATA spare parts
6038323105	COVER	TATA spare parts
60599	NUT	TATA spare parts
60600	NUT-SPIDER	TATA spare parts
6060201221	INTERM.PLATE	TATA spare parts
6060201242	CLUTCH BELL HOUSING	TATA spare parts
6060268037	RELEASE FORK	TATA spare parts
6060306086	STUD	TATA spare parts
6060306087	SEALING WASHER	TATA spare parts
6060306096	SUPPORT BRACKET	TATA spare parts
610000000046	VALVE POPPET	TATA spare parts
610000000089	12 INCH ROLLING DIAPHGRM	TATA spare parts
61000060072	SPACE COLLAR	TATA spare parts
61000060084	SPACE BUSH	TATA spare parts



611094033000	DOLLEY	TATA spare parts
611094033400	29MM SOCKET	TATA spare parts
611094132600	SPL TOOL-4021 GB- LOCKING OUT PUT GEAR	TATA spare parts
611094132700	SPL LEVER -4021 AXLE-DIFF BRG ADJUSTER	TATA spare parts
611094132800	SPL LEVER- 4021 AXLE DIFF BRG ADJUSTMENT	TATA spare parts
611094132900	PULLER-4021 FLANGE	TATA spare parts
611094133000	LIFTING TACKLE-4021AXLE/GEAR BOX M/SHAFT	TATA spare parts
611094133200	LIFTING HOOK-4021AX P G HSG & T/PINION	TATA spare parts
611094133300	HOLDER- 4021 COUPLING FLANGE	TATA spare parts
611094133400	SOCKET- 4021 GEAR BOX 29MM A/F	TATA spare parts
61342062SF000000	BATTERY BOX FRAME ASSY	TATA spare parts
61342063SN000000	BATTERY BOX ASSY	TATA spare parts
614011190001	FRONT FACIA ASSY BS6	TATA spare parts
614022950001	FRONT FLAP BS6	TATA spare parts
614310570001	ENGINE HOOD	TATA spare parts
614310580001	PODEST	TATA spare parts
614310610001	FRP ENGINEHOOD- 7T BSVI BS6	TATA spare parts
614310620001	FRP PODEST- 7T BSVI BS6	TATA spare parts
614310630001	FRP PODEST ILCV STAFF BSVI BS6	TATA spare parts
614310640001	FRP ENGINEHOOD ILCV STAFF BSVI BS6	TATA spare parts
614310710001	FRP PODEST-IL CV NEO STAFF BSVI BS6	TATA spare parts
614310720001	FRP PODEST - ILCV NEO STAFF BSVI BS6	TATA spare parts
614320340001	ENGINE HOOD FOR 712	TATA spare parts
614410820001	REAR FRP BS6	TATA spare parts
617010660001	SKIRT PANEL COMPL.	TATA spare parts
617010670001	SKIRT PANEL COMPL.	TATA spare parts
617010680001	SKIRT PANEL COMPL.	TATA spare parts
617010690002	DOOR ASSY. / B.B.	TATA spare parts
617010700001	DOOR ASSY. / S.T.	TATA spare parts
617010750001	SKIRT PANEL COMPL.	TATA spare parts
617010760002	SKIRT PANEL COMPL. (DRV. STEP)	TATA spare parts
617012190008	FLAP COMPL/UREA TANK BS6	TATA spare parts
617020750001	SKIRT PANEL COMPL./F.T.	TATA spare parts
617020760001	SKIRT PANEL COMPL.	TATA spare parts
617020760002	SKIRT PANEL COMPL.	TATA spare parts
617020760003	SKIRT PANEL COMPL.	TATA spare parts
617020770002	SKIRT PANEL BELOW EMG DOOR	TATA spare parts
617020800001	SKIRT PANEL COMPL.	TATA spare parts
6172031373	HOUSING	TATA spare parts
617301660001	WHEEL ARCH PANEL FRT LH	TATA spare parts
61730502CF012000	DOOR ASSY/B.T.	TATA spare parts
61740511CF008300	SKIRT PANEL COMPL/FT	TATA spare parts
620000000021	M22 X 1.5 / M12 X 1.5 UNION BODY	TATA spare parts
620000000023	M22 X 1.5 / M22 X 1.5 UNION BODY	TATA spare parts
620000000024	M16 X 1.5 / M12 X 1.5 UNION BODY	TATA spare parts
620000000026	M22 ALUMINIUM WASHER	TATA spare parts
620000000027	AIR FILTER	TATA spare parts

620000000035	NON RETURN VALVE	TATA spare parts
620000000039	M16 ALUMINIUM WASHER	TATA spare parts
620000000063	SPHERILASTIC BUSH - TAPER BUSH	TATA spare parts
620000000090	TAPER PIVOT WITH SPIGOT	TATA spare parts
620000000125	M24 MACHINED WASHER	TATA spare parts
620000000145	3/16IN X 2 1/2IN SPLIT PIN	TATA spare parts
620000000158	M12 ALUMINIUM WASHER	TATA spare parts
620000000232	SPHERILASTIC BUSH-PIN TYPE - PARALLEL LI	TATA spare parts
620000000285	M12 X 1.5 BRASS ELBOW	TATA spare parts
620000000300	M12 X 1.5 / M12 X 1.5 UNION BODY	TATA spare parts
620000000307	LEVELLING VALVE CONNECTING ROD	TATA spare parts
620000000309	LEVELLING VALVE LEVER	TATA spare parts
620000000341	ANTI ROLL BAR END LINK	TATA spare parts
620000000402	M12 X 1.5 'T' CONNECTOR WITH NUT	TATA spare parts
620000000444	COWHORN DOWEL	TATA spare parts
620000000449	12IN STEEL CLAMP PLATE	TATA spare parts
620000000502	M12 X 1.5 BRASS ELBOW WITH NUT	TATA spare parts
620000000523	12" STEEL PISTON	TATA spare parts
620000000539	SPHERILASTIC BUSH -RADIUS ROD	TATA spare parts
620000000585	LEVELLING VALVE LEVER	TATA spare parts
620000000624	M12 X 1.5 BRASS ELBOW WITH NUT	TATA spare parts
620000000639	BUMP STOP (BIG)	TATA spare parts
620000000649	CROSS LINK	TATA spare parts
620000000662	M12 X 1.75 X 85MM STUD	TATA spare parts
620000000666	ANABOND	TATA spare parts
620000000704	MR SPLIT BUSH -PER PCS	TATA spare parts
620000000763	RADIUS ROD	TATA spare parts
620000000769	LEVELLING VALVE CONNECTING ROD	TATA spare parts
620000000790	SPHERILASTIC BUSH (ARB)	TATA spare parts
620000000792	HANGER LINK PLATE	TATA spare parts
620000000793	U-BOLT SADDLE	TATA spare parts
620000000933	PNEUMATIC HOSE CONNECTION KIT	TATA spare parts
620000001016	12IN STEEL PISTON	TATA spare parts
620000001093	SHOCK ABSORBER	TATA spare parts
620000060212	LINK CHANNEL MTG BRACKET	TATA spare parts
620000060363	PARALLEL LINK	TATA spare parts
620000061260	SUB FRAME	TATA spare parts
620000061318	FRONT AIR SPRING CROSS MEMBER ASSY	TATA spare parts
620000061326	HANGER LINK BKT-LH	TATA spare parts
620000061328	HANGER LINK BKT-RH	TATA spare parts
620000061330	PARALLEL LINK PIVOT AND AIR SPRING BKT L	TATA spare parts
620000061333	PARALLEL LINK PIVOT AND AIR SPRING BKT R	TATA spare parts
620000061335	REAR AIR SPRING BKT -LH	TATA spare parts
620000061340	REAR AIR SPRING BKT -RH	TATA spare parts
620000100086	LEVELLING VALVE	TATA spare parts
620000100173	RADIUS ROD ASSY	TATA spare parts
620000100190	HANGER LINK ASSY	TATA spare parts

620000100191	12 AIR SPRING ASSY	TATA spare parts
620000100205	REPAIR KIT MAJOR	TATA spare parts
620000100206	REPAIR KIT MINOR	TATA spare parts
620000100207	RUBBER CONNECTOR SUB ASSY	TATA spare parts
620000130038	COMPOUND LINK PULLER	TATA spare parts
620000130039	SHOCK ABSORBER CLAMP	TATA spare parts
620000130164	ANTI ROLL BAR	TATA spare parts
620000130242	ANTI ROLL BAR	TATA spare parts
620000140046	M22X2.5 HEX NUT	TATA spare parts
620510150001	FRONT INNER FRP PANEL BS6	TATA spare parts
620510160001	REAR INNER FRP PANEL BS6	TATA spare parts
620510180001	FRONT INNER FRP PANEL BS6	TATA spare parts
620520260001	SCREW HEAD CAP (GREY)	TATA spare parts
620521060001	PRESS RIVET NYLON - OOTIS GREY	TATA spare parts
62112004004	SLEEVING PVC 4 BLACK	TATA spare parts
62113508065	CABLE LUG 6 X 0.8	TATA spare parts
62113510051	CABLE LUG 5 X 1	TATA spare parts
62113510086	CABLE LUG 8 X 1	TATA spare parts
62113600051	TERMINAL FEMALE 6.3X2.5	TATA spare parts
62113600107	TERMINAL FEMALE 6.3 X 6	TATA spare parts
62113610102	TERMINAL FEMALE 8 X 2.5	TATA spare parts
62113620108	TERMINAL MALE 6.3 X 2.5	TATA spare parts
62113655203	TERMINAL FEMALE 4.8 X 0.5	TATA spare parts
62116308434	JOINT TERMINAL	TATA spare parts
6212-GB/T276-94	DEEP CHASE RING BEARING	TATA spare parts
62120100012	BULB 12V 45/40W	TATA spare parts
62120100063	BULB 12V 35/35W	TATA spare parts
62120100152	HALOGEN BULB 12V 60/55W	TATA spare parts
62120100161	HALOGEN BULB 12V 60/55W	TATA spare parts
62120100209	HALOGEN BULB 24V 75/70W	TATA spare parts
62120101615	PARKING BULB HEAD LAMP 12V 5W W2.1X9.5D	TATA spare parts
62120300020	BULB F12V 15W	TATA spare parts
62120300062	BULB 12V 5W	TATA spare parts
62120300097	BULB 12V 10W	TATA spare parts
62120300127	BULB 12V 2W	TATA spare parts
62120300151	BULB 12V 4W	TATA spare parts
62120300194	BULB 12V 2W	TATA spare parts
62120300197	BULB G12V 10W	TATA spare parts
62120300208	LAMP 6V/10W	TATA spare parts
62120300216	BULB 12V 10W	TATA spare parts
62120300232	BULB 12V 5W	TATA spare parts
62120300267	BULB M12V 3W	TATA spare parts
62120399018	BULB L12V 6W	TATA spare parts
62120400083	BULB S12V 18/5W	TATA spare parts
62120400121	BULB 12V 21W BS4	TATA spare parts
62120400156	BULB F12V 15W	TATA spare parts
62120499055	LAMP 24V 5W F24/1 SV8.5 TS29201	TATA spare parts

62120510067	MINIATURE LAMP M24/1 2W	TATA spare parts
62120510075	BULB 24V 2W	TATA spare parts
62120510083	BULB 24V 4W	TATA spare parts
62120510105	BULB 24V 10W	TATA spare parts
62120515107	BULB 12V 10W	TATA spare parts
62120520038	BULB 12V 5/21W	TATA spare parts
62120520046	BULB 24V 21W	TATA spare parts
62120530157	BULB 24V 55/50W	TATA spare parts
62120540152	WED.LAMP 12V 5W W12/4 W2.1X9.5D TS29201	TATA spare parts
62120600015	LAMP 24V 5W R5W BA15S E CERT ECE R37	TATA spare parts
62120600040	LAMP 24V 10W C10W SV8.5 E CERT ECE R37 B	TATA spare parts
62120601011	LAMP 12V/ 60 BS1/2/3/4/6	TATA spare parts
62120601020	LAMP H4 24 V75/70W P 43 T 38 E CERT	TATA spare parts
62120601119	LAMP 12V/ 4W	TATA spare parts
62120601127	LAMP T4W 24V 4W BA9S E.CERT	TATA spare parts
62120601216	LAMP P21W 12V 21W BA15S E.CERT.ECE.R37	TATA spare parts
62120601259	BULB H/L H1 12V55 SAFARI	TATA spare parts
62120601283	LAMP H3 12V 55W PK-22S E CERT. ECE-R37	TATA spare parts
62120601291	LAMP H3 24V 70W PK-22S E CERT.ECE-R37	TATA spare parts
62120601313	BULB R10W 12V BA 15S E	TATA spare parts
62120601321	LAMP R10W 24V 10W BA15S E CERT. ECE R37	TATA spare parts
62120601402	LAMP P21/5W 12V21/5W BAY15D-E.CERT.ECE37	TATA spare parts
62120601411	LAMP P21/5 24V 21/5W BAY15D ECERT ECER37	TATA spare parts
62120601518	LAMP C5W 12V 5W SV8.5-36 E.CERT.ECE-R37	TATA spare parts
62120601551	LAMP 12 V 10 W	TATA spare parts
62120601577	BULB 24V 70W	TATA spare parts
62120601615	LAMP WSW 12 V 5W CAPLESS BS4	TATA spare parts
62120601623	LAMP WY5W 12V 5W W2.1X9.5D E.CERT.ECER37	TATA spare parts
62120601712	LAMP PY21 12V 21W BAU15 E CERT. ECE R37	TATA spare parts
62120601810	LAMP W5W 24V 5W W2.1X9.5D E CERT.ECE R37	TATA spare parts
62120601836	LAMP H11 24V 70W PGJ19-2 E CERT. ECE-R37	TATA spare parts
62120601844	LAMP H11 12V 55W	TATA spare parts
62120601852	LAMP PY21 24V 21W BAU15 E CERT. ECE R37	TATA spare parts
62120601909	LAMP H1 24V 70W P14-5S E CERT.ECE-R37; H	TATA spare parts
62120602506	LAMP H7 12V 55W PX26D E CERT. ECE R37	TATA spare parts
62120602514	LAMP H7 24V 70W PX26D E CERT. ECE R37	TATA spare parts
62120602603	LAMP H8 12V 35W PGJ19-1 E CERT. ECE R37	TATA spare parts
62120603014	LAMP PR21 12V 21W BAW15S E CERT. ECE R37	TATA spare parts
62120801011	HALOGEN BULB HEAD LAMP 60/55 W 12V E CER	TATA spare parts
62123008001	FUSE LINK 8 IS75281	TATA spare parts
62123050105	FUSE LINK 10 AMP RED	TATA spare parts
62123050156	FUSE LINK 15 AMP L/BLUE	TATA spare parts
62123050253	FUSE LINK 25 AMP WHITE	TATA spare parts
62123050300	FUSE LINK 30 AMP L/GREEN	TATA spare parts
62123055051	FUSE 5 AMP 54820501	TATA spare parts
62123055069	FUSE 7.5 A	TATA spare parts
62123055077	FUSE LINK	TATA spare parts

62123055085	FUSE LINK BLADE 15A BLUE	TATA spare parts
62123055093	FUSE 20A WEDGE TYPE YELLO	TATA spare parts
62123055107	FUSE LINK WHITE 25A	TATA spare parts
62123055115	FUSE LINK BLADE C 30A GREEN DIN72581-3 (	TATA spare parts
62123055123	FUSE 40A	TATA spare parts
62123060011	MINI FUSE 5A(ORANGE)	TATA spare parts
62123060020	MINI FUSE 10A(RED)	TATA spare parts
62123060038	MINI FUSE 15A(BLUE)	TATA spare parts
62123060046	MINI FUSE 20A(YELLOW)	TATA spare parts
62123060054	MINI FUSE 25A(WHITE)	TATA spare parts
62123070084	ATO BL.FUSE 15A/32VDC	TATA spare parts
62123214515	MINI FUSE 5A - 54890083 CREAM-MSSL	TATA spare parts
62123214523	MINI FUSE-10A	TATA spare parts
62123214531	MINI FUSE 15A- 54890051 BLUE - MSSL	TATA spare parts
62123214540	MINI FUSE 20A- 54890052 YELLOW - MSSL	TATA spare parts
62123214558	MINI FUSE 25A- WHITE	TATA spare parts
62123214761	MAXI FUSE 30A- 54890141-PINK- MSSL	TATA spare parts
62123214761_NIU1	MAXI FUSE 30A-PINK	TATA spare parts
62123214779	MAXI FUSE 40A 50102043 GREEN MSSL (COOLI	TATA spare parts
62123214787	MAXI FUSE-50A	TATA spare parts
62123214787_niu1	MAXI FUSE-50A	TATA spare parts
62123214795	MAXI FUSE 60A 63520274 YELLOW MSSL (ACCE	TATA spare parts
62123214809	MAXIFUSE80A-50100222-BLACK	TATA spare parts
62123214914	MAXI FUSE 30A PINK ISO8820	TATA spare parts
62123214922	MAXI FUSE 40A GREEN ISO8820	TATA spare parts
62123224006	FUSE ATO BLADE 5A ISO8820 BS4	TATA spare parts
62123224014	FUSE ATO BLADE 10A ISO8820 BS4	TATA spare parts
62123224022	FUSE ATO BLADE 15A ISO8820 BS4	TATA spare parts
62123224031	FUSE ATO BLADE 20A ISO8820 BS4	TATA spare parts
62123224049	FUSE ATO BLADE 25A ISO8820	TATA spare parts
62123224057	FUSE ATO BLADE 30A ISO8820	TATA spare parts
62123224065	FUSE ATO BLADE 40A ISO8820	TATA spare parts
62123224162	FUSE JCASE CARTRIDGE 20A ISO8820	TATA spare parts
62123224171	FUSE JCASE CARTRIDGE 25A ISO8820	TATA spare parts
62123224189	FUSE JCASE CARTRIDGE 30A ISO8820	TATA spare parts
62123224197	FUSE JCASE CARTRIDGE 40A ISO8820	TATA spare parts
62123224201	FUSE JCASE CARTRIDGE 50A ISO8820	TATA spare parts
62123224219	FUSE JCASE CARTRIDGE 60A ISO8820	TATA spare parts
62123224227	FUSE JCASE CARTRIDGE 100A ISO8820	TATA spare parts
62123224316	FUSE MICRO 02 BLADE 5A ISO8820	TATA spare parts
62123224324	FUSE MICRO 02 BLADE 7.5A ISO8820	TATA spare parts
62123224332	FUSE MICRO 02 BLADE 10A ISO8820	TATA spare parts
62123224341	FUSE MICRO 02 BLADE 15A ISO8820	TATA spare parts
62123224359	FUSE MICRO 02 BLADE 20A ISO8820	TATA spare parts
62123224367	FUSE MICRO 02 BLADE 25A ISO8820	TATA spare parts
62123224375	FUSE MICRO 02 BLADE 30A ISO8820	TATA spare parts
62123224464	FUSE MICRO 03 BLADE 5A ISO8820	TATA spare parts

62123224472	FUSE MICRO 03 BLADE 7.5A ISO8820	TATA spare parts
62123224481	FUSE MICRO 03 BLADE 10A ISO8820	TATA spare parts
62123224499	FUSE MICRO 03 BLADE 15A ISO8820	TATA spare parts
62123224618	FUSE MIDI BOLTABLE 30A ISO8820 BS4	TATA spare parts
62123224626	FUSE MIDI BOLTABLE 40A ISO8820 BS4	TATA spare parts
62123224634	FUSE MIDI BOLTABLE 50A ISO8820	TATA spare parts
62123224642	FUSE MIDI BOLTABLE 60A ISO8820 BS4	TATA spare parts
62123224651	FUSE MIDI BOLTABLE 80A ISO8820	TATA spare parts
62123224669	FUSE MIDI BOLTABLE 100A ISO8820	TATA spare parts
62123224675	FUSE MIDI BOLTABLE 125A ISO8820 BS4	TATA spare parts
62123224685	FUSE MIDI BOLTABLE 150A ISO8820	TATA spare parts
62123224693	FUSE MIDI BOLTABLE 70A ISO8820	TATA spare parts
62123224766	FUSE MINI BLADE 5A ISO8820 BS4	TATA spare parts
62123224774	FUSE MINI BLADE 10A ISO8820 BS4	TATA spare parts
62123224782	FUSE MINI BLADE 15A ISO8820 BS4	TATA spare parts
62123224791	FUSE MINI BLADE 20A ISO8820 BS4	TATA spare parts
62123224804	FUSE MINI BLADE 25A ISO8820	TATA spare parts
62123224812	FUSE MINI BLADE 30A ISO8820 BS4	TATA spare parts
62123224821	FUSE MINI BLADE 7.5A ISO8820	TATA spare parts
62123224910	FUSE BATTERY TERMINAL 300A ISO8820	TATA spare parts
62123225002	FUSE PAL 20A ISO8820	TATA spare parts
62123225011	FUSE PAL 30A ISO8820 BS4	TATA spare parts
62123225029	FUSE PAL 40A ISO8820 BS4	TATA spare parts
62123225037	FUSE PAL 50A ISO8820	TATA spare parts
62123225045	FUSE PAL 60A ISO8820 BS4	TATA spare parts
62123225053	FUSE PAL 70A ISO8820	TATA spare parts
62123225061	FUSE PAL 80A ISO8820 BS4	TATA spare parts
62123225070	FUSE PAL 100A ISO8820	TATA spare parts
62123225169	FUSE PAL BOLTABLE 60A ISO8820	TATA spare parts
62123225177	FUSE PAL BOLTABLE 80A ISO8820	TATA spare parts
62123225185	FUSE PAL BOLTABLE 100A ISO8820	TATA spare parts
62123225193	FUSE PAL BOLTABLE 30A ISO8820	TATA spare parts
62123225207	FUSE PAL BOLTABLE 40A ISO8820	TATA spare parts
62123225215	FUSE PAL BOLTABLE 50A ISO8820	TATA spare parts
62123225223	FUSE PAL BOLTABLE 70A ISO8820	TATA spare parts
62123225231	FUSE PAL BOLTABLE 120A ISO8820	TATA spare parts
62123225312	FUSE MEGA 80A ISO8820	TATA spare parts
62123225321	FUSE MEGA 125A ISO8820	TATA spare parts
62123225339	FUSE MEGA 150A ISO8820	TATA spare parts
62123225347	FUSE MEGA 250A ISO8820	TATA spare parts
62123225355	FUSE MEGA 400A ISO8820	TATA spare parts
62123225363	FUSE MEGA 500A ISO8820 BS3/4/6	TATA spare parts
62123225371	FUSE MEGA 40A ISO8820	TATA spare parts
62123225380	FUSE MEGA 60A ISO8820	TATA spare parts
62123225398	FUSE MEGA 100A ISO8820	TATA spare parts
62123225401	FUSE MEGA 175A ISO8820	TATA spare parts
62123225410	FUSE MEGA 200A ISO8820 BS3/4	TATA spare parts

62123225428	FUSE MEGA 225A ISO8820	TATA spare parts
62123225436	FUSE MEGA 300A ISO8820	TATA spare parts
62123225444	FUSE MEGA 350A ISO8820	TATA spare parts
62123225452	FUSE MEGA 450A ISO8820	TATA spare parts
62123225461	FUSE POWERVAL CAL2 150A ISO8820	TATA spare parts
62123225614	FUSE POWERVAL CAL3 150A ISO8820	TATA spare parts
62123225762	FUSE POWERVAL CAL4 180A ISO8820	TATA spare parts
62123226916	FUSE POWERVAL CAL5 180A ISO8820	TATA spare parts
62123242331	MEGAVAL FUSE LINK 125A	TATA spare parts
62123242349	POWERVAL FUSE LINK	TATA spare parts
62126030062	MINI FUSE 30A(Green)	TATA spare parts
62163055051	FUSE LINK BLADE-C5A L/BROWN	TATA spare parts
62191513423	FLEXIBLE SPLIT TUBE 16 TS29326	TATA spare parts
62191513440	FLEXIBLE SPLIT TUBE 25 TS29326	TATA spare parts
62196058252	CABLE TIE 4.7X110 NATURAL TS29360	TATA spare parts
62196058261	CABLE TIE 4.7 X 110 BLACK	TATA spare parts
62196058287	CABLE TIE 4.5X150 BLACK TS29360	TATA spare parts
62196058350	CABLE TIE 4.7X200 BLACK	TATA spare parts
62196058422	CABLE TIE 3.7X145 BLACK TS29360	TATA spare parts
62196058503	CABLE TIE 8.0 X 300 BLACK	TATA spare parts
62196058520	CABLE TIE 8.0X400 BLACK TS29360	TATA spare parts
62196062292	ADJUSTABLE CLAMP 16-21MM	TATA spare parts
622321350001	TOWER BOLT - BLACK BS6	TATA spare parts
622510510001	PASSENGER DOOR ASSEMBLY	TATA spare parts
622510540001	PASSENGER DOOR ASSEMBLY	TATA spare parts
623010340001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
623010400001	EMERGENCY DOOR ASSEMBLY	TATA spare parts
623010520001	EMERGENCY DOOR ASSEMBLY BS6	TATA spare parts
623022230001	EMG DOOR LOCK INNER COVER	TATA spare parts
623022240001	EMG DOOR LOCK INNER COVER	TATA spare parts
62311007SF	LOCK ASSY	TATA spare parts
62311016SF	LOCK ASSY	TATA spare parts
62312002CN	HANDLE	TATA spare parts
62312006CN	RECLINING LEVER /LH	TATA spare parts
62312026SF	STAY LINK ASSY.	TATA spare parts
62312027SF	STAY LINK ASSY.	TATA spare parts
623310810001	DRIVER DOOR ASSEMBLY BS6	TATA spare parts
623311000001	DRIVERS DOOR ASSLEMBLY	TATA spare parts
623311050001	DRIVERS DOOR ASSY BS6	TATA spare parts
623311100001	CO-DRIVERS DOOR ASSLEMBLY	TATA spare parts
623820350001	SPHEROS AC CC 225 (25KW)	TATA spare parts
62392	WASHER PLAIN	TATA spare parts
624023040001	PEEP GLASS BS6	TATA spare parts
624030330009	SIDE WINDOW ASSY 1/3 FIX 2/3 SLID CLR GL	TATA spare parts
624030330017	SIDE WINDOW ASSY 1/3 FIX 2/3 SLID CLR GL	TATA spare parts
624030330020	SIDE WINDOW ASSY 1/3 FIX 2/3 SLID CLR GL	TATA spare parts
624030330024	SIDE WINDOW ASSY 1/3 FIX 2/3 SLID CLR GL	TATA spare parts

624030330028	SIDE WINDOW ASSY 1/3 FIX 2/3 SLID CLR GL	TATA spare parts
624030350003	SIDE WINDOW ASSY CO-DRV	TATA spare parts
624030810001	SIDE WINDOW GLASS	TATA spare parts
624030820001	SIDE WINDOW ASSY (PASS DR)	TATA spare parts
624030830001	SIDE WINDOW ASSY (CO-DRV)	TATA spare parts
624030840001	SIDE WINDOW ASSY (DRIVER)	TATA spare parts
624030850001	PARTITION WINDOW	TATA spare parts
624031140002	SIDE WINDOW DRV DOOR	TATA spare parts
624031160002	SIDE WINDOW ASSY CO -DRIVER	TATA spare parts
624031180001	SIDE WINDOW DRV DOOR (SM 22)	TATA spare parts
624050520001	SIDE WINDOW ASSY-DRIVER	TATA spare parts
624050530001	SIDE WINDOW ASSY-EMG	TATA spare parts
624050540001	SIDE WINDOW ASSY-(CO-DRIVER)	TATA spare parts
624050580001	SIDE WINDOW ASSY	TATA spare parts
624050580002	SIDE WINDOW ASSY	TATA spare parts
624050580003	SIDE WINDOW ASSY	TATA spare parts
624050860001	HOPPER WINDOW BS6	TATA spare parts
624050900001	HOPPER WINDOW BS6	TATA spare parts
624050970001	SIDE WINDOW ASSY BS6	TATA spare parts
624050970002	SIDE WINDOW ASSY BS6	TATA spare parts
624050970003	SIDE WINDOW ASSY BS6	TATA spare parts
624050970004	SIDE WINDOW ASSY BS6	TATA spare parts
624050970005	SIDE WINDOW ASSY BS6	TATA spare parts
624050970006	SIDE WINDOW ASSY BS6	TATA spare parts
624050970007	SIDE WINDOW ASSY BS6	TATA spare parts
624050970008	SIDE WINDOW ASSY BS6	TATA spare parts
624050970009	SIDE WINDOW ASSY BS6	TATA spare parts
624050970010	SIDE WINDOW ASSY BS6	TATA spare parts
624051020001	CO DRIVER WINDOW ASSY BS6	TATA spare parts
624051020002	CO DRIVER WINDOW ASSY BS6	TATA spare parts
624051170001	HOOPER WINDOW BS6	TATA spare parts
624051170002	HOOPER WINDOW BS6	TATA spare parts
624051190001	SIDE WINDOW EMG DOOR BS6	TATA spare parts
624051200001	SIDE WINDOW DRV DOOR BS6	TATA spare parts
624051210001	SIDE WINDOW ASSY BS6	TATA spare parts
625000020048	M14 X 1.5 X 45MM HEX BOLT	TATA spare parts
625000020069	M16 X 2 X 100MM HEX BOLT	TATA spare parts
625000020108	M20 X 2.5 X 60 MM HEX SCREW	TATA spare parts
625000020178	M22 X 2.5 X 405 'U' BOLT	TATA spare parts
625000100003	M16 X 2 X 120MM HEX BOLT ASSY	TATA spare parts
625000100004	M16 X 2 X 100MM HEX BOLT ASSY	TATA spare parts
625000100005	M14 X 1.5 X 55MM HEX BOLT ASSY	TATA spare parts
625000140003	M8 X 1.25 NYLOC NUT	TATA spare parts
625000140009	HEX NUT M12 X 1.75	TATA spare parts
625000140011	M14 X 1.5 HEX NUT	TATA spare parts
625000140015	M16 X 2 NYLOC NUT	TATA spare parts
625000140020	M24 X 3 CASTLE NUT	TATA spare parts



625000140046	NUT M22 X 2.5	TATA spare parts
625000230004	SPRING WASHER M12	TATA spare parts
625000230005	M14 SPRING WASHER	TATA spare parts
625000230011	M16 MACHINED WASHER	TATA spare parts
625000230021	M22 SPHERICAL WASHER	TATA spare parts
62502303CN013640	SD.WIN.ASSY( 613/CURVE/FLOCK/LH	TATA spare parts
62502303CN113640	SD.WIN.ASSY( 613/CURVE/FLOCK/GR	TATA spare parts
62502352CN113740	SIDE WINDOW ASSY ( 613/TCUR/RH/FLOC/CL)	TATA spare parts
62550520104	PVC ADHESIVE TAPE 3/4"X10Y BLACK IS:2448	TATA spare parts
62559403101	SEALING TAPE PTFE 12MM WIDE	TATA spare parts
62559405278	ADHESIVE COTTON TAPE 19MM WIDE JOHNSON	TATA spare parts
63028	STUD	TATA spare parts
630513064	SNAP RING	TATA spare parts
6312NGB/T276-94	ANNULAR BALL BEARING	TATA spare parts
63333007226	RPAS ECU OFFLINE FLASHING PIGTAIL BS6	TATA spare parts
63333007234	OBD CBL 10M LENGTH P/N-11020001009-1 BS6	TATA spare parts
63333007235	OBD CBL 3M LENGTH P/N- 11020001009-3 BS	TATA spare parts
6365890021	GO/NO-GO GAUGE	TATA spare parts
6365890053	GLOW PLUG PORT	TATA spare parts
6365890253	REAMER	TATA spare parts
63700001500	HSG_2P_250_SRS_M_U_NA_ET	TATA spare parts
63700002290	HSG_2P_250_SRS_F_U_B_PLKBS6	TATA spare parts
63700004110	1 POLE UNSEALED FEMALE CONNECTOR FOR USB	TATA spare parts
63700005501	CONNECTOR BS6	TATA spare parts
63700005986	CONNECTOR&BS6	TATA spare parts
63700006150	CONNECTOR BS6	TATA spare parts
63700007910	ELECTRICAL CONNECTOR	TATA spare parts
63700008080	H-2P 047FS PA66B DTM06-2S-EP10-DEUTSCH	TATA spare parts
63700008210	6 P FEMALE CONN AC CONTROLLER INTERFACE	TATA spare parts
63700008250	HSG_4P_250_SRS_F_U_NA_ET BS6	TATA spare parts
63700008470	2 P FEMALE CONN SEAT BELT SWITCH PROVISI	TATA spare parts
63700008710	9P RELAY BASE	TATA spare parts
63700009010	2 POLE UNSEALED FEMALE CONNECTOR FOR RPA	TATA spare parts
63700009523	CONNECTOR BS6	TATA spare parts
63700010030	F/B(HSG_40P_MINIF280_SRS_F_U_GR)	TATA spare parts
63700010050	R/B(HSG_30P_110_187_SRS_F_U_GR_HYB)	TATA spare parts
63700010590	16 PBB FEMALE CONN FOR ITS & IGN BATT SU	TATA spare parts
63700011587	DIODE ASSY WITH CONNECTOR	TATA spare parts
63700012401	CONNECTOR BS6	TATA spare parts
63700013650	CONNECTOR HSG_3P_DT_SRS_M_S_GYBS6	TATA spare parts
63700100110	Head Lamp Connector	TATA spare parts
63700100250	2 P FEMALE CONN REVERSE BUZZ & FR & RR F	TATA spare parts
63700100790	2 P FEMALE CONN ALL SIDE MARKER & ROOF L	TATA spare parts
63700100980	2 P MALE MATING CONN FOR BB FOR SUPPLY O	TATA spare parts
63700101060	2 POLE SEALED MALE CONNECTOR FOR ADD IGN	TATA spare parts
63700101380	HSG_8P_70_SRS_M_S_B BS6	TATA spare parts
63700101430	FEMALE CONNECTOR 2 POLE (WATER PROOF)	TATA spare parts

63700101560	3 POLE SEALED MALE P CAN CONNECTORBS6	TATA spare parts
63700101660	HSG_6P_90_SRS_M_S_NA BS6	TATA spare parts
63700102140	MALE CONNECTOR 2 POLE (WATER PROOF)	TATA spare parts
63700102180	HSG_2P_DTM_SRS_M_S_GR	TATA spare parts
63700102400	16 P MALE MATING CONNFOR ITS & IGN BATT	TATA spare parts
63700102900	CONNECTOR HSG_3P_DT_SRS_M_S_B	TATA spare parts
63700103000	CONNECTOR HSG_3P_DT_SRS_M_S_BBS6	TATA spare parts
63700104310	2 P FEMALE BB CONN FOR SUPPLY OR POWERBS	TATA spare parts
63700104750	CAM SENSOR	TATA spare parts
63700105130	FUEL TEMP SNSR	TATA spare parts
63700105170	INLET METERING VALVE	TATA spare parts
63700105550	INJECTOR-1	TATA spare parts
63700107790	CONNECTOR BS6	TATA spare parts
63700108810	FEMALE CONNECTOR 3 POLE (WATER PROOF)	TATA spare parts
63700108890	HSG_4P_SEAL START 1.2MM_F_S_B BS6	TATA spare parts
63700110350	CRANK POSITION SENSOR	TATA spare parts
63700110390	HSG_3P_DT_SRS_F_S_GR	TATA spare parts
63700112610	CONNECTOR HSG_2P_090_SRS_F_S_GBS6	TATA spare parts
63700112890	3 POLE SEALED FEMALE CAN CONNECTOR FOR I	TATA spare parts
63700113070	4P CON FOR CAN BS6	TATA spare parts
63700200810	2P MAXI FB	TATA spare parts
63700200930	F/B ASSY 8P (HSG_8P_MIDIFUSE_SRS_F_U_B)	TATA spare parts
63700200950	F/B ASSY 4P (HSG_4P_MIDIFUSE_SRS_F_U_B)	TATA spare parts
63700200970	FUSE HOLDER	TATA spare parts
63700201250	FUSE & REL BASE (ASY_24P_XX_SRS_F_U_GR)	TATA spare parts
63700201410	FUSE BASE ASY_10P_MF_SRS_F_U_B W/O COVER	TATA spare parts
63700201630	FUSE & RELAY BOX CABIN	TATA spare parts
63700202000	FUSE & RELAY BOX ASSY	TATA spare parts
637009502	CASTLE NUT	TATA spare parts
63701000890	TRML REC 250 SRS TIN (AWG 14-12) BS6	TATA spare parts
63701002000	HSG-30-2 TIN BS6	TATA spare parts
63701002020	HSG30-2 3SQ TIN BS6	TATA spare parts
63701003070	TRML 250 SRS F (CSA 0.50-2.27) BS6	TATA spare parts
63701200280	EYELET (TER_EARTH_M6_6.00-8.00_SN) BS6	TATA spare parts
63702004138	FUSE BOX ASSY	TATA spare parts
63702004367	ASSY-10P FB W COV FU PAB 602001140-AK BS	TATA spare parts
63704002030	SL_XX_SRS_GR_4P (COVER)	TATA spare parts
63704002040	FUSE - RELAY BOX CABIN BS6	TATA spare parts
63704002480	SL_XX_SRS_B (FUSE HOLDER) BS6	TATA spare parts
63708000050	CC_EDGE_CLIP_B_/1.5/45_MM	TATA spare parts
63708000090	CC_FURR_CLIP_DIA_6.5_MM	TATA spare parts
63708000160	CC_FURR_CLIP_B_M6X10.00_MM	TATA spare parts
63708000300	CC_VAR_ST_N_5.00-6.00_MM	TATA spare parts
63708000360	MOUNTING_CLIP_B_DIA_6.50_MM BS6	TATA spare parts
63708000810	CC_HOSE_CLIP_B_DIA_6.00-6.50_MM	TATA spare parts
63708000820	CC_HOSE_CLIP_B_DIA_8.00-9.00_MM	TATA spare parts
63708000840	CC_HOSE_CLIP_B_DIA_10-12_MM BS6	TATA spare parts

63708000880	CC_HOSE_CLIP_B_DIA15.00-16.00_MM	TATA spare parts
63708000910	CC_SEPARATOR_CLAMP_B_17_MM BS6	TATA spare parts
63708000970	CLIP BS6	TATA spare parts
63708001120	CC_STUD_CLIP_B_DIA_25_MM BS6	TATA spare parts
63708001390	CC_VAR_HL_N_0.80-10.00_MM BS6	TATA spare parts
63708001530	STUD_CLIP	TATA spare parts
63708001580	CC_FUR_CLIP_B_6 50-7 00_MM	TATA spare parts
63708001990	CC_FURR_CLIP_B_DIA_8-8.5_MM BS6	TATA spare parts
63708002670	CC_FURR_CLIP_B_7_MM	TATA spare parts
63708002740	CC_EDGE_CLIP_B_3.00-6.00THK_MM BS6 PH2	TATA spare parts
63708002820	HOSE_CLIP_B_DIA_16.00-22.00_213_MM	TATA spare parts
63708002890	CC_SEPERATOR_CLAMP_B_10.00-14.00_MM BS6	TATA spare parts
63708003480	CLIP	TATA spare parts
63708003982	CLIP-2W HOSE PAB 081340-0-00 ARAYMOND	TATA spare parts
63708003991	CLIP EV	TATA spare parts
63708004008	CLIP EV	TATA spare parts
63708004032	CLIP EV	TATA spare parts
63717000080	MINI FUSE 5A (ENG BAY ILLUMINATION)	TATA spare parts
63717000090	MINI FUSE 10A 54890048 RED-MSSL (DIP BEA	TATA spare parts
63717000100	FUSE LINK BLADE C 15A L/BLUE DIN72581-3	TATA spare parts
63717000110	FUSE LINK BLADE C 20A YELLOW DIN72581-3	TATA spare parts
63717000130	MAXI FUSE 30A 54890141 PINK MSSL (STARTE	TATA spare parts
63717000590	FUSE 40A BS6	TATA spare parts
63727003055	FRAME FUSE BOX BS6	TATA spare parts
63727003268	FUSE BOX COVER BS6	TATA spare parts
63727100230	REL 12V 25A	TATA spare parts
63727302190	FRAME_FUSE_BOX_MTA_0301520_GR	TATA spare parts
640121030001	PARTITION GLASS ASSY (PCOAT) -LT GRN	TATA spare parts
640121780002	PARTITION GLASS ASSEMBLY (P.C) - CLR GLS	TATA spare parts
641710010001	FDSS KIT BS6	TATA spare parts
643120000001	ARM (ROOM MIRROR)	TATA spare parts
64502009SF	BRACKET	TATA spare parts
64502011SF	OUTSIDE MIRROR BRACKET	TATA spare parts
64502016SF000000	RVM ARM ASSY(613-LHD-CO DRV SD)	TATA spare parts
64504000CN	ARM TELCO 609 (RH)	TATA spare parts
64504007CN	ARM TELCO 609 (LH)	TATA spare parts
64510103AF	GUARD RAIL BRKT.	TATA spare parts
64510105CF000000	NYLON GUARD RAIL BKT (GREY 25 DI)	TATA spare parts
64602007FN	CAB COMPLT RHD SLEEPER	TATA spare parts
646020430001	FRONT BUMPER ASSEMBLY BS6	TATA spare parts
646020440001	FRONT BUMPER ASSY BS6	TATA spare parts
64605060001	GLASS (460X692X5 THK)	TATA spare parts
64605070011	PARTITION GLASS	TATA spare parts
647310-0120-0-H	STATOR MAGNETIC CLUTCH	TATA spare parts
647350-0190-1-H	ROTOR MAGNETIC CLUTCH	TATA spare parts
648010700001	SEAT FRAME COMPLETE (CO-DRV.SIDE)	TATA spare parts
650200470001	WIRING HARNESS COMPLETE	TATA spare parts

650200570001	ROOF HARNESS COMPLETE	TATA spare parts
650200590001	ROOF HARNESS COMPLETE	TATA spare parts
650200870001	ROOFHARNESSCOMPLETE	TATA spare parts
650200940001	ROOF HARNESS-7T BSVI BS6	TATA spare parts
650200950001	ROOF HARNESS -8T-52 BSVI BS6	TATA spare parts
650201020001	ROOF HARNESS COMPLETE- BSVI STAFF BS6	TATA spare parts
650201280001	ROOF HARNESS LP810 NEO STAFF CX BS6-PH2	TATA spare parts
650201300001	ROOF HARNESS LP710 NEO SKOOL BS6	TATA spare parts
650201310001	ROOF HARNESS LP710 NEO SKOOL BS6	TATA spare parts
650201320001	ROOF HARNESS LP 810 NEO SKOOL CX BS6	TATA spare parts
650201410001	ROOF HARNESS LP710 NEO SKOOL BS6-PH2	TATA spare parts
650210580001	W/H EMG SWITCH AIS140-710/45CX	TATA spare parts
650222080001	METER PANEL HARNESS	TATA spare parts
650330	RING PISTON	TATA spare parts
65111008FN	CAB COMPLT RHD SLEEPER	TATA spare parts
65111009FN	GARMISH L H	TATA spare parts
65111010FN	CAB COMPLT RHD SLEEPER	TATA spare parts
65111011FN	GARNISH CENTRE	TATA spare parts
65111012FN	FRONT FLAP SMALL	TATA spare parts
651110270001	HEAD LAMP 12V L.B LHD LH (FIEM)	TATA spare parts
651110280001	HEAD LAMP 12V L.B LHD RH (FIEM)	TATA spare parts
651120250001	FRONT INDICATOR (SIA1125-00AFL/AFR) 24V	TATA spare parts
651120270001	H L 24V H.B RHD WITH PARKING RH (FIEM)	TATA spare parts
651120540001	FRONT DIRECTION INDICATOR 12V BS6	TATA spare parts
651220230001	STOP LAMP 12V FIEM E CERT	TATA spare parts
651220240001	REVERSE LAMP 12V FIEM E CERT	TATA spare parts
651220250001	REAR DIRECTION IND LAMP 12 V	TATA spare parts
651220260001	STOP LAMP FIEM 24V E CERT SINGLE FILAMEN	TATA spare parts
651220280001	REVERSE LAMP 24V FIEM HOLDER	TATA spare parts
653210060001	REAR NO PLATE LAMP E MARKED	TATA spare parts
653320320001	FRONT DESTINATION BOARD 1200MM HANOVER	TATA spare parts
653710130001	WIPER SYSTEM ZEAL 12V BS6 2200WIDTH BS6	TATA spare parts
653710150001	WIPER SYSTEM ZEAL 12V BS6 2200WIDTH BS6	TATA spare parts
653720210001	WIPER LINKAGE ASSEMBLY -LHD	TATA spare parts
653720220001	WIPER ARM ASSEMBLY	TATA spare parts
653720230001	WIPER BLADE LHD 700MM	TATA spare parts
653720240001	LINKAGE SYSTEM BS6	TATA spare parts
653720250001	MOTOR 12V 70 NM BS6	TATA spare parts
653720260001	WIPER ARM ASSY BS6	TATA spare parts
653720270001	WIPER BLADE ASSY 32INCH BS6	TATA spare parts
653720280001	WASHER KIT ASSY 12 V BS6	TATA spare parts
653720310001	LINKAGE SYSTEM BS6	TATA spare parts
653720340001	WIPER BLADE ASSY 32 BS6	TATA spare parts
653720350001	MOTOR 12V 70 NM BS6	TATA spare parts
653720400001	WIPER SYSTEM NEO 2340W 12V BS6	TATA spare parts
653720410001	WIPER SYSTEM NEO 12V BS6 2200WIDTH BS6	TATA spare parts
653720480001	LINKAGE SYSTEM 92581000 BS6	TATA spare parts

653720490001	LINKAGE SYSTEM 92580000 BS6	TATA spare parts
654010210001	DASHBOARD COMPLETE - LCV SENEGAL	TATA spare parts
654010270001	FRP DASHBOARD- LP 613 JUPITER	TATA spare parts
654010310001	FRP DASHBOARD ZEAL BSVI (LP 7T 8T 4T) BS	TATA spare parts
654010480001	FRP DASHBOARD STAFF BSVI NEO 8T BS6	TATA spare parts
654010520001	FRP DASHBOARD BSVI NEO 2200W BS6	TATA spare parts
654040370002	PANEL	TATA spare parts
654040380001	CATCHER PLATE	TATA spare parts
655020020001	BODY BUILDER EMERGENCY SWITCH 12V BS6-PH	TATA spare parts
655020050001	NIGHT LAMP SWITCH 12V BS6-PH2	TATA spare parts
655020060001	DRIVER FAN SWITCH 12V BS6-PH2	TATA spare parts
655020100001	DRIVER LAMP SWITCH 12V BS6-PH2	TATA spare parts
655020230001	ROOM A/B LAMP SWITCH 12V BS6-PH2	TATA spare parts
655020250001	STEP LAMP SWITCH 12V BS6-PH2	TATA spare parts
656010500001	RELAY (12V 30 AMPS)	TATA spare parts
656020990001	SMPS 12V	TATA spare parts
656040090001	AIS 140 INFO FITTMENT -LP 709/42 WB	TATA spare parts
662750944011590	REAR WINDSHIELD GLASS/ CTR	TATA spare parts
668250960011970	REAR W/S CTR GLASS(6HD-3PC-TUF	TATA spare parts
67921	PINION BRG SHM 0.005	TATA spare parts
67922	PINION BRG SHM 0.010	TATA spare parts
67923	PINION BRG SHM 0.020	TATA spare parts
67924	PINION BRG SHM 0.030	TATA spare parts
680340013	CIRCLE NUT	TATA spare parts
680340015	STOP WASHER	TATA spare parts
680340023	O STYLE PACKING RING	TATA spare parts
68034165M10	DISC BRAKE RH	TATA spare parts
68034166M10	DISC BRAKE LH	TATA spare parts
680M3200015	O STYLE PACKING RING	TATA spare parts
680M330015	O STYLE PACKING RING	TATA spare parts
68138	CONNECTOR MALE	TATA spare parts
68139	ELBOW MALE ADAPTER	TATA spare parts
68152A	CLIP	TATA spare parts
68152B	CLIP	TATA spare parts
68274	SPRING COMPRESSION	TATA spare parts
68326511	ROTOR - MACHINED	TATA spare parts
68368B	SPACER MOUNTING	TATA spare parts
6881926	BUSHING GEAR SET	TATA spare parts
69000330008	PIN (FOR 13 T)	TATA spare parts
69000340028	RETURN SPRING	TATA spare parts
69015080001	FRONT PASS. DOOR GLASS	TATA spare parts
69015080003	GLASS TINTED (268X810X5)50PERCGRE	TATA spare parts
69015080012	GLASS TINTED (268X810X5 THK)	TATA spare parts
69375	CLIP	TATA spare parts
69465	CLIP	TATA spare parts
6B5.9CNG(A)	TESTED LONG BLOCK1510CNG VEHICLE	TATA spare parts
70012	RUBBER FOR RUB RAIL BEADING	TATA spare parts

70013	RUBBER FOR WIRING CHANNEL	TATA spare parts
70016	RUBBER FOR WINDOW .	TATA spare parts
70328	RETAINING SPG ORANGE	TATA spare parts
70458A	HOSE PLAIN	TATA spare parts
70777	ADAPTOR	TATA spare parts
70802	TEE	TATA spare parts
712420010001	LID CUP	TATA spare parts
715001003025	FRONT STRUCTURE ASSY BS6	TATA spare parts
715010901008	SOLID RUBBER PROF FOR¿ DOOR 6MTR	TATA spare parts
715010901009	SPONGY RUBBER PROFILE 6 MTR	TATA spare parts
715010901010	FOOT STEP AL. EXTRUSTION 4 MTR	TATA spare parts
715010901011	RUBBER PROFILE 6 MTR	TATA spare parts
715010901012	PVC+ABS PROFILE 1 MTR	TATA spare parts
715010901013	PVC PROFILE 3 MTR	TATA spare parts
715010901014	CORRUGATED TUBE 8MM DIA 10MTR	TATA spare parts
715010901015	PVC EXTRUSION PROFILE MTR	TATA spare parts
715010901016	PVC EXTRUSION PROFILE 6 MTR	TATA spare parts
715010901017	ALUMINIUM PROFILE 1 MTR	TATA spare parts
715010901018	PARTITION DOOR RUBBER 1 MTR	TATA spare parts
715010901019	V BELT ( COMP TO ALTR)	TATA spare parts
715010901020	V BELT ( COMP TO CRANK PULLEY )	TATA spare parts
715010901022	PASTED GLASSES SUPPORT RUBBER 2M BS6	TATA spare parts
715010901023	SOLID RUBBER PROFIL 2M BS6	TATA spare parts
715010901024	SOLID RUBBER PROFIL BOTTOM 2M BS6	TATA spare parts
715010901025	ALUMINIUM PROFILE FOR HATRACK 6M	TATA spare parts
715010901026	LAMP ALUMINIUM PROFILE 7.2M	TATA spare parts
715010901027	ROOF PVC PROFILE 7.2M	TATA spare parts
715010901030	SOLID RUBBER PROFILE FOR FLAPS 25M	TATA spare parts
715010901031	SOLID RUBBER PROFILE WITH LEAF 25M	TATA spare parts
715015003008	DRIVER DOOR HINGE ASSY	TATA spare parts
715015003009	DRIVER DOOR INTERNAL PANEL ASSY	TATA spare parts
715015003013	MAGNA INTERNAL GRAB HANDLE BS6	TATA spare parts
715015004007	DRIVER DOOR STRUCTURE & PANEL ASSY	TATA spare parts
715015004010	LATCH ASSY	TATA spare parts
715015004013	ASSY WITH INNER HANDLE RH	TATA spare parts
715015004014	BELL CRANK FR DOOR	TATA spare parts
715015004021	DRIVER DOOR STRUCTURE AND PANEL ASSY BS6	TATA spare parts
715015063001	D TYPE GRAB HANDLE	TATA spare parts
715015303001	DOOR BOLT COVER_ EVO2	TATA spare parts
715015323004	DRIVER DOOR LOCK COVER ABS (EVO-2)	TATA spare parts
715016002003	EMGENCY DOOR	TATA spare parts
715016003003	LH SIDE PASSANGER DOOR WINDOW ASSY	TATA spare parts
715016003004	RH SIDE DRIVER DOOR WINDOW ASSY	TATA spare parts
715016003010	EMERGENCY DOOR ASSLY WITH LOCK	TATA spare parts
715016003023	CASSETTE WINDOW 1691X1094MM	TATA spare parts
715016003024	CASSETE WINDOWTAPER LHLAYOUT1692X1094M	TATA spare parts
715016003025	CASSETTE WINDOWTAPER RHLAYOUT1692X1094	TATA spare parts

715016003026	CASSETTE WINDOW ASSY LH CORNER 1149X1094	TATA spare parts
715016003027	CASSETTE WINDOW ASSY RH 1219X1094	TATA spare parts
715016003028	CASSETTE WINDOW ASSY LH 915X1094	TATA spare parts
715016003034	EMG DOOR EXT PANEL ASSY 705X1500 APP BS6	TATA spare parts
715016003037	COMM WINDOW ASSY FOR MAGNA_APP 399X1149	TATA spare parts
715016003039	DR.PARTITION_WIND_1141X376_CLEAR_EPDM BS6	TATA spare parts
715016003041	REAR EMG DOOR LOCKY ASSY 705X1532 APP BS6	TATA spare parts
715016003046	VRL EMG LADDER WITH HINGE ASSY BS6	TATA spare parts
715016004001	PASSANGER DOOR WINDOW ASSY	TATA spare parts
715016004002	DRIVER DOOR WINDOW ASSY	TATA spare parts
715016004006	VENTILATION WINDOW_AUDACE SEATER	TATA spare parts
715016004012	VENTILATION WINDOW_AUDACE SEATER	TATA spare parts
715016183002	INTERNAL PANEL	TATA spare parts
715016183003	FINISHING PROFILE A	TATA spare parts
715016183004	FINISHING PROFILE B	TATA spare parts
715016233027	LH/RH SIDE PASTED WIN GLASS_(1690X1093)	TATA spare parts
715016233029	LH SIDE PASTED WINDOW GLASS (1926X1374)	TATA spare parts
715016233030	LH SIDE FRNT PASTED WIND GLASS (695X339)	TATA spare parts
715016233031	LH SIDE REAR PASTED WIND GLASS(1660X673)	TATA spare parts
715016233032	LH SIDE PASTED WIND GLASS(1121X480)	TATA spare parts
715016233034	RH SIDE REAR PASTE WIND GLASS(1927X1374)	TATA spare parts
715016233035	RH SIDE REAR PASTE WIND GLASS_(863X412)	TATA spare parts
715016233036	RH SIDE REAR PASTED WIND ASSY(1589X505)	TATA spare parts
715016233037	RH SIDE PASTED WIND GLASS(1289X455)	TATA spare parts
715016233043	LH SIDE PASTED WIND GLASS_50PERC T_1149X1094	TATA spare parts
715016233044	RR RH PASTED WIND GLASS_1219X1093_50PERC	TATA spare parts
715016233045	RH PASTED WIND GLASS 915X1094_50PERC TIN	TATA spare parts
715016233046	RH PASTED WIND GLASS_685X720_50PERC T	TATA spare parts
715016233047	RH PASTED WIND GLASS_695X357_50PERC T	TATA spare parts
715016233048	PASTED GLASS_PARTN.WINDOW_1155X390_CLR	TATA spare parts
715016233049	LH SIDE MRVM PASTED WIND GLASS(1660X673)	TATA spare parts
715016233050	RH SIDE MRVM PASTED WIND GLASS(1587X499)	TATA spare parts
715016233051	LH PASTED WIND GLASS_50PERCGRN_1149X1093	TATA spare parts
715016233052	SIDE PASTED GLASS_1690X1093_50PERCGRN	TATA spare parts
715016233053	LH SIDE PASTED GLASS_1926X1374_50PERCGR	TATA spare parts
715016233054	RH SIDE PASTED GLASS 1926X1374_50PERCGRN	TATA spare parts
715016233055	RH SIDE PASTED GLASS_1219X1093_50PERCGR	TATA spare parts
715016233056	RH SIDE PASTED GLASS_915X1094_50PERCGRN	TATA spare parts
715016233057	RH PASTED GLASS 685X720_50PERCGRN	TATA spare parts
715016233070	RH PASTED WIND GLASS 915X1094_50PERC TIN	TATA spare parts
715016233071	RH PASTED GLASS 685X830_50PERCGREEN TINT	TATA spare parts
715016233072	RH PASTED WIND GLASS_695X248_CLEAR BS6	TATA spare parts
715016233073	RH PAST WIND GLS_915X1094_50PERCGRY TNT	TATA spare parts
715016233074	RH PASTED GLASS 685X835_50PERCGRAY TINTE	TATA spare parts
715016234001	PASSANGER DOOR PASTED GLASS(942X666)	TATA spare parts
715016234002	DRIVER DOOR PASTED GLASS (1172X802)	TATA spare parts
715016234004	LH/RH PASTED GLASS (1690X1093)	TATA spare parts

715016234007	PASSANGER DOOR PASTED GLASS(747X666)	TATA spare parts
715016234008	PASTED GLS_1690X1093_50PERCGRN	TATA spare parts
715016234025	COMM. WINDOW GLASS FRONT BS6	TATA spare parts
715016234026	COMM WINDOW GLASS REAR BS6	TATA spare parts
715016303001	EMERGENCY DOOR LOCK COVER_EVO2	TATA spare parts
715016303002	EXTERNAL HINGE FINISHING COVER 1 BS6	TATA spare parts
715016303003	EXTERNAL HINGE FINISHING COVER 2 BS6	TATA spare parts
715016324001	FINISHING COVER BS6	TATA spare parts
715016324002	REAR DOOR LOCK COVER FINISH BS6	TATA spare parts
715017003004	TOP HINGE	TATA spare parts
715017003008	PARTITION DOOR STRUCTURE ASSY	TATA spare parts
715017003011	CYLINDER STEP ASSY	TATA spare parts
715017003012	GRAB HANDLE BS6	TATA spare parts
715017003021	PASSENGER DR STRUCTURE & PANEL ASSY_VRL	TATA spare parts
715017004005	TOP FIXED BRACKET ASSEMBLY BS6	TATA spare parts
715017004006	TOP MOVING HING BS6	TATA spare parts
715017004008	ARM ASSEMBLY BS6	TATA spare parts
715017004011	STOPPER	TATA spare parts
715017004015	BOOT ASSEMBLY BS6	TATA spare parts
715017004016	LOCK	TATA spare parts
715017004017	BRUSH	TATA spare parts
715017004018	DOOR ASSY	TATA spare parts
715017004020	PASSENGER DOOR STRUCTURE & PANEL ASSY BS	TATA spare parts
715017004021	24V ELECTRO PNEUMATIC SYS (SINGLE CYL)	TATA spare parts
715017004023	24V WIRE HARNESS(SINGLE CYL)	TATA spare parts
715017004025	PASSENGER DOOR PIVOT HINGE BS6	TATA spare parts
715017004026	DOOR SEALING RUBBER BS6	TATA spare parts
715017004033	COUPLING DIKITTING FOR MAGNA	TATA spare parts
715017004034	PANNELING DIKITTING PARTS FOR MAGNA	TATA spare parts
715017004037	TRIM PNEU DIKITTING PARTS FOR MAGNA	TATA spare parts
715017005033	BUZZER 24V DC	TATA spare parts
715017005034	CONTROLLER 24V RELAY	TATA spare parts
715017005035	5/2 DOUBLE SOLENOID VALVE	TATA spare parts
715017005036	PRESSURE REGULATOR VALVE	TATA spare parts
715017005037	REED SWITCH MAGNETIC SENSOR	TATA spare parts
715017005038	3/2 PUSH PULL VALVE	TATA spare parts
715017005039	EMERGENCY SWITCH INNER	TATA spare parts
715017005040	EMERGENCY SWITCH OUTER	TATA spare parts
715017005041	T CONNECTOR 8X8X6	TATA spare parts
715017005042	T CONNECTOR 8 X 6 X 6	TATA spare parts
715017005043	RED ON/OFF SWITCH	TATA spare parts
715017005044	GREEN ON/OFF SWITCH	TATA spare parts
715017005045	CYLINDER	TATA spare parts
715017005046	PRESSURE SWITCH	TATA spare parts
715017005047	3/2 PILOT OPERATED VALVE	TATA spare parts
715017005048	3/2 SOLENOID VALVE	TATA spare parts
715017005049	SLOW START VALVE	TATA spare parts



715017005050	T CONNECTOR 8X8X8	TATA spare parts
715017005051	PU TUBE OD8 X ID5_20MTR	TATA spare parts
715017005052	AIR FILTER REGULATOR	TATA spare parts
715017005053	QUICK EXHAUST VALVE	TATA spare parts
715017005054	FITTING STRAIGHT MALE 50020-1/4INCHBSP	TATA spare parts
715017005055	FITTING STRAIGHT MALE 50020-1/8INCHBSP	TATA spare parts
715017005056	BALL AND SOCKET JOINT CYL50	TATA spare parts
715017005057	FITTING TEE 55230-TUBE 8/6	TATA spare parts
715017005058	FITTING TEE MALE 55215	TATA spare parts
715017005059	FITTING ELBOW MALE 55115 1/8-8/6	TATA spare parts
715017005060	FITTING ELBOW MALE 55115 1/4-8/6	TATA spare parts
715017005061	ANTI PINCH VALVE	TATA spare parts
715017005062	DIA 63X165 STROKE CYLINDER ASSY BS6	TATA spare parts
715017015006	SPACER FOR PASSENGER DOOR PIVOT HINGE BS	TATA spare parts
715017074001	CYLINDER PIVOT PILLER	TATA spare parts
715017084007	STOPPER BRACKET	TATA spare parts
715017085017	METALLIC HAT	TATA spare parts
715017213001	ALUMINIUM PROFILE FOR PASSENGER DOOR	TATA spare parts
715017213002	ALUMINIUM PROFILE FOR TOP	TATA spare parts
715017233001	PARTITION DOOR GLASS	TATA spare parts
715017284001	SOLID RUBBER PROFIL BS6	TATA spare parts
715017284002	RUBBER PROFILE 6MTR	TATA spare parts
715017284003	SOLID RUBBER PROFIL BOTTOM BS6	TATA spare parts
715017304004	PVC+ABS PROFILE 1MTR	TATA spare parts
715017304005	DRAIN PLUG RH	TATA spare parts
715017304006	DRAIN PLUG LH	TATA spare parts
715017323010	DOOR BOTTOM ARM COVER BS6	TATA spare parts
715017964001	8X8 STRAIGHT CONNECTOR BS6	TATA spare parts
715017965001	24VDC COIL WITH LED	TATA spare parts
715018003003	AUDACE FRP FRONT BUMPER ASSEMBLY	TATA spare parts
715018003004	FRONT FLAP ASSEMBLY	TATA spare parts
715018003009	LH ARM GUIDE BRACKET ASSY	TATA spare parts
715018003010	RH ARM GUIDE BRACKET ASSY	TATA spare parts
715018003011	FRONT FLAP WITH STR GRILL ASSY	TATA spare parts
715018003012	FLAP GUIDE LOCK ASSY-RH	TATA spare parts
715018003013	FLAP GUIDE LOCK ASSY-LH	TATA spare parts
715018003014	FRONT BUMPER ASSLY_MAGNA	TATA spare parts
715018003020	FRONT FLAP WITH FRAME ASSY_MAGNA BS6 BS6	TATA spare parts
715018003022	FRONT FACE ASSY MAGNA 6.5 WITH FOG LAMP	TATA spare parts
715018003025	FRONT FACE ASSY MAGNA 6.5 W/O FOG LAMP B	TATA spare parts
715018003026	FRONT FACE ASSY_MAGNA SLEEPER_VRL BS6	TATA spare parts
715018075001	STAY ROD	TATA spare parts
715018083004	FRONT BUMPER GRILL_RH	TATA spare parts
715018083005	FRONT BUMPER GRILL_LH	TATA spare parts
715018083015	FRONT FACE TOP MESH BS6	TATA spare parts
715018085035	AUDACE FRONT BUMPER FITMENT BKT¿ LH & RH	TATA spare parts
715018184004	MAGNA FRONT FACE MESH_1 BS6	TATA spare parts

715018184005	MAGNA FRONT FACE MESH_2 BS6	TATA spare parts
715018184006	MAGNA FRONT FLAP MESH_BS6	TATA spare parts
715018213001	FRONT FINISHING PROFILE LH BS6	TATA spare parts
715018213002	FRONT FINISHING PROFILE RH BS6	TATA spare parts
715018213003	RAIN GUTTER PROFILE BS6	TATA spare parts
715018213004	RAIN GUTTER PROFILE RH BS6	TATA spare parts
715018263001	FRP FRONT FACE	TATA spare parts
715018912002	LPO 1618 FRONT FLAP FITMENT_AUDACE	TATA spare parts
715019003011	REAR BUMPER ASSY	TATA spare parts
715019074001	HINGED DOOR LATCH COVER	TATA spare parts
715019263005	FRP REAR FACE W/O RLB	TATA spare parts
715019263006	REAR FACE WITH INTEGRATED BUMPER	TATA spare parts
715019263007	REAR FACE WITH INTGRATED BUMPER BS6	TATA spare parts
715019263012	REAR FACE_SLEEPER VRL BS6	TATA spare parts
715019264006	REAR FACE MAGNA 6.5 WITH FOG LAMP	TATA spare parts
715019264008	REAR FACE MAGNA 6.5 W/O FOG LAMP BS6	TATA spare parts
715019304001	HINGE DOOR LATCH ASSEMBLY	TATA spare parts
715020003006	INTERNAL HINGE BS6	TATA spare parts
715020003021	ENGINE FORT FLAP LOCKING ROD ASSY	TATA spare parts
715020003022	LUGGAGE FLAP ASSY RH	TATA spare parts
715020003023	ENGINE FRONT FLAP LOCKING ROD ASSY	TATA spare parts
715020003024	LUGGAGE FLAP ASSY LH	TATA spare parts
715020003026	BATTERY FLAP STRUCTURE PANEL ASSEMBLY BS	TATA spare parts
715020003029	LUGGAGE FLAP ASSY- REAR END LH	TATA spare parts
715020003031	LUGGAGE FLAP ASSY-RH REAR END	TATA spare parts
715020003032	SLB LOCK	TATA spare parts
715020003033	RH BATTERY FLAP STRUCTURE PANEL ASSY	TATA spare parts
715020003040	SLB FLAP ASSY WITH SIDE MARKER HOLE BS6	TATA spare parts
715020003045	RH DIESEL PUMP FLAP STRUCTURE PANEL ASSY	TATA spare parts
715020003047	SLB FLAP OF APERTURE 1600X675 BS6	TATA spare parts
715020003048	SLB FLAP OF APERTURE 1200X675 BS6	TATA spare parts
715020003049	SLB FLAP LOCKING ROD ASSY_1513MM BS6	TATA spare parts
715020003050	SLB FLAP LOCKING ROD ASSY_1108MM BS6	TATA spare parts
715020003088	BATTRY FLAP STR PANEL ASSY BS6	TATA spare parts
715020003089	RH DIESEL PUMP FLAP STRUCTURE PANEL ASSY	TATA spare parts
715020003133	LUGGAGE FLAP ASSY LH BS6	TATA spare parts
715020003134	SLB FLAP ASSY RH BS6	TATA spare parts
715020003138	LUGGAGE FLAP ASSY LH BS6	TATA spare parts
715020003144	LUGGAGE FLAP ASSY-RH REAR END BS6	TATA spare parts
715020003148	LUGGAGE FLAP ASSY- REAR END LH BS6	TATA spare parts
715020003153	LUGGAGE FLAP ASSY LH BS6	TATA spare parts
715020004009	LOCK HOUSING	TATA spare parts
715020004035	AIR FILTER FLAP STRUCTURE PANEL ASSY	TATA spare parts
715020004067	LOCK ROD HOUSING BS6	TATA spare parts
715020004087	VRL LOCK ASSY - 01 BS6	TATA spare parts
715020004088	VRL LOCK ASSY- 04 BS6	TATA spare parts
715020004089	VRL LOCK ASSY - 02 BS6	TATA spare parts

715020004090	VRL LOCK ASSY - 03 BS6	TATA spare parts
715020005004	7 POINT HINGE LH	TATA spare parts
715020005005	7 POINT HINGE RH	TATA spare parts
715020005006	CYLINDER PIVOT ASSY	TATA spare parts
715020005007	CYLINDER PIVOT ASSY RH	TATA spare parts
715020085009	LOCK BRACKET BS6	TATA spare parts
715020085030	PIN WITH SPHERICAL HEAD & CHANNEL	TATA spare parts
715020086001	SIDE LUGGAGE LOCK PLATE	TATA spare parts
715020184002	SKIRT PANEL REAR WHEEL ARCH - LH & RH` B	TATA spare parts
715020184003	SKIRT PANEL REAR WHEEL ARCH -RH BS6	TATA spare parts
715020184017	SKIRT PANEL REAR WHEEL ARCH -RH BS6	TATA spare parts
715020184022	SKIRT PANEL REAR WHEEL ARCH - LH BS6	TATA spare parts
715020185016	SKIRT PANEL FOR AIR FILTER-BOTTOM BS6	TATA spare parts
715020185024	SKIRT PANEL FOR ABOVE AF FLAP RH BS6	TATA spare parts
715020185025	SKIRT PANEL FOR FRONT END RH BS6	TATA spare parts
715020185026	SKIRT PANEL FOR FRONT END LH BS6	TATA spare parts
715020185027	SKIRT PANEL FRONT WHEEL ARCH LH BS6	TATA spare parts
715020185038	SKIRT PANEL FOR REAR END -RH BS6	TATA spare parts
715020185039	SKIRT PANEL FOR REAR END -LH BS6	TATA spare parts
715020185056	SKIRT PANEL FOR DIESEL TANK_RH BS6	TATA spare parts
715020185066	FIXED SKIRT PANEL_RH 553 BS6	TATA spare parts
715020185067	SKRT PNL FOR BG FTSTP FRT WHL ARCH RH BS	TATA spare parts
715020185135	SKIRT PANEL FRONT WHEEL ARCH LH BS6	TATA spare parts
715020185136	SKIRT PANEL LH BS6	TATA spare parts
715020185137	FIXED SKIRT PANEL_RH 553 BS6	TATA spare parts
715020185139	SKIRT PANEL LH & RH BS6	TATA spare parts
715020185148	SKRT PNL BG FTSTP FRT W_ARCH RH BS6	TATA spare parts
715020185150	SKIRT PANEL FOR ABOVE AF FLAP RH BS6	TATA spare parts
715020185151	SKIRT PANEL FOR AIR FILTER-BOTTOM BS6	TATA spare parts
715020185153	SKIRT PANEL RH _1822 BS6	TATA spare parts
715020185184	SKT PANEL FRONT END LH BS6	TATA spare parts
715020185185	SKT PANEL FRONT END RH BS6	TATA spare parts
715020185186	VRL SKIRT PANEL FOR REAR END RH BS6	TATA spare parts
715020185187	VRL SKIRT PANEL FOR REAR END -LH BS6	TATA spare parts
715020263003	EMERGENCY_FOOT_STEP BS6	TATA spare parts
715020285001	PACKING O RING	TATA spare parts
715021002003	DRIVER PARTITION DOOR ASSY	TATA spare parts
715021003002	LIMITER ASSY	TATA spare parts
715021003003	PARTITION DOOR STRUCTURE ASSEMBLY BS6	TATA spare parts
715021233001	PARTITION DOOR GLASS BS6	TATA spare parts
715021324001	ABS PARTITION DOOR FINISH	TATA spare parts
715021324002	ABS PARTITION DOOR FINISH DS	TATA spare parts
715021324003	PARTITION DOOR COVER PS-SIDE BS6	TATA spare parts
715021324004	PARTITION DOOR COVER DR-SIDE BS6	TATA spare parts
715028003011	STRETCH PANEL SUPPORT_FRONT	TATA spare parts
715028003012	STRETCH PANEL SUPPORT IN EMG AREA	TATA spare parts
715028003013	STRETCH PANEL SUPPORT AT REAR BS6	TATA spare parts

715028004001	STRETCH PANEL SUPPORT AT REAR	TATA spare parts
715028083011	STRETCH PANEL SUPPORT	TATA spare parts
715028083012	SUPPORT PLATE FOR EMG DOOR HINGE	TATA spare parts
715028083013	PANEL SPACER PLATE	TATA spare parts
715028083014	STRETCH PANEL END PLATE FINISHING RH	TATA spare parts
715028083015	STRETCH PANEL END PLATE FINISHING LH	TATA spare parts
715028083016	EMG DOOR TOP PACKING PLATE LH & RH	TATA spare parts
715028083018	EMG DOOR TOP PACKING PLATE LH & RH BS6	TATA spare parts
715028083035	PANEL SPACER PLATE BS6	TATA spare parts
715028083070	EME DOOR TOP PACKING PLATE LH & RH_CTU B	TATA spare parts
715028083071	DRIVER DOOR TOP PACKING PLATE BS6	TATA spare parts
715028083075	STRETCH PANEL SLEEPER VRL BS6	TATA spare parts
715028083076	STRETCH PANEL SLEEPER VRL BS6	TATA spare parts
715028083077	STRETCH PANEL SLEEPER VRL BS6	TATA spare parts
715028083079	SIDE PANEL SLEEPER VRL BS6	TATA spare parts
715028083080	SIDE PANEL RH SLEEPER VRL BS6	TATA spare parts
715028083082	SIDE WINDOW PILLAR CLOSING PANEL BS6	TATA spare parts
715028083083	SIDE WINDOW PILLAR CLOSING PANEL_2 BS6	TATA spare parts
715028083084	RH SIDE DRIVER 1ST PILLAR CLOSING PANEL	TATA spare parts
715028083085	LH STRETCH PANEL UPPER SLEEPER VRL BS6	TATA spare parts
715028083086	RH STRETCH PANEL UPPER SLEEPER VRL BS6	TATA spare parts
715028083087	LH FRONT SCOPE WINDOW TUBE PANEL BS6	TATA spare parts
715028083088	FROM SOLIDWORKS BS6	TATA spare parts
715028084007	STRETCH PANEL	TATA spare parts
715028084013	STRETCH PANEL 8040	TATA spare parts
715028084014	STRETCH PANEL 1450	TATA spare parts
715028084015	EMG DOOR BOTTOM L-ANGLE 825	TATA spare parts
715028084040	STRETCH PANEL SLEEPER BS6	TATA spare parts
715028183001	ALU STRETCH PANEL REAR GLASS BOTTOM RH	TATA spare parts
715028183002	ALU STRETCH PANEL REAR GLASS BOTTOM LH	TATA spare parts
715029003008	INSPECTION COVER ASSY	TATA spare parts
715029003024	INSPECTION COVER ASSY_580X492 BS6	TATA spare parts
715040074001	SQUARE HEAD SCREW	TATA spare parts
715042002015	PANEL PLATE ASSY RH NEW D/B BS6	TATA spare parts
715042003004	PANEL PLATE ASSY MAGNA ERGO PACK	TATA spare parts
715042003010	PANEL PLATE ASSY -MAGNA WITH RETARDER	TATA spare parts
715042003012	PANEL PLATE ASSY WITH HVAC S/W	TATA spare parts
715042003016	PANEL PLATE ASSY-MAGNA CTU	TATA spare parts
715042003020	LH PANEL PLATE WITH TFT AND DVD CUTOUT B	TATA spare parts
715042082001	RH PANEL PLATE MAGNA 1622 BS6	TATA spare parts
715042083016	PANEL PLATE LH NEW D/B BS6	TATA spare parts
715042083019	LH PANEL PLATE	TATA spare parts
715042084013	LH_PANEL_PLATE_SLEEPER BS6	TATA spare parts
715042084014	RH_PANEL_PLATE_SLEEPER	TATA spare parts
715042084017	RH_PANEL_PLATE_SLPR BS6	TATA spare parts
715042362011	DESTINATION BOARD POWER SUPPLY HARNESS	TATA spare parts
715042363011	HATRACK WIRING HARNESS	TATA spare parts

715042363012	HATRACK CONSOLE WIRING HARNESS	TATA spare parts
715042363018	TAIL LAMP WIRING HARNESS LH	TATA spare parts
715042363019	TAIL LAMP WIRING HARNESS RH	TATA spare parts
715042363024	EMERGENCY DOOR WIRING HARNESS	TATA spare parts
715042363025	MONITOR WIRING HARNESS	TATA spare parts
715042363032	SPEAKER WIRING HARNESS CDS	TATA spare parts
715042363033	DASHBOARD ELECTRIC HARNESS	TATA spare parts
715042363034	REAR BOOTH LAMP WIRING HARNESS	TATA spare parts
715042363035	LAMP WIRING HARNESS	TATA spare parts
715042363036	UPPER FRONT ELECRCIC HARNESS	TATA spare parts
715042363038	INTERNAL LAMP HARNESS CDS	TATA spare parts
715042363040	SIDE MARKER & BLINKER WIRING HARNESS	TATA spare parts
715042363042	POWER SUPPLY DC-AC INVERTER WH	TATA spare parts
715042363043	STOP REQUEST HARNESS	TATA spare parts
715042363044	MOBILE CHARGER SOCKET WIRING HARNESS	TATA spare parts
715042363045	AC SUPPLY ELECTRICAL HARNESS	TATA spare parts
715042363047	ELECTRONIC CUT OFF TO STARTER MOTOR	TATA spare parts
715042363048	BATTERY TO STARTER MOTOR CONNECTION	TATA spare parts
715042363049	PIGTAIL FOR RETARDER SWITCH	TATA spare parts
715042363051	UPPER FRONT ELECTRICAL HARNESS_MAGNA	TATA spare parts
715042363053	CONVERTER O/P TO TV SUPPLY HARNESS	TATA spare parts
715042363061	SPEAKER WIRING HARNESS_MAGNA_DS	TATA spare parts
715042363062	SPEAKER WIRING HARNESS_MAGNA_CDS	TATA spare parts
715042363063	REAR STOP LAMP PIGTAIL HARNESS_MC	TATA spare parts
715042363064	MANUAL DESTINATION BOARD HARNESS_MAGNA	TATA spare parts
715042363065	REAR STOP LAMP PIGTAIL HARNESS RH_MC	TATA spare parts
715042363066	PASSENGER FAN SWITCH & INTERCONNECTION	TATA spare parts
715042363067	PASSENGER FAN HARNESS_5 FANS	TATA spare parts
715042363068	PIGTAIL 6.3MM TODIN 5-PIN¿ M/F	TATA spare parts
715042363069	RVM HARNESS_MAGNA	TATA spare parts
715042363070	ROOF MARKER TO RVM LAMP PIGTAIL HARNESS	TATA spare parts
715042363071	PIGTAIL HARNESS FOR DIGITAL CLOCK	TATA spare parts
715042363072	MOBILE CHARGER USB WIRING HARNESS	TATA spare parts
715042363073	MOBILE CHARGER HARNESS_DS	TATA spare parts
715042363074	MOBILE CHARGER HARNESS_USB	TATA spare parts
715042363078	HARNESS 600MM LED STRIP	TATA spare parts
715042363079	PIGTAIL HARNESS FOR 600MM LED STRIP	TATA spare parts
715042363080	INVERTER AND CONVERTER¿ SUPPLY HARNESS	TATA spare parts
715042363081	AIS140 EMERGENCY SW HARNESS 62WB	TATA spare parts
715042363083	GANGWAY LAMP & USB HARNESS	TATA spare parts
715042363085	SPEAKER HARNESS_ALL CONSOLES	TATA spare parts
715042363086	POWER SUPPLY DC-AC INVERTER WH_TROPICOO	TATA spare parts
715042363087	PIGTAIL HARNESS FOR SIDE MARKER BS3	TATA spare parts
715042363088	PIGTAIL HARNESS FOR AMPLIFIER SWITCH	TATA spare parts
715042363090	ITS W/H POWER ELECTRONICS	TATA spare parts
715042363091	PANIC BUTTON SITCH W/H	TATA spare parts
715042363092	4 CORE DATA CABLE 15 MTR	TATA spare parts

715042363093	4 CORE DATA CABLE 3 MTR	TATA spare parts
715042363095	SPEAKER HARNESS RH	TATA spare parts
715042363097	SPEAKER HARNESS LH	TATA spare parts
715042363098	DASHBOARD ELECTRICAL HARNESS	TATA spare parts
715042363099	DATA CABLE 15 MTR	TATA spare parts
715042363100	EMERGENCY DECLARATION HARNESS	TATA spare parts
715042363101	PIGTAIL FOR MOBILE CHARGER HARNESS_ USB	TATA spare parts
715042363102	PIGTAIL HARNESS FOR AMPLIFIER SWITCH	TATA spare parts
715042363103	STOP REQUEST HARNESS BS6 MAGNA BS6	TATA spare parts
715042363105	SPEAKER WIRING HARNESS RH SIDE	TATA spare parts
715042363106	SPEAKER WIRING HARNESS LH SIDE	TATA spare parts
715042363107	MONITOR TO SPEAKER HARNESS	TATA spare parts
715042363108	EMERGENCY DOOR WIRING HARNESS BS6	TATA spare parts
715042363110	POWER SUPPLY CABLE FOR MNVR	TATA spare parts
715042363113	AC TWIN BLOWER POWER SUPPLY 1623 BS6	TATA spare parts
715042363124	UPPER FRONT HARNESS BS6	TATA spare parts
715042363125	DASHBOARD HARNESS BS6	TATA spare parts
715042363126	LOWER ELECTRICAL HARNESS BS6	TATA spare parts
715042363127	AIS 140 S/W HARNESS BS6	TATA spare parts
715042363135	POWER SUPPLY PIGTAIL_ SLEEPER BS6	TATA spare parts
715042363137	PIGTAIL FOR INTERNAL LAMP BS6	TATA spare parts
715042363138	AIS140 SWITCH ASSY 69WB	TATA spare parts
715042363140	AIS140 SW HARNESS CO DRIVER SIDE	TATA spare parts
715042363141	PIGTAIL FOR SPEAKER HARNESS BS6	TATA spare parts
715042363146	INTERNAL LAMP HARNESS SLEEPER BS6	TATA spare parts
715042363150	SIDE MARKER LAMP HARNESS BS6	TATA spare parts
715042363157	WASHER TANK PIGTAIL_ SLEEPER BS6	TATA spare parts
715042363158	READING LAMP POWER SUPPLY HARNESS BS6	TATA spare parts
715042363159	PASSENGER MOBILE CHARGER SUPPLY HARNESS	TATA spare parts
715042363160	RFID POWER SUPPLY PROVISION HARNESS BS6	TATA spare parts
715042363163	BLOWER W/H BS6	TATA spare parts
715042363164	DIGITAL CLOCK PIGTAIL BS6	TATA spare parts
715042363165	HATRACK CONSOLE LAMP & SWITCH PIGTAIL BS	TATA spare parts
715042363166	CONSOLE POWER SUPPLY PIGTAIL TAIL BS6	TATA spare parts
715042363169	STOP REQUEST CABLE	TATA spare parts
715042363172	MOBILE CHARGER POWER SUPPLY HARNESS	TATA spare parts
715042363189	WH SPEAKER 5 BRANCH BS6	TATA spare parts
715042363190	WH BERTH READING LAMP_ MOBILE CHG LH BS6	TATA spare parts
715042363191	WH BERTH READING LAMP_ MOBILE CHG RH BS6	TATA spare parts
715042363192	W. HARNESS BERTH INTERCONN LH BS6	TATA spare parts
715042363193	W. HARNESS BERTH INTERCONN RH BS6	TATA spare parts
715042363194	STEP LAMP PIGTAIL BS6	TATA spare parts
715042363195	W. HARNESS BERTH MOOD LAMP LH BS6	TATA spare parts
715042363196	W. HARNESS BERTH MOOD LAMP RH BS6	TATA spare parts
715042363197	W.HARNESS UPPERFRONT BS6	TATA spare parts
715042363198	W.HARNESS DASHBOARD BS6	TATA spare parts
715042374010	REAR TOP MARKER LAMP - RH	TATA spare parts

715042374011	REAR TOP MARKER LAMP - LH	TATA spare parts
715042963001	TFT MONITOR WITH SHROUD BS6	TATA spare parts
715050003036	AC DUCT WITH HATRACK SUB-ASSY RH SIDE	TATA spare parts
715050003037	AC DUCT WITH HATRACK SUB-ASSY LH SIDE	TATA spare parts
715050003058	AC DUCT WITH HATRACK SUB-ASSY-LH SIDE	TATA spare parts
715050003069	AC DUCT WITH HATRACK SUB-ASSY-LH SIDE	TATA spare parts
715050003070	AC DUCT WITH HATRACK SUB-ASSY-RH SIDE	TATA spare parts
715050003076	AC DUCT WITH HATRACK SUB-ASSY-LH SIDE	TATA spare parts
715050003077	AC DUCT WITH HATRACK SUB-ASSY-RH SIDE	TATA spare parts
715050003089	AC DUCT WITH HATRACK SUB-ASSY-LH SIDE	TATA spare parts
715050003090	AC DUCT WITH HATRACK SUB-ASSY-RH SIDE	TATA spare parts
715050004022	HATRACK MOUNTING BRACKET ASSY	TATA spare parts
715050183101	HATRACK LUGGAGE AREA CLOSING PANEL 2000L	TATA spare parts
715050183102	HATRACK LUGGAGE AREA CLOSING PANEL 1605L	TATA spare parts
715050183103	HATRACK LUGGAGE AREA CLOSING PANEL 235L	TATA spare parts
715050183104	HATRACK LUGGAGE AREA CLOSING PANEL 1260L	TATA spare parts
715050264013	FRP BLOWER COVER BS6	TATA spare parts
715050264022	AC HOSE FINISHING COVER_LH	TATA spare parts
715050264023	AC HOSE FINISHING COVER TOP_RH	TATA spare parts
715050303001	HOSE (VENTILATION)	TATA spare parts
715050304001	HATRACK BRACKET COVER	TATA spare parts
715050304004	RVM CAP BS6	TATA spare parts
715050304005	AC CONTROLLER CAP	TATA spare parts
715050304006	HVAC CAP BS6	TATA spare parts
715050324001	HATRACK BRACKET COVER	TATA spare parts
715050963002	ASSY AC UNIT	TATA spare parts
715050963006	CC-430 AC UNIT BS6	TATA spare parts
715050963011	COMP MTG BRKT ASSY WITHOUT ALT. BS6	TATA spare parts
715050963020	7/8-45 DG (CRIMP TYPE) X FLANGE BS6	TATA spare parts
715050963021	LP-HP L-SHAPE ADAPTOR BS6	TATA spare parts
715050963032	MAIN WIRING HARNESS BS6	TATA spare parts
715050963033	FUSE TO BATTERY CUT OFF CABLE BS6	TATA spare parts
715050963046	EVAPORATER COIL LH CC355 BS6	TATA spare parts
715050963047	EVAPORATER COIL RH CC355 BS6	TATA spare parts
715050963050	TEMP SENSOR REF SP-S030 BS6	TATA spare parts
715050963052	RESISTENCE 100 OHM 50V BS6	TATA spare parts
715050963053	DIODE BS6	TATA spare parts
715050963057	TERMINAL BLOCK M-10 BS6	TATA spare parts
715050963059	ROOF WIRING HARNESS 355 BS6	TATA spare parts
715050963075	4 FANS CONDENSER CLOSING CC355 BS6	TATA spare parts
715050963078	SIGHT GLASS TUBE ASSY CC355 BS6	TATA spare parts
715050963079	TUBE ASSY. RECEIVER BOTTLEFILTER BS6	TATA spare parts
715050963089	CONDENSOR W/H CC355 SETBUS BS6	TATA spare parts
715050963092	LIQUID LINE FROM RECEIVER BS6	TATA spare parts
715050963094	COND COVER VX430 BS6	TATA spare parts
715050963096	TUBE ASSY (MFC_OUT X RD_IN)-CC354 BS6	TATA spare parts
715050963097	LIQUID LINE-1 (RD_OULET)-CC354 BS6	TATA spare parts

715050963098	SUCTION ASSY_EVP.XCOMP. CC 350 BS6	TATA spare parts
715050963099	EVAPORATOR COVER CC350 BS6	TATA spare parts
715050963100	LIQUID LINE VX430 TO TXV BS6	TATA spare parts
715050963101	EVAP. COIL RH CC350 W/H ORING CONN. BS6	TATA spare parts
715050963102	EVAP. COIL LH CC350 W/H ORING CONN. BS6	TATA spare parts
715050963104	RELAY BOARD SBF264 BS6	TATA spare parts
715050963107	DIODE IN 5408 BS6	TATA spare parts
715050963108	BRUSHLESS BLOWER MOTOR PIGTAIL BS6	TATA spare parts
715050963113	AIR FILTER 1400X178X20 BS6	TATA spare parts
715050963114	DASH CONTROL SBU410 (SW2) BS6	TATA spare parts
715050963129	PCB GRND TO EARTH CABLE ASSY 35MM BS6	TATA spare parts
715050963131	MAIN WH FICD CC355 SEIRES BS6	TATA spare parts
715050963132	ASSY POWER CABLE 35 SQMM RED BS6	TATA spare parts
715050963139	COMPRESSOR QP65_CCW_220/260MM 2B/2A BS6	TATA spare parts
715050963140	BANDED BELT BX 89( 2-GROOVE) BS6	TATA spare parts
715050963141	COMP. MTG BKT ASSY WITHOUT ALT. BS6	TATA spare parts
715050964002	BANDED BELT-BX82 ( BS- 4)	TATA spare parts
715050964004	FUSE 125A	TATA spare parts
715050964005	ALTERNATOR 150 AMP 24V	TATA spare parts
715050964006	FUSE BOX W/O CU PLATE(125A/100A)	TATA spare parts
715050964007	COMPRESSOR W/H WB042005	TATA spare parts
715050964008	MAIN W/H WB042302	TATA spare parts
715050964009	WIRE HARNESS¿ WB0150107	TATA spare parts
715050964010	MFC COIL CC355 (006-00165-000)	TATA spare parts
715050964011	EVAPORATER COIL LH CC355	TATA spare parts
715050964012	EVAPORATER COIL RH CC355	TATA spare parts
715050964013	RELAY BOARD GLT047 24V	TATA spare parts
715050964014	CAPACITOR 63V 10000UF	TATA spare parts
715050964015	FILTER DRIER DML 305 FS IN/OT 5/8	TATA spare parts
715050964016	EXPANSION VALVE-3.5T/EWB-35M001	TATA spare parts
715050964017	PULLEY DIA-114 MM	TATA spare parts
715050964018	PULLEY_COMPRESSOR DIA_175X250	TATA spare parts
715050964019	ROOF WIRING HARNESS CC355	TATA spare parts
715050964020	1.1/8 STRAT (CRIMPTYPE) XFLANGE	TATA spare parts
715050964021	1.1/8-90 DG (CRIMP TYPE) X FLANGE	TATA spare parts
715050964022	7/8-STRAIGHT(CRIMP TYPE) XFLANGE	TATA spare parts
715050964023	7/8 90 DG( CRIMP TYPE)XFLANGE	TATA spare parts
715050964024	REFRIGERANT ACCUMULATOR 3L AL CC355	TATA spare parts
715050964025	COND./EVAP. COVER FIBER CC355	TATA spare parts
715050964026	CENTRAL CLOSING PLATE CC355	TATA spare parts
715050964027	FOAM NBR 2766X20X6 MM	TATA spare parts
715050964030	GAS HOSE 16 (DISCHARGE)	TATA spare parts
715050964031	GAS HOSE 20 (SUCTION)	TATA spare parts
715050964038	TWIN BLOWER BS6	TATA spare parts
715050964039	HVAC SWITCH	TATA spare parts
715050964044	AC COMPRESSOR BANDED BELT BX86 (BS-6) BS6	TATA spare parts
715051003004	PARTITION WALL SUPP HANDLE ASSY TOP	TATA spare parts



715051003005	STEP PARTITION WALL SUPP HANDLE ASSY	TATA spare parts
715051003006	BERTH LADDER ASSY	TATA spare parts
715051063009	TUBE BS6	TATA spare parts
715051303002	BRACKET BS6	TATA spare parts
715052003004	FRP DASHBOARD ASSY	TATA spare parts
715052003005	ENGINE HOOD ASSY	TATA spare parts
715052003006	FRONT INNER ASSY	TATA spare parts
715052003015	FRP DASHBOARD ASSEMBLY	TATA spare parts
715052003016	MAGNA ENGINEHOOD & DASHBOARD ASSY	TATA spare parts
715052003017	LPO 1618 FRONT INNER ASSY	TATA spare parts
715052003019	FRONT INNER ASSY (DESTINATION BOARD)	TATA spare parts
715052003024	FUSE BOX COVER ASSBLY_BS6 BS6	TATA spare parts
715052003029	MAGNA_BS6 AC FRONT INNER ASSY BS6	TATA spare parts
715052003033	BS6_ENGINE HOOD ASSY BS6	TATA spare parts
715052003034	BS6_DASHBOARD & ENGINE HOOD ASSY BS6	TATA spare parts
715052003036	BS6_GSL COVER SUB ASSEMBLY BS6	TATA spare parts
715052003038	FRONT INNER ASSY MAGNA_SLEEPER BS6	TATA spare parts
715052003042	FRONT INNER ASSY MAGNA 6.5 BS6	TATA spare parts
715052003049	FRONT INNER ASSY_HALF PARTITION	TATA spare parts
715052003053	CLUSTER ASSEMBLY BS6	TATA spare parts
715052003054	DASHBOARD ASSEMBLY ASSY SLEEPER BS6	TATA spare parts
715052004005	LPO 1618 FRP RADIATOR FLAP ASSY	TATA spare parts
715052004006	LPO 1618 FRP COMPRESSOR FLAP ASSY	TATA spare parts
715052004017	BS6_DASH BOARD INSULATION ASSY BS6	TATA spare parts
715052004018	BS6_TOP FIXED FLAP SUB ASSY BS6	TATA spare parts
715052004019	BS6_FRP COMPRESSOR FLAP ASSY BS6	TATA spare parts
715052183001	LPO 1618 EXT B-PILLAR LH1 ALUMINIUM	TATA spare parts
715052183002	LPO 1618 EXT B-PILLAR LH2 ALUMINIUM	TATA spare parts
715052183003	LPO 1618 EXT B-PILLAR LH3 ALUMINIUM	TATA spare parts
715052183004	LPO 1618 EXT B-PILLAR RH1 ALUMINIUM	TATA spare parts
715052183005	LPO 1618 EXT B-PILLAR RH2 ALUMINIUM	TATA spare parts
715052183006	LPO 1618 EXT B-PILLAR RH3 ALUMINIUM	TATA spare parts
715052263005	FRP PASSENGER DOOR ARM COVER 1	TATA spare parts
715052263006	FRP PASSENGER DOOR ARM COVER 2	TATA spare parts
715052263022	LPO 1618 FRP PASSENGER STEP COVER BS6	TATA spare parts
715052263026	LPO 1618 FRONT WHEEL ARC LH FRP	TATA spare parts
715052263027	LPO 1618 FRONT WHEEL ARC RH FRP	TATA spare parts
715052263028	LPO 1618 REAR WHEEL ARC FRP	TATA spare parts
715052263031	FRP REAR INNER	TATA spare parts
715052263036	FRP REAR INNER (DESTINATION BOARD)	TATA spare parts
715052263045	BS6_FRP CLUSTER RING BS6	TATA spare parts
715052263047	FRP DRIVER DOOR FOOT STEP BS6	TATA spare parts
715052263049	HARNESS COVER_MAGNA 6.5 BS6	TATA spare parts
715052263050	A-PILLAR COVER RH MAGNA_6.5 BS6	TATA spare parts
715052263051	A-PILLAR COVER LH MAGNA_6.5 BS6	TATA spare parts
715052263053	ENGINE HOOD COVER SLEEPER BS6	TATA spare parts
715052264020	AC COVER RH	TATA spare parts

715052264039	BS6_FRP INSTRUMENT CLUSTER BS6	TATA spare parts
715052264046	MAGNA_BS6 FRP DRI CABIN RH BS6	TATA spare parts
715052264047	GNA_BS6 FRP DRI CABIN LH BS6	TATA spare parts
715052264064	CENTRAL FUSE BOX COVER (SLEEPER) BS6	TATA spare parts
715052264065	CENTRAL FUSE BOX FLAP -SLEEPER_BS6	TATA spare parts
715052264070	AC HOSE FINISHING COVER BOTTOM_RH	TATA spare parts
715052264083	MAGNA SLEEPER FRP DRI CABIN LH BS6	TATA spare parts
715052264084	MAGNA SLEEPER FRP DRI CABIN RH_VRL BS6	TATA spare parts
715052264087	FRONT INNER MAGNA_NON AC SLEEPER BS6	TATA spare parts
715052264088	MAGNA_SLEEPER A-PILLAR LH_NAC BS6	TATA spare parts
715052264089	MAGNA_SLEEPER A-PILLAR RH_NAC BS6	TATA spare parts
715052264094	CLUSTER RING_SLEEPER BS6	TATA spare parts
715052304003	FRONT INTERNAL SPEAKER GRILL LH	TATA spare parts
715052304004	FRONT INTERNAL SPEAKER GRILL RH	TATA spare parts
715052323021	AUDACE DRIVER DOOR INTERIOR COVER PART B	TATA spare parts
715052323022	EURO N4 GEAR FINISHING COVER BS6	TATA spare parts
715052324003	ABS DRIVER DOOR COVERING	TATA spare parts
715052324004	ABS DRIVER DOOR CONSOLE	TATA spare parts
715052324009	HINGE COVER AUDACE	TATA spare parts
715052324012	FRONT INTERNAL SPEAKER GRILL RH	TATA spare parts
715052324013	FRONT INTERNAL SPEAKER GRILL LH	TATA spare parts
715052324024	MAGNA_BS6 A-PILLAR RH BS6	TATA spare parts
715052324025	MAGNA_BS6 A-PILLAR LH BS6	TATA spare parts
715052324051	ABS DRIVER DOOR CONSOLE_AUDACE BS6	TATA spare parts
715052325001	ABS DRIVER DOOR COVER_VRL_NON AC BS6	TATA spare parts
715052335001	MAGNA STEERING COLUMN FINISHING BS6	TATA spare parts
715053003018	ABS MODULE REINF ASSY 703L	TATA spare parts
715053003021	ABS MODULE REINF ASSY 868L	TATA spare parts
715053003033	ABS MODULE REINF ASSY 481L	TATA spare parts
715053003034	ABS MODULE REINF ASSY 481L	TATA spare parts
715053003035	ABS MODULE REINF ASSY 414L	TATA spare parts
715053003036	ABS MODULE REINF ASSY 242L	TATA spare parts
715053264001	AC DUCT END CAP RH REAR & LH FRONT	TATA spare parts
715053264002	AC DUCT END CAP LH REAR & RH FRONT	TATA spare parts
715053324036	ABS MODULE 111L	TATA spare parts
715058333001	MAGNA STICKER MODEL BS6	TATA spare parts
715058963001	MAGNA DECAL STICKER ASSY_KIT	TATA spare parts
715059263001	PNEUMATIC CIRCUIT FINISHING BOX	TATA spare parts
715059263002	PNEUMATIC CIRCUIT FINISHING BOX_NAC BS6	TATA spare parts
715059304005	D TYPE GRAB HANDLE BS6	TATA spare parts
715059304007	CURTAIN HOLDER BS6	TATA spare parts
715059323009	AUDACE DRIVER DOOR INTERIOR COVER PART	TATA spare parts
715059333024	DRIVER PART. DOOR LOCK/UNLOCK STICKER BS	TATA spare parts
715059333029	CURTAIN 1030 X 1300 BS6	TATA spare parts
715060002002	EXTERNAL RVM RH SIDE	TATA spare parts
715060002003	EXTERNAL RVM LH SIDE	TATA spare parts
715060073001	MS BUSH FOR REAR VIEW MIRROR	TATA spare parts

715060963001	SUNVISOR ASSEMBLY_AUDACE BS6	TATA spare parts
715060963002	SUNVISOR ASSEMBLY	TATA spare parts
715060964001	COACH CLASS II MIRROR PLATE BS6	TATA spare parts
715060964002	COACH MIRROR ELECTRICAL ASSY LH & RH BS6	TATA spare parts
715060964003	COACH MIRROR CLASS II WELDED LH/RH BS6	TATA spare parts
715060964004	COACH MIRROR CLASS II ACTUATOR BS6	TATA spare parts
715060964005	COACH MIRROR END OUTLET LAMP BS6	TATA spare parts
715060964006	COACH MIRROR REG CLASS IV HSG BS6	TATA spare parts
715060964007	COACH MIRROR REG CLASS IV HSG & GLASS BS	TATA spare parts
715060964008	COACH MIRROR MTG. BKT. LH & RH BS6	TATA spare parts
715060964009	COACH MIRROR BELLOW BS6	TATA spare parts
715060964010	COACH MIRROR MTG. BKT. COVER BS6	TATA spare parts
715060964011	COACH MIRROR CLASS II INNER HSG CLAMP BS	TATA spare parts
715060964012	MIRROR CONTROLLER SWITCH RECTANGULAR BS	TATA spare parts
715061003019	1LH_2LM_485C535W_AR_BLU_FB_PB_HS_MAGN	TATA spare parts
715061003020	2RH_2LM_485C1025W_AR_BLU_FB_PB_HS_MAG	TATA spare parts
715061003021	5RR_LM_485C2350W_AR_BLU_FB_PB_HS_MAG	TATA spare parts
715061003022	2LH_2LM_485C1025W_AR_BLU_FB_PB_HS_MAG	TATA spare parts
715061003023	AUDACE CO DR.FOLDABLE SEAT_BLUE_FB_NEW	TATA spare parts
715061003029	DRIVER BERTH_FOLDABLE TYPE_AUDACE	TATA spare parts
715061003033	2 SEAT ASSY_RHS_2LM_475C1025W_AR_CS_BLU	TATA spare parts
715061003034	2 SEAT ASSY_LHS_2LM_475C1025W_AR_CS_BLU	TATA spare parts
715061003036	2LH_2LM_485C1025W_AR_LP_BLU_FB_PB_HS_M	TATA spare parts
715061003051	2RH_2LM_475C1025W_AR_BLF89164_PB_HS_M	TATA spare parts
715061003052	5R_LM_475C2400W_AR_LB_BLF89164_PB_HS_M	TATA spare parts
715061003053	2LH_2LM_475C1025W_AR_BLF89164_PB_HS_M	TATA spare parts
715061003054	2LH_2LM_475C1025W_AR_LB_BLF89164_PB_M	TATA spare parts
715061003055	1LH_2LM_485C535W_ARLB_BLF89164_PB_HS_M	TATA spare parts
715061003056	2RH_2LM_475C1025W_AR_BLF89174_PB_HS_M	TATA spare parts
715061003057	5R_LM_475C2400W_AR_LB_BLF89174_PB_HS_M	TATA spare parts
715061003058	2LH_2LM_475C1025W_AR_BLF89174_PB_HS_M	TATA spare parts
715061003059	2LH_2LM_475C1025W_AR_LB_BLF89174_PB_M	TATA spare parts
715061003060	1LH_2LM_485C535W_ARLB_BLF89174_PB_HS_M	TATA spare parts
715061003061	2RH_2LM_475C1025W_AR_BLF89167_PB_HS_M	TATA spare parts
715061003062	5R_LM_475C2400W_AR_LB_BLF89167_PB_HS_M	TATA spare parts
715061003063	2LH_2LM_475C1025W_AR_BLF89167_PB_HS_M	TATA spare parts
715061003064	2LH_2LM_475C1025W_AR_LB_BLF89167_PB_M	TATA spare parts
715061003065	1LH_2LM_485C535W_ARLB_BLF89167_PB_HS_M	TATA spare parts
715061003066	2RH_2LM_475C1025W_ARLB_FB89167_PB_HS_MG	TATA spare parts
715061003067	5R_LM_475C2400W_AR_5LB_FB89167_PB_HS_MG	TATA spare parts
715061003068	2LH_2LM_475C1025W_AR_LB_FB89167_PB_MG	TATA spare parts
715061003088	2RH_2LM_475C1025W_AR_RLF89163_PB_HS_M	TATA spare parts
715061003089	5R_LM_475C2400W_AR_LB_RDF89163_PB_HS_M	TATA spare parts
715061003090	2LH_2LM_475C1025W_AR_RDF89163_PB_HS_M	TATA spare parts
715061003091	2LH_2LM_475C1025W_AR_LB_RDF89163_PB_M	TATA spare parts
715061003092	1LH_2LM_485C535W_ARLB_RDF89163_PB_HS	TATA spare parts
715061003109	2RH_2LM_475C1025W_AR_BLF89167_HS_CRY	TATA spare parts

715061003110	5 RR_4LM_475C2400W_AR_LB_BLF89167_HS C	TATA spare parts
715061003111	2LH_2LM_475C1025W_AR_BLF89167_HS CRY	TATA spare parts
715061003112	2LH_2LM_475C1025W_AR_LB_BLF89167_HS CF	TATA spare parts
715061003113	MECH. SUSPENDED DRIVER SEAT_OSRTC	TATA spare parts
715061003115	3RH SM2L 480C1200W NHBT2 CVG	TATA spare parts
715061003116	3RR 3LM 480C1200W LB NHBT2 CVG	TATA spare parts
715061003117	3RL 3LM 480C1200W LB NHBT2 CVG	TATA spare parts
715061003118	2LH SM1L 480C 850W AR NHBT2 CVG	TATA spare parts
715061003119	2LH SM1L 480C 850W NHBT2 CVG	TATA spare parts
715061003121	2RH SM1L 480C850W AR NHBT2 CVG	TATA spare parts
715061003122	3RH SM2L 480C1200W LB NHBT2 CVG	TATA spare parts
715061003123	2LH SM1L 480C850W NHBT2 LB CVG	TATA spare parts
715061003124	1LH SM1L 480C410W AR NHBT2 CVG	TATA spare parts
715061003138	2RH 2LM 475C1025W AR 3P CS FB89164 PB MG	TATA spare parts
715061003139	5R LM 475C2400W AR 5LB FB89164 PB MG	TATA spare parts
715061003140	2LH 2LM 475C1025W AR 3P CS FB89164 PB MG	TATA spare parts
715061003141	1LH 2LM 475C535W AR 3P CS FB89164 PB MG	TATA spare parts
715061003142	MECH.SUSPENDED DRIVERSEAT FB89164	TATA spare parts
715061003143	5REAR 4LM 475C2400W 3PLB BLFB PB USB HS	TATA spare parts
715061003144	2LH 2LM 475C1025W AR 3PLB BLFB PB USB HS	TATA spare parts
715061003157	2RH_2LM_475C1025W_AR_BLF89167_USB_PB	TATA spare parts
715061003158	5R_LM_475C2400W_AR_LB_FB89167_USB_PBHM	TATA spare parts
715061003159	2LH_2LM_475C1025W_AR_BLF89093_USB_PB	TATA spare parts
715061003160	2LH_2LM_475C1025W_AR_LB_89167_USB_PB_H	TATA spare parts
715061003161	1LH_2LM_475C525W_ARLB_89093_USB_PB_HM	TATA spare parts
715061003168	FOLDABLE SEAT WITH HEAD & FOOT REST BS6	TATA spare parts
715061003197	2RH_2LM_465C920W_AR_3PLB_FB_USB_DLX_HI	TATA spare parts
715061003198	2RL_2LM_465C920W_AR_3PLB_FB_USB_DLX_HN	TATA spare parts
715061003199	1RM_2LM_465C920W_AR_3PLB_FB_USB_DLX_HI	TATA spare parts
715061003200	2RL_2LM_465C920W_AR_3PLB_FB_USB_DLX_HN	TATA spare parts
715061003201	2LH_2LM_465C920W_AR_3PLB_FB_USB_DLX_HN	TATA spare parts
715061003202	2RH_2LM_475C1025W_AR_ART_LEA_USB_PB_H	TATA spare parts
715061003203	5R_LM_475C2400W_AR_ART_LEA_USB_PB_HFB	TATA spare parts
715061003204	22LH_2LM_475C1025W_AR_ART_LEA_USB_PB_H	TATA spare parts
715061003205	1LH_2LM_475C537W_AR_ART_LEA_USB_PB_HF	TATA spare parts
715061003211	MATTRESS_TWIN BERTH(WINDOW SIDE)_UP & LO	TATA spare parts
715061003212	MATTRESS_TWIN & SINGLE BERTH_UP & LO BS	TATA spare parts
715061003213	MATTRESS(FIRST BERTH) FOR SINGLE BERTH B	TATA spare parts
715061003227	SLEEPER_CODRIVER FLIP SEAT WITH FOOTREST	TATA spare parts
715061003232	BOTTLE HOLDER BS6	TATA spare parts
715061003243	SLP_BACKREST CUSHION_430X430X76 THK BS6	TATA spare parts
715061003244	BERTH PARTITION BARRIER_650X433_VRL BS6	TATA spare parts
715061003245	DRIVER BERTH ASSY_1600X550_FOLDABLE BS6	TATA spare parts
715062004001	EMERGENCY WINDOW HAMMER ASSY KIT	TATA spare parts
715062004003	SOLID RUBBER PROFILE BS6	TATA spare parts
715062004005	SPRING HAMMER ASSY BS6	TATA spare parts
715062004006	SAFETY HAMMER	TATA spare parts

715062263001	AIR HATCH INNER CONTOUR BS6	TATA spare parts
715062263003	DRIVER CABIN ROOR HATCH INNER COVER BS6	TATA spare parts
715062264004	ROOR HATCH INNER COUNTER APP 402X384 BS6	TATA spare parts
715062964001	FDSS_PANELING KIT_SAFEX_MAGNA BS6	TATA spare parts
715062964002	FDSS_TRIM KIT_SAFEX_MAGNA BS6	TATA spare parts
715062965001	FDSS SUPPRESSION TUBE ASSLY BS6	TATA spare parts
715062965002	LINEAR HEAT SENSING CABLE ASSLY BS6	TATA spare parts
715062965003	WIRING HARNESS ASSLY BS6	TATA spare parts
715063003002	FRONT DESTINATION BOARD TUBE ASSY BS6	TATA spare parts
715063003008	FRONT DESTINATION SUPPORTING TUBE ASSY B	TATA spare parts
715064003008	RH DRIVER DR_WIND_664X676_CLEAR_4MMTHK	TATA spare parts
715064003009	LH/RH_PEEP WIND_311X495_CLEAR_4MM THK B	TATA spare parts
715064003013	LH_UPP.SLDG WIND_1805X517_50PERC GRY_NA	TATA spare parts
715064003014	LH_UPP.SLDG WIND_1803X517_50PERC GRY_NA	TATA spare parts
715064003015	LH_UPP.SLDG WIND_1643X517_50PERC GRY_NA	TATA spare parts
715064003016	LH_LOW.SLDG WIND_1805X620_50PERC GRY_NA	TATA spare parts
715064003017	LH_LOW.SLDG WIND_1803X620_50PERC GRY_NA	TATA spare parts
715064003018	LH_LOW.SLDG WIND_1643X620_50PERC GRY_NA	TATA spare parts
715064003019	RH_UPP.SLDG WIND_1805X517_50PERC GRY_NA	TATA spare parts
715064003020	RH_UPP.SLDG WIND_1803X517_50PERC GRAY_N	TATA spare parts
715064003021	RH_UPP.SLDG WIND_1643X517_50PERC GRAY_N	TATA spare parts
715064003022	RH_LOW.SLDG WIND_1805X620_50PERC GRAY_N	TATA spare parts
715064003023	RH_LOW.SLDG WIND_1803X620_50PERC GRAY_N	TATA spare parts
715064003024	RH_LOW.SLDG WIND_1643X620_50PERC GRAY_N	TATA spare parts
715064003025	LH CO_DRI.PASS_WIND_600X428_CLEAR_VRL BS	TATA spare parts
715064003026	LH FIXED PASS.DR PEEP WIND_596X474_CLEAR	TATA spare parts
715064003027	LH FIXED PEEP WIND_330X702_CLEAR_VRL BS6	TATA spare parts
715064003028	RH DRIVER DR WIND_669X633_CLEAR_VRL BS6	TATA spare parts
715064003029	RH SCOOP WINDOW ASSY_868X323_CLEAR GLS B	TATA spare parts
715064083001	LH_G.I SHEET_1.55MM THICK BS6	TATA spare parts
715064083002	RH_G.I SHEET_1.55 THICK BS6	TATA spare parts
715064233010	PASTED GLS_LH_463X677_CLEAR GLASS BS6	TATA spare parts
715064233011	LH_PASTED ABV PASSG_790X509_CLEAR BS6	TATA spare parts
715064233013	RH PEEP PASTED_456X748_CLEAR GLS BS6	TATA spare parts
715064233014	RH PASTED_781X304_CLEAR FULL CERA GLS BS	TATA spare parts
715064233016	RH PASTED GLS_695X225_CLEAR FULL CERA BS	TATA spare parts
715064233018	LH/RH PASTED GLS_1350X1072_50PERC GRAY T	TATA spare parts
715064233019	LH REAR PAST_1232X1072_50PERCGRAY TINT B	TATA spare parts
715064233020	RH PASTED GLS_677X1072_50PERC GRAY TINT	TATA spare parts
715064233021	RH EMG.DR PASTED_685X831_50PERC GRAY TNT	TATA spare parts
715064233022	RH REAR PASTED_1206X1072_50PERC GRAY TIN	TATA spare parts
715064233027	REAR RH PASTED GLS_1754X1466_50PERCGRAY	TATA spare parts
715064233062	LH SCOOP WIND_PASTED_463X677_CLEAR GLASS	TATA spare parts
715064233063	LH PASTED_ABV_PASSG_789X512_CLEAR CERA B	TATA spare parts
715064233064	RH SCOOPW_WIND_PASTED_464X1057_CLEAR G	TATA spare parts
715064233065	RH RVM COVER PASTED_622X304_CLEAR GLS BS	TATA spare parts
715064234020	LH/RH PASTED VENT WIN_1350X1072_50PERC G	TATA spare parts

715065002001	WIPER MECHANISM ASSY	TATA spare parts
715065002002	WIPER WATER SPRAYER BUSHING	TATA spare parts
715065002003	WIPER ROD ARM RH-850MM	TATA spare parts
715065002004	WIPER ROD ARM LH-850MM	TATA spare parts
715065002005	WIPER MOTOR ASSEMBLY	TATA spare parts
715065002006	WIPER BLADE ASSY	TATA spare parts
715065002007	WIPER ARM RH_R850_SNAP TYPE	TATA spare parts
715065002008	WIPER ARM LH_R850_SNAP TYPE	TATA spare parts
715065002009	WIPER BLADE_SNAP TYPE_1000MM	TATA spare parts
715065003019	24V WIPER INFO_SNAP TYPE_DOGA (PANELLING	TATA spare parts
715065003020	24V WIPER INFO_SNAP TYPE_DOGA (TRIM KIT)	TATA spare parts
715065233001	REAR WINDSHIELD	TATA spare parts
715065234002	FRONT WINDSHIELD GLASS BS3/4	TATA spare parts
715065234003	FRONT WINDSHIELD GLASS_WITH CERAMIC BS6	TATA spare parts
715065234005	FRONT WINDSHIELD GLASS MAGNA BS6	TATA spare parts
715065284001	FRONT WINDSHIELD RUBBER	TATA spare parts
715065284002	FRONT WINDSHIELD RUBBER MAGNA BS6	TATA spare parts
715065333001	TOP WINDSHIELD_VINYL BS6	TATA spare parts
715065333002	BTTOM WINDSHIELD_VINYL BS6	TATA spare parts
715065912001	WIPER ASSEMBLY DETAILS	TATA spare parts
715065912007	24V WIPER INFO_SNAP TYPE_DOGA BS6	TATA spare parts
715065964001	WIPER SPINDLE	TATA spare parts
71534201	HYDRAULIC CYLINDER LPK 2516TC 6X4	TATA spare parts
71534221	TIPING CYLINDER	TATA spare parts
717020750001	NYLONE CATCHER ASSY.	TATA spare parts
717021770001	NYLON CATCHER BS6	TATA spare parts
717410000001	FUEL TANK LID ASSEMBLY	TATA spare parts
71901430K	COMPLETE PACKSET	TATA spare parts
722520920010	PASSENGER DOOR RUBBER BEADING(L=1750MM)	TATA spare parts
73308N25	ALLEN SCREW M8 X 25	TATA spare parts
73508PLN	WASHER FOR M8	TATA spare parts
741030090068	AL.EXTRUSION 7473 (HATRACK)CUT TO LENGTH	TATA spare parts
741030110028	AL EXTRUSION 7440 (HATRACK)CUT TO LENGTH	TATA spare parts
741030150004	AL EXTRUSION (AC DUCT)CUT TO LENGTH=465	TATA spare parts
741030160005	AL EXTRUSION (AC DUCT)CUT TO LENGTH=465	TATA spare parts
751130150001	FOG LAMP-RH (WORLD TRUCK)	TATA spare parts
751130160001	FOG LAMP-LH (WORLD TRUCK)	TATA spare parts
751130220001	LHD HEAD LAMP SET RH PRIMA 24V	TATA spare parts
751130230001	LHD HEAD LAMP SET LH PRIMA 24V	TATA spare parts
751230010001	TAIL LAMP ROUND FIEM AMBER (HISPANO)	TATA spare parts
751230050001	FOG LAMP ROUND LED (DIA-100-RED)(FIEM)	TATA spare parts
753630000001	ROOF HATCH WEBASTO 2M3 MDL(HISPANO)	TATA spare parts
755020020001	PASSENGER DOOR SWITCH	TATA spare parts
755020040001	INDICATOR SWITCH LIGHT(DRIVER CABIN)	TATA spare parts
755020130001	SPARE SWITCH (DVD/TV)	TATA spare parts
755020180001	COVER FOR SWITCH HOLE MB (FRAME)	TATA spare parts
755020260001	DVD SWITCH	TATA spare parts

755020300001	STOP REQUEST RESET SWITCH	TATA spare parts
755720000001	HEIGHT MARKER FRONT (FIEM MAKE)	TATA spare parts
755720010001	HEIGHT MARKER REAR (FIEM MAKE)	TATA spare parts
755720020001	SIDE DIRECTION INDICATOR LH(CAT 6)	TATA spare parts
755720030001	SIDE DIRECTION INDICATOR RH(CAT 6)	TATA spare parts
756030630001	SPIRAL CABLE MIC-CSM-1062	TATA spare parts
756030810001	24-12V 10 A DC-DC CONVERTOR	TATA spare parts
7673041574	EXHAUST GAS PROCSSUR	TATA spare parts
7673201162	CAB COMPLT RHD SLEEPER	TATA spare parts
7684860104	267960120135 BODY SHELL ASSY PAINTED BS6	TATA spare parts
770032400101	ASSY LEAF SPRING-10T	TATA spare parts
770032400102	FRONT HANGER	TATA spare parts
770032400103	EQUALIZER HANGER	TATA spare parts
770032400104	REAR HANGER	TATA spare parts
770032400105	ASSY.ADJUSTABLE TORQUE ARM	TATA spare parts
770032400107	ADJUSTABLE TORQUE ARM	TATA spare parts
770032400112	TRI AXLE 135X150	TATA spare parts
770032403401	BUSH (TOP)	TATA spare parts
770032403402	BUSH	TATA spare parts
770032403403	BUSH LOWER	TATA spare parts
770032403701	SPRING SEAT	TATA spare parts
770032403703	SPRING PAD	TATA spare parts
770032404201	U-BOLT	TATA spare parts
770032406002	EQUALIZER	TATA spare parts
770032406003	FIXED TORQUE ARM	TATA spare parts
770032406005	FIXED TORQUE ARM ( MID & REAR )	TATA spare parts
770032406701	PIN TORQUE ARM	TATA spare parts
770032406702	PIN EQUALIZER	TATA spare parts
770032406703	PIN - TORQUE ARM(EQUALIZER)	TATA spare parts
770032408601	WASHER TQRQUE ARM PIN	TATA spare parts
770032408602	WASHER EQUALIZER SHAFT	TATA spare parts
770035000120	REAR AXLE ASSY WITH BRAKE	TATA spare parts
770035305430	PINION (NEW) - 41/6 - 0130CWP	TATA spare parts
770039000116	135X150 SECTION TRAILER AXLE	TATA spare parts
77003900011890	TRAILER AXLE ASSY	TATA spare parts
770039000131	ASSY. RA-910 COMP. (NVB) WITH BRAKES	TATA spare parts
770039000153	REAR AXLE ASSY WITH BRAKE	TATA spare parts
770039000181	TRAILER AXLE 1850-14MM 144X155MM -16 TON	TATA spare parts
770039000185	1950-14MM NON ABS AXLE WITH MANUAL SLAC	TATA spare parts
770039000187	TRAILER AXLE ASSY	TATA spare parts
770039000192	TRAILER AXLE ASSY	TATA spare parts
770039000197	1814-14 ABS TRAILER AXLE ASSY W/O AUTO S	TATA spare parts
770039000204	TRAILER AXLE 1950-14MM 144X155MM -16 TON	TATA spare parts
770039000214	TRAILER AXLE ASSY	TATA spare parts
77003900022190	REAR AXLE ASSY WITH BRAKES	TATA spare parts
770039100117	ASSY.RA BEAM W/PRESSURE RING	TATA spare parts
770039100118	ASSY.RA BEAM MACHINED(135X150X14)	TATA spare parts

770039100165	REAR AXLE BEAM ASSY	TATA spare parts
770039100172	AXLE BEAM BS6	TATA spare parts
770039100182	REAR AXLE BEAM ASSY	TATA spare parts
770039100183	REAR AXLE BEAM ASSY WITH PRESSURE RING B	TATA spare parts
770039600102	HUB ASSY REAR	TATA spare parts
770039600103	REAR HUB ASSY	TATA spare parts
770042300109	BRAKE ASSY WITH DC LH	TATA spare parts
770042300110	BRAKE ASSY WITH DC RH	TATA spare parts
770228000117	TRANSFER CASE ASSY WITH COVER	TATA spare parts
770335300107	CROWN WHEEL & PINION ASSY FOR SPARE KIT	TATA spare parts
770433000103	FRONT AXLE ASSY WITH BRAKE	TATA spare parts
770433000105	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
770433000107	FRONT AXLE ASSY WITH BRAKE ABS	TATA spare parts
770433150102	JOINT FLANGE ASSY WITH BEARING	TATA spare parts
770433250102	STEERING KNUCKLE ASSY	TATA spare parts
770435000112	REAR AXLE ASSY W/BRAKE 7.24 1955 TRACK	TATA spare parts
770435000127	REAR AXLE ASSY WITH BRAKE RWD ABS	TATA spare parts
770435000129	REAR AXLE ASSY WITH BRAKE FWD	TATA spare parts
770435000135	REAR AXLE ASSY WITH BRAKE	TATA spare parts
770435000141	REAR AXLE ASSY REAR-FWD	TATA spare parts
770435000143	REAR AXLE ASSY WITH BRAKE RWD	TATA spare parts
770435000162	REAR AXLE ASSY WITH BRAKE	TATA spare parts
770435100115	ASSY REAR AXLE BEAM W/PR.RING/STUD/DOWEL	TATA spare parts
770435606702	PIN HUB MTG	TATA spare parts
770435707905	REAR AXLE SHAFT .	TATA spare parts
770440206701	HUB BOLT FRONT	TATA spare parts
770446300101	TIE ROD ARM ASSY LH	TATA spare parts
770446300102	TIE ROD ARM ASSY RH	TATA spare parts
780320088	CHECK PLATE	TATA spare parts
780350055	FLAT HEAD LOCK	TATA spare parts
78580	SHOE RETURN SPG BLAK	TATA spare parts
78926	BRG ADJUSTER LOCK LH	TATA spare parts
79000320010	FLANGE ASSEMBLY (DIA 150)	TATA spare parts
79000320013	FLANGE NUT	TATA spare parts
79100360018	WORKING CYLINDER	TATA spare parts
79100360035	SPRING POWER STORAGE JAR	TATA spare parts
79100710003	PRESSURE SWITCH	TATA spare parts
7935	AIR VENT	TATA spare parts
79903	GREASE SHIELD SEAL	TATA spare parts
79935	SPIDER	TATA spare parts
80000001	Tank Rubber Mounting Kit	TATA spare parts
80000002	Hy Fix Locking Bar Mounting Kit	TATA spare parts
80000003	SEAL KIT - CYLINDER (NEW TYPE)	TATA spare parts
80000007	SEAMLESS TUBE ASSY.KIT	TATA spare parts
80000049	SEAL KIT - CYLINDER (OLD TYPE )	TATA spare parts
80000088	SEAMLESS TUBE ASSY.KIT	TATA spare parts
80000102	COMPLETE PACKSET	TATA spare parts



80000107	SEAL KIT	TATA spare parts
80000G200BGB308	IRON SHOT	TATA spare parts
80030	DESTI.TUBELIGHT	TATA spare parts
800320077	SLIDING BLOCK	TATA spare parts
80320028	ADJUSTING WASHER	TATA spare parts
8033401131	HOUSING ASSEMBLY	TATA spare parts
8035510	WING NUT	TATA spare parts
8040054	METAL WASHER	TATA spare parts
8040055	RUBBER WASHER	TATA spare parts
804008	BRACKET MTG STUD	TATA spare parts
804017	CAMSHAFT SNAP RING	TATA spare parts
804024	NUT	TATA spare parts
804285	DUSTSHIELD CLIP	TATA spare parts
804286	INSPECTION PLUG	TATA spare parts
8043443755	STEERING NUT & WORM	TATA spare parts
804703	SCREW DUST SHIELD	TATA spare parts
804704	SCREW - DUST SHIELD	TATA spare parts
805676	SHOE ASSY	TATA spare parts
806234	CAM ROLLER	TATA spare parts
806380	CAMSHAFT WASHER	TATA spare parts
808058	ROLLER RETAINER	TATA spare parts
808058	ROLLER RETAINER	TATA spare parts
808330	KIT MINOR O/H/AUL	TATA spare parts
8090040	Gasket	TATA spare parts
809718	DUST SHIELD	TATA spare parts
811330	BRAKE DRUM	TATA spare parts
811334	STUD	TATA spare parts
811548	SHOE & LINING ASSY.	TATA spare parts
811913	BRAKE LINING KIT	TATA spare parts
813218940013	WASHER	TATA spare parts
813218940099	SUPPORTING RING	TATA spare parts
813229	LINING AND RIVET KIT	TATA spare parts
81500010163	PLUG SCREW	TATA spare parts
8150010163	PLUG SCREW	TATA spare parts
815462	CAMSHAFT LH	TATA spare parts
815463	CAMSHAFT RH	TATA spare parts
816777	DUST SHIELD KIT	TATA spare parts
817432	MTG BRKT LH AIR CHAMBER	TATA spare parts
817433	MTG BRKT RH AIR CHAMBER	TATA spare parts
818278	SHOE RETURN SPRING	TATA spare parts
818728	SHOE RETURN SPRING	TATA spare parts
819725	SPRING RETAINING	TATA spare parts
819776	SHOE & LINING ASSY	TATA spare parts
819790	GREASE FITTING	TATA spare parts
819836	HUB	TATA spare parts
819852	BRACKET ASSY LH	TATA spare parts
819853	BRACKET ASSY RH	TATA spare parts

832128	FLANGE	TATA spare parts
8354042	Top Cover	TATA spare parts
83726	GR THRUST WASHER RH	TATA spare parts
84508	FORK AND ROLLER ASSY	TATA spare parts
859006004001	OIL TANK BRACKET ASSLY RH BS6	TATA spare parts
859006004002	OIL TANK BRACKET RH ASSLY BS6	TATA spare parts
859006004007	R CLIP WITH CHAIN BS6	TATA spare parts
859006074001	FULCROM PIN BS6	TATA spare parts
859006074003	CYLINDER PIN BOTTOM BS6	TATA spare parts
859006084012	SOLENOID SWITCH BRACKET BS6	TATA spare parts
859006084022	SOLENOID SWITCH BRACKET BS6	TATA spare parts
859006214001	BRASS BEARING FULCORM BS6	TATA spare parts
859006214002	BRASS BUSING CONT CYL. BS6	TATA spare parts
859006214003	BRASS BUSING BASE CYL. BS6	TATA spare parts
859010963001	PUSH PULL CABLE 2150MM BS6	TATA spare parts
859010963003	SUPER ACE PTO WITH 5CC PUMP ASSY BS6	TATA spare parts
859010963004	PRESSURE HOSE ASSY BSH390 BS6	TATA spare parts
859010963005	PRESSURE HOSE ASSY BSH424 BS6	TATA spare parts
859010963006	PRESSURE HOSE ASSY BSH471 BS6	TATA spare parts
859010963007	PRESSURE HOSE ASSY BSH481 BS6	TATA spare parts
859010963008	FILLER CUM BREATHER BS6	TATA spare parts
859010963009	TIPPING CYLINDER BS6	TATA spare parts
859010963010	VALVE BS6	TATA spare parts
859010963011	OIL TANK ASSY-X231150000 BS6	TATA spare parts
859011963001	WMT-031 WITH MANUAL DCV_PTT716002X050 B	TATA spare parts
859011963007	WMT-067 WITH MANUAL DCV_PTT955001X050	TATA spare parts
859011963008	IPH PUSH PULL CABLE FOR INTRA BS6	TATA spare parts
859012003001	BATTERY COVER BS6	TATA spare parts
859012003003	WHEEL ARCH SUPPORT ASSLY BS6	TATA spare parts
859012003004	FUEL NECK ASSLY BS6	TATA spare parts
859012003006	WHEEL ARCH SUPPORT ASSLY BS6	TATA spare parts
859012084003	MUDGUARD TAPER BRACKET RH BS6	TATA spare parts
859012084004	MUDGUARD TAPER BRACKET LH BS6	TATA spare parts
859012084009	MUDGUARD COVER BS6	TATA spare parts
859012084017	MUDGUARD SUPPORT LH SIDE BS6	TATA spare parts
859012283001	MUD FLAP_XENON	TATA spare parts
859012304001	PP MUDGUARD 281870906312 BS6	TATA spare parts
859013002001	BATTERY TRAY ASSEMBLY	TATA spare parts
859013083001	BATTERY TRAY L-ANGLE	TATA spare parts
859013083002	BATTERY TOP CLAMP C-SECTION	TATA spare parts
859015003004	REAR DOOR EXT PANEL ASSY BS6	TATA spare parts
859015083003	REAR DOOR INTERNAL PANEL BS6	TATA spare parts
859019264002	REAR TAIL LAMP MOUNTNG_YODHA BS6	TATA spare parts
859020003004	STAY ROD CATCHER ASSLY BS6	TATA spare parts
859020003005	TAILGATE ASSLY BS6	TATA spare parts
859020003006	TOP FLAP STAY ROD ASSLY BS6	TATA spare parts
859020003008	TOP FLAP ASSLY BS6	TATA spare parts

859020003012	PARTITION DOOR ASSLY BS6	TATA spare parts
859020003016	TAILGATE ASSLY BS6	TATA spare parts
859020003018	TOP FLAP ASSLY BS6	TATA spare parts
859020003019	TOP FLAP STAY ROD ASSLY BS6	TATA spare parts
859020003021	TAILGATE ASSLY 2.0CUM BS6	TATA spare parts
859020003022	PARTITION DOOR ASSLY_2CUM BS6	TATA spare parts
859020004004	TAILGATE LOCK MECH. ASSLY BS6	TATA spare parts
859020004005	TOP HINGE PLATE BS6	TATA spare parts
859020004006	TAILGATE HINGE ASSLY BS6	TATA spare parts
859020004008	TAILGATE LOCK MECH. ASSLY BS6	TATA spare parts
859020005002	GREAS PLUG I TYPE M10 BS6	TATA spare parts
859020074002	DIA 10MM STAY ROD BS6	TATA spare parts
859020074003	FLAP HANDLE BS6	TATA spare parts
859020075003	TAILGATE LOCKING BASE BS6	TATA spare parts
859020075004	TAILGATE LOCKING ROD BS6	TATA spare parts
859020075005	SPRING FOR LOCK BS6	TATA spare parts
859020083001	TAIL GATE LOCK CATCHER BS6	TATA spare parts
859020084002	TAIL GATE EXTERNAL PANEL BS6	TATA spare parts
859020084007	TOP FLAP PANEL BS6	TATA spare parts
859020084011	PARTITION PANEL BS6	TATA spare parts
859020084012	WASHER ID12.5 OD22 BS6	TATA spare parts
859020084019	TOP FLAP PANEL BS6	TATA spare parts
859020084024	PARTITION PANEL_2CUM BS6	TATA spare parts
859022074001	FOLDABLE STEP HINGE PIN	TATA spare parts
859022304001	NYLON BUSH FOR FOLDABLE STEP	TATA spare parts
859022304002	NYLON WASHER FOR FOLDABLE STEP	TATA spare parts
859027213001	914002042218 AL PROFILE 2440L	TATA spare parts
859028003001	TAPER PANEL ASSLY BS6	TATA spare parts
859028003006	TAPER PANEL ASSLY BS6	TATA spare parts
859028003007	TAPER PANEL ASSLY-2 BS6	TATA spare parts
859028083001	STRETCH PANEL_XENON	TATA spare parts
859028083002	DOOR SIDE PANEL RH	TATA spare parts
859028083003	DOOR SIDE PANEL	TATA spare parts
859028083006	SKIRT PANEL	TATA spare parts
859028083008	REAR BOTTOM PANEL	TATA spare parts
859028083009	REAR BOTTOM PANEL	TATA spare parts
859028083013	FRONT TOP PANEL	TATA spare parts
859028083014	FRONT BOTTOM PANEL	TATA spare parts
859028083015	FRONT BOTTOM CORNER PANEL	TATA spare parts
859028083021	SIDE WALL 1.55MM BS6	TATA spare parts
859028083022	TOP CLOSING PANEL 1.25MM BS6	TATA spare parts
859028083023	FRONT TOP CLOSING PANEL 1.25MM BS6	TATA spare parts
859028083024	FRONT BELOW CLOSING PANEL 1.55MM BS6	TATA spare parts
859028083025	BASE PLATE 1.95MM BS6	TATA spare parts
859028083029	BASE FRONT PANEL BS6	TATA spare parts
859028083030	REAR TOP PANEL BS6	TATA spare parts
859028083031	CORNER PANEL LH BS6	TATA spare parts

859028083032	CORNER PANEL RH BS6	TATA spare parts
859028083048	BASE PLATE 1.95MM BS6	TATA spare parts
859028083049	BASE FRONT PANEL BS6	TATA spare parts
859028083050	REAR COVER PANEL BS6	TATA spare parts
859028083051	SIDE WALL 1.55MM BS6	TATA spare parts
859028083052	SIDE PANEL RH 2.CUM BS6	TATA spare parts
859028083053	FRONT BELOW CLOSING PANEL 1.25MM BS6	TATA spare parts
859028083054	REAR TOP PANEL BS6	TATA spare parts
859028083085	REAR DOOR CONOPY BS6	TATA spare parts
859028084001	REAR DOOR COVER SHEET	TATA spare parts
859028084004	SKIRT PANEL RH	TATA spare parts
859028084007	ROOF CORNER PANEL	TATA spare parts
859028084008	ROOF EXT PANEL	TATA spare parts
859028084013	REAR COVER PANEL BS6	TATA spare parts
859028084014	SIDE PANEL RH BS6	TATA spare parts
859028085001	RH SKIRT PANEL BS6	TATA spare parts
859028085002	LH SKIRT PANEL BS6	TATA spare parts
859028085003	RH SIDE PANEL BS6	TATA spare parts
859028085004	LH SIDE PANEL BS6	TATA spare parts
859028085005	ROOF EXTERNAL PANEL BS6	TATA spare parts
859028085006	REAR BOTTOM PANEL BS6	TATA spare parts
859028085007	C CHANNEL REAR BOTTOM BS6	TATA spare parts
859028085008	REAR PANEL BS6	TATA spare parts
859028085009	REAR PANEL BS6	TATA spare parts
859028085010	FRONT EXTERNAL PANEL BS6	TATA spare parts
859028085011	FRONT EXT BOTTOM PANEL BS6	TATA spare parts
859028085012	PANEL REAR DOOR TOP BS6	TATA spare parts
859028213001	914002042193 AL PROFILE L2430	TATA spare parts
859028213003	914002042216 AL C PROFILE_L155	TATA spare parts
859028213004	RAIN GUTTER ABOVE SIDE WINDOW BS6	TATA spare parts
859028214002	ALUMINIUM PROFILE	TATA spare parts
859028214003	914002042210-ALUMINIUM PROFILE	TATA spare parts
859028215001	ALUMINIUM C PROFILE BS6	TATA spare parts
859028215002	LH SKIRT PANEL BS6	TATA spare parts
859028215003	ALUMINIUM FINISHING PROFILE BS6	TATA spare parts
859028215004	ALU. FINISHING PROFILE BS6	TATA spare parts
859028215005	COMM WIND MTG AL.FRAME BS6	TATA spare parts
859029003001	INP COVER XENON AMB_APP_303X370	TATA spare parts
859040003001	BENCH SEAT_XENON	TATA spare parts
859040003002	DOCTOR SEAT_XENON	TATA spare parts
859040003003	CANVAS TYPE FOLDABLE STRETCHER	TATA spare parts
859040003004	HEAD GUARD_50X50X1600	TATA spare parts
859040003010	XENON _ BACK REST (BERTH)	TATA spare parts
859040003012	BASE SEAT CUSHION_YODHA BS6	TATA spare parts
859042002005	MCB AND AC SOCKET ASSY	TATA spare parts
859042002006	AMPLIFIER WITH BRACKET BS6	TATA spare parts
859042002009	ASSY BRACKET CAMERA & SPEAKER MOUNTING B	TATA spare parts

859042003001	PA SYSTEM MOUNTING PLATE BS6	TATA spare parts
859042083002	BRACKET CAMERA & SPEAKER MOUNTING BS6	TATA spare parts
859042363001	PATIENT COMPARTMENT HARNESS XENON	TATA spare parts
859042363004	INVERTER OUTPUT CABLE_XENON	TATA spare parts
859042363005	INVERTER TO EXT.CHARGER WH_XENON	TATA spare parts
859042363006	AMPLIFIER PIGTAIL_XENON	TATA spare parts
859042363007	PARKING SUPPLY PIGTAIL_XENON	TATA spare parts
859042363008	BATTERY +VE TO BATTERY CUT OFF SW CABLE	TATA spare parts
859042363010	EXTENSION CABLE AMPLIFIER END	TATA spare parts
859042363011	EXTENSION CABLE BECAON LAMP& SPEAKER END	TATA spare parts
859042363012	EXTENSION CABLE INTERCOM 1	TATA spare parts
859042363013	EXTENSION CABLE INTRCOM 2	TATA spare parts
859042363014	HARNESS PIGTAIL GPS & AMPLIFIER SUPPLY B	TATA spare parts
859042363015	HARNESS PIGTAIL CAMERA SUPPLY BS6	TATA spare parts
859042363016	HARNESS GPS & AMPLIFIER SUPPLY_INTRA BS6	TATA spare parts
859042363017	HARNESS CAMERA SUPPLY_INTRA GT BS6	TATA spare parts
859042363018	PIGTAIL LICENSE PLATE LAMP BS6	TATA spare parts
859042363019	PIGTAIL INPUT SUPPLY BS6	TATA spare parts
859042363020	SUPPLY PIGTAIL TO FAN AND LAMP BS6	TATA spare parts
859042363021	SPEAKER TO PA SYSTEM W/H BS6	TATA spare parts
859042363023	INVERTER OUTPUT W/H BS6	TATA spare parts
859042373001	AMPLIFIER TO SPEAKER EXTENSION CABLE BS6	TATA spare parts
859042373002	AMPLIFIER TO SPEAKER EXT CABLE_INTRA GT	TATA spare parts
859045002015	TIPPING CONTAINER SHELL AND PANEL ASSLY	TATA spare parts
859045003001	CHARGING SOCKET HOUSING ASSLY	TATA spare parts
859045003012	PARTITION LOCK ASSY BS6	TATA spare parts
859045003013	PARTITION DOOR LOCK MECH BS6	TATA spare parts
859045003014	LATCH FOR PARTITION LOCK BS6	TATA spare parts
859045004002	SAFETY STAYROD ASSLY BS6	TATA spare parts
859045004017	SAFETY STAYROD ASSLY BS6	TATA spare parts
859045074001	CYLINDER CONTAINER PIN BS6	TATA spare parts
859045074003	LOCKING BUSH BS6	TATA spare parts
859045084001	CHARGING FLAP NECK STR	TATA spare parts
859045284001	BALATA PACKING 80X50X10MM	TATA spare parts
859050003004	TANK RECEIVER ASSY -DRYER	TATA spare parts
859050003005	CORE CONDENSER ( BUS A.C)	TATA spare parts
859050003006	TRIPLE PRESSURE SWITCH	TATA spare parts
859050003007	PACKING-DRYER	TATA spare parts
859050003008	O-RING-SUCTION	TATA spare parts
859050003009	BLOWER MOTOR ASSY.- RH	TATA spare parts
859050003010	BLOWER MOTOR ASSY.- LH	TATA spare parts
859050003011	WIRING HARNESS	TATA spare parts
859050003012	RESISTOR BLOWER	TATA spare parts
859050003013	EVAPORATOR SUB-ASSY.-FRONT	TATA spare parts
859050003014	VALVE EXP 1 TON	TATA spare parts
859050003015	THERMISTOR & THERMO AMPLIFIER ASSY	TATA spare parts
859050003016	EVAPORATOR SUB-ASSY-FRONT	TATA spare parts

859050003017	COVER PART(FRP)-WITHOUT GRILLS	TATA spare parts
859050003018	CONTROL PANEL BASE PLATE	TATA spare parts
859050003019	GRILL-RECIRCULATION	TATA spare parts
859050003020	GRILL ASSY.-RH	TATA spare parts
859050003021	W/H COOLING UNIT 2 (REAR COOLING UNIT)	TATA spare parts
859050003022	WIRING HARNESS ASSY (FUSE BOX & RELAYS)	TATA spare parts
859050003023	HARNESS S/A (MAIN WIRING HARNESS)	TATA spare parts
859050003024	SET ASSY RELEY	TATA spare parts
859050003025	SET ASSY RELAY	TATA spare parts
859050003026	SWITCH A/ COOLER	TATA spare parts
859050003027	SOLENOID VALVE	TATA spare parts
859050003028	W/H HARNESS	TATA spare parts
859050003029	W/H HARNESS	TATA spare parts
859050003030	W/H HARNESS	TATA spare parts
859050003031	HARNESS-AC SWITCH	TATA spare parts
859050003032	HOSE LIQUID ASSY (COND. TO T-JOINT)	TATA spare parts
859050003033	HOSE LIQUID ASSY (REAR)	TATA spare parts
859050003034	HOSE LIQUID ASSY (FRONT)	TATA spare parts
859050003035	HOSE DISCHARGE ASSY (CONDENSER)	TATA spare parts
859050003036	HOSE SUCTION ASSY	TATA spare parts
859050003037	TUBE SUCTION ASSY	TATA spare parts
859050003038	O-RING-LIQUID	TATA spare parts
859050003039	O-RING-DISCHARGE	TATA spare parts
859051003002	GRAB RAIL TUBE	TATA spare parts
859056003001	OXY CYLINDER HOLDING ASSEMBLY	TATA spare parts
859056183001	ROOF INNER PANEL	TATA spare parts
859056183002	SIDE PANEL RH	TATA spare parts
859056183005	SIDE INTERNAL PANEL	TATA spare parts
859056183006	INTERNAL PANEL BELOW WINDOW	TATA spare parts
859056183007	INTERNAL PANEL ABOVE WINDOW	TATA spare parts
859056183008	SIDE INTERIOR PANEL	TATA spare parts
859056183009	REAR TOP INT PANEL 253X1610	TATA spare parts
859056183010	REAR INT PANEL LH 167X1370	TATA spare parts
859056183011	REAR INT PANEL RH 167X1370	TATA spare parts
859056183012	FRONT WALL INT PANEL RH 1205X1618	TATA spare parts
859056183013	FRONT WALL LH INT PANEL 575X1618	TATA spare parts
859056183014	INTERNAL PANEL BELOW WINDOW	TATA spare parts
859056183015	SIDE INTERIOR PANEL	TATA spare parts
859056213003	ALUMINIUM PROFILE	TATA spare parts
859056213004	ALUMINIUM PROFILE	TATA spare parts
859056213005	AL PROFILE	TATA spare parts
859056213006	AL PROFILE	TATA spare parts
859056303007	PVC PROFILE	TATA spare parts
859057183002	ROOF INTERNAL PANEL	TATA spare parts
859057183003	ROOF INNER PANEL	TATA spare parts
859058263002	FRP WHEEL ARCH XENON BS6	TATA spare parts
859058263003	AIR DEFLECTOR YODHA BS6	TATA spare parts

859058264001	ROOF CORNER FINISHING RH	TATA spare parts
859058264002	ROOF CORNER FINISHING LH	TATA spare parts
859058333001	FRONT_ AMBULANCE LETTER STICKER	TATA spare parts
859058333002	REAR AMBULANCE LETTER STICKER	TATA spare parts
859058333003	VOLTAGE STICKER FOR SWITCH	TATA spare parts
859058333004	VOLTAGE STICKER FOR SWITCH	TATA spare parts
859058333006	BOX-AC STICKER FOR SWITCH	TATA spare parts
859058333007	PLUS STICKER FOR ABULANCE	TATA spare parts
859058333008	PLUS STICKER FOR ABULANCE	TATA spare parts
859058333009	FUEL STCKER	TATA spare parts
859058333010	MCB STICKER	TATA spare parts
859058333011	CHARGING STICKER	TATA spare parts
859059003001	WASH BASIN WITH MEDICAN CABINET	TATA spare parts
859059004001	FRESH WATER TANK	TATA spare parts
859059074001	SALIEN HOLDING HOOK	TATA spare parts
859059083005	240V INPUT COVER BS6	TATA spare parts
859059083006	240V INPUT COVER B BS6	TATA spare parts
859059304003	WASTE WATER CONTAINER PLASTIC	TATA spare parts
859059333001	BLUE COLOUR CURTAIN FABRIC	TATA spare parts
859062003001	HAZARDOUS WASTE BIN RED BS6	TATA spare parts
859062003003	HAZARDOUS WASTE BIN BLACK BS6	TATA spare parts
859062003004	STB BAR ASSLY BS6	TATA spare parts
859062014001	TUBE 50X40 BS6	TATA spare parts
859062014002	TUBE 40X30 BS6	TATA spare parts
859062014003	TUBE B BS6	TATA spare parts
859062014004	TUBE C BS6	TATA spare parts
859062084005	BOTTOM PLATE BS6	TATA spare parts
859062084006	TOP PLATE BS6	TATA spare parts
859064003001	REAR DR.WINDOW_323X545_CLEAR GLS_4MM	TATA spare parts
859064003002	LH/RH_WINDOW_762X544_CLEAR GLS_4MM	TATA spare parts
859064003003	LH/RH_WINDOW_762X544_CLEAR GLS_4MM	TATA spare parts
859064003006	WINDOW_528X702_CLEAR GLS_4MM BS6	TATA spare parts
859064003007	LH FIXED WIND_1044X693_CLEAR TNT_4MM BS6	TATA spare parts
859064233003	FRONT PASTED GLS_1046X359_CLEAR GLS_4MM	TATA spare parts
859064234001	FRNT_EXT GLS_323X545_CLEAR GLS_4MM	TATA spare parts
859064234002	FRNT_EXT GLS_323X545_CLEAR GLS_4MM	TATA spare parts
859064234003	FRNT_EXT GLS_390X521_CLEAR GLS_4MM	TATA spare parts
859064234004	FRNT_EXT GLS_390X521_CLEAR GLS_4MM	TATA spare parts
859064234005	FRNT_EXT GLS_390X521_CLEAR GLS_4MM	TATA spare parts
859064234006	REAR_INT GLS_390X521_CLEAR GLS_4MM	TATA spare parts
859064234008	REAR INT GLS_355X489_CLEAR GLS_4MM BS6	TATA spare parts
859064234009	FRNT_EXT GLS_355X489_CLEAR GLS_4MM BS6	TATA spare parts
859064234010	LH FIXED GLS_1035X684_CLEAR_4MM THK BS6	TATA spare parts
85CX001Z00	BUSHING POLYMER	TATA spare parts
861	HUB OIL SEAL	TATA spare parts
8678805	SPRING ACCUMULATOR	TATA spare parts
86AX007C01	BUSHING ASSY FOR PARAREV BEAMS	TATA spare parts

86CX001Z00	TORQUE ROD BAR PIN BUSH	TATA spare parts
86CX002Z00	A-FRAME CENTRE BUSH	TATA spare parts
86CX008C01	BUSHING OUTER RUBBER	TATA spare parts
86CX009C01	BUSHING INNER STEEL	TATA spare parts
86CX010C01	SLEEVE INNER	TATA spare parts
86CX011C01	SLEEVE OUTER	TATA spare parts
87CX001Z00	SEAL - TRUNNION	TATA spare parts
880094148400	LUG SOC 44D-3/4INCHSQ/R-NUT M26-1.5/SUM0	TATA spare parts
880094163200	SOC 16HEX-1/2SQ-240L/SPARK PLUG/CNG X3	TATA spare parts
880094163300	SPL.SPNR/PROTACTIVE SLEEVE UPPER/697 CNG	TATA spare parts
880094227000X	LUG SOCKET WRENCH / THRD RING / RA / 100	TATA spare parts
880094235400	3/4 SQ.SOC / CYL VALVE FIT / CNG / ACE	TATA spare parts
880094262600	3/8 INCSQ DR OIL FILTER SPNR/ 2.2 DICOR/	TATA spare parts
880094312700	C SOC 17BI-1/2IN-130L/AIR BLEED/4SP 497	TATA spare parts
880094312701	SPL SOCKET 17A/F BIHEX X 1/2IN SQDR X115	TATA spare parts
880094358400	SPL TOOL FOR¿ CRANK ROTATING	TATA spare parts
880094360100	SPL T SOCKET 10A/F HEX X 305L	TATA spare parts
880094360400	SPL T SOCKET 12A/F BIHEX X 180L	TATA spare parts
880094360900	SPL SOCKET95A/F HEX X3/4INCH SQDR X55L	TATA spare parts
880094366900	PCN REMOVAL TOOL	TATA spare parts
880094367000	PCN REMOVAL TOOL	TATA spare parts
880340018	BRAKE PREVENTED DUST CAP	TATA spare parts
880340022	WASHER	TATA spare parts
880340023	PACKING RING	TATA spare parts
880340037	CHOKE PLUG	TATA spare parts
88040800331	WALLCHART¿CONTAIN SIX IN ONE SET IN ENG	TATA spare parts
88040800357	WALLCHART CONTAIN TEN IN ONE SET IN ENG	TATA spare parts
88040800365	WALLCHART CONTAIN TEN IN ONE SET IN HIN	TATA spare parts
88040800373	WALLCHART CONTAIN THIRTEEN IN ONE SET IN	TATA spare parts
88040800381	WALLCHART CONTAIN THIRTEEN IN ONE SET IN	TATA spare parts
88040800438	9NO.WALLCHART CONTAIN IN ONE SET IN ENG.	TATA spare parts
880410029	BUSH	TATA spare parts
880410049	THRUST BALL BEARING	TATA spare parts
880410052	O STYLE PACKING RING	TATA spare parts
880410059	ADJUSTING BOLT	TATA spare parts
880410065	WASHER	TATA spare parts
880410066	PACKING RING	TATA spare parts
880410068	LOCATING COWL	TATA spare parts
880410069	NEEDLE GEAR	TATA spare parts
880410097	WASHER	TATA spare parts
880410102	PLUG	TATA spare parts
880410109	CANAL	TATA spare parts
880420012	O STYLE PACKING RING	TATA spare parts
880420014	CIRCLIP FOR AXLE	TATA spare parts
880420022	SPACE RING	TATA spare parts
880420023	CENTRAL GEAR	TATA spare parts
880420024	PLANETARY AXLE	TATA spare parts



880420027	PLANET CARRIER OIL BAFFLE DISC	TATA spare parts
880420028	CAULKING RING	TATA spare parts
880420030	BEAR WASHER	TATA spare parts
880420034	STOP WASHER	TATA spare parts
880440010	ADDITIVE WASHER	TATA spare parts
880440011	BRAKE FRICTION PLATE	TATA spare parts
880440012	RETURN SPRING	TATA spare parts
880440016	BRAKE FLOOR (LEFT)	TATA spare parts
880440018	BRAKE FLOOR (RIGHT)	TATA spare parts
880440019	BRAKE PREVENTED DUST CAP	TATA spare parts
880440022	BEARER	TATA spare parts
880440032	PIN	TATA spare parts
8804406	BUSH	TATA spare parts
8804408	POSTIVE PLATE	TATA spare parts
8804412	RETURN SPRING	TATA spare parts
8804420/21	ADJUSTING ARM	TATA spare parts
8804425	BEAR PIN	TATA spare parts
8804431	BUSH	TATA spare parts
8804432	RETURN SPRING PIN	TATA spare parts
882201000290	PROLIFE 6BT LONG BLOCK W/O INJEC EURO3	TATA spare parts
882201990101	PROLIFE ACE CNG-LONG BLOCK	TATA spare parts
882201990105	PROLIFE ACE LONG BLOCK - BS2/3	TATA spare parts
882201990108	PROLIFE 6BT EUROIII LONG BLOCK W/O INJEC	TATA spare parts
882201990116	PROLIFE ACE MAGIC LONG BLOCK-BS 2/3	TATA spare parts
882201990119	PROLIFE 4 SP EURO II½ LONG BLOCK	TATA spare parts
882201990120	PROLIFE ACE DICOR LONG BLOCK BSIV-TCIC	TATA spare parts
882201990129	PROLIFE ACE/MAGIC LONG BLOCK - BS4	TATA spare parts
882201990147	PROLIFE ACE DICOR LONG BLOCK - NA	TATA spare parts
882201990148	PROLIFE 497 CMVR EURO II LONG BLOCK	TATA spare parts
882201990150	PROLIFE 6BT EUROIII LONG BLOCK W/O INJEC	TATA spare parts
882201990180	PROLIFE 4 SP EURO III½ LONG BLOCK	TATA spare parts
882201990205	PROLIFE 697 BS II LONG BLOCK	TATA spare parts
882201990217	PROLIFE 697 BS III LONG BLOCK	TATA spare parts
882201990229	PROLIFE 275 IDI LONG BLOCK -ACE BS-IV	TATA spare parts
882225200106	ASSY. PROLIFE 352DIA. CLUTCH DISC	TATA spare parts
882225200109	PROLIFE 310 DIA CLUTCH DISC ASSY	TATA spare parts
882225200128	PROLIFE 240 DIA.CLUTCH DISC ASSY.	TATA spare parts
882225200134	ASSY. PROLIFE 380DIA. CL.DISC	TATA spare parts
882225200151	PROLIFE 330DIA.CLUTCH DISC-SETCO-ORGANIC	TATA spare parts
882225200163	PROLIFE 330 DIA.CLUTCH DISC-BUTTON TYPE	TATA spare parts
882225200190	PROLIFE 280 DIA CLUTCH DISC.ASSY	TATA spare parts
882225400102	PROLIFE CLUTCH COVER 310 DIA.	TATA spare parts
882225400105	ASSY. PROLIFE 352DIA. CIUTCH COVER	TATA spare parts
882225400106	PROLIFE 280DIA.CLUTCH COVER ASSY	TATA spare parts
882225400114	PROLIFE 240 DIA. CLUTCH COVER ASSY	TATA spare parts
882225400129	ASSY. PROLIFE 380DIA. CL.COVER	TATA spare parts
882225400135	PROLIFE170DIA.(CL.COVER ASSY + CL.DISC )	TATA spare parts

882225400138	PROLIFE 330DIA CLUTCH COVER ASSY.(SHEET)	TATA spare parts
882227860314	PROLIFE ISBE LONG BLOCK 5.9 BSIV	TATA spare parts
882227970124	PROLIFE SUPERACE DI LONGBLOCK 1.4L BSIV	TATA spare parts
882257060102	PROLIFE INJECTOR_3L	TATA spare parts
882257100109	PROLIFE ACE MEGA BSIV LONG BLOCK	TATA spare parts
8822C3931858	PROLIFE LONG BLOCK 6BT EURO II CUMMMINS	TATA spare parts
882500070322	BRAVO RECTANGULAR OPEN END SE 9X12 10MM	TATA spare parts
88252400251	CARPET LINING 100MM WIDTH	TATA spare parts
88273306751	STICKER 'CV-CX O.K'-LKO/1263A-A9	TATA spare parts
883502499500	P-DOLLEY / REAR OIL SEAL / 4SP BS4	TATA spare parts
883502499501	46.5D P-DOLLEY / REAR OIL SEAL / 4SP BS4	TATA spare parts
88374	BOLT-SPIDER	TATA spare parts
884025030255	HAND HELD PROGRAMMER FOR SLD	TATA spare parts
884201000295	PROLIFE 6BT EUROIII LONG BLOCK W/O INJEC	TATA spare parts
884201990220	PROLIFE 697 EURO III LONG BLOCK	TATA spare parts
884578140494	DISPENSING GUN FOR SEALANT LOCTITE 5900	TATA spare parts
884579020036	CARDO GIN LABELS (AVERY DENNISON MAKE)	TATA spare parts
885100001093	PROLIFE SHOCK ABSORBER REAR	TATA spare parts
885100100086	PROLIFE LEVELLING VALVE	TATA spare parts
885100990101	PROLIFE LONG BLOCK 497 NA CNG BS IV SGI	TATA spare parts
885100990114	PROLIFE 497CR LONG BLOCK BS-IV	TATA spare parts
885100990118	PROLIFE 497 Y1 BS-III LONG BLOCK	TATA spare parts
885100990120	PROLIFE 497 TCIC LONG BLOCK E-III UT	TATA spare parts
885100990130	PROLIFE 497 TCIC LONG BLOCK E-III UT	TATA spare parts
885101000025	SHORT BLOCK DSE(R/C)	TATA spare parts
885101000101	PROLIFE 6CTAA-300HP-24V-LMFO-E-II)	TATA spare parts
885101000103	ENGINE ASSY 697	TATA spare parts
885101000104	ENGINE 697NA S-CAM RECON	TATA spare parts
885101000114	RC SHORT BLOCK	TATA spare parts
885101000151	RECON 1/2 ENG. 697NA DAOH	TATA spare parts
885101000153	HALF BLOCK 697NA DAOH REC	TATA spare parts
885101000154	HALF BLOCK 697NA SCAM REC	TATA spare parts
885101000156	RECON LONG BLOCK 6BT CUM.	TATA spare parts
885101000252	ENGINE 697TC S-CAM RECON	TATA spare parts
885101000253	RECON 697 TC SHORT BLOCK	TATA spare parts
885101000266	PROLIFE B5.9 CNG LEAN BURN LONG BLOCK	TATA spare parts
885101000285	RECON LONG BLOCK 6BT CUM.	TATA spare parts
885101000290	PROLIFE 6BT EUROIII LONG BLOCK W/O INJEC	TATA spare parts
885101000351	HALF BLOCK RC 4DL/207	TATA spare parts
885101000352	ENGINE 4DL/RC/207	TATA spare parts
885101000401	RECONDITIONED ENGINE	TATA spare parts
885101000451	SHORT BLOCK	TATA spare parts
885101000452	RECON 692 DI SHORT BLOCK	TATA spare parts
885101000488	SHORT BLOCK 697TC	TATA spare parts
885101000651	HALF ENGINE 697SPSFC(R/C)	TATA spare parts
885101000701	ENGINE DSE497SP(R/C)	TATA spare parts
885101000751	HALF ENGINEDSE497SP R/C	TATA spare parts

885101000752	SHORT BLOCK 609 R/C	TATA spare parts
885101000753	RECON ENGINE 497 LPT 709	TATA spare parts
885101010101	PROLIFE GREAVES(IRIS/ZIP) LONG BLOCK	TATA spare parts
885101010102	PROLIFE GREAVES LONG BLOCK	TATA spare parts
885101150125	R.C. BARE HEAD	TATA spare parts
885101282903	SET VALVE GUIDE IN/EX O/S 003	TATA spare parts
885101282905	SET VALVE GUIDE IN/EX O/S 005	TATA spare parts
885101600159	RECON 497 SP TC SHORT BLOCK	TATA spare parts
885101600160	PROLIFE 497 SP TC LONG BLOCK	TATA spare parts
885101600161	RECON 497 CMVR LONG BLOCK	TATA spare parts
885101600162	RECON 497 SP TC LONG BLOCK	TATA spare parts
885101600163	RECON 497 SP TC LONG BLOCK	TATA spare parts
885101600165	PROLIFE 497 SP TC YELLOW ENGINE (EXPORT)	TATA spare parts
885101600166	PROLIFE 497SP LONGBLOCK CUT SECTION	TATA spare parts
885101600198	RECON LONG BLOCK 6BT CUM.	TATA spare parts
885101600378	RECON LONG BLOCK 6BT CUM.	TATA spare parts
885101610173	PROLIFE ASSY 697 CNG BS IV	TATA spare parts
885101990100	PROLIFE 275 IDI LONG BLOCK -ACE MODEL	TATA spare parts
885101990101	PROLIFE 275 IDI LONG BLOCK -ACE CNG	TATA spare parts
885101990102	Prolife 497 CMVR long block	TATA spare parts
885101990103	RECON GBS 600 ASSY (R-8.47)	TATA spare parts
885101990104	RECON LONG BLOCK 4SP	TATA spare parts
885101990105	PROLIFE 275 IDI LONG BLOCK -ACE	TATA spare parts
885101990105S	PROLIFE 275 IDI LONG BLOCK -ACE	TATA spare parts
885101990106	RECON 497 CMVR SHORT BLOCK	TATA spare parts
885101990107	PROLIFE 497 CMVR LONG BLOCK	TATA spare parts
885101990108	PROLIFE 475TCIC LONGBLOCK BSIII-superace	TATA spare parts
885101990108S	PROLIFE 475TC LONGBLOCK BSIII-SEMIFINISH	TATA spare parts
885101990109	RECON ACE CUT SECTION MOTORISED	TATA spare parts
885101990110	RECON LONG BLOCK 697 NA	TATA spare parts
885101990110EX	697NA long blk excavator	TATA spare parts
885101990111	PROLIFE 697 TC LONG BLOCK	TATA spare parts
885101990111EX	697TC long blk excavator	TATA spare parts
885101990112	PROLIFE 497 NA LONG BLOCK	TATA spare parts
885101990112EX	497 NA long block excavator	TATA spare parts
885101990113	RECON LONG BLOCK 697 NA WITH WP&AC	TATA spare parts
885101990114	RECON GBS 600 ASSY (R-8.47)	TATA spare parts
885101990116	PROLIFE 275 IDI LONG BLOCK -ACE MAGIC	TATA spare parts
885101990118	RECON 697 NA CMVR SHORT BLOCK	TATA spare parts
885101990119	PROLIFE 4 SP BS II LONG BLOCK	TATA spare parts
885101990120	PROLIFE ACE DICOR LONG BLOCK BSIV-TCIC	TATA spare parts
885101990121	Recon 275 IDI Long Block- BS IV	TATA spare parts
885101990122	PROLIFE 207DI LONG BLOCK - BS I	TATA spare parts
885101990123	PROLIFE 207DI LONG BLOCK(BS I )	TATA spare parts
885101990124	PROLIFE 4 SP TC EURO II LONG BLOCK	TATA spare parts
885101990125	PROLIFE 483 DL LONG BLOCK	TATA spare parts
885101990126	PROLIFE 483 DL LONG BLOCK WITH FIP	TATA spare parts

885101990127	PROLIFE 697 NA CMVR LONG BLOCK	TATA spare parts
885101990128	RECON 697 NA CMVR LONG BLOCK	TATA spare parts
885101990129	PROLIFE 275 IDI LONG BLOCK -ACE BS-IV	TATA spare parts
885101990130	PROLIFE 475 TCIC LONG BLOCK BSIII	TATA spare parts
885101990131	PROLIFE 697 TC CMVR LONG BLOCK	TATA spare parts
885101990132	RECON 697 TC CMVR SHORT BLOCK	TATA spare parts
885101990133	RECON 697 TC CMVR LONG BLOCK	TATA spare parts
885101990134	PROLIFE 697 TC CMVR LONG BLOCK	TATA spare parts
885101990142	PROLIFE 475TCIC LONG BLOCK BS-III-CUTSEC	TATA spare parts
885101990143	PROLIFE ACE YELLOW ENGINE(EXPORT) WITHOU	TATA spare parts
885101990145	PROLIFE 207DI LONG BLOCK - BS II	TATA spare parts
885101990147	PROLIFE ACE DICOR LONG BLOCK -NA	TATA spare parts
885101990148	PROLIFE 497 CMVR Euro II LONG BLOCK	TATA spare parts
885101990149	RECON 497 CMVR EURO II LONG BLOCK	TATA spare parts
885101990150	PROLIFE 497 BS III LONG BLOCK	TATA spare parts
885101990151	RECON 497 CMVR LONG BLOCK	TATA spare parts
885101990152	RECON 497 CMVR LONG BLOCK	TATA spare parts
885101990154	PROLIFE 497LONG BLOCK YELLOW CNG(EXPORT)	TATA spare parts
885101990156	PROLIFE 497 BS III LONG BLOCK - LP1512	TATA spare parts
885101990160	PROLIFE ACE DICOR LONG BLOCK BSIVTCIC EX	TATA spare parts
885101990180	PROLIFE 4 SP BS III LONG BLOCK	TATA spare parts
885101990181	RECON 4 SP EURO III LONG BLOCK	TATA spare parts
885101990205	PROLIFE 697 BS II LONG BLOCK	TATA spare parts
885101990205S	PROLIFE 697 BS II LONG BLOCK	TATA spare parts
885101990206	RECON 697 TC CMVR LONG BLOCK	TATA spare parts
885101990207	PROLIFE 697 EURO II LONG BLOCK	TATA spare parts
885101990217	PROLIFE 697 BS III LONG BLOCK	TATA spare parts
885101990218	RECON 697 TC CMVR LONG BLOCK	TATA spare parts
885101990219	RECON LONG BLOCK 6BT CUM.	TATA spare parts
885101990220	RECON 697 CUT SECTION MOTORISED	TATA spare parts
885101990221	PROLIFE 697 LONG BLOCK CUTSEC STATIC	TATA spare parts
885101990222	PROLIFE 697 YELLOW ENGINE	TATA spare parts
885101990228	PROLIFE ISBe BS III 270 HP LONG BLOCK	TATA spare parts
885101990229	PROLIFE 275 IDI LONG BLOCK -ACE BS-IV	TATA spare parts
885101990236	PROLIFE XENON 2.2L LONG BLOCK	TATA spare parts
885101990245	PROLIFE 697 NA CNG BSIII LONG BLOCK	TATA spare parts
885101990258	PROLIFE 697 CNG BSIV LONG BLOCK	TATA spare parts
885101990300	PROLIFE 697 BS III LONG BLOCK EX	TATA spare parts
885101990308	PROLIFE 483 DL EURO I LONG BLOCK	TATA spare parts
885101990314	PROLIFE DICOR 4 SP LONG BLOCK4 SP	TATA spare parts
885101990315	PROLIFE ISBE LONG BLOCK5.9BS IV UMBRELLA	TATA spare parts
885101990317	RECON LONG BLOCK 6BT CUM.	TATA spare parts
885101990342	PROLIFE WINGER LONG BLOCK 4DL TC	TATA spare parts
885101990343	RECON 483 DL LONG BLOCK	TATA spare parts
885101990344	PROLIFE WINGER¿ LONG BLOCK 4DL TC	TATA spare parts
885101990345	PROLIFE WINGER LONG BLOCK 4DL TC	TATA spare parts
885101990346	RECON ACE CUT SECTION MOTORISED	TATA spare parts

885101996920	RECON 692 DI LONG BLOCK	TATA spare parts
885103100145	R/C CRANKSHAFT 697NA	TATA spare parts
885103110125	PROLIFE FLYWHEEL FOR 310DIA.CLUTCH_BSIII	TATA spare parts
885103990133	PROLIFE FLYWHEEL FOR 352DIA.CLUTCH ASSY	TATA spare parts
885103999825	PROLIFE FLYWHEEL FOR 380DIA.CLUTCH ASSY	TATA spare parts
885105010102	PROLIFE C8.3G CNG BSIII Long Block	TATA spare parts
885105080101	PROLIFE 5.9G (6BG PLUS 230) LONG BLOCK	TATA spare parts
885107100163	RECON F.I.P. 697 NA	TATA spare parts
885107100294	RECON F.I.P. 697 TCK 6 B5.9	TATA spare parts
885107426330	PROLIFE FIP (ROTARY) 125HP EUROII 12V	TATA spare parts
8851075234AR	PROLIFE PUMP FUEL INJECTION	TATA spare parts
885107736892	PROLIFE F.I.P. 6 CTA E II (NOVUS)	TATA spare parts
885109999959	PROLIFE GAS MASS FLOW SENSOR	TATA spare parts
885114510114	TURBO CHARGER - RC	TATA spare parts
885115100106	RECON STARTER 24V	TATA spare parts
885115400107	RECON ALTERNATOR 24V	TATA spare parts
885115999905	PROLIFE ALTERNATOR 6 BT	TATA spare parts
885115999906	PROLIFE ALTERNATOR 6 BT	TATA spare parts
885115999966	PROLIFE STARTER MOTORS 6 BT	TATA spare parts
885115999967	PROLIFE STARTER MOTORS 6 BT	TATA spare parts
885115999968	RECON Starter Motor DTC	TATA spare parts
885120760001	PROLIFE 6BT CNG PERIPHERAL PARTS KIT	TATA spare parts
885120760103	PROLIFE ASSY 6BT ENGINE BS III_ver2	TATA spare parts
885120760118	PROLIFE ASSY 6BT ENGINE BS III	TATA spare parts
885120760390	PROLIFE ASSY 6BT ENGINE BS III_ver3	TATA spare parts
885121016860	PROLIFE GEAR BOX T14S10,W/PTO,NOVUS	TATA spare parts
885125200106	PROLIFE 352DIA.CLUTCH DISC SSY.(1.75IN S	TATA spare parts
885125200109	PROLIFE 310 DIA CLUTCH DISC ASSY-(REINF)	TATA spare parts
885125200128	PROLIFE 240 DIA.CLUTCH DISC ASSY	TATA spare parts
885125200134	PROLIFE 380DIA.CL.DISC ASSY(1.75IN SPL)	TATA spare parts
885125200151	PROLIFE 330DIA.CLUTCH DISC-ORGANIC	TATA spare parts
885125200163	PROLIFE 330 DIA.CLUTCH DISC-BUTTON TYPE	TATA spare parts
885125200190	PROLIFE 280 DIA CLUTCH DISC.ASSY	TATA spare parts
885125250127	PROLIFE LONG BLOCK 5.7SGI CNG BS6	TATA spare parts
885125250193	PROLIFE ASSY 697 CNG BS IV	TATA spare parts
885125250262	PROLIFE 697 BS III LONG BLOCK	TATA spare parts
885125270154	PROLIFE 3.8SGI CNG BS6 NA LONG BLOCK	TATA spare parts
885125270156	PROLIFE 3.8SGI CNG TCIC BS6 LONG BLOCK	TATA spare parts
885125270170	PROLIFE FULL ENGINE 497 TCIC BS-III	TATA spare parts
885125270395	PROLIFE ASSY 497 CNG BS IV	TATA spare parts
885125340339	PROLIFE DPF ASSY - SFC/SK/LP 4SPCR BS6	TATA spare parts
885125400102	PROLIFE 310 DIA CLUTCH COVER ASSY	TATA spare parts
885125400105	PROLIFE352DIA.CLCOVER SSY.-SETCO-1.75IN	TATA spare parts
885125400106	PROLIFE 280DIA.CLUTCH COVER ASSY	TATA spare parts
885125400107	PROLIFE352 DIA.CLCOVER ASSY.(1.75 SPLINE	TATA spare parts
885125400109	RECON352 DIA.CLCOVER ASSY.(SETCO)	TATA spare parts
885125400110	PROLIFE RELEASE BEARING ASSY.-1.75	TATA spare parts

885125400111	PROLIFE RELEASE BEARING ASSY.-1.75	TATA spare parts
885125400113	RECON RELEASE BEARING ASSY.-1.75	TATA spare parts
885125400114	PROLIFE 240 DIA. CLUTCH COVER ASSY	TATA spare parts
885125400117	RECON352 DIA.CLCOVER ASSY.(SETCO)	TATA spare parts
885125400121	PROLIFE 330DIA CLUTCHCOVER ASSY(COIL)CA	TATA spare parts
885125400129	PROLIFE380 DIA.CL.COVER ASSY(1.75IN SPLI	TATA spare parts
885125400130	PROLIFE 380 DIA.CL.COVER ASSY(1.75INSPLI	TATA spare parts
885125400135	PROLIFE170DIA.(CL.COVER ASSY + CL.DISC )	TATA spare parts
885125400138	PROLIFE 330 DIA.CLUTCHCOVER ASMBLY	TATA spare parts
885125400139	PROLIFE 330 DIA. CLUTCH COVER ASSY	TATA spare parts
885125400140	RECON 330 DIA. CLUTCH COVER ASSY SETCO	TATA spare parts
885125400166	PROLIFE 330DIA.CLUTCHCOVER ASSY.-SHEET M	TATA spare parts
885126000109	PROLIFE GBS ASSY .COMPLETE 4DL NA	TATA spare parts
885126000110	PROLIFE ZF 9S GEAR BOX-9.48 ratio	TATA spare parts
885126000111	PROLIFE GBS ASSY. COPMLETE 4DL TCIC	TATA spare parts
885126000112	RECON F.I.P. 697 TCK 6 B5.9	TATA spare parts
885126000113	PROLIFE ASSY. GEARBOX G550-6/6.9	TATA spare parts
885126000114	PROLIFE ZF 9S GEAR BOX- 12.73 ratio	TATA spare parts
885126000115	PROLIFE GEARBOX ASSY 4DLTCIC WINGER	TATA spare parts
885126000118	PROLIFE TA 70 TRANSAXLE ASSY -4DLTCIC WI	TATA spare parts
885126000119	PROLIFE ZF 9S GEAR BOX ASSY	TATA spare parts
885126000120	PROLIFE G550 -6/6.9 GEAR BOX ASSEMBLY	TATA spare parts
885126000121	PROLIFE YELLOW GEARBOX-550-6/6.9(EXPORT)	TATA spare parts
885126000123	G600 GB	TATA spare parts
885126010011	GEAR BOX 16R(DUMMY NO)	TATA spare parts
885126010102	PROLIFE G 65 ACE GEAR BOX ASSY	TATA spare parts
885126010103	RECON G 65 Ace Gear Box Assy	TATA spare parts
885126010104	RECON G 65 Ace Gear Box Assy	TATA spare parts
885126010105	PROLIFE YELLOW G65 ACE GEARBOX ASSY	TATA spare parts
885126010106	PROLIFE G 65 ACE GEAR BOX CUT SECTION	TATA spare parts
885126010110	PROLIFE ASSY GEAR BOX G1150-9/12.86 DD,P	TATA spare parts
885126010112	PROLIFE G1150 -9/12.86 DD GEAR BOX ASSEM	TATA spare parts
885126010119	PROLIFE GBS 600 ASSY (R-9.19)	TATA spare parts
885126010122	PROLIFE GBS 600 ASSY (R-8.47)	TATA spare parts
885126010128	RECON GBS 600 ASSY (R-8.47)-MODIFIED	TATA spare parts
885126010129	PROLIFE GBS 600 ASSY (R-8.47) MODIFIED	TATA spare parts
885126010139	PROLIFE ASSY GEARBOX G1150/9.371, 2'D/S	TATA spare parts
885126010155	RECON GBS 600 ASSY (R-8.47)-modified	TATA spare parts
885126010156	PROLIFE GBS 600 ASSY (R-9.19) MODIFIED	TATA spare parts
885126010157	G600 GB	TATA spare parts
885126010158	RECON GBS 600 ASSY (R-8.47)	TATA spare parts
885126010159	RECON GBS 600 ASSY (R-9.19) MODIFIED	TATA spare parts
885126010160	PROLIFE GBS 600 CUT SECTION	TATA spare parts
885126010161	RECON YELLOW GEARBOX- 600	TATA spare parts
885126010164	PROLIFE GBS 600 ASSY (R-6.58) OVERDRIVE	TATA spare parts
885126010168	PROLIFE GBS ASSY. G750-6/8.47	TATA spare parts
885126010169	PROLIFE ASSY. G750-6/8.47	TATA spare parts

885126010193	PROLIFE GBS600 ASSY(R-6.58) O/D MODIFIED	TATA spare parts
885126010194	RECON GBS 600 ASSY (R-6.58) O/D MODIFIED	TATA spare parts
885126010198	PROLIFE GBS ASSY. G750-6/9.19	TATA spare parts
885126020107	PROLIFE GBS 40 ASSY (R-7.51)TRUCK	TATA spare parts
885126020109	PROLIFE GBS40 ASSYR-7.51TRUCK CUT SEC	TATA spare parts
885126020117	PROLIFE ASSY.G750-6/8.47 TWIN CONE	TATA spare parts
885126020130	PROLIFE GBS ASSY( G750-6/9.19 TWIN CONE)	TATA spare parts
885126020132	PROLIFE G750 GEAR BOX ASSEMBLY - TWIN SY	TATA spare parts
885126030151	RECON LONG BLOCK 697 NA	TATA spare parts
885126040178	RECON LONG BLOCK 697 NA	TATA spare parts
885126040186	PROLIFE GBS 40 ASSY (R-7.508)TIPPER	TATA spare parts
885126040194	PROLIFE GBS 40 ASSY (R-7.51)BUS VERSION	TATA spare parts
885126790131	PROLIFE SLEEPER CABIN_COMFORT & RIDE1516	TATA spare parts
885127860298	PROLIFE ASSY 6BT ENGINE BS III_ver1	TATA spare parts
885127860314	Prolife ISBE LONG BLOCK 5.9 BSVI	TATA spare parts
885127860386	PROLIFE ASSY 6BT ENGINE BS III_ver3	TATA spare parts
885127860398	PROLIFE ASSY 6BT ENGINE BS III	TATA spare parts
885127863704	BLOCK CYLINDER	TATA spare parts
885127880112	PROLIFE ASSY 275 IDI ENGINE BS III	TATA spare parts
885127890308	PROLIFE 2.2L XENON BSVI LONG BLOCK BS6	TATA spare parts
885127970124	PROLIFE 475TCIC LONGBLOCK BSIII-superace	TATA spare parts
885128160127	PROLIFE SLEEPER CABIN_COMFORT & RIDE1516	TATA spare parts
885128160132	PROLIFE SLEEPER CABIN_COMFORT & RIDE1516	TATA spare parts
885128630119	PROLIFE ISLE 380 LONG BLOCK	TATA spare parts
885129000212	PROLIFE WIPER MOTOR ASSYS	TATA spare parts
885129500302	PROLIFE INVERTER MOBILE CHRGING_24V/150V	TATA spare parts
885129500401	PROLIFE ICU 600 IBIS COMMUNICATION MD	TATA spare parts
885129500403	PROLIFE FRONT DESTINATION BOARD	TATA spare parts
885129500404	PROLIFE SIDE DESTINATION BOARD	TATA spare parts
885129500405	PROLIFE REAR DESTINATION BOARD	TATA spare parts
885129500406	PROLIFE INTERNAL DESTINATION BOARD	TATA spare parts
885129600305	PROLIFE ELECTRIC FAN (24VDC) (REMI)	TATA spare parts
885132100102	PROLIFE INVERSION VALVE	TATA spare parts
885133000101	HCV REAR AXLE ASSY	TATA spare parts
885133000102	FRONT AXLE CUT SECTION	TATA spare parts
885133000106	HCV REAR AXLE ASSY	TATA spare parts
885133100102	PROLIFE ASSY BRAKE CALLIPER RH (ZF)	TATA spare parts
885133100103	PROLIFE ASSY BRAKE CALLIPER LH (ZF)	TATA spare parts
885133100122	PROLIFE SHOCK ABSORBER FRONT	TATA spare parts
885135000113	HCV REAR AXLE ASSY	TATA spare parts
885135000114	PROLIFE ACE REAR AXLE - YELLOW	TATA spare parts
885135000119	PROLIFE ACE REAR AXLE CUT-SEC STATIC	TATA spare parts
885135000372	HCV REAR AXLE ASSY	TATA spare parts
885135000373	REAR AXLE CUT SECTION	TATA spare parts
885135110103	PROLIFE CARRIER HOUSING 41/6 RA -10.8 RR	TATA spare parts
885135110105	PROLIFE CARRIER HOUSING 41/6 RA-108RR	TATA spare parts
885135110158	RECON Assy Brake Calliper RH (ZF)	TATA spare parts

885135110159	PROLIFE ASSY.CARRIER;(41/6-HN2)	TATA spare parts
885141100359	PROLIF CLUTCH 73.1.123(041-00227-000) AC	TATA spare parts
885141100360	PROLIFE ALTERNATOR150AMPS(041-L001-00)AC	TATA spare parts
885141100364	PROLIFE DASHCONTROL 12/24V AC	TATA spare parts
885142100101	PROLIFE RG2 RELAY VALVE	TATA spare parts
885142100102	RECON RG2 Relay Valve	TATA spare parts
885142100103	RECON RELAY VALVE CUT SECTION	TATA spare parts
885142100104	PROLIFE BRAKE ASSY. ELSA225H-LH meritor	TATA spare parts
885142100105	PROLIFE BRAKE ASSY. ELSA225H-RH meritor	TATA spare parts
885142100115	PROLIFE ASSY SLACK ADJUSTER(HALDEX)	TATA spare parts
885142103701	PROLIFE BRAKE DRUM RA109RR	TATA spare parts
885143700102	PROLIFE AIR DRIER UNIT	TATA spare parts
885143700103	PROLIFE SYSTEM PROTECTION VALVE M302911	TATA spare parts
885143700104	RECON LONG BLOCK 6BT CUM.	TATA spare parts
885143700105	PROLIFE DUAL BRAKE VALVE	TATA spare parts
885143700106	RECON Dual Brake Valve	TATA spare parts
885143700107	RECON DUAL BRAKE VALVE CUT SECTION	TATA spare parts
885143700108	RECON SYSTEM PROTECTION VALVE CUT SEC	TATA spare parts
885143700123	PROLIFE DUAL TREADLE VALVE (SCL)	TATA spare parts
885143700130	PROLIFE PRESSURE REDUCTION VALVE	TATA spare parts
885143700131	PROLIFE QUICK RELEASE VALVE M304500	TATA spare parts
885143700149	PROLIFE HAND BRAKE VALVE	TATA spare parts
885143700172	PROLIFE BRAKE ACTUATOR RH	TATA spare parts
885143700173	PROLIFE BRAKE ACTUATOR LH	TATA spare parts
885143700174	RECON Brake actuator RH	TATA spare parts
885143700175	RECON BRAKE ACTUATOR RH CUT SECTION	TATA spare parts
885146000109	PROLIFE ASSY.STG.G.BOX(CHINA HUBEI FORNI	TATA spare parts
885146000110	PROLIFE POWER STG.PUMP- DIRT DRIVE(SORLY	TATA spare parts
885146000111	PROLIFE ASSY.STG.GEAR BOX	TATA spare parts
885146000112	PROLIFE ASSY.STG.OIL PUMP DIRECT DRIVE	TATA spare parts
885146210121	PROLIFE ASSY. POWER STRG GEAR BOX-RH LCV	TATA spare parts
885146210122	PROLIFE ASSY. POWER STG GEAR BOX-RH	TATA spare parts
885146600102	PROLIFE STEERING GEAR BOX (ZF)	TATA spare parts
885146600104	PROLIFE ASSY. STG. GEAR BOX(CHINA )-SE/S	TATA spare parts
885146600105	PROLIFE ASSY.FORNI STG.GEAR BOX SE/SK	TATA spare parts
885146600106	PROLIFE DRAG LINK	TATA spare parts
885146600107	PROLIFE ASSY VANE PUMP- ZF	TATA spare parts
885146600108	CHINESE HCV PWR STRNG GB	TATA spare parts
885146600109	RECON F.I.P. 697 TCK 6 B5.9	TATA spare parts
885146600110	RECON ASSY. FORNI STG.GEARBOX CUT SEC.	TATA spare parts
885146600111	PROLIFE POWER STG.PUMPYBZ15A- BELT DRIVE	TATA spare parts
885146600112	PROLIFE POWER STG.PUMP- BELT DRIVE	TATA spare parts
885146600113	ASSY.STG.GEAR BOX(CHINA -HUBEI FORNI)	TATA spare parts
885146800143	PROLIFE ASSY. PUMPPOWER STRG. (CHIN) LCV	TATA spare parts
885146800144	PROLIFE ASSY. PUMP POWER STRG	TATA spare parts
885147700101	PROLIFE ASSY HPR (CLH I STAGE)	TATA spare parts
885150000117	PROLIFE RADIATOR WITH FRAME DTC	TATA spare parts



885150000118	PROLIFE INTERCOOLER HCBS	TATA spare parts
885150100105	PROLIFE AUXILLARY COOLANT TANK	TATA spare parts
885154109905	PROLIFE STARTER MOTOR- THERMAL CUT- OFF	TATA spare parts
885154209906	PROLIFE HORN (LOW TONE) 24V	TATA spare parts
885154209965	PROLIFE REMOTE BATTERY CUT-OFF SWITCH	TATA spare parts
885154249911	PROLIFE HORN (MINDA)	TATA spare parts
885154304905	PROLIFE MUX- 2B	TATA spare parts
885157010107	PROLIFE ISBe BS III 270 HP LONG BLOCK	TATA spare parts
885157010107_NIU	PROLIFE ISBe BS III 270 HP LONG BLOCK	TATA spare parts
885157010223	PROLIFE ISBe BS III 270 HP LONG BLOCK	TATA spare parts
885157060101	PROLIFE LONG BLOCK 3LNGE BS-IV	TATA spare parts
885157060105	PROLIFE ENGINE ASSY 3L NGE BS6_12V	TATA spare parts
885157060106	PROLIFE ENGINE ASSY 3LNG BS-IV_12V BUS	TATA spare parts
885157060146	PROLIFE LONG BLOCK 3.3L BS6 125HP (L6GN)	TATA spare parts
885157060158	PROLIFE ENGINE ASSY 3LNG BS-IV_24V BUS	TATA spare parts
885157060212	PROLIFE DOC ASSY - LPT/LP/ULTRA 3.3L BS6	TATA spare parts
885157060213	PROLIFE DPF ASSY - LPT/LP/ULTRA 3.3L BS6	TATA spare parts
885157090139	PROLIFE LONG BLOCK 3LNGE BS-IV	TATA spare parts
885157090148	PROLIFE 5L BS6 ENGINE LONG BLOCK	TATA spare parts
885157090152	PROLIFE LONG BLOCK 5L NGE BS6 210HP	TATA spare parts
885157090190	PROLIFE DOC ASSY - MHCV TRUCK 5L BS6	TATA spare parts
885157090198	PROLIFE DOC ASSY - MHCV TIPPER 5L BS6	TATA spare parts
885157100105	Prolife ASSY ACE DICOR NA	TATA spare parts
885157100109	PROLIFE ACE MEGA BSIV LONG BLOCK	TATA spare parts
885157100169	PROLIFE ENGINE LONG BLOCK 800CC DICOR BS	TATA spare parts
885157170000	PROLIFE ASSY GREAVES ENG BS III	TATA spare parts
885157175402	Prolife Alternator_Starter motor kit ZIP	TATA spare parts
885157240124	PROLIFE LONG BLOCK 1.5L CRAIL BS6	TATA spare parts
885157360105	PROLIFE ACE 700CC DICR BS-VI ENGINE ASSY	TATA spare parts
885157360114	PROLIFE ACE 700CC BS6 ENGINE LONG BLOCK	TATA spare parts
885157370149	PROLIFE ISBE LONG BLOCK5.9BS IV UMBRELLA	TATA spare parts
885157370151	PROLIFE ISBE LONG BLOCK5.9BS IV UMBRELLA	TATA spare parts
885160000119	PROLIFE NON SLEEPER CABIN ( 1109 TYPE )	TATA spare parts
885160000145	PROLIFE SLEEPER CABIN( 1109 TYPE )	TATA spare parts
885160000302	PROLIFE FIP (ROTARY) 180 HP EUROIII	TATA spare parts
885160000312	PROLIFE 6BT BS-III LONG BLOCK ( 235 HP)	TATA spare parts
885160000316	PROLIFE TURBOCHARGER 180 HP BSIII	TATA spare parts
885160110126	PROLIFE SLEEPER CABIN_COMFORT & RIDE1516	TATA spare parts
885160110127	PROLIFE SLEEPER CABIN( 1516 TYPE )	TATA spare parts
885160110144	PROLIFE NON SLEEPER CABIN ( 1516 TYPE )	TATA spare parts
885160120106	PROLIFE SLEEPER CABIN_COMFORT & RIDE1516	TATA spare parts
885162208224	FRONT INNER ASSY KIT	TATA spare parts
885162508201	FRONT ASSY KIT	TATA spare parts
885165708210	ROOF ASSY KIT	TATA spare parts
885166600120	BOTTOM ASSY KIT	TATA spare parts
8851A2750005	BARE ENGINE ASSY	TATA spare parts
8851A2750006	RECON 275¿ SHORT¿ BLOCK -ACE MODEL-CORE	TATA spare parts

8851A2750007	PROLIFE 275IDI LONG BLOCK MAGIC_CORE	TATA spare parts
8851A2750009	RECON(LLZC) 275 IDI LONG BLOCK CORE CNG	TATA spare parts
8851A2750010	Recon 275 IDI Long Block- BS IV- CORE	TATA spare parts
8851A2750014	BARE ENGINE ASSY	TATA spare parts
8851A2750020	Prolife Ace Dicor NA long block	TATA spare parts
8851A2750021	CYL CRANKCASE ASSY WITH BEDPLATE	TATA spare parts
8851A2750109	PROLIFE ACE MEGA BSIV LONG BLOCK CORE	TATA spare parts
8851A3NGN001	PROLIFE LONG BLOCK 3L NGE BS-IV_CORE	TATA spare parts
8851A4094089	PROLIFE ALTERNATOR DTC	TATA spare parts
8851A4750001	RECON 475 TCIC Long Block BSIII Core	TATA spare parts
8851A4750002	CYLINDER CRANKCASE ASSY	TATA spare parts
8851A4750005	PROLIFE SUPERACE DICOR LONG BLOCK_(CORE)	TATA spare parts
8851A4830016	RECON WINGER LONG BLOCK TC- core	TATA spare parts
8851A4970005	Recon(LLK) 497 CMVR long block core	TATA spare parts
8851A4970008	Recon(LLV)497 Euro II long Block Core	TATA spare parts
8851A4970010	Recon 497 Euro III long block Core	TATA spare parts
8851A4970012	Recon 497 Euro III long block CoreLP1512	TATA spare parts
8851A4970015	PROLIFE ASSY LONG BLOCK 497CR BS-IV CORE	TATA spare parts
8851A4970016	PROLIFE LONG BLOK 497 NA CNG BS IV SGI-C	TATA spare parts
8851A4970018	Prolife LONG BLOCK 497 Y1 BS-III- core	TATA spare parts
8851A4970022	PROLIFE 497TCIC BS-III LONG BLOCK( UT )	TATA spare parts
8851A4SP0005	Recon 497 SP TC long block core	TATA spare parts
8851A4SP0008	Recon 4 SP Euro II long block core	TATA spare parts
8851A4SP0010	Recon 4 SP Euro III long block core	TATA spare parts
8851A4SPDI01	PROLIFE DICOR 4 SP LONG BLOCK _CORE	TATA spare parts
8851A5263220	PROLIFE ALTERNATOR 26021592	TATA spare parts
8851A5736105	PROLIFE ACE 700 CC DICR BSVI ENGINE_CORE	TATA spare parts
8851A5736114	PROLIFE ACE 700CC BS-VI LONG BLOCK_CORE	TATA spare parts
8851A5NGN001	PROLIFE LONG BLOCK 5LNGE BS-IV_CORE	TATA spare parts
8851A6970005	Recon 697 NA CMVR long block core	TATA spare parts
8851A697CNG2	PROLIFE LONG BLOCK- 697 CNG BSIV CORE	TATA spare parts
8851A6BT00013	PROLIFE ASSY.318CC AIR COMPRESSOR- core	TATA spare parts
8851A6BT0002	PROLIFE 6BT LONG BLOCK E-1 _CORE	TATA spare parts
8851A6BT0004	Recon(LLP) 6 BT Euro II Long block core	TATA spare parts
8851A6BT0006	Recon 6 BT Euro III Long block core	TATA spare parts
8851A6BT0007	Recon6 BT Euro III Long block 180HP core	TATA spare parts
8851A6BT0009	RECON ISBe EURO III LONG BLOCK 240 HP-co	TATA spare parts
8851A6BT0012	Recon 6 BT long block core (235HP)	TATA spare parts
8851A6BT0014	Recon 6 BT Euro II Long block core 3118	TATA spare parts
8851A6BT0015	RECON ISBe EURO III LONG BLOCK 270 HP-CO	TATA spare parts
8851A6BT0018	RECON 6BT EUROIII LONG BLOCK W/O INJ CO	TATA spare parts
8851A6BT0026	PROLIFE 235 HP 6 BT E-III long block CO	TATA spare parts
8851A6BT0050	PROLIFE ISBe LONG BLOCK 5.9 LTR( CORE )	TATA spare parts
8851A6BT0053	Prolife ISBE LONG BLOCK 5.9 BSIV Core	TATA spare parts
8851A6TC0005	Recon(LLE) 697 TC CMVR long block core	TATA spare parts
8851A6TC0008	Recon(LLQ) 697 Euro II long block core	TATA spare parts
8851A6TC0010	Recon(LLR) 697 Euro III long block core	TATA spare parts

8851AALTN0003	RECON Alternator 6 Bt CORE	TATA spare parts
8851AALTN0004	RECON Alternator 26021592 core	TATA spare parts
8851AALTN0005	RECON ALTERNATOR 150AMPS AC- core	TATA spare parts
8851ABAL0001	Brake actuator LH Core	TATA spare parts
8851ABAR0001	Brake actuator RH CORE	TATA spare parts
8851ABCS0001	PROLIFE REMOTE BATTERY CUT-OFF SWITCH co	TATA spare parts
8851ACAC0001	Prolife CLUTCH 73.1.123 AC core	TATA spare parts
8851ACAL0003	PROLIFE BRAKE ASSY.ELSA225H-LHmeritor-Co	TATA spare parts
8851ACAL0004	PROLIFE BRAKE ASSY.ELSA225H-RHmeritor-Co	TATA spare parts
8851ACLC0001	PROLIFE352DIA.CL.COVR ASSY.(1.75"SP)CORE	TATA spare parts
8851ACLC0005	RECON 352DIAA. CL DIS ASSY SETCO core	TATA spare parts
8851ACLC0006	RECON 380DIA.CL.COVERASSY1.75"SPLI CORE	TATA spare parts
8851ACLC0022	PROLIFE 380 DIA.CL.DISC .(1.75"SP )_CO	TATA spare parts
8851ACNG0003	RECON CNG LEAN BRN LONG BLOCK B5.9 core	TATA spare parts
8851ACNG0004	RECON C8.3G CNG BSIII Long Block Core	TATA spare parts
8851ACNG0005	RECON 5.9G (6BG PLUS 230)LONG BLOCK Core	TATA spare parts
8851ACOU0001	Consep Unit CORE	TATA spare parts
8851ADB0001	Dual Brake Valve DTC Core	TATA spare parts
8851ADB0002	RECON DUAL TREADLE VALVE (SCL)- core	TATA spare parts
8851ADRL0002	Recon DRAG LINK- Core	TATA spare parts
8851ADRU0001	Air drier unit Core	TATA spare parts
8851AEDB0001	FRONT DESTINATION BOARD Core	TATA spare parts
8851AEDB0002	REAR DESTINATION BOARD Core	TATA spare parts
8851AEDB0004	Prolife INTERNAL DESTINATION BOARD Core	TATA spare parts
8851AG115001	Prolife ASSY COMP G1150-9/12.86 -core	TATA spare parts
8851AG550001	RECON ASSY. GEARBOX G550-6/6.9 - core	TATA spare parts
8851AG600003	CORE-RECON GBS 600 ASSY (R-6.58) OD	TATA spare parts
8851AG600004	CORE-RECON GBS 600 ASSY(R-8.47)-modified	TATA spare parts
8851AG600005	CORE-RECON GBS 600 ASSY(R-9.19)-modified	TATA spare parts
8851AG750002	CORE-RECON ASSY. G750-6/8.47	TATA spare parts
8851AG750003	CORE-RECON ASSY. G750-6/9.19	TATA spare parts
8851AG750004	RECON ASSY GB ( G750-6/9.19 TWINCONE)-co	TATA spare parts
8851AG750006	PROLIFE ASSY.G750-6/8.47 TWIN CONE _core	TATA spare parts
8851AGRE0001	RECON GREAVES LONG BLOCK CORE	TATA spare parts
8851AGRE0003	PROLIFE ASSY GREAVES ENG CORE	TATA spare parts
8851AGTA0001	RECON ASSY .GEARBOX COMPLETE 4DL NA - CO	TATA spare parts
8851AGTA0002	PROLIFE GEARBOX COMPLETE 4DL TCIC - CORE	TATA spare parts
8851AGZF0002	Recon ZF 9S Gear box -12.73 _core	TATA spare parts
8851AHBV0001	Prolife Hand Brake Valve core	TATA spare parts
8851AHON0001	RECON HORN (LOW TONE) 24V CORE	TATA spare parts
8851AHON0002	RECON HORN (MINDA) CORE	TATA spare parts
8851AINT0001	DTC Intercooler Core	TATA spare parts
8851AINV0001	Prolife INVERSION VALVE core	TATA spare parts
8851ALEV0001	RECON LEVELLING VALVE- CORE	TATA spare parts
8851APRV0001	Prolife Pressure Reduction Valve core	TATA spare parts
8851APSG0001	RECON ASSY.STG.GEAR BOX(CHINA )- Core	TATA spare parts
8851APSG0004	ASSY. POWER STRG GEAR BOX (CHINESE)CORE	TATA spare parts

8851APSG0006	Recon Steering gear box (ZF)CORE	TATA spare parts
8851AQRV0001	Quick Release Valve Core	TATA spare parts
8851AREV0001	RG2 Relay Valve Core	TATA spare parts
8851ASAD0002	Prolife Assy SLACK ADJUSTER(Haldex) - Co	TATA spare parts
8851ASAF0001	Shock Absorber Front Core	TATA spare parts
8851ASAR0001	Recon Shock Absorber Rear Core	TATA spare parts
8851ASPV0001	System protection valveCORE	TATA spare parts
8851ATCJ0001	PROLIFE TURBOCHARGER - 125 HP	TATA spare parts
8851ATCJ0004	Recon Turbocharger 697 E II 145HP core	TATA spare parts
8851ATCJ0005	ReconTurbocharger235 HPGas engHX35G core	TATA spare parts
8851ATCJ0008	Recon Turbocharger 180 HP BSIII- core	TATA spare parts
8851AWMA0001	Wiper motor assysCORE	TATA spare parts
8851AXEN0001	PROLIFE 2.2L LONG BLOCK BS IV _CORE	TATA spare parts
8851C10110LA	PROLIFE 6BT BS II (3118) LONG BLOCK	TATA spare parts
8851C3536474	PROLIFE TURBO CHARGER 160 HP	TATA spare parts
8851C3536475	PROLIFE TURBOCHARGER ç 160 HP	TATA spare parts
8851C3536476	RECON TURBOCHARGER 160 HP	TATA spare parts
8851C3590794	PROLIFE TURBO CHARGER - 125HP	TATA spare parts
8851C3590795	CUMMINS HX35 TURBOCHARGER	TATA spare parts
8851C3590796	PROLIFE TURBOCHARGER ç 125 HP	TATA spare parts
8851C3590797	RECON TURBOCHARGER CUT SECTION	TATA spare parts
8851C3596691	PROLIFE TURBOCHARGER 130 HP 697 HIGH TQ	TATA spare parts
8851C3596692	PROLIFE TURBOCHARGER ç 130 HP 697 (E 1)	TATA spare parts
8851C3599492	Prolife Turbocharger HX35G	TATA spare parts
8851C3700102	PROLIFE CONSEP UNIT	TATA spare parts
8851C3931837	RECON F.I.P. 697 NA	TATA spare parts
8851C3931838	PROLIFE F.I.P. 6 BT	TATA spare parts
8851C3931858	PROLIFE 6BT BS II LONG BLOCK	TATA spare parts
8851C3931859	PROLIFE 6BT BS II LONG BLOCK (WITH AC)	TATA spare parts
8851C3931860	RECON LONG BLOCK 6BT CUM.	TATA spare parts
8851C3931861	6BT MOTORIZED ENGINE	TATA spare parts
8851C3931862	RECON LONG BLOCK 6BT CUM.	TATA spare parts
8851C3931863	RECON LONG BLOCK 6BT CUM.	TATA spare parts
8851C3931864	RECON 6BT YELLOW ENGINE	TATA spare parts
8851C3931865	PROLIFE 6BT ENGINE CUTSEC MOTORIZED	TATA spare parts
8851C3931866	PROLIFE 6BT LONG BLOCK CUT SECTIONç STAT	TATA spare parts
8851C3931867	PROLIFE 6 BT EURO II LONG BLOCK	TATA spare parts
8851C3931901	PROLIFE 6BT BSI CUM LONG BLOCK	TATA spare parts
8851C3931901EX	6BT long block excavator	TATA spare parts
8851C3931902	PROLIFE LONG BLOCK 6BT WITH WP & AC	TATA spare parts
8851C3931903	PROLIFE 6BT LONGBLOCK (WITH SidePort AC)	TATA spare parts
8851C3931904	RECON LONG BLOCK 6BT CUM.	TATA spare parts
8851C3931906	PROLIFE LONG BLOCK 6BT CUM.	TATA spare parts
8851C3990124	PROLIFE ASSY.318CC AIR COMPRESSOR	TATA spare parts
8851C4037497	PROLIFE TURBOCHARGER 145 HP 697 (E 2)	TATA spare parts
8851C4037498	PROLIFE TURBOCHARGER ç145 HP 697 (E 2)	TATA spare parts
8851C4080670	PROLIFE 6 BT AIR COMPRESSOR SIDE PORT	TATA spare parts

8851C4080671	PROLIFE 6 BT AIR COMPRESSOR TOP PORT	TATA spare parts
8851C4080672	PROLIFE 6 BT AIR COMPRESSOR SIDE PORT	TATA spare parts
8851C4080673	RECON TURBOCHARGER 160 HP	TATA spare parts
8851C4946294	RECON 6 BT AIR COMPRESSOR DTC	TATA spare parts
8851C60230LA	PROLIFE 6BT BS III CUM 130HP LONG BLOCK	TATA spare parts
8851C60234LA	PROLIFE 6 BT BS II LONG BLOCK (235HP)	TATA spare parts
8851C60234LB	PROLIFE 6 BT EURO II LONG BLOCK (235HP)	TATA spare parts
8851C60275LA	PROLIFE 6BT BS III CUM 180HP LONG BLOCK	TATA spare parts
8851C60318LA	PROLIFE ISBe BS III 270 HP LONG BLOCK	TATA spare parts
8851C60318LB	PROLIFE ISBE EURO III LONG BLOCK 270 HP	TATA spare parts
8851C60330LA	PROLIFE ISBe BS III 240 HP LONG BLOCK	TATA spare parts
8851CNG6B59L	RECON CNG LONG BLOCK 6 B5.9	TATA spare parts
8851CS06933L	LONG BLOCK-4021 (RECONDITIONED)	TATA spare parts
8851E0001229	GEAR HOUSING	TATA spare parts
8851E0001408	CYLINDER HEAD SIDE PORT	TATA spare parts
8851E0001410	CYLINDER HEAD SIDE PORT	TATA spare parts
8851E0348091	GEAR HOUSING	TATA spare parts
8851E0348101	GEAR HOUSING	TATA spare parts
8851E1153412	VALVE SEAT RING NORMAL-1	TATA spare parts
8851E1153413	VALVE SEAT EXHAUST STD1	TATA spare parts
8851E1153414	VALVE SEAT RING NORMAL-1	TATA spare parts
8851E1153415	VALVE SEAT EXHAUST STD1	TATA spare parts
8851E1156B01	VALVE SEAT EXHAUST STD1	TATA spare parts
8851E1156B02	VALVE SEAT EXHAUST STD1	TATA spare parts
8851E1156B03	VALVE SEAT EXHAUST STD1	TATA spare parts
8851E1156B04	VALVE SEAT EXHAUST STD1	TATA spare parts
8851E1400192	CYLINDER HEAD SIDE PORT	TATA spare parts
8851E1537342	CYLINDER HEAD SIDE PORT	TATA spare parts
8851E1556604	CYLINDER HEAD SIDE PORT	TATA spare parts
8851E1556944	CYLINDER HEAD SIDE PORT	TATA spare parts
8851E1558042	CYLINDER HEAD SIDE PORT	TATA spare parts
8851E2789108	PROLIFE XENON 2.2 L KIT	TATA spare parts
8851E3519336	WHEEL SHAFT	TATA spare parts
8851E3936620	CRANK RECON(BIGEND RS1)	TATA spare parts
8851E3936621	crank recon(main RS1)	TATA spare parts
8851E3936895	DUST COVER	TATA spare parts
8851E3964422	GEAR HOUSING	TATA spare parts
8851E3965953	PROLIFE MODULE ELECTRONIC CONTROL BGI	TATA spare parts
8851E4018164	CYLINDER HEAD SIDE PORT	TATA spare parts
8851E5016252	CYLINDER HEAD SIDE PORT	TATA spare parts
8851E513SH01	SHIM 2.50 THK.	TATA spare parts
8851E513SH02	SHIM 2.50 THK.	TATA spare parts
8851E513SH03	SHIM 2.50 THK.	TATA spare parts
8851E513SH04	SHIM 2.50 THK.	TATA spare parts
8851E513SH05	SHIM 2.50 THK.	TATA spare parts
8851E513SH06	SHIM 2.50 THK.	TATA spare parts
8851E9052174	CYLINDER HEAD SIDE PORT	TATA spare parts

8851E9L01500	REPAIR KIT	TATA spare parts
8851EAIL1360	ROD ENGINE CONNECTING	TATA spare parts
8851ECBS4911	BRG.HALF NORMAL-CON.ROD	TATA spare parts
8851ECRS4961	CR BUSH KLOSR	TATA spare parts
8851EE030002	BARE PISTON LOW HEIGHT 697 TC BSI	TATA spare parts
8851EJ200001	INTEGRAL SHAFT BEARING	TATA spare parts
8851EJBUS002	BUSH CON ROD-6B-RS1-(OD:43.38)	TATA spare parts
8851EJLIN106	SLEEVE SALVAGE 106OD W/COLLAR	TATA spare parts
8851EMBS4921	MAIN BRG.HALF STD.(CRK.SHAFT)(BENARA	TATA spare parts
8851EQ030001	PISTON, 0.3mm LOW COMP HT.-697TC-BSII	TATA spare parts
8851ES119520	CON ROD BUSH-TC	TATA spare parts
8851ESLG0001	GASKET, TUBE(100GM) RTV SILICON	TATA spare parts
8851ETWL4682	THRUST WASHER LOWER 69 DIA	TATA spare parts
8851ETWU4682	THRUST WASHER UPPER 69 DIA	TATA spare parts
8851EVC17503	WASHER C/SHAFT GEAR	TATA spare parts
8851EX000001	SET PISTON AND RINGS_ RECON KIT	TATA spare parts
8851EX000002	SET BEARING AND BUSH_ RECON KIT	TATA spare parts
8851EX000003	ASSY CYL HD WITH GUIDE VALVE SEAL_ RECON	TATA spare parts
8851EX000004	SUB ASSY PARTS_ RECON KIT	TATA spare parts
8851EX000005	SET TIMING GEAR BELT AND COVER_ RECON KIT	TATA spare parts
8851EX000006	WASHER CORE PLUG MAG PLUG LOCKHALF_ RECON	TATA spare parts
8851EX000007	GASKET AND SEAL_ RECON KIT	TATA spare parts
8851EX000008	CRANK CR SHAFT CAMSHAFT CONROD_ RECON KIT	TATA spare parts
8851EX044595	ACTUATOR KIT ASSEMBLY	TATA spare parts
8851EZ030001	PISTON, 0.3mm LOW COMP HT-GRADE A (ACE)	TATA spare parts
8851EZ030003	PISTON 0.3MM LOW COMP HT-GRADE-A(S.ACE)	TATA spare parts
8851EZ180001	GEAR HOUSING	TATA spare parts
8851EZ180007	COVER PLATE (SFL# OP 427-02)	TATA spare parts
8851EZ180008	PLUG (SFL# OP 272-05)	TATA spare parts
8851EZ180009	SPRING (SFL# OP 427-06M1)	TATA spare parts
8851EZ180010	SPRING RETAINER (SFL# OP 427-08M)	TATA spare parts
8851EZ180011	PLUNGER (SFL# OP 427-07M)	TATA spare parts
8851EZ180012	C SUNK SCREW (SFL# OP 427-09)	TATA spare parts
8851EZ180013	WASHER (SFL# OP 427-10)	TATA spare parts
8851EZ180014	DOWEL PIN (SFL# OP 272-11)	TATA spare parts
8851EZBUS001	BUSH CON ROD - ACE-RS1- (OD: 26.40MM)	TATA spare parts
8851EZLN0001	LINER- INDIGO COLLARED, CYLINDER	TATA spare parts
8851EZLN0002	LINER- INDIGO 0.50MM O/S (20TH)	TATA spare parts
8851EZLN0004	LINER- INDIGO 1.00MM O/S (20TH)	TATA spare parts
8851F3936619	PROLIFE FIP (ROTARY) 160HP EUROII 24V	TATA spare parts
8851K278801150102	Assy. CYLINDER HEAD WITHOUT VALVES	TATA spare parts
8851K3925389	cyl head bare	TATA spare parts
8851K570601160102	INJECTOR 3L CORE 8409.91.99	TATA spare parts
8851K573649100101	SDPF ASSY WITH MIXER	TATA spare parts
8851S4093888	PROLIFE STARTER MOTOR DTC	TATA spare parts
8851TKAD0001	SPECIAL TOOL KIT FOR ENGINE (ACE DIESEL)	TATA spare parts
8851TKAD0002	SPECIAL TOOL KIT FOR GEAR BOX-ACE DIESEL	TATA spare parts

8851TKAD0003	SPECIAL TOOL KIT FOR REARAXLE-ACE DIESEL	TATA spare parts
8851TKAD0004	SPECIAL TOOL KIT FOR MISC- ACE DIESEL	TATA spare parts
8851TKAD0005	SPECIAL TOOL KIT_ ENG STAND_ ACE DIESEL	TATA spare parts
8851TKAD0006	SPECIAL TOOLKIT_ CARR. HOUS. STAND_ ACE D	TATA spare parts
8851TKCB0001	SPECIAL KIT_ CYL.BLK LEKG TEST6BT/697/497	TATA spare parts
8851TKWD0001	SPECIAL TOOL KIT_ ENGINE_ WINGER DIESEL	TATA spare parts
8851TKWD0002	SPECIAL TOOL KIT_ FRONTAXLE_ WINGER DIESEL	TATA spare parts
8851TKWD0003	SPECIAL TOOL KIT_ TA-70_ WINGER DIESEL	TATA spare parts
8851TKWD0004	SPECIAL TOOL KIT_ REAR AXLE_ WINGER DIESEL	TATA spare parts
8851TKWD0005	SPECIAL TOOL KIT_ MISC_ WINGER DIESEL	TATA spare parts
885201000201	ENGINE YELLOW 697 NA	TATA spare parts
885226000501	YELLOW GEAR BOX ASSY GBS4	TATA spare parts
885226000702	G76 YELLOW GEAR BOX	TATA spare parts
885246000701	YELLOW STRG.GEAR ASSY	TATA spare parts
88540000002	KANPUR ERROR 7	TATA spare parts
885400011613	EOK 697 BS III STD	TATA spare parts
885400012525	EOK 697CRDI BS4 STD	TATA spare parts
885400012527	EOK 497 STD CRB MB FOR IB	TATA spare parts
885400012534	EOK 4SPCR BS4 STD	TATA spare parts
885400012788	ACE GASKET KIT W/O CYL HEAD GASKET FOR I	TATA spare parts
885400012789	OIL + FUEL FILTER KIT 40K/80K 2.2L BS6	TATA spare parts
885400013138	MRLS KIT DRDO 3138	TATA spare parts
885400015701	KIT-40K KMS SERVICE-OIL DEF FILTERS BS6	TATA spare parts
885400015706	EOK 3L BS4 STD	TATA spare parts
885400015709	EOK 5L BS4 STD	TATA spare parts
885400015710	KIT-40K KMS SERV-OIL+FUEL+AIR FILTER-V10	TATA spare parts
885400015735	KIT-30K SER-OIL FUEL FILTER-ACE PTRL BS6	TATA spare parts
885400015736	KIT-40K KMS SERV-OIL FUEL AIR FILTER-ACE	TATA spare parts
885400022527	EOK 497 STD CRB MB FOR IB	TATA spare parts
885400022534	EOK 4SPCR BS4 YODHA STD	TATA spare parts
885400022789	OIL+FUEL+AIR FILTER KIT 40K/80K 2.2L BS6	TATA spare parts
885400025701	KIT-120K KMS SERVICE-OIL FUEL DEF FILTER	TATA spare parts
885400025706	KIT DECARBONISING GASKET_1.4MM CH Gasket	TATA spare parts
885400025709	KIT-SERVICE-60K-OIL+FUEL FILTER-5L BS6 I	TATA spare parts
885400025735	KIT-30K KMS SERV-OIL+LP FILTER-ACE CNG B	TATA spare parts
885400032527	EOK 497CRDI BS4 STD	TATA spare parts
885400032534	KIT-SERVICE-40K-OIL+FUEL FILTER-4SPCR BS	TATA spare parts
885400032789	EOK WINGER 2.2L BS4 STD	TATA spare parts
885400035706	KIT-SERVICE-60K-OIL+FUEL FILTER 3.3L BS6	TATA spare parts
885400035709	KIT-SERVICE-80K-OIL+FUEL FILTER-5L BS6 M	TATA spare parts
885400035735	KIT-40K KMS SERV-OIL+AIR FILTER-ACE CNG	TATA spare parts
885400042527	EOK 3.8SGI BS4 STD	TATA spare parts
885400042789	EOK XENON 2.2 L EURO 2 TUNISIA	TATA spare parts
885400052527	497 ENGINE OVERHAUL GASKET KIT (MLS GASK	TATA spare parts
885401011014	KIT-DECARBONISING GASKET	TATA spare parts
885401011109	KIT-ENGINE OVERHAUL STD 497 BS3	TATA spare parts
885401011613	SET VALVE INTAKE AND EXHAUST	TATA spare parts

885401012516	KIT UPPER ENGINE GASKETS	TATA spare parts
885401012518	CUMMINS HEAD REPAIR KIT BS2	TATA spare parts
885401012527	ENGINE OVERHAUL KIT 497NA	TATA spare parts
885401012534	ENGINE OVERHAUL KIT 4SP NA	TATA spare parts
885401012786	VALVE KIT 6BT BS II	TATA spare parts
885401012788	KIT-ENGINE OVERHAUL ACE	TATA spare parts
885401012789	VALVE SEAT KIT	TATA spare parts
885401012797	KIT-GASKET ENG O/H SUPER ACE 1.3 THK	TATA spare parts
885401012818	KIT-ENG. O/H SUP ACE(1.7? CYL. HD GSKT)	TATA spare parts
885401012829	KIT-ENG. O/H ACE (1.8 GASKET COL LINER)	TATA spare parts
885401013118	NON COLLARED CYLINDER LINER 6 BT	TATA spare parts
885401014923	ENGINE OVERHAUL KIT FOR TCL ENGINE	TATA spare parts
885401014923AE	ENG OVERHAUL KIT TCL ENG -2523	TATA spare parts
885401015523	EOK ACE BS4(1.8 GASKET COLLINER STD.BRG)	TATA spare parts
885401015537	KIT-DECARBONISING GASKET WITH 1.2 THK CY	TATA spare parts
885401015546	GASKET KIT ENG O/H W/CYL HD GASKET 1.3th	TATA spare parts
885401015701	SET CYL LINER STD 6.7 BS3/4/6	TATA spare parts
885401015708	KIT-ENG. O/H ACE CNG (COL LINER STD BRG)	TATA spare parts
885401015710	KIT-DECARBONISING WITH CYLD HEAD GSKT TH	TATA spare parts
885401015736	KIT-ENGINE O/H GASKET-CYL HD 0.3 THK BS6	TATA spare parts
885401021014	KIT CYLINDER HEAD GASKET 1.3 MM THK 3LNG	TATA spare parts
885401021109	ENGINE OVERHAUL KIT 497 BSIII RS1	TATA spare parts
885401022516	KIT LOWER ENGINE GASKETS	TATA spare parts
885401022527	ENGINE OVERHAUL KIT 497 TURBO	TATA spare parts
885401022786	KIT-VALVE 6BT BS3	TATA spare parts
885401022788	KIT-ENG. O/H? ACE (1.7 THK CYL. HD GSKT)	TATA spare parts
885401022797	KIT-GASKET ENG O/H SUPER ACE 1.4 THK	TATA spare parts
885401022829	ENG. O/H KIT ACE (1.7 GASKET COL LINER S	TATA spare parts
885401025523	EOK ACE BS4 (1.8 GASKET COL LINER RS1)	TATA spare parts
885401025537	KIT-DECARBONISING GASKET WITH 1.3 THK CY	TATA spare parts
885401025546	GASKET KIT ENG O/H W/CYL HD GASKET 1.5th	TATA spare parts
885401025708	EOK FOR ACE CNG (RS1 BRG)	TATA spare parts
885401025710	KIT-ENG OVERHAUL WITH CYLD HEAD GASKET 1	TATA spare parts
885401025736	KIT-ENGINE O/H GASKET-CYL HD 0.4 THK BS6	TATA spare parts
885401030713	KIT FOR CYLINDER BLOCK	TATA spare parts
885401031014	KIT CYLINDER HEAD GASKET 1.4 MM THK 3LNG	TATA spare parts
885401032516	ENGINE OVERHAUL KIT 6BT ENGINE	TATA spare parts
885401032534	ENGINE O H SEAL KIT	TATA spare parts
885401032786	VALVE KIT 6BT CNG	TATA spare parts
885401032788	KIT-ENG. O/H ACE (1.8 THK CYL HD GASKET)	TATA spare parts
885401032797	KIT-GASKET ENG O/H SUPER ACE 1.5 THK	TATA spare parts
885401032829	ENG. O/H KIT ACE (1.6 GASKET COL LINER S	TATA spare parts
885401035537	KIT-ENGINE OVERHAUL GASKET WITH 1.2 THK	TATA spare parts
885401035710	KIT-DECARBONISING W/CYLD HEAD GSKT 1.1MM	TATA spare parts
885401035736	EOK KIT ACE 700CC BS6 STD	TATA spare parts
885401040713	KIT FOR CYLINDER HEAD	TATA spare parts
885401042525	ENGINE OVERHAUL KIT 697 NA	TATA spare parts



885401042527	SERVICE KIT FOR 20K KMS-ILCV/BUS CNG BS6	TATA spare parts
885401042534	CYL HEAD O H SEAL KIT	TATA spare parts
885401042547	KIT DECARB GASKET 1.6 THK TC	TATA spare parts
885401042786	GASKET KIT FOR RING REPLACEMENT 6BT BS I	TATA spare parts
885401042788	ENG.O/H GASKET (W/- 1.7 THK CYL HD GASKE	TATA spare parts
885401042829	KIT-ENG. O/H? ACE (1.8 GASKET COL LINER)	TATA spare parts
885401045537	KIT-ENGINE OVERHAUL GASKET WITH 1.3 THK	TATA spare parts
885401045710	KIT-ENG OVERHAUL W/CYLD HEAD GSKT 1.2MM	TATA spare parts
885401052516	KIT-ENGINE OVERHAUL W/O VLV 6BT BS1/2/3	TATA spare parts
885401052534	ENGINE OVERHAUL KIT 4SP NA PRE96	TATA spare parts
885401052547	ENGINE OVERHAUL KIT 207 DI 4SP BSII	TATA spare parts
885401052786	SET CYL LINER STD 5.9 BS3/4/6	TATA spare parts
885401052788	ENG. O/H GASKET (1.8 THK CYL HD GSKT)	TATA spare parts
885401052829	ENG. O/H KIT ACE (1.7 GASKET COL LINER R	TATA spare parts
885401055710	KIT-DECARBONISING W/CYLD HEAD GSKT 1.3MM	TATA spare parts
885401062525	ENGINE O H SEAL KIT	TATA spare parts
885401062547	KIT-ENGINE OVERHAUL WINGER 483DL BS3/4	TATA spare parts
885401062786	EOK KIT ISBE5.9 UMB BS4 (WB)-STD	TATA spare parts
885401062788	ENG.O/H GASKET SUB-KIT (BS-II) W/- 1.7 T	TATA spare parts
885401062829	KIT-ENG. O/H ACE (1.6 GASKET COL LINER )	TATA spare parts
885401065710	KIT-ENG OVERHAUL W/CYLD HEAD GSKT 1.3MM	TATA spare parts
885401072525	CYL HEAD O H SEAL KIT	TATA spare parts
885401072534	ENGINE OVERHAUL KIT 4SP TURBO	TATA spare parts
885401072786	EOK KIT ISBE5.9 UMB BS4 (WOB)-STD	TATA spare parts
885401072788	ENG.O/H GASKET SUB-KIT (BS-II) W/- 1.8 T	TATA spare parts
885401072829	ENG. O/H MNR KIT ACE 1.8 GASKET RS1 BRG	TATA spare parts
885401075710	KIT-ENG O/H GASKET KIT - W/CYLD HEAD 1.2	TATA spare parts
885401082516	KIT-ENGINE OVERHAUL 6BT W/- STD BRGS	TATA spare parts
885401082525	KIT -ENG. O/H 697TURBO CMVR	TATA spare parts
885401082786	EOK KIT STD ISBE5.9 BS4 (AJINKYA)	TATA spare parts
885401082788	ENG.O/H GASKET SUB-KIT (BS-II) W/- 1.6 T	TATA spare parts
885401082829	ENG. O/H MNR KIT ACE 1.8 GASKET STD BRG	TATA spare parts
885401085710	KIT-ENG O/H GASKET KIT - W/CYLD HEAD 1.1	TATA spare parts
885401092516	KIT-ENGINE OVERHAUL 6BT W/- RS1 BRGS	TATA spare parts
885401092786	EOK KIT STD ISBE6.7 BS4	TATA spare parts
885401092788	SUB-KIT ENG. O/H GASKET W/- 1.8 T BS2	TATA spare parts
885401092829	SET-VALVE SEAT INLET & EXHAUST BS2/3/4	TATA spare parts
885401095710	EOK ACE 800CC DICOR MEGA/MAGIC BS4	TATA spare parts
885401102525	DECARB. GASKET KIT 697NA CMVR	TATA spare parts
885401102788	EOK ACE WITH GASKET 1.7 MLS	TATA spare parts
885401103702	CYLINDER LINER	TATA spare parts
885401105523	KIT-ENGINE OVERHAUL ACE DICOR BS3	TATA spare parts
885401112525	DECARB. GASKET KIT 697TC CMVR	TATA spare parts
885401112788	EOK ACE WITH GASKET 1.8 MLS	TATA spare parts
885401115523	KIT-ENGINE OVERHAUL ACE DICOR NA	TATA spare parts
885401122525	697TC O/H GASKET KIT W/ IMPORTED CYL HD	TATA spare parts
885401122829	EOK ACE RS2-GASKET 1.8/COL LINER	TATA spare parts

885401142829	EOK ACE_MAGIC 275DI CNG BS4 STD	TATA spare parts
885401162525	DECARBONISING GASKET KIT 697TCIC BS III	TATA spare parts
885401172525	SET OF VALVE SEAT RING BS III STD	TATA spare parts
885401182525	SET INLET & EXHAUST VALVES BS III	TATA spare parts
885401192525	KIT FOR CYLINDER HEAD AND COVER FOR ARMY	TATA spare parts
885401212525	KIT 697 ENG WITH G40 GEARBOX & RADIATOR	TATA spare parts
885401222525	KIT FOR CYLINDER CRANK CASE FOR ARMY	TATA spare parts
885401232525	KIT TIMING GEAR HOUSING FOR ARMY	TATA spare parts
885401242525	KIT FOR OIL SEPARATOR FOR ARMY	TATA spare parts
885401252525	KIT 697 ENG W/ G40 G BOX RAD.& GS LINKS	TATA spare parts
885401262525	KIT 697 ENG W/ G40 G BOX RAD.& GS LINKS	TATA spare parts
885401282525	KIT 697NA ENG W/ G40 G BOX RAD.& GS LINK	TATA spare parts
885401292525	KIT 697NA ENG W/GEAR BOX 330DCL RAD.& G	TATA spare parts
885401302525	KIT ENG. O/H W/OIL RING 4MM THK 697 BS2	TATA spare parts
885401312525	EOK 697 BS-II WITH OIL RING 3MM THK	TATA spare parts
885401322525	KIT-ENGINE OVERHAULING GASKET BS1/2	TATA spare parts
885401332525	KIT FOR 697 NA ENGINE AND GEAR BOX & CTB	TATA spare parts
885403010713	KIT CONNECTING ROD FOR ARMY	TATA spare parts
885403010906	SET-PISTON RINGS	TATA spare parts
885403011510	EOK697BS2 OR 4MM W/O LINER	TATA spare parts
885403011613	SET-PISTON 697 STD BS2/3	TATA spare parts
885403011618	KIT-ENG. O/H 6BT BS3 (NRE) (RS 1 BRGS)	TATA spare parts
885403012516	SET PISTON BARE STD	TATA spare parts
885403012520	M BEARING SET COLLAR TYPE STD	TATA spare parts
885403012523	KIT-SEALING RING C/SFT W/LOC.PIN 92D/4SP	TATA spare parts
885403012525	KIT SEMI OVERHAUL 697	TATA spare parts
885403012527	SET PISTON BARE STD 497D	TATA spare parts
885403012534	RING SET 497SP IKA	TATA spare parts
885403012547	SET CON ROD BRG STD	TATA spare parts
885403012788	LINER PISTON RINGS KIT TATA ACE	TATA spare parts
885403012790	SUPER ACE LPR KIT BS1/2/3	TATA spare parts
885403013118	EOK6B BS3NRE STDW/O LINER	TATA spare parts
885403013516	EOK6B BS2STD BRGSW/O LINER	TATA spare parts
885403014021	SET OF BARE PISTON STD.	TATA spare parts
885403015709	SET PISTON WITH PIN & CIRCLIP (5L-STD)	TATA spare parts
885403016560	PISTON SET OVERSIZE 1	TATA spare parts
885403020713	KIT VIBRATION DAMPER FOR ARMY	TATA spare parts
885403021613	SET-PISTON 697 STD BS3	TATA spare parts
885403021618	EOK 6BT BS III (NRE) (STD Brgs)	TATA spare parts
885403022516	SET PISTON BARE RS1	TATA spare parts
885403022523	PISTON SET W/RINGS 692DI	TATA spare parts
885403022525	SET PISTON RINGS STD 3RV	TATA spare parts
885403022527	BARE PISTON SET W/O RINGS	TATA spare parts
885403022534	BARE PISTON SET W/O RINGS	TATA spare parts
885403022786	PR-KIT 6BT BS3 PISTON AND PISTON RING	TATA spare parts
885403022788	SET PISTON RINGS	TATA spare parts
885403023118	EOK6B BS3NRE RS1W/O LINER	TATA spare parts

885403023516	EOK6B BS2RS1 MBRGSW/O LINER	TATA spare parts
885403024021	SET OF PISTON RINGS STD	TATA spare parts
885403026560	PISTON SET OVERSIZE 2	TATA spare parts
885403030713	KIT FOR CRANK SHAFT FOR ARMY	TATA spare parts
885403031613	SET-PISTON RING (STD) 697 BS2/3	TATA spare parts
885403031618	KIT ENG. O/H (NRE) RS1 MAIN/STD 6BT BS3	TATA spare parts
885403032516	SET PISTON BARE RS2	TATA spare parts
885403032520	M BEARING SET COLLAR TYPE R/S 1	TATA spare parts
885403032523	PISTON RING SET 692DI	TATA spare parts
885403032525	SET OF BARE PISTON STD W/O RINGS 697NA	TATA spare parts
885403032527	SET OF BARE PISTON 497 NA NON SLIPPER	TATA spare parts
885403032534	BARE PISTON SET W/O RINGS	TATA spare parts
885403032788	KIT-ACE LPR WITH COLLARED LINER	TATA spare parts
885403033118	EOK6B BS3NRE RS1MW/O LINER	TATA spare parts
885403033516	EOK6B BS2RS1 BRGSW/O LINER	TATA spare parts
885403036560	RING SET OVERSIZE 1	TATA spare parts
885403040713	KIT FOR CONNECTING ROD BEARING FOR ARMY	TATA spare parts
885403041613	SET-PR RING 697 STD BS3	TATA spare parts
885403041618	EOK 6BT BS3 (NRE) W/LINER W/O BRGS	TATA spare parts
885403042520	M BEARING SET COLLAR TYPE R/S 2	TATA spare parts
885403042525	SET PISTON BARE STD 3RV	TATA spare parts
885403042527	SET BARE PISTON 497 NA SLIPPER	TATA spare parts
885403042534	BARE PISTON SET W/O RINGS	TATA spare parts
885403043118	EOK 6BT BS3 (NRE) W/O LINER BRGS	TATA spare parts
885403046560	RING SET OVERSIZE 2	TATA spare parts
885403050713	KIT FOR MAIN BEARING FOR ARMY	TATA spare parts
885403051613	PISTON SET 697 BS- I STD	TATA spare parts
885403052516	SET PISTON RINGS STD	TATA spare parts
885403052520	M BEARING SET COLLAR TYPE R/S 3	TATA spare parts
885403052525	BARE PISTON SET W/O RINGS	TATA spare parts
885403052527	SET BARE PISTON 497 TC SLIPPER	TATA spare parts
885403052534	BARE PISTON SET W/O RINGS	TATA spare parts
885403060713	KIT FOR CRANK SHAFT AND MAIN BEARING	TATA spare parts
885403061613	P RING SET 697 BS I STD	TATA spare parts
885403062516	SET PISTON RINGS RS1	TATA spare parts
885403062520	M BEARING SET COLLAR TYPE R/S 4	TATA spare parts
885403062523	SET MAIN BRGS W/O THW STD	TATA spare parts
885403062525	SET PISTON BARE STD	TATA spare parts
885403062527	SET PISTON RINGS 4SP NA / 497 NA	TATA spare parts
885403062534	SET OF BARE PISTON 4SP NA PRE 96 NON SL	TATA spare parts
885403070713	KIT FOR CONNECTING ROD AND PISTON	TATA spare parts
885403072516	SET PISTON RINGS RS2	TATA spare parts
885403072525	PISTON RING SET 697ENG	TATA spare parts
885403072534	SET PISTON BARE 4SP NEW	TATA spare parts
885403080713	KIT FOR FLY WHEEL AND FLYWHEEL HOUSING	TATA spare parts
885403082523	SET MAIN BRGS W/O THW RS 1	TATA spare parts
885403082525	KIT-SEALING RING C/SHAFT W/LOC.PINS 97DI	TATA spare parts

885403082527	MAIN BEARING SET W/O TW STD 497	TATA spare parts
885403082534	SET OF CON ROD BUSH - STD 497/4SP NA/TC	TATA spare parts
885403090713	KIT FOR FRONT GEAR COVER	TATA spare parts
885403092516	SET CON ROD BRG STD	TATA spare parts
885403092523	SET MAIN BRGS W/O THW RS 2	TATA spare parts
885403092525	SET OF CON ROD BUSH - STD 697 NA/TC	TATA spare parts
885403100713	KIT FOR VIBRATION DAMPER	TATA spare parts
885403102516	SET CON ROD BRG RS1	TATA spare parts
885403102523	SET MAIN BRGS W/O THW RS 3	TATA spare parts
885403102527	SET MAIN BRGS W/O THW RS 1	TATA spare parts
885403102534	SET BARE PISTON 4SP NA SL-YR 96 TO 99	TATA spare parts
885403112516	SET CON ROD BRG RS2	TATA spare parts
885403112520	M BEARING SET COLLAR TYPE STD	TATA spare parts
885403112523	SET MAIN BRGS W/O THW RS 4	TATA spare parts
885403112525	PISTON SET W/RINGS 697 NA	TATA spare parts
885403112527	SET MAIN BRGS W/O THW RS 2	TATA spare parts
885403122516	SET CON ROD BRG RS3	TATA spare parts
885403122523	SET CON ROD BRGS STD	TATA spare parts
885403122525	PISTON RING SET 697 NA	TATA spare parts
885403122527	SET MAIN BRGS W/O THW RS 3	TATA spare parts
885403122534	SET MAIN BEARING W/O T/WASHER STD 4SP	TATA spare parts
885403132516	SET CON ROD BRG RS4	TATA spare parts
885403132520	M BEARING SET COLLAR TYPE R/S 1	TATA spare parts
885403132527	SET MAIN BRGS W/O THW RS 4	TATA spare parts
885403142520	M BEARING SET COLLAR TYPE R/S 2	TATA spare parts
885403142523	SET CON ROD BRGS RS 1	TATA spare parts
885403142534	SET MAIN BEARING W/O T/WASHER OS 010 4SP	TATA spare parts
885403152520	M BEARING SET COLLAR TYPE R/S 3	TATA spare parts
885403152523	SET CON ROD BRGS RS 2	TATA spare parts
885403152534	SET MAIN BRGS RS2	TATA spare parts
885403162520	M BEARING SET COLLAR TYPE R/S 4	TATA spare parts
885403162523	SET CON ROD BRGS RS 3	TATA spare parts
885403162534	SET MAIN BRGS RS3	TATA spare parts
885403172523	SET CON ROD BRGS RS 4	TATA spare parts
885403172534	SET MAIN BRGS RS4	TATA spare parts
885403182523	SET THRUST WASHER STD	TATA spare parts
885403182534	SET CON ROD BEARING STD 4SP/497	TATA spare parts
885403192523	SET THRUST WASHER RS 1	TATA spare parts
885403202523	SET THRUST WASHER RS 2	TATA spare parts
885403202525	SEMI O.H.KIT 697TC	TATA spare parts
885403202534	SET CON ROD BEARING OS 010 4SP/497	TATA spare parts
885403212523	CON ROD BUSH SET STD	TATA spare parts
885403212534	SET CON ROD BRGS RS 2	TATA spare parts
885403222534	SET CON ROD BRGS RS 3	TATA spare parts
885403232523	M BEARING SET W/O T/W STD	TATA spare parts
885403232534	SET CON ROD BRGS RS 4	TATA spare parts
885403242534	SET T/WASHER STD 4SP/497	TATA spare parts

885403252523	M BEARING SET W/O T/W RS 1	TATA spare parts
885403252534	SET T/WASHER OS 010 4SP NA/TC	TATA spare parts
885403262523	M BEARING SET W/O T/W RS 2	TATA spare parts
885403262534	SET THRUST WASHER RS2	TATA spare parts
885403272523	M BEARING SET W/O T/W RS 3	TATA spare parts
885403272534	MAIN BEARING SET W/O T/W RS 1	TATA spare parts
885403282523	M BEARING SET W/O T/W RS 4	TATA spare parts
885403282525	SET BARE PISTON 697 NA SLIPPER	TATA spare parts
885403282527	MAIN BEARING SET W/O TW STD 497	TATA spare parts
885403292523	CON ROD BEARING SET STD	TATA spare parts
885403292525	SET OF BARE PISTON 697 TC CMVR SLIPPER	TATA spare parts
885403292534	MAIN BEARING SET W/O T/W RS 3	TATA spare parts
885403302527	M BEARING SET W/O T/W RS 1	TATA spare parts
885403302534	MAIN BEARING SET W/O T/W RS 4	TATA spare parts
885403312523	CON ROD BEARING SET RS 1	TATA spare parts
885403312525	M B SET W/O T/W STD	TATA spare parts
885403312534	THRUST WASHER SET RS 2	TATA spare parts
885403322523	CON ROD BEARING SET RS 2	TATA spare parts
885403322527	M BEARING SET W/O T/W RS 3	TATA spare parts
885403322534	CON ROD BUSH SET STD	TATA spare parts
885403332523	CON ROD BEARING SET RS 3	TATA spare parts
885403332525	SET MAIN BEARING W/O T/WASHER OS 010 697	TATA spare parts
885403332527	M BEARING SET W/O T/W RS 4	TATA spare parts
885403342523	CON ROD BEARING SET RS 4	TATA spare parts
885403342525	SET MAIN BRGS RS2	TATA spare parts
885403342527	MAIN BEARING SET W/O TW STD 497	TATA spare parts
885403342534	THRUST WASHER SET RS 2	TATA spare parts
885403352523	THRUST WASHER SET STD	TATA spare parts
885403352525	SET MAIN BRGS RS3	TATA spare parts
885403352534	CON ROD BUSH SET STD	TATA spare parts
885403362523	THRUST WASHER SET RS 1	TATA spare parts
885403362525	SET MAIN BRGS RS4	TATA spare parts
885403362527	M BEARING SET W/O T/W RS 1	TATA spare parts
885403372523	THRUST WASHER SET RS 2	TATA spare parts
885403372525	SET CON ROD BEARING STD 697NA/TC	TATA spare parts
885403372527	M BEARING SET W/O T/W RS 2	TATA spare parts
885403372534	SET-MAIN BEARING W/O T/W STD BS1/2/3/4	TATA spare parts
885403382523	CAMSHAFT BUSH SET STD	TATA spare parts
885403382527	M BEARING SET W/O T/W RS 3	TATA spare parts
885403392525	SET CON ROD BEARING OS 010 697NA/TC	TATA spare parts
885403392527	M BEARING SET W/O T/W RS 4	TATA spare parts
885403392534	MAIN BEARING SET W/O T/W RS 1	TATA spare parts
885403402525	SET CON ROD BRGS RS 2	TATA spare parts
885403402527	SET-MAIN BEARING W/O TW STD 497 BS2/3/4	TATA spare parts
885403402534	MAIN BEARING SET W/O T/W RS 2	TATA spare parts
885403412525	SET CON ROD BRGS RS 3	TATA spare parts
885403412534	MAIN BEARING SET W/O T/W RS 3	TATA spare parts

885403422525	SET CON ROD BRGS RS 4	TATA spare parts
885403422527	M BEARING SET W/O T/W RS 1	TATA spare parts
885403422534	MAIN BEARING SET W/O T/W RS 4	TATA spare parts
885403432525	SET T/WASHER STD 697NA/TC	TATA spare parts
885403432527	M BEARING SET W/O T/W RS 2	TATA spare parts
885403432534	SET-CON. ROD BEARING - STD BS2/3/4	TATA spare parts
885403442525	SET T/WASHER OS 010 697 NA/TC	TATA spare parts
885403442527	M BEARING SET W/O T/W RS 3	TATA spare parts
885403452525	SET THRUST WASHER RS 2	TATA spare parts
885403452527	M BEARING SET W/O T/W RS 4	TATA spare parts
885403452534	CON ROD BEARING SET RS 1	TATA spare parts
885403462523	THRUST WASHER SET RS 2	TATA spare parts
885403462525	M BEARING SET COLLAR TYPE STD	TATA spare parts
885403462527	SET OF BARE PISTON 497 NA NON SLIPPER	TATA spare parts
885403462534	CON ROD BEARING SET RS 2	TATA spare parts
885403472527	SET OF BARE PISTON 497 NA SLIPPER	TATA spare parts
885403472534	CON ROD BEARING SET RS 3	TATA spare parts
885403482525	M BEARING SET COLLAR TYPE R/S-I	TATA spare parts
885403482527	SET OF BARE PISTON 497 NA SLIPPER	TATA spare parts
885403482534	CON ROD BEARING SET RS 4	TATA spare parts
885403492525	M BEARING SET COLLAR TYPE R/S-II	TATA spare parts
885403492527	SET OF BARE PISTON 497 NA SLIPPER	TATA spare parts
885403492534	THRUST WASHER SET STD	TATA spare parts
885403502525	M BEARING SET COLLAR TYPE R/S-III	TATA spare parts
885403502527	SET-BARE PISTON 497 TC CMVR EURO1 BS2/3	TATA spare parts
885403502534	THRUST WASHER SET RS 1	TATA spare parts
885403512525	M BEARING SET COLLAR TYPE R/S-IV	TATA spare parts
885403512527	SET OF BARE PISTON 497 TC CMVR EURO 2 N	TATA spare parts
885403512534	THRUST WASHER SET RS 2	TATA spare parts
885403522525	CON ROD BUSH SET STD	TATA spare parts
885403522527	SET OF BARE PISTON 497 TC CMVR SLIPPER	TATA spare parts
885403522534	CON ROD BUSH SET STD	TATA spare parts
885403532527	SET OF BARE PISTON 497 TC CMVR SLIPPER	TATA spare parts
885403542525	CON ROD BUSH SET STD	TATA spare parts
885403542527	SET BARE PISTON 497TC CMVR SL EUROII	TATA spare parts
885403542534	SET OF BARE PISTON 4SP NA PRE 96 NON SL	TATA spare parts
885403552527	SET OF BARE PISTON 497 TC CMVR SLIPPER	TATA spare parts
885403552534	SET OF BARE PISTON 4SP NA PRE 96 SLIPPE	TATA spare parts
885403562525	M BEARING SET COLLAR TYPE STD	TATA spare parts
885403562527	SET OF BARE PISTON 497 TC CMVR SLIPPER	TATA spare parts
885403562534	SET OF BARE PISTON 4SP NA PRE 96 SLIPPE	TATA spare parts
885403572527	SET-PISTON 497CRDI BS2/3	TATA spare parts
885403572534	SET OF BARE PISTON 4SP NA PRE 96 SLIPPE	TATA spare parts
885403582525	M BEARING SET COLLAR TYPE R/S-I	TATA spare parts
885403582527	SET-PISTON (STD) 497 BS3	TATA spare parts
885403582534	SET OF BARE PISTON 4SP NA PRE 96 SLIPPE	TATA spare parts
885403592525	M BEARING SET COLLAR TYPE R/S-II	TATA spare parts

885403592527	SET-PISTON RING (STD) 497 BS2/3	TATA spare parts
885403592534	SET OF BARE PISTON 4SP NA 96.99 NON SLI	TATA spare parts
885403602525	M BEARING SET COLLAR TYPE R/S-III	TATA spare parts
885403602527	SET-PISTON RING (STD) 497 BS3	TATA spare parts
885403602534	SET BARE PISTON 4SP NA SL-YR 96 TO 99	TATA spare parts
885403612525	M BEARING SET COLLAR TYPE R/S-IV	TATA spare parts
885403612527	PISTON SET 497 BS- I STD	TATA spare parts
885403612534	SET BARE PISTON 4SP NA SL-YR 96 TO 99	TATA spare parts
885403622523	SET OF PISTON RINGS 692 3RV STD	TATA spare parts
885403622525	SET-BEARING CON. ROD (STD) BS1/2/3/4	TATA spare parts
885403622527	P RING SET 497 BS I STD	TATA spare parts
885403622534	SET BARE PISTON 4SP NA SL-YR 96 TO 99	TATA spare parts
885403632523	SET OF PISTON RINGS 692 3RV RS1	TATA spare parts
885403632534	SET OF BARE PISTON 4SP NA 99.00 NON SLI	TATA spare parts
885403642523	SET OF PISTON RINGS 692 3RV RS2	TATA spare parts
885403642525	CON ROD BEARING SET RS 1	TATA spare parts
885403642534	SET OF BARE PISTON 4SP NA 99.00 SLIPPER	TATA spare parts
885403652523	SET OF PISTON RINGS 692 3RV RS3	TATA spare parts
885403652525	CON ROD BEARING SET RS 2	TATA spare parts
885403652534	SET OF BARE PISTON 4SP NA 99.00 SLIPPER	TATA spare parts
885403662523	THRUST WASHER SET STD	TATA spare parts
885403662525	CON ROD BEARING SET RS 3	TATA spare parts
885403662534	SET OF BARE PISTON 4SP NA 99.00 SLIPPER	TATA spare parts
885403672523	THRUST WASHER SET RS 1	TATA spare parts
885403672525	CON ROD BEARING SET RS 4	TATA spare parts
885403672534	SET OF BARE PISTON 4SP NA 99.00 SLIPPER	TATA spare parts
885403682523	CRANKSHAFT N1 692	TATA spare parts
885403682525	CON ROD BUSH SET STD	TATA spare parts
885403682534	SET-BARE PISTON 4SPTC CMVR EURO1/2 BS2/3	TATA spare parts
885403692534	SET OF BARE PISTON 4SP TC CMVR EURO 2 N	TATA spare parts
885403702525	SET-MAIN BEARING W/O T/W (STD) BS2	TATA spare parts
885403702534	SET OF BARE PISTON 4SP TC CMVR EURO 1 S	TATA spare parts
885403712534	SET OF BARE PISTON 4SP TC CMVR EURO 1 S	TATA spare parts
885403722525	SET-MAIN BEARING W/O T/W RS-I BS1/2/3/4	TATA spare parts
885403722534	SET OF BARE PISTON 4SP TC CMVR EURO 2 S	TATA spare parts
885403732525	M B SET W/O T/W R/S II	TATA spare parts
885403732534	SET OF BARE PISTON 4SP TC CMVR EURO 2 S	TATA spare parts
885403742525	M B SET W/O T/W R/S III	TATA spare parts
885403742534	SET-PISTON RING (STD) 497 E1/2/3 BS1/2/3	TATA spare parts
885403752525	M B SET W/O T/W R/S IV	TATA spare parts
885403752534	ENGINE BEARING KIT FOR 4SP	TATA spare parts
885403762525	THRUST WASHER SET STD	TATA spare parts
885403762534	XENON 4SPTC LPR KIT BS1/2/3	TATA spare parts
885403772525	THRUST WASHER SET RS 1	TATA spare parts
885403782525	THRUST WASHER SET RS 2	TATA spare parts
885403792525	SET OF BARE PISTON 697 NA NON SLIPPER	TATA spare parts
885403802525	SET OF BARE PISTON PISTON 697 NA SLIPPE	TATA spare parts

885403812525	SET BARE PISTON 697 NA SL	TATA spare parts
885403822525	SET OF BARE PISTON PISTON 697 NA SLIPPE	TATA spare parts
885403832525	SET OF BARE PISTON 697 TC OLD N-SLIPPER	TATA spare parts
885403842525	SET OF BARE PISTON 697 TC OLD SLIPPER	TATA spare parts
885403852525	SET OF BARE PISTON 697 TC OLD SLIPPER	TATA spare parts
885403862525	SET OF BARE PISTON 697 TC OLD SLIPPER	TATA spare parts
885403872525	SET OF BARE PISTON 697 TC OLD SLIPPER	TATA spare parts
885403882525	SET-BARE PISTON 697TC N-SLIPPE BS1/2/3	TATA spare parts
885403892525	SET OF BARE PISTON 697 TC CMVR SLIPPER	TATA spare parts
885403902525	SET OF BARE PISTON 697 TC CMVR SLIPPER	TATA spare parts
885403912525	SET-PISTON RINGS 697	TATA spare parts
885403922525	SET-PISTON RINGS 697 CMVR BS1/2/3	TATA spare parts
885403932525	THRUST WASHER SET STD	TATA spare parts
885403942525	THRUST WASHER SET RS 1	TATA spare parts
885403952525	THRUST WASHER SET RS 2	TATA spare parts
885403962525	ENGINE BEARING KIT FOR 697	TATA spare parts
885403972525	SET-VALVE SEAT RING BS2/3/4	TATA spare parts
885403982525	SET INLET AND EXHAUST VALVE BS2/3/4	TATA spare parts
885403991613	KIT-ENGINE NRE 130 HP	TATA spare parts
885404012525	BARE PISTON SET STD 697 BSII	TATA spare parts
885404022525	BARE PISTON SET BSIII STD	TATA spare parts
885405010713	KIT FOR CAMSHAFT AND TAPPETS	TATA spare parts
885405011613	VALVE KIT BSII 6BT OS1 (3 THOU)	TATA spare parts
885405012547	SET FINISHED VALVE GUIDE 483DL TCIC & NA	TATA spare parts
885405012789	VALVE KIT	TATA spare parts
885405012829	SET-VALVE GUIDE INLET & EXHAUST FINISHED	TATA spare parts
885405015710	KIT FOR TIMING SYSTEM ACE MEGA	TATA spare parts
885405015724	TIMING SYSTEM KIT-V30/V50 BS6	TATA spare parts
885405020713	KIT FOR ROCKER LEVER/ VALVE COVER	TATA spare parts
885405021613	VALVE KIT BSII 6BT OS2 (5 THOU)	TATA spare parts
885405022525	TIMER KIT 697NA/TC 692DI BS1/2/3	TATA spare parts
885405022534	SET CAMSHAFT BEARING STD 4SP/497	TATA spare parts
885405022789	TIMING BELT KIT XENON 2.2 EURO2	TATA spare parts
885405022829	KIT-TIMING SYSTEM ACE	TATA spare parts
885405025710	KIT FOR TIMING SYSTEM AND WATER PUMP ACE	TATA spare parts
885405031613	VALVE KIT BSIII OS1 (3 THOU)	TATA spare parts
885405032525	SET CAMSHAFT BUSH STD 697NA/TC	TATA spare parts
885405032527	KIT-TIMER 497X128	TATA spare parts
885405032534	CAMSHAFT BUSH SET STD	TATA spare parts
885405041613	VALVE KIT BSIII OS2 (5 THOU)	TATA spare parts
885405042525	CAMSHAFT BUSH SET STD	TATA spare parts
885405042534	CAMSHAFT BUSH SET STD	TATA spare parts
885405052525	CAMSHAFT BUSH SET STD	TATA spare parts
885405052534	SET VALVE GUIDES 4 SP / 497 NA-TC	TATA spare parts
885405062525	SET VALVE GUIDES 697 NA-TC	TATA spare parts
885405062534	VALVE SET TUFFTRIDED 4SP NA/TC	TATA spare parts
885405072525	VALVE SET TUFFTRIDED 697 NA/TC	TATA spare parts



885405082525	KIT FOR ENGINE TIMING FOR ARMY	TATA spare parts
885407012516	KIT CONVERSION ROT-INLINE	TATA spare parts
885407012829	KIT- Injector Overflow Tube(Rubber) ACE	TATA spare parts
885407020713	KIT FOR PUMP LIFT	TATA spare parts
885407022516	KIT CONVE FIXED FAN DRIVE	TATA spare parts
885407030713	KIT FOR LOCATION FUEL DRAIN	TATA spare parts
885407032516	KIT CONVER MANUAL SHUTOFF	TATA spare parts
885407040713	KIT FOR LEVER FUEL SHUT OFF	TATA spare parts
885407042516	CONVERSION KIT F/PUMP	TATA spare parts
885407052516	MOD.CON.KIT FEED PUMP	TATA spare parts
885407052525	KIT FOR FUEL PRESSURE AND LEAKAGE LINE F	TATA spare parts
885407062525	KIT FOR NOZZLE HOLDER FOR ARMY	TATA spare parts
885407072525	KIT FOR GOVERNOR (R.Q.V) FOR ARMY	TATA spare parts
885407082516	FUEL FILTER ELEMENT PRIMARY	TATA spare parts
885407082525	KIT FOR INJECTION PUMP (R Q V) FOR ARMY	TATA spare parts
885407092516	FUEL FILTER ELEMENT SECONDARY	TATA spare parts
885407092525	KIT FOR FUEL FEED PUMP FOR ARMY	TATA spare parts
885407102525	KIT FOR FUEL MULTISTAGE FILTER (MICO) FO	TATA spare parts
885409010407	KIT -AIR FILTER 407	TATA spare parts
885409010410	SET OF 2 AIR FILTER FOR 4SP TCIC	TATA spare parts
885409010713	KIT FOR FUEL FILTER	TATA spare parts
885409011210	SINGLE LIFE FILTER - KIT 1210	TATA spare parts
885409012525	DOUBLE LIFE FILTER KIT-1612	TATA spare parts
885409012534	407 FILTER KIT	TATA spare parts
885409012789	FILTER KIT 2.2L/ 3.0L DICOR XENON	TATA spare parts
885409012818	FILTER KIT BSIV- ZIP	TATA spare parts
885409015517	KIT-OIL AND FUEL FILTER ZIP	TATA spare parts
885409020712	SET OF 2 AIR FILTER FOR 497	TATA spare parts
885409021210	SINGLE LIFE FILTER KIT 1210 WITH STAR	TATA spare parts
885409022525	TURBO FILTER KIT-1612	TATA spare parts
885409022534	407 FILTER KIT-TURBO	TATA spare parts
885409022818	KIT- FILTER - MEGA BS4	TATA spare parts
885409032818	FILTER KIT BSIV- SUPER ACE MINT	TATA spare parts
885409041613	SET AIR FILTER CARTRIDGES 1613	TATA spare parts
885409051613	SET OF 2 AIR FILTER 697 TCIC BS2/BS3	TATA spare parts
885409052516	SET OF 2516 AIR FILTER ELEMENT	TATA spare parts
885410005001	PISTON W/O RING STD 94D	TATA spare parts
885410005006	SET PISTON RINGS STD	TATA spare parts
885410005007	SET PISTON RINGS RS1	TATA spare parts
885410005017	CL PR PLATE 310 DIA DIAPH	TATA spare parts
885410005018	CL PR PLATE 310 DIA	TATA spare parts
885410005019	REP KIT MAJ 310D DIAPH CL	TATA spare parts
885410005020	DRIVEN PLATE ASSY.310 DIA. PH-III	TATA spare parts
885410005021	REP KIT DIPH CL MNR 310 D	TATA spare parts
885410005023	SET CON ROD BRG STD	TATA spare parts
885410005025	CON ROD BRG SET R/S I	TATA spare parts
885410005026	CON ROD BRG SET R/S II	TATA spare parts

885410005027	CON ROD BRG SET RS III	TATA spare parts
885410005028	CON ROD BRG SET R/S IV	TATA spare parts
885410005030	SET CON ROD BEARING REP-I	TATA spare parts
885410005031	SET CON ROD BEARING REP-II	TATA spare parts
885410005035	M B SET UPPER/LOWER R/S I	TATA spare parts
885410005038	M B SET UPPE./LOWE.R/S IV	TATA spare parts
885410005044	THRUST WASHER SET STD	TATA spare parts
885410005050	BUSH	TATA spare parts
885410005053	BUSH KING PIN	TATA spare parts
885410005058	REP KIT REL LEVER&PR SPG	TATA spare parts
885410005073	KING PIN STD1	TATA spare parts
885410005074	330 DIA.ASSY. CLUTCH DISC CERAMIC LP1511	TATA spare parts
885410005078	PISTON SET W/ RINGS 697 NA	TATA spare parts
885410005079	THRUST WASHER UPPER STD	TATA spare parts
885410005080	THRUST WASHER LOWER STD	TATA spare parts
885410005081	KING PIN STD	TATA spare parts
885410005082	TH WASHER UPPER STD	TATA spare parts
885410005083	THRUST WASHER LOWER NORMAL	TATA spare parts
885410005084	THRUST WASHER BRASS	TATA spare parts
885410005085	TH WASHER UPPER STD1	TATA spare parts
885410005086	KING PIN STD	TATA spare parts
885410005087	KING PIN NORMAL I	TATA spare parts
885410005088	KING PIN RS1	TATA spare parts
885410005089	K.PIN MINOR KIT 1612	TATA spare parts
885410005090	A/FILTER ELEMENT PRIMARY	TATA spare parts
885410005091	A/FILTER ELEMENT SAFETY	TATA spare parts
885410005092	PISTON RING SET 697ENG	TATA spare parts
885410005093	CLUTCH COVER ASSY.310 DIA.-(PH-III)	TATA spare parts
885410210003	BRG TAPER ROLLER	TATA spare parts
885410210004	BRG TAPER ROLLER	TATA spare parts
885410210015	SET PISTON BARE STD	TATA spare parts
885410210017	ASSY TIE ROD	TATA spare parts
885410210018	REP KIT TIE ROD	TATA spare parts
885410210042	SET PISTON BARE RS1	TATA spare parts
885410210044	SET PISTON BARE RS2	TATA spare parts
885410210047	ASSY RAD WITH CAP & COCK	TATA spare parts
885410210048	CL PR PLATE 310 DIA COIL	TATA spare parts
885410210050	REP KIT REL LEVER&PR SPG	TATA spare parts
885410210051	CLUTCH COVER ASSY.310 DIA.- PH-III	TATA spare parts
885410210064	CL REL BRG W/SLEEVE	TATA spare parts
885410210067	REP KIT KING PIN STD 1613/1512	TATA spare parts
885410210072	THRUST WASHER UPPER STD	TATA spare parts
885410210073	THRUST WASHER LOWER STD	TATA spare parts
885410210074	LUBE FILTER	TATA spare parts
885410210075	A/FILTER ELEMENT PRIMARY	TATA spare parts
885410210076	A/FILTER ELEMENT SAFETY	TATA spare parts
885410210077	VALVE DRAIN FUEL WATER	TATA spare parts

885410210078	STRG GEAR BOX POWER RHD	TATA spare parts
885410210079	TANK FILTER ASSY SHORTER	TATA spare parts
885410210080	POWER STRG PUMP	TATA spare parts
885410210081	STEERING PUMP LPT 2516TC	TATA spare parts
885410210082	ASSEMBLY CARTRIDGE	TATA spare parts
885410210083	HYDRAULIC OIL TANK	TATA spare parts
885410210084	SHAFT SUB ASSY	TATA spare parts
885410210085	UNIVERSAL JOINT STRG	TATA spare parts
885410210086	SET OF BARE PISTON STD-EURO I & II	TATA spare parts
885410210087	SET PISTON RINGS STD	TATA spare parts
885410210088	ASSY.SLAVE CYLINDER 38.1 DIA	TATA spare parts
885410210089	CL.DISC 310 DIA GB40	TATA spare parts
885410210090	CLUTCH DISC 330 DIA CERAMIC TYPE	TATA spare parts
885410210091	ASSY RAD.LP1512 FR.MOUNTED	TATA spare parts
885410210092	CYL ROLLER 4 X 8	TATA spare parts
885410210093	BEARING TAPER ROLLER	TATA spare parts
885410210094	BEARING TAPER ROLLER	TATA spare parts
885410210095	BEARING TAPER ROLLER	TATA spare parts
885410210096	S R D G BALL BRG	TATA spare parts
885410210097	KING PIN THRUST BRG STD	TATA spare parts
885410210098	BEARING TAPER ROLLER	TATA spare parts
885410210099	KIT SEAL P/STRG G/BOX	TATA spare parts
885410210100	HOUSING FLYWHEEL(C.I)125HP	TATA spare parts
885410210101	BLOCK CYLINDER	TATA spare parts
885410210102	GEAR FLYWHEEL RING	TATA spare parts
885410210103	FLYWHEEL	TATA spare parts
885410210104	OIL PUMP	TATA spare parts
885410210105	TENSIONER BELT	TATA spare parts
885410210106	VISCOUS FAN 20 INCH	TATA spare parts
885410210107	FAN DRIVE VISCOUS	TATA spare parts
885411320001	KING PIN STD 1210	TATA spare parts
885411320002	KING PIN STD-I 1210	TATA spare parts
885411320003	KING PIN RS-I 1210	TATA spare parts
885411320004	KING PIN RS-II 1210	TATA spare parts
885411320005	BUSH-KING PIN	TATA spare parts
885411320006	KING PIN 35.10 MM DIA	TATA spare parts
885411320007	KING PIN 35.20 MM DIA	TATA spare parts
885411320009	TH WASHER UPPER STD1	TATA spare parts
885411320010	TH WASHER UPPER STD	TATA spare parts
885411320011	TH WASHER LOWER STD	TATA spare parts
885411320031	SET PISTON BARE STD	TATA spare parts
885411320032	SET PISTON BARE RS1	TATA spare parts
885411320033	SET PISTON BARE RS2	TATA spare parts
885411320034	SET PISTON RINGS STD	TATA spare parts
885411320035	SET PISTON RINGS RS1	TATA spare parts
885411320036	SET PISTON RINGS RS2	TATA spare parts
885411320037	HALOGEN BULB 24V P 43 75/70W	TATA spare parts

885411320038	REP KIT TIE ROD	TATA spare parts
885411320039	CEN BRG ASSY W/DUST SEAL	TATA spare parts
885411320040	BEARING D/ROW NEEDLE CAGE	TATA spare parts
885411320041	BEARING D/ROW NEEDLE CAGE	TATA spare parts
885411320044	SET CAMSHAFT BEARING	TATA spare parts
885411320045	M B SET UPPER/LOWER R/S I	TATA spare parts
885411320046	M B SET UPPER/LOW. R/S II	TATA spare parts
885411320047	M B SET UPPE/LOWE.R/S III	TATA spare parts
885411320048	SET CON ROD BRG STD	TATA spare parts
885411320049	CON ROD BRG SET R/S I	TATA spare parts
885411320050	CON ROD BRG SET R/S II	TATA spare parts
885411320051	CON ROD BRG SET RS III	TATA spare parts
885411320052	CON ROD BRG SET R/S IV	TATA spare parts
885411320053	CON ROD BUSH	TATA spare parts
885411320054	SET THRUST WASHER STD	TATA spare parts
885411320055	THRUST WASHER SET RS 1	TATA spare parts
885411320056	SEAL CAM SHAFT	TATA spare parts
885411320057	OIL SEAL-FRONT COVER	TATA spare parts
885411320058	CL PR PLATE 310 DIA	TATA spare parts
885411320059	PISTON SET W/ RINGS 697 NA	TATA spare parts
885411320060	BRAKE DRUM FRONT	TATA spare parts
885411320061	RUBBER CEN BRG HONEY COMB	TATA spare parts
885411320062	KING PIN STD 1612_38.25MM	TATA spare parts
885411320063	REP KIT KING PIN STD 35.00 mm 1210	TATA spare parts
885411320064	BUSH KING PIN	TATA spare parts
885412100002	CL.DISC 310 DIA GB40	TATA spare parts
885412100003	A/FILTER ELEMENT SAFETY	TATA spare parts
885412100004	V BELT COGGED 980MM	TATA spare parts
885412100005	ASSY. CLUTCH DISC-(7SPRING) 330 DIA	TATA spare parts
885412100006	HALOGEN BULB 24V P 45 75/70W	TATA spare parts
885412100007	HALOGEN BULB 24V P 43 75/70W	TATA spare parts
885413010713	KIT FOR AIR COMPRESSOR	TATA spare parts
885413012516	REP KIT MINOR A/COMP	TATA spare parts
885413012534	SET A/C BRG STD 70 DIA 4SP/497	TATA spare parts
885413021109	AIR COMPRESSOR CYL HEAD GAS/KIT	TATA spare parts
885413022516	REP KIT MAJOR A/COMP	TATA spare parts
885413022534	SET A/C CON ROD SMALL END BUSH 70 DIA 4S	TATA spare parts
885413032516	PISTON ASSY AIR COMP	TATA spare parts
885413042516	PISTON RING R/KIT - A/COM	TATA spare parts
885413042534	SET CON ROD BRG R/S1	TATA spare parts
885413052516	PISTON RING R/KIT STD.	TATA spare parts
885413052534	SET CON ROD BRG R/S2	TATA spare parts
885413062516	PISTON RINTG R/KIT O/S	TATA spare parts
885413062534	A/C BEARING SET STD	TATA spare parts
885413082534	A/C BEARING SET RS 1	TATA spare parts
885413092534	A/C BEARING SET RS 2	TATA spare parts
885413102525	PISTON W/O RING STD 94D	TATA spare parts

885413102534	A/C CON ROD BUSH SET STD	TATA spare parts
885413112525	ASSY PISTON W/O RING STDI	TATA spare parts
885413132525	94D A/C P/RING SET STD	TATA spare parts
885413152525	SET A/C BRG STD 94 DIA 697NA/TC	TATA spare parts
885413162525	SET A/C CON ROD SMALL END BUSH 94 DIA 69	TATA spare parts
885413182525	SET CON ROD BRG R/S1 94D	TATA spare parts
885413192525	SET CON ROD BRG R/S2 94D	TATA spare parts
885413202525	A/C CON ROD BUSH SET STD	TATA spare parts
885413212525	A/C CON ROD BUSH SET STD	TATA spare parts
885413222525	SET A/C BRG STD 94 DIA 697NA/TC	TATA spare parts
885413242525	A/C BEARING SET RS 1	TATA spare parts
885413252525	A/C BEARING SET RS 2	TATA spare parts
885413262525	A/C CON ROD BUSH SET STD	TATA spare parts
885413272525	AC PISTON 94 DIA W/O RING	TATA spare parts
885413282525	KIT FOR AIR COMPRESSOR FOR ARMY	TATA spare parts
885414011623	WHEEL SHAFT	TATA spare parts
885414012525	KIT FOR EXHAUST MANIFOLD FOR ARMY	TATA spare parts
885414012789	INTERCOOLER HOSE KIT	TATA spare parts
885414015710	KIT-TURBO HOSES AND CLAMPS-INTRA V10 BS6	TATA spare parts
885414020713	KIT FOR EXHAUST MANIFOLD	TATA spare parts
885414022525	KIT FOR ENGINE EXHAUST BRAKE FOR ARMY	TATA spare parts
885415011109	ALTERNATOR CLAMP ROD KIT ILCV	TATA spare parts
885415011613	ALTERNATOR CLAMP ROD KIT MCV	TATA spare parts
885415012516	RETROFIT KIT FOR STARTER 12 VOLTS	TATA spare parts
885415022516	RETROFIT KIT FOR STARTER & RING GEAR 12	TATA spare parts
885415032516	DC-DC CONVERTOR KIT FOR 1510 CGS	TATA spare parts
885415051512	RETROFIT KIT FOR STARTER 12 VOLTS	TATA spare parts
885415052525	KIT FOR STARTER 12 VOLT_ARMY	TATA spare parts
885415061512	RETROFIT KIT FOR STARTER & RING GEAR 12/	TATA spare parts
885415062525	KIT FOR STARTER 2SM127-12V_ARMY	TATA spare parts
885415072525	KIT FOR ALTERNATOR 12V 53/65AMPS_ARMY	TATA spare parts
885415082525	KIT FOR ALTERNATOR (12V 65 AMPS)_ARMY	TATA spare parts
885415500001	SET PISTON RING CNG ENG.SET	TATA spare parts
885415500002	KIT PISTON ENGINE(CNG) ENG SET	TATA spare parts
885415500003	CYL HEAD ASSY W/ VALVES 1510CNG	TATA spare parts
885415500004	CONVERTOR CATALYTIC	TATA spare parts
885416522001	KING PIN STD	TATA spare parts
885416522002	KING PIN STD1	TATA spare parts
885416522003	KING PIN RS1	TATA spare parts
885416522004	KING PIN RS2	TATA spare parts
885416522005	KING PIN STD	TATA spare parts
885416522006	BUSH-KING PIN	TATA spare parts
885416522007	THRUST WASHER UPPER STD	TATA spare parts
885416522022	SRDG BALL BEARING	TATA spare parts
885416522024	LUBE FILTER	TATA spare parts
885416522025	FUEL WATER SEPARATOR	TATA spare parts
885416522026	FUEL FILTER	TATA spare parts

885416522027	A/FILTER ELEMENT PRIMARY	TATA spare parts
885416522028	A/FILTER ELEMENT SAFETY	TATA spare parts
885416522029	CL.DISC 310 DIA GB40	TATA spare parts
885416522030	REP KIT MAJ 310D DIAPH CL	TATA spare parts
885416522031	REP KIT REL LEVER COIL	TATA spare parts
885416522032	DRIVEN PLATE ASSY.310 DIA. PH-III	TATA spare parts
885416522035	ASSY HOUSING BLOCK 1512/3015	TATA spare parts
885416522041	GEAR SHIFT LEVER	TATA spare parts
885416522047	SELECT & SHIFT FORK W/GSL	TATA spare parts
885416522050	SELECTOR & SHIFTER SHAFT	TATA spare parts
885416522051	SHIFTER FORK 2/3 SPEED	TATA spare parts
885416522052	SELECTOR FORK 4TH & 5TH GEAR GBS40	TATA spare parts
885416522053	SELECTOR.SHAFT 2/3	TATA spare parts
885416522054	SELECTOR.SHAFT 4/5	TATA spare parts
885416522058	TWIN GEAR - 17/23 T COUNTERSHAFT GBS40	TATA spare parts
885416522062	SYNCHRO CONE	TATA spare parts
885416522072	SYNCHRO SLEEVE 4/5 TH	TATA spare parts
885416522074	CYL ROLLER 4 X 8	TATA spare parts
885416522078	CWP SET 41/7 OERL	TATA spare parts
885416522079	BEVEL GEAR NEW	TATA spare parts
885416522084	GEAR REAR AXLE SHAFT	TATA spare parts
885416522085	GEAR REAR AXLE SHAFT	TATA spare parts
885416522088	SYNCHRO SLEEVE 4/5TH SPEED	TATA spare parts
885416522089	CWP SET 37/7 OERL LP/LPO 1512TC	TATA spare parts
885416522090	DIFFL BEVEL PINION	TATA spare parts
885416522092	KING PIN THRUST BRG STD	TATA spare parts
885416522094	KING PIN THRUST BRG STD1	TATA spare parts
885416522096	BEARING DRIVE END	TATA spare parts
885416522099	FLY WHEEL BEARING GB-60	TATA spare parts
885416522100	CL PR PLATE 310 DIA	TATA spare parts
885416522103	CLUTCH COVER ASSY.310 DIA.- PH-III	TATA spare parts
885416522106	KIT - STRAP & RIVETS 8+4+4	TATA spare parts
885416522107	PRESSURE PLATE 330 DIA COIL TYPE	TATA spare parts
885416522108	SET OF BARE PISTON STD-EURO I & II	TATA spare parts
885416522109	SET OF BARE PISTON R/S I-EURO I & II	TATA spare parts
885416522110	SET PISTON RINGS STD	TATA spare parts
885416522111	SET PISTON RINGS RS1	TATA spare parts
885416522113	PISTON SET W/RINGS 697 NA	TATA spare parts
885416522114	POWER STRG PUMP	TATA spare parts
885416522116	M B SET UPPER/LOW. R/S II	TATA spare parts
885416522117	CON ROD BRG SET R/S II	TATA spare parts
885416522118	V BELT COGGED 1280MM	TATA spare parts
885416522119	V BELT COGGED 980MM	TATA spare parts
885416522120	ELEMENT WATER SEPERATOR	TATA spare parts
885416522121	SET OF BARE PISTON R/S II-EURO I & II	TATA spare parts
885416522122	SET PISTON RINGS RS2	TATA spare parts
885416522123	KING PIN 1210 35.1 MM	TATA spare parts

885416522124	KING PIN 1210 35.2 MM	TATA spare parts
885416522125	KING PIN 1210 35.4 MM	TATA spare parts
885416522126	KING PIN 1210 35.5 MM	TATA spare parts
885416522127	REP KIT KING PIN STD	TATA spare parts
885416522128	THRUST WASHER LOWER NORMAL	TATA spare parts
885416522129	TH WASHER BRASS	TATA spare parts
885416522130	THRUST WASHER UPPER NORMAL I	TATA spare parts
885416522131	THRUST WASHER UPPER STD	TATA spare parts
885416522132	THRUST WASHER LOWER STD	TATA spare parts
885416522133	THRUST WASHER LOWER STD1	TATA spare parts
885416522134	KIT FACING 330 DIA CLUTCH DISC	TATA spare parts
885416522135	KIT FOR DISC	TATA spare parts
885416522136	CLUTCH DISC 330 DIA CERAMIC TYPE	TATA spare parts
885416522137	M B SET UPPER/LOWER R/S I	TATA spare parts
885416522138	M B SET UPPE/LOWE.R/S III	TATA spare parts
885416522139	CON ROD BEARING SET STD	TATA spare parts
885416522140	CON ROD BRG SET R/S I	TATA spare parts
885416522141	CON ROD BRG SET R/S IV	TATA spare parts
885416522142	STEERING PUMP LPT 2516TC	TATA spare parts
885416522143	ASSY BALL JOINT	TATA spare parts
885416522144	SUB ASSY BALL & SOCKET JT SMALL	TATA spare parts
885416522145	SET FUEL PR LINES	TATA spare parts
885416522146	CYLINDER HEAD GASKET FOR 697TURBO ENGINE	TATA spare parts
885416522147	GASKET CYL HEAD COVER	TATA spare parts
885416522148	CLUTCH HSG.310D	TATA spare parts
885416522149	ASSY BALL JOINT RH THREADS	TATA spare parts
885416522150	LEADER PART NO ASSY BALL JT.	TATA spare parts
885416522151	AIR PRESSURE REGULATOR	TATA spare parts
885416522152	REP KIT DRAG LINK	TATA spare parts
885416522153	RADIATOR CAP	TATA spare parts
885416522154	ASSY.STRAP FUEL TANK 430DIA.	TATA spare parts
885416522155	FUEL CAP ASSY	TATA spare parts
885416522156	DRAG LINK ASSY	TATA spare parts
885416522157	LP FACE LH W/FRAME	TATA spare parts
885416522158	LP FACE RH W/FRAME	TATA spare parts
885416522159	PITMAN ARM	TATA spare parts
885416522160	ASSY CLUTCH MASTER CYL	TATA spare parts
885416522161	ASSY BRACKET	TATA spare parts
885416522162	ASSY. TUBE 6 O.D. X 2060 LG.	TATA spare parts
885416522163	ASSY. TUBE-6 O.D. X 1630 LG.	TATA spare parts
885416522164	ASSY PIPE 15 DIA X 1665LG	TATA spare parts
885416522165	HOSE ASSY	TATA spare parts
885416522166	PIPE 10D X 1800	TATA spare parts
885416522167	ASSY.TUBE WITH CRIMPED R/HOSE COMPLT.	TATA spare parts
885416522168	ASSY.TUBE WITH CRIMPED R/HOSE COMPLT.	TATA spare parts
885416522169	3RD GEAR (T=22) COUNTER SHAFT	TATA spare parts
885416522170	2ND GEAR (T=17) COUNTER SHAFT	TATA spare parts

885416522171	SYNCHRONISING RING(1/2/3/4) 51T GBS50	TATA spare parts
885416522172	SYNCHRONISING CONE 1/2/3/4/5 SPEED	TATA spare parts
885416522173	MAIN SHAFT	TATA spare parts
885416522174	DRIVE SHAFT 350D	TATA spare parts
885416522175	DETENT PIN	TATA spare parts
885416522176	FUEL LINE	TATA spare parts
885416522177	LINER CYLINDER	TATA spare parts
885416522178	FUEL OVERFLOW LINE	TATA spare parts
885416522179	REP KIT CYL HEAD 94D MNR	TATA spare parts
885416522180	SET CON ROD BRG STD1 94D	TATA spare parts
885416522181	KIT ENG OVERHAUL GASKETS	TATA spare parts
885416522182	GASKET SUPPORT INJECTION PUMP	TATA spare parts
885416522183	BUSH HALF BOTTOM	TATA spare parts
885416522184	BUSH HALF TOP	TATA spare parts
885416522185	STUB AXLE STD P/STRG	TATA spare parts
885416522186	GASKET RA108	TATA spare parts
885416522187	REP KIT SLACKADJUSTER	TATA spare parts
885416522188	SPRING BRAKE SHOE RETURN	TATA spare parts
885416522189	SPRING BR SHOE RETAINER	TATA spare parts
885416522190	SLACK ADJ REAR LH	TATA spare parts
885416522191	KIT REP UNLOADER VALVE	TATA spare parts
885416522192	UNIVERSAL JOINT STRG	TATA spare parts
885416522193	UNIVERSAL JOINT STRG	TATA spare parts
885416522194	STRG SPINDLE TOP	TATA spare parts
885416522195	STRG WHEEL 550 DIA	TATA spare parts
885416522196	FUEL TANK 160 LTR	TATA spare parts
885416522197	SUPPORT W/STRAP	TATA spare parts
885416522198	OVER FLOW RETURN LINE	TATA spare parts
885416522199	HOUSING DIFFERENTIAL	TATA spare parts
885416522200	REAR AXLE SHAFT	TATA spare parts
885416522201	STEERING NUT & WORM	TATA spare parts
885416522202	STEERING SHAFT	TATA spare parts
885416522203	STEERING SHAFT	TATA spare parts
885416522204	STRG. SPINDLE BOTTOM	TATA spare parts
885416522205	HOSE 3/8INCH W/WIRE GUARD	TATA spare parts
885416522206	FRONT AXLE BEAM STD	TATA spare parts
885416522207	STUB AXLE STD	TATA spare parts
885416522208	DIFFERENTIAL CASE COVER	TATA spare parts
885416522209	HUB REAR W/BEARING	TATA spare parts
885416522210	REAR AXLE SHAFT	TATA spare parts
885416522211	CROSS ASSY	TATA spare parts
885416522212	KIT REP SYS PROT VALVE	TATA spare parts
885416522213	DUAL BRAKE VALVE	TATA spare parts
885416522214	PITMAN ARM	TATA spare parts
885416522215	KIT 330 DIA PRESSURE PLATE	TATA spare parts
885416522216	RELEASE LEVER KIT 330 DIA	TATA spare parts
885416522217	ASSY RELEASE LEVER WITH EYE BOLT	TATA spare parts



885416522218	COLLECTOR RING	TATA spare parts
885416522219	HOSE ASSY 1/2	TATA spare parts
885416522220	FUEL TANK 250 LTR	TATA spare parts
885416522221	PRESSURE PLATE MACHINED	TATA spare parts
885416522222	NYLON PIPE SET-1613	TATA spare parts
885416522223	ASSY.NYLON PIPE 6-DIA -2655 LG.	TATA spare parts
885416522224	ASSY.NYLON PIPE 6-DIA - 2790 LG.	TATA spare parts
885416522225	ASSY. NYLON PIPE 12-DIA-2135-LG.	TATA spare parts
885416522226	NYLON PIPE 6DIA 1420 LONG	TATA spare parts
885416522227	NYLON PIPE 6DIA 1420 LONG	TATA spare parts
885416522228	SET MAIN BRG STD	TATA spare parts
885416522229	SET MAIN BRG RS I	TATA spare parts
885416522230	SLEEVE SALVAGE	TATA spare parts
885416522231	GASKET CYLINDER HEAD	TATA spare parts
885416522232	KIT LOWER ENGINE GASKETS	TATA spare parts
885416522233	SET MAIN BEARING RS2	TATA spare parts
885416522234	SET MAIN BEARING RS3	TATA spare parts
885416522235	SET MAIN BEARING RS-4	TATA spare parts
885416522236	GEAR FLYWHEEL RING	TATA spare parts
885416522237	HOUSING FLYWHEEL(C.I)125HP	TATA spare parts
885416522238	RING GEAR - FLYWHEEL	TATA spare parts
885416522239	RING GEAR - FLYWHEEL	TATA spare parts
885416522240	FLYWHEEL	TATA spare parts
885416522241	SET BEARING CON ROD STD	TATA spare parts
885416522242	FLYWHEEL GB-60	TATA spare parts
885416522243	RING GEAR-4.9THK	TATA spare parts
885416522244	GASKET VALVE COVER	TATA spare parts
885416522245	TUBE INJ FUEL SUP	TATA spare parts
885416522246	TUBE INJ FUEL SUP	TATA spare parts
885416522247	FLYWHEEL 125 HP	TATA spare parts
885416522248	ASSY AIR FILTER	TATA spare parts
885416522249	MANIFOLD FUEL	TATA spare parts
885416522250	TUBE FUEL SUPPLY	TATA spare parts
885416522251	STRAINER FUEL	TATA spare parts
885416522252	HOSE PLAIN	TATA spare parts
885416522253	TUBE FUEL SUPPLY	TATA spare parts
885416522254	VALVE DRAIN FUEL WATER	TATA spare parts
885416522255	BEARING CON ROD 1.00 MM OVERSIZE	TATA spare parts
885416522256	BEARING CON ROD 0.75 MM OVERSIZE	TATA spare parts
885416522257	SET BEARING CON ROD RS2	TATA spare parts
885416522258	SET BEARING CON ROD RS1	TATA spare parts
885416522259	REP KIT MINOR A/COMP	TATA spare parts
885416522260	REP KIT MAJOR A/COMP	TATA spare parts
885416522261	AIR COMPRESSOR - SIDE PORT	TATA spare parts
885416522262	MANIFOLD FUEL	TATA spare parts
885416522263	ALTERNATOR 24V	TATA spare parts
885416522264	BUSHING	TATA spare parts

885416522265	STARTER 24 VOLTS	TATA spare parts
885416522266	THERMOSTAT	TATA spare parts
885416522267	KIT UPPER GASKET	TATA spare parts
885416522268	VISCOUS FAN 20 INCH	TATA spare parts
885416522269	WATER PUMP BRG SEPARATOR	TATA spare parts
885416522270	BUSH	TATA spare parts
885416522271	RELEASE SPRING	TATA spare parts
885416522272	RING GEAR	TATA spare parts
885416522273	CON ROD BUSH	TATA spare parts
885416522274	CON.ROD BUSH NORMAL-1- 697 ENGINE	TATA spare parts
885416522275	SPACER 40X4.2	TATA spare parts
885416522276	CON ROD BEARING SET RS 1	TATA spare parts
885416522277	CON ROD BEARING SET RS 2	TATA spare parts
885416522278	CON ROD BEARING SET RS 3	TATA spare parts
885416522279	CON ROD BEARING SET RS 4	TATA spare parts
885416522280	M B SET W/O T/W STD	TATA spare parts
885416522281	M B SET W/O T/W R/S I	TATA spare parts
885416522282	M B SET W/O T/W R/S II	TATA spare parts
885416522283	M B SET W/O T/W R/S III	TATA spare parts
885416522284	KING PIN PAIR 1210 RS1 35.10	TATA spare parts
885416522285	KING PIN PAIR 1210 RS2 35.20	TATA spare parts
885416522286	KING PIN PAIR 1210 RS4 35.40	TATA spare parts
885416522287	SHIFTER FINGER	TATA spare parts
885416522288	COVER FRONT TOP	TATA spare parts
885416522289	SYNCHROCONE-FORGED	TATA spare parts
885416522290	SUPPORT ALTERNATOR BS2	TATA spare parts
885416522291	SEAL OIL	TATA spare parts
885416522292	ASSY TIE ROD	TATA spare parts
885416522293	GASKET RING CR SHAFT FRT	TATA spare parts
885416522294	OIL SEAL PROP SHAFT 1612	TATA spare parts
885416522295	OIL SEAL R R GBS 40 /50	TATA spare parts
885416522296	OIL SEAL R R GBS 40 /50	TATA spare parts
885416522297	REP KIT KING PIN RS1	TATA spare parts
885416522298	REP KIT KING PIN RS2	TATA spare parts
885416522299	THRUST WASHER	TATA spare parts
885416522300	CL REL BRG W/SLEEVE	TATA spare parts
885416522301	CLUTCH RELS.BRG.(SELF-CENTERING)	TATA spare parts
885416522302	ALTERNATOR CLAMP	TATA spare parts
885416522303	ENGINE MOUNTING ARM RH-FRONT	TATA spare parts
885416522304	ENGINE MOUNTING ARM LH-FRONT	TATA spare parts
885416522305	A/FILTER ELEMENT PRIMARY	TATA spare parts
885416522306	A/FILTER ELEMENT SAFETY	TATA spare parts
885416522307	CONNECTING LINE	TATA spare parts
885416522308	FUEL LINE	TATA spare parts
885416522309	PIPE 6 DIA	TATA spare parts
885416522310	BRAKE DRUM SCAM FR & RR	TATA spare parts
885416522311	SHACKLE PIN	TATA spare parts

885416522312	KIT REP DRAG LINK	TATA spare parts
885416522313	4 WAY SYST PROT VALVE	TATA spare parts
885416522314	SPRING BRAKE ACTUATOR	TATA spare parts
885416522315	BUSH FULCRUM PIN	TATA spare parts
885416522316	DUST COVER BOTTOM	TATA spare parts
885416522317	DUST COVER TOP	TATA spare parts
885416522318	DUST COVER BOTTOM	TATA spare parts
885416522319	REP KIT REL LEVER COIL	TATA spare parts
885416522320	DISC FACING KIT	TATA spare parts
885416522321	KIT PRESSURE SPRING 330 DIA	TATA spare parts
885416522322	CLUTCH DISC ASSY 1.75 SPLINE 352 DIA	TATA spare parts
885416522323	CLUTCH COVER ASSY 1.75 SPLINE	TATA spare parts
885416522324	CLUTCH DISC ASSY 1.5 SPLINE	TATA spare parts
885416522325	CLUTCH COVER ASSY 1.5 SPLINE	TATA spare parts
885416522326	COVER & DIAPHRAGM SUB ASSY	TATA spare parts
885416522327	RETURN SPRING-CLUTCH CONTROL	TATA spare parts
885416522328	VALVE INTAKE	TATA spare parts
885416522329	VALVE EXHAUST	TATA spare parts
885416522330	CARTRIDGE - PLASTIC RESERVOIR	TATA spare parts
885416522331	AIR VENT SCREW	TATA spare parts
885416522332	CAP OIL FILLER	TATA spare parts
885416522333	DIPSTICK	TATA spare parts
885416522334	REP KIT CYL HEAD 94D MJR	TATA spare parts
885416522335	SERVICE INDICATOR	TATA spare parts
885416522336	ELBOW	TATA spare parts
885416522337	PULL CABLE ASSY	TATA spare parts
885416522338	ASSY. PULL CABLE ENG STOP	TATA spare parts
885416522339	TUBE DIPSTICK	TATA spare parts
885416522340	PLUG EXPANSION	TATA spare parts
885416522341	DOWEL RING M16X10	TATA spare parts
885416522342	CONNECTOR ENGINE VENT	TATA spare parts
885416522343	KIT-DIPSTICK LP/LPO 1512TC	TATA spare parts
885416522344	HOSE PLAIN	TATA spare parts
885416522345	DIPSTICK	TATA spare parts
885416522346	TUBE OIL GAUGE	TATA spare parts
885416522347	TUBE OIL GAUGE	TATA spare parts
885416522348	PIPE AIR INLET	TATA spare parts
885416522349	HOSE PLAIN	TATA spare parts
885416522350	COVER GEAR	TATA spare parts
885416522351	HOSE PLAIN	TATA spare parts
885416522352	DOWEL PIN	TATA spare parts
885416522353	SLEEVE WEAR-FRONT	TATA spare parts
885416522354	SLEEVE WEAR	TATA spare parts
885416522355	HOUSING GEAR	TATA spare parts
885416522356	PIN TIMING	TATA spare parts
885416522357	HOUSING TIMING PIN	TATA spare parts
885416522358	COVER PUSH ROD	TATA spare parts

885416522359	CAMSHAFT	TATA spare parts
885416522360	KEY PLAIN WOODRUFF	TATA spare parts
885416522361	SUPPORT CAMSHAFT THRUST	TATA spare parts
885416522362	TAPPET VALVE	TATA spare parts
885416522363	ROD PUSH	TATA spare parts
885416522364	VALVE COVER	TATA spare parts
885416522365	PLATE COVER	TATA spare parts
885416522366	DRAIN VALVE WATER SEPERATOR	TATA spare parts
885416522367	SCREW HEX FLANGE HD CAP	TATA spare parts
885416522368	SEAL BANJO CONNECTOR	TATA spare parts
885416522369	HOSE FLEXIBLE	TATA spare parts
885416522370	BRACE FUEL PUMP	TATA spare parts
885416522371	BRACE FUEL PUMP	TATA spare parts
885416522372	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
885416522373	VALVE CHECK	TATA spare parts
885416522374	CLAMP HOSE	TATA spare parts
885416522375	SEAL RECT RING	TATA spare parts
885416522376	CAP FILLER	TATA spare parts
885416522377	HEAD FUEL FILTER	TATA spare parts
885416522378	HEAD FUEL FILTER	TATA spare parts
885416522379	SCREW	TATA spare parts
885416522380	SEAL INJECTOR	TATA spare parts
885416522381	GEAR ACCESSORY DRIVE	TATA spare parts
885416522382	BRACE AIR COMPRESSOR	TATA spare parts
885416522383	COMPRESSOR AIR	TATA spare parts
885416522384	CLAMP HOSE	TATA spare parts
885416522385	CLAMP VBAND	TATA spare parts
885416522386	CONNECTION OIL DRAIN TC	TATA spare parts
885416522387	TURBOCHARGER LPT1613TC	TATA spare parts
885416522388	MINOR REPAIR KIT TURBOCHARGER	TATA spare parts
885416522389	BELT V RIBBED	TATA spare parts
885416522390	TENSIONER BELT	TATA spare parts
885416522391	CONNECTION FEMALE	TATA spare parts
885416522392	CORE COOLER	TATA spare parts
885416522393	PAN OIL FOR CNG ENGINE	TATA spare parts
885416522394	TUBE OIL FILLER	TATA spare parts
885416522395	OIL PUMP	TATA spare parts
885416522396	RING RETAINING	TATA spare parts
885416522397	TUBE TURBO OIL DRAIN	TATA spare parts
885416522398	SCREW HEX FLANGE HEAD	TATA spare parts
885416522399	SUPPORT FAN	TATA spare parts
885416522400	HOSE FLEXIBLE	TATA spare parts
885416522401	PULLEY FAN	TATA spare parts
885416522402	FAN DRIVE VISCOUS	TATA spare parts
885416522403	HOSE FLEXIBLE	TATA spare parts
885416522404	SUPPORT FRONT ENGINE	TATA spare parts
885416522405	SUPPORT FRT ENGINE ASSY	TATA spare parts

885416522406	HOSE RAD TO ENG LP1312	TATA spare parts
885416522407	SPACER VIB DAMPER	TATA spare parts
885416522408	DIPSTICK	TATA spare parts
885416522409	WASHER SEALING	TATA spare parts
885416522410	WASHER SEALING	TATA spare parts
885416522411	WASHER SEALING	TATA spare parts
885416522412	SPACER PUMP SUPPORT	TATA spare parts
885416522413	OIL SEAL	TATA spare parts
885416522414	OIL SEAL	TATA spare parts
885416522415	OIL SEAL FRT GBS40/50	TATA spare parts
885416522416	Banjo Washer	TATA spare parts
885416522417	Banjo Washer	TATA spare parts
885416522418	M.D Retainer Packing GB 40	TATA spare parts
885416522419	2ND & 3RD SHIFTER ROD	TATA spare parts
885416522420	SYNCHO CONE	TATA spare parts
885416522421	P/S HOSE PIPE METALLIC TYPE	TATA spare parts
885416522422	STEERING BOLT KIT	TATA spare parts
885416522423	STEERING U JOINT TC	TATA spare parts
885416522424	ASSEMBLY BRACKET STEERING GEAR BOX MOUN	TATA spare parts
885416522425	ASSY SLACK ADJUSTER REAR-RH(AUTO)	TATA spare parts
885416522426	ASSY SLACK ADJUSTER REAR-LH(AUTO)	TATA spare parts
885416522427	ASSY.CENTRE BEARING BRACKET.	TATA spare parts
885416522428	BRACKET FOR CENTRE B	TATA spare parts
885416522429	BRACKET FOR CENTRE BEARING-2	TATA spare parts
885416522430	BKT CENTRE BEARING	TATA spare parts
885416522431	ASSY EXHUAST PIPE	TATA spare parts
885416522432	ASSY EXH PIPE 81DIA X L 290	TATA spare parts
885416522433	ASSY.INTERMEDIATE PIPE	TATA spare parts
885416522434	ASSY. EXHAUST PIPE AT EXHAUST MANIFOLD	TATA spare parts
885416522435	FILTER CARTRIDGE-DOUBLE LIFE	TATA spare parts
885416522436	CYL ROLLER BRG	TATA spare parts
885416522437	BEARING ROLLER CAGE	TATA spare parts
885416522438	KING PIN THRUST BRG STD1	TATA spare parts
885416522439	ASSY CENTRE BRG WITH RET.	TATA spare parts
885416522440	KIT KING PIN W/O BRG T/W	TATA spare parts
885416522441	K.PIN UNIT-M.KIT&BUSH-RS1	TATA spare parts
885416522442	K.PIN UNIT-M.KIT&BUSH-RS2	TATA spare parts
885416522443	THRUST WASHER 0.8MM THK	TATA spare parts
885416522444	DRAG LINK ASSY RHDLP01313	TATA spare parts
885416522445	REP KIT BALL END	TATA spare parts
885416522446	RESERVE TANK ASSY COMPLETE	TATA spare parts
885416522447	FRAME RADIATOR MTG	TATA spare parts
885416522448	FAN SHROUD	TATA spare parts
885416522449	CLH.MAS.CYL. DIA 25.4X36	TATA spare parts
885416522450	ASSY.REPAIR KIT MAJOR 25.4 DIA M/CYL	TATA spare parts
885416522451	PISTON R/KIT	TATA spare parts
885416522452	PISTON RING R/KIT	TATA spare parts

885416522453	RELEASE LEVER SERVICE KIT	TATA spare parts
885416522454	PRESSURE SPRING SERVICE KIT	TATA spare parts
885416522455	RELEASE SLEEVE SERVICE KIT	TATA spare parts
885416522456	H/L BULB 100/90 24 V (P 43T FITMENT)	TATA spare parts
885416522457	H/L BULB 100/90 24 V (P45T FITMENT)	TATA spare parts
885416522458	ASSY ENG 125 HP 24 V EURO II LPO1512TC	TATA spare parts
885416522459	ASSY ENGINE 6BTA-EII 24V-45A 160HP	TATA spare parts
885416522460	ENGINE 6BTAA EII 160HP ENG RETARDER	TATA spare parts
885416522461	ASSY. RADIATOR COMPLETE	TATA spare parts
885416522462	ASSY RADIATOR	TATA spare parts
885416522463	ASSY FRONT AXLE -4018 3516 2516	TATA spare parts
885416522464	ASSY GEAR BOX GBS40 7.5 8BCF	TATA spare parts
885416522465	GEAR BOX HOUSING	TATA spare parts
885416522466	GEARBOX HOUSING COVER(FRONT TOP)	TATA spare parts
885416522467	CARRIER HOUSING 1312	TATA spare parts
885416522468	ASSY G600-6/6.58 RHD OD W*30DEG.SL LEVER	TATA spare parts
885416522469	ASSY G600-6/8.47 CABLESHIFT RE SL.LVERUP	TATA spare parts
885416522470	ASSY G600-6/6.58 W/150D C/FLG & 30D.SL	TATA spare parts
885416522471	CLUTCH HSG.LP1312TC	TATA spare parts
885416522472	INJECTOR	TATA spare parts
885416522473	BUSH	TATA spare parts
885416522474	FLYWHEEL HOUSING	TATA spare parts
885416522475	MOTOR STARTING 24 VOLTS	TATA spare parts
885416522476	ASSY.RADIATOR-TRNS TANK LP1512/LPT2515	TATA spare parts
885416522477	ASSY.RADIATOR(LP1512TC E-3)	TATA spare parts
885416522478	FIP EURO-II	TATA spare parts
885416522479	INJECTOR ASSY	TATA spare parts
885416522480	ASSY RADATOR BLOCK COMP (1616 TC)	TATA spare parts
885416522481	ASSY TIE TOD ALT/TIE ROD CUP	TATA spare parts
885416522482	GASKET TURBOCHAERGER	TATA spare parts
885416522483	GER BOX PACKING KIT	TATA spare parts
885416522484	GEAR BOX TOP COVER GASKET	TATA spare parts
885416522485	FRONT END COVER PACKING	TATA spare parts
885416522486	GASKET TOP COVER UPPER	TATA spare parts
885418010713	KIT FOR LUBRICATING OIL COOLER / OIL FIL	TATA spare parts
885418011613	SET OF 2 FILTER FOR 697	TATA spare parts
885418012516	SET OF 3 FILTER (9902+9904+9916)	TATA spare parts
885418012523	GEAR SET FOR OIL PUMP	TATA spare parts
885418013118	SET OF 3 FILTER (0145 9967 9909)	TATA spare parts
885418020713	KIT FOR PAN OIL AND DIPSTICK	TATA spare parts
885418022516	SET OF 3 FILTER (9902+9903+9904)	TATA spare parts
885418022525	KIT OIL PUMP GEAR	TATA spare parts
885418030713	KIT FOR LUBRICATING OIL PUMP	TATA spare parts
885418032516	SET OF 3 FILTER (9902+9904+9916)	TATA spare parts
885418032525	ASSY.OIL COOLER PLATE TYPE H.EXCHANGER	TATA spare parts
885418042516	SET OF 3 KIT (885418022516) CUMMINS ENG	TATA spare parts
885418042525	OIL PR RELEIF VALVE KIT	TATA spare parts

885418052516	SET OF 2 FILTERS (WITH 9904 & 9916)	TATA spare parts
885418052525	KIT FOR OIL COOLER AND OIL GAUGE LINES F	TATA spare parts
885418062516	SET OF 3 FILTER (WITH 0145 9904 & 9916)	TATA spare parts
885418062525	KIT FOR OIL PUMP FOR ARMY	TATA spare parts
885418072516	SET OF 2 FILTER ( WITH 0145 & 9965)	TATA spare parts
885418072525	KIT FOR OIL FILTER FOR ARMY	TATA spare parts
885418082516	SET OF 2 FILTER ( WITH 0145 & 0239)	TATA spare parts
885418082525	KIT OIL PUMP GEAR 50 MM LONG	TATA spare parts
885418092516	SET OF 2 FILTER ( WITH 0139 & 0239)	TATA spare parts
885420010713	KIT FOR FAN ( FIXED ) AND DRIVE	TATA spare parts
885420011312	CONVERSION KIT VISCOUSFAN	TATA spare parts
885420012525	SEAL KIT WATER PUMP	TATA spare parts
885420020713	KIT FOR THERMOSTAT AND ENGINE LIFTING	TATA spare parts
885420030713	KIT FOR WATER PUMP & CONNECTION	TATA spare parts
885420042525	KIT FOR WATER PUMP FOR ARMY	TATA spare parts
885420052525	KIT FOR COOLING WATER THERMOSTAT FOR ARMY	TATA spare parts
885420062525	KIT FOR COOLING WATER LINE AND ENGINE SU	TATA spare parts
885421012518	SET OF 2 AIR FILTER KIT LPK 2518	TATA spare parts
885421014023	SET OF 2 AIR FILTER PRIMA 4023S	TATA spare parts
885421014038	SET OF 2 AIR FILTER KIT PRIMA 4038S	TATA spare parts
885423312527	M BEARING SET W/O T/W RS 2	TATA spare parts
885424012829	Kit Engine Mtg Set -Ace/Magic	TATA spare parts
885424014018	KIT-ENGINE MOUNTING FR AND RR	TATA spare parts
885424022829	Kit Engine Mtg Set -Ace Zip	TATA spare parts
885425000001	CLUTCH FACING 207 DI NASB	TATA spare parts
885425000002	CL.FACING 407 NA STRAIGHT HOLE NASB	TATA spare parts
885425000003	CLUTCH FACING 407 TURBO DIFF. THK. NASB	TATA spare parts
885425000004	CLUTCH FACING 709 NA NASB	TATA spare parts
885425000006	CLUTCH FACING 310 DIA ASBESTOS	TATA spare parts
885425000007	CLUTCH FACING 310 DIA NON ASBESTOS	TATA spare parts
885425010216	CLUTCH SET W/CRB 280 DIA. ORGANIC	TATA spare parts
885425011010	ASY.310 DIA.DRIVEN DISC & COVER ASY	TATA spare parts
885425012527	310 DIA CLUTCH COVER KIT	TATA spare parts
885425012654	KIT-CLUTCH 240DIA. (W/-NON ASB. FACING)	TATA spare parts
885425012789	CLUTCH TWIN SET	TATA spare parts
885425012818	SET OF 3 (CP + CA + CRB) 200 DIA	TATA spare parts
885425012829	KIT -CLUTCH 170 DIA. DISC+COVER	TATA spare parts
885425012898	CLUTCH SET-260DIA.SAC W/SLAVE CYL. BS6	TATA spare parts
885425013118	ASSY. 380DIA. DRIVEN DISC & COVER	TATA spare parts
885425022525	KIT FOR CLUTCH HOUSING FOR ARMY	TATA spare parts
885425022829	CLUTCH KIT 170 DIA DISC+COVER	TATA spare parts
885425032525	KIT FOR CLUTCH (DIAPHRAGM) FOR ARMY	TATA spare parts
885425042829	KIT-CLUTCH PR PLATE TATA ACE W/BRG	TATA spare parts
885425052829	KIT-CL/PR PLATE TATA ACE WO BRG	TATA spare parts
885425062829	KIT-CL/PR PLATE 160 DIA ZIP/IRIS	TATA spare parts
885425072829	KIT CL/PR PLATE TATA ACE W/BRG	TATA spare parts
885425082829	KIT-CL/PR PLATE TATA ACE WO BRG	TATA spare parts

885425092829	SET OF 3 (CP + CA + CRB) 190 DIA	TATA spare parts
885425102829	KIT-CL/PR PLATE TATA ACE W/BRG	TATA spare parts
885425201613	CLUTCH DISC 330 DIA. (DOUBLE RING)	TATA spare parts
885425202518	ASSY. CLUTCH DISC 352DIA. - 1.75 SPLIN	TATA spare parts
885426010207	KIT GASKETS GBS76	TATA spare parts
885426010407	KIT SYNCHRO GB 380	TATA spare parts
885426010709	KIT GASKET GBS27	TATA spare parts
885426011109	KIT-SYNCHRO GB550	TATA spare parts
885426011613	GASKET KIT-GB40 REM CONT	TATA spare parts
885426011616	GEAR BOX GASKET KIT	TATA spare parts
885426012515	KIT ENG. O/H G600	TATA spare parts
885426012516	KIT-DETENT PIN G600	TATA spare parts
885426012518	SYNCHRO KIT-GB750/GB680	TATA spare parts
885426012818	KIT-GEAR LEVER BUSH-SUPER ACE BS1/3/4	TATA spare parts
885426012829	KIT-GEAR LEVER BUSH -ACE	TATA spare parts
885426012854	AXLE & BEVEL GEAR KIT WINGER	TATA spare parts
885426013118	KIT-GASKET G750 GEARBOX	TATA spare parts
885426013518	KIT-SYNCHRO GB1150	TATA spare parts
885426014018	KIT-OIL SEAL GB750	TATA spare parts
885426014021	G1150 GEARBOX GASKET KIT	TATA spare parts
885426020207	SYNCHRO KIT GB76	TATA spare parts
885426021109	GEAR LEVER KIT 407/709/1109	TATA spare parts
885426021613	OIL SEAL GBS-40	TATA spare parts
885426021616	SYN.KIT GBS50 W/O RE	TATA spare parts
885426022516	KIT-CIRCLIP? G-600	TATA spare parts
885426022854	DIFF WASHER KIT WINGER	TATA spare parts
885426023118	G750 GEARBOX GASKET KIT TIPPER	TATA spare parts
885426024018	BALL JOINT KIT	TATA spare parts
885426030207	GEAR LEVER REPAIR KIT 207 DI/ XENON	TATA spare parts
885426031109	GB 40 OIL SEAL KIT	TATA spare parts
885426031616	O/H KIT GBS50	TATA spare parts
885426032518	KIT-CIRCLIP? G-750	TATA spare parts
885426032854	SYNCHRO KIT-WINGER	TATA spare parts
885426041109	KIT GASKET FOR GBS 550	TATA spare parts
885426041612	KIT-SYNCHRO GBS-40 BS1/2/3/4	TATA spare parts
885426042518	KIT-CIRCLIP G-1150 BS2/3/4	TATA spare parts
885426051613	OVERHAULING KIT - GB40 BS4	TATA spare parts
885426051616	SYNCHRO KIT GBS-50	TATA spare parts
885426052518	SELECTOR SHAFT KIT G.B.750 1150	TATA spare parts
885426060407	KIT-SYNCHRO GBS-18 BS2/3/4	TATA spare parts
885426061613	GEAR LEVER KIT SE/ SK 1613_ G600	TATA spare parts
885426062518	SELECTOR SHAFT KIT G.B.750/60	TATA spare parts
885426070709	KIT-SYNCHRO GBS-27 BS2/3/4	TATA spare parts
885426071613	GEAR LEVER KIT LP/LPT LICVS & MHVS	TATA spare parts
885430010001	CYLINDER HEAD GASKET	TATA spare parts
885430010002	SPARK PLUG	TATA spare parts
885430010003	INSULATOR PACKING	TATA spare parts



885430010004	GASKET CARBURETOR	TATA spare parts
885430010005	GASKET AIR CLEANER	TATA spare parts
885430010006	FILTER FUEL - PETROL	TATA spare parts
885430010007	FILTER FUEL - KEROSENE	TATA spare parts
885430010008	GASKET SILENCER	TATA spare parts
885430010009	ELEMENT AIR CLEANER	TATA spare parts
885430010010	OIL SEAL INNER RING	TATA spare parts
885430010011	OIL SEAL INNER RING	TATA spare parts
885430010012	ROPE STARTER ASSY	TATA spare parts
885430010013	RUBBER PACKING	TATA spare parts
885430010014	RUBBER WATER SEAL	TATA spare parts
885430010015	RUBBER PKG TO THE SHAPE OF ITEM NO 10 (6	TATA spare parts
885430010016	RUBBER PACKING DIA 90 X 10 MM THK	TATA spare parts
885430010017	PVC PIPE DIA 40 X 600 LG	TATA spare parts
885430010018	REDUCER DIA 80 X 40 SS	TATA spare parts
885430010019	PIPE CAP DIA 40	TATA spare parts
885430010020	DELIVERY HOSE CAVAS 38 MM X 20 M WITH CO	TATA spare parts
885430010021	SUCTION HOSE CAVAS 38 MM X 30 M WITH COU	TATA spare parts
885430010909	CON.KIT-MECH.ENGINE STOP	TATA spare parts
885432010207	FRONT SPRING GREEN W/ RUBBER PAD 207DI	TATA spare parts
885432010909	RUBBER BUSH KIT	TATA spare parts
885432011012	ASSY. RUBBER BUSH KIT FRONT & REAR	TATA spare parts
885432012516	SET-BUSH BELL CRANK BS1/2/3/4	TATA spare parts
885432012818	KIT-FRONT BUSHING -SUPER ACE BS1/3/4	TATA spare parts
885432012829	KIT FOR FRONT SPRING ( 2 LEAF )	TATA spare parts
885432012897	KIT-FRONT SUSPENSION REPAIR-XENON 2.2L	TATA spare parts
885432020207	FRONT SPRING YELLOW W/ RUBBER PAD 207DI	TATA spare parts
885432021012	ASSY. RUBBER BUSH KIT - REAR	TATA spare parts
885432022818	KIT-FRONT SUSPENSION REPAIR-SUPER ACE BS	TATA spare parts
885432030207	FRONT SPRING SOL. PINK W/ RUBBER PAD 207	TATA spare parts
885432031012	ASSY. RUBBER BUSH KIT - FRONT	TATA spare parts
885432222698	KIT FRT SUSPEN.SUMO	TATA spare parts
885433010207	207 HUB GREASING KIT SPICER FRONT	TATA spare parts
885433010407	K.PIN UNIT-M.KIT&BUSH-RS1	TATA spare parts
885433010709	K.PIN UNIT-M.KIT&BUSH-RS1	TATA spare parts
885433010812	KING PIN KIT (ULTRA 812)	TATA spare parts
885433010909	KING PIN MINOR KIT - 909	TATA spare parts
885433010912	KING PIN REPAIR KIT (STD)	TATA spare parts
885433011109	KIT-HUB GREASING 1109	TATA spare parts
885433011210	K.PIN UNIT-M.KIT&BUSH-RS1	TATA spare parts
885433011612	MAJOR KIT-KING PIN & BUSH-RS1 BS1/2/3/4	TATA spare parts
885433011613	SET THRUST PAD (NORMAL)	TATA spare parts
885433012516	SET HUB BOLT AND NUT	TATA spare parts
885433012663	207DI / XENON HUB GREASING KIT	TATA spare parts
885433012818	KIT-HUB GREASING SUPER ACE	TATA spare parts
885433012829	KIT-ACE HUB GREASING	TATA spare parts
885433013718	KING PIN KIT MHV 3718/2518	TATA spare parts

885433014018	Hub Greasing kit FA - 2515/1613/4018	TATA spare parts
885433014023	Hub Greasing Kit FA 3118/Prima 4023	TATA spare parts
885433020207	KING PIN MINOR KIT - 207	TATA spare parts
885433020407	K.PIN UNIT-M.KIT&BUSH-RS2	TATA spare parts
885433020709	K.PIN UNIT-M.KIT&BUSH-RS2	TATA spare parts
885433020909	REPAIR KIT KING PIN STD. BS2/3/4	TATA spare parts
885433021210	K.PIN UNIT-M.KIT&BUSH-RS2	TATA spare parts
885433021612	K.PIN UNIT-M.KIT&BUSH-RS2	TATA spare parts
885433022663	207DI / XENON HUB GREASING KIT WITH TGG	TATA spare parts
885433022818	SUPER ACE HUB GREASING KIT WITH TGG	TATA spare parts
885433022829	KING PIN MINOR KIT - ACE	TATA spare parts
885433030207	REPAIR KIT-KING PIN 207 STD. FULL	TATA spare parts
885433030407	K.PIN UNIT-M.KIT&BUSH-RS3	TATA spare parts
885433030709	K.PIN UNIT-M.KIT&BUSH-RS3	TATA spare parts
885433030909	KING PIN PAIR 909 STD	TATA spare parts
885433031210	K.PIN UNIT-M.KIT&BUSH-RS3	TATA spare parts
885433031612	K.PIN UNIT-M.KIT&BUSH-RS3	TATA spare parts
885433032829	REPAIR KIT KING PIN ACE STD. FULL	TATA spare parts
885433040207	KING PIN PAIR 207 STD	TATA spare parts
885433040407	K.PIN SET-M.KIT-STD	TATA spare parts
885433040709	K.PIN SET-M.KIT-STD	TATA spare parts
885433040909	KING PIN SET MINOR KIT 909 STD	TATA spare parts
885433041210	K.PIN UNIT-M.KIT&BUSH-RS4	TATA spare parts
885433041612	K.PIN SET-M.KIT-STD	TATA spare parts
885433042829	KING PIN PAIR ACE STD	TATA spare parts
885433050207	KING PIN SET MINOR KIT 207 STD	TATA spare parts
885433050407	K.PIN SET-M.KIT-RS1	TATA spare parts
885433050709	K.PIN SET-M.KIT-RS1	TATA spare parts
885433050909	KING PIN UNIT MINOR KIT & BUSH 909 STD	TATA spare parts
885433051210	K.PIN UNIT-M.KIT&BUSH-RS5	TATA spare parts
885433051612	K.PIN SET-M.KIT-RS1	TATA spare parts
885433052829	KING PIN SET MINOR KIT ACE STD	TATA spare parts
885433060207	KING PIN UNIT MINOR KIT & BUSH 207 STD	TATA spare parts
885433060407	K.PIN SET-M.KIT-RS2	TATA spare parts
885433060709	K.PIN SET-M.KIT-RS2	TATA spare parts
885433060909	KING PIN PAIR BLACK 909 STD. 32.00	TATA spare parts
885433061109	KIT-HUB GREASING 1109 (MODIFIED)	TATA spare parts
885433061210	K.PIN UNIT-M.KIT&BUSH-RS6	TATA spare parts
885433061612	K.PIN SET-M.KIT-RS2	TATA spare parts
885433062829	KING PIN UNIT MINOR KIT & BUSH ACE STD	TATA spare parts
885433070207	KIT STRG BALL JOINTS 207DI(4 IN 1)	TATA spare parts
885433070407	K.PIN SET-M.KIT-RS3	TATA spare parts
885433070709	K.PIN SET-M.KIT-RS3	TATA spare parts
885433070909	KING PIN PAIR BLACK 909 STD. O/S 1 32.1	TATA spare parts
885433071109	Hub Greasing Kit FA- 1109	TATA spare parts
885433071210	K.PIN UNIT-M.KIT&BUSH-RS7	TATA spare parts
885433071612	K.PIN SET-M.KIT-RS3	TATA spare parts

885433072829	KIT-AXLE BRG. FRONT (30204+320/32)	TATA spare parts
885433080207	KING PIN PAIR BLACK 207 STD. 20.00	TATA spare parts
885433080407	K.PIN MINOR KIT 407	TATA spare parts
885433080709	K.PIN MINOR KIT 709/608	TATA spare parts
885433080909	KING PIN PAIR BLACK 909 STD. O/S 2 32.2	TATA spare parts
885433081210	K.PIN MINOR KIT 1210	TATA spare parts
885433081612	MINOR KIT-KING PIN 1612 BS1/2/3/4	TATA spare parts
885433090207	KING PIN PAIR BLACK 207 STD. O/S 1 20.1	TATA spare parts
885433090407	KING PIN PAIR 407 STD 25.00	TATA spare parts
885433090709	KING PIN PAIR 709 STD 30.00	TATA spare parts
885433090909	KING PIN PAIR BLACK 909 STD. O/S 3 32.3	TATA spare parts
885433091210	K.PIN SET-M.KIT -STD	TATA spare parts
885433091612	KING PIN PAIR 1612 STD 38.25	TATA spare parts
885433100207	KING PIN PAIR BLACK 207 STD. O/S 2 20.2	TATA spare parts
885433100407	KING PIN PAIR 407 RS1 25.10	TATA spare parts
885433100709	KING PIN PAIR 709 RS1 30.10	TATA spare parts
885433101210	K.PIN SET-M.KIT-RS1	TATA spare parts
885433101612	KING PIN PAIR 1612 RS1 38.35	TATA spare parts
885433110207	KING PIN PAIR BLACK 207 STD. O/S 3 20.3	TATA spare parts
885433110407	KING PIN PAIR 407 RS2 25.20	TATA spare parts
885433110709	KING PIN PAIR 709 RS2 30.20	TATA spare parts
885433111210	K.PIN SET-M.KIT-RS2	TATA spare parts
885433111612	KING PIN PAIR 1612 RS2 38.45	TATA spare parts
885433120407	KING PIN PAIR 407 RS3 25.30	TATA spare parts
885433120709	KING PIN PAIR 709 RS3 30.30	TATA spare parts
885433121210	K.PIN SET-M.KIT-RS3	TATA spare parts
885433121612	KING PIN PAIR 1612 RS3 38.55	TATA spare parts
885433131210	K.PIN SET-M.KIT-RS4	TATA spare parts
885433141210	K.PIN SET-M.KIT-RS5	TATA spare parts
885433150709	KIT-HUB GREASING 709	TATA spare parts
885433151210	K.PIN SET-M.KIT-RS6	TATA spare parts
885433160709	KIT-HUB GREASING 709 (MODIFIED)	TATA spare parts
885433161210	K.PIN SET-M.KIT-RS7	TATA spare parts
885433161612	KIT KING PIN W/O BRG T/W BS1/2/3/4	TATA spare parts
885433170709	Hub Greasing kit FA - 407/709/909	TATA spare parts
885433171210	K.PIN UNIT M.KIT&BUSH STD 35 MM 1210	TATA spare parts
885433180407	KIT KING PIN W/O BRG T/W	TATA spare parts
885433181210	KING PIN PAIR 1210 STD 35.00	TATA spare parts
885433181612	AXLE BRG KIT FRT (32308+565/562)	TATA spare parts
885433182829	REPAIR KIT KING PIN - ACE RS 1 FULL	TATA spare parts
885433190407	KING PIN PAIR BLACK 407 STD. 25.00	TATA spare parts
885433190709	KIT KING PIN W/O BRG T/W BS1/2/3/4	TATA spare parts
885433191210	KING PIN PAIR 1210 RS1 35.10	TATA spare parts
885433192829	REPAIR KIT KING PIN - ACE RS 2 FULL	TATA spare parts
885433200407	KING PIN PAIR BLACK 407 STD. O/S 1 25.1	TATA spare parts
885433200709	KING PIN PAIR BLACK 709 STD. 30.00	TATA spare parts
885433201210	KING PIN PAIR 1210 RS2 35.20	TATA spare parts

885433202829	KING PIN PAIR - ACE RS 1	TATA spare parts
885433210407	KING PIN PAIR BLACK 407 STD. O/S 2 25.	TATA spare parts
885433210709	KING PIN PAIR BLACK 709 STD. O/S 1 30.1	TATA spare parts
885433211210	KING PIN PAIR 1210 RS3 35.30	TATA spare parts
885433212829	KING PIN PAIR - ACE RS 2	TATA spare parts
885433220407	KING PIN PAIR BLACK 407 STD. O/S 3 25.	TATA spare parts
885433220709	KING PIN PAIR BLACK 709 STD. O/S 2 30.2	TATA spare parts
885433221210	KING PIN PAIR 1210 RS4 35.40	TATA spare parts
885433222829	KING PIN SET WITH MINOR KIT - ACE RS 1	TATA spare parts
885433230407	KING PIN REPAIR KIT-STD-407 BS2/3/4	TATA spare parts
885433230709	KING PIN PAIR BLACK 709 STD. O/S 3 30.3	TATA spare parts
885433231210	KING PIN PAIR 1210 RS5 35.50	TATA spare parts
885433231612	KINGPIN PAIR BLACK STD 38.25MM	TATA spare parts
885433232829	KING PIN SET WITH MINOR KIT - ACE RS 2	TATA spare parts
885433240407	KING PIN REP KIT W/O BRG-STD-407 BS2/3/4	TATA spare parts
885433241210	KING PIN PAIR 1210 RS6 35.60	TATA spare parts
885433241612	KINGPIN PAIR BLACK O/S 1 38.35MM	TATA spare parts
885433242829	KING PIN UNIT WITH MINOR & BUSH - ACE RS	TATA spare parts
885433251210	KING PIN PAIR 1210 RS7 35.70	TATA spare parts
885433251612	KINGPIN PAIR BLACK O/S 2 38.45MM	TATA spare parts
885433252829	KING PIN UNIT WITH MINOR & BUSH - ACE RS	TATA spare parts
885433261612	KINGPIN PAIR BLACK O/S 3 38.55MM	TATA spare parts
885433262829	ACE HUB GREASING KIT WITH TGG	TATA spare parts
885433271210	CONVERSION KIT 4X2 TO 4X4	TATA spare parts
885433271612	KINGPIN PAIR BLACK O/S 4 38.65MM	TATA spare parts
885433272829	AXLE BRG KIT FRT (30204+320/32)	TATA spare parts
885433281210	KING PIN PAIR BLACK 1210 STD. 35.00	TATA spare parts
885433281612	FULL REPAIR KIT BLACK KINGPIN STD (1612)	TATA spare parts
885433282829	KING PIN PAIR BLACK ACE STD. 16.00	TATA spare parts
885433291210	KING PIN PAIR BLACK 1210 STD. O/S 1 35.1	TATA spare parts
885433291612	KING PIN PAIR 1612 - STD 38.25	TATA spare parts
885433292829	KING PIN PAIR BLACK ACE STD. O/S 1 16.1	TATA spare parts
885433301210	KING PIN PAIR BLACK 1210 STD. O/S 2 35.2	TATA spare parts
885433301612	KING PIN PAIR 1612 - RS1 38.35	TATA spare parts
885433302829	KING PIN PAIR BLACK ACE STD. O/S 2 16.2	TATA spare parts
885433311210	KING PIN PAIR BLACK 1210 STD. O/S 3 35.3	TATA spare parts
885433312829	KING PIN PAIR BLACK ACE STD. O/S 3 16.3	TATA spare parts
885434013516	REPAIR KIT FIFTH WHEEL COUPLING	TATA spare parts
88543440521	SPL LP/LPO/LPT 1210 E	TATA spare parts
88543440941	SUPPL. DUMPER PLACER	TATA spare parts
885435010207	207 HUB GREASING KIT SPICER REAR	TATA spare parts
885435010407	KIT-HUB GREASING - 407 SINGLE TYRE	TATA spare parts
885435010709	REAR HUB GREASING KIT 709	TATA spare parts
885435011109	REAR HUB GREASING KIT 1109	TATA spare parts
885435011612	AXLE BRG KIT REAR (33214+33019)	TATA spare parts
885435012829	ACE REAR HUB GREASING KIT	TATA spare parts
885435013516	RA109RR WASHER KIT	TATA spare parts

885435013718	ASSY DIFF GEAR KIT RA110	TATA spare parts
885435014018	KIT-HUB GREASING SE1613 BS3/4018	TATA spare parts
885435014021	HUB W/MTG BOLTS BRG STUDS	TATA spare parts
885435020407	REAR HUB GREASING KIT 407	TATA spare parts
885435020709	KIT-DIFFERENTIAL W/SPIDER BS1/2/3/4	TATA spare parts
885435021109	WASHER KIT FOR 1109 DIFF	TATA spare parts
885435021612	AXLE BRG KIT REAR (32217+683/72)	TATA spare parts
885435021613	HUB GREASING KIT - 1612	TATA spare parts
885435024018	SE1613 BS3/4018 HUB GREASING KIT WITH TG	TATA spare parts
885435030407	WASHER KIT FOR 407 DIFF	TATA spare parts
885435030709	REAR HUB GREASING KIT - 709 (MODIFIED)	TATA spare parts
885435031210	KIT FOR R A 107 ( BANJO TYPE )1210 SD	TATA spare parts
885435031613	REAR HUB GREASING KIT 1613	TATA spare parts
885435040407	WASHER KIT FOR 407TWIN/709	TATA spare parts
885435041613	CWP FITMENT KIT FOR RA109/109RR	TATA spare parts
885435051510	CWP FITMENT TOOL KIT	TATA spare parts
885435051613	WASHER KIT FOR M/C DIFF GEARS RA108RR	TATA spare parts
885435061613	DIFF GEAR KIT W/SPIDER RA108 RR FORGED	TATA spare parts
885435071109	KIT-DIFFERENTIAL W/SPIDER BS2/3/4	TATA spare parts
885435071613	DIFF GEAR KIT W/SPIDER RA108 RR FORGED	TATA spare parts
885435072515	KIT-REAR HUB GREASING-EX BS1/2/3/4	TATA spare parts
885435072829	KIT DIFF CASE	TATA spare parts
885435081613	KIT-DIFF. GEAR W/SPIDER RA108 FORG BS1-4	TATA spare parts
885435082515	KIT-HUB GREASING EX	TATA spare parts
885435092525	DUMY AXLE KIT 1817TW/12TK/T24A W4 W/RI	TATA spare parts
885435102525	DUMMY AXLE KIT 1817TW/12THK/T24 W/4 W/RI	TATA spare parts
885435112525	DUMY AXLE KIT 1817TW/14TK/T24A W/4 W/RI	TATA spare parts
885435120407	AXLE BEARING KIT REAR 709	TATA spare parts
885435122525	DUMMY AXLE KIT 1817TW/14THK/T24 W/4 W/RI	TATA spare parts
885435132515	1950-14MM TRAILER AXLE WITH BOOSTERS	TATA spare parts
885435142515	DUMMY AXLE KIT 1950TW/14THK/T24	TATA spare parts
885435152515	DUMY AXLE KIT 1950TW/14TK/T24A W4 W/RI	TATA spare parts
885435162515	DUMY AXLE KIT 1950TW/14TK/T24 W4 W/RI	TATA spare parts
885435172515	DUMY AXLE KIT 1817TW/12TK/T24A W4 TYRE	TATA spare parts
885435182515	DUMMY AXLE KIT 1817TW/12THK/T24 W/4 TYRE	TATA spare parts
885435192515	DUMY AXLE KIT 1817TW/14TK/T24A W/4 TYRE	TATA spare parts
885435202515	DUMMY AXLE KIT 1817TW/14THK/T24 W/4 TYRE	TATA spare parts
885435212515	DUMMY AXLE KIT 1950TW/14THK/T24A W/4 TYR	TATA spare parts
885435222515	DUMMY AXLE KIT 1950TW/14THK/T24 W/4 TYRE	TATA spare parts
885435250407	HUB GREASING KIT - 407 SINGLE TYRE VEH (	TATA spare parts
885435252515	Long Life Rear Hub Greasing Kit - 2515	TATA spare parts
885435262515	REAR HUBGREASINGKIT O/METAL 2515	TATA spare parts
885435272515	HUBGREASINGKIT O/METAL 1613/4018	TATA spare parts
88543570101	SPL SFC 407-4 X 2	TATA spare parts
88543570421	SP SUPPLEMENT LP 407	TATA spare parts
88543730111	CATALOGUE 1613LPT/LPK/LPS	TATA spare parts
88543730431	CATALOGUE FOR 1613 SE SK	TATA spare parts

88543740781	CREW CAB SP.PTS.CATALOGUE	TATA spare parts
88543771081	TATA SIERA 4X4 SUPPLEMENT	TATA spare parts
88543800102	SPL LPT 2213/LPT 2213 A	TATA spare parts
88543860301	SPL LP 709E/LPT 709E	TATA spare parts
885439012599	TRIPLE SUSPN KIT 13T DUMMY AXLE	TATA spare parts
885439022599	DOUBLE SUSPN KIT 13T DUMMY AXLE	TATA spare parts
885439024018	1814-14MM ABS AXLE WITH SLACK ADJUSTER	TATA spare parts
885439032599	TRIPLE SUSPN KIT 16T DUMMY AXLE	TATA spare parts
885439033516	1817-12MM TRAILER AXLE WITH BOOSTERS	TATA spare parts
885439043516	DUMMY AXLE KIT 1817TW/12THK/T24	TATA spare parts
885439053516	1817-14MM TRAILER AXLE WITH BOOSTERS	TATA spare parts
885439063516	DUMMY AXLE KIT 1817TW/14THK/T24	TATA spare parts
885439073516	AXLE KIT 1850 - 12MM WITH TYPE 24 BOOSTE	TATA spare parts
885439083516	AXLE KIT 1850 - 12MM WITH TYPE 24 BOOSTE	TATA spare parts
885439093516	AXLE KIT 1850-12MM -ç 24 B. ACTUATOR WIT	TATA spare parts
885439103516	AXLE KIT 1850/12MM/24 B.ACTUATOR W/ RIMS	TATA spare parts
885439123516	AXLE KIT 1850/12MM/TYPE 24 BOOST KALYANI	TATA spare parts
885439133516	AXLE KIT 1950/14MM/TYPE 24 BOOST KALYANI	TATA spare parts
885439143516	AXLE KIT 1817/12MM/TYPE 24 BOOST KALYANI	TATA spare parts
885439153516	AXLE KIT 1817/14MM/TYPE 24 BOOST KALYANI	TATA spare parts
885439163516	AXLE KIT 1817-12mm - 24 b. Boosters+ Ri	TATA spare parts
885439173516	AXLE KIT 1817-14mm - 24 b. Boosters+ Ri	TATA spare parts
885439183516	AXLE KIT 1950-14mm - 24 b. Boosters+ Ri	TATA spare parts
885439203516	RA KIT 1817/14MM/TY24BOOST/RADTYRE	TATA spare parts
885439213516	RA KIT 1950/14MM/TY24BOOST/RADTYRE	TATA spare parts
885439223516	RA KIT 1817/12MM/TY24BOOST/RADTYRE	TATA spare parts
885439233516	RA KIT 1850/12MM/TY24BOOST/RADTYRE	TATA spare parts
885439243516	RA KIT 1817/14mm/Ty24Boost/ChRadTyre	TATA spare parts
885439253516	RA KIT 1950/14mm/Ty24Boost/ChRadTyre	TATA spare parts
885439263516	RA KIT 1817/12mm/Ty24Boost/ChRadTyre	TATA spare parts
885439273516	RA KIT 1850/12mm/Ty24Boost/ChRadTyre	TATA spare parts
885439343516	1817-12MM TRAILER AXLE WITH WHEEL RIMS	TATA spare parts
885439353350	BELT V RIBBED	TATA spare parts
885439353516	1817-14MM TRAILER AXLE WITH WHEEL RIMS	TATA spare parts
885439363516	1950-14MM TRAILER AXLE WITH WHEEL RIMS	TATA spare parts
885439373516	1850-12 Axle with SSWL Wheel Rim	TATA spare parts
885439383516	1817-12MM TRAILER AXLE WITH LUG TYRES	TATA spare parts
885439393516	1817-14MM TRAILER AXLE WITH LUG TYRES	TATA spare parts
885439403516	1950-14MM TRAILER AXLE WITH LUG TYRES	TATA spare parts
885439413516	DUMMY AXLE KIT 1850TW/12TK/T24A W4 LUG T	TATA spare parts
885439423516	1817-12MM TRAILER AXLE WITH RIB TYRES	TATA spare parts
885439433516	1817-14MM TRAILER AXLE WITH RIB TYRES	TATA spare parts
885439443516	1950-14MM TRAILER AXLES WITH RIB TYRES	TATA spare parts
885439453516	DUMMY AXLE KIT 1850TW/12TK/T24A W4 RIB T	TATA spare parts
885439463516	1817-14MM TRAILER AXLE WITH RADIAL TYRE	TATA spare parts
885439473516	1950-14MM TRAILER AXLES WITH RADIAL TYRE	TATA spare parts
885439483516	1817-12MM TRAILER AXLE WITH RADIAL TYRE	TATA spare parts

885439493516	KIT 1850 12MM 24 BR BOOSTERS APOLLO RADI	TATA spare parts
885439553516	1817-14MM W/O SADDLE TRAILER AXLE	TATA spare parts
885439563516	1817-14MM W/O SADDLE TRAILER AXLE W/TYRE	TATA spare parts
885439573516	1817-14MM W/O SADDLE TRAILER AXLE W/RIMS	TATA spare parts
885439583516	1850-12MM TRAILER AXLE WITH BOOSTERS	TATA spare parts
885439593516	1850-12MM TRAILER AXLE WITH WHEEL RIMS	TATA spare parts
885439603516	1850-12MM TRAILER AXLE WITH LUG TYRES	TATA spare parts
885439613516	1850-12MM TRAILER AXLE WITH RIB TYRES	TATA spare parts
885439623516	1850-12MM TRAILER AXLE WITH RADIAL TYRE	TATA spare parts
885439643516	135 X 150 TRAILER AXLE WITHOUT BOTTOM SA	TATA spare parts
885440010709	KIT REAR WHEEL HUB BOLT & NUT - 709	TATA spare parts
885440011109	KIT REAR WHEEL HUB BOLT & NUT - 1109	TATA spare parts
885440012516	KIT REAR WHEEL HUB BOLT & NUT - 2516/401	TATA spare parts
885440020709	KIT FRONT WHEEL HUB BOLT & NUT - 709	TATA spare parts
885440021109	KIT FRONT WHEEL HUB BOLT & NUT - 1109	TATA spare parts
885440022516	KIT FRONT WHEEL HUB BOLT & NUT -2516/40	TATA spare parts
885441010407	KIT UJ CROSS WITH CIRCLIP 407	TATA spare parts
885441011210	KIT-UNIVERSAL JOINT W/CIRCLIP BS1/2/3/4	TATA spare parts
885441011210AE	CROSS KIT CONSISTS OF: 713 715	TATA spare parts
885441011613	KIT FOR TWIN PROP SHAFT(SK1616/1613)	TATA spare parts
885441011615	JOINT NUT & BOLT 1615/2516	TATA spare parts
885441011618	KIT CENTRE BEARING PARTS	TATA spare parts
885441012515	COMPANION FLANGE	TATA spare parts
885441012518	CB KIT	TATA spare parts
885441012829	JOINT NUT & BOLT ACE	TATA spare parts
885441014018	ASSY. CROSS BS1/2/3/4	TATA spare parts
885441021618	SET OF CENTRE BEARING & CLAMPS	TATA spare parts
885441022515	FLANGE YOKE	TATA spare parts
885441022518	COMPANION FLANGE	TATA spare parts
885441032518	SLIP YOKE ASSY	TATA spare parts
885441042518	DUST CAP KIT	TATA spare parts
885441052518	JOINT NUT & BOLT 1618/2518	TATA spare parts
885441211612	KIT-UNIVERSAL JOINT BS1/2/3/4	TATA spare parts
885442010207	AXLE SET BRAKE LINING STD 207DI REAR	TATA spare parts
885442010407	AXLE SET BRAKE LINING PRIM & SEC ASB 9.	TATA spare parts
885442010709	AXLE SET BRAKE LINING STD 709 NON S CAM	TATA spare parts
885442010909	KIT-BRAKE LINING FRONT STD 909 BS2/3/4	TATA spare parts
885442010912	SET BRAKE LINING STD 912 W/RIVETS	TATA spare parts
885442011109	SET-BRK LINING STD W/RIVET NASB BS2/3/4	TATA spare parts
885442011210	KIT BRAKE LINING SINGLE WHEEL FRONT DAOH	TATA spare parts
885442011512	KIT-FRT BRK LINING STD (SET- 4) BS2/3/4	TATA spare parts
885442011613	WHEEL SET BRAKE LINING S CAM FR STD ASB	TATA spare parts
885442011616	WHEEL SET BRAKE LINING LPO1616 FR STD	TATA spare parts
885442011618	BRAKE LINING KIT(STD) 410X160NA1707 BS1-	TATA spare parts
885442011623	NGT Brake (Service KIT)	TATA spare parts
885442012518	KIT TORQUE PLATE	TATA spare parts
885442012530	6 MM DIA NYLON TUBE 25 M ROLL NOVUS	TATA spare parts

885442012829	KIT-FRONT BRAKE PAD FOR ACE	TATA spare parts
885442020207	AXLE SET BRAKE LINING R/S I 207DI REAR	TATA spare parts
885442020407	AXLE SET BRAKE LINING PRIM & SEC ASB 10	TATA spare parts
885442020709	AXLE SET BRAKE LINING RS1 709 NON S CAM	TATA spare parts
885442020909	AXLE SET BRAKE LINING R/S I 909 FRONT	TATA spare parts
885442021109	AXLE SET BRAKE LINING RS1 W/RIVETS NASB	TATA spare parts
885442021512	KIT-FRT BRK LINING OS1 (SET- 4) BS2/3/4	TATA spare parts
885442021613	WHEEL SET BRAKE LINING S CAM FR RS1 ASB	TATA spare parts
885442021616	WHEEL SET BRAKE LINING LPO1616 FR RSI	TATA spare parts
885442021618	BRAKE LINING KIT(STD)410X180NA1707 BS1-6	TATA spare parts
885442022530	8 MM DIA NYLON TUBE 25 M ROLL NOVUS	TATA spare parts
885442030207	AXLE SET BRAKE LINING R/S II 207DI REAR	TATA spare parts
885442030407	KIT BRAKE LININGS	TATA spare parts
885442030909	AXLE SET BRAKE LINING R/S II 909 FRONT	TATA spare parts
885442031109	AXLE SET BRAKE LINING RS2 W/RIVETS NASB	TATA spare parts
885442031512	SET FRT OS2 - 1512 4 LINERS	TATA spare parts
885442031616	WHEEL SET BRAKE LINING LPO1616 FR RSII	TATA spare parts
885442031618	BRAKE LINING KIT(OS1) 410X160NA1707 BS1-	TATA spare parts
885442032530	10 MM DIA NYLON TUBE 25 M ROLL NOVUS	TATA spare parts
885442040207	FRONT BRAKE PAD KIT FOR 207DI	TATA spare parts
885442040407	BRAKE LINING SET OF 4 F&R STD 407	TATA spare parts
885442040709	AXLE SET BRAKE LINING STD 709 S CAM ASB	TATA spare parts
885442040909	AXLE SET BRAKE LINING STD 909 REAR	TATA spare parts
885442041210	KIT BRAKE LINING SINGLE WHEEL REAR DAOH	TATA spare parts
885442041512	KIT-BRK LINING STD (SET- 4) 1512 BS2/3/4	TATA spare parts
885442041613	WHEEL SET BRAKE LINING S CAM RR STD ASB	TATA spare parts
885442041616	WHEEL SET BRAKE LINING LPO1616 REAR STD	TATA spare parts
885442041618	BRAKE LINING KIT(OS2) 410X160NA1707 BS1-	TATA spare parts
885442042530	12 MM DIA NYLON TUBE 25 M ROLL NOVUS	TATA spare parts
885442050207	KIT-LINED SHOE BS1/2/3/4	TATA spare parts
885442050407	BR LNG SET OF 4 F&R OS1 407	TATA spare parts
885442050709	AXLE SET BRAKE LINING RS1 709 S CAM ASB	TATA spare parts
885442050909	AXLE SET BRAKE LINING R/S I 909 REAR	TATA spare parts
885442051109	KIT-BRK LINING STD (SET- 4) 1109 BS2/3/4	TATA spare parts
885442051512	KIT-RR BRK LINING OS1 (SET- 4) BS2/3/4	TATA spare parts
885442051613	WHEEL SET BRAKE LINING S CAM RR RS1 ASB	TATA spare parts
885442051616	WHEEL SET BRAKE LINING LPO1616 REAR RSI	TATA spare parts
885442051618	BRAKE LINING KIT(OS1)410X180NA1707 BS1-6	TATA spare parts
885442052530	15 MM DIA NYLON TUBE 25 M ROLL NOVUS	TATA spare parts
885442060207	LINER KIT STD	TATA spare parts
885442060407	REPAIR KIT (MAJOR) FOR WHEEL CYLINDER (2	TATA spare parts
885442060909	AXLE SET BRAKE LINING R/S II 909 REAR	TATA spare parts
885442061109	KIT-BRK LINING OS1 (SET-4) 1109 BS2/3/4	TATA spare parts
885442061512	KIT-BRAKE LINING SET REAR OS2 BS2/3/4	TATA spare parts
885442061616	WHEEL SET BRAKE LINING LPO1616 REAR RSII	TATA spare parts
885442061618	BRAKE LINING KIT(OS2)410X180NA1707 BS1-6	TATA spare parts
885442062530	SET OF END CONNECTORS FOR 6MM DIA NYLON	TATA spare parts



885442070207	KIT - BLEED SCREW	TATA spare parts
885442070709	AXLE SET BRAKE LINING STD 709 S CAM N. A	TATA spare parts
885442070909	BRAKE LINING KIT(STD)325X140 NA1707BS2-4	TATA spare parts
885442071109	BR LNG SET of 4 OS2 1109	TATA spare parts
885442071618	KIT-BRAKE LINING REAR (WHEEL SET) + ALU.	TATA spare parts
885442072530	SET OF END CONNECTORS FOR 8MM DIA NYLON	TATA spare parts
885442080207	KIT SCREW & WASHER	TATA spare parts
885442080709	AXLE SET BRAKE LINING RS1 709 S CAM N. A	TATA spare parts
885442080909	BRAKE LINING KIT(OS1)325X140 NA1707BS2-4	TATA spare parts
885442081618	BRK LNG SET STD FR W/RVT 410X160CGT MB08	TATA spare parts
885442082530	SET OF END CONNECTORS FOR 10MM DIA NYLON	TATA spare parts
885442090207	KIT LEVER ASSY- LH	TATA spare parts
885442090709	AXLE SET BRAKE LINING STD709 HD ASB	TATA spare parts
885442090909	BRAKE LINING KIT(OS2)325X140 NA1707BS2-4	TATA spare parts
885442091613	SERVICE KIT FRONT BRAKE S CAM - B	TATA spare parts
885442091618	BRK LNG SET OS1 FR W/RVT 410X160CGT MB08	TATA spare parts
885442092530	SET OF END CONNECTORS FOR 12MM DIA NYLON	TATA spare parts
885442100207	KIT LEVER ASSY- RH	TATA spare parts
885442100407	BR LNG SET OF 4 FRT STD 407 E3&4	TATA spare parts
885442100709	AXLE SET BRAKE LINING RS1709 HD ASB	TATA spare parts
885442101613	SERVICE KIT REAR BRAKE S CAM - B	TATA spare parts
885442101618	BRK LNG SET OS2 FR W/RVT 410X160CGT MB08	TATA spare parts
885442102530	SET OF END CONNECTORS FOR 15MM DIA NYLON	TATA spare parts
885442110207	KIT LEVER PAWL- LH	TATA spare parts
885442110407	BRAKE LINING SET OF 4 STD RR 407 E3&4	TATA spare parts
885442110709	AXLE SET BRAKE LINING RS2 709 HD ASB	TATA spare parts
885442111109	BRK LNG SET OF 4 STD W/RVT 1109(360X140)	TATA spare parts
885442111613	SERVICE KIT FRONT BRAKE S CAM - A	TATA spare parts
885442111618	BRK LNG SET STD RR W/RVT 410X180CGT MB08	TATA spare parts
885442120207	KIT LEVER PAWL- RH	TATA spare parts
885442120407	REAR BRAKE LINING OS1(SET OF4)407BS3/BS4	TATA spare parts
885442120709	AXLE SET BRAKE LINING STD W/RIVETS NASB	TATA spare parts
885442121613	SERVICE KIT REAR BRAKE S CAM - A	TATA spare parts
885442121618	BRK LNG SET OS1 RR W/RVT 410X180CGT MB08	TATA spare parts
885442130207	KIT CALIPER WITH PISTON MAJOR	TATA spare parts
885442130407	BR LNG SET OF 4 OS2 RR 407 E3&4	TATA spare parts
885442130709	AXLE SET BRAKE LINING RS1 W/RIVETS NASB	TATA spare parts
885442130909	BRK LNG SET OF 4 STD W/RVT 909 (325X140)	TATA spare parts
885442131512	KIT-BRK LNG-SETOF4-FR STD-W/RVT-410X200N	TATA spare parts
885442131613	WHEEL SET BRAKE LINING S CAM FR STD N.	TATA spare parts
885442131618	BRK LNG SET OS2 RR W/RVT 410X180CGT MB08	TATA spare parts
885442140207	KIT CALIPER W/O PISTON	TATA spare parts
885442140407	ALUMINIUM RIVETS 407 (52 NOS)	TATA spare parts
885442140709	AXLE SET BRAKE LINING RS2 W/RIVETS NASB	TATA spare parts
885442141210	WHEEL SET BRAKE LINING STD FRONT ASB	TATA spare parts
885442141512	KIT-BRK LNG-SETOF4-RR STD-W/RVT-410X220N	TATA spare parts
885442141613	SET- BRAKE LINING S CAM FR RS1	TATA spare parts

885442141618	BRK LNG SET OF 4 STD FR W/RVT 410X160CGT	TATA spare parts
885442150207	KIT SLIDING PIN	TATA spare parts
885442150407	BR LNG SET OF 4 FRT OS1 407 E3&4	TATA spare parts
885442151210	WHEEL SET BRAKE LINING RS1 FRONT ASB	TATA spare parts
885442151613	WHEEL SET BRAKE LINING S CAM RR STD N.	TATA spare parts
885442160407	BR LNG SET OF 4 FRT OS2 407 E3&4	TATA spare parts
885442160709	BRAKE LINING KIT(STD)325X120NA1707 BS1-4	TATA spare parts
885442161210	WHEEL SET BRAKE LINING STD REAR ASB	TATA spare parts
885442161613	SET-WHEEL BRAKE LINING S CAM RR RS1? N.	TATA spare parts
885442170207	KIT FOR PAD	TATA spare parts
885442170407	BR LNG SET OF 4 F&R OS2 407	TATA spare parts
885442170709	BRAKE LINING KIT(OS1)325X120 NA1707BS1-4	TATA spare parts
885442171210	WHEEL SET BRAKE LINING RS1 REAR ASB	TATA spare parts
885442171613	REPAIR KIT FOR 261842300104	TATA spare parts
885442180407	BRK LNG SET OF 4 STD 407	TATA spare parts
885442180709	BRAKE LINING KIT(OS2)325X120NA1707 BS1-4	TATA spare parts
885442181210	WHEEL SET BRAKE LINING STD FRONT N. ASB	TATA spare parts
885442190407	BRK LNG SET OF 4 OS1 407	TATA spare parts
885442190709	BRASS RIVETS BRK LNG 24 NOS BS1/2/3/4/6	TATA spare parts
885442191210	WHEEL SET BRAKE LINING RS1 FRONT N. ASB	TATA spare parts
885442200407	BRK LNG SET OF 4 OS2 407	TATA spare parts
885442200709	ALUMINIUM RIVETS BRK LNG 24 NOS BS1- 4/6	TATA spare parts
885442201210	WHEEL SET BRAKE LINING STD REAR N. ASB	TATA spare parts
885442210407	BR LNG SET OF 4 STD M0	TATA spare parts
885442211210	WHEEL SET BRAKE LINING RS1 REAR N. ASB	TATA spare parts
885442212523	KIT-BRK LINING STD (SET OF 4) BS3/4	TATA spare parts
885442220407	BR LNG SET OF 4 OS1 M0	TATA spare parts
885442222523	KIT-BRAKE LINING OS1 (SET OF 4) BS2/3	TATA spare parts
885442230407	BR LNG SET OF 4 OS2 M0	TATA spare parts
885442232523	BR LNG SET OF 4 OS2 M0	TATA spare parts
885442240407	BRAKE LINING STD 407 BS1 & 2 (SET OF 4)	TATA spare parts
885442240709	BRK LNG SET OF 4 STD W/RVT 709 (325X120)	TATA spare parts
885442242523	BRK LNG SET OF 4 STD W/RVT (410X180)	TATA spare parts
885442250407	BRAKE LINING OS1 407 BS1 & 2 (SET OF 4)	TATA spare parts
885442260407	BRAKE LINING OS2 407 BS1 & 2 (SET OF 4)	TATA spare parts
885442270407	KIT-BRK LNG-SET OF 4-STD-W/RVT-407 BS1/2	TATA spare parts
885442280407	KIT-BRK LNG-SET OF 4-STD-W/RVT-407 BS3/4	TATA spare parts
885444011613	KIT HYD TIPPING W/APP MK2	TATA spare parts
885444012516	TIPPING KIT FOR GBS50 W/OUT PTO & APP	TATA spare parts
885444014018	U J KIT LPS4018/LPK2516_G600	TATA spare parts
885444021613	HYD T/KIT W/APP MK2 2 CYL	TATA spare parts
885444022516	TIPPING KIT FOR GBS50 WITH APP	TATA spare parts
885444031613	TANK FILTER	TATA spare parts
885444032516	TIPPING KIT FOR G600 W/OUT PTO & APP	TATA spare parts
885444041613	KIT SHIFTING LEVER M. C. VALVE & APP MKI	TATA spare parts
885444042516	TIPPING KIT FOR G600 WITH APP	TATA spare parts
885444052516	TIPPING KIT FOR G600 WITH APP 129 DIA	TATA spare parts

885444062516	TIPPING KIT FOR G600 W/OUT APP 129 DIA	TATA spare parts
885444072516	TIPPING KIT FOR G600 WITH APP 116 DIA	TATA spare parts
885444082516	TIPPING KIT FOR G600 W/OUT APP 116 DIA	TATA spare parts
885444092516	TIPPING KIT FOR G600 WITH APP 121 DIA	TATA spare parts
885444102516	TIPPING KIT FOR G600 W/OUT APP 121 DIA	TATA spare parts
885444202516	KIT-DDU REPAIR MAJOR BS1/2/3/4	TATA spare parts
885446010713	KIT FOR STEERING GEAR PUMP MOUNTING AND	TATA spare parts
885446051613	SET STEERING BUSH	TATA spare parts
885446230207	KIT FOR SPL TOOLS	TATA spare parts
885447011510	HPR KIT-FOR MODEL 2001	TATA spare parts
885447011623	HP FILTER KIT CNG	TATA spare parts
885447021510	HPR KIT-FOR MODEL 2002	TATA spare parts
885447031510	HPR KIT-FOR MODEL 2003	TATA spare parts
885447041510	UPGRADATION KIT 1510 CNG	TATA spare parts
885449011109	KIT EXHAUST BRAKE FOR 1109	TATA spare parts
885449011510	CONVERSION KIT EXH BRAKE 24 VOLTS	TATA spare parts
885449011613	CONVERSION KIT EXH BRAKE 12 VOLTS	TATA spare parts
88544950521	SPL 495 MARINE ENGINE	TATA spare parts
885450010207	207 DI RADIATOR HOSE KIT	TATA spare parts
885450010407	407 TURBO RADIATOR HOSE KIT	TATA spare parts
885450010709	SFC 709 E -S CAM RADIATOR HOSE KIT	TATA spare parts
885450010909	RAD HOSE KIT BSII LPT 909	TATA spare parts
885450011109	COMPLETE HOSE KIT LPT 1109/1112	TATA spare parts
885450011210	AL RADIATOR FOR 1612	TATA spare parts
885450011613	SE/SK 1613 TURBO & CMVR 2K RADIATOR HOSE	TATA spare parts
885450011623	COOLING HOSE KIT LPO1623 CNG DTC BUS	TATA spare parts
885450012515	LPT -2515C RADIATOR HOSE KIT	TATA spare parts
885450012516	LPK 2516 HYVA RADIATOR HOSE KIT	TATA spare parts
885450012789	RADIATOR HOSE KIT	TATA spare parts
885450012829	KIT-RADIATOR HOSE ACE /MAGIC	TATA spare parts
885450013516	RADIATOR HOSE KIT LPS 3516 EURO II/4018	TATA spare parts
885450020709	LP / LPT 709 RADIATOR HOSE KIT	TATA spare parts
885450021109	RADIATOR HOSE KIT BSII LPT 1109	TATA spare parts
885450021613	LPT 1613 TURBO RADIATOR HOSE KIT	TATA spare parts
885450022515	RADIATOR HOSE KIT LPT 2515 TCIC BSII	TATA spare parts
885450023516	RADIATOR HOSE KITS LPS 3516 BS I	TATA spare parts
885450031613	SE/ SK1613 C RADIATOR HOSE KIT	TATA spare parts
885450041613	LPT1613 C & LPT1613 C EX RADIATOR HOSE	TATA spare parts
885454000001	H/L BULB 100/90 12 V (P 43T FITMENT)	TATA spare parts
885454000002	H/L BULB 100/90 24 V (P 43T FITMENT)	TATA spare parts
885454000003	ASSY H/L PC RIM W/O BULB 12V RH	TATA spare parts
885454000004	ASSY H/L PC RIM W/O BULB 12V LH	TATA spare parts
885454000005	HEAD LAMP LH RHD 12 V W/O BULB	TATA spare parts
885454000006	HEAD LAMP RH RHD 12 V W/O BULB	TATA spare parts
885454000007	ASSY. ROUND HEAD LAMP	TATA spare parts
885454000008	ASSY HEAD LAMP LH W/O BULB (24 V)	TATA spare parts
885454000009	ASSY HEAD LAMP RH W/O BULB (24 V)	TATA spare parts

885454000010	ASSY. H/L W/O MOTOR-LH W/O BULB	TATA spare parts
885454000011	ASSY. H/L W/O MOTOR-RH W/O BULB	TATA spare parts
885454000012	ASSY H/L E-CER LH-RHD W/O BULB	TATA spare parts
885454000013	ASSY H/L E-CER RH-RHD W/O BULB	TATA spare parts
885454000014	ASSY HEAD LAMP LH W/O BULB	TATA spare parts
885454000015	ASSY HEAD LAMP RH W/O BULB	TATA spare parts
885454000016	HALO.HEAD LAMP LH RHD 12V W/O BULB	TATA spare parts
885454000017	HALO.HEAD LAMP RH RHD 12V W/O BULB	TATA spare parts
885454000018	ASSY H/L PC RIM W/O BULB 24V LH	TATA spare parts
885454000019	ASSY H/L PC RIM W/O BULB 24 V RH	TATA spare parts
885454000020	H/L BULB 100/90 12 V (P45T FITMENT)	TATA spare parts
885454000021	H/L BULB 100/90 24 V (P45T FITMENT)	TATA spare parts
885454012818	REPAIR KIT WIRING HARNESS ROUTING MINT	TATA spare parts
885454020407	H/L BULB 12 V P43T 100/90	TATA spare parts
885454030407	H/L BULB 24 V P43T 100/90	TATA spare parts
885458000001	BS6 NEW SPECIAL TOOLS KIT-SCV&BUS	TATA spare parts
885458000002	BS6 NEW SPECIAL TOOLS KIT-ILCV&BUS	TATA spare parts
885458000003	BS6 NEW SPECIAL TOOLS KIT-MHCV&BUS	TATA spare parts
885458000004	KIT- 9 SPECIAL TOOLS FOR GURU PROJECT	TATA spare parts
885458012515	SPECIAL TOOL KIT 352 Dia CLUTCH	TATA spare parts
885458012829	SPECIAL TOOL KIT ACE MAINTENANCE	TATA spare parts
885458012854	SPECIAL TOOL KIT WINGER MAINTENANCE	TATA spare parts
885458015507	SPECIAL TOOL KIT ULTRA MAINTENANCE	TATA spare parts
885458015517	KIT - ACE ZIP/IRIS REPAIR TOOLS	TATA spare parts
885458015538	KIT-SUPER ACE MINT 1.4L ENG REPAIR TOOLS	TATA spare parts
885458022829	SPECIAL TOOL KIT AGG OVERHAUL_ACE	TATA spare parts
885458022854	SPECIAL TOOL KIT AGG OVERHAUL_WINGER	TATA spare parts
885458025507	SPECIAL TOOL KIT AGG OVERHAUL_ULTRA	TATA spare parts
885458025517	KIT - ACE ZIP/IRIS OVERHAUL TOOLS	TATA spare parts
885458025538	KIT-SUPER ACE MINT 1.4L ENG O/H TOOLS	TATA spare parts
885458032829	KIT - ACE DICOR ENGINE REPAIR TOOLS	TATA spare parts
885458042829	KIT - ACE DICOR ENGINE OVERHAUL TOOLS	TATA spare parts
885460012518	Assy. Cabin with cowl With Blower	TATA spare parts
885460013718	Assy. Cabin with cowl Without Blower	TATA spare parts
885460015523	KIT CABIN GROMMETS ACE MEGA	TATA spare parts
885462014018	KIT-CAB REFURBISH FRONT FACIA 4018/2516	TATA spare parts
885465011618	ROOF REPAIR KIT	TATA spare parts
885465021618	KIT- BRTC ROOF REPAIR	TATA spare parts
885468015523	CABIN HEATING INSULATION KIT ACE MEGA	TATA spare parts
885468025523	CABIN HEATING INSULATION KIT ACE DICOR	TATA spare parts
885468035523	CABIN HEATING INSULATION KIT MAGIC MANTR	TATA spare parts
885472010407	LPT 407 LOCK KIT LH	TATA spare parts
885472011109	LOCK KIT 1109 LH	TATA spare parts
885472013516	DOOR REP KIT LPS3516/4018LPT2516 LH	TATA spare parts
885472020407	LPT 407 LOCK KIT RH	TATA spare parts
885472021109	LOCK KIT 1109 RLH	TATA spare parts
885472023516	DOOR REP KIT LPS3516/4018LPT2516 RH	TATA spare parts

885472030407	DOOR REP. KIT SFC 407/709 LH	TATA spare parts
885472033516	LOCK KIT LPS 4018/2516/3516 LH	TATA spare parts
885472040407	DOOR REP. KIT SFC 407/709 RH	TATA spare parts
885472043516	LOCK KIT LPS 4018/2516/3516 RH	TATA spare parts
885472050407	LOCK KIT SFC 407/709/909 LH	TATA spare parts
885472060407	LOCK KIT SFC 407/709/909 RH	TATA spare parts
885472070407	LOCK KIT LPT 407/709/909 LH	TATA spare parts
885472080407	LOCK KIT LPT 407/709/909 RH	TATA spare parts
885472090407	DOOR KIT RH	TATA spare parts
885472100407	DOOR KIT LH	TATA spare parts
885479012829	CANOPY COVER KIT FOR MAGIC VEHICLE	TATA spare parts
885479015517	CANOPY COVER KIT FOR IRIS VEHICLE	TATA spare parts
885481010407	BAZZLE KIT FOR LPT 407/709/909/1109	TATA spare parts
885481011109	ASSY FRONT GRILL KIT 1109 /909 /709	TATA spare parts
885481011613	TATA MASCOT KIT 1613/4018/4923	TATA spare parts
885481012829	WINDSCREEN ADHESIVE	TATA spare parts
885481012830	WINDSCREEN ADHESIVE KIT - SINGLE BOTTLE	TATA spare parts
885481013516	ASSY GRILLE COMPLETE LPS-3516	TATA spare parts
885481013518	ASSY GRILLE COMPLETE LPS-3518	TATA spare parts
885481014018	ASSY. GRILLE COMPLETE LPS-4018	TATA spare parts
885481014923	ASSY GRILLE COMPLETE LPS-4923	TATA spare parts
885481021109	ASSY DOOR CLADDING KIT 1109 /909 /709	TATA spare parts
885481024018	CAB MOUNTING BRACKET KIT OLD MODEL 4018	TATA spare parts
885481031109	ASSY FRONT GRILL KIT ( WIND SHIELD PANEL	TATA spare parts
885481034018	CAB MOUNTING BRACKET KIT NEW MODEL 4018	TATA spare parts
885485012698	KIT LUGGAGE CARRIER	TATA spare parts
885487012516	SUBFRAME ASSY FOR 12 CU M. SCOW	TATA spare parts
885487022516	PIVOT AND ATTACHMENT SET	TATA spare parts
885487032516	REAR HINGE BRACKET & BUSH ASSY LH	TATA spare parts
885487042516	REAR HINGE BRACKET & BUSH ASSY RH	TATA spare parts
885487052516	OIL TANK & CYL MOUNTING CRADLE ASSY	TATA spare parts
885488010407	Assy Grill Kit EX Model SFC 407	TATA spare parts
885488020407	Assy Grill Kit Non Ex Model SFC 407	TATA spare parts
885489000001	CAB MOUNTING KIT 207DI	TATA spare parts
885489000002	CAB MOUNTING KIT SFC 407/709	TATA spare parts
885489000003	CAB MOUNTING KIT LPT 1613/2515	TATA spare parts
885489000004	CAB MOUNTING KIT SE/SK 1613 TURBO CAB	TATA spare parts
885489000005	CAB MOUNTING KIT SE/SK 1613 COWL	TATA spare parts
885489000006	CAB MOUNTING KIT LPK 2516 CAB	TATA spare parts
885489000007	CAB MOUNTING KIT LPS 3516 CAB	TATA spare parts
885489000008	CAB MOUNTING KIT LPS 3516 COWL	TATA spare parts
885489011109	CAB MOUNTING KIT LPT 407 -1109	TATA spare parts
885489012898	XENON BODY FRONT MOUNTING KIT	TATA spare parts
885489014018	RUBBER MOUNTING KIT 2518 /4018	TATA spare parts
885489022898	XENON BODY REAR MOUNTING KIT	TATA spare parts
885499000001	FILTER KIT BSIV	TATA spare parts
885499000002	FILTER KIT BSIV XENON	TATA spare parts

885499000006	MHCV WITH CUMMINS ISBE 5.9 BS-IV AJINKYA	TATA spare parts
885499000007	MHCV WITH CUMMINS ISBE 5.9 BS-IV UMBRELL	TATA spare parts
885499000008	SERVICE KIT 30K ZIP BS4	TATA spare parts
885499000009	SERVICE KIT 40K ZIP BS4	TATA spare parts
885499011109	RADIATOR HOSE KIT - 1109 / 1112	TATA spare parts
885499011510	RADIATOR HOSE KIT - LPO 1510 697 BS II	TATA spare parts
885499011613	SERVICE KIT LPO 1613CNG BSIV-36000KM	TATA spare parts
885499012038	LPTA 2038 6X6 W/AUTO TRANSMISSION KIT	TATA spare parts
885499012516	KIT-PLUG EXPANSION 6BT CYL BLOCK BS3	TATA spare parts
885499012518	TC CONSTRUCK SERVICE KIT FOR 500 HRS	TATA spare parts
885499012534	EOK YODHA 4SPCR BS4	TATA spare parts
885499012663	FAST MOVING 25 PARTS KIT XENON 3LTR DICO	TATA spare parts
885499012898	SERVICE KIT SLV XENON YODHA FOR 60K	TATA spare parts
885499013118	HUB GREASING KIT FOR 12 WHEELS / 01 DRIV	TATA spare parts
885499013718	HUB GREASING KIT FOR 14 WHEELS / 01 DRIV	TATA spare parts
885499014018	TC TRUCK SERVICE KIT FOR 40000/400000KMS	TATA spare parts
885499021510	RADIATOR HOSE KIT - LP 1510 CNG BS II	TATA spare parts
885499021613	SERVICE KIT LPO 1613CNG BSIV-54000KM	TATA spare parts
885499022518	TC CONSTRUCK SERVICE KIT FOR 1000 HRS	TATA spare parts
885499022898	KIT-GASKET ENGINE OVERHAUL W/ CYLINDER H	TATA spare parts
885499023118	HUB GREASING KIT FOR 12 WHEELS / DOUBLE	TATA spare parts
885499024018	TC TRUCK SERV KIT 100K/160K/280K/340K KM	TATA spare parts
885499031613	SERVICE KIT LPO 1613CNG BSIV-72000KM	TATA spare parts
885499032518	TC CONSTRUCK SERVICE KIT 1500/4500 HRS	TATA spare parts
885499032818	1ST FREE SERVICE_10000KMS_SUPER ACE	TATA spare parts
885499032829	1ST FREE SERVICE_10000KMS_ACE	TATA spare parts
885499032854	1ST FREE SERVICE_10000KMS_WINGER	TATA spare parts
885499032898	KIT-DECARBONISING GASKET W/ CYLINDER HEA	TATA spare parts
885499034018	TC TRUCK SERVICE KIT FOR 220000KMS	TATA spare parts
885499035517	1ST FREE SERVICE_10000KMS_ZIP	TATA spare parts
885499041014	KIT 20K/60K/100K/140K/180K 9.6 ULTRA PMP	TATA spare parts
885499041512	RADIATOR HOSE KIT - LP 1512 TC BS-II	TATA spare parts
885499041613	SERVICE KIT LPO 1613CNG BSIV-9000 KM	TATA spare parts
885499042518	TC CONSTRUCK SERVICE KIT 2000/5000 HRS	TATA spare parts
885499042818	2ND FREE SERVICE_20000KMS_SUPER ACE	TATA spare parts
885499042829	2ND FREE SERVICE_20000KMS_ACE	TATA spare parts
885499042854	2ND FREE SERVICE_20000KMS_WINGER	TATA spare parts
885499045517	2ND FREE SERVICE_20000KMS_ZIP	TATA spare parts
885499050207	1ST FREE SERVICE_15000KMS_207EX	TATA spare parts
885499051014	KIT 40K/120K 9.6 ULTRA PMPML	TATA spare parts
885499051613	SERVICE KIT LPO 1613CNG BSIV-18000 KM	TATA spare parts
885499052518	TC CONSTRUCK SERVICE KIT 2500/3500 HRS	TATA spare parts
885499052818	3RD FREE SERVICE_30000KMS_SUPER ACE	TATA spare parts
885499052829	3RD FREE SERVICE_30000KMS_ACE	TATA spare parts
885499052854	3RD FREE SERVICE_45000KMS_WINGER	TATA spare parts
885499055517	3RD FREE SERVICE_30000KMS_ZIP	TATA spare parts
885499060207	2ND FREE SERVICE_20000KMS_207EX	TATA spare parts

885499061014	KIT 80K/160K/320K 9.6 ULTRA PMPML	TATA spare parts
885499061613	697 CONSTRUCK SERVICE KIT FOR 500 HRS	TATA spare parts
885499062518	TC CONSTRUCK SERVICE KIT FOR 3000 HRS	TATA spare parts
885499062818	4TH FREE SERVICE_40000KMS_SUPER ACE	TATA spare parts
885499062829	4TH FREE SERVICE_40000KMS_ ACE	TATA spare parts
885499062854	4TH FREE SERVICE_ WINGER	TATA spare parts
885499065517	4TH FREE SERVICE_40000KMS_ZIP	TATA spare parts
885499070207	3RD FREE SERVICE_30000KMS_207EX	TATA spare parts
885499071613	697 CONSTRUCK SERVICE KIT FOR 1000 HRS	TATA spare parts
885499072518	TC CONSTRUCK SERVICE KIT FOR 4000 HRS	TATA spare parts
885499072818	OIL AND FUEL FILTER KIT AUPER ACE	TATA spare parts
885499072829	OIL AND FUEL FILTER KIT ACE	TATA spare parts
885499072854	OIL AND FUEL FILTER KIT WINGER	TATA spare parts
885499075517	KIT-OIL AND FUEL FILTER ZIP	TATA spare parts
885499080207	4TH FREE SERVICE_40000KMS_207EX	TATA spare parts
885499081613	697 CONSTRUCK SERVICE KIT 1500/4500 HRS	TATA spare parts
885499082818	SERVICE KIT 40K SUPER ACE	TATA spare parts
885499082829	SERVICE KIT 40K ACE BS3	TATA spare parts
885499082854	SERVICE KIT 40K WINGER BS3	TATA spare parts
885499084018	RADIATOR HOSE KIT - 2515 /4018 /3516 TC	TATA spare parts
885499085517	SET OF 3 KIT ZIP	TATA spare parts
885499090207	1ST FREE SERVICE_15000KMS_207RX	TATA spare parts
885499091613	697 CONSTRUCK SERVICE KIT 2000/5000 HRS	TATA spare parts
885499092818	KIT-OIL & FUEL FILTER ELEMENTS (SPR ACE)	TATA spare parts
885499092829	KIT-OIL & FUEL FILTER ELEMENTS (ACE)	TATA spare parts
885499094018	Long Life Hub Greasing Kit 1613/4018	TATA spare parts
885499095517	SERVICE KIT 40K ZIP BS3	TATA spare parts
885499100207	2ND FREE SERVICE_30000KMS_207RX	TATA spare parts
885499101613	697 CONSTRUCK SERVICE KIT 2500/3500 HRS	TATA spare parts
885499102818	TIMING SYSTEM KIT - SUPER ACE	TATA spare parts
885499102829	KIT-OIL & FUEL FILTER ELEMENTS (ACE)	TATA spare parts
885499104018	HUB GREASING KIT FOR 06 WHEEL / SINGLE A	TATA spare parts
885499110207	3RD FREE SERVICE_45000_207RX	TATA spare parts
885499111613	697 CONSTRUCK SERVICE KIT FOR 3000 HRS	TATA spare parts
885499112518	SERVICE KIT M&HCV BS4 40/100/160/220K	TATA spare parts
885499120207	OIL AND FUEL FILTER KIT XENON	TATA spare parts
885499121613	697 CONSTRUCK SERVICE KIT FOR 4000 HRS	TATA spare parts
885499122518	SERVICE KIT 697 CONST FOR 4000 HRS	TATA spare parts
885499130207	SET OF 3 KIT XENON/ 207	TATA spare parts
885499131613	697 TRUCK SERVICE KIT 40K/160K/280K KMS	TATA spare parts
885499132518	SERVICE KIT M&HCV 40/200K EX BS4	TATA spare parts
885499140207	SERVICE KIT 40K 207EX /XENON BS3	TATA spare parts
885499141613	697 TRUCK SERVICE KIT 80K/120K/200K KMS	TATA spare parts
885499142518	SERVICE KIT M&HCV BS4 120/280K EXT	TATA spare parts
885499151613	697 TRUCK SERVICE KIT FOR 240K KMS	TATA spare parts
885499152518	SERVICE KIT TC CONST FOR 500 HRS	TATA spare parts
885499162518	SERV KIT TC TRUCK 100K/160K/280K/340K KM	TATA spare parts

885499172518	SERVICE KIT TC CONST 1500/4500 HRS	TATA spare parts
885499182518	SERVICE KIT TC CONST 2000/5000 HRS	TATA spare parts
885499192518	SERVICE KIT 697 CONST FOR 500 HRS	TATA spare parts
885499202518	SERVICE KIT TC CONST FOR 3000 HRS	TATA spare parts
885499211613	RADIATOR HOSE KIT - SE/SK 1613	TATA spare parts
885499212518	SERVICE KIT 697 CONST FOR 1000 HRS	TATA spare parts
885499221613	RADIATOR HOSE KIT - LPT 1613 697 BS II	TATA spare parts
885499222518	SERVICE KIT TC CONST FOR 1000 HRS	TATA spare parts
885499231613	KIT 20K / 60K / 110K / 140K LPO1613CNG P	TATA spare parts
885499232518	SERVICE KIT 697 CONST 2000/5000 HRS	TATA spare parts
885499241613	KIT 40K / 120K LPO1613CNG PMPML	TATA spare parts
885499242518	SERVICE KIT 697 CONST FOR 3000 HRS	TATA spare parts
885499251613	KIT 80K / 160K / 320K LPO1613CNG PMPML	TATA spare parts
885499252518	SERVICE KIT 697 TRUCK 80K/120K/200K KMS	TATA spare parts
885499261613	KIT 20K 60K 100K 140K 180K 220K 260K 300	TATA spare parts
885499262518	HUB GREASING KIT FOR 10 WHEEL / DOUBLE A	TATA spare parts
885499271613	KIT 40K 120K 200K 280K LPO1613CNG PMPML	TATA spare parts
885499272518	HUB GREASING KIT FOR 10 WHEEL / 01 DRIVE	TATA spare parts
885499281613	KIT 80K 160K 240K 320K LPO1613CNG PMPML	TATA spare parts
885499311613	KIT 180K LPO1613CNG PMPML	TATA spare parts
8854CONF2010	SAMPLE DISPLAY MATERIAL	TATA spare parts
8854CR102547	CON ROD BRG SET 0.010	TATA spare parts
8854CR202547	SET CON.ROD BRG.SHELL HALF REPII	TATA spare parts
8854GREASE00	GREASE PACK 200 GMS	TATA spare parts
8854GREASE01	GREASE PACK 1 KG	TATA spare parts
8854GREASE03	GREASE PACK 3 KG	TATA spare parts
8854GREASE05	GREASE PACK 5 KG	TATA spare parts
8854GREASE07	GREASE PACK 7 KG	TATA spare parts
8854GREASE82	GREASE DRUM 182 KG	TATA spare parts
885515400002	GLOW PLUG KIT INDICA	TATA spare parts
885525340002	SET CL DISC+PR PLATE 207DI	TATA spare parts
885526540002	1Set CL PR PLATE & CL DISC 228 dia	TATA spare parts
885526580001	SHAFT SEAL FOR IMPORTED PUMP	TATA spare parts
885526780008	SCUFF PLATE KIT-INDICA	TATA spare parts
885526990002	SPARE WHEEL COVER - SILVER - SAFARI	TATA spare parts
885526990008	TRACK LOCK KIT	TATA spare parts
885527020006	KIT CL/PR PLATE INDICA(CPL+CDISC+RELBRG)	TATA spare parts
885527020040	Strut Spring Compressor Set	TATA spare parts
885527900002	SET MAIN BEARING	TATA spare parts
885527900006	VALVE KIT VENTURE(INLET & EXHAUST)	TATA spare parts
885527900135N	FILTER PACK INDICA NA BSIII Ser. 10K/20K	TATA spare parts
885528010006	ASM OUTPUT SHAFT	TATA spare parts
885528180001	KIT VENTURE DEFLECTOR RETROFIT	TATA spare parts
885528180104	VENTURE ENGINE OVERHAULING KIT	TATA spare parts
885528180105	BARE ENGINE VENTURE	TATA spare parts
885528340027	Assy Compressor Kit.	TATA spare parts
885532020003	KIT FT SUSP (FRONT SHOCK) MODIFIED	TATA spare parts



885532020004	FRT SUSPENSION KIT 20 D A.R.BAR	TATA spare parts
885532020005	FRT SUSPENSION KIT 24 D A.R.BAR	TATA spare parts
885532020027	KIT RR SUSP (REAR SHOCK)	TATA spare parts
88553740561	DOUBLE CAB 4X2/4X4 CREW	TATA spare parts
885543020001	TANDEM MASTER CYL	TATA spare parts
885546010001	OUTER BALL JT	TATA spare parts
885554010003	MOTOR H/L LEVELING	TATA spare parts
885554010024	FUSE BOX FRAME CABIN	TATA spare parts
885554010030	FUSE 40AMP	TATA spare parts
885558020002	KIT SPL TOOLS G76/G16/TR.CASE	TATA spare parts
885558020003	KIT SPLTOOLS SUSP/PROPSH/RRAXLE	TATA spare parts
885582020001	WIPING KIT W/O MOTOR SAFA	TATA spare parts
885582020030	PLASTIC TUBE KIT DLX	TATA spare parts
885582020033	FILLER NECK WITH FLEXI PI	TATA spare parts
885583010024	PRESSURE SWITCH DLE	TATA spare parts
885588020001	LINER FRT WHEEL HOUSE (WITH EXTN)RH DLX	TATA spare parts
885588020026	FUEL FILL CUP WITH HINGE	TATA spare parts
885591010031	RECLINER COVER OUTBOARD LH	TATA spare parts
885591010032	RECLINER COVER INBOARD LH	TATA spare parts
885599020007	MOD FRT GRILL W/SURR MEL. GREEN NLS	TATA spare parts
885599020021	FRT GRILL W/SURR P.BLUE	TATA spare parts
8855WORK0083	Trans E Lift	TATA spare parts
8855WORK0086	Set of Insulated Tools EV (Nexon)	TATA spare parts
8855WORK0087	Insulated Torque Wrench	TATA spare parts
8855WORK0088	Add-on kit Insulated Tools	TATA spare parts
885610000055	Wooden Crate 41 x12.75 x32.25 inch	TATA spare parts
885610120101	Single Parts Plain 10" x 12"	TATA spare parts
885610120202	Two Part Plain 10" x 12"	TATA spare parts
885610120411	Blue Invoice	TATA spare parts
885611741001	SC 7ply 330x320x320 mm	TATA spare parts
885611741002	SH. CARTON GB30 36 X33 X28 CM 7 PLY	TATA spare parts
885611741003	SH. CARTON GB40 41 X 37 X 29 CM 7 PLY	TATA spare parts
885611741004	SH. CARTON CL. HSG 52 X 34 X27 CM 7 PLY	TATA spare parts
885612541025	SH. CARTON RADIATOR	TATA spare parts
885612541031	SH.CARTON FOR RADIATOR 278650100247	TATA spare parts
885612741003	SH. CARTON C.BONNET 407	TATA spare parts
885612741004	SH. CARTON AXLE SHAFT	TATA spare parts
885612741005	SH. CARTON PROP. SHAFT	TATA spare parts
885612741007	SH CARTON D.BOARD-LCV	TATA spare parts
885612741009	SHIP.CARTON DASH BOARD 407	TATA spare parts
885612741031	BRAKE DRUM CARTON 48X48X24 (BIG)CM 7 PLY	TATA spare parts
885612741032	SH. CARTON BR DRUM 365 DIA 37X37X29 CM 7	TATA spare parts
885612741033	SH. CARTON BRAKE DRUM LCV	TATA spare parts
885613741002	SH.CARTON PR PLT CWP BIG415X415X125 7PLY	TATA spare parts
885613741003	SH. CARTON PR PLATE 285*285*85	TATA spare parts
885613741004	SC FOR PR.PLATE 370 DIA	TATA spare parts
885613741007	CRANK SHAFT CARTON	TATA spare parts

885614541006	S C CENTRE GRILL	TATA spare parts
885614541007	SHIP CARTON 12 X 8 X 6	TATA spare parts
885614541008	SH. 16*12*8 INCH (41*31*21)	TATA spare parts
885614541009	SC 6/CASE CUMM.AIR FILTER	TATA spare parts
885614541010	SHIP CART. 6"X6"X6"	TATA spare parts
885614541012	CARTON FAN 517 DIA 520X520X50 MM 5 PLY	TATA spare parts
885614541013	SH. CARTON 20X14X9	TATA spare parts
885614541014	SH. CARTON 31X12X9	TATA spare parts
885614541016	SHIP CARTON DIFFERENTIAL	TATA spare parts
885614541033	SHIPCART 5P405L405W125H 250/28 150/18	TATA spare parts
885614541035	SH. CARTON FAN ENGINE	TATA spare parts
885614541072	GLS-2220x230x1190-INSERTS 2+2	TATA spare parts
885614543038	SC 5 Ply 800x600x400mm	TATA spare parts
885614543039	SC 5 Ply 600x400x400mm	TATA spare parts
885614543040	SC 5 Ply 400x300x200mm	TATA spare parts
885614543064	GLS-1240x230x1025-INSERTS 2+2	TATA spare parts
885614543065	GLS-2375x230x1020-INSERTS 2+2	TATA spare parts
885614543066	GLS-1545x230x970-INSERTS 2+2	TATA spare parts
885614543067	GLS-1720x230x820- INSERTS 2+2	TATA spare parts
885614543068	GLS-2060x230x1190-INSERTS 2+2	TATA spare parts
885614543069	GLS-1600x230x1100-INSERTS 2+2	TATA spare parts
885614543070	GLS-2390x230x1465-INSERTS 2+2	TATA spare parts
885614543071	GLS-2035x230x990-INSERTS 2+2	TATA spare parts
885614543073	GLS-2555x230x1605- INSERTS 2+2	TATA spare parts
885614543140	SC 5 Ply 600x400x200mm	TATA spare parts
885614543141	SC 5 Ply 300x200x200mm	TATA spare parts
885614543142	SC 5 Ply 800x300x200mm	TATA spare parts
885614543143	SC 5 Ply 150x100x100mm	TATA spare parts
885614543233	SC 5 ply 1420 x 260 x 830 With Fitments	TATA spare parts
885614543234	SC 5 ply 1585 x 260 x 860 With Fitments	TATA spare parts
885614543272	GLS-1545x230x970- Without Fitments	TATA spare parts
885614543273	GLS-1600x230x1100- Without Fitments	TATA spare parts
885614543283	SC 5 Ply 150x150x150mm	TATA spare parts
885614543341N	GLS-1240X230X1025-Without Fitments	TATA spare parts
885614543342N	GLS-2375X230X1020-Without Fitments	TATA spare parts
885614543343N	GLS-1720X230X820-Without Fitments	TATA spare parts
885614543344N	GLS-2060X230X1190-Without Fitments	TATA spare parts
885614543345N	GLS-2390X230X1465-Without Fitments	TATA spare parts
885614543346N	GLS-2035X230X990-Without Fitments	TATA spare parts
885614543347N	GLS-2555X230X1605-Without Fitments	TATA spare parts
885614741004	SH. CARTON 16X12X8	TATA spare parts
885614741005	SH. CARTON 20X14X9	TATA spare parts
885614741006	SH. CARTON 31X12X9	TATA spare parts
885614741010	SC 7ply 525x430x345 mm	TATA spare parts
885614741011	SHIP CARTON AIR FILTER	TATA spare parts
885614741014	SHIP CARTON CENTRE GRILL	TATA spare parts
885614741028	DRIVE SHAFT CARTON680X240X240 MM 7PLY	TATA spare parts

885614741029	MAIN SHAFT CARTON 540X260X130MM 7PLY	TATA spare parts
885614743026	SC 7 Ply 600x400x200mm	TATA spare parts
885614743028	SC 7 Ply 300x200x200mm	TATA spare parts
885621310001	UNIT CARTON 50X30X110	TATA spare parts
885621310002	UNIT CARTON 50X30X125	TATA spare parts
885621310003	UNIT CARTON 50X50X125	TATA spare parts
885621310004	UNIT CARTON 75X30X75	TATA spare parts
885621310005	PRINTEDCRTON 3PLY*75X50X90MMH ID NO 005	TATA spare parts
885621310006	PRINTEDCARTON3PLY 80X40X80MMH ID NO 006	TATA spare parts
885621310007	UNIT CARTON 85X85X120	TATA spare parts
885621310008	PRINTEDCARTON3PLY*95X45X95MMH ID NO 007	TATA spare parts
885621310009	UNIT CARETON 530X60X60 5 PLY	TATA spare parts
885621310010	UNIT CARTON 100X100X180	TATA spare parts
885621310011	PRINTEDCARTON3PLY*105X30X105MMH IDNO 0	TATA spare parts
885621310019	UNIT CARTON 60X60X530 5 PLY	TATA spare parts
885621310020	UNIT CARTON 150X55X150 5 PLY	TATA spare parts
885621310021	UNIT CARTON 155x155x25 5 PLY	TATA spare parts
885621310022	PRTDG/WCARTON3PLY 100X45X100MMH IDNO 0	TATA spare parts
885621310023	PRTDG/WCARTON3PLY 110X70X110MMH IDNO 0	TATA spare parts
885621310024	PRTDG/WCARTON3PLY 115X40X115MMH IDNO 0	TATA spare parts
885621310025	PRTDG/WCARTON3PLY 120X60X120MMH IDNO 0	TATA spare parts
885621310026	PRTDG/WCARTON3PLY 120X70X120MMH IDNO 0	TATA spare parts
885621310027	PRTDG/WCARTON3PLY 125X35X125MMH IDNO 0	TATA spare parts
885621310028	PRTDG/WCARTON3PLY 135X50X135MMH IDNO 0	TATA spare parts
885621310029	PRTDG/WCARTON3PLY 135X60X135MMH IDNO 0	TATA spare parts
885621310030	PRTDG/WCARTON3PLY 135X80X135MMH IDNO 0	TATA spare parts
885621310031	PRTDG/WCARTON3PLY 140X50X140MMH IDNO 0	TATA spare parts
885621350009	UNIT CARTON 55X55X155 VARNISHED	TATA spare parts
885621350013	UNIT CARTON 80 X 40 X 80 VARNISHED	TATA spare parts
885621350016	UNIT CARTON 85 X 85 X 120 VARNISHED	TATA spare parts
885621350018	UNIT CARTON 95 X 45 X 95 VARNISHED	TATA spare parts
885621350024	UNIT CARTON 105 X 55 X 105 VARNISHED	TATA spare parts
885621350032	UNIT CARTON 150X55X150 VARNISHED	TATA spare parts
885621350094	UC 135 X 135 X 385 VARNISHED FOR 9911 AI	TATA spare parts
885621350095	UC 175 X 175 X 360 VARNISHED FOR 2527091	TATA spare parts
885621350106	UC - FILTER 252509130117	TATA spare parts
885621350227	UC 90x90x90	TATA spare parts
885621350228	UC 90x90x164	TATA spare parts
885621350229	UC 110x110x230	TATA spare parts
885621350358N	UC 3 PLY 120X115X102 mm	TATA spare parts
885621510004	UNIT CARTON 045X045X410	TATA spare parts
885621510005	UNIT CARTON 050X050X100	TATA spare parts
885621510015	UNIT CARTON 120X070X120	TATA spare parts
885621510017	UNIT CARTON 125X125X370 VARNISHED	TATA spare parts
885621510018	CARTON CON ROD	TATA spare parts
885621510021	UNIT CARTON 135X060X135	TATA spare parts
885621510022	UNIT CARTON 135X090X135	TATA spare parts

885621510024	PRINTEDCARTON5PLY*145X75X145MMH IDNO 0	TATA spare parts
885621510029	PRINTEDWCARTON5PLY*155X110X155MMH ID 0	TATA spare parts
885621510030	PRINTEDCARTON5PLY150X110X260MMH IDNO 0	TATA spare parts
885621510031	UNIT CARTON 155X145X165	TATA spare parts
885621510032	UNIT CARTON 160X070X125	TATA spare parts
885621510033	PRINTEDCARTON5PLY170X50X170MMH IDNO 04	TATA spare parts
885621510034	PRINTEDCARTON5PLY*170X100X170MMH ID 042	TATA spare parts
885621510035	UNIT CARTON 230X050X680	TATA spare parts
885621510037	UNIT CARTON 235X235X445	TATA spare parts
885621510038	UNIT CARTON 290X065X290	TATA spare parts
885621510039	UNIT CARTON 295X065X295	TATA spare parts
885621510040	UNIT CARTON PISTON SET-6/SET W/O PIN	TATA spare parts
885621510041	UNIT CARTON 320X050X320	TATA spare parts
885621510042	UNIT CARTON 350X040X550	TATA spare parts
885621510043	UNIT CARTON 455X020X455	TATA spare parts
885621510044	UNIT CARTON 165X80X165	TATA spare parts
885621510046	UNIT CARTON 260X60X445	TATA spare parts
885621510048	UNIT CARTON 210X210X390	TATA spare parts
885621510049	UNIT CARTON 215X040X755	TATA spare parts
885621510050	UNIT CARTON 225X40X465	TATA spare parts
885621510051	UNIT CARTON 230X230X230	TATA spare parts
885621510052	UNIT CARTON 200X100X350	TATA spare parts
885621510053	UC CL.DISC 280X45X280	TATA spare parts
885621510055	UNIT CARTON 320X220X150-GREEN 12X8X6	TATA spare parts
885621510056	UNIT CARTON 350X55X350	TATA spare parts
885621510057	UC FOR PR.LINE SET-470X100X275	TATA spare parts
885621510061	PRTDG/WCARTON5PLY105X40X370MMH IDNO 0	TATA spare parts
885621510062	PRTDG/WCARTON5PLY120X90X150MMH IDNO 0	TATA spare parts
885621510063	PRTDG/WCARTON5PLY125X55X125MMH IDNO 0	TATA spare parts
885621510064	PRTDG/WCARTON5PLY125X85X125MMH IDNO 0	TATA spare parts
885621510065	PRTDG/WCARTON5PLY130X50X130MMH IDNO 0	TATA spare parts
885621510067	PRTDG/WCARTON5PLY140X75X170MMH IDNO 0	TATA spare parts
885621510068	PRTDG/WCARTON5PLY140X140X150MMH IDNO	TATA spare parts
885621510070	PRTDG/WCARTON5PLY155X65X155MMH IDNO 0	TATA spare parts
885621510071	PRTDG/WCARTON5PLY160X30X160MMH IDNO 0	TATA spare parts
885621510073	PRTDG/WCARTON5PLY170X170X80MMH IDNO 0	TATA spare parts
885621550001	UNIT CARTON 45X45X410 VARNISHED	TATA spare parts
885621550010	UNIT CARTON 130 X 45 X 330 VARNISHED	TATA spare parts
885621550013	UNIT CARTON 135 X 90 X 135 VARNISHED	TATA spare parts
885621550022	UNIT CARTON 160 X 160 X 160 VARNISHED	TATA spare parts
885621550023	UNIT CARTON 165X80X165 VARNISHED	TATA spare parts
885621550024	UNIT CARTON 170 X 50 X 170 VARNISHED	TATA spare parts
885621550040	UC 709 BR LINERS 255 X 155 X 125 VARNISH	TATA spare parts
885621550043	UNIT CARTON 295 X 65 X 295 VARNISHED	TATA spare parts
885621550045	UNIT CARTON 320 X 50 X 320 VARNISHED	TATA spare parts
885621550048	UNIT CARTON 350 X 55 X 350 VARNISHED	TATA spare parts
885621550083	UNIT CARTON 245 X 45 X 245 VARNISHED	TATA spare parts

885621550096	UC Headlamp 365x175x245mm	TATA spare parts
885621550105	UC280 x 240 x 125 VARNI for Turbo Filter	TATA spare parts
885621550172	Sp UC 380x220x140 inbuilt Partition	TATA spare parts
885621710001	UNIT CARTON 062X062X465	TATA spare parts
885621710003	UNIT CARTON 070X070X770	TATA spare parts
885621710004	PRINTEDCARTON7PLY*75X75X395MMH ID NO 04	TATA spare parts
885621710006	PRINTEDCARTON7PLY*80X80X455MMH IDNO 04	TATA spare parts
885621710009	UNIT CARTON85X85X340 7 PLY	TATA spare parts
885621710010	UNIT CARTON 100X100X270	TATA spare parts
885621710011	PRINTEDCARTON7PLY100X100X410MMH IDNO 0	TATA spare parts
885621710014	PRINTEDCARTON7PLY*115X115X340MMH ID 056	TATA spare parts
885621710016	PRINTEDCARTON7PLY140X140X190MMH IDNO 0	TATA spare parts
885621710017	PRINTEDCARTON7PLYX160X160X160MMH ID 067	TATA spare parts
885621710018	UNIT CARTON 160X160X470	TATA spare parts
885621710019	PRTDG/WCARTON7PLY*165X80X165MMH IDNO	TATA spare parts
885621710020	PRINTEDCARTON7PLY190X55X190MMH IDNO 07	TATA spare parts
885621710021	PRINTEDCARTON7PLY200X90X200MMH ID NO 07	TATA spare parts
885621710022	PRINTEDCARTON7PLY*200X175X340MMH ID 076	TATA spare parts
885621710023	PRINTEDCARTON7PLY*225X50X225MMH ID077	TATA spare parts
885621710024	PRINTEDCARTON7PLY*230X230X360MMH ID 079	TATA spare parts
885621710025	PRINTEDCARTON7PLY*250X140X450MMH ID 081	TATA spare parts
885621710026	UNIT CARTON 260X120X375	TATA spare parts
885621710027	PRINTEDCARTON7PLY*300X115X300MMH ID 083	TATA spare parts
885621710028	PRINTEDCARTON7PLY*380X50X380MMH ID 084	TATA spare parts
885621710030	UNIT CARTON 080X080X520	TATA spare parts
885621750019	UNIT CARTON 200X090X200 VARNISHED	TATA spare parts
885621750032	UC 160 X 160 X 125 VARNISHED	TATA spare parts
885621750036	U/CARTON 135 X 135 X 115 VARNISHED	TATA spare parts
885631400001	LDP BAGS 4 X 6	TATA spare parts
885631400002	LDP BAGS 6 X 9	TATA spare parts
885631400003	LDP BAG 6 X 12	TATA spare parts
885631400004	LDP BAGS 9 X 12	TATA spare parts
885631400005	LDP BAGS 9 X 15	TATA spare parts
885631400006	LDP BAGS 12 X 15	TATA spare parts
885631400007	LDP BAGS 15 X 22	TATA spare parts
885632201001	LDP ROLE 44 WIDE 200G	TATA spare parts
885632401001	LDP ROLE 44 WIDE 400G	TATA spare parts
885633150001	POUCH - HOLOGRAPHIC MET PET 100 X 100	TATA spare parts
885633150002	POUCH - HOLOGRAPHIC MET PET 150 X 150	TATA spare parts
885633150003	POUCH - HOLOGRAPHIC MET PET 190 X 190	TATA spare parts
885633150004	POUCH - HOLOGRAPHIC MET PET 250 X 250	TATA spare parts
885633350004	PP BAG 4IN.X6IN. GREY-BLUE	TATA spare parts
885633350005	PP BAG 6IN.X9IN. GREY-BLUE	TATA spare parts
885633350006	PP BAG 6IN.X20IN.GREY-BLUE	TATA spare parts
885633350007	PP BAG 9IN.X15IN. GREY-BLUE	TATA spare parts
885633350008	PP BAG 15IN.X22IN. GREY-BLUE	TATA spare parts
885633350009	PP BAG 15IN.X37IN. GREY-BLUE	TATA spare parts

885633350010	PP BAG 18IN.X28IN. GREY-BLUE	TATA spare parts
885633350011	PP BAG 18IN.X37IN. GREY-BLUE	TATA spare parts
885633350014	PB BAG 6IN.X28IN. GREY-BLUE	TATA spare parts
885633350016	PP BAG 9IN.X37IN. GREY-BLUE	TATA spare parts
885633350017	PP BAG 12IN.X15IN. GREY-BLUE	TATA spare parts
885633350018	PP BAG 12IN.X18IN. GREY-BLUE	TATA spare parts
885633350020	Roll Stretch film 29mic x20	TATA spare parts
885633350030	ROLL HDPE/ 3I Bubble laminate Printed	TATA spare parts
885633350031	SELF SEAL POUCH 4INX6IN-LDPE 75MICRON	TATA spare parts
885633350032	SELF SEAL POUCH 6INX9IN-LDPE 75MICRON	TATA spare parts
885633350033	SELF SEAL POUCH 6INX20IN-LDPE 75MICRON	TATA spare parts
885633350034	SELF SEAL POUCH 6INX28IN-LDPE 75MICRON	TATA spare parts
885633350036	SELF SEAL POUCH 9INX15IN-LDPE 75MICRON	TATA spare parts
885633350037	SELF SEAL POUCH 9INX37IN-LDPE 75MICRON	TATA spare parts
885633350039	SELF SEAL POUCH 12INX18IN-LDPE 75MICRON	TATA spare parts
885633350040	SELF SEAL POUCH 15INX22In-LDPE 75MICRON	TATA spare parts
885633350042	SELF SEAL POUCH 18INX28IN-LDPE 75MICRON	TATA spare parts
885633350043	SELF SEAL POUCH 18INX37IN-LDPE 75MICRON	TATA spare parts
885633350047	SELF SEAL POUCH 10INX10IN-LDPE 75MICRON	TATA spare parts
885633350057N	Stretch Film Roll 51 Mic-500mmX210mtr	TATA spare parts
885633353003	HOLOGRAM STCIKER 3D AS APPROVED (SPOOL)	TATA spare parts
885633410001	PP BAG 4 X 4 GREEN / WHIT	TATA spare parts
885633410002	PP BAGS 4 X 6 GREEN / WHI	TATA spare parts
885633410003	PP BAGS 6 X 9 GREEN / WHI	TATA spare parts
885633410004	PP BAGS 6 X 20 GREEN / WH	TATA spare parts
885633410005	PP BAGS 9 X 15 GREEN / WH	TATA spare parts
885633410006	PP BAGS 15 X 22 GREEN / W	TATA spare parts
885633410007	PP BAG 15 X 37 GREEN / WH	TATA spare parts
885633410008	PP BAG 18 X 28 GREEN / WH	TATA spare parts
885633410009	PP BAG 18 X 37 GREEN / WH	TATA spare parts
885633410010	PP BAGS 6INCHINCHX 6INCHINCH	TATA spare parts
885633410011	PP BAG 6 X 24 GREEN	TATA spare parts
885633410012	PP BAGS 6 X 28 GREEN	TATA spare parts
885633410013	PP BAGS 6 X 37	TATA spare parts
885633410014	PP BAGS 9INCHINCH X 37INCHINCH	TATA spare parts
885633410015	PP BAG 12 X 15 GREEN	TATA spare parts
885633410016	PP BAG 12 X 18 GREEN	TATA spare parts
885634410001	PP ROLL GREEN/WHITE 4INCH	TATA spare parts
885634410002	PP ROLL 6 INCHINCH GREEN/WHITEINCH	TATA spare parts
885634410003	PP ROLL GREEN/WHITE 9	TATA spare parts
885655173161	Seat Cover Front Set Black Red Iris	TATA spare parts
885690001001	BOPP Transparent Tape 36mm X 65mtr	TATA spare parts
885690001002	PRIN BOPP TAPE 48 X 65	TATA spare parts
885690001003	PRINT Bopp Tape 72mm X 65mtr	TATA spare parts
885690001004	Bituminised Hess/Roll 44w x 90M 10 OUNCE	TATA spare parts
885690001005	PRINTED PP STRAP 15MMX1KM	TATA spare parts
885690001007	AIR BUB PL ROLL 10MM 350G	TATA spare parts

885690001013	POUCHES OF SHEET-SIZE 5X5	TATA spare parts
885690001017	RECYCLED JUNGLE/RUB WOOD	TATA spare parts
885690001019	NEW JUNGLE/RUBBER WOOD	TATA spare parts
885690001020	SILVER OAK WOOD	TATA spare parts
885690001022	HOLOGRAM 3D AS APPROVED	TATA spare parts
885690001091	GLASS PACKING FOAM BUFFER	TATA spare parts
885690001092	PROFILE U SECTION	TATA spare parts
885690002001	WM Material ID label (4INCHX1INCH)	TATA spare parts
885690002002	WM UMRP label (4INCHX2INCH)	TATA spare parts
885690002003	WM Shipping label (4INCHX6INCH)	TATA spare parts
885690002010	Pre-printed Acknowledgement slip - 9.5X1	TATA spare parts
885690002013	Look for Laser Mark Sticker	TATA spare parts
885690002018	Glass Handle with care Sticker	TATA spare parts
885690002019	VOR Sticker	TATA spare parts
885690002021	Piston Ring sticker	TATA spare parts
885690002027	AIR BUB PL ROLL 10MM 400G-Kg	TATA spare parts
885690003020	Plastic Container 519mm dia x160mm h(Rou	TATA spare parts
885690003048	WM Ribbon(Resin) - 110mmX300mtr	TATA spare parts
885690003060	Plastic security tamper evident Seals	TATA spare parts
885690003061	Plastic container 460x460x80mm Flywheel	TATA spare parts
885690003065	Plastic Container 546x105x53mm (Shafts)	TATA spare parts
885690003066	PP Plastic Carton 425x425x200mm	TATA spare parts
885690003067	PP Plastic Carton 385x385x100mm	TATA spare parts
885690003073	NEW AIR IB FILM ROLL 12 INCH X 10 INCH	TATA spare parts
885690003075	Plastic Container 776x64mm (Cam Shafts)	TATA spare parts
885690003088	Plastic Container 420x420x55mm Clutch di	TATA spare parts
885690003090	Plastic Container 165x165x30mm for Synch	TATA spare parts
885690003440	Virgin PP strap 2000mx12mmx0.6mm	TATA spare parts
885690003479	Plastic Clip Support	TATA spare parts
885690003480	PRINT Bopp Tape 60mm X 65mtr	TATA spare parts
885690003481	WM UMRP label (3INCHX2INCH)	TATA spare parts
885690003484	Holographic MRP Label 82mmX50mm	TATA spare parts
885690003487	Universal Paper 2 Ply Roll-1 mtrX100 mtr	TATA spare parts
885690003489N	Saf-T-Lockout Tags-White Spl. Grade PVC	TATA spare parts
885690003491N	Holographic IB MRP Label 106mmX50mm	TATA spare parts
885690009001	HDPE COVER FOR 407	TATA spare parts
885690009002	HDPE COVER FOR 709	TATA spare parts
885690009003	HDPE COVER FOR LP 1612/1613 TC	TATA spare parts
885690009004	HDPE COVER FOR LP 1616/2416	TATA spare parts
885690009005	HDPE COVER FOR LP 1616SHOW	TATA spare parts
885701000147	HD UNIT 1DIN MECHLESS USB/SD/BT PLAYER	TATA spare parts
885701000152	TOKYO 110 MECHALESS WITH USB UNIT	TATA spare parts
885701210104	PURE COAXIAL 66.2 CAR SPEAKER	TATA spare parts
885701220127	Speaker _Coaxial GTX 542 / BGX 542 5"	TATA spare parts
885701220134	RIO De Jenario 110 BT	TATA spare parts
885701220138	SPEAKER CONNECTOR CABLE FOR LPT1	TATA spare parts
885701500126	AVN RADIO BRACKET - LEFT-INSTALLTION KIT	TATA spare parts

885701500127	AVN RADIO BRACKET -RIGHT-INSTALLTION KIT	TATA spare parts
885701500128	AVN RADIO BRACKET -TRIM RING	TATA spare parts
885701520109	5.25INCH 2-WAY FULL-RANGE SPEAKER	TATA spare parts
885701520112	POWER & SPEAKER CONNECTOR FOR SUPER ACE	TATA spare parts
885701520113	POWER & SPEAKER CONNECTOR FOR XENON XLT	TATA spare parts
885701530102	BRISBANE 230 BT -ANTENNA	TATA spare parts
885704000031	POWER WINDOW 2DR-front Zest	TATA spare parts
885704000032	Power Window Zest 4 Door	TATA spare parts
885704000033	Reverse camera with TFT display	TATA spare parts
885704000034	Vehicle Tracking Device	TATA spare parts
885707312794	TMA kit	TATA spare parts
885709501688	Mobile Holder Bergmann automatic	TATA spare parts
885712103006	FLOOR MAT - UNIVERSAL set of 4	TATA spare parts
885722101604	ROLL BAR SPRINT	TATA spare parts
885722101605	Roof Rack Xenon	TATA spare parts
885722101607	Hood Defelctor Xenon	TATA spare parts
885722101608	Door Visor Xenon	TATA spare parts
885722101609	Rear Bumper Xenon	TATA spare parts
885722101610	CANOPY XENON DBC PRIMER	TATA spare parts
885722101611	Boot Lid Xenon	TATA spare parts
885722101612	Scuff Plate Xenon	TATA spare parts
885722101614	REAR NUDGE GUARD BKT.XENON	TATA spare parts
885722101615	SIDE STEP MTG.BKT.XENON W/BUSH	TATA spare parts
885722101616	Bracket Canopy Xenon	TATA spare parts
885722101617	Body Cladding Xenon	TATA spare parts
885722101620	Rubber foam for Xenon Canopy	TATA spare parts
885722101623	Front Guard Prosport Xenon	TATA spare parts
885722101626	Luggage Carrier Xenon	TATA spare parts
885732000554	Seatcover A/L Tiago Spl Edtn Fixed HD	TATA spare parts
885732001520	Tiago PRO Kit	TATA spare parts
885732002727	Wheel Cover 13" Dual Color	TATA spare parts
885732002959	Silver Heavy Matty Safari Bodycover	TATA spare parts
885732002987	CAR MULTIMEDIA SERIES 370	TATA spare parts
885732011653	Tigor PRO Kit	TATA spare parts
885732300783	SEATCOVER VISTA JADE BEIGE REAR SEAT PLA	TATA spare parts
885752100684	Nexon PRO Kit	TATA spare parts
885752101660	Fog lamp Bezel garnish white (Nexon)	TATA spare parts
885773002605	GUARD FULL	TATA spare parts
885773002715	Bracket for Storme Fog Lamps	TATA spare parts
885773201527	Car Wireless Charger AC vent type	TATA spare parts
885773201528	Car Wireless Charger Suction Cup&AC vent	TATA spare parts
885776332602	Side Step Xenon W/Brkt	TATA spare parts
885776332603	Aluminium Side Step for Xenon	TATA spare parts
885792101521	BCP Xenon	TATA spare parts
885793001801	BEDLINER XENON	TATA spare parts
885793101502	FULL FLOOR MATTING- VINYL- BLACK	TATA spare parts
885794101501	Carpet Aria Black santos	TATA spare parts



885794101528	Carpet Floor Mat Hexa 6pc (AT)	TATA spare parts
885795101540	TPMS (App) Tyre sensors	TATA spare parts
885795101570	LED puddle lamp T logo	TATA spare parts
885795101589	Harrier Dark Edition Chrome Kit	TATA spare parts
885795101590	Harrier PRO Kit	TATA spare parts
885796312607	Roof rack complete set with tray 95x150	TATA spare parts
885797342601	Door Visor Xenon	TATA spare parts
885859004700	MICROLIS TELEMATIC PIGTAIL 281654641674	TATA spare parts
885859004701	KIT-TELEMATICS	TATA spare parts
885859004702	SKOOLMAN TELEMATICS KIT	TATA spare parts
886004000002	Security System TKE Nano 4A 2180	TATA spare parts
886032300308	Seat Cover A/L Nano Blk & Bedge	TATA spare parts
886300000001	COVER BS6	TATA spare parts
886300000002	PIPE BS6	TATA spare parts
886300000003	EXHAUST PIPE ( S.S.CORUGATE HOSE) BS6	TATA spare parts
886300000004	EXHAUST SILENSOR WITH CLAMP BS6	TATA spare parts
886300000005	V BELT - A 54 BS6	TATA spare parts
886300000006	LOW PRESSURE TEXTILE BREADED HOSE BS6	TATA spare parts
886300000007	EXHAUST PIPE CLAMP BS6	TATA spare parts
886300000008	PLATE BS6	TATA spare parts
886300000009	ADAPTOR M38 X 1.5P (F) (COMMON FOR ALL	TATA spare parts
886300000010	ADAPTOR M12X1.75 (M) BS6	TATA spare parts
886300000011	LOW PRESSURE FUEL HOSE BS6	TATA spare parts
886300000012	COPPER WASHER M14 BS6	TATA spare parts
886300000013	FUEL SUCTION ADAPTOR BS6	TATA spare parts
886300000014	COPPER WASHER M38 BS6	TATA spare parts
886300000015	SS WORM CLAMP 3INCH BS6	TATA spare parts
886300000016	COPPER WASHER BS6	TATA spare parts
886300000017	ADAPTOR BS6	TATA spare parts
886300000018	ENGINE COVER BS6	TATA spare parts
886300000019	ENGINE COVER SUPPORT BS6	TATA spare parts
886300000020	NUT-M8 BS6	TATA spare parts
886300000021	WASHER BS6	TATA spare parts
886300000022	WASHER BS6	TATA spare parts
886300000023	FUEL GAUGE SENSOR 105MM	TATA spare parts
886300000024	FUEL GAUGE SENSOR 120MM	TATA spare parts
886300000025	FUEL GAUGE SENSOR 153MM	TATA spare parts
886300000026	AUTOMATIC VOLTAGE REGULATOR AVR AS540	TATA spare parts
886300000027	AUTOMATIC VOLTAGE REGULATOR AVR AS440	TATA spare parts
886300000028	S TYPE HOSE RADIATOR TO THERMOSTAT - 4SP	TATA spare parts
886300000029	RADIATOR TOP HOSE FOR TATA 20KVA- 4SP	TATA spare parts
886300000030	B-399 HOSE THERMOSTAT TO ENGINE TOP - 4S	TATA spare parts
886300000031	DSL HOSE PIPE RUBR BLK 10MM 5FT 19X19 BE	TATA spare parts
886300000032	DSL HOSE PIPE RUBR BLK 10MM 5FT 19XPLAIN	TATA spare parts
886300000033	ACOUSTIC DOOR LOCKS - ALL DG	TATA spare parts
886300000034	ACOUSTIC DOOR HINGES - ALL DG	TATA spare parts
886300000035	EMERGENCY STOP BUTTON - ALL DG	TATA spare parts

886300000036	FUEL FILLING CAP - ALL DG	TATA spare parts
886300000037	SILENCER BELLOW 2350 RT 20-40KVA	TATA spare parts
886300000038	SILENCER BELLOW 3200 RT 82.5-125 KVA	TATA spare parts
886300000039	SILENCER BELLOW 2700 RT	TATA spare parts
886300000040	SILENCER BELLOW 2500 RT	TATA spare parts
886300000041	SLNC GKT OD ID PCD 125 50 100MM 4HOL 3MM	TATA spare parts
886300000042	SLNC GKT OD ID PCD 150 80 125MM 4HOL 3MM	TATA spare parts
886300000043	FUEL FILLING NECK W/ LOCK - ALL DG	TATA spare parts
886300000044	ACOUSTIC DOOR BIDDING (BILLED IN MTR)-AL	TATA spare parts
886300000045	FRPU FOAM 32 DENSITY SHEET 2MX1M & 50MM	TATA spare parts
886300000046	GENSET STARTING RELAY CARD	TATA spare parts
886300000047	GENSET CONTROLLER EASY GEN 1400	TATA spare parts
886300000048	MCB 25A 3 POLE ABB	TATA spare parts
886300000049	MCB 32A 3 POLE ABB	TATA spare parts
886300000050	MCB 40A 3 POLE ABB	TATA spare parts
886300000051	MCB 63A 3 POLE ABB	TATA spare parts
886300000052	MCB 25A 3 POLE SCHNEIDER	TATA spare parts
886300000053	MCB 32A 3 POLE SCHNEIDER	TATA spare parts
886300000054	MCB 40A 3 POLE SCHNEIDER	TATA spare parts
886300000055	MCB 63A 3 POLE SCHNEIDER	TATA spare parts
886300000056	MCCB 100A 3 POLE SCHNEIDER	TATA spare parts
886300000057	MCCB 125A 3 POLE SCHNEIDER	TATA spare parts
886300000058	MCCB 160A 3 POLE SCHNEIDER	TATA spare parts
886300000059	MCCB 200A 3 POLE SCHNEIDER	TATA spare parts
886300000060	MCCB 100A 3 POLE ABB	TATA spare parts
886300000061	MCCB 125A 3 POLE ABB	TATA spare parts
886300000062	MCCB 160A 3 POLE ABB	TATA spare parts
886300000063	MCCB 200A 3 POLE ABB	TATA spare parts
886300000064	CT 100A	TATA spare parts
886300000065	CT 150A	TATA spare parts
886300000066	CT 200A	TATA spare parts
886300000067	CONNECTION STRIP UPTO 100 A	TATA spare parts
886300000068	CONNECTION STRIP ABOVE 100A	TATA spare parts
886300000069	OEN RELAY KT684/1A/1C/12V	TATA spare parts
886300000070	WIRING HARNESS 497SPTC	TATA spare parts
886300000071	WIRING HARNESS 497TC	TATA spare parts
886300000072	WIRING HARNESS 697TC	TATA spare parts
886300000073	WIRING HARNESS 697TC10	TATA spare parts
886300000074	POWER HARNESS 15 KVA 1P	TATA spare parts
886300000075	POWER HARNESS 15 KVA 3P	TATA spare parts
886300000076	POWER HARNESS 20 KVA 1P	TATA spare parts
886300000077	POWER HARNESS 20 KVA 3P	TATA spare parts
886300000078	POWER HARNESS 25 KVA 1P	TATA spare parts
886300000079	POWER HARNESS 25 KVA 3P	TATA spare parts
886300000080	POWER HARNESS 30 KVA 1P	TATA spare parts
886300000081	POWER HARNESS 30 KVA 3P	TATA spare parts
886300000082	POWER HARNESS 40 KVA 1P	TATA spare parts

88630000083	POWER HARNESS 40 KVA 3P	TATA spare parts
88630000084	POWER HARNESS 62.5 KVA 1P	TATA spare parts
88630000085	POWER HARNESS 62.5 KVA 3P	TATA spare parts
88630000086	POWER HARNESS 82.5 KVA1P	TATA spare parts
88630000087	POWER HARNESS 82.5 KVA 3P	TATA spare parts
88630000088	POWER HARNESS 100 KVA 1P	TATA spare parts
88630000089	POWER HARNESS 100 KVA 3P	TATA spare parts
88630000090	POWER HARNESS 125 KVA 1P	TATA spare parts
88630000091	POWER HARNESS 125 KVA 3P	TATA spare parts
88630000092	FLEXIBLE HOSE	TATA spare parts
88630000093	ELASTIC COUPLIN	TATA spare parts
886301000002	ENGINE HEAD GASKET 2518 BS3	TATA spare parts
886301000003	2518 FULL GASKET KIT BSII	TATA spare parts
886301000004	2518 UPPER GASKET KIT BSII	TATA spare parts
886301000005	2518 LOWER GASKET KIT BSII	TATA spare parts
886301000006	2518 FULL GASKET KIT BSII W/O STEM SEAL	TATA spare parts
886301000007	2518 UPPER GASKET KIT BSII W/O STEM SEAL	TATA spare parts
886301000008	2518 FULL GASKET KIT BSIII	TATA spare parts
886301000009	2518 UPPER GASKET KIT BSIII	TATA spare parts
886301000010	2518 LOWER GASKET KIT BSIII	TATA spare parts
886301000011	2518 FULL GASKET KIT BSIII W/O STEM SEAL	TATA spare parts
886301000012	2518 UPPER GASKET KIT BSIII W/O STEM SEA	TATA spare parts
886301000014	O RING BS6	TATA spare parts
886301000015	CYLINDER HEAD GASKET	TATA spare parts
886301000016	GASKET CYLINDER HEAD	TATA spare parts
886301000017	ASSY. CAM ACTUATORE OVER FLOW NUT(BOOST	TATA spare parts
886301000018	CAM ACTUATOR WITH SENSOR (SUPER ACE)	TATA spare parts
886301000019	KIT EXESS PISTON ACE	TATA spare parts
886301000020	DISTRIBUTOR HEAD DELPHI TVS	TATA spare parts
886301000021	DISTRIBUTOR HEAD (SUPER ACE)	TATA spare parts
886301000022	ASSY. INJECTOR WITH SENSOR (SUPER ACE)	TATA spare parts
886301000023	ASSY. INJECTOR ACE /SUPER ACE	TATA spare parts
886301000024	PUMP HOUSING (S.ACE)	TATA spare parts
886301012786	CYLINDER LINER COLLARED(RS1)(6BT-BS2/BS3	TATA spare parts
886301022786	CYLINDER LINER COLLARED(RS2)(6BT-BS2/BS3	TATA spare parts
886301032786	CYLINDER LINER COLLARED(RS3)(6BT-BS2/BS3	TATA spare parts
886301042786	CYLINDER LINER COLLARED(RS4)(6BT-BS2/BS3	TATA spare parts
886301950001	LONG BLOCK FOR 215 BS III MECH	TATA spare parts
886301950002	LONG BLOCK FOR ENG G6BT5.9 HELIOS 230HP	TATA spare parts
886303000002	KIT-PISTON SET TC 6BT BS-3	TATA spare parts
886303000003	PISTON RING ACE BSIII	TATA spare parts
886303000004	VALVE SET 2518 BS2 STD	TATA spare parts
886303000005	VALVE SET 2518 BS2 RS1 3THOU	TATA spare parts
886303000006	VALVE SET 2518 BS2 RS2 5THOU	TATA spare parts
886303000007	VALVE SET 2518 BS2 RS3 10THOU	TATA spare parts
886303000008	VALVE SET 2518 BS2 RS4 15THOU	TATA spare parts
886303000009	VALVE SET 2518 BS2 RS5 20THOU	TATA spare parts

886303000010	VALVE SET W/SEAT 2518 BS2 STD	TATA spare parts
886303000011	VALVE SET W/SEAT 2518 BS2 RS1 3THOU	TATA spare parts
886303000012	VALVE SET W/SEAT 2518 BS2 RS2 5THOU	TATA spare parts
886303000013	VALVE SET W/SEAT 2518 BS2 RS3 10THOU	TATA spare parts
886303000014	VALVE SET W/SEAT 2518 BS2 RS4 15THOU	TATA spare parts
886303000015	VALVE SET W/SEAT 2518 BS2 RS5 20THOU	TATA spare parts
886303000016	VALVE SET 2518 BS3 STD	TATA spare parts
886303000017	VALVE SET 2518 BS3 RS1 3THOU	TATA spare parts
886303000018	VALVE SET 2518 BS3 RS2 5THOU	TATA spare parts
886303000019	VALVE SET 2518 BS3 RS3 10THOU	TATA spare parts
886303000020	VALVE SET W/SEAT BS3 2518 STD	TATA spare parts
886303000021	VALVE SET W/SEAT BS3 2518 RS1 3THOU	TATA spare parts
886303000022	VALVE SET W/SEAT BS3 2518 RS2 5THOU	TATA spare parts
886303000023	VALVE SET W/SEAT BS3 2518 RS3 10THOU	TATA spare parts
886303000024	VALVE SET STD ACE BS2/3	TATA spare parts
886303000025	VALVE SET WITH SEAT ACE BSII/III STD	TATA spare parts
886303000026	Flywheel 2518 CI (138 Teeth)	TATA spare parts
886303000027	LPR KIT ACE DURAFIT	TATA spare parts
886303012786	PISTON RING SET STD 2518 BS3	TATA spare parts
886303015717	ASSY. CONNECTING ROD BS2/3/4	TATA spare parts
886303950001	KIT FOR 180 HP ENGINE(NEW RECIPE)	TATA spare parts
886305000001	SCREW HEX FLANGE HEAD CAP BS6	TATA spare parts
886305000002	VALVE CAMSHAFT-SPLIT TYPE	TATA spare parts
886305000003	TIMING BELT	TATA spare parts
886305950001	GASKET VALVE COVER	TATA spare parts
886305950002	GASKET TURBOCHARGER	TATA spare parts
886307000001	PIN	TATA spare parts
886307000002	FUEL PUMP KEY	TATA spare parts
886307000003	FUEL INJECTION PUMP (BSIII EXCHANGE)	TATA spare parts
886307000006	"WASHER, SEALING"	TATA spare parts
886307000007	"SCREW, BANJO CONNECTOR"	TATA spare parts
886307000008	HP PUMP METERING UNIT ISBE5.9 BS3/4	TATA spare parts
886307012786	INLINE FIP KIT - CUMMINS ENGINE	TATA spare parts
886307012788	NOZZEL ACE	TATA spare parts
886307022788	SERVICE KIT ACE/SUPER ACE	TATA spare parts
886307032788	LINER TUSTER PUMP DELPHI	TATA spare parts
886307042788	TRANSFER PUMP BLADE (STEEL)	TATA spare parts
886307052788	DISTRIBUTOR HEAD DELPHI TVS	TATA spare parts
886307062788	ROLLER SHOW KIT WITH PLATE ACE	TATA spare parts
886307072788	M VALVE ACE	TATA spare parts
886307082788	CAM RING ACE	TATA spare parts
886307990001	CONNECTOR QUICK CONNECT BS6	TATA spare parts
886308000001	ACE HT COMMON CATALOGUE	TATA spare parts
886309000001	TEST EQUIPMENT KIT	TATA spare parts
886309000002	MINOR KIT - SUPER ACE	TATA spare parts
886309000003	MAJOR KIT - SUPER ACE	TATA spare parts
886309000004	MINOR KIT - ACE BS2	TATA spare parts

886309000005	MINOR KIT - ACE BS3	TATA spare parts
886309000006	MINOR KIT - ACE BS4	TATA spare parts
886309000007	MAJOR KIT ACE BS2	TATA spare parts
886309000008	MAJOR KIT - ACE BS3 & BS4	TATA spare parts
886309000009	MAJOR KIT - ACE BS2	TATA spare parts
886309000010	MAJOR KIT - ACE BS3	TATA spare parts
886309000011	MAJOR KIT - ACE BS4	TATA spare parts
886309000012	FUEL FILTER ELEMENT	TATA spare parts
886309000013	OIL FILTER-ZIP	TATA spare parts
886309000014	FUEL FILTER	TATA spare parts
886309000015	GASKET CYL.HEAD-2518	TATA spare parts
886309000016	SET CYL LINER COLLARED 2518	TATA spare parts
886309000017	SET PISTON RING STD 2518 BS2	TATA spare parts
886309000018	SET CYL LINER 697 OS 0.5 MM	TATA spare parts
886309000019	SET CYL LINER 697 OS 1.0 MM	TATA spare parts
886309000020	FLYWHEEL - 2518	TATA spare parts
886309000021	TIMING BELT - ACE	TATA spare parts
886309000022	OILSEAL INNER 109RR METALCASING	TATA spare parts
886309000023	OILSEAL OUTER 109RR METALCASING	TATA spare parts
886309000024	SET CYL LINER 497 OS 0.5 MM	TATA spare parts
886309000025	SET CYL LINER 497 OS 1.0 MM	TATA spare parts
886309000026	FUEL FILTER ELEMENT	TATA spare parts
886309000027	SECONDARY FUEL FILTER - AIR CONDITIONING	TATA spare parts
886309000028	FILTER ELEMENT - AIR CONDITIONING & REFR	TATA spare parts
886309000029	PIGTAIL ASSY	TATA spare parts
886309000030	FUEL FILTER 0.5 L CLOTH (9451037404)	TATA spare parts
886309000031	FUEL FILTER 0.5 L STAR (9451037405)	TATA spare parts
886309000032	FUEL FILTER 1.1 L CLOTH (1457431003)	TATA spare parts
886309000033	FUEL PAPER 1.1 L STAR (9451037406)	TATA spare parts
886309000034	FUEL FILTER 1.1 L COIL (9451037409)	TATA spare parts
886309000035	CARTRIDGE - (277046609901)	TATA spare parts
886309000036	AIR BREATHER FILTER (275144169901)	TATA spare parts
886309000037	RLF ELEMENT(275144159901)	TATA spare parts
886309000038	HAND PRIMER FUEL FILTER(ACE)	TATA spare parts
886309000039	DRAIN PLUG(WATER) BS6	TATA spare parts
886309000040	FILTER COVER BS6	TATA spare parts
886309000041	STRAIGHT BANJO BS6	TATA spare parts
886309000042	PRE FILTER FUEL	TATA spare parts
886309000119	FUEL FILTER ELEMENT & SEALS BS2/3/4	TATA spare parts
886311000001	OIL SUCTION FILTER CORE	TATA spare parts
886311000002	FILTER UNIT ES074 THX150A	TATA spare parts
886313000001	TOOTHED GEAR	TATA spare parts
886313000002	BUSH-RUBBER	TATA spare parts
886313000003	CONNECTING ROD BS6	TATA spare parts
886313000004	ADAPTOR	TATA spare parts
886313000005	ADAPTOR	TATA spare parts
886313000006	CYLINDER ASSEMBLY	TATA spare parts

88631300007	CYLINDER HEAD BS6	TATA spare parts
88631300008	BEARING	TATA spare parts
88631300009	BEARING ID 60 X 40 L	TATA spare parts
88631300010	COMPLETE WING COMPRESSOR 603 RR	TATA spare parts
88631300011	ADAPTOR	TATA spare parts
88631300012	CONNECTING ROD BOLT	TATA spare parts
88631400001	CHRA KIT	TATA spare parts
88631400002	MODULE DOC INLET BS6 (5.6/6.7/V)	TATA spare parts
88631400003	MODULE DOC INLET BS6 (6.7/F)	TATA spare parts
88631400004	MODULE DPF CATALYST BS6 (6.7/F)	TATA spare parts
88631400005	MODULE SCR OUTLET BS6 (6.7/F)	TATA spare parts
88631400006	DP SENSOR INLET LINE ASSY VR/HZ/FLX BS6	TATA spare parts
88631400007	WIRING HARNESS ASSY - HORIZONTAL BS6	TATA spare parts
88631400008	WIRING HARNESS EGP BS6	TATA spare parts
886314015737	BRACKET SENSOR SUPPORT ((5.6/6.7/F) BS6	TATA spare parts
886314025737	BRACKET SENSOR SUPPORT ((5.6/6.7/F) BS6	TATA spare parts
886314035737	BRACKET SENSOR SUPPORT ((5.6/6.7/F) BS6	TATA spare parts
886314950001	TURBOCHARGER	TATA spare parts
886314990001	AFTER TREATMENT SYSTEM ASSY BS6 (5.6/H)	TATA spare parts
886314990002	AFTER TREATMENT SYSTEM ASSY BS6 (6.7/H)	TATA spare parts
886314990003	AFTER TREATMENT SYSTEM ASSY BS6 (6.7/V)	TATA spare parts
886314990004	AFTER TREATMENT SYSTEM ASSY BS6 (6.7/V)	TATA spare parts
886314990005	AFTER TREATMENT SYSTEM ASSY BS6 (5.6/H)	TATA spare parts
886314990006	TUBE PRESSURE SENSING BS6	TATA spare parts
886314990007	BRACE BRACKET BS6	TATA spare parts
886314990008	DEF FILTER CARTRIDGE BS6	TATA spare parts
886315000001	SOLENOID SWITCH ASSEMBLY	TATA spare parts
886315000028	FASTENER KIT	TATA spare parts
886315000029	ALTERNATOR BELT XENON 2.2L EURO2 AMB	TATA spare parts
886315000030	SERVICE KIT FOR EGT ASSEMBLY BS6	TATA spare parts
886315000031	SERVICE KIT FOR STARTER MOTOR BS6	TATA spare parts
886315000039	ALTERNATOR 1 PHASE 10 KVA	TATA spare parts
886315000040	ALTERNATOR 3 PHASE 70 KVA	TATA spare parts
886315000052	ALTERNATOR BS6	TATA spare parts
886315000053	SWITCH PRESSURE	TATA spare parts
886318000001	OIL FILTER - AIR CONDITIONING & REFRIGER	TATA spare parts
886318000004	STRAINER (DN40)	TATA spare parts
886318000005	LUBE OIL FILTER ELEMENT BS6	TATA spare parts
886318000006	PLATE COVER	TATA spare parts
886320000001	WATER PUMP 2518-EUROII	TATA spare parts
886320000002	WATER PUMP 2518-E3	TATA spare parts
886320000005	WATER PUMP	TATA spare parts
886320000006	BLACK RUBBER HOSE-WATER PUMP SIDE	TATA spare parts
886320000007	BLACK RUBBER HOSE- WATER PUMP END SIDE	TATA spare parts
886320000008	V-BELT	TATA spare parts
886320000009	BLACK RUBBER HOSE - WATER FILLING SIDE	TATA spare parts
886320000010	ASSY FAN ENGINE BS6	TATA spare parts

88632000011	BELT V RIBBED BS6	TATA spare parts
88632000012	CLUTCH FAN	TATA spare parts
88632000013	CLUTCH FAN	TATA spare parts
88632000014	FAN ENGINE BS6	TATA spare parts
886320012829	ASSY. WATER PUMP TATA ACE/ MAGIC	TATA spare parts
886323011613	DIAGNOSTIC TOOL FOR BS3/BS4	TATA spare parts
886324000001	ENGINE MOUNTING ACE REAR	TATA spare parts
886324000002	ENGINE MOUNTING ACE FRONT	TATA spare parts
886324000003	ASSY ENGINE MOUNTING B	TATA spare parts
886324000004	ASSY ENGINE MOUNTING C	TATA spare parts
886324000005	ASSY ENGINE MOUNT D	TATA spare parts
886325000014	CLUTCH SET ASSY. 352 DIA. W/O RBA	TATA spare parts
886325000015	DIA 25MM HST	TATA spare parts
886325000016	DIA 35MM HST	TATA spare parts
886325000105	ASSY.352DIA.DRIVEN DISC & COVER ASY	TATA spare parts
886325003118	ASSY.380 DIA.DRIVEN DISC & COVER ASSY	TATA spare parts
886325010001	CLUTCH DISC 352 DIA(1.75 SPLINE)E3	TATA spare parts
886325010001AE	352 DIA.CL.DISC ASSY.(1.75 SPLINE)	TATA spare parts
886325010002	CLUTCH COVER 352 DIA. E3	TATA spare parts
886325010003	CLUTCH DISC 330 DIA. CERAMIC BS1/2/3	TATA spare parts
886325010004	330 DIA.CLUTCH COVER ASSY.(COIL)	TATA spare parts
886325010005	ASSY. CLUTCH COVER 352D (1.5 SPLIN)BS1/2	TATA spare parts
886325010006	KIT-PRESSURE PLATE & N.ROLLER EURO1	TATA spare parts
886325010006AE	PR.Plate & N.ROLLER SER.KIT	TATA spare parts
886325010007	ASSY. CLUTCH DISC 352D (1.5 SPLIN) BS1/2	TATA spare parts
886325010008	ASSY. CLUTCH RELEASE BEARING -1.75	TATA spare parts
886325010008AE	RELEASE BEARING ASSY.-1.75	TATA spare parts
886325010009	KIT-CLUTCH PRESSURE PLATE SPRING EURO3	TATA spare parts
886325010009AE	PRESSURE SPRING SERVICE KIT	TATA spare parts
886325010010	PR.Plate WITH NEEDLE BUSHES	TATA spare parts
886325010011	REL BRG.ASSY	TATA spare parts
886325010012	KIT-RELEASE LEVER? EURO3	TATA spare parts
886325010012AE	RELEASE LEVER SERVICE KIT	TATA spare parts
886325010013	KIT RELEASE LEVER-LIPE	TATA spare parts
886325010014	KIT-DISC FACING EURO3	TATA spare parts
886325010014AE	DISC FACING KIT	TATA spare parts
886325010015	ASSY. CL.COVER 380 DIA. (1.75 SPLINE)	TATA spare parts
886325010015AE	PRESSURE PLATE 2523	TATA spare parts
886325010016	KIT PRESSURE SPRING	TATA spare parts
886325010017	KIT FOR 330DIA. ASSY. CLUTCH DISC	TATA spare parts
886325010018	EYE BOLT & N.ROLLER SER.KIT	TATA spare parts
886325010019	ASSY. CL.DISC 380 DIA (1.75 SPLINE)	TATA spare parts
886325010019AE	ASSY CLUTCH PLATE 2523	TATA spare parts
886325010020	COLLECTOR RING	TATA spare parts
886325010021	REP KIT REL LEVER&PR SPG	TATA spare parts
886325010022	REP KIT REL LEVER COIL	TATA spare parts
886325010023	COVER (FINISHED)	TATA spare parts

886325010024	CLUTCH DISC 430 DIA. BS3/4	TATA spare parts
886325010024AE	430 DIA CLUTCH DISC ASSLY	TATA spare parts
886325010025	REP KIT PR SPRING 310D	TATA spare parts
886325010026	RELEASE SPIDER	TATA spare parts
886325010026AE	RELEASE SPIDER	TATA spare parts
886325010027	RELEASE SLEEVE SERVICE KIT	TATA spare parts
886325010027AE	RELEASE SLEEVE SERVICE KIT	TATA spare parts
886325010028	RELEASE BEARING CASTING SERVICE KIT	TATA spare parts
886325010028AE	RELEASE BEARING CASTING SERVICE KIT	TATA spare parts
886325010029	KIT-RELEASE LEVER	TATA spare parts
886325010031	RELEASE LEVER WITH EYE BOLT	TATA spare parts
886325010032	ASSY. RELEASE LEVER WITH EYE BOLT	TATA spare parts
886325010033	SPECIAL TOOL KIT 352 DIA	TATA spare parts
886325010034	HOLD DOWN BOLT KIT	TATA spare parts
886325010034AE	HOLD DOWN BOLT KIT	TATA spare parts
886325010035	COTTER PIN	TATA spare parts
886325010036	HOLD DOWN BOLT KIT	TATA spare parts
886325010037	PRESSURE PLATE SERVICE KIT	TATA spare parts
886325010038	ASSY CLUTCH RELEASE BEARING	TATA spare parts
886325010039	PRESSURE SPRING 380 DIA.	TATA spare parts
886325010040	CLUTCH COLLECTOR RING	TATA spare parts
886325010041	CLUTCH ASSLY SET 430 DIA	TATA spare parts
886325010041AE	CLUTCH ASSLY SET 430 DIA	TATA spare parts
886325010042	CLUTCH COVER 430 DIA. BS3/4	TATA spare parts
886325010042AE	430 DIA CLUTCH COVER ASSLY	TATA spare parts
886325010043	CLUTCH COVER 380 DIA.	TATA spare parts
886325010044	ASSY. CLUTCH RELEASE BRG. BS2/3	TATA spare parts
886325010045	CL. COVER ASSY(1.75 SPL	TATA spare parts
886325010047	ASSY. DRIVEN DISC & COVER 352DIA.	TATA spare parts
886325010048	ASSY. CLUTCH COV & DISC 352DIA.BS1/2/3/4	TATA spare parts
886325010049	ASSY.KIT 330DIA COIL/CERAMIC CL	TATA spare parts
886325010051	CLUTCH COVER 330 DIA. BS1/2/3	TATA spare parts
886325010053	RELEASE BEARING ASSEMBLY KIT	TATA spare parts
886325010053AE	RELEASE BEARING ASSEMBLY KIT	TATA spare parts
886325010055	ASSY. CLUTCH DISC 310 DIA. (REINF)BS1- 4	TATA spare parts
886325010056	ASSY. CLUTCH COVER 330 DIA. BS1/2/S4	TATA spare parts
886325010057	ASSY. CLUTCH COVER 310 DIA.(REINF) BS1-4	TATA spare parts
886325010059	430 DIA. ASSY. CLUTCH DISC	TATA spare parts
886325010060	DISC FACING KIT-GRADE	TATA spare parts
886325010060AE	DISC FACING KIT-GRADE	TATA spare parts
886325010062	COLLECTOR RING ASSEMBLY KIT	TATA spare parts
886325010062AE	COLLECTOR RING ASSEMBLY KIT	TATA spare parts
886325010063	CLUTCH DISC 330 DIA. BS1/3/4	TATA spare parts
886325010064	330 DIA COVER ASSY (COIL)	TATA spare parts
886325010075	ASSY. CLUTCH COVER 352 DIA. BS1/2/3/4	TATA spare parts
886325010075AE	352 DIA. ASSY. CL. COVER LPTA715	TATA spare parts
886325010076	ASSY. CLUTCH DISC 352 DIA. BS1/2/3/4	TATA spare parts



886325010076AE	352 DIA. ASSY. CL DISC IPTA715	TATA spare parts
886325010077	330 DIA.CLUTCH DISC FACING KIT	TATA spare parts
886325013118	ASSY. CLUTCH DISC 380 DIA. (ORGANIC)	TATA spare parts
886325200106	352 DIA DISC ASSY CERAMIC 1.75INCH SPLIN	TATA spare parts
886325200134	380 DIA DISC ASSY 1.75INCH SPLINE ORGANI	TATA spare parts
886325400014	CLUTCH COVER ASSY. 352 DIA. W/O RBA	TATA spare parts
886325400105	352 DIA COVER ASSY PULL TYPE 1.75INCHSPL	TATA spare parts
886325400129	380 DIA COVER ASSY 1.75INCH SPLINE H.C.L	TATA spare parts
886326000001	PTO-PUMP ASSEMBLY	TATA spare parts
886326000002	PTO PARALLEL AXIS LPK 909	TATA spare parts
886326000003	AXIAL PISTON PUMP MK II - 3	TATA spare parts
886326000004	ASY REAR COVER(RH SPEEDO-SLIDING BUSH)	TATA spare parts
886326000005	PUMP SEAL KIT	TATA spare parts
886326000006	SHAFT SEAL	TATA spare parts
886326000007	INPUT SHAFT	TATA spare parts
886326000008	GEAR SHIFT HOUSING ASSEMBLY	TATA spare parts
886326000009	PULSE SENSOR	TATA spare parts
886326000010	STUD M12X1.75PX95L TL=115MM	TATA spare parts
886326000011	GEAR BOX BS6	TATA spare parts
886326000012	SNAP RING BS6	TATA spare parts
886326000013	O-RING BS6	TATA spare parts
886326000014	O-RING BS6	TATA spare parts
886326000015	SEAL BS6	TATA spare parts
886326000016	ROLLER BEARING BS6	TATA spare parts
886326000017	THRUST BEARING BS6	TATA spare parts
886326000018	THRUST WASHER BS6	TATA spare parts
886326000019	GEAR SHIFT HOUSING	TATA spare parts
886326000020	RC-SPEEDOMETER HOUSING	TATA spare parts
886326000021	WASHER	TATA spare parts
886326000022	NEEDLE ROLLER	TATA spare parts
886326000023	RING PIECE	TATA spare parts
886326000024	PISTON	TATA spare parts
886326000025	SELECT CABLE ASSY BS6	TATA spare parts
886326000026	SHIFT CABLE ASSY BS6	TATA spare parts
886326000027	SELECT CABLE ASSY BS6	TATA spare parts
886326000028	SHIFT CABLE ASSY BS6	TATA spare parts
886326000029	MUDGUARD STRAIGHT SUPPORT LH BS6	TATA spare parts
886326000030	MOUNTING BRACKET FOR SPRAY SUPPRESSION B	TATA spare parts
886326000031	STRIP BS6	TATA spare parts
886326000032	STRIP BS6	TATA spare parts
886326000033	REAR MARKING PLATE - LH BS6	TATA spare parts
886326000034	PTO ASSY G400 WITH XP 43CC PUMP BS6	TATA spare parts
886326000035	GEAR LEVER BOTTOM TENSIONER SPRING	TATA spare parts
886326000036	PUSH TO FIT SWIVEL ADAPTOR	TATA spare parts
886326000037	SPRING WITH SLEEVE BS6	TATA spare parts
886326000038	TOP ASSEMBLY BS6	TATA spare parts
886326000039	SELECT KIT BS6	TATA spare parts

886326000040	SHIFT DAMPER BS6	TATA spare parts
886326000041	COUPLER ASSEMBLY BS6	TATA spare parts
886326000042	BALL JOINT-M12-SHGSL BS6	TATA spare parts
886326000043	BALL JOINT -M10SH TM BS6	TATA spare parts
886326000044	BALL JOINT -M8 SL TM BS6	TATA spare parts
886326000045	RETAINER CLIP BS6	TATA spare parts
886326000046	SHIFT CABLE BS6	TATA spare parts
886326000047	SELECT CABLE BS6	TATA spare parts
886326000048	SHIFT STOPPER BS6	TATA spare parts
886326000049	SPRING KIT -LH BS6	TATA spare parts
886326000050	SPRING KIT -RH BS6	TATA spare parts
886326000051	SHIFT CABLE ASSEMBLY BS6	TATA spare parts
886326000052	SELECT CABLE ASSEMBLY BS6	TATA spare parts
886326000053	TOP ASSEMBLY BS6	TATA spare parts
886326000054	RUBBER BELLOW KIT SHIFT BS6	TATA spare parts
886326000055	RUBBER BELLOW KIT SELECT BS6	TATA spare parts
886326000056	SPHERICAL BALL JOINT M8 BS6	TATA spare parts
886326800001	PTO GB750 V2 TYPE	TATA spare parts
886326800002	BENT AXIAL PISTON PUMP 40LPM	TATA spare parts
886327000001	FILTER KIT 2 INCH SUMP	TATA spare parts
886327000002	ADAPTER HUB	TATA spare parts
886327000003	FLEXPLATE ASSEMBLY	TATA spare parts
886327000004	FLEXPLATE	TATA spare parts
886327000005	PLATE WEAR	TATA spare parts
886327000006	BOLT HX HD PATCHLOCK M6 X 1.0 X 14	TATA spare parts
886327000007	HOSE CONFIG II 1-5/8 1100MM	TATA spare parts
886327000008	HOSE STR AND 45DEG 1-5/8 650MM	TATA spare parts
886327000009	GEN5 TCM - CALIBRATED	TATA spare parts
886327000010	FILTER KIT 4IN SUMP	TATA spare parts
886327000011	SOLENOID-ACCUMULATOR	TATA spare parts
886327000012	ADAPTER HUB	TATA spare parts
886327000013	KIT HARD 3K TURBINE/DAMPER ASSEMBLIES	TATA spare parts
886327000014	REAR COVER ASSY	TATA spare parts
886327000015	SEAL ASSY	TATA spare parts
886327000016	GASKET	TATA spare parts
886327000017	BEARING ASSY	TATA spare parts
886327000018	BEARING ASSY	TATA spare parts
886327000019	BEARING ASSY	TATA spare parts
886328600001	GEARBOX FOR 5TON	TATA spare parts
886329000001	IBDC CONTROLLER OBU4.1A DTC	TATA spare parts
886329000002	KIT-SPARE PART ASSY BS6	TATA spare parts
886329000003	RETAINING CLIP -CMC BS6	TATA spare parts
886329000004	PEDAL END	TATA spare parts
886329000005	BRACKET END	TATA spare parts
886330000001	CONTORL CABLE	TATA spare parts
886330000002	ENGINE STOP CABLE	TATA spare parts
886330000003	ACCELERATION CABLE/LHAA6800329	TATA spare parts

886332000001	SUSPENSION KIT TRAILER AXLE-3 AXLE	TATA spare parts
886332000002	AIR SPRING MAIN BELLOWS	TATA spare parts
886332000005	LIFT AXLE AIR SPRING	TATA spare parts
886332000020	U CLAMP	TATA spare parts
886332000021	U CLAMP BED	TATA spare parts
886332000040	PNEUMATIC HOSE KIT	TATA spare parts
886332000054	FIRST LEAF WITH BUSH	TATA spare parts
886332000055	TRAILER-SUSPENSION EQUALISER ASSY WITH B	TATA spare parts
886332000056	TRAILER-SUSPENSION-EQUALISER PIN WITH NU	TATA spare parts
886332000057	TRAILER-SUSPENSION- BOLT 16X140MM WITH N	TATA spare parts
886332000058	TRAILER-SUSPENSION- BOLT 14X 90MM WITH L	TATA spare parts
886332000059	TRAILER-SUSPENSION-PIN TORQUE ARM FRONT/	TATA spare parts
886332000060	TRAILER-SUSPENSION- LOCK NUT FOR EQUALIZ	TATA spare parts
886332000061	TRAILER-SUSPENSION WASHER FOR EQUALIZER	TATA spare parts
886332000062	TRAILER SUSPENSION BUSH-TORQUE ARM 36MM	TATA spare parts
886332000063	TRAILER SUSPENSION BUSH-EQUALIZER 68MM	TATA spare parts
886332000064	TRAILER SUSPENSION CENTRE HANGER ASSEMBL	TATA spare parts
886332000065	REPAIR KIT FOR THE ASSEMBLY RELAY AND IN	TATA spare parts
886332000066	SUSPENSION SYSTEM	TATA spare parts
886332000067	RUBBER BELLOW WITH TOP PLATE W/O PISTON	TATA spare parts
886332000068	RUBBER BELLOW WITH TOP PLATE STUD/NUT	TATA spare parts
886332000069	CASTLE NUT M24X1.5	TATA spare parts
886332000070	CAP END CLOSURE & SEAL (26T) BS6	TATA spare parts
886332000071	LEAF SPRING ASSEMBLY (90X16 9/L) 16T	TATA spare parts
886332000072	LEAF SPRING ASSEMBLY (90X16 8/L) 13T	TATA spare parts
886332000073	SUSPENSION KIT 16T 3 AXLE (TRIDEM)	TATA spare parts
886332000075	SUSPENSION KIT 13T 3 AXLE (TRIDEM)	TATA spare parts
886332000076	SUSPENSION KIT 13T 2 AXLE (TANDEM)	TATA spare parts
886332000077	AIR SPRING BS6	TATA spare parts
886332000078	FRONT HANGER 8MM ASSY WITH 36 MM TORQU	TATA spare parts
886332000079	REAR HANGER 8MM ASSY WITH 16MM BOLT & N	TATA spare parts
886332000080	CENTRE HANGER 8MM	TATA spare parts
886332000081	EQUALIZER WITH TWO BOLTS AND SPACER PIPE	TATA spare parts
886332000082	EQUALIZER BOLT 68MM NYLOCK NUT & WASHER	TATA spare parts
886332000083	TORQUE ARM FIX 380 MM WITH 36MM BUSH	TATA spare parts
886332000084	TORQUE ARM FIX 450 MM WITH 36MM BUSH	TATA spare parts
886332000085	TORQUE ARM ADJUSTABLE 380 MM	TATA spare parts
886332000086	TORQUE ARM ADJUSTABLE 450 MM	TATA spare parts
886332000087	U BOLT FOR THE 9 LEAVES	TATA spare parts
886332000088	AXLE PLATE HEAVY DUTY (UPPER)	TATA spare parts
886332000089	AXLE PLATE HEAVY DUTY (BOTTOM)	TATA spare parts
886332000090	TEATER (AXL) BRACKET	TATA spare parts
886332000091	SPRING BRACKET FOR U BOLT	TATA spare parts
886332000092	FRONT HANGER 6MM ASSY WITH 28 MM TORQU	TATA spare parts
886332000093	REAR HANGER 6MM ASSY WITH BOLT & NUT	TATA spare parts
886332000094	CENTRE HANGER 6MM	TATA spare parts
886332000095	EQUALIZER WITH TWO BOLTS AND SPACER PIPE	TATA spare parts

886332000096	EQUALIZER BOLT 60MM NYLOCK NUT & WASHER	TATA spare parts
886332000097	TORQUE ARM FIX 380 MM W/ 28MM BUSH (SMA	TATA spare parts
886332000098	TORQUE ARM FIX 450 MM W/ 28MM BUSH (LONG	TATA spare parts
886332000099	TORQUE ARM ADJUSTABLE 380 MM	TATA spare parts
886332000100	TORQUE ARM ADJUSTABLE 450 MM	TATA spare parts
886332000101	U BOLT FOR 8 LEAVES	TATA spare parts
886332000102	AXLE PLATE HEAVY DUTY (UPPER)	TATA spare parts
886332000103	AXLE PLATE HEAVY DUTY (BOTTOM)	TATA spare parts
886332000104	TEATER (AXL) BRACKET	TATA spare parts
886332000105	AIR SPRING (MAKE FORESTONE W01M588106)	TATA spare parts
886332000108	TRAILER-FIXED AXLE AIR SUSP-1135X150MM	TATA spare parts
886332000109	TRAILER-LIFT AXLE AIR SUSP-135X150MM	TATA spare parts
886333000001	COIL ASSY	TATA spare parts
886333000002	REBOUND STRAP AFTER-MARKET KIT 2LPT 3118	TATA spare parts
886333000003	LIFT AXLE STABILIZER	TATA spare parts
886333000004	BUSH ASSY SINGLE FOR LIFT AXLE	TATA spare parts
886333000012	TRI-FUNCTIONAL BUSHING	TATA spare parts
886333000013	KIT BRAKE LINING	TATA spare parts
886334000001	DOUBLE TENSION SPRING	TATA spare parts
886334000002	SPRING LOOP	TATA spare parts
886334000003	HEXAGONAL BOLT COMPLETE	TATA spare parts
886334000004	TOP PLATE BS2/3/4	TATA spare parts
886334000006	COUPLING PLATE WITH RIB (40T PRIME MOVER	TATA spare parts
886334000007	COUPLING PLATE	TATA spare parts
886335000001	AXLE SHAFT ASSY	TATA spare parts
886335000002	REAR AXLE SHAFT	TATA spare parts
886335000003	BALL BEARING	TATA spare parts
886335000005	SET-CROWN WHEEL PINION 8/39? 4.88 ACE	TATA spare parts
886335000008	ACE CROWN WHEEL PINION SET - 9/44? 4.88	TATA spare parts
886335000009	ACE CROWN WHEEL PINION SET - 9/40? 4.44	TATA spare parts
886335000010	SHAFT FOR B G KIT	TATA spare parts
886335000011	REAR AXLE GEAR	TATA spare parts
886335000012	BEVEL PINION	TATA spare parts
886335000013	SHIM REAR HUB BS6	TATA spare parts
886335000014	OIL SEAL	TATA spare parts
886335012850	RING RETAINING (40052548)	TATA spare parts
886339000001	TOP SPRING LEAF	TATA spare parts
886339000002	WHEEL STUD	TATA spare parts
886339000003	WHEEL NUT	TATA spare parts
886339000004	8 LEAF SPRING ASSY	TATA spare parts
886339000005	LEAF SPRING YTE 75 HOOK	TATA spare parts
886339000006	LEAF SPRING YTE 75 TOP	TATA spare parts
886340000001	TYRE PRESSURE VALVE CAP-SET OF 5NO	TATA spare parts
886340000002	TYRE PRESSURE VALVE CAP -SET OF 15NO	TATA spare parts
886340000003	ASSY WHEEL RIM TRAILER 7.5X20 (S/LOCK)	TATA spare parts
886340000004	ASSY WHEEL RIM TRAILER7.5X20(RL)(D/LOCK)	TATA spare parts
886340000005	POLE WHEEL KIT	TATA spare parts

88634100001	SHORT FORK	TATA spare parts
88634100002	FRONT END PIECE	TATA spare parts
88634100003	COUPLING FLANGE	TATA spare parts
88634100004	DUST COVER	TATA spare parts
88634100005	CLAMP	TATA spare parts
88634100006	CENTERBEARING BRACKET	TATA spare parts
88634100007	REAR HOUSING ASSY	TATA spare parts
88634100008	LONG FORK	TATA spare parts
88634100009	DUST COVER SUB ASSY	TATA spare parts
88634100010	SHORT FORK	TATA spare parts
88634100011	LONG FORK	TATA spare parts
88634100012	DUST COVER SUB ASSY	TATA spare parts
88634100013	FRONT END PIECE	TATA spare parts
88634100014	COUPLING FLANGE	TATA spare parts
88634100015	CENTERBEARING BRACKET	TATA spare parts
88634100016	CLAMP	TATA spare parts
88634100017	REAR HOUSING ASSY	TATA spare parts
88634100018	SHORT FORK	TATA spare parts
88634100019	REAR HOUSING ASSY	TATA spare parts
88634100020	SHORT FORK	TATA spare parts
88634100021	REAR HOUSING ASSY	TATA spare parts
88634100022	LONG FORK	TATA spare parts
88634100023	DUST COVER SUB ASSY	TATA spare parts
88634100024	SHORT FORK	TATA spare parts
88634100025	REAR HOUSING	TATA spare parts
88634100026	LONG FORK	TATA spare parts
88634100027	DUST COVER ASSY	TATA spare parts
88634100028	REAR HOUSING ASSY	TATA spare parts
88634100029	LONG FORK	TATA spare parts
88634100030	DUST COVER SUB ASSY	TATA spare parts
88634100031	PROP. SHAFT COMPLETE (REAR)	TATA spare parts
88634100032	SHORT FORK	TATA spare parts
88634100033	FRONT END PIECE	TATA spare parts
88634100034	COUPLING FLANGE	TATA spare parts
88634100035	DUST COVER	TATA spare parts
88634100036	REAR HOUSING	TATA spare parts
88634100037	LONG FORK	TATA spare parts
88634100038	DUST COVER SUB ASSY.	TATA spare parts
88634100042	ACE UJ CROSS (DIA23.8X60MM)	TATA spare parts
88634100043	U J CROSS ACE? (DIA22X55MM)	TATA spare parts
88634100045	CROSS ASSY LPT 3118	TATA spare parts
88634100046	KIT -U J LPS 4018	TATA spare parts
88634100047	CROSS ASSY LPT 2518	TATA spare parts
88634100048	CROSS ASSY LPK1615	TATA spare parts
88634100049	CROSS KIT WITH CIRCLIP 38X57	TATA spare parts
88634100050	ASSY U J CROSS 46X68.90	TATA spare parts
88634100051	UJ KIT 41.28X126	TATA spare parts

886341000052	YOKE SHAFT ASSY. WITH DUST CAP	TATA spare parts
886341000053	ASSY PROP.SHAFT INTER AXLE	TATA spare parts
886341000054	BEARING	TATA spare parts
886342000003	KIT -FRONT BRAKE PAD ACE	TATA spare parts
886342000006	DUST SHIELD TOP	TATA spare parts
886342000007	DUST SHIELD BOTTOM	TATA spare parts
886342000008	SPIDER ASSY(BUSH+OIL SEAL)	TATA spare parts
886342000009	AL RIVETS 40 PCS (10/12)	TATA spare parts
886342000010	AL RIVETS (10/12)	TATA spare parts
886342000011	BRASS RIVETS L-10	TATA spare parts
886342000014	BRAKE CALLIPER RH	TATA spare parts
886342000015	SPIDER ASSEMBLY KIT LH	TATA spare parts
886342000016	SPIDER ASSEMBLY KIT RH	TATA spare parts
886342000017	BRACKET ASSEMBLY KIT - LH	TATA spare parts
886342000018	BRACKET ASSEMBLY KIT - RH	TATA spare parts
886342000019	CAMSHAFT LH	TATA spare parts
886342000020	CAMSHAFT RH	TATA spare parts
886342000021	FRONT 22.22 CYLINDER ASSY 608	TATA spare parts
886342000022	ASSY CYLINDER - TELCOLINE/SUMO	TATA spare parts
886342000023	CYLINDER ASSY RH	TATA spare parts
886342000024	ASSY. CYLINDER ACE 15.87	TATA spare parts
886342000025	ASSY. CYLINDER ACE CNG	TATA spare parts
886342000026	ASSY. CYLINDER 22.22D RR TM/SUMO	TATA spare parts
886342000027	CAM SHAFT SERVICE KIT	TATA spare parts
886342000028	BRAKE SHOE KIT	TATA spare parts
886342000029	BRAKE SHOE & LINER KIT	TATA spare parts
886342000030	MINOR SERVICE KIT	TATA spare parts
886342000031	CAM SHAFT WASHER KIT	TATA spare parts
886342000032	SPIDER ASSEMBLY KIT LH	TATA spare parts
886342000033	SPIDER ASSEMBLY KIT RH	TATA spare parts
886342000034	BRACKET ASSEMBLY KIT LH	TATA spare parts
886342000035	BRACKET ASSEMBLY KIT RH	TATA spare parts
886342000036	CAMSHAFT KIT LH	TATA spare parts
886342000037	CAMSHAFT KIT RH	TATA spare parts
886342000038	DUSTSHIELD ASSY KIT	TATA spare parts
886342000039	ROLLER KIT	TATA spare parts
886342000040	BRACKET MTG. FASTNER KIT	TATA spare parts
886342000041	DUST SHIELD MOUNTING FASTNER KIT	TATA spare parts
886342000042	SPRING SHOE RETURN KIT	TATA spare parts
886342000043	SPRING RETAINING KIT	TATA spare parts
886342000044	ANCHOR PIN KIT	TATA spare parts
886342000045	RIVET KIT	TATA spare parts
886342000046	CAM SHAFT SERVICE KIT	TATA spare parts
886342000047	SPIDER ASSEMBLY KIT LH	TATA spare parts
886342000048	SPIDER ASSEMBLY KIT RH	TATA spare parts
886342000049	CAMSHAFT KIT LH	TATA spare parts
886342000050	CAMSHAFT KIT RH	TATA spare parts

886342000051	DUSTSHIELD ASSY KIT	TATA spare parts
886342000052	KIT-BRAKE LINING STD. (SET OF 8)394DIA	TATA spare parts
886342000053	KIT-BRAKE LINING RS1. (SET OF 8)394DIA	TATA spare parts
886342000054	KIT-BRAKE LINING RS2. (SET OF 8)394DIA	TATA spare parts
886342000057	BRAKE SHOE WITH LINER ASSY. KIT	TATA spare parts
886342000058	KIT-ANCHOR PIN WITH BUSH	TATA spare parts
886342000059	KIT - SPRING BRAKE ACTUATOR TY9/9	TATA spare parts
886342000060	KIT - Torque Plate Assy - LH	TATA spare parts
886342000061	KIT - Torque Plate Assy - RH	TATA spare parts
886342000062	KIT- BRACKET ASSY LH	TATA spare parts
886342000063	KIT- Bracket Assy RH	TATA spare parts
886342000064	AIR SPRING 400 RH WITH TWO STUD	TATA spare parts
886342000065	KIT - SPIDER ASSY	TATA spare parts
886342000066	KIT - DUST SHIELD ASSY BS6	TATA spare parts
886342000067	BRAKE SHOE AND LINER KIT (TVS AF 3939) B	TATA spare parts
886342000068	BRAKE SHOE AND LINER KIT (HC AF 1040G) B	TATA spare parts
886342000069	KIT - SPRING SHOE RETURN BS6	TATA spare parts
886342000070	KIT - SPIDER ASSEMBLY LH	TATA spare parts
886342000071	KIT - SPIDER ASSEMBLY RH	TATA spare parts
886342000072	KIT LINED SHOE ASSY BS6	TATA spare parts
886342000073	KIT LINED SHOE ASSY (MASU NA1707) BS6	TATA spare parts
886342000074	DUST SHIELD- TOP & BOTTOM BS6	TATA spare parts
886342000075	CALIPER ASSY-LH-SUPER ACE	TATA spare parts
886342000076	CALIPER ASSY-RH-SUPER ACE	TATA spare parts
886342000077	KIT TORQUE PLATE	TATA spare parts
886342000078	CAMSHAFT - LH	TATA spare parts
886342000079	CAMSHAFT - RH	TATA spare parts
886342000080	BRAKE PAD-4PCS-LPO1623 CNG BS3/4	TATA spare parts
886342010710	KIT-BRAKE LINER STD 325 & 100	TATA spare parts
886342011623	CALLIPER LH	TATA spare parts
886342012829	KIT LINED SHOE ACE & SUPER ACE	TATA spare parts
886342020710	KIT-BRAKE LINER OS1 325 & 100	TATA spare parts
886342021623	CALLIPER RH	TATA spare parts
886342022818	KIT-FRONT BRAKE PAD SUPER ACE	TATA spare parts
886342030710	KIT-BRAKE LINER OS2 325 & 100	TATA spare parts
886342040710	KIT-BRAKE LINER STD 325 & 100 74 MM	TATA spare parts
886342050710	KIT-BRAKE LINER OS1 325 & 100 74 MM	TATA spare parts
886342060710	KIT-BRAKE LINER OS2 325 & 100 74 MM	TATA spare parts
886343000001	INPUT SHAFT SEAL RING	TATA spare parts
886343000002	OUTPUT SHAFT SEAL RING	TATA spare parts
886343000003	NC SINGLE EXT. PILOT SP. RETURN VALVE	TATA spare parts
886343000004	AIR DRYER BODY KIT	TATA spare parts
886343000005	CYLINDER HEAD ASSEMBLY	TATA spare parts
886343000006	CONNECTING ROD-MACHINING	TATA spare parts
886343000007	NUT	TATA spare parts
886343000008	TURBO CHECK VALVE	TATA spare parts
886343000009	AIR DRYER WITH SYSTEM PURGE BS6	TATA spare parts

886343000010	KIT-BRAKE CHAMBER	TATA spare parts
886343000011	VOSS ADAPTOR	TATA spare parts
886343000012	AIR PROCESSING & DISTRIBUTION UNIT	TATA spare parts
886343000013	KIT - SCREW HOLDER	TATA spare parts
886343000014	ROD WIND OFF ASSY	TATA spare parts
886343000015	ADAPTOR BS6	TATA spare parts
886343000016	WASHER BS6	TATA spare parts
886343000017	MONO AIR SUSPENSION W/ELECTRICAL KIT	TATA spare parts
886343000018	MONO AIR SUSPENSION LIFT AXLE KIT	TATA spare parts
886343000019	MONO AIR SUSPENSION W/LIFT AXLE ELECTRIC	TATA spare parts
886343000020	RELAY VALVE	TATA spare parts
886344000001	PRESSURE CARTRIDGE ASSEMBLY	TATA spare parts
886344000002	HYDRAULIC PIPE PTO TO END CONTROL VALVE	TATA spare parts
886344000003	GEAR PUMP	TATA spare parts
886344000004	SEAL KIT 3 STAGES	TATA spare parts
886344000005	TIPPER BODY ASSEMBLY-16 BOX _WITHOUT HYD	TATA spare parts
886344000006	FILLER BREATHER	TATA spare parts
886344000007	CARTRIDGE	TATA spare parts
886344000008	Hydraulic Seal Kit	TATA spare parts
886344000009	PRESSURE FILTER	TATA spare parts
886344000010	RETURN LINE FILTER	TATA spare parts
886344000011	HYDRAULIC TANK BARE	TATA spare parts
886344000012	ELBOW WITH NIPPLE FOR 1IN HOSE (SUCTION)	TATA spare parts
886344000013	R2 HOSE 3/4IN 950 LG	TATA spare parts
886344000014	R2 HOSE 1/2IN 560 LG	TATA spare parts
886344000015	R2 HOSE 1/2IN 900 LG	TATA spare parts
886344000016	R2 HOSE 1/2IN 800 LG	TATA spare parts
886344000017	ADAPTOR OF MKII-2 PUMP WITH READELIVERY	TATA spare parts
886344000018	ADAPTOR M22X1.5	TATA spare parts
886344000019	R3 HOSE 1IN 320LG	TATA spare parts
886344000020	MS PIN	TATA spare parts
886344000021	CIRCLIP	TATA spare parts
886344000022	CYLINDER SEAL KIT	TATA spare parts
886344000023	FILTER COVER ALUMINIUM MOUNTING PLATE	TATA spare parts
886344000024	DISC BODY ASSEMBLY	TATA spare parts
886344000025	HOUSING	TATA spare parts
886344000026	FLANGE	TATA spare parts
886344000027	DRIVE GEAR-27T	TATA spare parts
886344000028	PUMP GEAR-25T	TATA spare parts
886344000029	PISTON	TATA spare parts
886344000030	WASHER	TATA spare parts
886344000031	HEXAGONAL SPECIAL BOLT	TATA spare parts
886344000032	SPRING	TATA spare parts
886344000033	NEEDLE ROLLER BEARING	TATA spare parts
886344000034	NEEDLE ROLLER BEARING	TATA spare parts
886344000035	HEX. NUT M12	TATA spare parts
886344000036	STUD M12X1.75X41L	TATA spare parts



886344000037	STUD M12X1.75X100L	TATA spare parts
886344000038	STUD M12X1.75X106L	TATA spare parts
886344000039	SPRING WASHER M12	TATA spare parts
886344000040	O RING	TATA spare parts
886344000041	GASKET FOR PUMP MOUNTING	TATA spare parts
886344000042	1/8TH ONE TOUCH PNEUMATIC CONNECTOR	TATA spare parts
886344000043	EXTERNAL CIRCLIP	TATA spare parts
886344000044	HYDRAULIC PUMP	TATA spare parts
886344000045	T- VALVE	TATA spare parts
886344000046	PTO BEARING (INPUT SHAFT)	TATA spare parts
886344000047	MOTOR 33 CC FOR SUCTION TANKER	TATA spare parts
886344000048	JAW COUPLING	TATA spare parts
886344000049	RUBBER GASKET FOR COUPLING	TATA spare parts
886344000050	MANUAL CONTROL VALVE	TATA spare parts
886344000051	OIL LEVEL INDICATOR 3/4 IN	TATA spare parts
886344000052	TELESCOPIC CYLINDER	TATA spare parts
886344000053	STRAIGHT REDUCER 1	TATA spare parts
886344000054	PUSH PULL CABLE	TATA spare parts
886344000055	VALVE OPERATING LEVER	TATA spare parts
886344000056	VALVE MOUNTING BRACKET	TATA spare parts
886344000057	MCV LEVER ASSY	TATA spare parts
886344000058	HYDRAULIC CYLINDER BS2/3/4	TATA spare parts
886344000059	HYDRAULIC TANK- MAKE TATA	TATA spare parts
886344000060	TIPPING VALVE ASSY	TATA spare parts
886344000061	RETURN FILTER ASSY	TATA spare parts
886344000062	ASSY AIR BREATHER ON HYDRAULIC TANK	TATA spare parts
886344000063	HYDRAULIC TANK MTG. BRACKETS	TATA spare parts
886344000064	PISTON ROD - 1 S/A(TC0371)	TATA spare parts
886344000065	PISTON ROD - 2 S/A (TC0371)	TATA spare parts
886344000066	TUBE S/A (TC0371)	TATA spare parts
886344000067	PISTON ROD- 3 S/A (TC0371)	TATA spare parts
886344000068	RETURN LINE FILTER ASSEMBLY (DFC <sub>2</sub> AND DF	TATA spare parts
886344000069	FULL CYLINDER	TATA spare parts
886344000070	HYDRAULIC KIT	TATA spare parts
886344000071	RETURN HOSE ASSEMBLY 1IN X 1150	TATA spare parts
886344000072	PRESSURE HOSE FITTING 3/4IN ID X 2080L	TATA spare parts
886344000073	PTO PIPE 3WAY	TATA spare parts
886344000074	MAGNETIC SOLENOID VALVE	TATA spare parts
886344000075	CYLINDER BOTTOM MTG PIN	TATA spare parts
886344000076	CYLINDER TOP MTG PIN	TATA spare parts
886344000077	PTO DRIVEN PUMP WITH PUSH PULL CABLE	TATA spare parts
886344000078	HYDRULIC KIT COMPLETE	TATA spare parts
886344000079	HEX.SOC.HD.SCREW M8 X 100	TATA spare parts
886344000080	CORREGATED HOSE ID 3/4IN	TATA spare parts
886344000081	SUCTION HOSE 1/2IN 90DEG X 1/2IN- 700L	TATA spare parts
886344000082	RETURN HOSE 1/2IN X 1/2IN - 300L	TATA spare parts
886344000083	PRESSURE HOSE 3/8IN X 3/8IN - 900L	TATA spare parts

88634400084	HOSE WITH ONE END BEND 3/8INX3/8IN	TATA spare parts
88634400085	DOUBLE ACTING SOL.OP.DCV	TATA spare parts
88634400086	POWER CABLE 2.5 MM.SQ. 3 CORE (3 MTS)	TATA spare parts
88634400087	2 BUTTON SWITCH (TYPE-ON/OFF)	TATA spare parts
88634400088	STRAIGHT COUPLING BODY 1/4IN BSP X 3/8IN	TATA spare parts
88634400089	ADAPTOR 1/4IN X 1/2IN BSP	TATA spare parts
88634400090	ADAPTOR 3/8IN X 1/2IN BSP	TATA spare parts
88634400091	ADAPTOR 1/2IN X 1/2IN BSP	TATA spare parts
88634400092	BANJO FITTING 3/8INX3/8IN	TATA spare parts
88634400093	TIPPING CYLINDER	TATA spare parts
88634400094	OIL TANK ASSY	TATA spare parts
88634400095	MANIFOLD ASSY(WITH CHECK VALVE & RELIEF)	TATA spare parts
88634400096	LINEAR SPOOL VALVE (TIPPING VALVE)	TATA spare parts
88634400097	FILTER ELEMENT	TATA spare parts
88634400098	ASSY. AIR BREATHER FILTER	TATA spare parts
88634400099	VALVE MOUNTING PLATE	TATA spare parts
88634400100	TOP MOUNTING BUSH	TATA spare parts
88634400101	BOTTOM MOUNTING BUSH	TATA spare parts
88634400102	GEAR PUMP	TATA spare parts
88634400103	BASE PLATE KIT	TATA spare parts
88634400104	PUSH PULL CABLE (1.3 MTR)	TATA spare parts
88634400105	ABS MODULATOR - VCS 24V ÷ PRIMA TRAILER	TATA spare parts
88634400106	HIGH PRESSURE SERVICE VALVE (DISCHARGE)	TATA spare parts
88634400107	LOW PRESSURE SERVICE VALVE÷ (SUCTION)	TATA spare parts
88634400108	HYDRAULIC OIL TANK	TATA spare parts
88634400109	DIRECTION CONTROL VALVE 3B-140L	TATA spare parts
88634400110	HP HOSE 1830 MM	TATA spare parts
88634400111	HP HOSE 1380 MM	TATA spare parts
88634400112	OIL TANK 63 LTRS	TATA spare parts
88634400113	PRESSURE ADAPTER KIT 3/4INCH	TATA spare parts
88634400114	PRESSURE ADAPTER KIT R1	TATA spare parts
88634400115	TANK ASSEMBLY	TATA spare parts
88634400116	SPOOL VALVE	TATA spare parts
88634400117	BALL VALVE	TATA spare parts
88634400118	HYD. TANK	TATA spare parts
88634400119	OIL LEVEL INDICATOR	TATA spare parts
88634400120	TALEGATE LIFTING HYDRAULIC CYLINDER	TATA spare parts
88634400121	PACKER PLATE HYDRAULIC CYLINDER	TATA spare parts
88634400122	BEARING PLATE HYDRAULIC CYLINDER	TATA spare parts
88634400123	RETURN LINE FILTER	TATA spare parts
88634400124	AIR BREATHER ELEMENT	TATA spare parts
88634400125	MUDGUARD	TATA spare parts
88634400126	GREASE NIPPLE 1/4	TATA spare parts
88634400127	GREASE NIPPLE 1/8	TATA spare parts
88634400128	HYDRAULIC HOSE ID-3/8	TATA spare parts
88634400129	REFLECTING TAPE	TATA spare parts
88634400130	SIDE MARKER LIGHT	TATA spare parts

886344000131	ROOF MARKER LIGHT	TATA spare parts
886344000132	BACK LIGHT	TATA spare parts
886344000133	BIN LIFTIG CYLINDER	TATA spare parts
886344000134	BIN TILTING CYLINDER	TATA spare parts
886344000135	PACKER PLATE ASSEMBLY	TATA spare parts
886344000136	M10X30 ALLEN CSK SCREW AND NUT FOR WEAR	TATA spare parts
886344000137	UHMW STRIP(FOR EJECTOR)	TATA spare parts
886344000138	M12X30 HT BOLT AND NUT	TATA spare parts
886344000139	1/8 BSP 45DEG BEND GREASE NIPPLE	TATA spare parts
886344000140	M16X100 HT NUT BOLT	TATA spare parts
886344000141	WASHER FOR BRASS BLOCK FITTING	TATA spare parts
886344000142	PIN FOR BRASS BLOCK	TATA spare parts
886344000143	BUSH FOR BRASS BLOCK(ID50 OD70 L45)	TATA spare parts
886344000144	HYDRAULIC çASSY (WIS 28TA FOR SK407 )	TATA spare parts
886344000145	PRESSURE HOSE	TATA spare parts
886344000146	HYDRAULIC CYLINDER 169-4 KIT	TATA spare parts
886344000147	COMP HYD KIT WIS-26 TB(A)- LPK407	TATA spare parts
886344000148	COMP HYD KIT WIS-23MTQ(B) ç LPK912	TATA spare parts
886344000149	COMP HYD KIT WIS 23 MTD (A) ç LPK909	TATA spare parts
886344000150	COMP HYD KIT WFR-280(B) DFC 110 ç LPK161	TATA spare parts
886344000151	TIPPING FOR LPK 912 W/O PTO-PUMP WITH PN	TATA spare parts
886344000152	HYD. TANK	TATA spare parts
886344000153	R2 HOSE 3/4INCH 1060 LG	TATA spare parts
886344000154	SUBFRAME ASSLY	TATA spare parts
886344000155	SNAPçRING 64 OD	TATA spare parts
886344000156	ACE PTO WITH 5CC PUMP	TATA spare parts
886344000157	PRESSURE ADAPTER CARTRIDGE 3/8INCH BSPOT	TATA spare parts
886344000158	TANK ASSY FET	TATA spare parts
886344000159	SLEEVE	TATA spare parts
886344000160	RETURN FILTER ASSY	TATA spare parts
886344000161	TELESCOPICç CYLINDER	TATA spare parts
886344000162	HYDRAULIC PUMP	TATA spare parts
886344000163	HYDRAULIC PUMP WITH PTO	TATA spare parts
886344000164	HYDRAULIC PUMP	TATA spare parts
886344000165	TELESCOPICç CYLINDER	TATA spare parts
886344000166	HYDRAULIC PUMP	TATA spare parts
886344000167	CLOG INDICATOR	TATA spare parts
886344000168	PNEUMATICALLY CONTROLLED D. C. VALVE	TATA spare parts
886344000169	PTO GB55	TATA spare parts
886344000170	PTO PUMP 43CC	TATA spare parts
886344000171	TELESCOPIC CYLINDER	TATA spare parts
886344000172	HYDRAULIC PUMP	TATA spare parts
886344000173	DUEL OVER CENTER VALVE	TATA spare parts
886344000174	HYDRAULIC HOSE ID-1/2	TATA spare parts
886344000175	DUMPER PLACER ARM CYLINDER	TATA spare parts
886344000176	LHS STABLIZER CYLINDER	TATA spare parts
886344000177	RHS STABLIZER CYLINDER	TATA spare parts

886344000178	CONTAINER BODY	TATA spare parts
886344000179	TAIL GATE	TATA spare parts
886344000180	TATA MONOGRAM	TATA spare parts
886344000181	MUD FLAP	TATA spare parts
886344000182	BODY ASSY. (W/O KIT)	TATA spare parts
886344000183	SUB FRAME ASSY	TATA spare parts
886344000184	TAIL GATE ASSEMBLY	TATA spare parts
886344000185	BODY PROP SUPPORT	TATA spare parts
886344000186	LOCK	TATA spare parts
886344000187	HINGE PIN	TATA spare parts
886344000188	FULCRUM SHAFT	TATA spare parts
886344000189	U- BOLT	TATA spare parts
886344000190	ALLUMINIUM PACKING	TATA spare parts
886344000191	BRACKET TAIL GATE MTG	TATA spare parts
886344000192	PIN TAIL LOCK (L-55)	TATA spare parts
886344000193	PIN TAIL LOCK(L-55)	TATA spare parts
886344000194	PIN TAIL LOCK (L-105)	TATA spare parts
886344000195	U BOLT SPACER	TATA spare parts
886344000196	TOP MARKER LAMP	TATA spare parts
886344000197	ASSS MUDGUARD SUPPORT	TATA spare parts
886344000198	MUDGUARD SIDE SPRAY SUPPRESSION	TATA spare parts
886344000199	MUDGUARD REAR SPRAY SUPPRESSION	TATA spare parts
886344000200	WIRING HARNESS	TATA spare parts
886344000201	REFLECTIVE TAPE YELLOW (50 MM)	TATA spare parts
886344000202	REFLECTIVE TAPE RED (50 MM)	TATA spare parts
886344000203	TATA STICKER (SIDE PANEL)	TATA spare parts
886344000204	TATA STICKER (TAIL GATE)	TATA spare parts
886344000205	HYDRAULIC TANK 127 LTRS	TATA spare parts
886344000206	SEAL KIT	TATA spare parts
886344000207	SUCTION HOSE	TATA spare parts
886344000208	COMPLETE HYDRAULIC KIT W/O PUMP	TATA spare parts
886344000209	ELBOW	TATA spare parts
886344000210	TIPPING CYLINDER GHS 175X4X4520 C	TATA spare parts
886344000211	TANK ASSLY 35 LTR (LPK-912)	TATA spare parts
886344000212	HYDRAULIC TANK MOUNTING BRACKET	TATA spare parts
886344000213	SOLENOID VALVE 24V	TATA spare parts
886344000214	RELAY VALVE	TATA spare parts
886344000215	FILTER	TATA spare parts
886344000216	PRESSURE HOSE ASSY. (240 BAR W.P.) 1/2I	TATA spare parts
886344000217	PRESSURE HOSE ASSY. (240 BAR W.P.) 1/2IN	TATA spare parts
886344000218	PR.HOSE ASSY.(275 BAR WP) 90 DEG-BEND	TATA spare parts
886344000219	SUCTION/RETURN HOSE 1INCHIDX550L	TATA spare parts
886344000220	ADAPTOR WITH CHECK VALVE FOR PZB PUMP PT	TATA spare parts
886344000221	PARALLEL MALE STUD ADAPTOR EN 1A	TATA spare parts
886344000222	VALVE MOUNTING BRACKET	TATA spare parts
886344000223	CABLE TIES 100 MM	TATA spare parts
886344000224	ADOPTOR 1/2INCH X 1INCH BARE HOSE	TATA spare parts

886344000225	ELBOW	TATA spare parts
886344000226	PNEUMATIC CONNECTOR	TATA spare parts
886344000227	REAR ATTACHEMENT PLATE	TATA spare parts
886344000228	ATTACHEMENT PLATE-1	TATA spare parts
886344000229	ATTACHEMENT PLATE-2	TATA spare parts
886344000230	PRESSURE HOSE 950L	TATA spare parts
886344000231	PRESSURE HOSE3/4INCHIDX 2400L	TATA spare parts
886344000232	PRESSURE HOSE 3/4INCH ID X 1750 L	TATA spare parts
886344000233	PRESSURE HOSE ASSY. 1/2INCHIDX2450 L	TATA spare parts
886344000234	SUCTION HOSE 1INCHIDX950 L	TATA spare parts
886344000235	RETURN LINE HOSE 1INCHIDX760 L	TATA spare parts
886344000236	CLEVIS BUSH	TATA spare parts
886344000237	ROD EYE BUSH	TATA spare parts
886344000238	PTO	TATA spare parts
886344000239	HP HOSE	TATA spare parts
886344000240	SPARE COMPLETE TANK	TATA spare parts
886344000241	HYDRAULIC PIPE (FROM HYD. JACK TO TIPPIN	TATA spare parts
886344000242	TANK SHELL	TATA spare parts
886344000243	HYDRAULIC CYLINDER(VERTICAL)	TATA spare parts
886344000244	HEX. HEAD SCREW M8 X 75 - 10.9	TATA spare parts
886344000245	HEX. HEAD SCREW M12 X 45 - 10.9	TATA spare parts
886344000246	PLAIN WASHER A8.5 IS 5370 - STEEL	TATA spare parts
886344000247	HEX. HEAD BOLT 3/8 INCH - BSF X 1	TATA spare parts
886344000248	STANDARD BONDED SEAL	TATA spare parts
886344000249	SUCTION/ RETIRN LINE HOSE	TATA spare parts
886344000250	PRESSURE HOSE WITH INCHUINCH BEND	TATA spare parts
886344000251	NYLOC NUT M8 X 1.25	TATA spare parts
886344000252	NYLOC NUT M 12 X 1.75	TATA spare parts
886344000253	NYLOC NUT 3/8 BSF BS 1073	TATA spare parts
886344000254	SWIVEL ELBOW ASSY. ( WITH PMSC )	TATA spare parts
886344000255	PROPELLER SHAFT TYPE A	TATA spare parts
886344000256	ADAPTOR PTO	TATA spare parts
886344000257	ADAPTOR (PUMP ) COMPLTE OPERATION	TATA spare parts
886344000258	PARALLEL MALE STUD ADAPTOR M33 X2	TATA spare parts
886344000259	TANK MOUNTI NG STRIP ASSY.	TATA spare parts
886344000260	RUBBER STRIP N50 ( BOC )	TATA spare parts
886344000261	ADAPTOR ( M33 X 2 X M30 X 2 )	TATA spare parts
886344000262	PUSH PULL CABLE ( 1.19 MTR )	TATA spare parts
886344000263	VALVE OPERATING LEVER & BRACKET	TATA spare parts
886344000264	PISTON PUMP AP F 330 21 210 1700 ( L11	TATA spare parts
886344000265	H210 095 X 083 NC CM + RE 1154	TATA spare parts
886344000266	LINEAR SPOOL VALVE WITH OPTG. LEVER	TATA spare parts
886344000267	HYD. TANK ASSY	TATA spare parts
886344000268	PUMP MOUNTING BRACKET	TATA spare parts
886344000269	SERVICE DRUM PINION	TATA spare parts
886344000270	DRUM PINION SHAFT	TATA spare parts
886344000271	CYLINDER	TATA spare parts

886344000272	HOSE	TATA spare parts
886344000273	GEAR PUMP 82 CC -BI-REAR PORT-4H ISO	TATA spare parts
886344000274	HYDRAULIC FILTER	TATA spare parts
886344000275	3 WAY BALL VALVE	TATA spare parts
886344000276	VALVE	TATA spare parts
886344000277	BARE TANK	TATA spare parts
886344000278	OIL LEVEL GAUGE	TATA spare parts
886344000279	METAL STRAINER	TATA spare parts
886344000280	FILLER CUM BREATHER	TATA spare parts
886344000281	DRAIN PLUG	TATA spare parts
886344000283	MALE STUD COUPLING 3/8INCH BSP	TATA spare parts
886344000284	EQUAL TEE 125	TATA spare parts
886344000285	HYDRAULIC NUT 12 OD	TATA spare parts
886344000286	HYDRAULIC RING	TATA spare parts
886344000287	STRAIGHT COUPLING	TATA spare parts
886344000288	MALE STUD COUPLING 1/4INCH BSP	TATA spare parts
886344000289	M/F REDUCER 1/2INCHX1/4INCH	TATA spare parts
886344000290	HYDRAULIC HOSE ID-3/8	TATA spare parts
886344000291	0.5 CUM HOPPER	TATA spare parts
886344000292	GASKET	TATA spare parts
886344000293	BALL VALVE 15 NB	TATA spare parts
886344000294	DC POWER PACK 24V DC	TATA spare parts
886344000295	HYDRAULIC CYLINDER	TATA spare parts
886344000296	ALTERNATOR	TATA spare parts
886344000297	FUSE 250 AMP + WIRE HARNESS	TATA spare parts
886344000298	CYLINDRICAL ROD	TATA spare parts
886344000299	BOLT	TATA spare parts
886344000300	LOCK NUT	TATA spare parts
886344000301	MTG KIT HT VLV1150 & 1220 TNK	TATA spare parts
886344000302	HYDRAULIC KIT	TATA spare parts
886344000303	DOUBLE ACTING SOLENOID VALVE	TATA spare parts
886344000304	POWER CABLE 2.5 SQMM X 3 CORE (3MTR)	TATA spare parts
886344000305	ST. COUPLING BODY	TATA spare parts
886344000306	SUCTION HOSE	TATA spare parts
886344000307	PRESSURE HOSE	TATA spare parts
886344000308	SOLENOID VALVE	TATA spare parts
886344000309	ELBOW ASSY	TATA spare parts
886344000310	CRADLE ASSY 14 CUM STD	TATA spare parts
886344000311	BASE TUBE KIT DIA175 X 1388 (CM) BS6	TATA spare parts
886344000312	SEAL KIT.	TATA spare parts
886344000313	72 CC PMP HYDRAULIC PUMP	TATA spare parts
886344000314	RUBBER HOSE 4SH25-(72CC+72CC) MOTOR +PUM	TATA spare parts
886344000315	RUBBER HOSE 4SH25-(72CC+72CC) MOTOR +PUM	TATA spare parts
886344000316	SPLIT FLANGE (72 CC PUMP HOSE)	TATA spare parts
886344000317	BALL VALVE	TATA spare parts
886344000318	COPPER BALL VALVE 20-	TATA spare parts
886344000319	PUMP CABLE/LHAA6800029	TATA spare parts

886344000320	MANHOLE COVERTM0601.8-7	TATA spare parts
886344000321	SEAL RING GJB312C8R.1.8-2	TATA spare parts
886344000322	TATA LPK3118 ¿ DFE-149-4-4525	TATA spare parts
886344000323	COMPLETE HYD KIT ASSY	TATA spare parts
886344000324	HYDRULIC KIT	TATA spare parts
886344000325	HYDRAULIC KIT (TC-0301)	TATA spare parts
886344000326	HYDRAULIC KIT WITH PUMP PTO	TATA spare parts
886344000327	HYDRAULIC KIT	TATA spare parts
886344000328	HOSE ID3/4X1100 LG UNF-UNF	TATA spare parts
886344000329	BALL VALVE 15 NB (3 WAY - HIGH PRESSURE)	TATA spare parts
886344000330	TENSION SPRING 300MM	TATA spare parts
886344000331	SEAL KIT 82CC PUMP	TATA spare parts
886344000332	WIRING HARNESS -14 CUM BOX (LPK2518/38)	TATA spare parts
886344000333	CRADLE + OT ASSLY 149 PRIMA RB	TATA spare parts
886344000334	POWER CYLINDER	TATA spare parts
886344000335	CHASSIS BRACKET HM12 DIA60 X 368	TATA spare parts
886344000336	PTO ASSY	TATA spare parts
886344000337	SEAL KIT	TATA spare parts
886344000338	RETURN LINE	TATA spare parts
886344000339	SEAL KIT COMPLETE UM 129-4	TATA spare parts
886344000340	PTO DRIVEN PUMP 5 SPEED BS6	TATA spare parts
886344000341	HYDRAULIC KIT (TC0180) - PTT915001X050-W	TATA spare parts
886344000342	PTO+PUMP( 5 SPEED) BS6	TATA spare parts
886344000343	RLF ELEMENT BS6	TATA spare parts
886344000344	BASE TUBE FINISH ¿155 X 1397	TATA spare parts
886344000345	TIPPING CYLINDER GHS 135 X 3 X 3400 C	TATA spare parts
886344000346	TOP MOUNTING PIN	TATA spare parts
886344000347	BOTTOM MOUNTING PIN	TATA spare parts
886344000348	TOP MOUNTING BKT	TATA spare parts
886344000349	BOTTOM MOUNTING BKT	TATA spare parts
886344000350	CHAIN POCKET	TATA spare parts
886344000351	INCH1 1/4INCH BSP SUCTION HOSE- 1450L BS	TATA spare parts
886344000352	3/4INCH R2 PRESSURE HOSE- 2000 BS6	TATA spare parts
886344000353	3/4INCH R2 - 1400 L PRESSURE HOSE BS6	TATA spare parts
886344000354	90L HYDRAULIC TANK SUB ASSEMBLY BS6	TATA spare parts
886344000355	RETURN LINE FILTER BS6	TATA spare parts
886344000356	PTO ASSY	TATA spare parts
886344000357	AIR BREATHER FILTER BS6	TATA spare parts
886344000358	GUIDE KIT BS6	TATA spare parts
886344000359	SEAL KIT BS6	TATA spare parts
886344000360	ADAPTOR M22X1.5(M)X 1/2INCHBSP(M)	TATA spare parts
886344000361	8.5 CUM COMPRESSOR + MTG KIT + PTO KIT	TATA spare parts
886344000362	PTO-GB 55	TATA spare parts
886344000363	RUBBER BS6	TATA spare parts
886344000364	HOSE BS6	TATA spare parts
886344000365	OIL COOLER BS6	TATA spare parts
886344000366	HOSE (LOW PRESSURE) BS6	TATA spare parts

886344000367	HOSE (LOW PRESSURE) BS6	TATA spare parts
886344000368	HOSE (LOW PRESSURE) BS6	TATA spare parts
886344000369	O-RING BS6	TATA spare parts
886344000370	HOSE CLIP BS6	TATA spare parts
886344000371	SWIVEL RUN TEE BS6	TATA spare parts
886344000372	SWIVEL 90° SWEPT ELBOW BS6	TATA spare parts
886344000373	U BOLT BS6	TATA spare parts
886344000374	CLIP BS6	TATA spare parts
886344000375	CLAMP BS6	TATA spare parts
886344000376	NIPPLE BS6	TATA spare parts
886344000377	SHOWER BS6	TATA spare parts
886344000378	BRASS BALL VALVE BS6	TATA spare parts
886344000379	BRASS BALL VALVE 3/4INCHB L-73 MM H-54	TATA spare parts
886344000380	BRASS BALL VALVE 1/2INCHB L-62 MM H-48	TATA spare parts
886344000381	NIPPLE BS6	TATA spare parts
886344000382	NIPPLE BS6	TATA spare parts
886344000383	FEMALE TEE 1 -1/4B CCD 46 MM ALL SIDE BS	TATA spare parts
886344000384	FEMALE TEE 3/4B CCD 32 MM ALL SIDE BS6	TATA spare parts
886344000385	CAP PT1-1/4 HEIGHT-30 MM TOP OUTER BS6	TATA spare parts
886344000386	BUSHING PT3/4(M)X18 MM-PT1/2(F) LG-24 B	TATA spare parts
886344000387	MS WORM DRIVE SERT. HOSE CLAMP BS6	TATA spare parts
886344000388	MS WORM DRIVE SERT. HOSE CLAMP BS6	TATA spare parts
886344000389	MS WORM DRIVE SERT. HOSE CLAMP BS6	TATA spare parts
886344000390	NIPPLE PT-2INCH(M)-PT-2INCH(M) LG-66 MM	TATA spare parts
886344000391	SOCKET BS6	TATA spare parts
886344000392	MS WORM DRIVE SERRT. HOSE CLAMP BS6	TATA spare parts
886344000393	HEADER BLOCK BS6	TATA spare parts
886344000394	HOSE (WATER) BS6	TATA spare parts
886344000395	WATER HOSE SIZE 25 (L=7) BS6	TATA spare parts
886344000396	WATER HOSE SIZE 19 (L=10.5) BS6	TATA spare parts
886344000397	WATER HOSE SIZE 38 (L=1.5) BS6	TATA spare parts
886344000398	CENTRIFUGAL WATER PUMP BS6	TATA spare parts
886344000399	MECHANICAL SEAL - BAKGM BS6	TATA spare parts
886344000400	HYD. MOTOR M72 BS6	TATA spare parts
886344000401	PLUNGER MOTOR BS6	TATA spare parts
886344000402	SCREW M12X45 BS6	TATA spare parts
886344000403	WASHER 12 BS6	TATA spare parts
886344000404	REDUCTION GEAR BS6	TATA spare parts
886344000405	BOLT M20X120 BS6	TATA spare parts
886344000406	WASHER BS6	TATA spare parts
886344000407	NUT M20 BS6	TATA spare parts
886344000408	BOLT M16X50 BS6	TATA spare parts
886344000409	RADIATOR BS6	TATA spare parts
886344000410	BOLT M12X80 BS6	TATA spare parts
886344000411	NUT M12 BS6	TATA spare parts
886344000412	WASHER BS6	TATA spare parts
886344000413	BOLT M10X45 BS6	TATA spare parts



886344000414	NUT M10 BS6	TATA spare parts
886344000415	WASHER BS6	TATA spare parts
886344000416	WASHER BS6	TATA spare parts
886344000417	STUD STRAIGHT CONNECTOR BS6	TATA spare parts
886344000418	PIPE CONNECTOR BS6	TATA spare parts
886344000419	BOLT M12x45 BS6	TATA spare parts
886344000420	STUD STRAIGHT CONNECTOR BS6	TATA spare parts
886344000421	JOINT BS6	TATA spare parts
886344000422	PIPE JOINT BS6	TATA spare parts
886344000423	PIPE JOINT BS6	TATA spare parts
886344000424	BOLT M16x55 BS6	TATA spare parts
886344000425	WASHER 16 BS6	TATA spare parts
886344000426	WASHER 16 BS6	TATA spare parts
886344000427	SPILT FLANGE BS6	TATA spare parts
886344000428	SCREW-M10X30 BS6	TATA spare parts
886344000429	PREVAILING TORQUE HEX NUT M12 BS6	TATA spare parts
886344000430	WASHER BS6	TATA spare parts
886344000431	SUPPORT ASSEMBLE TO WATER BS6	TATA spare parts
886344000432	BOLT BS6	TATA spare parts
886344000433	WASHER BS6	TATA spare parts
886344000434	RUBBER MAT BS6	TATA spare parts
886344000435	RUBBER BS6	TATA spare parts
886344000436	BOLT M8x35 BS6	TATA spare parts
886344000437	INNER JOINT BS6	TATA spare parts
886344000438	WATER PIPE BS6	TATA spare parts
886344000439	BEND BS6	TATA spare parts
886344000440	THROAT COLLAR BS6	TATA spare parts
886344000441	WATER PIPE2 BS6	TATA spare parts
886344000442	BLACK RUBBER HOSE BS6	TATA spare parts
886344000443	BLACK RUBBER HOSE BS6	TATA spare parts
886344000444	BLACK RUBBER HOSE 3 BS6	TATA spare parts
886344000445	BLACK RUBBER HOSE 4 BS6	TATA spare parts
886344000446	PLAIN WASHER BS6	TATA spare parts
886344000447	BOLT-M12X80 BS6	TATA spare parts
886344000448	WATER PUMP SEAL KIT BAC BS6	TATA spare parts
886344000449	WATER GAUGE ASSEMBLY BS6	TATA spare parts
886344000450	WASHER BS6	TATA spare parts
886344000451	PIPE CONNECTOR BS6	TATA spare parts
886344000452	TRANSPARENT TUBE BS6	TATA spare parts
886344000453	BOBBER BS6	TATA spare parts
886344000454	HOSE ASSEMBLY BS6	TATA spare parts
886344000455	WASHER BS6	TATA spare parts
886344000456	SPRING WASHER BS6	TATA spare parts
886344000457	NUT M6 GB6170 BS6	TATA spare parts
886344000458	BOLT M6X25 BS6	TATA spare parts
886344000459	NYLON BELTING BS6	TATA spare parts
886344000460	PUMP CABLE RH BS6	TATA spare parts

886344000461	ACCELERATION CABLE RH BS6	TATA spare parts
886344000462	HOSE LOOP BS6	TATA spare parts
886344000463	SUCTION HOSE BS6	TATA spare parts
886344000464	RETURN HOSE BS6	TATA spare parts
886344000465	SUCTION HOSE PIPE BS6	TATA spare parts
886344000466	RUBBER HOSE 1SN16-DKOL-600 Q/SY1102 BS6	TATA spare parts
886344000467	RUBBER HOSE-1SN16-DKOL-800Q/SY1102 BS6	TATA spare parts
886344000468	FITTING GES 18L M22X1.5 BS6	TATA spare parts
886344000469	U-BOLT SY5250GJB.5D-5-SY5250GJB8.5-9 BS6	TATA spare parts
886344000470	BOLT HHCS M 8X 25 DIN933- 8.8 BS6	TATA spare parts
886344000471	BOLT M12X55GB5783 BS6	TATA spare parts
886344000472	BOLT HHCS M 8X 20 DIN933- 8.8 BS6	TATA spare parts
886344000473	BOLT BS6	TATA spare parts
886344000474	CYLINDER ASSY HYD. (3400MM STROKE) BS6	TATA spare parts
886344000475	PLUNGER MOTOR	TATA spare parts
886344000476	REDUCTION GEAR	TATA spare parts
886344000477	RADIATOR KT	TATA spare parts
886344000478	RUBBER HOSE	TATA spare parts
886344000479	PLUNGER PUMP	TATA spare parts
886344000480	FLANGE SPLIT	TATA spare parts
886344000481	RUBBER HOSE	TATA spare parts
886344000482	MECHANICAL WATER PUMP	TATA spare parts
886344000483	V-BELT	TATA spare parts
886344000484	BALL VALVE	TATA spare parts
886344000485	STRAINER (DN40)	TATA spare parts
886344000486	BLACK RUBBER HOSE	TATA spare parts
886344000487	BLACK RUBBER HOSE	TATA spare parts
886344000488	BLACK RUBBER HOSE	TATA spare parts
886344000489	BLACK RUBBER HOSE	TATA spare parts
886344000490	COPPER BALL VALVE	TATA spare parts
886344000491	BLACK RUBBER HOSE	TATA spare parts
886344000492	BLACK RUBBER HOSE	TATA spare parts
886344000493	BLACK RUBBER HOSE	TATA spare parts
886344000494	WATER PUMP SEAL KIT	TATA spare parts
886344000495	PIPE CONNECTOR	TATA spare parts
886344000496	TRANSPARENT TUBE	TATA spare parts
886344000497	BOBBE	TATA spare parts
886344000498	HOSE ASSEMBLY	TATA spare parts
886344000499	FLAMEOUT CONTROL CABEL	TATA spare parts
886344000500	PUMP CABLE RH	TATA spare parts
886344000501	ACCELERATION CABLE RH	TATA spare parts
886344000502	PRESSURE HOSE 3/8INCH STRT X 600 BS6	TATA spare parts
886344000503	PRESSURE HOSE 3/8INCHIDX1400(90 END X S	TATA spare parts
886344000504	PRESSURE HOSE 3/8INCHIDX1000(90 END X S	TATA spare parts
886344000505	PUMP BRACKET CPL BS6	TATA spare parts
886344000506	CARDEN SHAFT HHS- LZ-420MM BS6	TATA spare parts
886344000507	FLANGE(WITH INTERNAL SPLINES) BS6	TATA spare parts

886344000508	DISC AD=57J6 ID=10.5 BS6	TATA spare parts
886344000509	HOLDING FOR JOINING SHAFT BS6	TATA spare parts
886344000510	HEX. SCREW M8X30 10.9 DIN 933 BS6	TATA spare parts
886344000511	LOCK WASHER 8 BS6	TATA spare parts
886344000512	SPACER FOR DRIVE SHAFT BS6	TATA spare parts
886344000513	HYD. HOSE DN25/4 X 1000 LG BS6	TATA spare parts
886344000514	PIPE ELBOW 90 DEG. DN 25 M42X2 BS6	TATA spare parts
886344000515	LOW PRESSURE HYD.HOSE DN 32X1400 SAER1 B	TATA spare parts
886344000516	GEAR BOX TYPE 577 L3 131A X1A BS6	TATA spare parts
886344000517	THREADED PIPE DN40 =123 STN 154 BS6	TATA spare parts
886344000518	TEES DN 40 B1 EN 10242 V BS6	TATA spare parts
886344000519	BOTH SIDE THREADED PIPE DN40 X 250STN154	TATA spare parts
886344000520	TEE DN 40-25-40 EN10242V BS6	TATA spare parts
886344000521	SCREW DIN 933 M 16 X 30-8.8-ZINC C. BS6	TATA spare parts
886344000522	DISC DIN 125 B 17-140HV-A3C BS6	TATA spare parts
886344000523	PIPE FITTING B DN25 = 73 BS6	TATA spare parts
886344000524	ELBOW DN25 A1 EN 10242 V BS6	TATA spare parts
886344000525	WATER HOSE (DN40) 48X6 =1000 BS6	TATA spare parts
886344000526	CAP DN 40 BS6	TATA spare parts
886344000527	SUCTION HOSE 1INCH IDX1080L	TATA spare parts
886344000528	SUCTION HOSE	TATA spare parts
886344000529	FILLER BREATHER ASSEMBLY BS6	TATA spare parts
886344000530	DRAIN PLUG KIT BS6	TATA spare parts
886344000531	SUCTION HOSE	TATA spare parts
886344000532	HYDRAULIC CONTROL VALVE BS6	TATA spare parts
886344000533	PRESSURE HOSE(3/8INCH X 3/8INCH) BS6	TATA spare parts
886344000534	G750 REAR MOUNTED PTO ONLY	TATA spare parts
886344000535	HYDRAULIC KIT BS6	TATA spare parts
886344000536	KIT-TIPPING CYLINDER WO PTO & PUMP BS6	TATA spare parts
886344000537	PTO KIT GB 1150 BS6	TATA spare parts
886344000538	GEAR PUMP 082L-LH-4H0-16BSP16 (14562127)	TATA spare parts
886344000539	PRESSURE HOSE BS6	TATA spare parts
886344000540	PRESSURE HOSE BS6	TATA spare parts
886344000541	CHECK VALVE BS6	TATA spare parts
886344000542	RLF EXTENSION PIPE 345L BS6	TATA spare parts
886344000543	OT MTG BASE PLT BS6	TATA spare parts
886344000544	HOSE 1INCHIDX2000 250BAR 1INCHBSP FS BS6	TATA spare parts
886344000545	HOSE 1INCHIDX4000 250BAR 1INCHBSP FS BS6	TATA spare parts
886344000546	PTO WITH PUMP( 4 SPEED) BS6	TATA spare parts
886344000547	AIR BREATHER ASSY BS6	TATA spare parts
886344000548	LP ADAPTER 90 ALU 1INCH-LP28+PART BS6	TATA spare parts
886344000549	LP ADAPTER 90 ALU 1*1/2INCH-LP28 BS6	TATA spare parts
886344000550	HEX. HEAD SCREW M5X10 - 8.8 BS6	TATA spare parts
886344000551	PLUG 1/2INCHBSP BS6	TATA spare parts
886344000552	QUICK RELEASE COUPLING L0-1201 BS6	TATA spare parts
886344000554	LADDER BS6	TATA spare parts
886344000555	HYDRAULIC CYLINDER ASSY BS6	TATA spare parts

886344000556	HEX HEAD SCREW M8X25 BS6	TATA spare parts
886344000557	HOSE PUMP TO VALVE BS6	TATA spare parts
886344000558	PISTON (DIA 105) BS6	TATA spare parts
886344000559	PISTON (DIA 72) BS6	TATA spare parts
886344000560	PISTON ROD BS6	TATA spare parts
886344000561	HEAD END COVER (DIA 120) BS6	TATA spare parts
886344000562	HEAD END COVER (DIA 90) BS6	TATA spare parts
886344000563	INNER PIPE BS6	TATA spare parts
886344000564	PISTON S/A BS6	TATA spare parts
886344000565	TUBE CE COVER S/A BS6	TATA spare parts
886344000566	SPARE SEAL KIT BS6	TATA spare parts
886344000567	SPARE SEAL KIT FOR 91-3-123 BS6	TATA spare parts
886344000568	STOP RING KIT (DIA 154 X 04)	TATA spare parts
886344000569	SUCTION HOSE BS6	TATA spare parts
886344000570	EMPTYING KIT - HYDRAULIC SYSTEM BS6	TATA spare parts
886344000571	TIPPING CYLINDER BS6	TATA spare parts
886344000572	LIFTING BKT LH BS6	TATA spare parts
886344000573	LIFTING BKT RH BS6	TATA spare parts
886344000574	OIL TANK BS6	TATA spare parts
886344000575	ELBOW 1 INCH BSPMX1 INCH SPFS BS6	TATA spare parts
886344000576	HOSE ROUTING CLAMP KIT DIA58 LONG BS6	TATA spare parts
886344000577	HP HOSE R2 3/4INCH DL60 BS6	TATA spare parts
886344000578	STAGE TUBE KIT DIA116 X 1345 BS6	TATA spare parts
886344000579	STAGE TUBE KIT DIA98 X 1355 (THREADED) B	TATA spare parts
886344000580	BASE PLATE O RING 149.3 X 5.7 BS6	TATA spare parts
886344000581	BASE PLATE SUPPORT RING 150.7BS6	TATA spare parts
886344000582	LOCKING PLATE 6 MM BS6	TATA spare parts
886344000583	HEXAGONAL BOLT M10 X 20 MM BS6	TATA spare parts
886344000584	SEAL KIT FOR STAGE TUBE DIA116 BS6	TATA spare parts
886344000585	OUTER RING KIT STAGE DIA 98 BS6	TATA spare parts
886344000586	COMPLETE PACKSET FOR 155-4 CYLINDER BS6	TATA spare parts
886344000587	COMPLETE OUTER RING KIT FOR 155-4 CYL. B	TATA spare parts
886344000588	COMPLETE LIFT RING KIT FOR 155-4 CYL. BS	TATA spare parts
886344000589	ROD EYE KIT BS6	TATA spare parts
886344000590	ROD EYE O RING DIA78 BS6	TATA spare parts
886344000591	DUST CAP BS6	TATA spare parts
886344000592	PTO+PUMP GBS 40	TATA spare parts
886344000593	FREE WHEEL LZQ-1-2	TATA spare parts
886344000594	OUTER RING KIT BS6	TATA spare parts
886344000595	BASE TUBE KIT BS6	TATA spare parts
886344000596	BASE TUBE KIT DIA 155 X 1483 ( C M ) BS6	TATA spare parts
886344000597	STAGE TUBE KIT DIA 135 X 1440 BS6	TATA spare parts
886344000598	STAGE TUBE KIT DIA 116 X 1440 BS6	TATA spare parts
886344000599	STAGE TUBE KIT DIA 98 X 1450 BS6	TATA spare parts
886344000600	BOTTOM BASE PLATE DIA 155 BS6	TATA spare parts
886344000601	BASE PLATE O RING DIA 129.3 X DIA 5.7 BS	TATA spare parts
886344000602	DUST CAP ( YELLOW ) BS6	TATA spare parts

886344000603	COMP.OUTER RING KIT 135-3 CYLINDER BS6	TATA spare parts
886344000604	COMP.LIFT RING KIT 135-3 CYLINDER BS6	TATA spare parts
886344000605	G750 V1 0.94 PTO	TATA spare parts
886344000606	RETURN LINE FILTER ASSEMBLY BS6	TATA spare parts
886344000607	FILLER BREATHER ELEMENT BS6	TATA spare parts
886344000608	RAM PROTECTION CAP BS6	TATA spare parts
886344000609	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000610	CYLINDER HEAD COVER BS6	TATA spare parts
886344000611	BREATHER TUBE BS6	TATA spare parts
886344000612	ENGINE OIL STRAINER BS6	TATA spare parts
886344000613	PACKING BREATHER CHAMBER BS6	TATA spare parts
886344000614	CAP BREATHER CHAMBER BS6	TATA spare parts
886344000615	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000616	SPARK PLUG BS6	TATA spare parts
886344000617	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000618	CYLINDER HEAD BS6	TATA spare parts
886344000619	STUD BS6	TATA spare parts
886344000620	GASKET FOR CYLINDER HEAD BS6	TATA spare parts
886344000621	STUD BS6	TATA spare parts
886344000622	OUTLET GASKET BS6	TATA spare parts
886344000623	CRANKCASE BODY BS6	TATA spare parts
886344000624	BEARING BS6	TATA spare parts
886344000625	FLAT WASHER BS6	TATA spare parts
886344000626	SEALING PLUG SCREW BS6	TATA spare parts
886344000627	OIL RULE COMBINATION BS6	TATA spare parts
886344000628	SIDE PLATE BS6	TATA spare parts
886344000629	CROSS RECESSED PAN HEAD SCREW BS6	TATA spare parts
886344000630	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000631	CRANKCASE COVER BS6	TATA spare parts
886344000632	PRESSING PLATE BS6	TATA spare parts
886344000633	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000634	CRANKCASE COVER GASKET BS6	TATA spare parts
886344000635	OCATION PIN BS6	TATA spare parts
886344000636	PISTON RING COMBINATION BS6	TATA spare parts
886344000637	PISTON BS6	TATA spare parts
886344000638	PISTON PIN BS6	TATA spare parts
886344000639	CONNECTING ROD BOLT BS6	TATA spare parts
886344000640	CONNECTING ROD BS6	TATA spare parts
886344000641	CRANKSHAFT BS6	TATA spare parts
886344000642	VALVE ROCKER COMBINATION BS6	TATA spare parts
886344000643	VALVE ROCKER SHAFT BS6	TATA spare parts
886344000644	SPLIT DAMPING RING BS6	TATA spare parts
886344000645	PUSH ROD BS6	TATA spare parts
886344000646	LIFTER VALVE BS6	TATA spare parts
886344000647	VALVE ADJUSTMENT CAP BS6	TATA spare parts
886344000648	RETAINER VALVE SPRING BS6	TATA spare parts
886344000649	VALVE OIL SEAL BS6	TATA spare parts

886344000650	CAMSHAFT ASSY BS6	TATA spare parts
886344000651	LOCATION WIRE NAIL BS6	TATA spare parts
886344000652	CABLE CLEAT BS6	TATA spare parts
886344000653	LOCATION WIRE NAIL BS6	TATA spare parts
886344000654	CARBURETOR GASKET BS6	TATA spare parts
886344000655	HEAT INSULATING PAD FOR CARBURETOR BS6	TATA spare parts
886344000656	CARBURETOR GASKET BS6	TATA spare parts
886344000657	CARBURETOR BS6	TATA spare parts
886344000658	CARBURETOR GASKET BS6	TATA spare parts
886344000659	CARBURETOR GASKET BS6	TATA spare parts
886344000660	HEXAGON NUT WITH FLANGE BS6	TATA spare parts
886344000661	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000662	AIR FILTER BRACKET BS6	TATA spare parts
886344000663	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000664	MUFFLER BODY BS6	TATA spare parts
886344000665	HEXAGON NUT BS6	TATA spare parts
886344000666	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000667	MUFFLER BRACKET BS6	TATA spare parts
886344000668	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000669	INVERTER ASSY BS6	TATA spare parts
886344000670	CUSHIONING RUBBER BS6	TATA spare parts
886344000671	INVERTER MOUNTING BRACKET BS6	TATA spare parts
886344000672	CUSHIONING RUBBER BS6	TATA spare parts
886344000673	ROPE SUPPORT BS6	TATA spare parts
886344000674	BATTERY CUSHION BS6	TATA spare parts
886344000675	STRAP BS6	TATA spare parts
886344000676	BATTERY BAFFLE BS6	TATA spare parts
886344000677	EARTH WIRE OF GENERAL-PURPOSE ENGINE BS6	TATA spare parts
886344000678	FRAME TOP COVER BS6	TATA spare parts
886344000679	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000680	FLAT WASHER BS6	TATA spare parts
886344000681	LINER TUBE OF TANK DAMPING CUSHION BS6	TATA spare parts
886344000682	TANK DAMPING CUSHION BS6	TATA spare parts
886344000683	TANK BS6	TATA spare parts
886344000684	OIL TUBE BS6	TATA spare parts
886344000685	CLIP COMBINATION BS6	TATA spare parts
886344000686	COMPONENTS OF OIL LEVEL BS6	TATA spare parts
886344000687	CROSS RECESSED COUNTERSUNK HEAD SCREW BS6	TATA spare parts
886344000688	SEAL RING BS6	TATA spare parts
886344000689	OIL LEVEL SIGHT GLASS BS6	TATA spare parts
886344000690	STARTING DISC BS6	TATA spare parts
886344000691	MOTOR FAN BS6	TATA spare parts
886344000692	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000693	COIL ASSY. IGNITION BS6	TATA spare parts
886344000694	PRESSING PLATE BS6	TATA spare parts
886344000695	FLAT WASHER BS6	TATA spare parts
886344000696	SOCKET HEAD SCREW BS6	TATA spare parts

886344000697	ELASTIC WASHER BS6	TATA spare parts
886344000698	LOCATION PIN BS6	TATA spare parts
886344000699	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000700	COMPONENTS OF STARTING MOTOR BS6	TATA spare parts
886344000701	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000702	COMPONENTS OF CONTROL PANEL BS6	TATA spare parts
886344000703	TARPAULIN BS6	TATA spare parts
886344000704	OUTLET BS6	TATA spare parts
886344000705	OUTLET BS6	TATA spare parts
886344000706	TARPAULIN BS6	TATA spare parts
886344000707	OUTLET BS6	TATA spare parts
886344000708	SLOTTED PAN HEAD SCREW WITH WAISTED SHAN	TATA spare parts
886344000709	CROSS RECESSED PAN HEAD TAPPING SCREW BS	TATA spare parts
886344000710	CONNECTING WIRE BS6	TATA spare parts
886344000711	HEXAGON NUT WITH FLANGE BS6	TATA spare parts
886344000712	CLIP NUT BS6	TATA spare parts
886344000713	SQUARE NUTS BS6	TATA spare parts
886344000714	HEXAGON BOLT WITH FLANGE BS6	TATA spare parts
886344000715	SUPPORT WHEEL STOP BLOCK BS6	TATA spare parts
886344000716	CAULKING BS6	TATA spare parts
886344000717	PIN CLIP BS6	TATA spare parts
886344000718	COMPONENTS OF SUPPORTING WHEEL BS6	TATA spare parts
886344000719	FLAT WASHER BS6	TATA spare parts
886344000720	COMPONENTS OF FRAME BS6	TATA spare parts
886344000721	SUPPORT WHEEL STOP ARM BS6	TATA spare parts
886344000722	OIL RELEASING RUBBE BS6	TATA spare parts
886344000723	MUFFLER GUARD SHIELD BS6	TATA spare parts
886344000724	MUFFLER GUARD SHIELD BS6	TATA spare parts
886344000725	LOCK WASHER BS6	TATA spare parts
886344000726	CUSHIONING RUBBER BS6	TATA spare parts
886344000727	PULL ROPE HANDLE BS6	TATA spare parts
886344000728	HEX HEAD FLANGE BOLT AXIAL BS6	TATA spare parts
886344000729	TANK DAMPING CUSHION BS6	TATA spare parts
886344000730	TANK DAMPING CUSHION BS6	TATA spare parts
886344000731	CUSHIONING RUBBER BS6	TATA spare parts
886344000732	HYDRAULIC STRAP TANK ASSEMBLY	TATA spare parts
886344000733	HYDRAULIC TANK S/A	TATA spare parts
886344000734	PNEUMATIC PUMP	TATA spare parts
886344000735	RETURN FILTER	TATA spare parts
886344000736	SEAL KIT	TATA spare parts
886344000737	SEAL KIT	TATA spare parts
886344000738	SEAL KIT	TATA spare parts
886344000739	SEAL KIT	TATA spare parts
886344000740	SEAL KIT	TATA spare parts
886344000741	SEAL KIT	TATA spare parts
886344000742	ROPE	TATA spare parts
886344000743	OIL GAUGE	TATA spare parts

886344000744	SUCTION HOSE	TATA spare parts
886344000745	PRESSURE HOSE	TATA spare parts
886344000746	SEAL KIT	TATA spare parts
886344000747	SEAL KIT	TATA spare parts
886344000748	LOAD HOLDING VALVE	TATA spare parts
886344000749	LIMIT SWITCH	TATA spare parts
886344000750	WIRING HARNESS KIT FOR SIDE MARKERS	TATA spare parts
886344000751	HYDRAULIC PUMP	TATA spare parts
886344000752	PTO	TATA spare parts
886344000753	GEAR PUMP	TATA spare parts
886344000754	HYDRAULIC KIT (PTT821004X048) BS6	TATA spare parts
886344000755	SEAL WASHER BS6	TATA spare parts
886344000756	RETURN LINE BANJO BOLT BS6	TATA spare parts
886344000757	RLF EXTENSION PIPE BS6	TATA spare parts
886344000758	HP HOSE R2 1 INCH STR 1 7/16 INCH 7/16 I	TATA spare parts
886344000759	PRESSURE ADAPTER KIT R1 INCH WITH EO SEA	TATA spare parts
886344000760	QUICK CHANGE COUPLING R1 INCH BS6	TATA spare parts
886344000761	BASE TUBE KIT DIA 197 X 1513 BS6	TATA spare parts
886344000762	STAGE TUBE KIT DIA 175 X 1470 BS6	TATA spare parts
886344000763	STAGE TUBE KIT DIA 155 X 1470 BS6	TATA spare parts
886344000764	STAGE TUBE KIT DIA 135 X 1470 BS6	TATA spare parts
886344000765	STAGE TUBE KIT DIA 116 X 1480 (THREADED)	TATA spare parts
886344000766	LOCK PLATE 3 BS6	TATA spare parts
886344000767	SEAL KIT - TANK MTD DCV BS6	TATA spare parts
886344000774	HYDRAULIC KIT BS6	TATA spare parts
886344000775	TIPPING CYLINDER GHS 175-4-4960C BS6	TATA spare parts
886344000776	PUMP ELBOW BS6	TATA spare parts
886344000777	HYDRAULIC OIL TANK 138 LTR FOR TIP TRAIL	TATA spare parts
886344000778	HYDRAULIC TANK BRACKET -HYVA FC 191 BS6	TATA spare parts
886344000779	2POS SOL OPERATED NO METALWORK BS6	TATA spare parts
886344000780	SEAL KIT BS6	TATA spare parts
886344000781	FC A110-3-02435-009-K0343HD-HC BS6	TATA spare parts
886344000782	HOSE 1 INCH IDX1065 R1 1 INCH 7/16 U BS6	TATA spare parts
886344000783	HOSE 3/4 INCH X1950 SAE100R2 ST-90 BS6	TATA spare parts
886344000784	ELBOW 3/4 INCH BSPX 1X3/16 INCH UNF ORS	TATA spare parts
886344000785	PINION SHAFT	TATA spare parts
886344000786	SERVICE DRUM PINION	TATA spare parts
886344000787	FLANCH CUPLING	TATA spare parts
886344000788	DRIVE HANDLE	TATA spare parts
886344000789	WATER TANK ASSEMBLY TM0601.5.2C BS6	TATA spare parts
886344000790	AIR BREATHER ASSY	TATA spare parts
886344000791	3 BUTTON SWITCH	TATA spare parts
886344600001	HOSE PIPE 4800 8D 275B	TATA spare parts
886344600002	HOSE PIPE 1000MM 16D 39B	TATA spare parts
886344600003	HOSE PIPE 1200MM 12D 215B	TATA spare parts
886344600004	HOSE PIPE 900MM 16D 88B	TATA spare parts
886344600005	HOSE PIPE 1050 8D 275B	TATA spare parts



886344600006	HOSE PIPE 300 8D 275B	TATA spare parts
886344600007	HOSE PIPE 1400 8D 275B	TATA spare parts
886344600008	HOSE PIPE 1050 8D 275B	TATA spare parts
886344600009	CONTROL VALVE 3 SPOOL	TATA spare parts
886344600010	DUAL COUNTER BALANCE VALVE	TATA spare parts
886344800001	TEE HEAD ASSY	TATA spare parts
886344800002	FLOW CONTROL VALVE	TATA spare parts
886344800003	HOSE-3/4 1100L	TATA spare parts
886344800004	ADAPTOR 1/4 INBSP M X3/8 INBSP	TATA spare parts
886344800005	ELBOW 3/8 BSP X 1/4 BSP FS	TATA spare parts
886344800006	ADAPTOR 1/2INBSPX1 X 3/16INUNF	TATA spare parts
886344800007	HOSE	TATA spare parts
886344800008	ADAPTOR	TATA spare parts
886344800009	HOSE	TATA spare parts
886344800010	SEAMLESS TUBE	TATA spare parts
886344800011	ADAPTOR	TATA spare parts
886344800012	PULLING PIPE ASSEMBLY	TATA spare parts
886344800013	HINGE PIN TD & CYL. EYE	TATA spare parts
886344800014	HINGE PIN TAIL GATE CYL	TATA spare parts
886344800015	TAILDOOR CYLINDER	TATA spare parts
886344800016	SEAL KIT	TATA spare parts
886344800017	COMPLETE SEAL KIT	TATA spare parts
886344800018	SUCTION HOSE	TATA spare parts
886344800019	CARTRIDGE PRES. RELIEF HT 170 BAR MK2	TATA spare parts
886344800020	TIPPING CYLINDER	TATA spare parts
886344800021	PTO G750 V1 TYPE	TATA spare parts
886344800022	HYDRAULIC PIPE(HYD. CYLINDER TO HYD. TAN	TATA spare parts
886344800023	GASKET (PUMP/PTO)	TATA spare parts
886344800024	HOSE TANK TO PUMP	TATA spare parts
886344800025	SEAL KIT COMPLETE FOR TIPPING CYLINDER	TATA spare parts
886344800026	DIRECTIONAL CONTROL VALVE	TATA spare parts
886344800027	HOSE 1INCHIDX4000 250BAR 1INCHBSP FS	TATA spare parts
886344800028	FE A169-4-4825-001-K1529-HD-HC	TATA spare parts
886344800029	HOSE 1INCHIDX2000 250BAR 1INCHBSP FS	TATA spare parts
886344800030	GEAR PUMP 84 LT	TATA spare parts
886344800031	SEAL KIT COMPLETE	TATA spare parts
886344800036	QUICK RELEASE COUPLING L0-1201	TATA spare parts
886344800037	PTO G1150+QUILL SHAFT	TATA spare parts
886344800038	GEAR PUMP 82L (14562325)	TATA spare parts
886344800042	HYFIX+LOCK BAR KIT	TATA spare parts
886344800044	LINEAR SPOOL VALVE	TATA spare parts
886344800045	CYLINDER	TATA spare parts
886344800046	FOLDABLE RAMP	TATA spare parts
886345000001	PNEUMATIC ACTUATOR	TATA spare parts
886345000002	PNEUMATIC SYSTEM CPL. - JCV (JPS 1473) B	TATA spare parts
886345000003	PU TUBE 12 DIA BS6	TATA spare parts
886345000004	MALE ELBOW DIA.12 X 1/2INCH BS6	TATA spare parts

88634500005	HYDER CLAMP - 12S BS6	TATA spare parts
88634600001	THREADED BALL JOINT RH	TATA spare parts
88634600002	BOLT M10X1.25 BS6	TATA spare parts
88634600003	UNIVERSAL JOINT BS6	TATA spare parts
88634600004	NYLOCK NUT BS6	TATA spare parts
88634700001	FUEL TANK GUARD ASSLY	TATA spare parts
88634700002	SHELL ASY	TATA spare parts
88634700003	HEATER & THERMOSTAT	TATA spare parts
88634700004	O RING	TATA spare parts
88634700005	HEAD ASY	TATA spare parts
88634700006	KIT-DRAIN PLUG BS6	TATA spare parts
88634700007	KIT-ROLLOVER VALVE WITH BREATHER TUBE BS	TATA spare parts
88634700008	DIESEL TANK JOLLY - M38 / 640 BS6	TATA spare parts
88634700009	DIESEL TANK JOLLY - 530MM LG. BS6	TATA spare parts
88634700010	BANJO BOLT REDUCTION M/F BS6	TATA spare parts
88634700011	METAL BRAIDED HOSE 14MM X 8MM 2MTR BS6	TATA spare parts
88634700012	BANJO BOLT 14MM BS6	TATA spare parts
88634700013	SEALING RING A 14 X 20 CU BS6	TATA spare parts
88634700014	SEALING RING A 8X11.5(CU) BS6	TATA spare parts
88634700015	CAMLOCK COUPLING COVER	TATA spare parts
88634700016	DIESEL TANK JOLLY M38-590 LG. BS6	TATA spare parts
88634900001	VERTICAL EXHAUST (EGP) TOOLBS6	TATA spare parts
88634900002	FLYWHEEL ROTATING & LOCKING TOOLBS6	TATA spare parts
88634900003	SUCTION / RESTRICTION TEST TOOL (GAUGE I	TATA spare parts
88634900004	DEF LINE CLEANING TOOLBS6	TATA spare parts
88634900005	DOSING UNIT PRESSURE GAUGE BS6	TATA spare parts
88634900006	DOSING VALVE PRESSURE GAUGE BS6	TATA spare parts
88634900007	DEF TANK & DOSING VALVE RETURN LINE PRES	TATA spare parts
88634900008	DEF TANK HEADER REMOVAL TOOL BS6	TATA spare parts
88634900009	ATS REMOVAL HYDRAULIC TROLLEY BS6	TATA spare parts
88634900010	TUBE AIR VENT BS6	TATA spare parts
88634900011	AIR VENT BS6	TATA spare parts
88634900012	AFTER TREATMENT SYSTEM ASSY BS6	TATA spare parts
88635000002	RADIATOR COMPLETE TATA ACE/ MAGIC	TATA spare parts
88635000003	ASSY. RESERVE TANK	TATA spare parts
88635000004	ASSY RADIATOR	TATA spare parts
88635000005	L TYPE RADIATOR HOSE WITH 25 MM ID	TATA spare parts
88635000006	RECOVERY BOTTLE ASSY	TATA spare parts
88635000007	OIL CASE KIT BS6	TATA spare parts
88635000008	OIL COOLER FAN	TATA spare parts
88635000009	FILTER UNIT	TATA spare parts
88635000010	FILTER UNIT ELEMENT	TATA spare parts
88635000011	TEMPERATURE CONTROL SWITCH	TATA spare parts
88635000012	VACUUM METER	TATA spare parts
88635000013	OUTLET PIPE BS6	TATA spare parts
88635000014	RADIATOR CAPS 9976428H	TATA spare parts
88635000015	KIT FOR COOLING SYSTEM (RADIATOR)	TATA spare parts

88635400001	DC-DC CONVERTER 24V TO 12V	TATA spare parts
88635400002	TAIL LAMP WITH NUMBER PLATE	TATA spare parts
88635400003	ROOF LAMP	TATA spare parts
88635400004	FRONT ROOF MARKER LAMP	TATA spare parts
88635400005	REAR ROOF MARKER LAMP	TATA spare parts
88635400006	SIDE MARKER LAMP	TATA spare parts
88635400007	BAR LIGHT	TATA spare parts
88635400008	Side Marker lamp	TATA spare parts
88635400009	SIDE MARKER LAMP	TATA spare parts
88635400010	Budget lock cover	TATA spare parts
88635400011	ROOF LAMP	TATA spare parts
88635400012	HEAD LAMP LH 24V (WITH PARKING)	TATA spare parts
88635400013	HEAD LAMP RH 24V (WITH PARKING)	TATA spare parts
88635400014	HEAD LAMP LH 24V (WITHOUT PARKING)	TATA spare parts
88635400015	HEAD LAMP RH 24V (WITHOUT PARKING)	TATA spare parts
88635400016	FRONT BLINKER LH 24V	TATA spare parts
88635400017	FRONT BLINKER RH 24V	TATA spare parts
88635400018	TAIL LAMP 24V (RED)	TATA spare parts
88635400019	TAIL LAMP 24V (YELLOW)	TATA spare parts
88635400020	ROOF LAMP	TATA spare parts
88635400021	TAIL LAMP 24V (WHITE)	TATA spare parts
88635400022	HEIGHT MARKER WHITE	TATA spare parts
88635400023	SIDE MARKER	TATA spare parts
88635400024	DESTINATION BOARD 1800MM	TATA spare parts
88635400025	HIGH MOUNT STOP LAMP	TATA spare parts
88635400026	WIRING HARNESS FOR CONTROL PANEL	TATA spare parts
88635400027	NUMBER PLATE LIGHT	TATA spare parts
88635400028	FRONT HEIGHT MARKER WHITE 12V	TATA spare parts
88635400029	HEAD LAMP 12V	TATA spare parts
88635400030	FOG LAMP 12V	TATA spare parts
88635400031	REAR HEIGHT MARKER 12V	TATA spare parts
88635400032	TAIL LIGHT 12V -COASTER	TATA spare parts
88635400033	BRAKE LIGHT	TATA spare parts
88635400034	PANEL LOCK WITH SIDE MARKER	TATA spare parts
88635400035	SIDE MARKER 12V	TATA spare parts
88635400036	DRIVER FAN 12V	TATA spare parts
88635400037	DRIVER CABIN LIGHT 12V	TATA spare parts
88635400038	ROOF STRIP LIGHT	TATA spare parts
88635400039	SPEAKER	TATA spare parts
88635400040	SIDE INDICATOR	TATA spare parts
88635400041	FLASHER LIGHT RED	TATA spare parts
88635400042	FLASHER LIGHT ORENGE	TATA spare parts
88635400043	FOCUS LIGHT	TATA spare parts
88635400044	REAR ROOF MARKER LAMP	TATA spare parts
88635400045	SIDE MARKER LAMP 12 V	TATA spare parts
88635400046	TOP MARKER LAMP 12 V	TATA spare parts
88635400047	WIRE HARNESS RH	TATA spare parts

886354000048	WIRE HARNESS LH	TATA spare parts
886354000049	SIDE INDICATOR LIGHT (6 NOS)	TATA spare parts
886354000050	WIRING HARNESS	TATA spare parts
886354000051	SIDE INDICATOR LIGHT (6 NOS)	TATA spare parts
886354000052	WIRING HARNESS	TATA spare parts
886354000053	WIRE HARNESS	TATA spare parts
886354000054	SIDE INDICATOR LIGHT	TATA spare parts
886354000055	WIRING HARNESS	TATA spare parts
886354000056	SIREN 12V	TATA spare parts
886354000057	SIREN 24V	TATA spare parts
886354000058	SIDE INDICATOR LIGHT	TATA spare parts
886354000059	WIRING HARNESS	TATA spare parts
886354000060	TAIL GATE ASSEMBLY	TATA spare parts
886354000061	AC FUSE BOX	TATA spare parts
886354000062	AC INVERTER 800VA	TATA spare parts
886354000063	BECON LAMP UNIT	TATA spare parts
886354000064	BODY FUSE BOX	TATA spare parts
886354000065	SWITCH BOARD (4 ROOF LAMP 3 FAN & 1 BUZ	TATA spare parts
886354000066	NO.PLATE LIGHT	TATA spare parts
886354000067	INTERCOM SYSTEM	TATA spare parts
886354000068	SIREN	TATA spare parts
886354000069	HEATER	TATA spare parts
886354000070	ROUND ROOF LAMP	TATA spare parts
886354000071	FOOT OPERATED PANEL	TATA spare parts
886354000075	THIRD BRAKE LAMP	TATA spare parts
886354000076	SIDE DIRECTION INDICATOR	TATA spare parts
886354000077	RESISTOR 24 V	TATA spare parts
886354000078	SIDE INDICATOR LIGHT	TATA spare parts
886354000079	CABIN LIGHTS	TATA spare parts
886354000080	TOP MARKER LAMPS	TATA spare parts
886354000081	FRONT FOG LAMPS	TATA spare parts
886354000082	FOUR POLE SWITCH(PIANO SWITCH)	TATA spare parts
886354000083	FLASHER LIGHT	TATA spare parts
886354000084	ELECTRONIC TESTING KIT FOR AVM2PCDETK-01	TATA spare parts
886354000086	FST DC CHARGER 120KW GB/T TYPE DUAL CONN	TATA spare parts
886354000087	SLOW CHARGER 60KW GB/T TYPE SINGLE CONNE	TATA spare parts
886354000088	PCB MASTER-F/DEST N BOARD-CMM	TATA spare parts
886354000089	MASTER PCB NS(091510-11010)	TATA spare parts
886354000090	CONVERTER-DC TO DC-24V/3.3V-CMM	TATA spare parts
886354000091	PCB MASTER-R/S DEST N BOARD-CMM	TATA spare parts
886354000092	KEY PAD FRONT PANEL ICU 600-CMM	TATA spare parts
886354000093	TOP MARKER LAMP GUARD ASSLY	TATA spare parts
886354000094	ROOF LAMP	TATA spare parts
886354000095	FOG LAMP	TATA spare parts
886354000096	SIDE MARKER LAMP	TATA spare parts
886354000097	SIDE MARKER LAMP	TATA spare parts
886354000098	TOP MARKER LAMP	TATA spare parts

88635400099	SIDE MARKER COVER	TATA spare parts
886354000100	TOP MARKER LAMP COVER	TATA spare parts
886354000101	WIRING HARNESS -14 CUM BOX (LPK2518/38)	TATA spare parts
886354000102	SIDE MARKER LAMP	TATA spare parts
886354000103	LIGHT STOP	TATA spare parts
886354000105	DIAPHRAGM	TATA spare parts
886354000106	CONDENSER	TATA spare parts
886354000107	GASKET	TATA spare parts
886354000108	ASSY PA SYSTEM	TATA spare parts
886354000109	BALILIGHT WITH SIREN( BLUE COLOUR)	TATA spare parts
886354000110	FLASHER LIGHT RED	TATA spare parts
886354000111	TUBE LIGHT WITH N/L 24V LED	TATA spare parts
886354000112	HEAD LIGHT LOW BEAM 24V WITH BULB	TATA spare parts
886354000113	HEAD LIGHT 24V H4 WITH BULB	TATA spare parts
886354000114	RED 95 DIA. ROUND TAIL & STOP LAMP LED 2	TATA spare parts
886354000115	WHITE 95 DIA. ROUND REVERSE LAMP LED 24V	TATA spare parts
886354000116	AMBER 95 DIA. ROUND REAR BLINKER LAMP LE	TATA spare parts
886354000117	FRONT DIRECTION INDICATOR ROUND	TATA spare parts
886354000118	MEDICAL BINS ( SET OF 6 )	TATA spare parts
886354000119	HUMIDIFIER BOTTLE WITH FLOW METER SET	TATA spare parts
886354000120	AMPLIFIER	TATA spare parts
886354000121	TAB CHARGING CONNECTOR	TATA spare parts
886354000122	TOUCH SCREEN DISPLAY	TATA spare parts
886354000123	ROOF LIGHT	TATA spare parts
886354000124	SHOLPHIN LIGHT BAR (SI-108) CLEAR LENS	TATA spare parts
886354000125	SIREN	TATA spare parts
886354000126	WIRE HARNESS ROOF LP 407/34	TATA spare parts
886354000127	EMERGENCY LIGHTING SYSTEM - 24V	TATA spare parts
886354000128	SIDE LIGHT ASSY¿ LED TYPE	TATA spare parts
886354000129	FUSE 250 AMP + WIRE HARNESS	TATA spare parts
886354000130	ROOF LAMP	TATA spare parts
886354000131	ROOF LAMP	TATA spare parts
886354000132	FRONT ROOF MARKER LAMP	TATA spare parts
886354000133	FRONT ROOF MARKER LAMP	TATA spare parts
886354000134	REAR ROOF MARKER LAMP	TATA spare parts
886354000135	SIREN LIGHT	TATA spare parts
886354000136	SOUND BUZZER	TATA spare parts
886354000137	WIRING HARNESS	TATA spare parts
886354000138	SWITCH BOARD	TATA spare parts
886354000139	OEM RELAY 35AMP 24 VOLT	TATA spare parts
886354000143	SPC-D-W-MP4-63/100(SPC63)	TATA spare parts
886354000144	SPC-D-W-MP4-50/100-SU (SPC50)	TATA spare parts
886354000145	SVAJ214 - 24VDC (9040012012)	TATA spare parts
886354000146	8 LED BLINKERS	TATA spare parts
886354000147	PATIENT CABIN ROOF LED LIGHT	TATA spare parts
886354000148	PATIENT CABIN SPOT LIGHT	TATA spare parts
886354000149	CAOCH FAN	TATA spare parts

886354000150	EMERGENCY LED LIGHT BAR AIS-125	TATA spare parts
886354000151	AMPLIFIER	TATA spare parts
886354000152	4 LED BLIKERS	TATA spare parts
886354000153	WORK LAMP	TATA spare parts
886354000154	EXTERNAL POWER SOCKET	TATA spare parts
886354000155	12V SOCKETS	TATA spare parts
886354000156	PIANO SWITCH	TATA spare parts
886354000157	INVERTER 850VA	TATA spare parts
886354000158	REAR DOOR OPEN ALARM SWITCH	TATA spare parts
886354000159	REAR DOOR SIREN	TATA spare parts
886354000160	HUMIDIFIER BOTTLE WITH FLOW METER SET	TATA spare parts
886354000161	PATIENT CABIN ROOF LED LIGHT	TATA spare parts
886354000162	PATIENT CABIN LAMP	TATA spare parts
886354000163	PATIENT CABIN SPOT LIGHT	TATA spare parts
886354000164	FANS	TATA spare parts
886354000165	EMERGENCY ROOF LED BAR	TATA spare parts
886354000166	AMPLIFIER	TATA spare parts
886354000167	3 LED BASE BLINKERS	TATA spare parts
886354000168	8 LED BASE BLINKERS	TATA spare parts
886354000169	WORK LAMP	TATA spare parts
886354000170	EXTERNAL POWER SOCKET	TATA spare parts
886354000171	SOCKETS 12V	TATA spare parts
886354000172	SWITCHES	TATA spare parts
886354000173	INVERTER	TATA spare parts
886354000174	DOOR OPEN ALARM SWITCH	TATA spare parts
886354000175	REAR DOOR SIREN	TATA spare parts
886354000176	HUMIDIFIER BOTTLE WITH FLOW METER SET	TATA spare parts
886354000177	PATIENT CABIN ROOF LED LIGHT	TATA spare parts
886354000178	PATIENT EXAMINATION LIGHT	TATA spare parts
886354000179	PATIENT CABIN SPOT LIGHT	TATA spare parts
886354000180	FANS	TATA spare parts
886354000181	EMERGENCY ROOF LED BAR	TATA spare parts
886354000182	AMPLIFIER	TATA spare parts
886354000183	3 LED BASE BLINKERS	TATA spare parts
886354000184	8 LED BASE BLINKERS	TATA spare parts
886354000185	WORK LAMP	TATA spare parts
886354000186	EXTERNAL POWER SOCKET	TATA spare parts
886354000187	SOCKETS 12V	TATA spare parts
886354000188	SWITCHES	TATA spare parts
886354000189	INVERTER	TATA spare parts
886354000190	DOOR OPEN ALARM SWITCH	TATA spare parts
886354000191	REAR DOOR SIREN	TATA spare parts
886354000192	HUMIDIFIER BOTTLE WITH FLOW METER SET	TATA spare parts
886354000193	FLASHER LIGHT RED	TATA spare parts
886354000194	FASHER LIGHT ORRANGE	TATA spare parts
886354000195	SPOT LIGHT WITHOUT FRP BOX	TATA spare parts
886354000196	BAR LIGHT WITH SIRENç BLUE COLOUR	TATA spare parts

886354000197	WIRING HARNESS 24CUM TIPPER	TATA spare parts
886354000198	WIRING HARNESS _1613/42	TATA spare parts
886354000199	WIRING HARNESS(SD1015/1628) .	TATA spare parts
886354000200	OIL COOLER FAN	TATA spare parts
886354000201	THERMOSWITCH 55-50 ?	TATA spare parts
886354000202	VACUUM METERS4.Y-40	TATA spare parts
886354000203	HOUR METER	TATA spare parts
886354000204	RELAY	TATA spare parts
886354000205	12V-STARTER RELAY	TATA spare parts
886354000206	BAR LIGHT BLUE WITH PA SYSTEMç - 12V	TATA spare parts
886354000207	EMERGENCY LIGHT BAR SIREN UNIT	TATA spare parts
886354000208	TOP MARKER LAMP	TATA spare parts
886354000209	TAIL LAMP	TATA spare parts
886354000210	TAIL DOOR HINGE PIN	TATA spare parts
886354000211	INSIDE LIGHT (LED)	TATA spare parts
886354000212	SIDE MARKER LAMP (LED)	TATA spare parts
886354000213	TOP MARKER LAMP	TATA spare parts
886354000214	WALL MOUNTED MOBILE USB CHARGER SOCKET	TATA spare parts
886354000215	HYDRAULIC KIT WIPRO	TATA spare parts
886354000216	ASSY H/L W/ HLLA W/O DRL(LHD)LH-24V	TATA spare parts
886354000217	ASSY H/L W/ HLLA W/O DRL(LHD)RH-24V	TATA spare parts
886354000219	PCB SLAVE-F/DEST N BOARD-CMM	TATA spare parts
886354000220	PCB SLAVE-R/S DEST N BOARD-CMM	TATA spare parts
886354000221	HEIGHT MARKER (FRONT)	TATA spare parts
886354000222	REAR HEIGHT MARKER	TATA spare parts
886354000223	NUMBER PLATE LIGHT	TATA spare parts
886354000224	FAN	TATA spare parts
886354000225	ROOF LIGHT	TATA spare parts
886354000226	MODULISE GANGBOX WITH SOCKET & SWITCH	TATA spare parts
886354000227	INVERTOR+BATTERY	TATA spare parts
886354000228	DIGITAL CLOCK	TATA spare parts
886354000229	MP3 PLAYER	TATA spare parts
886354000230	BUZZER	TATA spare parts
886354000231	ELECTRICAL WIRING HARNESS	TATA spare parts
886354000232	LCD DISPLAY (ICU-600) W/O BACK COVER	TATA spare parts
886354000233	CONTROLLER PCB BOARD	TATA spare parts
886354000234	EMERGENCY LED LIGHT BAR AIS-125 BS6	TATA spare parts
886354000235	RED & BLUE BLINKER BS6	TATA spare parts
886354000236	AMPLIFIER BS6	TATA spare parts
886354000237	SIDE MARKER LAMP(KIRAN LIGHT)	TATA spare parts
886354000238	REFLECTOR	TATA spare parts
886354000239	DOOR LIGHT BS6	TATA spare parts
886354000240	KEY SWITCH 24V DC BS6	TATA spare parts
886354000241	LIGHT BAR BS6	TATA spare parts
886354000242	WIRING HARNESS TIPPING BS6	TATA spare parts
886354000243	BLUE BLINKER BS6	TATA spare parts
886354000244	AMBER BLINKER BS6	TATA spare parts

886354000245	MCB FOR BMS	TATA spare parts
886354000246	MCB FOR PORT CONTROLLER	TATA spare parts
886354000247	RFID READER	TATA spare parts
886354000248	TOUCH SCREEN	TATA spare parts
886354000249	MPU	TATA spare parts
886354000250	INSULATION MONITOR 60KW	TATA spare parts
886354000251	INSULATION MONITOR 120KW	TATA spare parts
886354000252	AC - DC CONVENOR (12V)	TATA spare parts
886354000253	AC - DC CONVERTOR (24V)	TATA spare parts
886354000254	RELAY (12-24V 200A)	TATA spare parts
886354000255	RELAY (12-24V 150A)	TATA spare parts
886354000256	SHUNT (60KW)	TATA spare parts
886354000257	SHUNT (120KW)	TATA spare parts
886354000258	SMPS POWER MODULES (20KW)	TATA spare parts
886354000259	GBT GUN 125AMPS	TATA spare parts
886354000260	GBT GUN 250AMPS	TATA spare parts
886354000261	THERMOSTAT	TATA spare parts
886354000262	AC ENERGY METER	TATA spare parts
886354000263	DC ENERGY METER (750V 300A)	TATA spare parts
886354000264	SURGE ARRESTOR	TATA spare parts
886354000265	MCCB AND RCB (125AMPS 30MA)	TATA spare parts
886354000266	MCCB AND RCB ( 250AMPS 30MA)	TATA spare parts
886354000267	MCB (40A 3-POLE)	TATA spare parts
886354000268	MCB (16A 2-POLE)	TATA spare parts
886354000269	CT (200/5)AMPS	TATA spare parts
886354000270	EXHAUST FANS	TATA spare parts
886354000271	SOLPHIN JUNCTION BOX BS6	TATA spare parts
886354000272	DRIVER CABIN 4LED BLINKER FRP COVER BS6	TATA spare parts
886354000273	WORK LAMP FRP COVER BS6	TATA spare parts
886354000274	EXTERNAL POWER SOCKET FRP COVER BS6	TATA spare parts
886354000275	REVOLVING LIGHT BS6	TATA spare parts
886354000276	SIREN WITH PA SYSTEM BS6	TATA spare parts
886354000277	AMPLIFIER FRP COVER BS6	TATA spare parts
886354000279	CONNECTORS (3 4 6 9 LINK )	TATA spare parts
886354000280	AIR FILTERS	TATA spare parts
886354000281	ACRYLIC SHEETS	TATA spare parts
886354000282	EMERGENCY BUTTON	TATA spare parts
886354000283	PANEL LOCKS	TATA spare parts
886354000284	KEYS	TATA spare parts
886354000285	RED AND BLUE LIGHT BAR WITH HOOTER ASSY	TATA spare parts
886354000286	LIGHT BARS1-108 TRIUMPSHOLPHIN BS6	TATA spare parts
886354000287	LIGHT BARSIPHON BS6	TATA spare parts
886354000288	AMPLIFIERSE/MF-5 BS6	TATA spare parts
886354000289	AMPLIFIERSI-108 TRIUMP BS6	TATA spare parts
886354000290	AMPLIFIERSIPHON BS6	TATA spare parts
886354000291	INVERTER BS6	TATA spare parts
886354000292	RED BLINKER SE/MF-5 BS6	TATA spare parts



886354000293	RED BLINKER SI-108 TRIUMP BS6	TATA spare parts
886354000294	RED BLINKER SIPHON BS6	TATA spare parts
886354000295	BLUE BLINKER SI-108 TRIUMP BS6	TATA spare parts
886354000296	BLUE BLINKER SIPHON BS6	TATA spare parts
886354000297	AMBER BLINKER SI-108 TRIUMP BS6	TATA spare parts
886354000298	AMBER BLINKER SIPHON BS6	TATA spare parts
886354000299	RED & BLUE BLINKERSI-108 TRIUMP BS6	TATA spare parts
886354000300	RED & BLUE BLINKERSIPHON BS6	TATA spare parts
886354000301	MCB 1 BS6	TATA spare parts
886354000302	MCB 2 BS6	TATA spare parts
886354000303	JUNCTION BOXSIPHON BS6	TATA spare parts
886354000304	SOLENOID COIL 24V	TATA spare parts
886354000305	SIDE MARKER LAMP BS6	TATA spare parts
886354000306	FRONT ROOF MARKER LAMP BS6	TATA spare parts
886354000307	REAR ROOF MARKER LAMP BS6	TATA spare parts
886354000308	NUMBER PLATE LIGHT BS6	TATA spare parts
886354000309	NIGHT LIGHT BS6	TATA spare parts
886354000310	ROOF LAMP BS6	TATA spare parts
886354000311	HOOTER BLINKER BS6	TATA spare parts
886354000312	INDICATOR BS6	TATA spare parts
886354000313	WIRE HARNESS BS6	TATA spare parts
886354000314	WIRE HARNESS BS6	TATA spare parts
886354000315	SIDE MARKER LAMP 12 V BS6	TATA spare parts
886354000316	TOP MARKER LAMP 12 V BS6	TATA spare parts
886354000317	WIRE HARNESS AC BS6	TATA spare parts
886354000318	WIRE HARNESS DC BS6	TATA spare parts
886354000319	FAN BS6	TATA spare parts
886354000320	DC ROOF LIGHT 12V DC BS6	TATA spare parts
886354000321	GRAND BOX BS6	TATA spare parts
886354000322	ROOF LIGHT 36W AC BS6	TATA spare parts
886354000323	8 POLE MODULAR BOX BS6	TATA spare parts
886354000324	CHANGE OVER 60AMP BS6	TATA spare parts
886354000325	POLE MCB BOX BS6	TATA spare parts
886354000326	NO. PLATE LIGHT BS6	TATA spare parts
886354000327	GENSET BS6	TATA spare parts
886354000328	REAR ROOF MARKER LAMP BS6	TATA spare parts
886354000329	ROOF LAMP BS6	TATA spare parts
886354000330	VIDEO CAMERA BS6	TATA spare parts
886354000331	ELECTRICAL WIRING HARNESS BS6	TATA spare parts
886354000332	FAST CHARGER 200KW DC GB/T	TATA spare parts
886354000333	BAR LIGHT WITH PA SYSTEM BS6	TATA spare parts
886354000334	MTSL LAUNCHER BS6	TATA spare parts
886354000335	COMMANDO LIGHT BS6	TATA spare parts
886354000336	ELECTRICAL WIRING HARNESS BS6	TATA spare parts
886354000337	CHIP-FUSE -10A	TATA spare parts
886354000338	CHIP FUSE - 20A	TATA spare parts
886354000339	DIGITAL HOUR METER	TATA spare parts

886354000340	RELAY-37N-35095B	TATA spare parts
886354000341	KEYLO BASE STATION	TATA spare parts
886354000342	BAR LIGHT BS6	TATA spare parts
886354000343	HOOTER BLINKER BS6	TATA spare parts
886354000344	GPS BS6	TATA spare parts
886354000345	INTERCOM SYSTEM BS6	TATA spare parts
886354000346	WIRE HARNESS BS6	TATA spare parts
886354000347	WIRE HARNESS BS6	TATA spare parts
886354000348	WIRE HARNESS BS6	TATA spare parts
886354000349	WIRE HARNESS BS6	TATA spare parts
886354000350	ROUTE BOARD HARNESS BS6	TATA spare parts
886354000351	WIRE HARNESS BS6	TATA spare parts
886354000352	REMOTE CONTROL CABLE L=5.8M BS6	TATA spare parts
886354000353	TRANSMITTER SINGLE BS6	TATA spare parts
886354000354	HEX.HEAD SCREW DIN 933 M 6 X 55-8.8-A2C	TATA spare parts
886354000355	DISC 8 4 DIN 125 VERZ.ST BS6	TATA spare parts
886354000356	MULTI CORE CABLE 2 X 2.5 SQ.MM BS6	TATA spare parts
886354000357	MULTI CORE CABLE 2X1SQ.MM OLEFLEX C100 B	TATA spare parts
886354000358	PROTECTION HOSE-SILVYN RILL PA9-BLACK BS	TATA spare parts
886354000359	MCB SP 25A - 5SX41257RC BS6	TATA spare parts
886354000360	GLASS FUSE 5A 24V DC (SIZE 5X20) BS6	TATA spare parts
886354000361	FUSED TERMINAL BLOCK WITH LED 12-24V DC	TATA spare parts
886354000362	WORKING REFLECTOR CPL 24V BS6	TATA spare parts
886354000363	SELECTOR SWITCH 1NO+1NC 24VDC BLACK 22.5	TATA spare parts
886354000364	TERMINAL BOX 200X150X80 - KL1528.510 BS6	TATA spare parts
886354000365	LADDER LAMP SWITCH BOX ASSEMBLY. BS6	TATA spare parts
886354000366	LADDER LAMP SWITCH BOX BRACKET BS6	TATA spare parts
886354000367	SINGLE TERMINAL 5SQ.MM UK5N BS6	TATA spare parts
886354000368	END BRACKET E/UK BS6	TATA spare parts
886354000369	SELF TAP SCREW M5 WITH DRILLING EDGE BS6	TATA spare parts
886354000370	CABLE SHOES WITH PLASTIC SLLEVE 1SQ.MM B	TATA spare parts
886354000371	FOG LAMP BS6	TATA spare parts
886354000372	FDSS BS6	TATA spare parts
886354000373	DISPLAY CONTROLLER BS6	TATA spare parts
886354000374	PA SYSTEM BS6	TATA spare parts
886354000375	REAR CAMERA WITH SCREEN BS6	TATA spare parts
886354000376	SPEAKER BS6	TATA spare parts
886354000377	MIC BS6	TATA spare parts
886354000378	BAR LIGHT FRP COVER BS6	TATA spare parts
886354000379	BAR LIGHT MOUNTING FRAME BS6	TATA spare parts
886354000380	FOG LAMP BS6	TATA spare parts
886354000381	SIDE MARKER BS6	TATA spare parts
886354000382	SIDE INDICATOR BS6	TATA spare parts
886354000383	DIGITAL CLOCK BS6	TATA spare parts
886354000384	NUMBER PLATE LIGHT BS6	TATA spare parts
886354000385	12- MODULAR SWITCH BOARD ASSEMBLY BS6	TATA spare parts
886354000386	ROOF LED LIGHT BS6	TATA spare parts

886354000387	COACH FAN BS6	TATA spare parts
886354000388	EXTERNAL POWER SOCKET BS6	TATA spare parts
886354000389	12V SOCKETS BS6	TATA spare parts
886354000390	IV HOOKS BS6	TATA spare parts
886354000391	REAR DOOR OPEN ALARM SWITCH BS6	TATA spare parts
886354000392	SWITCH BS6	TATA spare parts
886354000393	BIN LOCK- KNOB TYPE BS6	TATA spare parts
886354000394	INVERTER 850VA BS6	TATA spare parts
886354000395	REAR DOOR SIREN BS6	TATA spare parts
886354000396	SS-HANDLE BS6	TATA spare parts
886354000397	SIREN WITH PA SYSTEM BS6	TATA spare parts
886354000398	REVOLVING LIGHT BS6	TATA spare parts
886354000399	FOOT OPERATED PUMP BS6	TATA spare parts
886354000400	BUZZER BS6	TATA spare parts
886354000401	ECG MONITOR WITH OXYGEN MONITOR BS6	TATA spare parts
886354000402	ELECTRIC SUCTION PUMP BS6	TATA spare parts
886354000403	TABLET WITH 4G CONNECTIVITY (I BALL) BS6	TATA spare parts
886354000404	NEBULIZER BS6	TATA spare parts
886354000405	TORCHLIGHT BS6	TATA spare parts
886354000406	WIRING HARNESS BS6	TATA spare parts
886354000407	LIMIT SWITCH AT4/11-S/I/R316+HR518	TATA spare parts
886354000408	CAB COMMAND CITIMAX -500	TATA spare parts
886354000409	SIDE MARKER LAMP BS6	TATA spare parts
886354000410	WIRING HARNESS BS6	TATA spare parts
886354000411	SIREN SPEAKER BS6	TATA spare parts
886354000412	FLEXIBLE LED EXAMINATION LIGHT BS6	TATA spare parts
886354000413	CCTV WITH SCREEN BS6	TATA spare parts
886354000414	TILT SWITCH FOR TIPPER BS6	TATA spare parts
886354000415	WORKING LAMP 30V 27W IP67 BS6	TATA spare parts
886354000416	SHOLPHIN REVOLVING LIGHT BS6	TATA spare parts
886354000417	AMPLIFIER BS6	TATA spare parts
886354000418	REVOLVING LIGHT BS6	TATA spare parts
886354000419	SIREN WITH PA SYSTEM BS6	TATA spare parts
886354000420	ROOF LAMP BS6	TATA spare parts
886354000421	WIRING HARNESS BS6	TATA spare parts
886354000422	SWITCH ON-OFF BS6	TATA spare parts
886354000423	TUBELIGHT (AC) BS6	TATA spare parts
886354000424	FAN (DC) BS6	TATA spare parts
886354000425	FOCUS LIGHT BS6	TATA spare parts
886354000426	AIR CONDITION BS6	TATA spare parts
886354000427	INVERTER 1650 VA UPS BS6	TATA spare parts
886354000428	EXTERNAL CABLE BS6	TATA spare parts
886354000429	SIREN BS6	TATA spare parts
886354000430	BATTERY BS6	TATA spare parts
886354000431	SIDE INDICATOR LAMP BS6	TATA spare parts
886354000432	TOP MARKER LAMP BS6	TATA spare parts
886354000433	WIRING HARNESS BS6	TATA spare parts

886354000434	SIREN SWITCH BS6	TATA spare parts
886354000435	FOCUS LIGHT SWITCH BS6	TATA spare parts
886354000436	TOP MARKER FRONT & REAR BS6	TATA spare parts
886354000437	SIDE MARKER BS6	TATA spare parts
886354000438	WIRING HARNESS BS6	TATA spare parts
886354000439	MOTOR 12V DC BS6	TATA spare parts
886354000440	CHANGE OVER SWITCH BS6	TATA spare parts
886354000441	FUSE BOX BS6	TATA spare parts
886354000442	3 PIN TOP BS6	TATA spare parts
886354000443	3 PIN SOCKET WITH SWITCH BS6	TATA spare parts
886354000444	INVERTER CABINET BS6	TATA spare parts
886354000445	WIRING HARNESS 16 CUM HD BS6	TATA spare parts
886354000446	WIRING HARNESS COMPLETE BS6	TATA spare parts
886354000447	FAST CHARGER 240KW DC GBT	TATA spare parts
886354000448	SIDE MARK LAMPS BRACKETS	TATA spare parts
886354000449	TAIL LAMP HOUSING (LH)	TATA spare parts
886354000450	REGISTRATION PLATE AND HOUSING (RH)	TATA spare parts
886354000451	SIDEMARKER LAMP 24V	TATA spare parts
886354000452	WIRING HARNESS	TATA spare parts
886354000453	PATIENT CABIN DC LIGHT BS6	TATA spare parts
886354000454	EMERGENCY LED LIGHT SIPHON BS6	TATA spare parts
886354000455	PA SYSTEM BS6	TATA spare parts
886354000456	EXTERNAL POWER SOCKET BS6	TATA spare parts
886354000457	12- MODULAR SWITCH BOARD ASSEMBLY BS6	TATA spare parts
886354000458	6- MODULAR SWITCH BOARD ASSEMBLY BS6	TATA spare parts
886354000459	3- MODULAR SWITCH BOARD ASSEMBLY BS6	TATA spare parts
886354000460	SINGLE MODULAR SWITCH BOARD ASSEMBLY BS6	TATA spare parts
886354000461	BAR LIGHT FRP COVER BS6	TATA spare parts
886354000462	BAR LIGHT MOUNTING FRAME BS6	TATA spare parts
886354000463	SIDE INDICATOR BS6	TATA spare parts
886354000464	3 PIN TOP BS6	TATA spare parts
886354000465	DICKY LIGHT BS6	TATA spare parts
886354000466	PIANO SWITCH BS6	TATA spare parts
886354000467	ROOF LED AC LIGHT BS6	TATA spare parts
886354000468	DC CAOCH FAN 200MM BS6	TATA spare parts
886354000469	AC CAOCH FAN BS6	TATA spare parts
886354000470	SPEAKER 4INCH BS6	TATA spare parts
886354000471	BLOOD COLLECTION MONITOR BS6	TATA spare parts
886354000472	LUMINUS CRUZE 3500 /48V BS6	TATA spare parts
886354000473	SPLIT AC BS6	TATA spare parts
886354000474	BATTERY 150 AH BS6	TATA spare parts
886354000475	CHANGE OVER 63 BS6	TATA spare parts
886354000476	MCB- DP- 32AMP BS6	TATA spare parts
886354000477	AC LOUVERS BS6	TATA spare parts
886354000478	HONDA 7.5KV GENSET BS6	TATA spare parts
886354000479	ENGINE DRIVEN AC BS6	TATA spare parts
886354000480	LED TV 32INCH BS6	TATA spare parts

886354000481	SIDE MARKER LAMP BS6	TATA spare parts
886354000482	TOP MARKER LAMP BS6	TATA spare parts
886354000483	SIDE MARKER COVER BS6	TATA spare parts
886354000484	TOP MARKER LAMP COVER BS6	TATA spare parts
886354000485	WIRING HARNESS BS6	TATA spare parts
886354000486	SIDE INDICATOR LAMP BS6	TATA spare parts
886354000487	WIRING HARNESS ASSY. BS6	TATA spare parts
886354000488	FOG LAMP ROUND TYPE 24V BS6	TATA spare parts
886354000489	TOP MARKER LAMP BS6	TATA spare parts
886354000490	MOBILE MDVR21 BS6	TATA spare parts
886354000491	PATIENT CABIN DC LIGHT BS6	TATA spare parts
886354000492	EMERGENCY LED LIGHT SIPHON BS6	TATA spare parts
886354000493	PA SYSTEM BS6	TATA spare parts
886354000494	EXTERNAL POWER SOCKET BS6	TATA spare parts
886354000495	12- MODULAR SWITCH BOARD ASSEMBLY BS6	TATA spare parts
886354000496	6- MODULAR SWITCH BOARD ASSEMBLY BS6	TATA spare parts
886354000497	3- MODULAR SWITCH BOARD ASSEMBLY BS6	TATA spare parts
886354000498	SINGLE MODULAR SWITCH BOARD ASSY BS6	TATA spare parts
886354000499	BAR LIGHT FRP COVER BS6	TATA spare parts
886354000500	BAR LIGHT MOUNTING FRAME BS6	TATA spare parts
886354000501	SIDE MARKER BS6	TATA spare parts
886354000502	SIDE INDICATOR BS6	TATA spare parts
886354000503	HONDA 7.5KV GENSET BS6	TATA spare parts
886354000504	DICKY LIGHT BS6	TATA spare parts
886354000505	PIANO SWITCH BS6	TATA spare parts
886354000506	ENGINE DRIVEN AC BS6	TATA spare parts
886354000507	ROOF LED AC LIGHT BS6	TATA spare parts
886354000508	DC CAOCH FAN 200MM BS6	TATA spare parts
886354000509	AC CAOCH FAN BS6	TATA spare parts
886354000510	SPEAKER 4INCH BS6	TATA spare parts
886354000511	BLOOD STORAGE REFRIGERATOR BS6	TATA spare parts
886354000512	GODREJ COFFEE VENDING MACHINE BS6	TATA spare parts
886354000513	BLOOD COLLECTION MONITOR BS6	TATA spare parts
886354000514	LUMINUS CRUZE 3500 /48V BS6	TATA spare parts
886354000515	SPLIT AC BS6	TATA spare parts
886354000516	BATTERY 150 AH BS6	TATA spare parts
886354000517	MCB- DP- 32AMP BS6	TATA spare parts
886354000518	AC LOUVERS BS6	TATA spare parts
886354000519	LED TV 32INCH BS6	TATA spare parts
886354000520	LAMP END OUTLINE MARKER - 24V BS6	TATA spare parts
886354000521	WIRING HARNESS LOAD BODY BS6	TATA spare parts
886354000522	HEIGHT MARKER LAMP	TATA spare parts
886354000523	SIREN BS6	TATA spare parts
886354000524	BATTERY CHARGER 15A	TATA spare parts
886354000525	12INCH LED LIGHT 36W	TATA spare parts
886354000526	DC LED LIGHT 24V	TATA spare parts
886354000527	MCB BOX 25 POLE	TATA spare parts

886354000528	CHANGE OVER 63A 3 PHASE	TATA spare parts
886354000529	16A 3 PHASE NEPTUNE BOX	TATA spare parts
886354000530	MODULER BOX 12 POLE WITH PLATE	TATA spare parts
886354000531	MODULER BOX 6 POLE WITH PLATE	TATA spare parts
886354000532	SIDE MARKER	TATA spare parts
886354000533	TOP MARKER 24V	TATA spare parts
886354000534	63A 3 PHASE NEPTUNE BOX SUPPLY BOX	TATA spare parts
886354000535	BULK LIGHT 6	TATA spare parts
886354000536	MODULER BOX 6 POLE WITH PLATE	TATA spare parts
886354000537	SINGE POLE NEPTUNE BOX	TATA spare parts
886354000538	WIRE HARNES AC	TATA spare parts
886354000539	WIRE HARNES DC	TATA spare parts
886354000540	LEAD WIRE	TATA spare parts
886354000541	WIRING HARNESS ASSY - FLEX BS6	TATA spare parts
886354000542	STEP LAMP WHITE COLOUR 24V	TATA spare parts
886354000543	WIRING HARNESS SIDE AND TOP MARKER BS6	TATA spare parts
886354000544	FAN AC BS6	TATA spare parts
886354000545	FAN DC BS6	TATA spare parts
886354000546	SWITCH BOARD - 8MODULAR BS6	TATA spare parts
886354000547	SWITCH BOARD - 12MODULAR BS6	TATA spare parts
886354000548	SWITCH BOARD - 3MODULAR BS6	TATA spare parts
886354000549	MCB - 32AMP SINGLE POLE BS6	TATA spare parts
886354000550	FUSE BOX AC BS6	TATA spare parts
886354000551	FOCUS LIGHT - DC BS6	TATA spare parts
886354000552	LUMINUS/CRUZE SW UPS BS6	TATA spare parts
886354000553	EXTERNAL CHARGING SOCKET BS6	TATA spare parts
886354000555	BATTERY CUTOFF SWITCH BS6	TATA spare parts
886354000556	SIREN WITHPA SYSTEAM BS6	TATA spare parts
886354000557	WIRING HARNESS BS6	TATA spare parts
886354000558	BATTERY BRACKET BS6	TATA spare parts
886354000559	TOP MARKER FRONT & REAR BS6	TATA spare parts
886354000560	SIDE MARKER BS6	TATA spare parts
886354000561	FOCUS LIGHT SWITCH BS6	TATA spare parts
886354000562	TAIL LAMP BRACKET BS6	TATA spare parts
886354000563	ELECTRONIC WEIGHING MACHINE - 20 KG CAPA	TATA spare parts
886354000564	LED LIGHT AC BS6	TATA spare parts
886354000565	LED ROOF LIGHT-12V PALTEX BS6	TATA spare parts
886354000566	FRONT HIGHT MARKER WHITE 12V BS6	TATA spare parts
886354000567	REAR HIGHT MARKER RED 12V BS6	TATA spare parts
886354000568	NIGHT LAMP 12 V BS6	TATA spare parts
886354000569	SIDE DIREC INDIC LAMP RH 12V CAT6 BS6	TATA spare parts
886354000570	SIDE DIREC INDIC LAMP LH 12V CAT6 BS6	TATA spare parts
886354000571	SIDE MARKER 12V BS6	TATA spare parts
886354000572	LICENSE PLATE LAMP 12V BS6	TATA spare parts
886354000573	STOP SWITCH BS6	TATA spare parts
886354000574	CABIN LIGHT(12V) BS6	TATA spare parts
886354000575	PICKO SWITCH BLACK FOURWAY BS6	TATA spare parts

886354000576	SIDE MARKER & SIDE INDICATOR MARKER HARN	TATA spare parts
886354000577	FUSE BOX HARNESS BS6	TATA spare parts
886354000578	ROOF HARNESS BS6	TATA spare parts
886354000579	EMERGENCY & DOOR SWITCH HARNESS BS6	TATA spare parts
886354000580	LHS WIRE BS6	TATA spare parts
886354000581	FDSS CONTROLLER BS6	TATA spare parts
886354000582	FIRE ALERT SOUNDER BS6	TATA spare parts
886354000583	SPLICING KIT BS6	TATA spare parts
886354000584	END OF LINE BS6	TATA spare parts
886354000585	ROOF LED LIGHT BS6	TATA spare parts
886354000586	PATIENT CABIN SPOT LIGHT BS6	TATA spare parts
886354000587	CAOCH FAN ( WHITE COLOUR ) BS6	TATA spare parts
886354000588	12- MODULAR SWITCH BOARD ASSEMBLY BS6	TATA spare parts
886354000589	WORK LAMP BS6	TATA spare parts
886354000590	EXTERNAL POWER SOCKET BS6	TATA spare parts
886354000591	12V SOCKETS BS6	TATA spare parts
886354000592	CAMERA BS6	TATA spare parts
886354000593	PIANO SWITCH BS6	TATA spare parts
886354000594	REAR DOOR OPEN ALARM SWITCH BS6	TATA spare parts
886354000595	REAR DOOR SIREN BS6	TATA spare parts
886354000596	BAR LIGHT BS6	TATA spare parts
886354000597	PA SYSTEM BS6	TATA spare parts
886354000598	LED TUBE LIGHT BS6	TATA spare parts
886354000599	230 V AC SOCKET BS6	TATA spare parts
886354000600	12 V DC CHARGING SOCKET BS6	TATA spare parts
886354000601	12 V DC FAN BS6	TATA spare parts
886354000602	CAMERA WITH DVR BS6	TATA spare parts
886354000603	DOOR SWITCH BS6	TATA spare parts
886354000604	ELECTRIC SWITCH BOARD 6 AMP BS6	TATA spare parts
886354000605	BAR LIGHT MTG BKT BS6	TATA spare parts
886354000606	BATTERY & INVERTER MTG PLATE BS6	TATA spare parts
886354000607	FOOT OPERATED SWITCH BS6	TATA spare parts
886354000608	EXTERNAL CHARGING CABLE BS6	TATA spare parts
886354000609	MCB 6 AMP WITH COVER ALL SEST BS6	TATA spare parts
886354000610	DC FUSE BOX BS6	TATA spare parts
886354000611	AC FUSE BOX BS6	TATA spare parts
886354000612	FRP SHOLPHIN BAR LIGHT COVER BS6	TATA spare parts
886354000613	PIPE COVER BS6	TATA spare parts
886354000614	SIREN WITH BLINKER -12V BS6	TATA spare parts
886354000615	FAN BLUE 200MM -CF20 BS6	TATA spare parts
886354000616	REFLECTOR RETRO BS6	TATA spare parts
886354000617	SLOW BLOW 10A FUSE 5X20MM	TATA spare parts
886354000618	SLOW BLOW 6A FUSE 5X20MM	TATA spare parts
886354000619	REVOLING LIGHT BS6	TATA spare parts
886354000620	DASHBOARD SWITCH SET BS6	TATA spare parts
886354000621	EPABX SYSTEM MASCOM MC102(TELCOM) BS6	TATA spare parts
886354000622	MODULAR BOX BS6	TATA spare parts

886354000623	TELEPHONE INSTRUMENT B25 BLACK BS6	TATA spare parts
886354000624	TELEPHONE CABLE - 2 PAIR HAWELLS BS6	TATA spare parts
886354000625	CONTROL UNIT TYPE AF300 - SEAL FLAP	TATA spare parts
886354000626	ELECTRIC ACTUATOR C3	TATA spare parts
886354000627	CCTV BS6	TATA spare parts
886354000628	LED ROOF LIGHT-24 V BS6	TATA spare parts
886354000629	FRONT HIGHT MARKER WHITE 24V (AARVI) BS6	TATA spare parts
886354000630	REAR HIGHT MARKER RED 24V (AARVI) BS6	TATA spare parts
886354000631	NIGHT LAMP 24 V BS6	TATA spare parts
886354000632	DICKY LIGHT 24V (AARVI) BS6	TATA spare parts
886354000633	EMERGENCY LIGHTING SYSTEM - 24V AIS 153	TATA spare parts
886354000634	PICKO SWITCH BLACK SINGLE WAY BS6	TATA spare parts
886354000635	WIRE HARNESS PANIC SWITCH BS6	TATA spare parts
886354000636	WIRE HARNESS ROOF BS6	TATA spare parts
886354000637	WIRE HARNESS VTS BS6	TATA spare parts
886354000638	WIRE HARNESS UNDERBODY BS6	TATA spare parts
886354000639	FDAS ASSY BS6	TATA spare parts
886354000640	MODULAR PLATE 3 WAY (WITH SWITCHES) BS6	TATA spare parts
886354000641	EXHAUST FAN DC 8INCH - 24V BS6	TATA spare parts
886354000642	MODULAR BOX 3 WAY PVC (WITH SWITCHES) BS	TATA spare parts
886354000643	WP 090 2M ASSY BS6	TATA spare parts
886354000644	MTO90M-2SQ-WP BS6	TATA spare parts
886354000645	MT090GUM SEAL(G) BS6	TATA spare parts
886354000646	ETO2-1W BS6	TATA spare parts
886354000647	HSG-30-2 TIN BS6	TATA spare parts
886354000648	4 WAY M SS 1.5 HOUS BLK BS6	TATA spare parts
886354000649	TER 060 MIC M (CSA 1.5-2.5) BS6	TATA spare parts
886354000650	SINGLE W/S (INS DIA 1.7-2.4) Y BS6	TATA spare parts
886354000651	SIDE MARKER LAMP 12 V BS6	TATA spare parts
886354000652	WIRE HARNESS RH BS6	TATA spare parts
886354000653	WIRE HARNESS LH BS6	TATA spare parts
886354000654	DASHBOARD SWITCH SET BS6	TATA spare parts
886354000655	LED LIGHT BAR INCLUDING AMPLIFIER AND PA	TATA spare parts
886354000656	MOBILE DVR (2 CAMERA 128GB M.CARD)-MDVR2	TATA spare parts
886354000657	CAMERA CABLE 3+1 BS6	TATA spare parts
886354000658	OUTER SPOT LIGHT BS6	TATA spare parts
886354000659	BLINKER LIGHT BS6	TATA spare parts
886354000660	SPOT LIGHT BS6	TATA spare parts
886354000661	DOOR LIGHT BS6	TATA spare parts
886354000662	SWITCH SET BS6	TATA spare parts
886354000663	DASHBOARD SWITCH SET BS6	TATA spare parts
886354000664	DASHBOARD SWITCH SET BS6	TATA spare parts
886354000665	SWITCH SET BS6	TATA spare parts
886354000666	DASHBOARD SWITCH SET BS6	TATA spare parts
886354000667	INDICATOR BLINKER LIGHT TYPE C & D AMB.	TATA spare parts
886354000668	AMPLIFIER BS6	TATA spare parts
886354000669	WIRING HARNESS BS6	TATA spare parts



886354000670	CHANGE OVER SWITCH BS6	TATA spare parts
886354000671EX	38B20L-TML 35AH BATTERY	TATA spare parts
886354000672EX	70D26L-TML 65AH BATTERY	TATA spare parts
886354000673EX	80D31R-TML 80AH BATTERY	TATA spare parts
886354000674EX	105E41L CV-TML 100AH BATTERY	TATA spare parts
886354000675EX	135G51 CV-TML 135AH BATTERY	TATA spare parts
886354000676EX	150G51CV-TML 150AH BATTERY	TATA spare parts
886354000677	RELAY 4 PT BS6-PH2	TATA spare parts
886354000678	HEATER UNIT TABLE BS6-PH2	TATA spare parts
886354600001	TOP MARKER LAMP	TATA spare parts
886354810001	HEIGHT MARKER LAMP	TATA spare parts
886354810002	BELL SWITCH	TATA spare parts
886354810003	ROOF LAMP COVER (INSIDE)	TATA spare parts
886354810004	FLUORESCENT LAMP	TATA spare parts
886354810005	FOOT BOARD LAMP REAR	TATA spare parts
886354810006	BULB (12V)	TATA spare parts
886354810007	REAR LICENSE PLATE LIGHTS (PACK)	TATA spare parts
886354810008	BULB REAR LICENSE PLATE LIGHTS(PACK)	TATA spare parts
886354810009	REAR WORKING LAMP	TATA spare parts
886354810010	EMERGENCY SWITCH	TATA spare parts
886354810011	REVOLVING LIGHT	TATA spare parts
886354960001	ROOF HARNESS	TATA spare parts
886354960002	CFL LAMP (POWER ELEL.)24V	TATA spare parts
886354960003	SIDE BLINKER LAMP	TATA spare parts
886354960004	ROOF HARNESS	TATA spare parts
886354960005	BULB 24V 21/ 5W	TATA spare parts
886354960006	MOTOR (24V HIGH POWER)	TATA spare parts
886354960007	MARKER LAMP (WHITE)	TATA spare parts
886354960008	MARKER LAMP (RED)	TATA spare parts
886354960009	WIRING HARNESS COMPLETE	TATA spare parts
886354960011	METER PANEL HARNESS	TATA spare parts
886354960012	BULB FOR INDICA SD MRK	TATA spare parts
886354960013	BRUSHLESS PASSENGER FAN (24V)	TATA spare parts
886354960014	CD PLAYER	TATA spare parts
886354960015	WIRING HARNESS COMPLETE	TATA spare parts
886354960016	METER PANEL HARNESS	TATA spare parts
886354960017	ROOF HARNESS	TATA spare parts
886354960018	METER PANEL HARNESS	TATA spare parts
886354960019	DUMMY COVER	TATA spare parts
886354960020	FOG LAMP RH	TATA spare parts
886354960021	FOG LAMP LH	TATA spare parts
886354960022	ROOF HARNESS	TATA spare parts
886354960023	BELL SWITCH	TATA spare parts
886354960024	STOP LAMP 24 V	TATA spare parts
886354960025	REVERSE LAMP 24 V	TATA spare parts
886354960026	SIDE INDICATOR LAMP	TATA spare parts
886354960027	ROOF HARNESS	TATA spare parts

886354960028	METER PANEL HARNESS	TATA spare parts
886354960029	METER PANEL HARNESS (EXPORT)	TATA spare parts
886354960030	WIRING HARNESS COMPLETE	TATA spare parts
886354960031	SWITCH COVER	TATA spare parts
886354960032	BULB SP 6 W	TATA spare parts
886354960033	15A FUSE	TATA spare parts
886354960034	WIRING HARNESS COMPLETE	TATA spare parts
886354960035	BULB 24V 2W	TATA spare parts
886354960036	SIDE DIRECTION INDICATOR RH	TATA spare parts
886354960037	SIDE DIRECTION INDICATOR LH	TATA spare parts
886354960038	ROOF HARNESS	TATA spare parts
886354960039	HEAD LAMP 7 IN MFR (24V)	TATA spare parts
886354960040	ROOF HARNESS	TATA spare parts
886354960041	ROOF HARNESS	TATA spare parts
886354960042	LAMP FITTED ON DOOR STEP	TATA spare parts
886354960043	FRIDGE CABLE	TATA spare parts
886354960044	BULB FOR INDICA SIDE MKR/24V/2	TATA spare parts
886354960045	END OUT MARKER ASSY	TATA spare parts
886354960046	HEAD LAMP	TATA spare parts
886354960047	FOG LAMP ASSY	TATA spare parts
886354960048	END OUT MARKER ASSY	TATA spare parts
886354960049	LAMP NET PLAST MAKE	TATA spare parts
886354960050	METER PANEL HARNESS	TATA spare parts
886354960051	BULB FOR INDICA SIDE MARKER	TATA spare parts
886354960052	SIDE MARKER LAMP	TATA spare parts
886354960053	2P ON-OFF TOGGLE SWITCH	TATA spare parts
886354960054	PILOT LAMP	TATA spare parts
886354960055	FLASHING LAMP AMBER 24V	TATA spare parts
886354960056	CASSET PLAYER/ FM	TATA spare parts
886354960057	SLIM FLUORESCENT LAMP	TATA spare parts
886354960058	WIRING HARNESS	TATA spare parts
886354960059	REFLEX REFLECTOR AMBER	TATA spare parts
886354960060	SIDE MARKER ASSY(LAUNCH TYPE)	TATA spare parts
886354960061	HIGH MOUNT STOP LAMP	TATA spare parts
886354960062	METER PLATE	TATA spare parts
886354960063	FOG LAMP ASSEMBLY 85 DIA	TATA spare parts
886354960064	DC CONVERTOR	TATA spare parts
886354960065	PILOT INDICATOR	TATA spare parts
886354960066	FLOUROSCENT LAMP 12V PLR 15RA	TATA spare parts
886354960067	LED CABIN LAMP 12V	TATA spare parts
886354960068	HEAD LAMP SET LH PRIMA 24V LHD	TATA spare parts
886354960069	HEAD LAMP SET RH PRIMA 24V LHD	TATA spare parts
886354960070	HEIGHT MARKER FRONT LED RED COLOUR	TATA spare parts
886354960071	LAMP ROUND FIEM AMBER	TATA spare parts
886354960072	CLUSTERED TAIL LAMP RH	TATA spare parts
886354960073	CLUSTERED TAIL LAMP LH	TATA spare parts
886354960074	DVD SWITCH	TATA spare parts

886354960075	ROOF HARNESS COMPLETE	TATA spare parts
886354960076	FAN 24V (RING TYPE)	TATA spare parts
886354960077	SPARE SWITCH (DVD/TV)	TATA spare parts
886354960078	SPEAKER COVER	TATA spare parts
886354960079	METER PANEL HARNESS	TATA spare parts
886354960080	FUSE CASSETTE TYPE (5 AMPS)	TATA spare parts
886354960081	FUSE CASSETTE TYPE (10 AMPS)	TATA spare parts
886354960082	FUSE CASSETTE TYPE (15 AMPS)	TATA spare parts
886354960083	FRONT REFLECTOR LH	TATA spare parts
886354960084	FRONT REFLECTOR RH	TATA spare parts
886354960085	SIDE INDICATOR	TATA spare parts
886354960086	TAIL LAMP (RED)	TATA spare parts
886354960087	SIDE INDICATOR	TATA spare parts
886354960088	METER PANEL HARNESS	TATA spare parts
886354960089	ROOF HARNESS	TATA spare parts
886354960090	LED DEST BOARD 24V1286MM	TATA spare parts
886354960091	DESTINATION BOARD CONROLLER	TATA spare parts
886354960092	DASHBOARD COMPLETE	TATA spare parts
886354960093	ROOF HARNESS	TATA spare parts
886354960094	JUNCTION CAP FOR LED TUBE LIGHT	TATA spare parts
886354960095	DESTINATION BOARD CONTROLLER	TATA spare parts
886354960096	H L 24V L.B RHD MOTORISED RH	TATA spare parts
886354960097	HEAD LAMP 24V H.B RHD WITH PARKING RH	TATA spare parts
886354960098	FRONT INDICATOR 24V	TATA spare parts
886354960099	SIDE BLINKER RH	TATA spare parts
886354960100	FRONT DIRECTION INDICATOR 12V	TATA spare parts
886354960101	SALOON LED LAMP 12V	TATA spare parts
886354960102	HEIGHT MARKER FRONT 12V	TATA spare parts
886354960103	REAR HEIGHT MARKER (12V)	TATA spare parts
886354960104	WIRING HARNESS COMPLETE	TATA spare parts
886354960105	METER PANEL HARNESS	TATA spare parts
886354960106	STOP SWITCH(PIPE MOUNTED)	TATA spare parts
886354960107	SIDE MARKER LAMP	TATA spare parts
886354960108	SIDE BLINKER LAMP -LH	TATA spare parts
886354960109	SIDE BLINKER LAMP -RH	TATA spare parts
886354960110	CABIN LAMP 12V	TATA spare parts
886354960111	TAIL LAMP LH	TATA spare parts
886354960112	TAIL LAMP RH	TATA spare parts
886354960113	HEADLAMP LH	TATA spare parts
886354960114	HEADLAMP RH	TATA spare parts
886354960115	FRONT DIRECTION INDICATOR -RH	TATA spare parts
886354960116	FAN 12V GREY	TATA spare parts
886354960117	FRONT DIRECTION INDICATOR -LH	TATA spare parts
886354960118	FRONT_LAMP_FENDER_PANEL_RH	TATA spare parts
886354960119	FRONT_LAMP_FENDER_PANEL_LH	TATA spare parts
886354960120	REAR LAMP FENDER PANEL LH	TATA spare parts
886354960121	REAR LAMP FENDER PANEL RH	TATA spare parts

886354960122	HEAD LAMP 24V H.B RHD WITH PARKING LH	TATA spare parts
886354960123	HEAD LAMP 24V L.B RHD MOTORISED LH	TATA spare parts
886354960124	SALOON LED LAMP 12V(POWER)	TATA spare parts
886354960125	ROOF HARNESS	TATA spare parts
886354960126	FRONT DESTINATION BOARD	TATA spare parts
886354960127	REAR DESTINATION BOARD	TATA spare parts
886354960128	FOG LAMP 24V	TATA spare parts
886354960129	REAR HEIGHT MARKER(RED) 12V--2/BUS	TATA spare parts
886354960130	SIDE MARKER FIEM MAKE 24 V	TATA spare parts
886354960131	LCD 22IN 24V	TATA spare parts
886354960132	WIRING HARNESS COMPLETE	TATA spare parts
886354960133	AIR HORN LEVER TYPE	TATA spare parts
886354960134	CIGERATTE LIGHTER SOCKET	TATA spare parts
886354960135	WIRING HARNESS COMPLETE	TATA spare parts
886354960136	CD PLAYER MP3 WITH USB PORT	TATA spare parts
886354960137	WIRING HARNESS COMPLETE	TATA spare parts
886354960138	CABIN LED LAMP	TATA spare parts
886354960139	ROOF HARNESS COMPLETE	TATA spare parts
886354960140	FLASHER HARNESS	TATA spare parts
886354960141	REAR FOG LAMP 24 V SUMO VICTA	TATA spare parts
886354960142	PASSENGER FAN 8IN 24V	TATA spare parts
886354960143	ROOF HARNESS COMPLETE	TATA spare parts
886354960144	CONTROLLER WITH GPS 24V	TATA spare parts
886354960145	ROOF HARNESS COMPLETE	TATA spare parts
886354960146	ROOF HARNESS	TATA spare parts
886354960147	ROOF HARNESS COMPLETE	TATA spare parts
886354960148	METER PANEL HARNESS	TATA spare parts
886354960149	HEAD LAMP LH NON MOT 12V	TATA spare parts
886354960150	HEAD LAMP RH NON MOT 12V	TATA spare parts
886354960151	HEAD LAMP RH MOTORISED 12V	TATA spare parts
886354960152	HEAD LAMP LH MOTORISED 12V	TATA spare parts
886354960153	ROOF HARNESS	TATA spare parts
886354960154	METER PANEL HARNESS	TATA spare parts
886354960155	SUMO NO. PLATE LAMP	TATA spare parts
886354960156	RELAY (12V 30 AMPS)	TATA spare parts
886354960157	ROOF HARNESS	TATA spare parts
886354960158	PASS FAN 8IN 12V ARAI CERTIF	TATA spare parts
886354960159	TAIL LAMP LH	TATA spare parts
886354960160	TAIL LAMP RH	TATA spare parts
886354960161	ROOF HARNESS COMPLETE	TATA spare parts
886354960162	LED ROOF LAMP 24V (6 NOS)	TATA spare parts
886354960163	DOMELAMP (YELLOW LENSE) 24V 10W BULB (4	TATA spare parts
886354960164	ROOF HARNESS COMPLETE	TATA spare parts
886354960165	SPEAKER COVER WHITE (7 NOS)	TATA spare parts
886354960166	METER PANEL HARNESS	TATA spare parts
886354960167	HEIGHT MARKER FRONT (2 NOS)	TATA spare parts
886354960168	HEIGHT MARKER REAR (2 NOS)	TATA spare parts

886354960169	WIRING HARNESS COMPLETE	TATA spare parts
886354960170	LH - SIDE HARNESS	TATA spare parts
886354960171	HEIGHT MARKER RED 24V	TATA spare parts
886354960172	DASH BOARD WIRING HARNESS	TATA spare parts
886354960173	SWITCH DUMMY COVER 22X44	TATA spare parts
886354960174	REAR¿ MUX¿ BOX¿ FRP	TATA spare parts
886354960175	FRONT CBCU BOX FRP	TATA spare parts
886354960176	REAR VENTILATOR HARNESS	TATA spare parts
886354960177	PIG TAIL VENTILATOR	TATA spare parts
886354960178	ETM¿ CHARGER¿ MTG¿ BOX	TATA spare parts
886354960179	ETM/¿ MOBILE HOLDING BOX	TATA spare parts
886354960180	ETM¿ CHARGER¿ 24V	TATA spare parts
886354960181	MOBILE CHARGER¿ 24V	TATA spare parts
886354960182	MOBILE¿ CHARGER¿ HARNESS	TATA spare parts
886354960183	RH ROOF LAMP HARNESS	TATA spare parts
886354960184	LH¿ ROOF LAMP HARNESS	TATA spare parts
886354960185	RH¿ HEIGHT MARKER HARNESS	TATA spare parts
886354960186	REAR MUX HARNESS	TATA spare parts
886354960187	FRONT DESTINATION BOARD 1800MM 2	TATA spare parts
886354960188	CONTROLLER NON GPS WITH VOICE ANNOU. SYS	TATA spare parts
886354960189	DESTINATION HARNESS SET	TATA spare parts
886354960190	FRP DESTINATION BOX	TATA spare parts
886354960191	MIKE	TATA spare parts
886354960192	SIDE DESTINATION BOARD 900MM	TATA spare parts
886354960193	BEST SIDE MARKER HARNESS	TATA spare parts
886354960194	PIG TAIL REVERSE HOOTER	TATA spare parts
886354960195	VENTILATOR FAN EF6	TATA spare parts
886354960196	WIRING HARNESS COMPLETE	TATA spare parts
886354960197	LED ROOF LAMP 24V GSO	TATA spare parts
886354960198	STOP LAMP BOARD 24V	TATA spare parts
886354960199	ROOF HARNESS COMPLETE	TATA spare parts
886354960200	MICROPEDAL SWITCH	TATA spare parts
886354960201	DASHBOARD HARNESS	TATA spare parts
886354960202	SIDE DESTINATION BOARD	TATA spare parts
886354960203	INNER DESTINATION BOARD	TATA spare parts
886354960204	24V-9V 5A DC-DC CONVERTOR	TATA spare parts
886354960205	ETM CHARGER 24V- 9V 750MA	TATA spare parts
886354960206	HARNESS SET-FRONT & REAR	TATA spare parts
886354960207	WIRING HARNESS KIT (ITS)	TATA spare parts
886354960208	BUS DISPLAY CONTROL HARNESS	TATA spare parts
886354960209	ITS HARNESS ASSEMBLY (POWER)	TATA spare parts
886354960210	ITS HARNESS ASSEMBLY PIS- VHMD	TATA spare parts
886354960211	ITS HARNESS ASSEMBLY CAMERA-SPEAKER	TATA spare parts
886354960212	FRONT - INNER DESTINATION PIG TAIL	TATA spare parts
886354960213	INNER- SIDE DESTINATION PIG TAIL	TATA spare parts
886354960214	REAR - SIDE DESTINATION PIG TAIL	TATA spare parts
886354960215	ROOF HARNESS COMPLETE	TATA spare parts

886354970001	DESTINATION BOARD REAR	TATA spare parts
886355000001	STICKER TIPPER (TATA)	TATA spare parts
886355000002	STICKER TIPPER (TATA LOGO)	TATA spare parts
886355000003	STICKER SET(ADVANCE LIFE SUPPORT) BS6	TATA spare parts
886356000024	GAS STAY	TATA spare parts
886356600003	ROLLER CHAIN/3/4 IN X 3.05	TATA spare parts
886356600004	GEAR DRUM ASSY	TATA spare parts
886356600005	RING GEAR	TATA spare parts
886358000001	WRKSHPTR-S5/2-RAL3002-FOAM-TOOLKIT	TATA spare parts
886358000002	WRKSHP-WE7-RAL7035-FOAM-TOOLSET	TATA spare parts
886358000003	CUMMINS INLINE MINI HARDWARE TOOL.	TATA spare parts
886358000004	ADAPTER DATALINK	TATA spare parts
886358000005	CABLE ELECTRICAL	TATA spare parts
886358000006	PRO SOFTWARE	TATA spare parts
886358000007	ICONNECT VCI	TATA spare parts
886358000008	CUMMINS INLINE 7 - KIT DATA LINK ADAPTER	TATA spare parts
886358000009	CUMMINS INLINE MINI ħ GUIDANZ SOFTWARE	TATA spare parts
886358000010	CUMMINS ENGINE - REAR OIL SEAL TOOL BS6	TATA spare parts
886358000011	TDS LITE - ICV2 (DUAL-CAN CHENNEL)	TATA spare parts
886358000012	LOAD BODY MS STAND WITH NUT & BOLT	TATA spare parts
886358000013	KIT FOR 54 SPECIAL TOOLS - ACE EV	TATA spare parts
886358000014	VTS DEVICE-AIS140+CAN-HARDWARE W/SIM	TATA spare parts
886358000015	WIRING HARNESS PIGTAIL-PANIC AND CAN	TATA spare parts
886358000016	FUEL SURE SULPHUR KIT - SET OF 2	TATA spare parts
886358000017	FUEL SURE SULPHUR KIT - SET OF 5	TATA spare parts
886358330001	FRONT BEARING PRESSING DOLLY TOOL BS6	TATA spare parts
886358330002	FRONT BEARING DISMANTLING DOLLY TOOL FRO	TATA spare parts
886358330003	FRONT HUB LOCK NUT TIGHTENING TOOL BS6	TATA spare parts
886358330004	FRONT THREAD PROTECTION TOOL HUB PUSHER	TATA spare parts
886358350001	REAR BEARING PRESSING DOLLY TOOL BS6	TATA spare parts
886358350002	REAR BEARING DISMANTLING DOLLY TOOL REAR	TATA spare parts
886358350003	REAR HUB END RING TIGHTENING TOOL BS6	TATA spare parts
886358350004	REAR THREAD PROTECTION TOOL HUB PUSHER B	TATA spare parts
886360000001	MANUAL DASH CONTROL	TATA spare parts
886360000002	FRONT FACE	TATA spare parts
886360000003	FRONT BUMPER	TATA spare parts
886360000004	COMPLETE WINDOW SET	TATA spare parts
886360000005	DASHBOARD ASSEMBLY	TATA spare parts
886360000006	FOG LAMP	TATA spare parts
886360000007	CABIN FAN	TATA spare parts
886360000008	DRIVER DOOR LOCK	TATA spare parts
886360000009	QUARTER GLASS LH	TATA spare parts
886360000010	GRAB HANDLE	TATA spare parts
886360000011	FRONT HEAD LAMP BAZEL RH	TATA spare parts
886360000012	FRONT HEAD LAMP BAZEL LH	TATA spare parts
886360000013	FRONT PANEL	TATA spare parts
886360000014	RH SIDE OUTER UPPER PANEL FRONT SIDE	TATA spare parts

886360000015	RH SIDE OUTER UPPER PANEL REAR SIDE	TATA spare parts
886360000016	RH SIDE OUTER LOWER PANEL FRONT SIDE	TATA spare parts
886360000017	RH SIDE OUTER LOWER PANEL FRONT SIDE	TATA spare parts
886360000018	LH SIDE OUTER UPPER PANEL FRONT SIDE	TATA spare parts
886360000019	LH SIDE OUTER UPPER PANEL FRONT SIDE	TATA spare parts
886360000020	LH SIDE OUTER LOWER PANEL FRONT SIDE	TATA spare parts
886360000021	LH SIDE OUTER LOWER PANEL FRONT SIDE	TATA spare parts
886360000022	FRONT GRILL	TATA spare parts
886360000023	CENTRE FLAP	TATA spare parts
886360000024	REAR FACE LP 1613/52	TATA spare parts
886360000025	AL.WINDOW GUARD RAIL BKT CLOSE 3/4	TATA spare parts
886360000026	AL.WINDOW GUARD RAIL BKT OPEN 3/4	TATA spare parts
886360000027	REAR FACE LP 1613/52 WITH DICKEY	TATA spare parts
886360000028	FRONT FACE LP 1613/52	TATA spare parts
886360000029	FRONT FLAP LP 1613/52	TATA spare parts
886360000030	SIDE SKIRT PLATE ASSY RH	TATA spare parts
886360000031	SIDE SKIRT RAIN FLAP RH	TATA spare parts
886360000032	NAMAKKAL HOOK	TATA spare parts
886360000033	HANDLE GRIPPER	TATA spare parts
886360000034	M8 X 25 BOLT	TATA spare parts
886360000035	M8 NYLOCK NUT	TATA spare parts
886360000036	CSK BOLT M10X40	TATA spare parts
886360000037	NUT M10	TATA spare parts
886360000038	ALUMINIUM TOWER BOLT 4INCH	TATA spare parts
886360000039	PIANO HINGES MS 1INCH	TATA spare parts
886360000040	LORRY HINGES 50MM	TATA spare parts
886360000041	HEX BOLT M6 X 15MM (10.9 GR)	TATA spare parts
886360000042	HEX BOLT M6 X 25 MM (8.8 GR)	TATA spare parts
886360000043	HEX BOLT M6 X 40 MM (8.8 GR)	TATA spare parts
886360000044	SCR HEX SST -M6 X 60MM	TATA spare parts
886360000045	HEX NUT M6 (10.9 GR)	TATA spare parts
886360000046	HEXAGON NYLOCK NUT M6	TATA spare parts
886360000047	PLAIN WASHER SS M6	TATA spare parts
886360000048	HEX SS BOLT M8 X 25 MM	TATA spare parts
886360000049	HEX SS BOLT M8 X 15 MM	TATA spare parts
886360000050	HEX SS BOLT M8 X 30 MM	TATA spare parts
886360000051	PLAIN WASHER 1/2INCH	TATA spare parts
886360000052	HEX NUT 1/2INCH	TATA spare parts
886360000053	POP RIVET M5X1INCH	TATA spare parts
886360000054	HEX BOLT M12 X 50 MM (10.9 GR)	TATA spare parts
886360000055	HEX NUT M12 (10.9 GR)	TATA spare parts
886360000056	M6 NYLOCK NUT	TATA spare parts
886360000057	WOOD SCREW-M6X25L	TATA spare parts
886360000058	PLAIN WASHER M6	TATA spare parts
886360000059	COMPLETE BULKER BODY	TATA spare parts
886360000060	EYE BOLT LOCKING	TATA spare parts
886360000061	HINGE	TATA spare parts

886360000064	WASHER 52.5X34.5X0.80 FOR BGKIT	TATA spare parts
886360000065	WASHER 33X15.5X0.80 FOR BGKIT	TATA spare parts
886360000066	DOWEL 3X28	TATA spare parts
886360000067	SEMIFINISHED STRUCTURE	TATA spare parts
886360000068	TOWER BOLT 6INCH	TATA spare parts
886360000069	HINGE UPPER BERTH	TATA spare parts
886360000070	RUBBER J BEADING	TATA spare parts
886360000071	JACKNIFE DOOR COMPLETE FOR RHD BUS	TATA spare parts
886360000072	FRONT METAL BUMPER (18G. G.I.)	TATA spare parts
886360000073	DESTINATION HIGH DOME TEMP. GLASS(1395X	TATA spare parts
886360000074	FRONT NUMBER PLATE (SIZE:-460X180)	TATA spare parts
886360000075	DRIVERS SEAT	TATA spare parts
886360000076	PARTITION BEND PIPE	TATA spare parts
886360000077	FRONT WAIST RAIL BEADING (SECTION NO - 6	TATA spare parts
886360000078	FRONT GUTTER (SECTION NO - 6250)	TATA spare parts
886360000079	FRONT WHEELCAP	TATA spare parts
886360000080	REAR WHEELCAP	TATA spare parts
886360000081	WIND DEFLECTOR PAINTED	TATA spare parts
886360000082	DOOR CANOPY (FIBRE)	TATA spare parts
886360000083	DASHBOARD PANEL (FIBRE)	TATA spare parts
886360000084	WHEEL ARCH LH	TATA spare parts
886360000085	STR.TATA CABIN RIVIGO ROOF	TATA spare parts
886360000086	STR.TATA CABIN RIVIGO REAR	TATA spare parts
886360000087	STR.TATA CABIN RIVIGO RHS	TATA spare parts
886360000088	STR.TATA CABIN RIVIGO FLOOR	TATA spare parts
886360000089	STR.TATA CABIN RIVIGO LHS	TATA spare parts
886360000090	DOOR RH	TATA spare parts
886360000091	DOOR LH	TATA spare parts
886360000092	DOOR INNER PANEL FRP	TATA spare parts
886360000093	BATTERY BOX WITH LOWER SLEEPER	TATA spare parts
886360000094	DOOR GRILL	TATA spare parts
886360000095	ASSY SIDE WINDOW	TATA spare parts
886360000096	GRILL FRONT INDICATOR TATA	TATA spare parts
886360000097	GRILL SIDE INDICATOR TATA	TATA spare parts
886360000098	SLEEPER COMPARTMENT CHAIN	TATA spare parts
886360000099	DOOR HANDLE	TATA spare parts
886360000100	CABIN LADDER	TATA spare parts
886360000101	UPPER BIRTH	TATA spare parts
886360000102	TOOL BOX	TATA spare parts
886360000103	762 BAY RHS REAR END WINDOW COMPLETE W/	TATA spare parts
886360000104	EMERGENCY DOOR WINDOW COMPLETE	TATA spare parts
886360000105	WAIST LEVEL BEADING	TATA spare parts
886360000106	P.V.C INSERT(GREY) FOR PART	TATA spare parts
886360000107	P.V.C BEADING END FOR PART	TATA spare parts
886360000108	WAIST RAIL BEADING (SECTION NO. - 6346)	TATA spare parts
886360000110	CUT SOCKET-SMALL	TATA spare parts
886360000111	25MM I.D. CASTED SOCKET	TATA spare parts



886360000112	SEMIFINISHED STRUCTURE	TATA spare parts
886360000113	ASSLY CUBBED BODY W/O HYD & SUBFRAME 5CU	TATA spare parts
886360000114	ASSLY SIDE PANEL LH/RH	TATA spare parts
886360000115	U BOLT M16*380	TATA spare parts
886360000116	LOCKING PIN OD-25*ID-20*58L.	TATA spare parts
886360000117	FORK RH (THREAD)105*40*40 [407/909/912TI	TATA spare parts
886360000118	FORK LH (THREAD)105*40*40 [407/909TIP]	TATA spare parts
886360000119	LOCKING TAIL GATE ROD DIA32*50	TATA spare parts
886360000120	TAIL GATE HINGE SPACER¿¿ OD-35*OD-26*20L	TATA spare parts
886360000121	SHAFT DIA 40*670	TATA spare parts
886360000122	SPARY SUPPRESSION 500*400	TATA spare parts
886360000123	SPARY SUPPRESSION 500*300	TATA spare parts
886360000124	RUBBER PAD [EPDM]200*70*25 MM THK[222887	TATA spare parts
886360000125	HYDRAULIC KIT WIS-23 MTQ[B] LPK912 TML	TATA spare parts
886360000129	ASLY CUBBED BODY W/O HYD 2.66CUM-SK-407-	TATA spare parts
886360000130	ASSLY SIDE PANEL LH/RH 2.66CUM-SK-407-TI	TATA spare parts
886360000131	MUDFLAP 709 [264081106301] .	TATA spare parts
886360000132	HANDLE LH (GREEN PASSI) 265170905606	TATA spare parts
886360000133	HANDLE RH (GREEN PASSI) 265170905607	TATA spare parts
886360000134	HYD.KIT WITH PUMP&PTO WIS-28(TA) (SK407)	TATA spare parts
886360000135	RUBBER PAD [EPDM]200*70*30 MM THK[222887	TATA spare parts
886360000136	SUNVISOR	TATA spare parts
886360000137	SUNVISOR	TATA spare parts
886360000138	WINDOW LPO 1512/55	TATA spare parts
886360000139	COMPLETE WINDOW SET	TATA spare parts
886360000140	SAFARI HANDLE	TATA spare parts
886360000141	INTERCOM SET	TATA spare parts
886360000142	DUST BIN	TATA spare parts
886360000143	8 WAY MODULISE SWITCH BOX WITH PLATE	TATA spare parts
886360000144	MCB	TATA spare parts
886360000145	TOWER BOLT	TATA spare parts
886360000146	ROOF BKT.	TATA spare parts
886360000147	FIRST AID BOX	TATA spare parts
886360000148	FIRE CYLINDER	TATA spare parts
886360000149	TOGGLE CLAMP	TATA spare parts
886360000150	CURTAIN HOOK	TATA spare parts
886360000151	REVOLVING HANGER	TATA spare parts
886360000152	FRP HATRACK	TATA spare parts
886360000153	SS HANDLE	TATA spare parts
886360000154	SEAT BELT	TATA spare parts
886360000155	DOCTOR SEAT	TATA spare parts
886360000156	FIRE EXTINGUISHER ABC TYPE BS6	TATA spare parts
886360000157	SEAT BELT-ARIA APPROVE BS6	TATA spare parts
886360000158	ROOF LED LIGHT BS6	TATA spare parts
886360000159	PATIENT CABIN SPOT LIGHT BS6	TATA spare parts
886360000160	DUSTBIN BS6	TATA spare parts
886360000161	CAOCH FAN BS6	TATA spare parts

886360000162	4 LED BLIKERS (RED-BLUE COLOUR) BS6	TATA spare parts
886360000163	8 LED BLINKERS LH F/RH/ REAR BS6	TATA spare parts
886360000164	WORK LAMP BS6	TATA spare parts
886360000165	EXTERNAL POWER SOCKET BS6	TATA spare parts
886360000166	12V SOCKETS BS6	TATA spare parts
886360000167	IV HOOKS BS6	TATA spare parts
886360000168	HAND SANATISER BS6	TATA spare parts
886360000169	PIANO SWITCH BS6	TATA spare parts
886360000170	MEDICAL BINS SET (06PCS) BS6	TATA spare parts
886360000171	AC OUTLET VENTS-FR GRADE BS6	TATA spare parts
886360000172	BIN SHUTTER BS6	TATA spare parts
886360000173	INVERTER 850VA BS6	TATA spare parts
886360000174	REAR DOOR OPEN ALARM SWITCH BS6	TATA spare parts
886360000175	REAR DOOR SIREN BS6	TATA spare parts
886360000176	HUMIDIFIER BOTTLE WITH FLOW METER SET BS	TATA spare parts
886360000177	HEADRACK FRAME BS6	TATA spare parts
886360000178	OXYGEN DELIVERY SYSTEM BS6	TATA spare parts
886360000179	OXYGEN REGULATOR (D-TYPE CYLINDER) BS6	TATA spare parts
886360000180	RAMP PLATE SET BS6	TATA spare parts
886360000181	B-TYPE OXYGEN TROLLY BS6	TATA spare parts
886360000182	D-TYPE OXYGEN TROLLY BS6	TATA spare parts
886360000183	EMT SEAT BS6	TATA spare parts
886360000184	PARTITION WINDOW GLASS FRAME ASSEMBLY BS	TATA spare parts
886360000185	OXYGEN REGULATOR (B-TYPE CYLINDER) BS6	TATA spare parts
886360000186	HIGH PRESSURE OXYGEN PIPE BS6	TATA spare parts
886360000187	SS BRADED HIGH PRESSURE OXYGEN CYLLINDER	TATA spare parts
886360000188	SS BRADED HIGH PRESSURE OXYGEN CYLINDER	TATA spare parts
886360000189	PATIENT CABIN VINYL ASSEMBLY BS6	TATA spare parts
886360000190	12- MODULAR SWITCH BOARD ASSEMBLY BS6	TATA spare parts
886360000191	PATIENT CABIN AC SUCTION GRILL BS6	TATA spare parts
886360000192	CABINET CHANNEL SOFT CLOSE BS6	TATA spare parts
886360000193	REGULATOR ADOPTER BS6	TATA spare parts
886360000194	ATTENDANT SEAT ASSEMBLY BS6	TATA spare parts
886360000195	ATTENDANT SEAT BACK REST BS6	TATA spare parts
886360000196	EMERGENCY LIGHT BAR DIAPHRAGM BS6	TATA spare parts
886360000197	AUTOLOADING STRECHER SATPUDA BS6	TATA spare parts
886360000198	WARM LIGHT BS6	TATA spare parts
886360000199	EXTERNAL CHARGING SOCKET BS6	TATA spare parts
886360000200	FUSE BOX D.C BS6	TATA spare parts
886360000201	FUSE BOX A.C BS6	TATA spare parts
886360000202	12-MODEL SWITCH BOARD BS6	TATA spare parts
886360000203	6-MODEL SWITCH BOARD BS6	TATA spare parts
886360000204	3-MODEL SWITCH BOARD BS6	TATA spare parts
886360000205	16A- SWITCH BS6	TATA spare parts
886360000206	6A SWITCH BS6	TATA spare parts
886360000207	16A-PLUG BS6	TATA spare parts
886360000208	6A- PLUG BS6	TATA spare parts

886360000209	DOOR SWITCH BS6	TATA spare parts
886360000210	JUNCTION BOX SE/MF-5 BS6	TATA spare parts
886360000211	JUNCTION BOX SI-108 TRIUMP BS6	TATA spare parts
886360000212	CIGERETTE LIGHTER BS6	TATA spare parts
886360000213	TUBELIGHT BS6	TATA spare parts
886360000214	EXTENSION WIRE BS6	TATA spare parts
886360000215	FAN BS6	TATA spare parts
886360000216	INVERTER CUTOFF SWITCH BS6	TATA spare parts
886360000217	DOCTOR SEAT BS6	TATA spare parts
886360000218	DOCTOR SEAT BELT BS6	TATA spare parts
886360000219	MEDICAL CABINET BS6	TATA spare parts
886360000220	SQUAD BENCH BS6	TATA spare parts
886360000221	SQUAD BENCH BELT BS6	TATA spare parts
886360000222	IV HOOK BS6	TATA spare parts
886360000223	SALINE HOOK BS6	TATA spare parts
886360000224	PARTITION WINDOW BS6	TATA spare parts
886360000225	HEAD RACK WINDOW BS6	TATA spare parts
886360000226	FIRE EXTINGUISHER BS6	TATA spare parts
886360000227	FIRE EXTINGUISHER BRACKET BS6	TATA spare parts
886360000228	A/C RETURN FLOW BS6	TATA spare parts
886360000229	A/C VENT BS6	TATA spare parts
886360000230	OXYGEN COMPARTMENT LOCKING SYSTEM BS6	TATA spare parts
886360000231	OXYGEN COMPARTMENT DOOR LOCKING SYSTEM	TATA spare parts
886360000232	OXYGEN CYLINDER PLATFORM BS6	TATA spare parts
886360000233	A/C BS6	TATA spare parts
886360000234	SPOT LIGHT COVER BS6	TATA spare parts
886360000235	SELF LOADER STRETCHER BS6	TATA spare parts
886360000236	SELF LOADER STRETCHER BS6	TATA spare parts
886360000237	SELF LOADER STRETCHER BS6	TATA spare parts
886360000238	UNIT DIAGPHARM BS6	TATA spare parts
886360000239	AMPLIFIER BS6	TATA spare parts
886360000240	WORK LAMP BS6	TATA spare parts
886360000241	LIGHT BAR DOOM BS6	TATA spare parts
886360000242	LIGHT BAR BASE BS6	TATA spare parts
886360000243	MIC BS6	TATA spare parts
886360000244	AUTOLOADING STRECHER SPENCER BS6	TATA spare parts
886360000245	GRAB HANDLE BS6	TATA spare parts
886360000246	BIN LOCK BS6	TATA spare parts
886360000247	D-HANDLE BS6	TATA spare parts
886360000248	SYRINGE PUMP ROD BS6	TATA spare parts
886360000249	PATIENT CABIN LH PANNEL BS6	TATA spare parts
886360000250	PATIENT CABIN RH PANNEL BS6	TATA spare parts
886360000251	PATEINT CABIN ROOF PANNEL BS6	TATA spare parts
886360000252	PATIENT CABIN PARTION WALL PANNEL BS6	TATA spare parts
886360000253	PARTION WINDOW FRP RING BS6	TATA spare parts
886360000254	D-TYPE CYLINDER DOOR ASSEMBLY BS6	TATA spare parts
886360000255	CYLINDER DOOR HINGE BS6	TATA spare parts

886360000256	DRIVER CABIN PARTION WALL FRP BS6	TATA spare parts
886360000257	DRIVER CABIN ROOF PANNEL ASSEMBLY BS6	TATA spare parts
886360000258	ATTENDANT SEAT FRP ASSEMBLY BS6	TATA spare parts
886360000259	GLUCOSE BOTTLE STAND FRP COVER BS6	TATA spare parts
886360000260	CABINET WITH DRAWERS BS6	TATA spare parts
886360000261	SOAP DISPENSAR BS6	TATA spare parts
886360000262	WASH BASIN SET BS6	TATA spare parts
886360000263	CANOPY RETRO KIT 19CUM RB PRIMA BS6	TATA spare parts
886360000264	SLIDER BS6	TATA spare parts
886360000265	SEATER BS6	TATA spare parts
886360000266	SQUAD BENCH LOWER COVER4 SEATER BS6	TATA spare parts
886360000267	SQUAD BENCH BACKREST BS6	TATA spare parts
886360000268	OXYGEN HOSE (2M) BS6	TATA spare parts
886360000269	OXYGEN CYLINDER 47.2L BS6	TATA spare parts
886360000270	PLYWOOD BS6	TATA spare parts
886360000271	OXYGEN COMPARTMENT DOOR BS6	TATA spare parts
886360000272	OXYGEN COMPARTMENT DOOR HINGES BS6	TATA spare parts
886360000273	HANDLE MOUNTING END COVER BS6	TATA spare parts
886360000274	HANDLE SUPPORT BS6	TATA spare parts
886360000275	HANDLE ROD BS6	TATA spare parts
886360000276	VERTICAL HANDLE AT DOOR BS6	TATA spare parts
886360000277	HEAD RACK BS6	TATA spare parts
886360000278	FRAME BS6	TATA spare parts
886360000279	LEVER FOR TRENDELENBURG SELECTION AND RE	TATA spare parts
886360000280	TRENDELENBURG BOARD BS6	TATA spare parts
886360000281	FOLDING SIDEBARS BS6	TATA spare parts
886360000282	BACKREST PISTON BS6	TATA spare parts
886360000283	FOLDING BACKREST BS6	TATA spare parts
886360000284	LOADING WHEEL BS6	TATA spare parts
886360000285	FRONT LEGS BS6	TATA spare parts
886360000286	FRONT WHEELS BS6	TATA spare parts
886360000287	OPENING/CLOSING PISTON FOR FRONT LEGS BS	TATA spare parts
886360000288	REAR LEGS BS6	TATA spare parts
886360000289	TURNING REAR WHEELS WITH BRAKE BS6	TATA spare parts
886360000290	OPENING/CLOSING PISTON FOR REAR LEGS BS6	TATA spare parts
886360000291	FRONT LEGS FOLDING LEVER BS6	TATA spare parts
886360000292	REAR LEGS FOLDING LEVER BS6	TATA spare parts
886360000293	ANTERIOR FIXATION SUPPORT BS6	TATA spare parts
886360000294	SIDEBARS BLOCKING SYSTEM BS6	TATA spare parts
886360000295	REAR LOCKING SYSTEM BS6	TATA spare parts
886360000296	LEVER FOR TRENDELENBURG AND FOWLER BS6	TATA spare parts
886360000297	TRENDELENBURG AND FOWLER PATIENT BOARD	TATA spare parts
886360000300	HEAD REST BS6	TATA spare parts
886360000301	TELESCOPIC MECHANISM BS6	TATA spare parts
886360000302	LEG REST BS6	TATA spare parts
886360000303	RATCHET ROD LEG REST BS6	TATA spare parts
886360000304	SIDE RAILING BS6	TATA spare parts

886360000305	TOP FRAME HANDLE BS6	TATA spare parts
886360000306	ACTUATING HANDLE REAR BS6	TATA spare parts
886360000307	ACTUATING HANDLE FRONT BS6	TATA spare parts
886360000308	REAR SUPPORT WHEEL ASSLY BS6	TATA spare parts
886360000309	RSW ?100X22 BS6	TATA spare parts
886360000310	LINKAGE ASSLY BS6	TATA spare parts
886360000311	REAR LEG ASSLY (WITH WHEELS) BS6	TATA spare parts
886360000312	RLAW ?50X22 BS6	TATA spare parts
886360000313	RLAW ?50X23 BS6	TATA spare parts
886360000314	RLA NYLON PAD BS6	TATA spare parts
886360000315	FRONT LEG ASSLY (WITH WHEELS) BS6	TATA spare parts
886360000316	FLAW ?30X24 BS6	TATA spare parts
886360000317	FLAWF ?125X31 BS6	TATA spare parts
886360000318	FLA NYLON PAD BS6	TATA spare parts
886360000319	FRONT SUPPORT WHEEL BRACKET BS6	TATA spare parts
886360000320	MIDDLE SUPPORT WHEEL BRACKET BS6	TATA spare parts
886360000321	REAR GUIDE PIN BS6	TATA spare parts
886360000322	MATTRESS BS6	TATA spare parts
886360000323	ANCHOR ASSLY COVER BS6	TATA spare parts
886360000324	FLAP BRKT ANCHOR ASSLY BS6	TATA spare parts
886360000325	Z-BRKT ANCHOR ASSLY BS6	TATA spare parts
886360000326	GUIDE PLATE RR LOCK BS6	TATA spare parts
886360000327	PULL HANDLE BS6	TATA spare parts
886360000328	FRONT LOCK UC NC BS6	TATA spare parts
886360000329	UC REAR LOCK NC BS6	TATA spare parts
886360000330	FOOT OPERATED PUMP BS6	TATA spare parts
886360000331	DIGITAL ODS SPENCER BS6	TATA spare parts
886360000332	STICKER SET(BASIC LIFE SUPPORT) BS6	TATA spare parts
886360000333	HANDLE BS6	TATA spare parts
886360000334	CLOCK BS6	TATA spare parts
886360000335	CURTAIN BS6	TATA spare parts
886360000336	OXYGEN DELIVERY SYSTEM BS6	TATA spare parts
886360000337	OXYGEN REGULATOR BS6	TATA spare parts
886360000338	FLOOR MAT BS6	TATA spare parts
886360000339	RUBBER BEEDING (L - 1.35 M) BS6	TATA spare parts
886360000340	ROOF HANDLE BS6	TATA spare parts
886360000341	WHEEL HUMP BS6	TATA spare parts
886360000342	OXYGEN FLEXIBLE HOSE (1.25M) BS6	TATA spare parts
886360000343	PASSENGER DOOR BS6	TATA spare parts
886360000344	JK DOOR ROLLER ASSY BS6	TATA spare parts
886360000345	HINGE WITH HANDLE FOR PESSERGER DOOR BS6	TATA spare parts
886360000346	BRUSH BS6	TATA spare parts
886360000347	WINDSHIELD LCV BS6	TATA spare parts
886360000348	WINDSHIELD LCV BS6	TATA spare parts
886360000349	FRONT BUMPER LCV L-FACIA BS6	TATA spare parts
886360000350	REAR BUMPER LCV L-FACIA BS6	TATA spare parts
886360000351	REAR BUMPER LCV S-FACIA BS6	TATA spare parts

886360000352	DRIVER DOOR HAND HOLD BS6	TATA spare parts
886360000353	GLASS BRAKE HAMMER SMALL BS6	TATA spare parts
886360000354	MUDFLAP LCV BS6	TATA spare parts
886360000355	FRONT FACE LP LCV L-FACIA BS6	TATA spare parts
886360000356	FRONT FACE LP LCV S-FACIA BS6	TATA spare parts
886360000357	REAR FACE LP LCV BS6	TATA spare parts
886360000358	REAR FACE LP LCV BS6	TATA spare parts
886360000359	FRONT FLAP LP LCV BS6	TATA spare parts
886360000360	STOP SWITCH BS6	TATA spare parts
886360000361	STICKER BS6	TATA spare parts
886360000362	DOOR PARTITION BS6	TATA spare parts
886360000363	DRIVER PARTITION BS6	TATA spare parts
886360000364	ROOF HATCH BS6	TATA spare parts
886360000365	WINDOW BS6	TATA spare parts
886360000366	PEEP WINDOW LCV BS6	TATA spare parts
886360000367	TRAP COVER ROUND BS6	TATA spare parts
886360000368	COVER BS6	TATA spare parts
886360000369	DASH BOARD LCV BS6	TATA spare parts
886360000370	ENGINE HOOD LCV L FACIA BS6	TATA spare parts
886360000371	ENGINE HOOD LCV S FACIA BS6	TATA spare parts
886360000372	FRONT WIRE MESH LCV BS6	TATA spare parts
886360000373	FRONT WIRE MESH LCV BS6	TATA spare parts
886360000374	REAR WIRE MESH LCV BS6	TATA spare parts
886360000375	REAR WIRE MESH LCV BS6	TATA spare parts
886360000376	WIREMESH LCV BS6	TATA spare parts
886360000377	ELS (12V) BS6	TATA spare parts
886360000378	FDAS BS6	TATA spare parts
886360000379	TARPAULIN COVER BS6	TATA spare parts
886360000380	VINYLE (PER SQM) BS6	TATA spare parts
886360000383	HINGE RIVETS 7.8 MM BS6	TATA spare parts
886360000384	HINGE ASSY.12INCH BS6	TATA spare parts
886360000385	LOCK SET REAR DOOR BS6	TATA spare parts
886360000386	INNER ROOF LIGHT BS6	TATA spare parts
886360000387	SIDE MARKER LIGHT BS6	TATA spare parts
886360000388	BODY LOCK CLAMPS BS6	TATA spare parts
886360000390	MUD FLAP BS6	TATA spare parts
886360000391	REFLECTIVE TAPE RED ( L= 2.6 MTR ) BS6	TATA spare parts
886360000392	REFLECTIVE TAPE YELLOW 50 MM WIDTH BS6	TATA spare parts
886360000393	BALLATA ( L= 14 MTR ) BS6	TATA spare parts
886360000394	DOOR HINGE BS6	TATA spare parts
886360000395	TEA FLASK BS6	TATA spare parts
886360000396	FIRE EXTINGUISHER BS6	TATA spare parts
886360000397	WINDOW BS6	TATA spare parts
886360000398	BENCH SEAT BS6	TATA spare parts
886360000399	WATER KATTLE BS6	TATA spare parts
886360000400	WIND DEFLECTOR BS6	TATA spare parts
886360000401	VEHICLE BODY BS6	TATA spare parts

886360000402	HINGE PASSENGER DOOR BS6	TATA spare parts
886360000403	MUDFLAP BS6	TATA spare parts
886360000404	WIPER ARM LH BS6	TATA spare parts
886360000405	NUT M8 BS6	TATA spare parts
886360000406	ROOF HATCH BS6	TATA spare parts
886360000407	FLOOD LIGHT BS6	TATA spare parts
886360000408	SIDE STAND BRACKET BS6	TATA spare parts
886360000409	TIE-BAR ASSEMBLY	TATA spare parts
886360000410	LOFT TANK BS6	TATA spare parts
886360000411	COMMODOE BS6	TATA spare parts
886360000412	CABINET BS6	TATA spare parts
886360000413	WASH BASIN BS6	TATA spare parts
886360000414	WASTE WATER TANK BS6	TATA spare parts
886360000415	L- DROOP BS6	TATA spare parts
886360000416	REAR WIND SHIELD MCV BS6	TATA spare parts
886360000417	SUPPRESSION TANK 6KG BS6	TATA spare parts
886360000418	FIRE EXTINGUISHER(4KG) BS6	TATA spare parts
886360000419	CATEGORY 6 MIRROR BS6	TATA spare parts
886360000420	HAND RAIL BS6	TATA spare parts
886360000421	GLASS BRAKE HAMMER LARGE BS6	TATA spare parts
886360000422	FRONT FACE LP MCV BS6	TATA spare parts
886360000423	DRIVER PARTITION BS6	TATA spare parts
886360000424	BENCH SEAT BS6	TATA spare parts
886360000425	BENCH SEAT BS6	TATA spare parts
886360000426	TARPAULIN COVER BS6	TATA spare parts
886360000427	TAP.HANDLE RUSTFREE BS6	TATA spare parts
886360000428	LOCKING PLATE BS6	TATA spare parts
886360000429	COMPRESSION SPRING E01448 BS6	TATA spare parts
886360000430	HEX.NUT M5 A2F- 8-ZNPBL DIN 934 BS6	TATA spare parts
886360000431	CARRYING ROLLER KPL.LEFT 8.. 10M3 BS6	TATA spare parts
886360000432	CARRYING ROLLER KPL. RIGHT 8..10M3 BS6	TATA spare parts
886360000433	HEX.SCREW DIN 931 M 16 X 70-10.9-GT500 B	TATA spare parts
886360000434	PLATE M.2L 21 A=125 B= 26 C= 20 BS6	TATA spare parts
886360000435	CARRYING ROLLER COVER LEFT C BS6	TATA spare parts
886360000436	ROLLER D=250 CPL. 8-10 M3 BS6	TATA spare parts
886360000437	BEARING BLOCK BS6	TATA spare parts
886360000438	HEX.SCREW M 8X 12 VERZ.8.8 DIN 933 BS6	TATA spare parts
886360000439	CARRYING ROLLER COVER RIGHT C BS6	TATA spare parts
886360000440	MOUNTING PLATE FOR TENSION LOCK BS6	TATA spare parts
886360000441	COVER FOR SUPPORTING ARM BS6	TATA spare parts
886360000442	FLEXIBLE EDGE PROTECTION BS6	TATA spare parts
886360000443	DISC 8.4 X 30 X 1.5 A2 BS6	TATA spare parts
886360000444	HEX.SCREW M 8X 25 (1.4401)DIN 933-A2C BS	TATA spare parts
886360000445	COUNTER HOLDER LH SIDE BS6	TATA spare parts
886360000446	COUNTER HOLDER RH SIDE BS6	TATA spare parts
886360000447	COUNTER HOLDER LONG VERSION BS6	TATA spare parts
886360000448	COUNTER HOLDER BS6	TATA spare parts

886360000449	PRESSURE PIECE BS6	TATA spare parts
886360000450	WASHER DIN 6916 21-C45-TZN BS6	TATA spare parts
886360000451	SQUARE BLOCK 22 = 50 LG. BS6	TATA spare parts
886360000452	WATER LINE C-ARM INSIDE ( RH ) BS6	TATA spare parts
886360000453	PLATE M1 M10 BS6	TATA spare parts
886360000454	SCALE PLATE 500 L DL BS6	TATA spare parts
886360000455	PRESSURIZED TANK 500 LTR. - RH BS6	TATA spare parts
886360000456	SPACER M12 - 8 THK. BS6	TATA spare parts
886360000457	WATER LINE PIPE 8FHC RH BS6	TATA spare parts
886360000458	THREADED PIPEDN25 =1050 ONE SIDE THREAD	TATA spare parts
886360000459	HYDER CLAMP - 30S BS6	TATA spare parts
886360000460	SUPPORT BRACKET PNEUMATIC CONTROL BOX BS6	TATA spare parts
886360000461	HEX.SCREW DIN 933 M 16 X 30-8.8-ZINC BS6	TATA spare parts
886360000462	DEFENSE GRATE BS6	TATA spare parts
886360000463	SPRING TOP BRACKET TATA BS VI BS6	TATA spare parts
886360000464	HEX. BOLT M14X1.5X50 10.9 GT500 BS6	TATA spare parts
886360000465	LOCK NUT M14X1.5 DIN 980 10 BS6	TATA spare parts
886360000466	SPACER SLEEVE M14 X 4 BS6	TATA spare parts
886360000467	HEX.HD.BT.DIN931 M16X130LG. 10.9GR- A2C	TATA spare parts
886360000468	SPRING BS6	TATA spare parts
886360000469	WASHER - ID -16.5 BS6	TATA spare parts
886360000470	MUDGUARD RH BS6	TATA spare parts
886360000471	MUDGUARD LH BS6	TATA spare parts
886360000472	MUDGUARD BEND SUPPORT BS6	TATA spare parts
886360000473	BEND SUPPORT BCS RH BS6	TATA spare parts
886360000474	BEND SUPPORT BCS LH BS6	TATA spare parts
886360000475	PIPE CLAMP - 42.7 BS6	TATA spare parts
886360000476	SPRAY SUPPRESSION MAT 570 X 900 BS6	TATA spare parts
886360000477	FLAT STRIP BS6	TATA spare parts
886360000478	SPRAY SUPPRESSION MAT 200 X 2415 BS6	TATA spare parts
886360000479	HEX..SCREW DIN933 M 8 X 45-8.8-A2C BS6	TATA spare parts
886360000480	S DOOR HANDLE BS6	TATA spare parts
886360000481	PEEP WINDOW MCV BS6	TATA spare parts
886360000482	DECALS BS6	TATA spare parts
886360000483	DESTINATION BOARD BS6	TATA spare parts
886360000484	EMT SEAT- FOLDABLE BS6	TATA spare parts
886360000485	RAMP PLATE SET BS6	TATA spare parts
886360000486	DOCTOR EMT SEAT BS6	TATA spare parts
886360000487	HEIGHT MARKER BS6	TATA spare parts
886360000488	REAR VIEW MIRROR BS6	TATA spare parts
886360000489	REAR VIEW MIRROR BKT BS6	TATA spare parts
886360000490	DASH BOARD ASSEMBLY WITH BONNET BS6	TATA spare parts
886360000491	CO- DRIVER SEAT BS6	TATA spare parts
886360000492	FIRST AID BOX BS6	TATA spare parts
886360000493	DRIVER DOOR WINDOW BS6	TATA spare parts
886360000494	CO-DRIVER DOOR WINDOW BS6	TATA spare parts
886360000495	QUARTER GLASS BS6	TATA spare parts



886360000496	C- HANDLE BS6	TATA spare parts
886360000497	D- HANDLE BS6	TATA spare parts
886360000498	SUN VISOR BS6	TATA spare parts
886360000499	MSL LOCK ASSEMBLY BS6	TATA spare parts
886360000500	BUDGET LOCK BS6	TATA spare parts
886360000501	REAR SIDE WINDOW BS6	TATA spare parts
886360000502	REAR DOOR GLASS BS6	TATA spare parts
886360000503	REAR DOOR GLASS RUBBER BIDDING WITH KEY B	TATA spare parts
886360000504	REAR DOOR HINGE BS6	TATA spare parts
886360000505	REAR REFLECTOR ROUND TYPE BS6	TATA spare parts
886360000506	ROLLING CURTAIN BS6	TATA spare parts
886360000507	HAND SANITIZER HOLDER BS6	TATA spare parts
886360000508	SEAT BELT-ARIA APPROVE- 3 POINT BS6	TATA spare parts
886360000509	DRIVER CO- DRIVER DOOR HINGE BS6	TATA spare parts
886360000510	STICKER SET(ADVANCE LIFE SUPPORT) BS6	TATA spare parts
886360000511	PARTITION BS6	TATA spare parts
886360000512	BODY MTG STOOL 145L BS6	TATA spare parts
886360000513	BODY MTG STOOL 110L BS6	TATA spare parts
886360000514	MUD GUARD ASSY. BS6	TATA spare parts
886360000515	CYLINDER TOP BKT BS6	TATA spare parts
886360000516	CYLINDER MTG BKT LOWER BS6	TATA spare parts
886360000517	BODY FULCRUM PLATE BS6	TATA spare parts
886360000518	TAIL DOOR BS6	TATA spare parts
886360000519	BODY PROB ASSY BS6	TATA spare parts
886360000520	BODY MTG PIN BS6	TATA spare parts
886360000521	BODY MTG BUSH BS6	TATA spare parts
886360000522	CYLINDER MTG BOTTOM PIN BS6	TATA spare parts
886360000523	CYLINDER MTG TOP PIN BS6	TATA spare parts
886360000524	PUSH PULL CABLE BS6	TATA spare parts
886360000525	HYDRAULIC KIT TC 0180 BS6	TATA spare parts
886360000526	PTO DRIVEN PUMP 5 SPEED BS6	TATA spare parts
886360000527	PARTITION DOOR BS6	TATA spare parts
886360000528	TARPAULIN BS6	TATA spare parts
886360000529	BODY BS6	TATA spare parts
886360000530	SUB FRAME BS6	TATA spare parts
886360000531	BUSH OD=40 ID=30 L=16MM BS6	TATA spare parts
886360000532	BUSH OD=40 ID=30 L=58MM BS6	TATA spare parts
886360000533	BUSH OD=40 ID=25.5 L=50MM BS6	TATA spare parts
886360000534	BUSH OD=50 ID=40 L=18MM BS6	TATA spare parts
886360000535	BUSH OD=50 ID=40 L=20MM BS6	TATA spare parts
886360000536	BUSH OD=50 ID=40 L=9MM BS6	TATA spare parts
886360000537	OD25 X L-115MM BS6	TATA spare parts
886360000538	BOD40 X ID29.75 X L-115MM BS6	TATA spare parts
886360000539	BOD50 X OD39.5 X L-103MM BS6	TATA spare parts
886360000540	CYLINDER TOP PIN-BOD50XOD39.75X153L BS6	TATA spare parts
886360000541	HYD CYLINDER- WIPRO TC246 - ACE GOLD HOP	TATA spare parts
886360000542	LANDING LEG BS6	TATA spare parts

886360000543	TARPAULIN BS6	TATA spare parts
886360000544	MUD GUARD BS6	TATA spare parts
886360000545	BATTERY COVER BS6	TATA spare parts
886360000546	FUEL COVER BS6	TATA spare parts
886360000547	5 SPEED PTO PUMP FOR ACE PETROL WITH PUS	TATA spare parts
886360000548	STICKER (TATA) BS6	TATA spare parts
886360000549	PATIENT CABIN LH PANEL BS6	TATA spare parts
886360000550	PATIENT CABIN RH PANEL BS6	TATA spare parts
886360000551	PATIENT CABIN ROOF PANEL BS6	TATA spare parts
886360000552	PATIENT CABIN PARTITION WALL PANEL BS6	TATA spare parts
886360000553	PARTITION WINDOW FRP RING BS6	TATA spare parts
886360000554	PATIENT CABIN VINYL ASSEMBLY BS6	TATA spare parts
886360000555	SEAT BELT-ARIA APPROVE BS6	TATA spare parts
886360000556	PATIENT CABIN AC SUCTION GRILL BS6	TATA spare parts
886360000557	CABINET CHANNEL SOFT CLOSE BS6	TATA spare parts
886360000558	DRIVER CABIN PARTITION WALL FRP BS6	TATA spare parts
886360000559	AMPLIFIER FRP COVER BS6	TATA spare parts
886360000560	DRIVER CABIN ROOF PANEL ASSEMBLY BS6	TATA spare parts
886360000561	ATTENDANT SEAT FRP ASSEMBLY BS6	TATA spare parts
886360000562	GLUCOSE BOTTLE STAND FRP COVER BS6	TATA spare parts
886360000563	ATTENDANT SEAT ASSEMBLY BS6	TATA spare parts
886360000564	ATTENDANT SEAT BACK REST BS6	TATA spare parts
886360000565	CABINET WITH DRAWERS BS6	TATA spare parts
886360000566	WASH BASIN SET BS6	TATA spare parts
886360000567	HAT RACK FRAME BS6	TATA spare parts
886360000568	DOCTOR SEAT BS6	TATA spare parts
886360000569	PARTITION WINDOW GLASS FRAME ASSEMBLY BS6	TATA spare parts
886360000570	STICKER SET BS6	TATA spare parts
886360000571	FOLDABLE TABLE BS6	TATA spare parts
886360000572	PORTABLE OXYGEN CYLINDER BS6	TATA spare parts
886360000573	HAND SANITISER STAND BS6	TATA spare parts
886360000574	DIGITAL CLOCK BS6	TATA spare parts
886360000575	ELECTRIC SUCTION PUMP BS6	TATA spare parts
886360000576	DOOR LIGHT BS6	TATA spare parts
886360000577	OXYGEN FLOW METER WITH DIGITAL DISPLAY B	TATA spare parts
886360000578	SUCTION PUMP (MANUAL & HANDHELD) BS6	TATA spare parts
886360000579	TRAVELLING VENTILATOR BS6	TATA spare parts
886360000580	CPR BOARD BS6	TATA spare parts
886360000581	STETHOSCOPE BS6	TATA spare parts
886360000582	BP APPARATUS BS6	TATA spare parts
886360000583	AUTOMATED EXTERNAL DEFIBRILLATOR (AED) B	TATA spare parts
886360000584	PNEUMATIC SPLINTS BS6	TATA spare parts
886360000585	CERVICAL COLLARS BS6	TATA spare parts
886360000586	CATHETERIZATIONS SET BS6	TATA spare parts
886360000587	CHEST DRAINAGE TUBES BS6	TATA spare parts
886360000588	HAEMOSTATIC SETS BS6	TATA spare parts
886360000589	WASHING EQUIPMENT BS6	TATA spare parts

886360000590	WHEEL CHAIR AND TROLLEY BS6	TATA spare parts
886360000591	TONGUE DEPRESSOR BS6	TATA spare parts
886360000592	IV DRIPS BS6	TATA spare parts
886360000593	LOCK BS6	TATA spare parts
886360000594	VELCRO BS6	TATA spare parts
886360000595	SCOOTER LOCK 535 BS6	TATA spare parts
886360000596	JK DOOR SWITCH BS6	TATA spare parts
886360000597	GAS BALANCER BS6	TATA spare parts
886360000598	RH DOOR INNER HANDLE BS6	TATA spare parts
886360000599	TAILDOOR ASSY BS6	TATA spare parts
886360000600	TAILDOOR LOCKING MECHANISM BS6	TATA spare parts
886360000601	DOOR HINGES BS6	TATA spare parts
886360000602	ROOF LIGHT BS6	TATA spare parts
886360000603	16AMP MCB BS6	TATA spare parts
886360000604	PANEL SWITCH BOARD BS6	TATA spare parts
886360000605	TOUGHENED GLASS BS6	TATA spare parts
886360000606	BULL BEEDING BS6	TATA spare parts
886360000607	BALATA BS6	TATA spare parts
886360000608	CONTAINER LOCK BS6	TATA spare parts
886360000609	SUBFRAME ASSY BS6	TATA spare parts
886360000610	RACK ASSY BS6	TATA spare parts
886360000611	SIDE DOOR ASSY RH BS6	TATA spare parts
886360000612	DOOR ASSY LH BS6	TATA spare parts
886360000613	TV DOOR ASSY BS6	TATA spare parts
886360000614	RH DOOR OUTER LOCK BS6	TATA spare parts
886360000615	LH DOOR LOCK BS6	TATA spare parts
886360000616	FRONT WALL SERVICE CUT OUT COVER BS6	TATA spare parts
886360000617	SPAREWHEEL CUT OUT COVER BS6	TATA spare parts
886360000618	UREA CUT OUT COVER BS6	TATA spare parts
886360000619	AIR FILTER CUT OUT COVER BS6	TATA spare parts
886360000620	STAY ROD FOR TV ROD BS6	TATA spare parts
886360000621	STAY ROD FOR RH DOOR BS6	TATA spare parts
886360000622	U HOOK BS6	TATA spare parts
886360000623	MOBILE SHOWROOM VAN BS6	TATA spare parts
886360000624	ANCHOR ASSLY COVER BS6	TATA spare parts
886360000625	FLAP BRKT ANCHOR ASSLY BS6	TATA spare parts
886360000626	Z-BRKT ANCHOR ASSLY BS6	TATA spare parts
886360000627	GUIDE PLATE RR LOCK BS6	TATA spare parts
886360000628	PULL HANDLE BS6	TATA spare parts
886360000629	FRONT LOCK UC BS6	TATA spare parts
886360000630	UC REAR LOCK BS6	TATA spare parts
886360000631	SQUAD BENCH BS6	TATA spare parts
886360000632	SQUAD BENCH CUSHION BS6	TATA spare parts
886360000633	A/C COVER BS6	TATA spare parts
886360000634	GRAB HANDLE BS6	TATA spare parts
886360000635	DUSTBIN BS6	TATA spare parts
886360000636	PORTABLE OXYGEN CYLINDER (4.5 LTR) BS6	TATA spare parts

886360000637	AED BS6	TATA spare parts
886360000638	O2 MASK BS6	TATA spare parts
886360000639	PULSEOXIMETER BS6	TATA spare parts
886360000640	SUCTION PUMP BS6	TATA spare parts
886360000641	FIRST AID KIT BS6	TATA spare parts
886360000642	HEAD IMMOBILIZER BS6	TATA spare parts
886360000643	AED (ZOLL - CARDIAC SCIENCE) BS6	TATA spare parts
886360000644	TRAUMA KIT BS6	TATA spare parts
886360000653	COMPLETE CONTAINER BS6	TATA spare parts
886360000654	CORRUGATED PANELS FRONT & SIDE BS6	TATA spare parts
886360000655	WIRING HARNESS BS6	TATA spare parts
886360000656	TAIL DOOR BS6	TATA spare parts
886360000657	U BOLTS BS6	TATA spare parts
886360000658	WIND DEFLECTOR BS6	TATA spare parts
886360000659	EMBOSSSED PANELS ROOF BS6	TATA spare parts
886360000660	FRONT GREEL BS6	TATA spare parts
886360000661	LH SIDE DOOR GLASS BS6	TATA spare parts
886360000662	LH SIDE RC LOCK (DRIVER DOOR ASSY LOCK)	TATA spare parts
886360000663	CO DRIVER SEAT BS6	TATA spare parts
886360000664	CABINE REAR GLASS BS6	TATA spare parts
886360000665	LH SIDE PILLAR TRIM BS6	TATA spare parts
886360000666	RH SIDE PILLAR TRIM BS6	TATA spare parts
886360000667	RH SIDE LOCK COVER INNER SIDE BS6	TATA spare parts
886360000668	ATTENDANT SEAT FRP ASSEMBLY 4 PERSON BS6	TATA spare parts
886360000669	WHEEL BRACKET REAR BS6	TATA spare parts
886360000670	WHEEL BRACKET FRONT BS6	TATA spare parts
886360000671	SIDE GUARD BS6	TATA spare parts
886360000672	WINGER AIR VENT BS6	TATA spare parts
886360000673	OXYGEN CYLNDER BKT. BS6	TATA spare parts
886360000674	ATTANDANCE 4 SEATERSEAT BS6	TATA spare parts
886360000675	MEDICAL CABINATE BS6	TATA spare parts
886360000676	SPEAR WHEEL BOX BS6	TATA spare parts
886360000677	SPEAR WHITE COVER BS6	TATA spare parts
886360000678	PARTATION WINDOW BS6	TATA spare parts
886360000679	2KG FIRE EXTINGUISHER BS6	TATA spare parts
886360000680	2 KG.FIRE EXTINGUISHER BRACKET BS6	TATA spare parts
886360000681	PVC FLOORING BEIGERESPOSIVE BS6	TATA spare parts
886360000682	4 PLYWOOD 8 X 4 BS6	TATA spare parts
886360000683	PASSENGER DOOR(MCV) BS6	TATA spare parts
886360000684	FIRE EXTINGUSHER(6KG) BS6	TATA spare parts
886360000685	FIRE EXTINGUISHER ABC TYPE BS6	TATA spare parts
886360000686	SEAT BELT-ARAI APPROVE BS6	TATA spare parts
886360000687	IV HOOKS BS6	TATA spare parts
886360000688	BIN LOCK BS6	TATA spare parts
886360000689	PARTITION WINDOW GLASS FRAME ASSY BS6	TATA spare parts
886360000690	PATIENT CABIN VINYL ASSEMBLY BS6	TATA spare parts
886360000691	PATIENT CABIN AC SUCTION GRILL BS6	TATA spare parts

886360000692	ATTENDANT SEAT ASSEMBLY BS6	TATA spare parts
886360000693	AUTOLOADING STRECHER SATPUDA BS6	TATA spare parts
886360000694	STICKER SET(PATIENT TRANSPORT ) BS6	TATA spare parts
886360000695	OXYGEN CYLINDER BRACKET (10L) BS6	TATA spare parts
886360000696	SPARE WHEEL COVER BS6	TATA spare parts
886360000697	AC COVER WITH GRILL BS6	TATA spare parts
886360000698	HEATER COVER BS6	TATA spare parts
886360000699	MEDICINE BOX BS6	TATA spare parts
886360000700	HEATER UNIT NM627001 BS6	TATA spare parts
886360000701	COOLANT PUMP RU464001 BS6	TATA spare parts
886360000702	HOSE PUMP INLET BS6	TATA spare parts
886360000703	HOSE PUMP OUTLET BS6	TATA spare parts
886360000704	HEATER HOSE 5/8 450 MM BS6	TATA spare parts
886360000705	HEATER HOSE 5/8 1150 MM BS6	TATA spare parts
886360000706	HEATER HOSE 5/8 2750 MM BS6	TATA spare parts
886360000707	JUBILEE CLIPS BS6	TATA spare parts
886360000708	HEATER INLET BS6	TATA spare parts
886360000709	HEATER OUTLET BS6	TATA spare parts
886360000710	UNION 5/8 BS6	TATA spare parts
886360000711	RELAY 4 PT BS6	TATA spare parts
886360000712	O-RINGS 5/8 BS6	TATA spare parts
886360000713	O-RINGS 1/2 BS6	TATA spare parts
886360000714	WHOLE VEHICLE DECAL TYPE C BS6	TATA spare parts
886360000715	WHOLE VEHICLE DECAL TYPE D BS6	TATA spare parts
886360000716	DOCTOR SEAT BS6	TATA spare parts
886360000717	WASHBASIN BS6	TATA spare parts
886360000718	FOOT SWITCH BS6	TATA spare parts
886360000719	WINDOW BS6	TATA spare parts
886360000720	AC CONDENSER UNIT BS6	TATA spare parts
886360000721	GUSSETS BS6	TATA spare parts
886360000722	CLITS BS6	TATA spare parts
886360000723	6½ SIZE ALLEY½S (4 OVER 3) BS6	TATA spare parts
886360000724	ELECTRONIC WEIGHING MACHINE BS6	TATA spare parts
886360000725	ARTERY FORCEPS 6½ SS CURVED BS6	TATA spare parts
886360000726	ARTERY FORCEPS 6½ SS STRAIGHT BS6	TATA spare parts
886360000727	ARTERY FORCEPS 8½ SS CURVED BS6	TATA spare parts
886360000728	ARTERY FORCEPS 8½ SS STRAIGHT BS6	TATA spare parts
886360000729	ARTIFICIAL INSEMINATION GUN BS6	TATA spare parts
886360000730	B.P. HANDLE NO. 3 SS BS6	TATA spare parts
886360000731	B.P. HANDLE NO. 4 SS BS6	TATA spare parts
886360000732	BUCKETS - SS WITHOUT LID BS6	TATA spare parts
886360000733	CASTING ROPE 25 FT BS6	TATA spare parts
886360000734	CASTRATOR - IMPORTED (BOVINE) BS6	TATA spare parts
886360000735	CASTRATOR - IMPORTED (OVINE) BS6	TATA spare parts
886360000736	CLINICAL THERMOMETER WITH LCD DISPLAY BS	TATA spare parts
886360000737	DRESSING FORCEPS 8½ PLAIN SS BS6	TATA spare parts
886360000738	FORCEPS THUMB 6½ SS RAT TOOTHED BS6	TATA spare parts

886360000739	FORCEPS THUMB 8½ SS RAT TOOTHED BS6	TATA spare parts
886360000740	FORCEPS TISSUE - ALLEY½S 10½ SIZE BS6	TATA spare parts
886360000741	FORCEPS TISSUE - ALLEY½S 8½ SIZE BS6	TATA spare parts
886360000742	GUM BOOTS FULL SIZE (PAIRS) BS6	TATA spare parts
886360000743	GYNAECOLOGY KIT BS6	TATA spare parts
886360000744	HAND SPRAYER - PLASTIC 1 LTR. CAPACITY B	TATA spare parts
886360000745	IRRIGATION CAN (DOUCH CAN) SS BS6	TATA spare parts
886360000746	IRRIGATOR CAN TUBES BS6	TATA spare parts
886360000747	KIDNEY TRAY S.S. BS6	TATA spare parts
886360000748	MAGNIFYING LENS - HAND HELD BS6	TATA spare parts
886360000749	MOUTH GAG SS FOR CATTLE BS6	TATA spare parts
886360000750	NEEDLE DESTROYER BS6	TATA spare parts
886360000751	NEEDLE HOLDING FORCEPS 6½ SS BS6	TATA spare parts
886360000752	NEEDLE HOLDING FORCEPS 8½ SS BS6	TATA spare parts
886360000753	PROBANG (STOMAVCH TUBE FOR CATTLE) BS6	TATA spare parts
886360000754	SCISSORS CURVED 8½ SS BS6	TATA spare parts
886360000755	SCISSORS FOR HAIR CLIPPING 8½ STRAIGHT	TATA spare parts
886360000756	SCISSORS STRAIGHT 6½ SS BS6	TATA spare parts
886360000757	SCISSORS STRAIGHT 8½ SS BS6	TATA spare parts
886360000758	SCISSORS STRAIGHT 8½ SS BLUNT/SINGLE BS	TATA spare parts
886360000759	SCISSOTS CURVED 6½ SS SHARP/BLUNT BS6	TATA spare parts
886360000760	SCOOP SMALL 6½ SIZE SS BS6	TATA spare parts
886360000761	STETHOSCOPE BS6	TATA spare parts
886360000762	SUTURE REMOVAL SCISSORS SS 6½ BS6	TATA spare parts
886360000763	TEAT INSTRUMENT KIT- BS6	TATA spare parts
886360000764	TROCAR AND CANULA FOR LARGE ANIMALS BS6	TATA spare parts
886360000765	TROCAR AND CANULA FOR SMALL ANIMALS BS6	TATA spare parts
886360000766	DR DOOR EXTERNAL HANDLE STEEL BS6	TATA spare parts
886360000767	DR DOOR INTERNAL HANDLE BS6	TATA spare parts
886360000768	FRONT WINDSHIELD GLASS BS6	TATA spare parts
886360000769	QUARTER GLASS LH / RH SIDE BS6	TATA spare parts
886360000770	DOOR STAY BELT BS6	TATA spare parts
886360000771	DOOR SEALING BS6	TATA spare parts
886360000772	RH SIDE DOOR SEALING BS6	TATA spare parts
886360000773	AUTOLOADING STRECHER(FLOOR MOUNTED) BS6	TATA spare parts
886360000774	DOCTOR SEAT BS6	TATA spare parts
886360000775	EXAMINATION TABLE BS6	TATA spare parts
886360000776	LH FIXED WINDOW BIG BS6	TATA spare parts
886360000777	LH FIXED WINDOW SMALL BS6	TATA spare parts
886360000778	WASH BASIN BS6	TATA spare parts
886360000779	HOT AND COLD WATER TAP BS6	TATA spare parts
886360000780	DISPLAY UNIT BS6	TATA spare parts
886360000781	LOAD CELL BS6	TATA spare parts
886360000782	PRESSURE PUMP 1.3 BAR BS6	TATA spare parts
886360000783	WASTE WATER TANK BS6	TATA spare parts
886360000784	EXHAUST FAN BS6	TATA spare parts
886360000785	WORK LAMP BS6	TATA spare parts

886360000786	8-MODEL SWITCH BOARD BS6	TATA spare parts
886360000787	DC SOCKET BS6	TATA spare parts
886360000788	OT LIGHT BS6	TATA spare parts
886360000789	EXTENSION WIRE 10MTR BS6	TATA spare parts
886360000790	FAN BS6	TATA spare parts
886360000791	SIREN BS6	TATA spare parts
886360000792	GYZER BS6	TATA spare parts
886360000793	SQUAD BENCH LOWER COVER 3 SEATER BS6	TATA spare parts
886360000794	WATER TANK 250LTR BS6	TATA spare parts
886360000795	HEATER COVER WITH FRAME BS6	TATA spare parts
886360000796	ATTENDANCE 4 SEATER SEAT BS6	TATA spare parts
886360000797	SQUAD BENCH LAP BELT BS6	TATA spare parts
886360000798	HEATER SWITCH ON DASH BOARD BS6	TATA spare parts
886360000799	12 PLYWOOD 8 X 4 BS6	TATA spare parts
886360000800	SUCTION HOSE BS6	TATA spare parts
886360000801	DELIVERY HOSE BS6	TATA spare parts
886360000802	FILLING HOSE BS6	TATA spare parts
886360000803	METAL STRAINER BS6	TATA spare parts
886360000804	SUCTION WRENCH BS6	TATA spare parts
886360000805	100 X 63 ADOPTER BS6	TATA spare parts
886360000806	BASKET STRAINER BS6	TATA spare parts
886360000807	LIGHT BAR BS6	TATA spare parts
886360000808	AMPLIFIER BS6	TATA spare parts
886360000809	FOG LIGHT BS6	TATA spare parts
886360000810	LOCKER CABIN LIGHT BS6	TATA spare parts
886360000811	PNEUMATIC ACTUATOR BS6	TATA spare parts
886360000812	PNEUMATIC VALVES BS6	TATA spare parts
886360000813	PRESSURE GAUGE BS6	TATA spare parts
886360000814	COMPOUND GAUGE BS6	TATA spare parts
886360000815	GAUGE CONNECTION BS6	TATA spare parts
886360000816	DOOR LOCKS BS6	TATA spare parts
886360000817	BALL VALVE BS6	TATA spare parts
886360000818	MUDGUARD RUBBER BS6	TATA spare parts
886360000819	COMPLETE HORIZONTAL HYDRAULIC KIT BS6	TATA spare parts
886360000820	COMPLETE VERTICAL HYDRAULIC KIT BS6	TATA spare parts
886360000821	DUST BIN BS6	TATA spare parts
886360000822	SIDE DOOR ASSY BS6	TATA spare parts
886360000823	YELLOW REFLECTIVE TAPE SIDE BS6	TATA spare parts
886360000824	RED REFLECTIVE TAPE REAR BS6	TATA spare parts
886360000825	REAR DOOR LH & RH BS6	TATA spare parts
886360000826	REAR LOCKING ASSY BS6	TATA spare parts
886360000827	U BOLT ASSY BS6	TATA spare parts
886360000828	COAT HOOKS BS6	TATA spare parts
886360000829	TRACTOR HOOKS BS6	TATA spare parts
886360000830	1/2 INCH BALL VALVE BS6	TATA spare parts
886360000831	1 INCH PVC BUTTERFLY VALVE BS6	TATA spare parts
886360000832	2 INCH PVC END CAP BS6	TATA spare parts

88636000833	SS TAP BS6	TATA spare parts
88636000834	WINDOW BS6	TATA spare parts
88636000835	GUSSETS BS6	TATA spare parts
88636000836	PARTITION DOOR BS6	TATA spare parts
88636000837	FRESH WATER TANK 20L BS6	TATA spare parts
88636000838	DRAIN WATER TANK 20L BS6	TATA spare parts
88636000839	FLEXIBLE PVC PIPE 8MM DIA IN 5 MTR BS6	TATA spare parts
88636000840	SMALL REFRIGERATOR (INSTALLED IN MAVC) B	TATA spare parts
88636000841	R PASS BRACKET ASSEMBLY BS6	TATA spare parts
88636000842	DOCTORS APRON FULL HANDS BS6	TATA spare parts
88636000843	DRESSING DRUM S.S. SEAMLESS BS6	TATA spare parts
88636000844	GYNAECOLOGY APRON BS6	TATA spare parts
88636000845	HANDLE SAFE AMPOULE CUTTER BS6	TATA spare parts
88636000846	INSTRUMENTS STERILISER (PORTABLE) BS6	TATA spare parts
88636000847	PROJECTOR SCREEN BS6	TATA spare parts
88636000848	CORNER CAP PLATIC BS6	TATA spare parts
88636000849	WIND FRP DEFELECTOR BS6	TATA spare parts
88636000850	SLIDING DOOR HANDLE BS6	TATA spare parts
88636000851	HYDRAULIC PLATFORM BS6	TATA spare parts
88636000852	GENERATOR 3KVA ROPE START BS6	TATA spare parts
88636000853	OXYGEN CYLINDER BRACKET BS6	TATA spare parts
88636000854	AUTOCLAVE S.S. STERLIZER PORTABLE BS6	TATA spare parts
88636000855	BLUE COLOUR APRON (PARA VETS) BS6	TATA spare parts
88636000856	COMPOUND MICROSCOPE BS6	TATA spare parts
88636000857	INSTRUMENT TRAY WITH LID S.S. BS6	TATA spare parts
88636000858	SLIDABLE DOOR BS6	TATA spare parts
88636000859	SS CORNER PLATE BS6	TATA spare parts
88636000860	SIDE FOOT STEP ASSY BS6	TATA spare parts
88636000861	REAR FOOT STEP ASSY BS6	TATA spare parts
88636000862	LH SIDE DOOR LOCK BS6	TATA spare parts
88636000863	FDAS & FIRE ALARM SWITCH BS6	TATA spare parts
88636000864	DASHBOARD CLUSTER METER COVER BS6	TATA spare parts
88636000865	DASHBOARD METER SWITCH BS6	TATA spare parts
88636000866	WINDOW ASSY GLASS RHS BS6	TATA spare parts
88636000867	FIRE EXTINGUISHER 4 KG BS6	TATA spare parts
88636000868	FIRE EXTINGUISHER 6KG BS6	TATA spare parts
88636000869	SEAT BELT-ARAI APPROVE- 2 POINT BS6	TATA spare parts
88636000870	DUSTBIN BS6	TATA spare parts
88636000871	IV HOOKS BS6	TATA spare parts
88636000872	CABINET HANDLE BS6	TATA spare parts
88636000873	VINYL ASSEMBLY BS6	TATA spare parts
88636000874	CABINET CHANNEL SOFT CLOSE BS6	TATA spare parts
88636000875	FRONT WINSHIELD BS6	TATA spare parts
88636000876	FRONT GLASS RUBBER BIDING BS6	TATA spare parts
88636000877	HEIGHT MARKER BS6	TATA spare parts
88636000878	REAR VIEW MIRROR BS6	TATA spare parts
88636000879	REAR VIEW MIRROR BKT BS6	TATA spare parts



886360000880	DASH BOARD ASSEMBLY WITH BONNET BS6	TATA spare parts
886360000881	CO- DRIVER SEAT BS6	TATA spare parts
886360000882	FIRST AID BOX BS6	TATA spare parts
886360000883	MSL LOCK ASSEMBLY BS6	TATA spare parts
886360000884	SIDE MARKER BS6	TATA spare parts
886360000885	BUDGET LOCK BS6	TATA spare parts
886360000886	BUDGET LOCK COVER BS6	TATA spare parts
886360000887	NUMBER PLATE LIGHT BS6	TATA spare parts
886360000888	DRIVER CO- DRIVER DOOR HINGE BS6	TATA spare parts
886360000889	REAR WINDSHIELD BS6	TATA spare parts
886360000890	CANOPY 10 BS6	TATA spare parts
886360000891	LIQUID SOAP STAND BS6	TATA spare parts
886360000892	FOOT OPERATED SWITCH BS6	TATA spare parts
886360000893	BELOW FACING MIRROR BS6	TATA spare parts
886360000894	D- HANDLE BS6	TATA spare parts
886360000895	GAS SPRING 24INCH BS6	TATA spare parts
886360000896	STICKER SET BS6	TATA spare parts
886360000897	GODREJ COFFEE VENDING MACHINE BS6	TATA spare parts
886360000898	MOVABLE TROLLY BS6	TATA spare parts
886360000899	DATA LOGGER BS6	TATA spare parts
886360000900	ICE BOX 25 LTR. BS6	TATA spare parts
886360000901	TUBE SEALER BS6	TATA spare parts
886360000902	OXYGEN CYLINDER 1.7 BS6	TATA spare parts
886360000903	FIX GLASS SET BS6	TATA spare parts
886360000904	WINDOW FRAME SET BS6	TATA spare parts
886360000905	FIX GLASS (SIZE-780X1090MM) LHS BS6	TATA spare parts
886360000906	FIX GLASS (SIZE-780X1090MM) RHS BS6	TATA spare parts
886360000907	FIX GLASS (SIZE-400X1090MM) LHS BS6	TATA spare parts
886360000908	FIX GLASS (SIZE-400X1090MM) RHS BS6	TATA spare parts
886360000909	FIX GLASS (SIZE-1190X1090MM) LHS BS6	TATA spare parts
886360000910	FIX GLASS (SIZE-1190X1090MM) RHS BS6	TATA spare parts
886360000911	FIX GLASS (SIZE-800X1090MM) RHS BS6	TATA spare parts
886360000912	FIX GLASS (SIZE-470X1090MM) LHS BS6	TATA spare parts
886360000913	FIX GLASS (SIZE-470X1090MM) RHS BS6	TATA spare parts
886360000914	FIX QUARTER GLASS LHS BS6	TATA spare parts
886360000915	FIX QUARTER GLASS RHS BS6	TATA spare parts
886360000916	FIX GLASS (SIZE-1190X270MM) LHS BS6	TATA spare parts
886360000917	FIX GLASS (SIZE-1190X270MM) RHS BS6	TATA spare parts
886360000918	JK DOOR GLASS (SIZE-240X1185MM) BS6	TATA spare parts
886360000919	PARTITION DOOR GLASS (SIZE-505X600MM) BS	TATA spare parts
886360000920	TV FIX GLASS (SIZE-485X785MM) BS6	TATA spare parts
886360000921	SLIDING WINDOW (SIZE-1140X779MM) LHS BS6	TATA spare parts
886360000922	SLIDING WINDOW (SIZE-1140X779MM) RHS BS6	TATA spare parts
886360000923	SLIDING WINDOW DRIVER DOOR BS6	TATA spare parts
886360000924	SLIDING WINDOW CO-DRIVER DOOR BS6	TATA spare parts
886360000925	SLIDING WINDOW EMERGENCY DOOR BS6	TATA spare parts
886360000926	SUN VISOR BS6	TATA spare parts

88636000927	ATTENDENT SEAT BS6	TATA spare parts
88636000928	STOOL BS6	TATA spare parts
88636000929	FOOT OPERATED PUMP BS6	TATA spare parts
88636000930	DONAR COUCH BS6	TATA spare parts
88636000931	FOLDABLE CHAIRS BS6	TATA spare parts
88636000932	EMERGENCY DOOR LOCK GLASS BS6	TATA spare parts
88636000933	COMMUNICATION WINDOW (SIZE-650X300MM)	TATA spare parts
88636000934	RED REFLECTOR RETRO BS6	TATA spare parts
88636000935	BLOOD STORAGE REFRIGERATOR BS6	TATA spare parts
88636000936	BUS BODY COMPLETE BS6	TATA spare parts
88636000937	TOWEL RING BS6	TATA spare parts
88636000938	FIRE EXTINGUISHER 4 KG BS6	TATA spare parts
88636000939	FIRE EXTINGUISHER 6KG BS6	TATA spare parts
88636000940	SEAT BELT-ARAI APPROVE- 2 POINT BS6	TATA spare parts
88636000941	DUSTBIN BS6	TATA spare parts
88636000942	IV HOOKS BS6	TATA spare parts
88636000943	CABINET HANDLE BS6	TATA spare parts
88636000944	VINYL ASSEMBLY BS6	TATA spare parts
88636000945	CABINET CHANNEL SOFT CLOSE BS6	TATA spare parts
88636000946	FRONT WINDSHIELD BS6	TATA spare parts
88636000947	FRONT GLASS RUBBER BIDDING BS6	TATA spare parts
88636000948	HEIGHT MARKER BS6	TATA spare parts
88636000949	REAR VIEW MIRROR BS6	TATA spare parts
88636000950	REAR VIEW MIRROR BKT BS6	TATA spare parts
88636000951	DASH BOARD ASSEMBLY BS6	TATA spare parts
88636000952	CO- DRIVER SEAT FOLDABLE BS6	TATA spare parts
88636000953	FIRST AID BOX BS6	TATA spare parts
88636000954	SUN VISOR BS6	TATA spare parts
88636000955	MSL LOCK ASSEMBLY BS6	TATA spare parts
88636000956	BUDGET LOCK BS6	TATA spare parts
88636000957	BUDGET LOCK COVER BS6	TATA spare parts
88636000958	NUMBER PLATE LIGHT BS6	TATA spare parts
88636000959	DRIVER CO- DRIVER DOOR HINGE BS6	TATA spare parts
88636000960	REAR WINDSHIELD BS6	TATA spare parts
88636000961	ATTENDENT SEAT BS6	TATA spare parts
88636000962	CANOPY 10 BS6	TATA spare parts
88636000963	TOWEL RING BS6	TATA spare parts
88636000964	LIQUID SOAP STAND BS6	TATA spare parts
88636000965	FOOT OPERATED PUMP BS6	TATA spare parts
88636000966	FOOT OPERATED SWITCH BS6	TATA spare parts
88636000967	BELOW FACING MIRROR BS6	TATA spare parts
88636000968	D- HANDLE BS6	TATA spare parts
88636000969	GAS SPRING 24INCH BS6	TATA spare parts
88636000970	3 PIN TOP BS6	TATA spare parts
88636000971	STICKER SET BS6	TATA spare parts
88636000972	MOVABLE TROLLY BS6	TATA spare parts
88636000973	DATA LOGGER BS6	TATA spare parts

88636000974	ICE BOX 25 LTR. BS6	TATA spare parts
88636000975	TUBE SEALER BS6	TATA spare parts
88636000976	OXYGEN CYLINDER 1.7 BS6	TATA spare parts
88636000977	FOLDABLE CHAIRS BS6	TATA spare parts
88636000978	FIX GLASS SET BS6	TATA spare parts
88636000979	WINDOW FRAME SET BS6	TATA spare parts
88636000980	CHANGE OVER 63 BS6	TATA spare parts
88636000981	FULL BODY FABRICATION BS6	TATA spare parts
88636000982	FIX GLASS (1190X1090MM) LHS BS6	TATA spare parts
88636000983	FIX GLASS (1190X1090MM) RHS BS6	TATA spare parts
88636000984	FIX GLASS (950X1090MM) LHS BS6	TATA spare parts
88636000985	FIX GLASS (950X1090MM) RHS BS6	TATA spare parts
88636000986	FIX QUARTER GLASS (200X360X765) LHS BS6	TATA spare parts
88636000987	FIX QUARTER GLASS (200X360X765) RHS BS6	TATA spare parts
88636000988	FIX GLASS (1190X260MM) LHS BS6	TATA spare parts
88636000989	FIX GLASS (1190X260MM) RHS BS6	TATA spare parts
88636000990	PARTITION DOOR GLASS (505X600MM) BS6	TATA spare parts
88636000991	TV FIX GLASS (485X785MM) BS6	TATA spare parts
88636000992	EMERGENCY DOOR LOCK GLASS (170X135) BS6	TATA spare parts
88636000993	SLIDING WINDOW (1140X790MM) LHS BS6	TATA spare parts
88636000994	SLIDING WINDOW (1140X790MM) RHS BS6	TATA spare parts
88636000995	DRIVER DOOR SLIDING WINDOW (745X705) BS6	TATA spare parts
88636000996	EMERGENCY DOOR SLIDING WINDOW(710X650)	TATA spare parts
88636000997	COMMUNICATION WINDOW (640X300MM) BS6	TATA spare parts
88636000998	STOOL BS6	TATA spare parts
88636000999	DONAR COUCH BS6	TATA spare parts
886360001000	FRONT WINDSHIELD ND5 TATA-LHD	TATA spare parts
886360001001	ATTENDANT SEAT FRP ASSEMBLY BS6	TATA spare parts
886360001002	CABINET WITH DRAWERS BS6	TATA spare parts
886360001003	QUARTER PEEP GLASS BS6	TATA spare parts
886360001004	FLAT REAR WINDSHIELD GLASS	TATA spare parts
886360001005	TOOL BOX	TATA spare parts
886360001006	DOOR LOCK	TATA spare parts
886360001007	CAM LOCK	TATA spare parts
886360001008	BODY	TATA spare parts
886360001009	LOAD BODY	TATA spare parts
886360001010	SUB FRAME	TATA spare parts
886360001011	MUDGUARD	TATA spare parts
886360001012	18 KL SHELL ASSY	TATA spare parts
886360001013	8 KL SHELL ASSY	TATA spare parts
886360001014	U BOLT (SET) 485 MM	TATA spare parts
886360001015	WINDOW	TATA spare parts
886360001016	TOWER BOLT 4	TATA spare parts
886360001017	HINGES3	TATA spare parts
886360001018	HINGES4	TATA spare parts
886360001019	HEAVY DUTY LOCK	TATA spare parts
886360001020	REAR WINDSHIELD GLASS BS6	TATA spare parts

886360001021	REAR WINDSHIELD MOULD RUBBER BS6	TATA spare parts
886360001022	MUDGUARD ASSEMBLY WITH RAIN FLAP BS6	TATA spare parts
886360001023	MUDGUARD RAIN FLAP BS6	TATA spare parts
886360001024	FULLY BUILT VEHICLE (CONTAINER) BS6	TATA spare parts
886360001025	FOLDABLE SEAT BS6	TATA spare parts
886360001026	FIRE EXTINGUISHER 2 KG BS6	TATA spare parts
886360001027	DR. WORK TABLE BS6	TATA spare parts
886360001028	WINDOW-500 X 550 BS6	TATA spare parts
886360001029	WINDOW-400 X 595 BS6	TATA spare parts
886360001030	HYDRAULIC PLATFORM BS6	TATA spare parts
886360001031	SQUAD BENCH BS6	TATA spare parts
886360001032	NITROGEN CYLINDER BRACKET BS6	TATA spare parts
886360001033	OXYGEN TROLLEY BRACKET BS6	TATA spare parts
886360001034	DUST BIN BS6	TATA spare parts
886360001035	SIDE FOOT STEP ASSY BS6	TATA spare parts
886360001036	REAR FOOT STEP ASSY BS6	TATA spare parts
886360001038	U BOLT ASSY BS6	TATA spare parts
886360001039	ALUMINIUM SPACER BS6	TATA spare parts
886360001040	FLAT FOR U-BOLT BS6	TATA spare parts
886360001042	CLOTH HOOK BS6	TATA spare parts
886360001043	RUBBER STOPPER BS6	TATA spare parts
886360001044	DOOR HANDLE SS INSIDE BS6	TATA spare parts
886360001045	TOWER BOLTS BS6	TATA spare parts
886360001046	SEAT BELTS FOR FOLDABLE SEAT BS6	TATA spare parts
886360001047	CORNER GUARDS BS6	TATA spare parts
886360001048	REMOTE RING BS6	TATA spare parts
886360001049	GREASE NIPPLE BS6	TATA spare parts
886360001050	RUBBER GROMMETS BS6	TATA spare parts
886360001055	MUD GUARD LH BS6	TATA spare parts
886360001056	MUD GUARD RH BS6	TATA spare parts
886360001057	MUD GUARD STAY ROD BS6	TATA spare parts
886360001058	SCOOTER HOOK BS6	TATA spare parts
886360001059	SIDE DOOR ASSY BS6	TATA spare parts
886360001060	DR DOOR EXTERNAL HANDLE STEEL BS6	TATA spare parts
886360001061	DR DOOR INTERNAL SS HANDLE BS6	TATA spare parts
886360001062	DR DOOR INTERNAL HANDLE BS6	TATA spare parts
886360001063	PARTITION DOOR SAFETY LOCK BS6	TATA spare parts
886360001064	INSIDE PARTITION DOOR BS6	TATA spare parts
886360001065	DOOR LOCK BS6	TATA spare parts
886360001068	ARTERY FORCEPS 6INCH SS CURVED BS6	TATA spare parts
886360001069	ARTERY FORCEPS 6INCH SS STRAIGHT BS6	TATA spare parts
886360001070	ARTERY FORCEPS 8INCH SS CURVED BS6	TATA spare parts
886360001071	ARTERY FORCEPS 8INCH SS STRAIGHT BS6	TATA spare parts
886360001072	AUTOCLAVE S.S. STERILIZER PORTABLE BS6	TATA spare parts
886360001073	B.P. HANDLE NO. 3 SS BS6	TATA spare parts
886360001074	B.P. HANDLE NO. 4 SS BS6	TATA spare parts
886360001075	BUCKETS - SS WITHOUT LID BS6	TATA spare parts

886360001076	CASTRATOR - IMPORTED (BOVINE) BS6	TATA spare parts
886360001077	CASTRATOR - IMPORTED (OVINE) BS6	TATA spare parts
886360001078	INFRARED THERMOMETER WITHOUT CELL BS6	TATA spare parts
886360001080	DRESSING DRUM S.S. SEAMLESS BS6	TATA spare parts
886360001081	GYNAECOLOGY KIT BS6	TATA spare parts
886360001082	HAND SPRAYER - PLASTIC 1 LTR. CAPACITY B	TATA spare parts
886360001083	HANDLE SAFE AMPOULE CUTTER BS6	TATA spare parts
886360001084	INSTRUMENT TRAY WITH LID S.S. BS6	TATA spare parts
886360001085	INSTRUMENTS STERILISER (PORTABLE) BS6	TATA spare parts
886360001086	MAGNIFYING LENS - HAND HELD BS6	TATA spare parts
886360001087	MOUTH GAG SS FOR CATTLE BS6	TATA spare parts
886360001088	NEEDLE DESTROYER BS6	TATA spare parts
886360001089	NEEDLE HOLDING FORCEPS 6INCH SS STRAIG	TATA spare parts
886360001090	NEEDLE HOLDING FORCEPS 8INCH SS STRAIG	TATA spare parts
886360001091	PROBANG (STOMACH TUBE FOR CATTLE) BS6	TATA spare parts
886360001092	SCISSORS FOR HAIR CLIPPING 8INCH STRAIGH	TATA spare parts
886360001093	SCOOP SMALL 6INCH SIZE SS BS6	TATA spare parts
886360001094	STITCH REMOVAL SCISSORS SS 6INCH BS6	TATA spare parts
886360001095	TEAT INSTRUMENT KIT- BS6	TATA spare parts
886360001096	TROCAR AND CANULA FOR LARGE ANIMALS BS6	TATA spare parts
886360001097	TROCAR AND CANULA FOR SMALL ANIMALS BS6	TATA spare parts
886360001098	FRONT FACE -MTS BS6	TATA spare parts
886360001099	FRONT FLAP - MTS BS6	TATA spare parts
886360001100	REAR FACE - MTS BS6	TATA spare parts
886360001101	REAR GLASS CLEAR FLAT CP 895X1840 - MTS	TATA spare parts
886360001102	D-HANDLE BS6	TATA spare parts
886360001103	HAND SANITIZER STAND BS6	TATA spare parts
886360001104	PARTITION WINDOW GLASS FRAME ASSEMBLY BS6	TATA spare parts
886360001105	PATIENT CABIN LH PANNEL BS6	TATA spare parts
886360001106	PATIENT CABIN RH PANNEL BS6	TATA spare parts
886360001107	PATEINT CABIN ROOF PANNEL BS6	TATA spare parts
886360001108	PATIENT CABIN PARTION WALL PANNEL BS6	TATA spare parts
886360001109	PARTION WINDOW FRP RING BS6	TATA spare parts
886360001110	PATIENT CABIN VINYL ASSEMBLY BS6	TATA spare parts
886360001111	PATIENT CABIN AC SUCTION GRILL BS6	TATA spare parts
886360001112	WORK LAMP FRP COVER BS6	TATA spare parts
886360001113	EXTERNAL POWER SOCKET FRP COVER BS6	TATA spare parts
886360001114	GENERATOR COMPARTMENT DOOR ASSEMBLY BS6	TATA spare parts
886360001115	GENERATOR DOOR HINGE BS6	TATA spare parts
886360001116	DRIVER CABIN PARTION WALL FRP BS6	TATA spare parts
886360001117	DRIVER CABIN ROOF PANNEL ASSEMBLY BS6	TATA spare parts
886360001118	STICKER SET BS6	TATA spare parts
886360001119	TV BRACKET BS6	TATA spare parts
886360001120	FIRE EXTINGUISHER ABC TYPE BS6	TATA spare parts
886360001121	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts
886360001122	HAND WASH STAND BS6	TATA spare parts
886360001123	SQUAT BENCH 2 SEATER SEAT BS6	TATA spare parts

886360001124	ARM REST BS6	TATA spare parts
886360001125	WATER PUMP BS6	TATA spare parts
886360001126	SS WASTE WATER TANK BS6	TATA spare parts
886360001127	SS FRESH WATER TANK BS6	TATA spare parts
886360001128	SS EXAMINATION TABLE CABINET 2 BS6	TATA spare parts
886360001129	MEDICAL CABINET BS6	TATA spare parts
886360001130	SS HINGES BS6	TATA spare parts
886360001131	DRAIN HOLE LID BS6	TATA spare parts
886360001132	SPARE WHEEL COVER BS6	TATA spare parts
886360001133	SQUAT BENCH LAP BELT SET BS6	TATA spare parts
886360001134	FRP SQUAT BENCH 2 SEATER PANEL BS6	TATA spare parts
886360001135	DRIVER SEAT BOTTOM SIDE COVER BS6	TATA spare parts
886360001136	FRP PA SYSTEM COVER BS6	TATA spare parts
886360001137	PARTITON WINDOW BS6	TATA spare parts
886360001138	FIRE EXTINGUISHER 1 KG BS6	TATA spare parts
886360001139	WATER VALVE BS6	TATA spare parts
886360001140	PVC ALLUMINIUM SHEET BS6	TATA spare parts
886360001141	ALUMINIUM CHEQUER PLATE BS6	TATA spare parts
886360001142	FIRE EXTINGUISHER MTG BKT BS6	TATA spare parts
886360001143	FIRST AID BOX BS6	TATA spare parts
886360001144	LN2 CONTAINER MTG BKT BS6	TATA spare parts
886360001145	ALUMINIUM BEEDING CHANNEL BS6	TATA spare parts
886360001146	SLEEVE BS6	TATA spare parts
886360001147	4 SEATER REAR BS6	TATA spare parts
886360001148	3 SEATER WITH 3 LEG BS6	TATA spare parts
886360001149	WHEEL ARC RH	TATA spare parts
886360001150	ASSY BIG MAIN MIRROR WITH ROUND MOUNTIN	TATA spare parts
886360001151	ASSY WIDE ANGLE MIRROR	TATA spare parts
886360001152	FRAME TUBULAR 22 LH	TATA spare parts
886360001153	FRAME TUBULAR 22 RH	TATA spare parts
886360001154	BOTTOM MOUNTING BRACKET	TATA spare parts
886360001155	BOTTOM MOUNTING COVER	TATA spare parts
886360001156	TOP MOUNTING BRACKET LH	TATA spare parts
886360001157	TOP MOUNTING BRACKET RH	TATA spare parts
886360001158	BOTTOM PIPE HOLDER BRACKET	TATA spare parts
886360001159	BOTTOM MTG. GASKET	TATA spare parts
886360001160	TOP MTG. GASKET	TATA spare parts
886360001161	HEX BOLT M8X80	TATA spare parts
886360001162	PLAIN WASHER M8	TATA spare parts
886360001163	NYLOCK NUT M8	TATA spare parts
886360001164	COIL SPRING	TATA spare parts
886360001165	ALLEN BOLT M8X25	TATA spare parts
886360001166	INSERT NUT M8X14	TATA spare parts
886360001167	SPRING CAP	TATA spare parts
886360001168	FRONT DOOM BS6	TATA spare parts
886360001169	FRONT DOOM LP 712 BS6	TATA spare parts
886360001170	REAR DOOM LP 712 BS6	TATA spare parts

886360001171	FRONT FACE FRP - BS6	TATA spare parts
886360001172	FRONT GRILL FRP - BS6	TATA spare parts
886360001173	FRONT GRILL FIX FRP -BS6	TATA spare parts
886360001174	REAR FACE 1618/53- BS6	TATA spare parts
886360001175	CLOSURE CLAMPING DEVICE BS6	TATA spare parts
886360001176	CYLINDER SCREW M10 X 20 DIN 6912 BS6	TATA spare parts
886360001177	FRONT DOOM BS6	TATA spare parts
886360001178	NEAR TAIL DOOR GRAB HANDLE BS6	TATA spare parts
886360001179	ROOF TOP GRAB HANDLE BS6	TATA spare parts
886360001180	WATER PUMP BS6	TATA spare parts
886360001181	SS EXAMINATION TABLE CABINET 2 BS6	TATA spare parts
886360001182	BELT BS6	TATA spare parts
886360001183	AC AIR IN LOURS BS6	TATA spare parts
886360001184	FRP TOP PANEL BS6	TATA spare parts
886360001185	FRP LH SIDE PANEL BS6	TATA spare parts
886360001186	FRP RH SIDE PANEL BS6	TATA spare parts
886360001187	FRP RH WHEEL ARCH COVER BS6	TATA spare parts
886360001188	FRP PILLAR RH BS6	TATA spare parts
886360001189	FRP PILLAR LH BS6	TATA spare parts
886360001190	FRP DRIVER CABIN AC PANEL BS6	TATA spare parts
886360001191	FRP AC COVER PANEL BS6	TATA spare parts
886360001192	FRP PARTITION PANEL DRIVER SIDE BS6	TATA spare parts
886360001193	FRP PARTITION PANEL PTIENT SIDE BS6	TATA spare parts
886360001194	FRP CUT OUT PANELS BS6	TATA spare parts
886360001195	DRIVER CABIN FRP ROOF PANEL BS6	TATA spare parts
886360001196	FRONT DOOM BS6	TATA spare parts
886360001197	ENGINE HOOD BS6	TATA spare parts
886360001198	REAR DOOM BS6	TATA spare parts
886360001199	REAR FACE BS6	TATA spare parts
886360001200	REAR DOOM BS6	TATA spare parts
886360001201	FRONT DOOM BS6	TATA spare parts
886360001202	REAR DOOM	TATA spare parts
886360001203	FRONT DOOM	TATA spare parts
886360001204	REAR DOOM	TATA spare parts
886360001205	FRONT DOOM	TATA spare parts
886360001206	REAR FACE BS6	TATA spare parts
886360001207	REAR DOOM BS6	TATA spare parts
886360001208	FRONT DOOM BS6	TATA spare parts
886360001209	FRONT FACE -MTS BS6	TATA spare parts
886360001210	FRONT FLAP - MTS BS6	TATA spare parts
886360001211	FRONT DOOM BS6	TATA spare parts
886360001212	MUDGUARD STRAIGHT SUPPORT - RH BS6	TATA spare parts
886360001213	REAR MUDGUARD ASSY (HINGE TYPE) LH BS6	TATA spare parts
886360001214	REAR MUDGUARD ASSY (HINGE TYPE) RH BS6	TATA spare parts
886360001215	PC HANDLE HOLDER DIA 35	TATA spare parts
886360001216	ALLEN BOLT M6X30 TB B	TATA spare parts
886360001217	ALLEN BOLT M6X40 TB B	TATA spare parts

886360001218	HEX LOCK NUT M6 TB	TATA spare parts
886360001219	SUBFRAME ASSY WITH CRADLE LPTK2518	TATA spare parts
886360001220	FRONT GLASS MTS -OLD (1320X2115)	TATA spare parts
886360001221	ASSLY BASKET TATA YODHA XENON HSD L/B 31	TATA spare parts
886360001222	SIDE FIXED GLASS. (1300X1120MM)	TATA spare parts
886360001223	SIDE FIXED GLASS. (1250X1120MM)	TATA spare parts
886360001224	SIDE FIXED GLASS. (1060X1120MM)	TATA spare parts
886360001225	SIDE FIXED GLASS. (420X1120MM)	TATA spare parts
886360001226	EMERGENCY DOOR TOP GLASS. (725X685MM)	TATA spare parts
886360001227	RHS QUARTERLITE CURVED GLASS	TATA spare parts
886360001228	PASSENGER DOOR PEEP GLASS(673*564MM)	TATA spare parts
886360001229	FRP PA SYSTEM COVER BS6-PH2	TATA spare parts
886360001230	ASSY BODY SHELL PAINTED BLUE	TATA spare parts
886360600001	LH REAR MUDGUARD	TATA spare parts
886360600002	RH REAR MUDGUARD	TATA spare parts
886360600003	TOP MARKER LAMP COVER	TATA spare parts
886360960001	SKIRT PANEL COMPL.	TATA spare parts
886360960002	PANEL	TATA spare parts
886360960003	WHEEL SIDE COVER	TATA spare parts
886360960004	SKIRT PANEL COMPL.	TATA spare parts
886360960005	SKIRT PANEL COMPL./FT	TATA spare parts
886360960006	SKIRT PANEL COMPL.	TATA spare parts
886360960007	SKIRT PANEL COMPL.	TATA spare parts
886360960008	WHEEL SIDE COVER/F	TATA spare parts
886360960009	SKIRT PANEL COMPL.	TATA spare parts
886360960010	WHEEL SIDE COVER/R	TATA spare parts
886360960011	DOOR ASSY. / S.T	TATA spare parts
886360960012	SKIRT PANEL COMPL.	TATA spare parts
886360960013	DOOR ASSY. / S.T	TATA spare parts
886360960014	PANEL	TATA spare parts
886360960015	WHEEL SIDE COVER/F LH	TATA spare parts
886360960016	CONNECTING ROD	TATA spare parts
886360960017	CONNECTING ROD	TATA spare parts
886360960018	SKIRT PANEL COMPL	TATA spare parts
886360960019	WHEEL SIDE COVER / F	TATA spare parts
886360960020	WHEEL SIDE COVER / R	TATA spare parts
886360960021	WHEEL SIDE COVER / F	TATA spare parts
886360960022	SKIRT PANEL COMPL.	TATA spare parts
886360960023	SKIRT PANEL COMPL. /FT	TATA spare parts
886360960024	SKIRT PANEL COMPL.	TATA spare parts
886360960025	SKIRT PANEL COMPL.	TATA spare parts
886360960026	SKIRT PANEL COMPL.	TATA spare parts
886360960027	SKIRT PANEL COMPL.	TATA spare parts
886360960028	SKIRT PANEL COMPL.	TATA spare parts
886360960029	SKIRT PANEL COMPL.	TATA spare parts
886360960030	AIR CLEANER PANEL ASSEMBLY	TATA spare parts
886360960031	SKIRT PANEL COMPLETE	TATA spare parts



886360960032	SKIRT PANEL COMPLETE / F.A.	TATA spare parts
886360960033	SKIRT PANEL COMPLETE / F.T.	TATA spare parts
886360960034	SPARE WHEEL PANEL COMPLETE	TATA spare parts
886360960035	SKIRT PANEL COMPLETE	TATA spare parts
886360960036	SKIRT PANEL COMPLETE	TATA spare parts
886360960037	SKIRT PANEL COMPLETE	TATA spare parts
886360960038	FRP FRONT GRILL FOR NIGERIA	TATA spare parts
886360960039	SKIRT PANEL COMPLETE	TATA spare parts
886360960040	SKIRT PANEL COMPLETE	TATA spare parts
886360960041	SKIRT PANEL COMPLETE	TATA spare parts
886360960042	SKIRT PANEL COMPLETE	TATA spare parts
886360960043	SKIRT PANEL COMPLETE	TATA spare parts
886360960044	FRP FRONT PANEL	TATA spare parts
886360960045	REAR FRP ASSEMBLY	TATA spare parts
886360960046	SKIRT PANEL COMPLETE	TATA spare parts
886360960047	SKIRT PANEL COMPLETE	TATA spare parts
886360960048	SKIRT PANEL COMPLETE	TATA spare parts
886360960049	SKIRT PANEL COMPLETE	TATA spare parts
886360960050	SKIRT PANEL COMPLETE	TATA spare parts
886360960051	SKIRT PANEL COMPLETE/F.T	TATA spare parts
886360960052	SKIRT PANEL COMPLETE	TATA spare parts
886360960053	SKIRT PANEL COMPLETE	TATA spare parts
886360960054	TRIAGULAR PANEL	TATA spare parts
886360960055	TRIAGULAR PANEL	TATA spare parts
886360960056	DOOR ASSY. / S.T.	TATA spare parts
886360960057	DOOR ASSY. / B.B.	TATA spare parts
886360960058	SPARES KIT PART FRONT VIEW	TATA spare parts
886360960059	SPARES KIT PART REAR VIEW	TATA spare parts
886360960060	SPARES KIT PART SIDE LH VIEW	TATA spare parts
886360960061	SPARES KIT PART SIDE RH VIEW	TATA spare parts
886360960062	AUX ENGINE FLAP	TATA spare parts
886360960063	VENTILATION PANEL	TATA spare parts
886360960064	REAR FRP ASSEMBLY	TATA spare parts
886360960065	SKIRT PANEL COMPLETE	TATA spare parts
886360960066	SKIRT PANEL COMPLETE	TATA spare parts
886360960067	SKIRT PANEL COMPLETE	TATA spare parts
886360960068	SKIRT PANEL COMPLETE	TATA spare parts
886360960069	SKIRT PANEL COMPLETE/F.T	TATA spare parts
886360960070	DOOR ASSEMBLY/S.T.	TATA spare parts
886360960071	DOOR ASSEMBLY/B.B.	TATA spare parts
886360960072	WHEEL SIDE COVER/F	TATA spare parts
886360960073	WHEEL SIDE COVER/R	TATA spare parts
886360960074	WHEEL SIDE COVER/F	TATA spare parts
886360960075	SKIRT PANEL COMPLETE	TATA spare parts
886360960076	FRP FRONT PANEL	TATA spare parts
886360960077	FRP FRONT GRILL	TATA spare parts
886360960078	FRP REAR PANEL	TATA spare parts

886360960079	SKIRT PANEL COMPL	TATA spare parts
886360960080	SKIRT PANEL COMPL	TATA spare parts
886360960081	SKIRT PANEL COMPL	TATA spare parts
886360960082	SKIRT PANEL COMPL	TATA spare parts
886360960083	DOOR ASSY / BB	TATA spare parts
886360960084	DOOR ASSY / ST	TATA spare parts
886360960085	WHEEL SIDE COVER / R	TATA spare parts
886360960086	WHEEL SIDE COVER / R	TATA spare parts
886360960087	WHEEL SIDE COVER / F	TATA spare parts
886360960088	WHEEL SIDE COVER / F	TATA spare parts
886360960089	SKIRT PANEL COMPL	TATA spare parts
886360960090	SKIRT PANEL COMPL	TATA spare parts
886360960091	SKIRT PANEL COMPL-DRFOOT STEP	TATA spare parts
886360960092	SKIRT PANEL COMPL.	TATA spare parts
886360960093	SKIRT PANEL COMPL.	TATA spare parts
886360960094	SKIRT PANEL COMPL.	TATA spare parts
886360960095	SKIRT PANEL COMPL.	TATA spare parts
886360960096	SKIRT PANEL COMPL.	TATA spare parts
886360960097	SKIRT PANEL COMPL.	TATA spare parts
886360960098	SKIRT PANEL COMPL. /FT	TATA spare parts
886360960099	SKIRT PANEL COMPL.	TATA spare parts
886360960100	DOOR ASSY. / B.B.	TATA spare parts
886360960101	DOOR ASSY. / S.T.	TATA spare parts
886360960102	WHEEL SIDE COVER / F	TATA spare parts
886360960103	WHEEL SIDE COVER / R	TATA spare parts
886360960104	WHEEL SIDE COVER / F	TATA spare parts
886360960105	SKIRT PANEL COMPL.	TATA spare parts
886360960106	SKIRT PANEL COMPL.	TATA spare parts
886360960107	SKIRT PANEL COMPL.	TATA spare parts
886360960108	SKIRT PANEL COMPL.	TATA spare parts
886360960109	SKIRT PANEL COMPL.	TATA spare parts
886360960110	SKIRT PANEL COMPL.	TATA spare parts
886360960111	SKIRT PANEL COMPL. /FT	TATA spare parts
886360960112	DOOR ASSY. / B.B.	TATA spare parts
886360960113	DOOR ASSY. / S.T.	TATA spare parts
886360960114	WHEEL SIDE COVER / F	TATA spare parts
886360960115	WHEEL SIDE COVER / R	TATA spare parts
886360960116	WHEEL SIDE COVER / F	TATA spare parts
886360960117	SKIRT PANEL COMPL. /FT	TATA spare parts
886360960118	SKIRT PANEL COMPL.	TATA spare parts
886360960119	DOOR ASSY. / S.T.	TATA spare parts
886360960120	WHEEL SIDE COVER / R	TATA spare parts
886360960121	SKIRT PANEL COMPLETE	TATA spare parts
886360960122	SKIRT PANEL COMPLETE	TATA spare parts
886360960123	SKIRT PANEL COMPLETE	TATA spare parts
886360960124	SKIRT PANEL COMPLETE	TATA spare parts
886360960125	SKIRT PANEL COMPLETE	TATA spare parts

886360960126	SKIRT PANEL COMPLETE/F.T	TATA spare parts
886360960127	DOOR ASSEMBLY/B.B.	TATA spare parts
886360960128	DOOR ASSEMBLY/S.T.	TATA spare parts
886360960129	WHEEL SIDE COVER/F.DRIVER	TATA spare parts
886360960130	SKIRT PANEL COMPLETE	TATA spare parts
886360960131	SKIRT PANEL COMPLETE	TATA spare parts
886360960132	SKIRT PANEL COMPLETE	TATA spare parts
886360960133	SKIRT PANEL COMPLETE/F.T	TATA spare parts
886360960134	SKIRT PANEL COMPLETE	TATA spare parts
886360960135	DOOR ASSEMBLY/B.B.	TATA spare parts
886360960136	DOOR ASSEMBLY/S.T.	TATA spare parts
886360960137	WHEEL SIDE COVER/R	TATA spare parts
886360960138	WHEEL SIDE COVER/F.DRIVER	TATA spare parts
886360960139	SKIRT PANEL COMPLETE	TATA spare parts
886360960140	FRP FRONT PANEL	TATA spare parts
886360960141	FRP FRONT BUMPER	TATA spare parts
886360960142	FRONT WINDSHIELD MOULD	TATA spare parts
886360960143	FRONT FRP FLAP	TATA spare parts
886360960144	SKIRT PANEL COMPL.	TATA spare parts
886360960145	SKIRT PANEL COMPL.	TATA spare parts
886360960146	SKIRT PANEL COMPL.	TATA spare parts
886360960147	HATCH COVER FITTED ON FLOOR	TATA spare parts
886360960148	FLAP ON LOCK OF EMERGENCY DOOR	TATA spare parts
886360960149	HOOPER TYPE WINDOW	TATA spare parts
886360960150	FRP REAR PANEL	TATA spare parts
886360960151	REAR BUMPER¿ (METAL SHEET)ASSEMBLY	TATA spare parts
886360960152	INSPECTION¿LID	TATA spare parts
886360960153	INSPECTION¿LID	TATA spare parts
886360960154	INSPECTION¿LID	TATA spare parts
886360960155	FRP REAR PANEL	TATA spare parts
886360960156	WHEEL SIDE COVER	TATA spare parts
886360960157	WHEEL SIDE COVER	TATA spare parts
886360960158	SKIRT PANEL COMPL	TATA spare parts
886360960159	SKIRT PANEL COMPL	TATA spare parts
886360960160	SKIRT PANEL COMPL	TATA spare parts
886360960161	WHEEL SIDE COVER	TATA spare parts
886360960162	WHEEL SIDE COVER	TATA spare parts
886360960163	SKIRT PANEL COMPL	TATA spare parts
886360960164	SKIRT PANEL COMPL	TATA spare parts
886360960165	INSPECTION DOOR PANEL	TATA spare parts
886360960166	INSPECTION DOOR PANEL	TATA spare parts
886360960167	PANEL	TATA spare parts
886360960168	PANEL	TATA spare parts
886360960169	PANEL	TATA spare parts
886360960170	PANEL	TATA spare parts
886360960171	PANEL	TATA spare parts
886360960172	SKIRT PANEL COMPL.	TATA spare parts

886360960173	AL-EXTR.(NEW FRONT RAIN CHANNEL)	TATA spare parts
886360960174	RUBBER BEADING WHL ARCH(L=2.3MTR)	TATA spare parts
886360960175	WEAT.STRIP(BULB+MET.INS/E DR L=10MTR)	TATA spare parts
886360960176	VOLVO TYPE AL- EXTRUSION(L=4MTR)	TATA spare parts
886360960177	PASSENGER DOOR ASSEMBLY	TATA spare parts
886360960178	SKIRT PANEL	TATA spare parts
886360960179	SKIRT PANEL	TATA spare parts
886360960180	SKIRT PANEL	TATA spare parts
886360960181	REAR BUMPER MIDDLE	TATA spare parts
886360960182	SCREW HEAD COVER (WHITE)	TATA spare parts
886360960183	SCREW HEAD CAP (GREY)	TATA spare parts
886360960184	DUST SEAL-DRIVER DOOR	TATA spare parts
886360960185	FRP FLAP COMPLETE	TATA spare parts
886360960186	VINYL TUBE	TATA spare parts
886360960187	F.R.P. FRONT GRILL	TATA spare parts
886360960188	SIDE WIN ASSY-FULL SLD-CLR GLASS-PC	TATA spare parts
886360960189	SIDE WINDOW ASSY EMG	TATA spare parts
886360960190	WIPER SYSTEM FOR 10.2	TATA spare parts
886360960191	FRONT FRP PANEL	TATA spare parts
886360960192	FRT WINDSHIELD	TATA spare parts
886360960193	PASSENGER DOOR ASSEMBLY	TATA spare parts
886360960194	FRONT BUMPER ASSEMBLY	TATA spare parts
886360960195	RVM ARM ASSEMBLY	TATA spare parts
886360960196	W/S BEADING 11MTR	TATA spare parts
886360960197	DOOR ASSY/B.B.	TATA spare parts
886360960198	WHEEL SIDE COVER/R	TATA spare parts
886360960199	SKIRT PANEL COMPLETE	TATA spare parts
886360960200	WHEEL SIDE COVER/F	TATA spare parts
886360960201	WHEEL SIDE COVER/F	TATA spare parts
886360960202	SKIRT PANEL COMPLETE	TATA spare parts
886360960203	REAR WINDSHIELD	TATA spare parts
886360960204	REAR WINDSHIELD MOULD	TATA spare parts
886360960210	SKIRT PANEL LOCK HANDLE	TATA spare parts
886360960211	FLAP LOCK ASSY	TATA spare parts
886360960212	SS ROD (4 DIA) FORç LOCK	TATA spare parts
886360960213	SKIRT PANEL LOCK HANDLE (SINGL)	TATA spare parts
886360960214	PANEL (STRETCH PANEL)	TATA spare parts
886360960215	AL-EXTRUSION (REAR)	TATA spare parts
886360960216	BLACK PVC EXTRUSION (REAR)	TATA spare parts
886360960217	MOULDING END	TATA spare parts
886360960218	WHEEL BOX RH	TATA spare parts
886360960219	WHEEL BOX LH	TATA spare parts
886360960220	SIDE WIN ASSY RH	TATA spare parts
886360960221	FRP FRONT PANEL	TATA spare parts
886360960222	FRONT FRP ASSY(ELANZA DOUBLE SKIN)	TATA spare parts
886360960223	FRONT WINDSHIELD GLASS	TATA spare parts
886360960224	FRONT WINDSHIELD MOULD	TATA spare parts

886360960225	FRONT BUMPER COMPT FRP	TATA spare parts
886360960226	HINGE ASSEMBLY (LH)	TATA spare parts
886360960227	HINGE ASSEMBLY (RH)	TATA spare parts
886360960228	FRONT FRP FLAP	TATA spare parts
886360960229	GRAB HANDLE	TATA spare parts
886360960230	ELANZA REAR FRP DOUBLE SKIN W/O BAGGAGE	TATA spare parts
886360960231	REAR BUMPER ASSY COMPLETE	TATA spare parts
886360960232	REAR GLASS WIND SHIELD	TATA spare parts
886360960233	SKIRT PANEL COMPL	TATA spare parts
886360960234	SKIRT PANEL COMPL	TATA spare parts
886360960235	SKIRT PANEL COMPL	TATA spare parts
886360960236	SKIRT PANEL COMPL	TATA spare parts
886360960237	SKIRT PANEL COMPL./FT	TATA spare parts
886360960238	SKIRT PANEL COMPL	TATA spare parts
886360960239	SKIRT PANEL COMPL./S.T	TATA spare parts
886360960240	SKIRT PANEL COMPL./B.B	TATA spare parts
886360960241	SKIRT PANEL COMPL./B.R	TATA spare parts
886360960242	WHEEL SIDE PANEL COMPL./F	TATA spare parts
886360960243	WHEEL SIDE PANEL COMPL./R	TATA spare parts
886360960244	WHEEL SIDE PANEL COMPL./F	TATA spare parts
886360960245	SKIRT PANEL COMPL	TATA spare parts
886360960246	FUEL TANK LID ASSEMBLY	TATA spare parts
886360960247	TRIANGULAR PANEL	TATA spare parts
886360960248	TRIANGULAR PANEL	TATA spare parts
886360960249	SIDE WIN ASSY-DARK GREY TINT	TATA spare parts
886360960250	B-PILLAR LH	TATA spare parts
886360960251	B-PILLAR RH	TATA spare parts
886360960252	INSPECTION LID ASSEMBLY	TATA spare parts
886360960253	INSPECTION LID ASSEMBLY	TATA spare parts
886360960254	INSPECTION LID ASSEMBLY	TATA spare parts
886360960255	INSPECTION LID ASSEMBLY	TATA spare parts
886360960256	DASHBOARD COMPLETE	TATA spare parts
886360960257	SKIRT PANEL COMPLETE	TATA spare parts
886360960258	SKIRT PANEL COMPLETE RH	TATA spare parts
886360960259	SKIRT PANEL COMPL.	TATA spare parts
886360960260	SKIRT PANEL COMPL.	TATA spare parts
886360960261	SKIRT PANEL COMPL.	TATA spare parts
886360960262	SKIRT PANEL COMPL.	TATA spare parts
886360960263	SKIRT PANEL COMPL.	TATA spare parts
886360960264	TRAIINGULAR PANEL	TATA spare parts
886360960265	SKIRT PANEL COMPL.	TATA spare parts
886360960266	SKIRT PANEL COMPL.	TATA spare parts
886360960267	SKIRT PANEL COMPL./F.T.	TATA spare parts
886360960268	SKIRT PANEL COMPL.	TATA spare parts
886360960269	SKIRT PANEL COMPL.	TATA spare parts
886360960270	DOOR ASSY. / B.T.	TATA spare parts
886360960271	DOOR ASSY. / S.T.	TATA spare parts

886360960272	WHEEL SIDE COVER /F	TATA spare parts
886360960273	WHEEL SIDE COVER/REAR	TATA spare parts
886360960274	SKIRT PANEL COMPL.	TATA spare parts
886360960275	SKIRT PANEL COMPL.	TATA spare parts
886360960276	SKIRT PANEL COMPL.	TATA spare parts
886360960277	SKIRT PANEL COMPL./F.T.	TATA spare parts
886360960278	SKIRT PANEL COMPL.	TATA spare parts
886360960279	SKIRT PANEL COMPL.	TATA spare parts
886360960280	SKIRT PANEL COMPL.	TATA spare parts
886360960281	SKIRT PANEL COMPL./B.BOX	TATA spare parts
886360960282	SKIRT PANEL COMPL./SPARE TYRE	TATA spare parts
886360960283	WHEEL SIDE COVER/FR	TATA spare parts
886360960284	WHEEL SIDE COVER /REAR	TATA spare parts
886360960285	WHEEL SIDE COVER/FR	TATA spare parts
886360960286	PLASTIC FOOT STEP COVER	TATA spare parts
886360960287	PIPE/ERW 19 DIA X 1MM THK(PC) L=3MTR	TATA spare parts
886360960288	GUARD RAIL BRACKET	TATA spare parts
886360960289	END GUARD RAIL BRACKET	TATA spare parts
886360960290	STICKER SET (RIVETTED TYPE)	TATA spare parts
886360960291	REAR FRP PANEL	TATA spare parts
886360960292	AL EXTRUSION-FLAT STRIP(4MTR CUT TO LENG	TATA spare parts
886360960293	AL BLIND RIVET(4DIAX16L)	TATA spare parts
886360960294	SIKA 252	TATA spare parts
886360960295	SKIRT PANEL	TATA spare parts
886360960296	SKIRT PANEL	TATA spare parts
886360960297	SIDE PANEL(SKRETCH PANEL)	TATA spare parts
886360960298	SKIRT PANEL COMPL. (DRV. STEP)	TATA spare parts
886360960299	SKIRT PANEL COMPL	TATA spare parts
886360960300	SKIRT PANEL COMPL/ BATTERY FLAP	TATA spare parts
886360960301	SKIRT PANEL COMPL	TATA spare parts
886360960302	SKIRT PANEL COMPL	TATA spare parts
886360960303	SKIRT PANEL COMPL	TATA spare parts
886360960304	SKIRT PANEL COMPL. /FT	TATA spare parts
886360960305	SKIRT PANEL COMPL	TATA spare parts
886360960306	SKIRT PANEL COMPL	TATA spare parts
886360960307	FRONT HEADER CORNER RH	TATA spare parts
886360960308	FRONT HEADER CORNER LH	TATA spare parts
886360960309	FRONT PILLAR RH - H/R	TATA spare parts
886360960310	FRONT PILLAR LH - H/R	TATA spare parts
886360960311	FRONT PANEL CENTER	TATA spare parts
886360960312	REAR HEADER CENTER PANEL	TATA spare parts
886360960313	REAR HEADER CORNER PANEL LH	TATA spare parts
886360960314	REAR HEADER CORNER PANEL RH	TATA spare parts
886360960315	REAR PILLAR LH	TATA spare parts
886360960316	REAR PILLAR RH	TATA spare parts
886360960318	SKIRT PANEL COMPL	TATA spare parts
886360960319	SKIRT PANEL COMPL	TATA spare parts

886360960320	SKIRT PANEL COMPL	TATA spare parts
886360960321	SKIRT PANEL COMPL	TATA spare parts
886360960322	SKIRT PANEL COMPL	TATA spare parts
886360960323	SKIRT PANEL COMPL	TATA spare parts
886360960324	SKIRT PANEL COMPL	TATA spare parts
886360960325	SKIRT PANEL COMPL./SPARE TYRE	TATA spare parts
886360960326	SKIRT PANEL COMPL./SPARE TYRE	TATA spare parts
886360960327	SKIRT PANEL COMPL. /FT	TATA spare parts
886360960328	SKIRT PANEL COMPL	TATA spare parts
886360960329	SKIRT PANEL COMPL	TATA spare parts
886360960330	SKIRT PANEL COMPL	TATA spare parts
886360960331	SKIRT PANEL COMPL	TATA spare parts
886360960332	WHEEL SIDE COVER / REAR	TATA spare parts
886360960333	WHEEL SIDE COVER / FRONT	TATA spare parts
886360960334	SKIRT PANEL COMPL	TATA spare parts
886360960335	WHEEL SIDE COVER / FRONT	TATA spare parts
886360960336	SKIRT PANEL COMPL	TATA spare parts
886360960337	SKIRT PANEL COMPL	TATA spare parts
886360960338	SKIRT PANEL COMPL	TATA spare parts
886360960339	SKIRT PANEL COMPL	TATA spare parts
886360960340	SKIRT PANEL COMPL	TATA spare parts
886360960341	SKIRT PANEL COMPL	TATA spare parts
886360960342	SKIRT PANEL COMPL. /FT	TATA spare parts
886360960343	SKIRT PANEL COMPL	TATA spare parts
886360960344	WHEEL SIDE COVER / F	TATA spare parts
886360960345	WHEEL SIDE COVER / R	TATA spare parts
886360960346	WHEEL SIDE COVER / F	TATA spare parts
886360960347	WHEEL SIDE COVER / R	TATA spare parts
886360960348	FRONT DVD PANEL	TATA spare parts
886360960349	SKIRT PANEL COMPL.	TATA spare parts
886360960350	SKIRT PANEL COMPL.	TATA spare parts
886360960351	SKIRT PANEL COMPL.	TATA spare parts
886360960352	SKIRT PANEL COMPL.	TATA spare parts
886360960353	SKIRT PANEL COMPL.	TATA spare parts
886360960354	SKIRT PANEL COMPL.	TATA spare parts
886360960355	SKIRT PANEL COMPL. /FT	TATA spare parts
886360960356	SKIRT PANEL COMPL.	TATA spare parts
886360960357	DOOR ASSY. / B.B.	TATA spare parts
886360960358	DOOR ASSY/S.T	TATA spare parts
886360960359	WHEEL SIDE COVER / F	TATA spare parts
886360960360	WHEEL SIDE COVER / R	TATA spare parts
886360960361	WHEEL SIDE COVER / F	TATA spare parts
886360960362	WHEEL SIDE COVER / R	TATA spare parts
886360960363	FRONT INNER ABS PANEL	TATA spare parts
886360960364	FRP FRONT PANEL	TATA spare parts
886360960365	SKIRT PANEL COMPL.	TATA spare parts
886360960366	SKIRT PANEL COMPL.	TATA spare parts

886360960367	SKIRT PANEL COMPL.	TATA spare parts
886360960368	SKIRT PANEL COMPL./B.R	TATA spare parts
886360960369	SKIRT PANEL COMPL.	TATA spare parts
886360960370	SKIRT PANEL COMPL.	TATA spare parts
886360960371	SKIRT PANEL COMPL.	TATA spare parts
886360960372	SKIRT PANEL COMPL.	TATA spare parts
886360960373	WHEEL SIDE COVER /R	TATA spare parts
886360960374	DOOR ASSY. / B.T.	TATA spare parts
886360960375	DOOR ASSY. / S.T.	TATA spare parts
886360960376	WHEEL SIDE COVER / F	TATA spare parts
886360960377	WHEEL SIDE COVER / R	TATA spare parts
886360960378	WHEEL SIDE COVER / F	TATA spare parts
886360960379	SKIRT PANEL COMPL./FT	TATA spare parts
886360960380	PANEL	TATA spare parts
886360960381	AL-EXTRUSION (SKIRT RAIL)	TATA spare parts
886360960382	SKIRT PANEL COMPL.	TATA spare parts
886360960383	SKIRT PANEL COMPL.	TATA spare parts
886360960384	SKIRT PANEL COMPL.	TATA spare parts
886360960385	SKIRT PANEL COMPL.	TATA spare parts
886360960386	SKIRT PANEL COMPL.	TATA spare parts
886360960387	SKIRT PANEL COMPL.	TATA spare parts
886360960388	SKIRT PANEL COMPL. /FT	TATA spare parts
886360960389	SKIRT PANEL COMPL.	TATA spare parts
886360960390	DOOR ASSY. / B.B.	TATA spare parts
886360960391	DOOR ASSY. / S.T.	TATA spare parts
886360960392	VINYL TUBE(L=19MTR)	TATA spare parts
886360960393	AL-EXTRUSION (GUTTER)(L=4MTR)	TATA spare parts
886360960394	FRONT FRP PANEL	TATA spare parts
886360960395	FRT HEADER CENT - L/R	TATA spare parts
886360960396	FRONT PILLAR RH	TATA spare parts
886360960397	FRONT PILLAR LH	TATA spare parts
886360960398	FRONT GRILL	TATA spare parts
886360960399	SKIRT PANEL COMPLETE	TATA spare parts
886360960400	SKIRT PANEL COMPLETE	TATA spare parts
886360960401	SKIRT PANEL COMPLETE	TATA spare parts
886360960402	SKIRT PANEL COMPL.	TATA spare parts
886360960403	SKIRT PANEL COMPL.	TATA spare parts
886360960404	SKIRT PANEL COMPL.	TATA spare parts
886360960405	PANEL	TATA spare parts
886360960406	WHEEL SIDE COVER	TATA spare parts
886360960407	DOOR ASSY. /¿ BAG BAT.	TATA spare parts
886360960408	DOOR ASST. / BAT	TATA spare parts
886360960409	WHEEL SIDE COVER/F LH	TATA spare parts
886360960410	WHEEL SIDE COVER	TATA spare parts
886360960411	WHEEL SIDE COVER /R	TATA spare parts
886360960412	SKIRT PANEL COMPL.	TATA spare parts
886360960413	SKIRT PANEL COMPL. / F.T	TATA spare parts



886360960414	FOOT STEP COVER	TATA spare parts
886360960415	SKIRT PANEL COMPLETE	TATA spare parts
886360960416	SKIRT PANEL COMPLETE	TATA spare parts
886360960417	SKIRT PANEL COMPLETE	TATA spare parts
886360960418	SKIRT PANEL COMPL.	TATA spare parts
886360960419	WHEEL SIDE COVER	TATA spare parts
886360960420	DOOR ASST. / B.T	TATA spare parts
886360960421	DOOR ASST. / S.T.	TATA spare parts
886360960422	WHEEL SIDE COVER/F	TATA spare parts
886360960423	WHEEL SIDE COVER/R	TATA spare parts
886360960424	SKIRT PANEL COMPLETE	TATA spare parts
886360960425	SKIRT PANEL COMPL./FT	TATA spare parts
886360960426	REAR INNER FRP PANEL	TATA spare parts
886360960427	G.P PVC SHEET OOTIS GREY	TATA spare parts
886360960428	FRONT PILLAR RH - H/R	TATA spare parts
886360960429	FRONT PILLAR LH - H/R	TATA spare parts
886360960430	FRONT GRILL	TATA spare parts
886360960431	FRONT BUMPER CENTER	TATA spare parts
886360960432	FRONT BUMPER ASSY LH	TATA spare parts
886360960433	FRONT BUMPER ASSY RH	TATA spare parts
886360960434	REAR PILLAR LH	TATA spare parts
886360960435	REAR PILLAR RH	TATA spare parts
886360960436	REAR GLASS MOUNTING PANEL	TATA spare parts
886360960437	REAR FLAP PANEL	TATA spare parts
886360960438	WEATHER STRIP(WINDSHILD FRONT)	TATA spare parts
886360960439	REAR BUMPER CENTER	TATA spare parts
886360960440	REAR BUMPER ASSY RH	TATA spare parts
886360960441	REAR BUMPER ASSY LH	TATA spare parts
886360960442	SKIRT PANEL COMPL.	TATA spare parts
886360960443	SKIRT PANEL COMPL.	TATA spare parts
886360960444	SKIRT PANEL COMPL.	TATA spare parts
886360960445	SKIRT PANEL COMPL.	TATA spare parts
886360960446	SKIRT PANEL COMPL.	TATA spare parts
886360960447	SKIRT PANEL COMPL.	TATA spare parts
886360960448	SKIRT PANEL COMPL.	TATA spare parts
886360960449	SKIRT PANEL COMPL. /FT	TATA spare parts
886360960450	SKIRT PANEL COMPL.	TATA spare parts
886360960451	SKIRT PANEL COMPL.	TATA spare parts
886360960452	SKIRT PANEL COMPL.	TATA spare parts
886360960453	WHEEL SIDE COVER/REAR	TATA spare parts
886360960454	SKIRT PANEL COMPL	TATA spare parts
886360960455	WHEEL SIDE COVER /FR	TATA spare parts
886360960456	WHEEL SIDE COVER/REAR	TATA spare parts
886360960457	WHEEL SIDE COVER /FR	TATA spare parts
886360960458	WHEEL ARCH BEADING WITH METAL PLATE	TATA spare parts
886360960459	REAR WINDSHIELD (30 PERC TINTED)	TATA spare parts
886360960460	SKIRT PANEL COMPL.	TATA spare parts

886360960461	SKIRT PANEL COMPL.	TATA spare parts
886360960462	SKIRT PANEL COMPL.	TATA spare parts
886360960463	SKIRT PANEL COMPL.	TATA spare parts
886360960464	SKIRT PANEL COMPL.	TATA spare parts
886360960465	SKIRT PANEL COMPL./FT	TATA spare parts
886360960466	DOOR ASSY. / B.R.	TATA spare parts
886360960467	HINGE RH	TATA spare parts
886360960468	HINGE LH	TATA spare parts
886360960469	SKIRT PANEL COMPLETE	TATA spare parts
886360960470	BATTERY BOX FLAP	TATA spare parts
886360960471	SKIRT PANEL (L=1844)	TATA spare parts
886360960472	SKIRT PANEL(L=1422)	TATA spare parts
886360960473	SKIRT PANEL(L=231)	TATA spare parts
886360960474	SKIRT PANEL(L=1415)	TATA spare parts
886360960475	SKIRT PANEL (L=1844)	TATA spare parts
886360960476	SKIRT PANEL (L=502)	TATA spare parts
886360960477	SKIRT PANEL (L=530)	TATA spare parts
886360960478	SKIRT PANEL (L=1055)	TATA spare parts
886360960479	WHEEL ARCH BEADING WITH METAL	TATA spare parts
886360960480	SKIRT PANEL COMPL.(L=712)	TATA spare parts
886360960481	SKIRT PANEL COMPL.(L=1264)	TATA spare parts
886360960482	SKIRT PANEL COMPL.(L=2300)	TATA spare parts
886360960483	SKIRT PANEL COMPL.(L=1980)	TATA spare parts
886360960484	SKIRT PANEL COMPL.(1350)	TATA spare parts
886360960485	SKIRT PANEL COMPL. /FT	TATA spare parts
886360960486	REAR BUMPER COMPLETE - SHEET METAL	TATA spare parts
886360960487	BAGGAGE BOX SKIRT PANEL	TATA spare parts
886360960488	SKIRT PANEL COMPLETE	TATA spare parts
886360960489	SKIRT PANEL COMPLETE/F.T	TATA spare parts
886360960490	SKIRT PANEL COMPLETE	TATA spare parts
886360960491	SKIRT PANEL COMPLETE	TATA spare parts
886360960492	TRIANGULAR PANEL COMPL.	TATA spare parts
886360960493	SKIRT PANEL COMPLETE (L=980)	TATA spare parts
886360960494	SKIRT PANEL COMPLETE/S.T	TATA spare parts
886360960495	WHEEL SIDE COVER/F.	TATA spare parts
886360960496	WHEEL SIDE COVER/REAR	TATA spare parts
886360960497	WHEEL SIDE COVER/F.	TATA spare parts
886360960498	FRONT FRP ASSEMBLY	TATA spare parts
886360960499	REAR FRP PANEL	TATA spare parts
886360960500	SKIRT PANEL COMPL.	TATA spare parts
886360960501	WHEEL SIDE PANEL COMPL./R	TATA spare parts
886360960502	SKIRT PANEL COMPL.	TATA spare parts
886360960503	SKIRT PANEL COMPL.	TATA spare parts
886360960504	SKIRT PANEL COMPL.(L=435)	TATA spare parts
886360960505	SKIRT PANEL COMPL./FT	TATA spare parts
886360960506	SKIRT PANEL COMPL./S.T	TATA spare parts
886360960507	SKIRT PANEL COMPL./B.B	TATA spare parts

886360960508	SKIRT PANEL COMPL./B.R	TATA spare parts
886360960509	WHEEL SIDE PANEL COMPL./F	TATA spare parts
886360960510	WHEEL SIDE PANEL COMPL./R	TATA spare parts
886360960511	WHEEL SIDE PANEL COMPL./F	TATA spare parts
886360960512	SKIRT PANEL COMPL.(L=427)	TATA spare parts
886360960513	TRIANGULAR PANEL	TATA spare parts
886360960514	TRIANGULAR PANEL	TATA spare parts
886360960515	SKIRT PANEL COMPLETE (L=1279)	TATA spare parts
886360960516	SKIRT PANEL COMPLETE (L=528)	TATA spare parts
886360960517	SKIRT PANEL COMPLETE (L=1128)	TATA spare parts
886360960518	SKIRT PANEL COMPLETE (L=1268)	TATA spare parts
886360960519	SKIRT PANEL COMPLETE	TATA spare parts
886360960520	SKIRT PANEL COMPLETE (L=1279)	TATA spare parts
886360960521	SKIRT PANEL COMPLETE/F.T	TATA spare parts
886360960522	SPARE TYRE PANEL	TATA spare parts
886360960523	SKIRT PANEL COMPLETE (L=1188)	TATA spare parts
886360960524	WHEEL SIDE COVER/F.	TATA spare parts
886360960525	WHEEL SIDE COVER/F.	TATA spare parts
886360960526	WEATHER STRIP(L=10MTR)	TATA spare parts
886360960527	FRONT BUMPER COMPLETE	TATA spare parts
886360960528	REAR BUMPER ASSEMBLY(ROLLED STEEL SECTIO	TATA spare parts
886360960529	REAR GLASS (CLEAR TOUGHENED)	TATA spare parts
886360960530	RUBBER BEADING(LENGTH=10 MTR)	TATA spare parts
886360960531	REAR DESTINATION GLASS	TATA spare parts
886360960532	SKIRT PANEL COMPL.B.B (L=1356)	TATA spare parts
886360960533	TAPER SKIRT PANEL COMPL.	TATA spare parts
886360960534	EMG STEP SKIRT PANEL COMPL.(L=935)	TATA spare parts
886360960535	WHEEL SIDE COVER (L=2103)	TATA spare parts
886360960536	WHEEL SIDE COVER (L=1875)	TATA spare parts
886360960537	FUEL TANK SKIRT PANEL COMPL.	TATA spare parts
886360960538	UREA TANK SKIRT PANEL COMPL.	TATA spare parts
886360960539	DRV STEP SKIRT PANEL COMPL.	TATA spare parts
886360960540	WHEEL SIDE COVER (L=1484)	TATA spare parts
886360960541	WHEEL SIDE COVER (L=1476)	TATA spare parts
886360960542	PANEL ASSEMBLY	TATA spare parts
886360960543	PANEL (L=1151)	TATA spare parts
886360960544	PANEL (L=1275)	TATA spare parts
886360960545	PANEL (L=85)	TATA spare parts
886360960546	PANEL (L=1375)	TATA spare parts
886360960547	PANEL (L=922)	TATA spare parts
886360960548	FLAP& ASSY	TATA spare parts
886360960549	PANEL (L=550)	TATA spare parts
886360960550	BATTERY FLAP PANEL	TATA spare parts
886360960551	ANGLE SECTION (50X140X1.6THK)	TATA spare parts
886360960552	PANEL (L=440)	TATA spare parts
886360960553	PANEL (L=922)	TATA spare parts
886360960554	SKIRT PANEL (L=1111)	TATA spare parts

886360960555	PANEL (L=1111)	TATA spare parts
886360960556	SKIRT PANEL (L=2180)	TATA spare parts
886360960557	PANEL (L=2180)	TATA spare parts
886360960558	PANEL (L=1828)	TATA spare parts
886360960559	PANEL (L=1818)	TATA spare parts
886360960560	REAR INNER ABS PANEL	TATA spare parts
886360960561	GP PVC SHEET OOTIS GREY	TATA spare parts
886360960562	FRP FRONT STRUCTURE COMPL(REDA+RHD)	TATA spare parts
886360960563	FRONT WINDSHIELD WITH BAND	TATA spare parts
886360960564	REAR W/S RH GLASS(6HD-3PC-TUF)	TATA spare parts
886360960565	REAR W/S CTR GLASS(6HD-3PC-TUF)	TATA spare parts
886360960566	REAR W/S LH GLASS(6HD-3PC-TUF)	TATA spare parts
886360960567	SKIRT PANEL COMPLETE (L=1037)	TATA spare parts
886360960568	SKIRT PANEL COMPLETE (L=980)	TATA spare parts
886360960569	SKIRT PANEL COMPLETE (L=980)	TATA spare parts
886360960570	SKIRT PANEL COMPLETE (L=1070)	TATA spare parts
886360960571	SKIRT PANEL COMPLETE (L=695)	TATA spare parts
886360960572	SKIRT PANEL COMPLETE (L=1037)	TATA spare parts
886360960573	SKIRT PANEL COMPLETE (L=991)	TATA spare parts
886360960574	SKIRT PANEL COMPLETE/F.T.	TATA spare parts
886360960575	SKIRT PANEL COMPLETE (L=831)	TATA spare parts
886360960576	SKIRT PANEL COMPLETE	TATA spare parts
886360960577	SKIRT PANEL COMPLETE/B.B (L=831)	TATA spare parts
886360960578	SKIRT PANEL COMPLETE/S.T. (L=991)	TATA spare parts
886360960579	WHEEL SIDE COVER /F	TATA spare parts
886360960580	WHEEL SIDE COVER /R	TATA spare parts
886360960581	WHEEL SIDE COVER /FRONT	TATA spare parts
886360960582	SKIRT PANEL COMPLETE	TATA spare parts
886360960583	G. P. PVC SHEET OOTIS GREY	TATA spare parts
886360960584	SIDE COVER PVC MOULDING - BIG (L=2.3 MTR	TATA spare parts
886360960585	ROOF COVER PVC MOULDING - SMALL (L=2.3 M	TATA spare parts
886360960586	ALUMINIUM EXTRUSION HAT SECTION 19.5 (L=	TATA spare parts
886360960587	ALUMINIUM EXTRUSION HAT SECTION 29.5 (L=	TATA spare parts
886360960588	FRONT FRP JNNURM.LPO 1618	TATA spare parts
886360960589	REAR WINDSHIELD GLASS - JNNURM	TATA spare parts
886360960590	REAR BUMPER ASSEMBLY	TATA spare parts
886360960591	SKIRT PANEL(COURIER BOX)	TATA spare parts
886360960592	SKIRT PANEL COMPL. B.B	TATA spare parts
886360960593	SKIRT PANEL COMPLETE (L=416)	TATA spare parts
886360960594	SKIRT PANEL COMPLETE (L=729)	TATA spare parts
886360960595	SKIRT PANEL COMPLETE	TATA spare parts
886360960596	SKIRT PANEL COMPLETE/F.T	TATA spare parts
886360960597	SKIRT PANEL COMPLETE (L=1939)	TATA spare parts
886360960598	SKIRT PANEL COMPLETE	TATA spare parts
886360960599	SKIRT WHEELARCH PANEL R.A/LH	TATA spare parts
886360960600	SKIRT WHEELARCH PANEL F.A/LH	TATA spare parts
886360960601	SKIRT PANEL COMP.	TATA spare parts

886360960602	SKIRT WHEELARCH PANEL R.A/RH	TATA spare parts
886360960603	SKIRT WHEELARCH PANEL F.A/RH	TATA spare parts
886360960604	SKIRT PANEL COMP.	TATA spare parts
886360960605	PLATE REAR DOOR	TATA spare parts
886360960606	PLATE FRONT DOOR	TATA spare parts
886360960607	FRONT BUMPER ASSY	TATA spare parts
886360960608	REAR BUMPER METTALIC	TATA spare parts
886360960609	LOCK INSTALLATION/ EMERGENCY DOOR	TATA spare parts
886360960610	PASS. DOOR ASSEMBLY	TATA spare parts
886360960611	PASS. DOOR ASSEMBLY	TATA spare parts
886360960612	HINGE ASSY(PASSENGER DOOR-W/O HDLE)	TATA spare parts
886360960613	WNOST.STRIP (PASS.DOOR.BIG BULB)	TATA spare parts
886360960614	GLASS (229X1575X5 THK)	TATA spare parts
886360960615	PASSENGER DOOR LOCK ASSY-LCV MARCOPOLO	TATA spare parts
886360960616	SKIRT PANEL COMPLETE	TATA spare parts
886360960617	SKIRT PANEL COMPLETE	TATA spare parts
886360960618	SKIRT PANEL COMPLETE	TATA spare parts
886360960619	SKIRT PANEL COMPLETE	TATA spare parts
886360960620	SKIRT PANEL COMPLETE	TATA spare parts
886360960621	SKIRT PANEL COMPLETE	TATA spare parts
886360960622	SKIRT PANEL COMPLETE	TATA spare parts
886360960623	SKIRT PANEL COMPLETE	TATA spare parts
886360960624	SKIRT PANEL COMPLETE	TATA spare parts
886360960625	SKIRT PANEL COMPLETE	TATA spare parts
886360960626	SKIRT PANEL COMPLETE	TATA spare parts
886360960627	SKIRT PANEL COMPLETE	TATA spare parts
886360960628	SKIRT PANEL COMPLETE	TATA spare parts
886360960629	SKIRT PANEL COMPLETE	TATA spare parts
886360960630	SEAT ASSY 2S RH	TATA spare parts
886360960631	SEAT ASSY 2S RH	TATA spare parts
886360960632	SEAT ASSY 2S RH	TATA spare parts
886360960633	SEAT ASSY 2S RH	TATA spare parts
886360960634	SEAT ASSY 2S RH	TATA spare parts
886360960635	SEAT ASSY 2S RH	TATA spare parts
886360960636	SEAT ASSY 1S (100 3149 0203 607)	TATA spare parts
886360960637	SEAT ASSEMBLY (2 STR)	TATA spare parts
886360960638	SEAT ASSY 2S LH	TATA spare parts
886360960639	SEAT ASSEMBLY (2 STR)	TATA spare parts
886360960640	SEAT ASSEMBLY (2 STR)	TATA spare parts
886360960641	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
886360960642	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
886360960643	SIDE WINDOW ASSEMBLY	TATA spare parts
886360960644	HOOPER WINDOW ASSEMBLY	TATA spare parts
886360960645	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
886360960646	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
886360960647	BRACKET	TATA spare parts
886360960648	RUBBER PAD-ROUND(DIA 103)	TATA spare parts

886360960649	BEND PIPE FOR DRIVER S PARTITION	TATA spare parts
886360960650	PIPE ERW 017129	TATA spare parts
886360960651	RUBBER PAD-ROUND (DIA 97)	TATA spare parts
886360960652	ERGO FRP DASHBOARD FOR CTC	TATA spare parts
886364000001	REAR FACE TOP PART	TATA spare parts
886364960001	FRP REAR PANEL	TATA spare parts
886367000001	FRONT WINDSHIELD RH_JSQR	TATA spare parts
886367000002	FRONT WINDSHIELD LH_JSQR	TATA spare parts
886367000003	DRIVER DOOR PEEP GLASS	TATA spare parts
886367000004	FRONT WINDSHIELD RUBBER MOULD	TATA spare parts
886367000005	WINDSHIELD GLASS RH	TATA spare parts
886367000006	FRONT WINDSHIELD GLASS LP 407	TATA spare parts
886367000007	ASSLY WINDOW FIX	TATA spare parts
886367000008	Assly window	TATA spare parts
886367000009	FRONT WINDSHIELD GLASS	TATA spare parts
886367000010	REAR WINDSHIELD RUBBER MOULD	TATA spare parts
886367000011	ASSLY WINDOW	TATA spare parts
886367000012	WEATHER STRIP(EMG.ACR.WINDO L=5MTR)	TATA spare parts
886367000013	FRONT WINDSHIELD	TATA spare parts
886367000014	REAR WINDSHIELD	TATA spare parts
886367000015	DRIVER WINDOW	TATA spare parts
886367000016	DRIVER UPPER FIX GLASS	TATA spare parts
886367000017	DRIVER LOWER FIX GLASS	TATA spare parts
886367000018	PEEP GLASS 2	TATA spare parts
886367000019	CO-DRIVER FIX GLASS 1	TATA spare parts
886367000020	CO-DRIVER FIX GLASS 2	TATA spare parts
886367000021	RH SIDE SLIDING WINDOW	TATA spare parts
886367000022	RH SIDE FIX WINDOW	TATA spare parts
886367000023	RH SIDE SLIDING TAPERED WINDOW	TATA spare parts
886367000024	CO-DRIVER SLIDING WINDOW	TATA spare parts
886367000025	CO-DRIVER FIX WINDOW	TATA spare parts
886367000026	PEEP GLASS 1	TATA spare parts
886367000027	CO-DRIVER UPPER FIX GLASS	TATA spare parts
886367000028	JK DOOR UPPER FIX GLASS	TATA spare parts
886367000029	JK DOOR GLASS	TATA spare parts
886367000030	SIDE SLIDING WINDOW LH	TATA spare parts
886367000031	LH SIDE FIX WINDOW	TATA spare parts
886367000032	LH SIDE SLIDING TAPERED WINDOW	TATA spare parts
886367000033	FIXED GLASS	TATA spare parts
886367000034	SLIDING GLASS	TATA spare parts
886367000035	SLIDING GLASS	TATA spare parts
886367000036	SLIDING GLASS	TATA spare parts
886367000037	SLIDING GLASS	TATA spare parts
886367000038	FIXED GLASS	TATA spare parts
886367000039	FIXED GLASS	TATA spare parts
886367000040	FIXED GLASS	TATA spare parts
886367000041	FIXED GLASS	TATA spare parts

88636700042	FIXED GLASS	TATA spare parts
88636700043	SLIDING GLASS	TATA spare parts
88636700044	SLIDING GLASS	TATA spare parts
88636700045	REAR WINDSHIELD GLASS LP 407 MTS BUS	TATA spare parts
88636700046	FRONT WINDSHIELD LPO 1613 JAIL VAN	TATA spare parts
88636700047	PEEP GLASS MTS	TATA spare parts
88636700048	FRONT WINDSCREEN RUBBER GLAZING	TATA spare parts
88636700049	FRONT WINDSHIELD GLASS LP 1613/52 SRF BU	TATA spare parts
88636700050	REAR WINDSCREEN (LH CORNER PIECE)	TATA spare parts
88636700051	2/3 BOTTOM SLIDING WITH LOCK	TATA spare parts
88636700052	LH WINDOW (1195 X 915)	TATA spare parts
88636700053	REAR WINDSHIELD FRAME	TATA spare parts
88636700054	REAR WINDSHIELD WIRE MESH RH	TATA spare parts
88636700057	FRONT GLASS NEW COBRA 1613	TATA spare parts
88636700058	WINDOW ASSY LP 712/42 LH	TATA spare parts
88636700059	WINDOW ASSY LP 712/42 LH REAR	TATA spare parts
88636700060	WINDOW ASSY LP 1613/52 FULL SLIDING	TATA spare parts
88636700061	REAR RH SIDE WINDO ASSY LP 1512/52	TATA spare parts
88636700062	WINDOW LOCK ASSY	TATA spare parts
88636700063	FRONT WINDSHIELD	TATA spare parts
88636700064	REAR WIND SHIELD CENTER	TATA spare parts
88636700065	REAR WIND SHIELD LH	TATA spare parts
88636700066	REAR WIND SHIELD RH	TATA spare parts
88636700067	FRONT GLASS RUBBER LP 1613/52	TATA spare parts
88636700068	WINDOW CO-DRIVER SIDE	TATA spare parts
88636700069	TARPAULIN FOR ACE FACELIFT HT TIPPER	TATA spare parts
88636700070	FIX GLASS SIZE-(32X11)	TATA spare parts
88636700071	EMERGENCY DOOR SLIDING WINDOW GLASS (31	TATA spare parts
88636700072	EMERGENCY DOOR SLIDING REAR SIDE GLASS (	TATA spare parts
88636700073	ASSY.GLASS WINDSHIELD	TATA spare parts
88636700074	LAMINATED SAFETY GLASS	TATA spare parts
88636700075	DRIVER DOOR WINDOW	TATA spare parts
88636700076	SIDE WINDOW 1290X840	TATA spare parts
88636700077	SIDE WINDOW 1490X840	TATA spare parts
88636700078	SIDE WINDOW 630X840	TATA spare parts
88636700079	SIDE WINDOW 575X640	TATA spare parts
88636700080	FRONT WINDSHEILD	TATA spare parts
88636700081	SIDE SLIDING WINDOW -LH	TATA spare parts
88636700082	REAR WINDSHIELD	TATA spare parts
88636700083	REAR WINDSHIELD FIX GLASS	TATA spare parts
88636700084	WINDOWS SFC 407 COMPLETE WITH FRAME -SET	TATA spare parts
88636700085	REAR WINDSHIELD GLASS	TATA spare parts
88636700086	REAR WINDSHIELD GLASS(CENTER)	TATA spare parts
88636700087	SLIDING GLASS WITH ALU FRAME 21INCH X 20	TATA spare parts
88636700088	SLIDING DOUBLE GLASS 14INCH X 20INCH	TATA spare parts
88636700089	SLIDING GLASS WITH FRAME 32INCH X 6.1/4I	TATA spare parts
88636700090	SAFETY GLASS - 907MM(L)X786MM(W)X6MM(T)	TATA spare parts

886367000091	CORNER GLASS - 739MM(L)X270MM(W)X6MM(T)	TATA spare parts
886367000092	TOP GLASS - 872MM(L)X142MM(W)X6MM(T)	TATA spare parts
886367000093	FRONT WINDSHIELD LH	TATA spare parts
886367000094	FRONT WINDSHIELD RH	TATA spare parts
886367000095	SIDE WINDOW GLASS LH	TATA spare parts
886367000096	SIDE WINDOW GLASS RH	TATA spare parts
886367000097	PEEP GLASS WITH FRAME	TATA spare parts
886367000098	Wind Deflector Primered	TATA spare parts
886367000099	Front Aperture FRP	TATA spare parts
886367000100	Foot rest	TATA spare parts
886367000101	DRIVER DOOR SLIDING WINDOW	TATA spare parts
886367000102	SIDE SLIDING WINDOW RH	TATA spare parts
886367000103	SIDE FIX WINDOW RH	TATA spare parts
886367000104	EMERGENCY DOOR SLIDING WINDOW	TATA spare parts
886367000105	CO-DRIVER SLIDING WINDOW	TATA spare parts
886367000106	CO-DRIVER FIX WINDOW	TATA spare parts
886367000107	SIDE SLIDING WINDOW LH	TATA spare parts
886367000108	FRONT WINDSHIELD GLASS 1010 X 760 X 1020	TATA spare parts
886367000109	FRONT WINDSHIELD GLASS 1010 X 760 X 1020	TATA spare parts
886367000110	REAR WINDSHIELD GLASS	TATA spare parts
886367000111	WINDOW GLASS RHS 1195X915	TATA spare parts
886367000112	1232 BAY LHS MAIN WINDOW COMPLETE WITHO	TATA spare parts
886367000113	CO-DRIVER WINDOW FIX	TATA spare parts
886367000114	SLIDING WINDOW OF LPT 2518 CONTAINER	TATA spare parts
886367000115	FRONT WINDSHIELD RUBBER MOULD	TATA spare parts
886367000116	SIDE SLIDING WINDOW LH	TATA spare parts
886367000117	WINDSHIELD GLASS SET 36INCHX48INCH(LH &	TATA spare parts
886367000118	WINDSHIELD GLASS SET LH LPT 2518	TATA spare parts
886367000119	WINDSHIELD GLASS SET RH LPT 2518	TATA spare parts
886367000200	WINDOW ASSEMBLY LHS XENON	TATA spare parts
886367000201	WINDOW ASSEMBLY REAR XENON	TATA spare parts
886367000203	PEEP WINDOW GLASS LH BS6	TATA spare parts
886367000204	SIDE EMERGENCY WINDOW RH BS6	TATA spare parts
886367000205	EMERGENCY DOOR SLIDING WINDOW BS6	TATA spare parts
886367000206	DRIVER DOOR WINDOW	TATA spare parts
886367000207	CO-DRIVER WINDOW SLIDING	TATA spare parts
886367000208	PEEP WINDOW GLASS	TATA spare parts
886367000209	PARTITION WINDOW	TATA spare parts
886367000210	DRIVER WINDOW SLIDING	TATA spare parts
886367000211	SLIDING WINDOW BS6	TATA spare parts
886367000212	RUBBER PROFILE 1INCH WITH KEY BS6	TATA spare parts
886367000213	FRONT GLASS BS6	TATA spare parts
886367000214	FRONT GLASS RUBBER BANDING BS6	TATA spare parts
886367000215	SIDE WINDOW EMERGENCY RHS LP 712/42	TATA spare parts
886367000216	DRIVER DOOR WINDOW LP 407/34	TATA spare parts
886367000217	REAR GLASS LP 712/45 BS6	TATA spare parts
886367000218	WINDOW ASSY BS6	TATA spare parts



886367000219	WINDOW ASSY BS6	TATA spare parts
886367000220	WINDOW ASSY(SIDE WINDOW )LH BS6	TATA spare parts
886367000221	WINDOW ASSY(SIDE WINDOW )RH BS6	TATA spare parts
886367000222	WINDOW ASSY(SIDE WINDOW )LH BS6	TATA spare parts
886367000223	WINDOW ASSY(SIDE WINDOW )RH BS6	TATA spare parts
886367000224	WINDOW ASSY(SIDE WINDOW ) BS6	TATA spare parts
886367000225	WINDOW ASSY(D/DOOR) BS6	TATA spare parts
886367000226	WINDOW ASSY(E/DOOR) BS6	TATA spare parts
886367000227	PEEP WINDOW GLASS-5MM BS6	TATA spare parts
886367000228	FIXED WINDOW GLASS-5MM BS6	TATA spare parts
886367000229	FRONT WINDSHIELD GLASS	TATA spare parts
886367000230	FRONT GLASS MTS NEW (1321X2278) BS6	TATA spare parts
886367000231	WINDOW ASSY BS6	TATA spare parts
886367000232	WINDOW ASSY BS6	TATA spare parts
886367000233	WINDOW ASSY(SIDE WINDOW-963X1040X820) B	TATA spare parts
886367000234	WINDOW ASSY BS6	TATA spare parts
886367000235	WINDOW ASSY(D/DOOR) BS6	TATA spare parts
886367000236	WINDOW ASSY BS6	TATA spare parts
886367000237	WINDOW ASSY BS6	TATA spare parts
886367000238	WINDOW ASSY(SIDE WINDOW )RH BS6	TATA spare parts
886367000239	WINDOW ASSY(SIDE WINDOW )LH BS6	TATA spare parts
886367000240	WINDOW ASSY(SIDE WINDOW ) BS6	TATA spare parts
886367000241	WINDOW ASSY(SIDE WINDOW ) BS6	TATA spare parts
886367000242	WINDOW ASSY(DRIVER DOOR) BS6	TATA spare parts
886367000243	PEEP WINDOW LH BS6	TATA spare parts
886367000244	PEEP WINDOW RH BS6	TATA spare parts
886367000245	CO- DRIVER WINDOW ASSY BS6	TATA spare parts
886367000246	DRIVER WINDOW ASSY BS6	TATA spare parts
886367000247	SIDE WINDOW ASSY-LH BS6	TATA spare parts
886367000248	SIDE WINDOW ASSY-RH BS6	TATA spare parts
886367000249	DRIVER PARTISION WINDOW ASSY BS6	TATA spare parts
886367000250	REAR WINDOW ASSY-LH BS6	TATA spare parts
886367000251	REAR WINDOW ASSY-RH BS6	TATA spare parts
886367000252	REAR DOOR WINDOW ASSY BS6	TATA spare parts
886367000253	FRONT WIND SHEILD BS6	TATA spare parts
886367000254	PEEP WINDOW GLASS -RH BS6	TATA spare parts
886367000255	WINDOW SLIDING GLASS(D/DOOR) BS6	TATA spare parts
886367000256	WINDOW SLIDING GLASS-W1-RH BS6	TATA spare parts
886367000257	WINDOW SLIDING GLASS-E/WINDOW BS6	TATA spare parts
886367000258	WINDOW SLIDING GLASS-W2-RH BS6	TATA spare parts
886367000259	WINDOW SLIDING GLASS-W3-RH BS6	TATA spare parts
886367000260	WINDOW SLIDING GLASS(E/DOOR) BS6	TATA spare parts
886367000261	WINDOW SLIDING GLASS-W4-RH BS6	TATA spare parts
886367000262	PEEP WINDOW GLASS -LH BS6	TATA spare parts
886367000263	WINDOW SLIDING GLASS-W1-LH BS6	TATA spare parts
886367000264	WINDOW SLIDING GLASS-W2-LH BS6	TATA spare parts
886367000265	WINDOW SLIDING GLASS-W3-LH BS6	TATA spare parts

886367000266	SLIDING WINDOW ASSY (D/DOOR) BS6	TATA spare parts
886367000267	SLIDING WINDOW ASSY -W1-RH BS6	TATA spare parts
886367000268	SLIDING WINDOW ASSY -(EMERGENCY WINDOW)	TATA spare parts
886367000269	SLIDING WINDOW ASSY -W2-RH BS6	TATA spare parts
886367000270	SLIDING WINDOW ASSY (E/DOOR) BS6	TATA spare parts
886367000271	SLIDING WINDOW ASSY -W1-LH BS6	TATA spare parts
886367000272	FIXED WINDOW ASSY -W1-LH BS6	TATA spare parts
886367000273	SLIDING WINDOW ASSY -W2-LH BS6	TATA spare parts
886367000274	SLIDING WINDOW ASSY -W3-LH BS6	TATA spare parts
886367000275	SLIDING WINDOW ASSY -W4-LH BS6	TATA spare parts
886367000276	SLIDING WINDOW ASSY -W5-LH BS6	TATA spare parts
886367000277	SIDING WINDOW (D/DOOR) BS6	TATA spare parts
886367000278	EMERGENCY WINDOW 1-RH BS6	TATA spare parts
886367000279	SIDING WINDOW 2-RH BS6	TATA spare parts
886367000280	EMERGENCY DOOR WINDOW (E/DOOR) BS6	TATA spare parts
886367000281	SIDING WINDOW 3-RH BS6	TATA spare parts
886367000282	PEEP WINDOW GLASS-5MM-LH BS6	TATA spare parts
886367000283	FIXED WINDOW 1-LH BS6	TATA spare parts
886367000284	FIXED GLASS (465 X465) BS6	TATA spare parts
886367000285	SIDING WINDOW 1-LH BS6	TATA spare parts
886367000286	SIDING WINDOW 2-LH BS6	TATA spare parts
886367000287	REAR WINDSHEILD TSB MM 007 (850X465X500)	TATA spare parts
886367000288	REAR WINDSHEILD TSB MM 007 (1370X950X500)	TATA spare parts
886367000289	REAR WINDSHEILD TSB MM 007 LEA (850X465X	TATA spare parts
886367000290	WINDOW SLIDING GLASS-5MM(1490X835MM) BS6	TATA spare parts
886367000291	WINDOW SLIDING GLASS-5MM(1290X835MM) BS6	TATA spare parts
886367000292	WINDOW SLIDING GLASS-5MM(630X835MM) BS6	TATA spare parts
886367000293	WINDOW SLIDING GLASS-5MM(640X575) -E/DOC	TATA spare parts
886367000294	WINDOW SLIDING GLASS-5MM(685X735)-D/DOC	TATA spare parts
886367000295	PEEP WINDOW GLASS-5MM(740X180X265)-PEEP	TATA spare parts
886367000296	WINDOW SLIDING GLASS-5MM(D/DOOR) BS6	TATA spare parts
886367000297	WINDOW SLIDING GLASS-5MM(1-RH) BS6	TATA spare parts
886367000298	WINDOW SLIDING GLASS-5MM(EMERGENCY WIN	TATA spare parts
886367000299	WINDOW SLIDING GLASS-5MM(EMERGENCY DOC	TATA spare parts
886367000300	WINDOW SLIDING GLASS-5MM(1-LH) BS6	TATA spare parts
886367000301	WINDOW SLIDING GLASS-5MM(2-LH)) BS6	TATA spare parts
886367000302	WINDOW SLIDING GLASS-5MM(3-LH)) BS6	TATA spare parts
886367000303	SLIDING WINDOW(D/DOOR) BS6	TATA spare parts
886367000304	SLIDING WINDOW -W1-RH BS6	TATA spare parts
886367000305	SLIDING WINDOW -W2-RH BS6	TATA spare parts
886367000306	SLIDING WINDOW(C/DOOR) BS6	TATA spare parts
886367000307	SLIDING WINDOW -W1-LH BS6	TATA spare parts
886367000308	SLIDING WINDOW -W2-LH BS6	TATA spare parts
886367000309	SLIDING WINDOW -W1 (REAR) BS6	TATA spare parts
886367000310	FRONT WINDSHEILD	TATA spare parts
886367000311	PEEP WINDOW BS6	TATA spare parts
886367000312	PEEP WINDOW RH BS6	TATA spare parts

886367000313	CO- DRIVER WINDOW ASSY BS6	TATA spare parts
886367000314	DRIVER WINDOW ASSY BS6	TATA spare parts
886367000315	SIDE WINDOW ASSY-LH BS6	TATA spare parts
886367000316	SIDE WINDOW ASSY-RH BS6	TATA spare parts
886367000317	DRIVER PARTISION WINDOW ASSY BS6	TATA spare parts
886367000318	REAR WINDOW ASSY-LH BS6	TATA spare parts
886367000319	REAR WINDOW ASSY-RH BS6	TATA spare parts
886367000320	REAR DOOR WINDOW ASSY BS6	TATA spare parts
886367000321	SLIDING WINDOW ASSY (D/DOOR) BS6	TATA spare parts
886367000322	SLIDING WINDOW ASSY -W1-RH BS6	TATA spare parts
886367000323	SLIDING WINDOW ASSY -(EMERGENCY WINDOW)	TATA spare parts
886367000324	SLIDING WINDOW ASSY -W2-RH BS6	TATA spare parts
886367000325	SLIDING WINDOW ASSY (E/DOOR) BS6	TATA spare parts
886367000326	SLIDING WINDOW ASSY -W1-LH BS6	TATA spare parts
886367000327	FIXED WINDOW ASSY -W1-LH BS6	TATA spare parts
886367000328	SLIDING WINDOW ASSY -W2-LH BS6	TATA spare parts
886367000329	SLIDING WINDOW ASSY -W3-LH BS6	TATA spare parts
886367000330	SLIDING WINDOW ASSY -W4-LH BS6	TATA spare parts
886367000331	SLIDING WINDOW ASSY -W5-LH BS6	TATA spare parts
886367000332	REAR GLASS CLEAR FLAT BS6	TATA spare parts
886367000333	SLIDING WINDOW ASSY-W1-(D/DOOR) BS6	TATA spare parts
886367000334	SLIDING WINDOW ASSY-W2-RH BS6	TATA spare parts
886367000335	SLIDING WINDOW ASSY-W3-RH(EMERGENCY WIN	TATA spare parts
886367000336	SLIDING WINDOW ASSY-W1-LH BS6	TATA spare parts
886367000337	FIXED WINDOW ASSY-W2-LH BS6	TATA spare parts
886367000338	FIXED WINDOW GLASS BS6	TATA spare parts
886367000339	SLIDING WINDOW ASSY-W3-LH BS6	TATA spare parts
886367000340	HATRACK ASSY-LH BS6	TATA spare parts
886367000341	HATRACK ASSY-RH BS6	TATA spare parts
886367000342	WINDOW SLIDING GLASS-(D/DOOR)	TATA spare parts
886367000343	WINDOW SLIDING GLASS-W1-RH	TATA spare parts
886367000344	WINDOW GLASS--EMERGENCY WINDOW	TATA spare parts
886367000345	WINDOW SLIDING GLASS-W2-RH	TATA spare parts
886367000346	WINDOW SLIDING GLASS-(E/DOOR)	TATA spare parts
886367000347	WINDOW SLIDING GLASS-W1-LH	TATA spare parts
886367000348	WINDOW GLASS-W2-LH	TATA spare parts
886367000349	WINDOW SLIDING GLASS-W3-LH	TATA spare parts
886367000350	WINDOW SLIDING GLASS-W4-LH	TATA spare parts
886367000351	WINDOW SLIDING GLASS-W5-LH	TATA spare parts
886367000352	PEEP WINDOW GLASS-5MM BS6	TATA spare parts
886367000353	SLIDING WINDOW(D/DOOR) BS6	TATA spare parts
886367000354	SLIDING WINDOW -W1-RH BS6	TATA spare parts
886367000355	PEEP WINDOW GLASS-5MM BS6	TATA spare parts
886367000356	SLIDING WINDOW(C/DOOR) BS6	TATA spare parts
886367000357	SLIDING WINDOW -W1-LH BS6	TATA spare parts
886367000358	SLIDING WINDOW -W1-REAR BS6	TATA spare parts
886367000359	WINDOW SLIDING GLASS-(D/DOOR)	TATA spare parts

886367000360	WINDOW SLIDING GLASS-W1-RH	TATA spare parts
886367000361	WINDOW GLASS--EMERGENCY WINDOW	TATA spare parts
886367000362	WINDOW SLIDING GLASS-W2-RH	TATA spare parts
886367000363	WINDOW SLIDING GLASS-(E/DOOR)	TATA spare parts
886367000364	WINDOW SLIDING GLASS-W1-LH	TATA spare parts
886367000365	WINDOW GLASS-W2-LH	TATA spare parts
886367000366	WINDOW SLIDING GLASS-W3-LH	TATA spare parts
886367000367	WINDOW SLIDING GLASS-W4-LH	TATA spare parts
886367000368	WINDOW SLIDING GLASS-W5-LH	TATA spare parts
886367000369	WINDOW ASSY(D/DOOR ) BS6	TATA spare parts
886367000370	WINDOW ASSY(C/DOOR ) BS6	TATA spare parts
886367000371	WINDOW SLIDING GLASS-5MM(D/DOOR) BS6	TATA spare parts
886367000372	WINDOW SLIDING GLASS-5MM1-RH BS6	TATA spare parts
886367000373	WINDOW SLIDING GLASS-5MM2-E- WINDOW BS6	TATA spare parts
886367000374	WINDOW SLIDING GLASS-5MM2-RH BS6	TATA spare parts
886367000375	WINDOW SLIDING GLASS-5MM3-RH BS6	TATA spare parts
886367000376	WINDOW SLIDING GLASS-5MM(E/DOOR) BS6	TATA spare parts
886367000377	WINDOW SLIDING GLASS-5MM4-RH BS6	TATA spare parts
886367000378	WINDOW SLIDING GLASS-5MM1-LH BS6	TATA spare parts
886367000379	WINDOW SLIDING GLASS-5MM2-LH BS6	TATA spare parts
886367000380	WINDOW SLIDING GLASS-5MM3-LH BS6	TATA spare parts
886367000381	REAR GLASS CLEAR FLAT BS6	TATA spare parts
886367000382	FIXED WINDOW ASSY-W1-LH BS6	TATA spare parts
886367000383	SLIDING WINDOW ASSY-W2-LH BS6	TATA spare parts
886367000384	SFIXED WINDOW ASSY-W3-LH BS6	TATA spare parts
886367000385	SLIDING WINDOW ASSY-W4-LH BS6	TATA spare parts
886367000386	SLIDING WINDOW ASSY-W1-RH(D/DOOR) BS6	TATA spare parts
886367000387	SLIDING WINDOW ASSY-W2-RH BS6	TATA spare parts
886367000388	SLIDING WINDOW ASSY-W3-RH(EMRRGRENCY W	TATA spare parts
886367000389	HATRACK ASSY-LH BS6	TATA spare parts
886367000390	HATRACK ASSY-RH BS6	TATA spare parts
886367000391	WINDOW SLIDING GLASS(D/DOOR) BS6	TATA spare parts
886367000392	WINDOW SLIDING GLASS-W1-RH BS6	TATA spare parts
886367000393	WINDOW SLIDING GLASS-E/WINDOW BS6	TATA spare parts
886367000394	WINDOW SLIDING GLASS-W2-RH BS6	TATA spare parts
886367000395	WINDOW SLIDING GLASS(E/DOOR) BS6	TATA spare parts
886367000396	WINDOW SLIDING GLASS-W3-RH BS6	TATA spare parts
886367000397	WINDOW SLIDING GLASS-W1-LH BS6	TATA spare parts
886367000398	WINDOW SLIDING GLASS-W2-LH BS6	TATA spare parts
886367000399	WINDOW SLIDING GLASS-W3-LH BS6	TATA spare parts
886367000400	PEEP WINDOW BS6	TATA spare parts
886367000401	WINDOW ASSY(D/DOOR ) BS6	TATA spare parts
886367000402	PEEP WINDOW BS6	TATA spare parts
886367000403	WINDOW ASSY(C/DOOR ) BS6	TATA spare parts
886367012829	ASSY.GLASS WINDSHIELD	TATA spare parts
886367022829	LAMINATED SAFETY GLASS	TATA spare parts
886367960001	REAR GLASS	TATA spare parts

886367960002	PIPE /ERW (25.4 DIA) GUARD RAIL	TATA spare parts
886367960003	MOULDED RUBBER BEADING	TATA spare parts
886367960004	FRONT WINDSHIELD	TATA spare parts
886367960005	QUARTER CLASS	TATA spare parts
886367960006	DRV. DOOR WINDOW ASSY.	TATA spare parts
886367960007	PASSENGER DOOR WINDOW	TATA spare parts
886367960008	SIDE WINDOW ASSY.	TATA spare parts
886367960009	SIDE WINDOW ASSY.	TATA spare parts
886367960010	SIDE WINDOW ASSY.	TATA spare parts
886367960011	SIDE WINDOW ASSY.	TATA spare parts
886367960012	SIDE WINDOW ASSY.	TATA spare parts
886367960013	WINDOW ASSEMBLY - EMG.	TATA spare parts
886367960014	WINDOW ASSY - EMG	TATA spare parts
886367960015	SD WIN ASSY-CTB-1/3 FIX-2/3 SLD-CLR TEMP	TATA spare parts
886367960016	SIDE WINDOW ASSEMBLY - EMG	TATA spare parts
886367960017	SD WIN ASSY-CTB-1/3 FIX-2/3 SLD-CLR TEMP	TATA spare parts
886367960018	SD WIN ASSY-CTB-1/3 FIX-2/3 SLD-CLR TEMP	TATA spare parts
886367960019	SD WIN ASSY-CTB-1/3 FIX-2/3 SLD-CLR TEMP	TATA spare parts
886367960020	DRIVER DOOR WINDOW - FULL SLIDING	TATA spare parts
886367960021	GLASS (268X1595X5 THK)	TATA spare parts
886367960022	GLASS (288X1595X5 THK)	TATA spare parts
886367960023	GLASS (265X1855X5 THK)	TATA spare parts
886367960024	GLASS TINTED (288X1795X5 THK)	TATA spare parts
886367960025	GLASS TINTED (268X1795X5 THK)	TATA spare parts
886367960026	SIDE WIN ASSY(OPTYP-1/3 FIX-2/3 SLD-DARK	TATA spare parts
886367960027	SIDE WINDOW ASSY (OPTYPE-2PC-GREEN)	TATA spare parts
886367960028	SIDE WIN ASSY(OPTYP-1/3 FIX-2/3 SLD-DARK	TATA spare parts
886367960029	SIDE WIN ASSY (1/3 FIX-2/3 SLD-DARK GREY	TATA spare parts
886367960030	SIDE WIN ASSY(OPTYP-1/3 FIX-2/3 SLD-DARK	TATA spare parts
886367960031	SIDE WIN ASSY(OPTYP-1/3 FIX-2/3 SLD-DARK	TATA spare parts
886367960032	SIDE WIN ASSY(OPTYP-1/3 FIX-2/3 SLD-DARK	TATA spare parts
886367960033	SIDE WIN ASSY(OPTYP-1/3FIX-2/3SLD-DARK G	TATA spare parts
886367960034	FRONT WIND SHIELD	TATA spare parts
886367960035	FRONT RUBBER BEEDING (MOULDED)	TATA spare parts
886367960036	SD WINDOW ASSY(OPTYPE-3PC-TFIX-GRN)	TATA spare parts
886367960037	SIDE WINOW ASSEMBLY	TATA spare parts
886367960038	SIDE WINOW ASSEMBLY	TATA spare parts
886367960039	SIDE WINOW ASSEMBLY	TATA spare parts
886367960040	SIDE WINOW ASSEMBLY	TATA spare parts
886367960041	SIDE WINOW ASSEMBLY	TATA spare parts
886367960042	SIDE WINOW ASSEMBLY	TATA spare parts
886367960043	SIDE WINDOW ASSY- EMERGENCY DOOR	TATA spare parts
886367960044	SIDE WINDOW ASSY	TATA spare parts
886367960045	SIDE WINDOW ASSY	TATA spare parts
886367960046	SIDE WINDOW ASSY	TATA spare parts
886367960047	SIDE WINDOW ASSY- DRIVER DOOR	TATA spare parts
886367960048	SIDE WINDOW ASSY	TATA spare parts

886367960049	SIDE WINDOW ASSY	TATA spare parts
886367960050	SIDE WINDOW ASSY	TATA spare parts
886367960051	WEATHER STRIP(L=1300)	TATA spare parts
886367960052	WEDGE STRIP(L=1300)	TATA spare parts
886367960053	WINDOW ASSY - EMG	TATA spare parts
886367960054	SIDE WINDOW ASSY	TATA spare parts
886367960055	SIDE WINDOW ASSY	TATA spare parts
886367960056	SIDE WINDOW ASSY	TATA spare parts
886367960057	SIDE WINDOW ASSY	TATA spare parts
886367960058	WINDOW ASSY - EMG	TATA spare parts
886367960059	FRONT WINSHIELD	TATA spare parts
886367960060	REAR WINSHIELD	TATA spare parts
886367960061	SIDE WINDOW ASSY	TATA spare parts
886367960062	SIDE WINDOW ASSY	TATA spare parts
886367960063	SIDE WINDOW ASSY	TATA spare parts
886367960064	WINDOW ASSY DRIVER DOOR	TATA spare parts
886367960065	QUARTER GLASS	TATA spare parts
886367960066	SD WINDOW ASSY(OPTYPE-3PC-TFIX-GRN)	TATA spare parts
886367960067	SIDE WIN ASSY(1/3 TOP FIX-2/3 SLD-LIGHT	TATA spare parts
886367960068	SIDE WIN ASSY(1/3 TOP FIX-2/3 SLD-LIGHT	TATA spare parts
886367960069	SD WINDOW ASSY(OPTYPE-3PC-TFIX-GRN)	TATA spare parts
886367960070	FRONT WINDSHIELD BS3/4	TATA spare parts
886367960071	SD WINDOW ASSY-EMERGENCY DOOR	TATA spare parts
886367960072	SD WINDOW ASSY	TATA spare parts
886367960073	SD WINDOW ASSY	TATA spare parts
886367960074	SD WINDOW ASSY	TATA spare parts
886367960075	SD WINDOW ASSY	TATA spare parts
886367960076	SD WINDOW ASSY	TATA spare parts
886367960077	SD WINDOW ASSY-DRIVER	TATA spare parts
886367960078	SD WINDOW ASSY	TATA spare parts
886367960079	SD WINDOW ASSY-DRIVER DOOR	TATA spare parts
886367960080	SIDE WIN ASSY(OPTYP-1/3 FIX-2/3 SLD-DARK	TATA spare parts
886367960081	SIDE WIN ASSY-EMG.DOOR	TATA spare parts
886367960082	SIDE WIN ASSY	TATA spare parts
886367960083	SIDE WIN ASSY	TATA spare parts
886367960084	SIDE WIN ASSY	TATA spare parts
886367960085	SIDE WIN ASSY	TATA spare parts
886367960086	SIDE WINDOW ASSY	TATA spare parts
886367960087	SIDE WINDOW ASSY	TATA spare parts
886367960088	FRONT WINDSHIELD / RH	TATA spare parts
886367960089	FRONT WINDSHIELD / LH	TATA spare parts
886367960090	REAR GLASS (CLEAR TOUGHENED)	TATA spare parts
886367960091	SIDE WINDOW ASSY	TATA spare parts
886367960092	PRINTED GLASS DARK GREY TINT	TATA spare parts
886367960093	T-BEADING FOR WINDSHIELD(L=10MTR)	TATA spare parts
886367960094	FRONT WINDSHIELD/RH	TATA spare parts
886367960095	FRONT WINDSHIELD/LH	TATA spare parts

886367960096	FRONT WINDSHIELD MOULD BS2/3/4	TATA spare parts
886367960097	RUBBER BEADING	TATA spare parts
886367960098	SIDE WINDOW ASSY	TATA spare parts
886367960099	SIDE WINDOW ASSY	TATA spare parts
886367960100	SIDE WINDOW ASSY	TATA spare parts
886367960101	SIDE WINDOW ASSY	TATA spare parts
886367960102	SIDE WIN ASSY-SM22-FULL SLD-CLR GLASS-PC	TATA spare parts
886367960104	SIDE WINDOW ASSY	TATA spare parts
886367960105	EMG. WINDOW ASSY	TATA spare parts
886367960106	SIDE WINDOW ASSY	TATA spare parts
886367960107	EMG. WINDOW ASSY	TATA spare parts
886367960108	EMG. WINDOW ASSY	TATA spare parts
886367960109	FRONT WINDSHIELD BEADING(MOULDED)	TATA spare parts
886367960110	SIDE WINDOW ASSY PASSENGER SIDE	TATA spare parts
886367960111	SIDE WINDOW ASSY DRIVER SIDE	TATA spare parts
886367960112	FRONT WINDSHIELD	TATA spare parts
886367960113	SIDE WINDOW ASSY	TATA spare parts
886367960114	SIDE WINDOW ASSY	TATA spare parts
886367960115	SIDE WINDOW ASSY-DRIVER	TATA spare parts
886367960116	CO-DRIVER WINDOW ASSY	TATA spare parts
886367960117	FRONT WINDSHIELD MOULD	TATA spare parts
886367960118	FRONT WINDSHIELD GLASS	TATA spare parts
886367960119	FRONT RUBBER BEADING (MOULDED)	TATA spare parts
886367960120	ASSY WINDOW LH	TATA spare parts
886367960121	DRIVER DOOR WINDOW RH	TATA spare parts
886367960122	ASSY WINDOW RH	TATA spare parts
886367960123	ASSY WINDOW RH	TATA spare parts
886367960124	EMG DOOR WINDOW RH	TATA spare parts
886367960125	REAR WINSHIELD GLASS	TATA spare parts
886367960126	WINDOW ASSY - EMG	TATA spare parts
886367960127	SIDE WINDOW ASSY LH - LHD	TATA spare parts
886367960128	SIDE WINDOW ASSY REAR LH -LHD	TATA spare parts
886367960129	SIDE WIN ASSY-SM22-FULL SLD-CLR GLASS-PC	TATA spare parts
886367960130	SIDE WINDOW ASSY (SM22)	TATA spare parts
886367960131	PEEP GLASS	TATA spare parts
886367960132	FIX GLASS- EMG DOOR	TATA spare parts
886367960133	FIX GLASS	TATA spare parts
886367960134	FIX GLASS	TATA spare parts
886367960135	FIX GLASS	TATA spare parts
886367960136	FIX GLASS	TATA spare parts
886367960137	FIX GLASS-DRIVER DOOR	TATA spare parts
886367960138	FIX GLASS	TATA spare parts
886367960139	SIDE GLASS	TATA spare parts
886367960140	SIDE GLASS	TATA spare parts
886367960141	SIDE GLASS	TATA spare parts
886367960142	SIDE GLASS	TATA spare parts
886367960143	SIDE GLASS	TATA spare parts

886367960144	GLASS (460X692X5 THK)	TATA spare parts
886367960145	SIDE WINDOW ASSY	TATA spare parts
886367960146	SIDE WINDOW ASSY	TATA spare parts
886367960147	SIDE WINDOW ASSY	TATA spare parts
886367960148	SIDE WINDOW EMG DOOR	TATA spare parts
886367960149	SIDE WINDOW DRV DOOR	TATA spare parts
886367960150	SIDE WINDOW ASSY REAR RH	TATA spare parts
886367960151	SIDE WINDOW ASSY REAR LH	TATA spare parts
886367960152	FLAP FOR FUEL TANK (SPRING LOADED)	TATA spare parts
886367960153	SIDE WINDOW ASSEMBLY RH	TATA spare parts
886367960154	SIDE WINDOW ASSEMBLY LH	TATA spare parts
886367960155	FRONT WINDSHIELD	TATA spare parts
886367960156	WEATHER STRIP(EMERGENCY ACR.WINDO L=5MT	TATA spare parts
886367960157	WEDGE(KEY)BEAD(SMAL-RR/DEST L=10MTR)	TATA spare parts
886367960158	FRONT PASS. DOOR GLASS	TATA spare parts
886367960159	WINDOW ASSY - EMG	TATA spare parts
886367960160	SIDE WINDOW ASSY	TATA spare parts
886367960161	SIDE WINDOW ASSY	TATA spare parts
886367960162	SIDE WINDOW ASSY	TATA spare parts
886367960163	SIDE WINDOW ASSY	TATA spare parts
886367960164	FRONT PASS. DOOR GLASS	TATA spare parts
886367960165	SIDE WINDOW ASSY	TATA spare parts
886367960166	SIDE WINDOW ASSY	TATA spare parts
886367960167	SIDE WINDOW ASSY	TATA spare parts
886367960168	WINDOW ASSY - DRIVER	TATA spare parts
886367960169	SIDE WINDOW ASSY-CO. DRIVER	TATA spare parts
886367960170	QUARTER GLASS	TATA spare parts
886367960171	CATCHER FOR OPTYPE WINDOW LOCK	TATA spare parts
886367960172	WEATHER STRIP (L=10MTRS)	TATA spare parts
886367960173	WEDGE (KEY) BEADING (W/S .BIG FRT/RE) (L	TATA spare parts
886367960174	REAR WINDSHIELD	TATA spare parts
886367960175	CATCHER FOR OPTYPE LOCK	TATA spare parts
886367960176	SIDE WINDOW ASSY LH	TATA spare parts
886367960177	SIDE WINDOW ASSY REAR RH	TATA spare parts
886367960178	SIDE WINDOW ASSY FRONT RH	TATA spare parts
886367960179	SIDE WINDOW ASSY RH	TATA spare parts
886367960180	SIDE WINDOW ASSY-EMG DOOR	TATA spare parts
886367960181	SIDE WINDOW ASSY RH	TATA spare parts
886367960182	SIDE WINDOW ASSY LH	TATA spare parts
886367960183	SIDE WINDOW ASSY FRONT RH	TATA spare parts
886367960184	SIDE WINDOW DRV DOOR	TATA spare parts
886367960185	SIDE WINDOW ASSY REAR LH	TATA spare parts
886367960186	SIDE WINDOW ASSY REAR RH	TATA spare parts
886367960187	FRP DASHBOARD DOCUMENT BOX	TATA spare parts
886367960188	DASHBOARD DOCUMENT FLAP	TATA spare parts
886367960189	WEATHER STRIP (REAR WINDSHIELD)(L=10MTR)	TATA spare parts
886367960190	CENTRE PLATE	TATA spare parts



886367960191	WEATHER STRIP (L=10MTR)	TATA spare parts
886367960192	GLASS CLEAR(281X1610X5 THK)	TATA spare parts
886367960193	SIDE WINDOW ASSEMBLY EMG	TATA spare parts
886367960194	REAR GLASS MOUNTING PANEL	TATA spare parts
886367960195	REAR WINDSHIELD	TATA spare parts
886367960196	PEEP GLASS	TATA spare parts
886367960197	GLASS (265X1799X5 THK)	TATA spare parts
886367960198	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960199	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960200	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960201	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960202	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960203	WIND ASSY - EMG	TATA spare parts
886367960204	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960205	HOOPER TYPE WINDOW	TATA spare parts
886367960206	PEEP WINDOW	TATA spare parts
886367960207	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960208	GLASS TINTED (293X695X5 THK)	TATA spare parts
886367960209	PARTITION GLASS ASSY	TATA spare parts
886367960210	SD WINDOW ASSY(3PC-SM22-TFIX-CLEAR)	TATA spare parts
886367960211	SIDE WINDOW( DRIVER DOOR)	TATA spare parts
886367960212	OPTYPE WINDOW LOCK (INNER SHUTTER)	TATA spare parts
886367960213	OPTYPE WINDOW LOCK (OUTER SHUTTER)	TATA spare parts
886367960214	FRONT WINDSHIELD GLASS - JNNURM	TATA spare parts
886367960215	GLASS CLEAR(1930X296X5)	TATA spare parts
886367960216	T-BEADING (L=10 MTR)	TATA spare parts
886367960217	EMERGENCY WINDOW ASSY 510 MM	TATA spare parts
886367960218	SIDE WINDOW ASSY LOWER 1350 MM	TATA spare parts
886367960219	SIDE WINDOW ASSY UPPER 1350 MM	TATA spare parts
886367960220	1ST SIDE WINDOW ASSY LHS 1070 MM	TATA spare parts
886367960221	SIDE WINDOW ASSY LHS REAR 550 MM	TATA spare parts
886367960222	SIDE WINDOW ASSY RHS REAR 748 MM	TATA spare parts
886367960223	QUARTER GLASS CO DRIVER SIDE	TATA spare parts
886367960224	REAR WINDSHIELD GLASS	TATA spare parts
886367960225	RUBBER BEADING FOR WINDOWS	TATA spare parts
886367960226	FRONT W/S (SINGLE-PIECE)	TATA spare parts
886367960227	REAR WINDSHIELD (30PERC TINTED)	TATA spare parts
886367960228	SIDE WINDOW ASSY	TATA spare parts
886367960229	SIDE WINDOW ASSY	TATA spare parts
886367960230	FRONT W/S LAM GLASS W/O BAND 1610/1510	TATA spare parts
886367960231	PIPE/ERW (19.0 DIA X 1.2 THK) (PC)(L=3MT	TATA spare parts
886367960232	FRONT WINDSHIELD	TATA spare parts
886367960233	WINDOW ASSEMBLY - EMG	TATA spare parts
886367960234	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960235	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960236	DRIVER DOOR WINDOW ASSEMBLY	TATA spare parts
886367960237	SIDE WINDOW ASSEMBLY	TATA spare parts

886367960238	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960239	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960240	SIDE WIN ASSY (SM22-FLOCK-2PC-CLR)	TATA spare parts
886367960241	GLASS LIGHT GREEN TINT(397X722X5 THK)	TATA spare parts
886367960242	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960243	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960244	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960245	SIDE WIN ASSY (SM22-FLOCK-2PC-CLR)	TATA spare parts
886367960246	BRACKET FOR GUARD RAIL (PC)	TATA spare parts
886367960247	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960248	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960249	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960250	SIDE WINDOW ASSEMBLY-EMG	TATA spare parts
886367960251	TOP FIXED GLASS	TATA spare parts
886367960252	TOP FIXED GLASS	TATA spare parts
886367960253	TOP FIXED GLASS	TATA spare parts
886367960254	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960255	TOP FIXED GLASS	TATA spare parts
886367960256	TOP FIXED GLASS	TATA spare parts
886367960257	TOP FIXED GLASS	TATA spare parts
886367960258	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960259	SIDE WINDOW ASSEMBLY	TATA spare parts
886367960260	TOP FIXED GLASS	TATA spare parts
886367960261	TOP FIXED GLASS	TATA spare parts
886367960262	PIPE/ERW (19.0 DIA X 1 THK) (PC)	TATA spare parts
886367960263	SD WINDOW ASSY-EMG	TATA spare parts
886367960264	SD WINDOW ASSY	TATA spare parts
886367960265	SD WINDOW ASSY	TATA spare parts
886367960266	EMG SD WINDOW ASSY	TATA spare parts
886367960267	SD WINDOW ASSY	TATA spare parts
886367960268	WINDOW ASSY-DRIVER	TATA spare parts
886367960269	OPTYPE WINDOW LOCK(INNER SHUTTER)	TATA spare parts
886367960270	OPTYPE WINDOW LOCK(OUTER SHUTTER)	TATA spare parts
886367960272	SIDE WIN ASSY-SM22-FULL SLD-CLR GLASS-PC	TATA spare parts
886367960273	GLASS LAMINATED(675X761X5) SHUTTER GLASS	TATA spare parts
886367960274	WINDOW ASSEMBLY - EMG	TATA spare parts
886367960275	SD WIND ASSY (SM 22-1/3 FIX-2/3 SLD- CLR	TATA spare parts
886367960276	SD WIND ASSY (1/3 FIX-2/3 SLD- CLR T GLA	TATA spare parts
886367960277	DR.DOOR WINDOW ASSY.	TATA spare parts
886367960278	FIX GLASS- EMG DOOR	TATA spare parts
886367960279	FIX GLASS	TATA spare parts
886367960280	FIX GLASS (7 NOS)	TATA spare parts
886367960281	FIX GLASS	TATA spare parts
886367960282	FIX GLASS	TATA spare parts
886367960283	FIX GLASS (2 NOS)	TATA spare parts
886367960284	WINDOW ASSEMBLY 2PC FULL SLD	TATA spare parts
886367960285	WINDOW ASSEMBLY 2PC FULL SLD	TATA spare parts

886367960286	WINDOW ASSEMBLY 2PC FULL SLD	TATA spare parts
886367960287	WINDOW ASSEMBLY 2PC FULL SLD	TATA spare parts
886367960288	SIDE WIN ASSY-EMG.DOOR	TATA spare parts
886367960289	GUARD RAIL BRACKET	TATA spare parts
886367960290	SIDE WINDOW ASSY RH	TATA spare parts
886367960291	SIDE WINDOW ASSY LH	TATA spare parts
886367960292	SIDE FIXED GLASS LH	TATA spare parts
886367960293	SIDE FIXED GLASS RH	TATA spare parts
886367960294	SIDE WINDOW ASSY	TATA spare parts
886367960295	SIDE WINDOW (HORIZONTAL SLIDING)	TATA spare parts
886367960296	PEEP GLASS (W=300 H=790)	TATA spare parts
886367960297	PEEP GLASS	TATA spare parts
886367960298	GLASS (325X1670X5 THK)	TATA spare parts
886367960299	SIDE WINDOW (EMG DDOR)	TATA spare parts
886367960300	SIDE WINDOW (DRIVER DOOR)	TATA spare parts
886367960301	SIDE WINDOW ASSY (W=990 H=820)	TATA spare parts
886367960302	SIDE WINDOW ASSY(COLLAPSIBLE)	TATA spare parts
886367960303	PEEP WINDOW	TATA spare parts
886367960304	FIXED GLASS	TATA spare parts
886367960305	MODESTY PARTITION WINDOW (TOP & BOTTOM	TATA spare parts
886367960306	MODESTY PARTITION WINDOW (TOP FIXED & BO	TATA spare parts
886367960307	AL-EXTR.(ROUND PIPE 25.4 DIA X 2 M.M.)(P	TATA spare parts
886367960308	SIDE WINDOW ASSY	TATA spare parts
886367960309	FRONT WINDSHIELD RH	TATA spare parts
886367960310	FRONT WINDSHIELD LH	TATA spare parts
886367960311	SIDE WINDOW ASSY (L=11350)	TATA spare parts
886367960312	SIDE WINDOW ASSY (L=11050)	TATA spare parts
886367960313	SIDE WINDOW EMG DOOR	TATA spare parts
886367960314	SIDE WINDOW DRIVER DOOR	TATA spare parts
886367960315	SIDE WINDOW ASSY (L=10575)	TATA spare parts
886367960316	SIDE WINDOW ASSY (L=01050)	TATA spare parts
886367960317	QUARTER GLASS(RH)	TATA spare parts
886367960318	QUARTER GLASS(LH)	TATA spare parts
886367960319	FIX WINDOW	TATA spare parts
886367960320	SLIDING WINDOW ASSY	TATA spare parts
886367960321	GUARD RAIL BRACKET (POWDER COATED)	TATA spare parts
886367960322	PIPE/ERW (SKTM 11 19DIA X 2.0 THK)(PC)(L	TATA spare parts
886367970103	TAPER GLASS FOR SIDE WINDOW	TATA spare parts
886368000001	DASHBOARD	TATA spare parts
886368000002	ASSY. DASHBOARD	TATA spare parts
886368000003	FRP DASHBOARD	TATA spare parts
886368000004	COMPLETE TIPPER BODY 8CUM (W/O HYDRAULIC	TATA spare parts
886368000005	DASHBOARD LP 1613/52	TATA spare parts
886368000008	DASHBOARD FRP	TATA spare parts
886368000009	DASH BOARD LPO 1512/55	TATA spare parts
886368000010	DASHBOARD	TATA spare parts
886368000011	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts

886368000012	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts
886368000013	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts
886368000014	ENGINE HOOD BS6	TATA spare parts
886368000015	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts
886368000016	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts
886368000017	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts
886368000018	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts
886368000019	DASHBOARD	TATA spare parts
886368000020	INSTRUMENT CLUSTER PLATE	TATA spare parts
886368000021	ENGINE HOOD	TATA spare parts
886368000022	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts
886368000023	DASHBOARD	TATA spare parts
886368000024	INSTRUMENT CLUSTER PLATE	TATA spare parts
886368000025	ENGINE HOOD	TATA spare parts
886368000026	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts
886368000027	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts
886368000028	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts
886368000029	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts
886368000030	ENGINE HOOD BS6	TATA spare parts
886368810001	WINDSHIELD GLASS ¿ FRONT LH	TATA spare parts
886368810002	WINDSHIELD GLASS ¿ REAR RH	TATA spare parts
886368960001	DASHBOARD COMPLETE	TATA spare parts
886368960002	DASHBOARD COMPLETE	TATA spare parts
886368960003	DASHBOARD COMPLETE	TATA spare parts
886368960004	FRONT BUMPER COMPLETE	TATA spare parts
886368960005	LAMP BAZZEL LH	TATA spare parts
886368960006	LAMP BAZZEL RH	TATA spare parts
886368960007	COVER FOR RADIATOR	TATA spare parts
886368960008	DASHBOARD COMPLETE	TATA spare parts
886368960009	DASHBOARD COMPLETE	TATA spare parts
886368960010	DASHBOARD COMPLETE	TATA spare parts
886368960011	FRP DASHBOARD FOR NBSTC	TATA spare parts
886368960012	DASHBOARD ASSY	TATA spare parts
886368960013	FRP DASHBOARD FOR KIDZ	TATA spare parts
886368960014	DASHBOARD	TATA spare parts
886368960015	ERGO DASHBOARD FOR UTC 5D	TATA spare parts
886368960016	DASHBOARD	TATA spare parts
886368960017	LATCH ASSEMBLY	TATA spare parts
886369960001	F.R.P. FRONT PANEL	TATA spare parts
886369960002	FRP FRONT FLAP COMPLETE-COMFORT2500	TATA spare parts
886369960003	FRP FRONT PANEL	TATA spare parts
886370000001	LOAD BODY ASSEMBLY	TATA spare parts
886370000002	TIPPER BODY W/O HYD KIT	TATA spare parts
886370000003	LOAD BODY	TATA spare parts
886370000004	LOAD BODY HIGH DECK	TATA spare parts
886370000005	LOAD BODY COMP	TATA spare parts
886370000006	TROOP CARRIER SEATS SET	TATA spare parts

88637000007	CANOPY	TATA spare parts
88637000008	load body	TATA spare parts
88637000009	CARGO BODY 24 FT HSLB LIGHT WT	TATA spare parts
88637000010	WATER PUMP CPL	TATA spare parts
88637000012	MUD FLAP HINGE ASSY	TATA spare parts
88637000013	PIPE FRAME ASSY	TATA spare parts
88637000014	RAIN FLAP (REAR)	TATA spare parts
88637000015	MUD FLAP HINGE ASSY RH	TATA spare parts
88637000016	PIPE FRAME ASSY RH	TATA spare parts
88637000017	REAR RAIN FLAP RH	TATA spare parts
88637000018	BODY OF 16CUM. WITHOUT HYDRAULIC	TATA spare parts
88637000019	LOAD BODY COMPLETE	TATA spare parts
88637000020	LOAD BODY ASSY	TATA spare parts
88637000021	LOAD BODY	TATA spare parts
88637000022	ASSY LOAD BODY COMPLETE	TATA spare parts
88637000023	REFLECTOR AMBER	TATA spare parts
88637000024	U BOLT	TATA spare parts
88637000025	PLATE	TATA spare parts
88637000026	SPACER	TATA spare parts
88637000027	MUDSUPRESSAR	TATA spare parts
88637000028	REFLECTIVE TAPE RED 50 MM WIDTH	TATA spare parts
88637000029	REFLECTIVE TAPE YELLOW 50 MM WIDTH	TATA spare parts
88637000030	REAR MARKING PLATE	TATA spare parts
88637000031	J HOOK	TATA spare parts
88637000032	BALLATA10 MM THK	TATA spare parts
88637000033	ASSY RUBBER STOPER	TATA spare parts
88637000034	HANDLE LH (GREEN PASSI)	TATA spare parts
88637000035	HANDLE RH (GREEN PASSI)	TATA spare parts
88637000036	ASSY HINGE	TATA spare parts
88637000037	P.V.C.CAP (HANDLE)	TATA spare parts
88637000038	TAIL PANEL ASSY	TATA spare parts
88637000040	RAIN FLAP (4 NOS)	TATA spare parts
88637000041	COMPLETE LOAD BODY	TATA spare parts
88637000042	TAIL GATE ASSEMBLY	TATA spare parts
88637000043	U BOLTS (8 NOS)	TATA spare parts
88637000044	HANDLE (4 NOS)	TATA spare parts
88637000045	HINGE (6 NOS)	TATA spare parts
88637000047	RAIN FLAP (4 NOS)	TATA spare parts
88637000048	COMPLETE LOAD BODY	TATA spare parts
88637000049	TAIL GATE ASSEMBLY	TATA spare parts
88637000050	U BOLTS (8 NOS)	TATA spare parts
88637000051	HANDLE (4 NOS)	TATA spare parts
88637000052	HINGE (6 NOS)	TATA spare parts
88637000053	COMPLETE LOAD BODY	TATA spare parts
88637000054	TAIL GATE ASSEMBLY	TATA spare parts
88637000055	U BOLTS	TATA spare parts
88637000056	HANDLE	TATA spare parts

886370000057	HINGE	TATA spare parts
886370000061	SIDE PANEL ¿LPT809EX2/38	TATA spare parts
886370000062	COMPLETE LOAD BODY	TATA spare parts
886370000063	ASSEMBLY TAIL GATE	TATA spare parts
886370000064	MUDGUARD FR	TATA spare parts
886370000065	MUDGUARD RR	TATA spare parts
886370000066	SIDE ASSEMBLY	TATA spare parts
886370000067	FRONT ASSEMBLY	TATA spare parts
886370000068	TAIL DOOR ASSEMBLY	TATA spare parts
886370000069	BODY MOUNTING BRACKET	TATA spare parts
886370000070	BALATA PACKING	TATA spare parts
886370000071	MUD FLAP (SPRAY SUPPRESSION)	TATA spare parts
886370000072	ASSY.TAIL GATE	TATA spare parts
886370000073	COMPLETE BODY	TATA spare parts
886370000074	FLOOR TATA LOAD BODY	TATA spare parts
886370000075	SIDE ASSEMBLY LH	TATA spare parts
886370000076	SIDE ASSEMBLY RH	TATA spare parts
886370000077	FRONT ASSEMBLY	TATA spare parts
886370000078	TAIL DOOR ASSEMBLY	TATA spare parts
886370000079	MUD FLAP (SPRAY SUPPRESSION) LH	TATA spare parts
886370000080	MUD FLAP (SPRAY SUPPRESSION) RH	TATA spare parts
886370000081	HIGH DECK LOADBODY _LPT1613	TATA spare parts
886370000082	BALATA PACKING	TATA spare parts
886370000083	LOAD BODY ASSY	TATA spare parts
886370000084	U BOLT	TATA spare parts
886370000085	ASSY LOAD BODY(LD36) BS6	TATA spare parts
886370000086	LOAD BODY LPT 1109/42 BSIV	TATA spare parts
886370000087	1613 HDLB 20 FEET WITH STEEL FLOOR	TATA spare parts
886370000088	LOAD BODY CONTAINER ASSY	TATA spare parts
886370000089	14FT HD LOADBODY ON LPT407/38 BS3	TATA spare parts
886370000090	SUB FRAME WITH FASTENERS	TATA spare parts
886370000091	LOAD BODY/DSL B LPT 1518	TATA spare parts
886370000092	LOAD BODY ASSY	TATA spare parts
886370000093	LOAD BODY SIGNA 3718.T	TATA spare parts
886370000094	LOAD BODY 710 SFC BS6	TATA spare parts
886370000095	LOAD BODY ASSY BS6	TATA spare parts
886370000096	SIDE ASSEMBLY LH BS6	TATA spare parts
886370000097	SIDE ASSEMBLY RH BS6	TATA spare parts
886370000098	FRONT ASSEMBLY BS6	TATA spare parts
886370000099	TAIL DOOR ASSEMBLY BS6	TATA spare parts
886370000100	U BOLT L BS6	TATA spare parts
886370000101	TAIL GATE HINGE BS6	TATA spare parts
886370000102	MUDGUARD FRONT/REAR BS6	TATA spare parts
886370000103	ROPE HOOK BS6	TATA spare parts
886370000104	MUD FLAP BS6	TATA spare parts
886370000105	SIDE ASSEMBLY LH BS6	TATA spare parts
886370000106	SIDE ASSEMBLY RH BS6	TATA spare parts

886370000107	FRONT ASSEMBLY BS6	TATA spare parts
886370000108	TAIL DOOR ASSEMBLY BS6	TATA spare parts
886370000109	BODY MOUNTING BRACKET BS6	TATA spare parts
886370000110	SIDE VALANCE BS6	TATA spare parts
886370000111	MUDGUARD FRONT/REAR BS6	TATA spare parts
886370000112	CONTAINER ASSY	TATA spare parts
886370000113	MUD FLAP BS6	TATA spare parts
886370000114	U BOLT DIA16 X 385 BS6	TATA spare parts
886370000115	U BOLT DIA16 X 414 BS6	TATA spare parts
886370000116	TAILGATE	TATA spare parts
886370000117	LOAD BODY BS6	TATA spare parts
886370000118	ASSY FRONT PANEL	TATA spare parts
886370000119	ASSY SIDE WALL LH	TATA spare parts
886370000120	ASSY SIDE WALL RH	TATA spare parts
886370000121	ASSY TAIL PANEL	TATA spare parts
886370000122	DOOR LOCK OUT SIDE	TATA spare parts
886370000123	LOAD BODY BS6	TATA spare parts
886370000124	ASSY. LOAD BODY	TATA spare parts
886370000125	LOAD BODY BS6	TATA spare parts
886370000126	LOAD BODY ASSY BS6	TATA spare parts
886370000138	SIDE INDICATOR LAMP BS6	TATA spare parts
886370000140	RUBBER BUFFER BS6	TATA spare parts
886370000141	WIRING HARNESS ASSY. BS6	TATA spare parts
886370000142	MUDFLAP BS6	TATA spare parts
886370000143	FOG LAMP ROUND TYPE 24V BS6	TATA spare parts
886370000144	TOP MARKER LAMP BS6	TATA spare parts
886370000145	BALATA PACKAGING BS6	TATA spare parts
886370000146	LOAD BODY ASSLY PAINTED 10FT DSD BS6	TATA spare parts
886370000147	SIDE PANEL LH / RH -10FT DSD BS6	TATA spare parts
886370000148	17FT NSD COMPLETE LOAD BODY ASSY BS6	TATA spare parts
886370000149	14FT FSD LOAD BODY ASSLY PAINTED BS6	TATA spare parts
886370000150	20FT FSD LOAD BODY ASSLY PAINTED BS6	TATA spare parts
886370000151	20FT FSD LOAD BODY ASSLY PAINTED BS6	TATA spare parts
886370000152	20FT HIGH DECK LOAD BODY BS6	TATA spare parts
886370000153	RUBBER STOPPER BS6	TATA spare parts
886370000154	TAIL GATE HANDLE BS6	TATA spare parts
886370000155	SIDE INDICATOR BS6	TATA spare parts
886370000156	REAR REFLECTOR BS6	TATA spare parts
886370000157	TAIL GATE ASSY BS6	TATA spare parts
886370000158	SPRAY SUPPRESSION BS6	TATA spare parts
886370000159	U BOLT BS6	TATA spare parts
886370000160	U BOLT PLATE BS6	TATA spare parts
886370000161	U BOLT GUIDE BS6	TATA spare parts
886370000162	FRONT TOGGLE CLAMP BS6	TATA spare parts
886370000163	HINGES ASSLY BS6	TATA spare parts
886370000164	ASSY CANVAS BS6	TATA spare parts
886370000165	MUDFLAP BS6	TATA spare parts

886370000166	COMPLETE LOAD BODY BS6	TATA spare parts
886370000167	SIDE PANEL LH BS6	TATA spare parts
886370000168	SIDE PANEL RH BS6	TATA spare parts
886370000169	TAIL PANEL ASSLY BS6	TATA spare parts
886370000170	YELLOW REFLECTIVE TAPE (12 MTR) BS6	TATA spare parts
886370000171	RED REFLECTIVE TAPE (2.2 MTR) BS6	TATA spare parts
886370000172	BED LINER-XENON FLAT BED LOAD BODY	TATA spare parts
886370000173	FLOOR ASSEMBLY BS6	TATA spare parts
886370000174	SIDE BOARD ASSEMBLY LH BS6	TATA spare parts
886370000175	SIDE BOARD ASSEMBLY RH BS6	TATA spare parts
886370000176	FRONT WALL ASSEMBLY BS6	TATA spare parts
886370000177	TAILDOOR ASSEMBLY BS6	TATA spare parts
886370000178	TOOL BOX ASSEMBLY BS6	TATA spare parts
886370000179	SUPER STRUCTURE BS6	TATA spare parts
886370000180	ATTACHMENT PLATE BS6	TATA spare parts
886370000181	ALUMINIUM CHEQUERED PLATE BS6	TATA spare parts
886370000182	U-BOLT ASSY BS6	TATA spare parts
886370000183	MUDFLAP BS6	TATA spare parts
886370000184	LOAD BODY ASSY BS6	TATA spare parts
886370000185	RUBBER BUFFER BS6	TATA spare parts
886370000186	BALATA PACKAGING BS6	TATA spare parts
886370000187	LOAD BODY	TATA spare parts
886370000188	LOAD BODY ASSEMBLY BS6	TATA spare parts
886370000189	LOAD BODY BS6	TATA spare parts
886370000190	SUBFRAME ASSY BS6	TATA spare parts
886370000191	ENGINE COVER BS6	TATA spare parts
886370000192	LEFT COVER ASSY BS6	TATA spare parts
886370000193	BRACKET SIDE MARKER LAMP BS6	TATA spare parts
886370000194	SIDE PANEL BS6	TATA spare parts
886370000195	TAIL PANEL BS6	TATA spare parts
886370000196	MUDGUARD BS6	TATA spare parts
886370000197	LOCK HANDLE BS6	TATA spare parts
886370000198	LOCK ROD BS6	TATA spare parts
886370000199	SIDE HINGE BS6	TATA spare parts
886370000200	HOOKS BS6	TATA spare parts
886370000201	LOAD BODY ASSY BS6	TATA spare parts
886370000202	MUDGAURD ASSY RH BS6	TATA spare parts
886370000203	LOAD BODY ASSY BS6	TATA spare parts
886370000204	LOAD BODY BS6	TATA spare parts
886370000205	WATER TANKER TFF LARGE MKVI	TATA spare parts
886370000206	DSD LOAD BODY ON LPT1512/42WB	TATA spare parts
886370000207	LOAD BODY WITH HYD KIT BS6	TATA spare parts
886370000208	LOAD BODY WITHOUT HYD KIT BS6	TATA spare parts
886370000209	LOAD BODY WITH HYD KIT	TATA spare parts
886370000210	LOAD BODY W/O HYD KIT	TATA spare parts
886370000211	16 CUM ROCK BODY TIPPER W/TIPPING KIT BS	TATA spare parts
886370000212	16 CUM ROCK BODY TIPPER WO/TIPPING KIT B	TATA spare parts



886370000213	ASSY DSD LOAD BODY ON LPT 1512/42W CUBBI	TATA spare parts
886370000214	ASSLY SIDE PANEL BS6	TATA spare parts
886370000215	ASSLY TAIL PANEL BS6	TATA spare parts
886370000216	U BOLT SHOE 100X50X40 BS6	TATA spare parts
886370000217	MIDDLE PILLAR ASSLY LH/RH BS6	TATA spare parts
886370000218	REAR G PILLER LH/RH ASSLY BS6	TATA spare parts
886370000219	SUBFRAME WITH MOUNTING ASSEMBLY BS6	TATA spare parts
886370000220	REAR HINGE BRACKET PLATE BS6	TATA spare parts
886370000221	REAR HINGE SHAFT BS6	TATA spare parts
886370000222	HOOK ASSEMBLY LH BS6	TATA spare parts
886370000223	PULLING PIPE ASSEMBLY BS6	TATA spare parts
886370000224	24 FT HSD ON SIGNA 3118 BS6	TATA spare parts
886370000225	SIDE FLAP BS6	TATA spare parts
886370000226	U BOLTS BS6	TATA spare parts
886370000227	ALUMINIUM SPACER BS6	TATA spare parts
886370000228	TAIL GATE HINGE BS6	TATA spare parts
886370000229	COMPLETE LOAD BODY BS6	TATA spare parts
886370000230	TAIL PANEL ASSLY BS6	TATA spare parts
886370000231	U BOLT BS6	TATA spare parts
886370000232	MTG. CLIT BS6	TATA spare parts
886370000233	MTG. CLIT BS6	TATA spare parts
886370000234	ALUMINIUM SPACER BS6	TATA spare parts
886370000235	REFLECTIVE TAPE YELLOW -1M BS6	TATA spare parts
886370000236	REFLECTIVE TAPE YELLOW 50 MM WIDTH 12 M	TATA spare parts
886370000237	J HOOK BS6	TATA spare parts
886370000238	BALLATA - 7M BS6	TATA spare parts
886370000239	ASSY RUBBER STOPER BS6	TATA spare parts
886370000240	HANDLE LH (GREEN PASSI) BS6	TATA spare parts
886370000241	HANDLE RH (GREEN PASSI) BS6	TATA spare parts
886370000242	ASSY HINGE BS6	TATA spare parts
886370000243	D HANDLE BS6	TATA spare parts
886370000244	TAIL PANEL ASSY BS6	TATA spare parts
886370000245	REAR MARKING PLATE BS6	TATA spare parts
886370000246	LOAD BODY BS6	TATA spare parts
886370000249	LOAD BODY ASSY BS6	TATA spare parts
886370000250	BALATA PACKING	TATA spare parts
886370000251	HSD LOAD BODY ASSY ON LPT 1815 BS6	TATA spare parts
886370000252	TAIL GATE ASSLY BS6	TATA spare parts
886370000253	MUDGUARD LH 783.2X723X1.20 BS6	TATA spare parts
886370000254	MUDGUARD RH 783.2X723X1.20 BS6	TATA spare parts
886370000255	MUDGUARD CENTRE 1285X761X1.20MM BS6	TATA spare parts
886370000256	P.V.C.CAP [HANDLE] BS6	TATA spare parts
886370000257	HANDLE LH/RH DIA16X143L [NGLB] BS6	TATA spare parts
886370000258	STAY ROD LH/RH 480X30X2.00 BS6	TATA spare parts
886370000259	BUSH(OVERHEAD BAR)OD15XID13X10L BS6	TATA spare parts
886370000260	REFLECTIVE TAPE 50 MM YELLOW 5.95 MTR BS	TATA spare parts
886370000261	REFLECTIVE TAPE 50 MM RED 1.04 MTR BS6	TATA spare parts

886370000262	M10 X30 BOLT BS6	TATA spare parts
886370000263	M12 X 50 BOLT BS6	TATA spare parts
886370000264	SPARE WHEEL MTG BKT BS6	TATA spare parts
886370000265	ATTACHMENT PLATE BS6	TATA spare parts
886370000266	GI TEE 2 INCH	TATA spare parts
886370000267	GI NIPPLE 2X70 BOTH SIDE THREAD	TATA spare parts
886370000268	GI NIPPLE 2X40 BOTH SIDE THREADED	TATA spare parts
886370000269	GI NIPPLE 150 X 50 NB BOTH SIDE THREAD	TATA spare parts
886370000270	GI PIPE 2X750 BOTH SIDE THREAD	TATA spare parts
886370000271	GI PIPE 2X300	TATA spare parts
886370000272	GI PIPE 2X1150	TATA spare parts
886370000273	GI PIPE 2X125	TATA spare parts
886370000274	GI PIPE 2X200	TATA spare parts
886370000275	MS SOCKET 2 1/2X2 INCH	TATA spare parts
886370000276	GI SOCKET 2 INCH	TATA spare parts
886370000277	CLAMP 210X35X3	TATA spare parts
886370000278	ANGLE 35X35X5 L1000(8 KL 1618 EXPORT)	TATA spare parts
886370000279	ANGLE 35X35X5 L650	TATA spare parts
886370000280	LOAD BODY BS6	TATA spare parts
886370000281	CUBED BODY ASSEMBLY-10 CUM ON TATA LPK 1	TATA spare parts
886370000282	LOAD BODY WITHOUT SUB FRAME & CYLINDER	TATA spare parts
886370000283	TAIL PANEL ASSY BS6	TATA spare parts
886370000284	TAIL GATE ASSY BS6-PH2	TATA spare parts
886370000285	LOAD BODY BS4	TATA spare parts
886372000001	LOCK HANDLE OUTER	TATA spare parts
886372000002	LOCK HANDLE INNER	TATA spare parts
886372000003	STRIKER PLATE	TATA spare parts
886372000004	LOCK ASSEMBLY INNER	TATA spare parts
886372000005	DOOR HANDLE COMPLETE ASSEMBLY	TATA spare parts
886372000006	DOOR LOCK REAR W/KEY	TATA spare parts
886372000007	¿24S_ DRIVER DOOR WINDOW	TATA spare parts
886372000008	EMERGENCY DOOR WINDOW	TATA spare parts
886372000009	PNEUMATIC JACK ASSEMBLY	TATA spare parts
886372000010	DOOR GLASS LH	TATA spare parts
886372000011	Door Pad RH	TATA spare parts
886372000012	Door Shell LH	TATA spare parts
886372000013	Door Pad LH	TATA spare parts
886372000014	DRIVER DOOR ASSY	TATA spare parts
886372000015	DOOR LOCK ASSY RH	TATA spare parts
886372000016	DOOR OPENING HINGE	TATA spare parts
886372000017	HINGE WITH HANDLE	TATA spare parts
886372000018	JK DOOR LOCK ASSY	TATA spare parts
886372000019	PARTITION DOOR HINGE	TATA spare parts
886372000020	PARTITION DOOR LOCK	TATA spare parts
886372000021	TOWER BOLT	TATA spare parts
886372000022	SCOOTER LOCK	TATA spare parts
886372000023	DRIVER DOOR COMPLETE¿¿¿¿¿¿¿¿¿¿	TATA spare parts

886372000024	DRIVER DOOR LOCK	TATA spare parts
886372000025	CO-DRIVER DOOR REAR SLIDING GLASS	TATA spare parts
886372000026	CO-DRIVER DOOR FRONT SLIDING GLASS	TATA spare parts
886372000027	CO-DRIVER SLIDING GLASS	TATA spare parts
886372000028	WINDOW FRAME FIX D.DOOR REAR	TATA spare parts
886372000029	WINDOW GLASS FIX D.DOOR REAR	TATA spare parts
886372000030	WINDOW FRAME D. DOOR	TATA spare parts
886372000031	WINDOW GLASS D. DOOR	TATA spare parts
886372000032	DOOR TRIMMING WITH DOOR LOCK COMP. ASSY	TATA spare parts
886372000033	DOOR TRIMMING WITH DOOR LOCK COMP. ASSY	TATA spare parts
886372000034	HINGE KIT	TATA spare parts
886372000035	EMERGENCY DOOR& WINDOW ASSY LP 1512/52	TATA spare parts
886372000036	DRIVER DOOR LOCK	TATA spare parts
886372000037	DRIVER DOOR SEALING	TATA spare parts
886372000038	DRIVER DOOR HINGES	TATA spare parts
886372000039	JK DOOR GLASS BEADING	TATA spare parts
886372000040	JK DOOR ROLLER ASSY	TATA spare parts
886372000041	HINGE PASSENGER DOOR	TATA spare parts
886372000042	HINGE WITH HANDLE FOR PASSENGER DOOR	TATA spare parts
886372000043	BRUSH	TATA spare parts
886372000044	PASSENGER DOOR LOCK	TATA spare parts
886372000045	AUTO DOOR OPERATED VALVE	TATA spare parts
886372000046	DOOR GLASS	TATA spare parts
886372000047	DOOR LOCK (HANDLE) WITHOUT KEY (6INCH X	TATA spare parts
886372000048	DOOR LOCK (HANDLE) WITH KEY (6INCH X 4IN	TATA spare parts
886372000049	DRIVER DOOR LOCK LH	TATA spare parts
886372000050	DRIVER DOOR LOCK RH	TATA spare parts
886372000051	LOCK HANDLE OLD METADOOR	TATA spare parts
886372000052	NON LOCKING HANDLE OLD M/DOOR	TATA spare parts
886372000053	DRIVER DOOR HINGES	TATA spare parts
886372000054	DRIVER DOOR HAND HOLD	TATA spare parts
886372000055	DRIVER DOOR GLASS	TATA spare parts
886372000056	DOOR HANDLE	TATA spare parts
886372000057	DOOR LOCK RH	TATA spare parts
886372000058	DOOR LOCK LH	TATA spare parts
886372000059	DRIVER DOOR HINGE LP 712/42 BSIII	TATA spare parts
886372000060	DRIVER DOOR HAND HOLD	TATA spare parts
886372000061	JK DOOR GLASS	TATA spare parts
886372000062	DRIVER WINDOW	TATA spare parts
886372000063	SEAT & BACK REST ASSLY [LPAT1628 4*4]	TATA spare parts
886372000064	DRIVER DOOR SHELL	TATA spare parts
886372000065	PVC CATCHER MALE/FEMALE	TATA spare parts
886372000066	DRIVER DOOR ASSLY	TATA spare parts
886372000067	DRIVER DOOR MTS LP 407 SKOOL	TATA spare parts
886372000068	PD RING WITH KEY BS6	TATA spare parts
886372000069	DOOR LOCK SET BS6	TATA spare parts
886372000070	DRIVER DOOR ASSY BS6	TATA spare parts

886372000071	DOOR HINGE BS6	TATA spare parts
886372000072	DOVETAIL BS6	TATA spare parts
886372000073	DOOR LOCK ASSY RH (RC LOCK) BS6	TATA spare parts
886372000074	EMERGENCY DOOR LOCK COVER - BS6	TATA spare parts
886372000075	E DOOR ASSY BS6	TATA spare parts
886372000076	DOOR RUBBER BEADING BS6	TATA spare parts
886372000077	JK DOOR ASSY COMPLETE BS6	TATA spare parts
886372000078	JK DOOR PIPE RUBBER 78 INCH BS6	TATA spare parts
886372000079	JK DOOR PRESS RUBBER 78 INCH BS6	TATA spare parts
886372000080	JK DOOR COLLER RUBBER 78 INCH BS6	TATA spare parts
886372000081	JK DOOR HINGE PLAIN BS6	TATA spare parts
886372000082	JK DOOR HINGE WITH HANDLE BS6	TATA spare parts
886372000083	DOOR LOCK SET	TATA spare parts
886372000084	DRIVER DOOR ASSY BS6	TATA spare parts
886372000085	EMERGENCY DOOR ASSY BS6	TATA spare parts
886372000086	JK DOOR BRUSH 12 INCH BS6	TATA spare parts
886372000087	JK DOOR MASTER LOCK BS6	TATA spare parts
886372000088	DOOR LOCK ASSY RH (GUCHHA) BS6	TATA spare parts
886372000089	DRIVER DOOR ASSY BS6	TATA spare parts
886372000090	DOOR LOCK ASSY LH (GUCHHA) BS6	TATA spare parts
886372000091	DRIVER DOOR ASSY BS6	TATA spare parts
886372000092	DOOR HINGE BS6	TATA spare parts
886372000093	DOVETAIL BS6	TATA spare parts
886372000094	ALU TOWER BOLT HEAVY DUTY - 12 INCH BS6	TATA spare parts
886372000095	REAR DOOR ASSY BS6	TATA spare parts
886372000096	DOOR HINGE BS6	TATA spare parts
886372000097	DOOR LOCK ASSY RH (GUCHHA) BS6	TATA spare parts
886372000098	C- HANDLE BS6	TATA spare parts
886372000099	MIDDLE DOOR ASSY BS6	TATA spare parts
886372000100	DOOR HINGE BS6	TATA spare parts
886372000101	DRIVER DOOR ASSY BS6	TATA spare parts
886372000102	EMERGENCY DOOR ASSY BS6	TATA spare parts
886372000103	DRIVER DOOR ASSY BS6	TATA spare parts
886372000104	DOOR LOCK SET BS6	TATA spare parts
886372000105	DRIVER DOOR ASSY BS6	TATA spare parts
886372000106	EMERGENCY DOOR ASSY BS6	TATA spare parts
886372000107	JK DOOR GLASS 267X1482 BS6	TATA spare parts
886372000108	DRIVER DOOR ASSY BS6	TATA spare parts
886372000109	EMERGENCY DOOR ASSY BS6	TATA spare parts
886372000110	TOILET DOOR ASSY BS6	TATA spare parts
886372000111	DRIVER DOOR ASSY BS6	TATA spare parts
886372000112	DRIVER DOOR ASSY(DOUBLE DOOR) BS6	TATA spare parts
886372000113	DRIVER DOOR ASSY(DOUBLE DOOR) BS6	TATA spare parts
886372000114	REAR GLASS RUBBER MOULDED 1613/52 BS6	TATA spare parts
886372000115	JK DOOR GLASS BEADING BS6	TATA spare parts
886372000116	DRIVER DOOR ASSY BS6	TATA spare parts
886372000117	CODRIVER DOOR ASSY BS6	TATA spare parts

886372000118	REAR DOOR ASSY BS6	TATA spare parts
886372000119	DOOR LOCK ASSY RH (GUCHHA) BS6	TATA spare parts
886372000120	C- HANDLE BS6	TATA spare parts
886372000121	MIDDLE DOOR ASSY BS6	TATA spare parts
886372000122	DRIVER DOOR ASSY BS6	TATA spare parts
886372000123	EMERGENCY DOOR ASSY BS6	TATA spare parts
886372000124	DIDDY LOCK SET BS6	TATA spare parts
886372000125	DRIVER DOOR ASSY BS6	TATA spare parts
886372000126	DRIVER DOOR ASSY BS6	TATA spare parts
886372000127	EMERGENCY DOOR ASSY	TATA spare parts
886372000128	DRIVER DOOR ASSY BS6	TATA spare parts
886372000129	DRIVER DOOR ASSY(DOUBLE DOOR) BS6	TATA spare parts
886372000130	DRIVER DOOR ASSY(DOUBLE DOOR) BS6	TATA spare parts
886372000131	DRIVER DOOR ASSY	TATA spare parts
886372000132	EMERGENCY DOOR ASSY	TATA spare parts
886372000133	DRIVER DOOR ASSY BS6	TATA spare parts
886372000134	DRIVER DOOR ASSY(DOUBLE DOOR) BS6	TATA spare parts
886372000135	REAR FLAP/DOOR ASSY BS6	TATA spare parts
886372000136	DOOR LOCK SET BS6	TATA spare parts
886372000137	DRIVER DOOR ASSY BS6	TATA spare parts
886372000138	DOOR LOCK SET(RT) BS6	TATA spare parts
886372000139	DRIVER DOOR ASSY BS6	TATA spare parts
886372000140	DOOR HINGE BS6	TATA spare parts
886372000141	DOVETAIL BS6	TATA spare parts
886372000142	DOOR LOCK SET(LT) BS6	TATA spare parts
886372000143	DRIVER DOOR ASSY(DOUBLE DOOR) BS6	TATA spare parts
886372000144	DOOR HINGE BS6	TATA spare parts
886372000145	DOVETAIL BS6	TATA spare parts
886372000146	REAR FLAP-DOOR ASSY BS6	TATA spare parts
886372000147	MS TOWER LOCK 4INCH BS6	TATA spare parts
886372000148	WINDOW	TATA spare parts
886372810001	DRIVER DOOR WINDOW	TATA spare parts
886372810002	DRIVER DOOR WINDOW STRAIGHT GLASS	TATA spare parts
886372810003	DRIVER DOOR WINDOW TAPER GLASS	TATA spare parts
886372960001	EMG LOCK COMPL.	TATA spare parts
886372960002	STOPPER/LOCK EMG DOOR	TATA spare parts
886372960003	COVER COMPL/LOCK EMG DOOR	TATA spare parts
886372960004	EMERGENCY DOOR ASSY.	TATA spare parts
886372960005	DRIVER'S DOOR ASSY	TATA spare parts
886372960006	HINGE ASSY. PASS. DOOR	TATA spare parts
886372960007	HINGE ASSY. PASS. DOOR	TATA spare parts
886372960008	ENTRANCE DOOR ASSY.	TATA spare parts
886372960009	HANDLE WITH KEY PASS. DOOR	TATA spare parts
886372960010	HEAVY DUTY PASS. DOOR LOCK ASSY	TATA spare parts
886372960011	IN SWING PASSENGER DOOR	TATA spare parts
886372960012	PEEP GLASS - DRIVER DOOR	TATA spare parts
886372960013	DRIVER DOOR ASSY	TATA spare parts

886372960014	EMERGENCY DOOR ASSY.	TATA spare parts
886372960015	WEATHER STRIP(L=2140)	TATA spare parts
886372960016	DOOR HINGE WITH HANDLE	TATA spare parts
886372960017	DRIVER'S DOOR ASSEMBLY	TATA spare parts
886372960018	EMERGENCY DOOR ASSEMBLY	TATA spare parts
886372960019	PASSENGER DOOR ASSEMBLY	TATA spare parts
886372960020	PASSENGER DOOR LOCK(EXPORT-6HD)	TATA spare parts
886372960021	EMERGENCY DOOR ASSEMBLY	TATA spare parts
886372960022	AIR CYLINDER	TATA spare parts
886372960023	EMERGENCY DOOR ASSEMBLY	TATA spare parts
886372960024	DOOR ASSEMBLY/B.R.	TATA spare parts
886372960025	DRIVER DOOR ASSY	TATA spare parts
886372960026	PASS DOOR ASSY COMPLETE	TATA spare parts
886372960027	DRIVER'S DOOR ASSEMBLY	TATA spare parts
886372960028	EMERGENCY DOOR ASSEMBLY	TATA spare parts
886372960029	PASSENGER DOOR ASSEMBLY	TATA spare parts
886372960030	DRIVER DOOR WINDOW SWITCH	TATA spare parts
886372960031	EMERGENCY DOOR ASSY	TATA spare parts
886372960032	PVC TRIM (4.915 MTR/BUS)	TATA spare parts
886372960033	DRIVER DOOR ASSY COMPLETE	TATA spare parts
886372960034	DRIVER DOOR ASSEMBLY	TATA spare parts
886372960035	DOOR HANDLE WITH KEY-RH	TATA spare parts
886372960036	PASSENGER DOOR ASSY. COMPLETE	TATA spare parts
886372960037	PASSENGER DOOR ASSEMBLY	TATA spare parts
886372960038	DRIVERS SIDE PEEP GLASS	TATA spare parts
886372960039	DRIVER'S DOOR ASSEMBLY	TATA spare parts
886372960040	EMERGENCY DOOR ASSEMBLY	TATA spare parts
886372960041	PASSENGER DOOR ASSMEBLY	TATA spare parts
886372960042	HINGE ASSEMBLY WITH HANDLE	TATA spare parts
886372960043	HINGE ASSEMBLY W/OUT HANDLE	TATA spare parts
886372960044	PASSENGER DOOR GLASS FIX	TATA spare parts
886372960045	PASSENGER DOOR GLASS - FIX	TATA spare parts
886372960046	PASSENGER DOOR GLASS/REAR DOOR	TATA spare parts
886372960047	PASSENGER DOOR GLASS/FRONT DOOR	TATA spare parts
886372960048	PASSENGER DOOR GLASS/FRONT DOOR	TATA spare parts
886372960049	FRONT PASS. DOOR GLASS	TATA spare parts
886372960050	FRONT PASS. DOOR GLASS (RECTANGULAR)	TATA spare parts
886372960051	REAR PASS. DOOR GLASS	TATA spare parts
886372960052	FRONT PASS. DOOR GLASS/REAR SIDE-TOP & B	TATA spare parts
886372960053	FRONT PASS. DOOR GLASS/FRONT SIDE -TOP R	TATA spare parts
886372960054	FRONT PASS. DOOR GLASS/FRONT SIDE -BOTTO	TATA spare parts
886372960055	FABRICATED DRIVER DOOR LH	TATA spare parts
886372960056	B.R.T DOOR ROTATING CYLINDER	TATA spare parts
886372960057	6 DIA CONNECTOR	TATA spare parts
886372960058	DRIVER DOOR ASSY	TATA spare parts
886372960059	PASS. DOOR ASSY. COMPLETE	TATA spare parts
886372960060	WEATHER STRIP	TATA spare parts

886372960061	MOULDED WEATHER STRIP	TATA spare parts
886372960062	MOULDED WEATHER STRIP	TATA spare parts
886372960063	PASSENGER DOOR GLASS	TATA spare parts
886372960064	PASSENGER DOOR GLASS	TATA spare parts
886372960065	PASS. DOOR ASSY. COMPLETE	TATA spare parts
886372960066	MOULDED WEATHER STRIP	TATA spare parts
886372960067	FRONT PASS. DOOR GLASS	TATA spare parts
886372960068	DRIVER DOOR ASSY	TATA spare parts
886372960069	PASS. DOOR ASSY. COMPLETE	TATA spare parts
886372960070	MOULDED WEATHER STRIP	TATA spare parts
886372960071	WEATHER STRIP	TATA spare parts
886372960072	WEATHER STRIP(ENTRANCE DOOR GLASS)	TATA spare parts
886372960073	PASSENGER DOOR GLASS	TATA spare parts
886372960074	P.DOOR GLASS (288X1795X5 THK)-CLEAR	TATA spare parts
886372960075	P.DOOR GLASS (268X1795X5 THK)-CLEAR	TATA spare parts
886372960076	DRIVER DOOR ASSY	TATA spare parts
886372960077	HINGE ASSY -TOP	TATA spare parts
886372960078	HINGE ASSY -BOTTOM	TATA spare parts
886372960079	EMERGENCY DOOR ASSEMBLY	TATA spare parts
886372960080	HINGE ASSY-EMERGENCY DOOR	TATA spare parts
886372960081	COVER	TATA spare parts
886372960082	LOCK COVER	TATA spare parts
886372960083	INNER HANDLE	TATA spare parts
886372960084	ACRALIC COVER	TATA spare parts
886372960085	PASSENGER DOOR ASSEMBLY	TATA spare parts
886372960086	WEATHER STRIP (PASS DOOR GLASS)	TATA spare parts
886372960087	BEARING CASE-LOWER	TATA spare parts
886372960088	DOOR ASSY. / S.T.	TATA spare parts
886372960089	FLAP ASSEMBLY	TATA spare parts
886372960090	DOOR PUSH SWITCH	TATA spare parts
886372960091	REAR FLAP PANEL	TATA spare parts
886372960092	DRIVER DOOR ASSEMBLY	TATA spare parts
886372960093	EMERGENCY DOOR ASSEMBLY	TATA spare parts
886372960094	PASSENGER DOOR ASSEMBLY	TATA spare parts
886372960095	DRIVER DOOR WINDOW	TATA spare parts
886372960096	REAR FLAP ASSEMBLY	TATA spare parts
886372960097	HINGE ASSY(PASS DOOR-WITH HANDLE) (PC)	TATA spare parts
886372960098	DOOR ASSY. / B.B.	TATA spare parts
886372960099	DOOR ASSY/S.T	TATA spare parts
886372960100	REAR FLAP ASSEMBLY	TATA spare parts
886372960101	PASSENGER DOOR ASSEMBLY	TATA spare parts
886372960102	HINGE ASSY (WITH HANDLE)	TATA spare parts
886372960103	HINGE ASSY (WITHOUT HANDLE)	TATA spare parts
886372960104	KNOB 50 MM	TATA spare parts
886372960105	DRIVER DOOR ASSY.	TATA spare parts
886372960106	EMERGENCY DOOR ASSEMBLY	TATA spare parts
886372960107	EMERGENCY LOCK ASSEMBLY	TATA spare parts

886372960108	PASS.DOOR ASSY	TATA spare parts
886372960109	HINGE ASSY PASS.DOOR	TATA spare parts
886372960110	HINGE COVER	TATA spare parts
886372960111	PASS DOOR LOCK	TATA spare parts
886372960112	PASSENGER DOOR ASSEMBLY	TATA spare parts
886372960113	GLASS (265X1799X5 THK)	TATA spare parts
886372960114	PASSENGER DOOR ASSEMBLY TOWARDS FRONT	TATA spare parts
886372960115	PASSENGER DOOR ASSEMBLY TOWARDS REAR	TATA spare parts
886372960116	HINGE ASSY (WITHOUT HANDLE)	TATA spare parts
886372960117	WEAT.STRIP (PASS.DR-MDL-SMALL D)	TATA spare parts
886372960118	WEATHER STRIP (PASS DOOR GLASS)	TATA spare parts
886372960119	GLASS (265X1799X5 THK)	TATA spare parts
886372960120	HINGE ASSY (WITH HANDLE)	TATA spare parts
886372960121	PASSENGER DOOR ASSEMBLY	TATA spare parts
886372960122	GLASS TINTED (268X810X5 THK)	TATA spare parts
886372960123	DRIVER DOOR ASSY	TATA spare parts
886372960124	BEARING	TATA spare parts
886372960125	WEDGE STRIP	TATA spare parts
886372960126	PASSENGER DOOR ASSEMBLY	TATA spare parts
886372960127	PNUEMATIC SYSTEM OF 1350 MM DOOR	TATA spare parts
886372960128	PNUEMATIC. SYSTEM OF 920 MM DOOR	TATA spare parts
886372960129	PASSENGER DOOR ASSEMBLY-FRONT	TATA spare parts
886372960130	PASSENGER DOOR ASSMEBLY	TATA spare parts
886372960131	MOULDED WEATHER STRIP	TATA spare parts
886372960132	GLASS TINTED (323X810X5 THK) DARK GREY 8	TATA spare parts
886372960133	MOULDED WEATHER STRIP	TATA spare parts
886372960134	MOULDED WEATHER STRIP	TATA spare parts
886372960135	GLASS TINTED (303X810X5 THK) DARK GREY 8	TATA spare parts
886372960136	GLASS TINTED (303X810X5 THK) DARK GREY 8	TATA spare parts
886372960137	PASSENGER DOOR ASSMEBLY	TATA spare parts
886372960138	MOULDED WEATHER STRIP	TATA spare parts
886372960139	GLASS TINTED (285X856X5 THK) DARK GREY 8	TATA spare parts
886372960140	EMERGENCY DOOR ASSEMBLY	TATA spare parts
886372960141	PASS. DOOR GLASS	TATA spare parts
886372960142	DRIVER DOOR ASSY.	TATA spare parts
886372960143	EMERGENCY DOOR ASSY	TATA spare parts
886372960144	PASSENGER DOOR ASSEMBLY	TATA spare parts
886372960145	WEATHER STRIP	TATA spare parts
886372960146	MOULDER WEATHER STRIP	TATA spare parts
886372960147	THROUGH SOCKET-VERTICAL POSITION (PC)	TATA spare parts
886372960148	END SOCKET FOR VERTICAL POSITION (PC)	TATA spare parts
886372960149	PNUEMATIC SYSTEM TWO DOOR 920MM WIDTH	TATA spare parts
886372960150	FRP COVER ASSY - FRONT	TATA spare parts
886372960151	FRP COVER ASSY - REAR	TATA spare parts
886372960152	DRIVERS DOOR ASSEMBLY	TATA spare parts
886372960153	EMERGENCY DOOR ASSEMBLY	TATA spare parts
886372960154	PASSENGER DOOR ASSEMBLY	TATA spare parts



886372960155	MOULDED WEATHER STRIP	TATA spare parts
886372960156	GLASS CLEAR (301X782X5 THK)	TATA spare parts
886372960157	GLASS CLEAR(281X782X5 THK)	TATA spare parts
886372960158	MOULDED WEATHER STRIP	TATA spare parts
886372960159	MOULDED WEATHER STRIP	TATA spare parts
886372960160	GLASS CLEAR(281X782X5 THK)	TATA spare parts
886372960161	DRIVER DOOR ASSEMBLY	TATA spare parts
886372960162	EMERGENCY DOOR ASSEMBLY	TATA spare parts
886372960163	LOCK ASSEMBLY-EMERGENCY DOOR	TATA spare parts
886372960164	PASSENGER DOOR ASSEMBLY-TOWARDS FRONT	TATA spare parts
886372960165	GLASS (210X1665X5 THK)	TATA spare parts
886372960166	PASS. DOOR ASSEMBLY-TOWARDS REAR	TATA spare parts
886372960167	FRP COVER ASSEMBLY/FRONT PASS. DOOR	TATA spare parts
886372960168	FRP COVER ASSEMBLY/W.B. PASS. DOOR	TATA spare parts
886372960169	PRESSURE DIFFERENTIAL VALVE FT DOOR	TATA spare parts
886372960170	MTG PLATE ASSEMBLY FOR JK	TATA spare parts
886372960171	DOOR REAR	TATA spare parts
886372960172	MTG PLATE ASSEMBLY FOR JK DOOR FRONT	TATA spare parts
886372960173	ROLLER MOUNTING SHAFT	TATA spare parts
886372960174	SPLINE SHAFT	TATA spare parts
886372960175	ROLLER MOUNTING SHAFT BASE	TATA spare parts
886372960176	MOUNTING PLATE FOR BOTTOM	TATA spare parts
886372960177	FULCRUM PIN	TATA spare parts
886372960178	SPHERICAL BEARING	TATA spare parts
886372960179	DOOR CLOSING CYLINDER 63/100	TATA spare parts
886372960180	DOOR CLOSING CYLINDER 50/100	TATA spare parts
886372960181	SOLENOID VALVE - 24VDC	TATA spare parts
886372960182	(BEEPER) 24V DC	TATA spare parts
886372960183	EMERGENCY VALVE ASS. PLASTIC	TATA spare parts
886372960184	EMERGENCY VALVE ASS. METAL	TATA spare parts
886372960185	CONTROLLER-FRONT & REAR	TATA spare parts
886372960186	SOLENOID VALVE	TATA spare parts
886372960187	SOLENOID VALVE RESET VALVE	TATA spare parts
886372960188	PRESSURE SWITCH	TATA spare parts
886372960189	SUPPORT PLATE FOR DOOR MTG 0- RH	TATA spare parts
886372960190	SUPPORT PLATE FOR DOOR MTG 0- LH	TATA spare parts
886372960191	SLOW START VALVE 1/4IN BSP	TATA spare parts
886372960192	QUICK EXHAUST VALVE 2G	TATA spare parts
886372960193	FITTING TEE TUBE 8/6	TATA spare parts
886372960194	BUSH1 FOR SPLINE SHAFT	TATA spare parts
886372960195	BUSH2 FOR SPLINE SHAFT	TATA spare parts
886372960196	PIN FOR LINKAGE	TATA spare parts
886372960197	LINKAGE FOR BUS DOOR ASSLY	TATA spare parts
886372960198	BEARING	TATA spare parts
886372960199	FITTING TEE MALE	TATA spare parts
886372960200	FITTING ELBOW MALE	TATA spare parts
886372960201	FITTING ELBOW MALE	TATA spare parts

886372960202	FITTING TEE MALE	TATA spare parts
886372960203	FITTING TEE TUBE8/6	TATA spare parts
886372960204	FITTING STRAIGHT FEMALE	TATA spare parts
886372960205	FITTING STRAIGHT FEMALE	TATA spare parts
886372960206	REED SWITCH MODEL	TATA spare parts
886372960207	AIR FLOW REGULATOR 1/4IN	TATA spare parts
886372960208	BALL AND SOCKET JOINT CYL	TATA spare parts
886372960209	REAR HINGE CYL	TATA spare parts
886372960210	FLOW REGULATOR	TATA spare parts
886372960211	FITTING STRAIGHT MALE	TATA spare parts
886372960212	SEAL KIT OR CYL DIA 63	TATA spare parts
886372960213	SEAL KIT OR CYL DIA 50	TATA spare parts
886372960214	ROLLER GUIDE	TATA spare parts
886372960215	STEEL BUSH/REAR BRACKET BUSH ASSY	TATA spare parts
886372960216	DOOR ARM STOPPER	TATA spare parts
886372960217	NYLON BEARING	TATA spare parts
886372960218	SEAL 63MM DIA	TATA spare parts
886372960219	LINK BALL M12	TATA spare parts
886372960220	TOP SEALING BRUSH WITH 50MM BRUSH L=1267	TATA spare parts
886372960221	TOP SEALING BRUSH WITH 50MM BRUSH L=505	TATA spare parts
886372960222	BOTTOM BEARING ROLLER	TATA spare parts
886372960223	DUST SEAL(EMG.DR/U-FLG (L=10MTR)	TATA spare parts
886372960224	ROUNDED BLACK ROLLER GUIDE	TATA spare parts
886373000001	SIDE BODY LOCK ASSY.	TATA spare parts
886373000002	REAR DOOR HINGE & LOCK ASSY	TATA spare parts
886373000003	FORGING HINGE REAR DOOR	TATA spare parts
886373000004	FIXED WINDOW GLASS (MODIFIED) LH	TATA spare parts
886373000005	FIXED WINDOW GLASS (MODIFIED) RH	TATA spare parts
886373960001	SEAT ASSY	TATA spare parts
886373960002	ENTRANCE DOOR ASSY	TATA spare parts
886374960001	PASS. DOOR ASSY. COMPLETE	TATA spare parts
886374960002	PASS. DOOR ASSY. COMPLETE	TATA spare parts
886375810001	REAR LUGGAGE DOOR COMPLETE	TATA spare parts
886375960001	BATTERY BOX PANEL COMPLETE	TATA spare parts
886375960002	REAR FLAP ASSEMBLY	TATA spare parts
886375960003	HINGE ASSEMBLY	TATA spare parts
886375960004	FLAP DOOR ASSEMBLY / B.R	TATA spare parts
886375960005	FLAP DOOR ASSEMBLY / B.B	TATA spare parts
886375960006	FLAP DOOR ASSEMBLY /ST	TATA spare parts
886375960007	REAR FLAP PANEL ASSEMBLY	TATA spare parts
886375960008	HINGE ASSY.	TATA spare parts
886375960009	REAR INSPECTION DOOR / LH	TATA spare parts
886380000001	ENGINE HOOD FRP 407 SKOOL BUS	TATA spare parts
886380000002	PODEST FRP 407 SKOOL BUS	TATA spare parts
886380000003	MICROSWITCH BZ-2RQ1-D6	TATA spare parts
886380000004	3RT20262BB40	TATA spare parts
886380000005	3RT20282BB40	TATA spare parts

88638000006	3RU21261KC0	TATA spare parts
88638000007	3RU2126 4NCO	TATA spare parts
88638000008	LV HARNESS 3PH DISTRIBUTION BOX	TATA spare parts
88638000009	HV HARNESS 3PH DISTRIBUTION BOX	TATA spare parts
88638000010	W/H 97B-4100R-20-22S	TATA spare parts
88638000011	W/H 97B-4100R-20-18S	TATA spare parts
88638000012	97B-25043-20D	TATA spare parts
88638000013	EV200AAANA CONT. WITH CONNECTOR	TATA spare parts
88638000014	170M4813_BUSSMAN FUSE	TATA spare parts
88638000015	FUSE-30A BUSSMAN	TATA spare parts
88638000016	FUSE FWP-100B BUSSMAN	TATA spare parts
88638000017	PT100 RTD WITH CONNECTOR	TATA spare parts
88638000018	LV HARNESS DC JB	TATA spare parts
88638000019	BOC NSTD TB ASSY TML FS112_110294748	TATA spare parts
88638000020	B-BOX RELAY CONTACT ACE EV	TATA spare parts
886381000001	MUDGUARD FRP	TATA spare parts
886381000002	ASSY. REAR MUD FLAP WITH FRAME	TATA spare parts
886381000003	REAR DUST COVER LH	TATA spare parts
886381000004	REAR DUST COVER RH	TATA spare parts
886381000005	Mudguard	TATA spare parts
886381000006	Tarpaulin	TATA spare parts
886381000007	TARPAULINç WITH NYLON ROPE	TATA spare parts
886381000008	SUNVISOR	TATA spare parts
886381000009	Inner saloon Mirror	TATA spare parts
886381000010	REAR VIEW MIRROR LH.WITH HANDLE	TATA spare parts
886381000011	REAR VIEW MIRROR	TATA spare parts
886381000012	SUNVISOR FLAP TYPE RH	TATA spare parts
886381000013	WIDE ANGLE MIRROR	TATA spare parts
886381000014	REGISTRATION PLATE FRONT	TATA spare parts
886381000015	REAR VIEW MIRROR BKT	TATA spare parts
886381000016	REGISTRATION PLATE - REAR	TATA spare parts
886381000017	PVC HANDLE	TATA spare parts
886381000018	EMERGENCY STICKER	TATA spare parts
886381000019	EMERGENCY GLASS BREAKING HAMMER W/H CO	TATA spare parts
886381000020	SCOOTER LOCK	TATA spare parts
886381000021	MUD FLAP	TATA spare parts
886381000022	DRIVER DOOR FOOT STEP	TATA spare parts
886381000023	FIRST AID BOX	TATA spare parts
886381000024	FIRE EXTINGUISHER (1KG)	TATA spare parts
886381000025	STEP WALL PARTITION	TATA spare parts
886381000026	RVM BRACKET SMALL (RVM-BKT-500)	TATA spare parts
886381000027	FRONT FLAP MTS	TATA spare parts
886381000028	STAND SUPPORT	TATA spare parts
886381000029	RUBBER BIDDING J TYPE	TATA spare parts
886381000030	CFL INTERNAL LIGHT 12V	TATA spare parts
886381000031	FRONT WINDOW GLASS	TATA spare parts
886381000032	GLASS RUBBER BEADING	TATA spare parts

886381000033	DOOR LOCK SET	TATA spare parts
886381000034	WIND DEFLECTOR	TATA spare parts
886381000035	FRONT WIRE MESH LP 1512/52	TATA spare parts
886381000036	RETRO REFLECTIVE TAPE YELLOW	TATA spare parts
886381000037	FUEL FLAP COVER LOCK	TATA spare parts
886381000038	EMERGENCY DOOR HANDLE KIT	TATA spare parts
886381000039	REAR VIEW MIRROR	TATA spare parts
886381000040	CATCHER	TATA spare parts
886381000041	DOOR HANDLE	TATA spare parts
886381000042	MUDFLAP	TATA spare parts
886381000043	DOOR OPERATING LEVER	TATA spare parts
886381000044	FUEL FLAP	TATA spare parts
886381000045	DUSTBIN	TATA spare parts
886381000046	IV BOTTLE HOOK	TATA spare parts
886381000047	SLIDING WINDOW	TATA spare parts
886381000048	SPARE WHEEL LID ASSY.	TATA spare parts
886381000049	FUEL TANK LID ASSY.	TATA spare parts
886381000050	FRESH WATER TANK	TATA spare parts
886381000051	CABIN MIRROR	TATA spare parts
886381000052	PVC END FOR RUBRAIL BEADING	TATA spare parts
886381000053	DIESEL TANK FLAP (FUEL LID)	TATA spare parts
886381000054	PRIMERLESS WINDSCREEN ADHESIVE	TATA spare parts
886381000055	NON-WOVEN LINT FREE WIPES	TATA spare parts
886381000056	MUDGUARD ASSEMBLY (HINGED TYPE)	TATA spare parts
886381000057	FRONT FACE	TATA spare parts
886381000058	TAIL LAMP GUARD ASSY LH	TATA spare parts
886381000059	TAIL LAMP GUARD ASSY RH	TATA spare parts
886381000060	REAR INNER VIEW MIRROR	TATA spare parts
886381000061	REAR VIEW MIRROR BRACKET PASSENGER SIDE	TATA spare parts
886381000062	MUD FLAP	TATA spare parts
886381000063	TOOL BOX HANDLE	TATA spare parts
886381000064	PVC HANDLE 12INCH	TATA spare parts
886381000065	CABIN FAN - 8INCH (REMI)	TATA spare parts
886381000066	MOBILE CHARGER (USB TYPE)	TATA spare parts
886381000067	GLOW PLUG ACE	TATA spare parts
886381000068	REAR FACE	TATA spare parts
886381000069	FIRE EXTINGUISHER	TATA spare parts
886381000070	SUN VISOR	TATA spare parts
886381000071	FIRST AID BOX	TATA spare parts
886381000072	SALOON MIRROR	TATA spare parts
886381000073	FAN	TATA spare parts
886381000074	OUTER HANDLE	TATA spare parts
886381000075	LOCK 1IN1	TATA spare parts
886381000076	HEIGHT MARKAR	TATA spare parts
886381000077	SWITCH INTERIOR	TATA spare parts
886381000080	FIRE EXTINGUISHER 2KG.	TATA spare parts
886381000081	L- DROOP	TATA spare parts

88638100082	FIRE EXTINGUISHER	TATA spare parts
88638100083	HIGHT MARKAR	TATA spare parts
88638100084	C TYPE HANDLE	TATA spare parts
88638100085	REAR BUMPER(RIGHT)	TATA spare parts
88638100086	REAR BUMPER(LEFT)	TATA spare parts
88638100087	FIRST AID BOX	TATA spare parts
88638100088	WIND DEFLACTOR	TATA spare parts
88638100089	REAR DOOR GRAB HANDLE	TATA spare parts
88638100090	STRETCHER	TATA spare parts
88638100091	HAND RAIL	TATA spare parts
88638100092	TAIL LAMP RING RED	TATA spare parts
88638100093	TAIL LAMP RING WHITE	TATA spare parts
88638100094	TAIL LAMP RING AMBER	TATA spare parts
88638100095	FILTER FLAP	TATA spare parts
88638100096	FIRE EXTINGUSHER(2KG) BS6	TATA spare parts
88638100097	SALOON MIRROR BS6	TATA spare parts
88638100098	SUNVISOR BS6	TATA spare parts
88638100099	FRONT INTERNAL DOME -MTS	TATA spare parts
88638100100	E.HOOD MTS	TATA spare parts
88638100101	BONNET (PODEST) MTS	TATA spare parts
88638100102	DRIVER DOOR COMPLETE WITHOUT WINDOW	TATA spare parts
88638100103	STRETCHER SAFETY BELT SATPUDA BS6	TATA spare parts
88638100104	SEALING PVC TAPE (19MM X 25M LEN) BS6	TATA spare parts
88638100105	ALUMINIUM RVM BRACKET SMALL BS6	TATA spare parts
88638100106	ALUMINIUM RVM BRACKET BIG BS6	TATA spare parts
88638100107	DRIVER DOOR STEP BS6	TATA spare parts
88638100108	EMERGENCY FOOT STEP BS6	TATA spare parts
88638100109	FUEL TANK FLAP BS6	TATA spare parts
88638100110	WHEEL ARC RUBBER BS6	TATA spare parts
88638100111	SPEAKER JALI 140MM BS6	TATA spare parts
88638100112	SALOON MIRROR BS6	TATA spare parts
88638100113	INSTRUMENT CLUSTER PLATE BS6	TATA spare parts
88638100114	GRAB PVC HANDLE BS6	TATA spare parts
88638100115	PVC HANDLE C TYPE 18 INCH BS6	TATA spare parts
88638100116	PARTITION ASSY (16X32X2MM)- JK DOOR BS6	TATA spare parts
88638100117	PARTITION ASSY (16X32X2MM)- DRIVER BS6	TATA spare parts
88638100118	ABC 4KG FIRE EXTINGUISHER WITH BKT BS6	TATA spare parts
88638100119	ABC 6KG FIRE EXTINGUISHER WITH BKT BS6	TATA spare parts
88638100120	FIRST AID BOX BS6	TATA spare parts
88638100121	PANIC SWITCH COVER BS6	TATA spare parts
88638100122	HATRACK BKT OPEN - CRPF BS6	TATA spare parts
88638100123	HATRACK BKT CLOSE - CRPF BS6	TATA spare parts
88638100124	GLASS BREAK HAMMER SMALL BS6	TATA spare parts
88638100125	ROOF GRAIB RAIL BRACKET BS6	TATA spare parts
88638100126	SERVICE COVER BS6	TATA spare parts
88638100127	MUD FLAP BS6	TATA spare parts
88638100128	ALU WINDOW GUARD RAIL BKT OPEN 3/4 BS6	TATA spare parts

886381000129	ALU WINDOW GUARD RAIL BKT CLOSE 3/4 BS6	TATA spare parts
886381000130	ROOF GRAIB RAIL HANDLE BS6	TATA spare parts
886381000131	FUEL FLAP STICKER BS6	TATA spare parts
886381000132	SPARE WHEEL STICKER BS6	TATA spare parts
886381000133	UREA TANK STICKER BS6	TATA spare parts
886381000134	BATTERY BOX STICKER BS6	TATA spare parts
886381000135	EMERGENCY EXIT STICKER BS6	TATA spare parts
886381000136	EMERGENCY EXIT STICKER SET BS6	TATA spare parts
886381000137	USE HAMMER STICKER BS6	TATA spare parts
886381000138	FIRE EXTN. STICKER 12X6 BS6	TATA spare parts
886381000139	RETRO REFLECTIVE TAPE YELLOW 983 - 50MM	TATA spare parts
886381000140	RETRO REFLECTIVE TAPE RED 983 - 50MM) PR	TATA spare parts
886381000141	RETRO REFLECTIVE TAPE WHITE 983 - 50MM P	TATA spare parts
886381000142	AIR FILTER FLAP STICKER BS6	TATA spare parts
886381000143	TATA STICKER BS6	TATA spare parts
886381000144	SCHOOL BUS STICKER(SMALL) BS6	TATA spare parts
886381000145	SCHOOL BUS STICKER(LARGE) BS6	TATA spare parts
886381000146	CYLINDER WITH ACTUATION VALUE BS6	TATA spare parts
886381000147	CYLINDER STAND BS6	TATA spare parts
886381000148	NOZZLE BS6	TATA spare parts
886381000149	HOSE - SS BRAIDED BS6	TATA spare parts
886381000150	SALOON MIRROR BS6	TATA spare parts
886381000164	1/2INCH STEEL REINFORCED HOSE STEEL REIN	TATA spare parts
886381000165	VALVE WITH PRESSURE GAUGE	TATA spare parts
886381000166	12L CYLINDER	TATA spare parts
886381000167	12L BRACKET	TATA spare parts
886381000168	PARTITION ASSY (16X32X2MM)- JK DOOR BS6	TATA spare parts
886381000169	PARTITION ASSY (16X32X2MM)- DRIVER BS6	TATA spare parts
886381000170	PADDED HATRACK ASSY RH BS6	TATA spare parts
886381000171	PADDED HATRACK ASSY LH BS6	TATA spare parts
886381000172	PVC HANDLE BS6	TATA spare parts
886381000173	PARTITION ASSY (16X32X2MM)- JK DOOR BS6	TATA spare parts
886381000174	PARTITION ASSY (16X32X2MM)- DRIVER BS6	TATA spare parts
886381000175	PADDED HATRACK ASSY RH BS6	TATA spare parts
886381000176	PADDED HATRACK ASSY LH BS6	TATA spare parts
886381000177	GLASS BREAK HAMMER SMALL BS6	TATA spare parts
886381000178	CATEGORY 6 MIRRO(UNDER VIEW MIRROR) BS6	TATA spare parts
886381000179	TOOL BOX STICKER BS6	TATA spare parts
886381000180	ORVM BARCKET BS6	TATA spare parts
886381000181	PADDED HATRACK ASSY RH BS6	TATA spare parts
886381000182	PADDED HATRACK ASSY LH BS6	TATA spare parts
886381000183	GLASS BREAK HAMMER BIG BS6	TATA spare parts
886381000184	LADDER BS6	TATA spare parts
886381000185	MONOGRAM TATA 1512 C BS6	TATA spare parts
886381000186	EXHAUST LIGHT STICKER BS6	TATA spare parts
886381000187	FRESH WATER FILLING INLET VALVE STICKER	TATA spare parts
886381000188	FRESH WATER STICKER BS6	TATA spare parts

886381000189	DRAIN TANK VALVE STICKER BS6	TATA spare parts
886381000190	DRAIN TANK CAUTION STICKER BS6	TATA spare parts
886381000191	SS HANDLE 5INCH ROUND TYPE BS6	TATA spare parts
886381000192	ESCAPE HATCH - AIS 153 BS6	TATA spare parts
886381000193	ENGINE HOOD BS6	TATA spare parts
886381000194	DIGITAL CLOCK BS6	TATA spare parts
886381000195	PARTITION ASSY (16X32X2MM)- JK DOOR BS6	TATA spare parts
886381000196	PARTITION ASSY (16X32X2MM)- DRIVER BS6	TATA spare parts
886381000197	PADDED HATRACK ASSY RH BS6	TATA spare parts
886381000198	PADDED HATRACK ASSY LH BS6	TATA spare parts
886381000199	PARTITION ASSY - JK DOOR	TATA spare parts
886381000200	PARTITION ASSY - DRIVER	TATA spare parts
886381000201	PADDED HATRACK ASSY RH	TATA spare parts
886381000202	PADDED HATRACK ASSY LH	TATA spare parts
886381000203	C HANDLE (INHOUSE) BS6	TATA spare parts
886381000204	LATHI STAND BS6	TATA spare parts
886381000205	PARTITION ASSY (16X32X2MM)- JK DOOR	TATA spare parts
886381000206	PARTITION ASSY (16X32X2MM)- DRIVER	TATA spare parts
886381000207	PADDED HATRACK ASSY RH	TATA spare parts
886381000208	PADDED HATRACK ASSY LH	TATA spare parts
886381000209	CO-DRIVER FOOT STEP BS6	TATA spare parts
886381000210	C HANDLE (INHOUSE) BS6	TATA spare parts
886381000211	LATHI STAND BS6	TATA spare parts
886381000212	PARTITION ASSY (16X32X2MM)- DRIVER BS6	TATA spare parts
886381000213	ENGINE HOOD BS6	TATA spare parts
886381000214	PARTITION ASSY- JK DOOR BS6	TATA spare parts
886381000215	PARTITION ASSY (16X32X2MM)- DRIVER BS6	TATA spare parts
886381000216	PADDED HATRACK ASSY RH BS6	TATA spare parts
886381000217	PADDED HATRACK ASSY LH BS6	TATA spare parts
886381000218	C HANDLE (INHOUSE) BS6	TATA spare parts
886381000219	LATHI STAND BS6	TATA spare parts
886381000220	TARPULINE SET BS6	TATA spare parts
886381800001	PIPE FRAME ASSEMBLY	TATA spare parts
886381800002	RAINFLAP REAR	TATA spare parts
886381800003	COMPLETE SEAL KIT	TATA spare parts
886381810001	FRONT GRILL LOCK SET	TATA spare parts
886381810002	PARTITION BEND PIPE	TATA spare parts
886381810003	RUBRAIL BEADING	TATA spare parts
886381810004	P.V.C BEADING END	TATA spare parts
886381960001	PIPE 32	TATA spare parts
886381960002	STANCHION PIPE ASSY	TATA spare parts
886381960003	PIPE MS	TATA spare parts
886381960004	PIPE MS	TATA spare parts
886381960005	PIPE MS	TATA spare parts
886381960006	PIPE COUPLER ASSY	TATA spare parts
886381960007	WHEEL ARCH BEADING(L=2300)	TATA spare parts
886381960008	MS PIPE(L=2500P)	TATA spare parts

886381960009	GRAB HANDLE-PASSENGER	TATA spare parts
886381960010	BEND PIPE DIA 32(017 129)	TATA spare parts
886381960011	GRAB RAIL BRACKET	TATA spare parts
886381960012	HAND STRAP WITH ADVERSTISEMENT PROV.	TATA spare parts
886381960013	PIPE 32/ERW	TATA spare parts
886381960014	PIPE 32/ERW	TATA spare parts
886381960015	DRIVER PARTION WINDOW ASSEMBLY	TATA spare parts
886381960016	DRIVER PARTION DOOR GLASS TINTED (785X44	TATA spare parts
886381960017	PIPE/ERW (32 DIA) (PC)	TATA spare parts
886381960018	BRACKET	TATA spare parts
886381960019	PIPE/ERW (32 DIA) (PC)	TATA spare parts
886381960020	RUBBER PAD	TATA spare parts
886381960021	PIPE/ERW (32 DIA) (PC)	TATA spare parts
886381960022	PIPE BRKT	TATA spare parts
886381960023	MIRROR ARM (CO-DRIVER)	TATA spare parts
886381960024	RUBBER PAD (70X48)(GREY)	TATA spare parts
886381960025	RUBBER PAD (32 DIA-TAPER)	TATA spare parts
886381960026	HUB COVER MOUNTING CAP	TATA spare parts
886381960027	FRIDGE CABLE	TATA spare parts
886381960028	STEREO PLATE	TATA spare parts
886381960029	DVD PLAYER ASSEMBLY	TATA spare parts
886381960030	WHEEL SIDE COVER -REAR END(DRIVER SIDE)	TATA spare parts
886381960031	WHEEL SIDE COVER -REAR END(PASSENGER SID	TATA spare parts
886381960032	GRILL HATRACK ASSEMBLY	TATA spare parts
886381960033	LH RVM ARM ASSEMBLY	TATA spare parts
886381960034	WHEEL ARCH BEADING(L=2300)	TATA spare parts
886381960035	STAR BUS STICKER (DECAL SET)	TATA spare parts
886381960036	STICKER (REDIAM)¿SIDE WALL LH RH(YELLOW	TATA spare parts
886381960037	FRONT CP FLAP METALLIC GRILL(6HD)	TATA spare parts
886381960038	BEND PIPE FOR SWING PARTITION (PC) (32 D	TATA spare parts
886381960039	BUS MIRROR TWIN	TATA spare parts
886381960040	ARM ASSEMBLY	TATA spare parts
886381960041	INSPECTION DOOR SKIRT PANEL	TATA spare parts
886381960042	ACGL STICKER	TATA spare parts
886381960043	TATA STICKER	TATA spare parts
886381960044	SCHOOL BUS STICKERING SET	TATA spare parts
886381960045	VENTURE AMBULANCE STICKER SET ALL SIDES	TATA spare parts
886381960046	RVM ARM ASSY.-LH	TATA spare parts
886381960047	RVM ASSY. -RH	TATA spare parts
886381960048	RVM ARM ASSY.-DRIVER DOOR	TATA spare parts
886381960049	RVM ASSY. -LH	TATA spare parts
886381960050	RVM ARM ASSY.-RH	TATA spare parts
886381960051	RVM ASSY. -DRIVER DOOR	TATA spare parts
886381960052	PARTITION / GLASS ASSEMBLY (P.C)	TATA spare parts
886381960053	PLASTIC PIPE BRACKET (32 DIA)	TATA spare parts
886381960054	ENGINE HOOD	TATA spare parts
886381960055	PODDEST	TATA spare parts



886381960056	HINGE ASSEMBLY	TATA spare parts
886381960057	GRAB HANDLE	TATA spare parts
886381960058	RUBBER BELLOW	TATA spare parts
886381960059	AUTOMATED FIRE SUPPRESSION SYSTEM	TATA spare parts
886381960060	DASHBOARD COMPLETE	TATA spare parts
886381960061	DRIVER DOOR GRAB HANDLE	TATA spare parts
886381960062	WHEEL ARCH BEADING L=10MTR	TATA spare parts
886381960063	WHEEL SIDE COVER / R	TATA spare parts
886381960064	WHEEL SIDE COVER /FR.	TATA spare parts
886381960066	PIPE/ERW (25.4 DIA X 1.2 THK) (PC)(L=6MT	TATA spare parts
886381960067	PIPE/ERW (32 DIA X 2 THK)(PC)(L=6MTR)	TATA spare parts
886381960068	PIPE BRACKET (32X32)(PC)	TATA spare parts
886381960069	PIPE BRACKET (32DIA)(PC)	TATA spare parts
886381960070	POLYMER TUBE (6 DIA)(L=10 MTRS)	TATA spare parts
886381960071	PIPE/ERW (25.4 DIA X 2 THK) (PC) (4M)	TATA spare parts
886381960072	PIPE BRACKET (C38 TAPER)	TATA spare parts
886381960073	BUSH (43ODX38ID)	TATA spare parts
886381960074	RUBBER PAD (74X54)(GREY)	TATA spare parts
886381960076	TRIM STRIP WHITE ( 10 MTRS EACH)	TATA spare parts
886381960078	FRONT_GRILL	TATA spare parts
886381960079	WHEEL ARCH BEADING WITH METAL(L=10MTR)	TATA spare parts
886381960080	GRAB RAIL PIPE BKT	TATA spare parts
886381960081	END BUSH FOR GUARD RAIL	TATA spare parts
886381960082	HAND STRAP	TATA spare parts
886381960083	RUBBER PAD	TATA spare parts
886381960084	REFLEX REFLECTOR (RED)	TATA spare parts
886381960085	FIRE EXTG. (6KG WITH BKT)	TATA spare parts
886381960086	HANGER FOR SUNVISOR	TATA spare parts
886381960087	FRONT HEADER CENTER - H/R	TATA spare parts
886381960088	GRAB RAIL BRACKET (PC)	TATA spare parts
886381960089	PIPE JOINT/T(38X32)(PC)	TATA spare parts
886381960090	PIPE BKT. COVER (C38)(YELLOW)	TATA spare parts
886381960091	PIPE JOINT/T(32X32)(PC)(YELLOW)	TATA spare parts
886381960092	PIPE BKT. COVER (C32)(YELLOW)	TATA spare parts
886381960093	FRP FRONT BUMPER - 4 TONNER	TATA spare parts
886381960094	FRONT FRP FLAP - 4 TONNER	TATA spare parts
886381960095	FRONT FRP PANEL	TATA spare parts
886381960096	PARTITION GLASS ASSY	TATA spare parts
886381960097	SUNVISOR 24IN (RHD)	TATA spare parts
886381960098	FRONT FRP INNER PANEL - 4 TONNER	TATA spare parts
886381960099	GUTTER RUBBER BEADING(L=10MTR)	TATA spare parts
886381960100	END CAP FOR LED	TATA spare parts
886381960101	ARM COMPLETE	TATA spare parts
886381960102	PIPE BRACKET	TATA spare parts
886381960103	RUBBER PAD (70X48)(GREY)	TATA spare parts
886381960104	PLASTIC PIPE BRACKET (32 X32)	TATA spare parts
886381960105	PLASTIC PIPE BRACKET (32 DIA)	TATA spare parts

886381960106	FRP DASHBOARD	TATA spare parts
886381960107	VENTILATOR ASSY	TATA spare parts
886381960108	PARTITION GLASS	TATA spare parts
886381960109	BEADING FOR ENGINE HOOD	TATA spare parts
886381960110	PIPE/ERW (25.4 DIA X 2 THK)(PC)L=4MTR	TATA spare parts
886381960111	BRACKET	TATA spare parts
886381960112	BRACKET CLOSE END	TATA spare parts
886381960113	PVC SLEEVE TUBE	TATA spare parts
886381960115	PVC TUBE 26.4 ID X 2.00THK	TATA spare parts
886381960116	M.S PIPE 28.0 DIA	TATA spare parts
886381960117	RUBBER PAD (70X48)(GREY)	TATA spare parts
886381960118	FRP PODEST FOR 407 BS3	TATA spare parts
886381960119	SUNVISOR	TATA spare parts
886381960120	PIPE/ERW (25.4 DIA X 2 THK)	TATA spare parts
886381960121	M.S PIPE 28.0 DIA	TATA spare parts
886381960122	COVER	TATA spare parts
886381960123	ENGINE HOOD FOR 912 BS4	TATA spare parts
886381960124	PODEST FOR LP 912 BS4	TATA spare parts
886381960125	DASHBOARD FOR BS4 CHASSIS	TATA spare parts
886381960126	RED REFLECTIVE TAPE	TATA spare parts
886381960127	REFLECTIVE TAPE - YELLOW	TATA spare parts
886381960128	STICKERING SET HRTC 42	TATA spare parts
886381960129	ENGINE HOOD FOR 712	TATA spare parts
886381960130	PODEST FOR 708	TATA spare parts
886381960131	FRP ENGINEHOOD FOR 407 BS3	TATA spare parts
886381960132	FRP PODEST FOR 407 BS3	TATA spare parts
886381960133	HAND STRAP (MODIFIED TYPE)	TATA spare parts
886381960134	DASHBOARD COMPLETE	TATA spare parts
886381960135	RVM ASSY.-LH	TATA spare parts
886381960136	RVM ASSY.-RH	TATA spare parts
886381960137	PIPE BRACKET	TATA spare parts
886381960138	DASHBOARD COMPLETE(FRP)	TATA spare parts
886381960139	HAND STRAP	TATA spare parts
886381960140	DASHBOARD COMPLETE(METAL SHEET)	TATA spare parts
886381960141	RED REFLECTIVE TAPE (L= 2.5 MTR)	TATA spare parts
886381960142	WHITE REFLECTIVE TAPE (L= 2.5 MTR)	TATA spare parts
886381960143	YELLOW REFLECTIVE TAPE (L=11.5 MTR)	TATA spare parts
886381960144	RVM ARM ASSY	TATA spare parts
886381960145	ARM FOR UNDERVIEW MIRROR	TATA spare parts
886381960146	MIRROR ARM COMPLETE	TATA spare parts
886381960147	S.S.PIPE (25.4 DIA X 2 THK)L=4.1MTR)	TATA spare parts
886381960148	BRACKET	TATA spare parts
886381960149	AL.CLAMP (25 DIA) (PC)	TATA spare parts
886381960150	PLASTIC PIPE BRACKET (25 DIA)	TATA spare parts
886381960151	BRACKET	TATA spare parts
886381960152	STANCTION PIPE ASSY	TATA spare parts
886381960153	GRILL ASSY	TATA spare parts

886381960154	S.S.PIPE(32 DIA X1.2 MM THK)(L=4MTR)	TATA spare parts
886381960155	S.S.PIPE (25.4 DIA X 1 THK)	TATA spare parts
886381960156	STANCTION PIPE ASSY (L=2150)	TATA spare parts
886381960157	STANCTION PIPE ASSY (L=1850)	TATA spare parts
886381960158	PVC TUBE GREY COLOUR(L=5MTR)	TATA spare parts
886381960159	ENGINE HOOD FOR BEST	TATA spare parts
886381960160	FRP PODEST FOR BEST	TATA spare parts
886381960161	FRP DASHBOARD FOR BEST	TATA spare parts
886381960162	DASHBOARD INSPECTION COVER	TATA spare parts
886381960163	MIRROR ARM COMPLETE (DRIVER SIDE)	TATA spare parts
886381960164	MIRROR ARM COMPLETE (PASSENGER SIDE)	TATA spare parts
886381960165	SUNVISOR ROLLER TYPE (36IN)	TATA spare parts
886381960166	FRP DASHBOARD COMPLETE	TATA spare parts
886381960167	PIPE BRACKET(40X32)4-WAY	TATA spare parts
886381960168	PIPE BRACKET (32 DIA)	TATA spare parts
886381960169	PIPE BRACKET (40X32)	TATA spare parts
886381960170	PIPE BRACKET (32X32)	TATA spare parts
886381960171	AL-PIPE 32DIA X3.15 THK - PC(L=4MTR)	TATA spare parts
886381960172	ALUMINIUM PIPE 40 DIA X 3.15 MM THK - PC	TATA spare parts
886381960173	PIPE BKT.COVER 40 DIA - YELLOW	TATA spare parts
886381960174	PIPE BKT(40 DIA) BOTTOM	TATA spare parts
886381960175	BUDGET KEY HANGER	TATA spare parts
886381960176	PIPE BRACKET (32X32) P.C	TATA spare parts
886381960177	PIPE BRACKET (40X32) PC	TATA spare parts
886381960178	PIPE BRACKET (32 DIA) PC	TATA spare parts
886381960179	FRP ENGINEHOOD	TATA spare parts
886381960180	FRP PODEST	TATA spare parts
886381960181	FRP DASHBOARD FOR KESRTC JNNURM	TATA spare parts
886381960182	IPEX CANISTER	TATA spare parts
886381960183	BRONZE NOZZLE WITH PROTECTIVE CUP	TATA spare parts
886381960184	CONTROL PANEL - FDSS	TATA spare parts
886381960185	JUNCTION BOX	TATA spare parts
886381960186	END OF LINE DEVICE	TATA spare parts
886381960187	EMERGENCY HAMMER WITH REFLECTIVE HANDLE	TATA spare parts
886381960188	AL-EXTRUSION (VINYL FLR/CORN.L-10X20	TATA spare parts
886382000001	WIPER LINKAGE	TATA spare parts
886382000002	WIPER MOTOR	TATA spare parts
886382000003	WASHER TANK	TATA spare parts
886382000004	COMPLETE WIPER KIT	TATA spare parts
886382000005	LINKAGE SYSTEM LP 1613/52	TATA spare parts
886382000006	WIPER ARM LH LP 1613/52	TATA spare parts
886382000007	WIPER ARM RH LP 1613/52	TATA spare parts
886382000008	WIPER BLADE-32 LP 1613/52	TATA spare parts
886382000009	WIPER MOTOR LP 1613/52	TATA spare parts
886382000010	WASHER KIT LP 1613/52	TATA spare parts
886382000011	WIPER MOTOR SET LP 1613/52	TATA spare parts
886382000013	WIPER BLADE	TATA spare parts

886382000014	WIPER BLADE SET	TATA spare parts
886382000015	L - Connector - 68	TATA spare parts
886382000016	L - CONNECTOR - 92	TATA spare parts
886382000017	Rod - ( As highlighted With Red Arrow)	TATA spare parts
886382000018	WINDSHIELD WIPER BLADE	TATA spare parts
886382000019	GEAR AND SLIP RING ASSEMBLY	TATA spare parts
886382000020	BRACKET UNIT ASSEMBLY	TATA spare parts
886382000021	SPINDLE LINK PIN ASSEMBLY (DRIVER)	TATA spare parts
886382000022	SPINDLE LINK PIN ASSEMBLY (PS)	TATA spare parts
886382000023	CHANNEL LINK MOULD (DS)	TATA spare parts
886382000024	CHANNEL LINK MOULD (PS)	TATA spare parts
886382000025	IDLER SUB ASSEMBLY	TATA spare parts
886382000026	PIVOT HOUSING & BEARING BUSH ASSEMBLY (I	TATA spare parts
886382000027	PIVOT HOUSING & DU BUSH ASSEMBLY (DS & P	TATA spare parts
886382000028	FASTENERS SEALING KIT	TATA spare parts
886382000029	GEAR BOX BRUSH PLATE & ARMATURE ASSEMBLY	TATA spare parts
886382000031	ROTARY LINK ASSEMBLY	TATA spare parts
886382000032	FASTENERS SEALING KIT BS6	TATA spare parts
886382000033	WASH AND WIPER SYSTEM 1515/55	TATA spare parts
886382000035	CONNECTOR LH	TATA spare parts
886382000036	ROD LH	TATA spare parts
886382000037	WIPER ARM & BLADE LCV BS6	TATA spare parts
886382000038	WIPER LINK ç DRIVER SIDE	TATA spare parts
886382000039	WIPER LINK ç CO DRIVER SIDE	TATA spare parts
886382000040	ROTARY LINK ASSEMBLY	TATA spare parts
886382000041	SPINDLE LINK PIN ASSEMBLY (DRIVER)	TATA spare parts
886382000042	SPINDLE LINK PIN ASSEMBLY (PS)	TATA spare parts
886382000043	IDLER SUB ASSEMBLY	TATA spare parts
886382000044	FASTENERS SEALING KIT ( FOR WIPER LINK )	TATA spare parts
886382000045	MOTOR CRANK ASSLY-G3 BS6	TATA spare parts
886382000046	MAIN FRAME & MOTOR BKT ASSLY BS6	TATA spare parts
886382000047	KIT CRANK ASSLY_DR_G3 2.55 BS6	TATA spare parts
886382000048	KIT CRANK ASSLY_PS-G3 2.55 BS6	TATA spare parts
886382000049	LINK PLATE DR-G3 BS6	TATA spare parts
886382000050	LINK UNIT PS-G3 BS6	TATA spare parts
886382000051	LINK UNIT MIDDLE-G3 BS6	TATA spare parts
886382000052	SHANK ASSLY IDLE-G3 BS6	TATA spare parts
886382000053	SHANK ASSLY DR & PS-G3 BS6	TATA spare parts
886382000054	NUT FLANGE BS6	TATA spare parts
886382000055	KIT CRANK ASSLY_DR_G3 BS6	TATA spare parts
886382000056	KIT CRANK ASSLY_PS-G3 BS6	TATA spare parts
886382000057	GEAR BOX AND BRUSH PLATE ASSY	TATA spare parts
886382000058	ARMATURE ASSEMBLY	TATA spare parts
886382000059	GEAR AND SLIP RING ASSEMBLY	TATA spare parts
886382000060	FASTENERS ( FOR WIPER MOTOR)	TATA spare parts
886382000061	SEALING KIT ( FOR WIPER MOTOR)	TATA spare parts
886382000062	FASTENERS SEALING KIT BS6	TATA spare parts

886382000063	WIPER WASHER BOTTLE LP 1618/53	TATA spare parts
886382000064	WIPER BLADE AND ARM LH & RH	TATA spare parts
886382000065	WIPER ARM WITH BLADE 32 INCH BS6	TATA spare parts
886382000066	MOTOR BS6	TATA spare parts
886382000067	LINKAGE BS6	TATA spare parts
886382000068	WATER KIT BS6	TATA spare parts
886382000069	MOTOTR BS6	TATA spare parts
886382000070	LINKAGE BS6	TATA spare parts
886382000071	WATER KIT BS6	TATA spare parts
886382000072	WIPER LINKAGE BS6	TATA spare parts
886382000073	WASHER KIT BS6	TATA spare parts
886382000074	WASHER MOTOR BS6	TATA spare parts
886382000075	WIPER LINKAGE BS6	TATA spare parts
886382000076	WATER KIT BS6	TATA spare parts
886382000077	WIPER MOTOR BS6	TATA spare parts
886382000078	WIPER SYSTEM 24V (32INCH ARM BLADE) ARM	TATA spare parts
886382000079	WIPER LINKAGE BS6	TATA spare parts
886382000080	WASHER KIT BS6	TATA spare parts
886382000081	WIPER MOTOR BS6	TATA spare parts
886382000082	WIPER LINKAGE BS6	TATA spare parts
886382000083	WASHER KIT BS6	TATA spare parts
886382000084	WIPER MOTOR BS6	TATA spare parts
886382000085	WIPER LINKAGE BS6	TATA spare parts
886382000086	WASHER KIT BS6	TATA spare parts
886382000087	WIPER MOTOR BS6	TATA spare parts
886382000088	WIPER LINKAGE	TATA spare parts
886382000089	WASHER KIT	TATA spare parts
886382000090	WIPER MOTOR	TATA spare parts
886382000091	WIPER LINKAGE	TATA spare parts
886382000092	WASHER KIT	TATA spare parts
886382000093	WIPER MOTOR	TATA spare parts
886382000094	WIPER LINKAGE BS6	TATA spare parts
886382000095	WASHER KIT BS6	TATA spare parts
886382000096	WIPER MOTOR BS6	TATA spare parts
886382000097	WIPER LINKAGE BS6	TATA spare parts
886382000098	WASHER KIT BS6	TATA spare parts
886382000099	WIPER MOTOR BS6	TATA spare parts
886382960001	WHEEL BOX	TATA spare parts
886382960002	WIPER LINKAGE	TATA spare parts
886382960003	WIPER LINKAGE	TATA spare parts
886382960004	ASSY. WIPER BLADE BS1/2/3/4	TATA spare parts
886382960005	WIPER ARM ASSY. (LH)	TATA spare parts
886382960006	WIPER ARM ASSY. (RH)	TATA spare parts
886382960007	WIPER MOTOR	TATA spare parts
886382960008	CONNECTING ROD	TATA spare parts
886382960009	CONNECTING ROD	TATA spare parts
886382960010	WIPER MOTOR 24 VOLTS	TATA spare parts

886382960011	CONNECTING ROD(RH)	TATA spare parts
886382960012	CONNECTING ROD(RH)	TATA spare parts
886382960013	WIPER BLADE (800MM)	TATA spare parts
886382960014	WIPER MOTOR-24V HIGH POWER	TATA spare parts
886382960015	CONNECTING ROD (L=505)	TATA spare parts
886382960016	CONNECTOR/RH(SMALLER)	TATA spare parts
886382960017	NUT	TATA spare parts
886382960018	NUT/LH	TATA spare parts
886382960019	CONNECTOR/LH(SMALLER)	TATA spare parts
886382960020	WIPER ARM RH	TATA spare parts
886382960021	WIPER ARM LH	TATA spare parts
886382960022	WIPER BLADE	TATA spare parts
886382960023	WIPER BLADE ASSY. 508 MM	TATA spare parts
886382960024	WIPER ARM (PENTOGRAPH-TYPE)	TATA spare parts
886382960025	BUTTERFLY SYSTEM LINKAGE	TATA spare parts
886382960026	WASHER TANK	TATA spare parts
886382960027	BUTTERFLY SYSTEM LINKAGE	TATA spare parts
886382960028	WHEEL BOX+SPACER	TATA spare parts
886382960029	WIPER SYSTEM FULL ASSY	TATA spare parts
886383000001	DASHCONTROL12/24V GL	TATA spare parts
886383000002	A/C COMPRESSOR	TATA spare parts
886383000003	AIRCONDITIONING UNIT COMPLETE	TATA spare parts
886383000004	BLOWER MOTOR ASSY	TATA spare parts
886383000005	MOTOR SPEED CONTROLLER	TATA spare parts
886383000006	LIQUID PIPE&& R/H	TATA spare parts
886383000007	LIQUID PIPE&& L/H	TATA spare parts
886383000008	LIQUID HOSE	TATA spare parts
886383000009	SERVICE VALVE	TATA spare parts
886383000010	RECEIVE TANK&V/V ASSY	TATA spare parts
886383000011	LOW PRESSURE SWITCH	TATA spare parts
886383000012	HIGH PRESSURE SWITCH	TATA spare parts
886383000013	LOW PRESSURE S/W ASSY	TATA spare parts
886383000014	AC UNIT	TATA spare parts
886383000015	AC LOUVER	TATA spare parts
886383000016	COND. FAN BLADE	TATA spare parts
886383000017	THERMO HEATER DBW / H	TATA spare parts
886383000018	V-BELT (L=780 MM)	TATA spare parts
886383000019	HOSE DISCHARGE ASSY	TATA spare parts
886383000020	HOSE DISCHARGE ASSY	TATA spare parts
886383000021	HOSE SUCTION ASSY	TATA spare parts
886383000022	SUCTION HOSE-ASSY	TATA spare parts
886383000023	DISCHARGE HOSE ASSY-1	TATA spare parts
886383000024	DISCHARGE HOSE ASSY-2	TATA spare parts
886383000027	COMPRESSOR	TATA spare parts
886383000028	CONDENSER FAN	TATA spare parts
886383000029	CONDENSER COIL	TATA spare parts
886383000030	COMPRESSORASSY	TATA spare parts

886383000031	CONDENSER FAN MOTOR 24V 180W	TATA spare parts
886383000032	MOTOR ASSY. (TWIN BLOWER 24 VOLT 240W)	TATA spare parts
886383000033	STUD	TATA spare parts
886383000034	IDLER PULLEY WITH BEARING	TATA spare parts
886383000035	PIN SLEEVE ¿ FRONT	TATA spare parts
886383000036	PIN SLEEVE ¿ REAR	TATA spare parts
886383000037	TENSIONER MOUNTING PLATE	TATA spare parts
886383000038	REAR BEARING ASSLY	TATA spare parts
886383000039	PIPE CLAMP	TATA spare parts
886383000040	SUPPORT-LOW PRE.S/W	TATA spare parts
886383000041	SUPPORT-SOL V/V	TATA spare parts
886383000042	SUPPORT-DRIER	TATA spare parts
886383000043	SUPPORT-OP/PANEL	TATA spare parts
886383000044	SUPPORT-LIQ PIPE	TATA spare parts
886383000045	CLIP-HOSE(D/HOSE)	TATA spare parts
886383000046	DRAIN HOSE	TATA spare parts
886383000047	INSULATION E/COIL	TATA spare parts
886383000048	RIVET BLIND	TATA spare parts
886383000049	INSULATION(SPONGE)	TATA spare parts
886383000050	CUSHION	TATA spare parts
886383000051	EVAPORATOR COIL(1) LH	TATA spare parts
886383000052	EVAPORATOR COIL(2) RH	TATA spare parts
886383000053	EXP.V/V & PIPE ASSY	TATA spare parts
886383000054	JAVA SCRIPT SHOW BOTTOM DIV(3)	TATA spare parts
886383000055	SUCTION PIPE CR26RS LH	TATA spare parts
886383000056	O-RING	TATA spare parts
886383000057	WATER ELIMINATOR	TATA spare parts
886383000058	ADHESIVE RUBBER PY	TATA spare parts
886383000059	BOLT ASSY	TATA spare parts
886383000060	EK305 R/DRIER	TATA spare parts
886383000061	SUC&DIS PIPE	TATA spare parts
886383000062	DIS PIPE KBA-CR26RS	TATA spare parts
886383000063	PIPE_LIQ. (2) KBA-CR26RS	TATA spare parts
886383000064	EQUALIZER PIPE LH	TATA spare parts
886383000065	SOLENOID PIPE(1)	TATA spare parts
886383000066	SOLENOID PIPE(2)	TATA spare parts
886383000067	SOLENOID V/V	TATA spare parts
886383000068	LOW PRESSURE S/W ASSY	TATA spare parts
886383000069	BOLT ASSY	TATA spare parts
886383000070	BOLT ASSY	TATA spare parts
886383000071	PLAIN WASHER	TATA spare parts
886383000072	FLANGE NUT	TATA spare parts
886383000073	CLAMP-DRIER	TATA spare parts
886383000074	O-RING	TATA spare parts
886383000075	CAP SUC	TATA spare parts
886383000076	CAP DIS	TATA spare parts
886383000077	RUBBER SUC.CAP	TATA spare parts

886383000078	RUBBER DIS.CAP	TATA spare parts
886383000079	SEALING RUBBER	TATA spare parts
886383000080	SEALING RUBBER	TATA spare parts
886383000081	OPERATION_PANEL ASSY	TATA spare parts
886383000082	BLOWER	TATA spare parts
886383000083	EVAP MOTOR ASSY	TATA spare parts
886383000084	CLIP-EVAP CASE	TATA spare parts
886383000085	SEAL-B/CASE	TATA spare parts
886383000086	E STOP RING	TATA spare parts
886383000087	PLAIN WASHER	TATA spare parts
886383000088	HEX NUT	TATA spare parts
886383000089	FLANGE NUT	TATA spare parts
886383000090	SCREW HIGH-LOW HR	TATA spare parts
886383000091	FLANGE NUT	TATA spare parts
886383000092	EVAP.BLOWER WIRE	TATA spare parts
886383000093	EARTH WIRE	TATA spare parts
886383000094	LEAD WIRE	TATA spare parts
886383000095	GROMMET-DIS PIPE	TATA spare parts
886383000096	GROMMET-L/PIPE	TATA spare parts
886383000097	CUSHION RUBBER-E/C	TATA spare parts
886383000098	CUSHION RUBBER-E/C	TATA spare parts
886383000099	AIR FILTER	TATA spare parts
886383000100	WING NUT	TATA spare parts
886383000101	SEALING RUBBER EVAP	TATA spare parts
886383000102	SILICON	TATA spare parts
886383000103	INSULATION E/COIL	TATA spare parts
886383000104	LOCKER BOLT ASSY BAC ALL	TATA spare parts
886383000105	BOLT ASSY M4X0.7PXX10L	TATA spare parts
886383000106	FLANGE CAP-DIS	TATA spare parts
886383000107	BRKET-3(COIL)	TATA spare parts
886383000108	BKT-R/TANK	TATA spare parts
886383000109	PLAIN WASHER	TATA spare parts
886383000110	FLANGE NUT	TATA spare parts
886383000111	INSUL.-C/COIL	TATA spare parts
886383000112	GROMMET KBA-CR26RS	TATA spare parts
886383000113	WIRE HOLDER	TATA spare parts
886383000114	COND. MOTOR ASSY PY	TATA spare parts
886383000115	RING FAN	TATA spare parts
886383000116	WASHER PLAIN	TATA spare parts
886383000117	WIRING-COND MOTOR	TATA spare parts
886383000118	COND COIL ASSY	TATA spare parts
886383000119	HOSE_LIQ. (1) KBA-CR26RS	TATA spare parts
886383000120	R/TANK & SERVICE V/V ASSY	TATA spare parts
886383000121	GROMMET-25	TATA spare parts
886383000122	INSUL-FAN SHROUD	TATA spare parts
886383000123	BOLT ASSY	TATA spare parts
886383000124	CONNECTING ROD ASSY	TATA spare parts



886383000125	GASKET/CYLINDER HEAD	TATA spare parts
886383000126	GASKET/VALVE PLATE	TATA spare parts
886383000127	CONNECTING ROD BEARING(1)	TATA spare parts
886383000128	CONNECTING ROD BEARING(2)	TATA spare parts
886383000129	PISTON	TATA spare parts
886383000130	SERVICE_VALVE_ASSY-DIS BAC ALL	TATA spare parts
886383000131	SERVICE_VALVE_ASSY-SUC BAC ALL	TATA spare parts
886383000132	GASKET-M/BEAR COVER	TATA spare parts
886383000133	GASKET/GLAND	TATA spare parts
886383000134	PISTON RING	TATA spare parts
886383000135	PLAIN WASHER	TATA spare parts
886383000136	PLAIN WASHER	TATA spare parts
886383000137	MAGNET OIL PLUG	TATA spare parts
886383000138	GASKET/ALUMINUM	TATA spare parts
886383000139	GASKET/SERVICE VALVE-SUC	TATA spare parts
886383000140	GASKET/SERVICE VALVE-DIS	TATA spare parts
886383000141	PISTON PIN	TATA spare parts
886383000142	SNAP RING	TATA spare parts
886383000143	CRANK SHAFT	TATA spare parts
886383000144	GLAND	TATA spare parts
886383000145	CRANK CASE COVER	TATA spare parts
886383000146	BASE	TATA spare parts
886383000147	CYLINDER HEAD M/C	TATA spare parts
886383000148	CRANK CASE M/C(4COMP)	TATA spare parts
886383000149	BOLT(L34)	TATA spare parts
886383000150	BOLT(M8X36L)	TATA spare parts
886383000151	BOLT(L44)	TATA spare parts
886383000152	BOLT(L54)	TATA spare parts
886383000153	BOLT(M6X16L)	TATA spare parts
886383000154	BOLT ASSY	TATA spare parts
886383000155	BOLT(L53)	TATA spare parts
886383000156	BOLT(M10X88L)	TATA spare parts
886383000157	BOLT(L80)	TATA spare parts
886383000158	GASKET-C/CASE COVER	TATA spare parts
886383000159	GASKET-BASE	TATA spare parts
886383000160	SIGHT GLASS COMPLETE	TATA spare parts
886383000161	MECHANICAL SEAL ASSY	TATA spare parts
886383000162	O-RING(SUC)	TATA spare parts
886383000163	O-RING(S/GLASS)	TATA spare parts
886383000164	COMP OIL SEAL	TATA spare parts
886383000165	OIL SEPARATOR	TATA spare parts
886383000166	TAP SCREW	TATA spare parts
886383000167	RIVET	TATA spare parts
886383000168	MAIN BEARING COVER	TATA spare parts
886383000169	BALL BEARING 6306C3	TATA spare parts
886383000170	ROLLER BEARING	TATA spare parts
886383000171	COVER-SVC VALVE	TATA spare parts

886383000172	PLUG(M14)	TATA spare parts
886383000173	GASKET/ALUMINUM	TATA spare parts
886383000174	BOLT(M8X28L)	TATA spare parts
886383000175	WASHER SPRING	TATA spare parts
886383000176	HOUSING COUPLING	TATA spare parts
886383000177	FLANGE WHEEL	TATA spare parts
886383000178	WOOD RUFF KEY	TATA spare parts
886383000179	WASHER COMP.	TATA spare parts
886383000180	HERI COIL	TATA spare parts
886383000181	BOLT ASSY	TATA spare parts
886383000182	LOCK PLATE	TATA spare parts
886383000183	COVER HOUSING	TATA spare parts
886383000184	OIL FILTER ASSY	TATA spare parts
886383000185	ENGINE MT G RUBBER	TATA spare parts
886383000186	OIL CAP	TATA spare parts
886383000187	COMPLET-FUEL FILTER	TATA spare parts
886383000188	INDICATOR-DUST	TATA spare parts
886383000189	MT G RUBBER-UNIT	TATA spare parts
886383000190	BKT-ENG MT G(R/H)	TATA spare parts
886383000191	BKT-ENG MT G(L/H)	TATA spare parts
886383000192	BASE-COMP KIA P/PACK	TATA spare parts
886383000193	BKT-R/TANK	TATA spare parts
886383000194	BKT-RAD MT G(L/H) AL RADIATOR	TATA spare parts
886383000195	BKT-RAD MT G(R/H) AL RADIATOR	TATA spare parts
886383000196	SUPPORT-RAD(L/H) AL RADIATOR	TATA spare parts
886383000197	SUPPORT-RAD(R/H) AL RADIATOR	TATA spare parts
886383000198	BKT-ACTUATOR CONTROL	TATA spare parts
886383000199	BKT-AIR CLEANER MT G	TATA spare parts
886383000200	BRACE-ALT	TATA spare parts
886383000201	BKT-FUEL FILTER	TATA spare parts
886383000202	BKT-OIL FILLER	TATA spare parts
886383000203	FAN SHROUD ASSY AL RADIATOR	TATA spare parts
886383000204	RADIATOR ASSY	TATA spare parts
886383000205	INSULATION CASE-C	TATA spare parts
886383000206	ALTERNATOR(150A) BOSCH	TATA spare parts
886383000207	BOLT ASSY	TATA spare parts
886383000208	BOLT ASSY	TATA spare parts
886383000209	CABLE-ASSY CONTROL HD P/PACK	TATA spare parts
886383000210	HOSE-WATER OUTLET	TATA spare parts
886383000211	HOSE-WATER INLET	TATA spare parts
886383000212	MUFFLER ASSY	TATA spare parts
886383000213	EXHAUST PIPE	TATA spare parts
886383000214	CLIP M/PIPE	TATA spare parts
886383000215	BOLT-U	TATA spare parts
886383000216	BAND-AIR CLEANER	TATA spare parts
886383000217	NIPPLE-DUST INDICATOR	TATA spare parts
886383000218	O-RING	TATA spare parts

886383000219	HOSE-AIR CLEANER OUTLET	TATA spare parts
886383000220	RADIATOR FILTER	TATA spare parts
886383000221	AMOURING	TATA spare parts
886383000222	SUCTION PORT	TATA spare parts
886383000223	DISCHARGE PORT	TATA spare parts
886383000224	CAP DIS	TATA spare parts
886383000225	CAP SUC.	TATA spare parts
886383000226	EARTH WIRE(ALT)	TATA spare parts
886383000227	EARTH WIRE	TATA spare parts
886383000228	HOUR METER	TATA spare parts
886383000229	WIRE ASSY-HOUR METER	TATA spare parts
886383000230	WIRING-START	TATA spare parts
886383000231	POWER WIRE(FUSE-ALT)	TATA spare parts
886383000232	WIRING ASSY-POWER UNIT	TATA spare parts
886383000233	CONTROL BOX_ASSY SLIM P/PACK	TATA spare parts
886383000234	CLAMP-SUC.HOSE	TATA spare parts
886383000235	RESERVOIR HOSE	TATA spare parts
886383000236	CAP	TATA spare parts
886383000237	SEAL	TATA spare parts
886383000238	RESERVOIR TANK	TATA spare parts
886383000239	CLAMP-RESERVIOR	TATA spare parts
886383000240	CLAMP-HOSE	TATA spare parts
886383000241	CLAMP-OIL FILLER	TATA spare parts
886383000242	CLAMP-HOSE	TATA spare parts
886383000243	CLAMP-HOSE	TATA spare parts
886383000244	CLAMP-HOSE	TATA spare parts
886383000245	HOSE-FUEL(IN)	TATA spare parts
886383000246	HOSE-FUEL(OUT)	TATA spare parts
886383000247	INLET-FUEL HOSE	TATA spare parts
886383000248	OUTLET-FUEL HOSE	TATA spare parts
886383000249	TAPPING SCREW	TATA spare parts
886383000250	BOLT ASSY	TATA spare parts
886383000251	BOLT ASSY	TATA spare parts
886383000252	BOLT ASSY	TATA spare parts
886383000253	BOLT ASSY	TATA spare parts
886383000254	BOLT ASSY	TATA spare parts
886383000255	PLAIN WASHER	TATA spare parts
886383000256	WASHER PLAIN	TATA spare parts
886383000257	SPRING WASHER	TATA spare parts
886383000258	SPRING WASHER	TATA spare parts
886383000259	HEX NUT	TATA spare parts
886383000260	HEX NUT	TATA spare parts
886383000261	TRIANGLE HEAD SCREW	TATA spare parts
886383000262	V-BELT B-45INCHINCH	TATA spare parts
886383000263	GASKET-OIL FILLER	TATA spare parts
886383000264	CLAMP	TATA spare parts
886383000265	CUSHION RUBBER COMP	TATA spare parts

886383000266	BKT-FUEL HOSE	TATA spare parts
886383000267	MT G BOLT	TATA spare parts
886383000268	BOLT ASSY	TATA spare parts
886383000269	BKT-WIRE	TATA spare parts
886383000270	CLIP-LIQUID TUBE	TATA spare parts
886383000271	BOLT(L110)	TATA spare parts
886383000272	WIRE CLAMP	TATA spare parts
886383000273	CLAMP-HOSE	TATA spare parts
886383000274	NAME PLATE POWER UNIT	TATA spare parts
886383000275	BOLT-FLANGE	TATA spare parts
886383000276	WASHER PLAIN(M10-?28X2.0T)	TATA spare parts
886383000277	SPRING WASHER	TATA spare parts
886383000278	BOLT(M10X40L)	TATA spare parts
886383000279	ACTUATOR_HOUSING	TATA spare parts
886383000280	P.H BOLT&S/P WASHER ASSY	TATA spare parts
886383000281	WIRE-RPM	TATA spare parts
886383000282	M/ACTUATOR-RPM	TATA spare parts
886383000283	CONTROL ASSY	TATA spare parts
886383000284	MANUAL-CR26/30RS(DIGITAL)	TATA spare parts
886383000285	AIRCUT FORMAL	TATA spare parts
886383000286	SUC HOSE	TATA spare parts
886383000287	DIS HOSE	TATA spare parts
886383000288	3-WAY JOINT	TATA spare parts
886383000289	DRAIN HOSE(1)	TATA spare parts
886383000290	MID WIRE ASSY(C/P-O/P)	TATA spare parts
886383000291	MID WIRE ASSY(C/P-P/U)	TATA spare parts
886383000292	DRAIN TUBE	TATA spare parts
886383000293	AIRCUT FORMAL 8000L	TATA spare parts
886383000294	RUBBER SPACER	TATA spare parts
886383000295	RUBBER SPACER CON.	TATA spare parts
886383000296	SEAL BOND	TATA spare parts
886383000297	CLAMP-PIPE	TATA spare parts
886383000298	LEAD WIRE ASSY_CONTROL	TATA spare parts
886383000299	POWER WIRE(FUSE-ALT)	TATA spare parts
886383000300	POWER WIRE(OP-M/RELAY)	TATA spare parts
886383000301	POWER WIRE	TATA spare parts
886383000302	AIR OUTLET GRILL	TATA spare parts
886383000303	GRILL SIDE	TATA spare parts
886383000304	ELEMENT-L/H	TATA spare parts
886383000305	AIR BOX ASSY	TATA spare parts
886383000306	HOSE-AIR CLEANER INLET	TATA spare parts
886383000307	AIR BOX FILTER	TATA spare parts
886383000308	MAIN FUSE ASSY	TATA spare parts
886383000309	BOLT ASSY(M6*1.0P*15L)?18	TATA spare parts
886383000310	EARTH WIRE	TATA spare parts
886383000311	CONDENSER ASSY	TATA spare parts
886383000312	CONDENSER FAN ASSY	TATA spare parts

886383000313	E/CASE & INSUL ASS Y MBA-260RSN	TATA spare parts
886383000314	CASE-UPPER_BLOWER	TATA spare parts
886383000315	CASE-LOWER_BLOWER	TATA spare parts
886383000316	COND. CASE ASS Y	TATA spare parts
886383000317	COND CASE COVER(NO DWG)	TATA spare parts
886383000318	COND. COIL(A)	TATA spare parts
886383000319	COND. COIL(B)	TATA spare parts
886383000320	DIS PIPE	TATA spare parts
886383000321	DISCHARE HOSE	TATA spare parts
886383000322	SERVICE VALVE ASS Y BAC ALL	TATA spare parts
886383000323	RELAY	TATA spare parts
886383000324	FUSE BOX ASS Y	TATA spare parts
886383000325	INCAR SENSOR ASS Y	TATA spare parts
886383000326	CATRIDGE-FUEL FILTER	TATA spare parts
886383000327	ALTERNATOR(150A) 8SC3200V	TATA spare parts
886383000328	REGULATOR 8RL3145S	TATA spare parts
886383000329	PULLEY-ALTERNATOR	TATA spare parts
886383000330	HIGH PRESSURE SWITCH EXPORT	TATA spare parts
886383000331	LOW PRESSURE SWITCH EXPORT	TATA spare parts
886383000332	COMPRESSOR	TATA spare parts
886383000333	POWER RELAY(24V/100A)	TATA spare parts
886383000334	RELAY-ISO 24V	TATA spare parts
886383000335	COOLING FAN D4BB	TATA spare parts
886383000336	FRAME HD P/PACK	TATA spare parts
886383000337	TENSIONER-TIMING BELT	TATA spare parts
886383000338	BELL-TIMING B	TATA spare parts
886383000339	INJECTION PUMP ASS Y	TATA spare parts
886383000340	RING VALVE ASS Y	TATA spare parts
886383000341	4COMP GASKET & O-RING SET	TATA spare parts
886383000342	COMPRESSOR ASS Y(655CC)	TATA spare parts
886383000343	CRANK SHAFT M/C	TATA spare parts
886383000344	CRANK SHAFT M/C	TATA spare parts
886383000345	BALL BEARING	TATA spare parts
886383000346	MAIN BEARING COVER	TATA spare parts
886383000347	GLAND	TATA spare parts
886383000348	CRANK CASE(66COMP)	TATA spare parts
886383000349	CRANK CASE(66COMP)	TATA spare parts
886383000350	PISTON	TATA spare parts
886383000351	CONNECTING ROD ASS Y(	TATA spare parts
886383000352	CONNECTING ROD ASS Y	TATA spare parts
886383000353	CON ROD BEARING(UPPER)	TATA spare parts
886383000354	CON ROD BEARING(LOWER)	TATA spare parts
886383000355	SNAP RING	TATA spare parts
886383000356	PISTON RING	TATA spare parts
886383000357	RING VALVE ASS Y	TATA spare parts
886383000358	CYLINDER HEAD	TATA spare parts
886383000359	CRANK CASE COVER	TATA spare parts

886383000360	CRANK CASE COVER	TATA spare parts
886383000361	OIL SEPARATOR	TATA spare parts
886383000362	BASE	TATA spare parts
886383000363	OIL SEAL	TATA spare parts
886383000364	OIL SEAL COVER	TATA spare parts
886383000365	SERVICE VALVE ASS&Y-SUC	TATA spare parts
886383000366	SERVICE VALVE ASS&Y-DIS	TATA spare parts
886383000367	O-RING(SUC)	TATA spare parts
886383000368	WASHER SPRING	TATA spare parts
886383000369	WASHER PLAIN	TATA spare parts
886383000370	PLUG	TATA spare parts
886383000371	GASKET/ALUMINUM	TATA spare parts
886383000372	GASKET-M/BEAR COVER	TATA spare parts
886383000373	GASKET-C/CASE COVER	TATA spare parts
886383000374	GASKET-C/CASE COVER	TATA spare parts
886383000375	GASKET-CYL HEAD	TATA spare parts
886383000376	GASKET-VALVE PLATE	TATA spare parts
886383000377	GASKET/GLAND	TATA spare parts
886383000378	GASKET-BASE	TATA spare parts
886383000379	GASKET/SERVICE VALVE-SUC	TATA spare parts
886383000380	GASKET/SERVICE VALVE-DIS	TATA spare parts
886383000381	BOLT(M10X43L)	TATA spare parts
886383000382	BOLT(M10X44L)	TATA spare parts
886383000383	BOLT	TATA spare parts
886383000385	COMP LIFT BRACKET	TATA spare parts
886383000386	BOLT(L56)	TATA spare parts
886383000387	FAN FOR BLOWER MOTOR (LHD)	TATA spare parts
886383000388	ALTERNATOR	TATA spare parts
886383000389	AC. UNIT	TATA spare parts
886383000390	AC COMPRESSOR	TATA spare parts
886383000391	CAPACITOR	TATA spare parts
886383000392	CONTROL PANEL	TATA spare parts
886383000393	TANK RECEIVER ASSY	TATA spare parts
886383000394	KNOB	TATA spare parts
886383000395	COMP. MTG BKT ASSY-TATA-613-E11	TATA spare parts
886383000396	KIT-CONDENSER COIL BRACKET & COVER	TATA spare parts
886383000397	EVAPORATOR ASSY W/ TXV BOLT & PACKAGING	TATA spare parts
886383000398	BOLT BS6	TATA spare parts
886383000399	PACKAGING BS6	TATA spare parts
886383000400	BELT 1570-6PK	TATA spare parts
886383000401	ALERNATOR PULLEY	TATA spare parts
886383000402	COMPRESSOR CLUTCH PULLEY	TATA spare parts
886383000403	COMPRESSOR BRACKET	TATA spare parts
886383000404	COMPRESSOR QP 160	TATA spare parts
886383000405	TWO POLE MALE COUPLER	TATA spare parts
886383000406	64 M/W BRZETRLW/SLVRPLT	TATA spare parts
886383000407	COMPRESSOR (FKX40/655 K) - BOCK	TATA spare parts

886383000408	COUPLING	TATA spare parts
886383000409	RUBBER COUPLING	TATA spare parts
886383000410	AIR FILTER - CLEANER	TATA spare parts
886383000411	SOLENOID ASSY	TATA spare parts
886383000412	FUEL FILTER	TATA spare parts
886383000413	RADIATOR ASSY	TATA spare parts
886383000414	HOSE RADIATOR OUT	TATA spare parts
886383000415	CAPACITOR	TATA spare parts
886383000416	CONTROL PANEL ASSY	TATA spare parts
886383000417	HYUNDAI ENGINE OVERHAULING KIT	TATA spare parts
886383000418	OIL FILTER	TATA spare parts
886383000419	RADIATOR FAN TYPE A	TATA spare parts
886383000420	RADIATOR FAN TYPE B	TATA spare parts
886383000421	POWER RELAY 24V/120A	TATA spare parts
886383000422	HOUR METER	TATA spare parts
886383000423	STARTER MOTOR	TATA spare parts
886383000424	FUEL INJECTION PUMP	TATA spare parts
886383000425	MT G CUSHION - ENG LH SIDE	TATA spare parts
886383000426	MT G CUSHION - ENG RH SIDE	TATA spare parts
886383000427	FUSE 150 A	TATA spare parts
886383000428	PRESSURE SWITCH 1 8 / 0 3BAR NO	TATA spare parts
886383000429	PRESSURE SWITCH 25 2 / 16 5BAR NC	TATA spare parts
886383000430	HOSE RADIATOR IN	TATA spare parts
886383000431	RELAY BOX ASSY	TATA spare parts
886383000432	ALTERNATOR 24V 150A	TATA spare parts
886383000434	HALF ENGINE ASSY	TATA spare parts
886383000435	DRIVE ASSEMBLY DIESEL	TATA spare parts
886383000436	HOUSING - COMPRESSOR	TATA spare parts
886383000437	MT G CUSHION - COMPRESSOR	TATA spare parts
886383000438	MUFFLER ASSY	TATA spare parts
886383000439	EXHAUST ASSY	TATA spare parts
886383000440	HOSE - AIR CLEANER	TATA spare parts
886383000441	CABLE ASSY - SPEED	TATA spare parts
886383000442	BELT B-47	TATA spare parts
886383000443	ELBOW SCREW 7/16	TATA spare parts
886383000444	RADIATOR AUX TANK ASSY	TATA spare parts
886383000445	WIRE HARNESS SET	TATA spare parts
886383000446	FUSE BOX	TATA spare parts
886383000447	5P RELAY	TATA spare parts
886383000448	AC UNIT FILTER BS6	TATA spare parts
886383000449	CENTRIFUGAL BLOWER ASSLY W/BALANCING 24V	TATA spare parts
886383000450	AXIAL FAN ASSEMBLY WITH BALANCING 24V	TATA spare parts
886383000451	HEATER COIL - RH	TATA spare parts
886383000452	HEATER COIL - LH	TATA spare parts
886383000453	HEATER HOSE(2)	TATA spare parts
886383000454	CLAMP	TATA spare parts
886383000455	BLOWER&MOTOR ASSY	TATA spare parts

886383000456	AIR FILTER BRKT	TATA spare parts
886383000457	AIR-FILTER	TATA spare parts
886383000458	CONDENSER ASSY	TATA spare parts
886383000459	SHROUD - LH	TATA spare parts
886383000460	SHROUD - RH	TATA spare parts
886383000461	FAN&MOTOR ASSY	TATA spare parts
886383000462	RECEIVER TANK ASSY	TATA spare parts
886383000463	GRILL	TATA spare parts
886383000464	SUC HOSE	TATA spare parts
886383000465	DIS HOSE	TATA spare parts
886383000466	3-WAY JOINT	TATA spare parts
886383000467	RUBBER SPACER	TATA spare parts
886383000468	MT&G PLATE	TATA spare parts
886383000469	CLAMP-D/HOSE	TATA spare parts
886383000470	HEATER WIRE	TATA spare parts
886383000471	LIQUID PIPE	TATA spare parts
886383000472	COND COVER	TATA spare parts
886383000473	WATER PUMP	TATA spare parts
886383000474	COIL-SOL. V/V	TATA spare parts
886383000475	SOL. V/V	TATA spare parts
886383000476	SHROUD SUPPORT BKT	TATA spare parts
886383000477	ABS AC VENT BASE	TATA spare parts
886383000478	AC VENT ASSEMBLY	TATA spare parts
886383000479	TAP SCREW/PAN HEAD	TATA spare parts
886383000480	ELECTRO MAGNETIC CLUTCH MOTOR W/O BEAR	TATA spare parts
886383000481	EXPANSION TANK WITH FOAM	TATA spare parts
886383000482	PRESSURE CAP	TATA spare parts
886383000483	WIRING ASSY-POWER UNIT	TATA spare parts
886383000484	MID WIRE	TATA spare parts
886383000485	OPERATION PANEL ASSY	TATA spare parts
886383000486	SUC & DIS PIPE	TATA spare parts
886383000487	HEATER HOSE(3)	TATA spare parts
886383000488	HEATER HOSE(1)	TATA spare parts
886383000489	HEATER IN/OUT PIPE	TATA spare parts
886383000490	DIS HOSE	TATA spare parts
886383000491	CONTROL ASSY	TATA spare parts
886383000492	MID WIRE	TATA spare parts
886383000493	POWER WIRE	TATA spare parts
886383000494	POWER WIRE	TATA spare parts
886383000495	POWER WIRE	TATA spare parts
886383000496	RELAY	TATA spare parts
886383000497	DISCHARGE PORT	TATA spare parts
886383000498	SUCTION PORT	TATA spare parts
886383000499	ROLLER BEARING	TATA spare parts
886383000500	PLUG	TATA spare parts
886383000501	BOLT (L110)	TATA spare parts
886383000502	BOLT (L103)	TATA spare parts



886383000503	BOLT (L56)	TATA spare parts
886383000504	SOL. V/V + COIL-SOL. V/V	TATA spare parts
886383000505	HEATER WIRE	TATA spare parts
886383000506	POWER STEERING ROD ASSY	TATA spare parts
886383000507	IDLER MOUNTING BRACKET ASSY	TATA spare parts
886383000508	CYLINDER HEAD	TATA spare parts
886383000509	CRANK SHAFT M/C	TATA spare parts
886383000510	BKT-AIR CLEANER MTG	TATA spare parts
886383000511	ACTUATOR HOUSING	TATA spare parts
886383000512	FLANGE WHEEL	TATA spare parts
886383000513	PISTON PIN	TATA spare parts
886383000514	M/ACTUATOR RPM	TATA spare parts
886383000515	FRAME-HD P/PACK	TATA spare parts
886383000516	CON ROD BEARING(LOWER)	TATA spare parts
886383000517	GASKET-C/CASE COVER	TATA spare parts
886383000518	GASKET-CYL HEAD	TATA spare parts
886383000519	GASKET-VALVE PLATE	TATA spare parts
886383000520	GASKET-BASE	TATA spare parts
886383000521	GASKET-SVE V/V SUC	TATA spare parts
886383000522	EVAP CASE ASSY	TATA spare parts
886383000523	COND. CASE ASSY	TATA spare parts
886383000524	COND CASE	TATA spare parts
886383000525	LIQ HOSE(1)	TATA spare parts
886383000526	LIQ HOSE(2)	TATA spare parts
886383000527	LIQ PIPE	TATA spare parts
886383000528	EVAP COIL - LH AND RH	TATA spare parts
886383000529	MID WIRE	TATA spare parts
886383000530	EXPANSION VALVE	TATA spare parts
886383000531	AC COMPRESSOR BELT BS6	TATA spare parts
886383000532	WIPER MOTOR BS6	TATA spare parts
886383000533	AIR FILTER	TATA spare parts
886383000562	BLOWER UNIT	TATA spare parts
886383000563	CONDENSER FAN MOTOR	TATA spare parts
886383000564	HEATER UNIT NM627001 BS6-PH2	TATA spare parts
886383000565	COOLANT PUMP RU464001 BS6-PH2	TATA spare parts
886383000566	HOSE PUMP INLET BS6-PH2	TATA spare parts
886383000567	HOSE PUMP OUTLET BS6-PH2	TATA spare parts
886383000568	HEATER HOSE 5/8 INCH 1560 MM BS6-PH2	TATA spare parts
886383000569	HEATER HOSE 5/8 INCH 2440 MM BS6-PH2	TATA spare parts
886383000570	JUBILEE CLIPS BS6-PH2	TATA spare parts
886383000571	UNION 5/8 BS6-PH2	TATA spare parts
886383000572	O-RINGS 5/8 BS6-PH2	TATA spare parts
886383000573	O-RINGS 1/2 BS6-PH2	TATA spare parts
886383000574	SWITCH ON-OFF WITH ILLUMINATION BS6-PH2	TATA spare parts
886383000575	CORE CONDENSER ASSY	TATA spare parts
886383960001	A/C LOUVER WITH READING LAMP	TATA spare parts
886383960002	WIPER SYSTEM KIT 24V	TATA spare parts

886383960003	FORCED AIR CIRCULATION VENTILATOR-SALOON	TATA spare parts
886386000001	ASSY STRETCHER 3200 WB. W/ BASE FRAME BS	TATA spare parts
886386000002	ASSY STRETCHER 3488 WB. W/ BASE FRAME BS	TATA spare parts
886386000003	ASSEMBLY STRETCHER W/O BASE FRAME BS6	TATA spare parts
886386000004	3488 WB AMBULANCE BASE FRAME ASSY BS6	TATA spare parts
886386000005	3200 WB AMBULANCE BASE FRAME ASSY BS6	TATA spare parts
886386000006	HEAD REST ASSY BS6	TATA spare parts
886386000007	FOOT REST ASSY BS6	TATA spare parts
886386000008	MAIN FRAME WELDING ASSY BS6	TATA spare parts
886386000009	LEG FOLDING ASSY-1 BS6	TATA spare parts
886386000010	LEG FOLDING ASSY-2 BS6	TATA spare parts
886386000011	MTG BRACKET ASSY-1 BS6	TATA spare parts
886386000012	MTG BRACKET ASSY LH/RH BS6	TATA spare parts
886386000013	LEG FOLDING ASSY LH/RH BS6	TATA spare parts
886386000014	LEG FOLDING ASSY-4 BS6	TATA spare parts
886386000015	FRONT LEG ASSY BS6	TATA spare parts
886386000016	REAR LEG ASSY BS6	TATA spare parts
886386000017	LIVER ASSY BS6	TATA spare parts
886386000018	GUIDE WHEEL LOCKING ROD ASSY BS6	TATA spare parts
886386000019	HEAD REST LOCKING CYLINDER ASSY BS6	TATA spare parts
886386000020	CONNECTING ROD BS6	TATA spare parts
886386000021	BRACKET BS6	TATA spare parts
886386000022	BRACKET BS6	TATA spare parts
886386000023	FRONT LOCK ASSY BS6	TATA spare parts
886386000024	WHEEL BRACKET ASSY -1 BS6	TATA spare parts
886386000025	WHEEL BRACKET ASSY -2 BS6	TATA spare parts
886386000026	GUIDE WHEEL BRACKET BS6	TATA spare parts
886386000027	FOOT REST ADJUSTING BAR ASSY BS6	TATA spare parts
886386000028	SPRING LH BS6	TATA spare parts
886386000029	SPRING RH BS6	TATA spare parts
886386000030	SIDE HANDLE BS6	TATA spare parts
886386000031	SPRING LOADED PLUNGER BS6	TATA spare parts
886386000032	SALINE STAND ASSY BS6	TATA spare parts
886386000037	MATTRESS BS6	TATA spare parts
886386000038	PULLING ROD BS6	TATA spare parts
886386000039	LOCKING PLATE BS6	TATA spare parts
886386000040	COVER PANEL BS6	TATA spare parts
886386000041	BRACKET ASSY BS6	TATA spare parts
886386000042	BRACKET BS6	TATA spare parts
886386000043	PULLING PLASTIC KNOB BS6	TATA spare parts
886386000044	BUSH BS6	TATA spare parts
886386000045	PVC REAR LEG SUPPORT RED BS6	TATA spare parts
886386000046	PVC FRONT LEG SUPPORT GREEN BS6	TATA spare parts
886386960001	FIRE EXTINGUISHER	TATA spare parts
886387000001	BELT GUARD	TATA spare parts
886387000002	BUTTERFLY VALVE 4 IN	TATA spare parts
886387000003	MONITOR FLAPPER & FLAPPER LEVER SHORT	TATA spare parts

88638700004	DOOR BREAKER -01PC	TATA spare parts
88638700005	HOSE SLINGS -02 PCS	TATA spare parts
88638700006	PUSH PULL CABLE	TATA spare parts
88638700007	ASSY. TAIL GATE	TATA spare parts
88638700008	TIPPER BODY ASSEMBLY ç 14 CUM BOX TIPPER	TATA spare parts
88638700009	MOTOR HOOD	TATA spare parts
88638700010	PLASTICç PIPE FOR AM 6 SHN WATER TANK	TATA spare parts
88638700011	SCREW IN HEAD(VALVE DN15)	TATA spare parts
88638700012	SLIDING PART CPL	TATA spare parts
88638700013	MIXER DRUM 6M3 GB VERSION RH	TATA spare parts
88638700014	ENGINE MOUNTING	TATA spare parts
88638700015	MUDGUARDç CPL	TATA spare parts
88638700016	CHARGING HOPPER C VERSION	TATA spare parts
88638700017	EXTENSION CHUTE WITH ATTACHMENT	TATA spare parts
88638700018	SUPPORT ARM C	TATA spare parts
88638700019	LADDER CPL RH C VERSION	TATA spare parts
88638700020	WATER PIPELINE AT THE DISCHARGE SUPPORT	TATA spare parts
88638700021	REMOTEç CONTROL ASSEMBLY	TATA spare parts
88638700033	TOW HITCH ASSY	TATA spare parts
88638700033AE	TOW HITCH ASSY	TATA spare parts
88638700040	TIPPER BODY W/O HYDRAULIC KIT	TATA spare parts
88638700041	PARALLEL AXIS PTO	TATA spare parts
88638700042	TANK ASSLY 35 LTR (LPK-909)	TATA spare parts
88638700043	3FT FRONT PANEL	TATA spare parts
88638700044	3FT LH SIDE PANEL	TATA spare parts
88638700045	SIDE WINDOW FOR 3FT LH SIDE PANEL	TATA spare parts
88638700046	TARPAULIN BOX	TATA spare parts
88638700047	SIDE COVER (FRONT) LH ASSY.	TATA spare parts
88638700048	SIDE COVER (FRONT) RH ASSY.	TATA spare parts
88638700049	SIDE COVER (REAR) LH ASSY.	TATA spare parts
88638700050	SIDE COVER (REAR) RH ASSY.	TATA spare parts
88638700051	MUD FLAP HINGE ASSY.	TATA spare parts
88638700052	PIPE FRAME ASSY.	TATA spare parts
88638700053	RAIN FLAP MIDDLE LH (1085X615MM)	TATA spare parts
88638700054	RAIN FLAP MIDDLE RH (1085X615MM)	TATA spare parts
88638700055	RAIN FLAP REAR LH (960X615MM)	TATA spare parts
88638700056	RAIN FLAP REAR RH (960X615MM)	TATA spare parts
88638700057	RAIN FLAP SIDE FRONT (1535X100MM)	TATA spare parts
88638700058	RAIN FLAP SIDE REAR (1330X100MM)	TATA spare parts
88638700059	SUBFRAME ASSY	TATA spare parts
88638700060	CRADLE & OIL TANK BKT ASSY	TATA spare parts
88638700061	ATTACHMENT PLATE (REAR)	TATA spare parts
88638700062	ATTACHMENT PLATE-3	TATA spare parts
88638700063	ATTACHMENT PLATE-4	TATA spare parts
88638700064	ATTACHMENT PLATE-2	TATA spare parts
88638700065	UPPER ATTACHMENT PIVOT	TATA spare parts
88638700066	ATTACHMENT PIVOT-1	TATA spare parts

886387000067	ATTACHMENT PIVOT-2	TATA spare parts
886387000068	ATTACHMENT PIVOT-3	TATA spare parts
886387000069	Rear Rain flap with Hinge	TATA spare parts
886387000070	MUD GUARD PLASTIC	TATA spare parts
886387000071	MUD FLAP	TATA spare parts
886387000072	TAIL GATE	TATA spare parts
886387000073	MUD FLAP BIG	TATA spare parts
886387000074	MUD FLAP SMALL	TATA spare parts
886387000075	ASSY. TIPPER BODY	TATA spare parts
886387000076	ASSLY BOX TIPPER W/O HYDRAULIC KIT	TATA spare parts
886387000077	R6 REALY VALVE	TATA spare parts
886387000078	REINFORCED TAILDOOR ASSY	TATA spare parts
886387000079	SINGLE NUT - STUB AXLE	TATA spare parts
886387000080	ASSY COMPLETE TIPPER BODY W/O HYDRAULICS	TATA spare parts
886387000081	TAIL GATE	TATA spare parts
886387000082	TAIL GATE	TATA spare parts
886387000083	HIGH DECK LOADBODY	TATA spare parts
886387000084	REAR AXLE DLT TRAILER	TATA spare parts
886387000085	RUPD	TATA spare parts
886387000086	SPRING BRAKE ACTUATOR TYPE 30/30	TATA spare parts
886387000087	AIR FILTER (BREATHER)	TATA spare parts
886387000088	RETURN LINE FILTER ELEMENT KIT 150 L 25	TATA spare parts
886387000089	REAR HINGE BRACKET ASSY	TATA spare parts
886387000090	REAR HINGE BRACKET PLATE	TATA spare parts
886387000091	REAR HINGE SHAFT	TATA spare parts
886387000092	REAR HINGE STEEL BUSH	TATA spare parts
886387000093	REAR HINGE BEARING BUSH	TATA spare parts
886387000094	REAR HINGE INNER BUSH (WITHOUT GROOVE)	TATA spare parts
886387000095	REAR HINGE OUTER BUSH (WITH GROOVE)	TATA spare parts
886387000096	REAR HINGE BRACKET REINFORCEMENT FLAT	TATA spare parts
886387000097	REAR HINGE LOCKING PIN	TATA spare parts
886387000098	REAR HINGE SHAFT SNAP RING	TATA spare parts
886387000099	WASHER 6 MM RUBBER FOR NOZZLE	TATA spare parts
886387000100	NOZZLE AL	TATA spare parts
886387000101	BARREL 75 X 1200 MM AL	TATA spare parts
886387000102	BOLT HEX HD. M6-12 MS GAL	TATA spare parts
886387000103	PTO PUMP HYDRAULIC 82CC	TATA spare parts
886387000104	TAILDOOR HINGE ASSY	TATA spare parts
886387000105	PTO UNIT	TATA spare parts
886387000106	TAIL GATE HINGE PIN 110X24.75MM	TATA spare parts
886387000107	TAIL GATE HINGE PIN COLLAR WITH HOLE 20X	TATA spare parts
886387000108	SUB FRAME ASSEMBLY	TATA spare parts
886387000109	TAIL DOOR L-PLATE	TATA spare parts
886387000110	BLOCK MOUNTING ASSY	TATA spare parts
886387000111	TIE ROD ASSY	TATA spare parts
886387000112	CROSS ROD	TATA spare parts
886387000113	CAM-MECH TAIL DOOR LOCKING MECHANISM	TATA spare parts

886387000114	MECH TAIL DOOR LOCKING MECHANISM-LOCKING	TATA spare parts
886387000115	STOPPER WASHER M30	TATA spare parts
886387000116	SPRING MOUNTING PLATE-1	TATA spare parts
886387000117	SPRING MOUNTING PLATE-2	TATA spare parts
886387000118	TIPPER BODY 14 CUM BOX	TATA spare parts
886387000119	SUB FRAME ASSEMBLY -16 CUM. HD	TATA spare parts
886387000120	TAIL DOOR ASSY WITH L-PLATE REINF.	TATA spare parts
886387000121	SPECIAL RUBBER HOSE PIPE	TATA spare parts
886387000122	TIPPER BODY 10 CUM BOX (WITHOUT SUB FRAM	TATA spare parts
886387000123	REAR MUDGAURD	TATA spare parts
886387000124	PULLING PIPE 775	TATA spare parts
886387000125	TENSION SPRING	TATA spare parts
886387000126	TIE ROD	TATA spare parts
886387000127	ASSY LOAD BODY	TATA spare parts
886387000128	SUB FRAME 18 CUM STD LPK 3118	TATA spare parts
886387000129	ATTACHMENT PLATE BIG	TATA spare parts
886387000130	ATTACHMENT PLATE SMALL	TATA spare parts
886387000131	LEVER BRACKET	TATA spare parts
886387000132	LEVER BRACKET GUSSET	TATA spare parts
886387000133	LOWER JACK	TATA spare parts
886387000134	SUCTION HOSE (1 IN ID X 950 L)	TATA spare parts
886387000135	RETURN LINE HOSE (1IN ID X 760 L)	TATA spare parts
886387000136	PRESSURE HOSE (3/4IN ID X 1100 L)	TATA spare parts
886387000137	STABILIZER ASSY (LADDER ASSY)¿ FOR 18 CU	TATA spare parts
886387000138	O-RING (D. C.¿ VALVE)	TATA spare parts
886387000139	ASSY LOAD BODY	TATA spare parts
886387000140	RUBBER PAD FRONT¿ 200X72X30	TATA spare parts
886387000141	RUBBER PAD REAR 200X72X25	TATA spare parts
886387000142	RETURN LINE HOSE	TATA spare parts
886387000143	TIPPER BODY	TATA spare parts
886387000144	SUB FRAME	TATA spare parts
886387000145	ASSY. REAR MUD FLAP	TATA spare parts
886387000146	TIPPER BODY 16 CUM.BOX (WITHOUT HYDRAULI	TATA spare parts
886387000147	TIPPER BODY WITHOUT HYDRAULICS	TATA spare parts
886387000148	REAR MUD FLAP	TATA spare parts
886387000149	SUBFRAME ASSY	TATA spare parts
886387000150	SUBFRAME WITH FITMENTS 8.5CUM	TATA spare parts
886387000151	LOAD BODY WITH HYDRAULIC KIT	TATA spare parts
886387000152	JACK BRACKET COUPLING	TATA spare parts
886387000153	SUBFRAME ASSLY	TATA spare parts
886387000154	SUBFRAME RH	TATA spare parts
886387000155	SUBFRAME LH	TATA spare parts
886387000156	SIDE SKIRT PLATE -1 (1542)	TATA spare parts
886387000157	SIDE SKIRT PLATE - 2 (1336)	TATA spare parts
886387000158	SIDE SKIRT PLATE CLOSER	TATA spare parts
886387000159	SKIRT SUPPORT	TATA spare parts
886387000160	SUB FRAME	TATA spare parts

886387000161	HYDRALIC PUMP	TATA spare parts
886387000162	LP HOSE 1 3/4IN (1700 MM)	TATA spare parts
886387000163	HP HOSE 2SN3/4 ID (1830 MM)	TATA spare parts
886387000164	ASSEMBLY SIDE BOARD FLAP LH /RH	TATA spare parts
886387000165	PRESSURE HOSE	TATA spare parts
886387000166	AERATION HOSE (25CBM)	TATA spare parts
886387000167	SUB FRAME ASSEMBLY	TATA spare parts
886387000168	TIPPER BODY ASSY. (WITH SUB FRAME & WITH	TATA spare parts
886387000169	TIPPER BODY ASSY. (WITHOUT SUB FRAME & W	TATA spare parts
886387000170	ALUMINIUM PACKING	TATA spare parts
886387000171	ASSY TAIL DOOR	TATA spare parts
886387000172	CONCRETE MIXER AM6SHN2 RH VERSION	TATA spare parts
886387000173	REAR LOAD BODY TAIL GATE DOOR ASSY	TATA spare parts
886387000174	SUBFRAME MOUNTING KIT (LPK 3118SLEEPER C	TATA spare parts
886387000175	FLOOR REINFORCEMENT PLATE COMPLETE SET	TATA spare parts
886387000176	TAIL DOOR ½½ PLATE 25MM	TATA spare parts
886387000177	FLOOR CROSS MEMBER (TUBE-80X80X3.2MM)	TATA spare parts
886387000178	TAIL DOOR PIN (40X25X95MM)	TATA spare parts
886387000179	MS SPACER (40X25X10MM)	TATA spare parts
886387000180	SPLIT PIN (8X65MM)	TATA spare parts
886387000181	FUEL FILTER ELEMENT	TATA spare parts
886387000182	V-BELT	TATA spare parts
886387000183	OIL FILTER	TATA spare parts
886387000184	CRADLE & OIL TANK BRACKET ASSY.	TATA spare parts
886387000185	STABILIZER ASSY.	TATA spare parts
886387000186	REAR HINGE BUSH (OD80/ID50 LENGTH-90MM)	TATA spare parts
886387000187	REAR HINGE OUTER BUSH(OD80/ID50 LEN50MM)	TATA spare parts
886387000188	REAR HINGE INNER BUSH(OD80/ID50 LEN50MM)	TATA spare parts
886387000189	CIRCLIP (4 X 60MM)	TATA spare parts
886387000190	GREASE NIPPLE M10	TATA spare parts
886387000191	M. S SHAFT 50X985	TATA spare parts
886387000192	ASSY FUEL TANKER ON LPT1613	TATA spare parts
886387000193	SUB FRAME WITH LOCKING MECHANISM ASSEMB	TATA spare parts
886387000194	ASSY LOAD BODY WITH SUB-FRAME WITHOUT HY	TATA spare parts
886387000195	TAIL LAMP BKT	TATA spare parts
886387000196	HP. HOSE 3/4IN (LENGTH 1380 MM)	TATA spare parts
886387000197	HP HOSE 3/4 IN ID (1860 MM)	TATA spare parts
886387000198	FLOOR CROSS MEMBER	TATA spare parts
886387000199	FLOOR REINFORCEMENT PLATE SET	TATA spare parts
886387000200	TIPPER BODY ASSY WITH SUB FRAME&CRADLE	TATA spare parts
886387000201	PULLING PIPE ASSLY	TATA spare parts
886387000202	SUBFRAME ASSEMBLY - 20 CUM BOX	TATA spare parts
886387000203	CAM TAIL DOOR LOCKING MECHANISM	TATA spare parts
886387000204	SUBFRAME ASSY WITH CRADLE & ALL MOUNTING	TATA spare parts
886387000205	AIR CLEANER	TATA spare parts
886387000206	RUBBER-ENG.OIL HOSE	TATA spare parts
886387000207	CENTER BOLT (8 LEAF)	TATA spare parts

886387000208	AIR RECEIVER TANK 40 LTR WITH DRAIN VALV	TATA spare parts
886387000209	TIPPER BODY COMPLETE WITHOUT HYDRAULIC K	TATA spare parts
886387000210	PULLING PIPE	TATA spare parts
886387000211	PULLING PIPE FORK PIN	TATA spare parts
886387000212	SEAL KIT	TATA spare parts
886387000213	BODY ASSEMBLY	TATA spare parts
886387000214	ASSY. CAM PROFILE BUSH FOR 16 CUM PRIMA	TATA spare parts
886387000215	PULLING PIPE ASSEMBLY	TATA spare parts
886387000216	HOOK ASSEMBLY (LH)	TATA spare parts
886387000217	TENSION SPRING	TATA spare parts
886387000218	SKELETAL CHASSIS FRAME	TATA spare parts
886387000219	HYD .KIT	TATA spare parts
886387000220	FLANGE FOR DIRECT DRIVE	TATA spare parts
886387000221	HALF ROUND KEY	TATA spare parts
886387000222	LOAD BODY COMPLETE WITH TIPPING SYSTEM	TATA spare parts
886387000223	BODY ASSEMBLY	TATA spare parts
886387000224	BOX BODY	TATA spare parts
886387000225	SUB FRAME ASSEMBLY	TATA spare parts
886387000226	TAIL DOOR ASSY	TATA spare parts
886387000227	MUD GUARD ASSY	TATA spare parts
886387000228	BODY PROB ASSEMBLY	TATA spare parts
886387000229	REAR HINGE PROFILE PLATE	TATA spare parts
886387000230	REAR HINGE BKT	TATA spare parts
886387000231	REAR HINGE BUSH ASSY	TATA spare parts
886387000232	LINK ROD	TATA spare parts
886387000233	HOPPER BODY ( WITHOUT HYD. KIT & SUB FRA	TATA spare parts
886387000234	SUBFRAME ASSLY	TATA spare parts
886387000235	TARPAULIN ASSLY	TATA spare parts
886387000236	BODY PROP BUSH	TATA spare parts
886387000237	BODY PROP PIN	TATA spare parts
886387000238	CYLINDER MTG.TOP PIN	TATA spare parts
886387000239	CYLINDER MTG.BOTTOM PIN	TATA spare parts
886387000240	REAR HINGE PIN	TATA spare parts
886387000241	REAR HINGE PIN COLLER	TATA spare parts
886387000242	HOUSING	TATA spare parts
886387000243	CONTROL LEVER	TATA spare parts
886387000244	EXTERNAL GEAR Z=36	TATA spare parts
886387000245	INTERNAL GEAR	TATA spare parts
886387000246	SLEEVE	TATA spare parts
886387000247	CENTRAL SHAFT	TATA spare parts
886387000248	WEAR PLATES	TATA spare parts
886387000249	PIN	TATA spare parts
886387000250	BUSH	TATA spare parts
886387000251	GASKET	TATA spare parts
886387000252	BRACKET	TATA spare parts
886387000253	SPRING	TATA spare parts
886387000254	STUD 8X20	TATA spare parts

886387000255	PLUG M22X1.5 DIN 908	TATA spare parts
886387000256	BEARING	TATA spare parts
886387000257	COVER	TATA spare parts
886387000258	BEARING	TATA spare parts
886387000259	SEAL	TATA spare parts
886387000260	Q-RING	TATA spare parts
886387000261	BALL 7/32IN	TATA spare parts
886387000262	O-RING	TATA spare parts
886387000263	DOWEL PIN	TATA spare parts
886387000264	SHAFT SLEEVE(JOINT)	TATA spare parts
886387000265	GEAR PUMP	TATA spare parts
886387000266	SKELETAL CHASSIS FRAME	TATA spare parts
886387000267	TIPPER BODY ASSLY (W/O KIT & SUB FRAME)	TATA spare parts
886387000268	CAM PIN (25X16X87MM)	TATA spare parts
886387000269	TAIL GATE ASSY	TATA spare parts
886387000270	TAIL GATE HINGE LH /RH	TATA spare parts
886387000271	TIPPER BODY ASSLY EXCLUDING HYD. KIT & S	TATA spare parts
886387000272	TIPPER BODY ASSEMBLY[W/O SUBFRAME /CRADLE]	TATA spare parts
886387000273	REAR WHEEL ARCH RH	TATA spare parts
886387000275	LOAD BODY ASSY(EXCLUDING SUB-FRAME & HYDRAULIC)	TATA spare parts
886387000276	ASSY LOAD BODY HSD ON LPT 407/38WB	TATA spare parts
886387000277	TIPPER BODY - 16 CUM HD BOX (LPK 2518)	TATA spare parts
886387000278	TAIL GATE ASSY	TATA spare parts
886387000279	HYDRAULIC CYLINDER	TATA spare parts
886387000280	TUBE & SINGLE ACTING HYDRAULIC CYLINDER	TATA spare parts
886387000281	PISTON ROD & SINGLE ACTING HYDRAULIC CYL	TATA spare parts
886387000282	PISTON & SINGLE ACTING HYDRAULIC CYLINDER	TATA spare parts
886387000283	HEAD END COVER & SINGLE ACTING HYDRAULIC	TATA spare parts
886387000284	SEAL KIT - HYDRAULIC CYLINDER	TATA spare parts
886387000285	HYDRAULIC TANK & SINGLE ACTING HYDRAULIC	TATA spare parts
886387000286	LOAD BODY BOX SHAPED LPT 1109	TATA spare parts
886387000287	SPARE COMPLETE CYLINDER	TATA spare parts
886387000288	BULKER UNIT ASSY 27 CM3 - LPT 3118	TATA spare parts
886387000289	SUBFRAME ASSEMBLY	TATA spare parts
886387000290	STABILIZER ASSEMBLY	TATA spare parts
886387000291	TAIL DOOR ASSY	TATA spare parts
886387000292	REAR HINGE PIN	TATA spare parts
886387000293	PUMP 84D	TATA spare parts
886387000294	SINGLE SPOOL VALVE	TATA spare parts
886387000295	SUB FRAME ASSY	TATA spare parts
886387000296	SUBFRAME ASSLY	TATA spare parts
886387000297	SUBFRAME ASSEMBLY -18 CUM HD BOX (LPK311)	TATA spare parts
886387000298	20FT CONTAINER (7.4W)	TATA spare parts
886387000299	CRADLE ASSEMBLY	TATA spare parts
886387000300	CRADLE ASSEMBLY	TATA spare parts
886387000301	SUB FRAME ASSLY (EXCLUDING CRADLE ASSEMBLY)	TATA spare parts
886387000302	LOAD BODY ASSEMBLY(EXCLUDING CRADLE HYDRAULIC)	TATA spare parts



886387000303	5 CUM CUBED BODY (WITHOUT SUB FRAME HYD.	TATA spare parts
886387000304	PULLING PIPE ASSY. FOR 18 CUM BOX TYPE L	TATA spare parts
886387000305	SUB FRAME ASSLY	TATA spare parts
886387000306	REAR HINGE BUSH ASSY	TATA spare parts
886387000307	COMPLETE BULKER BODY	TATA spare parts
886387000308	PIPE FRAME ASSY	TATA spare parts
886387000309	2ND AXLE MUDGUARD LH	TATA spare parts
886387000310	2ND AXLE MUDGUARD RH	TATA spare parts
886387000311	HOOK ASSY.¿ (LHS)	TATA spare parts
886387000312	HOOK ASSY.¿ (RHS)	TATA spare parts
886387000313	PULLING PIPE ASSY	TATA spare parts
886387000314	16 CUM. STD. TIPPER ASSY	TATA spare parts
886387000315	CRADLE ASSEMBLY	TATA spare parts
886387000316	STABILIZER ASSEMBLY	TATA spare parts
886387000317	DROP SIDE LOAD BODY COMPLETE	TATA spare parts
886387000318	IPH PTO-GB 55	TATA spare parts
886387000319	TIE ROD ASSY 4.5	TATA spare parts
886387000320	LOWER FRAME ASSEMBLY	TATA spare parts
886387000321	LOWER FRAME ASSEMBLY	TATA spare parts
886387000322	R/H PIN 60X135	TATA spare parts
886387000323	SWITCH BOX ASSEMBLY	TATA spare parts
886387000324	WATER TANK	TATA spare parts
886387000325	EXHAUST PIPE CONNECT	TATA spare parts
886387000327	CAM MOUNTING ASSEMBLY	TATA spare parts
886387000328	HAMMER ASSEMBLY (LH)	TATA spare parts
886387000329	HAMMER ASSEMBLY (RH)	TATA spare parts
886387000330	PIN FOR CAM MOUNTING	TATA spare parts
886387000331	FORK PIN	TATA spare parts
886387000332	CAM BUSH	TATA spare parts
886387000333	PULLING PIPE ASSEMBLY 1800	TATA spare parts
886387000334	TENSION SPRING	TATA spare parts
886387000335	SPRING MOUNTING HOOK	TATA spare parts
886387000336	CHASSIS¿24¿CUM TT	TATA spare parts
886387000337	COMPLETE¿BODY¿24¿CUM TT	TATA spare parts
886387000338	CRADLE ASSEMBLY FOR 16 CUM HD	TATA spare parts
886387000339	SUBFRAME MOUNTING KIT 16 CUM HD	TATA spare parts
886387000340	COMPLETE LOAD BODY ASSY. (BODY+SUBFRAME-	TATA spare parts
886387000341	TAIL DOOR ASSY (WITHOUT¿LOCKING MECHANIS	TATA spare parts
886387000342	10 CUM SK-42 W/O HYDRAULIC KIT	TATA spare parts
886387000343	10 CUM SK-42 W/O HYDRAULIC KIT & W/O SUB	TATA spare parts
886387000344	HYDRAULIC KIT GHS155-4-4520 C W/O PUMP C	TATA spare parts
886387000345	PULLING PIPE ASSY	TATA spare parts
886387000346	TENSION SPRING	TATA spare parts
886387000347	HOOK ASSEMBLY (LH)	TATA spare parts
886387000348	HOOK ASSEMBLY (RH)	TATA spare parts
886387000349	MUDGAURD	TATA spare parts
886387000350	RUBBER PAD	TATA spare parts

886387000351	PRESSURE GUAGE	TATA spare parts
886387000352	PRESSURE RELIEF VALVE (SAFETY VALVE)	TATA spare parts
886387000353	BUTTERFLY VALVE DN 50	TATA spare parts
886387000354	NON RETURN VALVE 2 1/2INCH	TATA spare parts
886387000355	BUTTERFLY VALVE DN 125	TATA spare parts
886387000356	BRADED HOSE PIPE WP20BAR	TATA spare parts
886387000357	HOSE CLAMP FOR 74MM OD	TATA spare parts
886387000358	HOSE CLAMP FOR 94MM OD	TATA spare parts
886387000359	RAIN FLAP ONLY WITHOUT PIPE FRAME LH	TATA spare parts
886387000360	RAIN FLAP ONLY WITHOUT PIPE FRAME RH	TATA spare parts
886387000361	RAIN FLAP ONLY WITHOUT SIDE SKIRT	TATA spare parts
886387000362	TAIL DOOR ASSEMBLY	TATA spare parts
886387000363	REFLECTIVE TAPE FOR TAIL DOOR VERTICAL	TATA spare parts
886387000364	REFLECTIVE TAPE FOR TAIL DOOR HORIZONTAL	TATA spare parts
886387000365	COMPRESSOR	TATA spare parts
886387000366	PROPELLER SHAFT ASSEMBLY	TATA spare parts
886387000367	SUBFRAME ASSEMBLY -18 CUM HD BOX (LPK311	TATA spare parts
886387000368	TIPPER BODY ASSEMBLY[W/O HYD & SUBFRAME	TATA spare parts
886387000369	ASSY. LOAD BODY WITHOUT SUBFRAME ¿FOR 18	TATA spare parts
886387000370	SUBFRAME ASSY. WITH INCLUDING ALL MOUNTI	TATA spare parts
886387000371	REAR HINGE BUSH ASSY.	TATA spare parts
886387000372	REAR HINGE SHAFT	TATA spare parts
886387000373	REAR HINGE INNER BUSH	TATA spare parts
886387000374	REAR HINGE OUTER BUSH	TATA spare parts
886387000375	REAR HINGE LOCKING PIN	TATA spare parts
886387000376	SUBFRAME ASSEMBLY -16 CUM HD BOX (LPK 25	TATA spare parts
886387000377	PULLING PIPE ASSEMBLY 1950 MM	TATA spare parts
886387000378	CRADDLE ASSY 24 CUM TT	TATA spare parts
886387000379	EXTENSION RAM	TATA spare parts
886387000380	GUIDE	TATA spare parts
886387000381	GUIDE	TATA spare parts
886387000382	GUIDE BLOCK	TATA spare parts
886387000383	GUIDE BLOCK	TATA spare parts
886387000384	ASSY. LOAD BODY WITHOUT SUBFRAME & KIT (	TATA spare parts
886387000385	SUBFRAME ASSEMBLY	TATA spare parts
886387000386	ENGINE - CONCRETE MIXER-04.1	TATA spare parts
886387000387	FAN BLADE	TATA spare parts
886387000388	CRADLE ASSEMBLY WITH OIL TANK BRACKET	TATA spare parts
886387000389	TIPPER BODY ASSEMBLY -14 CUM BOX (LPK 25	TATA spare parts
886387000390	TIPPER BODY ASSEMBLY -14 CUM BOX (LPK 25	TATA spare parts
886387000391	HYDRAULIC KIT - 14 CUM BOX (LPK 2518/38)	TATA spare parts
886387000392	TAIL LAMP BKT LH	TATA spare parts
886387000393	TAIL LAMP BKT RH	TATA spare parts
886387000394	TAIL DOOR ASSEMBLY	TATA spare parts
886387000395	TAIL DOOR HINGE ASSY LH	TATA spare parts
886387000396	TAIL DOOR HINGE ASSY RH	TATA spare parts
886387000397	CRADLE ASSEMBLY	TATA spare parts

886387000398	BODY GUIDE	TATA spare parts
886387000399	BODY PROP ASSEMBLY	TATA spare parts
886387000400	BODY PROP PIN ASSEMBLY	TATA spare parts
886387000401	V-BELTS AX-46	TATA spare parts
886387000402	LOAD BODY(W/O SUBFRAME & HYD. KIT.)	TATA spare parts
886387000403	LOAD BODY 18 C.UM TIPPER ON LPK 3118/56	TATA spare parts
886387000404	SUBFRAME ASSEMBLY	TATA spare parts
886387000405	LOAD BODY 18 C.UM TIPPER ON LPK 3118/56	TATA spare parts
886387000406	SUBFRAME ASSY( 24 CUM BOX TIPPER)	TATA spare parts
886387000407	ATTACHMENT PLATE-4 (4 HOLES)	TATA spare parts
886387000408	UPPER PIVOT	TATA spare parts
886387000409	BODY GUIDE	TATA spare parts
886387000410	BODY PROP ASSY	TATA spare parts
886387000411	BODY PROP REST ASSY.	TATA spare parts
886387000412	PIVOT SRPING	TATA spare parts
886387000413	HEX BOLT M16X150 - 10.9	TATA spare parts
886387000414	FRONT MUDGUARD ASSY LH/RH	TATA spare parts
886387000415	HAMMER ASSY LH/RH	TATA spare parts
886387000416	REAR HINGE SHAFT	TATA spare parts
886387000417	TROOP CARRIER	TATA spare parts
886387000418	ACCELERATOR THROTTLE WIRE	TATA spare parts
886387000419	MOUNTING KIT	TATA spare parts
886387000420	ASSY LOAD BODY (LOAD BODY + SUBFRAME+ MO	TATA spare parts
886387000421	REAR MUD FLAP ASSY LH	TATA spare parts
886387000422	REAR MUD FLAP ASSY RH	TATA spare parts
886387000423	PULLING PIPE ASSY 2050	TATA spare parts
886387000424	SUBFRAME ASSEMBLY -16 CUM HD BOX (LPK251	TATA spare parts
886387000425	5CUM912SUBFRAMEASSEMBLY	TATA spare parts
886387000426	BRAKEDRUM	TATA spare parts
886387000427	BULK TANK WITH SUPPORT	TATA spare parts
886387000428	CENTRIFUGAL WATER PUMP	TATA spare parts
886387000429	V - BELT - A49	TATA spare parts
886387000430	SEAL KIT	TATA spare parts
886387000431	SIDE SKIRT RAIN FLAP LH	TATA spare parts
886387000432	SIDE SKIRT RAIN FLAP RH	TATA spare parts
886387000433	RAIN FLAP REAR LH	TATA spare parts
886387000434	RAIN FLAP REAR RH	TATA spare parts
886387000435	PIPE FRAME ASSLY LH	TATA spare parts
886387000436	PIPE FRAME ASSLY RH	TATA spare parts
886387000437	FRONT MUDGUARD LH	TATA spare parts
886387000438	FRONT MUDGUARD RH	TATA spare parts
886387000439	SUBFRAME ASSY	TATA spare parts
886387000440	GASKET	TATA spare parts
886387000441	3CUM LPK 407 SUBFRAME ASSEMBLY	TATA spare parts
886387000442	LOAD BODY ASSLY (EXCLUDING SUBFRAME ASS	TATA spare parts
886387000443	BRAKE CHAMBER	TATA spare parts
886387000444	SIDE SKIRT RAIN FLAP RH	TATA spare parts

886387000445	SIDE SKIRT PLATE ASSY	TATA spare parts
886387000446	SIDE PANEL LH/RH ASSLY. (5CUM-912)	TATA spare parts
886387000447	TAIL GATE	TATA spare parts
886387000448	LOAD BODY COMPLETE	TATA spare parts
886387000449	LOAD BODY	TATA spare parts
886387000450	KIT BRAKE DRUM	TATA spare parts
886387000451	KIT HUB	TATA spare parts
886387000452	KIT BRAKE SHOE	TATA spare parts
886387000453	KIT BRAKE LINING	TATA spare parts
886387000454	CHASSIS 26 CUM TT	TATA spare parts
886387000455	CRADLE ASSY 26 CUM TT	TATA spare parts
886387000456	COMPLETE BODY 26 CUM TT	TATA spare parts
886387000457	KTX17AF0K1950 AXLE 6	TATA spare parts
886387000458	LEAF SPRING (10 LEAF - 16MM THICK)	TATA spare parts
886387000459	U BOLT 450MM(YTE75/90)	TATA spare parts
886387000460	RELAY VALVE	TATA spare parts
886387000461	BODY ASSEMBLY	TATA spare parts
886387000462	SUB FRAME ASSEMBLY	TATA spare parts
886387000463	MUD GUARD ASSY	TATA spare parts
886387000464	BODY PROB ASSEMBLY	TATA spare parts
886387000465	BODY PROB ASSEMBLY	TATA spare parts
886387000466	BODY HINGE BUSH	TATA spare parts
886387000467	TAIL DOOR ASSY	TATA spare parts
886387000468	CYLINDER TOP MOUNTING PIN	TATA spare parts
886387000469	CYLINDER BOTTOM MOUNTING PIN	TATA spare parts
886387000470	UPPER FLAP SMALL TYPE	TATA spare parts
886387000471	UPPER FLAP BIG TYPE	TATA spare parts
886387000472	CYLINDER PIN SPACER	TATA spare parts
886387000473	PUSH PULL CABLE	TATA spare parts
886387000474	PTO DRIVEN PUMP WITH PUSH PULL CABLE	TATA spare parts
886387000475	HYDRAULIC KIT	TATA spare parts
886387000476	PRESSURE HOSE	TATA spare parts
886387000477	PRESSURE HOSE	TATA spare parts
886387000478	CYLINDER	TATA spare parts
886387000479	DC VALVE	TATA spare parts
886387000480	GASKET 0.4 MM	TATA spare parts
886387000481	COMPLETE FABRICATED CONTAINER	TATA spare parts
886387000482	MUDGUARD ASSY	TATA spare parts
886387000483	MOUNTINGKIT 10 CUM	TATA spare parts
886387000484	TAIL DOOR ASSY 16 CUMHD	TATA spare parts
886387000485	TAILDOOR ASSEMBLY	TATA spare parts
886387000486	CUBED BODY ASSLY	TATA spare parts
886387000487	SUBFRAME ASSLY	TATA spare parts
886387000488	TAIL DOOR HINGE `L & PLATE	TATA spare parts
886387000489	BODY MOUNTING KIT	TATA spare parts
886387000490	TIPPER BODY ASSEMBLY - 18 CUM HD BOX	TATA spare parts
886387000491	SPLIT PIN	TATA spare parts

886387000492	REAR HINGE SHAFT ASSLY	TATA spare parts
886387000493	REAR HINGE LOCKING PIN	TATA spare parts
886387000494	REAR HINGE SHAFT SNAP RING	TATA spare parts
886387000495	WIND DEFLECTOR TATA ACE	TATA spare parts
886387000496	SLACK ADJUSTER RETURN SPRING	TATA spare parts
886387000497	TAIL DOOR ASSLY	TATA spare parts
886387000498	COMPLETE LOAD BODY ASSY. 28 FEET X 3.5 F	TATA spare parts
886387000499	SHAFT REAR HINGE	TATA spare parts
886387000500	COTTER PIN	TATA spare parts
886387000501	SNAP RING	TATA spare parts
886387000502	TAIL DOOR LOCKING MECHANISM	TATA spare parts
886387000503	LOAD BODY PLAIN SHEET ASSY. (W/O CHASSIS	TATA spare parts
886387000504	CAM MOUNTING ASSEMBLY	TATA spare parts
886387000505	CAM ASSY	TATA spare parts
886387000506	LOCK HOOK ASSY LH/RH	TATA spare parts
886387000507	PULLING PIPE ASSY 1950	TATA spare parts
886387000508	CAM PIN/DIA.16X87	TATA spare parts
886387000509	FORK PIN	TATA spare parts
886387000510	SPLIT PIN (USED IN PULLING PIPE/CAM ASSY	TATA spare parts
886387000511	SPRING HOOK	TATA spare parts
886387000512	TENSION SPRING/DIA5MM X 300L X 25	TATA spare parts
886387000513	SUB FRAME ASSY	TATA spare parts
886387000514	SUBFRAME ASSY WITHOUT CRADLE & STABILIZE	TATA spare parts
886387000515	CRADLE ASSY	TATA spare parts
886387000516	STABILIZER ASSY	TATA spare parts
886387000517	SIDE SUPPRESSION SKIRT	TATA spare parts
886387000518	SIDE SUPPRESSION RAIN FLAP 100X2710	TATA spare parts
886387000519	18 CUM HD MOUNTING KIT	TATA spare parts
886387000520	REAR HINGE SHAFT(60X1020) & BUSH ASSY	TATA spare parts
886387000521	SPOOL VALVE	TATA spare parts
886387000522	HYDRAULIC CYLINDER FOR HOPPER	TATA spare parts
886387000523	HYDRAULIC CYLINDER FOR BIN TILTING	TATA spare parts
886387000524	HYDRAULIC CYLINDER FOR BIN LIFTING	TATA spare parts
886387000525	HYD. TANK	TATA spare parts
886387000526	MALE STUD COUPLING 22X1.1/2X16MM	TATA spare parts
886387000527	MALE STUD COUPLING 1/2INCH BSP	TATA spare parts
886387000528	SWIVEL ELLBOW 16 OD	TATA spare parts
886387000529	MALE STUD COUPLING 3/8INCH BSP	TATA spare parts
886387000530	HYDRAULIC GEAR PUMP	TATA spare parts
886387000531	EQUAL ELBOW 12S MALE	TATA spare parts
886387000532	CHAIN	TATA spare parts
886387000533	MUDGUARD	TATA spare parts
886387000534	HYDRAULIC PLIUG 3/8	TATA spare parts
886387000535	BIN KART	TATA spare parts
886387000536	STABILIZER	TATA spare parts
886387000537	BASE FRAME	TATA spare parts
886387000538	HOPPER BUCKET 1.8 CUM	TATA spare parts

886387000539	STARTER MOTOR	TATA spare parts
886387000540	BELT-TIMING	TATA spare parts
886387000541	TENSIONER TIMING BELT	TATA spare parts
886387000542	PUMP ASSY- WATER	TATA spare parts
886387000543	CRADLE ASSY 16 CUM HD	TATA spare parts
886387000544	ASSLY SUBFRAME 2.66CUM-SK-407-TIPPER	TATA spare parts
886387000545	TAIL DOOR ASSY WITH ACCESSORIES &PAINT	TATA spare parts
886387000546	24 CUM BOX TIP SIGNA 3718TK W/O HYDRAULI	TATA spare parts
886387000547	TIPPER BODY ASSEMBLY - 10 CUM BOX	TATA spare parts
886387000548	LOAD BODY ASSY	TATA spare parts
886387000549	REAR HUGE SHAFT WITH PIN 10X25/1000X50	TATA spare parts
886387000550	REAR HING BUSH ASSY.	TATA spare parts
886387000551	REAR HING PIN	TATA spare parts
886387000552	REAR HINGE PIN LOCKING PLATE	TATA spare parts
886387000553	REAR HINGE STOPPER PLATE	TATA spare parts
886387000554	HEX BOLT M12X1.75X30-10.9	TATA spare parts
886387000555	M12 SPRING WASHER	TATA spare parts
886387000556	TAIL LAMP ASSY.	TATA spare parts
886387000557	BODY PROP ASSY	TATA spare parts
886387000558	STABILIZER ASSY.	TATA spare parts
886387000559	MUDGUARD RH	TATA spare parts
886387000560	MUDGUARD LH	TATA spare parts
886387000561	STOPPER FOR BODY PROP	TATA spare parts
886387000562	BODY PROP REST PLATE ASSY	TATA spare parts
886387000563	5TH ATTACHMENT PLATE L.H. FROM REAR.	TATA spare parts
886387000564	ATTACHMENT PLATE( 3RD ATTACHMENT PLATE F	TATA spare parts
886387000565	6TH ATTACHMENT PLATE	TATA spare parts
886387000566	5TH ATTACHMENT PLATE R.H. FROM REAR.	TATA spare parts
886387000567	7TH ATTACHMENT PLATE FROM REAR	TATA spare parts
886387000568	2ND ATTACHMENT PLATE R.H. FROM REAR	TATA spare parts
886387000569	2ND ATTACHMENT PLATE L.H. FROM REAR	TATA spare parts
886387000570	LOWER PIVOT ASSY. L.H.	TATA spare parts
886387000571	LOWER PIVOT R.H.	TATA spare parts
886387000572	LOWER¿ PIVOT R.H.	TATA spare parts
886387000573	1ST LOWER PIVOT FROM REAR	TATA spare parts
886387000574	8TH ATTACHMENT PLATE FROM REAR	TATA spare parts
886387000575	UPPER PIVOT	TATA spare parts
886387000576	REAR ATTACHMENT PLATE	TATA spare parts
886387000577	ATTACHMENT PLATE( 4TH ATTACHMENT PLATE F	TATA spare parts
886387000578	FL BOLT M12X50 TS17130 10.9SS8457S1-BL-C	TATA spare parts
886387000579	FLBOLT M16X1.5X150TS17130 10.9SS8451-8CH	TATA spare parts
886387000580	H/FL BOLT M16X85 TS17130-10.9SS8451S2-YH	TATA spare parts
886387000581	HEX FL NUT AM12X1.5 TS17430 10SS8451S2-Y	TATA spare parts
886387000582	NYLOC NUT M16X1.5 ISO 10512 10SS8451-8CH	TATA spare parts
886387000583	WASHER RESILIENCE MTG¿ 7MM THICK	TATA spare parts
886387000584	PIVOT SPRING	TATA spare parts
886387000585	CANOPY FOR 715 TROOP CARRIER	TATA spare parts

886387000586	COMPLETE LADDER ASSY LH/ RH	TATA spare parts
886387000587	WATER TANK (S.S) 5 LTR	TATA spare parts
886387000588	LOCATING PIECE 50 X 50	TATA spare parts
886387000589	ASSY SEAT ASSEMBLY WITH BACK REST	TATA spare parts
886387000590	SPARE WHEEL CARRIER	TATA spare parts
886387000591	WINCH WITH ROPE	TATA spare parts
886387000592	PULLEY WITH BRACKET SMALL	TATA spare parts
886387000593	PULLEY WITH BRACKET BIG	TATA spare parts
886387000594	ROOF LIGHT	TATA spare parts
886387000595	SIDE MARKER LAMP	TATA spare parts
886387000596	WIRE HARNESS	TATA spare parts
886387000597	MUDFLAP	TATA spare parts
886387000598	TOGGLE CLAMP	TATA spare parts
886387000599	TOOL BOX	TATA spare parts
886387000600	TOOL BOX BIDDING	TATA spare parts
886387000601	JERRY CAN CAGE	TATA spare parts
886387000602	REAR HINGE BKT.	TATA spare parts
886387000603	ASSLY SIDE PANEL LH/RH	TATA spare parts
886387000604	ASSLY. TAIL GATE	TATA spare parts
886387000605	COMPLETE LOAD BODY ASSEMBLY	TATA spare parts
886387000606	SIDE SKIRT PLATE ASSY LH	TATA spare parts
886387000607	SIDE SKIRT PLATE ASSY RH	TATA spare parts
886387000608	SIDE SKIRT RAIN FLAP LH	TATA spare parts
886387000609	SIDE SKIRT RAIN FLAP RH	TATA spare parts
886387000610	REAR RAIN FLAP	TATA spare parts
886387000611	FRONT MUDGUARD ASSY LH	TATA spare parts
886387000612	FRONT MUDGUARD ASSY RH	TATA spare parts
886387000613	MUDGUARD ASSEMBLY (FIXED TYPE) LH	TATA spare parts
886387000614	MUDGUARD ASSEMBLY (FIXED TYPE) RH	TATA spare parts
886387000615	MUDGUARD ASSEMBLY (HINGED TYPE)	TATA spare parts
886387000616	UNIVERSAL SHAFT	TATA spare parts
886387000617	PULLING PIPE STUD	TATA spare parts
886387000618	MOUNTING PLATE CHASSIS	TATA spare parts
886387000619	U BOLT M16*380	TATA spare parts
886387000620	NYLOCK NUT M16 MM PLATED (TC 17436)	TATA spare parts
886387000621	PLAIN WASHER M16 MM PLATED	TATA spare parts
886387000622	U BOLT PLATE 150*50*20.00	TATA spare parts
886387000623	TIPPER BODY ASSLY 7CUM TATA LPK 1618 LHD	TATA spare parts
886387000624	FCB TIPPER BODY ASSEMBLY	TATA spare parts
886387000625	JUROP MAKE PUMP	TATA spare parts
886387000626	CRADLE ASSY 10 CUM	TATA spare parts
886387000627	LPK 912 SUBFRAME MOUNTING PART	TATA spare parts
886387000628	STABLIZER SHAFT 45X900	TATA spare parts
886387000629	STABLIZER PIN 45X180	TATA spare parts
886387000630	STABLIZER PIN 45X150	TATA spare parts
886387000631	LOAD BODY	TATA spare parts
886387000632	PM60 SPECIAL / PLUS VANE	TATA spare parts

886387000633	32FT 3A 4FT SW CORRUGATED TRAILER	TATA spare parts
886387000634	LOAD BODY ASSY WITHOUT FITMENT	TATA spare parts
886387000635	FOOT REST	TATA spare parts
886387000636	SF ASSEMBLY WITH CRADLE & MTG	TATA spare parts
886387000637	TAILGATE	TATA spare parts
886387000638	KIN PIN DIA 2½ WELDABLE YORK	TATA spare parts
886387000639	MAST SHEVE YOKE	TATA spare parts
886387000640	407 PICK-UP LOAD BODY	TATA spare parts
886387000641	ASSY LOAD BODY COMPLETE (W/O SUB FRAME A	TATA spare parts
886387000642	LOAD BODY	TATA spare parts
886387000643	WIND DEFLECTOR TATA ACE	TATA spare parts
886387000644	5625 SHORT AXLE 1950	TATA spare parts
886387000645	BRAKE SHOE LINING RIVET	TATA spare parts
886387000646	OUTER BEARING 90MM	TATA spare parts
886387000647	INNER BEARING 65MM	TATA spare parts
886387000648	M22*2.5*98 WHEEL STUD	TATA spare parts
886387000649	M22*2.5 WHEEL NUT	TATA spare parts
886387000650	06 PC KIT HUB OIL SEAL	TATA spare parts
886387000651	COMPLETE BODY	TATA spare parts
886387000652	EQUALISER	TATA spare parts
886387000653	EQUALISER CENTRE BUSH	TATA spare parts
886387000654	HINGE ASSEMBLY	TATA spare parts
886387000655	SIDE ASSEMBLY RH	TATA spare parts
886387000656	RAMP HOLDING BELT	TATA spare parts
886387000657	20CUMHDSUBFRAMEASSY WITHOUT CRADLE & S	TATA spare parts
886387000658	CAM MOUNTING ASSY	TATA spare parts
886387000659	TAIL DOOR ASSY WITH ACCESSORIES -10.5 CU	TATA spare parts
886387000660	SUBFRAME ASSY WITH ACCESSORIES ½ 10 CUM	TATA spare parts
886387000661	PIN	TATA spare parts
886387000662	STABILIZER MOUNTING PIN	TATA spare parts
886387000663	SUB FRAME WITH CRADLE	TATA spare parts
886387000664	UPPER PIVOT	TATA spare parts
886387000665	LOWER PIVOT	TATA spare parts
886387000666	CLEAT PLATE 4 HOLES	TATA spare parts
886387000667	CLEAT PLATE 3 HOLES	TATA spare parts
886387000668	CLEAT PLATE 2 HOLES	TATA spare parts
886387000669	CLEAT PLATE 2 HOLES	TATA spare parts
886387000670	CLEAT PLATE 2 HOLES	TATA spare parts
886387000671	CLEAT PLATE REAR	TATA spare parts
886387000672	TAIL GATE LOCKING PULL ROD	TATA spare parts
886387000673	TAIL GATE LOCKING SPRING.	TATA spare parts
886387000674	FULCRUM HINGE TOP PIN CYL BOD-50*OD-39.7	TATA spare parts
886387000675	FULCRUM HINGE PIN COLLER/CYL OD-50*OD-40	TATA spare parts
886387000676	LOWER JACK PIN BOD-50*OD-39.75*220TL	TATA spare parts
886387000677	TAIL GATE HINGE PIN½BOD-35*OD-24.75*120L	TATA spare parts
886387000678	TAIL GATE HINGE PIN COLLAR OD-35*ID-26*2	TATA spare parts
886387000679	HINGE PIN M12*125 MM PLATED	TATA spare parts



886387000680	LOAD BODY ASSY	TATA spare parts
886387000681	BASE FRAME	TATA spare parts
886387000682	ASSY TAIL GATE	TATA spare parts
886387000683	20 CUM HD SUBFRAME ASSY WITH CRADLE & ST	TATA spare parts
886387000684	RUBBER J BEADING 9	TATA spare parts
886387000685	LIGHT STOP	TATA spare parts
886387000686	WIND DEFLECTOR TATA ACE	TATA spare parts
886387000687	HINGE REAR DOOR	TATA spare parts
886387000688	WIRING HARNESS	TATA spare parts
886387000689	MUDGUARD TATA ACE	TATA spare parts
886387000690	RUBBER STOP	TATA spare parts
886387000691	TATA STICKER	TATA spare parts
886387000692	TAIL GATE LH	TATA spare parts
886387000693	TAIL GATE RH	TATA spare parts
886387000694	COMPLETE FABRICATED CONTAINER	TATA spare parts
886387000695	COMPLETE LOAD BODY	TATA spare parts
886387000696	BODY MTG STOOL 110 L	TATA spare parts
886387000697	BODY MTG STOOL 145 L	TATA spare parts
886387000698	MUD GUARD ASSY.	TATA spare parts
886387000699	REAR HINGE PLATE	TATA spare parts
886387000700	CYLINDER MTG PLATE BOTTOM	TATA spare parts
886387000701	CYLINDER MTG PLATE UPPER	TATA spare parts
886387000702	BODY PROB ASSEMBLY	TATA spare parts
886387000703	BODY HINGE PIN	TATA spare parts
886387000704	BODY HINGE BUSH	TATA spare parts
886387000705	LH TAIL DOOR	TATA spare parts
886387000706	TAIL DOOR ASSY	TATA spare parts
886387000707	UPPER FLAP	TATA spare parts
886387000708	TAIL DOOR LOCKING PIN	TATA spare parts
886387000709	TAIL DOOR LOCKING BUSH	TATA spare parts
886387000710	PTO DRIVEN PUMP	TATA spare parts
886387000711	PUSH PULL CABLE	TATA spare parts
886387000712	TAIL DOOR HINGE L ASSY	TATA spare parts
886387000713	PUSH PULL CABLE (2.2 MTR)	TATA spare parts
886387000714	BODY LOCK ASSY	TATA spare parts
886387000715	HINGE REAR DOOR	TATA spare parts
886387000716	WIRING CLAMP	TATA spare parts
886387000717	TOWER BOLT	TATA spare parts
886387000718	MUDGUARD TATA ACE	TATA spare parts
886387000719	RUBBER KICK	TATA spare parts
886387000720	TATA STICKER	TATA spare parts
886387000721	RUBBER J BEADING LENGTH 3.3 MTR	TATA spare parts
886387000722	WIND DEFLECTOR TATA ACE	TATA spare parts
886387000723	WIRING CLAMP	TATA spare parts
886387000724	LOAD BODY	TATA spare parts
886387000725	LOAD BODY	TATA spare parts
886387000726	V BAR OF LRV	TATA spare parts

886387000727	PULLING PIPE ASSY	TATA spare parts
886387000728	HINGES FOR SHUTTER DOOR	TATA spare parts
886387000729	HANDLE ROD FOR SHUTTER DOOR 10 INCH	TATA spare parts
886387000730	6 CUM MIXER ASSY	TATA spare parts
886387000731	CENTAFLEX COUPLING	TATA spare parts
886387000732	REAR HINGE BKT. PROFILE	TATA spare parts
886387000733	REAR HINGE BKT STIFFENER-2	TATA spare parts
886387000734	REAR HINGE BKT STIFFENER-3	TATA spare parts
886387000735	BUSH WITH OUT HOLE	TATA spare parts
886387000736	BHUSH WITH HOLE	TATA spare parts
886387000737	CYLINDRICAL KNOCK OFF	TATA spare parts
886387000738	BRACKET-CYLINDER KNOCK OFF	TATA spare parts
886387000739	WASHER M8	TATA spare parts
886387000740	METAL STRAP FOR OIL TANK FE/FC 149	TATA spare parts
886387000741	M5 SPRING WASHER SQ. SECTION	TATA spare parts
886387000742	DUST COVER FE 149-3	TATA spare parts
886387000743	PISTON FL2 S 110-1445-HD-HC	TATA spare parts
886387000744	BOTTOM PLATE PISTON FL 110 MK2 HD	TATA spare parts
886387000745	PISTON EYE SPH.FL 110 MK2	TATA spare parts
886387000746	O RING 91.67 X 3.53 MM	TATA spare parts
886387000747	STAGE FL2 129-1440-HD-HC	TATA spare parts
886387000748	STAGE FL2 149 1440-HD-HC	TATA spare parts
886387000749	OUTER STORING FL 149 A22	TATA spare parts
886387000750	LIFTRING FL 149 A22	TATA spare parts
886387000751	BASE FL2 169-1479-4/4B SAE-190-HD	TATA spare parts
886387000752	BOTTOM PLATE FL2 169	TATA spare parts
886387000753	SEAL BOTTOM PLATE FL 169	TATA spare parts
886387000754	SEAL KIT COMPLETE	TATA spare parts
886387000755	SUBFRAME ASSY/14CUM LPK 2518	TATA spare parts
886387000756	LOAD BODY PIN	TATA spare parts
886387000757	16cUM BOX TIP Load Body without Kit	TATA spare parts
886387000758	TAIL GATE LOCK ASSEMBLY	TATA spare parts
886387000759	LOAD BODY LH SIDE PANEL	TATA spare parts
886387000760	16 CU.MTR. BOX TIP LOAD BODY WITH HIDROM	TATA spare parts
886387000761	COMPLETE LOCK ASSY. SET	TATA spare parts
886387000762	SHAFT REAR HINGE	TATA spare parts
886387000763	OUTER BUSH	TATA spare parts
886387000764	16 CU.MTR. BOX TIPç LOAD BODY WITHOUT KI	TATA spare parts
886387000765	16 CU.MTR. BOX TIP LOAD BODY WITH WIPRO	TATA spare parts
886387000766	PIVOTE SPRING/31080001/56.5X32.5X7 MM	TATA spare parts
886387000767	PIVOT BKT. ASSY UPPER	TATA spare parts
886387000768	PIVOT BKT ASSY LOWER	TATA spare parts
886387000769	HEX BOLT/16X150	TATA spare parts
886387000770	PULLING PIPE ASSY 1950	TATA spare parts
886387000771	PULLING PIPE ASSEMBLY 1950M	TATA spare parts
886387000772	TENSION SPRING/300X35X5 MM	TATA spare parts
886387000773	CAM HAMERER ASSY./FOR SK1616/36	TATA spare parts

886387000774	HOOK ASSY./FOR SK 1616/36	TATA spare parts
886387000775	CAM MOUNTING ASSY.	TATA spare parts
886387000776	PULLING PIPE ASSY/FOR LPK 2518 HD	TATA spare parts
886387000777	PULLING PIPE	TATA spare parts
886387000778	BUSH OD50XID35XL-20	TATA spare parts
886387000779	CYLINDER BOTTOM MOUNTING PIN BOD 50XOD 3	TATA spare parts
886387000780	SPACER OD50XID35XL-18	TATA spare parts
886387000781	CYLINDER TOP MOUNTING PIN BOD 50XOD 34.5	TATA spare parts
886387000782	SPACER OD50XID35XL-9	TATA spare parts
886387000783	PIN STABILIZER MTG TOP DIA60*202L	TATA spare parts
886387000784	RAIN FLAP 2709*100*3.0	TATA spare parts
886387000785	RAIN FLAP REAR 960*630	TATA spare parts
886387000786	ASSLY MUDGUARED SUPPORT (24CUM)	TATA spare parts
886387000787	SHAFT REAR HINGE DIA60*1020L	TATA spare parts
886387000788	STABILIZER SHAFT DIA 45*898	TATA spare parts
886387000789	LOCK BRACKET TAIL LOCK 100*50	TATA spare parts
886387000790	CLAMP DIA15*25	TATA spare parts
886387000791	CLAMP DIA22*25	TATA spare parts
886387000792	RAIN FLAP 1418*100*3.0	TATA spare parts
886387000793	BUSH OD60*ID46*84L	TATA spare parts
886387000794	LOCKING PIN DIA 25*90L	TATA spare parts
886387000795	SNAP RING DIA 4*200	TATA spare parts
886387000796	COTTER PIN DIA 12*25L	TATA spare parts
886387000797	DUST COVER LDPE IS 7078	TATA spare parts
886387000798	PIN TAIL LOCK OD22*ID14*75L	TATA spare parts
886387000799	REAR HINGE PIN¿ (60X135)	TATA spare parts
886387000800	ASSLY.RUBBER STOPPER 265170900105	TATA spare parts
886387000801	CROSS ROD DIA 30*1500	TATA spare parts
886387000802	TIE ROD DIA 16*1000	TATA spare parts
886387000803	FORK PIN DIA 16*46L	TATA spare parts
886387000804	HINGE PIN M12*126 MM W/O THREADED(OLIV.G	TATA spare parts
886387000805	U BOLT DIA.16*550 MM	TATA spare parts
886387000806	U BOLT DIA.16*475 MM	TATA spare parts
886387000807	U BOLT M16X460	TATA spare parts
886387000808	U BOLT M16X490	TATA spare parts
886387000809	U BOLT PLATE 138X40X20	TATA spare parts
886387000810	SUB-FRAME ASSY	TATA spare parts
886387000811	MOUNTING PARTS	TATA spare parts
886387000812	TAIL LAMP BKT RH	TATA spare parts
886387000813	TAIL LAMP BKT LH	TATA spare parts
886387000814	PULLING PIPE 1000 MM	TATA spare parts
886387000815	U¿ BOLT	TATA spare parts
886387000816	ALUMINUM ALLOY PACKING	TATA spare parts
886387000817	RUNNER	TATA spare parts
886387000818	16 CUM FE BOX TIP LPK 2518 HD/38/BS4/G11	TATA spare parts
886387000819	16 CUM FE BOX TIP LPK 2518 HD/38/BS4/G11	TATA spare parts
886387000820	16 CUM FE BOX TIP LPK 2518 HD/38/BS4/G11	TATA spare parts

886387000821	SUBFRAME ASSY.	TATA spare parts
886387000822	TOP MARKER LAMP	TATA spare parts
886387000823	SIDE INDICATOR LIGHT (LUMAX)	TATA spare parts
886387000824	HARNESS	TATA spare parts
886387000825	GREASE NIPPLE AM10X1 IS4009P2 SS8451-8C	TATA spare parts
886387000826	REAR HINGE SHAFT	TATA spare parts
886387000827	REAR HINGE SHAFT LOCK BAR	TATA spare parts
886387000828	REAR HINGE SHAFT SNAP RING	TATA spare parts
886387000829	CAM PROE SSY.	TATA spare parts
886387000830	PULLING PIPE ASSY.	TATA spare parts
886387000831	SIDE INDICATOR BRAKET ASSEMBLY	TATA spare parts
886387000832	LOWER PIVOT ATTACHMENT (90-60 HOLE CENTE	TATA spare parts
886387000833	LOWER PIVOT ATTACHMENT (90-80 HOLE CENTE	TATA spare parts
886387000834	UPPER PIVOT ATTACHMENT	TATA spare parts
886387000835	PIVOT SPRING	TATA spare parts
886387000836	RAIN FLAPS REAR	TATA spare parts
886387000837	SIDE RAINFLAPS	TATA spare parts
886387000838	HEX BOLT M16X110	TATA spare parts
886387000839	HEX BOLT M16X150	TATA spare parts
886387000840	NYLOCK NUT M16	TATA spare parts
886387000841	NYLOCK NUT M12	TATA spare parts
886387000842	FLANGE BOLT M12 X 50	TATA spare parts
886387000843	MUDGUARD PIPE FRAME ASSEMBLY	TATA spare parts
886387000844	OUTER FOOT REST ASSY.	TATA spare parts
886387000845	MUDGUARD MTG. PLATE BEND ( FRONT MUDGU	TATA spare parts
886387000846	2ND AXLE MUDGUARD PLATE (FRONT MUDGUAR	TATA spare parts
886387000847	GROMMET RUBBER (ID12 OD26)	TATA spare parts
886387000848	TAIL LAMP WITHOUT NO PLATE	TATA spare parts
886387000849	TAIL LAMP WITH NO PLATE	TATA spare parts
886387000850	TAIL DOOR HINGE INCHLINCH PLATE ( 25MM)	TATA spare parts
886387000851	BODY PROP MOUNTING ASSEMBLY	TATA spare parts
886387000852	HOOK BLOCK ASSEMBLY LH ( LOCK ASSY)	TATA spare parts
886387000853	HOOK BLOCK ASSEMBLY RH ( LOCK ASSY)	TATA spare parts
886387000854	TENSTION SPRING	TATA spare parts
886387000855	CRADLE	TATA spare parts
886387000856	TAIL DOOR HINGE PIN-1	TATA spare parts
886387000857	TAIL DOOR HINGE PIN-2	TATA spare parts
886387000858	PLAN WASHER M16	TATA spare parts
886387000859	NYLOCK NUT M8	TATA spare parts
886387000860	HEX BOLT M8 X 25	TATA spare parts
886387000861	16 CUM FE BOX TIP LPK 2518 HD/38/BS4/G11	TATA spare parts
886387000862	16 CUM FE BOX TIP LPK 2518 HD/38/BS4/G11	TATA spare parts
886387000863	16 CUM FE BOX TIP LPK 2518 HD/38/BS4/G11	TATA spare parts
886387000864	BODY ASSEMBLY	TATA spare parts
886387000865	PLATFORM ASSEMBLY	TATA spare parts
886387000866	SIDE ASSEMBLY	TATA spare parts
886387000867	BODY MTG STOOL 110 L	TATA spare parts

886387000868	BODY MTG STOOL 145 L	TATA spare parts
886387000869	MUD GUARD ASSY.	TATA spare parts
886387000870	REAR HINGE PLATE	TATA spare parts
886387000871	CYLINDER MTG PLATE BOTTOM	TATA spare parts
886387000872	BODY PROB ASSEMBLY	TATA spare parts
886387000873	BODY HINGE PIN	TATA spare parts
886387000874	BODY HINGE BUSH	TATA spare parts
886387000875	TAIL DOOR	TATA spare parts
886387000876	PARTITION WALL	TATA spare parts
886387000877	PTO DRIVEN PUMP WITH PUSH PULL CABLE	TATA spare parts
886387000878	TARPAULIN COVER	TATA spare parts
886387000879	HYDRAULIC KIT	TATA spare parts
886387000880	BODY MTG STOOL 110 L	TATA spare parts
886387000881	BODY MTG STOOL 145 L	TATA spare parts
886387000882	MUD GUARD ASSY.	TATA spare parts
886387000883	CYLINDER MTG PLATE UPPER	TATA spare parts
886387000884	REAR HINGE PLATE	TATA spare parts
886387000885	CYLINDER MTG PLATE BOTTOM	TATA spare parts
886387000886	TAIL DOOR HINGE PLATE	TATA spare parts
886387000887	BODY PROB ASSEMBLY	TATA spare parts
886387000888	BODY MTG PIN	TATA spare parts
886387000889	BODY MTG BUSH	TATA spare parts
886387000890	CYLINDER MTG BOTTOM PIN	TATA spare parts
886387000891	CYLINDER MTG TOP PIN	TATA spare parts
886387000892	TAIL DOOR LOCKING PIN	TATA spare parts
886387000893	TAIL DOOR LOCKING BUSH	TATA spare parts
886387000894	SIDE WALL DOOR	TATA spare parts
886387000895	LH SIDE DOOR ASSY	TATA spare parts
886387000896	RH SIDE TAIL DOOR	TATA spare parts
886387000897	BELL	TATA spare parts
886387000898	PTO DRIVEN PUMP	TATA spare parts
886387000899	PUSH PULL CABLE	TATA spare parts
886387000900	HYDRAULIC KIT	TATA spare parts
886387000901	ASSLY TAIL PANEL 16CUM TIP. LPK2523/38WB	TATA spare parts
886387000902	ASSY LOAD BODY (HIGH DECK)	TATA spare parts
886387000903	ASSY FRONT WALL	TATA spare parts
886387000904	ASSY SIDE WALL LH	TATA spare parts
886387000905	ASSY SIDE WALL RH	TATA spare parts
886387000906	ASSY TAIL GATE	TATA spare parts
886387000907	REAR MUD FLAP FITMENT ASSEMBLY	TATA spare parts
886387000908	BODY ASSEMBLY	TATA spare parts
886387000909	SUB FRAME ASSEMBLY	TATA spare parts
886387000910	SIDE ASSEMBLY	TATA spare parts
886387000911	CHASSIS MTG BKT ASSY.	TATA spare parts
886387000912	LENDING LEG ASSY.	TATA spare parts
886387000913	MUD GUARD ASSY.	TATA spare parts
886387000914	CUTTING PROFILE PLATES	TATA spare parts

886387000915	PARTITION WALL	TATA spare parts
886387000916	BODY PROB ASSEMBLY	TATA spare parts
886387000917	BODY HINGE PIN WITH BUSH	TATA spare parts
886387000918	PTO DRIVEN PUMP WITH PUSH PULL CABLE	TATA spare parts
886387000920	BODY MTG STOOL 145 L	TATA spare parts
886387000921	MUD GUARD ASSY.	TATA spare parts
886387000922	CYLINDERMTG TOP BKT	TATA spare parts
886387000923	CYLINDER MTG BKT LOWER	TATA spare parts
886387000924	BODY FULCRUM PLATE	TATA spare parts
886387000925	PARTITION WALL	TATA spare parts
886387000926	TAIL DOOR	TATA spare parts
886387000927	TOP LID FRONT	TATA spare parts
886387000928	TOP LID REAR	TATA spare parts
886387000929	BODY PROB ASSY	TATA spare parts
886387000930	BODY MTG PIN	TATA spare parts
886387000931	BODY MTG BUSH	TATA spare parts
886387000932	CYLINDER MTG BOTTOM PIN	TATA spare parts
886387000933	CYLINDER MTG TOP PIN	TATA spare parts
886387000934	PTO DRIVEN PUMP WITH PUSH PULL CABLE	TATA spare parts
886387000935	REMOTE CONTROL CABLE L- 6 M	TATA spare parts
886387000936	REMOTE CONTROL CABLE L- 5.4 M.	TATA spare parts
886387000937	STOP CABLE 1.6 MTR	TATA spare parts
886387000938	SPACER RUBBER	TATA spare parts
886387000939	THREADED FORK	TATA spare parts
886387000940	THREADED ROD	TATA spare parts
886387000941	LOCKING CHANNEL	TATA spare parts
886387000942	FORK PIN	TATA spare parts
886387000943	TOP PLATE	TATA spare parts
886387000944	HOOK PLATE ASSEMBLY	TATA spare parts
886387000945	DOWEL PIN	TATA spare parts
886387000946	PIN	TATA spare parts
886387000947	CHASSIS ASSEMBLY	TATA spare parts
886387000948	TAIL DOOR	TATA spare parts
886387000949	CUBED BODY	TATA spare parts
886387000950	TD HINGE ASSLY.	TATA spare parts
886387000951	PIVOT PIN	TATA spare parts
886387000952	TAIL LAMP GUARD	TATA spare parts
886387000953	NUMBER PLATE	TATA spare parts
886387000954	PIVOT BRACKET ASSLY.	TATA spare parts
886387000955	STABLIZER ASSLY.	TATA spare parts
886387000956	SPRAY SUPPRESSOR REAR/FRONT	TATA spare parts
886387000957	KING PIN MAKE- YORK	TATA spare parts
886387000958	LANDING GEAR MAKE- HDTPL	TATA spare parts
886387000959	TARP HOOK	TATA spare parts
886387000960	CONTAINER-SUB FRAME MOUNTING-TWIST LOCK	TATA spare parts
886387000961	EPDM P RUBBER (INNER) & J CUM C TYPE(OUT	TATA spare parts
886387000962	DOOR HINGES& FASTERNERS (GALVANISED)	TATA spare parts

886387000963	DLM BAR	TATA spare parts
886387000964	MOUNTING U BOLT ASSEMBLY 3/4INCH - (19MM	TATA spare parts
886387000965	SIDE VALANCE MAT	TATA spare parts
886387000966	REAR SPRAY SUPPRESSION MAT	TATA spare parts
886387000967	T BOLT ( SUB FRAME + CONTAINER INTEGRATI	TATA spare parts
886387000968	20 CUM BOX TIPPER LOAD BODY ASSY WO HYDR	TATA spare parts
886387000969	SEAL KIT	TATA spare parts
886387000970	HOOK HOLDING PLATE	TATA spare parts
886387000971	CHASSIS ASSEMBLY	TATA spare parts
886387000972	TAIL DOOR	TATA spare parts
886387000973	CUBED BODY	TATA spare parts
886387000974	20 CUM BOX TIPPER TAIL DOOR ASSY	TATA spare parts
886387000975	TAIL DOOR BOTTOM HINGE ASSEMBLY	TATA spare parts
886387000976	TAIL DOOR CHAIN LOCK ARRANGEMENT	TATA spare parts
886387000977	TAIL DOOR BOTTOM FRAME LOCK ARRANGEMEN	TATA spare parts
886387000978	CHASSIS ASSEMBLY	TATA spare parts
886387000979	TAIL DOOR	TATA spare parts
886387000980	CUBED BODY	TATA spare parts
886387000981	18CUM BOX TIPPER ASSY	TATA spare parts
886387000982	RAIN FLAP REAR LH	TATA spare parts
886387000983	PIPE FRAME ASSY	TATA spare parts
886387000984	TOP MARKER LIGHT GUARD ( JAALI)	TATA spare parts
886387000985	REAR HINGE SHAFT	TATA spare parts
886387000986	REAR HINGE INNER BUSH	TATA spare parts
886387000987	REAR HINGE OUTER BUSH	TATA spare parts
886387000988	BODY GUIDE	TATA spare parts
886387000989	BODY PROP ASSY LH/RH	TATA spare parts
886387000990	OUTER FOOT REST ASSY	TATA spare parts
886387000991	UPPER PIVOT	TATA spare parts
886387000992	LOWER PIVOT 190	TATA spare parts
886387000993	CRADLE ASSEMBLY	TATA spare parts
886387000994	TAIL DOOR HINGE ASSY LH	TATA spare parts
886387000995	TAIL DOOR HINGE ASSY RH	TATA spare parts
886387000996	REAR HINGE BKT. PROFILE	TATA spare parts
886387000997	CYLINDER MOUNTING PLATE	TATA spare parts
886387000998	TAIL LAMP GUARD ASSY LH	TATA spare parts
886387000999	TAIL LAMP GUARD ASSY RH	TATA spare parts
886387001000	SIDE BOARD ASSEMBLY LH/RH	TATA spare parts
886387001001	TAIL DOOR ASSEMBLY	TATA spare parts
886387001002	HEAD BOARD ASSEMBLY	TATA spare parts
886387001003	FLOOR ASSEMBLY	TATA spare parts
886387001004	MUDGUARD MTG BKT 150 LH	TATA spare parts
886387001005	MUDGUARD MTG BKT 150 RH	TATA spare parts
886387001006	MUDGUARD MTG BKT 230 LH	TATA spare parts
886387001007	MUDGUARD MTG BKT 230 RH	TATA spare parts
886387001008	SUBFRAME ASSEMBLY	TATA spare parts
886387001009	STABLIZER ASSEMBLY	TATA spare parts

886387001010	STABLIZER SHAFT 45X900	TATA spare parts
886387001011	RAIN FLAP REAR RH	TATA spare parts
886387001012	PULLING PIPE ASSEMBLY 2100	TATA spare parts
886387001013	STABLIZER PIN	TATA spare parts
886387001014	TAIL DOOR ASSEMBLY WITHOUT HINGE	TATA spare parts
886387001015	10 CUM SUBFRAME ASSY W/O CRADLE & MOUNT	TATA spare parts
886387001016	BRACKET	TATA spare parts
886387001017	FASTNER KIT	TATA spare parts
886387001018	STUD MS M18 X 196 MM	TATA spare parts
886387001019	PTO 4 450NM FROM IPH	TATA spare parts
886387001020	LEVER CONTROL VALVE [WABCO]	TATA spare parts
886387001021	BARE HOSE WITH WIRE BRAIDED 3.1/2INCHX10	TATA spare parts
886387001022	BUTTERFLY VALVE(DN80)	TATA spare parts
886387001023	HOSE CLAMP SS 4 1/2X KLIPCO	TATA spare parts
886387001024	TIPPER BODY ASSEMBLY -16 STD BOX (LPK 25	TATA spare parts
886387001025	SIDE SKIRT WITH RAIN FLAP FRONT LH	TATA spare parts
886387001026	SIDE SKIRT WITH RAIN FLAP FRONT RH	TATA spare parts
886387001027	SIDE SKIRT WITH RAIN FLAP REAR LH	TATA spare parts
886387001028	SIDE SKIRT WITH RAIN FLAP REAR RH	TATA spare parts
886387001029	PIPE FRAME ASSY WITH RAIN FLAP REAR LH	TATA spare parts
886387001030	PIPE FRAME ASSY WITH RAIN FLAP REAR RH	TATA spare parts
886387001031	PIPE FRAME ASSY WITH RAIN FLAP MIDDLE LH	TATA spare parts
886387001032	PIPE FRAME ASSY WITH RAIN FLAP MIDDLE RH	TATA spare parts
886387001033	FRONT MUDGUARD LH	TATA spare parts
886387001034	FRONT MUDGUARD RH	TATA spare parts
886387001035	RAIN FLAP ONLY WITHOUT PIPE FRAME LH	TATA spare parts
886387001036	RAIN FLAP ONLY WITHOUT PIPE FRAME RH	TATA spare parts
886387001037	RAIN FLAP ONLY WITHOUT SIDE SKIRT FRONT	TATA spare parts
886387001038	RAIN FLAP ONLY WITHOUT SIDE SKIRT REAR	TATA spare parts
886387001039	TAIL DOOR HINGE ASSY RH	TATA spare parts
886387001040	SUBFRAME ASSEMBLY	TATA spare parts
886387001041	ATTACHMENT PLATE REAR	TATA spare parts
886387001042	ATTACHMENT PLATE-2	TATA spare parts
886387001043	ATTACHMENT PLATE-3	TATA spare parts
886387001044	UPPER PIVOT	TATA spare parts
886387001045	LOWER PIVOT	TATA spare parts
886387001046	HAMMER MTG PROFILE ASSY	TATA spare parts
886387001047	HAMMER PIN ASSY	TATA spare parts
886387001048	FORK	TATA spare parts
886387001049	TIE ROD	TATA spare parts
886387001050	CAM PLATE	TATA spare parts
886387001051	CROSS ROD BUSH ASSY	TATA spare parts
886387001052	CROSS ROD WASHER	TATA spare parts
886387001053	TAIL DOOR LOCK	TATA spare parts
886387001054	SPRING PLATE1	TATA spare parts
886387001055	STUDS	TATA spare parts
886387001056	TENSION SPRING	TATA spare parts



886387001057	SPRING PLATE2	TATA spare parts
886387001058	CROSS ROD	TATA spare parts
886387001059	PIVOT SPRING	TATA spare parts
886387001060	HEX HEAD BOLT M16X110-10.9	TATA spare parts
886387001061	HEX HEAD BOLT M16X150-10.9	TATA spare parts
886387001062	M16 HARDENED WASHER 32/17X5	TATA spare parts
886387001063	NYLOCK NUT M16 COARSE THREAD	TATA spare parts
886387001064	HEX BOLT M12X1.25X50-10.9	TATA spare parts
886387001065	NYLOCK NUT M12 FINE THREAD	TATA spare parts
886387001066	R/H PIN 60X135	TATA spare parts
886387001067	R/H BUSH 88X90X70	TATA spare parts
886387001068	L CHAIN ASSY	TATA spare parts
886387001069	TAIL DOOR U BEND (DIA 12)	TATA spare parts
886387001070	J HOOK (DIA 10)	TATA spare parts
886387001071	BODY PROP BUSH	TATA spare parts
886387001072	BODY PROP PIN	TATA spare parts
886387001073	BODY PROP MTG PIN	TATA spare parts
886387001074	ATTACHMENT PLATE -1	TATA spare parts
886387001075	ATTACHMENT PLATE -2	TATA spare parts
886387001076	ATTACHMENT PLATE - 3	TATA spare parts
886387001077	REAR ATTACHMENT PLATE	TATA spare parts
886387001078	SERR. FLANGE BOLT M12X50	TATA spare parts
886387001079	SERR. FLANGE BOLT M12X40	TATA spare parts
886387001080	STABILIZER HINGE LOCK PLATE	TATA spare parts
886387001081	BASE 169-1689-4/4SAE-190-MK5	TATA spare parts
886387001082	SPRING WASHER M8 SET	TATA spare parts
886387001083	BOLT M8 X 1.25 X 20 SET	TATA spare parts
886387001084	STAGE 149-1650-MK5-HC	TATA spare parts
886387001085	STAGE 129-1650-MK5-HC	TATA spare parts
886387001086	PISTON S 110-1655-MK5-HC	TATA spare parts
886387001087	PISTON FL2 S 110-1645-HD-HC	TATA spare parts
886387001088	STAGE FL2 129-1640-HD-HC	TATA spare parts
886387001089	STAGE FL2 149-1640-HD-HC	TATA spare parts
886387001090	BASE FL2 169-1679-4/4B SAE-190-HD	TATA spare parts
886387001091	HOOK ASSEMBLY RH	TATA spare parts
886387001092	REAR HINGE BRACKET	TATA spare parts
886387001093	REAR HINGE BRACKET REINFORCEMENT 1	TATA spare parts
886387001094	REAR HINGE BRACKET REINFORCEMENT	TATA spare parts
886387001095	O RING 72.62 X 3.53 MM	TATA spare parts
886387001096	PISTON FL2 S 110-1560-HD-HC	TATA spare parts
886387001097	STAGE FL2 129-1510-HD-HC	TATA spare parts
886387001098	STAGE FL2 149-1510-HD-HC	TATA spare parts
886387001099	BASE FL2 169-1549-4/4B SAE-190-HD	TATA spare parts
886387001100	PROP MTG PIN	TATA spare parts
886387001101	REAR HINGE BRACKET ASSEMBLY LH	TATA spare parts
886387001102	REAR HINGE BRACKET ASSEMBLY RH	TATA spare parts
886387001103	TAILDOOR LOCKING ASSLY	TATA spare parts

886387001104	PROFILE PLATE	TATA spare parts
886387001105	HAMMER ASSLY	TATA spare parts
886387001106	EYE BOLT WITH NUT	TATA spare parts
886387001107	SPRING MTG PLT 1 �6 HOLE	TATA spare parts
886387001108	SPRING MTG PLT 2 �13.2	TATA spare parts
886387001109	PLAIN WASHER M30 DIN125	TATA spare parts
886387001110	LOCKING PIN	TATA spare parts
886387001111	CHAIN CUT TO LENGTH	TATA spare parts
886387001112	BISCUIT LOCKING PIN	TATA spare parts
886387001113	SLOTTED COLLAR	TATA spare parts
886387001114	PIN ENGAGEMENT PLT	TATA spare parts
886387001115	CROSS ROD �30MM	TATA spare parts
886387001116	SUCTION HOSE	TATA spare parts
886387001117	CARTRIDGE PRE RELIEF AT 170BAR	TATA spare parts
886387001118	PISTON FL2 S 091-1445-HD-HC	TATA spare parts
886387001119	STAGE FL2 110-1440-HD-HC	TATA spare parts
886387001120	BASE FL2 149-1497-4/4B SAE-190-HD	TATA spare parts
886387001121	DUST COVER FE 169-4/191-5	TATA spare parts
886387001122	PISTON FL2 S 110-1365-HD-HC	TATA spare parts
886387001123	STAGE FL2 149 1360-HD-HC	TATA spare parts
886387001124	STAGE FL2 169-1360-HD-HC	TATA spare parts
886387001125	BASE FL2 191-1403-4/4B SAE-190-HD	TATA spare parts
886387001126	BOTTOM PLATE FL2 191	TATA spare parts
886387001127	LOCKING PLATE FL2 191	TATA spare parts
886387001128	SEAL KIT(COMPRISES 1 3 5 6 23 27&28)	TATA spare parts
886387001129	ATTACHMENT PLATE REAR	TATA spare parts
886387001130	REAR HINGE SHAFT	TATA spare parts
886387001131	REAR HINGE OUTER BUSH	TATA spare parts
886387001132	FC A110-3-03150-K0343	TATA spare parts
886387001133	DUST COVER FC LOW 15 -168	TATA spare parts
886387001134	SLIDER FL 072(2 X 1/2) A35	TATA spare parts
886387001135	BOTTOM PLATE PISTON FL 072 MK2 HD	TATA spare parts
886387001136	CIRCLIP 58 (62.5 X 2.0)	TATA spare parts
886387001137	PISTON HEAD FL 072 MK2	TATA spare parts
886387001138	STAGE FL2 091-1275-HD-HC	TATA spare parts
886387001139	LIFTRING FL 091X4	TATA spare parts
886387001140	STAGE FL2 110-1275-HD-HC	TATA spare parts
886387001141	BASE FL2 129-1314-4/4B SAE-190-C168-HD	TATA spare parts
886387001142	BOTTOM PLATE FL2 129	TATA spare parts
886387001143	CAM ASSEMBLY RH	TATA spare parts
886387001144	CAM ASSEMBLY LH	TATA spare parts
886387001145	LP ADAPTOR 1 1/2INCH-LP28 + ORING	TATA spare parts
886387001146	PISTON FL2 S 091-1515-HD-HC	TATA spare parts
886387001147	STAGE FL2 110-15100-HD-HC	TATA spare parts
886387001148	BASE FL2 149-1549-4/4B SAE-190-HD	TATA spare parts
886387001149	HOOK BLOCK MOUNTING MEMBER	TATA spare parts
886387001150	CLOSER	TATA spare parts

886387001151	UPPER PIVOT	TATA spare parts
886387001152	ADAPTOR 1/2INCHBSP M X3/4INCHBSP M	TATA spare parts
886387001153	UM BRACKET TO WELD D50	TATA spare parts
886387001154	UCB BRACKET PLATE D50	TATA spare parts
886387001155	HEX. HEAD BOLT M10X60	TATA spare parts
886387001156	UCB CRADLE129-149CLOSING PLATE	TATA spare parts
886387001157	TAILDOOR ASSY WELDED+PARTS	TATA spare parts
886387001158	BOLT HSHC M10X60	TATA spare parts
886387001159	WASHER	TATA spare parts
886387001160	O RING	TATA spare parts
886387001161	REAR HINGE BRACKET	TATA spare parts
886387001162	REAR HINGE BRACKET REINFORCEMENT 1	TATA spare parts
886387001163	REAR HINGE BRACKET REINFORCEMENT	TATA spare parts
886387001164	DUST COVER FE 149-4/157-4	TATA spare parts
886387001165	PISTON FL2 S 091-1400-HD-HC	TATA spare parts
886387001166	BASE FL2 169-1399-4/4B SAE-190-HD	TATA spare parts
886387001167	SEAL KIT	TATA spare parts
886387001168	SNAP RING	TATA spare parts
886387001169	REAR HINGE BRACKET ASSEMBLY LH	TATA spare parts
886387001170	REAR HINGE BRACKET ASSEMBLY RH	TATA spare parts
886387001171	REAR HINGE PIN	TATA spare parts
886387001172	REAR HINGE PIN OUTER REST PLATE	TATA spare parts
886387001173	REAR HINGE PIN INNER BUSH	TATA spare parts
886387001174	PIVOT LH	TATA spare parts
886387001175	PIVOT RH	TATA spare parts
886387001176	LOWER PIVOT 1 RH	TATA spare parts
886387001177	REAR HINGE BKT PROFILE	TATA spare parts
886387001178	REAR HINGE BKT REINF. FLAT	TATA spare parts
886387001179	REAR HINGE BKT REINF. FLAT	TATA spare parts
886387001180	CHASSIS BRACKET 286 MACHINED	TATA spare parts
886387001182	CONNECTOR 1/8INCHBSP X 4X6 PIPE	TATA spare parts
886387001183	HEX. HEAD BOLT M16X85	TATA spare parts
886387001184	BASE 129-1314-4/4SAE-190	TATA spare parts
886387001185	STAGE 110-1275-HC	TATA spare parts
886387001186	STAGE 091-1275	TATA spare parts
886387001187	LIFTRING 091	TATA spare parts
886387001188	SLIDER 072 (2X1/2)	TATA spare parts
886387001192	SUBFRAME ASSEMBLY	TATA spare parts
886387001197	LOAD BODY ASSY STD 8.5CUM TATA LPK1615	TATA spare parts
886387001198	PIN FOR CAM MOUNTING	TATA spare parts
886387001199	SUBFRAME ASSEMBLY	TATA spare parts
886387001201	ATTACHMENT PLATE 2	TATA spare parts
886387001204	LOWER PIVOT ATTACHEMENT	TATA spare parts
886387001217	VALVE MOUNTING BLOCK	TATA spare parts
886387001218	HOSE PUMP TO VALVE	TATA spare parts
886387001222	PISTON FL2 S 072-1280-HD-HC	TATA spare parts
886387001223	OUTER STOPRING FL 072	TATA spare parts

886387001224	SEAL KIT COMPLETE(CONSISTS OF ITEM NO10	TATA spare parts
886387001225	SLIDER FL 129(2 X 1/2) A35	TATA spare parts
886387001226	SLIDER FL 149 A35	TATA spare parts
886387001228	LOAD BODY WITHOUT HYDRAULIC SYSTEM	TATA spare parts
886387001229	COMPLETE LOAD BODY WITH KIT	TATA spare parts
886387001230	SUBFRAME ASSY	TATA spare parts
886387001231	FRP DOOM	TATA spare parts
886387001232	FRONT PANEL ASSY	TATA spare parts
886387001233	SIDE PANEL ASSY LH	TATA spare parts
886387001234	SIDE PANEL ASSY RH	TATA spare parts
886387001235	TAIL DOOR HINGE PIN	TATA spare parts
886387001236	COMPLETE TIPPER BODY ASSY ( TIPPER BODY	TATA spare parts
886387001237	TIPPER BODY ASSY WITHOUT SUBFRAME AND WI	TATA spare parts
886387001238	14 CUM STD SUBFRAME ASSLY & WITHOUT CRAD	TATA spare parts
886387001239	CRASH GUARD SUB ASSY	TATA spare parts
886387001240	TAIL GATE SUB ASSY	TATA spare parts
886387001241	SUBFRAME ASSY	TATA spare parts
886387001242	COMPLETE SUBFRAME ASSY	TATA spare parts
886387001243	COMPLETE TIPPER BODY ASSY W/O HYDRAULICS	TATA spare parts
886387001244	TIPPER BODY ASSY WITHOUT SUBFRAME	TATA spare parts
886387001245	SUBFRAME ASSY ONLY FOR 18 CUM ON 3118 SL	TATA spare parts
886387001246	18 CUM HD COMPLETE TIPPER BOX ASSY	TATA spare parts
886387001247	18 CUM HDCOMPLETE SUBFRAME ASSY	TATA spare parts
886387001248	18 CUM HDCOMPLETE WITHOUT SUBFRAME ASS	TATA spare parts
886387001249	U BOLT L 535	TATA spare parts
886387001250	U BOLT L 515	TATA spare parts
886387001251	SHOE PLATE	TATA spare parts
886387001252	ASSY . SIDE MARKER BRACKET	TATA spare parts
886387001253	BALATA PACKING	TATA spare parts
886387001254	TOOL BOX	TATA spare parts
886387001255	TAIL GATE HINGE	TATA spare parts
886387001256	RUBBER BUMP STOPPER	TATA spare parts
886387001257	20 CUM TIPPER BODY WITHOUT S/F & MTG	TATA spare parts
886387001258	20 CUM SUBFRAME WITHOUT CRADLE ASSY	TATA spare parts
886387001259	MUDGUARD ASSY	TATA spare parts
886387001260	TIPPER BODY ASSEMBLY -16 STD BOX (LPK 25	TATA spare parts
886387001261	TIPPER BODY ASSEMBLY -16 STD BOX (LPK 25	TATA spare parts
886387001262	TIPPER BODY ASSEMBLY -16 STD BOX (LPK 25	TATA spare parts
886387001263	SIDE SKIRT WITH RAIN FLAP FRONT LH	TATA spare parts
886387001264	SIDE SKIRT WITH RAIN FLAP FRONT RH	TATA spare parts
886387001265	SIDE SKIRT WITH RAIN FLAP REAR LH	TATA spare parts
886387001266	SIDE SKIRT WITH RAIN FLAP REAR RH	TATA spare parts
886387001267	PIPE FRAME ASSY WITH RAIN FLAP REAR LH	TATA spare parts
886387001268	PIPE FRAME ASSY WITH RAIN FLAP REAR RH	TATA spare parts
886387001269	PIPE FRAME ASSY WITH RAIN FLAP MIDDLE LH	TATA spare parts
886387001270	PIPE FRAME ASSY WITH RAIN FLAP MIDDLE RH	TATA spare parts
886387001271	FRONT MUDGUARD LH	TATA spare parts

886387001272	FRONT MUDGUARD RH	TATA spare parts
886387001273	RAIN FLAP ONLY WITHOUT SIDE SKIRT FRONT	TATA spare parts
886387001274	RAIN FLAP ONLY WITHOUT SIDE SKIRT REAR	TATA spare parts
886387001275	TAIL DOOR ASSEMBLY	TATA spare parts
886387001276	TAIL DOOR HINGE ASSY LH	TATA spare parts
886387001277	HAMMER MTG PROFILE ASSY	TATA spare parts
886387001278	HAMMER PIN ASSY	TATA spare parts
886387001279	FORK	TATA spare parts
886387001280	TIE ROD	TATA spare parts
886387001281	CAM PLATE	TATA spare parts
886387001282	CROSS ROD BUSH ASSY	TATA spare parts
886387001283	CROSS ROD WASHER	TATA spare parts
886387001284	TAIL DOOR LOCK	TATA spare parts
886387001285	SPRING PLATE1	TATA spare parts
886387001286	STUDS	TATA spare parts
886387001287	TENSION SPRING	TATA spare parts
886387001288	SPRING PLATE2	TATA spare parts
886387001289	CROSS ROD	TATA spare parts
886387001290	PIVOT SPRING	TATA spare parts
886387001291	HEX HEAD BOLT M16X110-10.9	TATA spare parts
886387001292	HEX HEAD BOLT M16X150-10.9	TATA spare parts
886387001293	M16 HARDENED WASHER 32/17X5	TATA spare parts
886387001294	NYLOCK NUT M16 COARSE THREAD	TATA spare parts
886387001295	HEX BOLT M12X1.25X50-10.9	TATA spare parts
886387001296	NYLOCK NUT M12 FINE THREAD	TATA spare parts
886387001297	R/H PIN 60X135	TATA spare parts
886387001298	R/H BUSH 88X90X70	TATA spare parts
886387001299	L CHAIN ASSY	TATA spare parts
886387001300	TAIL DOOR U BEND (DIA 12)	TATA spare parts
886387001301	J HOOK (DIA 10)	TATA spare parts
886387001302	BODY PROP BUSH	TATA spare parts
886387001303	BODY PROP PIN	TATA spare parts
886387001304	SUBFRAME ASSEMBLY	TATA spare parts
886387001305	COMPLETE SUBFRAME ASSY	TATA spare parts
886387001306	COMPLETE TIPPER BODY ASSY W/O HYDRAULICS	TATA spare parts
886387001307	TIPPER BODY ASSY WITHOUT SUBFRAME AND W/	TATA spare parts
886387001308	HOOK ASSY RH	TATA spare parts
886387001309	ASSY TAIL PANEL 610 BS6	TATA spare parts
886387001310	STABLIZER ASSY	TATA spare parts
886387001311	14CUMSTDSUBFRAMEASSLY & WITHOUT CRAD	TATA spare parts
886387001312	14CUMSTD CRADLE ASSY	TATA spare parts
886387001313	COMPLETE TIPPER BODY W/O HYDRAULIC KIT	TATA spare parts
886387001314	CUBED BODY W/O SUBFRAME	TATA spare parts
886387001315	PULLING PIPE ASSY. 2523	TATA spare parts
886387001316	TAIL DOOR HINGE ASSY	TATA spare parts
886387001317	HAMMER ASSEMBLY (LH)	TATA spare parts
886387001318	HAMMER ASSEMBLY (RH)	TATA spare parts

886387001319	TAIL DOOR ASSEMBLY	TATA spare parts
886387001320	TAIL DOOR ASSY /8.5 CUM	TATA spare parts
886387001321	HEX HED SCREW BS6	TATA spare parts
886387001322	RUBBER STRIP BS6	TATA spare parts
886387001323	METALLIC MOUNTING STRIP BS6	TATA spare parts
886387001324	RUBBER PAD BS6	TATA spare parts
886387001325	HEX NUT BS6	TATA spare parts
886387001326	LOCKING CAM ASSY	TATA spare parts
886387001327	CAM PIN	TATA spare parts
886387001328	FORK PIN	TATA spare parts
886387001329	LOAD BODY ASSY 20CUM ON LPTK 3518	TATA spare parts
886387001330	U BOLT	TATA spare parts
886387001331	ALUMINIUM SPACER	TATA spare parts
886387001332	FLAT	TATA spare parts
886387001333	NY LOCK NUT M16	TATA spare parts
886387001334	TAIL GATE	TATA spare parts
886387001335	SUBFRAME ASSY WITH CRADLE STABILIZER & A	TATA spare parts
886387001336	UPPER PIVOT	TATA spare parts
886387001337	ATTACHMENT PLATE	TATA spare parts
886387001338	ATTACHMENT PLATE	TATA spare parts
886387001339	HAMMER ASSLY	TATA spare parts
886387001340	TAIL DOOR ASSY	TATA spare parts
886387001341	DOUBLE HINGE ASSEMBLY	TATA spare parts
886387001342	TAILDOOR HINGE BKT FOR 16 HD WITH PIN	TATA spare parts
886387001343	REMOTE CONTROL CABLE L=5.3 M	TATA spare parts
886387001344	ANTI VIBRATION PAD SET	TATA spare parts
886387001345	ROLLER D=280 CPL	TATA spare parts
886387001346	BEARING BOLT	TATA spare parts
886387001347	CONNECTION HOUSING	TATA spare parts
886387001348	SPACER SUPPORT FOR AIR BREATHER BS6	TATA spare parts
886387001349	GASKET BS6	TATA spare parts
886387001350	HEX. HD. SCREW BS6	TATA spare parts
886387001351	CAP END COVER BS6	TATA spare parts
886387001352	CEC CLAMPING RING BS6	TATA spare parts
886387001353	LOWER RING (DIA 129) BS6	TATA spare parts
886387001354	EXTERNAL STOPPER RING (DIA 149 ) BS6	TATA spare parts
886387001355	S-T-METAL PISTON BEARING (DIA 149) BS6	TATA spare parts
886387001356	S-T-METAL PISTON BEARING (DIA 169) BS6	TATA spare parts
886387001357	16 CUM HD SUBFRAME ASSY	TATA spare parts
886387001358	HANDLE LH BS6	TATA spare parts
886387001359	HANDLE RH BS6	TATA spare parts
886387001360	16STD PRIMA 2825 SF RETRO KIT BS6	TATA spare parts
886387001361	PLATE BS6	TATA spare parts
886387001362	SF CROSS MEMBER BS6	TATA spare parts
886387001363	5 HP PUMP	TATA spare parts
886387001365	HAND CONTRAOL VALVE	TATA spare parts
886387001366	KING PIN 2 BOLTED YORK	TATA spare parts

886387001367	SPRAY SUPPRESSION 720 X 560	TATA spare parts
886387001368	REAR MARKING PLATE 570 X 200	TATA spare parts
886387001369	TOOL BOX ASSEMBLY SIZE 1238 X 350 X 407	TATA spare parts
886387001370	BUTT HINGES 4INCH X 4INCH	TATA spare parts
886387001371	SUPD ASSEMBLY 12M 3A FB LH	TATA spare parts
886387001372	SUPD ASSEMBLY 12M 3A FB RH	TATA spare parts
886387001373	PULLING PIPE ASSEMBLY	TATA spare parts
886387001374	LADDER ASSY	TATA spare parts
886387001375	SUB FRAME ASSEMBLY BS6	TATA spare parts
886387001376	COLLER OD50*ID40*20L BS6	TATA spare parts
886387001377	RAM PROTECTION CAP BS6	TATA spare parts
886387001378	LOWER RING BS6	TATA spare parts
886387001379	UPPER RING ( DIA 72) BS6	TATA spare parts
886387001380	EXTERNAL STOPPER RING BS6	TATA spare parts
886387001381	TAIL GATE ASSLEMBLY	TATA spare parts
886387001382	ASSY SUBFRAME 16CUM TIPPER LPK 2523 /38W	TATA spare parts
886387001383	SUBFRAME ASSY/18 CUM/LPK 3118	TATA spare parts
886387001384	SIDEBOARD ASSY LEFT BS6	TATA spare parts
886387001385	SIDEBOARD ASSY RIGHT BS6	TATA spare parts
886387001386	HEADBOARD ASSY BS6	TATA spare parts
886387001387	SUBFRAME ASSEMBLY BS6	TATA spare parts
886387001388	ATTACHMENT PLATE ASSY 1 BS6	TATA spare parts
886387001389	ATTACHMENT PLATE ASSY 2 BS6	TATA spare parts
886387001390	ATTACHMENT PLATE ASSY 3 BS6	TATA spare parts
886387001391	CIRCLIP 75 BS6	TATA spare parts
886387001392	SIDEBOARD ASSEMBLY LEFT BS4	TATA spare parts
886387001393	SIDEBOARD ASSEMBLY RIGHT BS4	TATA spare parts
886387001394	HEADBOARD ASSEMBLY BS4	TATA spare parts
886387001395	FLOOR ASSEMBLY BS4	TATA spare parts
886387001396	TAIL DOOR ASSEMBLY BS4	TATA spare parts
886387001397	CRADLE + OIL TANK BRACKET ASSEMBLY BS4	TATA spare parts
886387001398	REAR ATTACHMNY PLATE LH BS4	TATA spare parts
886387001399	REAR ATTACHMNY PLATE RH BS4	TATA spare parts
886387001400	LOWER PIVOT ATTACHMENT -1 BS4	TATA spare parts
886387001401	REAR HINGE BKT ASSLY BS4	TATA spare parts
886387001402	REAR HINGE PIN OUTER REST PLATE BS4	TATA spare parts
886387001403	CAM HAMMER ASSEMBLY BS4	TATA spare parts
886387001404	PAD PLATE BS4	TATA spare parts
886387001405	CAM ASSEMBLY LH BS4	TATA spare parts
886387001406	CAM ASSEMBLY RH BS4	TATA spare parts
886387001407	HOOK MOUNTING ASSEMBLY LH BS4	TATA spare parts
886387001408	HOOK MOUNTING ASSEMBLY RH BS4	TATA spare parts
886387001409	HOOK BLOCK ASSLY LH BS4	TATA spare parts
886387001410	HOOK BLOCK ASSLY RH BS4	TATA spare parts
886387001411	SHAFT REAR HINGE	TATA spare parts
886387001412	10 CUM LOAD BODY WITHOUT HYD. KIT	TATA spare parts
886387001413	REFLECTIVE TAPE RED BS6	TATA spare parts

886387001414	HANDLE LH (GREEN PASSI) BS6	TATA spare parts
886387001415	REAR MARKING PLATE BS6	TATA spare parts
886387001416	TATA STICKER BS6	TATA spare parts
886387001417	MTG. CLIT BS6	TATA spare parts
886387001418	ALUMINIUM SPACER BS6	TATA spare parts
886387001419	SPRAY SUPPERASOR BS6	TATA spare parts
886387001420	SIDE MARKER LAMP 12 V BS6	TATA spare parts
886387001421	TOP MARKER LAMP 12 V BS6	TATA spare parts
886387001422	WIRE HARNESS RH BS6	TATA spare parts
886387001423	WIRE HARNESS LH BS6	TATA spare parts
886387001424	REFLECTIVE TAPE RED (1 MTR) BS6	TATA spare parts
886387001425	REFLECTIVE TAPE YELLOW 50 MM WIDTH (12 M	TATA spare parts
886387001426	J HOOK BS6	TATA spare parts
886387001427	BALLATA (12 MTR) BS6	TATA spare parts
886387001428	ASSY RUBBER STOPER BS6	TATA spare parts
886387001429	ASSY HINGE BS6	TATA spare parts
886387001430	D HANDLE BS6	TATA spare parts
886387001431	TAIL PANEL ASSY BS6	TATA spare parts
886387001432	REAR MARKING PLATE BS6	TATA spare parts
886387001433	PLY FLOOR - 2380 X 915 BS6	TATA spare parts
886387001434	PLY FLOOR - 2380 X 1200 BS6	TATA spare parts
886387001435	PLY FLOOR - 2380 X 475 BS6	TATA spare parts
886387001436	MUD FLAP (SPRAY SUPPRESSION) LH BS6	TATA spare parts
886387001437	MUD FLAP (SPRAY SUPPRESSION) RH BS6	TATA spare parts
886387001438	SIDE FLAP BS6	TATA spare parts
886387001439	ELECTRICAL WIRING HARNESS BS6	TATA spare parts
886387001440	SIDE ASSEMBLY LH BS6	TATA spare parts
886387001441	SIDE ASSEMBLY RH BS6	TATA spare parts
886387001442	FRONT ASSEMBLY BS6	TATA spare parts
886387001443	TAIL DOOR ASSEMBLY BS6	TATA spare parts
886387001444	U BOLTS BS6	TATA spare parts
886387001445	ALUMINIUM SPACER BS6	TATA spare parts
886387001446	ASSY . SIDE MARKER BRACKET BS6	TATA spare parts
886387001447	TOP LAMP BS6	TATA spare parts
886387001448	MUDGUARD ASSY. BS6	TATA spare parts
886387001449	REAR PILLAR HANDLE BS6	TATA spare parts
886387001450	PRESSURE HOSE 3/8INCHX3/8INCH BS6	TATA spare parts
886387001451	RETURN HOSE 1/2INCH X1/2INCH BS6	TATA spare parts
886387001452	SUCTION HOSE 1/2INCH X 1/2INCH BS6	TATA spare parts
886387001453	PRESSURE HOSE 3/8INCHX3/8INCH BS6	TATA spare parts
886387001454	PRESSURE HOSE 3/8INCHX3/8INCH BS6	TATA spare parts
886387001455	WIRE HARNESS BS6	TATA spare parts
886387001456	SUCTION FILTER BS6	TATA spare parts
886387001457	ASSLY MUD FLAP REAR (407) 265481100129 B	TATA spare parts
886387001458	PLASTIC MUDGUARD RH (407) BIG 2228701063	TATA spare parts
886387001459	PLASTIC MUDGUARD LH (407) BIG 2228701063	TATA spare parts
886387001460	PLASTIC MUDGUARD RH (407) SMALL 22287010	TATA spare parts



886387001461	PLASTIC MUDGUARD LH (407) SMALL 22287010	TATA spare parts
886387001462	LEG ASSY-TAIL LAMP AND R-PASS MTG[222970	TATA spare parts
886387001463	HAT SECTION FOR R-PASS [222970338233] BS	TATA spare parts
886387001464	BRACKET ASSY TAIL LAMP BS6 [222870100229	TATA spare parts
886387001465	R-PASS CENTER BRACKET [222970338234] BS6	TATA spare parts
886387001466	HANDLE LH (222870906703) A BS6	TATA spare parts
886387001467	HANDLE RH (222870906703) A BS6	TATA spare parts
886387001468	ASSEMBLY RUBBER STOPPERDIA.30*300(222970	TATA spare parts
886387001469	ACRYLIC TUBE BS6	TATA spare parts
886387001470	BALL VALVE BS6	TATA spare parts
886387001471	PVC FLEX HOSE BS6	TATA spare parts
886387001472	BALL VALVE 25 NB BS6	TATA spare parts
886387001473	VACUUM PUMP BS6	TATA spare parts
886387001474	V BELT (SPB-2000) BS6	TATA spare parts
886387001475	PULLEY FOR VACCUM PUMP BS6	TATA spare parts
886387001476	VACUUM RELIEF VALVE BS6	TATA spare parts
886387001477	PRESSURE RELIEF VALVE BS6	TATA spare parts
886387001478	PNEUMATIC CYLINDER BS6	TATA spare parts
886387001479	FORKFOR PNEUMATIC CYLINDDER BS6	TATA spare parts
886387001480	VACUUM GAUGE BS6	TATA spare parts
886387001481	OIL BATH FILTER BS6	TATA spare parts
886387001482	SILICON HOS BEND BS6	TATA spare parts
886387001483	TB CLAMP TB 76 BS6	TATA spare parts
886387001484	TB CLAMP TB 68 BS6	TATA spare parts
886387001485	RUBBER FOR FLOAT BALL BS6	TATA spare parts
886387001486	REAR DOOR RUBBER (2.5MTR) BS6	TATA spare parts
886387001487	PROPELLER SHAFT BS6	TATA spare parts
886387001488	PRIMARY SHUT OFF VALVE BS6	TATA spare parts
886387001489	SECONDARY SHUT OFF VALVE BS6	TATA spare parts
886387001490	TANK UNIT BS6	TATA spare parts
886387001491	REAR DOOR FOR TANK UNIT BS6	TATA spare parts
886387001492	REAR DOOR LOCK BS6	TATA spare parts
886387001493	SUB FRAME ASSEMBLY BS6	TATA spare parts
886387001494	U BOLT FOR MOUNTING BS6	TATA spare parts
886387001495	SPOOL VALVE BS6	TATA spare parts
886387001496	DUMPER PLACER ARM CYLINDER BS6	TATA spare parts
886387001497	DUMPER PLACER BIN BS6	TATA spare parts
886387001498	REAR PILLAR HANDLE BS6	TATA spare parts
886387001499	ROPE HOOK BS6	TATA spare parts
886387001500	MUDGUARD PANEL	TATA spare parts
886387001501	CARRYING ROLLER 6/7M3 C BS6	TATA spare parts
886387001502	BEARING BOLT 50 BS6	TATA spare parts
886387001503	GREASE NIPPLE A M 8X1 BS6	TATA spare parts
886387001504	GROOVED NUT M50X1.5 BS6	TATA spare parts
886387001505	CLAMPING SLEEVE 8X 20 BS6	TATA spare parts
886387001506	THREADED BUSH BS6	TATA spare parts
886387001507	ROLLER BODY BS6	TATA spare parts

886387001508	CHARGING HOPPER WITH MOUNT PLATE CPL. BS	TATA spare parts
886387001509	HEX.SCREW M 10X 25 VERZ.8.8 DIN 933 BS6	TATA spare parts
886387001510	HEX.NUT M 10 8 VERZ. DIN 934 BS6	TATA spare parts
886387001511	HEX BOLT M20 X 70 VERZ 8.8 DIN 931 ZINC	TATA spare parts
886387001512	CHUTE L=1497 O.VBL F.VR BS6	TATA spare parts
886387001513	WEARING SHEET FOR CHUTE L=1497 C/AR BS6	TATA spare parts
886387001514	DISCHRG TRAY W/O WEAR SHEET. BS6	TATA spare parts
886387001515	WASHER 17 BS6	TATA spare parts
886387001516	HEX.HEAD BOLT DIN 931 M 6X55-8.8-ZINC C.	TATA spare parts
886387001517	RUBBER FORMED PART BS6	TATA spare parts
886387001518	WASHER - M16 BS6	TATA spare parts
886387001519	WASHER DIN 125 A 21-140HV-ZINC C. BS6	TATA spare parts
886387001520	HEX.SOC.HD.CAPSCREW DIN912 M12 X120-10.9	TATA spare parts
886387001521	WATER TANK 450 LTS. ND BS6	TATA spare parts
886387001522	DISC 13 DIN 6916 TZN C45 BS6	TATA spare parts
886387001523	WASHER DIN 6916 21-C45-TZN BS6	TATA spare parts
886387001524	OIL COOLER (CODE NO 0803.035.1000) BS6	TATA spare parts
886387001525	PROTECTING CAP - TEMPERATURE SENSOR BS6	TATA spare parts
886387001526	STRAP BLACK 4.7X200MM(CABLE TIE - 200MM)	TATA spare parts
886387001527	RING SOCKET 10 X 2.5 MM WITH PLASTIC BS6	TATA spare parts
886387001528	RING SOCKET 6 X 2.5 MM WITH PLASTICI BS6	TATA spare parts
886387001529	CABLE SHOES WITH PLASTIC SLEEVE 2.5 BS6	TATA spare parts
886387001530	RING SOCKET 5 X 2.5 MM WITH PLASTIC BS6	TATA spare parts
886387001531	MULTI CORE CABLE - 4X2.5SQ.MM OLEFLEX BS	TATA spare parts
886387001532	SINGLE CORE WIRE 1 SQMM BLUE BS6	TATA spare parts
886387001533	SINGLE CORE WIRE 2.5 SQ.MM GREEN/ BS6	TATA spare parts
886387001534	CABLE SHOES WITH PLASTIC SLEEVE 1.5 BS6	TATA spare parts
886387001535	RUBBER BUSHING BS6	TATA spare parts
886387001536	ENGINE BASE FRAME ND BS6	TATA spare parts
886387001537	BRACKET BS6	TATA spare parts
886387001538	SILENCER BS6	TATA spare parts
886387001539	CLIP FOR SILENCER - TM BS6	TATA spare parts
886387001541	HEX. BOLT M12X120 VERZ. BS6	TATA spare parts
886387001542	DISC 13 DIN 7349 VERZ. BS6	TATA spare parts
886387001543	HEX.SCREW DIN 933 M 16 BS6	TATA spare parts
886387001544	WASHER DIN 6916 17-C45- BS6	TATA spare parts
886387001545	NYLOCK NUT M16 DIN 985 BS6	TATA spare parts
886387001546	SCHNORR LOCK WASHER BS6	TATA spare parts
886387001547	CLAMP FOR SILENCER BS6	TATA spare parts
886387001548	HEX.SCREWDIN 933 M 8 X BS6	TATA spare parts
886387001549	HOSE CLAMP 70 MM HD FOR BS6	TATA spare parts
886387001550	BRACKET FOR CABLE BS6	TATA spare parts
886387001551	HEX.HEAD SCREW DIN 933 M8 X 25- BS6	TATA spare parts
886387001552	HEX.HEAD SCREW DIN 933 M 10 X BS6	TATA spare parts
886387001553	HOLDING TUBE FOR 4 BS6	TATA spare parts
886387001554	WASHER DIN 126 11-100HV- BS6	TATA spare parts
886387001555	RUBBER BUFFER BS6	TATA spare parts

886387001556	SCREW DIN 933 M 10 X BS6	TATA spare parts
886387001557	NYLOCK NUT DIN 985 M12 BS6	TATA spare parts
886387001558	SQUARE BAR 16 X 16 X 60 BS6	TATA spare parts
886387001559	HEX.SCREW M 12X 50 VERZ. BS6	TATA spare parts
886387001560	PLAIN WASHER DIN 6916 BS6	TATA spare parts
886387001561	SPECIAL WASHER BS6	TATA spare parts
886387001562	DOOM [SS-CMP-001] BS6	TATA spare parts
886387001565	BEARING HOUSING [SS-CMP- BS6	TATA spare parts
886387001566	WATER CUTTING (19 X 32 X BS6	TATA spare parts
886387001567	BEARING SPACER BS6	TATA spare parts
886387001568	MECHANICAL SEAL (SS) BS6	TATA spare parts
886387001569	DOOM NUT BS6	TATA spare parts
886387001570	IMPELLER LOCAK WASHER BS6	TATA spare parts
886387001571	BEARING FOR WATER PUMP BS6	TATA spare parts
886387001572	INTERNAL CIRCLIP BS6	TATA spare parts
886387001573	KEY BS6	TATA spare parts
886387001574	PIN DIA (3 X 9)[SS-CMP-013] BS6	TATA spare parts
886387001575	NON METAL GASKET 164 X BS6	TATA spare parts
886387001576	HEX.SOCKET HEAD CAP SCREW BS6	TATA spare parts
886387001577	OIL SEAL FOR WATER PUMP BS6	TATA spare parts
886387001578	2INCH PLASTIC DUMMY BS6	TATA spare parts
886387001579	DIA 34 PLASTIC DUMMY BS6	TATA spare parts
886387001580	PULLEY BS6	TATA spare parts
886387001581	WATER LINE PIPE RH BS6	TATA spare parts
886387001582	PLATE (ND) BS6	TATA spare parts
886387001583	HOSE CLIP ID = 44 BS6	TATA spare parts
886387001584	TEE 25 EN10242 B1-1-ZN-A BS6	TATA spare parts
886387001585	HEXAGON NIPPLE DN25 N8 EN BS6	TATA spare parts
886387001586	M.S.PIPE 1INCH X 200 MM LG. ONE BS6	TATA spare parts
886387001587	L.P. HOSE DN32 X 650 STN 52 BS6	TATA spare parts
886387001588	HEXAGON NIPPLE DN 20 N8 BS6	TATA spare parts
886387001589	BALL VALVE DN20 BRASS BS6	TATA spare parts
886387001591	COCK DN25 (BALL VALVE 1INCH BRASS) BS6	TATA spare parts
886387001592	HEX.SOC.HD.CAPSCREWDIN912 BS6	TATA spare parts
886387001593	DISC M 8 BS6	TATA spare parts
886387001594	NYLOCK NUT M10 GR.10 DIN 985 BS6	TATA spare parts
886387001595	DISC 10 5 DIN 125 VERZ.ST BS6	TATA spare parts
886387001596	PAD FOR WATER PIPE MOUNTING BS6	TATA spare parts
886387001597	L.P. HOSE DN32 X 360 BS6	TATA spare parts
886387001598	LOW PRESSURE HOSE DN20 X 2570LG BS6	TATA spare parts
886387001599	ELBOW DN20 A1 EN10242 V BS6	TATA spare parts
886387001600	HEX. NIPPLE DN25-DN20 N8 EN 10242V BS6	TATA spare parts
886387001601	THREADED PIPE DN25 =1350MM(ONE SIDE) BS6	TATA spare parts
886387001602	U BOLT DIA 10MM BS6	TATA spare parts
886387001603	L.P. HOSE DN32 X 820 LG. STN 52 BS6	TATA spare parts
886387001604	PIPE LINE SMALL (TEE PIPE) BS6	TATA spare parts
886387001605	HEAVY DUTY CLAMP TB BS6	TATA spare parts

886387001606	L.P.HOSE DN48 X 790 BS6	TATA spare parts
886387001607	WATER HOSE (DN40) 48X6 BS6	TATA spare parts
886387001608	L.P. HOSE DN48 X 275 STN BS6	TATA spare parts
886387001609	ONE SIDE THREADED PIPE BS6	TATA spare parts
886387001610	ELBOW DN40 A1 EN 10242V BS6	TATA spare parts
886387001611	G.I. REDUCER 2INCH X 1 1/2INCH BS6	TATA spare parts
886387001612	WATER LINE HOLDER FOR BS6	TATA spare parts
886387001613	HEX.HEAD SCREW DIN 933 BS6	TATA spare parts
886387001614	BOTH SIDE THREADED PIPE BS6	TATA spare parts
886387001615	LOCK WASHER DIN 127 BS6	TATA spare parts
886387001616	SUPPORT PIPE BS6	TATA spare parts
886387001617	HOSE RETAINER BS6	TATA spare parts
886387001618	HEX.HEAD SCREW M8X20 BS6	TATA spare parts
886387001619	HOSE CLAMP ID 27 BS6	TATA spare parts
886387001620	ALLEN SCREW M4X30 BS6	TATA spare parts
886387001621	NYLOCKNUT M4 BS6	TATA spare parts
886387001622	SPRING WASHER DIN 127 B 8 BS6	TATA spare parts
886387001627	CHEESE HEAD SCREW M 6X140 DIN 912 BS6	TATA spare parts
886387001628	LOCK NUT M 6 10 TZN DIN 980 BS6	TATA spare parts
886387001629	PLASTIC SIDE ROLLER COVER. C BS6	TATA spare parts
886387001630	DISC 6 ISO 7093-1 200HV A2 BS6	TATA spare parts
886387001631	HEX.SCREW DIN 933 M 6 X 16-8.8-ZINC C. B	TATA spare parts
886387001632	NAME PLATE BS6	TATA spare parts
886387001633	ALUMINIUM RIVET 1/8INCH X 1/2INCH BS6	TATA spare parts
886387001634	RUBBER PLUG 16MM BS6	TATA spare parts
886387001635	RUBBER PLUG 20MM BS6	TATA spare parts
886387001636	SCHWING STETTER SIGN ALUMINIUM BS6	TATA spare parts
886387001637	HEX.HEAD SCREW DIN 933 M BS6	TATA spare parts
886387001638	NYLOCK NUT M6 DIN 985 GR. BS6	TATA spare parts
886387001639	WASHER DIN 125 B 6.4 BS6	TATA spare parts
886387001640	RUBBER PLUG 12MM BS6	TATA spare parts
886387001641	STICKER LABLE MIXER (DRUM BS6	TATA spare parts
886387001642	CABLE TIE 300 MM LONG BS6	TATA spare parts
886387001643	STETTER LOGO STICKER BS6	TATA spare parts
886387001644	SS LOGO WITH LETTERING BS6	TATA spare parts
886387001645	SYMBOL SIGN INCHCRANE HOOKINCH BS6	TATA spare parts
886387001646	GREASE NIPLLE CAP (1/8INCH) BS6	TATA spare parts
886387001647	DO S AND DON TS STICKER BS6	TATA spare parts
886387001648	PLATE BS6	TATA spare parts
886387001649	HOLDING HOOK BS6	TATA spare parts
886387001650	EXTENSION CHUTE BS6	TATA spare parts
886387001651	EXTENTION CHUTE BS6	TATA spare parts
886387001652	HEX.HEAD SCREW BS6	TATA spare parts
886387001653	DISC BS6	TATA spare parts
886387001654	U BOLT 8MM BS6	TATA spare parts
886387001655	WASHER M8 BS6	TATA spare parts
886387001656	NYLOCK NUT M8 BS6	TATA spare parts

886387001657	PROT. HELMET BS6	TATA spare parts
886387001658	BATTERY CABLE 35SQ.MM X 2500 MM LG BS6	TATA spare parts
886387001659	COCK (BALL VALVE 1 1/2INCH) BS6	TATA spare parts
886387001660	L.P. HOSE DN20 X 1500 STN 52 BS6	TATA spare parts
886387001661	RUBBER HOSE ID 19 MM X 5 MM X 10 M LONG	TATA spare parts
886387001662	HOSE CLIP 27-31MM BS6	TATA spare parts
886387001663	SPRAYER BS6	TATA spare parts
886387001664	TWIN NIPPLE DN 40= 80 EN 10241 BS6	TATA spare parts
886387001665	Y STRAINER DN40 - SS BS6	TATA spare parts
886387001666	GREASE (MULTI PURPOSE) S1 V160 BS6	TATA spare parts
886387001667	PLASTIC CONTAINER FOR GREASE BS6	TATA spare parts
886387001669	REAR PEDESTAL 6-7M3 C RH VERSION BS6	TATA spare parts
886387001670	FRONT PEDESTAL CPL. BS6	TATA spare parts
886387001671	GROOVED NUT M75X1.5 BS6	TATA spare parts
886387001672	THREADED PIN 5 X 10 BS6	TATA spare parts
886387001673	HOLDING PLATE FOR DISCHARGE SHELL BS6	TATA spare parts
886387001674	WASHER DIN 7349 10.5-ST-ZINC C BS6	TATA spare parts
886387001675	SUPPORT ARM C2 - RH BS6	TATA spare parts
886387001676	MAIN CHUTE PIVOT BS6	TATA spare parts
886387001677	CLAMPING RING ID=100 BS6	TATA spare parts
886387001678	THREADED PIECE BS6	TATA spare parts
886387001679	RING BS6	TATA spare parts
886387001680	LEVER BS6	TATA spare parts
886387001681	DISC ID= 56 OD=115 T= 5 CUSN8F40 BS6	TATA spare parts
886387001682	GREASE NIPPLE A S 8X1 DIN 71412 0 DEG BS	TATA spare parts
886387001683	DRUMFLAP BS6	TATA spare parts
886387001684	HEX.SCREW M 12X 30 (SPL) BS6	TATA spare parts
886387001685	WASHER 13 BS6	TATA spare parts
886387001686	WEAR PROTECTION BS6	TATA spare parts
886387001687	SPLIT PIN M4X 32 BS6	TATA spare parts
886387001688	BOLT 16H11X 45 BS6	TATA spare parts
886387001689	CHUTE SUPPORT WITH CRANK BS6	TATA spare parts
886387001690	POLYAMIDE BLOCK 25 X 40 X 30 MM BS6	TATA spare parts
886387001691	RAILING WITH PLATFORM - 4MM BS6	TATA spare parts
886387001692	CONSOLE FOR LADDER BS6	TATA spare parts
886387001693	LADDER BOTTOM PIPE ASEMBLY - RH C VER	TATA spare parts
886387001694	U BOLT 10MM DIA BIG(DIA 52) BS6	TATA spare parts
886387001695	PIPE CLAMP FOR U BOLT BS6	TATA spare parts
886387001696	WASHER DIN 440 R 9-100HV-ZINC C BS6	TATA spare parts
886387001697	HEX.SCREW DIN 933 M 8 X 30-8.8-A2C BS6	TATA spare parts
886387001698	PLATE RIGHT BS6	TATA spare parts
886387001699	TOP PLATE BS6	TATA spare parts
886387001700	SPRING-BOLT BS6	TATA spare parts
886387001701	LADDER 8-SPR. L=2080 BS6	TATA spare parts
886387001702	FLAP LEVER FOR STEEL LADDER BS6	TATA spare parts
886387001703	HEX.SCREW M 16X 55 VERZ.8.8 DIN 933 BS6	TATA spare parts
886387001704	CENTERING PIECE BS6	TATA spare parts

886387001705	GUIDE BLOACK BS6	TATA spare parts
886387001706	SUSPENSION FOR FEED HOPPER C BS6	TATA spare parts
886387001707	TRANSVERSAL PIPE CPL RH BS6	TATA spare parts
886387001708	CLAMPING PIECE ELBOW BS6	TATA spare parts
886387001709	HEX.SCREW M 16X 110 VERZ.8.8 DIN 931 BS6	TATA spare parts
886387001710	DISC DIN 7349 17-ST GALV. BS6	TATA spare parts
886387001711	HEX.NUT M 16 8 VERZ. DIN 934 BS6	TATA spare parts
886387001712	HEX.SCREW DIN 933 M 16 X 45-8.8-A2C BS6	TATA spare parts
886387001713	HEX.SCREW M 16X 60 VERZ.8.8 DIN 933 BS6	TATA spare parts
886387001714	RUBBER SHEET C2 BS6	TATA spare parts
886387001715	WASHER DIN 440 R 6.6-A2 EN BS6	TATA spare parts
886387001716	HEX.SCREW DIN 933 M 6 X 25-8.8-ZINC C. B	TATA spare parts
886387001717	PROTECTIVE GRILL-RH FOR C2 VERSION BS6	TATA spare parts
886387001718	GRID BS6	TATA spare parts
886387001719	SUPPORT FOR WATER TANK 450-800 L BS6	TATA spare parts
886387001720	PVC BAND 60 X 5 X 480MM BS6	TATA spare parts
886387001721	DISC 21 DIN 7349 VERZ.ST BS6	TATA spare parts
886387001722	HEX.HEAD SCREW DIN 933 M 20 X 70-8.8-A3C	TATA spare parts
886387001723	TANK BAND FOR OD = 754 BS6	TATA spare parts
886387001724	STRIP 60/52X4/2=1800 BS6	TATA spare parts
886387001725	NUT G1/2INCH DIN 431 BS6	TATA spare parts
886387001726	SCREW IN HEAD BS6	TATA spare parts
886387001727	RUBBER WASHER 12 X 19 X 4 BS6	TATA spare parts
886387001728	M.S.COUPLING 1/2INCH X 35 MM LONG BS6	TATA spare parts
886387001729	M.S.COUPLING 1/2INCH X 90MM LONG BS6	TATA spare parts
886387001730	WATER RUBBER HOSE (DN40) 48X6 = 1300 BS6	TATA spare parts
886387001731	WATER LEVEL SCALE BS6	TATA spare parts
886387001732	HOLDER FOR SCALE BS6	TATA spare parts
886387001733	TANK BAND FOR OD = 754 BS6	TATA spare parts
886387001734	BOLT 20H11 BS6	TATA spare parts
886387001735	SQUARE BAR 20 X 80 MM LG BS6	TATA spare parts
886387001736	COUNTER HOLDER BS6	TATA spare parts
886387001737	FORGING PRESSURE PIECE BS6	TATA spare parts
886387001738	U BOLT BS6	TATA spare parts
886387001739	PRESSURE PIECE BS6	TATA spare parts
886387001740	U BOLT BS6	TATA spare parts
886387001741	COUNTER HOLDER BS6	TATA spare parts
886387001742	LOCK NUT M20 X 1.5 10 T Z N DIN 980 BS6	TATA spare parts
886387001743	SQUARE BAR 20X20X60 LONG BS6	TATA spare parts
886387001744	SUPPORT BRACKET MN 6-7CUM. BS6	TATA spare parts
886387001745	TAPER WASHER M12 DIN 434 (GALVANIZED) BS	TATA spare parts
886387001746	HEX. SCREW DIN 933M12X45-10.9GT500 BS6	TATA spare parts
886387001747	NYLOCK NUT DIN 985 M12 - GR.10 A2C BS6	TATA spare parts
886387001748	HALF FLANGE DN 25 BS6	TATA spare parts
886387001749	H.P HOSE DN25/4SH 90đ ELBOW&ST.SHANK-925	TATA spare parts
886387001750	HEX. SCREW 7/16INCH-14 UNC X 44.5 BS6	TATA spare parts
886387001751	STRAIGHT ADAPTOR 11/4INCHBSP(M) & M36X2(	TATA spare parts

886387001752	SCREW IN NIPPLE DDL 22 BS6	TATA spare parts
886387001753	T-SCREWING EE L 22 BS6	TATA spare parts
886387001754	L.P HOSE DN20X650-BOTH SIDE - 90° ELBOW	TATA spare parts
886387001755	L.P HOSE DN20X1000 L.G BOTH SIDE- 90 BS6	TATA spare parts
886387001756	LOW PRE HYD HOSE OLNW DN32 X 1110 LG. BS	TATA spare parts
886387001757	SUCTION CONNECTION (M36X2 - 1 5INCH/16)	TATA spare parts
886387001758	MALE STUDELBOW ADJUSTABLE L28 BS6	TATA spare parts
886387001759	REDUCTION ASSEMBLY BS6	TATA spare parts
886387001760	GES 1 1/16INCH - 12 UNF / 22L BS6	TATA spare parts
886387001761	PUMP ACA462321R0BMMMCCHH0000020D BS6	TATA spare parts
886387001762	HEX.SOC.HD.SCREWDIN912 M10X40-10.9-GT500	TATA spare parts
886387001763	HEX.SOC.HD.SCREWDIN912 M10X30-10.9-GT500	TATA spare parts
886387001764	STUD M12 X 35 DIN 939 - 8.8 - ZINC.C BS6	TATA spare parts
886387001765	ENGINE FLANGE - CM BS6	TATA spare parts
886387001766	BONFIGLIOLI GEAR BOX 575L4 55030041_A BS	TATA spare parts
886387001767	HYDRAULIC MOTOR 75 CC/REV-(143) BS6	TATA spare parts
886387001768	HEX.HEAD BOLT DIN931 M20 X110-10.9-GT500	TATA spare parts
886387001769	NYLOCK NUT M20 GR.10 DIN 985 A2C BS6	TATA spare parts
886387001770	DISC 14 DIN 7989 TZN ST BS6	TATA spare parts
886387001771	STUD M 12X 40 VERZ.8.8 DIN 835 BS6	TATA spare parts
886387001772	PETROL HOSE ID 7.5 X 3 - 1.4 M BS6	TATA spare parts
886387001773	OIL COOLER-24V-REGULAR(CODE 0403.101.000	TATA spare parts
886387001774	RUBBER BUFFER M12 BS6	TATA spare parts
886387001775	HEX.NUT M 12 8 VERZ. DIN 934 BS6	TATA spare parts
886387001776	LOCK WASHER S 12-ZINC C. BS6	TATA spare parts
886387001777	SUCTION FILTERS (CODE NO 8061.018.0000)	TATA spare parts
886387001778	SEALING RING - 126X4(CODE 8059.002.0001)	TATA spare parts
886387001779	COOLER FAN 24V (AKG NO. - 8407.304.0246)	TATA spare parts
886387001780	MULTI CORE CABLE - 4X1.5SQ.MM OLEFLEX BS	TATA spare parts
886387001781	DISCONNECTABLE LUG WITH PLASTIC SLEEVE B	TATA spare parts
886387001782	CABLE GLAND PG9 BS6	TATA spare parts
886387001783	COUNTER NUT - PG9 BS6	TATA spare parts
886387001784	REMOTE CABLE ASSY.- 7 CU. BS6	TATA spare parts
886387001785	HEX.HD.BOLT DIN931 M6 X 80 BS6	TATA spare parts
886387001786	HEX. SCREW 3/8INCH-16UNC-2A- BS6	TATA spare parts
886387001787	CONTROL CABLE BKT FOR EATON BS6	TATA spare parts
886387001788	LOCK WASHER S TYPE M10 BS6	TATA spare parts
886387001789	ANGLE JOINT M6 X 20 BS6	TATA spare parts
886387001790	POWER RELAY 24V DC 20A BS6	TATA spare parts
886387001791	SWITCH BOX BS6	TATA spare parts
886387001792	ELEC. CABLE CONDUIT DIA 26.7X2.87X50MM B	TATA spare parts
886387001793	WIRING SLEEVE 10 MM BS6	TATA spare parts
886387001794	HEAT SHRINKABLE SLEEVE 25MM BS6	TATA spare parts
886387001795	TIPPING CYLINDER GHS175-4-4520 C (CM) BS	TATA spare parts
886387001796	HEXAGONAL BOLT M16 X 55 X 1.5 GRADE 10.9	TATA spare parts
886387001797	ACV SQUARE MOUNTING BRACKET (57 X 64 X 6	TATA spare parts
886387001798	TANK BODY KIT BP W/O BAFFEL (294 X 604 X	TATA spare parts

886387001799	RUBBER STRAP OIL TANK (46 X 3.3 X 1420)	TATA spare parts
886387001800	TANK METAL STRAP WELDED (294 X 604 X 40	TATA spare parts
886387001801	NRV ADAPTER KIT G1INCH BSPOT - 1 7/16INC	TATA spare parts
886387001802	PRESSURE ADAPTER KIT (R1 BSPOT - 1 7/1	TATA spare parts
886387001803	PRESSURE ADAPTER KIT 90° ELBOW SWIVEL (1	TATA spare parts
886387001804	SUCTION ELBOW ADAPTER KIT (R1INCH BSPOT	TATA spare parts
886387001805	HP HOSE R2 1INCH DL60 1 7/16INCH ORFS-ST	TATA spare parts
886387001806	HOSE ROUTING CLAMP KIT 131 BS6	TATA spare parts
886387001807	HOSE ROUTING CLAMP KIT 158 BS6	TATA spare parts
886387001808	BODY FIX KIT (IND-TYPE) BS6	TATA spare parts
886387001809	AIR TUBE (OD6 X ID4 12 MTRS) BS6	TATA spare parts
886387001810	SAFETY TIPPING STICKER (TATA) BS6	TATA spare parts
886387001811	AIR CONTROL VALVE (WITH PTO SWITCH AND C	TATA spare parts
886387001812	RETURN LINE FILTER BASE - BUILT IN TYP B	TATA spare parts
886387001813	RETURN LINE FILTER KIT (150L) BS6	TATA spare parts
886387001814	SPRING WASHER M8 (ZINC CR3) BS6	TATA spare parts
886387001815	SPRING WASHER M10 X 16 (ZINC CR3 DIN 79	TATA spare parts
886387001816	O-RING (143 X 13 NBR SHORE 70) BS6	TATA spare parts
886387001817	MIXER SUB FRAME CPL. 225 - 6CUM	TATA spare parts
886387001818	DISCHARGE SUPPORT BLOCK BS6	TATA spare parts
886387001819	FRONT PEDESTAL BS6	TATA spare parts
886387001820	CARRYING ROLLER CPL. D=250MM R.H ND BS	TATA spare parts
886387001821	CARRYING ROLLER CPL. D=250MM L.H ND BS	TATA spare parts
886387001822	ROLLER COVER FOR 7CUM. N2 - VERSION BS6	TATA spare parts
886387001823	CARRYING ROLLER D=250 CPL. BS6	TATA spare parts
886387001824	HEX.SCREW M8 X 45 (1.4301) DIN 933-A2C B	TATA spare parts
886387001825	LOCK WASHER 8 BS6	TATA spare parts
886387001826	HEX.SCREW DIN 933 M 12 X 30-8.8-ZINC C.	TATA spare parts
886387001827	FLAT 40 X 10 X 177 BS6	TATA spare parts
886387001828	HEX.HEAD BOLT DIN931M20X65-8.8-ZINC C. B	TATA spare parts
886387001829	SUPPORT ARM ND - RH BS6	TATA spare parts
886387001830	PLATT 8 X 20 X 60RM BS6	TATA spare parts
886387001831	BOLT SPACER BS6	TATA spare parts
886387001832	CHARGING HOPPER D VERSION BS6	TATA spare parts
886387001833	WEAR PLATE (CHARGING HOPPER) BS6	TATA spare parts
886387001834	LADDER JOINT BS6	TATA spare parts
886387001835	LADDER BOTTOM PIPE - 7 CU.M N2 VER. BS6	TATA spare parts
886387001836	HEX.SCREW M 20X 40 VERZ.8.8 DIN 933 BS6	TATA spare parts
886387001837	LADDER FIXING PIPE BS6	TATA spare parts
886387001838	LOCK WITH MOUNTING PARTS BS6	TATA spare parts
886387001839	OVERLAY BRACKET FOR COCK SHUTTER BS6	TATA spare parts
886387001840	BLOCK FOR COCK SHUTTER BS6	TATA spare parts
886387001841	HEX.HEAD SCREW DIN 933 M 12 X 35- BS6	TATA spare parts
886387001842	HEX.HEAD SCREW DIN 933 M 12 X 25- BS6	TATA spare parts
886387001843	RUBBER SHEET V VERSION BS6	TATA spare parts
886387001844	H.P.HOSE DN25/4 CAP NUT & ELBOW- BS6	TATA spare parts
886387001845	HEX.HD BOLT DIN 931 M 20 X150-10.9-GT500	TATA spare parts



886387001846	MOTOR FAN ( CODE NO 8407.304.0167) BS6	TATA spare parts
886387001847	FAN COWL ( CODE NO 1053.151.4010) BS6	TATA spare parts
886387001848	MULTICORE CABLE HARNESS 7*2.5 - 3 METER	TATA spare parts
886387001849	P HOSE DN40(ID-48.3) X 320 STN52 BS6	TATA spare parts
886387001850	MOUNTING BRACKET LH BS6	TATA spare parts
886387001851	MOUNTING BRACKET RH BS6	TATA spare parts
886387001852	HEX.HEAD SCREW DIN933 M16 X 35-8.8-A2C B	TATA spare parts
886387001853	WATER LINE BEND PIPE- DN40 BS6	TATA spare parts
886387001854	HEX. SCREW M10 X 30 10.9 DIN 933 - GT500	TATA spare parts
886387001855	DISC DIN 125 A 10.5-140HV-A2C BS6	TATA spare parts
886387001856	MOUNTING PLATE BS6	TATA spare parts
886387001857	OIL COOLER CPL.-24V(CODE -0403.009.0000)	TATA spare parts
886387001858	THERMO SWITCH - SEAL RING(CODE NO 603655	TATA spare parts
886387001859	M.S.PIPE 1INCH X 360MM L WITH ONESIDE TH	TATA spare parts
886387001860	HAYES COUPLING - Z 15 - 132845 BS6	TATA spare parts
886387001861	WATER PIPE LINE FOR ND BS6	TATA spare parts
886387001862	L.P HOSE DN32 X 480MM LONG BS6	TATA spare parts
886387001863	4-WAY FITTING DN 25 BS6	TATA spare parts
886387001864	P.HOSE DN 40 X 130 STN52 BS6	TATA spare parts
886387001865	HOSE RETAINER BRACKET BS6	TATA spare parts
886387001866	MIXER SUBFRAME RH - 7 CU.M. BS6	TATA spare parts
886387001867	MIXER SUBFRAME LH - 7 CU.M. BS6	TATA spare parts
886387001868	LOCK NUT M20 - 10-TZN DIN 980 BS6	TATA spare parts
886387001869	BEARING BLOCK BS6	TATA spare parts
886387001870	DISC ID= 13 AD= 60 T= 8 STN 177 BS6	TATA spare parts
886387001871	STOPPER PLATE 10 X 10 X 30 SQUARE BS6	TATA spare parts
886387001872	THREADED BUSH BS6	TATA spare parts
886387001873	TAPER ROLLER BEARING 30315 A DIN BS6	TATA spare parts
886387001874	RING NILO BS6	TATA spare parts
886387001875	BOLT BS6	TATA spare parts
886387001876	HEX. NUT M52 X 1.5 BS6	TATA spare parts
886387001877	RUBBER RING BS6	TATA spare parts
886387001878	SUPPORT PLATE BS6	TATA spare parts
886387001879	SUSPENSION ASSY - 3CUM BS6	TATA spare parts
886387001880	GRILL RH - 3CUM BS6	TATA spare parts
886387001881	WASHER - M12 BS6	TATA spare parts
886387001882	HEX.NUT DIN 934 M 12-8-A2C BS6	TATA spare parts
886387001883	L.P. HOSE DN32 X 1170 BS6	TATA spare parts
886387001884	BODY FITTING (M42x2) WITH O RING BS6	TATA spare parts
886387001885	GES FITTING R3/4-16 UNF WITH 22L (M30X2)	TATA spare parts
886387001886	HYDRAULIC PUMP 49CC BS6	TATA spare parts
886387001887	CONNECTION HOUSING BS6	TATA spare parts
886387001888	CONTROL CABLE BKT FOR EATON PUMP BS6	TATA spare parts
886387001889	HYDRAULIC MOTOR 55CC-(126) BS6	TATA spare parts
886387001890	THERMO SWITCH AKG 8060.003.0000 BS6	TATA spare parts
886387001891	L.P. HOSE DN32 X 1470 BS6	TATA spare parts
886387001892	CRADLE ASSEMBLY	TATA spare parts

886387001893	BODY MTG STOOL 145L BS6	TATA spare parts
886387001894	BODY MTG STOOL 110L BS6	TATA spare parts
886387001895	MUD GUARD ASSY. BS6	TATA spare parts
886387001896	CYLINDERMTG TOP BKT BS6	TATA spare parts
886387001897	CYLINDER MTG BKT LOWER BS6	TATA spare parts
886387001898	BODY FULCRUM PLATE BS6	TATA spare parts
886387001899	TAIL DOOR BS6	TATA spare parts
886387001900	BODY PROB ASSY BS6	TATA spare parts
886387001901	BODY MTG PIN BS6	TATA spare parts
886387001902	BODY MTG BUSH BS6	TATA spare parts
886387001903	CYLINDER MTG BOTTOM PIN BS6	TATA spare parts
886387001904	CYLINDER MTG TOP PIN BS6	TATA spare parts
886387001905	PUSH PULL CABLE BS6	TATA spare parts
886387001906	HYDRAULIC KIT TC 301 BS6	TATA spare parts
886387001907	PTO DRIVEN PUMP 5 SPEED BS6	TATA spare parts
886387001908	TOP LID BS6	TATA spare parts
886387001909	RUBBER STRAP OIL TANK (46 X 3.3 X 1420)	TATA spare parts
886387001910	HOSE ROUTING CLAMP KIT 31 BS6	TATA spare parts
886387001911	HOSE ROUTING CLAMP KIT 58 BS6	TATA spare parts
886387001912	T-VALVE EXTENSION FLANGE (G1 1/2INCH BSP	TATA spare parts
886387001913	BASE TUBE DIA 197X1388 CM BS6	TATA spare parts
886387001914	STAGE TUBE KIT DIA 175X1345 BS6	TATA spare parts
886387001915	STAGE TUBE KIT DIA 155X1345 BS6	TATA spare parts
886387001916	STAGE TUBE KIT DIA 135X1345 BS6	TATA spare parts
886387001917	STAGE TUBE KIT DIA 116 X1355 9 THREADED)	TATA spare parts
886387001918	BOTTON BASE PLATE DIA.197 BS6	TATA spare parts
886387001919	BOTTON BASE O-RING DIA 169.3X DIA 5.7 BS	TATA spare parts
886387001920	BASE SUPPORT RING DIA 170.5X4.75X1.9 BS6	TATA spare parts
886387001921	SEAL KIT FOR BASE TUBE DIA 197 BS6	TATA spare parts
886387001922	SEAL KIT FOR BASE TUBE DIA 175 BS6	TATA spare parts
886387001923	SEAL KIT FOR BASE TUBE DIA 155 BS6	TATA spare parts
886387001924	SEAL KIT FOR BASE TUBE DIA 135 BS6	TATA spare parts
886387001925	OUTER RING KIT DIA 175 CONSISTS OF BS6	TATA spare parts
886387001926	OUTER RING KIT DIA 155 CONSISTS OF BS6	TATA spare parts
886387001927	OUTER RING KIT DIA 135 CONSISTS OF BS6	TATA spare parts
886387001928	OUTER RING KIT DIA 116 CONSISTS OF BS6	TATA spare parts
886387001929	ROD RYE KIT BS6	TATA spare parts
886387001930	OUTER RING KIT 175-4 CYLINDER BS6	TATA spare parts
886387001931	SEAL KIT- CYL MOUNTING DCV BS6	TATA spare parts
886387001932	PRESSURE CARTRIDGE 3/8 BSPOT BS6	TATA spare parts
886387001933	BASE TUBE DIA 197X1388 CM BS6	TATA spare parts
886387001934	STAGE TUBE KIT DIA 175X1345 BS6	TATA spare parts
886387001935	STAGE TUBE KIT DIA 155X1345 BS6	TATA spare parts
886387001936	STAGE TUBE KIT DIA 135X1345 BS6	TATA spare parts
886387001937	STAGE TUBE KIT DIA 116 X1355 9 THREADED)	TATA spare parts
886387001938	LOCKING PLATE BS6	TATA spare parts
886387001939	SPHERICAL EYE BUSH BS6	TATA spare parts

886387001940	SEAL KIT 175-4 CYLINDER BS6	TATA spare parts
886387001941	SET SCREW BS6	TATA spare parts
886387001942	METAL BRAIDED HOSE 1M BS6	TATA spare parts
886387001943	ALUMINUM WASHER ID-40 X OD-46 X 3 THIK B	TATA spare parts
886387001944	LOAD BODY 10.5 CUM ON 1923 BSIV	TATA spare parts
886387001945	SUBFRAME 10.5 BSIV	TATA spare parts
886387001946	CRADLE ASSY 10.5 CUM	TATA spare parts
886387001947	MOUNTINGKIT 10.5 CUM	TATA spare parts
886387001948	CAM MOUNTING ASSEMBLY BS6	TATA spare parts
886387001949	CAM HAMMER ASSEMBLY LH/RH BS6	TATA spare parts
886387001950	PIN FOR CAM MOUNTING BS6	TATA spare parts
886387001951	FORK PIN BS6	TATA spare parts
886387001952	PULLING PIPE ASSEMBLY BS6	TATA spare parts
886387001953	HOOK ASSEMBLY LH BS6	TATA spare parts
886387001954	HOOK ASSEMBLY RH BS6	TATA spare parts
886387001955	SPRING BS6	TATA spare parts
886387001956	SPRING HOOK BS6	TATA spare parts
886387001957	HOOK BLOCK ASSEMBLY LH BS6	TATA spare parts
886387001958	HOOK BLOCK ASSEMBLY RH BS6	TATA spare parts
886387001959	GREASE NIPPLE BS6	TATA spare parts
886387001960	1INCH BSP X 1 1/4INCH HOSE NIPPLE ELBOW	TATA spare parts
886387001961	CV130 DC VALVE BS6	TATA spare parts
886387001962	M6 - 12L HEX HEAD BOLT BS6	TATA spare parts
886387001963	M6 SPRING WASHER BS6	TATA spare parts
886387001964	CCV MOUNTING BRACKET BS6	TATA spare parts
886387001965	ASSLY CUBBED BODY WITH SUBFRAME AND W/O	TATA spare parts
886387001966	ELECTRICAL WIRING HARNESS BS6	TATA spare parts
886387001967	SIDE ASSEMBLY LH BS6	TATA spare parts
886387001968	SIDE ASSEMBLY RH BS6	TATA spare parts
886387001969	U BOLT L 545 BS6	TATA spare parts
886387001970	MUDGUARD ASSY. BS6	TATA spare parts
886387001971	HOSE CLAMP 3 BS6	TATA spare parts
886387001972	BRASS COUPLING SET BS6	TATA spare parts
886387001973	BALL VALVE 2INCH BS6	TATA spare parts
886387001974	BALL VALVE 1INCH BS6	TATA spare parts
886387001975	WING NUT ASSY. BS6	TATA spare parts
886387001976	MAN HOLE RUBBER BS6	TATA spare parts
886387001977	GI NIPPLE 2INCHX70 BS6	TATA spare parts
886387001978	GI ELBOW 1/2INCH BS6	TATA spare parts
886387001979	GI ELBOW 1INCH BS6	TATA spare parts
886387001980	GI ELBOW 2INCH BS6	TATA spare parts
886387001981	GI TEE 1/2INCH BS6	TATA spare parts
886387001982	GI PIPE 2INCHX550 BS6	TATA spare parts
886387001983	REDUCER BS6	TATA spare parts
886387001984	UNION 2INCH BS6	TATA spare parts
886387001985	FLANGE 2INCH BS6	TATA spare parts
886387001986	FLANGE 1INCH BS6	TATA spare parts

886387001987	TOOL BOX BS6	TATA spare parts
886387001988	HYD KIT LPK 912 BS6 [TT776009X055][WIPRO	TATA spare parts
886387001989	PUMP TOOL KIT BS6	TATA spare parts
886387001990	MUDGUARD ASSY BS6	TATA spare parts
886387001991	U BOLT 16 DIA X 385 BS6	TATA spare parts
886387001992	U BOLT 16 DIA X 414 BS6	TATA spare parts
886387001993	SHOE PLATE BS6	TATA spare parts
886387001994	TAIL DOOR ASSY 10 CUM BSIV	TATA spare parts
886387001995	10 CUM SUBFRAME ASSY WITH CRADLE	TATA spare parts
886387001996	U & L CLAMP ASSY CPL	TATA spare parts
886387001997	LOAD BODY WITHOUT HYD. KIT	TATA spare parts
886387001998	CUBED BODY ASSY 18 BOX W/O HYD KIT BS6	TATA spare parts
886387001999	LOAD BODY ASSY ULTRA 1918 BS6	TATA spare parts
886387002000	TAILDOOR ASSEMBLY BS6	TATA spare parts
886387002001	HINGE ASSY TAILGATE BS6	TATA spare parts
886387002002	CUBED BODY ASSY-16 BOX W/O HYD KIT BS6	TATA spare parts
886387002003	SUBFRAME ASSY WITH STAIBLIZER BS6	TATA spare parts
886387002004	STAIBLIZER ASSY BS6	TATA spare parts
886387002005	BUSH REAR HINGE OUTER BS6	TATA spare parts
886387002006	BUSH REAR HINGE INNER BS6	TATA spare parts
886387002007	BODY PROP ASSY BS6	TATA spare parts
886387002008	CRADLE ASSY BS6	TATA spare parts
886387002009	TAIL DOOR HINGE INCHLINCH PLATE BS6	TATA spare parts
886387002010	TAIL DOOR HINGE PIN-2 BS6	TATA spare parts
886387002011	TAIL DOOR HINGE PIN WASHER BS6	TATA spare parts
886387002012	HINGE ASSY TAILGATE BS6	TATA spare parts
886387002013	PULLING PIPE ASSEMBLY BS6	TATA spare parts
886387002014	ATTACHMENT PLATE 1 BS6	TATA spare parts
886387002015	ATTACHMENT PLATE 2 BS6	TATA spare parts
886387002016	ATTACHMENT PLATE 3 BS6	TATA spare parts
886387002017	ATTACHMENT PLATE 4 BS6	TATA spare parts
886387002018	ATTACHMENT PLATE 5 BS6	TATA spare parts
886387002019	ATTACHMENT PLATE 6 BS6	TATA spare parts
886387002020	ATTACHMENT PLATE 7 BS6	TATA spare parts
886387002021	UPPER PIVOT BS6	TATA spare parts
886387002022	PLATE MUDGUARD BS6	TATA spare parts
886387002023	RAIN FLAP BS6	TATA spare parts
886387002024	RAIN FLAP BS6	TATA spare parts
886387002025	FRAME ASSY BS6	TATA spare parts
886387002026	PULLING PIPE ASSEMBLY BS6	TATA spare parts
886387002027	TIPPER BODY ASSY 10 CUM BOX W/O HYD. KIT	TATA spare parts
886387002028	REAR HINGE SHAFT LOCKING SNAP RING	TATA spare parts
886387002029	TAILDOOR ASSEMBLY BS6	TATA spare parts
886387002030	CABLE MTG. BKT. BS6	TATA spare parts
886387002031	CABLE CLAMP BS6	TATA spare parts
886387002032	SIDE ASSEMBLY LH BS6	TATA spare parts
886387002033	SIDE ASSEMBLY RH BS6	TATA spare parts

886387002034	TAIL DOOR ASSEMBLY BS6	TATA spare parts
886387002035	ASSLY MUD FLAP LH / RH BS6	TATA spare parts
886387002036	FRONT ASSEMBLY BS6	TATA spare parts
886387002037	SUBFRAME ASSEMBLY BS6	TATA spare parts
886387002038	KING PIN	TATA spare parts
886387002039	LANDING GEAR SET	TATA spare parts
886387002040	TUBE ç TC0422 BS6	TATA spare parts
886387002041	PISTON ROD -1 ç TC0422 BS6	TATA spare parts
886387002042	PISTON ROD -2 ç TC0422 BS6	TATA spare parts
886387002043	PISTON ROD -3 ç TC0422 BS6	TATA spare parts
886387002044	PISTON ROD -4 ç TC0422 BS6	TATA spare parts
886387002045	SUBFRAME ASSY WITHOUT CRADLE 2523	TATA spare parts
886387002046	SUB FRAME ASSY WITH MOUNTINGS	TATA spare parts
886387002047	HEX HEAD SCREW DIN 933 M 12X 50 10.9 GR	TATA spare parts
886387002048	MOUNTING ARRANGMENT CPL.6CUM-TATA 2518	TATA spare parts
886387002049	SIDE SUPPORT PLATE RH&LH-4	TATA spare parts
886387002050	CRADLE ASSY INCLUDE OIL TANK MOUNT. BKT.	TATA spare parts
886387002051	STABLIZER SHAFT 45X900	TATA spare parts
886387002052	STUD M16X180 BS6	TATA spare parts
886387002053	SUBFRAME ASSY W/O CRADLE 3118(18 CUM)BS4	TATA spare parts
886387002054	CRADLE ASSY (18 CUM)	TATA spare parts
886387002055	MOUNTING KIT 18STD	TATA spare parts
886387002056	SUB FRAME ASSEMBLY BS6	TATA spare parts
886387002057	ASSLY BODY CUBBING BQ22 BS6	TATA spare parts
886387002058	BUSH OD50*ID40*20L BS6	TATA spare parts
886387002059	SPACER OD50*ID40*9L BS6	TATA spare parts
886387002060	TAIL GATE PIN BOD30*ID19.5*38L BS6	TATA spare parts
886387002061	MUDGUARD BS6	TATA spare parts
886387002062	MUDGUARD ANGLE BS6	TATA spare parts
886387002063	PUSH PULL CABLE BS6	TATA spare parts
886387002064	OIL TANK MOUNTING ANGLE BS6	TATA spare parts
886387002065	HYDRAULIC CYLINDER (TC0180) BS6	TATA spare parts
886387002066	HYDRAULIC TANK (X231150000) BS6	TATA spare parts
886387002067	PENDANT (CWX193320009) BS6	TATA spare parts
886387002068	HYDRAULIC CONTROL VALVE BS6	TATA spare parts
886387002069	ASSLY BODY CUBBING BQ24 BS6	TATA spare parts
886387002070	TARPAULINE BS6	TATA spare parts
886387002071	ASSLY BODY CUBBING BQ27 BS6	TATA spare parts
886387002072	SUB FRAME ASSEMBLY BS6	TATA spare parts
886387002073	ASSLY BODY CUBBING BQ23 BS6	TATA spare parts
886387002074	SPACER OD50XID40XL-18 BS6	TATA spare parts
886387002075	ASSLY TAIL PANEL LH BQ23 BS6	TATA spare parts
886387002076	ASSLY TAIL PANEL RH BQ23 BS6	TATA spare parts
886387002077	TOP DOOR ASSLY BS6	TATA spare parts
886387002078	TOP DOOR LOCKING ASSLY BS6	TATA spare parts
886387002079	REAR SENSOR BRACKET INTRA V10/V30 BS6	TATA spare parts
886387002080	HYDRAULIC CYLINDER (TC0301) BS6	TATA spare parts

886387002081	ASSLY BODY CUBBING BQ25 BS6	TATA spare parts
886387002082	ASSLY TAIL PANEL BQ25 BS6	TATA spare parts
886387002083	ASSLY BODY CUBBING BQ28 BS6	TATA spare parts
886387002084	ASSLY TAIL PANEL LH BQ28 BS6	TATA spare parts
886387002085	ASSLY TAIL PANEL RH BQ28 BS6	TATA spare parts
886387002086	ASSLY BODY CUBBING BQ26 BS6	TATA spare parts
886387002087	ASSLY TAIL PANEL BQ30 BS6	TATA spare parts
886387002088	TOP DOOR ASSLY BS6	TATA spare parts
886387002089	MUDGUARD ANGLE BS6	TATA spare parts
886387002090	HAZARDOUS WASTE BOX ASSLY BS6	TATA spare parts
886387002091	ASSLY BODY CUBBING BQ31 BS6	TATA spare parts
886387002092	HAZARDOUS WASTE BOX ASSLY BS6	TATA spare parts
886387002093	ASSLY TAIL PANEL LH BQ31 BS6	TATA spare parts
886387002094	ASSLY TAIL PANEL RH BQ31 BS6	TATA spare parts
886387002095	SLUDGE BOX ASSLY BS6	TATA spare parts
886387002096	ASSLY TAIL PANEL LH BQ32 BS6	TATA spare parts
886387002097	BODY BS6	TATA spare parts
886387002098	SUB FRAME BS6	TATA spare parts
886387002099	REAR HINGE PIN BOD 40XOD 29.5XL-130 BS6	TATA spare parts
886387002100	REAR HINGE PIN BUSH OD40XID30XL-20 BS6	TATA spare parts
886387002101	COLLER OD50*ID40*20L BS6	TATA spare parts
886387002102	TAIL DOOR ASSEMBLY BS6	TATA spare parts
886387002103	TAIL DOOR PIN BS6	TATA spare parts
886387002104	WHEEL HUMP BS6	TATA spare parts
886387002105	BATTERY COVER BS6	TATA spare parts
886387002106	FUEL COVER BS6	TATA spare parts
886387002107	OIL TANK MOUNTING L-ANGLE BS6	TATA spare parts
886387002108	CONTROL VALVE COVER BS6	TATA spare parts
886387002109	STICKER TIPPER (TATA) BS6	TATA spare parts
886387002110	STICKER TIPPER (TATA LOGO) BS6	TATA spare parts
886387002111	PTO+PUMP( 5 SPEED) BS6	TATA spare parts
886387002112	TARPAULIN BS6	TATA spare parts
886387002113	BODY BS6	TATA spare parts
886387002114	TAIL DOOR ASSEMBLY BS6	TATA spare parts
886387002115	DOOR HINGE BS6	TATA spare parts
886387002116	DUMPING DOOR BS6	TATA spare parts
886387002117	DUMPING DOOR SUPPORT BS6	TATA spare parts
886387002118	BODY BS6	TATA spare parts
886387002119	TAIL DOOR ASSEMBLY LH BS6	TATA spare parts
886387002120	TAIL DOOR ASSEMBLY RH BS6	TATA spare parts
886387002121	BODY BS6	TATA spare parts
886387002122	SUB FRAME BS6	TATA spare parts
886387002123	TAIL DOOR ASSEMBLY LH BS6	TATA spare parts
886387002124	TAIL DOOR ASSEMBLY RH BS6	TATA spare parts
886387002125	HAZARDOUS BOX BS6	TATA spare parts
886387002126	BODY BS6	TATA spare parts
886387002127	REMOVABLE PARTITION BS6	TATA spare parts

886387002128	FUEL COVER BS6	TATA spare parts
886387002129	PTO+PUMP (4 SPEED) BS6	TATA spare parts
886387002130	PARTITION BS6	TATA spare parts
886387002131	MUDGUARD BS6	TATA spare parts
886387002132	BODY MTG STOOL 145L BS6	TATA spare parts
886387002133	BODY MTG STOOL 110L BS6	TATA spare parts
886387002134	MUD GUARD ASSY. BS6	TATA spare parts
886387002135	CYLINDERMTG TOP BKT BS6	TATA spare parts
886387002136	CYLINDER MTG BKT LOWER BS6	TATA spare parts
886387002137	BODY FULCRUM PLATE BS6	TATA spare parts
886387002138	TAIL DOOR BS6	TATA spare parts
886387002139	BODY PROB ASSY BS6	TATA spare parts
886387002140	BODY MTG PIN BS6	TATA spare parts
886387002141	BODY MTG BUSH BS6	TATA spare parts
886387002142	CYLINDER MTG BOTTOM PIN BS6	TATA spare parts
886387002143	CYLINDER MTG TOP PIN BS6	TATA spare parts
886387002144	PUSH PULL CABLE BS6	TATA spare parts
886387002145	HYDRAULIC KIT TC 0180 BS6	TATA spare parts
886387002146	PTO DRIVEN PUMP 5 SPEED BS6	TATA spare parts
886387002147	TARPAULIN BS6	TATA spare parts
886387002148	SUB FRAME BS6	TATA spare parts
886387002149	CUBED BODY BS6	TATA spare parts
886387002150	TAIL DOOR HING BS6	TATA spare parts
886387002151	BODY MTG STOOL 145L BS6	TATA spare parts
886387002152	BODY MTG STOOL 110L BS6	TATA spare parts
886387002153	MUD GUARD ASSY. BS6	TATA spare parts
886387002154	CYLINDERMTG TOP BKT BS6	TATA spare parts
886387002155	CYLINDER MTG BKT LOWER BS6	TATA spare parts
886387002156	BODY FULCRUM PLATE BS6	TATA spare parts
886387002157	TAIL DOOR BS6	TATA spare parts
886387002158	BODY PROB ASSY BS6	TATA spare parts
886387002159	BODY MTG PIN BS6	TATA spare parts
886387002160	BODY MTG BUSH BS6	TATA spare parts
886387002161	CYLINDER MTG BOTTOM PIN BS6	TATA spare parts
886387002162	CYLINDER MTG TOP PIN BS6	TATA spare parts
886387002163	PUSH PULL CABLE BS6	TATA spare parts
886387002164	HYDRAULIC KIT TC 0180 BS6	TATA spare parts
886387002165	TOP LID BS6	TATA spare parts
886387002166	SUB FRAME BS6	TATA spare parts
886387002167	CUBED BODY BS6	TATA spare parts
886387002168	TAIL DOOR HING BS6	TATA spare parts
886387002169	PARTITION DOOR BS6	TATA spare parts
886387002170	BODY MTG STOOL 145L BS6	TATA spare parts
886387002171	BODY MTG STOOL 110L BS6	TATA spare parts
886387002172	MUD GUARD ASSY. BS6	TATA spare parts
886387002173	CYLINDERMTG TOP BKT BS6	TATA spare parts
886387002174	CYLINDER MTG BKT LOWER BS6	TATA spare parts

886387002175	BODY FULCRUM PLATE BS6	TATA spare parts
886387002176	TAIL DOOR BS6	TATA spare parts
886387002177	BODY PROB ASSY BS6	TATA spare parts
886387002178	BODY MTG PIN BS6	TATA spare parts
886387002179	BODY MTG BUSH BS6	TATA spare parts
886387002180	CYLINDER MTG BOTTOM PIN BS6	TATA spare parts
886387002181	CYLINDER MTG TOP PIN BS6	TATA spare parts
886387002182	PUSH PULL CABLE BS6	TATA spare parts
886387002183	HYDRAULIC KIT TC 180/WIPRO BS6	TATA spare parts
886387002184	PTO DRIVEN PUMP 4 SPEED BS6	TATA spare parts
886387002185	TOP LID BS6	TATA spare parts
886387002186	SUB FRAME BS6	TATA spare parts
886387002187	CUBED BODY BS6	TATA spare parts
886387002188	TAIL DOOR HINGE BS6	TATA spare parts
886387002189	BODY MTG STOOL 145L BS6	TATA spare parts
886387002190	BODY MTG STOOL 110L BS6	TATA spare parts
886387002191	MUD GUARD ASSY. BS6	TATA spare parts
886387002192	CYLINDERMTG TOP BKT BS6	TATA spare parts
886387002193	CYLINDER MTG BKT LOWER BS6	TATA spare parts
886387002194	BODY FULCRUM PLATE BS6	TATA spare parts
886387002195	TAIL DOOR WITH ALU INNER PANEL BS6	TATA spare parts
886387002196	BODY PROB ASSY BS6	TATA spare parts
886387002197	BODY MTG PIN BS6	TATA spare parts
886387002198	BODY MTG BUSH BS6	TATA spare parts
886387002199	CYLINDER MTG BOTTOM PIN BS6	TATA spare parts
886387002200	CYLINDER MTG TOP PIN BS6	TATA spare parts
886387002201	PUSH PULL CABLE BS6	TATA spare parts
886387002202	HYDRAULIC KIT TC 180/WIPRO BS6	TATA spare parts
886387002203	PTO DRIVEN PUMP 5 SPEED BS6	TATA spare parts
886387002204	TOP LID BS6	TATA spare parts
886387002205	SUB FRAME BS6	TATA spare parts
886387002206	CUBED BODY BS6	TATA spare parts
886387002207	TAIL DOOR HING BS6	TATA spare parts
886387002208	PARTITION DOOR BS6	TATA spare parts
886387002209	BODY MTG STOOL 145L BS6	TATA spare parts
886387002210	BODY MTG STOOL 110L BS6	TATA spare parts
886387002211	MUD GUARD ASSY. BS6	TATA spare parts
886387002212	CYLINDERMTG TOP BKT BS6	TATA spare parts
886387002213	CYLINDER MTG BKT LOWER BS6	TATA spare parts
886387002214	BODY FULCRUM PLATE BS6	TATA spare parts
886387002215	TAIL DOOR BS6	TATA spare parts
886387002216	BODY PROB ASSY BS6	TATA spare parts
886387002217	BODY MTG PIN BS6	TATA spare parts
886387002218	BODY MTG BUSH BS6	TATA spare parts
886387002219	CYLINDER MTG BOTTOM PIN BS6	TATA spare parts
886387002220	CYLINDER MTG TOP PIN BS6	TATA spare parts
886387002221	PUSH PULL CABLE BS6	TATA spare parts



886387002222	HYDRAULIC KIT TC 301/WIPRO BS6	TATA spare parts
886387002223	PTO DRIVEN PUMP 5 SPEED BS6	TATA spare parts
886387002224	TOP LID BS6	TATA spare parts
886387002225	HAZARDOUS BOX BS6	TATA spare parts
886387002226	SUBE FRAME BS6	TATA spare parts
886387002227	CUBED BOX BS6	TATA spare parts
886387002228	TAIL DOOR HINGE BS6	TATA spare parts
886387002229	PARTITON DOOR BS6	TATA spare parts
886387002230	BODY MTG STOOL 145L BS6	TATA spare parts
886387002231	BODY MTG STOOL 110L BS6	TATA spare parts
886387002232	MUD GUARD ASSY. BS6	TATA spare parts
886387002233	CYLINDERMTG TOP BKT BS6	TATA spare parts
886387002234	CYLINDER MTG BKT LOWER BS6	TATA spare parts
886387002235	BODY FULCRUM PLATE BS6	TATA spare parts
886387002236	TAIL DOOR BS6	TATA spare parts
886387002237	BODY PROB ASSY BS6	TATA spare parts
886387002238	BODY MTG PIN BS6	TATA spare parts
886387002239	BODY MTG BUSH BS6	TATA spare parts
886387002240	CYLINDER MTG BOTTOM PIN BS6	TATA spare parts
886387002241	CYLINDER MTG TOP PIN BS6	TATA spare parts
886387002242	PUSH PULL CABLE BS6	TATA spare parts
886387002243	HYDRAULIC KIT TC 180/CANARA BS6	TATA spare parts
886387002244	PTO DRIVEN PUMP 5 SPEED BS6	TATA spare parts
886387002245	TOP LID BS6	TATA spare parts
886387002246	SUB FRAME BS6	TATA spare parts
886387002247	CUBED BODY BS6	TATA spare parts
886387002248	TAIL DOOR HINGE BS6	TATA spare parts
886387002249	PARTITION DOOR BS6	TATA spare parts
886387002250	SUBFRAME WITH MOUNTING & CRADLE 18 STD B	TATA spare parts
886387002251	ASSY TAIL PANEL BS6	TATA spare parts
886387002252	RUPD BRACKET ASSY BS6	TATA spare parts
886387002253	ASSY BATTERY BOX COVER BS6	TATA spare parts
886387002254	ASSY CONTROL VALVE COVER BS6	TATA spare parts
886387002255	REFLECTIVE TAPE RED 20 MM WIDTH BS6	TATA spare parts
886387002256	ASSY TAIL PANEL BS6	TATA spare parts
886387002257	HYDRAULIC KIT (TC0301) BS6	TATA spare parts
886387002258	CYLINDER MOUNTING BOTTOM PIN BS6	TATA spare parts
886387002259	HYDRAULIC KIT (PTT915001X050-WMT061) BS6	TATA spare parts
886387002260	CYLINDER MOUNTING TOP PIN BS6	TATA spare parts
886387002261	HYDRAULIC KIT (PTT915001X050-WMT061) BS6	TATA spare parts
886387002262	LEVER CPL BS6	TATA spare parts
886387002263	TAIL DOOR HINGE PIN 16HD	TATA spare parts
886387002264	HEX BOLT 14X1.5 L50	TATA spare parts
886387002265	BODY MTG STOOL 100L BS6	TATA spare parts
886387002266	MUD GUARD ASSY. BS6	TATA spare parts
886387002267	CYLINDERMTG TOP BKT BS6	TATA spare parts
886387002268	CYLINDER MTG BKT LOWER BS6	TATA spare parts

886387002269	BODY FULCRUM PLATE BS6	TATA spare parts
886387002270	TAIL DOOR BS6	TATA spare parts
886387002271	BODY PROB ASSY BS6	TATA spare parts
886387002272	BODY MTG PIN BS6	TATA spare parts
886387002273	BODY MTG BUSH BS6	TATA spare parts
886387002274	CYLINDER MTG BOTTOM PIN BS6	TATA spare parts
886387002275	CYLINDER MTG TOP PIN BS6	TATA spare parts
886387002276	PUSH PULL CABLE BS6	TATA spare parts
886387002277	HYDRAULIC KIT TC 301/WIPRO BS6	TATA spare parts
886387002278	PTO DRIVEN PUMP 5 SPEED BS6	TATA spare parts
886387002279	TOP LID BS6	TATA spare parts
886387002280	LOAD BODY WITHOUT HYDAULIC KIT BS6	TATA spare parts
886387002282	LEVER CPL BS6	TATA spare parts
886387002283	LOCKING BUSH 01 OD50 ID 40 L 20 BS6	TATA spare parts
886387002284	LOCKING BUSH 02 OD50 ID 40 L 16 BS6	TATA spare parts
886387002285	CYLINDER TOP PIN OD50 ID 39.5 L 105 BS6	TATA spare parts
886387002286	BODY PROP PIN OD 24.5 L 120 BS6	TATA spare parts
886387002287	BODY PROP BUSH OD39 ID 25.5 L 45 BS6	TATA spare parts
886387002288	PIVOT HINGE PIN OD40 ID29.5 L 140 BS6	TATA spare parts
886387002289	PIVOT PIN BUSH 1 ID 44 OD30 L 30 BS6	TATA spare parts
886387002290	PIVOT PIN BUSH 2 OD 50 ID 40 L 60 BS6	TATA spare parts
886387002291	PIVOT PIN BUSH 3 OD 44 ID 30 L 20 BS6	TATA spare parts
886387002292	PARTITION BUSH OD20 ID13 L20 BS6	TATA spare parts
886387002293	PIVOT BUSH 4 OD40 ID30 L60 BS6	TATA spare parts
886387002294	STICKER TIPPER (TATA) BS6	TATA spare parts
886387002295	PTO+PUMP( 5 SPEED) BS6	TATA spare parts
886387002296	FLANGE BOLT/12X60	TATA spare parts
886387002297	LOAD BODY W/MOUNTINGS W/O HYD KIT BS6	TATA spare parts
886387002298	LOAD BODY W/SUBFRAME BS6	TATA spare parts
886387002299	LOAD BODY W/O SUBFRAME BS6	TATA spare parts
886387002300	SUBFRAME ASSY W/MOUNTINGS BS6	TATA spare parts
886387002301	SUBFRAME ASSY BS6	TATA spare parts
886387002302	BODY PROP ASSY BS6	TATA spare parts
886387002303	CRADLE ASSY BS6	TATA spare parts
886387002304	TAILDOOR ASSEMBLY BS6	TATA spare parts
886387002305	TAIL DOOR HINGE L-PLATE BS6	TATA spare parts
886387002306	HINGE ASSY TAILGATE BS6	TATA spare parts
886387002307	PULLING PIPE ASSEMBLY (L=1950MM) BS6	TATA spare parts
886387002308	MUDGAURD ASSY - LH BS6	TATA spare parts
886387002309	MUDGAURD ASSY - RH BS6	TATA spare parts
886387002310	FRAME ASSY BS6	TATA spare parts
886387002311	TAIL DOOR HINGE PIN BS6	TATA spare parts
886387002312	ATTACHMENT PLATE 1 BS6	TATA spare parts
886387002313	ATTACHMENT PLATE 2 BS6	TATA spare parts
886387002314	ATTACHMENT PLATE 3 BS6	TATA spare parts
886387002315	ATTACHMENT PLATE 4 BS6	TATA spare parts
886387002316	UPPER PIVOT BS6	TATA spare parts

886387002317	RAIN FLAP REAR BS6	TATA spare parts
886387002318	SUCTION HOSE 1/2INCH X 1/2INCH BS6	TATA spare parts
886387002319	PRESSURE HOSE 3/8INCHX3/8INCH BS6	TATA spare parts
886387002320	WIRING HARNESS CABLE BS6	TATA spare parts
886387002321	RETURN HOSE 3/8INCHX3/8INCH BS6	TATA spare parts
886387002322	SUCTION HOSE 1/2INCHX1/2INCH BS6	TATA spare parts
886387002323	PRESSURE HOSE 3/8INCHX3/8INCH BS6	TATA spare parts
886387002324	DOUBLE ACTING SOLENOID VALVE BS6	TATA spare parts
886387002325	DRUM SHELL BS6	TATA spare parts
886387002326	DRUM BLADE ASSEMBLY BS6	TATA spare parts
886387002327	PLATE BS6	TATA spare parts
886387002328	BOLT BS6	TATA spare parts
886387002329	SEAL WASHER BS6	TATA spare parts
886387002330	PACKING MOC BS6	TATA spare parts
886387002331	FRONT PEDESTAL BS6	TATA spare parts
886387002332	LONG MEMBER ( L ) BS6	TATA spare parts
886387002333	LONG MEMBER ( R ) BS6	TATA spare parts
886387002334	BRACKET BS6	TATA spare parts
886387002335	REAR PEDESTAL BS6	TATA spare parts
886387002336	SUB ENGINE PEDESTAL BS6	TATA spare parts
886387002337	BOLT BS6	TATA spare parts
886387002338	BOLT BS6	TATA spare parts
886387002339	BOLT BS6	TATA spare parts
886387002340	BOLT BS6	TATA spare parts
886387002341	PLATE BS6	TATA spare parts
886387002342	HEX. BOLT BS6	TATA spare parts
886387002343	STOPPER ( ISF ) BS6	TATA spare parts
886387002344	STOPPER ( SQ.BAR ) BS6	TATA spare parts
886387002345	SHIM BS6	TATA spare parts
886387002346	SHIM BS6	TATA spare parts
886387002347	SHIM BS6	TATA spare parts
886387002348	SHIM BS6	TATA spare parts
886387002349	ROUND BAR BS6	TATA spare parts
886387002350	PLATE BS6	TATA spare parts
886387002351	HYDRAULIC PUMP - A4VTG071HW 100 BS6	TATA spare parts
886387002352	HYD. MOTOR AA2FM80/61W BS6	TATA spare parts
886387002353	GEAR BOX BS6	TATA spare parts
886387002354	DRUM ROLLER ASSLY BS6	TATA spare parts
886387002355	BRACKET BS6	TATA spare parts
886387002356	COLLAR BS6	TATA spare parts
886387002357	SEAL BS6	TATA spare parts
886387002358	PLATE BS6	TATA spare parts
886387002359	SHIM BS6	TATA spare parts
886387002360	SHIM BS6	TATA spare parts
886387002361	SHIM BS6	TATA spare parts
886387002362	WASHER BS6	TATA spare parts
886387002363	COVER (L) BS6	TATA spare parts

886387002364	COVER (R) BS6	TATA spare parts
886387002365	BEARING BS6	TATA spare parts
886387002366	ESBI HYTREX COUPLING (DRG. NO. BS6	TATA spare parts
886387002367	ENGINE FLANGE BS6	TATA spare parts
886387002368	PLATE BS6	TATA spare parts
886387002369	PLATE BS6	TATA spare parts
886387002370	PLATE BS6	TATA spare parts
886387002371	PLATE BS6	TATA spare parts
886387002372	PLATE BS6	TATA spare parts
886387002373	PLATE BS6	TATA spare parts
886387002374	PLATE BS6	TATA spare parts
886387002375	PLATE BS6	TATA spare parts
886387002376	PLATE BS6	TATA spare parts
886387002377	RUBBER REAR BS6	TATA spare parts
886387002378	FRAME BS6	TATA spare parts
886387002379	PLATE ( R ) BS6	TATA spare parts
886387002380	PLATE ( L ) BS6	TATA spare parts
886387002381	BRACKET BS6	TATA spare parts
886387002382	PLATE BS6	TATA spare parts
886387002383	PLATE BS6	TATA spare parts
886387002384	PLATE BS6	TATA spare parts
886387002385	PLATE BS6	TATA spare parts
886387002386	PLATE BS6	TATA spare parts
886387002387	PLATE BS6	TATA spare parts
886387002388	BRACKET BS6	TATA spare parts
886387002389	STOP CABLE BS6	TATA spare parts
886387002390	AV MNTG. BS6	TATA spare parts
886387002391	CONTROL PANEL ASSEMBLY BS6	TATA spare parts
886387002392	MDC GRADE PUMP CONTROL CABLE L 5.5 MTRS	TATA spare parts
886387002393	TRANSIT MIXER HOUR METER BS6	TATA spare parts
886387002394	RUBBER CONICAL HOOD COVER -DIA SIZE BS6	TATA spare parts
886387002395	OIL PRESSURE GUAGE BS6	TATA spare parts
886387002396	STRATER SWITCH BS6	TATA spare parts
886387002397	MICRO RELAY 5 PIN WITH SOCKET 24VDC BS6	TATA spare parts
886387002398	LEVER CONTROL ( DOUBLE COMMAND CONTROL	TATA spare parts
886387002399	THERMOM SWITCH BS6	TATA spare parts
886387002400	MDC GRADE ENGINE CONTROL CABLE BS6	TATA spare parts
886387002401	FILTER ELEMENT BS6	TATA spare parts
886387002402	FILTER ASSLY BS6	TATA spare parts
886387002403	MINI RELAY WITH SOCKET BS6	TATA spare parts
886387002404	FUSE HOLDER BIG BS6	TATA spare parts
886387002405	GLASS FUSE 30A FAST BLOW SIZE 34LX5D B	TATA spare parts
886387002406	FLOW GUIDE BS6	TATA spare parts
886387002407	FLOW GUIDE BS6	TATA spare parts
886387002408	CHARGE HOPPER BS6	TATA spare parts
886387002409	PLATE BS6	TATA spare parts
886387002410	PLATE BS6	TATA spare parts

886387002411	PLATE BS6	TATA spare parts
886387002412	PLATE BS6	TATA spare parts
886387002413	STOPPER DRUM BS6	TATA spare parts
886387002414	APRON BS6	TATA spare parts
886387002415	RUBBER BS6	TATA spare parts
886387002416	FLOW GUIDE CONNECTOR PLATE BS6	TATA spare parts
886387002417	ANGLE SUPPORT (L.H.) BS6	TATA spare parts
886387002418	PAD PLATE BS6	TATA spare parts
886387002419	ANGLE SUPPORT (R.H.) BS6	TATA spare parts
886387002420	DISCHARGE CHUTE BS6	TATA spare parts
886387002421	EXTENTION CHUTE BS6	TATA spare parts
886387002422	CHUTE SWIVEL SUPPORT BS6	TATA spare parts
886387002423	LOCK BS6	TATA spare parts
886387002424	CRAMP BS6	TATA spare parts
886387002425	PLATE BS6	TATA spare parts
886387002426	LEVER BS6	TATA spare parts
886387002427	PLATE BS6	TATA spare parts
886387002428	SPRING MOC SWPB (JIS G 3522 )NO OF BS	TATA spare parts
886387002429	BRACKET BS6	TATA spare parts
886387002430	LOCK BS6	TATA spare parts
886387002431	WATER TANK BS6	TATA spare parts
886387002432	BRACKET BS6	TATA spare parts
886387002433	BAND BS6	TATA spare parts
886387002434	WIRE HOSE BAND BS6	TATA spare parts
886387002435	STEP BS6	TATA spare parts
886387002436	STEP BS6	TATA spare parts
886387002437	PIN BS6	TATA spare parts
886387002438	CLIP BS6	TATA spare parts
886387002439	PLATE BS6	TATA spare parts
886387002440	BOLT BS6	TATA spare parts
886387002441	TIE ROD ASSEMBLY BS6	TATA spare parts
886387002442	MIXING DRUM BS6	TATA spare parts
886387002443	CONTROL BOX ASSEMBLY BS6	TATA spare parts
886387002444	BOLT-M10X25 BS6	TATA spare parts
886387002445	CHIP-FUSE -10A BS6	TATA spare parts
886387002446	CHIP FUSE - 20A BS6	TATA spare parts
886387002447	ELECTRICAL L.O.P GAUGE BS6	TATA spare parts
886387002448	DIGITAL HOUR METER BS6	TATA spare parts
886387002449	INDICATOR LAMP (RED) BS6	TATA spare parts
886387002450	RELAY SOCKET TTP-RB1 BS6	TATA spare parts
886387002451	FLEXIBLE HOSE BS6	TATA spare parts
886387002452	T MODEL ANCHOR EAR BS6	TATA spare parts
886387002453	SILENCER BRACKET BS6	TATA spare parts
886387002454	MUFFLER BS6	TATA spare parts
886387002455	DIESEL ENGINE BS6	TATA spare parts
886387002456	NUT M12 BS6	TATA spare parts
886387002457	ELASTIC COUPLING BS6	TATA spare parts

886387002458	SCREW-M10X45GB70.1 BS6	TATA spare parts
886387002459	FLANGE FIXED OIL PUMP BS6	TATA spare parts
886387002460	DIESEL FILTER STAY BS6	TATA spare parts
886387002461	RIDING WHEEL BS6	TATA spare parts
886387002462	RIDING WHEEL BS6	TATA spare parts
886387002463	BOLT-M20X70 BS6	TATA spare parts
886387002464	WASHER BS6	TATA spare parts
886387002465	BOLT M6x12 BS6	TATA spare parts
886387002466	UNIVERSAL PROTECTIVE CAP BS6	TATA spare parts
886387002467	DRUM JUMP LIMIT BRACKET BS6	TATA spare parts
886387002468	U-BOLT BS6	TATA spare parts
886387002469	HOPPER SUPPORT BRACKET BS6	TATA spare parts
886387002470	FEED HOPPER BS6	TATA spare parts
886387002471	HEXAGON HEAD BOLT M12x50 BS6	TATA spare parts
886387002472	DISCHARGE HOPPER BS6	TATA spare parts
886387002473	STAY BS6	TATA spare parts
886387002474	HANDLE BS6	TATA spare parts
886387002475	HANDLE RUBBER SLEEVE BS6	TATA spare parts
886387002476	SUPPORT TUBE BS6	TATA spare parts
886387002477	SHAFT BS6	TATA spare parts
886387002478	PIN BS6	TATA spare parts
886387002479	LOCKING MOUNT EQUIPMENT BS6	TATA spare parts
886387002480	PIN BS6	TATA spare parts
886387002481	OIL NIPPLE BS6	TATA spare parts
886387002482	BOLT M10x55 BS6	TATA spare parts
886387002483	SOLID KEEL ADHESIVE TAPE BS6	TATA spare parts
886387002484	RUBBER PLATE BS6	TATA spare parts
886387002485	BATTEN BS6	TATA spare parts
886387002486	TIE BAR ASSEMBLY BS6	TATA spare parts
886387002487	AUXILIARY MATERIALS BIN BRACKET BS6	TATA spare parts
886387002488	HEXAGON HEAD SCREW M12x30 BS6	TATA spare parts
886387002489	RUBBER BS6	TATA spare parts
886387002490	HANDLE BS6	TATA spare parts
886387002491	20 CUM LOAD BODY COMPLETE W/O HYD KIT BS	TATA spare parts
886387002492	LOAD BODY ASSY BS6	TATA spare parts
886387002493	CYLINDER BOTTOM PIN BS6	TATA spare parts
886387002494	CYLINDER TOP PIN BUSH BS6	TATA spare parts
886387002495	TAIL GATE MOUNTING PIN BS6	TATA spare parts
886387002496	CANOPY BS6	TATA spare parts
886387002497	MAN HOLE COVER ASSY BS6	TATA spare parts
886387002498	SUBFRAME BS6	TATA spare parts
886387002499	MUDGUARD BS6	TATA spare parts
886387002500	BATTERY COVER BS6	TATA spare parts
886387002501	FUEL COVER BS6	TATA spare parts
886387002502	OIL TANK MOUNTING L-ANGLE BS6	TATA spare parts
886387002503	CONTROL VALVE COVER BS6	TATA spare parts
886387002504	SUBFRAME ASSY WITH CRADLE 16CUM HD BS4	TATA spare parts

886387002505	TAIL DOOR HINGE16CUM HD BS4	TATA spare parts
886387002506	MOUNTINGKIT(PIVOT) 16CUM HD BS4	TATA spare parts
886387002507	LH SIDE REAR MUD FLAP	TATA spare parts
886387002508	PULLING PIPE ASSEMBLY BS6	TATA spare parts
886387002509	TAIL GATE ASSEMBLY BS6	TATA spare parts
886387002510	PARTITION PANEL BS6	TATA spare parts
886387002511	REAR HINGE SHAFT(60X1000)	TATA spare parts
886387002512	LOAD BODY ASSY WITH HYDRAULIC KIT	TATA spare parts
886387002513	LOAD BODY ASSY W/O HYDRAULIC KIT	TATA spare parts
886387002519	SEAL RING	TATA spare parts
886387002520	ROLLERS	TATA spare parts
886387002521	STAY	TATA spare parts
886387002522	HANDLE	TATA spare parts
886387002523	HANDLE RUBBER SLEEVE	TATA spare parts
886387002524	SUPPORT TUBE	TATA spare parts
886387002525	OIL NIPPLE	TATA spare parts
886387002526	RUBBER SHEET BS6	TATA spare parts
886387002527	PULLING PIPE	TATA spare parts
886387002528	BODY BS6	TATA spare parts
886387002529	20 CUM ON TATA LPK 2518-48 WITHOUT KIT	TATA spare parts
886387002530	CONCRETE MIXER ASSY BS6	TATA spare parts
886387002531	ASSLY TAIL GATE 3CUM-LPK-407-LD-TIPPER	TATA spare parts
886387002532	LOAD BODY 3CUM W/O SUBFRAME & HYD LPK40	TATA spare parts
886387002533	SUB FRAME ASSY 6.5 CUM UB BOX LPK 1212	TATA spare parts
886387002534	SUBFRAME WITH LOWER WITH MOUNTINGS	TATA spare parts
886387002535	WIRE ROPE	TATA spare parts
886387002536	SUBFRAME ASSY	TATA spare parts
886387002537	LOAD BODY WITH HYD KIT HYVA 14 CUM STD	TATA spare parts
886387002538	LOAD BODY W/O HYDRAULIC KIT 14 CUM STD	TATA spare parts
886387002539	SUBFRAME ASSY W/ BODY PROP GUARD & R/H P	TATA spare parts
886387002540	COMPLETE LOAD BODY W/O HYD. KIT AND OIL	TATA spare parts
886387002541	SUB FRAME WITH MOUNTINGS & CRADLE	TATA spare parts
886387002542	LOWER PIVOT -1	TATA spare parts
886387002543	SUBFRAME ASSY WITH ACCESSORIES	TATA spare parts
886387002544	LOAD BODY BS6	TATA spare parts
886387002545	SUPPORT LH.[L-BKT.LH.407] GR.PASSI BS6	TATA spare parts
886387002546	SUPPORT RH.[L-BKT.RH.407] GR.PASSI BS6	TATA spare parts
886387002547	8.5FT DSD LOADBODY ASSLY PAINTED BS6	TATA spare parts
886387002548	SIDE PANEL LH-8.5FT LOAD BODY ASSY BS6	TATA spare parts
886387002549	ASSY TAIL PANEL 407SFC GOLD DSD L/B BS6	TATA spare parts
886387002550	14FT FSD LOAD BODY ASSLY BS6	TATA spare parts
886387002551	TAIL PANEL ASSLY BS6	TATA spare parts
886387002552	8.5FT FSD LOAD BODY ASSLY BS6	TATA spare parts
886387002553	PULLING PIP ASSY BS6	TATA spare parts
886387002554	CAM MOUNTING ASSEMBLY BS6	TATA spare parts
886387002555	HAMMER ASSEMBLY (LH) BS6	TATA spare parts
886387002556	HAMMER ASSEMBLY (RH) BS6	TATA spare parts

886387002557	ASSLY TAIL GATE 5CUM-LPK 909/912 BS6	TATA spare parts
886387002558	LOAD BODY SIDE FLAP LHS (METAL PART) BS6	TATA spare parts
886387002559	LOAD BODY SIDE FLAP LHS (PLASTIC) BS6	TATA spare parts
886387002560	REAR LOAD BODY MUDFLAP FRAME LHS (METAL)	TATA spare parts
886387002561	REAR LOAD BODY MUDFLAP LHS BS6	TATA spare parts
886387002562	LOAD BODY MUDFLAP FRONT LHS BS6	TATA spare parts
886387002563	PULLING PIPE ASSY (LENGTH -1000 MM)	TATA spare parts
886387002564	FRAME ASSY W/HANGER STABILIZER HINGE ASS	TATA spare parts
886387002565	BODY + SUBFRAME BS6	TATA spare parts
886387002566	STABILIZER PIN BS6	TATA spare parts
886387002567	PARTITION PIN BS6	TATA spare parts
886387002568	PARTITION BUSH OD40 ID18 L25 BS6	TATA spare parts
886387002569	32 CBM TIP-TRAILER FE 169 TATA 55T BS6	TATA spare parts
886387002570	ASSY TAIL MUDGUARD LH 5CUM-LPK-909/912 B	TATA spare parts
886387002571	ASSY TAIL MUDGUARD RH 5CUM-LPK-909/912 B	TATA spare parts
886387002572	CAM MOUNTING ASSEMBLY	TATA spare parts
886387002573	LOAD BODY SUBFRAME W/HYDRAULIC KIT	TATA spare parts
886387002574	LOAD BODY SUBFRAME W/O HYDRAULIC KIT	TATA spare parts
886387002575	LOAD BODY W/O SUBFRAME & W/O HYD KIT	TATA spare parts
886387002576	LOAD BODY BS6	TATA spare parts
886387002577	RAM PROTECTION CAP BS6	TATA spare parts
886387002578	HEX.NUT M 8 8 VERZ. DIN 934 BS6	TATA spare parts
886387002579	TAILGATE ASSY FOR SK1613TC	TATA spare parts
886387002580	SUBFRAME ASSY WITH MTG	TATA spare parts
886387002581	SUBFRAME ASSY WITHOUT MTG	TATA spare parts
886387002582	TAILDOOR ASSEMBLY	TATA spare parts
886387002583	MIXER DRUM 7M3 C2-RH VERSION	TATA spare parts
886387002584	TIPPER BODY ASSY WITH MTG DETAILS BS6	TATA spare parts
886387002585	TIPPER BODY ASSY WITH SUBFRAME BS6	TATA spare parts
886387002586	SUBFRAME ASSY BS6	TATA spare parts
886387002587	SUBFRAME MIDDLE BUSH BS6	TATA spare parts
886387002588	SUBFRAME BEARING BUSH BS6	TATA spare parts
886387002589	BODY PROP BUSH BS6	TATA spare parts
886387002590	PROP LOCKING BUSH BS6	TATA spare parts
886387002591	PROP HINGE PIN BS6	TATA spare parts
886387002592	FULCRUM LOCK BUSH BS6	TATA spare parts
886387002593	TAILGATE ASSY BS6	TATA spare parts
886387002594	PANEL SIDE WALL LH/RH BS6	TATA spare parts
886387002595	MUDGUARD REAR COVER BS6	TATA spare parts
886387002596	MUDGUARD FRONT COVER BS6	TATA spare parts
886387002597	MUDGUARD VALANCE COVER BS6	TATA spare parts
886387002598	MUDGUARD FRONT II BOTTOM BS6	TATA spare parts
886387002599	ASSEMBLY STOPPER (SIDE ) BS6	TATA spare parts
886387002600	BODY LOCK ASSY LH BS6	TATA spare parts
886387002601	BODY LOCK ASSY RH BS6	TATA spare parts
886387002602	HINGE PIN COLLER BS6	TATA spare parts
886387002603	WASHER BS6	TATA spare parts



886387002604	BRACKET TAILGATE MTG BS6	TATA spare parts
886387002605	CHAIN BS6	TATA spare parts
886387002606	FORK TAILGATE LOCKING MECHANISIM BS6	TATA spare parts
886387002607	ALUMINIUM PACKING BS6	TATA spare parts
886387002608	U BOLT PLATE BS6	TATA spare parts
886387002609	LOCK BRACKET BS6	TATA spare parts
886387002610	HYD KIT FC110-3-2635 MODEL-WFR145B BS6	TATA spare parts
886387002611	SUBFRAME ASSY WITH MTG 18 CUM	TATA spare parts
886387002612	SUBFRAME ASSY WITHOUT MTG 18 CUM	TATA spare parts
886387002613	LOAD BODY ASSEMBLY WITH HYDRAULIC KIT BS	TATA spare parts
886387002614	LOAD BODY ASSEMBLY W/O HYDRAULICS KIT BS	TATA spare parts
886387002615	REAR MUDGUARD ASSEMBLY LH BS6	TATA spare parts
886387002616	REAR MUDGUARD ASSEMBLY RH BS6	TATA spare parts
886387002617	TAILDOOR ASSEMBLY BS6	TATA spare parts
886387002618	TAIL DOOR HINGE ASSY LH BS6	TATA spare parts
886387002619	TAIL DOOR HINGE ASSY RH BS6	TATA spare parts
886387002620	HOOK BLOCK ASSY LH BS6	TATA spare parts
886387002621	HOOK BLOCK ASSY RH BS6	TATA spare parts
886387002622	SUBFRAME ASSEMBLY BS6	TATA spare parts
886387002623	CRADLE ASSEMBLY BS6	TATA spare parts
886387002624	BODY GUIDE BS6	TATA spare parts
886387002625	BODY PROP ASSEMBLY BS6	TATA spare parts
886387002626	BODY PROP PIN ASSEMBLY BS6	TATA spare parts
886387002627	ATTACHMENT PLATE-2 BS6	TATA spare parts
886387002628	ATTACHMENT PLATE-3 BS6	TATA spare parts
886387002629	UPPER PIVOT BS6	TATA spare parts
886387002630	CAM MOUNTING ASSEMBLY BS6	TATA spare parts
886387002631	HAMMER ASSEMBLY (LH) BS6	TATA spare parts
886387002632	HAMMER ASSEMBLY (RH) BS6	TATA spare parts
886387002633	PIN FOR CAM MOUNTING BS6	TATA spare parts
886387002634	FORK PIN BS6	TATA spare parts
886387002635	CAM BUSH BS6	TATA spare parts
886387002636	PULLING PIPE ASSEMBLY BS6	TATA spare parts
886387002637	TENSION SPRING BS6	TATA spare parts
886387002638	HOOK ASSEMBLY (LH) BS6	TATA spare parts
886387002639	HOOK ASSEMBLY (LH) BS6	TATA spare parts
886387002640	PIVOT SPRING BS6	TATA spare parts
886387002641	HEX HEAD BOLT M16X70-10.9 BS6	TATA spare parts
886387002642	HEX HEAD BOLT M16X120-10.9 BS6	TATA spare parts
886387002643	M16 HARDENED WASHER 32/17X5 BS6	TATA spare parts
886387002644	NYLOCK NUT M16 COARSE THREAD BS6	TATA spare parts
886387002645	HEX BOLT M12X1.25X50-10.9 BS6	TATA spare parts
886387002646	NYLOCK NUT M12 FINE THREAD BS6	TATA spare parts
886387002647	REAR HINGE INNER BUSH(80X50X50) BS6	TATA spare parts
886387002648	REAR HINGE OUTER BUSH(80X50X50) BS6	TATA spare parts
886387002649	CERCLIP(DIA50) BS6	TATA spare parts
886387002650	TAIL DOOR U BEND DIA12 BS6	TATA spare parts

886387002651	J HOOK DIA10 BS6	TATA spare parts
886387002652	BODY PROP BUSH BS6	TATA spare parts
886387002653	BODY PROP PIN BS6	TATA spare parts
886387002654	CHASSIS ASSEMBLY BS6	TATA spare parts
886387002655	TAIL DOOR BS6	TATA spare parts
886387002656	CUBED BODY BS6	TATA spare parts
886387002657	16 CUM HD SUBFRAME WITH MTG	TATA spare parts
886387002658	16 CUM HD SUBFRAME WITHOUT MTG	TATA spare parts
886387002659	PULLING PIPE ASSY L900 BS6	TATA spare parts
886387002660	SUBFRAME ASSEMBLY WITH CRADLE	TATA spare parts
886387002661	FLAP ASSY LH	TATA spare parts
886387002662	FLAP ASSY RH	TATA spare parts
886387002663	SIDE SKIRT RAIN FLAP LH	TATA spare parts
886387002664	SIDE SKIRT RAIN FLAP RH	TATA spare parts
886387002683	CHAIN BS6	TATA spare parts
886387002684	REFLECTIVE TAPE RED BS6	TATA spare parts
886387002685	REFLECTIVE TAPE YELLOW BS6	TATA spare parts
886387002686	ROOF LAMP (PALTEX) BS6	TATA spare parts
886387002687	SIDE INDICATOR ( HILUX ) BS6	TATA spare parts
886387002688	TOP OUTLINE MARKER BS6	TATA spare parts
886387002689	FRONT FOG LAMP BS6	TATA spare parts
886387002690	SIDE MARKER ( NEOLIGHT ) BS6	TATA spare parts
886387002691	SWITCH INTERIOR BS6	TATA spare parts
886387002692	U BOLTS BS6	TATA spare parts
886387002693	GRAB HANDLE BS6	TATA spare parts
886387002694	COMPLETE LOAD BODY BS6	TATA spare parts
886387002695	SIDE FRONT & REAR HOOK BS6	TATA spare parts
886387002696	TAIL DOOR BS6	TATA spare parts
886387002697	CABIN FRONT BS6	TATA spare parts
886387002698	SIDE DOOR BS6	TATA spare parts
886387002699	TOOL BOX BS6	TATA spare parts
886387002700	SIDE MARKER LAMP BS6	TATA spare parts
886387002701	SIDE MARKER COVER BS6	TATA spare parts
886387002702	SIDE SKIRT RAIN FLAP LH BS6	TATA spare parts
886387002703	SIDE SKIRT RAIN FLAP RH BS6	TATA spare parts
886387002704	TAILDOOR ASSEMBLY BS6	TATA spare parts
886387002705	TAIL DOOR HINGE ASSY LH BS6	TATA spare parts
886387002706	TAIL DOOR HINGE ASSY RH BS6	TATA spare parts
886387002707	TAIL DOOR HINGE SUB ASSY LH BS6	TATA spare parts
886387002708	TAIL DOOR HINGE SUB ASSY RH BS6	TATA spare parts
886387002709	TAIL DOOR HINGE L PLATE BS6	TATA spare parts
886387002710	TAIL DOOR HINGE PROFILE PLATE BS6	TATA spare parts
886387002711	HOOK BLOCK ASSY LH BS6	TATA spare parts
886387002712	HOOK BLOCK ASSY RH BS6	TATA spare parts
886387002713	SUBFRAME ASSY W/CRADLE STAIB & MOUNTING	TATA spare parts
886387002714	SUBFRAME ASSY W/O CRADLE STAIB & MOUNTI	TATA spare parts
886387002715	CRADLE ASSEMBLY BS6	TATA spare parts

886387002716	STAIBLIZER ASSY BS6	TATA spare parts
886387002717	BODY PROP ASSEMBLY BS6	TATA spare parts
886387002718	PIN FOR CAM MOUNTING BS6	TATA spare parts
886387002719	FORK PIN BS6	TATA spare parts
886387002720	CAM BUSH BS6	TATA spare parts
886387002721	TENSION SPRING BS6	TATA spare parts
886387002722	HOOK ASSEMBLY (LH) BS6	TATA spare parts
886387002723	HOOK ASSEMBLY (RH) BS6	TATA spare parts
886387002724	PIVOT SPRING BS6	TATA spare parts
886387002725	HEX HEAD BOLT M16X110-10.9 BS6	TATA spare parts
886387002726	HEX HEAD BOLT M16X150-10.9 BS6	TATA spare parts
886387002727	M16 HARDENED WASHER 32/17X5 BS6	TATA spare parts
886387002728	NYLOCK NUT M16 COARSE THREAD BS6	TATA spare parts
886387002729	HEX BOLT M12X1.25X50-10.9 BS6	TATA spare parts
886387002730	NYLOCK NUT M12 FINE THREAD BS6	TATA spare parts
886387002731	REAR HINGE SHAFT(75X970) BS6	TATA spare parts
886387002732	R/H OUTER BUSH [120 X 50] BS6	TATA spare parts
886387002733	R/H INNER BUSH [120 X 50] BS6	TATA spare parts
886387002734	R/H BUSH ASSLY [120 X 90] BS6	TATA spare parts
886387002735	SNAP RING 75 DIA BS6	TATA spare parts
886387002736	TAIL DOOR U BEND DIA12 BS6	TATA spare parts
886387002737	J HOOK DIA10 BS6	TATA spare parts
886387002738	STAB. SHAFT 1037 L BS6	TATA spare parts
886387002739	TIPPER BODY ASSY W/HYDRAULIC KIT BS6	TATA spare parts
886387002740	TIPPER BODY ASSY W/O HYDRAULIC KIT BS6	TATA spare parts
886387002741	REAR MUDGUARD ASSEMBLY (HINGE TYPE) LH B	TATA spare parts
886387002742	REAR MUDGUARD ASSEMBLY (HINGE TYPE) RH B	TATA spare parts
886387002743	FOG LAMP - 441 BS6	TATA spare parts
886387002744	HELOGEN BULB H-3 BS6	TATA spare parts
886387002745	WIRE ROPE/13MMX75 MTR BS6	TATA spare parts
886387002746	CANVAS CANOPY/TARPOULINE ALL TYPE BS6	TATA spare parts
886387002747	GEAR BOX 5 TON (MECHANICAL) BS6	TATA spare parts
886387002748	U BOLT/350X97X16X2 BS6	TATA spare parts
886387002749	U BOLT/375X97X16X2 BS6	TATA spare parts
886387002750	ALLOY STEEL D SHAKLE PIN 8 TON CAP BS6	TATA spare parts
886387002751	PIN/30X150 LRV BS6	TATA spare parts
886387002752	PIN/30X108 LRV BS6	TATA spare parts
886387002753	D SHACKLE /32 MM BS6	TATA spare parts
886387002754	PIN (COLLER)/30X175X40 LRV BS6	TATA spare parts
886387002755	PIN/25X60 BS6	TATA spare parts
886387002756	MS PIN (HOLDING )/150X12 BS6	TATA spare parts
886387002757	PIN LEG JACK /25X140X40 LRV BS6	TATA spare parts
886387002758	RATCHIT BS6	TATA spare parts
886387002759	PAWL BS6	TATA spare parts
886387002760	BOOM DRUM SHAFT BS6	TATA spare parts
886387002761	BOOM HEEL BS6	TATA spare parts
886387002762	MAST CABLE GUIDE ASSY. BS6	TATA spare parts

886387002763	PIN/30X150 LRV BS6	TATA spare parts
886387002764	O.B.LEG PIN/60X225 BS6	TATA spare parts
886387002765	COMP SPRING LRV/60X10X8 BS6	TATA spare parts
886387002766	STUD ROD/100X6 BS6	TATA spare parts
886387002767	PAWL PUSH LEVER BS6	TATA spare parts
886387002768	COMP SPRING LRV/65X30X25X MM BS6	TATA spare parts
886387002769	PIN/30X130 LRV BS6	TATA spare parts
886387002770	PIN/30X110 LRV BS6	TATA spare parts
886387002771	ANCHOR CHAIN/12 MMX6 FEET WITH HOOK BS6	TATA spare parts
886387002772	CIRCLIP/85/90/95 BS6	TATA spare parts
886387002773	CHAIN MS/8 MM BS6	TATA spare parts
886387002774	WIRE ROPE SLING BS6	TATA spare parts
886387002775	MUD GUARD RUBBER BS6	TATA spare parts
886387002776	WOOD ROUGH KEY FOR LRV BS6	TATA spare parts
886387002777	PROPLER SHAFT FOR LRV BS6	TATA spare parts
886387002778	COMP SPRING LRV FOR ADDA/80X30X22X4 BS6	TATA spare parts
886387002779	U BOLT/180X110X10MM BS6	TATA spare parts
886387002780	PUMP BLOCK ASSY SPOCKET BS6	TATA spare parts
886387002781	BOSS/30X30X20 BS6	TATA spare parts
886387002782	SHAFT PIN/300X20 BS6	TATA spare parts
886387002783	COMP SPRING LRV/105X20 X14X3 BS6	TATA spare parts
886387002784	FORK PIN FOR FORK/20X10 BS6	TATA spare parts
886387002785	SPRING ROD/390X20 BS6	TATA spare parts
886387002786	CRANK HANDLE ASSY. BS6	TATA spare parts
886387002787	TOW CHAIN/16 MMX6 METER WITH HOOK BS6	TATA spare parts
886387002788	SEARCH LAMP ASSY/LRV BS6	TATA spare parts
886387002789	REVOLVING LIGHT 24-V BS6	TATA spare parts
886387002790	TOW BAR ASSY. BS6	TATA spare parts
886387002791	SNATCH BLOCK BS6	TATA spare parts
886387002792	ASSLY PULLING PIPE BS6	TATA spare parts
886387002793	TIPPER BODY ASSEMBLY BS6	TATA spare parts
886387002794	CUBED BODY ASSEMBLY BS6	TATA spare parts
886387002795	BOX ASSY TIPPER BODY BS6	TATA spare parts
886387002796	SUBFRAME ASSY WITH CRADLE & MOUNTING BS6	TATA spare parts
886387002797	SUBFRAME ASSY BS6	TATA spare parts
886387002798	TAIL GATE ASSY BS6	TATA spare parts
886387002799	CRADLE ASSY BS6	TATA spare parts
886387002800	MS BUSH 80X50X50 (WITHOUT GROUVE) BS6	TATA spare parts
886387002801	MS BUSH 80X50X50 (WITH GROVE) BS6	TATA spare parts
886387002802	MS PIN SHAFT 1020X60 REAR HINGE BS6	TATA spare parts
886387002803	TAIL DOOR HINGE ASSY BS6	TATA spare parts
886387002804	ATTACHMENT PLATE 1 BS6	TATA spare parts
886387002805	ATTACHMENT PLATE 2 BS6	TATA spare parts
886387002806	ATTACHMENT PLATE 3 BS6	TATA spare parts
886387002807	UPPER PIVOT BS6	TATA spare parts
886387002808	MUDGUARD BS6	TATA spare parts
886387002809	MUDGUARD ASSY BS6	TATA spare parts

886387002810	RAIN FLAP BS6	TATA spare parts
886387002811	RAIN FLAP BS6	TATA spare parts
886387002812	MUDGUARD LH BS6	TATA spare parts
886387002813	MUDGUARD RH BS6	TATA spare parts
886387002814	MUDGUARD RH BS6	TATA spare parts
886387002815	MUDGUARD RH BS6	TATA spare parts
886387002816	CAM HAMMER ASSEMBLY BS6	TATA spare parts
886387002817	PULLING PIPE ASSEMBLY BS6	TATA spare parts
886387002818	ADJUSTABLE ROD THREADED END ASSLY BS6	TATA spare parts
886387002819	FORK LH THREAD BS6	TATA spare parts
886387002820	CAM MOUNTING ASSEMBLY BS6	TATA spare parts
886387002821	BODY PROP ASSY BS6	TATA spare parts
886387002822	TIPPER BODY ASSEMBLY BS6	TATA spare parts
886387002823	CUBED BODY ASSEMBLY BS6	TATA spare parts
886387002824	BOX ASSY TIPPER BODY BS6	TATA spare parts
886387002825	SUBFRAME ASSY W/ CRADLE & MOUNTING BS6	TATA spare parts
886387002826	SUBFRAME ASSY W/O CRADLE & MOUNTING BS6	TATA spare parts
886387002827	TAIL GATE ASSY BS6	TATA spare parts
886387002828	CRADLE ASSY BS6	TATA spare parts
886387002829	TAIL DOOR HINGE ASSY BS6	TATA spare parts
886387002830	MUDGUARD ASSY BS6	TATA spare parts
886387002831	RAIN FLAP BS6	TATA spare parts
886387002832	RAIN FLAP BS6	TATA spare parts
886387002833	PULLING PIPE ASSEMBLY BS6	TATA spare parts
886387002834	CUSHION SEAT BS6	TATA spare parts
886387002835	CUSHION BACK SEAT BS6	TATA spare parts
886387002836	LEGS FOR TOW HITCH BS6	TATA spare parts
886387002837	TOW HITCH BS6	TATA spare parts
886387002838	BOOM SHIV CABLE YOKE BS6	TATA spare parts
886387002839	SPRING ROD/156X35 BS6	TATA spare parts
886387002840	LOCKING PIN HANDLE/30X37X16 BS6	TATA spare parts
886387002841	BARREL/TELESCOPIC BUSH/105X45X35 BS6	TATA spare parts
886387002842	SWIVEL COLUMN BS6	TATA spare parts
886387002843	ASSLY BODY CUBBING BS6	TATA spare parts
886387002844	ASSLY TAIL PANEL BS6	TATA spare parts
886387002845	ASSLY TOP DOOR BS6	TATA spare parts
886387002846	MASTER VALVE 3INCH	TATA spare parts
886387002847	GATE VALVE 3INCH	TATA spare parts
886387002848	SS BALL VALVE 2INCH	TATA spare parts
886387002849	HYDRAULIC MOTOR	TATA spare parts
886387002850	PRODUCT PUMP 2INCH	TATA spare parts
886387002851	DIESEL FILTER STRAINER	TATA spare parts
886387002852	FLOW-METER 380 LPM	TATA spare parts
886387002853	HOSE REEL	TATA spare parts
886387002854	HOSE	TATA spare parts
886387002855	NOZZLE	TATA spare parts
886387002856	MODULE LIGHT	TATA spare parts

886387002857	MODULE LIGHT SWITCH	TATA spare parts
886387002858	HYDRAULIC HOSE PIPE KIT	TATA spare parts
886387002859	9KG FIRE EXTINGUISHER	TATA spare parts
886387002860	MODULE ROOF SPOT LIGHT	TATA spare parts
886387002861	WALVOIL 1 SPOOL OPERATING VALVE	TATA spare parts
886387002862	SIDE INDICATOR	TATA spare parts
886387002863	U BOLT AND NUT	TATA spare parts
886387002864	ATTACHMENT PLATE AND MTG. BOLT	TATA spare parts
886387002865	REAR PARTION OPEN LEVER	TATA spare parts
886387002866	PRESSURE VACUUM VALVE	TATA spare parts
886387002867	EMERGENCY VENT	TATA spare parts
886387002868	FUSIBLE LINK	TATA spare parts
886387002869	JERRY CAN 20 LITRESS	TATA spare parts
886387002870	FIRE EXTINGUISER BRACKET	TATA spare parts
886387002871	LADDER TOP AND BOTTOM SET	TATA spare parts
886387002872	TAIL LIGHT COVER	TATA spare parts
886387002873	MODULE STRUCTURE	TATA spare parts
886387002874	MUD GUARD STRUCTURE FRAME	TATA spare parts
886387002875	WIRE HARNESS KIT	TATA spare parts
886387002876	REAR BUMPER FRAME	TATA spare parts
886387002877	10KL FABRICATION & ALL FITTINGS 1 SET	TATA spare parts
886387002878	TAIL GATE LOCKING MECHANISM ASSY	TATA spare parts
886387002879	14FT DSD LOAD BODY ASSY PAINTED BS6	TATA spare parts
886387002880	SUPPORT LH.[L-BKT.LH 709] BS6	TATA spare parts
886387002881	SUPPORT RH.[L-BKT.RH 709] BS6	TATA spare parts
886387002882	TAIL PANEL ASSY BS6	TATA spare parts
886387002883	LIFT RING KIT 175-4 CYLINDER BS6	TATA spare parts
886387002884	CYLINDER EYE SPACER 50 X 16 BS6	TATA spare parts
886387002885	CYLINDER MOUNTING PIN WITH SPLIT PIN BS6	TATA spare parts
886387002886	SUCTION VALVE KIT (R1 1/2 BSPOT X 45) BS	TATA spare parts
886387002887	HP HOSE R2 1 - 1200 MM BS6	TATA spare parts
886387002888	SUCTION HOSE R4 1 3/4 1.7 MTRS BS6	TATA spare parts
886387002889	PVC FLEXIBLE TUBE BS6	TATA spare parts
886387002890	FILLER CAP KIT (PLASTIC) BS6	TATA spare parts
886387002891	DUST CAP-YELLOW BS6	TATA spare parts
886387002892	ROD EYE O-RING BS6	TATA spare parts
886387002893	CIRCLIP BS6	TATA spare parts
886387002894	SCREW M12X20 BS6	TATA spare parts
886387002895	SPLIT PIN 10 X 100 MM (DIN 94) BS6	TATA spare parts
886387002896	CRADLE+OT BRACKET ASSEMBLY BS6	TATA spare parts
886387002897	HOSE VALVE TO RLF BS6	TATA spare parts
886387002898	CIRCLIP 97 DIN 472 (102.5X3) BS6	TATA spare parts
886387002899	MG 540WIDE 460HT	TATA spare parts
886387002900	STABILIZER LOCKING BRACKET BS6	TATA spare parts
886387002901	WIRE MESH BOTTOM PLATE	TATA spare parts
886387002902	STABLIZER CIRCLIP BS6	TATA spare parts
886387002903	PISTON ROD BS6	TATA spare parts

886387002904	PISTON ROD BS6	TATA spare parts
886387002905	PISTON ROD BS6	TATA spare parts
886387002906	TUBE PORT S/A BS6	TATA spare parts
886387002907	HOSE 2000MM	TATA spare parts
886387002908	FILL PIPE AND DIP PIPE CAP BS6	TATA spare parts
886387002912	TOP MARKER COVER BS6	TATA spare parts
886387002913	TOP MARKER LIGHT BS6	TATA spare parts
886387002914	SIDE MARKER NEOLITE BS6	TATA spare parts
886387002915	SIDE MARKER BRACKET ASSY BS6	TATA spare parts
886387002916	REFLECTIVE TAPE YELLOW BS6	TATA spare parts
886387002917	REFLECTIVE TAPE RED BS6	TATA spare parts
886387002918	FILTER ELEMENT DE 1	TATA spare parts
886387002919	WASHER KIT LPO 1515/55	TATA spare parts
886387002920	STARTING PULLEY BS6	TATA spare parts
886387002921	SUBFRAME ASSY 18 CUM BOX TIP LPK3118 BS4	TATA spare parts
886387002922	TIPPER BODY ASSEMBLY W/HYD. KIT BS6	TATA spare parts
886387002923	TIPPER BODY ASSEMBLY W/O HYD.BS6	TATA spare parts
886387002924	SIDE SKIRT RAIN FLAP LH BS6	TATA spare parts
886387002925	SIDE SKIRT RAIN FLAP RH BS6	TATA spare parts
886387002926	RAIN FLAP REAR LH BS6	TATA spare parts
886387002927	RAIN FLAP REAR RH BS6	TATA spare parts
886387002928	FRONT MUDGUARD LH BS6	TATA spare parts
886387002929	FRONT MUDGUARD RH BS6	TATA spare parts
886387002930	REAR MUDGUARD ASSY (HINGE TYPE) LH BS6	TATA spare parts
886387002931	REAR MUDGUARD ASSY (HINGE TYPE) RH BS6	TATA spare parts
886387002932	TAILDOOR ASSEMBLY BS6	TATA spare parts
886387002933	TAIL DOOR HINGE ASSY LH BS6	TATA spare parts
886387002934	TAIL DOOR HINGE ASSY RH BS6	TATA spare parts
886387002935	HOOK BLOCK ASSY LH BS6	TATA spare parts
886387002936	HOOK BLOCK ASSY RH BS6	TATA spare parts
886387002937	SUBFRAME ASSEMBLY BS6	TATA spare parts
886387002938	CRADLE ASSEMBLY BS6	TATA spare parts
886387002939	BODY GUIDE BS6	TATA spare parts
886387002940	BODY PROP ASSEMBLY BS6	TATA spare parts
886387002941	BODY PROP PIN ASSEMBLY BS6	TATA spare parts
886387002942	HAMMER ASSEMBLY (LH) BS6	TATA spare parts
886387002943	HAMMER ASSEMBLY (RH) BS6	TATA spare parts
886387002944	PIN FOR CAM MOUNTING BS6	TATA spare parts
886387002945	FORK PIN BS6	TATA spare parts
886387002946	CAM BUSH BS6	TATA spare parts
886387002947	TAIL LAMP BKT LH BS6	TATA spare parts
886387002948	TAIL LAMP BKT RH BS6	TATA spare parts
886387002949	ASSY LOAD BODY 23 CUM BOX W/HYD. KIT BS6	TATA spare parts
886387002950	TAIL DOOR BS6	TATA spare parts
886387002951	COMPLETE LOAD BODY BS6	TATA spare parts
886387002952	LH SIDE PULLING PIPE ASSY 2100MM L BS6	TATA spare parts
886387002953	LH SIDE LOCKING CAM ASSEMBLY BS6	TATA spare parts

886387002954	LH SIDE LOCKING HOOK ASSEMBLY BS6	TATA spare parts
886387002955	LH SIDE TENSION SPRING BS6	TATA spare parts
886387002956	SUBFRAME ASSY WITH MOUNTING AND CRADLE	TATA spare parts
886387002957	16 CUM HD TIPPER BODY W/ HYD. KIT	TATA spare parts
886387002958	16 CUM HD TIPPER BODY W/O HYD. KIT	TATA spare parts
886387002959	HEX HEAD BOLT M16X110	TATA spare parts
886387002960	LOWER PIVOT 190L	TATA spare parts
886387002961	SUBFRAME ASSY W/MOUNTINGS & CRADLE BS6	TATA spare parts
886387002962	TAIL DOOR HINGE PIN BS6	TATA spare parts
886387002963	HOOK BLOCK ASSY LH BS6	TATA spare parts
886387002964	HOOK BLOCK ASSY RH BS6	TATA spare parts
886387002965	LINK ARM BUSH BS6	TATA spare parts
886387002966	LINK ARM PIN BS6	TATA spare parts
886387002967	TAIL DOOR PIN BS6	TATA spare parts
886387002968	SUBFRAME ASSY WITH CRADLE & MOUNTING KIT	TATA spare parts
886387002969	CRADLE ASSY 10 CUM FOR FC CYLINDER	TATA spare parts
886387002970	GEAR PUMP 95 CC BS6	TATA spare parts
886387002971	SUBFRAME ASSY W/MOUNTINGS & CRADLE BS6	TATA spare parts
886387002972	LOAD BODY BS6	TATA spare parts
886387002973	ASSLY TAIL GATE-6.5CUM FEET	TATA spare parts
886387002974	LOAD BODY ASSY BS6	TATA spare parts
886387002975	SUBFRAME ASSY W/MOUNTINGS & CRADLE BS6	TATA spare parts
886387002976	MUD FLAP ASSY BS6	TATA spare parts
886387002977	P209 DC VALVE BS6	TATA spare parts
886387002978	SUBFRAME ASSY WITH CRADLE PRIMA 3525.K	TATA spare parts
886387002979	MUDGUARD BS6	TATA spare parts
886387002980	2ND AXLE RAIN FLAP BS6	TATA spare parts
886387002981	2ND AXLE MUDGUARD ASSEMBLY BS6	TATA spare parts
886387002982	LOAD BODY W/ HYD KIT FC 110 W/O PUMP PTO	TATA spare parts
886387002983	LOAD BODY WITHOUT HYD. KIT	TATA spare parts
886387002984	BOX ASSY TIPPER BODY BS6	TATA spare parts
886387002985	SUBFRAME ASSY W/ CRADLE & MOUNTING BS6	TATA spare parts
886387002986	LOAD BODY 3CUM W/ SUBFRAME & HYD	TATA spare parts
886387002987	LOAD BODY 3CUM W/ SUBFRAME W/O HYD	TATA spare parts
886387002988	REAR HINGE BUSH ASSY BS6	TATA spare parts
886387002989	SUBFRAME ASSY WITHOUT MOUNTING	TATA spare parts
886387002990	SUBFRAME ASSY WITH MOUNTING	TATA spare parts
886387002991	ASSY LOAD BODY 16 CUM BOX W/HYD. KIT	TATA spare parts
886387002992	ASSY LOAD BODY 16 CUM BOX W/O HYD. KIT	TATA spare parts
886387002993	GREASE PUMP	TATA spare parts
886387002994	LOAD BODY WITHOUT KIT & MTG	TATA spare parts
886387002995	SIDEBOARD ASSEMBLY LH BS6	TATA spare parts
886387002996	SIDEBOARD ASSEMBLY RH BS6	TATA spare parts
886387002997	HEADBOARD ASSEMBLY BS6	TATA spare parts
886387002998	FLOOR ASSEMBLY BS6	TATA spare parts
886387002999	FRONT UPPER PIVOT RH BS6	TATA spare parts
886387003000	CUBED BODY BS6	TATA spare parts



886387003001	HEADBOARD ASSEMBLY BS6	TATA spare parts
886387003002	SIDEBORD ASSEMBLY LH BS6	TATA spare parts
886387003003	SIDEBORD ASSEMBLY RH BS6	TATA spare parts
886387003004	FLOOR ASSEMBLY BS6	TATA spare parts
886387003005	TAILDOOR + WELDED PARTS BS6	TATA spare parts
886387003006	SUBFRAME ASSEMBLY BS6	TATA spare parts
886387003007	REAR ATTACHMENT ASSEMBLY LH BS6	TATA spare parts
886387003008	REAR ATTACHMENT ASSEMBLY RH BS6	TATA spare parts
886387003009	ATTACHMENT PLATE ASSEMBLY BS6	TATA spare parts
886387003010	CIRCLIP 97 (102.5 X3.0) BS6	TATA spare parts
886387003011	STEEL BATTENTM07W1.19.2-7 BS6	TATA spare parts
886387003012	MUDGUARD SUPPRT 2 TM0700 BS6	TATA spare parts
886387003013	MUDGUARD SUPPORT 1 TM0700 BS6	TATA spare parts
886387003014	STEEL BATTEN TM0700 BS6	TATA spare parts
886387003015	RIGHT COVER ASSY BS6	TATA spare parts
886387003016	ASSY LOAD BODY WITH SUBFRAME & W/O HYD B	TATA spare parts
886387003017	ASSLY SIDE PANEL RH BS6	TATA spare parts
886387003018	ASSLY MUDGUARD LH BS6	TATA spare parts
886387003019	ASSLY MUDGUARD RH BS6	TATA spare parts
886387003020	HP HOSE R2 1 - 1950 MM	TATA spare parts
886387003021	PULLING PIPE ASSEMBLY LENGTH 825 MM	TATA spare parts
886387003022	TIPPING SYSTEM	TATA spare parts
886387003024	SUBFRAME ASSY WITH MOUNTING	TATA spare parts
886387003025	TIPPER BODY WITH HYDRAULIC KIT BS6	TATA spare parts
886387003026	TIPPER BODY WITH OUT HYDRAULIC KIT BS6	TATA spare parts
886387003027	SUBFRAME WITHOUT CRADLE	TATA spare parts
886387003028	SUBFRAME MOUNTING KIT	TATA spare parts
886387003029	ASSY LOAD BODY W/O SUBFRAME & W/O HYD BS	TATA spare parts
886387003030	TIPPER BODY ASSEMBLY (WITH HYDRAULIC) BS	TATA spare parts
886387003031	TIPPER BODY ASSEMBLY (W/O HYDRAULIC) BS6	TATA spare parts
886387003032	WING NUT ASSY BS6	TATA spare parts
886387003033	MANHOLE COVER BS6	TATA spare parts
886387003034	MUDGUARD ASSY BS6	TATA spare parts
886387003035	SUPD ASSY BS6	TATA spare parts
886387003036	9 KL SHELL ASSY BS6	TATA spare parts
886387003037	SUBFRAME ASSY BS6	TATA spare parts
886387003038	SUBFRAME ASSY WITH MOUNTING	TATA spare parts
886387003039	TAIL DOOR HINGE PIN BS6	TATA spare parts
886387003040	CAM HAMMER ASSEMBLY HD BS6	TATA spare parts
886387003041	COMPLETE BULKER ASSEMBLY BS6	TATA spare parts
886387003042	CAM HAMMER ASSEMBLY HD BS6	TATA spare parts
886387003043	TIPPER BODY ASSY WITH MTG DETAILS BS6	TATA spare parts
886387003044	TIPPER BODY ASSY WITH SUBFRAME BS6	TATA spare parts
886387003045	SUBFRAME ASSS BS6	TATA spare parts
886387003046	PANEL-SIDE WALL BS6	TATA spare parts
886387003047	TIE ROD ASSEMBLY BS6	TATA spare parts
886387003048	SUBFRAME ASSY 4.5 CUM SK 1613	TATA spare parts

886387003049	CRADLE ASSEMBLY	TATA spare parts
886387003050	MIXING DRUM TM07W1.8 BS6	TATA spare parts
886387003051	SPACER RUBBER_40MM (FRONT) BS6	TATA spare parts
886387003052	SPACER RUBBER_35MM (REAR) BS6	TATA spare parts
886387003053	CRADLE ASSEMBLY BS6	TATA spare parts
886387003054	PMP HYD. MOTOR - MCL.7202 BS6	TATA spare parts
886387003055	PULLING PIPE ASSEMBLY BS6	TATA spare parts
886387003056	CAM ASSEMBLY BS6	TATA spare parts
886387003057	TIE ROD ASSY BS6	TATA spare parts
886387003058	SUBFRAME ASSY GARBAGE TIPPER 5CUM BS6	TATA spare parts
886387003059	5CUM GARBAGE TIPPER ASSY BS6	TATA spare parts
886387003060	SUBFRAME ASSY WITH MOUNTING	TATA spare parts
886387003061	CHUTE WITH WEAR PLATE L=1497 C AR BS6	TATA spare parts
886387003062	ROLLER MOUNTING KIT CPL. ( D=250MM) BS6	TATA spare parts
886387003063	CHUTE BEARING ASSEMBLY ND VERSION BS6	TATA spare parts
886387003064	CHUTE ADJUSTMENT BS6	TATA spare parts
886387003065	SUSPENSION & PROTECTION GRILL ASSY. BS6	TATA spare parts
886387003066	LADDER ASSEMBLY CPL.- RH ND VERSION BS	TATA spare parts
886387003067	SUBFRAME ASSY WITH MOUNTING WO CRADLE	TATA spare parts
886387003068	23 CUM BOX BODY TIPPER W/O HYDRAULIC KIT	TATA spare parts
886387003069	DISCHARGE HOSE WITH MALE COUPLER & FLANG	TATA spare parts
886387003070	PULLING PIPE ASSEMBLY BS6	TATA spare parts
886387003071	ADJUSTABLE ROD THREADED END BS6	TATA spare parts
886387003072	FORK LH THREAD BS6	TATA spare parts
886387003073	SUBFRAME ASSY WITH CRADLE & MOUNTINGS BS	TATA spare parts
886387003074	REAR RAIN FLAP BS6	TATA spare parts
886387003075	SUBFRAME ASSY WITH CRADLE & MOUNTINGS	TATA spare parts
886387003076	PULLING PIPE ASSEMBLY 900 BS6	TATA spare parts
886387003077	REMOTE CONTROL CABLE L=6.3 M BS6-PH2	TATA spare parts
886387003078	LOAD BODY ASSY WITH SUBFRAME & MOUNTING	TATA spare parts
886387003079	LADDER TOP PLATE - N2 BS6	TATA spare parts
886387003080	M.S.COUPLING 1/2INCH X 55MM LONG BS6	TATA spare parts
886387003081	FLOW CONTROL VALVE BS6	TATA spare parts
886387003082	P.U TUBE(CODE-WH00T12 B26 L17R2-K)-620MM	TATA spare parts
886387003083	COUNTER HOLDER INCHCINCH VERSION BS6	TATA spare parts
886387003084	HYDRAULIC HOSE ASSEMBLY - PMP- 55CC BS6	TATA spare parts
886387003085	FITTING BODY GES 30 S/ 1 1/16-12UN BS6	TATA spare parts
886387003086	HEX.SCREW DIN 933 M 12 X 40-8.8-ZINC C.	TATA spare parts
886387003087	FITTING BODY GES 28 LR-WD BS6	TATA spare parts
886387003088	FITTING BODY GES 22 LR-WD BS6	TATA spare parts
886387003089	JUNCTION PLATE(RIB) BS6	TATA spare parts
886387003090	PMP P55B R-MS-V-C4-21N-0-CP1-420-A BS6	TATA spare parts
886387003091	HAYES COUPLING - 132855 BS6	TATA spare parts
886387003092	REMOTE CONTROL ASSEMBLY (55 CC) CPL. BS6	TATA spare parts
886387003093	CONTROL CABLE BKT CPL. FOR PMP PUMP BS6	TATA spare parts
886387003094	ANGLE JOINT M8 X 20 BS6	TATA spare parts
886387003095	DOUBLE TOOTHED RACK TRANSMITTER RH VER.	TATA spare parts

886387003096	PMP6 R126 GEARBOX - TM BS6	TATA spare parts
886387003097	DIGITAL HOUR METER BS6	TATA spare parts
886387003098	HEX.HEAD SCREW DIN933 M16 X 35-8.8-A2C B	TATA spare parts
886387003099	HOSE RETAINER CPL. 7 CU.M N2 VER BS6	TATA spare parts
886387003100	HEX.SCREW M 10X 25 DAC.10.9 DIN 933 BS6	TATA spare parts
886387003101	BATTERY CABLE 35SQ.MM X 2500 MM (RED) BS	TATA spare parts
886387003102	MOUNTING PLATE TATA BS VI W884/ H180 BS6	TATA spare parts
886387003103	METAL BRAIDED HOSE 8X8 BANJO - 2MTS LONG	TATA spare parts
886387003104	BANJO BOLT M8 X 22 LG. BS6	TATA spare parts
886387003105	SUBFRAME ASSY WITH CRADLE & ATTACHMENT P	TATA spare parts
886387003106	LOAD BODY WITHOUT SUBFRAME & HYDRAULIC	TATA spare parts
886387600001	TIPPER BODY ASSEMBLY - 8 CUM UB TR (WITH	TATA spare parts
886387600002	SUBFRAME ASSEMBLY - 6.5 CUM FE IRON ORE	TATA spare parts
886387600003	3-SPOOL VALVE	TATA spare parts
886387600004	14 CUM HD TIPPER BODY ASSY. W/O HYDRAULI	TATA spare parts
886387600005	ASSY SUB FRAME	TATA spare parts
886387600006	TAIL GATE ASSY	TATA spare parts
886387600007	TIE ROD ASSY	TATA spare parts
886387600008	ASSEMBLY SUBFRAME (WITH CRADLE AND STABI	TATA spare parts
886387600009	ASSEMBLY SUBFRAME (W/O CRADLE AND STABIL	TATA spare parts
886387600010	REAR HINGE SHAFT/60X1000MM	TATA spare parts
886387600011	REAR HINGE INNER BUSH WITHOUT GROOVE/88X	TATA spare parts
886387600012	REAR HINGE OUTER BUSH WITH GROOVE/88X60X	TATA spare parts
886387600013	REAR HING SHAFT SNAP RING (HD)	TATA spare parts
886387600014	REAR HINGE STEEL BUSH ASSY/DIA 88X90	TATA spare parts
886387600015	HOSE PIPE 4800	TATA spare parts
886387600016	REAR MUDGUARD	TATA spare parts
886387600017	REAR SPRAY SUPPRESSION SUB ASSY	TATA spare parts
886387600018	REAR SUPPRESSION ASSY	TATA spare parts
886387600019	RAIN FLAP 640X530	TATA spare parts
886387600020	PIPE FRAME ASSEMBLY	TATA spare parts
886387600021	REAR RAIN FLAP (960X630MM )	TATA spare parts
886387600022	MUD FLAP HINGE ASSEMBLY	TATA spare parts
886387600023	TAIL-DOOR LOAD BODY FOR 2518 HD	TATA spare parts
886387600024	SUBFRAME ASSY - 8 CUB MTR - SK 1613	TATA spare parts
886387600025	SUBFRAME ASSY/8 CUM ON SK1613/36-960 ROH	TATA spare parts
886387600026	SUBFRAME ASSY /16 CUM HD/LPK2518	TATA spare parts
886387600027	SUB FRAME ASSY	TATA spare parts
886387600028	SUBFRAME ASSY-4.5 CUM/SK1613/32-960ROH	TATA spare parts
886387600029	CRADLE ASSY-10CUM DS BOX TIPPER ON LPK 1	TATA spare parts
886387600030	RUBBER PAD/200X72X20	TATA spare parts
886387600031	RUBBER PAD/200X72X30	TATA spare parts
886387600032	LOCKING PLATE	TATA spare parts
886387600033	STOPPER PLATE	TATA spare parts
886387600034	PULLING PIPE 2200 L	TATA spare parts
886387600035	TAIL LAMP BRACKET LH	TATA spare parts
886387600036	REAR MUD FLAP W/FRAME COMP. FRONT	TATA spare parts

886387600037	TAIL LAMP BRACKET RH	TATA spare parts
886387600038	CRADLE & OIL TANK MTG. BRACKET	TATA spare parts
886387600039	LOCKING HOOK BLOCK ASSY (RH)	TATA spare parts
886387600040	LOCKING HOOK BLOCK ASSY (LH)	TATA spare parts
886387600041	CAM PIN /DIA 16X87	TATA spare parts
886387600042	HAMMER MOUNTING BRACKET/6X200X120	TATA spare parts
886387600043	HAMMER ASSY/8.5 CUM	TATA spare parts
886387600044	CAM MOUNTING ASSY	TATA spare parts
886387600045	CAM ASSY	TATA spare parts
886387600046	PULLING PIPE ASSY/775 L	TATA spare parts
886387600047	HOOK ASSY	TATA spare parts
886387600048	FORK LINK PIN/48X16	TATA spare parts
886387600049	ASSY. SUBFRAME -18 CUM BOX	TATA spare parts
886387600050	SUB FRAME WITH CRADLE AND ALL MOUNTINGS	TATA spare parts
886387600051	W/H FOR SIDE MARKER LAMP L/B	TATA spare parts
886387600052	REAR HINGE PIN	TATA spare parts
886387600053	HEX BOLT 12X30	TATA spare parts
886387600055	TAIL DOOR HINGE PIN	TATA spare parts
886387600056	LOAD BODY ASSLY	TATA spare parts
886387600057	LOAD BODY 4.5 CUM SK 1613 36	TATA spare parts
886387600058	CAM HAMMER ASSY.10 CUM TIPPER	TATA spare parts
886387600059	TAIL GATE ASSY	TATA spare parts
886387600060	TAIL DOOR 16 CUM HD	TATA spare parts
886387600061	10 CUM ON 1616/42 BODY ONLY (WITHOUT KIT	TATA spare parts
886387600062	SUBFRAME ASSY 24 CUM & MOUNTING ACCESSO	TATA spare parts
886387600063	CAM PROFILE	TATA spare parts
886387600064	PIN	TATA spare parts
886387800001	1/2 IN X 16MM PIPE FERRUL & NUT	TATA spare parts
886387800002	TEE ADAPTOR 16MM X 16MM X 1/4IN	TATA spare parts
886387800003	3/4 IN BSP X 16MM PIPE FERRUL & NUT	TATA spare parts
886387800004	COUNTER BALANCE VALVE	TATA spare parts
886387800005	SEAMLESS TUBE	TATA spare parts
886387800006	SEAMLESS TUBE	TATA spare parts
886387800007	REAR HINGE PIN	TATA spare parts
886387800008	PIN LOCKING PLATE	TATA spare parts
886387800009	BASE	TATA spare parts
886387800010	STAGE	TATA spare parts
886387800011	STAGE	TATA spare parts
886387800012	PISTON	TATA spare parts
886387800013	SUB FRAME ASSY	TATA spare parts
886387800014	CYLINDER MOUNTING CRADDLE ASSEMBLY	TATA spare parts
886387800015	ASSY. TIPPER BODY COMPLETE W/O HYDRAULIC	TATA spare parts
886387800016	ASSY. TAIL GATE	TATA spare parts
886387800017	10CUM RIBLESS BODY (W/O HYDRAULICS)	TATA spare parts
886387800018	CYLINDER MTG PIN 1	TATA spare parts
886387800019	CYLINDER MTG PIN	TATA spare parts
886387800020	TAILDOOR HINGE PIN	TATA spare parts

886387800021	CRADLE + OIL TANK BKT	TATA spare parts
886387800022	STABILISER ASSY	TATA spare parts
886387800025	SA 40 CYLINDER 550 STROKE	TATA spare parts
886387800026	HYDRAULIC CYLINDER	TATA spare parts
886387800027	RAINFLAP INT RH 630X1085	TATA spare parts
886387800028	PL WASHER M8 FLAP	TATA spare parts
886387800029	MUDGUARD BKT	TATA spare parts
886387800030	STICKER TATA WITH LOGO BLUE	TATA spare parts
886387800031	STICKER TATA BIG	TATA spare parts
886387800032	CROSS ROD DIA 30MM	TATA spare parts
886387800033	HYDRAULIC TANK MOUNTING	TATA spare parts
886387800034	NEW TAIL DOOR WITH PARTS	TATA spare parts
886387800035	FITMENT KIT FOR SUB FRAME 10 CU.M STD	TATA spare parts
886387800036	SUBFRAME+CRADLE & MO	TATA spare parts
886387800037	MUDFLAP HINGE ASSEMBLY	TATA spare parts
886387800038	RAINFLAP REAR	TATA spare parts
886387800039	TIPPER BODY 20 CUM RIBLESS LPK 2518 (W/O	TATA spare parts
886387800040	CRADLE ASSY LPK 2518 14CUM	TATA spare parts
886387800041	CANOPY SUPPORT ROD	TATA spare parts
886387800042	SUB FRAME & ASSEMBLY + CRADLE + MOUNTINGS	TATA spare parts
886387800043	HYD RELIEF VALVE	TATA spare parts
886387800044	COMPLETE LOAD BODY (EXCLUDING SUB FRAME	TATA spare parts
886387800045	SUBFRAME+CRADL+MTGKIT (PAINTED)	TATA spare parts
886387800046	LOAD BODY WITH SUB FRAME	TATA spare parts
886387800047	TAIL DOOR ASSEMBLY	TATA spare parts
886387800048	TIPPING BODY 8.5 CUM W/SUB FRAME & HYD	TATA spare parts
886387800049	TIPPING BODY 8.5 CUM W/O SUB FRAME & HYD	TATA spare parts
886387800050	REAR RAINFLAP ASSLY	TATA spare parts
886387800051	PIN-2 GROOVES	TATA spare parts
886387800052	COTTER PIN (3 WAY TIPPER)	TATA spare parts
886387800053	CAM ASSY RH	TATA spare parts
886387800054	CAM ASSY LH	TATA spare parts
886387800055	PULLING PIPE ASSLY	TATA spare parts
886387800056	COMPLETE PACKSET TYPE A110-3	TATA spare parts
886387800057	TIPPING CYLINDER	TATA spare parts
886387800058	REAR HINGE SHAFT	TATA spare parts
886387800059	REFURBISH KIT 110-3 FL	TATA spare parts
886387800060	LOAD BODY ASSLY	TATA spare parts
886387800061	14CU STD LPK2518	TATA spare parts
886387800062	COMP 8.5 +MTG+PTO KIT TATA3118	TATA spare parts
886387800063	TAILDOOR ASSEMBLY	TATA spare parts
886387800064	SUBFRAME ASSY	TATA spare parts
886387800065	TD ASSEMBLY	TATA spare parts
886387800066	TAILDOOR HINGE L PLATE	TATA spare parts
886387800067	ADAPTOR 3/8INCHBSP X 3/8INCHBSP	TATA spare parts
886387800068	HOSE 3/8INCHI.DX1100 R2 3/8INCHBSP	TATA spare parts
886387800069	SEAMLESS PIPE DIA 12X150X100 MM	TATA spare parts

886387800070	ADAPTOR 3/8INCH BSP X M18X 1.5P	TATA spare parts
886387800071	HOSE 3/8INCHI.DX1900 R2 3/8INCHBSP	TATA spare parts
886387800072	TAILDOOR ASSEMBLY WELDED 8.5CU	TATA spare parts
886387800073	SPARE WHEEL CARRIER ARM ASSY	TATA spare parts
886387800074	SPARE WHEEL MTG BKT ASSY	TATA spare parts
886387800075	REAR HINGE INNER BRACKET BUSH	TATA spare parts
886387800076	HOOK BLOCK ASSLY LH	TATA spare parts
886387800077	HOOK BLOCK ASSLY RH	TATA spare parts
886387800078	IGUS BUSH	TATA spare parts
886387800079	AIR CONTROL VALVE BRACKET	TATA spare parts
886387800080	DUST COVER FE 129-3/137-3	TATA spare parts
886387800081	PISTON FL2 S091-1365-HD-HC	TATA spare parts
886387800082	OUTER STOPRING FL 091 A22	TATA spare parts
886387800083	BOTTOM PLATE PISTON FL 091 MK2 HD	TATA spare parts
886387800084	O RING PISTON BOTTOM 091	TATA spare parts
886387800085	PISTON EYE SPH.FL 091 MK2 L-075 GR	TATA spare parts
886387800086	O RING 72.62 X 3.53 MM	TATA spare parts
886387800087	PIN ROUND HEAD GROOVED 8X15 MM	TATA spare parts
886387800088	GREASE NIPPLE M8 X 1	TATA spare parts
886387800089	GREASER PROTECTION CAP	TATA spare parts
886387800090	STAGE FL2 110-1360-HD-HC	TATA spare parts
886387800091	OUTER STOPRING FL 110 A22	TATA spare parts
886387800092	LIFTRING FL 110 A22	TATA spare parts
886387800093	STAGE FL2 129-1360-HD-HC	TATA spare parts
886387800094	OUTER STOPRING FL 129 A22	TATA spare parts
886387800095	LIFTRING FL 129-A22	TATA spare parts
886387800096	BASE FL2 149-1399-4/4B SAE-190-HD	TATA spare parts
886387800097	BOTTOM PLATE FL2 149	TATA spare parts
886387800098	SEAL KIT COMPLETE(CONSISTS OF ITEM NO 7	TATA spare parts
886387800099	ASSLY LOAD BODY	TATA spare parts
886387800100	COUPLING (FLEXIBLE) LZQ-01	TATA spare parts
886387810001	HYD CONTROL LEVER PIPE	TATA spare parts
886387810002	HYD CONROL LEVER LINK SET(3nos)	TATA spare parts
886387810003	TAILGATE LOCK ASSEMBLY	TATA spare parts
886387960001	ROD	TATA spare parts
886387960002	CAM	TATA spare parts
886387960003	PNEUMATIC SYSTEM MECHANISM WITH ELCTRO	TATA spare parts
886387960004	FRONT WINDSHIELD MOULD	TATA spare parts
886387960005	QUARTER GLASS	TATA spare parts
886388000001	BUMPER FRONT	TATA spare parts
886388000002	FRONT BUMPER	TATA spare parts
886388000003	FRONT BUMPER	TATA spare parts
886388000004	REAR BUMPER WITHOUT PAINTED	TATA spare parts
886388000005	FRONT BUMPER ASSY FRP AB65	TATA spare parts
886388000006	REAR BUMPER(RIGHT)	TATA spare parts
886388000007	REAR BUMPER(LEFT)	TATA spare parts
886388000008	SQUARE REFLECTORç (RED)	TATA spare parts

88638800009	REAR BUMPER CENTER PIECE	TATA spare parts
88638800010	REAR BUMPER SIDE PIECE	TATA spare parts
88638800011	REAR BUMPER	TATA spare parts
88638800012	FRONT BUMPER LP 1613/52	TATA spare parts
88638800013	FRONT BUMPER ĩ MTS	TATA spare parts
88638800014	FRONT GRILL LP 1613/52	TATA spare parts
88638800015	FRONT BUMPER LPO 1512/55	TATA spare parts
88638800016	DASH BOARD	TATA spare parts
88638800017	FRONT BUMPER LCV S-FACIA	TATA spare parts
88638800018	REAR BUMPER FRP MTS BS4	TATA spare parts
88638800019	FRONT BUMPER - MTS BS6	TATA spare parts
88638800020	REAR BUMPER - MTS BS6	TATA spare parts
88638800021	FRONT GRILL HINGE LH BS6	TATA spare parts
88638800022	FRONT GRILL HINGE RH BS6	TATA spare parts
88638800023	REAR BUMPER (LH) BS6	TATA spare parts
88638800024	REAR BUMPER (RH) BS6	TATA spare parts
88638800025	ENGINE HOOD BS6	TATA spare parts
88638800026	REAR BUMPER METAL BS6	TATA spare parts
88638800027	REAR BUMPER (LH) BS6	TATA spare parts
88638800028	REAR BUMPER (RH) BS6	TATA spare parts
88638800029	REAR BUMPER BS6	TATA spare parts
88638800030	REAR BUMPER BS6	TATA spare parts
88638800031	FRONT BUMPER - MTS BS6	TATA spare parts
88638800032	FRONT GRILL HINGE LH BS6	TATA spare parts
88638800033	FRONT GRILL HINGE RH BS6	TATA spare parts
88638800034	FRONT BUMPER FRP	TATA spare parts
886388800001	HYVA MUD FLAP	TATA spare parts
886388810001	FRONT BUMPER FRP	TATA spare parts
886388960001	BUMPER BLADE LH	TATA spare parts
886388960002	BUMPER BLADE RH	TATA spare parts
886388960003	REAR BUMPER	TATA spare parts
886388960004	LOCK	TATA spare parts
886388960005	CATCHER	TATA spare parts
886388960006	FRP FRONT BUMPER	TATA spare parts
886388960007	FRP REAR BUMPER	TATA spare parts
886388960008	FRONT BUMPER ASSEMBLY	TATA spare parts
886388960009	SIDE BLADE (BUMPER)	TATA spare parts
886388960010	CENTRE PIECE (BUMPER)	TATA spare parts
886388960011	SIDE BLADE (BUMPER)	TATA spare parts
886388960012	F.R.P. FRONT BUMPER	TATA spare parts
886388960013	FRONT FENDER ASSY-RHS	TATA spare parts
886388960014	FRONT INSPECTION LID	TATA spare parts
886388960015	ENGINE HOOD	TATA spare parts
886388960016	PODEST	TATA spare parts
886388960017	DASHBOARD COMPLETE	TATA spare parts
886388960018	DASHBOARD GLOW BOX	TATA spare parts
886388960019	GLOW BOX FLAP	TATA spare parts

886388960020	VINYL BROWN 1.5MM-WIDTH=1500	TATA spare parts
886388960021	STICKRING SET-10.2 ULTRA SKOOL	TATA spare parts
886388960022	REAR BUMPER ASSEMBLY	TATA spare parts
886388960023	BRACKET LH	TATA spare parts
886388960024	BRACKET RH	TATA spare parts
886388960025	FRP REAR BUMPER COMPLETE	TATA spare parts
886388960026	ENGIN HOOD BEADING FOR 6HD (L=6MTR)	TATA spare parts
886388960027	FRONT BUMPER ASSY(METALALIC)	TATA spare parts
886388960028	REAR BUMPER COMPLETE (METALLIC)	TATA spare parts
886388960029	REAR FRP PANEL	TATA spare parts
886388960030	FRP ENGINE HOOD ASSY	TATA spare parts
886388960031	FRP ENGINEHOOD FOR 407 BS3	TATA spare parts
886388960032	REAR FRP STRUCTURE ASSEMBLY	TATA spare parts
886388960033	REAR BUMPER COMPLETE	TATA spare parts
886388960034	REAR BUMPER CORNER (LH)	TATA spare parts
886388960035	REAR BUMPER CORNER (RH)	TATA spare parts
886388960036	FRONT BOMPER ASSY	TATA spare parts
886388960037	FRP END BLADE(RE-SLF/LH)	TATA spare parts
886388960038	FRP END BLADE(RE-SLF-RH)	TATA spare parts
886388960039	FRP CENTER PEICE(RE-SLF)	TATA spare parts
886389000001	ASSY PUMP OPERATING LEVER	TATA spare parts
886391000001	DRIVER SEAT BELT	TATA spare parts
886391000002	RH SIDE PASSENGER SEAT	TATA spare parts
886391000003	LH SIDE PASSENGER SEAT	TATA spare parts
886391000004	REAR DIGGY MOUNTED 3 SEATER SEAT	TATA spare parts
886391000005	REAR DIGGY MOUNTED 2 SEATER SEAT	TATA spare parts
886391000006	FOLDING STRECHER	TATA spare parts
886391000007	PASSENGER SEAT SFC 407 19 SEATER	TATA spare parts
886391000008	SEAT - DRIVER & CO-DRIVER (WITHOUT SEAT	TATA spare parts
886391000009	RETRACTABLE SEAT BELT OF TMML (275491500	TATA spare parts
886391000010	RETRACTABLE SEAT BELT OF TMML (275491500	TATA spare parts
886391000011	BERTH SEAT 1625 MM X 525 MM (WITH FR CUS	TATA spare parts
886391000012	BERTH SEAT 675 MM X 525 MM (WITH FR CUSH	TATA spare parts
886391000013	BERTH SEAT 2085 MM X 445 MM (WITH FR CUS	TATA spare parts
886391000014	DRIVER SEAT	TATA spare parts
886391000015	ASSY SHELL LPO 1924	TATA spare parts
886391000016	SINGLE SEATER BS6	TATA spare parts
886391000017	TWO SEATER BS6	TATA spare parts
886391000018	THREE SEATER BS6	TATA spare parts
886391000019	ASSY SUSPENSION MECH	TATA spare parts
886391000020	SEAT DAMPER	TATA spare parts
886391000021	DRIVER SEAT MECHANISM EV	TATA spare parts
886391000022	3 SEATER BS6	TATA spare parts
886391000023	3 SEATER RH RAIL BS6	TATA spare parts
886391000024	3 SEATER RH HUMP BS6	TATA spare parts
886391000025	2 SEATER LH BS6	TATA spare parts
886391000026	2 SEATER LH HUMP BS6	TATA spare parts



886391000027	CO-DR SINGLE SEAT LH ARM BS6	TATA spare parts
886391000028	4 SEATER REAR BS6	TATA spare parts
886391000029	13 SEATER BENCH-LH BS6	TATA spare parts
886391000030	13 SEATER BENCH-RH BS6	TATA spare parts
886391000031	2 SEATER BENCH-LH BS6	TATA spare parts
886391000032	2 SEATER BENCH-RH BS6	TATA spare parts
886391000033	SINGLE SEAT LH 2LEG WITH ARMREST & LAPBE	TATA spare parts
886391000034	CO-DR SINGLE SEAT BS6	TATA spare parts
886391000035	PASSENGER SEAT HB 3 SEATER(3LEG) BS6	TATA spare parts
886391000036	PASSENGER SEAT HB 2 SEATER -RH FINDER BS	TATA spare parts
886391000037	PASSENGER SEAT HB 2 SEATER (HUMP)-RH FIN	TATA spare parts
886391000038	PASSENGER SEAT HB 2 SEATER -RH (WITH LEG	TATA spare parts
886391000039	PASSENGER SEAT HB 2 SEATER -LH FINDER BS	TATA spare parts
886391000040	PASSENGER SEAT HB 2 SEATER (HUMP)-LH FIN	TATA spare parts
886391000041	PASSENGER SEAT HB 2 SEATER BS6	TATA spare parts
886391000042	SINGLE SEAT WITH BELT BS6	TATA spare parts
886391000043	CO-DR SINGLE SEAT LH ARM-PART6 BS6	TATA spare parts
886391000044	FOLDABLE BENCH BS6	TATA spare parts
886391000045	BENCH SEAT BS6	TATA spare parts
886391000046	PASSENGER SEAT HB 2 SEATER BS6	TATA spare parts
886391000047	PASSENGER SEAT HB 2 SEATER BS6	TATA spare parts
886391000048	PASSENGER SEAT HB 3 SEATER BS6	TATA spare parts
886391000049	PASSENGER SEAT HB 3 SEATER BS6	TATA spare parts
886391000050	PASSENGER SEAT HB 3 SEATER BS6	TATA spare parts
886391000051	10 SEATER BENCH BS6	TATA spare parts
886391000052	9 SEATER BENCH BS6	TATA spare parts
886391000053	9 SEATER BENCH-LH BS6	TATA spare parts
886391000054	9 SEATER BENCH-RH BS6	TATA spare parts
886391000055	2 SEATER BENCH-LH BS6	TATA spare parts
886391000056	2 SEATER BENCH-RH BS6	TATA spare parts
886391000057	DOCTOR SEAT BS6	TATA spare parts
886391000058	8 SEATER BENCH BS6	TATA spare parts
886391000059	7 SEATER BENCH BS6	TATA spare parts
886391000060	CO DRIVER SEATS BS6	TATA spare parts
886391000061	PASSENGER SEAT HB 2SEATER(2LEG) BS6	TATA spare parts
886391000062	10SEATER BENCH BS6	TATA spare parts
886391000063	9 SEATER BENCH BS6	TATA spare parts
886391000064	CO-DRIVER FOOT STEP BS6	TATA spare parts
886391960001	SEAT ASSY. (1)	TATA spare parts
886391960002	SEAT ASSY. (3)	TATA spare parts
886391960003	SEAT ASSY(HBACK-3S-1215MM)	TATA spare parts
886391960004	SEAT ASSY (2S - LH+HEADREST FLAP)	TATA spare parts
886391960005	SEAT ASSY (2S - RH+HEADREST FLAP)	TATA spare parts
886391960006	SEAT ASY(5S -MID. SEAT W/BELT+HEADRST FL	TATA spare parts
886391960007	SEAT ASSY (2S - LH +BELT+HEADREST FLAP)	TATA spare parts
886391960008	SEAT ASSY (2S- RH +BELT+HEADREST FLAP)	TATA spare parts
886391960009	CO DRIVER SEAT INSTALLATION	TATA spare parts

886391960010	DRIVERS SEAT ASSEMBLY	TATA spare parts
886391960011	SEAT ASSY (3)	TATA spare parts
886391960012	SEAT ASSY (3)	TATA spare parts
886391960013	SEAT ASSY (2)	TATA spare parts
886391960014	SEAT ASSY (2)	TATA spare parts
886391960015	SEAT ASSY (3)	TATA spare parts
886391960016	SEAT ASSY (3)	TATA spare parts
886391960017	SEAT ASSY (3)(FLOOR MOUNTED)	TATA spare parts
886391960018	DRIVER SEAT ASSY	TATA spare parts
886391960019	SEAT ASSY	TATA spare parts
886391960020	2POINT LAP SEAT BELT	TATA spare parts
886391960021	BUSH	TATA spare parts
886391960022	SEAT ASSY (3)	TATA spare parts
886391960023	SEAT ASSY (3)	TATA spare parts
886391960024	SEAT ASSY (2)	TATA spare parts
886391960025	SEAT ASSY (2)	TATA spare parts
886391960026	SEAT ASSY (3)	TATA spare parts
886391960027	SEAT ASSY (3)	TATA spare parts
886391960028	SEAT BELT ¿DRIVER SEAT	TATA spare parts
886391960029	SEAT BELT PASSENGER SEAT	TATA spare parts
886391960030	SEAT ASSY(ORD-6 SEATER-LOW FOAM)	TATA spare parts
886391960031	SEAT ASSY(ORD-3SEATER-1000MM-LOW FOAM)	TATA spare parts
886391960032	SEAT ASSY(ORD-3SEATER-1000MM-LOW FOAM)	TATA spare parts
886391960033	SEAT ASSY.(6)	TATA spare parts
886391960034	SEAT ASSY.(2) /LH	TATA spare parts
886391960035	SEAT ASSY.(2) /RH	TATA spare parts
886391960036	SEAT ASSY.(5)	TATA spare parts
886391960037	SEAT ASSY.(2) /LH	TATA spare parts
886391960038	SEAT ASSY.(2) /RH	TATA spare parts
886391960039	DRIVER'S SEAT	TATA spare parts
886391960040	DRIVER SEAT ASSY	TATA spare parts
886391960041	SEAT SSEMBLY(2)	TATA spare parts
886391960042	SEAT SSEMBLY(2)	TATA spare parts
886391960043	SEAT SSEMBLY(1)	TATA spare parts
886391960044	SEAT SSEMBLY(1)	TATA spare parts
886391960045	SEAT SSEMBLY(2)	TATA spare parts
886391960046	SEAT SSEMBLY(2)	TATA spare parts
886391960047	SEAT SSEMBLY(1)	TATA spare parts
886391960048	SEAT SSEMBLY(1)	TATA spare parts
886391960049	SEAT ASSY (2)	TATA spare parts
886391960050	SUSPENED SEAT WITH HEADREST	TATA spare parts
886391960051	SEAT ASSY (3STR-HBK-LHD+SEAT BELT)	TATA spare parts
886391960052	SEAT ASSY (3STR - HBK)	TATA spare parts
886391960053	SEAT ASSY (1STR-HBK+SEAT BELT)	TATA spare parts
886391960054	SEAT ASSY (2STR-HBK+SEAT BELT)	TATA spare parts
886391960055	SEAT ASSY (3STR-HBK+SEAT BELT)	TATA spare parts
886391960056	SEAT ASSY (3STR-HBK+SEAT BELT)	TATA spare parts

886391960057	DRIVER SEAT COVER IN BLUE COLOR	TATA spare parts
886391960058	PASSENGER SEAT COVER	TATA spare parts
886391960059	DRIVER SEAT COVER	TATA spare parts
886391960060	SEAT ASSY. (3)	TATA spare parts
886391960061	SEAT ASSY. (3)	TATA spare parts
886391960062	SEAT ASSY. (3)	TATA spare parts
886391960063	SEAT ASSY. (2)	TATA spare parts
886391960064	SEAT ASSY. (2)	TATA spare parts
886391960065	SEAT ASSY. (1)	TATA spare parts
886391960066	SEAT ASSY. (3)	TATA spare parts
886391960067	SEAT ASSY. (3)	TATA spare parts
886391960068	SEAT ASSY (2S) + ARMREST	TATA spare parts
886391960069	SEAT ASSY (2S)	TATA spare parts
886391960070	SEAT ASSY (2S)	TATA spare parts
886391960071	SEAT ASSY (5S)	TATA spare parts
886391960072	SEAT ASSY (2S)	TATA spare parts
886391960073	SEAT ASSY (2S)	TATA spare parts
886391960074	SEAT ASSY (1S)+ARMREST+BELT	TATA spare parts
886391960075	SEAT ASSY(3)	TATA spare parts
886391960076	SEAT ASSY 3S	TATA spare parts
886391960077	SEAT ASSY 3 S	TATA spare parts
886391960078	SEAT ASSY 3S	TATA spare parts
886391960079	SEAT ASSY 2S	TATA spare parts
886391960080	SEAT ASSY 2S	TATA spare parts
886391960081	SEAT ASSY 2S	TATA spare parts
886391960082	SEAT ASSY 3S	TATA spare parts
886391960083	SEAT ASSY 1S	TATA spare parts
886391960084	SEAT ASSY 3S	TATA spare parts
886391960085	SEAT ASSY 3S	TATA spare parts
886391960086	SEAT ASSY 1S HBK FLR MOUNTED +A REST+ BE	TATA spare parts
886391960087	SEAT ASSY 2S HBK FLR MOUNTED +A REST+ BE	TATA spare parts
886391960088	SEAT ASSY 3S HBK FLR MOUNTED + BELT	TATA spare parts
886391960089	SEAT ASSY 3S HBK FLR MOUNTED +A REST+ BE	TATA spare parts
886391960090	SEAT ASSY (1) JUMP SEAT	TATA spare parts
886391960091	SEAT ASSY 2S HBK FLR MOUNTED +A REST+ BE	TATA spare parts
886391960092	SEAT ASSY 3S HBK FLR MOUNTED + BELT	TATA spare parts
886391960093	SEAT ASSY 3S HBK FLR MOUNTED + BELT	TATA spare parts
886391960094	SEAT ASSY(HIGHBACK-2SEAT+ARM REST)	TATA spare parts
886391960095	SEAT ASSY(HBACK-2S-775MM+BELT+ARM-V.EG)	TATA spare parts
886391960096	SEAT ASSY(HBACK-2S-775MM+BELT-V.ENGG)	TATA spare parts
886391960097	SEAT ASSY(HBACK-3S-1170MM+BELT+ARM-V.EG)	TATA spare parts
886391960098	SEAT ASSY(HBACK-3S-1170MM+BELT-V.ENGG)	TATA spare parts
886391960101	SEAT ASSY (CHILDREN-2-SEATER-MOD)	TATA spare parts
886391960102	CHILDREN SEAT(3-SEATER)	TATA spare parts
886391960103	SEAT ASSY (CHILDREN-3-SEATER-MOD)	TATA spare parts
886391960104	SEAT ASSY (CHILDREN-3-SEATER-MOD-BELT)	TATA spare parts
886391960105	SEAT ASSY (2S)	TATA spare parts

886391960106	SEAT ASSY (2S)	TATA spare parts
886391960107	SEAT ASSY 2 S FLR MOUNTED	TATA spare parts
886391960108	SEAT ASSY 2S	TATA spare parts
886391960109	SEAT ASSY. 6 STR (W/OUT BACKREST)	TATA spare parts
886391960110	SEAT ASSY (3 STR-ARMREST+SEAT BELT)	TATA spare parts
886391960111	SEAT ASSY 3S	TATA spare parts
886391960112	SEAT ASSY 3S FLR MOUNTED	TATA spare parts
886391960113	SEAT ASSY 1S	TATA spare parts
886391960114	SEAT ASSY(2 STR-ARM REST+LAP BELT)	TATA spare parts
886391960115	SEAT ASSY 3S FLR MOUNTED	TATA spare parts
886391960116	SEAT ASSY (2 STR-ARMREST+SEAT BELT)	TATA spare parts
886391960117	SEAT ASSY 3S	TATA spare parts
886391960118	SEAT ASSY. 6 STR (W/OUT B+J69ACKREST)	TATA spare parts
886391960119	SEAT ASSY(1S)	TATA spare parts
886391960120	SEAT ASSY (2S)	TATA spare parts
886391960121	SEAT ASSY (2S)	TATA spare parts
886391960122	SEAT ASSY (2S)	TATA spare parts
886391960123	SEAT ASSY (2S)	TATA spare parts
886391960124	SEAT ASSY (1S)	TATA spare parts
886391960125	DRV.SEAT WITH HDREST RH	TATA spare parts
886391960126	FOLDING SEAT(3)	TATA spare parts
886391960127	SEAT ASSEMBLY 2 SEATER	TATA spare parts
886391960128	SEAT ASSY (2 SEATER)	TATA spare parts
886391960129	SEAT ASSY (2 SEATER)	TATA spare parts
886391960130	SEAT ASSY¿ SKOOL 3S FLR MOUNTED	TATA spare parts
886391960131	SEAT ASSY¿ SKOOL 3S FLR MOUNTED	TATA spare parts
886391960132	SEAT ASSY¿ SKOOL 3S FLR MOUNTED	TATA spare parts
886391960133	SEAT ASSY 1S FLR MOUNTED	TATA spare parts
886391960134	SEAT ASSY¿ SKOOL 3S FLR MOUNTED	TATA spare parts
886391960135	SEAT ASSY 3S	TATA spare parts
886391960136	SEAT ASSY 3S	TATA spare parts
886391960137	SEAT ASSY 3S	TATA spare parts
886391960138	SEAT ASSY 6S	TATA spare parts
886391960139	SEAT ASSY 3S	TATA spare parts
886391960140	SEAT ASSY 2S	TATA spare parts
886391960141	SEAT ASSY 2S	TATA spare parts
886391960142	SEAT ASSEMBLY (2 SEATER)	TATA spare parts
886391960143	SEAT ASSEMBLY 2S	TATA spare parts
886391960144	SEAT ASSY 3S - HBK SKOOL FLR MNTD	TATA spare parts
886391960145	SEAT ASSY 3S - HBK SKOOL FLR MNTD	TATA spare parts
886391960146	SEAT ASSY 1S - HBK SKOOL FLR MNTD	TATA spare parts
886391960147	SEAT ASSY 2S - HBK SKOOL FLR MNTD	TATA spare parts
886391960148	SEAT ASSY 2S - HBK SKOOL FLR MNTD	TATA spare parts
886391960149	SEAT ASSY 1S - HBK SKOOL FLR MNTD	TATA spare parts
886391960150	SEAT ASSY 2S HBK FLR MOUNTED	TATA spare parts
886391960151	SEAT ASSY 2S HBK FLR MOUNTED	TATA spare parts
886391960152	SEAT ASSY 3S HBK FLR MOUNTED	TATA spare parts

886391960153	SEAT ASSY 3S HBK FLR MOUNTED	TATA spare parts
886391960154	SEAT ASSY 3S HBK FLR MOUNTED	TATA spare parts
886391960155	SEAT ASSY (3)	TATA spare parts
886391960156	SEAT ASSY (2)	TATA spare parts
886391960157	SEAT ASSY (3)	TATA spare parts
886391960158	SEAT ASSY (2)	TATA spare parts
886391960159	SEAT ASSY (1 SEATER-LH)	TATA spare parts
886391960160	SEAT ASSY (2 SEATER-LH)	TATA spare parts
886391960161	SEAT ASSY (2 SEATER-RH)	TATA spare parts
886391960162	LH 2 SEATER RAIL MTG & FL MTG W/O ARMRES	TATA spare parts
886391960163	SEAT ASSY (2 SEATER-LH REAR)	TATA spare parts
886391960164	SEAT ASSY (1 SEATER-CENTER LAST)	TATA spare parts
886391960165	SEAT ASSY (2 SEATER-RH REAR)	TATA spare parts
886391960166	RH 2 SEATER RAIL MTG & FL MTG W/O ARMRES	TATA spare parts
886391960167	RH 2 SEATER WITH BRACKET MTG & ARMREST (	TATA spare parts
886391960168	SEAT ASSY (2 SEATER-LH+RH)	TATA spare parts
886391960169	RH 2 SEATER 2 LEG WITH ARMREST	TATA spare parts
886391960170	SEAT ASSY (2 SEATER-RH REAR)	TATA spare parts
886391960171	LH 2 SEATER 2 LEG WITH ARMREST	TATA spare parts
886391960172	FOLDING SEAT LOCK-LH	TATA spare parts
886391960173	FOLDING SEAT LOCK-RH	TATA spare parts
886391960174	SEAT ASSY(HBACK-3S-1170MM+BELT-V.ENG)	TATA spare parts
886391960175	SEAT ASSY(HBACK-2S-775MM-BELT-V.ENG)	TATA spare parts
886391960176	SEAT ASSY(PINNACLE-HBACK-3SEATER-BH-SEAT	TATA spare parts
886391960177	2 SEATER SEAT ASSEMBLY LH	TATA spare parts
886391960178	2 SEATER SEAT ASSEMBLY RH	TATA spare parts
886391960179	1 SEATER SEAT ASSEMBLY	TATA spare parts
886391960180	2 SEATER SEAT ASSEMBLY REAR LH	TATA spare parts
886391960181	SEAT ASSY 2Sç FRT WHL HSG	TATA spare parts
886391960182	SEAT ASSY 2S RH SIDE	TATA spare parts
886391960183	SEAT ASSY 2S FLR MNTNG	TATA spare parts
886391960184	SEAT ASSY 2S WITH LEGS	TATA spare parts
886391960185	SEAT ASSY 2Sç LH SIDE	TATA spare parts
886391960186	SEAT ASSY 2Sç RH SIDE	TATA spare parts
886391960187	SEAT ASSY 2S LH SIDE	TATA spare parts
886391960188	SEAT ASSY 2S RH - EM DOOR	TATA spare parts
886391960189	SEAT ASSY 1S LHç WHL HSG	TATA spare parts
886391960190	SEAT ASSY 2S	TATA spare parts
886391960191	ARMç REST	TATA spare parts
886392960001	SEAT ASSY (2)	TATA spare parts
886392960002	SEAT ASSY (2)	TATA spare parts
886392960003	SEAT ASSY (2)	TATA spare parts
886393000001	BEDLINER XENON	TATA spare parts
886394000001	CO-DRIVER SEAT	TATA spare parts
886397960001	2 POINT LAP BELT OF PASSENGER SEAT	TATA spare parts
886397960002	SWIVELLING ARMREST ASSY LH WITH BRACKET	TATA spare parts
886397960003	SWIVELLING ARMREST ASSY RH WITH BRACKET	TATA spare parts

886398000001	FIRE EXTINGUISHER ABC TYPE	TATA spare parts
886398000002	SEAT BELT	TATA spare parts
886398000003	DUSTBIN	TATA spare parts
886398000004	AUTOLOADING STRECHER MEBER	TATA spare parts
886398000005	IV HOOKS	TATA spare parts
886398000006	ROOF BOOTLE HOOKS	TATA spare parts
886398000007	TISSUE DISPENSER	TATA spare parts
886398000008	MEDICAL BINS SET (06PCS)	TATA spare parts
886398000009	GRAB HANDLE	TATA spare parts
886398000010	HYDRAULLIC SHOCKER	TATA spare parts
886398000011	BIN LOCK	TATA spare parts
886398000012	HATRACK FRAME	TATA spare parts
886398000013	OXYGEN DELIVERY SYSTEM	TATA spare parts
886398000014	REGULATOR	TATA spare parts
886398000015	RAMP PLATE SET	TATA spare parts
886398000016	B-TYPE OXYGEN MOUNT	TATA spare parts
886398000017	DRAWER LOCK	TATA spare parts
886398000018	D-HANDLE	TATA spare parts
886398000019	EMT SEAT	TATA spare parts
886398000020	PARTITION WINDOW GLASS FRAME ASSEMBLY	TATA spare parts
886398000021	FIRE CYLINDER	TATA spare parts
886398000022	SEAT BELTS	TATA spare parts
886398000023	DUSTBIN	TATA spare parts
886398000024	STRECHER WITH LOCKING ARRANGEMENT	TATA spare parts
886398000025	IV HOOKS	TATA spare parts
886398000026	ROOF BOOTLE HOOKS	TATA spare parts
886398000027	TISSUE DISPENSER	TATA spare parts
886398000028	BINS SET (06PCS)	TATA spare parts
886398000029	GRAB HANDLE	TATA spare parts
886398000030	HYDRAULLIC SHOCKERS	TATA spare parts
886398000031	BIN LOCK	TATA spare parts
886398000032	HATRACK FRAME	TATA spare parts
886398000033	OXYGEN DELIVERY SYSTEM	TATA spare parts
886398000034	REGULATOR	TATA spare parts
886398000035	RAMP PLATE SET	TATA spare parts
886398000036	DRAWER LOCK	TATA spare parts
886398000037	D-HANDLE	TATA spare parts
886398000038	EMT SEAT	TATA spare parts
886398000039	PARTITION WINDOW GLASS FRAME ASSEMBLY	TATA spare parts
886398000040	FIRE CYLINDER	TATA spare parts
886398000041	SEAT BELTS	TATA spare parts
886398000042	DUSTBIN	TATA spare parts
886398000043	STRECHER WITH LOCKING ARRANGEMENT	TATA spare parts
886398000044	IV HOOKS	TATA spare parts
886398000045	ROOF BOOTLE HOOKS	TATA spare parts
886398000046	TISSUE DISPENSER	TATA spare parts
886398000047	BINS SET (06PCS)	TATA spare parts

886398000048	GRAB HANDLE	TATA spare parts
886398000049	HYDRAULLIC SHOCKERS	TATA spare parts
886398000050	BIN LOCK	TATA spare parts
886398000051	HATRACK FRAME	TATA spare parts
886398000052	OXYGEN DELIVERY SYSTEM	TATA spare parts
886398000053	REGULATOR	TATA spare parts
886398000054	RAMP PLATE SET	TATA spare parts
886398000055	DRAWER LOCK	TATA spare parts
886398000056	D-HANDLE	TATA spare parts
886398000057	EMT SEAT	TATA spare parts
886398000058	PARTITION WINDOW GLASS FRAME ASSEMBLY	TATA spare parts
886398000059	REGULATOR ADOPTER	TATA spare parts
886398000060	8 LED BLINKERS LH REAR/RH FRONT (BLUE CO	TATA spare parts
886398000061	8 LED BLINKERS REAR LH (RED AMBERCOLOUR)	TATA spare parts
886398000062	8 LED BLINKERS REAR RH(BLUE AMBER COLOUR	TATA spare parts
886398000063	OXYGEN REGULATOR (B-TYPE CYLINDER)	TATA spare parts
886398000064	SYRINGE PUMP ROD	TATA spare parts
886398000065	PATIENT CABIN LH PANNEL	TATA spare parts
886398000066	PATIENT CABIN RH PANNEL	TATA spare parts
886398000067	PATEINT CABIN ROOF PANNEL	TATA spare parts
886398000068	PATIENT CABIN PARTION WALL PANNEL	TATA spare parts
886398000069	PARTION WINDOW FRP RING	TATA spare parts
886398000070	CABINET FRP TRAY	TATA spare parts
886398000071	WHEEL HUMP FRP TRAY	TATA spare parts
886398000072	STRECHER FRP PLATFORM ASSEMBLY	TATA spare parts
886398000073	PATIENT CABIN VINYL ASSEMBLY	TATA spare parts
886398000074	PATIENT CABIN LH ALLUMINIUM STRIP	TATA spare parts
886398000075	PATIENT CABIN RH ALLUMINIUM STRIP	TATA spare parts
886398000076	PATIENT CABIN LH ALLUMINIUM COVER STRIP	TATA spare parts
886398000077	PATIENT CABIN RH ALLUMINIUM COVER STRIP	TATA spare parts
886398000078	6- MODULAR SWITCH BOARD ASSEMBLY	TATA spare parts
886398000079	8- MODULAR SWITCH BOARD ASSEMBLY	TATA spare parts
886398000080	PATIENT CABIN AC SUCTION GRILL	TATA spare parts
8863980000801	CABINET CHANNEL	TATA spare parts
886398000082	REAR DOOR GRAB HANDLE	TATA spare parts
886398000083	DRIVER CABIN 4LED BLINKER FRP COVER	TATA spare parts
886398000084	WORK LAMP FRP COVER	TATA spare parts
886398000085	EXTERNAL POWER SOCKET FRP COVER	TATA spare parts
886398000086	SINGLE D-TYPE CYLINDER TROLLEY ASSEMBLY	TATA spare parts
886398000087	SINGLE D-TYPE CYLINDER DOOR ASSEMBLY	TATA spare parts
886398000088	CYLINDER DOOR HINGE	TATA spare parts
886398000089	DRIVER CABIN PARTION WALL FRP	TATA spare parts
886398000090	DRIVER CABIN AC COVER FRP	TATA spare parts
886398000091	AMPLIFIER FRP COVER	TATA spare parts
886398000092	DRIVER CABIN ROOF PANNEL ASSEMBLY	TATA spare parts
886398000093	ATTENDANT SEAT FRP ASSEMBLY	TATA spare parts
886398000094	GLUCOSE BOTTLE STAND FRP COVER	TATA spare parts

886398000095	ATTENDANT SEAT ASSEMBLY	TATA spare parts
886398000096	ATTENDANT SEAT BACK REST	TATA spare parts
886398000097	DUSTBIN FRP DOOR	TATA spare parts
886398000098	PATIENT CABIN FRP BLOWER COVER	TATA spare parts
886398000099	PATIENT LIGHT FRP COVER	TATA spare parts
886398000100	EMERGENCY LIGHT BAR DIAPHRAGM	TATA spare parts
886398000101	DRIVER CABIN LH PILLAR PANNEL	TATA spare parts
886398000102	DRIVER CABIN RH PILLAR PANNEL	TATA spare parts
886398000103	MEDICAL BIN CABINET WITHOUT MEDICAL BINS	TATA spare parts
886398000104	CABINET WITH DRAWERS	TATA spare parts
886398000105	RUBBER HOSE WIRE BRAIDED	TATA spare parts
886398000106	REDUCER 2-3 INCH	TATA spare parts
886398000107	ELBOW 2INCH	TATA spare parts
886398000108	CLAMP DIA 8 X 65 X 115	TATA spare parts
886398000109	CLAMP DIA 8 X 95 X 135MM	TATA spare parts
886398000110	16 MM BULKER O RING	TATA spare parts
886398000111	LOCKING PIN DIA 16 X 80 MM LENGTH	TATA spare parts
886398000112	GASKET 250 X 145	TATA spare parts
886398000113	GASKET 180 X 92	TATA spare parts
886398000114	MANHOLE LOCKING PIN DIA 16 X 65 MM LENGT	TATA spare parts
886398000115	SPLIT PIN 5/32 X 2INCH	TATA spare parts
886398000116	LANDING GEAR 2 SPEED - FUWA (5002-02-02)	TATA spare parts
886398000117	BRAKE CHAMBER T24 - FUWA	TATA spare parts
886398000118	PNEUMATIC BRAKE KIT WITH BCS-3A (WABCO)	TATA spare parts
886398000119	LED REAR INDICATOR LIGHT-FOUR CHAMBER (2	TATA spare parts
886398000120	D - RUPD RUBBER CAP (LH & RH)	TATA spare parts
886398000121	WIRE HARNESS 40 CUM TRAILER BULKER	TATA spare parts
886398000122	ELECTRICAL SOCKET 7 PIN	TATA spare parts
886398000123	KING PIN 2INCH	TATA spare parts
886398000124	AXLE SQUARE 13 TON 1840 WT BRAKE SIZE	TATA spare parts
886398000125	SUSPENSION TRIPLE AXLE 13T - FUWA (FW 88	TATA spare parts
886398000126	SPRING BLADE ASSEMBLY - 9 LEAF (FUWA) -	TATA spare parts
886398000127	ELBOW SR 3INCH 75NB SCHEDULE 20	TATA spare parts
886398000128	LOCKABLE GAS PISTON	TATA spare parts
886398000129	ADJUSTMENT SYSTEM FOR BACKREST	TATA spare parts
886398000130	OXYGEN REGULATOR FRP COVER	TATA spare parts
886398000131	BIN SHUTTER	TATA spare parts
886398000132	RUBBER WHEEL	TATA spare parts
886398000133	BLACK VERTICAL LEG SLIDE	TATA spare parts
886398000134	SHORT VERTICAL LEG SLIDE	TATA spare parts
886398000135	WHEEL 200M	TATA spare parts
886398000136	LEFT LATERAL RAIL UNIT	TATA spare parts
886398000137	RIGHT LATERAL RAIL UNIT	TATA spare parts
886398000138	THREAD ADJUSTABLE BLOCK FOR EVOX PROOFi	TATA spare parts
886398000139	BACKREST BLOCKABLE GAS SPRING	TATA spare parts
886398000140	BACKREST ADJUSTMENT UNIT	TATA spare parts
886398000141	HIGH PRESSURE OXYGEN PIPE	TATA spare parts



886398000142	SS BRADED HIGH PRESSURE OXYGEN CYLLINDER	TATA spare parts
886398000143	SS BRADED HIGH PRESSURE OXYGEN CYLLINDER	TATA spare parts
886398012518	KIT - SEAT BERTH-MHCV NON SLPR CAB	TATA spare parts
886398022518	DRIVER SEAT BERTH RHS&MHCV NON SLPR CAB	TATA spare parts
886398032518	DRIVER SEAT BERTH LHS&MHCV NON SLPR CAB	TATA spare parts
886398042518	CENTRAL BERTH - MHCV NON SLPR CAB	TATA spare parts
886399000003	TATA GENUINE DEF 20 L (BUCKET)	TATA spare parts
886399000003EX	TATA GENUINE DEF 20 L (BUCKET)	TATA spare parts
886399000004	KITLRDEMRSLLPTA3138(8X8)	TATA spare parts
886399000005	ENGOILSAE 15W40 API CH4-210LT	TATA spare parts
886399000005AE	ENGOILSAE 15W40 API CH4-210LT	TATA spare parts
886399000006	ENGOILSAE 15W40 API CH4-20LT	TATA spare parts
886399000006AE	ENGOILSAE 15W40 API CH4-20LT	TATA spare parts
886399000007	GB OIL SAE 80W90 210LT	TATA spare parts
886399000007AE	GB OIL SAE 80W90 210LT	TATA spare parts
886399000008	GB EOIL SAE 80W90 20LT	TATA spare parts
886399000008AE	GB EOIL SAE 80W90 20LT	TATA spare parts
886399000009	FA SAE 85W140 WITH 7% AGL 210LT	TATA spare parts
886399000009AE	FA SAE 85W140 WITH 7% AGL 210LT	TATA spare parts
886399000010	FASAE 85W140 WITH 7% AGL 20LT	TATA spare parts
886399000010AE	FASAE 85W140 WITH 7% AGL 20LT	TATA spare parts
886399000011	RAD COOLANT CLASS 2 JIS-2234 210LT	TATA spare parts
886399000011AE	RAD COOLANT CLASS 2 JIS-2234 210LT	TATA spare parts
886399000012	RAD COOLANT CLASS 2 JIS-2234 20LT	TATA spare parts
886399000012AE	RAD COOLANT CLASS 2 JIS-2234 20LT	TATA spare parts
886399000013	STEERING OIL ATF DEXRON II D 210LT	TATA spare parts
886399000013AE	STEERING OIL ATF DEXRON II D 210LT	TATA spare parts
886399000014	STEERING OIL ATF DEXRON II D 20LT	TATA spare parts
886399000014AE	STEERING OIL ATF DEXRON II D 20LT	TATA spare parts
886399000015	HYD BRAKE FLUID HD DOT 3 210LT	TATA spare parts
886399000015AE	HYD BRAKE FLUID HD DOT 3 210LT	TATA spare parts
886399000016	HYD BRAKE FLUID HD DOT 3 20LT	TATA spare parts
886399000016AE	HYD BRAKE FLUID HD DOT 3 20LT	TATA spare parts
886399000017	TRCASEOIL SAE 80W90 210LT	TATA spare parts
886399000017AE	TRCASEOIL SAE 80W90 210LT	TATA spare parts
886399000018	TRCASEOIL SAE 80W90 20LT	TATA spare parts
886399000018AE	TRCASEOIL SAE 80W90 20LT	TATA spare parts
886399000019	RA SAE 85W140 WITH 7% AGL 210LT	TATA spare parts
886399000019AE	RA SAE 85W140 WITH 7% AGL 210LT	TATA spare parts
886399000020	RA SAE 85W140 WITH 7% AGL 210LT	TATA spare parts
886399000020AE	RA SAE 85W140 WITH 7% AGL 210LT	TATA spare parts
886399000021	SPECIAL GREASE 10 MG	TATA spare parts
886399000022	DEPAC 200 GM	TATA spare parts
886399000023	AUXILIARY ENGINE	TATA spare parts
886399000024	POWER PACK ENGINE	TATA spare parts
886399000025	POWER STEERING FLUID 500 ML	TATA spare parts
886399000026	POWER STEERING FLUID - 1 LITRE	TATA spare parts

886399000027	POWER STEERING FLUID -20 LITRES	TATA spare parts
886399000028	POWER STEERING FLUID - 210 LITRES	TATA spare parts
886399000029	BRAKE FLUID (DOT 3) - 250 ML	TATA spare parts
886399000030	BRAKE FLUID (DOT 3) - 500 ML	TATA spare parts
886399000031	BRAKE FLUID (DOT 4) - 250 ML	TATA spare parts
886399000032	BRAKE FLUID (DOT 4) - 500 ML	TATA spare parts
886399000033	METAL O SEAL - LIQUID GASKET MAKER 25 GM	TATA spare parts
886399000034	METAL O SEAL - LIQUID GASKET MAKER 85 GM	TATA spare parts
886399000035	METAL O SEAL PLUS PREMI GASKET MAKER 25G	TATA spare parts
886399000036	METAL O SEAL PLUS PREMI GASKET MAKER 85G	TATA spare parts
886399000037	Power Steering Fluid -50ml	TATA spare parts
886399000038	ROTARY TOOL KIT	TATA spare parts
886399000039	COOLANT 210 LITRE	TATA spare parts
886399000040	BRAKE FLUID (DOT 3) - 250 ML	TATA spare parts
886399000041	BRAKE FLUID (DOT 3) - 500 ML	TATA spare parts
886399000042	BRAKE FLUID (DOT 4) - 250 ML	TATA spare parts
886399000043	BRAKE FLUID (DOT 4) - 500 ML	TATA spare parts
886399000044	TATA GENUINE DEF 10 L	TATA spare parts
886399000045	TATA GENUINE D.E.F 200 L	TATA spare parts
886399000046	TATA GENUINE DEF 1 LITRE	TATA spare parts
886399000047	SPOUT FOR DEF IN BUCKETS	TATA spare parts
886399000048	TATA DEF 20L BAG IN BOX	TATA spare parts
886399000049	TATA GENUINE D.E.F 10 L BUCKET	TATA spare parts
886399000050	NANOCOATING SOLUTION_500 ML	TATA spare parts
886399000051	NANOCOATING SOLUTION_1 L	TATA spare parts
886399000052	NANOCOATING SOLUTION_5 L	TATA spare parts
886399000053	NANOCOATING SOLUTION_15 L	TATA spare parts
886399000054	PRECLEAN SOLUTION_1 L	TATA spare parts
886399000055	PRECLEAN SOLUTION_5 L	TATA spare parts
886399000056	PRECLEAN SOLUTION_15 L	TATA spare parts
886399000057	DEF 1000 LTR TANK	TATA spare parts
886399000058	DEF AUTO DISPENSING UNIT	TATA spare parts
886399000059	TATA GENUINE DEF 210 L	TATA spare parts
886399000060	PISTON PUMP FOR DEF DISPENSING	TATA spare parts
886399000061	8 LTR PLASTIC CAN FOR DEF	TATA spare parts
886399000062	5 LTR S.S. CAN FOR DEF	TATA spare parts
886399000063	TWO SEALED IBC WITH DEF 2KL	TATA spare parts
886399000064	1KL DEF REFILL	TATA spare parts
886399000065	TATA GENUINE D.E.F 1 MILLILITRE	TATA spare parts
886399000066	PNEUMATIC AIR FLOW GUN 310ML WINDSHIELD	TATA spare parts
886399000067	OPEN BARREL MANUAL GUN 310ML WINDSHIELD	TATA spare parts
886399000068	MAXICOOL PREMIX COOLANT 1 LTR	TATA spare parts
886399000069	MAXICOOL PREMIX COOLANT 3 LTR	TATA spare parts
886399000070	MAXICOOL PREMIX COOLANT 5 LTR	TATA spare parts
886399000071	MAXICOOL PREMIX COOLANT 210 LTR	TATA spare parts
886399000072	TATA GENUINE DEF 2 LTR	TATA spare parts
886399000073	TATA GENUINE DEF 5 LTR	TATA spare parts

886399000074	SPOUT FOR DEF IN JERRYCANS	TATA spare parts
886399000075	Gas Engine Oil 1 Ltr	TATA spare parts
886399000076	Front Hub Grease 100 Gms	TATA spare parts
886399000077	Chassis Grease 100 Gms	TATA spare parts
886399000078	Rear Axle Oil 1 Ltr	TATA spare parts
886399000079	Power Steering Oil 0.5 Ltr	TATA spare parts
886399000080	Transmission Oil 1 Ltr	TATA spare parts
886399000081	Engine Oil 15W40 CTU 1Ltr	TATA spare parts
886399000087	FRONT HUB GREASE EV BUS BEST 100 GMS	TATA spare parts
886399000088	REAR AXLE OIL 80W140 EV BUS BEST 1 LTR	TATA spare parts
886399000089	POWER STEERING OIL EV BUS BEST 0.5 LTR	TATA spare parts
886399000090	CUT SECTION-GEAR BOX GB40 DEMO KIT	TATA spare parts
886399000091	CUT SECTION-COOLING SYSTEM-TATA ACE	TATA spare parts
886399000092	CUT SECT-FUEL SYS CRDI (DSL) & MPFI (PET	TATA spare parts
886399000093	CUT SECTION-EGR AFFIXED AIR INTAKE SYSTE	TATA spare parts
886399000094	CUT SECTION-BS6 EXHAUST SYSTEM	TATA spare parts
886399000095	DEMO KIT - HVAC (PASSENGER CAR)	TATA spare parts
886399000096	CUT SECTION-ENGINE & TRANSMISSION MOUNTS	TATA spare parts
886399000097	DEMO KIT-ELECTRONIC IGNITION SYSTEM	TATA spare parts
886399000098	DEMO KIT - LIGHTING AND WIRING SYSTEM	TATA spare parts
886399000099	DEMO KIT - BOARD STARTING SYSTEM-MHCV	TATA spare parts
886399000100	DEMO KIT FOR CHARGING SYSTEM	TATA spare parts
886399000101	CUT SECTION-REAR AXLE (MHCV)	TATA spare parts
886399000102	DEMO KIT-COMMERCIAL VEHICLE CHASSIS FRAM	TATA spare parts
886399000103	DEMO KIT-SUSPENSION SYSTEM (MHCV)	TATA spare parts
886399000104	CUT SECTION-STEERING SYS & TYRES (MHCV)	TATA spare parts
886399000105	DEMO KIT-BRAKES & CONTROLS (CAR / LCV)	TATA spare parts
886399000106	CUT SECTION-ASSY. ENGINE CUMMINS 6BT BS3	TATA spare parts
886399000107	TATA GENUINE DEF 3 LTR	TATA spare parts
886399000108	DEF DISPENSING UNIT WITH AUTO CUT OFF NO	TATA spare parts
886399000109	TATA GENUINE DEF 10 LTR JERRY CAN	TATA spare parts
886399000110	TATA GENUINE DEF 10 LTR BAG IN BOX	TATA spare parts
886399000111	TATA GENUINE DEF 20 LTR JERRY CAN	TATA spare parts
886399000112	TATA DEF DISPENSER LM APPROVED	TATA spare parts
886399000113	ONE SEALED IBC WITH DEF 1KL	TATA spare parts
886399000114	ET-202 ELECTRONIC DIGITAL THEODOLITE	TATA spare parts
886399000115	DIGITAL TACHOMETER LASER NON-CONTACT 999	TATA spare parts
886399000116	NAVIGATION GPS ETREX¿¿ 22(GARMIN BRAND)	TATA spare parts
886399000117	TATA DEF DISPENSER LM APPRO V2	TATA spare parts
886399000118	DEF IBC REDUCER KIT ON BOTTOM VALVE	TATA spare parts
886399000119	TATA GENUINE D.E.F 10 ML (1 CENTILITRE)	TATA spare parts
886399000121	FRONT HUB GREASE EV BUS MKD 100 GMS	TATA spare parts
886399000122	REAR AXLE OIL 80W140 EV BUS MKD 1 LTR	TATA spare parts
886399000123	POWER STEERING OIL EV BUS MKD 0.5 LTR	TATA spare parts
886399000124	COOLANT EXTRA LONG LIFE 1 LTR BS6-PH2	TATA spare parts
886399000125	COOLANT EXTRA LONG LIFE 3 LTR BS6-PH2	TATA spare parts
886399000126	COOLANT EXTRA LONG LIFE 5 LTR BS6-PH2	TATA spare parts

886399000127	COOLANT EXTRA LONG LIFE 210 LTR BS6-PH2	TATA spare parts
886399012527	62.5KVA GENVOLTZ 3PH 497 DSL GENSET CPCB	TATA spare parts
886399012534	30KVA GENVOLTZ 3PH 4SP DSL GENSET CPCB2	TATA spare parts
886399015714	125KVA GENVOLTZ 3PH 697 DSL GENSET CPCB2	TATA spare parts
886399025714	82.5KV GENVOLTZ 3P 697 DSL MN WWC CPCB2	TATA spare parts
886399032527	35KV GENVOLTZ 3P 497 DSL MN WWC CPCB2	TATA spare parts
886399032534	25KV GENVOLTZ 3P 497SP DSL MN WWC CPCB2	TATA spare parts
886399035714	100KV GENVOLTZ 3P 697 DSL MN WWC CPCB2	TATA spare parts
886399042527	40KV GENVOLTZ 3P 497 DSL MN WWC CPCB2	TATA spare parts
886399042534	30KV GENVOLTZ 3P 497SP DSL MN WWC CPCB2	TATA spare parts
886399045714	125KV GENVOLTZ 3P 697 DSL MN WWC CPCB2	TATA spare parts
886399052527	50KV GENVOLTZ 3P 497 DSL MN WWC CPCB2	TATA spare parts
886399052534	35KV GENVOLTZ 3P 497SP DSL MN WWC CPCB2	TATA spare parts
886399055714	82.5KV GENVOLTZ 3P 697 DSL MN DSC CPCB2	TATA spare parts
886399062527	62.5KV GENVOLTZ 3P 497 DSL MN WWC CPCB2	TATA spare parts
886399062534	40KV GENVOLTZ 3P 497SP DSL MN WWC CPCB2	TATA spare parts
886399065714	100KV GENVOLTZ 3P 697 DSL MN DSC CPCB2	TATA spare parts
886399072527	35KV GENVOLTZ 3P 497 DSL MN DSC CPCB2	TATA spare parts
886399072534	25KV GENVOLTZ 3P 497SP DSL MN DSC CPCB2	TATA spare parts
886399075714	125KV GENVOLTZ 3P 697 DSL MN DSC CPCB2	TATA spare parts
886399082527	40KV GENVOLTZ 3P 497 DSL MN DSC CPCB2	TATA spare parts
886399082534	30KV GENVOLTZ 3P 497SP DSL MN DSC CPCB2	TATA spare parts
886399092527	50KV GENVOLTZ 3P 497 DSL MN DSC CPCB2	TATA spare parts
886399092534	35KV GENVOLTZ 3P 497SP DSL MN DSC CPCB2	TATA spare parts
886399102527	62.5KV GENVOLTZ 3P 497 DSL MN DSC CPCB2	TATA spare parts
886399102534	40KV GENVOLTZ 3P 497SP DSL MN DSC CPCB2	TATA spare parts
886399132534	40KV GENVOLTZ 3P 497SP DSL AT DSC CPCB2	TATA spare parts
886399800001	COLUMN (STRUCTURE + PINION )	TATA spare parts
886399800061	COOLANT 1 LITRE	TATA spare parts
886399800062	COOLANT 3 LITRE	TATA spare parts
886399800063	COOLANT 5 LITRE	TATA spare parts
886399800064	IMPERIAL HD GREASE 500GM	TATA spare parts
886399800065	IMPERIAL HD GREASE 1 KG	TATA spare parts
886399800066	IMPERIAL HD GREASE 2 KG	TATA spare parts
886399800067	IMPERIAL HD GREASE 3 KG	TATA spare parts
886399800068	IMPERIAL HD GREASE 5 KG	TATA spare parts
886399800069	IMPERIAL HD GREASE 7 KG	TATA spare parts
886399800070	IMPERIAL HD GREASE 20KG	TATA spare parts
886399800071	IMPERIAL HD GREASE 182 KG	TATA spare parts
886399800072	IMPERIAL HD GREASE 200GM	TATA spare parts
886399800073	SYNTHETIC GREASE PACK 5 KG	TATA spare parts
886399800074	SYNTHETIC GREASE PACK 7 KG	TATA spare parts
886399800075	SYNTHETIC GREASE PACK 182 KG	TATA spare parts
886399800076	IMPERIAL HD GREASE PACK 10KG	TATA spare parts
886399980001	GREASE PACK 100 GM BILLING FOR DTC	TATA spare parts
886399980002	GREASE PACK 200 GM	TATA spare parts
886399980003	GREASE PACK 500 GM	TATA spare parts

886399980004	GREASE PACK 1 KG	TATA spare parts
886399980005	GREASE PACK 2 KG	TATA spare parts
886399980006	GREASE PACK 3 KG	TATA spare parts
886399980007	GREASE PACK 5 KG	TATA spare parts
886399980008	GREASE PACK 7 KG	TATA spare parts
886399980009	GREASE PACK 20KG	TATA spare parts
886399980009AE	GREASE PACK 20KG	TATA spare parts
886399980009NEW	GREASE PACK 20KG	TATA spare parts
886399980010	GREASE DRUM 182 KG	TATA spare parts
886399980010AE	GREASE DRUM 182 KG	TATA spare parts
886399980019	AP2 GREASE PACK 20KG	TATA spare parts
886399980020	AP2 GREASE DRUM 182KG	TATA spare parts
886399980023	SYNTHETIC GREASE PACK 500 GM	TATA spare parts
886399980024	Synthetic GREASE PACK 1 KG	TATA spare parts
886399980025	AP2 Grease Pack 50 gm	TATA spare parts
886399980026	SYNTHETIC GREASE PACK 3 KG	TATA spare parts
886399980027	SYNTHETIC GREASE PACK 20 KG	TATA spare parts
886399980054	TATA GENUINE COOLANT 1LTR	TATA spare parts
886399980056	Tata Genuine Coolant 3Ltr	TATA spare parts
886399980057	Tata Genuine Coolant 5Ltr	TATA spare parts
886399980060	Tata Genuine Coolant 210Ltr	TATA spare parts
886399989901	GREASE PACK 50 GM	TATA spare parts
886399989905	TATA GENUINE COOLANT 50ML	TATA spare parts
886487800023	SEALKITSA50CYLINDER	TATA spare parts
886487800024	TAILDOOR ASSEMBLY	TATA spare parts
886570000011	VAS PTO SHIFT CABLE FOR 709	TATA spare parts
886628180111	FRONT NUDGE GUARD SS FIXED SUPER ACE	TATA spare parts
886628180112	FRONT NUDGE GUARD SS MS FIXED SUPER ACE	TATA spare parts
886628180113	FRONT NUDGE GUARD SS BOLTED SUPER ACE	TATA spare parts
886628180114	FRONT NUDGE GUARD SS MS BOLTED SUPER ACE	TATA spare parts
886628180511	BRACKET SET FFG SS -MS SUPER ACE	TATA spare parts
886628180512	BRACKET SET FBG SS -MS SUPER ACE	TATA spare parts
886628181511	COMFORT SEAT BLK LGT GREY SUPER ACE	TATA spare parts
886628183111	SEAT COVER SET BLACK RED SUPER ACE	TATA spare parts
886628183112	SEAT COVER SET BLK REDSLVR SUPERACE	TATA spare parts
886628183811	MUDFLAP SET SUPER ACE	TATA spare parts
886628290111	FRONT NUDGE GUARD SS FIXED ACE OLD	TATA spare parts
886628290112	FRONT NUDGE GUARD SS MS FIXED ACE OLD	TATA spare parts
886628290113	FRONT NUDGE GUARD SS BOLTED ACE OLD	TATA spare parts
886628290114	FRONT NUDGE GUARD SS MS BOLTED ACE OLD	TATA spare parts
886628290511	BRACKET SET FFG SS/MS ACE OLD	TATA spare parts
886628290512	BRACKET SET FBG SS/MS ACE OLD	TATA spare parts
886628940111	FRONT NUDGE GUARD SS FIXED XENON CREW CAB	TATA spare parts
886628940311	SIDE STEP SS XENON CREW CAB	TATA spare parts
886628940312	SIDE STEP ALUMINIUM XENON CREW CAB	TATA spare parts
886628940313	FOOT STEP-LH-XENON IB	TATA spare parts
886628940314	FOOT STEP-RH-XENON IB	TATA spare parts

886628940513	BRACKET SET SIDE STEP AL XENON CREW CAB	TATA spare parts
886628940514	BRACKET SET SIDE STEP SS XENON CREW CAB	TATA spare parts
886628943111	SEAT COVERSET SLVR BLK XENONCREWCAB	TATA spare parts
886628943112	SEATCOVERSET BLKSILVER XENONCREWCAB	TATA spare parts
886628943113	SEATCOVERSET BLKOFWHITE XENONCREWCAB	TATA spare parts
886628960111	FRONT NUDGE GUARD SS FIXED XENON PICKUP	TATA spare parts
886628960311	SIDE STEP SS XENON PICK UP	TATA spare parts
886628960312	SIDE STEP ALUMINIUM XENON PICK UP	TATA spare parts
886628960513	BRACKET SET SIDE STEP AL XENON PICK UP	TATA spare parts
886628960514	BRACKET SET SIDE STEP SS XENON PICK UP	TATA spare parts
886628963111	SEAT COVER SET SLVR BLK XENONPICKUP	TATA spare parts
886628963112	SEAT COVER SET BLK SLVR XENONPICKUP	TATA spare parts
886628963113	SEATCOVERSET BLKOFWHITE XENONPICKUP	TATA spare parts
886628980116	FRONT NUDGE GUARD SS XENON YODHA	TATA spare parts
886650200001	PRIMA SCALE MODEL (SOUVENIR)	TATA spare parts
886655010514	BRACKET SET FFG SS-XENON PICK UP	TATA spare parts
886655020514	BRACKET SET FFG SS-XENON CREW CAB	TATA spare parts
886655170115	FRONT NUDGE GUARD FULL MS ZIP- IRIS	TATA spare parts
886655170116	FRONT NUDGE GUARD HALF SS ZIP- IRIS	TATA spare parts
886655170117	FRONT NUDGE GUARD HALF MS ZIP- IRIS	TATA spare parts
886655170514	BRACKET SET HALF SS/MS ZIP IRIS	TATA spare parts
886655170515	BRACKET SET FULL MS ZIP IRIS	TATA spare parts
886655173111	Seat Cover Set Blk Grey Ace Zip	TATA spare parts
886655173112	SEAT COVER SET RED BLK ACE ZIP	TATA spare parts
886655173141	Seat Cover Full Set Black Red Iris	TATA spare parts
886655173142	SEATCOVER FULLSET DRKGRYORANGE IRIS	TATA spare parts
886655173161	SEAT COVER FRONT SET BLK RED IRIS	TATA spare parts
886655173162	SEAT COVER FRONTSET GREYORANGE IRIS	TATA spare parts
886655173811	MUDFLAP SET ACE ZIP	TATA spare parts
886655173812	MUDFLAP SET MAGIC IRIS	TATA spare parts
886655230111	FRONT NUDGE GUARD SS FIXED ACE HT	TATA spare parts
886655230112	FRONT NUDGE GUARD SS MS FIXED ACE HT	TATA spare parts
886655230113	FRONT NUDGE GUARD SS BOLTED ACE HT	TATA spare parts
886655230114	FRONT NUDGE GUARD SS MS BOLTED ACE HT	TATA spare parts
886655230511	BRACKET SET FFG SS/MS ACE HT	TATA spare parts
886655230512	BRACKET SET FBG SS/MS ACE HT	TATA spare parts
886655231511	COMFORTSEAT BLKLIGHTGRY ACEHT/MAGIC	TATA spare parts
886655233111	SEAT COVER SET BLKREDWHITE ACE HT	TATA spare parts
886655233112	SEAT COVER SET DRKGREYORANGE ACEHT	TATA spare parts
886655233113	SEAT COVER SET BLK BLUE&ACE HT	TATA spare parts
886655233711	FLOOR MAT ACE HT-EX-MAGIC	TATA spare parts
886655233811	MUDFLAP SET ACE HT/DICOR/EX/MEGA	TATA spare parts
886655373111	SEAT COVER FULLSET BLKREDSLVR MAGIC	TATA spare parts
886655373112	SEAT COVER FULLSET BLK YELLOW MAGIC	TATA spare parts
886655373161	SEATCOVER FRONTSET BLKREDSLVR MAGIC	TATA spare parts
886655373162	SEATCOVER FRONTSET BLK YELLOW MAGIC	TATA spare parts
886655373811	MUDFLAP SET MAGIC	TATA spare parts

886655383811	MUDFLAP SET VENTURE	TATA spare parts
886657083811	MUDFLAP SET ACE CNG	TATA spare parts
886699003211	STEERING GRIP SMALL SIZE BLK YELLOW	TATA spare parts
886699003212	STEERING GRIP SMALL SIZE - BLK BLK	TATA spare parts
886699003213	STEERING GRIP SMALL SIZE - BLK RED	TATA spare parts
886699003214	STEERING GRIP SMALL SIZE - BLK GREY	TATA spare parts
886699003215	STEERING GRIP MEDIUMSIZE BLK YELLOW	TATA spare parts
886699003216	STEERING GRIP MEDIUM SIZE - BLK BLK	TATA spare parts
886699003217	STEERING GRIP MEDIUM SIZE - BLK RED	TATA spare parts
886699003218	STEERING GRIP MEDIUM SIZE BLK GREY	TATA spare parts
886699003219	STEERING GRIP LARGE SIZE BLK YELLOW	TATA spare parts
886699003220	STEERING GRIP LARGE SIZE - BLK BLK	TATA spare parts
886699003221	STEERING GRIP LARGE SIZE BLACK RED	TATA spare parts
886699003222	STEERING GRIP LARGE SIZE - BLK GREY	TATA spare parts
886699003311	Back Cushion Universal Black	TATA spare parts
886699003611	DASHBOARD IDOL D1- HANUMAN	TATA spare parts
886699003612	DASHBOARD IDOL D2- HANUMAN	TATA spare parts
886699003616	DASHBOARD IDOL D1 - MAA KALI BENGAL	TATA spare parts
886699003619	DASHBOARD IDOL D1 - SHIVA	TATA spare parts
886699003620	DASHBOARD IDOL D2 - SHIVA	TATA spare parts
886699003621	DASHBOARD IDOL D3 - SHIVA	TATA spare parts
886699003622	DASHBOARD IDOL D4 - SHIVA	TATA spare parts
886699003623	DASHBOARD IDOL D5 - SHIVA	TATA spare parts
886699003626	DASHBOARD IDOL D1 - SHERA WALI MAA	TATA spare parts
886699003627	DASHBOARD IDOL D2- SHERA WALI MAA	TATA spare parts
886699003628	DASHBOARD IDOL D3 - SHERA WALI MAA	TATA spare parts
886699003631	DASHBOARD IDOL D1- SAI BABA	TATA spare parts
886699003632	DASHBOARD IDOL D2- SAI BABA	TATA spare parts
886699003633	DASHBOARD IDOL D3 - SAI BABA	TATA spare parts
886699003638	DASHBOARD IDOL D1- RADHA KRISHNA	TATA spare parts
886699003642	DASHBOARD IDOL D1- GANESH	TATA spare parts
886699003643	DASHBOARD IDOL D2- GANESH	TATA spare parts
886699003644	DASHBOARD IDOL D3- GANESH	TATA spare parts
886699003651	DASHBOARD IDOL D1- GANESH LAXMI	TATA spare parts
886699003654	DASHBOARD IDOL D1- TIRUPATI BALAJI	TATA spare parts
886699003657	DASHBOARD IDOL D1- JESUS	TATA spare parts
886699003660	DASHBOARD IDOL D1- DUS GURU	TATA spare parts
886699003664	DASHBOARD IDOL D1 - MACCA	TATA spare parts
886699003666	DASHBOARD IDOL D1 - 786	TATA spare parts
886699003667	DASHBOARD IDOL D1 - ALLAH	TATA spare parts
886699003668	DASHBOARD IDOL D1- GURUNANAK DEV	TATA spare parts
886699003669	DASHBOARD IDOL D1 - SHIV PARIVAR	TATA spare parts
886699003673	DASHBOARD IDOL D1 - CROSS	TATA spare parts
886699004011	Neck Rest Set of 2 - Polyfill Black	TATA spare parts
886699004012	Neck Rest Set of 2 - Polyfill Grey	TATA spare parts
886699004013	Neck Rest Set of 2 - Polyfill Red	TATA spare parts
886699005411	TYRE PRESSURE GAUGE(TWIN CONNECTOR)	TATA spare parts

886699005412	TYRE PRESSURE GAUGE(FLEXI TYPE)	TATA spare parts
886699009911	MOSGUARD - MOSQUITO REPELLANT	TATA spare parts
886701000002	ENGINE HEAD GASKET 2518 BS3	TATA spare parts
886701000003	KIT-FULL GASKET 6BT BS2	TATA spare parts
886701000004	UPPER GASKET KIT 6BT BS2	TATA spare parts
886701000005	KIT-LOWER GASKET 6BT BS2	TATA spare parts
886701000006	Full Gasket Kit 6Bt BSII w/o Stem Seal	TATA spare parts
886701000007	Upper Gasket kit 6BT BSII w/o stem seal	TATA spare parts
886701000008	KIT-FULL GASKET 6BT BS3	TATA spare parts
886701000009	UPPER GASKET KIT 6BT BS3	TATA spare parts
886701000010	KIT-LOWER GASKET 6BT BS3	TATA spare parts
886701000011	KIT-GASKET W/O STEM SEAL? 6BT BS3	TATA spare parts
886701000012	Upper Gasket kit 6BT BSIII w/o stem seal	TATA spare parts
886701000013	ACE GASKET CYL HEAD 1.2 RS1 CNG	TATA spare parts
886701000014	ACE GASKET CYL HEAD 1.3 RS2 CNG	TATA spare parts
886701000015	ACE GASKET CYL HEAD 1.4 RS3 CNG	TATA spare parts
886701000021	Camshaft Bush B Series Engine	TATA spare parts
886701000022	Main Brg Set 2518 RS1 10 Thou	TATA spare parts
886701012527	CYLINDER LINER SET 497-709/909 SF OS10-0	TATA spare parts
886701012786	SET CYL LINER B5.9 10OS SF COL BS2/3/4	TATA spare parts
886701012790	CYLINDER LINER SET 275IDI-ACE STD SF	TATA spare parts
886701015717	ASSY. CYLINDER BARREL BS2/3/4	TATA spare parts
886701022527	CYLINDER LINER SET 497-709/909 SF OS30-0	TATA spare parts
886701022786	SET CYL LINER B5.9 20OS SF COL BS2/3/4	TATA spare parts
886701025717	OIL SEAL - CRANKSHAFT REAR BS2/3/4	TATA spare parts
886701032527	CYLINDER LINER SET 497-709/909 SF OS60-1	TATA spare parts
886701032786	SET CYL LINER B5.9 30OS SF COL BS2/3/4	TATA spare parts
886701035717	OIL SEAL - CRANKSHAFT FRONT BS2/3/4	TATA spare parts
886701042527	CYLINDER LINER SET 697-LPT/LPK1613 SF OS	TATA spare parts
886701042786	SET CYL LINER B5.9 40OS SF COL BS2/3/4	TATA spare parts
886701045717	HEAD GASKET 1.10 ( TGP 1.00MM ) BS2/3/4	TATA spare parts
886701052527	CYLINDER LINER SET 697-LPT/LPK1613 SF OS	TATA spare parts
886701052786	SET CYL LINER B5.9 50OS SF COL BS2/3/4	TATA spare parts
886701055717	HEAD GASKET 1.30 (TGP 1.20MM) BS3/4	TATA spare parts
886701062527	CYLINDER LINER SET 697-LPT/LPK1613 SF OS	TATA spare parts
886701062786	SET CYL LINER B5.9 60OS SF COL BS2/3/4	TATA spare parts
886701065717	HEAD GASKET 1.50 (TGP 1.4MM) BS2/3/4	TATA spare parts
886701072786	SET CYL LINER B5.9 10OS SF W/O COL BS2/3	TATA spare parts
886701082786	SET CYL LINER B5.9 20OS SF W/O COL BS2/3	TATA spare parts
886701092786	SET CYL LINER B5.9 30OS SF W/O COL BS2/3	TATA spare parts
886701102786	SET CYL LINER B5.9 40OS SF W/O COL BS2/3	TATA spare parts
886701112786	SET CYL LINER B5.9 50OS SF W/O COL BS2/3	TATA spare parts
886701122786	SET CYL LINER B5.9 60OS SF W/O COL BS2/3	TATA spare parts
886701132786	CYLINDER LINER SET 6BT OS20 SF COL BS2/3	TATA spare parts
886703000002	KIT-PISTON SET TC 6BT BS3	TATA spare parts
886703000003	PISTON RING ACE BS3	TATA spare parts
886703000004	VALVE SET 2518 BS2 STD	TATA spare parts



886703000005	VALVE SET 2518 BS2 RS1 3THOU	TATA spare parts
886703000006	VALVE SET 2518 BS2 RS2 5THOU	TATA spare parts
886703000007	VALVE SET 2518 BS2 RS3 10THOU	TATA spare parts
886703000008	VALVE SET 2518 BS2 RS4 15THOU	TATA spare parts
886703000009	VALVE SET 2518 BS2 RS5 20THOU	TATA spare parts
886703000010	VALVE SET W/SEAT 2518 BS2 STD	TATA spare parts
886703000011	VALVE SET W/SEAT 2518 BS2 RS1 3THOU	TATA spare parts
886703000012	VALVE SET W/SEAT 2518 BS2 RS2 5THOU	TATA spare parts
886703000013	VALVE SET W/SEAT 2518 BS2 RS3 10THOU	TATA spare parts
886703000014	VALVE SET W/SEAT 2518 BS2 RS4 15THOU	TATA spare parts
886703000016	VALVE SET 2518 BS3 STD	TATA spare parts
886703000017	VALVE SET 2518 BS3 RS1 3THOU	TATA spare parts
886703000018	VALVE SET 2518 BS3 RS2 5THOU	TATA spare parts
886703000019	VALVE SET 2518 BS3 RS3 10THOU	TATA spare parts
886703000020	VALVE SET W/SEAT BS3 2518 STD	TATA spare parts
886703000021	VALVE SET W/SEAT BS3 2518 RS1 3THOU	TATA spare parts
886703000022	VALVE SET W/SEAT BS3 2518 RS2 5THOU	TATA spare parts
886703000023	VALVE SET W/SEAT BS3 2518 RS3 10THOU	TATA spare parts
886703000024	VALVE SET ACE BS2/3 STD	TATA spare parts
886703000025	VALVE SET WITH SEAT ACE BSII/III STD	TATA spare parts
886703000026	FLYWHEEL 3118 CI 138T-HIGHWAY APP	TATA spare parts
886703000027	KIT-LPR ACE	TATA spare parts
886703000028	KIT PISTON SET TC 6BT BS-III RS1(0.5MM)	TATA spare parts
886703000029	KIT PISTON SET TC 6BT BS-III RS2(1MM)	TATA spare parts
886703000030	KIT PISTON SET TC 6BT BS-III LONG LIFE	TATA spare parts
886703000031	697 FLYWHEEL CI HIGHWAY APP BS3	TATA spare parts
886703000032	FLYWHEEL CI 125T 697 BS2	TATA spare parts
886703000033	FLYWHEEL CLUTCH 330 DIA.? 697 BS2	TATA spare parts
886703000034	FLYWHEEL GB 750 CI HIGHWAY APP	TATA spare parts
886703000035	CR Bush Set ACE	TATA spare parts
886703000036	Thrust Washer Set ACE	TATA spare parts
886703000037	Main Brg Set ACE STD	TATA spare parts
886703000038	CR Bearing Set ACE	TATA spare parts
886703000039	CR Bush B Series Engine	TATA spare parts
886703000040	CR Brg Set 2518	TATA spare parts
886703000041	CR Brg Frac Set 2518 STD	TATA spare parts
886703000042	CR Brg Frac Set 2518 RS1 10 Thou	TATA spare parts
886703000043	CR Brg Frac Set 2518 RS2 20 Thou	TATA spare parts
886703000044	CR Brg Frac Set 2518 RS3 30 Thou	TATA spare parts
886703000045	CR Brg Frac Set 2518 RS3 40 Thou	TATA spare parts
886703000046	Main Brg Set 2518 STD	TATA spare parts
886703000047	Main Brg Set 2518 RS2 20 Thou	TATA spare parts
886703000048	Main Brg Set 2518 RS3 30 Thou	TATA spare parts
886703000049	Main Brg Set 2518 RS4 40 Thou	TATA spare parts
886703000050	FLYWHEEL SG 138T 6BT BS2/3/4	TATA spare parts
886703000051	LPR KIT LINER W/O COLLAR	TATA spare parts
886703012786	SET-PISTON RING STD 2518 BS3	TATA spare parts

886703012829	SET - THRUST WASHER RS1 - ACE/SUPER ACE	TATA spare parts
886703015717	PISTON TATA IRIS (GL-600) WITH PIN CIRC	TATA spare parts
886703022786	SET-CON ROD BRG NON-F RS1(010)-6BT BS2/3	TATA spare parts
886703022829	SET - THRUST WASHER RS2 - ACE/SUPER ACE	TATA spare parts
886703025717	CON ROD BEARING SET OF 2 P STD BS2/3/4	TATA spare parts
886703032786	SET-CON ROD BRG NON-F RS2(020)-6BT BS2/3	TATA spare parts
886703032829	SET - THRUST WASHER RS3 - ACE/SUPER ACE	TATA spare parts
886703035717	CON ROD BEARING SET OF 2 P OS10 BS2/3/4	TATA spare parts
886703042786	SET-CON ROD BRG NON-F RS3(030)-6BT BS2/3	TATA spare parts
886703042829	SET - MAIN BEARING RS1 - ACE	TATA spare parts
886703045717	CON ROD BEARING SET OF 2 P OS20 BS2/3/4	TATA spare parts
886703052786	SET-CON ROD BRG NON-F RS4(040)-6BT BS2/3	TATA spare parts
886703052829	SET - MAIN BEARING RS2 - ACE	TATA spare parts
886703055717	CON ROD BEARING SET OF 2 P OS30 BS2/3/4	TATA spare parts
886703062786	CON ROD BUSH RS1 - 6BT BS2/3	TATA spare parts
886703062829	SET - MAIN BEARING RS3 - ACE	TATA spare parts
886703065717	MAIN BEARING SET OF 2 PCS STD BS2/3/4	TATA spare parts
886703072786	CON ROD BUSH RS2 - 6BT BS2/3	TATA spare parts
886703072829	SET - MAIN BEARING RS4 - ACE	TATA spare parts
886703075717	MAIN BEARING SET OF 2 PCS OS10 BS2/3/4	TATA spare parts
886703082786	BELT V RIBBED - LPO 1618	TATA spare parts
886703082829	SET - CON ROD BEARING RS1 - ACE	TATA spare parts
886703085717	MAIN BEARING SET OF 2 PCS OS20 BS2/3/4	TATA spare parts
886703092786	MAIN BEARING SET 6BT BS2/3 STD-THK COLLA	TATA spare parts
886703092829	SET - CON ROD BEARING RS2 - ACE	TATA spare parts
886703095717	MAIN BEARING SET OF 2 PCS OS30 BS2/3/4	TATA spare parts
886703102829	SET - CON ROD BEARING RS3 - ACE	TATA spare parts
886703105717	CON ROD BUSH SET OF 1 PC STD BS2/3/4	TATA spare parts
886703112829	SET - CON ROD BEARING RS4 - ACE	TATA spare parts
886703115717	CON ROD BUSH SET OF 1 PC OS10 BS2/3/4	TATA spare parts
886703122829	SET - CON ROD BUSH RS1 - ACE	TATA spare parts
886703125717	CON ROD BUSH SET OF 1 PC OS20 BS2/3/4	TATA spare parts
886703132829	SET - CON ROD BUSH RS2 - ACE	TATA spare parts
886703135717	CON ROD BUSH SET OF 1 PC OS30 BS2/3/4	TATA spare parts
886703142829	SET - CON ROD BUSH RS3 - ACE	TATA spare parts
886703145717	THRUST WASHER SET OF 1 PC STD BS2/3/4	TATA spare parts
886703152829	SET - CON ROD BUSH RS4 - ACE	TATA spare parts
886703155717	THRUST WASHER SET OF 1 PC OS10 BS2/3/4	TATA spare parts
886703165717	THRUST WASHER SET OF 1 PC OS20 BS2/3/4	TATA spare parts
886703175717	THRUST WASHER SET OF 1 PC OS30 BS2/3/4	TATA spare parts
886703185717	PISTON RINGS SET BS2/3/4	TATA spare parts
886705000001	TIMING BELT -TATA ACE	TATA spare parts
886705000002	TIMING BELT BS4	TATA spare parts
886705012786	SET-IN/EX VALVE SEAT INSERT 6BT BS3/4	TATA spare parts
886705012829	TIMING BELT ACE CNG	TATA spare parts
886705015717	OIL SEAL - VALVE STEM BS2/3/4	TATA spare parts
886705022786	SET-IN/EX VALVE SEAT INSERT 6BT BS2	TATA spare parts

886705025717	VALVE IN / EX SET ZIP IRIS BS2/3/4	TATA spare parts
886709000015	GASKET CYL.HEAD-2518	TATA spare parts
886709000016	SET CYL LINER 6BT STD SF COL	TATA spare parts
886709000017	SET-PISTON RING STD 2518 BS2	TATA spare parts
886709000018	SET CYL LINER 697 RS2 OS 0.5 mm	TATA spare parts
886709000019	SET CYL LINER 697 RS4 OS 1.0 mm	TATA spare parts
886709000020	FLYWHEEL SG 138T B5.9 BS2/3/4	TATA spare parts
886709000021	TIMING BELT - ACE	TATA spare parts
886709000022	OILSEAL INNER 109RR METALCASING	TATA spare parts
886709000023	OILSEAL OUTER 109RR METALCASING	TATA spare parts
886709000024	SET CYL LINER 497 RS2 OS 0.5 mm	TATA spare parts
886709000025	SET CYL LINER 497 RS4 OS 1.0 mm	TATA spare parts
886709000036	AIR BREATHER FILTER	TATA spare parts
886709000037	RLF ELEMENT	TATA spare parts
886709000038	SET CYL LINER 6BT STD SF W/O COL	TATA spare parts
886709000042	SET CYL LINER 6BT STD FF W/O COL	TATA spare parts
886709000046	SET CYL LINER 6BT STD FF COL	TATA spare parts
886709000050	SET CYL LINER 497 STD SF	TATA spare parts
886709000054	SET CYL LINER 697 STD SF	TATA spare parts
886709000058	SET CYL LINER 497 STD SF	TATA spare parts
886709000062	SET CYL LINER 697 STD SF	TATA spare parts
886709000066	SET CYL LINER 697 STD FF	TATA spare parts
886709000070	SET CYL LINER 697 STD FF	TATA spare parts
886709012525	FUEL FILTER 1.1 L CLOTH (1457431003)	TATA spare parts
886709012534	FUEL FILTER 0.5L (407/207)	TATA spare parts
886709012829	FUEL FILTER-ACE	TATA spare parts
886709022525	FUEL PAPER 1.1 L STAR (9451037406)	TATA spare parts
886709022534	FUEL FILTER 0.5 L CLOTH (9451037404)	TATA spare parts
886709032525	FUEL FILTER 1.1 L COIL (9451037409)	TATA spare parts
886709032534	FUEL FILTER 0.5 L STAR (9451037405)	TATA spare parts
886715000001	POLY-V BELT (4 GROOVES-720)	TATA spare parts
886715012525	POLY V BELT 8PK 1260L - LPO 1613TC	TATA spare parts
886715012786	STARTER MOTOR 24V 6BT BS2/3	TATA spare parts
886715012818	GLOW PLUG BS4 SUPER ACE	TATA spare parts
886715012829	STARTER MOTOR ACE/MAGIC	TATA spare parts
886715012894	GLOW PLUG BS4 XENON	TATA spare parts
886715015717	GLOW PLUG BS4 ZIP IRIS	TATA spare parts
886715022786	ARMATURE 6BT BS2/3	TATA spare parts
886715022829	ARMATURE ACE/MAGIC	TATA spare parts
886715032786	BRUSH GEAR ASSY 6BT BS2/3	TATA spare parts
886715032829	BRUSH GEARACE/MAGIC	TATA spare parts
886715042786	DRIVE ASSY 6BT BS2/3	TATA spare parts
886715042829	DRIVE ASSY. ACE/MAGIC	TATA spare parts
886715052786	SOLENOID SWITCH 6BT BS2/3	TATA spare parts
886715052829	SOLENOID SWITCH ACE/MAGIC	TATA spare parts
886715062786	FIELD COIL 6BT BS2/3	TATA spare parts
886715062829	FIELD COIL ASSY. ACE/MAGIC	TATA spare parts

886715072786	FIXING BRACKET ASSY 6BT BS2/3	TATA spare parts
886715072829	FIXING BRACKET ASSY. ACE/MAGIC	TATA spare parts
886715082786	CARBON BRUSHES 6BT BS2/3	TATA spare parts
886715082829	CARBON BRUSHES ACE/MAGIC	TATA spare parts
886715092786	CE BRACKET ASSY 6BT BS2/3	TATA spare parts
886715092829	CE BRACKETS ASSY. ACE/MAGIC	TATA spare parts
886715102829	ALTERNATORS	TATA spare parts
886715112829	REGULATOR ASSY.	TATA spare parts
886715122829	RECTIFIER ASSY.	TATA spare parts
886715132829	STATORS ASSY.	TATA spare parts
886715142829	ROTORS ASSY.	TATA spare parts
886715152829	DE BRACKET ASSY.	TATA spare parts
886715162829	SRE BRACKET ASSY.	TATA spare parts
886715172829	PULLEY	TATA spare parts
886718012818	OIL FILTER- SUPER ACE	TATA spare parts
886718012829	OIL FILTER-ACE	TATA spare parts
886718015717	OIL FILTER-ZIP/IRIS	TATA spare parts
886720000001	WATER PUMP 2518-EURO2	TATA spare parts
886720000002	WATER PUMP 2518-EURO3	TATA spare parts
886720000003	ASSY. WATER PUMP TATA ACE/ MAGIC	TATA spare parts
886720000004	WATER PUMP 2518-E3 MOD. HIGH FLOW	TATA spare parts
886720000005	BELT FOR DRIVE PLANE-2 6PK - 1025MM(NON-	TATA spare parts
886720000006	BELT DRIVE PLANE ALTERNATOR 6PK 1575 MM	TATA spare parts
886720012527	POLY V BELT 8PK 1245 L - LP712 BS4	TATA spare parts
886720012786	BELT RIBBED 1443L - LPT3718	TATA spare parts
886720012829	ASSY. WATER PUMP ACE BS2/3/4 SUPER ACE	TATA spare parts
886720015701	BELT V RIBBED - LPT 2521TC	TATA spare parts
886720022525	V BELT COGGED 1450MM L - LPT 1116	TATA spare parts
886720025701	BELT (328 9831) - 8PK - LPK 2528TC	TATA spare parts
886720032525	V BELT COGGED 1325 L - LP709	TATA spare parts
886723000001	6PK EPDM BELT-1155(ALT+PSTG) BS4	TATA spare parts
886723000002	6PK EPDM BELT-875(A/C)	TATA spare parts
886723000003	6PK EPDM BELT-895(A/C) BS4	TATA spare parts
886723000004	BELT POWER STEERING PUMP BS4	TATA spare parts
886723000005	POLY-V BELT 1060MM	TATA spare parts
886723000006	POLY V BELT 6-PK 972MM TRUCK AC	TATA spare parts
886723000007	BELT 1760MM 8PK	TATA spare parts
886723000008	BELT AC	TATA spare parts
886723000009	POLY V BELT BS4	TATA spare parts
886723000010	POLY V BELT BS4	TATA spare parts
886723000011	MICRO V-BELT 5-PEAKS (915L) HPHW	TATA spare parts
886723000012	POLY V BELT (4-PK)(730 L-HPHW)	TATA spare parts
886723000013	POLY V-BELT	TATA spare parts
886724000001	ENGINE MOUNTING ACE REAR	TATA spare parts
886724000002	ENGINE MOUNTING ACE FRONT	TATA spare parts
886724000003	ASSY ENGINE MOUNTING B	TATA spare parts
886724000004	ASSY ENGINE MOUNTING C	TATA spare parts

88672400005	ASSY ENGINE MOUNT D	TATA spare parts
88672400006	REAR MOUNT WITH BACK PLATE -TATA ACE	TATA spare parts
88672500001	CLUTCH RELEASE BRG (352 DIA)	TATA spare parts
88672500002	ASSY CLUTCH RELEASE BRG.(380 DIA ) G750	TATA spare parts
88672500003	240 DIA CLUTCH FACING ORG 4MM	TATA spare parts
88672500004	280 DIA CLUTCH FACING ORG 3.5MM	TATA spare parts
88672500005	280 DIA CLUTCH FACING ORG 4MM	TATA spare parts
88672500006	310 DIA CLUTCH FACING ORG 4.2MM	TATA spare parts
88672500007	330 DIA CLUTCH FACING ORG 4.2MM	TATA spare parts
88672500008	352 DIA CLUTCH FACING ORG	TATA spare parts
88672500009	380 DIA CLUTCH FACING ORG	TATA spare parts
88672500010	430 DIA CLUTCH FACING ORG 3.5MM	TATA spare parts
88672500011	352 DIA. CLUTCH FACING CERAMIC	TATA spare parts
88672500012	170 DIA CLUTCH FACING ORG 3MM	TATA spare parts
88672500013	200 DIA CLUTCH FACING ORG 3MM	TATA spare parts
88672500014	CLUTCH FACING 240 DIA WITH RIVETS	TATA spare parts
88672500015	CLUTCH FACING 280 DIA 3.5MM WITH RIVETS	TATA spare parts
88672500016	CLUTCH FACING 280 DIA.4MM WITH RIVETS	TATA spare parts
88672500017	CLUTCH FACING 310 DIA WITH RIVETS	TATA spare parts
88672500018	CLUTCH FACING 330 DIA WITH RIVETS	TATA spare parts
88672500019	CLUTCH FACING 352 DIA WITH RIVETS	TATA spare parts
88672500020	CLUTCH FACING 380 DIA WITH RIVETS	TATA spare parts
88672500021	CLUTCH FACING 430 DIA WITH RIVETS	TATA spare parts
88672500022	CLUTCH FACING 170 DIA WITH RIVETS	TATA spare parts
88672500023	CLUTCH FACING 200 DIA WITH RIVETS	TATA spare parts
88672500024	CLUTCH FACING 325 DIA WITH RIVETS	TATA spare parts
88672600012	DRIVE SHAFT 19 T GBS18	TATA spare parts
88672600013	DRIVE SHAFT 19T W/- CIRCLIP GROOVE	TATA spare parts
88672600014	DRIVE SHAFT 18 T GBS18	TATA spare parts
88672600015	DRIVESHAFT 6.01 RATIO GBS18	TATA spare parts
88672600016	MAIN SHAFT GBS18	TATA spare parts
88672600017	COUNTER SHAFT GBS18	TATA spare parts
88672600018	COUNTER SHAFT GBS18	TATA spare parts
88672600019	REV.IDLER GEAR 22 T GBS18	TATA spare parts
88672600020	GEAR REVERSE SPEED GBS18	TATA spare parts
88672600021	GEAR ENGAGING 2/3RD SPEED GBS18	TATA spare parts
88672600022	CONSTANT MESH GEAR 36T GBS18	TATA spare parts
88672600023	C/SHAFT GEAR BIG 37 T GBS18	TATA spare parts
88672600024	1ST SPEED GEAR 38 T GBS18	TATA spare parts
88672600025	2ND SPEED GEAR 32 T GBS18	TATA spare parts
88672600026	3RD SPEED GEAR 23 T GBS18	TATA spare parts
88672600027	4TH SPEED GEAR 22 T GBS18	TATA spare parts
88672600028	C/SHAFT GEAR SMALL 33 T GBS18	TATA spare parts
88672600029	C/SHAFT GEAR SMALL 33 T MODIFIED	TATA spare parts
88672600030	ENGAGING GEAR 4/5 GBS18	TATA spare parts
88672600031	DRIVE SHAFT 7.36 GBS27	TATA spare parts
88672600032	MAIN SHAFT REMOTE GBS27	TATA spare parts

886726000033	COUNTER SHAFT 6.17 GBS27	TATA spare parts
886726000034	COUNTER SHAFT 6.17 GBS27 MODIFIED	TATA spare parts
886726000035	GEAR REVERSE IDLER GBS27	TATA spare parts
886726000036	GEAR REVERSE SPEED GBS27 EN 36	TATA spare parts
886726000037	GEAR CONMESH 7.36 C/SHAFT	TATA spare parts
886726000038	GEAR REVERSE 7.36 & 7.17 GBS27	TATA spare parts
886726000039	GEAR 1ST SPEED M/SHAFT GBS27	TATA spare parts
886726000040	GEAR 2ND SPEED M/SHAFT	TATA spare parts
886726000041	GEAR 2ND SPEED M/SHAFT MODIFIED	TATA spare parts
886726000042	GEAR 3RD SPEED	TATA spare parts
886726000043	GEAR 3 RD SPEED MODIFIED	TATA spare parts
886726000044	GEAR ASSY 4TH SPEED 7.36	TATA spare parts
886726000045	GEAR ASSY 4TH SPEED 7.36 MODIFIED	TATA spare parts
886726000046	GEAR 4TH SPEED 7.36 C/S	TATA spare parts
886726000047	GEAR 4TH COUNTER SHAFT	TATA spare parts
886726000048	SYNCHRONISING SLEEVE (4TH/5TH)	TATA spare parts
886726000049	COLLAR BUSH 45.00 MM	TATA spare parts
886726000050	COLLAR BUSH 45.40 MM	TATA spare parts
886726000051	DRIVESHAFT T=17 (697ENGINE)	TATA spare parts
886726000052	DRIVE SHAFT BS4 GBS40	TATA spare parts
886726000053	DRIVE SHAFT(T=17) GBS40	TATA spare parts
886726000054	MAIN SHAFT -LONGER PILOT BRG BS4	TATA spare parts
886726000055	COUNTER SHAFT -11 T GBS40	TATA spare parts
886726000056	REV. IDLER GEAR -20 T GBS40	TATA spare parts
886726000057	REVERSE GEAR 36 T GBS40	TATA spare parts
886726000058	REVERSE GEAR 36 T GBS40 MODIFIED	TATA spare parts
886726000059	2ND SPEED GEAR - 32 T HELICAL GBS40	TATA spare parts
886726000060	3RD SPEED GEAR - 25 T HELICAL GBS40	TATA spare parts
886726000061	COLLAR BUSHING 44.6 MM.LONG	TATA spare parts
886726000062	COLLAR BUSHING 44.5 MM.LONG.	TATA spare parts
886726000063	TWIN GEAR - 17/23 T COUNTERSHAFT GBS40	TATA spare parts
886726000064	SYNCRO SLEEVE 2/3 SPEED	TATA spare parts
886726000065	SYNCRO SLEEVE 2/3 SPEED MODIFIED	TATA spare parts
886726000066	3RD SPEED GEAR - 26 T GBS40 HELICAL	TATA spare parts
886726000067	4TH SPEED GEAR - 20 T GBS40 HELICAL	TATA spare parts
886726000068	SYN. SLEEVE 4/5 - 45 T GBS40	TATA spare parts
886726000069	TWIN GEAR C/SHAFT 22T-17T GBS40 2ND/3RD	TATA spare parts
886726000070	4TH GEAR C/SHAFT -28T GBS40	TATA spare parts
886726000071	3RD GEAR (T=22) COUNTER SHAFT	TATA spare parts
886726000072	3RD GEAR (T=22) COUNTER SHAFT MODIFIED	TATA spare parts
886726000073	SPLIT TWIN GEAR 23 T C_SHAFT GBS40	TATA spare parts
886726000074	SPLIT TWIN GEAR 23 T C_SHAFT GBS40_MODIF	TATA spare parts
886726000075	SPLIT TWIN GEAR 17 T C_SHAFT GBS40	TATA spare parts
886726000076	2ND GEAR (T=17) COUNTER SHAFT	TATA spare parts
886726000077	SYNCHRO-CONE 1/2-3/4.(CARBON)	TATA spare parts
886726000078	SYNCHRO-CONE (5/6 CARBON)	TATA spare parts
886726022715	OIL SEAL	TATA spare parts

886726032691	OIL SEAL	TATA spare parts
886726032715	OILSEAL(95-125-12)	TATA spare parts
886730000001	DRIVE SHAFT -17 T GBS40	TATA spare parts
886730000002	MAIN SHAFT - 8 T GBS40	TATA spare parts
886730000003	COUNTER SHAFT 7.51	TATA spare parts
886730000004	SYNCRO SLEEVE 4/5TH SPEED BS4	TATA spare parts
886730000005	SYNCRO SLEEVE 4/5TH SPEED BS4 MODIFIED	TATA spare parts
886730000006	4TH GEAR C/SHAFT - 29 T GBS40	TATA spare parts
886730000007	CONSTANT MESH GEAR - 36 T GBS40	TATA spare parts
886730000008	1ST SPEED GEAR-39 T GBS40	TATA spare parts
886730000009	1ST SPEED GEAR-38 T GBS40	TATA spare parts
886730000010	4TH SPEED GEAR - 19 T GBS40 HELICAL	TATA spare parts
886730000011	COLLAR BUSHING 47.20 MM	TATA spare parts
886730000012	CONSTANT MESH GEAR - 38 T GBS40	TATA spare parts
886730000013	DRIVE SHAFT - 15 T GBS40	TATA spare parts
886732000002	AIR BELLOW	TATA spare parts
886732000005	LIFT AXLE AIR SPRING	TATA spare parts
886732000006	TATA ACE FRONT M/L	TATA spare parts
886732000007	TATA ACE FRONT 2/L	TATA spare parts
886732000008	TATA ACE REAR M/L	TATA spare parts
886732000009	TATA ACE REAR 2/L	TATA spare parts
886732000010	TATA ACE REAR 3/L	TATA spare parts
886732000011	ACE FRONT AUXILIARY A	TATA spare parts
886732000012	ACE REAR AUXILIARY A	TATA spare parts
886732000013	RUBBER BLOSTER	TATA spare parts
886732000014	RUBBER BOLSTER	TATA spare parts
886732000015	FRONT SPRING BUSH	TATA spare parts
886732000016	REAR SPRING BUSH	TATA spare parts
886732000017	FRONT & REAR SPRING BUSH	TATA spare parts
886732000018	KING PIN BUSH	TATA spare parts
886732000019	KING PIN BUSH	TATA spare parts
886732000020	REAR SPRING BUSH	TATA spare parts
886732000021	FRONT SPRING BUSH	TATA spare parts
886732000022	REAR SPRING BUSH	TATA spare parts
886732000023	KING PIN BUSH	TATA spare parts
886732000024	KING PIN BUSH	TATA spare parts
886732000025	LPK 3118 FRONT M/L	TATA spare parts
886732000026	LPK 3118 FRONT 2/L	TATA spare parts
886732000027	LPK 3118 FRONT 3/L	TATA spare parts
886732000028	LPK 3118 FRONT 4/L	TATA spare parts
886732000029	2515 EX FRONT M/L	TATA spare parts
886732000030	2515 EX FRONT 2/L	TATA spare parts
886732000031	2515 EX FRONT 3/L	TATA spare parts
886732000032	LPT 2515 REAR M/L	TATA spare parts
886732000033	LPT 2515 REAR 2/L	TATA spare parts
886732000034	LPT 2515 REAR 3/L	TATA spare parts
886732000035	609 TRUCK FRONT M/L	TATA spare parts

886732000036	609 TRUCK FRONT 2/L	TATA spare parts
886732000037	609 TRUCK FRONT 3/L	TATA spare parts
886732000038	609/709 BUS FRONT M/L	TATA spare parts
886732000039	609/709 BUS FRONT 2/L	TATA spare parts
886732000040	609/709 BUS FRONT 3/L	TATA spare parts
886732000041	LPT 2515 / 2518 FRONT M/L	TATA spare parts
886732000042	LPT 2515 / 2518 FRONT 2/L	TATA spare parts
886732000043	SFC 609/709 LPT RR M/L	TATA spare parts
886732000044	SFC 609/709 LPT RR 2/L	TATA spare parts
886732000045	SFC 609/709 LPT RR 3/L	TATA spare parts
886732000046	SFC 609/709 LPT RR 4/L	TATA spare parts
886732000047	SFC 609/709 LPT RR 5/L	TATA spare parts
886732000048	609/709 BUS FRONT 4/L	TATA spare parts
886732000049	609/709 BUS FRONT 5/L	TATA spare parts
886732000050	LP 609 REAR M/L	TATA spare parts
886732000051	LP 609 REAR 2/L	TATA spare parts
886732000052	LP 609 REAR 3/L	TATA spare parts
886732000053	LP 609 REAR 4/L	TATA spare parts
886732000054	LP 609 REAR 5/L	TATA spare parts
886732000055	LP 709 FRONT M/L	TATA spare parts
886732000056	LP 709 FRONT 2/L	TATA spare parts
886732000057	2515 FRONT M/L	TATA spare parts
886732000058	2515 FRONT 2/L	TATA spare parts
886732000059	2515 FRONT 3/L	TATA spare parts
886732000060	LPT 3718 SPG FRONT M/L	TATA spare parts
886732000061	LPT 3718 SPG FRONT 2/L	TATA spare parts
886732000062	LPT 3718 SPG FRONT AUX-A	TATA spare parts
886732000063	LPT 3718 SPG FRONT 3/L	TATA spare parts
886732000064	LPT 3718 FRONT M/L	TATA spare parts
886732000065	LPT 3718 FRONT 2/L	TATA spare parts
886732000066	LPT 3718 FRONT AUX-A	TATA spare parts
886732000067	LPT 3718 FRONT 3/L	TATA spare parts
886732000068	TATA 1210 SE / 1612 FRONT M/L	TATA spare parts
886732000069	TATA 1210 SE / 1612 FRONT 5/L	TATA spare parts
886732000070	TATA 1210 SE / 1612 FRONT 6/L	TATA spare parts
886732000071	TATA 1210 SE / 1612 REAR 2/L	TATA spare parts
886732000072	TATA 1210 SE / 1612 FRONT 7/L	TATA spare parts
886732000073	TATA 1210 SE / 1612 REAR AUX-B	TATA spare parts
886732000074	TATA 1210 SE / 1612 REAR M/L	TATA spare parts
886732000075	TATA 1210 SE / 1612 REAR AUX-A	TATA spare parts
886732000076	TATA 1210 SE / 1612 REAR 4/L	TATA spare parts
886732000077	TATA 1210 SE/1612 HELPER 3/L (AUX)	TATA spare parts
886732000078	TATA 1210 SE/1612 HELPER 4/L (AUX)	TATA spare parts
886732000079	TATA 2515 EX FRONT AUX-A	TATA spare parts
886732000080	TATA 2515 EX FRONT AUX-B	TATA spare parts
886732000081	TATA LPS-4018/3516 EX/1613 LPK REAR AUX-	TATA spare parts
886732000082	TATA LPS-4018/3516 EX/1613 LPK REAR AUX-	TATA spare parts



886732000083	TATA 2515 EX FRONT 4/L	TATA spare parts
886732000084	TATA LPS-4018/3516 EX/1613 LPK REAR 3/L	TATA spare parts
886732000085	TATA 2515 EX FRONT 5/L	TATA spare parts
886732000086	TATA LPS-4018/3516 EX/1613 LPK REAR 5/L	TATA spare parts
886732000087	TATA LPS-4018/3516 EX MODIFIED HELPER M/	TATA spare parts
886732000088	TATA 1613 TOURBO REAR M/L	TATA spare parts
886732000089	1ST LEAF ASSY WITH BUSH	TATA spare parts
886732000090	TATA 1516/2416/2515 EX/2518 MOD FRONT AU	TATA spare parts
886732000091	TATA 609 / 709 TRUCK REAR 2/L	TATA spare parts
886732000092	TATA 609 / 709 TRUCK REAR AUX-A	TATA spare parts
886732000093	TATA 609 / 709 TRUCK REAR 3/L	TATA spare parts
886732000094	TATA 609 / 709 TRUCK REAR 4/L	TATA spare parts
886732000095	TATA LPT 2515 REAR 4/L	TATA spare parts
886732000096	TATA 609 / 709 BUS REAR AUX-A	TATA spare parts
886732000097	TATA LPS-4018/3516 EX/1613 LPK REAR M/L	TATA spare parts
886732000098	TATA ULTRA BUS FRONT M/L	TATA spare parts
886732000099	TATA ULTRA BUS FRONT 2/L	TATA spare parts
886732000100	THIRD LEAF	TATA spare parts
886732000101	TATA ULTRA BUS FRONT 4/L	TATA spare parts
886732000102	TATA ULTRA BUS REAR M/L	TATA spare parts
886732000103	TATA ULTRA BUS REAR 2/L	TATA spare parts
886732000104	TATA ULTRA BUS REAR 3/L	TATA spare parts
886732000105	TATA ULTRA BUS REAR 4/L	TATA spare parts
886732000106	TATA 609 TRUCK HELPER M/L	TATA spare parts
886732000107	TATA 609 TRUCK HELPER 2/L	TATA spare parts
886732000108	TATA 609 TRUCK HELPER AUX-B	TATA spare parts
886732000109	TATA 609 TRUCK HELPER AUX-A	TATA spare parts
886732000110	TATA 609 TRUCK HELPER 4/L	TATA spare parts
886732000111	TATA 1109 REAR M/L	TATA spare parts
886732000112	TATA 1109 REAR AUX-A	TATA spare parts
886732000113	TATA 1109 REAR AUX-B	TATA spare parts
886732000114	TATA 1109 REAR 3/L	TATA spare parts
886732000115	TATA 1109 REAR 4/L	TATA spare parts
886732000116	TATA-2213/2316/2416 REAR M/L	TATA spare parts
886732000117	TATA-2213/2316/2416 REAR 2/L	TATA spare parts
886732000118	TATA 2515 EX/2416 REAR 5/L	TATA spare parts
886732000119	TATA 609 TRUCK FRONT AUX-A	TATA spare parts
886732000120	TATA 609 TRUCK FRONT AUX-B	TATA spare parts
886732000121	TATA HENDRICKSON(T) M/L	TATA spare parts
886732000122	TATA HENDRICKSON(T) 2/L	TATA spare parts
886732000123	TATA HENDRICKSON(T) AUX-A	TATA spare parts
886732000124	TATA HENDRICKSON(T)3/L	TATA spare parts
886732000125	TATA HENDRICKSON(T) 4/L	TATA spare parts
886732000126	TATA HENDRICKSON(T) 5/L	TATA spare parts
886732000127	TATA 2515 EX/2416 REAR AUX-A	TATA spare parts
886732000128	TATA 2515 EX/2416 REAR AUX-B	TATA spare parts
886732000129	TATA 2515 EX/2416 REAR 3/L	TATA spare parts

886732000130	TATA 2515 EX/2416 REAR 4/L	TATA spare parts
886732000131	TATA 1210 SE / 1612 FRONT 2/L	TATA spare parts
886732000132	TATA 1210 SE / 1612 FRONT AUX-A	TATA spare parts
886732000133	TATA 1210 SE / 1612 FRONT AUX-B	TATA spare parts
886732000134	TATA 1210 SE / 1612 REAR 3/L	TATA spare parts
886732000135	TATA 1210 SE/1612 HELPER M/L	TATA spare parts
886732000136	TATA 1210 SE/1612 HELPER 2/L	TATA spare parts
886732000137	TATA 1210 SE/1612 HELPER AUX-A	TATA spare parts
886732000138	TATA 1210 SE/1612 HELPER AUX-B	TATA spare parts
886732000139	TATA LPT 2515 REAR 5/L	TATA spare parts
886732000140	TATA 1613 TOURBO REAR 2/L	TATA spare parts
886732000141	TATA 1613 TOURBO REAR AUX-A	TATA spare parts
886732000142	TATA 1613 TOURBO REAR AUX-B	TATA spare parts
886732000143	TATA 1613 TOURBO REAR 3/L	TATA spare parts
886732000144	TATA 1613 TOURBO REAR 4/L	TATA spare parts
886732000145	TATA 1613 TOURBO REAR 5/L	TATA spare parts
886732000146	TATA 1613 LPT N/M HELPER M/L	TATA spare parts
886732000147	TATA 1613 LPT N/M HELPER 2/L	TATA spare parts
886732000148	TATA 1613 LPT N/M HELPER AUX-A	TATA spare parts
886732000149	TATA 1613 LPT N/M HELPER AUX-B	TATA spare parts
886732000150	TATA 1613 LPT N/M HELPER 3/L	TATA spare parts
886732000151	TATA 1516/2416/2515 EX/2518 MOD FRONT M/	TATA spare parts
886732000152	TATA 1516/2416/2515 EX/2518 MOD FRONT 2/	TATA spare parts
886732000153	TATA 1516/2416/2515 EX/2518 MOD FRONT AU	TATA spare parts
886732000154	TATA 1516/2416/2515 EX/2518 MOD FRONT 3/	TATA spare parts
886732000155	TATA 1516/2416/2515 EX/2518 MOD FRONT 4/	TATA spare parts
886732000156	TATA 1516/2416/2515 EX/2518 MOD FRONT 5/	TATA spare parts
886732000157	TATA 1109 REAR 2/L	TATA spare parts
886732000158	TATA 2515 EX/2416 REAR M/L	TATA spare parts
886732000159	TATA 2515 EX/2416 REAR 2/L	TATA spare parts
886732000160	TATA 2515 EX/2416 REAR 3/L	TATA spare parts
886732000161	TATA 2515 EX/2416 REAR 4/L	TATA spare parts
886732000162	ASSY. AIR SPRING - TATA DLT	TATA spare parts
886732000164	SECOND LEAF (NORMAL CAMBER)	TATA spare parts
886732000165	ASSY FIRST LEAF(WITH BUSH)	TATA spare parts
886732000166	THIRD LEAF (NORMAL CAMBER)	TATA spare parts
886732000169	THIRD LEAF (NORMAL CAMBER)	TATA spare parts
886732000170	SECOND LEAF (NORMAL CAMBER)	TATA spare parts
886732000172	THIRD LEAF	TATA spare parts
886732000173	ASSY FIRST LEAF WITH BUSH(NORMAL CAMBER)	TATA spare parts
886732000174	THIRD LEAF	TATA spare parts
886732000175	ASSY. FIRST LEAF WITH END CLIPS	TATA spare parts
886732000177	SECOND LEAF (MAIN SPRING)	TATA spare parts
886732000178	FOURTH LEAF	TATA spare parts
886732000179	FIFTH LEAF	TATA spare parts
886732000180	ASSEMBLY MAIN LEAF WITH BUSHES	TATA spare parts
886732000181	SECOND LEAF	TATA spare parts

886732000182	THIRD LEAF	TATA spare parts
886732000183	FOURTH LEAF	TATA spare parts
886732000184	FIFTH LEAF	TATA spare parts
886732000185	SECOND LEAF	TATA spare parts
886732000186	FIRST LEAF(AUX. SPRING)	TATA spare parts
886732000187	SECOND LEAF(AUX.SPRING)	TATA spare parts
886732000188	THIRD LEAF(AUX.SPRING)	TATA spare parts
886732000194	ELEVENTH LEAF	TATA spare parts
886732000195	ASSY FIRST LEAF WITH BUSH	TATA spare parts
886732000196	SECOND LEAF	TATA spare parts
886732000200	LEAF SPRING 1ST W/BUSH	TATA spare parts
886732000204	ASSY.FIRST LEAF WITH BUSH	TATA spare parts
886732000205	ASSY.FIRST LEAF WITH BUSH	TATA spare parts
886732000206	SECOND LEAF	TATA spare parts
886732000207	FOURTH LEAF	TATA spare parts
886732000208	FIFTH LEAF	TATA spare parts
886732000209	SECOND LEAF	TATA spare parts
886732000210	ASSY.FIRST LEAF WITH BUSHES	TATA spare parts
886732000211	SECOND LEAF	TATA spare parts
886732000213	ASSY. FIRST LEAF WITH BUSH	TATA spare parts
886732000216	2ND LEAF	TATA spare parts
886732000217	THIRD LEAF	TATA spare parts
886732000218	FOURTH LEAF	TATA spare parts
886732000219	FIFTH LEAF	TATA spare parts
886732000220	ASSY FIRST LEAF WITH BUSHES.	TATA spare parts
886732000221	SECOND LEAF	TATA spare parts
886732000222	THIRD LEAF	TATA spare parts
886732000223	FOURTH LEAF	TATA spare parts
886732000224	FIFTH LEAF	TATA spare parts
886732000225	SIXTH LEAF	TATA spare parts
886732000244	FIRST LEAF W/BUSH (4	TATA spare parts
886732000245	1ST LEAF ASSY WITH BUSH	TATA spare parts
886732000247	2ND LEAF	TATA spare parts
886732000248	5TH LEAF	TATA spare parts
886732000249	ASSY. SECOND LEAF WITH END CLIPS	TATA spare parts
886732000250	THIRD LEAF	TATA spare parts
886732000251	FOURTH LEAF	TATA spare parts
886732000266	ASSY. REAR SPRING (PARABOLIC)	TATA spare parts
886732000267	SECOND LEAF	TATA spare parts
886732000268	THIRD LEAF	TATA spare parts
886732000269	FOURTH LEAF	TATA spare parts
886732000272	SECOND LEAF	TATA spare parts
886732000273	THIRD LEAF	TATA spare parts
886732000274	FOURTH LEAF	TATA spare parts
886732000275	FIFTH LEAF	TATA spare parts
886732000278	SECOND LEAF	TATA spare parts
886732000285	FIRST LEAF ASSY WITH BUSH	TATA spare parts

886732000286	SECOND LEAF	TATA spare parts
886732000287	THIRD LEAF	TATA spare parts
886732000288	SECOND LEAF	TATA spare parts
886732000289	THIRD LEAF	TATA spare parts
886732000295	SIXTH LEAF	TATA spare parts
886732000301	FIRST LEAF ASSY WITH BUSH	TATA spare parts
886732000305	FIFTH LEAF (AUXILLARY SPRING)	TATA spare parts
886732000306	FOURTH LEAF (AUXILLARY SPRING)	TATA spare parts
886732000307	THIRD LEAF (AUXILLARY SPRING)	TATA spare parts
886732000308	SECOND LEAF (AUXILLARY SPRING)	TATA spare parts
886732000309	ASSY FIRST LEAF WITH BUSH	TATA spare parts
886732000319	TATA DLT 90X13 M/L	TATA spare parts
886732000320	TATA DLT 90X13 2/L	TATA spare parts
886732000321	TATA DLT 90X13 3/L	TATA spare parts
886732000322	TATA DLT 90X13 4/L	TATA spare parts
886732000323	TATA DLT 90X13 5/L	TATA spare parts
886732000324	TATA DLT 90X16 M/L	TATA spare parts
886732000325	TATA DLT 90X16 2/L	TATA spare parts
886732000326	TATA DLT 90X16 3/L	TATA spare parts
886732000327	TATA DLT 90X16 4/L	TATA spare parts
886732000328	TATA DLT 90X16 5/L	TATA spare parts
886732000329	TRACTOR TRAILER 90X16 886332000071 M/L	TATA spare parts
886732000330	TRACTOR TRAILER 90X16 886332000071 2/L	TATA spare parts
886732000331	TRACTOR TRAILER 90X16 886332000071 3/L	TATA spare parts
886732000332	TRACTOR TRAILER 90X16 886332000071 4/L	TATA spare parts
886732000333	TRACTOR TRAILER 90X16 886332000071 5/L	TATA spare parts
886732000334	TRACTOR TRAILER 90X16 886332000071 6/L	TATA spare parts
886732002518	ANTI ROLL BAR BALL JOINT LINK-LPK2528	TATA spare parts
886732003118	ANTI ROLL BAR BALL JOINT LINK ASSY-LPT31	TATA spare parts
886732011618	AIR RUBBER BELLOW FRONT AXLE	TATA spare parts
886732012516	BUSH SET FOR BELL CRANK	TATA spare parts
886732012818	STUB AXLE BALL JOINT-SUPER ACE	TATA spare parts
886732013718	ASSY. MAIN AIR SPRING-3718 TAG AXLE	TATA spare parts
886732014825	ASSY. LIFT AIR SPRING 12.5T LA LPT4825	TATA spare parts
886732021618	AIR RUBBER BELLOW REAR	TATA spare parts
886732022523	ARB LINK ASSY-TML BOGIE SUSP-LPK2523	TATA spare parts
886732024825	ASSY. MAIN AIR SPRING 12.5T LA LPT4825	TATA spare parts
886732031618	REAR RUBBER AIR BELLOW	TATA spare parts
886732034825	ASSY. MAIN AIR SPRING 12.5T LA LPT4825	TATA spare parts
886733000001	BLACK KINGPIN OS2	TATA spare parts
886733000002	BLACK KINGPIN OS3	TATA spare parts
886733000003	BLACK KINGPIN OS4	TATA spare parts
886733000004	BUSHING BEAM ASSY	TATA spare parts
886733000005	BLACK KINGPIN OS1	TATA spare parts
886733000006	BLACK KINGPIN STD	TATA spare parts
886733000007	KIT -AXLE BRG. FRONT (30204+320/32)	TATA spare parts
886733000008	KING PIN PAIR BLACK 1210 STD.35.00	TATA spare parts

88673300009	KING PIN PAIR BLACK 1210 STD. O/S 1 35.1	TATA spare parts
88673300010	KING PIN PAIR BLACK 1210 STD. O/S 2 35.2	TATA spare parts
88673300011	KING PIN PAIR BLACK 1210 STD. O/S 3 35.3	TATA spare parts
88673300012	KING PIN PAIR BLACK 909 STD.32.00	TATA spare parts
88673300013	KING PIN PAIR BLACK 909 STD. O/S 1 32.10	TATA spare parts
88673300014	KING PIN PAIR BLACK 909 STD. O/S 2 32.20	TATA spare parts
88673300015	KING PIN PAIR BLACK 909 STD. O/S 3 32.30	TATA spare parts
88673300016	KING PIN PAIR BLACK 709 STD.30.00	TATA spare parts
88673300017	KING PIN PAIR BLACK 709 STD. O/S 1 30.10	TATA spare parts
88673300018	KING PIN PAIR BLACK 709 STD. O/S 2 30.20	TATA spare parts
88673300019	KING PIN PAIR BLACK 709 STD. O/S 3 30.30	TATA spare parts
88673300020	KING PIN PAIR BLACK 407 STD.25.00	TATA spare parts
88673300021	KING PIN PAIR BLACK 407 STD. O/S 1 25.10	TATA spare parts
88673300022	KING PIN PAIR BLACK 407 STD. O/S 2 25.20	TATA spare parts
88673300023	KING PIN PAIR BLACK 407 STD. O/S 3 25.30	TATA spare parts
88673300024	KING PIN PAIR BLACK 207 STD.20.00	TATA spare parts
88673300025	KING PIN PAIR BLACK 207 STD. O/S 1 20.10	TATA spare parts
88673300026	KING PIN PAIR BLACK 207 STD. O/S 2 20.20	TATA spare parts
88673300027	KING PIN PAIR BLACK 207 STD. O/S 3 20.30	TATA spare parts
88673300028	REPAIR BLACK KING PIN KIT 1612 STD. FULL	TATA spare parts
88673300030	REPAIR KIT KING PIN BALCK 1210 STD. FULL	TATA spare parts
88673300031	REPAIR KIT KING PIN BALCK 909 STD. FULL	TATA spare parts
88673300032	REPAIR KIT KING PIN BALCK 709(608) STD.	TATA spare parts
88673300033	REPAIR KIT KING PIN BALCK 407 STD. FULL	TATA spare parts
88673300034	REPAIR KIT KING PIN BALCK 207 STD. FULL	TATA spare parts
88673300035	REPAIR KIT KING PIN BALCK ACE STD. FULL	TATA spare parts
88673300036	LIFT AXLE BUSH	TATA spare parts
88673300037	LIFT AXLE BUSH	TATA spare parts
88673300041	OIL SEAL FRT HUB BS 1/2/3/4	TATA spare parts
886733000407	TIE ROD ENDS SET-LPT407	TATA spare parts
886733002523	TIE ROD BALL JOINT RH-PRIMA3128	TATA spare parts
886733003118	TIE ROD ENDS SET-LPT3718	TATA spare parts
886733005507	TIE ROD ENDS SET-ULTRA TRUCK	TATA spare parts
886733010407	TIE ROD ENDS SET SFC 407	TATA spare parts
886733012523	TIE ROD BALL JOINT LH-PRIMA3128	TATA spare parts
886733012829	TIE ROD END SOCKET-ACE (LH&RH SET)	TATA spare parts
886733012846	HUB SEAL 6.5T PII	TATA spare parts
886735000001	KIT DIFF CASE	TATA spare parts
886735000002	REAR AXLE SHAFT (W/1684 TRACK) BS4	TATA spare parts
886735000003	REAR AXLE BEARING	TATA spare parts
886735000004	REAR HUBGREASINGKIT O/METAL 2515 CONSIST	TATA spare parts
886735000005	ACE CROWN WHEEL PINION SET - 8/39 4.88	TATA spare parts
886735000008	ACE CROWN WHEEL PINION SET - 9/44 4.88	TATA spare parts
886735000009	CROWN PINION SET ACE 9X40LONG	TATA spare parts
886735000010	SHAFT FOR B G KIT	TATA spare parts
886735000011	REAR AXLE GEAR	TATA spare parts
886735000012	BEVEL PINION	TATA spare parts

886735000013	CWP SET TATA ACE 7X31 RATIO	TATA spare parts
886735000014	CWP SET TATA ACE 8X39 THICK	TATA spare parts
886735000015	CWP SET TATA ACE 9X44 THICK	TATA spare parts
886735000016	CROWN PINION SET ACE 9X44 LONG	TATA spare parts
886735000017	CWP SET TATA ACE 7X36 THIN	TATA spare parts
886735000018	CWP SET TATA ACE 7X36 THICK	TATA spare parts
886735000019	KIT-HUB GREASING O/METAL 1613/4018	TATA spare parts
886735000020	REAR AXLE GEAR (WITH LOW HEIGHT)	TATA spare parts
886735000021	KIT DIFF W/ LOW HEIGHT RA GEAR	TATA spare parts
886735000022	REAR AXLE SHAFT-(947 LENGTH) 1814 TRK	TATA spare parts
886735000023	REAR AXLE SHAFT-(1087 LENGTH) 1814 TRK	TATA spare parts
886735000024	REAR AXLE SHAFT-(992 LENGTH)	TATA spare parts
886735000025	REAR AXLE SHAFT-(1132 LENGTH)	TATA spare parts
886735000026	AXLE SHAFT (RA-109RR REAR AXLE)	TATA spare parts
886735000027	REAR AXLE SHAFT	TATA spare parts
886735000028	REAR AXLE SHAFT	TATA spare parts
886735000040	GEAR SET-6.83 (REAR RWD-2518)	TATA spare parts
886735000041	GEAR SET-6.83 (REAR FWD-2518)	TATA spare parts
886735000042	GEAR SET 6.17 (REAR RWD- 4923)	TATA spare parts
886735000043	GEAR SET-6.17 (REAR FWD-4923)	TATA spare parts
886735000044	GEAR SET-6.83 (REAR RWD-2518)NG	TATA spare parts
886735000045	GEAR SET-6.83 (REAR FWD-2518)NG	TATA spare parts
886735000046	GEAR SET 6.17 (REAR RWD- 4923) NG	TATA spare parts
886735000047	GEAR SET-6.17 (REAR FWD-4923)NG	TATA spare parts
886735000048	GEAR SET-5.83 (REAR RWD- 4923BSII)	TATA spare parts
886735000049	GEAR SET-6.83 (REAR RWD-2516 BSII)	TATA spare parts
886735000050	GEAR SET-6.83 (REAR FWD-2516 BSII)	TATA spare parts
886735000051	PINION - CWP 41/6 0040 RR RWD-2518	TATA spare parts
886735000052	PINION - CWP 41/6 0041 RR FWD-2518	TATA spare parts
886735000053	PINION - CWP 37/6 0042 RR RWD-4923	TATA spare parts
886735000054	PINION - CWP 37/6 0043 RR FWD-4923	TATA spare parts
886735000055	PINION - CWP 41/6 0044 LONGER	TATA spare parts
886735000056	PINION - CWP 41/6 0045 LONGER	TATA spare parts
886735000057	PINION - CWP 37/6 0046 LONGER	TATA spare parts
886735000058	PINION - CWP 37/6 0047 LONGER	TATA spare parts
886735000059	PINION - CWP 35/6 0048 RR RWD 4923 BSII	TATA spare parts
886735000060	PINION - CWP 41/6 0049 RR RWD-2516	TATA spare parts
886735000061	PINION - CWP 41/6 0050 RR FWD-2516	TATA spare parts
886735000062	ASSY DIFFERENTIAL WORM FORGED GEAR KIT	TATA spare parts
886735000063	ASSY DIFF GEAR KIT RA110	TATA spare parts
886735000064	DIFF GEAR KIT W/SPIDER RA108 RR FORGED	TATA spare parts
886735000065	DIFF. HOUSING ASSY WITH GEARS	TATA spare parts
886735000066	SHAFT GEAR-9/16 (I/P SHAFT-IAD)	TATA spare parts
886735000067	SHAFT GEAR-9/16 (I/P SHAFT-IAD)	TATA spare parts
886735000068	SHAFT GEAR 9/16 CONIFLEX (O/P SHAFT-IAD)	TATA spare parts
886735000069	SHAFT GEAR 9/16 CONIFLEX (O/P SHAFT-IAD)	TATA spare parts
886735012726	PINION CWP 41/7 RA110 BS3/4 OLD	TATA spare parts

886735012732	PINION CWP 43/7 RA109RR BS2/3/4/6	TATA spare parts
886735012850	REAR AXLE OIL SEAL - SUPER ACE/MEGA	TATA spare parts
886735015810	PINION CWP 43/7 RA109SRT FWD BS2/3/4/6	TATA spare parts
886735015817	REAR AXLE HUB INNER SEAL ILCV/BUS RA1068	TATA spare parts
886735022726	PINION CWP 41/6 RA110 BS3/4/6	TATA spare parts
886735022732	PINION CWP 41/6 RA109RR BS2/3/4/6	TATA spare parts
886735025810	PINION CWP 41/6 RA109SRT FWD BS3/4/6	TATA spare parts
886735025817	REAR AXLE HUB OUTER SEAL ILCV/BUS RA1068	TATA spare parts
886735032726	PINION CWP 43/7 RA110 BS3/4/6	TATA spare parts
886735032732	PINION CWP 41/7 RA109RR BS2/3/4/6	TATA spare parts
886735035810	PINION CWP 39/7 RA109SRT FWD BS3/4/6	TATA spare parts
886735042732	PINION CWP 45/7 RA109RR BS2/3/4/6	TATA spare parts
886735045810	PINION CWP 41/7 RA109SRT FWD BS2/3/4/6	TATA spare parts
886735052732	PINION CWP 39/7 RA109SRT BS3/4/6	TATA spare parts
886735055810	PINION CWP 45/7 RA109SRT FWD BS4	TATA spare parts
886741000042	ACE UJ CROSS (DIA23.8X60MM)	TATA spare parts
886741000043	ACE UJ CROSS (DIA22X55MM)	TATA spare parts
886741000045	ASSY. CROSS LPT 3118 (DIA 48X134.2MM)	TATA spare parts
886741000046	KIT-U J? LPS 4018	TATA spare parts
886741000047	ASSY. CROSS LPT 2518 (DIA 42X129MM)	TATA spare parts
886741000048	ASSY. CROSS LPK1615 (DIA 42X120MM)	TATA spare parts
886741000049	KIT-UNIVERSAL JOINT W/CIRCLIP 38X57	TATA spare parts
886741000050	U J CROSS 46X68.90	TATA spare parts
886741000051	UJ KIT 41.28X126	TATA spare parts
886741000052	U J CROSS LPT 3718 (52X147)	TATA spare parts
886741000066	U J CROSS LPK 3118/ LPK 2518 (57X152)	TATA spare parts
886741000067	U J CROSS LPT 1109 (34.95X126)	TATA spare parts
886741000068	U J CROSS FOR 407 PICK UP (34.95X106)	TATA spare parts
886741000069	U J CROSS FOR 709 / 909 (30.18X106)	TATA spare parts
886741000070	U J CROSS LPK LPS 4923/3138(47.68 X135)	TATA spare parts
886741000071	U J CROSS FOR 207 DI (27X81.8)	TATA spare parts
886741000072	U J CROSS FOR LPK 3138 / 2538 / 2528 LPT	TATA spare parts
886741005545	U J CROSS FOR INTRA (25X64)	TATA spare parts
886741010909	SLIP YOKE 1109	TATA spare parts
886741010912	SLIP YOKE 909/709	TATA spare parts
886741011312	SLIP YOKE 1312	TATA spare parts
886741012515	CROSS HOLDER 2515	TATA spare parts
886741012518	SLIP YOKE 2518	TATA spare parts
886741012846	CENTER BEARING ASSY 1615/2518/3118BS3/4	TATA spare parts
886741014018	LONG FORK 4018	TATA spare parts
886741015506	CENTER BEARING ASSY ULTRA 812/912/LPO10.	TATA spare parts
886741015532	CENTER BEARING ASSY SFC407 BS3/4	TATA spare parts
886741020709	CROSS HOLDER 709/909	TATA spare parts
886741021312	END PIECE	TATA spare parts
886741022515	REAR HOUSING 2515	TATA spare parts
886741022518	CROSS HOLDER 2518	TATA spare parts
886741024018	LONG FORK 4018	TATA spare parts

886741032515	HALF YOKE 2515	TATA spare parts
886741032518	HALF YOKE 2518	TATA spare parts
886741042515	CROSS HOLDER 2515	TATA spare parts
886741042518	HALF YOKE 2518	TATA spare parts
886741052515	CROSS HOLDER 2515	TATA spare parts
886741052518	CROSS HOLDER 3118/4018	TATA spare parts
886741054018	CROSS HOLDER 3118/4018	TATA spare parts
886741064018	CROSS HOLDER 4018	TATA spare parts
886741074018	CROSS HOLDER 4018	TATA spare parts
886741084018	CROSS HOLDER 3118/4018 LONG	TATA spare parts
886741094018	END PIECE 4018	TATA spare parts
886742000001	KIT-FRONT BRAKE PAD FOR SUPER ACE	TATA spare parts
886742000002	KIT-LINED SHOE ACE & SUPER ACE	TATA spare parts
886742000003	FRONT BRAKE PAD KIT FOR ACE	TATA spare parts
886742000004	BRAKE LINING STD 407 BS1 & 2 (SET OF 4)	TATA spare parts
886742000005	BRAKE LINING OS1 407 BS1 & 2 (SET OF 4)	TATA spare parts
886742000006	BRAKE LINING OS2 407 BS1 & 2 (SET OF 4)	TATA spare parts
886742000009	AL RIVETS 40 PCS (10/12)	TATA spare parts
886742000010	AL RIVETS (10/12)	TATA spare parts
886742000011	BRASS RIVETS L-10	TATA spare parts
886742000012	LOW CARBON STEEL RIVETS (L9)	TATA spare parts
886742000013	AL RIVETS (L10) 407	TATA spare parts
886742000014	KIT LINED SHOE ACE & SUPER ACE (K-TYPE)	TATA spare parts
886742000015	KIT BRAKE LINING(WHEEL SET-Y) WITH RIVET	TATA spare parts
886742000016	BRAKE PAD (207DI-PICKUP-SUV)	TATA spare parts
886742000017	KIT BRAKE LINING (WHEEL SET -Y OS1) WITH	TATA spare parts
886742000018	KIT BRAKE LINING (WHEEL SET -Y OS2) WITH	TATA spare parts
886742000019	BRAKE PAD (MAGIC MANTRA/ACE DICOR)	TATA spare parts
886742000020	AL RIVETS 48 PCS (10/12)	TATA spare parts
886742000021	AL RIVETS 56 PCS (10/12)	TATA spare parts
886742000022	AL RIVETS 52 PCS (10/12)	TATA spare parts
886742000023	AL RIVETS 64 PCS (10/12)	TATA spare parts
886742010207	KIT - BRAKE PAD - 207/PICKUP	TATA spare parts
886742012818	KIT - FRONT BRAKE PAD - SUPER ACE	TATA spare parts
886742012829	VENTILATED BRAKE DISC 17 THICK - ACE	TATA spare parts
886742012845	KIT PAD ASSY (WINGER-K TYPE)	TATA spare parts
886742012898	KIT ½ FRONT BRAKE PAD XENON/YODHA	TATA spare parts
886742022818	FRONT BRAKE DISC BS4 - SUPER ACE	TATA spare parts
886742022829	BRAKE DRUM ACE	TATA spare parts
886742022845	FRONT BRAKE DISC - WINGER	TATA spare parts
886743012829	KIT - FRONT BRAKE PAD - ACE	TATA spare parts
886746000001	STEERING HYDRAULIC FILTER (ZF TYPE)	TATA spare parts
886746000002	STEERING TANK FILTER CARTRIDGE (ZF TYPE)	TATA spare parts
886746000003	CARTRIDGE PLASTIC RESERVOIR	TATA spare parts
886746000004	FILTER ASSY FOR METALLIC TANK	TATA spare parts
886746000005	ASSY. DRAG LINK (407/709/909/712/912)	TATA spare parts
886746000407	DRAG LINK ASSY-LP407	TATA spare parts



886746002818	RACK PINION OUTER BALL JOINT-SUPER ACE	TATA spare parts
886746002829	DRAG LINK ASSY-ACE	TATA spare parts
886746002845	BALL JOINT-WINGER	TATA spare parts
886746003118	DRAG LINK ASSY-LPT3118	TATA spare parts
886746003718	DRAG LINK BALL JOINT SET-LPT3718	TATA spare parts
886746005523	DRAG LINK ASSY-ACE MEGA	TATA spare parts
886746012518	DRAG LINK REPAIR KIT-1618/2518	TATA spare parts
886746012818	RACK PINION INNER BALL JOINT-SUPER ACE	TATA spare parts
886746012845	RACK PINION OUTER BALL JOINT-WINGER	TATA spare parts
886746013118	DRAG LINK BALL JOINT ENDS-LPT3118	TATA spare parts
886746015523	DRAG LINK ENDS-ACE MEGA	TATA spare parts
886746022845	RACK PINION INNER BALL JOINT-WINGER	TATA spare parts
886749000001	FLEX CONNECTOR¿ STD 45X152	TATA spare parts
886749000002	FLEX CONNECTOR 45X170	TATA spare parts
886749000003	FLEX CONNECTOR¿ STD 45X152 WITH EXTENSIO	TATA spare parts
886749000004	FLEX CONNECTOR 45X170 WITH EXTENSION	TATA spare parts
886749000005	FLEX CONNECTOR¿ STD 45X152 ¿LONG LIFE	TATA spare parts
886749000006	FLEX CONNECTOR 45X170 LONG LIFE	TATA spare parts
886749000007	FLEX CONNECTOR¿ STD 45X152 WITH EXTENSIO	TATA spare parts
886749000008	FLEX CONNECTOR 45X170 WITH EXTENSION LON	TATA spare parts
886749011109	Flexible Connector Std 72X 152	TATA spare parts
886749012846	Flexible Con Std 102X353 3SLock LongLife	TATA spare parts
886749021109	Flexible Connector Std 73X 152 with Ext	TATA spare parts
886749031109	Flexible Con Std 73X152 LongLife wth Ext	TATA spare parts
886749041109	Flexible Connector 72X 152 Long Life	TATA spare parts
886750000002	RADIATOR COMPLETE TATA ACE/ MAGIC	TATA spare parts
886750000003	ASSY. RESERVE TANK	TATA spare parts
886750000004	SUPER ACE RADIATOR	TATA spare parts
886750000005	ASSLY RADIATOR SE/SK 1613 BS II (22X21)	TATA spare parts
886750000006	Assly Radiator LPT2518 BS3 (27x21)	TATA spare parts
886750000007	Assly Radiator LPT3118 (31x21)	TATA spare parts
886750000008	Assly Radiator LPS 4018 (29x21) ALK	TATA spare parts
886750000010	SUPER ACE MINT RADIATOR W/O NECK	TATA spare parts
886750000011	ZIP/IRIS RADIATOR	TATA spare parts
886750012898	RADIATOR XENON 4SP BS3/BS4 W/O FRAME	TATA spare parts
886750014103	RADIATOR LPO1618DSL/1623CNGBUS MARCOPO	TATA spare parts
886754000001	BULB -24V P43T100/90	TATA spare parts
886754000002	BULB -12V P43T100/90	TATA spare parts
886754000003	RAIL PRESSURE SENSOR CONNECTOR PIGTAIL	TATA spare parts
886754000004	250 SERIES MALE CONNECTOR PIGTAIL (ALTER	TATA spare parts
886754000005	250 SERIES FEMALE CONNECTOR (ALTERNATOR)	TATA spare parts
886754000006	TEMP SENSOR CONN. PIGTAIL	TATA spare parts
886754000007	TEMP SENSOR 2P FEMALE CONNECTOR	TATA spare parts
886754000008	WATER IN FUEL SENSOR	TATA spare parts
886754000009	VEHICLE SPEED SENSOR 3P CONN. PIGTAIL	TATA spare parts
886754000010	BLADE FUSE HOLDER WITHOUT FUSE	TATA spare parts
886754000011	MAXI FUSE HOLDER (2 PIN)	TATA spare parts

886754000012	FRONT SIDE INDICATOR FEMALE	TATA spare parts
886754000013	FRONT SIDE INDICATOR MALE	TATA spare parts
886754000014	INJECTOR CONNECTOR (FOR DELPHI)	TATA spare parts
886754000015	ACCELERATOR PEDAL SENSOR	TATA spare parts
886754000016	SPEED SENSOR	TATA spare parts
886754000017	FOR 105 C TEMP.	TATA spare parts
886754000018	COTTON TAPE 110-120ç C TEMP. 19MM X 25 M	TATA spare parts
886754000019	CLOTH TAPE 150ç C TEMP. 19MM X 25 MTR	TATA spare parts
886754000020	SPEEDO SENSOR CONNECTOR	TATA spare parts
886754000021	HL LEVELLING MOTOR CONNECTOR 3P	TATA spare parts
886754000022	HEAD LAMP HOLDER (3 PIN)	TATA spare parts
886754000023	BLADE FUSE 5 AMP	TATA spare parts
886754000024	BLADE FUSE 10 AMP	TATA spare parts
886754000025	BLADE FUSE 15 AMP	TATA spare parts
886754000026	BLADE FUSE 20 AMP	TATA spare parts
886754000027	BLADE FUSE 25 AMP	TATA spare parts
886754000028	BLADE FUSE 30 AMP	TATA spare parts
886754000029	BLADE FUSE 40 AMP	TATA spare parts
886754000030	MIDI FUSE 30 AMP	TATA spare parts
886754000031	MIDI FUSE 40 AMP	TATA spare parts
886754000032	MIDI FUSE 50 AMP	TATA spare parts
886754000033	MIDI FUSE 80 AMP	TATA spare parts
886754000034	MEGA FUSE 200 AMP	TATA spare parts
886754000035	MEGA FUSE 250 AMP	TATA spare parts
886754000036	MEGA FUSE 300 AMP	TATA spare parts
886754000037	MEGA FUSE 400 AMP	TATA spare parts
886754000038	MEGA FUSE 500 AMP	TATA spare parts
886754000039	MAXI FUSE 30 AMP	TATA spare parts
886754000040	MAXI FUSE 40 AMP	TATA spare parts
886754000041	MAXI FUSE 50 AMP	TATA spare parts
886754000042	MAXI FUSE 60 AMP	TATA spare parts
886754000043	MAXI FUSE 70 AMP	TATA spare parts
886754000044	MAXI FUSE 80 AMP	TATA spare parts
886754000045	DUAL TEMP SENSOR	TATA spare parts
886754000046	OBD CABLE (2M LENGTH WITH LOCK)	TATA spare parts
886754000047	LAMP 24V 2W M24_5 BA7S TS29201	TATA spare parts
886754000048	LAMP 24V 4W M24_2 BA9S TS29201	TATA spare parts
886754000049	LAMP 24V 10W M24_4 BA15S TS29201	TATA spare parts
886754000050	LAMP P21 24V 21W BA15S E CERT_ECE R37	TATA spare parts
886754000051	BULB P21W _ 24V	TATA spare parts
886754000052	BULB R10W _ 12V	TATA spare parts
886754000053	BULB PY21W - 24V	TATA spare parts
886754000054	LAMP 12V 21W D12/1 BA15S TS29201	TATA spare parts
886754000055	LAMP P21/5 24V 21/5W BAY15D ECE	TATA spare parts
886754000056	BULB W5W 24V 5W W2.1X9.5D E CERT.ECE R37	TATA spare parts
886754000057	BULB W5W - 24V	TATA spare parts
886754000058	BULB P21W - 12V	TATA spare parts

886754000059	BULB P21/5W - 12V	TATA spare parts
886754000060	BULB PY21W - 12V	TATA spare parts
886754000061	BULB P21/5 12V 21/5W BAY15D E CERT.ECE37	TATA spare parts
886754000062	BULB PY21 12V 21W BAU15 E CERT. ECE R37	TATA spare parts
886754000063	BULB C5W 12V 5W	TATA spare parts
886754000064	BULB R10W 24V 10W BA15S E CERT. ECE R37	TATA spare parts
886754000065	BULB R5W-12V	TATA spare parts
886754000066	BULB 12V 10W F12/6 SV8.5 TS29201	TATA spare parts
886754000067	BULB 12V 5W M12/5	TATA spare parts
886754000068	BULB R10W 12V 10W BA15S E.CERT.ECE.R37	TATA spare parts
886760000064	WASHER 52.5X34.5X0.80 FOR BGKIT	TATA spare parts
886760000065	WASHER 33X15.5X0.80 FOR BGKIT	TATA spare parts
886760000066	DOWEL 3X28	TATA spare parts
886767000073	ASSY.GLASS WINDSHIELD	TATA spare parts
886767000074	ASSY.GLASS WIND SCREEN	TATA spare parts
886767012829	ASSY.GLASS WINDSHIELD	TATA spare parts
886767022829	ASSY.GLASS WINDSHIELD	TATA spare parts
886781000067	GLOW PLUG ACE	TATA spare parts
886782000014	SET WIPERS FOR TATA ACE	TATA spare parts
886782000015	"WIPER BLADE DRIVER SIDE 500MM (20""")"	TATA spare parts
886782000016	Wiper Blade Co-Driver Side 356mm (14")	TATA spare parts
886782000017	WIPER BLADE24INCH BOLT FIT + SKT RH 2518	TATA spare parts
886782000018	SUPPORT ROD 24INCH WIPER BLADE RH 2518	TATA spare parts
886782000019	WIPER BLADE24INCH BOLT FIT +ROD RH 2518	TATA spare parts
886782000020	WIPER BLADE24INCH BOLT FITLH 2518/SIGNA4	TATA spare parts
886782000023	WIPER BLADE 21INCH BOLT FIT 1613	TATA spare parts
886782000025	WIPER BLADE20INCH BOLT FIT W/O BALL RH S	TATA spare parts
886782000026	WIPER BLADE 20INCH U FIT 9X3 RH -ACE	TATA spare parts
886782000027	WIPER BLADE 17INCH U FIT 9X3 LH-ACE	TATA spare parts
886782000029	WIPER BLADE20INCH BOLT FIT + BALL RH SFC	TATA spare parts
886782000030	SUPPORT ROD -20INCH WIPER BLADE RH SFC40	TATA spare parts
886782000031	WIPER BLADE20INCH BOLT FIT + ROD RH SFC4	TATA spare parts
886782000032	WIPER BLADE 17INCH BAYONET FIT 1613	TATA spare parts
886782000033	WIPER BLADE 21INCH UNI FIT WINGER	TATA spare parts
886782000039	WIPER BLADE 26INCH BOLT FIT START BUS	TATA spare parts
886782000041	WIPER BLADE 19INCH U FIT LH INTRA	TATA spare parts
886782000042	WIPER BLADE 22INCH BOLT FIT ULTRA 1412	TATA spare parts
886782000043	WIPER BLADE 14INCH BAYONET FIT IRIS	TATA spare parts
886799000001	METAL O SEAL - LIQUID GASKET MAKER 25 GM	TATA spare parts
886799000002	METAL O SEAL - LIQUID GASKET MAKER 85 GM	TATA spare parts
886799012829	OIL & FUEL FILTER KIT -ACE	TATA spare parts
886799015717	OIL & FUEL FILTER KIT-ZIP IRIS	TATA spare parts
886825270159	PROLIFE 497 NA PTFE LONG BLOCK (EX 70)	TATA spare parts
886825270302	PROLIFE 497 TCIC PTFE LONG BLOCK (TH76)	TATA spare parts
886825340161	PROLIFE 4 SP LONG BLOCK HARVESTER	TATA spare parts
8870259	COVER DETENT	TATA spare parts
8870343	TH. WASHER REV IDLER	TATA spare parts

8870352	PLUNGER-SYNCHRO	TATA spare parts
8870415	SYNCHRO FLANGE REV.	TATA spare parts
8870444	SPRING COMPRESSION	TATA spare parts
8870587	SPRING COMPRESSION	TATA spare parts
8870588	SPEEDO PINION	TATA spare parts
8870590	GASKET	TATA spare parts
8870808	SPACER	TATA spare parts
8870848	REACTION PLATE RETAIN	TATA spare parts
8871098	SPRING COMPRESSION	TATA spare parts
8871374	SPRING RETAINING CUP	TATA spare parts
8871478	WASHER M 8	TATA spare parts
8871481	STOP WASHER	TATA spare parts
8871639	SYNCHRO FLANGE 2/3	TATA spare parts
8871992	REAR COVER	TATA spare parts
8872006	SELECTOR FORK 4TH/5TH	TATA spare parts
8872007	SELECTOR FORK 2/3	TATA spare parts
8872059	COVER DETENT	TATA spare parts
8872069	SELECTOR BLOCK	TATA spare parts
8872233	NEEDLE ROLLER BEARING	TATA spare parts
8872445	BUSHING SEL. SHAFT	TATA spare parts
8872478	NEEDLE ROLLER BRG	TATA spare parts
8872479	SPACER REV. IDLER BRG	TATA spare parts
8872484	SPACER 3.70MM	TATA spare parts
8872588	SPACER 4TH GEAR	TATA spare parts
8872589	SPACER 2ND GEAR	TATA spare parts
8872626	RANGE SHIFT ROD	TATA spare parts
8872634	SELECTPR FORK 1ST/REV	TATA spare parts
8872636	SPACER	TATA spare parts
8872639	BUSH SPRING RETAINING	TATA spare parts
8872644	INNER STRIKING LEVER	TATA spare parts
8872649	HOUSING LRC- RH	TATA spare parts
8872680	GEAR ANNULUS	TATA spare parts
8872682	PLANET GEAR SPINDLE	TATA spare parts
8872731	SELECTOR KEY	TATA spare parts
8872732	INTERLOCK KEY	TATA spare parts
8872733	COVER FRONT	TATA spare parts
8872734	SELECT.SHAFT	TATA spare parts
8872737	RANGE SHIFT FORK	TATA spare parts
8872779	SHAFT REV. IDLER	TATA spare parts
8873041	SLIDING SLEEVE	TATA spare parts
8873133	SPEEDO HOUSING MECH.	TATA spare parts
8873511	COUPLING FLANGE	TATA spare parts
8873551	COUPLING FLANGE	TATA spare parts
8873571	COMPANION FLANGE	TATA spare parts
8873645	SPRING COMPRESSION	TATA spare parts
8873654	PLUNGER NEUTRAL	TATA spare parts
8873691	LOCATION SCREW M10X23	TATA spare parts

8873734	GASKER	TATA spare parts
8873917	RR COVER LAYSHAFT	TATA spare parts
8873918	SPACER-ROTOR	TATA spare parts
8873952	BRACKET SUPPORT	TATA spare parts
8874026	LIFTING EYE STRAIGHT	TATA spare parts
8874037	SYNCHRO FLANFE RANGE	TATA spare parts
8874143	INTERMEDIATE CASE	TATA spare parts
8874367	REAR CASE	TATA spare parts
8874921	OIL MUFF	TATA spare parts
8874923	SYNCHRO FLANGE	TATA spare parts
8875027	THRUST WASHER	TATA spare parts
8875135	SYNCHRO RING	TATA spare parts
8875179	PISTON RANGE	TATA spare parts
8875183	SYNCHRO RANGE	TATA spare parts
8875196	BEARING SLEEVE 2ND	TATA spare parts
88752588	SPACER 4TH GEAR	TATA spare parts
8875267	INTERLOCK PIN	TATA spare parts
8875293	BUSH	TATA spare parts
8875376	SLIDING SLLEVE CRAWLER RR	TATA spare parts
8875377	SLIDING SLEEVE 2/3	TATA spare parts
8875415	PLUNGER DETENT	TATA spare parts
8875430	CYLINDER RANGE	TATA spare parts
8875554	FIXED HUB 3/4	TATA spare parts
8875571	FIXED HUB 1/2	TATA spare parts
8875585	GEAR SUN	TATA spare parts
8875586	GEAR PLANET	TATA spare parts
8875604	FIXED HUB CRAWLER/REV	TATA spare parts
8875646	REACTION PLATE	TATA spare parts
8875879	SPACER 2.5/2.3 MM	TATA spare parts
8875881	FIXED HUB SYNCHRO RANGE	TATA spare parts
8875929	FRONT CASE	TATA spare parts
8875987	RANGE CON.VALVE ASSY	TATA spare parts
8876041	END COVER	TATA spare parts
8876083	SPEEDO DRIVE GEAR 9T	TATA spare parts
8876166	SYNCHRO FLANGE 3RD/4TH	TATA spare parts
8876353V	OIL STRAINCR ASSYL.	TATA spare parts
8876416	SWITCH REVERSE	TATA spare parts
8876438	GEAR MAIN SHAFT 3RD	TATA spare parts
8876439	GEAR MAIN SHAFT 2ND	TATA spare parts
8876441	MAIN SHAFT GEAR 1ST	TATA spare parts
8876457	GEAR REVERSE IDLER	TATA spare parts
8876477	GR. MAINSHAFT CRAWLER	TATA spare parts
8876478	MAINSHAFT GR REVERSE	TATA spare parts
8876724	INPUT SHAFT	TATA spare parts
8876871	BEARING COVER	TATA spare parts
8877184	CROSS SHAFT RH	TATA spare parts
8877185	OUTER LEVER	TATA spare parts

8877657	LEVER INNER STRIKING	TATA spare parts
8878020	GEAR MAINSHAFT 1ST	TATA spare parts
8878028	GEAR MAINSHAFT 2ND	TATA spare parts
8878030	SLEEVE-MAINSHAFT BEARING	TATA spare parts
8878040	GEAR MAINSHAFT CRAWLER	TATA spare parts
8878044	SLIDING SLEEVE CRAWLER	TATA spare parts
8878051	GEAR MAINSHAFT REV	TATA spare parts
8878120	SPINDLE PLANET	TATA spare parts
8878125	THRUST WASHER	TATA spare parts
8878150	GEAR REVERSE IDLER	TATA spare parts
8878163	PISTON RANGE CYLINDER	TATA spare parts
8878223	SYNCHRO FLANGE	TATA spare parts
8878240	BUSH	TATA spare parts
8878326	SELECTOR SHAFT	TATA spare parts
8878373	SLEEVE-MAINSHAFT BEARING	TATA spare parts
8878376	GEAR MAINSHAFT 3RD	TATA spare parts
8878445	PIN-DIA14	TATA spare parts
8878446	MAINSHAFT	TATA spare parts
8878503	SYNCHRO RING-RANGE	TATA spare parts
8878504	SLIDING SLEEVE SYNCHRO	TATA spare parts
8878506	HUB-FIXED RANGE SYNCHRO	TATA spare parts
8878517	HUB-FIXED CRAW/REV	TATA spare parts
8878518	FLANGE SYNCHRO CRAWLER	TATA spare parts
8878547	HIGH/LOW RANGE SHIFT ROD	TATA spare parts
8878594	SLIDING 1ST/2ND/3RD/4TH	TATA spare parts
8878689	OIL MUFF	TATA spare parts
8878775	FIXED HUB 1ST/2ND	TATA spare parts
8878776	FIXED HUB 3RD/4TH	TATA spare parts
8878781	FORK 3RD/4TH	TATA spare parts
8878783	FORK CRAWLER/REVERSE	TATA spare parts
8878883	FORK 1ST/2ND	TATA spare parts
8878934	INTERMEDIATE CASE	TATA spare parts
8878939	SPACER	TATA spare parts
8879047	PLANET GEAR	TATA spare parts
8879048	GEAR-SUN	TATA spare parts
8879052	FRONT BEARING COVER	TATA spare parts
8879055	INPUTSHAFT	TATA spare parts
8880069	REVERSE IDLER SHAFT	TATA spare parts
8880638	SEAL	TATA spare parts
8882415	BUSHING	TATA spare parts
888838900630	FUEL FILTER SEC. ELEMENT	TATA spare parts
888839036400	FUEL FILTER PRIM ELEMENT	TATA spare parts
888839086150	OIL FILTER CARTRIDGE	TATA spare parts
88893	SHIM 0.254 MM	TATA spare parts
88894	SHIM 0.510 MM	TATA spare parts
889447000279M	ARC FLASH SUIT 12 Cal/cm2 (Jacket/Trouse)	TATA spare parts
889447000280	Arc Flash Shield with Head Band	TATA spare parts

889447000281	Insulating Blanket 1.5mX1m(Transparent)	TATA spare parts
889923170001	COGGED V-BELT ENG. TO A/C COMPRESSOR	TATA spare parts
889923170002	COGGED V-BELT COMP. TO ALTERN.	TATA spare parts
889926170001	VOITH CABLE 9 MTS	TATA spare parts
889932170007	AIR BELLOW ASSY	TATA spare parts
889932170008	LEVELLING VALVE	TATA spare parts
889932170012	PRESSURE REDUCER VALVE	TATA spare parts
889942170002	POLYMIDE PIPE12/9MM_25M	TATA spare parts
889942170003	POLYMIDE PIPE 8/6MM_25M	TATA spare parts
889942170004	POLYMIDE PIPE 6/4MM_25M	TATA spare parts
889973170011	DOUBLE SOLENOID VALVE 24V	TATA spare parts
889973170018	HANDLE LEVER VALVE	TATA spare parts
89000340068	CLINCHER	TATA spare parts
89970146	SEALING RING	TATA spare parts
8GA002071241	BULB-24V 5W(R5W)	TATA spare parts
8GA002071251	BULB-24V 10W(R10W)	TATA spare parts
8GA002073241	BULB-24V 21W(P21W)	TATA spare parts
8GP003594251	BULB-24V 5W(W5W)	TATA spare parts
90003074340	AXLE PACKING RING	TATA spare parts
90003098026	PACKING RING	TATA spare parts
90003326067	ROW STEP ROLLER BEARING	TATA spare parts
90003326148	ROW STEEP ROLLER BEARING	TATA spare parts
90003326167	ROW STEEP ROLLER BEARING	TATA spare parts
90003326236	ROW STEEP ROLLER BEARING	TATA spare parts
90003326443	ROW TAPERED ROLLER BEARING	TATA spare parts
90003326445	ROW TAPERED ROLLER BEARING	TATA spare parts
90003326547	ROW STEEP ROLLER BEARING	TATA spare parts
90003330148	STEEL BALL	TATA spare parts
90003810631	STUD	TATA spare parts
90003812630	STUD	TATA spare parts
90003884160	WHEEL NUT	TATA spare parts
90003888457	HEX NUT	TATA spare parts
90003888459	SELF LOCKING NUT	TATA spare parts
90003901704	COLUMN PIN	TATA spare parts
90003901804	PIN	TATA spare parts
90003903661	PIN AXLE	TATA spare parts
90003933300	CIRCLIP FOR AXLE	TATA spare parts
90003933351	CIRCLIP FOR AXLE	TATA spare parts
90003933428	CIRCLIP FOR AXLE	TATA spare parts
90003934520	CIRCLIP FOR HOLE	TATA spare parts
90003936114	TAPER THREAD GREASE NIPPLE	TATA spare parts
90003961309	SQUARE HEAD TAPERED PLUG	TATA spare parts
90003962021	HEX PLUG SCREW	TATA spare parts
90003963114	TAPER THREAD GREASE NIPPLE	TATA spare parts
90003964418	Y-TYPE HINGE	TATA spare parts
90003989290	BOWLING CHOKE PLUG	TATA spare parts
9001036202	CAB COMPLT RHD SLEEPER	TATA spare parts

9001037000	CAB COMPLT RHD SLEEPER	TATA spare parts
90078	CAP SCREW-SHORT	TATA spare parts
9008-099AM	X NOZZLE ASSEMBLY	TATA spare parts
9009049	X SOLENOID	TATA spare parts
9010410550	HEX BOLT M10X1.25	TATA spare parts
9010458552	HEX BOLT M8X1.25	TATA spare parts
9010508800	HEX BOLT M8X1.25	TATA spare parts
9010560700	HEX BOLT	TATA spare parts
9010560800	HEX BOLT M10X1.25	TATA spare parts
9010608930	BOLT-GUIDE FIX	TATA spare parts
90114000	TAIL GATE LOCKING MECHANISM	TATA spare parts
9014610605	HEX BOLT M10X1.5	TATA spare parts
9016510450	FLANGE BOLT M10X1.25	TATA spare parts
9019006160	HEX BOLT W/WASHER	TATA spare parts
9019006200	BOLT-W/WASHER M6X1.0	TATA spare parts
9019008200	BOLT-W/WASHER M8X1.25	TATA spare parts
9019010160	BOLT-W/WASHER M10X1.25	TATA spare parts
9019106160	BOLT-LOCK WASHER	TATA spare parts
9019106250	BOLT-W/WASHER M6X1.0	TATA spare parts
9019108200	BOLT-W/WASHER	TATA spare parts
9019108250	BOLT-W/SP WASHER M8X1.25	TATA spare parts
9019110300	HEX BOLT W/WASHER M10X1.25	TATA spare parts
9019112300	BOLT-W/WASHER M12X1.25	TATA spare parts
9019112400	HEX BOLT W/WASHER M12X1.25	TATA spare parts
9019608200	BOLT-W/WASHER M8X1.25	TATA spare parts
9019708160	BOLT-W/WASHER M8X1.25	TATA spare parts
9019708200	BOLT-W/WASHER M8X1.25	TATA spare parts
9019708208	BOLT-W/WASHER M8X1.25	TATA spare parts
9019910350	HEX BOLT W/WASHER M10X1.5	TATA spare parts
90203555686	MAGNETIC STICK 6X300 WITH HANDLE	TATA spare parts
90203555694	.MAGNETIC STICK 8X300 W/HANDLE CRYSTAL	TATA spare parts
90203567455	CROWFOOT WR-19MM	TATA spare parts
90203742109	MAGNETIC DIAL GAUGE STAND	TATA spare parts
9020406400	STOPPER BOLT-M6X1.0	TATA spare parts
9020408160	HEX BOLT M8X1.25	TATA spare parts
9020408200	HEX BOLT M8X1.25	TATA spare parts
9020408250	HEX BOLT M8X1.25	TATA spare parts
9020408280	HEX BOLT M8X1.25	TATA spare parts
9020408350	HEX BOLT M8X1.25	TATA spare parts
9020408400	HEX BOLT M8X1.25	TATA spare parts
9020410160	BOLT-HEX HEAD M10X1.25	TATA spare parts
9020410250	HEX BOLT M10X1.25	TATA spare parts
9020410300	HEX BOLT M10X1.25	TATA spare parts
9020410600	HEX BOLT M10X1.25	TATA spare parts
9020510350	HEX BOLT M10X1.25	TATA spare parts
9020510400	HEX BOLT M10X1.25	TATA spare parts
9020510408	HEX HEAD BOLT M10X1.25	TATA spare parts



9020510500	HEX BOLT M10X1.25	TATA spare parts
9020510508	HEX BOLT M10X1.25	TATA spare parts
90206269188	BULB 24V 70W H11	TATA spare parts
9023510280	HEX BOLT M10X1.5	TATA spare parts
90300784	C.E. BRACKET	TATA spare parts
9030101	BRIDGE WIRE	TATA spare parts
90301014	P TERMINAL INSULATING PLATE	TATA spare parts
90301154	SHIMS 0-10MM	TATA spare parts
90301155	CHECK NUT BIG	TATA spare parts
90301246	SEALING RING	TATA spare parts
903012828	NAME PLATE ASSY	TATA spare parts
90301296	ALTERNATOR 24V 80A 6PULLEY	TATA spare parts
90301358	FIXING STUD	TATA spare parts
90301378	THRUST PLATE	TATA spare parts
90301391	STATER (24V)	TATA spare parts
90301513	CHECK NUT BIG	TATA spare parts
90301524	P LEAD	TATA spare parts
90301603	HEAT SINK ASSY. AUX	TATA spare parts
90301688	D-E BRACKET	TATA spare parts
90301765	DUST COVER	TATA spare parts
90301938	HEAT SINK ASSY. P	TATA spare parts
90301939	HEAT SINK ASSY. N	TATA spare parts
9030209	ARMATURE 24 V	TATA spare parts
9030214	N TERMINAL LOCK PLATE	TATA spare parts
9030216	THROUGH BOLT	TATA spare parts
9030229	BRUSH TIXING SCREW	TATA spare parts
9030298A	PLUNGER	TATA spare parts
9030315C	BRUSH BOX	TATA spare parts
9030330	Aquila Track TS101 Basic	TATA spare parts
9030340B	BRUSH	TATA spare parts
9030375D	SM CLUTCH	TATA spare parts
9030382	FIXING SCREW	TATA spare parts
9030401	PRESSURE SPRING	TATA spare parts
9030402	LOCK RING	TATA spare parts
9030436	C.E. COVER RUBBER RING	TATA spare parts
9030471	FAN SPACER	TATA spare parts
9030472	SPACER	TATA spare parts
90304A	M TERMINAL	TATA spare parts
9030501	OIL TAP SCREW	TATA spare parts
903051	MAIN FIELD COIL 24 V	TATA spare parts
903052	AUDILIARY FIELD COIL 24 VS	TATA spare parts
9030534	C.E. COVER STUD	TATA spare parts
9030535	SOLENIOD TERMINAL	TATA spare parts
9030610	PIPE TC TO IC	TATA spare parts
9030623	PIPE TC TO IC	TATA spare parts
9030633A	PRESSURE LINE ASSY	TATA spare parts
9030644	NOX SENSOR NA050G218	TATA spare parts

9030661	INSULATING BRUSH	TATA spare parts
9030681	POLE SCREW	TATA spare parts
9030683	CLUTCH VISCOUS	TATA spare parts
9030688B	FLY WHEEL RING	TATA spare parts
9030693	RUBBER BUSH	TATA spare parts
9030695	OIL DIPSTICK TUBE.	TATA spare parts
9030747	TOP WASHER	TATA spare parts
903076	SOLENOID TERMINAL BUSH	TATA spare parts
903076C	C.E. BRACKET	TATA spare parts
903077	BRUSH GEAR 24 V	TATA spare parts
9030774A	P TERMINAL	TATA spare parts
9030775D	C.E. COVER	TATA spare parts
9030776	CLUTCH INNER RACE FIBER	TATA spare parts
9030859AA	PINION (STEEL) T 9	TATA spare parts
9030859E	PINION	TATA spare parts
9030876	KIT 3/94 REALY	TATA spare parts
9030945160	SCREW-MACHINE	TATA spare parts
9030951	BRASS TEE 12 NO.	TATA spare parts
9030998	SM POLE SCREW (S)	TATA spare parts
9034906200	MACHINE SCREW-PAN HD M6X1.0	TATA spare parts
9034908200	SCREW-PAN HD M8X1.25	TATA spare parts
9039004160	SCREW WITH PLAIN WASHER	TATA spare parts
9039006160	SCREW WITH P/WASHER-PAN HD	TATA spare parts
9039205120	SCREW W/WASHER	TATA spare parts
9039206200	MACH SCREW W/WASHER	TATA spare parts
9041100272	HIGH RPM PROTECTION	TATA spare parts
904111	END YOKE1615	TATA spare parts
9041144H	X PUMP PRIMING	TATA spare parts
90414	LOCK WASHER	TATA spare parts
90415	LOCK WASHER	TATA spare parts
90422	LOCK WASHER	TATA spare parts
9050000000	ASSEMBLY	TATA spare parts
90507801926	SWAGELOK MAKE PTFE TAPE THREAD SEALANT	TATA spare parts
9051106100	BOLT-FLANGE M6X1.0	TATA spare parts
9051106140	BOLT-FLANGE M6X1.0	TATA spare parts
9051106180	HEX FLANGE BOLT M6X1.0	TATA spare parts
9051108140	FLANGE BOLT M8X1.25	TATA spare parts
9051108200	BOLT-FLANGE M8X1.25	TATA spare parts
9051108250	FLANGE BOLT M8X1.25	TATA spare parts
9051200000	ASSY SPACER BLOCK COMPLETE	TATA spare parts
9051206180	HEX FLANGE BOLT M6X1.0	TATA spare parts
9051206200	HEX FLANGE BOLT M6X1.0	TATA spare parts
9051208140	FLANGE BOLT M8X1.25	TATA spare parts
9051208200	FLANGE BOLT M8X1.25	TATA spare parts
9051208300	FLANGE BOLT M8X1.25	TATA spare parts
9051210200	HEX FLANGE BOLT M10X1.25	TATA spare parts
9051210250	FLANGE BOLT M10X1.25	TATA spare parts

9051210300	FLANGE BOLT M10X1.25	TATA spare parts
9051210350	FLANGE BOLT M10X1.25	TATA spare parts
9051210450	FLANGE BOLT M10X1.25	TATA spare parts
9051210600	FLANGE BOLT M10X1.25	TATA spare parts
9055560200	HEX BOLT-W/WASHER M10X1.5	TATA spare parts
9058210250	SOCKET BOLT M10X1.25	TATA spare parts
906032103201	CENTRE PIN	TATA spare parts
9067513520	RIVET A13	TATA spare parts
9070344200	SCREW-S/TAP	TATA spare parts
9070656160	SCREW-TAP PAN HEAD	TATA spare parts
9070665200	TAPPING SCREW M5	TATA spare parts
9070685160	SCREW-TAP PAN HEAD	TATA spare parts
907078000228	ASSY.BRACKET/FAIL SAFE	TATA spare parts
9081116180	SPLIT PIN	TATA spare parts
9081125220	SPLIT PIN	TATA spare parts
9081150400	SPLIT PIN	TATA spare parts
9081180700	SPLIT PIN	TATA spare parts
9082038280	JOINT PIN	TATA spare parts
9082038620	JOINT PIN	TATA spare parts
9082240280	JOINT PIN	TATA spare parts
9082336160	JOINT PIN	TATA spare parts
90876	COTTER PIN RH	TATA spare parts
9090310060	GREASE NIPPLE	TATA spare parts
9090310100	GREASE NIPPLE	TATA spare parts
9090311100	GREASE NIPPLE	TATA spare parts
9090312100	GREASE NIPPLE	TATA spare parts
9091104060	HEX NUT M6X1.0	TATA spare parts
9091104080	HEX NUT M8X1.25	TATA spare parts
9091104100	HEX NUT M10X1.25	TATA spare parts
9091105080	HEX NUT M8X1.25	TATA spare parts
9091105100	HEX NUT M10X1.25	TATA spare parts
9091105220	HEX NUT	TATA spare parts
9091114080	HEX NUT M8X1.25	TATA spare parts
9091114100	HEX NUT M10X1.25	TATA spare parts
9091123100	HEX NUT M10X1.25	TATA spare parts
9091140880	WELD NUT-M8X1.25	TATA spare parts
9091151060	FLANGE NUT M6X1.0	TATA spare parts
9091151080	FLANGE NUT M8X1.25	TATA spare parts
9091151088	HEX NUT M8X1.25	TATA spare parts
9091151100	FLANGE NUT M10X1.25	TATA spare parts
9091152080	FLANGE NUT M8X1.25	TATA spare parts
9091152100	HEX FLANGE NUT M10X1.25	TATA spare parts
9091152108	FLANGE NUT M10X1.25	TATA spare parts
9091304080	NUT-LOCK M8X1.25	TATA spare parts
9091304100	NUT-LOCK M10X1.25	TATA spare parts
9091314120	NUT-LOCK M12X1.25	TATA spare parts
9091315140	SELF LOCK NUT M14X1.5	TATA spare parts

9091505040	SPRING WASHER	TATA spare parts
9091505060	SPRING WASHER	TATA spare parts
9091505080	SPRING WASHER	TATA spare parts
9091505100	SPRING WASHER	TATA spare parts
9091505120	SPRING WASHER	TATA spare parts
9091505140	SPRING WASHER	TATA spare parts
9091505160	SPRING WASHER	TATA spare parts
9091505200	SPRING WASHER	TATA spare parts
9091505220	SPRING WASHER	TATA spare parts
9091506100	SPRING WASHER	TATA spare parts
9091506120	SPRING WASHER	TATA spare parts
9091506140	SPRING WASHER	TATA spare parts
9091506160	SPRING WASHER	TATA spare parts
9091506180	SPRING WASHER	TATA spare parts
9091506240	SPRING WASHER	TATA spare parts
9091512200	LOCK WASHER	TATA spare parts
9091605050	PLAIN WASHER	TATA spare parts
9091605080	PLAIN WASHER	TATA spare parts
9091605100	PLAIN WASHER	TATA spare parts
9091605120	PLAIN WASHER	TATA spare parts
9091606060	PLAIN WASHER	TATA spare parts
9091606120	PLAIN WASHER	TATA spare parts
9091607050	PLAIN WASHER	TATA spare parts
9091607060	PLAIN WASHER	TATA spare parts
9091607080	PLAIN WASHER	TATA spare parts
9091607100	PLAIN WASHER	TATA spare parts
9091643100	PLAIN WASHER	TATA spare parts
9091645080	PLAIN WASHER	TATA spare parts
9091645100	PLAIN WASHER	TATA spare parts
9091645140	PLAIN WASHER	TATA spare parts
9091646080	PLAIN WASHER	TATA spare parts
9091646100	PLAIN WASHER	TATA spare parts
9091646180	PLAIN WASHER	TATA spare parts
9091647160	PLAIN WASHER	TATA spare parts
9091648100	PLAIN WASHER	TATA spare parts
9091800380	SNAP RING	TATA spare parts
9091804800	SNAP RING	TATA spare parts
9091854060	SNAP RING- E TYPE	TATA spare parts
9091854080	SNAP RING-TYPE E	TATA spare parts
9092230080	UNION-2W	TATA spare parts
9092252120	UNION-ELBOW	TATA spare parts
9095245350	CLIP-TYPE A3	TATA spare parts
9095258320	CLIP-A3 TYPE(D19)	TATA spare parts
9095258350	CLIP-A3 TYPE(D19)	TATA spare parts
9095451060	CLIP-D1	TATA spare parts
9096106082	NYLON TUBE	TATA spare parts
9096106400	NYLON TUBE	TATA spare parts

9096108054	NYLON TUBE	TATA spare parts
9096108220	NYLON TUBE	TATA spare parts
9096112020	NYLON TUBE	TATA spare parts
9096112030	NYLON TUBE	TATA spare parts
9096112046	NYLON TUBE	TATA spare parts
9096112048	NYLON TUBE	TATA spare parts
9096112054	NYLON TUBE	TATA spare parts
9096112068	NYLON TUBE	TATA spare parts
9096112086	NYLON TUBE	TATA spare parts
9096112092	NYLON TUBE	TATA spare parts
9096112102	NYLON TUBE	TATA spare parts
9096112161	NYLON TUBE	TATA spare parts
9096112168	NYLON TUBE	TATA spare parts
9096112182	NYLON TUBE	TATA spare parts
9096112204	NYLON TUBE	TATA spare parts
9096115120	NYLON TUBE	TATA spare parts
9096115164	NYLON TUBE	TATA spare parts
9096406032	NYLON TUBE	TATA spare parts
9096408094	NYLON TUBE	TATA spare parts
9096408098	NYLON TUBE	TATA spare parts
9096408160	NYLON TUBE	TATA spare parts
9096408204	NYLON TUBE	TATA spare parts
9096408222	NYLON TUBE	TATA spare parts
9096410104	NYLON TUBE	TATA spare parts
9096410146	NYLON TUBE	TATA spare parts
9096410290	NYLON TUBE	TATA spare parts
9096412064	NYLON TUBE	TATA spare parts
9096412158	NYLON TUBE	TATA spare parts
9096412186	NYLON TUBE	TATA spare parts
9096412188	NYLON TUBE	TATA spare parts
9096412232	NYLON TUBE	TATA spare parts
9096412250	NYLON TUBE	TATA spare parts
9096415138	NYLON TUBE	TATA spare parts
9096415380	NYLON TUBE	TATA spare parts
9096708070	NYLON TUBE	TATA spare parts
9096708118	NYLON TUBE	TATA spare parts
9096708462	NYLON TUBE	TATA spare parts
9096708486	NYLON TUBE	TATA spare parts
9096708498	NYLON TUBE	TATA spare parts
9096708530	NYLON TUBE	TATA spare parts
9096710080	NYLON TUBE	TATA spare parts
9096710450	NYLON TUBE	TATA spare parts
9096710730	NYLON TUBE	TATA spare parts
9096712540	NYLON TUBE	TATA spare parts
9096712560	NYLON TUBE	TATA spare parts
911001010001	BULB H11 HEADLAMP LOW BEAM	TATA spare parts
911001010002	BULB H1 HEADLAMP HIGH BEAM	TATA spare parts

911001010004	BULB ROOF MARKER LAMP (FRONT AND REAR)	TATA spare parts
911001010005	BULB FUSE BOX MAINTENANCE	TATA spare parts
911001010006	BULB FUSE BOX MAINTENANCE LAMP	TATA spare parts
911001010008	BULB TAIL LAMP (PARKING AND BRAKE LAMPS)	TATA spare parts
911001010009	BULB (SIDE MARKER LAMP FRONT PARKING L	TATA spare parts
911001010018	HIGH MOUNTED STOP LAMP_12V_LAPL	TATA spare parts
911001010023	SIDE MARKER LAMP_12V_NEO	TATA spare parts
911001010024	FRONT ROOF MARKER LAMP 12V NEO BS6-PH2	TATA spare parts
911001010025	REAR ROOF MARKER LAMP 12V NEO BS6-PH2	TATA spare parts
911001010026	FRONT TURN SIGNAL LAMP_12V BS6	TATA spare parts
911001010027	AIS 153 EMERGENCY LIGHTING SYSTEM_12V BS	TATA spare parts
911001010028	AIS 153 EMERGENCY LIGHTING SYSTEM_12V BS	TATA spare parts
911001010033	SPOT LIGHT FOR AMBULANCE 12V BS6-PH2	TATA spare parts
911001020001	FUSE BOX MAINTENANCE BULB 21W / 24V	TATA spare parts
911001020002	HEAD LAMP HIGH BEAM	TATA spare parts
911001020003	HEAD LAMP LOW BEAM	TATA spare parts
911001020004	ROOF MARKER LAMP (FRONT & REAR)	TATA spare parts
911001020005	BULB21W*24V-(TAILLAMP(BLINKERANDREVERSE	TATA spare parts
911001020006	BULB15W*24V-(FUSEBOXMAINTENANCELAMP)	TATA spare parts
911001020007	BULB10W*24V-(DRIVERLUMINARY)	TATA spare parts
911001020009	BULB5/21W*24V-TAILLAMP(PARKINGANDBRAKE	TATA spare parts
911001020010	BULB2W*24V-(DASHBOARDINDICATORLAMP)	TATA spare parts
911001020011	FRONT FOG LAMP BULB H11_70W_24V	TATA spare parts
911001020013	DOOR LAMP LED 24V	TATA spare parts
911001020019	HIGH MOUNTED STOP LAMP_24V_LAPL	TATA spare parts
911001020047	FRONT ROOF MARKER LAMP_24V_NEO	TATA spare parts
911001020048	REAR ROOF MARKER LAMP_24V_NEO	TATA spare parts
911001020049	SIDE INDICATOR&MARKER_NEO_1544	TATA spare parts
911001020050	DRIVER & CO DRIVER LAMP_GRENTO BS6	TATA spare parts
911001020051	MAINTENANCE LAMP_GRENTO 12/24V BS6	TATA spare parts
911001020052	MAINTENANCE LAMP_GRENTO 12/24V BS6	TATA spare parts
911001020056	LICENCE PLATE LED LAMP 12/24V BS6	TATA spare parts
911001020063	TRIANGULAR BERTH LOCATOR LAMP RH BS6	TATA spare parts
911001020064	TRIANGULAR BERTH LOCATOR LAMP_LH BS6	TATA spare parts
911001020084	READING LAMP_24V_AARVI SHINX BS6	TATA spare parts
911001020086	LED LUMINARY 1870MM_24V BS6	TATA spare parts
911001020087	LED STRIP WITH AL PROFILE_550MM BS6	TATA spare parts
911001020105	TRAIANGULAR BERTH LAMP RH LAST ROW BS6	TATA spare parts
911001020106	TRAIANGULAR BERTH LAMP LH LAST ROW BS6	TATA spare parts
911001030001	BULB AMBER FRONT TURN INDICATOR	TATA spare parts
911001030002	BULB DRIVER LUMINARY	TATA spare parts
911001030004	BULB 5W*24V-GLASS BASE	TATA spare parts
911001030005	BULBAMBER21W*24V-(FRONTTURNINDICATOR)	TATA spare parts
911002010003	CONTACT RELAY_12V	TATA spare parts
911002020003	HIGH CURRENT RELAY	TATA spare parts
911002020004	HIGH CURRENT RELAY_24V 100A	TATA spare parts
911003010001	SWITCH FOR INTERNAL LAMP	TATA spare parts

911003010002	SWITCH FOR DRIVER LAMP	TATA spare parts
911003010003	SWITCH FOR MAINTENANCE LAMP	TATA spare parts
911003010004	STOP REQUEST SWITCH	TATA spare parts
911003010006	FOG LAMP SWITCH	TATA spare parts
911003010007	MOBILE CHARGER_12V	TATA spare parts
911003010013	S/W FOR FOG LAMP 12V/24V	TATA spare parts
911003010014	EMERGENCY HELP SWITCH_12V	TATA spare parts
911003010024	AC SWITCH	TATA spare parts
911003010025	SWITCH INTERNAL LAMP 2 STAGE 12V FF BS6-	TATA spare parts
911003010026	SWITCH DRIVER LAMP 12V FF BS6-PH2	TATA spare parts
911003010028	SWITCH MAINTAINANCE LAMP 12V FF BS6-PH2	TATA spare parts
911003020004	STOP ARM SWITCH	TATA spare parts
911003020008	EMERGENCY DECLARATION S/W	TATA spare parts
911003020010	EMERGENCY HELP SWITCH_24V	TATA spare parts
911003020014	PANIC BUTTON-NC TYPE_POWER ELECTRONIC	TATA spare parts
911003020020	DRIVER FAN SWITCH 12/24V (FOURFRONT) BS6	TATA spare parts
911003020021	DESTINATION BOARD SW 12/24V (FOURFRONT)	TATA spare parts
911003020022	DRIVER LAMP SWITCH 12/24V (FOURFRONT) BS	TATA spare parts
911003020024	MAINTENANCE LAMP SW 12/24V (FOURFRONT) B	TATA spare parts
911003020025	TV SWITCH 12/24V (FOURFRONT) BS6	TATA spare parts
911003020026	ELS SWITCH 12/24V (FOURFRONT) BS6	TATA spare parts
911003020027	INTERNAL LAMP SW 12/24V (FOURFRONT) BS6	TATA spare parts
911003020039	USB CHARGER SWITC 12/24V (FOUR FRONT) BS	TATA spare parts
911003020043	3 MODULE SWITCH BOARD BS6	TATA spare parts
911003040003	SOCKET WITH SWITCH 220V 3PIN	TATA spare parts
911003040005	INVERTER SWITCH	TATA spare parts
911003040006	MOBILE HOLDER WITH POWER SOCKET	TATA spare parts
911003040007	SOCKET WITH SWITCH 220V 2/3PIN	TATA spare parts
911003040008	MAINTENANCE LUGGAGE BHOOT SWITCH	TATA spare parts
911003040012	MONITOR SWITCH	TATA spare parts
911003040015	DRIVER FAN SWITCH_10A	TATA spare parts
911003040016	DRIVER LAMP SWITCH_10A	TATA spare parts
911003040017	INTERNAL LAMP SWITCH_10A	TATA spare parts
911003040018	EXHAUST FAN SWITCH 10A	TATA spare parts
911003040019	BEACON LAMP SWITCH_10A	TATA spare parts
911003040020	SIRON SWITCH_10A	TATA spare parts
911003040021	COVER FOR SWITCH HOLE_40X20MM	TATA spare parts
911003040023	S/W SPST 6A MAINTENANCE LAMP	TATA spare parts
911003040024	S/W SPST 6A DRIVER LAMP	TATA spare parts
911003040025	S/W SPST 6A FAN	TATA spare parts
911003040026	S/W SPST 6A DEFROSTER	TATA spare parts
911003040027	S/W SPST 6A FOG LAMP	TATA spare parts
911003040028	S/W SPST 6A DESTINATION BOARD	TATA spare parts
911003040029	S/W SPST 6A VIDEO MONITOR	TATA spare parts
911003040030	S/W SPST 6A NIGHT LAMP	TATA spare parts
911003040031	S/W SPST 6A ARM CHAIR	TATA spare parts
911003040032	S/W SPST 6A READING LAMP	TATA spare parts

911003040033	S/W SPST 6A INVERTER	TATA spare parts
911003040034	S/W SPST 6A EXHAUST FAN	TATA spare parts
911003040035	S/W SPST 6A STOP ARM	TATA spare parts
911003040036	S/W DPDT 6A INTERNAL LAMP	TATA spare parts
911003040037	S/W DPDT 6A WINDSHIELD WIPER	TATA spare parts
911003040039	S/W DPST 6A M/A STOP REQUEST RESET	TATA spare parts
911003040040	SWITCH BOARD-2 SWITCHES & 2 SOCKETS	TATA spare parts
911003040041	SWITCH BOARD-1 SWITCHES & 1 SOCKETS	TATA spare parts
911003040042	SWITCH BOARD-4 SWITCHES	TATA spare parts
911003040043	EXTERNAL SUPPLY AC 230V SOCKETS	TATA spare parts
911003040045	SWITCH BOARD-4 SWITCHES & 4 SOCKETS	TATA spare parts
911003040047	PANIC BUTTON ITS	TATA spare parts
911003040048	EMERGENCY DECLARATION SWITCH	TATA spare parts
911003040049	WI-FI SWITCH	TATA spare parts
911003040052	3 SOCKET +3 SWITCH BOARD	TATA spare parts
911003050001	DRIVER FAN SWITCH	TATA spare parts
911003050003	BUTTON SWITCH ASSY-DEFROSTER	TATA spare parts
911003050004	DOOR OPENING LIMIT S/W _ INDICAT BUZZER	TATA spare parts
911003050005	DESTINATION BOARD SWITCH	TATA spare parts
911003050006	WINDSHIELD WIPER SWITCH	TATA spare parts
911003050007	BUTTON SWITCH	TATA spare parts
911003050010	SWITCH ASSY MONITOR	TATA spare parts
911003050016	DOOR OPENING LIMIT S/W BS6	TATA spare parts
911004010002	DESTINATION BOARD LED LAMP	TATA spare parts
911004010003	LED ILLUMINURY _FLUSH TYPE _12V	TATA spare parts
911004010004	ROOF LAMP _12V _POWER ELECTRONIC BS6	TATA spare parts
911004010005	ROOF LAMP _12V _645MM BS6	TATA spare parts
911004010006	LED ILLU LAMP 645MM 12V WITH NIGHT LAMP	TATA spare parts
911004010007	LED LUMINARY 1180MM WITH NIGHT LAMP12V	TATA spare parts
911004010012	BEACON LAMP	TATA spare parts
911004010013	INTERNAL LAMP 500MM 12V BS6-PH2	TATA spare parts
911004020002	TYPE-E (ROUND) TYPE TUBE LIGHT 24V	TATA spare parts
911004020016	LED LAMP 24V _1200MM POWER ELECTRONICS	TATA spare parts
911004020019	LED ROOF LAMP 110*400 LAMP	TATA spare parts
911004020020	LED LUMINURY FLAT _INVEL	TATA spare parts
911004020021	LED LAMP _(PE) _645MM	TATA spare parts
911004020023	LED LUMINARY LAMP _INVEL	TATA spare parts
911004020032	LED LUMINARY 645 MM WITH NIGHT LAMP 24V	TATA spare parts
911004020033	LED LUMINARY 1180MM WITH NIGHT LAMP 24V	TATA spare parts
911004030003	FLUORESCENT LAMP -15 W	TATA spare parts
911004040001	LED STRIP	TATA spare parts
911004040003	LED STRIP	TATA spare parts
911004050002	LED LUMINARY	TATA spare parts
911004050004	LED FIRST LUMINARY	TATA spare parts
911004050005	LED MIDDLE LUMINARY	TATA spare parts
911004050006	LED END LUMINARY	TATA spare parts
911004050008	LED LAMP ASSEMBLY	TATA spare parts



911005040001	FUSE 30 A	TATA spare parts
911005040002	FUSE 5 A	TATA spare parts
911005040003	FUSE 10 A	TATA spare parts
911005040004	Diode 24V-2A	TATA spare parts
911005040006	INVERTOR FOR MOBILE CHARGING(24V/150VA)	TATA spare parts
911005040007	TOGGLE SWITCH 12V/24V	TATA spare parts
911005040009	DOOR LAMP SET-24V	TATA spare parts
911005040010	POSITION SENSOR(MAGNETIC SENSOR)	TATA spare parts
911005040011	MAGNET FOR MAGNETIC SENSOR	TATA spare parts
911005040012	TUBE LIGHT (20 WATT)	TATA spare parts
911005040015	FUSE 15 AMP	TATA spare parts
911005040016	SPEAKERS 4INCH WITH GRILLE	TATA spare parts
911005040017	FORCED AIR ENGINE	TATA spare parts
911005040020	A/C SWITCH 5A_230V_5PIN	TATA spare parts
911005040024	MAIN FUSE 100A	TATA spare parts
911005050001	FUSE HOLDER	TATA spare parts
911006010001	FRONT DOOR OPEN(RED)¿ D BOARD SIGNA 12V	TATA spare parts
911006010002	STOP REQUESTED SIGNAL _AMBER_12V	TATA spare parts
911006010003	REVERSE GEAR ALARAM-12V	TATA spare parts
911006010008	REAR DOOR OPEN(RED) _D BOARD SIGNA_12V	TATA spare parts
911006010010	EMERGENCY DOOR OPEN_ INDICATOR 12V_RED	TATA spare parts
911006010011	ELECTRIC FAN (12VDC)	TATA spare parts
911006010013	ROOF MOUNT MONITOR_19¿ TFT	TATA spare parts
911006010015	SIDE DIREC INDICATOR LAMP _LH_12V_CAT 6	TATA spare parts
911006010016	SIDE DIREC INDICATOR LAMP_RH_12V_CAT 6	TATA spare parts
911006010017	SIDE DIREC INDIC LAMP_LH_12V FIEM_CAT-6	TATA spare parts
911006010018	SIDE DIREC INDIC LAMP_RH_12V FIEM_CAT-6	TATA spare parts
911006010020	ACTIA AMPLIFIER VB2020R DC 12V	TATA spare parts
911006010023	HIGH MOUNTED STOP LAMP	TATA spare parts
911006010024	SIDE INDICATOR LAMP ASSY NEOLITE LH 12V	TATA spare parts
911006010025	SIDE INDICATOR LAMP ASSY_NEOLITE_RH_12V	TATA spare parts
911006010030	ELECTRIC FAN (12VDC)	TATA spare parts
911006010036	REAR VIEW CAMERA AND WIRE HARNESS	TATA spare parts
911006010058	ELECTRIC FAN_12V_AARVI SHINX	TATA spare parts
911006010065	AIS 153 EMERGENCY LIGHTING SYSTEM_12V	TATA spare parts
911006010066	AIS 153 EMERGENCY LIGHTING SYSTEM_12V	TATA spare parts
911006010068	AIS_153 ELS GT_12V	TATA spare parts
911006010075	INTERNAL DESTINATION BOARD CHEMITO BS6	TATA spare parts
911006010079	TOUCH SCREEN DISPLAY_12V_CHEMITO EV	TATA spare parts
911006010080	REVERSE CAMERA_12V_CHEMITO EV	TATA spare parts
911006010081	HANDHELD MICROPHONE_12V_CHEMITO EV	TATA spare parts
911006010082	GPS+LTE+WIFI COMBINATION ANTENA_CHEMITO	TATA spare parts
911006010083	MINI DOME CAMERA_12V_CHEMITO EV	TATA spare parts
911006010084	EXTERNAL POWER SOCKET CABLE	TATA spare parts
911006010085	INVERTER FOR AMBULANCE	TATA spare parts
911006010088	AMPLIFIER (140 X 45)	TATA spare parts
911006010091	ELECTRICAL SWITCH BOARD	TATA spare parts

911006010092	EXTERNAL 12V BATTERY CHARGER SOCKET	TATA spare parts
911006010095	LOUDSPEAKER	TATA spare parts
911006010096	INTERCOM	TATA spare parts
911006010099	MIC_12V	TATA spare parts
911006010101	INTERCOM 02	TATA spare parts
911006010103	WASHER PUMP AMBULANCE	TATA spare parts
911006010104	FOOT OPERATING SWITCH AMBULANCE	TATA spare parts
911006010105	AN WITH PLASTIC HSNG 12V W/O SWITCH BS6	TATA spare parts
911006010109	SPEAKER EHC 10 BS6	TATA spare parts
911006010110	AMPLIFIER INTRA_12V BS6	TATA spare parts
911006010111	SPEAKER INTRA GT_12V BS6	TATA spare parts
911006010112	MIC INTRA GT_12V BS6	TATA spare parts
911006010116	INTERNAL_MINI DOME CAMERA_12V	TATA spare parts
911006010118	REVERSE PARKING CAMERA IPC CHEMITO	TATA spare parts
911006010119	SPEAKER W/O GRILL CHEMITO_102X102	TATA spare parts
911006010120	HANDHELD MICROPHONE CHEMITO	TATA spare parts
911006010122	DRIVER FAN_12V_PLASTIC HOUSING_SHINX BS6	TATA spare parts
911006020001	REVERSE GEAR ALARM	TATA spare parts
911006020005	ELECTRIC FAN 24V	TATA spare parts
911006020006	CABIN ROOF LAMP RELAY	TATA spare parts
911006020008	STOP REQUEST TIMER RELAY_24V	TATA spare parts
911006020009	DASH BOARD INDICATOR-FRONT DOOR OPEN	TATA spare parts
911006020010	DASH BOARD INDICATOR-REAR DOOR OPEN	TATA spare parts
911006020011	DASH BOARD INDICATOR LAMP-STOP REQUEST S	TATA spare parts
911006020012	EMERGENCY DOOR OPEN_INDICATOR 24V_RED	TATA spare parts
911006020013	ELECTRIC FAN_24VDC (CG)	TATA spare parts
911006020014	SEAT BELT-INDICATOR	TATA spare parts
911006020015	MOBILE CHARGER_24V	TATA spare parts
911006020016	SIDE DIRECTION INDICATOR LAMP LH-CAT-6	TATA spare parts
911006020017	SIDE DIREC INDICATOR LAMP RH 24V CAT-6	TATA spare parts
911006020020	SIDE DIREC INDIC LAMP_LH_24V CAT-6	TATA spare parts
911006020021	SIDE DIREC INDIC LAMP_RH_24V CAT-6	TATA spare parts
911006020022	REVERSE GEAR ALARM_24V	TATA spare parts
911006020028	FRONT FOG LAMP INDICATOR 24V	TATA spare parts
911006020029	DESTINATION BOARD KPIT MOUD II	TATA spare parts
911006020030	DESTINATION INTERNAL BOARD KPIT MOUD II	TATA spare parts
911006020033	FRONTDESTINATIONBOARDKPITMOUDII	TATA spare parts
911006020035	INNER DESTINATION BOARD 910	TATA spare parts
911006020040	DRIVER DOOR LED LAMP	TATA spare parts
911006020046	MOBILE CHARGER DUAL USB	TATA spare parts
911006020047	SIDE INDICATOR LAMP ASSY NEOLITE LH 24V	TATA spare parts
911006020048	SIDE INDICATOR LAMP ASSY RH 24V	TATA spare parts
911006020053	ELECTRIC FAN_24VDC (CG)	TATA spare parts
911006020056	FRONT DESTINATION BOARD_HANNOVER	TATA spare parts
911006020056C	FRONT DESTINATION BOARD_HANNOVERCORE	TATA spare parts
911006020057	SIDE AND REAR DESTINATION BOARD_HONNOVE	TATA spare parts
911006020058	INTERNAL DESTINATION BOARD_HANNOVER	TATA spare parts

911006020060	PASSENGER FAN WITH SWITCH 24V	TATA spare parts
911006020064	REAR DESTINATION BOARD	TATA spare parts
911006020066	IBDC CONTROLLER	TATA spare parts
911006020069	7 REAR VIEW MONITOR TROPICOOOL	TATA spare parts
911006020071	FRONT DESTINATION BOARD HANOVER	TATA spare parts
911006020072	REAR DESTN BOARD HANOVER W/O CONTROLLER	TATA spare parts
911006020073	HYDRAULIC ROOF MOUNTED TV 24	TATA spare parts
911006020079	ROOF MOUNTED TV TROPICOOOL 24	TATA spare parts
911006020083	DIGITAL CLOCK _ INVEL	TATA spare parts
911006020084	DESTINATION BOARD INBUILT IBDC CHEMITO	TATA spare parts
911006020100	ELECTRIC FAN_24V_AARVI SHINX	TATA spare parts
911006020106	MICROPHONE	TATA spare parts
911006020108	SURVEILLANCE CAMERA HANNOVER	TATA spare parts
911006020109	BUS DRIVER CONSOLE HANNOVER	TATA spare parts
911006020115	WALL MOUNT TV 24 TROPICOOOL BS6	TATA spare parts
911006020125	AIS 153 EMERGENCY LIGHTING SYSTEM_24V	TATA spare parts
911006020126	AIS 153 EMERGENCY LIGHTING SYSTEM_24V	TATA spare parts
911006020135	SIS_153 ELS GT_24V	TATA spare parts
911006020137	ELS BATTERY & CONTROLLER_24V_MAGNA_GT B	TATA spare parts
911006020139	ELS BATTERY& CONTROLLER_MAGNA_24V SHINX	TATA spare parts
911006020145	DVD_TROPICOOOL BS6	TATA spare parts
911006020146	IBDC_WITH ACCESORIES_CHEMITO BS6	TATA spare parts
911006020152	FRONT DESTINATION BOARD_CHEMITO EV	TATA spare parts
911006020153	SIDE DESTINATION BOARD_CHEMITO EV	TATA spare parts
911006020154	REAR DESTINATION BOARD_CHEMITO EV	TATA spare parts
911006020155	INBUS DESTINATION BOARD_CHEMITO EV	TATA spare parts
911006020156	FOOT PEDAL SWITCH_12/24V_CHEMITO EV	TATA spare parts
911006020157	VTS(AIS140)_12/24V_CHEMITO EV	TATA spare parts
911006020158	EMERGENCY HELP SWITCH_12/24V_CHEMITO EV	TATA spare parts
911006020160	FRONT DEST BOARD_CHEMITO_1888X290MM	TATA spare parts
911006020165	FAN WITH PLASTIC HSG_24V BS6	TATA spare parts
911006020166	FAN 24V WITH REGULATOR BS6	TATA spare parts
911006020168	OBU UNIT_CHEMITO_9X12	TATA spare parts
911006020201	ANALOG REVERSE CAMERA 12V2MP_CHEMITO	TATA spare parts
911006020202	OBU WITH E_SIM & IRNSS CHEMITO	TATA spare parts
911006020203	DRIVER FAN_24V_PLASTIC HOUSING_SHINX BS6	TATA spare parts
911006020207	USB CHARGER 24V TROPICOOOL BS6	TATA spare parts
911006020210	STOP SIGNAL ARM WITH LAMP	TATA spare parts
911006030003	ELECTRONIC POWER INTERVER 150W 24V	TATA spare parts
911006030006	24 INCH WALL MOUNTING TYPE LCD	TATA spare parts
911006030007	4WATT 4INCH SPEAKER WITHOUT GRILL	TATA spare parts
911006030008	4WATT 4INCH SPEAKER WITH GRILL MOUD2	TATA spare parts
911006030011	SPEAKER WITH GRILL_CHEMITO EV	TATA spare parts
911006040001	DC-DC CONVERTER(24V TO 12V/10AMP)	TATA spare parts
911006040002	ISOLATED DC TO DC POWER SUPPLY CARBON	TATA spare parts
911006040003	AC SOCKET 220V 6A DUAL	TATA spare parts
911006050001	CONNECTION TERMINAL-CHASSIS	TATA spare parts

911006050004	LOUD SPEAKERS	TATA spare parts
911006050007	CONVERTERç 24V TO12V_DC 10A	TATA spare parts
911006050008	DEMISTER MOTOR	TATA spare parts
911006050009	AMLIFIER	TATA spare parts
911006050016	SPEAKERçç 4ç AC DUCT WITH OUT GRILL	TATA spare parts
911006050018	DVDç PLAYER	TATA spare parts
911006050019	CONVERTER DC TO DC (12V TO 24V)	TATA spare parts
911006050020	GPS SYSTEM_TM3000 IN BUILT ANTENNA	TATA spare parts
911006050022	AUDIO VIDEO CABLE 6.5METER	TATA spare parts
911006050023	ROOF MOUNT MONITOR 17ç TFT LCD CRM-1701	TATA spare parts
911006050026	MICROPHONE	TATA spare parts
911006050027	PA AMP&DIGITAL PLAYER	TATA spare parts
911006050031	DVD PLAYER	TATA spare parts
911006050032	WALL MOUNT LED MONITOR 22	TATA spare parts
911006050036	SEAL PLUG	TATA spare parts
911006050040	ADAPTER CHASSIS DIMMER SWITCH	TATA spare parts
911006050059	BUS DRIVER CONSOLE STAND SHORT	TATA spare parts
911006050060	GOOSE NECK MICç MOUD II	TATA spare parts
911006050061	HEADPHONE WITH MIC KPIT MOUD II	TATA spare parts
911006050063	DIGITAL CLOCK	TATA spare parts
911006050069	LED LUMINARY JUNCTION CAP	TATA spare parts
911006050070	LED LUMINARY SIDE CAP	TATA spare parts
911006050072	ADAPTOR FOR ITS EMERGENCY SWITCH	TATA spare parts
911006050074	SIDE MARKER LAMP LED 12V/24V	TATA spare parts
911006050085	VOICE ANNOUNCEMENT MIC	TATA spare parts
911006050086	VOICE CALLING HEADPHONE KPIT	TATA spare parts
911006050088	SAMSUNG LED MONITOR WITH 24	TATA spare parts
911006050089	VIDEO EXTENSION CABLE 3METRES(TROPICCOOL)	TATA spare parts
911006050090	VIDEO EXTENSION CABLE 10M(TROPICCOOL)	TATA spare parts
911006050091	VIDEO EXTENSION CABLE 5M(TROPICCOOL)	TATA spare parts
911006050092	VIDEO EXTENSION CABLE 15M(TROPICCOOL)	TATA spare parts
911006050101	MOBILE HOLDER	TATA spare parts
911006050104	SD CARD TYPE_256GB_TROPICCOOL BS6-PH2	TATA spare parts
911006050105	MIC_FOR CONTROLLER_CHEMITO BS6	TATA spare parts
911006050110	OBU UNIT_CHEMITO EV	TATA spare parts
911007050001	MALE CONNECTOR FOR MALE TERMINAL (EXT)	TATA spare parts
911007050004	FEMALE CONNECTOR (STOP REQ.)	TATA spare parts
911007050005	MALE CONNECTORç 1ç POLEç FASTIN-FASTON	TATA spare parts
911008050002	MALE TERMINAL (EXTERNAL LAMP)	TATA spare parts
911008050004	MALE TERMINAL (STOP REQ.)	TATA spare parts
911008050005	FEMALE TERMINAL (STOP REQUEST SWITCH)	TATA spare parts
911008050007	MALE TERMINAL (FOR MOTOR)	TATA spare parts
911009050002	SEALING RUBBER (STOP REQ.)	TATA spare parts
911010040001	DIODE IN 4007	TATA spare parts
911011010010	BATTERY 12V 80AH	TATA spare parts
911012010004	REVERSING SURVEILLANCE CAM 12 MOUD2	TATA spare parts
911012010005	SCN CAMERA KPIT 12V MOUD II	TATA spare parts

911012010010	DOME CAMERA-IP BASED_ PE	TATA spare parts
911012010015	GPS UNIT 12V BS6	TATA spare parts
911012010016	EXTERNAL CAMERA WITH SIM & 16GB SD CARD	TATA spare parts
911012020001	TAIL LAMP-RED 24V- BLINKER	TATA spare parts
911012020002	BUS DRIVER CONSOLEç 24V IP66	TATA spare parts
911012020002C	BUS DRIVER CONSOLE 24V IP66CORE	TATA spare parts
911012020003	SINGLE CONTROL UNIT 24V IP66	TATA spare parts
911012020004	GPS GSM WIFI COMBI ANTENNA	TATA spare parts
911012020005	4 CHANNEL AHD DVR	TATA spare parts
911012020006	PASSENGER SALOON CAMERA	TATA spare parts
911012020007	REVERSE CAMERA TROPICOOOL	TATA spare parts
911012020008	TFT MONITOR TROPICOOOL	TATA spare parts
911012020009	SINGLE CONTROL UNIT KPIT 24V LINUX	TATA spare parts
911012020009C	SINGLE CONTROL UNIT KPIT 24V LINUXCORE	TATA spare parts
911012020017	REVERSE CAMERA HANNOVER	TATA spare parts
911012020020	PASSENGER SALOON IP CAMERA	TATA spare parts
911012020021	REVERSE IP CAMERA POWER ELECTRONICS	TATA spare parts
911012020022	TFT MONITOR POWER ELECTRONICS	TATA spare parts
911012020024	CAMERA CABLE 3 MTR	TATA spare parts
911012020025	CAMERA CABLE 5MTR	TATA spare parts
911012020026	CAMERA CABLE 15MTR	TATA spare parts
911012020040	SIDE CAMERA_ TROPICOOOL BS6	TATA spare parts
911012050011	HARD DISC CAPACITY 1000GB	TATA spare parts
9111539252	REAR SEAL / ADAPTER KIT MAJOR	TATA spare parts
9111549202	HEAD ASM. KIT SINGLE 75MM US PORTS	TATA spare parts
9111549212	CONN ROD ASM. KIT SINGLE 75MM MAJOR	TATA spare parts
9111549222	PISTON ASM. KIT SINGLE 75MM MAJOR	TATA spare parts
9111549242	HEAD GASKET KIT SINGLE 75MM MAJOR	TATA spare parts
9111549302	SUMP PLUG KIT	TATA spare parts
9111559212	GASKET KIT 85 MM	TATA spare parts
9115159262	SPLINE ADAPTER 11TH	TATA spare parts
9121034004	ROTOR ASSY	TATA spare parts
9121034502	SHIM 1.96 MM	TATA spare parts
9121037303	RECTIFIER	TATA spare parts
9121037306	RECTIFIER ASSY 709 SFC	TATA spare parts
913001010003	PLASTIC T JOINT	TATA spare parts
913001010005	PLASTIC BASE FOR STANDING PIPE	TATA spare parts
913001010006	GANGWAY GRABRAIL TOP SUPPORT	TATA spare parts
913001010008	GRAB RAIL RUBBER BASE EXTERNAL DIA 22.5	TATA spare parts
913001010010	6.1 DIA GRAB RAIL SUPPORT	TATA spare parts
913001010017	SPEAKER GRILLE FRONT & REAR	TATA spare parts
913001010018	RADIO COVER	TATA spare parts
913001010020	RUBBER END CAP	TATA spare parts
913001010022	GRABRAIL END FINISHING COVER	TATA spare parts
913001010023	PLASTIC BASE FOR HANDHOLD TUBE	TATA spare parts
913001010024	HANDHOLD PLASTI JOINT	TATA spare parts
913001010025	HAND HOLD PLASTIC T- JOINT 36/36 _EVO 2	TATA spare parts

913001010026	HAND HOLD PLASTIC T- JOINT 36/44 _EVO 2	TATA spare parts
913001010027	PLASTIC BASE D51/H42_ HANDHOLD _EVO 2	TATA spare parts
913001010028	PLASTIC BASE D41/H41_ HANDHOLD _EVO 2	TATA spare parts
913001010029	HANDHOLD PLASTIC JOINT	TATA spare parts
913001010032	PLASTIC BASE SUPPORT FOR HAND HOLD TUBE	TATA spare parts
913001010033	SINGLE AC LOUVER(BIG)	TATA spare parts
913001010034	DUCT CLOSING WITHOUT LOUVERS	TATA spare parts
913001010058	GRABRAIL¿ END FINSHNG COVER OF ID35_ EVO2	TATA spare parts
913001010059	GRABRAIL SUPPORT BRACKET 340_ LN _ID36.5	TATA spare parts
913001010061	BOTTLE HOLDER BS6	TATA spare parts
913001013001	AIR DUCT CLOSING	TATA spare parts
913001013002	AIR DRIVING GUIDE	TATA spare parts
913001013003	AIR DRIVING GUIDE	TATA spare parts
913001013004	LOUDSPEAKER GRILLE	TATA spare parts
913001013005	DOOR LOCK COVER	TATA spare parts
913001013006	END COVER FOR EXTERNAL PANELING	TATA spare parts
913001013007	RH END COVER¿ FOR WHEEL ARCH FINISHING	TATA spare parts
913001013008	LH END COVER FOR WHEEL ARCH FINISHING	TATA spare parts
913001013009	GRAB RAIL END FININSHING COVER	TATA spare parts
913001013010	NORMAL T-SHAPED PLASTIC JOINT	TATA spare parts
913001013011	GANGWAY GRAB RAIL SUPPORT	TATA spare parts
913001013012	PLASTICS BASE FOR STANDING PIPE 33DIA	TATA spare parts
913001013013	LOUD SPEAKER GRILL Y1	TATA spare parts
913001013014	HANDHLD PLSTC JONT (DIA44 TO DAI36)	TATA spare parts
913001013017	PP GRAB HAND HOLD BLACK	TATA spare parts
913001013023	PP SCREW CAP WITH WASHER	TATA spare parts
913001013025	PVC SCREW CAP WITH WASHER(RAL 7024) BS6	TATA spare parts
913001013026	PARTITION DOOR FINISHING PART BS6	TATA spare parts
913001013027	PLASTIC BASE D40 HANDHOLD RAL8024	TATA spare parts
913001013028	PLASTIC BASE SUPPORT DIA 40MM	TATA spare parts
913001013032	PP SCREW CAP WITH WASHER	TATA spare parts
913001013033	PP SCREW CAP WITH WASHER(RAL7046)	TATA spare parts
913001013045	PLASTIC SHOE	TATA spare parts
913001020004	PARTITION GLASS HOLDING BRACKET	TATA spare parts
913001020007	CURTAIN BRACKETS	TATA spare parts
913001020029	4.6 MMX202 LN BLACK CABLE TIE	TATA spare parts
913001020031	POLYAMIDE BUSH	TATA spare parts
913001020032	WINDOW GUARD RAIL CLAMP -OPEN END	TATA spare parts
913001020033	WINDOW GUARD RAIL CLAMP -CLOSED END	TATA spare parts
913001023001	POWER ATTACHING SUPPORT	TATA spare parts
913001023002	CURTAIN RING HOLDER	TATA spare parts
913001023013	WINDOW GUARD RAIL CLAMP OPEN END	TATA spare parts
913001023014	WINDOW GUARD RAIL CLAMP CLOSED END	TATA spare parts
913001023016	INTEGRATED WINDOW GUARD RAIL CLAMP BS6	TATA spare parts
913001023017	INTEGRATED WINDOW GUARD RAIL CLOSED BS6	TATA spare parts
913001023020	3TYP WINDOW GUARD RAIL CLAMP -OPEN END B	TATA spare parts
913001023021	3TYP WINDOW GUARD RAIL CLAMP -CLOSE END	TATA spare parts

913001033001	AIR CONDITIONING DUCT EXTREMITY FINISH.	TATA spare parts
913001033002	AIR CONDITIONING DUCT EXTREMITY FINISH.	TATA spare parts
913001050001	DRIVER HANDHOLD 01	TATA spare parts
913001053001	AIR DRIVING GUIDE	TATA spare parts
913001053002	LUMINARY REACTOR COVER	TATA spare parts
913001053003	FIXING CLIP BRACKET	TATA spare parts
913001080003	HAND HOLD ATTACHING SUPPORT PLATE	TATA spare parts
913001080004	PILLAR ATTACHING SUPPORT BUSHING FOR 36D	TATA spare parts
913001080005	PILLAR ATTACHING SUPPORT BUSHING FOR 44	TATA spare parts
913001080006	PILLARG SUPPORT BUSHING FOR D44/H78	TATA spare parts
913001170001	COVER FOR SWITCH KEYS	TATA spare parts
913001170008	AC_LOUVER SMALL ROUND	TATA spare parts
913001170010	AC LOUVER EVO 01 LIGHT GREY	TATA spare parts
913001170011	DASHBOARD INDICATOR LAMP COVER	TATA spare parts
913001170028	FLUORSCENT LAMP CLAMP	TATA spare parts
913001175002	COVER FOR BUTTON SWITCH_44X22	TATA spare parts
913002010001	PNEUMATIC SWITCH COVER	TATA spare parts
913002050002	RUBBER JAMB	TATA spare parts
913002060005	RUBBER PROFILE	TATA spare parts
913002060006	SOLID RUBBER PROFILES	TATA spare parts
913002060010	SOLID RUBBER PROFILE (EVO3)	TATA spare parts
913002060011	SOLID RUBBER PROFILES EVO 3 GRAY	TATA spare parts
913002060012	SOLID RUBBER PROFILE _EVO 1	TATA spare parts
913002060015	PASTED GLASSES SUPPORT RUBBER 1	TATA spare parts
913002060025	RUBBER FOR SIDE EXT PANEL G2	TATA spare parts
913002060041	PP GRAB HAND HOLD BLACK	TATA spare parts
913002080001	FLEXIBLE RUBBER PROFILE FOR WHEEL ARCH	TATA spare parts
913002080003	RUBBER BEADING (GR LEVER BOTTOM BKT.)	TATA spare parts
913002080004	RAIN GUTTER FINISHING RU. PRFL. BLACK	TATA spare parts
913002080017	WEAT.STRIP(PASS.DR-FLAP/SH)	TATA spare parts
913002080018	WEAT.STRIP(PASS.DOOR.BIG B)	TATA spare parts
913002080019	WEAT.STRIP(PASS.DR-MDL.SMA)	TATA spare parts
913002080036	RUBBER BEADING (LHS RAIN CHANNEL)	TATA spare parts
913002080037	WHEEL ARCH FINSHING RUBBER PROFILE	TATA spare parts
913002080038	SOLID RUBBER PROFILE FOR DRVR PARTITION	TATA spare parts
913002150001	RUBBER FOR CUTOUT SEALENT	TATA spare parts
913002150002	DOOR SEALING RUBBER	TATA spare parts
913002150004	SPL RUBBER WATER OUTLET TAP	TATA spare parts
913002150010	FRONT INTERNAL FINISH RUBBER	TATA spare parts
913002150014	SOLID RUBBER PROFILE FORç DOOR	TATA spare parts
913002150017	PARTITION DOOR RUBBER	TATA spare parts
913002150026	FRP HEAT INSULATION SEALING RUBBER	TATA spare parts
913002150027	JK DOOR RUBBER PROFILE	TATA spare parts
913002150031	PASSENGER DOOR RUBBER PROFILE	TATA spare parts
913002150032	PASSENGER DOOR RUBBER PROFILE	TATA spare parts
913002150061	PASSENGER DOOR RUBBER PROFILE BS6	TATA spare parts
913002160020	RUBBER END CAP	TATA spare parts

913002160032	SOLID RUBBER PROFILES	TATA spare parts
913002170002	SPONGY RUBBER PROFILE	TATA spare parts
913002170008	RUBBER PROFILE FOR FIX GLASS	TATA spare parts
913002340001	DASHBOARD RUBBER GROMMET 90MM	TATA spare parts
913002340004	SPLIT RUBBER GROMMET ID 30	TATA spare parts
913002340005	SPLIT RUBBER GROMMET ID 45	TATA spare parts
913002340031	HARNESS PROTECTION RUBBER BS6	TATA spare parts
913003140004	VINYL FLOOR YELLOW (TML REF NO:532000944	TATA spare parts
913003140009	VINYL FLOOR RED	TATA spare parts
913003140010	2MM_HORIZON GREY (CODE_VOL 002) VINYL	TATA spare parts
913003140011	VINYL BLUE CANOPUS TYPE 2 MM SHADE	TATA spare parts
913003140015	2MM ANTI-SKID WITH SI GRAIN CANOPUS GRAN	TATA spare parts
913003140018	VINYL FLOOR BUTTON TYPE	TATA spare parts
913003140021	VINYLKIT_42_6.4X2 3X2&5.2X0.5M_S.BLUE1.5	TATA spare parts
913003140027	VINYL FLOOR 1.5THK_RE CANOPUS 5329-510-4	TATA spare parts
913003142014	VINYL FLOOR BLUE	TATA spare parts
913003142027	VINYL KIT 1.5THK	TATA spare parts
913003142037	VINYLKIT FLOOR_BUTTON TYPE -1.2THK_LCV	TATA spare parts
913003142042	VINYL FLOORING KIT ASSEMBLY_1.5	TATA spare parts
913003142051	VINYLKIT_E-RIDE 1MM	TATA spare parts
913003142052	VINYL FLOORING KIT ASSEMBLY	TATA spare parts
913003142059	VINYL FLO KIT ASSY_42WB_1.5MM-BUTTON TYP	TATA spare parts
913003142060	VINYL FLO KIT ASSY_49WB_1.2MM-B	TATA spare parts
913003170001	VINYL REXINE HATRACK 1000BJ GREEN	TATA spare parts
913003170002	FIRE RETARDANT GREY COLOR CARPET 4MM THK	TATA spare parts
913003170003	FR GRADE VINYL LEATHER FOR SKOOL HATRACK	TATA spare parts
913003170006	VINYL REXINE 1MM THK 520MMX7.6M	TATA spare parts
913003170009	VINYL REXINE DARK BROWN_1MM_520X7100	TATA spare parts
913003170010	VINYL REXINE_HATRACK_HB SEAT_BLU COLOUR	TATA spare parts
913004010030	CHASSIS SWITCH HOLDER Y1	TATA spare parts
913004030002	ROOF INTERNAL FINISHING PROFILE SMALL	TATA spare parts
913004050011	INTERNAL PANEL PVC TRIM PROFILE	TATA spare parts
913004050012	SEAT RAIL FINISHING TRIM	TATA spare parts
913004050015	FLOOR FINISHING PVC PROFILE	TATA spare parts
913004050016	ENGINE HOOD HANDHOLD PVC BUSH	TATA spare parts
913004052027	PVC + ABS PROFILE FOR HATRACK-Y1	TATA spare parts
913004052031	M PVC EXTRUSION PROFILE	TATA spare parts
913004052058	M PVC EXTRUSION PROFILE	TATA spare parts
913004052081	M PVC EXTRUSION PROFILE-RAL 8024	TATA spare parts
913004052100	END CAP_29.5MM	TATA spare parts
913004052118	END CAP (29.5MM) RAL 8024	TATA spare parts
913004052139	END CAP 21.2 MM -EVO-01 BS6	TATA spare parts
913004060014	RUBBER PROFILE FOR INSPECTION COVER	TATA spare parts
913004080037	PVC PROFILE	TATA spare parts
913004090018	RUBBER BEADING YELLOW (PASS. DOOR FOOT S	TATA spare parts
913004100019	PVC TUBE FOR HANDHOLD 26.4 (ID)	TATA spare parts
913004100037	PVC SLEEVE FOR HAND HOLD DIA 26.4 (ID)	TATA spare parts



913005110021	GRAPHITE CARPET WIDTH 430	TATA spare parts
913006120024	FALGUN	TATA spare parts
913007130004	WHITE CONSPICUITY TAPE AS PER AIS 090 5	TATA spare parts
913007130005	RED CONSPICUITY TAPE AS PER AIS 090 50	TATA spare parts
913007130008	AIR BLOCKING VALVE STICKER	TATA spare parts
913007130009	220 VOLTS STICKER	TATA spare parts
913007130011	WHEEL CHAIR STICKER	TATA spare parts
913007130012	INSIDE PASSENGER DOOR EMERGENCY INSTRUCT	TATA spare parts
913007130013	NO SMOKING STICKER	TATA spare parts
913007130014	PROIRORITY SEAT STICKER	TATA spare parts
913007130015	ENTRANCE STICKER	TATA spare parts
913007130016	EXIT STICKER	TATA spare parts
913007130017	YELLOW CONSPICUITY TAPE AS PER AIS 090	TATA spare parts
913007130018	MULTIPLEX FUSE BOX STICKER (NON AC)	TATA spare parts
913007130021	BROWN VINYL STICKER 150MM WIDE _SKOOL BU	TATA spare parts
913007130042	TATA DOME STICKER REAR	TATA spare parts
913007130045	TATA DOME STICKER _BLACK _SMALL	TATA spare parts
913007130046	MARCOPOLO DOME STICKER _BLACK _SMALL _LOG	TATA spare parts
913007130047	TATA DOME STICKER _BLACK _BIG	TATA spare parts
913007130048	MARCOPOLO DOME STICKER _BLACK _BIG _LOGO	TATA spare parts
913007130050	MARCOPOLO DOME STICKER _EVO2 _SMALL _N.LO	TATA spare parts
913007130059	SCHOOL INSIGNIA 200X200 B.ADHESIVE	TATA spare parts
913007130060	STARBUS ULTRA STICKER Y1 REAR & SIDES	TATA spare parts
913007130063	RETRO REFLECTIVE SIGN _EMIRATES	TATA spare parts
913007130064	NO MOBILE PHONE STICKER _EMIRATES	TATA spare parts
913007130065	NO SMOKING STICKER _EMIRATES	TATA spare parts
913007130066	PASSENGER SEAT NUMBERING KIT _EMIRATES	TATA spare parts
913007130067	DECAL _ARMY AMBU 460X460MM WHITE CIRCLE	TATA spare parts
913007130068	DECAL _ARMY AMBU 1180X1180MM WHITE CIRC	TATA spare parts
913007130069	DECAL _ARMY AMBU 400X400MM LG RED+LC210	TATA spare parts
913007130070	DECAL _ARMY AMBU 1000X1000MM LGRED+LC21	TATA spare parts
913007130071	DECAL _ECNALUBMA 1804X204MM LG RED-LC210	TATA spare parts
913007130073	EMERGENCY DOOR STICKER EXT	TATA spare parts
913007130074	MARCOPOLO DOME STICKER BLACK SMALL LOGO	TATA spare parts
913007130076	PRIORITY SEAT STICKER ON RH SIDE WALL BS	TATA spare parts
913007130087	SCHOOL INSIGNIA _200X200 _B.ADHESIVE	TATA spare parts
913007130089	Y1 _ULTRA STICKER	TATA spare parts
913007130106	PRIORITY PHYSICAL HANDICAPED STICKER	TATA spare parts
913007130107	PRIORITY LADIES STICKER _LH/RH SIDE WALL	TATA spare parts
913007130109	CHARGING PLUG STICKER	TATA spare parts
913007130110	HIGH VOLTAGE WARNING STIKCER	TATA spare parts
913007130116	LCTSL LOGO STICKER _EV 9/9	TATA spare parts
913007130141	BLIND PERSON STICKER ON LH/RH SIDE WALL	TATA spare parts
913007130142	SILVER STICKER (MATCHING RAL 7001) EV	TATA spare parts
913007130146	BEST _1 (EV 9/9)	TATA spare parts
913007130147	BEST _2 (EV 9/9)	TATA spare parts
913007130148	ECO FRIENDLY (EV 9/9 BEST)	TATA spare parts

913007130149	PAY CORRECT FARE (EV 9/9 BEST)	TATA spare parts
913007130150	SAAVADHAN_1 (EV 9/9 BEST)	TATA spare parts
913007130152	MOVE ALONG GANGWAY (EV 9/9 BEST)	TATA spare parts
913007130153	BEST_3 (EV 9/9)	TATA spare parts
913007130154	DO NOT PUT FEET ON SEAT (EV 9/9 BEST)	TATA spare parts
913007130155	TYPE PRESSURE STICKER (125.PSI)	TATA spare parts
913007130156	SPITTING AND SMOKING PROHIBITED (EV 9/9)	TATA spare parts
913007130157	BEST STICKER_1	TATA spare parts
913007130159	WHEEL CHAIR LIFT DO NOT TOUCH	TATA spare parts
913007130160	SAAVADHAN_3 (EV 9/9 BEST)	TATA spare parts
913007130161	SAAVADHAN_4 (EV 9/9 BEST)	TATA spare parts
913007130162	BEST STICKER_2	TATA spare parts
913007130163	BEST STICKER_3	TATA spare parts
913007130164	LADIES STICKER	TATA spare parts
913007130165	MOBILE CHARGER (EV 9/9 BEST)	TATA spare parts
913007130166	HANDICAPPED STICKER	TATA spare parts
913007130167	SENIOR CITIZEN STICKER	TATA spare parts
913007130168	TYPE PRESSURE STICKER (125.PSI)	TATA spare parts
913007130170	BEST STICKER_4	TATA spare parts
913007130175	SAAVADHAN_6 (EV 9/9 BEST)	TATA spare parts
913007130176	NO HORN STICKER_2	TATA spare parts
913007130179	BEST STICKER_6	TATA spare parts
913007130180	BEST STICKER_7	TATA spare parts
913007130181	LOW VOLTAGE BATTERY STICKER	TATA spare parts
913007130182	CRUETH HOLDER STICKER	TATA spare parts
913007130183	ULTRA EV _STICKER	TATA spare parts
913007130184	100PERC ELECTRIC STICKER (RED BACKGRND)	TATA spare parts
913007130185	ZERO EMISSION STICKER (RED BACKGRND)	TATA spare parts
913007130186	LH SIDE ZEBRA STICKER	TATA spare parts
913007130187	RH SIDE ZEBRA STICKER	TATA spare parts
913007130189	ELECTRIC BUS (BLUE) STICKER (EV AJL)	TATA spare parts
913007130190	LICENCED TO SEAT 35 ONLY (EV 9/12 BEST)	TATA spare parts
913007130191	SAAVADHAN (EV 9/12 BEST)	TATA spare parts
913007130195	STARBUS EV FRONT	TATA spare parts
913007130196	TATA STARBUS EV _ SIDE DECALS	TATA spare parts
913007130214	RH WHEEL CHAIR STICKER ROUND-153	TATA spare parts
913007130215	LH WHEEL CHAIR STICKER ROUND-153	TATA spare parts
913007130220	PRIORITY PHYSICAL HANDICAPPED STCKR BLUE	TATA spare parts
913007130221	PRIORITY LADIES STICKER BLUE	TATA spare parts
913007130222	FAME LOGO ENGLISH	TATA spare parts
913007130223	FAME LOGO HINDI	TATA spare parts
913007130224	EXIT	TATA spare parts
913007130225	ENTRY	TATA spare parts
913007130226	GOVT. VEHICLE	TATA spare parts
913007130227	ZERO EMISSION	TATA spare parts
913007130228	ZERO EMISSION (BIG)	TATA spare parts
913007130229	JAMMU SMART CITY LOGO	TATA spare parts

913007130230	SRINAGAR SMART CITY LOGO	TATA spare parts
913007130264	GOVT. VEHICLE-FRONT	TATA spare parts
913008170002	NON RETRACTABLE SAFETYBELT CODRIVER	TATA spare parts
913008170003	RETRACTABLE SAFETY BELT CO-DRIVER	TATA spare parts
913008170004	FIRE EXTINGUISHER_5KG	TATA spare parts
913008170034	FIRE EXTINGUISHER WITH CLAMP	TATA spare parts
913008170035	FIRST AID BOX	TATA spare parts
913008170037	FIRE EXTINGUISHER -SAFEX- IS 13849-2KG	TATA spare parts
913008170038	FIRE EXTINGUISHER_BCF HALOGENATED_2KG	TATA spare parts
913008170039	FIRST AID BOX _WITHOUT RED CROSS MARK	TATA spare parts
913008170042	FIRE EXTIGUSHER 6KG	TATA spare parts
913008170043	FIRE EXTINGUISHER	TATA spare parts
913008170044	FIRE EXTINGISHER 4 KG	TATA spare parts
913009100001	FIRE RETARDENT MARINE PLY WOOD 12 MM	TATA spare parts
913010170001	THERMOCOLE(EPS) FR IS4671_1000X500X35MM	TATA spare parts
913010170004	5X30-MM FOAM BLANKET	TATA spare parts
913010170005	FOAM BAND 3.2X20 APPLIED OVER STR	TATA spare parts
913010170008	POLIESTER MASS CARTRIDGE W/ CATALYZER	TATA spare parts
913010170021	6MM WIDE DOUBLE FACE TAPE(1.1MM THICK)	TATA spare parts
913010170024	1.2X15-MM DOUBLE FACE TAPE	TATA spare parts
913010170026	SELF ADHESIVE KINI FOAM FR 35 KG/CM3 6	TATA spare parts
913010190001	CAULKER ACCORDING TO ES 0006	TATA spare parts
913010190006	HARNESS SEALER_CG SEAL BR 4515	TATA spare parts
913010190009	CG SEAL DIA 100MM	TATA spare parts
913010200001	ADHESIVE 600ML WHITE	TATA spare parts
913010200006	SIKA FLEX 221 IA_BLACK	TATA spare parts
913010200018	CG SEAL 205TM SEALANT BS6	TATA spare parts
913010200019	CG SEAL 205TMB SEALANT_BLACK_SAUSAGE BS6	TATA spare parts
913010200025	5 BUTYL TAPE FOR ROOF PANELING	TATA spare parts
913010200028	CGSEAL 1007GB_GLASS BOND_SAUSAGE	TATA spare parts
913010230001	PRIMER 206	TATA spare parts
913010240001	WINDSHIELD SEALANT ACCORDING TO ES 0007	TATA spare parts
913010240002	WINDSHIELD SEALANT ACCORDING TO ES 0007	TATA spare parts
913010270001	ACTIVATOR 205	TATA spare parts
913011040002	CERAMIC FIBRE 12.5 THK 128KG/M3	TATA spare parts
913011080002	BALATA BELT OF 6MM THK	TATA spare parts
913011170001	FUSE BOX FLAP LOCK	TATA spare parts
913011170009	JK DOOR BOTTOM BRUSH	TATA spare parts
913011170014	CLAMP FOR HOLDING 20MM PIPE	TATA spare parts
913011170016	GAS PISTON	TATA spare parts
913011170018	CORRUGATED TUBE 3/8 (10MM) DIA	TATA spare parts
913011170019	GAS PISTON _SIDE FLAP	TATA spare parts
913011170021	CORRUGATED TUBE 1/4INCH (6MM) DIA	TATA spare parts
913011170022	GAS PISTON	TATA spare parts
913011170023	REAR LUGGAGE BOX GAS STRUD	TATA spare parts
913011170024	SPRING CLAMP	TATA spare parts
913011170028	STAINLESS BRACKET WITH RUBBER TRIM	TATA spare parts

913011170029	STAINLESS BRACKET WITH RUBBER TRIM	TATA spare parts
913011170030	STEEL BRACKET WITH RUBBER TRIM	TATA spare parts
913011170031	STAINLESS WITH RUBBER CLAMP	TATA spare parts
913011170036	LAMP CLAMP	TATA spare parts
913011170041	PNEUMATIC VALVE	TATA spare parts
913011170042	DIA6 ADAPTER	TATA spare parts
913011170043	DIA6 T CONNECTOR	TATA spare parts
913011170044	PNEUMATIC VALVE	TATA spare parts
913011170051	BELL	TATA spare parts
913011170056	AIR BLOW HORN	TATA spare parts
913011170062	GAS PISTON	TATA spare parts
913011175010	GAS PISTON	TATA spare parts
913011175025	STAINLESS WITH RUBBER CLAMP_DIA50	TATA spare parts
913011175033	1 1/4 IN FLEXIBLE WASH BASIN PIPE	TATA spare parts
913011175041	NON OVEN FABRIC	TATA spare parts
913011175057	FABRIC-MELBA FLAT WOVEN JACQUARD	TATA spare parts
913011175203	L&L D-MP-20 _ALUMINIUM FOIL	TATA spare parts
913011175211	STEEL BELL RIOLLER KIT	TATA spare parts
913011175217	GAS PISTON 50KG CL 300 OL 480 BS6	TATA spare parts
913011175222	INSIDE WINDOW GUARD RAIL BRACKET BS6	TATA spare parts
913011214001	FLAT HEAD COUNTER SUNK SCREW DIA 5X30	TATA spare parts
913014170001	FUSE BOX FLAP LOCK	TATA spare parts
913014170004	REAR FLAP LOCK	TATA spare parts
913014170007	DRIVER DOOR LOCK & KEY	TATA spare parts
913014170008	TERNAL LATCH FOR DOOR	TATA spare parts
913014170009	LOCKING MECHANISM FOR DOOR	TATA spare parts
913014170010	LOCKING BRACKET FOR DOOR	TATA spare parts
913014170011	LOCK RELEASE PIN OF DOOR	TATA spare parts
913014170012	INTERNAL LATCH LINK ROD FOR DOOR	TATA spare parts
913014170013	EXTERNAL LATCH LINK ROD FOR DOOR	TATA spare parts
913014170015	LOCKS AND LATCHES FOR L.E REAR FLAP	TATA spare parts
913014170016	DASH BOARD LOCK	TATA spare parts
913014170018	INTERNAL LOCK	TATA spare parts
913014170019	EXTERNAL LOCK	TATA spare parts
913014170020	LOCKING MECHANISM FOR DOOR RHD BS6	TATA spare parts
913014170029	EXTERNAL LATCH FOR DOOR	TATA spare parts
913014170030	INTERNAL LATCH LINK ROD FOR DOOR	TATA spare parts
913014170031	EXTERNAL LATCH FOR DOOR (LHD)	TATA spare parts
913014170033	LOCKS AND LATCHES FOR AMBULANCE (KIT)	TATA spare parts
913014170034	EXTERNAL LATCH FOR DOOR	TATA spare parts
913014170035	LOCK	TATA spare parts
913014170039	LOCKING KEY HANDLE	TATA spare parts
913014170056	LOCK RELEASE PIN OF DOOR LHD	TATA spare parts
913014170059	KEY	TATA spare parts
913014363001	FLAP HANDLE	TATA spare parts
914001038002	19.05X1.2 FICTITIUS ROUND TUBE	TATA spare parts
914002040017	ALLUMINIUM EXTRUSION Y1 GRILL HAT RACK	TATA spare parts

914002040048	AL PROFILE FOR SKIRT PANELING (RUB RAIL)	TATA spare parts
914002042001	ALUMINUM PROFILE * (DOOR FINISHING PROFI	TATA spare parts
914002042002	ALUMINUM PROFILE * (DRIVER DOOR FINISHIN	TATA spare parts
914002042003	ALUMINUM PROFILE * (EXTERNAL ROOF PANNEL	TATA spare parts
914002042004	ALUMINUM PROFILE * (INTERNAL PANNELING J	TATA spare parts
914002042005	ALUMINUM PROFILE * (SIDE PANNELING JOINT	TATA spare parts
914002042007	MOULDED HATRACK LONGITUDINAL AL PROFILE	TATA spare parts
914002042008	ALUMINUM PROFILE * (WATER GLUTER)	TATA spare parts
914002042009	ALUMINUM PROFILE * (LUGGAGE RACK)	TATA spare parts
914002042010	ALUMINUM PROFILE * (STEPS FINISHING)	TATA spare parts
914002042015	SIDE EXTERNAL JOINT FINISHING PROFILE-1	TATA spare parts
914002042016	SIDE EXTERNAL JOINT FINISHING PROFILE-2	TATA spare parts
914002042017	SIDE EXTERNAL JOINT FINISHING PROFILE-1	TATA spare parts
914002042018	SIDE EXTERNAL JOINT FINISHING PROFILE-1	TATA spare parts
914002042019	SKIRT & STRETCH PANEL JOINT PROFILE	TATA spare parts
914002042021	ALUMINUM PROFILE FOR DRIVER PARTITION	TATA spare parts
914002042022	ALUMINUM TUBE PROFILE FOR DRIVER PARTIT	TATA spare parts
914002042023	ALUMINIUM PROFILE INTERNAL PANNELING JO	TATA spare parts
914002042024	RAIN GUTTER ALLUMINIUM PROFILE	TATA spare parts
914002042025	SKIRT & STRETCH PANEL JOINT PROFILE-2	TATA spare parts
914002042027	ALUMINIUM PROFILE	TATA spare parts
914002042033	ALUMINIUM PROFILE 206	TATA spare parts
914002042042	SIDE EXTERNAL PANELLING FINISH ALU PROFI	TATA spare parts
914002042084	ROOF EXTERNAL CURVE PANELING MCV LOW FL	TATA spare parts
914002042087	AL PROFILE	TATA spare parts
914002042099	SIDE PILLAR ALUMINUM PROFILE_LEMCV	TATA spare parts
914002042131	HATRACK LONGITUDINAL AL FROFILE-Y1	TATA spare parts
914002042132	AL PROFILE_CUTOUT PLYWOOD_12MM	TATA spare parts
914002042133	AL PROFILE FOR HATRACK	TATA spare parts
914002042136	ALUMINIUM PROFILE FOR DOOR SEALING	TATA spare parts
914002042210	ALUMINIUM PROFILE	TATA spare parts
914002042212	ALUMINIUM PROFILE 202	TATA spare parts
914002042216	SIDE EXT PANELLING FINISH ALU PROFILE	TATA spare parts
914002042218	ROOF EXTERNAL JOINT FINISHING AL PROFILE	TATA spare parts
914002042219	INTERNAL PANELING JOINT ALU. PROFILE	TATA spare parts
914002042223	ALUMINIUM PROFILE 207	TATA spare parts
914002042225	ALUMINIUM PROFILE	TATA spare parts
914002042228	AL PROFILE FOR VINYL FINISHING	TATA spare parts
914002043013	AL PROFILE FOR CUTOUT PLYWOOD(19 MM)	TATA spare parts
914002043026	EXTERNAL PANELING PROFILE BS6	TATA spare parts
914002047020	WINDOW GUARD RAIL BRACKET (OPEN END)	TATA spare parts
914002047021	WINDOW GUARD RAIL BRACKET (CLOSED END)	TATA spare parts
914002047025	WINDOW GUARD RAIL AL BRKT 20DIA_OPEN END	TATA spare parts
914002047026	WINDOW GUARDRAIL AL BRKT 20DIA_CLOSE END	TATA spare parts
914002047030	AC DUCT ALUMINIUM EXTRUSION BS6	TATA spare parts
914002106001	AL CHEQ. SHEET 2.2 MM THK 813 X 3600	TATA spare parts
914005018002	GI COIL SKINN PASS 0.65X706 120 GSM	TATA spare parts

914005058045	0.65X1250X3928 _ GI SHT SK PASS 120 GSM	TATA spare parts
914008010001	CIRCLIP ID 5 ZINC COATED GREEN	TATA spare parts
91409001000101	FR STR KIT FOR PHOSPHATING	TATA spare parts
915001017002	WINDOW GUARD_1172	TATA spare parts
915001017004	WINDOW GUARD RAIL 2400	TATA spare parts
915001017006	WINDOW GUARD L - 4685	TATA spare parts
915001017009	WINDOW GAURD RAIL 2352 BS6	TATA spare parts
915001017010	WINDOW GAURD RAIL 4900	TATA spare parts
915001017012	WINDOW GAURD RAIL 2454 BS6	TATA spare parts
915001017015	WINDOW GAURD RAIL 587	TATA spare parts
915001017016	WINDOW GAURD RAIL 1072	TATA spare parts
915001017024	WINDOW GAURD RAIL 2160 BS6	TATA spare parts
915001017025	WINDOW GAURD RAIL 4255	TATA spare parts
915001017029	WINDOW GAURD RAIL 4871	TATA spare parts
915001017030	WINDOW GAURD RAIL 3654	TATA spare parts
915001017031	WINDOW GAURD RAIL 2364	TATA spare parts
915001017032	WINDOW GAURD RAIL 3729	TATA spare parts
915001017034	WINDOW GAURD RAIL 3129	TATA spare parts
915001017036	WINDOW GAURD RAIL 705	TATA spare parts
915001017043	WINDOW GAURD RAIL	TATA spare parts
915001017045	WINDOW GAURD RAIL 693	TATA spare parts
915001017046	WINDOW GAURD RAIL 2706	TATA spare parts
915001017048	WINDOW GAURD RAIL 5500 BS6	TATA spare parts
915001017050	WINDOW GUARD RAIL_1635	TATA spare parts
915001017051	WINDOW GUARD RAIL TUBE_RPVC_4725LN BS6	TATA spare parts
915001017057	WINDOW GAURD RAIL 2820	TATA spare parts
915001017058	WINDOW GUARD RAIL BS6	TATA spare parts
915001017060	WINDOW GAURD RAIL 3200	TATA spare parts
915001017061	WINDOW GAURD RAIL 3200	TATA spare parts
915001017071	WINDOW GUARD RAIL TUBE_RPVC_785LN BS6	TATA spare parts
915001017075	WINDOW GAURD RAIL 806	TATA spare parts
915001017089	WINDOW GUARD RAIL 5040	TATA spare parts
915001017099	WINDOW GUARD RAIL TUBE_RPVC_825LN BS6	TATA spare parts
915001017100	WINDOW GUARD RAIL TUBE_RPVC_2815LN BS6	TATA spare parts
915001017107	WINDOW GUARD RAIL 3539	TATA spare parts
915001017108	WINDOW GUARD RAIL 4100 BS6	TATA spare parts
915001017115	WINDOW GUARD RAIL L-3836	TATA spare parts
915001017117	WINDOW GAURD RAIL 747	TATA spare parts
915001017122	WINDOW GUARD RAIL TUBE_RPVC_4075LN BS6	TATA spare parts
915001017124	WINDOW GUARD RAIL L-2260	TATA spare parts
915001017125	WINDOW GAURD RAIL 3650	TATA spare parts
915001017130	WINDOW GUARD RAIL	TATA spare parts
915001017133	WINDOW GUARD RAIL 4790	TATA spare parts
915001017145	WINDOW GUARD RAIL	TATA spare parts
915001017155	WINDOW GUARD RAIL 1120	TATA spare parts
915001017156	WINDOW GAURD RAIL 1270	TATA spare parts
915001017157	WINDOW GUARD RAIL 1680	TATA spare parts

915001017158	ALUMINIUM TOWER BOLT 8INCH	TATA spare parts
915001017170	WINDOW GUARD-3775	TATA spare parts
915001017171	WINDOW GARDRAIL-2500	TATA spare parts
915001017172	WINDOW GARD RAIL-1980	TATA spare parts
915001017174	WINDOWGARDRAIL4085	TATA spare parts
915001017180	WINDOW GAURD RAIL	TATA spare parts
915001017195	WINDOW GUARD RAIL_1795 BS6	TATA spare parts
915001017196	WINDOW GUARD RAIL_1635 BS6	TATA spare parts
915001017197	WINDOW GUARD RAIL_902 BS6	TATA spare parts
915001017203	WINDOW GAURD RAIL_1878 BS6	TATA spare parts
915001017204	WINDOW GAURD RAIL_1870 BS6	TATA spare parts
915001017205	WINDOW GAURD RAIL_1675 BS6	TATA spare parts
91694	SPACER 0.181 THICK	TATA spare parts
91698	SPACER 0.183 INCH THICK	TATA spare parts
91712	PINION BRG SPACER	TATA spare parts
918010102002	PAN_HEAD_SCREW_B4X14X12_DIN7985_12C1	TATA spare parts
918010102110	BLACK SCREW MF 4 X 12 Z	TATA spare parts
918010102111	S_PAN_4.8_1.6_38_DIN968_1018_D_V BS6	TATA spare parts
918010103002	B4.8 X 25-ZN 12C4 -PANHEAD SCREW	TATA spare parts
918010103004	PAN HEAD SCREW B4.2X10X10 12C4 BLACK BS6	TATA spare parts
918010103005	PAN_HEAD_SCREW_M5X0.8X27X29_DIN7985	TATA spare parts
918010103006	PAN_HEAD_SCREW_M5X0.8X33X31_DIN7985 BS6	TATA spare parts
918010103086	S_PAN_5_0.8_24_DIN7981_1010_D_V	TATA spare parts
918010104001	M6X1X10LN-CL 8.8 -HEX BOLT	TATA spare parts
918010104002	PAN HEAD SCREW - DIN 7981-B5.5X22 LN	TATA spare parts
918010111002	B3.5X13-MM-ZN 12C1- PANHEAD SCREW	TATA spare parts
918010111005	PAN_HEAD_SCREW_B4.8X26X22_DIN7981	TATA spare parts
918010111009	PAN HEAD SCREW B2.9X9.5X9.5 DIN7981 BS6	TATA spare parts
918010111010	S_PAN_4.8_1.25_38_DIN7981_1018_D_U	TATA spare parts
918010111011	B6.3X38-MM PANHEAD SCREW	TATA spare parts
918010111012	PAN_HEAD_SCREW_B3.9X32X32_DIN7981_12C4	TATA spare parts
918010111013	PAN_HEAD_SCREW_B3.5X19X19_DIN7981_12C1	TATA spare parts
918010111014	PAN-HEAD M4X25 DIN7981 12C1(WHITE)	TATA spare parts
918010111017	PAN HEAD SCREWS-B4.8X16- FE/ZN 12 C4	TATA spare parts
918010111018	B 4.2X22.5-ZN 12 C1-FLAT HEAD SCREWS	TATA spare parts
918010111070	PANHEAD SCREW B4.8 X 25	TATA spare parts
918010111077	PAN_HEAD_SCREW_B3.5X15X13_DIN7981_12C4	TATA spare parts
918010111082	B 4.2X20-CL 4.8-ZN 12 C4	TATA spare parts
918010111083	PAN_HEAD_SCREW_B6.3X31X31	TATA spare parts
918010113002	B4.8 X 25-ZN 12C4 -PANHEAD SCREW	TATA spare parts
918010200001	B 4.2X16-TRET :SUP ALUSEALPAN HEAD SCREW	TATA spare parts
918010304076	S_ROUND_6_1_15_IS1364_1010_D_V	TATA spare parts
918010311083	B 6.3X42-12C2-ALLEN SCREW	TATA spare parts
918010501001	B3.5X13-CL5.8-ZN 12 C4	TATA spare parts
918010502001	CHEESE HEAD SCREW B4.2 X 16	TATA spare parts
918010502002	M4X0.7X15-CL 5.6- FLAT HEAD SCREW	TATA spare parts
918010502003	B 4.2X25-ZN 12 C1-FLAT HEAD SCREWS	TATA spare parts

918010502004	M4X0.7X25-MM FLATHEAD SCREW	TATA spare parts
918010502005	FLAT HEAD STAR SCREW M6X1.0X30	TATA spare parts
918010503001	B 4.2X22.5-ZN 12 C1-FLAT HEAD SCREWS	TATA spare parts
918010504001	M6 X 1 X 16 FLAT HEAD BOLT	TATA spare parts
918010504003	FLAT HEAD SCREW M6X1X55 FLAT END	TATA spare parts
918010504123	SQUARE HEAD SCREWS	TATA spare parts
918010505001	FLAT_HEAD_SCREW_M8X1.25X25X25_DIN7991	TATA spare parts
918010505002	FLANGE_SCREW_B4.2X22X22_12C4	TATA spare parts
918010505084	S_FLAT_5.5_1.8_25_DIN7982_1018_C_V BS6	TATA spare parts
918010505085	S_FLAT SOCK_8_1.25_25_DIN7991_SS304_E_X	TATA spare parts
918010511001	SPECIAL FLAT HEAD SCREW B4.8X25	TATA spare parts
918010511008	FLAT HEAD SCR. DIN 7982-B5.5X38-ZN 12 C1	TATA spare parts
918010511009	FLAT_HEAD_SCRW_B4.2X16X13.5_DIN7982_12C	TATA spare parts
918010511016	B 4.8X25 CLASSE 8.8 ZN 12C2 -FLAT HEAD	TATA spare parts
918010511030	FLAT HEAD SCRWB4.2X19X16.5 DIN7982 12C4	TATA spare parts
918010511088	FLAT_HEAD_SCREW_B4.2X38X32_DIN7982_12C4	TATA spare parts
918010511089	FLAT_HEAD_SCREW_B4.8X25X25_DIN7982_12C1	TATA spare parts
918010603048	OVAL HEAD SCREW M5X0.8X16X16 DIN966 12C4	TATA spare parts
918010604092	OVEL HEAD SCREW	TATA spare parts
918010605007	ENGINE HOOD HINGES MTG. BOLT ( ALEN KEY	TATA spare parts
918010611003	B4.2X25-ZN 12 C4-OVAL HEAD SCREWS	TATA spare parts
918010611047	B 4.2 X 19MM-ZN 12C4 - EGG HEAD SCREWS	TATA spare parts
918010704001	M6X1X20 CLASSE 5.6 ZN	TATA spare parts
918010704006	M6X1-ZN 12 C2-CL 5.6-HEX HEAD SCREW	TATA spare parts
918010704007	B_HEX_M6_1_35_IS1364P1_8.8_C_V	TATA spare parts
918010704008	AB 6.3X25-HEX FLANGED BOLT	TATA spare parts
918010704015	B HEX M6 1 16 IS1364P1 8.8 C V BS6	TATA spare parts
918010704019	AB 5.5X16-CL 8.8-ZN 12 C4-HEX FLANGD BLT	TATA spare parts
918010705001	NYLOC BOLT M8X1.25 30LN HEX HEAD	TATA spare parts
918010705002	HEX. HEAD SCREW M8X1 25X25-CLASS 8.8	TATA spare parts
918010705006	HEX_HEAD_BOLT_M8X1.25X25X25_FE/ZN 12C4	TATA spare parts
918010705074	ADJUSTABLE JAMB ROD - FLOP STOPPER	TATA spare parts
918010705097	HEX HEAD BOLT M8X1.25X40 12C2 TRIBULAR	TATA spare parts
918010705098	HEX COLLARED TRIBOULAR BOLT M 8X1.25X25	TATA spare parts
918010705100	HEX HEAD BOLT M8X1.25X70 FE/ZN 12C4-BLAC	TATA spare parts
918010705102	B HEX FL M8X35 TS17130 8.8-SS8451-8C BS6	TATA spare parts
918010706006	HEX HEAD BOLT M10X1.5X35 DIN933/70 12C3	TATA spare parts
918010708002	HEX_HEAD_BOLT_M12X1.75X55X36_CLASS 5.6	TATA spare parts
918010708073	NUT	TATA spare parts
918010714002	SPCL HEX HEAD SCRWB6X1 DIN 267 CLASS8.8	TATA spare parts
918010715095	FLAT HEAD SCREW BS6	TATA spare parts
918011205001	M8X50 CROSS RECESSED CSK_FLAT HD SCW SS	TATA spare parts
918011214001	FLAT_HEAD_SCREW_M5X2.5X35X30_FE/ZN12C3	TATA spare parts
918011304001	S_ALLEN_6_1_30_IS1364_SS304_E_X	TATA spare parts
918011304004	S_ALLEN_6.3_1.8_42_IS1364_1018_D_V	TATA spare parts
918011305001	ALLEN_SCREW_M/8X1.25X34	TATA spare parts
918011305046	ALLEN_SCREW_M8X1.25X20XDIN912/79_12C4	TATA spare parts



918011305047	S_SOCKET_8_1.25_20_DIN912_SS304_E_X BS6	TATA spare parts
918011305048	HEX.SOCKET HEAD CAP SCREW M8X1.25X60LN	TATA spare parts
918011305050	HEX.SOCKET HEAD CAP SCREW M8X1.25X90LN	TATA spare parts
918011306001	M10X1.50X45MM-CLASS12.9- ALLEN SCREW	TATA spare parts
918011306002	M10X1.50X45MM-CLASS12.9- ALLEN SCREW	TATA spare parts
918011308001	SP.ALEN SCREW M12X1.75X53.5X30 CLASS-5.	TATA spare parts
918011905001	HEX FLANGED BOLT M8X1.25X80LN	TATA spare parts
918011905081	S_HEXFLAN_M8_1.25_65_TS17130_10.9_D_V BS	TATA spare parts
918011911001	M8X1.25X45-CL8.8-ZN 12 C2-SILO SCREW	TATA spare parts
918012102001	SCREW HEAD WITH FLANGE-B 4.2X32-DIN 7970	TATA spare parts
918012102002	SCREW HEAD WITH FLANGE- B 4.2X32	TATA spare parts
918012105090	HEX_HEAD_SILO_SCREW_M8X1.25X35X35_12C2	TATA spare parts
918012204001	M6X1X25-ZN 12 C2-HEX FLANGED BOLT	TATA spare parts
918012204002	M6X1X31LN_TROX SCREW	TATA spare parts
918012316096	EAF SETSCREW 7/16 INCH-25.4LN(THRD LN19)	TATA spare parts
918012502001	M4X1X17LN CROSS RECESSED CSK FLAT HD SCW	TATA spare parts
918012504001	JAMB BOLT	TATA spare parts
918012504002	M6X1X30LN_CROSS RECESSED CSK_FLAT HD SCW	TATA spare parts
918012605001	NYLOCK BOLT-M8X1 25X45 CLAS. 5.6 ZA 12C2	TATA spare parts
918020702087	HEX NUT -M4X0.7- FE/ZN 12C2-CL 8.8-DIN 9	TATA spare parts
918020703020	HEX_NUT_M5X0.8_DIN934_FE/ZN12C2_YELLOW	TATA spare parts
918020704001	HEXAGONAL NUT 1/4 X 20 UNC	TATA spare parts
918020704018	HEX_NUT_M6X1_DIN985_FE/ZN12C4_BLACK	TATA spare parts
918020704021	M6 X 1.0-CLASSE 8 -ZN 12C2 -HEX NUT	TATA spare parts
918020704022	M6X1XCL 8-SAFETY HEX SHAPED NUT	TATA spare parts
918020704122	N_HEX_6_1_8_PROP_PLASTIC NUT	TATA spare parts
918020705019	HEX_NUT_M8X1.25_DIN934/68_FE/ZN12C3 BS6	TATA spare parts
918020705022	M8 X 1.25 -CLASSE 8-ZN 12C2 -HEX. NUT	TATA spare parts
918020705023	N_HEX_10_1.5_10_DIN934/IS1364_8_C_V	TATA spare parts
918020705024	HEX_NUT_M10X1.5_12C2	TATA spare parts
918020705025	NYLOK HEX NUT M8 X 1.25 CL 8 FE/ZN 12C3	TATA spare parts
918020705071	HEX_NUT_M8X1.25_DIN934_SAE304	TATA spare parts
918020706004	HEX SCREW 7/16 X 20 LN- EAF X 3/4-CLA	TATA spare parts
918020805002	BOX NUT M6X1.0 FE/ZN12C3 DIN 1587	TATA spare parts
918020805003	HEXAGON BOX NUTS M8X1.25 FE/ZN 12C3 DIN1	TATA spare parts
918022108001	M12 HEX FLANGE NUT - DIN 6927	TATA spare parts
918022504001	WING_NUT_M6X1_IS2636-1972_FE/ZN12C2	TATA spare parts
918022508001	N_NYLOCK_12_1.75_14_Din934/IS1364_8_C_V	TATA spare parts
918022602001	DOME_HEX_NUT_M4 X1FE/ZN 12C1	TATA spare parts
918022603001	DOME_HEX_NUT_M5 X 0.8_DIN 1587_FE/ZN 12C	TATA spare parts
918022604001	DOME_HEX_NUT_M6 X1FE/ZN 12C1	TATA spare parts
918030505121	W_PLAIN_BRASS_8_15.8_1_DIN125_BRASS	TATA spare parts
918031002001	PLAIN WASHER 4.3X9XT1	TATA spare parts
918031004033	SMOOTH WASHER-6.4X12.5X1.6- ZN 12C2	TATA spare parts
918031004040	ID6.4XOD12.5X1.6 THK SMOOTH WASHER	TATA spare parts
918031004041	SMOOTH WASHER-ID 6.4XOD 12X1.5	TATA spare parts
918031005001	2X6.6X24.7-MM FLAT WASHER W/ YELLOW	TATA spare parts

918031005034	FLAT WASHER-8.4X17X1.6--ZN 12C2	TATA spare parts
918031005035	W_PLAIN_6.2_16.7_3_AISI1010_C_V BS6	TATA spare parts
918031005037	W_SPRING_8.1_14.8_2_SPRING STEEL_C_V BS6	TATA spare parts
918031005041	W_PLAIN_8_28_2_AISI SHEET_C_V BS6	TATA spare parts
918031005057	PLAIN_WASHER_ID5XOD12XT1.5_DIN125_12C3	TATA spare parts
918031006052	PLAIN WASHER-ID 10X OD20X2-12 C2	TATA spare parts
918031006059	PLAIN WASHER 10.5 DIN 125 FEZN 12 C4	TATA spare parts
918031007003	PLANE WASHER-8.4X17X1 6 -ZN 12C3	TATA spare parts
918031009001	PLAIN_WASHER_ID13XOD40XT3_IS:5370	TATA spare parts
918031009003	WAVE WASHER M5	TATA spare parts
918031010038	PLAIN_WASHER_ID13XOD40XT3_IS_5370	TATA spare parts
918031013001	W PLAIN 8.4 17 1.6 AISI1010 C V BS6	TATA spare parts
918031104039	ID 6.1X OD 11.8 X 1.4 TH-PRESSURE WASHER	TATA spare parts
918031104042	W SPRING WASHER 6 1.9X2.8 IS3063 A V BS6	TATA spare parts
918031105037	M 8X 1.25- DIN 934-HEX NUTS	TATA spare parts
918031105038	WASHER	TATA spare parts
918031106001	W_SPRING_8.1_14.8_2.2_DIN127_C_V	TATA spare parts
918031106106	PRESSURE WASHER-10 2X18 1X2 2-ZN 12 C2	TATA spare parts
918031106108	W_SPRING_10.5_18_2.8_SS 304 DIN 127_E_W	TATA spare parts
918031108045	PLAIN_WASHER_ID12.8XOD24XT1.5_DIN125	TATA spare parts
918032503001	WASHER ID 5_OD 14_THICK0.5	TATA spare parts
918040313113	SOLID RIVET D4.76X10	TATA spare parts
918040313114	ROUND HEAD RIVIET DIA 3.18 X 10	TATA spare parts
918040313115	SOLID RIVET DIA 4.8X13 LN	TATA spare parts
918040913052	HOLLOW RIVET D4.8X17.1 DIN7337	TATA spare parts
918040913053	HOLLOW RIVET- OD 4.8X ID 2.7X21.6 LN	TATA spare parts
918040913054	HOLLOW RIVET- OD 4.8 X 17 1LN	TATA spare parts
918040913061	HOLLOW RIVET-OD 3.2 X 15.2 LN	TATA spare parts
918040913062	HOLLOW RIVET-DIA 3.2X10.2 LN-MANDREL	TATA spare parts
918040913066	HOLLOW RIVET_ID3.2X15.2LN-MANDRELLN 25.2	TATA spare parts
918040913116	ROUND HEAD_D 4.8X18_MILD STEEL_DIN 7337	TATA spare parts
918041613001	M6 X 1_FE/ZN 12C2-YELLOW_POP NUT	TATA spare parts
918042403001	SOLID TYPE HOLLOW RIVET 4.8X18	TATA spare parts
918042414003	SELF LOCK PLASTIC RIVET (SPECIAL RIVETS)	TATA spare parts
918051105079	PRESSURE WASHER- 8 1X14.8X2.2-ZN 12C2	TATA spare parts
918062514127	CIRCLIP BS6	TATA spare parts
9188092600000000	CAB COMPLT RHD SLEEPER	TATA spare parts
9191037302	REGULATOR	TATA spare parts
91CX117C01	M20-2.5 50LG GRD 10.9 HEX HD BOLT	TATA spare parts
921100100043	GI TUBE 30X30X1.55	TATA spare parts
921100100153	GI TUBE¿¿ 30X30X1.55X530L	TATA spare parts
921100100357	30X30X1.55 GI TUBE 152	TATA spare parts
921100100364	30X30X1.55 GI TUBE 600	TATA spare parts
921100300265	30X40X1.55 GI_TUBE_CUT 40 L355A0B0	TATA spare parts
921100500179	40X20X1.95 GI_TUBE_CUT 20L206A-23B34	TATA spare parts
921100500237	40X20X1.95 GI_TUBE_CUT 20L233A-34B24	TATA spare parts
921100800181	40X40X1.95 GI TUBE LEN 375 MM	TATA spare parts

921100900003	CROSS GI TUBES	TATA spare parts
921102000146	60X40X2.7 GI_TUBE_CUT 60 L355A0B0	TATA spare parts
921102300376	80X40X1.95 GI_TUBE_CUT 80 L355A0B0	TATA spare parts
921102500002	STEEL TUBE SQUARE 294 40 X 40 X 1.55	TATA spare parts
921102500003	STEEL TUBE SQUARE 494 40 X 40 X 1.55	TATA spare parts
921102500429	40X40X1.55GITUBEL3802A0B0	TATA spare parts
921103500005	80X40X3.75 GI TUBE LEN 376 MM	TATA spare parts
921105600011	40X40X3.75 GI_TUBEL535A0B0 BS6	TATA spare parts
921105600017	40X40X3.75 GI_TUBEL677A22B22	TATA spare parts
922102800048	GI C PR OFILE_20X50X20X1.55-364	TATA spare parts
922104000337	40X40X13X20X1.25 GI SKIRT G PROFILE_2835	TATA spare parts
922204300008	MS L PROFILE 30X40X3 THK 30	TATA spare parts
92284	DIFF CASE CAP SCREW	TATA spare parts
923001600206	3 THK SHAPE-1_50 BS6	TATA spare parts
923001700001	LADDER MOUNTING SUPPORT PLATE	TATA spare parts
923002200126	6 THK SHAPE 1 155	TATA spare parts
923002200127	6 THK SHAPE 1 300	TATA spare parts
923100100078	GI PLATE 1.55MM X 55 X 50 BS6	TATA spare parts
923100400004	PLATE 355	TATA spare parts
923100400012	REIINFORCEMENT PLATES	TATA spare parts
923100400104	GI PLATE 1.95MM THK	TATA spare parts
923100400239	GI 1.95 THK SHAPE-1 600	TATA spare parts
923100400355	GI_1.95 THK SHAPE-1_50	TATA spare parts
923100400632	END PLATE	TATA spare parts
923101300047	GI PLATE 2.7MM THK_100X32	TATA spare parts
923101300048	GI PLATE 2.7MM THK X 120 X 70 BS6	TATA spare parts
923102500034	GI PLATE (825 X 9045 X 0.95)	TATA spare parts
923102500035	GI PLATE (825 X 7275 X 0.95)	TATA spare parts
923102500036	GI PLATE (825 X 950 X 0.95)	TATA spare parts
923102500037	GI PLATE (30 X 870 X 0.95)	TATA spare parts
923102500041	GI PLATE 870X35X0.95 THK BS6	TATA spare parts
923102500051	GI 0.95 THK SHAPE-1 9380	TATA spare parts
923102500062	GI 0.95 THK SHAPE-1 7600	TATA spare parts
923102500063	GI_0.95 THK SHAPE-1_960	TATA spare parts
923102500086	GI 0.95 THK SHAPE-1 9700	TATA spare parts
923102500091	G.I SHEETS__0.95 THK SHAPE-1_9430X695	TATA spare parts
923102500092	G.I SHEETS__0.95 THK SHAPE-1_7650X695	TATA spare parts
923102500093	G.I SHEETS 0.95 THK SHAPE-1 955X695	TATA spare parts
923102500113	GI 0.95 THK SHAPE-1 (55X30X0.95)SPACER 1	TATA spare parts
923102500127	GI 0.95 THK SHAPE 1 410	TATA spare parts
923102500202	GI_0.95 THK SHAPE-1_4230	TATA spare parts
923102500206	GI_0.95 THK SHAPE-1_4670	TATA spare parts
923102500209	GI_0.95 THK SHAPE-1_620	TATA spare parts
923102500217	GI 0.95 THK SHAPE	TATA spare parts
923102500231	GI_0.95 THK SHAPE-1_4320	TATA spare parts
923102500232	GI_0.95 THK SHAPE-1_5190	TATA spare parts
923102500234	GI_0.95 THK SHAPE-1_450	TATA spare parts

923102500259	025-GI_0.95 THK SHAPE-1_2750	TATA spare parts
923102500260	025-GI_0.95 THK SHAPE-1_725	TATA spare parts
923102500268	GI SHEET_0.95	TATA spare parts
923102500269	GI SHEET_0.95	TATA spare parts
923102500282	025-GI_0.95 THK SHAPE-1_2072 BS6	TATA spare parts
923102500283	025-GI_0.95 THK SHAPE-1_1384 BS6	TATA spare parts
923102800109	GI PLATE_1150X440X1.25MM	TATA spare parts
923103000001	GI PLATE 48 X 1136 X 0.65MM THK	TATA spare parts
923103000002	GI PLATE 48 X 1136 X 0.65MM THK	TATA spare parts
923103000015	GI PLATE 600X50X.65	TATA spare parts
923103000036	ROOF EXTERNAL PANEL 3	TATA spare parts
923103000037	GI PLATE 0.65MM THK_1136 LN	TATA spare parts
923103000043	GI-695 X 950 X 0.65	TATA spare parts
923103000044	GI SHEET -695X7930X0.65	TATA spare parts
923103000045	GI SHEET -695X9700X0.65	TATA spare parts
923103000046	REAR STERTCH PANEL	TATA spare parts
923103000048	GI-695 X 9420 X 0.65	TATA spare parts
923103000049	GI-695 X 7650 X 0.65	TATA spare parts
923103000051	GI PLATE 0.65MM THK	TATA spare parts
923103000052	GI PLATE 0.65MM THK	TATA spare parts
923103000053	GI PLATE 0.65MM THK	TATA spare parts
923103000054	GI PLATE 0.65MM THK	TATA spare parts
923103000055	GI PLATE 0.65MM THK	TATA spare parts
923103000056	GI PLATE 0.65MM THK	TATA spare parts
923103000057	GI PLATE 0.65MM THK	TATA spare parts
923103000058	GI PLATE 0.65MM THK	TATA spare parts
923103000059	GI PLATE 0.65MM THK	TATA spare parts
923103000060	GI PLATE 0.65MM THK	TATA spare parts
923103000061	GI PLATE 0.65MM THK	TATA spare parts
923103000062	GI PLATE 0.65MM THK	TATA spare parts
923103000064	GI PLATE 0.65 THK 148X1136	TATA spare parts
923103000065	GI PLATE 0.65 THK 716X1030	TATA spare parts
923103000079	GI 0.65 THK SHAPE-1 9380	TATA spare parts
923103000088	GI SHEET 870X60X0.65	TATA spare parts
923103000093	GI_0.65 THK SHAPE-1_1150	TATA spare parts
923103000096	GI_0.65 THK SHAPE-1_1150	TATA spare parts
923103000111	GI_0.65 THK SHAPE-1_LN4745	TATA spare parts
923103000112	GI_0.65 THK SHAPE-1_182	TATA spare parts
923103000115	GI_0.65 THK SHAPE-1_3800	TATA spare parts
923103000124	GI 0.65 THK SHAPE-1 10090	TATA spare parts
923103000125	GI 0.65 THK SHAPE-1 10505	TATA spare parts
923103000126	GI_0.65 THK SHAPE-1_4745	TATA spare parts
923103000139	GI 0.65 THK SHAPE-1 2090	TATA spare parts
923103000140	GI 0.65 THK SHAPE 1 6250	TATA spare parts
923103000147	GI_0.65 THK SHAPE-1_695X6500	TATA spare parts
923103000151	120X1136X0.65	TATA spare parts
923103000152	GI PLATE 110X1136X0.65	TATA spare parts

923103000161	GI 0.65 THK SHAPE1 9045	TATA spare parts
923103000162	GI 0.65 THK SHAPE1 6470	TATA spare parts
923103000163	GI 0.65 THK SHAPE1 2715	TATA spare parts
923103000169	68X1136X0.65	TATA spare parts
923103000179	GI 0 65 THK SHAPE 1	TATA spare parts
923103000181	GI 0 65 THK SHAPE 1	TATA spare parts
923103000193	GI_0.65 THK SHAPE-1_3800	TATA spare parts
923103000200	GI 0.65 THK SHAPE	TATA spare parts
923103000203	GI_0.65 THK SHAPE-1_4720	TATA spare parts
923103000205	GI 0.65 THK SHAPE-1 5005	TATA spare parts
923103000206	GI 0.65 THK SHAPE-1 790	TATA spare parts
923103000207	GI 0.65 THK SHAPE-1 3260	TATA spare parts
923103000208	GI 0.65 THK SHAPE-1 745	TATA spare parts
923103000209	GI 0 65 THK SHAPE 1 4230	TATA spare parts
923103000210	GI 0 65 THK SHAPE 1 4670	TATA spare parts
923103000228	GI 0.65 THK SHAPE-1 876	TATA spare parts
923103000239	GI 0.65 THK SHAPE 1 3220	TATA spare parts
923103000240	GI 0.65 THK SHAPE 1 3760	TATA spare parts
923103000241	GI 0.65 THK SHAPE 1 100	TATA spare parts
923103000242	GI 0.65 THK SHAPE 1 200	TATA spare parts
923103000246	GI_0.65 THK SHAPE-1_1915	TATA spare parts
923103000247	GI_0.65 THK SHAPE-1_6685	TATA spare parts
923103000248	REAR STERTCH PANEL	TATA spare parts
923103000252	GI PLATE 0.65 THK 706X1030	TATA spare parts
923103000254	GI 0.65 THK SHAPE-1 3728X706	TATA spare parts
923103000267	GI 0.65 THK SHAPE 1 670	TATA spare parts
923103000268	GI 0.65 THK SHAPE-1 7225	TATA spare parts
923103000272	GI 0.65 THK SHAPE 1 9040	TATA spare parts
923103000273	GI 0.65 THK SHAPE-1 6300X706	TATA spare parts
923103000274	GI 0.65 THK SHAPE-1 615X706	TATA spare parts
923103000275	G.I SHEET 0.65THK 6200X695	TATA spare parts
923103000276	GI_0.65 THK SHAPE-1_1136	TATA spare parts
923103000280	GI 0 65 THK SHAPE 1 227X870	TATA spare parts
923103000281	GI 0 65 THK SHAPE 1 390X1350	TATA spare parts
923103000282	GI 0 65 THK SHAPE 1 370X920	TATA spare parts
923103000283	GI 0 65 THK SHAPE 1 470	TATA spare parts
923103000284	GI 0 65 THK SHAPE 1 8150	TATA spare parts
923103000300	GI 0.65 THK SHAPE 1 2720	TATA spare parts
923103000301	GI 0.65 THK SHAPE-1 3830	TATA spare parts
923103000302	GI 0.65 THK SHAPE-1 6270	TATA spare parts
923103000303	GI_0.65 THK SHAPE-1_670	TATA spare parts
923103000311	GI_0.65 THK SHAPE-1_1135X170	TATA spare parts
923103000315	GI_0.65 THK SHAPE-1_752	TATA spare parts
923103000316	GI 0.65 THK SHAPE-1 6970	TATA spare parts
923103000320	GI_0.65 THK SHAPE-1_1136	TATA spare parts
923103000324	GI_0.65 THK SHAPE-1_7225	TATA spare parts
923103000326	GI_0.65 THK SHAPE-1_1822	TATA spare parts

923103000327	GI_0.65 THK SHAPE-1_1136	TATA spare parts
923103000328	GI_0.65 THK SHAPE-1_1136	TATA spare parts
923103000335	GI_0.65 THK SHAPE-1_920	TATA spare parts
923103000336	GI_0.65 THK SHAPE-1_6975	TATA spare parts
923103000337	GI0.65THKSHAPE-1650	TATA spare parts
923103000338	GI 0.65 THK SHAPE 1 757	TATA spare parts
923103000339	GI 0.65THK SHAPE 1 7168	TATA spare parts
923103000340	GI_0.65 THK SHAPE-1_1136	TATA spare parts
923103000341	GI_0.65 THK SHAPE-1_1136	TATA spare parts
923103000342	GI_0.65 THK SHAPE-1_1840	TATA spare parts
923103000343	GI_0.65 THK SHAPE-1_6200	TATA spare parts
923103000363	GI 0.65 THK SHAPE-1 738	TATA spare parts
923103000364	GI 0.65 THK SHAPE-1 2157	TATA spare parts
923103000367	GI_0.65 THK SHAPE-1_706X7680	TATA spare parts
923103000371	GI 0.65 THK SHAPE-1 5750	TATA spare parts
923103000372	GI 0.65 THK SHAPE-1 4650	TATA spare parts
923103000384	GI_0.65 THK SHAPE-1	TATA spare parts
923103000387	GI 0.65 THK SHAPE 1 636X8590	TATA spare parts
923103000388	GI_0.65 THK SHAPE-1_130X1080	TATA spare parts
923103000389	GI_0.65 THK SHAPE-1_288X910	TATA spare parts
923103000390	GI_0.65 THK SHAPE-1_130X1578	TATA spare parts
923103000391	GI_0.65 THK SHAPE-1_118X790	TATA spare parts
923103000392	GI_0.65 THK SHAPE-1_80X790	TATA spare parts
923103000408	GI_0.65 THK SHAPE-1_636 EV	TATA spare parts
923103000409	GI_0.65 THK SHAPE-1_636X670	TATA spare parts
923103000423	GI 0.65 THK SHAPE-1 920	TATA spare parts
923103000424	GI 0.65 THK SHAPE-1 6975	TATA spare parts
923103000426	GI_0.65 THK SHAPE-1_7745	TATA spare parts
923103000434	GI_0.65 THK SHAPE-1_6270	TATA spare parts
923103000435	GI_0.65 THK SHAPE-1_3830	TATA spare parts
923103000436	GI_0.65 THK SHAPE-1_2720	TATA spare parts
923103000458	GI_0.65 THK SHAPE-1_1136	TATA spare parts
923103000459	GI_0.65 THK SHAPE-1_1840	TATA spare parts
923103000463	GI_0.65 THK SHAPE-1_420 EV	TATA spare parts
923103000464	GI_0.65 THK SHAPE-1_4560	TATA spare parts
923103000465	GI_0.65 THK SHAPE-1_3000	TATA spare parts
923103000466	GI_0.65 THK SHAPE-1_7660	TATA spare parts
923103000470	3135X655X0.65_G.I SHEET BS6	TATA spare parts
923103000471	3335X655X0.65_G.I SHEET BS6	TATA spare parts
923103000472	2246X655X0.65_G.I SHEET BS6	TATA spare parts
923103000473	3505X655X0.65_G.I SHEET BS6	TATA spare parts
923103000489	GI PLATE 825X740X0.65 THK BS6	TATA spare parts
923103000492	GI PLATE 825X990X0.65 THK BS6	TATA spare parts
923103000493	GI PLATE 735X470X0.65 THK BS6	TATA spare parts
923103000507	030-GI_0.65 THK SHAPE-1_3860 BS6	TATA spare parts
923103000508	030-GI_0.65 THK SHAPE-1_714 BS6	TATA spare parts
923103000509	030-GI_0.65 THK SHAPE-1_1216 BS6	TATA spare parts

923103000510	030-GI_0.65 THK SHAPE-1_7543 BS6	TATA spare parts
923103000521	9X9 GEN_5 CESL SIDE EXT PNL NR RELEASE	TATA spare parts
92409046000101	DASH BOARD ASSY	TATA spare parts
928109100003	SMALL WINDOW ARTICULATION GUIDE BASE	TATA spare parts
928109100004	SMALL WINDOW ARTICULATION PLATE II	TATA spare parts
92CX108Z00	M24 X 2 AMPT HEX NUT	TATA spare parts
932286010001	SIKAFLEX 222 UV (600ML)	TATA spare parts
9330031010	SOLENOID SWITCH ( MICO EURO II ENG )	TATA spare parts
9330031012	SOLENOID SWITCH	TATA spare parts
93319040003202	REAR MID SEAT 2L LB PLASTIC BLUE FAB	TATA spare parts
93319040003270	RH 2 SEAT 2LG PMS 460CH AR BLUE FAB	TATA spare parts
93319040003271	LH 2SEAT 2LG PMS 460CH AR BLUE FAB	TATA spare parts
93319040003272	LH 1 SEAT 360CH 2LM AR BLUE FAB PMS	TATA spare parts
93319040003274	RH 2 SEAT 2LG PMS 460CH BLUE FAB	TATA spare parts
93319040003275	LH 2 SEAT 2LG PMS 460CH BLUE FAB	TATA spare parts
93319040003276	RH 2 SEAT 2LG PMS 360CH BLUE FAB	TATA spare parts
93319040003277	LH 2 SEAT 2LG PMS 360CH BLUE FAB	TATA spare parts
93319040003280	RH 2 SEAT 2LG PMS 500CH BLUE FAB	TATA spare parts
93319040003281	LH 2 SEAT 2LG PMS 500CH BLUE FAB	TATA spare parts
9400030240	FUEL INJ PUMP 692DI RSV	TATA spare parts
9400030241	INJECTION PUMP DI-D	TATA spare parts
9400030311	FUEL INJ PUMP RSV 692 D/R	TATA spare parts
9400030461	FUEL INJ PUMP 692 RQV F/R	TATA spare parts
9400030462	FUEL INJECTION PUMP ASSY	TATA spare parts
9400030465	INJ PUMP 697NA	TATA spare parts
9400030466	FUEL INJECTION PUMP	TATA spare parts
9400030499	FUEL INJ PUMP 692 RSV SFC	TATA spare parts
9400030500	FUEL INJ.PUMP W/RSV GOVR	TATA spare parts
9400030517	F I P 697 NA	TATA spare parts
9400030520	FUEL INJ.PUMP W/RQV GOVR.	TATA spare parts
9400030525	FUEL INJ PUMP 697SP RSV	TATA spare parts
9400030526	FIP 526	TATA spare parts
9400030547	FUEL INJ PUMP 497SP RSV	TATA spare parts
9400030578	FUEL INJECTION PUMP	TATA spare parts
9400030587	FUEL INJECTION PUMP	TATA spare parts
9400030596	FUEL INJECTION PUMP	TATA spare parts
9400030631	ASSY RQV FUEL INJ. PUMP 697NA	TATA spare parts
9400030634	F I P - 497 TC	TATA spare parts
9400030658	FUEL INJ PUMP 497D RSVLPT	TATA spare parts
9400030669	FUEL INJ PUMP 160HP EURO I INLINE	TATA spare parts
9400030707	FUEL INJ PUMP 145HP EURO I INLINE	TATA spare parts
9400030708	PUMP FUEL INJECTION 125HP EURO I	TATA spare parts
9400030716	FUEL INJ PUMP LP407 MOD	TATA spare parts
9400030726	FUEL INJ PUMP SFC407 MOD	TATA spare parts
9411033000	DIPSTICK	TATA spare parts
9411033404	HOLLOW SCREW	TATA spare parts
9411033406	SCREW TEMPER	TATA spare parts

9411033412	AIR VENT SCREW	TATA spare parts
9411033428	SCREW	TATA spare parts
9411035502	BEARING END PLATE	TATA spare parts
9411035738	BEARING END PLATE	TATA spare parts
9411036110	CAMSHAFT 608 FIP	TATA spare parts
9411036152	CAMSHAFT	TATA spare parts
9411037025	FUEL INJETOR PUMP R KIT	TATA spare parts
9411037203	PRIMING HANDPUMP	TATA spare parts
9411038339	ELEMENT	TATA spare parts
9411038351	ELEMENT PUMP	TATA spare parts
9411038352	ELEMENT	TATA spare parts
9411038384	ELEMENT 9.5MM H/PRESSURE	TATA spare parts
9411038384AE	ELEMENT 9.5MM H/PRESSURE 713	TATA spare parts
9411038547	DELIVERY VALVE	TATA spare parts
9411038558	DELIVERY VALVE	TATA spare parts
9411038576	DELIVERY VALVE	TATA spare parts
9411038578	DELIVERY VALVE	TATA spare parts
9412036105	CAMSHAFT	TATA spare parts
9412038344	ELEMENT 497D	TATA spare parts
9412038416	ELEMENT	TATA spare parts
9412038431	ELEMENT	TATA spare parts
9412038501	DELIVERY VALVE	TATA spare parts
9413038520	DELIVERY VALVE	TATA spare parts
9420030128	GOVERNOR ASSY RQV	TATA spare parts
9420039101	INJECTION TIMER 692DI	TATA spare parts
9420039103	INJECTION TIMER	TATA spare parts
9421030111	WASHER	TATA spare parts
9421030701	LOOPED BANJO	TATA spare parts
9421030703	LOOPED BANJO RSV	TATA spare parts
9421031000	LOCKING PLATE	TATA spare parts
9421031004	GASKET	TATA spare parts
9421031907	LEVER	TATA spare parts
9421031908	LEVER LP/DI	TATA spare parts
9421031993	STOP LEVER ASSY. RSV GOVERNOR	TATA spare parts
9421033107	GUIDE PIN	TATA spare parts
9421033419	SCREW	TATA spare parts
9421033422	SCREW LOW TEMPER PROOF	TATA spare parts
9421033429	ADJUSTING SCREW	TATA spare parts
9421033430	CLOSING PLUG	TATA spare parts
9421033432	MAX SPEED SCREW	TATA spare parts
9421035673	GOVERNOR ALONE	TATA spare parts
9421035705	FLANGE	TATA spare parts
9421036300	DRIVE GEAR ASSY	TATA spare parts
9421036403	DRIVER	TATA spare parts
9421037005	RSV GOVERNOR KIT	TATA spare parts
9421037123	CONTROL ROD STOP	TATA spare parts
9421037400	AIR BREATHER	TATA spare parts



9421038106	FLY WEIGHT	TATA spare parts
9422035687	GOVERNOR COVER	TATA spare parts
9430031300	NOZZLE HOLDER	TATA spare parts
9430032212	NOZZLEHOLDER TC	TATA spare parts
9430032234	NOZZLE HOLDER WITH NOZZLE	TATA spare parts
9430032264	NOZZLE HOLDER W/NOZZLE	TATA spare parts
9430032266	NOZZLE W/HOLDER	TATA spare parts
9430032280	NOZZLE W/HOLDER 483DL	TATA spare parts
9430032304	NOZZLE W/HOLDER 497D	TATA spare parts
9430032328	INJECTOR 4DL TC	TATA spare parts
9430034243	NOZZLE 692DI	TATA spare parts
9430034245	NOZZLE	TATA spare parts
9430034271	NOZZLE 697TC	TATA spare parts
9430034284	NOZZLE 4SP 6SP	TATA spare parts
9430034717	NOZZLE 497D	TATA spare parts
9430037209	NOZZLE OM312	TATA spare parts
9430037232	NOZZLE 483DL	TATA spare parts
9431030149	SHIM 2.00 MM	TATA spare parts
9431030154	SHIM 2.20 MM	TATA spare parts
9431030157	SHIM 2.32 MM	TATA spare parts
9431030158	INJECTOR SEALING	TATA spare parts
9431030172	SEALING WASHER	TATA spare parts
9431031300	SEALING RING	TATA spare parts
9440030002	FEED PUMP	TATA spare parts
9440030003	ASSY. FEED PUMP BS1	TATA spare parts
9440030003AE	PUMP FUEL TRANSFER 713	TATA spare parts
9440030011	FEED PUMP ASSY 407	TATA spare parts
9440030023	FEED PUMP	TATA spare parts
9440030024	FEED PUMP	TATA spare parts
9440030028	FEED PUMP ASSY	TATA spare parts
9440030028AE	FEED PUMP FUEL 713	TATA spare parts
9440030029	FEED PUMP ASSY 495DI	TATA spare parts
9440030030	FEED PUMP ASSY	TATA spare parts
9440030036	ASSY FEED PUMP	TATA spare parts
9440030037	FEED PUMP - LP 609	TATA spare parts
9440030037AE	FEED PUMP - LP 609 713	TATA spare parts
9440030038	FEED PUMP	TATA spare parts
9440037000	LINE HAND PRIMER-697TC EURO II	TATA spare parts
9441030202	SHAFT SEALING RING	TATA spare parts
9441032101	ROLLER TAPPET	TATA spare parts
9441033112	PRESSURE SPINDLE	TATA spare parts
9441033404	CLOSING PLUG	TATA spare parts
9441033412	BLEEDER DRAIN SCREW	TATA spare parts
9441037000	REP KIT FEED PUMP	TATA spare parts
9441037001	REPAIR KIT FEED PUMP	TATA spare parts
9441037202	PRIMING PUMP 207	TATA spare parts
9441037203	PRIMING PUMP HAND(201B3)	TATA spare parts

9450030106	FUEL FILTER ASSY DUAL	TATA spare parts
9450030107	FUEL FILTER ASSY	TATA spare parts
9450030116	FUEL FILTER ASSY DUAL	TATA spare parts
9450030118	FUEL FILTER SFC	TATA spare parts
9450030205	WATER SEPARATOR	TATA spare parts
9450030209	STRAINER ASSY	TATA spare parts
9450035101	FUEL FILTER HSG.W/HAND PR	TATA spare parts
9451030105	SEALING SPG.	TATA spare parts
9451030109	O RING FILTER BOWL	TATA spare parts
9451030528	FILTER HOUSING	TATA spare parts
9451035101	BOWL FUEL FILTER	TATA spare parts
9451035110	FILTER HOUSING	TATA spare parts
9451035111	FILTER HOUSING	TATA spare parts
9451035532	FILTER COVER	TATA spare parts
9451035533	COVER FUEL FILTER	TATA spare parts
9451035553	COVER FOR FUEL FILTER-554	TATA spare parts
9451035554	COVER	TATA spare parts
9451035558	COVER D/FLOW FUEL FILTER	TATA spare parts
9451037404	FUEL FILTER ELEMENT CARTRIDGE BS1/2/3	TATA spare parts
9451037404DF	FUEL FILTER 0.5 L CLOTH	TATA spare parts
9451037405	PAPER ELEMENT STAR TYPE BS2/3	TATA spare parts
9451037405DF	FUEL FILTER 0.5 L STAR	TATA spare parts
9451037406	FUEL PAPER ELEMENT BS2/3	TATA spare parts
9451037406DF	FUEL PAPER 1.1 L STAR	TATA spare parts
9451037407	FUEL PAPER ELEMENT BS1/2/3/4	TATA spare parts
9451037407DF	FUEL FILTER 0.5L PAPER	TATA spare parts
9451037409	FUEL FILTER ELEMENT	TATA spare parts
9451037409DF	FUEL FILTER 1.1 L COIL	TATA spare parts
9451037430	INTEGRAL O/FLOW VALVE	TATA spare parts
9451037457	STRAINER ASSY.	TATA spare parts
9460034410	FUEL INJ PUMP 483DL	TATA spare parts
9460034413	FUEL INJ PUMP 483DLNA NEW	TATA spare parts
9461035104	PUMP HOUSING	TATA spare parts
9461037002	KIT SEALING	TATA spare parts
94CX100Z00	M24 HARDENED WASHER	TATA spare parts
957433056001	TIE ROD ASSEMBLY	TATA spare parts
95AL210C01	MACHINED BUSH SADDLE WELDMENT LH	TATA spare parts
95AR210C01	MACHINED BUSH SADDLE WELDMENT RH	TATA spare parts
96284	DIFF CASE CAP SCREW	TATA spare parts
9675114321	CLIP-RETURN CYLINDER LOCK	TATA spare parts
96CX001Z00	M24 X 2.0 CLASS 10.9 U BOLT	TATA spare parts
973586	AIR CHAMBER	TATA spare parts
97CX001Z00	CIRCLIP ROD END	TATA spare parts
98590	CARRIER & CAP	TATA spare parts
99000330006	AIR VENT ASSEMBLY	TATA spare parts
99000340027	HOLD DOWN WHEEL	TATA spare parts
99000340056	GAP ADJUSTING ARM ASSEMBLY (LEFT)	TATA spare parts

99000340057	GAP ADJUSTING ARM ASSEMBLY (RIGHT)	TATA spare parts
99000340061	BRAKE SHOE	TATA spare parts
99000340062	BRAKE FLOOR	TATA spare parts
99000340064	PIN AXLE	TATA spare parts
99000340068	BRAKE FRICTION PLATE	TATA spare parts
99000340070	BRAKE SHOE ASSEMBLY	TATA spare parts
99000360060	DIAPHRAGM BRAKE CHAMBER	TATA spare parts
99000398026	PACKING WASHER	TATA spare parts
99000410016	FRONT AXLE FORK	TATA spare parts
99000410021	CAP	TATA spare parts
99000410022	PROTECTION CLIP	TATA spare parts
99000410031	STEERING CROSS ROD ARM ASSEMBLY (LEFT)	TATA spare parts
99000410032	STEERING CROSS ROD ARM ASSEMBLY (RIGHT)	TATA spare parts
99000410103	WHEEL BOLT	TATA spare parts
99000410107	AXLE-PACKING RING CASE	TATA spare parts
99000410120	AIR VENT ASSEMBLY	TATA spare parts
99000420049	INSIDE GEAR RING	TATA spare parts
99000420050	PLANETARY	TATA spare parts
99000440017	BRAKE FRICTION PLATE	TATA spare parts
99000440018	BRAKE PREVENTED CAP	TATA spare parts
99004320031	PIERCING AXLE	TATA spare parts
99012250031	CIRCLE NUT	TATA spare parts
99012320002	HORSE SHOE BUSHING	TATA spare parts
99012320008	DIFFERENTIAL CASE (RIGHT)	TATA spare parts
99012320009	HALF AXLE GEAR	TATA spare parts
99012320010	PLANET GEAR	TATA spare parts
99012320014	DECLUTCH SHIFT	TATA spare parts
99012320023	BEND PLATE	TATA spare parts
99012320097	FINAL DRIVE CASE	TATA spare parts
99012320103	BEARING SEAT	TATA spare parts
99012320121	RING	TATA spare parts
99012320133	PACKING RING	TATA spare parts
99012320150	PLANET GEAR WASHER	TATA spare parts
99012320184	AXLE PACKING RING	TATA spare parts
99012320194	AXLE PACKING RING	TATA spare parts
99012320197	DIFFERENTIAL CASE(LEFT)	TATA spare parts
99012340004	PLANET GEAR AXLE	TATA spare parts
99012340005	CENTRAL GEAR	TATA spare parts
99012340011	END CAP PIN	TATA spare parts
99012340017	SPACING COLLAR	TATA spare parts
99012340018	OIL BAFFLE DISC	TATA spare parts
99012340020	PACKING RING	TATA spare parts
99012340021	OIL BAFFLE CAP	TATA spare parts
99012340023	AXLE SHAFT (LEFT)	TATA spare parts
99012340024	AXLE SHAFT (RIGHT)	TATA spare parts
99012340027	PACKING RING	TATA spare parts
99012340029	PACKING RING	TATA spare parts

99012340066	CHAMBER BEARER	TATA spare parts
99012340075	PLANET GEAR WASHER	TATA spare parts
99012340076	CENTRAL GEAR WASHER	TATA spare parts
99012340077	WASHER	TATA spare parts
99012340082	REAR WHEEL HUB ASSEMBLY	TATA spare parts
99012340093	AXLE PACKING RING	TATA spare parts
99012340094	AXLE PACKING RING	TATA spare parts
99012340113	AXLE PACKING RING -CONTROL CHART	TATA spare parts
99012340114	AXLE PACKING RING -CONTROL CHART	TATA spare parts
99012340121	INSIDE GEAR RING	TATA spare parts
99012340122	PLANET GEAR	TATA spare parts
99012340123	WHEEL BOLT	TATA spare parts
99012410005	HEX NUT	TATA spare parts
99014320032	AXLE SHAFT GEAR (FRONT)	TATA spare parts
99014320037	PACKING RING FOR AXLE	TATA spare parts
99014320039	PACKING RING FOR AXLE	TATA spare parts
99014320056	DECLUTCH SHIFT	TATA spare parts
99014320059	AXLE SHAFT GEAR (REAR)	TATA spare parts
99014320061	DIFFERENTIAL LOCK WASHER BETWEEN AXLE	TATA spare parts
99014320076	ROCKER ARM	TATA spare parts
99014320091	CROSS AXLE	TATA spare parts
99014320119	FINAL DRIVE CASE	TATA spare parts
99014320127	DIFFERENTIAL CASE (LEFT)	TATA spare parts
99014320128	BEARING EXTERNAL RING	TATA spare parts
99014320129	BEARING SEAT	TATA spare parts
99014320130	REAR DIFFERENTIAL CASE	TATA spare parts
99014320135	HOLLOWNESS AXLE	TATA spare parts
99014320137	PASSIVE SPUR GEAR	TATA spare parts
99014320139	DIFFERENTIAL CASE (FRONT)	TATA spare parts
99014320140	CAULKING RING	TATA spare parts
99014320141	BEARING SEAT	TATA spare parts
99014320144	PASS AXLE BOX CAP	TATA spare parts
99014320153	DIFFERENTIAL CASE WASHER	TATA spare parts
99014320154	FLANGE ASSEMBLY (DIA 180)	TATA spare parts
99014320156	BEARER ASSEMBLY	TATA spare parts
99014320174	OIL BAFFLE	TATA spare parts
99014320175	COVER	TATA spare parts
99014320209	ACTIVE SPUR GEAR	TATA spare parts
99014320256	STEEL WIRE COLLAR	TATA spare parts
99014320257	ROLLER BEARING	TATA spare parts
99014320259	PASS AXLE BOX	TATA spare parts
99014320261	FLANGE ASSEMBLY (DIA 180)	TATA spare parts
99014330125	OPERATION HANDLE ASSEMBLY	TATA spare parts
99014330146	BOW HOLD OPEN CATCH ASSEMBLY (DOWN)	TATA spare parts
99014330147	BOW HOLD OPEN CATCH ASSEMBLY (UP)	TATA spare parts
990143330147	BOW HOLD OPEN CATCH ASSEMBLY (UP)	TATA spare parts
99014340041	CAMSHAFT BEARER	TATA spare parts

99014340042	CHAMBER BEARER	TATA spare parts
9904036000	SPLIT PIN	TATA spare parts
99100410002	BUSH	TATA spare parts
99100410008	BOSS	TATA spare parts
99100410027	AXLE PACKING RING	TATA spare parts
99100410030	AXLE-PACKING RING	TATA spare parts
9910512750	BOLT-HEX HEAD M12X1.25	TATA spare parts
9910512800	BOLT-HEX HEAD M12X1.25	TATA spare parts
9910516700	HEX BOLT M16X1.5	TATA spare parts
9910516800	HEX BOLT M16X1.5	TATA spare parts
9910562600	HEX HEAD BOLT M12X1.25	TATA spare parts
9910614450	BOLT-HEX HD M14 X 1.5	TATA spare parts
9910614500	HEX BOLT M14X1.5	TATA spare parts
9910614550	HEX BOLT M14X1.5	TATA spare parts
9910616500	HEX BOLT M16X1.5	TATA spare parts
99112320030	AXLE PACKING RING	TATA spare parts
99112320031	AXLE PACKING RING	TATA spare parts
99112330016	PIN (FOR 16 T)	TATA spare parts
99112340001	END CAP	TATA spare parts
99112340006	BRAKE DRUM	TATA spare parts
99112340011	REAR WHEEL HUB ASSEMBLY (ABS)	TATA spare parts
99112340012	BRAKE PREVENTED DUST CAP (FOR ABS BRAKE)	TATA spare parts
99112340018	PLANET SHELF	TATA spare parts
99112340020	GEAR RING BEARER	TATA spare parts
99112340026	BRAKE CAMSHAFT (LEFT)	TATA spare parts
99112340027	BRAKE CAMSHAFT (RIGHT)	TATA spare parts
99112340049	RETURN SPRING	TATA spare parts
99112410040	MOUNTED PLATE	TATA spare parts
99112410041	MOUNTED PLATE	TATA spare parts
99112440003	BRAKE DRUM	TATA spare parts
99112440024	BRAKE CAMSHAFT (LEFT)	TATA spare parts
99112440025	BRAKE CAMSHAFT (RIGHT)	TATA spare parts
9915512350	BOLT-T/M MTG	TATA spare parts
9920412400	HEX BOLT M12X1.25	TATA spare parts
9920512300	HEX HEAD BOLT M12X1.25	TATA spare parts
9920512350	HEX BOLT M12X1.25	TATA spare parts
9920512400	HEX BOLT M12X1.25	TATA spare parts
9920512500	HEX BOLT M12X1.25	TATA spare parts
9920514350	HEX BOLT M14X1.5	TATA spare parts
9920514450	HEX BOLT M14X1.5	TATA spare parts
9920516400	HEX BOLT M16X1.5	TATA spare parts
9920614350	HEX BOLT M14X1.5	TATA spare parts
9920614400	HEX BOLT M14X1.5	TATA spare parts
992073015860R	ASSY COWL COMPLETE	TATA spare parts
992073025560R	LPO1512/55 EURO-III-APSRTC F/LESS -COWL	TATA spare parts
992073055860R	COWL LPO1512TC/58 BS3 KESRTC NOR SUP	TATA spare parts
992073065531L	ASSY.FRAME COMPLETE (LPO 55 W.B/60%ROH)	TATA spare parts

992073065560L	LPO-1512 LHD COWL PARTS	TATA spare parts
992073105331R	ASSY.FRAME COMPLETE (LPO1512TC/53 KSRTC)	TATA spare parts
992073105360R	COWL LPO-1512/53-TC-EURO-II-KSRTC	TATA spare parts
992073115831R	ASSY FRAME/BSIV/LPO1512TC/58	TATA spare parts
992073215860R	COWL LPO 1512TC/58 BS3 ABS RJN	TATA spare parts
992073375560R	COWL LPO1512/55 TC BS II UPSRTC	TATA spare parts
992073415560R	LPO1512/55 TC BS III-W/O FACE COWL PARTS	TATA spare parts
992073435331R	ASSY.FRAME COMP FOR NEW RECP ENG W/O SL	TATA spare parts
992073435360R	LPO 1512/53 BS3 KSRTC W/O SL COWL PARTS	TATA spare parts
992073445331R	ASSY.FRAME COMP FOR NEW RECP ENG WITH SL	TATA spare parts
992073445360R	COWL LPO 1512/53 BS3 KSRTC	TATA spare parts
992073465360R	ASSY COWL COMPLETE	TATA spare parts
992073485360R	LPO 1512/53 BS3 KSRTC RADIAL TYRE - COWL	TATA spare parts
992073535360R	LPO1512/55-TC-EURO-III-APSRTC COWL PARTS	TATA spare parts
992073565360R	COWL LPO1512/53 TC BS3 TNSTC 9XR20	TATA spare parts
992073585360R	ASSY COWL COMPLETE	TATA spare parts
992073585560R	COWL LPO1512/55 TC BS II HARYANA	TATA spare parts
992073605560R	LPO1512TC/55BSIII MULTIPLEXING COWL PART	TATA spare parts
992073645560R	COWL LPO 1512/55 BS3 NEW-REC	TATA spare parts
992073685560R	COWL LPO1512/55-TC-EURO-III-UPSRTC	TATA spare parts
992073715531R	ASSY FRAME COMPLETE (LPO 1512 WEVELLER)	TATA spare parts
992073715560R	COWL LPO1512/55TC APSRTC(NYLON TYRE)	TATA spare parts
992073725560R	COWL LPO1512/55-TC-EURO-III-APSRTC	TATA spare parts
992073735531R	ASSY FRAME FRONT WEV REAR P/SUP W/O SL	TATA spare parts
992073755560R	LPO 1512/55 BS3 FACE-NEW-REC-PVT COWL PA	TATA spare parts
992073775560R	COWL LPO1512/55-TC-EURO-III-HREC	TATA spare parts
992073795560R	COWL PARTS LPO-1512/55-TC-EURO-III ARMY	TATA spare parts
992073805560R	LPO 1512TC/55 TAMILNADU - COWL PARTS	TATA spare parts
992073885560R	LPO1512.55BS3COWLPARTS	TATA spare parts
992073895560R	LPO 1512TC/55 PRIVATE - COWL PARTS	TATA spare parts
992073945560R	COWL LPO 1512TC/55 PRTC	TATA spare parts
992073965560R	LPO1512/55-E-III-APSRTC F/L - COWL PARTS	TATA spare parts
992073985560R	LPO1512/55 TC BS I COWL PARTS SRI LANKA	TATA spare parts
992073995560R	LPO1512/55 TC BS I COWL PARTS SRI LANKA	TATA spare parts
992080223260R	LPS3518 TC BS-III ERGO - CAB PARTS	TATA spare parts
992080233260R	LPS3518 TC BS-III KB - CAB PARTS	TATA spare parts
992080243260R	LPS3518 TC BSIII ERGO W/O TELEMATICS CAB	TATA spare parts
992080263260R	LPS3518 TC BSIII /R&C/ CAB	TATA spare parts
992080273260R	CAB LPS3518 TC BSIII R&C	TATA spare parts
992082363260R	CAB LPS4018 TC BS-III	TATA spare parts
992082453260R	CAB LPS4018 TC BSIII R&C	TATA spare parts
99215332101R	ASSY SHOCK ABSORBER - RETRO	TATA spare parts
99215333105R	THRUST BEARING NORMAL	TATA spare parts
99215360002R	ASSY CAB COMPL LPT 1109/36 EX BS II RHD	TATA spare parts
992163016060R	LPO 1621AT/59 FE DIESEL COWL PARTS	TATA spare parts
992163036260R	COWL LPO 1610/62TC EURO II 100HP	TATA spare parts
992163076260R	COWL PARTS LPO 1610/62TC LATEST NORMS	TATA spare parts

992163116260R	COWL LPO 1612/62TC BS-3	TATA spare parts
992163166260R	COWL COMPL. LPT 1613/62 TC LONG TRUCK	TATA spare parts
992163216231R	ASSY FRAME LPO 1618 BS3 GSRTC.FRAME WEV/	TATA spare parts
992163346260R	LPO1616TC/62-W/O P/N SUPN COWL PARTS	TATA spare parts
992163466231R	ASSY. FRAME LPO1612TC/62 BS-3	TATA spare parts
992163466260R	LPO 1612/62TC BS3- COWL PARTS	TATA spare parts
992163506260R	ASSY COWL COMPLETE WITH FITMENTS RHD	TATA spare parts
992163636231R	ASSY. FRAME COMPLETE.LPO1612/62 PN. SUSP	TATA spare parts
992163636260R	COWL LPO1612TC/62 MSRTC WITH RANE STG	TATA spare parts
992163646231R	ASSY. FRAME LPT1613TC/62 TRUCK BS3	TATA spare parts
992163646260R	COWL LPT1613/62TC BS-3 LONG TRUCK	TATA spare parts
992163716260R	COWL LPO 1618 TC/62 BSIII W/O SL	TATA spare parts
992163746231R	ASSY FRAME LPO P418 TC/62 BSIII KSRTC	TATA spare parts
992163756260R	LPO 1616 BS4 G600-COWL PARTS	TATA spare parts
992163816260R	LPO 1618 TC/62 BSIII VR119 -COWL PART	TATA spare parts
992163926231R	ASSY FRAME WITH OUTRIGGER LPO1621/62 AJL	TATA spare parts
992163926260R	LPO 1621AT/62 AJL COWL PARTS	TATA spare parts
992163946260R	LPT 1613 CC WITH ERGO-PACK -COWL	TATA spare parts
992163976231R	LPO 1618/62 ISBE 5.9 BS III 900 FRAME	TATA spare parts
992163976260R	LPO 1618/62 ISBE 5.9 BS III 900 COWL	TATA spare parts
992163996260R	LPO 1618 BS3 CC ERGO COWL	TATA spare parts
992165125560R	COWL LPO1613/55 697 SUPER MILO	TATA spare parts
992165145260R	LP1613/52 697 BSII SUPERMILO-COWL PARTS	TATA spare parts
992165155560R	ASSY COWL LPO1613/55 697BSII SUPERMILO A	TATA spare parts
992165175960R	COWL LP1613/59 697 BS4 (OBD-II)	TATA spare parts
992165185560R	LPO1613/697 BS4 SUPERMILO COWL W/O FACE	TATA spare parts
992165225260R	LP1613/52 697 BS4 COWL PARTS	TATA spare parts
992165225560R	LPO1613/697 OBD 2 BS4¿ COWL PARTS	TATA spare parts
992165235260R	LP1613/52 697 BS4 (OBD-II) COWL PARTS	TATA spare parts
992165235560R	COWL LPO1613/697 OBD2 BS4 APSRTC	TATA spare parts
992167073860R	CAB ASSY LPK 2518 TC BS-III	TATA spare parts
992167083860R	LPK 2518 TC BS-III ERGO CAB PARTS	TATA spare parts
992167213860R	CAB LPK 2518 TC BS-II	TATA spare parts
992167263860R	CAB LPK 2518 TC BS-III	TATA spare parts
99217946001R	ASSY STG G.B WITH PIT.ARM UJ LPT 1116	TATA spare parts
992182073660R	ASSY CAB LPK 1618 TC BS-III	TATA spare parts
992186016331R1	ASSY FRAME (FRT MOD) LPO1623 CNG	TATA spare parts
99219042101R	INTERGRAL CHAMBER BKT + S CAM SHAFT-RETR	TATA spare parts
99219042102R	S CAM SHAFT- RETRO	TATA spare parts
99219042104R	RETRO KIT LINING WITH RIVETS	TATA spare parts
99219043101R	ADDTION OF INTEGRAL BR. CHAMBER PIPES	TATA spare parts
99219046102R	KIT OF ADAPTOR + PIPELINE - RETRO	TATA spare parts
99219046103R	ZF KIT OF ADAPTOR + PIPELINE -RETRO	TATA spare parts
99219046104R	RANE PLASTIC RESERVOIR- RETRO	TATA spare parts
99219046105R	RANE KIT OF ADAPTOR + PIPELINE - RETRO	TATA spare parts
99219047101R	ASSLY PROTCT FILTER WITH LINES -RETRO	TATA spare parts
99219047102R	FUEL TANK -RETRO	TATA spare parts

99219049102R	ASSY FRONT EXH PIPE WITH INNER WELDING -	TATA spare parts
99219054101R	P CLAMP - RETRO	TATA spare parts
99252500005L	LP613 EII PS 24 VOLT LHD CKD RUSSIA	TATA spare parts
99252500036R	ASY.ENG. 697TC EII PS HD RHD SOUTH	TATA spare parts
99252500037R	ENGINE COMPLETE LPT 1116 SOUTH AF	TATA spare parts
99252500102L	ASSY ENGINE 697 EIV PS HD 613 LHD	TATA spare parts
99252550003R	ASSY. RADIATOR INTER COOLER & RD E FRAM	TATA spare parts
99252550004R	ASSY. RADIATOR INTER COOLER & RD E FRAM	TATA spare parts
99252700112R	ASSY ENGINE LPT 1212 CR BS-3 WITH 330 DI	TATA spare parts
99252701101R	OIL SUMP + HEAD GASKET + OIL SUMP GASKET	TATA spare parts
99252715101R	ALTERNATOR BRG + ALTERNATOR TENSIONING	TATA spare parts
99252720101R	WATERPUMP- RETRO	TATA spare parts
99252720102R	THERMOSTAT-RETRO	TATA spare parts
99252750001R	ASSY.RADIATOR & INTRCOOLER LPT 709 S.A.	TATA spare parts
99264333003L	ASY FRONT AXLE LHD ABS PROVN PS RTCD	TATA spare parts
99264346001L	ASSY STG G.B WITH PIT.ARM UJ& BKT	TATA spare parts
99264349004L	ASSY EXHAUST BRAKE UNIT 24 V LP 613 E II	TATA spare parts
99266135015R	ASY REAR AXLE (ABS) LP 613/38 LHD RUSSIA	TATA spare parts
99267360003L	ASSY COWL COMPL LP613/38 LHD	TATA spare parts
99267360005L	ASY.DASH BOARD GRAY COMPL LP 613 E II	TATA spare parts
99267360006L	ASYCABLPT613EII	TATA spare parts
99267360082R	ASSY.CAB COMPL LPT	TATA spare parts
99267360085R	ASSY CAB COMPL LPT 1109/42 EX BS II RHD	TATA spare parts
99267360105L	ASSY D /BOARD WT CLUSTER AND SWITCHES	TATA spare parts
99267360107L	ASSY. CAB COMP. LPT 613/38 -LHD EURO4	TATA spare parts
99267360109L	LPT-613 EX LHD CAB FOR RUSSIA	TATA spare parts
99267360118R	ASSY CAB FITTED LPT-1212 EX2 CR RHD	TATA spare parts
99267360119R	ASSY SLPR CAB LPT 1212 48 WB BS-3 ABS B	TATA spare parts
99267360121R	LPT-709EX2 RHD CABIN	TATA spare parts
99267360123R	ASSY CAB LPT407/27WB BS2 B.DESH CKD WITH	TATA spare parts
99268426023R	ASSY GEAR BOX G76 4.1 XENON 2.2 L DICOR	TATA spare parts
99268426024R	ASSY G76/4.1 4X2 BUC WT CLH HSG CNG	TATA spare parts
99268426025R	ASSY G76/4.1 4X2 BUC CLH HSG 73OD CNG	TATA spare parts
99268426026R	ASY G.B.G76 4.1 XENON 2.2LDICOR LONG LEV	TATA spare parts
99268426028R	ASSY G76/4.1 4X2 BUC CLH HSG NEW LINKAGE	TATA spare parts
99268426029R	ASSY G76/4.1 4X2 BUC CLH HSG CPL FLNG	TATA spare parts
99268426030R	ASSY G 76 4.1XENON 2.2L CPL FLNG	TATA spare parts
99268426101R	G/BOX G76/4.1 XENON 2.2L DICOR 4X4 BU	TATA spare parts
99268426103R	ASY G76-5/4.1 XEN CNG 4X2 MK-II CL HSG	TATA spare parts
99268426104R	ASY G76-5/4.1 XEN CNG MK-II CPL FL CLHSG	TATA spare parts
99268426108R	ASY G76-5/4.1 XEN 2.2L 4X2 MK-II CLHSG	TATA spare parts
99268426109R	ASY G76-5/4.1 XEN 2.2L MK-II CPL FL CLHS	TATA spare parts
992705973460R	ASSY.CAB COMPLETE-RHD	TATA spare parts
99270746006R	ASSY STG G.B WITH PIT.ARM UJ	TATA spare parts
99272425101R	CAST CLUTCH COVER ASSLY -RETRO	TATA spare parts
99273035104R	RA BEAM SPIGOTTED-RETRO	TATA spare parts
99273035105R	REAR HUB ASSLY -RETRO	TATA spare parts



99273035106R	REAR HUB ASSLY	TATA spare parts
99273235005R	ASSY REAR AXLE LPT 1518 SA	TATA spare parts
99274760005R	ASSY CAB COMP-1518 EX2 CKD N/SLPRER	TATA spare parts
99274760006R	ASSY CAB COMP-RHD 1518 SLP CAB S.A.	TATA spare parts
99274760007R	FOOT STEP	TATA spare parts
99274760106R	ASSY CAB 1518 RHD NSLPR BS2 ABS SLD CKD	TATA spare parts
99274760107R	ASSY.CAB LPT-1518 SLPR BS2 ERGO PACK ABS	TATA spare parts
99274760108R	ASSY CAB LPT 1918 48 WB E2 ERGO ABS SOUT	TATA spare parts
992750085560L	LPO-1316 LHD (G600) COWL PARTS	TATA spare parts
992750085560R	COWL COMPLETE LPO 1316/55 G600 RHD	TATA spare parts
992750095560L	COWL LPO-1318 LHD	TATA spare parts
992750165560L	COWL LPO-1316 LHD WEVELLER SUSPN.	TATA spare parts
992750175560L	LPO-1316 LHD WEV SUSPN. ABS COWL PARTS	TATA spare parts
992750215560L	COWL LPO-1618 LHD	TATA spare parts
992750275560L	LPO-1618 LHD ABS COWL PARTS	TATA spare parts
992754016260R	COWL LPT 1615 CC WITH ERGO-PACK	TATA spare parts
992770075960R	LP 1512/59 TC BS-II -COWL PARTS W/O FACE	TATA spare parts
992770114860R	LP 1512TC/48 BS-III NGT FACE- COWL PARTS	TATA spare parts
992770405260R	COWL LP 1512TC/52 BS-III ABS	TATA spare parts
992770494260R	COWL LP 1512/42 BS3 NEW-REC	TATA spare parts
992770505260R	COWL LP 1512TC/52 BS3	TATA spare parts
992770524260R	LP 1512/42 TC BS3 NGT FACE- COWL PARTS	TATA spare parts
992770574260R	COWL LP 1512/42 TC BS3 HRTC FES	TATA spare parts
992770575260R	LP 1512/52 BS3 HRTC FACE COWL PARTS	TATA spare parts
992770585260R	LP 1512TC/52 BS-III PUNBUS-COWL PARTS	TATA spare parts
992770595960R	COWL PARTS LP 1512TC/59 BS-III MSRTC	TATA spare parts
992770615960R	LP 1512TC/59 BS-III NGT-COWL PARTS	TATA spare parts
992770625260R	NGT FACE COWL PARTS	TATA spare parts
992770625960R	COWL PARTS LP 1512TC/59 BS-III TNSTC	TATA spare parts
992770635960R	COWL LP 1512TC/59 BS-III TNSTC	TATA spare parts
992770655260R	LP 1512/52 BS3 APSRTC COWL PARTS	TATA spare parts
992770685260R	COWL LP 1512/52 BS3 HRTC FES	TATA spare parts
992776125560R	LPO1613 697CNG BSIV EXTD. FOH COWL PARTS	TATA spare parts
992776265560R	LPO 1613CNG BSIV 5.7SGI OBDII - COWL	TATA spare parts
992776285560R1	LPO 1613CNG BS4 OBDII(10R20) -COWL PARTS	TATA spare parts
992778075560R	LPO1510/55 CGS BS III - COWL	TATA spare parts
992782016060R	LPT 2515/60 TC BS-II - COWL PARTS	TATA spare parts
99278600014R	COMPLETE LPT1518 N/S ENGINE WITH GEARBOX	TATA spare parts
99278650004R	ASSY. RADIATOR INTER COOLER	TATA spare parts
99278801101R	ASSEMBLY ENGINE WITH CLUTCH AND GEAR BOX	TATA spare parts
99278900001L	ASY ENG 2.2L DICOR EIII PS AC	TATA spare parts
99278900001R	ASSY ENG 2.2L DICOR E3 PS AC RHD	TATA spare parts
99278900002R	ENG 2.2L DICOR E3 PS W/O A/C COMPRS BKT	TATA spare parts
99278900005L	ENGINE 2.2DICOR(140PS)-AC+PS+HD EURO-II	TATA spare parts
99278900005R	ENG 2.2L DICOR E3PSACXENON RHD THLD	TATA spare parts
99278900006R	ENGINE 2.2L DICOR-AC+PS E-IV W/CLUTCH	TATA spare parts
99278900101R	2.2L DICOR(140PS)-AC+PS EURO-II FOR XENO	TATA spare parts

99278900111R	ASSY. ENG. 2.2L DICR XENON THAILAND E4	TATA spare parts
99278900112R	ENGINE-2.2L DICOR E-5 FOR XENON AUS	TATA spare parts
99279900001R	ENGINE 486 CNG 2.1L EIII AC PS RHD	TATA spare parts
99279900001RCS	CUT SECTION FOR 486 CNG 2.1L ENG EIII	TATA spare parts
99279900001RYA	YELLOW AGGR FOR 486 CNG 2.1L ENG EIII	TATA spare parts
99279900002R	ENGINE 486 CNG,E3,PS,W/O A/C COMPBKT RHD	TATA spare parts
99279900003R	ASSY ENG CNG ETC PTC PS KD THAILAND RHD	TATA spare parts
99279900101R	ENGINE 486 CNG WT CLUTCH EIII PS AC RHD	TATA spare parts
99279900102R	XENON 486 CNG WT CL EIII PS AC W/O COMP	TATA spare parts
992806115960R	LP 1510/59 55% 697 BS-II -COWL ( MSRTC)	TATA spare parts
992806145960R	COWL LP 1510/59 697 BS-II 60% ROH FES	TATA spare parts
99280940002R	ASSY WHEEL RIM AND TYRE LPT 1518 SAF	TATA spare parts
99280946002R	SUB ASSY STRG GB WITH PIT ARM & UNIV JT	TATA spare parts
992821184960R	COWL LP 909 CNG BS IV MARCOPOLO	TATA spare parts
992821234960R	LP909 CNG BSIV/49WB OBDII - COWL PARTS	TATA spare parts
992821244960R	COWL LP909/49WB TMML CNGBS4 OBDII	TATA spare parts
992821463860R	COWL LPT 909 CNG BS-IV	TATA spare parts
992846306260R	COWL LPT 3118/62 TC BSIII	TATA spare parts
992846325260R	COWL LPT 3118 TC BSIII 52	TATA spare parts
992846325660R	COWL LPT 3118 TC BSIII	TATA spare parts
992846326260R	COWL LPT 3118/62 TC BSIII ERGO	TATA spare parts
992846405660R	COWL LPT3118TC BS3 56- PRT-STRAIGHT FRAM	TATA spare parts
992846525260R	COWL LPT 3118 TC BSIII 52- ERGO PARTS	TATA spare parts
992846525660R	LPT3118 56WB ERGO BSIII COWL-COWL PARTS	TATA spare parts
992846526060R	COWL LPT3118TC BS3 60-STRAIGHT FRAME	TATA spare parts
99285526101R	SYN CONE ASSLY + CLUTCH RELEASE BRG -RET	TATA spare parts
992881065260R	LP 1512/52 BS III WITH 497 TCIC-COWL PAR	TATA spare parts
992881074860R	LP 1112/48 BS III 497 TCIC-COWL PARTS	TATA spare parts
99289460101RD3	ARCTIC_SILVR-ASSY CAB COMPLETE XENON DC	TATA spare parts
9934904100	MACH SCREW-PAN HD	TATA spare parts
9934905300	SCREW-MACHINE PAN HD	TATA spare parts
9935035160	SCREW-FLANGE MACH;PAN HD	TATA spare parts
994101026131R1	FRONT FRAME LPO1628 HI DECK SAE 1 HSG	TATA spare parts
9941512630	STUD BOLT F TYPE	TATA spare parts
995030016031R	FRAME LPT2518TC BSIII COMPLETE	TATA spare parts
995030016260R	COWL LPT 2518/62 TC BS-III	TATA spare parts
995030025560R	COWL LPT 2518/55 TC BS-3ERGO NOSE UP	TATA spare parts
995030026060R	COWL LPT 2518TC BSIII 5955 6X2	TATA spare parts
995030026260R	LPT 2518/62 TC BS-III - COWL PARTS ERGO	TATA spare parts
995030056260R	Assy Cowl Complete LPT2518 62 WB	TATA spare parts
995030104860R	COWL LPT 2518/48TC BS-3	TATA spare parts
995030134860R	LPT 2518/48TC BS-3 - COWL PARTS- ERGO	TATA spare parts
995030154860R	COWL LPT 2518/48TC BS-3	TATA spare parts
995030254860R	COWL LPT 2518/48TC BS-3 - ERGO	TATA spare parts
9951212350	FLANGE BOLT M12X1.25	TATA spare parts
995515014960R	LP913/49WB CNG BS-IV FES TMML AC - COWL	TATA spare parts
995515024960R	COWL LP913/49WB CNG BS4 FES W/O AC	TATA spare parts

99552360001R	ASSY GLIDER ELECTRIC	TATA spare parts
995527293460R	ASSY.COWL COMPLETE-RHD WITH FITMENTS	TATA spare parts
995527333460R	ASSY.CAB COMPLETE-RHD	TATA spare parts
995533064760R	LP 9.6T FESLF CNG 650MM COWL PARTS	TATA spare parts
99581126103L	ASSY GEAR BOX G-76-5/4.1 XENON E-2 4X4 2	TATA spare parts
99581126104L	GEAR BOX G-76 SUIT FOR 260 DIA.CLUTCH	TATA spare parts
99581126105R	ASSY G B SUIT TO 260 DIA. CL -XENON EURO	TATA spare parts
99581126108R	GEAR BOX G76-5/4.1 XENON 4X4 2.2L 0.73	TATA spare parts
99581126109R	GEAR BOX G76-5/4.1 MK-II FOR XENON	TATA spare parts
9972084100	SCREW-TAP FLANGE:PAN HEAD	TATA spare parts
9972085160	TAPPING SCREW-P/HD FLANGE	TATA spare parts
99906	BEARING CONE-4021	TATA spare parts
9991104120	HEX NUT M12X1.25	TATA spare parts
9991104140	HEX NUT M14X1.5	TATA spare parts
9991104160	HEX NUT M16X1.5	TATA spare parts
9991104180	HEX NUT M18X1.5	TATA spare parts
9991104200	HEX NUT M20X1.5	TATA spare parts
9991105120	HEX NUT M12X1.25	TATA spare parts
9991105140	HEX NUT M14X1.5	TATA spare parts
9991105160	HEX NUT M16X1.5	TATA spare parts
9991105180	HEX NUT M18X1.5	TATA spare parts
9991114140	HEX NUT M14X1.5	TATA spare parts
9991114160	HEX NUT M16X1.5	TATA spare parts
9991114200	HEX NUT M20X1.5	TATA spare parts
9991115160	HEX NUT M16X1.5	TATA spare parts
9991152120	FLANGE NUT M12X1.25	TATA spare parts
999121042022	FRONT AXLE BRAKE LH	TATA spare parts
999121042051	BRAKE ASSY LH	TATA spare parts
999121042052	BRAKE ASSY RH	TATA spare parts
999121042053	BRAKE ASSY RR LH 1210DAOH	TATA spare parts
999131242024	BRAKE ASSY LH	TATA spare parts
999131242051	BRAKE ASSY 1312 FR LH	TATA spare parts
999131242052	ASY.FRONT AXLE BRAKE LH.	TATA spare parts
999131242053	ASSY RR AXLE BRAKE RH	TATA spare parts
999131242054	ASY.REAR AXLE BRAKE LH.	TATA spare parts
999161642013	A B ASSY 1616 FRONT REAR LH	TATA spare parts
999241660513	COWL COMP 2416 SCAM	TATA spare parts
999241660515	COWL BARE 2416 SCAM	TATA spare parts
999267460501	COWL COMP SFC 609	TATA spare parts
999267460502	COWL BARE SFC 609	TATA spare parts
99934013	QUILL ROLLER BEARING	TATA spare parts
9999999956	M.C. REPAIR KIT	TATA spare parts
9999999960	STRG. GEAR PUMP R.C	TATA spare parts
9999999962	M.C. REPAIR KIT	TATA spare parts
9999RAHT9724	REAR AXLE HSG W/TUBE	TATA spare parts
9999SDSW9007	SOLENOID SWITCH FIP	TATA spare parts
9999SMWD9916	SET LOCK SLIDING WIND FR	TATA spare parts

9999SUBR0010	O RING SAFARI	TATA spare parts
9999TV659009	REGULATOR 65A HYBRID	TATA spare parts
99CX004Z00	RETAINER PLATE A-FRAME	TATA spare parts
A-1205-T-2516	OIL SEAL	TATA spare parts
A-1205-X-2728	OIL SEAL	TATA spare parts
A-14496	STABILIZER (STEERING DAMPER)	TATA spare parts
A-3211-V-C074	SPIDER ASSY (WITH BUSHES & SEAL)	TATA spare parts
A-3222-S-C019	BRAKE SHOE	TATA spare parts
A-3261-C-289	CHAMBER ASSY AIR SHIFT	TATA spare parts
A-3299-N-C118	BRACKET ASSY- CAM SHAFT- LH	TATA spare parts
A-3299-P-C120	BRACKET ASSY- CAM SHAFT- RH	TATA spare parts
A09600000001	RH RVM ARM ASSY WITH BRACKET	TATA spare parts
A09600000002	REAR BUMPER ASSY COMPL(W/O DICKEY+NEW T	TATA spare parts
A09600000003	LH RVM ARM ASSY WITH BRACKET	TATA spare parts
A09600000004	FRP DASH BOARD FOR STARBUS(RHD)	TATA spare parts
A09600000005	WEATHER STRIP(PAS.DR-BIG BULB)	TATA spare parts
A09600000006	HINGE ASSY RHD EMG. DOOR	TATA spare parts
A09600000007	LOCK COMPL (SPRING LOCK)	TATA spare parts
A09600000008	BEARING	TATA spare parts
A09600000009	VENTILATOR ASSY COMPLETE	TATA spare parts
A09600000010	ARM COMPL.	TATA spare parts
A09600000011	GLASS TINTED (704X722X5 THK)-PARTITION	TATA spare parts
A09600000012	PARTITION GLASS ASSEMBLY	TATA spare parts
A09600000013	GLASS (265X2080X4 THK)-REAR DOOR	TATA spare parts
A09600000014	SD.WIN.ASSY.	TATA spare parts
A09600000015	SD.WIN.ASSY.	TATA spare parts
A09600000016	SD.WIN.ASSY.	TATA spare parts
A09600000017	SD.WIN.ASSY.	TATA spare parts
A09600000018	DRIVER DOOR WINDOW ASSY.	TATA spare parts
A09600000019	HINGE ASSY	TATA spare parts
A09600000020	PASSENGER DOOR ASSY-FRONT	TATA spare parts
A09600000021	ENTRANCE DOOR ASSY-REAR	TATA spare parts
A09600000022	BEARING CASE/LOWER	TATA spare parts
A09600000023	PIPE BRACKET ASSY(POWDER COATED)	TATA spare parts
A09600000024	PIPE BRACKET ASSY (POWDER COATED)	TATA spare parts
A09600000025	EMERGENCY LOCK ASSY	TATA spare parts
A09600000026	HINGE ASSY. FOR DRIVER DOOR.	TATA spare parts
A09600000027	REVOLVING LAMP	TATA spare parts
A09600000028	609 REAR VIEW MIRROR	TATA spare parts
A09600000029	GLASS REAR/LH (TUF)(609)	TATA spare parts
A09600000030	GLASS REAR/RH (TUF)(609)	TATA spare parts
A09600000031	ENTRANCE DOOR ASSY	TATA spare parts
A09600000032	SIDE WINDOW ASSY.	TATA spare parts
A09600000033	SIDE WINDOW ASSY.	TATA spare parts
A09600000034	SIDE WINDOW ASSY.	TATA spare parts
A09600000035	TWIN SEATER (PLASTIC MOULDED)	TATA spare parts
A09600000036	SINGLE SEATER (PLASTIC MOULDED)	TATA spare parts

A09600000037	HOOK COMPL	TATA spare parts
A09600000038	HINGE ASSY (REAR BAGGAGE)	TATA spare parts
A09600000039	GLASS TINTED (265X1613X5 THK)(P.DOOR)	TATA spare parts
A09600000040	GLASS TINTED (522X722X5 THK)(PARTITION)	TATA spare parts
A09600000041	REVERSE HORN (12V)	TATA spare parts
A09600000042	ACRYLIC MINI LAMP (ROUND)	TATA spare parts
A09600000043	WEAT.STRIP(PASS.DOOR.BIG BULB)	TATA spare parts
A09600000044	WEAT.STRIP(PASS.DR-MDL.SMALL D	TATA spare parts
A09600000045	WEAT.STRIP(PASS.DR-FLAP/SHAFT)	TATA spare parts
A09600000046	WEAT.STRIP(PASS.DOOR GLASS)	TATA spare parts
A09600000047	WEATH.STRIP(PASS.DR-GLASS KEY)	TATA spare parts
A09600000048	REAR WINDSHIELD GLASS CENTER	TATA spare parts
A09600000049	REAR BUMPER FRP	TATA spare parts
A09600000050	HINGE ASSY FOR DRIVER¿S DOOR	TATA spare parts
A09600000051	SUNVISOR ASSY.	TATA spare parts
A09600000052	WIPER ARM (370X210 RHD)	TATA spare parts
A09600000053	WIPER ARM (370X295 RHD)	TATA spare parts
A09600000054	DR. DOOR WINDOW ASSY ( 737 / 1015 X 71	TATA spare parts
A09600000055	DRIVER DOOR ASSY.	TATA spare parts
A09600000056	SIDE WINDOW ASSY ( 1464 X 965 )	TATA spare parts
A09600000057	FRP DASH BOARD 6HD WD BODY - RHD	TATA spare parts
A09600000058	SIDE WINDOW ASSY. ( 2PC-CUR-TAP )	TATA spare parts
A09600000059	REPAIR KIT FOR CYLINDER	TATA spare parts
A09600000060	CARBON BRUSH FOR FAN	TATA spare parts
A09600000061	FRONT GRILL (LPO1610FE )	TATA spare parts
A09600000062	FRONT FLAP (LPO1610FE )	TATA spare parts
A09600000063	WIPER ARM ASSY/ RH (WIPE)	TATA spare parts
A09600000064	WIN ASSY CTB/CLR/TOP FIX/PC	TATA spare parts
A09600000065	FRP REAR BUMP COMP-6HD W/O DIC	TATA spare parts
A09600000066	CURVED TAIL LAMP(6HD)(WHITE)	TATA spare parts
A09600000067	GLASS LIGHT GREEN TINT(301X1610X5)	TATA spare parts
A09600000068	SIDE WINDOW ASSY ( 429 X 965 )	TATA spare parts
A09600000069	GAS STAY (SKIRT PANEL)	TATA spare parts
A09600000070	GLASS LIGHT GREEN TINT(301X1610X5)	TATA spare parts
A09600000071	SIDE WINDOW ASSY ( 1379 X 965 )	TATA spare parts
A09600000072	FR WS/6HD2260X1240X7/LM.GR.BAND	TATA spare parts
A09600000073	REAR W/S CTR GLASS (6HD-3PC-TUF)	TATA spare parts
A09600000074	BRACKET	TATA spare parts
A09600000075	PIPE¿ BRACKET.	TATA spare parts
A09600000076	PASSENGER SIDE RVM(LHD-STARBUS)	TATA spare parts
A09600000077	FRP FRONT GRILL (MODIFIED)	TATA spare parts
A09600000078	HIGH MOUNT STOP LAMP WITH LED INDICATOR	TATA spare parts
A09600000079	GLASS TINTED (265X1925X5 THK)	TATA spare parts
A09600000080	PASSENGER DOOR ASSY	TATA spare parts
A09600000081	PASSENGER DOOR ASSY	TATA spare parts
A09600000082	GLASS TINTED (276X1930X5 THK)	TATA spare parts
A09600000083	GLASS TINTED (296X1930X5 THK)	TATA spare parts

A09600000084	DASHBOARD COMPLETE	TATA spare parts
A09600000085	FRP AIR CLEANER PANEL COMPLETE	TATA spare parts
A09600000086	SD WINDOW ASSY(3PC/EMG/GREEN/PC)	TATA spare parts
A09600000087	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
A09600000088	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
A09600000089	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
A09600000090	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
A09600000091	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
A09600000092	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
A09600000093	SD WINDOW ASSY(CTB/2PC/DRV.DOOR/PC)	TATA spare parts
A09600000094	SD WINDOW ASSY(CTB/3PC/GRN/STAR/PC)	TATA spare parts
A09600000095	GLASS TINTED (572X722X5 THK)	TATA spare parts
A09600000096	PARTITION GLASS ASSY.	TATA spare parts
A09600000097	TAIL LAMP ROUND (RED) LAPL	TATA spare parts
A09600000098	TAIL LAMP ROUND (WHITE)	TATA spare parts
A09600000099	TAIL LAMP ROUND (AMBER)	TATA spare parts
A09600000100	FRP REAR BUMPER COMPLETE ( MOD )	TATA spare parts
A09600000101	FRP REAR STRUCTURE ( MOD- WITH ROUND TAL	TATA spare parts
A09600000102	P.DOOR HINGE (R.E.)	TATA spare parts
A09600000103	DOOR E/G BRACKET	TATA spare parts
A09600000104	BEARING CASE/LOWER	TATA spare parts
A09600000105	PIPE BRACKET ASSY(MS PIPE-32DIA)	TATA spare parts
A09600000106	MIRROR ARM COMPL-DRV'S SD/RH	TATA spare parts
A09600000107	MOULDING END FOR OPTYPE OUTER(LH)	TATA spare parts
A09600000108	MOULDING END FOR OPTYPE OUTER(RH)	TATA spare parts
A09600000109	RVM ARM ASSY(6HD-RHD-CO-DRV	TATA spare parts
A09600000110	PASS.FAN/24V (GREY RING TYPE)	TATA spare parts
A09600000111	FRP STEERING COVER FOR 6HD	TATA spare parts
A09600000112	ENGINE HOOD BEADING FOR 6HD ( 6 MTR)	TATA spare parts
A09600000113	FLAP LOCK ASSY STRAIGHT FORK	TATA spare parts
A09600000114	WIPER ASSY (2.6HD)/RHD/SYNDICATE	TATA spare parts
A09600000115	FRP PANEL REAR WITH REAR DICKEY	TATA spare parts
A09600000116	REAR W/S LH GLASS(6HD-3PC-TUF)	TATA spare parts
A09600000117	REAR W/S RH GLASS(6HD-3PC-TUF)	TATA spare parts
A09600000118	PASS DOOR GLASS (281X1610X4 THK)	TATA spare parts
A09600000119	SD WIN ASSY(TOPFIX BOTTM SLD/GRN)	TATA spare parts
A09600000120	SD WIN ASSY(TOP FIX BOTT SLD/GRN)	TATA spare parts
A09600000121	SD.WIN.ASSY(CTB/TOPFIX/GREEN)	TATA spare parts
A09600000122	DRIV.DOOR WINDOW (2PC/CTB/GREEN)	TATA spare parts
A09600000123	WEAT.STRIP(PASS.DR-MDL-SMALL)	TATA spare parts
A09600000124	WEAT.STRIP(PASS.DR-FLAP/SHAFT)	TATA spare parts
A09600000125	6HD REAR DICKY LOCK	TATA spare parts
A09600000126	ALTERNATOR 140 AMPS. 24 VOLT	TATA spare parts
A09600000127	WIPER ARM (370X210 RHD)+SPRAY	TATA spare parts
A09600000128	BLACK EPDM WASHER MOTOR TUBE	TATA spare parts
A09600000129	WIPER ARM (370X295RHD)+SPRAY	TATA spare parts
A09600000130	6HD FRONT STRUC COMPL(REDA+RHD)	TATA spare parts

A09600000131	PASSENGER DOOR ASSY.	TATA spare parts
A09600000132	PARTITION GLASS ASSY.	TATA spare parts
A09600000133	RUBBER BEADING WITH KEY (LENGTH 10 MTR)	TATA spare parts
A09600000134	WEATHER STRIP(ENTR.DOOR GLASS)	TATA spare parts
A09600000135	DOOR BRUSH FOR 909 BUS	TATA spare parts
A09600000136	GLASS CLEAR(265X1193X4)	TATA spare parts
A09600000137	GLASS CLEAR(397X722X4)	TATA spare parts
A09600000138	BUDGET LOCK FOR SKIRT PANEL	TATA spare parts
A09600000139	SHAFT COMPLETE	TATA spare parts
A09600000140	MAGAZINE POUCH IN ABS (RHD)	TATA spare parts
A09600000141	SUNVISOR (SUN & SHADE)	TATA spare parts
A09600000142	HEIGHT MARKER LAMP(RED)AMBULANCE	TATA spare parts
A09600000143	HEIGHT MARKER LAMP(WHITE)AMBULANCE	TATA spare parts
A09600000144	FRP REAR STRUCTURE COMPLETE - STARBUS 40	TATA spare parts
A09600000145	PASSENGER DOOR COMPLETE	TATA spare parts
A09600000146	PEEP GLASS FOR 909-CLEAR-(310X385X4)	TATA spare parts
A09600000147	REAR WINDSHEILD AUTO WINDOW	TATA spare parts
A09600000148	SIDE WINDOW ASSY(2PC-CUR-CLEAR)	TATA spare parts
A09600000149	SIDE WINDOW ASSY(2PC-CUR-CLEAR)	TATA spare parts
A09600000150	SIDE WINDOW ASSY(2PC-CUR-CLEAR)	TATA spare parts
A09600000151	SIDE WINDOW ASSY(2PC-CUR-CLEAR)	TATA spare parts
A09600000152	SIDE WINDOW ASSY(2PC-CUR-CLEAR)	TATA spare parts
A09600000153	SIDE WINDOW ASSY(FIX-CUR-CLR-FLOCK)	TATA spare parts
A09600000154	MIRROR ARM CO DRV (909)	TATA spare parts
A09600000155	FRP REAR BUMPER COMPLETE	TATA spare parts
A09600000156	FRP REAR BUMPER COMPLETE	TATA spare parts
A09600000157	DRV DOOR INNER PANEL FOR RHD(PVC WITH FO	TATA spare parts
A09600000158	DRIVER'S PARTITION ASSEMBLY	TATA spare parts
A09600000159	FRP HINGE COVER (709 UPGRADE)	TATA spare parts
A09600000160	ROOF LAMP FOR 909	TATA spare parts
A09600000161	HAND STRAP ASSY (GREY COLOUR)	TATA spare parts
A09600000162	FRP REAR STRUCTURE COMPLETE-909 SKOOL	TATA spare parts
A09600000163	FRP REAR BUMPER COMPLETE	TATA spare parts
A09600000164	CONNECTING ROD	TATA spare parts
A09600000165	CONNECTING ROD	TATA spare parts
A09600000166	ROOF LIGHT LED TYPE ROUND	TATA spare parts
A09600000167	ROOF LIGHT LED¿ ROUND TAPER	TATA spare parts
A09600000168	DASH BOARD ASSY.	TATA spare parts
A09600000169	AIR CLEANER PANEL COMPLETE	TATA spare parts
A09600000170	FRONT STEP ASSY.	TATA spare parts
A09600000171	SIDE WINDOW ASSY( 1463X 967 )	TATA spare parts
A09600000172	SIDE WINDOW ASSY ( 1273 X 967 )	TATA spare parts
A09600000173	SIKAFLEX 252 WHITE	TATA spare parts
A09600000174	PASSENGER DOOR ASSY.	TATA spare parts
A09600000175	DRIVER¿ DOOR ASSY	TATA spare parts
A09600000176	DRIVER¿ DOOR ASSY	TATA spare parts
A09600000177	DOOR HANDLE FOR BUS	TATA spare parts

A09600000178	GLASS (1015X932X5 THK)	TATA spare parts
A09600000179	FRP REAR BUMPER FOR LCV BUSES	TATA spare parts
A09600000180	SD WINDOW ASSY(OPTYPE-2PC-CLEAR)	TATA spare parts
A09600000181	SD WINDOW ASSY(OPTYPE-2PC-CLEAR)	TATA spare parts
A09600000182	SD WINDOW ASSY(OPTYPE-2PC-TAP-CLR)	TATA spare parts
A09600000183	GLASS (265X1598X5 THK)	TATA spare parts
A09600000184	PARTITION GLASS ASSY(PCOAT)	TATA spare parts
A09600000185	ENTRANCE DOOR ASSY	TATA spare parts
A09600000186	FRONT WINDSHIELD BS2/3/4	TATA spare parts
A09600000187	WEAT.STRIP(PASS.DR-MDL-SMALL D)	TATA spare parts
A09600000188	WEAT.STRIP(PASS.DR-FLAP/SHAFT)	TATA spare parts
A09600000189	GLASS CLEAR(301X1610X4)	TATA spare parts
A09600000190	GLASS LIGHT GREEN TINT(301X1610X4)	TATA spare parts
A09600000191	GLASS LIGHT GREEN TINT(1087X441X5)	TATA spare parts
A09600000192	GLASS CLEAR(301X1610X5)	TATA spare parts
A09600000193	GLASS CLEAR(265X1795X5)	TATA spare parts
A09600000194	GLASS LIGHT GREEN TINT(265X1795X5)	TATA spare parts
A09600000195	GLASS LIGHT GREEN TINT(265X1945X5)	TATA spare parts
A09600000196	GLASS DARK GREY TINT(572X722X5)	TATA spare parts
A09600000197	REAR WINDSHIELD (TEMP-6HD-SIN.PC)	TATA spare parts
A09600000198	GLASS CLEAR(281X1610X4)	TATA spare parts
A09600000199	GLASS LIGHT GREEN TINT(281X1610X4)	TATA spare parts
A09600000200	GLASS CLEAR(281X1610X5)	TATA spare parts
A09600000201	PARTITION LOCK (RH)	TATA spare parts
A09600000202	AL.EXTRUSION(ANNODISED/OP TYPE)	TATA spare parts
A09600000203	WEAT.STRIP(PASS.DOOR-BIG BULB)	TATA spare parts
A09600000204	COMPLETE ASSY 2 SEATER ( 800 MM LN. )	TATA spare parts
A09600000205	COMPLETE ASSY 3 SEATER ( 1200 MM LN. )	TATA spare parts
A09600000206	ENTRANCE DOOR ASSY	TATA spare parts
A09600000207	ENTRANCE DOOR ASSY	TATA spare parts
A09600000208	ENTRANCE DOOR ASSY	TATA spare parts
A09600000209	ENTRANCE DOOR ASSY	TATA spare parts
A09600000210	PASSENGER DOOR ASSY.	TATA spare parts
A09600000211	PASSENGER DOOR ASSY COMPLETE	TATA spare parts
A09600000212	PASSENGER DOOR ASSY COMPLETE	TATA spare parts
A09600000213	PASSENGER DOOR ASSY COMPLETE	TATA spare parts
A09600000214	MAGAZINE POUCH IN ABS (LHD)	TATA spare parts
A09600000215	SIDE WINDOW ASSY ( 818 X 967 )	TATA spare parts
A09600000216	SIDE WINDOW ASSY ( 1268 X 967 )	TATA spare parts
A09600000217	SIDE WINDOW ASSY( 1373 X 967 )	TATA spare parts
A09600000218	SIDE WINDOW ASSY ( 1492 X 967 )	TATA spare parts
A09600000219	SIDE WINDOW ASSY ( 613 X 967 )	TATA spare parts
A09600000220	SIDE WINDOW ASSY ( 1313 X 967 )	TATA spare parts
A09600000221	SIDE WINDOW ASSY( 1458 X 967 )	TATA spare parts
A09600000222	SIDE WINDOW ASSY( 1348X 967 )	TATA spare parts
A09600000223	SIDE WINDOW ASSY ( 1348 X 967 )	TATA spare parts
A09600000224	SIDE WINDOW ASSY ( 1463 X 967 )	TATA spare parts



A09600000225	SIDE WINDOW ASSY( 1503X 967 )	TATA spare parts
A09600000226	SIDE WINDOW ASSY ( 1503 X 967 )	TATA spare parts
A09600000227	SIDE WINDOW ASSY ( 613 X 967 )	TATA spare parts
A09600000228	SIDE WINDOW ASSY ( 613X 967 )	TATA spare parts
A09600000229	SIDE WINDOW ASSY ( 1068 X 967 )	TATA spare parts
A09600000230	SIDE WINDOW ASSY ( 1068 X 967 )	TATA spare parts
A09600000231	SIDE WINDOW ASSY( 1273X 967 )	TATA spare parts
A09600000232	SIDE WINDOW ASSY( 1463X 967 )	TATA spare parts
A09600000233	SIDE WINDOW ASSY ( 1463 X 967 )	TATA spare parts
A09600000234	SIDE WINDOW ASSY EMG ( 609 X 896 )	TATA spare parts
A09600000235	SIDE WINDOW ASSY EMG ( 609 X 898 )	TATA spare parts
A09600000236	DR. DOOR WINDOW ASSY ( 737 /1018 X 712 )	TATA spare parts
A09600000237	SIDE WINDOW ASSY EMG ( 609 X 898 )	TATA spare parts
A09600000238	SIDE WINDOW ASSY EMG ( 609 X 898 )	TATA spare parts
A09600000239	DRIVER DOOR WINDOW ASSY. ( 737 /1018X710	TATA spare parts
A09600000240	DRIVER DOOR WINDOW ASSY. ( 737 /1018X710	TATA spare parts
A09600000241	SIDE WINDOW ASSY ( 1379 X 965 )	TATA spare parts
A09600000242	SIDE WINDOW ASSY ( 1464 X 965 )	TATA spare parts
A09600000243	SIDE WINDOW ASSY ( 639 X 965 )	TATA spare parts
A09600000244	SIDE WINDOW ASSY ( 1079 X 965 )	TATA spare parts
A09600000245	SIDE WINDOW ASSY ( 1379 X 965 )	TATA spare parts
A09600000246	SIDE WINDOW ASSY ( 639 X 965 )	TATA spare parts
A09600000247	SIDE WINDOW ASSY ( 1464 X 965 )	TATA spare parts
A09600000248	SIDE WINDOW ASSY ( 638 X 965 )	TATA spare parts
A09600000249	SIDE WINDOW ASSY ( 899 X 965 )	TATA spare parts
A09600000250	SIDE WINDOW ASSY ( 1079 X 965 )	TATA spare parts
A09600000251	SIDE WINDOW ASSY ( 1279 X 965 )	TATA spare parts
A09600000252	WINDOW ASSY - EMG ( 609 X 903 )	TATA spare parts
A09600000253	WINDOW ASSY - EMG ( 609 X 903 )	TATA spare parts
A09600000254	SIDE WINDOW ASSY EMG ( 609 X 903 )	TATA spare parts
A09600000255	SIDE WINDOW ASSY ( 1279 X 965 )	TATA spare parts
A09600000256	SIDE WINDOW ASSY ( 1379 X 965 )	TATA spare parts
A09600000257	SIDE WINDOW ASSY ( 639 X 965 )	TATA spare parts
A09600000258	SIDE WINDOW ASSY ( 1079 X 965 )	TATA spare parts
A09600000259	SIDE WINDOW ASSY ( 1379 X 965 )	TATA spare parts
A09600000260	SIDE WINDOW ASSY. (1279 X 965 )	TATA spare parts
A09600000261	SIDE WINDOW ASSY ( 1379 X 965 )	TATA spare parts
A09600000262	SIDE WINDOW ASSY ( 1464 X 965 )	TATA spare parts
A09600000263	SIDE WINDOW ASSY ( 1279 X 965 )	TATA spare parts
A09600000264	SIDE WINDOW ASSY ( 1464 X 965 )	TATA spare parts
A09600000265	WINDOW ASSY - EMG ( 609 X 903 )	TATA spare parts
A09600000266	A/ C ENGINE SKIRT PANEL	TATA spare parts
A09600000267	SIDE WINDOW ASSY ( 419 X 965 )	TATA spare parts
A09600000268	SIDE WINDOW ASSY ( 529 X 965 )	TATA spare parts
A09600000269	DRIVERS PARTITION WINDOW	TATA spare parts
A09600000270	PARTITION ACRYLIC ASSY	TATA spare parts
A09600000271	PARTITION ACRYLIC(572X722X5)GREEN TINT	TATA spare parts

A09600000272	REAR BUMPER COMPLETE	TATA spare parts
A09600000273	FRP DASHBOARD COMPL(6HD-LHD-ABS)	TATA spare parts
A09600000274	SIDE MARKER LAMP(2PT HOLDER)	TATA spare parts
A09600000275	DR. DOOR WINDOW ASSY ( 750/1043 X 712 )	TATA spare parts
A09600000276	DR. DOOR WINDOW ASSY ( 737 /1015 X 712 )	TATA spare parts
A09600000277	DR.DOOR WINDOW ASSY ( 750 / 1043 X 712	TATA spare parts
A09600000278	DR.DOOR. WINDOW ASSY ( 750/1043 X 712 )	TATA spare parts
A09600000279	NYLON GUARD RAIL BKT(GREY/25DIA)	TATA spare parts
A09600000280	ROOF HATCH (HISPANO)	TATA spare parts
A09600000281	A / C ENGINE DOOR ASSY.	TATA spare parts
A09600000282	WINDOW LOCK	TATA spare parts
A09600000283	WINDOW REAR L.H.	TATA spare parts
A09600000284	AUTOMATIC BATTERY CUT OFF RELAY	TATA spare parts
A09600000285	SIDE WINDOW ASSY. RH	TATA spare parts
A09600000286	SIDE WINDOW GLASS	TATA spare parts
A09600000287	DECAL COMPLETE SET FOR 909/49 MODEL	TATA spare parts
A09600000288	DRV.DOOR WINDOW (CTB-GREEN-2PC)	TATA spare parts
A09600000289	SD WIN ASSY( TOP/BOTT FIX/EMG/GRN)	TATA spare parts
A09600000290	WINDOW GLASS	TATA spare parts
A09600000291	WINDOW GLASS	TATA spare parts
A09600000292	WINDOW GLASS	TATA spare parts
A09600000293	CO-DRIVER SIDE GLASS	TATA spare parts
A09600000294	GAS SPRING/SHOCK ABSORBER-DRIVER SEAT	TATA spare parts
A09600000295	DRIVER DOOR ASSY LPO916 LHD	TATA spare parts
A09600000296	FRONT W/S 1210/LH	TATA spare parts
A09600000297	FRONT W/S 1210/RH	TATA spare parts
A09600000298	GLASS REAR/LH(TUF)(5E MODEL)	TATA spare parts
A09600000299	GLASS REAR/RH(TUF)(5E MODEL)	TATA spare parts
A09600000300	SIDE WINDOW FRONT GLASS ( 3RD WINDOW LH	TATA spare parts
A09600000301	DRIVER DOOR WINDOW ASSY (MASSATS)	TATA spare parts
A09600000302	WEATHER STRIP(WINDSHILD FRONT)	TATA spare parts
A09600000303	GLASS CLEAR(299X1498X4 THK)	TATA spare parts
A09600000304	GLASS CLEAR(777X859X5)	TATA spare parts
A09600000305	GLASS LIGHT GREEN TINT(397X722X5)	TATA spare parts
A09600000306	CUR RAIL BRKT(NYL-19DIA-BLACK)	TATA spare parts
A09600000307	PASSENGER DOOR ASSY	TATA spare parts
A09600000308	RECLINING LEVER /LH	TATA spare parts
A09600000309	RECLINING LEVER/RH	TATA spare parts
A09600000310	QUARTER GLASS - MSRTC 709 BUS	TATA spare parts
A09600000311	PEEP GLASS FOR MSRTC 709 BUS	TATA spare parts
A09600000312	SD WINDOW ASSY. ( 1134 X 817 )	TATA spare parts
A09600000313	SD WINDOW ASSY.( 1159 X 817 )	TATA spare parts
A09600000314	SD WINDOW ASSY.(1043 X 1327 X 817 )	TATA spare parts
A09600000315	DRIVER¿ WINDOW ASSY.( 619 X 736 )	TATA spare parts
A09600000316	REAR BUMPER ASSY - LH	TATA spare parts
A09600000317	REAR BUMPER ASSY - RH	TATA spare parts
A09600000318	SKIRT PANEL COMP.	TATA spare parts

A09600000319	DOOR ASSY CU	TATA spare parts
A09600000320	SKIRT PANEL COMP.	TATA spare parts
A09600000321	GLASS REAR CENTRE ( TUF ) 5E MODEL	TATA spare parts
A09600000322	LAMP BEZEL L. H.	TATA spare parts
A09600000323	LAMP BEZEL R. H	TATA spare parts
A09600000324	INSPECTION LID ( RADIATOR )	TATA spare parts
A09600000325	GLASS CLEAR ( 265 X1815 X 4 )	TATA spare parts
A09600000326	WHEEL SIDE COVER ASSY	TATA spare parts
A09600000327	RUBBER MOULD FOR FRONT W/S	TATA spare parts
A09600000328	REAR W/S TOUGHNED GLASS	TATA spare parts
A09600000329	RUBBER MOULD FOR REAR W/S BS2/3/3	TATA spare parts
A09600000330	FRP FRONT BUMPER FOR COMFORT MODEL BS2/	TATA spare parts
A09600000331	FRP REAR BUMPER	TATA spare parts
A09600000332	GLASS LIGHT GREEN TINT(265X1815X5)	TATA spare parts
A09600000333	FRP FRONT PANEL FOR COMFORT MODEL	TATA spare parts
A09600000334	FRP FRONT FLAP FOR COMFORT MODEL	TATA spare parts
A09600000335	FRP FRONT GRILL FOR COMFORT MODEL	TATA spare parts
A09600000336	FRP FRONT FIN FOR COMFORT MODEL	TATA spare parts
A09600000337	FRP PODEST FOR ENGINE HOOD-AIR CLEANER	TATA spare parts
A09600000338	FRP ENGINE HOOD FOR LP BUS	TATA spare parts
A09600000339	REAR FRP FOR COMFORT MODEL	TATA spare parts
A09600000340	HINGE ASSEMBLY	TATA spare parts
A09600000341	PASSENGER DOOR ASSEMBLY	TATA spare parts
A09600000342	QUARTER GLASS-COMFORT BUS-CLEAR-5MM	TATA spare parts
A09600000343	SD WIDNOW ASSY(OPTYPE-2PC-GREEN)	TATA spare parts
A09600000344	SD WIDNOW ASSY(OPTYPE-2PC-GREEN)	TATA spare parts
A09600000345	SD WINDOW ASSY(OPTYPE-2PC-GREEN)	TATA spare parts
A09600000346	SD WINDOW ASSY(OPTYPE-2PC-GREEN)	TATA spare parts
A09600000347	PARTITION GLASS ASSY	TATA spare parts
A09600000348	REAR VIEW MIRROR TWIN	TATA spare parts
A09600000349	BLINKER LAMP FOR COMFORT BUS	TATA spare parts
A09600000350	WIPER ASSY/SYNDICATE(2.6HD)/LHD	TATA spare parts
A09600000351	WIPER BLADE FOR COMFORT	TATA spare parts
A09600000352	WIPER ARM DR SIDE COMFORT	TATA spare parts
A09600000353	WIPER ARM PASS SD COMFORT	TATA spare parts
A09600000354	FRP DASHBOARD COMPLETE FOR COMFORT(LP)	TATA spare parts
A09600000355	SD WINDOW ASSY(OPTYPE-2PC-GREEN)	TATA spare parts
A09600000356	PRINTED CURV GLASS GREEN 50 TINT	TATA spare parts
A09600000357	GLASS LIGHT GREEN TINT (1458X55)	TATA spare parts
A09600000358	NUMBER PLATE LAMP	TATA spare parts
A09600000359	DOVE TAIL GUIDE	TATA spare parts
A09600000360	AL EXTRUSION/NONSKID(L SECTION) 4 MTR	TATA spare parts
A09600000361	AL-EXTRUSION (SEAT RAIL) (LENGTH 4000MM)	TATA spare parts
A09600000362	AL-EXTRUSION (STEP FLOORING) 4 MTR	TATA spare parts
A09600000363	AL EXTRUSION (GUTTER) (LENGTH 4000MM)	TATA spare parts
A09600000364	AL-EXTRUSION(FLAT WITH CURVED EDGE)	TATA spare parts
A09600000365	PIPE BRACKET (32 DIA)(PC)	TATA spare parts

A09600000366	PIPE BKT. (38 DIA)	TATA spare parts
A09600000367	PIPE BRACKET (38X32)(PC)	TATA spare parts
A09600000368	PIPE BRACKET/T (38X25)(PC)	TATA spare parts
A09600000369	PIPE BRACKET (32X32)(PC)	TATA spare parts
A09600000370	PIPE JOINT T (32X 25)(PC)	TATA spare parts
A09600000371	PIPEBKT (30X30 SQ TUBE)	TATA spare parts
A09600000372	STEP CORNER - AL. CASTING (MODIFIED)	TATA spare parts
A09600000373	GLASS-CLEAR (180X1520X5 THK)	TATA spare parts
A09600000374	GLASS-CLEAR (321X1520X5 THK)	TATA spare parts
A09600000375	FRONT FRP PANEL ASSY(COMFORT-JNNURM)	TATA spare parts
A09600000376	HINGE COMPL (FRONT FLAP)-RH	TATA spare parts
A09600000377	HINGE COMPL (FRONT FLAP)-LH	TATA spare parts
A09600000378	FRONT FRP FLAP(COMFORT-JNNURM)	TATA spare parts
A09600000379	FRONT FRP FIN(COMFORT-JNNURM)	TATA spare parts
A09600000380	FRP ENGINE HOOD FOR JNNURM BUS	TATA spare parts
A09600000381	BELLOW FOR ENG.HOOD	TATA spare parts
A09600000382	BELLOW FRAME	TATA spare parts
A09600000383	FRP REAR COMPLETE (COMFORT-JNNURM)	TATA spare parts
A09600000384	PLASTIC FOOT STEP COVER	TATA spare parts
A09600000385	SS PIANO HINGE	TATA spare parts
A09600000386	PASSENGER DOOR ASSEMBLY	TATA spare parts
A09600000387	PASSENGER DOOR ASSEMBLY	TATA spare parts
A09600000388	PASSENGER DOOR ASSEMBLY	TATA spare parts
A09600000389	TOWER BOLT(ALLUMINIUM)-10INCH	TATA spare parts
A09600000391	BEAM	TATA spare parts
A09600000392	BEAM	TATA spare parts
A09600000393	BEAM	TATA spare parts
A09600000394	DRIVER DOOR ASSEMBLY	TATA spare parts
A09600000395	LATCH FOR DRIVER'S DOOR	TATA spare parts
A09600000396	RECTANGULAR SIDE WINDOW GLASS	TATA spare parts
A09600000397	RECTANGULAR SIDE WINDOW GLASS	TATA spare parts
A09600000398	RECTANGULAR SIDE WINDOW GLASS	TATA spare parts
A09600000399	PASSENGER DOOR TOP WINDOW GLASS	TATA spare parts
A09600000400	PASSENGER DOOR TOP GLASS	TATA spare parts
A09600000401	DRIVER DOOR TOP WINDOW GLASS	TATA spare parts
A09600000402	WINDOW ASSY (RH SIDE)	TATA spare parts
A09600000403	WINDOW ASSY(RH SIDE)	TATA spare parts
A09600000404	WINDOW ASSY(RH SIDE)	TATA spare parts
A09600000405	SIDE WINDOW ASSY	TATA spare parts
A09600000406	SIDE WINDOW ASSY	TATA spare parts
A09600000407	WINDOW ASSY-DRIVER DOOR	TATA spare parts
A09600000408	HOOPER TYPE WINDOW	TATA spare parts
A09600000409	FRONT W/S GLASS LAMINATED(2.6MT)	TATA spare parts
A09600000410	REAR WINDSHIELD FOR COMFORT (JNNURM)	TATA spare parts
A09600000411	REAR GARNISH FOR APSRTC (RH)	TATA spare parts
A09600000412	REAR GARNISH FOR APSRTC (LH)	TATA spare parts
A09600000413	HAND STRAP TRIANGULAR-YELLOW	TATA spare parts

A09600000414	MIRROR ARM COMPL-DRV SIDE	TATA spare parts
A09600000415	RVM ARM BRACKET	TATA spare parts
A09600000416	RVM ARM BRACKET	TATA spare parts
A09600000417	ARM COMPLETE	TATA spare parts
A09600000418	JNNURM LOGO IN BLUE COLOUR	TATA spare parts
A09600000419	APSRTC MONOGRAM	TATA spare parts
A09600000420	FRP FRONT BUMPER COMPL-JNNURM	TATA spare parts
A09600000421	FRP REAR BUMPER COMPLETE -JNNURM	TATA spare parts
A09600000422	HEAD LAMP SET RHD RH	TATA spare parts
A09600000423	HEAD LAMP SET RHD LH	TATA spare parts
A09600000424	DESTINATION INDI. KIT	TATA spare parts
A09600000425	FRP DASHBOARD COMPLETE (JNNURM)	TATA spare parts
A09600000426	REFLECTOR (WHITE)	TATA spare parts
A09600000427	REFLECTOR (RED)	TATA spare parts
A09600000428	SIDE MARKER LED	TATA spare parts
A09600000429	CABIN LAMP ROUND	TATA spare parts
A09600000430	ROOF LAMP (SALOON LED LIGHT TYPE 48)	TATA spare parts
A09600000431	EMG. SWITCH COVER	TATA spare parts
A09600000432	W/S GLASS 609 LAM	TATA spare parts
A09600000433	GLASS CLEAR(677X552X5)	TATA spare parts
A09600000434	QUARTER GLASS FOR AMBULANCE	TATA spare parts
A09600000435	QUARTER GLASS FOR AMBULANCE	TATA spare parts
A09600000436	HINGE FOR DRIVER'S DOOR(AMBULANCE)	TATA spare parts
A09600000437	HINGE FOR REAR DOOR	TATA spare parts
A09600000438	SD WINDOW ASSY(OPTYPE-2PC-CLEAR-PC)	TATA spare parts
A09600000439	SD WINDOW ASSY(OPTYPE-2PC-CLEAR-PC)	TATA spare parts
A09600000440	SD WINDOW ASSY(OPTYPE-2PC-CLEAR-PC)	TATA spare parts
A09600000441	SD WINDOW ASSY(OPTYPE-2PC-GREEN-PC)	TATA spare parts
A09600000442	SD WINDOW ASSY(OPTYPE-2PC-GREEN-PC)	TATA spare parts
A09600000443	FRP DASH BOARD FOR AMBULANCE	TATA spare parts
A09600000444	FRP ENGINE HOOD FOR AMBULANCE	TATA spare parts
A09600000445	FRP HEAD LIGHT PANEL COMPLETE	TATA spare parts
A09600000446	DECAL KIT JNNURM WB BUS	TATA spare parts
A09600000447	WIRING HARNESS COMPLETE LPO1610C KINGFIS	TATA spare parts
A09600000448	EMERGENCY DOOR GLASS	TATA spare parts
A09600000449	PASSENGER GRAB HANDLE	TATA spare parts
A09600000450	COMPRESSOR MTG BKT KIT+ PULLY	TATA spare parts
A09600000451	BELT FOR COMP	TATA spare parts
A09600000452	AL.EXPENDED METAL	TATA spare parts
A09600000453	AL.FOIL 150 MICRONS	TATA spare parts
A09600000454	PHENOLIC RESINATED FLET	TATA spare parts
A09600000455	SATURATED PE NONWOVEN	TATA spare parts
A09600000456	PIPE ERW 1 METER	TATA spare parts
A09600000457	GLASS (299X1483X4 THK)	TATA spare parts
A09600000458	GLASS (299X1543X4 THK)	TATA spare parts
A09600000459	S.S.PIANO HINGE (L=874MM)	TATA spare parts
A09600000460	BRACKET FOR DOOR CYLINDER	TATA spare parts

A09600000461	BEAM	TATA spare parts
A09600000462	PASSENGER BELL	TATA spare parts
A09600000463	PUBLIC ADDRESS SYSTEM	TATA spare parts
A09600000464	SD WINDOW ASSY (FIXED-FLOCK-CLEAR)	TATA spare parts
A09600000465	PASSENGER DOOR ASSEMBLY	TATA spare parts
A09600000466	PASSENGER DOOR ASSEMBLY	TATA spare parts
A09600000467	CATCHER	TATA spare parts
A09600000468	SD WINDOW ASSY (FLOCK-2PC-CLEAR-PC)	TATA spare parts
A09600000469	SD WINDOW ASSY (FLOCK-2PC-CLEAR-PC)	TATA spare parts
A09600000470	SD WINDOW ASSY (FLOCK-2PC-CLEAR-PC)	TATA spare parts
A09600000471	SD WINDOW ASSY(FLOCK-TAP-FIX-CLR-PC)	TATA spare parts
A09600000472	SD WINDOW ASSY (FLOCK/TAPER/CLEAR)	TATA spare parts
A09600000474	SD WINDOW ASSY(OPTYPE/2PC/CO-DRV/GRN)	TATA spare parts
A09600000475	BELT FOR ALT	TATA spare parts
A09600000476	AL-EXTRUSION (TOP FIX)(PCOAT)	TATA spare parts
A09600000477	LINE LIGHT WITH SPEAKER	TATA spare parts
A09600000478	SPEAKER FOR LINE LIGHT	TATA spare parts
A09600000479	ACRYLIC PLATE (216 X 305)	TATA spare parts
A09600000480	S.WN.ASSY(613/CUR/RH/TAP/GR/PC	TATA spare parts
A09600000481	SD WINDOW ASSY(OPTYPE/2PC/GRN/PC)	TATA spare parts
A09600000482	SD WINDOW ASSY(OPTYPE/2PC/GRN/PC)	TATA spare parts
A09600000483	SD WINDOW ASSY(OPTYPE/2PC/GRN/PC)	TATA spare parts
A09600000484	SD WINDOW ASSY(OPTYPE/2PC/GRN/PC)	TATA spare parts
A09600000485	GLASS CLEAR(265X1613X5)	TATA spare parts
A09600000486	SHAFT FOR PASSENGER DOOR	TATA spare parts
A09600000487	FAN SWITCH	TATA spare parts
A09600000488	ENTRANCE DOOR ASSY	TATA spare parts
A09600000489	ENTRANCE DOOR ASSY	TATA spare parts
A09600000490	ENTRANCE DOOR ASSY	TATA spare parts
A09600000491	PASSENGER DOOR ASSY	TATA spare parts
A09600000492	ENTRANCE DOOR ASSY	TATA spare parts
A09600000493	PARTITION ACRYLIC FOR LCV BUS	TATA spare parts
A09600000494	S.WIN.ASSY(FLOCK/2PC/CURVED/GREEN)	TATA spare parts
A09600000495	S.WIN.ASSY(FLOCK/2PC/CURVED/GREEN)	TATA spare parts
A09600000496	S.WIN.ASSY(FLOCK/2PC/CURVED/GREEN)	TATA spare parts
A09600000497	S.WIN.ASSY(FLOCK/2PC/CURVED/GREEN)	TATA spare parts
A09600000498	S.WIN.ASSY(FLOCK/2PC/CURVED/GREEN)	TATA spare parts
A09600000499	S.WIN.ASSY(FLOCK/2PC/CURVED/GREEN)	TATA spare parts
A09600000500	S.WIN.ASSY(FLOCK/2PC/CURVED/GREEN)	TATA spare parts
A09600000501	SD WINDOW ASSY(OPTYPE/2PC/GRN/PC)	TATA spare parts
A09600000502	SD WINDOW ASSY(OPTYPE/2PC/GRN/PC)	TATA spare parts
A09600000503	SD WINDOW ASSY(OPTYPE/2PC/GRN/PC)	TATA spare parts
A09600000504	SD WINDOW ASSY(OPTYPE/2PC/GRN/PC)	TATA spare parts
A09600000505	SD WINDOW ASSY(OPTYPE/2PC/GRN/PC)	TATA spare parts
A09600000506	SD WINDOW ASSY(OPTYPE/2PC/GRN/PC)	TATA spare parts
A09600000507	SD WIN ASSY(OPTYPE-CUR-3PC-CLR-TFIX)	TATA spare parts
A09600000508	SD WIN ASSY(OPTYPE-CUR-3PC-CLR-TFIX)	TATA spare parts

A09600000509	SD WIN ASSY(OPTYPE-CUR-3PC-GRN-TFIX)	TATA spare parts
A09600000510	SD WIN ASSY(OPTYPE-CUR-3PC-GRN-TFIX)	TATA spare parts
A09600000511	SD WIN ASSY(OPTYPE-CUR-3PC-GRN-TFIX)	TATA spare parts
A09600000512	SD WIN ASSY(OPTYPE-CUR-3PC-GRN-TFIX)	TATA spare parts
A09600000513	SD WIN ASSY(OPTYPE-CUR-3PC-GRN-TFIX)	TATA spare parts
A09600000514	SD WIN ASSY(OPTYPE-CUR-3PC-GRN-TFIX)	TATA spare parts
A09600000515	BELL SW COVER	TATA spare parts
A09600000516	SD WINDOW ASSY(OPTYPE-TAP-CUR-CLR-FIX)	TATA spare parts
A09600000517	SD WIN ASSY(OPTYPE-CUR-CLR-TAP-TFIX)	TATA spare parts
A09600000518	SD WIN ASSY(OPTYPE-CUR-GRN-TAP-TFIX)	TATA spare parts
A09600000519	SPEAKER(10CM)	TATA spare parts
A09600000522	SD WIND ASSY (CUR/FLOCK/PARTIAL)	TATA spare parts
A09600000523	FRONT W/S LAM GLASS(COMFORT MODEL) BS1/2	TATA spare parts
A09600000524	FRONT W/S GLASS (LAMINATED SINGLE PC - 9	TATA spare parts
A09600000525	GLASS TINTED (288X1685X5 THK)	TATA spare parts
A09600000526	GLASS TINTED (268X1685X5 THK)	TATA spare parts
A09600000527	FRP ENGINE HOOD FOR COMFORT-1618 MODEL	TATA spare parts
A09600000528	FRP PODEST FOR COMFORT-1618 MODEL	TATA spare parts
A09600000529	FRP REAR STRUCTURE(COMFORT MODEL)	TATA spare parts
A09600000530	PLASTIC FOOTSTEP COVER(COMFORT MODEL)	TATA spare parts
A09600000531	PASSENGER DOOR ASSEMBLY	TATA spare parts
A09600000532	PEEP GLASS FOR LPO COMFORT BUS	TATA spare parts
A09600000533	SD WINDOW ASSY(OPTYPE-2PC-FIX-DGRY)	TATA spare parts
A09600000534	SD WINDOW ASSY(OPTYPE-3PC-TSLD-DGRY)	TATA spare parts
A09600000535	SD WINDOW ASSY(OPTYPE-3PC-TSLD-DGRY)	TATA spare parts
A09600000536	SD WINDOW ASSY(OPTYPE-3PC-TSLD-DGRY)	TATA spare parts
A09600000537	SD WINDOW ASSY(OPTYPE-3PC-TSLD-DGRY)	TATA spare parts
A09600000538	SD WINDOW ASSY(OPTYPE-3PC-TSLD-DGRY)	TATA spare parts
A09600000539	PLYWOOD BOARD FOR DRIVER'S PARTITION	TATA spare parts
A09600000540	PLYWOOD BOARD FOR STEP PARTITION	TATA spare parts
A09600000541	CUR RAIL BRKT(NYL-19 DIA-GREY)	TATA spare parts
A09600000542	RVM ARM ASSY & BKT- RHD-LH	TATA spare parts
A09600000543	RVM ARM ASSY & BKT- RHD-RH	TATA spare parts
A09600000544	HEAD LAMP SET LHD - RH SIDE (NON MOT)	TATA spare parts
A09600000545	HEAD LAMP SET LHD - LH SIDE (NON MOT)	TATA spare parts
A09600000546	TOWER BOLT (4 INCH)	TATA spare parts
A09600000547	WIPER ASSEMBLY COMPLETE	TATA spare parts
A09600000548	KNOB FOR 6HD AIR CLEANER(50MM)	TATA spare parts
A09600000549	FRP DASHBOARD COMPLETE (COMFORT-1618)	TATA spare parts
A09600000550	FRP AIR CLEANER PANEL ASSEMBLY	TATA spare parts
A09600000551	SD WINDOW ASSY (OPTYPE-2PC-GREEN)	TATA spare parts
A09600000552	REED SWITCH	TATA spare parts
A09600000553	BUS CONTROLLER III	TATA spare parts
A09600000557	45 DEG PIPE BRACKET (38DIA) (PC)	TATA spare parts
A09600000558	PVC TRIM BEADING(BLACK) (LENGTH 10 MTR)	TATA spare parts
A09600000559	PIPE BRACKET/BASE (38 DIA)(PC)	TATA spare parts
A09600000560	FRONT WINDSHIELD RUBBER	TATA spare parts

A09600000561	FRONT BUMPER ASSY	TATA spare parts
A09600000562	FRONT SHELL GRILL	TATA spare parts
A09600000563	FRONT FACE PANEL	TATA spare parts
A09600000564	FRONT CENTER FLAP	TATA spare parts
A09600000565	FRONT SHELL FIN	TATA spare parts
A09600000566	REAR BODY PANEL	TATA spare parts
A09600000567	REAR BOOT FLAP	TATA spare parts
A09600000568	REAR BUMPER ASSY	TATA spare parts
A09600000569	REAR WINDSHIELD	TATA spare parts
A09600000570	REAR WINDSHIELD BEADING	TATA spare parts
A09600000571	EMERGENCY DOOR LOCK	TATA spare parts
A09600000572	SLIDING WINDOW SIDE LH /RH	TATA spare parts
A09600000573	SLIDING WINDOW CO DRIVER SIDE FRONT	TATA spare parts
A09600000574	SLIDING WINDOW CO DRIVER SIDE REAR	TATA spare parts
A09600000576	FIXED GLASS	TATA spare parts
A09600000577	SLIDING WINDOW FIRST RH	TATA spare parts
A09600000578	FRP DASH BOARD COMPLETE (COMFORT BUS)	TATA spare parts
A09600000579	PRINTED CURV GLASS GREEN50 TIN	TATA spare parts
A09600000580	PRINTED CURV GLASS GREEN50 TIN	TATA spare parts
A09600000581	DRIVER DOOR WINDOW (PC)	TATA spare parts
A09600000582	PASSENGER DOOR WINDOW (PC)	TATA spare parts
A09600000583	QUARTER GLASS-PASSENGER SIDE	TATA spare parts
A09600000584	QUARTER GLASS-PASSENGER SIDE	TATA spare parts
A09600000585	FRP DASHBOARD COMPLETE	TATA spare parts
A09600000586	DRIVER'S DOOR COMPLETE	TATA spare parts
A09600000587	EMERGENCY DOOR COMPLETE	TATA spare parts
A09600000588	FRP PODEST FOR COMFORT	TATA spare parts
A09600000589	ENMERGENCY DOOR INNER HANDLE	TATA spare parts
A09600000590	BAGGAGE RACK (RH)	TATA spare parts
A09600000591	BAGGAGE RACK (LH)	TATA spare parts
A09600000592	PASSENGER DOOR ASSEMBLY(FRT)	TATA spare parts
A09600000593	PASSENGER DOOR HANDLE	TATA spare parts
A09600000594	PASSENGER DOOR ASSEMBLY(REAR)	TATA spare parts
A09600000595	RVM ARM ASSY & BKT- RHD-LH	TATA spare parts
A09600000596	FRONT PASSENGER DOOR ASSSY	TATA spare parts
A09600000597	DRIVER SEAT	TATA spare parts
A09600000598	DRIVER SEAT	TATA spare parts
A09600000599	FRP WHEEL HUB COVER FRT.10X20D	TATA spare parts
A09600000600	FRP WHL HUB COVER REAR.10X20D	TATA spare parts
A09600000601	GRAB RAIL PIPE BKT	TATA spare parts
A09600000602	GLASS TINTED(265X1865X5THK.)	TATA spare parts
A09600000603	FRP REAR STRUCTURE(COMFORT)	TATA spare parts
A09600000604	PASSENGER DOOR ASSEMBLY	TATA spare parts
A09600000605	FRONT W/S LAM GLASS(COMFORT MODEL)	TATA spare parts
A09600000606	SD WINDOW ASSY	TATA spare parts
A09600000607	SD WINDOW ASSY	TATA spare parts
A09600000608	SD WINDOW ASSY	TATA spare parts



A09600000609	CO-DRV. SIDE WINDOW ASSY.	TATA spare parts
A09600000610	SD WINDOW ASSY(EMG. DOOR)	TATA spare parts
A09600000611	PARTITION GLASS ASSY.	TATA spare parts
A09600000612	UNDR V MRR(PARK)ETECH	TATA spare parts
A09600000613	WIPER SYSTEM (COMFORT)	TATA spare parts
A09600000614	FRP AIR CLEANER PANEL ASSEMBLY	TATA spare parts
A09600000615	RUBBER PAD	TATA spare parts
A09600000616	RUBBER PAD	TATA spare parts
A09600000617	BAGGAGE RACK (RH)	TATA spare parts
A09600000618	BAGGAGE RACK (LH)	TATA spare parts
A09600000619	DRV DOOR ASSY.	TATA spare parts
A09600000620	DEST. TUBE LIGHT BKT.	TATA spare parts
A09600000621	HEAD LIGHT BULB	TATA spare parts
A09600000622	PASS. DOOR HANDLE	TATA spare parts
A09600000623	GRAB RAIL PIPE	TATA spare parts
A09600000624	GLASS TINTED (288X1645X5 THK)	TATA spare parts
A09600000625	GLASS TINTED (268X1645X5 THK)	TATA spare parts
A09600000626	FRP ENGINE HOOD FOR COMFORT	TATA spare parts
A09600000627	PEEP GLASS FOR LPO COMFORT BUS	TATA spare parts
A09600000628	SD WINDOW ASSY	TATA spare parts
A09600000629	SD WINDOW ASSY(DRV. DOOR)	TATA spare parts
A09600000630	SD WINDOW ASSY	TATA spare parts
A09600000631	SD WINDOW ASSY	TATA spare parts
A09600000632	FRP DASHBOARD COMPLETE	TATA spare parts
A09600000633	FRP AIR CLEANER PANEL ASSEMBLY	TATA spare parts
A09600000634	CLEAR GLASS TOUGHENED	TATA spare parts
A09600000635	RUBBER PAD	TATA spare parts
A09600000636	BAGGAGE RACK (LH)	TATA spare parts
A09600000637	SD WINDOW ASSY	TATA spare parts
A09600000638	SD WINDOW ASSY	TATA spare parts
A09600000639	SD WINDOW ASSY	TATA spare parts
A09600000640	SD WINDOW ASSY	TATA spare parts
A09600000641	RUBBER BEADING WITH KEY (W/S)	TATA spare parts
A09600000642	BUSH	TATA spare parts
A09600000643	BUSH	TATA spare parts
A09600000644	STICKRING SET(DECL SET)	TATA spare parts
A09600000645	WHEEL ARCH FRONT LH	TATA spare parts
A09600000646	WHEEL ARCH FRONT R/H	TATA spare parts
A09600000647	WHEEL ARCH REAR L/H	TATA spare parts
A09600000648	WHEEL ARCH REAR R/H	TATA spare parts
A09600000649	VINYL TUBE	TATA spare parts
A09600000650	WHEEL ARCH FRONT LH	TATA spare parts
A09600000651	WHEEL ARCH FRONT R/H	TATA spare parts
A09600000652	WHEEL ARCH REAR L/H	TATA spare parts
A09600000653	YELLOW REFLECTIVE TAPE	TATA spare parts
A09600000654	SEAT ASSY. (2)	TATA spare parts
A09600000655	SEAT ASSY. (6)	TATA spare parts

A09600000656	DRV. SEAT	TATA spare parts
A09600000657	HEAD LAMP SET LHD LH (MOTORIZED)	TATA spare parts
A09600000658	SEAT ASSY.(2)	TATA spare parts
A09600000659	DRV. SEAT	TATA spare parts
A09600000660	DOOR HANDLE WITH KEY LH (207)	TATA spare parts
A09600000661	ROOF HATCH	TATA spare parts
A09600000662	SEAT AASY (3)	TATA spare parts
A09600000663	SEAT AASY (2)	TATA spare parts
A09600000664	SEAT AASY (6)	TATA spare parts
A09600000665	STARBUS BADGE	TATA spare parts
A09600000666	WHEEL ARCH FRONT LH	TATA spare parts
A09600000667	WINDOW GUARD RAIL PIPE	TATA spare parts
A09600000668	STICKRING SET(DECAL SET)	TATA spare parts
A09600000669	ALTERNATOR & COMPRESSOR MOUNTING BRACK	TATA spare parts
A09600000670	FOG LAMP FRONT L/H	TATA spare parts
A09600000671	SIGNAL LAMP FRONT L/H	TATA spare parts
A09600000672	SIGNAL LAMP FRONT R/H	TATA spare parts
A09600000673	REVERSE LAMP	TATA spare parts
A09600000674	BRAKE LAMP	TATA spare parts
A09600000675	REAR SIGNAL LAMP	TATA spare parts
A09600000676	HEAD LAMP	TATA spare parts
A09600000677	REAR FOG LAMP	TATA spare parts
A09600000678	RIGHT REAR LATERAL GLASS	TATA spare parts
A09600000679	SIDE WINDOW GLASS (LEFT)	TATA spare parts
A09600000680	LEFT FRONT LATERAL GLASS	TATA spare parts
A09600000681	LEFT REAR LATERAL GLASS	TATA spare parts
A09600000682	SKIRT PANEL ASSEMBLY L= 1821 MM	TATA spare parts
A09600000683	SKIRT PANEL ASSEMBLY L= 1745 MM	TATA spare parts
A09600000684	SKIRT PANEL ASSEMBLY L= 1205 MM	TATA spare parts
A09600000685	SKIRT PANEL ASSEMBLY L= 1731 MM	TATA spare parts
A09600000686	SKIRT PANEL ASSEMBLY L= 855 MM	TATA spare parts
A09600000687	SKIRT PANEL ASSEMBLY L= 1371 MM	TATA spare parts
A09600000688	SKIRT PANEL ASSEMBLY L= 1520 MM	TATA spare parts
A09600000689	SKIRT PANEL ASSEMBLY L= 1505 MM	TATA spare parts
A09600000690	SKIRT PANEL ASSEMBLY L= 855 MM	TATA spare parts
A09600000691	SKIRT PANEL ASSEMBLY L= 1371 MM	TATA spare parts
A09600000692	SKIRT PANEL ASSEMBLY L= 396 MM	TATA spare parts
A09600000693	SKIRT PANEL ASSEMBLY L= 476 MM	TATA spare parts
A09600000694	SKIRT PANEL ASSEMBLY L= 1731 MM	TATA spare parts
A09600000695	DRIVER DOOR CATCHER COVER	TATA spare parts
A09600000696	DRIVER DOOR LOCK COVER	TATA spare parts
A09600000697	DOOR COVER LH (PASSENGER SIDE)	TATA spare parts
A09600000698	PASSENGER DOOR UPPER GARNISH	TATA spare parts
A09600000699	A PILLAR INNER COVER-RH	TATA spare parts
A09600000700	A PILLAR INNER COVER-LH	TATA spare parts
A09600000701	STEERING COVER	TATA spare parts
A09600000702	BOTTLE HOLDER (PLASTIC)	TATA spare parts

A09600000703	DASHBOARD LEATHER COVER (STICH	TATA spare parts
A09600000704	CO- DRIVER&S FOLDABLE SEAT	TATA spare parts
A09600000705	T- RAIL AL. EXTRUSION	TATA spare parts
A09600000706	T- RAIL AL. EXTRUSION COVER	TATA spare parts
A09600000707	SOCKET	TATA spare parts
A09600000708	SWITCH	TATA spare parts
A09600000709	REAR NO PLATE	TATA spare parts
A09600000710	LICENSE LAMP	TATA spare parts
A09600000711	ROOF LIGHT AMBER	TATA spare parts
A09600000712	FRONT NO PLATE	TATA spare parts
A09600000713	GLASS BREAKING HAMMER WITH ROTAR SPRING	TATA spare parts
A09600000714	AL-EXTRUSION	TATA spare parts
A09600000715	AL-EXTRUSION	TATA spare parts
A09600000716	WHEEL HUB CAP FRONT	TATA spare parts
A09600000717	WHEEL HUB CAP REAR	TATA spare parts
A09600000718	CURTAIN RAIL-C TYPE(GREY)	TATA spare parts
A09600000719	CURTAIN	TATA spare parts
A09600000720	FLEXIBLE BLIND SCREEN LH	TATA spare parts
A09600000721	FLEXIBLE BLIND SCREEN RH	TATA spare parts
A09600000722	SUNVISOR FRONT LARGE	TATA spare parts
A09600000723	FIRE EXTINGUISHER(1 KG)	TATA spare parts
A09600000724	SERV SET W/O VOL CO	TATA spare parts
A09600000725	HATRACK ASSY NEW	TATA spare parts
A09600000726	DRIVER PARTITION	TATA spare parts
A09600000727	ALUMINUM EXTRUSION (LENGTH 3000MM)	TATA spare parts
A09600000728	RUBBER BEADING	TATA spare parts
A09600000729	'H' EXTRUSION	TATA spare parts
A09600000730	EXTRUSION (SIEVE OUTER CTB) (3500MM)	TATA spare parts
A09600000731	AL EXTRUSION	TATA spare parts
A09600000732	RUBBER BEADING (LENGTH 10 MTR)	TATA spare parts
A09600000733	MARUTHI BEADING	TATA spare parts
A09600000734	LEFT TOP ABOVE DOORWAY GLASS	TATA spare parts
A09600000735	DRIVER SIDE LOWER GARNISH	TATA spare parts
A09600000736	INNER GRAB HANDLE	TATA spare parts
A09600000737	FOG LAMP REAR LED	TATA spare parts
A09600000738	ROOF LIGHT LED 24V	TATA spare parts
A09600000739	SIDE MARKER LAMP	TATA spare parts
A09600000740	REVERSE HORN (24V)	TATA spare parts
A09600000741	HEAD LAMP	TATA spare parts
A09600000742	T-MONOGRAM(OVAL TYPE)	TATA spare parts
A09600000743	SEAT BELT	TATA spare parts
A09600000744	SALOON MIRROR	TATA spare parts
A09600000745	FIRST AID BOX	TATA spare parts
A09600000746	FIRE EXTINGUISHER (5 KG)	TATA spare parts
A09600000747	TATA MUD FLAP	TATA spare parts
A09600000748	STEP CASTING	TATA spare parts
A09600000749	ALLUMINIUM EXT.(POWDER COATED)	TATA spare parts

A09600000750	BEADING(GREY)/CUSHION	TATA spare parts
A09600000751	LH PASS. SEAT W/ARM REST & SEAT BELT 2	TATA spare parts
A09600000752	PASS. SEAT W/O ARM REST & SEAT BELT 3	TATA spare parts
A09600000753	PASS. SEAT W/ARM REST W/O SEAT BELT 3	TATA spare parts
A09600000754	RH PASS. SEAT W/ARM REST & SEAT BELT 3	TATA spare parts
A09600000755	PASS. SEAT W/O ARM REST & SEAT BELT 2	TATA spare parts
A09600000756	PASS. SEAT W/O ARM REST & SEAT BELT 3	TATA spare parts
A09600000757	PASSENGER DOOR GLASS	TATA spare parts
A09600000758	FRONT TFT SCREEN	TATA spare parts
A09600000759	BUDGET LOCK	TATA spare parts
A09600000760	FRONT GAUGE PLATE ASSEMBLY	TATA spare parts
A09600000761	DASH BOARD (SINGLE PIECE)	TATA spare parts
A09600000762	STEERING COVER	TATA spare parts
A09600000763	DASHBOARD PLATING	TATA spare parts
A09600000764	HORN SHIELD	TATA spare parts
A09600000765	ALUMINIUM EXTRUSION	TATA spare parts
A09600000766	DIGITAL CLOCK	TATA spare parts
A09600000767	REFRIGRATOR	TATA spare parts
A09600000768	MINI ROUND LAMP ASSY(24V)	TATA spare parts
A09600000769	GAS STAY	TATA spare parts
A09600000770	FRONT SEAT RH	TATA spare parts
A09600000771	PASSENGER DOOR HANDLE	TATA spare parts
A09600000772	INTERNAL CAMERA	TATA spare parts
A09600000773	NYLON CATCHER ASSEMBLY	TATA spare parts
A09600000774	7 INCH TFT MONITOR	TATA spare parts
A09600000775	DVD PLAYER	TATA spare parts
A09600000776	17INCH LCD MONITOR	TATA spare parts
A09600000777	INNER PASSENGER DOOR KNOB	TATA spare parts
A09600000778	REAR PASS DOOR GLASS	TATA spare parts
A09600000779	FRONT PASS. DOOR GLASS	TATA spare parts
A09600000780	FRONT PASS. DOOR GLASS (TAPER)	TATA spare parts
A09600000781	FRONT FRP PANEL	TATA spare parts
A09600000782	GRILL (AC LOUVER)	TATA spare parts
A09600000783	FRONT PASS DOOR ASSY	TATA spare parts
A09600000784	LOCK COVER	TATA spare parts
A09600000785	DRV. DOOR ASSY	TATA spare parts
A09600000786	WINDSHIELD MOULD BS2	TATA spare parts
A09600000787	FRONT WINDSHIELD BS2/4	TATA spare parts
A09600000788	LAST FIX WINDOW	TATA spare parts
A09600000789	EMG. WINDOW	TATA spare parts
A09600000790	WINDOW ASSY LHS 1ST	TATA spare parts
A09600000791	WINDOW ASSY LHS 4TH & 5TH	TATA spare parts
A09600000792	WINDOW ASSY LHS 2ND & 3RD	TATA spare parts
A09600000793	WINDOW ASSY RHS 4TH & 5TH	TATA spare parts
A09600000794	WINDOW ASSY RHS 1ST . 2ND & 3RD	TATA spare parts
A09600000795	PASS. MIRROR ARM	TATA spare parts
A09600000796	3 SEATER.	TATA spare parts

A09600000797	2 SEATER.	TATA spare parts
A09600000798	DASHBOARD COMPL	TATA spare parts
A09600000799	REAR BUMPER ASSEMBLY	TATA spare parts
A1-3222-M-C091	BRAKE SHOE LINING ASSY	TATA spare parts
A1-3264-G-C007	DUST SHEILD- LH / RH	TATA spare parts
A1-3264-H-C008	DUST SHEILD- LH / RH	TATA spare parts
A67290000001	WIPER MOTOR 24 VDC/ 150 W/O 13.5 SPLINE	TATA spare parts
A67290000002	WIPER LINKAGE ASSY 1700 1800 MM (RHD)	TATA spare parts
A67290000003	TWIN ROD WIPER ARM 750 MM LH (RHD)	TATA spare parts
A67290000004	TWIN ROD WIPER ARM 750 MM RH (RHD)	TATA spare parts
A67290000005	HEAVY DUTY WIPER BLADE HD 40 / 1010 MM	TATA spare parts
A67290000006	WASHER TANK 3LTR BS1/3	TATA spare parts
A67290000007	WASH TUBE KIT	TATA spare parts
A67290000008	WIPER LINKAGE ASSY (LHD)	TATA spare parts
A67290000009	WIPER ARM LH (LHD)	TATA spare parts
A67290000010	WIPER ARM RH (LHD)	TATA spare parts
A67290000011	WIPER LINKAGE ( PANTOGRAPH ) DUAL PANTOM	TATA spare parts
A67290000012	PANTOGRAPH WIPER ARM 730 MM LONG	TATA spare parts
A67290000013	HEAVY DUTY WIPER BLADE( PANTOGRAPH) 710	TATA spare parts
A71680000001	DRIVER DOOR COMPLETE ASSY.(CITY RIDE 407	TATA spare parts
A71680000002	GREY VINYL 2 M.M.	TATA spare parts
A71680000003	PLYWOOD 12 M.M.	TATA spare parts
A71680000004	SEATS SET FOR VEHICLE	TATA spare parts
A71680000005	WINDOW SET FOR VEHICLE	TATA spare parts
A71680000006	CLOSE SOCKET 709	TATA spare parts
A71680000007	OPEN SOCKET 709	TATA spare parts
A71680000008	GRAB RAIL GUTKA	TATA spare parts
A71680000009	GRAB RAIL BKT	TATA spare parts
A71680000010	UPPER HINGE JK DOOR	TATA spare parts
A71680000011	CENTER HINGE JK DOOR	TATA spare parts
A71680000012	BEARING PLATE ROUND	TATA spare parts
A71680000013	SQUARE BEARING PLATE	TATA spare parts
A71680000014	BEARING	TATA spare parts
A71680000015	TOWER BOLT 10 INCH	TATA spare parts
A71680000016	TOWER BOLT 6 INCH	TATA spare parts
A71680000017	JK DOOR ROLLER	TATA spare parts
A71680000018	JK DOOR PIN BIG	TATA spare parts
A71680000019	JK DOOR PIN SMALL	TATA spare parts
A71680000020	CUT OUT BUSH	TATA spare parts
A71680000021	REAR BUMPER FIBER	TATA spare parts
A71680000022	GRAB HANDLE	TATA spare parts
A71680000023	RUBRAIL END CAP	TATA spare parts
A71680000024	ADHESIVE 3 M	TATA spare parts
A71680000025	DR. DOOR FRAME	TATA spare parts
A71680000026	DR. DOOR KIT	TATA spare parts
A71680000027	NYLON STOPPER JK DOOR	TATA spare parts
A71680000028	B PILLER	TATA spare parts

A7168000029	JK DOOR WASHER	TATA spare parts
A7168000030	ROOF PVC BEEDING	TATA spare parts
A7168000031	END CAP	TATA spare parts
A7168000032	PEACKING DR. PARTION	TATA spare parts
A7168000033	PEACKING DR. PARTION SIDE	TATA spare parts
A7168000034	PEACKING JK DOOR	TATA spare parts
A7168000035	WHITE SELENT 3 M	TATA spare parts
A7168000036	BLACK SELENT 3 M	TATA spare parts
A7168000037	CLEANER 3 M	TATA spare parts
A7168000038	CURTAIN RAIL HOOK	TATA spare parts
A7168000039	BALATA PEACKING 8 M.M	TATA spare parts
A7168000040	U BOLT 3204	TATA spare parts
A7168000041	U BOLT 3205	TATA spare parts
A7168000042	U BOLT 1837	TATA spare parts
A7168000043	NUT M - 12	TATA spare parts
A7168000044	J BEEDING WHITE	TATA spare parts
A7168000045	JK DOOR BRUSH	TATA spare parts
A7168000046	A PILER HANDLE	TATA spare parts
A7168000047	DOUBLE SIDE TAPE 3 M	TATA spare parts
A7168000048	ROUND END CAP 22 M.M.	TATA spare parts
A7168000049	HINGES 4 INCH	TATA spare parts
A7168000050	OUTER HANDLE	TATA spare parts
A7168000051	INNER HANDLE	TATA spare parts
A7168000052	FUEL LEAD LOCK	TATA spare parts
A7168000053	DR. DOOR LATCH	TATA spare parts
A7168000054	SUNVISOR	TATA spare parts
A7168000055	PROXIMITY MIRROR	TATA spare parts
A7168000056	RVM HANDLE	TATA spare parts
A7168000057	FIRST AID BOX	TATA spare parts
A7168000058	CEASE FIRE 1 KG	TATA spare parts
A7168000059	BATTERY CUT OF SWITCH COVER	TATA spare parts
A7168000060	STICKER CUT OF SWITCH	TATA spare parts
A7168000061	DIEASEL TANK STICKERS	TATA spare parts
A7168000062	HILUM PLATE	TATA spare parts
A7168000063	CABLE TIE	TATA spare parts
A7168000064	BALATA PACKING 6 M.M.	TATA spare parts
A7168000065	U- CLAMP GUTKA BIG	TATA spare parts
A7168000066	U- CLAMP GUTKA SMALL	TATA spare parts
A7168000067	GRAB RAIL PACKING	TATA spare parts
A7168000068	MUD FLAP BIG	TATA spare parts
A7168000069	MUD FLAP SMALL	TATA spare parts
A7168000070	STOP SWITCH	TATA spare parts
A7168000071	CORREGETED SLEAVE 6 M.M.	TATA spare parts
A7168000072	GATE HOOK 8 INCH	TATA spare parts
A7168000073	WHITE REFLECTIVE TAPE	TATA spare parts
A7168000074	RED REFLECTIVE TAPE	TATA spare parts
A7168000075	YELLOW REFLECTIVE TAPE	TATA spare parts

A71680000076	DOOR STRICKER PLATE	TATA spare parts
A71680000077	BASE SOCKET 1.5 INCH	TATA spare parts
A71680000078	CUT OUT HANDLE BRASS	TATA spare parts
A71680000079	DRIVER SEAT	TATA spare parts
A71680000080	HANGING HANDLE	TATA spare parts
A71680000081	DECAL COST	TATA spare parts
A71680000082	DR DOOR UPPER HINGE	TATA spare parts
A71680000083	DR DOOR LOWER HINGE	TATA spare parts
A71680000084	TATA MASCOT	TATA spare parts
A71680000085	DOOR SWITCH	TATA spare parts
A71680000086	JK DOOR RUBBER 1026	TATA spare parts
A71680000087	JK DOOR RUBBER 1027	TATA spare parts
A71680000088	JK DOOR RUBBER 1030	TATA spare parts
A71680000089	JK DOOR GLASS MOLDED RUBBER	TATA spare parts
A71680000090	PEEP WINDOW GLASS RUBBER	TATA spare parts
A71680000091	PARTION H SECTION RUBBER	TATA spare parts
A71680000092	RUBRAIL RUBBER	TATA spare parts
A71680000093	KICK RUBBER	TATA spare parts
A71680000094	CENTER GRAB RAIL PACKING	TATA spare parts
A71680000095	PEEP WINDOW GLASS	TATA spare parts
A71680000096	JK DOOR GLASS	TATA spare parts
A71680000097	PARTION GLASS	TATA spare parts
A71680000098	DR. DOOR GLASS	TATA spare parts
A71680000099	ROOF LIGHT WITH CFL	TATA spare parts
A71680000100	HEIGHT MARKER FRONT	TATA spare parts
A71680000101	HEIGHT MARKER REAR	TATA spare parts
A71680000102	REGISTRATION PLATE LIGHT	TATA spare parts
A71680000103	FOOT STEP LIGHT	TATA spare parts
A71680000104	HARNESS	TATA spare parts
A71680000105	HARNESS	TATA spare parts
A71680000106	HARNESS	TATA spare parts
A71680000107	HARNESS	TATA spare parts
A71680000108	HARNESS	TATA spare parts
A71680000109	HARNESS	TATA spare parts
A71680000110	SIDE MARKER LAMP	TATA spare parts
A71680000111	INDICATOR	TATA spare parts
A71680000112	BATORY CABLE 2830 M.M.	TATA spare parts
A71680000113	BATORY CABLE 2740 M.M.	TATA spare parts
A71680000114	DESTINATION BOARD	TATA spare parts
A71680000115	CORREGETED SLEEVE 25 M.M.	TATA spare parts
A71680000116	INSULATION TAPE	TATA spare parts
A71680000117	GROMET 40 M.M.	TATA spare parts
A71680000118	GROMET 30 M.M.	TATA spare parts
A71680000119	PIANO SWITCH	TATA spare parts
A71680000120	COUPLER TWO WAY MALE	TATA spare parts
A71680000121	COUPLER TWO MALE FEMALE	TATA spare parts
A71680000122	BUZZER	TATA spare parts

A8145000001	ROAD SPEED ALARM HOOTER 12 V	TATA spare parts
A8145000002	BUMPER STEP SECTION	TATA spare parts
A8145000003	EDGE SECTION FOR STEP & WHEEL HOUSES	TATA spare parts
A8145000004	WEARING STRIP FOR CHEQUERED FLOOR	TATA spare parts
A8145000005	SIDE GUTTER SECTION	TATA spare parts
A8145000006	PANEL JOINT BEADING	TATA spare parts
A8145000007	J WATER CHANNEL 6200	TATA spare parts
A8145000008	PANEL JOINT BEADING	TATA spare parts
A8145000009	PANEL JOINT BEADING	TATA spare parts
A8145000010	RUBRAIL BEADING	TATA spare parts
A8145000011	ROOF BEADING	TATA spare parts
A8145000012	ALUMINIUM BEADING	TATA spare parts
A8145000013	ALUMINIUM PIPE 1IN	TATA spare parts
A8145000014	SMALL 'Y' SECTION FOR DRIVER'S PARTITIO	TATA spare parts
A8145000015	ALUMINIUM ANGLE SECTION	TATA spare parts
A8145000016	ALUM. WINDOW WEATHER SHADES	TATA spare parts
A8145000017	FRONT & REAR DESTINATION GLASS 350X204	TATA spare parts
A8145000018	N/S DESTINATION GLASS 260X1050X5THK.	TATA spare parts
A8145000019	FRONT EXIT DOOR GLASS 230X1300	TATA spare parts
A8145000020	REAR ENTRANCE DOOR GLASS 140X1300X5THK	TATA spare parts
A8145000021	SALON WINDOW GLASS 700X380X5THK	TATA spare parts
A8145000022	SALON WINDOW GLASS 540X380X5THK	TATA spare parts
A8145000023	SALON WINDOW GLASS 380X380X5THK	TATA spare parts
A8145000024	QUARTERLITE GLASS 810X225X5THK	TATA spare parts
A8145000025	QUARTERLITE GLASS 810X225X180X5THK	TATA spare parts
A8145000026	REAR EMERGENCY & FIXED GLASS 990X610X5	TATA spare parts
A8145000027	FRONT WINDSHIELD GLASS-TOP 1133X1120X6	TATA spare parts
A8145000028	FRONT WINDSHIELD GLASS-BOTTOM 1135X190	TATA spare parts
A8145000029	M.S. PIANO HINGES 20X20X1.20	TATA spare parts
A8145000030	MS HINGES 4IN X 1IN X 14G	TATA spare parts
A8145000031	MS HINGES 5IN X 1IN X 12G	TATA spare parts
A8145000032	RAILWAY LOCK	TATA spare parts
A8145000033	CASTED FOOTSTEP BIG-267X100X114 DEEP	TATA spare parts
A8145000034	MUDFLAP RUBBER (BIG)	TATA spare parts
A8145000035	NYLON BELL ROLLER	TATA spare parts
A8145000036	BELL ROLLER END RING	TATA spare parts
A8145000037	ROOF ASSISTRAIL PIPE BRACKET-TOP HAT.	TATA spare parts
A8145000038	M S TOWER BOLT 4IN	TATA spare parts
A8145000039	GRAB HANDLE - BEST TYPE	TATA spare parts
A8145000040	REFLECTOR SQUARE (WHITE)	TATA spare parts
A8145000041	REFLECTOR RED ROUND	TATA spare parts
A8145000042	SQUARE REFLECTOR - AMBER.	TATA spare parts
A8145000043	CURTAIN HOOK SS	TATA spare parts
A8145000044	RV MIRROR ROD BRACKET ASSY.DIA 19X400 LG	TATA spare parts
A8145000045	REAR VIEW MIRROR - SLD RVM 16	TATA spare parts
A8145000046	COAT HOOK3IN	TATA spare parts
A8145000047	STAINLESS STEEL CLIP - 25 MM	TATA spare parts



A8145000048	STAINLESS STEEL CLIP - 100 MM	TATA spare parts
A8145000049	FIRE EXTINGUISHER WITH GUAGE - 2KG	TATA spare parts
A8145000050	FIRE EXTINGUISHER BRACKET.	TATA spare parts
A8145000051	BONNET LOCK 50 WIDE X2.5THK WITH KNOB	TATA spare parts
A8145000052	BUDGET LOCKS	TATA spare parts
A8145000053	BULB HORN DOUBLE TONE	TATA spare parts
A8145000054	ALUM. SECT. SOCKET 25 ID YELLOW PC	TATA spare parts
A8145000055	BASE SOCKET 1IN YELLOW POWDER COATED	TATA spare parts
A8145000056	BASE SOCKET 1 1/2IN YELLOW POWDER COATE	TATA spare parts
A8145000057	EXPORT SOCKET 1IN X 1IN	TATA spare parts
A8145000058	ALU VERTI. CLOSE SOCKET 25MM YELLOW P.C.	TATA spare parts
A8145000059	ALU HORIZ CLOSE SOCKET 25 MM	TATA spare parts
A8145000060	HANDICAPPED BRACKET	TATA spare parts
A8145000061	HAND STRAP (STARBUS) TRIANGULAR	TATA spare parts
A8145000062	BASE SOCKET PACKING 1 1/2IN STRAIGHT	TATA spare parts
A8145000063	SOCKET FOR MIRROR BRKT. ASSLY. 75X19 ID	TATA spare parts
A8145000064	TURN BUTTON (MALE-FEMALE)	TATA spare parts
A8145000065	PNEUMATIC CYLINDER KIT JANATICS (BEST)	TATA spare parts
A8145000066	DOOR COCK BRAND LOCK-RHS	TATA spare parts
A8145000067	DOOR COCK BRAND LOCK- LHS	TATA spare parts
A8145000068	NON-LOCKING HANDLE	TATA spare parts
A8145000069	QUARTER PIN 9/64 INCH	TATA spare parts
A8145000070	PVC INSERT	TATA spare parts
A8145000071	PVC SLEEVE 8MM BLACK FOR WIRING	TATA spare parts
A8145000072	PVC BEADING END	TATA spare parts
A8145000073	PVC SLEEVE 6MM BLACK FOR WIRING	TATA spare parts
A8145000074	PVC END BUSH 1IN BLACK	TATA spare parts
A8145000075	PVC HANDLE (BEST TYPE)	TATA spare parts
A8145000076	FIRST AID BOX 8IN PLASTIC	TATA spare parts
A8145000077	PVC HANDLE 2IN	TATA spare parts
A8145000078	PVC SLEEVE GOLDEN YELLOW COLOUR 22MM FO	TATA spare parts
A8145000079	RUBBER INSERT	TATA spare parts
A8145000080	BATTERY BOX GROMET	TATA spare parts
A8145000081	SOFT RUBBER 19 X 3 MM	TATA spare parts
A8145000082	WINDOW GLAZING RUBBER	TATA spare parts
A8145000083	NYLON KEY	TATA spare parts
A8145000084	RUBBER MAT 3MM	TATA spare parts
A8145000085	LIGHT COVER	TATA spare parts
A8145000086	KNOB TYPE SWING FAN 24VX8	TATA spare parts
A8145000087	PENCIL FUSE 30 AMP	TATA spare parts
A8145000088	LUG FOR 70 MM.SQ. BATT.CABLE.	TATA spare parts
A8145000089	FOOT STEP LIGHT	TATA spare parts
A8145000090	ENGINE LIGHT	TATA spare parts
A8145000091	STOP SWITCH PANEL MOUNTED	TATA spare parts
A8145000092	BELL BUZZER 24V	TATA spare parts
A8145000093	ROOF LAMP 212	TATA spare parts
A8145000094	BLINKER ORANGE	TATA spare parts

A8145000095	BLINKER WHITE	TATA spare parts
A8145000096	PARKING LIGHT RING	TATA spare parts
A8145000097	CUP HOLDER FOR HEADLAMP BULB	TATA spare parts
A8145000098	PARKING LIGHT CASTING	TATA spare parts
A8145000099	PIANO SWITCH 15 AMP (BLACK)	TATA spare parts
A8145000100	PNEUMATIC SWITCH (RED)	TATA spare parts
A8145000101	ON/OFF SWITCH	TATA spare parts
A8145000102	NYLON CONNECTOR BLACK 10 POLE	TATA spare parts
A8145000103	SWITCH 16 AMP	TATA spare parts
A8145000104	ROOF LAMP	TATA spare parts
A8145000105	NYLON CONNECTOR WHITE BIG 32 AMP 12 POLE	TATA spare parts
A8145000106	NYLON CONNECTOR BLACK 12 POLE	TATA spare parts
A8145000107	TUBE LIGHT 24V X 24IN TRANSPARENT	TATA spare parts
A8145000108	FRONT LED 15 ROWS X 140 COLUMNS	TATA spare parts
A8145000109	REAR & SIDE LED 15 ROWS X 96 COLUMNS	TATA spare parts
A8145000110	INTERNAL LED 16 ROWS X 144 COLUMNS	TATA spare parts
A8145000111	ANNOUNCEMENT UNIT AMPLIF & SPEAKER	TATA spare parts
A8145000112	MOULDED SEAT 865W WITH SL & AR RHS	TATA spare parts
A8145000113	MOULDED SEAT 865W WITH SL W/O AR RH	TATA spare parts
A8145000114	MOULDED SEAT 865W WITH SL W/O AR LH	TATA spare parts
A8145000115	MOULDED SEAT 1 SEATER WITH SL & AR LH	TATA spare parts
A8145000116	TWO SEATER CUSHION 381 X 813	TATA spare parts
A8145000117	TWO SEATER BACKREST 813 MM X 25 MM	TATA spare parts
A8145000118	TWO SEATER BACKREST 762 MM X 25 MM	TATA spare parts
A8145000119	BIG WINDOW ASSY - RHS	TATA spare parts
A8145000120	BIG WINDOW ASSY - LHS	TATA spare parts
A8145000121	BIG WINDOW ASSY BTM-FIX-TOP-SLD	TATA spare parts
A8145000122	BIG WINDOW ASSY-WITH COLLAR CUT	TATA spare parts
A8145000123	MEDIUM WINDOW WT STD FITMENTS - RHS	TATA spare parts
A8145000124	DRIVERS DOOR WINDOW ASSLY.	TATA spare parts
A8145000125	SMALL WINDOW ASSY - LHS	TATA spare parts
A8145000126	QUARTER GLASS WINDOW ASSY HORIZ SLD RHS	TATA spare parts
A8145000127	FRONT WINDSCREEN ASSY COMPLETE - RHS	TATA spare parts
A8145000128	FRONT WINDSCREEN ASSY COMPLETE - LHS	TATA spare parts
A8145000129	REAR EMERGENCY ASSY FIXED	TATA spare parts
A8145000130	REAR EMERGENCY ASSY FOLDING	TATA spare parts
A8145000131	WEATHER STRIP-CENTRE FEMALE	TATA spare parts
A8145000132	WEATHER STRIP-OUTER	TATA spare parts
A8145000133	TOWER BOLT NYLON GUIDE	TATA spare parts
A8145000134	ANGULAR PIVOT-TOP	TATA spare parts
A8145000135	PIVOT GUIDE-BOTTOM	TATA spare parts
A8145000136	WEATHER STRIP-CENTRE-MALE	TATA spare parts
A8145000137	DOOR FRAME SECTION-ALUMINIUM	TATA spare parts
A8145000138	BUTTERFLY FORGED HINGES	TATA spare parts
A8145000139	PVC COVER CAP-BLACK	TATA spare parts
A8145000140	NYLON ROLLER	TATA spare parts
A8145000141	TUBULAR HANDLE	TATA spare parts

A81450000142	NYLON ROLLER MOUNTING PIN -TOP	TATA spare parts
A81450000143	PIVOT GUIDE -TOP	TATA spare parts
A81450000144	PIVOT PIN-BOTTOM	TATA spare parts
A81450000145	ALUMINIUM HANDLE	TATA spare parts
A81450000146	SWING PIN-BOTTOM	TATA spare parts
A81450000147	ANTI RATTLING DISC	TATA spare parts
A81450000148	RUBBER GLAZING-DOOR GLASS MOUNTING	TATA spare parts
A81450000149	TOWER BOLT(SIZE:380MM LG)	TATA spare parts
A81450000150	DUST EXCLUDER HOLDING PANEL	TATA spare parts
A81450000151	DUST EXCLUDER RUBBER	TATA spare parts
A81450000152	DOOR STOPPER PLATE-TOP	TATA spare parts
A81450000153	P.V.C HANDLE	TATA spare parts
A81450000154	PVC KEY	TATA spare parts
A81450000155	MEIDUM WINDOW ASSY FOR DRIVERS DOOR RHS	TATA spare parts
A81450000156	MS HINGES 65MM	TATA spare parts
A81450000157	DOOR DISK	TATA spare parts
A81450000158	NON-LOCKING HANDLE	TATA spare parts
A81450000159	PVC HANDLE	TATA spare parts
A81450000160	LOCK STRIKER PLATE	TATA spare parts
A81450000161	DOVE TAIL MALE - NYLON	TATA spare parts
A81450000162	DOVE TAIL FEMALE - NYLON	TATA spare parts
A81450000163	RAILWAY LOCK	TATA spare parts
A81450000164	DOOR COCK BRAND LOCK-RHS	TATA spare parts
A81450000165	DESTINATION BOARD FLAP COMPLETE	TATA spare parts
A81450000166	D. B. LOCK	TATA spare parts
A81450000167	BUTT HINGE	TATA spare parts
A81450000168	BRASS HANDLE	TATA spare parts
A81450000169	BUDGET LOCK	TATA spare parts
A81450000170	AIR BELLOW FLAP	TATA spare parts
A81450000171	FLAP HINGE	TATA spare parts
A81450000172	CNG FLAP	TATA spare parts
A81450000173	RAILWAY TYPE LOCK	TATA spare parts
AA30011	REAR HUB DRUM REMOVE WRENCH	TATA spare parts
AA30041	REAR HUB BEARING INSTALLER	TATA spare parts
AA30051	FRONT HUB DRUM INSTALLER	TATA spare parts
AA30061	REAR HUB DRUM OIL SEAL INSTALLER	TATA spare parts
AA30071	FRONT AXLE DRUM BREARING CAP INSTALLER	TATA spare parts
AA30072	KING PIN BEARING REMOVER / INSTALLER	TATA spare parts
AA30091	FRONT HUB REMOVER	TATA spare parts
AAI0001017	MAIN SHAFT BEARING PULLER	TATA spare parts
AAI0001018	IDLE SHAFT PULLER-8 11 15TON	TATA spare parts
AAI0001019	COUNTER SHAFT BEARING PULLER	TATA spare parts
AAI0001042	3RD COLLAR REMOVE PULLER	TATA spare parts
AAI0001043	GEAR PULLER	TATA spare parts
AAI0001044	PILOT BEARING PULLER	TATA spare parts
AAI0001055	4 5TH HUB CLUTCH PULLER	TATA spare parts
AK04030SS	HOSE	TATA spare parts

AK4030SS	VACCUME HOSE FROM OVERSPEED SOLENOID TO	TATA spare parts
ALBAPFSHIRT32	CRO FEMALE SHIRT 32"	TATA spare parts
ALBAPFSHIRT34	CRO FEMALE SHIRT 34"	TATA spare parts
ALBAPFSHIRT36	CRO FEMALE SHIRT 36"	TATA spare parts
ALBAPFSHIRT38	CRO FEMALE SHIRT 38"	TATA spare parts
ALBAPFSHIRT40	CRO FEMALE SHIRT 40"	TATA spare parts
ALBAPFSHIRT42	CRO FEMALE SHIRT 42"	TATA spare parts
ALBAPFTROSUER26	CRO FEMALE JEGGING 26"	TATA spare parts
ALBAPFTROSUER28	CRO FEMALE JEGGING 28"	TATA spare parts
ALBAPFTROSUER30	CRO FEMALE JEGGING 30"	TATA spare parts
ALBAPFTROSUER32	CRO FEMALE JEGGING 32"	TATA spare parts
ALBAPFTROSUER34	CRO FEMALE JEGGING 34"	TATA spare parts
ALBAPFTROSUER36	CRO FEMALE JEGGING 36"	TATA spare parts
ALBAPJEAN0028	Cargo Jeans waist 28 inches	TATA spare parts
ALBAPJEAN0030	Cargo Jeans waist 30 inches	TATA spare parts
ALBAPJEAN0032	Cargo Jeans waist 32 inches	TATA spare parts
ALBAPJEAN0034	Cargo Jeans waist 34 inches	TATA spare parts
ALBAPJEAN0036	Cargo Jeans waist 36 inches	TATA spare parts
ALBAPJEAN0038	Cargo Jeans waist 38 inches	TATA spare parts
ALBAPJEAN0040	Cargo Jeans waist 40 inches	TATA spare parts
ALBAPRAINWEAR0L	WORKSHOP RAINWEAR SIZE L	TATA spare parts
ALBAPRAINWEAR0XL	WORKSHOP RAINWEAR SIZE XL	TATA spare parts
ALBAPRAINWEAR0XXL	WORKSHOP RAINWEAR SIZE XXL	TATA spare parts
ALBAPSWEATER34	SWEATER 34"	TATA spare parts
ALBAPSWEATER36	SWEATER 36"	TATA spare parts
ALBAPSWEATER38	SWEATER 38 "	TATA spare parts
ALBAPSWEATER40	SWEATER 40"	TATA spare parts
ALBAPSWEATER42	SWEATER 42"	TATA spare parts
ALBAPSWEATER44	SWEATER 44"	TATA spare parts
ALBAPTSHIRT0036	T-SHIRT 36 INCHES	TATA spare parts
ALBAPTSHIRT0038	T-SHIRT 38 INCHES	TATA spare parts
ALBAPTSHIRT0040	T-SHIRT 40 INCHES	TATA spare parts
ALBAPTSHIRT0042	T-SHIRT 42 INCHES	TATA spare parts
ALBAPTSHIRT0044	T-SHIRT 44 INCHES	TATA spare parts
ALBAPWHSHIRT0036	SERVICE ADVISOTR FULL SLEEVE SHIRT 36"	TATA spare parts
ALBAPWHSHIRT0038	SERVICE ADVISOTR FULL SLEEVE SHIRT 38"	TATA spare parts
ALBAPWHSHIRT0040	SERVICE ADVISOTR FULL SLEEVE SHIRT 40"	TATA spare parts
ALBAPWHSHIRT0042	SERVICE ADVISOTR FULL SLEEVE SHIRT 42"	TATA spare parts
ALBAPWHSHIRT0044	SERVICE ADVISOTR FULL SLEEVE SHIRT 44"	TATA spare parts
ALBATWHSHIRT0036	WORKS MANAGER SHIRT 36 INCHES	TATA spare parts
ALBATWHSHIRT0038	WORKS MANAGER SHIRT 38 INCHES	TATA spare parts
ALBATWHSHIRT0040	WORKS MANAGER SHIRT 40 INCHES	TATA spare parts
ALBATWHSHIRT0042	WORKS MANAGER SHIRT 42 INCHES	TATA spare parts
ALBATWHSHIRT0044	WORKS MANAGER SHIRT 44 INCHES	TATA spare parts
ALMAZ-01-CL-13	SMT/SME FOR CIL ENGINE	TATA spare parts
ALMAZ-02-ET-13	SMT/SME FOR EATON GEAR BOX	TATA spare parts
ALMAZ-03-CL-13	MRLS FOR CIL ENGINE	TATA spare parts

ALMAZ-04-DL-13	SMT/SME FOR AXLE	TATA spare parts
ALMAZ-05-CL-13	MFR RECOM LIST OF SPARES FOR ENGINE	TATA spare parts
ALMAZ-06-ZF-13	SPL MAINT TOOLS/EQUIP FOR AUX GEAR BOX	TATA spare parts
ALMAZ-07-ET-13	SPL MAINT TOOLS/EQUIP FOR GEAR BOX	TATA spare parts
AMC027L00400	Refrigerant R134a (027-L004-00)	TATA spare parts
AMC027L00600	Compressor Oil (027-L006-00)	TATA spare parts
AMC027L00700	Cleaning Agent for Coils (027-L007-00)	TATA spare parts
AMC215754100101	12V 150AH Battery NMMT (AMC)	TATA spare parts
AMC278054300101	Telematics kit for AMC inclu Fittment	TATA spare parts
AMC409078100101G	TOP COAT(Green)	TATA spare parts
AMC409078100101R	TOP COAT(Red)	TATA spare parts
AMC409078100102	HARDNER FOR TOP COAT	TATA spare parts
AMC409078100107	MATT BLACK PAINT	TATA spare parts
AMC409078200103	PRIMER SURAFACER	TATA spare parts
AMC409078200109	STRUCTURAL PRIMER	TATA spare parts
AMC409078200110	STRUCTURAL PR HARDNER	TATA spare parts
AMC409078300102	DEGREASER	TATA spare parts
AMC409078300104	THINNER	TATA spare parts
AMC409078400101	PUTTY	TATA spare parts
AMC55120860321	LONG LIFE COOLANT INDROL (AMC)	TATA spare parts
AMC55130860159	HYD BR FLUID HD IS8654 205 TS2 (AMC)	TATA spare parts
AMC55130860264	POWER STEERING OIL ATF DEXRON (AMC)	TATA spare parts
AMC55140860025	BALMEROL Synthetic Grease (AMC)	TATA spare parts
AMC885859004701	Telematics kit for AMC inclu Fittment	TATA spare parts
AMCA0019890351	LUBRICATING GREASE (AMC)	TATA spare parts
AMCBPMACOILSS75W85	MAC SPIROL SYNTH 75W85 (AMC)	TATA spare parts
AMCCASTCNGRX	Castrol RX CNG 15W40 (AMC)	TATA spare parts
AMCCASTOILSS75W85	CASTROL OIL SYNTRO S 75W85 (AMC)	TATA spare parts
AMCCNGSUPERGAS	Castrol RX SUPER GAS (AMC)	TATA spare parts
AMCDISTWATER1501	Distilled Water for AMC (Coolant filling)	TATA spare parts
AMCHYSPINEP68	Hydraulic Oil (AMC)	TATA spare parts
AMCOILBPMAC80WEP	MAK TATA MOTORS SPIROL 80WEP (AMC)	TATA spare parts
AMCOILCASTBRKFDOT4	CASTROL BRAKE FLUID UBF DOT 4	TATA spare parts
AMCOILCASTRX15W40	CASTROL RX TURBO TC 15W40 (CI4) (AMC)	TATA spare parts
AMCOILCASTTR80WEP	EXTREME PRESSURE 80EP (AMC)	TATA spare parts
AMCOILCATRXST15W40	CAST RX SUP TUR CI4+ 15W40 (AMC 16L PACK)	TATA spare parts
AMCOILDIFFL85W	Castrol Extra Long Life Rear A (AMC)	TATA spare parts
AMCOILDIFFL85W3	OILDIFFL85W3 (DIFFERENTIAL O (AMC)	TATA spare parts
AMCOILENBP15W40	MAK Tata Motors Genuine CH4 15 (AMC)	TATA spare parts
AMCOILENCAST15W40	Castrol RX Turbo 15 W 40 (CH4) (AMC)	TATA spare parts
AMCOILENG15W40	MAK Tata Motors Genuine engine (AMC)	TATA spare parts
AMCOILENVALV15W40	Valvoline premium blue 15W40 (AMC)	TATA spare parts
AMCOILGEARLL80W90	Castrol Extra Long Life Gear O (AMC)	TATA spare parts
AMCOILGEARLL80W90T	MAK Tata Motors Spirol LL 80W9 (AMC)	TATA spare parts
AMCOILGRCAST75W90	Castrol Synthetic 75W90 Transaxle Oil (AMC)	TATA spare parts
AMCOILGRSERV80W90	Servo Synchro TM (AMC)	TATA spare parts
AMCOILMAKCI415W40	MAK TATA MOTORS CI4 PLUS 15W40 (AMC)	TATA spare parts

AMCOILRASERV85W140	Servo Gear Axle TM (AMC)	TATA spare parts
AMCOILRXSUPERMAX	Castrol RX Supermax 15W40(CF4) (AMC)	TATA spare parts
AMCOILSERV80W140LL	IOCL Long life RA Oil IOCL	TATA spare parts
AMCOILSERVO80W90LL	IOCL Long life gear Oil IOCL	TATA spare parts
AMCOILSHELREM15W40	SHELL RIMULA T4 15W40 CI4 PLUS (AMC)	TATA spare parts
AMCOILSHELT215W40	SHELL RIMULA T2 15W40 (CF4) (AMC)	TATA spare parts
AMCOILSHELT315W40	SHELL RIMULA T3 15W40 (CH4) (AMC)	TATA spare parts
AMCOILSHELX80W90	SHELL SPIRAXT2 G 80W90 (AMC)	TATA spare parts
AMCOILSHELX85W140	SHELL SPIRAXT2 A 85W140 (AMC)	TATA spare parts
AMCOILSPIR80W140XL	MAK TM SPIROL XL 80W140 BPCL	TATA spare parts
AMCOILSPIRO80W90XL	MAK TM SPIROL XL 80W90 BPCL	TATA spare parts
AMCTRANSYND	TRANSMISSION OIL (AMC)	TATA spare parts
ANAB202	Anabond 202 (3 gm)	TATA spare parts
ANAB669RTV	Anabond 669T - RTV Silicones	TATA spare parts
ANAB7702T	Anabond 7702T - PU Sealant	TATA spare parts
ANABAQUB510T	Aquabond 510T Putty	TATA spare parts
ANABBEARET402	Bearing Retainer - 402 (4 ml)	TATA spare parts
ANABCCP05T	Anabond CCP-05T	TATA spare parts
ANABEPOXYPUTTY	Anabond Epoxy Putty - Steel Filled (58 gm)	TATA spare parts
ANABFCPUTTY	Anaseal FC Putty (25 gm)	TATA spare parts
ANABGASKMAK676	Anabond Gasket Maker - 676 (85 gm)	TATA spare parts
ANABGASKREMOPR50AT	Anabond Gasket Remover PR 50AT	TATA spare parts
ANABMASBON101T	Anabond Master Bond 101T (100 ml)	TATA spare parts
ANABNEVESEC975T	Anabond Nevezeiz C 975T	TATA spare parts
ANABOKTFOAM	Anabond OK - T Foam	TATA spare parts
ANABTHLOCK111FC	Thread Locker - 111FC (4 ml)	TATA spare parts
ANABV11TRPT	Anabond V11T Rust Penetrant	TATA spare parts
AR3815585	DRIVE DISTRIBUTOR	TATA spare parts
AS0401000SS	HOSE	TATA spare parts
AS0403200SC	HOSE	TATA spare parts
AS0502400SS	HOSE FLEXIBLE	TATA spare parts
AS0511600SS	HOSE	TATA spare parts
AS0513000SS	HOSE	TATA spare parts
AS1001200SS	HOSE FLEXIBLE	TATA spare parts
AS1001500SS	HOSE FLEXIBLE	TATA spare parts
AS1002000SS	HOSE	TATA spare parts
AS1604700SS	HOSE FOR GAS ID 25.4MM X 47 INCH LONG	TATA spare parts
AS1612000SS	HOSE	TATA spare parts
AS164700SS	HOSE FOR GAS ID 25.4MM X 47 INCH LONG	TATA spare parts
AS401000SS	HOSE	TATA spare parts
AS40100SS	HOSE-1510 CNG	TATA spare parts
AS403200SC	HOSE-1510 CNG	TATA spare parts
AS502400SS	HOSE-1510 CNG	TATA spare parts
AT72856	AUTO SLACK ADJUSTER-FRT	TATA spare parts
AT72857	AUTO SLACK ADJUSTER-FRT	TATA spare parts
AT72858	AUTOSLACK ADJUSTER-RR	TATA spare parts
ATIN 1247	ADAPTER & RING GEAR ASSY	TATA spare parts

AX1005300	Insite Pro with registration	TATA spare parts
AX1012840	BOX BREAK-OUT	TATA spare parts
AX1012841	Kit L-Series Communication Interface	TATA spare parts
AZ9100340065	AUTOMATIC GAP ADJUSTING (RIGHT)	TATA spare parts
AZ9100340066	AUTOMATIC GAP ADJUSTING (LEFT)	TATA spare parts
AZ9100368303	DIAPHRAGM SPRING BRAKE CHAMBER	TATA spare parts
AZ9100369303	DIAPHRAGM SPRING BRAKE CHAMBER	TATA spare parts
AZ9112320153	DIFFERENTIAL CASE WASHER	TATA spare parts
AZ911430178	OIL BAFFLE ASSEMBLY	TATA spare parts
AZ9114320002	CAULKING COWL	TATA spare parts
B-14202	MAIN PIVOT BUSH	TATA spare parts
B-14495	WEARPAD	TATA spare parts
B-3836-C-263X	SHIELD DUST ASSY - RH	TATA spare parts
B06400000001	MAJOR REPAIR KIT ALUMINIUM MASTER CYLIND	TATA spare parts
B06400000002	MINOR REPAIR KIT ALUMINIUM MASTER CYLIND	TATA spare parts
B07570000001	FRONT INDICATOR LIGHT	TATA spare parts
B07570000002	HEAD LIGHT WITHOUT PARKING LH	TATA spare parts
B07570000003	HEAD LIGHT WITHOUT PARKING RH	TATA spare parts
B07570000004	HEAD LIGHT WITH PARKING LH	TATA spare parts
B07570000005	HEAD LIGHT WITH PARKING RH	TATA spare parts
B07570000006	FIRST AID BOX	TATA spare parts
B07570000007	HAND STRIPE	TATA spare parts
B07570000008	BELL SWITCH ( STOP SWITCH)	TATA spare parts
B07570000009	SPEAKER COVER	TATA spare parts
B07570000010	EMERGENCY GLASS BREAKING HAMMER	TATA spare parts
B07570000011	REAR LUGGAGE COMPARTMENT LOCK	TATA spare parts
B07570000012	DICKY LIGHT	TATA spare parts
B07570000013	REAR VIEW MIRROR WITHOUT PAINTED	TATA spare parts
B07570000014	SIDE MARKER LAMP	TATA spare parts
B07570000015	FRONT WINDSHIELD	TATA spare parts
B07570000016	REAR WIND SHIELD	TATA spare parts
B07570000017	PVC HANDLE	TATA spare parts
B07570000018	LOCK	TATA spare parts
B07570000019	WHEEL CAP REAR	TATA spare parts
B07570000020	WHEEL CAP FRONT	TATA spare parts
B07570000021	WIPER MOTOR WITH BLADE	TATA spare parts
B07570000022	FRONT SHOW WITHOUT PAINTED	TATA spare parts
B07570000023	REAR DICKY WITHOUT PAINTED	TATA spare parts
B07570000024	SKIRT PANEL LH 1	TATA spare parts
B07570000025	SKIRT PANEL LH 2	TATA spare parts
B07570000026	SKIRT PANEL LH 3	TATA spare parts
B07570000027	SKIRT PANEL LH 4	TATA spare parts
B07570000028	SKIRT PANEL LH 5	TATA spare parts
B07570000029	SKIRT PANEL LH 6	TATA spare parts
B07570000030	SKIRT PANEL LH 7	TATA spare parts
B07570000031	SKIRT PANEL LH 8	TATA spare parts
B07570000032	SKIRT PANEL RH 1	TATA spare parts

B07570000033	SKIRT PANEL RH 2	TATA spare parts
B07570000034	SKIRT PANEL RH 3	TATA spare parts
B07570000035	SKIRT PANEL RH 4	TATA spare parts
B07570000036	SKIRT PANEL RH 5	TATA spare parts
B07570000037	SKIRT PANEL RH 6	TATA spare parts
B07570000038	SKIRT PANEL RH 7	TATA spare parts
B07570000039	1/4IN -3/2IN PUSH VALVE WITH FITTING	TATA spare parts
B07570000040	1/4IN -5/2 24V DC DOUBLE PILOT VALVE	TATA spare parts
B07570000041	63X125 CYL. MALE CLEVIS	TATA spare parts
B07570000042	MALE ELBOW DIA 6X1/4IN	TATA spare parts
B07570000043	FLOW CONTROL VALVE 1/4IN X DIA 6	TATA spare parts
B07570000044	TUBE PU O.D. 6 MM BLUE	TATA spare parts
B07570000045	NJSC	TATA spare parts
B07570000046	VALVE	TATA spare parts
B07570000047	OLONIDE VALVE	TATA spare parts
B07570000048	TUBE PU O.D. 8 MM BLUE	TATA spare parts
B07570000049	COCK VALVE	TATA spare parts
B07570000050	INLINE FILTER	TATA spare parts
B07570000051	AIR CYLINDER 63MMX125MM	TATA spare parts
B07570000052	DRIVER SEAT	TATA spare parts
B07570000053	J K DOOR GLASS	TATA spare parts
B07570000054	J K DOOR GLASS ( TAPER )	TATA spare parts
B07570000055	WINDOW ASSY.	TATA spare parts
B07570000056	WINDOW FIX GLASS	TATA spare parts
B07570000057	WINDOW GLASS	TATA spare parts
B07570000058	EMERGENCY WINDOW GLASS	TATA spare parts
B07570000059	FRONT FLAP WITH GRILL	TATA spare parts
B07570000060	FRONT BUMPER	TATA spare parts
B07570000061	REAR SHOW	TATA spare parts
B07570000062	REAR DICKY	TATA spare parts
B07570000063	FRONT FLAP	TATA spare parts
B07570000064	FOOT STEP LIGHT	TATA spare parts
B07570000065	INNER REAR VIEW MIRROR	TATA spare parts
B07570000066	SUNVISOR LHD	TATA spare parts
B07570000067	CFL TUBE LIGHT ( ROOF )	TATA spare parts
B07570000068	TAIL LAMP LH ( AMBER COLOUR )	TATA spare parts
B07570000069	TAIL LAMP RH ( AMBER COLOUR )	TATA spare parts
B07570000070	TAIL LAMP LH ( RED COLOUR )	TATA spare parts
B07570000071	TAIL LAMP RH ( RED COLOUR )	TATA spare parts
B07570000072	TAIL LAMP LH ( CLEAR )	TATA spare parts
B07570000073	TAIL LAMP RH ( CLEAR )	TATA spare parts
B07570000074	REAR NUMBER PLATE LIGHT	TATA spare parts
B07570000075	DRIVER DOOR HANDLE	TATA spare parts
B07570000076	HEIGHT MARKER LAMP FRONT ( CLEAR )	TATA spare parts
B07570000077	HEIGHT MARKER LAMP REAR ( RED )	TATA spare parts
B07570000078	DRIVER DOOR LOCK	TATA spare parts
B64480000001	FAN 28 INCH BUS	TATA spare parts



B6491000001	LIGHT BAR	TATA spare parts
B6491000002	FIRE BELL	TATA spare parts
B6491000003	EXTENSION LADDER 10.5 M	TATA spare parts
B6491000004	HOSE REEL ASSEMBLY	TATA spare parts
B6491000005	MONITOR ASSEMBLY	TATA spare parts
B6491000006	SUCTION HOSE	TATA spare parts
B6491000007	SEARCH LIGHT	TATA spare parts
B6491000008	HEAT EXCHANGER	TATA spare parts
B6491000009	PUMP SHAFT S.S	TATA spare parts
B6491000010	BEARING ANGULAR	TATA spare parts
B6491000011	O' RING 37*1.5	TATA spare parts
B6491000012	O' RING 110*3MM	TATA spare parts
B6491000013	OIL SEAL 60*80*8MM	TATA spare parts
B6491000014	WEAR RING OIL SEAL	TATA spare parts
B6491000015	OIL SEAL 50*22*8MM	TATA spare parts
B6491000016	SEAL HOUSING	TATA spare parts
B6491000017	DRIVE FLANGE	TATA spare parts
B6491000018	O' RING 43*2MM	TATA spare parts
B6491000019	SEAL WEAR RING	TATA spare parts
B6491000020	O' RING 18*2.5MM	TATA spare parts
B6491000021	WASHER SEALING 19MM	TATA spare parts
B6491000022	MECHANICAL SEAL ASSEMBLY	TATA spare parts
B6491000023	NECK RING	TATA spare parts
B6491000024	STRAINER WATER FILLING 450MM S.S	TATA spare parts
B6491000025	WASHER PLAIN 10MM S.S	TATA spare parts
B6491000026	GASKET COMPRESSED ASBESTOS 3MM THICK	TATA spare parts
B6491000027	NUT NYLON LOCK M-10S.S	TATA spare parts
B6491000028	WASHER PLAIN 10MM S.S	TATA spare parts
B6491000029	BOLT HEX. HD M-16*70 M.S GAL	TATA spare parts
B6491000030	CAP FILLER OPENING TANK FOAM SS	TATA spare parts
B6491000031	PACKING RUBBER 450 ID*5MM THICK	TATA spare parts
B6491000032	PIN LOCK 10MM SS	TATA spare parts
B6491000033	VALVE BREATHER VALVE M.S	TATA spare parts
B6491000034	TOP DISH FUNNEL SS 304	TATA spare parts
B6491000035	SHUTTER ASSEMBLY COMPLETE	TATA spare parts
B6491000036	U' CHANNEL AL	TATA spare parts
B6491000037	PIPE ROLLER 32 NB GI	TATA spare parts
B6491000038	RING SEALING TORODIAL 60*3 RUBBER	TATA spare parts
B6491000039	COLLECTING TEE AI.	TATA spare parts
B6491000040	NOZZLE AI.	TATA spare parts
B6491000041	RECEIVER NOZZLE G.M	TATA spare parts
B6491000042	HOUSING NOZZLE G.M	TATA spare parts
B6491000043	PLUG SSREWED SEALING RING	TATA spare parts
B6491000044	FLANGE PIPE 50MM ID CI	TATA spare parts
B6491000045	GASKET COMPRESSED ASBESTOS	TATA spare parts
B6491000046	LEVER COMPLETE	TATA spare parts
B6491000047	LEVER SPINDLE S.S	TATA spare parts

B6491000048	LEVER COMPLETE	TATA spare parts
B6491000049	HOUSING	TATA spare parts
B6491000050	VALVE DELIVERY SCREW DOWN SPOT	TATA spare parts
B6491000051	CAP PROTECTIVE MALE INSTANTANEOUS	TATA spare parts
B6491000052	CHAIN PROTECTIVE CAP	TATA spare parts
B6491000053	SEAT VALVE	TATA spare parts
B6491000054	DISC VALVE METALLIC G.M	TATA spare parts
B6491000055	WHEEL HAND G.M 80MM	TATA spare parts
B6491000056	BRACKET M.S TO GUIDE TO ALLOW MOVEMENT	TATA spare parts
B6491000057	CASING PROTECTIVE MATERIAL WIRE BRADED R	TATA spare parts
B6491000058	BOLT HEX. HD STEEL SIZE 8*25MM	TATA spare parts
B6491000059	O' RING 80*4	TATA spare parts
B6491000060	O' RING 85*4	TATA spare parts
B6491000061	PIPE FLANGE SECTION 100 NB SS 304	TATA spare parts
B6491000062	GASKET COMPRESSED ASBESTOS 3MM	TATA spare parts
B6491000063	CAP PROTECTIVE SUCTION MOUTH GM.	TATA spare parts
B6491000064	GASKET COMPRESSED ASBESTOS 3MM	TATA spare parts
B6491000065	ELBOW 75 NB GI	TATA spare parts
B6491000066	VALVE BALL 15 NB SS	TATA spare parts
B6491000067	SOCKET 15 NB GI	TATA spare parts
B6491000068	ADOPTOR 15MM	TATA spare parts
B6491000069	VALVE BALL 3 WAY SS	TATA spare parts
B6491000070	LEVEL INDICATOR ACRYLIC TUBING	TATA spare parts
B6491000071	COVER FOR FOAM LEVEL INDICATOR AI.	TATA spare parts
B6491000072	PLUG BREATHER NYLON FOR LEVEL INDICATOR	TATA spare parts
B6491000073	GASKET COMPRESSED ASBESTOS 3MM	TATA spare parts
B6491000074	GASKET COMPRESSED ASBESTOS 3MM	TATA spare parts
B6491000075	VALVE BALL 25 NB SS	TATA spare parts
B6491000076	GASKET COMPRESSED ASBESTOS 3MM	TATA spare parts
B6491000077	GASKET COMPRESSED ASBESTOS 3MM	TATA spare parts
B6491000078	VALVE BALL 40 NB SS	TATA spare parts
B6491000079	ELBOW 25 NB SS	TATA spare parts
B6491000080	VALVE BALL 15 NB SS	TATA spare parts
B6491000081	HOSE RUBBER 15MM	TATA spare parts
B6491000082	GASKET COMPRESSED ASBESTOS 3MM THICK	TATA spare parts
B6491000083	NON RETURN VALVE 25 NB SS	TATA spare parts
B6491000084	VALVE BALL 65NB SS	TATA spare parts
B6491000085	GASKET COMPRESSED ASBESTOS 3MM THICK	TATA spare parts
B6491000086	SLEVE 25M GM	TATA spare parts
B6491000087	HOSE RUBBER 25MM	TATA spare parts
B6491000088	GASKET COMPRESSED ASBESTOS 3MM THICK	TATA spare parts
B6491000089	VALVE BALL 50 NB SS	TATA spare parts
B6491000090	PIPE ONE END FLANGED 50 NB SS	TATA spare parts
B6491000091	VALVE BALL 50 NB SS	TATA spare parts
B6491000092	VALVE BALL 15 NB SS	TATA spare parts
B6491000093	NIPPLE HEX. 15MM GM	TATA spare parts
B6491000094	HOSE RUBBER 15MM	TATA spare parts

B6491000095	SWITCH PNEUMATIC	TATA spare parts
B6491000096	ELBOW MALE CONNECTOR	TATA spare parts
B6491000097	HOSE PNEUMATIC 6MM*20 METER	TATA spare parts
B6491000098	BEARING INTERMEDIATE	TATA spare parts
B6491000099	LOCKER/CABIN LIGHT	TATA spare parts
B6491000100	CONTROL PANEL LIGHT	TATA spare parts
B6491000101	GLASS FRONT DOOR SLINDING	TATA spare parts
B6491000102	GLASS REAR DOOR SLINDING	TATA spare parts
B6491000103	GLASS CABIN	TATA spare parts
B6491000104	GLASS FRONT DOOR FIXED	TATA spare parts
B6491000105	SEAL HOUSING	TATA spare parts
B6491000106	SUCTION HOSE BRACKET	TATA spare parts
B6491000107	PUMP CENTRIFUGAL	TATA spare parts
BD000000016401	SUPPORT RH	TATA spare parts
BD0000000211	BRACKET LH	TATA spare parts
BD000000021301	SUPPT. REAR MTG	TATA spare parts
BD000000021313	SPACER	TATA spare parts
BD000000032301	ANGLE SUPPT LH	TATA spare parts
BPMACOILSS75W85	MAC Spirol Synth 75W85	TATA spare parts
BPUSH2	ROUNDED BOX SWITCH	TATA spare parts
BRET13	ENGINE FLASHING BD	TATA spare parts
BS25C02250275	SEALING WASHER 22.5X27.5	TATA spare parts
BS25C02730319	SEALING WASHER 27.3X31.9	TATA spare parts
C04400000001	HARNESS WIRING	TATA spare parts
C04400000002	MOTOR STARTING	TATA spare parts
C04400000005	6.2 CALIBRATION FLEET REG	TATA spare parts
C1-3121-P-C302	HOUSING ASSY REAR FWD (4923)	TATA spare parts
C66610000001	TURBOCHARGER 180HP BUS APPLICATION	TATA spare parts
C66990000001	KIBES 32 RUNTIME SOFTWARE WITH DONGLE	TATA spare parts
C66990000002	K-LINE ADAPTER	TATA spare parts
C70/69AM/5	ROTARY CONTROL VALVE (SINGLE TYPE)	TATA spare parts
C75750000001	VINYLDECALS FOR CITY RIDE BUS	TATA spare parts
C80990000001	HOSE FLEXIBLE	TATA spare parts
C80990000002	SPARK PLUG	TATA spare parts
C80990000003	TURBOCHARGER	TATA spare parts
C80990000004	HOSE PLAIN TURBO COOLANT	TATA spare parts
C80990000005	HOSE PLAIN TURBO COOLANT	TATA spare parts
C80990000006	HOSE PLAIN COMPRESSOR COOLANT	TATA spare parts
C80990000012	HOSE PLAIN 1100 MM	TATA spare parts
C80990000013	CLAMP HOSE	TATA spare parts
CA21011	MAIN SHAFT BEARING PULLER	TATA spare parts
CA21021	IDLE SHAFT PULLER-8 11 15TON	TATA spare parts
CA21031	COUNTER SHAFT BEARING PULLER	TATA spare parts
CA21041	3RD COLLAR REMOVE PULLER	TATA spare parts
CA21071	CLUTCH CLEARANCE CHECKER	TATA spare parts
CA21101	GEAR PULLER	TATA spare parts
CA21111	4 5TH HUB CLUTCH PULLER	TATA spare parts

CA21121	PILOT BEARING PULLER	TATA spare parts
CA30011	DRUM PULLER	TATA spare parts
CA30021	REAR HUB BEARING NUT PULLER	TATA spare parts
CA30031	FRONT HUB BEARING NUT PULLER	TATA spare parts
CA31011	STEERING WHEEL PULLER	TATA spare parts
CA80021	TOE-IN CHECK ADAPTER	TATA spare parts
CASTOILSS75W85	Castrol Oil Syntro S 75W85	TATA spare parts
CBS6932	LONG BLOCK-INLINE FIP TYPE	TATA spare parts
CBS6932LA	LONG BLOCK INLINE FIP	TATA spare parts
CBS6933	INLINE FIP LONG BLOCK 210HP	TATA spare parts
CBS6933LA	LONG BLOCK-4021	TATA spare parts
CD0000000076	DOUBLE LEVER	TATA spare parts
COLNTGC2200NP	GOLDEN CRUISER 2200NP LONG LIFE COOLANT	TATA spare parts
CSFBG540CV	COOLING SYSTEM FLUSH	TATA spare parts
CWTSK1032	CABIN CONTROL VALVE	TATA spare parts
CWX155300001	POLYEURATHANE TUBE 15M	TATA spare parts
CWX167160000	PUMP-PTO ASSY	TATA spare parts
CWX181180001	ADAPTOR (M 22X1.5/M 26X1.5)	TATA spare parts
D-01-4038S-14	Prima Racing 4038.S -Misc parts	TATA spare parts
D-01-4038S-15	Prima Racing 4038.S -Misc parts	TATA spare parts
D-02-4038S-14	Prima Racing 4038.S -Tools	TATA spare parts
D-02-4038S-15	Prima Racing 4038.S -Tools	TATA spare parts
D-03-4038S-14	PRIMA RACING 4038.S TOOLS KIT 2	TATA spare parts
DCBG229CV	DIESEL CARE	TATA spare parts
DCRP24	DOOR CLOSER REPAIR KIT 24 VOLTS	TATA spare parts
DISBG255CV	DIESEL INDUCTION SYSTEM CLEANER	TATA spare parts
DMX-11-0604	SCREW M6X15 SKT HD SET	TATA spare parts
DNS		TATA spare parts
DTCA0019890351	LUBRICATING GREASE (for DTC)	TATA spare parts
DTCOILDIFLL85W	Castrol Extra Long Life Rear Axle Oil 85 (for DTC)	TATA spare parts
DZ9100340017	BUSH	TATA spare parts
DZ9100410104	WHEEL BOLT	TATA spare parts
DZ9112340056	BRAKE CAMSHAFT (LEFT) (ABS BRAKE)	TATA spare parts
DZ9112340057	BRAKE CAMSHAFT (RIGHT) (ABS BRAKE)	TATA spare parts
DZ9114320011	HEX BOLT	TATA spare parts
DZ9114320111	HEX BOLT	TATA spare parts
E000737	CAMSHAFT	TATA spare parts
E000755	SPACER	TATA spare parts
E000772	PISTON ENGINE	TATA spare parts
E000896	FLYWHEEL-LPS4923-380D CL	TATA spare parts
E116309	GEAR ASSEMBLY LIFTING FIXTURE	TATA spare parts
E64970000001	BLOWER ASSY	TATA spare parts
E64970000002	SPEED CONTROLLER	TATA spare parts
E64970000003	CAB COMMAND	TATA spare parts
E64970000004	CONDENSOR MOTOR ASSLY	TATA spare parts
E64970000005	CYLINDRICAL TENSIONER	TATA spare parts
E64970000006	FAN BLADE CONDENSOR	TATA spare parts

E6497000007	CLUTCH BEARING LINING	TATA spare parts
E6497000008	DISCHARGE HOSE	TATA spare parts
E6497000009	SUCTION HOSE	TATA spare parts
E6497000010	EXPANSION VALVE	TATA spare parts
E6497000011	RUBBER MOUNT BLOCK	TATA spare parts
E6497000012	CLUTCH ASSLY 160	TATA spare parts
E6497000013	FILTER DRIER	TATA spare parts
E6497000014	LP SWITCH	TATA spare parts
E6497000015	HP SWITCH	TATA spare parts
E6497000016	FILTER FOAM PP115/20 015*17MM	TATA spare parts
E6497000017	FILTER FOAM PP130/5 021*175MM	TATA spare parts
E6497000018	FILTER FOAMPP 115/10 795*360MM	TATA spare parts
E6497000019	24 VDC RELAY	TATA spare parts
E6497000020	COMPRESSOR 560 CC	TATA spare parts
E6497000021	BELT COMPRESSOR	TATA spare parts
E6497000022	FUSE 125 AMPS	TATA spare parts
E6497000023	SHAFT SEAL	TATA spare parts
E9090001	WIND SHIELD GLASS LH (909)-FLAT TYPE	TATA spare parts
E9090002	WIND SHIELD GLASS RH (909)-FLAT TYPE	TATA spare parts
E9092108	DOOM LIGHT	TATA spare parts
E9159000001	ANNULUS	TATA spare parts
E9159000002	CIRCLIP M90	TATA spare parts
E9159000003	DETENT COVER	TATA spare parts
E9159000004	DOWEL	TATA spare parts
E9159000005	THRUST WASHER(PLANET GEAR)	TATA spare parts
E9159000006	SELECTOR FORK RANGE	TATA spare parts
E9159000007	PLATE LAYSHAFT BEARING	TATA spare parts
E9159000008	SCREW M12X60HEXFLGHD	TATA spare parts
E9159000009	REACTION PLATE	TATA spare parts
E9159000010	PLUG CORE OIL RESTRICTOR	TATA spare parts
E9159000011	CROSS SHAFT	TATA spare parts
E9159000012	CLUTCH HOUSING	TATA spare parts
E9159000013	PTO COVER	TATA spare parts
F002A0Z122	FUEL INJECTION PUMP-130HP	TATA spare parts
F002A0Z160	407 SFC FIP	TATA spare parts
F002A0Z161	407 LP FIP	TATA spare parts
F002A0Z169	709 LP FIP	TATA spare parts
F002A0Z170	709 SFC FIP	TATA spare parts
F002A0Z178	FIP VAC. BRAKE	TATA spare parts
F002A0Z198	FIP 697NA CMVR 2K (110 HP) LP1510 RHD	TATA spare parts
F002A0Z199	FIP 697NA CMVR 2K (130 HP) SK1613 RHD	TATA spare parts
F002A0Z243	ASSY. FUEL INJECTION PUMP BS1	TATA spare parts
F002A0Z288	ASSY. FIP 130PS 2800RPM LP613 CMVR BS1	TATA spare parts
F002A0Z289	FUEL INJECTION PUMP	TATA spare parts
F002A0Z297	FUEL INJ PUMP 145HP EUROI INLINE	TATA spare parts
F002A0Z298	ASSY. FUEL INJECTION PUMP 125HP BS1/3	TATA spare parts
F002A0Z298AE	FUEL PUMP 713	TATA spare parts

F002A0Z301	ASSY. FIP 160 HP 6BT BS1/3	TATA spare parts
F002A0Z305	ASSY FIP	TATA spare parts
F002A0Z328	FIP 110 EURO-II	TATA spare parts
F002A0Z375	ASSY FIP	TATA spare parts
F002A0Z384	FIP 30KVA	TATA spare parts
F002A0Z385	FIP 35 KVA	TATA spare parts
F002A0Z386	FIP 40 KVA CPCB ENG	TATA spare parts
F002A0Z387	FIP 45 KVA	TATA spare parts
F002A0Z388	FIP 50 KVA	TATA spare parts
F002A0Z389	FIP 62.5 KVA	TATA spare parts
F002A0Z426	ASSY FUEL INJECTION PUMP	TATA spare parts
F002A0Z428	ASSY FIP 697TC LPT2515EX	TATA spare parts
F002A10627	OVERFLOW VALVE	TATA spare parts
F002A20632	GOVERNOR COVER ASSY	TATA spare parts
F002A20868	CONTROL LEVER	TATA spare parts
F002A21302	GOVERNOR COVER	TATA spare parts
F002A50005	HOUSING WITH SHAFT SEALING RING-16	TATA spare parts
F002A50013	HAND PRIMING PUMP	TATA spare parts
F002A50023	PUMP FUEL TRANSFER	TATA spare parts
F002A50023AE	PUMP FUEL TRANSFER 715	TATA spare parts
F002A50025	ASSY. FEED PUMP(MECHANICAL) BS2/3	TATA spare parts
F002A50028	ASSY FEED PUMP MECHANICAL	TATA spare parts
F002AOZ122	FUEL INJECTION PUMP-130HP	TATA spare parts
F002AOZ160	ASSY FIP IN - LINE	TATA spare parts
F002AOZ161	ASSY FIP IN - LINE	TATA spare parts
F002AOZ169	ASSY FIP IN - LINE	TATA spare parts
F002AOZ178	ASSY FIP IN - LINE	TATA spare parts
F002AOZ198	FIP 697NA CMVR 2K (110 HP) LP1510 RHD	TATA spare parts
F002AOZ199	FIP 697NA CMVR 2K (130 HP) SK1613 RHD	TATA spare parts
F002AOZ243	FUEL INJECTION PUMP	TATA spare parts
F002AOZ289	FUEL INJECTION PUMP	TATA spare parts
F002AOZ297	FIP (PEAK TORQUE AT LOW RPM) 145 HP	TATA spare parts
F002AOZ298	FIP (PEAK TORQUE AT LOW RPM) 125 HP	TATA spare parts
F002AOZ305	ASSY FIP	TATA spare parts
F002AOZ428	ASSY FIP 697TC LPT2515EX	TATA spare parts
F002B10027	ELEMENT	TATA spare parts
F002B70030	DELIVERY VALVE	TATA spare parts
F002B700303	D'VALVE (NEW ENGINE)	TATA spare parts
F002C30104	INJECTION NOZZLE	TATA spare parts
F002C40008	NOZZLE	TATA spare parts
F002C40020	NOZZLE	TATA spare parts
F002C40023	NOZZLE	TATA spare parts
F002C40504	NOZZLE LPT 709E TURBO	TATA spare parts
F002C40507	NOZZLE SFC/LP 407 TC/CMVR2000	TATA spare parts
F002C40512	NOZZLE INJECTOR 160 HP EURO II	TATA spare parts
F002C40519	NOZZLE	TATA spare parts
F002C40527	NOZZLE 125HP BSII	TATA spare parts

F002C40528	NOZZLE 145 HP EURO II	TATA spare parts
F002C40529	NOZZLE 697NA CMVR 2K1510/1613	TATA spare parts
F002C40531	NOZZLE	TATA spare parts
F002C40544	NOZZLE	TATA spare parts
F002C40547	NOZZLE	TATA spare parts
F002C40559	NOZZLE 207DI EX BSII	TATA spare parts
F002C40565	NOZZLE	TATA spare parts
F002C40580	NOZZLE	TATA spare parts
F002C40620	NOZZLE	TATA spare parts
F002C40623	NOZZLE 145 HP BSII	TATA spare parts
F002C7Z006	INJECTOR TC BSIII	TATA spare parts
F002C7Z008	INJECTOR	TATA spare parts
F002C7Z011	INJECTOR	TATA spare parts
F002C7Z244	ASSY.INJECTOR 4SP BS-III NORMAL	TATA spare parts
F002C7Z245	ASSY. INJECTOR NORMAL 497 BS3	TATA spare parts
F002C7Z261	ASSY.INJECTOR NORMAL 697 EURO III	TATA spare parts
F002C80001	NOZZLE HOLDER	TATA spare parts
F002C80004	NOZZLE HOLDER	TATA spare parts
F002C8Z201	INJECTOR 125 HP/ 160 HP EURO I BS1/3	TATA spare parts
F002C8Z205	ASSY. INJECTOR LPT 709E TURBO	TATA spare parts
F002C8Z206	ASSY. INJECTOR 407	TATA spare parts
F002C8Z208	INJECTOR	TATA spare parts
F002C8Z500	INJECTOR HARVESTOR	TATA spare parts
F002C8Z851	INJECTOR ASSY 697SK & 1510 CMVR	TATA spare parts
F002C8Z852	ASSY INJECTOR	TATA spare parts
F002C8Z859	ASSY INJECTOR	TATA spare parts
F002C8Z860	ASSY INJECTOR BS II	TATA spare parts
F002C8Z863	INJECTOR (125HP)EUROII	TATA spare parts
F002C8Z864	INJECTOR 145 HP EURO II	TATA spare parts
F002C8Z864AE	INJECTOR 145 HP EURO IILPA 1415/	TATA spare parts
F002C8Z865	INJECTOR 160 HP EURO II	TATA spare parts
F002C8Z873	INJECTOR ASSY	TATA spare parts
F002C8Z874	ASSY INJECTOR HOLDER WITH NOZZLE	TATA spare parts
F002C8Z876	ASSY INJECTOR 145 HP BS I	TATA spare parts
F002C8Z880	INJECTOR BS2/3	TATA spare parts
F002C8Z887	ASSY NOZZLE HOLDER 207DI BSIII	TATA spare parts
F002C8Z888	INJECTOR ASSY 145 HP BS II	TATA spare parts
F002C8Z903	INJECTOR ASSY 145 HP EURO I	TATA spare parts
F002CBZ851	NOZZLE HOLDER WITH NOZZLE 697NA CMVR 2K1	TATA spare parts
F002D11347	SOLNOID SWITCH FIP BS2/3	TATA spare parts
F002D11350	SOLENOID SWITCH FOR FIP 180 HP BIPOLAR	TATA spare parts
F002D113894	FIP SOLENOID SWITCH	TATA spare parts
F002D11413	FIP SOLONOID	TATA spare parts
F002G50000	GLOW PLUG QUICK START	TATA spare parts
F002G50024	GLOW PLUG	TATA spare parts
F002H20113	ASSY FUEL FILTER WITH WATER SEP.	TATA spare parts
F002H20134	ASSY. FUEL FILTER (FWS) BS2/3	TATA spare parts

F002H20136	ASSY FUEL FILTER SPIN ON BSII	TATA spare parts
F002H20139	ASSY FUEL FILTER SPIN ON BSII	TATA spare parts
F002H20306	ASSY. FINE FILTER BS2/3	TATA spare parts
F002H20308	PRE FILTER SPIN ON PRIMARY	TATA spare parts
F002H20332	COVER FUEL FILTER	TATA spare parts
F002H20387	WATER SEPARATOR W/HANDPRIMER BS2	TATA spare parts
F002H20392	WATER SEP COVER W/ HAND PRIMER	TATA spare parts
F002H22095	FUEL FILTER BSIV SPIN ON CARTRIDGE	TATA spare parts
F002H31103	SPECIAL TOOL FOR BSII FIP	TATA spare parts
F002K30079	EGR CONTROLLER	TATA spare parts
F002R20000	FILTER ELEMENT PETROL	TATA spare parts
F00RJ01620	HIGH PRESSURE CONNECTOR BS3	TATA spare parts
F00RJ01831	HIGH PRESSURE CONNECTOR BS4	TATA spare parts
F2590	PISTON SLEEVE DI 692	TATA spare parts
F81353	JOINT	TATA spare parts
F88891	SHIM 0.051 MM	TATA spare parts
F88892	SHIM 0.127 MM	TATA spare parts
F91353	GASKET RANGE CONT.VAL	TATA spare parts
F9175000001	WIPER MOTOR	TATA spare parts
F9175000002	LINKAGE ASSY	TATA spare parts
F9175000003	WIPER ARM ASSY¿ LH	TATA spare parts
F9175000004	WIPER ARM ASSY¿ RH	TATA spare parts
F9175000005	WIPER BLADE 800 MM	TATA spare parts
F9175000006	WASHER ASSY WITH RESERVOIR/PUMP UNIT	TATA spare parts
F9175000007	WIPER BLADE 1000 MM	TATA spare parts
F96387	RANGE VALVE	TATA spare parts
FBRFSH	FRP FRONT SHOW	TATA spare parts
FK100	CARDBOARD BOX (192.5 x 76.5 x 111 CM)	TATA spare parts
FK101	CARDBOARD BOX (192.5 x 76.5 x 121 CM)	TATA spare parts
FK105	CARDBOARD BOX (192.5 x 76.5 x 62 CM)	TATA spare parts
G0460494418	F INJ PUMP W/KSB EXP TC	TATA spare parts
G1202610080	ROTARY SHAFT OIL SEAL	TATA spare parts
G207620153101	BALL BEARING	TATA spare parts
G254703140155	RING OIL STD	TATA spare parts
G254703140277	SET PISTON NA STD GR A	TATA spare parts
G254703153449	4DLTC CON ROD BUSH	TATA spare parts
G254705125115	INLET VALVE	TATA spare parts
G254705125116	EXHAUST VALVE	TATA spare parts
G254709130132	A/FILTER ELEMENT	TATA spare parts
G254709130296	A/FILTER ELEMENT TC E/TECH	TATA spare parts
G254714510104	TURBO CHARGER	TATA spare parts
G254714605852	HOSE TO PIPE TO I.C.	TATA spare parts
G254714609922	INTERCOOLER SAFARI	TATA spare parts
G254715135806	RUBBER HOSE VACCUM PUMP	TATA spare parts
G254715146321	POLY V BELT 4 GROOVE 1050 L	TATA spare parts
G254718130104	OIL FILTER ASSY	TATA spare parts
G254720100124	WATER PUMP	TATA spare parts



G254720125821	R HOSE RED TO ELBOW NEW	TATA spare parts
G254720129904	THERMOSTAT ASSY 83 SOT	TATA spare parts
G254750100177	RAD.4 ROW	TATA spare parts
G254750105857	HOSE COMMON	TATA spare parts
G254750105862	RUBBER HOSE	TATA spare parts
G265429100163	CL SLAVE CYL 23.81D	TATA spare parts
G265432110194	Gear Lever Kit Xenon	TATA spare parts
G265433200113	BALL JOINT STD LOW	TATA spare parts
G265433403107	TAPER ROLLER BEARING-OUTER	TATA spare parts
G265433403108	TAPER ROLLER BEARING-INNER	TATA spare parts
G265442100110	REP KIT SLIDING PIN	TATA spare parts
G265442108202	ANTI RATTLE CLIP	TATA spare parts
G265481106316	MUD LINER LH OUTER	TATA spare parts
G265488700124	CABLE BONNET RELEASE LHD	TATA spare parts
G265954400183	ROOF LAMP	TATA spare parts
G265954700143	COND FAN UNIT 120W/7BLADE	TATA spare parts
G267872500139	DUST SEAL FRT DR LH	TATA spare parts
G267873500136	DUST SEAL RR DR LH	TATA spare parts
G269026257706	OIL SEAL (INPUT SHAFT)	TATA spare parts
G269026300134	DRIVE SHAFT - LH	TATA spare parts
G269026300135	DRIVE SHAFT - RH	TATA spare parts
G269832100165	ASSY. PIVOT BUSH	TATA spare parts
G269946600113	TIE ROD SAFARI RH	TATA spare parts
G269946600132	FILTER/END COVER ASSY	TATA spare parts
G269982409908	WIPER BLADE FR CODR SIDE	TATA spare parts
G270215409901	GLOW PLUG SR5	TATA spare parts
G270232110106	BALL JOINT RH POWER STRG	TATA spare parts
G270247100125	ASSY SCREW CAP-VENTED	TATA spare parts
G270254409913	HEADLAMP WITH BLINKER LH	TATA spare parts
G270254409914	REAR CLUSTER LAMP RH	TATA spare parts
G270254409915	RR CLUSTER LAMP LH	TATA spare parts
G270254419902	REAR CLUSTER LAMP RH DLX MOD.	TATA spare parts
G270254509930	STOP LIGHT SWITCH M10 X 1.25	TATA spare parts
G270254509935	HAZARD WARNING SWITCH	TATA spare parts
G270254509960	Reverse Light SW	TATA spare parts
G277032301602	FRONT SHOCK ABSORBER	TATA spare parts
G279001103714	CYLINDER LINER	TATA spare parts
G279001155308	GASKET FOR CYL.HEAD COVER	TATA spare parts
G279001155339	GASKET CYL HEAD MLS (1.5 THK)	TATA spare parts
G279001155340	GASKET (FOR CYL.HEAD COVER )	TATA spare parts
G279001155341	GASKET CYL HEAD	TATA spare parts
G279003990117	SET THRUST WASHER	TATA spare parts
G279005107808	O/S CAM FRT	TATA spare parts
G279005107810	OIL SEAL (CAMSHAFT REAR)	TATA spare parts
G279005125104	INTAKE VALVE	TATA spare parts
G279005125105	EXHAUST VALVE	TATA spare parts
G279024100155	ASSY. ENGINE MOUNT -B	TATA spare parts

G28182900008F2	CRL POSITION CHECKING GAUGE	TATA spare parts
G282346600151	ASSY. TIE ROD	TATA spare parts
G284354209914	VEHICLE SPEED SENSOR-(FACELIFT)	TATA spare parts
G62123055123	FUSE 40A	TATA spare parts
GB/T276-94	BEARING	TATA spare parts
GB75-85-M18X20ZN	SLIT BOLT	TATA spare parts
GRRF01	REAR ONE PIECE FIXED	TATA spare parts
GX8876352	PLUG OIL STRAINER	TATA spare parts
H01332007000	BEARING	TATA spare parts
H01332207000	BEARING	TATA spare parts
H01522991	HYDRAULIC CYLINDER LPK 2516TC 6X4	TATA spare parts
H01527453	CYLINDER	TATA spare parts
H01528336	Cylinder FE-141-3-3830-001-HC	TATA spare parts
H01705301	BASE DIA	TATA spare parts
H01705507	Base Tube B162-1544-4/4-190	TATA spare parts
H01706937	Base Tube B141 - 1480 -3/4-190	TATA spare parts
H01726808	PISTON DIA	TATA spare parts
H01726857	Piston with Eye PE099-1665-HC	TATA spare parts
H01730046	BOTTOM PLATE DIA	TATA spare parts
H01730058	Bottom Plate Dia 141	TATA spare parts
H01731040	Locking Plate For Cyl FE141	TATA spare parts
H01731051	Locking Plate For Cyl FE120	TATA spare parts
H01733059	O-Ring Base Dia 141	TATA spare parts
H01733060	O-Ring Base Dia 120	TATA spare parts
H01740209	SNAP RING 099DIA.	TATA spare parts
H01740209K	Snap Ring Dia 099	TATA spare parts
H01740430	SNAP RING DIA 141	TATA spare parts
H01740430K	Snap Ring Dia 141	TATA spare parts
H01740441	SNAP RING 120 DIA.	TATA spare parts
H01740441K	Snap Ring Dia 120	TATA spare parts
H01750069	SLIDER SET DIA	TATA spare parts
H01750069K	Slider Set Dia 141	TATA spare parts
H01750070	SLIDER SET DIA	TATA spare parts
H01750070K	Slider Set Dia 120	TATA spare parts
H01750082	SLIDER SET DIA	TATA spare parts
H01750082K	Slider Set Dia 099	TATA spare parts
H01750094	SLIDER SET DIA	TATA spare parts
H01750094K	Slider Set Dia 078	TATA spare parts
H01760040K	PACKSET DIA 162	TATA spare parts
H01760051K	Packset for Stage Dia 141	TATA spare parts
H01760063K	Packset for Stage Dia 120	TATA spare parts
H01760075K	Packset for Stage Dia 099	TATA spare parts
H01762278K	Packset ( Complete) for Cylinder FE141	TATA spare parts
H01762308K	Packset ( Complete) for Cylinder FE120	TATA spare parts
H01770019	Spherical Eye Dia 50.8	TATA spare parts
H01770500	CIRCLIP FOR 50.8 DIA	TATA spare parts
H01963510H	Seal Kit for 3DHMP Valve	TATA spare parts

H02269356	DRIVEN SHAFT	TATA spare parts
H02269359	THRUST PLATE	TATA spare parts
H02300000	TIPPING CYL	TATA spare parts
H02300010	UBEE	TATA spare parts
H02300020	UBEE	TATA spare parts
H02300030	UBEE	TATA spare parts
H02300050	UBEE	TATA spare parts
H02404823	SHAFT SEAL BAU 24X40X7	TATA spare parts
H02404825	SHAFT SEAL BA 24X40X7	TATA spare parts
H02652259	STAGE DIA	TATA spare parts
H02652805	Stage S141-1510-HC	TATA spare parts
H02673605	Stage S120-1446-DS-HC	TATA spare parts
H02674105	Stage 120-1510-DS-HC	TATA spare parts
H02688405	Stage S099-1446-DS-HC	TATA spare parts
H02771810	Piston with Eye PE078-1601-HC	TATA spare parts
H02858800	BASE 162 X 1480	TATA spare parts
H02859440	BASE 162 X 1544	TATA spare parts
H02874700	BASE 141 X 1480	TATA spare parts
H02952259	STAGE 141 X 1446-HC	TATA spare parts
H02973601	STAGE 120 X 1446-HC	TATA spare parts
H02974105	STAGE 120 X 1510-HC	TATA spare parts
H02988405	STAGE 099 X 1446	TATA spare parts
H08102116	Breather Assy	TATA spare parts
H08102117	Breather Element	TATA spare parts
H08102119	Breather Cover	TATA spare parts
H08102125	FILTER HOUSE	TATA spare parts
H08102126	Breather Seal	TATA spare parts
H08102127	Bolt - Breather	TATA spare parts
H08102128	Sleeve - Breather	TATA spare parts
H08102864	Hyfix Body Clamp Assy	TATA spare parts
H10090961094	AIR CONTROL VALVE LPK 2516TC 6X4	TATA spare parts
H10090961227	AIR CONTROL VALVE	TATA spare parts
H14708317H	TIPPING VALVE LPK 2516TC 6X4	TATA spare parts
H14739975A	NON RETURN VALVE	TATA spare parts
H14750150H	Air Control Valve	TATA spare parts
H14767317	VALVE	TATA spare parts
H14770170	CARTRIDGE	TATA spare parts
H14771170	PRESSURE CATRIDGE	TATA spare parts
H14780306	Return Line Filter Assembly	TATA spare parts
H14780980	Ball Valve 1-1/2INCHBSP LP	TATA spare parts
H14843910	O RING KIT - PT VALVE	TATA spare parts
H14844010	PT VALVE REPAIR KIT	TATA spare parts
H14896905	Filter Cap	TATA spare parts
H14896920	Return Line Filter Housing	TATA spare parts
H14896950	Seal Kit for Return Line Filter	TATA spare parts
H14896985	Spring for Return Line Filter	TATA spare parts
H14896991A	Return Line Filter Element	TATA spare parts

H14897003	HYFIX HOOK	TATA spare parts
H14897015	HYFIX MOUNTING EYE (MACHINED)	TATA spare parts
H14897027	Hyfix Rubber	TATA spare parts
H14897039	HYFIX COMPRESSION PLATE	TATA spare parts
H14897040	HYFIX PIN - 1 (DIA31.5X110L)	TATA spare parts
H14897052	HYFIX PIN -2(DIA 25 X 85L)	TATA spare parts
H14897064	HYFIX SECURE(SPRING DOWEL)PIN	TATA spare parts
H14897088	HYFIX STUD SET(M20 NUT+PIN)	TATA spare parts
H14897106	HYFIX PIN - 3 (DIA31.5X80L)	TATA spare parts
H2F451015000	THRUST PLATE	TATA spare parts
H2Z554090000	SEAL KIT	TATA spare parts
H53771210	EXTRACTION REMOVAL DEVICE	TATA spare parts
H53942810	DISASSEMBLY TOOL	TATA spare parts
H53947310	INSTALLATION TOOLS	TATA spare parts
H56252120801H	STARTING RELAY 12 V	TATA spare parts
H5626361120DG	COIL 12 V	TATA spare parts
H71534201H	HYDRAULIC CYLINDER LPK 2516TC 6X4	TATA spare parts
H71534201I	HYDRAULIC CYLINDER LPK 2516TC 6X4	TATA spare parts
H71535301	TIPPING CYLINDER	TATA spare parts
H71802110	PACKSET FOR STAGE DIA	TATA spare parts
H71802129	PACKSET FOR STAGE DIA	TATA spare parts
H71802149	PACKSET FOR STAGE DIA	TATA spare parts
H71807091	SLIDER	TATA spare parts
H71807110	SLIDER	TATA spare parts
H71807129	SLIDER	TATA spare parts
H71810110	STOPRING TYPE	TATA spare parts
H71810129	INNER STOPRING TYPE	TATA spare parts
H71810149	INNER STOPRING TYPE	TATA spare parts
H71812110	LIFTRING	TATA spare parts
H71812129	LIFTRING	TATA spare parts
H80020000001	FRONT WINDSHIELD GLASS	TATA spare parts
H80020000002	REAR WINDSHIELD GLASS	TATA spare parts
H80020000003	FIXED WINDOW GLASS	TATA spare parts
H80020000004	PASSENGER DOOR GLASS	TATA spare parts
H80020000005	PASSENGER DOOR QUARTER GLASS	TATA spare parts
H80020000006	DRIVER DOOR GLASS	TATA spare parts
H80020000007	DRIVER DOOR QUARTER GLASS	TATA spare parts
H80020000008	EMERGENCY EXIT WINDOW/DOOR GLASS	TATA spare parts
H80020000009	SIDE MARKER LAMP	TATA spare parts
H80020000010	SIDE BLINKER (FRONT SIDE DEFLECTOR/INDIC	TATA spare parts
H80020000011	SIDE BLINKER (FRONT SIDE DEFLECTOR/INDIC	TATA spare parts
H80020000012	HEIGHT MARKER (RED)	TATA spare parts
H80020000013	HEIGHT MARKER (WHITE)	TATA spare parts
H80020000014	STOP SWITCH	TATA spare parts
H80020000015	NUMBER PLATE LAMP ASSY	TATA spare parts
H80020000016	SWITCHES - PIANO TYPE	TATA spare parts
H80020000017	TOGGLE SWITCH FOR PASSENGER DOOR	TATA spare parts

H80020000018	INTERMITTENT BUZZER (DOOR)	TATA spare parts
H80020000019	SPOT LAMP (FOR PASSENGER/SALOON AREA)	TATA spare parts
H80020000020	FLOURSCENT LAMP (TUBE LIGHTS)	TATA spare parts
H80020000021	REVERSE HORN	TATA spare parts
H80020000022	FOG LAMP ASSY	TATA spare parts
H80020000023	DOOR HANDLE LOCK WITH KEY(OUTER LOCK)	TATA spare parts
H80020000024	LINK ROD DRIVER DOOR LOCK	TATA spare parts
H80020000025	FRONT BUMPER CPTC	TATA spare parts
H80020000026	REAR BUMPER CPTC	TATA spare parts
H80020000027	DRIVER DOOR ASSY CPTC(GUCHA LOCK)	TATA spare parts
H80020000028	DOOR GLASS RUBBER BEADING	TATA spare parts
H80020000029	DOOR HINGES	TATA spare parts
H80020000030	DOOR BEARINGS/BUSHES	TATA spare parts
H80020000031	HINGE WITH HANDLE	TATA spare parts
H80020000032	PNEUMATIC KIT COMPLETE	TATA spare parts
H80020000033	BUDGET LOCK COVER	TATA spare parts
H80020000034	RUBBER BEADING FOR WHEEL ARCH	TATA spare parts
H80020000035	T BEADING FOR WINDSHIELD	TATA spare parts
H80020000036	WEATHER STRIP - DRIVER DOOR	TATA spare parts
H80020000037	WEATHER STRIP - WINDSHIELD	TATA spare parts
H80020000038	WEATHER STRIP - PASSENGE DOOR GLASS(REAR	TATA spare parts
H80020000039	WIPER SYSTEM	TATA spare parts
H80020000040	RVM ASSY RH	TATA spare parts
H80020000041	RVM ASSY LH	TATA spare parts
H80020000042	GAS STAY	TATA spare parts
H80020000043	HAND STRAP	TATA spare parts
H80020000044	SALOON MIRROR	TATA spare parts
H80020000045	DRIVER DOOR INNER HANDLE ASSY	TATA spare parts
H80020000046	DRIVER DOOR STRIKER ASSY	TATA spare parts
H80020000047	DESTINATION INDICATOR - FRONT	TATA spare parts
H80020000048	DESTINATION INDICATOR - SIDE	TATA spare parts
H80020000049	MASCOT(STICKERS)	TATA spare parts
H80020000050	FRONT FACE COMPLETE	TATA spare parts
H80020000051	FRONT GRILL (CENTER FLAP)	TATA spare parts
H80020000052	DASHBOARD	TATA spare parts
H80020000053	REAR FACE COMPLETE	TATA spare parts
H80020000054	WIPER MOTORS	TATA spare parts
H80020000055	WING NUT	TATA spare parts
H80020000056	FRONT WINDSHIELD GLASS RH SIDE	TATA spare parts
H80020000057	FRONT WINDSHIELD GLASS LH SIDE	TATA spare parts
H80020000058	ROOF HARNESS CNG	TATA spare parts
H80020000059	BELL HARNESS	TATA spare parts
H80020000060	PNEUMATIC CYLINDER HARNESS	TATA spare parts
H80880000001	TIPPING CYLINDER	TATA spare parts
H80880000002	LEVER MECHANISM& ASSLY	TATA spare parts
H80880000003	CARBON	TATA spare parts
H80880000004	EXHAUST PIPE	TATA spare parts

H80880000005	COMP DELIVERY PIPE 10 CUM	TATA spare parts
H80880000006	BEARING	TATA spare parts
H80880000007	BEARING	TATA spare parts
H80880000008	BEARING	TATA spare parts
H80880000009	EXHAUST PIPE	TATA spare parts
H80880000010	FILTER	TATA spare parts
H80880000011	CARBON SPRING	TATA spare parts
H80880000012	EXHAUST PIPE	TATA spare parts
H80880000013	COMP DELIVERY PIPE 10 CUM	TATA spare parts
H80880000014	LIFTING BKT FC110 RH	TATA spare parts
H80880000015	LIFTING BKT FC110 LH	TATA spare parts
H80880000016	LIFTING BKT RH 149 169 191 IGUS BUSH	TATA spare parts
H80880000017	LIFTING BKT RH 149 169 191 IGUS BUSH	TATA spare parts
H80880000018	SPH. BEARING GE50 ES XID GR.	TATA spare parts
H80880000019	DRIVEN GEAR	TATA spare parts
H80880000020	THRUST PLATE	TATA spare parts
H80880000021	THRUST PLATE	TATA spare parts
H80880000022	THRUST PLATE	TATA spare parts
H80880000023	DRIVE GEAR	TATA spare parts
H80880000024	GRIVEN GEAR	TATA spare parts
H80880000025	DRIVE GEAR	TATA spare parts
H80880000026	SEAL KIT	TATA spare parts
H80880000027	SEAL KIT	TATA spare parts
H80880000028	STAGE 1446-DS-HC	TATA spare parts
H80880000029	GEAR PUMP 87L R 4H	TATA spare parts
H80880000030	RLF FLANGE PIPE	TATA spare parts
H80880000031	BASE 1399-4/4SAE-190	TATA spare parts
H80880000032	OIL TANK FE149 FOR PT VALVE	TATA spare parts
H80880000033	OIL TANK FE149 FOR 3-DHMP	TATA spare parts
H80880000034	GREASE NIPPLE PUSH TYPE M8	TATA spare parts
H80880000035	HOSE 3/4INIDX2250 R2 1*3/16INUNF	TATA spare parts
H80880000036	GEAR PUMP BLUE	TATA spare parts
H80880000037	GEAR PUMP 51CC-R-4H BLACK	TATA spare parts
H80880000038	GEAR PUMP 82L-R-4H BLACK	TATA spare parts
H80880000039	GEAR PUMP (BLACK)	TATA spare parts
H80880000040	AIR CONTROL SWITCH TATA	TATA spare parts
H80880000041	CYLINDER TIPPING CYL	TATA spare parts
H80880000042	CYLINDER TIPPING	TATA spare parts
H80880000043	CYLINDER TIPPING CYL	TATA spare parts
H80880000044	CYLINDER TIPPING KIT	TATA spare parts
H80880000045	CYLINDER TIPPING CYL	TATA spare parts
H80880000046	CYLINDER TIPPING CYL	TATA spare parts
H80880000047	CYLINDER TIPPING CYL	TATA spare parts
H80880000048	CYLINDER TIPPING CYL	TATA spare parts
H80880000049	CYLINDER TIPPING CYL	TATA spare parts
H80880000050	COVER 168-1035 PIN60	TATA spare parts
H80880000051	COVER 219-1245	TATA spare parts

H80880000052	COVER 219-1445	TATA spare parts
H80880000053	SLIDER TYPE 149	TATA spare parts
H80880000054	SLIDER TYPE 169	TATA spare parts
H80880000055	SLIDER TYPE 191	TATA spare parts
H80880000056	LIFTRING TYPE 149	TATA spare parts
H80880000057	LIFTRING TYPE 169 SQUARE	TATA spare parts
H80880000058	LIFTRING TYPE 191 SQUARE	TATA spare parts
H80880000059	LIFTRING TYPE 169 ROUND	TATA spare parts
H80880000060	LIFTRING TYPE 191 ROUND	TATA spare parts
H80880000061	LIFTRING TYPE 214 ROUND	TATA spare parts
H80880000062	SNAP RING FOR PISTON TYPE 072	TATA spare parts
H80880000063	SNAP RING FOR PISTON TYPE 110	TATA spare parts
H80880000064	BOTTOM PLATE PISTON TYPE 072	TATA spare parts
H80880000065	BOTTOM PLATE PISTON TYPE 110	TATA spare parts
H80880000066	BOTTOM PLATE SET 129	TATA spare parts
H80880000067	BOTTOM PLATE SET 149	TATA spare parts
H80880000068	BOTTOM PLATE SET 169	TATA spare parts
H80880000069	BOTTOM PLATE SET 191	TATA spare parts
H80880000070	BOTTOM PLATE SET 214	TATA spare parts
H80880000071	PISTON HEAD	TATA spare parts
H80880000072	PISTON HEAD	TATA spare parts
H80880000073	PISTON EYE GREASED	TATA spare parts
H80880000074	PISTON EYE	TATA spare parts
H80880000075	PISTON EYE	TATA spare parts
H80880000076	'O' RING PISTON TOP 072	TATA spare parts
H80880000077	'O' RING PISTON TOP 110	TATA spare parts
H80880000078	'O' RING PISTON BOTTOM 072	TATA spare parts
H80880000079	'O' RING PISTON BOTTOM 110	TATA spare parts
H80880000080	PIN ROUND HEAD GROOVED 6X15MM	TATA spare parts
H80880000081	COMPLETE PACK SET 110	TATA spare parts
H80880000082	COMPLETE PACK SET 149	TATA spare parts
H80880000083	COMPLETE PACKSET 169	TATA spare parts
H80880000084	PISTON S 072-1280-HC	TATA spare parts
H80880000085	PISTON S 091-1365-HC	TATA spare parts
H80880000086	PISTON S 091-1498-HC	TATA spare parts
H80880000087	PISTON S 110-1445-HC	TATA spare parts
H80880000088	PISTON S 110-1560-HC	TATA spare parts
H80880000089	BASE 129-1314-4/4SAE-190	TATA spare parts
H80880000090	BASE 149-1459-4/4SAE-190	TATA spare parts
H80880000091	BASE 169-1559-4/4SAE-190	TATA spare parts
H80880000092	BASE 191-1479-4/4SAE-700	TATA spare parts
H80880000093	STAGE 091-1275-HC	TATA spare parts
H80880000094	STAGE 110-1360-HC	TATA spare parts
H80880000095	STAGE 110-1420-HC	TATA spare parts
H80880000096	STAGE 110-1520-HC	TATA spare parts
H80880000097	STAGE 129-1360-HC	TATA spare parts
H80880000098	STAGE 129-1420-HC	TATA spare parts

H80880000099	STAGE 129-1520-HC	TATA spare parts
H80880000100	STAGE 149-1440-HC	TATA spare parts
H80880000101	STAGE 149-1520-HC	TATA spare parts
H80880000102	STAGE 169-1440-HC	TATA spare parts
H80880000103	STAGE 169-1440-HC	TATA spare parts
H80880000104	STAGE 191-1440-HC	TATA spare parts
H80880000105	PISTON 1655-HC	TATA spare parts
H80880000106	STAGE 1650-HC	TATA spare parts
H80880000107	STAGE 1650-HC	TATA spare parts
H80880000108	CHASSIS BKT FE/FC110	TATA spare parts
H80880000109	CHASSIS BKT 129 149 IB	TATA spare parts
H80880000110	SLIDER TYPE (2X1/2)	TATA spare parts
H80880000111	SLIDER TYPE (2X1/2)	TATA spare parts
H80880000112	SLIDER TYPE (2X1/2)	TATA spare parts
H80880000113	LIFTRING TYPE 105	TATA spare parts
H80880000114	LIFTRING TYPE 086	TATA spare parts
H80880000115	TD LOCKING BUSH ASSY	TATA spare parts
H80880000116	STAGE 110-1275-HC	TATA spare parts
H80880000117	CAM MECH LOCKING	TATA spare parts
H80880000118	CAM MECH LOCKING	TATA spare parts
H80880000119	LOCKING HOOK	TATA spare parts
H80880000120	TOP NUT M48X3	TATA spare parts
H80880000121	WASHER M48	TATA spare parts
H80880000122	SERR. FLANGE SCREW M8 X 18	TATA spare parts
H80880000123	LOCKING PLATE TYPE	TATA spare parts
H80880000124	BOTTOM PLATE TYPE	TATA spare parts
H80880000125	O RING BOTTOM PLATE	TATA spare parts
H80880000126	BODY PROP ASSY	TATA spare parts
H80880000127	HEX.BOLT M12X1.25X50 - 10.9	TATA spare parts
H80880000130	SPLIT PIN 3X30	TATA spare parts
H80880000132	M12 HARD WASHER 13/25/3	TATA spare parts
H80880000134	ELBOW M26X1.5 X 1*3/16INUNF ORS	TATA spare parts
H80880000135	HOSE 1IN ID X 1500 R1 TANK TO PUMP	TATA spare parts
H80880000136	FILTER CLOG INDICATOR	TATA spare parts
H80880000137	RUBBER PAD FOR FC CYL	TATA spare parts
H80880000138	SPRING HOOK	TATA spare parts
H80880000139	ANTI RATTLE BRACKET	TATA spare parts
H80880000140	CAM MTG ASSY	TATA spare parts
H80880000141	CAM HAMMER ASSY	TATA spare parts
H80880000142	HOOK ASSEMBLY	TATA spare parts
H80880000143	REAR HINGE SHAFT SNAP RING 50 DIA	TATA spare parts
H80880000144	REAR HINGE BUSH ASSY ID50	TATA spare parts
H80880000145	HOOK BLOCK ASSEMBLY LH	TATA spare parts
H80880000146	HOOK BLOCK ASSEMBLY RH	TATA spare parts
H80880000147	REAR HINGE SHAFT 50DIA X1000L	TATA spare parts
H80880000148	SIDE BOARD LH	TATA spare parts
H80880000149	SIDE BOARD RH	TATA spare parts



H80880000150	HEAD BOARD ASSY	TATA spare parts
H80880000151	TAIL DOOR ASSY	TATA spare parts
H80880000152	FLOOR WITH SUBFRAME	TATA spare parts
H80880000153	CRADLE ASSY	TATA spare parts
H80880000154	PULLING PIPE ASSEMBLY	TATA spare parts
H80880000155	LOWER PIVOT - 1	TATA spare parts
H80880000156	LOWER PIVOT - 2	TATA spare parts
H80880000157	PACKSET	TATA spare parts
H80880000158	REAR HINGE SHAFT BUSH ASSY	TATA spare parts
H80880000159	COVER PLATE	TATA spare parts
H80880000160	GASKET	TATA spare parts
H80880000161	BUSH	TATA spare parts
H80880000162	SLIDE BLOCK	TATA spare parts
H80880000163	CAP SCREW	TATA spare parts
H80880000164	BEARING ASSEMBLY	TATA spare parts
H80880000165	ADAPTOR GREASE NIPPLE	TATA spare parts
H80880000166	GREASE NIPPLE	TATA spare parts
H80880000167	BEARING	TATA spare parts
H80880000168	BLOCK PACKER SEAL	TATA spare parts
H80880000169	SPACER	TATA spare parts
H80880000170	BOLT	TATA spare parts
H80880000171	GROMMET	TATA spare parts
H80880000172	PACKER CYLINDER	TATA spare parts
H80880000173	BEARING ASSEMBLY	TATA spare parts
H80880000174	CIRCLIP	TATA spare parts
H80880000175	PIVOT PIN	TATA spare parts
H80880000176	BOLT	TATA spare parts
H80880000177	MALE STUD COUPLING	TATA spare parts
H80880000178	MALE STUD COUPLING	TATA spare parts
H80880000179	SEAL KIT PACKER CYLINDER	TATA spare parts
H80880000180	SWEEPER CYLINDER	TATA spare parts
H80880000181	PIVOT PIN	TATA spare parts
H80880000182	HEX. BOLT	TATA spare parts
H80880000183	NYLOC NUT	TATA spare parts
H80880000184	WASHER	TATA spare parts
H80880000185	PIVOT PIN	TATA spare parts
H80880000186	BEARING BUSH	TATA spare parts
H80880000187	PIVOT PIN	TATA spare parts
H80880000188	BUSH	TATA spare parts
H80880000189	PIVOT PIN	TATA spare parts
H80880000190	WASHER	TATA spare parts
H80880000191	BEARING BUSH	TATA spare parts
H80880000192	PIVOT PIN	TATA spare parts
H80880000193	BEARING BUSH	TATA spare parts
H80880000194	PIVOT PIN	TATA spare parts
H80880000195	BEARING BUSH	TATA spare parts
H80880000196	HYDRAULIC CYLINDER	TATA spare parts

H80880000197	PIVOT PIN	TATA spare parts
H80880000198	PIVOT PIN	TATA spare parts
H80880000199	SEAL KIT TAILGATE CYLINDER	TATA spare parts
H80880000200	HOSE ASSEMBLY	TATA spare parts
H80880000201	HOSE ASSEMBLY	TATA spare parts
H80880000202	HOSE ASSEMBLY	TATA spare parts
H80880000203	BULKHEAD CONNECTOR 28L	TATA spare parts
H80880000204	BULKHEAD CONNECTOR 22L	TATA spare parts
H80880000205	TEE PIECE	TATA spare parts
H80880000206	TEE PIECE	TATA spare parts
H80880000207	HOSE ASSEMBLY	TATA spare parts
H80880000208	HOSE ASSEMBLY	TATA spare parts
H80880000209	HOSE ASSEMBLY	TATA spare parts
H80880000210	HOSE ASSEMBLY	TATA spare parts
H80880000211	HOSE ASSEMBLY	TATA spare parts
H80880000212	HOSE ASSEMBLY	TATA spare parts
H80880000213	HOSE ASSEMBLY	TATA spare parts
H80880000214	HOSE ASSEMBLY	TATA spare parts
H80880000215	HOPPER PROP	TATA spare parts
H80880000216	PIVOT PIN	TATA spare parts
H80880000217	RUBBER RING	TATA spare parts
H80880000218	WASHER	TATA spare parts
H80880000219	COTTER PIN	TATA spare parts
H80880000220	BEARING BUSH	TATA spare parts
H80880000221	PLAIN WASHER	TATA spare parts
H80880000222	NYLOC NUT	TATA spare parts
H80880000223	SPRING DISC	TATA spare parts
H80880000224	BUSH	TATA spare parts
H80880000225	BUSH	TATA spare parts
H80880000226	BEARING SPHERICAL	TATA spare parts
H80880000227	FLAP	TATA spare parts
H80880000228	SLIDE BLOCK- BARRIER	TATA spare parts
H80880000229	SLIDE BLOCK	TATA spare parts
H80880000230	PLATE- BRG RETAINER	TATA spare parts
H80880000231	BOLT	TATA spare parts
H80880000232	WASHER SPRING	TATA spare parts
H80880000233	HOSE ASSEMBLY	TATA spare parts
H80880000234	HOSE ASSEMBLY	TATA spare parts
H80880000235	FLANGED OVER CENTER	TATA spare parts
H80880000236	PLATE COVER	TATA spare parts
H80880000237	BRACKET PROX SWITCH	TATA spare parts
H80880000238	PIVOT PIN	TATA spare parts
H80880000239	PIVOT PIN	TATA spare parts
H80880000240	BLANKING CAP DRAINAGE	TATA spare parts
H80880000241	COVER TOP LH	TATA spare parts
H80880000242	COVER TOP RH	TATA spare parts
H80880000243	COVER TOP CENTRE	TATA spare parts

H80880000244	UPPER PANEL TAILGATE	TATA spare parts
H80880000245	UPPER PANEL RH- TAILGATE	TATA spare parts
H80880000246	COVER - CYLINDER TOP L.H.	TATA spare parts
H80880000247	COVER - CYLINDER TOP R.H.	TATA spare parts
H80880000248	COVER-CYLINDER BOTTOM LH-TG	TATA spare parts
H80880000249	COVER-CYLINDER BOTTOM RH-TG	TATA spare parts
H80880000250	LUG NUT	TATA spare parts
H80880000251	VALVE COMPACTION ASSEMBLY	TATA spare parts
H80880000252	HOSE LAYFLAT	TATA spare parts
H80880000253	CLAMP S/STEEL FOR PI	TATA spare parts
H80880000254	VALVE BODY FRONT ASSY	TATA spare parts
H80880000255	PUMP VANE DOUBLE	TATA spare parts
H80880000256	SAE FLANGE ADAPTOR	TATA spare parts
H80880000257	HOSE CLIP	TATA spare parts
H80880000258	HOSE BARE	TATA spare parts
H80880000259	BSP ELBOW WITH CHECK NUT	TATA spare parts
H80880000260	BALL VALVE	TATA spare parts
H80880000261	SAE FLANGE ADAPTOR	TATA spare parts
H80880000262	HOSE	TATA spare parts
H80880000263	SAE FLANGE ADAPTOR	TATA spare parts
H80880000264	HOSE	TATA spare parts
H80880000265	HOSE ASSY	TATA spare parts
H80880000266	HOSE ASM	TATA spare parts
H80880000267	HOSE ASSY	TATA spare parts
H80880000268	HOSE	TATA spare parts
H80880000269	HOSE ASSEMBLY	TATA spare parts
H80880000270	HOSE ASSEMBLY	TATA spare parts
H80880000271	HOSE ASSEMBLY	TATA spare parts
H80880000272	EJECTOR CYLINDER_18W	TATA spare parts
H80880000273	RAM MOUNTING PIN	TATA spare parts
H80880000274	M6X65 HT BOLT ZP	TATA spare parts
H80880000275	CLAMP RAM MOUNT	TATA spare parts
H80880000276	BOLT M12X40P	TATA spare parts
H80880000277	HOSE ASSEMBLY	TATA spare parts
H80880000278	HOSE ASSEMBLY	TATA spare parts
H80880000279	FILTER RETURN LINE	TATA spare parts
H80880000280	ACCESS COVER HYD. TANK	TATA spare parts
H80880000281	ACCESS GASKET - HYD OIL	TATA spare parts
H80880000282	AIR BREATHER ASSY	TATA spare parts
H80880000283	FLUID LEVEL GUAGE	TATA spare parts
H80880000284	PTO GB600	TATA spare parts
H80880000285	HOSE	TATA spare parts
H80880000286	HOSE ASM	TATA spare parts
H80880000287	HOSE ASM	TATA spare parts
H80880000288	HOSE ASM	TATA spare parts
H80880000289	HOSE ASM	TATA spare parts
H80880000290	HOSE ASM	TATA spare parts

H80880000291	HYDRAULIC CYLINDER	TATA spare parts
H80880000292	HOSE ASM	TATA spare parts
H80880000293	PROXIMITY SWITCH	TATA spare parts
H80880000294	PROXIMITY SWITCH	TATA spare parts
H80880000295	PROXIMITY SWITCH	TATA spare parts
H80880000296	PROXIMITY SWITCH	TATA spare parts
H80880000297	CAM	TATA spare parts
H80880000298	SPACER	TATA spare parts
H80880000299	BOLT	TATA spare parts
H80880000300	CLIP	TATA spare parts
H80880000301	SWITCH FLAG	TATA spare parts
H80880000302	BRACKET	TATA spare parts
H80880000303	TRUNNION LATCH DINARM-BL	TATA spare parts
H80880000304	RUBBER PAD FOR BIN LIFT ASSY	TATA spare parts
H80880000305	INT CIRCLIP DIN	TATA spare parts
H80880000306	BEARING	TATA spare parts
H80880000307	STAY ROPE MTG PIN	TATA spare parts
H80880000308	PIVOT TOP LH	TATA spare parts
H80880000309	PIVOT TOP RH	TATA spare parts
H80880000310	TOP PIVOT SUPPORT MTG BKT	TATA spare parts
H80880000311	HOSE ASSEMBLY	TATA spare parts
H80880000312	HOSE ASSEMBLY	TATA spare parts
H80880000313	FLAP (RUBBER)	TATA spare parts
H80880000314	SLIDE BLOCK- BARRIER	TATA spare parts
H80880000315	END CAP	TATA spare parts
H80880000316	BOLT	TATA spare parts
H80880000317	ELBOW WITH CHECK NUT	TATA spare parts
H80880000318	BALL VALVE	TATA spare parts
H80880000319	HOSE	TATA spare parts
H80880000320	HOSE	TATA spare parts
H80880000321	HOSE	TATA spare parts
H80880000322	HOSE ASSY	TATA spare parts
H80880000323	HOSE ASSEMBLY	TATA spare parts
H80880000324	HOSE ASSEMBLY	TATA spare parts
H80880000325	EJECTOR CYLINDER	TATA spare parts
H80880000326	RLF ASSEMBLY	TATA spare parts
H80880000327	AIR BREATHER FILTER ELEMENT	TATA spare parts
H80880000328	RLF ELEMENT	TATA spare parts
H80880000329	ASSEMBLY PIVOT PIN	TATA spare parts
H80880000330	SCREW	TATA spare parts
H80880000331	PIN	TATA spare parts
H80880000332	WASHER	TATA spare parts
H80880000333	SPRING DIN ARM LOCKING	TATA spare parts
H80880000334	14 STD BOX BODY WITH SUB-FRAME(LPK 2518C	TATA spare parts
H80880000335	LOCK BOLT M10X65	TATA spare parts
H80880000336	SOLENOIDE COIL & CONNECTOR 24V	TATA spare parts
H80880000337	CRADLE ASSY FORçCYL.	TATA spare parts

H80880000338	FL & S/F ASSLY-8.5CUM	TATA spare parts
H80880000339	HB ASSY 8.5 STD TATA 1618	TATA spare parts
H80880000340	RH SIDE BOARD ASSY	TATA spare parts
H80880000341	LH SIDE BOARD ASSY	TATA spare parts
H80880000343	ATTACHMENT PLATE -1	TATA spare parts
H80880000344	ATTACHMENT PLATE -2	TATA spare parts
H80880000345	LOWER PIVOT -1	TATA spare parts
H80880000346	LOWER PIVOT -2	TATA spare parts
H80880000347	LOWER PIVOT -3	TATA spare parts
H80880000348	TIPPING CYLINDER	TATA spare parts
H80880000349	CONTROL BOX BODY	TATA spare parts
H80880000350	FABRICATION BIN LIFT ASLY WIDE	TATA spare parts
H80880000351	BOTTOM PIVOT SUPPORT MTG BKT	TATA spare parts
H80880000352	JUNCTION BOX BODY	TATA spare parts
HD-XS-TZGM001	SLEEVE BARREL	TATA spare parts
HD-XS-TZGM002	SLEEVE BARREL	TATA spare parts
HD-XS-TZGM003	SLEEVE BARREL	TATA spare parts
HD-XS-TZGM004	SLEEVE BARREL	TATA spare parts
HD-XS-TZGM005	HEX-HEAD SPANNER FOR DIFF	TATA spare parts
HD-XS-TZGM006	HEX HEAD SPANNER FOR DIFF LOCK	TATA spare parts
HD-XS-TZGM007	SHAFT HEAD NUT SPANNER	TATA spare parts
HD-XS-TZGM008	BEARING EXTRACTOR FOR INNER HUB BEARING	TATA spare parts
HD-XS-TZGM009	BEARING EXTRACTOR FOR DIFF & PINION GEAR	TATA spare parts
HD-XS-TZGM010	RATCHET SPANNER	TATA spare parts
HOBARBDCl	Bardahl Diesel Combustion Improver (BDCl)	TATA spare parts
HOBARBDT	Bardahl Dieseltune (BDT)	TATA spare parts
HOBARBETF	Bardahl Engine Tune-up & Flush (BETF)	TATA spare parts
HOBARBRFF	Bardahl Radiator Fast Flush (BRFF)	TATA spare parts
HS507906/V	AIR SPRING MAIN BELLOWS	TATA spare parts
HS507907/P	LIFT AIR SPRING	TATA spare parts
HS508337-F01	UPPER DAMPER MOUNT	TATA spare parts
HS508386	HWS DAMPER	TATA spare parts
HS508562	WEARPAD (SMALL)	TATA spare parts
I60420000001	PIANO SWITCH 4 IN1	TATA spare parts
INS-90-1-0017	COMPANION FLANGE (FRONT PROP SHAFT)	TATA spare parts
INSKU-100258	SLIP YOKE ASSY. (REAR P.SHAFT -)	TATA spare parts
INSKU-100760	DUST CAP KIT (REAR P.SHAFT)	TATA spare parts
J3120000133	BRACKET	TATA spare parts
J3120000175	DASH BOARD COVER	TATA spare parts
J3120001126	SPRING FOR CATCH	TATA spare parts
J3120001160	TMB EMBLEM	TATA spare parts
J3120001323	KNOTTED CHAIN	TATA spare parts
J3120001392	CABLE LUG	TATA spare parts
J80250000001	FIRST AID BOX	TATA spare parts
J80250000002	BALATA BELTING 6X60X3450	TATA spare parts
J80250000003	SKIRT PANELS RH SIDE DIESEL TANK	TATA spare parts
J80250000004	SKIRT PANELS LH SIDE BATTERY SERVICEABIL	TATA spare parts

J8025000005	HEAVY DUTY FORGED HINGE(REAR DOOR )	TATA spare parts
J8025000006	LOCK (REAR DOOR)	TATA spare parts
J8025000007	RUBBER BEADING WIND SHIELD GLASS	TATA spare parts
J8025000008	BULLET PRF WIND SHIELD LH (RHD) BS2	TATA spare parts
J8025000009	BULLET PROOF WIND SHIELD RH (RHD) BS2	TATA spare parts
J8025000010	BP FIRING PORT GLASS 40 MM.THK.	TATA spare parts
J8025000011	BP SIDE GLASS 45MM.THK.	TATA spare parts
J8025000012	RUBBER BEADING BP SIDE GLASS	TATA spare parts
J8025000013	BP CAB DOOR GLASS 45MM.THK. RH DRIVER SI	TATA spare parts
J8025000014	BP CAB DOOR GLASS 45MM.THK. LH CO-DRIVER	TATA spare parts
J8025000015	RUBBER BEADING CAB DOOR GLASS	TATA spare parts
J8025000016	RUBBER DOOR SEAL CAB DOOR & REAR DOOR	TATA spare parts
J8025000017	FIRING PORT ASSY.	TATA spare parts
J8025000018	FIRING PORT LID HINGE(2")	TATA spare parts
J8025000019	FIRING PORT SPRING LOCK(MAGNETIC CATCHER	TATA spare parts
J8025000020	ASSY. SUSPENDED TROOPSEAT	TATA spare parts
J8025000021	WHEEL ARC V-RUBBER(TATA PANELS)	TATA spare parts
J8025000022	ROOF LIGHT 12V	TATA spare parts
J8025000023	FAN CABIN 12V(8" BLUE)	TATA spare parts
J8025000024	ROOF LAMP(SMALL) 12V	TATA spare parts
J8025000025	DRIVER CABIN ROUND LIGHT 12V	TATA spare parts
J8025000026	SPEAKER	TATA spare parts
J8025000027	SWITCH PLATE ( 4X7 BACKALITE SHEET)	TATA spare parts
J8025000028	PIANO SWITCHES	TATA spare parts
J8025000029	STEREO SYSTEM	TATA spare parts
J8025000030	KEVLAR ( BULLET PROOF ANTI-EXPLOSIVE MAT	TATA spare parts
J8025000031	CO-DRIVER SEAT REXINE	TATA spare parts
J8025000032	CHEQUERED PLATE	TATA spare parts
J8025000033	DICKEY PANEL(INTER LOCK)	TATA spare parts
J8025000034	REAR VIEW MIRROR	TATA spare parts
J8025000035	TURRET STOOL	TATA spare parts
J8025000036	U-BOLT DIA 16X350 LG.	TATA spare parts
J8025000037	U-BOLT DIA 16X275 LG.	TATA spare parts
J8025000038	ALUMINIUM PACKING 44X31X76	TATA spare parts
J8025000039	MUD FLAPS TATA	TATA spare parts
J8025000040	BUDJET LOCK COVER(DICKEY PANEL)	TATA spare parts
J8025000041	GRAB HANDLE BLACK(REAR DOOR)	TATA spare parts
J8025000042	GRAB HANDLE GREY(CAB DOOR TURRET&BONNE	TATA spare parts
J8025000043	MAGZINE HOLDER(REAR DOOR)	TATA spare parts
J8025000044	FIRE EXTINGUISHER 1KG.	TATA spare parts
J8025000045	FIRING PORT LID	TATA spare parts
J8025000046	CAB DOOR HINGE	TATA spare parts
J8025000047	INTERNAL PANEL (ABS)	TATA spare parts
J8025000048	HOOD BALANCER HYDRAULIC(280MM.)	TATA spare parts
J8025000049	TURRET BEARING	TATA spare parts
J8025000050	CAB DOOR LOCK RH (DRIVER SIDE)	TATA spare parts
J8025000051	CAB DOOR LOCK LH ( CO-DRIVER SIDE)	TATA spare parts

J80250000052	FOLDABLE FOOT STEP	TATA spare parts
J80250000053	TURRET ROLLER ASSY.	TATA spare parts
J80250000054	PARTITION FRAME (AL. FINISHER BP SIDE G	TATA spare parts
J80250000055	TURRET ROLLER	TATA spare parts
J80250000056	TURRET BUSH	TATA spare parts
J80250000057	CAB DOOR GLASS FIXER ( WING HEAD BOLT)	TATA spare parts
J80250000058	TOWER BOLT ( REAR DOOR)	TATA spare parts
J80250000059	RAILWAY LOCK (REAR DOOR)	TATA spare parts
J80250000060	TURRET CHAIN	TATA spare parts
J80250000061	LOCKING BOLT ( DRIVER & CO-DRIVER DOOR)	TATA spare parts
J80250000062	DOVE TAIL 3 STEP	TATA spare parts
JA071532URNL16	CKD CAB LPTA 715 LHD BSII 24V WITH AC FO	TATA spare parts
K-01-4038CAB-13	ASSY CAB COMPLETE 4038.S FITTED-TDCV	TATA spare parts
K-02-4038CAB-13	ASSY CAB 4038.S -ASSY LINE FITMENT PARTS	TATA spare parts
K-03-4038CAB-13	CAB 4038.S -ASSY -SPARE ITEMS	TATA spare parts
K-2414	SPLIT COTTER PIN	TATA spare parts
K-2618	SPLIT COTTER PIN	TATA spare parts
K03-4038CAB1312	CASE NO. 12 : MISCELLANEOUS-1	TATA spare parts
K03-4038CAB1316	CASE NO. 16 : MISCELLANEOUS-2	TATA spare parts
K03-4038CAB1319	CASE NO. 19 : CAB-1	TATA spare parts
K03-4038CAB1326	CASE NO. 26 : CAB KIT 1	TATA spare parts
K03-4038CAB1327	CASE NO. 27 : CAB KIT 2	TATA spare parts
K03-4038CAB1329	CASE NO. 29 : SHEET METAL PARTS	TATA spare parts
K63440000001	CAP METALLIC TUBELESS TYRE	TATA spare parts
K64720000001	FRONT CLAMP.( GUARD RAIL BRACKET OPEN )	TATA spare parts
K64720000002	MIDDLE CLAMP. ( GUARD RAIL BRACKET CLOSE	TATA spare parts
K64720000003	WINDOW ROD. ( WINDOW GUARD RAIL LH)	TATA spare parts
K67830000001	FRONT WINDSHIELD GLASS	TATA spare parts
K67830000002	REAR WINDSHIELD GLASS / EMERGENCY EXIT G	TATA spare parts
K67830000003	FIXED WINDOW GLASS 760 X 1465	TATA spare parts
K67830000004	FIXED WINDOW GLASS 760 X 1300	TATA spare parts
K67830000005	FIXED WINDOW GLASS 760 X 1130	TATA spare parts
K67830000006	FIXED WINDOW GLASS 490 X 1465	TATA spare parts
K67830000007	FIXED WINDOW GLASS 425 X 865	TATA spare parts
K67830000008	PASSENGER DOOR GLASS 172 X 1400	TATA spare parts
K67830000009	PASSENGER DOOR GLASS 283 X 1400	TATA spare parts
K67830000010	DRIVER DOOR GLASS	TATA spare parts
K67830000011	DRIVER DOOR QUARTER GLASS	TATA spare parts
K67830000012	HEAD LAMP	TATA spare parts
K67830000013	SIDE MARKER LAMP	TATA spare parts
K67830000014	SIDE BLINKER (FRONT SIDE DEFLECTOR/INDIC	TATA spare parts
K67830000015	SIDE BLINKER (FRONT SIDE DEFLECTOR/INDIC	TATA spare parts
K67830000016	TOP SIDE MARKER (AMBER)	TATA spare parts
K67830000017	SWITCHES - PIANO TYPE	TATA spare parts
K67830000018	TOGGLE SWITCH FOR PASSENGER DOOR	TATA spare parts
K67830000019	DOOR INDICATOR LAMP (ON DASHBOARD)	TATA spare parts
K67830000020	FLOURSCENT LAMP (TUBE LIGHTS)	TATA spare parts

K67830000021	TAIL LAMP - RED	TATA spare parts
K67830000022	TAIL LAMP - AMBER	TATA spare parts
K67830000023	TAIL LAMP - WHITE	TATA spare parts
K67830000026	LINK ROD DRIVER DOOR LOCK	TATA spare parts
K67830000028	FRONT FACE KIT	TATA spare parts
K67830000029	REAR FACE KIT	TATA spare parts
K67830000030	DASHBOARD	TATA spare parts
K67830000031	DOOR GLASS RUBBER BEADING	TATA spare parts
K67830000032	DOOR HINGES	TATA spare parts
K67830000033	DOOR BEARINGS/BUSHES	TATA spare parts
K67830000034	HINGE WITH HANDLE	TATA spare parts
K67830000035	COMPLETE PNEUMATICS KIT	TATA spare parts
K67830000037	RUBBER BEADING FOR WHEEL ARCH	TATA spare parts
K67830000038	T BEADING FOR WINDSHIELD	TATA spare parts
K67830000043	WIPER SYSTEM	TATA spare parts
K67830000044	RVM ASSY RH	TATA spare parts
K67830000045	RVM ASSY LH	TATA spare parts
K67830000046	GAS STAY	TATA spare parts
K67830000047	HAND STRAP	TATA spare parts
K67830000048	SALOON MIRROR	TATA spare parts
K67830000049	DESTINATION INDICATOR - SET	TATA spare parts
K67830000051	STICKER(JNNURM)	TATA spare parts
K67830000052	WEATHER STRIPS KIT	TATA spare parts
K91970000001	COOLING UNIT	TATA spare parts
K91970000002	POWER PACK UNIT	TATA spare parts
KBX4022	PAD KIT POT CALIPER NEW	TATA spare parts
L01402000001	D.E. Bearing	TATA spare parts
L01402000002	S.R.E. Ball Bearing	TATA spare parts
L01402000003	S.R.E. Bearing	TATA spare parts
L01402000004	Rotor Final Assembly	TATA spare parts
L01402000005	Stator Winding Final	TATA spare parts
L01402000006	Cover Moulding	TATA spare parts
L01402000007	Rotor Final Assembly	TATA spare parts
L01402000008	Stator Winding Final	TATA spare parts
L01402000009	SRE BALL BEARING	TATA spare parts
L01402000010	Rotor Assembly	TATA spare parts
L01402000011	Stator Assembly	TATA spare parts
L01402000012	Cover Moulding	TATA spare parts
L01402000013	Stator Winding Assy.	TATA spare parts
L01402000014	Rotor Assembly	TATA spare parts
L01402000015	Rectifier	TATA spare parts
L01402000016	D.E. Ball Bearing	TATA spare parts
L01402000017	Stator Winding Assy.	TATA spare parts
L01402000018	Rotor Assy.	TATA spare parts
L01402000019	Regulator	TATA spare parts
L01402000020	Rectifier Assy.	TATA spare parts
L01402000021	Regulator & Brush Box Assy.	TATA spare parts



L01402000022	DE Ball Bearing (Type BB1)	TATA spare parts
L01402000023	Regulator & B Box Assy.	TATA spare parts
L01402000024	Stator Winding Assy.	TATA spare parts
L01402000025	Armature Assy.	TATA spare parts
L01402000026	Brush Gear Assy.	TATA spare parts
L01402000027	Solenoid Switch	TATA spare parts
L01402000028	Solenoid Switch	TATA spare parts
L01402000029	Drive Assembly	TATA spare parts
L01402000030	Field Coil Assembly	TATA spare parts
L01402000031	Drive Assembly	TATA spare parts
L01402000032	Field Coil Assy.	TATA spare parts
L01402000033	Solenoid Switch	TATA spare parts
L01402000034	Armature Assembly	TATA spare parts
L01402000035	Armature Assembly	TATA spare parts
L01402000036	Field Coil Assembly	TATA spare parts
L01402000037	Brush Set ( Insul Brush )	TATA spare parts
L01402000038	Brush Set ( Earth )	TATA spare parts
L01402000039	Drive Assembly	TATA spare parts
L01402000040	Drive Assembly	TATA spare parts
L01402000041	Brush Gear Assembly	TATA spare parts
L01402000042	Brush Carrier Assembly	TATA spare parts
L01402000043	Plunger Assy.	TATA spare parts
L01402000044	Drive Assembly	TATA spare parts
L01402000045	Brush Gear Assembly	TATA spare parts
L01402000046	Armature Assembly	TATA spare parts
L01402000047	Field Coil Assembly	TATA spare parts
L01402000049	Field Coil Assembly	TATA spare parts
L01402000050	Solenoid Switch (w/o Plunger Assy.)	TATA spare parts
L01402000051	Regulator & Brush Box Assy.	TATA spare parts
L01402000052	Plunger Assembly	TATA spare parts
L01402000053	Plunger Assembly	TATA spare parts
L01402000054	Regulator & B. Box Assy.	TATA spare parts
L01402000055	Rectifier Assembly (RA65)	TATA spare parts
L01402000056	Rectifier Assembly (RA65)	TATA spare parts
L01402000057	Rectifier Assembly	TATA spare parts
L01402000058	Oil seal	TATA spare parts
L01402000059	Oil seal	TATA spare parts
L01402000060	Oil seal	TATA spare parts
L01402000061	DE Bearing Assembling Kit	TATA spare parts
L01402000062	BALL	TATA spare parts
L01402000063	ALTERNATOR	TATA spare parts
L01402000064	ALTERNATOR	TATA spare parts
L01402000065	ALTERNATOR	TATA spare parts
L01402000066	ALTERNATOR	TATA spare parts
L01402000067	ALTERNATOR	TATA spare parts
L01402000068	ALTERNATOR	TATA spare parts
L01402000069	STARTER MOTOR	TATA spare parts

L01402000070	STARTER MOTOR	TATA spare parts
L01402000071	WIPER MOTOR	TATA spare parts
L01402000072	WIPING SYSTEM	TATA spare parts
L01402000073	WIPER MOTOR	TATA spare parts
L01402000074	COVER FIXING SCREW	TATA spare parts
L01402000075	SCREW (REG FIXING)	TATA spare parts
L01402000076	SCREW	TATA spare parts
L01402000077	SCREW FIXING	TATA spare parts
L01402000078	FIXING BOLT	TATA spare parts
L01402000079	THROUGH BOLT	TATA spare parts
L01402000080	NUT	TATA spare parts
L01402000081	NUT	TATA spare parts
L01402000082	SHAFT NUT	TATA spare parts
L01402000083	NUT (PULLEY)	TATA spare parts
L01402000084	NUT (PULLEY)	TATA spare parts
L01402000085	SPRING WASHER	TATA spare parts
L01402000086	SPRING WASHER	TATA spare parts
L01402000087	SPACING COLLAR	TATA spare parts
L01402000088	ASYMMETRIC FAN	TATA spare parts
L01402000089	RETAINER PLATE	TATA spare parts
L01402000090	STATOR ASSY	TATA spare parts
L01402000091	COVER MOULDING	TATA spare parts
L01402000092	SEAL	TATA spare parts
L01402000093	SEAL BRUSH BOX	TATA spare parts
L01402000094	SRE BRACKET ASSY	TATA spare parts
L01402000095	BRUSH BOX	TATA spare parts
L01402000096	DUST SEAL	TATA spare parts
L01402000097	BRUSH PLATE ASSY	TATA spare parts
L01402000098	D E BRACKET ASSY	TATA spare parts
L01402000099	PULLEY	TATA spare parts
L01402000100	FIXING BOLT	TATA spare parts
L01402000101	O RING	TATA spare parts
L01402000102	ROTOR ASSY	TATA spare parts
L01402000103	RETAINING PLATE	TATA spare parts
L01402000104	SPACING COLLAR	TATA spare parts
L01402000105	SRE BALL BEARING	TATA spare parts
L01402000106	CHECK VALVE ASSY	TATA spare parts
L01402000107	CONNECTER ASSY (DELIVERY)	TATA spare parts
L01402000108	SLIP RING	TATA spare parts
L01402000109	SUCTION CONNECTOR ASSY	TATA spare parts
L01402000110	FAN	TATA spare parts
L01402000111	INSUL BUSH	TATA spare parts
L01402000112	INSUL BUSH	TATA spare parts
L01402000113	CAPACITOR ASSY	TATA spare parts
L01402000114	FUSE	TATA spare parts
L01402000115	STUD	TATA spare parts
L01402000116	INSERT (BOTTOM)	TATA spare parts

L01402000117	INSERT SRE	TATA spare parts
L01402000118	D E BRACKET ASSY	TATA spare parts
L01402000119	SRE BRACKET ASSY	TATA spare parts
L01402000120	D E BALL BEARING	TATA spare parts
L01402000121	D E BRACKET ASSY	TATA spare parts
L01402000122	RETAINING PLATE	TATA spare parts
L01402000123	PULLEY	TATA spare parts
L01402000124	SPACING COLLAR	TATA spare parts
L01402000125	INSUL BUSH	TATA spare parts
L01402000126	CUP WASHER	TATA spare parts
L01402000127	SUCT CONNECTOR ASSY	TATA spare parts
L01402000128	ROTOR ASSY	TATA spare parts
L01402000129	PULLEY (6 GROOVE)	TATA spare parts
L01402000130	INSUL BUSH	TATA spare parts
L01402000131	COLLAR	TATA spare parts
L01402000132	ASYMMETRIC FAN	TATA spare parts
L01402000133	ASYMMETRIC FAN	TATA spare parts
L01402000134	DE BRACKET ASSY	TATA spare parts
L01402000135	PULLEY	TATA spare parts
L01402000136	SRE BRACKET ASSY	TATA spare parts
L01402000137	VACCUM PUMP ASSY	TATA spare parts
L01402000138	SRE BRACKET ASSY	TATA spare parts
L01402000139	DE BRACKET ASSY	TATA spare parts
L01402000140	STATOR WINDING ASSY	TATA spare parts
L01402000141	STATOR WINDING ASSY	TATA spare parts
L01402000142	BRUSH	TATA spare parts
L01402000143	COVER MOULDING ASSY	TATA spare parts
L01402000144	DE BRACKET ASSY	TATA spare parts
L01402000145	PULLEY	TATA spare parts
L01402000146	ROTOR ASSY	TATA spare parts
L01402000147	RECTIFIER ASSY	TATA spare parts
L01402000148	3RU RECTIFIER ASSY	TATA spare parts
L01402000149	REGULATOR	TATA spare parts
L01402000150	RECTIFIER ASSY	TATA spare parts
L01402000151	PULLEY ASSEMBLING KIT	TATA spare parts
L01402000152	DE BEARING ASSEMBLING KIT	TATA spare parts
L01402000153	RECTIFIER ASSEMBLING KIT	TATA spare parts
L01402000154	PLUG MLDG ASSEMBLING KIT	TATA spare parts
L01402000155	FINAL GEAR ASSY	TATA spare parts
L01402000156	VACUUM PUMP ASSY	TATA spare parts
L01402000157	STATOR WINDING ASSY	TATA spare parts
L01402000158	BEARING & SEALLING ASSEMBLING KIT	TATA spare parts
L01402000159	FASTENERS ASSEMBLING KIT	TATA spare parts
L01402000160	VAC PUMP FASTENER KIT	TATA spare parts
L01402000161	SRE BRACKET ASSY	TATA spare parts
L01402000162	FASTENERS ASSEMBLING KIT	TATA spare parts
L01402000163	ROTOR ASSY	TATA spare parts

L01402000164	PLUNGER ASSY	TATA spare parts
L01402000165	PLUNGER RETURN SPRING	TATA spare parts
L01402000166	ARMATURE ASSY	TATA spare parts
L01402000166DF	STARTER ARMATURE-ACE/MAGIC	TATA spare parts
L01402000167	BRUSH GEAR ASSY	TATA spare parts
L01402000168	SPINDLE ASSY	TATA spare parts
L01402000169	TER BASE ASSY	TATA spare parts
L01402000170	SOLOINOID SWITCH ASSY	TATA spare parts
L01402000171	FIXING BRACKET ASSY	TATA spare parts
L01402000172	C E BRACKET ASSY	TATA spare parts
L01402000172DF	STARTER CE BRACKET-ACE/MAGIC	TATA spare parts
L01402000173	ARMATURE ASSEMBLING KIT	TATA spare parts
L01402000174	FASTENERS ASSEMBLING KIT	TATA spare parts
L01402000175	SEALING ASSEMBLING KIT	TATA spare parts
L01402000176	ARMATURE ASSEMBLING KIT	TATA spare parts
L01402000177	BRUSH BOX KIT	TATA spare parts
L01402000178	FASTENERS ASSEMBLING KIT	TATA spare parts
L01402000179	BEARING BUSH ASSEMBLING KIT	TATA spare parts
L01402000180	BEARING BUSH ASSEMBLING KIT	TATA spare parts
L01402000181	BRUSH ASSEMBLING KIT	TATA spare parts
L01402000182	ARMATURE ASSY	TATA spare parts
L01402000183	SOLOINOID SWITCH ASSY	TATA spare parts
L01402000184	PLUNGER RETURN SPRING	TATA spare parts
L01402000185	PLUNGER ASSY	TATA spare parts
L01402000186	SHAFT ASSY (GEAR)	TATA spare parts
L01402000187	CONNECTOR BRUSH ASSY	TATA spare parts
L01402000188	BRUSH SPRING	TATA spare parts
L01402000189	ARMATURE ASSY	TATA spare parts
L01402000190	INTERNAL GEAR ASSY	TATA spare parts
L01402000191	DUST COVER	TATA spare parts
L01402000192	FIXING BRACKET ASSY	TATA spare parts
L01402000193	DRIVE ASSY	TATA spare parts
L01402000194	DOWEL	TATA spare parts
L01402000195	ENG LEVER ASSY	TATA spare parts
L01402000196	CE BRACKET ASSY	TATA spare parts
L01402000197	SHROUD	TATA spare parts
L01402000198	FIELD COIL ASSY	TATA spare parts
L01402000199	FIXING BRACKET ASSY	TATA spare parts
L01402000200	DRIVE ASSY	TATA spare parts
L01402000201	GEAR ASSY	TATA spare parts
L01402000202	STOPPER	TATA spare parts
L01402000203	PACKING	TATA spare parts
L01402000204	PIVOT PLATE	TATA spare parts
L01402000205	JUMP RING	TATA spare parts
L01402000206	ENGAGING LEVER	TATA spare parts
L01402000207	STR TERMINAL NUT	TATA spare parts
L01402000208	FLANGE SCREW	TATA spare parts

L01402000209	FLANGE SCREW	TATA spare parts
L01402000210	BALL	TATA spare parts
L01402000211	NEEDLE BEARING	TATA spare parts
L01402000212	CE BRACKET ASSY	TATA spare parts
L01402000213	DRIVE ASSY	TATA spare parts
L01402000214	ENGAGING LEVER ASSY	TATA spare parts
L01402000215	SOLONOID SWITCH ASSY	TATA spare parts
L01402000216	FIELD COIL ASSY	TATA spare parts
L01402000217	BRUSH GEAR ASSY	TATA spare parts
L01402000218	SHROUD	TATA spare parts
L01402000219	PLUNGER ASSY	TATA spare parts
L01402000220	YOKE ASSY	TATA spare parts
L01402000221	LOCATING PLATE	TATA spare parts
L01402000222	FINAL GEAR	TATA spare parts
L01402000223	COVER PLATE	TATA spare parts
L01402000224	SHAFT & LINK PIN	TATA spare parts
L01402000225	WORM WHEEL	TATA spare parts
L01402000226	THROUGH BOLT	TATA spare parts
L01402000227	GEAR BOX ASSY	TATA spare parts
L01402000228	FINAL GEAR ASSY	TATA spare parts
L01402000229	BEARING BUSH	TATA spare parts
L01402000230	SPHERICAL BEARING	TATA spare parts
L01402000231	WORM WHEEL & PINION	TATA spare parts
L01402000232	YOKE ASSY	TATA spare parts
L01402000233	ARMATURE ASSY	TATA spare parts
L01402000234	GEAR BOX & BEARING ASSY	TATA spare parts
L01402000235	ARMATURE ASSY	TATA spare parts
L01402000236	ARMATURE ASSY	TATA spare parts
L01402000237	GEAR & SLIP RING ASSY	TATA spare parts
L01402000238	THRUST SCREW	TATA spare parts
L01402000239	BALL BEARING	TATA spare parts
L01402000240	GEAR BOX ASSY	TATA spare parts
L01402000241	SHAFT & LINK PIN	TATA spare parts
L01402000242	YOKE POLE & BEARING ASSY	TATA spare parts
L01402000243	MOUNTING BRACKET	TATA spare parts
L01402000244	BRUSH PLATE & SWITCH ASSY	TATA spare parts
L01402000245	COVER & BRUSH PLATE ASSY	TATA spare parts
L01402000246	MOTOR MOUNTING BRACKET	TATA spare parts
L01402000247	GASKET	TATA spare parts
L01402000248	ARMATURE & BEARING ASSY	TATA spare parts
L01402000249	BRUSH PLATE & SWITCH ASSY	TATA spare parts
L01402000250	FASTENERS/ SEALING KIT	TATA spare parts
L01402000251	FASTENERS / SEALING ASSY KIT	TATA spare parts
L01402000252	ROTARY LINK ASSY	TATA spare parts
L01402000253	COVER & BRUSH PL ASSY	TATA spare parts
L01402000254	FASTENERS / SEALING KIT	TATA spare parts
L01402000255	SCREW	TATA spare parts

L01402000256	KEY	TATA spare parts
L01402000257	O RING	TATA spare parts
L01402000258	WIPER MOTOR	TATA spare parts
L01402000259	WIPER MOTOR	TATA spare parts
L01402000260	STARTER MOTOR	TATA spare parts
L01402000261	RECTIFIER ASSY	TATA spare parts
L01402000262	REC ASSY	TATA spare parts
L01402000263	WIPER MOTOR	TATA spare parts
L01402000264	INSERT (BOTTOM)	TATA spare parts
L01402000265	SLIDING BUSH	TATA spare parts
LC105A	BEARING REMOVER (PULLER)	TATA spare parts
LFOGLT	FOG LAMP WITH BRACKET	TATA spare parts
LU9030595	CASTLE NUT	TATA spare parts
M-111230	VALVE PLATE ASSY-A/C	TATA spare parts
M66550000001	HOUSING	TATA spare parts
M66550000002	TERMINAL	TATA spare parts
M66550000003	HOUSING	TATA spare parts
M66550000004	TERMINAL	TATA spare parts
M66550000005	GUM SEAL	TATA spare parts
M66550000006	HOUSING	TATA spare parts
M66550000007	TERMINAL	TATA spare parts
M66550000008	TERMINAL	TATA spare parts
M66550000009	TERMINAL	TATA spare parts
M66550000010	HOUSING	TATA spare parts
M69070000001	OIL SEAL	TATA spare parts
M69070000001AE	OIL SEAL 2523	TATA spare parts
M69070000002	CARRIER ASSY DIFFERENTIAL	TATA spare parts
M69070000003	SLEEVE- OIL SEAL	TATA spare parts
M69070000004	KIT FASTENER BRG CAGE	TATA spare parts
M69070000005	SHIFT FORK & YOKE ASSY	TATA spare parts
M69070000006	BRG. CUP & CONE	TATA spare parts
M69070000007	COMPANION FLANGE ASSY	TATA spare parts
M69070000008	BEAM ASSY.REAR-FWD	TATA spare parts
M69070000009	CARRIER MTG.FASTENERS KIT	TATA spare parts
M69070000010	CARRIER ASSY.DIFFERENTIAL	TATA spare parts
M69070000011	BEAM ASSY.REAR-RWD	TATA spare parts
M69070000012	DRIVE HEAD ASSY FWD REAR	TATA spare parts
M74770000001	WINDOW SLIDING (590X388 MM) LH SIDE	TATA spare parts
M74770000002	WINDOW SLIDING (590X388.MM) RH SIDE	TATA spare parts
M74770000003	WINDOW FIXED (395X205 MM) FRONT SIDE	TATA spare parts
M74770000004	WINDOW SLIDING (485X370 MM) REAR SIDE	TATA spare parts
M74770000005	REAR DOOR WINDOW (637X487.MM)	TATA spare parts
M74770000006	COMMUNICATION WINDOW (690X360) MM	TATA spare parts
M74770000007	CABIN WINDOW (600X335)	TATA spare parts
M74770000008	TROOP CABIN PROTECTION GRILL RH	TATA spare parts
M74770000009	TROOP CABIN PROTECTION GRILL LH	TATA spare parts
M74770000010	TROOP CABIN PROTECTION GRILL FRONT	TATA spare parts

M74770000011	TROOP CABIN PROTECTION GRILL REAR	TATA spare parts
M74770000012	TROOP CABIN REAR DOOR GRILL	TATA spare parts
M74770000013	PROTECTION GRILL DRIVER CABIN FRONT WIND	TATA spare parts
M74770000014	PROTECTION GRILL DRIVER CABIN WINDOW RH	TATA spare parts
M74770000015	PROTECTION GRILL DRIVER CABIN WINDOW LH	TATA spare parts
M74770000016	PROTECTION GRILL HEAD LIGHT	TATA spare parts
M74770000017	PROTECTION GRILL TAIL LIGHT	TATA spare parts
M74770000018	FRP CANOPY	TATA spare parts
M74770000019	CANOPY DOOR SWING AIR SPRING	TATA spare parts
M74770000020	FRP WHEEL GUARD RH	TATA spare parts
M74770000021	FRP WHEEL GUARD LH	TATA spare parts
M74770000022	RIFLE BUTT CLIPS	TATA spare parts
M74770000023	WATER TANK	TATA spare parts
M74770000024	INSTRUCTION SHEET	TATA spare parts
M74770000025	EXPLOSION SUPPRESSION MATERIAL IN DIESEL	TATA spare parts
M74770000026	FLOOD LIGHT	TATA spare parts
M74770000027	EMERGENCY LIGHT	TATA spare parts
M74770000028	ELECTRICAL WIRING HARNES	TATA spare parts
M74770000029	VINYL 207 VAJRA STICKER	TATA spare parts
M74770000030	GENSET	TATA spare parts
M74770000031	MTSL	TATA spare parts
M74770000032	COMMANDO LIGHT	TATA spare parts
M74770000033	TEA FLASK	TATA spare parts
M74770000034	FAN	TATA spare parts
M74770000035	FIRE EXTINGUISHER	TATA spare parts
M74770000036	FIRST AID BOX	TATA spare parts
M74770000037	FM RADIO WITH MP3	TATA spare parts
M74770000038	21 W DC LAMP	TATA spare parts
MAACEE20UNKR	ACE GLIDER KIT	TATA spare parts
OILBPMKAUTRAN2	MAK TATA MOTORS AUTRAN II	TATA spare parts
MF552320SRLR17	CABIN WITH TRIM PARTS FITTED ACE HT	TATA spare parts
MS284	SLIDE HAMMER WITH ADAPTOR	TATA spare parts
MSP25/24	REPAIR KIT (MAJOR) SPRING BRAKE ACTUATOR	TATA spare parts
MSP25/27	REPAIR KIT SPRING BRAKE ACTUATOR T-20/24	TATA spare parts
MSP25/33	REPAIR KIT SPRING BRAKE ACTUATOR T-24/75	TATA spare parts
MSP25/39	REPAIR KIT SPRING BRAKE ACTUATOR T-20/75	TATA spare parts
MSP3/93	REPAIR KIT GRADUATED HAND BRAKE VALVE	TATA spare parts
MSP3/98	REPAIR KIT DRYING & DISTRIBUTION UNIT HI	TATA spare parts
MSP6/24	REPAIR KIT DUAL BRAKE VALVE	TATA spare parts
MSP8/73	BRAKE CHAMBER REPAIR KIT	TATA spare parts
MX-0-1001	NUT	TATA spare parts
MX-10-0601	WASHER M6	TATA spare parts
MX-3-0602	SPRING WASHER M 6	TATA spare parts
MX-3-0801	WASHER M8	TATA spare parts
MX-3-1001	SPRING WASHER M 10	TATA spare parts
MX-3-1201	WASHER M12	TATA spare parts
MX-8-0603	BOLT M6 X 55	TATA spare parts

MX-8-0607	HEX SCREW	TATA spare parts
MX-8-0801	SCREW M8 X 14	TATA spare parts
MX-8-0803	SCREW M8X25	TATA spare parts
MX-8-0806	SCREW M8 X 20	TATA spare parts
MX-8-0810	SCREW M8X30	TATA spare parts
MX-8-1001	SCREW M 10 X 20	TATA spare parts
MX-8-1002	SCREW M 10 X 25	TATA spare parts
MX-8-1003	SCREW M10 X 35	TATA spare parts
MX-8-1004	BOLT M10 X 40	TATA spare parts
MX-8-1005	BOLT M10 X 55	TATA spare parts
MX-8-1006	BOLT M 10 X 30	TATA spare parts
MX-8-1007	BOLT M10X50	TATA spare parts
MX-8-1012	BOLT M 10 X 100	TATA spare parts
MX-8-1067	BOLT M 10 X 60	TATA spare parts
MX-8-1209	SCREW M 12 X 25	TATA spare parts
MX-9-0601	NUT M 6	TATA spare parts
MX-9-1001	NUT M10 X 1.5	TATA spare parts
MX-9-1204	SELF LOCKING NUT M12	TATA spare parts
MX-9-1602	NUT M 16	TATA spare parts
MX30602	WASHER	TATA spare parts
N80270000001	FRP FRONT SHOW	TATA spare parts
N80270000002	REAR WIND SHIELD SINGLE PIECE	TATA spare parts
N80270000003	ROUNDED BOX SWITCH	TATA spare parts
N80270000004	FOG LAMP WITH BRACKET	TATA spare parts
N80270000005	DOOR CLOSER R/KIT 24 VOLT-SOLENOID VALVE	TATA spare parts
N80270000006	DOOR CLOSER REPAIR KIT 24 VOLTS CYLINDER	TATA spare parts
N80270000007	SIDE WINDOW	TATA spare parts
NEWEOLCATRXST15W40	CAST RX SUP TUR CI4+ 15W40 (AMC 16L PACK)	TATA spare parts
NIU_264160030103	ASSY.CAB COMPLT.-RHD(LPT-709H EX2 BS-III	TATA spare parts
O06016000001	RADIAL BALL BEARING (6001)	TATA spare parts
O16323000072	AL-EXTRUSION (ROOF INNER)	TATA spare parts
O16323000073	AL-EXTRUSION (ROOF INNER)	TATA spare parts
O16353000001	AL-EXTRUSION (SIDE OUTER-CTB)	TATA spare parts
O16404000005	AL-EXTRUSION - RAIN CHANNEL BS6	TATA spare parts
O16404000013	AL-EXTRUSION - RAIN CHANNEL	TATA spare parts
O16559000005	AL EXTRUSION FOR CONCEALED WINDOW - PC(L	TATA spare parts
O16560000041	AL. EXTRUSION CRESCENT TYPE L=4 MTR	TATA spare parts
O16563000004	AL-EXTRUSION(VOLVO TYPE-OUTER)(L=4.7MTR)	TATA spare parts
O17129000230	PIPE (ERW) DIA32 WITH PVC SLEEVE WITH CU	TATA spare parts
O17145000001	PIPE/ERW (SKTM 11 19DIA X 2.0 THK)	TATA spare parts
O17146000020	MS PIPE (PERCPC12.75)(PC)	TATA spare parts
O17205000001	M.S PIPE 28.0 DIA X 2 THK ( L = 0.550 MT	TATA spare parts
O17205000053	PIPE/ERW(28DIA)L=3MTR	TATA spare parts
O20231040001	WEAT.STRIP (PASS.DR-MDL-SMALL D)	TATA spare parts
O20231040007	WEAT.STRIP (PASS.DR-MDL-SMALL D)	TATA spare parts
O20231040008	WEAT.STRIP (PASS.DR-MDL-SMALL D)	TATA spare parts
O2023104001	WEAT.STRIP (PASS.DR-MDL-SMALL D)	TATA spare parts



O20231040136	WEATHER STRIP	TATA spare parts
O20231050001	WEAT.STRIP (PASS.DR-FLAP/SHAFT)	TATA spare parts
O20412000075	PVC EXTRUSION (BLACK-WAIST RAIL) (L=2300	TATA spare parts
O20430000052	PVC EXTRUSION (ROOF INNER-WHITE)	TATA spare parts
O20455000002	WEATHER STRIP (CENTRE-5PC WINDSHIELD) (	TATA spare parts
O20455000009	WEATHER STRIP(L=1.5MTR)	TATA spare parts
O20455000010	WEATHER STRIP (CENTRE-5PC WINDSHIELD)	TATA spare parts
O20466000001	GUTTER RUBBER BEADING (L=10MTR)	TATA spare parts
O20466000009	GUTTER RUBBER BEADING (L=4.5MTR) BS6	TATA spare parts
O20802000001	STOPPER (ENTRANCE DOOR) BS6	TATA spare parts
O20840010005	END CAP-OUTER EXTRUSION (CTB) (LH)	TATA spare parts
O20840010007	END CAP-OUTER EXTRUSION (CTB) (RH)	TATA spare parts
O20910000001	RUBBER PAD (70X48)(GREY)	TATA spare parts
O20910000003	HANDLE PAD	TATA spare parts
O20910000004	RUBBER PAD (74X54)(GREY)	TATA spare parts
O20933XX0001	WHEEL ARCH BEADING WITH METAL PLATE	TATA spare parts
O21300000001	BUSH (43ODX38ID)	TATA spare parts
O21301000001	END BUSH FOR GUARD RAIL	TATA spare parts
O21301000002	END BUSH	TATA spare parts
O21303000001	BUSH (AL.PIPE)	TATA spare parts
O21303000003	BUSH (AL.PIPE)	TATA spare parts
O21316000004	WAIST RAIL EXTRUSION(L=3.5MTR)	TATA spare parts
O26010000001	HINGE ASSY (WITHOUT HANDLE) (PC)	TATA spare parts
O26010000003	HINGE ASSY(PASS DOOR-W/O HANDLE) (PC)	TATA spare parts
O26010000004	HINGE ASSY(PASS DOOR-WITH HANDLE) (PC)	TATA spare parts
O26010000005	HINGE ASSY (WITH HANDLE)	TATA spare parts
O26010000006	HINGE ASSY (WITHOUT HANDLE)	TATA spare parts
O26321020001	DOOR BRUSH (55X20X320MM)	TATA spare parts
O43520220001	PIPE BRACKET-BASE(32 DIA)(PC)	TATA spare parts
O43520300003	PIPE JOINT/T(38X32)(PC)	TATA spare parts
O43520300005	PIPE BRACKET (32X32)(PC)	TATA spare parts
O60005060002	FRONT PASS. DOOR GLASS	TATA spare parts
O60005080001	GLASS TINTED (285X875X5 THK)	TATA spare parts
O60005080002	GLASS TINTED (303X810X5 THK) DARK GREY 8	TATA spare parts
O60005080003	GLASS TINTED (323X810X5 THK) DARK GREY 8	TATA spare parts
O60005080005	GLASS TINTED (268X810X5 THK)	TATA spare parts
O60005080006	GLASS TINTED (288X810X5 THK)	TATA spare parts
O60005080007	GLASS TINTED (268X810X5 THK)50	TATA spare parts
O60005080008	GLASS TINTED (288X810X5 THK)50	TATA spare parts
O60005080009	GLASS TINTED (268X810X5 THK)	TATA spare parts
O60005080010	GLASS TINTED (288X810X5 THK)	TATA spare parts
O60005150025	GLASS (271X1540X5 THK)	TATA spare parts
O60005160004	GLASS CLEAR(225X1646X5 THK)	TATA spare parts
O60005160009	FRONT PASS. DOOR GLASS REAR	TATA spare parts
O60005160010	GLASS TINTED (225X1646X5 THK)	TATA spare parts
O60005160040	GLASS TINTED (288X1645X5 THK)	TATA spare parts
O60005170002	GLASS (265X1799X5 THK)	TATA spare parts

O60005170003	GLASS (288X1795X5 THK)	TATA spare parts
O60005180001	GLASS CLEAR(265X1815X5 THK)	TATA spare parts
O60005180003	GLASS TINTED (288X1835X5 THK)	TATA spare parts
O64605020001	DRIVER PARTITION GLASS (CLEAR)	TATA spare parts
O64605050001	PARTITION GLASS (506X572X5 THK)	TATA spare parts
O64605050002	PARTITION GLASS (506X572X5 THK)	TATA spare parts
O64605050006	PARTITION GLASS (506X572X5 THK)	TATA spare parts
O64605060001	GLASS (460X692X5 THK)	TATA spare parts
O64605070001	GLASS CLEAR(397X722X5 THK)	TATA spare parts
O64605070002	GLASS CLEAR(397X722X5 THK)	TATA spare parts
O64605070011	GLASS LIGHT GREEN TINT(397X722X5 THK)	TATA spare parts
O69015080001	GLASS TINTED (303X810X5 THK) DARK GREY 8	TATA spare parts
O69015080002	GLASS TINTED (268X810X5 THK)	TATA spare parts
O69015080003	GLASS TINTED (268X810X5 THK)	TATA spare parts
O69015160005	FRONT PASS. DOOR GLASS FRONT	TATA spare parts
O69015160017	GLASS TINTED (268X1645X5 THK)	TATA spare parts
O69015170001	GLASS (268X1795X5 THK)	TATA spare parts
O69015180001	GLASS TINTED (268X1835X5 THK)	TATA spare parts
OILBPMAC80WEP	MAK TATA MOTORS SPIROL 80WEP	TATA spare parts
OILBMAKCI415W40	MAK TATA MOTORS CI4 PLUS 15W40 (CI4)	TATA spare parts
OILBMAKGM15W40	MAK TATA GEM SAE 15W40	TATA spare parts
OILBMAKTMG15W40	MAK TATA MOTORS GEM 15W40	TATA spare parts
OILBMAKTMGM15W40	MAK TATA MOTORS GEM 15W40	TATA spare parts
OILCASLDTA80W140	Axle Extended Drain GL5 SAE 80W140	TATA spare parts
OILCASLDTRO80W90	MANL EXT DRN GL-4 80W90	TATA spare parts
OILCAST75W85	Syntrans WT 75W85	TATA spare parts
OILCASTATFDEX2	Power Steering Fluid ML0020	TATA spare parts
OILCASTBRKFLUDOT4	CASTROL BRAKE FLUID DOT 4	TATA spare parts
OILCASTLDTAO80W140	Axle Extended Drain GL-5 80W-140	TATA spare parts
OILCASTLDTRO80W90	Manual Extended Drain GL-4 80W-90	TATA spare parts
OILCASTRXCNGT	CASTROL RX CNG (T) 15W40	TATA spare parts
OILCASTRXSMFE10W40	Castrol RX Super Max Fuel Saver 10W40	TATA spare parts
OILCASTRXSMX15W40	Castrol RX Supermax 15W40(CH4)	TATA spare parts
OILCASTRXSTURB15W40	Castrol RX Super Turbo 15W40(CI4 Plus)	TATA spare parts
OILCASTRXSUPER15W40	Castrol RX Super 15W40(CF4)	TATA spare parts
OILCASTRXTC15W40	Castrol RX Turbo TC 15W40 (CI4)	TATA spare parts
OILCASTTR80WEP	EXTREME PRESSURE 80EP	TATA spare parts
OILCASTTRANSYND	OILCASTTRANSYND	TATA spare parts
OILCASTVCTNRXFS10W40	CASTROL VECTON RX FUEL SAVER 10W40	TATA spare parts
OILCASVCTR10W40	Castrol VECTON RX FUEL Saver 10W40	TATA spare parts
OILCASXSMX15W40	Rx Super Max 15W40 (CH4)	TATA spare parts
OILCASXSTUR15W40	Rx Super Turbo 15W40 (CI4+)	TATA spare parts
OILCASXSUP15W40	Rx Super 15W40 (CF4)	TATA spare parts
OILDIFLL85W	Castrol Extra Long Life Rear Axle Oil 85W140	TATA spare parts
OILDIFLL85W3	MAK TATA Motors Spirol LL 85W140	TATA spare parts
OILENBP15W40	MAK TATA MOTORS GENUINE CH4 15W-40	TATA spare parts
OILENCAS15W40	Castrol RX Turbo 15 W- 40	TATA spare parts

OILENG15W40	MAK TATA Motors Genuine Engine Oil 15W40	TATA spare parts
OILGEARLL80W90	Castrol Extra Long Life Gear Oil 80W90	TATA spare parts
OILGEARLL80W90T	MAK TATA Motors Spirol LL 80W90	TATA spare parts
OILGREASEAP2	GREASE AP-2-500G	TATA spare parts
OILGRSERV80W90	Servo Synchro TM	TATA spare parts
OILMOBILTMGO80W90	MOBIL DELVAC TM GENUINE GEAR OIL 80W90	TATA spare parts
OILMOBILTMRO85W140	MOBIL DELVAC TM GENUINE REAR AXLE OIL 85W	TATA spare parts
OILRASERV85W140	Servo Gear Axle TM	TATA spare parts
OILRXCNG15W40	RX CNG 15W40	TATA spare parts
OILRXSUPERMAX	Castrol Rx Super Max 15W40	TATA spare parts
OILSAE30CASTR	ENGINE OIL CRD 30-CASTROL	TATA spare parts
OILSERVOTM80W140LL	IOCL Long life RA Oil	TATA spare parts
OILSERVOTM80W90LL	IOCL Long life gear oil	TATA spare parts
OILSERVTML80W140	SERVO TM 80W-140 LL	TATA spare parts
OILSERVTML80W90	SERVO TM 80W-90 LL	TATA spare parts
OILSHELREMT15W40	Shell Remula T4 15W40 CI4 Plus	TATA spare parts
OILSHELX80W140LL	SHELL SPIRAX T2 A 80W140 LL	TATA spare parts
OILSHELX80W90	Shell Spirax T2 G 80 W 90	TATA spare parts
OILSHELX80W90LL	SHELL SPIRAX T2 G 80W90 LL	TATA spare parts
OILSHELX85W140	Shell Spirax T2 A 85 W 140	TATA spare parts
OILSHELXSL80W140	Shell Spirax T2 A 80W140 LL	TATA spare parts
OILSHELT215W40	Shell Rimula T2 15 w 40 ( CF4)	TATA spare parts
OILSHELT315W40	Shell Rimula T3 15 w 40 ( CH4)	TATA spare parts
OILSHELT5E10W30	SHELL RIMULA T5 E 10W30 CI4 PLUS	TATA spare parts
OILSPIROLTM80W140X	MAK TM SPIROL XL 80W 140	TATA spare parts
OILSPIROLTM80W140XL	MAK TM SPIROL XL 80W140	TATA spare parts
OILSPIROLTM80W90XL	MAK TM SPIROL XL 80W90	TATA spare parts
OILSPITMX80W140	MAK TM SPIROL XL 80W140	TATA spare parts
OILSPITMX80W90	MAK TM SPIROL XL 80W90	TATA spare parts
OSRAM94196	HALOGEN BULB-75/70W	TATA spare parts
P06700000001	SLD MOTOR COVER - L TYPE	TATA spare parts
P06700000002	SEALING SCREW (FOR 1NO.OF L TYPE MOTOR C	TATA spare parts
P06700000003	STAR SCREW(FOR 1NO.OF L TYPE MOTOR COVER	TATA spare parts
P06700000004	SEALING KIT	TATA spare parts
P06700000005	INSTALLATION KIT	TATA spare parts
P090-107	PACKSET FOR STAGE	TATA spare parts
P090-108	PACKSET FOR STAGE	TATA spare parts
P090-109	PACKSET FOR STAGE	TATA spare parts
P090-110	COMPLETE PACKSET	TATA spare parts
P090-181	BOTTOM PLATE TYPE	TATA spare parts
P090-182	LOCKING PLATE TYPE	TATA spare parts
P090-240	TIPPING CYLINDER	TATA spare parts
P090-241	TIPPING CYL	TATA spare parts
P090-242	STAGE	TATA spare parts
P090-243	STAGE	TATA spare parts
P090-244	BASE	TATA spare parts
P090-246	COVER	TATA spare parts

P090-337	BASE O RING 100 X 3	TATA spare parts
P090-801	PISTON	TATA spare parts
P6671000001	WINDOW GLASS TOP FIXED (A)	TATA spare parts
P6671000002	WINDOW GLASS FRONT/REAR SLIDING (A)	TATA spare parts
P6671000003	WINDOW GLASS TOP FIXED (B)	TATA spare parts
P6671000004	WINDOW GLASS FRONT/REAR SLIDING (B)	TATA spare parts
P6671000005	WINDOW GLASS TOP FIXED (C)	TATA spare parts
P6671000006	WINDOW GLASS FRONT/REAR SLIDING (C)	TATA spare parts
P6671000007	WINDOW GLASS TOP FIXED (D)	TATA spare parts
P6671000008	WINDOW GLASS FRONT SLIDING (D)	TATA spare parts
P6671000009	WINDOW GLASS REAR SLIDING (D)	TATA spare parts
P6671000010	WINDOW GLASS FRONT/REAR SLIDING (E)	TATA spare parts
P6671000011	WINDOW GLASS TOP FIXED (F)	TATA spare parts
P6671000012	WINDOW GLASS FRONT/REAR SLIDING (F)	TATA spare parts
P6671000013	WINDOW GLASS FRONT/REAR SLIDING (G)	TATA spare parts
P6671000014	WINDOW GLASS TOP FIXED (H)	TATA spare parts
P6671000015	WINDOW GLASS FRONT/REAR SLIDING (H)	TATA spare parts
P6671000016	WINDOW LOCK	TATA spare parts
P6671000017	FRONT WINDSHIELD GLASS RH	TATA spare parts
P6671000018	FRONT WINDSHIELD GLASS LH	TATA spare parts
P6671000019	FRONT WINDSHIELD GLASS LH	TATA spare parts
P6671000020	FRONT WINDSHIELD GLASS RH	TATA spare parts
P6671000021	FRONT WINDSHIELD RUBER BEADING LH	TATA spare parts
P6671000022	FRONT WINDSHIELD RUBER BEADING RH	TATA spare parts
P6671000023	FRONT WINDSHIELD RUBER BEADING LH	TATA spare parts
P6671000024	REAR WINDSHIELD LH GLASS	TATA spare parts
P6671000025	REAR WINDSHIELD LH GLASS RUBER BEADING	TATA spare parts
P6671000026	REAR WINDSHIELD CENTRE GLASS.	TATA spare parts
P6671000027	REAR WINDSHIELD CENTRE GLASS RUBBER BEAD	TATA spare parts
P6671000028	REAR WINDSHIELD RH GLASS	TATA spare parts
P6671000029	REAR WINDSHIELD RH GLASS RUBER BEADING	TATA spare parts
P6671000030	PASSENGER DOOR GLASS	TATA spare parts
P6671000031	PASSENGER DOOR RUBBER BEADING	TATA spare parts
P6671000032	DRIVER PARTITION WINDOW GLASS	TATA spare parts
P6671000033	DRIVER PARTITION WINDOW GLASS BEADING /	TATA spare parts
P6671000034	PEEP WINDOW GLASS RH	TATA spare parts
P6671000035	SIDE MARKER LAMP	TATA spare parts
P6671000036	HEIGHT MARKER (RED)	TATA spare parts
P6671000037	HEIGHT MARKER (WHITE)	TATA spare parts
P6671000038	STOP SWITCH	TATA spare parts
P6671000039	NUMBER PLATE LAMP ASSY	TATA spare parts
P6671000040	SWITCHES - PIANO TYPE	TATA spare parts
P6671000041	SPOT LAMP (FOR PASSENGER/SALOON AREA)	TATA spare parts
P6671000042	FLOURSCENT LAMP (TUBE LIGHTS)	TATA spare parts
P6671000043	SALOON LAMP	TATA spare parts
P6671000044	NIGHT LAMP	TATA spare parts
P6671000045	BATTERY CABLE WITH SLEEVES.	TATA spare parts

P6671000046	BATTERY CABLE (INTERMEDIATE)	TATA spare parts
P6671000047	BATTERY TRAY	TATA spare parts
P6671000048	BATTERY TRAY BEARING	TATA spare parts
P6671000049	BATTERY TRAY CHAIN	TATA spare parts
P6671000050	TWO POLE CONNECTOR	TATA spare parts
P6671000051	THREE POLE CONNECTOR	TATA spare parts
P6671000052	BODY FUSE- 3A	TATA spare parts
P6671000053	BODY FUSE - 5A	TATA spare parts
P6671000054	BODY FUSE - 7.5A	TATA spare parts
P6671000055	BODY FUSE - 10A	TATA spare parts
P6671000056	BODY FUSE - 15A	TATA spare parts
P6671000057	DOOR HANDLE LOCK WITH KEY	TATA spare parts
P6671000058	DIKKI LOCK	TATA spare parts
P6671000059	DIKKI HINGE	TATA spare parts
P6671000060	DIKKI RUBBER BEADING	TATA spare parts
P6671000061	FRONT BUMPER COMPLETE	TATA spare parts
P6671000062	REAR BUMPER COMPLETE	TATA spare parts
P6671000063	DOOR ASSY COMPLETE	TATA spare parts
P6671000064	DOOR GLASS RUBBER BEADING	TATA spare parts
P6671000065	DOOR HINGES	TATA spare parts
P6671000066	DOOR BEARINGS/BUSHES	TATA spare parts
P6671000067	TOWER BOLT	TATA spare parts
P6671000068	HINGE WITH HANDLE	TATA spare parts
P6671000069	REAR BUMPER MTG BKT	TATA spare parts
P6671000070	CENTRE GRILL	TATA spare parts
P6671000071	CENTRE GRILL HINGE	TATA spare parts
P6671000072	CENTRE GRILL STAY ROD	TATA spare parts
P6671000073	FRONT FACE COMPLETE WITHOUT FITMENT AND	TATA spare parts
P6671000074	REAR FACE COMPLETE WITHOUT FITMENT AND P	TATA spare parts
P6671000075	REAR LADDER MTG. BKT	TATA spare parts
P6671000076	REAR LADDER COMPLETE	TATA spare parts
P6671000077	ROOF LOAD CARRIER	TATA spare parts
P6671000078	SIDE UNLADEN LADDER.	TATA spare parts
P6671000079	GEARBOX INSPECTION COVER	TATA spare parts
P6671000080	FUELTANK INSPECTION COVER	TATA spare parts
P6671000081	WIPER SYSTEM	TATA spare parts
P6671000082	SALOON MIRROR	TATA spare parts
P6671000083	DRIVER DOOR INNER HANDLE ASSY	TATA spare parts
P6671000084	FIRE EXTINGUISHER	TATA spare parts
P6671000085	FIRST AID BOX	TATA spare parts
P6671000086	SUNVISOR	TATA spare parts
P6671000087	WINDOW LH NO 1 BOTTOM SLIDING GLASS (A)	TATA spare parts
P6671000088	WINDOW LH NO 2 3 4 BOTTOM SLIDING GLASS	TATA spare parts
P6671000089	WINDOW REAR LH BOTTOM SLIDING GLASS (C)	TATA spare parts
P6671000090	WINDOW LH NO 1 TOP FIX GLASS (D)	TATA spare parts
P6671000091	WINDOW LH NO 2 3 4 TOP FIX GLASS (E)	TATA spare parts
P6671000092	WINDOW REAR LH TOP FIX GLASS (F)	TATA spare parts

P6671000093	PASSENGER DOOR GLASS (G)	TATA spare parts
P6671000094	EMERGENCY DOOR GLASS (G)	TATA spare parts
P6671000095	DRIVER DOOR GLASS (H)	TATA spare parts
P6671000096	PEEP WINDOW FIX GLASS (I)	TATA spare parts
P6671000097	DRIVER DOOR PIP WINDOW GLASS (J)	TATA spare parts
P6671000166	FRONT WINDSHIELD RUBER BEADING RH	TATA spare parts
P6671000167	FRONT WINDSHIELD RUBER BEADING LH	TATA spare parts
P6671000168	REAR WINDSHIELD GLASS RH	TATA spare parts
P6671000169	REAR WINDSHIELD GLASS LH	TATA spare parts
P6671000170	REAR WINDSHIELD RUBBER BEADING RH	TATA spare parts
P6671000171	REAR WINDSHIELD RUBBER BEADING LH	TATA spare parts
P6671000172	PASSENGER DOOR GLASS (SINGLE)	TATA spare parts
P6671000173	PASSENGER DOOR RUBBER BEADING (SINGLE)	TATA spare parts
P6671000174	DRIVER DOOR QUARTER GLASS WITH BEADING	TATA spare parts
P6671000175	EMERGENCY EXIT DOOR HANDLE GLASS	TATA spare parts
P6671000176	EMERGENCY EXIT DOOR HANDLE GLASS BEADING	TATA spare parts
P6671000177	DRIVER PARTITION WINDOW GLASS	TATA spare parts
P6671000178	DRIVER PARTITION WINDOW GLASS BEADING /	TATA spare parts
P6671000179	SIDE MARKER LAMP	TATA spare parts
P6671000182	NUMBER PLATE LAMP ASSY	TATA spare parts
P6671000183	SWITCHES - PIANO TYPE	TATA spare parts
P6671000184	SPOT LAMP (FOR PASSENGER/SALOON AREA)	TATA spare parts
P6671000185	FLOURSCENT LAMP (TUBE LIGHTS)	TATA spare parts
P6671000186	TAIL LAMP GRILL	TATA spare parts
P6671000187	SALOON LAMP	TATA spare parts
P6671000188	NIGHT LAMP	TATA spare parts
P6671000189	DIKKI LAMP	TATA spare parts
P6671000190	CABLE HARNESS (BODY)	TATA spare parts
P6671000191	BATTERY CABLE (RED)	TATA spare parts
P6671000192	BATTERY CABLE (BLACK)	TATA spare parts
P6671000193	BATTERY TRAY BEARING	TATA spare parts
P6671000194	BATTERY TRAY CHAIN	TATA spare parts
P6671000195	SINGLE POLE CONNECTOR	TATA spare parts
P6671000196	TWO POLE CONNECTOR	TATA spare parts
P6671000197	BODY FUSE- 5A	TATA spare parts
P6671000198	BODY FUSE - 15A	TATA spare parts
P6671000199	MAXI FUSE 40A	TATA spare parts
P6671000200	FUSE BOX (BODY) WITH HARNESS	TATA spare parts
P6671000201	FAN DRIVER CABIN	TATA spare parts
P6671000202	DRIVER DOOR HANDLE LOCK WITH KEY	TATA spare parts
P6671000203	DIKKI LOCK	TATA spare parts
P6671000204	DIKKI HINGE	TATA spare parts
P6671000205	DIKKI RUBBER BEADING	TATA spare parts
P6671000206	DIKKI FLOOR MAT	TATA spare parts
P6671000207	FRONT BUMPER CPT	TATA spare parts
P6671000208	REAR BUMPER CPT	TATA spare parts
P6671000209	DOOR ASSY CPT	TATA spare parts

P66710000210	DOOR RUBBER BEADING SINGLE	TATA spare parts
P66710000211	DOOR HINGES	TATA spare parts
P66710000212	DOOR BEARINGS/BUSHES	TATA spare parts
P66710000213	HINGE WITH HANDLE	TATA spare parts
P66710000214	DOOR STOPPER	TATA spare parts
P66710000215	LOCKING (TOWER BOLT)	TATA spare parts
P66710000216	FRONT FACE COMPLETE WITHOUT FITTINGS	TATA spare parts
P66710000217	REAR FACE COMPLETE WITHOUT FITTINGS	TATA spare parts
P66710000218	CENTRE GRILL	TATA spare parts
P66710000219	CENTRE GRILL HINGE SINGLE	TATA spare parts
P66710000220	CENTRE GRILL STAY ROD	TATA spare parts
P66710000221	CENTRE FLAP LOCKING KNOB WITH LOCK	TATA spare parts
P66710000222	REAR LADDER	TATA spare parts
P66710000223	ROOF LOAD CARRIER	TATA spare parts
P66710000224	ENGINE GUARD (STENSION PIPE)	TATA spare parts
P66710000225	GEARBOX CUTOFF COMPL	TATA spare parts
P66710000226	BATTERY TRAY	TATA spare parts
P66710000227	FUEL TANK CUT OUT	TATA spare parts
P66710000228	FUEL FLAP (RH SIDE PANEL)	TATA spare parts
P66710000229	AIR CLEANER FLAP	TATA spare parts
P66710000230	WIPER SYSTEM (ALMIGHTY)	TATA spare parts
P66710000231	RVM ASSY RH	TATA spare parts
P66710000232	RVM ASSY LH	TATA spare parts
P66710000233	SALOON MIRROR	TATA spare parts
P66710000234	DRIVER DOOR INNER HANDLE ASSY	TATA spare parts
P66710000235	MASCOT	TATA spare parts
P66710000236	TATA (TEXT)	TATA spare parts
P66710000237	UTC STICKER (SET)	TATA spare parts
P66710000238	FRONT BUMPER END COVER (RUBBER) RH	TATA spare parts
P66710000239	FRONT BUMPER END COVER (RUBBER) LH	TATA spare parts
P66710000240	REAR WIND SHIELD GUARD	TATA spare parts
P66710000241	FRONT WIND SHIELD	TATA spare parts
P69830000001	FRONT WIND SHIELD LH ( LP1510/52 BSF )	TATA spare parts
P69830000002	FRONT WIND SHIELD RH ( LP1510/52 BSF )	TATA spare parts
P69830000003	REAR EMERGENCY WINDOW GLASS	TATA spare parts
P69830000004	REAR FRP BUMPER 909 CNG	TATA spare parts
P69830000005	DRIVER PARTITION GLASS	TATA spare parts
P69830000006	REAR BUMPER - FRP SMALL	TATA spare parts
P69830000008	DRIVER DOOR LOCK	TATA spare parts
P69830000010	DRIVER DOOR HINGES	TATA spare parts
P69830000011	GRAB HANDLE	TATA spare parts
P69830000013	JK DOOR ROLLER ASSY	TATA spare parts
P69830000014	HINGE PASSENGER DOOR	TATA spare parts
P69830000015	HINGE WITH HANDLE FOR PASSENGER DOOR	TATA spare parts
P69830000016	BRUSH	TATA spare parts
P69830000017	PASSENGER DOOR LOCK	TATA spare parts
P69830000018	Front Windshield Glass	TATA spare parts

P69830000022	FUEL FLAP COVER LOCK	TATA spare parts
P69830000032	JK DOOR GLASS BEADING	TATA spare parts
P69830000033	REAR WIND SHIELD	TATA spare parts
P69830000034	REAR WIND SHIELD	TATA spare parts
P69830000035	REAR WIND SHIELD	TATA spare parts
P69830000036	WINDSHIELD GLASS LH	TATA spare parts
P69830000037	DRIVER DOOR CATCHER	TATA spare parts
P69830000038	REAR WIND SHIELD MIDDLE	TATA spare parts
P69830000039	REAR WIND SHIELD LH / RH	TATA spare parts
P69830000040	FIXED GLASS LH SIDE FRONT WINDOW- 1055X	TATA spare parts
P69830000041	SLIDING TAPER GLASS LH SIDE FRONT WINDOW	TATA spare parts
P69830000042	SLIDING RECTANGULAR GLASS LH SIDE FRONT	TATA spare parts
P69830000043	PEEP WINDOW GLASS- 285X300 MM	TATA spare parts
P69830000044	FIXED GLASS LH & RH SIDE WINDOW- SIZE 10	TATA spare parts
P69830000045	SLIDING GLASS LH & RH SIDE WINDOW- SIZE	TATA spare parts
P69830000046	FIXED GLASS RH SIDE WINDOW- SIZE 1183X2	TATA spare parts
P69830000047	SLIDING GLASS RH SIDE WINDOW -SIZE -610X	TATA spare parts
P69830000048	TAPER GLASS DRIVER DOOR WINDOW- SIZE 400	TATA spare parts
P69830000049	SLIDING GLASS DRIVER DOOR WINDOW- 400X59	TATA spare parts
P69830000050	JK DOOR GLASS- SIZE 1335X225 MM	TATA spare parts
P69830000051	REAR VIEW MIRROR BRACKET	TATA spare parts
P69830000052	WINDOW SLIDING 1(1490X 895) MM LH SIDE	TATA spare parts
P69830000053	WINDOW SLIDING 2(1290X895) MM LH SIDE	TATA spare parts
P69830000054	EMERGENCY DOOR WINDOW 3 (660 X600 ) MM	TATA spare parts
P69830000055	WINDOW SLIDING (REAR)4 (420 X895 ) MM	TATA spare parts
P69830000056	DRIVER DOOR WINDOW (660X695)MM	TATA spare parts
P69830000057	JK DOOR GLASS	TATA spare parts
P69830000058	DESTINATION BOX GLASS	TATA spare parts
P69830000059	FIXED GLASS SIZE FOR WINDOW NO.1 (LH & R	TATA spare parts
P69830000060	SLIDING GLASS FOR WINDOW NO.1(LH & TH SI	TATA spare parts
P69830000061	FIXED GLASS FOR WINDOW NO.2(LH & RH SIDE	TATA spare parts
P69830000062	SLIDING GLASS FOR WINDOWNO. 2 (LH & RH S	TATA spare parts
P69830000063	FIXED GLASS FOR WINDOW NO. 3 (LH & RH SI	TATA spare parts
P69830000064	SLIDING GLASS FOR WINDOW NO 3(LH & RH SI	TATA spare parts
P69830000065	SLIDING GLASS FOR WINDOW NO.3(LH & RH SI	TATA spare parts
P69830000066	J.K. DOOR GLASS (FRONT)- SIZE 1482X237	TATA spare parts
P69830000067	J.K. DOOR GLASS (1482X237) REAR	TATA spare parts
P69830000068	EMERGENCY DOOR GLASS (350X598)	TATA spare parts
P69830000069	DRIVER DOOR GLASS - SIZE 703X 325 MM	TATA spare parts
P69830000070	FRONT BUMPER	TATA spare parts
P69830000071	REAR BUMPER	TATA spare parts
P69830000072	SUNVISOR LHD	TATA spare parts
P69830000073	REAR VIEW MIRROR	TATA spare parts
P69830000074	THERMAS & WASH BASIN	TATA spare parts
P69830000075	ROOF LAMP	TATA spare parts
P69830000076	HEIGHT MARKER LAMP FRONT (CLEAR)	TATA spare parts
P69830000077	HEIGHT MARKER LAMP REAR (RED)	TATA spare parts



P69830000078	ROOF BEAM LIGHT	TATA spare parts
P69830000079	WINDOW RHS	TATA spare parts
P69830000080	WINDOW LHS	TATA spare parts
P69830000081	PVC HANDLE	TATA spare parts
P69830000082	STRETCHER	TATA spare parts
P69830000083	IV HOOKS	TATA spare parts
P69830000084	OXYGEN CYLINDER MOUNTING	TATA spare parts
P69830000085	PATIENT BENCH	TATA spare parts
P69830000086	DOCTOR SEAT	TATA spare parts
P69830000087	ATTENDENT SEAT	TATA spare parts
P69830000088	CUPBOARD	TATA spare parts
P69830000089	REAR NO PLATE LIGHT	TATA spare parts
P69830000090	REAR DOOR LOCK	TATA spare parts
P69830000091	REAR DOOR HANDLE	TATA spare parts
P69830000092	UNDER FLOOR STORAGE WASTE WATER TANK	TATA spare parts
P69830000093	FRONT WIND SHIELD GLASS	TATA spare parts
P69830000094	FRONT WINDSHIELD RUBBER MOULD	TATA spare parts
P69830000095	REAR WIND SHIELD LH	TATA spare parts
P69830000096	REAR WIND SHIELD CENTER	TATA spare parts
P69830000097	REAR WIND SHIELD RH	TATA spare parts
P69830000098	REAR WINDSHIELD RUBBER MOULD	TATA spare parts
P69830000099	FRONT BUMPER	TATA spare parts
P69830000100	REAR BUMPER WITHOUT PAINTED	TATA spare parts
P69830000101	REAR VIEW MIRROR BRACKET RHS	TATA spare parts
P69830000102	REAR VIEW MIRROR BRACKET LHS	TATA spare parts
P69830000103	RVM LHS	TATA spare parts
P69830000104	RVM RHS	TATA spare parts
P69830000105	FAN	TATA spare parts
P69830000106	STOP REQUEST BUZZER	TATA spare parts
P69830000107	NUMBER PLATE LIGHT	TATA spare parts
P69830000108	ROOF LAMP	TATA spare parts
P69830000109	CABIN LAMP	TATA spare parts
P69830000114	SUNVISER	TATA spare parts
P69830000115	SALOON MIRROR	TATA spare parts
P69830000119	FRONT WINDSHIELD	TATA spare parts
P69830000120	FRONT WINDSHIELD RUBBER MOULD	TATA spare parts
P69830000121	REAR WIND SHIELD	TATA spare parts
P69830000122	REAR WINDSHIELD RUBBER MOULD	TATA spare parts
P69830000123	FRONT BUMPER	TATA spare parts
P69830000124	REAR BUMPER WITHOUT PAINTED	TATA spare parts
P69830000125	NUMBER PLATE LIGHT	TATA spare parts
P69830000137	BOTTOM SLIDING GLASS LH	TATA spare parts
P69830000138	BOTTOM SLIDING GLASS LH	TATA spare parts
P69830000139	TOP FIXED GLASS LH	TATA spare parts
P69830000140	TOP FIXED GLASS LH	TATA spare parts
P69830000141	TOP FIXED GLASS LH	TATA spare parts
P69830000142	BOTTOM SLIDING GLASS RH	TATA spare parts

P69830000143	BOTTOM SLIDING GLASS RH	TATA spare parts
P69830000144	BOTTOM SLIDING GLASS RH	TATA spare parts
P69830000145	TOP FIXED GLASS RH	TATA spare parts
P69830000146	TOP FIXED GLASS RH	TATA spare parts
P69830000147	TOP FIXED GLASS RH	TATA spare parts
P69830000148	TOP FIXED GLASS RH	TATA spare parts
P69830000149	TOP FIXED GLASS RH	TATA spare parts
P69830000150	TOP FIXED GLASS LH	TATA spare parts
P69830000151	TOP FIXED GLASS LH	TATA spare parts
P69830000152	TOP FIXED GLASS LH	TATA spare parts
P69830000153	TOP FIXED GLASS LH	TATA spare parts
P69830000154	TOP FIXED GLASS LH	TATA spare parts
P69830000155	TOP FIXED GLASS RH	TATA spare parts
P75050000008	LEVER ASSEMBLY	TATA spare parts
P75050000009	KNOB ASSEMBLY-LSS FRONT FACING	TATA spare parts
P75050000001	HOSE	TATA spare parts
P75050000010	CLIP-RETAINING KNOB	TATA spare parts
P75050000002	HOSE	TATA spare parts
P75050000003	HOSE	TATA spare parts
P75050000004	HOSE	TATA spare parts
P75050000005	SHIFT SELECTOR	TATA spare parts
P75050000006	KIT CONTROL MODULE SEAL AND GASKET	TATA spare parts
P75050000007	TCM HARNESS	TATA spare parts
P75050000009	KNOB ASSY.- LSS FRONT FACING	TATA spare parts
P75050000010	CLIP- RETAINING KNOB	TATA spare parts
P75050000011	TRANSMISSION ADAPTATION KIT (FLY WHEEL)	TATA spare parts
P75050000012	HARNESS	TATA spare parts
P75050000013	TRANSMISSION CONTROL MODULE (UNFLASHED)	TATA spare parts
P75050000014	O RING	TATA spare parts
P75050000015	HARNESS T C M	TATA spare parts
P75050000016	WASHER - FLAT M10	TATA spare parts
P75050000017	TCM BOLT KIT	TATA spare parts
P75050000018	TCM 80 WAY BOLT ASSIST	TATA spare parts
P75050000019	KIT GT 150 SPEED SENSOR	TATA spare parts
P75050000020	RETARDER SOLENOID CONNECTOR	TATA spare parts
P75050000021	CONNECTOR ACCUMULATOR	TATA spare parts
P75050000022	BOLT - M8X1.25X25 LG	TATA spare parts
P75050000023	TEMP. GAGE	TATA spare parts
P75050000024	RESISTANCE MODULE 3 STEP APPLY	TATA spare parts
P75050000025	RETARDER CONTROLS	TATA spare parts
P75050000026	RETARDER CONTROLS	TATA spare parts
P75050000027	FLEXPLATE ASSY.	TATA spare parts
P75050000028	FLEXPLATE	TATA spare parts
P75050000029	PLATE - WEAR	TATA spare parts
P75050000030	VIM - 24V	TATA spare parts
P75050000031	DUST SHIELD	TATA spare parts
P75050000032	FLANGE OUT PUT	TATA spare parts

P75050000033	TCM (A43009X1)	TATA spare parts
P75050000034	INT. HARNESS	TATA spare parts
P75050000035	SWITCH ASSY PRESSURE	TATA spare parts
P75050000036	BOLT - M12X25 LG	TATA spare parts
P75050000037	ADAPTOR TRANSMISSION	TATA spare parts
P75050000038	ADAPTOR HUB	TATA spare parts
P75050000039	HOSE - RETARDER (350 MM)	TATA spare parts
P75050000040	HARNESS KIT 1500 MM	TATA spare parts
P75050000041	SPACER HOUSING (SAE 2 TO SAE 2)	TATA spare parts
P75050000042	HOSE TRANS. TO COOLER (2200 MM)	TATA spare parts
P75050000043	HOSE COOLER TO TRANSMISSION (2300MM)	TATA spare parts
P75050000044	HOUSING ASSEMBLY MAIN	TATA spare parts
P75050000045	HOSE - RETARDER ( FOR AC BUS)	TATA spare parts
P75050000046	FLANGE - OUTPUT	TATA spare parts
P75050000047	BOLT - M10X70 LG	TATA spare parts
P75050000048	BOLT - M10X1.5X30 LG	TATA spare parts
P75050000049	PRESSURE SWITCH 2 PSI	TATA spare parts
P75050000050	PRESSURE SWITCH 10 PSI	TATA spare parts
P75050000051	TEMP. SENSOR - ENGINE WATER	TATA spare parts
P75050000052	TEMP. GUAGE - KIT	TATA spare parts
P75050000053	ACCUMULATOR - ASSY.	TATA spare parts
P75050000054	SELECTOR SHIFT	TATA spare parts
P75050000055	CONNECTOR STRAIGHT - COOLER	TATA spare parts
P75050000056	CONNECTOR - ELBOW- COOLER	TATA spare parts
P75050000057	CONNECTOR - T	TATA spare parts
P75050000058	CONNECTOR STRAIGHT- TRANSMISSION	TATA spare parts
P75050000059	BOLT - 5/16 X 0.87 LG	TATA spare parts
P75050000060	BOLT - ACCUMULATOR	TATA spare parts
P75050000061	ACCUMULATOR AIR SOLENOID	TATA spare parts
PLY037015M005700	PLYWOOD	TATA spare parts
PRP050010008	WHEEL SIDE COVER FRP	TATA spare parts
Q1200850F3	STUD	TATA spare parts
Q1201028F3	STUD	TATA spare parts
Q1201040F3	STUD	TATA spare parts
Q1201225F3	STUD	TATA spare parts
Q1201230F3	STUD	TATA spare parts
Q1231230B	STUD	TATA spare parts
Q12316120	STUD	TATA spare parts
Q150B0816	HEX BOLT	TATA spare parts
Q150B0818	HEX BOLT	TATA spare parts
Q150B1018	HEX BOLT	TATA spare parts
Q150B1025	HEX BOLT	TATA spare parts
Q150B1050	HEX BOLT	TATA spare parts
Q150B1230TF2	HEX BOLT	TATA spare parts
Q150B1430TF2	HEX BOLT	TATA spare parts
Q151B1440	HEX BOLT	TATA spare parts
Q151B1455	HEX BOLT	TATA spare parts

Q151B1480TF2	HEX BOLT	TATA spare parts
Q151B1490	HEX BOLT	TATA spare parts
Q151B1635TF2	HEX BOLT	TATA spare parts
Q151B1645TF2	HEX BOLT	TATA spare parts
Q151B1660TF2	HEX BOLT	TATA spare parts
Q151B181100TF2	HEX BOLT	TATA spare parts
Q151B181130TF2	HEX BOLT	TATA spare parts
Q151B1870	HEX BOLT	TATA spare parts
Q151B2040TF2	HEX BOLT	TATA spare parts
Q151C1230	HEX BOLT	TATA spare parts
Q151C1265TF2	BOLT-CLOSELY-PITCHED	TATA spare parts
Q151C1295TF2	HEX BOLT	TATA spare parts
Q2540820	SLIT BOLT	TATA spare parts
Q2541020	SLIT BOLT	TATA spare parts
Q2800825	SLIT BOLT	TATA spare parts
Q33208	HEX NUT	TATA spare parts
Q33210	HEX NUT	TATA spare parts
Q340B08	HEX NUT	TATA spare parts
Q340B10	HEX NUT	TATA spare parts
Q340B12	HEX NUT	TATA spare parts
Q340B8	HEX NUT	TATA spare parts
Q341B16	HEX NUT	TATA spare parts
Q350B08T15	HEX NUT	TATA spare parts
Q351B18	HEX NUT	TATA spare parts
Q381B16	SLIT HEX NUT	TATA spare parts
Q387B24	HEX NUT	TATA spare parts
Q40108	PLAIN WASHER	TATA spare parts
Q40114	FLAT WASHER	TATA spare parts
Q40308	SPRING WASHER	TATA spare parts
Q40310	SPRING WASHER	TATA spare parts
Q40312	SPRING WASHER	TATA spare parts
Q40314	SPRING WASHER	TATA spare parts
Q41216	LOCKING WASHER	TATA spare parts
Q43117	CIRCLIP FOR AXLE	TATA spare parts
Q43125	CIRCLIP FOR AXLE	TATA spare parts
Q433130	WIRE CIRCLIP FOR AXLE	TATA spare parts
Q43705	WIRE CIRCLIP FOR AXLE	TATA spare parts
Q43740	WIRE CIRCLIP FOR AXLE	TATA spare parts
Q43870	WIRE CIRCLIP FOR AXLE	TATA spare parts
Q5004022	COTTER PIN	TATA spare parts
Q5004028	COTTER PIN	TATA spare parts
Q5004030	COTTER PIN	TATA spare parts
Q500422	COTTER PIN	TATA spare parts
Q5005040	COTTER PIN	TATA spare parts
Q5005055	COTTER PIN	TATA spare parts
Q5005056	COTTER PIN	TATA spare parts
Q510440	PIN AXLE	TATA spare parts

Q5210814	PIN	TATA spare parts
Q5210820	COLUMN PIN	TATA spare parts
Q5211014	PIN	TATA spare parts
Q5211016	COLUMN PIN	TATA spare parts
Q5211222	PIN	TATA spare parts
Q5211435	PIN	TATA spare parts
Q5211626	PIN	TATA spare parts
Q5280624	ELASTANE PIN	TATA spare parts
Q58116	HEX NUT	TATA spare parts
Q72318	PACKING WASHER	TATA spare parts
Q72336	PACKING WASHER	TATA spare parts
Q72339AL	PARKING WASHER	TATA spare parts
QCBG105CV	ENGINE FLASHING BG	TATA spare parts
R0423530452J	SPACER RING ( RAW PART ) BS6-PH2	TATA spare parts
R71900000001	WEARING STRIP	TATA spare parts
R71900000002	INTERIOR+EXTERIOR	TATA spare parts
R71900000003	WEARING STRIP 2IN	TATA spare parts
R71900000004	RUBRAIL	TATA spare parts
R71900000005	INTERNAL BEADING	TATA spare parts
R71900000006	1IN X16G PIPE FOR GUARD RAIL	TATA spare parts
R71900000007	INTERIOR+EXTERIOR 3/4IN BEADING	TATA spare parts
R71900000008	INTERIOR	TATA spare parts
R71900000009	1IN OPEN SOCKET YELLOW	TATA spare parts
R71900000010	GUTTER SECTION	TATA spare parts
R71900000011	MAIN WINDOW PAN SECTION	TATA spare parts
R71900000012	SPLIT W/S-PAN	TATA spare parts
R71900000013	SPLIT W/S HINGE--MALE	TATA spare parts
R71900000014	SPLIT W/S HINGE--FEMALE	TATA spare parts
R71900000015	REAR EMER.SECTION	TATA spare parts
R71900000016	ROOF INNER BEADING	TATA spare parts
R71900000017	WINDOW SECTION - 1	TATA spare parts
R71900000018	WINDOW SECTION - 2	TATA spare parts
R71900000019	MAIN WINDOW SLIDING GLASS (2 CR 50MM)	TATA spare parts
R71900000020	MID WINDOW SLIDING GLASS (2 CR 50MM)	TATA spare parts
R71900000021	SMALLWINDOW SLIDING GLASS (2 CR 50MM)	TATA spare parts
R71900000022	EMERGENCY WINDOW GLASS	TATA spare parts
R71900000023	QUARTER GLASS-DR.SIDE	TATA spare parts
R71900000024	QUARTER GLASS-DR.SIDE	TATA spare parts
R71900000025	FRONT & REAR DESTINATION GLASS	TATA spare parts
R71900000026	SIDE DESTINATION	TATA spare parts
R71900000027	J-K DOOR FRONT	TATA spare parts
R71900000028	J-K DOOR-REAR	TATA spare parts
R71900000029	TOP WINDSCREEN GLASS (LAMINATED SAFETY -	TATA spare parts
R71900000030	BOTTOM WINDSCREEN GLASS	TATA spare parts
R71900000031	ALU.BUTT HINGES 5 1/2IN	TATA spare parts
R71900000032	FLOORING HANDLE DISH	TATA spare parts
R71900000033	MS HINGES 3IN	TATA spare parts

R71900000034	ALU.PIANO HINGES 36IN	TATA spare parts
R71900000035	MIRROR BRKT	TATA spare parts
R71900000036	38MM BASE SOCKET	TATA spare parts
R71900000037	GRAB RAIL SUPPORT	TATA spare parts
R71900000038	REAR EMER. WINDOW OUTER HANDLE	TATA spare parts
R71900000039	BRASS VENTILATOR LATCHES	TATA spare parts
R71900000040	TOWER BOLT	TATA spare parts
R71900000041	BUDGET LOCK	TATA spare parts
R71900000042	STANCHION PIPE	TATA spare parts
R71900000043	FRONT DR. SIDE MIRROR	TATA spare parts
R71900000044	BUDGET LOCK KEY	TATA spare parts
R71900000045	BRASS HANDLE	TATA spare parts
R71900000046	FRONT PASS. SIDE SMALL MIRROR	TATA spare parts
R71900000047	REAR PARTITION MIRROR	TATA spare parts
R71900000048	FIRE ESTINGUSHION STAND	TATA spare parts
R71900000049	WIPER KIT	TATA spare parts
R71900000050	HAND STRAP	TATA spare parts
R71900000051	DRIVER DOOR LOCK	TATA spare parts
R71900000052	FLAP SIDE LOCK	TATA spare parts
R71900000053	FIRE ESTINGUSHION BOTTLE	TATA spare parts
R71900000054	PATTI FOR HANDICAP STAND	TATA spare parts
R71900000055	DRIVER SIGNAL	TATA spare parts
R71900000056	STANCHION PIPE SOCKET	TATA spare parts
R71900000057	REAR EMER. WINDOW INNER HANDLE	TATA spare parts
R71900000058	WHEEL MUD FLAP	TATA spare parts
R71900000059	RUB RAIL BEADING END CAP	TATA spare parts
R71900000060	WINDOW STOPER	TATA spare parts
R71900000061	WIPER MOTOR COVER	TATA spare parts
R71900000062	M.S. DOOR ROUND HING	TATA spare parts
R71900000063	GRAB RAIL SOCKET	TATA spare parts
R71900000064	ANTI RATLING DISC FOR DOOR	TATA spare parts
R71900000065	AL. SOCKET WITH GUN METAL BUSH	TATA spare parts
R71900000066	MIDDLE TOP DOOR GUIDE PIN	TATA spare parts
R71900000067	LOCKING PIN	TATA spare parts
R71900000068	PATTI WELDED BUSH (MALE)	TATA spare parts
R71900000069	PNUEMETIC KIT	TATA spare parts
R71900000070	DOOR OPERATING MECH.	TATA spare parts
R71900000071	DOOR SHAFT LEAVER	TATA spare parts
R71900000072	OUTSIDE HANDLE	TATA spare parts
R71900000073	WEATHER SHADE	TATA spare parts
R71900000074	8MM PVC GROMMET	TATA spare parts
R71900000075	DR. DOOR DOVE TAIL (MALE)	TATA spare parts
R71900000076	DR. DOOR DOVE TAIL (FEMALE)	TATA spare parts
R71900000077	DOOR CATCHER	TATA spare parts
R71900000078	NYLONE GUIDE PIN ROLLER J/K DOOR	TATA spare parts
R71900000079	PVC PACKING FOR J.K. DOOR	TATA spare parts
R71900000080	HANDLE PLANE GRAY	TATA spare parts

R7190000081	PVC J SECTION FOR HATCH	TATA spare parts
R7190000082	PVC GRAIB HANDLE	TATA spare parts
R7190000083	PVC PACKING ANTI RATLING DISC	TATA spare parts
R7190000084	PVC PACKING FOR 1IN BASE SOC.	TATA spare parts
R7190000085	PVC CUP WASHER	TATA spare parts
R7190000086	PVC END BUSH 1 IN	TATA spare parts
R7190000087	PVC CAP FOR GREASE NIPPLE	TATA spare parts
R7190000088	PVC SECTION FOR 2676	TATA spare parts
R7190000089	PVC PACKING FOR D/B LATCHES	TATA spare parts
R7190000090	JK DOOR SIDE RUBBER BIG	TATA spare parts
R7190000091	JK DOOR SIDE RUBBER SMALL	TATA spare parts
R7190000092	JK DOOR LOWER RUBBER	TATA spare parts
R7190000093	JK MIDDLE RUBBER FEMALE	TATA spare parts
R7190000094	JK MIDDLE RUBBER MALE	TATA spare parts
R7190000095	RUBBER GLAZING FOR GLASS	TATA spare parts
R7190000096	RUBBER FOR RUB RAIL BEADING	TATA spare parts
R7190000097	RUBBER FOR WINDOWS	TATA spare parts
R7190000098	RUBBER GROMMET 2IN	TATA spare parts
R7190000099	RUBBER FOR WINDOW SLIDING GLASS	TATA spare parts
R7190000100	RUBBER PACKING FLAT FOR PARTITION & STAN	TATA spare parts
R7190000101	DRIVER CABIN FAN	TATA spare parts
R7190000102	SIDE LIGHT	TATA spare parts
R7190000103	SPEAKER	TATA spare parts
R7190000104	TUBE LIGHT	TATA spare parts
R7190000105	LIGHT	TATA spare parts
R7190000106	BELL SWITCH	TATA spare parts
R7190000107	AL.ROUND STEP LIGHT	TATA spare parts
R7190000108	ROOF LAMP ROUND	TATA spare parts
R7190000109	DRIVER CABIN LAMP	TATA spare parts
R7190000110	FUSE & SWITCH BOARD	TATA spare parts
R7190000111	WIPER MOTOR	TATA spare parts
R7190000112	TWO SEATER SEAT FRAME	TATA spare parts
R7190000113	TWO SEATER BACK REST FRAME	TATA spare parts
R7190000114	TWO SEATER SEAT CUSHION	TATA spare parts
R7190000115	TWO SEATER SEAT BACK REST	TATA spare parts
R7190000116	TWO SEATER SEAT FRAME - MIDDLE	TATA spare parts
R7190000117	TWO SEATER BACK REST FRAME - MIDDLE	TATA spare parts
R7190000118	TWO SEATER SEAT CUSHION - MIDDLE	TATA spare parts
R7190000119	TWO SEATER SEAT BACK REST - MIDDLE	TATA spare parts
R7190000120	BIG WINDOW (CO-DRIVER SIDE)	TATA spare parts
R7190000121	BIG WINDOW (DRIVER SIDE)	TATA spare parts
R7190000122	SMALL WINDOW (CO-DRIVER SIDE)	TATA spare parts
R7190000123	SMALL WINDOW (DRIVER SIDE)	TATA spare parts
R7190000124	MEDIUM WINDOW (CO-DRIVER SIDE)	TATA spare parts
R7190000125	MEDIUM WINDOW (DRIVER SIDE)	TATA spare parts
R7190000126	DR.DOOR WINDOW	TATA spare parts
R7190000127	DR.SIDE FRNT QUARTER WINDOW	TATA spare parts

R71900000128	REAR PARTITION WINDOW	TATA spare parts
R71900000129	REAR EMERGENCY WINDOW	TATA spare parts
R71900000130	REAR PASSENGER DOOR	TATA spare parts
R71900000131	FRONT PASSENGER DOOR	TATA spare parts
R71900000132	DRIVER DOOR	TATA spare parts
R71900000133	DRIVER DOOR WINDOW	TATA spare parts
R71900000134	GAS FLAP PANEL CO-DR SIDE & DR-SIDE	TATA spare parts
R71900000135	F/O SIDE AND F/NEAR SIDE BOTTOM PANNEL	TATA spare parts
R71900000136	DR-SIDE AIR VENTILATION PANEL	TATA spare parts
R71900000137	FRONT DR-SIDE AIR VENTILATION PANEL	TATA spare parts
R71900000138	DR-DOOR AIR VENTILATION PANEL	TATA spare parts
R71900000139	FRONT WIND SCREEN-R.H.	TATA spare parts
R71900000140	FRONT WIND SCREEN-L.H.	TATA spare parts
RTYREAMC001	RETREADED TYE ( FOR CTU BUSES UNDER AMC)	TATA spare parts
RX3865312	SENSOR TEMPERTURE	TATA spare parts
RX4091852-01CVC	MIDRANGE ENG CM2150 LIBRARY CD	TATA spare parts
S 602	WASHER PLAIN	TATA spare parts
S-915-A	PLUG PIPE	TATA spare parts
S-932-E	NIPPLE PIPE	TATA spare parts
S-945	NIPPLE PIPE	TATA spare parts
S-980	ELBOW PIPE	TATA spare parts
S-982	BUSHING	TATA spare parts
S-988	ELBOW PLAIN	TATA spare parts
S-KIT-1000	KING PIN SERVICE KIT	TATA spare parts
S-KIT-1001	KNUCKLE BUSHING REPLACEMENT KIT	TATA spare parts
S-KIT-1002	THRUST BEARING REPLACEMENT KIT	TATA spare parts
S-KIT-1003	KING PIN CAP REPLACEMENT KIT	TATA spare parts
S-KIT-1005	STEERING KNUCKLE REPLACEMENT KIT LH	TATA spare parts
S-KIT-1006	STEERING KNUCKLE REPLACEMENT KIT RH	TATA spare parts
S-KIT-1007	STEERING ARM REPLACEMENT KIT	TATA spare parts
S-KIT-1008	TIE ROD ARM REPLACEMENT KIT LH	TATA spare parts
S-KIT-1009	TIE ROD ARM REPLACEMENT KIT RH	TATA spare parts
S-KIT-1010	ROTOR REPLACEMENT KIT	TATA spare parts
S0001500	SCREW HEX FLANGE HD CAP	TATA spare parts
S000150A	SCREW HEX FLANGE HD CAP	TATA spare parts
S000279	NUT	TATA spare parts
S000602	WASHER M10	TATA spare parts
S000611	WASHER LOCK	TATA spare parts
S06933L	LONG BLOCK-4021	TATA spare parts
S1000A	ELBOW MALE ADAPTER	TATA spare parts
S10041	ELBOW PLAIN ADAPTER (M8 X 1.25 X 16)	TATA spare parts
S150	SCREW HEX FLANGE HD CAP	TATA spare parts
S150A	SCREW HEX FLANGE HD CAP	TATA spare parts
S16022A	BEARING BALL(CLUTCH REAR)	TATA spare parts
S2286	SCREW DRIVE	TATA spare parts
S279	NUT HEAVY HEX JAM	TATA spare parts
S602	WASHER M10	TATA spare parts



S611	WASHER LOCK	TATA spare parts
S626	WASHER PLAIN	TATA spare parts
S6328000001	GLASS FOR -- WINDOW 884X835 FRT	TATA spare parts
S6328000002	GLASS FOR -- WINDOW 884X835 RR	TATA spare parts
S6328000003	GLASS FOR -- WINDOW 605X790 FRT	TATA spare parts
S6328000004	GLASS FOR -- WINDOW 605X790 RR	TATA spare parts
S6328000005	GLASS FOR -- WINDOW 287X835 FIXED	TATA spare parts
S6328000006	GLASS FOR -- WINDOW 581X835 FIXED	TATA spare parts
S6328000007	GLASS FOR -- WINDOW 974/712X835 FRT	TATA spare parts
S6328000008	GLASS FOR -- WINDOW 974/712X835 RR	TATA spare parts
S6328000009	GLASS FOR -- WINDOW 1317X833 SLIDING FRT	TATA spare parts
S6328000010	GLASS FOR -- WINDOW 1317X833 SLIDING RR	TATA spare parts
S6328000011	GLASS FOR -- WINDOW 648X833 SLIDING FRT	TATA spare parts
S6328000012	GLASS FOR -- WINDOW 648X833 SLIDING RR	TATA spare parts
S8775000001	ALTERNATOR BELT	TATA spare parts
S8775000002	BELT IDLER TO COMPRESSOR	TATA spare parts
S8775000003	BELT ENGINE CRANK TO IDLER	TATA spare parts
S8839000001	WIPER BLADE	TATA spare parts
S8839000002	WIPER ARM RHD DR SIDE	TATA spare parts
S8839000003	WIPER ARM RHD PASS SIDE	TATA spare parts
S8839000004	WIPER MOTOR	TATA spare parts
S8839000005	WIPER LINKAGE RHD	TATA spare parts
S8839000006	WASHER SYSTEM	TATA spare parts
S904A	BUSHING PIPE	TATA spare parts
S910B	PLUG PIPE	TATA spare parts
S915A	PLUG PIPE	TATA spare parts
S921D	BUSHING REDUC	TATA spare parts
S923E	DRAIN COCK	TATA spare parts
S929B	BUSHING REDUC	TATA spare parts
S939B	CONNECTOR-A/F CNTROLR TO CARBU	TATA spare parts
S962	PLUG PIPE	TATA spare parts
S962E	COCK DRAIN	TATA spare parts
S967	BUSHING REDUCING PIPE	TATA spare parts
S974A	BUSHING REDUCING PIPE	TATA spare parts
S982	BUSHING REDUC	TATA spare parts
S983	BUSHING REDUCING PIPE	TATA spare parts
S995	PLUG PIPE	TATA spare parts
SK-ET154381	OIL PUMP SEAL INSTALLER	TATA spare parts
SK-ET154391	INPUT SHAFT MAIN BEARING INSTALLER	TATA spare parts
SK-ET154404	BEARING REMOVER (SLEEVE)	TATA spare parts
SK-ET154405	BEARING REMOVER (THREADED SPINDLE)	TATA spare parts
SK-ET154406	BEARING REMOVER (NUT)	TATA spare parts
SK-ET154408	BEARING REMOVER	TATA spare parts
SK-ET15441	LAY SHAFT REAR BEARING INSTALLER	TATA spare parts
SK-ET154431	LAY SHAFT FRONT BEARING INSTALLER	TATA spare parts
SK-ET154461	MAIN SHAFT REAR BEARING INSTALLER	TATA spare parts
SK-ET15447-A1	REAR SEAL INSTALLER	TATA spare parts

SK-ET154481	OUT PUT SHAFT BEARING INSTALLER	TATA spare parts
SK-ET154491	BEARING INSTALLER OUTPUT SHAFT	TATA spare parts
SK-ET1545701	BUSH INSTALLER	TATA spare parts
SK-ET154581	SELECTOR SHAFT BUSH INSTALLER	TATA spare parts
SK-ET15477	SUN GEAR RETAINER	TATA spare parts
SK-ET154951	DRIVER	TATA spare parts
SK-ET154961	MAIN SHAFT BEARING REAR PILOT	TATA spare parts
SKIT-701	WHEEL MOUNTING FASTENER KIT	TATA spare parts
SKIT-706	OIL SLINGER KIT	TATA spare parts
SKIT-707	DRUM TO HUB MOUNTING FASTENERS KIT	TATA spare parts
SKIT-715-A	AXLE SHAFT MOUNTING FASTENERS KIT	TATA spare parts
SKIT-724	BRAKE MOUNTING FASTENER KIT	TATA spare parts
SKIT-725	ABS KIT	TATA spare parts
SKIT-C0113	MINOR SERVICE KIT	TATA spare parts
SKIT-C0116	CAM SHAFT REPAIR KIT	TATA spare parts
SKIT-C0118A	REAR BRAKE LINER KIT	TATA spare parts
SKIT-C0135	RIVET KIT	TATA spare parts
SKIT-C0154	DUST SHIELD MOUNTING FASTENER KIT	TATA spare parts
SKIT-C0158	CAMSHAFT WASHER KIT	TATA spare parts
SKIT-C0191	BRKACET MOUNTING FASTENER KIT	TATA spare parts
SO10110LA	LONG BLOCK 6BT EURO II	TATA spare parts
SO20001	LONG BLOCK INLINE FIP	TATA spare parts
SO20110	LONG BLOCK 6BT EURO II	TATA spare parts
SO20196	CNG LONG BLOCK BSIII	TATA spare parts
SO20230	LONG BLOCK 130 HP BSIII	TATA spare parts
SO20234	LONG BLOCK 235 HP BS-II	TATA spare parts
SO20321	CNG SERVICE LONG BLOCK BG+	TATA spare parts
SO41112	ASSY LONG BLOCK 300HP BSII	TATA spare parts
SO60230LA	LONG BLOCK 130 HP BSIII	TATA spare parts
SO60230LA.	LONG BLOCK 130 HP BSIII	TATA spare parts
SO60234LA	LONG BLOCK 235 HP BSII	TATA spare parts
SO6933L	LONG BLOCK-4021	TATA spare parts
SPIRAX80W90020	Spirax heavy duty gear oil 80W90	TATA spare parts
SSTC0020	SPARE SEAL KIT HYD.CYLINDER	TATA spare parts
ST-1138	BELT TENSION GAUGE ( V-RIBBED WITH 6 TO	TATA spare parts
ST-1143	AIR COMPRESSOR NUSHING MANDREL	TATA spare parts
ST-1273	PRESSURE GAUGE - [0 TO 75INCH HG] - TO	TATA spare parts
ST-1325	DIAL GAUGE ATTACHMENT - USED TO MOUNT ON	TATA spare parts
ST-302	BALL JOINT VICE - TO HOLD AIR COMPRESSOR	TATA spare parts
ST-537	DIAL DEPTH GAUGE - TO MEASURE TURBO AXIA	TATA spare parts
ST-647	STANDARD PULLER	TATA spare parts
ST-749	MOUNTING PLATE - TO MOUNT AIR COMPRESSO	TATA spare parts
ST-755	PISTON RING COMPRESSOR	TATA spare parts
ST1111-3	WATER MANOMETER	TATA spare parts
ST11113	MANOMETER	TATA spare parts
ST1134	DOWEL PULLER	TATA spare parts
ST1229	CYL. LINER DRIVER	TATA spare parts

ST1232	DRILL/REAM FIXTURE	TATA spare parts
ST561	CON ROD CHECKING FIXTURE	TATA spare parts
ST647	PULLER	TATA spare parts
ST6850	VALUE SEAT GRINDING MCH.	TATA spare parts
ST755	PISTON RING COMPRESSOR	TATA spare parts
SU216	Front Indicator LHS	TATA spare parts
T01-715TC1201	CASE NO- 01 ENGINE	TATA spare parts
T01-715TC1202	CASE NO- 02 GEAR BOX WITH LINKAGES	TATA spare parts
T01-715TC1204	CASE NO- 04 REAR AXLE WITH LINKAGES	TATA spare parts
T01-715TC1207	CASE NO- 07 FRAME	TATA spare parts
T01-715TC1212	CASE NO- 12 MISCELLANEOUS-1	TATA spare parts
T01-715TC1213	CASE NO- 13 FUEL TANK	TATA spare parts
T01-715TC1216	CASE NO- 16 MISCELLANEOUS-2	TATA spare parts
T01-715TC1217	CASE NO- 17 MISCELLANEOUS-3	TATA spare parts
T01-715TC1218	CASE NO- 18 AUX GEAR BOX WITH LINKAGE	TATA spare parts
T01-715TC1219	CASE NO- 19 CAB-1	TATA spare parts
T01-715TC1221	CASE NO- 21 PIPES	TATA spare parts
T01-715TC1222	CASE NO- 22 SPRINGS	TATA spare parts
T01-715TC1228	CASE NO- 28 CAB	TATA spare parts
T01-715TC1234	CASE NO- 34 WHEEL RIM AND TYRE ASSEMB	TATA spare parts
T01-715TC1241	CASE NO- 41 PROP.SHAFT	TATA spare parts
T01-715TC1242	CASE NO- 42 FRONT AXLE WITH LINKAGES	TATA spare parts
T01-715TC1244	CASE NO- 44 BATTERY	TATA spare parts
T01-715TC1248	CASE NO- 48 TOOLS	TATA spare parts
T01-715TC1250	CASE NO- 50 ENGINE-1	TATA spare parts
T06560000001	TUBE FUEL SUPPLY FLEXIBLE PIPE	TATA spare parts
T06560000002	SEAL O RING	TATA spare parts
T06560000003	HOUSING FLYWHEEL	TATA spare parts
T06560000004	PLUG PIPE	TATA spare parts
T06560000005	SEAL O RING	TATA spare parts
T06560000006	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000007	SEAL O RING	TATA spare parts
T06560000008	PLUG THREADED	TATA spare parts
T06560000009	COUPLING PLAIN HOSE	TATA spare parts
T06560000010	HOSE MOULDED	TATA spare parts
T06560000011	CLAMP HOSE	TATA spare parts
T06560000012	BRACKET IDLER PULLEY	TATA spare parts
T06560000013	PLATE CLAMPING	TATA spare parts
T06560000014	PLUG THREADED	TATA spare parts
T06560000015	PLUG THREADED	TATA spare parts
T06560000016	DOWEL PIN	TATA spare parts
T06560000017	PULLEY CRANKSHAFT	TATA spare parts
T06560000018	SEAL O RING	TATA spare parts
T06560000019	WASHER SEALING	TATA spare parts
T06560000020	BREATHER CRANKCASE	TATA spare parts
T06560000021	HOUSING FLYWHEEL	TATA spare parts
T06560000022	TURBOCHARGER	TATA spare parts

T06560000023	CONNECTOR QCK DISCONNECT	TATA spare parts
T06560000024	PLATE CLAMPING	TATA spare parts
T06560000025	TUBE FUEL SUPPLY	TATA spare parts
T06560000026	CRANKSHAFT ENGINE	TATA spare parts
T06560000027	TENSIONER BELT	TATA spare parts
T06560000028	COVER VALVE	TATA spare parts
T06560000029	BELT V RIBBED	TATA spare parts
T06560000030	TUBE LUB OIL SUCTION	TATA spare parts
T06560000031	ADAPTER FUEL CONNECTOR	TATA spare parts
T06560000032	BRACE ALTERNATOR	TATA spare parts
T06560000033	MANIFOLD AIR INTAKE	TATA spare parts
T06560000034	HEAD LUB OIL FILTER	TATA spare parts
T06560000035	PIPE AIR TRANSFER	TATA spare parts
T06560000036	TUBE FUEL DRAIN	TATA spare parts
T06560000037	ASSY ROCKER LEVER	TATA spare parts
T06560000038	CONNECTION WATER INLET	TATA spare parts
T06560000040	EXHAUST MANIFOLD	TATA spare parts
T06560000041	ALTERNATOR 90 AMP	TATA spare parts
T06560000042	PISTON	TATA spare parts
T06560000043	PIN PISTON	TATA spare parts
T06560000044	RING RETAINING	TATA spare parts
T06560000045	OIL RING	TATA spare parts
T06560000046	COMPRESSION RING	TATA spare parts
T06560000047	COMPRESSION RING	TATA spare parts
T06560000048	SET BARE PISTON 6BT BSIII ENGINE	TATA spare parts
T06560000049	SET PISTON RINGS 6BT BSIII ENGINE	TATA spare parts
T06560000050	RING GEAR	TATA spare parts
T06560000051	HOSE FLEXIBLE	TATA spare parts
T06560000052	COMPRESSOR AIR	TATA spare parts
T06560000053	FLY WHEEL	TATA spare parts
T06560000054	CLIP	TATA spare parts
T06560000055	CLIP	TATA spare parts
T06560000056	BREATHER CRANKCASE	TATA spare parts
T06560000057	SEAL O RING	TATA spare parts
T06560000058	GASKET EXHAUST MANIFOLD	TATA spare parts
T06560000059	GASKET OIL COOLER CORE	TATA spare parts
T06560000060	GASKET FILTER HEAD	TATA spare parts
T06560000061	GASKET HYDRAULIC PUMP	TATA spare parts
T06560000062	SCREW SOCKET HEAD CAP	TATA spare parts
T06560000063	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000064	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000065	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000066	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000067	NUT HEXAGON FLANGE	TATA spare parts
T06560000068	PUMP FUEL INJECTION 230HP ENGINE	TATA spare parts
T06560000069	INJECTOR	TATA spare parts
T06560000070	CONNECTOR MALE	TATA spare parts

T06560000071	TUBE CPR WATER OUTLET	TATA spare parts
T06560000072	CONNECTOR QCK DISCONNECT	TATA spare parts
T06560000073	TUBE CPR WATER OUTLET	TATA spare parts
T06560000073AE	TUBE CPR WATER OUTLET 1628	TATA spare parts
T06560000074	TUBE CPR WATER INLET	TATA spare parts
T06560000074AE	TUBE CPR WATER INLET 1628	TATA spare parts
T06560000075	WASHER SEALING	TATA spare parts
T06560000076	CONNECTION TUR OIL DRAIN	TATA spare parts
T06560000077	BRACKET EXH CONNECTION	TATA spare parts
T06560000078	HARNESS WIRING	TATA spare parts
T06560000079	CLIP WIRE RETAINING	TATA spare parts
T06560000080	NUT REGULAR HEXAGON	TATA spare parts
T06560000081	BELT V RIBBED	TATA spare parts
T06560000082	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000083	CONNECTOR WATER INLET	TATA spare parts
T06560000084	HOSE PLAIN	TATA spare parts
T06560000085	SUPPORT AIR COMPRESSOR	TATA spare parts
T06560000086	COMPRESSOR AIR	TATA spare parts
T06560000087	TURBOCHARGER	TATA spare parts
T06560000088	SEAL O RING	TATA spare parts
T06560000089	SEAL O RING	TATA spare parts
T06560000090	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000091	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000092	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000093	SCREW HEX FLANGE HEAD	TATA spare parts
T06560000094	NUT HEXAGONAL FLANGE	TATA spare parts
T06560000095	SCREW SOCKET HEAD CAP	TATA spare parts
T06560000096	SEAL RECTLR WATER	TATA spare parts
T06560000097	PLATE COVER	TATA spare parts
T06560000098	ADAPTER FILTER HEAD	TATA spare parts
T06560000099	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000100	CONNECTION WATER INLET	TATA spare parts
T06560000101	CLAMP SPRING HOSE	TATA spare parts
T06560000102	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000103	GASKET TURBOCHARGER	TATA spare parts
T06560000104	SCREW HEX HEAD CAP	TATA spare parts
T06560000105	SCREW HEX HEAD	TATA spare parts
T06560000106	SHIELD DUST	TATA spare parts
T06560000107	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000108	GASKET THM HOUSING COVER	TATA spare parts
T06560000109	CLAMP SPRING HOSE	TATA spare parts
T06560000110	ELBOW PLAIN STREET PIPE	TATA spare parts
T06560000111	BUSHING REDUCING PIPE	TATA spare parts
T06560000112	COUPLING PLAIN HOSE	TATA spare parts
T06560000113	PISTON	TATA spare parts
T06560000114	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000115	TUBE AIR FUEL CONTROL	TATA spare parts

T06560000116	MAIN BEARING BOLT	TATA spare parts
T06560000117	SEAL O RING	TATA spare parts
T06560000118	SCREW HEX. FLANGE HEAD CAP	TATA spare parts
T06560000119	GASKET ACC DRIVE COVER	TATA spare parts
T06560000120	HOUSING THERMOSTAT	TATA spare parts
T06560000121	GEAR FUEL PUMP	TATA spare parts
T06560000122	SHAFT IDLER	TATA spare parts
T06560000123	SPACER THREADED	TATA spare parts
T06560000124	KEY PLAIN WOODRUFF	TATA spare parts
T06560000125	HOSE PLAIN	TATA spare parts
T06560000126	CARTRIDGE LUB. OIL FILTER	TATA spare parts
T06560000127	BUSHING	TATA spare parts
T06560000128	SCREW ROUND HEAD CAP	TATA spare parts
T06560000129	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000130	RETAINER INJ FUL SUP CNR	TATA spare parts
T06560000131	TAPPET VALVE	TATA spare parts
T06560000132	PLATE COVER	TATA spare parts
T06560000133	DOWEL RING	TATA spare parts
T06560000134	STUD	TATA spare parts
T06560000135	SCREW ROUND HEAD CAP	TATA spare parts
T06560000136	DOWEL RING	TATA spare parts
T06560000137	PULLEY CRANKSHAFT	TATA spare parts
T06560000138	RING SPEED INDICATOR	TATA spare parts
T06560000139	GEAR CAMSHAFT	TATA spare parts
T06560000140	GEAR FUEL PUMP	TATA spare parts
T06560000141	ISOLATOR VIBRATION	TATA spare parts
T06560000142	ISOLATOR VIBRATION	TATA spare parts
T06560000143	VALVE CHECK	TATA spare parts
T06560000144	SCREW SOCKET HEAD CAP	TATA spare parts
T06560000145	SPACER MOUNTING	TATA spare parts
T06560000146	SCREW HEXAGON HEAD CAP	TATA spare parts
T06560000147	CONNECTOR QCK DISCONNECT	TATA spare parts
T06560000148	SCREW BANJO CONNECTOR	TATA spare parts
T06560000149	COUPLING PLAIN HOSE	TATA spare parts
T06560000150	SEAL OIL	TATA spare parts
T06560000151	TUBE BREATHER	TATA spare parts
T06560000152	GEAR ACCESSORY DRIVE	TATA spare parts
T06560000153	HOSE PLAIN 1150 MM	TATA spare parts
T06560000154	CAP MAIN BEARING	TATA spare parts
T06560000155	CAP MAIN BEARING	TATA spare parts
T06560000156	COUPLING ELBOW HOSE	TATA spare parts
T06560000157	CONNECTOR INJ FUEL SUPPLY	TATA spare parts
T06560000158	COOLER OIL	TATA spare parts
T06560000159	COVER VALVE	TATA spare parts
T06560000160	CLAMP INJECTOR	TATA spare parts
T06560000161	TENSIONER BELT	TATA spare parts
T06560000162	DIPSTICK	TATA spare parts

T06560000163	WIRE GROUND	TATA spare parts
T06560000164	MANIFOLD FUEL	TATA spare parts
T06560000165	SCREW ROUND HEAD CAP	TATA spare parts
T06560000166	TUBE LUB OIL SUCTION	TATA spare parts
T06560000167	PLUG THREADED	TATA spare parts
T06560000168	PLUG THREADED	TATA spare parts
T06560000169	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
T06560000170	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
T06560000171	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
T06560000172	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
T06560000173	PULLEY IDLER	TATA spare parts
T06560000174	FLANGE CRANKSHAFT	TATA spare parts
T06560000175	MANIFOLD EXHAUST	TATA spare parts
T06560000176	CAMSHAFT	TATA spare parts
T06560000177	HOSE PLAIN	TATA spare parts
T06560000178	TURBOCHARGER	TATA spare parts
T06560000179	TURBOCHARGER	TATA spare parts
T06560000180	SENSOR PRESSURE	TATA spare parts
T06560000181	SWITCH PRESSURE	TATA spare parts
T06560000182	CONNECTION WATER OUTLET	TATA spare parts
T06560000183	PUMP FUEL INJECTION	TATA spare parts
T06560000184	HOUSING THERMOSTAT	TATA spare parts
T06560000185	CONNECTION AIR INTAKE	TATA spare parts
T06560000186	CONNECTION WATER INLET	TATA spare parts
T06560000187	FAN ENGINE 24 INCH	TATA spare parts
T06560000188	COMPRESSOR AIR	TATA spare parts
T06560000189	FAN ENGINE	TATA spare parts
T06560000190	TUBE OIL GAUGE	TATA spare parts
T06560000191	DIPSTICK	TATA spare parts
T06560000192	SEAL BANJO CONNECTOR	TATA spare parts
T06560000193	COUPLING PLAIN HOSE	TATA spare parts
T06560000194	FLYWHEEL	TATA spare parts
T06560000195	CONNECTION AIR INTAKE	TATA spare parts
T06560000196	CLIP WIRE RETAINING	TATA spare parts
T06560000197	SEAL OIL	TATA spare parts
T06560000198	GASKET OIL DRAIN	TATA spare parts
T06560000199	WASHER SEALING	TATA spare parts
T06560000200	PLATE COVER	TATA spare parts
T06560000201	ALTERNATOR	TATA spare parts
T06560000202	MOTOR STARTING	TATA spare parts
T06560000203	GASKET COVER PLATE	TATA spare parts
T06560000204	NUT HEXAGON FLANGE	TATA spare parts
T06560000205	BRACKET LIFTING	TATA spare parts
T06560000206	SCREW CAPTIVE WASHER CAP	TATA spare parts
T06560000207	CAP FILLER	TATA spare parts
T06560000208	SEAL O RING	TATA spare parts
T06560000208AE	SEAL O RINGLPTA 1628/LPTA 1828/	TATA spare parts

T06560000209	SCREW SOCKET HEAD CAP	TATA spare parts
T06560000210	PLUNGER PRS REGULATOR	TATA spare parts
T06560000211	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000212	STUD	TATA spare parts
T06560000213	SUPPORT CAMSHAFT THRUST	TATA spare parts
T06560000214	PAN OIL	TATA spare parts
T06560000215	GASKET OIL SUC CONNECTION	TATA spare parts
T06560000216	SEAL O RING	TATA spare parts
T06560000217	GASKET VALVE COVER	TATA spare parts
T06560000218	GASKET RKR LEVER HOUSING	TATA spare parts
T06560000219	ISOLATOR NOISE	TATA spare parts
T06560000220	PLATE COVER	TATA spare parts
T06560000221	CLIP	TATA spare parts
T06560000222	HOSE FLEXIBLE	TATA spare parts
T06560000223	SENSOR PRS TEMPERATURE	TATA spare parts
T06560000224	SENSOR POSITION	TATA spare parts
T06560000225	ASSEMBLY ROCKER LEVER	TATA spare parts
T06560000226	THERMOSTAT	TATA spare parts
T06560000227	TUBE FUEL SUPPLY	TATA spare parts
T06560000228	TUBE FUEL SUPPLY	TATA spare parts
T06560000229	COVER FRONT	TATA spare parts
T06560000230	PLUG PIPE (3/4 NPT)	TATA spare parts
T06560000231	GASKET CYLINDER HEAD	TATA spare parts
T06560000232	CLIP	TATA spare parts
T06560000233	BRACE ALTERNATOR	TATA spare parts
T06560000234	BRACKET LIFTING	TATA spare parts
T06560000235	HARNESS WIRING	TATA spare parts
T06560000236	PLUG PIPE	TATA spare parts
T06560000237	BRACE AIR COMPRESSOR	TATA spare parts
T06560000238	PIPE AIR TRANSFER	TATA spare parts
T06560000239	GASKET OIL PAN	TATA spare parts
T06560000240	CRANKSHAFT ENGINE	TATA spare parts
T06560000241	COMPRESSOR AIR	TATA spare parts
T06560000242	SPRING VALVE	TATA spare parts
T06560000243	HEAD CYLINDER	TATA spare parts
T06560000244	HOUSING GEAR	TATA spare parts
T06560000245	INJECTOR	TATA spare parts
T06560000246	NOZZLE PISTON COOLING	TATA spare parts
T06560000247	SCREW ROUND HEAD CAP	TATA spare parts
T06560000248	PLUG EXPANSION	TATA spare parts
T06560000249	ADAPTER OIL PAN	TATA spare parts
T06560000250	HOUSING ROCKER LEVER	TATA spare parts
T06560000251	CLAMP V BAND	TATA spare parts
T06560000252	CONNECTION EXHAUST OUTLET	TATA spare parts
T06560000253	PUMP LUBRICATING OIL	TATA spare parts
T06560000254	UNION MALE	TATA spare parts
T06560000255	TUBE FUEL SUPPLY	TATA spare parts



T06560000256	CONNECTION WATER INLET	TATA spare parts
T06560000257	HOUSING STARTING AID	TATA spare parts
T06560000258	BRACE TUBE	TATA spare parts
T06560000259	ROD ENGINE CONNECTING	TATA spare parts
T06560000260	HEAD FUEL FILTER	TATA spare parts
T06560000261	STIFFENER CYLINDER BLOCK	TATA spare parts
T06560000261AE	STIFFENER CYLINDER BLOCK 1628	TATA spare parts
T06560000262	BLOCK CYLINDER	TATA spare parts
T06560000263	ADAPTER FUEL CONNECTOR	TATA spare parts
T06560000264	FAN ENGINE	TATA spare parts
T06560000265	DAMPER VIBRATION	TATA spare parts
T06560000266	HOUSING FLYWHEEL	TATA spare parts
T06560000267	SENSOR TEMPERATURE	TATA spare parts
T06560000268	SET MAIN BEARING	TATA spare parts
T06560000269	FLYWHEEL	TATA spare parts
T06560000270	HEAD LUB OIL FILTER	TATA spare parts
T06560000271	PUMP FUEL	TATA spare parts
T06560000272	MODULE ELECTRONIC CONTROL	TATA spare parts
T06560000273	DAMPER VIBRATION	TATA spare parts
T06560000273AE	DAMPER VIBRATION 1628	TATA spare parts
T06560000274	BRACKET ETR CNT MODULE	TATA spare parts
T06560000275	FAN ENGINE	TATA spare parts
T06560000276	FAN ENGINE	TATA spare parts
T06560000277	CLUTCH FAN	TATA spare parts
T06560000278	SET UPPER ENGINE GASKET	TATA spare parts
T06560000279	SET LOWER ENGINE GASKET	TATA spare parts
T06560000280	SET OIL SEALS	TATA spare parts
T06560000280AE	SET OIL SEALS 1628 1828	TATA spare parts
T06560000281	SET FULL ENGINE GASKET	TATA spare parts
T06560000281AE	SET FULL ENGINE GASKET 1628	TATA spare parts
T06560000282	KIT ENGINE PISTON (STD.)	TATA spare parts
T06560000283	SET PISTON RING (STD.)	TATA spare parts
T06560000284	SET BEARING CONNECTING ROD (STD.)	TATA spare parts
T06560000285	SET INSERT VALVE (INTAKE)	TATA spare parts
T06560000286	SET INSERT VALVE (EXHAUST)	TATA spare parts
T06560000287	CLIP	TATA spare parts
T06560000288	CLIP	TATA spare parts
T06560000289	SPACER MOUNTING	TATA spare parts
T06560000290	LONG BLOCK 235 HP BS-II	TATA spare parts
T06560000291	COMPRESSOR AIR	TATA spare parts
T06560000292	GASKET EXHAUST MANIFOLD	TATA spare parts
T06560000293	TUBE FUEL SUPPLY	TATA spare parts
T06560000294	SWITCH TEMPERATURE	TATA spare parts
T06560000295	COMPRESSOR AIR	TATA spare parts
T06560000296	SUPPORT ALTERNATOR	TATA spare parts
T06560000297	BRACE ALTERNATOR	TATA spare parts
T06560000298	COVER INTAKE MANIFOLD	TATA spare parts

T06560000299	ELBOW MALE ADAPTER	TATA spare parts
T06560000300	SWITCH PRESSURE	TATA spare parts
T06560000303	TUBE FUEL SUPPLY	TATA spare parts
T06560000304	TUBE AIR FUEL CONTROL	TATA spare parts
T06560000305	INJECTOR	TATA spare parts
T06560000306	SEAL RECTANGULAR RING	TATA spare parts
T06560000307	SPACER MOUNTING	TATA spare parts
T06560000308	MANIFOLD EXHAUST	TATA spare parts
T06560000309	MANIFOLD EXHAUST	TATA spare parts
T06560000310	BRACE ALTERNATOR	TATA spare parts
T06560000311	SPACER MOUNTING	TATA spare parts
T06560000312	LONG BLOCK 4V MECH BSIII	TATA spare parts
T06560000313	SET BARE PISTON 6BT BSIII ENGINE(OLD REC	TATA spare parts
T06560000314	COMPRESSOR AIR	TATA spare parts
T06560000315	MANIFOLD EXHAUST	TATA spare parts
T06560000316	TURBOCHARGER	TATA spare parts
T06560000317	ALTERNATOR	TATA spare parts
T06560000346	SCREW HEX FLANGE HEAD CAP	TATA spare parts
T06560000393	GASKET COVER PLATE	TATA spare parts
T06560000447	LONG BLOCK 235 HP BSII FE	TATA spare parts
T06560000448	LONG BLOCK 180 HP RE BUS BSIII	TATA spare parts
T06560000449	LONG BLOCK FOR ISBE ENG	TATA spare parts
T06560000474	HOUSING GEAR	TATA spare parts
T06560000475	TUBE AIR FUEL CONTROL	TATA spare parts
T06560000476	FAN ENGINE	TATA spare parts
T06560000477	TEE STREET PIPE	TATA spare parts
T06560000478	DAMPER TUNED VIBRATION	TATA spare parts
T06560000479	FAN ENGINE	TATA spare parts
T20183	O RING KIT RANGE	TATA spare parts
T20215	RANGE BUSH KIT	TATA spare parts
T20275	NEEDLE ROLLER ASSY	TATA spare parts
T20611	SYNCHRO RING	TATA spare parts
T21041	GASKET/SEAL KIT	TATA spare parts
T21043	NEEDLE ROLLER BRG KIT - PLANETARY ASSY	TATA spare parts
T21044	O RING KIT	TATA spare parts
T21049	SYNCHRO KIT - FLANGE/RING - MAIN SECTION	TATA spare parts
T21051	SYNCHRO KIT - FLANGE/RING - HI RANGE	TATA spare parts
T21052	SYNCHRO KIT - FLANGE/RING - LO RANGE	TATA spare parts
T63193000001	ASSY CUSHION BLUE	TATA spare parts
T63193000002	ASSY CUSHION BLACK BLUE	TATA spare parts
T63193000003	ASSY ARMREST	TATA spare parts
T63670000001	VALVE NUT TUBELESS TYRE	TATA spare parts
T64782000001	L' SHAPED BALL + SOCKET HINGE	TATA spare parts
T64782000002	TIGHTENING BAR ASSEMBLY	TATA spare parts
T64782000003	HINGES ASSEMBLY	TATA spare parts
T64782000004	DRIVER DOOR LOCK KIT	TATA spare parts
T64782000005	DRIVER DOOR GLASS ASSEMBLY	TATA spare parts

T64782000006	PASSENGER DOOR LOCK KIT	TATA spare parts
T64782000007	RUBBER STOP	TATA spare parts
T64782000008	HINGE 3/4 M- 16	TATA spare parts
T64782000009	TURNING SUPPORT KIT	TATA spare parts
T64782000010	BEARING 40 X 80 X 18	TATA spare parts
T64782000011	BEARING 12 X 32 X 10	TATA spare parts
T64782000012	CYLINDER FOR PLATES	TATA spare parts
T64782000013	SENSITIVITY VALVE	TATA spare parts
T64782000014	FRONT DOOR TENSION BAR	TATA spare parts
T64782000015	REAR DOOR TENSION BAR	TATA spare parts
T64782000016	HINGE SIKB 12F	TATA spare parts
T64782000017	HINGE SIKB 12F	TATA spare parts
T64782000018	CONTACTOR NO 1KG	TATA spare parts
T64782000019	1 LEAF DOOR LOCK KIT	TATA spare parts
T64782000020	2 LEAF DOOR LOCK KIT	TATA spare parts
T64782000021	ENGRAVED SWINGING PUSH BUTTON	TATA spare parts
T64782000022	RACK CYLINDER ASSEMBLY	TATA spare parts
T64782000023	CONNECTOR DIODES 12 PIN 6 DIODES	TATA spare parts
T64782000024	CONNECTOR DIODES 12 PIN 3 DIODES	TATA spare parts
T64830000001	FRONT FRP BUMPER RE SLF	TATA spare parts
T65780000001	NUMBER ONE LEAF	TATA spare parts
T65780000002	NUMBER TWO LEAF	TATA spare parts
T65780000003	NUMBER THREE LEAF	TATA spare parts
T65780000004	NUMBER FOUR LEAF	TATA spare parts
T65780000005	NUMBER FIVE LEAF ASSEMBLY	TATA spare parts
T65780000006	NUMBER SIX LEAF	TATA spare parts
T65780000007	NUMBER SEVEN LEAF	TATA spare parts
T65780000008	CENTER BOLT M12 X 205 CLASS 8.8	TATA spare parts
T65780000009	CLAMP	TATA spare parts
T65780000010	RIVET 10X27	TATA spare parts
T65780000011	M10 X 1.5 X 114 HEX HEAD BOLT	TATA spare parts
T65780000012	M10 X 1.5 X 114 HEX HEAD NUT	TATA spare parts
T65780000013	11 ID X 94 SPACER TUBE	TATA spare parts
T65780000014	M12 X 1.75 HEX HEAD NUT	TATA spare parts
T65780000015	MACHINED BUSH SADDLE WELDMENT LH	TATA spare parts
T65780000016	MACHINED BUSH SADDLE WELDMENT RH	TATA spare parts
T65780000017	SLEEVE INNER	TATA spare parts
TATA000000001	SUPPORT FAN	TATA spare parts
TATA000000002	BRACE AIR COMPRESSOR	TATA spare parts
TATA000000003	COMPRESSOR AIR	TATA spare parts
TATA000000004	SEAL THERMOSTAT	TATA spare parts
TATA000000005	SUPPORTFAN	TATA spare parts
TATA000000006	GASKET CONNECTION	TATA spare parts
TATA000000007	HEATER INTAKE AIR	TATA spare parts
TATA000000015	BCT COMPRESSOR 8.5 CUM	TATA spare parts
TATA000000053	HEAD CYLINDER	TATA spare parts
TATA000000054	HOUSING ASSY REAR FWD	TATA spare parts

TATA00000055	RETURN LINE FILTER	TATA spare parts
TATA00000056	AIR COMPRESSOR	TATA spare parts
TATA00000058	TIPPING CYLINDER	TATA spare parts
TATA00000059	OIL TANK ASSY WITH FITMENT KIT	TATA spare parts
TATA00000060	KIT LINER BLADE ACE	TATA spare parts
TATA00000061	KIT EXCESS PISTON ACE	TATA spare parts
TATA00000062	DESC KIT XS FUEL ACE	TATA spare parts
TATA00000063	OVER HAULING KIT ACE	TATA spare parts
TATA00000064	DESC KIT ADJ.FUEL ACE	TATA spare parts
TATA00000065	ROTOR HEAD ACE	TATA spare parts
TATA00000066	CAM RING ACE	TATA spare parts
TATA00000067	PIPE A TRANSFER	TATA spare parts
TATA00000068	BELT V RIBBED	TATA spare parts
TATA00000069	BEARING CONNECTING	TATA spare parts
TATA00000070	VALVE EXHAUST	TATA spare parts
TATA00000071	VALVE INTAKE	TATA spare parts
TATA00000072	CONTROL BOX BODY	TATA spare parts
TATA00000073	CONTROL BOX COVER - BODY	TATA spare parts
TATA00000074	BASE PLATE FOR CONTROL BOX BODY	TATA spare parts
TATA00000075	PISTON ROD-TAILGATE CYLINDER	TATA spare parts
TATA00000076	PISTON ROD-SWEEPER CYLINDER	TATA spare parts
TATA00000077	SEAL KIT-SWEEPER¿ CYLINDER	TATA spare parts
TATA00000078	PISTON ROD-PACKER CYLINDER	TATA spare parts
TATA00000079	FIRST STAGE-12N EJECTRO CYLINDER	TATA spare parts
TATA00000080	2ND STAGE-12 N EJECTOR CYLINDER	TATA spare parts
TATA00000081	PISTON-12 N EJECTOR CYLINDER	TATA spare parts
TATA00000082	SEAL KIT-12 N EJECTOR CYLINDER	TATA spare parts
TATA00000083	PENDENT SWITCH ON/OFF¿ 2BUTTON	TATA spare parts
TATA00000084	TUBE TAILGATE CYL.	TATA spare parts
TATA00000085	TUBE PACKER CYL.	TATA spare parts
TATA00000086	TUBE SWEEPER CYL.	TATA spare parts
TATA00000087	TUBE EJECTOR CYL. 12N	TATA spare parts
TATA00000088	TUBE BINLIFT CYLINDER	TATA spare parts
TATA00000089	PISTON ROD-BINLIFT CYLINDER	TATA spare parts
TATA00000090	CONTROL BOX TAILGATE	TATA spare parts
TATA00000091	FAN ENGINE	TATA spare parts
TATA00000092	CONNECTION AIR INTAKE	TATA spare parts
TATA00000093	WASHER SEALING	TATA spare parts
TATA00000094	CLIP	TATA spare parts
TATA00000095	HOSE ELBOW	TATA spare parts
TATA00000096	BREATHER CRANKCASE	TATA spare parts
TATA00000097	MOUNTING BRACKET-LEFT	TATA spare parts
TATA00000098	MOUNTING BRACKET-RIGHT	TATA spare parts
TATA00000099	BOTTOM MOUNTING BRACKET	TATA spare parts
TATA00000100	O-RING	TATA spare parts
TATA00000101	HEX.HEAD SCREW M 6X20	TATA spare parts
TATA00000102	HEX.HEAD SCREW M12X60	TATA spare parts

TATA00000103	SUCTION HOSE	TATA spare parts
TATA00000104	PRESSURE HOSE	TATA spare parts
TATA00000105	PRESSURE HOSE	TATA spare parts
TATA00000106	HEX.LOCK NUT	TATA spare parts
TATA00000107	ADAPTOR (1IN BSP X 1IN BSP)	TATA spare parts
TATA00000108	VINYL DIPPED CLAMP(1IN)	TATA spare parts
TATA00000109	HYDRAULIC TANK ASSY WITH VALVE	TATA spare parts
TATA00000110	CABIN VALVE MOUNT BRACKET	TATA spare parts
TATA00000111	CYLINDER RESTNG PAD	TATA spare parts
TATA00000112	CABIN CONTROL VALVE	TATA spare parts
TATA00000113	T-TYPE METAL PISTON BEARING	TATA spare parts
TATA00000114	COVER TUBE FLANGE S/A	TATA spare parts
TATA00000115	LOCK PLATE	TATA spare parts
TATA00000116	SOC.HD.CAP SCREW IS:2269 P12	TATA spare parts
TATA00000117	SEAL KIT	TATA spare parts
TATA00000118	TUBE SUB ASSEMBLY	TATA spare parts
TATA00000119	PISTON 1 ASSEMBLY	TATA spare parts
TATA00000120	PISTON 2 ASSEMBLY	TATA spare parts
TATA00000121	PISTON 3 ASSEMBLY	TATA spare parts
TATA00000122	HYDRAULIC TANK S/A	TATA spare parts
TATA00000123	BONDED SEAL	TATA spare parts
TATA00000124	RETURN LINE FILTER ASSY 140 L	TATA spare parts
TATA00000125	HEX.HD.SCREW M8X16-8.8	TATA spare parts
TATA00000126	HEX.HEAD SCREW M 8X25	TATA spare parts
TATA00000127	CYLINDER	TATA spare parts
TATA00000128	OIL TANK 138/160 L	TATA spare parts
TATA00000129	REPAIR KIT	TATA spare parts
TATA00000130	UPPER ENGINE GASKET KIT	TATA spare parts
TATA00000131	LOWER ENGINE GASKET KIT	TATA spare parts
TATA00000132	VALVE EXHAUST	TATA spare parts
TATA00000133	CAP FILLER	TATA spare parts
TATA00000134	SWITCH PRESSURE	TATA spare parts
TATA00000135	THERMOSTAT	TATA spare parts
TATA00000136	SPACER MOUNTING	TATA spare parts
TATA00000137	TURBOCHARGER	TATA spare parts
TATA00000138	TURBOCHARGER	TATA spare parts
TATA00000139	CYLINDER MOUNTING CRADLE	TATA spare parts
TATA00000140	ASSY PISTON WITH MAGNETIC RING	TATA spare parts
TATA00000141	M12 SPRING WASHER	TATA spare parts
TATA00000142	TENSION SPRING SIDE LOCKING	TATA spare parts
TATA00000143	PNEUMATIC PTO SHIFT CYLINDER	TATA spare parts
TATA00000144	PIN FOR PNEUMATIC CYLINDER MTG	TATA spare parts
TATA00000145	SPLIT PIN	TATA spare parts
TATA00000146	SCREW	TATA spare parts
TATA00000147	HARNESS - MD	TATA spare parts
TATA00000148	HARNESS- TCM	TATA spare parts
TATA00000149	HARNESS T C M	TATA spare parts

TATA00000150	HARNES MAIN	TATA spare parts
TATA00000151	NIPPLE- AUTOMOTIVE PIPE	TATA spare parts
TATA00000152	BALL- 3/4 DIA	TATA spare parts
TATA00000153	KIT C1 AND BALANCE PISTON	TATA spare parts
TATA00000154	BUSHING GEAR SET	TATA spare parts
TATA00000155	BOLT- M10 X 1.5 X 30 LG	TATA spare parts
TATA00000156	BOLT- M10 X 1.5 X 65 LG	TATA spare parts
TATA00000157	BOLT- M10 X 1.5 X 90 LG	TATA spare parts
TATA00000158	PIN- SPRING 5 X 45 LG	TATA spare parts
TATA00000159	PIN- SPRING 5 X 55 LG	TATA spare parts
TATA00000160	BOLT- M10 X 1.5 X 25 LG	TATA spare parts
TATA00000161	BOLT- M10 X 1.5 X 35 LG	TATA spare parts
TATA00000162	BOLT- METRIC HVY HEX HD M6 X 1.0 X 60 LG	TATA spare parts
TATA00000163	BOLT- M6 X 1.0 X 95 LG	TATA spare parts
TATA00000164	BOLT- M6 X 1.0 X 20 LG	TATA spare parts
TATA00000165	BOLT- M6X1X30H	TATA spare parts
TATA00000166	BOLT- M8 X 1.25 X 25 LG	TATA spare parts
TATA00000167	BOLT- M8 X 1.25 X 90 LG	TATA spare parts
TATA00000168	BOLT- L HEX FLANGE HEAD M6X1 45 LG	TATA spare parts
TATA00000169	CONNECTOR SHO 3-WAY	TATA spare parts
TATA00000170	SEAL-CONNECTOR	TATA spare parts
TATA00000171	CONNECTOR - 2-WAY	TATA spare parts
TATA00000172	LOCK	TATA spare parts
TATA00000173	TERMINAL-FEM	TATA spare parts
TATA00000174	LOCK - SECONDARY	TATA spare parts
TATA00000175	CONNECTOR	TATA spare parts
TATA00000176	TERMINAL	TATA spare parts
TATA00000177	CONNECTOR	TATA spare parts
TATA00000178	TERMINAL - FEMALE	TATA spare parts
TATA00000179	TERMINAL FEM	TATA spare parts
TATA00000180	SENSOR TEMPERATURE (OLD T)	TATA spare parts
TATA00000181	CONNECTOR SE	TATA spare parts
TATA00000182	SENSOR ASSEMBLY TEMPERATURE	TATA spare parts
TATA00000183	CONNECTOR	TATA spare parts
TATA00000184	SEAL-O-RING	TATA spare parts
TATA00000185	PACKING O RING	TATA spare parts
TATA00000186	O-RING 16.4 MM ID	TATA spare parts
TATA00000187	PACKING- O RING .299 ID	TATA spare parts
TATA00000188	SEAL RING KIT EXTERNAL	TATA spare parts
TATA00000189	PACKING- O RING 8.92 ID	TATA spare parts
TATA00000190	SPRING ASSY- C1 RETURN	TATA spare parts
TATA00000191	SEALRING EXTERNAL	TATA spare parts
TATA00000192	RING- RET EXT 104 DIA	TATA spare parts
TATA00000193	BEARING ASSY- ROLLER	TATA spare parts
TATA00000194	BEARING ASSY- THRUST PUMP	TATA spare parts
TATA00000195	BRG ASM	TATA spare parts
TATA00000196	PACKING- O RING 25.1 ID	TATA spare parts

TATA00000197	RING- RET INT 281 DIA	TATA spare parts
TATA00000198	PIN-DOWEL 10 X 50 LG	TATA spare parts
TATA00000199	SEAL - FACE	TATA spare parts
TATA00000200	CONE AND ROLLER ASSY- BRG	TATA spare parts
TATA00000201	CUP- ROLLER BRG	TATA spare parts
TATA00000202	PACKING- O RING 11.48 ID	TATA spare parts
TATA00000203	VENT ASSY- OIL	TATA spare parts
TATA00000204	PACKING- O RING 110 ID	TATA spare parts
TATA00000205	BOLT- HEX HD M16 X 2 X 30 LG	TATA spare parts
TATA00000206	BEARING ASSY- THRUST	TATA spare parts
TATA00000207	BEARING ASSY- THRUST	TATA spare parts
TATA00000208	PISTON- BAL ROT CL	TATA spare parts
TATA00000209	PLATE- CL PRESSURE	TATA spare parts
TATA00000210	PISTON-C2	TATA spare parts
TATA00000211	TUBE- OIL FILL	TATA spare parts
TATA00000212	VALVE- LOCKUP	TATA spare parts
TATA00000213	VALVE- LUBE RGLTR	TATA spare parts
TATA00000214	VALVE- EX BACK	TATA spare parts
TATA00000215	SPRING- 14.1 OD X 42.1 LG	TATA spare parts
TATA00000216	SPRING- 11.10 OD X 46.3 L	TATA spare parts
TATA00000217	STOP- LOCKUP VALVE	TATA spare parts
TATA00000218	STOP- LUBE RGLTR	TATA spare parts
TATA00000219	STOP- VALVE	TATA spare parts
TATA00000220	PIN- RET 5 OD X 43 LG	TATA spare parts
TATA00000221	PACKING- O RING 368.8 ID	TATA spare parts
TATA00000222	SPRING- 7.80 OD X 29.2 LG	TATA spare parts
TATA00000223	SEAL RING	TATA spare parts
TATA00000224	PLUG ASSY PRESSURE TAP	TATA spare parts
TATA00000225	ROLLER- STATOR	TATA spare parts
TATA00000226	SPRING- STATOR	TATA spare parts
TATA00000227	WASHER-STATOR THRUST FRNT	TATA spare parts
TATA00000228	RACE- STATOR	TATA spare parts
TATA00000229	GEAR SET-PINION 3000 P2CR/EV DRIVE P1/P2	TATA spare parts
TATA00000230	GEAR ASSY- MATCHED(6)	TATA spare parts
TATA00000231	BOLT- T HEAD	TATA spare parts
TATA00000232	RING- RET INT 159.2 DIA	TATA spare parts
TATA00000233	RING- RET INT 190.2 DIA	TATA spare parts
TATA00000234	GEAR- P2 SUN	TATA spare parts
TATA00000235	BEARING ASSY- THRUST	TATA spare parts
TATA00000236	PIN-RET 2.5 OD X 40 LG	TATA spare parts
TATA00000237	WASHER	TATA spare parts
TATA00000238	SPRING- 22 OD X 98.5 LG	TATA spare parts
TATA00000239	PIN- DOWEL 10 X 32 LG	TATA spare parts
TATA00000240	NUT	TATA spare parts
TATA00000241	GEAR- P3 SUN	TATA spare parts
TATA00000242	WASHER-THRUST P2/EV P1/P2	TATA spare parts
TATA00000243	WASHER- P1 THRUST	TATA spare parts

TATA00000244	SHIM CONVERTER SELECTIVE 0.715 MM (0.028	TATA spare parts
TATA00000245	SHIM COVERTER SELECTIVE 0.485 MM (0.019	TATA spare parts
TATA00000246	SHIM COVERTER SELECTIVE 0.254 MM (0.010	TATA spare parts
TATA00000247	O-RING 66.3 MM ID	TATA spare parts
TATA00000248	GEAR SET- MATCHED(4)	TATA spare parts
TATA00000249	GEAR- P2 PLNT RING	TATA spare parts
TATA00000250	GEAR- P3 PLNT RING	TATA spare parts
TATA00000251	GEAR ASSY- SUN (COMPL)	TATA spare parts
TATA00000252	O-RING	TATA spare parts
TATA00000253	RING- RET INT 45.82 OD	TATA spare parts
TATA00000254	SPRING ASSY- RETURN	TATA spare parts
TATA00000255	SHIM SELECTIVE 0.27 MM (0.01 INCH)	TATA spare parts
TATA00000256	SHIM SELECTIVE 0.54 MM (0.02 INCH)	TATA spare parts
TATA00000257	SHIM SELECTIVE 0.81 MM (0.03 INCH)	TATA spare parts
TATA00000258	SHIM SELECTIVE 1.08 MM (0.04 INCH)	TATA spare parts
TATA00000259	SHIM SELECTIVE 1.35 MM (0.05 INCH)	TATA spare parts
TATA00000260	SHIM SELECTIVE 1.62 MM (0.06 INCH)	TATA spare parts
TATA00000261	SHIM SELECTIVE 1.89 MM (0.07 INCH)	TATA spare parts
TATA00000262	BEARING ASSY- THRUST	TATA spare parts
TATA00000263	RING- RETAINING	TATA spare parts
TATA00000264	HOUSING CONVERTER	TATA spare parts
TATA00000265	GASKET CASE	TATA spare parts
TATA00000266	GASKET CONVERTER HOUSING	TATA spare parts
TATA00000267	FRONT SUPPORT	TATA spare parts
TATA00000268	PACKING-O-RING 13.82 ID	TATA spare parts
TATA00000269	PACKING-O-RING 15.37 ID	TATA spare parts
TATA00000270	PACKING-O-RING 18.54 MM I	TATA spare parts
TATA00000271	LINK SLIP - THROTTLE SEN	TATA spare parts
TATA00000272	STOP- MAIN RGLTR	TATA spare parts
TATA00000273	SEALRING- ROTATING	TATA spare parts
TATA00000274	KIT-SHIM	TATA spare parts
TATA00000275	KIT-SPACER	TATA spare parts
TATA00000276	KIT SHIM	TATA spare parts
TATA00000277	RETAINER SPEED SENSOR	TATA spare parts
TATA00000278	KIT-SEALRING	TATA spare parts
TATA00000279	TURB. ASM	TATA spare parts
TATA00000280	PLATE ASSY- STATOR THRUST	TATA spare parts
TATA00000281	SPACER- BEARING	TATA spare parts
TATA00000282	WASHER-TANGED THRST BRG#2	TATA spare parts
TATA00000283	SHIM TURBINE SELECTIVE 4.203 MM (0.165 I	TATA spare parts
TATA00000284	SHIM TURBINE SELECTIVE 4.381 MM (0.172 I	TATA spare parts
TATA00000285	SHIM TURBINE SELECTIVE 4.559 MM (0.179 I	TATA spare parts
TATA00000286	SHIM TURBINE SELECTIVE 4.736 MM (0.186 I	TATA spare parts
TATA00000287	SHIM TURBINE SELECTIVE 4.914MM (0.193 IN	TATA spare parts
TATA00000288	SHIM TURBINE SELECTIVE 5.092 MM (0.200 I	TATA spare parts
TATA00000289	SHIM TURBINE SELECTIVE 4.000 MM (0.157 I	TATA spare parts
TATA00000290	SEAL QUAD RING	TATA spare parts



TATA00000291	RING- RET EXT 48 DIA	TATA spare parts
TATA00000292	PLATE- WEAR	TATA spare parts
TATA00000293	SCREW - M5 X .08 X 16LG	TATA spare parts
TATA00000294	WASHER - M5 FLAT	TATA spare parts
TATA00000295	PISTON- C5 CLUTCH	TATA spare parts
TATA00000296	STATOR AND CAM ASSY	TATA spare parts
TATA00000297	MODULE	TATA spare parts
TATA00000298	PACKING O RING	TATA spare parts
TATA00000299	SPRING- 11 OD X 30.3 LG	TATA spare parts
TATA00000300	VALVE- CONVERTER REGULATO	TATA spare parts
TATA00000301	SPRING	TATA spare parts
TATA00000302	BRACKET-OIL FILL TUBE	TATA spare parts
TATA00000303	BRACKET-CONV SHIPPING	TATA spare parts
TATA00000304	SENSOR ASSY	TATA spare parts
TATA00000305	RETAINER ASSY-SPRING	TATA spare parts
TATA00000306	PLUG ASSY	TATA spare parts
TATA00000307	RESISTOR 24V TEMPRATURE GUAGE	TATA spare parts
TATA00000308	HARNESS AND SOCKET ASSY	TATA spare parts
TATA00000309	TEMPRATURE GUAGE BULB	TATA spare parts
TATA00000310	INIDICATOR OIL LEVEL	TATA spare parts
TATA00000311	DRUM-ROT. CLUTCH	TATA spare parts
TATA00000312	PLUG END CONV	TATA spare parts
TATA00000313	SEALRING-INT 140 DIA	TATA spare parts
TATA00000314	SWITCH	TATA spare parts
TATA00000315	SWITCH	TATA spare parts
TATA00000316	P3 THRUST WASHER	TATA spare parts
TATA00000317	PLUG- TACHOGRAPH	TATA spare parts
TATA00000318	WASHER- PLUG TACHOGRAPH	TATA spare parts
TATA00000319	O RING	TATA spare parts
TATA00000320	O-RING 12.3 MM ID	TATA spare parts
TATA00000321	PLUG-FLOW VALVE-RET	TATA spare parts
TATA00000322	RING-RET EXT 128 DIA	TATA spare parts
TATA00000323	PUMP ASSY CONVERTER COMPLETE	TATA spare parts
TATA00000324	PUMP ASSY-CO	TATA spare parts
TATA00000325	PUMP - ASSY.	TATA spare parts
TATA00000326	PLATE- LU CL BACKING (MAC	TATA spare parts
TATA00000327	SPRING	TATA spare parts
TATA00000328	DOWEL PIN	TATA spare parts
TATA00000329	PLATE- STIFFENING	TATA spare parts
TATA00000330	SLEEVE-GROUND	TATA spare parts
TATA00000331	CONNECTOR	TATA spare parts
TATA00000332	TERM-SOCKET	TATA spare parts
TATA00000333	PLUG ASSY	TATA spare parts
TATA00000334	PLUG SHIPPING	TATA spare parts
TATA00000335	SCREW TAPPING M8X25	TATA spare parts
TATA00000336	LEVER	TATA spare parts
TATA00000337	PLATE CHANNEL	TATA spare parts

TATA00000338	COVER FILTER	TATA spare parts
TATA00000339	GASKET FILTER COVER	TATA spare parts
TATA00000340	PISTON	TATA spare parts
TATA00000341	SEAL-LIP	TATA spare parts
TATA00000342	RING	TATA spare parts
TATA00000343	SHAFT MAIN CR	TATA spare parts
TATA00000344	ROTOR ASSY	TATA spare parts
TATA00000345	BOLT - 6-32 X 7/16 T10	TATA spare parts
TATA00000346	SPRING DETENT	TATA spare parts
TATA00000347	SPRING	TATA spare parts
TATA00000348	PLUG-OIL FILL HOLE	TATA spare parts
TATA00000349	HUB-C1 DRIVE	TATA spare parts
TATA00000350	HUB - C2 DRIVE	TATA spare parts
TATA00000351	SHAFT ASSY TUR.STD	TATA spare parts
TATA00000352	BUSHING-99ID	TATA spare parts
TATA00000353	BUSHING-68ID	TATA spare parts
TATA00000354	BUSHING-45ID	TATA spare parts
TATA00000355	CLIP - VALVE STOP	TATA spare parts
TATA00000356	PLUG - SV 2 SV 3	TATA spare parts
TATA00000357	BUSHING TORQUE	TATA spare parts
TATA00000358	BRACKET TEMPERATURE SENSOR	TATA spare parts
TATA00000359	PLUG ASSY OIL DRAIN	TATA spare parts
TATA00000360	CAP-CYLINDER END (HYDRAULIC)	TATA spare parts
TATA00000361	CAP-CYLINDER END (GAS)	TATA spare parts
TATA00000362	SEAL-END CAP	TATA spare parts
TATA00000363	HUB ASSY-ROT CL(COMPLETE)	TATA spare parts
TATA00000364	PLATE-APPLY C1	TATA spare parts
TATA00000365	PLATE RETAINING	TATA spare parts
TATA00000366	BOLT-M14 X 2.0 X 70 LG	TATA spare parts
TATA00000367	ORING SOLENOID	TATA spare parts
TATA00000368	PLUG PILOT THREADED	TATA spare parts
TATA00000369	COVER ASSY - BUSHING	TATA spare parts
TATA00000370	RELAY-24 VOLT	TATA spare parts
TATA00000371	PLUG-ACCUMULATOR	TATA spare parts
TATA00000372	PLATE - CL FRICTION C1	TATA spare parts
TATA00000373	PLATE-FRICTION C2	TATA spare parts
TATA00000374	PLATE FRICTION C3/C4	TATA spare parts
TATA00000375	PLATE - FRICTION C5	TATA spare parts
TATA00000376	PLATE-REACTION C1	TATA spare parts
TATA00000377	PLATE-REACTION C2	TATA spare parts
TATA00000378	PLATE-REACTION C5	TATA spare parts
TATA00000379	SHOULDER BOLT	TATA spare parts
TATA00000380	COVER-RET HSG	TATA spare parts
TATA00000381	GASKET RETARDER HOUSING COVER	TATA spare parts
TATA00000382	VALVE-SUMP COOLER AUTOFLO	TATA spare parts
TATA00000383	GASKET RETARDER HOUSING	TATA spare parts
TATA00000384	STATOR - HOUSING	TATA spare parts

TATA00000385	MANIFOLD-JUMPER	TATA spare parts
TATA00000386	GASKET JUMPER MANIFOLD	TATA spare parts
TATA00000387	COVER SENSOR SHIPPING	TATA spare parts
TATA00000388	GASKET SUCTION FILTER	TATA spare parts
TATA00000389	BOLT-HVYHEXFLGM8X1.25 20LG	TATA spare parts
TATA00000390	C1 PISTON	TATA spare parts
TATA00000391	KIT-TRANSMISSION FLUID SAMPLING AND ANAL	TATA spare parts
TATA00000392	GASKET STATOR HOUSING	TATA spare parts
TATA00000393	CARRIER-P1	TATA spare parts
TATA00000394	SPINDLE-P1	TATA spare parts
TATA00000395	SPINDLE-P2 PLANET CR	TATA spare parts
TATA00000396	SPINDLE P3 PLANET CR	TATA spare parts
TATA00000397	CARRIERANDBUSHING ASSY P2 CR	TATA spare parts
TATA00000398	RING-INDEXING P1	TATA spare parts
TATA00000399	RING-INDEXING P2/P3 WR	TATA spare parts
TATA00000400	RING-INDEXING P3 CR	TATA spare parts
TATA00000401	PLATE - THRUST GEAR	TATA spare parts
TATA00000402	KIT-SEALRING	TATA spare parts
TATA00000403	PLATE ASSEMBLY - BACKING	TATA spare parts
TATA00000404	PLATE-BACKING C1	TATA spare parts
TATA00000405	RING-RETAINING EXT	TATA spare parts
TATA00000406	WASHER OUTPUT BELLEVILLE	TATA spare parts
TATA00000407	SHAFT ASSY OUTPUT	TATA spare parts
TATA00000408	SNAPRING	TATA spare parts
TATA00000409	NUT - OUTPUT	TATA spare parts
TATA00000410	CARRIER P3 (CR RET.)	TATA spare parts
TATA00000411	BOLT M10X1.5X100 MM	TATA spare parts
TATA00000412	BOLT M10X1.5X55 MM	TATA spare parts
TATA00000413	BEARING ASSEMBLY P3-CR	TATA spare parts
TATA00000414	P2 CR PINION BEARING ASSEMBLY	TATA spare parts
TATA00000415	P1 PINION BEARING ASSEMBLY	TATA spare parts
TATA00000416	CONNECTOR - 2 WAY	TATA spare parts
TATA00000417	BOLT-M10X1.5X192 12 PT HEAD	TATA spare parts
TATA00000418	BOLT-M10X1.5X182.5	TATA spare parts
TATA00000419	BOLT- M12 X 1.75 X 190 LG	TATA spare parts
TATA00000420	BOLT - M12 X 1.75 X 130MM	TATA spare parts
TATA00000421	SOLENOID VARIABLE BLEED CENH	TATA spare parts
TATA00000422	BEZEL LEVER RIGHT	TATA spare parts
TATA00000423	LABEL - MODE DISPLAY DUA	TATA spare parts
TATA00000424	SCREW - STOP MOUNTING	TATA spare parts
TATA00000425	PISTON - LOCKUP (MACHINING)	TATA spare parts
TATA00000426	GEAR SET ASSY - GEROTOR	TATA spare parts
TATA00000427	BUSHING - GEROTOR PUMP	TATA spare parts
TATA00000428	SEAL - WT HARNESS STANDOFF	TATA spare parts
TATA00000429	MD P1 RING GEAR	TATA spare parts
TATA00000430	HOUSING ASSEMBLY-PUMP (STD)	TATA spare parts
TATA00000431	SOLENOID & CONNECTION ASSY.	TATA spare parts

TATA00000432	VALVE REGULATOR	TATA spare parts
TATA00000433	VALVE RELAY	TATA spare parts
TATA00000434	PLATE - REACTION C3/C4	TATA spare parts
TATA00000435	HOUSING - C4 CL	TATA spare parts
TATA00000436	PLATE ASSY-PISTON RET C3/C4	TATA spare parts
TATA00000437	HOUSING - C3 CLUTCH	TATA spare parts
TATA00000438	PLUG ASSEMBLY STRAIGHT THREAD O-RING 7	TATA spare parts
TATA00000439	PLATE - RETARDER SEPARATOR	TATA spare parts
TATA00000440	PLATE - SEPARATOR	TATA spare parts
TATA00000441	GASKET - MD CHANNEL PLATE	TATA spare parts
TATA00000442	VALVE - CONTROL MAIN	TATA spare parts
TATA00000443	SPRING - CONTROL MAIN	TATA spare parts
TATA00000444	VALVE - MAIN REGULATOR	TATA spare parts
TATA00000445	VALVE - C1 LATCH	TATA spare parts
TATA00000446	STOP - LATCH	TATA spare parts
TATA00000447	BODY ASSEMBLY -PIN/SOLENOID	TATA spare parts
TATA00000448	VALVE - TCC TRIM	TATA spare parts
TATA00000449	SPRING - TCC TRIM	TATA spare parts
TATA00000450	VALVE - CLUTCH TRIM	TATA spare parts
TATA00000451	VALVE - DIAGNOSTIC	TATA spare parts
TATA00000452	SPRING - DIAGNOSTIC	TATA spare parts
TATA00000453	BRACKET - SOLENOID RIGHT SIDE	TATA spare parts
TATA00000454	PIN - DOWEL	TATA spare parts
TATA00000455	ORING - PACKING 10.65 ID	TATA spare parts
TATA00000456	BODY - RETARDER CONTROL	TATA spare parts
TATA00000457	BOLT - M8 X 1.25 X 65 LG	TATA spare parts
TATA00000458	SEAL-FACE	TATA spare parts
TATA00000459	PIN - RET 2.5 OD X 46 LG	TATA spare parts
TATA00000460	CHANNEL ASSEMBLY	TATA spare parts
TATA00000461	SEAL - DUST/DIRT	TATA spare parts
TATA00000462	SUCTION FILTER AND SEAL ASSY	TATA spare parts
TATA00000463	SENSOR ASSEMBLY-SPEED ROTATIONAL	TATA spare parts
TATA00000464	SENSOR - TURBINE SPEED	TATA spare parts
TATA00000465	SENSOR ASSY SPEED RETARDER	TATA spare parts
TATA00000466	CAP. INTERNAL HARNESS 20W	TATA spare parts
TATA00000467	SEAL ASSEMBLY - OIL	TATA spare parts
TATA00000468	DAMPER ASSEMBLY - COMPLETE	TATA spare parts
TATA00000469	HARNESS-CONNECTOR SERVICE KIT 90 DEG	TATA spare parts
TATA00000470	SOLENOID - CENL VBS	TATA spare parts
TATA00000471	BOLT - TIE ROD	TATA spare parts
TATA00000472	BODY - CYLINDER	TATA spare parts
TATA00000473	O RING	TATA spare parts
TATA00000474	FERRULE - ONE PIECE	TATA spare parts
TATA00000475	KIT - FILTER ASSEMBLY SUCTION	TATA spare parts
TATA00000476	VALVE - LATCH C2	TATA spare parts
TATA00000477	SPRING - LATCH C1/C2	TATA spare parts
TATA00000478	COVER OUT PUT SHIPPING	TATA spare parts

TATA00000479	SEAL ASSEMBLY - OIL	TATA spare parts
TATA00000480	SOLENOID ASSEMBLY - FORWARD	TATA spare parts
TATA00000481	SEALRING - PISTON	TATA spare parts
TATA00000482	SEALRING - PISTON	TATA spare parts
TATA00000483	SEALRING - PISTON	TATA spare parts
TATA00000484	SEALRING - PISTON	TATA spare parts
TATA00000485	SEALRING - PISTON	TATA spare parts
TATA00000486	SEALRING - PISTON	TATA spare parts
TATA00000487	SEALRING - PISTON	TATA spare parts
TATA00000488	LEVER ASSY	TATA spare parts
TATA00000489	SEAL - FILL TUBE	TATA spare parts
TATA00000490	SEAL ASSEMBLY - OUTPUT	TATA spare parts
TATA00000491	KIT - SEAL & GASKET RETARDER	TATA spare parts
TATA00000492	PLATE - CHANNEL	TATA spare parts
TATA00000493	GASKET - CHANNEL PLATE	TATA spare parts
TATA00000494	BODY - VALVE MAIN	TATA spare parts
TATA00000495	PLATE - SEPARATOR SOLENOID	TATA spare parts
TATA00000496	BODY FILTER LIFE	TATA spare parts
TATA00000497	VALVE - FILTER LIFE	TATA spare parts
TATA00000498	SPRING - FILTER LIFE 25 PSI	TATA spare parts
TATA00000499	STOP - CONVERTER REGULATOR	TATA spare parts
TATA00000500	BUSHING - SHAFT	TATA spare parts
TATA00000501	HOUSING ASSEMBLY- RETARDER	TATA spare parts
TATA00000502	BODY - VALVE MAIN	TATA spare parts
TATA00000503	SWITCH ASSY PRESSURE	TATA spare parts
TATA00000504	PISTON C1	TATA spare parts
TATA00000505	PISTON BALANCE	TATA spare parts
TATA00000506	KIT - MAIN VALVE BODY 6 SPEED	TATA spare parts
TATA00000507	PLATE-IDENTIFICATION	TATA spare parts
TATA00000508	PLATE - IDENTIFICATION	TATA spare parts
TATA00000509	KIT-SEAL AND GASKET CONT. MOD.	TATA spare parts
TATA00000510	SPRING - ACCUMULATOR	TATA spare parts
TATA00000511	FILTER KIT	TATA spare parts
TATA00000512	BUSHING - CONVERTER COVER	TATA spare parts
TATA00000513	KIT-SEAL AND GASKET MD CONT. MOD.	TATA spare parts
TATA00000514	HARNESS INTERNAL	TATA spare parts
TATA00000515	SWITCH ASSY PRESSURE	TATA spare parts
TATA00000516	PLATE SEPARATOR	TATA spare parts
TATA00000517	SPRING - TRIM	TATA spare parts
TATA00000518	SENSOR ASSEMBLY - OIL LEVEL	TATA spare parts
TATA00000519	SENSOR ASSY OIL	TATA spare parts
TATA00000520	PISTON - C3/C4	TATA spare parts
TATA00000521	GPVI HARNESS	TATA spare parts
TATA00000522	VIWX HARNESS KIT	TATA spare parts
TATA00000523	HOSE TRANSMISSION TO COOLER	TATA spare parts
TATA00000524	HOSE COOLER TO TRANSMISSION	TATA spare parts
TATA00000525	HARNESS(TCM BACKBONE)	TATA spare parts

TATA00000526	HARNES CAB MD 3K/4K	TATA spare parts
TATA00000527	HARNES CHASIS MD 3K/4K	TATA spare parts
TATA00000528	KIT - SEAL AND GASKET STRAIGHT-THRU	TATA spare parts
TATA00000529	GEAR CRANKSHAFT	TATA spare parts
TATA00000529AE	GEAR CRANKSHAFT 1628	TATA spare parts
TATA00000530	GEAR CRANKSHAFT	TATA spare parts
TATA00000530AE	GEAR CRANKSHAFT 1628	TATA spare parts
TATA00000531	CLIP	TATA spare parts
TATA00000532	KIT TORQUE PLATE LH	TATA spare parts
TATA00000533	KIT TORQUE PLATE RH	TATA spare parts
TATA00000534	KIT BUSH	TATA spare parts
TATA00000535	KIT TUBE -¿ FLANGE AND BRACKET ASSY. - L	TATA spare parts
TATA00000536	KIT TUBE -¿ FLANGE AND BRACKET ASSY. - R	TATA spare parts
TATA00000537	KIT TORQUE PLATE	TATA spare parts
TATA00000538	KIT BUSH	TATA spare parts
TATA00000539	TURBOCHARGER	TATA spare parts
TATA00000540	ADAPTOR 1 IN BSP M X1*3/16 IN UNFORS	TATA spare parts
TATA00000541	SEAL O RING	TATA spare parts
TATA00000542	PIPE AIR TRAN	TATA spare parts
TATA00000543	VALVE SHUTOFF	TATA spare parts
TATA00000544	COUPLING ELBO	TATA spare parts
TATA00000545	SENSOR POSITI	TATA spare parts
TATA00000546	SENSOR POSITI	TATA spare parts
TATA00000547	PLUG PIPE	TATA spare parts
TATA00000548	SEAL O RING	TATA spare parts
TATA00000549	HOSE PLAIN	TATA spare parts
TATA00000550	UNION MALE	TATA spare parts
TATA00000551	CLAMP V BAND	TATA spare parts
TATA00000552	CONNECTOR ELE	TATA spare parts
TATA00000553	SCREW HEX FLA	TATA spare parts
TATA00000554	PLUG THREADED	TATA spare parts
TATA00000555	SCREW HEX FLA	TATA spare parts
TATA00000556	HOSE FLEXIBLE	TATA spare parts
TATA00000557	TUBE OIL GAUG	TATA spare parts
TATA00000558	DOWEL PIN	TATA spare parts
TATA00000559	CLIP	TATA spare parts
TATA00000560	DRAINCOCK	TATA spare parts
TATA00000561	CONNECTION AI	TATA spare parts
TATA00000562	SEAL O RING	TATA spare parts
TATA00000563	SCREW HEX FLA	TATA spare parts
TATA00000564	CONNECTION WA	TATA spare parts
TATA00000565	SCREW HEX FLA	TATA spare parts
TATA00000566	HOSE FLEXIBLE	TATA spare parts
TATA00000567	SCREW HEX FLA	TATA spare parts
TATA00000568	BRACE TUBE	TATA spare parts
TATA00000569	GASKET LUB OI	TATA spare parts
TATA00000570	PLUG THREADED	TATA spare parts

TATA00000571	SCREW STUDED	TATA spare parts
TATA00000572	MANIFOLD EXHA	TATA spare parts
TATA00000573	GASKET EXHAUS	TATA spare parts
TATA00000574	GASKET OIL SU	TATA spare parts
TATA00000575	GEAR FUEL PUM	TATA spare parts
TATA00000576	CROSSHEAD VAL	TATA spare parts
TATA00000577	SCREW HEX FLA	TATA spare parts
TATA00000578	SUPPORT CAMSH	TATA spare parts
TATA00000579	CONNECTION OI	TATA spare parts
TATA00000580	BRACKET FILTE	TATA spare parts
TATA00000581	CROSSHEAD VAL	TATA spare parts
TATA00000582	CAP ADJUSTING	TATA spare parts
TATA00000583	SPACER THREAD	TATA spare parts
TATA00000584	WASHER PLAIN	TATA spare parts
TATA00000585	RING COMPRESS	TATA spare parts
TATA00000586	GEAR CAMSHAFT	TATA spare parts
TATA00000587	SCREW HEX FLA	TATA spare parts
TATA00000588	PIN PISTON	TATA spare parts
TATA00000589	HOUSING BREAT	TATA spare parts
TATA00000590	COVER GEAR	TATA spare parts
TATA00000591	CLAMP INJECTOR	TATA spare parts
TATA00000592	FILTER FUEL	TATA spare parts
TATA00000593	GASKET VALVE	TATA spare parts
TATA00000594	ISOLATOR VIBR	TATA spare parts
TATA00000595	CLIP WIRE RET	TATA spare parts
TATA00000596	HOUSING ENGIN	TATA spare parts
TATA00000597	HOUSING ENGIN	TATA spare parts
TATA00000598	MANIFOLD FUEL	TATA spare parts
TATA00000599	WASHER SEALIN	TATA spare parts
TATA00000600	RING COMPRESS	TATA spare parts
TATA00000601	TUBE INJECTOR	TATA spare parts
TATA00000602	TUBE INJECTOR	TATA spare parts
TATA00000603	TUBE INJECTOR	TATA spare parts
TATA00000604	ROD PUSH	TATA spare parts
TATA00000605	CRANKSHAFT EN	TATA spare parts
TATA00000606	CONNECTION OI	TATA spare parts
TATA00000607	CONNECTION AD	TATA spare parts
TATA00000608	TAPPET VALVE	TATA spare parts
TATA00000609	TUBE FUEL SUP	TATA spare parts
TATA00000610	BEARING CONNE	TATA spare parts
TATA00000611	SCREW STUDED	TATA spare parts
TATA00000612	CORE COOLER	TATA spare parts
TATA00000613	CAMSHAFT	TATA spare parts
TATA00000614	CONNECTION FU	TATA spare parts
TATA00000615	GASKET RKR LE	TATA spare parts
TATA00000616	SKIRT PISTON	TATA spare parts
TATA00000617	DAMPER VISCOU	TATA spare parts

TATA00000618	MANIFOLD EXHA	TATA spare parts
TATA00000619	COVER VALVE	TATA spare parts
TATA00000620	GASKET CONNEC	TATA spare parts
TATA00000621	TUBE FUEL DRA	TATA spare parts
TATA00000622	TUBE FUEL DRA	TATA spare parts
TATA00000623	TUBE FUEL DRA	TATA spare parts
TATA00000624	HARNES WIRIN	TATA spare parts
TATA00000625	HARNES WIRIN	TATA spare parts
TATA00000626	CONNECTION AD	TATA spare parts
TATA00000627	HOUSING ROCKE	TATA spare parts
TATA00000628	CLIP WIRE RET	TATA spare parts
TATA00000629	RING SPEED IN	TATA spare parts
TATA00000630	CLAMP V BAND	TATA spare parts
TATA00000631	SCREW STUDED	TATA spare parts
TATA00000632	PLUG THREADED	TATA spare parts
TATA00000633	PUMP FUEL INJ	TATA spare parts
TATA00000634	PAN OIL	TATA spare parts
TATA00000635	TEE PLAIN ADA	TATA spare parts
TATA00000636	TENSIONER BEL	TATA spare parts
TATA00000637	PLUG THREADED	TATA spare parts
TATA00000638	PLUG THREADED	TATA spare parts
TATA00000639	SUPPORT FUEL	TATA spare parts
TATA00000640	PUMP LUBRICAT	TATA spare parts
TATA00000641	SCREW STUDED	TATA spare parts
TATA00000642	SCREW HEX FLA	TATA spare parts
TATA00000643	TURBOCHARGER	TATA spare parts
TATA00000644	SCREW STUDED	TATA spare parts
TATA00000645	THERMOSTAT	TATA spare parts
TATA00000646	DIPSTICK	TATA spare parts
TATA00000647	BRACKET LIFTI	TATA spare parts
TATA00000648	CONNECTOR QCK	TATA spare parts
TATA00000649	HEATER INTAKE	TATA spare parts
TATA00000650	SCREW HEX FLA	TATA spare parts
TATA00000651	INJECTOR	TATA spare parts
TATA00000652	TOP PISTON	TATA spare parts
TATA00000653	ROD ENGINE CO	TATA spare parts
TATA00000654	NUT LOCK	TATA spare parts
TATA00000655	GASKET CYLIND	TATA spare parts
TATA00000656	BRACKET LIFTI	TATA spare parts
TATA00000657	PLUG THREADED	TATA spare parts
TATA00000658	NUT HEXAGON F	TATA spare parts
TATA00000659	RESISTOR CORR	TATA spare parts
TATA00000660	RING OIL PIST	TATA spare parts
TATA00000661	BEARING MAIN	TATA spare parts
TATA00000662	BEARING MAIN	TATA spare parts
TATA00000663	TURBOCHARGER	TATA spare parts
TATA00000664	CATALYTIC CONVERTER	TATA spare parts



TATA00000665	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
TATA00000666	SHORT FORK TUBE & REAR HOUSING ASSY.	TATA spare parts
TATA00000667	SHORT FORK TUBE & FRONT END PIECE	TATA spare parts
TATA00000668	CENTER BEARING ASSY	TATA spare parts
TATA00000669	HOLDING RELAY	TATA spare parts
TATA00000670	RELAY	TATA spare parts
TATA00000671	PNEUMATIC CYLINDER FORK EXT	TATA spare parts
TATA00000672	RELAY	TATA spare parts
TATA00000673	THREADED BALL JOINT ASSEMBLY RH	TATA spare parts
TATA00000674	ADAPTOR M18X1.5 FS X1/4IN MALE	TATA spare parts
TATA00000675	ADAPTOR 1/4IN BSP (M)X 3/8IN BSP	TATA spare parts
TATA00000676	MANIFOLD BLOCK	TATA spare parts
TATA00000677	PRESSURE RELIEF VALVE	TATA spare parts
TATA00000678	SOLENOID OPT. D.C. VALVE	TATA spare parts
TATA00000679	SKT.HEAD SCREW M5X95-12.9	TATA spare parts
TATA00000680	M12 X 1.5 UNION NUT	TATA spare parts
TATA00000681	M16 X 1.5 / M12 X 1.5 UNION BODY	TATA spare parts
TATA00000682	M14 X 1.5 / M12 X 1.5 UNION BODY	TATA spare parts
TATA00000683	M12 X 1.5 / M12 X 1.5 UNION BODY	TATA spare parts
TATA00000684	M12 X1.5 T CONNECTOR WITH NUT	TATA spare parts
TATA00000685	LEVELLING VALVE LEVER	TATA spare parts
TATA00000686	FR ASPG CRM ASSY	TATA spare parts
TATA00000687	RADIUS ROD ASSY	TATA spare parts
TATA00000688	SPRING WASHER M12	TATA spare parts
TATA00000689	CLIP	TATA spare parts
TATA00000690	CONNECTOR QCK DISCONNECT	TATA spare parts
TATA00000691	SCREW HEX FLANGE HEAD CAP	TATA spare parts
TATA00000692	TUBE CPR WATER QUTELT	TATA spare parts
TATA00000693	TUBE CPR WATER QUTELT	TATA spare parts
TATA00000695	CLIP	TATA spare parts
TATA00000696	CLIP	TATA spare parts
TATA00000697	CONNECTOR MALE	TATA spare parts
TATA00000698	CONNECTOR TUBE	TATA spare parts
TATA00000699	CLIP	TATA spare parts
TATA00000700	TUBE FUEL DRAIN	TATA spare parts
TATA00000701	TURBOCHARGER 280 HP PRIMA TIPPERS	TATA spare parts
TATA00000702	SOL.OPTD PNEUMATIC VALVE	TATA spare parts
TATA00000703	SET PISTON RING E III	TATA spare parts
TATA00000704	KIT ENGINE PISTON E III	TATA spare parts
TATA00000705	V BELT	TATA spare parts
TATA00000706	TAPPET VALVE	TATA spare parts
TATA00000707	VALVE CHECK	TATA spare parts
TATA00000708	COUPLING ELBOW HOSE	TATA spare parts
TATA00000709	HOUSING TIMING PIN	TATA spare parts
TATA00000710	RING RETAINING	TATA spare parts
TATA00000711	AC CLUTCH ASSY. 160 DIA	TATA spare parts
TATA00000712	SPARK PLUG IMPROVED	TATA spare parts

TATA00000713	COMPRESSOR AIR	TATA spare parts
TATA00000714	COMPRESSOR AIR	TATA spare parts
TATA00000715	CONNECTION EXHAUST OUTLET	TATA spare parts
TATA00000716	CONNECTION EXHAUST OUTLET	TATA spare parts
TATA00000717	SEAL O RING	TATA spare parts
TATA00000718	SEAL OIL	TATA spare parts
TATA00000719	ALTERNATOR	TATA spare parts
TATA00000720	PULLEY ALTERNATOR	TATA spare parts
TATA00000721	SEAL GROMMET	TATA spare parts
TATA00000722	NUTJUBE	TATA spare parts
TATA00000723	CONNECTOR MALE	TATA spare parts
TATA00000724	FAN ENGINE	TATA spare parts
TATA00000725	DRIVE FAN	TATA spare parts
TATA00000726	SCREW HEX FLA	TATA spare parts
TATA00000727	ADAPTER CRANK	TATA spare parts
TATA00000728	SCREW HEX FLANGE	TATA spare parts
TATA00000729	BEARING CRANK	TATA spare parts
TATA00000730	NOZZLE PISTON	TATA spare parts
TATA00000731	BLOCK CYUNDE	TATA spare parts
TATA00000732	SCREW SOCKET	TATA spare parts
TATA00000733	CLIP	TATA spare parts
TATA00000734	TUBE LUBOIL	TATA spare parts
TATA00000735	CONNECTOR QCK	TATA spare parts
TATA00000736	TEE PLAIN ADA	TATA spare parts
TATA00000737	TUBE CPRWATE	TATA spare parts
TATA00000738	TUBE CPRWATE	TATA spare parts
TATA00000739	BRACE/TUBE	TATA spare parts
TATA00000740	COUPUNG ELBO	TATA spare parts
TATA00000741	TUBE COM PRESS	TATA spare parts
TATA00000742	UNION MALE	TATA spare parts
TATA00000743	COMPRESSORS	TATA spare parts
TATA00000744	PULLEY CRANKS	TATA spare parts
TATA00000745	WIRE GROUND	TATA spare parts
TATA00000746	HARNESS WIRIN	TATA spare parts
TATA00000747	HARNESS WIRIN	TATA spare parts
TATA00000748	THERMOSTAT	TATA spare parts
TATA00000749	FILTER FUEL	TATA spare parts
TATA00000750	SUPPORT FILTE	TATA spare parts
TATA00000751	SCREW STUDDED	TATA spare parts
TATA00000752	TUBE FUELSUP	TATA spare parts
TATA00000753	TUBE FUELSUP	TATA spare parts
TATA00000754	UNION MALE	TATA spare parts
TATA00000755	PUMP FUELTRA	TATA spare parts
TATA00000756	SCREW STUDDED	TATA spare parts
TATA00000757	CONNECTION	TATA spare parts
TATA00000758	SEAL O RING	TATA spare parts
TATA00000759	CORE COOLER	TATA spare parts

TATA00000760	SEAL RECTANGULAR	TATA spare parts
TATA00000761	CAP FILLER	TATA spare parts
TATA00000762	TUBE FUELSUP	TATA spare parts
TATA00000763	RING COMPRESS	TATA spare parts
TATA00000764	GEAR CAMSHAFT	TATA spare parts
TATA00000765	HEAD CYLINDER	TATA spare parts
TATA00000766	SENSOR PRESSU	TATA spare parts
TATA00000767	BRACEJUBE	TATA spare parts
TATA00000768	TUBE FUELSUP	TATA spare parts
TATA00000769	BRACEJUBE	TATA spare parts
TATA00000770	GASKET EXHAUS	TATA spare parts
TATA00000771	CLAMP HOSE	TATA spare parts
TATA00000772	BELT V RIBBED	TATA spare parts
TATA00000773	FLYWHEEL	TATA spare parts
TATA00000774	PC SERVICE TOOL ON DVD	TATA spare parts
TATA00000775	KIT WIRELESS/USB TRANSLATOR	TATA spare parts
TATA00000776	NAMEPLATE	TATA spare parts
TATA00000777	SPACER CRANKSHAFT	TATA spare parts
TATA00000778	VALVE PRESSURE NREGULATOR	TATA spare parts
TATA00000779	SEAL RECTANGULAR RING	TATA spare parts
TATA00000780	TUBE AIR FUEL CONTROL	TATA spare parts
TATA00000781	SCREW HEX FLANGE HEAD CAP	TATA spare parts
TATA00000782	SCREW HEX FLANGE HEAD CAP	TATA spare parts
TATA00000783	SLEEVE	TATA spare parts
TATA00000784	SCREW SOCKET HEAD CAP	TATA spare parts
TATA00000785	BODY WASTAGE VALVE	TATA spare parts
TATA00000786	COUPLING ELBOW HOSE	TATA spare parts
TATA00000787	SENSOR MASS FLOW	TATA spare parts
TATA00000788	GASKET PRESSURE MODULE	TATA spare parts
TATA00000789	SCREW STUDED FLANGE CAP	TATA spare parts
TATA00000790	SEAL O RING	TATA spare parts
TATA00000791	SEAL O RING	TATA spare parts
TATA00000792	SEAL O RING	TATA spare parts
TATA00000793	SEAL O RING	TATA spare parts
TATA00000794	TUBE COUPLING	TATA spare parts
TATA00000795	STUD	TATA spare parts
TATA00000796	SCREW HEX FLANGE HEAD CAP	TATA spare parts
TATA00000797	HOSE ELBOW	TATA spare parts
TATA00000798	BRACKET SENSOR	TATA spare parts
TATA00000799	HARENESS WIRING	TATA spare parts
TATA00000800	HOUSING FUEL CONTROL	TATA spare parts
TATA00000801	SEAL O RING	TATA spare parts
TATA00000802	SEAL O RING	TATA spare parts
TATA00000803	SENSOR PRESSURE	TATA spare parts
TATA00000804	SENSOR PRESSURE	TATA spare parts
TATA00000805	SENSOR POSITION	TATA spare parts
TATA00000806	CLAMP HOSE	TATA spare parts

TATA00000807	FAN ENGINE WITH VISCOUS CLUTCH	TATA spare parts
TATA00000808	SYNCHRO SET WITH CLUTCH BODY	TATA spare parts
TATA00000809	FAN ENGINE	TATA spare parts
TATA00000811	COVER FRONT	TATA spare parts
TATA00000812	VALVE EXHAUST	TATA spare parts
TATA00000813	DAMPER VISCOUS VIBRATION	TATA spare parts
TATA00000814	FLYWHEEL	TATA spare parts
TATA00000815	HOUSING FLYWHEEL	TATA spare parts
TATA00000816	SEAL OIL	TATA spare parts
TATA00000817	RETAINER INJ FULSUPCNR	TATA spare parts
TATA00000818	CLAMP INJECTOR	TATA spare parts
TATA00000819	SEAL O RING	TATA spare parts
TATA00000823	PLUG/THREADED	TATA spare parts
TATA00000824	CONNECTION WATER INLET	TATA spare parts
TATA00000824AE	CONNECTION WATER INLET 1628	TATA spare parts
TATA00000825	CONNECTION WATER OUTLET	TATA spare parts
TATA00000826	ASSY. CYLINDER HEAD	TATA spare parts
TATA00000827	REED VALVE PLATE ASSY	TATA spare parts
TATA00000828	BLOCK CYLINDER	TATA spare parts
TATA00000829	MODULE ELECTRONIC CONTROL	TATA spare parts
TATA00000830	PISTON ENGINE	TATA spare parts
TATA00000831	PIN PISTON	TATA spare parts
TATA00000832	RING OIL PISTON	TATA spare parts
TATA00000833	RING COMPRESSION PISTON	TATA spare parts
TATA00000834	RING COMPRESSION PISTON	TATA spare parts
TATA00000835	BEARING CONNECTING ROD	TATA spare parts
TATA00000836	BEARING CONNECTING ROD	TATA spare parts
TATA00000837	SCREW CONNECTING ROD CAP	TATA spare parts
TATA00000839	TUBE FUEL SUPPLY	TATA spare parts
TATA00000840	TUBE FUEL SUPPLY	TATA spare parts
TATA00000841	BRACE TUBE	TATA spare parts
TATA00000842	TUBE FUEL DRAIN	TATA spare parts
TATA00000843	ADAPTER FUEL CONNECTOR	TATA spare parts
TATA00000844	MANIFOLD FUEL	TATA spare parts
TATA00000845	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
TATA00000846	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
TATA00000847	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
TATA00000848	TUBE INJECTOR FUEL SUPPLY	TATA spare parts
TATA00000849	CONNECTOR INJ FUEL SUPPLY	TATA spare parts
TATA00000851	HARNESS ETR CNT MDL WIRING	TATA spare parts
TATA00000852	ASSY FUEL FILTER	TATA spare parts
TATA00000853	HEAD FUEL FILTER	TATA spare parts
TATA00000854	TUBE FUEL SUPPLY	TATA spare parts
TATA00000855	TUBE FUEL SUPPLY	TATA spare parts
TATA00000856	TURBOCHARGER	TATA spare parts
TATA00000858	WATER PUMP	TATA spare parts
TATA00000860	HEX BOLT M14X1.5X35	TATA spare parts

TATA00000863	LONG BLOCK 180 HP NEW RCP RE ENG	TATA spare parts
TATA00000864	LONG BLOCK 180 HP NEW RCP FRT ENG	TATA spare parts
TATA00000866	PULLEY CRANKSHAFT	TATA spare parts
TATA00000867	SENSOR POSITION LEAN BURN ENGINE	TATA spare parts
TATA00000869	STARTER MOTOR	TATA spare parts
TATABB000001	FRONT WINDSHIELD GLASS	TATA spare parts
TATABB000002	FRONT WINDSHIELD RUBER BEADING	TATA spare parts
TATABB000003	REAR WINDSHIELD GLASS	TATA spare parts
TATABB000004	PASSENGER DOOR GLASS	TATA spare parts
TATABB000005	PASSENGER DOOR RUBBER BEADING	TATA spare parts
TATABB000006	DRIVER DOOR BEADING	TATA spare parts
TATABB000007	DRIVER DOOR QUARTER GLASS	TATA spare parts
TATABB000008	EMERGENCY EXIT WINDOW/DOOR BEADING	TATA spare parts
TATABB000009	EMERGENCY EXIT DOOR HANDLE WITH GLASS	TATA spare parts
TATABB000010	EMERGENCY EXIT DOOR HANDLE GLASS BEADING	TATA spare parts
TATABB000011	HEAD LAMP (LH SIDE)	TATA spare parts
TATABB000012	HEAD LAMP (LH SIDE)	TATA spare parts
TATABB000013	HEAD LAMP (RH SIDE)	TATA spare parts
TATABB000014	HEAD LAMP (RH SIDE)	TATA spare parts
TATABB000015	SIDE MARKER LAMP	TATA spare parts
TATABB000016	SIDE BLINKER (FRONT SIDE DEFLECTOR/INDIC	TATA spare parts
TATABB000017	SIDE BLINKER (FRONT SIDE DEFLECTOR/INDIC	TATA spare parts
TATABB000018	HEIGHT MARKER (RED)REAR	TATA spare parts
TATABB000019	HEIGHT MARKER (WHITE)FRONT	TATA spare parts
TATABB000020	NUMBER PLATE LAMP ASSY	TATA spare parts
TATABB000021	SWITCHES - PIANO TYPE	TATA spare parts
TATABB000022	FLOURSCENT LAMP (TUBE LIGHTS)	TATA spare parts
TATABB000023	TAIL LAMP	TATA spare parts
TATABB000024	TAIL LAMP	TATA spare parts
TATABB000025	TAIL LAMP	TATA spare parts
TATABB000026	SALOON LAMP	TATA spare parts
TATABB000027	BATTERY CABLE (RED)	TATA spare parts
TATABB000028	BATTERY CABLE (BLACK)	TATA spare parts
TATABB000029	BATTERY TRAY BEARING	TATA spare parts
TATABB000030	BATTERY TRAY CHAIN	TATA spare parts
TATABB000031	SINGLE POLE CONNECTOR	TATA spare parts
TATABB000032	TWO POLE CONNECTOR	TATA spare parts
TATABB000033	BODY FUSE- 5A	TATA spare parts
TATABB000034	BODY FUSE - 15A	TATA spare parts
TATABB000035	MAXI FUSE 40A	TATA spare parts
TATABB000036	FUSE BOX (BODY)	TATA spare parts
TATABB000037	DOOR HANDLE LOCK WITH KEY	TATA spare parts
TATABB000038	DIKKI LOCK	TATA spare parts
TATABB000039	DIKKI HINGE	TATA spare parts
TATABB000040	DIKKI RUBBER BEADING	TATA spare parts
TATABB000041	DIKKI FLOOR MAT	TATA spare parts
TATABB000042	FRONT BUMPER CPTC	TATA spare parts

TATABB000043	REAR BUMPER CPTC	TATA spare parts
TATABB000044	DOOR ASSY CPTC	TATA spare parts
TATABB000045	DOOR RUBBER BEADING	TATA spare parts
TATABB000046	DOOR HINGES	TATA spare parts
TATABB000047	DOOR BEARINGS/BUSHES	TATA spare parts
TATABB000048	HINGE WITH HANDLE	TATA spare parts
TATABB000049	DOOR STOPPER	TATA spare parts
TATABB000050	LOCKING (TOWER BOLT)	TATA spare parts
TATABB000051	FRONT FACE COMPLETE	TATA spare parts
TATABB000052	REAR FACE COMPLETE	TATA spare parts
TATABB000053	CENTRE GRILL	TATA spare parts
TATABB000054	CENTRE FLAP LOCKING KNOB	TATA spare parts
TATABB000055	GEARBOX CUT OUT	TATA spare parts
TATABB000056	BATTERY COMPARTMENT WITH TRAY	TATA spare parts
TATABB000057	FUEL TANK CUT OUT	TATA spare parts
TATABB000058	FUEL FLAP (RH SIDE PANEL)	TATA spare parts
TATABB000059	AIR CLEANER FLAP	TATA spare parts
TATABB000060	STEERING OIL FLAP	TATA spare parts
TATABB000061	WIPER SYSTEM	TATA spare parts
TATABB000062	ADDITIONAL RVM ASSY RH	TATA spare parts
TATABB000063	RVM ASSY RH	TATA spare parts
TATABB000064	UNDER VIEW MIRROR (ROUND)	TATA spare parts
TATABB000065	RVM ASSY LH	TATA spare parts
TATABB000066	SALOON MIRROR	TATA spare parts
TATABB000067	DRIVER DOOR INNER HANDLE ASSY	TATA spare parts
TATABB000068	MASCOT	TATA spare parts
TATABB000069	TATA (TEXT)	TATA spare parts
TATABB000070	TATA (LOGO)	TATA spare parts
TATABB000071	LCD TV & DVD MTG BRACKET	TATA spare parts
TATABB000072	CAMERA COVER	TATA spare parts
TATABB000073	STOP REQUEST SWITCH	TATA spare parts
TATABB000074	HAND HOLD	TATA spare parts
TATABB000075	ASSY WINDOW LH 1328 X 900 ( C )	TATA spare parts
TATABB000076	ASSY WINDOW RH 1280 X 900 ( G )	TATA spare parts
TATABB000077	ASSY WINDOW LH / RH 1195 X 900 ( B )	TATA spare parts
TATABB000078	ASSY WINDOW LH 1260 X 900 ( D )	TATA spare parts
TATABB000079	ASSY WINDOW RH 805 X 900 ( F )	TATA spare parts
TATABB000080	ASSY WINDOW RH 595 X 900 ( I )	TATA spare parts
TATABB000081	ASSY WINDOW RH 640 X 675 ( H )	TATA spare parts
TATABB000082	ASSY WINDOW LH 690 / 790 X 660 ( A )	TATA spare parts
TATABB000083	ASSY WINDOW RH 575/675 X620 ( E )	TATA spare parts
TATABB000084	WINDOW TOP FIX GLASS	TATA spare parts
TATABB000085	WINDOW TOP FIX GLASS	TATA spare parts
TATABB000086	WINDOW TOP FIX GLASS	TATA spare parts
TATABB000087	WINDOW TOP FIX GLASS	TATA spare parts
TATABB000088	WINDOW TOP FIX GLASS	TATA spare parts
TATABB000089	WINDOW TOP FIX GLASS	TATA spare parts

TATABB000090	FRONT & REAR SLIDING GLASS	TATA spare parts
TATABB000091	FRONT & REAR SLIDING GLASS	TATA spare parts
TATABB000092	FRONT & REAR SLIDING GLASS	TATA spare parts
TATABB000093	FRONT & REAR SLIDING GLASS	TATA spare parts
TATABB000094	FRONT & REAR SLIDING GLASS	TATA spare parts
TATABB000095	FRONT & REAR SLIDING GLASS	TATA spare parts
TATABB000096	FRONT & REAR SLIDING GLASS	TATA spare parts
TATABB000097	FRONT SLIDING GLASS	TATA spare parts
TATABB000098	REAR SLIDING GLASS	TATA spare parts
TATABB000099	FRONT SLIDING GLASS	TATA spare parts
TATABB000100	REAR SLIDING GLASS	TATA spare parts
TATABB000101	DROP SIDE LOAD BODY LPT613/38	TATA spare parts
TATABB000102	SIDE PANEL LH FOR LOAD BODY LPT613/38	TATA spare parts
TATABB000103	SIDE PANEL RH FOR LOAD BODY LPT613/38	TATA spare parts
TATABB000104	CHAIN WITH SLEEVE ( LB )	TATA spare parts
TATABB000105	HANDLE LOCK ASSY( LB )	TATA spare parts
TATABB000106	WIPER BLADE 810 MM	TATA spare parts
TATABB000107	NEW LCV FRP REAR BUMPER	TATA spare parts
TATABB000108	AL. EXTRUSION (LENGTH 4000MM)	TATA spare parts
TATABB000109	MIRROR ARM DRIVER DOOR	TATA spare parts
TATABB000110	DOOR BRUSH	TATA spare parts
TATABB000111	DOOR BRUSH PLATE	TATA spare parts
TATABB000112	GREASE NIPPLE	TATA spare parts
TATABB000113	COVER	TATA spare parts
TATABB000114	PLATE	TATA spare parts
TATABB000115	DASHBOARD COMPLETE	TATA spare parts
TATABB000116	KNOB 50 MM	TATA spare parts
TATABB000117	3 SEATER	TATA spare parts
TATABB000118	3 SEATER	TATA spare parts
TATABB000119	3 SEATER	TATA spare parts
TATABB000120	3 SEATER	TATA spare parts
TATABB000121	3 SEATER	TATA spare parts
TATABB000122	3 SEATER	TATA spare parts
TATABB000123	2 SEATER	TATA spare parts
TATABB000124	2 SEATER	TATA spare parts
TATABB000125	2 SEATER	TATA spare parts
TATABB000126	2 SEATER	TATA spare parts
TATABB000127	AL. EXTRUSION (LENGTH 3500MM)	TATA spare parts
TATABB000128	AL EXTR (LENGTH 2300MM)	TATA spare parts
TATABB000129	MOULDING END	TATA spare parts
TATABB000130	EMERGENCY DOOR ASSY.	TATA spare parts
TATABB000131	DOOR ENG. BRKT B	TATA spare parts
TATABB000132	CLEVIS PIN	TATA spare parts
TATABB000133	BRKT SOLENOID VALVE	TATA spare parts
TATABB000134	FLEXIBLE HOSE (10 MTR)	TATA spare parts
TATABB000135	CORRUGATED PIPE (LENGTH 10 MTR)	TATA spare parts
TATABB000136	FIRE EXTINGUISHER (5KGS)	TATA spare parts

TATABB000137	END BUSH	TATA spare parts
TATABB000138	WINDOW ASSY.	TATA spare parts
TATABB000139	PIPE BRACKET(38 DIA TAPER)	TATA spare parts
TATABB000140	STEERING COVER	TATA spare parts
TATABB000141	BASRUR HATRACK	TATA spare parts
TATABB000142	SPEAKER COVER	TATA spare parts
TATABB000143	DOOR BRUSH	TATA spare parts
TATABB000144	3 SEATER.	TATA spare parts
TATABB000145	SEAT BASE CUSHION	TATA spare parts
TATABB000146	SEAT BASE COVER	TATA spare parts
TATABB000147	BACKREST CUSHION	TATA spare parts
TATABB000148	BACKREST COVER	TATA spare parts
TATABB000149	HEADREST CUSHION	TATA spare parts
TATABB000150	HEADREST COVER	TATA spare parts
TATABB000151	FRONT WINDSHIELD	TATA spare parts
TATABB000152	FRONT FRP	TATA spare parts
TATABB000153	FRONT BUMPER	TATA spare parts
TATABB000154	LAMP (AMBER)	TATA spare parts
TATABB000155	REVERSE LAMP (WHITE)	TATA spare parts
TATABB000156	REAR FOG LAMP LH	TATA spare parts
TATABB000157	REAR NO. PLATE LAMP	TATA spare parts
TATABB000158	RED REFLECTOR	TATA spare parts
TATABB000159	REAR FOG LAMP RH	TATA spare parts
TATABB000160	BRAKE LAMP (RED)	TATA spare parts
TATABB000161	REAR WINDSHIELD	TATA spare parts
TATABB000162	WINDOW ASSY.	TATA spare parts
TATABB000163	WINDOW ASSY.	TATA spare parts
TATABB000164	WINDOW ASSY. (DRIVER)	TATA spare parts
TATABB000165	PEEP GLASS	TATA spare parts
TATABB000166	MIRROR ARM COMPLETE/DRIVER	TATA spare parts
TATABB000167	PEEP GLASS	TATA spare parts
TATABB000168	DOOR BRUSH PLATE	TATA spare parts
TATABB000169	DOOR BRUSH PLATE	TATA spare parts
TATABB000170	WHEEL HUB CAP	TATA spare parts
TATABB000171	WHEEL HUB COVER MTG CAP	TATA spare parts
TATABB000172	BASRUR HATRACK	TATA spare parts
TATABB000173	ROOM MIRROR	TATA spare parts
TATABB000174	PARTITION GLASS ASSEMBLY	TATA spare parts
TATABB000175	PARTITION GLASS	TATA spare parts
TATABB000176	FIRE EXTINGUISHER (2KGS)	TATA spare parts
TATABB000177	WINDOW ASSY.	TATA spare parts
TATABB000178	PASS. DOOR ASSY.	TATA spare parts
TATABB000179	DOOR GLASS-FRONT	TATA spare parts
TATABB000180	DOOR GLASS-REAR	TATA spare parts
TATABB000181	PLATE	TATA spare parts
TATABB000182	ENGINE HOOD	TATA spare parts
TATABB000183	ENGINE HOOD PODEST	TATA spare parts



TATABB000184	WIND SHIELD RUBBER BEADING	TATA spare parts
TATABB000185	AMPLIFIER FOR HISPANO BUS	TATA spare parts
TATABB000186	LH BOTTOM SLIDING GLASS 700X1381 ( C )	TATA spare parts
TATABB000187	LH BOTTOM SLIDING GLASS 700X1310 (D)	TATA spare parts
TATABB000188	LH BOTTOM SLIDING GLASS 700X1030 (B)	TATA spare parts
TATABB000189	LH BOTTOM SLIDING GLASS 700X1234 ( A )	TATA spare parts
TATABB000190	RH BOTTOM SLIDING GLASS 700X1340 ( J )	TATA spare parts
TATABB000191	FRONT SWEL TYPE WINDOW	TATA spare parts
TATABB000192	DRIVER DOOR WINDOW	TATA spare parts
TATABB000193	WINDOW STRIKER OUTER / INNER	TATA spare parts
TATABB000194	FLOCKING CHANNEL	TATA spare parts
TATABB000195	LATCH WINDOW	TATA spare parts
TATABB000196	NUMBER PLATE	TATA spare parts
TATABB000197	REAR FRP	TATA spare parts
TATABB000198	SIDE WINDOW ASSY	TATA spare parts
TATABB000199	SIDE WINDOW ASSY	TATA spare parts
TATABB000200	FIX WINDOW ASSY	TATA spare parts
TATABB000201	SIDE WINDOW ASSY.	TATA spare parts
TATABB000202	SIDE WINDOW ASSY.	TATA spare parts
TATABB000203	DESTINATION PLATE	TATA spare parts
TATABB000204	SEAT ASSY (5-SEATER-ORD)	TATA spare parts
TATABB000205	SEAT ASSY (2-S-ORD-800MM)	TATA spare parts
TATABB000206	SEAT ASSY (ORD-800MM+AREST+BELT)	TATA spare parts
TATABB000207	SEAT ASSY (2-S-ORD-800MM-ARMREST)	TATA spare parts
TATABB000208	SEAT ASSY (3-SEATER+ARMREST)	TATA spare parts
TATABB000209	SEAT ASSY (ORD-SINGLE SEAT+BELT)	TATA spare parts
TATABB000210	FRONT PANEL-ICU	TATA spare parts
TATABB000211	REAR PASS DOOR GLASS	TATA spare parts
TATABB000212	DOOR FRONT	TATA spare parts
TATABB000213	PASS. DOOR GLASS TAPER	TATA spare parts
TATABB000214	PASS DOOR GLASS	TATA spare parts
TATABB000215	DOOR REAR	TATA spare parts
TATABB000216	DRIVER DOOR ASSY	TATA spare parts
TATABB000217	WINDOW	TATA spare parts
TATABB000218	WINDOW ASSY	TATA spare parts
TATABB000219	WINDOW ASSY	TATA spare parts
TATABB000220	WINDOW ASSY	TATA spare parts
TATABB000221	WINDOW	TATA spare parts
TATABB000222	WINDOW	TATA spare parts
TATABB000223	DR. DOOR WINDOW	TATA spare parts
TATABB000224	SEAT ASSY(HBACK-3S-1215MM-V.ENGG)	TATA spare parts
TATABB000225	SEAT ASSY(HBACK-3S-1215MM-BELT+ARM-V.EG)	TATA spare parts
TATABB000226	SEAT ASSY(HBACK-3S-1215MM-AREST-V.ENGG)	TATA spare parts
TATABB000227	SEAT ASSY(HBACK-2S-810MM-VALUE ENGG)	TATA spare parts
TATABB000228	SEAT ASSY(HBACK-2S-810MM-ARM+BELT-V ENG)	TATA spare parts
TATABB000229	SEAT ASSY(HBACK-2S-810MM+AREST-V ENG)	TATA spare parts
TATABB000230	SEAT ASSY(HBACK-3SEATER-REAR SEAT)	TATA spare parts

TATABB000231	FRONT BUMPER	TATA spare parts
TATABB000232	FRP REAR BUMPER	TATA spare parts
TATABB000233	DASH BOARD COMPL.	TATA spare parts
TATABB000234	REAR FRP	TATA spare parts
TATABB000235	BAGGAGE RACK ASSY.	TATA spare parts
TATABB000237	WIPER LINKAGE ASSY. 1700 1800 MM	TATA spare parts
TATABB000238	TWIN ROD WIPER ARM 650 MMç LH	TATA spare parts
TATABB000239	TWIN ROD WIPER ARM 650 MMç RH	TATA spare parts
TATABB000240	EMERGENCY DOOR ASSEMBLY (6HD-LHD)	TATA spare parts
TATABB000241	SEAT ASSY(ORD-2S-800MM-LOW FOAM)	TATA spare parts
TATABB000242	SEAT ASSY(ORD-2S-800MM-LOW F+ARM+BELT)	TATA spare parts
TATABB000243	SEAT ASSY(ORD-3S-1200MM-LOW FOAM)	TATA spare parts
TATABB000244	SEAT ASSY(ORD-3S-1200MM-LOW F+ARM+BELT)	TATA spare parts
TATABB000245	SEAT ASSY(ORD-6S-LOW FOAM)	TATA spare parts
TATABB000246	AIR CLEANER PANEL COMPLETE	TATA spare parts
TATABB000247	REAR VIEW MIRROR	TATA spare parts
TATABB000248	SD WINDOW ASSY(OPTYPE-3PC-TSLD-GRN)	TATA spare parts
TATABB000249	SEAT ASSY (ORD-7-SEATER-MOD)	TATA spare parts
TATABB000250	SEAT ASSY (ORD-2-SEATER-800MM-MOD-TGRD)	TATA spare parts
TATABB000251	SEAT ASSY(ORD 2S-800-TGUARD-BELT)	TATA spare parts
TATABB000252	SEAT ASSY(ORD 3S-1200MM-MOD-TGUARD)	TATA spare parts
TATABB000253	SEAT ASSY(ORD 3S-1200-TGUARD-BELT)	TATA spare parts
TATABB000254	FABRICATED DRIVER'S DOOR(LHD)	TATA spare parts
TATABB000255	SD WIND ASSY(OPTYPE-3PC-TSLD-CUR-GRN)	TATA spare parts
TATABB000256	SD WIND ASSY(OPTYPE-3PC-TSLD-CUR-GRN)	TATA spare parts
TATABB000257	SD WIND ASSY(OPTYPE-3PC-TSLD-CUR-GRN)	TATA spare parts
TATABB000258	SD WIND ASSY(OPTYPE-3PC-TSLD-CUR-GRN)	TATA spare parts
TATABB000259	SD WIND ASSY(OPTYPE-3PC-TSLD-CUR-GRN)	TATA spare parts
TATABB000260	SD WIND ASSY(OPTYPE-3PC-TSLD-CUR-GRN)	TATA spare parts
TATABB000261	SD WIND ASSY(OPTYPE-2PC-TSLD-CUR-GRN)	TATA spare parts
TATABB000262	DRIVER SEAT WITH HDREST (LHD)	TATA spare parts
TATABB000263	SEAT ASSY(HBACK-2S+BELT+POUCH)	TATA spare parts
TATABB000264	SEAT ASSY(HBACK-2-SEATER+AREST+BELT)	TATA spare parts
TATABB000265	SEAT ASSY (JUMP SEATER)	TATA spare parts
TATABB000266	SEAT ASSY(1S+MAGZINE POUCH+SEAT BELT)	TATA spare parts
TATABB000267	SEAT ASSY(5S WITH SEAT BELT)	TATA spare parts
TATABB000268	SEAT ASSY(HBACK-2S+BELT)	TATA spare parts
TATABB000269	FRP REAR BUMPER COMPLETE 613 LH	TATA spare parts
TATABB000270	FRP REAR BUMPER COMPLETE 613 RH	TATA spare parts
TATABB000271	WINDOW ASSY.	TATA spare parts
TATABB000272	WINDOW ASSY.	TATA spare parts
TATABB000273	WINDOW ASSY. (FIXED)	TATA spare parts
TATABB000274	HGHT MARKER LAMP 24V (SILVER+WHITE LENS)	TATA spare parts
TATABB000275	WINDOW ASSY. (DRIVER)	TATA spare parts
TATABB000276	WINDOW ASSY.(EMG. DOOR)	TATA spare parts
TATABB000277	AC BELT ( CRANK PULLEY TO TRANSFER PULLE	TATA spare parts
TATABB000278	AC BELT ( TRANSFER PULLEY TO COMPRESSOR)	TATA spare parts

TATABB000279	AC BELT (¿ COMPRESSOR TO ALTERNATOR)	TATA spare parts
TATABB000280	HT MARKER LAMP (SIL BASE+RED)	TATA spare parts
TATABB000281	DR DOOR MIRROR ARM	TATA spare parts
TATABB000282	MIRROR ARM (CO-DRIVER SIDE)	TATA spare parts
TATABB000283	FIRE EXTINGUISHER (1KG)	TATA spare parts
TATABB000284	HBACK SEAT ASSY (5 SEATER)	TATA spare parts
TATABB000285	HBACK SEAT ASSY (2 SEATER-RH)	TATA spare parts
TATABB000286	HBACK SEAT ASSY (2 SEATER-LH)	TATA spare parts
TATABB000287	HBACK SEAT ASSY (2 SEATER-RH)	TATA spare parts
TATABB000288	HBACK SEAT ASSY (2 SEATER-LH)	TATA spare parts
TATABB000289	HBACK SEAT ASSY (2 SEATER-RH)	TATA spare parts
TATABB000290	HBACK SEAT ASSY (2 SEATER-LH)	TATA spare parts
TATABB000291	HBACK SEAT ASSY (2 SEATER-RH)	TATA spare parts
TATABB000292	HBACK SEAT ASSY (2 SEATER-LH)	TATA spare parts
TATABB000293	HBACK SEAT ASSY (2 SEATER-RH)	TATA spare parts
TATABB000294	HBACK SEAT ASSY (1 SEATER-LH)	TATA spare parts
TATABB000295	HBACK SEAT ASSY (2 SEATER-RH)	TATA spare parts
TATABB000296	GLASS BPR WIND SHIELD RH	TATA spare parts
TATABB000297	GLASS BPR WIND SHIELD LH	TATA spare parts
TATABB000298	GLASS BPR VIEW PORT	TATA spare parts
TATABB000299	GLASS BPR RIGHT FRONT DOOR	TATA spare parts
TATABB000300	GLASS BPR LEFT FRONT DOOR	TATA spare parts
TATABB000301	EMERGENCY DOOR	TATA spare parts
TATABB000302	PASS. DOOR ASSY COMPLETE	TATA spare parts
TATABB000303	EMERGENCY DOOR WINDOW	TATA spare parts
TATABB000304	SD WINDOW ASSY RH - FIRST	TATA spare parts
TATABB000305	SD WINDOW ASSY RH- SIXTH	TATA spare parts
TATABB000306	SD WINDOW ASSY LH -FIRST	TATA spare parts
TATABB000307	SD WINDOW ASSY LH -SIXTH	TATA spare parts
TATABB000308	DAHBOARD	TATA spare parts
TATABB000309	LEFT SIDE FRONT PASSENGER DOOR	TATA spare parts
TATABB000310	BOTH SIDE MIRRORS¿¿ LH	TATA spare parts
TATABB000311	BOTH SIDE MIRRORS¿¿ RH	TATA spare parts
TATABB000312	CYLINDER ASSEMBLY	TATA spare parts
TATABB000313	5/2 SINGLE IMPULSE SINGLE EXTERNAL PILOT	TATA spare parts
TATABB000314	3/2 NO PUSH PULL VALVE WITH STRAINER ASS	TATA spare parts
TATABB000315	3/2 NO PUSH PULL VALVE WITH DETENT VALVE	TATA spare parts
TATABB000316	FLOW CONTROL VALVE 1/4 X 6	TATA spare parts
TATABB000317	UNION TEE	TATA spare parts
TATABB000318	PU TUBE	TATA spare parts
TATABB000319	RELAY BOX ASSLY	TATA spare parts
TATABB000320	COVER ASSEMBLY	TATA spare parts
TATABB000321	FRONT END COVER	TATA spare parts
TATABB000322	REAR END COVER	TATA spare parts
TATABB000323	CYLINDER BARREL	TATA spare parts
TATABB000324	SEAL KIT	TATA spare parts
TATABB000325	PISTON WITH PISTON ROD ASSMBLY	TATA spare parts

TATABB000326	COIL ASSEMBLY	TATA spare parts
TATABB000327	SPOOL ASSEMBLY	TATA spare parts
TATABB000328	MALE ELBOW 1/4 X 6	TATA spare parts
TATABB000329	SILENCER	TATA spare parts
TATABB000330	SPOOL ASSEMBLY	TATA spare parts
TATABB000331	SILENCER	TATA spare parts
TATABB000332	MALE NIPPLE 1/4 X 1/4	TATA spare parts
TATABB000333	STRAINER ASSLY.	TATA spare parts
TATABB000334	RELAY BOX ASSLY	TATA spare parts
TATABB000335	SPOOL ASSEMBLY	TATA spare parts
TATABB000336	COVER ASSEMBLY	TATA spare parts
TATABB000337	ABS BACK COVER	TATA spare parts
TATABB000338	GAS SPRING WITH SPACER	TATA spare parts
TATABB000339	ASSY PLASTIC MAGAZINE POUCH - KIT ASSY	TATA spare parts
TATABB000340	SEAT - TWO SEATER	TATA spare parts
TATABB000341	FRONT WIND SHIELD GLASS-SPLIT -RH	TATA spare parts
TATABB000342	FRONT WIND SHIELD GLASS-SPLIT - LH	TATA spare parts
TATABB000343	FRONT BUMPER-METAL	TATA spare parts
TATABB000344	REAR BUMPER-METAL	TATA spare parts
TATABB000345	ELECTRONIC DISPLAY UNIT-FRONT	TATA spare parts
TATABB000346	AC PIPE LOW / HIGH PRESSURE SET	TATA spare parts
TATABB000347	REAR AC CONDENSER ( 24 VOLT BLOWER )	TATA spare parts
TATABB000348	TATA BADGE	TATA spare parts
TATABB000349	WINDSHIELD GLASS FRONT	TATA spare parts
TATABB000350	WHEEL BOX	TATA spare parts
TATABB000351	WHEEL BOX	TATA spare parts
TATABB000352	DECAL FOR STANDARD LPO 1610/62	TATA spare parts
TATABB000353	REAR STRUCTURE FRP	TATA spare parts
TATABB000354	REAR W/S LH GLASS (LAMINATED)	TATA spare parts
TATABB000355	GLASS LAMINATED (265X875X5 THK)	TATA spare parts
TATABB000356	REAR W/S RH GLASS (LAMINATED)	TATA spare parts
TATABB000359	HAND STRAP (STANDARD)	TATA spare parts
TATABB000360	WIPER BLADE ASSY. 508 MM	TATA spare parts
TATABB000361	LOCKING CLIP (MINI LAMP)	TATA spare parts
TATABB000362	KNOB (CP FLAP)	TATA spare parts
TATABB000363	NOZZEL ASSEMBLY	TATA spare parts
TATABB000364	BULB 24VX10W	TATA spare parts
TATABB000365	EMERGENCY DOOR BEADING	TATA spare parts
TATABB000366	RUBBER EXTRUSION (RUB-RAIL)	TATA spare parts
TATABB000367	TWIN SPINDLE KIT(CD 64)+SPACER	TATA spare parts
TATABB000368	HINGE ASSY FOR RADIATOR FLAP	TATA spare parts
TATABB000369	RUBBER BUFFER	TATA spare parts
TATABB000370	SS LATCH (REAR BAGGAGE DOOR)	TATA spare parts
TATABB000371	PADLOCK FOR REAR BAGGAGE.& TARPULN	TATA spare parts
TATABB000372	ROUND VENTILATOR	TATA spare parts
TATABB000373	SD WINDOW ASSY (CTB-2PC-LAM CLR GLASS)	TATA spare parts
TATABB000374	SD WINDOW ASSY (CTB-2PC-LAM CLR GLASS)	TATA spare parts

TATABB000375	SD WINDOW ASSY (CTB-2PC-LAM CLR GLASS)	TATA spare parts
TATABB000376	SD WINDOW ASSY (CTB-2PC-LAM CLR GLASS)	TATA spare parts
TATABB000377	SD WINDOW ASSY (CTB-2PC-LAM CLR GLASS)	TATA spare parts
TATABB000378	SD WINDOW ASSY (CTB-2PC-LAM CLR GLASS)	TATA spare parts
TATABB000379	SD WINDOW ASSY (CTB-2PC-LAM CLR GLASS)	TATA spare parts
TATABB000380	WEATHER STRIP(MOULD-REAR 5E MODEL)	TATA spare parts
TATABB000381	MUD FLAP FOR 6HD (550X405)	TATA spare parts
TATABB000382	NOTICE BOARD	TATA spare parts
TATABB000383	PIPE BRACKET (25 DIA)	TATA spare parts
TATABB000384	SUNVISOR RHD	TATA spare parts
TATABB000385	ROOM MIRROR ARM	TATA spare parts
TATABB000386	RVM ARM ASSY (5E-RHD-DRIVER SIDE)	TATA spare parts
TATABB000387	RVM ARM ASSY (5E-RHD-CO.DRV SIDE)	TATA spare parts
TATABB000388	RUBBER END BLADE FRONT/RH	TATA spare parts
TATABB000389	RUBBER END BLADE FRONT/LH	TATA spare parts
TATABB000390	CEILING LAMP (24V)	TATA spare parts
TATABB000391	ROUND FOG LAMP	TATA spare parts
TATABB000392	CONNECTING ROD (L=160)	TATA spare parts
TATABB000393	CONNECTING ROD (L=690)	TATA spare parts
TATABB000394	WIPER ARM (PENTOGRAPH-TYPE)	TATA spare parts
TATABB000395	FRP DASH BOARD COMPLETE(5E)	TATA spare parts
TATABB000396	FLASHER UNIT (4X21W/24V-15A)	TATA spare parts
TATABB000397	CD PLAYER WITH USB-FM	TATA spare parts
TATABB000398	FLOUROSCENT LAMP-24V	TATA spare parts
TATABB000399	ANTENNA CHORD - 3 MTS	TATA spare parts
TATABB000400	24-12V 10 A DC-DC CONVERTOR	TATA spare parts
TATABB000401	AL-EXTRUSION (RUB-RAIL)	TATA spare parts
TATABB000402	WEAT.STRIP (PASS.DR-MDL-SMALL D)	TATA spare parts
TATABB000403	WEAT.STRIP (PASS.DR-FLAP/SHAFT)	TATA spare parts
TATABB000404	PVC EXTRUSION (ROOF INNER-WHITE)	TATA spare parts
TATABB000405	EMERGENCY DOOR BEADING	TATA spare parts
TATABB000406	MOULDING END (REAR OUTER)	TATA spare parts
TATABB000407	MOULDING END FOR OPTYPE OUTER (RH)	TATA spare parts
TATABB000408	MOULDING END FOR OPTYPE OUTER (LH)	TATA spare parts
TATABB000409	BUSH FOR DRIVERS COMPARTMENT	TATA spare parts
TATABB000410	PIPE END (D=15)	TATA spare parts
TATABB000411	END BUSH FOR GUARD RAIL	TATA spare parts
TATABB000412	SLEEVE FOR DRAIN HOLE	TATA spare parts
TATABB000413	END CAP FOR RUB RAIL	TATA spare parts
TATABB000414	LEAF SPRING-CATCHER (STAY FRONT)	TATA spare parts
TATABB000415	HINGE ASSY (WITHOUT HANDLE)	TATA spare parts
TATABB000416	HINGE ASSY (WITH HANDLE)	TATA spare parts
TATABB000417	LOCK COMPLETE (SPRING LOCK)	TATA spare parts
TATABB000418	DOOR BRUSH (55X20X320MM)	TATA spare parts
TATABB000419	DRAIN PLUG FOR DRAIN HOLE	TATA spare parts
TATABB000420	GLASS LAMINATED (240X847X5 THK) - FRONT	TATA spare parts
TATABB000421	DESTINATION GLASS (LAMINATED-6MM-5E)	TATA spare parts

TATABB000422	REAR W/S CENTER GLASS (5E-LAMINATED)	TATA spare parts
TATABB000423	FUSE - 5 AMP	TATA spare parts
TATABB000424	FUSE - 10 AMP	TATA spare parts
TATABB000425	FUSE - 15 AMP	TATA spare parts
TATABB000426	HIGHBACK SEAT ASSEMBLY (1-SEATER)	TATA spare parts
TATABB000427	HIGHBACK SEAT ASSEMBLY (2-SEATER)	TATA spare parts
TATABB000428	HIGHBACK SEAT ASSEMBLY (3-SEATER)	TATA spare parts
TATABB000429	DRIVER FOOT STEP PANEL	TATA spare parts
TATABB000430	FRONT WHEEL SIDE COVER	TATA spare parts
TATABB000431	SKIRT PANEL	TATA spare parts
TATABB000432	SKIRT PANEL	TATA spare parts
TATABB000433	SKIRT PANEL( FUEL TANK )	TATA spare parts
TATABB000434	SKIRT PANEL	TATA spare parts
TATABB000435	REAR WHEEL SIDE COVER	TATA spare parts
TATABB000436	REAR WHEEL ( EMG DOOR )	TATA spare parts
TATABB000437	SKIRT PANEL	TATA spare parts
TATABB000438	FRONT WHEEL SIDE COVER	TATA spare parts
TATABB000439	BATTERY BOX PANEL	TATA spare parts
TATABB000440	SKIRT PANEL	TATA spare parts
TATABB000441	BAGGAGE BOX PANEL	TATA spare parts
TATABB000442	SPARE TYRE PANEL	TATA spare parts
TATABB000443	REAR WHEEL SIDE COVER	TATA spare parts
TATABB000444	SKIRT PANEL	TATA spare parts
TATABB000445	DRIVER DOOR GLASS	TATA spare parts
TATABB000446	SIDE WINDOW GLASS	TATA spare parts
TATABB000447	SIDE WINDOW GLASS	TATA spare parts
TATABB000448	EMG.WINDOW GLASS	TATA spare parts
TATABB000449	SIDE WINDOW GLASS	TATA spare parts
TATABB000450	SIDE WINDOW GLASS	TATA spare parts
TATABB000451	LUGGAGE CARRIER	TATA spare parts
TATABB000452	REAR WINDSHIELD GUARD	TATA spare parts
TATABB000453	LADDER ASSEMBLY	TATA spare parts
TATABB000454	PANEL ABOVE THE FRONT WHEEL ON THE LEFT	TATA spare parts
TATABB000455	BATTERY BOX DOOR PANEL ON THE LEFT HAND	TATA spare parts
TATABB000456	SEAT (3 SEATER )	TATA spare parts
TATABB000457	SEAT (3 SEATER )	TATA spare parts
TATABB000458	SEAT (2 SEATER )	TATA spare parts
TATABB000459	SEAT (3 SEATER )	TATA spare parts
TATABB000460	SEAT (7 SEATER )	TATA spare parts
TATABB000461	STEP LAMP (SUNKEN TYPE)	TATA spare parts
TATABB000462	HEAD LAMP SET LHD RH (NON MOT)	TATA spare parts
TATABB000463	HEAD LAMP SET LHD LH (NON MOT)	TATA spare parts
TATABB000464	DOOR ASSY. FRONT	TATA spare parts
TATABB000465	DOOR ASSY. REAR	TATA spare parts
TATABB000466	DOOR BRUSH PLATE	TATA spare parts
TATABB000467	CONOPY	TATA spare parts
TATABB000470	WIPER (FEIPING)	TATA spare parts

TATABB000471	DASHBOARD COMPL.	TATA spare parts
TATABB000472	PASSENGER DOOR BRUSH	TATA spare parts
TATABB000473	DOOR GLASS	TATA spare parts
TATABB000474	DOOR GLASS	TATA spare parts
TATABB000475	WINDOW DRIVER DOOR	TATA spare parts
TATABB000476	WINDOW EMERGENCY DOOR	TATA spare parts
TATABB000477	LH SIDE WINDOW	TATA spare parts
TATABB000478	LH SIDE WINDOW	TATA spare parts
TATABB000479	LH SIDE WINDOW	TATA spare parts
TATABB000480	RH SIDE WINDOW	TATA spare parts
TATABB000481	RH SIDE WINDOW	TATA spare parts
TC0095	HYDRAULIC CYLINDER	TATA spare parts
TDH20116300	YOKE-FLANGE	TATA spare parts
TDH20170100	BRG KIT-JOURNAL	TATA spare parts
TDI20116300	YOKE-FLANGE	TATA spare parts
TDI20116400	YOKE-FLANGE	TATA spare parts
TDI20170100	BRG KIT-JOURNAL	TATA spare parts
TDI20170110	BEARING KIT - JOURNAL	TATA spare parts
TMCONGODK000	DIAGNOSTIC KIT COPY	TATA spare parts
TMCONGODK001	DIAGNOSTIC COMPUTER KIT FOR VEHICLES	TATA spare parts
TMCONGODK002	DIAGNOSTIC COMPUTER SOFTWARE KIT.	TATA spare parts
TMCONGODK003	DIAGNOSTIC KIT - DATA STORAGE	TATA spare parts
TMCONGODK004	DIAGNOSTIC HANDHELD DIGITAL KIT	TATA spare parts
TMCONGODK005	DIAGNOSTIC KIT - PRINTING DEVICE(L)	TATA spare parts
TMCONGODK006	DIAGNOSTIC KIT - PRINTING DEVICE	TATA spare parts
TMCONGODK007	DIAGNOSTIC KIT - POWER SUPPLY	TATA spare parts
TMCONGORK000	SLOTTED ANGLE STORAGE RACKS	TATA spare parts
TMCONGOWK001	INSPECTION LAMP. DROP LIGHT)	TATA spare parts
TMCONGOWK002	AUTO MECHANIC TOOL KIT	TATA spare parts
TMCONGOWK003	TOOLS TROLLEY	TATA spare parts
TMCONGOWK004	ELECTRICIAN TOOLS	TATA spare parts
TMCONGOWK005	TORQUE KIT	TATA spare parts
TMCONGOWK006	ENGINE CHECKING KIT	TATA spare parts
TMCONGOWK007	BENCH GRINDER	TATA spare parts
TMCONGOWK008	PORTABLE ELECTRICAL DRILL MACHINE 1/2 IN	TATA spare parts
TMCONGOWK009	DRILL KIT	TATA spare parts
TMCONGOWK010	RADIUS GAUGE	TATA spare parts
TMCONGOWK011	BENCH DRILL MACHINE	TATA spare parts
TMCONGOWK012	HAND GRINDER M/C	TATA spare parts
TMCONGOWK013	OIL DISPENSING UNIT (WASTE OIL COLLECTIO	TATA spare parts
TMCONGOWK014	USED OIL STORAGE TANK.(1000 LTR CAPACITY	TATA spare parts
TMCONGOWK015	PORTABLE DRUM PUMP.	TATA spare parts
TMCONGOWK016	GREASE BUCKET GUN.( 20 KG. CAPACITY.)	TATA spare parts
TMCONGOWK017	POWER WASHING EQUIPMENT (HIGH PRESSURE	TATA spare parts
TMCONGOWK018	GREASING EQUIPMENT	TATA spare parts
TMCONGOWK019	SOLDERING & BRAZING EQUIPMENT	TATA spare parts
TMCONGOWK020	GAS & ELECTRICAL WELDING MACHINE.	TATA spare parts

TMCONGOWK021	DENTING EQUIPMENT	TATA spare parts
TMCONGOWK022	PAINT SPRAY GUN	TATA spare parts
TMCONGOWK023	BATTERY CHARGER ( 6 BATTERIES IN SERIES)	TATA spare parts
TMCONGOWK024	ELECTRICAL TEST BENCH FOR TESTING INSTR	TATA spare parts
TMCONGOWK025	ENGINE WORK STAND	TATA spare parts
TMCONGOWK026	GEARBOX WORK STAND	TATA spare parts
TMCONGOWK027	AXLE WORK STAND	TATA spare parts
TMCONGOWK028	TROLLEY FOR ENGINE PARTS	TATA spare parts
TMCONGOWK029	NOZZLE TESTER	TATA spare parts
TMCONGOWK030	PNEUMATIC NUT RUNNER (COMPLETE UNIT WITH	TATA spare parts
TMCONGOWK031	JIB CRANE WHEEL MOUNTED 2 TON.	TATA spare parts
TMCONGOWK032	PARTS DEGREASING TANK (MULTIJET PARTS CL	TATA spare parts
TMCONGOWK033	HYD. FLOOR JACK 10 TON CAPACITY.( TROLLE	TATA spare parts
TMCONGOWK034	WALL MOUNTED TYRE INFLATER WITH PRESSURE	TATA spare parts
TMCONGOWK035	40 TON HYDRAULIC PRESS. (HAND OPERATED)	TATA spare parts
TMCONGOWK036	WORK BENCH (WITH VICE.)	TATA spare parts
TMCONGOWK037	REAR AXLE/CHASSIS FRAME SUPPORTS	TATA spare parts
TMCONGOWK038	TROLLEY JACK( 5TON CAPACITY.)	TATA spare parts
TMCONGOWK039	TOWING TACKLE	TATA spare parts
TMCONGOWK040	AIR COMPRESSOR 10 HP	TATA spare parts
TMCONGOWK041	AIR COMPRESSOR 15 HP	TATA spare parts
TMCONGOWK042	GREASE GUN PUSH TYPE	TATA spare parts
TMCONGOWK043	ENGINE OIL REPLACEMENT	TATA spare parts
TMCONGOWK044	GEAR OIL REPLACEMENT	TATA spare parts
TMCONGOWK045	DIFFERENTIAL OIL REPLACEMENT	TATA spare parts
TMCONGOWK046	NON CONTACT DIGITAL TACHOMETER	TATA spare parts
TMCONGOWK047	CYLINDER RE-BORING BAR MACHINE (MODEL C)	TATA spare parts
TMCONGOWK048	BRAKE DRUM MACHINING	TATA spare parts
TMCONGOWK049	BRAKE RIVETING MACHINE	TATA spare parts
TMCONGOWK050	MULTIJET SPARE PARTS WASHER	TATA spare parts
TMCONGOWK051	MIG WELDER	TATA spare parts
TMCONGOWK052	ARC WELDING MACHINE	TATA spare parts
TMCONGOWK053	RECTIFIER WELDING MACHINE	TATA spare parts
TMCONGOWK054	COMPRESSION CHECKING GAUGE AND ADAPTOR	TATA spare parts
TMGOCH415W40	TMGO Diesel Engine Oil CH4 15W40	TATA spare parts
TMGOCI4P10W40	TMGO Engine Oil Ci4 Plus 10W40	TATA spare parts
TMGOCI4P15W40	TMGO Diesel Engine Oil Ci4 Plus 15W40	TATA spare parts
TMGOCK410W30	TMGO Engine oil CK410W30 BSVI	TATA spare parts
TMGOCK410W30001C	TMGO Engine Oil CK410W30 1 Litres PROMO	TATA spare parts
TMGOCK410W30003C	TMGO Engine Oil CK410W30 3 Litres PROMO	TATA spare parts
TMGOCK415W40	TMGO Engine oil CK415W40 BSVI	TATA spare parts
TMGOCK415W40001C	TMGO Engine Oil CK415W40 1 Litres PROMO	TATA spare parts
TMGOCK415W40020C	TMGO Engine Oil CK415W40 20 Litres PROMO	TATA spare parts
TMGOEOCH4001C	TMGO Diesel Engine OilCH415W40 1 Litres PROM	TATA spare parts
TMGOEOCH4003	TMGO DIESEL ENGINE OILCH415W40 3 LITRES	TATA spare parts
TMGOEOCH4003C	TMGO Diesel Engine OilCH415W40 3 Litres	TATA spare parts
TMGOEOCH4005	TMGO Diesel Engine OilCH415W40 5 Litres	TATA spare parts



TMGOEOCH4007	TMGO Diesel Engine OilCH415W40 7.5 Litre	TATA spare parts
TMGOEOCH4007C	TMGO Diesel Engine OilCH415W40 7.5 Litre	TATA spare parts
TMGOEOCI4P001	TMGO DIESEL ENGINE OILCI415W40 1 LITRES	TATA spare parts
TMGOEOCI4P003C	TMGO Diesel Engine Oil CI4P15W40 3L PROM	TATA spare parts
TMGOEOCI4P005	TMGO Diesel Engine Oil CI4P15W40 5L	TATA spare parts
TMGOEOCI4P007C	TMGO Diesel Engine OilCI415W40 7.5L PROM	TATA spare parts
TMGOEOCI4P010	TMGO Diesel Engine OilCI415W40 10 Litres	TATA spare parts
TMGOEOCI4P015	TMGO DIESEL ENGINE OILCI415W40 15 LITRES	TATA spare parts
TMGOEOCI4P015C	TMGO Diesel Engine OilCI415W40 15 Litres Prom	TATA spare parts
TMGOEOCNG003	TMGO GAS ENGINE OIL 15W40 LONG LIFE 3L	TATA spare parts
TMGOEOSYN05W30	TMGO SYNTHETIC ENGINE OIL 5W30	TATA spare parts
TMGOGEO15W40LL	TMGO GAS ENGINE OIL 15W40 LONG LIFE	TATA spare parts
TMGOGR80W90001	TMGO Gear Oil 80W90LL 1 Litre	TATA spare parts
TMGOGR80W90007	TMGO Gear Oil 80W90LL 7.5 Litres	TATA spare parts
TMGOGR80W90007C	TMGO Gear Oil 80W90LL 7.5 Litres PROM	TATA spare parts
TMGOGR80W90010	TMGO Gear Oil 80W90LL 10 Litres	TATA spare parts
TMGOGR80W90LL	TMGO Gear oil 80W90 Long Life	TATA spare parts
TMGOGRSYN75W85	TMGO GEAR SYNTHETIC OIL 75W85	TATA spare parts
TMGOGRSYN75W90	TMGO GEAR SYNTHETIC OIL 75W90	TATA spare parts
TMGOHYD680020	TMGO HYDRAULIC GR68 OIL 20 L	TATA spare parts
TMGOHYDOIL68	TMGO Hydraulic Oil 68 Grade	TATA spare parts
TMGOPROFE80W90LL	TMGO Pro FE 80W90 LL axle oil	TATA spare parts
TMGORA80W140001	TMGO Rear Axle Oil 80W140LL 1 Litre	TATA spare parts
TMGORA80W140010	TMGO Rear Axle Oil 80W140LL 10 Litres	TATA spare parts
TMGORA80W140015	TMGO Rear Axle Oil 80W140LL 15 Litres	TATA spare parts
TMGORA80W140LL	TMGO RA oil 80W140 Long Life	TATA spare parts
TMLBATT105E41LCV	105E41L CV-TML 100AH BATTERY	TATA spare parts
TMLBATT135G51CV	135G51 CV-TML 135AH BATTERY	TATA spare parts
TMLBATT150G51CV	150G51CV-TML 150AH BATTERY	TATA spare parts
TMLBATT38B20L	38B20L-TML 35AH BATTERY	TATA spare parts
TMLBATT70D26L	70D26L-TML 65AH BATTERY	TATA spare parts
TMLBATT80D31R	80D31R-TML 80AH BATTERY	TATA spare parts
TRANSYND	Synthetic Transmission Fluid	TATA spare parts
TYBS1000R20G611TT	Bridgestone 1000R20 G611 TT	TATA spare parts
TYBS1000R20G620TT	Bridgestone 1000R20 G620 TT	TATA spare parts
TYBS1000R20L301TT	Bridgestone 1000R20 L301 TT	TATA spare parts
TYBS1000R20M729TT	Bridgestone 1000R20 M729 TT	TATA spare parts
TYBS1000R20M751HLTT	Bridgestone 1000R20 M751-HL TT	TATA spare parts
TYBS1000R20M751TT	Bridgestone 1000R20 M751 TT	TATA spare parts
TYBS1000R20M840TT	Bridgestone 1000R20 M840 TT	TATA spare parts
TYBS1000R20M851TT	Bridgestone 1000R20 M851 TT	TATA spare parts
TYBS1000R20R153TT	Bridgestone 1000R20 R153 TT	TATA spare parts
TYBS1100R20L301TT	Bridgestone 1100R20 L301 TT	TATA spare parts
TYBS1100R20M729TT	Bridgestone 1100R20 M729 TT	TATA spare parts
TYBS1100R20M751TT	Bridgestone 1100R20 M751 TT	TATA spare parts
TYBS1100R20M840TT	Bridgestone 1100R20 M840 TT	TATA spare parts
TYBS1100R20R150TT	Bridgestone 1100R20 R150 TT	TATA spare parts

TYBS1100R20R153TT	Bridgestone 1100R20 R153 TT	TATA spare parts
TYBS11R225M851TL	Bridgestone 11R22.5 M851 TL	TATA spare parts
TYBS11R225R150TL	Bridgestone 11R22.5 R150 TL	TATA spare parts
TYBS11R225R153TL	Bridgestone 11R22.5 R153 TL	TATA spare parts
TYBS1200R20M840TT	Bridgestone 1200R20 M840 TT	TATA spare parts
TYBS295R225M751TL	Bridgestone 295/80R22.5 M751 TL	TATA spare parts
TYBS295R225M851TL	Bridgestone 295/80R22.5 M851 TL	TATA spare parts
TYBS295R225R150TL	Bridgestone 295/80R22.5 R150 TL	TATA spare parts
TYBS295R225R156TL	Bridgestone 295/80R22.5 R156 TL	TATA spare parts
TYBS295R225R159TL	Bridgestone 295/80R22.5 R159 TL	TATA spare parts
TYBS825R20M751TT	Bridgestone 825R20 M751 TT	TATA spare parts
TYBS825R20R187TT	Bridgestone 825R20 R187 TT	TATA spare parts
TYBS900R20R187TT	Bridgestone 900R20 R187 TT	TATA spare parts
U33009	SPEEDO ADAPTOR	TATA spare parts
U66470000001	SHAFT MAIN SS LENGTH 585MM SHAFT FOR CEN	TATA spare parts
U66470000002	IMPELLER LTB 2 FORNT FOR CENTRIFUGAL PUM	TATA spare parts
U66470000003	IMPELLER LTB 2REAR FOR CENTRIFUGAL PUMP	TATA spare parts
U66470000004	SEAL RADIAL FOR CENTRIFUGAL PUMP	TATA spare parts
U66470000005	DISC FIBER ID 45MM OD 65MM THICKNESS 10M	TATA spare parts
U66470000006	OIL SEAL FOR REAR COVER FOR PUMP GEAR BO	TATA spare parts
U66470000007	OIL SEAL FOR HOUSING FOR PUMP GEAR BOX R	TATA spare parts
U66470000008	O-RING FOR PUMP REAR COVER	TATA spare parts
U66470000009	VALVE SPINDLE FOR ADJUSTING SCREW BODY	TATA spare parts
U66470000010	WHEEL HAND 150MM FOR ADJUSTING SCREW BO	TATA spare parts
U66470000011	FIBRE WASHER FOR DELIVERY COUPLER	TATA spare parts
U66470000012	GASKET BETWEEN EXHAUST PIPE & NOZZLE FOR	TATA spare parts
U66470000013	GASKET BETWEEN HOUSING & NIPPLE	TATA spare parts
U66470000014	UNIVERSAL JOINT CROSS(TATA) SHAFT FOR PT	TATA spare parts
U66470000015	YOKE UNIVERSAL JOINT (TATA) SHAFT FOR PT	TATA spare parts
U66470000016	OIL SEAL FOR OUT PUT SHAFT 58 X 38 X 10	TATA spare parts
U66470000017	GASKET FOR UPPER COVER OF PTP	TATA spare parts
U66470000018	GASKET FOR UPPER BODY OF PTO	TATA spare parts
U66470000019	GASKET FELT FOR PTO	TATA spare parts
U66470000020	GASKET FOR PTO	TATA spare parts
U66470000021	WATER LEVEL INDICATOR(ASSY) FOR WATER TA	TATA spare parts
U66470000022	SCREW FOR ACCELERATOR MANUAL AT REAR	TATA spare parts
U66470000023	GASKET 125MM X 250MM X 3MM TANK TO PUM	TATA spare parts
U66470000024	GASKET ASBESTOS PACKING 75MM X 180MM X 3	TATA spare parts
U66470000025	GASKET 40NB X 120 X 3MM THICKNESS ASBEST	TATA spare parts
U66470000026	GASKET 25NB X 110 X 3MM THICKNESS ASBEST	TATA spare parts
U66470000027	NOZZLE SHUT OFF 6MM NB FOR HOSE REEL	TATA spare parts
U66470000028	RUBBER PACKING FOR WATER TANK	TATA spare parts
U66470000029	RUBBER PACKING FOR WATER TANK	TATA spare parts
U66470000030	RUBBER PACKING FOR WATER TANK	TATA spare parts
U66470000031	HOSE PIPE 15MM NB X 2000MM WATER TANK TO	TATA spare parts
U66470000032	ACRYLIC PIPE 15MM X 1220MM FOR LEVEL IND	TATA spare parts
U66470000036	HOSE RUBBER 12.7MM ID 22MM OD X 5M LONG	TATA spare parts

U66470000037	BALL STEEL 7MM FOR MONITOR	TATA spare parts
U66470000038	O RING 70 X 5MM RUBBER FOR MONITOR	TATA spare parts
U66470000039	GRIP HANDLE RUBBER FOR MONITOR	TATA spare parts
U66470000040	CONNECTION FOR HOSE 20MM NB FOR HOSE RE	TATA spare parts
U8875469	OIL PUMP ASSY 125 STD	TATA spare parts
U8875506	CLUTCH HOUSING ASSY	TATA spare parts
U8875777	LAYSHAFT ASSY	TATA spare parts
U8875888	MAINSHAFT SUB ASSY.	TATA spare parts
U8875987	RANGE CONT.VALVE ASSY	TATA spare parts
U8876353	OIL STRAINER ASSY	TATA spare parts
U8876456	OUTPUT SHAFT ASSY.	TATA spare parts
U8876461	REAR HOUSING ASSY	TATA spare parts
U8876669	PLANET GEAR ASSY	TATA spare parts
U8877191	LRC ASSY RH H-H	TATA spare parts
U8878121	NEEDLE BEARING PACK ASSY	TATA spare parts
U8878649	OIL PUMP ASSY	TATA spare parts
U8878710	LAYSHAFT & BEARING ASSY	TATA spare parts
U8880245	LRC HOUSING ASSEMBLY	TATA spare parts
U8882215	BANJO ADAPTOR	TATA spare parts
UZ0861	HUB OIL SEAL	TATA spare parts
V35025410024	ASSY LADDER	TATA spare parts
V35025410025	ASSY.EQUPT.BOX-SD/LB	TATA spare parts
V35025410026	ASSY.SPR.WHL.LIFTING UNIT	TATA spare parts
V35025410029	ASSY HANDLE	TATA spare parts
V35025411502	WATER TANK INSULATED	TATA spare parts
V35025411512	ASSY.PULLEY	TATA spare parts
V35025411514	PLATE LOCATINGPIN	TATA spare parts
V35025411517	ASSY.ROPE	TATA spare parts
V35025416531	WASHER-SD/LB	TATA spare parts
W01190000001	SUCTION HOSE (1 ID X 850 L)	TATA spare parts
W01190000002	RETURN LINE HOSE (1 ID X 700 L)	TATA spare parts
W01190000003	PRESSURE HOSE (3/4 ID X 600 L)	TATA spare parts
W01190000004	PRESSURE HOSE (1/2 ID X 2450 L)	TATA spare parts
W01190000005	PRESSURE HOSE (3/4 ID X 1750 L)	TATA spare parts
W01190000006	PARALLEL MALE STUD ADAPTOR	TATA spare parts
W01190000007	OIL PIPE S/A	TATA spare parts
W01190000008	VALVE ELBOW WITH SWIVEL NUT ASSY.	TATA spare parts
W01190000009	ADAPTOR (M33X2 / M30X2)	TATA spare parts
W01190000010	CLAMP	TATA spare parts
W01190000011	CLAMP	TATA spare parts
W01190000012	PUMP + GBS 40 PTO ASSY. (PNEUMATIC)	TATA spare parts
W01190000013	SPARE COMPLETE TANK	TATA spare parts
W01190000014	TUBE S/A	TATA spare parts
W01190000015	PISTON - 1	TATA spare parts
W01190000016	INNER PIPE	TATA spare parts
W01190000017	PISTON ROD - 1	TATA spare parts
W01190000018	PISTON - 2	TATA spare parts

W01190000019	PISTON ROD - 2	TATA spare parts
W01190000020	LOCK WASHER - 1	TATA spare parts
W01190000021	H.E.COVER - 1	TATA spare parts
W01190000022	LOCK WAHSER - 2	TATA spare parts
W01190000023	H.E.COVER - 2	TATA spare parts
W01190000024	CLEVIS BUSH	TATA spare parts
W01190000025	PRESS PIECE	TATA spare parts
W01190000026	HEX. SOC. SET SCREW	TATA spare parts
W01190000027	ROD EYE BUSH	TATA spare parts
W01190000028	SPARE SEAL KIT	TATA spare parts
W01190000029	BEARING HOUSING	TATA spare parts
W01190000030	TAPPER ROLLER BEARING	TATA spare parts
W01190000031	SHAFT	TATA spare parts
W01190000032	PIN	TATA spare parts
W01190000033	KIDNEY PLATE (LEFT)	TATA spare parts
W01190000034	HARNESS PLATE	TATA spare parts
W01190000035	PUMP HOUSING	TATA spare parts
W01190000036	PLUNGER SEAT	TATA spare parts
W01190000037	PLUNGER	TATA spare parts
W01190000038	SPRING	TATA spare parts
W01190000039	CHECK VALVE HOUSING	TATA spare parts
W01190000040	SPRING	TATA spare parts
W01190000041	CHECK VALVE	TATA spare parts
W01190000042	NEEDLE ROLLER BEARING	TATA spare parts
W01190000043	INNER RING	TATA spare parts
W01190000044	RETAINING RING	TATA spare parts
W01190000045	RETAINING RING	TATA spare parts
W01190000046	CIRCLIP	TATA spare parts
W01190000047	HEX.SOC.HD.CAP SCREW	TATA spare parts
W01190000048	SEALING WASHER	TATA spare parts
W01190000049	HEX.SOC.HD.SCREW	TATA spare parts
W01190000050	SPRING DOWEL SLEEVE	TATA spare parts
W01190000051	SPARE COMPLETE PUMP	TATA spare parts
W01190000052	SPARE SEAL KIT	TATA spare parts
W01190000053	PTO HOUSING	TATA spare parts
W01190000054	SPLINE COUPLING	TATA spare parts
W01190000055	SHIFTING FORK	TATA spare parts
W01190000056	SHIFTING SHOE	TATA spare parts
W01190000057	SHIFTING CLEVIS	TATA spare parts
W01190000058	HEX.HD.SCREW	TATA spare parts
W01190000059	HEX.NUT	TATA spare parts
W01190000060	OIL SEAL	TATA spare parts
W01190000061	MOUNTING PIN	TATA spare parts
W01190000062	CLAMP	TATA spare parts
W01190000063	PNEUMATIC CYLINDER	TATA spare parts
W01190000064	HEX. HD. SCREW	TATA spare parts
W01190000065	SPRING WASHER	TATA spare parts

W01190000066	HEX. HD. SCREW	TATA spare parts
W01190000067	GASKET PTO	TATA spare parts
W01190000068	SEALING WASHER	TATA spare parts
W01190000069	COUPLING BODY - 2	TATA spare parts
W01190000070	EXHAUST PIPE	TATA spare parts
W01190000071	COMPLETE PTO ASSEMBLY	TATA spare parts
W01190000072	SPOOL	TATA spare parts
W01190000073	VALVE BLOCK	TATA spare parts
W01190000074	SPACER	TATA spare parts
W01190000075	SPRING	TATA spare parts
W01190000076	SPRING SEAT	TATA spare parts
W01190000077	WASHER	TATA spare parts
W01190000078	BALL SEAT	TATA spare parts
W01190000079	ALLOY STEEL BALL	TATA spare parts
W01190000080	SPRING SEAT	TATA spare parts
W01190000081	SPRING	TATA spare parts
W01190000082	RELIEF ADJUSTING SCREW	TATA spare parts
W01190000083	HEX.SOC.HD.SCREW	TATA spare parts
W01190000084	HEX.SOC.SET SCREW	TATA spare parts
W01190000085	SPRING HOUSING	TATA spare parts
W01190000086	HEX.SOC.HD.SCREW	TATA spare parts
W01190000087	EYE	TATA spare parts
W01190000088	PIN	TATA spare parts
W01190000089	HANDLE	TATA spare parts
W01190000090	PIN	TATA spare parts
W01190000091	SPLIT PIN	TATA spare parts
W01190000092	SPARE SEAL KIT	TATA spare parts
W01190000093	HYDRAULIC TANK	TATA spare parts
W01190000094	OIL LEVEL INDICATOR (BULL EYE)	TATA spare parts
W01190000095	RETURN LINE FILTER ASSY.	TATA spare parts
W01190000096	FILTER CARTRIDGE	TATA spare parts
W01190000097	DRAIN PLUG	TATA spare parts
W01190000098	HEX. HEAD. SCREW	TATA spare parts
W01190000099	SPRING WASHER	TATA spare parts
W01190000100	FILLER CUM BREATHER	TATA spare parts
W01190000101	PRESSURE HOSE(1/2"ID X 2050LONG)	TATA spare parts
W01190000102	PRESSURE HOSE(3/4"ID X 1350LONG)	TATA spare parts
W01190000103	SUCTION HOSE (1 1/2IN ID X 1000 L)	TATA spare parts
W01190000104	PRESSURE HOSE (3/4IN ID X 600 L)	TATA spare parts
W01190000105	PRESSURE HOSE (1/2IN ID X 2700 L)	TATA spare parts
W01190000106	PRESSURE HOSE (3/4IN ID X 210 L)	TATA spare parts
W01190000107	PRESSURE HOSE (1/2IN ID X 210 L)	TATA spare parts
W01190000108	PRESSURE HOSE (3/4IN ID X 1900 L)	TATA spare parts
W01190000109	PARALLEL MALE STUD COUPLING BODY (M22X1.	TATA spare parts
W01190000110	SWIVEL ELBOW ASSEMBLY WITH PMSC	TATA spare parts
W01190000111	EQUAL TEE BODY (M26X1.5) DIA 18 PIPE	TATA spare parts
W01190000112	CLAMP	TATA spare parts

W01190000113	EQUAL TEE BODY (M27X2) DIA 20 PIPE	TATA spare parts
W01190000114	HYDRAULIC TANK	TATA spare parts
W01190000115	SPARE SEAL KIT	TATA spare parts
W01190000116	SPARE SEAL KIT	TATA spare parts
W10103500001	LEVELLING VALVE	TATA spare parts
W61550000001	PISTON KIT (85 MM) AIR COMP	TATA spare parts
W61550000002	GASKET KIT (85 MM) AIR COMP	TATA spare parts
W61550000003	REPAIR KIT PISTON RING(STD)	TATA spare parts
W61550000004	REPAIR KIT PISTON	TATA spare parts
W61550000006	CYLINDER HEAD SIDE PORT	TATA spare parts
W61550000007	CYLINDER HEAD TOP PORT	TATA spare parts
W80210000001	PARALLEL AXIS PTO LPK 909	TATA spare parts
W80210000002	TUBE S/A	TATA spare parts
W80210000003	PISTON - 1	TATA spare parts
W80210000004	INNER PIPE	TATA spare parts
W80210000005	PISTON - 2	TATA spare parts
W80210000006	PISTON ROD - 2	TATA spare parts
W80210000007	PISTON ROD - 1	TATA spare parts
W80210000008	LOCK WAHSER - 2	TATA spare parts
W80210000009	LOCK WASHER - 1	TATA spare parts
W80210000010	H.E.COVER - 1	TATA spare parts
W80210000011	H.E.COVER - 2	TATA spare parts
W80210000012	GRUB SCREW	TATA spare parts
W80210000013	GRUB SCREW	TATA spare parts
W80210000014	SHAFT	TATA spare parts
W80210000015	PUMP HOUSING	TATA spare parts
W80210000016	HARNESS PLATE	TATA spare parts
W80210000017	HANDLE	TATA spare parts
W80210000018	HEX. HEAD SCREW (3/8INBSFX1-1/2INLONG) -	TATA spare parts
W80210000019	HYDRAULIC TANK	TATA spare parts
W80210000020	SUCTION HOSE (1IN X 550 LONG)	TATA spare parts
W80210000021	RETURN LINE HOSE (1IN X 660 LONG)	TATA spare parts
W80210000022	PRESSURE HOSE (1/2INIDX600 LONG)	TATA spare parts
W80210000023	PRESSURE HOSE (1/2INIDX620 LONG)	TATA spare parts
W80210000024	SWIVEL ELBOW	TATA spare parts
W80210000025	VALVE OPERATING LEVER & BRACKET S/A	TATA spare parts
W80210000026	HYDRAULIC TANK	TATA spare parts
W80210000027	HYDRAULIC TANK	TATA spare parts
W80210000028	RUBBER STRAP	TATA spare parts
W80210000029	PLAIN WASHER	TATA spare parts
W80210000030	PLAIN WASHER	TATA spare parts
W80210000031	BOWL LESS FILTER	TATA spare parts
W80210000032	PRESSURE HOSE (1/2IN X 620 LONG)	TATA spare parts
W80210000033	PRESSURE HOSE	TATA spare parts
W80210000034	PUSH PULL CABLE	TATA spare parts
W80210000035	DRAIN PLUG	TATA spare parts
W80210000036	PUMP+PTO (PARALLEL AXIS)	TATA spare parts

W80210000037	HOUSING	TATA spare parts
W80210000038	COUPLING (GBS 40)	TATA spare parts
W80210000039	SPACER (GBS 40)	TATA spare parts
W80210000040	B 80 INTERNAL CIRCLIP	TATA spare parts
W80210000041	BEARING COVER (GBS 40)	TATA spare parts
W80210000042	O-RING(GBS 40)	TATA spare parts
W80210000043	PISTON (GBS 40)	TATA spare parts
W80210000044	A 42 EXTERNAL CIRCLIP	TATA spare parts
W80210000045	SPRING	TATA spare parts
W80210000046	M12 X50 HEXAGONAL BOLT	TATA spare parts
W80210000047	HOUSING	TATA spare parts
W80210000048	PISTON	TATA spare parts
W80210000049	U-CUP	TATA spare parts
W80210000050	HEX-SPL-BOLT	TATA spare parts
W80210000051	SPRING	TATA spare parts
W80210000052	BEARING COVER	TATA spare parts
W80210000053	NEEDLE ROLLER BEARING	TATA spare parts
W80210000054	NEEDLE ROLLER BEARING	TATA spare parts
W80210000055	FLANGE(GBS40 PARALLEL AXIS)	TATA spare parts
W80210000056	STUD M12X1.75X100L	TATA spare parts
W80210000057	STUD M12X1.75X115L	TATA spare parts
W80210000058	STUD M12X1.75X50L	TATA spare parts
W80210000059	NUT M12X1.75	TATA spare parts
W80210000060	O-RING	TATA spare parts
W80210000061	PUMP GEAR	TATA spare parts
W80210000062	O - RING	TATA spare parts
W80210000063	DRIVE GEAR	TATA spare parts
W80210000064	WASHER	TATA spare parts
W80210000065	CENTER PORT PUMP	TATA spare parts
W80210000066	BULL EYE	TATA spare parts
W80210000067	BONDED SEAL	TATA spare parts
W80210000068	STUD-3	TATA spare parts
W80210000069	CIRCLIP	TATA spare parts
W80210000070	CABIN CONTROL VALVE MOUNTING BRACKET	TATA spare parts
W80210000071	L-CLAMP	TATA spare parts
W80210000072	BODY LOCK	TATA spare parts
W80210000073	STRAIGHT CLAMP	TATA spare parts
W80210000074	SUCTION HOSE (1INID X 1000 LONG)	TATA spare parts
W80210000075	PRESSURE HOSE ASSY. (1/2INID X 1750 LONG	TATA spare parts
W80210000076	ADAPTOR (1INBSP / M30X2)	TATA spare parts
W80210000077	ADAPTOR (3/4INBSPX3/4INBSP)	TATA spare parts
W80210000078	STRAIGHT ADAPTOR (M39X2 / 1INPIPE)	TATA spare parts
W80210000079	ADAPTOR (M22X1.5 / 3/4INBSP)	TATA spare parts
W80210000080	ADAPTOR (M26X1.5 / M26X1.5)	TATA spare parts
W80210000081	CYLINDER TOP MOUNTING PIN	TATA spare parts
W80210000082	COLLAR	TATA spare parts
W80210000083	FILLER BREATHER	TATA spare parts

W80210000084	CYLINDER MOUNTING BRACKET	TATA spare parts
W80210000085	WASHER	TATA spare parts
W80210000086	FILTER CATRIDGE	TATA spare parts
W80210000087	CAP END COVER	TATA spare parts
W80210000088	C.E COVER CLAMPING RING	TATA spare parts
W80210000089	HEX.HD. SCREW	TATA spare parts
W80210000090	PISTON ROD END PLUG	TATA spare parts
W80210000091	LOWER RING (DIA 91)	TATA spare parts
W80210000092	LOWER RING (DIA 110)	TATA spare parts
W80210000093	SPHERICAL BEARING	TATA spare parts
W80210000094	HEX.SOC.HD.SCREW	TATA spare parts
W80210000095	T-METALLIC PISTON BRG (DIA 91)	TATA spare parts
W80210000096	T-METALLIC PISTON BRG (DIA 110)	TATA spare parts
W80210000097	T-METALLIC PISTON BRG (DIA 129)	TATA spare parts
W80210000098	S-T-METALLIC PISTON BRG (DIA 91)	TATA spare parts
W80210000099	S-T-METALLIC PISTON BRG (DIA 110)	TATA spare parts
W80210000100	S-T-METALLIC PISTON BRG (DIA 129)	TATA spare parts
W80210000101	RAM PROTECTION CAP	TATA spare parts
W80210000102	OUTER TUBE (ASSEMBLED)	TATA spare parts
W80210000103	PISTON ROD - 1 (ASSEMBLED)	TATA spare parts
W80210000104	PISTON ROD - 2 (ASSEMBLED)	TATA spare parts
W80210000105	PISTON ROD - 3 (ASSEMBLED)	TATA spare parts
W80210000106	HYDRAULIC CYLINDER	TATA spare parts
W80210000107	SPACER	TATA spare parts
W80210000108	SPRING SEAT	TATA spare parts
W80210000109	SPRING	TATA spare parts
W80210000110	SPACER	TATA spare parts
W80210000111	PISTON	TATA spare parts
W80210000112	PNEUMATIC COVER	TATA spare parts
W80210000113	BALL SEAT	TATA spare parts
W80210000114	ALLOY STEEL BALL	TATA spare parts
W80210000115	SPRING SEAT	TATA spare parts
W80210000116	SPRING	TATA spare parts
W80210000117	RELIEF ADJ. SCREW	TATA spare parts
W80210000118	DUST PROTECTION CAP	TATA spare parts
W80210000119	METAL CAP	TATA spare parts
W80210000120	HYDRULIC VALVE	TATA spare parts
W80210000121	HEX. HD. SCREW (M6X20)	TATA spare parts
W80210000122	CLAMP (VINYL DIPPED)	TATA spare parts
W80210000123	PRESSURE HOSE ASSY. (3/4INIDX850L)	TATA spare parts
W80210000124	PR. HOSE (3/4INIDX2200L)	TATA spare parts
W80210000125	SUCITON HOSE (1INIDX1140L)	TATA spare parts
W80210000126	ADAPTOR (M39X2 - 1INBSP)	TATA spare parts
W80210000127	NYLOC NUT (M6X1)	TATA spare parts
W80210000128	HOSE STRAP	TATA spare parts
W80210000129	BODY LOCK - HOOK ASSY.	TATA spare parts
W80210000130	BODY LOCK - RUBBER SPRING	TATA spare parts



W80210000131	ADAPTOR (3/4INBSPXM26X1.5)	TATA spare parts
W80210000132	BALL VALVE	TATA spare parts
W80210000133	BODY LOCK - LOCK PLATE ASSY.	TATA spare parts
W80210000134	HYDRULIC TANK ASSY. (50 LTRS.)	TATA spare parts
W80210000135	RETURN LINE HOSE (1IN ID X 750 L)	TATA spare parts
W80210000136	CYLINDER MOUNTING CRADLE ASSEMBLY	TATA spare parts
W80210000137	PUMP ELBOW WITH SWIVEL NUT ASSEMBLY	TATA spare parts
W80210000138	ADAPTOR (1INBSPX1 1/2INBSP)	TATA spare parts
W80210000139	STRAIGHT ADAPTOR	TATA spare parts
W80210000140	ADAPTOR (1INBSPX3/4INBSP)	TATA spare parts
W80210000141	CORRUGATED HOSE	TATA spare parts
W80210000142	HOSE CLIP	TATA spare parts
W80210000143	BODY LOCK ASSY.	TATA spare parts
W80210000144	SPARE COMPLETE TANK	TATA spare parts
W80210000145	STANDARD BONDED SEAL	TATA spare parts
W80210000146	STANDARD O RING	TATA spare parts
W80210000147	LOCK NUT	TATA spare parts
W80210000148	SEALING WASHER	TATA spare parts
W80210000149	ROUND LOGO STICKER	TATA spare parts
W80210000150	INSTRUCTION STICKER	TATA spare parts
W80210000151	HEX. HD. SCREW (M6X30)	TATA spare parts
W80210000152	HEX. HD. NUT (M6X1)	TATA spare parts
X11245	WASHER M 10	TATA spare parts
X11405	BREATHER GEAR BOX	TATA spare parts
X11603	WASHER M 22	TATA spare parts
X14851	DOWEL	TATA spare parts
X2011035	O-RING	TATA spare parts
X2013517	PIPE PLUG 1/8PTF	TATA spare parts
X263160000	PARALLEL AXIS PTO PUMP ASSY LPK909 WIPRO	TATA spare parts
X8870178	NEEDLE ROLLER BRG	TATA spare parts
X8870180	NEEDLE ROLLER BRG	TATA spare parts
X8870277	DOWEL	TATA spare parts
X8870305	NEDLE ROLLER BRG	TATA spare parts
X8870341	CIRCLIP	TATA spare parts
X8870342	CIRCLIP	TATA spare parts
X8870344	CIRCLIP	TATA spare parts
X8870355	ROLLER SYNCHRO	TATA spare parts
X8870356	ROLLER SYNCHRO	TATA spare parts
X8870370	CIRCLIP 40 DIA X 2.12MM	TATA spare parts
X8870371	CIRCLIP 40 DIA X 2.02MM	TATA spare parts
X8870372	CIRCLIP 40 DIA X 2.02MM	TATA spare parts
X8870378	CIRCLIP 60 DIA X 2.10MM	TATA spare parts
X8870536	CIRCLIP 46 DIA X 2.0MM	TATA spare parts
X8870553	NYLOC NUT M 39	TATA spare parts
X8870699	SCREW M 16 X 45	TATA spare parts
X8870711	DETENT BALL	TATA spare parts
X8870726	GROOVED PIN	TATA spare parts

X8870760	INPUT OIL SEAL	TATA spare parts
X8870844	BEARING SYNCHRO HUB	TATA spare parts
X8871258	O RING 24.5 DIA	TATA spare parts
X8871377	BUSH CROSS SHAFT	TATA spare parts
X8871378	DOWEL	TATA spare parts
X8871394	OIL SEAL CROSS SHAFT	TATA spare parts
X8871536	CIRCLIP 40 DIAX1.97THK	TATA spare parts
X8871537	CIRCLIP 40 DIAX1.92THK	TATA spare parts
X8871538	CIRCLIP 40 DIAX1.87MM	TATA spare parts
X8871539	CIRCLIP 40 DIAX1.82MM	TATA spare parts
X8871540	CIRCLIP 40 DIAX1.77MM	TATA spare parts
X8872069	SELECTOR BLOCK	TATA spare parts
X8872233	NEEDLE ROLLER BRG.	TATA spare parts
X8872472	CIRCLIP	TATA spare parts
X8872478	NEEDLE ROLLER BRG.	TATA spare parts
X8872593	BEARING INPUT SHAFT	TATA spare parts
X8872721	BEARING	TATA spare parts
X8872722	OIL SEAL	TATA spare parts
X8873008	O RING ON CYLINDER	TATA spare parts
X8873133	SPEEDO HOUSING MECH.	TATA spare parts
X8873690	NYLON TUBING	TATA spare parts
X8873729	PARALLEL GROOVE PIN	TATA spare parts
X8873734	GASKET END COVER	TATA spare parts
X8873993	CIRCLIP	TATA spare parts
X8873994	CIRCLIP - SYNCHRO	TATA spare parts
X8875280	WASHER	TATA spare parts
X8875292	O RING	TATA spare parts
X8875296	ANNULUS CIRCLIP	TATA spare parts
X8875532	SEALING RING	TATA spare parts
X8875560	FIXED ELBOW ADAPTOR	TATA spare parts
X8875561	ELBOW ADAPTOR 45	TATA spare parts
X8875566	STRAIGHT ADAPTER	TATA spare parts
X8875567	STRAIGHT ADAPTOR	TATA spare parts
X8875568	SWIVEL ELBOW	TATA spare parts
X8875587	BEARING	TATA spare parts
X8875587V	BRG. ASSY	TATA spare parts
X8876391	O RING	TATA spare parts
X8876392	O RING	TATA spare parts
X8876430	BEARING OUT-PUT	TATA spare parts
X8877164	BRG. RR MAIN SHAFT	TATA spare parts
X8878022	NEEDLE BEARING ASSY	TATA spare parts
X8878029	NEEDLE BEARING ASSY	TATA spare parts
X8878033	NEEDLE BEARING ASSY	TATA spare parts
X8878041	NEEDLE BEARING ASSY	TATA spare parts
X8878134	CIRCLIP	TATA spare parts
X8878137	CIRCLIP	TATA spare parts
X8878144	BEARING OUTPUT	TATA spare parts

X8878166	O RING	TATA spare parts
X8878361	CIRCLIP	TATA spare parts
X8878362	CIRCLIP	TATA spare parts
X8878363	CIRCLIP	TATA spare parts
X8878364	CIRCLIP	TATA spare parts
X8878365	CIRCLIP	TATA spare parts
X8878463	NEEDLE ROLLER BEARING	TATA spare parts
X8878681	BEARING INPUT SHAFT	TATA spare parts
X8878682	BEARING REAR - MAINSHAFT	TATA spare parts
X8879111	IAS GASKET	TATA spare parts
X8879112	IAS SEALING	TATA spare parts
X8879145	O-RING	TATA spare parts
X8879146	PILOT VALVE ASSEMBLY	TATA spare parts
X8880820	BEARING-ASSY LAYSHAFT	TATA spare parts
X8881424	CIRCLIP	TATA spare parts
XHS509007	SADDLE ASSEMBLY	TATA spare parts
XHS509039-01	ACTUATOR ARM ASSEMBLY LH	TATA spare parts
XHS509039-02	ACTUATOR ARM ASSEMBLY RH	TATA spare parts
XHS509040-01	SIDE RAIL L/H	TATA spare parts
XHS509040-02	SIDE RAIL R/H	TATA spare parts
XHS509043-01	AXLE SEAT LH	TATA spare parts
XHS509043-02	AXLE SEAT RH	TATA spare parts
XHS509051-01	UPPER AIRSPRING PLATE WELDMENT LH	TATA spare parts
XHS509051-02	UPPER AIRSPRING PLATE WELDMENT RH	TATA spare parts
XHS509076	SHIMMY DAMPER SPACER	TATA spare parts
XHS509082	RETAINING PLATE	TATA spare parts
XHS509083-01	MACHINED BEAM ASSEMBLY LH	TATA spare parts
XHS509083-02	MACHINED BEAM ASSEMBLY RH	TATA spare parts
XHS509084	PLASTIC LINER- 5INCH LONG	TATA spare parts
Y99082010011	FRONT AXLE	TATA spare parts
Y99082010012	REAR AXLE	TATA spare parts
Y99082010013	REAR AXLE	TATA spare parts
Y99082010014	STEERING ASSY LP	TATA spare parts
Y99082010015	STEERING ASSY L	TATA spare parts
Y99082030004	ENGINE LP	TATA spare parts
Y99082030005	ENGINE L	TATA spare parts
Y99082030006	GEAR BOX LP	TATA spare parts
Y99082030007	GEAR BOX L	TATA spare parts
Y99082100011	FRONT AXLE	TATA spare parts
Y99082100013	REAR AXLE LP	TATA spare parts
Z60060000001	STRG RESERVOIR CAP	TATA spare parts
Z60060000002	GREASE	TATA spare parts
Z60060000003	WASHER	TATA spare parts
Z60060000004	SEALING RING	TATA spare parts
Z60060000005	SECTOR SHAFT ASSY	TATA spare parts
Z60060000006	ADJUSTING SCREW	TATA spare parts
Z60060000007	RETAINING RING	TATA spare parts

Z6006000008	HOUSING COVER	TATA spare parts
Z6006000009	GASKET	TATA spare parts
Z6006000010	SUPPORT PLATE	TATA spare parts
Z6006000011	GASKET	TATA spare parts
Z6006000012	GASKET	TATA spare parts
Z6006000013	O RING	TATA spare parts
Z6006000014	GASKET	TATA spare parts
Z6006000015	O RING	TATA spare parts
Z6006000016	PROTECTING SLEEVE	TATA spare parts
Z6006000017	SCREW PLUG M18X1.5	TATA spare parts
Z6006000018	SCREW PLUG	TATA spare parts
Z6006000019	SEALING KIT	TATA spare parts
Z6006000020	HARDWARE KIT	TATA spare parts
Z9001200001	CALIPER RH	TATA spare parts
Z9001200002	CALIPER LH	TATA spare parts
Z9023000001	OIL PUMP	TATA spare parts
Z9023000002	DOUBLE GEAR	TATA spare parts
Z9023000003	SLEEVE CARRIER	TATA spare parts
Z9023000004	SYNCHRO.BODY	TATA spare parts
Z9023000005	CIRCLIP 42X2.5	TATA spare parts
Z9023000006	OIL DAM	TATA spare parts
Z9023000007	SYNCHRONIZER	TATA spare parts
Z9023000008	RELAY LEVER	TATA spare parts
Z9023000009	SNAP RING	TATA spare parts
Z9023000010	CABLE NAT	TATA spare parts
Z9023000011	SHIFTING INTERLOCK	TATA spare parts
Z9023000012	SHIFT CYLINDER BS3	TATA spare parts
Z9023000013	VALVE	TATA spare parts
Z9023000014	SEALING RING	TATA spare parts
Z9023000015	UNION SCREW	TATA spare parts
Z9023000016	PIPE	TATA spare parts
Z9023000017	PIPE	TATA spare parts
Z9023000018	HEXAGON NUT	TATA spare parts
Z9023000019	GASKET	TATA spare parts
Z9023000020	PLANET SHAFT	TATA spare parts
Z9023000021	CABLE NAT	TATA spare parts
Z9023000022	CLUTCH BODY	TATA spare parts
Z9023000023	SYNCHRO.BODY	TATA spare parts
Z9023000024	O-RING	TATA spare parts
Z9023000025	SHAFT SEAL	TATA spare parts
Z9023000026	HEXAGON SCREW	TATA spare parts
Z9023000027	CLUTCH CYLINDER	TATA spare parts
Z9023000028	HEXAGON SCREW	TATA spare parts
Z9023000029	GEAR SHIFT HOUSING	TATA spare parts
Z9023000030	PLUG	TATA spare parts
Z9023000031	INPUT SHAFT	TATA spare parts
Z9023000033	HELICAL GEAR	TATA spare parts

Z90230000034	SWING FORK	TATA spare parts
Z90230000035	GEAR SHIFT RAIL	TATA spare parts
Z90230000036	HELICAL GEAR	TATA spare parts
Z90230000037	VALVE	TATA spare parts
Z90230000038	PIPE UNION	TATA spare parts
Z90230000039	CLUTCH BODY	TATA spare parts
ZU8878844	SUCTION PIPE ASSY	TATA spare parts
ZU8878869	OIL SPRAY BAR FRONT	TATA spare parts
ZX8878885	O-RING	TATA spare parts